

DTELDR
Load/Dump Utility for PDP-11 from
DECsystem-10 over DTE20

October 1981

DTELDR Version 4(40)
Edition 2

First Printing, March 1978
Revised, July 1980
Updated, October 1981

The information in this document is subject to change without notice and should not be construed as a commitment by Digital Equipment Corporation. Digital Equipment Corporation assumes no responsibility for any errors that may appear in this document.

The software described in this document is furnished under a license and may only be used or copied in accordance with the terms of such license.

No responsibility is assumed for the use or reliability of software on equipment that is not supplied by DIGITAL or its affiliated companies.

Copyright ©, 1978, 1980, 1981, Digital Equipment Corporation.
All Rights Reserved.

The postage-prepaid READER'S COMMENTS form on the last page of this document requests the user's critical evaluation to assist us in preparing future documentation.

The following are trademarks of Digital Equipment Corporation:

DEC	DECnet	IAS
DECUS	DECsystem-10	MASSBUS
Digital Logo	DECSYSTEM-20	PDT
PDP	DECwriter	RSTS
UNIBUS	DIBOL	RSX
VAX	EduSystem	VMS
		VT

CONTENTS

	Page
1.0 INTRODUCTION	1
2.0 COMMAND FORMAT	1
3.0 FILE SPECIFICATIONS	1
4.0 DTELDR SWITCHES	3
5.0 RUNNING DTELDR	6
INDEX	Index-1

FIGURES

FIGURE 1	Packed Mode .BIN Format	1
2	Image Mode Format	2
3	Eight-bit Image-Mode Byte	2
4	.All Diagnostics Format	2

TABLES

TABLE 1	Octal Values to use with /SWITCH	4.2
2	Speed Table (Bits 6 to 3)	5

1.0 INTRODUCTION

DTELDR is a communications utility program used to load programs from the TOPS-10 file system into a front end, and to dump front-end memory into a file on disk. DTELDR loads and dumps through the DTE20 (Data Ten-to-Eleven interface). This program runs in user mode under normal timesharing; its user must be logged in as [1,2], and have TRPSET and LOCK privileges. To use DTELDR, the TOPS-10 monitor must have been assembled with MSGSER.

2.0 COMMAND FORMAT

The format for commands to DTELDR is:

```
dev:filename.ext[p,pn, SFD, SFD, ...]/switch/switch...
```

where all entries except /switch are optional.

3.0 FILE SPECIFICATIONS

The default name for a file to load into the PDP-11 front end is:

```
DSK:DTELxy.BIN
```

where x = CPU number (0 to (n-1), where n is the number of CPUs in your system)
y = DTE number (0 to 3).


The file on which a dump is written is called:

```
DSK:DTEDxy.BIN
```

where x and y are as defined above.

Once the DTEDxy.BIN file exists, new generations .B00,.B01,...,B99 are created automatically.


There are three allowable formats for files loaded or dumped by DTELDR, packed mode, image mode and diagnostics mode. Packed mode (typically generated by MACY11/P for a PDP-11) is as follows:



MR-S-896-80

Figure 1 Packed Mode .BIN Format


Image mode is as follows:



MR-S-897-80

Figure 2 Image Mode Format

Bytes are stored one byte/word as follows:




Function Bits: Indicate that the Data Bits Contain:

00	Data or checksum
01	Starting address for loading memory
10	Leader
11	Memory field (for extended addressing)

MR-S-899-80

Figure 3 Eight-Bit Image-Mode Byte

Diagnostics mode format is as follows:



- specifies end of word: a character less than ASCII octal 75
- data blocks can be up to four characters long
- the word count specifies the number of data words only
- the checksum must be zero or an error message is returned
- ; specifies comment

MR-S-898-80

Figure 4 .All Diagnostics Format

4.0 DTELR SWITCHES

DTELR switches fall into two groups: those that initiate action such as loading or dumping, and those that modify action switches. Switches are listed below in the two groups. Switches in brackets [] are modification switches that can optionally be used with the switch specified.

Action switches are:

```
/ASWITCH
/AUTOMATIC [/DUMP, /IMAGE, /All, /NOLOG, /NODUMP, [/SELECT
           /SWITCH], /TALK]
/DDT
/DUMP [/NOLOG, /IMAGE, /All]
/EXIT
/HELP
/IGNORE
/INITIALIZE
/NOLISTEN
/RELOAD [/NOLOG, /NODUMP, /All]
/TALK
/TERMINATE
```

Modification switches are:

```
/All
/IMAGE
/NODUMP
/NOLOG
/SELECT /SWITCH
/SWITCH
```

The function of each DTELR switch is described below (switches are listed alphabetically).

<u>Switch</u>	<u>Function</u>
/All	Specifies that the binary file is in .All format encoded by diagnostics (see Section 3.0, "File Specifications").
/ASWITCH: xy:value	Uses octal value when reloading given front end automatically.
/AUTOMATIC	Automatically reloads a front end from an implied file. The file for the reload is taken from SYS:DTELRxy.BIN where x, y are as defined above. The file must exist or an error message is returned.
/DDT	Enters loaded DDT, returns with CPOPJ\$G.
/DUMP:xy	Dumps specified front end, placing dumped file on XPN:DTEDxy.BIN (or later generations .B00, .B01, etc.). x can be omitted. File extension generation numbers are automatically increased to the maximum .B99. If an attempt is made to create an additional file past this maximum, an error message is returned.
/EXIT	Exits to monitor.

<u>Switch</u>	<u>Function</u>
/HELP	Outputs the DTEHDR HELP file.
/IGNORE: xy:xy:....:xy	In automatic mode, does nothing to the given front end.
/IMAGE	Specifies that the .BIN file is in image format. The default format for a .BIN file is /PACKED.
/INITIALIZE:xy	Starts primary protocol on the specified front end. The primary protocol is used until the DECsystem-10 CPU is reloaded or a /TERMINATE command is issued; x and y are as defined above.
/NODUMP	Turns off the /DUMP switch and /RELOAD dump activity for dumping the PDP-11.
/NOLISTEN: xy:xy:....:xy	Does not listen to CTY of given front end except when reloading.
/NOLOG	Turns off the automatic error logging that is normally invoked with /RELOAD.
/RELOAD:xy	Takes dump, reloads the specified front end, starts primary protocol, and starts error logging. Dumps and error logging can be eliminated by using the /NODUMP and /NOLOG switches.
/SELECT:dev	Specifies source device from which to reload the front end.

<u>For</u>	<u>Dev</u>	<u>Reloads over</u>
KL10	10	DTE20
PDP-11 ¹	11	

¹ With SELECT:11, the /SWITCH switch must be used and no filespec can be given.

Switch	Function
/SWITCH:o	<p>Specifies (with an octal value o) the loading procedure on the unit that contains the reload file. Use this switch with /SELECT. You can use DTELDR to load any front end in your system connected over a DTE20, by giving the front end number with /RELOAD. When you load RSX20F into front-end 0, the value you give to /SWITCH specifies how KLINIT and primary protocol will be used. When you load some other front end, use /SELECT and /SWITCH to give the device and unit number of the device that contains the reload file. Use the octal values given below. Shading in Table 1 shows the functional divisions and indicates which bits are being described under "Meaning."</p>

Table 1
Octal Value to use with /SWITCH

Switches/Bits →	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
			Retry	DH11 or Boot Unit			Boot Device			Line Speed			Load Select		Switch Enable				
Octal Value	Binary Equivalent																		Meaning
000001	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1	Do a complete reload, as specified by bits 1 to 17 below. Bits 1 and 2 must be zero to run CHK11.
000005	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0	1	Load RSX20F without communicating with the central processor. KL10 is assumed up. This reloads and starts the -11, does not use KLINIT.
000007	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1	1	1	Load RSX20F, load and start KLINIT dialog to control loading.
000001	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1	To use software implementations of console speed and fill class, set these bits to zero. To use these bits to specify a physical line for the CTY, give the line speed with these bits (from Table 2), give the DH11 unit number in bits 10 to 8, and give the hardware line number within the DH11 in bits 14 to 11. You can also use these bits to give the line speed for a DL11 line specified in bits 14 to 11.
000001	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1	Use as available, floppy (for 1091) or DECTape (for all but 1091).
000201	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0	0	0	1	Use disk unit selected in bits 10 to 8.
000201	0	0	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0	1	Use unit 0 as the boot device.
000601	0	0	0	0	0	0	0	0	1	1	0	0	0	0	0	0	0	1	Use unit 1 as the boot device.
001201	0	0	0	0	0	0	0	0	1	0	1	0	0	0	0	0	0	1	Use unit 2 as the boot device.
001601	0	0	0	0	0	0	0	0	1	1	1	0	0	0	0	0	0	1	Use unit 3 as the boot device.
002201	0	0	0	0	0	0	0	1	0	0	1	0	0	0	0	0	0	1	Use unit 4 as the boot device.
002601	0	0	0	0	0	0	0	1	0	1	1	0	0	0	0	0	0	1	Use unit 5 as the boot device.
003201	0	0	0	0	0	0	0	1	1	0	1	0	0	0	0	0	0	1	Use unit 6 as the boot device.
003601	0	0	0	0	0	0	0	1	1	1	1	0	0	0	0	0	0	1	Use unit 7 as the boot device.
000001	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1	For software implementations of console line number (as for RSX20F and TOPS-10) these bits must always be zero. These bits can also give a line number for the CTY. To do so, set the line speed with bits 6 to 3, above, and give the DH11 unit number in bits 10 to 8.
000001	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1	Retry 10 times when an I/O error occurs during booting.
100001	0	0	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1	Retry indefinitely when an I/O error occurs during booting. Abort with manual intervention.
000001	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1	Always zero.

MR-S-1693-81

Table 2
Speed Table (Bits 6 to 3)

<u>Octal Value</u>	<u>Bits</u>				<u>Baud Rate</u>
	<u>6</u>	<u>5</u>	<u>4</u>	<u>3</u>	
0	0	0	0	0	zero
1	0	0	0	1	50
2	0	0	1	0	75
3	0	0	1	1	110
4	0	1	0	0	134.5
5	0	1	0	1	150
6	0	1	1	0	200
7	0	1	1	1	300
10	1	0	0	0	600
11	1	0	0	1	1200
12	1	0	1	0	1800
13	1	0	1	1	2400
14	1	1	0	0	4800
15	1	1	0	1	9600

MR-S-1694-81

NOTE

These switches can be used together in combination. To combine functions, first form the binary value, then derive the octal value to use with /SWITCH.

<u>Switch</u>	<u>Function</u>
/TALK: xy:xy:....:xy	Talk to the CTY of the given front ends.
/TERMINATE:xy	Shuts down the specified front end.

5.0 RUNNING DTELDR

To run DTELDR, you must be logged in as [1,2], have the appropriate TRPSET and LOCK privileges, and have a file containing the appropriate .BIN software. You can then enter:

```
.R DTELDR
```

The program prompts for input with a star (*):

Enter the file specification and the necessary switches. For example, to load a DN87S over DTE20 number 2 from DSK:DN8721.BIN and suppress automatic dumping, respond as follows:

```
DN8721.BIN/RELOAD:2/NODUMP
```

Once loading is complete and the -11 tells the -10 that its initialization is complete, primary protocol starts and the star (*) prompt reappears.

For automatic execution of DTELDR, the appropriate commands are normally put in the OPR.ATO file to be run by OPSER.

For example, the following sequence of commands placed in the OPR.ATO file provides for both the automatic loading of a front end at system initialization time, and for subsequent automatic reloading if the front end crashes.

```
:SLOG                log in a subjob
:DEF DTE=            call it DTE
DTE-R DTELDR         load and start DTELDR
DTE-/RELOAD:2/NODUMP load over DTE20 number 2, suppress
                    automatic dumping
DTE-/AUTO            do automatic reload (the default file
                    called DTEL02.BIN that is to be loaded
                    must exist on SYS:)
```

6.0 ERROR MESSAGES

Messages output by DTELDR occur because of hardware, software, or user error.

<u>Message</u>	<u>Cause and Corrective Action</u>
All retries failed	Hardware - verify configuration or call Field Service.
Ambiguous switch--type /H for help	User - reenter command.
Bad All format	Software or user - input file is wrong. Use another file.
Cannot specify both /All and /IMAGE	User - reenter command.
Cannot specify filespec if /SELECT:11 used	User - reenter command.
Cannot use /AUTOMATIC with /RELOAD	User - reenter command.

<u>Message</u>	<u>Cause and Corrective Action</u>
Cannot use /INITIALIZE with /RELOAD	User - reenter command.
Cannot use /TERMINATE with /RELOAD	User - reenter command.
Can't OPEN the input device	Software or user - reenter command.
Can't OPEN the output device	Software or user - reenter command.
Checksum failure	Hardware - call Field Service.
Command error--type /H for help	User - reenter command.
DAEMON CALL failure, no entry made in ERROR.SYS	Hardware - call Field Service.
DATA Checksum failure	Hardware - call Field Service.
DTE number too large	User - reenter command.
DTE. UO failed to set reload job	Hardware - call Field Service.
ENTER failed	Hardware or user - try again. You may not have the right privileges to run DTELDR.
EOF after file constant 1	Software - use another file.
EOF at start of file group	Software - use another file.
EOF during data in file group	Software - use another file.
EOF during first byte of a word	Software - use another file.
EOF during second byte of a word	Software - use another file.
EOF found when looking for checksum	Software - use another file.
ERROR CODE FROM DTE. UO	Hardware or user - call Field Service.
ERROR CODE 0 -- DTE. UO NOT IMPLEMENTED IN THIS MONITOR	Software - you cannot use DTELDR. You must obtain a monitor that supports networks.
ERROR CODE 1 -- MUST HAVE PRIVILEGES TO RUN DTELDR	User - obtain operator privileges to run DTELDR.
ERROR CODE 2 -- INTERNAL ERROR - DTE. UO CALLED WITH BAD FUNCTION NUMBER	Hardware - call Field Service.
ERROR CODE 3 -- BAD FRONT END NUMBER	User - reenter command.
ERROR CODE 4 -- PRIMARY PROTOCOL STILL RUNNING	Hardware - call Field Service.

<u>Message</u>	<u>Cause and Corrective Action</u>
ERROR CODE 5 -- -11 POWER FAIL DID NOT SET	Hardware - call Field Service.
ERROR CODE 6 -- -11 ROM PROGRAM FAILED TO START - CHECK HALT SWITCH	Hardware - check and reset HALT switch or call Field Service.
ERROR CODE 7 -- TO-10 ERROR DURING BOOTSTRAP SEQUENCE	Hardware - call Field Service.
ERROR CODE 10 -- -11 OBJECT PROGRAM FAILED TO SEND TO-10 DOORBELL	Hardware - call Field Service.
ERROR CODE 11 -- INTERNAL ERROR - BAD JOB NUMBER GIVEN TO DTE. UUU	Hardware - call Field Service.
ERROR CODE 12 -- BAD ERROR CODE FROM DTE. UUU	Hardware - call Field Service.
ERROR CODE 13 -- BAD ERROR CODE FROM DTE. UUU	Hardware - call Field Service.
ERROR CODE 14 -- BAD ERROR CODE FROM DTE. UUU	Hardware - call Field Service.
ERROR CODE 15 -- BAD ERROR CODE FROM DTE. UUU	Hardware - call Field Service.
ERROR CODE 16 -- BAD ERROR CODE FROM DTE. UUU	Hardware - call Field Service.
ERROR CODE 17 -- FAILED TO START PRIMARY PROTOCOL	Hardware - call Field Service.
ERROR DURING BOOTSTRAP SEQUENCE	Hardware - call Field Service.
ERROR DURING DUMP	Hardware - call Field Service.
ERROR - BAD JOB NUMBER GIVEN TO DTE. UUU	Hardware - call Field Service.
ERROR - DTE. UUU CALLED WITH BAD FUNCTION NUMBER	Hardware - call Field Service.
error after To-11 byte transfer	Hardware - call Field Service.
error for dump file	Hardware - call Field Service.
error while dumping	Hardware - call Field Service.
error--type /H for help	User - reenter command.
File group byte count less than 6	Hardware - call Field Service.
File group has junk instead of constant n	Hardware - call Field Service.
File zero byte count -- trying again in /IMAGE mode	Hardware, software, or user - either use another file, reenter your command, or call Field Service.

<u>Message</u>	<u>Cause and Corrective Action</u>
HIBER failure	Hardware or software - use another file or call Field Service.
Illegal address for /START	User - reenter command.
Illegal switch or switches used with /TERMINATE	User - reenter command.
Illegal switch or switches used with /INITIALIZE	User - reenter command.
Input file read error	Hardware or user - reenter command, use another file or call Field Service.
Junk after start group	Hardware - call Field Service.
Junk bits in input file	Hardware or software - use another file or call Field Service.
Junk in input file--may not be /IMAGE mode	User or software - use another file or reenter command.
LOCK failure m	System software - verify privileges.
LOCKUP failed	System software - verify privileges.
Must specify address for /START	User - reenter command.
Must specify either 10 or 11 for /SELECT	User - reenter command.
Must specify front end in /RELOAD	User - reenter command.
Must specify front end in /TERMINATE	User - reenter command.
Must specify front end number for /INITIALIZE	User - reenter command.
Must specify switch value	User - reenter command.
Only legal values for /SELECT are 10, 11	User - reenter command.
Output error for dump file	Hardware - call Field Service.
Reload source is -10, /SWITCH ignored	User - no action needed.
START BLOCK Checksum failure	Hardware - call Field Service.
STRING OUTPUT TO OPR FAILED	Hardware or software.
Timeout waiting for ll program to start	Hardware or software - try again.

<u>Message</u>	<u>Cause and Corrective Action</u>
Timeout while doing To-11 byte transfer	Hardware - call Field Service.
Timeout while waiting for dump transfer to complete	Hardware - call Field Service.
To-10 error while dumping	Hardware - call Field Service.
To-11 error after To-11 byte transfer	Hardware - call Field Service.
TRPSET failed	Software - verify your privileges.
UNKNOWN DTE. ERROR CODE	Hardware - call Field Service.
Unexpected EOF	Hardware or software - call Field Service or use another file.
Unknown switch--type /H for help	User - reenter command.
Value for /SWITCH must not exceed 177777	User - reenter command.

INDEX

.All format, 2
/All switch, 3
/ASWITCH switch, 3
Automatic mode, 3
Automatic reload, 6
/AUTOMATIC switch, 3

Command,
 /TERMINATE, 5
Command format, 1
CPU number, 1
CTY, 4, 5

Data ten-to-eleven
 interface, 1
/DDT switch, 3
DEctape source, 4.2
Default filename, 1
Device,
 reload, 4
Device unit number, 4.2
Diagnostics mode, 2
Disk,
 dual-ported, 4.2
DTE number, 1
DTE20, 1
DTELDR,
 running, 6
Dual-ported disk, 4.2
Dump memory, 1
/DUMP switch, 3

Error logging, 4
/EXIT switch, 3

File,
 OPR.ATO, 6
Filename,
 default, 1
Filename generations, 1
Floppy source, 4.2
Format,
 .All, 2
 command, 1
Front end, 1

Generations,
 filename, 1

/HELP switch, 4

/IGNORE switch, 4
Image mode, 2
/IMAGE switch, 4
Initialization,
 system, 6
/INITIALIZE switch, 4
Interface,
 Data ten-to-eleven, 1

KL10 source, 4
KLINIT switch, 4.2

Load programs, 1
Logging,
 error, 4

MACY11/P, 1
Memory,
 dump, 1
Mode,
 automatic, 3
 diagnostics, 2
 image, 2
 packed, 1

/NODUMP switch, 4
/NOLISTEN switch, 4
/NOLOG switch, 4
Number,
 CPU, 1
 device unit, 4.2
 DTE, 1

INDEX (CONT.)

Octal Value Table, 4.2
 OPR.ATO file, 6
 OPSER program, 6

 Packed mode, 1
 PDP-11 source, 4
 Primary protocol, 4, 6
 Privileges,
 TOPS-10, 1
 Program,
 OPSER, 6
 Programs,
 load, 1
 Protocol,
 primary, 4, 6

 Reload,
 automatic, 6
 Reload device, 4
 /RELOAD switch, 4
 RSX-20F, 4.2
 Running DTELDR, 6

 /SELECT switch, 4
 Source,
 DEctape, 4.2
 floppy, 4.2
 KL10, 4
 PDP-11, 4

 Speed Table, 5
 Switch,
 /All, 3
 /ASWITCH, 3
 /AUTOMATIC, 3
 /DDT, 3
 /DUMP, 3
 /EXIT, 3
 /HELP, 4
 /IGNORE, 4
 /IMAGE, 4
 /INITIALIZE, 4
 KLINIT, 4.2
 /NODUMP, 4
 /NOLISTEN, 4
 /NOLOG, 4
 /RELOAD, 4
 /SELECT, 4
 /SWITCH, 4.1
 /TALK, 5
 /TERMINATE, 5
 /SWITCH switch, 4.1
 Switches, 3
 System initialization, 6
 /TALK switch, 5
 Ten-to-eleven interface,
 Data, 1
 /TERMINATE command, 4
 /TERMINATE switch, 5
 TOPS-10 privileges, 1

 Unit number,
 device, 4.2