

# DUP11

CONFIDENCE TEST  
MD-11-DZDPE-A

EP-DZDPE-A-DL-A  
COPYRIGHT © 1976  
FICHE 1 OF 1

NOV 1976  
**digital**  
MADE IN USA

Frame 1	Frame 2	Frame 3	Frame 4
Frame 5	Frame 6	Frame 7	Frame 8
Frame 9	Frame 10	Frame 11	Frame 12
Frame 13	Frame 14	Frame 15	Frame 16
Frame 17	Frame 18	Frame 19	Frame 20
Frame 21	Frame 22	Frame 23	Frame 24
Frame 25	Frame 26	Frame 27	Frame 28
Frame 29	Frame 30	Frame 31	Frame 32
Frame 33	Frame 34	Frame 35	Frame 36
Frame 37	Frame 38	Frame 39	Frame 40



45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55  
56  
57  
58  
59  
60  
61  
62  
63  
64  
65  
66  
67  
68  
69  
70  
71  
72  
73  
74  
75  
76  
77  
78  
79  
80  
81  
82  
83  
84  
85

1.0 ABSTRACT

THE FUNCTION OF THE MAINDEC IS TO PROVIDE A LEVEL OF CONFIDENCE IN THE OPERATION OF THE DUP-11 WITHOUT CHANGING JUMPERS OR SWITCHES FROM CUSTOMER CONFIGURATION.

THE OPTION IS TESTED IN SOLC MODE (BIT-STUFFING), THEN IN DEC MODE USING A SIMULATED DDCMP-LINE PROTOCOL WITH AN IMBEDDED CRC CHARACTER. BOTH OF THESE MODES WILL BE TESTED OVER A CABLE IF A TURNAROUND IS POSSIBLE.

THE MODEM CONTROL LEADS WILL ALSO BE TESTED, IF THE DUP-11 IS CONFIGURED CORRECTLY. THE DETERMINATION OF WHAT WILL BE TESTED IS DONE BY ANSWERING A "PARAMETER DIALOG" (LOAD ADDRESS 200, START ADDRESS 0 OR 1.) ALL QUESTIONS MUST BE ANSWERED. IF AN ERROR SHOULD OCCUR, A TYPEOUT WILL EXPLAIN THE FUNCTIONAL AREA OF THE DEVICE WHICH FAILED. TO REPAIR THE OPTION, THE DIAGNOSTICS WILL HAVE TO BE RUN.

CURRENTLY THERE ARE THREE OFF-LINE DIAGNOSTICS THAT ARE TO BE RUN IN SEQUENCE TO ENSURE THAT IF AN ERROR SHOULD OCCUR IT WILL BE DETECTED AT AN EARLY STAGE AND ESTABLISH THAT DIAGNOSIS OF THE ERROR WILL BE IMMEDIATE TO DISCOVERING THE PROBLEM.

NOTE: ADDITIONAL DIAGNOSTICS MAY BE ADDED IN THE FUTURE.

THE THREE DIAGNOSTICS ARE:

1. DZDPB (REV) BASIC AND OFFLINE TRANSMITTER TESTS.
2. DZDPC (REV) OFFLINE RECEIVER TESTS, MODEM CONTROL AND INTERRUPT TESTS
3. DZDPD (REV) OFFLINE SOLC DATA AND FUNCTION OFFLINE DECMODE DATA AND FUNCTION TESTS

NOTE: THE FOURTH TAPE IS:

4. DZDPE (REV) THIS CONFIDENCE TEST.

108  
109  
110  
111  
112  
113  
114  
115  
116  
117  
118  
119  
120  
121  
122  
123  
124  
125  
126  
127  
128  
129  
130  
131  
132  
133  
134  
135

2.0 REQUIREMENTS

2.1 EQUIPMENT

ANY PDP11 FAMILY CPU (WITH MINIMUM 4K MEMORY)  
ASR 33 (OR EQUIVALENT)  
DUP11

2.2 STORAGE

PROGRAM WILL USE ALL 4K OF MEMORY EXCEPT WHERE ABS AND BOOTSTRAP LOADER RESIDE. LOCATION 1500 THRU 1560 ARE ESPECIALLY TO BE NOTED AND LEFT UNTOUCHED BY THE OPERATOR AFTER THE DUP11 PARAMETER DIALOG HAS BEEN EXECUTED OR AFTER THE DEFAULT SETUP HAS BEEN DONE.

3.0 LOADING PROCEDURE

3.1 METHOD

ALL PROGRAMS ARE IN ABSOLUTE FORMAT AND ARE LOADED USING THE ABSOLUTE LOADER. NOTE: IF THE DIAGNOSTICS ARE ON A MEDIA SUCH AS DISK, MAGTAPE, DECTAPE, OR CASSETTE FOLLOW INSTRUCTIONS FOR THE MONITOR WHICH HAS BEEN PROVIDED ON THAT SPECIFIC MEDIA.

ABSOLUTE LOADER STARTING ADDRESS = \*+500

MEMORY	SIZE
	(#)=
4K	17
8K	37
12K	57
16K	77
20K	117
24K	137
28K	157

3.1.1 PLACE ADDRESS OF ABS LOADER INTO SWITCH REGISTER. (ALSO PLACE 'HALT' SW UP)

3.1.2 DEPRESS 'LOAD ADDRESS' KEY ON CONSOLE AND RELEASE.

3.1.3 DEPRESS 'START KEY' ON CONSOLE AND RELEASE (PROGRAM SHOULD NOW BE LOADING INTO CPU)

136  
137  
138  
139  
140  
141  
142  
143  
144  
145  
146  
147  
148  
149  
150  
151  
152  
153  
154  
155  
156  
157  
158  
159  
160  
161  
162  
163  
164  
165  
166  
167  
168  
169  
170  
171  
172  
173  
174  
175  
176  
177  
178  
179  
180  
181  
182  
183  
184  
185  
186  
187  
188  
189  
190  
191

4.0 STARTING PROCEEDURE

- A. SET SWITCH REGISTER TO 000200
- B. DEPRESS 'LOAD ADDRESS' KEY AND RELEASE
- C. LEAVE SWR BIT 7=1 TO USE EXISTING PARAMETERS PREVIOUSLY SET UP BY THE DUP11 PARAMETER DIALOG. SET SWR 0 OR 1 TO GO THROUGH THE PARAMETER DIALOG. (\*)
- D. DEPRESS 'START KEY' AND RELEASE. THE PROGRAM WILL TYPE MAINDEC NAME AND PROGRAM NAME (IF THIS WAS THE FIRST START UP OF THE PROGRAM) AND ALSO THE FOLLOWING:

'EXAMPLE'

'MAP OF DUP11 STATUS'

1500	160050	CSR OF DUP11
1502	000300	VECTOR OF DUP11

THE ABOVE IS ONLY AN EXAMPLE! 'THIS WOULD INDICATE THE STATUS TABLE STARTING AT ADDRESS 1500 IN THE PROGRAM. THE STATUS TABLE MUST BE VERIFIED BY THE USER.

IT IS POSSIBLE FOR THE OPERATOR TO MANUALLY CHANGE (TOGGLE IN) THE INFORMATION IN THE MAP TO SUIT A SPECIFIC CONFIGURATION, BUT THE RESPONSIBILITY FOR VERIFYING THAT INFORMATION RESTS WITH THE OPERATOR.

THE PROGRAM WILL TYPE 'R' AND PROCEED TO RUN THE MAINDEC

4.1 CONTROL SWITCH SETTINGS

SW 15	SET:	HALT ON ERROR
SW 14	SET:	LOOP ON CURRENT TEST
SW 13	SET:	INHIBIT ERROR PRINT OUT
SW 12	SET:	INHIBIT TYPE OUT/BELL ON ERROR.
SW 11	SET:	INHIBIT ITERATIONS. (QUICK PASS)
SW 10	SET:	ESCAPE TO NEXT TEST ON ERROR
SW 09	SET:	RESERVED
SW 08	SET:	CATCH ERROR AND LOOP ON IT
SW 07	SET:	'USE PREVIOUS STATUS TABLE.
SW 06	SET:	RESERVED
SW 05	SET:	RESERVED
SW 04	SET:	RESERVED
SW 03	SET:	RESERVED
SW 02	SET:	LOCK ON SELECTED TEST
SW 01	SET:	RESTART PROGRAM AT SELECTED TEST
SW 00	SET:	ENTER PARAMETERS USING MANUAL DIALOG

-----  
(\* ) THIS MUST BE DONE EVERY TIME A NEW DEVICE IS TESTED.

F01

DZDPE-A MACY11 27(732) 21-OCT-76 16:11 PAGE 6  
DZDPER.CMB

192

PARAMETERS MUST BE CHANGED TO TEST MORE THAN ONE DEVICE.

193  
194  
195  
196  
197  
198  
199  
200  
201  
202  
203  
204  
205  
206  
207  
208  
209  
210  
211  
212  
213  
214  
215  
216  
217  
218  
219  
220  
221  
222  
223  
224  
225  
226  
227  
228  
229  
230  
231  
232  
233  
234  
235  
236  
237  
238  
239  
240  
241

SWITCHES 8 THROUGH 15 ARE DYNAMIC AND SHOULD BE USED AS NEEDED IN THE DIAGNOSTIC. SWITCHES 0 THROUGH 2 ARE STATIC (ONLY ARE OPERABLE WHEN THE MONITOR PORTION OF THE TAPE IS RUNNING) AND SHOULD BE SET UP PRIOR TO STARTING OR RESTARTING THE DIAGNOSTIC.

#### 4.1.2 SWITCH REGISTER RESTRICTIONS

SW 01 RESTART PROGRAM AT SELECTED TEST. IT IS STRONGLY SUGGESTED THAT AT LEAST ONE PASS HAS BEEN MADE BEFORE TRYING TO SELECT A TEST THAT IS NOT IN THE ORDER OF SEQUENCE. THE REASON FOR THIS IS THAT THE PROGRAM HAS TO CLEAR AREAS AND SET UP PARAMETERS IN THE MONITOR PORTION OF THE PROGRAM. IT IS POSSIBLE TO LD200, AND RAISE SW01, THEN START, PROVIDED PARAMETERS HAVE BEEN PREVIOUSLY SET UP AS DESCRIBED IN SECTION 4.0. ALSO, WHEN A TEST IS SELECTED, ALWAYS START AT THE VERY BEGINNING OF THAT TEST.

#### 4.1.3 SWITCH REGISTER PRIORITIES

##### A) ERROR SWITCHES

1. SW 12 DELETE PRINT OUT/BELL ON ERROR.
2. SW 13 DELETE ERROR PRINTOUT.
3. SW 15 HALT ON THE ERROR.
4. SW 08 GOTO BEGINNING OF THE TEST(ON ERROR).
5. SW 10 GOTO NEXT TEST(ON ERROR).

##### B) SCOPE SWITCHES

1. SW 14 - LOOP ON TEST. WILL LOOP ON TEST UNTIL SWITCH IS LOWERED.
2. SW 11 - INHIBIT ITERATIONS (QUICK PASS). ALLOWS ONLY ONE PASS THROUGH A TEST.

#### 4.2 STARTING ADDRESS

STARTING ADDRESS IS AT 000200. THERE ARE NO OTHER STARTING ADDRESSES FOR THE DUP11 DIAGNOSTICS OR THIS EXERCISER.

NOTE: IF ADDRESS 000042 IS NON-ZERO THE PROGRAM ASSUMES IT IS UNDER ACT11 OR XXDP CONTROL AND WILL ACT ACCORDINGLY. AFTER DUP11 IS TESTED, THE PROGRAM WILL RETURN TO 'XXDP' OR 'ACT-11'.

242  
243  
244  
245  
246  
247  
248  
249  
250  
251  
252  
253  
254  
255  
256  
257  
258  
259  
260  
261  
262  
263  
264  
265  
266  
267  
268  
269  
270  
271  
272  
273  
274  
275  
276  
277  
278  
279  
280  
281  
282  
283  
284  
285  
286

5.0 OPERATING PROCEDURE

WHEN THE PROGRAM IS INITIALLY STARTED MESSAGES AS DESCRIBED IN SECTION FOUR WILL BE PRINTED AND PROGRAM WILL BEGIN RUNNING THE DIAGNOSTIC.

5.1 PROGRAM AND/OR OPERATOR ACTION

THE TYPICAL APPROACH SHOULD BE

1. HALT ON ERROR (VIA SW 15=1) WHENEVER AN ERROR OCCURS.
2. CLEAR SW 15.

THE TEST NUMBER AND PC WILL BE TYPED OUT AND POSSIBLY AN ERROR MESSAGE (THIS DEPENDS ON THE TEST), TO GIVE THE OPERATOR AN IDEA AS TO THE SOURCE OF THE PROBLEM. IF IT IS NECESSARY TO KNOW MORE INFORMATION CONCERNING THE ERROR REPORT, LOOK IN THE LISTING FOR THAT TEST NUMBER WHICH WAS TYPED OUT AND THEN NOTE THE PC OF THE ERROR REPORT. IN THIS WAY THE EXACT FUNCTIONING OF THE TEST CAN BE INTERPRETED SINCE THE ERROR PC IS THE HLT+2 LOCATION.

AT THIS POINT IT IS RECOMMENDED THAT THE NORMAL DIAGNOSTICS BE RUN TO ISOLATE THE ERROR CONDITION.

6.0 ERRORS

AS DESCRIBED PREVIOUSLY THERE WILL ALWAYS BE A TEST NUMBER AND PC TYPED OUT AT THE TIME OF AN ERROR (PROVIDING SW 13=0 AND SW 12=0). ADDITIONAL INFORMATION WILL BE SUPPLIED TO THE ERROR MESSAGE WHICH IS TO GIVE THE OPERATOR AN INDICATION OF THE ERROR.

6.1 ERROR RECOVERY

IF FOR SOME REASON THE DUPI1 SHOULD 'HANG THE BUS' (GAIN CONTROL OF BUS SO THAT CONSOLE MANUAL FUNCTIONS ARE INHIBITED) AN INIT OR POWER DOWN/UP IS NECESSARY FOR OPERATOR TO REGAIN CONTROL OF CPU. IF THIS SHOULD HAPPEN LOOK IN LOCATION 'TSTNO' FOR THE NUMBER OF THE TEST THAT WAS RUNNING AT THE TIME OF THE CATASTROPHIC ERROR. THIS GIVES THE OPERATOR SOME IDEA AS TO WHAT THE DUPI1 WAS DOING AT THE TIME OF THE ERROR.

287  
288  
289  
290  
291  
292  
293  
294  
295  
296  
297  
298  
299  
300  
301  
302  
303  
304  
305  
306  
307  
308  
309  
310  
311  
312  
313  
314  
315  
316  
317  
318  
319  
320  
321  
322  
323  
324  
325  
326  
327  
328  
329  
330  
331  
332  
333  
334

## 7.0 RESTRICTIONS

## 7.1 STARTING RESTRICTIONS

SEE SECTION 4 (PLEASE). STATUS TABLE SHOULD BE VERIFIED REGARDLESS OF HOW THE PROGRAM WAS STARTED.

## 7.2 OPERATING RESTRICTIONS

DUPI1 PARAMETER DIALOG MUST BE ANSWERED BEFORE RUNNING THIS MAINDEC. THERE ARE NO DEFAULT PARAMETERS FOR THIS MAINDEC. IF MORE THAN ONE DEVICE IS TO BE TESTED THERE ARE TWO OPTIONS FOR THE USER:

1. ANSWER THE COMPLETE PARAMETER DIALOG AGAIN.
2. TOGGLE IN THE NEW CSR AT 1500 AND THE VECTOR AT 1502, THEN RESTART THE PROGRAM WITH SW07=1.

## 8.0 MISCELLANEOUS

## 8.1 EXECUTION TIME

ALL DUPI1 DEVICE DIAGNOSTICS WILL GIVE AN 'END PASS' MESSAGE (PROVIDING NO ERRORS AND SW12=0) WITHIN 4 MINS. THIS IS ASSUMING SW11=1 (DELETE ITERATIONS) IS SET TO GIVE THE FASTEST POSSIBLE EXECUTION. THE ACTUAL EXECUTION TIME DEPENDS GREATLY ON THE PDP11 CPU CONFIGURATION.

## 8.2 PASS COMPLETE

NOTE: \*EVERY\* TIME THE PROGRAM IS STARTED, THE TESTS WILL RUN AS IF SW11 (DELETE ITERATIONS) WAS UP (=1). THIS IS TO VERIFY NO \*HARD\* ERRORS AS SOON AS POSSIBLE. THEREFORE THE FIRST PASS--EACH TIME PROGRAM IS STARTED--WILL BE A 'QUICK PASS' UNTIL ALL DUPI1'S IN SYSTEM ARE TESTED. WHEN THE DIAGNOSTIC HAS COMPLETED A PASS WITH THE NORMAL ITERATION COUNT (ICOUNT=50), THE FOLLOWING IS AN EXAMPLE OF THE PRINT OUT TO BE EXPECTED.

END PASS DZDPBA CSR:160050 VEC:300 PASSES:000001 ERRORS:000000

NOTE: THE NUMBERS FOR CSR AND VEC ARE NOT NECESSARILY THE VALUES FOR THE DEVICE. THEY ARE ONLY FOR THIS EXAMPLE.

335  
336  
337  
338  
339  
340  
341  
342  
343  
344  
345  
346  
347  
348  
349  
350  
351  
352  
353  
354  
355  
356  
357  
358  
359  
360  
361  
362  
363  
364  
365  
366  
367  
368  
369  
370  
371  
372  
373  
374  
375  
376  
377  
378  
379  
380  
381  
382  
383  
384

8.3 KEY LOCATIONS

RETURN           CONTAINS THE ADDRESS WHERE PROGRAM WILL RETURN WHEN ITERATION COUNT IS REACHED OR IF LOOP ON TEST IS ASSERTED.

NEXT             CONTAINS THE ADDRESS OF THE NEXT TEST TO BE PERFORMED.

TSTNO            CONTAINS THE NUMBER OF THE TEST NOW BEING PERFORMED.

RUN              THE BIT IN 'RUN' ALWAYS POINTS ONE PAST THE DUP11 CURRENTLY BEING TESTED.

DUPCR00-DUPCR07  
(1500)-(1560)    THESE LOCATIONS CONTAIN THE INFORMATION NEEDED TO TEST UP TO 8 (DECIMAL) DUP11S SEQUENTIALLY (USED ONLY IN THE DIAGNOSTICS, NOT IN THIS CONFIDENCE TEST). THEY CONTAIN THE CSR, VECTOR AND STATUS CONCERNING THE CONFIGURATION OF EACH DUP11.

RXCSR            CONTAINS THE RECEIVER CSR OF THE DUP11 UNDER TEST.

8.4 MORE ON THAT 'STATUS TABLE' (1500-1560)

'MAP OF DUP11 STATUS'

	1500	160050	
	1502	000300	
1500	160050	THIS IS THE SYSTEM CONTROL REGISTER FOR THE 1ST DUP11 IN THE SYSTEM.	
1502	000300	THIS IS VECTOR 'A' FOR THE FIRST DUP11 IN THE SYSTEM.	

THE ABOVE IS REPEATED FOR EACH DUP11 IN THE SYSTEM. THE TABLE IS FILLED BY THE MANUAL PARAMETER INPUT AS DESCRIBED PREVIOUSLY. ALSO, IF DESIRED BY THE USER - THE LOCATIONS MAY BE ALTERED BY HAND (TOGGLED IN) TO SUIT THE SPECIFIC CONFIGURATION, THUS MAKING EACH DEVICE MAP DIFFERENT. IT IS THE RESPONSIBILITY OF THE OPERATOR TO VERIFY THE DATA IN THE MAP.

2

# K01

DZDPE-A MACY11 27(732) 21-OCT-76 16:11 PAGE 11  
DZDPEA.CMB INTRODUCTION TO DUP11 DIAGNOSTIC

385  
386  
387  
388  
389  
390  
391  
392  
393  
394  
395  
396  
397  
398  
399  
400  
401  
402  
403  
404  
405  
406  
407  
408  
409  
410  
411  
412  
413  
414  
415  
416  
417  
418

```
;*MAINDEC-11-DZDPE-A /<377>/DUP11 QUICK-VERIFY EXERCISER  
;*COPYRIGHT 1975, DIGITAL EQUIPMENT CORP., MAYNARD, MASS. 01754  
*-----
```

```
;STARTING PROCEDURE  
;LOAD PROGRAM  
;LOAD ADDRESS 000200  
;PRESS START  
;PROGRAM WILL TYPE "MAINDEC-11-DZDPE-A /<377>/DUP11 QUICK-VERIFY EXERCISER "  
;PROGRAM WILL TYPE "R" TO INDICATE THAT TESTING HAS STARTED  
;AT THE END OF A PASS, PROGRAM WILL TYPE PASS COMPLETE MESSAGE  
;AND THEN RESUME TESTING
```

```
;SWITCH REGISTER OPTIONS  
-----
```

100000  
040000  
020000  
010000  
004000  
002000  
001000  
000400  
000200  
000100  
000040  
000020  
000010  
  
000004  
000002  
000001

SW15=100000  
SW14=40000  
SW13=20000  
SW12=10000  
SW11=4000  
SW10=2000  
SW09=1000  
SW08=400  
SW07=200  
SW06=100  
SW05=40  
SW04=20  
SW03=10  
  
SW02=4  
SW01=2  
SW00=1

```
=1, HALT ON ERROR  
=1, LOOP ON CURRENT TEST  
=1, INHIBIT ERROR TYPEOUT  
=1, DELETE TYPEOUT/BELL ON ERROR.  
=1, INHIBIT ITERATIONS  
=1, ESCAPE TO NEXT TEST ON ERROR  
=1, LOOP WITH CURRENT DATA  
=1, LOOP ON ERROR
```

```
;SELECT DUP'S DESIRED ACTIVE  
;NOTE: THIS MUST NOT EXCEED ORIGINAL COUNT  
;LOCK ON TEST SELECT  
;RESTART PROGRAM AT SELECTED TEST  
;ENTER PARAMETERS
```

```

419
420
421          ;REGISTER DEFINITIONS
422          ;-----
423
424          000000          R0=%0          ;GENERAL REGISTER
425          000001          R1=%1          ;GENERAL REGISTER
426          000002          R2=%2          ;GENERAL REGISTER
427          000003          R3=%3          ;GENERAL REGISTER
428          000004          R4=%4          ;GENERAL REGISTER
429          000005          R5=%5          ;GENERAL REGISTER
430          000006          SP=%6         ;PROCESSOR STACK POINTER
431          000007          PC=%7         ;PROGRAM COUNTER
432
433          ;LOCATION EQUIVALENCIES
434          ;-----
435
436          177776          PS=177776      ;PROCESSOR STATUS WORD
437          001150          STACK=1150     ;START OF PROCESSOR STACK
438
439          ;INSTRUCTION DEFINITIONS
440          ;-----
441
442          005746          PUSH1SP=5746    ;DECREMENT PROCESSOR STACK 1 WORD
443          005726          POP1SP=5726     ;INCREMENT PROCESSOR STACK 1 WORD
444          010046          PUSHRO=10046    ;SAVE R0 ON STACK
445          012600          POPRO=12600     ;RESTORE R0 FROM STACK
446          024646          PUSH2SP=24646  ;DECREMENT STACK TWICE
447          022626          POP2SP=22626   ;INCREMENT STACK TWICE
448          .EQUIV EMT,HLT ;BASIC DEFINITION OF ERROR CALL
449
450
451          100000          BIT15=100000
452          040000          BIT14=40000
453          020000          BIT13=20000
454          010000          BIT12=10000
455          004000          BIT11=4000
456          002000          BIT10=2000
457          001000          BIT9=1000
458          000400          BIT8=400
459          000200          BIT7=200
460          000100          BIT6=100
461          000040          BIT5=40
462          000020          BIT4=20
463          000010          BIT3=10
464          000004          BIT2=4
465          000002          BIT1=2
466          000001          BIT0=1
467
468

```

# MO1

DZDPE-A MACY11 27(732) 21-OCT-76 16:11 PAGE 13  
 DZDPEA.CMB TRAPCATCHER FOR UNEXPECTED INTERRUPTS

```

469 ;*****
470 ;-----
471 ; TRAPCATCHER FOR ILLEGAL INTERRUPTS
472 ; THE STANDARD "TRAP CATCHER" IS PLACED
473 ; BETWEEN ADDRESS 0 TO ADDRESS 776.
474 ; IT LOOKS LIKE "PC+2 HALT".
475 ;-----
476 ;*****
477
478 000000 . =0
479 ; STANDARD INTERRUPT VECTORS
480 ;-----
481
482 . =24
483 000024 004614 .PFAIL ; POWER FAIL HANDLER
484 000026 000340 340 ; SERVICE AT LEVEL 7
485 000030 004232 .HLT ; ERROR HANDLER
486 000032 000340 340 ; SERVICE AT LEVEL 7
487 000034 004200 .TRPSRV ; GENERAL HANDLER DISPATCH SERVICE
488 000036 000340 340 ; SERVICE AT LEVEL 7
489
490 . =40
491 000040 000000 0 ; SAVE FOR ACT-11 OR DDP2
492 000042 000000 0 ; RETURN ADDRESS IF UNDER ACT-11 OR DDP2
493 000044 000000 0 ; SAVE FOR ACT-11 OR DDP2
494 000046 002766 $ENDAD ; FOR USE WITH ACT-11 OR DDP2
495 000052 000000 0 ; ACT-11 PROGRAM CHARACTERISTICS
496
497 . =174
498 000174 000000 DISPREG: 0 ; SOFTWARE DISPLAY REGISTER
499 000176 000000 SWREG: 0 ; SOFTWARE SWITCH REGISTER
500 . =200
501 000200 000137 001562 JMP .START ; GO TO START OF PROGRAM
502
503
504 . =1000
505 001000 005377 040515 047111 MTITLE: .ASCIZ <377><12>/MAINDEC-11-DZDPE-A /<377>/DUP11 QUICK-VERIFY EXERCISER /<377>
506 (2) 001200
507 . =1200
508 ; SWR AND LIGHTS
509 ;-----
510 001200 177570 DISPLAY: 177570 ; 11/45 CONSOLE LIGHTS
511 001202 177570 SWR: 177570 ; INDIRECT POINTER TO SWITCH REGISTER
512
513 ; INDIRECT POINTERS TO TELETYPE VECTORS AND REGISTERS
514 ;-----
515
516 001204 177560 TKCSR: 177560 ; TELETYPE KEYBOARD CONTROL REGISTER
517 001206 177562 TKDBR: 177562 ; TELETYPE KEYBOARD DATA BUFFER
518 001210 177564 TPCSR: 177564 ; TELEPRINTER CONTROL REGISTER
519 001212 177566 TPDBR: 177566 ; TELEPRINTER DATA BUFFER
520
521 ; PROGRAM CONTROL PARAMETERS
522 ;-----
523

```

524	001214	000000	RETURN:	0	: SCOPE ADDRESS FOR LOOP ON TEST
525	001216	000000	NEXT:	0	: ADDRESS OF NEXT TEST TO BE EXECUTED
526	001220	000000	LOCK:	0	: ADDRESS FOR LOCK ON CURRENT DATA
527	001222	000001	ICOUNT:	1	: NUMBER OF ITERATIONS THAT CURRENT TEST WILL BE EXECUTED
528	001224	000000	LPCNT:	0	: NUMBER OF ITERATIONS COMPLETED
529	001226	000000	TSTNO:	0	: NUMBER OF TEST IN PROGRESS
530	001230	000000	PASCNT:	0	: NUMBER OF PASSES COMPLETED
531	001232	000000	ERRCNT:	0	: TOTAL NUMBER OF ERRORS
532	001234	000000	LSTERR:	0	: PC OF LAST ERROR CALL
533					
534					
535			; PROGRAM CONTROL FLAGS		
536			:-----		
537					
538	001346	000	INIFLG:	.BYTE 0	: PROGRAM INITIALIZATION FLAG
539	001347	000	ERRFLG:	.BYTE 0	: ERROR OCCURED FLAG
540	001350	000	LOKFLG:	.BYTE 0	: LOCK ON CURRENT TEST FLAG
541	001351	000	QV.FLG:	.BYTE 0	: QUICK VERIFY FLAG.
542					: ON FIRST PASS OF EACH DUPL1 ITERATIONS
543					: WILL BE SUPPRESSED
544			.EVEN		

545  
546  
547  
548  
549  
550  
551  
552  
553  
554  
555  
556  
557  
558  
559  
560  
561  
562  
563  
564  
565  
566  
567  
568  
569  
570  
571  
572  
573  
574  
575  
576

;DEFINITIONS FOR TRAP SUBROUTINE CALLS  
;POINTERS TO SUBROUTINES CAN BE FOUND  
;IN THE TABLE IMMEDIATELY FOLLOWING THE DEFINITIONS

```

:*****
:-----
:TRPTAB:
SCOPE=TRAP+0 ;CALL TO SCOPE LOOP AND ITERATION HANDLER
      .SCOPE
SCOPI=TRAP+1 ;CALL TO LOOP ON CURRENT DATA HANDLER
      .SCOPI
TYPE=TRAP+2 ;CALL TO TELETYPE OUTPUT ROUTINE
      .TYPE
INSTR=TRAP+3 ;CALL TO ASCII STRING INPUT ROUTINE
      .INSTR
INSTER=TRAP+4 ;CALL TO INPUT ERROR HANDLER
      .INSTER
PARAM=TRAP+5 ;CALL TO NUMERICAL DATA INPUT ROUTINE
      .PARAM
SAVOS=TRAP+6 ;CALL TO REGISTER SAVE ROUTINE
      .SAVOS
RESOS=TRAP+7 ;CALL TO REGISTER RESTORE ROUTINE
      .RESOS
CONVRT=TRAP+10 ;CALL TO DATA OUTPUT ROUTINE
      .CONVRT
CNVRT=TRAP+11 ;CALL TO DATA OUTPUT ROUTINE WITHOUT CR/LF.
      .CNVRT
SETFLG=TRAP+12 ;CALL TO TELETYPE INPUT ROUTINE
      .SETFLG
:-----
:*****

```

```

577                                     ;DUPI1 VECTOR AND REGISTER INDIRECT POINTERS
578
579 001400 000000 DUPRVC: 0 ; POINTER TO DUPI1 RECEIVER INTERRUPT VECTOR
580 001402 000000 DUPRPS: 0 ; POINTER TO DUPI1 RECEIVER INTERRUPT SERVICE PS
581 001404 000000 DUPTVC: 0 ; POINTER TO DUPI1 TRANSMITTER INTERRUPT VECTOR
582 001406 000000 DUPTPS: 0 ; POINTER TO DUPI1 TRANSMITTER INTERRUPT SERVICE PS
583 001410 000000 RXCSR: 0 ; POINTER TO DUPI1 RECEIVER STATUS REGISTER
584 001412 000000 RXDBUF: 0 ; POINTER TO DUPI1 RECEIVER DATA BUFFER
585 001414 000000 PARCSR: 0 ; POINTER TO DUPI1 PARAMETER STATUS REGISTER
586 001416 000000 TXCSR: 0 ; POINTER TO DUPI1 TRANSMITTER STATUS REGISTER
587 001420 000000 TXDBUF: 0 ; POINTER TO DUPI1 TRANSMITTER DATA BUFFER
588 001422 000000 DUPSEC: 0 ; POINTER TO DUPI1 SECONDARY REGISTER SELECT REGISTER
589 001424 000000 HUPPSR: 0 ; POINTER TO PARAMETER STATUS HIGH BYTE
590 001426 000000 HUPRBF: 0 ; POINTER TO RECEIVER BUFFER HIGH BYTE
591 001430 000000 HUPRCR: 0 ; POINTER TO RECEIVER CONTROL REG HIGH BYTE
592 001432 000000 HUPTBF: 0 ; POINTER TO TRANSMITTER BUFFER HIGH BYTE
593 001434 000000 HUPTCR: 0 ; POINTER TO TRANSMITTER CONTROL REG HIGH BYTE
594
595                                     ;DUPI1 CONTROL INDICATORS FOR CURRENT DUPI1 UNDER TEST
596 -----
597
598 001436 000 MASK.A: .BYTE 000 ; LAST CHAR TO TEST AND PARITY MASK
599 001437 010 CLK.A: .BYTE 8. ; NUMBER OF CLOCKS NEEDED FOR ONE CHAR
600 001440 000000 LDD.OO: 000000 ; PARAMETERS
601
602
603
604
605
606
607

```

```

608
609
610
611
612
613
614
615
        ;PROGRAM INITIALIZATION
        ;LOCK OUT INTERRUPTS
        ;SET UP PROCESSOR STACK
        ;SET UP POWER FAIL VECTOR
        ;CLEAR PROGRAM CONTROL FLAGS AND COUNTS
        ;TYPE TITLE MESSAGE
616 001562 012737 000340 177776 .START: MOV      #340,PS          ;LOCK OUT INTERRUPTS
617 001570 012706 001150          MOV      #STACK,SP      ;SET UP STACK
618 001574 012737 004614 000024 MOV      #.PFAIL,#24    ;SET UP POWER FAIL VECTOR
619 001602 113737 001311 001313 MOVVB   DUPNUM,SAVNUM    ;SAVE NUMBER OF DEVICES IN SYSTEM
620 001610 005037 001230          CLR      PASCNT         ;CLEAR PASS COUNT
621 001614 105037 001347          CLRB   ERRFLG          ;CLEAR ERROR FLAG
622 001620 105037 001351          CLRB   QV.FLG         ;ZERO QUICK VERIFY FLAG
623 001624 012737 001500 001316 MOV      #DUP.MAP,CREAM ;GET MAP POINTER.
624 001632 112737 000001 001314 MOVVB   #1,RUN          ;POINT POINTER TO FIRST DEVICE.
625 001640 005037 001232          CLR      ERRCNT        ;CLEAR ERROR COUNT
626 001644 005037 001234          CLR      LSTERR        ;CLEAR LAST ERROR POINTER
627 001650 012737 000001 001226 MOV      #1,TSTNO       ;SET UP FOR TEST 1
628 001656 012737 001562 001214 MOV      #.START,RETURN ;SET UP FOR POWER FAIL BEFORE
629
630 001664 013746 000006          MOV      #2#6,-(SP)     ;SAVE CURRENT VECTORS
631 001670 013746 000004          MOV      #2#4,-(SP)
632 001674 012737 001710 000004 MOV      #12#,#2#4
633 001702 005777 177274          TST     #SWR           ;SETUP FOR TIMEOUT
634 001706 000407          BR      13$           ;REFERENCE HARDWARE SWITCH REG
635 001710 012737 000176 001202 12$: MOV      #SWREG,SWR      ;BR IF IT EXISTS
636 001716 012737 000174 001200 MOV      #DISPREG,DISPLAY ;POINT TO SOFT SWR
637 001724 022626          CMP     (SP)+,(SP)+    ;POINT TO SOFT DISPLAY REG
638 001726 012637 000004 13$: MOV      (SP)+,#2#4    ;ADJUST STACK
639 001732 012637 000006          MOV      (SP)+,#2#6    ;RESTORE VECTORS
640 001736 105737 001346          TSTB   INIFLG         ;HAS INITIALIZATION BEEN PERFORMED
641 001742 001010          BNE    6$
642 001744 022737 002766 000042 11$: CMP      #SENDAD,#2#42 ;IF ACT-11 AUTO MODE,
643 001752 001404          BEQ    6$             ;DON'T TYPE ID
644 001754 104402 001000          TYPE   #MTITLE        ;TYPE TITLE MESSAGE
645 001760 105137 001346          COMB   INIFLG         ;IF NOT SET FLAG AND DO
646 001764 105777 177212 6$: TSTB   #SWR           ;BIT7=1??
647 001770 100002          BPL    10$
648 001772 000137 002402          JMP
649 001776          10$:
650 001776 105137 001332          COMB   FLAG
651 002002 112737 000001 001346 MOVVB   #1,INIFLG      ;SET TO MANUAL ENTRY
652 002010 012700 001500          MOV      #DUP.MAP,RO   ;CLR MAP
653 002014 000020 68$: CLR      (RO)+
654 002016 000027 001560          CMP     RO,#DUP.END    ;DONE WITH MAP?
655 002022 001374          BNE    68$           ;BR IF NO
656 002024 105037 001340          CLRB   MONFLG
657 002030 100037 001342          CLRB   ALJMF
658 002034 104403          INSTR  #OUTPUT MESSAGE & GET INPUT STRING
659 002036 005237          MCSR   #MESSAGE
660 002040 104405          PARAM  #CONVERT STRING
661 002042 160000          160000 ;LOW LIMIT
662 002044 175500          175500 ;HIGH LIMIT
663 002046 001500          DUCRO  #STORE AT THIS LOCATION

```

# E02

DZDPE-A MACY11 27(732) 21-OCT-76 16:11 PAGE 18  
 DZDPEA.CMB PROGRAM INITIALIZATION AND START UP.

664	002050	001				.BYTE	1	;MASK
665	002051	001				.BYTE	1	;HOW MANY TIMES + 2
666	002052	104403					INSTR	;OUTPUT MESSAGE & GET INPUT STRING
667	002054	005256					MVEC	;MESSAGE
668	002056	104405					PARAM	;CONVERT STRING
669	002060	000360					300	;LOW LIMIT
670	002062	000770					770	;HIGH LIMIT
671	002064	001502					DUPTRO	;STORE AT THIS LOCATION
672	002066	001				.BYTE	1	;MASK
673	002067	001				.BYTE	1	;HOW MANY TIMES + 2
674	002070	104403					INSTR	;OUTPUT MESSAGE & GET INPUT STRING
675	002072	005606					MMODEM	;MESSAGE
676	002074	104412					SETFLG	;SET FLAG BASED UPON INPUT STRING
677	002076	001340					MDMFLG	;THIS FLAG
678	002100	105737	001340				TSTB	MDMFLG
679	002104	001405					BEQ	715
680	002106	105037	001322				CLRB	TCNFLG
681	002112	105037	001342				CLRB	ALJMF
682	002116	104441					BR	705
683	002120	012737	000001	001236	715:		MOV	#1,TEMP1
684	002126	104403					INSTR	;OUTPUT MESSAGE & GET INPUT STRING
685	002130	005344					MTCN	;MESSAGE
686	002132	104412					SETFLG	;SET FLAG BASED UPON INPUT STRING
687	002134	001322					TCNFLG	;THIS FLAG
688	002136	105737	001322				TSTB	TCNFLG
689	002142	001427					BEQ	705
690	002144	104403					INSTR	;OUTPUT MESSAGE & GET INPUT STRING
691	002146	005263					MALLJM	;MESSAGE
692	002150	104412					SETFLG	;SET FLAG BASED UPON INPUT STRING
693	002152	001342					ALJMF	;THIS FLAG
694	002154	105737	001342				TSTB	ALJMF
695	002160	001020					BNE	705
696	002162	104403					INSTR	;OUTPUT MESSAGE & GET INPUT STRING
697	002164	005271					MJMPR	;MESSAGE
698	002166	104412					SETFLG	;SET FLAG BASED UPON INPUT STRING
699	002170	001323					CPCLRJ	;THIS FLAG
700	002172	104403					INSTR	;OUTPUT MESSAGE & GET INPUT STRING
701	002174	005472					MSTJM	;MESSAGE
702	002176	104412					SETFLG	;SET FLAG BASED UPON INPUT STRING
703	002178	001334					STJMF	;THIS FLAG
704	002180	104403					INSTR	;OUTPUT MESSAGE & GET INPUT STRING
705	002184	005525					MSTRJM	;MESSAGE
706	002186	104412					SETFLG	;SET FLAG BASED UPON INPUT STRING
707	002190	001336					SRJMF	;THIS FLAG
708	002192	104403					INSTR	;OUTPUT MESSAGE & GET INPUT STRING
709	002194	005737					MESC	;MESSAGE
710	002216	104412					SETFLG	;SET FLAG BASED UPON INPUT STRING
711	002218	001344					DSCFLG	;THIS FLAG
712	002220	112737	000001	001312	705:		MOVB	#1,SAVACT
713	002222	113737	001236	001311			MOVB	TEMP1,DUPNUM
714	002224	113737	001236	001313			MOVB	TEMP1,SAVNUM
715	002226	005337	001236		655:		DEC	TEMP1
716	002228	001404					BEQ	645
717	002230	000261					SEC	
718	002254	106137	001312				ROLB	SAVACT
719	002260	000771					BR	655

# F02

DZDPE-A MACY11 27(732) 21-OCT-76 16:11 PAGE 19  
 DZDPER.CMB PROGRAM INITIALIZATION AND START UP.

```

720 002262 113737 001312 001240 64$: MOV B SAVACT,TEMP2 :# OF TIMES
721 002270 113737 001312 001310 MOV B SAVACT,DUPACTV
722 002276 000241 CLC
723 002300 106037 001240 ROR B TEMP2
724 002304 012700 0C1500 MOV #DUPCR0,RO
725 002310 012701 001506 MOV #DUPCR1,R1
726 002314 000241 67$: CLC
727 002316 106037 001240 ROR B TEMP2
728 002322 103010 BCC 66$
729 002324 012011 MOV (RO)+,(R1)
730 002326 062721 000010 ADD #10,(R1)+ ;CSR
731 002332 012011 MOV (RO)+,(R1)
732 002334 062721 000010 ADD #10,(R1)+ ;VECTOR
733 002340 012021 MOV (RO)+,(R1)+ ;PARAMETERS
734 002342 000764 BR 67$
735 002344 66$:
736 002344 104402 005560 16$: TYPE XHEAD ;TYPE HEADER
737 002350 012737 001500 001236 MOV #DUP.MAP,TEMP1 ;SET POINTER
738 002356 017737 176654 001240 5$: MOV #TEMP1,TEMP2 ;SET DATA
739 002364 001406 BEQ 1$ ;ALL DONE WITH DATA
740 002366 104410 CONV RT
741 002370 005004 XSTAT@
742 002372 002737 000002 001236 ADD #2,TEMP1 ;UPDATE POINTER
743 002376 001766 BR 5$
744 002382 062777 000001 176572 1$: BIT #SW00,#SWR
745 002410 001405 BEQ 7$
746 002412 002737 001332 TST FLAG
747 002416 001002 BNE 7$
748 002420 002137 001776 JMP 10$
749 002424 002037 001332 7$: CLR FLAG
750 002430 005737 000042 TST #42 ;IS PROGRAM RUNNING UNDER MONITOR
751 002434 001030 BNE 3$ ;BR IF YES
752 002436 002777 000010 176536 BIT #SW03,#SWR ;SELECT SPECIFIC DEVICES??
753 002444 001424 BEQ 3$ ;BR IF NO.
754 002446 104402 005157 TYPE MNEW ;TYPE THE MESSAGE.
755 002452 001000 CLR RO ;ZERO DATA LIGHTS
756 002454 001000 HALT ;WAIT FOR USER TO TELL WHAT DEVICES TO RUN
757 002456 127737 176520 001312 CMP B #SWR,SAVACT ;IS THE NUMBER VALID?
758 002464 101404 BLOS 2$ ;BR IF NUMBER IS OK.
759 002466 104402 005020 TYPE ,MERR3 ;TELL USER OF INVALID NUMBER.
760 002472 001000 HALT ;STOP EVERY THING.
761 002474 002776 BR -2 ;RESTART THE PROGRAM AGAIN.
762 002476 117737 176500 001310 2$: MOV B #SWR,DUPACTV ;GET NEW DEVICE PATTERN
763 002504 113700 001310 MOV B DUPACTV,RO ;SHOW THE USER WHAT HE SELECTED.
764 002510 042700 177400 BIC #1<377>,RO ;USE ONLY LOW BYTE.
765 002514 000000 HALT ;CONTINUE DYNAMIC SWITCHES.
766 002516 012700 000300 3$: MOV #300,RO ;PREPARE TO CLEAR THE FLOATING
767 002522 012701 000302 MOV #302,R1 ;VECTOR AREA. 300-776
768 002526 010120 4$: MOV R1,(RO)+ ;START PUTTING "PC+2 - HALT"
769 002530 002021 CLR (R1)+ ;IN VECTOR AREA.
770 002532 022021 CMP (RO)+,(R1)+ ;POP POINTERS
771 002534 022700 001000 CMP #1000,RO ;ALL DONE??
772 002540 001372 BNE 4$ ;BR IF NO.
773
774 ;TEST START AND RESTART
775 -----

```

DZDPE-A MACY11 27(732) 21-OCT-76 16:11 PAGE 20  
 DZDPEA.CMB PROGRAM INITIALIZATION AND START UP.

776											
777	002542	012737	000340	177776	.BEGIN:	MOV	#340,PS				;LOCK OUT INTERRUPTS
778	002550	012706	001150			MOV	#STACK,SP				;SET UP STACK
779	002554	005737	000042			TST	#42				;IS PROGRAM UNDER MONITOR CONTROL
780	002560	001023				BNE	2\$				;BR IF YES
781	002562	032777	000004	176412		BIT	#BIT2,JSWR				;CHECK FOR LOCK ON TEST
782	002570	001411				BEQ	1\$				;BR IF NO LOCK DESIRED.
783	002572	104402	005056			TYPE	,MLOCK				;TYPE LOCK SELECTED.
784	002576	012737	000240	003056		MOV	#NOP,TTST				;ADJUST SCOPE ROUTINE.
785	002604	012737	000240	003060		MOV	#NOP,TTST+2				;SET UP TO LOCK
786	002612	000406				BR	2\$				;CONTINUE ALONG.
787	002614	013737	003170	003056	1\$:	MOV	BRW,TTST				;PREPARE NORMAL SCOPE ROUTINE
788	002622	013737	003172	003060		MOV	BRX,TTST+2				;LOCK NOT SELECTED, SET UP FOR NORMAL SCOPE LOOP
789	002630	012737	006166	001214	2\$:	MOV	#CYCLE,RETURN				;START AT "CYCLE" FIND WHICH DEVICE TO TEST
790	002636	104402	004746			TYPE	,MR				;TYPE R
791	002642	003177	176346			JMP	RETURN				;START TESTING

```

792                                     ;END OF PASS
793                                     ;TYPE NAME OF TEST
794                                     ;UPDATE PASS COUNT
795                                     ;CHECK FOR EXIT TO ACT-11
796                                     ;RESTART TEST
797
798 002646 005037 001234      .EOP: CLR      LSTERR      ;CLEAR LAST ERROR PC
799 001652 105037 001347      CLR      ERRFLG      ;CLEAR ERROR FLAG
800 000056 005237 001230      INC      PASCNT      ;UPDATE PASS COUNT
801 000002 013777 001230      MOV      PASCNT, @DISPLAY ;DISPLAY PASS COUNT
802 000070 104402 004723      TYPE    ,MEPASS     ;TYPE END PASS
803 000074 104402 005105      TYPE    ,MCSRX      ;TYPE CSR
804 000070 104411 003012      CNVRT   ,XCSR       ;SHOW IT
805 000270 104402 005113      TYPE    ,MVECX      ;TYPE VECTOR
806 000271 104411 003020      CNVRT   ,XVEC       ;SHOW IT
807 000271 104402 005121      TYPE    ,MPASSX     ;TYPE PASSES
808 000272 104411 003026      CNVRT   ,XPASS      ;SHOW IT
809 000274 104402 005132      TYPE    ,MERRX      ;TYPE ERRORS
810 000273 104411 003034      CNVRT   ,XERR       ;SHOW IT
811 000273 105337 001313      DECB    SAVNUM      ;ARE ALL DEVICES TESTED?
812 000274 001017              BNE     RESTRT      ;BR IF NO.
813 000274 112737 000377 001351  MOV     #377, @.FLG  ;SET THE QUICK VERIFY FLAG.
814 000275 113737 001311 001313  MOV     DUPNUM, SAVNUM ;RESTORE THE COUNT
815 000275 013701 000042      MOV     @#42, R1    ;CHECK FOR ACT-11 OR DDP
816 000276 001406              BEQ     RESTRT      ;IF NOT, CONTINUE TESTING
817 000276 000005              RESET            ;STOP THE SHOW--CLEAR THE WORLD
818
819 000276 004711              SENDAD: JSR     PC, (R1)
820 000277 000240              NOP
821 000277 000240              NOP
822 000277 000240              NOP
823 000277 000240              NOP
824 000300 012737 006166 001214  RESTRT: MOV     #CYCLE, RETURN
825 000300 000137 006166              JMP     CYCLE
826 000301 000001              XCSR:   1
827 000301 000006              .BYTE  6,2
828 000301 001410              RXCSR
829 000302 000001              XVEC:   1
830 000302 000003              .BYTE  3,2
831 000302 001400              DUPRVC
832 000302 000001              XPASS:  1
833 000303 000006              .BYTE  6,2
834 000303 001230              PASCNT
835 000303 000001              XERR:   1
836 000303 000006              .BYTE  6,2
837 000304 001232              ERRCNT
838
839                                     ;SCOPE LOOP AND INTERATION HANDLER
840
841 000304 005037 001234      .SCOPE: CLR      LSTERR      ;CLEAR LAST ERROR PC
842 000304 010016              MOV     R0, (SP)    ;SAVE R0 ON STACK
843 000305 032777 040000 176124  BIT     #BIT14, @SWR ;LOOP ON TEST?
844 000305 001407              BEQ     1$          ;BR IF NO (IF LOCK SW01 = 1; THIS LOCATION = 240)
845 000306 000437              BR     3$           ;GO TO 3$ (DITTO)
846 000306 105777 176116      TSTB   @TKCSR      ;KYBD DONE?
847 000306 100034              BPL     3$          ;BR IF NO (LOCK: HIT A KEY ON TTY TO GO TO NEXT TEST)

```

```

848 003070 017700 176112      MOV      QTKDBR,RO      ;CLR DONE BIT
849 003074 000415      BR       2$            ;CONTINUE
850 003076 032777 004000 176076 1$:  BIT      #SW11,@SWR    ;DELETE ITERATION (QUICK PASS)?
851 003104 001011      BNE     2$            ;BR IF YES
852 003106 105737 001351      TSTB   QV.FLG        ;HAS FIRST PASS BEEN COMPLETED?
853 003112 001406      BEQ    2$            ;BR IF QUICK VERIFY
854 003114 005237 001224      INC    LPCNT         ;UPDATE ITERATION COUNTER
855 003120 023737 001224 001222      CMP    LPCNT,ICOUNT  ;ALL ITERATIONS DONE?
856 003126 001014      BNE    3$            ;BR IF NOT YET
857 003130 105037 001347      CLRB   ERRFLG       ;PREPARE FOR NEW TEST
858 003134 005037 001224      CLR    LPCNT        ;START ICOUNT AT ZERO
859 003140 005037 001220      CLR    LOCK
860 003144 012737 000050 001222      MOV    #50,ICOUNT   ;RESET ITERATIONS
861 003152 013737 001216 001214      MOV    NEXT,RETURN  ;GET NEXT TEST
862 003160 011600      MOV    (SP),RO      ;POP RO OFF STACK
863 003162 022626      POP2SP              ;FAKE AN RTI
864 003164 000177 176024      JMP    QRETURN      ;GO DO THE TEST
865 003170 001407      BRW:   1407
866 003172 000437      BRX:   437
867                                     ;TELETYPE OUTPUT ROUTINE
868                                     -----
869
870 003220 010546      .TYPE: MOV    R5, -(SP)   ;SAVE R5 ON THE STACK.
871 003222 017605 000002      MOV    @2(SP),R5    ;GET ADDRESS OF MESSAGE.
872 003226 062766 000002 000002      ADD    #2,2(SP)     ;POP OVER ADDRESS.
873 003234 032777 010000 175740 1$:  BIT      #SW12,@SWR  ;INHIBIT ALL PRINT OUT??
874 003242 001012      BNE    3$            ;BR IF NO PRINT OUT WANTED (SW12=1)
875 003244 105715      TSTB   (R5)         ;IS NUMBER MINUS? (MSB=1(BIT?))
876 003246 100002      BPL    2$            ;BR IF NUMBER IS PLUS
877 003250 104402 004702      TYPE   MCRLF        ;TYPE A CR/LF!
878 003254 105777 175730 2$:  TSTB   QTPCSR       ;TTY READY?
879 003260 100375      BPL    2$            ;BR IF NO.
880 003262 112577 175724      MOVB   (R5)+,QTPDBR ;PRINT CURRENT CHAR.
881 003266 001362      BNE    1$            ;IF NOT ZERO KEEP PRINTING!
882 003270 012605 3$:  MOV    (SP)+,R5     ;END OF OUTPUT. RESTORE R5
883 003272 000002      RTI                                     ;GO HOME
884                                     -----
885
886 003274 010346      .INSTR: MOV    R3, -(SP)   ;SAVE R3 ON STACK
887 003276 010446      MOV    R4, -(SP)   ;SAVE R4 ON STACK
888 003300 017637 000004 003316      MOV    @4(SP),MSG
889 003306 062766 000002 000004      ADD    #2,4(SP)
890 003314 104402      .INST1: TYPE
891 003316 000000      .MSG:   0
892 003320 012704 006122      MOV    #INBUF,R4
893 003324 012703 000007      MOV    #7,R3
894 003330 105777 175650 1$:  TSTB   QTKCSR
895 003334 100375      BPL    1$
896 003336 117714 175644      MOVB   QTKDBR,(R4)
897 003342 142714 000200      BICB   #200,(R4)
898 003346 122427 000015      CMPB   (R4),#15
899 003352 001417      BEQ    INSTR2
900 003354 105777 175630 2$:  TSTB   QTPCSR
901 003360 100375      BPL    2$
902 003362 017777 175620 175622      MOV    QTKDBR,QTPDBR
903 003370 005303      DEC    R3

```

904	003372	001356		BNE	1\$	
905	003374	012604		MOV	(SP)+,R4	
906	003376	012603		MOV	(SP)+,R3	
907	003400	010346		.INSTE: MOV	R3,-(SP)	
908	003402	010446		MOV	R4,-(SP)	
909	003404	104402	004676	TYPE	,MOM	
910	003410	000741		BR	.INST1	
911	003412	012604		INSTR2: MOV	(SP)+,R4	;RESTORE R4
912	003414	012603		MOV	(SP)+,R3	;RESTORE R3
913	003416	000002		RTI		
914						
915						
916						
917						
918	003420	010546		.PARAM: MOV	R5,-(SP)	
919	003422	010446		MOV	R4,-(SP)	
920	003424	016605	000004	MOV	4(SP),R5	
921	003430	012537	003610	MOV	(R5)+,LOLIM	
922	003434	012537	003612	MOV	(R5)+,HILIM	
923	003440	012537	003614	MOV	(R5)+,DEVADR	
924	003444	112537	003616	MOV8	(R5)+,LOBITS	
925	003450	112537	003617	MOV8	(R5)+,ADRCNT	
926	003454	010566	000004	MOV	R5,4(SP)	
927	003460	005005		PARAM1: CLR	R5	
928	003462	012704	006122	MOV	#INBUF,R4	
929	003466	122714	000015	CMPB	#15,(R4)	
930	003472	001420		BEQ	PARERR	
931	003474	121427	000060	1\$: CMPB	(R4),#60	
932	003500	002415		BLT	PARERR	
933	003502	121427	000067	CMPB	(R4),#67	
934	003506	003012		BGT	PARERR	
935	003510	142714	000060	BICB	#60,(R4)	
936	003514	152405		BISB	(R4)+,R5	
937	003516	122714	000015	CMPB	#15,(R4)	
938	003522	001406		BEQ	LIMITS	
939	003524	006305		ASL	R5	
940	003526	006305		ASL	R5	
941	003530	006305		ASL	R5	
942	003532	000760		BR	1\$	
943	003534	104404		PARERR: INSTER		
944	003536	000750		BR	PARAM1	
945						
946						
947						
948						
949	003540	020537	003612	LIMITS: CMP	R5,HILIM	
950	003544	101373		BHI	PARERR	
951	003546	020537	003610	CMP	R5,LOLIM	
952	003552	103770		BLO	PARERR	
953	003554	133705	003616	BITB	LOBITS,R5	
954	003560	001365		BNE	PARERR	
955						
956						
957						
958	003562	013704	003614	1\$: MOV	DEVADR,R4	
959	003566	010524		MOV	R5,(R4)+	

;CONVERT ASCII STRING TO OCTAL  
 -----

;TEST TO SEE IF NUMBER IS WITHIN LIMITS  
 -----

;STORE NUMBER AT SPECIFIED ADDRESS

960	003570	062705	000002
961	003574	105337	003617
962	003600	001372	
963	003602	012604	
964	003604	012605	
965	003606	000002	
966	003610	000000	
967	003612	000000	
968	003614	000000	
969	003616	000000	
970		003617	
971			
972			
973			
974	003712	104402	004702
975	003716	010046	
976	003720	010146	
977	003722	010346	
978	003724	010446	
979	003726	010546	
980	003730	017601	000012
981	003734	062766	000002 000012
982	003742	012137	004116
983	003746	112137	004120
984	003752	112137	004121
985	003756	013137	004122
986	003762	013704	004122
987	003766	113705	004120
988	003772	012700	006016
989	003776	010403	
990	004000	042703	177770
991	004004	062703	000060
992	004010	110320	
993	004012	000241	
994	004014	000004	
995	004016	000241	
996	004020	006004	
997	004022	000241	
998	004024	000004	
999	004026	000305	
1000	004030	001362	
1001	004032	012703	006060
1002	004036	114023	
1003	004040	105337	004120
1004	004044	001374	
1005	004046	105737	004121
1006	004052	001405	
1007	004054	112723	000040
1008	004060	105337	004121
1009	004064	001373	
1010	004066	105013	
1011	004070	104402	006060
1012	004074	005337	004116
1013	004100	001322	
1014	004102	012605	
1015	004104	012604	

```

ADD #2,R5
DECB ADRCNT
BNE 1$
MOV (SP)+,R4
MOV (SP)+,R5
RTI
LOLIM: 0
HILIM: 0
DEVADR: 0
LOBITS: 0
ADRCNT=LOBITS+1
;CONVERT OCTAL NUMBER TO ASCII AND OUTPUT TO TELEPRINTER
;-----
.CONVR: TYPE MCRLF
.CNVRT: MOV R0,-(SP)
MOV R1,-(SP)
MOV R3,-(SP)
MOV R4,-(SP)
MOV R5,-(SP)
MOV @12(SP),R1
ADD #2,12(SP)
MOV (R1)+,WDRCNT
1$: MOV (R1)+,CHRCNT
MOV (R1)+,SPACNT
MOV @2(R1)+,BINWRD
2$: MOV BINWRD,R4
MOV CHRCNT,R5
MOV #TEMP,R0
3$: MOV R4,R3
BIC #177770,R3
ADD #060,R3
MOVB R3,(R0)+
CLC
ROR R4
CLC
ROR R4
CLC
ROR R4
DEC R5
BNE 3$
MOV #MDATA,R3
4$: MOV (R0)+,(R3)+
DECB CHRCNT
BNE 4$
TSTB SPACNT
BEQ 6$
5$: MOV #040,(R3)+
DECB SPACNT
BNE 5$
6$: CLRB (R3)
TYPE ,MDATA
DEC WDRCNT
BNE 1$
MOV (SP)+,R5
MOV (SP)+,R4
  
```

```

1016 004106 012603          MOV      (SP)+,R3
1017 004110 012601          MOV      (SP)+,R1
1018 004112 012600          MOV      (SP)+,R0
1019 004114 000002          RTI
1020 004116 000000          WRDCNT: 0
1021 004120 000000          CHRCNT: 0
1022          004121          SPACNT=CHRCNT+1
1023 004122 000000          BINWRD: 0
1024
1025
1026          ;COMPARE THE FIRST CHARACTER IN THE TELETYPE INPUT
1027          ;BUFFER TO THE CHARACTERS "N" AND "Y"
1028          ;IF THE CHARACTER IS "N" CLEAR THE FLAG
1029          ;IF THE CHARACTER IS "Y" SET THE FLAG
1030
1031 004124 017605 000000          .SETFLG:MOV      @ (SP),R5
1032 004130 042737 000040 006122          BIC      #40,INBUF
1033 004136 122737 000116 006122          CMPB    #'N',INBUF          ;IS IT "N" ?
1034 004144 001002          BNE     1$
1035 004146 105015          CLRB    (R5)          ;000
1036 004150 000406          BR      2$
1037 004152 122737 000131 006122 1$: CMPB    #'Y',INBUF          ;IS IT "Y" ?
1038 004160 001005          BNE     3$
1039 004162 112715 177777          MOVB    #-1,(R5)          ;377
1040 004166 062716 000002          2$: ADD     #2,(SP)
1041 004172 000002          RTI
1042 004174 104404          3$: INSTER ;RETRY
1043 004176 000752          BR      .SETFLG
1044
1045
1046          ;TRAP DISPATCH SERVICE
1047          ;ARGUMENT OF TRAP IS EXTRACTED
1048          ;AND USED AS OFFSET TO OBTAIN POINTER
1049          ;TO SELECTED SUBROUTINE
1050
1051 004200 011646          .TRPSR:MOV      (SP),-(SP)          ;GET PC OF RETURN
1052 004202 162716 000002          SUB     #2,(SP)          ;=PC OF TRAP
1053 004206 017616 000000          MOV     @ (SP), (SP)          ;GET TRP
1054 004212 006316          TRPOK:ASL     (SP)          ;MULTIPLY TRAP ARG BY 2
1055 004214 042716 177001          BIC     #177001,(SP)          ;CLEAR UNWANTED BITS
1056 004220 062716 001352          ADD     #.TRPTAB,(SP)          ;POINTER TO SUBROUTINE ADDRESS
1057 004224 017616 000000          MOV     @ (SP), (SP)          ;SUBROUTINE ADDRESS
1058 004230 000136          JMP     @ (SP)+          ;GO TO SUBROUTINE
1059
1060          ;ERROR HANDLER
1061          ;-----
1062
1063 004232 032777 010000 174742          .HLT: BIT     #SW12,@SWR          ;BELL ON ERROR?
1064 004240 001406          BEQ     XBX          ;BR IF NO BELL
1065 004242 105777 174742          TSTB   @TPCSR          ;TTY READY.
1066 004246 100003          BPL     XBX          ;DON'T WAIT IF TTY NOT READY.
1067 004250 112777 000207 174734          MOVB   #207,@TPDBR          ;PUSH A BELL AT THE TTY.
1068 004256 032777 020000 174716          XBX: BIT     #SW13,@SWR          ;DELETE ERROR PRINT OUT?
1069 004264 001105          BNE     HALTS          ;BR IF NO PRINT OUT WANTED.
1070 004266 021637 001234          CMP     (SP),LSTERR          ;WAS THIS ERROR FOUND LAST TIME?
1071 004272 001404          BEQ     1$          ;BR IF YES

```

1072	004274	011637	001234		MOV	(SP),LSTERR	:RECORD BEING HERE
1073	004300	105037	001347		CLRB	ERRFLG	:PREPARE HEADER
1074	004304	104406		15:	SAVOS		:SAVE ALL PROC REGISTERS
1075	004306	011605			MOV	(SP),R5	:GET THE PC OF ERROR
1076	004310	162705	000002		SUB	#2,R5	:GET ADDRESS OF TRAP CALL
1077	004314	011504			MOV	(R5),R4	:GET HLT INSTRUCTION
1078	004316	006304			ASL	R4	:MULT BY TWO
1079	004320	061504			ADD	(R5),R4	:DOUBLE IT
1080	004322	006304			ASL	R4	:MULT AGAIN
1091	004324	042704	177001		BIC	#177001,R4	:CLEAR JUNK
1082	004330	062704	011674		ADD	#.ERRTAB,R4	:GET POINTER
1083	004334	012437	004450		MOV	(R4)+,ERRMSG	:GET ERROR MESSAGE
1084	004340	012437	004462		MOV	(R4)+,DATAHD	:GET DATA HEADRER
1085	004344	011437	004474		MOV	(R4),DATABP	:GET DATA TABLE
1086	004350	105737	001347		TSTB	ERRFLG	:TYPE HEADREER
1087	004354	001403			BEQ	TYPMSG	:BR IF YES
1088	004356	005737	004474		TST	DATABP	:DOES DATA TABLE EXIST?
1089	004362	001040			BNE	TYPDAT	:BR IF YES.
1090	004364	104402	004702	TYPMSG:	TYPE	,MCRLF	
1091	004370	104402	004702		TYPE	,MCRLF	
1092	004374	005737	001220		TST	LOCK	
1093	004400	001402			BEQ	15	
1094	004402	104402	005155		TYPE	,MASTEK	
1095	004406	104402	005143	15:	TYPE	,MTSTN	
1096	004412	104411	004602		CNVRT	,XTSTN	:SHOW IT
1097	004416	104402	005232		TYPE	,MERRPC	:TYPE PC.
1098	004422	104411	004574		CNVRT	,ERTABO	:SHOW IT
1099	004426	104402	004702		TYPE	,MCRLF	:GIVE A CR/LF
1100	004432	112737	177777	001347	MOVB	#-1,ERRFLG	:NO MORE HEADER UNLESS NO DATA TABLE.
1101	004440	005737	004450		TST	ERRMSG	:IS THERE AN ERROR MESSAGE?
1102	004444	001402			BEQ	WRKO.FM	:BR IF NO.
1103	004446	104402			TYPE		:TYPE
1104	004450	000000		ERRMSG:	0		:ERROR MESSAGE
1105	004452			WRKO.FM:			
1106	004452	005737	004462		TST	DATAHD	:DATA HEADER?
1107	004456	001402			BEQ	TYPDAT	:BR IF NO
1108	004460	104402			TYPE		:TYPE
1109	004462	000000		DATAHD:	0		:DATA HEADER
1110	004464	005737	004474	TYPDAT:	TST	DATABP	:DATA TABLE?
1111	004470	001402			BEQ	RESREG	:BR IF NO.
1112	004472	104410			CONVRT		:SHOW
1113	004474	000000		DATABP:	0		:DATA TABLE
1114	004476	104407		RESREG:	RESOS		:RESTORE PROC REGISTERS
1115	004500	022737	002766	000042	HALTS:	CMF	#SENDAD,#42
1116	004506	001403			BEQ	15	
1117	004510	005777	174466		TST	2SWR	:HALT ON ERROR?
1118	004514	100005			BPL	EXITER	:BR IF NO HALT ON ERROR
1119	004516	010046		15:	PUSHRO		:SAVE R0
1120	004520	016600	000002		MOV	2(SP),R0	:SHOW ERROR PC IN JATA LIGHTS
1121	004524	000000			HALT		:HALT
1122	004526	012600			POPPO		:GET R0
1123	004530	005237	001232	EXITER:	INC	ERRCNT	:UPDATE ERROR COUNT
1124	004534	032777	000400	174440	BIT	#SW08,2SWR	:GOTO TOP OF TEST?
1125	004542	001007			BNE	15	:BR IF YES
1126	004544	032777	002000	174430	BIT	#SW10,2SWR	:GOTO NEXT TEST?
1127	004552	001407			BEQ	25	:BR IF NO

DZDPE-A MACY11 27(732) 21-OCT-76 16:11 PAGE 27  
DZDPER.CMB END OF PASS ROUTINE

1128	004554	013737	001216	001214		MOV	NEXT, RETURN	; SET FOR NEXT TEST
1129	004552	012706	001150		1S:	MOV	#STACK, SP	; RESET SP
1130	004566	000177	174422			JMP	@RETURN	; GOTO SPECIFIED TEST
1131	004572	000002			2S:	RTI		; RETURN
1132	004574	000001			ERTABO:	1		
1133	004576	006	002			.BYTE	6,2	
1134	004600	001266				SAVPC		
1135	004602	000001			XTSTN:	1		
1136	004604	003	002			.BYTE	3,2	
1137	004606	001226				TSTNO		
1138								

```

1139          :WAIT ROUTINE
1140 004610 000240      SMALL: NOP          ;STALL
1141 004612 000207      RTS          PC      ;RETURN
1142
1143
1144          ;POWER FAIL ROUTINE
1145
1146 004614 012737 004624 000024 .PFAIL: MOV      #PWRUP,24      ;LOAD PFAIL VECTOR FOR POWER UP
1147 004622 000000      HALT
1148 004624 000005      PWRUP: RESET      ;WAIT TTY TO COME UP
1149 004626 012706 001150      MOV      #STACK,SP      ;REINIT STACK POINTER
1150 004632 012737 004614 000024      MOV      #.PFAIL,24      ;LOAD PFAIL VECTOR FOR POWER DOWN
1151 004640 104402      TYPE
1152 004642 004705      MPOWER
1153 004644 000177 174344      JMP      @RETURN
1154
1155          ;CLRVEC,ROUTINE TO FILL COMMUNICATION VECTOR AREA WITH .+2,HALT
1156
1157 004650 012702 000300      CLRVEC: MOV      #300,R2      ;R2 COMM VECTOR AREA ADRS
1158 004654 012701 000302      MOV      #302,R1      ;INIT R1 WITH ADRS OF HALT
1159 004660 010122      IS:  MOV      R1,(R2)+      ;MOV .+2 TO PC
1160 004662 005022      CLR      (R2)+      ;MOV HALT TO PC
1161 004664 022121      CMP      (R1)+,(R1)+      ;INC TO NEXT VECTOR AREA
1162 004666 022701 000776      CMP      #776,R1      ;END OF VECTOR AREA
1163 004672 001372      BNE      IS
1164 004674 000207      RTS          PC      ;RETURN
1165
1166
1167
1168 006004 000002      XSTAT0: 2
1169 006006 006 003      .BYTE 6,3
1170 006010 001236      TEMP1
1171 006012 006 002      .BYTE 6,2
1172 006014 001240      TEMP2
1173
1174          .EVEN
1175 006016 000000      TEMP: 0
1176 006060      .=.+40
1177 006060 000000      MDATA: 0
1178 006122      .=.+40
1179 006122 000000      INBUF: 0
1180 006164      .=.+40
1181 006164 000001      TRP.PC: .BLKW 1
1182

```

```

1183
1184
1185          ; ROUTINE USED TO "CYCLE" THROUGH UP TO EIGHT DUPI1'S
1186          ; THIS ROUTINE SETS UP THE CONTROL ADDRESS FOR THE DIAGNOSTIC
1187          ; AND RUNS THE SPECIFIED DUPI1'S.  THIS ROUTINE *MUST*
1188          ; BE RUN FIRST BEFORE ENTERING THE DIAGNOSTIC FOR THE
1189          ; SETUP NECESSARY.
1190
1191
1192 006166 105737 001310          CYCLE: TSTB   DUPACTV   ; ARE ANY DUPI1'S TO BE TESTED?
1193 006172 001004          BNE     1$      ; BR IF OK.
1194 006174 104402 004751          TYPE   ,MERR2   ; NO DUPI1'S SELECTED!!
1195 006200 000000          HALT                    ; STOP THE SHOW.
1196 006202 000776          BR     .-2     ; DISQUALIFY CONT. SW.
1197 006204 133737 001314 001310 1$: BITB   RUN,DUPACTV ; IS THIS ONE "ACTIVE"
1198 006212 001020          BNE     2$      ; BR IF GOOD ONE FOUND.
1199 006214 000241          CLC                    ; CLEAR PROC. CARRY BIT.
1200 006216 106137 001314          ROLB   RUN     ; UPDATE POINTER
1201 006222 105537 001314          ADCB   RUN     ; CATCH CARRY FROM RUN
1202 006226 062737 000006 001316  ADD    #6,CREAM ; UPDATE ADDRESS POINTER.
1203 006234 022737 001560 001316  CMP    #DUP.END,CREAM
1204 006242 001360          BNE     1$      ; KEEP GOING; NOT ALL TESTED FOR.
1205 006244 012737 001500 001316  MOV    #DUP.MAP,CREAM ; RESET ADDRESS POINTER.
1206 006252 000754          BR     1$      ; KEEP LOOKING FOR ACTIVE DUPI1
1207 006254 000241          CLC                    ; CLEAR PROC. CARRY.
1208 006256 106137 001314          ROLB   RUN     ; UPDATE POINTER.
1209 006262 105537 001314          ADCB   RUN     ; CATCH CARRY.
1210 006266 013700 001316          MOV    CREAM,RO   ; GET ADDRESS POINTER.
1211 006272 062737 000006 001316  ADD    #6,CREAM   ; UPDATE.
1212 006300 022737 001560 001316  CMP    #DUP.END,CREAM
1213
1214 006306 001003          BNE     3$      ; ALL DONE?
1215 006310 012737 001500 001316  MOV    #DUP.MAP,CREAM ; BR IF NO.
1216 006316 012037 001410          MOV    (RO)+,RXCSR ; RESTORE POINTER.
1217 006322 012037 001400          MOV    (RO)+,DUPRVC ; LOAD SYSTEM CTRL. REG
1218 006326 012037 001440          MOV    (RO)+,LOO.00 ; LOAD VECTOR
1219 006332 012700 000002          MOV    #2,RO     ; GET PARAMETERS
1220 006336 013737 001410 001430  MOV    RXCSR,HUPRCR ; SAVE CORE THIS WAY!
1221 006344 005237 001430          INC    HUPRCR    ; GET CONTROL REG HIGH BYTE
1222 006350 013737 001430 001412  MOV    HUPRCR,RXDBUF ; GOT IT
1223 006356 005237 001412          INC    RXDBUF   ; GET RX CONTROL REG BUFFER
1224 006362 013737 001412 001422  MOV    RXD.F,DUPSEC ; GOT IT
1225 006370 013737 001412 001414  MOV    RXD.F,PARCSR ; GOT SECONDARY REG SELECT REG
1226 006376 013737 001412 001426  MOV    RXD.F,HUPRHF ; GOT PARAMETER STATUS REGISTER
1227 006404 005237 001426          INC    HUPRHF   ; GET RX BUFFER HIGH BYTE
1228 006410 013737 001426 001424  MOV    HUPRHF,HUPPSR ; GOT IT
1229 006416 013737 001424 001416  MOV    HUPPSR,TXCSR ; GOT PAR STATUS REG HIGH BYTE
1230 006424 005237 001416          INC    TXCSR    ; GET TX CONTROL REGISTER
1231 006430 013737 001416 001434  MOV    TXCSR,HUPTCR ; GOT IT
1232 006436 005237 001434          INC    HUPTCR   ; GET TX CONTROL REG HIGH BYTE
1233 006442 013737 001434 001420  MOV    HUPTCR,TXDBUF ; GOT IT
1234 006450 005237 001420          INC    TXDBUF  ; GET TX BUFFER
1235 006454 013737 001420 001432  MOV    TXDBUF,HUPTBF ; GOT TX BUFFER HIGH BYTE
1236 006462 005237 001432          INC    HUPTBF  ; GOT IT
1237
1238 006466 013737 001400 001402  MOV    DUPRVC,DUPRPS ; RX VECTOR

```

1239	006474	060037	001402			ADD	RO, DUPRPS	;RX PRIORITY LEVEL
1240	006500	013737	001402	001404		MOV	DUPRPS, DUPTVC	
1241	006506	060037	001404			ADD	RO, DUPTVC	;TX VECTOR
1242	006512	013737	001404	001406		MOV	DUPTVC, DUPTPS	
1243	006520	060037	001406			ADD	RO, DUPTPS	;TX PRIORITY LEVEL
1244								
1245								
1246	006524	012700	001440			MOV	#L00.00, RO	;LOAD STAU5 00-00
1247	006530	012701	001436			MOV	#MASK.A, R1	;PREPARE MASK.
1248	006534	012702	001437			MOV	#CLK.A, R2	;PREPARE CLOCKS
1249	006540	004737	006704			JSR	PC, FIX.00	;GO AND CALCULATE CONFIGURATION.
1250	006544	005737	000042			TST	#42	
1251	006550	001050				BNE	4\$	
1252	006562	032777	000002	172422		BIT	#SW01, #SWR	;IF SW01=1, GET STARTING TEST #
1253	006560	001444				BEQ	4\$	
1254	006562	104402	004702		7\$:	TYPE	, MCRLF	
1255	006576	104403				INSTR	, #	OUTPUT MESSAGE & GET INPUT STRING
1256	006570	005143				MTSTN	, #	MESSAGE
1257	006572	104405				PARAM	, #	CONVERT STRING
1258	006574	000001				1	, #	LOW LIMIT
1259	006576	001000				1000	, #	HIGH LIMIT
1260	006500	001226				TSTNO	, #	STORE AT THIS LOCATION
1261	006502	000			.BYTE	0	, #	MASK
1262	006603	001			.BYTE	1	, #	HOW MANY TIMES + 2
1263	006604	012700	007034			MOV	#TST1, RO	
1264	006610	022710	012737		5\$:	CMP	#12737, (RO)	
1265	006614	001017				BNE	6\$	
1266	006616	023760	001226	000002		CMP	TSTNO, 2(RO)	
1267	006624	001013				BNE	6\$	
1268	006626	022760	001226	000004		CMP	#TSTNO, 4(RO)	
1269	006634	001037				BNE	6\$	
1270	006636	010037	001214			MOV	RO, RETURN	;SAVE PC
1271	006642	104402	004702			TYPE	, MCRLF	
1272	006646	104402	004746			TYPE	, MR	
1273	006652	002412				BR	6\$	
1274	006654	005720			6\$:	TST	(RO)+	
1275	006656	003027	010370			CMP	RO, #TLAST+10	
1276	006652	001752				BNE	5\$	
1277	006654	104402	004676			TYPE	, MQM	
1278	006670	000734				BR	7\$	
1279								
1280	006672	012737	007034	001214	4\$:	MOV	#TST1, RETURN	;PREPARE RETURN ADDRESS
1281	006700	000177	172310		8\$:	JMP	#RETURN	;GO START TESTING.
1282								
1283	006704	011003			FIX.00:	MOV	(RO), R3	;GET PARAMETERS.
1284	006706	000207			5\$:	RTS	PC	

# E03

```

1285                                     ; THIS ROUTINE PICKS UP THE ADDRESS OF
1286                                     ; THE JUMPER TABLE AND LOADS R5 WITH
1287                                     ; THE CORRECT DATA BASED ON THE STATE
1288                                     ; OF THE JUMPER AND CONNECTOR FLAGS.
1289                                     -----
1290
1291 006710 012100          JUMPER: MOV    (R1)+,R0          ; GET THE TABLE ADDRESS
1292 006712 105737 001322  TSTB   TCNFLG          ; TEST THE TURN AROUND CONNECTOR FLAG
1293 006716 001406          BEQ    2$              ; BRANCH IF CONNECTOR IS MISSING
1294 006720 105737 001323  TSTB   OPCLRJ          ; TEST CLEAR JUMPER FLAG
1295 006724 001403          BEQ    2$              ; BRANCH IF JUMPER IS MISSING
1296 006726 011005          MOV    (R0),R5         ; MOVE THE DATA TO R5, BOTH JUMPER
1297                                     ; AND CONNECTOR ARE THERE
1298 006730 000137 006754          JMP    5$
1299 C 6734 022020 2$:      CMP    (R0)+,(R0)+        ; POP POINTER
1300 C 5736 105737 001323  TSTB   OPCLRJ          ; TEST CLEAR JUMPER FLAG
1301 C 6742 001403          BEQ    3$              ; BRANCH IF MISSING
1302 006744 011005          MOV    (R0),R5         ; MOVE DATA- JUMPER IN, CONNECTOR OFF
1303 006746 000137 006754          JMP    5$
1304 006752 012005 3$:      MOV    (R0)+,R5         ; NO CONNECTOR OR JUMPER
1305 006754 000201 5$:      RTS    R1              ; RETURN
1306
1307 006756 012100          OJUMPER: MOV   (R1)+,R0          ; GET THE POINTER ADDRESS
1308 C 6760 105737 001322  TSTB   TCNFLG          ; CHECK FOR TURNAROUND CONNECTOR
1309 006764 001403          BEQ    4$              ; BR IF MISSING
1310 006766 011005          MOV    (R0),R5         ; MOVE THE INFO TO R5
1311 006770 000137 007000          JMP    6$
1312 006774 022020 4$:      CMP    (R0)+,(R0)+        ; POP POINTER
1313 006776 011005          MOV    (R0),R5         ; LOAD DATA TO R5
1314 007000 000201 6$:      RTS    R1              ; RETURN
1315
1316
1317                                     ; ROUTINE TO SET UP INTERRUPT VECTORS
1318 007002 012577 172372  SETVEC: MOV   (R5)+,20UPRVC
1319 007006 012577 172372      MOV   (R5)+,20UPTVC
1320 007012 112577 172364      MOVB (R5)+,20UPRPS
1321 007016 112577 172364      MOVB (R5)+,20UPTPS
1322 007022 000205          RTS    R5
1323 007024          NO.ATRAP:
1324 007024 104001          HLT    1
1325 007026 000002          RTI
1326
1327          NO.BTRAP:
1328 007030 104002          HLT    2
1329 007032 000002          RTI
1330

```

```

1331
1332
1333
1334
1335
1336
1337
1338
1339
1340
1341
1342
1343
1344
1345
1346 007034 012737 000001 001226
1347 007042 012737 007370 001216
1348 007050 105737 001322
1349 007054 001002
1350 007056 000137 007356
1351 007062 105737 001342
1352 007066 001040
1353 007070 012701 002010
1354 007074 105737 001334
1355 007100 001011
1356 007102 040137 007360
1357 007106 040137 007362
1358 007112 040137 007364
1359 007116 107737 001344
1360 007122 001413
1361 007124 105737 001336
1362 007130 001010
1363 007132 040137 007360
1364 007136 040137 007362
1365 007142 040137 007364
1366 007146 107737 001344
1367 007152 107737 001344
1368 007156 001004
1369 007160 001337 007360
1370 007164 001337 007362
1371 007170 004137 006756
1372 007174 007360
1373
1374 007176 005077 172206
1375 007202 002777 000400 172206
1376 007210 004737 004610
1377 007214 013703 001410
1378 007220 052777 010000 172170
1379 007225 052713 000016
1380 007230 012737 001010 007262
1381 007240 032777 004000 172152
1382 007246 001374
1383 007250 032777 004000 172142
1384 007255 001774
1385 007260 005327
1386 007262 000110
  
```

```

***** TEST 1 *****
*THIS TEST PROVES THE INTERACTION OF DTR!RTS!STD
*WITH RING DSR,CTS,CARDET,STD,SRD
*AND DATA SET CHANGE ONE AND DATA SET CHANGE TWO.
*SET THE BIT AND VERIFY THE OTHER BITS ARE SET. CLEAR
*THE BIT AND VERIFY CLEAR. REPEAT FOR MRESET.
*****
  
```

```

*****
: TEST 1
*****
*****
  
```

```

TST1: MOV #1,2#TSTNO
      MOV #TST2,NEXT
      TSTB TCNFLG
      BNE 100$
      JMP 6$
100$: TSTB ALJMF
      BNE 12$
      MOV #STD!SRD,R1
      TSTB STJMF
      BNE 101$
      BIC R1,7$
      BIC R1,7$+2
      BIC R1,7$+4
      CLRB DSCFLG
      BR 102$
101$: TSTB SRJMF
      BNE 102$
      BIC R1,7$
      BIC R1,7$+2
      BIC R1,7$+4
      CLRB DSCFLG
102$: TSTB DSCFLG
      BNE 12$
      DEC 7$
12$: DEC 7$+2
      JSR R1,0JUMPER ; THIS CALL DETERMINES IF TURNAROUND CONNECTOR
                       ; AND OPTIONAL JUMPER ARE USED
                       ; AND LOADS R5 (EXPECTED) ACCORDINGLY.
      CLR @RXCSR
      BIS @MRESET,@TXCSR ; RESET THE DEVICE
      JSR PC,5,ALL ; WAIT FOR RESET TO FINISH
      MOV RXCSR,R3 ; LOAD THE RECEIVER CONTROL REGISTER TO R3.
      BIS @NEXT,@TXCSR ; ENTER EXTERNAL MAINT. MODE
      BIS @DTR!RTS!STD,(R3) ; TURN ON DTR!RTS!STD
      MOV #110,68$ ; LOAD THE NUMBER
1$: BIT @TIMER,@TXDBUF ; CHECK THE TIMER BIT
   BNE 66$ ; BR IF SET
66$: BIT @TIMER,@TXDBUF ; CHECK THE BIT
   BEQ 67$ ; BR IF CLEAR
   DEC (PC)+ ; DECREMENT THE NUMBER
68$: ; OF TIMES TO REPEAT
  
```

```

1387 007264 001365      BNE      66$          ;BR IF MORE TO GO
1388 007266 011304      MOV      (R3),R4     ;GET THE BITS FROM THE RXCSR
1389 007270 020504      CMP      R5,R4      ;R5=GOOD R4=?
1390 007272 001401      BEQ      2$         ;BRANCH IF THEY MATCH
1391 007274 104003      HLT      3          ;NO MATCH - SHOW OPR.
1392 007276 012737 007310 001220 2$:  MOV      #3$,LOCK   ;SW09 SETUP
1393 007304 042705 073016      BIC      #RING!CTS!CARDET!SRD!DSR!STD!RTS!DTR,R5 ;CLEAR OUT UNWANTED BITS
1394 007310 005013      CLR      (R3)      ;CLEAR OUT THE REGISTER
1395 007312 012737 000005 007342 3$:  MOV      #5,73$     ;LOAD THE NUMBER
1396 007320 032777 004000 172072 71$:  BIT      #TIMER,#TXDBUF ;CHECK THE TIMER BIT
1397 007326 001374      BNE      71$       ;BR IF SET
1398 007330 032777 004000 172062 72$:  BIT      #TIMER,#TXDBUF ;CHECK THE BIT
1399 007336 001774      BEQ      72$       ;BR IF CLEAR
1400 007340 005327      DEC      (PC)+     ;DECREMENT THE NUMBER
1401 007342 000005      5              ;OF TIMES TO REPEAT
1402 007344 001365      BNE      71$       ;BR IF MORE TO GO
1403 007346 011304      MOV      (R3),R4     ;READ BACK THE REGISTER
1404 007350 020504      CMP      R5,R4      ;R5=GOOD R4=?
1405 007352 001401      BEQ      6$         ;BRANCH IF ONLY THE DSC BITS ARE SET
1406 007354 104003      HLT      3          ;NO-GO TELL OPR
1407 007356 104400      6$:  SCOPE          ;SCOPE THE WHOLE TEST
1408 007360 173017      7$:  .WORD      173017
1409 007362 173001      .WORD      173001
1410 007364 001016      .WORD      1016
1411 007366 000000      .WORD      0

```

```

***** TEST 2 *****
*TEST OF THE DUP RUNNING A BINARY COUNT
*PATTERN WITH A CRC CALCULATION AS A SECONDARY STATION
*****

```

```

1412
1413
1414
1415
1416
1417
1418
1419
1420
1421
1422
1423
1424
1425 007370 012737 000002 001226 1ST2:  MOV      #2,#TSTNO
1426 007376 012737 010360 001216      MOV      #TST3,NEXT
1427 007404 052777 000400 172004      BIS      #MRESET,#TXCSR ;RESET THE DEVICE
1428 007412 004737 004610      JSR      PC,SMALL ;WAIT FOR RESET TO FINISH
1429 007416 105737 001322      TSTB    TCNPLG
1430 007422 001403      BEQ      102$
1431 007424 012737 010070 007530      MOV      #NEXT,103$+2
1432 007432 012737 000005 001244 102$:  MOV      #5,TEMP4
1433 007440 005001      CLR      R1 ;CLEAR OUT DATA
1434 007442 012737 102010 010352      MOV      #CRC.CCITT,XPOLY ;SET UP THE POLYNOMIAL
1435 007470 012737 177777 010776      MOV      #-1,CALBCC ;SETUP FOR THE FIRST TIME
1436 007476 013737 010356 007500 16$:  MOV      CALBCC,20$ ;ALLOW FOR THE NEXT CHARACTER
1437 007464 010137 007476      MOV      R1,17$ ;LOAD DATA
1438 007470 004537 010200      JSR      R5,SIMBCC ;GO CALCULATE SOFTWARE BCC
1439 007474 007010      B. ;BASED ON THESE PARAMETERS
1440 007476 000001 17$:  .BLKW    1 ;DATA
1441 007500 000001 20$:  .BLKW    1 ;PREVIOUS BCC
1442 007502 105201      INCB    R1 ;INCREMENT DATA

```

```

1443 007504 001364 BNE 16$ ;BR IF MORE TO GO
1444 007506 012737 000001 001236 MOV #1,TEMP1 ;LOAD DATA
1445 007514 005037 001240 CLR TEMP2 ;CLEAR EXPECTED
1446 007520 012737 000340 177776 MOV #340,PS ;PS = 7
1447 007526 052777 004000 171662 103$: BIS #SYSTST,@TXCSR ;ENTER SYSTEM TEST MODE
1448 007534 004537 007002 JSR R5,SETVEC ;LOAD INTERRUPT VECTORS
1449 007540 007734 11$ RECEIVER
1450 007542 010002 12$ TRANSMITTER
1451 007544 340 340 .BYTE 340,340 ;LEVEL
1452 007546 052777 000020 171634 BIS #RCVEN,@RXCSR ;TURN ON THE RECEIVER
1453 007554 052777 00C100 171626 BIS #RINTEN,@RXCSR ;TURN ON REC INTERRUPT ENABLE
1454 007562 105777 171630 1$: TSTB @TXCSR ;TEST FOR TX DONE
1455 007566 100375 BPL 1$ ;BR IF NOT SET
1456 007570 052777 000020 171620 2$: BIS #SEND,@TXCSR ;TURN ON SEND
1457 007576 012777 000400 171614 MOV #TSON,@TXDBUF ;TURN ON START OF MESSAGE
1458 007604 101$:
1459 007604 012737 000005 007634 MOV #5,68$ ;LOAD THE NUMBER
1460 007612 012777 004000 171600 66$: BIT #TIMER,@TXDBUF ;CHECK THE TIMER BIT
1461 007620 001374 BNE 66$ ;BR IF SET
1462 007622 032777 004000 171570 67$: BIT #TIMER,@TXDBUF ;CHECK THE BIT
1463 007630 001774 BEQ 67$ ;BR IF CLEAR
1464 007632 005327 DEC (PC)+ ;DECREMENT THE NUMBER
1465 007634 000005 68$: 5 ;OF TIMES TO REPEAT
1466 007636 001365 BNE 66$ ;BR IF MORE TO GO
1467 007640 005337 001244 DEC TEMP4
1468 007644 001001 BNE 3$
1469 007646 104004 HLT 4
1470 007650 105777 171542 3$: TSTB @TXCSR ;WAIT FOR DONE
1471 007654 10353 BPL 101$ ;BR IF NOT SET
1472 00766 01077 171536 4$: CLR @TXDBUF ;PUSH OUT DATA
1473 007662 012777 000100 171526 BIS #TXINTE,@TXCSR ;TURN ON TRANSMITTER INT ENABLE
1474 007670 005037 177776 CLR PS ;LOWER PROCESOR STATUS
1475 007674 5$:
1476 007674 012737 000040 007724 MOV #32,73$ ;LOAD THE NUMBER
1477 007702 032777 004000 171510 71$: BIT #TIMER,@TXDBUF ;CHECK THE TIMER BIT
1478 007710 001374 BNE 71$ ;BR IF SET
1479 007712 032777 004000 171500 72$: BIT #TIMER,@TXDBUF ;CHECK THE BIT
1480 007720 001774 BEQ 72$ ;BR IF CLEAR
1481 007722 005327 DEC (PC)+ ;DECREMENT THE NUMBER
1482 007724 000040 73$: 32 ;OF TIMES TO REPEAT
1483 007726 001365 BNE 71$ ;BR IF MORE TO GO
1484 007730 104004 HLT 4 ;FAILED TO INTERRUPT IN TIME
1485 007732 104400 6$: SCOPE ;SCOPE THIS TEST
1486
1487 ;INTERRUPT SERVICE ROUTINES
1488 -----
1489 ;RECEIVER:
1490 007734 017737 171452 001324 11$: MOV @RXDBUF,DATA ;GET THE REGISTER AND DATA
1491 007742 123737 001240 001324 CMPB TEMP2,DATA ;CHECK IT
1492 007750 001401 BEQ .+4 ;BR IF OK
1493 007752 104004 HLT 4 ;COMPARISON ERROR
1494 007754 102337 001240 INCB TEMP2 ;COUNT UP EXPECTED
1495 007760 105737 001240 TSTB TEMP2 ;CHECK TO SEE IF DONE
1496 007764 001005 BNE 7$ ;BR IF NO
1497 007766 004537 007002 JSR R5,SETVEC ;YES--RESET THE VECTORS
1498 007772 010106 14$ RECEIVER
  
```

1499	007774	010002					12\$		:TRANSMITTER
1500	007776	340	340				.BYTE	340,340	:LEVEL
1501	010000	000002				7\$:	RTI		:RETURN
1502							:TRANSMITTER:		
1503	010002	113777	001236	171410		12\$:	MOV B	TEMP1, @TXDBUF	:LOAD THE TRANSMITTER BUFFER
1504	010010	105237	001236				INCB	TEMP1	:UP THE COUNT
1505	010014	122737	000377	001236			CMP B	#377, TEMP1	:ARE WE DONE
1506	010022	001026					BNE	13\$	:BR IF NO
1507	010024	012777	010034	171352			MOV	#21\$, @DUPTVC	:SETUP FOR NEXT PART
1508	010032	000422					BR	13\$	:LEAVE
1509	010034	012777	000377	171356		21\$:	MOV	#377, @TXDBUF	:LOAD BUFFER
1510	010042	012777	010052	171334			MOV	#22\$, @DUPTVC	:SETUP NEXT PART
1511	010050	000413					BR	13\$	:LEAVE
1512	010052	012777	001000	171340		22\$:	MOV	#TEOM, @TXDBUF	:SET END OF MSG
1513	010060	000240					NOP		:STALL
1514	010062	000240					NOP		:DITTO
1515	010064	042777	000120	171324			BIC	#SEND!TXINTE, @TXCSR	:TURN OFF TRANSMITTER
1516	010072	012777	007030	171304			MOV	#NO.BTRAP, @DUPTVC	:LOAD VECTOR
1517	010100	012716	007674			13\$:	MOV	#5\$, (SP)	:CRUNCH STACK
1518	010104	000002					RTI		:RETURNS
1519							:CRC	CATCH INT SVC	
1520	010106	117737	171300	001324		14\$:	MOV B	@RXDBUF, DATA	:GET FIRST PART OF CRC
1521	010114	105777	171270				TST B	@RXCSR	:WAIT FOR SECOND PART
1522	010120	100375					BPL	.-4	:DITTO
1523	010122	117737	171264	001325			MOV B	@RXDBUF, DATA+1	:GET THE REST OF THE CRC
1524	010130	012716	010136				MOV	#15\$, (SP)	:SETUP FOR RETURN
1525	010134	000002					RTI		:RETURN
1526	010136	012737	000340	177776		15\$:	MOV	#340, PS	:RAISE PS
1527	010144	005137	010356				COM	CALBCC	:INVERT BCC
1528	010150	023737	010356	001324			CMP	CALBCC, DATA	:COMPARE SOFTWARE AND HARDWARE BCC
1529	010156	001401					BEQ	+.4	:BR IF OK
1530	010160	104004					HLT	4	:BCC COMPARISON ERROR
1531	010162	052777	000400	171226			BIS	#MRESET, @TXCSR	:RESET THE DEVICE
1532	010170	004737	004610				JSR	PC, SMALL	:WAIT FOR RESET TO FINISH
1533	010174	000137	007732				JMP	6\$	:LEAVE
1534									
1535									
1536	010200	010046				SIMBCC:	MOV	R0, -(SP)	
1537	010202	010146					MOV	R1, -(SP)	
1538	010204	010246					MOV	R2, -(SP)	
1539	010206	010237	001236				MOV	(R5)+, TEMP1	
1540	010212	010237	001240				MOV	(R5)+, TEMP2	
1541	010216	010237	001242				MOV	(R5)+, TEMP3	
1542	010222	005037	010354			1\$:	CLR	BCCFBK	
1543	010226	013700	001242				MOV	TEMP3, R0	
1544	010230	006037	001240				ROR	TEMP2	
1545	010236	005500					ADC	R0	
1546	010240	032700	000001				BIT	#BIT0, R0	
1547	010244	001402					BEQ	2\$	
1548	010246	005137	010354				COM	BCCFBK	
1549	010252	013700	010352			2\$:	MOV	XPOLY, R0	
1550	010256	005100					COM	R0	
1551	010260	040037	010354				BIC	R0, BCCFBK	
1552	010264	000241					CLC		
1553	010266	006037	001242				ROR	TEMP3	
1554	010272	013700	010354				MOV	BCCFBK, R0	

```

1555 010276 013701 001242      MOV      TEMP3,R1
1556 010302 010102      MOV      R1,R2
1557 010304 040100      BIC      R1,R0
1558 010306 043702 010354      BIC      BCCFBK,R2
1559 010312 050200      BIS      R2,R0
1560 010314 043737 010352 001242      BIC      XPOLY,TEMP3
1561 010322 050037 001242      BIS      R0,TEMP3
1562 010326 005337 001236      DEC      TEMP1
1563 010332 001333      BNE      IS
1564 010334 013737 001242 010356      MOV      TEMP3,CALBCC
1565 010342 012602      MOV      (SP)+,R2
1566 010344 012601      MOV      (SP)+,R1
1567 010346 012600      MOV      (SP)+,R0
1568 010350 000205      RTS      RS
1569 010352 000000      XPOLY: 0
1570 010354 000000      BCCFBK: 0
1571 010356 000000      CALBCC: 0
1572      120001      CRC16=120001
1573      102010      CRC.CCITT=102010
  
```

```

***** TEST 3 *****
*THIS TEST PROVES THE DEVICE WILL HANDLE THE
*DDCMP PROTOCOL. SEND AND RECEIVE SYNCs,
*FOLLOWED BY DATA,BCC,DATA AND FINAL BCC.
*****
  
```

```

*****
: TEST 3
*****
*****
TST3: MOV      #3,@TSTNO
      MOV      #.EOP_NEXT
      TSTB     TCNFLG
      BEQ      101$
      MOV      #NEXT,102$+2
101$: MOV      #340,PS          ;RAISE PROCESSOR STATUS
      JSR      R5,SETVEC      ;SET UP VECTORS
      10$      ;BASED ON
      2$       ;THESE
      .BYTE    340,340        ;PARAMETERS
      CLR      TEMP1
      CLR      TEMP2
      CLR      TEMP3
      CLR      TEMP4
      CLR      TEMP5
1603: BIS      #MRESET,@TXCSR ;RESET THE DEVICE
1604: JSR      PC_SMALL        ;WAIT FOR RESET TO FINISH
1605: MOV      #DECMOD!26,@PARCSR ;LOAD THE MODE AND SYNC CHARACTER
1606:
1607: BIS      #SYSTST,@TXCSR   ;ENTER SYSTEM TEST MODE
1608: BIS      #RCVEN!STPSYN,@RXCSR ;LOAD RCVEN!STPSYN
1609: BIS      #SEND,@TXCSR     ;TURN ON TRANSMITTER
1610: MOV      #TSM!26,@TXOBUF  ;OUTPUT A SYNC CHAR
  
```

```

1611 010524 012737 000005 010554      MOV      #5,68$      ;LOAD THE NUMBER
1612 010532 032777 004000 170660 66$:    BIT      #TIMER,@TXDBUF ;CHECK THE TIMER BIT
1613 010540 001374      BNE      66$        ;BR IF SET
1614 010542 032777 004000 170650 67$:    BIT      #TIMER,@TXDBUF ;CHECK THE BIT
1615 010550 001774      BEQ      67$        ;BR IF CLEAR
1616 010552 005327      DEC      (PC)+      ;DECREMENT THE NUMBER
1617 010554 000005      S          5          ;OF TIMES TO REPEAT
1618 010556 001365      BNE      66$        ;BR IF MORE TO GO
1619 010560 105777 170632      TSTB    @TXCSR
1620 010564 100401      BMI     .+4
1621 010566 104005      HLT     5          ;EXTERNAL CLOCKING STOPPED
1622 010570 012777 000426 170622      MOV      #TSOM!26,@TXDBUF
1623 010576 105777 170614 69$:    TSTB    @TXCSR      ;CHECK DONE
1624 010602 100375      BPL     69$        ;BR IF NOT SET
1625 010604 012777 000426 170606      MOV      #TSOM!26,@TXDBUF ;SEND SYNC
1626 010612 052777 000100 170570      BIS      #RINTEN,@RXCSR ;TURN ON INTERRUPTS
1627 010620 052777 000100 170570      BIS      #TXINTE,@TXCSR ;DITTO
1628 010626 005037 177776      CLR     PS          ;LOWER PROCESSOR STATUS
1629 010632
1630 010632 012737 000144 010662 100$:    MOV      #100,74$    ;LOAD THE NUMBER
1631 010640 032777 004000 170552 72$:    BIT      #TIMER,@TXDBUF ;CHECK THE TIMER BIT
1632 010646 001374      BNE      72$        ;BR IF SET
1633 010650 032777 004000 170542 73$:    BIT      #TIMER,@TXDBUF ;CHECK THE BIT
1634 010656 001774      BEQ      73$        ;BR IF CLEAR
1635 010660 005327      DEC      (PC)+      ;DECREMENT THE NUMBER
1636 010662 000144      100.      74$:    ;OF TIMES TO REPEAT
1637 010664 001365      BNE      72$        ;BR IF MORE TO GO
1638 010666 104005      HLT     5          ;FAILED TO FINISH TEST
1639 010670
1640 010670 052777 000400 170520 1$:     BIS      #MRESET,@TXCSR ;RESET THE DEVICE
1641 010676 004737 004610      JSR     PC,SMALL    ;WAIT FOR RESET TO FINISH
1642 010702 012706 001150      MOV     #STACK,SP   ;RESET THE STACK
1643 010706 104400      SCOPE ;SCOPE THIS TEST
1644
1645 ;INTERRUPT SERVICE ROUTINES
1646 ;TRANSMITTER
1647
1648 010710 012777 000252 170502 2$:     MOV      #252,@TXDBUF ;LOAD FIRST DATA CHAR
1649 010716 012737 000326 001236      MOV     #26,TEMP1   ;LOAD DATA
1650 010724 012777 010734 170452      MOV     #35,@DUPTVC ;RELOAD VECTOR
1651 010732 000452      BR      7$         ;LEAVE
1652 010734 013777 001236 170456 3$:     MOV     TEMP1,@TXDBUF ;MOV DATA TO BUFFER
1653 010742 105237 001236      INCB   TEMP1        ;UPDATE DATA
1654 010746 122737 000032 001236      CMPB   #32,TEMP1   ;CHECK FOR DONE
1655 010754 001041      BNE     7$         ;BR IF MORE TO SEND
1656 010756 012777 010766 170420      MOV     #45,@DUPTVC ;RELOAD VECTOR
1657 010764 000435      BR      7$         ;RETURN
1658 010766 012777 001000 170424 4$:     MOV     #TEOM,@TXDBUF ;PUT OUT BCC
1659 010774 012777 011004 170402      MOV     #55,@DUPTVC ;RELOAD VECTOR
1660 011002 000426      BR      7$         ;RETURN
1661 011004 013777 001240 170406 5$:     MOV     TEMP2,@TXDBUF ;LOAD DATA
1662 011012 105237 001240      INCB   TEMP2        ;UPDATE DATA
1663 011016 122737 000100 001240      CMPB   #100,TEMP2  ;CHECK FOR FINISH
1664 011024 001015      BNE     7$         ;BR IF MORE TO GO
1665 011026 012777 011036 170350      MOV     #65,@DUPTVC ;RELOAD VECTOR
1666 011034 000411      BR      7$         ;RETURN

```

```

1667 011036 012777 001000 170354 6$: MOV #TEOM, @TXDBUF ; PUSH OUT DATA BCC
1668 011044 042777 000120 170344 BIC #SEND!TXINTE, @TXCSR ; SHUT DOWN TRANSMITTER
1669 011052 012777 007030 170324 MOV #NO.BTRAP, @DUPTVC ; RESET VECTOR
1670 011060 012716 010632 7$: MOV #100$, (SP) ; SETUP RETURN
1671 011064 000002 RTI ; RETURN
1672
1673 ; RECEIVER
1674
1675 011066 017737 170316 001242 10$: MOV @RXCSR, TEMP3 ; SAVE CSR
1676 011074 017737 170312 001244 MOV @RXDBUF, TEMP4 ; SAVE BUFFER
1677 011102 105737 001242 TSTB TEMP3 ; CHECK FOR DONE
1678 011106 100401 BMI 11$ ; BR IF SET
1679 011110 104005 HLT 5 ; FALSE INTERRUPT
1680 011112 005737 001244 11$: TST TEMP4 ; CHECK FOR ERROR
1681 011116 100001 BPL 12$ ; BR IF NO ERROR
1682 011120 104005 HLT 5 ; RECEIVER ERROR
1683 011122 122737 000252 001244 12$: CMPB #252, TEMP4 ; CHECK DATA
1684 011130 001401 BEQ 13$ ; BR IF A MATCH
1685 011132 104005 HLT 5 ; DATA COMPARE ERROR
1686 011134 012737 000026 001246 13$: MOV #26, TEMPS ; LOAD NEXT EXPECTED
1687 011142 012777 011152 170230 MOV #14$, @DUPRVC ; RELOAD VECTOR
1688 011150 000531 BR 26$ ; LEAVE
1689 011152 017737 170234 001244 14$: MOV @RXDBUF, TEMP4 ; GET DATA
1690 011160 005737 001244 TST TEMP4 ; CHECK FOR ERROR
1691 011164 100001 BPL 15$ ; BR IF NO ERROR
1692 011166 104005 HLT 5 ; DATA ERROR
1693 011170 123737 001246 001244 15$: CMPB TEMPS, TEMP4 ; CHECK DATA
1694 011176 001401 BEQ 16$ ; BR IF A MATCH
1695 011200 104005 HLT 5 ; DATA COMPARE ERROR
1696 011202 105237 001246 16$: INCB TEMPS ; UPDATE DATA
1697 011206 122737 000032 001246 CMPB #32, TEMPS ; CHECK FOR FIRST PART FINISH
1698 011214 001107 BNE 26$ ; BR IF MORE TO GO
1699 011216 012777 011226 170154 MOV #17$, @DUPRVC ; SET UP NEXT VECTOR
1700 011224 000503 BR 26$ ; LEAVE
1701 011226 017737 170160 001244 17$: MOV @RXDBUF, TEMP4 ; GET THE BUFFER
1702 011234 005737 001244 TST TEMP4 ; TEST FOR ERROR
1703 011240 100001 BPL +4 ; BR IF OK
1704 011242 104005 HLT 5 ; RECEIVER ERROR
1705 011244 012777 011254 170126 MOV #18$, @DUPRVC ; RELOAD THE VECTOR
1706 011252 000470 BR 26$ ; LEAVE
1707 011254 017737 170132 001324 18$: MOV @RXDBUF, DATA ; GET DATA
1708 011262 032737 010000 001324 BIT #CRCERR, DATA ; CHECK FOR CRC ERROR
1709 011270 001001 BNE 19$ ; BR IF OK
1710 011272 104005 HLT 5 ; CRC ERROR!!!!!!
1711 011274 012777 011310 170076 19$: MOV #20$, @DUPRVC ; SET UP VECTOR
1712 011302 005037 001330 CLR MIND ; SETUP FOR NEXT DATA
1713 011306 000452 BR 26$ ; LEAVE
1714 011310 017737 170076 001244 20$: MOV @RXDBUF, TEMP4 ; GET DATA
1715 011316 005737 001244 TST TEMP4 ; CHECK FOR ERROR
1716 011322 100001 BPL 21$ ; BR IF NO ERROR
1717 011324 104005 HLT 5 ; RECEIVER ERROR
1718 011326 123737 001330 001244 21$: CMPB MIND, TEMP4 ; CHECK DATA
1719 011334 001401 BEQ 22$ ; BR IF A MATCH
1720 011336 104005 HLT 5 ; DATA ERROR
1721 011340 105237 001330 22$: INCB MIND ; UPDATE SOFTWARE DATA
1722 011344 122737 000100 001330 CMPB #100, MIND ; CHECK FOR FINISH

```

# M03

DZDPE-A MACY11 27(732) 21-OCT-76 16:11 PAGE 39  
 DZDPEA.CMB END OF PASS ROUTINE

1723	011352	001030			BNE	26\$	:BR IF MORE TO GO
1724	011354	012777	011364	170016	MOV	#23\$,ADUPRVC	:RELOAD FINAL VECTOR
1725	011362	000424			BR	26\$	:LEAVE
1726	011364	017737	170022	001244	23\$:	MOV	@RXDBUF,TEMP4
1727	011372	005737	001244		TST	TEMP4	:GET DATA
1728	011376	100001			BPL	24\$	:CHECK FOR ERROR
1729	011400	104005			HLT	5	:BR IF OK
1730							:RECEIVER ERROR ON FIRST OCTET
1731	011402	105777	170002		24\$:	TSTB	@RXCSR
1732	011406	100375			BPL	24\$	:TEST DONE
1733	011410	017737	167776	001324	MOV	@RXDBUF,DATA	:BR IF NOT SET
1734	011416	032737	010000	001324	BIT	#CRCERR,DATA	:GET SECOND BCC OCTET
1735	011424	001001			BNE	25\$	:CHECK FOR BCC ERROR
1736	011426	104005			HLT	5	:BR IF OK
1737	011430	012716	010670		25\$:	MOV	#1\$, (SP)
1738	011434	000002			26\$:	RTI	:BCC ERROR ON SECOND PART OF MSG
1739							:SETUP TO FINISH TEST
1740							:RETURN

# N03

DZDPE-A MACY11 27(732) 21-OCT-76 16:11 PAGE 40  
 DZDPEA.CMB END OF PASS ROUTINE

1741	011436	052777	042516	050130	EM1:	.ASCIZ	<377>/UNEXPECTED INTERRUPT ON VECTOR "A" /
(1)	011503	377	047125	054105	EM2:	.ASCIZ	<377>/UNEXPECTED INTERRUPT ON VECTOR "B" /
(1)	011550	042777	051122	051117	EM3:	.ASCIZ	<377>/ERROR WHEN USING MODEM LEADS /
(1)	011607	377	051105	047522	EM4:	.ASCIZ	<377>/ERROR IN SDLC /
(1)	011627	377	051105	047522	EM5:	.ASCIZ	<377>/ERROR IN DECMODE /
(1)	011652	051377	047125	042040	EM6:	.ASCIZ	<377>/RUN DIAGNOSTICS /
(1)							
(1)							
(1)	011674						
(1)	011674	000000					
(1)	011676	000000					
(1)	011700	000000					
(1)	011702	011436					
(1)	011704	011652					
(1)	011706	000000					
(1)							
(1)	011710	011503					
(1)	011712	011652					
(1)	011714	000000					
(1)							
(1)	011716	011550					
(1)	011720	011652					
(1)	011722	000000					
(1)							
(1)	011724	011607					
(1)	011726	011652					
(1)	011730	000000					
(1)							
(1)	011732	011627					
(1)	011734	011652					
(1)	011736	000000					
(1)	011740						
1742		000001					

  

	.ERRTAB:	0	
		0	
		0	
		EM1	
		EM6	;HALT 1
		0	
		EM2	
		EM6	;HALT 2
		0	
		EM3	
		EM6	;HALT 3
		0	
		EM4	
		EM6	;HALT 4
		0	
		EM5	
		EM6	;HALT 5
		0	
	CORMAX:		
	.END		





INSTR2	003412	899	911#						
JUMPER	006710	1291#							
LIMITS	003540	938	949#						
LOBITS	003616	924*	953	969#	970				
LOCK	001220	526#	859*	867	1092	1392*			
LOKFLG	001350	540#							
LOLIM	003610	921*	971	966#					
LPCNT	001224	528#	4*	855	858*				
LSTERR	001234	532#	6*	798*	841*	1070	1072*		
LOO.OO	001440	603#	1248#	1246					
MALLJM	005663	691	1168#						
MASK.A	001436	599#	1247						
MASSTK	005155	1094	1168#						
MCRLF	004702	877	974	1090	1091	1099	1168#	1254	1271
MCSR	005237	659	1168#						
MCSRX	005105	803	1168#						
MDATA	006060	1001	1011	1177#					
MDFLG	001340	533#	656*	677	678				
MOSC	005737	709	1168#						
MEPASS	004723	802	1168#						
MEPPPC	005232	1097	1168#						
MERFX	005132	809	1168#						
MEF92	004751	1168#	1194						
MEF93	005020	759	1168#						
NEXT =	010000	533#	1378	1431	1592				
MIND	001330	533#	1712*	1718	1721*	1722			
MJMPR	005271	697	1168#						
MLOCK	007756	783	1168#						
MPJOE =	015300	533#							
MPMODEA=	004300	533#							
MPMODEB=	010000	533#							
MPMODEH	005606	675	1168#						
MNEW	005157	754	1168#						
MPAR	005446	1168#							
MPASSX	005121	807	1168#						
MPOWER	004705	1152	1168#						
MPM	004676	909	1168#	1277					
MR	004746	790	1169#	1272					
MRESET=	000400	467#	533#	1375	1427	1531	1603	1640	
MSRJM	005525	705	1168#						
MSTJM	005472	701	1168#						
MTCN	005344	685	1168#						
MTDATA=	040000	533#							
MTITLE	001000	505#	644						
MTOTAL	005413	1168#							
MTSTN	005143	1095	1168#	1256					
MTSTPC	005044	1168#							
MVEC	005256	66*	1168#						
MVECX	005113	805	1168#						
NEXT	001216	525#	861	1128	1347*	1426*	1589*		
NO.ATR	007024	1323#							
NO.BTR	007030	1327#	1516	1669					
OJUMPE	006756	1307#	1371						
OPCLRJ	001323	533#	699	1294	1300				
OVRUN=	040000	533#							
PARAM =	104405	562#	660	668	1257				

# E04

DZDPE-A MACY11 27(732) 21-OCT-76 16:11 PAGE 45  
 DZDPEA.CMB CROSS REFERENCE TABLE -- USER SYMBOLS

PARAM1 003460	927#	944																	
PARBIT= 000000	467#																		
PARCSR 001414	585#	1225*	1605*																
PARERR 003534	930	932	934	943#	950	952	954												
PASCNT 001230	530#	620*	800*	801	834														
PC =%000007	431#	819*	1141*	1164*	1249*	1284*	1376*	1385*	1400*	1428*	1464*	1481*	1532*						
	1604*	1616*	1635*	1641*															
PERFOR= 000000	467#																		
POPPO = 012600	445#	1122																	
POP1SP= 005726	443#																		
POP2SP= 022626	447#	863																	
PRIRTY 001320	533#																		
PRISEC= 010000	533#																		
PS = 177776	436#	616*	777*	1446*	1474*	1526*	1593*	1628*											
PUSHRO= 010046	444#	1119																	
PUSH1S= 005746	442#																		
PUSH2S= 024646	446#																		
PURUP 004624	1146	1148#																	
QV.FLG 001351	541#	622*	813*	852															
RAFORT= 007000	533#																		
RCRCIN= 07.000	533#																		
RCRC7T= 100000	533#																		
RCVEN = 000020	533#	1452	1608																
RE.CACT= 004000	533#																		
REOM = 001000	533#																		
RESREG 004476	1111	1114#																	
RESTRT 003000	812	816	824#																
RESOS = 104407	566#	1114																	
RETURN 001214	524#	628*	789*	791	824*	861*	864	1128*	1130	1153	1270*	1280*	1281						
RING = 040000	533#	1393																	
RINTEN= 000100	533#	1453	1626																
RSOM = 000400	533#																		
RTS = 000004	533#	1379	1393																
RUN 001314	533#	624*	1197	1200*	1201*	1208*	1209*												
RXCSR 001410	583#	828	1216*	1220	1374*	1377	1452*	1453*	1521	1608*	1626*	1675	1731						
RXDBUF 001412	584#	1222*	1223*	1224	1225	1226	1490	1520	1523	1676	1689	1701	1707						
	1714	1726	1733																
RXDERR= 100000	533#																		
RXDONE= 000200	533#																		
RD =%000000	424#	652*	653*	654	724*	729	731	733	755*	763*	764*	766*	768*						
	770	771	842	849#	842*	971*	975	988*	992*	1002	1018*	1120*	1210*						
	1216	1217	1218	1219#	1239	1241	1243	1246*	1263*	1264	1266	1268	1270						
	1274	1275	1293	1291#	1296	1299	1302	1304	1307*	1310	1312	1313	1536						
	1543*	1545*	1546	1549*	1550*	1551	1554*	1557*	1559*	1561	1567*								
R1 =%000001	425#	725*	729*	730*	731*	732*	733*	767*	768	769*	770	815*	819						
	971#	976	982	983	984	985	1017*	1158*	1159	1161	1162	1247*							
	1291	1305*	1307	1314*	1353*	1356	1357	1358	1363	1364	1365	1371*	1433*						
	1437	1442*	1537	1555*	1556	1557	1566*												
R2 =%000002	426#	971*	1157*	1159*	1160*	1248*	1538	1556*	1558*	1559	1565*								
R3 =%000003	427#	886	893*	903*	906*	907	912*	971*	977	989*	990*	991*	992						
	1001#	1002*	1007*	1010*	1016*	1283*	1377*	1379*	1388	1394*	1403								
R4 =%000004	428#	887	892*	896*	897*	898	905*	908	911*	919	928*	929	931						
	933	935*	936	937	959*	959*	963*	971*	978	986*	989	994*	996*						
	998#	1015*	1077*	1078*	1079*	1080*	1081*	1082*	1083	1084	1085	1388*	1389						
	1403#	1404																	
R5 =%000005	429#	870	871*	875	880	882*	918	920*	921	922	923	924	925						









ADC	1545														
ADCB	1201	1209													
ADU	730	732	742	872	889	960	981	991	1040	1056	1079	1082	1202	1211	1239
	1241	1243													
ASL	929	940	941	1054	1078	1080									
BCC	728														
BEQ	643	679	689	716	739	745	753	782	816	844	853	867	899	930	938
	1006	1064	1071	1087	1093	1102	1107	1111	1116	1127	1253	1293	1295	1301	1309
	1384	1390	1399	1405	1430	1463	1480	1492	1529	1547	1591	1615	1634	1684	1694
	1719														
BGT	934														
BHI	950														
BIC	764	990	1032	1055	1081	1356	1357	1358	1363	1364	1365	1393	1515	1551	1557
	1558	1560	1668												
BICB	897	935													
BIS	1375	1378	1379	1427	1447	1452	1453	1456	1473	1531	1559	1561	1603	1607	1608
	1609	1626	1627	1640											
BISB	936														
BIT	744	752	781	843	850	867	873	1063	1068	1124	1126	1252	1381	1383	1396
	1398	1460	1462	1477	1479	1546	1612	1614	1631	1633	1708	1734			
BITB	953	1197													
BLO	952														
BLOS	758														
BLT	932														
BMI	1620	1678													
BNE	641	655	695	747	751	772	780	812	851	856	874	881	904	954	962
	1000	1004	1009	1013	1034	1038	1069	1089	1125	1163	1193	1198	1204	1214	1251
	1265	1267	1269	1276	1349	1352	1355	1362	1368	1382	1387	1397	1402	1443	1461
	1466	1468	1478	1483	1496	1506	1563	1613	1618	1632	1637	1655	1664	1698	1709
	1723	1735													
.L	647	847	876	879	895	901	1066	1118	1455	1471	1522	1624	1681	1691	1703
	1716	1728	1732												
BR	634	682	719	734	743	761	786	845	849	910	942	944	1036	1043	1196
	1206	1273	1278	1360	1508	1511	1651	1657	1660	1666	1688	1700	1706	1713	1725
CLC	722	726	993	995	997	1199	1207	1552							
CLR	620	625	626	653	749	755	769	798	841	858	859	927	1160	1374	1394
	1433	1445	1472	1474	1542	1598	1599	1600	1601	1602	1628	1712			
CLRB	621	622	656	657	680	681	799	857	1010	1035	1073	1359	1366		
CMP	637	642	654	770	771	855	949	951	1070	1115	1161	1162	1203	1212	1264
	1266	1268	1275	1299	1312	1389	1404	1528							
CMPB	757	898	929	931	933	937	1033	1037	1491	1505	1654	1663	1683	1693	1697
	1718	1722													
COM	1527	1548	1550												
COMB	645	650													
DEC	715	903	999	1012	1369	1370	1385	1400	1464	1467	1481	1562	1616	1635	
DECB	811	961	1003	1008											
EMT	448														
HALT	479	756	760	765	1121	1147	1195								
INC	800	854	1123	1221	1223	1227	1230	1232	1234	1236					
INCB	1442	1494	1504	1653	1662	1696	1721								
J.F.P	501	648	748	791	825	864	1058	1130	1153	1281	1298	1303	1311	1350	1533
JSR	819	1249	1371	1376	1428	1438	1449	1497	1532	1594	1604	1641			
MOV	616	617	618	623	627	628	630	631	632	635	636	638	639	652	683
	724	725	729	731	733	737	738	766	767	768	777	778	784	785	787
	788	789	801	815	824	842	848	860	861	862	867	870	871	882	886
	887	888	892	893	902	905	906	907	908	911	912	918	919	920	921



L04

DZDPE-A MACY11 27(732) 21-OCT-76 16:11 PAGE 54  
DZDPEA.CMB CROSS REFERENCE TABLE -- PERMANENT SYMBOLS

.SBTTL	385	419	469	503	608	792
.TITLE	398					
.WORD	533	1408	1409	1410	1411	

ERRORS DETECTED: 0  
DEFAULT GLOBALS GENERATED: 0

\* DZDPEA.SEG/SOL/CRF/PAGNUM/NL:TOC=DZDPEA.MAC,DZDPEA.CMB  
RUN-TIME: 15 21 3 SECONDS  
RUN-TIME RATIO: 120/41=2.9  
CORE USED: 18K (35 PAGES)

