



symbols (such as any) not associated with


PD 700 Pulse Distributor



FEED-PULSE SHAPER 5600

CTS 3600-3900

TTS 4000



INIT. WRITE CONTROL 4900

RAW INIT. WRITE

OPER. STOPS & JUMP 5000







C.S. CONTROL



WRONG ADDRESS 2E

- SA Shaper Amplifier
- PF Thyatron Pulse Former
- PA Pulse Amplifier
- T Trigger Tube
- D Delay
- DC A DC Amplifier

SINCYDEP

Note: Leads labeled with Command Symbols are connected to TTS or CTS output as the particular Command.
Nos. in paren. identify misc. F.P.'s





Control Block 5300

MAIN ELECTRONIC CONTROL
13-100
XG 5663