KD11-A

CPU DIAG

MD-11-DQBEA-B

EP-DQBEA-B-DL-A

COPYRIGHT © 1976

FICHE 1 OF 4

NOV 1976

digital

MADE IN USA

KD11-A

11/40 CPU TEST

MD-11-DBQEA-B

EP-DBQEA-B-DL-A

COPYRIGHT © 1976

FICHE 2 OF 4

NOV 1976

digital

MADE IN USA



KD11-A

11/40 CPU TEST

MD-11-DBQEA-B

EP-DBQEA-B-DL-A

COPYRIGHT © 1976

FICHE 3 OF 4

NOV 1976

digital

MADE IN USA

KD11-A

11/40 CPU TEST

MD-11-DBQEA-B

EP-DBQEA-B-DL A

COPYRIGHT © 1976

FICHE 4 OF 4

NOV 1976

digital

MADE IN USA



```
                                        .REM    0
```

PRODUCT CODE: MAINDEC - 11 - DBQEA-B

PRODUCT NAME: KD11-A CPU DIAGNOSTIC (PDP11/40)

DATE: 21-AUGUST-1975

MAINTAINER: DIAGNOSTIC ENGINEERING

AUTHOR: E. CROWLEY

COPYRIGHT (C) 1975
DIGITAL EQUIPMENT CORPORATION, MAYNARD, MASS.

THIS SOFTWARE IS FURNISHED UNDER A LICENSE FOR USE ONLY ON A SINGLE COMPUTER SYSTEM AND MAY BE COPIED ONLY WITH THE INCLUSION OF THE ABOVE COPYRIGHT NOTICE. THIS SOFTWARE, OR ANY OTHER COPIES THEREOF , MAY NOT BE PROVIDED OR OTHERWISE MADE AVAILABLE TO ANY OTHER PERSON EXCEPT FOR USE ON SUCH SYSTEM AND TO ONE WHO AGREES TO TO THESE LICENSE TERMS. TITLE TO AND OWNERSHIP OF THE SOFTWARE SHALL AT ALL TIMES REMAIN IN DEC.

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION.

DEC ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT WHICH IS NOT SUPPLIED BY DEC.

PRODUCT CODE: MAINDEC - 11 - DBQEA-B
PRODUCT NAME: KD11-A CPU DIAGNOSTIC (PDP11/40)
DATE: 21-AUGUST-1975
MAINTAINER: DIAGNOSTIC ENGINEERING
AUTHOR: E. CROWLEY

COPYRIGHT (C) 1975
DIGITAL EQUIPMENT CORPORATION, MAYNARD, MASS.

THIS SOFTWARE IS FURNISHED UNDER A LICENSE FOR USE ONLY ON A SINGLE COMPUTER SYSTEM AND MAY BE COPIED ONLY WITH THE INCLUSION OF THE ABOVE COPYRIGHT NOTICE. THIS SOFTWARE, OR ANY OTHER COPIES THEREOF , MAY NOT BE PROVIDED OR OTHERWISE MADE AVAILABLE TO ANY OTHER PERSON EXCEPT FOR USE ON SUCH SYSTEM AND TO ONE WHO AGREES TO TO THESE LICENSE TERMS. TITLE TO AND OWNERSHIP OF THE SOFTWARE SHALL AT ALL TIMES REMAIN IN DEC.

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION.

DEC ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT WHICH IS NOT SUPPLIED BY DEC.

TABLE OF CONTENTS

1.0 GENERAL PROGRAM INFORMATION

1.1 PROGRAM PURPOSE
1.2 SYSTEM REQUIREMENTS
1.3 RELATED DOCUMENTS AND STANDARDS
1.4 DIAGNOSTIC HIERARCHY PREREQUISITES
1.5 FAILURE ASSUMPTIONS

2.0 OPERATING INSTRUCTIONS

2.1 LOADING AND STARTING PROCEDURES
2.2 SPECIAL ENVIRONMENTS
2.3 PROGRAM OPTIONS
2.4 EXECUTION TIMES

3.0 ERROR INFORMATION

3.1 ERROR REPORTING PROCEDURES

4.0 PERFORMANCE AND PROGRESS REPORTS

4.1 PERFORMANCE REPORTS
4.2 PROGRESS REPORTS

5.0 DEVICE INFORMATION TABLES

5.1 KD11-A MICROPROGRAMMING INFORMATION
5.2 MICROWORD CONTROL SIGNAL TEST POINTS
5.3 KD11-A LOGIC PRINT SUMMARY

6.0 MAINTENANCE PROCEDURES

6.1 INTRODUCTION
6.2 MICROPROGRAMMING / LOGIC INFORMATION
6.3 KM11 MAINTENANCE MODULE
6.4 UPP MATCH MAINTENANCE FEATURE

7.0 FLOW CHARTS

7.1 FUNCTIONAL FLOW
7.2 SUB-FUNCTIONAL FLOW
7.3 FUNCTIONAL TEST FLOWS
7.4 CORE MEMORY MAP

8.0 SUB-TITLE INDEX OF TESTS

1.0 GENERAL PROGRAM INFORMATION

1.1 PROGRAM PURPOSE

"DBQEAB" IS A DIAGNOSTIC PROGRAM DESIGNED TO DETECT, REPORT, AND IDENTIFY LOGIC FAULTS IN THE KD11-A CENTRAL PROCESSING UNIT OF THE PDP11/40 SYSTEM. IT CONSISTS OF 525(10) INDIVIDUAL TESTS CAREFULLY DESIGNED AND SEQUENCED TO DETECT AND ATTEMPT TO IDENTIFY LOGIC FAULTS AT A MINIMUM HARDWARE/SOFTWARE LEVEL. THESE TESTS ARE PARTITIONED INTO THREE MAJOR SECTIONS AS DESCRIBED BELOW:

A. BASIC INSTRUCTION TESTS (BIT)

THIS SECTION CONSISTS OF A LOGICALLY SEQUENCED SET OF BASIC INSTRUCTION TESTS DESIGNED TO VERIFY THE INTEGRITY OF THOSE INSTRUCTIONS AND LOGIC OPERATIONS USED BY THE UTILITY ROUTINES THAT PROVIDE ERROR LOGGING AND SCOPE LOOPING FACILITIES FOR THE SUBSEQUENT TWO MAJOR SECTIONS. NO UTILITY IS CALLED UNTIL ITS INSTRUCTION COMPLEMENT HAS BEEN VERIFIED. THIS SCHEME ACCOMPLISHES TWO IMPORTANT MAINTENANCE OBJECTIVES: 1)IT MINIMIZES THE POSSIBILITY OF THE ERROR REPORTING ROUTINES CONVEYING AMBIGUOUS ERROR INFORMATION TO THE USER, AND 2)IT MAXIMIZES THE POSSIBILITY THAT THE ERROR WILL BE DETECTED BY A ROUTINE DESIGNED TO IDENTIFY FAILING OPERATIONS RATHER THAN HAVE THE ERROR MANIFEST ITSELF IN A MORE COMPLEX UTILITY ROUTINE THAT IS NOT STRUCTURED TO DIAGNOSE FAULTS.

ANY FAULT DETECTED IN THIS SECTION CAUSES THE PROGRAM TO "HALT" WITH THE CONSOLE ADDRESS AND DATA DISPLAYS INDICATING THE FAILING TEST. ADDITIONAL FAULT IDENTIFICATION INFORMATION IS AVAILABLE IN THE PROCESSOR'S GENERAL REGISTERS, PSW, STACK, AND PROGRAM ANNOTATION FOR THE FAILING TEST. A LOCK ON HARD ERROR FEATURE IS EMPLOYED TO PREVENT THE PROGRAM FROM CONTINUING ON ONCE A SOLID ERROR IS DETECTED. DEPRESSING CONTINUE AFTER THE ERROR HALT CAUSES A RETRY OF THE FAILING TEST

B. COMPREHENSIVE INSTRUCTION TESTS (CIT)

THIS SECTION, COMPRISED OF THE BULK OF THE TESTS, CONSISTS OF A LOGICALLY SEQUENCED AND PARTITIONED SET OF INSTRUCTION TESTS DESIGNED TO TEST AND VERIFY ALL THE MICROINSTRUCTION SEQUENCES AND DATA PATH DATA MANIPULATIONS IMPLICIT IN THE DESIGN SPECIFICATION OF THE KD11-A MICROPROGRAM. ALL LOGIC SEQUENCES, THAT CAN BE ACTIVATED IN THE PROGRAM "RUN" MODE ARE TESTED WITH THE EXCEPTION OF THE SMALL AMOUNT OF LOGIC THAT REQUIRES AN ACTIVE "DMA" DEVICE. THIS EXCLUDES THOSE SEQUENCES AND LOGIC FUNCTIONS THAT SUPPORT THE CONSOLE FUNCTIONS (LOAD ADDRESS, DEPOSIT, ETC.). EACH TEST IN THIS SECTION CALLS A "SCOPE LOOP" UTILITY THAT FACILITATES USER CONTROL OF TEST SELECTION AND EXECUTION VIA THE CONSOLE SWITCH REGISTER.

UPON DETECTION OF A LOGIC FAULT, EACH TEST IN THIS SECTION CALLS AN "ERROR SERVICE" ROUTINE THAT LOGS THE ERROR AND REPORTS IT AS HARD COPY ON THE CONSOLE TERMINAL DEVICE. THE ERROR SERVICE ROUTINE ALSO FACILITATES USER CONTROL OF THE PROGRAM SEQUENCE VIA CONSOLE SWITCH REGISTER OPTIONS. AFTER REPORTING THE ERROR THE PROGRAM CONTINUES ON IN ITS NORMAL SEQUENCE UNLESS MODIFIED BY THE USER ACTIVATING THE "LOCK ON HARD ERROR" SWITCH OPTION.

C. COMBINED INSTRUCTION EXERCISER (IEX)

THIS SECTION CONSISTS OF A MORE COMPLEX SET OF INSTRUCTION TESTS DESIGNED TO TEST THE INSTRUCTIONS WHEN USED IN VARIOUS COMBINATIONS MANIPULATING VARIABLE DATA PATTERNS. LIKE THE PREVIOUS SECTION, IT CALLS THE "ERROR SERVICE" AND "SCOPE LOOP" UTILITIES TO REPORT ERRORS AND ALLOW USER CONTROL OF TEST EXECUTION.

WHERE AT ALL POSSIBLE THE PROGRAM ANNOTATION ATTEMPTS TO CALL OUT THE MOST PROBABLE FAILURE TO THE FUNCTIONAL LOGIC AREA. EACH TEST OR GROUP OF GENERIC TESTS INCLUDES MICROPROGRAMMING AND LOGIC INFORMATION TO FACILITATE FURTHER ISOLATION OF THE FAULTY COMPONENT THRU THE USE OF ADDITIONAL LOWER LEVEL CHECKS BY THE MAINTENANCE TECHNICIAN USING THE KM-11 MAINTENANCE MODULE OR OSCILLOSCOPE. DETAILED PROCEDURES FOR USING THIS MAINTENANCE INFORMATION IS INCLUDED IN PARA. 6.0.

1.2 SYSTEM REQUIREMENTS

A. HARDWARE REQUIREMENTS

1. PDP11/40 CPU WITH OPERATOR'S CONSOLE
2. 16K OF CORE STORAGE - MF11/U OR EQUIVALENT
3. DL11 ASYNCHRONOUS LINE INTERFACE WITH TERMINAL
4. KW11-L LINE CLOCK (OPTIONAL)

B. SOFTWARE REQUIREMENTS

1. PDP11 ABSOLUTE LOADER PROGRAM FOR PAPER TAPE SYSTEMS
2. XXDP MONITOR FOR DECTAPE,MAGTAPE,CASSETTE, OR DISK SYSTEMS.

1.3 RELATED DOCUMENTS AND STANDARDS

A. PDP11/40 PROCESSOR HANDBOOK
B. PDP11 PERIPHERALS HANDBOOK
C. KD11-A PROCESSOR MAINTENANCE MANUAL
D. PDP11/40 SYSTEM ENGINEERING DRAWINGS
E. DIAGNOSTIC ENGINEERING STANDARDS AND CONVENTIONS
PROGRAMMING PRACTICES - DOC NO. 175-003-009-00

1.4 DIAGNOSTIC HIERARCHY PREREQUISITES

"DBQEAB" ASSUMES THAT THE HARDCORE VERIFIED BY THE "BCPT" (RESIDENT BASIC CPU TEST FOR 1080 SYSTEMS) IS OPERATIONAL. A COPY OF THE "BCPT" TEST IS INCLUDED AS PART OF THE LOAD MODULE AND IS RESIDENT IN CORE STARTING AT LOCATION 1000(8) WHENEVER "DBQEAB" IS LOADED. AUTOMATIC LINKAGE TO THE START OF "DBQEAB" OCCURS IF "BCPT" RUNS ERROR FREE. THIS PROVIDES THE USER WITH THE OPTION OF RUNNING "BCPT" PRIOR TO EXECUTING "DBQEAB" IF HE SUSPECTS A FAULT IN THE "HARD CORE".

1.5 FAILURE ASSUMPTIONS

"DBQEAB" ASSUMES THAT THE STORAGE MEDIUM USED TO STORE THE PROGRAM IS INTACT AND THAT IT CAN BE LOADED INTO CORE. IT ALSO ASSUMES THAT THE BASIC TESTS DESCRIBED IN PARA. 1.4 RUN ERROR FREE AND ANY ASSUMPTIONS MADE BY THESE TESTS IS VALID. (REFER TO MAINDEC-10-DFQMAA FOR A DESCRIPTION OF THE 1080 RESIDENT TESTS)

2.0 OPERATING INSTRUCTIONS

2.1 LOADING AND STARTING PROCEDURES

A. LOADING PROCEDURES

1) PAPER TAPE SYSTEMS

USE THE STANDARD PDP11 ABSOLUTE LOADER PROCEDURES.

2) XXDP SYSTEMS

USE THE STANDARD XXDP MONITOR LOADING PROCEDURES.

B. STARTING PROCEDURES

1. TO RUN "DBQEAB" ONLY

A) SET SR = 000200
B) DEPRESS LOAD ADDRESS
C) SET SR = 000000 (NO SWITCH OPTIONS)
D) SET HALT/ENABLE IN THE ENABLE POSITION
E) DEPRESS START
F) REFER TO PARA. 3.0 AND 4.0 FOR NORMAL PROGRAM RESPONSES AND ERROR REPORTS.

2. TO RUN "BCPT" PRIOR TO "DBQEAB"

A) SET THE SR = 1000
B) DEPRESS LOAD ADDRESS
C) SET SR = 000000 (NO SWITCH OPTIONS)

```
                                                    D) SET HALT/ENABLE IN THE ENABLE POSITION
                                                    E) DEPRESS START
                                                    F) REFER TO PARA. 3.0 AND 4.0 FOR NORMAL
                                                       PROGRAM RESPONSES AND ERROR REPORTS OR TO
                                                       THE "BCPT" DOCUMENT IF AN ERROR HALT OCCURS
                                                       IN THE BCPT SECTION.

                                        C. RESTART PROCEDURES

                                                1. TO INITIALIZE "PASCNT","ERRCNT", AND "PFCNT" TO ZERO

                                                       SAME AS IN 2.1(B1) ABOVE

                                                2. TO PRESERVE "PASCNT","ERRCNT", AND 'PFCNT"

                                                       A) SET SR=003034
                                                       B) DEPRESS LOAD ADDRESS
                                                       C) SET SR=000000 (NO OPTIONS)
                                                       D) SET HALT/ENABLE TO ENABLE POSITION
                                                       E) DEPRESS START SWITCH
```

2.2 SPECIAL ENVIRONMENTS

A. 16K PDP11/40 SYSTEMS

FOR 16K SYSTEMS USING THE "XXDP" PACKAGE YOU WILL BE UNABLE TO USE THE "UPDATE" PROGRAMS TO LOAD,SAVE, UPDATE ETC. SINCE THE SIZE OF "DBQEAB" WILL NOT PERMIT SIMULTANEOUS RESIDENCY OF THE UPDATE PROGRAMS. SUFFICIENT FREE CORE IS AVAILABLE FOR THE "XXDP" MONITOR SO THAT "DBQEAB" CAN BE LOADED BY THE MONITOR.

2.3 PROGRAM OPTIONS

A. SWITCH REGISTER OPTIONS

THE FOLLOWING CONSOLE SWITCH REGISTER OPTIONS ARE ACTIVE UPON ENTERING THE COMPREHENSIVE INSTRUCTION TESTS (CIT) SECTION: (SWITCH OPTION IS ACTIVE WHEN SW IS SET TO A "1")

SW15 HALT ON ERROR. IF ERROR PRINTING IS ENABLED THE HALT OCCURS AFTER THE PRINTOUT. DEPRESSING "CONTINUE" CAUSES THE PROGRAM TO PROCEED ON IN NORMAL SEQUENCE FROM THE POINT OF ERROR.

SW14 CONTINUOUSLY LOOP ON THE CURRENT TEST

SW13 INHIBIT NORMAL ERROR PRINTOUTS - THIS DOES NOT INCLUDE POWER FAIL, BUS ERROR, RSVD INSTR TRAPS, OR MISSED TEST PRINTOUTS.

SW12 INHIBIT ALL PRINTOUTS NOT COVERED UNDER SW13. THIS INCLUDES I.D., OPTIONS FOUND, ENDPAS, ETC.

SW11 INHIBIT SUB-TEST ITERATIONS. TEST ITERATIONS ARE AUTOMATICALLY INHIBITED ON THE FIRST PASS.

SW10 SEARCH FOR AND CONTINUOUSLY LOOP ON THE TEST NUMBER SELECTED BY THE CONTENTS OF SW<09:00>. ONLY USE THIS OPTION FOR TESTS T0145 THRU T1015 SINCE THE "SCOPE" UTILITY IS NOT ACTIVE UNTIL TEST T0145.

SW09 IF SW10=0 , SW09=1 WILL ACTIVATE THE "LOCK ON HARD ERROR" FEATURE.

IF SW10=1, SW09 BECOMES THE HIGH ORDER BIT IN THE TEST NUMBER TO BE SELECTED.

SW<9:0> USED TO SELECT A PARTICULAR TEST FOR LOOPING IF SW10=1 THERE IS NO TEST 000 DEFINED.

B. MEMORY LOCATIONS

1. FILLS: THERE IS A LOCATION TAGGED "FILLS" THAT IS USED TO SPECIFY THE FILL COUNT AND FILL CHARACTER FOR THOSE TERMINAL DEVICES REQUIRING THE USE OF FILLERS. THE HIGH BYTE CONTAINS THE FILL COUNT AND THE LOW BYTE CONTAINS THE FILLER CHARACTER. IT IS PROGRAM LOADED AS A 002400(8) TO SPECIFY FIVE NULL CHARACTERS.

2. ITCOUNT: THERE IS A LOCATION TAGGED "ITCOUNT" THAT CONTAINS THE ITERATION COUNT TO BE USED ON PASSES SUBSEQUENT TO PASS 0 TO SPECIFY THE NO. OF SUB-TEST ITERATIONS IT IS PROGRAM LOADED TO SPECIFY 32.(10) ITERATIONS.

3. OPTION: THERE IS A LOCATION TAGGED "OPTION" THAT IS SET UP AUTOMATICALLY BY THE PROGRAM TO INDICATE THE PDP11/40 INTERNAL OPTIONS FOUND:

```
BIT15=1 KW11-L INSTALLED
BIT07=1 KT11-D INSTALLED
BIT02=1 KJ11-A INSTALLED
BIT01=1 KE11-F INSTALLED
BIT00=1 KE11-E INSTALLED
```

THE PROGRAM USES THE BITS IN "OPTION" TO SKIP THOSE TESTS THAT ARE OPTION DEPENDENT TO PREVENT REDUNDANT ERROR REPORTS.

4. BPTLOC: THERE IS A LOCATION TAGGED "BPTLOC" THAT PROVIDES THE USER THE MECHANISM FOR SETTING SIXTEEN "BREAKPOINT HALTS" THROUGHOUT THE PROGRAM. THIS ENABLES RAPIDLY "HOMING IN" ON THE FAILING TEST IN THOSE CASES WHERE THE FAULT CAUSES A RUNAWAY OR HUNG PROGRAM. REFER TO PARA. 4.2 FOR A DETAILED DESCRIPTION OF THE USE OF THIS FEATURE.

2.4 EXECUTION TIMES

ONE COMPLETE ERROR FREE PASS OF DBQEAA WITH NO TEST ITERATIONS SHOULD TAKE LESS THAN 5 SECONDS. A SUCCESSFUL PASS WILL BE INDICATED BY THE FOLLOWING PRINTOUT ON THE CONSOLE DEVICE:

```
PASCNT = 000001  ERRCNT = 000000
```

WITH ITERATIONS ENABLED A COMPLETE ERROR FREE PASS SHOULD TAKE LESS THAN 2 MINUTES.

3.0 ERROR INFORMATION

3.1 ERROR REPORTING PROCEDURES

A. ERROR MESSAGE FORMATS

1. STANDARD ERROR MESSAGE HEADER

```
                THE FOLLOWING HEADER IS PRINTED ON DETECTION OF THE FIRST
                ERROR DETECTED AFTER THE BASIC INSTRUCTION TEST SECTION.
                IT IS ONLY PRINTED ONCE PER PROGRAM PASS.

              (PC)   (PS)    (SP)   (TEST)   (IR)   DEST    WAS    S/B
              (R7)   (PSW)   (R6)    (R0)    (R1)   (R2)   (R3)   (R4)

              WHERE:

              (PC)    INDICATES THE CONTENTS OF THE PROGRAM COUNTER AT THE
                      TIME OF THE ERROR CALL. THIS IS NORMALLY AN ADDRESS
                      THAT IS USED TO LOCATE THE ERROR CALL STATEMENT IN
                      THE FAILING TEST.

              (PSW)   INDICATES THE CONTENTS OF THE PROCESSOR STATUS WORD
                      AT THE TIME OF THE ERROR CALL

              (SP)    INDICATES THE CONTENTS OF THE STACK POINTER (R6) AT
                      THE TIME OF THE ERROR. (NOTE THAT THE ERROR CALL
                      WILL PUSH THE STACK TWICE)

              (R0)    INDICATES THE TEST NO. (IN OCTAL) THAT FAILED

              (R1)    CONTAINS A COPY OF THE TEST INSTRUCTION
                      THIS WILL BE THE FIRST WORD IN THE CASE OF TWO
                      OR THREE WORD INSTRUCTIONS.

              (R2)    FOR SINGLE AND DOUBLE OPERAND INSTRUCTIONS R2
                      NORMALLY CONTAINS THE DESTINATION ADDRESS

              (R3)    FOR SINGLE AND DOUBLE OPERAND INSTRUCTIONS R3
                      CONTAINS WHAT THE RESULT (DEST. OPERAND) ACTUALLY
                      WAS AFTER THE TEST.

              (R4)    FOR SINGLE AND DOUBLE OPERAND INSTRUCTIONS R4
                      CONTAINS WHAT THE RESULT (DEST. OPERAND)
                      SHOULD HAVE BEEN (S/B).

              IN SOME CASES THE ERROR INFORMATION MAY DEVIATE FROM THAT
              DESCRIBED ABOVE BUT THE PROGRAM ANNOTATION FOR THOSE TESTS
              WILL DESCRIBE THE MEANING OF THOSE ENTRIES THAT HAVE BEEN
              RE-DEFINED.

              THE ERROR CALL STATEMENT MAY BE ENCODED TO PRINT ONLY THE
              INFORMATION RELATIVE TO THE PARTICULAR FUNCTION BEING TESTED.
              INTERPRETATION OF THE ERROR CALLS IS AS FOLLOWS:

                      ERROR   PRINTS ALL 8 COLUMNS
                      ERROR1  PRINT ONLY COLUMN 1
                      ERROR2  PRINT COLUMNS 1,2
                      ERROR3  PRINT COLUMNS 1,2,3
                      ERROR4  PRINT COLUMNS 1,2,3,4
                      ERROR5  PRINT COLUMNS 1,2,3,4,5
                      ERROR6  PRINT COLUMNS 1,2,3,4,5,6
                      ERROR7  PRINT COLUMNS 1,2,3,4,5,6,7
```

2. STANDARD ERROR PRINTOUT

A LINE OF FROM ONE TO EIGHT SIX DIGIT OCTAL NUMBERS THAT LINE UP UNDER THE APPROPRIATE HEADER ENTRY AND HAVE THE MEANINGS DESCRIBED IN THE PREVIOUS SECTION.

3. RESERVED INSTRUCTION TRAP ERROR MESSAGE

ANY RESERVED INSTRUCTION TRAP DETECTED AFTER THE BASIC TESTS RESULTS IN THE FOLLOWING PRINTOUT:

TRAPPED TO 10 PC = XXXXXX

WHERE: XXXXXX IS THE CONTENTS OF THE PROGRAM COUNTER AT THE TIME THE TRAP WAS SPRUNG.

AFTER REPORTING THE ERROR, THE PROGRAM IS RESTARTED FROM THE BEGINNING.

IF A RSVD INSTRUCTION TRAP OCCURS WHILE IN THE PROCESS OF TRYING TO SERVICE A PREVIOUS RSVD INSTRUCTION TRAP OR A BUS ERROR TRAP THE PROGRAM HALTS. A DESCRIPTION OF THIS HALT IS CONTAINED IN PARA. 3.1 B4 BELOW.

IF A RSVD INSTRUCTION TRAP OCCURS PRIOR TO COMPLETION OF THE BASIC INSTRUCTION TEST SECTION THE PROGRAM WILL HALT VIA A TRAPCATCHER IN THE VECTOR. A DESCRIPTION OF THIS HALT IS DESCRIBED IN PARA. 3.1,B2 BELOW.

4. BUS ERROR TRAP ERROR MESSAGE

ANY UNEXPECTED BUS ERROR TRAPS (BUS TIMEOUT, ODD ADDRESS ERROR, ILLEGAL INSTRUCTION, OR STACK OVERFLOW) RESULTS IN THE FOLLOWING PRINTOUT:

TRAPPED TO 4 PC = XXXXXX

WHERE: XXXXXX IS THE CONTENTS OF THE PC AT THE TIME THE TRAP WAS SPRUNG.

AFTER REPORTING THE ERROR THE PROGRAM IS RESTARTED FROM THE BEGINNING.

IF A BUS ERROR TRAP OCCURS WHILE A PREVIOUS BUS ERROR OR RSVD INSTRUCTION IS STILL PENDING THE PROGRAM WILL HALT. A DESCRIPTION OF THE HALT INTERPRETATION IS GIVEN IN PARA. 3.1,B4 BELOW.

IF A BUS ERROR OCCURS PRIOR TO THE COMPLETION OF THE BASIC INSTRUCTION TESTS, THE PROGRAM WILL HALT VIA A TRAPCATCHER IN THE VECTOR. A DESCRIPTION OF THIS HALT

IS INCLUDED IN PARA. 3.1,B2 BELOW.

5. POWER FAIL

IF A POWER FAIL CONDITION IS DETECTED, THE FOLLOWING MESSAGE IS PRINTED:

POWER

AFTER PRINTING AN ATTEMPT IS MADE TO RESTART THE PROGRAM AT THE BEGINNING.

EACH POWER FAIL ENCOUNTERED DURING ANY PASS IS COUNTED IN A LOCATION TAGGED "PFCNT". DURING END OF PASS PRINTOUT THIS LOCATION IS QUERIED AND IF FOUND NON-ZERO THE NORMAL ENDPAS MESSAGE IS MODIFIED AS SHOWN BELOW:

PASCNT=XXXXXX ERRCNT=YYYYYY PFCNT=ZZZZZZ

WHERE "ZZZZZZ" GIVES THE TOTAL COUNT OF THE POWER FAILS (IN OCTAL) OCCURRING DURING ANY PROGRAM RUN.

IF THE POWER FAIL IS DETECTED BEFORE COMPLETION OF THE BASIC INSTRUCTION TESTS, THE PROGRAM WILL HALT VIA A TRAP CATCHER IN THE VECTOR. A DESCRIPTION OF THIS HALT IS GIVEN IN PARA. 3.1,B2 BELOW.

6. MISSED TEST MESSAGE

THERE IS A 512 BYTE TABLE TAGGED "STAB1" THAT CONTAINS A BYTE ENTRY THAT CORRESPONDS TO EACH SEQUENTIAL TEST NO.. AFTER THE "MOVB #N,X(R)" INSTRUCTION HAS BEEN VERIFIED IN THE "BIT" SECTION, EACH TEST WILL USE THIS INSTRUCTION TO SET THE BYTE THAT CORRESPONDS TO THAT TEST NO. TO ALL ONES (377) THROUGHOUT THE REMAINDER OF THE "BASIC INSTRUCTION TESTS" SECTION. DURING THE "CIT" AND "IEX" SECTIONS THE TABLE ENTRIES ARE UPDATED BY THE "SCOPE" LOOP UTILITY. DURING END OF PASS SERVICE, A CHECK ROUTINE IS CALLED TO SCAN THE TABLE AND INSURE THAT EACH BYTE IS SET TO ALL ONES (377). ANY ENTRY THAT STILL CONTAINS ZEROES (TABLE IS INITIALIZED TO ZEROES BEFORE BEING USED) MEANS THAT ONE OR MORE TESTS WERE SKIPPED FOR SOME REASON. IF ANY TESTS ARE FOUND "MISSED" THE PRINTOUT SHOWN BELOW IS DISPLAYED:

```
MISSED TEST
XXXXXX
YYYYYY
```

WHERE: XXXXXX AND YYYYYY ARE THE TEST NUMBERS MISSED.

B. ERROR HALTS

---

1. BASIC INSTRUCTION TESTS (BIT)

ANY ERROR DETECTED IN THE BASIC TESTS CAUSES THE PROGRAM TO HALT WITH THE FOLLOWING INFORMATION DISPLAYED IN THE CONSOLE INDICATORS:

ADDRESS DISPLAY: ADDRESS + 2 OF THE LOCATION CONTAINING THE HALT. THIS IS USED TO LOCATE THE SPECIFIC ERROR CALL IN THE FAILING TEST

DATA DISPLAY: NUMBER OF THE FAILING TEST (IN OCTAL). USING THE SBTTL INDEX THIS MAY BE USED TO LOCATE THE FAILING TEST IN THE LISTING.

EXAMINING THE CONTENTS OF THE CPU'S GENERAL REGISTERS, THE PSW, AND THE STACK WILL PROVIDE ADDITIONAL FAULT IDENTIFICATION INFORMATION.

DEPRESSING "CONTINUE" AFTER THE HALT WILL CAUSE AN AUTOMATIC RETRY OF THE FAILING TEST. IF THE ERROR IS SOLID THE PROGRAM WILL LOCK ON THIS TEST, BUT IF IT IS INTERMITTENT THE PROGRAM WILL CONTINUE ON IN NORMAL SEQUENCE ONCE THE TEST IS SUCCESSFULLY EXECUTED.

TO ESTABLISH A TIGHT SCOPE LOOP ON THE FAILING TEST, REPLACE THE "HALT" WITH A 400(8). AND DEPRESS "CONTINUE" THE "400" IS A "BR .+2" WHICH FUNCTIONS AS A NOP. THIS IS NECESSARY TO PRESERVE THE INTEGRITY OF THE CONDITION CODE OPERATE INSTRUCTION THAT IS USED AS A SCOPE SYNC. THIS BUILT IN SYN URE IS DESCRIBED IN PARA. 6.0.

2. TRAPCATCHER HALTS

THE VECTOR AREA (LOC 000 - 776) IS PROGRAM LOADED WITH A STANDARD TRAPCATCHER AS SHOWN BELOW:

```
V  / V+2
V+2/ HALT
```

AFTER THE BASIC INSTRUCTION TESTS THE FOLLOWING VECTORS ARE SET UP TO POINT TO APPROPRIATE SERVICE ROUTINES:

4/6	BUS ERROR SERVICE
10/12	RSVD INSTRUCTION TRAP SERVICE
20/22	SCOPE LOOP SERVICE
24/26	POWER FAIL SERVICE
30/32	ERROR SERVICE
34/36	PRINT SERVICE

AT THE APPROPRIATE POINTS IN THE COMPREHENSIVE INSTRUCTION TESTS THE KW11-L VECTOR (100/102) AND THE DL11 VECTORS (60/62 - 64/66) ARE SET UP TO CHECK INTERRUPTS

FROM THESE DEVICES. ALL OTHER VECTORS REMAIN SET UP TO "CATCH" UNEXPECTED TRAPS OR INTERRUPTS BY HALTING.

WHEN AN UNEXPECTED TRAP OR INTERRUPT NOT SUPPORTED BY AN APPROPRIATE SERVICE ROUTINE OCCURS THE CPU HALTS. WITH THE FOLLOWING INFORMATION DISPLAYED IN THE CONSOLE:

ADDRESS DISPLAY: V+4 OF THE VECTOR. THIS IS USED TO IDENTIFY THE CAUSE OF THE UNEXPECTED TRAP OR INTERRUPT.

DATA DISPLAY: TEST NO. OF THE LAST TEST BEING EXECUTED WHEN THE TRAP OR INTERRUPT OCCURRED.

THE LAST ENTRY PUSHED ON THE STACK CAN BE EXAMINED TO DETERMINE WHERE THE PROGRAM WAS WHEN THE TRAP OR INTERRUPT WAS SPRUNG. REMEMBER THAT THE "OLD PC" GETS SAVED ON THE STACK WHEN A TRAP OR INTERRUPT OCCURS.

4. CATASTROPHIC ERROR HALTS

THERE ARE TWO HALTS, ONE IN THE BUS ERROR SERVICE ROUTINE AND THE OTHER IN THE RSVD INSTRUCTION TRAP SERVICE ROUTINE THAT HALT THE PROGRAM IF ONE OF THESE ERRORS OCCURS WHILE STILL SERVICING A PREVIOUS BUS ERROR OR RSVD INSTRUCTION TRAP. AFTER THE HALT THE CONSOLE DISPLAYS THE FOLLOWING INFORMATION:

ADDRESS DISPLAY: PC+2 OF THE ERROR HALT. THIS IS USED TO IDENTIFY WHICH OF THE TWO TYPES OF ERRORS - RSVD OR BUS ERROR.

DATA DISPLAY: LAST TEST NUMBER BEING EXECUTED WHEN THE TRAPS OCCURRED.

THERE IS A SOFTWARE FLAG TAGGED "CATERR" THAT MAY BE EXAMINED TO OBTAIN THE FOLLOWING INFORMATION:

[CATERR] = 000002 TWO SUCCESSIVE BUS ERRORS
[CATERR] = 001000 TWO SUCCESSIVE RSVD INSTR. TRAPS
[CATERR] = 000401 A COMBINATION OF THE TWO. THE CONTENTS OF THE ADDRESS DISPLAY IDENTIFIES WHICH TYPE OCCURRED LAST.

THE STACK PROVIDES THE FOLLOWING ADDITIONAL INFORMATION:

[SP] / PC OF THE 2ND TRAP
[SP+2] / PSW OF THE 2ND TRAP
[SP+4] / PC OF THE 1ST TRAP
[SP+6] / PSW OF THE 1ST TRAP

4.0 PERFORMANCE AND PROGRESS REPORTS

4.1 PERFORMANCE REPORTS

THERE IS ONLY ONE PERFORMANCE REPORT SUPPLIED BY THE PROGRAM AND CONSISTS OF A SIMPLE END OF PASS MESSAGE OF THE FORMAT SHOWN BELOW:

```
PASCNT = XXXXXX  ERRCNT = YYYYYY
```

WHERE: XXXXXX IS THE TOTAL NUMBER OF COMPLETE PASSES OF THE ENTIRE PROGRAM (OCTAL)

YYYYYY IS THE TOTAL ERROR COUNT IN OCTAL WHICH IS FROZEN WHEN IT REACHES 177777(8).

THIS PRINTOUT IS MODIFIED TO PRINT THE POWER FAIL COUNT AS DESCRIBED IN PARA. 3.1,AS ABOVE IF POWER FAILED DURING A PASS.

4.2 PROGRESS REPORTS

THERE ARE THREE PROGRESS REPORTS PRINTED THAT REPORT NORMAL ERROR FREE EXECUTION OF THE PROGRAM.

A. END OF PASS PRINTOUT AS DESCRIBED IN 4.1 ABOVE.

B. PROGRAM IDENTIFICATION MESSAGE AS DESCRIBED BELOW:

```
DBQEAB PDP11/40 CPU DIAGNOSTIC  VERSION XXX
```

THIS MESSAGE GETS PRINTED THE FIRST TIME THE PROGRAM ENTERS THE COMPREHENSIVE INSTRUCTION TEST SECTION UNLESS INHIBITED BY SW12=1. AFTER THE FIRST PASS THIS PRINTOUT IS AUTOMATICALLY INHIBITED UNLESS THE PROGRAM IS RESTARTED AT 200(8).

C. PDP11/40 OPTIONS FOUND PRINTOUT

AFTER PRINTING THE PROGRAM I.D. MESSAGE, A SUBROUTINE IS CALLED TO "LOOK FOR" THE 11/40 INTERNAL OPTIONS (KT11-D, KW11-L,KE11-E,KE11-F,AND KJ11-A). IF ANY OF THESE OPTIONS ARE FOUND THE FOLLOWING PRINTOUT OCCURS:

```
PDP11/40 INTERNAL OPTIONS FOUND

XXXX-X

YYYY-Y
```

WHERE "X" AND "Y" ETC. ARE THE NAMES OF THE OPTIONS.

IF NO OPTIONS ARE FOUND THE FOLLOWING PRINTOUT OCCURS:

```
PDP11/40 INTERNAL OPTIONS FOUND

NONE FOUND
```

THE OPTIONS FOUND MESSAGE IS ONLY PRINTED ON THE FIRST PASS
THROUGH THE PROGRAM AND MAY ALSO BE INHIBITED BY SETTING SW12=1.

E MAINTENANCE BREAKPOINT FEATURE

THERE IS A MANUAL PROGRESS REPORT FEATURE THAT ALLOWS THE USER
TO STEP THROUGH THE PROGRAM, HALTING AFTER EVERY N'TH TEST WITH
PROGRESS INFORMATION DISPLAYED IN THE CONSOLE ADDRESS AND DATA
DISPLAYS. TO ACTIVATE THIS FEATURE THE USER MUST SET THE DESIRED
"BREAKPOINT HALT" BITS IN THE MEMORY LOCATION TAGGED "BPTLOC".
THIS LOCATION PROVIDES SIXTEEN POSSIBLE HALTS DISPERSED EVENLY
THROUGHOUT THE PROGRAM (APPROX. EVERY 32 TESTS). AT EACH CHECK-
POINT THE PROGRAM EXAMINES A PARTICULAR BIT IN "BPTLOC" AND
HALTS IF THE BIT IS SET TO A "1" OTHERWISE IT CONTINUES IN
NORMAL SEQUENCE. AFTER THE HALT DEPRESSING "CONTINUE" WILL CAUSE
RESUMPTION OF NORMAL PROGRAM EXECUTION. SETTING LOCATION "BPTLOC"
TO ALL 1'S (177777) WILL RESULT IN THE FOLLOWING SIXTEEN HALTS
WITH THE INFORMATION SHOWN DISPLAYED IN THE CONSOLE:

[BPTLOC]	DATA DISPLAY TEST NO.	ADDRESS DISPLAY HALT PC+2
BIT00=1	000040	005076
BIT01=1	000077	007460
BIT02=1	000134	012574
BIT03=1	000174	014700
BIT04=1	000234	016434
BIT05=1	000274	021552
BIT06=1	000334	024532
BIT07=1	000374	027532
BIT08=1	000444	033506
BIT09=1	000504	037340
BIT10=1	000544	042222
BIT11=1	000604	045446
BIT12=1	000644	050226
BIT13=1	000704	054400
BIT14=1	000745	061222
BIT15=1	001005	063566

NOTE: IF THE USER DEPOSITED A 000400(8) IN LOCATION "BPTLOC"
ONLY ONE HALT WOULD OCCUR AND AT THAT TIME THE DATA
DISPLAY SHOULD CONTAIN 000444 AND THE ADDRESS DISPLAY
SHOULD CONTAIN 033506.

THIS FEATURE IS USEFUL FOR TRACKING DOWN THE TEST THAT CAUSES
A "RUNAWAY" OR "HUNG" PROGRAM.

LOCATION "BPTLOC" IS PROGRAM LOADED AS 000000 TO INHIBIT ANY HALTS.

5.0 DEVICE INFORMATION TABLES

5.1 KD11-A MICROPROGRAMMING INFORMATION

A. INTRODUCTION

THE KD11-A PROCESSOR EMPLOYS A MICROPROGRAMMED CONTROL SECTION THAT GENERATES THE PROPER SEQUENCES OF CONTROL SIGNALS REQUIRED TO EXECUTE THE PDP11 INSTRUCTION SET. THE HEART OF THE CONTROL IS A CONTROL STORE THAT CONSISTS OF 256 WORDS OF 56 BITS EACH, STORED IN A READ ONLY MEMORY (ROM). EACH 56 BIT WORD IS CALLED A MICROINSTRUCTION AND IS MICROPROGRAMMED TO PERFORM A UNIQUE ELEMENTARY OPERATION WITHIN THE PROCESSOR. EACH ONE OF THE 56 BITS IS ASSIGNED A PARTICULAR CONTROL FUNCTION THAT MAY BE TURNED "ON" OR "OFF" DEPENDENT UPON HOW EACH MICROWORD IS PROGRAMMED. TO ACTIVATE A SPECIFIC SET OF CONTROL SIGNALS SIMPLY MEANS READING OUT A SPECIFIC ROM ADDRESS. TO GENERATE A SPECIFIC SEQUENCE OF CONTROL SIGNAL SETS SIMPLY MEANS GENERATING A SPECIFIC ROM ADDRESS SEQUENCE. THE PURPOSE OF THIS SECTION IS TO DESCRIBE THE FUNCTION OF EACH BIT OR GROUP OF BITS (CALLED A FIELD) AND PROVIDE A LIST OF BACKPLANE TEST POINTS WHERE THE STATE OF ANY PARTICULAR BIT CAN BE OBSERVED.

B. MICROINSTRUCTION FORMAT

THIS SECTION LISTS THE FUNCTIONAL DESCRIPTION OF EACH BIT. FOR A MORE DETAILED DESCRIPTION OF THE SPECIFIC ENCODING REFER TO THE PDP11/40 SYSTEM ENGINEERING DRAWINGS, KD11A PROCESSOR (UWORD AND TABLES) SHEET.

BIT NO.	NAME	FUNCTIONAL DESCRIPTION
U<56:55>	CLKL<1:0>	THIS TWO BIT CONTROL FIELD IS USED TO SPECIFY THE CLOCK LENGTH FOR EACH MICROINSTRUCTION. THERE ARE THREE CLOCK LENGTHS POSSIBLE AS DESCRIBED BELOW: (PRT - PULSE REPETITION TIME) U<56:55>=00 OR 01 -CLOCK LENGTH 1 - GENERATES A "P1" PULSE WITH PRT=140NSEC U<56:55>=10 -CLOCK LENGTH 2 - GENERATES A "P2" PULSE WITH PRT=200NS U<56:55>=11 -CLOCK LENGTH 3 - GENERATES A "P2" PULSE

```
                                                                    FOLLOWED 100 NSEC LATER
                                                                    BY A "P3" PULSE. TOTAL
                                                                    PRT=300 NSEC.

                    U<54>          CLKOFF          THIS BIT ALLOWS TURNING OFF THE PRO-
                                                   CESSOR CLOCK TO STALL PROCESSOR OPERA-
                                                   TIONS WHILE WAITING FOR SOME INTERNAL
                                                   OR EXTERNAL RESPONSE.

                    U<53>          CLKIR           THIS BIT ENABLES CLOCKING NEW DATA
                                                   INTO THE INSTRUCTION REGISTER.  IT IS
                                                   ONLY ACTIVE WHEN THE PROCESSOR IS
                                                   FETCHING A NEW INSTRUCTION.

                    U<52:51>       WRH,WRL         THESE TWO BITS CONTROL THE WRITING
                                                   INTO THE PROCESSOR'S GENERAL REGIS-
                                                   TERS.  THEY PROVIDE THE MECHANISM FOR
                                                   CONTROLLING WHETHER WE READ, WRITE A
                                                   16 BIT WORD, OR WRITE AN 8 BIT BYTE AS
                                                   DESCRIBED BELOW:

                                                   U<52:51>=00   READ ONLY - INHIBIT
                                                                 WRITING

                                                   U<52:51>=01   WRITE ONLY THE LOW
                                                                 BYTE BITS <7:0>

                                                   U<52:51>=11   WRITE A FULL 16 BIT
                                                                 WORD BITS <15:00>

                    U<50>          CLKB            THIS BIT ALLOWS CLOCKING NEW DATA
                                                   INTO THE "B" REGISTER

                                                   U<50>=0   HOLD B REGISTER

                                                   U<50>=1   LOAD B REGISTER

                    U<49>          CLKD            THIS BIT ALLOWS CLOCKING THE OUTPUT
                                                   OF THE "ALU" INTO THE "D" REGISTER.

                                                   U<49>=0   HOLD D REGISTER

                                                   U<49>=1   LOAD "D" REGISTER

                    U<48>          CLKBA           THIS BIT ALLOWS CLOCKING THE BUS
                                                   ADDRESS REGISTER "BA"

                                                   U<48>=0   HOLD BA REGISTER

                                                   U<48>=1   LOAD BA REGISTER

                    U<47:46>       C1BUS,C0BUS     THIS TWO BIT FIELD SPECIFIES THE
                                                   TYPE OF DATA TRANSFER BUS CYCLE WHEN
                                                   U<45> BGBUS IS ACTIVE

                                                   U<46:47>=00   DATI
```

```
                                                                U<46:47>=01   DATIP
                                                                U<46:47>=10   DATO
                                                                U<46:47>=11   DATOB

                                                                WHEN U<45> IS INACTIVE U<47:46> ARE
                                                                USED TO CONTROL INTERNAL PROCESSOR
                                                                LOGIC RELATED TO PRIORITY TRANSFER
                                                                OF UNIBUS CONTROL

                                U<45>           BGBUS           THIS BIT IS USED TO TRIGGER INITIATION
                                                                OF A UNIBUS DATA TRANSFER BUS CYCLE
                                                                WHICH RESULTS IN ACTIVATING BUS MSYN:

                                U<44:41>        DAD<3:0>        THIS FOUR BIT FIELD (DISCRETE ALTER-
                                                                ATION OF DATA) PROVIDES THE MECHANISM
                                                                FOR ALTERING THE OPERATION OF THE
                                                                BASIC CONTROL FUNCTIONS BASED ON
                                                                CONDITIONS EXISTING WITHIN THE PRO-
                                                                CESSOR.  IE:  CHECK FOR STACK OVFLW
                                                                IF PUSHING ON STACK, ALLOW ODD ADDRESS
                                                                IF BYTE INSTRUCTION, MODIFY ALU OPER-
                                                                ATION AS A FUNCTION OF THE IR DECODE
                                                                ETC.

                                U<40:38>        SPS<2:0>        THIS THREE BIT FIELD CONTROLS LOADING,
                                                                CLOCKING, AND GATING OF THE PROCESSOR
                                                                STATUS WORD.

                                U<37:33>        ALUM,S<3:0>     THESE FIVE BITS CONTROL WHAT OPERATION
                                                                IS TO BE PERFORMED BY THE PROCESSOR'S
                                                                ALU.  THE FINAL ALU CONTROL IS SUBJECT
                                                                TO MODIFICATION BY THE "DAD" CODE AS
                                                                DESCRIBED ABOVE.

                                U<32:29>        SBC<3:0>        THIS FOUR BIT FIELD IS ENCODED TO
                                                                SELECT SPECIFIC CONSTANTS THAT MAY
                                                                BE FED INTO THE ALU'S "B" INPUT VIA
                                                                THE B MUX.  IE: SWR ADDRESS=177570

                                U<28:27>        SBMH<1:0>       THIS TWO BIT FIELD IS USED TO CONTROL
                                                                THE HIGH SECTION OF THE B MUX, BITS
                                                                <15:08> AND DETERMINES WHAT APPEARS
                                                                AT THE B INPUT TO THE ALU, BIN<15:08>

                                                                U<28:27>=00  BIN<15:08>=BREG<15:08>
                                                                U<28:27>=01  BIN<15:08>=BREG07(SEX)
                                                                U<28:27>=10  BIN<15:08>=BREG<07:00>(BYTE)
                                                                U<28:27>=11  BIN<15:08>=BCON<15:08>(CONSTANT)

                                U<26:25>        SBML<1:0>       THIS TWO BIT FIELD IS USED TO CONTROL
                                                                THE LOW SECTION OF THE B MUX, BITS
                                                                <07:00>.  AND DETERMINES WHAT APPEARS
                                                                AT THE B INPUT TO THE ALU.  BIN<07:00>

                                                                U<26:25>=00  BIN<07:00>=BREG<07:00>
                                                                U<26:25>=01  BIN<07:00>=BREG<07:00>
```

```
                                                                U<26:25>=10  BIN<07:00=BREG<15:08>(BYTE)
                                                                U<26:25>=11  BIN<07:00>=BCON<07:00>(CONSTANT)

                        U<24:23>        SDM<1:0>                THIS TWO BIT FIELD IS USED TC SELECT
                                                                ONE OF FOUR INPUTS THAT APPEAR AT THE
                                                                INPUT TO THE "D" MUX.

                                                                U<24:23>=00  DMUX<15:00>=BUS RD<15:00>(REG)
                                                                U<24:23>=01  DMUX<15:00>=BUS D<15-00>(UNIBUS)
                                                                U<24:23>=10  DMUX<15:00>=D<15:00>
                                                                U<24:23>=11  DMUX<15:00>=D<C>,D<15:01>(SHF RIGHT

                        U<22>           SBAM                    THIS BIT IS USED TO SELECT THE DATA
                                                                LOADED INTO THE BA REGISTER

                                                                U<22>=1  BA<15:00=BUS RD<15:00>(REG)
                                                                U<22>=0  BA<15:00>=ALU<15:00>

                                                                BIT 48 (CLKBA) MUST BE ACTIVE TO
                                                                ALLOW CLOCKING INTO THE BA REGISTER.

                        U<21:17>        UBF<4:0>                THIS FOUR BIT FIELD (BUT BITS) IS USED
                                                                TO SPECIFY ONE OF 16 POSSIBLE MICRO-
                                                                BRANCH TESTS WHICH PROVIDES THE MECHANISM
                                                                FOR MODIFYING THE ROM ADDRESS SEQUENCE
                                                                GENERATED BASED ON THE PRESENCE OR
                                                                ABSENCE OF SPECIFIC C^^DITIONS.

                        U<16:13>        SR<S,D,BA,I>            THESE FOUR BITS ARE USED TO SELECT
                                                                THE SPECIFIC BITS USED TO ADDRESS A
                                                                GENERAL REGISTER.

                                                                SRS =1 USE IR<8:6> SOURCE REG BITS
                                                                SRD =1 USE IR<2:0> DEST REG BITS
                                                                SRBA=1 USE BA<3:0> CONSOLE (EXAM + DEP)
                                                                SRI =1 USE U<12:9> MICROWORD

                        U<12:09>        RIF<3:0>                THESE FOUR BITS SPECIFY WHICH GENERAL
                                                                REGISTER TO ACCESS IF "SRI" (U<13>)
                                                                IS ACTIVE

                                                                U<12:09>=0000  R0
                                                                U<12:09>=0001  R1
                                                                U<12:09>=0001
                                                                U<12:09>=0001
                                                                U<12:09>=1111  R17

                        U<08>           UPF8                    THIS BIT IS NOT STORED IN THE ROM BUT
                                                                IS A SEPARATE CONTROL SIGNAL THAT
                                                                PROVIDES THE MECHANISM FOR IMPLEMENTING
                                                                AN EXPANSION ROM WHEN THE EIS/FIS
                                                                OPTIONS ARE INSTALLED - NOT IN THE
                                                                BASIC MACHINE.

                        U<07:00>        UPF<7:0>                THIS EIGHT BUT FIELD (NEXT FIELD) PRO-
                                                                VIDES A MEANS OF EACH MICROINSTRUCTION
```

```
TO SPECIFY THE ADDRESS OF THE NEXT
MICROWORD TO BE ACCESSED.  THE CONTENTS
OF THIS FIELD MAY BE MODIFIED AS A
RESULT OF A MICROBRANCH TEST BEFORE
BEING LOADED INTO THE ROM ADDRESS
REGISTER. (UPP<7:0>.

IT IS THE COMBINATION OF THIS FIELD
AND THE BUT BITS U<21:17> THAT MAKE
IT POSSIBLE TO GENERATE VARIABLE ROM
ADDRESS SEQUENCES.

THESE 8 BITS ARE UNIQUE IN THAT THEY
ARE ACTIVE (1) WHEN "LOW" IN CONTRAST
TO ALL OTHER BITS THAT ARE ACTIVE (1)
WHEN HIGH.

   IE: UPF<7:0>=01010010 = ADDRESS 255
```

5.2 MICROWORD CONTROL SIGNAL TEST POINTS

KD11-A MICROWORD CONTROL SIGNALS (SH1 OF 2)

U(N)	PRINT	SIGNAL NAME		ROM	UREG
56	K2-8	CLKL1(1)	H	E38-09	D03N2
56	"	CLKL1(0)	H	"	D03M2
55	"	CLKLO(1)	H	E38-10	D03L2
55	"	CLKLO(1)	H	"	D03R1
54	"	CLKOFF(1)	H	E38-11	D03U2
53	"	CLKIR(1)	H	E38-12	D03T2
52	K2-7	WRH(1)	H	E34-09	D03J2
51	"	WRL(1)	H	E34-10	D03H2
50	"	CLKB(1)	H	E34-11	D03J1
49	"	CLKD(1)	H	E34-12	D03K2
48	"	CLKBA(1)	H	E35-09	D03L1
47	"	C1BUS(1)	H	E35-10	D03K1
46	"	COBUS(1)	H	E35-11	D03F2
45	"	3GBUS(1)	H	E35-12	D03E2
44	"	DAD3(1)	H	E37-09	D03M1
43	"	DAD2(1)	H	E37-10	D03N1
42	"	DAD1(1)	H	E37-11	D03P1
41	"	DADO(1)	H	E37-12	D03D2
40	K2-6	SPS2(1)	H	E31-09	C03M2
39	"	SPS1(1)	H	E31-10	D03H1
38	"	SPSO(1)	H	E31-11	D03F1
37	"	SALUM(1)	H	E31-12	D03E1
36	"	SALU3(1)	H	E30-09	C03N2
35	"	SALU2(1)	H	E30-10	C03P2
34	"	SALU1(1)	H	E30-11	C03T2
33	"	SALUO(1)	H	E30-12	C03U2
32	"	SBC3(1)	H	E27-09	C03S2
31	"	SBC2(1)	H	E27-10	C03U2
30	"	SBC1(1)	H	E27-11	C03R2
29	"	SBCO(1)	H	E27-12	D03D1

KD11-A MICROWORD CONTROL SIGNALS (SH2 OF 2)

U<N>	PRINT	SIGNAL NAME		ROM	UREG
28	K2-5	SBMH1(1)	H	E22-09	C03N1
27	"	SBMH0(1)	H	E22-10	C03M1
26	"	SBML1(1)	H	E22-11	C03L1
25	"	SBML0(1)	H	E22-12	C03J1
24	"	SDM1(1)	H	E23-09	C03L2
23	"	SDM0(1)	H	E23-10	C03K2
22	"	SBAM(1)	H	E23-11	C03J2
21	"	UBF4(1)	H	E23-12	C03H2
20	"	UBF3(1)	H	E26-09	C03S1
19	"	UBF2(1)	H	E26-10	C03R1
18	"	UBF1(1)	H	E26-11	C03P1
17	"	UBF0(1)	H	E26-12	C03F2
16	K2-4	SRS(1)	H	E21-09	C03E1
15	"	SRD(1)	H	E21-10	C03D2
14	"	SRBA(1)	H	E21-11	C03E2
13	"	SRI(1)	H	E21-12	C03B1
12	"	RIF3(1)	H	E20-09	B03S1
11	"	RIF2(1)	H	E20-10	B03U1
10	"	RIF1(1)	H	E20-11	B03U2
09	"	RIF0(1)	H	E20-12	B03T2
08	K2-3	BUPP8(1)	H	N/A	B03E2
07	"	BUPP7(1)	H	E14-09	B03J2
06	"	BUPP6(1)	H	E14-10	B03M2
05	"	BUPP5(1)	H	E14-11	B03P2
04	"	BUPP4(1)	H	E14-12	B03R2
03	K2-2	BUPP3(1)	H	E15-09	A03L2
02	"	BUPP2(1)	H	E15-10	A03P2
01	"	BUPP1(1)	H	E15-11	A03S2
00	"	BUPP0(1)	H	E15-12	A03U2

NOTES:

1. THE ROM TEST POINTS CORRESPOND TO THE WORD BEING READ OUT AS DEFINED BY THE CONTENTS OF THE "UPP"
2. THE UREG TEST POINTS CORRESPOND TO THE WORD BEING EXECUTED AS DEFINED BY THE CONTENTS OF THE "PUPP"
3. AN "H" (HIGH LEVEL) IS OBSERVED IF THE BIT IS PROGRAMMED AS A "1" AND A "L" (LOW LEVEL) IS OBSERVED IF THE BIT IS PROGRAMMED AS A "0" WITH EXCEPTION OF THE "UPF" FIELD BITS <7:0> WHEN OBSERVED AT THE OUTPUT OF THE ROM DIRECTLY. IN THIS CASE THE BITS ARE STORED IN 1'S COMPLEMENT FORM.

5.3 KD11-A LOGIC PRINT SUMMARY

THE LOGIC CIRCUIT DESIGN USED TO IMPLEMENT THE KD11-A CPU IS WELL ORGANIZED AND LOGICALLY PARTITIONED INTO FUNCTIONAL AREAS ON THE FIVE MODULES(4 HEX AND 1 QUAD). EACH MODULE IS IDENTIFIED FOR DOCUMENTATION PURPOSES BY A "KN" NUMBER AS LISTED BELOW AND EACH PRINT APPROPRIATELY ITENTIFIED WITHIN THE PRINT SET:

M7231	DATA PATHS	PRINTS K1-1 THRU K1-9
M7232	UWORD (ROM)	PRINTS K2-1 THRU K2-8
M7233	IR DECODE	PRINTS K3-1 THRU K3-9
M7234	TIMING	PRINTS K4-1 THRU K4-6
M7235	STATUS	PRINTS K5-1 THRU K5-8

THE FIRST PRINT IN EACH SET (KN-1) SHOWS THE PHYSICAL LAYOUT OF THE MODULE AND INCLUDES A COMPONENT PARTS LIST. THE LOGIC PARTITIONING INTO FUNCTIONAL AREAS IS SUMMARIZED IN THE TABLE BELOW:

```
                                        ****** M7231 ******

                                K1-2    DESCRIBES THE LOGIC AREAS THAT SUPPORT THE PRIMARY
                                        DATA PATH FACILITIES FOR BITS<03:00> THAT INCLUDES:

                                                1. UNIBUS DATA RECEIVERS AND DRIVERS
                                                2. REGISTER DATA BUS RECEIVERS
                                                3. "D" MULTIPLEXOR
                                                4. "B" MULTIPLEXOR
                                                5. "D" REGISTER
                                                6. "B" REGISTER
                                                7. ARITHMETIC LOGIC UNIT
                                                8. "BA" MULTIPLEXOR

                                K1-3    SAME AS THE K1-2 EXCEPT IT SUPPORTS BITS<07:04>

                                K1-4    SAME AS THE K1-2 EXCEP IT SUPPORTS BITS<11:08>

                                K1-5    SAME AS THE K1-2 EXCEPT IT SUPPORTS BITS<15:12>
                                        AND ALSO INCLUDES*

                                                1. "COUT" MULTIPLEXOR
                                                2. "D<C>" CONTROL FLOP

                                K1-6    DESCRIBES THE LOGIC THAT SUPPORTS:

                                                1. BUS ADDRESS REGISTER (BA)
                                                2. UNIBUS ADDRESS LINE DRIVERS

                                K1-7    DESCRIBES THE IMPLEMENTATION OF:

                                                1. INTERNAL ADDRESS DECODERS
                                                2. "D" REGISTER DECODER

                                K1-8    DESCRIBES THE:

                                                1. GENERAL REGESTERS (R00 THRU R17)
                                                2. GENERAL REGISTER ADDRESS SELECTION SWITCHES

                                K1-9    DESCRIBES THE:

                                                1. KY11-D DATA DISPLAY AND SWITCH REGISTER
                                                   INTERFACES
                                                2. CABLE CONNECTOR
```

```
                                        ****** M7232 ******

                                K2-2    DESCRIBES THE:

                                                1. UPP REGISTER BITS<03:00>
                                                2. PUPP REGISTER BITS<03:00>
                                                3. MICROBRANCH CONTROL "OR" GATES BITS<03:00>

                                K2-3    DESCRIBES THE:

                                                1. UPP REGISTER BITS<08:04>
                                                2. PUPP REGISTER BITS<08:04>
                                                3. MICROBRANCH CONTROL "OR" GATES BITS<07:04>

                                K2-4    DESCRIBES THE:

                                                1. ROM U<16:09>
                                                2. UREG <16:09>

                                K2-5    DESCRIBES THE:

                                                1. ROM U <28:17>
                                                2. UREG <28:17>

                                K2-6    DESCRIBES THE:

                                                1. ROM U <40:29>
                                                2. UREG <40:29>

                                K2-7    DESCRIBES THE:

                                                1. ROM U <52:41>
                                                2. UREG <52:41>

                                K2-8    DESCRIBES THE:

                                                1. ROM U <56:53>
                                                2. UREG <56:53>
                                                3. EXPANSION ROM CONNECTORS
```

```
                                        ****** M7233 ******

                                K3-2    DESCRIBES THE:

                                                1. BUT MULTIPLEXOR

                                K3-3    DESCRIBES THE:

                                                1. INSTRUCTION REGISTER
                                                2. IR DECODERS

                                K3-4    DESCRIBES THE:

                                                1. IR DECODERS
                                                2. "OVLAP" DECODER

                                K3-5    DESCRIBES THE:

                                                1. MICRO BRANCH CONTROL LOGIC

                                K3-6    DESCRIBES THE*

                                                1. IR DECODERS (DISCRETE)

                                K3-7    DESCRIBES THE:

                                                1. MICROBRANCH CONTROL LOGIC

                                K3-8    DESCRIBES THE:

                                                1. "COUT" MUX CONTROL LOGIC
                                                2. AUX ALU CONTROL MULTIPLEXORS
                                                3. "CIN" GENERATION LOGIC

                                K3-9    DESCRIBES THE:

                                                1. "C" AND "V" BIT CONTROL LOGIC
```

```
                                        ****** M7234 ******

                                K4-2    DESCRIBES THE:

                                                1. CPU CLOCK WITH ASYNCHRONOUS CONTROL LOGIC
                                                2. PRIMARY REGISTER TIMING LOGIC FOR:

                                                        A. UPP AND PUPP REGISTERS
                                                        B. U REGISTER
                                                        C. INSTRUCTION REGISTER
                                                        D. B, D, AND BA REGISTERS
                                                        E. GENERAL REGISTERS - WRITE TIMING

                                K4-3    DESCRIBES THE:

                                                1. JAMUPP CONTROL LOGIC AND TIMING

                                K4-4    DESCRIBES THE:

                                                1. UNIBUS DATA TRANSFER CONTROL LOGIC

                                K4-5    DESCRIBES THE:

                                                1. BUS PRIORITY TRANSFER CONTROL LOGIC

                                K4-6    DESCRIBES THE:

                                                1. PRIORITY ARBITRATION LOGIC FOR "BR'S"
                                                2. BUS TIMEOUT AND NO SACK TIMEOUT CONTROL
```

```
                                        ****** M7235 ******

                                K5-2    DESCRIBES THE:

                                                1. PROCESSOR STATUS REGISTER
                                                2. PSW CONTROL
                                                3. PSW BUS DRIVERS (UNIBUS AND RD BUS)

                                K5-3    DESCRIBES THE:

                                                1. BRANCH INSTRUCTION DECODERS
                                                2. "BUT" DECODER (WORKING BUTS)

                                K5-4    DESCRIBES THE:

                                                1. MISCELLANEOUS HISTORY AND CONTROL FLOPS

                                K5-5    DESCRIBES THE:

                                                1. "B" CONSTANTS GENERACTOR
                                                2. TRAP VECTOR ADDRESS GENERATOR

                                K5-6    DESCRIBES THE:

                                                1. CONSOLE CONTROL SWITCH INTERFACE

                                K5-7    DESCRIBES THE:

                                                1. CONSOLE INTERFACE CABLE CONNECTIONS

                                K5-8    DESCRIBES THE:

                                                1. POWER FAIL/AUTO RESTART CONTROL LOGIC
```

6.0 MAINTENANCE PROCEDURES

6.1 INTRODUCTION

THE PROCEDURES OUTLINED IN THIS SECTION ASSUME THAT "DBQEAA" CAN BE LOADED INTO CORE AND STARTED. IF THE FAILURE MODE PREVENTS PROGRAM LOADING OR AFFECTS NORMAL POWER UP AND CONSOLE OPERATIONS, THE TECHNICIAN MUST REVERT TO THE MANUAL DEBUG AND CHECKOUT PROCEDURES CONTAINED IN THE "BCPT" DOCUMENT.

THE FIVE MODULES THAT COMPRISE THE KD11-A CENTRAL PROCESSING UNIT OF AN 11/40 SYSTEM CAN BE VIEWED AS CONSISTING OF TWO MAJOR INTERRACTING AND INTERDEPENDENT LOGIC AREAS AS DEPICT- BELOW:

```
                                  DATA IN ****
                                           *
                                           *
                                           V
          **************          *****************
          *            *          *               *
          * CONTROL    *>>>>>>>>>>>>>*    DATA       *
          *  SECTION   *<<<<<<<<<<<<<*     PATHS     *
          *            *          *               *
          **************          *****************
                                           *
                                           *
                                           ***>DATA OUT
```

THE DATA PATHS CONSIST OF A LOGICALLY INTERCONNECTED GROUP OF STATIC DATA FACILITIES (REGISTERS, MULTIPLEXORS, ALU'S ETC.) REQUIRED TO TEMPORARILY STORE, MODIFY, AND TRANSFER DATA ITEMS (16 BIT WORDS OR 8 BIT BYTES) ACCORDING TO THE DESIGN SPECIFICATIONS FOR THE PDP11.

THE CONTROL SECTION SUPPLIES PRE-DEFINED SEQUENCES OF CONTROL SIGNAL SETS TO ACTIVATE THE REQUIRED DATA FACILITIES WITHIN THE DATA PATHS. IN THE KD11-A THESE CONTROL SIGNAL SETS ARE STORED IN A READ ONLY MEMORY (ROM) AND GENERATED BY READING OUT A UNIQUE SEQUENCE OF ROM WORDS FOR ERCH OPERATION TO BE PERFORMED.

THE SEQUENCE GENERATED BY THE CONTROL SECTION IS VARIABLE AND DEPENDENT UPON THE INSTRUCTION OR LOGIC OPERATION BEING EXECUTED. THERE ARE HUNDREDS OF THESE SEQUENCES POSS- IBLE DEPENDENT UPON OF THE PROGRAM CODING.

"DBQEAA" IS DESIGNED TO GENERATE ALL POSSIBLE MICROINSTRUCTION SEQUENCES AND COMBINATIONS OF DATA AND CONTROL SIGNALS. THE INDIVIDUAL TESTS ARE LOGICALLY SEQUENCED AND STRUCTURED TO DETECT AND ISOLATE PARTICULAR MICROPROGRAM SEQUENCES THAT ARE FAULTY.

6.2 MICROPROGRAMMING / LOGIC INFORMATION

ALL OF THE TESTS DESIGNED TO TEST AND VERIFY A SPECIFIC INST-
RUCTION OR LOGIC OPERATION CONTAIN A MAINTENANCE HEADER IN THE
LISTING AT THE BEGINNING OF THE TEST. THIS HEADER PROVIDES THE
TECHNICIAN WITH DETAILED MICROPROGRAMMING AND LOGIC INFORMATION
RELATIVE TO THE INSTRUCTION OR LOGIC OPERATION BEING TESTED.
THIS SECTION OF THE DOCUMENT DESCRIBES THE FORMAT AND CONTENT
OF THIS INFORMATION AND SUGGESTS WAYS THAT THE TECHNICIAN
MAY USE IT TO ISOLATE FAULTS TO THE FAILING MODULE OR IC.

INFORMATION FORMAT:

THE MAINTENANCE HEADER SHOWN BELOW IS FOR THE TEST THAT
VERIFIES THE OPERATION OF THE INSTRUCTION:

"DECB 1(SP)"

WHERE: 1)THE INITIAL CONTENTS OF THE STACK WORD IS 000000
2)THE DEC (DECREMENT) MODIFIES THIS TO 177400 (DEC ODD BYTE)

HEADER:

```
;MICROPROGRAMMING / LOGIC INFORMATION

;ROM SEQ:        [166,261,262,267,237,270,222,253,075,374,375,
                 016] FC 1,3,9,8

;ACT BUTS:       37[004]100,166 / 17[166]262,262 / 33[266]220,237
                 34[237]220,222 / 16[374]016,016

;EXEC:           [222]ALUC=LHHHH :[375] D=177400

;CODES:          [253]SPS=1, [275]SPS=3 / N:C = 1000

;SYNC:           B05J2  (-)  T = 4.0 USEC

;KEY SIG:        K3-3 DM=6 L / K3-4 DEC L / K3-6 BYTE INSTR H
                 K3-7 ODD BYTE L
```

1) ROM SEQ ENTRIES:

THIS LISTS THE ROM ADDRESS SEQUENCE THAT MUST BE GENERAT
ED TO PROPERLY EXECUTE THE INSTRUCTION. IT BEGINS WITH
THE FIRST ROM WORD AFTER FETCH AND INCLUDES ALL MICRO-
WORDS UP TO THE BEGINNING OF THE NEXT FETCH. THIS IS
THE SEQUENCE THE TECHNICIAN SHOULD OBSERVE WHEN CLOCK-
ING THE ROM USING THE KM-11 MAINTENANCE MODULE. IT ALSO
INCLUDES A LIST OF THE FLOW CHART NUMBERS TO REFER TO
TO OBTAIN THE DETAILS OF EACH MICROWORD.

2) ACT BUTS (ACTIVE MICROBRANCH TESTS) ENTRIES:

```
                                        THIS IS A LIST OF ONE OR MORE ENTRIES THAT INDICATE
                                        ALL THE MICROBRANCHES THAT OCCUR DURING THE SEQUENCE.
                                        EACH ENTRY CONSISTS OF FOUR OCTAL NUMBERS AND EACH
                                        SEPARATE ENTRY IS DELIMITED BY A "/". THE NO.S ARE
                                        INTERPRETED AS FOLLOWS:

                                                A) THE FIRST NO. IS THE OCTAL CODE OF THE
                                                   BUT (UBF <4:0> FIELD)
                                                B) THE SECOND NO. (IN BRACKETS) INDICATES
                                                   THE ADDRESS OF THE WORD CONTAINING THE BUT
                                                C) THE THIRD NO. INDICATES THE ENCODING OF THE
                                                   NEXT FIELD (UPF <7:0>). THIS IS THE BASE
                                                   ADDRESS THAT MAY OR MAY NOT BE MODIFIED BY
                                                   THE MICROBRANCH TEST.
                                                D) THE FOURTH NO. INDICATES THE RESULT OF THE
                                                   MICROBRANCH MODIFICATION. BY COMPARING THIS
                                                   NO. WITH THE NEXT FIELD IT IS POSSIBLE TO
                                                   DETERMINE WHICH MICROBRANCH CONTROL SIGNALS
                                                   MUST BE ASSERTED TO OBTAIN THE PROPER ROM
                                                   SEQUENCE.

                                        THE KEY TO GENERATING THE PROPER MICROINSTRUCTION
                                        SEQUENCE IS WHAT THE "BUT" DOES TO GENERATE THE
                                        MICROBRANCH CONTROL SIGNALS (K3-2 BUBC<5:0>).
                                        FROM THE "ACT BUTS" INFORMATION THE TECHNICIAN CAN
                                        QUICKLY DETERMINE WHICH OF THESE SIGNALS MUST BE
                                        ACTIVE TO GENERATE THE PROPER ROM SEQUENCE.

                                        FOR EXAMPLE THE ENTRY:  37[004]100,166

                                        INDICATES THAT THE BUT37 IN LOC 004 MUST MODIFY THE
                                        ROM ADDRESS IN SUCH A WAY THAT THE 100 (NEXT FIELD)
                                        GETS CHANGED TO A 166. THIS MEANS THAT WE MUST SOME-
                                        HOW "OR" IN A 066 WITH THE BASE ADDRESS OF 100. THIS
                                        IS DONE BY GENERATING THE FOLLOWING CONTROL SIGNALS:

                                                K3-2 BUBC5, BUBC4, BUBC2, AND BUBC1

                                        ALL OF THESE SIGNALS CAN BE OBSERVED AT THE OUTPUT
                                        OF THE "BUT MUX" ON THE K3-2 PRINT. IT IS IMPORTANT
                                        THAT THEY BE OBSERVED WHEN THE PUPP=004 WHIC IS
                                        THE WORD CONTAINING THE BUT37.

                                        SINCE OVER 50% OF THE LOGIC FAULTS THAT CAN OCCUR
                                        IN THE KD11-A WILL MANIFEST THEMSELVES BY CAUSING
                                        AN INCORRECT ROM SEQUENCE TO BE GENERATED, THIS
                                        INFORMATION PROVIDES THE TECHNICIAN WITH A CONVENIENT
                                        STARTING POINT TO PROCEED TO ISOLATE THE FAULTY COMP-
                                        ONENT.

                                3) EXEC ENTRIES:

                                        THESE ENTRIES DESCRIBE TWO IMPORTANT MICROWORDS.

                                                A) THE WORD THAT EXECUTES THE INSTRUCTION
                                                B) THE WORD WHERE THE RESULT MAY BE OBSERVED
```

IN THE DATA DISPLAY ON THE CONSOLE

THE FIRST ENTRY INCLUDES A ROM ADDRESS THAT CONTAINS THE MICROINSTRUCTION THAT EXECUTES THE INSTRUCTION AND INCLUDES THE REQUIRED STATE OF THE ALU CONTROL SIGNALS TO PERFORM THE CORRECT OPERATION ON THE DATA AS DESCRIBED BELOW:

ALUC = ALU M,S<3:0> = LHHHH

WHICH MEANS THE LOGIC LEVELS SHOWN BELOW MUST EXIST:

K3-8 ALUM L
K3-8 ALUS3 H
K3-8 ALUS2 H
K3-8 ALUS1 H
K3-8 ALUS0 H

THE SECOND ENTRY SPECIFIES THE ROM ADDRESS WHERE THE RESULT IS DISPLAYED IN THE CONSOLE DATA DISPLAY. IN THE EXAMPLE SHOWN WITH THE ROM AT PUPP=375 THE DATA DISPLAY ON THE CONSOLE SHOULD CONTAIN A 177400.

4) CODES ENTRIES:

THIS ENTRY SPECIFIES THE SPS CODES USED TO ALTER THE FLAGS AND THE ROM WORDS THAT CONTAIN THESE CODES. WHERE APPLICABLE IT ALSO SPECIFIES HOW THE CODES SHOULD APPEAR AFTER THE INSTRUCTION. IN THE EXAMPLE:

N:C = 1000 MEANS THE THE "N" BIT IS SET AND THE "Z","V", AND "C" BITS ARE CLEAR.

5) SYNC ENTRIES:

THIS INFORMATION CONTAINS A BACKBOARD PIN NO. THAT MAY BE USED TO SYNC DURING A SCOPE LOOP, THE SCOPE TRIGGER SLOPE (-) TRAILING EDGE TO USE, AND THE APPROXIMATE SETTING OF THE HORIZONTAL SWEEP LENGTH. THIS INSURES THAT WHEN LOOPING ON A TEST, ONLY THE AREA OF INTEREST (THE TEST INSTRUCTION) IS DISPLAYED. THIS MINIMIZES THE POSSIBILITY OF LOOKING AT SIGNALS AT THE "WRONG TIME".

6) KEY SIGNALS:

THIS ENTRY CONTAINS A LIST OF UNIQUE SIGNALS THAT MUST BE ACTIVATED TO PROPERLY EXECUTE THE OPERATION UNDER TEST. THIS ALSO HELPS TO POINT THE TECHNICIAN TO THE KEY FUNCTIONAL AREAS OF LOGIC IN THE PRINT SETS.

6.3 KM11 MAINTENANCE MODULE

A. PURPOSE

THE KM11 MAINTENANCE MODULE OPTION PROVIDES THE TECHNICIAN WITH A MECHANISM FOR SINGLE CLOCKING THE KD11-A MICROPROGRAM. IT ALLOWS HIM TO VERIFY THAT THE PROPER ROM SEQUENCES ARE BEING GENERATED AND ALSO TO "FREEZE" THE ROM AT ANY ADDRESS AND CHECK THE CONTROL AND DATA PATH SIGNALS THAT SHOULD BE ACTIVE FOR THE PARTICULAR MICROWORD BEING INVESTIGATED.

B. BASIC COMPONENTS

1. W130 — SINGLE HEIGHT MODULE THAT CONTAINS THE INDICATOR DRIVERS FO THE W131 AND ALSO DOUBLES AS A MODULE EXTENDER FOR THE W131. WHEN INSTALLED IT PLUGS INTO SLOT "F1" IN THE KD11-A BACKPLANE WHICH IS PREWIRED TO ACCEPT THE KM11.

2. W131 — SINGLE HEIGHT MODULE THAT CONTAINS THE INDICATOR LAMPS AND CONTROL SWITCHES WITH FILTERS. IT PLUGS INTO THE W130 WHEN INSTALLED.

3. KD11-A OVERLAY (5509081-0-12)

A PLASTIC ETCHED OVERLAY THAT DEFINES THE INDICATORS AND SWITCHES ON THE W131.

C. INDICATORS

PUPP<08:00> — NINE INDICATOR LAMPS THAT DISPLAY THE CONTENTS OF THE PUPP (PAST MICROPROGRAM POINTER). THEY INDICATE THE ADDRESS OF THE MICROWORD THAT IS CURRENTLY STORED IN THE "UREG" (THIS WORD IS EXECUTED ON THE NEXT CLOCK PULSE)

BUPP<08:00> — NINE INDICATOR LAMPS THAT DISPLAY THE CONTENTS OF THE "UPP" (MICROPROGRAM POINTER).THEY INDICATE THE ADDRESS OF THE MICROWORD THAT IS CURRENTLY BEING READ OUT OF THE ROM. THIS MICROWORD IS LOADED INTO THE UREG ON THE NEXT CLOCK AND THE CONTENTS OF THE UPP GETS TRANSFERRED INTO THE PUPP.

<T,N:C> — FIVE INDICATORS THAT DISPLAY THE STATE OF THE FOLLOWING PSW FLAGS:

"T" BIT
"N" BIT
"Z" BIT
"V" BIT
"C" BIT

MSYN — A SINGLE INDICATOR THAT DISPLAYS THE STATE OF BUS MASTER SYNC.

SSYN — A SINGLE INDICATOR THAT DISPLAYS THE STATE OF BUS SLAVE SYNC.

```
                                                        NOTE:

                                                                THE STATE OF ALL INDICATOR LAMPS IS
                                                                DEFINED AS FOLLOWS:

                                                                "ON"    (1), ASSERTED, ACTIVE
                                                                "OFF"   (0), NEGATED, INACTIVE

                                        D. SWITCHES

                                        MCLK ENAB       WHEN ACTIVE THIS SWITCH DISABLES THE INTERNAL
                                                        PROCESSOR CLOCK AND ALLOWS TOGGLING A MAINT
                                                        ENTANCE CLOCK USING THE "MCLK" SWITCH.

                                        MCLK            WHEN ACTIVATED (ON-OFF SEQUENCE) THIS SWITCH
                                                        GENERATES ONE CLOCK PULSE TO THE KD11-A.

                                        MSTOP           WHEN ACTIVE THIS SWITCH ENABLES TURNING OFF THE
                                                        PROCESSOR CLOCK WHEN THE CONTENTS OF BUPP<8:0>
                                                        MATCHES THE ADDRESS CONTAINED IN SR<8:0> IN
                                                        THE CONSOLE SWITCH REGISTER. WHEN THE CLOCK
                                                        STOPS, THE CONTENTS OF THE ROM ADDRESS SELECT-
                                                        ED BY SR<8:0> IS STORED IN THE "UREG" AND THE
                                                        ADDRESS ITSELF CONTAINED IN THE "PUPP".

                                                NOTE:

                                                        ALL SWITCHES ARE INACTIVE WHEN POSITIONED
                                                        TOWARD THE INDICATOR DISPLAY ON THE W131.
                                                        AN "ARROW" ETCHED ON THE OVERLAY SIGNIFIES THE
                                                        DIRECTION OF THE ACTIVE POSITION.

                                        E. TYPICAL OPERATING PROCEDURES

                                          1. INSTALLATION

                                                A) TURN OFF ALL POWER TO THE KD11-A
                                                B) SLIDE OUT THE KD11-A FROM THE CABINET
                                                C) OPEN THE HINGED COVER ON THE LEFT SIDE
                                                D) PLUG THE W130 INTO SLOT F1
                                                E) PLUG THE W131 INTO THE W130 (WITH OVERLAY ATTACHED)

                                        *********CAUTION*********

                                        INSURE THAT THE HINGED COVER IS SECURED PROPERLY TO PREVENT
                                        IT FROM SWINGING FORWARD AND SHORTING THE PRINTED CIRCUIT
                                        ETCH ON THE BACK OF THE W131.

                                                D) PLACE ALL THREE SWITCHES ON THE W131 TO "OFF"
                                                E) TURN ON THE KD11-A POWER AND LOAD AND START
                                                   THE "DBKDAA" DIAGNOSTIC.

                                        2. OPERATION

                                                A) ESTABLISH A SCOPE LOOP ON THE FAILING TEST
                                                B) CONSULT THE LISTING FOR THAT TEST TO DETERMINE
```

```
                                        IF THE SCOPE SYNC INSTRUCTION IS A SET OR CLEAR
                                        CONDITION CODES AND SET UP SR<8:0> ON THE
                                        CONSOLE AS FOLLOWS:

                                             SET CODES       SR<8:0> = 352
                                             CLR CODES       SR<8:0> = 351

                                     C) PLACE THE "MSTOP" SWITCH IN THE ACTIVE POSITION.
                                        THE CLOCK SHOULD STOP AND FREEZE THE ROM WITH THE
                                        ADDRESS OF THE FIRST MICROWORD USED TO FETCH THE
                                        TARGET INSTRUCTION CONTAINED IN THE "UPP" REG.

                                     D) PLACE THE "MCLK ENAB" SWITCH ON AND THE "MSTOP"
                                        SWITCH OFF.

                                     E) NOW YOU ARE READY TO "TOGGLE" THROUGH THE ROM
                                        SEQUENCE FOR THE TEST INSTRUCTION USING THE "MCLK"
                                        SWITCH TO LOCATE AND ISOLATE THE FAILING MICROWORD.
                                        EACH TIME THE "MCLK" SWITCH IS TOGGLED THE CONTENTS
                                        OF THE "BUPP" AND "PUPP" INDICATORS SHOULD CHANGE
                                        TO INDICATE THE ROM SEQUENCE BEING GENERATED.
                                        COMPARE THIS SEQUENCE WITH THE CORRECT SEQUENCE
                                        INDICATED BY THE MAINTENANCE HEADER INCLUDED IN THE
                                        PROGRAM LISTING.
                              6.4     UPP MATCH MAINTENANCE FEATURE
                                      ----------------------------

                                              THERE IS A VALUABLE HARDWARE MAINTENANCE AID BUILT
                                      INTO THE KD11-A LOGIC THAT PROVIDES THE TECHNICIAN WITH A
                                      METHOD OF ANALYZING THE ROM SEQUENCES BEING GENERATED.
                                      IT IS CONTAINED ON THE K1 MODULE AND CONSISTS OF A COMP-
                                      ARATOR CIRCUIT (K1-9 PRINT) THAT ALLOWS TWO UNIQUE LOGIC
                                      SIGNALS TO BE GENERATED AS A FUNCTION OF THE ROM ADDRESS
                                      CONTAINED IN THE "UPP" AND THE SETTING OF THE CONSOLE SWITCH
                                      REGISTER SR<8:0>.


                                                  **************
                                     SR<8:> ---->*  MATCH     *---> UPP MATCH H
                                                 *  CIRCUIT   *
                                     BUPP<8:0>-->*            *---> P MATCH L
                                                  **************

                                      UPP MATCH H     THIS SIGNAL IS ASSERTED WHENEVER A MATCH OCCURS
                                                      BETWEEN THE CONTENTS OF THE "UPP" AND THE CONT-
                                                      ENTS OF SR<8:0>. IT CAN BE OBSERVED ON BACK-
                                                      PLANE PIN C04L2 AND IS USEFUL FOR DETERMINING
                                                      IF AND WHEN A SPECIFIC ROM WORD IS ACCESSED
                                                      DURING A PARTICULAR ROM SEQUENCE. IT MAY BE USED
                                                      AS A SCOPE SYNC TRIGGER OR AS A REFERENCE SIGNAL
                                                      FOR INVESTIGATING ADDITIONAL CONTROL SIGNALS
                                                      THAT SHOULD OCCUR DURING A SPECIFIC MICROWORD.

                                      P MATCH L       THIS SIGNAL WORKS IN CONJUNCTION WITH THE
                                                       "MSTOP" SWITCH ON THE KM11 MAINTENANCE MODULE
                                                      TO STOP THE CLOCK AND "FREEZE" THE ROM AT A
```

```
SPECIFIC ROM ADDRESS. AS DESCRIBED IN PARA.
6.3 (E2), IT IS USEFUL FOR INITIALLY STOPPING
THE ROM AT THE CORRECT POINT PRIOR TO SINGLE
CLOCKING ROM SEQUENCES.
```

7.0 FLOW CHARTS

7.1 FUNCTIONAL FLOW

```
        *****************
        * BASIC         *
>>>>>>>>* INSTRUCTION   *
I       * TESTS (BIT)   *
I       *****************
I               I
I               I
I               I
I       *****************
I       * COMPREHENSIVE *
I       * INSTRUCTION   *
I       * TESTS (CIT)   *>>>>>>>V
I       *****************       V
I               I               V
I               I               V
I               I               V
I       *****************       V
I       * COMBINED      *       V
I       * INSTRUCTION   *       V
I       * EXERCISER(IEX)*>>>>>>>V
I       *****************       V
I               I               V
I               I               V
I               I               V
I       *****************       V
I       * END OF PASS   *       V
I       * SERVICE       *>>>>>>>V
I       *****************       V
I               I               V
I               I               V
I<<<<<<<<<<<<<<<<               V
                        *****************
                        *               *
                        *  UTILITIES    *
                        *               *
                        *****************
```

7.2 SUB-FUNCTIONAL FLOWS

A. BASIC INSTRUCTION TESTS SECTION

```
                    *****************
                    * "BIT" STARTUP *
                    * SET UP STACK  *
                    * POINTER AND   *
                    * INIT FLAGS AND*
                    * COUNTERS.     *
                    *****************
                           I
                           I
T0001-T0006
*********************************
* SIX BASIC TESTS TO VERIFY THE *
* BNE,BEQ, AND BPL INSTRUCTIONS *
* FOR BOTH THE "1" AND "0" STATE*
* OF THE "Z" AND "N" FLAGS.     *
*********************************
                           I
T0007-T0017                I
*********************************
* NINE BASIC TESTS OF THE MOV,  *
* CMP, AND MOVB INSTRUCTIONS AS *
* THEY ARE USED TO CLEAR THE    *
* MISSED TEST TABLE.            *
*********************************
                           I
*********************************
* ROUTINE TO CLEAR THE MISSED   *
* TEST TABLE - BEGIN FLAGGING   *
* EACH TEST ENTERED STARTING    *
* WITH T0020                    *
*********************************
                           I
T0020-T0035                I
*********************************
* FOURTEEN BASIC TESTS OF THE   *
* SINGLE OPERAND INSTRUCTIONS IN*
* THE FORMATS USED BY THE       *
* UTILITIES (TST,COM,INC,DEC,CLR*
* AND ASL/ROL)                  *
*********************************
                           I
T0036-T0041                I
*********************************
* FOUR BASIC TESTS OF THE TSTB  *
* INSTRUCTION FOR BOTH EVEN AND *
* ODD ADDRESSES.                *
*********************************
                           I
T0042                      I
*********************************
* BASIC TEST OF THE DECB INSTR- *
```

```
                                        * UCTION IN ADDRESS MODE 6      *
                                        * USING THE STACK POINTER.      *
                                        ********************************
                                                        I
```

```
                                        I
                                        I
T0043-T0062                             I
                                        ********************************
                                        * SIXTEEN BASIC TESTS TO VERIFY *
                                        * THE MOVE INSTRUCTION IN THOSE *
                                        * FORMATS USED BY THE UTILITIES *
                                        ********************************
                                        I
                                        I
T0063-T0066                             I
                                        ********************************
                                        * FOUR BASIC TESTS OF THE COMP- *
                                        * ARE INSTRUCTION IN THOSE FORM-*
                                        * ATS USED BY THE UTILITIES     *
                                        ********************************
                                        I
                                        I
T0067-T0074                             I
                                        ********************************
                                        * SIX BASIC TESTS OF THE LOGIC  *
                                        * INSTRUCTIONS (BIS,BIC,BIT) AS *
                                        * USED BY THE UTILITIES.        *
                                        ********************************
                                        I
                                        I
T0075-T0076                             I
                                        ********************************
                                        * TWO BASIC TESTS OF THE ADD    *
                                        * INSTRUCTIONS AS IT IS USED BY *
                                        * THE UTILITIES.                *
                                        ********************************
                                        I
                                        I
T0077-T0103                             I
                                        ********************************
                                        * FOUR BASIC TESTS OF THE CMPB  *
                                        * INSTRUCTIONS USING BOTH EVEN  *
                                        * AND ODD ADDRESSES.            *
                                        ********************************
                                        I
                                        I
T0104-T0123                             I
                                        ********************************
                                        * SIXTEEN BASIC TESTS OF THE    *
                                        * MOVB INSTRUCTION USING BOTH   *
                                        * EVEN AND ODD ADDRESSES AND IN *
                                        * ALL ADDRESS MODES USED BY THE *
                                        * THE UTILITIES.                *
                                        ********************************
                                        I
                                        I
T0124-T0125                             I
                                        ********************************
                                        * TWO TESTS TO VERIFY THE BASIC *
                                        * RTS/JSR INSTRUCTIONS AS USED  *
                                        * IN THE UTILITIES.             *
                                        ********************************
                                        I
                                        I
T0126-T0127                             I
                                        ********************************
                                        * TWO BASIC TESTS OF THE RTI    *
                                        * INSTRUCTION.                  *
```

```
  1949                                                  **********************************
  1950                                                                  I
  1951
```

```
                                                    I
                                        T0130-T0137 I
                                        ********************************
                                        * EIGHT BASIC TESTS OF THE VAR- *
                                        * IOUS TRAP TYPE INSTRUCTIONS   *
                                        * TO VERIFY THAT THE UTILITIES  *
                                        * CAN BE CALLED VIA THE TRAP    *
                                        * MECHANISM. (IOT,TRAP,EMT, AND *
                                        * RSVD INSTR AND BUS TIMEOUT    *
                                        * TRAPS)                        *
                                        ********************************
                                                    I
                                        T0140-T0144 I
                                        ********************************
                                        * FIVE BASIC TESTS TO VERIFY THE*
                                        * DL11 INTERFACE USED TO REPORT *
                                        * ERRORS. THE MAINTENANCE MODE  *
                                        * FEATURE IS USED TO TURNAROUND *
                                        * AND CHECK AN ALL 1'S ALL 0'S  *
                                        * SEQUENCE.                     *
                                        ********************************
                                                    I
                                              *******************
                                              * ENTER THE "CIT" *
                                              *     SECTION     *
                                              *******************
```

B. COMPREHENSIVE INSTRUCTION TESTS SECTION

```
                    *****************
                    * FROM "BIT" SEC*
                    *****************
                            I
                            I
                *********************************
                * START-UP ROUTINE FOR THE "CIT"*
                * (COMPREHENSIVE INSTRUCTION    *
                * TESTS SECTION). THE FOLLOWING:*
                * FUNCTIONS ARE PERFORMED:      *
                *   1) SET UP REQUIRED VECTORS  *
                *   2) CALL SUBROUTINE TO SET   *
                *      BITS IN "OPTION" TO IND- *
                *      ICATE INTERNAL OPTIONS   *
                *      FOUND.                   *
                *   3) PRINT PROGRAM NAME       *
                *   4) PRINT OPTIONS FOUND      *
                *   5) CLEAR THE PSW AND INIT-  *
                *      THE "SCOPE LOOP" RETURN  *
                *********************************
                            I
                T0145-T0146 I
                *********************************
                * TWO QUICK VERIFY TESTS OF THE *
                * BASIC CONDITIONAL BRANCHES    *
                * (BMI,BEQ,BVS,BCS) FOR BOTH    *
                * THE "1" AND "0" STATE OF THE  *
                * PERTINENT PSW FLAG.           *
                *********************************
                            I
                T0147-T0223 I
                *********************************
                * FORTY-FIVE LOGICALLY SEQUENCED*
                * TESTS TO VERIFY ALL THE BRANCH*
                * INSTRUCTIONS FOR ALL PERTIN-  *
                * ENT COMBINATIONS OF THE PSW   *
                * FLAGS. THESE TESTS FOCUS ON   *
                * THE BRANCH MICROROUTINES ON   *
                * FLOW CHART 7 AND THE BRANCH   *
                * INSTR DECISION LOGIC ON THE   *
                * K5-3 PRINT.                   *
                *********************************
                            I
                T0224-T0227 I
                *********************************
                * THESE FOUR TESTS VERIFY THE   *
                * SXT INSTR. IN MODE 0. THEY    *
                * FOCUS ON THE (SXT*DM0) MICRO- *
                * ROUTINE ON FLOW CHART 8       *
                *********************************
                            I
```

```
                                        T0230-T0233     I
                                        ********************************
                                        * THESE FOUR TESTS VERIFY THE   *
                                        * SXT INSTR. IN MODE 1 AND 2.   *
                                        * THEY FOCUS ON THE (SXT*-DMO)  *
                                        * MICROROUTINE ON FLOW CHART 8  *
                                        * AND THE BUT33 IN ROM LOCATIONS*
                                        * 260 AND 266 ON FLOW CHART 3   *
                                        ********************************
                                                        I
                                        T0234-T0235     I
                                        ********************************
                                        * TWO TESTS TO VERIFY THE SWAB  *
                                        * INSTR. IN MODE 0. THEY FOCUS  *
                                        * ON THE (SWAB*DMO) MICROROUTINE*
                                        * ON FLOW CHART 7.              *
                                        ********************************
                                                        I
                                        T0236-T0237     I
                                        ********************************
                                        * TWO TESTS TO VERIFY THE SWAB  *
                                        * INSTR. IN MODE 1. THEY FOCUS  *
                                        * ON THE (SWAB) MICROROUTINE ON *
                                        * FLOW CHART 9                  *
                                        ********************************
                                                        I
                                        T0240-T0243     I
                                        ********************************
                                        * FOUR TESTS TO VERIFY THE NEG  *
                                        * INSTR. IN MODE 0 THAT FOCUS ON*
                                        * THE (SOPMORE*DMO*NEG) MICRO-*
                                        * ROUTINE ON FLOW CHART 7.      *
                                        ********************************
                                                        I
                                        T0244-T0247     I
                                        ********************************
                                        * FOUR TESTS TO VERIFY THE NEG  *
                                        * INSTRUCTION IN MODE 1 THAT    *
                                        * FOCUS ON THE [(SWAB+SOPMORE)  *
                                        * *-DMO*NEG] MICROROUTINE ON    *
                                        * FLOW CHART 9.                 *
                                        ********************************
                                                        I
                                        T0250-T0273     I
                                        ********************************
                                        * TWENTY TESTS THAT VERIFY THE  *
                                        * ROR/ASR INSTRUCTIONS THAT     *
                                        *FOCUS ON THE (ROTSHF) MICRO-   *
                                        * ROUTINES ON FLOW CHART 9. BOTH*
                                        * WORD AND BYTE OPERATIONS ARE  *
                                        * TESTED FOR BOTH EVEN AND ODD  *
                                        * ADDRESSES.                    *
                                        ********************************
                                                        I
```

```
                                        T0274-T0323     I
                                        ********************************
                                        * TWENTY FOUR TESTS THAT VERIFY *
                                        * ALL SINGLE OPR. INSTR. OTHER  *
                                        * THAN SXT,SWAB,NEG,ASR,ROR, OR *
                                        * JMP. THEY FOCUS ON THE MODE 0 *
                                        * CASE AND THE MICROROUTINE     *
                                        * (SOPMORE*DMO*-NEG) ON FLOW    *
                                        * CHART 7.                      *
                                        ********************************
                                                        I
                                        T0324-T0353     I
                                        ********************************
                                        * TWENTY FOUR TESTS SIMILAR TO  *
                                        * THE PREVIOUS GROUP EXCEPT     *
                                        * THEY HANDLE THE NON MODE 0    *
                                        * CASE FOCUSING ON THE (SOPMORE *
                                        * +SWAB)*-NEG*-DMO MICROROUTINE *
                                        * ON FLOW CHART 9               *
                                        ********************************
                                                        I
                                        T0354-T0370     I
                                        ********************************
                                        * THIRTEEN TESTS USING THE CLR  *
                                        * AND NEG INSTRUCTIONS TO VERIFY*
                                        * THE BYTE MICROROUTINES THAT   *
                                        * SUPPORT SINGLE OPERAND INSTR- *
                                        * UCTIONS FOR BOTH EVEN AND ODD *
                                        * ADDRESS CASES.                *
                                        ********************************
                                                        I
                                        T0371-T0417     I
                                        ********************************
                                        * TWENTY THREE TESTS THAT USE   *
                                        * THE ADD INSTRUCTION TO VERIFY *
                                        * THE SOURCE AND DESTINATION    *
                                        * MICROBRANCHES ON FLOW CHARTS  *
                                        * 2 AND 3.                      *
                                        ********************************
                                                        I
                                        T0420-T0427     I
                                        ********************************
                                        * EIGHT TESTS THAT VERIFY THE   *
                                        * XOR INSTRUCTION FOR BOTH THE  *
                                        * MODE 0 AND 1 CASES.           *
                                        ********************************
                                                        I
                                        T0430-T0444     I
                                        ********************************
                                        * THIRTEEN TESTS THAT VERIFY THE*
                                        * MICROWORDS UNIQUE TO THE SUB- *
                                        * TRACT INSTR. FOCUSING ON ROM  *
                                        * LOCATIONS 363,370, AND 365.   *
                                        ********************************
                                                        I
```

```
                                        T0445-T0452     I
                                        ********************************
                                        * SIX TESTS USING THE NEG INSTR-*
                                        * TO VERIFY FETCH TO DESTINATION*
                                        * MICROBRANCHES FOR SINGLE OPER-*
                                        * ERAND INSTRUCTIONS USING DM2  *
                                        * THRU DM7.                     *
                                        ********************************
                                                        I
                                        T0453-T0536     I
                                        ********************************
                                        * FIFTY TWO MOVE INSTRUCTION    *
                                        * TESTS THAT FOCUS ON ALL THE   *
                                        * POSSIBLE MOV MICROINSTRUCTION *
                                        * SEQUENCES ON FLOW CHART 4 AND *
                                        * ALL MICRBRANCHES ENTERING AND *
                                        * EXITING THIS SHEET.           *
                                        ********************************
                                                        I
                                        T0537-T0602     I
                                        ********************************
                                        * THIRTY SIX TESTS THAT VERIFY  *
                                        * THE BIS,BIC,BIT, AND CMP INSTR*
                                        * UCTIONS IN ALL SOURCE AND DEST*
                                        * MODE COMBINATIONS FOR WORD OPS*
                                        ********************************
                                                        I
                                        T0603-T0616     I
                                        ********************************
                                        * TWELVE TESTS THAT USE THE BIS *
                                        * INSTRUCTION TO VERIFY THE     *
                                        * BYTE MICROROUTINES THAT SUPP- *
                                        * DOUBLE OPERAND INSTRUCTIONS   *
                                        * FOR BOTH THE EVEN AND ODD CASE*
                                        ********************************
                                                        I
                                        T0617-T0634     I
                                        ********************************
                                        * FOURTEEN TESTS THAT VERIFY THE*
                                        * JMP MICROUTINES ON FLOW CHART *
                                        * 5 AND ALL MICROBRANCHES WITH- *
                                        * WITHIN THESE ROUTINES.        *
                                        ********************************
                                                        I
                                        T0635-T0647     I
                                        ********************************
                                        * TEN TESTS TO VERIFY THE JSR   *
                                        * MICROUTINE ON FLOW CHART 5 AND*
                                        * ALL MICROBRANCHES INTO THIS   *
                                        * ROUTINE.                      *
                                        ********************************
                                                        I
                                        T0647-T0654     I
                                        ********************************
                                        * SIX TESTS TO VERIFY THE SOB   *
                                        * INSTRUCTION FOCUSING ON THE   *
```

```
                                        * MICROROUTINES ON FLOW CHART 7 *
                                        * BOTH THE BRANCH AND NO BRANCH *
                                        * CASES ARE TESTED.             *
                                        ***********************************
```

```
T0655-T0656     I
*********************************
* TWO TESTS TO VERIFY THE RTS   *
* MICROROUTINE ON FLOW CHART 6  *
*********************************
                I
T0657-T0660     I
*********************************
* TWO TESTS TO VERIFY THE RTT   *
* MICROROUTINE ON FLOW CHART 6  *
*********************************
                I
T0661-T0662     I
*********************************
* TWO TESTS TO VERIFY THE MARK  *
* MICROROUTINE ON FLOW CHART 5  *
*********************************
                I
T0663-T0667     I
*********************************
* FIVE TESTS TO VERIFY THE INT- *
* EGRITY OF THE KW11-L LINE     *
* CLOCK OPTION. THESE TESTS ARE *
* SKIPPED IF THE KW11-L IS NOT  *
* INSTALLED.                    *
*********************************
                I
T0670-T0673     I
*********************************
* FOUR TESTS THAT VERIFY THE    *
* RESET AND WAIT INSTRUCTIONS   *
* THAT FOCUS ON THE SERVICE MIC-*
* ROROUTINE ON FLOW CHART 10 AND*
* THE RESET MICROROUTINE ON FLOW*
* CHART 6.                      *
*********************************
                I
T0674-T0715     I
*********************************
* EIGHTEEN TESTS THAT VERIFY THE*
* PRIORITY ARBITRATION LOGIC    *
* FOR BR REQUESTS. THEY FOCUS   *
* ON THE SERVICE AND TRAP MICRO-*
* ROUTINES ON FLOW CHARTS 10 AND*
* 6. SEVERAL OF THESE TESTS MAY *
* BE SKIPPED IF THE KW11-L IS   *
* NOT INSTALLED.                *
*********************************
                I
                I
        *****************
        * GO TO "IEX"   *
        *   SECTION     *
        *****************
```

```
                                C. COMBINED INSTRUCTION EXERCISER TEST SECTION

                                          *****************
                                          * "IEX" ENTRY   *
                                          *****************
                                                I
                                T0716           I
                                *********************************
                                * TEST TO VERIFY THAT THE "BPT" *
                                * INSTRUCTION CAUSES A TRAP TO  *
                                * THE VECTOR AT LOC. 14         *
                                *********************************
                                                I
                                T0717-T0734     I
                                *********************************
                                * FOURTEEN TESTS TO VERIFY THAT *
                                * THE STACK OVERFLOW (BOTH RED  *
                                * AND YELLOW ZONE) MECHANISM AND*
                                * THE ODD ADDRESS TRAP MECHANISM*
                                *FUNCTION PROPERLY FOR ALL CASES*
                                * OF ODD ADDR. ERRORS AND STACK *
                                * OVERFLOW.                     *
                                *********************************
                                                I
                                T0735-T0736     I
                                *********************************
                                * TWO TESTS TO VERIFY THAT THE  *
                                * JMP AND JSR CAUSE AN ILLEGAL  *
                                * INSTRUCTION TRAP TO THE VECTOR*
                                * AT LOCATION 4 WHEN ENCODED IN *
                                * ADDRESS MODE 0.               *
                                *********************************
                                                I
                                T0737-T0740     I
                                *********************************
                                * TWO TESTS TO VERIFY THE BUS   *
                                * TIMEOUT AND "T" BIT TRAP      *
                                * MECHANISM.                    *
                                *********************************
                                                I
                                T0741-T0743     I
                                *********************************
                                * THREE TESTS TO VERIFY THAT A  *
                                * "RED" ZONE TRAP IS SPRUNG IF  *
                                * AN ATTEMPT IS MADE TO PUSH    *
                                * INTO THE PSW,SR, OR SLR USING *
                                * R6. T0743 IS CONDITIONAL ON   *
                                * WETHER THE KJ11-A OPTION IS   *
                                * INSTALLED OR NOT.             *
                                *********************************
                                                I
```

```
T0744-T0754     I
********************************
* NINE TESTS TO VERIFY THAT A  *
* RSVD INSTRUCTION TRAP IS SPRU-*
* NG FOR ALL CASES OF RESERVED *
* OPERATION CODES.             *
********************************
                I
T0755-T1007     I
********************************
* TWENTY SEVEN TESTS THAT USE  *
* THE "T" BIT TRAP TO VERIFY   *
* THAT ALL MICROWORDS ENCODED  *
* WITH A "BUT SERVICE" CAUSE   *
* A MICROBRANCH TO THE SERVICE *
* MICROROUTINE.          *
********************************
                I
T1010-T1015     I
********************************
* SIX ALU/DATA PATH TESTS THAT *
* VERIFY THE ALU OPERATION FOR *
* ALL POSSIBLE BIT INPUT COMBIN-*
* ATIONS FOR THE ADD,SUB,AND,OR,*
* AND LOGICAL FUNCTIONS USING  *
* THE ADD,SUB,BIS,BIC,INC,AND  *
* DEC INSTRUCTIONS IN VARIOUS  *
* COMBINATIONS.                *
********************************
                I
                I
        *****************
        * GO TO END OF  *
        * PASS SERVICE  *
        *****************
```

7.3 FUNCTIONAL TEST FLOWS

A. BASIC INSTRUCTION TEST STRUCTURE

```
                                  *************
                             TN: *           *
                                 * TEST      *
                                 * SETUP     *
                >>>>>>>>RN: *           *
                I                *************
                I                      I
                I                      I
                I                      I
                I                *************
                I                * TEST      *
                I             IN: *INSTRUCTION*
                I                *           *
                I                *************
                I                      I
                I                      I
                I                *************
                I                *  VERIFY   *
                I                *************
                I                  I       I
                I                  I       I
            CONTINUE           ERROR   NO ERROR
                I                  I       I
                I                  I       I
                I             *********    I
                I          EN: * HALT  *   I
                I             *********    I
                I                 I        I
                I<<<<<<<<<<<<<<            I
                                           I
                                  *************
                                  * GO TO NEXT*
                                  *   TEST    *
                                  *************
```

NOTES:

1) THE TEST ENTRY IS ALWAYS TAGGED "TN" WHERE "N" IS THE TEST NO. IN OCTAL.
2) THE TEST INSTRUCTION IS ALWAYS TAGGED "IN".
3) THE ERROR HALT IS ALWAYS TAGGED "EN".
4) THE RETURN POINT FOR LOOPING IS ALWAYS TAGGED "RN".
5) IF MORE THAN ONE VERIFICATION IS MADE IN A SINGLE TEST THE ENTRIES TO SUBSEQUENT CHECKS ARE TAGGED "AN", "BN", ETC.
6) IF MORE THAN ONE ERROR HALT IS INCLUDED, SUBSEQUENT ERROR HALTS ARE TAGGED: "E1N", "E2N", E3N", ETC.
7) WHEN AN ERROR HALT OCCURS THE CONSOLE ADDRESS AND DATA DISPLAYS CONVEY THE FOLLOWING INFORMATION:

```
                                        ADDRESS DISPLAY:        ADDRESS + 2 OF THE
                                                                LOCATION CONTAINING
                                                                THE "HALT"

                                        DATA DISPLAY:           TEST NUMBER

                                    8) TO ESTABLISH A CONTINUOUS SCOPE LOOP THE HALT INSTRUCTION
                                       MUST BE REPLACED WITH A "000400" (BR .+2) BEFORE
                                       DEPRESSING "CONTINUE".
```

B. COMPREHENSIVE INSTRUCTION TEST STRUCTURE

```
                    *****************
          ON-1:     *     SCOPE     *>>>>>>>>>>>>>>>>>
                    *****************                 I
                                                      I
                                                      I
                                                      I
                    *****************                 I
             TN:    *               *<<<<<<<<         I
                    *  TEST SET-UP  *       I         I
>>>>>>>>>>>>RN:     *               *       I         I
I                   *****************       I         I
I                           I               I         I
I                           I               I         I
I                   *****************       I         I
I            IN:    * TEST INSTRUCT.*       I         I
I                   *****************     LOOP        I
I                           I               I      (IOT)
I                           I               I         I
I                   *****************       I         I
I                   *  VERIFICATION *       I<<<      I
I                   *****************           I     I
I                      I        I               I     I
I                      I        I>>>>           I     I
I                  FAULT           I           I     I
I                      I       NO FAULT     *****************
I                   ********       I         *  SCOPE LOOP   *
I            EN:    *ERRORX*       I         *    UTILITY    *
I                   ********       I         *****************
 SW09=1                I           I                 I    I
I                      I           I                 I    I
I                  (EMT)           I                 I    I
I                      I           I                 I    I
I                   <<<<           I                 I    I
I                   I              I                 I    I
I            ******************     I                 I    I
I<<<<<<<<    * ERROR SERVICE *      I                 I    I
             *   ROUTINE     *      I                 I    I
I<<<<<<<<    *               *      I                 I    I
I            ******************     I                 I    I
SW15=1              I               I                 I    I
I                   I>> SW13=1 >>>>>I                 I    I
*********           I               I                 I    I
* HALT  *           I               I                 I  NO LOOP
*********       SW13=0              I                 I    I
   AA(CONT)         BB(CONT)         CC(CONT)         DD   EE(CONT)
```

```
2461                                    AH(CONT)        BB(CONT)        CC(CONT)        DD   EE(CONT)
2462                                    I               I               I               I    I
2463                                    I               I               I               I    I
2464                                    I       *****************       I               I    I
2465                                    I       * OTA AND PRINT *       I               I    I
2466                                    I       *  ROUTINES     *       I               I    I
2467                                    I       *****************       I               I    I
2468                                  DEPRESS                           I              (IOT) I
2469                                 CONTINUE                           I               I    I
2470                                    I                               I               I    I
2471                                    I>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>               I    I
2472                                                            I                       I    I
2473                                                            I                       I    I
2474                                                    *****************               I    I
2475                                             ON:    *    SCOPE      *>>>>>>>>>>>>>>>>>    I
2476                                                    *****************               I    I
2477                                                                                    I    I
2478                                                            <<<<<<<<<<<<<<<<<<<<<<<<<<<<<<<<<<<<<
2479                                                            I
2480                                                    *****************
2481                                            TN+1:   *  TEST SET-UP  *
2482                                                    *  FOR NEXT TEST*
2483
2484                                LOOP = [SW14=1]+[ITCOUNT NOT ZERO)*PASCNT>0]+[SW10=1*(R0)=TST#]
2485
2486                                NO LOOP = [SW14=0*ITCOUNT=0] + [PASCNT=0]
```

7.4 CORE MEMORY MAP

```
000000  ********************************
        *          VECTOR AREA         *
        * (ALL UNUSED VECTORS LOADED   *
        *  WITH STANDARD PDP11 TRAP-   *
        *    CATCHER)                  *
        *                              *
        ********************************
000200  *  MOV  #3000,PC               *
        ********************************
        *                              *
        *   PROCESSOR STACK AREA       *
        *                              *
001000  ********************************
        *            "BCPT"            *
        *   (BASIC CENTRAL PROCESSOR   *
        *    TESTS)                    *
        ********************************
003000  *  "BIT" START-UP CODE          *
        ********************************
T0001:  *                              *
        *           "BIT"              *
        *                              *
        *  BASIC INSTRUCTION TESTS     *
        *       (100[10] TESTS)        *
        *                              *
        ********************************
CITST:  *                              *
        *   "CIT" INITIALIZATION       *
        *                              *
        ********************************
T0145:  *                              *
        *          "CIT"               *
        *                              *
        *  COMPREHENSIVE INSTRUCTION   *
        *          TESTS               *
        *      (360[10] TESTS)         *
        *                              *
        ********************************
T0715:  *                              *
        *          "IEX"               *
        *                              *
        *  COMBINED INSTRUCTION        *
        *    EXERCISER TESTS           *
        *      (65[10] TESTS)          *
        *                              *
        ********************************
ENDPS:  *                              *
        *      END OF PASS SERVICE     *
        *                              *
        ********************************
        *                              *
        *  UTILITIES AND MISCELLANEOUS *
```

```
                                        *   SUBROUTINES                 *
                                        *                               *
                                        *********************************
```

```
                                  ********************************
OPTION:                           *                              *
                                  *  CONSTANTS, FLAGS, AND       *
                                  *   VARIABLES                  *
                                  *                              *
                                  ********************************
BELL:                             *                              *
                                  *     ASCII MESSAGES           *
                                  *                              *
                                  *                              *
                                  ********************************
OBUF:                             *                              *
                                  *  COMMON DATA STRJCTURES      *
                                  *                              *
                                  *                              *
                                  ********************************
```

```
                                        8.0     SUB-TITLE INDEX OF TESTS
                                                ------------------------

                                                REFER TO THE TABLE OF CONTENTS IN THE LISTING FOR A DETAILED
                                                SUB-TITLE INDEX OF TESTS. THIS TABLE LISTS ALL TESTS SEQ-
                                                UENTIALLY BY TEST NO. WITH A BRIEF DESCRIPTION OF THE FUNCTION
                                                OF EACH TEST. THE LEFT HAND COLUMN CONTAINS LINE NUMBERS THAT
                                                FACILITATE RAPIDLY LOCATING ANY PARTICULAR TEST WITHIN THE
                                                LISTING.


                                                ∂
                                        .ENABLE ABS

        000000                          .=0

                                        ; ***********************************************************************
                                                        .SBTTL STANDARD PDP11 "TRAP CATCHER"
                                        ; ***********************************************************************

                                        ;WHEN THE PROGRAM IS LOADED, LOCATIONS 000000-000776 (VECTOR AREA)
                                        ;GET LOADED WITH THE STANDARD PDP11 "TRAP CATCHER". THE FIRST WORD
                                        ;IN EACH VECTOR (NEW PC) IS SET UP TO POINT TO THE SECOND WORD WHICH
                                        ;CONTAINS A "HALT" INSTRUCTION. ANY UNEXPECTED TRAP OR INTERRUPT
                                        ;DIRECTED TO A VECTOR THAT HAS NOT BEEN INITIALIZED BY THE PROGRAM TO
                                        ;POINT TO AN APPROPRIATE SERVICE ROUTINE WILL CAUSE THE PROGRAM TO HALT.
                                        ;AFTER THE HALT THE FOLLOWING ERROR INFORMATION IS AVAILABLE FOR
                                        ;DETAILED ERROR ANALYSIS BY THE SERVICE TECHNICIAN:

                                                ;ADDRESS DISPLAY-       V+4 - WHERE "V" IS THE VECTOR THE
                                                                        ;TRAP OR INTR. TRAPPED TO.

                                                ;DATA DISPLAY-          NUMBER OF THE TEST BEING EXECUTED WHEN
                                                                        ;THE TRAP WAS SPRUNG.

                                                ;CONTENTS OF THE SP-    MEMORY ADDRESS CONTAINING THE CONTENTS
                                                                        ;OF THE PC WHEN THE TRAP WAS SPRUNG

                                        ;"TRAP CATCHER" HALTS ARE CONSIDERED TO BE CATASTROPHIC ERRORS THAT
                                        ;NORMALLY PRECLUDE CONTINUING ON IN THE PROGRAM FROM THE POINT OF THE
                                        ;ERROR. THE PROGRAM MUST BE RESTARTED OR PROPER MODIFICATIONS MADE
                                        ;BASED ON THE ANALYSIS OF THE ERROR INFORMATION.

000000  000002                                  .+2
000002  000000                                  HALT

                                        ;AFTER EXECUTION OF THE BASIC INSTRUCTION TESTS AND BEFORE THE COM-
                                        ;PREHENSIVE INSTRUCTION TESTS, THE VECTOR BELOW IS SET UP TO POINT
                                        ;TO THE BUS ERROR SERVICE ROUTINE AT "BERR:" WITH A PRIORITY OF 7

000004  000006                                  .+2
000006  000000                                  HALT

                                        ;AFTER EXECUTION OF THE BASIC INSTRUCTION TESTS AND BEFORE THE COM-
                                        ;PREHENSIVE INSTRUCTION TESTS, THE VECTOR BELOW IS SET UP TO POINT
                                        ;TO THE RSVD INSTR. TRAP SERVICE ROUTINE AT "RSERR:" WITH A PRIORITY OF 7
```

```
000010  000012                          .+2
000012  000000                          HALT
000014  000016                          .+2
000016  000000                          HALT

                                ;AFTER EXECUTION OF THE BASIC INSTRUCTION TESTS AND BEFORE THE COM-
                                ;PREHENSIVE INSTRUCTION TESTS, THE VECTOR BELOW IS SET UP TO POINT
                                ;TO THE SCOPE  SERVICE ROUTINE AT "SCOPEB:" WITH A PRIORITY OF 0

000020  000022                          .+2
000022  000000                          HALT

                                ;AFTER EXECUTION OF THE BASIC INSTRUCTION TESTS AND BEFORE THE COM-
                                ;PREHENSIVE INSTRUCTION TESTS, THE VECTOR BELOW IS SET UP TO POINT
                                ;TO THE POWER FAIL SERVICE ROUTINE AT "PDWN:" WITH A PRIORITY OF 7

000024  000026                          .+2
000026  000000                          HALT

                                ;AFTER EXECUTION OF THE BASIC INSTRUCTION TESTS AND BEFORE THE COM-
                                ;PREHENSIVE INSTRUCTION TESTS, THE VECTOR BELOW IS SET UP TO POINT
                                ;TO THE  ERROR SERVICE ROUTINE AT "ERRB:" WITH A PRIORITY OF 0

000030  000032                          .+2
000032  000000                          HALT

                                ;AFTER EXECUTION OF THE BASIC INSTRUCTION TESTS AND BEFORE THE COM-
                                ;PREHENSIVE INSTRUCTION TESTS, THE VECTOR BELOW IS SET UP TO POINT
                                ;TO THE PRINT SERVICE ROUTINE AT "PRINT:" WITH A PRIORITY OF 0

000034  000036                          .+2
000036  000000                          HALT
000040  000042                          .+2
000042  000000                          HALT
000044  000046                          .+2
000046  000000                          HALT
000050  000052                          .+2
000052  000000                          HALT
000054  000056                          .+2
000056  000000                          HALT
000060  000062                          .+2
000062  000000                          HALT
000064  000066                          .+2
000066  000000                          HALT
000070  000072                          .+2
000072  000000                          HALT
000074  000076                          .+2
000076  000000                          HALT
000100  000102                          .+2
000102  000000                          HALT
000104  000106                          .+2
000106  000000                          HALT
000110  000112                          .+2
000112  000000                          HALT
000114  000116                          .+2
```

```
000116  000000                          HALT
000120  000122                          .+2
000122  000000                          HALT
000124  000126                          .+2
000126  000000                          HALT
000130  000132                          .+2
000132  000000                          HALT
000134  000136                          .+2
000136  000000                          HALT
000140  000142                          .+2
000142  000000                          HALT
000144  000146                          .+2
000146  000000                          HALT
000150  000152                          .+2
000152  000000                          HALT
000154  000156                          .+2
000156  000000                          HALT
000160  000162                          .+2
000162  000000                          HALT
000164  000166                          .+2
000166  000000                          HALT
000170  000172                          .+2
000172  000000                          HALT
000174  000176                          .+2
000176  000000                          HALT
000200  012707  003000                  MOV     #3000,PC        ;GO START UP AT LOC. 3000
000204  000206                          .+2
000206  000000                          HALT
000210  000212                          .+2
000212  000000                          HALT
000214  000216                          .+2
000216  000000                          HALT
000220  000222                          .+2
000222  000000                          HALT
000224  000226                          .+2
000226  000000                          HALT
000230  000232                          .+2
000232  000000                          HALT
000234  000236                          .+2
000236  000000                          HALT
000240  000242                          .+2
000242  000000                          HALT
000244  000246                          .+2
000246  000000                          HALT
000250  000252                          .+2
000252  000000                          HALT
000254  000256                          .+2
000256  000000                          HALT
000260  000262                          .+2
000262  000000                          HALT
000264  000266                          .+2
000266  000000                          HALT
000270  000272                          .+2
000272  000000                          HALT
000274  000276                          .+2
000276  000000                          HALT
```

```
2731  000300  000302                    .+2
2732  000302  000000                    HALT
2733  000304  000306                    .+2
2734  000306  000000                    HALT
2735  000310  000312                    .+2
2736  000312  000000                    HALT
2737  000314  000316                    .+2
2738  000316  000000                    HALT
2739  000320  000322                    .+2
2740  000322  000000                    HALT
2741  000324  000326                    .+2
2742  000326  000000                    HALT
2743  000330  000332                    .+2
2744  000332  000000                    HALT
2745  000334  000336                    .+2
2746  000336  000000                    HALT
2747  000340  000342                    .+2
2748  000342  000000                    HALT
2749  000344  000346                    .+2
2750  000346  000000                    HALT
2751  000350  000352                    .+2
2752  000352  000000                    HALT
2753  000354  000356                    .+2
2754  000356  000000                    HALT
2755  000360  000362                    .+2
2756  000362  000000                    HALT
2757  000364  000366                    .+2
2758  000366  000000                    HALT
2759  000370  000372                    .+2
2760  000372  000000                    HALT
2761  000374  000376                    .+2
2762  000376  000000                    HALT
2763  000400  000402                    .+2
2764  000402  000000                    HALT
2765  000404  000406                    .+2
2766  000406  000000                    HALT
2767  000410  000412                    .+2
2768  000412  000000                    HALT
2769  000414  000416                    .+2
2770  000416  000000                    HALT
2771  000420  000422                    .+2
2772  000422  000000                    HALT
2773  000424  000426                    .+2
2774  000426  000000                    HALT
2775  000430  000432                    .+2
2776  000432  000000                    HALT
2777  000434  000436                    .+2
2778  000436  000000                    HALT
2779  000440  000442                    .+2
2780  000442  000000                    HALT
2781  000444  000446                    .+2
2782  000446  000000                    HALT
2783  000450  000452                    .+2
2784  000452  000000                    HALT
2785  000454  000456                    .+2
2786  000456  000000                    HALT
```

```
  2787  000460  000462                          .+2
  2788  000462  000000                          HALT
  2789  000464  000466                          .+2
  2790  000466  000000                          HALT
  2791  000470  000472                          .+2
  2792  000472  000000                          HALT
  2793  000474  000476                          .+2
  2794  000476  000000                          HALT
  2795  000500  000502                          .+2
  2796  000502  000000                          HALT
  2797  000504  000506                          .+2
  2798  000506  000000                          HALT
  2799  000510  000512                          .+2
  2800  000512  000000                          HALT
  2801  000514  000516                          .+2
  2802  000516  000000                          HALT
  2803  000520  000522                          .+2
  2804  000522  000000                          HALT
  2805  000524  000526                          .+2
  2806  000526  000000                          HALT
  2807  000530  000532                          .+2
  2808  000532  000000                          HALT
  2809  000534  000536                          .+2
  2810  000536  000000                          HALT
  2811  000540  000542                          .+2
  2812  000542  000000                          HALT
  2813  000544  000546                          .+2
  2814  000546  000000                          HALT
  2815  000550  000552                          .+2
  2816  000552  000000                          HALT
  2817  000554  000556                          .+2
  2818  000556  000000                          HALT
  2819  000560  000562                          .+2
  2820  000562  000000                          HALT
  2821  000564  000566                          .+2
  2822  000566  000000                          HALT
  2823  000570  000572                          .+2
  2824  000572  000000                          HALT
  2825  000574  000576                          .+2
  2826  000576  000000                          HALT
  2827  000600  000602                          .+2
  2828  000602  000000                          HALT
  2829  000604  000606                          .+2
  2830  000606  000000                          HALT
  2831  000610  000612                          .+2
  2832  000612  000000                          HALT
  2833  000614  000616                          .+2
  2834  000616  000000                          HALT
  2835  000620  000622                          .+2
  2836  000622  000000                          HALT
  2837  000624  000626                          .+2
  2838  000626  000000                          HALT
  2839  000630  000632                          .+2
  2840  000632  000000                          HALT
  2841  000634  000636                          .+2
  2842  000636  000000                          HALT
```

```
2843  000640  000642                    .+2
2844  000642  000000                    HALT
2845  000644  000646                    .+2
2846  000646  000000                    HALT
2847  000650  000652                    .+2
2848  000652  000000                    HALT
2849  000654  000656                    .+2
2850  000656  000000                    HALT
2851  000660  000662                    .+2
2852  000662  000000                    HALT
2853  000664  000666                    .+2
2854  000666  000000                    HALT
2855  000670  000672                    .+2
2856  000672  000000                    HALT
2857  000674  000676                    .+2
2858  000676  000000                    HALT
2859  000700  000702                    .+2
2860  000702  000000                    HALT
2861  000704  000706                    .+2
2862  000706  000000                    HALT
2863  000710  000712                    .+2
2864  000712  000000                    HALT
2865  000714  000716                    .+2
2866  000716  000000                    HALT
2867  000720  000722                    .+2
2868  000722  000000                    HALT
2869  000724  000726                    .+2
2870  000726  000000                    HALT
2871  000730  000732                    .+2
2872  000732  000000                    HALT
2873  000734  000736                    .+2
2874  000736  000000                    HALT
2875  000740  000742                    .+2
2876  000742  000000                    HALT
2877  000744  000746                    .+2
2878  000746  000000                    HALT
2879  000750  000752                    .+2
2880  000752  000000                    HALT
2881  000754  000756                    .+2
2882  000756  000000                    HALT
2883  000760  000762                    .+2
2884  000762  000000                    HALT
2885  000764  000766                    .+2
2886  000766  000000                    HALT
2887  000770  000772                    .+2
2888  000772  000000                    HALT
2889  000774  000776                    .+2
2890  000776  000000                    HALT
```

```
                                ; ***************************************************************
                                                    ;PROGRAM DEFINITIONS
                                ; ***************************************************************

                                        ;GENERAL REGISTER DEFINITIONS

        000000                          R0 = %0
        000001                          R1 = %1
        000002                          R2 = %2
        000003                          R3 = %3
        000004                          R4 = %4
        000005                          R5 = %5
        000006                          SP = %6
        000007                          PC = %7

                                        ;DEFINITIONS FOR KD11-A PROCESSOR STATUS WORD AND CONSOLE SWITCH REGISTER

        177570                          SR = 177570             ;CONSOLE SWITCH REG. ADDR
        177776                          PSW = 177776            ;PROCESSOR STATUS REG. ADDR

                                        ;DEFINITIONS FOR CONSOLE SWITCH REG. - BIT POSITIONS

        100000                          SW15 = 100000
        040000                          SW14 = 040000
        020000                          SW13 = 020000
        010000                          SW12 = 010000
        004000                          SW11 = 004000
        002000                          SW10 = 002000
        001000                          SW09 = 001000

                                        ;IOT USED TO CALL "SCOPE" LOOP UTILITY

        000004                          SCOPE = IOT

                                        ;EMT USED TO CALL "ERROR" SERVICE ROUTINE

        104000                          ERROR=EMT               ;PRINT 8 COLUMNS
        104001                          ERROR1 = EMT+1          ;PRINT COLUMN 1 ONLY
        104002                          ERROR2=EMT+2            ;PRINT COLUMNS 1 AND 2
        104003                          ERROR3 = EMT+3          ;PRINT COLUMNS 1,2,3
        104004                          ERROR4 = EMT+4          ;PRINT COLUMNS 1,2,3,4
        104005                          ERROR5 = EMT+5          ;PRINT COLUMNS 1,2,3,4,5
        104006                          ERROR6 = EMT+6          ;PRINT COLUMNS 1,2,3,4,5,6
        104007                          ERROR7 = EMT+7          ;PRINT COLUMNS 1,2,3,4,5,6,7

                                        ;TRAP USED TO CALL THE PRINT UTILITY

        104400                          TYPE = TRAP

        177546                          LKCSR=  177546          ;KW11-L LINE CLOCK ADDRESS

                                        ;ADDRESS ASSIGNMENTS FOR DL11 CONSOLE TERMINAL INTERFACE

        177560                          RCSR=177560             ;RCVR. CONTROL / STATUS REG. ADDRESS
        177562                          RDBR = 177562           ;RECEIVER DATA BUFFER REG. ADDR.
```

```
177564                          XCSR = 177564          ;TRANSMITTER CONTROL / STATUS REG. ADDR
177566                          XDBR = 177566          ;TRANSMIT DATA BUFFER REG. ADDR.
001000                  .=1000

001000                          STACKL=001000          ;TOP OF STACK FOR LOWER TESTS
```

```
                                                        ;////////////////////
                                                        ;  "BCPT" TESTS      /
                                                        ;////////////////////

                                ; ***************************************************************
                                        .SBTTL BT001 "BR" TEST -POSITIVE OFFSET
                                ; ***************************************************************

                                ;MICROPROGRAMMING / LOGIC INFORMATION

                                ;ROM SEQ:       [111,340,341,016] FC 1,7

                                ;ACT BUTS:      37[004]100,111 / 16[340]016,016

                                ;EXEC:          [341]ALUC=LHLLH :[016]D=001004

                                ;CODES:         N/A     /       N:C=0000

                                ;SYNC:          N/A     T=1.76 USEC

                                ;KEY SIG:       K5-3 BR INSTR L / K5-3 TRUE BR L / K3-3 SM=0 L / K3-3 IR(14:12)=0 L

001000  000401                  BT001:  BR      BT002           ;TEST THE BR FORWARD

001002  000000                  E001:   HALT                    ;BR FAILED TO LOAD PC PROPERLY
```

```
                                ; ***********************************************************************
                                        .SBTTL BT002 "BR" TEST - NEGATIVE OFFSET
                                ; ***********************************************************************

                                ;MICROPROGRAMMING / LOGIC INFORMATION

                                ;ROM SEQ:       [111,340,341,016] FC 1,7

                                ;ACT BUTS:      37[004]100,111 / 16[340]016,016

                                ;EXEC:          [341]ALUC=LHLLH :[016]D=001006

                                ;CODES:         N/A     /       N:C=0000

                                ;SYNC:          N/A     T=1.76 USEC

                                ;KEY SIG:       K5-3 BR INSTR L / K5-3 TRUE BR L / K3-3 SM=0 L / K3-3 IR(14:12)=0 L

001004  000402                  BT002:  BR      I002            ;GO TO TEST INSTRUCTION

001006  000403                  A002:   BR      BT003           ;GO TO NEXT TEST

001010  000000                  EX002:  HALT                    ;JUST IN CASE

001012  000775                  I002:   BR      A002            ;TEST THE BR - NEG. OFFSET

001014  000000                  E2002:  HALT                    ;BR FAILED WITH NEG. OFFSET
```

```
                                ; ***********************************************************************
                                        .SBTTL BT003 "BASIC COND. BR" TEST - FLAGS CLEARED
                                ; ***********************************************************************

                                ;MICROPROGRAMMING / LOGIC INFORMATION (BMI,BEQ,BVS)

                                ;ROM SEQ:       [110,347,016] FC 1,7

                                ;ACT BUTS:      37[004]100,110 / 16[110]016,016

                                ;EXEC:          NO BRANCH

                                ;CODES:         N/A     /       N:C=0000

                                ;SYNC:          N/A     T=1.4 USEC

                                ;KEY SIG:       K5-3 BR INSTR L / (BMI)K3-3 SM=0 L / (BEQ)K3-3 SM=1 L / (BVS)K3-3 SM=2 L
                                                ; (BMI,BVS)K3-4 IR15 L

001016  100403                  BT003:  BMI     E003            ;BR IF "N" SET
001020  001402                          BEQ     E003            ;BR IF "Z" SET
001022  102401                          BVS     E003            ;BR IF "V" SET
001024  103002                          BCC     BT004           ;BR IF "C" CLEAR

001026  000000                  E003:   HALT                    ;ERROR - ONE OF THE ABOVE BR'S FAILED
                                                                ;OR THE FLAGS FAILED TO CLEAR ON "START"
001030  000772                          BR      BT003           ;LOCK ON HARD ERROR
```

```
                                ; ***********************************************************************
                                        .SBTTL BT004 "SCC AND COND. BR'S" TEST - FLAGS SET
                                ; ***********************************************************************

                                ;MICROPROGRAMMING / LOGIC INFORMATION (SCC)

                                ;ROM SEQ:       [117,352,016] FC 1,7

                                ;ACT BUTS:      37[004]100,117 / 16[117]016,016

                                ;EXEC:          [117]ALUC=HHLHH,[352]ALUC=HHHHL :[016]D=000017

                                ;CODES:         [352]SPS=3      /       N:C=1111

                                ;SYNC:          B05J2   (+)     T=1.72 USEC

                                ;KEY SIG:       K3-6 CC INSTR H / K3-6 IIKO(CINSTR) L / K3-3 IR04(1) H

 001032  000277                 BT004:  SCC                     ;MAKE N:C=1111

 001034  100003                 I004:   BPL     E004            ;BR IF "N" FAILED TO SET
 001036  001002                         BNE     E004            ;BR IF "Z" FAILED TO SET
 001040  102001                         BVC     E004            ;BR IF "V" FAILED TO SET
 001042  103402                         BCS     BT005           ;BR IF "C" SET OK

 001044  000000                 E004:   HALT                    ;ERROR - ONE OF THE ABOVE BR'S FAILED
                                                                ;OR THA SCC FAILED TO SET ALL THE FLAGS
 001046  000771                         BR      BT004           ;LOCK ON HARD ERROR
```

```
                                ; ***********************************************************************
                                        .SBTTL BT005 "CCC AND COND. BR'S" TEST - FLAGS CLEARED
                                ; ***********************************************************************

                                ;MICROPROGRAMMING / LOGIC INFORMATION (CCC)

                                ;ROM SEQ:       [116,350,351,016] FC 1,7

                                ;ACT BUTS:      37[004]100,116 / 16[350]016,016

                                ;EXEC:          [116,351]ALUC=HHLHH,[350]ALUC=HLHLH     :[016]D=000000

                                ;CODES:         [351]SPS=3      /       N:C=0000

                                ;SYNC:          B05J2   (+)     T=2.02 USEC

                                ;KEY SIG:       K3-6 CC INSTR H

001050  000257                  BT005:  CCC                     ;MAKE N:C=0000

001052  100403                  I005:   BMI     E005            ;BR IF "N" STILL SET
001054  001402                          BEQ     E005            ;BR IF "Z" STILL SET
001056  102401                          BVS     E005            ;BR IF "V" STILL SET
001060  103002                          BCC     BT006           ;BR IF "C" GOT CLEARED

001062  000000                  E005:   HALT                    ;ERROR - ONE OF THE ABOVE BR'S FAILED
                                                                ;OR THE CCC FAILED TO CLEAR ALL FLAGS
001064  000771                          BR      BT005           ;LOCK ON HARD ERROR
```

```
                                ; ***********************************************************************
                                        .SBTTL BT006 "CLR  %R" TEST - SETS THE "Z" BIT
                                ; ***********************************************************************

                                ;MICROPROGRAMMING / LOGIC INFORMATION

                                ;ROM SEQ:       [104,373,360,001] FC 1,7,8

                                ;ACT BUTS:      37[004]100,104 / 31[104]360,360 / 27[373]000,001

                                ;EXEC:          [104]ALUC=HLLHH :[373]D=000000

                                ;CODES:         [373]SPS=1,[360]SPS=3   /       N:C=0100

                                ;SYNC:          B05J2   (-)     T=1 USEC

                                ;KEY SIG:       K3-4 CLR L / K3-3 DM=0 L / K3-4 OVLAP INSTR H

001066  000257                  BT006:  CCC                     ;MAKE N:C=0000

001070  005000                  I006:   CLR     R0              ;TEST THE CLR - IT SHOULD SET "Z"

001072  001402                          BEQ     BT007           ;BR IF CLR SET "Z"

001074  000000                  E006:   HALT                    ;ERROR - CLR FAILED TO SET "Z"
001076  000773                          BR      BT006           ;LOCK ON HARD ERROR
```

```
                                ; ***********************************************************************
                                        .SBTTL BT007 "TST  %R" TEST - USING THE CLR
                                ; ***********************************************************************

                                ;MICROPROGRAMMING / LOGIC INFORMATION

                                ;ROM SEQ:       [104,373,362,001] FC 1,7,8

                                ;ACT BUTS:      37[004]100,104 / 31[104]360,362 / 27[373]000,001

                                ;EXEC:          [104]ALUC=LLLLL :[373]D=000000

                                ;CODES:         [373]SPS=1,[362]SPS=3   /       N:C=0100

                                ;SYNC:          B05J2   (-)     T=1 USEC

                                ;KEY SIG:       K3-3 DM=0 L / K3-4 TST L / K3-4 OVLAP INSTR H

 001100  005000                 BT007:  CLR     R0              ;MAKE [R0] = 000000
 001102  000257                         CCC                     ;MAKE N:C=0000

 001104  005700                 T007:   TST     R0              ;TEST THE TST - IT SHOULD SET "Z"

 001106  001402                         BEQ     BT010           ;BR IF "Z" SET OK

 001110  000000                 E007:   HALT                    ;ERROR - CLR FAILED TO LOAD R0 WITH
                                                                ;ALL ZEROES OR TST FAILED
 001112  000772                         BR      BT007           ;LOCK ON HARD ERROR
```

```
                                ; ***********************************************************************
                                        .SBTTL BT010 "COM  %R" TEST - SHOULD SET "N" AND "C"
                                ; ***********************************************************************

                                ;MICROPROGRAMMING / LOGIC INFORMATION

                                ;ROM SEQ:       [104,373,360,001] FC 1,7,8

                                ;ACT BUTS:      37[004]100,104 / 31[104]360,360 / 27[373]000,001

                                ;EXEC:          [104]ALUC=HLLLL :[373]D=177777

                                ;CODES:         [373]SPS=1,[360]SPS=3   /       N:C=1001

                                ;SYNC:          B05J2   (-)     T=1 USEC

                                ;KEY SIG:       K3-4 COM L / K3-3 DM=0 L / K3-4 OVLAP INSTR H

001114  005000                  BT010:  CLR     R0              ;MAKE [R0] = 000000
001116  000257                          CCC                     ;MAKE N:C=0000

001120  005100                  I01C:   COM     R0              ;TEST THE COM - [R0] S/B = 177777

001122  100001                          BPL     E010            ;BR IF "N" FAILED TO SET
001124  103402                          BCS     BT011           ;BR IF "C" SET OK

001126  000000                  E010:   HALT                    ;ERROR - COM FAILED
001130  000771                          BR      BT010           ;LOCK ON HARD ERROR
```

```
                                ; ***********************************************************************
                                        .SBTTL BT011 "COM  %R AND ADC  %R" TEST
                                ; ***********************************************************************

                                ;MICROPROGRAMMING / LOGIC INFORMATION (COM  %0)

                                ;ROM SEQ:       [104,373,360,001] FC 1,7,8

                                ;ACT BUTS:      37[004]100,104 / 31[104]360,360 / 27[373]000,001

                                ;EXEC:          [104]ALUC=HLLLL :[373]D=177777
                                ;                          (ADC) :[373]D=000000


                                ;CODES:         [373]SPS=1,[360]SPS=3   /       N:C=1001
                                ;                                       (ADC)   N:C=0101

                                ;SYNC:          B05J2   (-)     T=1 USEC

                                ;KEY SIG:       K3-3 DM=0 L / K3-4 COM L / K3-4 OVLAP INSTR H
                                ;       (ADC)   K3-3 DM=0 L / K3-4 ADC L / K3-4 OVLAP INSTR H / K3-8 CINOO L

 001132  005000                 BT011:  CLR     R0              ;MAKE [R0] = 000000
 001134  000257                         CCC                     ;MAKE N:C=0000

 001136  005100                 I011:   COM     R0              ;TEST THE COM - [R0] S/B = 177777
 001140  005500                         ADC     R0              ;TEST THE ADC - [R0] S/B = 000000

 001142  001001                         BNE     E011            ;BR IF "Z" DID NOT SET
 001144  103402                         BCS     BT012           ;BR IF "C" SET OK

 001146  000000                 E011:   HALT                    ;ERROR - COM OR ADC FAILED
 001150  000770                         BR      BT011           ;LOCK ON HARD ERROR
```

```
                                ; ***********************************************************************
                                        .SBTTL BT012 "MOV  #N,R" TEST WITH N=177777,[R]=000000
                                ; ***********************************************************************

                                ;MICROPROGRAMMING / LOGIC INFORMATION

                                ;ROM SEQ:       [172,257,200,125,375,016] FC 1,4,8

                                ;ACT BUTS:      37[004]100,172 / 22[172]200,200 / 16[125]016,016

                                ;EXEC:          [200]ALUC=LLLLL :[125]D=177777

                                ;CODES:         [125]SPS=3      /       N:C=1000

                                ;SYNC:          B05J2   (-)     T= 2.3 USEC

                                ;KEY SIG:       K3-3 MOV L / K3-3 SM=2 L / K3-3 DM=0 L

001152  005000                  BT012:  CLR     R0              ;MAKE [R0] = 000000
001154  000257                          CCC                     ;MAKE N:C=0000

001156  012700  177777          I012:   MOV     #-1,R0          ;TEST THE MOV - [R0] S/B = 177777

001162  005100                          COM     R0              ;MAKE [R0] = 000000
001164  001402                          BEQ     BT013           ;BR IF "Z" SET

001166  000000                  E012:   HALT                    ;ERROR - MOV FAILED TO LOAD R0 WITH ALL 1'S
001170  000770                          BR      BT012           ;LOCK ON HARD ERROR
```

```
                                ; ***************************************************************
                                        .SBTTL BT013 "MOV  #N,R" TEST WITH N=000000,[R]=177777
                                ; ***************************************************************

                                ;MICROPROGRAMMING / LOGIC INFORMATION

                                ;ROM SEQ:       [142,240,250,160,204,000] FC 1,4,8

                                ;ACT BUTS:      37[004]100,142 / 35[240]120,160 / 20[160]000,000

                                ;EXEC:          [160]ALUC=LLLLL :[204]D=000000

                                ;CODES:         [204]SPS=3      /       N:C=0100

                                ;SYNC:          B05J2   (-)     T=2.3 USEC

                                ;KEY SIG:       K3-3 MOV L / K3-3 SM=2 L / K3-3 DM=0 L

001172  005000                  BT013:  CLR     R0              ;MAKE [R0] = 000000
001174  005100                          COM     R0              ;MAKE [R0] = 177777
001176  000257                          CCC                     ;SCOPE SYNC

001200  012700  000000          I013:   MOV     #0,R0           ;TEST THE MOV - [R0] S/B = 000000

001204  005100                          COM     R0              ;MAKE [R0] = 177777, SET "C"
001206  005500                          ADC     R0              ;MAKE [R0] = 000000
001210  001402                          BEQ     BT014           ;BR IF "Z" GOT SET

001212  000000                  E013:   HALT                    ;ERROR - MOV FAILED TO CLEAR R0
001214  000766                          BR      BT013           ;LOCK ON HARD ERROR
```

```
                                ; ***********************************************************************
                                        .SBTTL BT014 "CLR  (R)" TEST - [R] = 177776
                                ; ***********************************************************************

                                ;MICROPROGRAMMING / LOGIC INFORMATION

                                ;ROM SEQ:       [161,266,267,220,211,367,375,016] FC 1,3,9,8

                                ;ACT BUTS:      37[004]100,161 / 33[266]220,220 / 16[367]016,016

                                ;EXEC:          [220]ALUC=HLLHH :[211]D=000000

                                ;CODES:         [211]SPS=1,[367]SPS=3   /       N:C=0000

                                ;SYNC:          B05J2   (-)     T=2.6 USEC

                                ;KEY SIG:       K3-4 CLR L / K3-3 DM=1 L

001216  012706  001000          BT014:  MOV     #STACKL,SP      ;SET UP STACK POINTER
001222  012700  177776                  MOV     #PSW,R0         ;R0 POINTS TO PSW
001226  000277                          SCC                     ;MAKE [PSW] = 017

001230  005010                  I014:   CLR     (R0)            ;TEST THE CLR - IT SHOULD CLEAR PSW

001232  001002                          BNE     BT015           ;BR IF CLR MADE "Z" = 0 - IT SHOULD

001234  000000                  E014:   HALT                    ;ERROR- CLR FAILED TO CLEAR PSW
001236  000767                          BR      BT014           ;LOCK ON HARD ERROR
```

```
                                ; ***********************************************************************
                                        .SBTTL BT015 "CLR  (R)+" TEST - [R] = 177776
                                ; ***********************************************************************

                                ;MICROPROGRAMMING / LOGIC INFORMATION

                                ;ROM SEQ:       [162,260,267,220,211,367,375,016] FC 1,3,9,8

                                ;ACT BUTS:      37[004]100,162 / 33[260]220,220 / 16[367]016,016

                                ;EXEC:          [220]ALUC=HLLHH :[211]D=000000

                                ;CODES:         [211]SPS=1,[367]SPS=3   /       N:C=0000

                                ;SYNC:          B05J2   (-)     T=2.6 USEC

                                ;KEY SIG:       K3-4 CLR L / K3-3 DM=2 L / K5-5 BCON (1+2) H

001240  012700  177776          BT015:  MOV     #PSW,R0         ;R0 POINTS TO PSW
001244  000277                          SCC                     ;MAKE [PSW] = 017

001246  005020                  I015:   CLR     (R0)+           ;TEST THE CLR - IT SHOULD CLEAR PSW

001250  001002                          BNE     A015            ;BR IF CLR MADE "Z" = 0 - IT SHOULD

001252  000000                  E1015A: HALT                    ;ERROR- CLR FAILED TO CLEAR PSW
001254  000771                          BR      BT015           ;LOCK ON HARD ERROR

001256  005700                  A015:   TST     R0              ;AUTO INC SHOULD ZERO R0

001260  001402                          BEQ     BT016           ;BR IF IT DID

001262  000000                  E2015:  HALT                    ;ERROR - AUTOINC. FAILED
001264  000765                          BR      BT015           ;LOCK ON HARD ERROR
```

```
                                ; ***********************************************************************
                                        .SBTTL BT016 "COM  (R)" TEST - [R] = 177776
                                ; ***********************************************************************

                                ;MICROPROGRAMMING / LOGIC INFORMATION

                                ;ROM SEQ:       [161,266,267,220,211,367,375,016] FC 1,3,9,8

                                ;ACT BUTS:      37[004]100,161 / 33[266]220,220 / 16[367]016,016

                                ;EXEC:          [220]ALUC=HLLLL :[211]D=000357

                                ;CODES:         [211]SPS=1,[367]SPS=3   /       N:C=1111

                                ;SYNC:          BOSJ2   (-)     T=1.8 USEC

                                ;KEY SIG:       K3-4 COM L / K3-3 DM=1 L

001266  012700  177776          BT016:  MOV     #PSW,R0         ;R0 POINTS TO PSW
001272  000257                          CCC                     ;MAKE [PSW] = 000

001274  005110                  I016:   COM     (R0)            ;TEST THE COM - [PSW] S/B = 357

001276  100003                          BPL     E016            ;N:C=1111 ?
001300  001002                          BNE     E016
001302  102001                          BVC     E016
001304  103402                          BCS     BT017

001306  000000                  E016:   HALT                    ;ERROR - COM FAILED TO MAKE [PSW] = 357
001310  000766                          BR      BT016           ;LOCK ON HARD ERROR
```

```
                                ; ***********************************************************************
                                        .SBTTL BT017 "COM  (R0)+" TEST - [R0] = 177776
                                ; ***********************************************************************

                                ;MICROPROGRAMMING / LOGIC INFORMATION

                                ;ROM SEQ:       [162,160,267,220,211,367,375,016] FC 1,3,9,8

                                ;ACT BUTS:      37[004]100,162 / 33[260]220,220 / 16[367]016,016

                                ;EXEC:          [220]ALUC=HLLLL :[211]D=000357

                                ;CODES:         [211]SPS=1,[367]SPS=3   /       N:C=1111

                                ;SYNC:          B05J2   (-)     T=2 USEC

                                ;KEY SIG:       K3-4 COM L / K3-3 DM=2 L / K5-5 BCON(1+2) H

001312  012700  177776          BT017:  MOV     #PSW,R0         ;R0 POINTS TO PSW
001316  005010                          CLR     (R0)            ;MAKE [PSW] = 000
001320  000257                          CCC                     ;SCOPE SYNC

001322  005120                  I017:   COM     (R0)+           ;TEST THE COM - [PSW] S/B = 357

001324  100003                          BPL     E1017           ;N:C = 1111 ?
001326  001002                          BNE     E1017
001330  102001                          BVC     E1017
001332  103402                          BCS     A017

001334  000000                  E1017:  HALT                    ;COM FAILED TO SET ALL FLAGS
001336  000765                          BR      BT017           ;LOCK ON HARD ERROR

001340  005100                  A017:   COM     R0              ;SHOULD MAKE [R0] = 177777
001342  005500                          ACC     R0              ;SHOULD MAKE [R0] = 000000
001344  001402                          BEQ     BT020

001346  000000                  E2017:  HALT                    ;ERROR - COM FAILED TO AUTO INC. R0
001350  000760                          BR      BT017           ;LOCK ON HARD ERROR
```

```
                                ; ***********************************************************************
                                        .SBTTL BT020 "MOV  RA,RB" TEST - WITH [RA]=177777,[RB]=000000
                                ; ***********************************************************************

                                ;MICROPROGRAMMING / LOGIC INFORMATION

                                ;ROM SEQ:       [170,204,001] FC 1,4,8

                                ;ACT BUTS:      37[004]100,170 / 20[170]000,001

                                ;EXEC:          [170]ALUC=LLLLL :[204]D=177777

                                ;CODES:         [204]SPS=3      /       N:C=1000

                                ;SYNC:          B05J2   (-)     T=1 USEC

                                ;KEY SIG:       K3-3 MOV L / K3-3 SM=0 L / K3-3 DM=0 L / K3-4 OVLAP INSTR H

001352  005000                  BT020:  CLR     R0              ;MAKE [R0]=000000
001354  005001                          CLR     R1              ;MAKE [R1]=000000
001356  005101                          COM     R1              ;MAKE [R1]=0207777
001360  000257                          CCC                     ;SCOPE SYNC

001362  010100                  I020:   MOV     R1,R0           ;TEST THE MOV

001364  100402                          BMI     A020            ;BR IF "N" GOT SET

001366  000000                  E1020:  HALT                    ;ERROR-MOV FAILED TO SET "N"
001370  000770                          BR      BT020           ;LOCK ON HARD ERROR

001372  005100                  A020:   COM     R0              ;[R0] SHOULD GO TO 000000
001374  001402                          BEQ     BT021           ;BR IF IT DID

001376  000000                  E2020:  HALT                    ;ERROR-MOV FAILED TO LOAD R0 WITH 1'S
001400  000764                          BR      BT020           ;LOCK ON HARD ERROR
```

```
                                ; ***********************************************************************
                                        .SBTTL BT021 "MOV  RA,RB" TEST WITH [RA]=000000,[RB]=177777
                                ; ***********************************************************************

                                ;MICROPROGRAMMING / LOGIC INFORMATION

                                ;ROM SEQ:       [170,204,001] FC 1,4,8

                                ;ACT BUTS:      37[004]100,170 / 20[170]000,001

                                ;EXEC:          [170]ALUC=LLLLL :[204]D=000000

                                ;CODES:         [204]SPS=3      /       N:C=0100

                                ;SYNC:          B05J2   (-)     T=1 USEC

                                ;KEY SIG:       K3-3 MOV L / K3-3 SM=0 L / K3-3 DM=0 L / K3-4 OVLAP INSTR H

001402  005000                  BT021:  CLR     R0              ;MAKE [R0]=000000
001404  005100                          COM     R0              ;MAKE [R0]=177777
001406  005001                          CLR     R1              ;MAKE [R1]=000000
001410  000257                          CCC                     ;SCOPE SYNC

001412  010100                  I021:   MOV     R1,R0           ;TEST THE MOV

001414  001402                          BEQ     A021            ;BR IF "Z" GOT SET

001416  000000                  E1021:  HALT                    ;MOV FAILED TO SET "Z"
001420  000770                          BR      BT021           ;LOCK ON HARD ERROR

001422  005100                  A021:   COM     R0              ;SHOULD MAKE [R0]=177777 AND SET "C"
001424  005500                          ADC     R0              ;SHOULD MAKE [R0]=000000
001426  001402                          BEQ     BT022           ;BR IF "Z" SET

001430  000000                  E2021:  HALT                    ;MOV FAILED TO ZERO R0
001432  000763                          BR      BT021           ;LOCK ON HARD ERROR
```

```
                                ; ***********************************************************************
                                        .SBTTL BT022 "MOV  #N,@#A" TEST WITH N=17,A=177776
                                ; ***********************************************************************

                                ;MICROPROGRAMMING / LOGIC INFORMATION

                                ;ROM SEQ:       [142,240,250,173,207,210,200,125,375,016] FC 1,2,4,8

                                ;ACT BUTS:      37[004]100,142 / 35[240]120,173 / 22[207]200,200 / 16[125]016,016

                                ;EXEC:          [200]ALUC=LLLLL :[125]D=000017

                                ;CODES:         [125]SPS=3      /       N:C=1111

                                ;SYNC:          BOSJ2   (-)     T=4 USEC

                                ;KEY SIG:       K3-3 MOV L / K3-3 SM=2 L / K3-3 DM=3 L / K5-5 BC01 H
                                                ; K5-5 BCON(1+2) H

001434  000257                  BT022:  CCC                     ;MAKE [PSW]=000

001436  012737  000017  177776  I022:   MOV     #17,@#PSW       ;TEST THE MOV

001444  100003                          BPL     E022            ;N:C=1111
001446  001002                          BNE     E022
001450  102001                          BVC     E022
001452  103402                          BCS     BT023

001454  000000                  E022:   HALT                    ;MOV FAILED TO LOAD PSW
001456  000766                          BR      BT022           ;LOCK ON HARD ERROR
```

```
                                ; ***********************************************************************
                                        .SBTTL BT023 "MOV  RA,(RB)+" TEST WITH [RA]=17,[RB]=177776
                                ; ***********************************************************************

                                ;MICROPROGRAMMING / LOGIC INFORMATION

                                ;ROM SEQ:       [172,257,201,125,375,016] FC 1,4,8

                                ;ACT BUTS:      37[004]100,172 / 22[172]200,201 / 16[125]016,016

                                ;EXEC:          [201]ALUC=LLLLL :[125]D=000017

                                ;CODES:         [125]SPS=3      /       N:C=1111

                                ;SYNC:          BOSJ2   (-)     T=2.42 USEC

                                ;KEY SIG:       K3-3 MOV L / K3-3 SM=0 L / K3-3 DM=2 L / K5-5 BCON(1+2) H

001460  012700  177776          BT023:  MOV     #PSW,R0         ;R0 POINTS TO PSW
001464  012701  000017                  MOV     #17,R1          ;[SOURCE]=017
001470  005010                          CLR     (R0)            ;MAKE [PSW]=000
001472  000257                          CCC                     ;SCOPE SYNC

001474  010120                  I023:   MOV     R1,(R0)+        ;TEST THE MOV

001476  100003                          BPL     E1023           ;N:C = 1111 ?
001500  001002                          BNE     E1023
001502  102001                          BVC     E1023
001504  103402                          BCS     A023

001506  000000                  E1023:  HALT                    ;MOV FAILED TO LOAD PSW
001510  000763                          BR      BT023           ;LOCK ON HARD ERROR

001512  005100                  A023:   COM     R0              ;SHOULD MAKE [R0]=177777
001514  005500                          ADC     R0              ;SHOULD MAKE [R0]=000000
001516  001402                          BEQ     BT024           ;BR IF IT DID

001520  000000                  E0232:  HALT                    ;MOV FAILED TO AUTO INC. R0
001522  000756                          BR      BT023           ;LOCK ON HARD ERROR
```

```
                                        ; ***********************************************************************
                                                .SBTTL BT024 "CMP  #N,@#A" TEST WITH N=(A)
                                        ; ***********************************************************************

                                        ;MICROPROGRAMMING / LOGIC INFORMATION

                                        ;ROM SEQ:       [142,240,250,163,264,265,266.267,225,367,375,016] FC 1,2,3,8

                                        ;ACT BUTS:      37[004]100,142 / 35[240]120,163 / 33[266]220,225 / 16[367]016,016

                                        ;EXEC:          [225]ALUC=LLHHL :[367]D=000000

                                        ;CODES:         [367]SPS=3      /       N:C=0100

                                        ;SYNC:          B05J2   (-)     T=5.2 USEC

                                        ;KEY SIG:       K3-3 CMP L / K3-3 SM=2 L / K3-3 DM=3 L / K3-8 CINOD L
                                                        ; K4-4 ALLOW CLK L / K5-5 BC01 H

001524  012700  177776          BT024:  MOV     #PSW,R0         ;R0 POINTS TO PSW
001530  005010                          CLR     (R0)            ;MAKE [PSW]=000
001532  000273                          273                     ;MAKE N:C=1011

001534  022737  000013  177776  I024:   CMP     #13,@#PSW       ;TEST THE CMP

001542  001402                          BEQ     BT025           ;BR IF "Z" GOT SET

001544  000000                  E024:   HALT                    ;CMP FAILED TO SET "Z"
001546  000766                          BR      BT024           ;LOCK ON HARD ERROR
```

```
                                        ; ***********************************************************************
                                                .SBTTL BT025 "CMP  #N,@#A" WITH N >  (A)
                                        ; ***********************************************************************

                                        ;MICROPROGRAMMING / LOGIC INFORMATION

                                        ;ROM SEQ:       [142,240,250,163,264,265,266,267,225,367,375,016] FC 1,2,3,8

                                        ;ACT BUTS:      37[004]100,142 / 35[240]120,163 / 33[266]220,225 / 16[367]016,016

                                        ;EXEC:          [225]ALUC=LLHHL :[367]D=177761

                                        ;CODES:         [367]SPS=3      /       N:C=1001

                                        ;SYNC:          B05J2   (-)     T=5.2 USEC

                                        ;KEY SIG:       K3-3 CMP L / K3-3 SM=2 L / K3-3 DM=3 L / K3-8 CINOO L
                                                        ; K4-4 ALLOW CLK L / K5-5 BC01 H

001550  000257                          BT025:  CCC                     ;MAKE [PSW]=000

001552  022737  000017  177776          I025:   CMP     #17,@#PSW       ;TEST THE CMP

001560  001401                                  BEQ     E025            ;BR IF "Z" GOT SET
001562  000402                                  BR      BT026           ;GO TO NEXT TEST

001564  000000                          E025:   HALT                    ;CMP FAILED TO CLEAR "Z"
001566  000770                                  BR      BT025           ;LOCK ON HARD ERROR
```

```
                                ; ***************************************************************
                                        .SBTTL BT026 "CMP  #N,@#A" WITH N <  (A)
                                ; ***************************************************************

                                ;MICROPROGRAMMING / LOGIC INFORMATION

                                ;ROM SEQ:       [142,240,250,163,264,265,266,267,225,367,375,016] FC 1,2,3,8

                                ;ACT BUTS:      37[004]100,142 / 35[240]120,163 / 33[266]220,225 / 16[367]016,016

                                ;EXEC:          [225]ALUC=LLHHL :[367]D=177761

                                ;CODES:         [367]SPS=3      /       N:C=1001

                                ;SYNC:          B05J2   (-)     T=5.2 USEC

                                ;KEY SIG:       K3-3 CMP L / K3-3 SM=2 L / K3-3 DM=3 L / K3-8 CINOO L
                                                ; K4-4 ALLOW CLK L / K5-5 BC01 H

001570  000277                  BT026:  SCC                     ;MAKE [PSW]=017

001572  022737  000000  177776  I026:   CMP     #0,@#PSW        ;TEST THE CMP

001600  001401                          BEQ     E026            ;BR IF "Z" GOT SET
001602  000402                          BR      BT027           ;GO TO NEXT TEST

001604  000000                  E026:   HALT                    ;CMP FAILED TO CLEAR "Z"
001606  000770                          BR      BT026           ;LOCK ON HARD ERROR
```

```
                                        ; ***********************************************************************
                                                .SBTTL BT027 "CMP  R,#N" TEST WITH [R]=N
                                        ; ***********************************************************************

                                        ;MICROPROGRAMMING / LOGIC INFORMATION

                                        ;ROM SEQ:       [162,260,267,224,367,375,016] FC 1,3,8

                                        ;ACT BUTS:      37[004]100,162 / 33[260]220,224 / 16[367]016,016

                                        ;EXEC:          [224]ALUC=LLHHL :[367]D=000000

                                        ;CODES:         [367]SPS=3      /       N:C=0100

                                        ;SYNC:          B05J2   (-)     T=2.6 USEC

                                        ;KEY SIG:       K3-3 CMP L / K3-3 SM=0 L / K3-3 DM=2 L / K3-8 CIN00 L
                                                        ; K4-4 ALLOW CLK L

001610  012700  177777          BT027:  MOV     #-1,R0          ;MAKE [R0]=177777
001614  000257                          CCC                     ;N:C=0000

001616  020027  177777          I027:   CMP     R0,#-1          ;TEST THE CMP

001622  001402                          BEQ     BT030           ;BR IF CMP SET "Z"

001624  000000                  E027:   HALT                    ;CMP FAILED
001626  000770                          BR      BT027           ;LOCK ON HARD ERROR
```

```
                                ; ***************************************************************
                                        .SBTTL BT030 "CMP  R,#N" TEST WITH [R] > N
                                ; ***************************************************************

                                ;MICROPROGRAMMING / LOGIC INFORMATION

                                ;ROM SEQ:       [162,260,267,224,367,375,016] FC 1,3,8

                                ;ACT BUTS:      37[004]100,162 / 33[260]220,224 / 16[367]016,016

                                ;EXEC:          [224]ALUC=LLHHL :[367]D=000002

                                ;CODES:         [367]SPS=3      /       N:C=0001

                                ;SYNC:          B05J2   (-)     T=2.6 USEC

                                ;KEY SIG:       K3-3 CMP L / K3-3 SM=0 L / K3-3 DM=2 L / K3-8 CINOO L
                                                ; K4-4 ALLOW CLK L

001630  012700  000001          BT030:  MOV     #1,R0           ;MAKE [R0]=000001
001634  000264                          SEZ                     ;SET THE "Z" BIT

001636  020027  177777          I030:   CMP     R0,#-1          ;TEST THE CMP

001642  001002                          BNE     BT031           ;BR IF CMP CLEARED "Z"

001644  000000                  E030:   HALT                    ;CMP FAILED
001646  000770                          BR      BT030           ;LOCK ON HARD ERROR
```

```
                                ; ****************************************************************
                                        .SBTTL BT031 "CMP  R,#N" TEST WITH [R] < N
                                ; ****************************************************************

                                ;MICROPROGRAMMING / LOGIC INFORMATION

                                ;ROM SEQ:       [162,260,267,224,367,375,016] FC 1,3,8

                                ;ACT BUTS:      37[004]100,162 / 33[260]220,224 / 16[367]016,016

                                ;EXEC:          [224]ALUC=LLHHL :[367]D=177762

                                ;CODES:         [367]SPS=3      /       N:C=1001

                                ;SYNC:          BOSJ2   (-)     T=2.6 USEC

                                ;KEY SIG:       K3-3 CMP L / K3-3 SM=0 L / K3-3 DM=2 L / K3-8 CINOO L
                                                ; K4-4 ALLCM CLK L

001650  012700  000001          BT031:  MOV     #1,R0           ;MAKE [R0] = 000001
001654  000264                          SEZ                     ;SET THE "Z" BIT

001656  020027  000017          I031:   CMP     R0,#17          ;TEST THE CMP

001662  001002                          BNE     BT032           ;BR IF CMP CLEARED "Z"

001664  000000                  E031:   HALT                    ;CMP FAILED TO SET "Z"
001666  000770                          BR      BT031           ;LOCK ON HARD ERROR
```

```
                                        ; ***********************************************************************
                                                .SBTTL BT032 "CMP  (RA)+,RB" TEST WITH [SOURCE]=[RB]
                                        ; ***********************************************************************

                                        ;MICROPROGRAMMING / LOGIC INFORMATION

                                        ;ROM SEQ:       [142,240,250,120,371,362,000] FC 1,2,8

                                        ;ACT BUTS:      37[004]100,142 / 35[240]120,120 / 31[120]360,362 / 27[371]016,016

                                        ;EXEC:          [371]ALUC=LLHHL :[362]D=000000

                                        ;CODES:         [362]SPS=3      /       N:C=0100

                                        ;SYNC:          B05J2   (-)     T=2.5 USEC

                                        ;KEY SIG:       K3-3 CMP L / K3-3 SM=2 L / K3-3 DM=0 L / K5-5 BCON(1+2) H
                                                        ; K3-8 CINOO L

001670  012700  177776          BT032:  MOV     #PSW,R0         ;R0 POINTS TO PSW
001674  012737  000340  177776          MOV     #340,@#PSW      ;MAKE [PSW]=340
001702  012701  000340                  MOV     #340,R1         ;MAKE [DEST]=340
001706  000257                          CCC                     ;N:C=0000

001710  022001                  I032:   CMP     (R0)+,R1        ;TEST THE CMP

001712  001402                          BEQ     A032            ;BR IF "Z" GOT SET

001714  000000                  E1032:  HALT                    ;CMP FAILED TO ACCESS PSW
001716  000764                          BR      BT032           ;LOCK ON HARD ERROR

001720  005100                  A032:   COM     R0              ;MAKE [R0]=177777
001722  005500                          ADC     R0              ;MAKE [R0]=000000
001724  001402                          BEQ     BT033           ;BR IF "Z" SET

001726  000000                  E2032:  HALT                    ;CMP FAILED TO AUTO INC. R0
001730  000757                          BR      BT032           ;LOCK ON HARD ERROR
```

```
                                        ; ***********************************************************************
                                                .SBTTL BT033 "CMP  (RA)+,RB" TEST WITH [SOURCE]>[RB]
                                        ; ***********************************************************************

                                        ;MICROPROGRAMMING / LOGIC INFORMATION

                                        ;ROM SEQ:       [142,240,250,120,371,362,000] FC 1,2,8

                                        ;ACT BUTS:      37[004]100,142 / 35[240]120,120 / 31[120]360,362 / 27[371]016,016

                                        ;EXEC:          [371]ALUC=LLHHL :[362]D=000010

                                        ;CODES:         [362]SPS=3      /       N:C=0000

                                        ;SYNC:          B05J2   (-)     T=2.5 USEC

                                        ;KEY SIG:       K3-3 CMP L / K3-3 SM=2 L / K3-3 DM=0 L / K5-5 BCON(1+2) H
                                                        ; K3-8 CINOO L

001732  012700  177776          BT033:  MOV     #PSW,R0         ;R0 POINTS TO PSW
001736  012737  000340  177776          MOV     #340,@#PSW      ;MAKE [PSW]=340
001744  012701  000330                  MOV     #330,R1         ;MAKE [DEST]=330
001750  000264                          SEZ                     ;SET THE "Z" BIT

001752  022001                  I033:   CMP     (R0)+,R1        ;TEST THE CMP

001754  001002                          BNE     A033            ;BR IF "Z" GOT CLEARED

001756  000000                  E1033:  HALT                    ;CMP FAILED TO ACCESS PSW
001760  000764                          BR      BT033           ;LOCK ON HARD ERROR

001762  005100                  A033:   COM     R0              ;MAKE [R0]=177777
001764  005500                          ADC     R0              ;MAKE [R0]=000000
001766  001402                          BEQ     BT034           ;BR IF "Z" SET

001770  000000                  E2033:  HALT                    ;CMP FAILED TO AUTO INC. R0
001772  000757                          BR      BT033           ;LOCK ON HARD ERROR
```

```
                                        ; ***********************************************************************
                                                .SBTTL BT034 "CMP  (RA)+,RB" TEST WITH [SOURCE]<[RB]
                                        ; ***********************************************************************

                                        ;MICROPROGRAMMING / LOGIC INFORMATION

                                        ;ROM SEQ:       [142,240,250,120,371,362,000] FC 1,2,8

                                        ;ACT BUTS:      37[004]100,142 / 35[240]120,120 / 31[120]360,362 / 27[371]016,016

                                        ,EXTC:          [371]ALUC=LLHHL :[362]D=177770

                                        ;CODES:         [362]SPS=3      /       N:C=1001

                                        ;SYNC:          B05J2   (-)     T=2.5 USEC

                                        ;KEY SIG:       K3-3 CMP L / K3-3 SM=2 L / K3-3 DM=0 L / K5-5 BCON(1+2) H
                                                        ; K3-8 CINOO L

001774  012700  177776          BT034:  MOV     #PSW,R0         ;R0 POINTS TO PSW
002000  012737  000330  177776          MOV     #330,@#PSW      ;MAKE [PSW]=330
002006  012701  000340                  MOV     #340,R1         ;MAKE [DEST]=340
002012  000264                          SEZ                     ;SET THE "Z" BIT

002014  022001                  I034:   CMP     (R0)+,R1        ;TEST THE CMP

002016  001002                          BNE     A034            ;BR IF "Z" GOT CLEARED

002020  000000                  E1034:  HALT                    ;CMP FAILED TO ACCESS PSW
002022  000764                          BR      BT034           ;LOCK ON HARD ERROR

002024  005100                  A034:   COM     R0              ;MAKE [R0]=177777
002026  005500                          ADC     R0              ;MAKE [R0]=000000
002030  001402                          BEQ     BT035           ;BR IF "Z" SET

002032  000000                  E2034:  HALT                    ;CMP FAILED TO AUTO INC. R0
002034  000757                          BR      BT034           ;LOCK ON HARD ERROR
```

```
                                ; ***************************************************************
                                        .SBTTL BT035 "CMP  RA,RB" TEST WITH [RA] = [RB]
                                ; ***************************************************************

                                ;MICROPROGRAMMING / LOGIC INFORMATION

                                ;ROM SEQ:       [102,364,362,001] FC 1,8

                                ;ACT BUTS:      37[004]100,102 / 31[102]360,362 / 27[364]000,001

                                ;EXEC:          [364]ALUC=LLHHL :[362]D=000000

                                ;CODES:         [362]SPS=3      /       N:C=0100

                                ;SYNC:          B05J2   (-)     T=1 USEC

                                ;KEY SIG:       K3-3 CMP L / K3-3 SM=0 L / K3-3 DM=0 L / K3-4 OVLAP INSTR H
                                                ; K3-8 CINOO L

002036  012700  125252          BT035:  MOV     #125252,R0      ;MAKE [R0] = 125252
002042  010001                          MOV     R0,R1           ;MAKE [R1] = 125252
002044  000257                          CCC                     ;SCOPE SYNC

002046  020100                  I035:   CMP     R1,R0           ;TEST THE CMP

002050  001402                          BEQ     BT036           ;BR IF "Z" GOT SET

002052  000000                  E035:   HALT                    ;ERROR - CMP FAILED TO SET "Z"
002054  000770                          BR      BT035           ;LOCK ON HARD ERROR
```

```
                                ; ***********************************************************************
                                        .SBTTL BT036 "CMP  RA,RB" TEST WITH [RA] < [RB]
                                ; ***********************************************************************

                                ;MICROPROGRAMMING / LOGIC INFORMATION

                                ;ROM SEQ:       [102,364,362,001] FC 1,8

                                ;ACT BUTS:      37[004]100,102 / 31[102]360,362 / 27[364]000,001

                                ;EXEC:          [364]ALUC=LLHHL :[362]D=152526

                                ;CODES:         [362]SPS=3      /       N:C=1001

                                ;SYNC:          BOSJ2   (-)     T=1 USEC

                                ;KEY SIG:       K3-3 CMP L / K3-3 SM=0 L / K3-3 DM=0 L / K3-4 OVLAP INSTR H
                                                ; K3-8 CINOO L

002056  012700  025252          BT036:  MOV     #25252,R0       ;MAKE [R0] = 25252
002062  005001                          CLR     R1              ;MAKE [R1] = 000000
002064  000264                          SEZ                     ;SCOPE SYNC - SET "Z"

002066  020100                  I036:   CMP     R1,R0           ;TEST THE CMP

002070  001002                          BNE     BT037           ;BR IF "Z" GOT  CLEARED

002072  000000                  E036:   HALT                    ;ERROR - CMP FAILED TO SET "Z"
002074  000770                          BR      BT036           ;LOCK ON HARD ERROR
```

```
                                ; ***************************************************************
                                        .SBTTL BT037 "CMP  RA,RB" TEST WITH [RA] > [RB]
                                ; ***************************************************************

                                ;MICROPROGRAMMING / LOGIC INFORMATION

                                ;ROM SEQ:       [102,364,362,001] FC 1,8

                                ;ACT BUTS:      37[004]100,102 / 31[102]360,362 / 27[364]000,001

                                ;EXEC:          [364]ALUC=LLHHL :[362]D=000017

                                ;CODES:         [362]SPS=3      /       N:C=0000

                                ;SYNC:          B05J2   (-)     T=1 USEC

                                ;KEY SIG:       K3-3 CMP L / K3-3 SM=0 L / K3-3 DM=0 L / K3-4 OVLAP INSTR H
                                                ; K3-8 CINOO L

002076  005000                  BT037:  CLR     R0              ;MAKE [R0] = 000000
002100  012701  000017                  MOV     #17,R1          ;MAKE [R1] = 000017
002104  000264                          SEZ                     ;SCOPE SYNC - SET "Z"

002106  020100                  I037:   CMP     R1,R0           ;TEST THE CMP

002110  001002                          BNE     BT040           ;BR IF "Z" GOT CLEARED

002112  000000                  E037:   HALT                    ;ERROR - CMP FAILED TO SET "Z"
002114  000770                          BR      BT037           ;LOCK ON HARD ERROR
```

```
                                ; ***********************************************************************
                                        .SBTTL BT040 "MOV  (RA),RB" TEST WITH [SOURCE]=[RB]=17
                                ; ***********************************************************************

                                ;MICROPROGRAMMING / LOGIC INFORMATION

                                ;ROM SEQ:       [141,247,250,160,204,000] FC 1,2,4,8

                                ;ACT BUTS:      37[004]100,141 / 35[247]120,160 / 20[160]000,000

                                ;EXEC:          [160]ALUC=LLLLL :[204]D=000017

                                ;CODES:         [204]SPS=3      /       N:C=0001

                                ;SYNC:          B05J2   (-)     T=2.3 USEC

                                ;KEY SIG:       K3-3 MOV L / K3-3 SM=1 L / K3-3 DM=0 L

002116  012700  177776          BT040:  MOV     #PSW,R0         ;R0 POINTS TO PSW
002122  005010                          CLR     (R0)            ;MAKE [PSW]=000
002124  005001                          CLR     R1              ;MAKE [R1]=000000
002126  000277                          SCC                     ;MAKE N:C=1111

002130  011001                  I040:   MOV     (R0),R1         ;TEST THE MOV

002132  020127  000017                  CMP     R1,#17          ;DID R1 GET LOADED WITH 000017 ?
002136  001402                          BEQ     BT041           ;BR IF YES

002140  000000                  E040:   HALT                    ;MOV FAILED TO LOAD R1
002142  000765                          BR      BT040           ;LOCK ON HARD ERROR
```

```
                                ; ***********************************************************************
                                        .SBTTL BT041 "MOV (RA)+,RB" TEST WITH [SOURCE]=[RB]=17
                                ; ***********************************************************************

                                ;MICROPROGRAMMING / LOGIC INFORMATION

                                ;ROM SEQ:       [141,247,250,160,204,000] FC 1,2,4,8

                                ;ACT BUTS:      37[004]100,141 / 35[247]120,160 / 20[160]000,000

                                ;EXEC:          [160]ALUC=LLLLL :[204]D=000017

                                ;CODES:         [204]SPS=3      /       N:C=0001

                                ;SYNC:          B05J2   (-)     T=2.3 USEC

                                ;KEY SIG:       K3-3 MOV L / K3-3 SM=1 L / K3-3 DM=0 L

002144  012700  177776          BT041:  MOV     #PSW,R0         ;R0 POINTS TO PSW
002150  005010                          CLR     (R0)            ;MAKE [PSW]=000
002152  005001                          CLR     R1              ;MAKE [R1]=000000
002154  000277                          SCC                     ;MAKE N:C=1111

002156  012001                  I041:   MOV     (R0)+,R1                ;TEST THE MOV

002160  020127  000017                  CMP     R1,#17          ;DID R1 GET LOADED WITH 000017 ?
002164  001402                          BEQ     A041            ;BR IF YES

002166  000000                  E1041:  HALT                    ;MOV FAILED TO LOAD R1
002170  000765                          BR      BT041           ;LOCK ON HARD ERROR

002172  005100                  A041:   COM     R0              ;[R0] SHOULD GO TO 177777
002174  005500                          ADC     R0              ;[R0] SHOULD GO TO 000000
002176  001402                          BEQ     BT042           ;BR IF "Z" GOT SET

002200  000000                  E2041:  HALT                    ;MOV FAILED TO AUTO INC. R0
002202  000760                          BR      BT041           ;LOCK ON HARD ERROR
```

```
                                ; ***********************************************************************
                                        .SBTTL BT042 "XOR  RA,RB" TEST WITH [RA] = [RB] = 000000
                                ; ***********************************************************************

                                ;MICROPROGRAMMING / LOGIC INFORMATION

                                ;ROM SEQ:       [102,364,360,001] FC 1,7,8

                                ;ACT BUTS:      37[004]100,102 / 31['02]360,360 / 27[364]000,001

                                ;EXEC:          [364]ALUC=HLHHL :[360]D=000000

                                ;CODES:         [360]SPS=3      /       N:C=0100

                                ;SYNC:          BOSJ2   (-)     T=1 USEC

                                ;KEY SIG:       K3-3 DM=0 L / K3-3 IR(08:06)=1 L / K3-5 XOR L / K3-4 OVLAP INSTR H


002204  005000                  BT042:  CLR     R0              ;MAKE [R0] = 000000
002206  005001                          CLR     R1              ;MAKE [R1] = 000000
002210  000257                          CCC                     ;SCOPE SYNC

002212  074100                  I042:   XOR     R1,R0           ;TEST THE XOR

002214  005700                          TST     R0              ;RESULT = 000000 ?
002216  001402                          BEQ     BT043           ;BR IF YES

002220  000000                  E042:   HALT                    ;XOR FAILED
002222  000770                          BR      BT042
```

```
                                ; ***********************************************************************
                                        .SBTTL BT043 "XOR  RA,RB" TEST WITH [RA] = [RB] = 177777
                                ; ***********************************************************************

                                ;MICROPROGRAMMING / LOGIC INFORMATION

                                ;ROM SEQ:       [102,364,360,001] FC 1,7,8

                                ;ACT BUTS:      37[004]100,102 / 31[102]360,360 / 27[364]000,001

                                ;EXEC:          [364]ALUC=HLHHL :[360]D=000000

                                ;CODES:         [360]SPS=3      /       N:C=0100

                                ;SYNC:          BOSJ2   (-)     T=1 USEC

                                ;KEY SIG:       K3-3 DM=0 L / K3-3 IR(08:06)=1 L / K3-5 XOR L / K3-4 OVLAP INSTR H

002224  005000                  BT043:  CLR     R0              ;MAKE [R0] = 177777
002226  005100                          COM     R0
002230  010001                          MOV     R0,R1           ;MAKE [R1] = 177777
002232  000257                          CCC                     ;SCOPE SYNC

002234  074100                  I043:   XOR     R1,R0           ;TEST THE XOR

002236  005700                          TST     R0              ;RESULT = 000000 ?
002240  001402                          BEQ     BT044   ;BR IF YES

002242  000000                  E043:   HALT                    ;XOR FAILED
002244  000767                          BR      BT043           ;LOCK ON HARD ERROR
```

```
                                ; ***********************************************************************
                                        .SBTTL BT044 "XOR  RA,RB" TEST WITH [RB]=052525,[RA]=125252
                                ; ***********************************************************************

                                ;MICROPROGRAMMING / LOGIC INFORMATION

                                ;ROM SEQ:       [102,364,360,001] FC 1,7,8

                                ;ACT BUTS:      37[004]100,102 / 31[102]360,360 / 27[364]000,001

                                ;EXEC:          [364]ALUC=HLHHL :[360]D=177777

                                ;CODES:         [360]SPS=3      /       N:C=1000

                                ;SYNC:          B05J2   (-)     T=1 USEC

                                ;KEY SIG:       K3-3 DM=0 L / K3-3 IR(08:06)=1 L / K3-5 XOR L / K3-4 OVLAP INSTR H

002246  012701  125252          BT044:  MOV     #125252,R1      ;MAKE [R1]=125252
002252  012700  052525                  MOV     #052525,R0      ;MAKE [R0]=052525
002256  000257                          CCC                     ;SCOPE SYNC

002260  074100                  I044:   XOR     R1,R0           ;TEST THE XOR

002262  020027  177777                  CMP     R0,#-1          ;RESULT = 177777 ?
002266  001402                          BEQ     BT045           ;BR IF YES

002270  000000                  E044:   HALT                    ;XOR FAILED
002272  000400                          BR      BT045           ;LOCK ON HARD ERROR
```

```
                                ; ***********************************************************************
                                        .SBTTL BT045 "XOR  RA,RB" TEST WITH [RA]=052525,[RB]=125252
                                ; ***********************************************************************

                                ;MICROPROGRAMMING / LOGIC INFORMATION

                                ;ROM SEQ:       [102,364,360,001] FC 1,7,8

                                ;ACT BUTS:      37[004]100,102 / 31[102]360,360 / 27[364]000,001

                                ;EXEC:          [364]ALUC=HLHHL :[360]D=177777

                                ;CODES:         [360]SPS=3      /       N:C=1000

                                ;SYNC:          B05J2   (-)     T=1 USEC

                                ;KEY SIG:       K3-3 DM=0 L / K3-3 IR(08:06)=1 L / K3-5 XOR L / K3-4 OVLAP INSTR H

002274  012700  125252          BT045:  MOV     #125252,R0      ;MAKE [R0]=125252
002300  012701  052525                  MOV     #052525,R1      ;MAKE [R1]=052525
002304  000257                          CCC                     ;SCOPE SYNC

002306  074100                  IO45:   XOR     R1,R0           ;TEST THE XOR

002310  020027  177777                  CMP     R0,#-1          ;RESULT = 177777 ?
002314  001402                          BEQ     BT046           ;BR IF YES

002316  000000                  EO45:   HALT                    ;XOR FAILED
002320  000765                          BR      BT045           ;LOCK ON HARD ERROR
```

```
                                        ; ***************************************************************
                                                .SBTTL BT046 GPR ADDRESS INTERRACTION TEST
                                        ; ***************************************************************

002322  012700  125252          BT046:  MOV     #125252,R0      ;[R0] = 125252
002326  010001                          MOV     R0,R1
002330  005101                          COM     R1              ;[R1] = 052525
002332  010102                          MOV     R1,R2
002334  005102                          COM     R2              ;[R2] = 125252
002336  010203                          MOV     R2,R3
002340  005103                          COM     R3              ;[R3] = 052525
002342  010304                          MOV     R3,R4
002344  005104                          COM     R4              ;[R4] = 125252
002346  010405                          MOV     R4,R5
002350  005105                          COM     R5              ;[R5] = 052525

002352  074100                  IO46:   XOR     R1,R0           ;[R0] S/B = 177777
002354  074200                          XOR     R2,R0           ;[R0] S/B = 125252
002356  074300                          XOR     R3,R0           ;[R0] S/B = 177777
002360  074400                          XOR     R4,R0           ;[R0]  S/B = 125252
002362  074500                          XOR     R5,R0           ;[R0]  S/B = 177777
002364  005100                          COM     R0              ;[R0] S/B = 000000

002366  001402                          BEQ     A046            ;BR IF [R0] WAS 000000

002370  000000                  E1046:  HALT                    ;GPR ADDRESSING PROBLEM
002372  000753                          BR      BT046           ;LOCK ON HARD ERROR

002374  020627  001000          A046:   CMP     SP,#STACKL      ;DID R6 GET DISTURBED
002400  001577                          BEQ     INIT            ;BR IF NOT

002402  000000                  E2046:  HALT                    ;R6 ADDRESS PROBLEM
002404  000746                          BR      BT046           ;LOCK ON HARD ERROR

        003000                  .=3000
```

```
                                        ;XXXX
```

```
                                ; ***************************************************************
                                        .SBTTL T0002 BASIC "BNE" TEST WITH Z=1
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [110,347,016]FC 1,7

                                ;ACT BUTS:      37[004]100,110 / 16[110]016,016

                                ;EXEC:          NO-OP=[016] D= #I0002

                                ;CODES:         N / A

                                ;SYNC:          B05J2 (-)       /       T= 1.4 USEC

                                ;KEY SIG:       K5-3 BR INSTR L

003054  012700  000002          T0002:  MOV     #0002,R0                ;LOAD R0 WITH TEST NO.
003060  000264                  R0002:  SEZ                             ;SET THE "Z" BIT

003062  001001                  I0002:  BNE     E0002                   ;TEST THE BNE - IT SHOULD NOT BR

003064  000402                          BR      T0003                   ;GO TO NEXT TEST

003066  000000                  E0002:  HALT                            ;BNE BRANCHED WITH Z=1
003070  000773                          BR      R0002                   ;LOCK ON HARD ERROR
```

```
                                ; ***************************************************************
                                        .SBTTL T0003 BASIC "BEQ" TEST WITH Z=1
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [111,340,341,016] FC 1,7

                                ;ACT BUTS:      37[004]100,111 / 16[340]16,16

                                ;EXEC:          [341]ALUC=LHLLH :[016]D=#T0004

                                ;CODES:         N / A

                                ;SYNC:          B05J2 (-)       /       T= 1.8 USEC

                                ;KEY SIG:       K5-3 FALSE BRL  /  K5-3 BR INSTRL

003072  012700  000003          T0003:  MOV     #0003,R0                ;LOAD R0 WITH THE TEST NO.
003076  000264                  R0003:  SEZ                             ;MAKE Z=1

003100  001402                  I0003:  BEQ     T0004                   ;TEST THE BEQ - IT SHOULD BR

003102  000000                  E0003:  HALT                            ;BEQ FAILED TO LOAD THE PC
003104  000774                          BR      R0003                   ;LOCK ON HARD ERROR
```

F09


```
                                ; ***************************************************************
                                        .SBTTL T0004 BASIC "BEQ" TEST WITH Z=0
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [110,347,016] FC 1,7

                                ;ACT BUTS:      37[004]100,110 / 16[110]016,016

                                ;EXEC:          NO-OP=[016] D= #I0004

                                ;CODES:         N / A

                                ;SYNC:          B05J2 (-)       /       T= 1.4 USEC

                                ;KEY SIG:       K5-3 BR INSTR L

003106  012700  000004          T0004:  MOV     #0004,R0        ;LOAD R0 WITH THE TEST NO.
003112  000257                  R0004:  CCC                     ;MAKE Z=0

003114  001401                  I0004:  BEQ     E0004           ;TEST THE BEQ - IT SHOULD NOT BR

003116  000402                          BR      T0005           ;GO TO NEXT TEST

003120  000000                  E0004:  HALT                    ;BEQ BRANCHED WITH Z=0
003122  000773                          BR      R0004           ;LOCK ON HARD ERROR
```

```
                                ; ***************************************************************
                                        .SBTTL T0005 BASIC "BPL" TEST WITH N=1
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [110,347,016] FC 1,7

                                ;ACT BUTS:      37[004]100,110 / 16[110]16,16

                                ;EXEC:          NO-OP=[016] D=#I0005

                                ;CODES:         N / A

                                ;SYNC:          B05J2 (-)       /       T= 1.4 USEC

                                ;KEY SIG:       K5-3 BR INSTR L

003124  012700  000005          T0005:  MOV     #0005,R0                ;LOAD R0 WITH TEST NO.
003130  005037  177776          R0005:  CLR     @#PSW           ;CLEAR THE PSW
003134  000270                          SEN                     ;MAKE N=1

003136  100001                  I0005:  BPL     E0005           ;TEST THE BPL - IT SHOULDN'T BR

003140  000402                          BR      T0006           ;GO TO NEXT TEST

003142  000000                  E0005:  HALT                    ;BPL BRANCHED WITH N=1
003144  000771                          BR      R0005           ;LOCK ON HARD ERROR
```

```
                                ; ***************************************************************
                                        .SBTTL T0006 BASIC "BPL" TEST WITH N=0
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [111,340,341,016] FC 1,7

                                ;ACT BUTS:      37[004]100,111 / 16[340]16,16

                                ;EXEC:          [341]ALUC LHLLH :[016]D=#T0007

                                ;CODES:         N / A

                                ;SYNC:          BOSJ2 (-)       /       T= 1.8 USEC

                                ;KEY SIG:       K5-3 BR INSTR L  /  K5-3 FALSE BR L

003146  012700  000006          T0006:  MOV     #0006,R0        ;LOAD R0 WITH TEST NO.
003152  005037  177776          R0006:  CLR     @#PSW           ;CLEAR THE PSW
003156  000257                          CCC                     ;SCOPE SYNC

003160  100002                  I0006:  BPL     T0007           ;TEST THE BPL - IT SHOULD BR

003162  000000                  E0006:  HALT                    ;BPL FAILED TO LOAD THE PC
003164  000772                          BR      R0006           ;LOCK ON HARD ERROR
```

```
                                ; ***********************************************************************
                                        .SBTTL T0007 BASIC "MOV  (RA),RB" TEST - (RA)=177776
                                ; ***********************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [141,247,250,160,204,000] FC 1,2,4,8

                                ;ACT BUTS:      37[004]100,141  /  35[247]120,160  /  20[160]000,000

                                ;EXEC:          [160]ALUC=LLLLL :[204]D=000017

                                ;CODES:         [204]SPS=3       /      N:C=0000

                                ;SYNC:          B05J2   (-)     T=2.25 USEC

                                ;KEY SIG:       K3-3 MOV L  /  K3-3 SM=1 L  /  K3-3 DM=0 L

003166  012700  000007          T0007:  MOV     #0007,R0                ;LOAD R0 WITH TEST NO.
003172  012702  177703                  MOV     #177703,R2      ;DEST ADDR = R3
003176  012705  177776                  MOV     #PSW,R5         ;SOURCE ADDR = 177776
003202  012704  000017                  MOV     #17,R4          ;RESULT S / B=000017
003206  005015                  R0007:  CLR     (R5)            ;MAKE [PSW]=000
003210  005003                          CLR     R3              ;[DEST] = 000000
003212  000277                          SCC                     ;MAKE [PSW]=017

003214  011503                  I0007:  MOV     (R5),R3         ;TEST THE MOV

003216  020403                          CMP     R4,R3           ;CORRECT RESULT ?
003220  001402                          BEQ     T0010           ;BR IF YES

003222  000000                  E0007:  HALT                    ;ERROR-MOV FAILED
003224  000770                          BR      R0007           ;LOCK ON HARD ERROR
```

```
                                        ; ***************************************************************
                                                .SBTTL T0010 BASIC "CMP  RA,(RB)" TEST - [RA] = [DEST]
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [161,266,267,224,367,375,016] FC 1,3,8

                                        ;ACT BUTS:      37[004]100,161  /  33[266]220,224  /  16[367]016,016

                                        ;EXEC:          [224]ALUC=LLHHL :[367]D=000000

                                        ;CODES:         [367]SPS=3       /      N:C=0100

                                        ;SYNC:          B05J2   (-)     T=2.6 USEC

                                        ;KEY SIG:       K3-3 CMP L  /  K3-3 SM=0 L  /  K3-3 DM=1 L  /  K4-4 ALLOW CLK L
                                                        ;  K3-8 CINOO L

003226  012700  000010          T0010:  MOV     #0010,R0                ;LOAD R0 WITH TEST NO.
003232  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
003236  012704  125252                  MOV     #125252,R4      ;RESULT S / B = 125252
003242  012737  125252  067602  R0010:  MOV     #125252,@#MBUF0 ;MAKE [DEST] = 125252
003250  000257                          CCC                     ;MAKE N:C=0000

003252  020412                  I0010:  CMP     R4,(R2)         ;TEST THE CMP

003254  001403                          BEQ     T0011           ;BR IF "Z" GOT SET

003256  011203                          MOV     (R2),R3         ;GET THE WAS DATA
003260  000000                  E0010:  HALT                    ;ERROR - CMP FAILED TO SET "Z"
003262  000767                          BR      R0010           ;LOCK ON HARD ERROR
```

```
                                ; ***************************************************************
                                        .SBTTL T0011 BASIC "CMP  RA,(RB)" TEST - [RA] NOT EQUAL TO  [DEST]
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [161,266,267,224,367,375,016] FC 1,3,8

                                ;ACT BUTS:      37[004]100,161  /  33[266]220,224  /  16[367]016,016

                                ;EXEC:          [224]ALUC=LLHHL :[367]D=177777

                                ;CODES:         [367]SPS=3       /      N:C=1001

                                ;SYNC:          B05J2   (-)     T=2.6 USEC

                                ;KEY SIG:       K3-3 CMP L  /  K3-3 SM=0 L  /  K3-3 DM=1 L  /  K4-4 ALLOW CLK L
                                                ;  K3-8 CINOD L


003264  012700  000011          T0011:  MOV     #0011,R0                ;LOAD R0 WITH TEST NO.
003270  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
003274  012704  000001                  MOV     #1,R4           ;RESULT S / B = 000001
003300  012737  000000  067602  R0011:  MOV     #0,@#MBUF0      ;MAKE [DEST] = 000000
003306  000264                          SEZ                     ;MAKE N:C=0100

003310  020412                  I0011:  CMP     R4,(R2)         ;TEST THE CMP

003312  001003                          BNE     T0012           ;BR IF "Z" GOT CLEARED

003314  011203                          MOV     (R2),R3         ;GET THE WAS DATA
003316  000000                  E0011:  HALT                    ;ERROR - CMP FAILED TO CLR "Z"
003320  000767                          BR      R0011           ;LOCK ON HARD ERROR
```

```
                                ; ***************************************************************
                                        .SBTTL T0012 BASIC "CMP #N,R" TEST - N = [R]
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [142,240,250,120,371,362,000] FC 1,2,8

                                ;ACT BUTS:      37[004]100,142 / 35[240]120,120 / 27[371]000,000

                                ;EXEC:          [371]ALUC=LLHHL :[362]D=125252

                                ;CODES:         [362] SPS=3  /  N:C=

                                ;SYNC:          B05J2 (-)       /       T= 2.5 USEC

                                ;KEY SIG:       K3-3 CMPL  /  K3-3 DM=DL  /  K3-6 BYTE INSTR H

003322  012700  000012          T0012:  MOV     #0012,R0                ;LOAD R0 WITH TEST NO.
003326  012704  125252                  MOV     #125252,R4      ;RESULT S / B = 125252
003332  012702  177703                  MOV     #177703,R2      ;DEST ADDR = R3
003336  010403                  R0012:  MOV     R4,R3           ;[DEST] = 125252
003340  000257                          CCC                     ;SCOPE SYNC

003342  022703  125252          I0012:  CMP     #125252,R3      ;TEST THE CMP

003346  001402                          BEQ     A0012           ;BR IF N = [R]

003350  000000                  E10012: HALT                    ;CMP FAILED
003352  000771                          BR      R0012           ;LOCK ON HARD ERROR

003354  020403                  A0012:  CMP     R4,R3           ;DID CMP ALTER [DEST]?
003356  001402                          BEQ     T0013           ;BR IF NO

003360  000000                  E20012: HALT                    ;CMP DELIVERED A RESULT
003362  000765                          BR      R0012           ;LOCK ON HARD ERROR
```

```
                                ; ***************************************************************
                                        .SBTTL T0013 BASIC "CMP #N,R" TEST - N NOT EQUAL TO [R]
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [142,240,250,120,371,362,000] FC 1,2,8

                                ;ACT BUTS:      37[004]100,142 / 35[240]120,120 / 27[371]000,000

                                ;EXEC:          [371]ALUC=LLHHL :[362]D=177777

                                ;CODES:         [362] SPS=3  /  N:C=1001

                                ;SYNC:          B05J2 (-)       T=2.5 USEC

                                ;KEY SIG:       K3-3 CMPL  /  K3-3 DM=OL  /  K3-6 BYTE INSTR H  /  K3-8 CINCO L

003364  012700  000013         T0013:  MOV     #0013,R0                ;LOAD R0 WITH TEST NO.
003370  005004                         CLR     R4              ;RESULT S / B = 000000
003372  012702  177703                 MOV     #177703,R2      ;DEST ADDR = R3
003376  010403                 R0013:  MOV     R4,R3           ;[DEST] = 125252
003400  000264                         SEZ                     ;SCOPE SYNC

003402  022703  000001         I0013:  CMP     #1,R3           ;TEST THE CMP

003406  001002                         BNE     A0013           ;BR IF N NOT EQUAL TO [R]

003410  000000                 E10013: HALT                    ;CMP FAILED
003412  000771                         BR      R0013           ;LOCK ON HARD ERROR

003414  020403                 A0013:  CMP     R4,R3           ;DID CMP ALTER [DEST]?
003416  001402                         BEQ     T0014           ;BR IF NO

003420  000000                 E20013: HALT                    ;CMP DELIVERED A RESULT
003422  000765                         BR      R0013           ;LOCK ON HARD ERROR
```

```
                                ; ***********************************************************************
                                        .SBTTL T0014 BASIC "MOV  RA,(RB)" TEST
                                ; ***********************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [171,257,201,125,375,016] FC 1,4,8

                                ;ACT BUTS:      37[004]100,171  /  22[171]200,201  /  16[125]016,016

                                ;EXEC:          [201]ALUC=LLLLL :[125]D=177777

                                ;CODES:         [125]SPS=3       /      N:C=1000

                                ;SYNC:          B05J2   (-)     T=2.42 USEC

                                ;KEY SIG:       K3-3 MOV L  /  K3-3 SM=0 L  /  K3-3 DM=1 L

003424  012700  000014          T0014:  MOV     #0014,R0                ;LOAD R0 WITH TEST NO.
003430  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR=MBUF0
003434  012704  177777                  MOV     #-1,R4          ;RESULT S / B = 177777
003440  005012                  R0014:  CLR     (R2)            ;MAKE [DEST] = 000000
003442  000257                          CCC                     ;SCOPE SYNC - N:C=0000

003444  010412                  I0014:  MOV     R4,(R2)         ;TEST THE MOV

003446  020412                          CMP     R4,(R2)         ;RESULT CORRECT ?
003450  001403                          BEQ     T0015           ;BR IF  YES

003452  011203                          MOV     (R2),R3         ;GET THE WAS DATA
003454  000000                  E0014:  HALT                    ;ERROR - MOV FAILED
003456  000770                          BR      R0014           ;LOCK ON HARD ERROR
```

```
                                        ; ***********************************************************************
                                                .SBTTL T0015 BASIC "MOV  #N,(R)" TEST
                                        ; ***********************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ        [142,240,250,171,257,200,125,375,016] FC 1,2,4,8

                                        ;ACT BUTS:      37[004]100,142  /  35[240]120,171  /  22[171]200,200  /  16[125]016,016

                                        ;EXEC:          [200]ALUC=LLLLL :[125]D=177777

                                        ;CODES:         [125]SPS=3       /      N:C=1000

                                        ;SYNC:          BOSJ2   (-)     T=3.26 USEC

                                        ;KEY SIG:       K3-3 MOV L  /  K3-3 SM=2 L  /  K3-3 DM=1 L  /  K5-5 BCON(1+2) H

003460  012700  000015                  T0015:  MOV     #0015,R0                ;LOAD R0 WITH TEST NO.
003464  012702  067602                          MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
003470  012704  177777                          MOV     #-1,R4          ;RESULT S / B = 177777
003474  005012                          R0015:  CLR     (R2)            ;MAKE [DEST] = 000000
003476  000257                                  CCC                     ;SCOPE SYNC

003500  012712  177777                  I0015:  MOV     #-1,(R2)        ;TEST THE MOV

003504  020412                                  CMP     R4,(R2)         ;RESULT OK ?
003506  001403                                  BEQ     T0016           ;BR IF YES

003510  011203                                  MOV     (R2),R3 ;GET THE WAS DATA
003512  000000                          E0015:  HALT                    ;ERROR - MOV FAILED
003514  000767                                  BR      R0015           ;LOCK ON HARD ERROR
```

```
                                        ; ***********************************************************************
                                                .SBTTL T0016 BASIC "MOVB #N,X(R)" TEST - DEST EVEN
                                        ; ***********************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [142,240,250,177,206,212,202,205,125,375,016] FC 1,2,4

                                        ;ACT BUTS:      37[004]100,142 / 35[240]120,177 / 17[177]212,212 / 21[206]200,202
                                                        ; / 16[125]016,016

                                        ;EXEC:          [205]ALUC=LLLLL :[125]D=001001

                                        ;CODES:         [125] SPS=3  /  N:C=0000

                                        ;SYNC:          B05J2 (-)       /       T= 4.2 USEC

                                        ;KEY SIG:       K3-3 MOVL  /  K3-3 DM=6L  /  K3-5 DGPL  /  K3-6 BYTE INSTR H

003516  012700  000016          T0016:  MOV     #0016,R0                ;LOAD R0 WITH TEST NO.
003522  012704  177401                  MOV     #177401,R4      ;RESULT S / B = 177401
003526  012702  067606                  MOV     #MBUF1,R2       ;DEST ADDR = MBUF1
003532  012705  067602                  MOV     #MBUF0,R5       ;BASE DEST ADDR = MBUF0
003536  012712  177777          R0016:  MOV     #-1,(R2)        ;[DEST] = 177777
003542  000257                          CCC                     ;SCOPE SYNC

003544  112765  000001  000004  I0016:  MOVB    #1,4(R5)        ;TEST THE MOVB

003552  020412                          CMP     R4,(R2)         ;RESULT OK?
003554  001403                          BEQ     T0017           ;BR IF YES

003556  011203                          MOV     (R2),R3         ;GET WAS DATA
003560  000000                  E0016:  HALT                    ;MOVB DELIVERED WRONG RESULT
003562  000765                          BR      R0016           ;LOCK ON HARD ERROR
```

```
                                ; ***********************************************************************
                                        .SBTTL T0017 BASIC "MOVB #N,X(R)" TEST -.DEST ODD
                                ; ***********************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [142,240,250,177,206,212,202,205,125,375,016] FC 1,2,4

                                ;ACT BLTS:      37[004]100,142 / 35[240]120,177 / 17[177]212,212 / 21[206]200,202
                                                ; / 16[125]016,016

                                ;EXEC:          [205]ALUC=LLLLL :[125]D=001001

                                ;CODES:         [125] SPS=3  /  N:C=0000

                                ;SYNC:          BOSJ2 (-)       /       T= 4.2 USEC

                                ;KEY SIG:       K3-3 MOVL  /  K3-3 DM=6L  /  K3-5 DOPL  /  K3-6 BYTE INSTR H

003564  012700  000017          T0017:  MOV     #0017,R0                ;LOAD R0 WITH TEST NO.
003570  012704  000777                  MOV     #777,R4         ;RESULT S / B = 777
003574  012702  067606                  MOV     #MBUF1,R2       ;DEST ADDR = MBUF1
003600  012705  067602                  MOV     #MBUF0,R5       ;BASE DEST ADDR = MBUF0
003604  012712  177777          R0017:  MOV     #-1,(R2)        ;[DEST] = 177777
003610  000257                          CCC                     ;SCOPE SYNC

003612  112765  000001  000005  I0017:  MOVB    #1,5(R5)        ;TEST THE MOVB

003620  020412                          CMP     R4,(R2)         ;RESULT OK?
003622  001403                          BEQ     CLMT            ;BR IF YES

003624  011203                          MOV     (R2),R3         ;GET WAS DATA
003626  000000                  E0017:  HALT                    ;MOVB DELIVERED WRONG RESULT
003630  000765                          BR      R0017           ;LOCK ON HARD ERROR

                                ;THIS ROUTINE CLEARS THE 512 BYTE MISSED TEST STATUS TABLE

003632  012701  070162          CLMT:   MOV     #STAB1,R1       ;R1 POINTS TO BEGINNING OF TABLE
003636  012702  071204                  MOV     #STAB2,R2       ;R2 POINTS TO END OF TABLE
003642  012721  000000          MT:     MOV     #0,(R1)+        ;CLEAR ONE WORD
003646  020102                          CMP     R1,R2           ;AT END OF TABLE ?
003650  001374                          BNE     MT              ;BR IF NOT AT END
```

```
                                        ; ***************************************************************
                                                .SBTTL T0020 BASIC "TST  @#A" TEST WITH [A]>0
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [163,264,265,266,267,220,211,367,376,016] FC 1,3,9,8

                                        ;ACT BUTS:      37[004]100,163 / 33[266]220,220 / 16[367]016,016

                                        ;EXEC:          [220]ALUC LLLLL :[211]D=377

                                        ;CODES:         [367]SPS=3  /  N:C=0000

                                        ;SYNC:          BOSJ2 (-)       /       T= 2.8 USEC

                                        ;KEY SIG:       K3-4 TSTL  /  K3-3 DM=3L

003652  012700  000020          T0020:  MOV     #0020,R0                ;LOAD R0 WITH TEST NO.
003656  112760  000377  070162          MOVB    #377,STAB1(R0)  ;SET FLAG FOR THIS TEST IN MISSED TABLE
003664  012703  066704                  MOV     #FIRST,R3       ;R3 POINTS TO LOCATION THAT STORES NO OF FIRST TEST
003670  010013                          MOV     R0,(R3)         ;SAVE FIRST TEST NO. CHECKED
003672  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
003676  012704  000377                  MOV     #377,R4         ;RESULT S / B = 377 (NO CHANGE)
003702  010412                  R0020:  MOV     R4,(R2)         ;[DEST] = 377
003704  000257                          CCC                     ;SCOPE SYNC

003706  005737  067602          I0020:  TST     @#MBUF0         ;TEST THE TST

003712  001401                          BEQ     E0020           ;BR IF "Z" SET - IT SHOULDN'T BE
003714  100002                          BPL     T0021           ;BR IF "N" CLEAR - IT SHOULD BE

003716  000000                  E0020:  HALT                    ;TST FAILED TO ALTER CODES PROPERLY
003720  000770                          BR      R0020           ;LOCK ON HARD ERROR
```

```
                                        ; ****************************************************************
                                                .SBTTL T0021 BASIC "TST @#A" TEST WITH [A] < 0
                                        ; ****************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [163,264,265,266,267,220,211,367,375,016] FC 1,3,9,8

                                        ;ACT BUTS:      37[004]100,163  /  33[266]220,220  /  16[367]016,016

                                        ;EXEC:          [220]ALUC=LLLLL :[211]D=100000

                                        ;CODES:         [367]SP=3  /  N:C=1000

                                        ;SYNC:          B05J2 (-)       /       T= 2.8 USEC

                                        ;KEY SIG:       K3-4 TSTL  /  K3-3 DM=3L  /  K5-2 PS(N)(1)H

003722  012700  000021                  T0021:  MOV     #0021,R0                ;LOAD R0 WITH TEST NO.
003726  112760  000377  070162                  MOVB    #377,STAB1(R0)  ;SET FLAG FOR THIS TEST IN MISSED TABLE
003734  012702  067602                          MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
003740  012704  100000                          MOV     #100000,R4      ;MAKE S / B = 100000
003744  010412                          R0021:  MOV     R4,(R2)         ;MAKE [DEST] = 100000
003746  000257                                  CCC                     ;SCOPE SYNC

003750  005737  067602                  I0021:  TST     @#MBUF0         ;TEST THE TST

003754  001401                                  BEQ     E10021          ;BR IF "Z" SET - IT SHOULDN'T BE
003756  100402                                  BMI     A0021           ;BR IF "N" SET - IT SHOULD BE

003760  000000                          E10021: HALT                    ;TST FAILED TO ALTER CODES PROPERLY
003762  000770                                  BR      R0021           ;LOCK ON HARD ERROR
003764  020412                          A0021:  CMP     R4,(R2)         ;DID TST DISTURB [DEST] ?
003766  001403                                  BEQ     T0022           ;BR IF NOT

003770  011203                                  MOV     (R2),R3         ;GET THE WAS DATA
003772  000000                          E20021: HALT                    ;TST DELIVERED A RESULT
003774  000763                                  BR      R0021           ;LOCK ON HARD ERROR
```

```
                                        ; ****************************************************************
                                                .SBTTL T0022 BASIC "TST  @#A" WITH [A] = 0
                                        ; ****************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [163,264,265,266,267,220,211,367,375,016] FC 1,3,9,8

                                        ;ACT BUTS:      37[004]100,163 / 33[266]220,220 / 16[367]016,016

                                        ;EXEC:          [220]ALUC=LLLLL :[211]D=000000

                                        ;CODES:         [367]SPS=3  /  N:C=0100

                                        ;SYNC:          B05J2 (-)       /       T=2.8 USEC

                                        ;KEY SIG:       K3-4 TSTL  /  K3-3 DM=3L  /  K5-2 PS(Z)(1)H

003776  012700  000022                  T0022:  MOV     #0022,R0                ;LOAD R0 WITH TEST NO.
004002  112760  000377  070162                  MOVB    #377,STAB1(R0)  ;SET FLAG FOR THIS TEST IN MISSED TABLE
004010  012702  067602                          MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
004014  005004                                  CLR     R4              ;RESULT S / B = 0 (IT SHOULDN'T CHANGE
004016  005012                          R0022:  CLR     (R2)            ;[DEST] = 0
004020  000257                                  CCC                     ;SCOPE SYNC - Z=0

004022  005737  067602                  I0022:  TST     @#MBUF0         ;TEST THE TST

004026  001402                                  BEQ     A0022           ;BR IF TST SET "Z"

004030  000000                          E10022: HALT                    ;TST FAILED TO SET "Z"
004032  000771                                  BR      R0022           ;LOCK ON HARD ERROR

004034  020412                          A0022:  CMP     R4,(R2)         ;[DEST] STILL = 000000
004036  001403                                  BEQ     T0023           ;BR IF YES

004040  011203                                  MOV     (R2),R3         ;GET THE WAS DATA
004042  000000                          E20022: HALT                    ;TST ALTERED THE [DEST]
004044  000764                                  BR      R0022           ;LOCK ON HARD ERROR
```

```
                                ; ***************************************************************
                                        .SBTTL T0023 BASIC "TST  (R)+" TEST
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [162,260,267,220,211,367,375,016] FC 1,3,8,9

                                ;ACT BUTS:      37[004]100,162 / 33[260]220,220 / 16[367]016,016

                                ;EXEC:          [220]ALUC=LLLLL :[211]D=000000

                                ;CODES:         [367] SPS=3  /  N:C=0100

                                ;SYNC:          B05J2 (-)       /       T= 1.84 USEC

                                ;KEY SIG:       K3-4 TSTL  /  K3-3 DM=2L  /  K5-2 PS(Z)(1)H

004046  012700  000023          T0023:  MOV     #0023,R0                ;LOAD R0 WITH TEST NO.
004052  112760  000377  070162          MOVB    #377,STA81(R0)  ;SET FLAG FOR THIS TEST IN MISSED TABLE
004060  012702  067602                  MOV     #MBUF0,R2       ;INITIAL DEST ADDR = MBUF0
004064  005004                          CLR     R4              ;RESULT S / B = 0 (NO CHANGE)
004066  005012                  R0023:  CLR     (R2)            ;MAKE [DEST] = 000000
004070  000257                          CCC                     ;SCOPE SYNC

004072  005722                  I0023:  TST     (R2)+           ;TEST THE TST

004074  001402                          BEQ     A0023           ;BR IF "Z" SET - IT SHOULD BE

004076  000000                  E10023: HALT                    ;TST FAILED TO SET "Z"
004100  000772                          BR      R0023           ;LOCK ON HARD ERROR

004102  022702  067604          A0023:  CMP     #MBUF0+2,R2     ;DID REG. GET AUTO-INCREMENTED ?
004106  001402                          BEQ     T0024           ;BR IF YES

004110  000000                  E20023: HALT                    ;TST FAILED TO UPDATE REGISTER
004112  000765                          BR      R0023           ;LOCK ON HARD ERROR
```

```
                                        ; ***********************************************************************
                                                .SBTTL T0024 BASIC "TST -(R)" TEST
                                        ; ***********************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [164,260,267,220,211,367,375,016]

                                        ;ACT BUTS:      37[004]100,164 / 33[260]220,220 / 16[367]016,016

                                        ;EXEC:          [220]ALUC=LLLLL :[211]D=125252

                                        ;CODES:         [367] SPS=3  /  N:C=0000

                                        ;SYNC:          B05J2 (-)       /       T= 1.84 USEC

                                        ;KEY SIG:       K3-4 TSTL  /  K3-3 DM=4

004114  012700  000024          T0024:  MOV     #0024,R0                ;LOAD R0 WITH TEST NO.
004120  112760  000377  070162          MOVB    #377,STAB1(R0)  ;SET FLAG FOR THIS TEST IN MISSED TABLE
004126  012702  067620                  MOV     #DWTA+6,R2      ;DEST ADDR = DWTA+6
004132  012704  000377                  MOV     #377,R4         ;RESULT S / B = 377
004136  012705  067622          R0024:  MOV     #DWTA+10,R5     ;BASE DEST ADDR = DWTA+10
004142  000270                          SEN                     ;SCOPE SYNC

004144  005745                  I0024:  TST     -(R5)           ;TEST THE TST

004146  100002                          BPL     A0024           ;BR IF "N" CLEAR

004150  000000                  E10024: HALT                    ;TST FAILED TO CLEAR "N"
004152  000771                          BR      R0024           ;LOCK ON HARD ERROR

004154  020502                  A0024:  CMP     R5,R2           ;DID DEST REG GET DECREMENTED?
004156  001402                          BEQ     B0024           ;BR IF YES

004160  000000                  E20024: HALT                    ;ERROR - TST FAILED TO UPDATE DEST REG
004162  000765                          BR      R0024           ;LOCK ON HARD ERROR

004164  020412                  B0024:  CMP     R4,(R2)         ;DID TST ALTER [DEST]?
004166  001404                          BEQ     T0025           ;BR IF NOT

004170  011203                          MOV     (R2),R3         ;GET WAS DATA
004172  000000                  E30024: HALT                    ;TST ALTERED [DEST]
004174  010412                          MOV     R4,(R2)         ;RESTORE [DEST]
004176  000757                          BR      R0024           ;LOCK ON HARD ERROR
```

```
                                        ; ***************************************************************
                                                .SBTTL T0025 BASIC "COM  @#A" TEST
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [163,264,265,266,267,220,211,267,375,016] FC 1,3,9,8

                                        ;ACT BUS:       37[004]100,163  /  33[266]220,220  /  16 [367]016,016

                                        ;EXEC:          [220]ALUC=HLLLL :[211]D=177777

                                        ;CODES:         [367] SPS=3  /  N:C=1001

                                        ;SYNC:          B05J2 (-)       /       T= 2.8 USEC

                                        ;KEY SIG:       K3-4 COM L  /  K3-3 DM=3L  /  K5-2 PS(N)(1)H  /  K5-2 PS(C)(1)H

004200  012700  000025          T0025:  MOV     #0025,R0                ;LOAD R0 WITH TEST NO.
004204  112760  000377  070162          MOVB    #377,STAB1(R0)  ;SET FLAG FOR THIS TEST IN MISSED TABLE
004212  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
004216  005004                          CLR     R4              ;RESULT S / B = 177777
004220  005104                          COM     R4
004222  005012                  R0025:  CLR     (R2)            ;MAKE [DEST] = 000000
004224  000257                          CCC                     ;SCOPE SYNC

004226  005137  067602          I0025:  COM     @#MBUF0 ;TEST THE COM

004232  020412                          CMP     R4,(R2)         ;RESULT = 177777 ??
004234  001403                          BEQ     T0026           ;BR IF YES

004236  011203                  E0025:  MOV     (R2),R3         ;GET THE WAS DATA
004240  000000                          HALT                    ;COM DELIVERED THE WRONG RESULT
004242  000767                          BR      R0025
```

```
                                ; ***************************************************************
                                        .SBTTL T0026 BASIC "INC @#A" TEST
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [163,264,265,266,267,220,211,367,375,016] FC 1,3,9,8

                                ;ACT BUTS:      37[004]100,163 / 33[266]220,220 / 16[367]016,016

                                ;EXEC:          [220]ALUC=LLLLL :[211]D=100

                                ;CODES:         [367] SPS=3  /  N:C=0000

                                ;SYNC:          BOSJ2 (-)       /       T= 2.8 USEC

                                ;KEY SIG:       K3-4 INC L  /  K3-3 DM=3L  /  K3-8 CIN 00 L

004244  012700  000026          T0026:  MOV     #0026,R0                ;LOAD R0 WITH TEST NO.
004250  112760  000377  070162          MOVB    #377,STAB1(R0)  ;SET FLAG FOR THIS TEST IN MISSED TABLE
004256  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
004262  012704  000100                  MOV     #100,R4         ;RESULT S / B = 100
004266  012712  000077          R0026:  MOV     #77,(R2)        ;[DEST] = 77
004272  000257                          CCC                     ;SCOPE SYNC

004274  005237  067602          I0026:  INC     @#MBUF0         ;TEST THE INC

004300  020412                          CMP     R4,(R2)         ;DID RESULT = 100 ??
004302  001403                          BEQ     T0027           ;BR IF YES

004304  011203                          MOV     (R2),R3         ;GET THE WAS DATA
004306  000000          E0026:  HALT                            ;INC DELIVERED WRONG RESULT
004310  000766                          BR      R0026           ;LOCK ON HARD ERROR
```

```
                                        ; ***************************************************************
                                                .SBTTL T0027 BASIC "DEC  RN" TEST
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [104,373,360,001] FC 1,7,8

                                        ;ACT BUTS:      37[004]100,104 / 31[104]360,360 / 27[373]000,001

                                        ;EXEC:          [104]ALUC=LHHHH :[373]D=000000

                                        ;CODES:         [367] SPS=3  /  N:C=0100

                                        ;SYNC:          B05J2 (-)       /       T= 1 USEC

                                        ;KEY SIG:       K3-4 DEC L  /  K3-4 OVLAP INSTR H  /  K3-3 DM=0L  /  K5-2 PS(Z)(1)H

004312  012700  000027          T0027:  MOV     #0027,R0                ;LOAD R0 WITH TEST NO.
004316  112760  000377  070162          MOVB    #377,STAB1(R0)  ;SET FLAG FOR THIS TEST IN MISSED TABLE
004324  012702  177703                  MOV     #177703,R2      ;DEST ADDR = R3
004330  005004                          CLR     R4              ;RESULT S / B = 000000
004332  012703  000001          R0027:  MOV     #1,R3           ;[DEST0030
004336  000257                          CCC                     ;SCOPE SYNC

004340  005303                  I0027:  DEC     R3              ;TEST THE DEC

004342  005703                          TST     R3              ;RESULT = 000000 ??
004344  001402                          BEQ     T0030           ;BR IF YES

004346  000000                  E0027:  HALT                    ;DEC DELIVERED THE WRONG RESULT
004350  000770                          BR      R0027           ;LOCK ON HARD ERROR
```

```
                                        ; ***************************************************************
                                                .SBTTL T0030 BASIC "DEC @#A" TEST
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [163,264,265,266,267,220,211,367,375,016] FC 1,3,9,8

                                        ;ACT BUTS:      37[004]100,163 / 33[266]220,220 / 16[367]016,016

                                        ;EXEC:          [220]ALUC=LHHHH :[211]D=177777

                                        ;CODES:         [367] SPS=3  /  N:C=1000

                                        ;SYNC:          B05J2 (-)       /       T=2.8 USEC

                                        ;KEY SIG:       K3-4 DEC L  /  K3-3 DM=3L  /  K5-2 PS(N)(1)H

004352  012700  000030          T0030:  MOV     #0030,R0                ;LOAD R0 WITH TEST NO.
004356  112760  000377  070162          MOVB    #377,STAB1(R0)  ;SET FLAG FOR THIS TEST IN MISSED TABLE
004364  012704  177777                  MOV     #-1,R4          ;RESULT S / B = 177777
004370  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
004374  005012                  R0030:  CLR     (R2)            ;MAKE [DEST] = 000000
004376  000257                          CCC                     ;SCOPE SYNC

004400  005337  067602          I0030:  DEC     @#MBUF0         ;TEST THE DEC

004404  020412                          CMP     R4,(R2)         ;DID RESULT = 177777 ??
004406  001403                          BEQ     T0031           ;BR IF YES

004410  011203                          MOV     (R2),R3         ;[R3] = WAS DATA
004412  000000                  E0030:  HALT                    ;DEC DELIVERED WRONG RESULT
004414  000767                          BR      R0030           ;LOCK ON HARD ERROR
```

```
                                ; ***********************************************************************
                                        .SBTTL T0031 BASIC "CLR X(R)" TESTS
                                ; ***********************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [167,261,262,266,267,220,211,367,375,016] FC 1,3,9,8

                                ;ACT BUTS:      37[004]100,167 / 17[167]262,262 / 33[266]220,220 / 16[367]016,016

                                ;EXEC:          [220]ALUC HLLHH :[211]D=000000

                                ;CODES:         [367] SPS=3  /  N:C=0100

                                ;SYNC:          B05J2 (-)       /       T= 2.5 USEC

                                ;KEY SIG:       K3-3 DM=6L  /  K3-4 CLRL

004416  012700  000031          T0031:  MOV     #0031,R0                ;LOAD R0 WITH TEST NO.
004422  112760  000377  070162          MOVB    #377,STAB1(R0)  ;SET FLAG FOR THIS TEST IN MISSED TABLE
004430  012702  067604                  MOV     #MBUF0+2,R2     ;DEST ADDR = MBUF0+2
004434  005004                          CLR     R4              ;RESULT S / B = 000000
004436  012705  067602          R0031:  MOV     #MBUF0,R5       ;BASE DEST ADDR = MBUF0
004442  012712  177777                  MOV     #-1,(R2)        ;[DEST] = 177777
004446  000257                          CCC                     ;SCOPE SYNC

004450  005065  000002          I0031:  CLR     2(R5)           ;TEST THE CLR

004454  020412                          CMP     R4,(R2)         ;RESULT = 0?
004456  001403                          BEQ     T0032           ;BR IF YES

004460  011203                          MOV     (R2),R3         ;GET WAS DATA
004462  000000                  E0031:  HALT                    ;CLR FAILED TO ZERO [DEST]
004464  000764                          BR      R0031           ;LOCK ON HARD ERROR.
```

```
                                        ; ***************************************************************
                                                .SBTTL T0032 BASIC "ASL  RN" TEST WITH [DEST]=125252 AND C(0)
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [104,373,360,000] FC 1,7,8

                                        ;ACT BUTS:      37[004]160,104 / 31[104]360,360 / 27[373]000,000

                                        ;EXEC:          [104]ALUC=LHHLL :[373]D=52524

                                        ;CODES:         [360] SPS=3  /  N:C=0001

                                        ;SYNC:          B05J2 (-)       /       T= 1 USEC

                                        ;KEY SIG:       K3-5 ROTSHF H  /  K3-3 SM=6L  /  K5-2 PS (C)(1)H

004466  012700  000032          T0032:  MOV     #0032,R0                ;LOAD R0 WITH TEST NO.
004472  112760  000377  070162          MOVB    #377,STAB1(R0)          ;SET FLAG FOR THIS TEST IN MISSED TABLE
004500  012704  052524                  MOV     #52524,R4               ;RESULT S / B = 52524
004504  012702  177703                  MOV     #177703,R2              ;DEST ADDR = R3
004510  012703  125252          R0032:  MOV     #125252,R3              ;MAKE [DEST] = 125252
004514  000257                          CCC                             ;MAKE C=0

004516  006303                  I0032:  ASL     R3                      ;TEST THE ASL - IT SHOULD SET "C"

004520  103402                          BCS     A0032                   ;BR IF "C" GOT SET

004522  000000                  E10032: HALT                            ;ASL FAILED TO SET "C" BIT
004524  000771                          BR      R0032                   ;LOCK ON HARD ERROR

004526  020403                  A0032:  CMP     R4,R3                   ;WAS RESULT = 52524 ??
004530  001402                          BEQ     T0033                   ;BR IF YES

004532  000000                  E20032: HALT                            ;ASL DELIVERED THE WRONG RESULT
004534  000765                          BR      R0032                   ;LOCK ON HARD ERROR
```

```
                                        ; ***************************************************************
                                                .SBTTL T0033 BASIC "ASL  RN" TEST WITH [DEST]=052525 AND C(1)
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [104,373,360,000] FC 1,7,8]

                                        ;ACT BUTS:      37[004]100,104 / 31[104]360,360 / 27[373]000,000

                                        ;EXEC:          [104]ALUC=LHHLL :[373]D=125252

                                        ;CODES:         [360] SPS=3  /  N:C=1000

                                        ;SYNC:          BOSJ2 (-)       /       T= 1 USEC

                                        ;KEY SIG:       K3-5 ROTSHF H  /  K3-3 SM=6L  /  K5-2 PS(N)(1)H

004536  012700  000033                  T0033:  MOV     #0033,R0                ;LOAD R0 WITH TEST NO.
004542  112760  000377  070162                  MOVB    #377,STAB1(R0)  ;SET FLAG FOR THIS TEST IN MISSED TABLE
004550  012704  125252                          MOV     #125252,R4      ;RESULT S / B = 125252
004554  012702  177703                          MOV     #177703,R2      ;DEST ADDR = R3
004560  012703  052525                  R0033:  MOV     #052525,R3      ;MAKE [DEST] = 052525
004564  000241                                  SEC                     ;MAKE C=1

004566  006303                          I0033:  ASL     R3              ;TEST THE ASL - IT SHOULD CLR "C"

004570  103002                                  BCC     A0033           ;BR IF "C" GOT CLEARED

004572  000000                          E10033: HALT                    ;ASL FAILED TO CLEAR "C"
004574  000771                                  BR      R0033           ;LOCK ON HARD ERROR

004576  020403                          A0033:  CMP     R4,R3           ;RESULT = 125252 ??
004600  001402                                  BEQ     T0034           ;BR IF YES

004602  000000                          E20033: HALT                    ;ASL DELIVERED WRONG REULT
004604  000765                                  BR      R0033           ;LOCK ON HARD ERROR
```

```
                                        ; ***************************************************************
                                                .SBTTL T0034 BASIC "ROL  RN" TEST WITH [DEST]=125252 AND C(0)
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [104,373,360,000] FC 1,7,8

                                        ;ACT BUTS:      37[004]100,104 / 31[104]360,360 / 27[373]000,000

                                        ;EXEC:          [104]ALUC=LHHLL :[373]D=052524

                                        ;CODES:         [360] SPS=3  /  N:C=0001

                                        ;SYNC:          BOSJ2 (-)       /       T= 1 USEC

                                        ;KEY SIG:       K3-5 ROTSHF H  /  K3-3 SM=6L  /  K5-2 PS(C)(1)H

004606  012700  000034                  T0034:  MOV     #0034,R0                ;LOAD R0 WITH TEST NO.
004612  112760  000377  070162                  MOVB    #377,STAB1(R0)  ;SET FLAG FOR THIS TEST IN MISSED TABLE
004620  012702  177703                          MOV     #177703,R2      ;DEST ADDR = R3
004624  012704  052524                          MOV     #052524,R4      ;RESULT S / B = 052524
004630  012703  125252                  R0034:  MOV     #125252,R3      ;MAKE [DEST] = 125252
004634  000257                                  CCC                     ;MAKE C=0

004636  006103                          I0034:  ROL     R3              ;TEST THE ROL - IT SHOULD SET C

004640  103402                                  BCS     A0034           ;BR IF "C" GOT SET

004642  000000                          E10034: HALT                    ;ROL FAILED TO SET "C"
004644  000771                                  BR      R0034           ;LOCK ON HARD ERROR

004646  020403                          A0034:  CMP     R4,R3           ;RESULT = 052524 ??
004650  001402                                  BEQ     T0035           ;BR IF YES

004552  000000                          E20034: HALT                    ;ROL DELIVERED WRONG RESULT
004654  000765                                  BR      R0034           ;LOCK ON HARD ERROR
```

```
                                ; ****************************************************************
                                        .SBTTL T0035 BASIC "ROL  RN" TEST WITH [DEST]=052524 AND C(1)
                                ; ****************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [104,373,360,000] FC 1,7,8

                                ;ACT BUTS:      37[004]100,104 / 31[104]360,360 / 27[373]000,000

                                ;EXEC:          [104]ALUC=LHHLL :[373]D=125251

                                ;CODES:         [360] SPS=3  /  N:C=1000

                                ;SYNC:          B05J2 (-)       /       T= 1 USEC

                                ;KEY SIG:       K3-5 ROTSHF H  /  K3-3 SM=6L  /  K5-2 PS(N)(1)H

004656  012700  000035          T0035:  MOV     #0035,R0                ;LOAD R0 WITH TEST NO.
004662  112760  000377  070162          MOVB    #377,STAB1(R0)  ;SET FLAG FOR THIS TEST IN MISSED TABLE
004670  012702  177703                  MOV     #177703,R2      ;DEST ADDR = R3
004674  012704  125251                  MOV     #125251,R4      ;RESULT S / B = 125251
004700  012703  052524          R0035:  MOV     #052524,R3      ;MAKE [DEST] = 052524
004704  000261                          SEC                     ;MAKE C=1

004706  006103                  I0035:  ROL     R3              ;TEST THE ROL - IT SHOULD CLEAR C

004710  103002                          BCC     F0035           ;BR IF "C" IS CLEAR

004712  000000                  E10035: HALT                    ;ROL FAILED TO CLEAR "C"
004714  000771                          BR      R0035           ;LOCK ON HARD ERROR

004716  020403                  A0035:  CMP     R4,R3           ;RESULT = 125251 ??
004720  001402                          BEQ     T0036           ;BR IF YES

004722  000000                  E20035: HALT                    ;ROL DELIVERED WRONG RESULT
004724  000765                          BR      R0035           ;LOCK ON HARD ERROR
```

```
                                ; ***********************************************************************
                                        .SBTTL T0036 BASIS "TSTB (R)" TEST - EVEN ADDRESS
                                ; ***********************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [161,266,267,220,211,367,375,016] FC 1,3,9,8

                                ;ACT BUTS:      37[004]100,161 / 33[266]220,220 / 16[367]016,016

                                ;EXEC:          [220]ALUC=LLLLL :[211]D=000377

                                ;CODES:         [367] SPS=3  /  N:C=1000

                                ;SYNC:          BOSJ2 (-)       /       T= 1.8 USEC

                                ;KEY SIG:       K3-4 TSTL  /  K3-3 DM=1L  /  K5-2 PS(N)(1)H  /  K3-6 BYTE INSTR H

004726  012700  000036          T0036:  MOV     #0036,R0                ;LOAD R0 WITH TEST NO.
004732  112760  000377  070162          MOVB    #377,STAB1(R0)  ;SET FLAG FOR THIS TEST IN MISSED TABLE
004740  012702  067620                  MOV     #DWTA+6,R2      ;DEST ADDR = DWTA+6
004744  012704  000377                  MOV     #377,R4         ;RESULT S / B = 377
004750  000257                  R0036:  CCC                     ;SCOPE SYNC

004752  105712                  I0036:  TSTB    (R2)            ;TEST THE TSTB

004754  100402                          BMI     A0036           ;BR IF "N" SET - IT SHOULD BE

004756  000000                  E10036: HALT                    ;TSTB FAILED TO SET "N"
004760  000773                          BR      R0036           ;LOCK ON HARD ERROR

004762  020412                  A0036:  CMP     R4,(R2)         ;DID TSTB DISTURB [DEST]
004764  001404                          BEQ     T0037           ;BR IF NOT

004766  011203                          MOV     (R2),R3         ;GET WAS DATA
004770  000000                  E20036: HALT                    ;TSTB ALTERED [DEST]
004772  010412                          MOV     R4,(R2)         ;RESTORE [DEST]
004774  000765                          BR      R0036           ;LOCK ON HARD EROR
```

```
                                        ; ***************************************************************
                                                .SBTTL T0037 BASIS "TSTB (R)" TEST - ODD ADDRESS
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [161,266,267,237,270,222,253,075,374,375,016] FC 1,3,9,8

                                        ;ACT BUTS:      37[004]100,161 / 33[266]220,237 / 34[237]220,222 / 16[374]016,016

                                        ;EXEC:          [222]ALUC=LLLLL :[253]D=000377

                                        ;CODES:         [075] SPS=3  /  N:C=1000

                                        ;SYNC:          BOSJ2 (-)       /       T= 1.9 USEC

                                        ;KEY SIG:       K3-4 TSTL  /  K3-3 DM=1L  /  K5-2 PS(N)(1)H  /  K3-6 BYTE INSTR H

004776  012700  000037                  T0037:  MOV     #0037,R0                ;LOAD R0 WITH TEST NO.
005002  112760  000377  070162                  MOVB    #377,STAB1(R0)  ;SET FLAG FOR THIS TEST IN MISSED TABLE
005010  012702  070144                          MOV     #DWTB+6,R2      ;DEST ADDR = DWTB+6
005014  012704  177401                          MOV     #177401,R4      ;RESULT S / B = 177401
005020  012703  070145                          MOV     #DWTB+7,R3      ;DEST ADDR USED = DWTB+7
005024  000257                          R0037:  CCC                     ;SCOPE SYNC

005026  105713                          I0037:  TSTB    (R3)            ;TEST THE TSTB

005030  100402                                  BMI     A0037           ;BR IF "N" SET - IT SHOULD BE

005032  000000                          E10037: HALT                    ;TSTB FAILED TO SET "N"
005034  000773                                  BR      R0037           ;LOCK ON HARD ERROR

005036  020412                          A0037:  CMP     R4,(R2)         ;DID TSTB DISTURB [DEST]
005040  001404                                  BEQ     T0040           ;BR IF NOT

005042  011203                                  MOV     (R2),R3         ;GET WAS DATA
005044  000000                          E20037: HALT                    ;TSTB ALTERED [DEST]
005046  010412                                  MOV     R4,(R2)         ;RESTORE [DEST]
005050  000765                                  BR      R0037           ;LOCK ON HARD EROR
```

```
                                        ; ***************************************************************
                                                .SBTTL T0040 BASIC "TSTB @#A" TEST - EVEN ADDRESS
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [163,264,265,266,267,225,367,375,016] FC 1,3,9,8

                                        ;ACT BUTS:      37[004]100,163 / 33[266]220,220 / 16[367]016,016

                                        ;EXEC:          [220]ALUC=LLLLL :[211]D=177400

                                        ;CODES:         [075] SPS=3  /  N:C=0100

                                        ;SYNC:          B05J2 (-)       /       T= 2.8 USEC

                                        ;KEY SIG:       K3-4 TSTL  /  K3-3 DM=3L  /  K5-2 PS(Z)(1)H  /  K3-6 BYTE INSTR H

005052  012700  000040          T0040:  MOV     #0040,R0                ;LOAD R0 WITH TEST NO.
005056  112760  000377  070162          MOVB    #377,STAB1(R0)  ;SET FLAG FOR THIS TEST IN MISSED TABLE
005064  032737  000001  066642          BIT     #1,@#BPTLOC     ;BREAKPOINT HALT SET ??
005072  001401                          BEQ     .+4             ;BR IF NOT
005074  000000                          HALT                    ;BREAK - DEPRESS CONTINUE TO RESTART
005076  012702  067616                  MOV     #DWTA+4,R2      ;DEST ADDR = DWTA+4
005102  012704  177400                  MOV     #177400,R4      ;RESULT S / B = 177400
005106  000257                  R0040:  CCC                     ;SCOPE SYNC

005110  105737  067616          I0040:  TSTB    @#DWTA+4        ;TEST THE TSTB

005114  001402                          BEQ     A0040           ;BR IF "Z" SET - IT SHOULD BE

005116  000000                  E10040: HALT                    ;TSTB FAILED TO SET "Z"
005120  000772                          BR      R0040           ;LOCK ON HARD ERROR

005122  020412                  A0040:  CMP     R4,(R2)         ;DID TSTB DISTURB [DEST]?
005124  001404                          BEQ     T0041           ;BR IF NOT

005126  011203                          MOV     (R2),R3         ;GET WAS DATA
005130  000000                  E20040: HALT                    ;TSTB ALTERED [DEST]
005132  010412                          MOV     R4,(R2)         ;RESTORE [DEST]
005134  000764                          BR      R0040           ;LOCK ON HARD ERROR
```

```
                                ; ***********************************************************************
                                        .SBTTL T0041 BASIC "TSTB @#A" TEST - ODD ADDRESS
                                ; ***********************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [163,264,265,266,267,237,270,222,253,075,374,375,016] FC 1,3,9,8

                                ;ACT BUTS:      37[004]100,163 / 33[266]220,237 / 34[237]220,222 / 16[374]016,016

                                ;EXEC:          [222]ALUC=LLLLL :[253]D=000377

                                ;CODES:         [075] SPS=3  /  N:C=0100

                                ;SYNC:          BOSJ2 (-)       /       T= 2.8 USEC

                                ;KEY SIG:       K3-4 TSTL  /  K3-3 DM=3L  /  K5-2 PS(Z)(1)H  /  K3-6 BYTF INSTR H

005136  012700  000041          T0041:  MOV     #0041,R0                ;LOAD R0 WITH TEST NO.
005142  112760  000377  070162          MOVB    #377,STAB1(R0)  ;SET FLAG FOR THIS TEST IN MISSED TABLE
005150  012702  067620                  MOV     #DWTA+6,R2      ;DEST ADDR = DWTA+6
005154  012704  000377                  MOV     #377,R4         ;RESULT S / B = 377
005160  000257                  R0041:  CCC                     ;SCOPE SYNC

005162  105737  067621          I0041:  TSTB    @#DWTA+7        ;TEST THE TSTB

005166  001402                          BEQ     A0041           ;BR IF "Z" SET - IT SHOULD BE

005170  000000                  E10041: HALT                    ;TSTB FAILED TO SET "Z"
005172  000772                          BR      R0041           ;LOCK ON HARD ERROR

005174  020412                  A0041:  CMP     R4,(R2)         ;DID TSTB DISTURB [DEST]?
005176  001404                          BEQ     T0042           ;BR IF NOT

                                        MOV     (R2),R3         ;GET WAS DATA
005200  011203                  E20041: HALT                    ;TSTB ALTERED [DEST]
005202  000000                          MOV     R4,(R2)         ;RESTORE [DEST]
005204  010412                          BR      R0041           ;LOCK ON HARD ERROR
005206  000764
```

```
                                        ; ***********************************************************************
                                                .SBTTL T0042 BASIC "DECB 1(SP)"
                                        ; ***********************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;RCM SEQ:       [167,261,262,266,267,237,270,222,253,075,374,375,016] FC 1,3,9,8

                                        ;ACT BUTS:      37[004]100,167 / 33[266]220,237 / 34[237]220,222 / 16[374]016,016

                                        ;EXEC:          [222]ALUC=LHHHH :[253]D=177400

                                        ;CODES:         [075] SPS=3  /  N:C=1000

                                        ;SYNC:          BOSJ2 (-)       /       T= 2.8 USEC

                                        ;KEY SIG:       K3-4 DEC L  /  K3-3 DM=6L  /  K5-2 PS(N)(1)H  /  K3-6 BYTE INSTR H

005210  012700  000042          T0042:  MOV     #0042,R0                ;LOAD R0 WITH TEST NO.
005214  112760  000377  070162          MOVB    #377,STAB1(R0)  ;SET FLAG FOR THIS TEST IN MISSED TABLE
005222  010605                          MOV     SP,R5           ;SAVE SP
005224  012704  177400                  MOV     #177400,R4      ;RESULT S / B = 177400
005230  010506                  R0042:  MOV     R5,SP
005232  012746  000000                  MOV     #0,-(SP)        ;[DEST] = 000000
005236  000257                          CCC                     ;SCOPE SYNC

005240  105366  000001          I0042:  DECB    1(SP)           ;TEST THE DECB

005244  020416                          CMP     R4,(SP)         ;RESULT = 177400?
005246  001405                          BEQ     A0042           ;BR IF YES

005250  011603                          MOV     (SP),R3         ;GET WAS DATA
005252  010602                          MOV     SP,R2           ;GENERATE DEST ADDR IN R2
005254  005202                          INC     R2
005256  000000                  E0042:  HALT                    ;ERROR - DECB FAILED
005260  000763                          BR      R0042           ;LOCK ON HARD ERROR

005262  010506                  A0042:  MOV     R5,SP           ;RESET THE SP
```

```
                                        ; ***********************************************************************
                                                .SBTTL T0043 BASIC "MOV @#A,R" TEST
                                        ; ***********************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [143,245,246,247,250,160,204,000] FC 1,2,4

                                        ;ACT BUTS:      37[004]100,143 / 35[247]120,160 / 20[160]000,000

                                        ;EXEC:          [160]ALUC=LLLLL :[204]D=#DWTA

                                        ;CODES:         [204] SPS=3  /  N:C=0000

                                        ;SYNC:          B05J2 (-)       /       T= 3.2 USEC

                                        ;KEY SIG:       K3-3 MOV L  /  K3-3 DM=OL  /  K3-5 DOPL

005264  012700  000043                  T0043:  MOV     #0043,R0                ;LOAD R0 WITH TEST NO.
005270  112760  000377  070162                  MOVB    #377,STAB1(R0)  ;SET FLAG FOR THIS TEST IN MISSED TABLE
005276  012702  177703                          MOV     #177703,R2      ;DEST ADDR = 3
005302  012704  067612                          MOV     #DWTA,R4        ;RESUTL S / B = #DWTA
005306  005003                          R0043:  CLR     R3              ;[DEST] = 000000
005310  000257                                  CCC                     ;SCOPE SYNC

005312  013703  067566                  I0043:  MOV     @#ATA,R3        ;TEST THE MOV

005316  020403                                  CMP     R4,R3           ;RESULT = DWTA?
005320  001402                                  BEQ     T0044           ;BR IF YES

005322  000000                          E0043:  HALT                    ;MOV FAILED TO DELIVER CORRECT RESULT
005324  000770                                  BR      R0043           ;LOCK ON HARD ERROR
```

```
                                        ; ***********************************************************************
                                                .SBTTL T0044 BASIC "MOV #N,X(R)" TEST
                                        ; ***********************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [142,240,250,177,206,212,200,125,375,016] FC 1,2,4,8

                                        ;ACT BUTS:      37[004]100,142 / 35[240]120,177 / 17[177]212,212 / 16[125]016,016

                                        ;EXEC:          [200]ALUC=LLLLL :[125]D=125252

                                        ;CODES:         [125] SPS=3  /  N:C=0000

                                        ;SYNC:          B05J2 (-)       /       T= 4 USEC

                                        ;KEY SIG:       K3-3 MOVL  /  K3-3 DM=0  /  K3-5 DOPL

005326  012700  000044          T0044:  MOV     #0044,R0                ;LOAD R0 WITH TEST NO.
005332  112760  000377  070162          MOVB    #377,STAB1(R0)  ;SET FLAG FOR THIS TEST IN MISSED TABLE
005340  012702  067604                  MOV     #MBUF0+2,R2     ;DEST ADDR = MBUF0+2
005344  012704  125252                  MOV     #125252,R4      ;RESULT S / B = 125252
005350  012703  067602          R0044:  MOV     #MBUF0,R3       ;[R3] = BASE DEST ADDR
005354  005012                          CLR     (R2)            ;[DEST] = 000000
005356  000257                          CCC                     ;SCOPE SYNC

005360  012763  125252  000002  I0044:  MOV     #125252,2(R3)   ;TEST THE MOV

005366  020412                          CMP     R4,(R2)         ;RESULT OK?
005370  001403                          BEQ     T0045           ;BR IF YES

005372  011203                          MOV     (R2),R3         ;GET WAS DATA
005374  000000                  E0044:  HALT                    ;MOV DELIVERED WRONG RESULT
005376  000764                          BR      R0044           ;LOCK ON HARD ERROR
```

```
                                ; ***********************************************************************
                                        .SBTTL T0045 BASIC "MOV #N,(R)" TEST
                                ; ***********************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [142,240,250,171,257,200,125,375,016] FC 1,2,4

                                ;ACT BUTS:      37[004]100,142 / 35[240]120,171 / 22[171]200,200 / 16[125]016,016

                                ;EXEC:          [200]ALUC=LLLLL :[125]D=125252

                                ;CODES:         [125] SPS=3  /  N:C=1000

                                ;SYNC:          B05J2 (-)       /       T= 2.3 USEC

                                ;KEY SIG:       K3-3 MOVL  /  K3-3 DM=1L  /  K3-5 DOPL  /  K5-2 PS (N)(1)H

005400  012700  000045          T0045:  MOV     #0045,R0                ;LOAD R0 WITH TEST NO.
005404  112760  000377  070162          MOVB    #377,STAB1(R0)  ;SET FLAG FOR THIS TEST IN MISSED TABLE
005412  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
005416  012704  125252                  MOV     #125252,R4      ;RESULT S / B = 125252
005422  010203                  R0045:  MOV     R2,R3           ;R3 GETS DEST ADDR
005424  005013                          CLR     (R3)            ;[DEST] = 000000
005426  000257                          CCC                     ;SCOPE SYNC

005430  012713  125252          I0045:  MOV     #125252,(R3)    ;TEST THE MOV

005434  020412                          CMP     R4,(R2)         ;RESULT OK?
005436  001403                          BEQ     T0046           ;BR IF YES

005440  011203                          MOV     (R2),R3         ;GET WAS DATA
005442  000000                  E0045:  HALT                    ;MOV DELIVERED WRONG RESULT
005444  000766                          BR      R0045           ;LOCK ON HARD ERROR
```

```
                                        ; ***************************************************************
                                                .SBTTL T0046 BASIC "MOV (RA)+,RB" TEST
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [142,240,250,160,204,000] FC 1,2,4

                                        ;ACT BUTS:      37[004]100,142 /  35[240]120,160 / 20[160]000,000

                                        ;EXEC:          [160]ALUC=LLLLL :[204]D=#DWTA

                                        ;CODES:         [204] SPS=3  /  N:C=0000

                                        ;SYNC:          B05J2 (-)       /       T= 2.3 USEC

                                        ;KEY SIG:       K3-3 MOVL  /  K3-3 DM=0L  /  K3-5 DOPL

005446  012700  000046          T0046:  MOV     #0046,R0                ;LOAD R0 WITH TEST NO.
005452  112760  000377  070162          MOVB    #377,STAB1(R0)  ;SET FLAG FOR THIS TEST IN MISSED TABLE
005460  012704  067612                  MOV     #DWTA,R4        ;RESULT S / B = #DWTA
005464  012702  177703                  MOV     #177703,R2      ;DEST ADDR = R3
005470  012705  067566          R0046:  MOV     #ATA,R5         ;SRC ADDR = ATA
005474  005003                          CLR     R3              ;[DEST] = 000000
005476  000257                          CCC                     ;SCOPE SYNC

005500  012503                  I0046:  MOV     (R5)+,R3        ;TEST THE MOV

005502  020403                          CMP     R4,R3           ;RESULT OK?
005504  000402                          BR      A0046           ;BR IF YES

005506  000000                  E10046: HALT                    ;MOV DELIVERED WRONG RESULT
005510  000767                          BR      R0046           ;LOCK ON HARD ERROR

005512  022705  067570          A0046:  CMP     #ATA+2,R5       ;DID SRC REG GET INCREMENTED?
005516  001402                          BEQ     T0047           ;BR IF YES

005520  000000                  E20046: HALT                    ;MOV FAILED TO UPDATE SRC. REG.
005522  000762                          BR      R0046           ;LOCK ON HARD ERROR
```

```
                                        ; ***************************************************************
                                                .SBTTL T0047 BASIC "MOV  @#A,@#B"
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [143,245,256,247,250,173,207,210,200,125,375,016] FC 1,2,4

                                        ;ACT BUTS:      37[004]100,143 / 35[247]120,173 . 22[207]200,200 / 16[125]016,016

                                        ;EXEC:          [200]ALUC=LLLLL :[125]D=#DWTA

                                        ;CODES:         [125] SPS=3  /  N:C=0000

                                        ;SYNC:          BOSJ2 (-)       /       T= 5 USEC

                                        ;KEY SIG:       K3-3 MOVL  /  K3-3 SM=3L  /  K3-3 DM=3L

005524  012700  000047          T0047:  MOV     #0047,R0                ;LOAD R0 WITH TEST NO.
005530  112760  000377  070162          MOVB    #377,STAB1(R0)  ;SET FLAG FOR THIS TEST IN MISSED TABLE
005536  012702  067606                  MOV     #MBUF1,R2       ;DEST ADDR = MBUF1
005542  012704  067612                  MOV     #DWTA,R4        ;RESULT S / B = #DWTA
005546  005012                  R0047:  CLR     (R2)            ;MAKE [DEST] = 000000
005550  000257                          CCC                     ;SCOPE SYNC

005552  013737  067566  067606  I0047:  MOV     @#ATA,@#MBUF1   ;TEST THE MOV
005560  020412                          CMP     R4,(R2)         ;DID RESULT = #DWTA ?
005562  001403                          BEQ     T0050           ;BR IF YES

005564  011203                          MOV     (R2),R3         ;GET THE WAS DATA
005566  000000                  E0047:  HALT    .               ;MOV DELIVERED THE WRONG RESULT
005570  000766                          BR      R0047           ;LOCK ON HARD ERROR
```

```
                                        ; ***************************************************************
                                                .SBTTL T0050 BASIC "MOV   X(R),PC" TEST
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [146,241,242,247,250,160,204,000] FC 1,2,4

                                        ;ACT BUTS:      37[004]100,146 / 35[247]120,160 / 20[160]000,000

                                        ;EXEC:          [160]ALUC=LLLLL :[204]D=#T077

                                        ;CODES:         [204] SPS=3  /  N:C=0000

                                        ;SYNC:          BOSJ2 (-)       /       T= 4 USEC

                                        ;KEY SIG:       K3-3 MOVL  /  K3-3 SM=6L  /  K3-3 DM=0L  /  K3-4 IR (02:00)=7L

005572  012700  000050                  T0050:  MOV     #0050,R0                ;LOAD R0 WITH TEST NO.
005576  112760  000377  070162                  MOVB    #377,STAB1(R0)  ;SET FLAG FOR THIS TEST IN MISSED TABLE
005604  012705  005612                  R0050:  MOV     #I0050,R5       ;[R5] = I0050 (BASE ADDRESS)
005610  000257                                  CCC                     ;SCOPE SYNC

005612  016507  000010                  I0050:  MOV     A0050-I0050(R5),PC      ;TEST THE MOV - GO TO A0050

005616  000000                          E0050:  HALT                    ;MOV FAILED TO LOAD THE PC
005620  000771                                  BR      R0050           ;LOCK ON HARD ERROR

005622  005624                          A0050:    T0051                         ;POINTER TO NEXT TEST
```

```
                                        ; ****************************************************************
                                                .SBTTL T0051 BASIC "MOV @#A,(R)" TEST
                                        ; ****************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [143,245,246,247,250,171,257,200,125,375,016] FC 1,2,4

                                        ;ACT BUTS:      37[004]100,143 / 35[247]120,171 / 22[171]200,200 / 16[125]016,016

                                        ;EXEC:  [200]ALUC=LLLLL :[125]D=051300

                                        ;CODES: [125] SPS=3  /  N:C=0000

                                        ;SYNC:          BOSJ2 (-)       /       T= 4.2 USEC

                                        ;KEY SIG:       K3-3 MOVL  /  K3-3 SM=3L  /  K3-3 DM=1L

005624  012700  000051          T0051:  MOV     #0051,R0                ;LOAD R0 WITH TEST NO.
005630  112760  000377  070162          MOVB    #377,STAB1(R0)  ;SET FLAG FOR THIS TEST IN MISSED TABLE
005636  012704  067612                  MOV     #DWTA,R4        ;RESULT S / B = #DWTA
005642  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
005646  005012                  R0051:  CLR     (R2)            ;MAKE [DEST]=000000
005650  000257                          CCC                     ;SCOPE SYNC - Z=0

005652  013712  067566          I0051:  MOV     @#ATA,(R2)      ;TEST THE MOV

005656  020412                          CMP     R4,(R2)         ;DID RESULT = #DWTA ??
005660  001403                          BEQ     T0052           ;BR IF YES

005662  011203                          MOV     (R2),R3         ;GET THE WAS DATA
005664  000000                  E0051:  HALT                    ;MOV DELIVERED WRONG RESULT
005666  000767                          BR      R0051           ;LOCK ON HARD ERROR
```

```
                                        ; ***************************************************************
                                                .SBTTL TOOS2 BASIC "MOV  X(RA),RB" TEST
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [146,241,242,247,250,160,204,000] FC 1,2,4

                                        ;ACT BUTS:      37[004]100,146 / 35[247]120,160 / 20[160]000,000

                                        ;EXEC:          [160]ALUC=LLLLL :[204]D=#DBTA

                                        ;CODES:         [204] SPS=3  /  N:C=0000

                                        ;SYNC:          BOSJ2 (-)       /       T= 3 USEC

                                        ;KEY SIG:       K3-3 MOVL  /  K3-3 SM=6L  /  K3-3 DM=0L

005670  012700  000052                  TOOS2:  MOV     #0052,R0                ;LOAD R0 WITH TEST NO.
005674  112760  000377  070162                  MOVB    #377,STAB1(R0)  ;SET FLAG FOR THIS TEST IN MISSED TABLE
005702  012704  070152                          MOV     #DBTA,R4        ;RESULT S / B = #DBTA
005706  012702  177703                          MOV     #177703,R2      ;DEST ADDR = R3
005712  012705  067566                          MOV     #ATA,R5         ;[R5] = BASE ADDR FOR SOURCE (ATA)
005716  005003                          ROOS2:  CLR     R3              ;MAKE [DEST] = 000000
005720  000257                                  CCC                     ;SCOPE SYNC

005722  016503  000004                  IOOS2:  MOV     4(R5),R3        ;TEST THE MOV

005726  020403                                  CMP     R4,R3           ;RESULT = #DBTA ??
005730  001402                                  BEQ     TOOS3           ;BR IF YES

005732  000000                          EOCS2:  HALT                    ;MOV DELIVERED WRONG RESULT
005734  000770                                  BR      ROOS2           ;LOCK ON HARD ERROR
```

```
                                        ; ***************************************************************
                                                .SBTTL T0053 BASIC "MOV  RA,-(RB)" TEST
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [174,257,201,125,375,016] FC 1,4

                                        ;ACT BUTS:      37[004]100,174 / 22[174]200,201 / 16[125]016,016

                                        ;EXEC:          [201]A_UC=LLLLL :[125]D=125252

                                        ;CODES:         [125] SPS=3  /  N:C=1000

                                        ;SYNC:          BOSJ2 (-)       /       T= 1.8 USEC

                                        ;KEY SIG:       K-3 MOVL  /  K3-3 SM=0L  /  K3-3 DM=4L  /  K5-2 PS(N)(1)H

005736  012700  000053          T0053:  MOV     #J053,R0                ;LOAD R0 WITH TEST NO.
005742  112760  000377  070162          MOVB    #377,STAB1(R0)  ;SET FLAG FOR THIS TEST IN MISSED TABLE
005750  012702  067602                  MOV     #MBUF0,R2       ;FINAL DEST ADDR = MBUF0
005754  012704  125252                  MOV     #125252,R4      ;RESULT S / B = 125252
005760  012705  067604          R0053:  MOV     #MBUF0+2,R5     ;INITIAL DEST ADDR = TEMP2 + 2
005764  005012                          CLR     (R2)            ;MAKE [DEST] = 000000
005766  000257                          CCC                     ;SCOPE SYNC

005770  010445                  I0053:  MOV     R4,-(R5)        ;TEST THE MOV

005772  020412                          CMP     R4,(R2)         ;RESULT = 125252
005774  001403                          BEQ     A0053           ;BR IF YES

005776  011203                          MOV     (R2),R3         ;GET THE S / B DATA
006000  000000                  E10053: HALT                    ;MOV DELIVERED THE WRONG ESULT
006002  000766                          BR      R0053           ;LOCK ON HARD ERROR

006004  020205                  A0053:  CMP     R2,R5           ;DID REGISTER GET DECREMENTED ?
006006  001402                          BEQ     T0054           ;BR IF YES

006010  000000                  E20053: HALT                    ;MOV FAILED TO UPDATE REGISTER
006012  000762                          BR      R0053           ;LOCK ON HARD ERROR
```

```
                                        ; ***************************************************************
                                                .SBTTL T0054 BASIC "MOV   @#A,-(R)" TEST
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [143,245,246,247,250,174,200,125,375,016] FC 1,2,4

                                        ;ACT BUTS:      37[004]100,143 / 35[247]120,174 / 22[174]200,200 / 16[125]016,016

                                        ;EXEC:          [200]ALUC=LLLLL :[125]D=#DWTA

                                        ;CODES:         [125] SPS=3  /  N:C=0100

                                        ;SYNC:          B05J2 (-)       /       T= 4.2 USEC

                                        ;KEY SIG:       K3-3 MOVL  /  K3-3 SM=3L  /  K3-3 DM=4L  /  K5-2 PS(Z)(1)H

006014  012700  000054          T0054:  MOV     #0054,R0                ;LOAD R0 WITH TEST NO.
006020  112760  000377  070162          MOVB    #377,STAB1(R0)  ;SET FLAG FOR THIS TEST IN MISSED TABLE
006026  012704  067612                  MOV     #DWTA,R4        ;RESULT S / B = #DWTA
006032  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
006036  012705  067604          R0054:  MOV     #MBUF0+2,R5     ;INITIAL DEST ADDR = MBUF0+2
006042  005012                          CLR     (R2)            ;MAKE [DEST] = 000000
006044  000257                          CCC                     ;SCOPE SYNC

006046  013745  067566          I0054:  MOV     @#ATA,-(R5)     ;TEST THE MOV

006052  020412                          CMP     R4,(R2)         ;RESULT = 000000
006054  001403                          BEQ     A0054           ;BR IF YES

006056  011203                          MOV     (R2),R3         ;GET THE WAS DATA
006060  000000          E10054: HALT                            ;MOV DELIVERED THE WRONG RESULT
006062  000765                          BR      R0054           ;LOCK ON HARD ERROR

006064  020502          A0054:  CMP     R5,R2           ;DID DEST REG GET DECREMENTED ??
006066  001402                          BEQ     T0055           ;BR IF YES

006070  000000          E20054: HALT                            ;MOV FAILED TO UPDATE REGISTER
006072  000761                          BR      R0054           ;LOCK ON HARD ERROR
```

```
                                        ; ***************************************************************
                                                .SBTTL T0055 BASIC "MOV  (R),@#A" TEST
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [141,247,250,173,210,200,125,375,016]  FC 1,2,4

                                        ;ACT BUTS:      37[004]100,141 / 35[247]120,173 / 22[207]200,200 / 16[125]016,016

                                        ;EXEC:          [200]ALUC=LLLLL :[125]D=#DWTA

                                        ;CODES:         [125] SPS=3  /  N:C=0100

                                        ;SYNC:          BOSJ2 (-)       /       T= 4 USEC

                                        ;KEY SIG:       K3-3 MOVL  /  K3-3 SM=1L  /  K3-3 DM=3L  /  K5-2 PS(Z)(1)H

006074  012700  000055                  T0055:  MOV     #0055,R0                ;LOAD R0 WITH TEST NO.
006100  112760  000377  070162                  MOVB    #377,STAB1(R0)  ;SET FLAG FOR THIS TEST IN MISSED TABLE
006106  012702  067602                          MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
006112  012704  067612                          MOV     #DWTA,R4        ;RESULT S / B = #DWTA
006116  012705  067566                          MOV     #ATA,R5         ;SOURCE ADDR = ATA
006122  005012                          R0055:  CLR     (R2)            ;MAKE [DEST] = 000000
006124  000257                                  CCC                     ;SCOPE SYNC

006126  011537  067602                  I0055:  MOV     (R5),@#MBUF0    ;TEST THE MOV

006132  020412                                  CMP     R4,(R2)         ;RESULT = #DWTA ??
006134  001403                                  BEQ     T0056           ;BR IF YES

006136  011203                                  MOV     (R2),R3         ;GET THE WAS DATA
006140  000000                          E0055:  HALT                    ;MOV DELIVERED THE WRONG RESULT
006142  000767                                  BR      R0055           ;LOCK ON HARD ERROR
```

```
                                        ; ***************************************************************
                                                .SBTTL T0056 BASIC "MOV  -(R),@#A" TEST
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [144,240,250,173,207,210,200,125,375,016] FC 1,2,4

                                        ;ACT BUTS:      37[004]100,144 / 35[240]120,173 / 22[207]200,200 / 16[125]016,016

                                        ;EXEC:          [200]ALUC=LLLLL :[125]D=#DWTA

                                        ;CODES:         [125] SPS=3  /  N:C=0100

                                        ;SYNC:          BOSJ2 (-)       /       T= 4 USEC

                                        ;KEY SIG:       K3-3 MOVL  /  K3-3 SM=4L  /  K3-3 DM=3L  /  K5-2 PS(Z)(1)H

006144  012700  000056                  T0056:  MOV     #0056,R0                ;LOAD R0 WITH TEST NO.
006150  112760  000377  070162                  MOVB    #377,STA81(R0)  ;SET FLAG FOR THIS TEST IN MISSED TABLE
006156  012702  067602                          MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
006162  012704  067612                          MOV     #DWTA,R4        ;RESULT S / B = #DWTA
006166  012705  067570                  R0056:  MOV     #ATA+2,R5       ;INITIAL SOURCE ADDR = ATA+2
006172  005012                                  CLR     (R2)            ;MAKE [DEST] = 000000
006174  000257                                  CCC                     ;SCOPE SYNC

006176  014537  067602                  I0056:  MOV     -(R5),@#MBUF0   ;TEST THE MOV

006202  020412                                  CMP     R4,(R2)         ;RESULT = #DWTA ?
006204  001403                                  BEQ     A0056           ;BR IF YES

006206  011203                                  MOV     (R2),R3         ;GET THE WAS DATA
006210  000000                          E10056: HALT                    ;MOV DELIVERED THE WRONG RESULT
006212  000765                                  BR      R0056           ;LOCK ON HARD ERROR

006214  022705  067566                  A0056:  CMP     #ATA,R5         ;DID THE SRC REG GET DECREMENTED ?
006220  001402                                  BEQ     T0057           ;BR IF YES

006222  000000                          E20056: HALT                    ;MOV FAILED TO UPDATE SOURCE REG
006224  000760                                  BR      R0056           ;LOCK ON HARD ERROR
```

```
                                ; ***************************************************************
                                        .SBTTL T0057 BASIC "MOV   (RA),RB" TEST
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [142,240,250,160,204,000] FC 1,2,4

                                ;ACT BUTS:      37[004]100,142 / 35[240]120,160 / 20[160]000,000

                                ;EXEC:          [160]ALUC=LLLLL :[204]D=#DWTA

                                ;CODES:         [204] SPS=3  /  N:C=0100

                                ;SYNC:          B05J2 (-)       /       T= 1.8 USEC

                                ;KEY SIG:       K3-3 MOVL  /  K3-3 SM=2L  /  K3-3 DM=0L  /  K5-2 PS(Z)(1)H

006226  012700  000057          T0057:  MOV     #0057,R0                ;LOAD R0 WITH TEST NO.
006232  112760  000377  070162          MOVB    #377,STAB1(R0)  ;SET FLAG FOR THIS TEST IN MISSED TABLE
006240  012702  177703                  MOV     #177703,R2      ;DEST ADDR = R3
006244  012704  067612                  MOV     #DWTA,R4        ;RESULT S / B = #DWTA
006250  012705  067566          R0057:  MOV     #ATA,R5         ;INITIAL SOURCE ADDR = ATA
006254  005003                          CLR     R3              ;MAKE [DEST] = 000000
006256  000257                          CCC                     ;SCOPE SYNC

006260  012503                  I0057:  MOV     (R5)+,R3        ;TEST THE MOV

006262  020403                          CMP     R4,R3           ;RESULT = #DWTA ?
006264  001402                          BEQ     A0057           ;BR IF YES

006266  000000                  E10057: HALT                    ;MOV DELIVERED WRONG RESULT
006270  000767                          BR      R0057           ;LOCK ON HARD ERROR

006272  022705  067570          A0057:  CMP     #ATA+2,R5       ;DID SOURCE REG GET INCREMENTED
006276  001402                          BEQ     T0060           ;BR IF YES

006300  000000                  E20057: HALT                    ;MOV FAILED TO UPDATE SOURCE REGISTER
006302  000762                          BR      R0057           ;LOCK ON HARD ERROR
```

```
                                        ; ***************************************************************
                                                .SBTTL T0060 BASIC "MOV   X(RA),RB" TEST
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [146,241,242,247,250,160,204,000] FC 1,2,4

                                        ;ACT BLTS:      37[004]100,146 / 35[247]120,160 / 20[160]000,000

                                        ;EXEC:          [160]ALUC=LLLLL :[204]D=#DWTB

                                        ;CODES:         [204] SPS=3  /  N:C=0100

                                        ;SYNC:          B05J2 (-)       /       T= 2.5 USEC

                                        ;KEY SIG:       K3-3 MOVL  /  K3-3 SM=6L  /  K3-3 DM=0L  /  K5-2 PS(Z)(1)H

006304  012700  000060          T0060:  MOV     #0060,R0                ;LOAD R0 WITH TEST NO.
006310  112760  000377  070162          MOVB    #377,STAB1(R0)  ;SET FLAG FOR THIS TEST IN MISSED TABLE
006316  012702  177703                  MOV     #177703,R2      ;DEST ADDR = R3
006322  012704  070136                  MOV     #DWTB,R4        ;RESULT S / B = #DWTB
006326  012705  067566                  MOV     #ATA,R5         ;BASE SOURCE ADDR = ATA
006332  005003                  R0060:  CLR     R3              ;MAKE [DEST] = 000000
006334  000257                          CCC                     ;SCOPE SYNC

006336  016503  000002          I0060:  MOV     2(R5),R3        ;TEST THE MOV

006342  020403                          CMP     R4,R3           ;RESULT = #DWTB ?
006344  001402                          BEQ     T0061           ;BR IF YES

006346  000000                  E0060:  HALT                    ;MOV FAILED TO DELIVER CORRECT RESULT
006350  000770                          BR      R0060           ;LOCK ON HARD ERROR
```

```
                                        ; ***************************************************************
                                                .SBTTL T0061 BASIC "MOV   @X(RA),RB" TEST
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [147,243,244,245,246,247,250,160,204,000] FC 1,2,4

                                        ;ACT BUTS:      37[004]100,147 / 35[247]120,160 / 20[160]000,000

                                        ;EXEC:          [160]ALUC=LLLLL :[204]D=177777

                                        ;CODES:         [204] SPS=3  /  N:C=1000

                                        ;SYNC:          B05J2 (-)       /       T= 3.4 USEC

                                        ;KEY SIG:       K3-3 MOVL  /  K3-3 SM=7L  /  K3-3 DM=0L  /  K5-2 PS(N)(1)H

006352  012700  000061          T0061:  MOV     #0061,R0                ;LOAD R0 WITH TEST NO.
006356  112760  000377  070162          MOVB    #377,STAB1(R0)  ;SET FLAG FOR THIS TEST IN MISSED TABLE
006364  005004                          CLR     R4              ;RESULT S / B = 177777
006366  005104                          COM     R4
006370  012702  177703                  MOV     #177703,R2      ;DEST ADDR = R3
006374  012737  067614  067604          MOV     #DWTA+2,@#MBUF0+2 ;SET UP ADDRESS TABLE MBUF0
006402  012705  067602                  MOV     #MBUF0,R5       ;BASE ADDRESS IN R5
006406  005003                  R0061:  CLR     R3              ;MAKE [DEST] = 000000
006410  000257                          CCC                     ;SCOPE SYNC

006412  017503  000002          I0061:  MOV     @2(R5),R3       ;TEST THE MOV

006416  020403                          CMP     R4,R3           ;RESULT = 177777
006420  001402                          BEQ     T0062           ;BR IF YES

006422  000000                  E0061:  HALT                    ;MOV DELIVERED THE WRONG RESULT
006424  000770                          BR      R0061           ;LOCK ON HARD ERROR
```

```
                                ; ***************************************************************
                                        .SBTTL T0062 BASIC "MOV  (R)+,X(R)" TEST
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [142,240,250,177,206,212,200,125,375,016] FC 1,2,4

                                ;ACT BUTS:      37[004]100,142 / 35[240]120,177 / 17[177]212,212 / 21[206]200,200
                                                ; / 16[125]016,016

                                ;EXEC:          [200]ALUC=LLLLL :[125]D=125252

                                ;CODES:         [125] SPS=3  /  N:C=1000

                                ;SYNC:          B05J2 (-)       /       T= 4 USEC

                                ;KEY SIG:       K3-3 MOVL  /  K3-3 SM=2L  /  K3-3 DM=6L  /  K5-2 PS(N)(1)H

006426  012700  000062          T0062:  MOV     #0062,R0                ;LOAD R0 WITH TEST NO.
006432  112760  000377  070162          MOVB    #377,STAB1(R0)  ;SET FLAG FOR THIS TEST IN MISSED TABLE
006440  012704  125252                  MOV     #125252,R4      ;RESULT S / B = 125252
006444  012702  067610                  MOV     #MBUF1+2,R2     ;FINAL DEST ADDR = MBUF1+2
006450  010437  067602                  MOV     R4,@#MBUF0      ;SOURCE OPERAND = 125252
006454  012705  067602          R0062:  MOV     #MBUF0,R5       ;[R5] = INITIAL SRC ADDR = MBUF0
006460  005012                          CLR     (R2)            ;MAKE [DEST] = 000000
006462  000257                          CCC                     ;SCOPE SYNC

006464  012565  000004          I0062:  MOV     (R5)+,4(R5)     ;TEST THE MOV

006470  020412                          CMP     R4,(R2)         ;RESULT = 125252 ?
006472  001403                          BEQ     A0062           ;BR IF YES

006474  011203                          MOV     (R2),R3         ;GET THE WAS DATA
006476  000000          E10062: HALT                            ;MOV    DELIVERED WRONG RESULT
006500  000765                          BR      R0062           ;LOCK ON HARD ERROR

006502  022705  067604          A0062:  CMP     #MBUF0+2,R5     ;DID REGISTER GET INCREMENTED ?
006506  001402                          BEQ     T0063           ;BR IF YES

006510  000000          E20062: HALT                            ;MOV FAILED TO UPDATE REGISTER
006512  000750                          BR      R0062           ;LOCK ON HARD ERROR
```

```
                                ; ****************************************************************
                                        .SBTTL T0063 BASIC "CMP  R,@#A" TEST WITH [R] = [A]
                                ; ****************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [163,264,265,266,267,224,367,375,016] FC 1,3,8

                                ;ACT BUTS:      37[004]100,163 / 33[266]220,224 / 16[367]016,016

                                ;EXEC:          [224]ALUC=LLHHL :[367]D=125252

                                ;CODES:         [367] SPS=3  /  N:C=1100

                                ;SYNC:          B05J2 (-)       /       T= 3.5 USEC

                                ;KEY SIG:       K3-3 CMP L  /  K3-3 SM=0L  /  K3-3 DM=3L  /  K5-2 PS(Z)(1)H
                                                ;  K3-8 BTI + CMP + TST H

006514  012700  000063          T0063:  MOV     #0063,R0                ;LOAD R0 WITH TEST NO.
006520  112760  000377  070162          MOVB    #377,STAB1(R0)  ;SET FLAG FOR THIS TEST IN MISSED TABLE
006526  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
006532  012704  125252                  MOV     #125252,R4      ;RESULT S / B = 125252
006536  010405                  R0063:  MOV     R4,R5           ;[R5] = SOURCE OP = 125252
006540  010412                          MOV     R4,(R2)         ;MAKE [DEST] = 125252
006542  000257                          CCC                     ;SCOPE SYNC

006544  020537  067602          I0063:  CMP     R5,@#MBUF0      ;TEST THE CMP

006550  001402                          BEQ     A0063           ;BR IF "Z" WAS SET - IT SHOULD BE

006552  000000                  E10063: HALT                    ;CMP FAILED TO SET "Z"
006554  000770                          BR      R0063           ;LOCK ON HARD ERROR

006556  020412                  A0063:  CMP     R4,(R2)         ;IS RESULT STILL = 125252 ?
006560  001403                          BEQ     T0064           ;BR IF YES

006562  011203                          MOV     (R2),R3         ;GET THE WAS DATA
006564  000000                  E20063: HALT                    ;CMP ALTERED [DEST]
006566  000763                          BR      R0063           ;LOCK ON HARD ERROR
```

```
                                ; ***************************************************************
                                        .SBTTL T0064 BASIC "CMP  R,@#A" WITH [R] NOT EQUAL TO [A]
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [163,264,266,267,224,367,375,016] FC 1,3,8

                                ;ACT BUTS:      37[004]100,163 / 33[266]220,224 / 16[367]016,016

                                ;EXEC:          [224]ALUC=LLHHL :[367]D=052526

                                ;CODES:         [367] SPS=3  /  N:C=1000

                                ;SYNC:          BOSJ2 (-)       /       T= 3.5 USEC

                                ;KEY SIG:       K3-3 MOVL  /  K3-3 SM=0L  /  K3-3 DM=3L  /  K3-8 BIT+CMP+TSTH

006570  012700  000064          T0064:  MOV     #0064,R0                ;LOAD R0 WITH TEST NO.
006574  112760  000377  070162          MOVB    #377,STAB1(R0)  ;SET FLAG FOR THIS TEST IN MISSED TABLE
006602  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
006606  012704  125252                  MOV     #125252,R4      ;MAKE RESULT S / B = 125252
006612  005005                  R0064:  CLR     R5              ;[R5] = SOURCE OP = 000000
006614  010412                          MOV     R4,(R2)         ;MAKE [DEST] = 125252
006616  000277                          SCC                     ;SCOPE SYNC - MAKE Z=1

006620  020537  067602          T0064:  CMP     R5,@#MBUF0      ;TEST THE CMP

006624  001002                          BNE     T0065           ;BR IF Z=0 - IT SHOULD BE

006626  000000                  E0064:  HALT                    ;CMP FAILED TO CLEAR "Z"
006630  000770                          BR      R0064           ;LOCK ON HARD ERROR
```

```
                                        ; ***************************************************************
                                                .SBTTL T0065 BASIC "CMP  #N,@#A" TEST WITH [A] = N
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [142,240,250,163,264,265,266,267,225,367,375,016] FC 1,2,3,8

                                        ;ACT BUTS:      37[004]100,142 / 35[240]120,163 / 33[266]220,225 / 16[367]016,016

                                        ;EXEC:          [225]ALUC=LLHHL :[367]D=000000

                                        ;CODES:         [367] SPS=3  /  N:C=0100

                                        ;SYNC:          B05J2 (-)       /       T= 4.3 USEC

                                        ;KEY SIG:       K3-3 CMPL  /  K3-3 SM=2L  /  K3-3 DM=3L  /  K5-2 PS(Z)(1)H
                                                        ;  K3-8 BIT+CMP+TSTH

006632  012700  000065          T0065:  MOV     #0065,R0                ;LOAD R0 WITH TEST NO.
006636  112760  000377  070162          MOVB    #377,STAB1(R0)  ;SET FLAG FOR THIS TEST IN MISSED TABLE
006644  012704  125252                  MOV     #125252,R4      ;RESULT S / B = 125252
006650  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
006654  010412                  R0065:  MOV     R4,(R2)         ;MAKE [DEST] = 125252
006656  000257                          CCC                     ;SCOPE SYNC - Z=0

006660  022737  125252  067602  I0065:  CMP     #125252,@#MBUF0 ;TEST THE CMP

006666  001402                          BEQ     T0066           ;BR IF Z=1 - IT SHOULD BE

006670  000000                  E0065:  HALT                    ;CMP FAILED TO SET "Z"
006672  000770                          BR      R0065           ;LOCK ON HARD ERROR
```

```
                                ; ***************************************************************
                                        .SBTTL T0066 BASIC "CMP  #N,@#A" TEST WITH [A] NOT EQUAL TO #N
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [142,240,250,163,264,265,266,267,225,367,375,016] FC 1,2,3,8

                                ;ACT BUTS:      37[004]100,142 / 35[240]120,163 / 33[266]220,225 / 16[367]016,016

                                ;EXEC:          [225]ALUC=LLHHL :[367]D=125252

                                ;CODES:         [367] SPS=3  /  N:C=1000

                                ;SYNC:          BOSJ2 (-)       /       T= 4.3 USEC

                                ;KEY SIG:       K3-3 CMPL  /  K3-3 SM=2L  /  K3-3 DM=3L  /  K5-2 PS(N)(1)H
                                                ;  K3-8 BIT+CMP+TSTH

006674  012700  000066          T0066:  MOV     #0066,R0                ;LOAD R0 WITH TEST NO.
006700  112760  000377  070162          MOVB    #377,STAB1(R0)  ;SET FLAG FOR THIS TEST IN MISSED TABLE
006706  012704  125252                  MOV     #125252,R4      ;RESULT S / B=125252
006712  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
006716  005012                  R0066:  CLR     (R2)            ;MAKE [DEST] = 000000
006720  000277                          SCC                     ;SCOPE SYNC - Z=1

006722  022737  125252  067602  I0066:  CMP     #125252,@#MBUF0 ;TEST THE CMP

006730  001002                          BNE     T0067           ;BR IF Z=0 - IT SHOULD BE

006732  000000                  E0066:  HALT                    ;CMP FAILED TO CLEAR "Z"
006734  000770                          BR      R0066           ;LOCK ON HARD ERROR
```

```
                                        ; ***************************************************************
                                                .SBTTL T0067 BASIC "BIS #N,@#A" TEST - N=177777,[A]=000000
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [142,240,250,163,264,265,266,267,225,367,375,016] FC 1,3,8

                                        ;ACT BUTS:      37[004]100,142 / 35[240]120,163 / 33[266]220,225 / 16[367]016,016

                                        ;EXEC:          [225]ALUC LLLLH :[367]D=177777

                                        ;CODES:         [367] SPS=3  /  N:C=1000

                                        ;SYNC:          BOSJ2 (-)       /       T= 4.3 USEC

                                        ;KEY SIG:       K3-5 DOPL  /  K3-3 DM=3L  /  K3-3 BIS L

006736  012700  000067          T0067:  MOV     #0067,R0                ;LOAD R0 WITH TEST NO.
006742  112760  000377  070162          MOVB    #377,STAB1(R0)  ;SET FLAG FOR THIS TEST IN MISSED TABLE
006750  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
006754  012704  177777                  MOV     #-1,R4          ;RESULT S / B = 177777
006760  005012                  R0067:  CLR     (R2)            ;[DEST] = 000000
006762  000257                          CCC                     ;SCOPE SYNC

006764  052737  177777  067602  I0067:  BIS     #-1,@#MBUF0     ;TEST THE BIS

006772  020412                          CMP     R4,(R2)         ;RESULT OK?
006774  001403                          BEQ     T0070           ;OR IF YES

006776  011203                          MOV     (R2),R3         ;GET WAS DATA
007000  000000                  E0067:  HALT                    ;BIS FAILED TO SET ALL BITS IN BITFLG
007002  000766                          BR      R0067           ;LOCK ON HARD ERROR
```

```
                                ; ***************************************************************
                                        .SBTTL T0070 BASIC "BIC  #N,@#A" TEST
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [142,240,250,163,264,265,266,267,225,367,375,016] FC 1,2,3,8

                                ;ACT BUTS:      37[004]100,142 / 35[240]120,163 / 33[266]220,225 / 16[367]016,016

                                ;EXEC:          [225]ALUC=HLLHL :[367]D=000077

                                ;CODES:         [367] SPS=3  /  N:C=0000

                                ;SYNC:          B05J2 (-)       /       T= 4.3 USEC

                                ;KEY SIG:       K3-3 BICL  /  K3-3 SM=2L  /  K3-3 DM=3L

007004  012700  000070          T0070:  MOV     #0070,R0                ;LOAD R0 WITH TEST NO.
007010  112760  000377  070162          MOVB    #377,STAB1(R0)  ;SET FLAG FOR THIS TEST IN MISSED TABLE
007016  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
007022  012704  000077                  MOV     #77,R4          ;RESULT S / B = 77
007026  012712  177777          R0070:  MOV     #-1,(R2)        ;MAKE [DEST] = 177777
007032  000257                          CCC                     ;SCOPE SYNC

007034  042737  177700  067602  I0070:  BIC     #177700,@#MBUF0 ;TEST THE BIC

007042  020412                          CMP     R4,(R2)         ;DID RESULT = 77 ?
007044  001403                          BEQ     T0071           ;BR IF YES

007046  011203                          MOV     (R2),R3         ;GET THE WAS DATA
007050  000000                  E0070:  HALT                    ;BIC DELIVERED THE WRONG RESULT
007052  000765                          BR      R0070           ;LOCK ON HARD ERROR
```

```
                                ; ***********************************************************************
                                        .SBTTL T0071 BASIC "BIC #N,R" TEST
                                ; ***********************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [142,240,250,120,371,360,000] FC 1,2,8

                                ;ACT BUTS:      35[240]120,120 / 31[120]360,360 / 27[371]000,000

                                ;EXEC:          [371]ALUC MLLHL :[360]D=377

                                ;CODES:         [360] SPS=3  /  N:C=0000

                                ;SYNC:          BOSJ2 (-)       /       T= 4.3 USEC

                                ;KEY SIG:       K3-5 DOPL  /  K3-3 DM=0L  /  K3-3 BIC L

007054  012700  000071          T0071:  MOV     #0071,R0                ;LOAD R0 WITH TEST NO.
007060  112760  000377  070162          MOVB    #377,STAB1(R0)  ;SET FLAG FOR THIS TEST IN MISSED TABLE
007066  012704  000377                  MOV     #377,R4         ;RESULT S / B = 377
007072  012702  177703                  MOV     #177703,R2      ;DEST ADDR = R3
007076  005003                  R0071:  CLR     R3              ;[DEST] = 177777
007100  005103                          COM     R3
007102  000257                          CCC                     ;SCOPE SYNC

007104  042703  177400          I0071:  BIC     #177400,R3      ;TEST THE BIC

007110  020304                          CMP     R3,R4           ;RESULT OK?
007112  001402                          BEQ     T0072           ;BR IF YES

007114  000000                  E0071:  HALT                    ;BIC FAILED TO CLEAR HI-BYTE
007116  000767                          BR      R0071           ;LOCK ON HARD ERROR
```

```
                                        ; ***********************************************************************
                                                .SBTTL T0072 BASIC "BIC #N,2(SP)" TEST
                                        ; ***********************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [142,240,250,167,261,262,266,267,225,367,375,016] FC 1,2,3,8

                                        ;ACT BUTS:      37[004]100,142 / 35[250]120,167 / 17[167]262,262 / 33[266]220,225
                                                        ; / 16[367]016,016

                                        ;EXEC:          [225]ALUC HLLHL :[367]D=357

                                        ;CODES:         [367] SPS=3  /  N:C=0000

                                        ;SYNC:          BOSJ2 (-)       /       T= 3.3 USEC

                                        ;KEY SIG:       K3-5 DOPL  /  K3-3 DM=6  /  K3-3 BIC L

007120  012700  000072                  T0072:  MOV     #0072,R0                ;LOAD R0 WITH TEST NO.
007124  112760  000377  070162                  MOVB    #377,STAB1(R0)  ;SET FLAG FOR THIS TEST IN MISSED TABLE
007132  012704  000357                          MOV     #357,R4         ;RESULT S / B = 357
007136  010605                                  MOV     SP,R5           ;SAVE SP
007140  010506                          R0072:  MOV     R5,SP           ;RESET SP FOR ERROR LOOP
007142  012746  000377                          MOV     #377,-(SP)      ;[DEST] = 377 PUT ON STACK
007146  005746                                  TST     -(SP)           ;DECREMENT SP
007150  000257                                  CCC                     ;SCOPE SYNC

007152  042766  000020  000002          I0072:  BIC     #20,2(SP)       ;TEST THE BIC - CLEAR BIT 4

007160  010602                                  MOV     SP,R2           ;[R2] = DEST ADDR
007162  005722                                  TST     (R2)+
007164  020412                                  CMP     R4,(R2)         ;RESULT = 357?
007166  001403                                  BEQ     A0072           ;BR IF YES

007170  011203                                  MOV     (R2),R3         ;GET WAS DATA
007172  000000                          E0072:  HALT                    ;BIC FAILED TO CLR BIT2 OF DEST
007174  000761                                  BR      R0072           ;LOCK ON HARD ERROR

007176  010506                          A0072:  MOV     R5,SP
```

```
                                        ; ***************************************************************
                                                .SBTTL T0073 BASIC "BIT  #N,@#A" WITH BIT SET IN "A"
                                        ; ***************************************************************

                                        ;MICRO PROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [142,240,250,163,264,265,266,267,225,367,375,016] FC 1,2,3,8

                                        ;ACT BUTS:      37[004]100,142 / 35[240]120,163 / 33[266]220,225 / 16[367]016,016

                                        ;EXEC:          [225]ALUC=HHLHH :[367]D=040000

                                        ;CODES:         [367] SPS=3  /  N:C=0000

                                        ;SYNC:          B05J2 (-)       /       T= 4.3 USEC

                                        ;KEY SIG:       K3-3 BITL  /  K3-3 SM=2L  /  K3-3 DM=3L  /  K3-8 BIT+CMP+TSTH

007200  012700  000073          T0073:  MOV     #0073,R0                ;LOAD R0 WITH TEST NO.
007204  112760  000377  070162          MOVB    #377,STAB1(R0)  ;SET FLAG FOR THIS TEST IN MISSED TABLE
007212  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
007216  012704  040000                  MOV     #40000,R4       ;RESULT S / B = 40000
007222  010412                  R0073:  MOV     R4,(R2)         ;MAKE [DEST] = 40000
007224  000277                          SCC                     ;SCOPE SYNC - Z=1

007226  032737  040000  067602  I0073:  BIT     #40000,@#MBUF0  ;TEST THE BIT

007234  001002                          BNE     T0074           ;BR IF Z=0 - IT SHOULD BE

007236  000000                  E0073:  HALT                    ;BIT FAILED TO CLEAR "Z"
007240  000770                          BR      R0073           ;LOCK ON HARD ERROR
```

```
                                ; ***************************************************************
                                        .SBTTL T0074 BASIC "BIT  #N,@#A" WITH BIT CLEAR IN "A"
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [142,240,250,163,264,265,266,267,225,367,375,016] FC 1,2,3,8

                                ;ACT BUTS:      37[004]100,142 / 35[240]120,163 / 33[266]220,225 / 16[367]016,016

                                ;EXEC:          [225]ALUC=HHLHH :[367]D=000000

                                ;CODES:         [367] SPS=3  /  N:C=0100

                                ;SYNC:          BOSJ2 (-)       /       T= 4.3 USEC

                                ;KEY SIG:       K3-3 BITL  /  K3-3 SM=2L  /  K3-3 DM=3L  /  K3-8 BIT+CMP+TSTH
                                                ;  K5-2 PS(Z)(1)H

007242  012700  000074          T0074:  MOV     #0074,R0                ;LOAD R0 WITH TEST NO.
007246  112760  000377  070162          MOVB    #377,STAB1(R0)  ;SET FLAG FOR THIS TEST IN MISSED TABLE
007254  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
007260  005004                          CLR     R4              ;RESULT S / B = 000000
007262  005012                  R0074:  CLR     (R2)            ;MAKE [DEST] = 000000
007264  000257                          CCC                     ;SCOPE SYNC - Z=0

007266  032737  040000  067602  I0074:  BIT     #40000,@#MBUF0  ;TEST THE BIT

007274  001402                          BEQ     A0074           ;BR IF Z=1 - IT SHOULD BE

007276  000000                  E10074: HALT                    ;BIT FAILED TO SET "Z"
007300  000770                          BR      R0074           ;LOCK ON HARD ERROR

007302  020412                  A0074:  CMP     R4,(R2)         ;DID BIT DELIVER A RESULT
007304  001403                          BEQ     T0075           ;BR IF NOT

00730E  011203                          MOV     (R2),R3         ;GET THE WAS DATA
007310  000000                  E20074: HALT                    ;BIT DISTURBED THE [DEST]
007312  000763                          BR      R0074           ;LOCK ON HARD ERROR
```

```
                                ; ******************************************************************
                                        .SBTTL T0075 BASIC "ADD  #N,(R) " TEST
                                ; ******************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [142,240,250,161,266,267,225,367,375,016] FC 1,2,3,8

                                ;ACT BUTS:      37[004]100,142 / 35[240]120,161 / 33[266]220,225 / 16[367]016,016

                                ;EXEC:          [225]ALUC=LHLLH :[367]D=000004

                                ;CODES:         [367] SPS=3  /  N:C=0000

                                ;SYNC:          BOSJ2 (-)       /       T=3.4 USEC

                                ;KEY SIG:       K3-3 ADD+SUBL  /  K3-3 SM=2L  /  K3-3 DM=1L

007314  012700  000075          T0075:  MOV     #0075,R0                ;LOAD R0 WITH TEST NO.
007320  112760  000377  070162          MOVB    #377,STAB1(R0)  ;SET FLAG FOR THIS TEST IN MISSED TABLE
007326  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
007332  012704  000004                  MOV     #4,R4           ;RESULT S / B = 4
007336  012712  000002          R0075:  MOV     #2,(R2)         ;MAKE [DEST] = 2
007342  000257                          CCC                     ;SCOPE SYNC

007344  062712  000002          I0075:  ADD     #2,(R2) ;TEST THE ADD

007350  020412                          CMP     R4,(R2)         ;RESULT = 4 ?
007352  001403                          BEQ     T0076           ;BR IF YES

007354  011203                          MOV     (R2),R3         ;GET THE WAS DATA
007356  000000                  E0075:  HALT                    ;ADD DELIVERED THE WRONG RESULT
007360  000766                          BR      R0075           ;LOCK ON HARD ERROR
```

```
                                ; ***************************************************************
                                        .SBTTL T0076 BASIC "ADD  #N,X(R)" TEST
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [142,240,250,167,261,262,266,267,225,367,375,016] FC 1,2,3,8

                                ;ACT BUTS:      37[004]100,142 / 35[240]120,167 / 17[167]262,262 / 33[266]220,225
                                                ; / 16[367]016,016

                                ;EXEC:          [225]ALUC=LHLLH :[367]D=000004

                                ;CODES:         [367] SPS=3  /  N:C=0000

                                ;SYNC:          B05J2 (-)       /       T= 3.4 USEC

                                ;KEY SIG:       K3-3 ADD+SUBL  /  K3-3 SM=2L  /  K3-3 DM=6L

007362  012700  000076          T0076:  MOV     #0076,R0                ;LOAD R0 WITH TEST NO.
007366  112760  000377  070162          MOVB    #377,STAB1(R0)  ;SET FLAG FOR THIS TEST IN MISSED TABLE
007374  012704  000002                  MOV     #2,R4           ;RESULT S / B = 4
007400  012702  067604                  MOV     #MBUF0+2,R2     ;DEST ADDR = MBUF0 + 2
007404  012705  067602          R0076:  MOV     #MBUF0,R5       ;BASE DEST ADDR = MBUF0
007410  005012                          CLR     (R2)            ;MAKE [DEST] = 000000
007412  000257                          CCC                     ;SCOPE SYNC

007414  062765  000002  000002  I0076:  ADD     #2,2(R5)        ;TEST THE ADD

007422  020412                          CMP     R4,(R2)         ;RESULT = 4 ?
007424  001403                          BEQ     T0077           ;BR IF YES

007426  011203                          MOV     (R2),R3         ;GET THE WAS DATA
007430  000000                  E0076:  HALT                    ;ADD DELIVERED THE WRONG RESULT
007432  000764                          BR      R0076           ;LOOP ON HARD ERROR
```

```
                                        ; ***************************************************************
                                                .SBTTL T0077 BASIC "CMPB #N,(SP)+" TEST
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [142,240,250,162,260,267,225,367,375,016] FC 1,2,3,8

                                        ;ACT BUTS:      37[004]100,142 / 35[240]120,162 / 33[260]220,225 / 16[367]016,016

                                        ;EXEC:          [225]ALUC=LLHHL :[367]D=177400

                                        ;CODES:         [367] SPS=3  /  N:C=0100

                                        ;SYNC:          B05J2 (-)       /       T= 4 USEC

                                        ;KEY SIG:       K3-3 CMPL  /  K3-3 DM=2L  /  K3-6 BYTE INSTR H

007434  012700  000077          T0077:  MOV     #0077,R0                ;LOAD R0 WITH TEST NO.
007440  112760  000377  070162          MOVB    #377,STAB1(R0)  ;SET FLAG FOR THIS TEST IN MISSED TABLE
007446  032737  000002  066642          BIT     #2,@#BPTLOC     ;BREAKPOINT HALT SET ??
007454  001401                          BEQ     .+4             ;BR IF NOT
007456  000000                          HALT                    ;BREAK - DEPRESS CONTINUE TO RESTART
007460  012704  177400                  MOV     #177400,R4      ;RESULT S / B = 177400
007464  010605                          MOV     SP,R5           ;SAVE SP
007466  010602                          MOV     SP,R2           ;SET UP DEST ADDR
007470  005742                          TST     -(R2)           ;R2 CONTAINS DEST ADDR
007472  010506                  R0077:  MOV     R5,SP           ;RESET SP FOR ERROR LOOP
007474  010446                          MOV     R4,-(SP)        ;MAKE [DEST] = 177400
007476  000257                          CCC                     ;SCOPE SYNC - "Z" = 0

007500  122726  000000          I0077:  CMPB    #0,(SP)+        ;TEST THE CMPB

007504  001403                          BEQ     A0077           ;BR IF "Z" SET - IT SHOULD BE

007506  011203                          MOV     (R2),R3         ;GET WAS DATA
007510  000000                  E10077: HALT                    ;CMPB FAILED TO SET "Z"
007512  000767                          BR      R0077           ;LOCK ON HARD ERROR

007514  020506                  A0077:  CMP     R5,SP           ;DID SP GET UPDATED BY 2?
007516  001402                          BEQ     B0077           ;BR IF YES

007520  000000                  E20077: HALT                    ;CMPB FAILED TO UPDATE SP PROPERLY
007522  000763                          BR      R0077           ;LOCK ON HARD ERROR

007524  020412                  B0077:  CMP     R4,(R2)         ;[DEST] ALTERED?
007526  001403                          BEQ     T0100           ;BR IF NOT

007530  011203                          MOV     (R2),R3         ;GET WAS DATA
007532  000000                  E30077: HALT                    ;CMPB MODIFIED [DEST]
007534  000756                          BR      R0077           ;LOCK ON HARD ERROR.
```

```
                                ; ***************************************************************
                                        .SBTTL T0100 BASIC "CMPB (RA)+,(RB)+" - SRC AND DEST EVEN
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [142,240,250,162,260,267,225,367,375,016] FC 1,2,3,8

                                ;ACT BUTS:      37[004]100,142 / 35[240]120,162 / 33[260]220,225 / 16[367]016,016

                                ;EXEC:          [225]ALUC=LLHHL :[326]D=177400

                                ;CODES:         [367] SPS=3  /  N:C=0100

                                ;SYNC:          B05J2 (-)       /       T= 4.5 USEC

                                ;KEY SIG:       K3-3 CMPL  /  K3-3 DM=2L  /  K3-6 BYTE INSTR H

007536  012700  000100          T0100:  MOV     #0100,R0                ;LOAD R0 WITH TEST NO.
007542  112760  000377  070162          MOVB    #377,STAB1(R0)  ;SET FLAG FOR THIS TEST IN MISSED TABLE
007550  012704  177777                  MOV     #-1,R4          ;RESULT S / B = 177777
007554  012702  067614                  MOV     #DWTA+2,R2      ;DEST ADDR = DWTA+2
007560  012705  067620          R0100:  MOV     #DWTA+6,R5      ;SRC ADDR = DWTA+6
007564  010203                          MOV     R2,R3           ;R3 GETS DEST ADDR
007566  000257                          CCC                     ;SCOPE SYNC

007570  122523                  I0100:  CMPB    (R5)+,(R3)+     ;TEST THE CMPB

007572  001402                          BEQ     A0100           ;BR IF "Z" = 1 - IT SHOULD BE

007574  000000                  E10100: HALT                    ;CMPB FAILED TO SET "Z"
007576  000770                          BR      R0100           ;LOCK ON HARD ERROR

007600  022703  067615          A0100:  CMP     #DWTA+3,R3      ;DID DEST REG GET UPDATED?
007604  001402                          BEQ     B0100           ;BR IF YES

007606  000000                  E20100: HALT                    ;CMPB FAILED TO UPDATE DEST REG
007610  000763                          BR      R0100           ;LOCK ON HARD ERROR

007612  022705  067621          B0100:  CMP     #DWTA+7,R5      ;DID SRC REG GET UPDATED?
007616  001402                          BEQ     C0100           ;BR IF YES

007620  000000                  E30100: HALT                    ;CMPB FAILED TO UPDATE SRC REG
007622  000756                          BR      R0100           ;LOCK ON HARD ERROR

007624  020412                  C0100:  CMP     R4,(R2)         ;DID [DEST] GET ALTERED?
007626  001404                          BEQ     T0101           ;BR IF NOT

007630  011203                          MOV     (R2),R3         ;GET WAS DATA
007632  000000                  E40100: HALT                    ;CMPB DELIVERED A RESULT
007634  010412                          MOV     R4,(R2)         ;RESTORE [DEST]
007636  000750                          BR      R0100           ;LOCK ON HARD ERROR
```

```
                                        ; ***********************************************************************
                                                .SBTTL T0101 BASIC "CMPB (RA)+,(RB)+" - SRC AND DEST ODD
                                        ; ***********************************************************************

                                /       ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [142,240,250,137,251,162,260,267,237,270,231,254,074,366,375,016] FC 1,2

                                        ;ACT BUTS:      37[004]100,142 / 35[240]120,137 / 36[137]120,162 / 33[260]220,237
                                                        ; / 34[237]220,231 / 16[366]016,016

                                        ;EXEC:          [231]ALUC=LLHHL :[254]D=000000

                                        ;CODES:         [074] SPS=3  /  N:C=0100

                                        ;SYNC:          B05J2 (-)       /       T= 4.5 USEC

                                        ;KEY SIG:       K3-3 CMPL  /  K3-3 DM=2L  /  K3-6 BYTE INSTR H

007640  012700  000101          T0101:  MOV     #0101,R0                ;LOAD R0 WITH TEST NO.
007644  112760  000377  070162          MOVB    #377,STAB1(R0)  ;SET FLAG FOR THIS TEST IN MISSED TABLE
007652  012704  177777                  MOV     #-1,R4          ;RESULT S / B = 177777
007656  012702  067614                  MOV     #DWTA+2,R2      ;DEST ADDR = DWTA+2
007662  012705  067617          R0101:  MOV     #DWTA+5,R5      ;SRC ADDR = DWTA+5
007666  012703  067615                  MOV     #DWTA+3,R3      ;R3 GETS DEST ADDR+1
007672  000257                          CCC                     ;SCOPE SYNC

007674  122523                  I0101:  CMPB    (R5)+,(R3)+     ;TEST THE CMPB

007676  001402                          BEQ     A0101           ;BR IF "Z" = 1 - IT SHOULD BE

007700  000000                  E10101: HALT                    ;CMPB FAILED TO SET "Z"
007702  000767                          BR      R0101           ;LOCK ON HARD ERROR

007704  022703  067616          A0101:  CMP     #DWTA+4,R3      ;DID DEST REG GET UPDATED?
007710  001402                          BEQ     B0101           ;BR IF YES

007712  000000                  E20101: HALT                    ;CMPB FAILED TO UPDATE DEST REG
007714  000762                          BR      R0101           ;LOCK ON HARD ERROR

007716  022705  067620          B0101:  CMP     #DWTA+6,R5      ;DID SRC REG GET UPDATED?
007722  001402                          BEQ     C0101           ;BR IF YES

007724  000000                  E30101: HALT                    ;CMPB FAILED TO UPDATE SRC REG
007726  000755                          BR      R0101           ;LOCK ON HARD ERROR

007730  020412                  C0101:  CMP     R4,(R2)         ;DID [DEST] GET ALTERED?
007732  001404                          BEQ     T0102           ;BR IF NOT

007734  011203                          MOV     (R2),R3         ;GET WAS DATA
007736  000000                  E40101: HALT                    ;CMPB DELIVERED A RESULT
007740  010412                          MOV     R4,(R2)         ;RESTORE [DEST]
007742  000747                          BR      R0101           ;LOCK ON HARD ERROR
```

```
                                        ; ***********************************************************************
                                                .SBTTL T0102 BASIC "CMPB (RA)+,(RB)+" - SRC / EVEN,DEST / ODD
                                        ; ***********************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [142,240,250,162,260,267,237,270,231,254,074,366,375,016] FC 1,2,3,8

                                        ;ACT BUTS:      37[004]100,142 / 35[240]120,162 / 33[260]220,237 / 34[237]220,231
                                                        ; / 16[366]016,016

                                        ;EXEC:          [231]ALUC=LLHH  :[367]D=000400

                                        ;CODES:         [074] SPS=8  /  N:C=0100

                                        ;SYNC:          BOSJ2 (-)  /     /       T= 4.5 USEC

                                        ;KEY SIG:       K3-3 CMPL  /  K3-3 DM=2  /  K3-6 BYTE INSTR H

007744  012700  000102                  T0102:  MOV     #0102,R0                ;LOAD R0 WITH TEST NO.
007750  112760  000377  070162                  MOVB    #377,TAB1(R0)   ;SET FLAG FOR THIS TEST IN MISSED TABLE
007756  012704  177400                          MOV     #177400,R4      ;RESULT S / B = 177400
007762  012702  067616                          MOV     #DWTA+4,R2      ;DEST ADDR = DWTA+4
007766  012705  067620                  R0102:  MOV     #DWTA+6,R5      ;SRC ADDR = DWTA+6
007772  012703  067617                          MOV     #DWTA+5,R3      ;R3 GETS DEST ADDR
007776  000257                                  CCC                     ;SCOPE SYNC

010000  122523                          I0102:  CMPB    (R5)+,(R3)+     ;TEST THE CMPB

010002  001402                                  BEQ     A0102           ;BR IF "Z" = 1 - IT SHOULD BE

010004  000000                          E10102: HALT                    ;CMPB FAILED TO SET "Z"
010006  000767                                  BR      R0102           ;LOCK ON HARD ERROR

010010  022703  067620                  A0102:  CMP     #DWTA+6,R3      ;DID DEST REG GET UPDATED?
010014  001402                                  BEQ     B0102           ;BR IF YES

010016  000000                          E20102: HALT                    ;CMPB FAILED TO UPDATE DEST REG
010020  000762                                  BR      R0102           ;LOCK ON HARD ERROR

010022  022705  067621                  B0102:  CMP     #DWTA+7,R5      ;DID SRC REG GET UPDATED?
010026  001402                                  BEQ     C0102           ;BR IF YES

010030  000000                          E30102: HALT                    ;CMPB FAILED TO UPDATE SRC REG
010032  000755                                  BR      R0102           ;LOCK ON HARD ERROR

010034  020412                          C0102:  CMP     R4,(R2)         ;DID [DEST] GET ALTERED?
010036  001404                                  BEQ     T0103           ;BR IF NOT

010040  011203                                  MOV     (R2),R3         ;GET WAS DATA
010042  000000                          E40102: HALT                    ;CMPB DELIVERED A RESULT
010044  010412                                  MOV     R4,(R2)         ;RESTORE [DEST]
010046  000747                                  BR      R0102           ;LOCK ON HARD ERROR
```

```
                                        ; ***************************************************************
                                                .SBTTL T0103 BASIC "CMPB (RA)+,(RB)+" - SRC / ODD,DEST / EVEN
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [142,240,250,137,251,162,260,267,225,367,375,016] FC 1,2,3,8

                                        ;ACT BUTS:      37[004]100,142 / 35[240]120,137 / 36[137]120,162 / 33[260]220,225
                                                        ; / 16[367]016,016

                                        ;EXEC:          [225]ALUC=LLHHL :[367]D=000000

                                        ;CODES:         [367] SPS=3  /  N:C=0100

                                        ;SYNC:          BOSJ2 (-)       /       T= 4.5 USEC

                                        ;KEY SIG:       K3-3 CMPL  /  K3-3 DM=2  /  K3-6 BYTE INSTR H

010050  012700  000103          T0103:  MOV     #0103,R0                ;LOAD R0 WITH TEST NO.
010054  112760  000377  070162          MOVB    #377,STAB1(R0)  ;SET FLAG FOR THIS TEST IN MISSED TABLE
010062  012704  177777                  MOV     #-1,R4          ;RESULT S / B = 177777
010066  012702  067614                  MOV     #DWTA+2,R2      ;DEST ADDR = DWTA+2
010072  012705  067617          R0103:  MOV     #DWTA+5,R5      ;SRC ADDR = DWTA+5
010076  010203                          MOV     R2,R3           ;R3 GETS DEST ADDR
010100  000257                          CCC                     ;SCOPE SYNC

010102  122523                  I0103:  CMPB    (R5)+,(R3)+     ;TEST THE CMPB

010104  001402                          BEQ     A0103           ;BR IF "Z" = 1 - IT SHOULD BE

010106  000000                  E10103: HALT                    ;CMPB FAILED TO SET "Z"
010110  000770                          BR      R0103           ;LOCK ON HARD ERROR

010112  022703  067615          A0103:  CMP     #DWTA+3,R3      ;DID DEST REG GET UPDATED?
010116  001402                          BEQ     B0103           ;BR IF YES

010120  000000                  E20103: HALT                    ;CMPB FAILED TO UPDATE DEST REG
010122  000763                          BR      R0103           ;LOCK ON HARD ERROR

010124  022705  067620          B0103:  CMP     #DWTA+6,R5      ;DID SRC REG GET UPDATED?
010130  001402                          BEQ     C0103           ;BR IF YES

010132  000000                  E30103: HALT                    ;CMPB FAILED TO UPDATE SRC REG
010134  000756                          BR      R0103           ;LOCK ON HARD ERROR

010136  020412                  C0103:  CMP     R4,(R2)         ;DID [DEST] GET ALTERED?
010140  001404                          BEQ     T0104           ;BR IF NOT

010142  011203                          MOV     (R2),R3         ;GET WAS DATA
010144  000000                  E40103: HALT                    ;CMPB DELIVERED A RESULT
010146  010412                          MOV     R4,(R2)         ;RESTORE [DEST]
010150  000750                          BR      R0103           ;LOCK ON HARD ERROR
```

```
                                        ; ***************************************************************
                                                .SBTTL T0104 BASIC "MOVB (RA)+,X(RB) - SRC EVEN / DEST EVEN
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [142,240,250,177,206,212,202,205,125,375,016] FC 1,2,4

                                        ;ACT BUTS:      37[004]100,142 / 35[240]120,177 / 17[177]212,212 / 21[206]200,202
                                                        ; / 16[125]016,016

                                        ;EXEC:          [205]ALUC=LLLLL :[125]D=000000

                                        ;CODES:         [125] SPS=3  /  N:C=0100

                                        ;SYNC:          B05J2 (-)       /       T=4.5 USEC

                                        ;KEY SIG:       K3-3 MOVL  /  K3-3 DM=6L  /  K3-5 DOPL  /  K5-2 PS(Z)(1)H
                                                        ;  K3-6 BYTE INSTR H

010152  012700  000104          T0104:  MOV     #0104,R0                ;LOAD R0 WITH TEST NO.
010156  112760  000377  070162          MOVB    #377,STAB1(R0)  ;SET FLAG FOR THIS TEST IN MISSED TABLE
010164  012702  067606                  MOV     #MBUF1,R2       ;DEST ADDR = MBUF1
010170  012703  067602                  MOV     #MBUF0,R3       ;BASE DEST ADDR = MBUF0
010174  012704  177400                  MOV     #177400,R4      ;RESULT S / B = 177400
010200  012705  070152          R0104:  MOV     #DBTA,R5        ;SRC ADDR = DBTA
010204  012712  177777                  MOV     #-1,(R2)        ;[DEST] = 177777
010210  000257                          CCC                     ;SCOPE SYNC

010212  112563  000004          I0104:  MOVB    (R5)+,4(R3)     ;TEST THE MOVB

010216  020412                          CMP     R4,(R2)         ;RESULT OK?
010220  001403                          BEQ     A0104           ;BR IF YES

010222  011203                          MOV     (R2),R3         ;GET WAS DATA
010224  000000          E10104: HALT                            ;MOV DELIVERED WRONG RESULT
010226  000764                          BR      R0104           ;LOCK ON HARD ERROR

010230  022705  070153          A0104:  CMP     #DBTA+1,R5      ;DID SRC REG GET INCREMENTED BY +1
010234  001402                          BEQ     T0105           ;BR IF YES

010236  000000          E20104: HALT                            ;MOVB FAILED TO UPDATE SRC REG
010240  000757                          BR      R0104           ;LOCK ON HARD ERROR
```

```
                                        ; ***********************************************************************
                                                .SBTTL T0105 BASIC "MOVB (RA)+,X(RB) - SRC ODD / DEST ODD
                                        ; ***********************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [142,240,250,137,251,177,206,212,202,205,125,375,016] FC 1,2,4

                                        ;ACT BUTS:      37[004]100,142 / 35[240]120,137 / 36[137]120,177 / 17[177]212,212
                                                        ; / 21[206]200,202 / 16[125]016,016

                                        ;EXEC:          [205]ALUC=LLLLL :[125]D=177777

                                        ;CODES:         [125] SPS=3  /  N:C=1000

                                        ;SYNC:          BOSJ2 (-)       /       T=4.5 USEC

                                        ;KEY SIG:       K3-3 MOVL  /  K3-3 DM=6L  /  K3-5 DOPL  /  K5-2 PS (N)(1) H
                                                        ;  K3-6 BYTE INSTR H

010242  012700  000105          T0105:  MOV     #0105,R0                ;LOAD R0 WITH TEST NO.
010246  112760  000377  070162          MOVB    #377,STAB1(R0)  ;SET FLAG FOR THIS TEST IN MISSED TABLE
010254  012702  067606                  MOV     #MBUF1,R2       ;DEST ADDR = MBUF1
010260  012703  067602                  MOV     #MBUF0,R3       ;BASE DEST ADDR = MBUF0
010264  012704  000777                  MOV     #777,R4         ;RESULT S / B = 777
010270  012705  070157          R0105:  MOV     #DBTB+1,R5      ;SRC ADDR = DBTB+1
010274  012712  177777                  MOV     #-1,(R2)        ;[DEST] = 177777
010300  000257                          CCC                     ;SCOPE SYNC

010302  112563  000005          I0105:  MOVB    (R5)+,5(R3)     ;TEST THE MOVB

010306  020412                          CMP     R4,(R2)         ;RESULT OK?
010310  001403                          BEQ     A0105           ;BR IF YES

010312  011203                          MOV     (R2),R3         ;GET WAS DATA
010314  000000          E10105: HALT                            ;MOV DELIVERED WRONG RESULT
010316  000764                          BR      R0105           ;LOCK ON HARD ERROR

010320  022705  070160          A0105:  CMP     #DBTB+2,R5      ;DID SRC REG GET INCREMENTED BY +1
010324  001402                          BEQ     T0106           ;BR IF YES

010326  000000          E20105: HALT                            ;MOVB FAILED TO UPDATE SRC REG
010330  000757                          BR      R0105           ;LOCK ON HARD ERROR
```

```
                                ; ***************************************************************
                                        .SBTTL T0106 BASIC "MOVB (RA)+,X(RB) - SRC EVEN / DEST ODD
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [142,240,250,177,206,212,202,205,125,375,016] FC 1,2,4

                                ;ACT BUTS:      37[004]100,142 / 35[240]120,177 / 17[177]212,212 / 21[206]200,202
                                                ; / 16[125]016,016

                                ;EXEC:          [205]ALUC=LLLLL :[125]D=177777

                                ;CODES:         [125] SPS=3  /  N:C=1000

                                ;SYNC:          BOSJ2 (-)       /       T=4.5 USEC

                                ;KEY SIG:       K3-3 MOVL  /  K3-3 DM=6L  /  K3-5 DOPL  /  K5-2 PS (N)(1) H
                                                ;  K3-6 BYTE INSTR

010332  012700  000106          T0106:  MOV     #0106,R0                ;LOAD R0 WITH TEST NO.
010336  112760  000377  070162          MOVB    #377,STAB1(R0)  ;SET FLAG FOR THIS TEST IN MISSED TABLE
010344  012702  067606                  MOV     #MBUF1,R2       ;DEST ADDR = MBUF1
010350  012703  067602                  MOV     #MBUF0,R3       ;BASE DEST ADDR = MBUF0
010354  012704  000377                  MOV     #377,R4         ;RESULT S / B = 377
010360  012705  070152          R0106:  MOV     #DBTA,R5        ;SRC ADDR = DBTA
010364  012712  177777                  MOV     #-1,(R2)        ;[DEST] = 177777
010370  000257                          CCC                     ;SCOPE SYNC

010372  112563  000005          T0106:  MOVB    (R5)+,5(R3)     ;TEST THE MOVB

010376  020412                          CMP     R4,(R2)         ;RESULT OK?
010400  001403                          BEQ     A0106           ;BR IF YES

010402  011203                          MOV     (R2),R3         ;GET WAS DATA
010404  000000          E10106: HALT                            ;MOV DELIVERED WRONG RESULT
010406  000764                          BR      R0106           ;LOCK ON HARD ERROR

010410  022705  070153          A0106:  CMP     #DBTA+1,R5      ;DID SRC REG GET INCREMENTED BY +1
010414  001402                          BEQ     T0107           ;BR IF YES

010416  000000          E20106: HALT                            ;MOVB FAILED TO UPDATE SRC REG
010420  000757                          BR      R0106           ;LOCK ON HARD ERROR
```

```
                                ; ***************************************************************
                                        .SBTTL T0107 BASIC "MOVB (RA)+,X(RB) - SRC ODD / DEST EVEN
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [142,240,250,137,251,177,206,212,202,205,125,375,016] FC 1,2,4

                                ;ACT BUTS:      37[004]100,142 / 35[240]120,137 / 36[137]120,177 / 17[177]212,212
                                                ; / 21[206]200,202 / 16[125]016,016

                                ;EXEC:          [205]ALUC=LLLLL :[125]D=001001

                                ;CODES:         [125] SPS=3  /  N:C=0000

                                ;SYNC:          BOSJ2 (-)       /       T=4.5 USEC

                                ;KEY SIG:       K3-3 MOVL  /  K3-3 DM=6L  /  K3-5 DOPL  /  K3-6 BYTE INSTR H

010422  012700  000107          T0107:  MOV     #0107,R0                ;LOAD R0 WITH TEST NO.
010426  112760  000377  070162          MOVB    #377,STAB1(R0)  ;SET FLAG FOR THIS TEST IN MISSED TABLE
010434  012702  067606                  MOV     #MBUF1,R2       ;DEST ADDR = MBUF1
010440  012703  067602                  MOV     #MBUF0,R3       ;BASE DEST ADDR = MBUF0
010444  012704  177401                  MOV     #177401,R4      ;RESULT S / B = 177401
010450  012705  070157          R0107:  MOV     #DBTB+1,R5      ;SRC ADDR = DBTB+1
010454  012712  177777                  MOV     #-1,(R2)        ;[DEST] = 177777
010460  000257                          CCC                     ;SCOPE SYNC

010462  112563  000004          I0107:  MOVB    (R5)+,4(R3)     ;TEST THE MOVB

010466  020412                          CMP     R4,(R2)         ;RESULT OK?
010470  001403                          BEQ     A0107           ;BR IF YES

010472  011203                          MOV     (R2),R3         ;GET WAS DATA
010474  000000          E10107: HALT                            ;MOV DELIVERED WRONG RESULT
010476  000764                          BR      R0107           ;LOCK ON HARD ERROR

010500  022705  070160          A0107:  CMP     #DBTB+2,R5      ;DID SRC REG GET INCREMENTED BY +1
010504  001402                          BEQ     T0110           ;BR IF YES

010506  000000          E20107: HALT                            ;MOVB FAILED TO UPDATE SRC REG
010510  000757                          BR      R0107           ;LOCK ON HARD ERROR
```

```
                                ; ***********************************************************************
                                        .SBTTL T0110 BASIC "MOVB 2(RA),(RB)+" TEST - SRC EVEN / DEST EVEN
                                ; ***********************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [146,241,242,247,250,172,257,202,205,125,375,016] FC 1,2,4

                                ;ACT BUTS:      37[004]100,146 / 35[247]120,172 / 22[172]200,202 / 16[125]016,016

                                ;EXEC:          [205]ALUC=LLLLL :[125]D=001001

                                ;CODES:         [125] SPS=3  /  N:C=0000

                                ;SYNC:          BOSJ2 (-)       /       T=4.2 USEC

                                ;KEY SIG:       K3-3 MOVL  /  K3-3 DM=2L  /  K3-5 DOPL  /  K3-6 BYTE INSTR H

010512  012700  000110          T0110:  MOV     #0110,R0                ;LOAD R0 WITH TEST NO.
010516  112760  000377  070162          MOVB    #377,STAB1(R0)  ;SET FLAG FOR THIS TEST IN MISSED TABLE
010524  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
010530  012704  177401                  MOV     #177401,R4      ;RESULT S / B = 177401
010534  012705  070136                  MOV     #DWTB,R5        ;SRC ADDR = DWTB
010540  010203                  R0110:  MOV     R2,R3           ;R3 GETS DEST ADDR
010542  012713  177777                  MOV     #-1,(R3)        ;[DEST] = 177400
010546  000257                          CCC                     ;SCOPE SYNC

010550  116523  000002          I0110:  MOVB    2(R5),(R3)+     ;TEST THE MOVB

010554  020412                          CMP     R4,(R2)         ;RESULT OK?
010556  001403                          BEQ     A0110           ;BR IF YES

010560  011203                          MOV     (R2),R3         ;GET WAS DATA
010562  000000                  E10110: HALT                    ;MOVB DELIVERED WRONG RESULT
010564  000765                          BR      R0110           ;LOCK ON HARD ERROR

010566  022703  067603          A0110:  CMP     #MBUF0+1,R3     ;DID DEST REG GET INCREMENTED?
010572  001402                          BEQ     T0111           ;BR IF YES

010574  000000                  E20110: HALT                    ;MOVB FAILED TO AUTO INCREMENT DEST REG
010576  000760                          BR      R0110           ;LOCK ON HARD ERROR
```

```
                                        ; ***************************************************************
                                                .SBTTL TO111 BASIC "MOVB 2(RA),(RB)+" TEST - SRC ODD / DEST EVEN
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [146,241,242,247,250,137,251,172,257,202,205,125,375,016] FC 1,2,4

                                        ;ACT BUTS:      37[004]100,146 / 35[247]120,137 / 36[137]120,172 / 22[172]200,202
                                                        ; / 16[125]016,016

                                        ;EXEC:          [205]ALUC=LLLLL :[125]D=001001

                                        ;CODES:         [125] SPS=3  / N:C=0000

                                        ;SYNC:          BOSJ2 (-)       /       T=4.2 USEC

                                        ;KEY SIG:       K3-3 MOVL  /  K3-3 DM=2L  /  K3-5 DOPL  /  K3-6 BYTE INSTR H

010600  012700  000111          TO111:  MOV     #0111,R0                ;LOAD R0 WITH TEST NO.
010604  112760  000377  070162          MOVB    #377,STAB1(R0)  ;SET FLAG FOR THIS TEST IN MISSED TABLE
010612  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
010616  012704  177401                  MOV     #177401,R4      ;RESULT S / B = 177401
010622  012705  070156                  MOV     #DBTB,R5        ;SRC ADDR = DBTB
010626  010203                  RO111:  MOV     R2,R3           ;R3 GETS DEST ADDR
010630  012713  177777                  MOV     #-1,(R3)        ;[DEST] = 177777
010634  000257                          CCC                     ;SCOPE SYNC

010636  116523  000001          IO111:  MOVB    1(R5),(R3)+     ;TEST THE MOVB

010642  020412                          CMP     R4,(R2)         ;RESULT OK?
010644  001403                          BEQ     AO111           ;BR IF YES

010646  011203                          MOV     (R2),R3         ;GET WAS DATA
010650  000000                  EI0111: HALT                    ;MOVB DELIVERED WRONG RESULT
010652  000765                          BR      RO111           ;LOCK ON HARD ERROR

010654  022703  067603          AO111:  CMP     #MBUF0+1,R3     ;DID DEST REG GET INCREMENTED?
010660  001402                          BEQ     TO112           ;BR IF YES

010662  000000                  EI0111: HALT                    ;MOVB FAILED TO AUTO INCREMENT DEST REG
010664  000760                          BR      RO111           ;LOCK ON HARD ERROR
```

```
                                        ; ***************************************************************
                                                .SBTTL TO112 BASIC "MOVB 2(RA),(RB)+" TEST - SRC EVEN / DEST ODD
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [146,241,242,247,250,172,257,202,205,125,375,016] FC 1,2,4

                                        ;ACT BUTS:      37[004]100,146 / 35[247]120,172 / 22[172]200,202 / 16[125]016,016

                                        ;EXEC:          [205]ALUC=LLLLL :[125]D=001001

                                        ;CODES:         [125] SPS=3  /  N:C=0000

                                        ;SYNC:          BOSJ2 (-)       /       T=4.2 USEC

                                        ;KEY SIG:       K3-3 MOVL  /  K3-3 DM=2L  /  K3-5 DOPL  /  K3-6 BYTE INSTR H

010666  012700  000112                  TO112:  MOV     #0112,R0                ;LOAD R0 WITH TEST NO.
010672  112760  000377  070162                  MOVB    #377,STAB1(R0)  ;SET FLAG FOR THIS TEST IN MISSED TABLE
010700  012702  067602                          MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
010704  012704  000777                          MOV     #777,R4         ;RESULT S / B = 777
010710  012705  070136                          MOV     #DWTB,R5        ;SRC ADDR = DWTB
010714  012703  067603                  RO112:  MOV     #MBUF0+1,R3     ;R3 GETS DEST ADDR
010720  012712  177777                          MOV     #-1,(R2)        ;[DEST] = 177777
010724  000257                                  CCC                     ;SCOPE SYNC

010726  116523  000002                  IO112:  MOVB    2(R5),(R3)+     ;TEST THE MOVB

010732  020412                                  CMP     R4,(R2)         ;RESULT OK?
010734  001403                                  BEQ     AO112           ;BR IF YES

010736  011203                                  MOV     (R2),R3         ;GET WAS DATA
010740  000000                          EIO112: HALT                    ;MOVB DELIVERED WRONG RESULT
010742  000764                                  BR      RO112           ;LOCK ON HARD ERROR

010744  022703  067604                  AO112:  CMP     #MBUF0+2,R3     ;DID DEST REG GET INCREMENTED?
010750  001402                                  BEQ     TO113           ;BR IF YES

010752  000000                          E2O112: HALT                    ;MOVB FAILED TO AUTO INCREMENT DEST REG
010754  000757                                  BR      RO112           ;LOCK ON HARD ERROR
```

```
                                        ; ***********************************************************************
                                                .SBTTL T0113 BASIC "MOVB 2(RA),(RB)+" TEST - SRC ODD / DEST ODD
                                        ; ***********************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [146,241,242,247,250,137,251,172,257,202,205,125,375,016] FC 1,2,4

                                        ;ACT BUTS:      37[004]100,146 / 35[247]120,137 / 36[137]120,172 / 22[172]200,202
                                                        ; / 16[125]016,016

                                        ;EXEC:          [205]ALUC=LLLLL :[125]D=001001

                                        ;CODES:         [125] SPS=3  /  N:C=0000

                                        ;SYNC:          B05J2 (-)       /       T=4.2 USEC

                                        ;KEY SIG:       K3-3 MOVL  /  K3-3 DM=2L  /  K3-5 DOPL  /  K3-6 BYTE INSTR H

010756  012700  000113          T0113:  MOV     #0113,R0                ;LOAD R0 WITH TEST NO.
010762  112760  000377  070162          MOVB    #377,STAB1(R0)  ;SET FLAG FOR THIS TEST IN MISSED TABLE
010770  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
010774  012704  000777                  MOV     #777,R4         ;RESULT S / B = 777
011000  012705  070156                  MOV     #DBTB,R5        ;SRC ADDR = DBTB
011004  012703  067603          R0113:  MOV     #MBUF0+1,R3     ;R3 GETS DEST ADDR = MBUF0+1
011010  012712  177777                  MOV     #-1,(R2)        ;[DEST] = 177777
011014  000257                          CCC                     ;SCOPE SYNC

011016  116523  000001          I0113:  MOVB    1(R5),(R3)+     ;TEST THE MOVB

011022  020412                          CMP     R4,(R2)         ;RESULT OK?
011024  001403                          BEQ     A0113           ;BR IF YES

011026  011203                          MOV     (R2),R3         ;GET WAS DATA
011030  000000          E10113: HALT                            ;MOVB DELIVERED WRONG RESULT
011032  000764                          BR      R0113           ;LOCK ON HARD ERROR

011034  022703  067604          A0113:  CMP     #MBUF0+2,R3     ;DID DEST REG GET INCREMENTED?
011040  001402                          BEQ     T0114           ;BR IF YES

011042  000000          E20113: HALT                            ;MOVB FAILED TO AUTO INCREMENT DEST REG
011044  000757                          BR      R0113           ;LOCK ON HARD ERROR
```

```
                                ; ***********************************************************************
                                        .SBTTL T0114 BASIC "MOVB -(RA),RB" TEST - SRC EVEN ADDR
                                ; ***********************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [144,240,250,160,204,003,204,000] FC 1,2,4

                                ;ACT BUTS:      37[004]100 144 / 35[240]120,160 / 20[160]000,003 / 27[003]000,000

                                ;EXEC:          [003]ALUC=LLLLL :[204]D=177777

                                ;CODES:         [204] SPS=3  /  N:C=1000

                                ;SYNC:          B05J2 (-)       /       T=2 USEC

                                ;KEY SIG:       K3-3 MOVL  /  K3-3 DM=OL  /  K3-5 DOPL  /  K3-6 BYTE INSTR
                                                ;  K5-2 PS (N)(1)H

011046  012700  000114          T0114:  MOV     #0114,R0                ;LOAD R0 WITH TEST NO.
011052  112760  000377  070162          MOVB    #377,STAB1(R0)  ;SET FLAG FOR THIS TEST IN MISSED TABLE
011060  012702  177703                  MOV     #177703,R2      ;DEST ADDR = R3
011064  012704  177777                  MOV     #-1,R4          ;RESULT S / B = 177777
011070  012705  067621          R0114:  MOV     #DWTA+7,R5      ;SRC ADDR = DWTA+7
011074  005003                          CLR     R3              ;[DEST] = 000000
011076  000257                          CCC                     ;SCOPE SYNC

011100  114503                  I0114:  MOVB    -(R5),R3        ;TEST THE MOVB

011102  020403                          CMP     R4,R3           ;RESULT OK?
011104  001402                          BEQ     A0114           ;BR IF YES

011106  000000                  E10114: HALT                    ;MOVB FAILED - WRONG RESULT
011110  000767                          BR      R0114           ;LOCK ON HARD ERROR

011112  022705  067620          A0114:  CMP     #DWTA+6,R5      ;SRC REG GET DECREMENTED?
011116  001402                          BEQ     T0115           ;BR IF YES

011120  000000                  E20114: HALT                    ;MOVB FAILED TO UPDATE SRC REG
011122  000762                          BR      R0114           ;LOCK ON HARD ERROR
```

```
                                        ; ***************************************************************
                                                .SBTTL TO115 BASIC "MOVB -(RA),RB" TEST - SRC ODD ADDR
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [144,240,250,137,251,160,204,003,204,000] FC 1,2,4

                                        ;ACT BUTS:      37[004]100,144 / 35[240]120,137 / 36[137]120,160 / 20[160]000,003
                                                        ; / 27[003]000,000

                                        ;EXEC:          [003]ALUC=LLLLL :[204]D=177777

                                        ;CODES:         [204] SPS=3  /  N:C=1000

                                        ;SYNC:          B05J2 (-)       /       T= 2 USEC

                                        ;KEY SIG:       K3-3 MOVL  /  K3-3 DM=OL  /  K3-5 DOPL  /  K3-6 BYTE INSTR H
                                                        ;  K5-2 PS(N)(_)H

011124  012700  000115          TO115:  MOV     #O115,RO                ;LOAD RO WITH TEST NO.
011130  112760  000377  070162          MOVB    #377,STAB1(RO)  ;SET FLAG FOR THIS TEST IN MISSED TABLE
011136  012702  177703                  MOV     #177703,R2      ;DEST ADDR = R3
011142  012704  177777                  MOV     #-1,R4          ;RESULT S / B = 177777
011146  012705  067620          RO115:  MOV     #DWTA+6,R5      ;SRC ADDR = DWTA+6
011152  005003                          CLR     R3              ;[DEST] = 000000
011154  000257                          CCC                     ;SCOPE SYNC

011156  114503                  IO115:  MOVB    -(R5),R3        ;TEST THE MOVB

011160  020403                          CMP     R4,R3           ;RESULT OK?
011162  001402                          BEQ     AO115           ;BR IF YES

011164  000000                  E1O115: HALT                    ;MOVB FAILED - WRONG RESULT
011166  000767                          BR      RO115           ;LOCK ON HARD ERROR

011170  022705  067617          AO115:  CMP     #DWTA+5,R5      ;SRC REG GET DECREMENTED?
011174  001402                          BEQ     TO116           ;BR IF YES

011176  000000                  E2O115: HALT                    ;MOVB FAILED TO UPDATE SRC REG
011200  000762                          BR      RO115           ;LOCK ON HARD ERROR
```

```
                                        ; ***********************************************************************
                                                .SBTTL TO116 BASIC "MOVB (RA)+,-(SP)" TEST - SRC ADDR EVEN
                                        ; ***********************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [142,240,250,174,257,202,205,125,375,016] FC 1,2,4

                                        ;ACT BUTS:      37[004]100,142 / 35[240]120,174 / 22[174]200,202 / 16[125]016,016

                                        ;E.EC:          [205]ALUC=LLLLL :[125]D=000000

                                        ;CODES:         [125] SPS=3  /  N:C=0100

                                        ;SYNC:          BOSJ2 (-)       /       T= 3.3 USEC

                                        ;KEY SIG:       K3-3 MOVL  /  K3-3 DM=4L  /  K3-5 DOPL  /  K3-6 BYTE INSTR H
                                                        ;  K5-2 PS(Z)(1)H

011202  012700  000116                  TO116:  MOV     #0116,R0                ;LOAD R0 WITH TEST NO.
011206  112760  000377  070162                  MOVB    #377,STAB1(R0)  ;SET FLAG FOR THIS TEST IN MISSED TABLE
011214  010605                                  MOV     SP,R5           ;SAVE SP
011216  012704  177400                          MOV     #177400,R4      ;RESULT S / B = 177400
011222  010506                          R0116:  MOV     R5,SP           ;RESET SP FOR ERROR LOOP
011224  012703  070152                          MOV     #DBTA,R3        ;SRC ADDR = DBTA
011230  012746  177777                          MOV     #-1,-(SP)       ;[DEST] = 177777
011234  010602                                  MOV     SP,R2           ;R2 GETS DEST ADDR
011236  005726                                  TST     (SP)+           ;RESET SP
011240  000257                                  CCC                     ;SCOPE SYNC

011242  112346                          I0116:  MOVB    (R3)+,-(SP)     ;TEST THE MOVB

011244  022703  070153                          CMP     #DBTA+1,R3      ;DID MOVB INCREMENT SRC REG?
011250  001402                                  BEQ     A0116           ;BR IF YES

011252  000000                          E0116:  HALT                    ;MOVB FAILED TO UPDATE SRC REG
011254  000762                                  BR      R0116           ;LOCK ON HARD ERROR

011256  020412                          A0116:  CMP     R4,(R2)         ;RESULT OK?
011260  001403                                  BEQ     B0116           ;BR IF YES

011262  011203                                  MOV     (R2),R3         ;GET WAS DATA
011264  000000                          E10116: HALT                    ;MOVB FAILED TO DELIVER CORRECT RESULT
011266  000755                                  BR      R0116           ;LOCK ON HARD ERROR

011270  020206                          B0116:  CMP     R2,SP           ;DID SP GET PUSHED BY 2 ?
011272  001402                                  BEQ     C0116           ;BR IF YES

011274  000000                          E20116: HALT                    ;MOVB FAILED TO PUSH SP PROPERLY
011276  000751                                  BR      R0116           ;LOCK ON HARD ERROR

011300  010506                          C0116:  MOV     R5,SP           ;RESET SP IN CASE OF ERROR
```

```
                                        ; ***************************************************************
                                                .SBTTL T0117 BASIC "MOVB (RA)+,-(SP)" TEST - SRC ADDR ODD
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [142,240,250,137,251,174,257,202,205,125,375,016] FC 1,2,4

                                        ;ACT BUTS:      37[004]100,142 / 35[240]120,137 / 36[137]120,174 / 22[174]200,202
                                                        ; / 16[125]016,016

                                        ;EXEC:          [205]ALUC=LLLLL :[125]D=000000

                                        ;CODES:         [125] SPS=3  /  N:C=0100

                                        ;SYNC:          BOSJ2 (-)       /       T= 3.3 USEC

                                        ;KEY SIG:       K3-3 MOVL  /  K3-3 DM=4L  /  K3-5 DOPL  /  K3-6 BYTE INSTR H
                                                        ;  K5-2 PS(Z)(1)H

011302  012700  000117          T0117:  MOV     #0117,R0                ;LOAD R0 WITH TEST NO.
011306  112760  000377  070162          MOVB    #377 STAB1(R0)          ;SET FLAG FOR THIS TEST IN MISSED TABLE
011314  010605                          MOV     SP,R5                   ;SAVE SP
011316  012704  177400                  MOV     #177400,R4              ;RESULT S / B = 177400
011322  010506                  R0117:  MOV     R5,SP                   ;RESET SP FOR ERROR LOOP
011324  012703  070141                  MOV     #DWTB+3,R3              ;SRC ADDR = DWTB+3
011330  012746  177777                  MOV     #-1,-(SP)               ;[DEST] = 177777
011334  010602                          MOV     SP,R2                   ;R2 GETS DEST ADDR
011336  005726                          TST     (SP)+                   ;RESET SP
011340  000257                          CCC                             ;SCOPE SYNC

011342  112346                  I0117:  MOVB    (R3)+,-(SP)             ;TEST THE MOVB

011344  022703  070142                  CMP     #DWTB+4,R3              ;DID MOVB INCREMENT SRC REG?
011350  001402                          BEQ     A0117                   ;BR IF YES

011352  000000                  E0117:  HALT                            ;MOVB FAILED TO UPDATE SRC REG
011354  000762                          BR      R0117                   ;LOCK ON HARD ERROR

011356  020412                  A0117:  CMP     R4,(R2)                 ;RESULT OK?
011360  001403                          BEQ     B0117                   ;BR IF YES

011362  011203                          MOV     (R2),R3                 ;GET WAS DATA
011364  000000                  E10117: HALT                            ;MOVB FAILED TO DELIVER CORRECT RESULT
011366  000755                          BR      R0117                   ;LOCK ON HARD ERROR

011370  020206                  B0117:  CMP     R2,SP                   ;DID SP GET PUSHED BY 2
011372  001402                          BEQ     C0117                   ;BR IF YES

011374  000000                  E20117: HALT                            ;MOVB FAILED TO PUSH SP
011376  000751                          BR      R0117                   ;LOCK ON HARD ERROR

011400  010506                  C0117:  MOV     R5,SP                   ;RESET SP IN CASE OF ERROR
```

```
                                        ; ***************************************************************
                                                .SBTTL T0120 BASIC "MOVB X(R),@#A" TEST - SRC EVEN / DEST EVEN
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [146,241,242,247,250,173,207,210,202,205,125,375,016] FC 1,2,4

                                        ;ACT BUTS:      37[004]100,146 / 35[247]120,173 / 22[207]200,202 / 16[125]016,016

                                        ;EXEC:          [205]ALUC=LLLLL :[125]D=001001

                                        ;CODES:         [125] SPS=3  /  N:C=0000

                                        ;SYNC:          BOSJ2 (-)       /       T= 4.7 USEC

                                        ;KEY SIG:       K3-3 MOVL  /  K3-3 DM=3L  /  K3-5 DOPL  /  K3-6 BYTE INSTR H

011402  012700  000120                  T0120:  MOV     #0120,R0                ;LOAD R0 WITH TEST NO.
011406  112760  000377  070162                  MOVB    #377,STAB1(R0)  ;SET FLAG FOR THIS TEST IN MISSED TABLE
011414  012702  067602                          MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
011420  012704  000001                          MOV     #1,R4           ;RESULT S / B = 1
011424  012705  070136                          MOV     #DWTB,R5        ;BASE SRC ADDR = DWTB
011430  005012                          R0120:  CLR     (R2)            ;[DEST] = 000000
011432  000257                                  CCC                     ;SCOPE SYNC

011434  116537  000006  067602          I0120:  MOVB    6(R5),@#MBUF0   ;TEST THE MOVB

011442  020412                                  CMP     R4,(R2)         ;RESULT OK?
011444  001403                                  BEQ     T0121           ;BR IF YES

011446  011203                                  MOV     (R2),R3         ;GET WAS DATA
011450  000000                          E0120:  HALT                    ;MOVB DELIVERED WRONG RESULT
011452  000766                                  BR      R0120           ;LOCK ON HARD ERRROR
```

```
                                        ; ***********************************************************************
                                                .SBTTL T0121 BASIC "MOVB X(R),@#A" TEST - SRC ODD / DEST EVEN
                                        ; ***********************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [146,241,242,247,250,137,251,173,207,210,202,205,125,375,016] FC 1,2,4

                                        ;ACT BUTS:      37[004]100,146 / 35[247]120,137 / 22[207]200,202 / 16[125]016,016

                                        ;EXEC:          [205]ALUC=LLLLL :[125]D=001001

                                        ;CODES:         [125] SPS=3  /  N:C=0000

                                        ;SYNC:          BOSJ2 (-)       /       T= 4.7 USEC

                                        ;KEY SIG:       K3-3 MOVL  /  K3-3 DM=3  /  K3-5 DOPL  /  K3-6 BYTE INSTR H

011454  012700  000121          T0121:  MOV     #0121,R0                ;LOAD R0 WITH TEST NO.
011460  112760  000377  070162          MOVB    #377,STAB1(R0)  ;SET FLAG FOR THIS TEST IN MISSED TABLE
011466  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
011472  012704  000001                  MOV     #1,R4           ;RESULT S / B = 1
011476  012705  070156                  MOV     #DBTB,R5        ;BASE SRC ADDR = DBTB
011502  005012                  R0121:  CLR     (R2)            ;[DEST] = 000000
011504  000257                          CCC                     ;SCOPE SYNC

011506  116537  000001  067602  I0121:  MOVB    1(R5),@#MBUF0   ;TEST THE MOVB

011514  020412                          CMP     R4,(R2)         ;RESULT OK?
011516  001403                          BEQ     T0122           ;BR IF YES

011520  011203                          MOV     (R2),R3         ;GET WAS DATA
011522  000000                  E0121:  HALT                    ;MOVE DELIVERED WRONG RESULT
011524  000766                          BR      R0121           ;LOCK ON HARD ERRROR
```

```
                                        ; ***********************************************************************
                                                .SBTTL T0122 BASIC "MOVB X(R),@#A" TEST - SRC EVEN / DEST ODD
                                        ; ***********************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [146,241,242,247,250,173,207,210,202,205,125,375,016] FC 1,2,4

                                        ;ACT BUTS:      37[004]100,146 / 35[247]120,177 / 21[206]200,202 / 16[125]016,016

                                        ;EXEC:          [205]ALUC=LLLLL :[125]D=000401

                                        ;CODES:         [125] SPS=3  /  N:C=0000

                                        ;SYNC:          BOSJ2 (-)       /       T= 4.7 USEC

                                        ;KEY SIG:       K3-3 MOVL  /  K3-3 DM=3L  /  K3-5 DOPL  /  K3-6 BYTE INSTR H

011526  012700  000122                  T0122:  MOV     #0122,R0                ;LOAD R0 WITH TEST NO.
011532  112760  000377  070162                  MOVB    #377,STAB1(R0)  ;SET FLAG FOR THIS TEST IN MISSED TABLE
011540  012702  067602                          MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
011544  012704  000400                          MOV     #400,R4         ;RESULT     B = 400
011550  012705  070136                          MOV     #DWTB,R5        ;BASE SRC ADDR = DWTB
011554  005012                          R0122:  CLR     (R2)            ;[DEST] = 000000
011556  000257                                  CCC                     ;SCOPE SYNC

011560  116537  000006  067603          I0122:  MOVB    6(R5),@#MBUF0+1 ;TEST THE MOVB

011566  020412                                  CMP     R4,(R2)         ;RESULT OK?
011570  001403                                  BEQ     T0123           ;BR IF YES

011572  011203                                  MOV     (R2),R3         ;GET WAS DATA
011574  000000                          E0122:  HALT                    ;MOVB DELIVERED WRONG RESULT
011576  000766                                  BR      R0122           ;LOCK ON HARD ERRROR
```

```
                                        ; ***********************************************************************
                                                .SBTTL T0123 BASIC "MOVB X(R),@#A" TEST - SRC ODD / DEST ODD
                                        ; ***********************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [146,241,242,247,250,137,251,173,207,210,202,205,125,375,016] FC 1,2,4

                                        ;ACT BUTS:      37[004]100,146 / 35[247]120,137 / 36[137]120,173 / 22[207]200,202
                                                        ; / 16[125]016,016

                                        ;EXEC:          [205]ALUC=LLLLL :[125]D=001001

                                        ;CODES:         [125] SPS=3  /  N:C=0000

                                        ;SYNC:          BOSJ2 (-)       /       T= 4.7 USEC

                                        ;KEY SIG:       K3-3 MOVL  /  K3-3 DM=3L  /  K3-5 DOPL  /  K3-6 BYTE INSTR H

011600  012700  000123                  T0123:  MOV     #0123,R0                ;LOAD R0 WITH TEST NO.
011604  112760  000377  070162                  MOVB    #377,STAB1(R0)  ;SET FLAG FOR THIS TEST IN MISSED TABLE
011612  012702  067602                          MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
011616  012704  000400                          MOV     #400,R4         ;RESULT S / B = 400
011622  012705  070156                          MOV     #DBTB,R5        ;BASE SRC ADDR = DBTB
011626  005012                          R0123:  CLR     (R2)            ;[DEST] = 000000
011630  000257                                  CCC                     ;SCOPE SYNC

011632  116537  000001  067603          I0123:  MOVB    1(R5),@#MBUF0+1 ;TEST THE MOVB

011640  020412                                  CMP     R4,(R2)         ;RESULT OK?
011642  001403                                  BEQ     T0124           ;BR IF YES

011644  011203                                  MOV     (R2),R3         ;GET WAS DATA
011646  000000                          E0123:  HALT                    ;MOVB DELIVERED WRONG RESULT
011650  000766                                  BR      R0123           ;LOCK ON HARD ERRROR
```

```
                                ; ***************************************************************
                                        .SBTTL T0124 BASIC "RTS  PC" TEST
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [124,323,324,325,016] FC 1,6

                                ;ACT BUTS:      37[004]100,124 / 16[324]016,016

                                ;EXEC:          N / A

                                ;CODES:         N / A

                                ;SYNC:          BOSJ2 (-)       /       T= 2.5 USEC

                                ;KEY SIG:       K3-6 RTSL

011652  012700  000124          T0124:  MOV     #0124,R0                ;LOAD R0 WITH TEST NO.
011656  112760  000377  070162          MOVB    #377,STAB1(R0)  ;SET FLAG FOR THIS TEST IN MISSED TABLE
011664  010605                          MOV     SP,R5           ;SAVE THE ORIGINAL SP
011666  010506                  R0124:  MOV     R5,SP           ;RESET SP FOR ERROR LOOP
011670  012746  011704                  MOV     #A0124,-(SP)    ;PUSH NEW PC ON STACK
011674  000257                          CCC                     ;SCOPE SYNC

011676  000207                  I0124:  RTS     PC              ;TEST THE RTS - GO TO A0124

011700  000000                  E10124: HALT                    ;RTS FAILED TO LOAD PC
011702  000771                          BR      R0124           ;LOCK ON HARD ERROR

011704  020605                  A0124:  CMP     SP,R5           ;DID SP GET POPPED ?
011706  001402                          BEQ     T0125           ;BR IF YES

011710  000000                  E20124: HALT                    ;RTS FAILED TO UPDATE SP
011712  000765                          BR      R0124           ;LOCK ON HARD ERROR
```

```
                                ; ***********************************************************************
                                        .SBTTL T0125 BASIC "JSR  PC,@#A" TEST
                                ; ***********************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [153,303,307,310,311,312,306,313,016] FC 1,5

                                ;ACT BUTS:      37[004]100,153 / 15[153]306,307 / 16[306]016,016

                                ;EXEC:          N / A

                                ;CODES:         N / A

                                ;SYNC:          B05J2 (-)       /       T= 3.5 USEC

                                ;KEY SIG:       K3-5 JMP+JSRH  /  K3-3 DM=3L

011714  012700  000125          T0125:  MOV     #0125,R0                ;LOAD R0 WITH TEST NO.
011720  112760  000377  070162          MOVB    #377,STAB1(R0)  ;SET FLAG FOR THIS TEST IN MISSED TABLE
011726  010605                          MOV     SP,R5           ;SAVE ORIGINAL SP
011730  010506                  R0125:  MOV     R5,SP           ;RESET SP FOR ERROR LOOP
011732  000257                          CCC                     ;SCOPE SYNC

011734  004737  011744          I0125:  JSR     PC,@#A0125      ;TEST THE JSR - GO TO A0125

011740  000000                  E10125: HALT                    ;JSR FAILED TO LOAD PC
011742  000772                          BR      R0125           ;LOCK ON HARD ERROR

011744  022726  011740          A0125:  CMP     #E10125,(SP)+   ;DID JSR SAVE OLD PC ON STACK ?
011750  001402                          BEQ     T0126           ;BR IF YES

011752  000000                  E20125: HALT                    ;JSR FAILED TO SAVE OLD PC
011754  000765                          BR      R0125           ;LOCK ON HARD ERROR
```

```
                                        ; ***************************************************************
                                                .SBTTL T0126 BASIC "RTI" TEST - N:C=0000
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [101,320,321,322,017,015,013] FC 6,10

                                        ;ACT BUTS:      37[004]100,101 / 26[017]010,013

                                        ;EXEC:          N / A

                                        ;CODFS:         N / A

                                        ;SYNC:          B05J2 (-)       /       T= 3 USEC

                                        ;KEY SIG:       K3-6 RTI+RTTL

011756  012700  000126          070174  T0126:  MOV     #0126,R0                ;LOAD R0 WITH TEST NO.
011762  112760  000377  070162                  MOVB    #377,STAB1(R0)  ;SET FLAG FOR THIS TEST IN MISSED TABLE
011770  010605                                  MOV     SP,R5           ;SAVE THE SP
011772  010506                          R0126:  MOV     R5,SP           ;RESET THE SP FOR ERROR LOOP
011774  012746  000357                          MOV     #357,-(SP)      ;NEW PSW = 357
012000  012746  012020                          MOV     #A0126,-(SP)    ;NEW PC = A0126
012004  005037  177776                          CLR     @#PSW           ;MAKE [PSW] = 000
012010  000257                                  CCC                     ;MAKE N:C=0000

012012  000002                          I0126:  RTI                     ;TEST THE RTI - GO TO A0126

012014  000000                          E10126: HALT                    ;RTI FAILED TO LOAD PC
012016  000765                                  BR      R0126           ;LOOP ON HARD ERROR

012020  013702  177776                  A0126:  MOV     @#PSW,R2        ;SAVE THE [PSW] IN R2
012024  022702  000357                          CMP     #357,R2         ;WAS [PSW] = 357 ?
012030  001404                                  BEQ     B0126           ;BR IF YES

012032  010237  177776                          MOV     R2,@#PSW        ;RESTORE THE ERROR PSW
012036  000000                          E20126: HALT                    ;RTI FAILED TO LOAD PSW
012040  000754                                  BR      R0126           ;LOCK ON HARD ERROR

012042  020605                          B0126:  CMP     SP,R5           ;DID SP GET UPDATED OK ?
012044  001402                                  BEQ     T0127           ;BR IF YES

012046  000000                          E30126: HALT                    ;RTI FAILED TO UPDATE THE SP
012050  000750                                  BR      R0126           ;LOCK ON HARD ERROR
```

```
                                ; ***************************************************************
                                        .SBTTL T0127 BASIC "RTI" TEST WITH N:C=1111
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [101,320,321,322,017,015,013] FC 6,10

                                ;ACT BUTS:      37[004]100,101 / 26[017]010,013

                                ;EXEC:          N / A

                                ;CODES:         N / A

                                ;SYNC:          BOSJ2 (-)       /       T= 3 USEC

                                ;KEY SIG:       K3-6 RTI+RTTL

012052  012700  000127          T0127:  MOV     #0127,R0                ;LOAD R0 WITH TEST NO.
012056  112760  000377  070162          MOVB    #377,STAB1(R0)  ;SET FLAG FOR THIS TEST IN MISSED TABLE
012064  010605                          MOV     SP,R5           ;SAVE THE SP IN R5
012066  010506                  R0127:  MOV     R5,SP           ;RESET SP FOR ERROR LOOP
012070  005046                          CLR     -(SP)           ;NEW PSW = 000000
012072  012746  012110                  MOV     #A0127,-(SP)    ;NEW PC = A0127
012076  012737  000357  177776          MOV     #357,@#PSW      ;MAKE OLD PSW = 357
012104  000240                          NOP                     ;SCOPE SYNC

012106  000002                  I0127:  RTI                     ;TEST THE RTI - GO TO A0127

012110  013702  177776          A0127:  MOV     @#PSW,R2        ;GET THE PSW
012114  022702  000000                  CMP     #0,R2           ;WAS [PSW]=000
012120  001404                          BEQ     T0!30           ;BR IF YES

012122  010237  177776                  MOV     R2,@#PSW        ;RESTORE ERROR PSW
012126  000000                  E0127:  HALT                    ;RTI FAILED TO CLEAR PSW
012130  000756                          BR      R0127           ;LOCK ON HARD ERROR
```

```
                                ; ************************************************************
                                        .SBTTL T0130 BASIC "IOT" TEST -VERIFY LOADING PSW WITH 357
                                ; ************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [126,007,115,326,327,113,330,331,77,140,332,333,123,015,013] FC 1,6,10

                                ;ACT BUTS:      37[004]100,126 / 04[140]REG EXAM / 0:[332]122,123 / 03[333]REG DEP
                                                ; / 26[123]010,013

                                ;EXEC:          N / A

                                ;CODES:         N / A

                                ;SYNC:          B05J2 (-)       /       T= 6 USEC

                                ;KEY SIG:       K3-6 TRAP INSTR L

012132  012700  000130          T0130:  MOV     #0130,R0                ;LOAD R0 WITH TEST NO.
012136  112760  000377  070162          MOVB    #377,STAB1(R0)  ;SET FLAG FOR THIS TEST IN MISSED TABLE
012144  010605                          MOV     SP,R5           ;SAVE THE SP
012146  010506                  R0130:  MOV     R5,SP           ;RESET SP FOR ERROR LOOP
012150  012737  012206  000020          MOV     #A0130,@#20     ;SET UP IOT VECTOR
012156  012737  000357  000022          MOV     #357,@#22
012164  012766  177777  177776          MOV     #-1,-2(SP)      ;IOT SHOULD CHANGE -1 TO 0
012172  005037  177776                  CLR     @#PSW           ;MAKE [PSW] = 000
012176  000257                          CCC                     ;SCOPE SYNC

012200  000004                  I0130:  IOT                     ;TEST THE IOT

012202  000000                  E10130: HALT                    ;IOT FAILED TO LOAD PC
012204  000760                          BR      R0130           ;LOCK ON HARD ERROR

012206  013702  177776          A0130:  MOV     @#PSW,R2        ;GET THE PSW
012212  022702  000357                  CMP     #357,R2         ;DID IOT LOAD A 357 ?
012216  001404                          BEQ     B0130           ;BR IF YES

012220  010237  177776                  MOV     R2,@#PSW        ;RESTORE ERROR PSW
012224  000000                  E20130: HALT                    ;IOT FAILED TO LOAD PSW
012226  000747                          BR      R0130           ;LOCK ON HARD ERROR

012230  022726  012202          B0130:  CMP     #E10130,(SP)+   ;DID IOT SAVE OLD PC ?
012234  001404                          BEQ     C0130           ;BR IF YES

012236  010237  177776                  MOV     R2,@#PSW        ;RESTORE ERROR PSW
012242  000000                  E30130: HALT                    ;IOT FAILED TO SAVE OLD PC
012244  000740                          BR      R0130           ;LOCK ON HARD ERROR

012246  005726                  C0130:  TST     (SP)+           ;DID IOT SAVE OLD PSW ?
012250  001404                          BEQ     T0131           ;BR IF YES

012252  010237  177776                  MOV     R2,@#PSW        ;RESTORE ERROR PSW
012256  000000                  E40130: HALT                    ;IOT FAILED TO SAVE OLD PSW
012260  000732                          BR      R0130           ;LOCK ON HARD ERROR
```

7519

```
                                ; ***************************************************************
                                        .SBTTL T0131 BASIC "IOT" TEST - VERIFY LINKAGE TO SCOPE SERVICE
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [126,007,115,326,327,113,330,331,77,140,332,333,123,015,013] FC 1,6,10

                                ;ACT BUTS:      37[004]100,126 / 04[140]REG EXAM / 01[332]122,123 / 03[333]REG DEP
                                                ; / 26[123]010,013

                                ;EXEC:          N / A

                                ;CODES:         N / A

                                ;SYNC           B05J2 (-)       /       T= 6 USEC

                                ;KEY SIG:       K3-6 TRAP INSTR L

012262  012700  000131          T0131:  MOV     #0131,R0                ;LOAD R0 WITH TEST NO.
012266  112760  000377  070162          MOVB    #377,STAB1(R0)  ;SET FLAG FOR THIS TEST IN MISSED TABLE
012274  010605                          MOV     SP,R5           ;SAVE SP
012276  010506                  R0131:  MOV     R5,SP           ;RESET SP FOR ERROR LOOP
012300  005037  066702                  CLR     @#SCOFLG        ;TRAP SERVICE WILL COM "SCOFLG"
012304  012737  065260  000020          MOV     #SCOPEA,@#20    ;SET UP IOT VECTOR
012312  005037  000022                  CLR     @#22
012316  000257                          CCC                     ;SCOPE SYNC

012320  000004                  I0131:  SCOPE                   ;TEST THE IOT

012322  005137  066702                  COM     @#SCOFLG        ;SCOFLG SHOULD BECOME 000000
012326  001402                          BEQ     A0131           ;BR IF IT DID

012330  000000                  E0131:  HALT                    ;IOT FAILED TO LINK TO SCOPE SERVICE
012332  000761                          BR      R0131           ;LOCK ON HARD ERROR

012334  010506                  A0131:  MOV     R5,SP           ;RESET SP IN CASE OF ERROR
```

```
                                        ; ***********************************************************************
                                                .SBTTL T0132 BASIC "IOT" TEST -VERIFY LOADING PSW WITH 357
                                        ; ***********************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [126,007,115,326,327,113,330,331,77,140,332,333,123,015,013] FC 1,6,10

                                        ;ACT BUTS:      37[004]100,126 / 04[140]REG EXAM / 01[332]122,123 / 03[333]REG DEP
                                                        ; / 26[123]010,013

                                        ;EXEC:          N / A

                                        ;CODES:         N / A

                                        ;SYNC:          BCSJ2 (-)       /       T= 6 USEC

                                        ;KEY SIG:       K3-6 TRAP INSTR L

012336  012700  000132          T0132:  MOV     #0132,R0                ;LOAD R0 WITH TEST NO.
012342  112760  000377  070162          MOVB    #377,STAB1(R0)  ;SET FLAG FOR THIS TEST IN MISSED TABLE
012350  010605                          MOV     SP,R5           ;SAVE THE SP
012352  010506          R0132:  MOV     R5,SP           ;RESET SP FOR ERROR LOOP
012354  012737  012412  000020          MOV     #A0132,@#20     ;SET UP IOT VECTOR
012362  012737  000357  000022          MOV     #357,@#22
012370  012766  177777  177776          MOV     #-1,-2(SP)      ;IOT SHOULD CHANGE -1 TO 0
012376  005037  177776                  CLR     @#PSW           ;MAKE [PSW] = 000
012402  000257                          CCC                     ;SCOPE SYNC

012404  000004          I0132:  IOT                             ;TEST THE IOT

012406  000000          E10132: HALT                            ;IOT FAILED TO LOAD PC
012410  000760                  BR      R0132                   ;LOCK ON HARD ERROR

012412  013702  177776  A0132:  MOV     @#PSW,R2        ;GET THE PSW
012416  022702  000357          CMP     #357,R2         ;DID IOT LOAD A 357 ?
012422  001404                  BEQ     B0132           ;BR IF YES

012424  010237  177776          MOV     R2,@#PSW        ;RESTORE ERROR PSW
012430  000000          E20132: HALT                            ;IOT FAILED TO LOAD PSW
012432  000747                  BR      R0132                   ;LOCK ON HARD ERROR

012434  022726  012406  B0132:  CMP     #E10132,(SP)+   ;DID IOT SAVE OLD PC ?
012440  001404                  BEQ     C0132           ;BR IF YES

012442  010237  177776          MOV     R2,@#PSW        ;RESTORE ERROR PSW
012446  000000          E30132: HALT                            ;IOT FAILED TO SAVE OLD PC
012450  000740                  BR      R0132                   ;LOCK ON HARD ERROR

012452  005726          C0132:  TST     (SP)+           ;DID IOT SAVE OLD PSW ?
012454  001404                  BEQ     T0133           ;BR IF YES

012456  010237  177776          MOV     R2,@#PSW        ;RESTORE ERROR PSW
012462  000000          E40132: HALT                            ;IOT FAILED TO SAVE OLD PSW
012464  000732                  BR      R0132                   ;LOCK ON HARD ERROR
```

7613

```
                                        ; ***************************************************************
                                                .SBTTL T0133 BASIC IOT TEST - VERIFY LOADING PSW WITH 000
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [126,007,115,326,327,113,330,331,77,140,323,333,123,015,013] FC 1,6,10

                                        ;ACT BUTS:      37[004]100,126 / 04[140]REG EXAM / 01[332]122,123 / 03[333]REG DEP
                                                        ; / 26[123]010,013

                                        ;EXEC:          N / A

                                        ;CODES:         N / A

                                        ;SYNC:          BOSJ2 (-)       /       T= 6 USEC

                                        ;KEY SIG:       K3-6 TRAP INSTR L

012466  012700  000133          T0133:  MOV     #0133,R0                ;LOAD R0 WITH TEST NO.
012472  112760  000377  070162          MOVB    #377,STAB1(R0)  ;SET FLAG FOR THIS TEST IN MISSED TABLE
012500  010605                          MOV     SP,R5           ;SAVE THE SP
012502  010506                  R0133:  MOV     R5,SP           ;RESET SP FOR ERROR LOOP
012504  012737  012530  000020          MOV     #A0133,@#20     ;SET UP IOT VECTOR
012512  005037  000022                  CLR     @#22            ;
012516  012737  000340  177776          MOV     #340,@#PSW      ;MAKE [PSW] = 340
012524  000277                          SCC                     ;MAKE N:C=1111

012526  000004                  I0133:  IOT                     ;TEST THE IOT

012530  013702  177776          A0133:  MOV     @#PSW,R2        ;GET THE [PSW]
012534  001404                          BEQ     B0133           ;BR IF [PSW] = 000

012536  010237  177776                  MOV     R2,@#PSW        ;RESTORE THE ERROR PSW
012542  000000                  E0133:  HALT                    ;IOT FAILED TO CLEAR THE PSW
012544  000756                          BR      R0133           ;LOCK ON HARD ERROR

012546  010506                  B0133:  MOV     R5,SP           ;RESET THE SP BEFORE CONTINUING
```

```
                                        ; ***************************************************************
                                                .SBTTL T0134 BASIC "TRAP" TEST - LINKAGE TO PRINT ROUTINE
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [126,007,115,326,327,113,330,331,77,140,332,333,123,015,013] FC 1,6,10

                                        ;ACT BUTS:      37[004]100,126 / 04[140]REG EXAM / 01[332]122,123 / 03[333]REG DEP
                                                        ; / 26[123]010,013

                                        ;EXEC:          N / A

                                        ;CODES:         N / A

                                        ;SYNC:          BOSJ2 (-)       /       T= 6 USEC

                                        ;KEY SIG:       K3-6 TRAP INSTR L

012550  012700  000134          T0134:  MOV     #0134,R0                ;LOAD R0 WITH TEST NO.
012554  112760  000377  070162          MOVB    #377,STAB1(R0)  ;SET FLAG FOR THIS TEST IN MISSED TABLE
012562  032737  000004  066642          BIT     #4,@#BPTLOC     ;BREAKPOINT HALT SET ??
012570  001401                          BEQ     .+4             ;BR IF NOT
012572  000000                          HALT                    ;BREAK - DEPRESS CONTINUE TO RESTART
012574  010605                          MOV     SP,R5           ;SAVE THE SP
012576  010506                  R0134:  MOV     R5,SP           ;RESET SP FOR ERROR LOOP
012600  012737  066042  000034          MOV     #PRINA,@#34     ;SET UP THE "TRAP" VECTOR
012606  005037  000036                  CLR     @#36
012612  005037  066674                  CLR     @#PRIFLG        ;INITIALIZE TEST FLAG
012616  000257                          CCC                     ;SCOPE SYNC

012620  104400                  I0134:  TYPE                    ;TEST THE TRAP

012622  005137  066674                  COM     @#PRIFLG        ;SHOULD MAKE [PRIFLG] = 000000
012626  001402                          BEQ     T0135           ;BR IF IT DID

012630  000000                  E0134:  HALT                    ;TRAP FAILED TO LINK TO PRINT SERV.
012632  000761                          BR      R0134           ;LOCK ON HARD ERROR
```

```
                                        ; ***************************************************************
                                                .SBTTL T0135 BASIC "EMT" TEST - LINKAGE TO ERROR SERVICE
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [126,007,115,326,327,113,330,331,077,140,332,333,123,015,013] FC 1,6,10

                                        ;ACT BUTS:      37[004]100,126 / 04[140]REG EXAM / 01[332]122,123 / 03[333]REG DEP
                                                        ; / 26[123]010,013

                                        ;EXEC:          N / A

                                        ;CODES:         N / A

                                        ;SYNC:          B05J2 (-)       /       T= 6 USEC

                                        ;KEY SIG:       K3-6 TRAP INSTR L

012634  012700  000135          T0135:  MOV     #0135,R0                ;LOAD R0 WITH TEST NO.
012640  112760  000377  070162          MOVB    #377,STAB1(R0)  ;SET FLAG FOR THIS TEST IN MISSED TABLE
012646  010605                          MOV     SP,R5           ;SAVE THE SP
012650  010506                  R0135:  MOV     R5,SP           ;RESET SP FOR ERROR LOOP
012652  012737  065400  000030          MOV     #ERRA,@#30      ;SET UP THE EMT VECTOR
012660  005037  000032                  CLR     @#32
012664  005037  066676                  CLR     @#ERRFLG        ;EMT SERVICE WILL COM [ERRFLG]
012670  000257                          CCC                     ;SCOPE SYNC

012672  104000                  I0135:  ERROR                   ;TEST THE EMT

012674  005137  066676                  COM     @#ERRFLG        ;DID EMT SERV. COM ERRFLG?
012700  001402                          BEQ     T0136           ;BR IF YES

012702  000000                  E0135:  HALT                    ;EMT DID NOT LINK PROPERLY
012704  000761                          BR      R0135           ;LOCK ON HARD ERROR
```

```
                                        ; ***************************************************************
                                                .SBTTL T0136 BASIC TEST OF RSVD INSTR. TRAP LINKAGE
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [100,126,007,115,327,113,330,331,077,140,332,333,123,015,013] FC 1,6,10

                                        ;ACT BUTS:      37[004]100,100 / 04[140]REG EXAM / 01[332]122,123 / 03[333]REG DEP
                                                        ; / 26[123]010,013

                                        ;EXEC:          N / A

                                        ;CODES:         N / A

                                        ;SYNC:          B05J2 (-)       /       T= 6 USEC

                                        ;KEY SIG:       K3-6 RSVD INSTR L

012706  012700  000136          T0136:  MOV     #0136,R0                ;LOAD R0 WITH TEST NO.
012712  112760  000377  070162          MOVB    #377,STA81(R0)  ;SET FLAG FOR THIS TEST IN MISSED TABLE
012720  013701  012752                  MOV     @#I0136,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
012724  010605                          MOV     SP,R5           ;SAVE THE SP
012726  012737  065042  000010          MOV     #RSVTST,@#10    ;SET UP RSVD INSTR. TRAP VECTOR
012734  012737  000340  000012          MOV     #340,@#12
012742  010506                  R0136:  MOV     R5,SP           ;RESET SP FOR ERROR LOOP
012744  005037  066712                  CLR     @#RSVFLG        ;INITIALIZE TEST FLAG THAT WILL GET
                                                                ;COMPLEMENTED BY TRAP SERVICE
012750  000257                          CCC                     ;SCOPE SYNC

012752  177777                  I0136:  177777                  ;FORCE RSVD INSTR. TRAP

012754  005137  066712                  COM     @#RSVFLG                ;TEST FLAG SHOULD GO TO 000000
012760  001402                          BEQ     A0136           ;BR IF TRAP SPRUNG

012762  000000                  E0136:  HALT                    ;RSVD INSTR. TRAP FAILED
012764  000750                          BR      T0136           ;LOCK ON HARD ERROR

012766  012737  065050  000010  A0136:  MOV     #RSERR,@#10     ;SET UP RSVD INSTR TRAP VECTOR TO POINT
012774  012737  000340  000012          MOV     #340,@#12       ;TO ERROR SERVICE ROUTINE
```

```
                                        ; ***************************************************************
                                                .SBTTL T0137 BASIC TEST OF BUS TIMEOUT TRAP LINKAGE
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [150,007,115,326,327,113,330,331,077,140,332,333,123,015,013] FC 1,6,10

                                        ;ACT BUTS:      37[004]100,126 / 04[140]REG EXAM / 01[332]122,123 / 03[333]REG DEP
                                                        ; / 26[123]010,013

                                        ;EXEC:          N / A

                                        ;CODES:         N / A

                                        ;SYNC:          BOSJ2 (-)       /       T= 6 USEC

                                        ;KEY SIG:       K4-6 NOSACK(1)L

013002  012700  000137          T0137:  MOV     #0137,R0                ;LOAD R0 WITH TEST NO.
013006  112760  000377  070162          MOVB    #377,STAB1(R0)  ;SET FLAG FOR THIS TEST IN MISSED TABLE
013014  013701  013046                  MOV     @#I0137,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
013020  010605                          MOV     SP,R5           ;SAVE THE SP
013022  012737  065152  000004          MOV     #BETST,@#4      ;SET UP THE BUS ERROR VECTOR
013030  012737  000340  000006          MOV     #340,@#6
013036  010506          R0137:  MOV     R5,SP           ;RESET SP FOR ERROR LOOP
013040  005037  066714                  CLR     @#BERFLG        ;INITIALIZE TEST FLAG THAT WILL GET
                                                                ;COMPLEMENTED BY TRAP SERVICE
013044  000257                          CCC                     ;SCOPE SYNC

013046  005737  177700          I0137:  TST     @#177700        ;FORCE BUS TIMEOUT USING R0 ADDR.

013052  005137  066714                  COM     @#BERFLG        ;TEST FLAG SHOULD GO TO 000000
013056  001402                          BEQ     T0140           ;BR IF TRAP SPRUNG

013060  000000          E0137:  HALT                            ;BUS ERROR FAILED TO SPRING TRAP
013062  000747                          BR      T0137           ;LOCK ON HARD ERROR
```

```
                                        ; ***************************************************************
                                                .SBTTL T0140 BASIC TEST FOR ACCESSING DL11 REGISTERS
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [162,260,267,220,211,367,375,016] FC 1,3,9,8

                                        ;ACT BUTS:      37[004]100,162 / 33[260]220,220 / 16[367]016,016

                                        ;EXEC:          [220]ALUC=LLLLL :[211]D=N / A

                                        ;CODES:         N / A

                                        ;SYNC:          B05J2 (-)

                                        ;KEY SIG:       K3-8 BIT+CMP+TSTH  /  K3-3 DM=2L

013064  012700  000140          T0140:  MOV     #0140,R0                ;LOAD R0 WITH TEST NO.
013070  112760  000377  070162          MOVB    #377,STAB1(R0)  ;SET FLAG FOR THIS TEST IN MISSED TABLE
013076  005067  054500                  CLR     MBUF0           ;INIT STALL COUNTER
013102  005367  054474          1$:     DEC     MBUF0           ;COUNT THE TIMER
013106  001375                          BNE     1$              ;BR IF NO TIMEOUT
013110  012737  013150  000004          MOV     #E0140,@#4      ;SET UP BUS TIMEOUT VECTOR
013116  012737  000340  000006          MOV     #340,@#6
013124  010605                          MOV     SP,R5           ;SAVE TH SP
013126  010506                  R0140:  MOV     R5,SP           ;RESET SP FOR ERROR LOOP
013130  012702  177560                  MOV     #RCSR,R2        ;[R2] = STARTING DL11 ADDR.
013134  000257                          CCC                     ;SCOPE SYNC

013136  005722                  I0140:  TST     (R2)+           ;REFERENCE DL11 - RCSR
013140  005722                          TST     (R2)+           ;REFERENCE DL11 - RDBR
013142  005722                          TST     (R2)+           ;REFERENCE DL11 - XCSR
013144  005712                          TST     (R2)            ;REFERENCE DL11 - XDBR

013146  000403                          BR      A0140           ;GO TO NEXT TEST

013150  005742                  E0140:  TST     -(R2)           ;BAD ADDRESS IN R2
013152  000000                          HALT                    ;ONE OF DL11 ADDR'S CAUSED TIME OUT
013154  000764                          BR      R0140           ;LOCK ON HARD ERROR

013156  012737  065160  000004  A0140:  MOV     #BERR,@#4       ;SET UP BUS ERROR VECTOR TO POINT
013164  012737  000340  000006          MOV     #340,@#6        ;TO ERROR SERVICE ROUTINE
```

```
                                ; ***********************************************************************
                                        .SBTTL TO141 BASIC TEST OF DL11 - XCSR - READY(1)
                                ; ***********************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [161,266,267,224,367,375,016] FC 1,3,8

                                ;ACT BUTS:      37[004]100,161 / 33[266]220,224 / 16[367]016,016

                                ;EXEC:          [224]ALUC=LLHHL :[367]D=000000

                                ;CODES:         [367] SPS=3  /  N:C=0100

                                ;SYNC:          BOSJ2 (-)

                                ;KEY SIG:       K3-3 SM=OL  /  K3-3 DM=1L  /  K5-2 PS(Z)(1)H  /  K3-8 BIT+CMP+TSTH

013172  012700  000141          TO141:  MOV     #0141,R0                ;LOAD R0 WITH TEST NO.
013176  112760  000377  070162          MOVB    #377,STAB1(R0)  ;SET FLAG FOR THIS TEST IN MISSED TABLE
013204  012702  177564                  MOV     #XCSR,R2        ;DEST ADDR = XCSR
013210  012704  000200                  MOV     #200,R4         ;RESULT S / B = 200
013214  005012                  RO141:  CLR     (R2)            ;CLEAR [DEST]
013216  012701  000000                  MOV     #0,R1           ;SET UP TIMEOUT COUNTER
013222  000257                          CCC                     ;SCOPE SYNC

013224  020412                  IO141:  CMP     R4,(R2)         ;TEST READY BIT - IT SHOULD BE SET

013226  001405                          BEQ     TO142           ;BR IF IT WAS
013230  005301                          DEC     R1              ;TICK-TOCK GOES THE TIMER
013232  001374                          BNE     IO141           ;BR IF NOT A TIMEOUT

013234  011203                          MOV     (R2),R3         ;GET THE WAS DATA
013236  000000                  EO141:  HALT                    ;READY BIT IN XCSR FAILED ON A (0)
013240  000765                          BR      RO141           ;LOCK ON HARD ERROR
```

```
                                ; ***************************************************************
                                        .SBTTL T0142 BASIC TEST OF DL11 - XCSR - MAINT BIT (0)
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [161,266,267,224,367,375,016] FC 1,3,8

                                ;ACT BUTS:      37[004]100,161 / 33[266]220,224 / 16[367]016,016

                                ;EXEC:          [224]ALUC=LLHHL :[367]D=000000

                                ;CODES:         [367] SPS=3  /  N:C=0100

                                ;SYNC:          BOSJ2 (-)

                                ;KEY SIG:       K3-3 SM=0L  /  K3-3 DM=1L  /  K5-2 PS(Z)(1)H  /  K3-8 BIT+CMP+TSTH

013242  012700  000142          T0142:  MOV     #0142,R0                ;LOAD R0 WITH TEST NO.
013246  112760  000377  070162          MOVB    #377,STAB1(R0)  ;SET FLAG FOR THIS TEST IN MISSED TABLE
013254  012702  177564                  MOV     #XCSR,R2        ;DEST ADDR = XCSR
013260  012704  000200                  MOV     #200,R4         ;RESULT S / B = 200
013264  005012                  R0142:  CLR     (R2)            ;CLEAR MAINT. BIT
013266  000257                          CCC                     ;SCOPE SYNC

013270  020412                  I0142:  CMP     R4,(R2)         ;TEST MAINT(0)

013272  001403                          BEQ     T0143           ;BR IF MAINT BIT CLEAR

013274  011203                          MOV     (R2),R3         ;GET THE WAS DATA
013276  000000                  E0142:  HALT                    ;CAN'T CLEAR MAINT BIT
013300  000771                          BR      R0142           ;LOCK ON HARD ERROR
```

```
                                ; ***************************************************************
                                        .SBTTL TO143 BASIC TEST OF DL11 XCSR - MAINT BIT = 1
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [161,266,267,224,367,375,016] FC 1,3,8

                                ;ACT BUTS:      37[004]100,161 / 33[266]220,224 / 16[367]016,016

                                ;EXEC:          [224]SLUC=LLHHL :[367]D=000000

                                ;CODES:         [367] SPS=3  /  N:C=0100

                                ;SYNC:          BOSJ2 (-)

                                ;KEY SIG:       K3-3 SM=0L  /  K3-3 DM=1L  /  K5-2 PS(Z)(1)H  /  K3-8 BIT+CMP+TSTH

013302  012700  000143          TO143:  MOV     #0143,R0                ;LOAD R0 WITH TEST NO.
013306  112760  000377  070162          MOVB    #377,STAB1(R0)  ;SET FLAG FOR THIS TEST IN MISSED TABLE
013314  012702  177564                  MOV     #XCSR,R2        ;DEST ADDR = XCSR
013320  012704  000204                  MOV     #204,R4         ;RESULT S / B = 204
013324  012712  000004          RO143:  MOV     #4,(R2)         ;SET THE MAINT. BIT
013330  000257                          CCC                     ;SCOPE SYNC

013332  020412                  IO143:  CMP     R4,(R2)         ;TEST MAINT.(1)

013334  001403                          BEQ     TO144           ;BR IF IT WAS

013336  011203                          MOV     (R2),R3         ;GET THE WAS DATA
013340  000000                  EO143:  HALT                    ;CAN'T SET MAINT BIT IN XCSR
013342  000770                          BR      RO143           ;LOCK O HARD ERROR
```

```
                                ; ***************************************************************
                                        .SBTTL T0144 BASIC DL11 OUT / IN ECHO TEST (MAINT MODE)
                                ; ***************************************************************


                                ;THIS ROUTINE USES THE MAINTENANCE MODE FEATURE OF THE DL11 TO
                                ;TURN AROUND A STRING OF 8 CHARACTERS TO THE DL11. THIS STRING CONSISTS
                                ;OF ALTERNATING NULL / DELETE CHARS WHICH ARE NON PRINTING. THE 8 CHARS
                                ;ARE OUTPUT THEN READ BACK INTO A CORE BUFFER AND THEN THE INPUT AND
                                ;OUTPUT CORE BUFFERS ARE CHECKED FOR EQUIVALENCE. IF AN ERROR IS DET-
                                ;ECTED DURING THE COMPARISON THE ROUTINE HALTS WITH THE WAS AND S / B
                                ;DATA IN R3 AND R4 RESPECTFULLY. A TIMER IS EMPLOYED TO PREVENT THE
                                ;TEST FROM HANGING IF RECEIVER DONE DOES NOT RESPOND.

013344  012700  000144          T0144:  MOV     #0144,R0                ;LOAD R0 WITH TEST NO.
013350  112760  000377  070162          MOVB    #377,STAB1(R0)  ;SET FLAG FOR THIS TEST IN MISSED TABLE
013356  012702  177560                  MOV     #RCSR,R2        ;R2 POINTS TO DL11 - START ADDR
013362  105762  000002                  TSTB    2(R2)           ;REFERENCE DL11 INPUT DATA BUFFER TWICE
013366  105762  000002                  TSTB    2(R2)           ;TO FLUSH RCVR "DONE" BIT
013372  012703  067556                  MOV     #IBUF,R3        ;R3 POINTS TO CORE INPUT BUFFER
013376  012704  067546                  MOV     #OBUF,R4        ;R4 POINTS TO CORE OUTPUT BUFFER
013402  012705  000010                  MOV     #10,R5          ;R5 WILL COUNT 8 CHARS OUTPUT
013406  012762  000004  000004          MOV     #4,4(R2)        ;TURN ON MAINT MODE

013414  012701  000000          1$:     MOV     #0,R1           ;R1 USED AS TIMEOUT COUNTER
013420  112462  000006                  MOVB    (R4)+,6(R2)     ;LOAD OUTPUT BUFFER IN DL11
013424  105712                  2$:     TSTB    (R2)            ;RECEIVER DONE SET ?
013426  100404                          BMI     3$              ;BR IF YES
013430  005301                          DEC     R1              ;COUNT THE TIMER
013432  001374                          BNE     2$              ;BR IF NO TIMEOUT

013434  000000                          HALT                    ;DL11 FAILED TO RESPOND IN TIME
013436  000742                          BR      T0144           ;LOCK ON HARD ERROR

013440  116223  000002          3$:     MOVB    2(R2),(R3)+     ;READ THE DL11 INPUT BUFFER INTO CORE
013444  005305                          DEC     R5              ;COUNT ONE CHAR
013446  001362                          BNE     1$              ;BR IF NOT DONE 8 CHARS

013450  005062  000004                  CLR     4(R2)           ;TURN OFF MAINT. MODE
013454  012705  000010                  MOV     #10,R5          ;RESET CHAR COUNTER
013460  012703  067556                  MOV     #IBUF,R3        ;RESET INBUF POINTER
013464  012704  067546                  MOV     #OBUF,R4        ;RESET OUTBUF POINTER

013470  122324                  4$:     CMPB    (R3)+,(R4)+     ;INPUT = OUTPUT ??
013472  001003                          BNE     5$              ;BR IF NOT
013474  005305                          DEC     R5              ;COUNT ONE CHECKED
013476  001374                          BNE     4$              ;BR UNTIL 8 DONE
013500  000410                          BR      CITST           ;GO TO NEXT TEST

013502  114303                  5$:     MOVB    -(R3),R3        ;WAS DATA IN R3 [BITS 7:0]
013504  114404                          MOVB    -(R4),R4        ;S / B DATA IN R4 [BITS 7:0]
013506  042703  177400                  BIC     #177400,R3      ;STRIP OFF BITS <15:08>
013512  042704  177400                  BIC     #177400,R4      ;  "          "
013516  000000                          HALT                    ;RECEIVED DATA NOT EQUAL TO OUTPUT DATA
013520  000711                          BR      T0144           ;LOCK ON HARD ERROR
```

```
B008
B009
```

```
                                        ;XXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXX
                                        ;////////////COMPREHENSIVE INSTRUCTION TESTS//////////////////////
                                        ;XXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXX

013522  012737  065266  000020  CITST:  MOV     #SCOPEB,@#20    ;SET UP IOT VECTOR
013530  005037  000022                  CLR     @#22
013534  012737  065406  000030          MOV     #ERRB,@#30      ;SET UP EMT VECTOR
013542  012737  000340  000032          MOV     #340,@#32
013550  012737  066050  000034          MOV     #PRINT,@#34     ;SET UP TRAP VECTOR
013556  012737  000340  000036          MOV     #340,@#36
013564  012737  064706  000024          MOV     #PDWN,@#24      ;SET UP POWER FAIL VECTOR
013572  012737  000340  000026          MOV     #340,@#26
013600  032737  010000  177570          BIT     #SW12,@#SR      ;INHIBIT PRINTING INTRO. I.D. MESSAGE
013606  001007                          BNE     1$              ;BR IF YES
013610  005737  066722                  TST     @#ONCE          ;FIRST TIME INTO "CIT" TESTS ?
013614  001004                          BNE     1$              ;BR IF NOT - PRINT ID ONLY ONCE
013616  005137  066722                  COM     @#ONCE          ;SET FLAG TO INHIBIT PRINTING AGAIN
013622  104400                          TYPE                    ;IDENTIFY THIS PROGRAM
013624  067212                          IDENT1                  ;ADDR OF THE ID MESSAGE
013626  004737  066210          1$:     JSR     PC,@#TSTOPT     ;GO TEST FOR 11/40 OPTIONS
013632  005037  177776                  CLR     @#PSW           ;SET CPU PRIORITY TO LEVEL 000
013636  012737  013636  066654  2$:     MOV     #2$,@#RETURN    ;INITIALIZE SCOPE LOOP RETURN
```

```
                                ; ***************************************************************
                                        .SBTTL TD145 QUICK VERIFY TEST FOR BMI,BEQ,BVS,BCS-FLG=0
                                ; ***************************************************************

                                ;MICROPROGRAMMING   /   LOGIC INFORMATION

                                ;ROM SEQ:       [110,347,016] FC 1,7

                                ;ACT BUTS:      37[004]100,110   /   16[110]016,016

                                ;EXEC:          N  /  A

                                ;CODES:         N  /  A

                                ;SYNC:          BOSJ2  (-)  T = 1.5 USEC

                                ;KEY SIG:       K5-3 BR INSTR L   /   K3-5 BUBC3(BUT37) H

013644  012700  000145          TD145:  MOV     #0145,R0                ;LOAD R0 WITH TEST NO.
013650  013701  013656                  MOV     2#ID145,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
013654  000257                  RD145:  CCC                     ;CLEAR ALL FLAGS

013656  001404                  ID145:  BEQ     ED145           ;NO BR SHOULD OCCUR-FLAG=0
013660  100403                          BMI     ED145           ;NO BR SHOULD OCCUR-FLAG=0
013662  102402                          BVS     ED145           ;NO BR SHOULD OCCUR-FLAG=0
013664  103401                          BCS     ED145           ;NO BR SHOULD OCCUR-FLAG=0
013666  000402                          BR      OD145           ;GO CALL SCOPE

013670  104005                  ED145:  ERRORS                  ;ONE OF ABOVE BR'S FAILED
013672  013654                          RD145                   ;ERROR LOOP RETURN

013674  000004                  OD145:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0146 QUICK VERIFY TEST FOR BMI,BEQ,BVS,BCS-FLAG=1
                                ; ***************************************************************

                                ;MICROPROGRAMMING   /   LOGIC INFORMATION

                                ;ROM SEQ:       [111,340,341,016] FC 1,7

                                ;ACT BUTS:      37[004]100,111  /  16[340]016,016

                                ;EXEC:          [341]ALUC=LHLLH :[016]D=#I20146 OR #I30146 OR #I40146 OR #00146 DEPENDEN

                                ;CODES:         N  /  A

                                ;SYNC:          BOSJ2 (-) T = 2 USEC

                                ;KEY SIG:       K5-3 BR INSTR L   /   K5-3 TRUE BR L   /   K3-5 BUBC3(BUT37) H   /   K3-

013676  012700  000146          T0146:  MOV     #0146,R0                ;LOAD R0 WITH TEST NO.
013702  013701  013710                  MOV     @#I10146,R1     ;LOAD R1 WITH TEST INSTRUCTION WORD

013706  000277                  R0146:  SCC                     ;MAKE N:C = 1111

013710  001402                  I10146: BEQ     I20146          ;TEST THE BEQ-IT SHOULD BR

013712  104005                  E10146: ERRORS                  ;BEQ FAILED
013714  013706                          R0146                   ;ERROR LOOP RETURN

013716  100402                  I20146: BMI     I30146          ;TEST THE BMI-IT SHOULD BR

013720  104005                  E20146: ERRORS                  ;BMI FAILED
013722  013706                          R0146                   ;ERROR LOOP RETURN

013724  102402                  I30146: BVS     I40146          ;TEST THE BVS-IT SHOULD BR

013726  104005                  E30146: ERRORS                  ;BVS FAILED
013730  013706                          R0146                   ;ERROR LOOP RETURN

013732  103402                  I40146: BCS     00146           ;TEST THE BCS-IT SHOULD BR

013734  104005                  E40146: ERRORS                  ;BCS FAILED
013736  013706                          R0146                   ;ERROR LOOP RETURN

013740  000004                   00146: SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0147 BNE TEST WITH Z=1
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [110,347,016] FC 1,7

                                ;ACT BUTS:      37[004]100,110 / 16[110]016,016

                                ;EXEC:          N / A

                                ;CODES:         N / A

                                ;SYNC:          BOSJ2 (-) T = 1.5 USEC

                                ;KEY SIG:       K5-3 BR INSTR L  /  K3-5 BUBC3(BUT37) H

013742  012700  000147          T0147:  MOV     #0147,R0                ;LOAD R0 WITH TEST NO.
013746  013701  013754                  MOV     @#I0147,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD

013752  000264                  R0147:  SEZ                     ;MAKE Z=1

013754  001001                  I0147:  BNE     E0147           ;TEST THE BNE-IT SHOULDN'T BR
013756  000402                          BR      00147           ;GO TO SCOPE EXIT

013760  104005                  E0147:  ERROR5                  ;BNE FAILED
013762  013752                          R0147                   ;ERROR LOOP RETURN

013764  000004                  00147:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0150 BNE TEST WITH Z=0
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [111,340,341,016] FC 1,7

                                ;ACT BUTS:      37[004]100,111 / 16[340]016,016

                                ;EXEC:          [016] D = #00150

                                ;CODES:         N / A

                                ;SYNC:          B05J2 (-) T = 1.8 USEC

                                ;KEY SIG:       K5-3 BR INSTR L  /  K5-3 FALSE BR L  /  K3-3 SM=1L

013766  012700  000150          T0150:  MOV     #0150,R0                ;LOAD R0 WITH TEST NO.
013772  013701  014000                  MOV     @#I0150,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD

013776  000244                  R0150:  CLZ                     ;MAKE Z=0
014000  001002                  I0150:  BNE     00150           ;TEST THE BNE-IT SHOULD BR
014002  104005                  E0150:  ERRORS                  ;BNE FAILED
014004  013776                          R0150                   ;ERROR LOOP RETURN
014006  000004                   00150: SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0151 BPL TEST WITH N=1
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [110,347,016] FC 1,7

                                ;ACT BUTS:      37[004]100,110 / 16[110]016,016

                                ;EXEC:          NO BRANCH

                                ;CODES:         N / A

                                ;SYNC:          B05J2 (-) T= 1.4 USEC

                                ;KEY SIG:       K5-3 BR INSTR L  /  K3-3 SM=0L  /  K3-4 IR15 L

014010  012700  000151          T0151:  MOV     #0151,R0                ;LOAD R0 WITH TEST NO.
014014  013701  014022                  MOV     @#I0151,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD

014020  000270                  R0151:  SEN                     ;MAKE N=1

014022  100001                  I0151:  BPL     E0151           ;TEST THE BPL-IT SHOULDN'T BR
014024  000402                          BR      00151           ;GO TO SCOPE EXIT

014026  104005                  E0151:  ERROR5                  ;BPL FAILED
014030  014020                          R0151                   ;ERROR LOOP RETURN

014032  000004                  00151:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0152 BPL TEST WITH N=0
                                ; ***************************************************************

                                ;MICROPROGRAMMING   /   LOGIC INFORMATION

                                ;ROM SEQ:       [111,340,341,016] FC 1,7

                                ;ACT BUTS:      37[004:100,111  /  16[340]016,016

                                ;EXEC:          [016] D = #00152

                                ;CODES:         N  /  A

                                ;SYNC:          B05J2 (-) T = 1.8 USEC

                                ;KEY SIG:       K5-3 BR INSTR L   /   K5-3 FALSE BR L   /   K3-3 SM=DL   /   K3-4 IR15 L

014034  012700  000152          T0152:  MOV     #0152,R0                ;LOAD R0 WITH TEST NO.
014040  013701  014046                  MOV     @#T0152,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD

014044  000250                  P0152:  CLN                     ;MAKE N=0

014046  100002                  T0152:  BPL     00152           ;TEST THE BPL-IT SHOULD BR

014050  104005                  E0152:  ERROR5                  ;BPL FAILED
014052  014044                          R0152                   ;ERROR LOOP RETURN

014054  000004                  00152:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0153 BVC TEST WITH V=1
                                ; ***************************************************************

                                ;MICROPROGRAMMING   /   LOGIC INFORMATION

                                ;ROM SEQ:       [110,347,016] FC 1,7

                                ;ACT BUTS:      37[004]100,110  /  16[110]016,016

                                ;EXEC:          NO BRANCH

                                ;CODES:         N  /  A

                                ;SYNC:          B05J2 (-) T = 1.4 USEC

                                ;KEY SIG:       K5-3 BR INSTR L   /   K3-3 SM=2L   /   K3-4 IR15 L

014056  012700  000153          T0153:  MOV     #0153,R0                ;LOAD R0 WITH TEST NO.
014062  013701  014070                  MOV     @#I0153,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD

014066  000262                  R0153:  SEV                     ;MAKE V=1

014070  102001                  I0153:  BVC     E0153           ;TEST THE BVC-IT SHOULDN'T BR
014072  000402                          BR      00153           ;GO TO SCOPE EXIT

014074  104005                  E0153:  ERROR5                  ;BVC FAILED
014076  014066                          R0153                   ;ERROR LOOP RETURN

014100  000004                  00153:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0154 BVC TEST WITH V=0
                                ; ***************************************************************

                                ;MICROPROGRAMMING   /   LOGIC INFORMATION

                                ;ROM SEQ:       [111,340,341,016] FC 1,7

                                ;ACT BUTS:      37[004]100,111  /  16[340]016,016

                                ;EXEC:          [016] D = #00154

                                ;CODES:         N  /  A

                                ;SYNC:          B05J2 (-) T = 1.8 USEC

                                ;KEY SIG:       K5-3 BR INSTR L   /   KK5-3 FALSE BR L   /   K3-3 SM-2L   /   K3-4 IR15


                                ;CODES:         N  /  A
014102  012700  000154          T0154:  MOV     #0154,R0                ;LOAD R0 WITH TEST NO.
014106  013701  014114                  MOV     @#T0154,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD

014112  000242                  R0154:  CLV                     ;MAKE V=0

014114  102002                  T0154:  BVC     00154           ;TEST THE BVC-IT SHOULD BR

014116  104005                  E0154:  ERROR5                  ;BVC FAILED
014120  014112                          R0154                   ;ERROR LOOP RETURN

014122  000004                  00154:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0155 BCC TEST WITH C=1
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [110,347,016] FC 1,7

                                ;ACT BUTS:      37[004]100,110 / 16[110]016,016

                                ;EXEC:          NO BRANCH

                                ;CODES:         N / A

                                ;SYNC:          B05J2 (-) T = 1.4 USEC

                                ;KEY SIG:       K5-3 BR INSTR L  /  K3-3 SM=3L  /  K3-4 IR15 L

014124  012700  000155          T0155:  MOV     #0155,R0                ;LOAD R0 WITH TEST NO.
014130  013701  014136                  MOV     @#I0155,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD

014134  000261                  R0155:  SEC                     ;MAKE C=1

014136  103001                  I0155:  BCC     E0155           ;TEST THE BCC, IT SHOULDN'T BR
014140  000402                          BR      00155           ;GO TO SCOPE EXIT

014142  104005                  E0155:  ERROR5                  ;BCC FAILED
014144  014134                          R0155                   ;ERROR LOOP RETURN

014146  000004                   00155: SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0156 BCC TEST WITH C=0
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [111,340,341,016] FC 1,7

                                ;ACT BUTS:      37[004]100,111 / 16[340]016,016

                                ;EXEC:          [016] D = #00156

                                ;CODES:         N / A

                                ;SYNC:          B05J2 (-) T = 1.8 USEC

                                ;KEY SIG:       K5-3 BR INSTR L  /  K5-3 FALSE BR L  /  K3-3 SM=3L  /  K3-4 IR15 L

014150  012700  000156          T0156:  MOV     #0156,R0                ;LOAD R0 WITH TEST NO.
014154  013701  014162                  MOV     @#I0156,R1             ;LOAD R1 WITH TEST INSTRUCTION WORD

014160  000241                  R0156:  CLC                             ;MAKE C=0

014162  103002                  I0156:  BCC     00156                   ;TEST THE BCC-IT SHOULD BR

014164  104005                  E0156:  ERROR5                          ;BCC FAILED
014166  014160                          R0156                           ;ERROR LOOP RETURN

014170  000004                  00156:  SCOPE                           ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0157 VERIFY NO BRANCH MICROROUTINE DOES NOT CLR FLAGS
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [110,347,016] FC 1,7

                                ;ACT BUTS:      37[004]100,110 / 16[110]016,016

                                ;EXEC:          NO BRANCH

                                ;CODES:         N:C = 1111      (NO CHANGE)

                                ;SYNC:          B05J2 (-) T = 1.4 USEC

                                ;KEY SIG:       K5-3 BR INSTR L  /  K3-3 SM=3L  /  K3-4 IR15 L

014172  012700  000157          T0157:  MOV     #0157,R0                ;LOAD R0 WITH TEST NO.
014176  013701  014204                  MOV     @#I0157,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD

014202  000277                  R0157:  SCC                     ;MAKE N:C = 1111

014204  103007                  I0157:  BCC     E0157           ;TEST THE BCC-IT SHOULDN'T BR

014206  013702  177776                  MOV     @#PSW,R2        ;GET WAS FLAGS
014212  022702  000017                  CMP     #17,R2          ;N:C = 1111?
014216  001404                          BEQ     00157           ;BR IF YES

014220  010237  177776                  MOV     R2,@#PSW        ;RESTORE N:C

014224  104005                  E0157:  ERROR5                  ;NO BRANCH MICROROUTINE ALTERED CODES
014226  014202                          R0157                   ;ERROR LOOP RETURN

014230  000004                  00157:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0160 VERIFY BRANCH MICROROUTINE DOES NOT CLR FLAGS
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [111,340,341,016] FC 1,7

                                ;ACT BUTS:      37[004]100,111 / 16[340]016,016

                                ;EXEC:          [016] D = #A0160

                                ;CODES:         N:C = 1111      (NO CHANGE)

                                ;SYNC:          B05J2 (-) T = 1.8 USEC

                                ;KEY SIG:       K5-3 BR INSTR L  /  K5-3 TRUE BR  /  K3-3 SM=0L  /  K3-3 IR(14:12) = 0 L

014232  012700  000160          T0160:  MOV     #0160,R0                ;LOAD R0 WITH TEST NO.
014236  013701  014244                  MOV     @#I0160,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD

014242  000277                  R0160:  SCC                     ;MAKE N:C = 1111

014244  000402                  I0160:  BR      A0160           ;TEST THE BR

014246  104005                  E10160: ERRORS                  ;JUST IN CASE THE BR DIDN'T WORK
014250  014242                          R0160                   ;ERROR LOOP RETURN

014252  013702  177776          A0160:  MOV     @#PSW,R2        ;GET THE FLAGS
014256  022702  000017                  CMP     #17,R2          ;N:C = 1111?
014262  001404                          BEQ     00160           ;BR IF YES

014264  010237  177776                  MOV     R2,@#PSW        ;RESTORE FLAGS

014270  104005                  E20160: ERRORS                  ;BRANCH MICROROUTINE ALTERED CODES
014272  014242                          R0160                   ;ERROR LOOP RETURN

014274  000004                  00160:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0161 VERIFY NO BRANCH MICROROUTINE DOES NOT SET FLAGS
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [110,347,016] FC 1,7

                                ;ACT BUTS:      37[004]100,110 / 16[110]016,016

                                ;EXEC:          NO BRANCH

                                ;CODES:         N:C = 0000      (NO CHANGE)

                                ;SYNC:          BOSJ2 (-) T = 1.4 USEC

                                ;KEY SIG:       K5-3 BR INSTR L  /  K3-3 SM=3L  /  K3-4 IR15 L

014276  012700  000161          T0161:  MOV     #0161,R0                ;LOAD R0 WITH TEST NO.
014302  013701  014310                  MOV     @#I0161,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD

014306  000257                  R0161:  CCC                     ;MAKE N:C = 0000

014310  103406                  I0161:  BCS     E0161           ;TEST THE BCS-IT SHOULDN'T BR

014312  013702  177776                  MOV     @#PSW,R2        ;GET FLAGS
014316  005702                          TST     R2              ;N:C = 0000
014320  001404                          BEQ     00161           ;BR IF YES

014322  010237  177776                  MOV     R2,@#PSW        ;RESTORE FLAGS

014326  104005                  E0161:  ERRORS                  ;NO BRANCH MICROROUTINE-ALTERED CODES
014330  014306                          R0161                   ;ERROR LOOP RETURN

014332  000004                  00161:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0162 VERIFY BRANCH MICROROUTINE DOES NOT SET FLAGS
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [111,340,341,016] FC 1,7

                                ;ACT BUTS:      37[004]100,111 / 16[340]016,016

                                ;EXEC:          [016] D = #A0162

                                ;CODES:         N:C = 0000      (NO CHANGE)

                                ;SYNC:          BOSJ2 (-) T = 1.8 USEC

                                ;KEY SIG:       K5-3 BIT INSTR L  /  K5-3 TRUE BR L  /  K3-3 SM=OL  /  K3-4 IR(14:12)=0

014334  012700  000162          T0162:  MOV     #0162,R0                ;LOAD R0 WITH TEST NO.
014340  013701  014346                  MOV     @#I0162,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD

014344  000257                  R0162:  CCC                     ;MAKE N:C = 0000

014346  000402                  I0162:  BR      A0162           ;TEST THE BR

014350  104005                  E10162: ERRORS                  ;JUST IN CASE THE BR DIDN'T WORK
014352  014344                          R0162                   ;ERROR LOOP RETURN

014354  013702  177776          A0162:  MOV     @#PSW,R2        ;GET FLAGS
014360  005702                          TST     R2              ;N:C = 0000
014362  001404                          BEQ     00162           ;BR IF YES

014364  010237  177776                  MOV     R2,@#PSW        ;RESTORE FLAGS

014370  104005                  E20162: ERRORS                  ;BRANCH MICROROUTINE ALTERED CODES.
014372  014344                          R0162                   ;ERROR LOOP RETURN

014374  000004                   00162: SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***************************************************************
                                                .SBTTL TO163 BGE TEST WITH N,V = 00
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [111,340,341,016] FC 1,7

                                        ;ACT BUTS:      37[004]100,111 / 16[340]016,016

                                        ;EXEC:          [016] D = #00163

                                        ;CODES:         N:C = 0000

                                        ;SYNC:          BOSJ2 (-) T = 1.8 USEC

                                        ;KEY SIG:       K5-3 BR INSTR L  /  K5-3 FALSE BR L  /  K3-3 SM=2L

014376  012700  000163                  TO163:  MOV     #0163,R0                ;LOAD R0 WITH TEST NO.
014402  013701  014410                          MOV     @#I0163,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD

014406  000257                          R0163:  CCC                     ;MAKE N:C = 0000

014410  002002                          I0163:  BGE     00163           ;TEST THE BGE-IT SHOULD BR

014412  104005                          E0163:  ERROR5                  ;BGE FAILED
014414  014406                                  R0163                   ;ERROR LOOP RETURN

014416  000004                           00163: SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0164 BGE TEST WITH N,V = 01
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [110,347,016] FC 1,7

                                ;ACT BUTS:      37[004]100,110 / 16[110]016,016

                                ;EXEC:          NO BRANCH

                                ;CODES:         N:C = 0010

                                ;SYNC:          B05J2 (-) T = 1.4 USEC

                                ;KEY SIG:       K5-3 BR INSTR L  /  K3-3 SM=2L  /  K3-3 IR(14:12)=0 L

014420  012700  000164          T0164:  MOV     #0164,R0                ;LOAD R0 WITH TEST NO.
014424  013701  014434                  MOV     @#I0164,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD

014430  000257                  R0164:  CCC                     ;CLEAR FLAGS
014432  000262                          SEV                     ;MAKE N,V = 01

014434  002001                  I0164:  BGE     E0164           ;TEST THE BGE-IT SHOULDN'T BR
014436  000402                          BR      00164           ;GO TO SCOPE EXIT

014440  104005                  E0164:  ERROR5                  ;BGE FAILED
014442  014430                          R0164                   ;ERROR LOOP RETURN
014444  000004                   00164: SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0165 BGE TEST WITH N,V = 10
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [110,347,016] FC 1,7

                                ;ACT BUTS:      37[004]100,110 / 16[110]016,016

                                ;EXEC:          NO BRANCH

                                ;CODES:         N:C = 1000

                                ;SYNC:          B05J2 (-) T = 1.4 USEC

                                ;KEY SIG:       K5-3 BR INSTR L  /  K3-3 SM=2L

014446  012700  000165          T0165:  MOV     #0165,R0                ;LOAD R0 WITH TEST NO.
014452  013701  014462                  MOV     @#I0165,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD

014456  000257                  R0165:  CCC                     ;CLEAR FLAGS
014460  000270                          SEN                     ;MAKE N,V = 10

014462  002001                  I0165:  BGE     E0165           ;TEST THE BGE-IT SHOULDN'T BR
014464  000402                          BR      00165           ;GO TO SCOPE EXIT

014466  104005                  E0165:  ERROR5                  ;BGE FAILED
014470  014456                          R0165                   ;ERROR LOOP RETURN

014472  000004                  00165:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0166 BGE TEST WITH N,V = 11
                                ; ***************************************************************

                                ;MICROPROGRAMMING   /   LOGIC INFORMATION

                                ;ROM SEQ:       [111,340,341,016] FC 1,7

                                ;ACT BUTS:      37[004]100,111  /  16[340]016,016

                                ;EXEC:          [016] D = #00166

                                ;CODES:         N:C = 1010

                                ;SYNC:          BOSJ2 (-) T = 1.8 USEC

                                ;KEY SIG:       K5-3 BR INSTR L   /   K5-3 FALSE BR L   /   K3-3 SM=2L   /   K3-3 IR(14:

014474  012700  000166          T0166:  MOV     #0166,R0                ;LOAD R0 WITH TEST NO.
014500  013701  014510                  MOV     @#I0166,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD

014504  000257                  R0166:  CCC                     ;CLEAR FLAGS
014506  000272                          272                     ;MAKE N,V = 11

014510  002002                  I0166:  BGE     00166           ;TEST THE BGE-IT SHOULD BR

014512  104005                  E0166:  ERROR5                  ;BGE FAILED
014514  014504                          R0166                   ;ERROR LOOP RETURN

014516  000004                   00166: SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0167 BLT TEST WITH N,V = 00
                                ; ***************************************************************

                                ;MICROPROGRAMMING   /   LOGIC INFORMATION

                                ;ROM SEQ:       [110,347,016] FC 1,7

                                ;ACT BUTS:      37[004]100,110  /  16[110]016,016

                                ;EXEC:          NO BRANCH

                                ;CODES:         N:C = 0000

                                ;SYNC:          B05J2 (-) T = 1.4 USEC

                                ;KEY SIG:       K5-3 BR INSTR L   /   K3-3 SM=2L

014520  012700  000167          T0167:  MOV     #0167,R0                ;LOAD R0 WITH TEST NO.
014524  013701  014532                  MOV     @#I0167,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD

014530  000257                  R0167:  CCC                     ;CLEAR FLAGS

014532  002401                  I0167:  BLT     E0167           ;TEST THE BLT-IT SHOULDN'T BR
014534  000402                          BR      00167           ;GO TO SCOPE EXIT

014536  104005                  E0167:  ERROR5                  ;BLT FAILED
014540  014530                          R0167                   ;ERROR LOOP RETURN

014542  000004                  00167:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0170 BLT TEST WITH N,V = 01
                                ; ***************************************************************

                                ;MICROPROGRAMMING   /   LOGIC INFORMATION

                                ;ROM SEQ:       [111,340,341,016] FC 1,7

                                ;ACT BUTS:      37[004]100,111  /  16[340]016,016

                                ;EXEC:          [016] D = #00170

                                ;CODES:         N:C = 0010

                                ;SYNC:          B05J2 (-) T = 1.8 USEC

                                ;KEY SIG:       K5-3 BR INSTR L   /   K5-3 TRUE BR L   /   K3-3 SM=2L   /   K3-3 IR(14:1

014544  012700  000170          T0170:  MOV     #0170,R0                ;LOAD R0 WITH TEST NO.
014550  013701  014560                  MOV     @#I0170,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD

014554  000257                  R0170:  CCC                     ;CLEAR FLAGS
014556  000262                          SEV                     ;MAKE N,V = 01

014560  002402                  I0170:  BLT     00170           ;TEST THE BLT-IT SHOULD BR

014562  104005                  E0170:  ERROR5                  ;BLT FAILED
014564  014554                          R0170                   ;ERROR LOOP RETURN

014566  000004                  00170:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0171 BLT TEST WITH N,V = 10
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [111,340,341,016] FC 1,7

                                ;ACT BUTS:      37[004]100,111 / 16[340]016,016

                                ;EXEC:          [016] D = #00171

                                ;CODES:         N:C = 1000

                                ;SYNC:          BOSJ2 (-) T = 1.8 USEC

                                ;KEY SIG:       K5-3 BR INSTR L  /  K3-3 SM=2L  /  K5-3 TRUE L

014570  012700  000171          T0171:  MOV     #0171,R0                ;LOAD R0 WITH TEST NO.
014574  013701  014604                  MOV     @#I0171,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD

014600  000257                  R0171:  CCC                     ;CLEAR FLAGS
014602  000270                          SEN                     ;SET N - N,V = 10

014604  002402                  I0171:  BLT     00171           ;TEST THE BLT-IT SHOULD BR

014606  104005                  E0171:  ERROR5                  ;BLT FAILED
014610  014600                          R0171                   ;ERROR LOOP RETURN

014612  000004                   00171: SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0172 BLT TEST WITH N,V = 11
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [110,347,016] FC 1,7

                                ;ACT BUTS:      37[004]100,110 / 16[110]016,016

                                ;EXEC:          NO BRANCH

                                ;CODES:         N:C = 1010

                                ;SYNC:          B05J2 (-) T = 1.4 USEC

                                ;KEY SIG:       K5-3 BR INSTR L  /  K3-3 SM=2L  /  K3-3 IR(14:12)=0 L

014614  012700  000172          T0172:  MOV     #0172,R0                ;LOAD R0 WITH TEST NO.
014620  013701  014630                  MOV     @#I0172,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD

014624  000257                  R0172:  CCC                     ;CLEAR FLAGS
014626  000272                          272                     ;MAKE N,V = 11

014630  002401                  I0172:  BLT     E0172           ;TEST THE BLT-IT SHOULDN'T BR
014632  000402                          BR      00172           ;GO TO SCOPE EXIT

014634  104005                  E0172:  ERROR5                  ;BLT FAILED
014636  014624                          R0172                   ;ERROR LOOP RETURN

014640  000004                  00172:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0173 BGT TEST WITH Z = 1 AND N,V = 01
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [110,347,016] FC 1,7

                                ;ACT BUTS:      37[004]100,110 / 16[110]016,016

                                ;EXEC:          NO BRANCH

                                ;CODES:         N:C = 0110

                                ;SYNC:          B05J2 (-) T = 1.4 USEC

                                ;KEY SIG:       K5-3 BR INSTR L  /  K3-3 SM=3L

014642  012700  000173          T0173:  MOV     #0173,R0                ;LOAD R0 WITH TEST NO.
014646  013701  014656                  MOV     @#I0173,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD

014652  000257                  R0173:  CCC                     ;CLEAR FLAGS
014654  000266                          266                     ;SET Z AND V

014656  003001                  I0173:  BGT     E0173           ;TEST THE BGT-IT SHOULDN'T BR
014660  000402                          BR      00173           ;GO TO SCOPE EXIT

014662  104005                  E0173:  ERROR5                  ;BGT FAILED
014664  014652                          R0173                   ;ERROR LOOP RETURN

014666  000004                  00173:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0174 BGT TEST WITH Z = 0 AND N,V = 01
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [110,347,016] FC 1,7

                                ;ACT BUTS:      37[004]100,110 / 16[110]016,016

                                ;EXEC:          NO BRANCH

                                ;CODES:         N:C = 0010

                                ;SYNC:          B05J2 (-) T = 1.4 USEC

                                ;KEY SIG:       K5-3 BR INSTR L  /  K3-3 SM=3L  /  K3-3 IR(14:12)=0 L

014670  012700  000174          T0174:  MOV     #0174,R0                ;LOAD R0 WITH TEST NO.
014674  013701  014716                  MOV     @#I0174,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD

014700  032737  000010  066642          BIT     #10,@#BPTLOC    ;BREAKPOINT HALT SET ??
014706  001401                          BEQ     .+4             ;BR IF NOT
014710  000000                          HALT                    ;BREAK - DEPRESS CONTINUE TO RESTART
014712  000257                  R0174:  CCC                     ;CLEAR FLAGS
014714  000262                          SEV                     ;SET V

014716  003001                  I0174:  BGT     E0174           ;TEST THE BGT-IT SHOULD NOT BR
014720  000402                          BR      00174           ;GO TO SCOPE LOOP EXIT

014722  104005                  E0174:  ERROR5                  ;BGT FAILED
014724  014712                          R0174                   ;ERROR LOOP RETURN

014726  000004                  00174:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0175 BGT TEST WITH Z = 1 AND N,V = 00
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [110,347,016] FC 1,7

                                ;ACT BUTS:      37[004]100,110 / 16[110]016,016

                                ;EXEC:          NO BRANCH

                                ;CODES:         N:C = 0100

                                ;SYNC:          BOSJ2 (-) T = 1.4 USEC

                                ;KEY SIG:       K5-3 BR INSTR L  /  K3-3 SM=3L

014730  012700  000175          T0175:  MOV     #0175,R0                ;LOAD R0 WITH TEST NO.
014734  013701  014744                  MOV     @#I0175,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD

014740  000257                  R0175:  CCC                     ;CLEAR FLAGS
014742  000264                          SEZ                     ;SET Z

014744  003001                  I0175:  BGT     E0175           ;TEST THE BGT-IT SHOULD NOT BR
014746  000402                          BR      00175           ;GO TO SCOPE LOOP EXIT

014750  104005                  E0175:  ERROR5                  ;BGT FAILED
014752  014740                          R0175                   ;ERROR LOOP RETURN

014754  000004                  00175:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0176 BGT TEST WITH Z = 0 AND N,V = 00
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [111,340,347,016] FC 1,7

                                ;ACT BUTS:      37[004]100,111 / 16[340]016,016

                                ;EXEC:          [016] D = #00176

                                ;CODE           N:C = 0000

                                ;SYNC:          BOSJ2 (-) T = 1.8 USEC

                                ;KEY SIG:       K5-3 BR INSTR L  /  K5-3 FALSE BR L  /  K3-3 SM=3L  /  K3-3 IR(14:12)=0

014756  012700  000176          T0176:  MOV     #0176,R0                ;LOAD R0 WITH TEST NO.
014762  013701  014770                  MOV     @#I0176,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD

014766  000257                  R0176:  CCC                     ;CLEAR FLAGS

014770  003002                  I0176:  BGT     00176           ;TEST THE BGT - IT SHOULD BR

014772  104005                  E0176:  ERROR5                  ;BGT FAILED
014774  014766                          R0176                   ;ERROR LOOP RETURN

014776  000004                  00176:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0177 BGT TEST WITH Z = 1 AND N,V = 01
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [110,347,016] FC 1,7

                                ;ACT BUTS:      37[004]100,110 / 16[110]016,016

                                ;EXEC:          NO BRANCH

                                ;CODES:         N:C = 0110

                                ;SYNC:          BOSJ2 (-) T = 1.4 USEC

                                ;KEY SIG:       K5-3 BR INSTR L  /  K3-3 SM=3L

015000  012700  000177          T0177:  MOV     #0177,R0                ;LOAD R0 WITH TEST NO.
015004  013701  015014                  MOV     @#I0177,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD

015010  000257                  R0177:  CCC                     ;CLEAR FLAGS
015012  000266                          266                     ;MAKE N,V = 01 AND Z = 1

015014  003001                  I0177:  BGT     E0177           ;TEST THE BGT-IT SHOULDN'T BR
015016  000402                          BR      00177           ;GO TO SCOPE EXIT

015020  104005                  E0177:  ERRORS                  ;BGT FAILED
015022  015010                          R0177                   ;ERROR LOOP RETURN

015024  000004                  00177:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0200 BGT TEST WITH Z = 1 AND N,V = 10
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [110,347,016] FC 1,7

                                ;ACT BUTS:      37[004]100,110 / 16[110]016,016

                                ;EXEC:          NO BRANCH

                                ;CODES:         N:C = 1100

                                ;SYNC:          B05J2 (-) T = 1.4 USEC

                                ;KEY SIG:       K5-3 BR INSTR L  /  K3-3 SM=3L  /  K3-3 IR(14:12)=0 L

015026  012700  000200          T0200:  MOV     #0200,R0                ;LOAD R0 WITH TEST NO.
015032  013701  015042                  MOV     @#I0200,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD

015036  000257                  R0200:  CCC                     ;CLEAR FLAGS
015040  000274                          274                     ;MAKE Z = 1 AND N,V = 10

015042  003001                  I0200:  BGT     E0200           ;TEST THE BLT-IT SHOULDN'T BR
015044  000402                          BR      00200           ;GO TO SCOPE EXIT

015046  104005                  E0200:  ERROR5                  ;BLT FAILED
015050  015036                          R0200                   ;ERROR LOOP RETURN

015052  000004                   00200: SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0201 BGT TEST WITH Z = 1 AND N,V = 11
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [110,347,016] FC 1,7

                                ;ACT BUTS:      37[004]100,110 / 16[110]016,016

                                ;EXEC:          NO BRANCH

                                ;CODES:         N:C = 1110

                                ;SYNC:          BOSJ2 (-) T = 1.4 USEC

                                ;KEY SIG:       K5-3 BR INSTR L  /  K3-3 SM=3L

015054  012700  000201          T0201:  MOV     #0201,R0                ;LOAD R0 WITH TEST NO.
015060  013701  015070                  MOV     @#I0201,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD

015064  000257                  R0201:  CCC                     ;CLEAR FLAGS
015066  000276                          276                     ;MAKE Z = 1 AND N,V = 11

015070  003001                  I0201:  BGT     E0201           ;TEST THE BGT-IT SHOULD NOT BR
015072  000402                          BR      00201           ;GO TO SCOPE EXIT

015074  104005                  E0201:  ERRORS                  ;BLT FAILED
015076  015064                          R0201                   ;ERROR LOOP RETURN

015100  000004                  00201:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0202 BGT TEST WITH Z=0 AND N,V=11
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [111,340,341,016] FC 1,7

                                ;ACT BUTS:      37[004]100,111 / 16[340]016,016

                                ;EXEC:          [016] D = #00202

                                ;CODES:         N:C = 1010

                                ;SYNC:          B05J2 (-) T = 1.8 USEC

                                ;KEY SIG:       K5-3 BR INSTR L  /  K5-3 FALSE BR L  /  K3-3 SM=3L  /  K3-3 IR(14:12)=0


015102  012700  000202          T0202:  MOV     #0202,R0                ;LOAD R0 WITH TEST NO.
015106  013701  015116                  MOV     @#I0202,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD

015112  000257                  R0202:  CCC                     ;CLEAR FLAGS
015114  000272                          272                     ;MAKE N:C=1010

015116  003002                  I0202:  BGT     00202           ;TEST THE BGT - IT SHOULD BR

015120  104005                  E0202:  ERRORS                  ;BGT FAILED
015122  015112                          R0202                   ;ERROR LOOP RETURN

015124  000004                  00202:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0203 BLE TEST WITH Z = 0, AND N,V = 00
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [110,347,016] FC 1,7

                                ;ACT BUTS:      37[004]100,110 / 16[110]016,016

                                ;EXEC:          NO BRANCH

                                ;CODES:         N:C = 0000

                                ;SYNC:          BOSJ2 (-) T = 1.4 USEC

                                ;KEY SIG:       K5-3 BR INSTR L  /  K3-3 SM=3L

015126  012700  000203          T0203:  MOV     #0203,R0                ;LOAD R0 WITH TEST NO.
015132  013701  015140                  MOV     @#I0203,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD

015136  000257                  R0203:  CCC                     ;CLEAR FLAGS

015140  003401                  I0203:  BLE     E0203           ;TEST THE BLE-IT SHOULDN'T BR
015142  000402                          BR      00203           ;GO TO SCOPE EXIT

015144  104005                  E0203:  ERROR5                  ;BLE FAILED
015146  015136                          R0203                   ;ERROR LOOP RETURN

015150  000004                   00203: SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0204 BLE TEST WITH Z = 1 AND N,V = 00
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [111,340,341,016] FC 1,7

                                ;ACT BUTS:      37[004]100,111 / 16[340]016,016

                                ;EXEC:          [016] D = #00204

                                ;CODES:         N:C = 0100

                                ;SYNC:          B05J2 (-) T = 1.8 USEC

                                ;KEY SIG:       K5-3 BR INSTR L  /  K5-3 TRUE BR L  /  K3-3 SM=3L  /  K3-3 IR(14:12)=0 L

015152  012700  000204          T0204:  MOV     #0204,R0                ;LOAD R0 WITH TEST NO.
015156  013701  015166                  MOV     @#I0204,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD

015162  000257                  R0204:  CCC                     ;CLEAR FLAGS
015164  000264                          SEZ                     ;SET Z = 1

015166  003402                  I0204:  BLE     00204           ;TEST THE BLE-IT SHOULD BR

015170  104005                  E0204:  ERROR5                  ;BLE FAILED
015172  015162                          R0204                   ;ERROR LOOP RETURN

015174  000004                   00204: SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0205 BLE TEST WITH Z = 0 AND N,V = 01
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [111,340,341,016] FC 1,7

                                ;ACT BUTS:      37[004]100,111 / 16[340]016,016

                                ;EXEC:          [016] D = #00205

                                ;CODES:         N:C = 0010

                                ;SYNC:          B05J2 (-) T = 1.8 USEC

                                ;KEY SIG:       K5-3 BR INSTR L  /  K5-3 TRUE BR L  /  K3-3 SM=3L  /  K5-2 PS(V)(1)H

015176  012700  000205          T0205:  MOV     #0205,R0                ;LOAD R0 WITH TEST NO.
015202  013701  015212                  MOV     @#I0205,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD

015206  000257                  R0205:  CCC                     ;CLEAR FLAGS
015210  000262                          SEV                     ;MAKE Z = 0 AND N,V = 01

015212  003402                  I0205:  BLE     00205           ;TEST THE BLE-IT SHOULD BR

015214  104005                  E0205:  ERROR5                  ;BLE FAILED
015216  015206                          R0205                   ;ERROR LOOP RETURN

015220  000004                   00205: SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0206 BLE TEST WITH Z = 0 AND N,V = 10
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [111,340,341,016] FC 1,7

                                ;ACT BUTS:      37[004]100,111 / 16[340]016,016

                                ;EXEC:          [016] D = #00206

                                ;CODES:         N:C = 1000

                                ;SYNC:          B05J2 (-) T = 1.8 USEC

                                ;KEY SIG:       K5-3 BR INSTR L  /  K5-3 TRUE BR L  /  K3-3 SM=3L  /  K3-3 IR(14:12)=0 L
                                                ;  K5-2 PS(N)(I)H

015222  012700  000206          T0206:  MOV     #0206,R0                ;LOAD R0 WITH TEST NO.
015226  013701  015236                  MOV     @#I0206,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD

015232  000257                  R0206:  CCC                     ;CLEAR FLAGS
015234  000270                          SEN                     ;MAKE Z = 0 AND N,V = 10

015236  003402                  I0206:  BLE     00206           ;TEST THE BLE-IT SHOULD BR

015240  104005                  E0206:  ERROR5                  ;BLE FAILED
015242  015232                          R0206                   ;ERROR LOOP RETURN

015244  000004                  00206:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0207 BLE TEST WITH Z = 0 AND N,V = 11
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [110,347,016] FC 1,7

                                ;ACT BUTS:      37[004]100,110 / 16[110]016,016

                                ;EXEC:          NO BRANCH

                                ;CODES:         N:C = 1010

                                ;SYNC:          B05J2 (-) T = 1.4 USEC

                                ;KEY SIG:       K5-3 BR INSTR L  /  K3-3 SM=3L

015246  012700  000207          T0207:  MOV     #0207,R0                ;LOAD R0 WITH TEST NO.
015252  013701  015262                  MOV     @#I0207,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD

015256  000257                  R0207:  CCC                     ;CLEAR FLAGS
015260  000272                          272                     ;MAKE Z = 0 AND N,V = 11

015262  003401                  I0207:  BLE     E0207           ;TEST THE BLE-IT SHOULDN'T BR
015264  000402                          BR      00207           ;GO TO SCOPE EXIT

015266  104005                  E0207:  ERROR5                  ;BLE FAILED
015270  015256                          R0207                   ;ERROR LOOP RETURN

015272  000004                  00207:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0210 BHI TEST WITH Z,C = 00
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [111,340,341,016] FC 1,7

                                ;ACT BUTS:      37[004]100,111 / 16[340]016,016

                                ;EXEC:          [016] D = #00210

                                ;CODES:         N:C = 0000

                                ;SYNC:          B05J2 (-) T = 1.8 USEC

                                ;KEY SIG:       K5-3 BR INSTR L  /  K5-3 FALSE BR L  /  K3-3 SM=1L  /  K3-4 IR15 L

015274  012700  000210          T0210:  MOV     #0210,R0                ;LOAD R0 WITH TEST NO.
015300  013701  015306                  MOV     @#I0210,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD

015304  000257                  R0210:  CCC                     ;MAKE Z,C = 00

015306  101002                  I0210:  BHI     00210           ;TEST THE BHI-IT SHOULD BR

015310  104005                  E0210:  ERROR5                  ;BHI FAILED
015312  015304                          R0210                   ;ERROR LOOP RETURN

015314  000004                   00210: SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0211 BHI TEST WITH Z,C = 01
                                ; ***************************************************************

                                ;MICROPROGRAMMING   /   LOGIC INFORMATION

                                ;ROM SEQ:       [110,347,016] FC 1,7

                                ;ACT BUTS:      37[004]100,110  /  16[110]016,016

                                ;EXEC:          NO BRANCH

                                ;CODES:         N:C = 0001

                                ;SYNC:          B05J2 (-) T = 1.4 USEC

                                ;KEY SIG:       K5-3 BR INSTR L   /   K3-3 SM=1L   /   K3-4 IR15 L

015316  012700  000211          T0211:  MOV     #0211,R0                ;LOAD R0 WITH TEST NO.
015322  013701  015332                  MOV     @#I0211,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD

015326  000257                  R0211:  CCC                     ;CLEAR FLAGS
015330  000261                          SEC                     ;MAKE Z,C = 01

015332  101001                  I0211:  BHI     E0211           ;TEST THE BHI-IT SHOULD NOT BR
015334  000402                          BR      00211           ;GO TO SCOPE EXIT

015336  104005                  E02'1:  ERROR5                  ;BHI FAILED
015340  015326                          R0211                   ;ERROR LOOP RETURN

015342  000004                   00211: SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0212 BHI TEST WITH Z,C = 10
                                ; ***************************************************************

                                ;MICROPROGRAMMING   /   LOGIC INFORMATION

                                ;ROM SEQ:       [110,347,016] FC 1,7

                                ;ACT BUTS:      37[004]100,110  /  16[110]016,016

                                ;EXEC:          NO BRANCH

                                ;CODES:         N:C = 0100

                                ;SYNC:          B05J2 (-) T = 1.4 USEC

                                ;KEY SIG:       K5-3 BR INSTR L   /   K3-3 SM=1L   /   K3-4 IR15 L

015344  012700  000212          T0212:  MOV     #0212,R0                ;LOAD R0 WITH TEST NO.
015350  013701  015360                  MOV     @#I0212,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD

015354  000257                  R0212:  CCC                     ;CLEAR FLAGS
015356  000264                          SEZ                     ;MAKE Z,C = 10

015360  101001                  I0212:  BHI     E0212           ;TEST THE BHI-IT SHOULD NOT BR
015362  000402                          BR      00212           ;GO TO SCOPE EXIT

015364  104005                  E0212:  ERROPS                  ;BHI FAILED
015366  015354                          R0212                   ;ERROR LOOP RETURN

015370  000004                   00212: SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0213 BHI TEST WITH Z,C = 11
                                ;*****************************************************************

                                ;MICROPROGRAMMING   /   LOGIC INFORMATION

                                ;ROM SEQ:       [110,347,016] FC 1,7

                                ;ACT BUTS:      37[004]100,110  /  16[110]016,016

                                ;EXEC:          NO BRANCH

                                ;CODES:         N:C = 0101

                                ;SYNC:          B05J2 (-) T = 1.4 USEC

                                ;KEY SIG:       K5-3 BR INSTR L   /   K3-3 SM=1L   /   K3-4 IR15 L

015372  012700  000213          T0213:  MOV     #0213,R0                ;LOAD R0 WITH TEST NO.
015376  013701  015406                  MOV     @#I0213,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD

015402  000257                  R0213:  CCC                     ;CLEAR FLAGS
015404  000265                          265                     ;MAKE Z,C = 11

015406  101001                  I0213:  BHI     E0213           ;TEST THE BHI-IT SHOULDN'T BR
015410  000402                          BR      00213           ;GO TO SCOPE EXIT

015412  104005                  E0213:  ERRORS                  ;BHI FAILED
015414  015402                          R0213                   ;ERROR LOOP RETURN

015416  000004                  00213:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***********************************************************************
                                        .SBTTL T0214 BLOS TEST WITH Z,C = 00
                                ; ***********************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [110,347,016] FC 1,7

                                ;ACT BUTS:      37[004]100,110 / 16[110]016,016

                                ;EXEC:          NO BRANCH

                                ;CODES:         N:C = 0000

                                ;SYNC:          BOSJ2 (-) T = 1.4 USEC

                                ;KEY SIG:       K5-3 BR INSTR H  /  K3-3 SM=3L  /  K3-4 IR15 L

015420  012700  000214          T0214:  MOV     #0214,R0                ;LOAD R0 WITH TEST NO.
015424  013701  015432                  MOV     @#I0214,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD

015430  000257                  R0214:  CCC                     ;MAKE Z,C = 00

015432  101401                  I0214:  BLOS    E0214           ;TEST THE BLOS-IT SHOULDN'T BR
015434  000402                          BR      00214           ;GO TO SCOPE EXIT

015436  104005                  E0214:  ERRORS                  ;BLOS FAILED
015440  015430                          R0214                   ;ERROR LOOP RETURN

015442  000004                   00214: SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ****************************************************************
                                        .SBTTL T0215 BLOS TEST WITH Z,C = 01
                                ; ****************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [111,340,341,016] FC 1,7

                                ;ACT BUTS:      37[004]100,111 / 16[340]016,016

                                ;EXEC:          [016] D = #00215

                                ;CODES:         N:C = 0001

                                ;SYNC:          BOSJ2 (-) T = 1.8 USEC

                                ;KEY SIG:       K5-3 BR INSTR L  /  K5-3 TRUE BR L  /  K3-3 SMALL  /  K3-4 IR15 L
                                                ;  K5-2 PS(C)(1)L

015444  012700  000215          T0215:  MOV     #0215,R0                ;LOAD R0 WITH TEST NO.
015450  013701  015460                  MOV     @#I0215,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD

015454  000257                  R0215:  CCC                     ;CLEAR FLAGS
015456  000261                          SEC                     ;MAKE Z,C = 01

015460  101402                  I0215:  BLOS    00215           ;TEST THE BLOS-IT SHOULD BR

015462  104005                  E0215:  ERRORS                  ;BLOS FAILED
015464  015454                          R0215                   ;ERROR LOOP RETURN

015466  000004                   00215: SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL TO216 BLOS TEST WITH Z,C = 10
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [111,340,341,016] FC 1,7

                                ;ACT BUTS:      37[004]100,111 / 16[340]016,016

                                ;EXEC:          [016] D = #00216

                                ;CODES:         N:C = 0100

                                ;SYNC:          B05J2 (-) T = 1.8 USEC

                                ;KEY SIG:       K5-3 BR INS.R L  /  K5-3 TRUE BR L  /  K3-3 SM=1L  /  K3-4 IR15 L
                                                ;  K5-2 PS(Z)(I)L

015470  012700  000216          TO216:  MOV     #0216,R0                ;LOAD R0 WITH TEST NO.
015474  013701  015504                  MOV     @#I0216,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD

015500  000257                  RO216:  CCC                     ;CLEAR FLAGS
015502  000264                          SEZ                     ;MAKE Z,C = 10

015504  101402                  IO216:  BLOS    00216           ;TEST THE BLOS-IT SHOULD BR

015506  104005                  EO216:  ERROR5                  ;BLOS FAILED
015510  015500                          RO216                   ;ERROR LOOP RETURN

015512  000004                   00216: SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0217 BLOS TEST WITH Z,C = 11
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [111,340,341,016] FC 1,7

                                ;ACT BUTS:      37[004]100,111 / 16[340]016,016

                                ;EXEC:          [016] D = #00217

                                ;CODES:         N:C = 0101

                                ;SYNC:          BOSJ2 (-) T = 1.8 USEC

                                ;KEY SIG:       K5-3 BR INSTR L  /  K5-3 TRUE BR L  /  K3-3 SM=1L  /  K3-4 IR15 L
                                                ;  K5-2 PS(C)(I)L

015514  012700  000217          T0217:  MOV     #0217,R0                ;LOAD R0 WITH TEST NO.
015520  013701  015530                  MOV     @#I0217,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD

015524  000257                  R0217:  CCC                     ;CLEAR FLAGS
015526  000265                          265                     ;MAKE Z,C = 11

015530  101402                  I0217:  BLOS    00217           ;TEST THE BLOS-IT SHOULD BR

015532  104005                  E0217:  ERROR5                  ;BLOS FAILED
015534  015524                          R0217                   ;ERROR LOOP RETURN

015536  000004                  00217:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0220 BHIS TEST WITH C = 0
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [111,340,341,016] FC 1,7

                                ;ACT BUTS:      37[004]100,111 / 16[340]016,016

                                ;EXEC:          [016] D = #00220

                                ;CODES:         N:C = 0000

                                ;SYNC:          BOSJ2 (-)  T = 1.8 USEC

                                ;KEY SIG:       K5-3 BR INSTR L  /  K5-3 FALSE BR L  /  K3-3 SM=3L  /  K3-4 IR15 L

015540  012700  000220          T0220:  MOV     #0220,R0                ;LOAD R0 WITH TEST NO.
015544  013701  015552                  MOV     @#T0220,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD

015550  000257                  R0220:  CCC                     ;CLEAR FLAGS

015552  103002                  T0220:  BHIS    00220           ;TEST THE BHIS-IT SHOULD BR

015554  104000                  E0220:  ERROR                   ;BHIS FAILED
015556  015550                          R0220                   ;ERROR LOOP RETURN

015560  000004                   00220: SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0221 BHIS TEST WITH C = 1
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [110,347,016] FC 1,7

                                ;ACT BUTS:      37[004]100,110 / 16[110]016,016

                                ;EXEC:          NO BRANCH

                                ;CODES:         N:C = 0001

                                ;SYNC:          B05J2 (-) T = 1.4 USEC

                                ;KEY SIG:       K5-3 BR INSTR L  /  K3-3 SM=3L  /  K3-4 IR15 L

015562  012700  000221          T0221:  MOV     #0221,R0                ;LOAD R0 WITH TEST NO.
015566  013701  015576                  MOV     @#I0221,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD

015572  000257                  R0221:  CCC                     ;CLEAR FLAGS
015574  000261                          SEC                     ;MAKE C = 1

015576  103001                  I0221:  BHIS    E0221           ;TEST THE BHIS-IT SHOULDN'T BR
015600  000402                          BR      00221           ;GO TO SCOPE EXIT

015602  104000                  E0221:  ERROR                   ;BHIS FAILED
015604  015572                          R0221                   ;ERROR LOOP RETURN

015606  000004                  00221:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ****************************************************************
                                        .SBTTL T0222 BLO TEST WITH C = 0
                                ; ****************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [110,347,016] FC 1,7

                                ;ACT BUTS:      37[004]100,111 / 16[110]016,016

                                ;EXEC:          NO BRANCH

                                ;CODES:         N:C = 0000

                                ;SYNC:          B05J2 (-) T = 1.4 USEC

                                ;KEY SIG:       K5-3 BR INSTR L  /  K3-3 SM=3L  /  K3-4 IR15 L

015610  012700  000222          T0222:  MOV     #0222,R0                ;LOAD R0 WITH TEST NO.
015614  013701  015622                  MOV     @#I0222,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD

015620  000257                  R0222:  CCC                     ;CLEAR FLAGS

015622  103401                  I0222:  BLO     E0222           ;TEST THE BLO-IT SHOULDN'T BR
015624  000402                          BR      00222           ;GO TO SCOPE EXIT

015626  104005                  E0222:  ERROR5                  ;BLO FAILED
015630  015620                          R0222                   ;ERROR LOOP RETURN

015632  000004                  00222:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0223 BLO TEST WITH C = 1
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [111,340,341,016] FC 1,7

                                ;ACT BUTS:      37[004]100,111 / 16[340]016,016

                                ;EXEC:          [016] D = #00223

                                ;CODES:         N:C = 0001

                                ;SYNC:          B05J2 (-) T = 1.8 USEC

                                ;KEY SIG:       K5-3 BR INSTR L  /  K5-3 TRUE BR L  /  K5-2 PS(C)(1)H  /  K3-3 SM=3L
                                                ;  K3-4 IR15 L

015634  012700  000223          T0223:  MOV     #0223,R0                ;LOAD R0 WITH TEST NO.
015640  013701  015650                  MOV     @#I0223,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD

015644  000257                  R0223:  CCC                     ;CLEAR FLAGS
015646  000261                          SEC                     ;MAKE C = 1

015650  103402                  I0223:  BLO     00223           ;TEST THE BLO-IT SHOULD BR

015652  104005                  E0223:  ERROR5                  ;BLO FAILED
015654  015644                          R0223                   ;ERROR LOOP RETURN

015656  000004                   00223: SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0224 SXT MODE 0 TEST WITH N = 0 AND C = 1
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [132,360,001] FC 1,8

                                ;ACT BUTS:      37[004]100,132 / 27[132]000,001

                                ;EXEC:          [132]ALUC=HLLHH :[360] D = 000000

                                ;CODES:         [360] SPS=3  /  N:C = 0101

                                ;SYNC:          BOSJ2 (-) T = 1 USEC

                                ;KEY SIG:       K3-3 DM=OL  /  K3-4 ONLAP INSTR H  /  K3-5 SXT L  /  K3-8 ALUM H

015660  012700  000224          T0224:  MOV     #0224,R0                ;LOAD R0 WITH TEST NO.
015664  013701  015706                  MOV     @#I0224,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
015670  005004                          CLR     R4              ;RESULT S . B = 0
015672  012702  177703                  MOV     #177703,R2      ;DEST ADDR = R3
015676  012703  177777          R0224:  MOV     #-1,R3          ;INITAL DEST. OP = 177777
015702  000257                          CCC                     ;CLEAR CODES
015704  000263                          263                     ;N:C = 0011

015706  006703                  I0224:  SXT     R3              ;TEST THE SXT

015710  100403                          BMI     E10224
015712  001002                          BNE     E10224          ;DID SXT MAKE N:C = 0101?
015714  102401                          BVS     E10224
015716  103402                          BCS     A0224

015720  104000                  E10224: ERROR                   ;SXT FAILED TO ALTER CODES PROPERLY
015722  015676                          R0224                   ;ERROR LOOP RETURN

015724  005703                  A0224:  TST     R3              ;DID RESULT = 0?
015726  001402                          BEQ     00224           ;BR IF IT DID

015730  104000                  E20224: ERROR                   ;SXT DELIVERED WRONG RESULT TO R3
015732  015676                          R0224                   ;ERROR LOOP RETURN

015734  000004                   00224: SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0225 SXT MODE 0 TEST WITH N = 0 AND C = 0
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [132,360,001] FC 1,8

                                ;ACT BUTS:      37[004]100,132 / 27[132]000,001

                                ;EXEC:          [132]ALUC=HLLHH :[360] D = 000000

                                ;CODES:         [360] SPS=3  /  N:C = 0100

                                ;SYNC:          BOSJ2 (-) T = 1 USEC

                                ;KEY SIG:       K3-3 DM=OL  /  K3-4 OVLAP INSTR H  /  K3-5 SXT L  /  K3-8 ALUM H

015736  012700  000225          T0225:  MOV     #0225,R0                ;LOAD R0 WITH TEST NO.
015742  013701  015762                  MOV     @#I0225,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD

015746  005004                          CLR     R4              ;RESULT S / B = 0
015750  012702  177703                  MOV     #177703,R2      ;DEST ADDR = R3
015754  012703  177777          R0225:  MOV     #-1,R3          ;INITIAL DEST OP = 177777
015760  000257                          CCC                     ;CLEAR N:C

015762  006703                  I0225:  SXT     R3              ;TEST THE SXT
015764  103002                          BCC     00225           ;BR IF "C" STILL CLEAR

015766  104000                  E0225:  ERROR                   ;SXT AFFECTED "C" BIT
015770  015754                          R0225                   ;ERROR LOOP RETURN

015772  000004                   00225: SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0226 SXT MODE 0 TEST WITH N = 1 AND C = 1
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [132,360,001] FC 1,8

                                ;ACT BUTS:      37[004]100,132 / 27[132]000,001

                                ;EXEC:          [132]A' UC=LL.HH :[360] D = 177777

                                ;CODES:         [360] SPS=3  /  N:C = 1001

                                ;SYNC:          B05J2 (-) T = 1 USEC

                                ;KEY SIG:       K3-3 DM=OL  /  K3-4 OVLAP INSTR H  /  K3-5 SXT L  /  K5-2 PS(N)(1)H

015774  012700  000226          T0226:  MOV     #0226,R0                ;LOAD R0 WITH TEST NO.
016000  013701  016020                  MOV     @#I0226,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD

016004  012704  177777                  MOV     #-1,R4          ;RESULT S / B = 177777
016010  012703  177703                  MOV     #177703,R3      ;DEST ADDR = 177703
016014  005003                  R0226:  CLR     R3              ;INITIAL DEST OP = 0
016016  000277                          SCC                     ;MAKE N:C = 1111

016020  006703                  I0226:  SXT     R3              ;TEST THE SXT

016022  100003                          BPL     E10226
016024  001402                          BEQ     E10226          ;N:C = 1001?
016026  102401                          BVS     E10226
016030  103402                          BCS     A0226

016032  104000                  E10226: ERROR                   ;SXT FAILED TO ALTER CODES PROPERLY
016034  016014                          R0226                   ;ERROR LOOP RETURN

016036  010305                  A0226:  MOV     R3,R5           ;GET RESULT
016040  005105                          COM     R5              ;COMPLEMENT IT-SHOULD GO TO 0
016042  001402                          BEQ     00226           ;BR IF RESULT OF SXT = 1

016044  104000                  E20226: ERROR                   ;SXT DELIVERED WRONG RESULT.
016046  016014                          R0226                   ;ERROR LOOP RETURN

016050  000004                   00226: SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***************************************************************
                                                .SBTTL TO227 SXT MODE 0 TEST WITH N = 1 AND C = 0
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [132,360,001] FC 1,8

                                        ;ACT BUTS:      37[004]100,132 / 27[132]000,001

                                        ;EXEC:          [132]ALUC=LLLHH :[360] D = 177777

                                        ;CODES:         [360] SPS=3  /  N:C = 1000

                                        ;SYNC:          B05J2 (-)  T = 1 USEC

                                        ;KEY SIG:       K3-3 DM = DL  /  K3-4 OVLAP INSTR H  /  K3-5 SXT L  /  K5-2 PS(N)(1) H

016052  012700  000227                  TO227:  MOV     #0227,R0                ;LOAD R0 WITH TEST NO.
016056  013701  016100                          MOV     @#I0227,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD

016062  012704  177777                          MOV     #-1,R4          ;RESULT S / B = 177777
016066  012702  177703                          MOV     #177703,R2      ;DEST ADDR = 177703
016072  005003                          R0227:  CLR     R3              ;INITIAL DEST OP = 0
016074  000257                                  CCC                     ;CLEAR FLAGS
016076  000276                                  276                     ;MAKE N:C = 1110

016100  006703                          I0227:  SXT     R3              ;TEST THE SXT
016102  103002                                  BCC     00227           ;BR IF "C" UNAFFECTED

016104  104000                          E0227:  ERROR                   ;SXT SET "C" BIT
016106  016072                                  R0227                   ;ERROR LOOP RETURN

016110  000004                           00227: SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***************************************************************
                                                .SBTTL TO230 SXT MODE 1 AND 2 TEST WITH N = 0 AND C = 1
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:(DM1)  [161,266,267,234,367,375,016] FC 1,3,8
                                        ;       :(DM2)  [162,260,267,234,367,375,016] FC 1,3,8

                                        ;ACT BUTS:(DM1) 37[004]100,161 / 33[266]220,234 / 16[367]016,016
                                        ;       :(DM2)  37[004]100,162 / 33[260]220,234 / 16[367]016,016

                                        ;EXEC:          [234]ALUC=HLLHH :[367] D = 000000

                                        ;CODES:         [367] SPS=3  /  N:C = 0101

                                        ;SYNC:          B05J2 (-) T = 2.5 USEC

                                        ;KEY SIG:       K3-3 DM=1L  /  K3-5 SXT L  /  K3-8 ALUM H

016112  012700  000230                  TO230:  MOV     #0230,R0                ;LOAD R0 WITH TEST NO.
016116  013701  016140                          MOV     @#I10230,R1     ;LOAD R1 WITH TEST INSTRUCTION WORD

016122  012702  067602                          MOV     #MBUF0,R2       ;R2 POINTS TO DEST OP
016126  005004                                  CLR     R4              ;RESULT S / B = 0
016130  012712  177777                  R10230: MOV     #-1,(R2)        ;INITIAL [DEST] = 177777
016134  000257                                  CCC                     ;CLEAR CODES
016136  000263                                  263                     ;MAKE N:C = 0011

016140  006712                          I10230: SXT     (R2)            ;TEST THE SXT - DM1

016142  100403                                  BMI     E10230
016144  001002                                  BNE     E10230          ;N:C = 0101
016146  102401                                  BVS     E10230
016150  103402                                  BCS     A0230

016152  104000                          E10230: ERROR                   ;SXT FAILED TO ALTER CODES PROPERLY
016154  016130                                  R10230                  ;ERROR LOOP RETURN

016156  005712                          A0230:  TST     (R2)            ;DID RESULT = 0?
016160  001402                                  BEQ     R20230          ;BR IF YES

016162  104000                          E20230: ERROR                   ;SXT SHOULD HAVE ZEROED [DEST]
016164  016130                                  R10230                  ;ERROR LOOP RETURN

016166  012702  067602                  R20230: MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
016172  013701  016206                          MOV     @#I20230,R1     ;LOAD R1 WITH TEST INSTR WORD
016176  012712  177777                          MOV     #-1,(R2)        ;INITIAL [DEST] = 177777
016202  000257                                  CCC                     ;CLEAR CODES
016204  000263                                  263                     ;MAKE N:C = 0011

016206  006722                          I20230: SXT     (R2)+           ;TEST SXT - DM2

016210  100403                                  BMI     E30230          ;N:C = 0101 ?
016212  001002                                  BNE     E30230
016214  102401                                  BVS     E30230
```

```
016216  103402                          BCS     B0230

016220  104000                  E30230: ERROR                   ;SXT FAILED TO ALTER CODES PROPERLY
016222  016166                          R20230                  ;ERROR LOOP RETURN ADDRESS

016224  005737  067602          B0230:  TST     @#MBUF0         ;DID RESULT GET ZEROED ?
016230  001402                          BEQ     C0230           ;BR IF YES

016232  104000                  E40230: ERROR                   ;SXT FAILED TO ZERO [DEST]
016234  016166                          R20230                  ;ERROR LOOP RETURN ADDRESS

016236  020227  067604          C0230:  CMP     R2,#MBUF0+2     ;WAS IT REALLY MODE 2 ?
016242  001402                          BEQ     00230           ;BR IF YES

016244  104000                  E50230: ERROR                   ;SXT FAILED TO AUTO INCREMENT
016246  016166                          R20230                  ;ERROR LOOP RETURN ADDRESS

016250  000004                   00230: SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0231 SXT MODE 1 TEST WITH N = 0 AND C = 0
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [161,266,267,234,367,375,016] FC 1,3,8

                                ;ACT BUTS:      37[004]100,161 / 33[266]220,234 / 16[367]016,016

                                ;EXEC:          [234]ALUC=HLLHH :[367] D = 000000

                                ;CODES:         [367] SPS=3  /  N:C = 0100

                                ;SYNC:          BOSJ2 (-) T = 2.5 USEC

                                ;KEY SIG:       K3-3 DM=1L  /  K3-5 SXT L  /  K3-8 ALUM H

016252  012700  000231          T0231:  MOV     #0231,R0                ;LOAD R0 WITH TEST NO.
016256  013701  016276                  MOV     @#I0231,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD

016262  005004                          CLR     R4              ;RESULT S / B = 0
016264  012702  067602                  MOV     #MBUF0,R2       ;R2 POINTS TO DEST OP
016270  012712  177777          R0231:  MOV     #-1,(R2)        ;INITIAL [DEST] = 177777
016274  000257                          CCC                     ;CLEAR "C" BIT

016276  006712                  I0231:  SXT     (R2)            ;TEST THE SXT
016300  103002                          BCC     00231           ;BR IF "C" UNDISTURBED

016302  104000                  E0231:  ERROR                   ;SXT SET THE "C" BIT
016304  016270                          R0231                   ;ERROR LOOP RETURN

016306  000004                  00231:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0232 SXT MODE 1 TEST WITH N = 1 AND C = 1
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [161,266,267,234,367,375,016] FC 1,3,8

                                ;ACT BUTS:      37[004]100,161 / 33[266]220,234 / 16[367]016,016

                                ;EXEC:          [234]ALUC=LLLHH :[367] D = 177777

                                ;CODES:         [367] SPS=3  /  N:C =1001

                                ;SYNC:          B05J2 (-) T = 2.5 USEC

                                ;KEY SIG:       K3-3 DM=1L  /  K3-5 SXT L  /  K5-2 PS(N)(1)H

016310  012700  000232          T0232:  MOV     #0232,R0                ;LOAD R0 WITH TEST NO.
016314  013701  016334                  MOV     @#I0232,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD

016320  012704  177777                  MOV     #-1,R4          ;RESULT S / B = 177777
016324  012702  067602                  MOV     #MBUF0,R2       ;R2 POINTS TO DEST OP
016330  005012                  R0232:  CLR     (R2)            ;INITIAL [DEST] = 0
016332  000277                          SCC                     ;MAKE N:C = 1111

016334  006712                  I0232:  SXT     (R2)            ;TEST THE SXT

016336  100003                          BPL     E10232
016340  001402                          BEQ     E10232          ;N:C = 1001?
016342  102401                          BVS     E10232
016344  103402                          BCS     A0232

016346  104000                  E10232: ERROR                   ;SXT FAILED TO ALTER CODES PROPERLY
016350  016330                          R0232                   ;ERROR LOOP RETURN

016352  021204                  A0232:  CMP     (R2),R4         ;RESULT = 177777?
016354  001402                          BEQ     00232           ;BR IF YES

016356  104000                  E20232: ERROR                   ;SXT DELIVERED WRONG RESULT
016360  016330                          R0232                   ;ERROR LOOP RETURN

016362  000004                  00232:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0233 SXT MODE 1 TEST WITH N = 1 AND C = 0
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [161,266,267,234,367,375,016] FC 1,3,8

                                ;ACT BUTS:      37[004]100,161 / 33[266]220,234 / 16[367]016,016

                                ;EXEC:          [234]ALUC=LLLHH :[367] D = 177777

                                ;CODES:         [367] SPS=3  /  N:C = 1000

                                ;SYNC:          BOSJ2 (-) T = 2.5 USEC

                                ;KEY SIG:       K3-3 DM=1L  /  K3-5 SXT L  /  K5-2 PS(N)(1)H

016364  012700  000233          T0233:  MOV     #0233,R0                ;LOAD R0 WITH TEST NO.
016370  013701  016412                  MOV     @#I0233,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD

016374  012704  177777                  MOV     #-1,R4          ;RESULT S / B = 177777
016400  012702  067602                  MOV     #MBUF0,R2       ;R2 POINTS TO DEST OP
016404  005012                  R0233:  CLR     (R2)            ;INITIAL [DEST] = 0
016406  000257                          CCC                     ;CLEAR FLAGS
016410  000276                          276                     ;MAKE N:C = 1110

016412  006712                  I0233:  SXT     (R2)            ;TEST THE SXT
016414  103002                          BCC     00233           ;BR IF "C" UNAFFECTED

016416  104000                  E0233:  ERROR                   ;SXT SET THE "C" BIT
016420  016404                          R0233                   ;ERROR LOOP RETURN

016422  000004                   00233: SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***************************************************************
                                                .SBTTL T0234 SWAB MODE 0 TEST WITH POS. RESULT
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [134,135,360,001] FC 1,7,8

                                        ;ACT BUTS:      37[004]100,134 / 27[135]000,001

                                        ;EXEC:          [135]ALUC=HHLHL :[360] D = 177400

                                        ;CODES:         [360] SPS=3  /  N:C = 0100

                                        ;SYNC:          B05J2 (-) T = 1 USEC

                                        ;KEY SIG:       K2-5 SBML1 (1) H  /  K2-5 SMBL0 (1) L  /  K2-5 SBMH1 (1) H
                                                        ;  /  K2-5 SBMH0 (1) L  /  K3-3 DM=0L  /  K3-5 SWAB H  /  K3-4 OVLAP INS

016424  012700  000234          T0234:  MOV     #0234,R0                ;LOAD R0 WITH TEST NO.
016430  013701  016466                  MOV     @#I0234,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD

016434  032737  000020  066642          BIT     #20,@#BPTLOC    ;BREAKPOINT HALT SET ??
016442  001401                          BEQ     .+4             ;BR IF NOT
016444  000000                          HALT                    ;BREAK - DEPRESS CONTINUE TO RESTART
016446  012704  177400                  MOV     #177400,R4      ;RESULT S / B = 177400
016452  012702  177703                  MOV     #177703,R2      ;DEST ADDR = 177703
016456  012703  000377          R0234:  MOV     #377,R3         ;INITIAL DEST OP = 377
016462  000257                          CCC                     ;CLEAR FLAGS
016464  000273                          273                     ;MAKE N:C = 1011

016466  000303                  I0234:  SWAB    R3              ;TEST THE SWAB

016470  100403                          BMI     E10234
016472  001002                          BNE     E10234          ;N:C = 0100
016474  102401                          BVS     E10234
016476  103002                          BCC     A0234

016500  104000                  E10234: ERROR                   ;SWAB FAILED TO ALTER CODES PROPERLY
016502  016456                          R0234                   ;ERROR LOOP RETURN

016504  020403                  A0234:  CMP     R4,R3           ;CORRECT RESULT?
016506  001402                          BEQ     00234           ;BR IF YES

016510  104000                  E20234: ERROR                   ;SWAB DELIVERED WRONG RESULT
016512  016456                          R0234                   ;ERROR LOOP RETURN

016514  000004                   00234: SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0235 SWAB MODE 0 TEST WITH NEG. RESULT
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [134,135,360,001] FC 1,7,8

                                ;ACT BUTS:      37[004]100,134 / 27[135]000,001

                                ;EXEC:          [135]ALUC=HHLHL :[360] D = 000377

                                ;CODES:         [360] SPS=3   /   N:C = 1000

                                ;SYNC:          BOSJ2 (-) T = 1 USEC

                                ;KEY SIG:       K2-5 SBML1 (1) H   /   K2-5 SBML0 (1) L   /   K2-5 SBMH1 (1) H
                                                ;   /   K2-5 SBMH0 (1) L   /   K3-3 DM=0L   /   K3-5 SWAB H   /   K3-4 0

016516  012700  000235          T0235:  MOV     #0235,R0                ;LOAD R0 WITH TEST NO.
016522  013701  016546                  MOV     @#I0235,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD

016526  012704  000377                  MOV     #377,R4         ;RESULT S  /  B = 377
016532  012702  177703                  MOV     #177703,R2      ;DEST ADDR = 177703
016536  012703  177400          R0235:  MOV     #177400,R3      ;INITIAL DEST OP = 177400
016542  000257                          CCC                     ;CLEAR FLAGS
016544  000267                          267                     ;MAKE N:C = 0111

016546  000303                  I0235:  SWAB    R3              ;TEST THE SWAB

016550  100003                          BPL     E10235
016552  001402                          BEQ     E10235          ;DID SWAB MAKE N:C = 1000
016554  102401                          BVS     E10235
016556  103002                          BCC     A0235

016560  104000                  E10235: ERROR                   ;SWAB FAILED TO ALTER CODES PROPERLY
016562  016536                          R0235                   ;ERROR LOOP RETURN

016564  020403                  A0235:  CMP     R4,R3           ;DID SWAB DELIVER CORRECT RESULT?
016566  001402                          BEQ     00235           ;BR IF OK

016570  104000                  E20235: ERROR                   ;SWAB DELIVERED WRONG RESULT
016572  016536                          R0235                   ;ERROR LOOP RETURN

016574  000004                   00235: SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0236 SWAB MODE 1 AND 2 TEST WITH POS. RESULT
                                ; ***************************************************************

                                ;MICROPROGRAMMING   /   LOGIC INFORMATION

                                ;ROM SEW:(DM1)  [161,266,267,236,367,375,016] FC 1,3,9,8
                                ;       :(DM2)  [162,260,267,236,367,375,016] FC 1,3,9,8

                                ;ACT BUTS:(DM1) 37[004]100,161  /  33[266]220,236  /  16[367]016,016
                                ;        (DM2)  37[004]100,162  /  33[260]220,236  /  16[367]016,016

                                ;EXEC:          [236]ALUC=HHLHL :[367] D = 177400

                                ;CODES:         [367] SPS=3   /   N:C = 0100

                                ;SYNC:          B05J2 (-) T = 2 USEC

                                ;KEY SIG:       K2-5 SBML1 (1) H   /   K2-5 SBML0 (1) L   /   K2-5 SBMH1 (1) H   /   K2-
                                                ;   K3-3 DM=1L   /   K3-5 SWAB H

016576  012700  000236          T0236:  MOV     #0236,R0                ;LOAD R0 WITH TEST NO.
016602  013701  016626                  MOV     @#I10236,R1     ;LOAD R1 WITH TEST INSTRUCTION WORD

016606  012704  177400                  MOV     #177400,R4      ;RESULT S  /  B = 177400
016612  012702  067602                  MOV     #MBUF0,R2       ;R2 POINTS TO DEST OP
016616  012712  000377          R10236: MOV     #377,(R2)       ;SET UP DEST OP = 377
016622  000257                          CCC                     ;CLEAR FLAGS
016624  000273                          273                     ;MAKE N:C = 1011

016626  000312                  I10236: SWAB    (R2)            ;TEST THE SWAB - DM1

016630  100403                          BMI     E10236
016632  001002                          BNE     E10236          ;N:C = 0100
016634  102401                          BVS     E10236
016636  103002                          BCC     A0236

016640  104000                  E10236: ERROR                   ;SWAB FAILED TO ALTER CODES PROPERLY
016642  016616                          R10236                  ;ERROR LOOP RETURN

016644  020412                  A0236:  CMP     R4,(R2)         ;CORRECT RESULT?
016646  001402                          BEQ     R20236          ;BR IF OK

016650  104000                  E20236: ERROR                   ;SWAB DELIVERED WRONG RESULT
016652  016616                          R10236                  ;ERROR LOOP RETURN

016654  013701  016674          R20236: MOV     @#I20236,R1     ;LOAD R1 WITH TEST INSTR. WORD
016660  012702  067602                  MOV     #MBUF0,R2       ;R2 POINTS TO DEST OP
016664  012712  000377                  MOV     #377,(R2)       ;[DEST] = 000377
016670  000257                          CCC                     ;CLEAR FLAGS
016672  000273                          273                     ;MAKE N:C = 1011

016674  000322                  I20236: SWAB    (R2)+           ;TEST THE SWAB - DM2

016676  100403                          BMI     E30236          ;N:C = 0100
016700  001002                          BNE     E30236
```

```
016702  102401                          BVS     E30236
016704  103002                          BCC     B0236

016706  104000                  E30236: ERROR                   ;SWAB FAILED TO SET CODES PROPERLY
016710  016654                          R20236                  ;ERROR LOOP RETURN ADDRESS

016712  020437  067602          B0236:  CMP     R4,@#MBUF0      ;CORRECT RESULT ?
016716  001402                          BEQ     C0236           ;BR IF YES

016720  104000                  E40236: ERROR                   ;SWAB DELIVERED THE WRONG RESULT
016722  016654                          R20236                  ;ERROR LOOP RETURN ADDRESS

016724  020227  067604          C0236:  CMP     R2,#MBUF0+2     ;DID AUTO INCREMENT OCCUR ?
016730  001402                          BEQ     00236           ;BR IF YES

016732  104000                  E50236: ERROR                   ;SWAB FAILED TO AUTO INC REG.
016734  016654                          R20236                  ;ERROR LOOP RETURN ADDRESS

016736  000004                   00236: SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0237 SWAB MODE 1 TEST WITH NEG. RESULT
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [161,266,267,236,367,375,016] FC 1,3,9,8

                                ;ACT BUTS:      37[004]100,134 / 33[266]220,236 / 16[367]016,016

                                ;EXEC:          [236]ALUC=HHLHL :[367] D = 000377

                                ;CODES:         [367] SPS=3  /  N:C = 1000

                                ;SYNC:          B05J2 (-) T = 2 USEC

                                ;KEY SIG:       K2-5 SBML1 (1) H  /  K2-5 SBMLO (1) L  /  K2-5 SBMH2 (1) H  /  K2-5 SBMH
                                                ;  K3-3 DM=1L  /  K3-5 SWAB H

016740  012700  000237          T0237:  MOV     #0237,R0                ;LOAD R0 WITH TEST NO.
016744  013701  016770                  MOV     @#I0237,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD

016750  012704  000377                  MOV     #377,R4         ;RESULT S / B = 377
016754  012702  067602                  MOV     #MBUF0,R2       ;R2 POINTS TO DEST OP
016760  012712  177400          R0237:  MOV     #177400,(R2)    ;SET UP DEST. OP = 177400
016764  000257                          CCC                     ;CLEAR FLAGS
016766  000267                          267                     ;MAKE N:C = 0111

016770  000312                  I0237:  SWAB    (R2)            ;TEST THE SWAB

016772  100003                          BPL     E10237
016774  001402                          BEQ     E10237          ;N:C = 1000?
016776  102401                          BVS     E10237
017000  103002                          BCC     A0237

017002  104000                  E10237: ERROR                   ;SWAB FAILED TO ALTER CODES PROPERLY
017004  016760                          R0237                   ;ERROR LOOP RETURN

017006  020412                  A0237:  CMP     R4,(R2)         ;CORRECT RESULT?
017010  001402                          BEQ     00237           ;BR IF YES

017012  104000                  E20237: ERROR                   ;SWAB DELIVERED WRONG RESULT
017014  016760                          R0237                   ;ERROR LOOP RETURN

017016  000004                   00237: SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0240 NEG MODE 0 TEST : [DEST] = 0
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [105,372,360,001] FC 1,7,8

                                ;ACT BUTS:      37[004]100,105 / 31[105]360,360 / 27[372]000,001

                                ;EXEC:          [372]ALUC=LLHHL :[360] D = 000000

                                ;CODES:         [360] SPS=3  /  N:C = 0100

                                ;SYNC:          B05J2 (-) T = 1 USEC

                                ;KEY SIG:       K3-8 CINOO L  /  K3-3 DM=OL  /  K3-4 NEG L  /  K3-4 OVLAP INSTR H

017020  012700  000240          T0240:  MOV     #0240,R0                ;LOAD R0 WITH TEST NO.
017024  013701  017044                  MOV     @#I0240,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD

017030  012702  177703                  MOV     #177703,R2      ;DEST ADDR = 177703
017034  005004                          CLR     R4              ;RESULT S / B = 0
017036  005003                  R0240:  CLR     R3              ;INITIAL [DEST] = 0
017040  000257                          CCC                     ;CLEAR FLAGS
017042  000273                          273                     ;MAKE N:C = 1011

017044  005403                  I0240:  NEG     R3              ;TEST THE NEG

017046  100403                          BMI     E10240
017050  001002                          BNE     E10240          ;N:C = 0100 ONLY "Z" SET?
017052  102401                          BVS     E10240
017054  103002                          BCC     A0240

017056  104000                  E10240: ERROR                   ;NEG FAILED TO ALTER CODES PROPERLY
017060  017036                          R0240                   ;ERROR LOOP RETURN

017062  020304                  A0240:  CMP     R3,R4           ;WAS RESULT = 0
017064  001402                          BEQ     00240           ;BR IF YES

017066  104000                  E20240: ERROR                   ;NEG DELIVERED WRONG RESULT
017070  017036                          R0240                   ;ERROR LOOP RETURN

017072  000004                   00240: SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0241 NEG MODE 0 TEST : [DEST] > 0
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [105,372,360,001] FC 1,7,8

                                ;ACT BUTS:      37[004]100,105 / 31[105]360,360 / 27[372]000,001

                                ;EXEC:          [372]ALUC=LLHHL :[360] D = 177776

                                ;CODES:         [360] SPS=3  /  N:C = 1001

                                ;SYNC:          B05J2 (-) T = 1 USEC

                                ;KEY SIG:       K3-8 CINOO L  /  K3-3 DM=OL  /  K3-4 NEG L  /  K3-4 OVLAP INSTR H

017074  012700  000241          T0241:  MOV     #0241,R0                ;LOAD R0 WITH TEST NO.
017100  013701  017124                  MOV     @#I0241,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD

017104  012702  177703                  MOV     #177703,R2      ;DEST ADDR = 177703
017110  012704  177776                  MOV     #-2,R4          ;RESULT S / B = 177776
017114  012703  000002          R0241:  MOV     #2,R3           ;INITIAL [DEST] = 2
017120  000257                          CCC                     ;CLEAR FLAGS
017122  000266                          266                     ;MAKE N:C = 0110

017124  005403                  I0241:  NEG     R3              ;TEST THE NEG

017126  100003                          BPL     E10241
017130  001402                          BEQ     E10241          ;DID N:C = 1001?
017132  102401                          BVS     E10241
017134  103402                          BCS     A0241

017136  104000                  E10241: ERROR                   ;NEGATE FAILED TO ALTER CODES PROPERLY
017140  017114                          R0241                   ;ERROR LOOP RETURN

017142  020304                  A0241:  CMP     R3,R4           ;CORRECT RESULT?
017144  001402                          BEQ     00241           ;BR IF YES

017146  104000                  E20241: ERROR                   ;NEG DELIVERED WRONG RESULT
017150  017114                          R0241                   ;ERROR LOOP RETURN

017152  000004                   00241: SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***************************************************************
                                                .SBTTL T0242 NEG MODE 0 TEST : [DEST] < 0
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [105,372,360,001] FC 1,7,8

                                        ;ACT BUTS:      37[004]100,105 / 31[105]360,360 / 27[372]000,001

                                        ;EXEC:          [372]ALUC=LLHHL :[360] D = 000002

                                        ;CODES:         [360] SPS=3  /  N:C = 0001

                                        ;SYNC:          B05J2 (-) T = 1 USEC

                                        ;KEY SIG:       K3-8 CINOO L  /  K3-3 DM=OL  /  K3-4 NEG L  /  K3-4 OVLAP INSTR H

017154  012700  000242          T0242:  MOV     #0242,R0                ;LOAD R0 WITH TEST NO.
017160  013701  017204                  MOV     @#I0242,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD

017164  012702  177703                  MOV     #177703,R2      ;DEST ADDR = 177703
017170  012704  000002                  MOV     #2,R4           ;RESULT S / B = 2
017174  012703  177776          R0242:  MOV     #-2,R3          ;INITIAL [DEST] = 177776
017200  000257                          CCC                     ;CLEAR FLAGS
017202  000276                          276                     ;MAKE N:C = 1110

017204  005403                  I0242:  NEG     R3              ;TEST THE NEG

017206  100403                          BMI     E10242
017210  001402                          BEQ     E10242          ;N·C = 0001?
017212  102401                          BVS     E10242
017214  103402                          BCS     A0242

017216  104000                  E10242: ERROR                   ;NEG FAILED TO ALTER CODES PROPERLY
017220  017174                          R0242                   ;ERROR LOOP RETURN

017222  020304                  A0242:  CMP     R3,R4           ;RESULT = 2?
017224  001402                          BEQ     00242           ;BR IF YES

017226  104000                  E20242: ERROR                   ;NEG DELIVERED WRONG RESULT
017230  017174                          R0242                   ;ERROR LOOP RETURN

017232  000004                   00242: SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0243 NEG MODE 0 TEST : [DEST] = 100000 (8)
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [105,372,360,001] FC 1,7,8

                                ;ACT BUTS:      37[004]100,105 / 31[105]360,360 / 27[372]000,001

                                ;EXEC:          [372]ALUC=LLHHL :[360] D = 100000

                                ;CODES:         [360] SPS=3  /  N:C = 1011

                                ;SYNC:          B05J2 (-) T = 1 USEC

                                ;KEY SIG:       K3-8 CINOD L  /  K3-3 DM=DL  /  K3-4 NEG L  /  K3-4 OVLAP INSTR H

017234  012700  000243          T0243:  MOV     #0243,R0                ;LOAD R0 WITH TEST NO.
017240  013701  017262                  MOV     @#T0243,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD

017244  012702  177703                  MOV     #177703,R2      ;DEST ADDR = 177703
017250  012704  100000                  MOV     #100000,R4      ;RESULT S / B = 100000
017254  010403                  R0243:  MOV     R4,R3           ;INITIAL [DEST] = 100000
017256  000257                          CCC                     ;CLEAR FLAGS
017260  000264                          SEZ                     ;MAKE N:C = 01000

017262  005403                  T0243:  NEG     R3              ;TEST THE NEG

017264  100003                          BPL     E10243
017266  001402                          BEQ     E10243          ;N:C = 1011?
017270  102001                          BVC     E10243
017272  103402                          BCS     A0243

017274  104000                  E10243: ERROR                   ;NEG FAILED TO ALTER CODES PROPERLY
017276  017254                          R0243                   ;ERROR LOOP RETURN

017300  020304                  A0243:  CMP     R3,R4           ;RESULT STILL 100000?
017302  001402                          BEQ     00243           ;BR IF YES

017304  104000                  E20243: ERROR                   ;NEG DELIVERED WRONG RESULT
017306  017254                          R0243                   ;ERROR LOOP RETURN

017310  000004                   00243: SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***************************************************************
                                                .SBTTL T0244 NEG MODE 1 TEST : [DEST] = 0
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [161,266,267,221,367,375,016] FC 1,3,9,8

                                        ;ACT BUTS:      37[004]100,161 / 33[266]220,221 / 16[367]016,016

                                        ;EXEC:          [221]ALUC=LLHHL :[367] D = 000000

                                        ;CODES:         [367] SPS=3  /  N:C = 0100

                                        ;SYNC:          BOSJ2 (-) T = 2 USEC

                                        ;KEY SIG:       K3-8 CINOO L  /  K3-3 DM=1L  /  K3-4 NEG L

017312  012700  000244          T0244:  MOV     #0244,R0                ;LOAD R0 WITH TEST NO.
017316  013701  017336                  MOV     @#I0244,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD

017322  012702  067602                  MOV     #MBUF0,R2       ;R2 POINTS TO DEST OP
017326  005004                          CLR     R4              ;RESULT S / B = 0
017330  005012                  R0244:  CLR     (R2)            ;INITIAL [DEST] = 0
017332  000257                          CCC                     ;CLEAR FLAGS
017334  000273                          273                     ;MAKE N:C = 1011

017336  005412                  I0244:  NEG     (R2)            ;TEST THE NEG

017340  100403                          BMI     E10244
017342  001002                          BNE     E10244          ;N:C = 0100?
017344  102401                          BVS     E10244
017346  103002                          BCC     A0244

017350  104000                  E10244: ERROR                   ;NEG FAILED TO ALTER CODES PROPERLY
017352  017330                          R0244                   ;ERROR LOOP RETURN

017354  021204                  A0244:  CMP     (R2),R4         ;RESULT = 0?
017356  001402                          BEQ     00244           ;BR IF YES

017360  104000                  E20244: ERROR                   ;NEG DELIVERED WRONG RESULT
017362  017330                          R0244                   ;ERROR LOOP RETURN

017364  000004                   00244: SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***************************************************************
                                                .SBTTL T0245 NEG MODE 1  TEST : [DEST] > 0
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [161,266,267,221,367,375,016] FC 1,3,9,8

                                        ;ACT BUTS:      37[004]100,161 / 33[266]220,221 / 16[367]016,016

                                        ;EXEC:          [221]ALUC=LLH#L :[367] D = 177776

                                        ;CODES:         [367] SPS=3  /  N:C = 1001

                                        ;SYNC:          B05J2 (-)  T = 2 USEC

                                        ;KEY SIG:       K3-8 CINOO L  /  K3-3 DM=1L  /  K3-4 NEG L

017366  012700  000245          T0245:  MOV     #0245,R0                ;LOAD R0 WITH TEST NO.
017372  013701  017416                  MOV     @#I0245,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD

017376  012702  067602                  MOV     #MBUF0,R2       ;R2 POINTS TO DEST OP
017402  012704  177776                  MOV     #-2,R4          ;RESULT S / B = 177776
017406  012712  000002          R0245:  MOV     #2,(R2)         ;INITIAL [DEST] = 2
017412  000257                          CCC                     ;CLEAR FLAGS
017414  000266                          266                     ;MAKE N:C = 0110

017416  005412                  I0245:  NEG     (2)             ;TEST THE NEG

017420  100003                          BPL     E10245
017422  001402                          BEQ     E10245          ;N:C = 1001?
017424  102401                          BVS     E10245
017426  103402                          BCS     A0245

017430  104000                  E10245: ERROR                   ;NEG FAILED TO ALTER CODES PROPERLY
017432  017406                          R0245                   ;ERROR LOOP RETURN

017434  021204                  A0245:  CMP     (R2),R4         ;CORRECT RESULT?
017436  001402                          BEQ     00245           ;BR IF YES

017440  104000                  E20245: ERROR                   ;NEG DELIVERED WRONG RESULT
017442  017406                          R0245                   ;ERROR LOOP RETURN

017444  000004                   00245: SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0246 NEG MODE 1 TEST : [DEST] < 0
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOG.C INFORMATION

                                ;ROM SEQ:       [161,266,267,221,367,375,016] FC 1,3,9,8

                                ;ACT BUTS:      37[004]100,161 / 33[266]220,221 / 16[367]016,016

                                ;EXEC:          [221]ALUC=LLHHL :[367] D = 000002

                                ;CODES:         [367] SPS=3  /  N:C = 0001

                                ;SYNC:          BOSJ2 (-) T = 2 USEC

                                ;KEY SIG:       K3-8 CINOO L  /  K3-3 DM=1L  /  K3-4 NEG L

017446  012700  000246          T0246:  MOV     #0246,R0                ;LOAD R0 WITH TEST NO.
017452  013701  017476                  MOV     @#I0246,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD

017456  012702  067602                  MOV     #MBUF0,R2       ;R2 POINTS TO DEST OP
017462  012704  000002                  MOV     #2,R4           ;RESULT S / B = 2
017466  012712  177776          R0246:  MOV     #-2,(R2)        ;INITIAL [DEST] = 177776
017472  000257                          CCC                     ;CLEAR FLAGS
017474  000276                          276                     ;MAKE N:C = 1110

017476  005412                  I0246:  NEG     (R2)            ;TEST THE NEG

017500  100403                          BMI     E10246
017502  001402                          BEQ     E10246          ;N:C = 0001?
017504  102401                          BVS     E10246
017506  103402                          BCS     A0246

017510  104000                  E10246: ERROR                   ;NEG FAILED TO ALTER CODES PROPERLY
017512  017466                          R0246                   ;ERROR LOOP RETURN

017514  021204                  A0246:  CMP     (R2),R4         ;CORRECT RESULT = 2?
017516  001402                          BEQ     00246           ;BR IF YES

017520  104000                  E20246: ERROR                   ;NEG DELIVERED WRONG RESULT
017522  017466                          R0246                   ;ERROR LOOP RETURN

017524  000004                  00246:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***************************************************************
                                                .SBTTL TO247 NEG MODE 1 TEST: [DEST] = 100000 (8)
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [161,266,267,221,367,375,016] FC 1,3,9,8

                                        ;ACT BUTS:      37[004]100,161 / 33[266]220,221 / 16[367]016,016

                                        ;EXEC:          [221]ALUC=LLHHL :[367] D = 100000

                                        ;CODES:         [367] SPS=3  /  N:C = 1011

                                        ;SYNC:          BOSJ2 (-) T = 2 USEC

                                        ;KEY SIG:       K3-8 CINOO L  /  K3-3 DM=1L  /  K3-4 NEG L

017526  012700  000247                  TO247:  MOV     #0247,R0                ;LOAD R0 WITH TEST NO.
017532  013701  017554                          MOV     @#I0247,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD

017536  012702  067602                          MOV     #MBUF0,R2       ;R2 POINTS TO DEST OP
017542  012704  100000                          MOV     #100000,R4      ;RESULT S / B = 100000
017546  010412                          R0247:  MOV     R4,(R2)         ;INITIAL [DEST] = 100000
017550  000257                                  CCC                     ;CLEAR FLAGS
017552  000264                                  SEZ                     ;MAKE N:Z = 0100

017554  005412                          I0247:  NEG     (R2)            ;TEST THE NEG

017556  100003                                  BPL     E10247
017560  001402                                  BEQ     E10247          ;N:C = 1011?
017562  102001                                  BVC     E10247
017564  103402                                  BCS     A0247

017566  104000                          E10247: ERROR                   ;NEG FAILED TO ALTER CODES PROPERLY
017570  017546                                  R0247                   ;ERROR LOOP RETURN

017572  021204                          A0247:  CMP     (R2),R4         ;CORRECT RESULT = 100000?
017574  001402                                  BEQ     00247           ;BR IF YES

017576  104000                          E20247: ERROR                   ;NEG DELIVERED WRONG RESULT
017600  017546                                  R0247                   ;ERROR LOOP RETURN

017602  000004                           00247: SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***************************************************************
                                                .SBTTL T0250 ROR TEST - DMO - <N:C> = 1110
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [106,271,274,001] FC 1,9

                                        ;ACT BUTS:      37[004]100,106 / 27[271]000,001

                                        ;EXEC:          [106]ALUC=LLLLL :[271] D = 052525

                                        ;CODES:         [106] SPS=1, [274] SPS=2  /  N:C = 0000

                                        ;SYNC:          B05J2 (-) T = 1.25 USEC

                                        ;KEY SIG:       K2-5 SDM1 (1) H  /  K2-5 SDMO (1) H  /  K3-3 DM=DL  /  K3-4 OVLAP INSTR
                                                        ;  K3-8 ROT (R)L  /  K3-8 ROTSHF (R)H

017604  012700  000250          T0250:  MOV     #0250,R0                ;LOAD R0 WITH TEST NO.
017610  013701  017634                  MOV     @#I0250,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
017614  012702  177703                  MOV     #177703,R2      ;DEST ADDR = R3
017620  012704  052525                  MOV     #52525,R4       ;RESULT S / B = 52525
017624  012703  125252          R0250:  MOV     #125252,R3      ;[DEST] = 125252
017630  000257                          CCC                     ;CLEAR FLAGS
017632  000276                          276                     ;N:C = 1111

017634  006003                  I0250:  ROR     R3              ;TEST THE ROR

017636  100403                          BMI     E10250          ;N:C = 0000 ?
017640  001402                          BEQ     E10250
017642  102401                          BVS     E10250
017644  103002                          BCC     A0250

017646  104005                  E10250: ERROR5                  ;ROR FAILED TO ALTER CODES PROPERLY
017650  017624                          R0250                   ;ERROR LOOP RETURN ADDRESS

017652  020403                  A0250:  CMP     R4,R3           ;CORRECT RESULT ?
017654  001402                          BEQ     00250           ;BR IF YES

017656  104000                  E20250: ERROR                   ;ROR DELIVERED THE WRONG RESULT
017660  017624                          R0250                   ;ERROR LOOP RETURN

017662  000004                  00250:  SCOPE                   ;CALL THE SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0251 ROR TEST - DM0 - (N:C) = 1000
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [106,271,274,001] FC 1,9

                                ;ACT BUTS:      37[004]100,106 / 27[271]000,001

                                ;EXEC:          [106]ALUC=LLLLL :[271] D = 000000

                                ;CODES:         [106] SPS=1, [274] SPS=2  /  N:C = 0111

                                ;SYNC:          B05J2 (-) T = 1.25 USEC

                                ;KEY SIG:       K2-5 SDM1 (1) H  /  K2-5 SDM0 (1) H  /  K3-3 DM=DL  /  K3-8 ROT (R)H
                                                ;  K3-8 ROTSHF (R)H  /  K3-4 OVLAP INSTR H

017664  012700  000251          T0251:  MOV     #0251,R0                ;LOAD R0 WITH TEST NO.
017670  013701  017712                  MOV     @#I0251,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
017674  012702  177703                  MOV     #177703,R2      ;DEST ADDR = R3
017700  005004                          CLR     R4              ;RESULT S / B = 000000
017702  012703  000001          R0251:  MOV     #1,R3           ;[DEST] = 1
017706  000257                          CCC                     ;CLEAR FLAGS
017710  000270                          SEN                     ;N:C = 1000

017712  006003                  I0251:  ROR     R3              ;TEST THE ROR

017714  100403                          BMI     E10251          ;N:C = 0111 ?
017716  001002                          BNE     E10251
017720  102001                          BVC     E10251
017722  103402                          BCS     A0251

017724  104005                  E10251: ERROR5                  ;ROR FAILED TO ALTER CODES PROPERLY
017726  017702                          R0251                   ;ERROR LOOP RETURN ADDRESS

017730  020403                  A0251:  CMP     R4,R3           ;CORRECT RESULT ?
017732  001402                          BEQ     00251           ;BR IF YES

017734  104000                  E20251: ERROR                   ;ROR DELIVERED THE WRONG RESULT
017736  017702                          R0251                   ;ERROR LOOP RETURN

017740  000004                  00251:  SCOPE                   ;CALL THE SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0252 ROR TEST - DM0 - <N:C> = 0111
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [106,271,274,001] FC 1,9

                                ;ACT BUTS:      37[004]100,106 / 27[271]000,001

                                ;EXEC:          [106]ALUC=LLLLL :[271] D = 125252

                                ;CODES:         [106] SPS=1, [274] SPS=2  /  N:C = 1001

                                ;SYNC:          B05J2 (-) T = 1.25 USEC

                                ;KEY SIG:       K1-5 D(C)(1) H  /  K2-5 SDM1 (1) H  /  K2-5 SDM0 (1) H  /  K3-8 ROT (R)
                                                ;  /  K3-8 ROTSHF (R)H  /  K3-3 DM=0L  /  K3-4 OVLAP INSTR H

017742  012700  000252          T0252:  MOV     #0252,R0                ;LOAD R0 WITH TEST NO.
017746  013701  017772                  MOV     @#I0252,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
017752  012702  177703                  MOV     #177703,R2      ;DEST ADDR = R3
017756  012704  125252                  MOV     #125252,R4      ;RESULT S / B = 125252
017762  012703  052525          R0252:  MOV     #52525,R3       ;[DEST] = 052525
017766  000257                          CCC                     ;CLEAR FLAGS
017770  000267                          267                     ;N:C = 0111

017772  006003                  I0252:  ROR     R3              ;TEST THE ROR

017774  100003                          BPL     E10252          ;N:C = 1001 ?
017776  001402                          BEQ     E10252
020000  102401                          BVS     E10252
020002  103402                          BCS     A0252

020004  104005                  E10252: ERROR5                  ;ROR FAILED TO ALTER CODES PROPERLY
020006  017762                          R0252                   ;ERROR LOOP RETURN ADDRESS

020010  020403                  A0252:  CMP     R4,R3           ;CORRECT RESULT ?
020012  001402                          BEQ     00252           ;BR IF YES

020014  104000                  E20252: ERROR                   ;ROR DELIVERED THE WRONG RESULT
020016  017762                          R0252                   ;ERROR LOOP RETURN

020020  000004                  00252:  SCOPE                   ;CALL THE SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0253 ASR TEST - DM0 - <N:C> = 1000
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [106,271,274,001] FC 1,9

                                ;ACT BUTS:      37[004]100,106 / 27[271]000,001

                                ;EXEC:          [106]ALUC=LLLLL :[271] D = 000000

                                ;CODES:         [106] SPS=1, [274] SPS=2  /  N:C = 0111

                                ;SYNC:          B05J2 (-) T = 1.25 USEC

                                ;KEY SIG:       K2-5 SDM1 (1) H  /  K2-5 SDM0 (1) H  /  K3-3 DM=0L  /  K3-8 SHF (R)L
                                                ;  K3-8 ROTSHF (R)H  /  K3-4 OVLAP INSTR H

020022  012700  000253          T0253:  MOV     #0253,R0                ;LOAD R0 WITH TEST NO.
020026  013701  020050                  MOV     @#I0253,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
020032  012702  177703                  MOV     #177703,R2      ;DEST ADDR = R3
020036  005004                          CLR     R4              ;RESULT S / B = 000000
020040  012703  000001          R0253:  MOV     #1,R3           ;[DEST] = 1
020044  000257                          CCC                     ;CLEAR FLAGS
020046  000270                          SEN                     ;N:C = 1000

020050  006003                  I0253:  ROR     R3              ;TEST THE ROR

020052  100403                          BMI     E10253          ;N:C = 0111 ?
020054  001002                          BNE     E10253
020056  102001                          BVC     E10253
020060  103402                          BCS     A0253

020062  104005                  E10253: ERROR5                  ;ROR FAILED TO ALTER CODES PROPERLY
020064  020040                          R0253                   ;ERROR LOOP RETURN ADDRESS

020066  020403                  A0253:  CMP     R4,R3           ;CORRECT RESULT ?
020070  001402                          BEQ     00253           ;BR IF YES

020072  104000                  E20253: ERROR                   ;ROR DELIVERED THE WRONG RESULT
020074  020040                          R0253                   ;ERROR LOOP RETURN

020076  000004                  00253:  SCOPE                   ;CALL THE SCOPE LOOP UTILITY
```

```
                                        ; ***************************************************************
                                                .SBTTL T0254 ASR TEST - DMO - <N:C> = 0101
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [106,271,274,001] FC 1,9

                                        ;ACT BUTS:      37[004]100,106 / 27[271]000,001

                                        ;EXEC:          [106]ALUC=LLLLL :[271] D = 152525

                                        ;CODES:         [106] SPS=1, [274] SPS=2  /  N:C = 1010

                                        ;SYNC:          B05J2 (-) T = 1.25 USEC

                                        ;KEY SIG:       K2-5 SDM1 (1) H  /  K2-5 SDMO (1) H  /  K3-3 DM=OL  /  K1-5 D(C)(1)H
                                                        ;  /  K3-4 OVLAP INSTR H  /  K3-8 SHF (R)L  /  K3-8 ROTSHF (R) H

020100  012700  000254          T0254:  MOV     #0254,R0                ;LOAD R0 WITH TEST NO.
020104  013701  020130                  MOV     @#I0254,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
020110  012702  177703                  MOV     #177703,R2      ;DEST ADDR = R3
020114  012704  152525                  MOV     #152525,R4      ;RESULT S / B = 152525
020120  012703  125252          R0254:  MOV     #125252,R3      ;[DEST] = 125252
020124  000257                          CCC                     ;CLEAR FLAGS
020126  000265                          265                     ;N:C = 0101

020130  006003                  I0254:  ROR     R3              ;TEST THE ROR

020132  100003                          BPL     E10254          ;N:C = 1010 ?
020134  001402                          BEQ     E10254
020136  102001                          BVC     E10254
020140  103002                          BCC     A0254

020142  104005                  E10254: ERROR5                  ;ROR FAILED TO ALTER CODES PROPERLY
020144  020120                          R0254                   ;ERROR LOOP RETURN ADDRESS

020146  020403                  A0254:  CMP     R4,R3           ;CORRECT RESULT ?
020150  001402                          BEQ     00254           ;BR IF YES

020152  104000                  E20254: ERROR                   ;ROR DELIVERED THE WRONG RESULT
020154  020120                          R0254                   ;ERROR LOOP RETURN

020156  000004                  00254:  SCOPE                   ;CALL THE SCOPE LOOP UTILITY
```

```
                                ; ****************************************************************
                                        .SBTTL T0255 ASR TEST - DMO - <N:C> = 1100
                                ; ****************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [106,271,274,001] FC 1,9

                                ;ACT BUTS:      37[004]100,106 / 27[271]000,001

                                ;EXEC:          [106]ALUC=LLLLL :[271] D = 025252

                                ;CODES:         [106] SPS=1, [274] SPS=2  /  N:C = 0011

                                ;SYNC:          B05J2 (←) T = 1.25 USEC

                                ;KEY SIG:       K2-5 SDM1 (1) H  /  K2-5 SDMO (1) H  /  K3-3 DM=OL  /  K3-8 SHF (R)L
                                                ;  K3-8 ROTSHF (R)H  /  K3-4 OVLAP INSTR H

020160  012700  000255          T0255:  MOV     #0255,R0                ;LOAD R0 WITH TEST NO.
020164  013701  020210                  MOV     @#I0255,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
020170  012702  177703                  MOV     #177703,R2      ;DEST ADDR = R3
020174  012704  025252                  MOV     #25252,R4       ;RESULT S / B = 25252
020200  012703  052525          R0255:  MOV     #52525,R3       ;[DEST] = 52525
020204  000257                          CCC                     ;CLEAR FLAGS
020206  000274                          274                     ;N:C = 1100

020210  006003                  I0255:  ROR     R3              ;TEST THE ROR

020212  100403                          BMI     E10255          ;N:C = 0011 ?
020214  001402                          BEQ     E10255
020216  102001                          BVC     E10255
020220  103402                          BCS     A0255

020222  104005                  E10255: ERROR5                  ;ROR FAILED TO ALTER CODES PROPERLY
020224  020200                          R0255                   ;ERROR LOOP RETURN ADDRESS

020226  020403                  A0255:  CMP     R4,R3           ;CORRECT RESULT ?
020230  001402                          BEQ     00255           ;BR IF YES

020232  104000                  E20255: ERROR                   ;ROR DELIVERED THE WRONG RESULT
020234  020200                          R0255                   ;ERROR LOOP RETURN

020236  000004                  00255:  SCOPE                   ;CALL THE SCOPE LOOP UTILITY
```

```
                                ; ****************************************************************
                                        .SBTTL T0256 ROR TEST - DM1 - <N:C> = 1110
                                ; ****************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [161,266,267,232,275,277,376,016] FC 1,3,9

                                ;ACT BUTS:      37[004]100,161 / 33[266]220,232 / 16[277]016,016

                                ;EXEC:          [232]ALUC=HHLHL :[275] D = 052525

                                ;CODES:         [232] SPS=1, [277] SPS=2  /  N:C = 0000

                                ;SYNC:          B05J2 (-) T = 2 USEC

                                ;KEY SIG:       K3-3 DM=1L  /  K3-6 ROTSHF L  /  K3-8 ROT (R) L  /  K3-8 ROTSHF (R) L
                                                ;  K2-5 SDM1 (1) H  /  K2-5 SDM0 (1) L

020240  012700  000256          T0256:  MOV     #0256,R0                ;LOAD R0 WITH TEST NO.
020244  013701  020270                  MOV     @#I0256,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
020250  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
020254  012704  052525                  MOV     #52525,R4       ;RESULT S / B = 52525
020260  012712  125252          R0256:  MOV     #125252,(R2)    ;[DEST] = 125252
020264  000257                          CCC                     ;CLEAR FLAGS
020266  000276                          276                     ;N:C = 1110

020270  006012                  I0256:  ROR     (R2)            ;TEST THE ROR

020272  100403                          BMI     E10256          ;N:C = 0000 ?
020274  001402                          BEQ     E10256
020276  102401                          BVS     E10256
020300  103002                          BCC     A0256

020302  104005                  E10256: ERROR5                  ;ROR FAILED TO ALTER CODES PROPERLY
020304  020260                          R0256                   ;ERROR LOOP RETURN

020306  020412                  A0256:  CMP     R4,(R2)         ;CORRECT RESULT ?
020310  001403                          BEQ     00256           ;BR IF YES

020312  011203                          MOV     (R2),R3         ;GET THE WAS DATA
020314  104000                  E20256: ERROR                   ;ROR DELIVERED WRONG RESULT
020316  020260                          R0256                   ;ERROR LOOP RETURN ADDRESS

020320  000004                  00256:  SCOPE                   ;CALL THE SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0257 ROR TEST - DM1 - (N:C) = 1000
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [161,266,267,232,275,277,376,016] FC 1,3,9

                                ;ACT BUTS:      37[004]100,161 / 33[266]220,232 / 16[277]016,016

                                ;EXEC:          [232]ALUC=HHLHL :[275] D = 000000

                                ;CODES:         [232] SPS=1, [277] SPS=2  /  N:C = 0111

                                ;SYNC:          BOSJ2 (-) T = 2 USEC

                                ;KEY SIG:       K3-3 DM=1L  /  K3-6 ROTSHF L  /  K3-8 ROT (R) L  /  K3-8 ROTSHF (R) L
                                                ;  K2-5 SDM1 (1) H  /  K2-5 SDMO (1) L

020322  012700  000257          T0257:  MOV     #0257,R0                ;LOAD R0 WITH TEST NO.
020326  013701  020350                  MOV     @#I0257,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
020332  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
020336  005004                          CLR     R4              ;RESULT S / B = 000000
020340  012712  000001          R0257:  MOV     #1,(R2)         ;[DEST] = 1
020344  000257                          CCC                     ;CLEAR FLAGS
020346  000270                          SEN                     ;N:C = 1000

020350  006012                  I0257:  ROR     (R2)            ;TEST THE ROR

020352  100403                          BMI     E10257          ;N:C = 0111 ?
020354  001002                          BNE     E10257
020356  102001                          BVC     E10257
020360  103402                          BCS     A0257

020362  104005                  E10257: ERRORS                  ;ROR FAILED TO ALTER CODES PROPERLY
020364  020340                          R0257                   ;ERROR LOOP RETURN

020366  020412                  A0257:  CMP     R4,(R2)         ;CORRECT RESULT ?
020370  001403                          BEQ     00257           ;BR IF YES

020372  011203                          MOV     (R2),R3         ;GET THE WAS DATA
020374  104000                  E20257: ERROR                   ;ROR DELIVERED WRONG RESULT
020376  020340                          R0257                   ;ERROR LOOP RETURN ADDRESS

020400  000004                  00257:  SCOPE                   ;CALL THE SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0260 ROR TEST - DM1 - <N:C> = 0111
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [161,266,267,232,275,277,376,016] FC 1.3.9

                                ;ACT BUTS:      37[004]100,161 / 33[266]220,232 / 16[277]016,016

                                ;EXEC:          [232]ALUC=HHLHL :[275] D = 125252

                                ;CODES:         [232] SPS=1, [277] SPS=2  /  N:C = 1001

                                ;SYNC:          BOSJ2 (-) T = 2 USEC

                                ;KEY SIG:       K3-3 DM=1L  /  K3-6 ROTSHF L  /  K3-8 ROT (R) L  /  K3-8 ROTSHF (R) L
                                                ;  /  K2-5 SDM1 (1) H  /  K2-5 SDMO (1) L  /  K1-5 D(C)(1) H

020402  012700  000260          T0260:  MOV     #0260,R0                ;LOAD R0 WITH TEST NO.
020406  013701  020432                  MOV     @#I0260,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
020412  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
020416  012704  125252                  MOV     #125252,R4      ;RESULT S / B = 125252
020422  012712  052525          R0260:  MOV     #52525,(R2)     ;[DEST] = 52525
020426  000257                          CCC                     ;CLEAR FLAGS
020430  000267                          267                     ;N:C = 0111

020432  006012                  I0260:  ROR     (R2)            ;TEST THE ROR

020434  100003                          BPL     E10260          ;N:C = 1001 ?
020436  001402                          BEQ     E10260
020440  102401                          BVS     E10260
020442  103402                          BCS     A0260

020444  104005                  E10260: ERRORS                  ;ROR FAILED TO ALTER CODES PROPERLY
020446  020422                          R0260                   ;ERROR LOOP RETURN

020450  020412                  A0260:  CMP     R4,(R2)         ;CORRECT RESULT ?
020452  001403                          BEQ     00260           ;BR IF YES

020454  011203                          MOV     (R2),R3         ;GET THE WAS DATA
020456  104000                  E20260: ERROR                   ;ROR DELIVERED WRONG RESULT
020460  020422                          R0260                   ;ERROR LOOP RETURN ADDRESS

020462  000004                  00260:  SCOPE                   ;CALL THE SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0261 ASR TEST - DM1 - <N:C> = 1000
                                ; ***************************************************************

                                ;MICROPROGRAMMING   /   LOGIC INFORMATION

                                ;ROM SEQ:       [161,266,267,232,275,277,376,016] FC 1,3,9

                                ;ACT BUTS:      37[004]100,161  /  33[266]220,232  /  16[277]016,016

                                ;EXEC:          [232]ALUC=HHLHL :[275] D = 000000

                                ;CODES:         [232] SPS=1, [277] SPS=2   /   N:C = 0111

                                ;SYNC:          BOSJ2 (-) T = 2 USEC

                                ;KEY SIG:       K3-3 DM=1L   /   K3-6 ROTSHF L   /   K3-8 SHF (R) L   /   K3-8 ROTSHF (R
                                                ;   K2-5 SDM1 (1) H   /   K2-5 SDMO (1) L

020464  012700  000261          T0261:  MOV     #0261,R0                ;LOAD R0 WITH TEST NO.
020470  013701  020512                  MOV     @#I0261,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
020474  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
020500  005004                          CLR     R4              ;RESULT S  /  B = 000000
020502  012712  000001          R0261:  MOV     #1,(R2)         ;[DEST] = 1
020506  000257                          CCC                     ;CLEAR FLAGS
020510  000270                          SEN                     ;N:C = 1000

020512  006012                  I0261:  ROR     (R2)            ;TEST THE ROR

020514  100403                          BMI     E10261          ;N:C = 0111 ?
020516  001002                          BNE     E10261
020520  102001                          BVC     E10261
020522  103402                          BCS     A0261

020524  104005                  E10261: ERRORS                  ;ROR FAILED TO ALTER CODES PROPERLY
020526  020502                          R0261                   ;ERROR LOOP RETURN

020530  020412                  A0261:  CMP     R4,(R2)         ;CORRECT RESULT ?
020532  001403                          BEQ     00261           ;BR IF YES

020534  011203                          MOV     (R2),R3         ;GET THE WAS DATA
020536  104000                  E20261: ERROR                   ;ROR DELIVERED WRONG RESULT
020540  020502                          R0261                   ;ERROR LOOP RETURN ADDRESS

020542  000004                  00261:  SCOPE                   ;CALL THE SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0262 ASR TEST - DM1 - (N:C) = 1100
                                ; ***************************************************************

                                ;MICROPROGRAMMING   /   LOGIC INFORMATION

                                ;ROM SEQ:       [161,266,267,232,275,277,376,016] FC 1,3,9

                                ;ACT BUTS:      37[004]100,161  /  33[266]220,232  /  16[277]016,016

                                ;EXEC:          [232]ALUC=HHLHL :[275] D= 025252

                                ;CODES:         [232] SPS=1, [277] SPS=2   /   N:C = 0011

                                ;SYNC:          BOSJ2 (-) T = 2 USEC

                                ;KEY SIG:       K3-3 DM=1L   /   K3-6 ROTSHF L   /   K3-8 SHF (R) L   /   K3-8 ROTSHF (R
                                                ;   K2-5 SDM1(1) H   /   K2-5 SDM0 (1) L

020544  012700  000262          T0262:  MOV     #0262,R0                ;LOAD R0 WITH TEST NO.
020550  013701  020574                  MOV     @#T0262,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
020554  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
020560  012704  025252                  MOV     #25252,R4       ;RESULT S  /  B = 25252
020564  012712  052525          R0262:  MOV     #52525,(R2)     ;[DEST] = 52525
020570  000257                          CCC                     ;CLEAR FLAGS
020572  000274                          274                     ;N:C = 1100

020574  006012                  T0262:  ROR     (R2)            ;TEST THE ROR

020576  100403                          BMI     E10262          ;N:C = 0011 ?
020600  001402                          BEQ     E10262
020602  102001                          BVC     E10262
020604  103402                          BCS     A0262

020606  104005                  E10262: ERROR5                  ;ROR FAILED TO ALTER CODES PROPERLY
020610  020564                          R0262                   ;ERROR LOOP RETURN

020612  020412                  A0262:  CMP     R4,(R2)         ;CORRECT RESULT ?
020614  001403                          BEQ     00262           ;BR IF YES

020616  011203                          MOV     (R2),R3         ;GET THE WAS DATA
020620  104000                  E20262: ERROR                   ;ROR DELIVERED WRONG RESULT
020622  020564                          R0262                   ;ERROR LOOP RETURN ADDRESS

020624  000004                  00262:  SCOPE                   ;CALL THE SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0263 ASR TEST - DM1 - <N:C> = 0101
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [161,266,267,232,275,277,376,016] FC 1,3,9

                                ;ACT BUTS:      37[004]100,161 / 33[266]220,232 / 16[277]016,016

                                ;EXEC:          [232]ALUC=HHLHL :[275] D= 152525

                                ;CODES:         [232] SPS=1, [277] SPS=2  /  N:C = 1010

                                ;SYNC:          BOSJ2 (-) T = 2 USEC

                                ;KEY SIG:       K3-3 DM=1L  /  K3-6 ROTSHF L  /  K3-8 SHF (R) L  /  K3-8 ROTSHF (R) L
                                                ;  /  K2-5 SDM1 (1) H  /  K2-5 SDMO (1) L  /  K1-5 D(C)(1) H

020626  012700  000263          T0263:  MOV     #0263,R0                ;LOAD R0 WITH TEST NO.
020632  013701  020656                  MOV     @#I0263,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
020636  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
020642  012704  152525                  MOV     #152525,R4      ;RESULT S / B = 152525
020646  012712  125252          R0263:  MOV     #125252,(R2)    ;[DEST] = 125252
020652  000257                          CCC                     ;CLEAR FLAGS
020654  000265                          265                     ;N:C = 0101

020656  006012                  I0263:  ROR     (R2)            ;TEST THE ROR

020660  100003                          BPL     E10263          ;N:C = 1010 ?
020662  001402                          BEQ     E10263
020664  102001                          BVC     E10263
020666  103002                          BCC     A0263

020670  104005                  E10263: ERROR5                  ;ROR FAILED TO ALTER CODES PROPERLY
020672  020646                          R0263                   ;ERROR LOOP RETURN

020674  020412                  A0263:  CMP     R4,(R2)         ;CORRECT RESULT ?
020676  001403                          BEQ     00263           ;BR IF YES

020700  011203                          MOV     (R2),R3         ;GET THE WAS DATA
020702  104000                  E20263: ERROR                   ;ROR DELIVERED WRONG RESULT
020704  020646                          R0263                   ;ERROR LOOP RETURN ADDRESS

020706  000004                  00263:  SCOPE                   ;CALL THE SCOPE LOOP UTILITY
```

```
                                ; ***********************************************************************
                                        .SBTTL T0264 RORB TEST - DM2 - EVEN ADDRESS
                                ; ***********************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [162,260,267,233,276,277,376,016] FC 1,3,9

                                ;ACT BUTS:      37[004]100,162 / 33[260]220,233 / 16[277]016,016

                                ;EXEC:          [233] DMUX SHIFT RIGHT :[277] D = 077777

                                ;CODES:         [233] SPS=1, [277] SPS=2  /  N:C = 0000

                                ;SYNC:          BOSJ2 (-) T = 2.4 USEC

                                ;KEY SIG:       K3-6 BYTE INSTR H  /  K1-5 D(C)(1) H

020710  012700  000264          T0264:  MOV     #0264,R0                ;LOAD R0 WITH TEST NO.
020714  013701  020740                  MOV     @#I0264,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
020720  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
020724  012704  000177                  MOV     #177,R4         ;RESULT S / B = 177
020730  010203                  R0264:  MOV     R2,R3           ;R3 CONTAINS DEST ADDR
020732  012712  000377                  MOV     #377,(R2)       ;[DEST] = 377
020736  000257                          CCC                     ;SCOPE SYNC "C" = 0

020740  106023                  I0264:  RORB    (R3)+           ;TEST THE RORB

020742  103402                          BCS     A0264           ;BR IF ROR SET "C"

020744  104005                  E10264: ERROR5                  ;ROR FAILED TO SET "C"
020746  020730                          R0264                   ;ERROR LOOP RETURN ADDRESS

020750  022703  067603          A0264:  CMP     #MBUF0+1,R3     ;DID DEST REG GET INCREMENTED ?
020754  001402                          BEQ     B0264           ;BR IF YES

020756  104005                  E20264: ERROR5                  ;RORB FAILED TO UPDATE DEST REG
020760  020730                          R0264                   ;ERROR LOOP RETURN ADDRESS

020762  020412                  B0264:  CMP     R4,(R2)         ;CORRECT RESULT ?
020764  001403                          BEQ     00264           ;BR IF YES

020766  011203                          MOV     (R2),R3         ;GET THE WAS DATA
020770  104000                  E30264: ERROR                   ;RORB DELIVERED WRONG RESULT
020772  020730                          R0264                   ;ERROR LOOP RETURN ADDRESS

020774  000004                  00264:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***********************************************************************
                                        .SBTTL T0265 RORB TEST - DM1 - EVEN ADDRESS
                                ; ***********************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [161,266,267,233,276,277,376,016] FC 1,3,9

                                ;ACT BUTS:      37[004]100,161 / 33[266]220,233 / 16[277]016,016

                                ;EXEC:          [233] DMUX SHIFT RIGHT :[277] D = 077777

                                ;CODES:         [233] SPS=1, [277] SPS=  /  N:C = 1010

                                ;SYNC:          BOSJ2 (-) T = 2.4 USEC

                                ;KEY SIG:       K3-6 BYTE INSTR H  /  K1-5 D(C)(1) H

020776  012700  000265          T0265:  MOV     #0265,R0                ;LOAD R0 WITH TEST NO.
021002  013701  021030                  MOV     @#I0265,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
021006  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
021012  012704  000377                  MOV     #377,R4         ;RESULT S / B = 377
021016  010203                  R0265:  MOV     R2,R3           ;R3 CONTAINS DEST ADDR
021020  012712  000376                  MOV     #376,(R2)       ;[DEST] = 376
021024  000257                          CCC                     ;CLEAR FLAGS
021026  000261                          SEC                     ;SCOPE SYNC - SET "C"

021030  106013                  I0265:  RORB    (R3)            ;TEST THE RORB

021032  103002                          BCC     A0265           ;BR IF "C" CLR - IT SHOULD BE

021034  104005                  E10265: ERROR5                  ;RORB FAILED TO CLR "C"
021036  021016                          R0265                   ;ERROR LOOP RETURN ADDRESS

021040  020412                  A0265:  CMP     R4,(R2)         ;CORRECT RESULT ?
021042  001403                          BEQ     00265           ;BR IF YES

021044  011203                          MOV     (R2),R3         ;GET THE WAS DATA
021046  104000                  E20265: ERROR                   ;RORB DELIVERED WRONG RESULT
021050  021016                          R0265                   ;ERROR LOOP RETURN ADDRESS

021052  000004                  00265:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***********************************************************************
                                        .SBTTL T0266 RORB TEST - DM2 - ODD ADDRESS
                                ; ***********************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [162,260,267,237,270,233,276,277,376,016] FC 1,3,9

                                ;ACT BUTS:      37[004]100,162 / 33[260]220,237 / 34[237]220,233 / 16[277]016,016

                                ;EXEC:          [233] DMUX SHIFT RIGHT : [277] D = 77577

                                ;CODES:         [233] SPS=1, [277] SPS=3  /  N:C = 0011

                                ;SYNC:          B05J2 (-) T = 2.8 USEC

                                ;KEY SIG:       K3-6 BYTE INSTR H  /  K3-7 ODD BYTE H  /  K1-6 BADD(1) H

021054  012700  000266          T0266:  MOV     #0266,R0                ;LOAD R0 WITH TEST NO.
021060  013701  021110                  MOV     @#I0266,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
021064  012702  067603                  MOV     #MBUF0+1,R2     ;DEST ADDR = MBUF0+1
021070  012704  077777                  MOV     #77777,R4       ;RESULT S / B = 77777
021074  012705  067602                  MOV     #MBUF0,R5       ;POINT R5 TO CHECK RESULT
021100  010203                  R0266:  MOV     R2,R3           ;R3 CONTAINS DEST ADDR
021102  012715  177777                  MOV     #-1,(R5)        ;[DEST] = 177777
021106  000257                          CCC                     ;SCOPE SYNC - "C" =0

021110  106023                  I0266:  RORB    (R3)+           ;TEST THE RORB

021112  103402                          BCS     A0266           ;BR IF "C" IS SET - IT SHOULD BE

021114  104005                  E10266: ERROR5                  ;RORB FAILED TO SET "C"
021116  021100                          R0266                   ;ERROR LOOP RETURN ADDRESS

021120  022703  067604          A0266:  CMP     #MBUF0+2,R3     ;DID DEST REG GET INCREMENTED ?
021124  001402                          BEQ     B0266           ;BR IF YES

021126  104005                  E20266: ERROR5                  ;RORB FAILED TO UPDATE DEST REG
021130  021100                          R0266                   ;ERROR LOOP RETURN ADDRESS

021132  020415                  B0266:  CMP     R4,(R5)         ;CORRECT RESULT ?
021134  001403                          BEQ     00266           ;BR IF YES

021136  011503                          MOV     (R5),R3         ;GET THE WAS DATA
021140  104000                  E30266: ERROR                   ;RORB DELIVERED WRONG RESULT
021142  021100                          R0266                   ;ERROR LOOP RETURN ADDRESS

021144  000004                  00266:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***********************************************************************
                                        .SBTTL T0267 RORB TEST - DM1 - ODD ADDRESS
                                ; ***********************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [161,266,267,237,270,233,276,277,376,016] FC 1,3,9

                                ;ACT BUTS:      37[004]100,161 / 33[266]220,237 / 34[237]220,233 / 16[277]016,016

                                ;EXEC:           [233] DMUX SHIFT RIGHT :[277] D = 177777

                                ;CODES:         [233] SPS=1, [277] SPS=2  /  N:C - 1010

                                ;SYNC:          B05J2 (-) T = 2.8 USEC

                                ;KEY SIG:       K1-5 D(C)(1) H  /  K3-6 BYTE INSTR H  /  K3-7 ODD BYTE H  /  K1-6 BADD(1

021146  012700  000267          T0267:  MOV     #0267,R0                ;LOAD R0 WITH TEST NO.
021152  013701  021202                  MOV     @#I0267,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
021156  012702  067603                  MOV     #MBUF0+1,R2     ;DEST ADDR = MBUF0+1
021162  012704  177777                  MOV     #-1,R4          ;RESULT S / B = 177777
021166  012705  067602                  MOV     #MBUF0,R5       ;POINT R5 TO CHECK RESULT
021172  010203                  R0267:  MOV     R2,R3           ;R3 CONTAINS DEST ADDR
021174  012715  177377                  MOV     #177377,(R5)    ;[DEST] = 177377
021200  000261                          SEC                     ;SCOPE SYNC - SET "C"

021202  106023                  I0267:  RORB    (R3)+           ;TEST THE RORB

021204  103002                          BCC     A0267           ;BR IF "C" CLEAR - IT SHOULD BE

021206  104005                  E10267: ERROR5                  ;RORB FAILED TO CLEAR "C"
021210  021172                          R0267                   ;ERROR LOOP RETURN ADDRESS

021212  020415                  A0267:  CMP     R4,(R5)         ;CORRECT RESULT ?
021214  001403                          BEQ     00267           ;BR IF YES

021216  011503                          MOV     (R5),R3         ;GET THE WAS DATA
021220  104000                  E20267: ERROR                   ;RORB DELIVERED WRONG RESULT
021222  021172                          R0267                   ;ERROR LOOP RETURN ADDRESS

021224  000004                  00267:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***********************************************************************
                                        .SBTTL T0270 ASRB TEST - DM2 - ODD ADDRESS
                                ; ***********************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [162,260,267,237,270,233,276,277,376,016] FC 1,3,9

                                ;ACT BUTS:      37[004]100,162 / 33[260]220,237 / 34[237]220,233 / 16[277]016,016

                                ;EXEC:          [233] DMUX SHIFT RIGHT :[277] D = 000000

                                ;CODES:         [233] SPS=1, [277] SPS=2  /  N:C = 0111

                                ;SYNC:          B05J2 (-) T = 2.8 USEC

                                ;KEY SIG:       K3-6 BYTE INSTR H  /  K3-7 ODD BYTE H  /  K1-6 BA00(1) H

021226  012700  000270          T0270:  MOV     #0270,R0                ;LOAD R0 WITH TEST NO.
021232  013701  021262                  MOV     @#I0270,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
021236  012702  067603                  MOV     #MBUF0+1,R2     ;DEST ADDR = MBUF0+1
021242  012704  000377                  MOV     #377,R4         ;RESULT S / B = 377
021246  012705  067602                  MOV     #MBUF0,R5       ;POINT R5 TO CHECK RESULT
021252  010203                  R0270:  MOV     R2,R3           ;R3 CONTAINS DEST ADDR
021254  012715  000777                  MOV     #777,(R5)       ;[DEST] = 777
021260  000257                          CCC                     ;SCOPE SYNC "C" = 0

021262  106223                  I0270:  ASRB    (R3)+           ;TEST THE ASRB

021264  103402                          BCS     A0270           ;BR IF CARRY SET - IT SHOULD BE

021266  104005                  E10270: ERROR5                  ;ASRB FAILED TO SET THE CARRY
021270  021252                          R0270                   ;ERROR LOOP RETURN ADDRESS

021272  022703  067604          A0270:  CMP     #MBUF0+2,R3     ;DID DEST REG GET INCREMENTED ?
021276  001402                          BEQ     B0270           ;BR IF YES

021300  104005                  E20270: ERROR5                  ;ASRB FAILED TO UPDATE DEST REG
021302  021252                          R0270                   ;ERROR LOOP RETURN ADDRESS

021304  020415                  B0270:  CMP     R4,(R5)         ;CORRECT RESULT ?
021306  001403                          BEQ     00270           ;BR IF YES

021310  011503                          MOV     (R5),R3         ;GET THE WAS DATA
021312  104000                  E30270: ERROR                   ;ASRB DELIVERED WRONG RESULT
021314  021252                          R0270                   ;ERROR LOOP RETURN ADDRESS

021316  000004                  00270:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0271 ASRB TEST - DM1 - ODD ADDRESS
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [161,266,267,237,270,233,276,277,376,016] FC 1,3,9

                                ;ACT BUTS:      37[004]100,161 / 33[266]220,237 / 34[237]220,233 / 16[277]016,016

                                ;EXEC:          [233] DMUX SHIFT RIGHT :[277] D = 140300

                                ;CODES:         [233] SPS=1, [277] SPS=2  /  N:C = 1010

                                ;SYNC:          BOSJ2 (-) T = 2.8 USEC

                                ;KEY SIG:       K1-5 D(C)(1) H  /  K3-6 BYTE INSTR H  /  K3-7 ODD BYTE H  /  K1-6 BADD(1

021320  012700  000271          T0271:  MOV     #0271,R0                ;LOAD R0 WITH TEST NO.
021324  013701  021354                  MOV     @#I0271,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
021330  012702  067603                  MOV     #MBUF0+1,R2     ;DEST ADDR = MBUF0+1
021334  012704  140377                  MOV     #140377,R4      ;RESULT S / B = 140377
021340  012705  067602                  MOV     #MBUF0,R5       ;POINT R5 TO CHECK RESULT
021344  010203          R0271:  MOV     R2,R3           ;R3 CONTAINS DEST ADDR
021346  012715  100377                  MOV     #100377,(R5)    ;[DEST] = 100377
021352  000261                          SEC                     ;SCOPE SYNC - "C" = 1

021354  106213          I0271:  ASRB    (R3)            ;TEST THE ASRB

021356  103002                          BCC     A0271           ;BR IF CARRY CLEAR - IT SHOULD BE

021360  104005          E10271: ERROR5                  ;ASRB FAILED TO CLEAR THE CARRY
021362  021344                  R0271                   ;ERROR LOOP RETURN ADDRESS

021364  020415          A0271:  CMP     R4,(R5)         ;CORRECT RESULT ?
021366  001403                  BEQ     00271           ;BR IF YES

021370  011503                  MOV     (R5),R3         ;GET THE WAS DATA
021372  104000          E20271: ERROR                   ;ASRB DELIVERED WRONG RESULT
021374  021344                  R0271                   ;ERROR LOOP RETURN ADDRESS

021376  000004          00271:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0272 ASRB TEST - DM2 - EVEN ADDRESS
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [162,260,267,233,276,277,376,016] FC 1,3,9

                                ;ACT BUTS:      37[004]100,162 / 33[260]220,233 / 16[277]016,016

                                ;EXEC:          [233] DMUX SHIFT RIGHT :[277] D =

                                ;CODES:         [233] SPS=1, [277] SPS=2  /  N:C =

                                ;SYNC:          B05J2 (-) T = 2.8 USEC

                                ;KEY SIG:       K3-6 BYTE INSTR H  /  K3-3 DM=2L

021400  012700  000272          T0272:  MOV     #0272,R0                ;LOAD R0 WITH TEST NO.
021404  013701  021430                  MOV     @#I0272,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
021410  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
021414  012704  000077                  MOV     #77,R4          ;RESULT S / B = 77
021420  010203                  R0272:  MOV     R2,R3           ;R3 CONTAINS DEST ADDR
021422  012712  000177                  MOV     #177,(R2)       ;[DEST] = 177
021426  000257                          CCC                     ;SCOPE SYNC - "C" = 0

021430  106223                  I0272:  ASRB    (R3)+           ;TEST THE ASRB

021432  103402                          BCS     A0272           ;BR IF "C" = 1 - IT SHOULD BE

021434  104005                  E10272: ERROR5                  ;ASRB FAILED TO SET "C"
021436  021420                          R0272                   ;ERROR LOOP RETURN ADDRESS

021440  022703  067603          A0272:  CMP     #MBUF0+1,R3     ;DID DEST REG GET INCREMENTED ?
021444  001402                          BEQ     B0272           ;BR IF YES

021446  104005                  E20272: ERROR5                  ;ASRB FAILED TO UPDATE DEST REG
021450  021420                          R0272                   ;ERROR LOOP RETURN ADDRESS

021452  020412                  B0272:  CMP     R4,(R2)         ;CORRECT RESULT ?
021454  001403                          BEQ     00272           ;BR IF YES

021456  011203                          MOV     (R2),R3         ;GET THE WAS DATA
021460  104000                  E30272: ERROR                   ;ASRB DELIVERED WRONG RESULT
021462  021420                          R0272                   ;ERROR LOOP RETURN ADDRESS

021464  000004                  00272:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***********************************************************************
                                                .SBTTL T0273 ASRB TEST - DM1 - EVEN ADDRESS
                                        ; ***********************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [161,266,267,233,276,277,376,016] FC 1,3,9

                                        ;ACT BUTS:      37[004]100,161 / 33[266]220,233 / 16[277]016,016

                                        ;EXEC:          [233] DMUX SHIFT RIGHT :[277] D = 141703

                                        ;CODES:         [233] SPS=1, [277] SPS=2  /  N:C = 1010

                                        ;SYNC:          B05J2 (-) T = 2.4 USEC

                                        ;KEY SIG:       K1-5 D(C)(1) H  /  K3-6 BYTE INSTR H

021466  012700  000273                  T0273:  MOV     #0273,R0                ;LOAD R0 WITH TEST NO.
021472  013701  021516                          MOV     @#I0273,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
021476  012702  067602                          MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
021502  012704  000303                          MOV     #303,R4         ;RESULT S / B = 303
021506  010203                          R0273:  MOV     R2,R3           ;R3 CONTAINS DEST ADDR
021510  012712  000206                          MOV     #206,(R2)       ;[DEST] = 206
021514  000261                                  SEC                     ;SCOPE SYNC - "C" = 1

021516  106213                          I0273:  ASRB    (R3)            ;TEST THE CLRASRB

021520  103002                                  BCC     A0273           ;BR IF CARRY CLEAR - ITSHOULD BE

021522  104005                          E10273: ERROR5                  ;ASRB FAILED TO CLEAR THE CARRY
021524  021506                                  R0273                   ;ERROR LOOP RETURN ADDRESS

021526  020412                          A0273:  CMP     R4,(R2)         ;CORRECT RESULT ?
021530  001403                                  BEQ     00273           ;BR IF YES

021532  011203                                  MOV     (R2),R3         ;GET THE WAS DATA
021534  104000                          E20273: ERROR                   ;ASRB DELIVERED WRONG RESULT
021536  021506                                  R0273                   ;ERROR LOOP RETURN ADDRESS

021540  000004                          00273:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***********************************************************************
                                                .SBTTL T0274 TST DMO TEST - <N:C> = 1011
                                        ; ***********************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [104,373,362,001] FC 1,7,8

                                        ;ACT BUTS:      37[004]100,104 / 31[104]360,362 / 27[373]000,001

                                        ;EXEC:          [104]ALUC=LLLLL :[373] D = 000000

                                        ;CODES:         [373] SPS=1, [362] SPS=2  /  N:C = 0100

                                        ;SYNC:          B05J2 (-) T = 1 USEC

                                        ;KEY SIG:       K3-3 DM=OL  /  K1-7 D(15:00)=0 H  /  K3-4 TST L  /  K3-4 OVLAP INSTR H

021542  012700  000274          T0274:  MOV     #0274,R0                ;LOAD R0 WITH TEST NO.
021546  013701  021600                  MOV     @#T0274,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
021552  032737  000040  066642          BIT     #40,@#BPTLOC    ;BREAKPOINT HALT SET ??
021560  001401                          BEQ     .+4             ;BR IF NOT
021562  000000                          HALT                    ;BREAK - DEPRESS CONTINUE TO RESTART
021564  012702  177703                  MOV     #177703,R2      ;DEST ADDR = R3
021570  005004                          CLR     R4              ;RESULT S / B = 000000
021572  005003                  R0274:  CLR     R3              ;[DEST] = 000000
021574  000257                          CCC                     ;CLEAR CODES
021576  000273                          273                     ;N:C=1011

021600  005703                  T0274:  TST     R3              ;TEST THE TST

021602  100403                          BMI     E10274          ;N:C = 0100 ?
021604  001002                          BNE     E10274
021606  102401                          BVS     E10274
021610  103002                          BCC     A0274

021612  104005                  E10274: ERROR5                  ;TST FAILED TO ALTER CODES PROPERLY
021614  021572                          R0274                   ;ERROR LOOP RETURN

021616  020403                  A0274:  CMP     R4,R3           ;RESULT OK ?
021620  001402                          BEQ     00274           ;BR IF YES

021622  104000                  E20274: ERROR                   ;TST ALTERED THE [DEST]
021624  021572                          R0274                   ;ERROR LOOP RETURN

021626  000004                  00274:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***********************************************************************
                                        .SBTTL T0275 TST DMO TEST - <N:C> = 0100
                                ; ***********************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [104,373,362,001] FC 1,7,8

                                ;ACT BUTS:      37[004]100,104 / 31[104]360,362 / 27[373]000,001

                                ;EXEC:          [104]ALUC=LLLLL :[373] D = 177777

                                ;CODES:         [373] SPS=1, [362] SPS=3  /  N:C = 1000

                                ;SYNC:          BOSJ2 (-) T = 1 USEC

                                ;KEY SIG:       K3-3 DM=OL  /  K3-4 OVLAP INSTR H  /  K3-4 TST L

021630  012700  000275          T0275:  MOV     #0275,R0                ;LOAD R0 WITH TEST NO.
021634  013701  021656                  MOV     @#I0275,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
021640  012702  177703                  MOV     #177703,R2      ;DEST ADDR = R3
021644  005004                          CLR     R4
021646  005104                          COM     R4              ;RESULT S / B = 177777
021650  010403          R0275:  MOV     R4,R3           ;[DEST] = 177777
021652  000257                          CCC                     ;CLEAR CODES
021654  000264                          264                     ;N:C=0100

021656  005703          I0275:  TST     R3              ;TEST THE TST

021660  100003                          BPL     E10275          ;N:C = 1000 ?
021662  001402                          BEQ     E10275
021664  102401                          BVS     E10275
021666  103002                          BCC     A0275

021670  104005          E10275: ERRORS                  [illegible]     ALTER CODES PROPERLY
021672  021650                          R0275           [illegible]     JRN

021674  020403          A0275:  CMP     R4,R3           [illegible] ?
021676  001402                          BEQ     00275           ;BR [illegible]

021700  104000          E20275: ERROR                   ;TS[illegible] [illegible]HE [DEST]
021702  021650                          R0275           ;ERROR [illegible]OP RETURN

021704  000004          00275:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***********************************************************************
                                        .SBTTL T0276 CLR DMD TEST - (N:C) = 1011
                                ; ***********************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [104,373,360,001] FC 1,7,8

                                ;ACT BUTS:      37[004]100,104 / 31[104]360,360 / 27[373]000,001

                                ;EXEC:          [104]ALUC=HLLHH :[373] D = 000000

                                ;CODES:         [373] SPS=1, [360] SPS=3  /  N:C = 0100

                                ;SYNC:          BOSJ2 (-) T = 1 USEC

                                ;KEY SIG:       K3-3 DM=OL  /  K3-4 OVLAP INSTR H  /  K3-4 CLR L

021706  012700  000276          T0276:  MOV     #0276,R0                ;LOAD R0 WITH TEST NO.
021712  013701  021734                  MOV     @#I0276,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
021716  012702  177703                  MOV     #177703,R2      ;DEST ADDR = R3
021722  005004                          CLR     R4              ;RESULT S / B = 000000
021724  012703  177777          R0276:  MOV     #-1,R3          ;[DEST] = 177777
021730  000257                          CCC                     ;CLEAR CODES
021732  000273                          273                     ;N:C = 1011

021734  005003                  I0276:  CLR     R3              ;TEST THE CLR

021736  100403                          BMI     E10276          ;N:C = 0100 ?
021740  001002                          BNE     E10276
021742  102401                          BVS     E10276
021744  103002                          BCC     A0276

021746  104005                  E10276: ERROR5                  ;CLR FAILED TO ALTER THE CODES PROPERLY
021750  021724                          R0276                   ;ERROR LOOP RETURN
021752  020403                  A0276:  CMP     R4,R3           ;RESULT OK ?
021754  001402                          BEQ     00276           ;BR IF YES

021756  104000                  E20276: ERROR                   ;CLR DELIVERED THE WRONG RESULT
021760  021724                          R0276                   ;ERROR LOOP RETURN

021762  000004                  00276:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***********************************************************************
                                                .SBTTL T0277 CLR DMD TEST - <N:C> = 0000
                                        ; ***********************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [104,373,360,001] FC 1,7,8

                                        ;ACT BUTS:      37[004]100,104 / 31[104]360,360 / 27[373]000,001

                                        ;EXEC:          [104]ALUC=HLLHH :[373] D = 000000

                                        ;CODES:         [373] SPS=1, [360] SPS=3  /  N:C = 0100

                                        ;SYNC:          B05J2 (-) T = 1 USEC

                                        ;KEY SIG:       K3-3 DM=OL  /  K3-4 OVLAP INSTR H  /  K3-4 CLR L

021764  012700  000277                  T0277:  MOV     #0277,R0                ;LOAD R0 WITH TEST NO.
021770  013701  022010                          MOV     @#I0277,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
021774  012702  177703                          MOV     #177703,R2      ;DEST ADDR = R3
022000  005004                                  CLR     R4              ;RESULT S / B = 000000
022002  012703  177777                  R0277:  MOV     #-1,R3          ;[DEST] = 177777
022006  000257                                  CCC                     ;CLEAR CODES

022010  005003                          I0277:  CLR     R3              ;TEST THE CLR

022012  100403                                  BMI     E10277          ;N:C = 0100 ?
022014  001002                                  BNE     E10277
022016  102401                                  BVS     E10277
022020  103002                                  BCC     A0277

022022  104005                          E10277: ERROR5                  ;CLR FAILED TO ALTER THE CODES PROPERLY
022024  022002                                  R0277                   ;ERROR LOOP RETURN
022026  020403                          A0277:  CMP     R4,R3           ;RESULT OK ?
022030  001402                                  BEQ     O0277           ;BR IF YES

022032  104000                          E20277: ERROR                   ;CLR DELIVERED THE WRONG RESULT
022034  022002                                  R0277                   ;ERROR LOOP RETURN

022036  000004                          O0277:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***********************************************************************
                                        .SBTTL T0300 COM DMD TEST - <N:C> = 0110
                                ; ***********************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [104,373,360,001] FC 1,7,8

                                ;ACT BUTS:      37[004]100,104 / 31[104]360,360 / 27[373]000,001

                                ;EXEC:          [104]ALUC=HLLLL :[373] D = 125252

                                ;CODES:         [373] SPS=1, [360] SPS=3  /  N:C = 1001

                                ;SYNC:          B05J2 (-) T = 1 USEC

                                ;KEY SIG:       K3-3 DM=OL  /  K3-4 OVLAP INSTR H  /  K3-4 COM L

022040  012700  000300          T0300:  MOV     #0300,R0                ;LOAD R0 WITH TEST NO.
022044  013701  022070                  MOV     @#I0300,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
022050  012702  177703                  MOV     #177703,R2      ;DEST ADDR = R3
022054  012704  125252                  MOV     #125252,R4      ;RESULT S / B = 125252
022060  012703  052525          R0300:  MOV     #52525,R3       ;[DEST] = 52525
022064  000257                          CCC                     ;CLEAR CODES
022066  000266                          266                     ;N:C = 0110

022070  005103                  I0300:  COM     R3              ;TEST THE COM

022072  100003                          BPL     E10300          ;N:C = 1001 ?
022074  001402                          BEQ     E10300
022076  102401                          BVS     E10300
022100  103402                          BCS     A0300

022102  104005                  E10300: ERROR5                  ;COM FAILED TO ALTER THE CODES PROPERLY
022104  022060                          R0300                   ;ERROR LOOP RETURN
022106  020403                  A0300:  CMP     R4,R3           ;RESULT OK ?
022110  001402                          BEQ     00300           ;BR IF YES

022112  104000                  E20300: ERROR                   ;COM DELIVERED THE WRONG RESULT
022114  022060                          R0300                   ;ERROR LOOP RETURN

022116  000004                  00300:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***********************************************************************
                                        .SBTTL T0301 COM DMO TEST - <N:C> = 1001
                                ; ***********************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [104,373,360,001] FC 1,7,8

                                ;ACT BUTS:      37[004]100,104 / 31[104]360,360 / 27[373]000,001

                                ;EXEC:          [104]ALUC=HLLLL :[373] D = 000000

                                ;CODES:         [373] SPS=1, [360] SPS=3  /  N:C =0101

                                ;SYNC:          B05J2 (-) T = 1 USEC

                                ;KEY SIG:       K3-3 DM=OL  /  K3-4 OVLAP INSTR H  /  K3-4 COM L

022120  012700  000301          T0301:  MOV     #0301,R0                ;LOAD R0 WITH TEST NO.
022124  013701  022146                  MOV     @#I0301,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
022130  012702  177703                  MOV     #177703,R2      ;DEST ADDR = R3
022134  005004                          CLR     R4              ;RESULT S / B = 000000
022136  012703  177777          R0301:  MOV     #-1,R3          ;[DEST] = 177777
022142  000257                          CCC                     ;CLEAR CODES
022144  000271                          271                     ;N:C = 1001

022146  005103                  I0301:  COM     R3              ;TEST THE COM

022150  100403                          BMI     E10301          ;N:C = 0101 ?
022152  001002                          BNE     E10301
022154  102401                          BVS     E10301
022156  103402                          BCS     A0301

022160  104005                  E10301: ERRORS                  ;COM FAILED TO ALTER THE CODES PROPERLY
022162  022136                          R0301                   ;ERROR LOOP RETURN
022164  020403                  A0301:  CMP     R4,R3           ;RESULT OK ?
022166  001402                          BEQ     00301           ;BR IF YES

022170  104000                  E20301: ERROR                   ;COM DELIVERED THE WRONG RESULT
022172  022136                          R0301                   ;ERROR LOOP RETURN

022174  000004                  00301:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***********************************************************************
                                        .SBTTL T0302 INC DMO TEST - <N:C> = 1011
                                ; ***********************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [104,373,360,001] FC 1,7,8

                                ;ACT BUTS:      37[004]100,104 / 31[104]360,360 / 27[373]000,001

                                ;EXEC:          [104]ALUC=LLLLL :[373] D = 000000

                                ;CODES:         [373] SPS=1, [360] SPS=3  /  N:C = 0101

                                ;SYNC:          B05J2 (-) T = 1 USEC

                                ;KEY SIG:       K3-8 CINOO L  /  K3-3 DM=OL  /  K3-4 OVLAP INSTR H  /  K3-4 INC L

022176  012700  000302          T0302:  MOV     #0302,R0                ;LOAD R0 WITH TEST NO.
022202  013701  022224                  MOV     @#I0302,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
022206  012702  177703                  MOV     #177703,R2      ;DEST WDR = R3
022212  005004                          CLR     R4              ;RESULT S / B = 000000
022214  012703  177777          R0302:  MOV     #-1,R3          ;[DEST] = 177777
022220  000257                          CCC                     ;CLEAR CODES
022222  000273                          273                     ;N:C = 1011

022224  005203                  I0302:  INC     R3              ;TEST THE INC

022226  100403                          BMI     E10302          ;N:C = 0101 ?
022230  001002                          BNE     E10302
022232  102401                          BVS     E10302
022234  103402                          BCS     A0302

022236  104005                  E10302: ERROR5                  ;INC FAILED TO ALTER THE CODES PROPERLY
022240  022214                          R0302                   ;ERROR LOOP RETURN
022242  020403                  A0302:  CMP     R4,R3           ;RESULT OK ?
022244  001402                          BEQ     00302           ;BR IF YES

022246  104000                  E20302: ERROR                   ;INC DELIVERED THE WRONG RESULT
022250  022214                          R0302                   ;ERROR LOOP RETURN

022252  000004                  00302:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***********************************************************************
                                        .SBTTL T0303 INC DMO TEST - <N:C> = 0100
                                ; ***********************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [104,373,360,001] FC 1,7,8

                                ;ACT BUTS:      37[004]100,104 / 31[104]360,360 / 27[373]000,001

                                ;EXEC:          [104]ALUC=LLLLL :[373] D = 100000

                                ;CODES:         [373] SPS=1, [360] SPS=3  /  N:C = 1010

                                ;SYNC:          B05J2 (-) T = 1 USEC

                                ;KEY SIG:       K3-8 CINOO L  /  K3-3 DM=OL  /  K3-4 INC L  /  K3-4 OVLAP INSTR H

022254  012700  000303          T0303:  MOV     #0303,R0                ;LOAD R0 WITH TEST NO.
022260  013701  022304                  MOV     @#I0303,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
022264  012702  177703                  MOV     #177703,R2      ;DEST ADDR = R3
022270  012704  100000                  MOV     #100000,R4      ;RESULT S / B = 100000
022274  012703  077777          R0303:  MOV     #77777,R3       ;[DEST] = 77777
022300  000257                          CCC                     ;CLEAR CODES
022302  000264                          264                     ;N:C = 0100

022304  005203                  I0303:  INC     R3              ;TEST THE INC

022306  100003                          BPL     E10303          ;N:C = 1010 ?
022310  001402                          BEQ     E10303
022312  102001                          BVC     E10303
022314  103002                          BCC     A0303

022316  104005                  E10303: ERROR5                  ;INC FAILED TO ALTER THE CODES PROPERLY
022320  022274                          R0303                   ;ERROR LOOP RETURN
022322  020403                  A0303:  CMP     R4,R3           ;RESULT OK ?
022324  001402                          BEQ     00303           ;BR IF YES

022326  104000                  E20303: ERROR                   ;INC DELIVERED THE WRONG RESULT
022330  022274                          R0303                   ;ERROR LOOP RETURN

022332  000004                  00303:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***********************************************************************
                                        .SBTTL T0304 DEC DMO TEST - <N:C> = 1011
                                ; ***********************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [104,373,360,001] FC 1,7,8

                                ;ACT BUTS:      37[004]100,104 / 31[104]360,360 / 27[373]000,001

                                ;EXEC:          [104]ALUC=LHHHH :[373] D = 000000

                                ;CODES:         [373] SPS=1, [360] SPS=3  /  N:C = 0101

                                ;SYNC:          B05J2 (-) T = 1 USEC

                                ;KEY SIG:       K3-3 DM=OL  /  K3-4 OVLAP INSTR H  /  K3-4 DEC L

022334  012700  000304          T0304:  MOV     #0304,R0                ;LOAD R0 WITH TEST NO.
022340  013701  022362                  MOV     @#I0304,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
022344  012702  177703                  MOV     #177703,R2      ;DEST ADDR = R3
022350  005004                          CLR     R4              ;RESULT S / B = 000000
022352  012703  000001          R0304:  MOV     #1,R3           ;[DEST] = 1
022356  000257                          CCC                     ;CLEAR CODES
022360  000273                          273                     ;N:C = 1011

022362  005303                  I0304:  DEC     R3              ;TEST THE DEC

022364  100403                          BMI     E10304          ;N:C = 0101 ?
022366  001002                          BNE     E10304
022370  102401                          BVS     E10304
022372  103402                          BCS     A0304

022374  104005                  E10304: ERROR5                  ;DEC FAILED TO ALTER THE CODES PROPERLY
022376  022352                          R0304                   ;ERROR LOOP RETURN
022400  020403                  A0304:  CMP     R4,R3           ;RESULT OK ?
022402  001402                          BEQ     00304           ;BR IF YES

022404  104000                  E20304: ERROR                   ;DEC DELIVERED THE WRONG RESULT
022406  022352                          R0304                   ;ERROR LOOP RETURN

022410  000004                  00304:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***********************************************************************
                                        .SBTTL T0305 DEC DMO TEST - <N:C> = 1100
                                ; ***********************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [104,373,360,001] FC 1,7,8

                                ;ACT BUTS:      37[004]100,104 / 31[104]360,360 / 27[373]000,001

                                ;EXEC:          [104]ALUC=LHHHH :[373] D = 77777

                                ;CODES:         [373] SPS=1, [360] SPS=3  /  N:C = 0010

                                ;SYNC:          B05J2 (-) T = 1 USEC

                                ;KEY SIG:       K3-3 DM=OL  /  K3-4 OVLAP INSTR H  /  K3-4 DEC L

022412  012700  000305          T0305:  MOV     #0305,R0                ;LOAD R0 WITH TEST NO.
022416  013701  022442                  MOV     @#I0305,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
022422  012702  177703                  MOV     #177703,R2      ;DEST ADDR = R3
022426  012704  077777                  MOV     #77777,R4       ;RESULT S / B = 77777
022432  012703  100000          R0305:  MOV     #100000,R3      ;[DEST] = 100000
022436  000257                          CCC                     ;CLEAR CODES
022440  000274                          274                     ;N:C = 1100

022442  005303                  I0305:  DEC     R3              ;TEST THE DEC

022444  100403                          BMI     E10305          ;N:C = 0010 ?
022446  001402                          BEQ     E10305
022450  102001                          BVC     E10305
022452  103002                          BCC     A0305

022454  104005                  E10305: ERROR5                  ;DEC FAILED TO ALTER THE CODES PROPERLY
022456  022432                          R0305                   ;ERROR LOOP RETURN
022460  020403                  A0305:  CMP     R4,R3           ;RESULT OK ?
022462  001402                          BEQ     00305           ;BR IF YES

022464  104000                  E20305: ERROR                   ;DEC DELIVERED THE WRONG RESULT
022466  022432                          R0305                   ;ERROR LOOP RETURN

022470  000004                  00305:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***********************************************************************
                                        .SBTTL T0306 DEC DMO TEST - (N:C) = 0000
                                ; ***********************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [104,373,360,001] FC 1,7,8

                                ;ACT BUTS:      37[004]100,104 / 31[104]360,360 / 27[373]000,001

                                ;EXEC:          [104]ALUC=LHHHH :[373] D = 177777

                                ;CODES:         [373] SPS=1, [360] SPS=3  /  N:C = 1000

                                ;SYNC:          B05J2 (-) T = 1 USEC

                                ;KEY SIG:       K3-3 DM=OL  /  K3-4 OVLAP INSTR H  /  K3-4 DEC L

022472  012700  000306          T0306:  MOV     #0306,R0                ;LOAD R0 WITH TEST NO.
022476  013701  022516                  MOV     @#I0306,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
022502  012702  177703                  MOV     #177703,R2      ;DEST ADDR = R3
022506  012704  177777                  MOV     #-1,R4          ;RESULT S / B = 177777
022512  005003                  R0306:  CLR     R3              ;[DEST] = 000000
022514  000257                          CCC                     ;CLEAR CODES

022516  005303                  I0306:  DEC     R3              ;TEST THE DEC

022520  100003                          BPL     E10306          ;N:C = 1000 ?
022522  001402                          BEQ     E10306
022524  102401                          BVS     E10306
022526  103002                          BCC     A0306

022530  104005                  E10306: ERROR5                  ;DEC FAILED TO ALTER THE CODES PROPERLY
022532  022512                          R0306                   ;ERROR LOOP RETURN
022534  020403                  A0306:  CMP     R4,R3           ;RESULT OK ?
022536  001402                          BEQ     00306           ;BR IF YES

022540  104000                  E20306: ERROR                   ;DEC DELIVERED THE WRONG RESULT
022542  022512                          R0306                   ;ERROR LOOP RETURN

022544  000004                  00306:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***********************************************************************
                                        .SBTTL T0307 ASL DMO TEST - <N:C> = 1000
                                ; ***********************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [104,373,360,001] FC 1,7,8

                                ;ACT BUTS:      37[004]100,104 / 31[104]360,360 / 27[373]000,001

                                ;EXEC:          [104]ALUC=LHHLL :[373] D = 000000

                                ;CODES:         [373] SPS=1, [360] SPS=3  /  N:C = 0111

                                ;SYNC:          B05J2 (-) T = 1 USEC

                                ;KEY SIG:       K3-3 DM=OL  /  K3-4 OVLAP INSTR H  /  K3-6 ROTSHF (L) L  /  K3-5 ROTSHF

022546  012700  000307          T0307:  MOV     #0307,R0                ;LOAD R0 WITH TEST NO.
022552  013701  022574                  MOV     @#I0307,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
022556  012702  177703                  MOV     #177703,R2      ;DEST ADDR = R3
022562  005004                          CLR     R4              ;RESULT S / B = 000000
022564  012703  100000          R0307:  MOV     #100000,R3      ;[DEST] = 100000
022570  000257                          CCC                     ;CLEAR CODES
022572  000270                          SEN                     ;N:C = 1000

022574  006303                  I0307:  ASL     R3              ;TEST THE ASL

022576  100403                          BMI     E10307          ;N:C = 0111 ?
022600  001002                          BNE     E10307
022602  102001                          BVC     E10307
022604  103402                          BCS     A0307

022606  104005                  E10307: ERRORS                  ;ASL FAILED TO ALTER THE CODES PROPERLY
022610  022564                          R0307                   ;ERROR LOOP RETURN
022612  020403                  A0307:  CMP     R4,R3           ;RESULT OK ?
022614  001402                          BEQ     00307           ;BR IF YES

022616  104000                  E20307: ERROR                   ;ASL DELIVERED THE WRONG RESULT
022620  022564                          R0307                   ;ERROR LOOP RETURN

022622  000004                  00307:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***********************************************************************
                                        .SBTTL T0310 ASL DMO TEST - <N:C> = 0101
                                ; ***********************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [104,373,360,001] FC 1,7,8

                                ;ACT BUTS:      37[004]100,104 / 31[104]360,360 / 27[373]000,001

                                ;EXEC:          [104]ALUC=LHHLL :[373] D = 100000

                                ;CODES:         [373] SPS=1, [360] SPS=3  /  N:C = 1010

                                ;SYNC:          B05J2 (-) T = 1 USEC

                                ;KEY SIG:       K3-3 DM=OL  /  K3-4 OVLAP INSTR H  /  K3-6 ROTSHF (L) L  /  K3-5 ROTSHF

022624  012700  000310          T0310:  MOV     #0310,R0                ;LOAD R0 WITH TEST NO.
022630  013701  022654                  MOV     @#I0310,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
022634  012702  177703                  MOV     #177703,R2      ;DEST ADDR = R3
022640  012704  100000                  MOV     #100000,R4      ;RESULT S / B = 100000
022644  012703  040000          R0310:  MOV     #40000,R3       ;[DEST] = 40000
022650  000257                          CCC                     ;CLEAR CODES
022652  000265                          265                     ;N:C = 0101

022654  006303                  I0310:  ASL     R3              ;TEST THE ASL

022656  100003                          BPL     E10310          ;N:C = 1010 ?
022660  001402                          BEQ     E10310
022662  102001                          BVC     E10310
022664  103002                          BCC     A0310

022666  104005                  E10310: ERROR5                  ;ASL FAILED TO ALTER THE CODES PROPERLY
022670  022644                          R0310                   ;ERROR LOOP RETURN
022672  020403                  A0310:  CMP     R4,R3           ;RESULT OK ?
022674  001402                          BEQ     00310           ;BR IF YES

022676  104000                  E20310: ERROR                   ;ASL DELIVERED THE WRONG RESULT
022700  022644                          R0310                   ;ERROR LOOP RETURN

022702  000004                  00310:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***********************************************************************
                                                .SBTTL T0311 ASL DMO TEST - (N:C) = 0010
                                        ; ***********************************************************************

                                        ;MICROPROGRAMMING   /   LOGIC INFORMATION

                                        ;ROM SEQ:       [104,373,360,001] FC 1,7,8

                                        ;ACT BUTS:      37[004]100,104  /  31[104]360,360  /  27[373]000,001

                                        ;EXEC:          [104]ALUC=LHHLL :[373] D = 000000

                                        ;CODES:         [373] SPS=1, [360] SPS=3   /   N:C = 0100

                                        ;SYNC:          BOSJ2 (-) T = 1 USEC

                                        ;KEY SIG:       K3-3 DM=OL   /   K3-4 OVLAP INSTR H   /   K3-6 ROTSHF (L) L   /   K3-5 R

 022704  012700  000311                 T0311:  MOV     #0311,R0                ;LOAD R0 WITH TEST NO.
 022710  013701  022730                         MOV     @#I0311,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
 022714  012702  177703                         MOV     #177703,R2      ;DEST ADDR = R3
 022720  005004                                 CLR     R4              ;RESULT S  /  B = 000000
 022722  005003                         R0311:  CLR     R3              ;[DEST] = 000000
 022724  000257                                 CCC                     ;CLEAR CODES
 022726  000262                                 SEV                     ;N:C = 0010

 022730  006303                         I0311:  ASL     R3              ;TEST THE ASL

 022732  100403                                 BMI     E10311          ;N:C = 0100 ?
 022734  001002                                 BNE     E10311
 022736  102401                                 BVS     E10311
 022740  103002                                 BCC     A0311

 022742  104005                         E10311: ERRORS                  ;ASL FAILED TO ALTER THE CODES PROPERLY
 022744  022722                                 R0311                   ;ERROR LOOP RETURN
 022746  020403                         A0311:  CMP     R4,R3           ;RESULT OK ?
 022750  001432                                 BEQ     00311           ;BR IF YES

 022752  104000                         E20311: ERROR                   ;ASL DELIVERED THE WRONG RESULT
 022754  022722                                 R0311                   ;ERROR LOOP RETURN

 022756  000004                         00311:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***********************************************************************
                                        .SBTTL T0312 ROL DMO TEST - <N:C> = 1101
                                ; ***********************************************************************

                                ;MICROPROGRAMMING   /   LOGIC INFORMATION

                                ;ROM SEQ:       [104,373,360,001] FC 1,7,8

                                ;ACT BUTS:      37[004]100,104  /  31[104]360,360  /  27[373]000,001

                                ;EXEC:          [104]ALUC=LHMLL :[373] D = 052525

                                ;CODES:         [373] SPS=1, [360] SPS=3   /   N:C = 0011

                                ;SYNC:          B05J2 (-) T = 1 USEC

                                ;KEY SIG:       K3-3 DM=OL   /   K3-4 OVLAP INSTR H   /   K3-6 ROTSHF (L) L   /   K3-5 R
                                                ;   K3-8 ROT (L) H

022760  012700  000312          T0312:  MOV     #0312,R0                ;LOAD R0 WITH TEST NO.
022764  013701  023010                  MOV     @#I0312,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
022770  012702  177703                  MOV     #177703,R2      ;DEST ADDR = R3
022774  012704  052525                  MOV     #52525,R4       ;RESULT S  /  B = 52525
023000  012703  125252          R0312:  MOV     #125252,R3      ;[DEST] = 125252
023004  000257                          CCC                     ;CLEAR CODES
023006  000275                          275                     ;N:C = 1101

023010  006103                  I0312:  ROL     R3              ;TEST THE ROL

023012  100403                          BMI     E10312          ;N:C = 0011 ?
023014  001402                          BEQ     E10312
023016  102001                          BVC     E10312
023020  103402                          BCS     A0312

023022  104005                  E10312: ERRORS                  ;ROL FAILED TO ALTER THE CODES PROPERLY
023024  023000                          R0312                   ;ERROR LOOP RETURN
023026  020403                  A0312:  CMP     R4,R3           ;RESULT OK ?
023030  001402                          BEQ     00312           ;BR IF YES

023032  104000                  E20312: ERROR                   ;ROL DELIVERED THE WRONG RESULT
023034  023000                          R0312                   ;ERROR LOOP RETURN

023036  000004                  00312:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***********************************************************************
                                        .SBTTL T0313 ROL DMO TEST - (N:C) = 0101
                                ; ***********************************************************************

                                ;MICROPROGRAMMING   /   LOGIC INFORMATION

                                ;ROM SEQ:       [104,373,360,001] FC 1,7,8

                                ;ACT BUTS:      37[004]100,104 / 31[104]360,360 / 27[373]000,001

                                ;EXEC:          [104]ALUC=LHHLL :[373] D = 125252

                                ;CODES:         [373] SPS=1, [360] SPS=3  /  N:C = 1010

                                ;SYNC:          BOSJ2 (-) T = 1 USEC

                                ;KEY SIG:       K3-3 DM=OL  /  K3-4 OVLAP INSTR H  /  K3-6 ROTSHF (L) L  /  K3-5 ROTSHF
                                                ;  K3-8 ROT (L) H

023040  012700  000313          T0313:  MOV     #0313,R0                ;LOAD R0 WITH TEST NO.
023044  013701  023070                  MOV     @#I0313,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
023050  012702  177703                  MOV     #177703,R2      ;DEST ADDR = R3
023054  012704  125253                  MOV     #125253,R4      ;RESULT S / B = 125253
023060  012703  052525          R0313:  MOV     #52525,R3       ;[DEST] = 52525
023064  000257                          CCC                     ;CLEAR CODES
023066  000265                          265                     ;N:C = 0101

023070  006103                  I0313:  ROL     R3              ;TEST THE ROL

023072  100003                          BPL     E10313          ;N:C = 1010 ?
023074  001402                          BEQ     E10313
023076  102001                          BVC     E10313
023100  103002                          BCC     A0313

023102  104005                  E10313: ERRORS                  ;ROL FAILED TO ALTER THE CODES PROPERLY
023104  023060                          R0313                   ;ERROR LOOP RETURN
023106  020403                  A0313:  CMP     R4,R3           ;RESULT OK ?
023110  001402                          BEQ     00313           ;BR IF YES

023112  104000                  E20313: ERROR                   ;ROL DELIVERED THE WRONG RESULT
023114  023060                          R0313                   ;ERROR LOOP RETURN

023116  000004                  00313:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***********************************************************************
                                        .SBTTL T0314 ROL DMO TEST - (N:C) = 0010
                                ; ***********************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [104,373,360,001] FC 1,7,8

                                ;ACT BUTS:      37[004]100,104 / 31[104]360,360 / 27[373]000,001

                                ;EXEC:          [104]ALUC=LHHLL :[373] D = 000000

                                ;CODES:         [373] SPS=1, [360] SPS=3  /  N:C = 0100

                                ;SYNC:          B05J2 (-) T = 1 USEC

                                ;KEY SIG:       K3-3 DM=OL  /  K3-4 OVLAP INSTR H  /  K3-6 ROTSHF (L) L  /  K3-5 ROTSHF
                                                ;  K3-8 ROT (L) H

023120  012700  000314          T0314:  MOV     #0314,R0                ;LOAD R0 WITH TEST NO.
023124  013701  023144                  MOV     @#I0314,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
023130  012702  177703                  MOV     #177703,R2      ;DEST ADDR = R3
023134  005004                          CLR     R4              ;RESULT S / B = 000000
023136  005003                  R0314:  CLR     R3              ;[DEST] = 000000
023140  000257                          CCC                     ;CLEAR CODES
023142  000262                          SEV                     ;N:C = 0010

023144  006103                  I0314:  ROL     R3              ;TEST THE ROL

023146  100403                          BMI     E10314          ;N:C = 0100 ?
023150  001002                          BNE     E10314
023152  102401                          BVS     E10314
023154  103002                          BCC     A0314

023156  104005                  E10314: ERRORS                  ;ROL FAILED TO ALTER THE CODES PROPERLY
023160  023136                          R0314                   ;ERROR LOOP RETURN
023162  020403                  A0314:  CMP     R4,R3           ;RESULT OK ?
023164  001402                          BEQ     00314           ;BR IF YES

023166  104000                  E20314: ERROR                   ;ROL DELIVERED THE WRONG RESULT
023170  023136                          R0314                   ;ERROR LOOP RETURN

023172  000004                  00314:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***********************************************************************
                                        .SBTTL T0315 ADC DMO TEST - <N:C> = 0101
                                ; ***********************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [104,373,360,001] FC 1,7,8

                                ;ACT BUTS:      37[004]100,104 / 31[104]360,360 / 27[373]000,001

                                ;EXEC:          [104]ALUC=LLLLL :[373] D = 100000

                                ;CODES:         [373] SPS=1, [360] SPS=3  /  N:C = 1010

                                ;SYNC:          BOSJ2 (-) T = 1 USEC

                                ;KEY SIG:       K3-8 CINOO L  /  K3-3 DM=OL  /  K3-4 OVLAP INSTR H  /  K3-4 ADC L

023174  012700  000315          T0315:  MOV     #0315,R0                ;LOAD R0 WITH TEST NO.
023200  013701  023224                  MOV     @#I0315,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
023204  012702  177703                  MOV     #177703,R2      ;DEST ADDR = R3
023210  012704  100000                  MOV     #100000,R4      ;RESULT S / B = 100000
023214  012703  077777          R0315:  MOV     #77777,R3       ;[DEST] = 77777
023220  000257                          CCC                     ;CLEAR CODES
023222  000265                          265                     ;N:C = 0101

023224  005503                  I0315:  ADC     R3              ;TEST THE ADC

023226  100003                          BPL     E10315          ;N:C = 1010 ?
023230  001402                          BEQ     E10315
023232  102001                          BVC     E10315
023234  103002                          BCC     A0315

023236  104005                  E10315: ERROR5                  ;ADC FAILED TO ALTER THE CODES PROPERLY
023240  023214                          R0315                   ;ERROR LOOP RETURN
023242  020403                  A0315:  CMP     R4,R3           ;RESULT OK ?
023244  001402                          BEQ     00315           ;BR IF YES

023246  104000                  E20315: ERROR                   ;ADC DELIVERED THE WRONG RESULT
023250  023214                          R0315                   ;ERROR LOOP RETURN

023252  000004                  00315:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***********************************************************************
                                        .SBTTL T0316 ADC DMO TEST - <N:C> = 1011
                                ; ***********************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [104,373,360,001] FC 1,7,8

                                ;ACT BUTS:      37[004]100,104 / 31[104]360,360 / 27[373]000,001

                                ;EXEC:          [104]ALUC=LLLLL :[373] D = 000000

                                ;CODES:         [373] SPS=1, [360] SPS=3  /  N:C = 0101

                                ;SYNC:          B05J2 (-) T = 1 USEC

                                ;KEY SIG:       K3-8 CINOO L  /  K3-3 DM=OL  /  K3-4 OVLAP INSTR H  /  K3-4 ADC L

023254  012700  000316          T0316:  MOV     #0316,R0                ;LOAD R0 WITH TEST NO.
023260  013701  023302                  MOV     @#I0316,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
023264  012702  177703                  MOV     #177703,R2      ;DEST ADDR = R3
023270  005004                          CLR     R4              ;RESULT S / B = 000000
023272  012703  177777          R0316:  MOV     #-1,R3          ;[DEST] = 177777
023276  000257                          CCC                     ;CLEAR CODES
023300  000273                          273                     ;N:C = 1011

023302  005503                  I0316:  ADC     R3              ;TEST THE ADC

023304  100403                          BMI     E10316          ;N:C = 0101 ?
023306  001002                          BNE     E10316
023310  102401                          BVS     E10316
023312  103402                          BCS     A0316

023314  104005                  E10316: ERROR5                  ;ADC FAILED TO ALTER THE CODES PROPERLY
023316  023272                          R0316                   ;ERROR LOOP RETURN
023320  020403                  A0316:  CMP     R4,R3           ;RESULT OK ?
023322  001402                          BEQ     O0316           ;BR IF YES

023324  104000                  E20316: ERROR                   ;ADC DELIVERED THE WRONG RESULT
023326  023272                          R0316                   ;ERROR LOOP RETURN

023330  000004                  O0316:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***********************************************************************
                                        .SBTTL T0317 ADC DMO TEST - <N:C> = 1010
                                ; ***********************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [104,373,360,001] FC 1,7,8

                                ;ACT BUTS:      37[004]100,104 / 31[104]360,360 / 27[373]000,001

                                ;EXEC:          [104]ALUC=LLLLL :[373] D = 177777

                                ;CODES:         [373] SPS=1, [360] SPS=3  /  N:C = 1000

                                ;SYNC:          BOSJ2 (-) T = 1 USEC

                                ;KEY SIG:         /  K3-3 DM=OL  /  K3-4 OVLAP INSTR H  /  K3-4 ADC L

023332  012700  000317          T0317:  MOV     #0317,R0                ;LOAD R0 WITH TEST NO.
023336  013701  023362                  MOV     @#I0317,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
023342  012702  177703                  MOV     #177703,R2      ;DEST ADDR = R3
023346  012704  177777                  MOV     #-1,R4          ;RESULT S / B = 177777
023352  012703  177777          R0317:  MOV     #-1,R3          ;[DEST] = 177777
023356  000257                          CCC                     ;CLEAR CODES
023360  000272                          272                     ;N:C = 1010

023362  005503                  I0317:  ADC     R3              ;TEST THE ADC

023364  100003                          BPL     E10317          ;N:C = 1000 ?
023366  001402                          BEQ     E10317
023370  102401                          BVS     E10317
023372  103002                          BCC     A0317

023374  104005                  E10317: ERRORS                  ;ADC FAILED TO ALTER THE CODES PROPERLY
023376  023352                          R0317                   ;ERROR LOOP RETURN
023400  020403                  A0317:  CMP     R4,R3           ;RESULT OK ?
023402  001402                          BEQ     00317           ;BR IF YES

023404  104000                  E20317: ERROR                   ;ADC DELIVERED THE WRONG RESULT
023406  023352                          R0317                   ;ERROR LOOP RETURN

023410  000004                  00317:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0320 SBC DMO TEST - <N:C> = 1011
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [104,373,360,001] FC 1,7,8

                                ;ACT BUTS:      37[004]100,104 / 31[104]360,360 / 27[373]000,001

                                ;EXEC:          [104]ALUC=LHHHH :[373] D = 000000

                                ;CODES:         [373] SPS=1, [360] SPS=3  /  N:C = 0100

                                ;SYNC:          B05J2 (-) T = 1 USEC

                                ;KEY SIG:       K3-3 DM=OL  /  K3-4 OVLAP INSTR H  /  K3-4 SBC L

023412  012700  000320          T0320:  MOV     #0320,R0                ;LOAD R0 WITH TEST NO.
023416  013701  023440                  MOV     @#I0320,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
023422  012702  177703                  MOV     #177703,R2      ;DEST ADDR = R3
023426  005004                          CLR     R4              ;RESULT S / B = 000000
023430  012703  000001          R0320:  MOV     #1,R3           ;[DEST0321
023434  000257                          CCC                     ;CLEAR CODES
023436  000273                          273                     ;N:C = 1011

023440  005603                  I0320:  SBC     R3              ;TEST THE SBC

023442  100403                          BMI     E10320          ;N:C = 0100 ?
023444  001002                          BNE     E10320
023446  102401                          BVS     E10320
023450  103002                          BCC     A0320

023452  104005                  E10320: ERROR5                  ;SBC FAILED TO ALTER THE CODES PROPERLY
023454  023430                          R0320                   ;ERROR LOOP RETURN
023456  020403                  A0320:  CMP     R4,R3           ;RESULT OK ?
023460  001402                          BEQ     00320           ;BR IF YES

023462  104000                  E20320: ERROR                   ;SBC DELIVERED THE WRONG RESULT
023464  023430                          R0320                   ;ERROR LOOP RETURN

023466  000004                  00320:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***********************************************************************
                                        .SBTTL T0321 SBC DMO TEST - <N:C> = 0101
                                ; ***********************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [104,373,360,001] FC 1,7,8

                                ;ACT BUTS:      37[004]100,104 / 31[104]360,360 / 27[373]000,001

                                ;EXEC:          [104]ALUC=LHHHH :[373] D = 077777

                                ;CODES:         [373] SPS=1, [360] SPS=3  /  N:C = 0010

                                ;SYNC:          B05J2 (-) T = 1 USEC

                                ;KEY SIG:       K3-3 DM=OL  /  K3-4 OVLAP INSTR H  /  K3-4 SBC L

023470  012700  000321          T0321:  MOV     #0321,R0                ;LOAD R0 WITH TEST NO.
023474  013701  023520                  MOV     @#I0321,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
023500  012702  177703                  MOV     #177703,R2      ;DEST ADDR = R3
023504  012704  077777                  MOV     #077777,R4      ;RESULT S / B = 077777
023510  012703  100000          R0321:  MOV     #100000,R3      ;[DEST] = 100000
023514  000257                          CCC                     ;CLEAR CODES
023516  000265                          265                     ;N:C = 0101

023520  005603                  I0321:  SBC     R3              ;TEST THE SBC

023522  100403                          BMI     E10321          ;N:C = 0010 ?
023524  001402                          BEQ     E10321
023526  102001                          BVC     E10321
023530  103002                          BCC     A0321

023532  104005                  E10321: ERROR5                  ;SBC FAILED TO ALTER THE CODES PROPERLY
023534  023510                          R0321                   ;ERROR LOOP RETURN
023536  020403                  A0321:  CMP     R4,R3           ;RESULT OK ?
023540  001402                          BEQ     00321           ;BR IF YES

023542  104000                  E20321: ERROR                   ;SBC DELIVERED THE WRONG RESULT
023544  023510                          R0321                   ;ERROR LOOP RETURN

023546  000004                  00321:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0322 SBC DMO TEST - <N:C> = 1110
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [104,373,360,001] FC 1,7,8

                                ;ACT BUTS:      37[004]100,104 / 31[104]360,360 / 27[373]000,001

                                ;EXEC:          [104]ALUC=LLLLL :[373] D = 000001

                                ;CODES:         [373] SPS=1, [360] SPS=3  /  N:C = 0000

                                ;SYNC:          B05J2 (-) T = 1 USEC

                                ;KEY SIG:       K3-3 DM=OL  /  K3-4 OVLAP INSTR H  /  K3-4 SBC L

023550  012700  000322          T0322:  MOV     #0322,R0                ;LOAD R0 WITH TEST NO.
023554  013701  023600                  MOV     @#I0322,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
023560  012702  177703                  MOV     #177703,R2      ;DEST ADDR = R3
023564  012704  000001                  MOV     #1,R4           ;RESULT S / B = 1
023570  012703  000001          R0322:  MOV     #1,R3           ;[DEST] = 1
023574  000257                          CCC                     ;CLEAR CODES
023576  000276                          276                     ;N:C = 1110

023600  005603                  I0322:  SBC     R3              ;TEST THE SBC

023602  100403                          BMI     E10322          ;N:C = 0000 ?
023604  001402                          BEQ     E10322
023606  102401                          BVS     E10322
023610  103002                          BCC     A0322

023612  104005                  E10322: ERROR5                  ;SBC FAILED TO ALTER THE CODES PROPERLY
023614  023570                          R0322                   ;ERROR LOOP RETURN
023616  020403                  A0322:  CMP     R4,R3           ;RESULT OK ?
023620  001402                          BEQ     00322           ;BR IF YES

023622  104000                  E20322: ERROR                   ;SBC DELIVERED THE WRONG RESULT
023624  023570                          R0322                   ;ERROR LOOP RETURN

023626  000004                  00322:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***********************************************************************
                                        .SBTTL T0323 SBC DMO TEST - <N:C> = 0111
                                ; ***********************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [104,373,360,001] FC 1,7,8

                                ;ACT BUTS:      37[004]100,104 / 31[104]360,360 / 27[373]000,001

                                ;EXEC:          [104]ALUC=LHHHH :[373] D = 177777

                                ;CODES:         [373] SPS=1, [360] SPS=3  /  N:C 1001

                                ;SYNC:          B05J2 (-) T = 1 USEC

                                ;KEY SIG:       K3-3 DM=OL  /  K3-4 OVLAP INSTR H  /  K3-4 SBC L

023630  012700  000323          T0323:  MOV     #0323,R0                ;LOAD R0 WITH TEST NO.
023634  013701  023656                  MOV     @#I0323,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
023640  012702  177703                  MOV     #177703,R2      ;DEST ADDR = R3
023644  012704  177777                  MOV     #-1,R4          ;RESULT S / B = 177777
023650  005003                  R0323:  CLR     R3              ;[DEST] = 000000
023652  000257                          CCC                     ;CLEAR CODES
023654  000267                          267                     ;N:C = 0111

023656  005603                  I0323:  SBC     R3              ;TEST THE SBC

023660  100003                          BPL     E10323          ;N:C = 1001 ?
023662  001402                          BEQ     E10323
023664  102401                          BVS     E10323
023666  103402                          BCS     A0323

023670  104005                  E10323: ERROR5                  ;SBC FAILED TO ALTER THE CODES PROPERLY
023672  023650                          R0323                   ;ERROR LOOP RETURN
023674  020403                  A0323:  CMP     R4,R3           ;RESULT OK ?
023676  001402                          BEQ     00323           ;BR IF YES

023700  104000                  E20323: ERROR                   ;SBC DELIVERED THE WRONG RESULT
023702  023650                          R0323                   ;ERROR LOOP RETURN ADDRESS

023704  000004                  00323:  SCOPE                   ;CALL THE SCOPE LOOP UTILITY
```

```
                                ; ***********************************************************************
                                        .SBTTL T0324 TST DM1 TEST - (N:C) = 1011
                                ; ***********************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [161,266,267,220,211,367,375,016] FC 1,3,9,8

                                ;ACT BUTS:      37[004]100,161 / 33[266]220,220 / 16[367]016,016

                                ;EXEC:          [220]ALUC=LLLLL :[211] D = 000000

                                ;CODES:         [211] SPS=1, [367] SPS=3  /  N:C = 0100

                                ;SYNC:          B05J2 (-) T = 2 USEC

                                ;KEY SIG:       K3-3 DM=1L  / K3-4 TST L  /  K1-7 D(15:00)=0 H

023706  012700  000324          T0324:  MOV     #0324,R0                ;LOAD R0 WITH TEST NO.
023712  013701  023732                  MOV     @#I0324,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
023716  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
023722  005004                          CLR     R4              ;RESULT S / B = 000000
023724  005012                  R0324:  CLR     (R2)            ;[DEST] = 000000
023726  000257                          CCC                     ;CLEAR CODES
023730  000273                          273                     ;N:C=1011

023732  005712                  I0324:  TST     (R2)            ;TEST THE TST

023734  100403                          BMI     E10324          ;N:C = 0100 ?
023736  001002                          BNE     E10324
023740  102401                          BVS     E10324
023742  103002                          BCC     A0324

023744  104005                  E10324: ERROR5                  ;TST FAILED TO ALTER CODES PROPERLY
023746  023724                          R0324                   ;ERROR LOOP RETURN

023750  020412                  A0324:  CMP     R4,(R2)         ;RESULT OK ?
023752  001403                          BEQ     00324           ;BR IF YES

023754  011203                          MOV     (R2),R3         ;GET THE WAS DATA
023756  104000                  E20324: ERROR                   ;TST ALTERED THE [DEST]
023760  023724                          R0324                   ;ERROR LOOP RETURN

023762  000004                  00324:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***********************************************************************
                                                .SBTTL T0325 TST DM1 TEST - <N:C> = 0100
                                        ; ***********************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [161,266,267,220,211,367,375,016] FC 1,3,9,8

                                        ;ACT BUTS:      37[004]100,161 / 33[266]220,220 / 16[367]016,016

                                        ;EXEC:          [220]ALUC=LLLLL :[211] D = 177777

                                        ;CODES:         [211] SPS=1, [367] SPS=3  /  N:C = 1000

                                        ;SYNC:          B05J2 (-) T = 2 USEC

                                        ;KEY SIG:       K3-3 DM=1L  /  K3-4 TST L

023764  012700  000325          T0325:  MOV     #0325,R0                ;LOAD R0 WITH TEST NO.
023770  013701  024014                  MOV     @#I0325,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
023774  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
024000  005004                          CLR     R4
024002  005104                          COM     R4              ;RESULT S / B = 177777
024004  012712  177777          R0325:  MOV     #-1,(R2)        ;[DEST] = 177777
024010  000257                          CCC                     ;CLEAR CODES
024012  000264                          264                     ;N:C=0100

024014  005712                  I0325:  TST     (R2)            ;TEST THE TST

024016  100003                          BPL     E10325          ;N:C = 1000 ?
024020  001402                          BEQ     E10325
024022  102401                          BVS     E10325
024024  103002                          BCC     A0325

024026  104005                  E10325: ERROR5                  ;TST FAILED TO ALTER CODES PROPERLY
024030  024004                          R0325                   ;ERROR LOOP RETURN

024032  020412                  A0325:  CMP     R4,(R2)         ;RESULT OK ?
024034  001403                          BEQ     00325           ;BR IF YES

024036  011203                          MOV     (R2),R3         ;GET THE WAS DATA
024040  104000                  E20325: ERROR                   ;TST ALTERED THE [DEST]
024042  024004                          R0325                   ;ERROR LOOP RETURN

024044  000004                  00325:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***********************************************************************
                                                .SBTTL T0326 CLR DM1 TEST - (N:C) = 1011
                                        ; ***********************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [161,266,267,220,211,367,375,016] FC 1,3,9,8

                                        ;ACT BUTS:      37[004]100,161 / 33[266]220,220 / 16[367]016,016

                                        ;EXEC:          [220]ALUC=HLLHH :[211] D = 000000

                                        ;CODES:         [211] SPS=1, [367] SPS=3  /  N:C = 0100

                                        ;SYNC:          B05J2 (-) T = 2 USEC

                                        ;KEY SIG:       K3-3 DM=1L  /  K3-4 CLR L

024046  012700  000326          T0326:  MOV     #0326,R0                ;LOAD R0 WITH TEST NO.
024052  013701  024074                  MOV     @#I0326,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
024056  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
024062  005004                          CLR     R4              ;RESULT S / B = 000000
024064  012712  177777          R0326:  MOV     #-1,(R2)        ;[DEST] = 177777
024070  000257                          CCC                     ;CLEAR CODES
024072  000273                          273                     ;N:C = 1011

024074  005012                  I0326:  CLR     (R2)            ;TEST THE CLR

024076  100403                          BMI     E10326          ;N:C = 0100 ?
024100  001002                          BNE     E10326
024102  102401                          BVS     E10326
024104  103002                          BCC     A0326

024106  104005                  E10326: ERRORS                  ;CLR FAILED TO ALTER THE CODES PROPERLY
024110  024064                          R0326                   ;ERROR LOOP RETURN
024112  020412                  A0326:  CMP     R4,(R2)         ;RESULT OK ?
024114  001403                          BEQ     00326           ;BR IF YES

024116  011203                          MOV     (R2),R3         ;GET THE WAS DATA
024120  104000                  E20326: ERROR                   ;CLR DELIVERED THE WRONG RESULT
024122  024064                          R0326                   ;ERROR LOOP RETURN

024124  000004                  00326:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***********************************************************************
                                                .SBTTL T0327 CLR DM2 TEST - (N:C) = 0000
                                        ; ***********************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [161,266,267,220,211,367,375,016] FC 1,3,9,8

                                        ;ACT BUTS:      37[004]100,161 / 33[266]220,220 / 16[367]016,016

                                        ;EXEC:          [220]ALUC=HLLHH :[211] D = 000000

                                        ;CODES:         [211] SPS=1, [367] SPS=3  /  N:C = 0100

                                        ;SYNC:          BOSJ2 (-) T = 2 USEC

                                        ;KEY SIG:       K3-3 DM=1L  /  K3-4 CLR L

024126  012700  000327          T0327:  MOV     #0327,R0                ;LOAD R0 WITH TEST NO.
024132  013701  024152                  MOV     @#I0327,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
024136  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
024142  005004                          CLR     R4              ;RESULT S / B = 000000
024144  013712  067614          R0327:  MOV     @#DWTA+2,(R2)   ;[DEST] = 177777
024150  000257                          CCC                     ;CLEAR CODES

024152  005022                  I0327:  CLR     (R2)+           ;TEST THE CLR

024154  100403                          BMI     E10327          ;N:C = 0100 ?
024156  001002                          BNE     E10327
024160  102401                          BVS     E10327
024162  103002                          BCC     A0327

024164  104005                  E10327: ERROR5                  ;CLR FAILED TO ALTER THE CODES PROPERLY
024166  024144                          R0327                   ;ERROR LOOP RETURN
024170  022702  067604          A0327:  CMP     #MBUF0+2,R2     ;DID CLR INCREMENT DEST REG
024174  001402                          BEQ     B0327           ;BR IF YES

024176  104005                  E20327: ERROR5                  ;CLR FAILED TO UPDATE DEST REG
024200  024144                          R0327                   ;ERROR LOOP RETURN

024202  020442                  B0327:  CMP     R4,-(R2)                ;RESULT OK ?
024204  001403                          BEQ     00327           ;BR IF YES

024206  010203                          MOV     (R2),R3         ;GET THE WAS DATA
024210  104000                  E30327: ERROR                   ;CLR DELIVERED THE WRONG RESULT
024212  024144                          R0327                   ;ERROR LOOP RETURN

024214  000004                  00327:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***********************************************************************
                                        .SBTTL T0330 COM DM1 TEST - <N:C> = 0110
                                ; ***********************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [161,266,267,220,211,367,375,016] FC 1,3,9,8

                                ;ACT BUTS:      37[004]100,161 / 33[266]220,220 / 16[367]016,016

                                ;EXEC:          [220]ALUC=HLLLL :[211] D = 125252

                                ;CODES:         [211] SPS=1, [367] SPS=3  /  N:C=1001

                                ;SYNC:          B05J2 (-) T = 2 USEC

                                ;KEY SIG:       K3-3 DM=1L  /  K3-4 COM L

024216  012700  000330          T0330:  MOV     #0330,R0                ;LOAD R0 WITH TEST NO.
024222  013701  024246                  MOV     @#I0330,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
024226  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
024232  012704  125252                  MOV     #125252,R4      ;RESULT S / B = 125252
024236  012712  052525          R0330:  MOV     #52525,(R2)     ;[DEST] = 52525
024242  000257                          CCC                     ;CLEAR CODES
024244  000266                          266                     ;N:C = 0110

024246  005112                  I0330:  COM     (R2)            ;TEST THE CLR

024250  100003                          BPL     E10330          ;N:C = 1001 ?
024252  001402                          BEQ     E10330
024254  102401                          BVS     E10330
024256  103402                          BCS     A0330

024260  104005                  E10330: ERROR5                  ;COM FAILED TO ALTER THE CODES PROPERLY
024262  024236                          R0330                   ;ERROR LOOP RETURN
024264  020412                  A0330:  CMP     R4,(R2)         ;RESULT OK ?
024266  001403                          BEQ     00330           ;BR IF YES

024270  011203                          MOV     (R2),R3         ;GET THE WAS DATA
024272  104000                  E20330: ERROR                   ;COM DELIVERED THE WRONG RESULT
024274  024236                          R0330                   ;ERROR LOOP RETURN

024276  000004                  00330:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***********************************************************************
                                        .SBTTL T0331 COM DM1 TEST - <N:C> = 1001
                                ; ***********************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [161,266,267,220,211,367,375,016] FC 1,3,9,8

                                ;ACT BUTS:      37[004]100,161 / 33[266]220,220 / 16[367]016,016

                                ;EXEC:          [220]ALUC=HLLLL :[211] D = 000000

                                ;CODES:         [211] SPS=1, [367] SPS=3  /  N:C = 0101

                                ;SYNC:          B05J2 (-) T = 2 USEC

                                ;KEY SIG:       K3-3 DM=1L  /  K3-4 COM L

024300  012700  000331          T0331:  MOV     #0331,R0                ;LOAD R0 WITH TEST NO.
024304  013701  024326                  MOV     @#I0331,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
024310  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
024314  005004                          CLR     R4              ;RESULT S / B = 000000
024316  012712  177777          R0331:  MOV     #-1,(R2)        ;[DEST] = 177777
024322  000257                          CCC                     ;CLEAR CODES
024324  000271                          271                     ;N:C = 1001

024326  005112                  I0331:  COM     (R2)            ;TEST THE COM

024330  100403                          BMI     E10331          ;N:C = 0101 ?
024332  001002                          BNE     E10331
024334  102401                          BVS     E10331
024336  103402                          BCS     A0331

024340  104005                  E10331: ERRORS                  ;COM FAILED TO ALTER THE CODES PROPERLY
024342  024316                          R0331                   ;ERROR LOOP RETURN
024344  020412                  A0331:  CMP     R4,(R2)         ;RESULT OK ?
024346  001403                          BEQ     00331           ;BR IF YES

024350  011203                          MOV     (R2),R3         ;GET THE WAS DATA
024352  104000                  E20331: ERROR                   ;COM DELIVERED THE WRONG RESULT
024354  024316                          R0331                   ;ERROR LOOP RETURN

024356  000004                  00331:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***********************************************************************
                                        .SBTTL T0332 INC DM1 TEST - <N:C> = 1011
                                ; ***********************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [161,266,267,220,211,367,275,016] FC 1,3,9,8

                                ;ACT BUTS:      37[004]100,161 / 33[266]220,220 / 16[367]016,016

                                ;EXEC:          [220]ALUC=LLLLL :[211] D = 000000

                                ;CODES:         [211] SPS=1, [367] SPS=3  /  N:C = 0101

                                ;SYNC:          BOSJ2 (-) T = 2 USEC

                                ;KEY SIG:       K3-3 DM=1L  /  K3-4 INC L  /  K3-8 CINOO L

024360  012700  000332          T0332:  MOV     #0332,R0                ;LOAD R0 WITH TEST NO.
024364  013701  024406                  MOV     @#I0332,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
024370  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
024374  005004                          CLR     R4              ;RESULT S / B = 000000
024376  012712  177777          R0332:  MOV     #-1,(R2)                ;[DEST] = 177777
024402  000257                          CCC                     ;CLEAR CODES
024404  000273                          273                     ;N:C = 1011

024406  005212                  I0332:  INC     (R2)            ;TEST THE INC

024410  100403                          BMI     E10332          ;N:C = 0101 ?
024412  001002                          BNE     E10332
024414  102401                          BVS     E10332
024416  103402                          BCS     A0332

024420  104005                  E10332: ERRORS                  ;INC FAILED TO ALTER THE CODES PROPERLY
024422  024376                          R0332                   ;ERROR LOOP RETURN
024424  020412                  A0332:  CMP     R4,(R2)         ;RESULT OK ?
024426  001403                          BEQ     00332           ;BR IF YES

024430  011203                          MOV     (R2),R3         ;GET THE WAS DATA
024432  104000                  E20332: ERROR                   ;INC DELIVERED THE WRONG RESULT
024434  024376                          R0332                   ;ERROR LOOP RETURN

024436  000004                  00332:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***********************************************************************
                                        .SBTTL T0333 INC DM1 TEST - <N:C> = 0100
                                ; ***********************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [161,266,267,220,211,367,375,016] FC 1,3,9,8

                                ;ACT BUTS:      37[004]100,161 / 33[266]220,220 / 16[367]016,016

                                ;EXEC:          [220]ALUC=LLLLL :[211] D = 100000

                                ;CODES:         [211] SPS=1, [367] SPS=3  /  N:C = 1010

                                ;SYNC:          B05J2 (-) T = 2 USEC

                                ;KEY SIG:       K3-3 DM=1L  /  K3-4 INC L  /  K3-8 CINOO L

024440  012700  000333          T0333:  MOV     #0333,R0                ;LOAD R0 WITH TEST NO.
024444  013701  024470                  MOV     @#I0333,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
024450  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
024454  012704  100000                  MOV     #100000,R4      ;RESULT S / B = 100000
024460  012712  077777          R0333:  MOV     #77777,(R2)     ;[DEST] = 77777
024464  000257                          CCC                     ;CLEAR CODES
024466  000264                          264                     ;N:C = 0100

024470  005212                  I0333:  INC     (R2)            ;TEST THE INC

024472  100003                          BPL     E10333          ;N:C = 1010 ?
024474  001402                          BEQ     E10333
024476  102001                          BVC     E10333
024500  103002                          BCC     A0333

024502  104005                  E10333: ERROR5                  ;INC FAILED TO ALTER THE CODES PROPERLY
024504  024460                          R0333                   ;ERROR LOOP RETURN
024506  020412                  A0333:  CMP     R4,(R2)         ;RESULT OK ?
024510  001403                          BEQ     00333           ;BR IF YES

024512  011203                          MOV     (R2),R3         ;GET THE WAS DATA
024514  104000                  E20333: ERROR                   ;INC DELIVERED THE WRONG RESULT
024516  024460                          R0333                   ;ERROR LOOP RETURN

024520  000004                  00333:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***********************************************************************
                                                .SBTTL T0334 DEC DM1 TEST - <N:C> = 1011
                                        ; ***********************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [161,266,267,220,211,367,375,016] FC 1,3,9,8

                                        ;ACT BUTS:      37[004]100,161 / 33[266]220,220 / 16[367]016,016

                                        ;EXEC:          [220]ALUC=LHHHH :[211] D = 000000

                                        ;CODES:         [211] SPS=1, [367] SPS=3  /  N:C = 0101

                                        ;SYNC:          B05J2 (-) T = 2 USEC

                                        ;KEY SIG:       K3-3 DM=1L  /  K3-4 DEC L

024522  012700  000334          T0334:  MOV     #0334,R0                ;LOAD R0 WITH TEST NO.
024526  013701  024562                  MOV     @#I0334,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
024532  032737  000100  066642          BIT     #100,@#BPTLOC   ;BREAKPOINT HALT SET
024540  001401                          BEQ     .+4             ;BR IF NOT
024542  000000                          HALT                    ;BREAK-DEPRESS CONTINUE TO RESTART
024544  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
024550  005004                          CLR     R4              ;RESULT S / B = 000000
024552  012712  000001          R0334:  MOV     #1,(R2)         ;[DEST] = 1
024556  000257                          CCC                     ;CLEAR CODES
024560  000273                          273                     ;N:C = 1011

024562  005312                  I0334:  DEC     (R2)            ;TEST THE DEC

024564  100403                          BMI     E10334          ;N:C = 0101 ?
024566  001002                          BNE     E10334
024570  102401                          BVS     E10334
024572  103402                          BCS     A0334

024574  104005                  E10334: ERROR5                  ;DEC FAILED TO ALTER THE CODES PROPERLY
024576  024552                          R0334                   ;ERROR LOOP RETURN
024600  020412                  A0334:  CMP     R4,(R2)         ;RESULT OK ?
024602  001403                          BEQ     00334           ;BR IF YES

024604  011203                          MOV     (R2),R3         ;GET THE WAS DATA
024606  104000                  E20334: ERROR                   ;DEC DELIVERED THE WRONG RESULT
024610  024552                          R0334                   ;ERROR LOOP RETURN

024612  000004                  00334:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***********************************************************************
                                        .SBTTL T0335 DEC DM1 TEST - (N:C) = 1100
                                ; ***********************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [161,266,267,220,211,367,375,016] FC 1,3,9,8

                                ;ACT BUTS:      37[004]100,161 / 33[266]220,220 / 16[367]016,016

                                ;EXEC:          [220]ALUC=LHHHH :[211] D = 77777

                                ;CODES:         [211] SPS=1, [367] SPS=3  /  N:C = 0010

                                ;SYNC:          B05J2 (-) T = 2 USEC

                                ;KEY SIG:       K3-3 DM=1L  /  K3-4 DEC L

024614  012700  000335          T0335:  MOV     #0335,R0                ;LOAD R0 WITH TEST NO.
024620  013701  024644                  MOV     @#I0335,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
024624  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
024630  012704  077777                  MOV     #77777,R4       ;RESULT S / B = 77777
024634  012712  100000          R0335:  MOV     #100000,(R2)    ;[DEST] = 100000
024640  000257                          CCC                     ;CLEAR CODES
024642  000274                          274                     ;N:C = 1100

024644  005312                  I0335:  DEC     (R2)            ;TEST THE DEC

024646  100403                          BMI     E10335          ;N:C = 0010 ?
024650  001402                          BEQ     E10335
024652  102001                          BVC     E10335
024654  103002                          BCC     A0335

024656  104005                  E10335: ERROR5                  ;DEC FAILED TO ALTER THE CODES PROPERLY
024660  024634                          R0335                   ;ERROR LOOP RETURN
024662  020412                  A0335:  CMP     R4,(R2)         ;RESULT OK ?
024664  001403                          BEQ     00335           ;BR IF YES

024666  011203                          MOV     (R2),R3         ;GET THE WAS DATA
024670  104000                  E20335: ERROR                   ;DEC DELIVERED THE WRONG RESULT
024672  024634                          R0335                   ;ERROR LOOP RETURN

024674  000004                  00335:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***********************************************************************
                                        .SBTTL T0336 DEC DM1 TEST - <N:C> = 0000
                                ; ***********************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [161,266,267,220,211,367,375,016] FC 1,3,9,8

                                ;ACT BUTS:      37[004]100,161 / 33[266]220,220 / 16[367]016,016

                                ;EXEC:          [220]ALUC=LHHHH :[211] D = 177777

                                ;CODES:         [211] SPS=1, [367] SPS=3  /  N:C 1000

                                ;SYNC:          B05J2 (-) T = 2 USEC

                                ;KEY SIG:       K3-3 DM=1L  /  K3-4 DEC L

024676  012700  000336          T0336:  MOV     #0336,R0                ;LOAD R0 WITH TEST NO.
024702  013701  024722                  MOV     @#I0336,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
024706  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
024712  012704  177777                  MOV     #-1,R4          ;RESULT S / B = 177777
024716  005012                  R0336:  CLR     (R2)            ;[DEST] = 000000
024720  000257                          CCC                     ;CLEAR CODES

024722  005312                  I0336:  DEC     (R2)            ;TEST THE DEC

024724  100003                          BPL     E10336          ;N:C = 1000 ?
024726  001402                          BEQ     E10336
024730  102401                          BVS     E10336
024732  103002                          BCC     A0336

024734  104005                  E10336: ERROR5                  ;DEC FAILED TO ALTER THE CODES PROPERLY
024736  024716                          R0336                   ;ERROR LOOP RETURN
024740  020412                  A0336:  CMP     R4,(R2)         ;RESULT OK ?
024742  001403                          BEQ     00336           ;BR IF YES

024744  011203                          MOV     (R2),R3         ;GET THE WAS DATA
024746  104000                  E20336: ERROR                   ;DEC DELIVERED THE WRONG RESULT
024750  024716                          R0336                   ;ERROR LOOP RETURN

024752  000004                  00336:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***********************************************************************
                                        .SBTTL T0337 ASL DM1 TEST - <N:C> = 1000
                                ; ***********************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [161,266,267,220,211,367,375,016] FC 1,3,9,8

                                ;ACT BUTS:      37[004]100,161 / 33[266]220,220 / 16[367]016,016

                                ;EXEC:          [220]ALUC=LHHLL :[211] D = 000000

                                ;CODES:         [211] SPS=1, [367] SPS=3  /  N:C = 0111

                                ;SYNC:          B05J2 (-) T = 2 USEC

                                ;KEY SIG:       K3-3 DM=1L  /  K3-6 ROTSHF (L) L  /  K3-5 ROTSHF H

024754  012700  000337          T0337:  MOV     #0337,R0                ;LOAD R0 WITH TEST NO.
024760  013701  025002                  MOV     @#I0337,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
024764  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
024770  005004                          CLR     R4              ;RESULT S / B = 000000
024772  012712  100000          R0337:  MOV     #100000,(R2)    ;[DEST] = 100000
024776  000257                          CCC                     ;CLEAR CODES
025000  000270                          SEN                     ;N:C = 1000

025002  006312                  I0337:  ASL     (R2)            ;TEST THE ASL

025004  100403                          BMI     E10337          ;N:C = 0111 ?
025006  001002                          BNE     E10337
025010  102001                          BVC     E10337
025012  103402                          BCS     A0337

025014  104005                  E10337: ERROR5                  ;ASL FAILED TO ALTER THE CODES PROPERLY
025016  024772                          R0337                   ;ERROR LOOP RETURN
025020  020412                  A0337:  CMP     R4,(R2)         ;RESULT OK ?
025022  001403                          BEQ     00337           ;BR IF YES

025024  011203                          MOV     (R2),R3         ;GET THE WAS DATA
025026  104000                  E20337: ERROR                   ;ASL DELIVERED THE WRONG RESULT
025030  024772                          R0337                   ;ERROR LOOP RETURN

025032  000004                  00337:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0340 ASL DM1 TEST - <N:C> = 0101
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [161,266,267,220,211,367,375,016] FC 1,3,9,8

                                ;ACT BUTS:      37[004]100,161 / 33[266]220,220 / 16[367]016,016

                                ;EXEC:          [220]ALUC=LHHLL :[211] D = 100000

                                ;CODES:         [211] SPS=1, [367] SPS=3  /  N:C = 1010

                                ;SYNC:          B05J2 (-) T = 2 USEC

                                ;KEY SIG:       K3-3 DM=1L  /  K3-6 ROTSHF (L) L  /  K3-5 ROTSHF H

025034  012700  000340          T0340:  MOV     #0340,R0                ;LOAD R0 WITH TEST NO.
025040  013701  025064                  MOV     @#I0340,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
025044  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
025050  012704  100000                  MOV     #100000,R4      ;RESULT S / B = 100000
025054  012712  040000          R0340:  MOV     #40000,(R2)     ;[DEST] = 40000
025060  000257                          CCC                     ;CLEAR CODES
025062  000265                          265                     ;N:C = 0101

025064  006312                  I0340:  ASL     (R2)            ;TEST THE ASL

025066  100003                          BPL     E10340          ;N:C = 1010 ?
025070  001402                          BEQ     E10340
025072  102001                          BVC     E10340
025074  103002                          BCC     A0340

025076  104005                  E10340: ERROR5                  ;ASL FAILED TO ALTER THE CODES PROPERLY
025100  025054                          R0340                   ;ERROR LOOP RETURN
025102  020412                  A0340:  CMP     R4,(R2)         ;RESULT OK ?
025104  001403                          BEQ     00340           ;BR IF YES

025106  011203                          MOV     (R2),R3         ;GET THE WAS DATA
025110  104000                  E20340: ERROR                   ;ASL DELIVERED THE WRONG RESULT
025112  025054                          R0340                   ;ERROR LOOP RETURN

025114  000004                  00340:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***********************************************************************
                                        .SBTTL T0341 ASL DM1 TEST - (N:C) = 0010
                                ; ***********************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [161,266,267,220,211,367,375,016] FC 1,3,9,8

                                ;ACT BUTS:      37[004]100,161 / 33[266]220,220 / 16[367]016,016

                                ;EXEC:          [220]ALUC=LHHLL :[211] D = 000000

                                ;CODES:         [211] SPS=1, [367] SPS=3  /  N:C = 0100

                                ;SYNC:          B05J2 (-) T = 2 USEC

                                ;KEY SIG:       K3-3 DM=1L  /  K3-6 ROTSHF (L) L  /  K3-5 ROTSHF F

025116  012700  000341          T0341:  MOV     #0341,R0                ;LOAD R0 WITH TEST NO.
025122  013701  025142                  MOV     @#I0341,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
025126  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
025132  005004                          CLR     R4              ;RESULT S / B = 000000
025134  005012                  R0341:  CLR     (R2)            ;[DEST] = 000000
025136  000257                          CCC                     ;CLEAR CODES
025140  000262                          SEV                     ;N:C = 0010

025142  006312                  I0341:  ASL     (R2)            ;TEST THE ASL

025144  100403                          BMI     E10341          ;N:C = 0100 ?
025146  001002                          BNE     E10341
025150  102401                          BVS     E10341
025152  103002                          BCC     A0341

025154  104005                  E10341: ERROR5                  ;ASL FAILED TO ALTER THE CODES PROPERLY
025156  025134                          R0341                   ;ERROR LOOP RETURN
025160  020412                  A0341:  CMP     R4,(R2)         ;RESULT OK ?
025162  001403                          BEQ     00341           ;BR IF YES

025164  011203                          MOV     (R2),R3         ;GET THE WAS DATA
025166  104000                  E20341: ERROR                   ;ASL DELIVERED THE WRONG RESULT
025170  025134                          R0341                   ;ERROR LOOP RETURN

025172  000004                  00341:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***********************************************************************
                                        .SBTTL T0342 ROL DM1 TEST - (N:C) = 1101
                                ; ***********************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [161,266,267,220,211,367,375,016] FC 1,3,9,8

                                ;ACT BUTS:      37[004]100,161 / 33[266]220,220 / 16[367]016,016

                                ;EXEC:          [220]ALUC=LHHLL :[211] D = 052525

                                ;CODES:         [211] SPS=1, [367] SPS=3  /  N:C = 0011

                                ;SYNC:          BOSJ2 (-) T = 2 USEC

                                ;KEY SIG:       K3-3 DM=1L  /  K3-6 ROTSHF (L) L  /  K3-5 ROTSHF H  /  K3-8 ROT (L) H

025174  012700  000342          T0342:  MOV     #0342,R0                ;LOAD R0 WITH TEST NO.
025200  013701  025224                  MOV     @#I0342,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
025204  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
025210  012704  052525                  MOV     #52525,R4       ;RESULT S / B = 52525
025214  012712  125252          R0342:  MOV     #125252,(R2)    ;[DEST] = 125252
025220  000257                          CCC                     ;CLEAR CODES
025222  000275                          275                     ;N:C = 1101

025224  006112                  I0342:  ROL     (R2)            ;TEST THE ROL

025226  100403                          BMI     E10342          ;N:C = 0011 ?
025230  001402                          BEQ     E10342
025232  102001                          BVC     E10342
025234  103402                          BCS     A0342

025236  104005                  E10342: ERROR5                  ;ROL FAILED TO ALTER THE CODES PROPERLY
025240  025214                          R0342                   ;ERROR LOOP RETURN
025242  020412                  A0342:  CMP     R4,(R2)         ;RESULT OK ?
025244  001403                          BEQ     00342           ;BR IF YES

025246  011203                          MOV     (R2),R3         ;GET THE WAS DATA
025250  104000                  E20342: ERROR                   ;ROL DELIVERED THE WRONG RESULT
025252  025214                          R0342                   ;ERROR LOOP RETURN

025254  000004                  00342:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***********************************************************************
                                                .SBTTL T0343 ROL DM1 TEST - (N:C) = 0101
                                        ; ***********************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [161,266,267,220,211,367,075,016] FC 1,3,9,8

                                        ;ACT BUTS:      37[004]100,161 / 33[266]220,220 / 16[367]016,016

                                        ;EXEC:          [220]ALUC=LHHLL :[211] D = 125253

                                        ;CODES:         [211] SPS=1, [367] SPS=3  /  N:C = 1010

                                        ;SYNC:          BC5J2 (-) T = 2 USEC

                                        ;KEY SIG:       K3-3 DM=1L  /  K3-6 ROTSHF (L) L  /  K3-5 ROTSHF H  /  K3-8 ROT (L) H

025256  012700  000343          T0343:  MOV     #0343,R0                ;LOAD R0 WITH TEST NO.
025262  013701  025306                  MOV     @#T0343,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
025266  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
025272  012704  125253                  MOV     #125253,R4      ;RESULT S / B = 125253
025276  012712  052525          R0343:  MOV     #52525,(R2)     ;(DEST) = 52525
025302  000257                          CCC                     ;CLEAR CODES
025304  000265                          265                     ;N:C = 0101

025306  006112                  T0343:  ROL     (R2)            ;TEST THE ROL

025310  100003                          BPL     E10343          ;N:C = 1010 ?
025312  001402                          BEQ     E10343
025314  102001                          BVC     E10343
025316  103002                          BCC     A0343

025320  104005                  E10343: ERROR5                  ;ROL FAILED TO ALTER THE CODES PROPERLY
025322  025276                          R0343                   ;ERROR LOOP RETURN
025324  020412                  A0343:  CMP     R4,(R2)         ;RESULT OK ?
025326  001403                          BEQ     00343           ;BR IF YES

025330  011203                          MOV     (R2),R3         ;GET THE WAS DATA
025332  104000                  E20343: ERROR                   ;ROL DELIVERED THE WRONG RESULT
025334  025276                          R0343                   ;ERROR LOOP RETURN

025336  000004                  00343:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***********************************************************************
                                        .SBTTL T0344 ROL DMI TEST - (N:C) = 0010
                                ; ***********************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [161,266,267,220,211,367,375,016] FC 1,3,9,8

                                ;ACT BUTS:      37[004]100,161 / 33[266]220,220 / 16[367]016,016

                                ;EXEC:          [220]ALUC=LHHLL :[211] D = 000000

                                ;CODES:         [211] SPS=1, [367] SPS=3  /  N:C =0100

                                ;SYNC:          BOSJ2 (-) T = 2 USEC

                                ;KEY SIG:       K3-3 DM=1L  /  K3-6 ROTSHF (L) L  /  K3-5 ROTSHF H  /  K3-8 ROT (L) H

025340  012700  000344          T0344:  MOV     #0344,R0                ;LOAD R0 WITH TEST NO.
025344  013701  025364                  MOV     @#T0344,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
025350  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
025354  005004                          CLR     R4              ;RESULT S / B = 000000
025356  005012                  R0344:  CLR     (R2)            ;[DEST] = 000000
025360  000257                          CCC                     ;CLEAR CODES
025362  000262                          SEV                     ;N:C = 0010

025364  006112                  T0344:  ROL     (R2)            ;TEST THE ROL

025366  100403                          BMI     E10344          ;N:C = 0100 ?
025370  001002                          BNE     E10344
025372  102401                          BVS     E10344
025374  103002                          BCC     A0344

025376  104005                  E10344: ERRORS                  ;ROL FAILED TO ALTER THE CODES PROPERLY
025400  025356                          R0344                   ;ERROR LOOP RETURN
025402  020412                  A0344:  CMP     R4,(R2)         ;RESULT OK ?
025404  001403                          BEQ     00344           ;BR IF YES

025406  011203                          MOV     (R2),R3         ;GET THE WAS DATA
025410  104000                  E20344: ERROR                   ;ROL DELIVERED THE WRONG RESULT
025412  025356                          R0344                   ;ERROR LOOP RETURN

025414  000004                  00344:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***********************************************************************
                                        .SBTTL T0345 ADC DM1 TEST - <N:C> = 0101
                                ; ***********************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [161,266,267,220,211,367,375,016] FC 1,3,9,8

                                ;ACT BUTS:      37[004]100,161 / 33[266]220,220 / 16[367]016,016

                                ;EXEC:          [220]ALUC=LLLLL :[211] D = 100000

                                ;CODES:         [211] SPS=1, [367] SPS=3  /  N:C =1010

                                ;SYNC:          B05J2 (-) T = 2 USEC

                                ;KEY SIG:       K3-8 CINOO L  /  K3-3 DM=1L  /  K3-4 ADC L

025416  012700  000345          T0345:  MOV     #0345,R0                ;LOAD R0 WITH TEST NO.
025422  013701  025446                  MOV     @#I0345,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
025426  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
025432  012704  100000                  MOV     #100000,R4      ;RESULT S / B = 100000
025436  012712  077777          R0345:  MOV     #77777,(R2)     ;[DEST] = 77777
025442  000257                          CCC                     ;CLEAR CODES
025444  000265                          265                     ;N:C = 0101

025446  005512                  I0345:  ADC     (R2)            ;TEST THE ADC

025450  100003                          BPL     E10345          ;N:C = 1010 ?
025452  001402                          BEQ     E10345
025454  102001                          BVC     E10345
025456  103002                          BCC     A0345

025460  104005                  E10345: ERROR5                  ;ADC FAILED TO ALTER THE CODES PROPERLY
025462  025436                          R0345                   ;ERROR LOOP RETURN
025464  020412                  A0345:  CMP     R4,(R2)         ;RESULT OK ?
025466  001403                          BEQ     00345           ;BR IF YES

025470  011203                          MOV     (R2),R3         ;GET THE WAS DATA
025472  104000                  E20345: ERROR                   ;ADC DELIVERED THE WRONG RESULT
025474  025436                          R0345                   ;ERROR LOOP RETURN

025476  000004                  00345:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***********************************************************************
                                        .SBTTL T0346 ADC DM1 TEST - <N:C> = 1011
                                ; ***********************************************************************

                                ;MICROPROGRAMMING   /   LOGIC INFORMATION

                                ;ROM SEQ:       [161,266,267,220,211,367,375,016] FC 1,3,9,8

                                ;ACT BUTS:      37[004]100,161  /  33[266]220,220  /  16[367]016,016

                                ;EXEC:          [220]ALUC=LHHLL :[211] D = 000000

                                ;CODES:         [211] SPS=1, [367] SPS=3   /   N:C = 0101

                                ;SYNC:          B05J2 (-) T = 2 USEC

                                ;KEY SIG:       K3-8 CINOO L   /   K3-3 DM=1L   /   K3-4 ADC L

025500  012700  000346          T0346:  MOV     #0346,R0                ;LOAD R0 WITH TEST NO.
025504  013701  025526                  MOV     @#T0346,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
025510  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
025514  005004                          CLR     R4              ;RESULT S  /  B = 000000
025516  012712  177777          R0346:  MOV     #-1,(R2)        ;[DEST] = 177777
025522  000257                          CCC                     ;CLEAR CODES
025524  000273                          273                     ;N:C = 1011

025526  005512                  I0346:  ADC     (R2)            ;TEST THE ADC

025530  100403                          BMI     E10346          ;N:C = 0101 ?
025532  001002                          BNE     E10346
025534  102401                          BVS     E10346
025536  103402                          BCS     A0346

025540  104005                  E10346: ERRORS                  ;ADC FAILED TO ALTER THE CODES PROPERLY
025542  025516                          R0346                   ;ERROR LOOP RETURN
025544  020412                  A0346:  CMP     R4,(R2)         ;RESULT OK ?
025546  001403                          BEQ     00346           ;BR IF YES

025550  011203                          MOV     (R2),R3         ;GET THE WAS DATA
025552  104000                  E20346: ERROR                   ;ADC DELIVERED THE WRONG RESULT
025554  025516                          R0346                   ;ERROR LOOP RETURN

025556  000004                  00346:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***********************************************************************
                                        .SBTTL T0347 ADC DM1 TEST - <N:C> = 1010
                                ; ***********************************************************************

                                ;MICROPROGRAMMING   /   LOGIC INFORMATION

                                ;ROM SEQ:       [161,266,267,220,211,367,375,016] FC 1,3,9,8

                                ;ACT BUTS:      37[004]100,161  /  33[266]220,220  /  16[367]016,016

                                ;EXEC:          [220]ALUC=LHHLL :[211] D = 177777

                                ;CODES:         [211] SPS=1, [367] SPS=3   /   N:C = 1000

                                ;SYNC:          BOSJ2 (-) T = 2 USEC

                                ;KEY SIG:          /   K3-3 DM=1L   /   K3-4 ADC L

025560  012700  000347          T0347:  MOV     #0347,R0                ;LOAD R0 WITH TEST NO.
025564  013701  025610                  MOV     @#T0347,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
025570  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
025574  012704  177777                  MOV     #-1,R4          ;RESULT S  /  B = 177777
025600  012712  177777          R0347:  MOV     #-1,(R2)        ;[DEST] = 177777
025604  000257                          CCC                     ;CLEAR CODES
025606  000272                          272                     ;N:C = 1010

025610  005512                  T0347:  ADC     (R2)            ;TEST THE ADC

025612  100003                          BPL     E10347          ;N:C = 1000 ?
025614  001402                          BEQ     E10347
025616  102401                          BVS     E10347
025620  103002                          BCC     A0347

025622  104005                  E10347: ERROR5                  ;ADC FAILED TO ALTER THE CODES PROPERLY
025624  025600                          R0347                   ;ERROR LOOP RETURN
025626  020412                  A0347:  CMP     R4,(R2)         ;RESULT OK ?
025630  001403                          BEQ     00347           ;BR IF YES

025632  011203                          MOV     (R2),R3         ;GET THE WAS DATA
025634  104000                  E20347: ERROR                   ;ADC DELIVERED THE WRONG RESULT
025636  025600                          R0347                   ;ERROR LOOP RETURN

025640  000004                  00347:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***********************************************************************
                                        .SBTTL T0350 SBC DM1 TEST - <N:C> = 1011
                                ; ***********************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [161,266,267,220,211,367,375,016] FC 1,3,9,8

                                ;ACT BUTS:      37[004]100,161 / 33[266]220,220 / 16[367]016,016

                                ;EXEC:          [220]ALUC=LHHHH :[211] D = 000000

                                ;CODES:         [211] SPS=1, [367] SPS=3  /  N:C = 0100

                                ;SYNC:          B05J2 (-) T = 2 USEC

                                ;KEY SIG:       K3-3 DM=1L  /  K3-4 SBC L

025642  012700  000350          T0350:  MOV     #0350,R0                ;LOAD R0 WITH TEST NO.
025646  013701  025670                  MOV     @#I0350,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
025652  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
025656  005004                          CLR     R4              ;RESULT S / B = 000000
025660  012712  000001          R0350:  MOV     #1,(R2)         ;[DEST0351
025664  000257                          CCC                     ;CLEAR CODES
025666  000273                          273                     ;N:C = 1011

025670  005612                  I0350:  SBC     (R2)            ;TEST THE SBC

025672  100403                          BMI     E10350          ;N:C = 0100 ?
025674  001002                          BNE     E10350
025676  102401                          BVS     E10350
025700  103002                          BCC     A0350

025702  104005                  E10350: ERRORS                  ;SBC FAILED TO ALTER THE CODES PROPERLY
025704  025660                          R0350                   ;ERROR LOOP RETURN
025706  020412                  A0350:  CMP     R4,(R2)         ;RESULT OK ?
025710  001403                          BEQ     00350           ;BR IF YES

025712  011203                          MOV     (R2),R3         ;GET THE WAS DATA
025714  104000                  E20350: ERROR                   ;SBC DELIVERED THE WRONG RESULT
025716  025660                          R0350                   ;ERROR LOOP RETURN

025720  000004                  00350:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***********************************************************************
                                        .SBTTL T0351 SBC DM1 TEST - <N:C> = 0101
                                ; ***********************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [161,266,267,220,211,367,375,016] FC 1,3,9,8

                                ;ACT BUTS:      37[004]100,161 / 33[266]220,220 / 16[367]016,016

                                ;EXEC:          [220]ALUC=LHHLL :[211] D = 077777

                                ;CODES:         [211] SPS=1, [367] SPS=3  /  N:C = 0010

                                ;SYNC:          B05J2 (-) T = 2 USEC

                                ;KEY SIG:       K3-3 DM=1L  /  K3-4 SBC L

025722  012700  000351          T0351:  MOV     #0351,R0                ;LOAD R0 WITH TEST NO.
025726  013701  025752                  MOV     @#I0351,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
025732  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
025736  012704  077777                  MOV     #077777,R4      ;RESULT S / B = 077777
025742  012712  100000          R0351:  MOV     #100000,(R2)    ;[DEST] = 100000
025746  000257                          CCC                     ;CLEAR CODES
025750  000265                          265                     ;N:C = 0101

025752  005612                  I0351:  SBC     (R2)            ;TEST THE SBC

025754  100403                          BMI     E10351          ;N:C = 0010 ?
025756  001402                          BEQ     E10351
025760  102001                          BVC     E10351
025762  103002                          BCC     A0351

025764  104005                  E10351: ERROR5                  ;SBC FAILED TO ALTER THE CODES PROPERLY
025766  025742                          R0351                   ;ERROR LOOP RETURN
025770  020412                  A0351:  CMP     R4,(R2)         ;RESULT OK ?
025772  001403                          BEQ     00351           ;BR IF YES

025774  011203                          MOV     (R2),R3         ;GET THE WAS DATA
025776  104000                  E20351: ERROR                   ;SBC DELIVERED THE WRONG RESULT
026000  025742                          R0351                   ;ERROR LOOP RETURN

026002  000004                  00351:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***********************************************************************
                                        .SBTTL T0352 SBC DM1 TEST - <N:C> = 1110
                                ; ***********************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [161,266,267,220,211,367,375,016] FC 1,3,9,8

                                ;ACT BUTS:      37[004]100,161 / 33[266]220,220 / 16[367]016,016

                                ;EXEC:          [220]ALUC=LLLLL :[211] D = 000001

                                ;CODES:         [211] SPS=1, [367] SPS=3  /  N:C 0001

                                ;SYNC:          B05J2 (-) T = 0001

                                ;KEY SIG:       K3-3 DM=1L  /  K3-4 SBC L

026004  012700  000352          T0352:  MOV     #0352,R0                ;LOAD R0 WITH TEST NO.
026010  013701  026034                  MOV     @#I0352,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
026014  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
026020  012704  000001                  MOV     #1,R4           ;RESULT S / B = 1
026024  012712  000001          R0352:  MOV     #1,(R2)         ;[DEST] = 1
026030  000257                          CCC                     ;CLEAR CODES
026032  000276                          276                     ;N:C = 1110

026034  005612                  I0352:  SBC     (R2)            ;TEST THE SBC

026036  100403                          BMI     E10352          ;N:C = 0000 ?
026040  001402                          BEQ     E10352
026042  102401                          BVS     E10352
026044  103002                          BCC     A0352

026046  104005                  E10352: ERROR5                  ;SBC FAILED TO ALTER THE CODES PROPERLY
026050  026024                          R0352                   ;ERROR LOOP RETURN
026052  020412                  A0352:  CMP     R4,(R2)         ;RESULT OK ?
026054  001403                          BEQ     00352           ;BR IF YES

026056  011203                          MOV     (R2),R3         ;GET THE WAS DATA
026060  104000                  E20352: ERROR                   ;SBC DELIVERED THE WRONG RESULT
026062  026024                          R0352                   ;ERROR LOOP RETURN

026064  000004                  00352:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***********************************************************************
                                                .SBTTL T0353 SBC DM1 TEST - <N:C> = 0111
                                        ; ***********************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [161,266,267,220,211,367,375,016] FC 1,3,9,8

                                        ;ACT BUTS:      37[004]100,161 / 33[266]220,220 / 16[367]016,016

                                        ;EXEC:          [220]ALUC=LHHLL :[211] D = 177777

                                        ;CODES:         [211] SPS=1, [367] SPS=3  /  N:C = 1001

                                        ;SYNC:          B05J2 (-) T = 2 USEC

                                        ;KEY SIG:       K3-3 DM=1L  /  K3-4 SBC L

026066  012700  000353          T0353:  MOV     #0353,R0                ;LOAD R0 WITH TEST NO.
026072  013701  026114                  MOV     @#I0353,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
026076  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
026102  012704  177777                  MOV     #-1,R4          ;RESULT S / B = 177777
026106  005012                  R0353:  CLR     (R2)            ;[DEST] = 000000
026110  000257                          CCC                     ;CLEAR CODES
026112  000267                          267                     ;N:C = 0111

026114  005612                  I0353:  SBC     (R2)            ;TEST THE SBC

026116  100003                          BPL     E10353          ;N:C = 1001 ?
026120  001402                          BEQ     E10353
026122  102401                          BVS     E10353
026124  103402                          BCS     A0353

026126  104005                  E10353: ERROR5                  ;SBC FAILED TO ALTER THE CODES PROPERLY
026130  026106                          R0353                   ;ERROR LOOP RETURN
026132  020412                  A0353:  CMP     R4,(R2)         ;RESULT OK ?
026134  001403                          BEQ     00353           ;BR IF YES

026136  011203                          MOV     (R2),R3         ;GET THE WAS DATA
026140  104000                  E20353: ERROR                   ;SBC DELIVERED THE WRONG RESULT
026142  026106                          R0353                   ;ERROR LOOP RETURN

026144  000004                  00353:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0354 NEGB - MODE 0 TEST - <N:C> = 0110
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [105,372,361,001] FC 1,7,8

                                ;ACT BUTS:      37[004]100,105  /  31[105]360,361  /  27[372]000,001

                                ;EXEC:          [372]ALUC=LLHHL :[361]D= 000376

                                ;CODES:         [36'']SPS=3       /      N:C=1001

                                ;SYNC:          BOSJ2   (-)     T= 1 USEC

                                ;KEY SIG:       K3-4 NEG L  /  K3-4 OVLAP INSTR H  /  K3-8 CINOO L
                                                ;K3-3 DM=0 L  /  K3-6 BYTE INSTR H

026146  012700  000354          T0354:  MOV     #0354,R0                ;LOAD R0 WITH TEST NO.
026152  013701  026176                  MOV     @#I0354,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
026156  012702  177703                  MOV     #177703,R2      ;DEST ADDR = R3
026162  012704  177776                  MOV     #177776,R4      ;RESULT S / B = 376 (LO BYTE)
026166  012703  177402          R0354:  MOV     #177402,R3      ;[DEST] = 177402
026172  000257                          CCC                     ;CLEAR FLAGS
026174  000266                          266                     ;N:C = 0110

026176  105403                  I0354:  NEGB    R3              ;TEST THE NEGB

026200  100003                          BPL     E10354          ;N:C = 1001
026202  001402                          BEQ     E10354
026204  102401                          BVS     E10354
026206  103402                          BCS     A0354

026210  104000                  E10354: ERROR                   ;NEGB FAILED TO ALTER CODES PROPERLY
026212  026166                          R0354                   ;ERROR LOOP RETURN ADDRESS

026214  020403                  A0354:  CMP     R4,R3           ;CORRECT RESULT ?
026216  001402                          BEQ     00354           ;BR IF YES

026220  104000                  E20354: ERROR                   ;NEGB DELIVERED THE WRONG RESULT
026222  026166                          R0354                   ;ERROR LOOP RETURN ADDRESS

026224  000004                  00354:  SCOPE                   ;CALL THE SCOPE LOOP UTILITY
```

```
                                ; ****************************************************************
                                        .SBTTL T0355 NEGB - MODE 0 TEST - <N:C> = 0011
                                ; ****************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [105,372,361,001] FC 1,7,8

                                ;ACT BUTS:      37[004]100,105  /  31[105]360,361  /  27[372]000,001

                                ;EXEC:          [372]ALUC=LLHHL :[361]D=000400

                                ;CODES:         [361]SPS=3       /      N:C=0100

                                ;SYNC:          B05J2   (-)     T= 1 USEC

                                ;KEY SIG:       K3-4 NEG L  /  K3-4 OVLAP INSTR H  /  K3-8 CINOO L
                                                ;K3-3 DM=0 L  /  K3-6 BYTE INSTR H

026226  012700  000355          T0355:  MOV     #0355,R0                ;LOAD R0 WITH TEST NO.
026232  013701  026256                  MOV     @#I0355,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
026236  012702  177703                  MOV     #177703,R2      ;DEST ADDR = R3
026242  012704  177400                  MOV     #177400,R4      ;RESULT S / B = 000 (LO BYTE)
026246  012703  177400          R0355:  MOV     #177400,R3      ;[DEST] = 177400
026252  000257                          CCC                     ;CLEAR FLAGS
026254  000263                          263                     ;N:C = 0011

026256  105403                  I0355:  NEGB    R3              ;TEST THE NEGB

026260  100403                          BMI     E10355          ;N:C = 0100
026262  001002                          BNE     E10355
026264  102401                          BVS     E10355
026266  103002                          BCC     A0355

026270  104000                  E10355: ERROR                   ;NEGB FAILED TO ALTER CODES PROPERLY
026272  026246                          R0355                   ;ERROR LOOP RETURN ADDRESS

026274  020403                  A0355:  CMP     R4,R3           ;CORRECT RESULT ?
026276  001402                          BEQ     00355           ;BR IF YES

026300  104000                  E20355: ERROR                   ;NEGB DELIVERED THE WRONG RESULT
026302  026246                          R0355                   ;ERROR LOOP RETURN ADDRESS

026304  000004                  00355:  SCOPE                   ;CALL THE SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0356 NEGB - MODE 0 TEST - <N:C> = 1101
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [105,372,361,001] FC 1,7,8

                                ;ACT BUTS:      37[004]100,105  /  31[105]360,361  /  27[372]000,001

                                ;EXEC:          [372]ALUC=LLHHL :[361]D=000200

                                ;CODES:         [361]SPS=3       /      N:C=1011

                                ;SYNC:          B05J2   (-)     T= 1 USEC

                                ;KEY SIG:       K3-4 NEG L  /  K3-4 OVLAP INSTR H  /  K3-8 CINDO L
                                                ;K3-3 DM=0 L  /  K3-6 BYTE INSTR H

026306  012700  000356          T0356:  MOV     #0356,R0                ;LOAD R0 WITH TEST NO.
026312  013701  026336                  MOV     @#10356,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
026316  012702  177703                  MOV     #177703,R2      ;DEST ADDR = R3
026322  012704  177600                  MOV     #177600,R4      ;RESULT S / B = 200 (LO BYTE)
026326  012703  177600          R0356:  MOV     #177600,R3      ;[DEST] = 177600
026332  000257                          CCC                     ;CLEAR FLAGS
026334  000275                          275                     ;N:C = 1101

026336  105403                  I0356:  NEGB    R3              ;TEST THE NEGB

026340  100003                          BPL     E10356          ;N:C = 1011
026342  001402                          BEQ     E10356
026344  102001                          BVC     E10356
026346  103402                          BCS     A0356

026350  104000                  E10356: ERROR                   ;NEGB FAILED TO ALTER CODES PROPERLY
026352  026326                          R0356                   ;ERROR LOOP RETURN ADDRESS

026354  020403                  A0356:  CMP     R4,R3           ;CORRECT RESULT ?
026356  001402                          BEQ     00356           ;BR IF YES

026360  104000                  E20356: ERROR                   ;NEGB DELIVERED THE WRONG RESULT
026362  026326                          R0356                   ;ERROR LOOP RETURN ADDRESS

026364  000004                  00356:  SCOPE                   ;CALL THE SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0357 CLRB - MODE 0 TEST - <N:C> = 1011
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [104,373,361,001] FC 1,7,8

                                ;ACT BUTS:      37[004]100,104  /  31[105]360,361  /  27[372]000,001

                                ;EXEC:          [104]ALUC=HLLHH :[373]D=000000

                                ;CODES:         [373]SPS=1,[361]SPS=3    /      N:C=0100

                                ;SYNC:          B05J2   (-)     T= 1 USEC

                                ;KEY SIG:       K3-4 CLR L  /  K3-6 BYTE INSTR H  /  K3-4 OVLAP INSTR H  /  K3-3 DM=0 L

026366  012700  000357          T0357:  MOV     #0357,R0                ;LOAD R0 WITH TEST NO.
026372  013701  026416                  MOV     @#I0357,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
026376  012702  177703                  MOV     #177703,R2      ;DEST ADDR = R3
026402  012704  177400                  MOV     #177400,R4      ;RESULT S / B = 000 (LO BYTE)
026406  012703  177777          R0357:  MOV     #-1,R3          ;[DEST] = 177777
026412  000257                          CCC                     ;CLEAR FLAGS
026414  000273                          273                     ;N:C = 1011

026416  105003                  I0357:  CLRB    R3              ;TEST THE CLRB

026420  100403                          BMI     E10357          ;N:C = 0100 ?
026422  001002                          BNE     E10357
026424  102401                          BVS     E10357
026426  103002                          BCC     A0357

026430  104000                  E10357: ERROR                   ;CLRB FAILED TO SET CODES PROPERLY
026432  026406                          R0357                   ;ERROR LOOP RETURN ADDRESS

026434  020403                  A0357:  CMP     R4,R3           ;RESULT CORRECT ?
026436  001402                          BEQ     00357           ;BR IF YES

026440  104000                  E20357: ERROR                   ;CLRB DELIVERED THE WRONG RESULT
026442  026406                          R0357                   ;ERROR LOOP RETURN ADDRESS

026444  000004                  00357:  SCOPE                   ;CALL THE SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0360 CLRB - MODE 0 TEST - (N:C) = 0100
                                ; ***************************************************************

                                :MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;RCM SEQ:       [104,373,361,001] FC 1,7,8

                                ;ACT BUTS:      37[004]100,104  /  31[360,361  /  27[373]000,001

                                ;EXEC:          [104]ALUC=HLLHH :[373]D=000000

                                ;CODES:         [373]SPS=1,[361]SPS=3    /      N:C=0100

                                ;SYNC:          BOSJ2   (-)     T= 1 USEC

                                ;KEY SIG:       K3-4 CLR L  /  K3-4 OVLAP INSTR H  /  K3-6 BYTE INSTR H  /  K3-8 CINOO L
                                                ;  K3-3 DM=0 L

026446  012700  000360          T0360:  MOV     #0360,R0                ;LOAD R0 WITH TEST NO.
026452  013701  026476                  MOV     @#T0360,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
026456  012702  177703                  MOV     #177703,R2      ;DEST ADDR = R3
026462  012704  177400                  MOV     #177400,R4      ;RESULT S / B = 000 (LO BYTE)
026466  012703  177777          R0360:  MOV     #-1,R3          ;[DEST] = 177777
026472  000257                          CCC                     ;CLEAR FLAGS
026474  000264                          SEZ                     ;N:C = 0100

026476  105003                  T0360:  CLRB    R3              ;TEST THE CLRB

026500  100403                          BMI     E10360          ;N:C = 0100 ?
026502  001002                          BNE     E10360
026504  102401                          BVS     E10360
026506  103002                          BCC     A0360

026510  104000                  E10360: ERROR                   ;CLRB FAILED TO SET CODES PROPERLY
026512  026466                          R0360                   ;ERROR LOOP RETURN ADDRESS

026514  020403                  A0360:  CMP     R4,R3           ;RESULT CORRECT ?
026516  001402                          BEQ     00360           ;BR IF YES

026520  104000                  E20360: ERROR                   ;CLRB DELIVERED THE WRONG RESULT
026522  026466                          R0360                   ;ERROR LOOP RETURN ADDRESS

026524  000004                  00360:  SCOPE                   ;CALL THE SCOPE LOOP UTILITY
```

```
                                        ; ***************************************************************
                                                .SBTTL T0361 CLRB TEST - DM2 - ODD ADDRESS
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [162,260,267,237,270,222,253,075,374,375,016] FC 1,3,9,8

                                        ;ACT BUTS:      37[004]100,162 / 33[260]220,237 / 34[237]220,222 / 16[374]016,016

                                        ;EXEC:          [222]ALUC=HLLHH :[375] D = 000000

                                        ;CODES:         [253] SP=1, [075] SP=3  /  N:C = 0100

                                        ;SYNC:          BOSJ2 (-) T = 1.9 USEC

                                        ;KEY SIG:       K3-6 BYTE INSTR H  /  K1-6 BADD(1) H  /  K3-7 ODD BYTE H  /  K3-3 DM=2L

026526  012700  000361                  T0361:  MOV     #0361,R0                ;LOAD R0 WITH TEST NO.
026532  013701  026562                          MOV     @#I0361,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
026536  012702  067603                          MOV     #MBUF0+1,R2     ;DEST ADDR = MBUF0+1
026542  012704  000377                          MOV     #377,R4         ;RESULT S / B = 377
026546  012705  067602                          MOV     #MBUF0,R5       ;POINT R5 TO CHECK RESULT
026552  010203                          R0361:  MOV     R2,R3           ;R3 CONTAINS DEST ADDR
026554  012715  177777                          MOV     #-1,(R5)        ;[DEST] = 177777
026560  000257                                  CCC                     ;SCOPE SYNC

026562  105023                          I0361:  CLRB    (R3)+           ;TEST THE CLRB

026564  022703  067604                          CMP     #MBUF0+2,R3     ;DID DEST REG GET INCREMENTED ?
026570  001402                                  BEQ     A0361           ;BR IF YES

026572  104005                          E10361: ERROR5                  ;CLRB FAILED TO UPDATE DEST REG
026574  026552                                  R0361                   ;ERROR LOOP RETURN ADDRESS

026576  020415                          A0361:  CMP     R4,(R5)         ;CORRECT RESULT ?
026600  001403                                  BEQ     00361           ;BR IF YES

026602  011503                                  MOV     (R5),R3         ;GET THE WAS DATA
026604  104000                          E20361: ERROR                   ;CLRB DELIVERED WRONG RESULT
026606  026552                                  R0361                   ;ERROR LOOP RETURN ADDRESS

026610  000004                          00361:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***********************************************************************
                                                .SBTTL T0362 CLRB TEST - DM1 - ODD ADDRESS
                                        ; ***********************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [161,266,267,237,270,222,253,075,374,375,016] FC 1,3,9,8

                                        ;ACT BUTS:      37[004]100,161 / 33[266]220,237 / 34[237]220,222 / 16[374]016,016

                                        ;EXEC:          [222]ALUC=HLLHH :[375] D = 000000

                                        ;CODES:         [253] SPS=1, [075] SPS=3  /  N:C = 0100

                                        ;SYNC:          B05J2 (-) T = 1.9 USEC

                                        ;KEY SIG:       K3-6 BYTE INSTR H  /  K1-6 BADD (1) H  /  K3-7 ODD BYTE H  /  K3-3 DM=2L

026612  012700  000362                  T0362:  MOV     #0362,R0                ;LOAD R0 WITH TEST NO.
026616  013701  026646                          MOV     @#T0362,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
026622  012702  067603                          MOV     #MBUF0+1,R2     ;DEST ADDR = MBUF0+1
026626  012704  000377                          MOV     #377,R4         ;RESULT S / B = 377
026632  012705  067602                          MOV     #MBUF0,R5       ;POINT R5 TO CHECK RESULT
026636  010203                          R0362:  MOV     R2,R3           ;R3 CONTAINS DEST ADDR
026640  012715  177777                          MOV     #-1,(R5)        ;[DEST] = 177777
026644  000257                                  CCC                     ;SCOPE SYNC

026646  105013                          T0362:  CLRB    (R3)            ;TEST THE CLRB

026650  020415                                  CMP     R4,(R5)         ;CORRECT RESULT ?
026652  001403                                  BEQ     00362           ;BR IF YES

026654  011503                                  MOV     (R5),R3         ;GET THE WAS DATA
026656  104000                          E0362:  ERROR                   ;CLRB DELIVERED WRONG RESULT
026660  026636                                  R0362                   ;ERROR LOOP RETURN ADDRESS

026662  000004                          00362:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***********************************************************************
                                                .SBTTL T0363 CLRB TEST - DM2 - EVEN ADDRESS
                                        ; ***********************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [162,260,267,220,211,367,375,016] FC 1,3,9,8

                                        ;ACT BUTS:      37[004]100,162 / 33[260]220,220 / 16[367]016,016

                                        ;EXEC:          [220]ALUC=HLLHH :[211] D = 000000

                                        ;CODES:         [211] SPS=1, [367] SPS=3  /  N:C = 0100

                                        ;SYNC:          BOSJ2 (-) T = 1.9 USEC

                                        ;KEY SIG:       K3-6 BYTE INSTR H  /  K3-3 DM=1L  /  K3-4 CLR L

026664  012700  000363                  T0363:  MOV     #0363,R0                ;LOAD R0 WITH TEST NO.
026670  013701  026714                          MOV     @#T0363,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
026674  012702  067602                          MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
026700  012704  177400                          MOV     #177400,R4      ;RESULT S / B = 177400
026704  010203                          R0363:  MOV     R2,R3           ;R3 CONTAINS DEST ADDR
026706  012712  177777                          MOV     #-1,(R2)        ;[DEST] = 177777
026712  000257                                  CCC                     ;SCOPE SYNC

026714  105023                          T0363:  CLRB    (R3)+           ;TEST THE CLRB

026716  022703  067603                          CMP     #MBUF0+1,R3     ;DID DEST REG GET INCREMENTED ?
026722  001402                                  BEQ     A0363           ;BR IF YES

026724  104005                          E10363: ERROR5                  ;CLRB FAILED TO UPDATE DEST REG
026726  026704                                  R0363                   ;ERROR LOOP RETURN ADDRESS

026730  020412                          A0363:  CMP     R4,(R2)         ;CORRECT RESULT ?
026732  001403                                  BEQ     00363           ;BR IF YES

026734  011203                                  MOV     (R2),R3         ;GET THE WAS DATA
026736  104000                          E20363: ERROR                   ;CLRB DELIVERED WRONG RESULT
026740  026704                                  R0363                   ;ERROR LOOP RETURN ADDRESS

026742  000004                          00363:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***********************************************************************
                                        .SBTTL T0364 CLRB TEST - DM1 - EVEN ADDRESS
                                ; ***********************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [161,266,267,220,211,367,375,016] FC 1,3,9,8

                                ;ACT BUTS:      37[004]100,161 / 33[266]220,220 / 16[367]016,016

                                ;EXEC:          [220]ALUC=HLLHH :[367] D = 000000

                                ;CODES:         [211] SPS=1, [367] SPS=3  /  N:C = 0100

                                ;SYNC:          BOSJ2 (-) T = 1.8 USEC

                                ;KEY SIG:       K3-6 BYTE INSTR H

026744  012700  000364          T0364:  MOV     #0364,R0                ;LOAD R0 WITH TEST NO.
026750  013701  026774                  MOV     @#I0364,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
026754  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
026760  012704  177400                  MOV     #177400,R4      ;RESULT S / B = 177400
026764  010203                  R0364:  MOV     R2,R3           ;R3 CONTAINS DEST ADDR
026766  012712  177777                  MOV     #-1,(R2)        ;[DEST] = 177777
026772  000257                          CCC                     ;SCOPE SYNC

026774  105013                  I0364:  CLRB    (R3)            ;TEST THE CLRB

026776  020412                          CMP     R4,(R2)         ;CORRECT RESULT ?
027000  001403                          BEQ     00364           ;BR IF YES

027002  011203                          MOV     (R2),R3         ;GET THE WAS DATA
027004  104000                  E0364:  ERROR                   ;CLRB DELIVERED WRONG RESULT
027006  026764                          R0364                   ;ERROR LOOP RETURN ADDRESS

027010  000004                  00364:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***************************************************************
                                                .SBTTL T0365 NEGB TEST - DM2 - ODD ADDRESS
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [162,260,267,237,270,223,253,075,374,375,016] FC 1,3,9,8

                                        ;ACT BUTS:      37[004]100,162 / 33[260]220,237 / 34[237]220,223 / 16[374]016,016

                                        ;EXEC:          [223]ALUC=LLHHL :[375] D = C00400

                                        ;CODES:         [253] SPS=1, [075] SPS=3  /  N:C = 0001

                                        ;SYNC:          B05J2 (-) T = 1.9 USEC

                                        ;KEY SIG:       K3-6 BYTE INSTR H  /  K1-6 BADD(1) H  /  K3-7 ODD BYTE H  /  K3-9 CINOD

027012  012700  000365          T0365:  MOV     #0365,R0                ;LOAD R0 WITH TEST NO.
027016  013701  027046                  MOV     @#I0365,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
027022  012702  067603                  MOV     #MBUF0+1,R2     ;DEST ADDR = MBUF0+1
027026  012704  000777                  MOV     #777,R4         ;RESULT S / B = 777
027032  012705  067602                  MOV     #MBUF0,R5       ;POINT R5 TO CHECK RESULT
027036  010203          R0365:  MOV     R2,R3           ;R3 CONTAINS DEST ADDR
027040  012715  177777                  MOV     #-1,(R5)        ;[DEST] = 177777
027044  000257                          CCC                     ;SCOPE SYNC

027046  105423          I0365:  NEGB    (R3)+           ;TEST THE NEGB

027050  022703  067604                  CMP     #MBUF0+2,R3     ;DID DEST REG GET INCREMENTED ?
027054  001402                          BEQ     A0365           ;BR IF YES

027056  104005          E10365: ERROR5                          ;NEGB FAILED TO UPDATE DEST REG
027060  027036                  R0365                           ;ERROR LOOP RETURN ADDRESS

027062  020415          A0365:  CMP     R4,(R5)         ;CORRECT RESULT ?
027064  001403                          BEQ     00365           ;BR IF YES

027066  011503                          MOV     (R5),R3         ;GET THE WAS DATA
027070  104000          E20365: ERROR                           ;NEGB DELIVERED WRONG RESULT
027072  027036                  R0365                           ;ERROR LOOP RETURN ADDRESS

027074  000004          00365:  SCOPE                           ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***************************************************************
                                                .SBTTL T0366 NEGB TEST - DM1 - ODD ADDRESS
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [161,266,267,237,270,223,253,075,374,375,016] FC 1,3,9,8

                                        ;ACT BUTS:      37[004]100,161 / 33[266]220,237 / 34[237]220,223 / 16[374]016,016

                                        ;EXEC:          [223]ALUC=LLHHL :[375] D = 000400

                                        ;CODES:         [253] SPS=1, [075] SPS=3  /  N:C = 0001

                                        ;SYNC:          BOSJ2 (-) T = 1.9 USEC

                                        ;KEY SIG:       K3-6 BYTE INSTR H  /  K1-6 BADD (1) H  /  K3-7 ODD BYTE H  /  K3-8 CINOD

027076  012700  000366                  T0366:  MOV     #0366,R0                ;LOAD R0 WITH TEST NO.
027102  013701  027132                          MOV     @#I0366,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
027106  012702  067603                          MOV     #MBUF0+1,R2     ;DEST ADDR = MBUF0+1
027112  012704  000777                          MOV     #777,R4         ;RESULT S / B = 777
027116  012705  067602                          MOV     #MBUF0,R5       ;POINT R5 TO CHECK RESULT
027122  010203                          R0366:  MOV     R2,R3           ;R3 CONTAINS DEST ADDR
027124  012715  177777                          MOV     #-1,(R5)        ;[DEST] = 177777
027130  000257                                  CCC                     ;SCOPE SYNC

027132  105413                          I0366:  NEGB    (R3)            ;TEST THE NEGB

027134  020415                                  CMP     R4,(R5)         ;CORRECT RESULT ?
027136  001403                                  BEQ     00366           ;BR IF YES

027140  011503                                  MOV     (R5),R3         ;GET THE WAS DATA
027142  104000                          E0366:  ERROR                   ;NEGB DELIVERED WRONG RESULT
027144  027122                                  R0366                   ;ERROR LOOP RETURN ADDRESS

027146  000004                          00366:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***************************************************************
                                                .SBTTL T0367 NEGB TEST - DM2 - EVEN ADDRESS
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [162,260,267,221,367,375,016] FC 1,3,9,8

                                        ;ACT BUTS:      37[004]100,162 / 33[260]220,221 / 16[367]016,016

                                        ;EXEC:          [221]ALUC=LLHHL :[367] D = 000001

                                        ;CODES:         [367] SPS=3  /  N:C = 0001

                                        ;SYNC:          B05J2 (-) T = 1.8 USEC

                                        ;KEY SIG:       K3-6 BYTE INSTR H  /  K3-8 CINOO L  /  K3-4 NEG L  /  K3-3 DM=2L

027150  012700  000367                  T0367:  MOV     #0367,R0                ;LOAD R0 WITH TEST NO.
027154  013701  027200                          MOV     @#I0367,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
027160  012702  067602                          MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
027164  012704  177401                          MOV     #177401,R4      ;RESULT S / B = 177401
027170  010203                          R0367:  MOV     R2,R3           ;R3 CONTAINS DEST ADDR
027172  012712  177777                          MOV     #-1,(R2)        ;[DEST] = 177777
027176  000257                                  CCC                     ;SCOPE SYNC

027200  105423                          I0367:  NEGB    (R3)+           ;TEST THE NEGB

027202  022703  067603                          CMP     #MBUF0+1,R3     ;DID DEST REG GET INCREMENTED ?
027206  001402                                  BEQ     A0367           ;BR IF YES

027210  104005                          E10367: ERROR5                  ;NEGB FAILED TO UPDATE DEST REG
027212  027170                                  R0367                   ;ERROR LOOP RETURN ADDRESS

027214  020412                          A0367:  CMP     R4,(R2)         ;CORRECT RESULT ?
027216  001403                                  BEQ     00367           ;BR IF YES

027220  011203                                  MOV     (R2),R3         ;GET THE WAS DATA
027222  104000                          E20367: ERROR                   ;NEGB DELIVERED WRONG RESULT
027224  027170                                  R0367                   ;ERROR LOOP RETURN ADDRESS

027226  000004                          00367:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0370 NEGB TEST - DM1 - EVEN ADDRESS
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [161,266,267,221,367,375,016] FC 1,3,9,8

                                ;ACT BUTS:      37[004]100,161 / 33[266]220,221 / 16[367]016,016

                                ;EXEC:          [221]ALUC=LLHHL :[367] D = 000001

                                ;CODES:         [367] SPS=3  /  N:C = 0001

                                ;SYNC:          B05J2 (-) T = 1.8 USEC

                                ;KEY SIG:       K3-6 BYTE INSTR H  /  K3-8 CINOO L  /  K3-4 NEG L  /  K3-3 DM=2L

027230  012700  000370          T0370:  MOV     #0370,R0                ;LOAD R0 WITH TEST NO.
027234  013701  027260                  MOV     @#I0370,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
027240  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
027244  012704  177401                  MOV     #177401,R4      ;RESULT S / B = 177401
027250  010203                  R0370:  MOV     R2,R3           ;R3 CONTAINS DEST ADDR
027252  012712  177777                  MOV     #-1,(R2)        ;[DEST] = 177777
027256  000257                          CCC                     ;SCOPE SYNC

027260  105413                  I0370:  NEGB    (R3)            ;TEST THE NEGB

027262  020412                          CMP     R4,(R2)         ;CORRECT RESULT ?
027264  001403                          BEQ     00370           ;BR IF YES

027266  011203                          MOV     (R2),R3         ;GET THE WAS DATA
027270  104000                  E0370:  ERROR                   ;NEGB DELIVERED WRONG RESULT
027272  027250                          R0370                   ;ERROR LOOP RETURN ADDRESS

027274  000004                  00370:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0371 ADD TEST - SM0,DM0 - <N:C> = 1010
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [102,364,300,001] FC 1,7,8

                                ;ACT BUTS:      37[004]100,102 / 31[102]360,360 / 27[364]000,001

                                ;EXEC:          [364]ALUC=LHLLH :[360] D = 000000

                                ;CODES:         [360] SPS=3  /  N:C = 0101

                                ;SYNC:          B05J2 (-) T = 1 USEC

                                ;KEY SIG:       K3-3 ADD+SUB L  /  K3-3 SM=0L  /  K3-3 DM=0L

027276  012700  000371          T0371:  MOV     #0371,R0                ;LOAD R0 WITH TEST NO.
027302  013701  027330                  MOV     @#I0371,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
027306  012702  177703                  MOV     #177703,R2      ;DEST ADDR = R3
027312  005004                          CLR     R4              ;RESULT S / B = 000000
027314  012705  177777                  MOV     #-1,R5          ;SRC OPR = 177777
027320  012703  000001          R0371:  MOV     #+1,R3          ;[DEST0372
027324  000257                          CCC                     ;CLEAR FLAGS
027326  000272                          272                     ;N:C = 1010

027330  060503                  I0371:  ADD     R5,R3           ;TEST THE ADD

027332  100403                          BMI     E10371          ;N:C = 0101
027334  001002                          BNE     E10371
027336  102401                          BVS     E10371
027340  103402                          BCS     A0371

027342  104005                  E10371: ERROR5                  ;ADD FAILED TO ALTER CODES PROPERLY
027344  027320                          R0371                   ;ERROR LOOP RETURN ADDRESS

027346  020403                  A0371:  CMP     R4,R3           ;CORRECT RESULT ?
027350  001402                          BEQ     00371           ;BR IF YES

027352  104000                  E20371: ERROR                   ;ADD DELIVERED THE WRONG RESULT
027354  027320                          R0371                   ;ERROR LOOP RETURN ADDRESS

027356  000004                  00371:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0372 ADD TEST - SMO,DMO - <N:C> = 0101
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [102,364,360,001] FC 1,7,8

                                ;ACT BUTS:      37[004]100,102 / 31[102]360,360 / 27[364]000,001

                                ;EXEC:          [364]ALUC=LHLLH :[360] D = 100006

                                ;CODES:         [360] SPS=3  /  N:C = 1010

                                ;SYNC:          B05J2 (-) T = 1 USEC

                                ;KEY SIG:       K3-3 ADD+SUB L  /  K3-3 SM=0L  /  K3-3 DM=0L

027360  012700  000372          T0372:  MOV     #0372,R0                ;LOAD R0 WITH TEST NO.
027364  013701  027414                  MOV     @#I0372,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
027370  012702  177703                  MOV     #177703,R2      ;DEST ADDR = R3
027374  012704  100006                  MOV     #100006,R4      ;RESULT S / B = 100006
027400  012705  077777                  MOV     #77777,R5       ;SRC OPR = 77777
027404  012703  000007          R0372:  MOV     #7,R3           ;[DEST] = 7
027410  000257                          CCC                     ;CLEAR FLAGS
027412  000265                          265                     ;N:C = 0101

027414  060503                  I0372:  ADD     R5,R3           ;TEST THE ADD

027416  100003                          BPL     E10372          ;N:C = 1010
027420  001402                          BEQ     E10372
027422  102001                          BVC     E10372
027424  103002                          BCC     A0372

027426  104005                  E10372: ERROR5                  ;ADD FAILED TO ALTER CODES PROPERLY
027430  027404                          R0372                   ;ERROR LOOP RETURN ADDRESS

027432  020403                  A0372:  CMP     R4,R3           ;CORRECT RESULT ?
027434  001402                          BEQ     00372           ;BR IF YES

027436  104000                  E20372: ERROR                   ;ADD DELIVERED THE WRONG RESULT
027440  027404                          R0372                   ;ERROR LOOP RETURN ADDRESS

027442  000004                  00372:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***********************************************************************
                                        .SBTTL T0373 ADD SM1,DM0 TEST
                                ; ***********************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [141,247,250,120,371,360,000] FC 1,2,8

                                ;ACT BUTS:      37[004]100,141 / 35[247]120,120 / 31[120]360,360 / 27[371]000,000

                                ;EXEC:          [371]ALUC=LHLLH :[360] D = #DWTA

                                ;CODES:         [360] SPS=3

                                ;SYNC:          B05J2 (-) T = 2 USEC

                                ;KEY SIG:       K3-3 ADD+SUB L  /  K3-3 DM=0L  / K3-3 SM=1L

027444  012700  000373          T0373:  MOV     #0373,R0                ;LOAD R0 WITH THE TEST NO.
027450  013701  027474                  MOV     @#I0373,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
027454  012702  177703                  MOV     #177703,R2      ;DEST ADDR = R3
027460  012704  067612                  MOV     #DWTA,R4        ;RESULT S / B = #DWTA
027464  012705  067566          R0373:  MOV     #ATA,R5         ;SOURCE ADDR = ATA
027470  005003                          CLR     R3              ;[DEST] = 0
027472  000257                          CCC                     ;SCOPE SYNC

027474  061503                  I0373:  ADD     (R5),R3         ;TEST THE ADD - SM1,DM0

027476  020403                          CMP     R4,R3           ;RESULT = #DWTA?
027500  001402                          BEQ     A0373           ;BR IF YES

027502  104000                  E10373: ERROR                   ;ADD DELIVERED WRONG RESULT
027504  027464                          R0373                   ;ERROR LOOP RETURN

027506  022705  067566          A0373:  CMP     #ATA,R5         ;DID ADD CHANGE REG.
027512  001402                          BEQ     00373           ;BR IF NOT

027514  104005                  E20373: ERROR5                  ;REG GOT MODIFIED
027516  027464                          R0373                   ;ERROR LOOP RETURN

027520  000004                  00373:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0374 ADD SM2,DMO TEST
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [142,240,250,120,371,360,000] FC 1,2,8

                                ;ACT BUTS:      37[004]100,142 / 35[240]120,120 / 31[120]360,360 / 27[371]000,000

                                ;EXEC:          [371]ALUC=LHLLH :[360] D = #DWTA

                                ;CODES:         [360] SPS=3

                                ;SYNC:          B05J2 (-) T = USEC

                                ;KEY SIG:       K3-3 ADD+SUB L  /  K3-3 DM=0L  /  K3-3 SM=2L  /  K5-5 BCON (1+2) H

027522  012700  000374          T0374:  MOV     #0374,R0                ;LOAD R0 WITH THE TEST NO.
027526  013701  027564                  MOV     @#I0374,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
027532  032737  000200  066642          BIT     #200,@#BPTLOC   ;BREAKPOINT HALT SET ??
027540  001401                          BEQ     .+4             ;BR IF NOT
027542  000000                          HALT                    ;BREAK- DEPRESS CONTINUE TO RESTART
027544  012702  177703                  MOV     #177703,R2      ;DEST ADDR = R3
027550  012704  067612                  MOV     #DWTA,R4        ;RESULT S / B = #DWTA
027554  012705  067566          R0374:  MOV     #ATA,R5         ;SOURCE ADDR = ATA
027560  005003                          CLR     R3              ;[DEST] = 0
027562  000257                          CCC                     ;SCOPE SYNC

027564  062503                  I0374:  ADD     (R5)+,R3        ;TEST THE ADD - SM2,DMO

027566  020403                          CMP     R4,R3           ;RESULT = #DWTA
027570  001402                          BEQ     A0374           ;BR IF YES

027572  104000                  E10374: ERROR                   ;ADD DELIVERED WRONG RESULT
027574  027554                          R0374                   ;ERROR LOOP RETURN

027576  022705  067570          A0374:  CMP     #ATA+2,R5       ;DID ADD AUTO INCREMENT SOURCE REG?
027602  001402                          BEQ     00374           ;BR IF YES

027604  104005                  E20374: ERROR5                  ;ADD FAILED TO UPDATE SOURCE REG.
027606  027554                          R0374                   ;ERROR LOOP RETURN

027610  000004                  00374:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***************************************************************
                                                .SBTTL T0375 ADD SM3,DMO TEST
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [143,245,246,247,250,120,371,360,000] FC 1,2,8

                                        ;ACT BUTS:      37[004]100,143 / 35[247]120,120 / 31[120]360,360 / 27[371]000,000

                                        ;EXEC:          [371]ALUC=LHLLH :[360] D = #DWTA

                                        ;CODES:         [360] SPS=3

                                        ;SYNC:          B05J2 (-) T = 2.75 USEC

                                        ;KEY SIG:       K3-3 ADD+SUB L  /  K3-3 DM=0L  /  K3-3 SM=2L  /  K5-5 BC01 H

027612  012700  000375                  T0375:  MOV     #0375,R0                ;LOAD R0 WITH THE TEST NO.
027616  013701  027646                          MOV     @#I0375,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
027622  012702  177703                          MOV     #177703,R2      ;DEST ADDR = R3
027626  012704  067612                          MOV     #DWTA,R4        ;RESULT S / B = #DWTA
027632  012705  067576                  R0375:  MOV     #ATA+10,R5      ;R5 POINTS TO SOURCE ADDR
027636  010437  067602                          MOV     R4,@#MBUF0      ;[SOURCE] = #DWTA
027642  005003                                  CLR     R3              ;[DEST] = 0
027644  000257                                  CCC                     ;SCOPE SYNC

027646  063503                          I0375:  ADD     @(R5)+,R3       ;TEST THE ADD - SM3,DMO

027650  020437  067602                          CMP     R4,@#MBUF0      ;RESULT = #DWTA?
027654  001402                                  BEQ     A0375           ;BR IF YES

027656  104000                          E10375: ERROR                   ;ADD DELIVERED WRONG RESULT
027660  027632                                  R0375                   ;ERROR LOOP RETURN

027662  022705  067600                  A0375:  CMP     #ATA+12,R5      ;DID ADD AUTO INCREMENT SOURCE REG?
027666  001402                                  BEQ     00375           ;BR IF YES

027670  104005                          E20375: ERROR5                  ;ADD FAILED TO UPDATE SOURCE REG.
027672  027632                                  R0375                   ;ERROR LOOP RETURN

027674  000004                          00375:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0376 ADD SM4,DMO TEST
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [144,240,250,120,371,360,000] FC 1,2,8

                                ;ACT BUTS:      37[004]100,144 / 35[240]120,120 / 31[120]360,360 / 27[371]000,000

                                ;EXEC:          [371]ALUC=LHLLH :[360] D = #DWTA

                                ;CODES:         [360] SPS=3

                                ;SYNC:          B05J2 (-) T = 2 USEC

                                ;KEY SIG:       K3-3 ADD+SUB L  /  K3-3 DM=0L  /  K3-3 SM=4L  /  K5-5 BCON (1+2) H

027676  012700  000376          T0376:  MOV     #0376,R0                ;LOAD R0 WITH THE TEST NO.
027702  013701  027726                  MOV     @#I0376,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
027706  012702  177703                  MOV     #177703,R2      ;DEST ADDR = R3
027712  012704  067612                  MOV     #DWTA,R4        ;RESULT S / B = #DWTA
027716  012705  067570          R0376:  MOV     #ATA+2,R5       ;SOURCE ADDR = ATA
027722  005003                          CLR     R3              ;[DEST] = 0
027724  000257                          CCC                     ;SCOPE SYNC

027726  064503                  I0376:  ADD     -(R5),R3        ;TEST THE ADD - SM4,DMO

027730  020403                          CMP     R4,R3           ;RESULT = #DWTA?
027732  001402                          BEQ     A0376           ;BR IF YES

027734  104000                  E10376: ERROR                   ;ADD DELIVERED WRONG RESULT
027736  027716                          R0376                   ;ERROR LOOP RETURN

027740  022705  067566          A0376:  CMP     #ATA,R5         ;DID SOURCE REG GET DECREMENTED?
027744  001402                          BEQ     00376           ;BR IF YES

027746  104005                  E20376: ERRORS                  ;ADD FAILED TO UPDATE SOURCE REG
027750  027716                          R0376                   ;ERROR LOOP RETURN

027752  000004                  00376:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***********************************************************************
                                                .SBTTL T0377 ADD SM5,DMO TEST
                                        ; ***********************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [145,245,246,247,250,120,371,360,000] FC 1,2,8

                                        ;ACT BUTS:      37[004]100,145 / 35[247]120,120 / 31[120]360,360 / 27[371]000,000

                                        ;EXEC:          [371]ALUC=LHLLH :[360] D = #DWTA

                                        ;CODES:         [360] SPS=3

                                        ;SYNC:          B05J2 (-) T = 2.75 USEC

                                        ;KEY SIG:       K3-3 ADD+SUB L  /  K3-3 DM=0L  /  K3-3 SM=5L  /  K5-5 BC01 H

027754  012700  000377                  T0377:  MOV     #0377,R0                ;LOAD R0 WITH THE TEST NO.
027760  013701  030010                          MOV     @#I0377,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
027764  012702  177703                          MOV     #177703,R2      ;DEST ADDR = R3
027770  012704  067612                          MOV     #DWTA,R4        ;RESULT S / B = #DWTA
027774  012705  067600                  R0377:  MOV     #ATA+12,R5      ;R5 POINTS TO SOURCE ADDR
030000  010437  067602                          MOV     R4,@#MBUF0      ;[SOURCE] = #DWTA
030004  005003                                  CLR     R3              ;[DEST] = 0
030006  000257                                  CCC                     ;SCOPE SYNC

030010  065503                          I0377:  ADD     @-(R5),R3       ;TEST THE ADD - SM5,DMO

030012  020437  067602                          CMP     R4,@#MBUF0      ;RESULT = #DWTA?
030016  001402                                  BEQ     A0377           ;BR IF YES

030020  104000                          E10377: ERROR                   ;ADD DELIVERED WRONG RESULT
030022  027774                                  R0377                   ;ERROR LOOP RETURN

030024  022705  067576                  A0377:  CMP     #ATA+10,R5      ;DID ADD DECREMENT SOURCE REG?
030030  001402                                  BEQ     00377           ;BR IF YES

030032  104005                          E20377: ERROR5                  ;ADD FAILED TO UPDATE SOURCE REG.
030034  027774                                  R0377                   ;ERROR LOOP RETURN

030036  000004                          00377:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***********************************************************************
                                                .SBTTL T0400 ADD SM6,DM0 TEST
                                        ; ***********************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [146,241,242,247,250,120,371,360,000] FC 1,2,8

                                        ;ACT BUTS:      37[004]100,146 / 35[247]120,120 / 31[120]360,360 / 27[371]000,000

                                        ;EXEC:          [371]ALUC=LHLLH :[360] D = #MBUF0

                                        ;CODES:         [360] SPS=3

                                        ;SYNC:          BOSJ2 (-) T = 2.5 USEC

                                        ;KEY SIG:       K3-3 ADD+SUB L  /  K3-3 DM=0L  /  K3-3 SM=6L  /  K3-4 OVLAP CYCLE L

030040  012700  000400                  T0400:  MOV     #0400,R0                ;LOAD R0 WITH THE TEST NO.
030044  013701  030070                          MOV     @#I0400,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
030050  012703  177703                          MOV     #177703,R3      ;DEST ADDR = R3
030054  012704  067602                          MOV     #MBUF0,R4       ;RESULT S / B = MBUF0
030060  012705  067566                  R0400:  MOV     #ATA,R5         ;BASE SOURCE ADDR = ATA
030064  005003                                  CLR     R3              ;[DEST] = 0
030066  000257                                  CCC                     ;SCOPE SYNC

030070  066503  000010                  I0400:  ADD     10(R5),R3       ;TEST THE ADD - SM6,DM0

030074  020403                                  CMP     R4,R3           ;RESULT =MBUF0?
030076  001402                                  BEQ     00400           ;BR IF YES

030100  104000                          E0400:  ERROR                   ;ADD DELIVERED WRONG RESULT
030102  030060                                  R0400                   ;ERROR LOOP RETURN

030104  000004                          00400:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0401 ADD SM7,DMO TEST
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [147,243,244,245,246,247,250,120,371,360,000] FC 1,2,8

                                ;ACT BUTS:      37[004]100,147 / 35[247]120,120 / 31[120]360,360 / 27[371]000,000

                                ;EXEC:          [371]ALUC=LHLLH :[360] D = #DWTA

                                ;CODES:         [360] SPS=3

                                ;SYNC:          BOSJ2 (-) T = 3.5 USEC

                                ;KEY SIG:       K3-3 ADD+SUB L  /  K3-3 DM=0L  /  K3-3 SM=7L  /  K3-4 OVLAP CYCLE L

030106  012700  000401          T0401:  MOV     #0401,R0                ;LOAD R0 WITH THE TEST NO.
030112  013701  030142                  MOV     @#I0401,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
030116  012702  177703                  MOV     #177703,R2      ;DEST ADDR = R3
030122  012704  067612                  MOV     #DWTA,R4        ;RESULT S / B = #DWTA
030126  012705  067566          R0401:  MOV     #ATA,R5         ;BASE SOURCE ADDR = ATA
030132  010437  067602                  MOV     R4,@#MBUF0      ;[SOURCE] = #DWTA
030136  005003                          CLR     R3              ;[DEST] = 0
030140  000257                          CCC                     ;SCOPE SYNC

030142  067503  000010          I0401:  ADD     @10(R5),R3      ;TEST THE ADD - SM7,DMO

030146  020403                          CMP     R4,R3           ;RESULT = #DWTA?
030150  001402                          BEQ     00401           ;BR IF YES

030152  104000                  E0401:  ERROR                   ;ADD DELIVERED WRONG RESULT
030154  030126                          R0401                   ;ERROR LOOP RETURN

030156  000004                  00401:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***********************************************************************
                                        .SBTTL T0402 ADD SM1,DM1 TEST
                                ; ***********************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [141,247,250,161,266,267,225,367,375,016] FC 1,2,3,8

                                ;ACT BUTS:      37[004]100,141 / 35[247]120,161 / 33[266]220,225 / 16[367]016,016

                                ;EXEC:          [225]ALUC=LHLLH :[367] D = #DWTA

                                ;CODES:         [367] SPS=3

                                ;SYNC:          B05J2 (-) T = 2.6 USEC

                                ;KEY SIG:       K3-3 ADD+SUB L  /  K3-3 DM=1L  /  K3-3 SM=1L

030160  012700  000402          T0402:  MOV     #0402,R0                ;LOAD R0 WITH THE TEST NO.
030164  013701  030210                  MOV     @#I0402,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
030170  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
030174  012704  067612                  MOV     #DWTA,R4        ;RESULT S / B = #DWTA
030200  012705  067566          R0402:  MOV     #ATA,R5         ;SOURCE ADDR = ATA
030204  005012                          CLR     (R2)            ;[DEST] = 0
030206  000257                          CCC                     ;SCOPE SYNC

030210  061512                  I0402:  ADD     (R5),(R2)       ;TEST THE ADD - SM1,DM1

030212  020412                          CMP     R4,(R2)         ;RESULT = #DWTA?
030214  001403                          BEQ     00402           ;BR IF YES

030216  011203                          MOV     (R2),R3         ;GET WAS DATA
030220  104000                  E0402:  ERROR                   ;ADD DELIVERED WRONG RESULT
030222  030200                          R0402                   ;ERROR LOOP RETURN

030224  000004                  00402:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***************************************************************
                                                .SBTTL T0403 ADD SM2,DM1 TEST
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [142,240,250,161,266,267,225,367,375,016] FC 1,2,3,8

                                        ;ACT BUTS:      37[004]100,142 / 35[240]120,161 / 35[266]220,225 / 16[367]016,016

                                        ;EXEC:          [225]ALUC=L!LLH :[367] D = #DWTA

                                        ;CODES:         [367] SPS=3

                                        ;SYNC:          B05J2  (-) T = 2.7 USEC

                                        ;KEY SIG:       K3-3 ADD+SUB L  /  K3-3 SM=1L  /  K3-3 DM=1L

030226  012700  000403                  T0403:  MOV     #0403,R0                ;LOAD R0 WITH THE TEST NO.
030232  013701  030256                          MOV     @#I0403,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
030236  012702  067602                          MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
030242  012704  067612                          MOV     #DWTA,R4        ;RESULT S / B = #DWTA
030246  012705  067566                  R0403:  MOV     #ATA,R5         ;SOURCE ADDR = ATA
030252  005012                                  CLR     (R2)            ;[DEST] = 0
030254  000257                                  CCC                     ;SCOPE SYNC

030256  062512                          I0403:  ADD     (R5)+,(R2)      ;TEST THE ADD - SM2,DM1

030260  020412                                  CMP     R4,(R2)         ;RESULT = #DWTA?
030262  001403                                  BEQ     C0403           ;BR IF YES

030264  011203                                  MOV     (R2),R3         ;GET WAS DATA
030266  104000                          E0403:  ERROR                   ;ADD DELIVERED WRONG RESULT
030270  030246                                  R0403                   ;ERROR LOOP RETURN

030272  000004                          00403:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***********************************************************************
                                        .SBTTL T0404 ADD SM1,DM2 TEST
                                ; ***********************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [141,247,250,162,260,267,225,367,375,016] FC 1,2,3,8

                                ;ACT BUTS:      37[004]100,141 / 35[247]120,162 / 33[260]220,225 / 16[367]016,016

                                ;EXEC:          [225]ALUC=LHLLH :[367] D = #DWTA

                                ;CODES:         [367] SPS=3

                                ;SYNC:          B05J2 (-) T = 2.7 USEC

                                ;KEY SIG:       K3-3 ADD+SUB L  /  K3-3 DM=2L  /  K3-3 SM=1L

030274  012700  000404          T0404:  MOV     #0404,R0                ;LOAD R0 WITH THE TEST NO.
030300  013701  030326                  MOV     @#I0404,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
030304  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
030310  012704  067612                  MOV     #DWTA,R4        ;RESULT S / B = #DWTA
030314  012705  067566          R0404:  MOV     #ATA,R5         ;SOURCE ADDR = ATA
030320  010203                          MOV     R2,R3           ;[R3] = DEST ADDR
030322  005012                          CLR     (R2)            ;[DEST] = 0
030324  000257                          CCC                     ;SCOPE SYNC

030326  061523                  I0404:  ADD     (R5),(R3)+      ;TEST THE ADD - SM1,DM2

030330  020412                          CMP     R4,(R2)         ;RESULT = #DWTA?
030332  001407                          BEQ     A0404           ;BR IF YES

030334  010337  067606                  MOV     R3,@#MBUF1      ;SAVE UPDATED DEST ADDR
030340  011203                          MOV     (R2),R3         ;GET WAS DATA
030342  104000                  E10404: ERROR                   ;ADD DELIVERED WRONG RESULT
030344  030314                          R0404                   ;ERROR LOOP RETURN

030346  013703  067606                  MOV     @#MBUF1,R3      ;RESTORE UPDATED DEST ADDR
030352  022703  067604          A0404:  CMP     #MBUF0+2,R3     ;DID ADD INCREMENT DEST REG
030356  001402                          BEQ     00404           ;BR IF YES

030360  104005                  E20404: ERROR5                  ;ADD FAILED TO UPDATE DEST REG
030362  030314                          R0404                   ;ERROR LOOP RETURN

030364  000004                  00404:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***********************************************************************
                                        .SBTTL T0405 ADD SM2,DM2 TEST
                                ; ***********************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [142,240,250,162,260,267,225,367,375,016] FC 1,2,3,8

                                ;ACT BUTS:      37[004]100,142 / 35[240]120,162 / 33[260]220,225 / 16[367]016,016

                                ;EXEC:          [225]ALUC=LHLLH :[367] D = #DWTA

                                ;CODES:         [367] SPS=3

                                ;SYNC:          B05J2 (-) T = 2.7 USEC

                                ;KEY SIG:       K3-3 ADD+SUB L  /  K3-3 SM=2L  /  K3-3 DM=2L

030366  012700  000405          T0405:  MOV     #0405,R0                ;LOAD R0 WITH THE TEST NO.
030372  013701  030420                  MOV     @#I0405,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
030376  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
030402  012704  067612                  MOV     #DWTA,R4        ;RESULT S / B = #DWTA
030406  012705  067566          R0405:  MOV     #ATA,R5         ;SOURCE ADDR = ATA
030412  010203                          MOV     R2,R3           ;[R3] = DEST ADDR
030414  005012                          CLR     (R2)            ;[DEST] = 0
030416  000257                          CCC                     ;SCOPE SYNC

030420  062523                  I0405:  ADD     (R5)+,(R3)+     ;TEST THE ADD - SM2,DM2

030422  020412                          CMP     R4,(R2)         ;RESULT = #DWTA
030424  001407                          BEQ     A0405           ;BR IF YES

030426  010337  067606                  MOV     R3,@#MBUF1      ;SAVE UPDATED DEST ADDR
030432  011203                          MOV     (R2),R3         ;GET WAS DATA
030434  104000                  E10405: ERROR                   ;ADD DELIVERED WRONG RESULT
030436  030406                          R0405                   ;ERROR LOOP RETURN

030440  013703  067606                  MOV     @#MBUF1,R3      ;RESTORE UPDATED DEST ADDR
030444  022703  067604          A0405:  CMP     #MBUF0+2,R3     ;DID ADD INCREMENT DEST REG?
030450  001402                          BEQ     00405           ;BR IF YES

030452  104005                  E20405: ERROR5                  ;ADD FAILED TO UPDATE DEST REG
030454  030406                          R0405                   ;ERROR LOOP RETURN

030456  000004                  00405:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0406 ADD SM1,DM3 TEST
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [141,247,250,163,264,265,266,267,225,367,375,016] FC 1,2,3,8

                                ;ACT BUTS:      37[004]100,141 / 35[247]120,163 / 33[266]220,225 / 16[367]016,016

                                ;EXEC:          [225]ALUC=LHLLH :[367] D = #DWTA

                                ;CODES:         [367] SPS=3

                                ;SYNC:          B05J2 (-) T = 4.5 USEC

                                ;KEY SIG:       K3-3 ADD+SUB L  /  K3-3 SM=1L  /  K3-3 DM=3L

030460  012700  000406          T0406:  MOV     #0406,R0                ;LOAD R0 WITH THE TEST NO.
030464  013701  030514                  MOV     @#I0406,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
030470  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
030474  012704  067612                  MOV     #DWTA,R4        ;RESULT S / B = #DWTA
030500  012705  067566          R0406:  MOV     #ATA,R5         ;SOURCE ADDR = ATA
030504  012703  067576                  MOV     #ATA+10,R3      ;[R3] = ADDR OF DEST ADDR
030510  005012                          CLR     (R2)            ;[DEST] = 0
030512  000257                          CCC                     ;SCOPE SYNC

030514  061533                  I0406:  ADD     (R5),@(R3)+     ;TEST THE ADD - SM1,DM3

030516  020412                          CMP     R4,(R2)         ;RESULT = #DWTA?
030520  001407                          BEQ     A0406           ;BR IF YES

030522  010337  067606                  MOV     R3,@#MBUF1      ;SAVE R3
030526  011203                          MOV     (R2),R3         ;GET WAS DATA
030530  104000                  E10406: ERROR                   ;ADD DELIVERED WRONG RESULT
030532  030500                          R0406                   ;ERROR LOOP RETURN

030534  013703  067606                  MOV     @#MBUF1,R3      ;RESTORE R3
030540  022703  067600          A0406:  CMP     #ATA+12,R3      ;DID ADD INCREMENT DEST REG
030544  001402                          BEQ     00406           ;BR IF YES

030546  104005                  E20406: ERROR5                  ;ADD FAILED TO UPDATE DEST REG
030550  030500                          R0406                   ;ERROR LOOP RETURN

030552  000004                  00406:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***************************************************************
                                                .SBTTL T0407 ADD SM2,DM3 TEST
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [142,240,250,163,264,265,266,267,225,367,375,016] FC 1,2,3,8

                                        ;ACT BUTS:      37[004]100,142 / 35[240]120,163 / 33[266]220,225 / 16[367]016,016

                                        ;EXEC:          [225]ALUC=LHLLH :[367] D = #DWTA

                                        ;CODES:         [367] SPS=3

                                        ;SYNC:          B05J2 (-) T = 3.6 USEC

                                        ;KEY SIG:       K3-3 ADD+SUB L  /  K3-3 SM=2L  /  K3-3 DM=3L

030554  012700  000407                  T0407:  MOV     #0407,R0                ;LOAD R0 WITH THE TEST NO.
030560  013701  030610                          MOV     @#I0407,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
030564  012702  067602                          MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
030570  012704  067612                          MOV     #DWTA,R4        ;RESULT S / B = #DWTA
030574  012705  067566                  R0407:  MOV     #ATA,R5         ;SOURCE ADDR = ATA
030600  012703  067576                          MOV     #ATA+10,R3      ;[R3] = ADDR OF DEST ADDR
030604  005012                                  CLR     (R2)            ;[DEST] = 0
030606  000257                                  CCC                     ;SCOPE SYNC

030610  062533                          I0407:  ADD     (R5)+,@(R3)+    ;TEST THE ADD - SM2,DM3

030612  020412                                  CMP     R4,(R2)         ;RESULT = #DWTA?
030614  001407                                  BEQ     A0407           ;BR IF YES

030616  010337  067606                          MOV     R3,@#MBUF1      ;SAVE R3
030622  011203                                  MOV     (R2),R3         ;GET WAS DATA
030624  104000                          E10407: ERROR                   ;ADD DELIVERED WRONG RESULT
030626  030574                                  R0407                   ;ERROR LOOP RETURN

030630  013703  067606                          MOV     @#MBUF1,R3      ;RESTORE R3
030634  022703  067600                  A0407:  CMP     #ATA+12,R3      ;DID ADD INCREMENT DEST REG
030640  001402                                  BEQ     00407           ;BR IF YES

030642  104005                          E20407: ERROR5                  ;ADD FAILED TO UPDATE DEST REG
030644  030574                                  R0407                   ;ERROR LOOP RETURN

030646  000004                          00407:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0410 ADD SM1,DM4 TEST
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [141,247,250,164,260,267,225,367,375,016] FC 1,2,3,8

                                ;ACT BUTS:      37[004]100,141 / 35[247]120,164 / 33[260]220,225 / 16[367]016,016

                                ;EXEC:          [225]ALUC=LHLLH :[367] D = #DWTA

                                ;CODES:         [367] SPS=3

                                ;SYNC:          B05J2 (-) T = 2.6 USEC

                                ;KEY SIG:       K3-3 ADD+SUB L  /  K3-3 SM=1L  /  K3-3 DM=4L

030650  012700  000410          T0410:  MOV     #0410,R0                ;LOAD R0 WITH THE TEST NO.
030654  013701  030704                  MOV     @#I0410,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
030660  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
030664  012704  067612                  MOV     #DWTA,R4        ;RESULT S / B = #DWTA
030670  012705  067566          R0410:  MOV     #ATA,R5         ;SOURCE ADDR = ATA
030674  012703  067604                  MOV     #MBUF0+2,R3     ;R3 POINTS TO DEST ADDR +2
030700  005012                          CLR     (R2)            ;[DEST] = 0
030702  000257                          CCC                     ;SCOPE SYNC

030704  061543                  I0410:  ADD     (R5),-(R3)      ;TEST THE ADD - SM1,DM4

030706  020412                          CMP     R4,(R2)         ;RESULT = #DWTA?
030710  001407                          BEQ     A0410           ;BR IF YES

030712  010337  067606                  MOV     R3,@#MBUF1      ;SAVE R3
030716  011203                          MOV     (R2),R3         ;GET WAS DATA
030720  104000                  E10410: ERROR                   ;ADD DELIVERED WRONG RESULT
030722  030670                          R0410                   ;ERROR LOOP RETURN

030724  013703  067606                  MOV     @#MBUF1,R3      ;RESTORE R3
030730  020302                  A0410:  CMP     R3,R2           ;DID ADD INCREMENT DEST REG?
030732  001402                          BEQ     00410           ;BR IF YES

030734  104005                  E20410: ERROR5                  ;ADD FAILED TO UPDATE DEST REG.
030736  030670                          R0410                   ;ERROR LOOP RETURN

030740  000004                  00410:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0411 ADD SM2,DM4 TEST
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [142,240,250,164,260,267,225,367,375,016] FC 1,2,3,8

                                ;ACT BUTS:      37[004]100,142 / 35[240]120,164 / 33[260]220,225 / 16[367]016,016

                                ;EXEC:          [225]ALUC=LHLLH :[367] D = #DWTA

                                ;CODES:         [367] SPS=3

                                ;SYNC:          B05J2 (-) T = 2.6 USEC

                                ;KEY SIG:       K3-3 ADD+SUB L  /  K3-3 SM0=2L  /  K3-3 DM=4L

030742  012700  000411          T0411:  MOV     #0411,R0                ;LOAD R0 WITH THE TEST NO.
030746  013701  030776                  MOV     @#I0411,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
030752  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
030756  012704  067612                  MOV     #DWTA,R4        ;RESULT S / B = #DWTA
030762  012705  067566          R0411:  MOV     #ATA,R5         ;SOURCE ADDR = ATA
030766  012703  067604                  MOV     #MBUF0+2,R3     ;R3 POINTS TO DEST ADDR +2
030772  005012                          CLR     (R2)            ;[DEST] = 0
030774  000257                          CCC                     ;SCOPE SYNC

030776  061543                  I0411:  ADD     (R5),-(R3)      ;TEST THE ADD - SM2,DM4

031000  020412                          CMP     R4,(R2)         ;RESULT = #DWTA?
031002  001407                          BEQ     A0411           ;BR IF YES

031004  010337  067606                  MOV     R3,@#MBUF1      ;SAVE R3
031010  011203                          MOV     (R2),R3         ;GET WAS DATA
031012  104000                  E10411: ERROR                   ;ADD DELIVERED WRONG RESULT
031014  030762                          R0411                   ;ERROR LOOP RETURN

031016  013703  067606                  MOV     @#MBUF1,R3      ;RESTORE R3
031022  020302                  A0411:  CMP     R3,R2           ;DID ADD INCREMENT DEST REG?
031024  001402                          BEQ     00411           ;BR IF YES

031026  104005                  E20411: ERROR5                  ;ADD FAILED TO UPDATE DEST REG.
031030  030762                          R0411                   ;ERROR LOOP RETURN

031032  000004                  00411:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***********************************************************************
                                                .SBTTL T0412 ADD SM1,DM5 TEST
                                        ; ***********************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [141,247,250,165,264,265,266,267,225,367,375,016] FC 1,2,3,8

                                        ;ACT BUTS:      37[004]100,141 / 35[247]120,165 / 33[266]220,225 / 16[367]016,016

                                        ;EXEC:          [225]ALUC=LHLLH :[367] D = #DWTA

                                        ;CODES:         [367] SPS=3

                                        ;SYNC:          BOSJ2 (-) T = 3.6 USEC

                                        ;KEY SIG:       K3-3 ADD+SUB L  /  K3-3 SM=1L  /  K3-3 DM=5L

031034  012700  000412                  T0412:  MOV     #0412,R0                ;LOAD R0 WITH THE TEST NO.
031040  013701  031070                          MOV     @#T0412,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
031044  012702  067602                          MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
031050  012704  067612                          MOV     #DWTA,R4        ;RESULT S / B = #DWTA
031054  012705  067566                  R0412:  MOV     #ATA,R5         ;SOURCE ADDR = ATA
031060  012703  067600                          MOV     #ATA+12,R3      ;R3 CONTAINS ADDR OF DEST ADDR PLUS 2
031064  005012                                  CLR     (R2)            ;[DEST] = 0
031066  000257                                  CCC                     ;SCOPE SYNC

031070  061553                          T0412:  ADD     (R5),@-(R3)     ;TEST THE ADD - SM1,DM5

031072  020412                                  CMP     R4,(R2)         ;RESULT = #DWTA?
031074  001407                                  BEQ     A0412           ;BR IF YES

031076  010337  067606                          MOV     R3,@#MBUF1      ;SAVE R3
031102  011203                                  MOV     (R2),R3         ;GET WAS DATA
031104  104000                          E10412: ERROR                   ;ADD DELIVERED WRONG RESULT
031106  031054                                  R0412                   ;ERROR LOOP RETURN

031110  013703  067606                          MOV     @#MBUF1,R3      ;RESTORE R3
031114  022703  067576                  A0412:  CMP     #ATA+10,R3      ;DID ADD DECREMENT DEST REG?
031120  001402                                  BEQ     C0412           ;BR IF YES

031122  104005                          E20412: ERROR5                  ;ADD FAILED TO UPDATE DEST REG.
031124  031054                                  R0412                   ;ERROR LOOP RETURN

031126  000004                          C0412:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***********************************************************************
                                                .SBTTL T0413 ADD SM2,DM5 TEST
                                        ; ***********************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [142,240,250,165,264,265,266,267,225,367,375,016] FC 1,2,3,8

                                        ;ACT BUTS:      37[004]100,142 / 35[240]120,165 / 33[266]220,225 / 16[367]016,016

                                        ;EXEC:          [225]ALUC=LHLLH :[367] D = #DWTA

                                        ;CODES:         [367] SPS = 3

                                        ;SYNC:          B05J2 (-) T = 3.6 USEC

                                        ;KEY SIG:       K3-3 ADD+SUB L  /  K3-3 SM=2L  /  K3-3 DM=5L

031130  012700  000413                  T0413:  MOV     #0413,R0                ;LOAD R0 WITH THE TEST NO.
031134  013701  031164                          MOV     @#I0413,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
031140  012702  067602                          MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
031144  012704  067612                          MOV     #DWTA,R4        ;RESULT S / B = #DWTA
031150  012705  067566                  R0413:  MOV     #ATA,R5         ;SOURCE ADDR = ATA
031154  012703  067600                          MOV     #ATA+12,R3      ;R3 CONTAINS ADDR OF DEST ADDR PLUS 2
031160  005012                                  CLR     (R2)            ;[DEST] = 0
031162  000257                                  CCC                     ;SCOPE SYNC

031164  062553                          I0413:  ADD     (R5)+,@-(R3)    ;TEST THE ADD - SM2,DM5

031166  020412                                  CMP     R4,(R2)         ;RESULT = #DWTA?
031170  001407                                  BEQ     A0413           ;BR IF YES

031172  010337  067606                          MOV     R3,@#MBUF1      ;SAVE R3
031176  011203                                  MOV     (R2),R3         ;GET WAS DATA
031200  104000                          E10413: ERROR                   ;ADD DELIVERED WRONG RESULT
031202  031150                                  R0413                   ;ERROR LOOP RETURN

031204  013703  067606                          MOV     @#MBUF1,R3      ;RESTORE R3
031210  022703  067576                  A0413:  CMP     #ATA+10,R3      ;DID ADD DECREMENT DEST REG?
031214  001402                                  BEQ     00413           ;BR IF YES

031216  104005                          E20413: ERROR5                  ;ADD FAILED TO UPDATE DEST REG
031220  031150                                  R0413                   ;ERROR LOOP RETURN

031222  000004                          00413:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0414 ADD SM1,DM6 TEST
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [141,247,250,167,261,262,266,267,225,367,375,016] FC 1,2,3,8

                                ;ACT BUTS:      37[004]100,141 / 35[247]120,167 / 17[167]262,262 / 33[266]220,225
                                                ; / 16[367]016,016

                                ;EXEC:          [225]ALUC=LHLLH :[367] D = #DWTA

                                ;CODES:         [367] SPS=3

                                ;SYNC:          BOSJ2 (-) T = 3.25 USEC

                                ;KEY SIG:       K3-3 ADD+SUB L  /  K3-3 SM=1L  /  K3-3 DM=6L

031224  012700  000414          T0414:  MOV     #0414,R0                ;LOAD R0 WITH THE TEST NO.
031230  013701  031260                  MOV     @#I0414,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
031234  012702  067606                  MOV     #MBUF0+4,R2     ;DEST ADDR = MBUF0+4
031240  012704  067612                  MOV     #DWTA,R4        ;RESULT S / B = #DWTA
031244  012705  067566          R0414:  MOV     #ATA,R5         ;SOURCE ADDR = ATA
031250  012703  067602                  MOV     #MBUF0,R3       ;[R3] = BASE DEST ADDR
031254  005012                          CLR     (R2)            ;[DEST] = 0
031256  000257                          CCC                     ;SCOPE SYNC

031260  061563  000004          I0414:  ADD     (R5),4(R3)      ;TEST THE ADD - SM1,DM6

031264  020412                          CMP     R4,(R2)         ;RESULT = #DWTA?
031266  001403                          BEQ     00414           ;BR IF YES

031270  011203                          MOV     (R2),R3         ;GET WAS DATA
031272  104000          E0414:  ERROR                           ;ADD DELIVERED WRONG RESULT
031274  031244                  R0414                           ;ERROR LOOP RETURN

031276  000004          00414:  SCOPE                           ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***************************************************************
                                                .SBTTL T0415 ADD SM2,DM6 TEST
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [142,240,250,167,261,262,266,267,225,367,375,016] FC 1,2,3,8

                                        ;ACT BUTS:      37[004]100,142 / 35[240]120,167 / 17[167]262,262 / 33[266]220,225
                                                        ; / 16[367]016,016

                                        ;EXEC:          [225]ALUC=LHLLH :[367] D = #DWTA

                                        ;CODES:         [367] SPS=3

                                        ;SYNC:          BOSJ2 (-) T = 3.25 USEC

                                        ;KEY SIG:       K3-3 ADD+SUB L  /  K3-3 SM= _  /  K3-3 DM=6L

031300  012700  000415          T0415:  MOV     #0415,R0                ;LOAD R0 WITH THE TEST NO.
031304  013701  031334                  MOV     @#I0415,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
031310  012702  067606                  MOV     #MBUF0+4,R2     ;DEST ADDR = MBUF0+4
031314  012704  067612                  MOV     #DWTA,R4        ;RESULT S / B = #DWTA
031320  012705  067566          R0415:  MOV     #ATA,R5         ;SOURCE ADDR = ATA
031324  012703  067602                  MOV     #MBUF0,R3       ;[R3] = BASE DEST ADDR
031330  005012                          CLR     (R2)            ;[DEST] = 0
031332  000257                          CCC                     ;SCOPE SYNC

031334  062563  000004          I0415:  ADD     (R5)+,4(R3)     ;TEST THE ADD - SM2,DM6

031340  020412                          CMP     R4,(R2)         ;RESULT = #DWTA?
031342  001403                          BEQ     00415           ;BR IF YES

031344  011203                          MOV     (R2),R3         ;GET WAS DATA
031346  104000          E0415:  ERROR                           ;ADD DELIVERED WRONG RESULT
031350  031320                  R0415                           ;ERROR LOOP RETURN

031352  000004          00415:  SCOPE                           ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***********************************************************************
                                        .SBTTL T0416 ADD SM1,DM7 TEST
                                ; ***********************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [141,247,250,167,261,263,264,265,266,267,225,367,375,016] FC 1,2,3,8

                                ;ACT BUTS:      37[004]100,141 / 35[247]120,167 / 17[167]262,263 / 33[266]220,225
                                                ; / 16[367]016,016

                                ;EXEC:          [225]ALUC=LHLLH :[367] D = #DWTA

                                ;CODES:         [367] SPS=3

                                ;SYNC:          B05J2 (-) T = 4.25 USEC

                                ;KEY SIG:       K3-3 ADD+SUB L  /  K3-3 SM=1L  /  K3-3 DM=7L

031354  012700  000416          T0416:  MOV     #0416,R0                ;LOAD R0 WITH THE TEST NO.
031360  013701  031406                  MOV     #T0416,R1       ;LOAD R1 WITH TEST INSTRUCTION WORD
031364  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
031370  012704  067612                  MOV     #DWTA,R4        ;RESULT S / B = #DWTA
031374  012705  067566          R0416:  MOV     #ATA,R5         ;SOURCE ADDR = ATA
031400  010503                          MOV     R5,R3           ;BASE DEST ADDR = ATA
031402  005012                          CLR     (R2)            ;[DEST] = 0
031404  000257                          CCC                     ;SCOPE SYNC

031406  061573  000010          T0416:  ADD     (R5),@10(R3)    ;TEST THE ADD - SM1,DM7

031412  02[illegible]                   CMP     R4,(R2)         ;RESULT = #DWTA?
031[illegible]  [illegible]1403                 BEQ     00416           ;BR IF YES

031416  011203                          MOV     (R2),R3         ;GET WAS DATA
031420  104000                  E0416:  ERROR                   ;ADD DELIVERED WRONG RESULT
031422  031374                          R0416                   ;ERROR LOOP RETURN

031424  000004                  00416:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0417 ADD SM2,DM7 TEST
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [142,240,250,167,261,263,264,265,266,267,225,367,375,016] FC 1,2,3,8

                                ;ACT BUTS:      37[004]100,142 / 35[240]120,167 / 17[167]262,263 / 33[266]220,225
                                                ; / 16[367]016,016

                                ;EXEC:          [225]ALUC=LHLLH :[367] D = #DWTA

                                ;CODES:         [367] SPS=3

                                ;SYNC:          B05J2 (-) T = 4.25 USEC

                                ;KEY SIG:       K3-3 ADD+SUB L  /  K3-3 SM=2L  /  K3-3 DM=7L

031426  012700  000417          T0417:  MOV     #0417,R0                ;LOAD R0 WITH THE TEST NO.
031432  013701  031460                  MOV     @#I0417,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
031436  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
031442  012704  067612                  MOV     #DWTA,R4        ;RESULT S / B = #DWTA
031446  012705  067566          R0417:  MOV     #ATA,R5         ;SOURCE ADDR = ATA
031452  010503                          MOV     R5,R3           ;BASE DEST ADDR = ATA
031454  005012                          CLR     (R2)            ;[DEST] = 0
031456  000257                          CCC                     ;SCOPE SYNC

031460  062573  000010          I0417:  ADD     (R5)+,@10(R3)   ;TEST THE ADD - SM2,DM7

031464  020412                          CMP     R4,(R2)         ;RESULT = #DWTA?
031466  001403                          BEQ     00417           ;BR IF YES

031470  011203                          MOV     (R2),R3         ;GET WAS DATA
031472  104000          E0417:  ERROR                           ;ADD DELIVERED WRONG RESULT
031474  031446                  R0417                           ;ERROR LOOP RETURN

031476  000004          00417:  SCOPE                           ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***********************************************************************
                                        .SBTTL T0420 "XOR RA,RB" TEST - A=B=000000 N:C=1010
                                ; ***********************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [102,364,360,001] FC 1,7,8

                                ;ACT BUTS:      37[004]100,102 / 31[102]360,360 / 27[364]000,001

                                ;EXEC:          [364]ALUC=HLHHL :[360]D=000000

                                ;CODES:         [360] SPS=3  /  N:C=0100

                                ;SYNC:          BOSJ2 (-)       /       T=1 USEC

                                ;KEY SIG:       K3-5 XOR L  /  K3-3 DM=0 L / K3-4 OVLAP INSTR H

031500  012700  000420          T0420:  MOV     #0420,R0                ;LOAD R0 WITH TEST NO.
031504  013701  031524                  MOV     @#I0420,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
031510  005004                          CLR     R4              ;RESULT AND MASK = 000000
031512  012702  177703                  MOV     #177703,R2      ;DEST ADDR = R3
031516  005003                  R0420:  CLR     R3              ;[DEST] = 000000
031520  000257                          CCC                     ;SCOPE SYNC
031522  000272                          272                     ;MAKE N:C=1010

031524  074403                  I0420:  XOR     R4,R3           ;TEST THE XOR

031526  100403                          BMI     E10420          ;N:C=0100 ??
031530  001002                          BNE     E10420
031532  102401                          BVS     E10420
031534  103002                          BCC     A0420

031536  104000                  E10420: ERROR                   ;XOR FAILED TO SET FLAGS PROPERLY
031540  031516                          R0420                   ;ERROR LOOP RETURN ADDRESS

031542  020403                  A0420:  CMP     R4,R3           ;RESULT CORRECT?
031544  001402                          BEQ     00420           ;BR IF YES

031546  104000                  E20420: ERROR                   ;XOR DELIVERED THE WRONG RESULT
031550  031516                          R0420                   ;ERROR LOOP RETURN ADDRESS

031552  000004                  00420:  SCOPE                   ;CALL THE SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0421 "XOR RA,RB" TEST - A=B=177777 N:C=0101
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [102,364,360,001] FC 1,7,8

                                ;ACT BUTS:      37[004]100,102 / 31[102]360,360 / 27[364]000,001

                                ;EXEC:          [364]ALUC=HLHHL :[360]D=000000

                                ;CODES:         [360] SPS=3  /  N:C=0101

                                ;SYNC:          B05J2 (-)       /       T=1 USEC

                                ;KEY SIG:       K3-5 XOR L  /  K3-3 DM=0 L / K3-4 OVLAP INSTR H

031554  012700  000421          T0421:  MOV     #0421,R0                ;LOAD R0 WITH TEST NO.
031560  013701  031604                  MOV     @#I0421,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
031564  005004                          CLR     R4              ;RESULT  = 000000
031566  012705  177777                  MOV     #-1,R5          ;MASK = 177777
031572  012702  177703                  MOV     #177703,R2      ;DEST ADDR = R3
031576  010503                  R0421:  MOV     R5,R3           ;[DEST]=177777
031600  000257                          CCC                     ;SCOPE SYNC
031602  000265                          265                     ;MAKE N:C=0101

031604  074503                  I0421:  XOR     R5,R3           ;TEST THE XOR

031606  100403                          BMI     E10421          ;N:C=0101 ??
031610  001002                          BNE     E10421
031612  102401                          BVS     E10421
031614  103402                          BCS     A0421

031616  104000                  E10421: ERROR                   ;XOR FAILED TO SET FLAGS PROPERLY
031620  031576                          R0421                   ;ERROR LOOP RETURN ADDRESS

031622  020403                  A0421:  CMP     R4,R3           ;RESULT CORRECT?
031624  001402                          BEQ     00421           ;BR IF YES

031626  104000                  E20421: ERROR                   ;XOR DELIVERED THE WRONG RESULT
031630  031576                          R0421                   ;ERROR LOOP RETURN ADDRESS

031632  000004                  00421:  SCOPE                   ;CALL THE SCOPE LOOP UTILITY
```

```
                                        ; ***************************************************************
                                                .SBTTL T0422 "XOR RA,RB" TEST - A=125252,B=052525 N:C=0110
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [102,364,360,001] FC 1,7,8

                                        ;ACT BUTS:      37[004]100,102 / 31[102]360,360 / 27[364]000,001

                                        ;EXEC:          [364]ALUC=HLHHL :[360]D=177777

                                        ;CODES:         [360] SPS=3  /  N:C=1000

                                        ;SYNC:          B05J2 (-)       /       T=1 USEC

                                        ;KEY SIG:       K3-5 XOR L  /  K3-3 DM=0 L / K3-4 OVLAP INSTR H

031634  012700  000422                  T0422:  MOV     #0422,R0                ;LOAD R0 WITH TEST NO.
031640  013701  031670                          MOV     @#I0422,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
031644  012704  177777                          MOV     #-1,R4          ;RESULT S/B = 177777
031650  012702  177703                          MOV     #177703,R2      ;DEST ADDR = R3
031654  012705  125252                          MOV     #125252,R5      ;MASK=125252
031660  012703  052525                  R0422:  MOV     #052525,R3      ;[DEST] = 052525
031664  000257                                  CCC                     ;SCOPE SYNC
031666  000266                                  266                     ;MAKE N:C=0110

031670  074503                          I0422:  XOR     R5,R3           ;TEST THE XOR

031672  100003                                  BPL     E10422          ;N:C=1000 ??
031674  001402                                  BEQ     E10422
031676  102401                                  BVS     E10422
031700  103002                                  BCC     A0422

031702  104000                          E10422: ERROR                   ;XOR FAILED TO SET FLAGS PROPERLY
031704  031660                                  R0422                   ;ERROR LOOP RETURN ADDRESS

031706  020403                          A0422:  CMP     R4,R3           ;RESULT CORRECT?
031710  001402                                  BEQ     00422           ;BR IF YES

031712  104000                          E20422: ERROR                   ;XOR DELIVERED THE WRONG RESULT
031714  031660                                  R0422                   ;ERROR LOOP RETURN ADDRESS

031716  000004                          00422:  SCOPE                   ;CALL THE SCOPE LOOP UTILITY
```

```
                                ; ***********************************************************************
                                        .SBTTL T0423 "XOR RA,RB" TEST - A=052525,B=125252 N:C=1001
                                ; ***********************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [102,364,360,001] FC 1,7,8

                                ;ACT BUTS:      37[004]100,102 / 31[102]360,360 / 27[364]000,001

                                ;EXEC:          [364]ALUC=HLHHL :[360]D=000000

                                ;CODES:         [360] SPS=3  /  N:C=1001

                                ;SYNC:          B05J2 (-)       /       T=1 USEC

                                ;KEY SIG:       K3-5 XOR L  /  K3-3 DM=0 L / K3-4 OVLAP INSTR H

031720  012700  000423          T0423:  MOV     #0423,R0                ;LOAD R0 WITH TEST NO.
031724  013701  031754                  MOV     @#T0423,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
031730  012704  177777                  MOV     #-1,R4          ;RESULT S/B = 177777
031734  012702  177703                  MOV     #177703,R2      ;DEST ADDR = R3
031740  012705  052525                  MOV     #52525,R5       ;MASK=052525
031744  012703  125252          R0423:  MOV     #125252,R3      ;[DEST] = 125252
031750  000257                          CCC                     ;SCOPE SYNC
031752  000271                          271                     ;MAKE N:C=1001

031754  074503                  I0423:  XOR     R5,R3           ;TEST THE XOR

031756  100003                          BPL     E10423          ;N:C=1001 ??
031760  001402                          BEQ     E10423
031762  102401                          BVS     E10423
031764  103402                          BCS     A0423

031766  104000                  E10423: ERROR                   ;XOR FAILED TO SET FLAGS PROPERLY
031770  031744                          R0423                   ;ERROR LOOP RETURN ADDRESS

031772  020403                  A0423:  CMP     R4,R3           ;RESULT CORRECT?
031774  001402                          BEQ     00423           ;BR IF YES

031776  104000                  E20423: ERROR                   ;XOR DELIVERED THE WRONG RESULT
032000  031744                          R0423                   ;ERROR LOOP RETURN ADDRESS

032002  000004                  00423:  SCOPE                   ;CALL THE SCOPE LOOP UTILITY
```

```
                                ; ***********************************************************************
                                        .SBTTL T0424 "XOR RA,(RB)" TEST - A=B=000000 N:C=1010
                                ; ***********************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [161,266,267,224,367,375,016] FC 1,3,8

                                ;ACT BUTS:      37[004]100,161 / 33[266]220,224 / 16[367]016,016

                                ;EXEC:          [224]ALUC=HLHHL :[367]D=000000

                                ;CODES:         [367] SPS=3  /  N:C=0100

                                ;SYNC:          B05J2 (-)       /       T=2.6 USEC

                                ;KEY SIG:       K3-5 XOR L  /  K3-3 DM=1L

032004  012700  000424          T0424:  MOV     #0424,R0                ;LOAD R0 WITH TEST NO.
032010  013701  032032                  MOV     @#I0424,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
032014  005004                          CLR     R4              ;RESULT S / B = 000000
032016  005005                          CLR     R5              ;MASK = 000000
032020  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
032024  005012                  R0424:  CLR     (R2)            ;[DEST] = 000000
032026  000257                          CCC                     ;SCOPE SYNC
032030  000272                          272                     ;MAKE N:C=1010

032032  074512                  I0424:  XOR     R5,(R2)         ;TEST THE XOR

032034  100403                          BMI     E10424          ;N:C = 0100 ??
032036  001002                          BNE     E10424
032040  102401                          BVS     E10424
032042  103002                          BCC     A0424

032044  104000                  E10424: ERROR                   ;XOR FAILED TO ALTER CODES PROPERLY
032046  032024                          R0424                   ;ERROR LOOP RETURN ADDRESS

032050  020412                  A0424:  CMP     R4,(R2)         ;RESULT CORRECT?
032052  001403                          BEQ     00424           ;BR IF YES

032054  011203                          MOV     (R2),R3         ;GET THE WAS DATA
032056  104000                  E20424: ERROR                   ;XOR DELIVERED THE WRONG RESULT
032060  032024                          R0424                   ;ERROR LOOP RETURN ADDRESS

032062  000004                  00424:  SCOPE                   ;CALL THE SCOPE LOOP UTILITY
```

```
                                ; ***********************************************************************
                                        .SBTTL T0425 "XOR RA,(RB)" TEST - A=B=177777 N:C=0101
                                ; ***********************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [161,266,267,224,367,375,016] FC 1,3,8

                                ;ACT BUTS:      37[004]100,161 / 33[266]220,224 / 16[367]016,016

                                ;EXEC:          [224]ALUC=HLHHL :[367]D=000000

                                ;CODES:         [367] SPS=3  /  N:C=0101

                                ;SYNC:          BOSJ2 (-)       /       T=2.6 USEC

                                ;KEY SIG:       K3-5 XOR L  /  K3-3 DM=1L

032064  012700  000425          T0425:  MOV     #0425,R0                ;LOAD R0 WITH TEST NO.
032070  013701  032116                  MOV     @#I0425,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
032074  005004                          CLR     R4              ;RESULT S / B = 000000
032076  012705  177777                  MOV     #-1,R5          ;MASK = 177777
032102  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
032106  012712  177777          R0425:  MOV     #-1,(R2)        ;[DEST] = 177777
032112  000257                          CCC                     ;SCOPE SYNC
032114  000265                          265                     ;MAKE N:C=0101

032116  074512                  I0425:  XOR     R5,(R2)         ;TEST THE XOR

032120  100403                          BMI     E10425          ;N:C = 0101 ??
032122  001002                          BNE     E10425
032124  102401                          BVS     E10425
032126  103402                          BCS     A0425

032130  104000                  E10425: ERROR                   ;XOR FAILED TO ALTER CODES PROPERLY
032132  032106                          R0425                   ;ERROR LOOP RETURN ADDRESS

032134  020412                  A0425:  CMP     R4,(R2)         ;RESULT CORRECT?
032136  001403                          BEQ     00425           ;BR IF YES

032140  011203                          MOV     (R2),R3         ;GET THE WAS DATA
032142  104000                  E20425: ERROR                   ;XOR DELIVERED THE WRONG RESULT
032144  032106                          R0425                   ;ERROR LOOP RETURN ADDRESS

032146  000004                  00425:  SCOPE                   ;CALL THE SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0426 "XOR RA,(RB)" TEST - A=125252,B=052525 N:C=0110
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [161,266,267,224,367,375,016] FC 1,3,8

                                ;ACT BUTS:      37[004]100,161 / 33[266]220,224 / 16[367]016,016

                                ;EXEC:          [224]ALUC=HLHHL :[367]D=00177777

                                ;CODES:         [367] SPS=3  /  N:C=1000

                                ;SYNC:          B05J2 (-)       /       T=2.6 USEC

                                ;KEY SIG:       K3-5 XOR L  /  K3-3 DM=1L

032150  012700  000426          T0426:  MOV     #0426,R0                ;LOAD R0 WITH TEST NO.
032154  013701  032204                  MOV     @#I0426,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
032160  012704  177777                  MOV     #-1,R4          ;RESULT S/B = 177777
032164  012705  125252                  MOV     #125252,R5      ;MASK = 125252
032170  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
032174  012712  052525          R0426:  MOV     #052525,(R2)    ;[DEST] = 052525
032200  000257                          CCC                     ;SCOPE SYNC
032202  000266                          266                     ;MAKE N:C=0110

032204  074512                  I0426:  XOR     R5,(R2)         ;TEST THE XOR

032206  100003                          BPL     E10426          ;N:C = 1000 ??
032210  001402                          BEQ     E10426
032212  102401                          BVS     E10426
032214  103002                          BCC     A0426

032216  104000                  E10426: ERROR                   ;XOR FAILED TO ALTER CODES PROPERLY
032220  032174                          R0426                   ;ERROR LOOP RETURN ADDRESS

032222  020412                  A0426:  CMP     R4,(R2)         ;RESULT CORRECT?
032224  001403                          BEQ     00426           ;BR IF YES

032226  011203                          MOV     (R2),R3         ;GET THE WAS DATA
032230  104000                  E20426: ERROR                   ;XOR DELIVERED THE WRONG RESULT
032232  032174                          R0426                   ;ERROR LOOP RETURN ADDRESS

032234  000004                  00426:  SCOPE                   ;CALL THE SCOPE LOOP UTILITY
```

```
                                ; ***********************************************************************
                                        .SBTTL T0427 "XOR RA,(RB)" TEST - A=052525,B=125252 N:C=1001
                                ; ***********************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [161,266,267,224,367,375,016] FC 1,3,8

                                ;ACT BUTS:      37[004]100,161 / 33[266]220,224 / 16[367]016,016

                                ;EXEC:          [224]ALUC=HLHHL :[367]C=177777

                                ;CODES:         [367] SPS=3  /  N:C=1001

                                ;SYNC:          B05J2 (-)       /       T=2.6 USEC

                                ;KEY SIG:       K3-5 XOR L  /  K3-3 DM=1L

032236  012700  000427          T0427:  MOV     #0427,R0                ;LOAD R0 WITH TEST NO.
032242  013701  032272                  MOV     @#T0427,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
032246  012704  177777                  MOV     #-1,R4          ;RESULT S/B = 177777
032252  012705  052525                  MOV     #52525,R5       ;MASK = 052525
032256  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
032262  012712  125252          R0427:  MOV     #125252,(R2)    ;[DEST] = 125252
032266  000257                          CCC                     ;SCOPE SYNC
032270  000271                          271                     ;MAKE N:C=1001

032272  074512                  T0427:  XOR     R5,(R2)         ;TEST THE XOR

032274  100003                          BPL     E10427          ;N:C = 1001 ??
032276  001402                          BEQ     E10427
032300  102401                          BVS     E10427
032302  103402                          BCS     A0427

032304  104000                  E10427: ERROR                   ;XOR FAILED TO ALTER CODES PROPERLY
032306  032262                          R0427                   ;ERROR LOOP RETURN ADDRESS

032310  020412                  A0427:  CMP     R4,(R2)         ;RESULT CORRECT?
032312  001403                          BEQ     00427           ;BR IF YES

032314  011203                          MOV     (R2),R3         ;GET THE WAS DATA
032316  104000                  E20427: ERROR                   ;XOR DELIVERED THE WRONG RESULT
032320  032262                          R0427                   ;ERROR LOOP RETURN ADDRESS

032322  000004                  00427:  SCOPE                   ;CALL THE SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0430 SUB TEST SMO,DMO - (SRC) = (DEST) = +,+
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [103,363,360,001] FC 1,7,8

                                ;ACT BUTS:      37[004]100,103 / 27[363]000,001

                                ;EXEC:          [363]ALUC=LLHHL :[360] D = 000000

                                ;CODES:         [360] SPS=3  /  N:C = 0100

                                ;SYNC:          BOSJ2 (-) T = 1 USEC

                                ;KEY SIG:       K3-3 ADD+SUB L  /  K3-3 DM=OL  /  K3-3 SM=OL  /  K3-4 OVLAP INSTR H
                                                ;  K3-8 CINOO L

032324  012700  000430          T0430:  MOV     #0430,R0                ;LOAD R0 WITH TEST NO.
032330  013701  032354                  MOV     @#I0430,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD

032334  012702  177703                  MOV     #177703,R2      ;R2 CONTAINS DEST ADDR
032340  005004                          CLR     R4              ;RESULT S / B = 0
032342  012703  052525          R0430:  MOV     #052525,R3      ;[R3] = DEST OP = 52525
032346  010305                          MOV     R3,R5           ;[R5] = SRC OP = 52525
032350  000257                          CCC                     ;CLEAR FLAGS
032352  000273                          273                     ;MAKE N:C = 1011

032354  160503                  I0430:  SUB     R5,R3           ;TEST THE SUB

032356  100403                          BMI     E10430
032360  001002                          BNE     E10430          ;DID N:C = 0100
032362  102401                          BVS     E10430
032364  103002                          BCC     A0430

032366  104000                  E10430: ERROR                   ;SUB FAILED TO ALTER CODES PROPERLY
032370  032342                          R0430                   ;ERROR LOOP RETURN

032372  020304                  A0430:  CMP     R3,R4           ;WAS RESULT = 0?
032374  001402                          BEQ     00430           ;BR IF YES

032376  104000                  E20430: ERROR                   ;SUB DELIVERED WRONG RESULT
032400  032342                          R0430                   ;ERROR LOOP RETURN

032402  000004                   00430: SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***************************************************************
                                                .SBTTL T0431 SUB TEST SMO,DMO - (SRC) = (DEST) = -,-
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [103,363,360,001] FC 1,7,8

                                        ;ACT BUTS:      37[004]100,103 / 27[363]000,001

                                        ;EXEC:          [363]ALUC=LLHHL :[360] D = 000000

                                        ;CODES:         [360] SPS=3  /  N:C = 0100

                                        ;SYNC:          B05J2 (-) T = 1 USEC

                                        ;KEY SIG:       K3-3 ADD+SUB L  /  K3-3 DM=0L  /  K3-3 SM=0L  /  K3-4 OVLAP INSTR H
                                                        ;  K3-8 CINOO L

032404  012700  000431          T0431:  MOV     #0431,R0                ;LOAD R0 WITH TEST NO.
032410  013701  032434                  MOV     @#I0431,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD

032414  012702  177703                  MOV     #177703,R2      ;DEST ADDR  = R3
032420  005004                          CLR     R4              ;RESULT S / B = 0
032422  012703  125252          R0431:  MOV     #125252,R3      ;[R3] = DEST OP = 125252
032426  010305                          MOV     R3,R5           ;[R5] = SOURCE OP = 125252
032430  000257                          CCC                     ;CLEAR FLAGS
032432  000273                          273                     ;MAKE N:C = 1011

032434  160503                  I0431:  SUB     R5,R3           ;TEST THE SUB

032436  100403                          BMI     E10431
032440  001002                          BNE     E10431          ;N:C = 0100?
032442  102401                          BVS     E10431
032444  103002                          BCC     A0431

032446  104000                  E10431: ERROR                   ;SUB FAILED TO ALTER CODES PROPERLY
032450  032422                          R0431                   ;ERROR LOOP RETURN

032452  020304                  A0431:  CMP     R3,R4           ;RESULT = 0?
032454  001402                          BEQ     00431           ;BR IF YES

032456  104000                  E20431: ERROR                   ;SUB DELIVERED WRONG RESULT
032460  032422                          R0431                   ;ERROR LOOP RETURN

032462  000004                   00431: SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***************************************************************
                                                .SBTTL T0432 SUB TEST SM0,DM0 - (SRC) = (DEST) = -,+
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [103,363,360,001] FC 1,7,8

                                        ;ACT BUTS:      37[004]100,103 / 27[363]000,001

                                        ;EXEC:          [363]ALUC=LLHHL :[360] D = 000002

                                        ;CODES:         [360] SPS=3  /  N:C = 0001

                                        ;SYNC:          B05J2 (-) T = 1 USEC

                                        ;KEY SIG:       K3-3 ADD+SUB L  /  K3-3 SM=0L  /  K3-3 DM=0L  /  K3-4 OVLAP INSTR H
                                                        ;  K3-8 CIN00 L

032464  012700  000432          T0432:  MOV     #0432,R0                ;LOAD R0 WITH TEST NO.
032470  013701  032520                  MOV     @#I0432,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD

032474  012702  177703                  MOV     #177703,R2      ;R2 CONTAINS DEST ADDR
032500  012704  000002                  MOV     #2,R4           ;RESULT S / B = 2
032504  012703  000001          R0432:  MOV     #1,R3           ;[R3] = DEST OP = 1
032510  012705  177777                  MOV     #-1,R5          ;[R5] = SRC OP = -1
032514  000257                          CCC                     ;CLEAR FLAGS
032516  000276                          276                     ;MAKE N:C = 1110

032520  160503          I0432:  SUB     R5,R3           ;TEST THE SUB

032522  100403                  BMI     E10432
032524  001402                  BEQ     E10432          ;N:C = 0001
032526  102401                  BVS     E10432
032530  103402                  BCS     A0432

032532  104000          E10432: ERROR                   ;SUB FAILED TO ALTER CODES PROPERLY
032534  032504                  R0432                   ;ERROR LOOP RETURN

032536  020304          A0432:  CMP     R3,R4           ;RESULT = +2?
032540  001402                  BEQ     00432           ;BR IF YES

032542  104000          E20432: ERROR                   ;SUB DELIVERED WRONG RESULT
032544  032504                  R0432                   ;ERROR LOOP RETURN

032546  000004           00432: SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***************************************************************
                                                .SBTTL T0433 SUB TEST SMD,DMD (SRC) = -(DEST) = +,-
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [103,363,360,001] FC 1,7,8

                                        ;ACT BUTS:      37[004]100,103 / 27[363]000,001

                                        ;EXEC:          [363]ALUC=LLHHL :[360] D = 177776

                                        ;CODES:         [360] SPS=3  /  N:C = 1000

                                        ;SYNC:          BOSJ2 (-) T = 1 USEC

                                        ;KEY SIG:       K3-3 ADD+SUB L  /  K3-3 DM=OL  /  K3-3 SM=OL  /  K3-4 OVLAP INSTR H
                                                        ;  K3-8 CINOO L

032550  012700  000433          T0433:  MOV     #0433,R0                ;LOAD R0 WITH TEST NO.
032554  013701  032604                  MOV     @#I0433,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD

032560  012702  177703                  MOV     #177703,R2      ;R2 CONTAINS DEST ADDR
032564  012704  177776                  MOV     #-2,R4          ;RESULT S / B = -2
032570  012703  177777          R0433:  MOV     #-1,R3          ;[R3] = [DEST] = -1
032574  012705  000001                  MOV     #1,R5           ;[R5] = [SOURCE] = +1
032600  000257                          CCC                     ;CLEAR FLAGS
032602  000267                          267                     ;MAKE N:C = 0111

032604  160503                  I0433:  SUB     R5,R3           ;TEST THE SUB

032606  100003                          BPL     E10433
032610  001402                          BEQ     E10433          ;N:C = 1000
032612  102401                          BVS     E10433
032614  103002                          BCC     A0433

032616  104000                  E10433: ERROR                   ;SUB DID NOT ALTER CODES PROPERLY
032620  032570                          R0433                   ;ERROR LOOP RETURN

032622  020403                  A0433:  CMP     R4,R3           ;RESULT = -2?
032624  001402                          BEQ     00433           ;BR IF YES

032626  104000                  E20433: ERROR                   ;SUB DELIVERED WRONG RESULT
032630  032570                          R0433                   ;ERROR LOOP RETURN

032632  000004                  00433:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0434 SUB TEST SMO,DMO - "V" BIT SETS
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [103,363,360,001] FC 1,7,8

                                ;ACT BUTS:      37[004]100,103 / 27[363]000,001

                                ;EXEC:          [363]ALUC=LLHHL :[360] D = 77777

                                ;CODES:         [360] SPS=3  /  N:C = 0011

                                ;SYNC:          BOSJ2 (-) T = 1 USEC

                                ;KEY SIG:       K3-3 ADD+SUB L  /  K3-3 DM=OL  /  K3-3 SM=OL  /  K3-4 OVLAP INSTR H
                                                ;  K3-8 CINOO L

032634  012700  000434          T0434:  MOV     #0434,R0                ;LOAD R0 WITH TEST NO.
032640  013701  032670                  MOV     @#I0434,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD

032644  012702  177703                  MOV     #177703,R2      ;DEST ADDR = 177703
032650  012704  077777                  MOV     #77777,R4       ;RESULT = 77777
032654  012703  100000          R0434:  MOV     #100000,R3      ;[R3] = DEST OP = 100000
032660  012705  000001                  MOV     #1,R5           ;[R5] = SRC OP = 1
032664  000257                          CCC                     ;CLEAR FLAGS
032666  000274                          274                     ;MAKE N:C = 1100

032670  160503                  I0434:  SUB     R5,R3           ;TEST THE SUB

032672  100403                          BMI     E10434
032674  001402                          BEQ     E10434          ;N:C = 0011 ("V" BIT SHOULD SET)
032676  102001                          BVC     E10434
032700  103002                          BCC     A0434

032702  104000                  E10434: ERROR                   ;SUB FAILED TO ALTER CODES PROPERLY
032704  032654                          R0434                   ;ERROR LOOP RETURN

032706  020304                  A0434:  CMP     R3,R4           ;RESULT = 77777?
032710  001402                          BEQ     00434           ;BR IF YES

032712  104000                  E20434: ERROR                   ;SUB DELIVERED WRONG RESULT
032714  032654                          R0434                   ;ERROR LOOP RETURN

032716  000004                  00434:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0435 SUB TEST - SM0,DM1 - <N:C> = 0110
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [161,266,267,226,365,367,375,016] FC 1,3,8

                                ;ACT BUTS:      37[004]100,161 / 33[266]220,226 / 16[367]016,016

                                ;EXEC:          [365]ALUC=LLHHL :[367] D = 177777

                                ;CODES:         [367] SPS=3  /  N:C = 1001

                                ;SYNC:          B05J2 (-) T = 2.7 USEC

                                ;KEY SIG:       K3-8 CIN00 L  /  K3-3 ADD+SUB L  /  K3-3 SM=0L  /  K3-3 DM=1L

032720  012700  000435          T0435:  MOV     #0435,R0                ;LOAD R0 WITH TEST NO.
032724  013701  032752                  MOV     @#I0435,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
032730  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
032734  012704  177777                  MOV     #-1,R4          ;RESULT S / B = 177777
032740  012705  000001                  MOV     #+1,R5          ;SRC OPR = +1
032744  005012                  R0435:  CLR     (R2)            ;[DEST] = 000000
032746  000257                          CCC                     ;CLEAR FLAGS
032750  000266                          266                     ;N:C = 0110

032752  160512                  I0435:  SUB     R5,(R2)         ;TEST THE SUB

032754  100003                          BPL     E10435          ;N:C = 1001
032756  001402                          BEQ     E10435
032760  102401                          BVS     E10435
032762  103402                          BCS     A0435

032764  104005                  E10435: ERROR5                  ;SUB FAILED TO ALTER CODES PROPERLY
032766  032744                          R0435                   ;ERROR LOOP RETURN ADDRESS

032770  020412                  A0435:  CMP     R4,(R2)         ;CORRECT RESULT ?
032772  001403                          BEQ     00435           ;BR IF YES

032774  011203                          MOV     (R2),R3         ;GET THE WAS DATA
032776  104000                  E20435: ERROR                   ;SUB DELIVERED THE WRONG RESULT
033000  032744                          R0435                   ;ERROR LOOP RETURN ADDRESS

033002  000004                  00435:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0436 SUB TEST - SM0,DM1 - <N:C> = 1010
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       1616,266,267,226,365,367,375,016] FC 1,3,8

                                ;ACT BUTS:      37[004]100,161 / 33[266]220,226 / 16[367]016,016

                                ;EXEC:          [365]ALUC=LLHHL :[367] D = 000000

                                ;CODES:         [367] SPS=3  /  N:C = 0100

                                ;SYNC:          B05J2 (-) T = 2.7 USEC

                                ;KEY SIG:       K3-8 CINOO L  /  K3-3 ADD+SUB L  /  K3-3 SM=0L  /  K3-3 DM=1L

033004  012700  000436          T0436:  MOV     #0436,R0                ;LOAD R0 WITH TEST NO.
033010  013701  033036                  MOV     @#I0436,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
033014  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
033020  005004                          CLR     R4              ;RESULT S / B = 000000
033022  012705  177777                  MOV     #-1,R5          ;SRC OPR = 177777
033026  012712  177777          R0436:  MOV     #-1,(R2)        ;[DEST] = 177777
033032  000257                          CCC                     ;CLEAR FLAGS
033034  000272                          272                     ;N:C = 1010

033036  160512                  I0436:  SUB     R5,(R2)         ;TEST THE SUB

033040  100403                          BMI     E10436          ;N:C = 0100
033042  001002                          BNE     E10436
033044  102401                          BVS     E10436
033046  103002                          BCC     A0436

033050  104005                  E10436: ERROR5                  ;SUB FAILED TO ALTER CODES PROPERLY
033052  033026                          R0436                   ;ERROR LOOP RETURN ADDRESS

033054  020412                  A0436:  CMP     R4,(R2)         ;CORRECT RESULT ?
033056  001403                          BEQ     00436           ;BR IF YES

033060  011203                          MOV     (R2),R3         ;GET THE WAS DATA
033062  10 000                  E20436: ERROR                   ;SUB DELIVERED THE WRONG RESULT
033064  033026                          R0436                   ;ERROR LOOP RETURN ADDRESS

033066  000004                  00436:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0437 SUB TEST - SM0,DM1 - (N:C) = 0000
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [161,266,267,226,365,367,375,016] FC 1,3,8

                                ;ACT BUTS:      37[004]100,161 / 33[266]220,226 / 16[367]016,016

                                ;EXEC:          [365]ALUC=LLHHL :[367] D = 77777

                                ;CODES:         [367] SPS=3  /  N:C = 0010

                                ;SYNC:          B05J2 (-) T = 2.7 USEC

                                ;KEY SIG:       K3-8 CIN00 L  /  K3-3 ADD+SUB L  /  K3-3 SM=0L  /  K3-3 DM=1L

033070  012700  000437          T0437:  MOV     #0437,R0                ;LOAD R0 WITH TEST NO.
033074  013701  033122                  MOV     @#I0437,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
033100  012702  067602                  MOV     #^MBUF0,R2      ;DEST ADDR = MBUF0
033104  012704  077777                  MOV     #77777,R4       ;RESULT S / B = 77777
033110  012705  000001                  MOV     #+1,R5          ;SRC OPR = +1
033114  012712  100000          R0437:  MOV     #100000,(R2)    ;[DEST] = 100000
033120  000257                          CCC                     ;CLEAR FLAGS

033122  160512                  I0437:  SUB     R5,(R2)         ;TEST THE SUB

033124  100403                          BMI     E10437          ;N:C = 0010
033126  001402                          BEQ     E10437
033130  102001                          BVC     E10437
033132  103002                          BCC     A0437

033134  104005                  E10437: ERROR5                  ;SUB FAILED TO ALTER CODES PROPERLY
033136  033114                          R0437                   ;ERROR LOOP RETURN ADDRESS

033140  020412                  A0437:  CMP     R4,(R2)         ;CORRECT RESULT ?
033142  001403                          BEQ     00437           ;BR IF YES

033144  011203                          MOV     (R2),R3         ;GET THE WAS DATA
033146  104000                  E20437: ERROR                   ;SUB DELIVERED THE WRONG RESULT
033150  033114                          R0437                   ;ERROR LOOP RETURN ADDRESS

033152  000004                  00437:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0440 SUB TEST - SM1,DM0 - (N:C) = 0110
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [141,247,250,121,370,360,000] FC 1,2,8

                                ;ACT BUTS:      37[004]100,141 / 35[247]120,121 / 27[370]000,000

                                ;EXEC:          [370]ALUC=LLHHL :[360] D = 177777

                                ;CODES:         [360] SPS=3  /  N:C = 1001

                                ;SYNC:          B05J2 (-) T = 2.7 USEC

                                ;KEY SIG:       K3-8 CIN00 L  /  K3-3 ADD+SUB L  /  K3-3 SM=1L  /  K3-3 DM=0L

033154  012700  000440          T0440:  MOV     #0440,R0                ;LOAD R0 WITH TEST NO.
033160  013701  033206                  MOV     @#I0440,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
033164  012702  177703                  MOV     #177703,R2      ;DEST ADDR = R3
033170  012704  177777                  MOV     #-1,R4          ;RESULT S / B = 177777
033174  012705  070140                  MOV     #DWTB+2,R5      ;SRC ADDR = DWTB+2
033200  005003                  R0440:  CLR     R3              ;[DEST] = 000000
033202  000257                          CCC                     ;CLEAR FLAGS
033204  000266                          266                     ;N:C = 0110

033206  161503                  I0440:  SUB     (R5),R3         ;TEST THE SUB

033210  100003                          BPL     E10440          ;N:C = 1001
033212  001402                          BEQ     E10440
033214  102401                          BVS     E10440
033216  103402                          BCS     A0440

033220  104005                  E10440: ERROR5                  ;SUB FAILED TO ALTER CODES PROPERLY
033222  033200                          R0440                   ;ERROR LOOP RETURN ADDRESS

033224  020403                  A0440:  CMP     R4,R3           ;CORRECT RESULT ?
033226  001402                          BEQ     00440           ;BR IF YES

033230  104000                  E20440: ERROR                   ;SUB DELIVERED THE WRONG RESULT
033232  033200                          R0440                   ;ERROR LOOP RETURN ADDRESS

033234  000004                  00440:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0441 SUB TEST - SM1,DM0 - <N:C> = 1010
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [141,247,250,121,370,360,000] FC 1,2,8

                                ;ACT BUTS:      37[004]100,141 / 35[247]120,121 / 27[370]000,000

                                ;EXEC:          [370]ALUC=LLHHL :[360] D = 000000

                                ;CODES:         [360] SPS=3  /  N:C = 0100

                                ;SYNC:          B05J2 (-) T = 2.7 USEC

                                ;KEY SIG:       K3-8 CIN00 L  /  K3-3 ADD+SUB L  /  K3-3 SM=1L  /  K3-3 DM=0L

033236  012700  000441          T0441:  MOV     #0441,R0                ;LOAD R0 WITH TEST NO.
033242  013701  033266                  MOV     @#I0441,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
033246  012702  177703                  MOV     #177703,R2      ;DEST ADDR = R3
033252  005004                          CLR     R4              ;RESULT S / B = 000000
033254  012705  067614                  MOV     #DWTA+2,R5      ;SRC ADDR = DWTA+2
033260  011503                  R0441:  MOV     (R5),R3         ;[DEST] = 177777
033262  000257                          CCC                     ;CLEAR FLAGS
033264  000272                          272                     ;N:C = 1010

033266  161503                  I0441:  SUB     (R5),R3 ;TEST THE SUB

033270  100403                          BMI     E10441          ;N:C = 0100
033272  001002                          BNE     E10441
033274  102401                          BVS     E10441
033276  103002                          BCC     A0441

033300  104005                  E10441: ERROR5                  ;SUB FAILED TO ALTER CODES PROPERLY
033302  033260                          R0441                   ;ERROR LOOP RETURN ADDRESS

033304  020403                  A0441:  CMP     R4,R3           ;CORRECT RESULT ?
033306  001402                          BEQ     00441           ;BR IF YES

033310  104000                  E20441: ERROR                   ;SUB DELIVERED THE WRONG RESULT
033312  033260                          R0441                   ;ERROR LOOP RETURN ADDRESS

033314  000004                  00441:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ******************************************************************
                                        .SBTTL T0442 SUB TEST - SM1,DM0 - (N:C) = 0000
                                ; ******************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [141,247,250,121,370,360,000] FC 1,2,8

                                ;ACT BUTS:      37[004]100,141 / 35[247]120,121 / 27[370]000,000

                                ;EXEC:          [370]ALUC=LLHHL :[360] D = 077777

                                ;CODES:         [360] SPS=3  /  N:C = 0010

                                ;SYNC:          B05J2 (-) T   2.7 USEC

                                ;KEY SIG:       K3-8 CIN00 L  /  K3-3 ADD+SUB L  /  K3-3 SM=1L  /  K3-3 DM=0L

033316  012700  000442          T0442:  MOV     #0442,R0                ;LOAD R0 WITH TEST NO.
033322  013701  033354                  MOV     @#I0442,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
033326  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
033332  012704  077777                  MOV     #77777,R4               ;RESULT S / B = 77777
033336  012705  067606                  MOV     #MBUF1,R5               ;SRC ADDR =MBUF1
033342  012703  100000          R0442:  MOV     #100000,R3      ;[DEST] = 100000
033346  012715  000001                  MOV     #+1,(R5)        ;SRC OPR = +1
033352  000257                          CCC                     ;CLEAR FLAGS

033354  161503                  I0442:  SUB     (R5),R3         ;TEST THE SUB

033356  100403                          BMI     E10442          ;N:C = 0010
033360  001402                          BEQ     E10442
033362  102001                          BVC     E10442
033364  103002                          BCC     A0442

033366  104005                  E10442: ERROR5                  ;SUB FAILED TO ALTER CODES PROPERLY
033370  033342                          R0442                   ;ERROR LOOP RETURN ADDRESS

033372  020403                  A0442:  CMP     R4,R3           ;CORRECT RESULT ?
033374  001402                          BEQ     00442           ;BR IF YES

033376  104000                  E20442: ERROR                   ;SUB DEL.VERED THE WRONG RESULT
033400  033342                          R0442                   ;ERROR LOOP RETURN ADDRESS

033402  000004                  00442:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ****************************************************************
                                        .SBTTL T0443 SUB  SM1.DM1 TEST - <N:C> = 0110
                                ; ****************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [141,247,250,161,266,267,227,365,367,375,016] FC 1,2,3,8

                                ;ACT BUTS:      37[004]100,141  /  35[247]120,161  /  33[266]220,227  /  16[367]016,016

                                ;EXEC:          [365]ALUC=LLHHL :[367]D=177777

                                ;CODES:         [367]SPS=3       /      N:C=1001

                                ;SYNC:          B05J2   (-)     T=3.4 USEC

                                ;KEY SIG:       K3-3 ADD+SUB L  /  K3-3 SM=1 L  /  K3-3 DM=1 L  /  K3-8 CINOD L

033404  012700  000443          T0443:  MOV     #0443,R0                ;LOAD R0 WITH TEST NO.
033410  013701  033444                  MOV     @#I0443,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
033414  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
033420  012704  177777                  MOV     #-1,R4          ;RESULT S / B = 177777
033424  012705  067606                  MOV     #MBUF1,R5       ;SOURCE ADDR = MBUF1
033430  012715  000001          R0443:  MOV     #+1,(R5)        ;[SOURCE] = 000001
033434  012712  000000                  MOV     #0,(R2)         ;[DEST] = 000000
033440  000257                          CCC                     ;CLEAR FLAGS
033442  000266                          266                     ;N:C = 0110

033444  161512                  I0443:  SUB     (R5),(R2)       ;TEST THE SUB

033446  100003                          BPL     E10443          ;N:C = 1001 ?
033450  001402                          BEQ     E10443
033452  102401                          BVS     E10443
033454  103402                          BCS     A0443

033456  104005                  E10443: ERROR5                  ;SUB FAILED TO ALTER CODES PROPERLY
033460  033430                          R0443                   ;ERROR LOOP RETURN ADDRESS

033462  020412                  A0443:  CMP     R4,(R2)         ;CORRECT RESULT ?
033464  001403                          BEQ     00443           ;BR IF YES

033466  011203                          MOV     (R2),R3         ;GET THE WAS DATA
033470  104000                  E20443: ERROR                   ;SUB DELIVERED THE WRONG RESULT
033472  033430                          R0443                   ;ERROR LOOP RETURN ADDRESS

033474  000004                  00443:  SCOPE                   ;CALL THE SCOPE LOOP UTILITY
```

```
                                        ; ***************************************************************
                                                .SBTTL T0444 SUB  SM1,DM2 TEST - (N:C) = 0110
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [141,247,250,162,260,267,227,365,367,375,016] FC 1,2,3,8

                                        ;ACT BUTS:      37[004]100,141  /  35[247]120,162  /  33[260]220,227  /  16[367]C16,016

                                        ;EXEC:          [365]ALUC=LLHHL :[367]D=177777

                                        ;CODES:         [367]SPS=3       /      N:C=1001

                                        ;SYNC:          B05J2   (-)     T=3.4 USEC

                                        ;KEY SIG:       K3-3 ADD+SUB L  /  K3-3 SM=1 L  /  K3-3 DM=2  /  K3-8 CINOO L
                                                        ;  K5-5 BCON(1+2) H

033476  012700  000444          T0444:  MOV     #0444,R0                ;LOAD R0 WITH TEST NO.
033502  013701  033552                  MOV     @#T0444,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
033506  032737  000400  066642          BIT     #400,@#BPTLOC   ;BREAKPOINT HALT SET ??
033514  001401                          BEQ     .+4             ;BR IF NOT
033516  000000                          HALT                    ;BREAK-DEPRESS CONTINUE TO RESTART
033520  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
033524  012704  177777                  MOV     #-1,R4          ;RESULT S / B = 177777
033530  012705  067606                  MOV     #MBUF1,R5       ;SOURCE ADDR = MBUF1
033534  012715  000001          R0444:  MOV     #+1,(R5)        ;[SOURCE] = 000001
033540  012712  000000                  MOV     #0,(R2)         ;[DEST] = 000000
033544  010203                          MOV     R2,R3           ;R3 GETS DEST ADDR
033546  000257                          CCC                     ;CLEAR FLAGS
033550  000266                          266                     ;N:C = 0110

033552  161523                  T0444:  SUB     (R5),(R3)+      ;TEST THE SUB

033554  100003                          BPL     E10444          ;N:C = 1001 ?
033556  001402                          BEQ     E10444
033560  102401                          BVS     E10444
033562  103402                          BCS     A0444

033564  104005                  E10444: ERROR5                  ;SUB FAILED TO ALTER CODES PROPERLY
033566  033534                          R0444                   ;ERROR LOOP RETURN ADDRESS

033570  020412                  A0444:  CMP     R4,(R2)         ;CORRECT RESULT ?
033572  001403                          BEQ     00444           ;BR IF YES

033574  011203                          MOV     (R2),R3         ;GET THE WAS DATA
033576  104000                  E20444: ERROR                   ;SUB DELIVERED THE WRONG RESULT
033600  033534                          R0444                   ;ERROR LOOP RETURN ADDRESS

033602  000004                  00444:  SCOPE                   ;CALL THE SCOPE LOOP UTILITY
```

```
                                        ; ***********************************************************************
                                                .SBTTL T0445 NEG DM2 TEST
                                        ; ***********************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [162,260,267,221,367,375,016] FC 1,3,9,8

                                        ;ACT BUTS:      37[004]100,162 / 33[260]220,221 / 16[367]016,016

                                        ;EXEC:          [221]ALUC=LLHHL :[367] D = 125252

                                        ;CODES:         [367] SPS=3  /  N:C = 1001

                                        ;SYNC:          BOSJ2 (-) T = 2 USEC

                                        ;KEY SIG:       K3-8 CINOO L  /  K3-3 DM=2L  /  K3-4 NEG L  /  K5-5 BCON(1+2)H

033604  012700  000445                  T0445:  MOV     #0445,R0                ;LOAD R0 WITH THE TEST NO.
033610  013701  033634                          MOV     @#I0445,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
033614  012702  067602                          MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
033620  012704  125252                          MOV     #125252,R4      ;RESULT S / B = 125252
033624  010205                          R0445:  MOV     R2,R5           ;[R5] = DEST ADDR
033626  012712  052526                          MOV     #52526,(R2)     ;[DEST] = 52526
033632  000257                                  CCC                     ;SCOPE SYNC

033634  005425                          I0445:  NEG     (R5)+           ;TEST THE NEG - MODE 2

033636  020412                                  CMP     R4,(R2)         ;RESULT = 125252?
033640  001403                                  BEQ     A0445           ;BR IF YES

033642  011203                                  MOV     (R2),R3         ;GET THE WAS DATA
033644  104000                          E10445: ERROR                   ;NEG DELIVERED WRONG RESULT
033646  033624                                  R0445                   ;ERROR LOOP RETURN

033650  022705  067604                  A0445:  CMP     #MBUF0+2,R5     ;DID REG. GET AUTO INCREMENTED?
033654  001402                                  BEQ     00445           ;BR IF YES

033656  104005                          E20445. ERROR5                  ;NEG FAILED TO UPDATE REG.
033660  033624                                  R0445                   ;ERROR LOOP RETURN

033662  000004                          00445:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***********************************************************************
                                                .SBTTL T0446 NEG DM3 TEST
                                        ; ***********************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [163,264,265,266,267,221,367,375,016] FC 1,3,9,8

                                        ;ACT BUTS:      37[004]100,163 / 33[266]210,221 / 16[367]016,016

                                        ;EXEC:          [221]ALUC=LLHHL :[367] D = 125252

                                        ;CODES:         [367] SPS=3  /  N:C = 1001

                                        ;SYNC:          B05J2 (-) T = 2.75 USEC

                                        ;KEY SIG:       K3-8 CINOO L  /  K3-3 DM=3L  /  K3-4 NEG L  /  K5-5 BC01 H

033664  012700  000446          T0446:  MOV     #0446,R0                ;LOAD R0 WITH THE TEST NO.
033670  013701  033716                  MOV     @#I0446,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
033674  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
033700  012704  125252                  MOV     #125252,R4      ;RESULT S / B = 125252
033704  012705  067576          R0446:  MOV     #ATA+10,R5      ;[ATA+10] = MBUF0
033710  012712  052526                  MOV     #52526,(R2)     ;[DEST] = 52526
033714  000257                          CCC                     ;SCOPE SYNC

033716  005435                  I0446:  NEG     @(R5)+          ;TEST THE NEG - MODE 3

033720  020412                          CMP     R4,(R2)         ;RESULT = 125252?
033722  001403                          BEQ     A0446           ;BR IF YES

033724  011203                          MOV     (R2),R3         ;GET WAS DATA
033726  104000                  E10446: ERROR                   ;NEG DELIVERED WRONG RESULT
033730  033704                          R0446                   ;ERROR LOOP RETURN

033732  022705  067600          A0446:  CMP     #ATA+12,R5      ;DID REG GET AUTO INCREMENTED?
033736  001402                          BEQ     00446           ;BR IF YES

033740  104005                  E20446: ERROR5                  ;NEG FAILED TO UPDATE REG.
033742  033704                          R0446                   ;ERROR LOOP RETURN

033744  000004                  00446:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0447 NEG DM4 TEST
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [164,260,267,221,367,375,061] FC 1,3,9,8

                                ;ACT BUTS:      37[004]100,164 / 33[260]220,221 / 16[367]016,016

                                ;EXEC:          [221]ALUC=LLHHL :[367] D = 125252

                                ;CODES:         [367] SPS=3  /  N:C = 1001

                                ;SYNC:          BOSJ2 (-) T = 2 USEC

                                ;KEY SIG:       K3-8 CINOO L  /  K3-3 DM=4L  /  K3-4 NEG L  /  K5-5 BCON(1+2) H

033746  012700  000447          T0447:  MOV     #0447,R0                ;LOAD R0 WITH THE TEST NO.
033752  013701  034000                  MOV     @#I0447,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
033756  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
033762  012704  125252                  MOV     #125252,R4      ;RESULT S / B = 125252
033766  012705  067604          R0447:  MOV     #MBUF0+2,R5     ;[R5] = DEST ADDR + 2
033772  012712  052526                  MOV     #52526,(R2)     ;[DEST] = 52526
033776  000257                          CCC                     ;SCOPE SYNC

034000  005445                  I0447:  NEG     -(R5)           ;TEST THE NEG - MODE 4

034002  020412                          CMP     R4,(R2)         ;RESULT = 125252?
034004  001403                          BEQ     A0447           ;BR IF YES

034006  011203                          MOV     (R2),R3         ;GET WAS DATA
034010  104000                  E10447: ERROR                   ;NEG DELIVERED WRONG RESULT
034012  033766                          R0447                   ;ERROR LOOP RETURN

034014  020502                  A0447:  CMP     R5,R2           ;DID REG GET AUTO INCREMENTED?
034016  001402                          BEQ     00447           ;BR IF YES

034020  104005                  E20447: ERROR5                  ;NEG FAILED TO UPDATE REG
034022  033766                          R0447                   ;ERROR LOOP RETURN

034024  000004                  00447:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***********************************************************
                                                .SBTTL T0450 NEG DM5 TEST
                                        ; ***********************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [165,264,265,266,267,221,367,375,016] FC 1,3,9,8

                                        ;ACT BUTS:      37[004]100,165 / 33[266]220,221 / 16[367]016,016

                                        ;EXEC:          [221]ALUC=LLHHL :[367] D = 125252

                                        ;CODES:         [367] SPS=3  /  N:C = 1001

                                        ;SYNC:          B05J2 (-) T = 2 USEC

                                        ;KEY SIG:       K3-8 CINOD L  /  K3-3 DM=5L  /  K3-4 NEG L  /  K5-5 BCD1 H

034026  012700  000450                  T0450:  MOV     #0450,R0                ;LOAD R0 WITH THE TEST NO.
034032  013701  034060                          MOV     @#T0450,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
034036  012702  067602                          MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
034042  012704  125252                          MOV     #125252,R4      ;RESULT S / B = 125252
034046  012705  067600                  R0450:  MOV     #ATA+12,R5      ;[R5] = (ADR OF MBUF0) +2
034052  012712  052526                          MOV     #52526,(R2)     ;[DEST] = 52526
034056  000257                                  CCC                     ;SCOPE SYNC

034060  005455                          T0450:  NEG     @-(R5)          ;TEST THE NEG - MODE 5

034062  020412                                  CMP     R4,(R2)         ;RESULT = 125252?
034064  001403                                  BEQ     A0450           ;BR IF YES

034066  011203                                  MOV     (R2),R3         ;GET WAS DATA
034070  104000                          E0450:  ERROR                   ;NEG DELIVERED WRONG RESULT
034072  034046                                  R0450                   ;ERROR LOOP RETURN

034074  022705  067576                  A0450:  CMP     #ATA+10,R5      ;DID NEG UPDATE REG
034100  001402                                  BEQ     00450           ;BR IF YES

034102  104005                          E20450: ERROR5                  ;NEG FAILED TO UPDATE REG
034104  034046                                  R0450                   ;ERROR LOOP RETURN

034106  000004                          00450:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***********************************************************************
                                                .SBTTL T0451 NEG DM6 TEST
                                        ; ***********************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [166,261,262,266,267,221,367,375,016] FC 1,3,9,8

                                        ;ACT BUTS:      37[004]100,166 / 33[266]220,221 / 16[367]016,016

                                        ;EXEC:          [221]ALUC=LLHHL :[367] D = 125252

                                        ;CODES:         [367] SPS=3  /  N:C = 1001

                                        ;SYNC:          B05J2 (-) T = 2.5 USEC

                                        ;KEY SIG:       K3-8 CIN00 L  /  K3-3 DM=6L  /  K5-5 BC01 H
                                                        ;  K3-4 OVLAP CYCLE L

034110  012700  000451          T0451:  MOV     #0451,R0                ;LOAD R0 WITH THE TEST NO.
034114  013701  034142                  MOV     @#T0451,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
034120  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
034124  012704  125252                  MOV     #125252,R4      ;RESULT S / B = 125252
034130  012705  067600          R0451:  MOV     #MBUF0-2,R5     ;[R5] = BASE ADDR
034134  012712  052526                  MOV     #52526,(R2)     ;[DEST] = 52526
034140  000257                          CCC                     ;SCOPE SYNC

034142  005465  000002          T0451:  NEG     2(R5)           ;TEST THE NEG - MODE 6

034146  020412                          CMP     R4,(R2)         ;RESULT = 125252?
034150  001403                          BEQ     00451           ;BR IF YES

034152  011203                          MOV     (R2),R3         ;GET WAS DATA
034154  104000          E0451:  ERROR                           ;NEG DELIVERED WRONG RESULT
034156  034130                  R0451                           ;ERROR LOOP RETURN

034160  000004          00451:  SCOPE                           ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0452 NEG DM7 TEST
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [166,261,263,264,265,266,267,221,367,375,016] FC 1,3,9,8

                                ;ACT BUTS:      37[004]100,166 / 33[266]220,221 / 16[367]016,016

                                ;EXEC:          [221]ALUC=LLHHL :[367] D = 125252

                                ;CODES:         [367] SPS=3  /  N:C = 1001

                                ;SYNC:          B05J2 (-) T = 3.5 USEC

                                ;KEY SIG:       K3-8 CINOO L  /  K3-3 DM=7L  /  K3-4 NEG L  /  K5-5 BCO1 H
                                                ;  K3-4 OVLAP CYCLE L

034162  012700  000452          T0452:  MOV     #0452,R0                ;LOAD R0 WITH THE TEST NO.
034166  013701  034214                  MOV     @#I0452,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
034172  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
034176  012704  125252                  MOV     #125252,R4      ;RESULT S / B = 125252
034202  012705  067566          R0452:  MOV     #ATA,R5         ;[R5] = BASE ADDR
034206  012712  052526                  MOV     #52526,(R2)     ;[DEST] = 52526
034212  000257                          CCC                     ;SCOPE SYNC

034214  005475  000010          I0452:  NEG     @10(R5)         ;TEST THE NEG - MODE 7

034220  020412                          CMP     R4,(R2)         ;RESULT = 125252?
034222  001403                          BEQ     00452           ;BR IF YES

034224  011203                          MOV     (R2),R3         ;GET WAS DATA
034226  104000          E0452:  ERROR                           ;NEG DELIVERED WRONG RESULT
034230  034202                  R0452                           ;ERROR LOOP RETURN

034232  000004          00452:  SCOPE                           ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***************************************************************
                                                .SBTTL T0453 MOV SM1,DM1 TEST - <N:C> = 0100
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [141,247,250,171,257,200,125,375,016] FC 1,2,4,8

                                        ;ACT BUTS:      37[004]100,141 / 35[247]120,171 / 22[171]200,200 / 16[125]016,016

                                        ;EXEC:          [200]ALUC=LLLLL :[]25] D = 177777

                                        ;CODES:         [125] SPS=3  /  N:C = 1000

                                        ;SYNC:          B05J2 (--) T = 3.25 USEC

                                        ;KEY SIG:       K3-3 SM=1L  /  K3-3 DM=1L  /  K3-3 MOV L

034234  012700  000453          T0453:  MOV     #0453,R0                ;LOAD R0 WITH TEST NO.
034240  013701  034270                  MOV     @#I0453,R1      ;LOAD R1 WITH TEST INSTRUCTION  WORD
034244  005004                          CLR     R4              ;RESULT S / B = 177777
034246  005104                          COM     R4
034250  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
034254  012705  067614                  MOV     #DWTA+2,R5      ;SOURCE ADDR = DWTA+2
034260  010203                  R0453:  MOV     R2,R3           ;BASE DEST ADDR = MBUF0
034262  005012                          CLR     (R2)            ;MAKE [DEST] = 000000
034264  000257                          CCC                     ;CLEAR FLAGS
034266  000264                          264                     ;N:C = 0100

034270  011513                  I0453:  MOV     (R5),(R3)       ;TEST THE MOV - SM1,DM1

034272  100003                          BPL     E10453          ;N:C = 1000 ?
034274  001402                          BEQ     E10453
034276  102401                          BVS     E10453
034300  103002                          BCC     A0453

034302  104005                  E10453: ERROR5                  ;MOV FAILED TO ALTER CODES PROPERLY
034304  034260                          R0453                   ;ERROR LOOP RETURN

034306  020412                  A0453:  CMP     R4,(R2)         ;RESULT CORRECT ??
034310  001404                          BEQ     00453           ;BR IF YES

034312  005003                          CLR     R3              ;GET THE WAS DATA
034314  051203                          BIS     (R2),R3
034316  104000                  E20453: ERROR                   ;MOV DELIVERED THE WRONG RESULT
034320  034260                          R0453                   ;ERROR LOOP RETURN

034322  000004                  00453:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0454 MOV SM2,DM1 TEST - <N:C> = 0100
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [142,240,250,171,257,200,125,375,016] FC 1,2,4,8

                                ;ACT BUTS:      37[004]100,142 / 35[240]120,171 / 22[171]200,200 / 16[125]016,016

                                ;EXEC:          [200]ALUC=LLLLL :[125] D = 177777

                                ;CODES:         [125] SPS=3  /  N:C = 1000

                                ;SYNC:          B05J2 (-) T = 3.25 USEC

                                ;KEY SIG:       K3-3 SM=2L  /  K3-3 DM=1L  /  K3-3 MOV L  /  K5-5 BCON (1+2) H

034324  012700  000454          T0454:  MOV     #0454,R0                ;LOAD R0 WITH TEST NO.
034330  013701  034360                  MOV     @#I0454,R1      ;LOAD R1 WITH TEST INSTRUCTION  WORD
034334  005004                          CLR     R4              ;RESULT S / B = 177777
034336  005104                          COM     R4
034340  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
034344  012705  067614                  MOV     #DWTA+2,R5      ;SOURCE ADDR = DWTA+2
034350  010203                  R0454:  MOV     R2,R3           ;BASE DEST ADDR = MBUF0
034352  005012                          CLR     (R2)            ;MAKE [DEST] = 000000
034354  000257                          CCC                     ;CLEAR FLAGS
034356  000264                          264                     ;N:C = 0100

034360  012513                  I0454:  MOV     (R5)+,(R3)      ;TEST THE MOV - SM2,DM1

034362  100003                          BPL     E10454          ;N:C = 1000 ?
034364  001402                          BEQ     E10454
034366  102401                          BVS     E10454
034370  103002                          BCC     A0454

034372  104005                  E10454: ERROR5                  ;MOV FAILED TO ALTER CODES PROPERLY
034374  034350                          R0454                   ;ERROR LOOP RETURN

034376  020412                  A0454:  CMP     R4,(R2)         ;RESULT CORRECT ??
034400  001404                          BEQ     00454           ;BR IF YES

034402  005003                          CLR     R3              ;GET THE WAS DATA
034404  051203                          BIS     (R2),R3
034406  104000                  E20454: ERROR                   ;MOV DELIVERED THE WRONG RESULT
034410  034350                          R0454                   ;ERROR LOOP RETURN

034412  000004                  00454:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***********************************************************************
                                        .SBTTL T0455 MOV SM1,DM1 TEST - <N:C> = 1011
                                ; ***********************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [142,247,250,171,257,200,125,375,016] FC 1,2,4,8

                                ;ACT BUTS:      37[004]100,142 / 35[247]120,171 / 22[171]200,200 / 16[125]016,016

                                ;EXEC:          [200]ALUC=LLLLL :[125] D = 000000

                                ;CODES:         [125] SPS=3  /  N:C = 0101

                                ;SYNC:          BOSJ2 (-) T = 3.25 USEC

                                ;KEY SIG:       K3-3 SM=1L  /  K3-3 DM=1L  /  K3-3 MOV L

034414  012700  000455          T0455:  MOV     #0455,R0                ;LOAD R0 WITH TEST NO.
034420  013701  034450                  MOV     @#T0455,R1      ;LOAD R1 WITH TEST INSTRUCTION  WORD
034424  005004                          CLR     R4              ;RESULT S / B = 000000
034426  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
034432  012705  067612                  MOV     #DWTA,R5        ;SOURCE ADDR = DWTA
034436  010203                  R0455:  MOV     R2,R3           ;BASE DEST ADDR = MBUF0
034440  005012                          CLR     (R2)            ;MAKE [DEST] = 177777
034442  005112                          COM     (R2)
034444  000257                          CCC                     ;CLEAR FLAGS
034446  000273                          273                     ;N:C = 1011

034450  011513                  I0455:  MOV     (R5),(R3)       ;TEST THE MOV - SM1,DM1

034452  100403                          BMI     E10455          ;N:C = 0101 ?
034454  001002                          BNE     E10455
034456  102401                          BVS     E10455
034460  103402                          BCS     A0455

034462  104005                  E10455: ERROR5                  ;MOV FAILED TO ALTER CODES PROPERLY
034464  034436                          R0455                   ;ERROR LOOP RETURN

034466  020412                  A0455:  CMP     R4,(R2)         ;RESULT CORRECT ??
034470  001404                          BEQ     00455           ;BR IF YES

034472  005003                          CLR     R3              ;GET THE WAS DATA
034474  051203                          BIS     (R2),R3
034476  104000                  E20455: ERROR                   ;MOV DELIVERED THE WRONG RESULT
034500  034436                          R0455                   ;ERROR LOOP RETURN

034502  000004                  00455:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***********************************************************************
                                        .SBTTL T0456 MOV SM2,DM1 TEST - <N:C> = 1011
                                ; ***********************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [142,240,250,171,257,200,125,375,016] FC 1,2,4,8

                                ;ACT BUTS:      37[004]100,142 / 35[240]120,171 / 22[171]200,200 / 16[125]016,016

                                ;EXEC:          [200]ALUC=LLLLL :[125] D = 000000

                                ;CODES:         [125] SP=3  /  N:C = 0101

                                ;SYNC:          B05J2 (-) T = 3.25 USEC

                                ;KEY SIG:       K3-3 SM=2L  /  K3-3 DM=1L  /  K3-3 MOV L  /  K5-5 BCON (1+2) H

034504  012700  000456          T0456:  MOV     #0456,R0                ;LOAD R0 WITH TEST NO.
034510  013701  034540                  MOV     @#I0456,R1      ;LOAD R1 WITH TEST INSTRUCTION  WORD
034514  005004                          CLR     R4              ;RESULT S / B = 000000
034516  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
034522  012705  067612                  MOV     #DWTA,R5        ;SOURCE ADDR = DWTA
034526  010203                  R0456:  MOV     R2,R3           ;BASE DEST ADDR = MBUF0
034530  005012                          CLR     (R2)            ;MAKE [DEST] = 177777
034532  005112                          COM     (R2)
034534  000257                          CCC                     ;CLEAR FLAGS
034536  000273                          273                     ;N:C = 1011

034540  012513                  I0456:  MOV     (R5)+,(R3)      ;TEST THE MOV - SM2,DM1

034542  100403                          BMI     E10456          ;N:C = 0101 ?
034544  001002                          BNE     E10456
034546  102401                          BVS     E10456
034550  103402                          BCS     A0456

034552  104005                  E10456: ERROR5                  ;MOV FAILED TO ALTER CODES PROPERLY
034554  034526                          R0456                   ;ERROR LOOP RETURN

034556  020412                  A0456:  CMP     R4,(R2)         ;RESULT CORRECT ??
034560  001404                          BEQ     00456           ;BR IF YES

034562  005003                          CLR     R3              ;GET THE WAS DATA
034564  051203                          BIS     (R2),R3
034566  104000                  E20456: ERROR                   ;MOV DELIVERED THE WRONG RESULT
034570  034526                          R0456                   ;ERROR LOOP RETURN

034572  000004                  00456:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***********************************************************************
                                                .SBTTL T0457 MOV SM1,DM2 TEST - <N:C> = 0100
                                        ; ***********************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [141,247,250,172,257,200,125,375,016] FC 1,2,4,8

                                        ;ACT BUTS:      37[004]100,141 / 35[247]120,172 / 22[172]200,200 / 16[125]016,016

                                        ;EXEC:          [200]ALUC=LLLLL :[125] D = 177777

                                        ;CODES:         [125] SPS=3  /  N:C = 1000

                                        ;SYNC:          B05J2 (-) T = 3.25 USEC

                                        ;KEY SIG:       K3-3 SM=1L  /  K3-3 DM=2L  /  K3-3 MOV L  /  K5-5 BCON (1+2) H

034574  012700  000457          T0457:  MOV     #0457,R0                ;LOAD R0 WITH TEST NO.
034600  013701  034630                  MOV     @#I0457,R1      ;LOAD R1 WITH TEST INSTRUCTION  WORD
034604  005004                          CLR     R4              ;RESULT S / B = 177777
034606  005104                          COM     R4
034610  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
034614  012705  067614                  MOV     #DWTA+2,R5      ;SOURCE ADDR = DWTA
034620  010203                  R0457:  MOV     R2,R3           ;BASE DEST ADDR = MBUF0
034622  005012                          CLR     (R2)            ;MAKE [DEST] = 000000
034624  000257                          CCC                     ;CLEAR FLAGS
034626  000264                          264                     ;N:C = 0100

034630  011523                  I0457:  MOV     (R5),(R3)+      ;TEST THE MOV - SM1,DM2

034632  100003                          BPL     E10457          ;N:C =  1000 ?
034634  001402                          BEQ     E10457
034636  102401                          BVS     E10457
034640  103002                          BCC     A0457

034642  104005                  E1C457: ERROR5                  ;MOV FAILED TO ALTER CODES PROPERLY
034644  034620                          R0457                   ;ERROR LOOP RETURN

034646  022703  067604          A0457:  CMP     #MBUF0+2,R3     ;DID MOV INCREMENT DEST REG ?
034652  001402                          BEQ     B0457           ;BR IF YES

034654  104005                  E20457: ERROR5                  ;MOV FAILED TO UPDATE DEST REG
034656  034620                          R0457                   ;ERROR LOOP RETURN

034660  020412                  B0457:  CMP     R4,(R2)         ;RESULT CORRECT ??
034662  001404                          BEQ     00457           ;BR IF YES

034664  005003                          CLR     R3              ;GET THE WAS DATA
034666  051203                          BIS     (R2),R3
034670  104000                  E30457: ERROR                   ;MOV DELIVERED THE WRONG RESULT
034672  034620                          R0457                   ;ERROR LOOP RETURN

034674  000004                  00457:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***********************************************************************
                                                .SBTTL T0460 MOV SM2,DM2 TEST - (N:C) = 0100
                                        ; ***********************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [142,240,250,172,257,200,125,375,016] FC 1,2,4,8

                                        ;ACT BUTS:      37[004]100,142 / 35[240]120,172 / 22[172]200,200 / 16[125]016,016

                                        ;EXEC:          [200]ALUC=LLLLL :[125] D = 177777

                                        ;CODES:         [125] SPS=3  /  N:C = 1000

                                        ;SYNC:          BOSJ2 (-) T = 3.25 USEC

                                        ;KEY SIG:       K3-3 SM=2L  /  K3-3 DM=2L  /  K3-3 MOV L  /  K5-5 BCON (1+2) H

034676  012700  000460          T0460:  MOV     #0460,R0                ;LOAD R0 WITH TEST NO.
034702  013701  034732                  MOV     @#I0460,R1      ;LOAD R1 WITH TEST INSTRUCTION  WORD
034706  005004                          CLR     R4              ;RESULT S / B = 177777
034710  005104                          COM     R4
034712  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
034716  012705  067614                  MOV     #DWTA+2,R5      ;SOURCE ADDR = DWTA
034722  010203                  R0460:  MOV     R2,R3           ;BASE DEST ADDR = MBUF0
034724  005012                          CLR     (R2)            ;MAKE [DEST] = 000000
034726  000257                          CCC                     ;CLEAR FLAGS
034730  000264                          264                     ;N:C = 0100

034732  012523                  I0460:  MOV     (R5)+,(R3)+     ;TEST THE MOV - SM2,DM2

034734  100003                          BPL     E10460          ;N:C = 1000 ?
034736  001402                          BEQ     E10460
034740  102401                          BVS     E10460
034742  103002                          BCC     A0460

034744  104005                  E10460: ERROR5                  ;MOV FAILED TO ALTER CODES PROPERLY
034746  034722                          R0460                   ;ERROR LOOP RETURN

034750  022703  067604          A0460:  CMP     #MBUF0+2,R3     ;DID MOV INCREMENT DEST REG ?
034754  001402                          BEQ     B0460           ;BR IF YES

034756  104005                  E20460: ERROR5                  ;MOV FAILED TO UPDATE DEST REG
034760  034722                          R0460                   ;ERROR LOOP RETURN

034762  020412                  B0460:  CMP     R4,(R2)         ;RESULT CORRECT ??
034764  001404                          BEQ     00460           ;BR IF YES

034766  005003                          CLR     R3              ;GET THE WAS DATA
034770  051203                          BIS     (R2),R3
034772  104000                  E30460: ERROR                   ;MOV DELIVERED THE WRONG RESULT
034774  034722                          R0460                   ;ERROR LOOP RETURN

034776  000004                  00460:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***********************************************************************
                                                .SBTTL T0461 MOV SM1,DM2 TEST - <N:C> = 1011
                                        ; ***********************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [141,247,250,172,257,200,125,375,016] FC 1,2,4,8

                                        ;ACT BUTS:      37[004]100,141 / 35[247]120,172 / 22[172]200,200 / 16[125]016,016

                                        ;EXEC:          [200]ALUC=LLLLL :[125] D = 000000

                                        ;CODES:         [125] SPS=3  /  N:C = 0101

                                        ;SYNC:          B05J2 (-) T = 3.25 USEC

                                        ;KEY SIG:       K3-3 SM=1L  /  K3-3 DM=2L  /  K3-3 MOV L  /  K5-5 BCON (1+2) H

035000  012700  000461          T0461:  MOV     #0461,R0                ;LOAD R0 WITH TEST NO.
035004  013701  035034                  MOV     @#I0461,R1      ;LOAD R1 WITH TEST INSTRUCTION  WORD
035010  005004                          CLR     R4              ;RESULT S / B = 000000
035012  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
035016  012705  067612                  MOV     #DWTA,R5        ;SOURCE ADDR = DWTA
035022  010203                  R0461:  MOV     R2,R3           ;BASE DEST ADDR = MBUF0
035024  005012                          CLR     (R2)            ;MAKE [DEST] = 177777
035026  005112                          COM     (R2)
035030  000257                          CCC                     ;CLEAR FLAGS
035032  000273                          273                     ;N:C = 1011

035034  011523                  I0461:  MOV     (R5),(R3)+      ;TEST THE MOV - SM1,DM2

035036  100403                          BMI     E10461          ;N:C = 0101 ?
035040  001002                          BNE     E10461
035042  102401                          BVS     E10461
035044  103402                          BCS     A0461

035046  104005                  E10461: ERROR5                  ;MOV FAILED TO ALTER CODES PROPERLY
035050  035022                          R0461                   ;ERROR LOOP RETURN

035052  022703  067604          A0461:  CMP     #MBUF0+2,R3     ;DID MOV INCREMENT DEST REG ?
035056  001402                          BEQ     B0461           ;BR IF YES

035060  104005                  E20461: ERROR5                  ;MOV FAILED TO UPDATE DEST REG
035062  035022                          R0461                   ;ERROR LOOP RETURN

035064  020412                  B0461:  CMP     R4,(R2)         ;RESULT CORRECT ??
035066  001404                          BEQ     00461           ;BR IF YES

035070  005003                          CLR     R3              ;GET THE WAS DATA
035072  051203                          BIS     (R2),R3
035074  104000                  E30461: ERROR                   ;MOV DELIVERED THE WRONG RESULT
035076  035022                          R0461                   ;ERROR LOOP RETURN

035100  000004                  00461:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***********************************************************************
                                        .SBTTL T0462 MOV SM2,DM2 TEST - (N:C) = 1011
                                ; ***********************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [142,240,250,172,257,200,125,375,016] FC 1,2,4,8

                                ;ACT BUTS:      37[004]100,142 / 35[240]120,172 / 22[172]200,200 / 16[125]016,016

                                ;EXEC:          [200]ALUC=LLLLL :[125] D = 000000

                                ;CODES:         [125] SPS=3  /  N:C = 0101

                                ;SYNC:          BOSJ2 (-) T = 3.25 USEC

                                ;KEY SIG:       K3-3 SM=2L  /  K3-3 DM=2L  /  K3-3 MOV L  /  K5-5 BCON (1+2) H

035102  012700  000462          T0462:  MOV     #0462,R0                ;LOAD R0 WITH TEST NO.
035106  013701  035136                  MOV     @#T0462,R1      ;LOAD R1 WITH TEST INSTRUCTION  WORD
035112  005004                          CLR     R4              ;RESULT S / B = 000000
035114  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
035120  012705  067612                  MOV     #DWTA,R5        ;SOURCE ADDR = DWTA
035124  010203                  R0462:  MOV     R2,R3           ;BASE DEST ADDR = MBUF0
035126  005012                          CLR     (R2)            ;MAKE [DEST] = 177777
035130  005112                          COM     (R2)
035132  000257                          CCC                     ;CLEAR FLAGS
035134  000273                          273                     ;N:C = 1011

035136  012523                  T0462:  MOV     (R5)+,(R3)+     ;TEST THE MOV - SM2,DM2

035140  100403                          BMI     E10462          ;N:C = 0101 ?
035142  001002                          BNE     E10462
035144  102401                          BVS     E10462
035146  103402                          BCS     A0462

035150  104005                  E10462: ERROR5                  ;MOV FAILED TO ALTER CODES PROPERLY
035152  035124                          R0462                   ;ERROR LOOP RETURN

035154  022703  067604          A0462:  CMP     #MBUF0+2,R3     ;DID MOV INCREMENT DEST REG ?
035160  001402                          BEQ     B0462           ;BR IF YES

035162  104005                  E20462: ERROR5                  ;MOV FAILED TO UPDATE DEST REG
035164  035124                          R0462                   ;ERROR LOOP RETURN

035166  020412                  B0462:  CMP     R4,(R2)         ;RESULT CORRECT ??
035170  001404                          BEQ     C0462           ;BR IF YES

035172  005003                          CLR     R3              ;GET THE WAS DATA
035174  051203                          BIS     (R2),R3
035176  104000                  E30462: ERROR                   ;MOV DELIVERED THE WRONG RESULT
035200  035124                          R0462                   ;ERROR LOOP RETURN

035202  000004                  C0462:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***********************************************************************
                                        .SBTTL T0463 MOV SM1,DM3 TEST - <N:C> = 0100
                                ; ***********************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [141,247,250,173,207,2010,200,125,375,016] FC 1,2,4,8

                                ;ACT BUTS:      37[004]100,141 / 35[247]120,173 / 22[207]200,200 / 16[125]016,016

                                ;EXEC:          [200]ALUC=LLLLL :[125] D = 177777

                                ;CODES:         [125] SPS=3  /  N:C = 1000

                                ;SYNC:          BOSJ2 (-) T = 4 USEC

                                ;KEY SIG:       K3-3 SM=1L  /  K3-3 DM=3L  /  K3-3 MOV L  /  K5-5 BC01 H

035204  012700  000463          T0463:  MOV     #0463,R0                ;LOAD R0 WITH TEST NO.
035210  013701  035242                  MOV     @#I0463,R1      ;LOAD R1 WITH TEST INSTRUCTION  WORD
035214  005004                          CLR     R4              ;RESULT S / B = 177777
035216  005104                          COM     R4
035220  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
035224  012705  067614                  MOV     #DWTA+2,R5      ;SOURCE ADDR = DWTA+2
035230  012703  067576          R0463:  MOV     #ATA+10,R3      ;BASE DEST ADDR = ATA+10
035234  005012                          CLR     (R2)            ;MAKE [DEST] = 000000
035236  000257                          CCC                     ;CLEAR FLAGS
035240  000264                          264                     ;N:C = 0100

035242  011533                  I0463:  MOV     (R5),@(R3)+     ;TEST THE MOV - SM1,DM3

035244  100003                          BPL     E10463          ;N:C = 1000 ?
035246  001402                          BEQ     E10463
035250  102401                          BVS     E10463
035252  103002                          BCC     A0463

035254  104005                  E10463: ERROR5                  ;MOV FAILED TO ALTER CODES PROPERLY
035256  035230                          R0463                   ;ERROR LOOP RETURN

035260  022703  067600          A0463:  CMP     #ATA+12,R3      ;DID MOV INCREMENT DEST REG ?
035264  001402                          BEQ     B0463           ;BR IF YES

035266  104005                  E20463: ERROR5                  ;MOV FAILED TO UPDATE DEST REG
035270  035230                          R0463                   ;ERROR LOOP RETURN

035272  020412                  B0463:  CMP     R4,(R2)         ;RESULT CORRECT ??
035274  001404                          BEQ     00463           ;BR IF YES

035276  005003                          CLR     R3              ;GET THE WAS DATA
035300  051203                          BIS     (R2),R3
035302  104000                  E30463: ERROR                   ;MOV DELIVERED THE WRONG RESULT
035304  035230                          R0463                   ;ERROR LOOP RETURN

035306  000004                  00463:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***********************************************************************
                                        .SBTTL T0464 MOV SM2,DM3 TEST - <N:C> = 0100
                                ; ***********************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [142,240,250,173,207,210,200,125,375,016] FC 1,2,4,8

                                ;ACT BUTS:      37[004]100,142 / 35[240]120,173 / 22[207]200,200 / 16[125]016,016

                                ;EXEC:          [200]ALUC=LLLLL :[125] D = 177777

                                ;CODES:         [125] SPS=3  /  N:C = 1000

                                ;SYNC:          B05J2 (-) T = 4 USEC

                                ;KEY SIG:       K3-3 SM=2L  /  K3-3 DM=3L  /  K3-3 MOV L  /  K5-5 BC01 H
                                                ;  K5-5 BCON (1+2) H

035310  012700  000464          T0464:  MOV     #0464,R0                ;LOAD R0 WITH TEST NO.
035314  013701  035346                  MOV     @#I0464,R1      ;LOAD R1 WITH TEST INSTRUCTION  WORD
035320  005004                          CLR     R4              ;RESULT S / B = 177777
035322  005104                          COM     R4
035324  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
035330  012705  067614                  MOV     #DWTA+2,R5      ;SOURCE ADDR = DWTA+2
035334  012703  067576          R0464:  MOV     #ATA+10,R3      ;BASE DEST ADDR = ATA+10
035340  005012                          CLR     (R2)            ;MAKE [DEST] = 000000
035342  000257                          CCC                     ;CLEAR FLAGS
035344  000264                          264                     ;N:C = 0100

035346  012533                  I0464:  MOV     (R5)+,@(R3)+    ;TEST THE MOV - SM2,DM3

035350  100003                          BPL     E10464          ;N:C = 1000 ?
035352  001402                          BEQ     E10464
035354  102401                          BVS     E10464
035356  103002                          BCC     A0464

035360  104005                  E10464: ERROR5                  ;MOV FAILED TO ALTER CODES PROPERLY
035362  035334                          R0464                   ;ERROR LOOP RETURN

035364  022703  067600          A0464:  CMP     #ATA+12,R3      ;DID MOV INCREMENT DEST REG ?
035370  001402                          BEQ     B0464           ;BR IF YES

035372  104005                  E20464: ERROR5                  ;MOV FAILED TO UPDATE DEST REG
035374  035334                          R0464                   ;ERROR LOOP RETURN

035376  020412                  B0464:  CMP     R4,(R2)         ;RESULT CORRECT ??
035400  001404                          BEQ     00464           ;BR IF YES

035402  005003                          CLR     R3              ;GET THE WAS DATA
035404  051203                          BIS     (R2),R3
035406  104000                  E30464: ERROR                   ;MOV DELIVERED THE WRONG RESULT
035410  035334                          R0464                   ;ERROR LOOP RETURN

035412  000004                  00464:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***********************************************************************
                                        .SBTTL T0465 MOV SM1,DM3 TEST - <N:C> = 1011
                                ; ***********************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [141,247,250,173,207,210,200,125,375,016] FC 1,2,4,8

                                ;ACT BUTS:      37[004]100,141 / 35[247]120,173 / 22[207]200,200 / 16[125]016,016

                                ;EXEC:          [200]ALUC-LLLLL :[125] D = 000000

                                ;CODES:         [125] SPS=3  /  N:C = 0101

                                ;SYNC:          B05J2 (-) T = 4 USEC

                                ;KEY SIG:       K3-3 SM=1L  /  K3-3 DM=3L  /  K3-3 MOV L  /  K5-5 BC01 H

035414  012700  000465          T0465:  MOV     #0465,R0                ;LOAD R0 WITH TEST NO.
035420  013701  035452                  MOV     @#I0465,R1      ;LOAD R1 WITH TEST INSTRUCTION  WORD
035424  005004                          CLR     R4              ;RESULT S / B = 000000
035426  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
035432  012705  067612                  MOV     #DWTA,R5        ;SOURCE ADDR = DWTA
035436  012703  067576          R0465:  MOV     #ATA+10,R3      ;BASE DEST ADDR = ATA+10
035442  005012                          CLR     (R2)            ;MAKE [DEST] = 177777
035444  005112                          COM     (R2)
035446  000257                          CCC                     ;CLEAR FLAGS
035450  000273                          273                     ;N:C = 1011

035452  011533                  I0465:  MOV     (R5),@(R3)+     ;TEST THE MOV - SM1,DM3

035454  100403                          BMI     E10465          ;N:C = 0101 ?
035456  001002                          BNE     E10465
035460  102401                          BVS     E10465
035462  103402                          BCS     A0465

035464  104005                  E10465: ERROR5                  ;MOV FAILED TO ALTER CODES PROPERLY
035466  035436                          R0465                   ;ERROR LOOP RETURN

035470  022703  067600          A0465:  CMP     #ATA+12,R3      ;DID MOV INCREMENT DEST REG ?
035474  001402                          BEQ     B0465           ;BR IF YES

035476  104005                  E20465: ERROR5                  ;MOV FAILED TO UPDATE DEST REG
035500  035436                          R0465                   ;ERROR LOOP RETURN

035502  020412                  B0465:  CMP     R4,(R2)         ;RESULT CORRECT ??
035504  001404                          BEQ     00465           ;BR IF YES

035506  005003                          CLR     R3              ;GET THE WAS DATA
035510  051203                          BIS     (R2),R3
035512  104000                  E30465: ERROR                   ;MOV DELIVERED THE WRONG RESULT
035514  035436                          R0465                   ;ERROR LOOP RETURN

035516  000004                  00465:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***************************************************************
                                                .SBTTL T0466 MOV SM2,DM3 TEST - <N:C> = 1011
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [142,240,250,173,207,210,200,125,375,016] FC 1,2,4,8

                                        ;ACT BUTS:      37[004]100,142 / 35[240]120,173 / 22[207]200,200 / 16[125]016,016

                                        ;EXEC:          [200]ALUC=LLLLL :[125] D = 000000

                                        ;CODES:         [125] SPS=3  /  N:C = 0101

                                        ;SYNC:          B05J2 (-) T = 4 USEC

                                        ;KEY SIG:       K3-3 SM=2L  /  K3-3 DM=3L  /  K3-3 MOV L  /  K5-5 BC01 H
                                                        ;  K5-5 BCON (1+2) H

035520  012700  000466          T0466:  MOV     #0466,R0                ;LOAD R0 WITH TEST NO.
035524  013701  035556                  MOV     @#I0466,R1      ;LOAD R1 WITH TEST INSTRUCTION  WORD
035530  005004                          CLR     R4              ;RESULT S / B = 000000
035532  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
035536  012705  067612                  MOV     #DWTA,R5        ;SOURCE ADDR = DWTA
035542  012703  067576          R0466:  MOV     #ATA+10,R3      ;BASE DEST ADDR = ATA+10
035546  005012                          CLR     (R2)            ;MAKE [DEST] = 177777
035550  005112                          COM     (R2)
035552  000257                          CCC                     ;CLEAR FLAGS
035554  000273                          273                     ;N:C = 1011

035556  012533                  I0466:  MOV     (R5)+,@(R3)+    ;TEST THE MOV - SM2,DM3

035560  100403                          BMI     E10466          ;N:C = 0101 ?
035562  001002                          BNE     E10466
035564  102401                          BVS     E10466
035566  103402                          BCS     A0466

035570  104005                  E10466: ERROR5                  ;MOV FAILED TO ALTER CODES PROPERLY
035572  035542                          R0466                   ;ERROR LOOP RETURN

035574  022703  067600          A0466:  CMP     #ATA+12,R3      ;DID MOV INCREMENT DEST REG ?
035600  001402                          BEQ     B0466           ;BR IF YES

035602  104005                  E20466: ERROR5                  ;MOV FAILED TO UPDATE DEST REG
035604  035542                          R0466                   ;ERROR LOOP RETURN

035606  020412                  B0466:  CMP     R4,(R2)         ;RESULT CORRECT ??
035610  001404                          BEQ     00466           ;BR IF YES

035612  005003                          CLR     R3              ;GET THE WAS DATA
035614  051203                          BIS     (R2),R3
035616  104000                  E30466: ERROR                   ;MOV DELIVERED THE WRONG RESULT
035620  035542                          R0466                   ;ERROR LOOP RETURN

035622  000004                  00466:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***********************************************************************
                                        .SBTTL T0467 MOV SM1,DM4 TEST - <N:C> = 0100
                                ; ***********************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [141,247,250,174,257,200,125,375,016] FC 1,2,4,8

                                ;ACT BUTS:      37[004]100,141 / 35[247]120,174 / 22[174]200,200 / 16[125]016,016

                                ;EXEC:          [200]ALUC=LLLLL :[125] D = 177777

                                ;CODES:         [125] SPS=3  /  N:C = 1000

                                ;SYNC:          BOSJ2 (-) T = 3.2 USEC

                                ;KEY SIG:       K3-3 SM=1L  /  K3-3 DM=4L  /  K3-3 MOV L  /  K5-5 BCON (1+2) H

035624  012700  000467          T0467:  MOV     #0467,R0                ;LOAD R0 WITH TEST NO.
035630  013701  035662                  MOV     @#I0467,R1      ;LOAD R1 WITH TEST INSTRUCTION  WORD
035634  005004                          CLR     R4              ;RESULT S / B = 177777
035636  005104                          COM     R4
035640  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
035644  012705  067614                  MOV     #DWTA+2,R5      ;SOURCE ADDR = DWTA+2
035650  012703  067604          R0467:  MOV     #MBUF0+2,R3     ;BASE DEST ADDR = MBUF0+2
035654  005012                          CLR     (R2)            ;MAKE [DEST] = 000000
035656  000257                          CCC                     ;CLEAR FLAGS
035660  000264                          264                     ;N:C = 0100

035662  011543                  I0467:  MOV     (R5),-(R3)      ;TEST THE MOV - SM1,DM4

035664  100003                          BPL     E10467          ;N:C = 1000 ?
035666  001402                          BEQ     E10467
035670  102401                          BVS     E10467
035672  103002                          BCC     A0467

035674  104005                  E10467: ERROR5                  ;MOV FAILED TO ALTER CODES PROPERLY
035676  035650                          R0467                   ;ERROR LOOP RETURN

035700  020203                  A0467:  CMP     R2,R3           ;DID MOV DECREMENT DEST REG ?
035702  001402                          BEQ     B0467           ;BR IF YES

035704  104005                  E20467: ERROR5                  ;MOV FAILED TO UPDATE DEST REG
035706  035650                          R0467                   ;ERROR LOOP RETURN

035710  020412                  B0467:  CMP     R4,(R2)         ;RESULT CORRECT ??
035712  001404                          BEQ     00467           ;BR IF YES

035714  005003                          CLR     R3              ;GET THE WAS DATA
035716  051203                          BIS     (R2),R3
035720  104000                  E30467: ERROR                   ;MOV DELIVERED THE WRONG RESULT
035722  035650                          R0467                   ;ERROR LOOP RETURN

035724  000004                  00467:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0470 MOV SM2,DM4 TEST - <N:C> = 0100
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [142,240,250,174,257,200,125,375,016] FC 1,2,4,8

                                ;ACT BUTS:      37[004]100,142 / 35[240]140,174 / 22[174]200,200 / 16[125]016,016

                                ;EXEC:          [200]ALUC=LLLLL :[125] D = 177777

                                ;CODES:         [125] SPS=3  /  N:C = 1000

                                ;SYNC:          B05J2 (-) T = 3.2 USEC

                                ;KEY SIG:       K3-3 SM=2L  /  K3-3 DM=4L  /  K3-3 MOV L  /  K5-5 BCON (1+2) H

035726  012700  000470          T0470:  MOV     #0470,R0                ;LOAD R0 WITH TEST NO.
035732  013701  035764                  MOV     @#I0470,R1      ;LOAD R1 WITH TEST INSTRUCTION  WORD
035736  005004                          CLR     R4              ;RESULT S / B = 177777
035740  005104                          COM     R4
035742  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
035746  012705  067614                  MOV     #DWTA+2,R5      ;SOURCE ADDR = DWTA+2
035752  012703  067604          R0470:  MOV     #MBUF0+2,R3             ;BASE DEST ADDR = MBUF0+2
035756  005012                          CLR     (R2)            ;MAKE [DEST] = 000000
035760  000257                          CCC                     ;CLEAR FLAGS
035762  000264                          264                     ;N:C = 0100

035764  012543                  I0470:  MOV     (R5)+,-(R3)     ;TEST THE MOV - SM2,DM4

035766  100003                          BPL     E10470          ;N:C = 1000 ?
035770  001402                          BEQ     E10470
035772  102401                          BVS     E10470
035774  103002                          BCC     A0470

035776  104005                  E10470: ERROR5                  ;MOV FAILED TO ALTER CODES PROPERLY
036000  035752                          R0470                   ;ERROR LOOP RETURN

036002  020203                  A0470:  CMP     R2,R3           ;DID MOV INCREMENT DEST REG ?
036004  001402                          BEQ     B0470           ;BR IF YES

036006  104005                  E20470: ERROR5                  ;MOV FAILED TO UPDATE DEST REG
036010  035752                          R0470                   ;ERROR LOOP RETURN

036012  020412                  B0470:  CMP     R4,(R2)         ;RESULT CORRECT ??
036014  001404                          BEQ     00470           ;BR IF YES

036016  005003                          CLR     R3              ;GET THE WAS DATA
036020  051203                          BIS     (R2),R3
036022  104000                  E30470: ERROR                   ;MOV DELIVERED THE WRONG RESULT
036024  035752                          R0470                   ;ERROR LOOP RETURN

036026  000004                  00470:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***********************************************************************
                                        .SBTTL T0471 MOV SM1,DM4 TEST - <N:C> = 1011
                                ; ***********************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [141,247,250,174,257,200,125,375,016] FC 1,2,4,8

                                ;ACT BUTS:      37[004]100,141 / 35[247]120,174 / 22[174]200,200 / 16[125]016,016

                                ;EXEC:          [200]ALUC=LLLLL :[125] D = 000000

                                ;CODES:         [125] SPS=3  /  N:C = 0101

                                ;SYNC:          B05J2 (-) T = 3.2 USEC

                                ;KEY SIG:       K3-3 SM=1L  /  K3-3 DM=4L  /  K3-3 MOV L  /  K5-5 BCON (1+2) H

036030  012700  000471          T0471:  MOV     #0471,R0                ;LOAD R0 WITH TEST NO.
036034  013701  036066                  MOV     @#I0471,R1      ;LOAD R1 WITH TEST INSTRUCTION  WORD
036040  005004                          CLR     R4              ;RESULT S / B = 000000
036042  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
036046  012705  067612                  MOV     #DWTA,R5        ;SOURCE ADDR = DWTA
036052  012703  067604          R0471:  MOV     #MBUF0+2,R3             ;BASE DEST ADDR = MBUF0+2
036056  005012                          CLR     (R2)            ;MAKE [DEST] = 177777
036060  005112                          COM     (R2)
036062  000257                          CCC                     ;CLEAR FLAGS
036064  000273                          273                     ;N:C = 1011

036066  011543                  I0471:  MOV     (R5),-(R3)      ;TEST THE MOV - SM1,DM4

036070  100403                          BMI     E10471          ;N:C = 0101 ?
036072  001002                          BNE     E10471
036074  102401                          BVS     E10471
036076  103402                          BCS     A0471

036100  104005                  E10471: ERROR5                  ;MOV FAILED TO ALTER CODES PROPERLY
036102  036052                          R0471                   ;ERROR LOOP RETURN

036104  020203                  A0471:  CMP     R2,R3           ;DID MOV INCREMENT DEST REG ?
036106  001402                          BEQ     B0471           ;BR IF YES

036110  104005                  E20471: ERROR5                  ;MOV FAILED TO UPDATE DEST REG
036112  036052                          R0471                   ;ERROR LOOP RETURN

036114  020412                  B0471:  CMP     R4,(R2)         ;RESULT CORRECT ??
036116  001404                          BEQ     00471           ;BR IF YES

036120  005003                          CLR     R3              ;GET THE WAS DATA
036122  051203                          BIS     (R2),R3
036124  104000                  E30471: ERROR                   ;MOV DELIVERED THE WRONG RESULT
036126  036052                          R0471                   :ERROR LOOP RETURN

036130  000004                  00471:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***************************************************************
                                                .SBTTL T0472 MOV SM2,DM4 TEST - (N:C) = 1011
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [142,240,250,174,257,200,125,375,016] FC 1,2,4,8

                                        ;ACT BUTS:      37[004]100,142 / 35[240]120,174 / 22[174]200,200 / 16[125]016,016

                                        ;EXEC:          [200]ALUC=LLLLL :[125] D = 000000

                                        ;CODES:         [125] SPS=3  /  N:C = 0101

                                        ;SYNC:          B05J2 (-) T = 3.2 USEC

                                        ;KEY SIG:       K3-3 SM=2L  /  K3-3 DM=4L  /  K3-3 MOV L  /  K5-5 BCON (1+2) H

036132  012700  000472          T0472:  MOV     #0472,R0                ;LOAD R0 WITH TEST NO.
036136  013701  036170                  MOV     @#I0472,R1      ;LOAD R1 WITH TEST INSTRUCTION  WORD
036142  005004                          CLR     R4              ;RESULT S / B = 000000
036144  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
036150  012705  067612                  MOV     #DWTA,R5        ;SOURCE ADDR = DWTA
036154  012703  067604          R0472:  MOV     #MBUF0+2,R3     ;BASE DEST ADDR = MBUF0+2
036160  005012                          CLR     (R2)            ;MAKE [DEST] = 177777
036162  005112                          COM     (R2)
036164  000257                          CCC                     ;CLEAR FLAGS
036166  000273                          273                     ;N:C = 1011

036170  012543                  I0472:  MOV     (R5)+,-(R3)     ;TEST THE MOV - SM2,DM4

036172  100403                          BMI     E10472          ;N:C = 0101 ?
036174  001002                          BNE     E10472
036176  102401                          BVS     E10472
036200  103402                          BCS     A0472

036202  104005                  E10472: ERROR5                  ;MOV FAILED TO ALTER CODES PROPERLY
036204  036154                          R0472                   ;ERROR LOOP RETURN

036206  020203                  A0472:  CMP     R2,R3           ;DID MOV INCREMENT DEST REG ?
036210  001402                          BEQ     B0472           ;BR IF YES

036212  104005                  E20472: ERROR5                  ;MOV FAILED TO UPDATE DEST REG
036214  036154                          R0472                   ;ERROR LOOP RETURN

036216  020412                  B0472:  CMP     R4,(R2)         ;RESULT CORRECT ??
036220  001404                          BEQ     00472           ;BR IF YES

036222  005003                          CLR     R3              ;GET THE WAS DATA
036224  051203                          BIS     (R2),R3
036226  104000                  E30472: ERROR                   ;MOV DELIVERED THE WRONG RESULT
036230  036154                          R0472                   ;ERROR LOOP RETURN

036232  000004                  00472:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***********************************************************************
                                                .SBTTL T0473 MOV SM1,DM5 TEST - <N:C> = 0100
                                        ; ***********************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [141,247,250,175,207,210,200,125,375,016] FC 1,2,4,8

                                        ;ACT BUTS:      37[004]100,141 / 35[247]120,175 / 22[207]200,200 / 16[125]016,016

                                        ;EXEC:          [200]ALUC=LLLLL :[125] D = 177777

                                        ;CODES:         [125] SPS=3  /  N:C = 1000

                                        ;SYNC:          B05J2 (-) T = 4 USEC

                                        ;KEY SIG:       K3-3 SM=1L  /  K3-3 DM=5L  /  K3-3 MOV L  /  K5-5 BC01 H

036234  012700  000473                  T0473:  MOV     #0473,R0                ;LOAD R0 WITH TEST NO.
036240  013701  036272                          MOV     @#I0473,R1      ;LOAD R1 WITH TEST INSTRUCTION  WORD
036244  005004                                  CLR     R4              ;RESULT S / B = 177777
036246  005104                                  COM     R4
036250  012702  067602                          MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
036254  012705  067614                          MOV     #DWTA+2,R5      ;SOURCE ADDR = DWTA+2
036260  012703  067600                  R0473:  MOV     #ATA+12,R3              ;BASE DEST ADDR = ATA+12
036264  005012                                  CLR     (R2)            ;MAKE [DEST] = C00000
036266  000257                                  CCC                     ;CLEAR FLAGS
036270  000264                                  264                     ;N:C = 0100

036272  011553                          I0473:  MOV     (R5),@-(R3)     ;TEST THE MOV - SM1,DM5

036274  100C03                                  BPL     E10473          ;N:C = 0100 ?
036276  001402                                  BEQ     E10473
036300  102401                                  BVS     E10473
036302  103002                                  BCC     A0473

036304  104005                          E10473: ERROR5                  ;MOV FAILED TO ALTER CODES PROPERLY
036306  036260                                  R0473                   ;ERROR LOOP RETURN

036310  022703  067576                  A0473:  CMP     #ATA+10,R3      ;DID MOV DECREMENT DEST REG ?
036314  001402                                  BEQ     B0473           ;BR IF YES

036316  104005                          E20473: ERROR5                  ;MOV FAILED TO UPDATE DEST REG
036320  036260                                  R0473                   ;ERROR LOOP RETURN

036322  020412                          B0473:  CMP     R4,(R2)         ;RESULT CORRECT ??
036324  001404                                  BEQ     00473           ;BR IF YES

036326  005003                                  CLR     R3              ;GET THE WAS DATA
036330  051203                                  BIS     (R2),R3
036332  104000                          E30473: ERROR                   ;MOV DELIVERED THE WRONG RESULT
036334  036260                                  R0473                   ;ERROR LOOP RETURN

036336  000004                          00473:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***********************************************************************
                                                .SBTTL T0474 MOV SM2,DM5 TEST - <N:C> = 0100
                                        ; ***********************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [142,240,250,175,207,210,200,125,375,016] FC 1,2,4,8

                                        ;ACT BUTS:      37[004]100,142 / 35[240]120,175 / 22[207]200,200 / 16[125]016,016

                                        ;EXEC:          [200]ALUC=LLLLL :[125] D = 177777

                                        ;CODES:         [125] SPS=3  /  N:C = 1000

                                        ;SYNC:          B05J2 (-) T = 4 USEC

                                        ;KEY SIG:       K3-3 SM=2L  /  K3-3 DM=5L  /  K3-3 MOV L  /  K5-5 BC01 H
                                                        ;  K5-5 BCON (1+2) H

036340  012700  000474          T0474:  MOV     #0474,R0                ;LOAD R0 WITH TEST NO.
036344  013701  036376                  MOV     @#I0474,R1      ;LOAD R1 WITH TEST INSTRUCTION  WORD
036350  005004                          CLR     R4              ;RESULT S / B = 177777
036352  005104                          COM     R4
036354  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
036360  012705  067614                  MOV     #DWTA+2,R5      ;SOURCE ADDR = DWTA+2
036364  012703  067600          R0474:  MOV     #ATA+12,R3      ;BASE DEST ADDR = ATA+12
036370  005012                          CLR     (R2)            ;MAKE [DEST] = 00000
036372  000257                          CCC                     ;CLEAR FLAGS
036374  000264                          264                     ;N:C = 1000

036376  012553                  I0474:  MOV     (R5)+,@-(R3)    ;TEST THE MOV - SM2,DM5

036400  100003                          BPL     E10474          ;N:C = 1000 ?
036402  001402                          BEQ     E10474
036404  102401                          BVS     E10474
036406  103002                          BCC     A0474

036410  104005                  E10474: ERROR5                  ;MOV FAILED TO ALTER CODES PROPERLY
036412  036364                          R0474                   ;ERROR LOOP RETURN

036414  022703  067576          A0474:  CMP     #ATA+10,R3      ;DID MOV DECREMENT DEST REG ?
036420  001402                          BEQ     B0474           ;BR IF YES

036422  104005                  E20474: ERROR5                  ;MOV FAILED TO UPDATE DEST REG
036424  036364                          R0474                   ;ERROR LOOP RETURN

036426  020412                  B0474:  CMP     R4,(R2)         ;RESULT CORRECT ??
036430  001404                          BEQ     00474           ;BR IF YES

036432  005003                          CLR     R3              ;GET THE WAS DATA
036434  051203                          BIS     (R2),R3
036436  104000                  E30474: ERROR                   ;MOV DELIVERED THE WRONG RESULT
036440  036364                          R0474                   ;ERROR LOOP RETURN

036442  000004                  00474:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***********************************************************************
                                                .SBTTL T0475 MOV SM1,DM5 TEST - (N:C) = 1011
                                        ; ***********************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [141,247,250,175,207,210,200,125,375,016] FC 1,2,4,8

                                        ;ACT BUTS:      37[004]100,141 / 35[247]120,175 / 22[207]200,200 / 16[125]016,016

                                        ;EXEC:          [200]ALUC=LLLLL :[125] D = 000000

                                        ;CODES:         [125] SPS=3  /  N:C = 0101

                                        ;SYNC:          B05J2 (-) T = 4 USEC

                                        ;KEY SIG:       K3-3 SM=1L  /  K3-3 DM=5L  /  K3-3 MOV L  /  K5-5 BC01 H

036444  012700  000475                  T0475:  MOV     #0475,R0                ;LOAD R0 WITH TEST NO.
036450  013701  036502                          MOV     @#I0475,R1      ;LOAD R1 WITH TEST INSTRUCTION  WORD
036454  005004                                  CLR     R4              ;RESULT S / B = 000000
036456  012702  067602                          MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
036462  012705  067612                          MOV     #DWTA,R5        ;SOURCE ADDR = DWTA
036466  012703  067600                  R0475:  MOV     #ATA+12,R3              ;BASE DEST ADDR = ATA+12
036472  005012                                  CLR     (R2)            ;MAKE [DEST] = 177777
036474  005112                                  COM     (R2)
036476  000257                                  CCC                     ;CLEAR FLAGS
036500  000273                                  273                     ;N:C = 1011

036502  011553                          I0475:  MOV     (R5),@-(R3)     ;TEST THE MOV - SM1,DM5

036504  100403                                  BMI     E10475          ;N:C = 0101 ?
036506  001002                                  BNE     E10475
036510  102401                                  BVS     E10475
036512  103402                                  BCS     A0475

036514  104005                          E10475: ERROR5                  ;MOV FAILED TO ALTER CODES PROPERLY
036516  036466                                  R0475                   ;ERROR LOOP RETURN

036520  022703  067576                  A0475:  CMP     #ATA+10,R3      ;DID MOV DECREMENT DEST REG ?
036524  001402                                  BEQ     B0475           ;BR IF YES

036526  104005                          E20475: ERROR5                  ;MOV FAILED TO UPDATE DEST REG
036530  036466                                  R0475                   ;ERROR LOOP RETURN

036532  020412                          B0475:  CMP     R4,(R2)         ;RESULT CORRECT ??
036534  001404                                  BEQ     00475           ;BR IF YES

036536  005003                                  CLR     R3              ;GET THE WAS DATA
036540  051203                                  BIS     (R2),R3
036542  104000                          E30475: ERROR                   ;MOV DELIVERED THE WRONG RESULT
036544  036466                                  R0475                   ;ERROR LOOP RETURN

036546  000004                          00475:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***********************************************************************
                                                .SBTTL T0476 MOV SM2,DM5 TEST - (N:C) = 1011
                                        ; ***********************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [142,240,250,175,207,210,200,125,375,016] FC 1,2,4,8

                                        ;ACT BUTS:      37[004]100,142 / 35[240]120,175 / 22[207]200,200   16[125]016,016

                                        ;EXEC:          [200]ALUC=LLLLL :[125] D = 000000

                                        ;CODES:         [125] SPS=3  /  N:C = 0101

                                        ;SYNC:          BOSJ2 (-) T = 4 USEC

                                        ;KEY SIG:       K3-3 SM=2L  /  K3-3 DM=5L  /  K3-3 MOV L  /  K5-5 BC01 H
                                                        ;  K5-5 BCON (1+2) H

036550  012700  000476          T0476:  MOV     #0476,R0                ;LOAD R0 WITH TEST NO.
036554  013701  036606                  MOV     @#T0476,R1      ;LOAD R1 WITH TEST INSTRUCTION  WORD
036560  005004                          CLR     R4              ;RESULT S / B = 000000
036562  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
036566  012705  067612                  MOV     #DWTA,R5        ;SOURCE ADDR = DWTA
036572  012703  067600          R0476:  MOV     #ATA+12,R3      ;BASE DEST ADDR = ATA+12
036576  005012                          CLR     (R2)            ;MAKE [DEST] = 177777
036600  005112                          COM     (R2)
036602  000257                          CCC                     ;CLEAR FLAGS
036604  000273                          273                     ;N:C = 1011

036606  011553                  T0476:  MOV     (R5),@-(R3)     ;TEST THE MOV - SM2,DM5

036610  100403                          BMI     E10476          ;N:C = 0101 ?
036612  001302                          BNE     E10476
036614  102401                          BVS     E10476
036616  103402                          BCS     A0476

036620  104005                  E10476: ERROR5                  ;MOV FAILED TO ALTER CODES PROPERLY
036622  036572                          R0476                   ;ERROR LOOP RETURN

036624  022703  067576          A0476:  CMP     #ATA+10,R3      ;DID MOV DECREMENT DEST REG ?
036630  001402                          BEQ     B0476           ;BR IF YES

036632  104005                  E20476: ERROR5                  ;MOV FAILED TO UPDATE DEST REG
036634  036572                          R0476                   ;ERROR LOOP RETURN

036636  020412                  B0476:  CMP     R4,(R2)         ;RESULT CORRECT ??
036640  001404                          BEQ     00476           ;BR IF YES

036642  005003                          CLR     R3              ;GET THE WAS DATA
036644  051203                          BIS     (R2),R3
036646  104000                  E30476: ERROR                   ;MOV DELIVERED THE WRONG RESULT
036650  036572                          R0476                   ;ERROR LOOP RETURN

036652  000004                  00476:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***********************************************************************
                                                .SBTTL T0477 MOV SM1,DM6 TEST - (N:C) = 0100
                                        ; ***********************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [141,247,250,177,206,212,200,125,375,016] FC 1,2,4,8

                                        ;ACT BUTS:      37[004]100,141 / 35[247]120,177 / 17[177]212,212 / 21[206]200,200
                                                        ; / 16[125]016,016

                                        ;EXEC:          [200]ALUC=LLLLL :[125] D = 177777

                                        ;CODES:         [125] SPS=3  /  N:C = 1000

                                        ;SYNC:          B05J2 (-) T = 4 USEC

                                        ;KEY SIG:       K3-3 SM=1L  /  K3-3 DM=6L K3-3 MOV L

036654  012700  000477          T0477:  MOV     #0477,R0                ;LOAD R0 WITH TEST NO.
036660  013701  036712                  MOV     @#I0477,R1      ;LOAD R1 WITH TEST INSTRUCTION  WORD
036664  005004                          CLR     R4              ;RESULT S / B = 177777
036666  005104                          COM     R4
036670  012702  067610                  MOV     #MBUF0+6,R2     ;DEST ADDR = MBUF0+6
036674  012705  067614                  MOV     #DWTA+2,R5      ;SOURCE ADDR = DWTA+2
036700  012703  067602          R0477:  MOV     #MBUF0,R3       ;BASE DEST ADDR = MBUF0
036704  005012                          CLR     (R2)            ;MAKE [DEST] = 000000
036706  000257                          CCC                     ;CLEAR FLAGS
036710  000264                          264                     ;N:C = 0100

036712  011563  000006          I0477:  MOV     (R5),6(R3)      ;TEST THE MOV - SM1,DM6

036716  100003                          BPL     E10477          ;N:C = 1000 ?
036720  001402                          BEQ     E10477
036722  102401                          BVS     E10477
036724  103002                          BCC     A0477

036726  104005          E10477: ERROR5                          ;MOV FAILED TO ALTER CODES PROPERLY
036730  036700                  R0477                           ;ERROR LOOP RETURN

036732  020412          A0477:  CMP     R4,(R2)         ;RESULT CORRECT ??
036734  001404                  BEQ     00477           ;BR IF YES

036736  005003                          CLR     R3              ;GET THE WAS DATA
036740  051203                          BIS     (R2) R3
036742  104000          E20477: ERROR                           ;MOV DELIVERED THE WRONG RESULT
036744  036700                  R0477                           ;ERROR LOOP RETURN

036746  000004          00477:  SCOPE                           ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***********************************************************************
                                                .SBTTL T0500 MOV SM2,DM6 TEST - (N:C) = 0100
                                        ; ***********************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [142,240,250,177,206,212,200,125,375,016] FC 1,2,4,8

                                        ;ACT BUTS:      37[004]100,142 / 35[240]120,177 / 17[177]212,212 / 21[206]200,200
                                                        ; / 16[125]016,016

                                        ;EXEC:          [200]ALUC=LLLLL :[125] D = 177777

                                        ;CODES:         [125] SPS=3  /  N:C = 1000

                                        ;SYNC:          BOSJ2 (-) T = 4 USEC

                                        ;KEY SIG:       K3-3 SM=1L  /  K3-3 DM=6L  /  K3-3 MOV L  /  K5-5 BCON (1+2) H

036750  012700  000500          T0500:  MOV     #T0500,R0               ;LOAD R0 WITH TEST NO.
036754  013701  037006                  MOV     @#I0500,R1      ;LOAD R1 WITH TEST INSTRUCTION  WORD
036760  005004                          CLR     R4              ;RESULT S / B = 177777
036762  005104                          COM     R4
036764  012702  067610                  MOV     #MBUF0+6,R2     ;DEST ADDR = MBUF0+6
036770  012705  067614                  MOV     #DWTA+2,R5      ;SOURCE ADDR = DWTA+2
036774  012703  067602          R0500:  MOV     #MBUF0,R3       ;BASE DEST ADDR = MBUF0
037000  005012                          CLR     (R2)            ;MAKE [DEST] = 000000
037002  000257                          CCC                     ;CLEAR FLAGS
037004  000264                          264                     ;N:C = 0100

037006  012563  000006          I0500:  MOV     (R5)+,6(R3)     ;TEST THE MOV - SM2,DM6

037012  100003                          BPL     E10500          ;N:C = 1000 ?
037014  001402                          BEQ     E10500
037016  102401                          BVS     E10500
037020  103002                          BCC     A0500

037022  104005                  E10500: ERROR5                  ;MOV FAILED TO ALTER CODES PROPERLY
037024  036774                          R0500                   ;ERROR LOOP RETURN

037026  020412                  A0500:  CMP     R4,(R2)         ;RESULT CORRECT ??
037030  001404                          BEQ     00500           ;BR IF YES

037032  005003                          CLR     R3              ;GET THE WAS DATA
037034  051203                          BIS     (R2),R3
037036  104000                  E20500: ERROR                   ;MOV DELIVERED THE WRONG RESULT
037040  036774                          R0500                   ;ERROR LOOP RETURN

037042  000004                  00500:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***************************************************************
                                                .SBTTL T0501 MOV SM1,DM6 TEST - <N:C> = 1011
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [141,247,250,177,206,212,200,125,375,016] FC 1,2,4,8

                                        ;ACT BUTS:      37[004]100,141 / 35[247]120,177 / 17[177]212,212 / 21[206]200,200
                                                        ; / 16[125]016,016

                                        ;EXEC:          [200]ALUC=LLLLL :[125] D = 000000

                                        ;CODES:         [125] SPS=3  /  N:C = 0101

                                        ;SYNC:          B05J2 (-) T = 4 USEC

                                        ;KEY SIG:       K3-3 SM=1L  /  K3-3 DM=6L  /  K3-3 MOV L

037044  012700  000501                  T0501:  MOV     #0501,R0                ;LOAD R0 WITH TEST NO.
037050  013701  037102                          MOV     @#I0501,R1      ;LOAD R1 WITH TEST INSTRUCTION  WORD
037054  005004                                  CLR     R4              ;RESULT S / B = 000000
037056  012702  067610                          MOV     #MBUF0+6,R2     ;DEST ADDR = MBUF0+6
037062  012705  067612                          MOV     #DWTA,R5        ;SOURCE ADDR = DWTA
037066  012703  067602                  R0501:  MOV     #MBUF0,R3               ;BASE DEST ADDR = MBUF0
037072  005012                                  CLR     (R2)            ;MAKE [DEST] = 177777
037074  005112                                  COM     (R2)
037076  000257                                  CCC                     ;CLEAR FLAGS
037100  000273                                  273                     ;N:C = 1011

037102  011563  000006                  I0501:  MOV     (R5),6(R3)      ;TEST THE MOV - SM1,DM6

037106  100403                                  BMI     E10501          ;N:C = 0101 ?
037110  001002                                  BNE     E10501
037112  102401                                  BVS     E10501
037114  103402                                  BCS     A0501

037116  104005                          E10501: ERROR5                  ;MOV FAILED TO ALTER CODES PROPERLY
037120  037066                                  R0501                   ;ERROR LOOP RETURN

037122  020412                          A0501:  CMP     R4,(R2)         ;RESULT CORRECT ??
037124  001404                                  BEQ     00501           ;BR IF YES

037126  005003                                  CLR     R3              ;GET THE WAS DATA
037130  051203                                  BIS     (R2),R3
037132  104000                          E20501: ERROR                   ;MOV DELIVERED THE WRONG RESULT
037134  037066                                  R0501                   ;ERROR LOOP RETURN

037136  000004                          00501:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***********************************************************************
                                                .SBTTL T0502 MOV SM2,DM6 TEST - <N:C> = 1011
                                        ; ***********************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [142,240,250,177,206,212,200,125,375,016] FC 1,2,4,8

                                        ;ACT BUTS:      37[004]100,142 / 35[240]120,177 / 17[177]212,212 / 21[206]200,200
                                                        ; / 16[125]016,016

                                        ;EXEC:          [200]ALUC=LLLLL :[125] D = 000000

                                        ;CODES:         [125] SPS=3  /  N:C = 0101

                                        ;SYNC:          B05J2 (-) T = 4 USEC

                                        ;KEY SIG:       K3-3 SM=2L  /  K3-3 DM=6L  /  K3-3 MOV L  /  K5-5 BCON (1+2) H

037140  012700  000502          T0502:  MOV     #0502,R0                ;LOAD R0 WITH TEST NO.
037144  013701  037176                  MOV     @#I0502,R1      ;LOAD R1 WITH TEST INSTRUCTION  WORD
037150  005004                          CLR     R4              ;RESULT S / B = 000000
037152  012702  067610                  MOV     #MBUF0+6,R2     ;DEST ADDR = MBUF0+6
037156  012705  067612                  MOV     #DWTA,R5        ;SOURCE ADDR = DWTA
037162  012703  067602          R0502:  MOV     #MBUF0,R3       ;BASE DEST ADDR = MBUF0
037166  005012                          CLR     (R2)            ;MAKE [DEST] = 177777
037170  005112                          COM     (R2)
037172  000257                          CCC                     ;CLEAR FLAGS
037174  000273                          273                     ;N:C = 1011

037176  012563  000006          I0502:  MOV     (R5)+,6(R3)     ;TEST THE MOV - SM2,DM6

037202  100403                          BMI     E10502          ;N:C = 0101 ?
037204  001002                          BNE     E10502
037206  102401                          BVS     E10502
037210  103402                          BCS     A0502

037212  104005          E10502: ERROR5                          ;MOV FAILED TO ALTER CODES PROPERLY
037214  037162                  R0502                           ;ERROR LOOP RETURN

037216  020412          A0502:  CMP     R4,(R2)         ;RESULT CORRECT ??
037220  001404                  BEQ     00502           ;BR IF YES

037222  005003                          CLR     R3              ;GET THE WAS DATA
037224  051203                          BIS     (R2),R3
037226  104000          E20502: ERROR                           ;MOV DELIVERED THE WRONG RESULT
037230  037162                  R0502                           ;ERROR LOOP RETURN

037232  000004          00502:  SCOPE                           ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***********************************************************************
                                                .SBTTL T0503 MOV SM1,DM7 TEST - (N:C) = 0100
                                        ; ***********************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [141,247,250,177,206,213,207,210,200,125,375,016] FC 1,2,4,8

                                        ;ACT BUTS:      37[004]100,141 / 35[247]120,177 / 17[177]212,213 / 22[207]200,200
                                                        ; / 16[125]016,016

                                        ;EXEC:          [200]ALUC=LLLLL :[125] D = 177777

                                        ;CODES:         [125] SPS=3  /  N:C = 1000

                                        ;SYNC:          BOSJ2 (-) T = 5 USEC

                                        ;KEY SIG:       K3-3 SM=1L  /  K3-3 DM=7L  /  K3-3 MOV L

037234  012700  000503          T0503:  MOV     #0503,R0                ;LOAD R0 WITH TEST NO.
037240  013701  037272                  MOV     @#I0503,R1      ;LOAD R1 WITH TEST INSTRUCTION  WORD
037244  005004                          CLR     R4              ;RESULT S / B = 177777
037246  005104                          COM     R4
037250  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
037254  012705  067614                  MOV     #DWTA+2,R5      ;SOURCE ADDR = DWTA+2
037260  012703  067566          R0503:  MOV     #ATA,R3         ;BASE DEST ADDR = ATA
037264  005012                          CLR     (R2)            ;MAKE [DEST] = 000000
037266  000257                          CCC                     ;CLEAR FLAGS
037270  000264                          264                     ;N:C = 0100

037272  011573  000010          I0503:  MOV     (R5),@10(R3)    ;TEST THE MOV - SM1,DM7

037276  100003                          BPL     E10503          ;N:C = 1000 ?
037300  001402                          BEQ     E10503
037302  102401                          BVS     E10503
037304  103002                          BCC     A0503

037306  104005                  E10503: ERROR5                  ;MOV FAILED TO ALTER CODES PROPERLY
037310  037260                          R0503                   ;ERROR LOOP RETURN

037312  020412                  A0503:  CMP     R4,(R2)         ;RESULT CORRECT ??
037314  001404                          BEQ     00503           ;BR IF YES

037316  005003                          CLR     R3              ;GET THE WAS DATA
037320  051203                          BIS     (R2),R3
037322  104000                  E20503: ERROR                   ;MOV DELIVERED THE WRONG RESULT
037324  037260                          R0503                   ;ERROR LOOP RETURN

037326  000004                  00503:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***************************************************************
                                                .SBTTL TO504 MOV SM2,DM7 TEST - <N:C> = 0100
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [142,240,250,177,206,213,207,210,200,125,375,016] FC 1,2,4,8

                                        ;ACT BUTS:      37[004]100,142 / 35[240]120,177 / 17[177]212,213 / 21[207]200,200
                                                        ; / 16[125]016,016

                                        ;EXEC:          [200]ALUC=LLLLL :[125] D = 177777

                                        ;CODES:         [125] SPS=3  /  N:C = 1000

                                        ;SYNC:          B05J2 (-) T = 5 USEC

                                        ;KEY SIG:       K3-3 SM=2L  /  K3-3 DM=7L  /  K3-3 MOV L  /  K5-5 BCON (1+2) H

037330  012700  000504          TO504:  MOV     #0504,R0                ;LOAD R0 WITH TEST NO.
037334  013701  037400                  MOV     @#IO504,R1      ;LOAD R1 WITH TEST INSTRUCTION  WORD
037340  032737  001000  066642          BIT     #1000,@#BPTLOC  ;BREAKPOINT HALT SET ??
037346  001401                          BEQ     .+4             ;BR IF NOT
037350  000000                          HALT                    ;BREAK-DEPRESS CONTINUE TO RESTART
037352  005004                          CLR     R4              ;RESULT S / B = 177777
037354  005104                          COM     R4
037356  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
037362  012705  067614                  MOV     #DWTA+2,R5      ;SOURCE ADDR = DWTA+2
037366  012703  067566          RO504:  MOV     #ATA,R3         ;BASE DEST ADDR = ATA
037372  005012                          CLR     (R2)            ;MAKE [DEST] = 000000
037374  000257                          CCC                     ;CLEAR FLAGS
037376  000264                          264                     ;N:C = 0100

037400  011573  000010          IO504:  MOV     (R5),@10(R3)    ;TEST THE MOV - SM2,DM7

037404  100003                          BPL     E10504          ;N:C = 1000 ?
037406  001402                          BEQ     E10504
037410  102401                          BVS     E10504
037412  103002                          BCC     AO504

037414  104005          E10504: ERROR5                          ;MOV FAILED TO ALTER CODES PROPERLY
037416  037366                  RO504                           ;ERROR LOOP RETURN

037420  020412          AO504:  CMP     R4,(R2)         ;RESULT CORRECT ??
037422  001404                  BEQ     OO504           ;BR IF YES

037424  005003                  CLR     R3              ;GET THE WAS DATA
037426  051203                  BIS     (R2),R3
037430  104000          E20504: ERROR                           ;MOV DELIVERED THE WRONG RESULT
037432  037366                  RO504                           ;ERROR LOOP RETURN

037434  000004          OO504:  SCOPE                           ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***********************************************************************
                                                .SBTTL T0505 MOV SM1,DM7 TEST - (N:C) = 1011
                                        ; ***********************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [141,247,250,177,206,213,207,210,200,125,375,016] FC 1,2,4,8

                                        ;ACT BUTS:      37[004]100,141 / 35[247]120,177 / 17[177]212,213 / 22[207]200,200
                                                        ; / 16[125]016,016

                                        ;EXEC:          [200]ALUC=LLLLL :[125] D = 000000

                                        ;CODES:         [125] SPS= 3  /  N:C = 0101

                                        ;SYNC:          B05J2 (-) T = 5 USEC

                                        ;KEY SIG:       K3-3 SM=1L  /  K3-3 DM=7L  /  K3-3 MOV L

037436  012700  000505          T0505:  MOV     #0505,R0                ;LOAD R0 WITH TEST NO.
037442  013701  037474                  MOV     @#I0505,R1      ;LOAD R1 WITH TEST INSTRUCTION  WORD
037446  005004                          CLR     R4              ;RESULT S / B = 000000
037450  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
037454  012705  067612                  MOV     #DWTA,R5        ;SOURCE ADDR = DWTA
037460  012703  067566          R0505:  MOV     #ATA,R3         ;BASE DEST ADDR = ATA
037464  005012                          CLR     (R2)            ;MAKE [DEST] = 177777
037466  005112                          COM     (R2)
037470  000257                          CCC                     ;CLEAR FLAGS
037472  000273                          273                     ;N:C = 1011

037474  011573  000010          I0505:  MOV     (R5),@10(R3)    ;TEST THE MOV - SM1,DM7

037500  100403                          BMI     E10505          ;N:C = 0101 ?
037502  001002                          BNE     E10505
037504  102401                          BVS     E10505
037506  103402                          BCS     A0505

037510  104005                  E10505: ERROR5                  ;MOV FAILED TO ALTER CODES PROPERLY
037512  037460                          R0505                   ;ERROR LOOP RETURN

037514  020412                  A0505:  CMP     R4,(R2)         ;RESULT CORRECT ??
037516  001404                          BEQ     00505           ;BR IF YES

037520  005003                          CLR     R3              ;GET THE WAS DATA
037522  051203                          BIS     (R2),R3
037524  104000                  E20505: ERROR                   ;MOV DELIVERED THE WRONG RESULT
037526  037460                          R0505                   ;ERROR LOOP RETURN

037530  000004                  00505:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***************************************************************
                                                .SBTTL T0506 MOV SM2,DM7 TEST - (N:C) = 1011
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [142,240,250,177,206,213,207,210,200,125,375,016] FC 1,2,4,8

                                        ;ACT BUTS:      37[004]100,142 / 35[240]120,177 / 17[177]212,213 / 22[207]200,200
                                                        ; / 16[125]016,016

                                        ;EXEC:          [200]ALUC=LLLLL :[125] D = 000000

                                        ;CODES:         [125] SPS=3  /  N:C = 0101

                                        ;SYNC:          B05J2 (-) T = 5 USEC

                                        ;KEY SIG:       K3-3 SM=2L  /  K3-3 DM=7L  /  K3-3 MOV L  /  K5-5 BCON (1+2) H

037532  012700  000506          T0506:  MOV     #0506,R0                ;LOAD R0 WITH TEST NO.
037536  013701  037570                  MOV     @#I0506,R1      ;LOAD R1 WITH TEST INSTRUCTION  WORD
037542  005004                          CLR     R4              ;RESULT S / B = 000000
037544  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
037550  012705  067612                  MOV     #DWTA,R5        ;SOURCE ADDR = DWTA
037554  012703  067566          R0506:  MOV     #ATA,R3         ;BASE DEST ADDR = ATA
037560  005012                          CLR     (R2)            ;MAKE [DEST] = 177777
037562  005112                          COM     (R2)
037564  000257                          CCC                     ;CLEAR FLAGS
037566  000273                          273                     ;N:C = 1011

037570  011573  000010          I0506:  MOV     (R5),@10(R3)    ;TEST THE MOV - SM2,DM7

037574  100403                          BMI     E10506          ;N:C = 0101 ?
037576  001002                          BNE     E10506
037600  102401                          BVS     E10506
037602  103402                          BCS     A0506

037604  104005                  E10506: ERROR5                  ;MOV FAILED TO ALTER CODES PROPERLY
037606  037554                          R0506                   ;ERROR LOOP RETURN

037610  020412                  A0506:  CMP     R4,(R2)         ;RESULT CORRECT ??
037612  001404                          BEQ     00506           ;BR IF YES

037614  005003                          CLR     R3              ;GET THE WAS DATA
037616  051203                          BIS     (R2),R3
037620  104000                  E20506: ERROR                   ;MOV DELIVERED THE WRONG RESULT
037622  037554                          R0506                   ;ERROR LOOP RETURN

037624  000004                  00506:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0507 MOV  SM0,DM1 TEST
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [171,257,201,125,375,016] FC 1,4,8

                                ;ACT BUTS:      37[004]100,171  /  22[171]200,201  /  16[125]016,016

                                ;EXEC:          [201]ALUC=LLLLL :[125]D=TEST NO.

                                ;CODES:         [125] SPS=3      /      N:C=X000

                                ;SYNC:          B05J2   (-)     T=2.42 USEC

                                ;KEY SIG:       K3-3 MOV L  /  K3-3 SM=0 L  /  K3-3 DM=1 L

037626  012700  000507          T0507:  MOV     #0507,R0                ;LOAD R0 WITH TEST NO.
037632  013701  037652                  MOV     @#I0507,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
037636  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
037642  010004                          MOV     R0,R4           ;RESULT S / B = #T0507
037644  010205          R0507:  MOV     R2,R5           ;R5 GETS DEST ADDR
037646  005012                  CLR     (R2)            ;[DEST] = 000000
037650  000257                  CCC                     ;SCOPE SYNC

037652  010015          I0507:  MOV     R0,(R5)         ;TEST THE MOV

037654  020412                  CMP     R4,(R2)         ;RESULT CORRECT ?
037656  001403                  BEQ     00507           ;BR IF YES

037660  011203                  MOV     (R2),R3         ;GET THE WAS DATA
037662  104000          E0507:  ERROR                   ;MOV DELIVERED THE WRONG RESULT
037664  037644                  R0507                   ;ERROR LOOP RETURN ADDRESS

037666  000004          00507:  SCOPE                   ;CALL THE SCOPE LOOP UTILITY
```

```
                                        ; ***************************************************************
                                                .SBTTL T0510 MOV  SM0,DM2 TEST
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [172,257,201,125,375,016] FC 1,4,8

                                        ;ACT BUTS:      37[004]100,172  /  22[172]200,201  /  16[125]016,016

                                        ;EXEC:          [201]ALUC=LLLLL :[125]D= TEST NO.

                                        ;CODES:         [125]SPS=3       /       N:C=X000

                                        ;SYNC:          B05J2   (-)     T=2.5 USEC

                                        ;KEY SIG:       K3-3 MOV L  /  K3-3 SM=0 L  /  K3-3 DM=2 L  /  K5-5 BCON(1+2) H
                                                        ;K3-8 CIN00 L

037670  012700  000510          T0510:  MOV     #0510,R0                ;LOAD R0 WITH TEST NO.
037674  013701  037714                  MOV     @#I0510,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
037700  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
037704  010004                          MOV     R0,R4           ;RESULT S / B = #T0510
037706  010205                  R0510:  MOV     R2,R5           ;R5 GETS DEST ADDR
037710  005012                          CLR     (R2)            ;[DEST] = 000000
037712  000257                          CCC                     ;SCOPE SYNC

037714  010025                  I0510:  MOV     R0,(R5)+        ;TEST THE MOV

037716  020412                          CMP     R4,(R2)         ;RESULT CORRECT ?
037720  001403                          BEQ     00510           ;BR IF YES

037722  011203                          MOV     (R2),R3         ;GET THE WAS DATA
037724  104000                  E0510:  ERROR                   ;MOV DELIVERED THE WRONG RESULT
037726  037706                          R0510                   ;ERROR LOOP RETURN ADDRESS

037730  000004                  00510:  SCOPE                   ;CALL THE SCOPE LOOP UTILITY
```

N02


```
                                        ; ***********************************************************
                                                .SBTTL T0511 MOV  SM0,DM3 TEST
                                        ; ***********************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [173,207,210,201,125,375,016] FC 1,4,8

                                        ;ACT BUTS:      37[004]100,173  /  22[207]200,201  /  16[125]016,016

                                        ;EXEC:          [201]ALUC=LLLLL :[125]D= TEST NO.

                                        ;CODES:         [125]SPS=3       /      N:C=X000

                                        ;SYNC:          B05J2   (-)     T=3.2 USEC

                                        ;KEY SIG:       K3-3 MOV L  /  K3-3 SM=0 L  /  K3-3 DM=3 L  /  K5-5 BC01 H

037732  012700  000511          T0511:  MOV     #0511,R0                ;LOAD R0 WITH TEST NO.
037736  013701  037760                  MOV     @#I0511,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
037742  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
037746  010004                          MOV     R0,R4           ;RESULT S / B = #T0511
037750  012705  067576          R0511:  MOV     #ATA+10.R5      ;BASE DEST ADDR = ATA+10
037754  005012                          CLR     (R2)            ;[DEST] = 000000
037756  000257                          CCC                     ;SCOPE SYNC

037760  010035                  I0511:  MOV     R0,@(R5)+       ;TEST THE MOV

037762  020412                          CMP     R4,(R2)         ;CORRECT RESULT
037764  001403                          BEQ     00511           ;BR IF YES

037766  011203                          MOV     (R2),R3         ;GET THE WAS DATA
037770  104000                  E0511:  ERROR                   ;MOV DELIVERED THE WRONG RESULT
037772  037750                          R0511                   ;ERROR LOOP RETURN ADDRESS

037774  000004                  00511:  SCOPE                   ;CALL THE SCOPE LOOP UTILITY
```

```
                                        ; ***************************************************************
                                                .SBTTL TO512 MOV  SMO,DM4 TEST
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [174,257,201,125,375,016] FC 1,4,8

                                        ;ACT BUTS:      37[004]100,174  /  22[174]200,201  /  16[125]016,016

                                        ;EXEC:          [201]ALUC=LLLLL :[125]D= TEST NO.

                                        ;CODES:         [125]SPS=3       /      N:C=X000

                                        ;SYNC:          B05J2   (-)     T=2.5 USEC

                                        ;KE' SIG:       K3-3 MOV L  /  K3-3 SM=0 L  /  K3-3 DM=4 L  /  K5-5 BCON(1+2) H
                                                        ;K3-8 CINOO L

037776  012700  000512          TO512:  MOV     #0512,R0                ;LOAD R0 WITH TEST NO.
040002  013701  040024                  MOV     @#IO512,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
040006  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
040012  010004                          MOV     R0,R4           ;RESULT S / B = #TO512
040014  012705  067604          RO512:  MOV     #MBUF0+2,R5     ;R5 CONTAINS BASE DEST ADDR
040020  005012                          CLR     (R2)            ;[DEST] = 000000
040022  000257                          CCC                     ;SCOPE SYNC

040024  010045                  IO512:  MOV     R0,-(R5)        ;TEST THE MOV

040026  020412                          CMP     R4,(R2)         ;CORRECT RESULT ?
040030  001403                          BEQ     00512           ;BR IF YES

040032  011203                          MOV     (R2),R3         ;GET THE WAS DATA
040034  104000                  EO512:  ERROR                   ;MOV DELIVERED THE WRONG RESULT
040036  040014                          RO512                   ;ERROR LOOP RETURN ADDRESS

040040  000004                  00512:  SCOPE                   ;CALL THE SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL TO513 MOV  SMO,DM5 TEST
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [175,207,210,201,125,375,016] FC 1,4,8

                                ;ACT BUTS:      37[004]100,175  /  22[207]200,201  /  16[125]016,016

                                ;EXEC:          [201]ALUC=LLLLL :[125]D= TEST NO.

                                ;CODES:         [125]SPS=3       /      N:C=X000

                                ;SYNC:          B05J2   (-)     T= 3.2 USEC

                                ;KEY SIG:       K3-3 MOV L  /  K3-3 SM=0 L  /  K3-3 DM=5 L  /  K5-5 BC01 H

040042  012700  000513          TO513:  MOV     #O513,R0                ;LOAD R0 WITH TEST NO.
040046  013701  040070                  MOV     @#IO513,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
040052  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
040056  010004                          MOV     R0,R4           ;RESULT S / B = #TO513
040060  012705  067600          RO513:  MOV     #ATA+12,R5      ;R5 CONTAINS BASE DEST ADDR
040064  005012                          CLR     (R2)            ;[DEST] = 000000
040066  000257                          CCC                     ;SCOPE SYNC

040070  010055                  IO513:  MOV     R0,@-(R5)       ;TEST THE MOV

040072  020412                          CMP     R4,(R2)         ;CORRECT RESULT ?
040074  001403                          BEQ     00513           ;BR IF YES

040076  011203                          MOV     (R2),R3         ;GET THE WAS DATA
040100  104000                  EO513:  ERROR                   ;MOV DELIVERED THE WRONG RESULT
040102  040060                          RO513                   ;ERROR LOOP RETURN ADDRESS

040104  000004                  00513:  SCOPE                   ;CALL THE SCOPE LOOP UTILITY
```

```
                                        ; ***************************************************************
                                                .SBTTL TO514 MOV  SMO,DM6 TEST
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [176,206,212,201,125,375,016] FC 1,4,8

                                        ;ACT BUTS:      37[004]100,176  /  17[176]212,212  /  21[206]200,201
                                                        ; /  16[125]016,016

                                        ;EXEC:          [201]ALUC=LLLLL :[125]D= TEST NO.

                                        ;CODES:         [125]SPS=3       /       N:C=X000

                                        ;SYNC:          BOSJ2   (-)     T= 2.84 USEC

                                        ;KEY SIG:       K3-3 MOV L  /  K3-3 SM=0 L  /  K3-3 DM=6 L  /  K5-5 BC01 H
                                                        ;K4-4 OVLAP CYCLE L

040106  012700  000514          TO514:  MOV     #O514,R0                ;LOAD R0 WITH TEST NO.
040112  013701  040134                  MOV     @#IO514,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
040116  012702  067606                  MOV     #MBUF1,R2       ;DEST ADDR = MBUF1
040122  010004                          MOV     R0,R4           ;RESULT S / B = #TO514
040124  012705  067602                  MOV     #MBUF0,R5       ;BASE DEST ADDR = MBUF0
040130  005012                  RO514:  CLR     (R2)            ;[DEST] = 000000
040132  000257                          CCC                     ;SCOPE SYNC

040134  010065  000004          IO514:  MOV     R0,4(R5)        ;TEST THE MOV

040140  020412                          CMP     R4,(R2)         ;RESULT CORRECT ?
040142  001403                          BEQ     OO514           ;BR IF YES

040144  011203                          MOV     (R2),R3         ;GET THE WAS DATA
040146  104000                  EO514:  ERROR                   ;MOV DELIVERED THE WRONG RESULT
040150  040130                          RO514                   ;ERROR LOOP RETURN ADDRESS

040152  000004                  OO514:  SCOPE                   ;CALL THE SCOPE LOOP UTILITY
```

```
                                        ; ***************************************************************
                                                .SBTTL TO515 MOVB TEST - SMO,DMO - EXTEND 1'S
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [170,204,003,204,001] FC 1,4

                                        ;ACT BUTS:      37[004]100,170 / 20[170]000,003 / 27[003]000,001

                                        ;EXEC:          [170]ALUC=LLLLL :[204] AND TIME D = 177652

                                        ;CODES:         [204] SPS=3  /  N:C = 1000

                                        ;SYNC:          BOSJ2 (-) T = 1.8 USEC

                                        ;KEY SIG:       K3-6 BYTE INSTR H  /  K3-3 MOV L  /  K3-3 SM=OL  /  K3-3 DM=OL

040154  012700  000515                  TO515:  MOV     #0515,R0                ;LOAD R0 WITH TEST NO.
040160  013701  040206                          MOV     @#I0515,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
040164  012702  177703                          MOV     #177703,R2      ;DEST ADDR = R3
040170  012704  177652                          MOV     #177652,R4      ;RESULT S / B = 177652
040174  012705  000252                          MOV     #252,R5         ;SOURCE OP = 252
040200  005003                          R0515:  CLR     R3              ;[DEST] = 000000
040202  000257                                  CCC                     ;CLEAR FLAGS
040204  000266                                  266                     ;N:C = 0110

040206  110503                          I0515:  MOVB    R5,R3           ;TEST THE MOVB

040210  100003                                  BPL     E10515          ;N:C = 1000 ?
040212  001402                                  BEQ     E10515
040214  102401                                  BVS     E10515
040216  103002                                  BCC     A0515

040220  104005                          E10515: ERROR5                  ;MOVB FAILED TO ALTER CODES PROPERLY
040222  040200                                  R0515                   ;ERROR LOOP RETURN ADDRESS

040224  020403                          A0515:  CMP     R4,R3           ;RESULT CORRECT ?
040226  001402                                  BEQ     00515           ;BR IF YES

040230  104000                          E20515: ERROR                   ;MOVB DELIVERED THE WRONG RESULT
040232  040200                                  R0515                   ;ERROR LOOP RETURN ADDRESS

040234  000004                          00515:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL TO516 MOVB TEST - SMO,DMO - EXTEND 0'S
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [170,204,003,204,001] FC 1,4

                                ;ACT BUTS:      37[004]100,170 / 20[170]000,003 / 27[003]000,001

                                ;EXEC:          [170]ALUC=LLLLL :[204] D = 000000

                                ;CODES:         [204] SPS=3  /  N:C = 0101

                                ;SYNC:          B05J2 (-) T = 1.8 USEC

                                ;KEY SIG:       K3-6 BYTE INSTR H  /  K3-3 MOV L

040236  012700  000516          TO516:  MOV     #0516,R0                ;LOAD R0 WITH TEST NO.
040242  013701  040270                  MOV     @#IO516,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
040246  012702  177703                  MOV     #177703,R2      ;DEST ADDR = R3
040252  005004                          CLR     R4              ;RESULT S / B = 000000
040254  012705  177400                  MOV     #177400,R5      ;SOURCE OP = 177400
040260  005003                  RO516:  CLR     R3              ;[DEST] = 177777
040262  005103                          COM     R3
040264  000257                          CCC                     ;CLEAR FLAGS
040266  000271                          271                     ;N:C = 1001

040270  110503                  IO516:  MOVB    R5,R3           ;TEST THE MOVB

040272  100403                          BMI     E10516          ;N:C = 0101 ?
040274  001002                          BNE     E10516
040276  102401                          BVS     E10516
040300  103402                          BCS     AO516

040302  104005                  E10516: ERROR5                  ;MOVB FAILED TO ALTER CODES PROPERLY
040304  040260                          RO516                   ;ERROR LOOP RETURN ADDRESS

040306  020403                  AO516:  CMP     R4,R3           ;RESULT CORRECT ?
040310  001402                          BEQ     OO516           ;BR IF YES

040312  104000                  E20516: ERROR                   ;MOVB DELIVERED THE WRONG RESULT
040314  040260                          RO516                   ;ERROR LOOP RETURN ADDRESS

040316  000004                  OO516:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***********************************************************************
                                        .SBTTL T0517 MOVB TEST - SM1,DM0 - SOURCE ADDR EVEN
                                ; ***********************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [141,247,250,160,204,003,204,000] FC 1,2,4

                                ;ACT BUTS:      37[004]140,141 / 35[247]120,160 / 20[160]000,003 / 27[003]000,000

                                ;EXEC:          [160]ALUC=LLLLL :[204] 2ND TIME D = 000000

                                ;CODES:         [204] SPS=3  /  N:C = 0100

                                ;SYNC:          B05J2 (-) T = 2 USEC

                                ;KEY SIG:       K3-6 BYTE INSTR H  /  K3-3 MOV L  /  K3-3 SM=1L  /  K3-3 DM=0L

040320  012700  000517          T0517:  MOV     #0517,R0                ;LOAD R0 WITH TEST NO.
040324  013701  040350                  MOV     @#I0517,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
040330  012702  177703                  MOV     #177703,R2      ;DEST ADDR = R3
040334  005004                          CLR     R4              ;RESULT S / B = 000000
040336  012705  070152                  MOV     #DBTA,R5        ;SOURCE ADDR = DBTA
040342  005003                  R0517:  CLR     R3              ;[DEST] = 177777
040344  005103                          COM     R3
040346  000257                          CCC                     ;SCOPE SYNC

040350  111503                  I0517:  MOVB    (R5),R3         ;TEST THE MOVB

040352  020403                          CMP     R4,R3           ;RESULT CORRECT ?
040354  001402                          BEQ     00517           ;BR IF YES

040356  104000                  E0517:  ERROR                   ;MOVB DELIVERED THE WRONG RESULT
040360  040342                          R0517                   ;ERROR LOOP RETURN ADDRESS

040362  000004                  00517:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0520 MOVB TEST - SM1,DM0 - SOURCE ADDR ODD
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [141,247,250,137,251,160,204,003,204,000] FC 1,2,4

                                ;ACT BUTS:      37[004]100,141 / 35[247]120,137 / 20[160]000,003 / 27[003]000,000

                                ;EXEC:          [160]ALUC=LLLLL :[204](2ND TIME)  D = 000125

                                ;CODES:         [204] SPS=3  /  N:C = 0000

                                ;SYNC:          B05J2 (-) T = 2 USEC

                                ;KEY SIG:       K3-6 BYTE INSTR H  /  K3-3 MOV L  /  K3-7 ODD BYTE H  /  K1-6 BA00 (1) H

040364  012700  000520          T0520:  MOV     #0520,R0                ;LOAD R0 WITH TEST NO.
040370  013701  040416                  MOV     @#I0520,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
040374  012702  177703                  MOV     #177703,R2      ;DEST ADDR = R3
040400  012704  000125                  MOV     #125,R4         ;RESULT S / B = 125
040404  012705  070155                  MOV     #DBTA+3,R5      ;SOURCE ADDR = DBTA+3
040410  012703  177400          R0520:  MOV     #177400,R3      ;[DEST] = 177400
040414  000257                          CCC                     ;SCOPE SYNC

040416  111503                  I0520:  MOVB    (R5),R3         ;TEST THE MOVB

040420  020403                          CMP     R4,R3           ;RESULT CORRECT ?
040422  001402                          BEQ     00520           ;BR IF YES

040424  104000                  E0520:  ERROR                   ;MOVB DELIVERED THE WRONG RESULT
040426  040410                          R0520                   ;ERROR LOOP RETURN ADDRESS

040430  000004                  00520:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***************************************************************
                                                .SBTTL T0521 MOVB TEST - SM2,DM0 - SOURCE ADDR ODD
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [142,240,250,137,251,160,204,003,204,000] FC 1,2,4

                                        ;ACT BUTS:      37[004]100,142 / 35[240]120,137 / 36[137]120,160 / 20[160]000,003
                                                        ; / 27[003]000,000

                                        ;EXEC:          [160]ALUC=LLLLL :[204] 2ND TIME D = 177777

                                        ;CODES:         [204] SPS=3  /  N:C = 1000

                                        ;SYNC:          B05J2 (-) T = 2.1 USEC

                                        ;KEY SIG:       K3-6 BYTE INSTR H  /  K3-3 MOV L  /  K5-5 BCON (1+2) H  /  K3-7 ODD BYTE
                                                        ;  K1-6 BADD (1) H

040432  012700  000521          T0521:  MOV     #0521,R0                ;LOAD R0 WITH TEST NO.
040436  013701  040462                  MOV     @#T0521,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
040442  012702  177703                  MOV     #177703,R2      ;DEST ADDR = R3
040446  012704  177777                  MOV     #-1,R4          ;RESULT S / B = 177777
040452  012705  070153          R0521:  MOV     #DBTA+1,R5      ;SOURCE ADDR = DBTA+1
040456  005003                          CLR     R3              ;[DEST] = 000000
040460  000257                          CCC                     ;SCOPE SYNC

040462  112503                  I0521:  MOVB    (R5)+,R3        ;TEST THE MOVB

040464  020403                          CMP     R4,R3           ;RESULT CORRECT ?
040466  001402                          BEQ     A0521           ;BR IF YES

040470  104000                  E10521: ERROR                   ;MOVB DELIVERED THE WRONG RESULT
040472  040452                          R0521                   ;ERROR LOOP RETURN ADDRESS

040474  022705  070154          A0521:  CMP     #DBTA+2,R5      ;DID MOVB INCREMENT SRC REG ?
040500  001402                          BEQ     O0521           ;BR IF YES

040502  104005                  E20521: ERROR5                  ;MOVB FAILED TO UPDATE SRC REG
040504  040452                          R0521                   ;ERROR LOOP RETURN ADDRESS

040506  000004                  O0521:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***************************************************************
                                                .SBTTL T0522 MOVB TEST - SM2,DM0 - SOURCE ADDR EVEN
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [142,240,250,160,204,003,204,000] FC 1,2,4

                                        ;ACT BUTS:      37[004]100,142 / 35[240]120,160 / 20[160]000,003 / 27[003]000,000

                                        ;EXEC:          [160]ALUC=LLLLL :[204]2ND TIME D = 000000

                                        ;CODES:         [204] SPS=3  /  N:C - 0100

                                        ;SYNC:          B05J2 (-) T = 2.1 USEC

                                        ;KEY SIG:       K3-6 BYTE INSTR H  /  K3-3 MOV L  /  K5-5 BCON (1+2) H

040510  012700  000522          T0522:  MOV     #0522,R0                ;LOAD R0 WITH TEST NO.
040514  013701  040540                  MOV     @#I0522,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
040520  012702  177703                  MOV     #177703,R2      ;DEST ADDR = R3
040524  005004                          CLR     R4              ;RESULT S / B = 000000
040526  012705  070152          R0522:  MOV     #DBTA,R5        ;SOURCE ADDR = DBTA
040532  012703  177400                  MOV     #177400,R3      ;[DEST] = 177400
040536  000257                          CCC                     ;SCOPE SYNC

040540  112503                  I0522:  MOVB    (R5)+,R3                ;TEST THE MOVB

040542  020403                          CMP     R4,R3           ;RESULT CORRECT ?
040544  001402                          BEQ     A0522           ;BR IF YES

040546  104000                  E10522: ERROR                   ;MOVB DELIVERED THE WRONG RESULT
040550  040526                          R0522                   ;ERROR LOOP RETURN ADDRESS

040552  022705  070153          A0522:  CMP     #DBTA+1,R5      ;DID MOVB INCREMENT SRC REG ?
040556  001402                          BEQ     00522           ;BR IF YES

040560  104005                  E20522: ERROR5                  ;MOVB FAILED TO UPDATE SOURCE REG
040562  040526                          R0522                   ;ERROR LOOP RETURN ADDRESS

040564  000004                  G0522:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ****************************************************************
                                        .SBTTL T0523 MOVB TEST - SM1,DM1 - SRC ADR ODD / DST ADR EVEN
                                ; ****************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [141,247,250,137,251,171,257,202,205,125,375,016] FC 1,2,4,8

                                ;ACT BUTS:      37[004]100,141 / 35[247]120,137 / 36[137]120,171 / 22[171]200,202
                                                ; / 16[125]016,016

                                ;EXEC:          [202]ALUC=LLLLL :[125] D = 177777

                                ;CODES:         [125] SPS=3  /  N:C = 1000

                                ;SYNC:          B05J2 (-) T = 3.2 USEC

                                ;KEY SIG:       K3-6 BYTE INSTR H  /  K3-3 MOV L  /  K3-3 SM=1L  /  K3-3 DM=1L
                                                ;  K1-6 BA00(1) H  /  K3-7 ODD BYTE H

040566  012700  000523          T0523:  MOV     #0523,R0                ;LOAD R0 WITH TEST NO.
040572  013701  040616                  MOV     @#I0523,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
040576  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
040602  012704  000377                  MOV     #377,R4         ;RESULT S / B = 377
040606  012705  070153                  MOV     #DBTA+1,R5      ;SRC ADDR = DBTA +1
040612  005012                  R0523:  CLR     (R2)            ;[DEST] = 000000
040614  000257                          CCC                     ;CLEAR FLAGS - SCOPE SYNC

040616  111512                  I0523:  MOVB    (R5),(R2)       ;TEST THE MOVB

040620  020412                          CMP     R4,(R2)         ;CORRECT RESULT ?
040622  001403                          BEQ     00523           ;BR IF YES

040624  011203                          MOV     (R2),R3         ;GET THE WAS DATA
040626  104000                  E0523:  ERROR                   ;MOVB DELIVERED WRONG RESULT
040630  040612                          R0523                   ;ERROR LOOP RETURN ADDRESS

040632  000004                  00523:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***************************************************************
                                                .SBTTL T0524 MOVB TEST - SM1,DM2 - SRC ADR ODD / DST ADR EVEN
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [141,247,250,137,251,172,257,202,205,125,375,016] FC 1,2,4,8

                                        ;ACT BUTS:      37[004]100,141 / 35[247]120,137 / 36[137]120,172 / 22[172]200,202
                                                        ; / 16[125]016,016

                                        ;EXEC:          [202]ALUC=LLLLL :[125] D = 177777

                                        ;CODES:         [125] SPS=3  /  N:C = 1000

                                        ;SYNC:          BOSJ2 (-) T = 3.7 USEC

                                        ;KEY SIG:       K3-6 BYTE INSTR H  /  K3-3 MOV L  /  K5-5 BCON (1+2) H  /  K3-7 ODD BYTE
                                                        ;  K1-6 BAOD(1) H

040634  012700  000524          T0524:  MOV     #0524,R0                ;LOAD R0 WITH TEST NO.
040640  013701  040666                  MOV     @#I0524,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
040644  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
040650  012704  000377                  MOV     #377,R4         ;RESULT S / B = 377
040654  012705  070153                  MOV     #DBTA+1,R5      ;SRC ADDR = DBTA +1
040660  005012                  R0524:  CLR     (R2)            ;[DEST] = 000000
040662  010203                          MOV     R2,R3           ;[R3] = DEST ADDR
040664  000257                          CCC                     ;CLEAR FLAGS - SCOPE SYNC

040666  111523                  I0524:  MOVB    (R5),(R3)+      ;TEST THE MOVB

040670  020412                          CMP     R4,(R2)         ;CORRECT RESULT ?
040672  001403                          BEQ     A0524           ;BR IF YES

040674  011203                          MOV     (R2),R3         ;GET THE WAS DATA
040676  104000                  E10524: ERROR                   ;MOVB DELIVERED WRONG RESULT
040700  040660                          R0524                   ;ERROR LOOP RETURN ADDRESS

040702  022703  067603          A0524:  CMP     #MBUF0+1,R3     ;DID MOVB INCREMENT THE DEST REG ?
040706  001402                          BEQ     00524           ;BR IF YES

040710  104005                  E20524: ERROR5                  ;MOVB FAILED TO UPDATE DEST REG
040712  040660                          R0524                   ;ERROR LOOP RETURN ADDRESS

040714  000004                  00524:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0525 MOVB TEST - SM1,DM3 - SRC ADR ODD / DST ADR EVEN
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [141,247,250,137,251,173,207,210,202,205,125,375,016] FC 1,2,4,8

                                ;ACT BUTS:      37[004]100,141 / 35[247]120,137 / 36[137]120,173 / 22[207]200,202
                                                ; / 16[125]016,016

                                ;EXEC:          [202]ALUC=LLLLL :[125] D = 177777

                                ;CODES:         [125] SPS=3  /  N:C = 1000

                                ;SYNC:          B05J2 (-) T = 4 USEC

                                ;KEY SIG:       K3-6 BYTE INSTR H  /  K3-3 MOV L  /  K5-5 BC01 H  /  K3-7 ODD BYTE H
                                                ;  K1-6 BADD (1) H

040716  012700  000525          T0525:  MOV     #0525,R0                ;LOAD R0 WITH TEST NO.
040722  013701  040752                  MOV     @#I0525,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
040726  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
040732  012704  000377                  MOV     #377,R4         ;RESULT S / B = 377
040736  012705  070153                  MOV     #DBTA+1,R5      ;SRC ADDR = DBTA +1
040742  005012                  R0525:  CLR     (R2)            ;[DEST] = 000000
040744  012703  067576                  MOV     #ATA+10,R3      ;BASE DEST ADDR = ATA +10
040750  000257                          CCC                     ;CLEAR FLAGS - SCOPE SYNC

040752  111533                  I0525:  MOVB    (R5),@(R3)+     ;TEST THE MOVB

040754  022703  067600                  CMP     #ATA+12,R3      ;DID DEST REG GET INCREMENTED ?
040760  001402                          BEQ     A0525           ;BR IF YES

040762  104005                  E10525: ERROR5                  ;MOVB FAILED TO UPDATE DEST REG
040764  040742                          R0525                   ;ERROR LOOP RETURN ADDRESS

040766  020412                  A0525:  CMP     R4,(R2)         ;CORRECT RESULT ?
040770  001403                          BEQ     00525           ;BR IF YES

040772  011203                          MOV     (R2),R3         ;GET THE WAS DATA
040774  104000                  E20525: ERROR                   ;MOVB DELIVERED WRONG RESULT
040776  040742                          R0525                   ;ERROR LOOP RETURN ADDRESS


041000  000004                  00525:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0526 MOVB TEST - SM1,DM4 - SRC ADR ODD / DST ADR EVEN
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [141,247,250,137,251,174,257,202,205,125,375,016] FC 1,2,4,8

                                ;ACT BUTS:      37[004]100,141 / 35[247]120,137 / 36[137]120,174 / 22[174]200,202
                                                ; / 16[125]016,016

                                ;EXEC:          [202]ALUC=LLLLL :[125] D = 177777

                                ;CODES:         [125] SPS=3  /  N:C = 1000

                                ;SYNC:          B05J2 (-) T = 3.1 USEC

                                ;KEY SIG:       K3-6 BYTE INSTR H  /  K3-3 MOV L  /  K5-5 BCON (1+2) H  /  K3-7 ODD BYTE
                                                ;  K1-6 BA00(1) H

041002  012700  000526          T0526:  MOV     #0526,R0                ;LOAD R0 WITH TEST NO.
041006  013701  041036                  MOV     @#I0526,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
041012  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
041016  012704  000377                  MOV     #377,R4         ;RESULT S / B = 377
041022  012705  070153                  MOV     #DBTA+1,R5      ;SRC ADDR = DBTA +1
041026  005012          R0526:  CLR     (R2)            ;[DEST] = 000000
041030  012703  067603                  MOV     #MBUF0+1,R3     ;INITIAL DEST ADDR = MBUF0+1
041034  000257                          CCC                     ;CLEAR FLAGS - SCOPE SYNC

041036  111543          I0526:  MOVB    (R5),-(R3)      ;TEST THE MOVB

041040  020302                  CMP     R3,R2           ;DID MOVB DECREMENT DEST REG ?
041042  001402                  BEQ     A0526           ;BR IF YES

041044  104005          E10526: ERROR5                  ;MOVB FAILED TO UPDATE DEST REG
041046  041026                  R0526                   ;ERROR LOOP RETURN ADDRESS

041050  020412          A0526:  CMP     R4,(R2)         ;CORRECT RESULT ?
041052  001403                  BEQ     00526           ;BR IF YES

041054  011203                  MOV     (R2),R3         ;GET THE WAS DATA
041056  104000          E20526: ERROR                   ;MOVB DELIVERED WRONG RESULT
041060  041026                  R0526                   ;ERROR LOOP RETURN ADDRESS

041062  000004          00526:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0527 MOVB TEST - SM1,DM5 - SRC ADR ODD / DST ADR EVEN
                                ; ***************************************************************

                                ;MICROPROGRAMMING     LOGIC INFORMATION

                                ;ROM SEQ:       [141,247,250,137,251,175,207,210,202,205,125,375,016] FC 1,2,4,8

                                ;ACT BUTS:      37[004]100,141 / 35[247]120,137 / 36[137]120,175 / 22[207]200,202
                                                ; / 16[125]016,016

                                ;EXEC:          [202]ALUC=LLLLL :[125] D = 177777

                                ;CODES:         [125] SPS=3  /  N:C = 1000

                                ;SYNC:          B05J2 (-) T = 4 USEC

                                ;KEY SIG:       K3-6 BYTE INSTR H  /  K3-3 MOV L  /  K5-5 BC01 H  /  K3-7 ODD BYTE H
                                                ;  K1-6 BADD(1) H

041064  012700  000527          T0527:  MOV     #0527,R0                ;LOAD R0 WITH TEST NO.
041070  013701  041120                  MOV     @#I0527,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
041074  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
041100  012704  000377                  MOV     #377,R4         ;RESULT S / B = 377
041104  012705  070153                  MOV     #DBTA+1,R5      ;SRC ADDR = DBTA +1
041110  005012          R0527:  CLR     (R2)            ;[DEST] = 000000
041112  012703  067600                  MOV     #ATA+12,R3      ;INITIAL DEST ADDR = ATA +12
041116  000257                          CCC                     ;CLEAR FLAGS - SCOPE SYNC

041120  111553          I0527:  MOVB    (R5),@-(R3)     ;TEST THE MOVB

041122  022703  067576                  CMP     #ATA+10,R3      ;DID MOVB DECREMENT DEST REG ?
041126  001402                          BEQ     A0527           ;BR IF YES

041130  104005          E10527: ERROR5                          ;MOVB FAILED TO UPDATE DEST REG
041132  041110                  R0527                           ;ERROR LOOP RETURN ADDRESS

041134  020412          A0527:  CMP     R4,(R2)         ;CORRECT RESULT ?
041136  001403                  BEQ     00527           ;BR IF YES

041140  011203                  MOV     (R2),R3         ;GET THE WAS DATA
041142  104000          E20527: ERROR                           ;MOVB DELIVERED WRONG RESULT
041144  041110                  R0527                           ;ERROR LOOP RETURN ADDRESS

041146  000004          00527:  SCOPE                           ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***************************************************************
                                                .SBTTL T0530 MOVB TEST - SM1,DM6 - SRC ADR ODD / DST ADR EVEN
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [141,247,250,137,251,177,206,212,202,205,125,375,016] FC 1,2,4,8

                                        ;ACT BUTS:      37[004]100,141 / 35[247]120,137 / 36[137]120,177 / 17[177]212,212
                                                        ; / 21[206]200,202 / 16[125]016,016

                                        ;EXEC:          [202]ALUC=LLLLL :[125] D = 177777

                                        ;CODES:         [125] SPS=3  /  N:C = 1000

                                        ;SYNC:          BOSJ2 (-) T = 4.4 USEC

                                        ;KEY SIG:       K3-6 BYTE INSTR H  /  K3-3 MOV L  /  K3-5 BC01 H  /  K3-7 ODD BYTE H
                                                        ;  K1-6 BADC(1) H

041150  012700  000530          T0530:  MOV     #0530,R0                ;LOAD R0 WITH TEST NO.
041154  013701  041204                  MOV     @#I0530,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
041160  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
041164  012704  000377                  MOV     #377,R4         ;RESULT S / B = 377
041170  012705  070153                  MOV     #DBTA+1,R5      ;SRC ADDR = DBTA +1
041174  005012          R0530:  CLR     (R2)            ;[DEST] = 000000
041176  012703  067610                  MOV     #MBUF0+6,R3     ;BASE DEST ADDR = MBUF0+6
041202  000257                          CCC                     ;CLEAR FLAGS - SCOPE SYNC

041204  111563  177772          I0530:  MOVB    (R5),-6(R3)     ;TEST THE MOVB

041210  020412                          CMP     R4,(R2)         ;CORRECT RESULT ?
041212  001403                          BEQ     00530           ;BR IF YES

041214  011203                          MOV     (R2),R3         ;GET THE WAS DATA
041216  104000          E0530:  ERROR                           ;MOVB DELIVERED WRONG RESULT
041220  041174                          R0530                   ;ERROR LOOP RETURN ADDRESS

041222  000004          00530:  SCOPE                           ;CALL THE SCOPE LOOP UTILITY
```

```
                                        ; ***************************************************************
                                                .SBTTL T0531 MOVB TEST - SM1,DM7 - SRC ADR ODD / DST ADR EVEN
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [141,247,250,137,251,177,206,213,207,210,202,205,125,375,016] FC 1,2,4,8

                                        ;ACT BUTS:      37[004]100,141 / 35[247]120,137 / 36[137]120,177 / 17[177]212,213
                                                        ; / 21[206]XNU / 22[207]200,202 / 16[125]016,016

                                        ;EXEC:          [202]ALUC=LLLLL :[125] D = 177777

                                        ;CODES:         [125] SPS=3  /  N:C - 1000

                                        ;SYNC:          B05J2 (-) T = 4.8 USEC

                                        ;KEY SIG:       K3-6 BYTE INSTR H  /  K3-3 MOV L  /  K5-5 BC01 H  /  K3-7 ODD BYTE H
                                                        ;  K1-6 BA00 (1) H

041224  012700  000531          T0531:  MOV     #0531,R0                ;LOAD R0 WITH TEST NO.
041230  013701  041260                  MOV     @#T0531,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
041234  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
041240  012704  000377                  MOV     #377,R4         ;RESULT S / B = 377
041244  012705  070153                  MOV     #DBTA+1,R5      ;SRC ADDR = DBTA +1
041250  005012          R0531:  CLR     (R2)            ;[DEST] = 000000
041252  012703  067566                  MOV     #ATA,R3         ;BASE DEST ADDR = ATA
041256  000257                          CCC                     ;CLEAR FLAGS - SCOPE SYNC

041260  111573  000010          T0531:  MOVB    (R5),@10(R3)    ;TEST THE MOVB

041264  020412                          CMP     R4,(R2)         ;CORRECT RESULT ?
041266  001403                          BEQ     00531           ;BR IF YES

041270  011203                          MOV     (R2),R3         ;GET THE WAS DATA
041272  104000          E0531:  ERROR                           ;MOVB DELIVERED WRONG RESULT
041274  041250                  R0531                           ;ERROR LOOP RETURN ADDRESS

041276  000004          00531:  SCOPE                           ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0532 MOVB  SM0,DM1 TEST
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [171,257,203,205,125,375,016] FC 1,4,8

                                ;ACT BUTS:      37[004]100,171  /  22[171]200,203  /  16[125]016,016

                                ;EXEC:          [203]ALUC=LLLLL :[125]D=177777

                                ;CODES:         [125]SPS=3       /      N:C=1000

                                ;SYNC:          B05J2   (-)     T=2.6 USEC

                                ;KEY SIG:       K3-3 MOV L  /  K3-3 SM=0 L  /  K3-3 DM=1 L  /  K3-6 BYTE INSTR H

041300  012700  000532          T0532:  MOV     #0532,R0                ;LOAD R0 WITH TEST NO.
041304  013701  041332                  MOV     @#I0532,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
041310  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
041314  012704  000377                  MOV     #377,R4         ;RESULT S / B = 377
041320  012703  177777                  MOV     #-1,R3          ;R3 CONTAINS SOURCE OP
041324  010205                  R0532:  MOV     R2,R5           ;R5 CONTAINS DEST ADDR
041326  005012                          CLR     (R2)            ;[DEST] = 000000
041330  000257                          CCC                     ;SCOPE SYNC

041332  110315                  I0532:  MOVB    R3,(R5)         ;TEST THE MOVB

041334  020412                          CMP     R4,(R2)         ;RESULT CORRECT ?
041336  001403                          BEQ     00532           ;BR IF YES

041340  011203                          MOV     (R2),R3         ;GET THE WAS DATA
041342  104000                  E0532:  ERROR                   ;MOVB DELIVERED THE WRONG RESULT
041344  041324                          R0532                   ;ERROR LOOP RETURN ADDRESS

041346  000004                  00532:  SCOPE                   ;CALL THE SCOPE LOOP UTILITY
```

```
                                        ; ***************************************************************
                                                .SBTTL TO533 MOVB  SM0,DM2 TEST
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [172,257,203,205,125,375,016] FC 1,4,8

                                        ;ACT BUTS:      37[004]100,172  /  22[172]200,203  /  16[125]016,016

                                        ;EXEC:          [203]ALUC=LLLLL :[125]D=177777

                                        ;CODES:         [125]SPS=3       /      N:C=1000

                                        ;SYNC:          B05J2   (-)     T=2.6 USEC

                                        ;KEY SIG:       K3-3 MOV L  /  K3-3 SM=0 L  /  K3-3 DM=1 L  /  K3-6 BYTE INSTR H
                                                        ;  K5-5 BCON(1+2) H

041350  012700  000533          TO533:  MOV     #0533,R0                ;LOAD R0 WITH TEST NO.
041354  013701  041402                  MOV     @#IO533,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
041360  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
041364  012704  000377                  MOV     #377,R4         ;RESULT S / B = 377
041370  012703  177777                  MOV     #-1,R3          ;R3 CONTAINS SOURCE OP
041374  010205                  RO533:  MOV     R2,R5           ;R5 CONTAINS DEST ADDR
041376  005012                          CLR     (R2)            ;[DEST] = 000000
041400  000257                          CCC                     ;SCOPE SYNC

041402  110325                  IO533:  MOVB    R3,(R5)+        ;TEST THE MOVB

041404  020412                          CMP     R4,(R2)         ;RESULT CORRECT ?
041406  001403                          BEQ     00533           ;BR IF YES

041410  011203                          MOV     (R2),R3         ;GET THE WAS DATA
041412  104000                  EO533:  ERROR                   ;MOVB DELIVERED THE WRONG RESULT
041414  041374                          RO533                   ;ERROR LOOP RETURN ADDRESS

041416  000074                  00533:  SCOPE                   ;CALL THE SCOPE LOOP UTILITY
```

```
                                        ; ***************************************************************
                                                .SBTTL T0534 MOVB  SM0,DM3 TEST
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [173,207,210,203,205,125,375,016] FC 1,4,8

                                        ;ACT BUTS:      37[004]100,173  /  22[207]200,203  / 16[125]016,016

                                        ;EXEC:          [203]ALUC=LLLLL :[125]D=177777

                                        ;CODES:         [125]SPS=3       /      N:C=1000

                                        ;SYNC:          B05J2   (-)     T=3.4 USEC

                                        ;KEY SIG:       K3-3 MOV L  /  K3-6 BYTE INSTR H  /  K3-3 SM=0 L  /  K3-3 DM=3 L

041420  012700  000534                  T0534:  MOV     #0534,R0                ;LOAD R0 WITH TEST NO.
041424  013701  041454                          MOV     @#I0534,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
041430  012702  067602                          MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
041434  012704  000377                          MOV     #377,R4         ;RESULT S / B = 377
041440  012703  177777                          MOV     #-1,R3          ;SOURCE OP IN R3
041444  012705  067576                  R0534:  MOV     #ATA+10,R5      ;BASE DEST ADDR = ATA+10
041450  005012                                  CLR     (R2)            ;[DEST] = 000000
041452  000257                                  CCC                     ;SCOPE SYNC

041454  110335                          I0534:  MOVB    R3,@(R5)+       ;TEST THE MOVB

041456  020412                                  CMP     R4,(R2)         ;RESULT CORRECT ?
041460  001403                                  BEQ     00534           ;BR IF YES

041462  011203                                  MOV     (R2),R3         ;GET THE WAS DATA
041464  104000                          E0534:  ERROR                   ;MOVB DELIVERED THE WRONG RESULT
041466  041444                                  R0534                   ;ERROR LOOP RETURN ADDRESS

041470  000004                          00534:  SCOPE                   ;CALL THE SCOPE LOOP UTILITY
```

```
                                        ; ***************************************************************
                                                .SBTTL T0535 MOVB  SM0,DM4 TEST
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [174,257,203,205,125,375,016] FC 1,4,8

                                        ;ACT BUTS:      37[004]100,174  /  22[174]200,203  /  16[125]016,016

                                        ;EXEC:          [203]ALUC=LLLLL :[125]D=177777

                                        ;CODES:         [125]SPS=3       /      N:C=1000

                                        ;SYNC:          B05J2   (-)     T=2.6 USEC

                                        ;KEY SIG:       K3-3 MOV L  /  K3-3 SM=0 L  /  K3-3 DM=4 L  /  K3-6 BYTE INSTR H
                                                        ;  K5-5 BCON(1+2) H

041472  012700  000535          T0535:  MOV     #0535,R0                ;LOAD R0 WITH TEST NO.
041476  013701  041526                  MOV     @#I0535,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
041502  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
041506  012704  177400                  MOV     #177400,R4      ;RESULT S / B = 177400
041512  012703  177777                  MOV     #-1,R3          ;R3 CONTAINS SOURCE OP
041516  012705  067604          R0535:  MOV     #MBUF0+2,R5     ;BASE DEST ADDR = MBUF0+2
041522  005012                          CLR     (R2)            ;[DEST] = 000000
041524  000257                          CCC                     ;SCOPE SYNC

041526  110345                  I0535:  MOVB    R3,-(R5)        ;TEST THE MOVB

041530  020412                          CMP     R4,(R2)         ;RESULT CORRECT ?
041532  001403                          BEQ     00535           ;BR IF YES

041534  011203                          MOV     (R2),R3         ;GET THE WAS DATA
041536  104000                  E0535:  ERROR                   ;MOVB DELIVERED THE WRONG RESULT
041540  041516                          R0535                   ;ERROR LOOP RETURN ADDRESS

041542  000004                  00535:  SCOPE                   ;CALL THE SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0536 MOVB  SM0,DM6 TEST
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [176,206,212,203,205,125,375,016] FC 1,4,8

                                ;ACT BUTS:      37[004]100,176  /  17[176]212,212  /  21[206]200,203  /  16[125]016,016

                                ;EXEC:          [203]ALUC=LLLLL :[125]D=177777

                                ;CODES:         [125]SPS=3       /      N:C=1000

                                ;SYNC:          B05J2   (-)     T=3 USEC

                                ;KEY SIG:       K3-3 MOV L  /  K3-3 SM=0 L  /  K3-3 DM=6 L  /  K3-6 BYTE INSTR H
                                                ;  K3-4 OVLAP CYCLE L

041544  012700  000536          T0536:  MOV     #0536,R0                ;LOAD R0 WITH TEST NO.
041550  013701  041600                  MOV     @#I0536,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
041554  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
041560  012704  000377                  MOV     #377,R4         ;RESULT S / B = 377
041564  012703  177777                  MOV     #-1,R3          ;R3 CONTAINS SOURCE OP
041570  012705  067604          R0536:  MOV     #MBUF0+2,R5     ;BASE DEST ADDR = MBUF0+2
041574  005012                          CLR     (R2)            ;[DEST] = 000000
041576  000257                          CCC                     ;SCOPE SYNC

041600  110365  177776          I0536:  MOVB    R3,-2(R5)       ;TEST THE MOVB

041604  020412                          CMP     R4,(R2)         ;RESULT CORRECT ?
041606  001403                          BEQ     00536           ;BR IF YES

041610  011203                          MOV     (R2),R3         ;GET THE WAS DATA
041612  104000                  E0536:  ERROR                   ;MOVB DELIVERED THE WRONG RESULT
041614  041570                          R0536                   ;ERROR LOOP RETURN ADDRESS

041616  000004                  00536:  SCOPE                   ;CALL THE SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0537 BIS TEST - SM0,DM0 - <N:C> = 0111
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [102,364,360,001] FC 1,7,8

                                ;ACT BUTS:      37[004]100,102 / 31[102]360,360 / 27[364]000,001

                                ;EXEC:          [364]ALUC=LLLLH :[360] D = 177777

                                ;CODES:         [360] SPS=3  /  N:C = 1001

                                ;SYNC:          B0SJ2 (-) T = 1 USEC

                                ;KEY SIG:       K3-4 OVLAP INSTR H  /  K3-3 BIS L  /  K3-3 SM=0L  /  K3-3 DM=0L

041620  012700  000537          T0537:  MOV     #0537,R0                ;LOAD R0 WITH TEST NO.
041624  013701  041654                  MOV     @#I0537,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
041630  012702  177703                  MOV     #177703,R2      ;DEST ADDR = 177703
041634  012704  177777                  MOV     #-1,R4          ;RESULT S / B = 177777
041640  012705  125252                  MOV     #125252,R5      ;SRC OPR = 125252
041644  012703  052525          R0537:  MOV     #52525,R3       ;[DEST] = 52525
041650  000257                          CCC                     ;CLEAR FLAGS
041652  000267                          267                     ;N:C = 0111

041654  050503                  I0537:  BIS     R5,R3           ;TEST THE BIS

041656  100003                          BPL     E10537          ;N:C = 1001 ?
041660  001402                          BEQ     E10537
041662  102401                          BVS     E10537
041664  103402                          BCS     A0537

041666  104005                  E10537: ERROR5                  ;BIS FAILED TO ALTER CODES PROPERLY
041670  041644                          R0537                   ;ERROR LOOP RETURN ADDRESS

041672  020403                  A0537:  CMP     R4,R3           ;CORRECT RESULT ?
041674  001402                          BEQ     00537           ;BR IF YES

041676  104000                  E20537: ERROR                   ;BIS DELIVERED THE WRONG RESULT
041700  041644                          R0537                   ;ERROR LOOP RETURN ADDRESS

041702  000004                  00537:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ****************************************************************
                                        .SBTTL T0540 BIS TEST - SM0,DM0 - <N:C> = 1000
                                ; ****************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [102,364,360,001] FC 1,7,8

                                ;ACT BUTS:      37[004]100,102 / 31[102]360,360 / 27[364]000,001

                                ;EXEC:          [364]ALUC=LLLLH :[360] D = 000000

                                ;CODES:         [360] SPS=3  /  N:C = 0100

                                ;SYNC:          B05J2 (-) T = 1 USEC

                                ;KEY SIG:       K3-4 OVLAP INSTR H  /  K3-3 BIS L  /  K3-3 SM=0L  /  K3-3 DM=0L

041704  012700  000540          T0540:  MOV     #0540,R0                ;LOAD R0 WITH TEST NO.
041710  013701  041732                  MOV     @#I0540,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
041714  012702  177703                  MOV     #177703,R2      ;DEST ADDR = 177703
041720  005004                          CLR     R4              ;RESULT S / B = 000000
041722  005005                          CLR     R5              ;SRC OPR = 000000
041724  005003                  R0540:  CLR     R3              ;[DEST] = 000000
041726  000257                          CCC                     ;CLEAR FLAGS
041730  000270                          SEN                     ;N:C = 1000

041732  050503                  I0540:  BIS     R5,R3           ;TEST THE BIS

041734  100403                          BMI     E10540          ;N:C = 0100
041736  001002                          BNE     E10540
041740  102401                          BVS     E10540
041742  103002                          BCC     A0540

041744  104005                  E10540: ERROR5                  ;BIS FAILED TO ALTER CODES PROPERLY
041746  041724                          R0540                   ;ERROR LOOP RETURN ADDRESS

041750  020403                  A0540:  CMP     R4,R3           ;CORRECT RESULT ?
041752  001402                          BEQ     00540           ;BR IF YES

041754  104000                  E20540: ERROR                   ;BIS DELIVERED THE WRONG RESULT
041756  041724                          R0540                   ;ERROR LOOP RETURN ADDRESS

041760  000004                  00540:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ****************************************************************
                                        .SBTTL T0541 BIC TEST - SMO,DMO - <N:C> = 0111
                                ; ****************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [102,364,360,001] FC 1,7,8

                                ;ACT BUTS:      37[004]100,102 / 31[102]360,360 / 27[364]000,001

                                ;EXEC:          [364]ALUC=HLLHL :[360] D = 100000

                                ;CODES:         [360] SPS=3  /  N:C = 1001

                                ;SYNC:          B05J2 (-) T = 1 USEC

                                ;KEY SIG:       K3-4 OVLAP INSTR H  /  K3-3 BIC L  /  K3-3 SM=0L  /  K3-3 DM=0L

041762  012700  000541          T0541:  MOV     #0541,R0                ;LOAD R0 WITH TEST NO.
041766  013701  042016                  MOV     @#I0541,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
041772  012702  177703                  MOV     #177703,R2      ;DEST ADDR = 177703
041776  012704  100000                  MOV     #100000,R4      ;RESULT S / B = 100000
042002  012705  077777                  MOV     #77777,R5       ;SRC OPR = 77777
042006  012703  177777          R0541:  MOV     #-1,R3          ;[DEST] = 177777
042012  000257                          CCC                     ;CLEAR FLAGS
042014  000267                          267                     ;N:C = 0111

042016  040503                  I0541:  BIC     R5,R3           ;TEST THE BIC

042020  100003                          BPL     E10541          ;N:C = 1001 ?
042022  001402                          BEQ     E10541
042024  102401                          BVS     E10541
042026  103402                          BCS     A0541

042030  104005                  E10541: ERROR5                  ;BIC FAILED TO ALTER CODES PROPERLY
042032  042006                          R0541                   ;ERROR LOOP RETURN ADDRESS

042034  020403                  A0541:  CMP     R4,R3           ;CORRECT RESULT ?
042036  001402                          BEQ     00541           ;BR IF YES

042040  104000                  E20541: ERROR                   ;BIC DELIVERED THE WRONG RESULT
042042  042006                          R0541                   ;ERROR LOOP RETURN ADDRESS

042044  000004                  00541:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ****************************************************************
                                        .SBTTL T0542 BIC TEST - SM0,DM0 - (N:C) = 1000
                                ; ****************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [102,364,360,001] FC 1,7,8

                                ;ACT BUTS:      37[004]100,102 / 31[102]360,360 / 27[364]000,001

                                ;EXEC:          [364]ALUC=HLLHL :[360] D = 000000

                                ;CODES:         [360] SPS=3  /  N:C = 0100

                                ;SYNC:          B05J2 (-) T = 1 USEC

                                ;KEY SIG:       K3-4 OVLAP INSTR H  /  K3-3 BIC L  /  K3-3 SM=0L  /  K3-3 DM=0L

042046  012700  000542          T0542:  MOV     #0542,R0                ;LOAD R0 WITH TEST NO.
042052  013701  042074                  MOV     @#I0542,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
042056  012702  177703                  MOV     #177703,R2      ;DEST ADDR = 177703
042062  005004                          CLR     R4              ;RESULT S / B = 000000
042064  005005                          CLR     R5              ;SRC OPR = 000000
042066  005003                  R0542:  CLR     R3              ;[DEST] = 000000
042070  000257                          CCC                     ;CLEAR FLAGS
042072  000270                          SEN                     ;N:C = 1000

042074  040503                  I0542:  BIC     R5,R3           ;TEST THE BIC

042076  100403                          BMI     E10542          ;N:C = 0100
042100  001002                          BNE     E10542
042102  102401                          BVS     E10542
042104  103002                          BCC     A0542

042106  104005                  E10542: ERROR5                  ;BIC FAILED TO ALTER CODES PROPERLY
042110  042066                          R0542                   ;ERROR LOOP RETURN ADDRESS

042112  020403                  A0542:  CMP     R4,R3           ;CORRECT RESULT ?
042114  001402                          BEQ     00542           ;BR IF YES

042116  104000                  E20542: ERROR                   ;BIC DELIVERED THE WRONG RESULT
042120  042066                          R0542                   ;ERROR LOOP RETURN ADDRESS

042122  000004                  00542:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0543 BIT TEST - SM0,DM0 - <N:C> = 0111
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [102,364,362,001] FC 1,7,8

                                ;ACT BUTS:      37[004]100,102 / 31[102]360,362 / 27[364]000,001

                                ;EXEC:          [364]ALUC=HHLHH :[362] D = 100000

                                ;CODES:         [362] SPS=3  /  N:C = 1001

                                ;SYNC:          B05J2 (-) T = 1 USEC

                                ;KEY SIG:       K3-4 OVLAP INSTR H  /  K3-3 BIT L  /  K3-3 SM=0L  /  K3-3 DM=0L
                                                ;  K4-4 ALLOW CLK L

042124  012700  000543          T0543:  MOV     #0543,R0                ;LOAD R0 WITH TEST NO.
042130  013701  042160                  MOV     @#I0543,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
042134  012702  177703                  MOV     #177703,R2      ;DEST ADDR = 177703
042140  012704  100000                  MOV     #100000,R4      ;RESULT S / B = 100000
042144  012705  100000                  MOV     #100000,R5      ;SRC OPR = 100000
042150  012703  100000          R0543:  MOV     #100000,R3      ;[DEST] = 100000
042154  000257                          CCC                     ;CLEAR FLAGS
042156  000267                          267                     ;N:C = 0111

042160  030503                  I0543:  BIT     R5,R3           ;TEST THE BIT

042162  100003                          BPL     E10543          ;N:C = 1001
042164  001402                          BEQ     E10543
042166  102401                          BVS     E10543
042170  103402                          BCS     A0543

042172  104005                  E10543: ERROR5                  ;BIT FAILED TO ALTER CODES PROPERLY
042174  042150                          R0543                   ;ERROR LOOP RETURN ADDRESS

042176  020403                  A0543:  CMP     R4,R3           ;CORRECT RESULT ?
042200  001403                          BEQ     00543           ;BR IF YES

042202  011203                          MOV     (R2),R3         ;GET THE WAS DATA
042204  104000                  E20543: ERROR                   ;BIT DELIVERED A RESULT
042206  042150                          R0543                   ;ERROR LOOP RETURN ADDRESS

042210  000004                  00543:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***************************************************************
                                                .SBTTL T0544 BIT TEST - SMO,DMO - <N:C> = 1000
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [102,364,362,001] FC 1,7,8

                                        ;ACT BUTS:      37[004]100,102 / 31[102]360,362 / 27[364]000,001

                                        ;EXEC:          [364]ALUC=HHLHH :[362] D = 000000

                                        ;CODES:         [362] SPS=3  /  N:C = 0100

                                        ;SYNC:          B05J2 (-) T = 1 USEC

                                        ;KEY SIG:       K3-3 BIT L  /  K3-3 SM=OL  /  K3-3 DM=OL  /  K3-4 OVLAP INSTR H
                                                        ;  K4-4 ALLOW CLK L

042212  012700  000544          T0544:  MOV     #0544,R0                ;LOAD R0 WITH TEST NO.
042216  013701  042256                  MOV     @#I0544,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
042222  032737  002000  066642          BIT     #2000,@#BPTLOC  ;BREAKPOINT HALT SET ??
042230  001401                          BEQ     .+4             ;BR IF NOT
042232  000000                          HALT                    ;BREAK-DEPRESS CONTINUE TO RESTART
042234  012702  177703                  MOV     #177703,R2      ;DEST ADDR = 177703
042240  012704  125252                  MOV     #125252,R4      ;RESULT S / B = 125252
042244  012705  052525                  MOV     #52525,R5       ;SRC OPR = 52525
042250  010403                  R0544:  MOV     R4,R3           ;[DEST] = 125252
042252  000257                          CCC                     ;CLEAR FLAGS
042254  000270                          SEN                     ;N:C = 1000

042256  030503                  I0544:  BIT     R5,R3   ;TEST THE BIT

042260  100403                          BMI     E10544          ;N:C = 0100
042262  001002                          BNE     E10544
042264  102401                          BVS     E10544
042266  103002                          BCC     A0544

042270  104005                  E10544: ERROR5                  ;BIT FAILED TO ALTER CODES PROPERLY
042272  042250                          R0544                   ;ERROR LOOP RETURN ADDRESS

042274  020403                  A0544:  CMP     R4,R3           ;CORRECT RESULT ?
042276  001402                          BEQ     00544           ;BR IF YES

042300  104000                  E20544: ERROR                   ;BIT DELIVERED A RESULT
042302  042250                          R0544                   ;ERROR LOOP RETURN ADDRESS

042304  000004                  00544:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***************************************************************
                                                .SBTTL TO545 CMP TEST - SMO,DMO - (N:C) = 0110
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [102,364,362,001]FC 1,7,8

                                        ;ACT BUTS:      37[004]100,102 / 31[102]360,362 / 27[364]000,001

                                        ;EXEC:          [364]ALUC=LLHHL :[362] D = 177777

                                        ;CODES:         [362] SPS=3  /  N:C = 1001

                                        ;SYNC:          BOSJ2 (-) T = 1 USEC

                                        ;KEY SIG:       K3-8 CINOO L  /  K3-3 CMP L  /  K3-3 SM=OL  /  K3-3 DM=OL
                                                        ;  K3-4 OVLAP INSTR H  /  K4-4 ALLOW CLK L

042306  012700  000545          TO545:  MOV     #O545,R0                ;LOAD R0 WITH TEST NO.
042312  013701  042340                  MOV     @#IO545,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
042316  012702  177703                  MOV     #177703,R2      ;DEST ADDR = R3
042322  012704  000001                  MOV     #+1,R4          ;RESULT S / B = +1
042326  005005                          CLR     R5              ;SRC OPR = 000000
042330  012703  000001          RO545:  MOV     #+1,R3          ;[DESTO546
042334  000257                          CCC                     ;CLEAR FLAGS
042336  000266                          266                     ;N:C = 0110

042340  020503                  IO545:  CMP     R5,R3           ;TEST THE CMP

042342  100003                          BPL     E1O545          ;N:C = 1001
042344  001402                          BEQ     E1O545
042346  102401                          BVS     E1O545
042350  103402                          BCS     AO545

042352  104005                  E1O545: ERRORS                  ;CMP FAILED TO ALTER CODES PROPERLY
042354  042330                          RO545                   ;ERROR LOOP RETURN ADDRESS

042356  020403                  AO545:  CMP     R4,R3           ;CORRECT RESULT ?
042360  001402                          BEQ     OO545           ;BR IF YES

042362  104000                  E2O545: ERROR                   ;CMP DELIVERED A RESULT
042364  042330                          RO545                   ;ERROR LOOP RETURN ADDRESS

042366  000C04                  OO545:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***************************************************************
                                                .SBTTL T0546 CMP TEST - SM0,DM0 - <N:C> = 1010
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [102,364,362,001] FC 1,7,8

                                        ;ACT BUTS:      37[004]100,102 / 31[102]360,362 / 27[364]000,001

                                        ;EXEC:          [364]ALUC=LLHHL :[362] D = 000000

                                        ;CODES:         [362] SPS=3  /  N:C = 0100

                                        ;SYNC:          BOSJ2 (-) T = 1 USEC

                                        ;KEY SIG:       K3-8 CINOO L  /  K3-3 CMP L  /  K3-3 SM=OL  /  K3-3 DM=OL
                                                        ;  K3-4 OVLAP INSTR H  /  K4-4 ALLOW CLK L

042370  012700  000546          T0546:  MOV     #0546,R0                ;LOAD R0 WITH TEST NO.
042374  013701  042422                  MOV     @#I0546,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
042400  012702  177703                  MOV     #177703,R2      ;DEST ADDR = R3
042404  012704  177777                  MOV     #-1,R4          ;RESULT S / B = 177777
042410  012705  177777                  MOV     #-1,R5          ;SRC OPR = 177777
042414  010403                  R0546:  MOV     R4,R3           ;[DEST] = 177777
042416  000257                          CCC                     ;CLEAR FLAGS
042420  000272                          272                     ;N:C = 1010

042422  020503                  I0546:  CMP     R5,R3           ;TEST THE CMP

042424  100403                          BMI     E10546          ;N:C = 0100
042426  001002                          BNE     E10546
042430  102401                          BVS     E10546
042432  103002                          BCC     A0546

042434  104005                  E10546: ERROR5                  ;CMP FAILED TO ALTER CODES PROPERLY
042436  042414                          R0546                   ;ERROR LOOP RETURN ADDRESS

042440  020403                  A0546:  CMP     R4,R3           ;CORRECT RESULT ?
042442  001402                          BEQ     00546           ;BR IF YES

042444  104000                  E20546: ERROR                   ;CMP DELIVERED A RESULT
042446  042414                          R0546                   ;ERROR LOOP RETURN ADDRESS

042450  000004                  00546:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0547 CMP TEST - SM0,DM0 - (N:C) = 0000
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [102,364,362,001] FC 1,7,8

                                ;ACT BUTS:      37[004]100,102 / 31[102]360,362 / 27[364]000,001

                                ;EXEC:          [364]ALUC=LLHHL :[362] D = 077777

                                ;CODES:         [362] SPS=3  /  N:C = 0010

                                ;SYNC:          B05J2 (-) T = 1 USEC

                                ;KEY SIG:       K3-8 CINDO L  /  K3-3 CMP L  /  K3-3 SM=0L  /  K3-3 DM=0L
                                                ;  K3-4 OVLAP INSTR H  /  K34-4 ALLOW CLK L

042452  012700  000547          T0547:  MOV     #0547,R0                ;LOAD R0 WITH TEST NO.
042456  013701  042504                  MOV     @#I0547,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
042462  012702  177703                  MOV     #177703,R2      ;DEST ADDR = R3
042466  012704  000001                  MOV     #+1,R4          ;RESULT S / B = +1
042472  012705  100000                  MOV     #100000,R5                      ;SRC OPR = 100000
042476  012703  000001          R0547:  MOV     #+1,R3          ;[DEST0550
042502  000257                          CCC                     ;CLEAR FLAGS

042504  020503                  I0547:  CMP     R5,R3           ;TEST THE CMP

042506  100403                          BMI     E10547          ;N:C = 0010
042510  001402                          BEQ     E10547
042512  102001                          BVC     E10547
042514  103002                          BCC     A0547

042516  104005                  E10547: ERROR5                  ;CMP FAILED TO ALTER CODES PROPERLY
042520  042476                          R0547                   ;ERROR LOOP RETURN ADDRESS

042522  020403                  A0547:  CMP     R4,R3           ;CORRECT RESULT ?
042524  001402                          BEQ     00547           ;BR IF YES

042526  104000                  E20547: ERROR                   ;CMP DELIVERED A RESULT
042530  042476                          R0547                   ;ERROR LOOP RETURN ADDRESS

042532  000004                  00547:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0550 BIS TEST - SM0,DM1 - (N:C) = 0111
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [161,266,267,224,367,375,016] FC 1,3,7,8

                                ;ACT BUTS:      37[004]100,161 / 33[266]220,224 / 16[367]016,016

                                ;EXEC:          [224]ALUC=LLLLH :[367] D = 177777

                                ;CODES:         [367] SPS=3  /  N:C = 1001

                                ;SYNC:          B05J2 (-) T = 2.8 USEC

                                ;KEY SIG:       K3-3 BIS L  /  K3-3 SM=0L  /  K3-3 DM=1L

042534  012700  000550          T0550:  MOV     #0550,R0                ;LOAD R0 WITH TEST NO.
042540  013701  042570                  MOV     @#I0550,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
042544  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
042550  012704  177777                  MOV     #-1,R4          ;RESULT S / B = 177777
042554  012705  125252                  MOV     #125252,R5      ;SRC OPR = 125252
042560  012712  052525          R0550:  MOV     #52525,(R2)     ;[DEST] = 52525
042564  000257                          CCC                     ;CLEAR FLAGS
042566  000267                          267                     ;N:C = 0111

042570  050512                  I0550:  BIS     R5,(R2)         ;TEST THE BIS

042572  100003                          BPL     E10550          ;N:C = 1001
042574  001402                          BEQ     E10550
042576  102401                          BVS     E10550
042600  103402                          BCS     A0550

042602  104005                  E10550: ERROR5                  ;BIS FAILED TO ALTER CODES PROPERLY
042604  042560                          R0550                   ;ERROR LOOP RETURN ADDRESS

042606  020412                  A0550:  CMP     R4,(R2)         ;CORRECT RESULT ?
042610  001403                          BEQ     00550           ;BR IF YES

042612  011203                          MOV     (R2),R3         ;GET THE WAS DATA
042614  104000                  E20550: ERROR                   ;BIS DELIVERED THE WRONG RESULT
042616  042560                          R0550                   ;ERROR LOOP RETURN ADDRESS

042620  000004                  00550:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***********************************************************************
                                        .SBTTL T0551 BIS TEST - SM0,DM1 - (N:C) = 1000
                                ; ***********************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [161,266,267,224,367,375,016] FC 1,3,7,8

                                ;ACT BUTS:      37[004]100,161 / 33[266]220,224 / 16[367]016,016

                                ;EXEC:          [224]ALUC=LLLLH :[367] D = 000000

                                ;CODES:         [367] SPS=3  /  N:C = 0100

                                ;SYNC:          B05J2 (-) T = 2.8 USEC

                                ;KEY SIG:       K3-3 BIS L  /  K3-3 SM=0L  /  K3-3 DM=1L

042622  012700  000551          T0551:  MOV     #0551,R0                ;LOAD R0 WITH TEST NO.
042626  013701  042650                  MOV     @#I0551,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
042632  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
042636  005004                          CLR     R4              ;RESULT S / B = 000000
042640  005005                          CLR     R5              ;SRC OPR = 000000
042642  005012                  R0551:  CLR     (R2)            ;[DEST] = 000000
042644  000257                          CCC                     ;CLEAR FLAGS
042646  000270                          SEN                     ;N:C = 1000

042650  050512                  I0551:  BIS     R5,(R2)         ;TEST THE BIS

042652  100403                          BMI     E10551          ;N:C = 0100
042654  001002                          BNE     E10551
042656  102401                          BVS     E10551
042660  103002                          BCC     A0551

042662  104005                  E10551: ERROR5                  ;BIS FAILED TO ALTER CODES PROPERLY
042664  042642                          R0551                   ;ERROR LOOP RETURN ADDRESS

042666  020412                  A0551:  CMP     R4,(R2)         ;CORRECT RESULT ?
042670  001403                          BEQ     00551           ;BR IF YES

042672  011203                          MOV     (R2),R3         ;GET THE WAS DATA
042674  104000                  E20551: ERROR                   ;BIS DELIVERED THE WRONG RESULT
042676  042642                          R0551                   ;ERROR LOOP RETURN ADDRESS

042700  000004                  00551:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0552 BIC TEST - SM0,DM1 - <N:C> = 0111
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [161,266,267,224,367,375,016] FC 1,3,7,8

                                ;ACT BUTS:      37[004]100,161 / 33[266]220,224 / 16[367]016,016

                                ;EXEC:          [224]ALUC=HLLHL :[367] D = 100000

                                ;CODES:         [367] SPS=3  /  N:C = 1001

                                ;SYNC:          B05J2 (-) T = 2.7 USEC

                                ;KEY SIG:       K3-3 BIC L  /  K3-3 SM=0L  /  K3-3 DM=1L

042702  012700  000552          T0552:  MOV     #0552,R0                ;LOAD R0 WITH TEST NO.
042706  013701  042736                  MOV     @#I0552,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
042712  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
042716  012704  100000                  MOV     #100000,R4      ;RESULT S / B = 100000
042722  012705  077777                  MOV     #77777,R5               ;SRC OPR = 77777
042726  012712  177777          R0552:  MOV     #-1,(R2)        ;[DEST] = 177777
042732  000257                          CCC                     ;CLEAR FLAGS
042734  000267                          267                     ;N:C = 0111

042736  040512                  I0552:  BIC     R5,(R2)         ;TEST THE BIC

042740  100003                          BPL     E10552          ;N:C = 1001
042742  001402                          BEQ     E10552
042744  102401                          BVS     E10552
042746  103402                          BCS     A0552

042750  104005                  E10552: ERROR5                  ;BIC FAILED TO ALTER CODES PROPERLY
042752  042726                          R0552                   ;ERROR LOOP RETURN ADDRESS

042754  020412                  A0552:  CMP     R4,(R2)         ;CORRECT RESULT ?
042756  001403                          BEQ     00552           ;BR IF YES

042760  011203                          MOV     (R2),R3         ;GET THE WAS DATA
042762  104000                  E20552: ERROR                   ;BIC DELIVERED THE WRONG RESULT
042764  042726                          R0552                   ;ERROR LOOP RETURN ADDRESS

042766  000004                  00552:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0553 BIC TEST - SM0,DM1 - <N:C> = 1000
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [161,266,267,224,367,375,016] FC 1,3,7,8

                                ;ACT BUTS:      37[004]100,161 / 33[266]220,224 / 16[367]016,016

                                ;EXEC:          [224]ALUC=HLLHL :[367] D = 000000

                                ;CODES:         [367] SPS=3  /  N:C = 0100

                                ;SYNC:          B05J2 (-) T = 2.7 USEC

                                ;KEY SIG:       K3-3 BIC L  /  K3-3 SM=0L  /  K3-3 DM=1L

042770  012700  000553          T0553:  MOV     #0553,R0                ;LOAD R0 WITH TEST NO.
042774  013701  043016                  MOV     @#I0553,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
043000  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
043004  005004                          CLR     R4              ;RESULT S / B = 000000
043006  005005                          CLR     R5              ;SRC OPR = 000000
043010  005012          R0553:  CLR     (R2)            ;[DEST] = 000000
043012  000257                          CCC                     ;CLEAR FLAGS
043014  000270                          SEN                     ;N:C = 1000

043016  040512          I0553:  BIC     R5,(R2)         ;TEST THE BIC

043020  100403                          BMI     E10553          ;N:C = 0100
043022  001002                          BNE     E10553
043024  102401                          BVS     E10553
043026  103002                          BCC     A0553

043030  104005          E10553: ERROR5                  ;BIC FAILED TO ALTER CODES PROPERLY
043032  043010                          R0553           ;ERROR LOOP RETURN ADDRESS

043034  020412          A0553:  CMP     R4,(R2)         ;CORRECT RESULT ?
043036  001403                          BEQ     00553           ;BR IF YES

043040  011203                          MOV     (R2),R3         ;GET THE WAS DATA
043042  104000          E20553: ERROR                   ;BIC DELIVERED THE WRONG RESULT
043044  043010                          R0553           ;ERROR LOOP RETURN ADDRESS

043046  000004          00553:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0554 BIC TEST - SM0,DM1 - <N:C> = 0111
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [161,266,267,224,367,375,016] FC 1,3,7,8

                                ;ACT BUTS:      37[004]100,161 / 33[266]220,224 / 16[367]016,016

                                ;EXEC:          [224]ALUC=HHLHH :[367] D = 100000

                                ;CODES:         [367] SPS=3  /  N:C = 1001

                                ;SYNC:          B05J2 (-) T = 2.7 USEC

                                ;KEY SIG:       K3-3 BIT L  /  K3-3 SM=0L  /  K3-3 DM=0L  /  K4-4 ALLOW CLK L

043050  012700  000554          T0554:  MOV     #U554,R0                ;LOAD R0 WITH TEST NO.
043054  013701  043104                  MOV     @#I0554,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
043060  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
043064  012704  100000                  MOV     #100000,R4      ;RESULT S / B = 100000
043070  012705  100000                  MOV     #100000,R5      ;SRC OPR = 100000
043074  012712  100000          R0554:  MOV     #100000,(R2)    ;[DEST] = 100000
043100  000257                          CCC                     ;CLEAR FLAGS
043102  000267                          267                     ;N:C = 0111

043104  030512                  I0554:  BIT     R5,(R2)         ;TEST THE BIT

043106  100003                          BPL     E10554          ;N:C = 1001
043110  001402                          BEQ     E10554
043112  102401                          BVS     E10554
043114  103402                          BCS     A0554

043116  104005                  E10554: ERROR5                  ;BIT FAILED TO ALTER CODES PROPERLY
043120  043074                          R0554                   ;ERROR LOOP RETURN ADDRESS

043122  020412                  A0554:  CMP     R4,(R2)         ;CORRECT RESULT ?
043124  001403                          BEQ     00554           ;BR IF YES

043126  011203                          MOV     (R2),R3         ;GET THE WAS DATA
043130  104000                  E20554: ERROR                   ;BIT DELIVERED A RESULT
043132  043074                          R0554                   ;ERROR LOOP RETURN ADDRESS

043134  000004                  00554:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***********************************************************************
                                        .SBTTL TO555 BIT TEST - SM0,DM1 - <N:C> = 1000
                                ; ***********************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [161,266,267,224,367,375,016] FC 1,3,7,8

                                ;ACT BUTS:      37[004]100,161 / 33[266]220,224 / 16[367]016,016

                                ;EXEC:          [224]ALUC=H#LHH :[367] D = 000000

                                ;CODES:         [367] SPS=3  /  N:C = 0100

                                ;SYNC:          B05J2 (-) T = 2.7 USEC

                                ;KEY SIG:       K3-3 BIT L  /  K3-3 SM=0L  /  K3-3 DM=1L  /  K4-4 ALLOW CLK L

043136  012700  000555          TO555:  MOV     #0555,R0                ;LOAD R0 WITH TEST NO.
043142  013701  043172                  MOV     @#IO555,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
043146  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
043152  012704  052525                  MOV     #52525,R4       ;RESULT S / B = 52525
043156  012705  125252                  MOV     #125252,R5      ;SRC OPR = 125252
043162  012712  052525          RO555:  MOV     #52525,(R2)     ;(DEST) = 52525
043166  000257                          CCC                     ;CLEAR FLAGS
043170  000270                          SEN                     ;N:C = 1000

043172  030512                  IO555:  BIT     R5,(R2)         ;TEST THE BIT

043174  100403                          BMI     E10555          ;N:C = 0100
043176  001002                          BNE     E10555
043200  102401                          BVS     E10555
043202  103002                          BCC     A0555

043204  104005                  E10555: ERROR5                  ;BIT FAILED TO ALTER CODES PROPERLY
043206  043162                          RO555                   ;ERROR LOOP RETURN ADDRESS

043210  020412                  A0555:  CMP     R4,(R2)         ;CORRECT RESULT ?
043212  001403                          BEQ     00555           ;BR IF YES

043214  011203                          MOV     (R2),R3         ;GET THE WAS DATA
043216  104000                  E20555: ERROR                   ;BIT DELIVERED A RESULT
043220  043162                          RO555                   ;ERROR LOOP RETURN ADDRESS
043222  000004                  00555:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0556 CMP TEST - SM0,DM1 - <N:C> = 1010
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [161,266,267,224,367,375,016] FC 1,3,8

                                ;ACT BUTS:      37[004]100,161 / 33[266]220,224 / 16[367]016,016

                                ;EXEC:          [224]ALUC=LLHHL :[367] D = 000000

                                ;CODES:         [367] SPS=3  /  N:C = 0100

                                ;SYNC:          B05J2 (-) T = 2.7 USEC

                                ;KEY SIG:       K3-8 CINOD L  /  K3-3 CMP L  /  K3-3 SM=0L  /  K3-3 DM=1L
                                                ;  K4-4 ALLOW CLK L

043224  012700  000556          T0556:  MOV     #0556,R0                ;LOAD R0 WITH TEST NO.
043230  013701  043260                  MOV     @#I0556,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
043234  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
043240  012704  177777                  MOV     #-1,R4          ;RESULT S / B = -1
043244  012705  177777                  MOV     #-1,R5          ;SRC OPR = 177777
043250  012712  177777          R0556:  MOV     #-1,(R2)        ;[DEST] = 177777
043254  000257                          CCC                     ;CLEAR FLAGS
043256  000272                          272                     ;N:C = 1010

043260  020512                  I0556:  CMP     R5,(R2)         ;TEST THE CMP

043262  100403                          BMI     E10556          ;N:C = 0100
043264  001002                          BNE     E10556
043266  102401                          BVS     E10556
043270  103002                          BCC     A0556

043272  104005                  E10556: ERROR5                  ;CMP FAILED TO ALTER CODES PROPERLY
043274  043250                          R0556                   ;ERROR LOOP RETURN ADDRESS

043276  020412                  A0556:  CMP     R4,(R2)         ;CORRECT RESULT ?
043300  001403                          BEQ     00556           ;BR IF YES

043302  011203                          MOV     (R2),R3         ;GET THE WAS DATA
043304  104000                  E20556: ERROR                   ;CMP DELIVERED A RESULT
043306  043250                          R0556                   ;ERROR LOOP RETURN ADDRESS

043310  000004                  00556:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0557 CMP TEST - SM0,DM1 - (N:C) = 0110
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [161,266,267,224,367,375,016] FC 1,3,8

                                ;ACT BUTS:      37[004]100,161 / 33[266]220,224 / 16[367]016,016

                                ;EXEC:          [224]ALUC=LLHHL :[367] D = 177777

                                ;CODES:         [367] SPS=3  /  N:C = 1001

                                ;SYNC:          B05J2 (-) T = 2.7 USEC

                                ;KEY SIG:       K3-8 CINOO L  /  K3- CMP L  /  K3-3 SM=0L  /  K3-3 DM=1L
                                                ;  K4-4 ALLOW CLK L

043312  012700  000557          T0557:  MOV     #0557,R0                ;LOAD R0 WITH TEST NO.
043316  013701  043344                  MOV     @#I0557,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
043322  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
043326  012704  000001                  MOV     #+1,R4          ;RESULT S / B = +1
043332  005005                          CLR     R5              ;SRC OPR = 000000
043334  012712  000001          R0557:  MOV     #+1,(R2)        ;[DEST0560
043340  000257                          CCC                     ;CLEAR FLAGS
043342  000266                          266                     ;N:C = 0110

043344  020512                  I0557:  CMP     R5,(R2)         ;TEST THE CMP

043346  100003                          BPL     E10557          ;N:C = 1001
043350  001402                          BEQ     E10557
043352  102401                          BVS     E10557
043354  103402                          BCS     A0557

043356  104005                  E10557: ERROR5                  ;CMP FAILED TO ALTER CODES PROPERLY
043360  043334                          R0557                   ;ERROR LOOP RETURN ADDRESS

043362  020412                  A0557:  CMP     R4,(R2)         ;CORRECT RESULT ?
043364  001403                          BEQ     00557           ;BR IF YES

043366  011203                          MOV     (R2),R3         ;GET THE WAS DATA
043370  104000                  E20557: ERROR                   ;CMP DELIVERED A RESULT
043372  043334                          R0557                   ;ERROR LOOP RETURN ADDRESS

043374  000004                  00557:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0560 CMP TEST - SM0,DM1 - <N:C> = 0000
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [161,266,267,224,367,375,016] FC 1,3,8

                                ;ACT BUTS:      37[004]100,161 / 33[266]220,224 / 16[367]016,016

                                ;EXEC:          [224]ALUC=LLHHL :[367] D = 077777

                                ;CODES:         [367] SPS=3  /  N:C = 0010

                                ;SYNC:          B05J2 (-) T = 2.7 USEC

                                ;KEY SIG:       K3-8 CIN00 L  /  K3-3 CMP L  /  K3-3 SM=0L  /  K3-3 DM=1L
                                                ;  K4-4 ALLOW CLK L

043376  012700  000560          T0560:  MOV     #0560,R0                ;LOAD R0 WITH TEST NO.
043402  013701  043430                  MOV     @#I0560,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
043406  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
043412  012704  000001                  MOV     #+1,R4          ;RESULT S / B = +1
043416  012705  100000                  MOV     #100000,R5      ;SRC OPR = 100000
043422  012712  000001          R0560:  MOV     #+1,(R2)        ;[DEST0561
043426  000257                          CCC                     ;CLEAR FLAGS

043430  020512                  I0560:  CMP     R5,(R2)         ;TEST THE CMP

043432  100403                          BMI     E10560          ;N:C = 0010
043434  001402                          BEQ     E10560
043436  102001                          BVC     E10560
043440  103002                          BCC     A0560

043442  104005                  E10560: ERROR5                  ;CMP FAILED TO ALTER CODES PROPERLY
043444  043422                          R0560                   ;ERROR LOOP RETURN ADDRESS

043446  020412                  A0560:  CMP     R4,(R2)         ;CORRECT RESULT ?
043450  001403                          BEQ     00560           ;BR IF YES

043452  011203                          MOV     (R2),R3         ;GET THE WAS DATA
043454  104000                  E20560: ERROR                   ;CMP DELIVERED A RESULT
043456  043422                          R0560                   ;ERROR LOOP RETURN ADDRESS

043460  000004                  00560:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***********************************************************************
                                                .SBTTL T0561 BIS TEST - SM1,DM0 - (N:C) = 0111
                                        ; ***********************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [141,247,250,120,371,360,000] FC 1,2,8

                                        ;ACT BUTS:      37[004]100,141 / 35[247]120,120 / 31[120]360,360 / 27[37]000,000

                                        ;EXEC:          [371]ALUC=LLLLH :[360] D = 177777

                                        ;CODES:         [360] SPS=3  /  N:C = 1001

                                        ;SYNC:          B05J2 (-) T = 2.8 USEC

                                        ;KEY SIG:       K3-3 BIS L  /  K3-3 SM=1L  /  K3-3 DM=0L

043462  012700  000561          T0561:  MOV     #0561,R0                ;LOAD R0 WITH TEST NO.
043466  013701  043516                  MOV     @#I0561,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
043472  012702  177703                  MOV     #177703,R2      ;DEST ADDR = 177703
043476  012704  177777                  MOV     #-1,R4          ;RESULT S / B = 177777
043502  012705  067622                  MOV     #DWTA+10,R5     ;SRC ADDR = DWTA+10
043506  012703  052525          R0561:  MOV     #52525,R3       ;[DEST] = 52525
043512  000257                          CCC                     ;CLEAR FLAGS
043514  000267                          267                     ;N:C = 0111

043516  051503                  I0561:  BIS     (R5),R3         ;TEST THE BIS

043520  100003                          BPL     E10561          ;N:C = 1001
043522  001402                          BEQ     E10561
043524  102401                          BVS     E10561
043526  103402                          BCS     A0561

043530  104005                  E10561: ERROR5                  ;BIS FAILED TO ALTER CODES PROPERLY
043532  043506                          R0561                   ;ERROR LOOP RETURN ADDRESS

043534  020403                  A0561:  CMP     R4,R3           ;CORRECT RESULT ?
043536  001402                          BEQ     00561           ;BR IF YES

043540  104000                  E20561: ERROR                   ;BIS DELIVERED THE WRONG RESULT
043542  043506                          R0561                   ;ERROR LOOP RETURN ADDRESS

043544  000004                  00561:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***********************************************************************
                                                .SBTTL T0562 BIS TEST - SM1,DM0 - <N:C> = 1000
                                        ; ***********************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [141,247,250,120,371,360,000] FC 1,2,8

                                        ;ACT BUTS:      37[004]100,141 / 35[247]120,120 / 31[120]360,360 / 27[371]000,000

                                        ;EXEC:          [371]ALUC=LLLLH :[360] D = 000000

                                        ;CODES:         [360] SPS=3  /  N:C =0100

                                        ;SYNC:          B05J2 (-) T = 2.8 USEC

                                        ;KEY SIG:       K3-3 BIS L  /  K3-3 SM=1L  /  K3-3 DM=0L

043546  012700  000562                  T0562:  MOV     #0562,R0                ;LOAD R0 WITH TEST NO.
043552  013701  043576                          MOV     @#I0562,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
043556  012702  177703                          MOV     #177703,R2      ;DEST ADDR = 177703
043562  005004                                  CLR     R4              ;RESULT S / B =000000
043564  012705  067612                          MOV     #DWTA,R5        ;SRC ADDR = DWTA
043570  005003                          R0562:  CLR     R3              ;[DEST] = 000000
043572  000257                                  CCC                     ;CLEAR FLAGS
043574  000270                                  SEN                     ;N:C = 1000

043576  051503                          I0562:  BIS     (R5),R3         ;TEST THE BIS

043600  100403                                  BMI     E10562          ;N:C = 0100
043602  001002                                  BNE     E10562
043604  102401                                  BVS     E10562
043606  103002                                  BCC     A0562

043610  104005                          E10562: ERROR5                  ;BIS FAILED TO ALTER CODES PROPERLY
043612  043570                                  R0562                   ;ERROR LOOP RETURN ADDRESS

043614  020403                          A0562:  CMP     R4,R3           ;CORRECT RESULT ?
043616  001402                                  BEQ     00562           ;BR IF YES

043620  104000                          E20562: ERROR                   ;BIS DELIVERED THE WRONG RESULT
043622  043570                                  R0562                   ;ERROR LOOP RETURN ADDRESS

043624  000004                          00562:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0563 BIC TEST - SM1,DM0 - (N:C) = 0111
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [141,247,250,120,371,360,000] FC 1,2,8

                                ;ACT BUTS:      37[004]100,141 / 35[247]120,120 / 31[120]360,360 / 27[371]000,000

                                ;EXEC:          [371]ALUC=HLLHL :[360] D = 100000

                                ;CODES:         [360] SPS=3  /  N:C = 1001

                                ;SYNC:          B05J2 (-) T = 2.5 USEC

                                ;KEY SIG:       K3-3 BIC L  /  K3-3 SM=1L  /  K3-3 DM=0L

043626  012700  000563          T0563:  MOV     #0563,R0                ;LOAD R0 WITH TEST NO.
043632  013701  043666                  MOV     @#I0563,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
043636  012702  177703                  MOV     #177703,R2      ;DEST ADDR = 177703
043642  012704  100000                  MOV     #100000,R4      ;RESULT S / B = 100000
043646  012705  067606                  MOV     #MBUF1,R5       ;SRC ADDR = MBUF1
043652  012703  177777          R0563:  MOV     #-1,R3  ;[DEST] = 177777
043656  012715  077777                  MOV     #77777,(R5)     ;SRC OPR = 77777
043662  000257                          CCC                     ;CLEAR FLAGS
043664  000267                          267                     ;N:C = 0111

043666  041503                  I0563:  BIC     (R5),R3         ;TEST THE BIC

043670  100003                          BPL     E10563          ;N:C = 1001 ?
043672  001402                          BEQ     E10563
043674  102401                          BVS     E10563
043676  103402                          BCS     A0563

043700  104005                  E10563: ERROR5                  ;BIC FAILED TO ALTER CODES PROPERLY
043702  043652                          R0563                   ;ERROR LOOP RETURN ADDRESS

043704  020403                  A0563:  CMP     R4,R3           ;CORRECT RESULT ?
043706  001402                          BEQ     00563           ;BR IF YES

043710  104000                  E20563: ERROR                   ;BIC DELIVERED THE WRONG RESULT
043712  043652                          R0563                   ;ERROR LOOP RETURN ADDRESS

043714  000004                  00563:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0564 BIC TEST - SM1,DM0 - (N:C) = 1000
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [141,247,250,120,371,360,000] FC 1,2,8

                                ;ACT BUTS:      37[004]100,141 / 35[247]120,120 / 31[120]360,360 / 27[371]000,000

                                ;EXEC:          [371]ALUC=HLLHL :[360] D = 000000

                                ;CODES:         [360] SPS=3  /  N:C = 0100

                                ;SYNC:          B05J2 (-) T = 2.5 USEC

                                ;KEY SIG:       K3-3 BIC L  /  K3-3 SM=1L  /  K3-3 DM=0L

043716  012700  000564          T0564:  MOV     #0564,R0                ;LOAD R0 WITH TEST NO.
043722  013701  043746                  MOV     @#I0564,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
043726  012702  177703                  MOV     #177703,R2      ;DEST ADDR = 177703
043732  005004                          CLR     R4              ;RESULT S / B = 000000
043734  012705  067612                  MOV     #DWTA,R5        ;SRC ADDR = DWTA
043740  005003                  R0564:  CLR     R3              ;[DEST] =000000
043742  000257                          CCC                     ;CLEAR FLAGS
043744  000270                          SEN                     ;N:C = 1000

043746  041503                  I0564:  BIC     (R5),R3         ;TEST THE BIC

043750  100403                          BMI     E10564          ;N:C = 0100
043752  001002                          BNE     E10564
043754  102401                          BVS     E10564
043756  103002                          BCC     A0564

043760  104005                  E10564: ERROR5                  ;BIC FAILED TO ALTER CODES PROPERLY
043762  043740                          R0564                   ;ERROR LOOP RETURN ADDRESS

043764  020403                  A0564:  CMP     R4,R3           ;CORRECT RESULT ?
043766  001402                          BEQ     00564           ;BR IF YES

043770  104000                  E20564: ERROR                   ;BIC DELIVERED THE WRONG RESULT
043772  043740                          R0564                   ;ERROR LOOP RETURN ADDRESS

043774  000004                  00564:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0565 BIC TEST - SM1,DM0 - (N:C) = 0111
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [141,247,250,120,371,362,000] FC 1,2,8

                                ;ACT BUTS:      37[004]100,141 / 35[247]120,120 / 31[120]360,362 / 27[371]000,000

                                ;EXEC:          [371]ALUC=HHLHH :[362] D = 100000

                                ;CODES:         [362] SPS=3  /  N:C = 1001

                                ;SYNC:          B05J2 (-) T = 2.5 USEC

                                ;KEY SIG:       K3-3 BIT L  /  K3-3 SM=1L  /  K3-3 DM=0L  /  K4-4 ALLOW CLK L

043776  012700  000565          T0565:  MOV     #0565,R0                ;LOAD R0 WITH TEST NO.
044002  013701  044030                  MOV     @#I0565,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
044006  012702  177703                  MOV     #177703,R2      ;DEST ADDR = 177703
044012  012704  100000                  MOV     #100000,R4      ;RESULT S / B = 100000
044016  012705  067614                  MOV     #DWTA+2,R5      ;SRC ADDR = DWTA+2
044022  010403                  R0565:  MOV     R4,R3           ;[DEST] = 100000
044024  000257                          CCC                     ;CLEAR FLAGS
044026  000267                          267                     ;N:C = 0111

044030  031503                  I0565:  BIT     (R5),R3         ;TEST THE BIT

044032  100003                          BPL     E10565          ;N:C = 1001 ?
044034  001402                          BEQ     E10565
044036  102401                          BVS     E10565
044040  103402                          BCS     A0565

044042  104005                  E10565: ERROR5                  ;BIT FAILED TO ALTER CODES PROPERLY
044044  044022                          R0565                   ;ERROR LOOP RETURN ADDRESS

044046  020403                  A0565:  CMP     R4,R3           ;CORRECT RESULT ?
044050  001402                          BEQ     O0565           ;BR IF YES

044052  104000                  E20565: ERROR                   ;BIT DELIVERED A RESULT
044054  044022                          R0565                   ;ERROR LOOP RETURN ADDRESS

044056  000004                  O0565:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0566 BIT TEST - SM1,DM0 - (N:C) = 1000
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [141,247,250,120,371,362,000] FC 1,2,8

                                ;ACT BUTS:      37[004]100,141 / 35[247]120,120 / 31[120]360,362 / 27[371]000,000

                                ;EXEC:          [371]ALUC=HHLHH :[362] D = 000000

                                ;CODES:         [362] SPS=3  /  N:C = 0100

                                ;SYNC:          B05J2 (-) T = 2.5 USEC

                                ;KEY SIG:       K3-3 BIT L  /  K3-3 SM=1L  /  K3-3 DM=0L  /  K4-4 ALLOW CLK L

044060  012700  000566          T0566:  MOV     #0566,R0                ;LOAD R0 WITH TEST NO.
044064  013701  044112                  MOV     @#I0566,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
044070  012702  177703                  MOV     #177703,R2      ;DEST ADDR = R3
044074  012704  052525                  MOV     #52525,R4       ;RESULT S / B = 52525
044100  012705  067622                  MOV     #DWTA+10,R5     ;SRC ADDR = DWTA+10
044104  010403                  R0566:  MOV     R4,R3           ;[DEST] = 52525
044106  000257                          CCC                     ;CLEAR FLAGS
044110  000270                          SEN                     ;N:C = 1000

044112  031503                  I0566:  BIT     (R5),R3         ;TEST THE BIT

044114  100403                          BMI     E10566          ;N:C = 0100
044116  001002                          BNE     E10566
044120  102401                          BVS     E10566
044122  103002                          BCC     A0566

044124  104005                  E10566: ERROR5                  ;BIT FAILED TO ALTER CODES PROPERLY
044126  044104                          R0566                   ;ERROR LOOP RETURN ADDRESS

044130  020403                  A0566:  CMP     R4,R3           ;CORRECT RESULT ?
044132  001402                          BEQ     00566           ;BR IF YES

044134  104000                  E20566: ERROR                   ;BIT DELIVERED A RESULT
044136  044104                          R0566                   ;ERROR LOOP RETURN ADDRESS
044140  000004                  00566:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0567 CMP TEST - SM1,DM0 - (N:C) = 0110
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [141,247,250,120,371,362,000] FC 1,2,8

                                ;ACT BUTS:      37[004]100,141 / 35[247]120,120 / 31[120]360,362 / 27[371]000,000

                                ;EXEC:          [371]ALUC=LLHHL :[362] D = 177777

                                ;CODES:         [362] SPS=3  /  N:C = 1001

                                ;SYNC:          B05J2 (-) T = 2.7 USEC

                                ;KEY SIG:       K3-8 CIN00 L  /  K3-3 CMP L  /  K3-3 SM=1L  /  K3-3 DM=0L
                                                ;  K4-4 ALLOW CLK L

044142  012700  000567          T0567:  MOV     #0567,R0                ;LOAD R0 WITH TEST NO.
044146  013701  044174                  MOV     @#I0567,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
044152  012702  177703                  MOV     #177703,R2      ;DEST ADDR = R3
044156  012704  000001                  MOV     #+1,R4          ;RESULT S / B = +1
044162  012705  067612                  MOV     #DWTA,R5        ;SRC ADDR = DWTA
044166  010403                  R0567:  MOV     R4,R3           ;[DEST]0570
044170  000257                          CCC                     ;CLEAR FLAGS
044172  000266                          266                     ;N:C = 0110

044174  021503                  I0567:  CMP     (R5),R3         ;TEST THE CMP

044176  100003                          BPL     E10567          ;N:C = 1001
044200  001402                          BEQ     E10567
044202  102401                          BVS     E10567
044204  103402                          BCS     A0567

044206  104005                  E10567: ERROR5                  ;CMP FAILED TO ALTER CODES PROPERLY
044210  044166                          R0567                   ;ERROR LOOP RETURN ADDRESS

044212  020403                  A0567:  CMP     R4,R3           ;CORRECT RESULT ?
044214  001402                          BEQ     00567           ;BR IF YES

044216  104000                  E20567: ERROR                   ;CMP DELIVERED A RESULT
044220  044166                          R0567                   ;ERROR LOOP RETURN ADDRESS

044222  000004                  00567:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0570 CMP TEST - SM1,DM0 - (N:C) = 1010
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [141,247,250,120,371,362,000] FC 1,2,8

                                ;ACT BUTS:      37[004]100,141 / 35[247]120,120 / 31[120]360,362 / 27[371]000,000

                                ;EXEC:          [371]ALUC=LLHHL :[362] D = 000000

                                ;CODES:         [362] SPS=3  /  N:C = 0100

                                ;SYNC:          B05J2 (-) T = 2.7 USEC

                                ;KEY SIG:       K3-8 CINOD L  /  K3-3 CMP L  /  K3-3 SM=1L  /  K3-3 DM=0L
                                                ;  K4-4 ALLOW CLK L

044224  012700  000570          T0570:  MOV     #0570,R0                ;LOAD R0 WITH TEST NO.
044230  013701  044256                  MOV     @#I0570,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
044234  012702  177703                  MOV     #177703,R2      ;DEST ADDR = R3
044240  012704  177777                  MOV     #-1,R4          ;RESULT S / B = 177777
044244  012705  067614                  MOV     #DWTA+2,R5      ;SRC ADDR = DWTA+2
044250  010403                  R0570:  MOV     R4,R3           ;[DEST] = 177777
044252  000257                          CCC                     ;CLEAR FLAGS
044254  000272                          272                     ;N:C = 1010

044256  021503                  I0570:  CMP     (R5),R3         ;TEST THE CMP

044260  100403                          BMI     E10570          ;N:C = 0100
044262  001002                          BNE     E10570
044264  102401                          BVS     E10570
044266  103002                          BCC     A0570

044270  104005                  E10570: ERROR5                  ;CMP FAILED TO ALTER CODES PROPERLY
044272  044250                          R0570                   ;ERROR LOOP RETURN ADDRESS

044274  020403                  A0570:  CMP     R4,R3           ;CORRECT RESULT ?
044276  001402                          BEQ     00570           ;BR IF YES

044300  104000                  E20570: ERROR                   ;CMP DELIVERED A RESULT
044302  044250                          R0570                   ;ERROR LOOP RETURN ADDRESS

044304  000004                  00570:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0571 CMP TEST - SM1,DM0 - (N:C) = 0000
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [141,247,250,120,371,362,000] FC 1,2,8

                                ;ACT BUTS:      37[004]100,141 / 35[247]120,120 / 31[120]360,362 / 27[371]000,000

                                ;EXEC:          [371]ALUC=LLHHL :[362] D = 077777

                                ;CODES:         [362] SPS=3  /  N:C = 0010

                                ;SYNC:          B05J2 (-) T = 2.7 USEC

                                ;KEY SIG:       K3-8 CINOO L  /  K3-3 CMP L  /  K3-3 SM=1L  /  K3-3 DM=0L
                                                ;  K4-4 ALLOW CLK L

044306  012700  000571          T0571:  MOV     #0571,R0                ;LOAD R0 WITH TEST NO.
044312  013701  044344                  MOV     @#I0571,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
044316  012702  177703                  MOV     #177703,R2      ;DEST ADDR = R3
044322  012704  000001                  MOV     #+1,R4          ;RESULT S / B = +1
044326  012705  067606                  MOV     #MBUF1,R5       ;SRC ADDR = MBUF1
044332  012703  000001          R0571:  MOV     #+1,R3          ;[DEST0572
044336  012715  100000                  MOV     #100000,(R5)    ;SRC OPR = 100000
044342  000257                          CCC                     ;CLEAR FLAGS

044344  021503                  I0571:  CMP     (R5),R3         ;TEST THE CMP

044346  100403                          BMI     E10571          ;N:C = 0010
044350  001402                          BEQ     E10571
044352  102001                          BVC     E10571
044354  103002                          BCC     A0571

044356  104005                  E10571: ERROR5                  ;CMP FAILED TO ALTER CODES PROPERLY
044360  044332                          R0571                   ;ERROR LOOP RETURN ADDRESS

044362  020403                  A0571:  CMP     R4,R3           ;CORRECT RESULT ?
044364  001402                          BEQ     00571           ;BR IF YES

044366  104000                  E20571: ERROR                   ;CMP DELIVERED A RESULT
044370  044332                          R0571                   ;ERROR LOOP RETURN ADDRESS

044372  000004                  00571:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ****************************************************************
                                        .SBTTL T0572 BIS  SM1,DM1 TEST - <N:C> = 0111
                                ; ****************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [141,247,250,161,266,267,225,367,375,016] FC 1,2,3,8

                                ;ACT BUTS:      37[004]100,141  /  35[247]120,161  /  33[266]220,225  /  16[367]016,016

                                ;EXEC:          [225]ALUC=LLLLH :[367]D=177777

                                ;CODES:         [367]SPS=3       /      N:C=1001

                                ;SYNC:          B05J2   (-)     T= 3.4 USEC

                                ;KEY SIG:       K3-3 BIS L  /  K3-3 SM=1 L  /  K3-3 DM=1 L

044374  012700  000572          T0572:  MOV     #0572,R0                ;LOAD R0 WITH TEST NO.
044400  013701  044430                  MOV     @#I0572,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
044404  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
044410  012704  177777                  MOV     #-1,R4          ;RESULT S / B = 1777777
044414  012705  067622                  MOV     #DWTA+10,R5     ;SOURCE ADDR = DWTA+10
044420  012712  052525          R0572:  MOV     #52525,(R2)     ;[DEST] = 052525
044424  000257                          CCC                     ;CLEAR FLAGS
044426  000267                          267                     ;N:C = 0111

044430  051512                  I0572:  BIS     (R5),(R2)       ;TEST THE BIS

044432  100003                          BPL     E10572          ;N:C = 1001?
044434  001402                          BEQ     E10572
044436  102401                          BVS     E10572
044440  103402                          BCS     A0572

044442  104005                  E10572: ERROR5                  ;BIS FAILED TO ALTER CODES PROPERLY
044444  044420                          R0572                   ;ERROR LOOP RETURN ADDRESS

044446  020412                  A0572:  CMP     R4,(R2)         ;CORRECT RESULT ?
044450  001403                          BEQ     00572           ;BR IF YES

044452  011203                          MOV     (R2),R3         ;GET THE WAS DATA
044454  104000                  E20572: ERROR                   ;BIS DELIVERED THE WRONG RESULT
044456  044420                          R0572                   ;ERROR LOOP RETURN ADDRESS

044460  000004                  00572:  SCOPE                   ;CALL THE SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0573 BIS  SM1,DM1 TEST - <N:C> = 1000
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [141,247,250,161,266,267,225,367,375,016] FC 1,2,3,8

                                ;ACT BUTS:      37[004]100,141  /  35[247]120,161  /  33[266]220,225  /  16[367]016,016

                                ;EXEC:          [225]ALUC=LLLLH :[367]D=000000

                                ;CODES:         [367]SPS=3       /      N:C=0100

                                ;SYNC:          B05J2   (-)     T=3.4 USEC

                                ;KEY SIG:       K3-3 BIS L  /  K3-3 SM=1 L  /  K3-3 DM=1 L

044462  012700  000573          T0573:  MOV     #0573,R0                ;LOAD R0 WITH TEST NO.
044466  013701  044516                  MOV     @#I0573,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
044472  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
044476  012704  000000                  MOV     #0,R4           ;RESULT S / B = 000000
044502  012705  067612                  MOV     #DWTA,R5        ;SOURCE ADDR = DWTA
044506  012712  000000          R0573:  MOV     #0,(R2)         ;[DEST] = 000000
044512  000257                          CCC                     ;CLEAR FLAGS
044514  000270                          SEN                     ;N:C = 1000

044516  051512                  I0573:  BIS     (R5),(R2)       ;TEST THE BIS

044520  100403                          BMI     E10573          ;N:C = 0100 ?
044522  001002                          BNE     E10573
044524  102401                          BVS     E10573
044526  103002                          BCC     A0573

044530  104005                  E10573: ERROR5                  ;BIS FAILED TO ALTER CODES PROPERLY
044532  044506                          R0573                   ;ERROR LOOP RETURN ADDRESS

044534  020412                  A0573:  CMP     R4,(R2)         ;CORRECT RESULT ?
044536  001403                          BEQ     00573           ;BR IF YES

044540  011203                          MOV     (R2),R3         ;GET THE WAS DATA
044542  104000                  E20573: ERROR                   ;BIS DELIVERED THE WRONG RESULT
044544  044506                          R0573                   ;ERROR LOOP RETURN ADDRESS

044546  000004                  00573:  SCOPE                   ;CALL THE SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0574 BIC  SM1,DM1 TEST - <N:C> = 0111
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [141,247,250,161,266,267,225,367,375,016] FC 1,2,3,8

                                ;ACT BUTS:      37[004]100,141  /  35[247]120,161  /  33[266]220,225  /  16[367]016,016

                                ;EXEC:          [225]ALUC=HLLHL :[367]D=100000

                                ;CODES:         [367]SPS=3       /      N:C=1001

                                ;SYNC:          B05J2   (-)     T= 3.4 USEC

                                ;KEY SIG:       K3-3 BIC L  /  K3-3 SM=1 L  /  K3-3 DM=1 L

044550  012700  000574          T0574:  MOV     #0574,R0                ;LOAD R0 WITH TEST NO.
044554  013701  044610                  MOV     @#I0574,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
044560  012702  067603                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
044564  012704  100000                  MOV     #100000,R4      ;RESULT S / B = 100000
044570  012705  067606                  MOV     #MBUF1,R5       ;SOURCE ADDR = MBUF1
044574  012715  077777          R0574:  MOV     #77777,(R5)     ;[SOURCE] = 77777
044600  012712  177777                  MOV     #-1,(R2)        ;[DEST] = 177777
044604  000257                          CCC                     ;CLEAR FLAGS
044606  000267                          267                     ;N:C = 0111

044610  041512                  I0574:  BIC     (R5),(R2)       ;TEST THE BIC

044612  100003                          BPL     E10574          ;N:C = 1001 ?
044614  001402                          BEQ     E10574
044616  102401                          BVS     E10574
044620  103402                          BCS     A0574

044622  104005                  E10574: ERROR5                  ;BIC FAILED TO ALTER CODES PROPERLY
044624  044574                          R0574                   ;ERROR LOOP RETURN ADDRESS

044626  020412                  A0574:  CMP     R4,(R2)         ;CORRECT RESULT ?
044630  001403                          BEQ     00574           ;BR IF YES

044632  011203                          MOV     (R2),R3         ;GET THE WAS DATA
044634  104000                  E20574: ERROR                   ;BIC DELIVERED THE WRONG RESULT
044636  044574                          R0574                   ;ERROR LOOP RETURN ADDRESS

044640  000004                  00574:  SCOPE                   ;CALL THE SCOPE LOOP UTILITY
```

```
                                        ; ***************************************************************
                                                .SBTTL T0575 BIC  SM1,DM1 TEST - <N:C> = 1000
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [141,247,250,162,266,267,225,367,375,016] FC 1,2,3,8

                                        ;ACT BUTS:      37[004]100,141  /  35[247]120,161  /  33[266]220,225  /  16[367]016,016

                                        ;EXEC:          [225]ALUC=HLLHL :[367]D=000000

                                        ;CODES:         [367]SPS=3       /      N:C=0100

                                        ;SYNC:          B05J2   (-)     T= 3.4 USEC

                                        ;KEY SIG:       K3-3 BIC L  /  K3-3 SM=1 L  /  K3-3 DM=1 L

044642  012700  000575                  T0575:  MOV     #0575,R0                ;LOAD R0 WITH TEST NO.
044646  013701  044702                          MOV     @#I0575,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
044652  012702  067602                          MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
044656  012704  000000                          MOV     #0,R4           ;RESULT S / B = 000000
044662  012705  067606                          MOV     #MBUF1,R5       ;SOURCE ADDR = MBUF1
044666  012715  000000                  R0575:  MOV     #0,(R5)         ;[SOURCE] = 000000
044672  012712  000000                          MOV     #0,(R2)         ;[DEST] = 000000
044676  000257                                  CCC                     ;CLEAR FLAGS
044700  000270                                  SEN                     ;N:C = 1000

044702  041512                          I0575:  BIC     (R5),(R2)       ;TEST THE BIC

044704  100403                                  BMI     E10575          ;N:C = 0100 ?
044706  001002                                  BNE     E10575
044710  102401                                  BVS     E10575
044712  103002                                  BCC     A0575

044714  104005                          E10575: ERROR5                  ;BIC FAILED TO ALTER CODES PROPERLY
044716  044666                                  R0575                   ;ERROR LOOP RETURN ADDRESS

044720  020412                          A0575:  CMP     R4,(R2)         ;CORRECT RESULT ?
044722  001403                                  BEQ     00575           ;BR IF YES

044724  011203                                  MOV     (R2),R3         ;GET THE WAS DATA
044726  104000                          E20575: ERROR                   ;BIC DELIVERED THE WRONG RESULT
044730  044666                                  R0575                   ;ERROR LOOP RETURN ADDRESS

044732  000004                          00575:  SCOPE                   ;CALL THE SCOPE LOOP UTILITY
```

```
                                        ; ***************************************************************
                                                .SBTTL T0576 BIT  SM1,DM1 TEST - <N:C> = 1000
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [141,247,250,161,266,267,225,367,375,016] FC 1,2,3,8

                                        ;ACT BUTS:      37[004]100,141  /  35[247]120,161  /  33[266]220,225  /  16[367]016,016

                                        ;EXEC:          [225]ALUC=HHLHH :[367]D=000000

                                        ;CODES:         [367]SPS=3       /       N:C=0100

                                        ;SYNC:          B05J2   (-)     T=3.4 USEC

                                        ;KEY SIG:       K3-3 BIT L  /  K3-3 SM=1 L  /  K3-3 DM=1 L  /  K4-4 ALLOW CLK L

044734  012700  000576                  T0576:  MOV     #0576,R0                ;LOAD R0 WITH TEST NO.
044740  013701  044774                          MOV     @#I0576,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
044744  012702  067602                          MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
044750  012704  125252                          MOV     #125252,R4      ;RESULT S / B = 125252
044754  012705  067606                          MOV     #MBUF1,R5       ;SOURCE ADDR = MBUF1
044760  012715  052525                  R0576:  MOV     #52525,(R5)     ;[SOURCE] = 052525
044764  012712  125252                          MOV     #125252,(R2)    ;[DEST] = 125252
044770  000257                                  CCC                     ;CLEAR FLAGS
044772  000270                                  SEN                     ;N:C = 1000

044774  031512                          I0576:  BIT     (R5),(R2)       ;TEST THE BIT

044776  100403                                  BMI     E10576          ;N:C = 0100 ?
045000  001002                                  BNE     E10576
045002  102401                                  BVS     E10576
045004  103002                                  BCC     A0576

045006  104005                          E10576: ERROR5                  ;BIT FAILED TO ALTER CODES PROPERLY
045010  044760                                  R0576                   ;ERROR LOOP RETURN ADDRESS

045012  020412                          A0576:  CMP     R4,(R2)         ;CORRECT RESULT ?
045014  001403                                  BEQ     00576           ;BR IF YES

045016  011203                                  MOV     (R2),R3         ;GET THE WAS DATA
045020  104000                          E20576: ERROR                   ;BIT DELIVERED A RESULT
045022  044760                                  R0576                   ;ERROR LOOP RETURN ADDRESS

045024  000004                          00576:  SCOPE                   ;CALL THE SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL TO577 BIT  SM1,DM1 TEST - <N:C> = 0111
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [141,247,250,161,266,267,225,367,375,016] FC 1,2,3,8

                                ;ACT BUTS:      37[004]100,141  /  35[247]120,161  /  33[266]220,225  /  16[367]016,016

                                ;EXEC:          [225]ALUC=HHLHH :[367]D=100000

                                ;CODES:         [367]SPS=3       /      N:C=1001

                                ;SYNC:          BOSJ2   (-)     T=3.4 USEC

                                ;KEY SIG:       K3-3 BIT L  /  K3-3 SM=1 L  /  K3-3 DM=1 L  /  K4-4 ALLOW CLK L

045026  012700  000577          TO577:  MOV     #0577,R0                ;LOAD R0 WITH TEST NO.
045032  013701  045066                  MOV     @#IO577,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
045036  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
045042  012704  100000                  MOV     #100000,R4      ;RESULT S / B = 100000
045046  012705  067606                  MOV     #MBUF1,R5       ;SOURCE ADDR = MBUF1
045052  012715  100000          RO577:  MOV     #100000,(R5)    ;[SOURCE] = 100000
045056  012712  100000                  MOV     #100000,(R2)    ;[DEST] = 100000
045062  000257                          CCC                     ;CLEAR FLAGS
045064  000267                          267                     ;N:C = 0111

045066  031512                  IO577:  BIT     (R5),(R2)       ;TEST THE BIT

045070  100003                          BPL     EI0577          ;N:C = 1001 ?
045072  001402                          BEQ     EI0577
045074  102401                          BVS     EI0577
045076  103402                          BCS     AO577

045100  104005                  EI0577: ERROR5                  ;BIT FAILED TO ALTER CODES PROPERLY
045102  045052                          RO577                   ;ERROR LOOP RETURN ADDRESS

045104  020412                  AO577:  CMP     R4,(R2)         ;CORRECT RESULT ?
045106  001403                          BEQ     OO577           ;BR IF YES

045110  011203                          MOV     (R2),R3         ;GET THE WAS DATA
045112  104000                  E2O577: ERROR                   ;BIT DELIVERED A RESULT
045114  045052                          RO577                   ;ERROR LOOP RETURN ADDRESS

045116  000004                  OO577:  SCOPE                   ;CALL THE SCOPE LOOP UTILITY
```

```
                                        ; ***************************************************************
                                                .SBTTL T0600 CMP  SM1,DM1 TEST - (N:C) = 1010
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [141,247,250,161,266,267,225,367,375,016] FC 1,2,3,8

                                        ;ACT BUTS:      37[004]100,141  /  35[247]120,161  /  33[266]220,225  /  16[367]016,016

                                        ;EXEC:          [225]ALUC=L.4HL :[367]D=000000

                                        ;CODES:         [367]SPS=3       /      N:C=0100

                                        ;SYNC:          BOSJ2   (-)      T=3.4 USEC

                                        ;KEY SIG:       K3-3 CMP L  /  K3-3 SM=1 L  /  K3-3 DM=1 L  /  K3-8 CINOO L
                                                        ;  K4-4 ALLOW CLK L

045120  012700  000600          T0600:  MOV     #0600,R0                ;LOAD R0 WITH TEST NO.
045124  013701  045156                  MOV     @#I0600,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
045130  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
045134  012704  177777                  MOV     #-1,R4          ;RESULT S / B = 177777
045140  012705  067606                  MOV     #MBUF1,R5               ;SOURCE ADDR =
045144  012715  177777          R0600:  MOV     #-1,(R5)        ;[SOURCE] = 177777
045150  010412                          MOV     R4,(R2)         ;[DEST] = 177777
045152  000257                          CCC                     ;CLEAR FLAGS
045154  000272                          272                     ;N:C = 1010

045156  021512                  I0600:  CMP     (R5),(R2)       ;TEST THE CMP

045160  100403                          BMI     E10600          ;N:C = 0100
045162  001002                          BNE     E10600
045164  102401                          BVS     E10600
045166  103002                          BCC     A0600

045170  104005                  E10600: ERROR5                  ;CMP FAILED TO ALTER CODES PROPERLY
045172  045144                          R0600                   ;ERROR LOOP RETURN ADDRESS

045174  020412                  A0600:  CMP     R4,(R2)         ;CORRECT RESULT ?
045176  001403                          BEQ     00600           ;BR IF YES

045200  011203                          MOV     (R2),R3         ;GET THE WAS DATA
045202  104000                  E20600: ERROR                   ;CMP DELIVERED A RESULT
045204  045144                          R0600                   ;ERROR LOOP RETURN ADDRESS

045206  000004                  00600:  SCOPE                   ;CALL THE SCOPE LOOP UTILITY
```

```
                                        ; ***************************************************************
                                                .SBTTL T0601 CMP  SM1,DM1 TEST - <N:C> = 0110
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [141,247,250,161,266,267,225,367,375,016] FC 1,2,3,8

                                        ;ACT BUTS:      37[004]100,141  /  35[247]120,161  /  33[266]220,225  /  16[367]016,016

                                        ;EXEC:          [225]ALUC=LLHHL :[367]D=177777

                                        ;CODES:         [367]SPS=3       /       N:C=1001

                                        ;SYNC:          B05J2   (-)      T=3.4 USEC

                                        ;KEY SIG:       K3-3 CMP L  /  K3-3 SM=1 L  /  K3-3 DM=1 L  /  K3-8 CINOO L
                                                        ;  K4-4 ALLOW CLK L

045210  012700  000601          T0601:  MOV     #0601,R0                ;LOAD R0 WITH TEST NO.
045214  013701  045250                  MOV     @#I0601,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
045220  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
045224  012704  000001                  MOV     #+1,R4          ;RESULT S / B = 000001
045230  012705  067606                  MOV     #MBUF1,R5       ;SOURCE ADDR = MBUF1
045234  012715  000000          R0601:  MOV     #0,(R5)         ;[SOURCE] = 000000
045240  012712  000001                  MOV     #+1,(R2)        ;[DEST] = 000001
045244  000257                          CCC                     ;CLEAR FLAGS
045246  000266                          266                     ;N:C = 0110

045250  021512                  I0601:  CMP     (R5),(R2)       ;TEST THE CMP

045252  100003                          BPL     E10601          ;N:C = 1001 ?
045254  001402                          BEQ     E10601
045256  102401                          BVS     E10601
045260  103402                          BCS     A0601

045262  104005                  E10601: ERROR5                  ;CMP FAILED TO ALTER CODES PROPERLY
045264  045234                          R0601                   ;ERROR LOOP RETURN ADDRESS

045266  020412                  A0601:  CMP     R4,(R2)         ;CORRECT RESULT ?
045270  001403                          BEQ     00601           ;BR IF YES

045272  011203                          MOV     (R2),R3         ;GET THE WAS DATA
045274  104000                  E20601: ERROR                   ;CMP DELIVERED A RESULT
045276  045234                          R0601                   ;ERROR LOOP RETURN ADDRESS

045300  000004                  00601:  SCOPE                   ;CALL THE SCOPE LOOP UTILITY
```

```
20282                                   ; ***************************************************************
20283                                           .SBTTL T0602 CMP  SM1,DM1 TEST - <N:C> = 0000
20284                                   ; ***************************************************************
20285
20286                                   ;MICROPROGRAMMING  /  LOGIC INFORMATION
20287
20288                                   ;ROM SEQ:       [141,247,250,161,266,267,225,367,375,016] FC 1,2,3,8
20289
20290                                   ;ACT BUTS:      37[004]100,141  /  35[247]120,161  /  33[266]220,225  /  16[367]016,016
20291
20292                                   ;EXEC:          [225]ALUC=LLHHL :[367]D=077777
20293
20294                                   ;CODES:         [367]SPS=3       /      N:C=0010
20295
20296                                   ;SYNC:          B05J2   (-)     T=3.4 USEC
20297
20298                                   ;KEY SIG:       K3-3 CMP L  /  K3-3 SM=1 L  /  K3-8 CINOO L
20299                                                   ;  K4-4 ALLOW CLK L
20300
20301  045302  012700  000602           T0602:  MOV     #0602,R0                ;LOAD R0 WITH TEST NO.
20302  045306  013701  045340                   MOV     @#I0602,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
20303  045312  012702  067602                   MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
20304  045316  012704  000001                   MOV     #+1,R4          ;RESULT S / B = 000001
20305  045322  012705  067606                   MOV     #MBUF1,R5       ;SOURCE ADDR = MBUF1
20306  045326  012715  100000           R0602:  MOV     #100000,(R5)    ;[SOURCE] = 100000
20307  045332  012712  000001                   MOV     #+1,(R2)        ;[DEST] = 000001
20308  045336  000257                           CCC                     ;N:C = 0000
20309
20310  045340  021512                   I0602:  CMP     (R5),(R2)       ;TEST THE CMP
20311
20312  045342  100403                           BMI     E10602          ;N:C = 0010 ?
20313  045344  001402                           BEQ     E10602
20314  045346  102001                           BVC     E10602
20315  045350  103002                           BCC     A0602
20316
20317  045352  104005                   E10602: ERROR5                  ;CMP FAILED TO ALTER CODES PROPERLY
20318  045354  045326                           R0602                   ;ERROR LOOP RETURN ADDRESS
20319
20320  045356  020412                   A0602:  CMP     R4,(R2)         ;CORRECT RESULT ?
20321  045360  001403                           BEQ     00602           ;BR IF YES
20322
20323  045362  011203                           MOV     (R2),R3         ;GET THE WAS DATA
20324  045364  104000                   E20602: ERROR                   ;CMP DELIVERED A RESULT
20325  045366  045326                           R0602                   ;ERROR LOOP RETURN ADDRESS
20326
20327  045370  000004                   00602:  SCOPE                   ;CALL THE SCOPE LOOP UTILITY
20328
20329
```

```
                                ; ****************************************************************
                                        .SBTTL T0603 BISB  SM1,DM0 TEST - SOURCE ADDR ODD
                                ; ****************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [141,247,250,137,251,120,371,360,000] FC 1,2,8

                                ;ACT BUTS:      37[004]100,141  /  35[247]120,137  /  36[137]120,120  /  31[120]360,360
                                                ;  /  27[371]000,000

                                ;EXEC:          [371]ALUC=LLLLH :[360]D=177777

                                ;CODES:         [360]SPS=3       /      N:C=1000

                                ;SYNC:          B05J2   (-)     T=2.8 USEC

                                ;KEY SIG:       K3-3 BIS L  /  K3-3 SM=1 L  /  K3-3 DM=0 L  /  K1-6 BADD(1) H
                                                ;  K3-7 ODD BYTE H  /  K3-6 BYTE INSTR H

045372  012700  000603          T0603:  MOV     #0603,R0                ;LOAD R0 WITH TEST NO.
045376  013701  045422                  MOV     @#I0603,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
045402  012702  177703                  MOV     #177703,R2      ;DEST ADDR = R3
045406  012704  000377                  MOV     #377,R4         ;RESULT S / B = 377
045412  012705  070153          R0603:  MOV     #DBTA+1,R5      ;SOURCE ADDR = DBTA+1
045416  005003                          CLR     R3              ;[DEST] = 000000
045420  000257                          CCC                     ;SCOPE SYNC

045422  151503                  I0603:  BISB    (R5),R3         ;TEST THE BISB

045424  020403                          CMP     R4,R3           ;RESULT CORRECT ?
045426  001402                          BEQ     00603           ;BR IF YES

045430  104000                  E0603:  ERROR                   ;BISB DELIVERED THE WRONG RESULT
045432  045412                          R0603                   ;ERROR LOOP RETURN ADDRESS

045434  000004                  00603:  SCOPE                   ;CALL THE SCOPE LOOP UTILITY
```

```
                                        ; ***************************************************************
                                                .SBTTL T0604 BISB  SM1,DM1 TEST - SOURCE ADDR ODD
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [141,247,250,137,251,161,266,267,225,367,375,016] FC 1,2,3,8

                                        ;ACT BUTS:      37[004]100,141  /  35[247]120,137  /  36[137]120,161  /  33[266]220,225
                                                        ;  /  16[367]016,016

                                        ;EXEC:          [225]ALUC=LLLLH :[367]D=177777

                                        ;CODES:         [367]SPS=3       /       N:C=1000

                                        ;SYNC:          B05J2   (-)     T=3.8 USEC

                                        ;KEY SIG:       K3-3 BIS L  /  K3-3 SM=1 L  /  K3-3 DM=1 L  /  K3-6 BYTE INSTR H
                                                        ;  K3-7 ODD BYTE H  /  K1-6 BADD(1) H

045436  012700  000604          T0604:  MOV     #0604,R0                ;LOAD R0 WITH TEST NO.
045442  013701  045500                  MOV     @#I0604,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
045446  032737  004000  766642          BIT     #4000,@#BPTLOC  ;BREAKPOINT HALT SET ??
045454  001401                          BEQ     .+4             ;BR IF NOT
045456  000000                          HALT                    ;BREAK-DEPRESS CONTINUE TO RESTART
045460  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
045464  012704  000377                  MOV     #377,R4         ;RESULT S / B = 377
045470  012705  070153          R0604:  MOV     #DBTA+1,R5      ;SOURCE ADDR = DBTA+1
045474  005012                          CLR     (R2)            ;[DEST] = 000000
045476  000257                          CCC                     ;SCOPE SYNC

045500  151512                  I0604:  BISB    (R5),(R2)       ;TEST THE BISB

045502  020412                          CMP     R4,(R2)         ;CORRECT RESULT
045504  001403                          BEQ     00604           ;BR IF YES

045506  011203                          MOV     (R2),R3         ;GET THE WAS DATA
045510  104000                  E0604:  ERROR                   ;BISB DELIVERED THE WRONG RESULT
045512  045470                          R0604                   ;ERROR LOOP RETURN ADDRESS

045514  000004                  00604:  SCOPE                   ;CALL THE SCOPE LOOP UTILITY
```

```
                                        ; ****************************************************************
                                                .SBTTL T0605 BISB  SM1,DM2 TEST - SOURCE ADDR ODD
                                        ; ****************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [141,247,250,137,251,162,260,267,225,367,375,016] FC 1,2,3,8

                                        ;ACT BUTS:      37[004]100,141  /  35[247]120,137  /  36[137]120,162  /  33[260]220,225
                                                        ;  /  16[367]016,016

                                        ;EXEC:          [225]ALUC=LLLLH :[367]D=177777

                                        ;CODES:         [367]SPS=3       /      N:C=1000

                                        ;SYNC:          BOSJ2   (-)     T=3.8 USEC

                                        ;KEY SIG:       K3-3 BIS L  /  K3-3 SM=1 L  /  K3-3 DM=2 L  /  K3-6 BYTE INSTR H
                                                        ;  /  K1-6 BADD(1) H  /  K3-7 ODD BYTE H  /  K5-5 BCON(1+2) H

045516  012700  000605          T0605:  MOV     #0605,R0                ;LOAD R0 WITH TEST NO.
045522  013701  045550                  MOV     @#I0605,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
045526  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
045532  012704  000377                  MOV     #377,R4         ;RESULT S / B = 377
045536  012705  070153          R0605:  MOV     #DBTA+1,R5      ;SOURCE ADDR = DBTA+1
045542  005012                          CLR     (R2)            ;[DEST] = 000000
045544  010203                          MOV     R2,R3           ;DEST ADDR IN R3
045546  000257                          CCC                     ;SCOPE SYNC

045550  151523                  I0605:  BISB    (R5),(R3)+      ;TEST THE BISB

045552  020412                          CMP     R4,(R2)         ;CORRECT RESULT
045554  001403                          BEQ     00605           ;BR IF YES

045556  011203                          MOV     (R2),R3         ;GET THE WAS DATA
045560  104000                  E0605:  ERROR                   ;BISB DELIVERED THE WRONG RESULT
045562  045536                          R0605                   ;ERROR LOOP RETURN ADDRESS

045564  000004                  00605:  SCOPE                   ;CALL THE SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0606 BISB  SM1,DM3 TEST - SOURCE ADDR ODD
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [141,247,250,137,251,163,264,265,266,267,225,367,375,016] FC 1,2,3,8

                                ;ACT BUTS:      37[004]100,141  /  35[247]120,137  /  36[137]120,163  /  33[266]220,225
                                                ;  /  16[367]016,016

                                ;EXEC:          [225]ALUC=LLLLH :[367]D=177777

                                ;CODES:         [367]SPS=3       /       N:C=1000

                                ;SYNC:          B05J2   (-)      T=4.5 USEC

                                ;KEY SIG:       K3-3 BIS L  /  K3-3 SM=1 L  /  K3-3 DM=3 L  /  K3-6 BYTE INSTR H
                                                ;  /  K3-7 ODD BYTE H  /  K1-6 BA00(1) H  /  K5-5 BC01 H

045566  012700  000606          T0606:  MOV     #0606,R0                ;LOAD R0 WITH TEST NO.
045572  013701  045622                  MOV     @#I0606,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
045576  012702  067602                  MOV     #MB_F0,R2       ;DEST ADDR = MBUF0
045602  012704  000377                  MOV     #377,R4         ;RESULT S / B = 377
045606  012705  070153          R0606:  MOV     #DBTA+1,R5      ;SOURCE ADDR = DBTA+1
045612  005012                          CLR     (R2)            ;[DEST] = 000000
045614  012703  067576                  MOV     #ATA+10,R3      ;BASE DEST ADDR = ATA+10
045620  000257                          CCC                     ;SCOPE SYNC

045622  151533                  I0606:  BISB    (R5),@(R3)+     ;TEST THE BISB

045624  020412                          CMP     R4,(R2)         ;CORRECT RESULT
045626  001403                          BEQ     00606           ;BR IF YES

045630  011203                          MOV     (R2),R3         ;GET THE WAS DATA
045632  104000                  E0606:  ERROR                   ;BISB DELIVERED THE WRONG RESULT
045634  045606                          R0606                   ;ERROR LOOP RETURN ADDRESS

045636  000004                  00606:  SCOPE                   ;CALL THE SCOPE LOOP UTILITY
```

```
                                        ; ***************************************************************
                                                .SBTTL T0607 BISB  SM1,DM4 TEST - SOURCE ADDR ODD
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [141,247,250,137,251,164,260,267,225,367,375,016] FC 1,2,3,8

                                        ;ACT BUTS:      37[004]100,141  /  35[247]120,137  /  36[137]120,164  /  33[260]220,225
                                                        ;  /  16[367]016,016

                                        ;EXEC:          [225]ALUC=LLLLH :[367]D=177777

                                        ;CODES:         [367]SPS=3       /      N:C=1000

                                        ;SYNC:          B05J2   (-)     T=3.8 USEC

                                        ;KEY SIG:       K3-3 BIS L  /  K3-3 SM=1 L  /  K3-3 DM=4 L  /  K3-6 BYTE INSTR H
                                                        ;  /  K1-6 BA00(1) H  /  K3-7 ODD BYTE H  /  K5-5 BCON(1+2) H

045640  012700  000607          T0607:  MOV     #0607,R0                ;LOAD R0 WITH TEST NO.
045644  013701  045674                  MOV     @#I0607,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
045650  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
045654  012704  177400                  MOV     #177400,R4      ;RESULT S / B = 177400
045660  012705  070153          R0607:  MOV     #DBTA+1,R5      ;SOURCE ADDR = DBTA+1
045664  012703  067604                  MOV     #MBUF0+2,R3     ;BASE DEST ADDR = MBUF0+2
045670  005012                          CLR     (R2)            ;[DEST] = 000000
045672  000257                          CCC                     ;SCOPE SYNC

045674  151543                  I0607:  BISB    (R5),-(R3)      ;TEST THE BISB

045676  020412                          CMP     R4,(R2)         ;CORRECT RESULT
045700  001403                          BEQ     00607           ;BR IF YES

045702  011203                          MOV     (R2),R3         ;GET THE WAS DATA
045704  104000                  E0607:  ERROR                   ;BISB DELIVERED THE WRONG RESULT
045706  045660                          R0607                   ;ERROR LOOP RETURN ADDRESS

045710  000004                  00607:  SCOPE                   ;CALL THE SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0610 BISB  SM1,DM5 TEST - SOURCE ADDR ODD
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [141,247,250,137,251,165,264,265,266,267,225,367,375,016] FC 1,2,3,8

                                ;ACT BUTS:      37[004]100,141  /  35[247]120,137  /  36[137]120,165  /  33[266]220,225
                                                ;  /  16[367]016,016

                                ;EXEC:          [225]ALUC=LLLLH :[367]D=177777

                                ;CODES:         [367]SPS=3       /      N:C=1000

                                ;SYNC:          BOSJ2   (-)     T= 4.5 USEC

                                ;KEY SIG:       K3-3 BIS L  /  K3-3 SM=1 L  /  K3-3 DM=5 L  /  K3-6 BYTE INSTR H
                                                ;  K1-6 BA00(1) H  /  K3-7 ODD BYTE H  /  K5-5 BC01 H

045712  012700  000610          T0610:  MOV     #0610,R0                ;LOAD R0 WITH TEST NO.
045716  013701  045746                  MOV     @#I0610,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
045722  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
045726  012704  000377                  MOV     #377,R4         ;RESULT S / B = 377
045732  012705  070153          R0610:  MOV     #DBTA+1,R5      ;SOURCE ADDR = DBTA+1
045736  012703  067600                  MOV     #ATA+12,R3      ;BASE DEST ADDR = ATA+12
045742  005012                          CLR     (R2)            ;[DEST] = 000000
045744  000257                          CCC                     ;SCOPE SYNC

045746  151553                  I0610:  BISB    (R5),@-(R3)     ;TEST THE BISB

045750  020412                          CMP     R4,(R2)         ;CORRECT RESULT
045752  001403                          BEQ     00610           ;BR IF YES

045754  011203                          MOV     (R2),R3         ;GET THE WAS DATA
045756  104000                  E0610:  ERROR                   ;BISB DELIVERED THE WRONG RESULT
045760  045732                          R0610                   ;ERROR LOOP RETURN ADDRESS

045762  000004                  00610:  SCOPE                   ;CALL THE SCOPE LOOP UTILITY
```

```
                                        ; ***************************************************************
                                                .SBTTL T0611 BISB  SM1,DM6 TEST - SOURCE ADDR ODD
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [141,247,250,137,251,167,261,262,266,267,225,367,375,016] FC 1,2,3,8

                                        ;ACT BUTS:      37[004]100,141  /  35[247]120,137  /  36[137]120,167  /  17[167]262,262
                                                        ;  /  33[266]220,225  /  16[367]016,016

                                        ;EXEC:          [225]ALUC=LLLLH :[367]D=177777

                                        ;CODES:         [367]SPS=3       /       N:C=1000

                                        ;SYNC:          B05J2   (-)     T=4.6 USEC

                                        ;KEY SIG:       K3-3 BIS L  /  K3-3 SM=1 L  /  K3-3 DM=6 L  /  K3-6 BYTE INSTR H
                                                        ;  K3-7 ODD BYTE H  /  K1-6 BA00(1) H

045764  012700  000611          T0611:  MOV     #0611,R0                ;LOAD R0 WITH TEST NO.
045770  013701  046020                  MOV     @#I0611,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
045774  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
046000  012704  000377                  MOV     #377,R4         ;RESULT S / B = 377
046004  012705  070153          R0611:  MOV     #DBTA+1,R5      ;SOURCE ADDR = DBTA+1
046010  012703  067610                  MOV     #MBUF0+6,R3     ;BASE DEST ADDR = MBUF0+6
046014  005012                          CLR     (R2)            ;[DEST] = 000000
046016  000257                          CCC                     ;SCOPE SYNC

046020  151563  177772          I0611:  BISB    (R5),-6(R3)     ;TEST THE BISB

046024  020412                          CMP     R4,(R2)         ;CORRECT RESULT
046026  001403                          BEQ     00611           ;BR IF YES

046030  011203                          MOV     (R2),R3         ;GET THE WAS DATA
046032  104000          E0611:  ERROR                           ;BISB DELIVERED THE WRONG RESULT
046034  046004                  R0611                           ;ERROR LOOP RETURN ADDRESS

046036  000004          00611:  SCOPE                           ;CALL THE SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0612 BISB  SM1,DM7 TEST - SOURCE ADDR ODD
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [141,247,250,137,251,167,261,263,264,265,266,267,225,367,375,016] FC 1,2

                                ;ACT BUTS:      37[004]100,141  /  35[247]120,137  /  36[137]120,167  /  17[167]262,263
                                                ;  /  33[266]220,225  /  16[367]016,016

                                ;EXEC:          [225]ALUC=LLLLH :[367]D=177777

                                ;CODES:         [367]SPS=3       /       N:C=1000

                                ;SYNC:          B05J2   (-)     T=5.2 USEC

                                ;KEY SIG:       K3-3 BIS L  /  K3-3 SM=1 L  /  K3-3 DM=7 L  / K3-6 BYTE INSTR H
                                                ;  K3-7 ODD BYTE H  /  K1-6 BADD(1) H

046040  012700  000612          T0612:  MOV     #0612,R0                ;LOAD R0 WITH TEST NO.
046044  013701  046074                  MOV     @#I0612,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
046050  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
046054  012704  000377                  MOV     #377,R4         ;RESULT S / B = 377
046060  012705  070153          R0612:  MOV     #DBTA+1,R5      ;SOURCE ADDR = DBTA+1
046064  012703  067566                  MOV     #ATA,R3         ;BASE DEST ADDR = ATA
046070  005012                          CLR     (R2)            ;[DEST] = 000000
046072  000257                          CCC                     ;SCOPE SYNC

046074  151573  000010          I0612:  BISB    (R5),@10(R3)    ;TEST THE BISB

046100  020412                          CMP     R4,(R2)         ;CORRECT RESULT
046102  001403                          BEQ     00612           ;BR IF YES

046104  011203                          MOV     (R2),R3         ;GET THE WAS DATA
046106  104000          E0612:  ERROR                           ;BISB DELIVERED THE WRONG RESULT
046110  046060                  R0612                           ;ERROR LOOP RETURN ADDRESS

046112  000004          00612:  SCOPE                           ;CALL THE SCOPE LOOP UTILITY
```

```
                                        ; ***************************************************************
                                                .SBTTL T0613 BISB  SM0,DM2 TEST - DEST ADDR EVEN
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [162,260,267,224,367,375,016] FC 1,3,8

                                        ;ACT BUTS:      37[004]100,162  /  33[260]220,224  /  16[367]016,016

                                        ;EXEC:          [224]ALUC=LLLLH :[367]D=000377

                                        ;CODES:         [367]SPS=3       /  N:C=1000

                                        ;SYNC:          B05J2   (-)     T=2.7 USEC

                                        ;KEY SIG:       K3-3 BIS L  /  K3-3 SM=0 L  /  K3-3 DM=1 L  /  K3-6 BYTE INSTR H
                                                        ;  K5-5 BCON(1+2) H

046114  012700  000613          T0613:  MOV     #0613,R0                ;LOAD R0 WITH TEST NO.
046120  013701  046142                  MOV     @#I0613,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
046124  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
046130  012704  000377                  MOV     #377,R4         ;RESULT S / B = 377
046134  010203                  R0613:  MOV     R2,R3           ;DEST ADDR IN R3
046136  005012                          CLR     (R2)            ;[DEST] = 000000
046140  000257                          CCC                     ;SCOPE SYNC

046142  150423                  I0613:  BISB    R4,(R3)+        ;TEST THE BISB

046144  020412                          CMP     R4,(R2)         ;CORRECT RESULT
046146  001403                          BEQ     C0613           ;BR IF YES

046150  011203                          MOV     (R2),R3         ;GET THE WAS DATA
046152  104000                  EC613:  ERROR                   ;BISB DELIVERED THE WRONG RESULT
046154  046134                          R0613                   ;ERROR LOOP RETURN ADDRESS

046156  000004                  OD613:  SCOPE                   ;CALL THE SCOPE LOOP UTILITY
```

```
                                        ; ***************************************************************
                                                .SBTTL T0614 BISB  SM0,DM1 TEST - DEST ADDR ODD
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [161,266,267,237,270,230,254,074,366,375,016] FC 1,3,8

                                        ;ACT BUTS:      37[004]100,161  /  33[266]220,237  /  34[237]220,230  /  16[366]016,016

                                        ;EXEC:          [230]ALUC=LLLLH :[375]D=177777

                                        ;CODES:         [254]SPS=1,[074]SPS=3    /      N:C=1000

                                        ;SYNC:          B05J2   (-)     T=3 USEC

                                        ;KEY SIG:       K3-3 BIS L  /  K3-3 SM=0 L  /  K3-3 DM=1 L  /  K3-6 BYTE INSTR H
                                                        ;  K3-7 ODD BYTE H  /  K1-6 BADD(1) H

046160  012700  000614          T0614:  MOV     #0614,R0                ;LOAD R0 WITH TEST NO.
046164  013701  046214                  MOV     @#I0614,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
046170  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
046174  012704  177400                  MOV     #177400,R4      ;RESULT S / B = 177400
046200  012705  000377                  MOV     #377,R5         ;[R5]=SOURCE CPR = 377
046204  012703  067603          R0614:  MOV     #MBUF0+1,R3     ;ODD DEST ADDR IN R3
046210  005012                          CLR     (R2)            ;[DEST] = 000000
046212  000257                          CCC                     ;SCOPE SYNC

046214  150513                  I0614:  BISB    R5,(R3)         ;TEST THE BISB

046216  020412                          CMP     R4,(R2)         ;CORRECT RESULT
046220  001403                          BEQ     O0614           ;BR IF YES

046222  011203                          MOV     (R2),R3         ;GET THE WAS DATA
046224  104000                  E0614:  ERROR                   ;BISB DELIVERED THE WRONG RESULT
046226  046204                          R0614                   ;ERROR LOOP RETURN ADDRESS

046230  000004                  O0614:  SCOPE                   ;CALL THE SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0615 BISB  SM0,DM1 TEST - DEST ADDR EVEN
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [161,266,257,224,367,375,016] FC 1,3,8

                                ;ACT BUTS:      37[004]100,161  /  33[266]220,224  /  16[367]016,016

                                ;EXEC:          [224]ALUC=LLLLH :[367]D=000377

                                ;CODES:         [367]SPS=3       /      N:C=1000

                                ;SYNC:          B05J2   (-)     T=2.6 USEC

                                ;KEY SIG:       K3-3 BIS L  /  K3-3 SM=0 L  /  K3-3 DM=1 L  /  K3-6 BYTE INSTR H

046232  012700  000615          T0615:  MOV     #0615,R0                ;LOAD R0 WITH TEST NO.
046236  013701  046260                  MOV     @#I0615,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
046242  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
046246  012704  000377                  MOV     #377,R4         ;RESULT S / B = 377
046252  010203                  R0615:  MOV     R2,R3           ;DEST ADDR IN R3
046254  005012                          CLR     (R2)            ;[DEST] = 000000
046256  000257                          CCC                     ;SCOPE SYNC

046260  150413                  I0615:  BISB    R4,(R3)         ;TEST THE BISB

046262  020412                          CMP     R4,(R2)         ;CORRECT RESULT
046264  001403                          BEQ     00615           ;BR IF YES

046266  011203                          MOV     (R2),R3         ;GET THE WAS DATA
046270  104000                  E0615:  ERROR                   ;BISB DELIVERED THE WRONG RESULT
046272  046252                          R0615                   ;ERROR LOOP RETURN ADDRESS

046274  000004                  00615:  SCOPE                   ;CALL THE SCOPE LOOP UTILITY
```

```
                                        ; ***************************************************************
                                                .SBTTL T0616 BISB  SM1,DM1 TEST - DEST ADDR ODD
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [141,247,250,137,251,161,266,257,237,270,231,254,074,366,375,016] FC 1,2

                                        ;ACT BUTS:      37[004]100,141  /  35[247]120,137  /  36[137]120,161  /  33[266]220,237
                                                        ;  /  34[237]220,231  /  16[366]016,016

                                        ;EXEC:          [231]ALUC=LLLLH :[375]D=177777

                                        ;CODES:         [254]SPS=1,[074]SPS=3    /      N:C=1000

                                        ;SYNC:          B05J2   (-)     T=4.2 USEC

                                        ;KEY SIG:       K3-3 BIS L  /  K3-3 SM=1 L  /  K3-3 DM=1 L  /  K3-6 BYTE INSTR H
                                                        ;  K3-7 ODD BYTE H  /  K1-6 BADD(1) H

046276  012700  000616                  T0616:  MOV     #0616,R0                ;LOAD R0 WITH TEST NO.
046302  013701  046332                          MOV     @#I0616,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
046306  012702  067602                          MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
046312  012704  177400                          MOV     #177400,R4      ;RESULT S / B = 177400
046316  012705  070153                  R0616:  MOV     #DBTA+1,R5      ;SOURCE ADDR = DBTA+1
046322  012703  067603                          MOV     #MBUF0+1,R3     ;ODD DEST ADDR IN R3
046326  005012                                  CLR     (R2)            ;[DEST] = 000000
046330  000257                                  CCC                     ;SCOPE SYNC

046332  151513                          I0616:  BISB    (R5),(R3)       ;TEST THE BISB

046334  020412                                  CMP     R4,(R2)         ;CORRECT RESULT
046336  001403                                  BEQ     00616           ;BR IF YES

046340  011203                                  MOV     (R2),R3         ;GET THE WAS DATA
046342  104000                          E0616:  ERROR                   ;BISB DELIVERED THE WRONG RESULT
046344  046316                                  R0616                   ;ERROR LOOP RETURN ADDRESS

046346  000004                          00616:  SCOPE                   ;CALL THE SCOPE LOOP UTILITY
```

```
                                        ; ***************************************************************
                                                .SBTTL T0617 JMP MODE 1 TEST, FLAGS = 1111
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [151,300,306,313,016] FC 1,5

                                        ;ACT BUTS:      37[004]100,151 / 15[151]306,306 / 16[306]016,016

                                        ;EXEC:          [306]ALUC=LLLLL :[313] D = #A0617

                                        ;CODES:         N:C = 1111 (NO CHANGE)

                                        ;SYNC:          BOSJ2 (-) T = 1.8 USEC

                                        ;KEY SIG:       K3-3 DM=1L  /  K3-5 JMP L  /  K3-5 JMP+JSR H

046350  012700  000617                  T0617:  MOV     #0617,R0                ;LOAD R0 WITH TEST NO.
046354  013701  046366                          MOV     @#I0617,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD

046360  012702  046376                  R0617:  MOV     #A0617,R2               ;R2 CONTAINS JUMP ADDRESS
046364  000277                                  SCC                     ;MAKE N:C = 1111

046366  000112                          I0617:  JMP     (R2)            ;TEST THE JMP - GO TO A0617

046370  104006                          E10617: ERROR6                  ;JMP FAILED TO LOAD PC
046372  046360                                  R0617                   ;ERROR LOOP RETURN
046374  000406                                  BR      00617           ;GO CALL SCOPE

046376  103003                          A0617:  BCC     E20617          ;BR IF JMP CLEARED "C"
046400  102002                                  BVC     E20617          ;BR IF JMP CLEARED "V"
046402  001001                                  BNE     E20617          ;BR IF JMP CLEARED "Z"
046404  100402                                  BMI     00617           ;BR IF "N" STILL SET

046406  104006                          E20617: ERROR6                  ;JMP ALTERED CODES - CLEARED ONE
046410  046360                                  R0617                   ;ERROR LOOP RETURN

046412  000004                           00617: SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0620 JMP MODE 1 TEST, FLAGS = 0000
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [151,300,306,313,016] FC 1,5

                                ;ACT BUTS:      37[004]100,151 / 15[151]306,306 / 16[306]016,016

                                ;EXEC:          [306]ALUC=LLLLL :[313] D = #A0620

                                ;CODES:         N:C = 0000 (NO CHANGE)

                                ;SYNC:          B05J2 (-) T = 1.8 USEC

                                ;KEY SIG:       K3-3 DM=1L  /  K3-5 JMP L  /  K3-5 JMP+JSR H

046414  012700  000620          T0620:  MOV     #0620,R0                ;LOAD R0 WITH TEST NO.
046420  013701  046432                  MOV     @#I0620,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD

046424  012702  046442          R0620:  MOV     #A0620,R2               ;R2 CONTAINS JMP ADDRESS
046430  000257                          CCC                     ;MAKE N:C = 0000

046432  000112                  I0620:  JMP     (R2)            ;TEST THE JMP - GO TO A0620

046434  104006                  E10620: ERROR5                  ;JMP FAILED TO LOAD PC
046436  046424                          R0620                   ;ERROR LOOP RETURN
046440  000406                          BR      00620           ;GO CALL SCOPE

046442  103403                  A0620:  BCS     E20620          ;BR IF JMP SET "C"
046444  102402                          BVS     E20620          ;BR IF JMP SET "V"
046446  001401                          BEQ     E20620          ;BR IF JMP SET "Z"
046450  100002                          BPL     00620           ;BR IF "N" STILL CLEAR

046452  104006                  E20620: ERROR6                  ;JMP ALTERED CODES - SET ONE
046454  046424                          R0620                   ;ERROR LOOP RETURN

046456  000004                   00620: SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ****************************************************************
                                        .SBTTL T0621 JMP MODE 2 TEST; FLAGS = 1111
                                ; ****************************************************************
046460  012700  000621          T0621:  MOV     #0621,R0                ;LOAD R0 WITH TEST NO.
                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [152,235,300,306,313,016] FC 1,5

                                ;ACT BUTS:      37[004]100,152 / 15[235]306,306 / 16[306]016,016

                                ;EXEC:          [306]ALUC=LLLLL :[313] D = #A0621

                                ;CODES:         N:C = 1111 (NO CHANGE)

                                ;SYNC:          B05J2 (-) T = 2.1 USEC

                                ;KEY SIG:       K3-3 DM=2L  /  K3-5 JMP L  /  K3-5 JMP+JSR H  /  K5-5 BC01 H

046464  013701  046476                  MOV     @#I0621,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD

046470  012702  046506          R0621:  MOV     #A0621,R2               ;R2 CONTAINS JUMP ADDRESS
046474  000277                          SCC                     ;SET N:C = 1111

046476  000122                  I0621:  JMP     (R2)+           ;TEST THE JMP - GO TO A0621

046500  104006                  E10621: ERROR6                  ;JMP FAILED TO LOAD PC
046502  046470                          R0621                   ;ERROR LOOP RETURN
046504  000413                          BR      00621           ;GO TO SCOPE EXIT

046506  103003                  A0621:  BCC     E20621          ;BR IF JMP CLEARED "C"
046510  102002                          BVC     E20621          ;BR IF JMP CLEARED "V"
046512  001001                          BNE     E20621          ;BR IF JMP CLEARED "Z"
046514  100402                          BMI     B0621           ;BR IF "N" STILL SET

046516  104006                  E20621: ERROR6                  ;JMP ALTERED CODES - CLEARED
046520  046470                          R0621                   ;ERROR LOOP RETURN

046522  022702  046510          B0621:  CMP     #A0621+2,R2     ;DID R2 GET AUTO-INCREMENTED?
046526  001402                          BEQ     00621           ;BR IF YES

046530  104006                  E30621: ERROR6                  ;JMP FAILED TO UPDATE REGISTER (R2)
046532  046470                          R0621                   ;ERROR LOOP RETURN

046534  000004                   00621: SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0622 JMP MODE 2 TEST; FLAGS = 0000
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [152,235,300,306,313,016] FC 1,5

                                ;ACT BLTS:      37[004]100,152 / 15[235]306,306 / 16[306]016,016

                                ;EXEC:          [306]ALUC=LLLLL :[313] D = #A0622

                                ;CODES:         N:C = 0000 (NO CHANGE)

                                ;SYNC:          B05J2 (-) T = 2.1 USEC

                                ;KEY SIG:       K3-3 DM=2L  /  K3-5 JMP L  /  K3-5 JMP+JSR H  /  K5-5 BC01 H

046536  012700  000622          T0622:  MOV     #0622,R0                ;LOAD R0 WITH TEST NO.
046542  013701  046554                  MOV     @#I0622,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD

046546  012702  046564          R0622:  MOV     #A0622,R2               ;R2 CONTAINS JUMP ADDRESS
046552  000257                          CCC                     ;MAKE N:C = 0000

046554  000122                  I0622:  JMP     (R2)+           ;TEST THE JMP - GO TO A0622

046556  104006                  E10622: ERROR6                  ;JMP FAILED TO LOAD PC
046560  046546                          R0622                   ;ERROR LOOP RETURN
046562  000406                          BR      00622           ;GO TO SCOPE EXIT

046564  103403                  A0622:  BCS     E20622          ;BR IF JMP SET "C"
046566  102402                          BVS     E20622          ;BR IF JMP SET "V"
046570  001401                          BEQ     E20622          ;BR IF JMP SET "Z"
046572  100002                          BPL     00622           ;BR IF "N" IS CLEAR

046574  104006                  E20622: ERROR6                  ;JMP ALTERED CODES - SET
046576  046546                          R0622                   ;ERROR LOOP RETURN

046600  000004                  00622:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0623 JMP TEST MODE 3; FLAGS = 1111
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [153,303,306,313,016] FC 1,5

                                ;ACT BUTS:      37[004]100,153 / 15[153]306,306 / 16[306]016,016

                                ;EXEC:          [306]ALUC=LLLLL :[313] D = #A0623

                                ;CODES:         N:C = 1111 (NO CHANGE)

                                ;SYNC:          B05J2 (-) T = 2.3 USEC

                                ;KEY SIG:       K3-3 DM=3L  /  K3-5 JMP L  /  K3-5 JMP+JSR H  /  K5-5 BC01 H

046602  012700  000623          T0623:  MOV     #0623,R0                ;LOAD R0 WITH TEST NO.
046606  013701  046620                  MOV     @#I0623,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD

046612  012702  046660          R0623:  MOV     #JMP3,R2        ;R2 CONTAINS ADDRESS OF JUMP ADDRESS
046616  000277                          SCC                     ;SET N:C = 1111

046620  000132                  I0623:  JMP     @(R2)+          ;TEST THE JMP - GO TO A0623

046622  104006                  E10623: ERROR6                  ;JMP FAILED TO LOAD PC
046624  046612                          R0623                   ;ERROR LOOP RETURN
046626  000417                          BR      00623           ;GO TO SCOPE EXIT

046630  103003                  A0623:  BCC     E20623          ;BR IF JMP CLEARED "C"
046632  102002                          BVC     E20623          ;BR IF JMP CLEARED "V"
046634  001001                          BNE     E20623          ;BR IF JMP CLEARED "Z"
046636  100402                          BMI     B0623           ;BR IF "N" STILL SET

046640  104006                  E20623: ERROR6                  ;JMP ALTERED CODES - CLEAR
046642  046612                          R0623                   ;ERROR LOOP RETURN

046644  022702  046662          B0623:  CMP     #JMP3+2,R2      ;DID JMP UPDATE R2?
046650  001406                          BEQ     00623           ;BR IF YES

046652  104006                  E30623: ERROR6                  ;JMP FAILED TO UPDATE REGISTER
046654  046612                          R0623                   ;ERROR LOOP RETURN
046656  000403                          BR      00623           ;GO TO SCOPE EXIT
046660  046630                  JMP3:   A0623                   ;JMP3 CONTAINS JUMP ADDRESS
046662  104006                  E40623: ERROR6                  ;ERROR CALL OCCURS IF MODE3 HAPPENS
046664  046612                          R0623                   ;ERROR LOOP RETURN
                                                                ;TO EXECUTE AS MODE 1 OR 2 AND
                                                                ;A0623 IS LEGAL INSTRUCTION

046666  000004                  00623:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0624 JMP TEST MODE 3; FLAGS = 0000
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [153,303,306,313,016] FC 1,5

                                ;ACT BUTS:      37[004]100,153 / 15[153]306,306 / 16[306]016,016

                                ;EXEC:          [306]ALUC=LLLLL :[313] D = #A0624

                                ;CODES:         N:C = 0000 (NO CHANGE)

                                ;SYNC:          B05J2 (-) T = 2.3 USEC

                                ;KEY SIG:       K3-3 DM=3L  /  K3-5 JMP L  /  K3-5 JMP+JSR H  /  K5-5 BC01 H

046670  012700  000624          T0624:  MOV     #0624,R0                ;LOAD R0 WITH TEST NO.
046674  013701  046706                  MOV     @#I0624,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD

046700  012702  046734          R0624:  MOV     #JMP3A,R2       ;R2 CONTAINS ADDRESS OF JUMP ADDRESS
046704  000257                          CCC                     ;MAKE N:C = 0000

046706  000132                  I0624:  JMP     @(R2)+          ;TEST THE JMP - GO TO A0624

046710  104006                  E10624: ERROR6                  ;JMP FAILED TO LOAD THE PC
046712  046700                          R0624                   ;ERROR LOOP RETURN
046714  000412                          BR      00624           ;GO TO SCOPE EXIT

046716  103403                  A0624:  BCS     E20624          ;BR IF JMP SET "C"
046720  102402                          BVS     E20624          ;BR IF JMP SET "V"
046722  001401                          BEQ     E20624          ;BR IF JMP SET "Z"
046724  100006                          BPL     00624           ;BR IF "N" STILL CLEAR

046726  104006                  E20624: ERROR6                  ;JMP ALTERED CODES - SET
046730  046700                          R0624                   ;ERROR LOOP RETURN
046732  000403                          BR      00624           ;GO TO SCOPE EXIT

046734  046716                  JMP3A:  A0624                   ;JUMP ADDRESS IN JMP3A
046736  104006                  E30624: ERROR6                  ;JMP MODE 3 EXECUTED LIKE MODE 1 OR 2
046740  046700                          R0624                   ;ERROR LOOP RETURN

046742  000004                   00624: SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***************************************************************
                                                .SBTTL T0625 JMP TEST MODE 4; FLAGS = 1111
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [154,300,306,313,016] FC 1,5

                                        ;ACT BUTS:      37[004]100,154 / 15[154]306,306 / 16[306]016,016

                                        ;EXEC:          [306]ALUC=LLLLL :[313] D = #E20625-2

                                        ;CODES:         N:C = 1111 (NO CHANGE)

                                        ;SYNC:          B05J2 (-) T = 1.9 USEC

                                        ;KEY SIG:       K3-3 DM=4L  /  K3-5 JMP L  /  K3-5 JMP+JSR H  /  K5-5 BC01 H

046744  012700  000625                  T0625:  MOV     #0625,R0                ;LOAD R0 WITH TEST NO.
046750  013701  046762                          MOV     @#I0625,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
046754  012702  046774                  R0625:  MOV     #E20625,R2      ;[R2] = JMP ADDRESS PLUS 2
046760  000277                                  SCC                     ;MAKE N:C = 1111

046762  000142                          I0625:  JMP     -(R2)           ;TEST THE JMP - GO TO E20625 MINUS 2

046764  104006                          E10625: ERROR6                  ;JMP FAILED TO LOAD PC
046766  046754                                  R0625                   ;ERROR LOOP RETURN
046770  000417                                  BR      00625           ;GO TO SCOPE EXIT

046772  000403                                  BR      A0625           ;GO TEST FLAGS - JMP LOADED PC OK
046774  104006                          E20625: ERROR6                  ;JMP FAILED TO AUTO-DECREMENT R2
046776  046754                                  R0625                   ;ERROR LOOP RETURN
047000  000413                                  BR      00625           ;GO TO SCOPE EXIT

047002  103003                          A0625:  BCC     E30625          ;BR IF JMP CLEARED "C"
047004  102002                                  BVC     E30625          ;BR IF JMP CLEARED "V"
047006  001001                                  BNE     E30625          ;BR IF JMP CLEARED "Z"
047010  100402                                  BMI     B0625           ;BR IF "N" STILL SET

047012  104006                          E30625: ERROR6                  ;JMP ALTERED FLAGS
047014  046754                                  R0625                   ;ERROR LOOP RETURN

047016  022702  046772                  B0625:  CMP     #E20625-2,R2    ;DID JMP UPDATE R2 PROPERLY?
047022  001402                                  BEQ     00625           ;BR IF YES

047024  104006                          E40625: ERROR6                  ;JMP FAILED TO UPDATE REGISTER
047026  046754                                  R0625                   ;ERROR LOOP RETURN

047030  000004                           00625: SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0626 JMP TEST MODE 4; FLAGS = 0000
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [154,300,306,313,016] FC 1,5

                                ;ACT BUTS:      37[004]100,154 / 15[154]306,306 / 16[306]016,016

                                ;EXEC:          [306]ALUC=LLLLL :[313] D = #A0626

                                ;CODES:         N:C = 0000 (NO CHANGE)

                                ;SYNC:          B05J2 (-) T = 1.9 USEC

                                ;KEY SIG:       K3-3 DM=4L  /  K3-5 JMP L  /  K3-5 JMP+JSR H  /  K5-5 BC01 H

047032  012700  000626          T0626:  MOV     #0626,R0                ;LOAD R0 WITH TEST NO.
047036  013701  047050                  MOV     @#I0626,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD

047042  012702  047062          R0626:  MOV     #A0626+2,R2     ;[R2] = JUMP ADDRESS PLUS 2
047046  000257                          CCC                     ;MAKE N:C = 0000

047050  000142                  I0626:  JMP     -(R2)           ;TEST THE JMP - TO TO A0626

047052  104006                  E10626: ERROR6                  ;JMP FAILED TO LOAD PC
047054  047042                          R0626                   ;ERROR LOOP RETURN
047056  000406                          BR      00626           ;GO TO SCOPE EXIT

047060  103403                  A0626:  BCS     E20626          ;BR IF JMP SET "C"
047062  102402                          BVS     E20626          ;BR IF JMP SET "V"
047064  001401                          BEQ     E20626          ;BR IF JMP SET "Z"
047066  100002                          BPL     00626           ;BR IF "N" STILL CLEAR

047070  104006                  E20626: ERROR6                  ;JMP ALTERED CODES - SET
047072  047042                          R0626                   ;ERROR LOOP RETURN

047074  000004                   00626: SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***************************************************************
                                                .SBTTL T0627 JMP TEST MODE 5; FLAGS = 1111
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [155,303,306,313,016] FC 1,5

                                        ;ACT BUTS:      37[004]100,155 / 15[155]306,306 / 16[306]016,016

                                        ;EXEC:          [306]ALUC=LLLLL :[313] D = #A0627

                                        ;CODES:         N:C = 1111 (NO CHANGE)

                                        ;SYNC:          B05J2 (-) T = 2.3 USEC

                                        ;KEY SIG:       K3-3 DM=5L  /  K3-5 JMP L  /  K3-5 JMP+JSR H  /  K5-5 BC01 H

047076  012700  000627          T0627:  MOV     #0627,R0                ;LOAD R0 WITH TEST NO.
047102  013701  047114                  MOV     @#I0627,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD

047106  012702  047156          R0627:  MOV     #JMP5,R2        ;JMP CONTAINS ADDR+2 OF JUMP ADDRESS
047112  000277                          SCC

047114  000152                  I0627:  JMP     @-(R2)          ;TEST THE JMP - GO TO A0627

047116  104006                  E10627: ERROR6                  ;JMP FAILED TO LOAD PC
047120  047106                          R0627                   ;ERROR LOOP RETURN
047122  000417                          BR      00627           ;GO TO SCOPE OXIT

047124  103003                  A0627:  BCC     E20627          ;BR IF JMP CLEARED "C"
047126  102002                          BVC     E20627
047130  001001                          BNE     E20627
047132  100402                          BMI     B0627

047134  104006                  E20627: ERROR6                  ;JMP ALTERED CODES - CLEARED
047136  047106                          R0627                   ;ERROR LOOP RETURN

047140  022702  047154          B0627:  CMP     #JMP5-2,R2      ;DID R2 GET AUTO-DECREMENTED
047144  001406                          BEQ     00627           ;BR IF YES

047146  104006                  E30627: ERROR6                  ;JMP FAILED TO UPDATE REGISTER
047150  047106                          R0627                   ;ERROR LOOP RETURN
047152  000403                          BR      00627           ;GO TO SCOPE EXIT
047154  047124                          A0627                   ;THIS LOCATION CONTAINS JMP ADDRESS
047156  104006                  JMP5:   ERROR6                  ;JMP EXECUTED LIKE A MODE 1 OR 2
047160  047106                          R0627                   ;ERROR LOOP RETURN

047162  000004                   00627: SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***************************************************************
                                                .SBTTL T0630 JMP TEST MODE 5; FLAG = 0000
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [155,303,306,313,016] FC 1,5

                                        ;ACT BUTS:      37[004]100,155 / 15[155]306,306 / 16[306]016,016

                                        ;EXEC:          [306]ALUC=LLLLL :[313] D = #A0630

                                        ;CODES:         N:C = 0000 (NO CHANGE)

                                        ;SYNC:          B05J2 (-) T = 2.3 USEC

                                        ;KEY SIG:       K3-3 DM=SL  /  K3-5 JMP L  /  K3-5 JMP+JSR H  /  K5-5 BC01 H

047164  012700  000630          T0630:  MOV     #0630,R0                ;LOAD R0 WITH TEST NO.
047170  013701  047202                  MOV     @#I0630,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD

047174  012702  047232          RC630:  MOV     #JMP5A,R2       ;[R2] = ADDR +2 OF JUMP ADDRESS
047200  000257                          CCC                     ;SET N:C = C000

047202  000152                  I0630:  JMP     @-(R2)          ;TEST THE JMP - GO TO A0630

047204  104006                  E10630: ERROR6                  ;JMP FAILED TO LOAD PC
047206  047174                          R0630                   ;ERROR LOOP RETURN
047210  000412                          BR      00630           ;GO TO SCOPE EXIT

047212  103403                  A0630:  BCS     E20630          ;BR IF JMP SET "C"
047214  102402                          BVS     E20630          ;BR IF JMP SET "V"
047216  001401                          BEQ     E20630          ;BR IF JMP SET "Z"
047220  100006                          BPL     00630           ;BR IF "N" STILL CLEAR

047222  104006                  E20630: ERROR6                  ;JMP ALTERED THE CODES - SET
047224  047174                          R0630                   ;ERROR LOOP RETURN
047226  000403                          BR      00630           ;GO TO SCOPE EXIT

047230  047212                          A0630                   ;THIS LOCATION CONTAINS JUMP ADDRESS
047232  104006                  JMP5A:  ERROR6                  ;JMP EXECUTED LIKE A MODE 1 OR 2
047234  047174                          R0630                   ;ERROR LOOP RETURN

047236  000004                  00630:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0631 JMP TEST MODE 6; FLAGS = 1111
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [156,304,305,300,306,313,016] FC 1,5

                                ;ACT BUTS:      37[004]100,156 / 15[305]306,306 / 16[306]016,016

                                ;EXEC:          [306]ALUC=LLLLL :[313] D = #A0631

                                ;CODES:         N:C = 1111 (NO CHANGE)

                                ;SYNC:          BOSJ2 (-) T = 2.4 USEC

                                ;KEY SIG:       K3-3 DM=6L  /  K3-5 JMP L  /  K3-5 JMP+JSR H

047240  012700  000631          T0631:  MOV     #0631,R0                ;LOAD R0 WITH TEST NO.
047244  013701  047256                  MOV     @#I0631,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD

047250  012702  047306          R0631:  MOV     #E30631,R2      ;[R2] = BASE ADDRESS TO BE INDEXED
047254  000277                          SCC                     ;MAKE N:C = 1111

047256  000162  177762          I0631:  JMP     A0631-E30631(R2)        ;TEST THE JMP - GO TO A0631

047262  104006                  E10631: ERROR6                  ;JMP FAILED TO LOAD THE PC
047264  047250                          R0631                   ;ERROR LOOP RETURN
047266  000411                          BR      00631           ;GO TO SCOPE EXIT

047270  103003                  A0631:  BCC     E20631          ;BR IF JMP CLEARED "C"
047272  102002                          BVC     E20631
047274  001001                          BNE     E20631
047276  100405                          BMI     00631           ;BR IF "N" STILL SET

047300  104006                  E20631: ERROR6                  ;JMP ALTERED CODES - CLEARED
047302  047250                          R0631                   ;ERROR LOOP RETURN
047304  000402                          BR      00631           ;GO TO SCOPE EXIT

047306  104006                  E30631: ERROR6                  ;JMP EXECUTED LIKE A MODE 1 OR 2 OR
047310  047250                          R0631                   ;ERROR LOOP RETURN
                                                                ;FAILED TO INDEX [R2]

047312  000004                   00631: SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0632 JMP TEST MODE 6; FLAGS = 0000
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [156,304,305,300,306,313,016] FC 1,5

                                ;ACT BUTS:      37[004]100,156 / 15[305]306,306 / 16[306]016,016

                                ;EXEC:          [306]ALUC=LLLLL :[313] D = #A0632

                                ;CODES:         N:C = 0000 (NO CHANGE)

                                ;SYNC:          BOSJ2 (-) T = 2.4 USEC

                                ;KEY SIG:       K3-3 DM=6L  /  K3-5 JMP L  /  K3-5 JMP+JSR H

047314  012700  000632          T0632:  MOV     #0632,R0                ;LOAD R0 WITH TEST NO.
047320  013701  047332                  MOV     @#I0632,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD

047324  012702  047362          R0632:  MOV     #E30632,R2      ;[R2] = BASE ADDRESS FOR JUMP
047330  000257                          CCC                     ;MAKE N:C = 0000

047332  000162  177762          I0632:  JMP     A0632-E30632(R2)        ;TEST THE JMP - GO TO A0632

047336  104006                  E10632: ERROR6                  ;JMP FAILED TO LOAD PC
047340  047324                          R0632                   ;ERROR LOOP RETURN
047342  000411                          BR      00632           ;GO TO SCOPE EXIT

047344  103403                  A0632:  BCS     E20632          ;BR IF JMP SET "C"
047346  102402                          BVS     E20632          ;BR IF JMP SET "V"
047350  001401                          BEQ     E20632          ;BR IF JMP SET "Z"
047352  100005                          BPL     00632           ;BR IF "N" STILL CLEAR

047354  104006                  E20632: ERROR6                  ;JMP ALTERED CODES
047356  047324                          R0632                   ;ERROR LOOP RETURN
047360  000402                          BR      00632           ;GO TO SCOPE EXIT

047362  104006                  E30632: ERROR6                  ;JMP EXECUTED LIKE A MODE 1 OR 2, OR
047364  047324                          R0632                   ;ERROR LOOP RETURN
                                                                ;FAILED TO INDEX [R2]

047366  000004                   00632: SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***************************************************************
                                                .SBTTL T0633 JMP TEST MODE 7; FLAGS = 1111
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [157,301,302,303,306,313,016] FC 1,5

                                        ;ACT BUTS:      37[004]100,157 / 15[302]306,306 / 16[306]016,016

                                        ;EXEC:          [360]ALUC=LLLLL :[313] D = #A0633

                                        ;CODES:         N:C = 1111 (NO CHANGE)

                                        ;SYNC:          BOSJ2 (-) T = 3 USEC

                                        ;KEY SIG:       K3-3 DM=7L  /  K3-5 JMP L  /  K3-5 JMP+JSR H

047370  012700  000633          T0633:  MOV     #0633,R0                ;LOAD R0 WITH TEST NO.
047374  013701  047406                  MOV     @#I0633,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD

047400  012702  047420          R0633:  MOV     #E20633,R2      ;[R2] = BASE ADDRESS
047404  000277                          SCC                     ;MAKE N:C = 1111

047406  000172  000024          I0633:  JMP     @JMP7-E20633(R2)        ;TEST THE JMP - GO TO A0633

047412  104006                  E10633: ERROR6                  ;JMP FAILED TO LOAD PC
047414  047400                          R0633                   ;ERROR LOOP RETURN
047416  000415                          BR      00633           ;GO TO SCOPE EXIT

047420  104006                  E20633: ERROR6                  ;JMP FAILED TO INDEX OR ACTED LIKE MODE 1 OR 2
047422  047400                          R0633                   ;ERROR LOOP RETURN
047424  000412                          BR      00633           ;GO TO SCOPE EXIT

047426  103003                  A0633:  BCC     E30633          ;BR IF JMP CLEARED "C"
047430  102002                          BVC     E30633          ;BR IF JMP CLEARED "V"
047432  00:001                          BNE     E30633          ;BR IF JMP CLEARED "Z"
047434  100406                          BMI     00633           ;BR IF "N" STILL SET

047436  104006                  E30633: ERROR6                  ;JMP ALTERED CODES - CLEARED
047440  047400                          R0633                   ;ERROR LOOP RETURN
047442  000403                          BR      00633           ;GO TO SCOPE EXIT

047444  047426                  JMP7:   A0633                   ;THIS LOCATION CONTAINS JMP ADDRESS

047446  104006                  E40633: ERROR6                  ;JMP EXECUTED LIKE MODE 6
047450  047400                          R0633                   ;ERROR LOOP RETURN

047452  000004                   00633: SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***************************************************************
                                                .SBTTL T0634 JMP TEST MODE 7; FLAGS = 0000
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [157,301,302,303,306,313,016] FC 1,5

                                        ;ACT BUTS:      37[004]100,157 / 15[302]306,306 / 16[306]016,016

                                        ;EXEC:          [306]ALUC=LLLLL :[313] D = #A0634

                                        ;CODES:         N:C = 0000 (NO CHANGE)

                                        ;SYNC:          B05J2 (-) T = 3 USEC

                                        ;KEY SIG:       K3-3 DM=7L  /  K3-5 JMP L  /  K3-5 JMP+JSR H

047454  012700  000634          T0634:  MOV     #0634,R0                ;LOAD R0 WITH TEST NO.
047460  013701  047472                  MOV     @#I0634,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD

047464  012702  047504          R0634:  MOV     #E20634,R2      ;[R2] = BASE ADDRESS
047470  000257                          CCC                     ;MAKE N:C = 0000

047472  000172  000024          I0634:  JMP     @JMP7A-E20634(R2)       ;TEST THE JMP - GO TO A0634

047476  104006                  E10634: ERROR6                  ;JMP FAILED TO LOAD PC
047500  047464                          R0634                   ;ERROR LOOP RETURN
047502  000415                          BR      00634           ;GO TO SCOPE EXIT

047504  104006                  E20634: ERROR6                  ;JMP FAILED TO INDEX
047506  047464                          R0634                   ;ERROR LOOP RETURN
047510  000412                          BR      00634           ;GO TO SCOPE EXIT

047512  103403                  A0634:  BCS     E30634          ;BR IF JMP SET "C"
047514  102402                          BVS     E30634          ;BR IF JMP SET "V"
047516  001401                          BEQ     E30634          ;BR IF JMP SET "Z"
047520  100006                          BPL     00634           ;BR IF "N" STILL CLEAR

047522  104006                  E30634: ERROR6                  ;JMP ALTERED CODES - SET
047524  047464                          R0634                   ;ERROR LOOP RETURN
047526  000403                          BR      00634           ;GO TO SCOPE EXIT

047530  047512                  JMP7A:  A0634                   ;THIS LOCATION CONTAINS JUMP ADDRESS

047532  104006                  E40634: ERROR6                  ;JMP EXECUTED LIKE A MODE 6
047534  047464                          R0634                   ;ERROR LOOP RETURN

047536  000004                   00634: SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***********************************************************************
                                        .SBTTL T0635 JSR MODE 1 TEST - LOAD PC  /  PUSH SP
                                ; ***********************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [151,300,307,310,311,312,306,313,016] FC 1,5

                                ;ACT BUTS:      37[004]100,151 / 15[151]306,307 / 16[306]016,016

                                ;EXEC:          [306]ALUC=LLLLL :[313] D = #A0635

                                ;CODES:         N / A

                                ;SYNC:          B05J2 (-) T = 3 USEC

                                ;KEY SIG:       K3-3 DM=1L  /  K3-5 JMP+JSR H  /  K3-5 JSR H

047540  012700  000635          T0635:  MOV     #0635,R0                ;LOAD R0 WITH TEST NO.
047544  013701  047560                  MOV     @#I0635,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
047550  010605                          MOV     SP,R5           ;SAVE THE SP
047552  012702  047566          R0635:  MOV     #A0635,R2               ;DEST ADDR = A0635
047556  000257                          CCC                     ;SCOPE SYNC

047560  004412                  I0635:  JSR     R4,(R2)         ;TEST THE JSR - GO TO A0635

047562  104005                  E10635: ERROR5                  ;JSR FAILED TO LOAD THE PC
047564  047552                          R0635                   ;ERROR LOOP RETURN

047566  005726                  A0635:  TST     (SP)+           ;POP THE SP
047570  020605                          CMP     SP,R5           ;DID JSR PUSH THE SP ?
047572  001404                          BEQ     00635           ;BR IF YES

047574  005746                          TST     -(SP)           ;RESTORE ERROR SP
047576  104005                  E20635: ERROR5                  ;JSR FAILED TO PUSH THE SP
047600  047552                          R0635                   ;ERROR LOOP RETURN

047602  010506                          MOV     R5,SP           ;RESTORE SP IN CASE OF ERROR
047604  000004                  00635:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***************************************************************
                                                .SBTTL T0636 JSR MODE 1 TEST - CHECK RN AND OLD PC
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [151,300,307,310,311,312,306,313,016] FC 1,5

                                        ;ACT BUTS:      37[004]100,151 / 15[151]306,307 / 16[306]016,016

                                        ;EXEC:          [310] D = 125252  /  [312] D = #E10636  /  [313] D = #A0636

                                        ;CODES:         N / A

                                        ;SYNC:          B05J2 (-) T = 3 USEC

                                        ;KEY SIG:       K3-3 DM=1L  /  K3-5 JSR H  /  K3-5 JMP+JSR H

047606  012700  000636          T0636:  MOV     #0636,R0                ;LOAD R0 WITH TEST NO.
047612  013701  047636                  MOV     @#I0636,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
047616  010605                          MOV     SP,R5           ;SAVE THE SP
047620  012702  047644          R0636:  MOV     #A0636,R2               ;DEST ADDR = A0636
047624  005066  177776                  CLR     -2(SP)          ;INIT STACK LOC TO GET [R4]
047630  012704  125252                  MOV     #125252,R4      ;INIT RN = 125252
047634  000257                          CCC                     ;SCOPE SYNC

047636  004412                  I0636:  JSR     R4,(R2)         ;TEST THE JSR - GO TO A0636

047640  104005                  E10636: ERROR5                  ;JSR FAILED TO LOAD THE PC
047642  047620                          R0636                   ;ERROR LOOP RETURN

047644  022726  125252          A0636:  CMP     #125252,(SP)+   ;DID JSR SAVE REG ON STACK
047650  001402                          BEQ     C0636           ;BR IF IT DID

047652  104005                  E20636: ERROR5                  ;JSR FAILED TO SAVE REG ON STACK
047654  047620                          R0636                   ;ERROR LOOP RETURN

047656  022704  047640          C0636:  CMP     #E10636,R4      ;DID OLD PC GET SAVED ?
047662  001402                          BEQ     B0636           ;BR IF YES

047664  104005                  E30636: ERROR5                  ;JSR FAILED TO SAVE TH OLD PC
047666  047620                          R0636                   ;ERROR LOOP RETURN

047670  010506                  B0636:  MOV     R5,SP           ;RESTORE SP IN CASE ERROR SCREWED IT UP
047672  000004                  00636:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***********************************************************************
                                        .SBTTL T0637 JSR MODE 1 TEST - (N:C) = 0000
                                ; ***********************************************************************
047674  012700  000637          T0637:  MOV     #0637,R0                ;LOAD R0 WITH TEST NO.
                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [151,300,307,310,311,312,306,313,016] FC 1,5

                                ;ACT BUTS:      37[004]100,151 / 15[151]306,307 / 16[306]016,016

                                ;EXEC:          [306]ALUC=LLLLL :[313] D = #A0637

                                ;CODES:         N:C = 0000 (NO CHANGE)

                                ;SYNC:          B05J2 (-) T = 3 USEC

                                ;KEY SIG:       K3-3 DM=1L  /  K3-5 JSR H  /  K3-5 JMP+JSR H

047700  013701  047714                  MOV     @#I0637,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
047704  010605                          MOV     SP,R5           ;SAVE THE SP
047706  012702  047722          R0637:  MOV     #A0637,R2               ;DEST ADDR = A0637
047712  000257                          CCC                     ;N:C = 0000

047714  004412                  I0637:  JSR     R4,(R2)         ;TEST THE JSR - GO TO A0637

047716  104005                  E10637: ERROR5                  ;JSR FAILED TO LOAD THE PC
047720  047706                          R0637                   ;ERROR LOOP RETURN

047722  100403                  A0637:  BMI     E20637          ;N:C = 0000 ?
047724  001402                          BEQ     E20637
047726  102401                          BVS     E20637
047730  103002                          BCC     B0637

047732  104005                  E20637: ERROR5                  ;JSR FAILED - ALTERED FLAGS
047734  047706                          R0637                   ;ERROR LOOP RETURN

047736  010506                  B0637:  MOV     R5,SP           ;RESET SP IN CASE OF ERROR
047740  000004                  00637:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***********************************************************************
                                                .SBTTL T0640 JSR MODE 1 TEST - (N:C) = 1111
                                        ; ***********************************************************************
047742  012700  000640                  T0640:  MOV     #0640,R0                ;LOAD R0 WITH TEST NO.
                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [151,300,307,311,312,306,313,016] FC 1,5

                                        ;ACT BUTS:      37[004]100,151 / 15[151]306,307 / 16[306]016,016

                                        ;EXEC:          [306]ALUC=LLLLL :[313] D = #A0640

                                        ;CODES:         N:C = 1111 (NO CHANGE)

                                        ;SYNC:          B05J2 (-) T = 3 USEC

                                        ;KEY SIG:       K3-3 DM=1L  /  K3-5 JSR H  /  K3-5 JMP+JSR H

047746  013701  047762                          MOV     @#I0640,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
047752  010605                                  MOV     SP,R5           ;SAVE THE SP
047754  012702  047770                  R0640:  MOV     #A0640,R2               ;DEST ADDR = A0640
047760  000277                                  SCC                     ;N:C = 1111

047762  004412                          I0640:  JSR     R4,(R2)         ;TEST THE JSR - GO TO A0640

047764  104005                          E10640: ERROR5                  ;JSR FAILED TO LOAD THE PC
047766  047754                                  R0640                   ;ERROR LOOP RETURN

047770  100003                          A0640:  BPL     E20640          ;N:C = 1111 ?
047772  001002                                  BNE     E20640
047774  102001                                  BVC     E20640
047776  103402                                  BCS     B0640
050000  104005                          E20640: ERROR5                  ;JSR ALTERED FLAGS
050002  047754                                  R0640                   ;ERROR LOOP RETURN

050004  010506                          B0640:  MOV     R5,SP           ;RESET SP IN CASE OF ERROR
050006  000004                          00640:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***********************************************************************
                                        .SBTTL T0641 JSR MODE 2 TEST
                                ; ***********************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [152,235,300,307,310,311,312,306,313,016] FC 1,5

                                ;ACT BUTS:      37[004]100,152 / 15[235]306,307 / 16[306]016,016

                                ;EXEC:          [306]ALUC=LLLLL :[313] D = #A0641

                                ;CODES:         N / A

                                ;SYNC:          B05J2 (-) T = 3.25 USEC

                                ;KEY SIG:       K3-3 DM=2L  /  K3-5 JSR H  /  K3-5 JMP+JSR H  /  K5-5 BC01 H

050010  012700  000641          T0641:  MOV     #0641,R0                ;LOAD R0 WITH TEST NO.
050014  013701  050032                  MOV     @#I0641,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
050020  010605                          MOV     SP,R5           ;SAVE THE SP
050022  010506                  R0641:  MOV     R5,SP           ;RESET SP FOR ERROR LOOPS
050024  012702  050040                  MOV     #A0641,R2               ;DEST ADDR = A0641
050030  000257                          CCC                     ;SCOPE SYNC

050032  004422                  I0641:  JSR     R4,(R2)+        ;TEST THE JSR - GO TO A0641

050034  104005                  E10641: ERROR5                  ;JSR FAILED TO LOAD THE PC
050036  050022                          R0641                   ;ERROR LOOP RETURN

050040  005726                  A0641:  TST     (SP)+           ;RESET SP
050042  020605                          CMP     SP,R5           ;DID JSR PUSH STACK ?
050044  001404                          BEQ     00641           ;BR IF YES

050046  005746                          TST     -(SP)           ;RESET SP TO ERROR VALUE
050050  104005                  E20641: ERROR5                  ;JSR FAILED TO PUSH SP
050052  050022                          R0641                   ;ERROR LOOP RETURN

050054  010506                          MOV     R5,SP           ;RESTORE SP JUST IN CASE

050056  000004                  00641:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0642 JSR MODE 3 TEST
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [153,303,307,310,311,312,306,313,016] FC 1,5

                                ;ACT BUTS:      37[004]100,153 / 15[153]306,307 / 16[313]016,016

                                ;EXEC:          [306]ALUC=LLLLL :[313] D = #A0642

                                ;CODES:         N / A

                                ;SYNC:          B05J2 (-) T = 3.5 USEC

                                ;KEY SIG:       K3-3 DM=3L  /  K3-5 JSR H  /  K3-5 JMP+JSR H  /  K5-5 BC01 H

050060  012700  000642          T0642:  MOV     #0642,R0                ;LOAD R0 WITH TEST NO.
050064  013701  050102                  MOV     @#I0642,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
050070  010605                          MOV     SP,R5           ;SAVE THE SP
050072  010506          R0642:  MOV     R5,SP           ;RESET SP FOR ERROR LOOPS
050074  012702  050126                  MOV     #JSR3,R2                ;DEST ADDR = [JSR3]
050100  000257                          CCC                     ;SCOPE SYNC

050102  004432          I0642:  JSR     R4,@(R2)+       ;TEST THE JSR - GO TO A0642 VIA JSR3

050104  104005          E10642: ERROR5                  ;JSR FAILED TO LOAD THE PC
050106  050072                  R0642                   ;ERROR LOOP RETURN

050110  005726          A0642:  TST     (SP)+           ;RESET SP
050112  020605                  CMP     SP,R5           ;DID JSR PUSH STACK ?
050114  001410                  BEQ     00642           ;BR IF YES

050116  005746                  TST     -(SP)           ;RESET SP TO ERROR VALUE
050120  104005          E20642: ERROR5                  ;JSR FAILED
050122  050072                  R0642                   ;ERROR LOOP RETURN
050124  000403                  BR      B0642           ;GO EXIT

050126  050110          JSR3:   A0642                   ;CONTAINS JUMP ADDR
050130  104005          E30642: ERROR5                  ;JSR EXECUTED LIKE A MODE 1 OR 2
050132  050072                  R0642                   ;ERROR LOOP RETURN

050134  010506          B0642:  MOV     R5,SP           ;RESTORE SP JUST IN CASE

050136  000004          00642:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0643 JSR MODE 4 TEST
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [154,300,307,311,312,306,313,016] FC 1,5

                                ;ACT BUTS:      37[004]100,154 / 15[154]306,307 / 16[306]016,016

                                ;EXEC:          [306]ALUC=LLLLL :[313] D = #A0643

                                ;CODES:         N / A

                                ;SYNC:          B05J2 (-) T = 3.1 USEC

                                ;KEY SIG:       K3-3 DM=4L  /  K3-5 JSR H  /  K3-5 JMP+JSR H  /  K5-5 BC01 H

050140  012700  000643          T0643:  MOV     #0643,R0                ;LOAD R0 WITH TEST NO.
050144  013701  050162                  MOV     @#I0643,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
050150  010605                          MOV     SP,R5           ;SAVE THE SP
050152  010506                  R0643:  MOV     R5,SP           ;RESET SP FOR ERROR LOOPS
050154  012702  050172                  MOV     #E20643,R2      ;DEST ADDR = A0643+2
050160  000257                          CCC                     ;SCOPE SYNC

050162  004442                  I0643:  JSR     R4,-(R2)        ;TEST THE JSR - GO TO A0643

050164  104005                  E10643: ERROR5                  ;JSR FAILED TO LOAD THE PC
050166  050152                          R0643                   ;ERROR LOOP RETURN

050170  000402                  A0643:  BR      B0643           ;JUMPED OK - GO CHECK SP
050172  104005                  E20643: ERROR5                  ;JSR FAILED TO DECREMENT DEST REG
050174  050152                          R0643                   ;ERROR LOOP RETURN

050176  005726                  B0643:  TST     (SP)+           ;RESET SP
050200  020605                          CMP     SP,R5           ;DID JSR PUSH STACK ?
050202  001404                          BEQ     00643           ;BR IF YES

050204  005746                          TST     -(SP)           ;RESET SP TO ERROR VALUE
050206  104005                  E30643: ERROR5                  ;JSR FAILED TO PUSH SP
050210  050152                          R0643                   ;ERROR LOOP RETURN

050212  010506                  C0643:  MOV     R5,SP           ;RESTORE SP JUST IN CASE

050214  000004                  00643:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***************************************************************
                                                .SBTTL T0644 JSR MODE 5 TEST
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [155,303,307,310,311,312,306,313,016] FC 1,5

                                        ;ACT BUTS:      37[004]100,155 / 15[155]306,307 / 16[306]016,016

                                        ;EXEC:          [306]ALUC=LLLLL :[313] D = #A0644

                                        ;CODES:         N / A

                                        ;SYNC:          B05J2 (-) T = 3.5 USEC

                                        ;KEY SIG:       K3-3 DM=5L  /  K3-5 JSR H  /  K3-5 JMP+JSR H  /  K5-5 BC01 H

050216  012700  000644          T0644:  MOV     #0644,R0                ;LOAD R0 WITH TEST NO.
050222  013701  050252                  MOV     @#I0644,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
050226  032737  010000  066642          BIT     #10000,@#BPTLOC ;BREAKPOINT HALT SET ??
050234  001401                          BEQ     .+4             ;BR IF NOT
050236  000000                          HALT                    ;BREAK-DEPRESS CONTINUE TO RESTART
050240  010605                          MOV     SP,R5           ;SAVE THE SP
050242  010506                  R0644:  MOV     R5,SP           ;RESET SP FOR ERROR LOOPS
050244  012702  050300                  MOV     #E30644,R2      ;DEST ADDR = [E30644 - 2]
050250  000257                          CCC                     ;SCOPE SYNC

050252  004452                  I0644:  JSR     R4,@-(R2)       ;TEST THE JSR - GO TO A0644

050254  104005                  E10644: ERROR5                  ;JSR FAILED TO LOAD THE PC
050256  050242                          R0644                   ;ERROR LOOP RETURN

050260  005726                  A0644:  TST     (SP)+           ;RESET SP
050262  020605                          CMP     SP,R5           ;DID JSR PUSH STACK ?
050264  001410                          BEQ     00644           ;BR IF YES

050266  005746                          TST     -(SP)           ;RESET SP TO ERROR VALUE
050270  104005                  E20644: ERROR5                  ;JSR FAILED TO PUSH SP
050272  050242                          R0644                   ;ERROR LOOP RETURN
050274  000403                          BR      B0644           ;GO EXIT

050276  050260                          A0644                   ;CONTAINS JUMP ADDRESS
050300  104005                  E30644: ERROR5                  ;JSR EXECUTED LIKE A MODE 1 OR 2
050302  050242                          R0644                   ;ERROR LOOP RETURN

050304  010506                  B0644:  MOV     R5,SP           ;RESTORE SP JUST IN CASE

050306  000004                  00644:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***********************************************************************
                                                .SBTTL T0645 JSR MODE 6 TEST
                                        ; ***********************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;RCM SEQ:       [156,304,305,300,307,310,311,312,306,313,016] FC 1,5

                                        ;ACT BUTS:      37[004]100,156 / 15[305]306,307 / 16[306]016,016

                                        ;EXEC:          [306]ALUC=LLLLL :[313] D = #A0645

                                        ;CODES:         N / A

                                        ;SYNC:          BOSJ2 (-) T = 3.5 USEC

                                        ;KEY SIG:       K3-3 DM=6L  /  K3-5 JSR H  /  K3-5 JMP+JSR H

050310  012700  000645          T0645:  MOV     #0645,R0                ;LOAD R0 WITH TEST NO.
050314  013701  050332                  MOV     @#I0645,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
050320  010605                          MOV     SP,R5           ;SAVE THE SP
050322  010506          R0645:          MOV     R5,SP           ;RESET SP FOR ERROR LOOPS
050324  012702  050336                  MOV     #E10645,R2      ;[R2] = BASE DEST ADDR
050330  000257                          CCC                     ;SCOPE SYNC

050332  004462  000004          I0645:  JSR     R4,A0645-E10645(R2)     ;TEST THE JSR - GO TO A0645

050336  104005                  E10645: ERROR5                  ;JSR FAILED TO LOAD THE PC OR INDEX FAILED
050340  050322                          R0645                   ;ERROR LOOP RETURN

050342  005726                  A0645:  TST     (SP)+           ;RESET SP
050344  020605                          CMP     SP,R5           ;DID JSR PUSH STACK ?
050346  001404                          BEQ     G0645           ;BR IF YES


050350  005746                          TST     -(SP)           ;RESET SP TO ERROR VALUE
050352  104005                  E20645: ERROR5                  ;JSR FAILED TO PUSH STACK
050354  050322                          R0645                   ;ERROR LOOP RETURN
050356  010506                          MOV     R5,SP           ;RESET SP JUST IN CASE

050360  000004                  G0645:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***************************************************************
                                                .SBTTL T0646 JSR MODE 7 TEST
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [157,301,302,303,307,310,311,312,306,313,016] FC 1,5

                                        ;ACT BUTS:      37[004]100,157 / 15[302]306,307 / 16[306]016,016

                                        ;EXEC:          [306]ALUC=LLLLL :[313] D = #A0646

                                        ;CODES:         N / A

                                        ;SYNC:          B05J2 (-) T = 4.1 USEC

                                        ;KEY SIG:       K3-3 DM=7L  /  K3-5 JSR H  /  K3-5 JMP+JSR H

050362  012700  000646          T0646:  MOV     #0646,R0                ;LOAD R0 WITH TEST NO.
050366  013701  050404                  MOV     @#I0646,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
050372  010605                          MOV     SP,R5           ;SAVE THE SP
050374  010506          R0646:          MOV     R5,SP           ;RESET SP FOR ERROR LOOPS
050376  012702  05041C                  MOV     #E10646,R2      ;BASE DEST ADDR = E10646
050402  000257                          CCC                     ;SCOPE SYNC

050404  004472  000022          I0646:  JSR     R4,@JSR7-E10646(R2);TEST THE JSR - GO TO A0646 VIA JSR7

050410  104005                  E10646: ERROR5                  ;JSR FAILED TO LOAD THE PC
                                                                ;OR INDEX FAILED
050412  050374                          R0646                   ;ERROR LOOP RETURN

050414  005726                  A0646:  TST     (SP)+           ;RESET SP
050416  020605                          CMP     SP,R5           ;DID JSR PUSH STACK ?
050420  001410                          BEQ     00646           ;BR IF YES

050422  005746                          TST     -(SP)           ;RESET SP TO ERROR VALUE
050424  104005                  E20646: ERROR5                  ;JSR FAILED TO PUSH STACK
050426  050374                          R0646                   ;ERROR LOOP RETURN
050430  000403                          BR      B0646           ;SKIP TO EXIT

050432  050414                  JSR7:   A0646                   ;CONTAINS JUMP ADDR
050434  104005                  E30646: ERROR5                  ;JSR WORKED LIKE A MODE 1 OR 2
050436  050374                          R0646                   ;ERROR LOOP RETURN

050440  010506                  B0646:  MOV     R5,SP           ;RESTORE SP JUST IN CASE

050442  000004                  00646:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***************************************************************
                                                .SBTTL T0647 SOB TEST, [R] = 1, NO BRANCH
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [130,342,343,345,347,016] FC 1,7

                                        ;ACT BUTS:      37[004]100,130 / 12[342]344,345 / 16[345]016,016

                                        ;EXEC:          [130]ALUC=LHHHH :[343] D = 000000

                                        ;CODES:         N / A

                                        ;SYNC:          BOSJ2 (-) T = 2 USEC

                                        ;KEY SIG:       K3-6 SOB L  /  K1-7 D(15:00)=0 H

050444  012700  000647          T0647:  MOV     #0647,R0                ;LOAD R0 WITH TEST NO.
050450  013701  050472                  MOV     @#I0647,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD

050454  012702  000001          R0647:  MOV     #1,R2           ;SET SOB COUNTER = 1
050460  000403                          BR      I0647-2         ;GO DO THE SOB

050462  104006                  E0647:  ERROR6                  ;SOB SHOULDN'T HAVE BRANCHED HERE
050464  050454                          R0647                   ;ERROR LOOP RETURN
050466  000402                          BR      C0647           ;GO TO SCOPE CALL

050470  000257                          CCC                     ;SYNC INSTR.
050472  077205                  I0647:  SOB     R2,E0647                ;TEST THE SOB

050474  000004                   C0647: SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***************************************************************
                                                .SBTTL T0650 SOB TEST, [R] = 5, BRANCH 4 TIMES
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [130,342,343,344,346,016] FC 1,7

                                        ;ACT BUTS:      37[004]100,130 / 12[342]344,344 / 16[344]016,016

                                        ;EXEC:          [130]ALUC=LHHHH :[343] D = 000004 (1ST TIME)
                                        ;               [346]ALUC=LLHHL :[016] D = #A0650
                                        ;CODES:         N / A

                                        ;SYNC:          B05J2 (-) T = 2.36 USEC

                                        ;KEY SIG:       K3-6 SOB L  /  K2-7 DAD3 (1) H  /  K3-8 CINOO L

050476  012700  000650                  T0650:  MOV     #0650,R0                ;LOAD R0 WITH TEST NO.
050502  013701  050526                          MOV     @#I0650,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD

050506  012702  000005                  R0650:  MOV     #5,R2           ;SET SOB COUNTER = 5
050512  012705  177773                          MOV     #-5,R5          ;SET UP R5 TO COUNT 5 BRANCHES
050516  000402                                  BR      I0650-2         ;GO DO THE SOB

050520  005205                          A0650:  INC     R5              ;COUNT ONE BRANCH
050522  001412                                  BEQ     E20650          ;BR IF TOO MANY LOOPS BY SOB

050524  000257                                  CCC                     ;SCOPE SYNC
050526  077204                          I0650:  SOB     R2,A0650                ;TEST THE SOB
050530  000402                                  BR      S0B2            ;SKIP NEXT TWO WORDS

050532  000474                          S0B1:   BR      S0B3            ;USED BY LAST SOB TEST TO TEST MAX OFFSET
050534  000240                                  NOP

050536  005702                          S0B2:   TST     R2              ;R2 SHOULD CONTAIN 0
050540  001405                                  BEQ     00650           ;BR IF IT DOES

050542  104006                          E10650: ERROR6                  ;SOB COUNTER NOT ZERO
050544  050506                                  R0650                   ;ERROR LOOP RETURN
050546  000402                                  BR      00650           ;GO TO SCOPE CALL
050550  104006                          E20650: ERROR6                  ;SOB MADE TOO MANY BRANCHES
050552  050506                                  R0650                   ;ERROR LOOP RETURN
050554  000004                          00650:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ****************************************************************
                                        .SBTTL T0651 SOB TEST, [R] = 1, FLAGS = 1111
                                ; ****************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [130,342,343,345,347,016] FC 1,7

                                ;ACT BUTS:      37[004]100,130 / 12[342]344,345 / 16[345]016,016

                                ;EXEC:          [130]ALUC=LHHHH :[343] D = 000000

                                ;CODES:         N:C = 1111 (NO CHANGE)

                                ;SYNC:          B05J2 (-) T = 2 USEC

                                ;KEY SIG:       K3-6 SOB L  /  K1-7 D(15:00)=0 H

050556  012700  000651          T0651:  MOV     #0651,R0                ;LOAD R0 WITH TEST NO.
050562  013701  050574                  MOV     @#I0651,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD

050566  012702  000001          R0651:  MOV     #1,R2           ;SET SOB COUNTER = 1
050572  000277                          SCC                     ;MAKE N:C = 1111

050574  077202                  I0651:  SOB     R2,I0651-2      ;TEST THE SOB

050576  103003                          BCC     E0651           ;BR IF C = 0
050600  102002                          BVC     E0651           ;BR IF V = 0
050602  001001                          BNE     E0651           ;BR IF Z = 0
050604  100402                          BMI     00651           ;BR IF N = 1

050606  104006                  E0651:  ERROR6                  ;SOB ALTERED CODES - CLEARED ONE
050610  050566                          R0651                   ;ERROR LOOP RETURN

050612  000004                   00651: SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***********************************************************
                                                .SBTTL T0652 SOB TEST, [R] = 1, FLAGS = 0000
                                        ; ***********************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [130,342,343,345,347,016] FC 1,7

                                        ;ACT BUTS:      37[004]100,130 / 12[342]344,345 / 16[345]016,016

                                        ;EXEC:          [130]ALUC=LHHHH :[343] D = 000000

                                        ;CODES:         N:C = 0000 (NO CHANGE)

                                        ;SYNC:          B05J2 (-) T = 2 USEC

                                        ;KEY SIG:       K3-6 SOB L  / K1-7 D(15:00)=0 H

050614  012700  000652                  T0652:  MOV     #0652,R0                ;LOAD R0 WITH TEST NO.
050620  013701  050632                          MOV     @#I0652,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD

050624  012702  000001                  R0652:  MOV     #1,R2           ;SET SOB COUNTER = 1
050630  000257                                  CCC                     ;MAKE N:C = 0000

050632  077202                          I0652:  SOB     R2,I0652-2      ;TEST THE SOB

050634  103403                                  BCS     E0652           ;BR IF C = 1
050636  102402                                  BVS     E0652           ;BR IF V = 1
050640  001401                                  BEQ     E0652           ;BR IF Z = 1
050642  100002                                  BPL     00652           ;BR IF N = 0

050644  104006                          E0652:  ERROR6                  ;SOB ALTERED CODES - SET ONE
050646  050624                                  R0652                   ;ERROR LOOP RETURN

050650  000004                          00652:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0653 SOB TEST, [R] = 5, FLAGS = 1111
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [130,342,343,344,346,016] FC 1,7

                                ;ACT BUTS:      37[004]100,130 / 12[342]344,344 / 16[344]016,016

                                ;EXEC:          [130]ALUC=LHHHH :[343] D = 000004 (1ST TIME9
                                ;               [346]ALUC=LLHHL :[016] D = #I0653
                                ;CODES:         N:C = 1111 (NO CHANGE)

                                ;SYNC:          B05J2 (-) T = 2.36 USEC

                                ;KEY SIG:       K3-6 SOB L  /  K2-7 DAD3 (1) H  /  K3-8 CINOO L

050652  012700  000653          T0653:  MOV     #0653,R0                ;LOAD R0 WITH TEST NO.
050656  013701  050670                  MOV     @#I0653,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD

050662  012702  000005          R0653:  MOV     #5,R2           ;SET SOB COUNTER = 5
050666  000277                          SCC                     ;MAKE N:C = 1111

050670  077201                  I0653:  SOB     R2,I0653                ;TEST THE SOB

050672  103003                          BCC     E0653           ;BR IF C = 0
050674  102002                          BVC     E0653           ;BR IF V = 0
050676  001001                          BNE     E0653           ;BR IF Z = 0
050700  100402                          BMI     00653           ;BR IF N = 1

050702  104006                  E0653:  ERROR6                  ;SOB ALTERED CODES - CLEARED ONE
050704  050662                          R0653                   ;ERROR LOOP RETURN

050706  000004                  00653:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0654 SOB TEST, [R] = 5, FLAGS = 0000
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [130,342,343,344,346,016] FC 1,7

                                ;ACT BUTS:      37[004]100,130 / 12[342]344,344 / 16[344]016,016

                                ;EXEC:          [130]ALUC=LHHHH :[343] D = 000004 (1ST TIME)
                                ;               [346]ALUC=LLHHL :[016] D = #T0654
                                ;CODES:         N:C = 0000 (NO CHANGE)

                                ;SYNC:          B05J2 (-) T = 2.36 USEC

                                ;KEY SIG:       K3-6 SOB L  /  K2-7 DAD3 (1) H  /  K3-8 CIN00 L

050710  012700  000654          T0654:  MOV     #0654,R0                ;LOAD R0 WITH TEST NO.
050714  013701  050726                  MOV     @#T0654,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD

050720  012702  000005          R0654:  MOV     #5,R2           ;SET SOB COUNTER = 5
050724  000257                  SOB3:   CCC                     ;MAKE N:C = 0000

050726  077277                  T0654:  SOB     R2,SOB1         ;TEST THE SOB

050730  103403                          BCS     E0654           ;BR IF C = 1
050732  102402                          BVS     E0654           ;BR IF V = 1
050734  001401                          BEQ     E0654           ;BR IF Z = 1
050736  100002                          BPL     00654           ;BR IF N = 0

050740  104006                  E0654:  ERROR6                  ;SOB ALTERED CODES - SET ONE
050742  050720                          R0654                   ;ERROR LOOP RETURN

050744  000004                  00654:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***********************************************************************
                                        .SBTTL T0655 RTS TEST - <N:C> = 1111
                                ; ***********************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [124,323,324,325,016] FC 1,6

                                ;ACT BUTS:      37[004]100,124 / 16[324]016,016

                                ;EXEC:          [323] D = #A0655  /  [325] D = 177777

                                ;CODES:         N:C = 1111 (NO CHANGE)

                                ;SYNC:          B05J2 (-) T = 2.5 USEC

                                ;KEY SIG:       K3-6 RTS L  /  K5-5 BC01 H

050746  012700  000655          T0655:  MOV     #0655,R0                ;LOAD R0 WITH TEST NO.
050752  013701  051000                  MOV     @#I0655,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
050756  010605                          MOV     SP,R5           ;SAVE THE SP
050760  012704  177777          R0655:  MOV     #-1,R4          ;R3 SHOULD GET 177777
050764  010506                          MOV     R5,SP           ;RESET SP FOR ERROR LOOP
050766  012703  051010                  MOV     #A0655,R3               ;RTS SHOULD LOAD PC FROM [R3]
050772  012746  177777                  MOV     #-1,-(SP)       ;RTS SHOULD LOAD R3 WITH 177777
050776  000277                          SCC                     ;N:C = 1111

051000  000203                  I0655:  RTS     R3              ;TEST THE RTS - GO TO A0655

051002  104005                  E10655: ERROR5                  ;RTS FAILED TO LOAD THE PC
051004  050760                          R0655                   ;ERROR LOOP RETURN ADDRESS
051006  000420                          BR      D0655           ;GO TO EXIT - SCHOOLS OUT

051010  100003                  A0655:  BPL     E20655          ;N:C = 1111 ?
051012  001002                          BNE     E20655
051014  102001                          BVC     E20655
051016  103402                          BCS     B0655

051020  104005                  E20655: ERROR5                  ;RTS ALTERED CODES - CLEARED ONE
051022  050760                          R0655                   ;ERROR LOOP RETURN

051024  020403                  B0655:  CMP     R4,R3           ;DID R3 GET LOADED FROM STACK ?
051026  001402                          BEQ     C0655           ;BR IF YES

051030  104000                  E30655: ERROR                   ;RTS FAILED TO LOAD REG
051032  050760                          R0655                   ;ERROR LOOP RETURN

051034  020506                  C0655:  CMP     R5,SP           ;DID RTS POP THE STACK POINTER ?
051036  001405                          BEQ     00655           ;BR IF YES

051040  010504                          MOV     R5,R4           ;[R4] = S / B SP
051042  010603                          MOV     SP,R3           ;[R3] = WAS SP
051044  104000                  E40655: ERROR                   ;RTS FAILED TO POP SP
051046  050760                          R0655                   ;ERROR LOOP RETURN

051050  010506                  D0655:  MOV     R5,SP           ;FIX THE SP
```

```
22158  051052  000004                    00655:  SCOPE                    ;CALL  THE SCOPE LOOP UTILITY
22159
```

```
                                ; ***********************************************************
                                        .SBTTL T0656 RTS TEST - <N:C> = 0000
                                ; ***********************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [124,323,324,325,016] FC 1,6

                                ;ACT BUTS:      37[004]100,124 / 16[324]016,016

                                ;EXEC:          [323] D = #A0656  /  [325] D = 177777

                                ;CODES:         N:C = 0000 (NO CHANGE)

                                ;SYNC:          B05J2 (-) T = 2.5 USEC

                                ;KEY SIG:       K3-6 RTS L  /  K5-5 BC01 H

051054  012700  000656          T0656:  MOV     #0656,R0                ;LOAD R0 WITH TEST NO.
051060  013701  051106                  MOV     @#I0656,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
051064  010605                          MOV     SP,R5           ;SAVE THE SP
051066  012704  177777          R0656:  MOV     #-1,R4          ;R3 SHOULD GET 177777
051072  010506                          MOV     R5,SP           ;RESET SP FOR ERROR LOOP
051074  012703  051116                  MOV     #A0656,R3               ;RTS SHOULD LOAD PC FROM [R3]
051100  012746  177777                  MOV     #-1,-(SP)       ;RTS SHOULD LOAD R3 WITH 177777
051104  000257                          CCC                     ;N:C = 0000

051106  000203                  I0656:  RTS     R3              ;TEST THE RTS - GO TO A0656

051110  104005                  E10656: ERROR5                  ;RTS FAILED TO LOAD THE PC
051112  051066                          R0656                   ;ERROR LOOP RETURN ADDRESS
051114  000420                          BR      D0656           ;GO TO EXIT - SCHOOLS OUT

051116  100403                  A0656:  BMI     E20656          ;N:C = 0000 ?
051120  001402                          BEQ     E20656
051122  102401                          BVS     E20656
051124  103002                          BCC     B0656

051126  104005                  E20656: ERROR5                  ;RTS ALTERED CODES - CLEARED ONE
051130  051066                          R0656                   ;ERROR LOOP RETURN

051132  020403                  B0656:  CMP     R4,R3           ;DID R3 GET LOADED FROM STACK ?
051134  001402                          BEQ     C0656           ;BR IF YES

051136  104000                  E30656: ERROR                   ;RTS FAILED TO LOAD REG
051140  051066                          R0656                   ;ERROR LOOP RETURN

051142  020506                  C0656:  CMP     R5,SP           ;DID RTS POP THE STACK POINTER ?
051144  001405                          BEQ     00656           ;BR IF YES

051146  010504                          MOV     R5,R4           ;[R4] = S / B SP
051150  010603                          MOV     SP,R3           ;[R3] = WAS SP
051152  104000                  E40656: ERROR                   ;RTS FAILED TO POP SP
051154  051066                          R0656                   ;ERROR LOOP RETURN

051156  010506                  D0656:  MOV     R5,SP           ;FIX THE SP
```

```
22216  051160  000004                00656:  SCOPE                    ;CALL  THE SCOPE LOOP UTILITY
22217
```

```
                                        ; ***********************************************************
                                                .SBTTL T0657 RTT TEST - (N:C) = 1111
                                        ; ***********************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [101,320,321,322,017,015,013] FC 1,6,10

                                        ;ACT BUTS:      37[004]100,101 / 26[017]010,013

                                        ;EXEC:          [320] D = #A0657  /  [322] D = 340

                                        ;CODES:         [322] SPS=7  /  N:C = 0000

                                        ;SYNC:          B05J2 (-) T = 3 USEC

                                        ;KEY SIG:       K3-6 RTT H  /  K3-6 RTI+RTT L  /  K5-5 BC01 H

051162  012700  000657          T0657:  MOV     #0657,R0                ;LOAD R0 WITH TEST NO.
051166  013701  051220                  MOV     @#I0657,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
051172  010605                          MOV     SP,R5           ;SAVE THE SP
051174  010506          R0657:          MOV     R5,SP           ;RESET SP FOR ERROR LOOP
051176  012704  000340                  MOV     #340,R4         ;[R4] = S / B PSW AT HTIS POINT
051202  012746  000340                  MOV     #340,-(SP)      ;NEW PSW S / B = 340
051206  012746  051230                  MOV     #A0657,-(SP)    ;NEW PC S / B = A0657
051212  005037  177776                  CLR     @#PSW           ;CLEAR THE PSW
051216  000277                          SCC                     ;N:C = 1111

051220  000006          I0657:  RTT                             ;TEST THE RTT - GO TO A0657

051222  104005          E10657: ERROR5                          ;RTT FAILED TO LOAD THE PC
051224  051174                  R0657                           ;ERROR LOOP RETURN ADDRESS
051226  000414                  BR      C0657                   ;GO TO EXIT - SCHOOL'S OUT

051230  013703  177776  A0657:  MOV     @#PSW,R3                ;SAVE THE PSW
051234  020403                  CMP     R4,R3                   ;WAS PSW = 340 ?
051236  001402                  BEQ     B0657                   ;BR IF IT WAS

051240  104000          E20657: ERROR                           ;RTT FAILED TO LOAD PSW PROPERLY
                                                                ;[R3] = WAS PSW
                                                                ;[R4] = S / B PSW
051242  051174                  R0657                           ;ERROR LOOP RETURN ADDRESS

051244  020506          B0657:  CMP     R5,SP                   ;DID RTT UPDATE THE SP ?
051246  001405                  BEQ     00657                   ;BR IF YES

051250  010504                  MOV     R5,R4                   ;[R4] = S / B SP
051252  010603                  MOV     SP,R3                   ;[R3] = WAS SP
051254  104000          E30657: ERROR                           ;RTT FAILED TO UPDATE SP
051256  051174                  R0657                           ;ERROR LOOP RETURN ADDRESS

051260  010506          C0657:  MOV     R5,SP                   ;FIX THE SP
051262  000004          00657:  SCOPE                           ;CALL THE SCOPE LOOP UTILITY
```

```
                                        ; ***************************************************************
                                                .SBTTL T0660 RTT TEST - (N:C) = 0000
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [101,320,321,322,017,015,013] FC 1,6,10

                                        ;ACT BUTS:      37[004]100,101 / 26[017]010,013

                                        ;EXEC:          [320] D = #A0660  /  [322] D = 000017

                                        ;CODES:         [322] SPS=7  /  N:C = 1111

                                        ;SYNC:          B05J2 (-) T = 3 USEC

                                        ;KEY SIG:       K3-6 RTI+RTT L  /  K3-6 RTT H  /  K5-5 BC01 H

051264  012700  000660          T0660:  MOV     #0660,R0                ;LOAD R0 WITH TEST NO.
051270  013701  051324                  MOV     @#I0660,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
051274  010605                          MOV     SP,R5           ;SAVE THE SP
051276  010506          R0660:          MOV     R5,SP           ;RESET SP FOR ERROR LOOP
051300  012704  000017                  MOV     #017,R4         ;[R4] = S / B PSW AT HTIS POINT
051304  012746  000017                  MOV     #017,-(SP)      ;NEW PSW S / B = 017
051310  012746  051334                  MOV     #A0660,-(SP)    ;NEW PC S / B = A0660
051314  012737  000340  177776          MOV     #340,@#PSW      ;MAKE [PSW] = 340
051322  000257                          CCC                     ;N:C = 0000

051324  000006          I0660:  RTT                             ;TEST THE RTT - GO TO A0660

051326  104005          E10660: ERROR5                          ;RTT FAILED TO LOAD THE PC
051330  051276                  R0660                           ;ERROR LOOP RETURN ADDRESS
051332  000414                  BR      C0660                   ;GO TO EXIT - SCHOOL'S OUT

051334  013703  177776  A0660:  MOV     @#PSW,R3                ;SAVE THE PSW
051340  020403                  CMP     R4,R3                   ;WAS PSW = 017 ?
051342  001402                  BEQ     B0660                   ;BR IF IT WAS

051344  104000          E20660: ERROR                           ;RTT FAILED TO LOAD PSW PROPERLY
                                                                ;[R3] = WAS PSW
                                                                ;[R4] = S / B PSW
051346  051276                  R0660                           ;ERROR LOOP RETURN ADDRESS

051350  020506          B0660:  CMP     R5,SP                   ;DID RTT UPDATE THE SP ?
051352  001405                  BEQ     00660                   ;BR IF YES

051354  010504                  MOV     R5,R4                   ;[R4] = S / B SP
051356  010603                  MOV     SP,R3                   ;[R3] = WAS SP
051360  104000          E30660: ERROR                           ;RTT FAILED TO UPDATE SP
051362  051276                  R0660                           ;ERROR LOOP RETURN ADDRESS

051364  010506          C0660:  MOV     R5,SP                   ;FIX THE SP
051366  000004          00660:  SCOPE                           ;CALL THE SCOPE LOOP UTILITY
```

```
                                ; ***********************************************************************
                                        .SBTTL T0661 MARK INSTRUCTION TEST - (N:C)=0000
                                ; ***********************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [112,353,354,355,356,357,016] FC 1,5

                                ;ACT BUTS:      37[004]100,112 / 16[356]016,016

                                ;EXEC:          [355] D = #B0661+2  /  [356] D = 125252  /  [357] D = #A0661

                                ;CODES:         N:C = 0000 (NO CHANGE)

                                ;SYNC:          B05J2 (-) T = 2.6 USEC

                                ;KEY SIG:       K3-6 MARK L  /  K5-5 BC01 H

051370  012700  000661          T0661:  MOV     #0661,R0                ;LOAD R0 WITH TEST NO.
051374  013701  051420                  MOV     @#I0661,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
051400  010604                          MOV     SP,R4           ;SAVE SP
051402  012703  125252                  MOV     #125252,R3      ;[R5] SHOULD BE 125252
051406  012705  051444          R0661:  MOV     #A0661,R5               ;MARK GOES TO A0661 VIA [R5]
051412  010337  051432                  MOV     R3,@#B0661      ;INITIALIZE WORD LOADED INTO R5
051416  000257                          CCC                     ;N:C=0000

051420  006404                  I0661:  MARK+4                  ;TEST THE MARK

051422  010406                          MOV     R4,SP           ;RESET SP
051424  104005                  E10661: ERROR5                  ;MARK FAILED TO EXECUTE
051426  051406                          R0661                   ;ERROR LOOP RETURN ADDRESS

051430  000435                          BR      00661           ;GO TO SCOPE EXIT

051432  125252                  B0661:  125252                  ;THIS WORD SHOULD GET LOADED INTO R5

051434  010406                          MOV     R4,SP           ;RESET SP
051436  104005                  E20661: ERROR5                  ;MARK FAILED TO LOAD RC FROM [R5]
051440  051406                          R0661                   ;ERROR LOOP RETURN ADDRESS

051442  000430                          BR      00661           ;GO TO SCOPE EXIT

051444  100403                  A0661:  BMI     D0661           ;N:C=0000?
051446  001402                          BEQ     D0661
051450  102401                          BVS     D0661
051452  103005                          BCC     C0661

051454  013702  177776          D0661:  MOV     @#PSW,R2        ;SAVE FLAGS IN R2
051460  010406                          MOV     R4,SP           ;RESET SP
051462  104006                  E30661: ERROR6                  ;MSRK SET A FLAG -[PSW] IN R2
051464  051406                          R0661                   ;ERROR LOOP RETURN ADDRESS

051466  020627  051434          C0661:  CMP     SP,#B0661+2     ;DID MARK RESET SP?
051472  001405                          BEQ     F0661           ;BR IF YES
051474  010602                          MOV     SP,R2           ;PUT BAD SP IN R2
051476  010406                          MOV     R4,SP           ;RESET SP
```

```
051500  104005          E40661: ERROR5                  ;MARK FAILED TO RESET SP -[R2]=SP WAS
051502  051406                  R0661                   ;ERROR LOOP RETURN ADDRESS

051504  000407                  BR      00661           ;GO TO SCOPE EXIT

051506  020503          F0661:  CMP     R5,R3           ;DID MARK RESTORE OLD R5
051510  001404                  BEQ     G0661           ;BR IF YES

051512  010502                  MOV     R5,R2           ;[R2]=WAS R5
051514  010406                  MOV     R4,SP           ;RESET SP
051516  104007          E50661: ERROR7                  ;MARK FAILED TO RESET R5
051520  051406                  R0661                   ;ERROR LOOP RETURN

051522  010406          G0661:  MOV     R4,SP           ;RESET SP

051524  000004          00661:  SCOPE                   ;CALL THE SCOPE LOOP UTILITY
```

```
                                        ; ***********************************************************************
                                                .SBTTL T0662 MARK INSTRUCTION TEST - (N:C)=1111
                                        ; ***********************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [112,353,354,355,356,357,016] FC 1,5

                                        ;ACT BUTS:      37[004]100,112 / 16[356]016,016

                                        ;EXEC:          [355] D = #B0662+2  /  [356] D = 125252  /  [357] D = #A0662

                                        ;CODES:         N:C = 1111 (NO CHANGE)

                                        ;SYNC:          B05J2 (-) T = 2.6 USEC

                                        ;KEY SIG:       K3-6 MARK L  /  K5-5 BC01 H

051526  012700  000662                  T0662:  MOV     #0662,R0                ;LOAD R0 WITH TEST NO.
051532  013701  051556                          MOV     @#I0662,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
051536  010604                                  MOV     SP,R4           ;SAVE SP
051540  012703  125252                          MOV     #125252,R3      ;[R5] SHOULD BE 125252
051544  012705  051602                  R0662:  MOV     #A0662,R5               ;MARK GOES TO A0662 VIA [R5]
051550  010337  051570                          MOV     R3,@#B0662      ;INITIALIZE WORD LOADED INTO R5
051554  000277                                  SCC                     ;N:C=1111

051556  006404                          I0662:  MARK+4                  ;TEST THE MARK

051560  010406                                  MOV     R4,SP           ;RESET SP
051562  104005                          E10662: ERROR5                  ;MARK FAILED TO EXECUTE
051564  051544                                  R0662                   ;ERROR LOOP RETURN ADDRESS

051566  000435                                  BR      00662           ;GO TO SCOPE EXIT

051570  125252                          B0662:  125252                  ;THIS WORD SHOULD GET LOADED INTO R5

051572  010406                                  MOV     R4,SP           ;RESET SP
051574  104005                          E20662: ERROR5                  ;MARK FAILED TO LOAD RC FROM [R5]
051576  051544                                  R0662                   ;ERROR LOOP RETURN ADDRESS

051600  000430                                  BR      00662           ;GO TO SCOPE EXIT

051602  100003                          A0662:  BPL     D0662           ;N:C=1111?
051604  001002                                  BNE     D0662
051606  102001                                  BVC     D0662
051610  103405                                  BCS     C0662

051612  013702  177776                  D0662:  MOV     @#PSW,R2        ;SAVE FLAGS IN R2
051616  010406                                  MOV     R4,SP           ;RESET SP
051620  104006                          E30662: ERROR6                  ;MSRK SET A FLAG -[PSW] IN R2
051622  051544                                  R0662                   ;ERROR LOOP RETURN ADDRESS

051624  020627  051572                  C0662:  CMP     SP,#B0662+2     ;DID MARK RESET SP?
051630  001405                                  BEQ     F0662           ;BR IF YES
051632  010602                                  MOV     SP,R2           ;PUT BAD SP IN R2
051634  010406                                  MOV     R4,SP           ;RESET SP
```

```
051636  104005          E40662: ERROR5                  ;MARK FAILED TO RESET SP -[R2]=SP WAS
051640  051544                  R0662                   ;ERROR LOOP RETURN ADDRESS

051642  000407                  BR      00662           ;GO TO SCOPE EXIT

051644  020503          F0662:  CMP     R5,R3           ;DID MARK RESTORE OLD R5
051646  001404                  BEQ     G0662           ;BR IF YES

051650  010502                  MOV     R5,R2           ;[R2]=WAS R5
051652  010406                  MOV     R4,SP           ;RESET SP
051654  104007          E50662: ERROR7                  ;MARK FAILED TO RESET R5
051656  051544                  R0662                   ;ERROR LOOP RETURN

051660  010406          G0662:  MOV     R4,SP           ;RESET SP

051662  000004          00662:  SCOPE                   ;CALL THE SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0663 BASIC KW11-L RESPONSE TEST
                                ; ***************************************************************

051664  012700  000663          T0663:  MOV     #0663,R0                ;LOAD R0 WITH TEST NO.
051670  013701  051722                  MOV     @#I0663,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
051674  005737  066636                  TST     @#OPTION        ;IS THE KW11 INSTALLED ??
051700  100023                          BPL     00663           ;BR IF NOT - SKIP THIS TEST
051702  010605                          MOV     SP,R5           ;SAVE SP
051704  012702  177546                  MOV     #LKCSR,R2       ;[R2] = LINE CLOCK ADDRESS
051710  010506          R0663:  MOV     R5,SP           ;RESET SP FOR ERROR LOOP
051712  012737  051726  000004          MOV     #A0663,@#4      ;GO TO A0663 IF BUS TIMEOUT
051720  000257                          CCC                     ;SCOPE SYNC

051722  005712          I0663:  TST     (R2)            ;REFERENCE LKCSR ADDR

051724  000405                          BR      B0663           ;GO TO EXIT

051726  012737  065160  000004  A0663:  MOV     #BERR,@#4       ;RESTORE TIMEOUT VECTOR
051734  104006          E0663:  ERROR6                          ;LKCSR FAILED TO RESPOND
051736  051710                          R0663                   ;ERROR LOOP RETURN ADDRESS

051740  010506          B0663:  MOV     R5,SP           ;RESET SP
051742  012737  065160  000004          MOV     #BERR,@#4       ;RESTORE TIMEOUT VECTOR

051750  000004          00663:  SCOPE                           ;CALL THE SCOPE LOOP UTILITY
```

```
                                ; ***********************************************************************
                                        .SBTTL T0664 KW11-L TEST - LKCSR BIT 7 SET
                                ; ***********************************************************************

051752  012700  000664          T0664:  MOV     #0664,R0                ;LOAD R0 WITH TEST NO.
051756  013701  052002                  MOV     @#I0664,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
051762  005737  066636                  TST     @#OPTION        ;IS THE KW11-L INSTALLED ??
051766  100012                          BPL     00664           ;BR IF NOT - SKIP THIS TEST
051770  012702  177546                  MOV     #LKCSR,R2       ;DEST ADDR = 177546
051774  012704  000200                  MOV     #200,R4         ;[LKCSR] S / B = 200
052000  000257                  R0664:  CCC                     ;SCOPE SYNC

052002  030412                  I0664:  BIT     R4,(R2)         ;TEST BIT 7 IN LKCSR

052004  001003                          BNE     00664           ;BR IF IT'S SET

052006  011203                          MOV     (R2),R3         ;GET WAS DATA
052010  104000                  E0664:  ERROR                   ;BIT 7 NOT SET IN LKCSR
052012  052000                          R0664                   ;ERROR LOOP RETURN ADDRESS

052014  000004                  00664:  SCOPE                   ;CALL THE SCOPE LOOP UTILITY
```

```
                                        ; ***********************************************************************
                                                .SBTTL T0665 KW11-L TEST - LKCSR BIT 6 CLEAR
                                        ; ***********************************************************************

052016  012700  000665          T0665:  MOV     #0665,R0                ;LOAD R0 WITH TEST NO.
052022  013701  052046                  MOV     @#I0665,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
052026  005737  066636                  TST     @#OPTION        ;IS THE KW11-L INSTALLED ??
052032  100013                          BPL     00665           ;BR IF NOT - SKIP THIS TEST
052034  012702  177546                  MOV     #LKCSR,R2       ;R2 POINTS TO LKCSR
052040  012704  000200                  MOV     #200,R4         ;[LKCSR] S / B = 200
052044  000257                  R0665:  CCC                     ;SCOPE SYNC

052046  032712  000100          I0665:  BIT     #100,(R2)       ;TEST BIT 6 IN LKCSR

052052  001403                          BEQ     00665           ;BR IF CLEAR

052054  011203                          MOV     (R2),R3         ;GET WAS DATA
052056  104000                  E0665:  ERROR                   ;BIT 6 (INTR. ENAB.) IN LKCSR WAS SET
052060  052044                          R0665                   ;ERROR LOOP RETURN ADDRESS

052062  000004                  00665:  SCOPE                   ;CALL THE SCOPE LOOP UTILITY
```

```
                                        ; *****************************************************************
                                                .SBTTL T0666 KW11-L TEST - LKCSR BIT 6 SET
                                        ; *****************************************************************

052064  012700  000666          T0666:  MOV     #0666,R0                ;LOAD R0 WITH TEST NO.
052070  013701  052142                  MOV     @#I0666,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
052074  005737  066636                  TST     @#OPTION        ;IS THE KW11 INSTALLED ??
052100  100037                          BPL     00666           ;BR IF NOT - SKIP THIS TEST
052102  010605                          MOV     SP,R5           ;SAVE SP
052104  012702  177546                  MOV     #LKCSR,R2       ;R2 POINTS TO LKCSR
052110  012704  000300                  MOV     #300,R4         ;[LKCSR] S / B = 300
052114  012737  052160  000100  R0666:  MOV     #A0666,@#100    ;SET UP LCLK VECTOR IN CASE LOGIC
052122  012737  000340  000102          MOV     #340,@#102      ;FAULT CAUSES ATL INTERRUPT
052130  010506                          MOV     R5,SP           ;RESET SP FOR ERROR LOOP
052132  012737  000340  177776          MOV     #340,@#PSW      ;SET PRIORITY TO LEVEL 7
052140  000257                          CCC                     ;SCOPE SYNC

052142  052712  000100          I0666:  BIS     #100,(R2)       ;SET BIT 6 IN LKCSR

052146  020412                          CMP     R4,(R2)         ;RESULT CORRECT?
052150  001403                          BEQ     A0666           ;BR IF YES

052152  011203                          MOV     (R2),R3         ;GET WAS DATA
052154  104000                  E10666: ERROR                   ;BIT 6 FAILED TO SET IN LKCSR
052156  052114                          R0666                   ;ERROR LOOP RETURN ADDRESS


052160  042737  000102  000100  A0666:  BIC     #102,@#100      ;RESTORE TRAP CATCHER IN KW11-L VECTOR
052166  005037  000102                  CLR     @#102
052172  042712  000100                  BIC     #100,(R2)       ;TURN OF KW11-L INTR. ENAB.
052176  010506                          MOV     R5,SP           ;RESET SP

052200  000004                  00666:  SCOPE                   ;CALL THE SCOPE LOOP UTILITY
```

```
                                        ; *****************************************************************
                                                .SBTTL T0667 KW11-L BASIC INTERRUPT TEST
                                        ; *****************************************************************


052202  012700  000667          T0667:  MOV     #0667,R0                ;LOAD R0 WITH TEST NO.
052206  013701  052256                  MOV     @#I0667,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
052212  005737  066636                  TST     @#OPTION        ;IS THE KW11-L INSTALLED ??
052216  100041                          BPL     00667           ;BR IF NOT - SKIP THIS TEST
052220  010605                          MOV     SP,R5           ;SAVE SP
052222  012702  177546                  MOV     #LKCSR,R2       ;R2 POINTS TO LKCSR
052226  010506                  R0667:  MOV     R5,SP           ;RESET SP FOR ERROR LOOP
052230  005004                          CLR     R4              ;INITIALIZE TIMER
052232  012737  052276  000100          MOV     #A0667,@#100    ;SET UP LINE CLOCK VECTOR TO TO
052240  012737  000340  000102          MOV     #340,@#102      ;TO A0667 WITH PROCESSOR PRIORITY = 7
052246  005012                          CLR     (R2)            ;CLEAR LKCSR
052250  005037  177776                  CLR     @#PSW           ;SET PRIORITY TO LEVEL 000
052254  000257                          CCC                     ;SCOPE SYNC

052256  052712  000100          I0667:  BIS     #100,(R2)       ;ENABLE LINE CLK INTERRUPT

052262  005304                          DEC     R4              ;WAIT FOR INTR - REPORT ERROR IF
052264  001376                          BNE     .-2             ;R4 GOES TO 000000

052266  042712  000100                  BIC     #100,(R2)       ;TURN OFF INTR. ENAB.
052272  104006                  E0667:  ERROR6                  ;KW11-L FAILED TO INTERRUPT
052274  052226                          R0667                   ;ERROR LOOP RETURN ADDRESS

052276  042712  000100          A0667:  BIC     #100,(R2)       ;TURN OFF INTR. ENAB.
052302  012737  000102  000100          MOV     #102,@#100      ;RESTORE TRAP CATCHER IN KW11-L VECTOR
052310  005037  000102                  CLR     @#102
052314  010506                          MOV     R5,SP           ;RESET SP
052316  005037  177776                  CLR     @#PSW           ;RESET PRIORITY TO LEVEL 0

052322  000004                  00667:  SCOPE                   ;CALL THE SCOPE LOOP UTILITY
```

```
                                        ; ***************************************************************
                                                .SBTTL T0670 RESET TEST - <N:C> = 1111
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [127,025,040,043,016] FC 1,6

                                        ;ACT BUTS:      37[004]100,127 / 02[025]042,043

                                        ;EXEC:          [025] BUT02 TRIGGERS RESET LOGIC ON K5-8

                                        ;CODES:         N:C = 1111 (NO CHANGE)

                                        ;SYNC:          B05J2 (-) T = 80 MILLISEC

                                        ;KEY SIG:       K3-6 RESET L  /  K3-6 HALT+RESET L  /  K5-3 BUT02 H  /  K5-8 RESET RESTA
                                                        ;K5-8 INIT*RESET H  /  K5-8 BUS INIT L  /  K5-8 P ENDRESET L  /
                                                        ;  K2-8 CLKOFF(1) H


052324  012700  000670          T0670:  MOV     #0670,R0                ;LOAD R0 WITH TEST NO.
052330  013701  052362                  MOV     @#I0670,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
052334  012737  000001  066664          MOV     #1,@#ITCNT      ;NO ITERATIONS ON THIS TEST
052342  012702  177564                  MOV     #XCSR,R2        ;R2 POINTS TO DL11 XCSR
052346  012737  000340  177776  R0670:  MOV     #340,@#PSW      ;MAKE PRTY. BITS ALL 1'S
052354  052712  000004                  BIS     #4,(R2)         ;SET THE DL11 MAINT. BIT
052360  000277                          SCC                     ;N:C = 1111

052362  000005                  I0670:  RESET                   ;TEST THE RESET - IT SHOULD CLEAR THE DL11 MAINT BIT

052364  013705  177776                  MOV     @#PSW,R5        ;SAVE THE PSW
052370  032712  000004                  BIT     #4,(R2)         ;DID MAINT. BIT CLEAR ??
052374  001404                          BEQ     A0670           ;BR IF YES

052376  042712  000004                  BIC     #4,(R2)         ;MAKE SURE TO TURN OFF MAINT. BIT
052402  104006                  E10670: ERROR6                  ;RESET FAILED TO CLEAR MAINT BIT
052404  052346                          R0670                   ;ERROR LOOP RETURN ADDRESS

052406  022705  000357          A0670:  CMP     #357,R5         ;DID RESET ALTER THE PSW ??
052412  001405                          BEQ     B0670           ;BR IF NOT

052414  012704  000357                  MOV     #357,R4         ;[R4] = S/B PSW
052420  010503                          MOV     R5,R3           ;[R3] = WAS PSW
052422  104000                  E20670: ERROR                   ;RESET ALTERED THE PSW
052424  052346                          R0670                   ;ERROR LOOP RETURN ADDRESS

052426  005037  177776          B0670:  CLR     @#PSW           ;CLEAR OUT THE PSW
052432  042712  000004                  BIC     #4,(R2)         ;MAKE SURE MAINT BIT IS OFF

052436  000004                  00670:  SCOPE                   ;CALL THE SCOPE LOOP UTILITY
```

```
                                        ; ***************************************************************
                                                .SBTTL T0671 RESET TEST - <N:C> = 0000
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [127,025,040,043,016] FC 1,6

                                        ;ACT BUTS:      37[004]100,127 / 02[025]042,043

                                        ;EXEC:          [025] BUT02 TRIGGERS RESET LOGIC ON K5-8

                                        ;CODES:         N:C = 0000 (NO CHANGE)

                                        ;SYNC:          B05J2 (-) T = 80 MILLISEC

                                        ;KEY SIG:       K3-6 RESET L  /  K3-6 HALT+RESET L  /  K5-3 BUT02 H  /  K5-8 RESET RESTA
                                                        ;K5-8 INIT*RESET H  /  K5-8 BUS INIT L  /  K5-8 P ENDRESET L  /
                                                        ;  K2-8 CLKOFF (1) H

052440  012700  000671          T0671:  MOV     #0671,R0                ;LOAD R0 WITH TEST NO.
052444  013701  052476                  MOV     @#I0671,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
052450  012737  000001  066664          MOV     #1,@#ITCNT      ;NO ITERATIONS ON THIS TEST
052456  012702  177564                  MOV     #XCSR,R2        ;R2 POINTS TO DL11 XCSR
052462  012737  000000  177776  R0671:  MOV     #0,@#PSW        ;MAKE PRTY. BITS ALL 0'S
052470  052712  000004                  BIS     #4,(R2)         ;SET THE DL11 MAINT. BIT
052474  000257                          CCC                     ;N:C = 0000

052476  000005                  I0671:  RESET                   ;TEST THE RESET - IT SHOULD CLEAR THE DL11 MAINT BIT

052500  013705  177776                  MOV     @#PSW,R5        ;SAVE THE PSW
052504  032712  000004                  BIT     #4,(R2)         ;DID MAINT. BIT CLEAR ??
052510  001404                          BEQ     A0671           ;BR IF YES

052512  042712  000004                  BIC     #4,(R2)         ;MAKE SURE TO TURN OFF MAINT. BIT
052516  104006                  E10671: ERROR6                  ;RESET FAILED TO CLEAR MAINT BIT
052520  052462                          R0671                   ;ERROR LOOP RETURN ADDRESS

052522  022705  000000          A0671:  CMP     #0,R5           ;DID RESET ALTER THE PSW ??
052526  001405                          BEQ     B0671           ;BR IF NOT

052530  012704  000357                  MOV     #357,R4         ;[R4] = S/B PSW
052534  010503                          MOV     R5,R3           ;[R3] = WAS PSW
052536  104000                  E20671: ERROR                   ;RESET ALTERED THE PSW
052540  052462                          R0671                   ;ERROR LOOP RETURN ADDRESS

052542  005037  177776          B0671:  CLR     @#PSW           ;CLEAR OUT THE PSW
052546  042712  000004                  BIC     #4,(R2)         ;MAKE SURE MAINT BIT IS OFF

052552  000004                  00671:  SCOPE                   ;CALL THE SCOPE LOOP UTILITY
```

```
                                        ; ***************************************************************
                                                .SBTTL T0672 WAIT INSTRUCTION TEST - [PSW] = 151
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [114,015,012,020,021:
                                        ;                       INTR.   014,022,023,007,[TRAP MICROROUTINE]
                                        ;                   NO  INTR.   017,015,012,020,021,017 ETC. FC 1,10,6,10

                                        ;ACT BUTS:      37[004]100,114  /  26[114]010,012  /  25[020]014,014  /  07[022]006,007

                                        ;EXEC           BUT 25 IN LOC. 020 SHOULD CAUSE EXIT FROM WAIT LOOP

                                        ;CODES:         N / A    /      N:C=1001 (NO CHANGE)

                                        ;SYNC:          B05J2   (-)     T=2.24 USEC + INTR. WAIT TIME

                                        ;KEY SIG:       K4-5 BRPTR(1) L  /  K3-6 WAIT L  /  K4-6 BRQ H  /  K5-4 -BRSV(0) H

052554  012700  000672          T0672:  MOV     #0672,R0                ;LOAD R0 WITH TEST NO.
052560  013701  052642                  MOV     @#I0672,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
052564  010605                          MOV     SP,R5           ;SAVE THE SP
052566  012702  177564                  MOV     #XCSR,R2        ;R2 POINT TO DL11 XCSR
052572  012737  052662  000064  R0672:  MOV     #A0672,@#64     ;GO TO A0672 ON DL11 INTR.
052600  012737  000200  000066          MOV     #200,@#66       ;AT LEVEL 4
052606  010506                          MOV     R5,SP           ;RESET SP FOR ERROR LOOP
052610  005012                          CLR     (R2)            ;INIT DL11 XCSR
052612  005003                          CLR     R3              ;INIT TIMER

052614  105712                  1$:     TSTB    (R2)            ;DL11 XMIT READY SET ??
052616  100403                          BMI     2$              ;BR IF YES
052620  005303                          DEC     R3              ;COUNT THE TIMER
052622  001374                          BNE     1$              ;BR IF NO TIMEOUT
052624  000441                          BR      E40672          ;GO REPORT TIMEOUT

052626  012737  000140  177776  2$:     MOV     #140,@#PSW      ;SET PSW PRTY BITS TO LEVEL 3
052634  000277                          SCC                     ;N:C=1111
052636  152712  000100                  BISB    #100,(R2)       ;ENAB. DL11 INTR - N:C=1001

052642  000001                  I0672:  WAIT                    ;TEST THE WAIT-GO TO A0672 ON INTR

052644  012737  000340  177776          MOV     #340,@#PSW      ;LOCK OUT INTR
052652  005012                          CLR     (R2)            ;TURN OFF DL11 INTR ENAB
052654  104006                  E10672: ERROR6                  ;WAIT FAILED TO EXECUTE PROPERLY
052656  052572                          R0672                   ;ERROR LOOP RETURN ADDRESSS
052660  000425                          BR      C0672           ;GO EXIT THIS TEST

052662  042712  000100          A0672:  BIC     #100,(R2)       ;TURN OFF DL11 INTR ENAB
052666  022716  052644                  CMP     #I0672+2,(SP)   ;DID WAIT GET FETCHED ??
052672  001403                          BEQ     B0672           ;BR IF YES

052674  104006                  E20672: ERROR6                  ;WAIT NOT FETCHED PROPERLY
052676  052572                          R0672                   ;ERROR LOOP RETURN ADDRESS
052700  000415                          BR      C0672           ;GO EXIT THE TEST
```

```
052702  022766  000151  000002  B0672:  CMP     #151,2(SP)      ;DID "WAIT" ALTER THE PSW ??
052710  001411                          BEQ     C0672           ;BR IF YES

052712  012704  000151                  MOV     #151,R4         ;[R4] = S/B PSW
052716  016603  000002                  MOV     2(SP),R3        ;[R3] = WAS PSW
052722  104000                  E30672: ERROR                   ;"WAIT" ALTERED THE PSW
052724  052572                          R0672                   ;ERROR LOOP RETURN ADDRESS
052726  000402                          BR      C0672           ;GOT TO EXIT TEST

052730  104006                  E40672: ERROR6                  ;DL11 FAILED TO SET READY ON TIME
052732  052572                          R0672                   ;ERROR LOOP RETURN ADDRESS

052734  010506                  C0672:  MOV     R5,SP           ;RESET THE SP
052736  005037  177776                  CLR     @#PSW           ;CLEAR OUT THE PSW
052742  005012                          CLR     (R2)            ;TURN OFF DL11 INTR.
052744  012737  000066  000064          MOV     #66,@#64        ;RESTORE DL11 VECTOR WITH TRAPCATCHER
052752  005037  000066                  CLR     @#66

052756  000004                  D0672:  SCOPE                   ;CALL THE SCOPE LOOP UTILITY
```

```
                                        ; ***************************************************************
                                                .SBTTL T0673 WAIT INSTRUCTION TEST - [PSW] = 010
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [114,015,012,020,021:
                                        ;                       INTR.   014,022,023,007,[TRAP MICROROUTINE]
                                        ;                   NO  INTR.   017,015,012,020,021,017 ETC. FC 1,10,6,10

                                        ;ACT BUTS:      37[004]100,114  /  26[114]010,012  /  25[020]014,014  /  07[022]006,007

                                        ;EXEC           BUT 25 IN LOC. 020 SHOULD CAUSE EXIT FROM WAIT LOOP

                                        ;CODES:         N / A    /      N:C=1000 (NO CHANGE)

                                        ;SYNC:          B05J2   (-)     T=2.24 USEC + INTR. WAIT TIME

                                        ;KEY SIG:       K4-5 BRPTR(1) L  /  K3-6 WAIT L  /  K4-6 BRQ H  /  K5-4 -BRSV(0) H

052760  012700  000673          T0673:  MOV     #0673,R0                ;LOAD R0 WITH TEST NO.
052764  013701  053046                  MOV     @#I0673,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
052770  010605                          MOV     SP,R5           ;SAVE THE SP
052772  012702  177564                  MOV     #XCSR,R2        ;R2 POINT TO DL11 XCSR
052776  012737  053066  000064  R0673:  MOV     #A0673,@#64     ;GO TO A0673 ON DL11 INTR.
053004  012737  000200  000066          MOV     #200,@#66       ;AT LEVEL 4
053012  010506                          MOV     R5,SP           ;RESET SP FOR ERROR LOOP
053014  005012                          CLR     (R2)            ;INIT DL11 XCSR
053016  005003                          CLR     R3              ;INIT TIMER

053020  105712                  1$:     TSTB    (R2)            ;DL11 XMIT READY SET ??
053022  100403                          BMI     2$              ;BR IF YES
053024  005303                          DEC     R3              ;COUNT THE TIMER
053026  001374                          BNE     1$              ;BR IF NO TIMEOUT
053030  000441                          BR      E40673          ;GO REPORT TIMEOUT

053032  012737  000000  177776  2$:     MOV     #0,@#PSW        ;SET PSW PRTY BITS TO LEVEL 0
053040  000257                          CCC                     ;N:C=0000
053042  152712  000100                  BISB    #100,(R2)       ;ENAB. DL11 INTR - N:C=1000

053046  000001                  I0673:  WAIT                    ;TEST THE WAIT-GO TO A0673 ON INTR

053050  012737  000340  177776          MOV     #340,@#PSW      ;LOCK OUT INTR
053056  005012                          CLR     (R2)            ;TURN OFF DL11 INTR ENAB
053060  104006                  E10673: ERROR6                  ;WAIT FAILED TO EXECUTE PROPERLY
053062  052776                          R0673                   ;ERROR LOOP RETURN ADDRESSS
053064  000425                          BR      C0673           ;GO EXIT THIS TEST

053066  042712  000100          A0673:  BIC     #100,(R2)       ;TURN OFF DL11 INTR ENAB
053072  022716  053050                  CMP     #I0673+2,(SP)   ;DID WAIT GET FETCHED ??
053076  001403                          BEQ     B0673           ;BR IF YES

053100  104006                  E20673: ERROR6                  ;WAIT NOT FETCHED PROPERLY
053102  052776                          R0673                   ;ERROR LOOP RETURN ADDRESS
053104  000415                          BR      C0673           ;GO EXIT THE TEST
```

```
053106  022766  000010  000002  B0673:  CMP     #010,2(SP)      ;DID "WAIT" ALTER THE PSW ??
053114  001411                          BEQ     C0673           ;BR IF YES

053116  012704  000010                  MOV     #010,R4         ;[R4] = S/B PSW
053122  016603  000002                  MOV     2(SP),R3        ;[R3] = WAS PSW
053126  104000                  E30673: ERROR                   ;"WAIT" ALTERED THE PSW
053130  052776                          R0673                   ;ERROR LOOP RETURN ADDRESS
053132  000402                          BR      C0673           ;GOT TO EXIT TEST

053134  104006                  E40673: ERROR6                  ;DL11 FAILED TO SET READY ON TIME
053136  052776                          R0673                   ;ERROR LOOP RETURN ADDRESS

053140  010506                  C0673:  MOV     R5,SP           ;RESET THE SP
053142  005037  177776                  CLR     @#PSW           ;CLEAR OUT THE PSW
053146  005012                          CLR     (R2)            ;TURN OFF DL11 INTR.
053150  012737  000066  000064          MOV     #66,@#64        ;RESTORE DL11 VECTOR WITH TRAPCATCHER
053156  005037  000066                  CLR     @#66

053162  000004                  00673:  SCOPE                   ;CALL THE SCOPE LOOP UTILITY
```

```
                                        ; ***********************************************************************
                                                .SBTTL T0674 BR PRIORITY ARBITRATION TEST - LEVEL 0 USING KW11-L
                                        ; ***********************************************************************

053164  012700  000674          T0674:  MOV     #0674,R0                ;LOAD R0 WITH TEST NO.
053170  013701  053240                  MOV     @#T0674,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
053174  005737  066636                  TST     @#OPTION        ;IS KW11-L INSTALLED ??
053200  100041                          BPL     00674           ;BR IF NOT - SKIP THIS TEST
053202  010605                          MOV     SP,R5           ;SAVE THE SP
053204  012702  177546                  MOV     #LKCSR,R2       ;R2 POINTS TO LCLK
053210  012737  053260  000100          MOV     #A0674,@#100    ;GO TO A0674 ON LCLK INTR
053216  012737  000340  000102          MOV     #340,@#102      ;LOCK OUT INTRS IN LCLK SERV.
053224  010506                  R0674:  MOV     R5,SP           ;RESET SP FOR ERROR LOOP
053226  005004                          CLR     R4              ;INIT R4 AS TIMER
053230  012737  000000  177776          MOV     #0,@#PSW        ;SET CPU PRTY TO LEVEL 000
053236  000257                          CCC                     ;SCOPE SYNC

053240  052712  000100          I0674:  BIS     #100,(R2)       ;ENABLE LCLK INTR

053244  005304                          DEC     R4              ;COUNT TIMER
053246  001376                          BNE     .-2             ;LCLK SHOULD INTR BEFORE TIMEOUT

053250  042712  000100                  BIC     #100,(R2)       ;TURN OFF INTR ENAB.
053254  104006                  E0674:  ERROR6                  ;KW11-L FAILED TO INTR AT LEVEL 0
053256  053224                          R0674                   ;ERROR LOOP RETURN ADDRESS

053260  042712  000100          A0674:  BIC     #100,(R2)       ;TURN OFF INTR. ENABLE
053264  012737  000102  000100          MOV     #102,@#100      ;RESTORE TRAP CATCHER IN THE VECTOR
053272  005037  000102                  CLR     @#102
053276  010506                          MOV     R5,SP           ;RESET THE SP
053300  005037  177776                  CLR     @#PSW           ;SET CPU PRIORITY BACK TO LEVEL 0

053304  000004                  00674:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***************************************************************
                                                .SBTTL T0675 BR PRIORITY ARBITRATION TEST - LEVEL 1 USING KW11-L
                                        ; ***************************************************************

053306  012700  000675          T0675:  MOV     #0675,R0                ;LOAD R0 WITH TEST NO.
053312  013701  053362                  MOV     @#I0675,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
053316  005737  066636                  TST     @#OPTION        ;IS KW11-L INSTALLED ??
053322  100041                          BPL     00675           ;BR IF NOT - SKIP THIS TEST
053324  010605                          MOV     SP,R5           ;SAVE THE SP
053326  012702  177546                  MOV     #LKCSR,R2       ;R2 POINTS TO KW11-L CSR
053332  012737  053402  000100          MOV     #A0675,@#100    ;IF INTR OCCURS - GO TO A0675
053340  012737  000340  000102          MOV     #340,@#102      ;WITH CPU PRIORITY AT LEVEL 7
053346  010506                  R0675:  MOV     R5,SP           ;RESET SP FOR ERROR LOOPING
053350  005004                          CLR     R4              ;INITIALIZE R4 AS TIMER
053352  012737  000040  177776          MOV     #40,@#PSW       ;SET CPU PRIORITY TO LEVEL 1
053360  000257                          CCC                     ;SCOPE SYNC

053362  052712  000100          I0675:  BIS     #100,(R2)       ;ENABLE KW11-L INTERRUPTS

053366  005304                          DEC     R4              ;COUNT THE TIMER - LCLK SHOULD PREVENT
053370  001376                          BNE     .-2             ;TIMER FROM GETTING BACK TO 000000

053372  042712  000100                  BIC     #100,(R2)       ;TURN OFF THE INTERRUPT ENABLE
053376  104006                  E0675:  ERROR6                  ;KW11-L FAILED TO INTR AT LEVEL 1
053400  053346                          R0675                   ;ERROR LOOP RETURN ADDRESS

053402  042712  000100          A0675:  BIC     #100,(R2)       ;TURN OFF INTR. ENABLE
053406  012737  000102  000100          MOV     #102,@#100      ;RESTORE TRAP CATCHER IN THE VECTOR
053414  005037  000102                  CLR     @#102
053420  010506                          MOV     R5,SP           ;RESET THE SP
053422  005037  177776                  CLR     @#PSW           ;SET CPU PRIORITY BACK TO LEVEL 0

053426  000004                  00675:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***************************************************************
                                                .SBTTL T0676 BR PRIORITY ARBITRATION TEST - LEVEL 2 USING KW11-L
                                        ; ***************************************************************

053430  012700  000676          T0676:  MOV     #0676,R0                ;LOAD R0 WITH TEST NO.
053434  013701  053504                  MOV     @#I0676,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
053440  005737  066636                  TST     @#OPTION        ;IS KW11-L INSTALLED ??
053444  100041                          BPL     00676           ;BR IF NOT - SKIP THIS TEST
053446  010605                          MOV     SP,R5           ;SAVE THE SP
053450  012702  177546                  MOV     #LKCSR,R2       ;R2 POINTS TO KW11-L CSR
053454  012737  053524  000100          MOV     #A0676,@#100    ;IF INTR OCCURS - GO TO A0676
053462  012737  000340  000102          MOV     #340,@#102      ;WITH CPU PRIORITY AT LEVEL 7
053470  010506                  R0676:  MOV     R5,SP           ;RESET SP FOR ERROR LOOPING
053472  005004                          CLR     R4              ;INITIALIZE R4 AS TIMER
053474  012737  000100  177776          MOV     #100,@#PSW      ;SET CPU PRIORITY TO LEVEL 2
053502  000257                          CCC                     ;SCOPE SYNC

053504  052712  000100          I0676:  BIS     #100,(R2)       ;ENABLE KW11-L INTERRUPTS

053510  005304                          DEC     R4              ;COUNT THE TIMER - LCLK SHOULD PREVENT
053512  001376                          BNE     .-2             ;TIMER FROM GETTING BACK TO 000000

053514  042712  000100                  BIC     #100,(R2)       ;TURN OFF THE INTERRUPT ENABLE
053520  104006                  E0676:  ERROR6                  ;KW11-L FAILED TO INTR AT LEVEL 2
053522  053470                          R0676                   ;ERROR LOOP RETURN ADDRESS

053524  042712  000100          A0676:  BIC     #100,(R2)       ;TURN OFF INTR. ENABLE
053530  012737  000102  000100          MOV     #102,@#100      ;RESTORE TRAP CATCHER IN THE VECTOR
053536  005037  000102                  CLR     @#102
053542  010506                          MOV     R5,SP           ;RESET THE SP
053544  005037  177776                  CLR     @#PSW           ;SET CPU PRIORITY BACK TO LEVEL 0

053550  000004                  00676:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; *****************************************************************
                                                .SBTTL T0677 BR PRIORITY ARBITRATION TEST - LEVEL 3 USING KW11-L
                                        ; *****************************************************************

053552  012700  000677          T0677:  MOV     #0677,R0                ;LOAD R0 WITH TEST NO.
053556  013701  053626                  MOV     @#I0677,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
053562  005737  066636                  TST     @#OPTION        ;IS KW11-L INSTALLED ??
053566  100041                          BPL     00677           ;BR IF NOT - SKIP THIS TEST
053570  010605                          MOV     SP,R5           ;SAVE THE SP
053572  012702  177546                  MOV     #LKCSR,R2       ;R2 POINTS TO KW11-L CSR
053576  012737  053646  000100          MOV     #A0677,@#100    ;IF INTR OCCURS - GO TO A0677
053604  012737  000340  000102          MOV     #340,@#102      ;WITH CPU PRIORITY AT LEVEL 7
053612  010506                  R0677:  MOV     R5,SP           ;RESET SP FOR ERROR LOOPING
053614  005004                          CLR     R4              ;INITIALIZE R4 AS TIMER
053616  012737  000140  177776          MOV     #140,@#PSW      ;SET CPU PRIORITY TO LEVEL 3
053624  000257                          CCC                     ;SCOPE SYNC

053626  052712  000100          I0677:  BIS     #100,(R2)       ;ENABLE KW11-L INTERRUPTS

053632  005304                          DEC     R4              ;COUNT THE TIMER - LCLK SHOULD PREVENT
053634  001376                          BNE     .-2             ;TIMER FROM GETTING BACK TO 000000

053636  042712  000100                  BIC     #100,(R2)       ;TURN OFF THE INTERRUPT ENABLE
053642  104006                  E0677:  ERROR6                  ;KW11-L FAILED TO INTR AT LEVEL 3
053644  053612                          R0677                   ;ERROR LOOP RETURN ADDRESS

053646  042712  000100          A0677:  BIC     #100,(R2)       ;TURN OFF INTR. ENABLE
053652  012737  000102  000100          MOV     #102,@#100      ;RESTORE TRAP CATCHER IN THE VECTOR
053660  005037  000102                  CLR     @#102
053664  010506                          MOV     R5,SP           ;RESET THE SP
053666  005037  177776                  CLR     @#PSW           ;SET CPU PRIORITY BACK TO LEVEL 0

053672  000004                  00677:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; *****************************************************************
                                                .SBTTL T0700 BR PRIORITY ARBITRATION TEST - LEVEL 4 USING KW11-L
                                        ; *****************************************************************

053674  012700  000700          T0700:  MOV     #0700,R0                ;LOAD R0 WITH TEST NO.
053700  013701  053750                  MOV     @#I0700,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
053704  005737  066636                  TST     @#OPTION        ;IS KW11-L INSTALLED ??
053710  100041                          BPL     00700           ;BR IF NOT - SKIP THIS TEST
053712  010605                          MOV     SP,R5           ;SAVE THE SP
053714  012702  177546                  MOV     #LKCSR,R2       ;R2 POINTS TO KW11-L CSR
053720  012737  053770  000100          MOV     #A0700,@#100    ;IF INTR OCCURS - GO TO A0700
053726  012737  000340  000102          MOV     #340,@#102      ;WITH CPU PRIORITY AT LEVEL 7
053734  010506                  R0700:  MOV     R5,SP           ;RESET SP FOR ERROR LOOPING
053736  005004                          CLR     R4              ;INITIALIZE R4 AS TIMER
053740  012737  000200  177776          MOV     #200,@#PSW      ;SET CPU PRIORITY TO LEVEL 4
053746  000257                          CCC                     ;SCOPE SYNC

053750  052712  000100          I0700:  BIS     #100,(R2)       ;ENABLE KW11-L INTERRUPTS

053754  005304                          DEC     R4              ;COUNT THE TIMER - LCLK SHOULD PREVENT
053756  001376                          BNE     .-2             ;TIMER FROM GETTING BACK TO 000000

053760  042712  000100                  BIC     #100,(R2)       ;TURN OFF THE INTERRUPT ENABLE
053764  104006                  E0700:  ERROR6                  ;KW11-L FAILED TO INTR AT LEVEL 4
053766  053734                          R0700                   ;ERROR LOOP RETURN ADDRESS

053770  042712  000100          A0700:  BIC     #100,(R2)       ;TURN OFF INTR. ENABLE
053774  012737  000102  000100          MOV     #102,@#100      ;RESTORE TRAP CATCHER IN THE VECTOR
054002  005037  000102                  CLR     @#102
054006  010506                          MOV     R5,SP           ;RESET THE SP
054010  005037  177776                  CLR     @#PSW           ;SET CPU PRIORITY BACK TO LEVEL 0

054014  000004                  00700:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***************************************************************
                                                .SBTTL T0701 BR PRIORITY ARBITRATION TEST - LEVEL 5 USING KW11-L
                                        ; ***************************************************************

054016  012700  000701          T0701:  MOV     #0701,R0                ;LOAD R0 WITH TEST NO.
054022  013701  054072                  MOV     @#I0701,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
054026  005737  066636                  TST     @#OPTION        ;IS KW11-L INSTALLED ??
054032  100041                          BPL     00701           ;BR IF NOT - SKIP THIS TEST
054034  010605                          MOV     SP,R5           ;SAVE THE SP
054036  012702  177546                  MOV     #LKCSR,R2       ;R2 POINTS TO KW11-L CSR
054042  012737  054112  000100          MOV     #A0701,@#100    ;IF INTR OCCURS - GO TO A0701
054050  012737  000340  000102          MOV     #340,@#102      ;WITH CPU PRIORITY AT LEVEL 7
054056  010506                  R0701:  MOV     R5,SP           ;RESET SP FOR ERROR LOOPING
054060  005004                          CLR     R4              ;INITIALIZE R4 AS TIMER
054062  012737  000240  177776          MOV     #240,@#PSW      ;SET CPU PRIORITY TO LEVEL 5
054070  000257                          CCC                     ;SCOPE SYNC

054072  052712  000100          I0701:  BIS     #100,(R2)       ;ENABLE KW11-L INTERRUPTS

054076  005304                          DEC     R4              ;COUNT THE TIMER - LCLK SHOULD PREVENT
054100  001376                          BNE     .-2             ;TIMER FROM GETTING BACK TO 000000

054102  042712  000100                  BIC     #100,(R2)       ;TURN OFF THE INTERRUPT ENABLE
054106  104005                  E0701:  ERROR6                  ;KW11-L FAILED TO INTR AT LEVEL 5
054110  054056                          R0701                   ;ERROR LOOP RETURN ADDRESS

054112  042712  000100          A0701:  BIC     #100,(R2)       ;TURN OFF INTR. ENABLE
054116  012737  000102  000100          MOV     #102,@#100      ;RESTORE TRAP CATCHER IN THE VECTOR
054124  005037  000102                  CLR     @#102
054130  010506                          MOV     R5,SP           ;RESET THE SP
054132  005037  177776                  CLR     @#PSW           ;SET CPU PRIORITY BACK TO LEVEL 0

054136  000004                  00701:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; *****************************************************************
                                                .SBTTL T0702 BR PRIORITY ARBITRATION TEST - LEVEL 0 USING DL11
                                        ; *****************************************************************

054140  012700  000702          T0702:  MOV     #0702,R0                ;LOAD R0 WITH TEST NO.
054144  013701  054206                  MOV     @#I0702,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
054150  010605                          MOV     SP,R5           ;SAVE THE SP
054152  012702  177564                  MOV     #XCSR,R2        ;R2 POINTS TO DL11 XCSR
054156  012737  054226  000064          MOV     #A0702,@#64     ;IF INTR OCCURS - GO TO A0702
054164  012737  000340  000066          MOV     #340,@#66       ;WITH CPU PRIORITY AT LEVEL 7
054172  010506                  R0702:  MOV     R5,SP           ;RESET SP FOR ERROR LOOPING
054174  005004                          CLR     R4              ;INITIALIZE R4 AS TIMER
054176  012737  000000  177776          MOV     #0,@#PSW        ;SET CPU PRIORITY TO LEVEL 0
054204  000257                          CCC                     ;SCOPE SYNC

054206  052712  000100          I0702:  BIS     #100,(R2)       ;ENABLE DL11 INTERRUPTS

054212  005304                          DEC     R4              ;COUNT THE TIMER - DL11 SHOULD PREVENT
054214  001376                          BNE     .-2             ;TIMER FROM GETTING BACK TO 000000

054216  042712  000100                  BIC     #100,(R2)       ;TURN OFF THE INTERRUPT ENABLE
054222  104006                  E0702:  ERROR6                  ;DL11 FAILED TO INTR AT LEVEL 0
054224  054172                          R0702                   ;ERROR LOOP RETURN ADDRESS

054226  042712  000100          A0702:  BIC     #100,(R2)       ;TURN OFF INTR. ENABLE
054232  012737  000066  000064          MOV     #66,@#64        ;RESTORE TRAP CATCHER IN THE VECTOR
054240  005037  000066                  CLR     @#66
054244  010506                          MOV     R5,SP           ;RESET THE SP
054246  005037  177776                  CLR     @#PSW           ;SET CPU PRIORITY BACK TO LEVEL 0

054252  000004                  00702:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***************************************************************
                                                .SBTTL T0703 BR PRIORITY ARBITRATION TEST - LEVEL 1 USING DL11
                                        ; ***************************************************************

054254  012700  000703          T0703:  MOV     #0703,R0                ;LOAD R0 WITH TEST NO.
054260  013701  054322                  MOV     @#I0703,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
054264  010605                          MOV     SP,R5           ;SAVE THE SP
054266  012702  177564                  MOV     #XCSR,R2        ;R2 POINTS TO DL11 XCSR
054272  012737  054342  000064          MOV     #A0703,@#64     ;IF INTR OCCURS - GO TO A0703
054300  012737  000340  000066          MOV     #340,@#66       ;WITH CPU PRIORITY AT LEVEL 7
054306  010506                  R0703:  MOV     R5,SP           ;RESET SP FOR ERROR LOOPING
054310  005004                          CLR     R4              ;INITIALIZE R4 AS TIMER
054312  012737  000040  177776          MOV     #40,@#PSW       ;SET CPU PRIORITY TO LEVEL 1
054320  000257                          CCC                     ;SCOPE SYNC

054322  052712  000100          I0703:  BIS     #100,(R2)       ;ENABLE DL11 INTERRUPTS

054326  005304                          DEC     R4              ;COUNT THE TIMER - DL11 SHOULD PREVENT
054330  001376                          BNE     .-2             ;TIMER FROM GETTING BACK TO 000000

054332  042712  000100                  BIC     #100,(R2)       ;TURN OFF THE INTERRUPT ENABLE
054336  104006                  E0703:  ERROR6                  ;DL11 FAILED TO INTR AT LEVEL 1
054340  054306                          R0703                   ;ERROR LOOP RETURN ADDRESS

054342  042712  000100          A0703:  BIC     #100,(R2)       ;TURN OFF INTR. ENABLE
054346  012737  000066  000064          MOV     #66,@#64        ;RESTORE TRAP CATCHER IN THE VECTOR
054354  005037  000066                  CLR     @#66
054360  010506                          MOV     R5,SP           ;RESET THE SP
054362  005037  177776                  CLR     @#PSW           ;SET CPU PRIORITY BACK TO LEVEL 0

054366  000004                  00703:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***************************************************************
                                                .SBTTL T0704 BR PRIORITY ARBITRATION TEST - LEVEL 2 USING DL11
                                        ; ***************************************************************

054370  012700  000704          T0704:  MOV     #0704,R0                ;LOAD R0 WITH TEST NO.
054374  013701  054450                  MOV     @#I0704,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
054400  032737  020000  066642          BIT     #20000,@#BPTLOC ;BREAKPOINT HALT SET ??
054406  001401                          BEQ     .+4             ;BR IF NOT
054410  000000                          HALT                    ;BREAK-DEPRESS CONTINUE TO RESTART
054412  010605                          MOV     SP,R5           ;SAVE THE SP
054414  012702  177564                  MOV     #XCSR,R2        ;R2 POINTS TO DL11 CSR
054420  012737  054470  000064          MOV     #A0704,@#64     ;IF INTR OCCURS - GO TO A0704
054426  012737  000340  000066          MOV     #340,@#66       ;WITH CPU PRIORITY AT LEVEL 7
054434  010506                  R0704:  MOV     R5,SP           ;RESET SP FOR ERROR LOOPING
054436  005004                          CLR     R4              ;INITIALIZE R4 AS TIMER
054440  012737  000100  177776          MOV     #100,@#PSW      ;SET CPU PRIORITY TO LEVEL 2
054446  000257                          CCC                     ;SCOPE SYNC

054450  052712  000100          I0704:  BIS     #100,(R2)       ;ENABLE DL11 INTERRUPTS

054454  005304                          DEC     R4              ;COUNT THE TIMER - DL11 SHOULD PREVENT
054456  001376                          BNE     .-2             ;TIMER FROM GETTING BACK TO 000000

054460  042712  000100                  BIC     #100,(R2)       ;TURN OFF THE INTERRUPT ENABLE
054464  104006                  E0704:  ERROR6                  ;DL11 FAILED TO INTR AT LEVEL 2
054466  054434                          R0704                   ;ERROR LOOP RETURN ADDRESS

054470  042712  000100          A0704:  BIC     #100,(R2)       ;TURN OFF INTR. ENABLE
054474  012737  000066  000064          MOV     #66,@#64        ;RESTORE TRAP CATCHER IN THE VECTOR
054502  005037  000066                  CLR     @#66
054506  010506                          MOV     R5,SP           ;RESET THE SP
054510  005037  177776                  CLR     @#PSW           ;SET CPU PRIORITY BACK TO LEVEL 0

054514  000004                  00704:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***************************************************************
                                                .SBTTL T0705 BR PRIORITY ARBITRATION TEST - LEVEL 3 USING DL11
                                        ; ***************************************************************

054516  012700  000705          T0705:  MOV     #0705,R0                ;LOAD R0 WITH TEST NO.
054522  013701  054564                  MOV     @#I0705,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
054526  010605                          MOV     SP,R5           ;SAVE THE SP
054530  012702  177564                  MOV     #XCSR,R2        ;R2 POINTS TO DL11 CSR
054534  012737  054604  000064          MOV     #A0705,@#64     ;IF INTR OCCURS - GO TO A0705
054542  012737  000340  000066          MOV     #340,@#66       ;WITH CPU PRIORITY AT LEVEL 7
054550  010506                  R0705:  MOV     R5,SP           ;RESET SP FOR ERROR LOOPING
054552  005004                          CLR     R4              ;INITIALIZE R4 AS TIMER
054554  012737  000140  177776          MOV     #140,@#PSW      ;SET CPU PRIORITY TO LEVEL 3
054562  000257                          CCC                     ;SCOPE SYNC

054564  052712  000100          I0705:  BIS     #100,(R2)       ;ENABLE DL11 INTERRUPTS

054570  005304                          DEC     R4              ;COUNT THE TIMER - DL11 SHOULD PREVENT
054572  001376                          BNE     .-2             ;TIMER FROM GETTING BACK TO 000000

054574  042712  000100                  BIC     #100,(R2)       ;TURN OFF THE INTERRUPT ENABLE
054600  104006                  E0705:  ERROR6                  ;DL11 FAILED TO INTR AT LEVEL 3
054602  054550                          R0705                   ;ERROR LOOP RETURN ADDRESS

054604  042712  000100          A0705:  BIC     #100,(R2)       ;TURN OFF INTR. ENABLE
054610  012737  000066  000064          MOV     #66,@#64        ;RESTORE TRAP CATCHER IN THE VECTOR
054616  005037  000066                  CLR     @#66
054622  010506                          MOV     R5,SP           ;RESET THE SP
054624  005037  177776                  CLR     @#PSW           ;SET CPU PRIORITY BACK TO LEVEL 0

054630  000004                  00705:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***************************************************************
                                                .SBTTL T0706 BR PRIORITY ARBITRATION TEST - LEVEL 7 USING KW11-L
                                        ; ***************************************************************

054632  012700  000706          T0706:  MOV     #0706,R0                ;LOAD R0 WITH TEST NO.
054636  013701  054706                  MOV     @#T0706,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
054642  005737  066636                  TST     @#OPTION        ;IS KW11-L INSTALLED ??
054646  100042                          BPL     00706           ;BR IF NOT - SKIP THIS TEST
054650  010605                          MOV     SP,R5           ;SAVE THE SP
054652  012702  177546                  MOV     #LKCSR,R2       ;R2 POINTS TO KW11-L CSR
054656  012737  054720  000100          MOV     #A0706,@#100    ;IF INTR OCCURS - GO TO A0706
054664  012737  000340  000102          MOV     #340,@#102      ;WITH CPU PRIORITY AT LEVEL 7
054672  010506                  R0706:  MOV     R5,SP           ;RESET SP FOR ERROR LOOP
054674  005004                          CLR     R4              ;INITIALIZE R4 AS TIMER
054676  012737  000340  177776          MOV     #340,@#PSW      ;SET CPU PRIORITY TO LEVEL 7
054704  000257                          CCC                     ;SCOPE SYNC

054706  052712  000100          T0706:  BIS     #100,(R2)       ;ENABLE INTERRUPTS

054712  005304                          DEC     R4              ;COUNT UNTIL [R4] = 000000 - THEN
054714  001376                          BNE     .-2             ;CONTINUE - NO INTERRUPT SHOULD OCCUR
054716  000404                          BR      B0706           ;GO TO EXIT - ALL OK

054720  042712  000100          A0706:  BIC     #100,(R2)       ;TURN OFF THE INTR ENABLE
054724  104006                  E0706:  ERROR6                  ;INTR OCCURRED WITH CPU AT LEVEL 7
054726  054672                          R0706                   ;ERROR LOOP RETURN ADDRESS

054730  042712  000100          B0706:  BIC     #100,(R2)       ;TURN OFF INTR ENABLE
054734  012737  000102  000100          MOV     #102,@#100      ;RESET THE TRAP CATCHER IN THE VECTOR
054742  005037  000102                  CLR     @#102
054746  010506                          MOV     R5,SP           ;RESET SP JUST IN CASE
054750  005037  177776                  CLR     @#PSW           ;SET CPU PRIORITY BACK TO LEVEL 0

054754  000004                  00706:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; *****************************************************************
                                                .SBTTL T0707 BR PRIORITY ARBITRATION TEST - LEVEL 6 USING KW11-L
                                        ; *****************************************************************

054756  012700  000707          T0707:  MOV     #0707,R0                ;LOAD R0 WITH TEST NO.
054762  013701  055032                  MOV     @#I0707,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
054766  005737  066636                  TST     @#OPTION        ;IS KW11-L INSTALLED ??
054772  100042                          BPL     00707           ;BR IF NOT - SKIP THIS TEST
054774  010605                          MOV     SP,R5           ;SAVE THE SP
054776  012702  177546                  MOV     #LKCSR,R2       ;R2 POINTS TO KW11-L CSR
055002  012737  055044  000100          MOV     #A0707,@#100    ;IF INTR OCCURS - GO TO A0707
055010  012737  000340  000102          MOV     #340,@#102      ;WITH CPU PRIORITY AT LEVEL 7
055016  010506                  R0707:  MOV     R5,SP           ;RESET SP FOR ERROR LOOP
055020  005004                          CLR     R4              ;INITIALIZE R4 AS TIMER
055022  012737  000300  177776          MOV     #300,@#PSW      ;SET CPU PRIORITY TO LEVEL 6
055030  000257                          CCC                     ;SCOPE SYNC

055032  052712  000100          I0707:  BIS     #100,(R2)       ;ENABLE INTERRUPTS

055036  005304                          DEC     R4              ;COUNT UNTIL [R4] = 000000 - THEN
055040  001376                          BNE     .-2             ;CONTINUE - NO INTERRUPT SHOULD OCCUR
055042  000404                          BR      B0707           ;GO TO EXIT - ALL OK

055044  042712  000100          A0707:  BIC     #100,(R2)       ;TURN OFF THE INTR ENABLE
055050  104006                  E0707:  ERROR6                  ;INTR OCCURRED WITH CPU AT LEVEL 6
055052  055016                          R0707                   ;ERROR LOOP RETURN ADDRESS

055054  042712  000100          B0707:  BIC     #100,(R2)       ;TURN OFF INTR ENABLE
055060  012737  000102  000100          MOV     #102,@#100      ;RESET THE TRAP CATCHER IN THE VECTOR
055066  005037  000102                  CLR     @#102
055072  010506                          MOV     R5,SP           ;RESET SP JUST IN CASE
055074  005037  177776                  CLR     @#PSW           ;SET CPU PRIORITY BACK TO LEVEL 0

055100  000004                  00707:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***************************************************************
                                                .SBTTL T0710 BR PRIORITY ARBITRATION TEST - LEVEL 7 USING DL11
                                        ; ***************************************************************

055102  012700  000710          T0710:  MOV     #0710,R0                ;LOAD R0 WITH TEST NO.
055106  013701  055150                  MOV     @#I0710,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
055112  010605                          MOV     SP,R5           ;SAVE THE SP
055114  012702  177564                  MOV     #XCSR,R2        ;R2 POINTS TO DL11 XCSR
055120  012737  055162  000064          MOV     #A0710,@#64     ;IF INTR OCCURS - GO TO A0710
055126  012737  000340  000066          MOV     #340,@#66       ;WITH CPU PRIORITY AT LEVEL 7
055134  010506                  R0710:  MOV     R5,SP           ;RESET SP FOR ERROR LOOP
055136  005004                          CLR     R4              ;INITIALIZE R4 AS TIMER
055140  012737  000340  177776          MOV     #340,@#PSW      ;SET CPU PRIORITY TO LEVEL 7
055146  000257                          CCC                     ;SCOPE SYNC

055150  052712  000100          I0710:  BIS     #100,(R2)       ;ENABLE INTERRUPTS

055154  005304                          DEC     R4              ;COUNT UNTIL [R4] = 000000 - THEN
055156  001376                          BNE     .-2             ;CONTINUE - NO INTERRUPT SHOULD OCCUR
055160  000404                          BR      B0710           ;GO TO EXIT - ALL OK

055162  042712  000100          A0710:  BIC     #100,(R2)       ;TURN OFF THE INTR ENABLE
055166  104006                  E0710:  ERROR6                  ;INTR OCCURRED WITH CPU AT LEVEL 7
055170  055134                          R0710                   ;ERROR LOOP RETURN ADDRESS

055172  042712  000100          B0710:  BIC     #100,(R2)       ;TURN OFF INTR ENABLE
055176  012737  000066  000064          MOV     #66,@#64        ;RESET THE TRAP CATCHER IN THE VECTOR
055204  005037  000066                  CLR     @#66            ;
055210  010506                          MOV     R5,SP           ;RESET SP JUST IN CASE
055212  005037  177776                  CLR     @#PSW           ;SET CPU PRIORITY BACK TO LEVEL 0

055216  000004                  D0710:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***************************************************************
                                                .SBTTL T0711 BR PRIORITY ARBITRATION TEST - LEVEL 6 USING DL11
                                        ; ***************************************************************

055220  012700  000711          T0711:  MOV     #0711,R0                ;LOAD R0 WITH TEST NO.
055224  013701  055266                  MOV     @#I0711,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
055230  010605                          MOV     SP,R5           ;SAVE THE SP
055232  012702  177564                  MOV     #XCSR,R2        ;R2 POINTS TO DL11 XCSR
055236  012737  055300  000064          MOV     #A0711,@#64     ;IF INTR OCCURS - GO TO A0711
055244  012737  000340  000066          MOV     #340,@#66       ;WITH CPU PRIORITY AT LEVEL 7
055252  010506                  R0711:  MOV     R5,SP           ;RESET SP FOR ERROR LOOP
055254  005004                          CLR     R4              ;INITIALIZE R4 AS TIMER
055256  012737  000300  177776          MOV     #300,@#PSW      ;SET CPU PRIORITY TO LEVEL 6
055264  000257                          CCC                     ;SCOPE SYNC

055266  052712  000100          I0711:  BIS     #100,(R2)       ;ENABLE INTERRUPTS

055272  005304                          DEC     R4              ;COUNT UNTIL [R4] = 000000 - THEN
055274  001376                          BNE     .-2             ;CONTINUE - NO INTERRUPT SHOULD OCCUR
055276  000404                          BR      B0711           ;GO TO EXIT - ALL OK

055300  042712  000100          A0711:  BIC     #100,(R2)       ;TURN OFF THE INTR ENABLE
055304  104006                  E0711:  ERROR6                  ;INTR OCCURRED WITH CPU AT LEVEL 6
055306  055252                          R0711                   ;ERROR LOOP RETURN ADDRESS

055310  042712  000100          B0711:  BIC     #100,(R2)       ;TURN OFF INTR ENABLE
055314  012737  000066  000064          MOV     #66,@#64        ;RESET THE TRAP CATCHER IN THE VECTOR
055322  005037  000066                  CLR     @#66
055326  010506                          MOV     R5,SP           ;RESET SP JUST IN CASE
055330  005037  177776                  CLR     @#PSW           ;SET CPU PRIORITY BACK TO LEVEL 0

055334  000004                  00711:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***************************************************************
                                                .SBTTL T0712 BR PRIORITY ARBITRATION TEST - LEVEL 5 USING DL11
                                        ; ***************************************************************

055336  012700  000712          T0712:  MOV     #0712,R0                ;LOAD R0 WITH TEST NO.
055342  013701  055404                  MOV     @#I0712,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
055346  010605                          MOV     SP,R5           ;SAVE THE SP
055350  012702  177564                  MOV     #XCSR,R2        ;R2 POINTS TO DL11 XCSR
055354  012737  055416  000064          MOV     #A0712,@#64     ;IF INTR OCCURS - GO TO A0712
055362  012737  000340  000066          MOV     #340,@#66       ;WITH CPU PRIORITY AT LEVEL 7
055370  010506                  R0712:  MOV     R5,SP           ;RESET SP FOR ERROR LOOP
055372  005004                          CLR     R4              ;INITIALIZE R4 AS TIMER
055374  012737  000240  177776          MOV     #240,@#PSW      ;SET CPU PRIORITY TO LEVEL 5
055402  000257                          CCC                     ;SCOPE SYNC

055404  052712  000100          I0712:  BIS     #100,(R2)       ;ENABLE INTERRUPTS

055410  005304                          DEC     R4              ;COUNT UNTIL [R4] = 000000 - THEN
055412  001376                          BNE     .-2             ;CONTINUE - NO INTERRUPT SHOULD OCCUR
055414  000404                          BR      B0712           ;GO TO EXIT - ALL OK

055416  042712  000100          A0712:  BIC     #100,(R2)       ;TURN OFF THE INTR ENABLE
055422  104006                  E0712:  ERROR6                  ;INTR OCCURRED WITH CPU AT LEVEL 5
055424  055370                          R0712                   ;ERROR LOOP RETURN ADDRESS

055426  042712  000100          B0712:  BIC     #100,(R2)       ;TURN OFF INTR ENABLE
055432  012737  000066  000064          MOV     #66,@#64        ;RESET THE TRAP CATCHER IN THE VECTOR
055440  005037  000066                  CLR     @#66
055444  010506                          MOV     R5,SP           ;RESET SP JUST IN CASE
055446  005037  177776                  CLR     @#PSW           ;SET CPU PRIORITY BACK TO LEVEL 0

055452  000004                  00712:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***************************************************************
                                                .SBTTL T0713 BR PRIORITY ARBITRATION TEST - LEVEL 4 USING DL11
                                        ; ***************************************************************

055454  012700  000713          T0713:  MOV     #0713,R0                ;LOAD R0 WITH TEST NO.
055460  013701  055522                  MOV     @#I0713,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
055464  010605                          MOV     SP,R5           ;SAVE THE SP
055466  012702  177564                  MOV     #XCSR,R2        ;R2 POINTS TO DL11 XCSR
055472  012737  055534  000064          MOV     #A0713,@#64     ;IF INTR OCCURS - GO TO A0713
055500  012737  000340  000066          MOV     #340,@#66       ;WITH CPU PRIORITY AT LEVEL 7
055506  010506                  R0713:  MOV     R5,SP           ;RESET SP FOR ERROR LOOP
055510  005004                          CLR     R4              ;INITIALIZE R4 AS TIMER
055512  012737  000200  177776          MOV     #200,@#PSW      ;SET CPU PRIORITY TO LEVEL 4
055520  000257                          CCC                     ;SCOPE SYNC

055522  052712  000100          I0713:  BIS     #100,(R2)       ;ENABLE INTERRUPTS

055526  005304                          DEC     R4              ;COUNT UNTIL [R4] = 000000 - THEN
055530  001376                          BNE     .-2             ;CONTINUE - NO INTERRUPT SHOULD OCCUR
055532  000404                          BR      B0713           ;GO TO EXIT - ALL OK

055534  042712  000100          A0713:  BIC     #100,(R2)       ;TURN OFF THE INTR ENABLE
055540  104006                  E0713:  ERROR6                  ;INTR OCCURRED WITH CPU AT LEVEL 4
055542  055506                          R0713                   ;ERROR LOOP RETURN ADDRESS

055544  042712  000100          B0713:  BIC     #100,(R2)       ;TURN OFF INTR ENABLE
055550  012737  000066  000064          MOV     #66,@#64        ;RESET THE TRAP CATCHER IN THE VECTOR
055556  005037  000066                  CLR     @#66
055562  010506                          MOV     R5,SP           ;RESET SP JUST IN CASE
055564  005037  177776                  CLR     @#PSW           ;SET CPU PRIORITY BACK TO LEVEL 0

055570  000004                  D0713:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***********************************************************************
                                                .SBTTL T0714 "CLR  @#PSW" ALLOWS IMMEDIATE BR-BG-INTR SEQUENCE
                                        ; ***********************************************************************

                                        ;THIS TEST VERIFIES THAT IF A "BR" REQUEST IS PENDING WHEN A "CLR  @#PSW"
                                        ;IS EXECUTED TO LOWER THE CPU PRIORITY, THE REQUEST IS GRANTED BEFORE
                                        ;EXECUTION OF THE INSTRUCTION FOLLOWING THE "CLR"

055572  012700  000714          T0714:  MOV     #0714,R0                ;LOAD R0 WITH THE TEST NO.
055576  013701  055672                  MOV     @#I0714,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
055602  005737  066636                  TST     @#OPTION        ;IS THE KW11-L INSTALLED ??
055606  100053                          BPL     00714           ;SKIP THIS TEST IF NOT
055610  012702  177546                  MOV     #LKCSR,R2       ;R2 POINTS TO KW11-L CSR
055614  010605                          MOV     SP,R5           ;SAVE THE SP
055616  012737  055700  000100          MOV     #A0714,@#100    ;SET UP LCLK VECTOR TO GO TO A0714
055624  012737  000300  000102          MOV     #300,@#102
055632  010506                  R0714:  MOV     R5,SP           ;RESET THE SP FOR ERROR LOOPING
055634  005004                          CLR     R4              ;INITIALIZE TIMER FO KW
055636  005003                          CLR     R3              ;CLEAR SOFTWARE FLAG
055640  012737  000340  177776          MOV     #340,@#PSW      ;LOCK OUT ALL INTRS
055646  052712  000100                  BIS     #100,(R2)       ;ENABLE LCLK INTRS
055652  042712  000200                  BIC     #200,(R2)       ;CLEAR LINE CLOCK READY
055656  105712                  1$:     TSTB    (R2)            ;LCLK READY TO INTR ??
055660  100403                          BMI     2$              ;BR IF YES
055662  005304                          DEC     R4              ;COUNT THE TIMER
055664  001374                          BNE     1$              ;BR IF NO TIMEOUT
055666  000412                          BR      B0714           ;GO REPORT TIMEOUT
055670  000257                  2$:     CCC                     ;SCOPE SYNC

055672  005037  177776          I0714:  CLR     @#PSW           ;ALLOW INTRS - LCLK SHOULD INTERRUPT
                                                                ;BEFORE FETCHING NEXT INSTRUCTION
055676  005103                          COM     R3              ;SHOULD NOT BE FETCHED
055700  005012                  A0714:  CLR     (R2)            ;DISABLE THE LCLK INTR
055702  005703                          TST     R3              ;DID SOFTWARE FLAG GET SET ??
055704  001406                          BEQ     C0714           ;BR IF NOT - IT WORKED OK
055706  104006                  E10714: ERROR6                  ;LCLK FAILED TO INTR ONTIME
055710  055632                          R0714                   ;ERROR LOOP RETURN ADDRESS
055712  000403                          BR      C0714           ;GO EXIT

055714  005012                  B0714:  CLR     (R2)            ;DISABLE  LCLK INTR
055716  104006                  E20714: ERROR6                  ;KW11-L TIMED OUT
055720  055632                          R0714                   ;ERROR LOOP RETURN ADDRESS

055722  010506                  C0714:  MOV     R5,SP           ;RESET THE SP
055724  012737  000102  000100          MOV     #102,@#100      ;RESTORE THE KW11-L TRAPCATCHER
055732  005037  000102                  CLR     @#102

055736  000004                  00714:  SCOPE                   ;CALL THE SCOPE LOOP UTILITY
```

```
                                        ; ***********************************************************************
                                                .SBTTL T0715 "BR6 VS BR4" PRIORITY ARBITRATION TEST
                                        ; ***********************************************************************

                                        ;THIS TEST VERIFIES THAT IF BOTH A "BR4" AND A "BR6" REQUEST ARE
                                        ;PENDING WHEN THE CPU PRIORITY IS LOWERED TO ALLOW INTRS. THAT "BR6"
                                        ;REQUEST IS GRANTED FIRST EVEN THOUGH THE "BR4" REQUEST MAY HAVE
                                        ;OCCURRED FIRST

055740  012700  000715          T0715:  MOV     #0715,R0                ;LOAD R0 WITH THE TEST NO.
055744  013701  056106                  MOV     @#I0715,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
055750  005737  066636                  TST     @#OPTION        ;IS THE LCLK INSTALLED ??
055754  100133                          BPL     00715           ;BR IF NOT - SKIP THIS TEST
055756  012702  177546                  MOV     #LKCSR,R2       ;R2 POINTS TO KW11-L CSR
055762  012703  177564                  MOV     #XCSR,R3        ;R3 POINTS TO DL11 XCSR
055766  010605                          MOV     SP,R5           ;SAVE THE SP
055770  012737  056116  000100          MOV     #A0715,@#100    ;SET UP THE LCLK VECTOR - GO TO A0715
055776  012737  000300  000102          MOV     #300,@#102
056004  012737  056152  000064          MOV     #C0715,@#64     ;SET UP THE DL11 VECTOR - GO TO C0715
056012  012737  000200  000066          MOV     #200,@#66
056020  010506                  R0715:  MOV     R5,SP           ;RESET SP FOR ERROR LOOPING
056022  012737  000340  177776          MOV     #340,@#PSW      ;LOCK OUT ALL INTRS
056030  005037  067602                  CLR     @#MBUF0         ;INIT TIMER
056034  005037  067606                  CLR     @#MBUF1         ;CLEAR DL11 INTR FLAG
056040  005004                          CLR     R4              ;INIT TIMER
056042  052713  000100                  BIS     #100,(R3)       ;ENABLE DL11 XMIT INTR
056046  105713                  1$:     TSTB    (R3)            ;XMIT READY SET ??
056050  100403                          BMI     2$              ;BR IF YES
056052  005304                          DEC     R4              ;COUNT THE TIMER
056054  001374                          BNE     1$              ;BR IF NO TIMEOUT
056056  000444                          BR      F0715           ;GO REPORT TIMEOUT FOR DL11

056060  005004                  2$:     CLR     R4              ;INIT THE TIMER AGAIN
056062  052712  000100                  BIS     #100,(R2)       ;ENABLE LCLK INTRS
056066  042712  000200                  BIC     #200,(R2)       ;CLEAR THE LINE CLOCK READY BIT
056072  105712                  3$:     TSTB    (R2)            ;LCLK READY TO INTR
056074  100403                          BMI     4$              ;BR IF YES
056076  005304                          DEC     R4              ;COUNT THE TIMER
056100  001374                          BNE     3$              ;BR IF NO TIMEOUT
056102  000437                          BR      G0715           ;GO REPORT KW11-L TIMEOUT
056104  000257                  4$:     CCC                     ;SCOPE SYNC

056106  005037  177776          I0715:  CLR     @#PSW           ;ALLOW INTRS - KW SHOULD INTR FIRST

056112  005137  067602                  COM     @#MBUF0         ;SET SOFTWARE FLAG IF FETCHED
056116  005013                  A0715:  CLR     (R3)            ;DISABLE BOTH INTERRUPTS
056120  005012                          CLR     (R2)
056122  005737  067602                  TST     @#MBUF0         ;DID SOFTWARE FLAG GET SET ??
056126  001403                          BEQ     B0715           ;BR IF NOT

056130  104007                  E10715: ERROR7                  ;KW11-L INTR OCCURRED TOO LATE
056132  056020                          R0715                   ;ERROR LOOP RETURN ADDRESS
056134  000426                          BR      H0715           ;GO TO EXIT

056136  005737  067606          B0715:  TST     @#MBUF1         ;DID DL11 SOFTWARE FLAG SET ??
056142  001423                          BEQ     H0715           ;BR IF NOT
```

```
056144  104007                  E20715: ERROR7                  ;DL11 INTERRUPTED THE KW11
056146  056020                          R0715                   ;ERROR LOOP RETURN ADDDRESS
056150  000420                          BR      H0715           ;GO TO EXIT TEST

056152  005137  067606          C0715:  COM     @#MBUF1         ;FLAG THE DL11 INTR
056156  005013                          CLR     (R3)            ;DISABLE BOTH INTR ENABLES
056160  005012                          CLR     (R2)
056162  104007                  E30715: ERROR7                  ;DL11 SHOULD NOT HAVE INTERRUPTED
056164  056020                          R0715                   ;ERROR LOOP RETURN ADDDRESS
056166  000411                          BR      H0715           ;GO EXIT TEST

056170  005012                  F0715:  CLR     (R2)            ;DISABLE THE INTR ENABLES
056172  005013                          CLR     (R3)
056174  104007                  E40715: ERROR7                  ;DL11 TIMEOUT
056176  056020                          R0715                   ;ERROR LOOP RETURN ADDRESS
056200  000404                          BR      H0715           ;GO TO EXIT

056202  005012                  G0715:  CLR     (R2)            ;DISABLE INTR ENABLES
056204  005013                          CLR     (R3)
056206  104007                  E50715: ERROR7                  ;KW11 TIMEOUT
056210  056020                          R0715                   ;ERROR LOOP RETURN ADDRESS

056212  010506                  H0715:  MOV     R5,SP           ;RESET THE SP
055214  005037  177776                  CLR     @#PSW           ;RESET THE CPU PRIORITY
056220  012737  000102  000100          MOV     #102,@#100      ;RESTORE LCLK VECTOR
056226  005037  000102                  CLR     @#102
056232  012737  000066  000064          MOV     #66,@#64        ;RESTORE THE DL11 XMIT VECTOR
056240  005037  000066                  CLR     @#66

056244  000004                  00715:  SCOPE                   ;CALL THE SCOPE LOOP UTILITY
```

```
                                        ; ****************************************************************
                                        ; /////////////COMBINED INSTRUCTION EXERCISER SECTION ////////////
                                        ; ****************************************************************

                                        ; ****************************************************************
                                                .SBTTL T0716 "BPT" TRAP LINKAGE TEST
                                        ; ****************************************************************

056246  012700  000716          T0716:  MOV     #0716,R0                ;SAVE THE TEST NO. IN R0
056252  013701  056272                  MOV     @#I0716,R1      ;LOAD INSTRUCTION TEST WORD INTO R1
056256  010605                          MOV     SP,R5           ;SAVE THE SP
056260  012737  056300  000014          MOV     #A0716,@#14     ;GO TO A0716 ON "BPT" TRAP
056266  010506                  R0716:  MOV     R5,SP           ;RESET THE SP FOR ERROR LOOPING
056270  000257                          CCC                     ;SCOPE SYNC

056272  000003                  I0716:  BPT                     ;TEST THE "BPT" - GO TO A0716

056274  104005                  E0716:  ERROR5                  ;BPT FAILED TO TRAP
056276  056266                          R0716                   ;ERROR LOOP RETURN ADDRESS

056300  010506                  A0716:  MOV     R5,SP           ;RESET THE SP
056302  012737  000016  000014          MOV     #16,@#14        ;RESTORE THE VECTOR

056310  000004                  00716:  SCOPE                   ;CALL THE SCOPE LOOP UTILITY


                                        ; ****************************************************************
                                                .SBTTL T0717 RED ZONE OVERFLOW TEST - MOV R,-(SP)
                                        ; ****************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [174,257,200,JAMUPP,TRAP MICROROUTINE] FC 1,4,6,10

                                        ;ACT BUTS:      37[004]100,174 / 22[174]200,200 / 01[332]122,123 / 26[123]010,013

                                        ;EXEC:          [200] BUS STOP TRIGGERS JAMUPP LOGIC

                                        ;CODES:         N / A

                                        ;SYNC:          B05J2 (-) T = 10 USEC

                                        ;KEY SIG:       K5-5 STACK04 H  /  K5-5 STPM2 H  /  K1-7 BOVFLW STOP H  /  K4-4 OVFLW ER
                                                        ;K4-4 BUS STOP H  /  K4-3 JBERR (1) L  /  K4-3 JAMUPP L  /  K4-3 JAM CLK

056312  012700  000717          T0717:  MOV     #0717,R0                ;LOAD R0 WITH TEST NO.
056316  013701  056356                  MOV     @#I0717,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
056322  010605                          MOV     SP,R5           ;SAVE SP
056324  013704  000004          R0717:  MOV     @#4,R4          ;SAVE T.O. VECTOR
056330  013703  000336                  MOV     @#336,R3        ;SAVE VECTOR AT 336
056334  012737  056372  000004          MOV     #A0717,@#4      ;GO TO A0717 ON OVFLW
056342  012737  125252  000336          MOV     #125252,@#336   ;INIT. [336]
056350  012706  000340                  MOV     #340,SP         ;SET SP TO CAUSE RED ZONE TRAP
056354  000257                          CCC                     ;SCOPE SYNC

056356  010046                  I0717:  MOV     R0,-(SP)        ;FORCE RED ZONE TRAP - GO TO A0717
```

```
056360  010437  000004                  MOV     R4,@#4          ;RESTORE T.O. VECTOR
056364  010506                          MOV     R5,SP           ;RESET SP FOR ERROR CALL
056366  104005                  E10717: ERROR5                  ;MOV FAILED TO CAUSE TRAP
056370  056324                          R0717                   ;ERROR LOOP RETURN ADDRESS

056372  010437  000004          A0717:  MOV     R4,@#4          ;RESTORE T.O. VECTOR
056376  022706  000000                  CMP     #0,SP           ;[SP]=0?
056402  001403                          BEQ     B0717           ;BE IF YES

056404  010506                          MOV     R5,SP           ;RESET SP FOR ERROR CALL
056406  104005                  E20717: ERROR5                  ;SP NOT BEING JAMMED TO 4
056410  056324                          R0717                   ;ERROR LOOP RETURN ADDRESS

056412  022737  125252  000336  B0717:  CMP     #125252,@#336   ;DID PUSH OCCUR IN YELLOW ZONE?
056420  001403                          BEQ     C0717           ;BR IF NOT

056422  010506                          MOV     R5,SP           ;RESET SP FOR ERROR CALL
056424  104005                  E30717: ERROR5                  ;MOV PUSHED INTO YELLOW ZONE
056426  056324                          R0717                   ;ERROR LOOP RETURN ADDRESS

056430  010337  000336          C0717:  MOV     R3,@#336        ;RESTORE VECTOR 336
056434  010506                          MOV     R5,SP           ;RESET SP

056436  000004                  00717:  SCOPE                   ;CALL THE SCOPE LOOP UTILITY
```

```
                                        ; ***************************************************************
                                                .SBTTL T0720 YELLOW ZONE OVERFLOW TEST - MOV R,-(SP)
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [174,257,201,125,375,017,015,010,TRAP MICROROUTINE] FC 1,4,8,10,6

                                        ;ACT BUTS:      37[004]100,174 / 22[174]200,201 / 16[125]016,017 / 26[017]010,010

                                        ;EXEC:          K4-4 CLK BOVFL SETS K5-4 BOVFLW FLOP

                                        ;CODES:         N/A

                                        ;SYNC:          B05J2   (-)     T= 10USEC

                                        ;KEY SIG:       K4-4 CLK BOVFLW H / K4-4 CKOVF H / K1-7 BOVFL L

056440  012700  000720          T0720:  MOV     #0720,R0                ;LOAD R0 WITH TEST NO.
056444  013701  056476                  MOV     @#I0720,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
056450  010605                          MOV     SP,R5           ;SAVE SP
056452  012702  000376                  MOV     #376,R2         ;R2 POINTS TO STACK
056456  013704  000004          R0720:  MOV     @#4,R4          ;SAVE T.O. VECTOR
056462  012737  056512  000004          MOV     #A0720,@#4      ;ON OVFLW - GO TO A0720
056470  012706  000400                  MOV     #400,SP         ;SET SP TO CAUSE OVFLW
056474  000257                          CCC                     ;SCOPE SYNC

056476  010046                  I0720:  MOV     R0,-(SP)        ;FORCE STACK OVFLW - GO TO A0720

056500  010437  000004                  MOV     R4,@#4          ;RESTORE T.O. VECTOR
056504  010506                          MOV     R5,SP           ;RESET SP FOR ERROR CALL
056506  104005                  E10720: ERROR5                  ;STACK OVFLW FAILED TO TRAP
056510  056456                          R0720                   ;ERROR LOOP RETURN ADDRESS

056512  010437  000004          A0720:  MOV     R4,@#4          ;RESTORE T.O. VECTOR
056516  020012                          CMP     R0,(R2)         ;DID [R0] GET PUSHED?
056520  001403                          BEQ     B0720           ;BR IF YES

056522  010506                          MOV     R5,SP           ;RESET SP FOR ERROR CALL
056524  104005                  E20720: ERROR5                  ;MOV FAILED TO PUSH IN YELLOW ZONE
056526  056456                          R0720                   ;ERROR LOOP RETURN ADDRESS

056530  005706                  B0720:  TST     SP              ;[SP]=0?
056532  001003                          BNE     C0720           ;BR IF NOT

056534  010506                          MOV     R5,SP           ;RESET SP FOR ERROR CALL
056536  104005                  E30720: ERROR5                  ;RED ZONE INSTEAD OF YELLOW ZONE
056540  056456                          R0720                   ;ERROR LOOP RETURN ADDRESS

056542  010506                  C0720:  MOV     R5,SP           ;RESET SP

056544  000004                  00720:  SCOPE                   ;CALL THE SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                        .SBTTL T0721 YELLOW ZONE OVERFLOW TEST - (CMP  R0,-(SP))
                                ; ***************************************************************

056546  012700  000721          T0721:  MOV     #0721,R0                ;LOAD R0 WITH TEST NO.
056552  013701  056600                  MOV     @#I0721,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
056556  010605                          MOV     SP,R5           ;SAVE THE SP
056560  013704  000004                  MOV     @#4,R4          ;SAVE TRAP VECTOR
056564  012737  056604  000004  R0721:  MOV     #A0721,@#4      ;GO TO A0721 IF TRAP SPRUNG
056572  012706  000400                  MOV     #400,SP         ;SET SP TO PUSH INTO "YELLOW ZONE"
056576  000257                          CCC                     ;SCOPE SYNC

056600  020046                  I0721:  CMP     R0,-(SP)        ;TEST THE CMP - NO TRAP SHOULD OCCUR

056602  000405                          BR      B0721           ;GO TO EXIT TEST

056604  010437  000004          A0721:  MOV     R4,@#4          ;RESTORE TRAP VECTOR
056610  010506                          MOV     R5,SP           ;RESET THE SP
056612  104005                  E0721:  ERROR5                  ;CMP CAUSED OVERFLOW TRAP
056614  056564                          R0721                   ;ERROR LOOP RETURN ADDRESS

056616  010437  000004          B0721:  MOV     R4,@#4          ;RESTORE THE VECTOR
056622  010506                          MOV     R5,SP           ;RESET THE SP

056624  000004                  00721:  SCOPE                   ;CALL THE SCOPE LOOP UTILITY
```

```
                                        ; ***************************************************************
                                                .SBTTL T0722 YELLOW ZONE OVERFLOW TEST - (BIT  R0,-(SP))
                                        ; ***************************************************************

056626  012700  000722          T0722:  MOV     #0722,R0                ;LOAD R0 WITH TEST NO.
056632  013701  056660                  MOV     @#I0722,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
056636  010605                          MOV     SP,R5           ;SAVE THE SP
056640  013704  000004                  MOV     @#4,R4          ;SAVE TRAP VECTOR
056644  012737  056664  000004  R0722:  MOV     #A0722,@#4      ;GO TO A0722 IF TRAP SPRUNG
056652  012706  000400                  MOV     #400,SP         ;SET SP TO PUSH INTO "YELLOW ZONE"
056656  000257                          CCC                     ;SCOPE SYNC

056660  030046                  I0722:  BIT     R0,-(SP)        ;TEST THE BIT - NO TRAP SHOULD OCCUR

056662  000405                          BR      B0722           ;GO TO EXIT TEST

056664  010437  000004          A0722:  MOV     R4,@#4          ;RESTORE TRAP VECTOR
056670  010506                          MOV     R5,SP           ;RESET THE SP
056672  104005                  E0722:  ERROR5                  ;BIT CAUSED OVERFLOW TRAP
056674  056644                          R0722                   ;ERROR LOOP RETURN ADDRESS

056676  010437  000004          B0722:  MOV     R4,@#4          ;RESTORE THE VECTOR
056702  010506                          MOV     R5,SP           ;RESET THE SP

056704  000004                  00722:  SCOPE                   ;CALL THE SCOPE LOOP UTILITY
```

```
                                        ; *****************************************************************
                                                .SBTTL T0723 YELLOW ZONE OVERFLOW TEST - (TST  -(SP))
                                        ; *****************************************************************

056706  012700  000723          T0723:  MOV     #0723,R0                ;LOAD R0 WITH TEST NO.
056712  013701  056740                  MOV     @#I0723,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
056716  010605                          MOV     SP,R5           ;SAVE THE SP
056720  013704  000004                  MOV     @#4,R4          ;SAVE TRAP VECTOR
056724  012737  056744  000004  R0723:  MOV     #A0723,@#4      ;GO TO A0723 IF TRAP SPRUNG
056732  012706  000400                  MOV     #400,SP         ;SET SP TO PUSH INTO "YELLOW ZONE"
056736  000257                          CCC                     ;SCOPE SYNC

056740  005746                  I0723:  TST     -(SP)           ;TEST THE TST - NO TRAP SHOULD OCCUR

056742  000405                          BR      B0723           ;GO TO EXIT TEST

056744  010437  000004          A0723:  MOV     R4,@#4          ;RESTORE TRAP VECTOR
056750  010505                          MOV     R5,SP           ;RESET THE SP
056752  104005                  E0723:  ERROR5                  ;TST CAUSED OVERFLOW TRAP
056754  056724                          R0723                   ;ERROR LOOP RETURN ADDRESS

056756  010437  000004          B0723:  MOV     R4,@#4          ;RESTORE THE VECTOR
056762  010506                          MOV     R5,SP           ;RESET THE SP

056764  000004                  00723:  SCOPE                   ;CALL THE SCOPE LOOP UTILITY
```

```
                                        ; ***********************************************************************
                                                .SBTTL T0724 ODD ADDRESS ERROR TEST - SUB  RA,(RB) - (RB) = ODD
                                        ; ***********************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:

                                        ;ACT BUTS:

                                        ;EXEC:

                                        ;CODES:

                                        ;SYNC:

                                        ;KEY SIG:

056766  012700  000724          T0724:  MOV     #0724,R0                ;LOAD R0 WITH TEST NO.
056772  013701  057022                  MOV     @#I0724,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
056776  010605                          MOV     SP,R5           ;SAVE SP
057000  013704  000004          R0724:  MOV     @#4,R4          ;SAVE T.O. VECTOR
057004  012737  057034  000004          MOV     #A0724,@#4      ;ON ODD ADDR ERROR - GO TO A0724
057012  010506                          MOV     R5,SP           ;RESET SP FOR ERROR LOOP
057014  012702  000001                  MOV     #1,R2           ;R2 GETS ODD ADDRESS
057020  000257                          CCC                     ;SCOPE SYNC

057022  160012                  I0724:  SUB     R0,(R2)         ;FORCE ODD ADDR ERROR - GO TO A0724

057024  010437  000004                  MOV     R4,@#4          ;RESTORE T.O. VECTOR
057030  104005                  E0724:  ERROR5                  ;ODD ADDR FAILED TO TRAP
057032  057000                          R0724                   ;ERROR LOOP RETURN ADDRESS

057034  010437  000004          A0724:  MOV     R4,@#4          ;RESTORE T.O. VECTOR
057040  010506                          MOV     R5,SP           ;RESET SP
057042  005037  000000                  CLR     @#0             ;CLR LOC. 0 JUST IN CASE

057046  000004                  00724:  SCOPE                   ;CALL THE SCOPE LOOP UTILITY
```

```
                                        ; ***************************************************************
                                                .SBTTL T0725 TEST FOR ODD ADDR. ERROR TRAP FOR DEST. DEFERRED MODES
                                        ; ***************************************************************

057050  012700  000725          T0725:  MOV     #0725,R0                ;LOAD R0 WITH TEST NO.
057054  012702  067607                  MOV     #MBUF1+1,R2     ;DEST ADDR=MBUF1+1 (ODD)
057060  012737  057154  000004          MOV     #A0725,@#4      ;GO TO A0725 ON ODA TRAP

057066  010205                  R10725: MOV     R2,R5           ;[R5] = DEST. ADDR
057070  013701  057076                  MOV     @#I10725,R1     ;[R1] = TEST INSTR
057074  000257                          CCC                     ;SCOPE SYNC

057076  105435                  I10725: NEGB    @(R5)+          ;TEST DM=3 TRAP

057100  104006                  E10725: ERROR6                  ;ODA TRAP NOT SPRUNG IN ROM LOC. 163
057102  057066                          R10725                  ;ERROR LOOP RETURN ADDRESS

057104  012705  067611          R20725: MOV     #MBUF1+3,R5     ;[R5] = DEST. ADDR
057110  013701  057116                  MOV     @#I20725,R1     ;[R1] = TEST INSTR
057114  000257                          CCC                     ;SCOPE SYNC

057116  105455                  I20725: NEGB    @-(R5)          ;TEST DM=5 TRAP

057120  104006                  E20725: ERROR6                  ;ODA TRAP NOT SPRUNG IN ROM LOC. 165
057122  057104                          R20725                  ;ERROR LOOP RETURN ADDRESS

057124  010205                  R30725: MOV     R2,R5           ;[R5] = DEST ADDR
057126  013701  057134                  MOV     @#I30725,R1     ;[R1] = TEST INSTR
057132  000257                          CCC                     ;SCOPE SYNC

057134  105475  000000          I30725: NEGB    @0(R5)          ;TEST DM=7 TRAP

057140  104006                  E30725: ERROR6                  ;ODA TRAP NOT SPRUNG IN ROM LOC 263
057142  057124                          R30725                  ;ERROR LOOP RETURN ADDRESS

057144  012737  065160  000004          MOV     #BERR,@#4       ;RESET T.O. VECTOR
057152  000403                          BR      00725           ;GO TO SCOPE EXIT

057154  062716  000004          A0725:  ADD     #4,(SP)         ;MOV RETURN PC AROUND ERROR CALL
057160  000002                          RTI                     ;RETURN TO NEXT SUB-TEST

057162  000004                  00725:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***********************************************************************
                                                .SBTTL TO726 TEST FOR ODD ADDR ERROR TRAP FOR SOURCE DEFERRED MODES
                                        ; ***********************************************************************

057164  012700  000726          TO726:  MOV     #0726,R0                ;LOAD R0 WITH TEST NO.
057170  012702  067607                  MOV     #MBUF1+1,R2     ;[R2] = SOURCE ADDR. (ODD)
057174  012737  057270  000004          MOV     #A0726,@#4      ;GO TO A0726 ON TRAP

057202  010205                  R10726: MOV     R2,R5           ;[R5] = SOURCE ADDR.
057204  013701  057212                  MOV     @#I10726,R1     ;[R1] = TEST INSTR.
057210  000257                          CCC                     ;SCOPE SYNC

057212  113504                  I10726: MOVB    @(R5)+,R4       ;TEST SM=3

057214  104006                  E10726: ERROR6                  ;ODA TRAP NOT SPRUNG IN ROM LOC. 143
057216  057202                          R10726                  ;ERROR LOOP RETURN ADDRESS

057220  012705  067611          R20726: MOV     #MBUF1+3,R5     ;[R5] = SOURCE ADDR
057224  013701  057232                  MOV     @#I20726,R1     ;[R1] = TEST INSTR
057230  000257                          CCC                     ;SCOPE SYNC

057232  115504                  I20726: MOVB    @-(R5),R4       ;TEST SM=5

057234  104006                  E20726: ERROR6                  ;ODA TRAP NOT SPRUNG IN ROM LOC 145
057236  057220                          R20726                  ;ERROR LOOP RETURN ADDRESS
057240  010205                  R30726: MOV     R2,R5           ;[R5] = SOURCE ADDR
057242  013701  057250                  MOV     @#I30726,R1     ;[R1] = TEST INSTR
057246  000257                          CCC                     ;SCOPE SYNC

057250  117504  000000          I30726: MOVB    @0(R5),R4       ;TEST SM=7

057254  104006                  E30726: ERROR6                  ;ODA TRAP NOT SPRUNG IN ROM LOC 244
057256  057240                          R30726                  ;ERROR LOOP RETURN ADDRESS

057260  012737  065160  000004          MOV     #BERR,@#4       ;RESET T.O. VECTOR
057266  000403                          BR      00726           ;GO TO SCOPE EXIT

057270  062716  000004          A0726:  ADD     #4,(SP)         ;MOVE RETURN PC AROUND ERROR CALL
057274  000002                          RTI                     ;RETURN TO NEXT SUB-TEST

057276  000004                  00726:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; *****************************************************************
                                                .SBTTL T0727 TEST FOR ODD ADDR ERROR TRAP FOR JMP DEST DEFERRED MODES
                                        ; *****************************************************************

057300  012700  000727          T0727:  MOV     #0727,R0                .LOAD R0 WITH TEST NO.
057304  012702  057407                  MOV     #B0727+3,R2     ;DEST ADDR = B0727+3 (ODD)
057310  012737  057412  000004          MOV     #A0727,@#4      ;GO TO A0727 ON ODA TRAP

057316  010205                  R10727: MOV     R2,R5           ;[R5] = DEST ADDR
057320  013701  057326                  MOV     @#I10727,R1     ;[R1] = TEST INSTR
057324  000257                          CCC                     ;SCOPE SYNC

057326  000135                  I10727: JMP     @(R5)+          ;TEST JMP DM=3

057330  104006                  E10727: ERROR6                  ;ODA TRAP NOT SPRUNG IN ROM LOC '53
057332  057316                          R10727                  ;ERROR LOOP RETURN ADDRESS

057334  012705  057407          R20727: MOV     #B0727+3,R5     ;[R5] = DEST ADDR
057340  013701  057346                  MOV     @#I20727,R1     ;[R1] = TEST INSTR
057344  000257                          CCC                     ;SCOPE SYNC

057346  000155                  I20727: JMP     @-(R5)          ;TEST JMP DM=5

057350  104006                  E20727: ERROR6                  ;ODA TRAP NOT SPRUNG IN ROM LOC 155
057352  057334                          R20727                  ;ERROR LOOP RETURN ADDRESS

057354  010205                  R30727: MOV     R2,R5           ;[R5] = DEST ADDR
057356  013701  057364                  MOV     @#I30727,R1     ;[R1] = TEST INSTR
057362  000257                          CCC                     ;SCOPE SYNC

057364  000175  000000          I30727: JMP     @0(R5)          ;TEST JMP DM=7

057370  104006                  E30727: ERROR6                  ;ODA TRAP NOT SPRUNG IN LOC 302
057372  057354                          R30727                  ;ERROR LOOP RETURN ADDRESS

057374  012737  065160  000004          MOV     #BERR,@#4       ;RESET BUS T.O. VECTOR
057402  000421                          BR      00727           ;GO TO SCOPE EXIT

057404  000000                  B0727:  HALT                    ;CATASTOPHIC ERROR - [PC] QUESTIONABLE.
057406  000000                          HALT                    ;RESTART PROGRAM - DO NOT CONTINUE.
057410  000000                          HALT

057412  032716  000001          A0727:  BIT     #1,(SP)         ;TRAP DUE TO ODD PC?
057416  001003                          BNE     C0727           ;BR IF YES
057420  062716  000004                  ADD     #4,(SP)         ;MOV RETURN PC AROUND ERROR CALL
057424  000002                          RTI                     ;RETURN TO NEXT SUB TEST

057426  011603                  C0727:  MOV     (SP),R3         ;GET ODD PC OFF STACK INTO R3
057430  062706  000004                  ADD     #4,SP           ;FIX SP

057434  104007                  E40727: ERROR7                  ;PC TRAPPED WITH ODD ADDRESS
057436  057300                          T0727

057440  012737  065160  000004          MOV     #BERR,@#4       ;RESET T.O. VECTOR

057446  000004                  00727:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

23932

```
                                        ; *****************************************************************
                                                .SBTTL T0730 TEST FOR STACK OFLW FOR DEST MODES 1,2,4, AND 6.
                                        ; *****************************************************************

057450  012700  000730          T0730:  MOV     #0730,R0                ;LOAD R0 WITH TEST NO.
057454  012737  057602  000004          MOV     #A0730,@#4      ;GO TO A0730 ON OVFLW TRAP
057462  010605                          MOV     SP,R5           ;SAVE SP
057464  012702  000376                  MOV     #376,R2         ;USE R2 TO SET UP SP TO CAUSE TRAP

057470  013701  057500          R10730: MOV     @#I10730,R1     ;[R1] = TEST INSTR.
057474  010206                          MOV     R2,SP           ;SET UP SP TO CAUSE OVERFLOW
057476  000257                          CCC                     ;SCOPE SYNC

057500  005016                  I10730: CLR     (SP)            ;TEST DM1 - SHOULD SPRING TRAP

057502  010506                          MOV     R5,SP           ;RESET SP
057504  104006                  E10730: ERROR6                  ;DM1 FAILED TO CAUSE OVERFLOW TRAP
057506  057470                          R10730                  ;ERROR LOOP RETURN ADDRESS

057510  013701  057520          R20730: MOV     @#I20730,R1     ;[R1] = TEST INSTR.
057514  010206                          MOV     R2,SP           ;SET UP SP TO CAUSE OVERFLOW
057516  000257                          CCC                     ;SCOPE SYNC

057520  005026                  I20730: CLR     (SP)+           ;TEST DM2 - SHOULD SPRING TRAP

057522  010506                          MOV     R5,SP           ;RESET SP
057524  104006                  E20730: ERROR6                  ;DM2 FAILED TO CAUSE OVERFLOW TRAP
057526  057510                          R20730                  ;ERROR LOOP RETURN ADDRESS

057530  013701  057540          R30730: MOV     @#I30730,R1     ;[R1] = TEST INSTR.
057534  010206                          MOV     R2,SP           ;SET UP SP TO CAUSE OVERFLOW
057536  000257                          CCC                     ;SCOPE SYNC

057540  005046                  I30730: CLR     -(SP)           ;TEST DM4 - SHOULD SPRING TRAP

057542  010506                          MOV     R5,SP           ;RESET SP
057544  104006                  E30730: ERROR6                  ;DM4 FAILED TO CAUSE OVERFLOW TRAP
057546  057530                          R30730                  ;ERROR LOOP RETURN ADDRESS

057550  013701  057560          R40730: MOV     @#I40730,R1     ;[R1] = TEST INSTR.
057554  010206                          MOV     R2,SP           ;SET SP TO CAUSE ERROR
057556  000257                          CCC                     ;SCOPE SYNC

057560  005066  000000          I40730: CLR     0(SP)           ;TEST DM6 - SHOULD SPRING TRAP

057564  010506                          MOV     R5,SP           ;RESET SP
057566  104006                  E40730: ERROR6                  ;DM6 FAILED TO CAUSE OVERFLOW TRAP
057570  057550                          R40730                  ;ERROR LOOP RETURN ADDRESS

057572  012737  065160  000004          MOV     #BERR,@#4       ;RESET BUS T.O. VECTOR
057600  000407                          BR      00730           ;GO TO SCOPE EXIT

057602  011604                  A0730:  MOV     (SP),R4         ;GET RETURN PC OFF STACK
057604  062704  000006                  ADD     #6,R4           ;MOVE RETURN PC AROUND ERROR CALL
057610  010506                          MOV     R5,SP           ;RESET SP
057612  005046                          CLR     -(SP)           ;PUSH NEW PS ON STACK
```

```
057614  010446                          MOV     R4,-(SP)        ;PUSH RETURN PC ON STACK
057616  000002                          RTI                     ;RETURN TO NEXT SUB-TEST

057620  000004                  00730:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***********************************************************************
                                                .SBTTL T0731 TEST FOR STACK OVFLW FOR MOV DEST MODES 1,2,4, AND 6.
                                        ; ***********************************************************************

057622  012700  000731          T0731:  MOV     #0731,R0                ;LOAD R0 WITH TEST NO.
057626  012737  057754  000004          MOV     #A0731,@#4      ;GO TO A0731 ON STACK OVFLW TRAP
057634  010605                          MOV     SP,R5           ;SAVE SP
057636  012702  000376                  MOV     #376,R2         ;USE R2 TO SET UP SP TO CAUSE TRAP

057642  013701  057652          R10731: MOV     @#I10731,R1     ;[R1] = TEST INSTR.
057646  010206                          MOV     R2,SP           ;SET UP SP TO CAUSE OVERFLOW
057650  000257                          CCC                     ;SCOPE SYNC

057652  010016                  I10731: MOV     R0,(SP)         ;TEST MOV DM1 - SHOULD SPRING TRAP

057654  010506                          MOV     R5,SP           ;RESET SP
057656  104006                  E10731: ERROR6                  ;MOV DM1 FAILED TO SPRING TRAP
057660  057642                          R10731                  ;ERROR LOOP RETURN ADDRESS

057662  013701  057672          R20731: MOV     @#I20731,R1     ;[R1] = TEST INSTR.
057666  010206                          MOV     R2,SP           ;SET UP SP TO CAUSE OVERFLOW
057670  000257                          CCC                     ;SCOPE SYNC

057672  010026                  I20731: MOV     R0,(SP)+        ;TEST MOV DM2 - SHOULD SPRING TRAP

057674  010506                          MOV     R5,SP           ;RESET SP
057676  104006                  E20731: ERROR6                  ;MOV DM2 FAILED TO SPRING TRAP
057700  057662                          R20731                  ;ERROR LOOP RETURN ADDRESS

057702  013701  057712          R30731: MOV     @#I30731,R1     ;[R1] = TEST INSTR.
057706  010206                          MOV     R2,SP           ;SET UP SP TO CAUSE OVERFLOW
057710  000257                          CCC                     ;SCOPE SYNC

057712  010046                  I30731: MOV     R0,-(SP)        ;TEST MOV DM4 - SHOULD SPRING TRAP

057714  010506                          MOV     R5,SP           ;RESET SP
057716  104006                  E30731: ERROR6                  ;MOV DM4 FAILED TO SPRING TRAP
057720  057702                          R30731                  ;ERROR LOOP RETURN ADDRESS

057722  013701  057732          R40731: MOV     @#I40731,R1     ;[R1] = TEST INSTR.
057726  010206                          MOV     R2,SP           ;SET UP SP TO CAUSE OVERFLOW
057730  000257                          CCC                     ;SCOPE SYNC

057732  010066  000000          I40731: MOV     R0,0(SP)        ;TEST MOV DM6 - SHOULD SPRING TRAP

057736  010506                          MOV     R5,SP           ;RESET SP
057740  104006                  E40731: ERROR6                  ;MOV DM6 FAILED TO CAUSE OVFLW TRAP
057742  057722                          R40731                  ;ERROR LOOP RETURN ADDRESS

057744  012737  065160  000004          MOV     #BERR,@#4       ;RESET T.O. VECTOR
057752  000407                          BR      00731           ;GO TO SCOPE EXIT

057754  011604                  A0731:  MOV     (SP),R4         ;GET RETURN PC
057756  062704  000006                  ADD     #6,R4           ;MOVE RETURN PC AROUND ERROR CALL
057762  010506                          MOV     R5,SP           ;RESET SP
057764  005046                          CLR     -(SP)           ;PUSH NEW PSW
```

```
24050  057766  010446                          MOV     R4,-(SP)        ;PUSH RETURN PC
24051  057770  000002                          RTI                     ;RETURN TO NEXT SUB-TEST
24052
24053  057772  000004                  00731:  SCOPE                   ;CALL SCOPE LOOP UTILITY
24054
```

```
                                        ; ***************************************************************
                                                .SBTTL T0732 TEST THAT JSR CAN CAUSE OVERFLOW TRAP
                                        ; ***************************************************************

057774  012700  000732          T0732:  MOV     #0732,R0                ;LOAD R0 WITH TEST NO.
050000  012737  060036  000004          MOV     #A0732,@#4      ;GO TO A0732 ON OVERFLOW ERROR
060006  010605                          MOV     SP,R5           ;SAVE SP
060010  013701  060022                  MOV     @#I0732,R1      ;LOAD R1 WITH TEST INSTR WORD
060014  012706  000400          R0732:  MOV     #400,SP         ;SET THE SP TO CAUSE TRAP
060020  000257                          CCC                     ;SCOPE SYNC

060022  004737  060042          I0732:  JSR     PC,@#B0732      ;TEST JSR - SHOULD SPRING TRAP

060026  010506                          MOV     R5,SP           ;RESET SP
060030  104005                  E10732: ERROR5                  ;JSR PUSH DID NOT SPRING OVFL TRAP
060032  060014                          R0732                   ;ERROR LOOP RETURN ADDRESS

060034  000405                          BR      C0732           ;GO TO SCOPE EXIT

060036  010506                  A0732:  MOV     R5,SP           ;RESET SP
060040  000403                          BR      C0732           ;GO EXIT TEST - ALL OK

060042  010506                  B0732:  MOV     R5,SP           ;RESET SP
060044  104005                  E20732: ERROR5                  ;JSR PUSH FAILED TO SPRING OVFLW TRAP
060046  060014                          R0732                   ;ERROR LOOP RETURN ADDRESS

060050  012737  065160  000004  C0732:  MOV     #BERR,@#4       ;RESET BUS T.O. VECTOR

060056  000004                  00732:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***************************************************************
                                                .SBTTL T0733 TEST THAT 1ST PUSH IN TRAP MICROROUTINE CAUSES OVFLW TRAP
                                        ; ***************************************************************

060060  012700  000733          T0733:  MOV     #0733,R0                ;LOAD R0 WITH TEST NO.
060064  013704  000014                  MOV     @#14,R4         ;SAVE BREAK POINT TRAP VECTOR
060070  013701  060120                  MOV     @#I0733,R1      ;LOAD R1 WITH TEST INSTR
060074  010605                          MOV     SP,R5           ;SAVE SP
060076  012737  060132  000004          MOV     #A0733,@#4      ;GO TO A0733 ON OVFLW TRAP
060104  012737  060136  000014          MOV     #B0733,@#14     ;GO TO B0733 IF BPT SERVICED
060112  012706  000400          R0733:  MOV     #400,SP         ;SET UP SP TO CAUSE OVFLW ON 1ST PUSH
060116  000257                          CCC                     ;SCOPE SYNC

060120  000003                  I0733:  BPT                     ;TEST THE BPT - SHOULD CAUSE OVERFLOW TRAP

060122  010506                          MOV     R5,SP           ;RESET SP
060124  104005                  E10733: ERROR5                  ;BPT FAILED TO TRAP
060126  060112                          R0733                   ;ERROR LOOP RETURN ADDRESS

060130  000405                          BR      C0733           ;GO TO SCOPE EXIT

060132  010506                  A0733:  MOV     R5,SP           ;RESET SP
060134  000403                          BR      C0733           ;GO EXIT - ALL OK

060136  010506                  B0733:  MOV     R5,SP           ;RESET SP
060140  104005                  E20733: ERROR5                  ;OVFLW TRAP FAILED TO BUMP BPT SERVICE
060142  060112                          R0733                   ;ERROR LOOP RETURN ADDRESS

060144  012737  065160  000004  C0733:  MOV     #BERR,@#4       ;RESET VECTORS
060152  010437  000014                  MOV     R4,@#14

060156  000004                  00733:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***********************************************************************
                                                .SBTTL T0734 TEST THAT 2ND PUSH IN TRAP MICROUTINE CAUSES OVFLW TRAP
                                        ; ***********************************************************************

060160  012700  000734          T0734:  MOV     #0734,R0                ;LOAD R0 WITH TEST NO.
060164  013701  060220                  MOV     @#I0734,R1      ;LOAD R1 WITH TEST INSTR WORD
060170  013704  000014                  MOV     @#14,R4         ;SAVE BPT VECTOR
060174  010605                          MOV     SP,R5           ;SAVE SP
060176  012737  060232  000004          MOV     #A0734,@#4      ;GO TO A0734 ON STACK OVFLOW
060204  012737  060236  000014          MOV     #B0734,@#14     ;GO TO B0734 IF BPT SERVICED
060212  012706  000402          R0734:  MOV     #402,SP         ;SET SP TO CAUSE TRAP ON 2ND PUSH
060216  000257                          CCC                     ;SCOPE SYNC

060220  000003                  I0734:  BPT                     ;TEST THE BPT - SHOULD CAUSE OVERFLOW TRAP

060222  010506                          MOV     R5,SP           ;RESET SP
060224  104005                  E10734: ERROR5                  ;BPT FAILED TO TRAP
060226  060212                          R0734                   ;ERROR LOOP RETURN ADDRESS

060230  000405                          BR      C0734           ;GO TO SCOPE EXIT

060232  010506                  A0734:  MOV     R5,SP           ;RESET SP
060234  000403                          BR      C0734           ;GO EXIT - ALL OK

060236  010506                  B0734:  MOV     R5,SP           ;RESET SP
060240  104005                  E20734: ERROR5                  ;OVFLW TRAP FAILED TO BUMP BPT SERVICE
060242  060212                          R0734                   ;ERROR LOOP RETURN ADDRESS

060244  012737  065160  000004  C0734:  MOV     #BERR,@#4       ;RESET VECTORS
060252  010437  000014                  MOV     R4,@#14

060256  000004                  D0734:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***********************************************************************
                                                .SBTTL T0735 ILLEGAL INSTRUCTION TEST - JSR RN,%R
                                        ; ***********************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;RCM SEQ:       [150,007,115,326,327,113,330,331,077,140,332,333,123,015,013] FC 1,6,10

                                        ;ACT BLTS:      37[004]100,150 / 01[332]122,123 / 26[123]010,013

                                        ;EXEC:          [115] D = NEW PSW  /  [113] D = OLD PSW  /  [331] D = #I0735+2  /  [333]

                                        ;CODES:         [140] SPS=7  /  N:C = [LOC 6]

                                        ;SYNC:          BOSJ2 (-) T = 5.8 USEC

                                        ;KEY SIG:       K3-6 ILL INSTR L  /  K5-5 STPM3 H  /  K3-3 DM=OL  /  K3-5 JMP+JSR H

060260  012700  000735          T0735:  MOV     #0735,R0                ;LOAD R0 WITH TEST NO.
060264  013701  060314                  MOV     @#I0735,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
060270  010605                          MOV     SP,R5           ;SAVE SP
060272  013704  000004          R0735:  MOV     @#4,R4          ;SAVE T.O. VECTOR
060276  012737  060326  000004          MOV     #A0735,@#4      ;ILLEGAL INSTR. TRAP GOES TO A0735
060304  010506                          MOV     R5,SP           ;RESET SP FOR ERROR LOOP
060306  012702  060322                  MOV     #E0735,R2               ;IN CASE JSR JUMPS TO [R2]
060312  000257                          CCC                     ;SCOPE SYNC

060314  004302                  I0735:  JSR     R3,R2           ;JSR MODE 0 FORCES TRAP - GO TO A0735

060316  010437  000004                  MOV     R4,@#4          ;RESTORE T.O. VECTOR
060322  104005                  E0735:  ERROR5                  ;JSR FAILED TO SPRING TRAP
060324  060272                          R0735                   ;ERROR LOOP RETURN ADDRESS

060326  010437  000004          A0735:  MOV     R4,@#4          ;RESTORE VECTOR
060332  010506                          MOV     R5,SP           ;RESET SP

060334  000004                  00735:  SCOPE                   ;CALL THE SCOPE LOOP UTILITY
```

```
                                        ; ***********************************************************************
                                                .SBTTL T0736 ILLEGAL INSTRUCTION TEST - JMP %R
                                        ; ***********************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [150,007,115,326,327,113,330,331,077,140,332,333,123,015,013] FC 1,6,10

                                        ;ACT BUTS:      37[004]100,150 / 01[332]122,123 / 26[123]010,013

                                        ;EXEC:          [115] D = NEW PSW  /  [113] D = OLD PSW  /  [311] D = #I0736+2  /  [333]

                                        ;CODES:         [140] SPS=7  /  N:C = [LOC 6]

                                        ;SYNC:          BOSJ2 (-) T = 5.8 USEC

                                        ;KEY SIG:       K3-6 ILL INSTR L  /  K5-5 STPM3 H  /  K3-3 DM=OL  /  K3-5 JMP+JSR H

060336  012700  000736                  T0736:  MOV     #0736,R0                ;LOAD R0 WITH TEST NO.
060342  013701  060372                          MOV     @#I0736,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
060346  010605                                  MOV     SP,R5           ;SAVE SP
060350  013704  000004                  R0736:  MOV     @#4,R4          ;SAVE VECTOR POINTER AT LOC. 4
060354  012737  060404  000004                  MOV     #A0736,@#4      ;ON TRAP - GO TO A0736
060362  010506                                  MOV     R5,SP           ;RESET SP FOR ERROR LOOP
060364  012702  060400                          MOV     #E0736,R2               ;IN CASE IT JUMPS TO ADDR IN RN
060370  000257                                  CCC                     ;SCOPE SYNC

060372  000102                          I0736:  JMP     R2              ;JMP MODE 0 FORCES TRAP - GO TO A0736

060374  010437  000004                          MOV     R4,@#4          ;RESTORE VECTOR POINTER AT LOC. 4
060400  104005                          E0736:  ERROR5                  ;ILLEGAL INSTR TRAP FAILED
060402  060350                                  R0736                   ;ERROR LOOP RETURN ADDRESS

060404  010437  000004                  A0736:  MOV     R4,@#4          ;RESTORE VECTOR POINTER AT LOC. 4
060410  010506                                  MOV     R5,SP           ;RESET SP

060412  000004                          00736:  SCOPE                   ;CALL THE SCOPE LOOP UTILITY
```

```
                                        ; ***********************************************************************
                                                .SBTTL T0737 BUS TIMEOUT TRAP TEST - TST (R)
                                        ; ***********************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:

                                        ;ACT BUTS:

                                        ;EXEC:

                                        ;CODES:

                                        ;SYNC:

                                        ;KEY SIG:

060414  012700  000737                  T0737:  MOV     #0737,R0                ;LOAD R0 WITH TEST NO.
060420  013701  060450                          MOV     @#T0737,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
060424  010505                                  MOV     SP,R5           ;SAVE SP
060426  013704  000004                  R0737:  MOV     @#4,R4          ;SAVE ORIGINAL T.O. VECTOR POINTER
060432  012737  060462  000004                  MOV     #A0737,@#4      ;ON T.O. TRAP - GO TO A0737
060440  012702  160000                          MOV     #160000,R2      ;R3 ADDRESS CAUSES T.O.
060444  010506                                  MOV     R5,SP           ;RESET SP FOR ERROR LOOP
060446  000257                                  CCC                     ;SCOPE SYNC

060450  005712                          I0737:  TST     (R2)            ;FORCE T.O. TRAP - GO TO A0737

060452  010437  000004                          MOV     R4,@#4          ;RESTORE T.O. VECTOR
060456  104005                          E0737:  ERROR5                  ;TIMEOUT TRAP FAILED
060460  060426                                  R0737                   ;ERROR LOOP RETURN ADDRESS
060462  010437  000004                  A0737:  MOV     R4,@#4          ;RESTORE T.O. VECTOR
060466  010506                                  MOV     R5,SP           ;RESET SP

060470  000004                          00737:  SCOPE                   ;CALL THE SCOPE LOOP UTILITY
```

```
                                        ; ***********************************************************************
                                                .SBTTL T0740 "T" BIT TRAP TEST
                                        ; ***********************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [104,373,362,002,015,010,216,215,115,326,327,113,330,331
                                                        ;077,140,332,333,123,015,013] FC 1,7,8,10,6,10
                                        ;ACT BUTS:      37[004]100,104 / 31[104]360,362 / 27[373]000,002 / 26[002]010,010
                                                        ;01[332]122,123 / 26[123]010,013
                                        ;EXEC:          [362] BUPP = 002 ("T" BIT TRAP)

                                        ;CODES:         N / A

                                        ;SYNC:          B05J2 (-) T = 8 USEC

                                        ;KEY SIG:       K5-2 PS(T)(1) H  /  K5-5 STPM3 H  /  K5-5 STPM2 H

060472  012700  000740          T0740:  MOV     #0740,R0                ;LOAD R0 WITH TEST NO.
060476  013701  060530                  MOV     @#I0740,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
060502  010605                          MOV     SP,R5           ;SAVE SP
060504  010506                  R0740:  MOV     R5,SP           ;RESET SP FOR ERROR LOOP
060506  012737  060540  000014          MOV     #A0740,@#14     ;GO TO A0740 WHEN "T" TRAP SPRUNG
060514  012746  000020                  MOV     #20,-(SP)       ;SET "T" BIT ON STACK
060520  012746  060530                  MOV     #I0740,-(SP)    ;SET UP NEW PC ON STACK
060524  000257                          CCC                     ;SCOPE SYNC
060526  000006                          RTT                     ;TURN ON "T" BIT - GO TO I0740

060530  005700                  I0740:  TST     R0              ;SPRING "T" BIT TRAP - GO TO A0740

060532  104005                  E10740: ERROR5                  ;NO "T" BIT TRAP OCCURRED
060534  060504                          R0740                   ;ERROR LOOP RETURN ADDRESS

060536  000406                          BR      B0740           ;GO EXIT

060540  032766  000020  000002  A0740:  BIT     #20,2(SP)       ;"T" BIT SET IN OLD PSW?
060546  001002                          BNE     B0740           ;BR IF YES

060550  104000                  E20740: ERROR                   ;#T# BIT NOT SAVED ON STACK
060552  060504                          R0740                   ;ERROR LOOP RETURN ADDRESS

060554  012737  000016  000014  B0740:  MOV     #16,@#14        ;RESTORE "T" BIT TRAP CATCHER
060562  005037  000016                  CLR     @#16
060566  010506                          MOV     R5,SP           ;RESET SP

060570  000004                  00740:  SCOPE                   ;CALL THE SCOPE LOOP UTILITY
```

```
                                        ; ***************************************************************
                                                .SBTTL T0741 TEST PUSH INTO PSW WITH [SP] = 000000
                                        ; ***************************************************************

                                        ;THESE NEXT TWO TESTS VERIFY THAT A "RED ZONE" TRAP OCCURS IF A
                                        ;PUSH IS ATTEMPTED WITH THE [SP] INITIALLY EQUAL TO 000000,177572,

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [142,240,250,174,257,200,JAMUPP,336,317,215,115
                                                        ; 326,327,113,330,331,077,140,332,333,123,015,013] FC 1,2,4,6,10
                                        ;ACT BUTS:      37[004]100,142 / 35[240]120,174 / 22[174]200,200 / 01[332]122,123
                                                        ; / 26[123]010,013

                                        ;EXEC:          [200] BUS STOP TRIGGERS JAMUPP LOGIC

                                        ;CODES:         N / A

                                        ;SYNC:          BOSJ2 (-) T = 10 USEC

                                        ;KEY SIG:       K4-6 PROC ADRS H  /  K4-4 BUS STOP H  /  K4-4 OVFLW ERR L  /  K4-3 JBERR
                                                        ; K4-3 JAMUPP L  /  K4-3 JAM CLK H  /  K4-3 PJAMSTART H  /  K5-5 STACK04

060572  012700  000741          T0741:  MOV     #0741,R0                ;LOAD R0 WITH TEST NO.
060576  013701  060622                  MOV     @#I0741,R1      ;LOAD R1 WITH COPY OF TEST INSTRUCTION
060602  010605                          MOV     SP,R5           ;SAVE THE SP
060604  013704  000004          R0741:  MOV     @#4,R4          ;SAVE THE BUS ERROR VECTOR
060610  012737  060646  000004          MOV     #A0741,@#4      ;"RED ZONE" TRAP GOES TO A0741
060616  005006                          CLR     SP              ;MAKE SP = 000000
060620  000257                          CCC                     ;SCOPE SYNC

060622  012746  177777          I0741:  MOV     #-1,-(SP)       ;ATTEMPT PUSH INTO PSW - SHOULD CAUSE
                                                                ;"RED ZONE" TRAP TO BE SPRUNG

060626  010437  000004                  MOV     R4,@#4          ;RESTORE BUS ERROR VECTOR
060632  005004                          CLR     R4              ;[R4] = S / B SP
060634  010603                          MOV     SP,R3           ;[R3] = WAS SP
060636  010506                          MOV     R5,SP           ;RESET THE SP
060640  104000                  E10741: ERROR                   ;TRAP NOT SPRUNG
060642  060604                          R0741                   ;ERROR LOOP RETURN ADDRESS
060644  000413                          BR      00741           ;GO TO SCOPE EXIT - SCHOOL'S OUT

060646  022706  000000          A0741:  CMP     #0,SP           ;WAS IT A RED ZONE TRAP ?
060652  001407                          BEQ     B0741           ;BR IF YES

060654  010437  000004                  MOV     R4,@#4          ;RESTORE BUS ERROR VECTOR
060660  005004                          CLR     R4              ;[R4]= S / B SP
060662  010603                          MOV     SP,R3           ;[R3] = WAS SP
060664  010506                          MOV     R5,SP           ;RESET THE SP
060666  104000                  E20741: ERROR                   ;TRAP SPRUNG BUT NOT RED ZONE
060670  060604                          R0741                   ;ERROR LOOP RETURN ADDRESS

060672  010506                  B0741:  MOV     R5,SP           ;FIX UP THE SP

060674  000004                  00741:  SCOPE                   ;CALL THE SCOPE LOOP UTILITY
```

```
                                        ; ***************************************************************
                                                .SBTTL T0742 TEST PUSH INTO SR WITH [SP] = 177572
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [142,240,250,174,257,200,JAMUPP 336,317,215,115
                                                        ; 326,327,113,330,331,077,140,332,333,123,015,013] FC 1,2,4,6,10
                                        ;ACT BUTS:      37[004]100,142 / 35[240]120,174 / 22[174]200,200 / 01[332]122,123
                                                        ; / 26[123]010,013

                                        ;EXEC:          [200] BUS STOP TRIGGERS JAMUPP LOGIC

                                        ;CODES:         N / A

                                        ;SYNC:          B05J2 (-) T = 10 USEC

                                        ;KEY SIG:       K4-6 PROC ADRS H  /  K4-4 BUS STOP  /  K4-4 OVFLW ERR L  /  K4-3 JBERR(1
                                                        ;4-3 JAMUPP L  /  K4-3 JAM CLK H  /  K4-3 PJAMSTART H  /  K5-5 STACKO4 H

060676  012700  000742          T0742:  MOV     #0742,R0                ;LOAD R0 WITH TEST NO.
060702  013701  060730                  MOV     @#I0742,R1      ;LOAD R1 WITH COPY OF TEST INSTRUCTION
060706  010605                          MOV     SP,R5           ;SAVE THE SP
060710  013704  000004          R0742:  MOV     @#4,R4          ;SAVE THE BUS ERROR VECTOR
060714  012737  060754  000004          MOV     #A0742,@#4      ;"RED ZONE" TRAP GOES TO A0742
060722  012706  177572                  MOV     #177572,SP      ;MAKE SP=177572
060726  000257                          CCC                     ;SCOPE SYNC

060730  012746  177777          I0742:  MOV     #-1,-(SP)       ;ATTEMPT PUSH INTO SR - SHOULD CAUSE
                                                                ;"RED ZONE" TRAP TO BE SPRUNG

060734  010437  000004                  MOV     R4,@#4          ;RESTORE BUS ERROR VECTOR
060740  005004                          CLR     R4              ;[R4] = S / B SP
060742  010603                          MOV     SP,R3           ;[R3] = WAS SP
060744  010506                          MOV     R5,SP           ;RESET THE SP
060746  104000          E10742: ERROR                           ;TRAP NOT SPRUNG
060750  060710                  R0742                           ;ERROR LOOP RETURN ADDRESS
060752  000413                  BR      00742                   ;GO TO SCOPE EXIT - SCHOOL'S OUT

060754  022706  000000          A0742:  CMP     #0,SP           ;WAS IT A RED ZONE TRAP ?
060760  001407                  BEQ     B0742                   ;BR IF YES

060762  010437  000004                  MOV     R4,@#4          ;RESTORE BUS ERROR VECTOR
060766  005004                          CLR     R4              ;[R4]= S / B SP
060770  010603                          MOV     SP,R3           ;[R3] = WAS SP
060772  010506                          MOV     R5,SP           ;RESET THE SP
060774  104000          E20742: ERROR                           ;TRAP SPRUNG BUT NOT RED ZONE
060776  060710                  R0742                           ;ERROR LOOP RETURN

061000  010506          B0742:  MOV     R5,SP           ;FIX UP THE SP

061002  000004          00742:  SCOPE                   ;CALL THE SCOPE LOOP UTILITY
```

```
                                        ; ***************************************************************
                                                .SBTTL T0743 TEST PUSH INTO SLR WITH [SP] = 177776
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [142,240,250,174,257,200,JAMUPP 336,317,215,115
                                                        ; 326,327,113,330,331,077,140,332,333,123,015,013] FC 1,2,4,6,10
                                        ;ACT BUTS:      37[004]100,142 / 35[240]120,174 / 22[174]200,200 / 01[332]122,123
                                                        ; / 26[123]010,013

                                        ;EXEC:          [200] BUS STOP TRIGGERS JAMUPP LOGIC

                                        ;CODES:         N / A

                                        ;SYNC:          B05J2 (-) T = 10 USEC

                                        ;KEY SIG:       K4-6 PROC ADRS H  /  K4-4 BUS STOP  /  K4-4 OVFLW ERR L  /  K4-3 JBERR(1
                                                        ;4-3 JAMUPP L  /  K4-3 JAM CLK H  /  K4-3 PJAMSTART H  /  K5-5 STACK04 H

061004  012700  000743          T0743:  MOV     #0743,R0                ;LOAD R0 WITH TEST NO.
061010  013701  061046                  MOV     @#I0743,R1      ;LOAD R1 WITH COPY OF TEST INSTRUCTION
061014  010605                          MOV     SP,R5           ;SAVE THE SP
061016  032737  000004  066636          BIT     #4,@#OPTION     ;IS KJ11 INSTALLED ??
061024  001435                          BEQ     00743           ;BR IF NOT - SKIP THIS TEST
061026  013704  000004          R0743:  MOV     @#4,R4          ;SAVE THE BUS ERROR VECTOR
061032  012737  061072  000004          MOV     #A0743,@#4      ;"RED ZONE" TRAP GOES TO A0743
061040  012706  177776                  MOV     #177776,SP      ;MAKE SP=177776
061044  000257                          CCC                     ;SCOPE SYNC

061046  012746  177777          I0743:  MOV     #-1,-(SP)       ;ATTEMPT PUSH INTO SR - SHOULD CAUSE
                                                                ;"RED ZONE" TRAP TO BE SPRUNG

061052  010437  000004                  MOV     R4,@#4          ;RESTORE BUS ERROR VECTOR
061056  005004                          CLR     R4              ;[R4] = S / B SP
061060  010603                          MOV     SP,R3           ;[R3] = WAS SP
061062  010506                          MOV     R5,SP           ;RESET THE SP
061064  104000                  E10743: ERROR                   ;TRAP NOT SPRUNG
061066  061026                          R0743                   ;ERROR LOOP RETURN ADDRESS
061070  000413                          BR      00743           ;GO TO SCOPE EXIT - SCHOOL'S OUT

061072  022706  000000          A0743:  CMP     #0,SP           ;WAS IT A RED ZONE TRAP ?
061076  001407                          BEQ     B0743           ;BR IF YES

061100  010437  000004                  MOV     R4,@#4          ;RESTORE BUS ERROR VECTOR
061104  005004                          CLR     R4              ;[R4]= S / B SP
061106  010603                          MOV     SP,R3           ;[R3] = WAS SP
061110  010506                          MOV     R5,SP           ;RESET THE SP
061112  104000                  E20743: ERROR                   ;TRAP SPRUNG BUT NOT RED ZONE
061114  061026                          R0743                   ;ERROR LOOP RETURN

061116  010506                  B0743:  MOV     R5,SP           ;FIX UP THE SP

061120  000004                  00743:  SCOPE                   ;CALL THE SCOPE LOOP UTILITY
```

```
061122  013737  000010  067606          MOV     @#10,@#MBUF1    ;SAVE RSVD INSTR VECTOR
061130  013737  000012  067610          MOV     @#12,@#MBUF1+2

                                ; ***********************************************************************
                                        .SBTTL T0744 RSVD INSTRUCTION TEST - 000007 THRU 000077
                                ; ***********************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [100,126,007,115,326,327,113,330,331,077,140,332,333,123,015,013] FC 1,6

                                ;ACT BUTS:      37[004]100,100 / 01[332]122,123 / 26[123]010,013

                                ;EXEC:          [115] D = 000000  /  [113] D = OLD PSW  /  [331] D = #I0744+2  /  [333]

                                ;CODES:         [140] SPS=7  /  N:C = 0000

                                ;SYNC:          B05J2 (-) T = 5.8 USEC

                                ;KEY SIG:       K3-6 RSVD INSTR L  /  K5-5 BC01 H  /  K5-3 BUT01 H  /  K5-3 BUT03 H
                                                ;  K5-3 BUT04 H

061136  012700  000744          T0744:  MOV     #0744,R0                ;LOAD R0 WITH TEST NO.
061142  010605                          MOV     SP,R5           ;SAVE THE SP
061144  012737  061200  000010          MOV     #A0744,@#10     ;SET UP RSVD INSTR. TRAP VECTOR
061152  005037  000012                  CLR     @#12
061156  012701  000007                  MOV     #7,R1           ;SET UP FIRST ONE IN GROUP
061162  010506                  R0744:  MOV     R5,SP           ;RESET SP FOR ERROR LOOP AND NEW INSTR
061164  010137  061172                  MOV     R1,@#I0744      ;LOAD NEW INSTR
061170  000257                          CCC                     ;SCOPE SYNC

061172  000007                  I0744:  000007                  ;TEST THE RSVD INSTR - THIS LOCATION
                                                                ;GETS CHANGED EACH PASS THROUGH

061174  104005                  E0744:  ERROR5                  ;RSVD INSTR. IN R1 FAILED TO TRAP
061176  061162                          R0744                   ;ERROR LOOP RETURN

061200  005201                  A0744:  INC     R1              ;GENERATE NEW RSVD INSTR
061202  022701  000100                  CMP     #100,R1         ;AT END OF THIS GROUP ??
061206  001365                          BNE     R0744           ;BR IF NOT

061210  010506                          MOV     R5,SP           ;MAKE SURE TO RESET THE SP
061212  000004                  00744:  SCOPE                   ;CALL THE SCOPE LOOP UTILITY
```

```
                                        ; ***********************************************************************
                                                .SBTTL T0745 RSVD INSTRUCTION TEST - 000210 THRU 000237
                                        ; ***********************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [100,126,007,115,326,327,113,330,331,077,140,332,333,123,015,013] FC 1,6

                                        ;ACT BUTS:      37[004]100,100 / 01[332]122,123 / 26[123]010,013

                                        ;EXEC:          [115] D = 000000  /  [113] D = OLD PSW  /  [331] D = #I0745+2  /  [333]

                                        ;CODES:         [140] SPS=7  /  N:C = 0000

                                        ;SYNC:          B05J2 (-) T = 5.8 USEC

                                        ;KEY SIG:       K3-6 RSVD INSTR L  /  K5-5 BC01 H  /  K5-3 BUT01 H  /  K5-3 BUT03 H
                                                        ;  K5-3 BUT04 H
                                                        ;K5-5 STPM3 H

061214  012700  000745          T0745:  MOV     #0745,R0                ;LOAD R0 WITH TEST NO.
061220  010605                          MOV     SP,R5           ;SAVE THE SP
061222  032737  040000  066642          BIT     #40000,@#BPTLOC ;BREAKPOINT HALT SET ??
061230  001401                          BEQ     .+4             ;BR IF NOT
061232  000000                          HALT                    ;BREAK-DEPRESS CONTINUE TO RESTART
061234  012737  061270  000010          MOV     #A0745,@#10     ;SET UP RSVD INSTR. TRAP VECTOR
061242  005037  000012                  CLR     @#12
061246  012701  000210                  MOV     #210,R1         ;SET UP FIRST ONE IN GROUP
061252  010506                  R0745:  MOV     R5,SP           ;RESET SP FOR ERROR LOOP AND NEW INSTR
061254  010137  061262                  MOV     R1,@#I0745      ;LOAD NEW INSTR
061260  000257                          CCC                     ;SCOPE SYNC

061262  000210                  I0745:  000210                  ;TEST THE RSVD INSTR - THIS LOCATION
                                                                ;GETS CHANGED EACH PASS THROUGH

061264  104005                  E0745:  ERROR5                  ;RSVD INSTR. IN R1 FAILED TO TRAP
061266  061252                          R0745                   ;ERROR LOOP RETURN

061270  005201                  A0745:  INC     R1              ;GENERATE NEW RSVD INSTR
061272  022701  000240                  CMP     #240,R1         ;AT END OF THIS GROUP ??
061276  001365                          BNE     R0745           ;BR IF NOT

061300  010506                          MOV     R5,SP           ;MAKE SURE TO RESET THE SP
061302  000004                  00745:  SCOPE                   ;CALL THE SCOPE LOOP UTILITY
```

```
                                        ; ***************************************************************
                                                .SBTTL T0746 RSVD INSTRUCTION TEST - 000065 THRU 000066
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [100,126,007,115,326,327,113,330,331,077,140,332,333,123,015,013] FC 1,6

                                        ;ACT BUTS:      37[004]100,100 / 01[332]122,123 / 26[123]010,013

                                        ;EXEC:          [115] D = 000000  /  [113] D = OLD PSW  /  [331] D = #I0746+2  /  [333]

                                        ;CODES:         [140] SPS=7  /  N:C = 0000

                                        ;SYNC:          B05J2 (-) T = 5.8 USEC

                                        ;KEY SIG:       K3-6 RSVD INSTR L  /  K5-5 BC01 H  /  K5-3 BUT01 H  /  K5-3 BUT03 H
                                                        ;  K5-3 BUT04 H
                                                        ;K5-5 STPM3 H

061304  012700  000746          T0746:  MOV     #0746,R0                ;LOAD R0 WITH TEST NO.
061310  105737  066636                  TSTB    @#OPTION        ;KT11D INSTALLED ??
061314  100424                          BMI     00746           ;SKIP THIS TEST IF YES
061316  010605                          MOV     SP,R5           ;SAVE THE SP
061320  012737  061354  000010          MOV     #A0746,@#10     ;SET UP RSVD INSTR. TRAP VECTOR
061326  005037  000012                  CLR     @#12
061332  012701  000065                  MOV     #65,R1          ;SET UP FIRST ONE IN GROUP
061336  010506                  R0746:  MOV     R5,SP           ;RESET SP FOR ERROR LOOP AND NEW INSTR
061340  010137  061346                  MOV     R1,@#I0746      ;LOAD NEW INSTR
061344  000257                          CCC                     ;SCOPE SYNC

061346  000065                  I0746:  000065                  ;TEST THE RSVD INSTR - THIS LOCATION
                                                                ;GETS CHANGED EACH PASS THROUGH

061350  104005                  E0746:  ERROR5                  ;RSVD INSTR. IN R1 FAILED TO TRAP
061352  061336                          R0746                   ;ERROR LOOP RETURN

061354  005201                  A0746:  INC     R1              ;GENERATE NEW RSVD INSTR
061356  022701  000067                  CMP     #67,R1          ;AT END OF THIS GROUP ??
061362  001365                          BNE     R0746           ;BR IF NOT

061364  010506                          MOV     R5,SP           ;MAKE SURE TO RESET THE SP
061366  000004                  00746:  SCOPE                   ;CALL THE SCOPE LOOP UTILITY
```

```
                                        ; ***************************************************************
                                                .SBTTL T0747 RSVD INSTRUCTION TEST - 007000 THRU 007777
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [100,126,007,115,326,327,113,330,331,077,140,332,333,123,015,013] FC 1,6

                                        ;ACT BUTS:      37[004]100,100 / 01[332]122,123 / 26[123]010,013

                                        ;EXEC:          [115] D = 000000  /  [113] D = OLD PSW  /  [331] D = #I0747+2  /  [333]

                                        ;CODES:         [140] SPS=7  /  N:C = 0000

                                        ;SYNC:          B05J2 (-) T = 5.8 USEC

                                        ;KEY SIG:       K3-6 RSVD INSTR L  /  K5-5 BC01 H  / K5-3 BUT01 H  /  K5-3 BUT03 H
                                                        ;  K5-3 BUT04 H
                                                        ;K5-5 STPM3 H

061370  012700  000747          T0747:  MOV     #0747,R0                ;LOAD R0 WITH TEST NO.
061374  032737  000001  066636          BIT     #1,@#OPTION     ;KE11-E (EIS) INSTALLED ??
061402  001024                          BNE     00747           ;SKIP THIS TEST IF YES
061404  010605                          MOV     SP,R5           ;SAVE THE SP
061406  012737  061442  000010          MOV     #A0747,@#10     ;SET UP RSVD INSTR. TRAP VECTOR
061414  005037  000012                  CLR     @#12
061420  012701  007000                  MOV     #7000,R1        ;SET UP FIRST ONE IN GROUP
061424  010506                  R0747:  MOV     R5,SP           ;RESET SP FOR ERROR LOOP AND NEW INSTR
061426  010137  061434                  MOV     R1,@#I0747      ;LOAD NEW INSTR
061432  000257                          CCC                     ;SCOPE SYNC

061434  007000                  I0747:  007000                  ;TEST THE RSVD INSTR - THIS LOCATION
                                                                ;GETS CHANGED EACH PASS THROUGH

061436  104005                  E0747:  ERROR5                  ;RSVD INSTR. IN R1 FAILED TO TRAP
061440  061424                          R0747                   ;ERROR LOOP RETURN

061442  005201                  A0747:  INC     R1              ;GENERATE NEW RSVD INSTR
061444  022701  010000                  CMP     #10000,R1       ;AT END OF THIS GROUP ??
061450  001365                          BNE     R0747           ;BR IF NOT

061452  010506                          MOV     R5,SP           ;MAKE SURE TO RESET THE SP
061454  000004                  00747:  SCOPE                   ;CALL THE SCOPE LOOP UTILITY
```

```
                                        ; ***************************************************************
                                                .SBTTL T0750 RSVD INSTRUCTION TEST - 070000 THRU 073777
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [100,126,007,115,326,327,113,330,331,077,140,332,333,123,015,013] FC 1,6

                                        ;ACT BUTS:      37[004]100,100 / 01[332]122,123 / 26[123]010,013

                                        ;EXEC:          [115] D = 000000  /  [113] D = OLD PSW  /  [331] D = #I0750+2  /  [333]

                                        ;CODES:         [140] SPS=7  /  N:C = 0000

                                        ;SYNC:          BOSJ2 (-) T = 5.8 USEC

                                        ;KEY SIG:       K3-6 RSVD INSTR L  /  K5-5 BC01 H  /  K5-3 BUT01 H  /  K5-3 BUT03 H
                                                        ;  K5-3 BUT04 H
                                                        ;K5-5 STPM3 H

061456  012700  000750          T0750:  MOV     #0750,R0                ;LOAD R0 WITH TEST NO.
061462  032737  000001  066636          BIT     #1,@#OPTION     ;IS THE KE11-E INSTALLED ??
061470  001024                          BNE     00750           ;BR IF YES - SKIP THIS TEST
061472  010605                          MOV     SP,R5           ;SAVE THE SP
061474  012737  061530  000010          MOV     #A0750,@#10     ;SET UP RSVD INSTR. TRAP VECTOR
061502  005037  000012                  CLR     @#12
061506  012701  070000                  MOV     #70000,R1       ;SET UP FIRST ONE IN GROUP
061512  010506                  R0750:  MOV     R5,SP           ;RESET SP FOR ERROR LOOP AND NEW INSTR
061514  010137  061522                  MOV     R1,@#I0750      ;LOAD NEW INSTR
061520  000257                          CCC                     ;SCOPE SYNC

061522  070000                  I0750:  070000                  ;TEST THE RSVD INSTR - THIS LOCATION
                                                                ;GETS CHANGED EACH PASS THROUGH

061524  104005                  E0750:  ERROR5                  ;RSVD INSTR. IN R1 FAILED TO TRAP
061526  061512                          R0750                   ;ERROR LOOP RETURN

061530  005201                  A0750:  INC     R1              ;GENERATE NEW RSVD INSTR
061532  022701  074000                  CMP     #74000,R1       ;AT END OF THIS GROUP ??
061536  001365                          BNE     R0750           ;BR IF NOT

061540  010506                          MOV     R5,SP           ;MAKE SURE TO RESET THE SP
061542  000004                  00750:  SCOPE                   ;CALL THE SCOPE LOOP UTILITY
```

```
                                        ; ***********************************************************************
                                                .SBTTL T0751 RSVD INSTRUCTION TEST - 075000 THRU 075037
                                        ; ***********************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [100,126,007,115,326,327,113,330,331,077,140,332,333,123,015,013] FC 1,6

                                        ;ACT BUTS:      37[004]100,100 / 01[332]122,123 / 26[123]010,013

                                        ;EXEC:          [115] D = 000000  /  [113] D = OLD PSW  /  [331] D = #I0751+2  /  [333]

                                        ;CODES:         [140] SPS=7  /  N:C = 0000

                                        ;SYNC:          B05J2 (-) T = 5.8 USEC

                                        ;KEY SIG:       K3-6 RSVD INSTR L  /  K5-5 BC01 H  /  K5-3 BUT01 H  /  K5-3 BUT03 H
                                                        ;  K5-3 BUT04 H
                                                        ;K5-5 STPM3 H

061544  012700  000751          T0751:  MOV     #0751,R0                ;LOAD R0 WITH TEST NO.
061550  032737  000002  066636          BIT     #2,@#OPTION     ;KE11-F (FIS) INSTALLED ??
061556  001024                          BNE     00751           ;SKIP TEST IF YES
061560  010605                          MOV     SP,R5           ;SAVE THE SP
061562  012737  061616  000010          MOV     #A0751,@#10     ;SET UP RSVD INSTR. TRAP VECTOR
061570  005037  000012                  CLR     @#12
061574  012701  075000                  MOV     #75000,R1       ;SET UP FIRST ONE IN GROUP
061600  010506                  R0751:  MOV     R5,SP           ;RESET SP FOR ERROR LOOP AND NEW INSTR
061602  010137  061610                  MOV     R1,@#I0751      ;LOAD NEW INSTR
061606  000257                          CCC                     ;SCOPE SYNC

061610  075000                  I0751:  75000                   ;TEST THE RSVD INSTR - THIS LOCATION
                                                                ;GETS CHANGED EACH PASS THROUGH

061612  104005                  E0751:  ERROR5                  ;RSVD INSTR. IN R1 FAILED TO TRAP
061614  061600                          R0751                   ;ERROR LOOP RETURN

061616  005201                  A0751:  INC     R1              ;GENERATE NEW RSVD INSTR
061620  022701  075040                  CMP     #75040,R1       ;AT END OF THIS GROUP ??
061624  001365                          BNE     R0751           ;BR IF NOT

061626  010506                          MOV     R5,SP           ;MAKE SURE TO RESET THE SP
061630  000004                  00751:  SCOPE                   ;CALL THE SCOPE LOOP UTILITY
```

```
                                        ; ***********************************************************************
                                                .SBTTL T0752 RSVD INSTRUCTION TEST - 075040 THRU 076777
                                        ; ***********************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [100,126,007,115,326,327,113,330,331,077,140,332,333,123,015,013] FC 1,6

                                        ;ACT BUTS:      37[004]100,100 / 01[332]122,123 / 26[123]010,013

                                        ;EXEC:          [115] D = 000000  /  [113] D = OLD PSW  /  [331] D = #T0752+2  /  [333]

                                        ;CODES:         [140] SPS=7  /  N:C = C000

                                        ;SYNC:          B05J2 (-) T = 5.8 USEC

                                        ;KEY SIG:       K3-6 RSVD INSTR L  /  K5-5 BC01 H  /  K5-3 BUT01 H  /  K5-3 BUT03 H
                                                        ;  K5-3 BUT04 H
                                                        ;K5-5 STPM3 H

061632  012700  000752          T0752:  MOV     #0752,R0                ;LOAD R0 WITH TEST NO.
061636  010605                          MOV     SP,R5           ;SAVE THE SP
061640  012737  061674  000010          MOV     #A0752,@#10     ;SET UP RSVD INSTR. TRAP VECTOR
061646  005037  000012                  CLR     @#12
061652  012701  075040                  MOV     #75040,R1       ;SET UP FIRST ONE IN GROUP
061656  010506                  R0752:  MOV     R5,SP           ;RESET SP FOR ERROR LOOP AND NEW INSTR
061660  010137  061666                  MOV     R1,@#T0752      ;LOAD NEW INSTR
061664  000257                          CCC                     ;SCOPE SYNC

061666  075040                  T0752:  75040                   ;TEST THE RSVD INSTR - THIS LOCATION
                                                                ;GETS CHANGED EACH PASS THROUGH

061670  104005                  E0752:  ERROR5                  ;RSVD INSTR. IN R1 FAILED TO TRAP
061672  061656                          R0752                   ;ERROR LOOP RETURN

061674  005201                  A0752:  INC     R1              ;GENERATE NEW RSVD INSTR
061676  022701  077000                  CMP     #77000,R1       ;AT END OF THIS GROUP ??
061702  001365                          BNE     R0752           ;BR IF NOT

061704  010506                          MOV     R5,SP           ;MAKE SURE TO RESET THE SP
061706  000004                  G0752:  SCOPE                   ;CALL THE SCOPE LOOP UTILITY
```

```
                                        ; ***********************************************************
                                                .SBTTL T0753 RSVD INSTRUCTION TEST - 106400 THRU 107777
                                        ; ***********************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [100,126,007,115,326,327,113,330,331,077,140,332,333,123,015,013] FC 1,6

                                        ;ACT BUTS:      37[004]100,100 / 01[332]122,123 / 26[123]010,013

                                        ;EXEC:          [115] D = 000000  /  [113] D = OLD PSW  /  [331] D = #I0753+2  /  [333]

                                        ;CODES:         [140] SPS=7  /  N:C = 0000

                                        ;SYNC:          BOSJ2 (-) T = 5.8 USEC

                                        ;KEY SIG:       K3-6 RSVD INSTR L  /  K5-5 BC01 H  /  K5-3 BUT01 H  /  K5-3 BUT03 H
                                                        ;  K5-3 BUT04 H
                                                        ;K5-5 STPM3 H

061710  012700  000753          T0753:  MOV     #0753,R0                ;LOAD R0 WITH TEST NO.
061714  032737  000200  066636          BIT     #200,@#OPTION   ;IS THE KT11-D INSTALLED ??
061722  001024                          BNE     00753           ;BR IF YES - SKIP THIS TEST
061724  010605                          MOV     SP,R5           ;SAVE THE SP
061726  012737  061762  000010          MOV     #A0753,@#10     ;SET UP RSVD INSTR. TRAP VECTOR
061734  005037  000012                  CLR     @#12
061740  012701  106400                  MOV     #106400,R1      ;SET UP FIRST ONE IN GROUP
061744  010506                  R0753:  MOV     R5,SP           ;RESET SP FOR ERROR LOOP AND NEW INSTR
061746  010137  061754                  MOV     R1,@#I0753      ;LOAD NEW INSTR
061752  000257                          CCC                     ;SCOPE SYNC

061754  106400                  I0753:  106400                  ;TEST THE RSVD INSTR - THIS LOCATION
                                                                ;GETS CHANGED EACH PASS THROUGH

061756  104005                  E0753:  ERROR5                  ;RSVD INSTR. IN R1 FAILED TO TRAP
061760  061744                          R0753                   ;ERROR LOOP RETURN

061762  005201                  A0753:  INC     R1              ;GENERATE NEW RSVD INSTR
061764  022701  110000                  CMP     #110000,R1      ;AT END OF THIS GROUP ??
061770  001365                          BNE     R0753           ;BR IF NOT

061772  010506                          MOV     R5,SP           ;MAKE SURE TO RESET THE SP
061774  000004                  00753:  SCOPE                   ;CALL THE SCOPE LOOP UTILITY
```

```
                                        ; ***********************************************************************
                                                .SBTTL T0754 RSVD INSTRUCTION TEST - 170000 THRU 177777
                                        ; ***********************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [100,126,007,1115,326,327,113,330,331,077,140,332,333,123,015,013] FC 1,

                                        ;ACT BUTS:      37[004]100,100 / 01[332]122,123 / 26[123]010,013

                                        ;EXEC:          [115] D = 000000  /  [113] D = OLD PSW  /  [331] D = #T0754+2  /  [333]

                                        ;CODES:         [140] SPS=7  /  N:C = 0000

                                        ;SYNC:          B05J2 (-) T = 5.8 USEC

                                        ;KEY SIG:       K3-6 RSVD INSTR L  /  K5-5 BC01 H  /  K5-3 BUT01 H  /  K5-3 BUT03 H
                                                        ;  K5-3 BUT04 H
                                                        ;K5-5 STPM3 H

061776  012700  000754          T0754:  MOV     #0754,R0                ;LOAD R0 WITH TEST NO.
062002  010605                          MOV     SP,R5           ;SAVE THE SP
062004  012737  062040  000010          MOV     #A0754,@#10     ;SET UP RSVD INSTR. TRAP VECTOR
062012  005037  000012                  CLR     @#12
062016  012701  170000                  MOV     #170000,R1      ;SET UP FIRST ONE IN GROUP
062022  010506                  R0754:  MOV     R5,SP           ;RESET SP FOR ERROR LOOP AND NEW INSTR
062024  010137  062032                  MOV     R1,@#I0754      ;LOAD NEW INSTR
062030  000257                          CCC                     ;SCOPE SYNC

062032  170000                  I0754:  170000                  ;TEST THE RSVD INSTR - THIS LOCATION
                                                                ;GETS CHANGED EACH PASS THROUGH

062034  104005                  E0754:  ERROR5                  ;RSVD INSTR. IN R1 FAILED TO TRAP
062036  062022                          R0754                   ;ERROR LOOP RETURN

062040  005201                  A0754:  INC     R1              ;GENERATE NEW RSVD INSTR
062042  022701  000000                  CMP     #0,R1           ;AT END OF THIS GROUP ??
062046  001365                          BNE     R0754           ;BR IF NOT

062050  010506                          MOV     R5,SP           ;MAKE SURE TO RESET THE SP
062052  000004                  C0754:  SCOPE                   ;CALL THE SCOPE LOOP UTILITY
062054  013737  067606  000010          MOV     @#MBUF1,@#10    ;RESTORE RSVD INSTR VECTOR
062062  013737  067610  000012          MOV     @#MBUF1+2,@#12
```

```
062070  012737  065026  000014  TSET:   MOV     #TBSER,@#14     ;SET UP THE "T" BIT TRAP VECTOR
062076  012737  000340  000016          MOV     #340,@#16       ;PRIORITY 7
062104  012737  062104  066654  DMRET:  MOV     #DMRET,@#RETURN ;INITIALIZE SCOPE LOOP RETURN

                                ; ***********************************************************************
                                .SBTTL T0755 BUT SERVICE TEST IN ROM LOCATION 373 - (TST %R)
                                ; ***********************************************************************

                                ;THIS NEXT GROUP OF 28 SEQUENTIAL TESTS VERIFIES THAT A "T" BIT
                                ;TRAP CAN BE SERVICED IN EACH MICROWORD THAT DOES A "BUT SERVICE"
                                ;EACH ROUTINE ENTERS THE TRAP MICROUTINE WHEN THE TRAP IS SPRUNG
                                ;WHICH GENERATES THE FOLLOWING ROM SEQUENCE:

                                        ;[010,216,215,115,326,327,113,330,331,077,140,332,333,
                                        ;123,015,013]  FC 6,10,1

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [104,373,362,002,015,TRAP MICOROUTINE] FC 1,7,8,10,6

                                ;ACT BUTS:      37[004]100,104  /  27[373]000,002  /  26[002]010,010

                                ;EXEC:          [362] BUPP=002 ("T" BIT TRAP)

                                ;CODES:         N / A

                                ;SYNC:          B05J2  (-)

                                ;KEY SIG:       K5-2 2S (T) (1) H  /  K3-7 SERVICE H  /  K5-5 STPM3 H
                                ;               K5-5 STPM2 H

062112  012700  000755          T0755:  MOV     #0755,R0                ;LOAD R0 WITH TEST NO.
062116  013701  062142                  MOV     @#I0755,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
062122  010605                          MOV     SP,R5           ;SAVE THE SP
062124  010506          R0755:          MOV     R5,SP           ;RESTORE SP FOR ERROR LOOPING
062126  012746  000020                  MOV     #20,-(SP)       ;SET "T" BIT IN THE NEW PSW
062132  012746  062142                  MOV     #I0755,-(SP)    ;MAKE NEW PC = I0755
062136  000257                          CCC                     ;SCOPE SYNC
062140  000006                          RTT                     ;SET "T" BIT - GO TO I0755

062142  005700          I0755:  TST     R0              ;TST INSTRUCTION SHOULD SPRING TRAP

062144  104005          E0755:  ERROR5                  ;BUT SERVICE IN 373 FAILED
062146  062124                  R0755                   ;ERROR LOOP RETURN

062150  000004          00755:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***********************************************************************
                                        .SBTTL T0756 BUT SERVICE TEST IN ROM LOCATION 366 - (BISB RA,(RB))
                                        ; ***********************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [161,266,267,270,230,254,074,366,375,017,015,
                                        ;               TRAP MICROROUTINE] FC 1,3,8,10,6
                                        ;ACT BUTS:      37[004]100,161  /  33[266]220,237  /  34[237]220,230
                                        ;               16[366]016,017  /  26[017]010,010
                                        ;EXEC:          [375] BUPP=017 ("T" BIT TRAP)

                                        ;CODES:         N / A

                                        ;SYNC:          B05J2  (-)

                                        ;KEY SIG:       K5-2 PS (T) (1) H  /  K3-7 SERVICE H  /  K5-5 STPM3 H
                                        ;               K5-5 STPM2 H

062152  012700  000756          T0756:  MOV     #0756,R0                ;LOAD R0 WITH TEST NO.
062156  013701  062206                  MOV     @#I0756,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
062162  010605                          MOV     SP,R5           ;SAVE THE SP
062164  010506          R0756:          MOV     R5,SP           ;RESTORE SP FOR ERROR LOOPING
062166  012702  067603                  MOV     #MBUF0+1,R2     ;DEST ADDR = MBUF0
062172  012746  000020                  MOV     #20,-(SP)       ;SET "T" BIT IN THE NEW PSW
062176  012746  062206                  MOV     #I0756,-(SP)    ;MAKE NEW PC = I0756
062202  000257                          CCC                     ;SCOPE SYNC
062204  000006                          RTT                     ;SET "T" BIT - GO TO I0756

062206  150012          I0756:  BISB    R0,(R2)         ;BISB INSTRUCTION SHOULD SPRING TRAP

062210  104005          E0756:  ERROR5                  ;BUT SERVICE IN 366 FAILED
062212  062164                  R0756                   ;ERROR LOOP RETURN

062214  000004          00756:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***********************************************************************
                                        .SBTTL T0757 BUT SERVICE TEST IN ROM LOCATION 367 - (SXT (RN))
                                        ; ************************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [161,266,267,234,367,375,017,015,TRAP MICROROUTINE]
                                        ;               FC 1,3,8,10,6
                                        ;ACT BLTS:      37[004]100,161  /  33[266]220,234  /  16[367]016,017
                                        ;               26[017]010,010

                                        ;EXEC:          [375] BUPP=017 ("T" BIT TRAP)

                                        ;CODES:         N / A

                                        ;SYNC:          B05J2  (-)

                                        ;KEY SIG:       K5-2 PS (T) (1) H  /  K3-7 SERVICE H  /  K5-5 STPM3 H
                                        ;               K5-5 STPM2 H

062216  012700  000757                  T0757:  MOV     #0757,R0                ;LOAD R0 WITH TEST NO.
062222  013701  062252                          MOV     @#I0757,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
062226  010605                                  MOV     SP,R5           ;SAVE THE SP
062230  010506                          R0757:  MOV     R5,SP           ;RESTORE SP FOR ERROR LOOPING
062232  012702  067602                          MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
062236  012746  000020                          MOV     #20,-(SP)       ;SET "T" BIT IN THE NEW PSW
062242  012746  062252                          MOV     #I0757,-(SP)    ;MAKE NEW PC = I0757
062246  000257                                  CCC                     ;SCOPE SYNC
062250  000006                                  RTT                     ;SET "T" BIT - GO TO I0757

062252  006712                          I0757:  SXT     (R2)            ;SXT INSTRUCTION SHOULD SPRING TRAP

062254  104005                          E0757:  ERROR5                  ;BUT SERVICE IN 367 FAILED
062256  062230                                  R0757                   ;ERROR LOOP RETURN

062260  000004                          00757:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***********************************************************************
                                        .SBTTL T0760 BUT SERVICE TEST IN ROM LOCATION 132 - (SXT %R)
                                        ; ***********************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [132,360,002,015,TRAP MICROROUTINE] FC 1,8,10,6

                                        ;ACT BUTS:      37[004]100,132  /  27[132]000,002  /  26[002]010,010

                                        ;EXEC:          [360] BUPP=002 ("T" BIT TRAP)

                                        ;CODES:         N / A

                                        ;SYNC:          B05J2  (-)

                                        ;KEY SIG:       K5-2 PS (T) (1) H  /  K3-7 SERVICE H  /  K5-5 STPM3 H
                                        ;               K5-5 STPM2 H

062262  012700  000760          T0760:  MOV     #0760,R0                ;LOAD R0 WITH TEST NO.
062266  013701  062312                  MOV     @#I0760,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
062272  010605                          MOV     SP,R5           ;SAVE THE SP
062274  010506          R0760:          MOV     R5,SP           ;RESTORE SP FOR ERROR LOOPING
062276  012746  000020                  MOV     #20,-(SP)       ;SET "T" BIT IN THE NEW PSW
062302  012746  062312                  MOV     #I0760,-(SP)    ;MAKE NEW PC = I0760
062306  000257                          CCC                     ;SCOPE SYNC
062310  000006                          RTT                     ;SET "T" BIT - GO TO I0760

062312  006702          I0760:  SXT     R2              ;SXT INSTRUCTION SHOULD SPRING TRAP

062314  104005          E0760:  ERROR5                  ;BUT SERVICE IN 132 FAILED
062316  062274                  R0760                   ;ERROR LOOP RETURN

062320  000004          00760:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***********************************************************************
                                        .SBTTL T0761 BUT SERVICE TEST IN ROM LOCATION 372 - (NEG %R)
                                        ; ***********************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [105,372,360,002,015,TRAP MICROROUTINE] FC 1,7,8,10,6

                                        ;ACT BUTS:      37[004]100,105  /  31[105]360,360  /  27[372]000,002
                                        ;               26[002]010,010

                                        ;EXEC:          [360] BUPP=002 ("T" BIT TRAP)

                                        ;CODES:         N / A

                                        ;SYNC:          B05J2  (-)

                                        ;KEY SIG:       K5-2 PS (T) (1) H  /  K3-7 SERVICE H  /  K5-5 STPM3 H
                                        ;               K5-5 STPM2 H

062322  012700  000761                  T0761:  MOV     #0761,R0                ;LOAD R0 WITH TEST NO.
062326  013701  062352                          MOV     @#I0761,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
062332  010605                                  MOV     SP,R5           ;SAVE THE SP
062334  010506                          R0761:  MOV     R5,SP           ;RESTORE SP FOR ERROR LOOPING
062336  012746  000020                          MOV     #20,-(SP)       ;SET "T" BIT IN THE NEW PSW
062342  012746  062352                          MOV     #I0761,-(SP)    ;MAKE NEW PC = I0761
062346  000257                                  CCC                     ;SCOPE SYNC
062350  000006                                  RTT                     ;SET "T" BIT - GO TO I0761

062352  005402                          I0761:  NEG     R2              ;NEG INSTRUCTION SHOULD SPRING TRAP

062354  104005                          E0761:  ERROR5                  ;BUT SERVICE IN 372 FAILED
062356  062334                                  R0761                   ;ERROR LOOP RETURN

062360  000004                          00761:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***********************************************************************
                                        .SBTTL T0762 BUT SERVICE TEST IN ROM LOCATION 370 - (SUB (RA),RB)
                                        ; ***********************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [141,247,250,121,370,360,002,015,TRAP MICROROUTINE]
                                        ;               FC 1,2,8,10,6

                                        ;ACT BUTS:      37[004]100,141  /  35[247]120,121  /  27[370]000,002
                                        ;               26[002]010,010

                                        ;EXQC:  [360] BUPP=002 ("T" BIT TRAP)

                                        ;CODES:         N / A

                                        ;SYNC:          BOSJ2  (-)

                                        ;KEY SIG:       K5-2 PS (T) (1) H  /  K3-7 SERVICE H  /  K5-5 STPM3 H
                                        ;               K5-5 STPM2 H

062362  012700  000762                  T0762:  MOV     #0762,R0                ;LOAD R0 WITH TEST NO.
062366  013701  062416                          MOV     @#I0762,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
062372  010605                                  MOV     SP,R5           ;SAVE THE SP
062374  010506                          R0762:  MOV     R5,SP           ;RESTORE SP FOR ERROR LOOPING
062376  012703  067602                          MOV     #MBUF0,R3       ;SOURCE ADDR = MBUF0
062402  012746  000020                          MOV     #20,-(SP)       ;SET "T" BIT IN THE NEW PSW
062406  012746  062416                          MOV     #I0762,-(SP)    ;MAKE NEW PC = I0762
062412  000257                                  CCC                     ;SCOPE SYNC
062414  000006                                  RTT                     ;SET "T" BIT - GO TO I0762

062416  161302                          I0762:  SUB     (R3),R2         ;SUB INSTRUCTION SHOULD SPRING TRAP

062420  104005                          E0762:  ERROR5                  ;BUT SERVICE IN 370 FAILED
062422  062374                                  R0762                   ;ERROR LOOP RETURN

062424  000004                          00762:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                .SBTTL T0763 BUT SERVICE TEST IN ROM LOCATION 371 - (ADD (RA),RB)
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [141,247,250,120,371,360,002,015,TRAP MICROROUTINE]
                                ;               FC 1,2,8,10,6

                                ;ACT BUTS:      37[004]100,141  /  35[247]120,120  /  31[120]360,360
                                ;               27[371]000,002  /  26[002]010,010

                                ;EXEC:          [360] BUPP=002 ("T" BIT TRAP)

                                ;CODES:         N / A

                                ;SYNC:          B05J2  (-)

                                ;KEY SIG:       K5-2 PS (T) (1) H  /  K3-7 SERVICE H  /  K5-5 STPM3 H
                                ;               K5-5 STPM2 H

062426  012700  000763          T0763:  MOV     #0763,R0                ;LOAD R0 WITH TEST NO.
062432  013701  062462                  MOV     @#I0763,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
062436  010605                          MOV     SP,R5           ;SAVE THE SP
062440  010506                  R0763:  MOV     R5,SP           ;RESTORE SP FOR ERROR LOOPING
062442  012705  037602                  MOV     #MBUF0,R5       ;SOURCE ADDR = MBUF0
062446  012746  000020                  MOV     #20,-(SP)       ;SET "T" BIT IN THE NEW PSW
062452  012746  062462                  MOV     #I0763,-(SP)    ;MAKE NEW PC = I0763
062456  000257                          CCC                     ;SCOPE SYNC
062460  000006                          RTT                     ;SET "T" BIT - GO TO I0763

062462  061502                  I0763:  ADD     (R5),R2         ;ADD INSTRUCTION SHOULD SPRING TRAP

062464  104005                  E0763:  ERROR5                  ;BUT SERVICE IN 371 FAILED
062466  062440                          R0763                   ;ERROR LOOP RETURN

062470  000004                  00763:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***********************************************************************
                                .SBTTL T0764 BUT SERVICE TEST IN ROM LOCATION 135 - (SWAB %R)
                                ; ***********************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [134,135,360,002,015,TRAP MICROROUTINE] FC 1,7,8,10,6

                                ;ACT BUTS:      37[004]100,134  /  27[135]000,002  /  26[002]010,010

                                ;EXEC:          [135] BUPP=002 ("T" BIT TRAP)

                                ;CODES:         N / A

                                ;SYNC:          B05J2  (-)

                                ;KEY SIG:       K5-2 PS (T) (1) H  /  K3-7 SERVICE H  /  K5-5 STPM3 H
                                ;               K5-5 STPM2 H

062472  012700  000764          T0764:  MOV     #0764,R0                ;LOAD R0 WITH TEST NO.
062476  013701  062522                  MOV     @#I0764,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
062502  010605                          MOV     SP,R5           ;SAVE THE SP
062504  010506                  R0764:  MOV     R5,SP           ;RESTORE SP FOR ERROR LOOPING
062506  012746  000020                  MOV     #20,-(SP)       ;SET "T" BIT IN THE NEW PSW
062512  012746  062522                  MOV     #I0764,-(SP)    ;MAKE NEW PC = I0764
062516  000257                          CCC                     ;SCOPE SYNC
062520  000006                          RTT                     ;SET "T" BIT - GO TO I0764

062522  000302                  I0764:  SWAB    R2              ;SWAB INSTRUCTION SHOULD SPRING TRAP

062524  104005                  E0764:  ERROR5                  ;BUT SERVICE IN 135 FAILED
062526  062504                          R0764                   ;ERROR LOOP RETURN

062530  000004                  00764:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***********************************************************************
                                        .SBTTL T0765 BUT SERVICE TEST IN ROM LOCATION 363 - (SUB RA,RB)
                                        ; ***********************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [103,363,360,002,015,TRAP MICROROUTINE] FC 1,7,8,10,6

                                        ;ACT BUTS:      37[004]100,103  /  27[363]000,002  /  26[002]010,010

                                        ;EXEC:          [360] BUPP=002 ("T" BIT TRAP)

                                        ;CODES:         N / A

                                        ;SYNC:          BOSJ2  (-)

                                        ;KEY SIG:       K5-2 PS (T) (1) H  /  K3-7 SERVICE H  /  K5-5 STPM3 H
                                        ;               K5-5 STPM2 H

062532  012700  000765          T0765:  MOV     #0765,R0                ;LOAD R0 WITH TEST NO.
062536  013701  062562                  MOV     @#I0765,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
062542  010605                          MOV     SP,R5           ;SAVE THE SP
062544  010506          R0765:          MOV     R5,SP           ;RESTORE SP FOR ERROR LOOPING
062546  012746  000020                  MOV     #20,-(SP)       ;SET "T" BIT IN THE NEW PSW
062552  012746  062562                  MOV     #I0765,-(SP)    ;MAKE NEW PC = I0765
062556  000257                          CCC                     ;SCOPE SYNC
062560  000006                          RTT                     ;SET "T" BIT - GO TO I0765

062562  160304          I0765:  SUB     R3,R4           ;SUB INSTRUCTION SHOULD SPRING TRAP

062564  104005          E0765:  ERRORS                  ;BUT SERVICE IN 363 FAILED
062566  062544                  R0765                   ;ERROR LOOP RETURN

062570  000004          00765:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***********************************************************************
                                        .SBTTL T0766 BUT SERVICE TEST IN ROM LOCATION 364 - (ADD RA,RB)
                                        ; ***********************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [102,364,360,002,015,TRAP MICROROUTINE] FC 1,7,8,10,6

                                        ;ACT BUTS:      37[004]100,102  /  31[102]360,360  /  27[364]000,002
                                        ;               26[002]010,010

                                        ;EXEC:          [360] BUP°=002 ("T" BIT TRAP)

                                        ;CODES:         N / A

                                        ;SYNC:          B05J2  (-)

                                        ;KEY SIG:       K5-2 PS (T) (1) H  /  K3-7 SERVICE H  /  K5-5 STPM3 H
                                        ;               K5-5 STPM2 H

062572  012700  000766          T0766:  MOV     #0766,R0                ;LOAD R0 WITH TEST NO.
062576  013701  062622                  MOV     @#I0766,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
062602  010605                          MOV     SP,R5           ;SAVE THE SP
062604  010506          R0766:          MOV     R5,SP           ;RESTORE SP FOR ERROR LOOPING
062606  012746  000020                  MOV     #20,-(SP)       ;SET "T" BIT IN THE NEW PSW
062612  012746  062622                  MOV     #I0766,-(SP)    ;MAKE NEW PC = I0766
062616  000257                          CCC                     ;SCOPE SYNC
062620  000006                          RTT                     ;SET "T" BIT - GO TO I0766

062622  060304          I0766:  ADD     R3,R4           ;ADD INSTRUCTION SHOULD SPRING TRAP

062624  104005          E0766:  ERRORS                  ;BUT SERVICE IN 364 FAILED
062626  062604                  R0766                   ;ERROR LOOP RETURN

062630  000004          00766:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***********************************************************************
                                .SBTTL T0767 BUT SERVICE TEST IN ROM LOCATION 125 - (MOV RA,(RB))
                                ; ***********************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [171,257,201,125,375,017,015,TRAP MICROROUTINE] FC 1,4,8,10,6

                                ;ACT BUTS:      37[004]100,171  /  22[171]200,201  /  16[125]016,017
                                ;               26[017]010,010

                                ;EXEC:          [375] BUPP=017 ("T" BIT TRAP)

                                ;CODES:         N / A

                                ;SYNC:          BOSJ2  (-)

                                ;KEY SIG:       K5-2 PS (T) (1) H  /  K3-7 SERVICE H  /  K5-5 STPM3 H
                                ;               K5-5 STPM2 H

062632  012700  000767          T0767:  MOV     #0767,R0                ;LOAD R0 WITH TEST NO.
062636  013701  062666                  MOV     @#I0767,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
062642  010605                          MOV     SP,R5           ;SAVE THE SP
062644  012702  067602                  MOV     #MBUF0,R2       ;DEST ADDR = MBUF0
062650  010506                  R0767:  MOV     R5,SP           ;RESTORE SP FOR ERROR LOOPING
062652  012746  000020                  MOV     #20,-(SP)       ;SET "T" BIT IN THE NEW PSW
062656  012746  062666                  MOV     #I0767,-(SP)    ;MAKE NEW PC = I0767
062662  000257                          CCC                     ;SCOPE SYNC
062664  000006                          RTT                     ;SET "T" BIT - GO TO I0767

062666  010012                  I0767:  MOV     R0,(R2)         ;MOV INSTRUCTION SHOULD SPRING TRAP

062670  104005                  E0767:  ERROR5                  ;BUT SERVICE IN 125 FAILED
062672  062650                          R0767                   ;ERROR LOOP RETURN

062674  000004                  00767:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***********************************************************************
                                        .SBTTL T0770 BUT SERVICE TEST IN ROM LOCATION 170 - (MOV RA,RB)
                                        ; ***********************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [170,204,002,015,TRAP MICROROUTINE] FC 1,4,10,6

                                        ;ACT BUTS:      37[004]100,170  /  20[170]000,002  /  26[002]010,010

                                        ;EXEC:          [204] BUPP=002 ("T" BIT TRAP)

                                        ;CODES:         N / A

                                        ;SYNC:          B05J2  (-)

                                        ;KEY SIG:       K5-2 PS (T) (1) H  /  K3-7 SERVICE H  /  K5-5 STPM3 H
                                        ;               K5-5 STPM2 H

062676  012700  000770          T0770:  MOV     #0770,R0                ;LOAD R0 WITH TEST NO.
062702  013701  062726                  MOV     @#I0770,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
062706  010605                          MOV     SP,R5           ;SAVE THE SP
062710  010506          R0770:          MOV     R5,SP           ;RESTORE SP FOR ERROR LOOPING
062712  012746  000020                  MOV     #20,-(SP)       ;SET "T" BIT IN THE NEW PSW
062716  012746  062726                  MOV     #I0770,-(SP)    ;MAKE NEW PC = I0770
062722  000257                          CCC                     ;SCOPE SYNC
062724  000006                          RTT                     ;SET "T" BIT - GO TO I0770

062726  010003          I0770:  MOV     R0,R3           ,MOV INSTRUCTION SHOULD SPRING TRAP

062730  104005          E0770:  ERROR5                          ;BUT SERVICE IN 170 FAILED
062732  062710                  R0770                           ;ERROR LOOP RETURN

062734  000004          00770:  SCOPE                           ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***************************************************************
                                        .SBTTL T0771 BUT SERVICE TEST IN ROM LOCATION 160 - (MOV (RA),RB)
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [141,247,250,160,204,002,015,TRAP MICROROUTINE]
                                        ;               FC 1,2,4,10,6

                                        ;ACT BUTS:      37[004]100,141  /  35[247]120,160  /  20[160]000,002
                                        ;               26[002]010,010

                                        ;EXEC:          [204] BUPP=002 ("T" BIT TRAP)

                                        ;CODES:         N / A

                                        ;SYNC:          BOSJ2  (-)

                                        ;KEY SIG:       K5-2 PS (T) (1) H  /  K3-7 SERVICE H  /  K5-5 STPM3 H
                                        ;               K5-5 STPM2 H

062736  012700  000771          T0771:  MOV     #0771,R0                ;LOAD R0 WITH TEST NO.
062742  013701  062772                  MOV     @#I0771,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
062746  010605                          MOV     SP,R5           ;SAVE THE SP
062750  012703  067612                  MOV     #DWTA,R3        ;SOURCE ADDR = DWTA
062754  010506                  R0771:  MOV     R5,SP           ;RESTORE SP FOR ERROR LOOPING
062756  012746  000020                  MOV     #20,-(SP)       ;SET "T" BIT IN THE NEW PSW
062762  012746  062772                  MOV     #I0771,-(SP)    ;MAKE NEW PC = I0771
062766  000257                          CCC                     ;SCOPE SYNC
062770  000006                          RTT                     ;SET "T" BIT - GO TO I0771

062772  011304                  I0771:  MOV     (R3),R4         ;MOV INSTRUCTION SHOULD SPRING TRAP

062774  104005                  E0771:  ERRORS                  ;BUT SERVICE IN 160 FAILED
062776  062754                          R0771                   ;ERROR LOOP RETURN

063000  000004                  00771:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***********************************************************************
                                .SBTTL T0772 BUT SERVICE TEST IN ROM LOCATION 003 - (MOVB RA,RB)
                                ; ***********************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:        [170,204,003,204,002,015,TRAP MICROROUTINE] FC 1,4,10,6

                                ;ACT BUTS:       37[004]100,170  /  20[170]000,003  /  27[003]000,002
                                ;                26[002]010,010

                                ;EXEC:           [204] END TIME THRU BUPP=002  ("T" BIT TRAP)

                                ;CODES:          N / A

                                ;SYNC:           B05J2  (-)

                                ;KEY SIG:        K5-2 PS (T) (1) H  /  K3-7 SERVICE H  /  K5-5 STPM3 H
                                ;                K5-5 STPM2 H

063002  012700  000772          T0772:  MOV     #0772,R0                ;LOAD R0 WITH TEST NO.
063006  013701  063032                  MOV     @#I0772,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
063012  010605                          MOV     SP,R5           ;SAVE THE SP
063014  010506                  R0772:  MOV     R5,SP           ;RESTORE SP FOR ERROR LOOPING
063016  012746  000020                  MOV     #20,-(SP)       ;SET "T" BIT IN THE NEW PSW
063022  012746  063032                  MOV     #I0772,-(SP)    ;MAKE NEW PC = I0772
063026  000257                          CCC                     ;SCOPE SYNC
063030  000006                          RTT                     ;SET "T" BIT - GO TO I0772

063032  110003                  I0772:  MOVB    R0,R3           ;MOVB INSTRUCTION SHOULD SPRING TRAP

063034  104005                  E0772:  ERROR5                  ;BUT SERVICE IN 003 FAILED
063036  063014                          R0772                   ;ERROR LOOP RETURN

063040  000004                  00772:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***********************************************************************
                                        .SBTTL T0773 BUT SERVICE TEST IN ROM LOCATION 271 - (ROR %R)
                                        ; ***********************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [106,271,274,002,015,TRAP MICROROUTINE] FC 1,9,10,6

                                        ;ACT BUTS:      37[004]100,106  /  27[271]000,002  /  26[002]010,010

                                        ;EXEC:          [274] BUPP=002 ("T" BIT TRAP)

                                        ;CODES:         N / A

                                        ;SYNC:          B05J2  (-)

                                        ;KEY SIG:       K5-2 PS (T) (1) H  /  K3-7 SERVICE H  /  K5-5 STPM3 H
                                        ;               K5-5 STPM2 H

063042  012700  000773          T0773:  MOV     #0773,R0                ;LOAD R0 WITH TEST NO.
063046  013701  063072                  MOV     @#I0773,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
063052  010605                          MOV     SP,R5           ;SAVE THE SP
063054  010506                  R0773:  MOV     R5,SP           ;RESTORE SP FOR ERROR LOOPING
063056  012746  000020                  MOV     #20,-(SP)       ;SET "T" BIT IN THE NEW PSW
063062  012746  063072                  MOV     #I0773,-(SP)    ;MAKE NEW PC = I0773
063066  000257                          CCC                     ;SCOPE SYNC
063070  000006                          RTT                     ;SET "T" BIT - GO TO I0773

063072  006003                  I0773:  ROR     R3              ;ROR INSTRUCTION SHOULD SPRING TRAP

063074  104005                  E0773:  ERROR5                  ;BUT SERVICE IN 271 FAILED
063076  063054                          R0773                   ;ERROR LOOP RETURN

063100  000004                  00773:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***************************************************************
                                        .SBTTL T0774 BUT SERVICE TEST IN ROM LOCATION 273 - (RORB %R)
                                        ; ****************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [107,272,273,274,002,015,TRAP MICROROUTINE] FC 1,9,10,6

                                        ;ACT BUTS:      [274] BUPP=002 ("T" BIT TRAP)

                                        ;EXEC:          Z

                                        ;CODES:         N / A

                                        ;SYNC:          B05J2  (-)

                                        ;KEY SIG:       K5-2 PS (T) (1) H  /  K3-7 SERVICE H  /  K5-5 STPM3 H
                                        ;               K5-5 STPM2 H

063102  012700  000774          T0774:  MOV     #0774,R0                ;LOAD R0 WITH TEST NO.
063106  013701  063132                  MOV     @#I0774,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
063112  010605                          MOV     SP,R5           ;SAVE THE SP
063114  010506          R0774:          MOV     R5,SP           ;RESTORE SP FOR ERROR LOOPING
063116  012746  000020                  MOV     #20,-(SP)       ;SET "T" BIT IN THE NEW PSW
063122  012746  063132                  MOV     #I0774,-(SP)    ;MAKE NEW PC = I0774
063126  000257                          CCC                     ;SCOPE SYNC
063130  000006                          RTT                     ;SET "T" BIT - GO TO I0774

063132  106003          I0774:  RORB    R3              ;RORB INSTRUCTION SHOULD SPRING TRAP

063134  104005          E0774:  ERROR5                  ;BUT SERVICE IN 273 FAILED
063136  063114                  R0774                   ;ERROR LOOP RETURN

063140  000004          00774:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***************************************************************
                                .SBTTL TO775 BUT SERVICE TEST IN ROM LOCATION 277 - (ROR (RN))
                                ; ***************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [161,266,267,232,275,277,376,017,015,TRAP MICROROUTINE]
                                ;               FC 1,3,9,10,6

                                ;ACT BUTS:      37[004]100,161  /  33[266]220,232  /  16[277]016,017
                                ;               26[017]010,010

                                ;EXEC:          [376] BUPP = 017 ("T" BIT TRAP)

                                ;CODES:         N / A

                                ;SYNC:          B05J2  (-)

                                ;KEY SIG:       K5-2 PS (T) (1) H  /  K3-7 SERVICE H  /  K5-5 STPM3 H
                                ;               K5-5 STPM2 H

063142  012700  000775          TO775:  MOV     #0775,R0                ;LOAD R0 WITH TEST NO.
063146  013701  063176                  MOV     @#I0775,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
063152  010605                          MOV     SP,R5           ;SAVE THE SP
063154  012703  067602                  MOV     #MBUF0,R3       ;DEST ADDR = MBUF0
063160  010506                  RO775:  MOV     R5,SP           ;RESTORE SP FOR ERROR LOOPING
063162  012746  000020                  MOV     #20,-(SP)       ;SET "T" BIT IN THE NEW PSW
063166  012746  063176                  MOV     #I0775,-(SP)    ;MAKE NEW PC = I0775
063172  000257                          CCC                     ;SCOPE SYNC
063174  000006                          RTT                     ;SET "T" BIT - GO TO I0775

063176  006013                  I0775:  ROR     (R3)            ;ROR INSTRUCTION SHOULD SPRING TRAP

063200  104005                  E0775:  ERRORS                  ;BUT SERVICE IN 277 FAILED
063202  063160                          RO775                   ;ERROR LOOP RETURN

063204  000004                  00775:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***********************************************************************
                                .SBTTL T0776 BUT SERVICE TEST IN ROM LOCATION 374 - (NEGB (RN))
                                ; ***********************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [161,266,267,223,253,075,374,375,017,015,TRAP MICROROUTINE]
                                ;               FC 1,3,9,8,10,6

                                ;ACT BUTS:      37[004]100,161  /  33[266]220,223  /  16[374]016,017
                                ;               26[017]010,010

                                ;EXEC:          [375] BUPP=017 ("T" BIT TRAP)

                                ;CODES:         N / A

                                ;SYNC:          B05J2  (-)

                                ;KEY SIG:       K5-2 PS (T) (1) H  /  K3-7 SERVICE H  /  K5-5 STPM3 H
                                ;               K5-5 STPM2 H

063206  012700  000776          T0776:  MOV     #0776,R0                ;LOAD R0 WITH TEST NO.
063212  013701  063242                  MOV     @#I0776,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
063216  010605                          MOV     SP,R5           ;SAVE THE SP
063220  012703  067603                  MOV     #MBUF0+1,R3     ;DEST ADDR = MBUF0+1 (ODD)
063224  010506                  R0776:  MOV     R5,SP           ;RESTORE SP FOR ERROR LOOPING
063226  012746  000020                  MOV     #20,-(SP)       ;SET "T" BIT IN THE NEW PSW
063232  012746  063242                  MOV     #I0776,-(SP)    ;MAKE NEW PC = I0776
063236  000257                          CCC                     ;SCOPE SYNC
063240  000006                          RTT                     ;SET "T" BIT - GO TO I0776

063242  105413                  I0776:  NEGB    (R3)            ;NEGB INSTRUCTION SHOULD SPRING TRAP

063244  104005                  E0776:  ERROR5                  ;BUT SERVICE IN 374 FAILED
063246  063224                          R0776                   ;ERROR LOOP RETURN

063250  000004                  00776:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***********************************************************
                                        .SBTTL T0777 BUT SERVICE TEST IN ROM LOCATION 306 - (JMP (RN))
                                        ; ***********************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [151,300,306,313,017,015,TRAP MICROROUTINE] FC 1,5,10,6

                                        ;ACT BUTS:      37[004]100,151  /  15[151]306,306  /  16[306]016,017
                                        ;               26[017]010,010

                                        ;EXEC:          [313] BUPP=017 ("T" BIT TRAP)

                                        ;CODES:         N / A

                                        ;SYNC:          B05J2  (-)

                                        ;KEY SIG:       K5-2 PS (T) (1) H  /  K3-7 SERVICE H  /  K5-5 STPM3 H
                                        ;               K5-5 STPM2 H

063252  012700  000777                  T0777:  MOV     #0777,R0                ;LOAD R0 WITH TEST NO.
063256  013701  063306                          MOV     @#I0777,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
063262  010605                                  MOV     SP,R5           ;SAVE THE SP
063264  012702  063310                          MOV     #E0777,R2       ;DEST ADDR = E0777 FOR JMP
063270  010506                          R0777:  MOV     R5,SP           ;RESTORE SP FOR ERROR LOOPING
063272  012746  000020                          MOV     #20,-(SP)       ;SET "T" BIT IN THE NEW PSW
063276  012746  063306                          MOV     #I0777,-(SP)    ;MAKE NEW PC = I0777
063302  000257                                  CCC                     ;SCOPE SYNC
063304  000006                                  RTT                     ;SET "T" BIT - GO TO I0777

063306  000112                          I0777:  JMP     (R2)            ;JMP INSTRUCTION SHOULD SPRING TRAP

063310  104005                          E0777:  ERROR5                  ;BUT SERVICE IN 306 FAILED
063312  063270                                  R0777                   ;ERROR LOOP RETURN

063314  000004                          00777:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***************************************************************
                                        .SBTTL T1000 BUT SERVICE TEST IN ROM LOCATION 110 - (BVS A)
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [110,347,017,015,TRAP MICROROUTINE] FC 1,7,10,6

                                        ;ACT BUTS:      37[004]100,110  /  16[110]016,017  /  26[017]010,010

                                        ;EXEC:          [347] BUPP=017 ("T" BIT TRAP)

                                        ;CODES:         N / A

                                        ;SYNC:          B05J2  (-)

                                        ;KEY SIG:       K5-2 PS (T) (1) H  /  K3-7 SERVICE H  /  K5-5 STPM3 H
                                        ;               K5-5 STPM2 H

063316  012700  001000                  T1000:  MOV     #1000,R0                ;LOAD R0 WITH TEST NO.
063322  013701  063346                          MOV     @#I1000,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
063326  010605                                  MOV     SP,R5           ;SAVE THE SP
063330  010506                          R1000:  MOV     R5,SP           ;RESTORE SP FOR ERROR LOOPING
063332  012746  000020                          MOV     #20,-(SP)       ;SET "T" BIT IN THE NEW PSW
063336  012746  063346                          MOV     #I1000,-(SP)    ;MAKE NEW PC = I1000
063342  000257                                  CCC                     ;SCOPE SYNC
063344  000006                                  RTT                     ;SET "T" BIT - GO TO I1000

063346  102400                          I1000:  BVS     E1000           ;BVS INSTRUCTION SHOULD SPRING TRAP

063350  104005                          E1000:  ERROR5                  ;BUT SERVICE IN 110 FAILED
063352  063330                                  R1000                   ;ERROR LOOP RETURN

063354  000004                          01000:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***************************************************************
                                        .SBTTL T1001 BUT SERVICE TEST IN ROM LOCATION 340 - (BR A)
                                        ; ***************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [111,340,341,017,015,TRAP MICROROUTINE] FC 1,7,10,6

                                        ;ACT BUTS:      37[004]100,111  /  16[340]016,017  /  26[017]010,010

                                        ;EXEC:          [341] BUPP=017 ("T" BIT TRAP)

                                        ;CODES:         N / A

                                        ;SYNC:          B05J2  (-)

                                        ;KEY SIG:       K5-2 PS (T) (1) H  /  K3-7 SERVICE H  /  K5-5 STPM3 H
                                        ;               K5-5 STPM2 H

063356  012700  001001                  T1001:  MOV     #1001,R0                ;LOAD R0 WITH TEST NO.
063362  013701  063406                          MOV     @#I1001,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
063366  010605                                  MOV     SP,R5           ;SAVE THE SP
063370  010506                          R1001:  MOV     R5,SP           ;RESTORE SP FOR ERROR LOOPING
063372  012746  000020                          MOV     #20,-(SP)       ;SET "T" BIT IN THE NEW PSW
063376  012746  063406                          MOV     #I1001,-(SP)    ;MAKE NEW PC = I1001
063402  000257                                  CCC                     ;SCOPE SYNC
063404  000006                                  RTT                     ;SET "T" BIT - GO TO I1001

063406  000400                          I1001:  BR      E1001           ;BR INSTRUCTION SHOULD SPRING TRAP

063410  104005                          E1001:  ERROR5                  ;BUT SERVICE IN 340 FAILED
063412  063370                                  R1001                   ;ERROR LOOP RETURN

063414  000004                          01001:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***********************************************************************
                                        .SBTTL T1002 BUT SERVICE TEST IN ROM LOCATION 350 - (CCC)
                                        ; ***********************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [116,350,351,017,015,TRAP MICROROUTINE] FC 1,7,10,6

                                        ;ACT BUTS:      37[004]100,116  /  16[350]016,017  /  26[017]010,010

                                        ;EXEC   [351] BUPP=017 ("T" BIT TRAP)

                                        ;CODES:         N / A

                                        ;SYNC:          B05J2  (-)

                                        ;KEY SIG:       K5-2 PS (T) (1) H  /  K3-7 SERVICE H  /  K5-5 STPM3 H
                                        ;               K5-5 STPM2 H

063416  012700  001002                  T1002:  MOV     #1002,R0                ;LOAD R0 WITH TEST NO.
063422  013701  063444                          MOV     @#I1002,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
063426  010605                                  MOV     SP,R5           ;SAVE THE SP
063430  010506                          R1002:  MOV     R5,SP           ;RESTORE SP FOR ERROR LOOPING
063432  012746  000020                          MOV     #20,-(SP)       ;SET "T" BIT IN THE NEW PSW
063436  012746  063444                          MOV     #I1002,-(SP)    ;MAKE NEW PC = I1002
063442  000006                                  RTT                     ;SET "T" BIT - GO TO I1002

063444  000257                          I1002:  CCC             ;CCC INSTRUCTION SHOULD SPRING TRAP

063446  104005                          E1002:  ERRORS                  ;BUT SERVICE IN 350 FAILED
063450  063430                                  R1002                   ;ERROR LOOP RETURN

063452  000004                          01002:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***********************************************************************
                                        .SBTTL T1003 BUT SERVICE TEST IN ROM LOCATION 117 - (SCC)
                                        ; ***********************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [117,352,017,015,TRAP MICROROUTINE] FC 1,7,10,6

                                        ;ACT BUTS:      37[004]100,117  /  16[117]016,017  /  26[017]010,010

                                        ;EXEC:          [352] BUPP=017 ("T" BIT TRAP)

                                        ;CODES:         N / A

                                        ;SYNC:          B05J2  (-)

                                        ;KEY SIG:       K5-2 PS (T) (1) H  /  K3-7 SERVICE H  /  K5-5 STPM3 H
                                        ;               K5-5 STPM2 H

063454  012700  001003                  T1003:  MOV     #1003,R0                ;LOAD R0 WITH TEST NO.
063460  013701  063502                          MOV     @#I1003,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
063464  010605                                  MOV     SP,R5           ;SAVE THE SP
063466  010506                          R1003:  MOV     R5,SP           ;RESTORE SP FOR ERROR LOOPING
063470  012746  000020                          MOV     #20,-(SP)       ;SET "T" BIT IN THE NEW PSW
063474  012746  063502                          MOV     #I1003,-(SP)    ;MAKE NEW PC = I1003
063500  000006                                  RTT                     ;SET "T" BIT - GO TO I1003

063502  000277                          I1003:  SCC                     ;SCC INSTRUCTION SHOULD SPRING TRAP

063504  104005                          E1003:  ERRORS                  ;BUT SERVICE IN 117 FAILED
063506  063466                                  R1003                   ;ERROR LOOP RETURN

063510  000004                          01003:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***********************************************************************
                                .SBTTL T1004 BUT SERVICE TEST IN ROM LOCATION 324 - (RTS PC)
                                ; ***********************************************************************

                                ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                ;ROM SEQ:       [124,323,324,325,017,015,TRAP MICROROUTINE] FC 1,6,10,6

                                ;ACT BUTS:      37[004]100,124  /  16[324]016,017  /  26[017]010,010

                                ;EXEC:          [325] PUPP=017 ("T" BIT TRAP)

                                ;CODES:         N / A

                                ;SYNC:          BOSJ2  (-)

                                ;KEY SIG:       K5-2 PS (T) (1) H  /  K3-7 SERVICE H  /  K5-5 STPM3 H
                                ;               K5-5 STPM2 H

063512  012700  001004          T1004:  MOV     #1004,R0                ;LOAD R0 WITH TEST NO.
063516  013701  063546                  MOV     @#I1004,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
063522  010605                          MOV     SP,R5           ;SAVE THE SP
063524  010506                  R1004:  MOV     R5,SP           ;RESTORE SP FOR ERROR LOOPING
063526  012746  063550                  MOV     #E1004,-(SP)    ;RTS WILL LOAD PC WITH E1004
063532  012746  000020                  MOV     #20,-(SP)       ;SET "T" BIT IN THE NEW PSW
063536  012746  063546                  MOV     #I1004,-(SP)    ;MAKE NEW PC = I1004
063542  000257                          CCC                     ;SCOPE SYNC
063544  000006                          RTT                     ;SET "T" BIT - GO TO I1004

063546  000207                  I1004:  RTS     PC              ;RTS INSTRUCTION SHOULD SPRING TRAP

063550  104005                  E1004:  ERRORS                  ;BUT SERVICE IN 324 FAILED
063552  063524                          R1004                   ;ERROR LOOP RETURN

063554  000004                  01004:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***********************************************************************
                                        .SBTTL T1005 BUT SERVICE TEST IN ROM LOCATION 345 - (SOB RN,A)
                                        ; ***********************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [130,342,343,345,347,017,015,TRAP MICROROUTINE] FC 1,7,10,6

                                        ;ACT BUTS:      37[004]100,130  /  16[345]016,017  /  26[017]010,010

                                        ;EXEC:          [347] BUPP=017 ("T" BIT TRAP)

                                        ;CODES:         N / A

                                        ;SYNC:          BOSJ2  (-)

                                        ;KEY SIG:       K5-2 PS (T) (1) H  /  K3-7 SERVICE H  /  K5-5 STPM3 H
                                        ;               K5-5 STPM2 H

063556  012700  001005          T1005:  MOV     #1005,R0                ;LOAD R0 WITH TEST NO.
063562  013701  063626                  MOV     @#I1005,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
063566  032737  100000  066642          BIT     #100000,@#BPTLOC;BREAKPOINT HALT SET ??
063574  001401                          BEQ     .+4             ;BR IF NOT
063576  000000                          HALT                    ;BREAK-DEPRESS CONTINUE TO RESTART
063600  010605                          MOV     SP,R5           ;SAVE THE SP
063602  010506                  R1005:  MOV     R5,SP           ;RESTORE SP FOR ERROR LOOPING
063604  012703  000001                  MOV     #1,R3           ;SOB COUNT = +1
063610  012746  000020                  MOV     #20,-(SP)       ;SET "T" BIT IN THE NEW PSW
063614  012746  063626                  MOV     #I1005,-(SP)    ;MAKE NEW PC = I1005
063620  000257                          CCC                     ;SCOPE SYNC
063622  000006                          RTT                     ;SET "T" BIT - GO TO I1005
063624  000401                          BR      E1005

063626  077302                  I1005:  SOB     R3,I1005-2      ;SOB INSTRUCTION SHOULD SPRING TRAP

063630  104005                  E1005:  ERROR5                  ;BUT SERVICE IN 345 FAILED
063632  063602                          R1005                   ;ERROR LOOP RETURN

063634  000004                  01005:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***********************************************************************
                                        .SBTTL T1006 BUT SERVICE TEST IN ROM LOCATION 344 - (SOB RA,A)
                                        ; ***********************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [130,342,343,344,346,017,015,TRAP MICROROUTINE] FC 1,7,10,6

                                        ;ACT BUTS:      37[004]100,130  /  16[344]016,017  /  26[017]010,010

                                        ;EXEC:          [346] BUPP=017 ("T" BIT TRAP)

                                        ;CODES:         N / A

                                        ;SYNC:          B05J2  (-)

                                        ;KEY SIG:       K5-2 PS (T) (1) H  /  K3-7 SERVICE H  /  K5-5 STPM3 H
                                        ;               K5-5 STPM2 H

063636  012700  001006          T1006:  MOV     #1006,R0                ;LOAD R0 WITH TEST NO.
063642  013701  063700                  MOV     @#I1006,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
063646  010605                          MOV     SP,R5           ;SAVE THE SP
063650  010506          R1006:          MOV     R5,SP           ;RESTORE SP FOR ERROR LOOPING
063652  012703  000002                  MOV     #2,R3           ;SOB COUNT = +2
063656  012746  000020                  MOV     #20,-(SP)       ;SET "T" BIT IN THE NEW PSW
063662  012746  063700                  MOV     #I1006,-(SP)    ;MAKE NEW PC = I1006
063666  000257                          CCC                     ;SCOPE SYNC
063670  000006                          RTT                     ;SET "T" BIT - GO TO I1006
063672  104005          E1006:          ERROR5                  ;BUT SERVICE IN 373 FAILED
063674  063650                          R1006                   ;ERROR LOOP RETURN
063676  000403                          BR      01006           ;GO TO SCOPE EXIT

063700  077304          I1006:          SOB     R3,E1006                ;SOB INSTRUCTION SHOULD SPRING TRAP

063702  000240                          NOP                     ;TO BE COMPATIBLE WITH "T" BIT SERV.
063704  000240                          NOP

063706  000004          01006:          SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***********************************************************************
                                        .SBTTL T1007 BUT SERVICE TEST IN ROM LOCATION 356 - (MARK 0)
                                        ; ***********************************************************************

                                        ;MICROPROGRAMMING  /  LOGIC INFORMATION

                                        ;ROM SEQ:       [112,353,354,355,356,357,017,015,TRAP MICROROUTINE]
                                        ;               FC 1,5,10,6

                                        ;ACT BUTS:      37[004]100,112  /  016[356]016,017  /  26[017]010,010

                                        ;EXEC:          [357]  BUPP = 017  ("T" BIT TRAP)

                                        ;CODES:         N / A

                                        ;SYNC:          B05J2  (-)

                                        ;KEY SIG:       K5-2 PS (T) (1) H  /  K3-7 SERVICE H  /  K5-5 STPM3 H
                                        ;               K5-5 STPM2 H


063710  012700  001007          T1007:  MOV     #1007,R0                ;LOAD R0 WITH TEST NO.
063714  013701  063744                  MOV     @#I1007,R1      ;LOAD R1 WITH TEST INSTRUCTION WORD
063720  010604                          MOV     SP,R4           ;SAVE THE SP
063722  010406          R1007:          MOV     R4,SP           ;RESTORE SP FOR ERROR LOOPING
063724  012746  000020                  MOV     #20,-(SP)       ;SET "T" BIT IN THE NEW PSW
063730  012746  063744                  MOV     #I1007,-(SP)    ;MAKE NEW PC = I1007
063734  012705  063754                  MOV     #A1007,R5               ;MARK GOES TO A1007 IF TRAP NOT SPRUNG
063740  000257                          CCC                     ;SCOPE SYNC
063742  000006                          RTT                     ;SET "T" BIT - GO TO I1007

063744  006401          I1007:  MARK+1                          ;MRK INSTRUCTION SHOULD SPRING TRAP

063746  000000                  0                               ;"T" BIT SERVICE WILL PUSH THE "PSW"
063750  000000                  0                               ;AND THE "PC" IN THESE LOCATIONS
063752  000400                  BR      A1007                   ;JUST IN CASE MARK FAILS

063754  010406          A1007:  MOV     R4,SP                   ;RESET THE SP
063756  000401                  BR      E1007                   ;GO REPORT ERROR
063760  000402                  BR      B1007                   ;"T" TRAP WORKED - GO TO EXIT
063762  104005          E1007:  ERROR5                          ;MRK FAILED TO SPRING "T" TRAP
063764  063722                  R1007                           ;ERROR LOOP RETURN ADDRESS

063766  010406          B1007:  MOV     R4,SP                   ;RESET THE SP IF ALL OK

063770  000004          01007:  SCOPE                           ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***********************************************************************
                                        .SBTTL T1010 ALU ADD FUNCTION TEST
                                ; ***********************************************************************

                                ;THIS TEST VERIFIES THAT THE ALU ADD FUNCTION CAN RESPOND CORRECTLY
                                ;TO THE 8 POSSIBLE COMBINATIONS THAT COULD OCCUR AT THE INPUTS OF
                                ;EACH OF THE 16 BIT POSITIONS AS DESCRIBED BELOW:

                                ;       AIN     BIN     CIN

                                ;       0       0       0
                                ;       0       0       1
                                ;       0       1       0
                                ;       0       1       1
                                ;       1       0       0
                                ;       1       0       1
                                ;       1       1       0
                                ;       1       1       1

                                ;THE TEST NO.S ALONG WITH THE CORRECT ANSWERS ARE STORED IN A TABLE
                                ;TAGGED "ALUADD" AS SHOWN BELOW:

                                        ;ALUADD:        NULL
                                ;                       SRC OP1
                                ;                       DST OP1
                                ;                       SUM1
                                ;                       SRC OP2
                                ;                       DST OP2
                                ;                       SUM2
                                ;                       ETC.

                                ;UPON DETECTION OF AN ERROR THE PRINTOUT HAS THE FOLLOWING SIG-
                                ;NIFICANCE IN COLUMNS 5-8:

                                ;       COL5 [R1] = SOURCE OPR
                                ;       COL6 [R2] = DEST OPR
                                ;       COL7 [R3] = WAS SUM
                                ;       COL8 [R4] = S / B SUM

                                ;AFTER REPORTING THE ERROR THE ROUTINE WILL LOCK ON THE FAILING PAIR
                                ;OF NO.S IF SW09=1 OR GO ON TO THE NEXT PAIR IF SW09=0.

063772  012700  001010          T1010:  MOV     #1010,R0                ;LOAD R0 WITH TEST NO.
063776  012705  067626                  MOV     #ALUADD,R5      ;R5 POINTS TO TABLE OF NO.S
064002  005725                  L1010:  TST     (R5)+           ;POINT TO A SRC OP
064004  022705  067710                  CMP     #ALUADD+62,R5   ;DONE ALL NO.S IN TABLE ?
064010  001416                          BEQ     01010           ;BR IF YES
064012  012501                          MOV     (R5)+,R1        ;LOAD SRC OP
064014  012503                          MOV     (R5)+,R3        ;LOAD DEST OP
064016  000257                          CCC                     ;SCOPE SYNC

064020  060103                  I1010:  ADD     R1,R3           ;TEST THE ADD FUNCTION

064022  021503                          CMP     (R5),R3         ;CORRECT SUM ?
064024  001766                          BEQ     L1010           ;GO ADD NEXT PAIR IF YES
```

```
064026  011504                          MOV     (R5),R4         ;GET S / B SUM
064030  014502                          MOV     -(R5),R2        ;GET DEST OP
064032  104000                  E1010:  ERROR                   ;ALU ADD OPERATION FAILED
064034  064042                          R1010                   ;ERROR LOOP RETURN ADDRESS

064036  005725                          TST     (R5)+           ;CORRECT R5 POINTER
064040  000760                          BR      L1010           ;GO DO NEXT PAIR

064042  024545                  R1010:  CMP     -(R5),-(R5)     ;RESET R5 TO POINT TO BAD GUYS
064044  000756                          BR      L1010           ;GO REPEAT FAILING PAIR

064046  000004                  01010:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***********************************************************************
                                        .SBTTL T1011 ALU SUB FUNCTION TEST
                                ; ***********************************************************************

                                ;THIS TEST VERIFIES THAT THE ALU ADD FUNCTION CAN RESPOND CORRECTLY
                                ;TO THE 8 POSSIBLE COMBINATIONS THAT COULD OCCUR AT THE INPUTS OF
                                ;EACH OF THE 16 BIT POSITIONS AS DESCRIBED BELOW:

                                ;       AIN     BIN     CIN

                                ;       0       0       0
                                ;       0       0       1
                                ;       0       1       0
                                ;       0       1       1
                                ;       1       0       0
                                ;       1       0       1
                                ;       1       1       0
                                ;       1       1       1

                                ;THE TEST NO.S ALONG WITH THE CORRECT ANSWERS ARE STORED IN A TABLE
                                ;TAGGED "ALUADD" AS SHOWN BELOW:

                                        ;ALUSUB:        NULL
                                ;                       SRC OP1
                                ;                       DST OP1
                                ;                       DIFF1
                                ;                       SRC OP2
                                ;                       DST OP2
                                ;                       DIFF2
                                ;                       ETC.

                                ;UPON DETECTION OF AN ERROR THE PRINTOUT HAS THE FOLLOWING SIG-
                                ;NIFICANCE IN COLUMNS 5-8:

                                ;       COL5 [R1] = SOURCE OPR
                                ;       COL6 [R2] = DEST OPR
                                ;       COL7 [R3] = WAS DIFFERENCE
                                ;       COL8 [R4] = S / B DIFFERENCE

                                ;AFTER REPORTING THE ERROR THE ROUTINE WILL LOCK ON THE FAILING PAIR
                                ;OF NO.S IF SW09=1 OR GO ON TO THE NEXT PAIR IF SW09=0.

064050  012700  001011          T1011:  MOV     #1011,R0                ;LOAD R0 WITH TEST NO.
064054  012705  070054                  MOV     #ALUSUB,R5      ;R5 POINTS TO TABLE OF NO.S
064060  005725                  L1011:  TST     (R5)+           ;POINT TO A SRC OP
064062  022705  070136                  CMP     #ALUSUB+62,R5   ;DONE ALL NO.S IN TABLE ?
064066  001416                          BEQ     01011           ;BR IF YES
064070  012501                          MOV     (R5)+,R1        ;LOAD SRC OP
064072  012503                          MOV     (R5)+,R3        ;LOAD DEST OP
064074  000257                          CCC                     ;SCOPE SYNC

064076  160103                  I1011:  SUB     R1,R3           ;TEST THE SUB FUNCTION

064100  021503                          CMP     (R5),R3         ;CORRECT DIFF. ?
064102  001766                          BEQ     L1011           ;GO SUB NEXT PAIR IF YES
```

```
064104  011504                          MOV     (R5),R4         ;GET S / B DIFF
064106  014502                          MOV     -(R5),R2        ;GET DEST OP
064110  104000                  E1011:  ERROR                   ;ALU SUB OPERATION FAILED
064112  064120                          R1011                   ;ERROR LOOP RETURN ADDRESS

064114  005725                          TST     (R5)+           ;CORRECT R5 POINTER
064116  000760                          BR      L1011           ;GO DO NEXT PAIR

064120  024545                  R1011:  CMP     -(R5),-(R5)     ;RESET R5 TO POINT TO BAD GUYS
064122  000756                          BR      L1011           ;GO REPEAT FAILING PAIR

064124  000004                  01011:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***********************************************************************
                                        .SBTTL T1012 ALU "AND" FUNCTION TEST USING BIC INSTRUCTION
                                ; ***********************************************************************

                                ;THIS TEST VERIFIES THAT THE ALU "AND" FUNCTION RESPONDS CORRECTLY
                                ;TO ALL POSSIBLE COMBINATIONS FOR EACH OF THE 16 BIT POSITIONS
                                ;IT  EXECUTES THE BIC INSTRUCTION FOR THE FOLLOWING PAIRS OF
                                ;OPERANDS AND TESTS FOR THE INDICATED RESULT:

                                        ;SOURCE OP      DEST. OP        RESULT

                                        ;000000         000000          000000
                                        ;177777         177777          000000
                                        ;000000         177777          177777
                                        ;177777         000000          000000
                                        ;125252         125252          000000
                                        ;052525         052525          000000
                                        ;125252         052525          052525
                                        ;052525         125252          125252

                                ;THE 8 PAIRS OF NO.S AND THE ANSWERS ARE STORED IN A TEBLE TAGGED
                                ;"ANDTAB" IN THE FOLLOWING PATTERN:
                                        ;ANDTAB:        NULL
                                ;                       SRC OP1
                                ;                       DST OP1
                                ;                       ANS1
                                ;                       SRC OP2
                                ;                       DST OP2
                                ;                       ANS2
                                ;                       ETC.

                                ;WHEN AN ERROR IS REPORTED THE PRINTOUT IN COL. 5-8 HAS THE
                                ;FOLLOWING SIGNIFICANCE:

                                ;       COL 5 [R1] = SOURCE OPR
                                ;       COL 6 [R2] = DEST OPR
                                ;       COL 7 [R3] = WAS ANSWER
                                ;       COL 8 [R4] = S / B ANSWER

                                ;AFTER REPORTING THE ERROR THE ROUTINE WILL LOCK ON THE FAILING
                                ;PAIR OF NO.S IF SW09=1 OR GO ON TO TEST THE NEXT PAIR IF SW09=0

064126  012700  001012          T1012:  MOV     #1012,R0                ;LOAD R0 WITH TEST NO.
064132  012705  067710                  MOV     #ANDTAB,R5      ;R5 POINTS TO TABLE OF TEST NO.S
064136  005725                  L1012:  TST     (R5)+           ;POINT TO A SOURCE OPR
064140  022705  067772                  CMP     #ANDTAB+62,R5   ;DONE ALL COMBINATIONS ?
064144  001416                          BEQ     01012           ;BR IF YES
064146  012501                          MOV     (R5)+,R1        ;LOAD THE SRC OP
064150  012503                          MOV     (R5)+,R3        ;LOAD THE DEST OP
064152  000257                          CCC                     ;SCOPE SYNC

064154  040103                  I1012:  BIC     R1,R3           ;TEST THE "AND"

064156  020315                          CMP     R3,(R5)         ;RESULT CORRECT ?
064160  001766                          BEQ     L1012           ;BR IF YES - GET THE NEXT PAIR
```

```
064162  011504                          MOV     (R5),R4         ;GET THE S / B DATA
064164  014502                          MOV     -(R5),R2        ;GET DEST OP
064166  104000                  E1012:  ERROR                   ;ALU "AND" FAILED
064170  064176                          R1012                   ;ERROR LOOP RETURN

064172  005725                          TST     (R5)+           ;CORRECT R5 POINTER
064174  000760                          BR      L1012           ;GO GET NEXT PAIR

064176  024545                  R1012:  CMP     -(R5),-(R5)     ;RESET R5 TO POINT BACK TO BAD GUYS
064200  000756                          BR      L1012           ;GO REPEAT THE BAD GUYS

064202  000004                  01012:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                ; ***********************************************************************
                                        .SBTTL T1013 ALU "OR" FUNCTION TEST USING BIS INSTRUCTION
                                ; ***********************************************************************

                                ;THIS TEST VERIFIES THAT THE ALU "OR" FUNCTION RESPONDS CORRECTLY
                                ;TO ALL POSSIBLE COMBINATIONS FOR EACH OF THE 16 BIT POSITIONS
                                ;IT  EXECUTES THE BIS INSTRUCTION FOR THE FOLLOWING PAIRS OF
                                ;OPERANDS AND TESTS FOR THE INDICATED RESULT:

                                        ;SOURCE OP      DEST. OP        RESULT

                                        ;000000         000000          000000
                                        ;177777         177777          177777
                                        ;000000         177777          177777
                                        ;177777         000000          177777
                                        ;125252         125252          125252
                                        ;052525         052525          052525
                                        ;125252         052525          177777
                                        ;052525         125252          177777

                                ;THE 8 PAIRS OF NO.S AND THE ANSWERS ARE STORED IN A TABLE TAGGED
                                ;"ORTAB" IN THE FOLLOWING PATTERN:
                                        ;ORTAB: NULL
                                ;                       SRC OP1
                                ;                       DST OP1
                                ;                       ANS1
                                ;                       SRC OP2
                                ;                       DST OP2
                                ;                       ANS2
                                ;                       ETC.

                                ;WHEN AN ERROR IS REPORTED THE PRINTOUT IN COL. 5-8 HAS THE
                                ;FOLLOWING SIGNIFICANCE:

                                ;       COL 5 [R1] = SOURCE OPR
                                ;       COL 6 [R2] = DEST OPR
                                ;       COL 7 [R3] = WAS ANSWER
                                ;       COL 8 [R4] = S / B ANSWER

                                ;AFTER REPORTING THE ERROR THE ROUTINE WILL LOCK ON THE FAILING
                                ;PAIR OF NO.S IF SW09=1 OR GO ON TO TEST THE NEXT PAIR IF SW09=0

064204  012700  001013          T1013:  MOV     #1013,R0                ;LOAD R0 WITH TEST NO.
064210  012705  067772                  MOV     #ORTAB,R5       ;R5 POINTS TO TABLE OF TEST NO.S
064214  005725                  L1013:  TST     (R5)+           ;POINT TO A SOURCE OPR
064216  022705  070054                  CMP     #ORTAB+62,R5    ;DONE ALL COMBINATIONS ?
064222  001416                          BEQ     01013           ;BR IF YES
064224  012501                          MOV     (R5)+,R1        ;LOAD THE SRC OP
064226  012503                          MOV     (R5)+,R3        ;LOAD THE DEST OP
064230  000257                          CCC                     ;SCOPE SYNC

064232  050103                  I1013:  BIS     R1,R3           ;TEST THE "OR"

064234  020315                          CMP     R3,(R5)         ;RESULT CORRECT ?
064236  001766                          BEQ     L1013           ;BR IF YES - GET THE NEXT PAIR
```

```
064240  011504                          MOV     (R5),R4         ;GET THE S / B DATA
064242  014502                          MOV     -(R5),R2        ;GET DEST OP
064244  104000                  E1013:  ERROR                   ;ALU "OR" FAILED
064246  064254                          R1013                   ;ERROR LOOP RETURN

064250  005725                          TST     (R5)+           ;CORRECT R5 POINTER
064252  000760                          BR      L1013           ;GO GET NEXT PAIR

064254  024545                  R1013:  CMP     -(R5),-(R5)     ;RESET R5 TO POINT BACK TO BAD GUYS
064256  000756                          BR      L1013           ;GO REPEAT THE BAD GUYS

064260  000004                  01013:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***********************************************************************
                                                .SBTTL T1014 INC / DEC / ADD TEST - CYCLE NO.5 000000-077777
                                        ; ***********************************************************************

                                        ;THIS TEST COMBINES THE INC / DEC / ADD INSTRUCTIONS IN THE FOLLOWING
                                        ;TEST SEQUENCE:

                                                ;1. BOTH SOURCE AND DEST OPS ARE ZEROED
                                                ;2. THE TWO NO.S ARE ADDED AND THE RESULT COMPARED WITH 000000
                                                ;3. THE SOURCE OP IS INCREMENTED
                                                ;4. THE DEST OP IS DECREMENTED
                                                ;5. STEPS 2,3, AND 4 ARE REPEATED UNTIL THE SOURCE OP GOES
                                                ;   NEGATIVE

                                        ;ON DETECTION OF A NON-ZERO RESULT THE ERROR IS REPORTED AND THEN IF:

                                        ;       1. SW09=0  THE SCOPE LOOP UTILITY IAS CALLED TO REINITIALIZE
                                        ;                  THE TEST
                                        ;       2. SW09=1  THE ROUTINE LOCKS ON THE FAILING PAIR OF OPERANDS
                                        ;                  UNTIL THE ERROR GOES AWAY OR SW09 IS RESET

                                        ;THE SIGNIFICANCE OF THE PRINTOUT IN COLUMNS 5 - 8:

                                                ;COLUMN 5       [R1] SOURCE OP
                                                ;COLUMN 6       [R2] DEST OP
                                                ;COLUMN 7       [R3] WAS ANSWER
                                                ;COLUMN 8       [R4] S / B ANSWER (ALWAYS 000000)

064262  012700  001014          T1014:  MOV     #1014,R0                ;LOAD R0 WITH TEST NO.
064266  005001                          CLR     R1              ;INITIALIZE REGS TO 000000
064270  005002                          CLR     R2
064272  005004                          CLR     R4
064274  010203                  R1014:  MOV     R2,R3           ;LOAD DEST OPERAND
064276  000257                          CCC                     ;SCOPE SYNC

064300  060103                  I1014:  ADD     R1,R3           ;ADD THE TWO TEST NO.S
                                                                ;RESULT S / B = 000000

064302  020403                          CMP     R4,R3           ;RESULT = 000000 ?
064304  001403                          BEQ     A1014           ;BR IF YES

064306  104000                  E1014:  ERROR                   ;INCORRECT RESULT IN R3
064310  064274                          R1014                   ;ERROR LOOP RETURN

064312  000404                          BR      O1014           ;GO TO SCOPE EXIT

064314  005201                  A1014:  INC     R1              ;ADD 1 TO SOURCE OP
064316  100402                          BMI     O1014           ;GET OUT IF IT WENT NEGATIVE
064320  005302                          DEC     R2              ;SUB 1 FROM THE DEST OP
064322  000764                          BR      R1014           ;GO ADD THE TWO NO.S

064324  000004                  C1014:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***********************************************************************
                                                .SBTTL T1015 INC / DEC / ADD TEST - CYCLE NO.S 077777-000000
                                        ; ***********************************************************************

                                        ;THIS TEST COMBINES THE INC / DEC / ADD INSTRUCTIONS IN THE FOLLOWING
                                        ;TEST SEQUENCE:

                                                ;1. BOTH SOURCE AND DEST OPS ARE ZEROED
                                                ;2. THE TWO NO.S ARE ADDED AND THE RESULT COMPARED WITH 000000
                                                ;3. THE SOURCE OP IS DECREMENTED
                                                ;4. THE DEST OP IS INCREMENTED
                                                ;5. STEPS 2,3, AND 4 ARE REPEATED UNTIL THE DEST. OP GOES
                                                ;   NEGATIVE

                                        ;ON DETECTION OF A NON-ZERO RESULT THE ERROR IS REPORTED AND THEN IF:

                                        ;       1. SW09=0  THE SCOPE LOOP UTILITY IAS CALLED TO REINITIALIZE
                                        ;                  THE TEST
                                        ;       2. SW09=1  THE ROUTINE LOCKS ON THE FAILING PAIR OF OPERANDS
                                        ;                  UNTIL THE ERROR GOES AWAY OR SW09 IS RESET

                                        ;THE SIGNIFICANCE OF THE PRINTOUT IN COLUMNS 5 - 8:

                                                ;COLUMN 5       [R1] SOURCE OP
                                                ;COLUMN 6       [R2] DEST OP
                                                ;COLUMN 7       [R3] WAS ANSWER
                                                ;COLUMN 8       [R4] S / B ANSWER (ALWAYS 000000)

064326  012700  001015          T1015:  MOV     #1015,R0                ;LOAD R0 WITH TEST NO.
064332  005001                          CLR     R1              ;INITIALIZE REGS TO 000000
064334  005002                          CLR     R2
064336  005004                          CLR     R4
064340  010203                  R1015:  MOV     R2,R3           ;LOAD DEST OPERAND
064342  000257                          CCC                     ;SCOPE SYNC

064344  060103                  I1015:  ADD     R1,R3           ;ADD THE TWO TEST NO.S
                                                                ;RESULT S / B = 000000

064346  020403                          CMP     R4,R3           ;RESULT = 000000 ?
064350  001403                          BEQ     A1015           ;BR IF YES

064352  104000                  E1015:  ERROR                   ;INCORRECT RESULT IN R3
064354  064340                          R1015                   ;ERROR LOOP RETURN

064356  000404                          BR      01015           ;GO TO SCOPE EXIT

064360  005202                  A1015:  INC     R2              ;ADD 1 TO DEST. OP
064362  100402                          BMI     01015           ;GET OUT IF IT WENT NEGATIVE
064364  005301                          DEC     R1              ;SUB 1 FROM THE SOURCE OP
064366  000764                          BR      R1015           ;GO ADD THE TWO NO.S

064370  000004                  01015:  SCOPE                   ;CALL SCOPE LOOP UTILITY
```

```
                                        ; ***********************************************************************
                                                .SBTTL END OF PASS SERVICE ROUTINE
                                        ; ***********************************************************************

064272  010037  066706          ENDPS:  MOV     R0,@#LAST       ;SAVE LAST TEST NO. FOR
                                                                ;MISSED TEST ERROR CHECK
064376  004737  064564                  JSR     PC,@#MISS       ;GO CHECK FOR MISSED TESTS
064402  005237  066670          1$:     INC     @#PASCNT        ;UPDATE THE PASS COUNTER
064406  032737  010000  177570          BIT     #SW12,@#SR      ;INHIBIT END PASS PRINTOUT ?
064414  001035                          BNE     6$              ;BR IF YES
064416  104400                          TYPE
064420  067147                          EOP1
064422  013702  066670                  MOV     @#PASCNT,R2     ;CONVERT AND PRINT PASS COUNT
064426  004737  065760                  JSR     PC,@#OTA
064432  104400                          TYPE
064434  067136                          DIGITS
064436  104400                          TYPE
064440  067176                          EOP2
064442  013702  066666                  MOV     @#ERRCNT,R2     ;CONVERT AND PRINT ERROR COUNT
064446  004737  065760                  JSR     PC,@#OTA
064452  104400                          TYPE
064454  067136                          DIGITS
064456  005737  066672                  TST     @#PFCNT         ;ANY POWER FAILS LOGGED THIS PASS?
064462  001410                          BEQ     2$              ;BR IF NONE
064464  013702  066672                  MOV     @#PFCNT,R2      ;GET THE PWR FAIL COUNT
064470  004737  065760                  JSR     PC,@#OTA        ;GO CONVERT PFCNT
064474  104400                          TYPE
064476  067163                          PFMESS
064500  104400                          TYPE                    ;TYPE "PFCNT = NNNNNN
064502  067136                          DIGITS
064504  104400                  2$:     TYPE
064506  066726                          CRLF
064510  012737  000040  066662  6$:     MOV     #32.,@#ICOUNT
064516  012737  000040  066664          MOV     #32.,@#ITCNT
064524  012701  066674          PFRET:  MOV     #PRIFLG,R1      ;R1 POINTS TO BEGINNING OF FLAGS
064530  005021                  1$:     CLR     (R1)+           ;CLEAR A FLAG
064532  022701  066722                  CMP     #ONCE,R1        ;ALL DONE?
064536  001374                          BNE     1$              ;BR IF NOT
064540  000005                          RESET                   ;CLEAR THE WORLD PRIOR TO RESTART
064542  013702  000042                  MOV     @#42,R2         ;CHECK FOR XXDP/ACT11 HOOK
064546  001404                          BEQ     DONE1           ;BR IF NO HOOK FOUND
064550  004712                  LOGICAL:JSR     PC,(R2)         ;RETURN TO XXDP OR ACT MONITOR
064552  000240                          NOP
064554  000240                          NOP
064556  000240                          NOP
064560  000137  003034          DONE1:  JMP     @#BEGIN         ;GO RESTART AT THE BEGINNNING
```

```
                                ;XXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXX
                                        .SBTTL  /  /  /  /  /  /  UTILITIES  /  /  /  /  /  /
                                ;XXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXX
                                .SBTTL
                                ; ****************************************************************
                                        .SBTTL SUBROUTINE TO CHECK FOR AND REPORT MISSED TESTS
                                ; ****************************************************************

                                ;THERE IS A BYTE TABLE TAGGED "STAB1" THAT IS MAINTAINED BY THE SCOPE
                                ;LOOP SERVICE ROUTINE. EACH TIME A TEST IN THE "CIT" OR "IEX" SECTION
                                ;IS ENTERED A CORRESPONDING BYTE IN THE TABLE IS SET TO 377.
                                ;DURING THE "BIT" SECTION OF THE PROGRAM A "MOVB  #377,STAB1(R0)"
                                ;IS USED TO FLAG EACH TEST ENTERED SINCE THE "SCOPE" TRAP HAS NOT BEEN
                                ;VERIFIED YET.
                                ;EACH ENTRY INDEX CORRESPONDS TO AN OCTAL TEST #. THE TABLE IS CLEARED
                                ;UPON ENTRY INTO THE "CIT" SECTION AND MAINTAINED BY THE SCOPE LOOP
                                ;SERVICE UNTIL END OF PASS SERVICE. THIS ROUTINE IS CALLED THEN TO
                                ;SCAN THE TABLE AND REPORT ANY MISSED TESTS. THIS ERROR CHECKING CAN
                                ;BE INHIBITED BY SETTING SW12 TO A"1". THE ERROR PRINTOUT HAS THE
                                ;FORMAT SHOWN BELOW:


                                ;       MISSED TEST
                                ;       NNN
                                ;       MMM
                                ;       XXX

                                ;       ETC

                                ;       WHERE: THE HEADER IS PRINTED ONLY ONCE AND NNN,MMM,XXX,
                                ;       ETC ARE THE OCTAL NO.S OF THE MISSED TESTS.


064564  032737  010000  177570  MISS:   BIT     #SW12,@#SR      ;INHIBIT MISSED TEST PRINTOUT ?
064572  001044                          BNE     5$              ;BR IF YES
064574  032737  020000  177570          BIT     #SW13,@#SR      ;INHIBIT PRINT ?
064602  001040                          BNE     5$              ;BR IF YES
064604  013700  066704                  MOV     @#FIRST,R0      ;USE TEST NO. AS INDEX TO ERROR TABLE
064610  013701  066706                  MOV     @#LAST,R1       ;USE [R1] TO INDICATE END OF MISSED
                                                                ;TEST ERROR TABLE
064614  122760  000377  070162  2$:     CMPB    #377,STAB1(R0)  ;WAS TEST FLAG = 377 ?
064622  001424                          BEQ     4$              ;BR IF YES - TEST EXECUTED
064624  005737  066710                  TST     @#MISFLG        ;HEADER PRINTED ?
064630  001004                          BNE     3$              ;BR IF YES - PRINT ONLY ONCE
064632  104400                          TYPE                    ;GO TYPE "MISSED TESTS"
064634  067477                          MISHDR
064636  005137  066710                  COM     @#MISFLG        ;SET FLAG TO PREVENT PRINTING AGAIN
064642  010002          3$:             MOV     R0,R2           ;GET THE TEST NO.
064644  004737  065760                  JSR     PC,@#OTA        ;GO CONVERT AND PRINT THE NO.
064650  104400                          TYPE
064652  067136                          DIGITS
064654  104400                          TYPE
064656  066726                          CRLF
064660  022737  177777  066666          CMP     #-1,@#ERRCNT    ;MAX ERROR COUNT ??
064666  001402                          BEQ     4$              ;BR IF YES
064670  005237  066666                  INC     @#ERRCNT        ;COUNT THE ERROR
```

```
26365  064674  020001          4$:     CMP     R0,R1           ;DONE ALL TABLE ENTRIES ?
26366  064676  001402                  BEQ     5$              ;BR IF YES
26367  064700  005200                  INC     R0              ;INDEX POINTS TO NEXT TEST FLAG
26368  064702  000744                  BR      2$              ;GO CHECK THE NEXT FLAG
26369  064704  000207          5$:     RTS     PC              ;RETURN TO END OF PASS SERVICE
26370
```

```
                                        ; ***************************************************************
                                                .SBTTL POWER FAIL SUBROUTINE
                                        ; ***************************************************************

064706  012737  064746  000024  PDWN:   MOV     #PUP,@#24       ;SET UP POWER FAIL VECTOR TO GO
064714  012737  000340  000026          MOV     #340,@#26       ;TO PUP ON POWER UP - LEVEL 7
064722  005237  066672                  INC     @#PFCNT         ;COUNT THE POWER FAIL
064726  022737  177777  066666          CMP     #-1,@#ERRCNT    ;MAX ERROR COUNT ??
064734  001402                          BEQ     1$              ;BR IF YES
064736  005237  066666                  INC     @#ERRCNT        ;COUNT THE ERROR
064742  000000                  1$:     HALT                    ;PWR RESTART SHOULD GO TO "PUP"
064744  000776                          BR      1$              ;HANG IF CONTINUE DEPRESSED

064746  012737  000340  177776  PUP:    MOV     #340,@#PSW      ;SET PRIORITY TO LEVEL 7 JUST IN CASE
064754  012706  001000                  MOV     #BTOO1,SP       ;RESET THE STACK POINTER
064760  005037  067602                  CLR     @#MBUFO         ;INIT STALL COUNTER
064764  005337  067602          1$:     DEC     @#MBUFO         ;COUNT ONE TIME
064770  001375                          BNE     1$              ;BR IF NOT BACK TO 000000
064772  012737  064706  000024          MOV     #PDWN,@#24      ;SET UP POWER FAIL VECTOR
065000  012737  000340  000026          MOV     #340,@#26       ;PRIORITY LEVEL 7
065006  032737  010000  177570          BIT     #SW12,@#SR      ;INHIBIT POWER FAIL MESSAGE ?
065014  001002                          BNE     2$              ;BR IF YES
065016  104400                          TYPE                    ;GO PRINT POWER MESSAGE
065020  067440                          PFMSG
065022  000137  064524          2$:     JMP     @#PFRET         ;GO CLEANUP AND ATTEMPT RESTART


                                        ; ***************************************************************
                                                .SBTTL "T" BIT SERVICE ROUTINE
                                        ; ***************************************************************

065026  062716  000004          TBSER:  ADD     #4,(SP)         ;MOVE RETURN PC AROUND ERROR WORDS
065032  042766  000020  000002          BIC     #20,2(SP)       ;TURN OFF THE "T" BIT
065040  000006                          RTT                     ;RETURN TO THE CALLING TEST
```

```
                                        ; ***************************************************************
                                                .SBTTL  RSVD INSTRUCTION TRAP SERVICE ROUTINE
                                        ; ***************************************************************

                                        ;THIS ROUTINE SERVICES UNEXPECTED RESERVED INSTRUCTION TRAP ERRORS
                                        ;IT RESULTS IN PRINTING THE ERROR MESSAGE: "TRAPPED TO 10 PC=XXXXXX"
                                        ;WHERE XXXXXX IS THE ADDRESS CONTAINING THE INSTRUCTION WORD THAT
                                        ;SPRUNG THE TRAP.  AFTER PRINTING THE ERROR MESSAGE AN ATTEMPT IS
                                        ;MADE TO RESTART THE PROGRAM AT THE BEGINNING.

                                        ;IF THE TRAP IS SPRUNG WHILE IN THE PROCESS OF TRYING TO SERVICE A
                                        ;PREVIOUS RSVD INSTRUCTION TRAP OR AN UNEXPECTED BUS ERROR THE PROGRAM
                                        ;WILL HALT.  AFTER THE HALT THE STACK WILL CONTAIN INFORMATION RELATIVE
                                        ;TO THE TWO SUCCESSIVE TRAPS AS SHOWN BELOW:

                                                ;[SP]   PC+2    OF 2ND TRAP
                                                ;[SP]+2 PSW         "
                                                ;[SP]+4 PC+2    OF 1ST TRAP
                                                ;[SP]+6 PSW         "

                                                ;LOCATION "CATERR" CAN BE EXAMINED TO OBTAIN THE FOLLOWING
                                                ;INFORMATION:

                                                        ;[CATERR]=401   RSVD INSTR TRAP COMBINED WITH A BUS ERROR
                                                                        ;TRAP (PC AT TIME OF ERROR HALT INDICATES
                                                                        ;WHICH OCCURRED FIRST)
                                                        ;[CATERR]=2     TWO SUCCESSIVE BUS ERROR TRAPS
                                                        ;[CATERR]=1000  TWO SUCCESSIVE RSVD INSTR TRAPS

                                        ;THE CONTENTS OF R0 (DISPLAYED IN THE DATA LIGHTS) AT THE TIME OF THE
                                        ;HALT PROVIDES FURTHER INFORMATION AS TO THE LAST TEST BEING EXECUTED
                                        ;WHEN THE TRAPS OCCURRED.


                                        ;THESE TWO INSTRUCTIONS ARE USED BY THE BASIC INSTRUCTION
                                        ;TESTS TO VERIFY THE RSVD INSTR TRAP MECHANISM PRIOR TO ACTIVATING THE SERVICE
                                        ;ROUTINE

065042  005167  001644          RSVTST: COM     RSVFLG          ;SET RSVD INSTR TRAP TEST FLAG
065046  000002                          RTI                     ;RETURN TO BASIC TEST

065050  005737  066720          RSERR:  TST     @#CATERR        ;ANY PENDING CATASTROPHIC ERRORS
065054  001032                          BNE     2$              ;BE IF YES
065056  105237  066721                  INCB    @#1+CATERR      ;SET RSVD INSTR FLAG
065062  032737  010000  177570          BIT     #SW12,@#SR      ;INHIBIT ERROR PRINT ?
065070  001020                          BNE     1$              ;BR IF YES
065072  104400                          TYPE                    ;GO TYPE "TRAPPED TO 10 PC="
065074  067520                          RSMSG
065076  011602                          MOV     (SP),R2         ;GET, CONVERT AND PRINT CONTENTS
065100  005742                          TST     -(R2)
065102  004737  065760                  JSR     PC,@#OTA        ;OF THE OC
065106  104400                          TYPE
065110  067136                          DIGITS
065112  104400                          TYPE                    ;OUTPUT CR / LF
065114  066726                          CRLF
065116  022737  177777  066666          CMP     #-1,@#ERRCNT    ;MAX ERROR COUNT ??
```

```
065124  001402                          BEQ     1$              ;BR IF YES
065126  005237  066666                  INC     @#ERRCNT        ;COUNT THE ERROR
065132  012706  001000          1$:     MOV     #BT001,SP
065136  000137  064524                  JMP     @#PFRET         ;GO ATTEMPT RESTART
065142  105237  066721          2$:     INCB    @#1+CATERR      ;INCREMENT RSVD INSTR FLAG
065146  000000                          HALT                    ;CATASTROPHIC ERROR HALT
065150  000770                          BR      1$              ;DEPRESSING CONTINUE WILL CAUSE
                                                                ;ATTEMPT TO RESTART.
```

```
                                ; ***********************************************************************
                                        .SBTTL  BUS ERROR TRAP SERVICE ROUTINE
                                ; ***********************************************************************

                                ;THIS ROUTINE SERVICES UNEXPECTED BUS ERROR TRAPS (BUS TIMEOUT, ODD ADDRESS
                                ;ERRORS, STACK OVERFLOW, AND ILLEGAL INSTRUCTIONS). IT RESULTS IN PRINTING THE
                                ;ERROR MESSAGE: "TRAPPED TO 4 PC =XXXXXX" WHERE XXXXXX IS THE
                                ;CONTENTS OF THE PC WHEN THE TRAP WAS SPRUNG.  AFTER PRINTING THE
                                ;ERROR MESSAGE AN ATTEMPT IS MADE TO RESTART THE PROGRAM AT
                                ;THE BEGINNING.

                                ;IF THE TRAP IS SPRUNG WHILE IN THE PROCESS OF TRYING TO SERVICE A PREVIOUS
                                ;RSVD INSTR TRAP OR A PREVIOUS BUS ERROR, THE PROGRAM WILL HALT.
                                ;AFTER THE HALT THE STACK WILL CONTAIN INFORMATION RELATIVE TO THE
                                ;TWO SUCCESSIVE TRAPS AS SHOWN BELOW:

                                        ;[SP]   PC+2    OF 2ND TRAP
                                        ;[SP]+2 PSW        "
                                        ;[SP]+4 PC+2    OF 1ST TRAP
                                        ;[SP]+6 PSW        "


                                        ;LOCATION "CATERR" CAN BE EXAMINED TO OBTAIN THE LOLLOWING
                                        ;INFORMATION:

                                                ;[CATERR]=401   RSVD INSTR TRAP COMBINED WITH A BUS ERROR
                                                                ;TRAP (PC AT TIME OF ERROR HALT
                                                                ;INDICATES WHICH OCCURRED FIRST)
                                                ;[CATERR]=2     TWO SUCCESSIVE BUS ERRORS
                                                ;[CATERR]=1000  TWO SUCCESSIVE RSVD INSTR TRAPS

                                ;THE CONTENTS OF R0 (DISPLAYED IN THE DATA LIGHTS) AT THE TIME OF
                                ;THE HALT PROVIDED FURTHER INFORMATION AS TO THE TEST IN PROGRESS
                                ;WHEN THE TRAPS OCCURRED.

                                ;THE CONTENTS OF THE SP CAN BE USED TO INDICATE IF STACK OVERFLOW CAUSED
                                ;THE BUSS ERROR TRAP(S) AS SHOWN BELOW:

                                        ;400>[SP]>336   YELLOW ZONE
                                        ;[SP]=0         RED ZONE

                                ;THESE TWO INSTRUCTIONS ARE USED BY THE BASIC INSTRUCTION TESTS TO
                                ;VERIFY THAT THE BUS ERROR TRAP MECHANISM WORKS PRIOR TO ACTIVATING
                                ;THE SERVICE ROUTINE

065152  005167  001536          BETST:  COM     BERFLG          ;SET BUS ERROR TRAP TEST FLAG
065156  000002                          RTI                     ;RETURN TO BASIC TEST

065160  005737  066720          BERR:   TST     @#CATERR        ;ANY CATASTROPHIC ERRORS PENDING?
065164  001031                          BNE     2$              ;BR IF YES
065166  105237  066720                  INCB    @#CATERR        ;SET CATASTROPHIC ERROR FLAG
065172  032737  010000  177570          BIT     #SW12,@#SR      ;INHIBIT ERROR PRINT
065200  001017                          BNE     1$              ;BR IF YES
065202  104400                          TYPE                    ;PRINT "TRAP TO 4" MESSAGE
065204  067452                          BEMSG
065206  011602                          MOV     (SP),R2         ;GET TRAP PC FROM STACK
```

```
065210  004737  065760                  JSR     PC,@#OTA        ;CONVERT IT TO ASCII
065214  104400                          TYPE                    ;GO TYPE TRAP PC
065216  067136                          DIGITS
065220  104400                          TYPE                    ;GO OUTPUT CR / LF
065222  066726                          CRLF
065224  022737  177777  066666          CMP     #-1,@#ERRCNT    ;MAX ERROR COUNT ??
065232  001402                          BEQ     1$              ;BR IF YES
065234  005237  066666                  INC     @#ERRCNT        ;COUNT THE ERROR
065240  012706  001000          1$:     MOV     #BT001,SP       ;RESET THE STACK POINTER
065244  000137  064524                  JMP     @#PFRET         ;GO CLEANUP FOR RESTART

065250  105237  066720          2$:     INCB    @#CATERR        ;SET CATASTROPHIC ERROR FLAG
065254  000000                          HALT                    ;CATASTROPHIC ERROR HALT-SCHOOLS OUT
065256  000770                          BR      1$              ;DEPRESS CONTINUE TO ATTEMPT RESTART
```

```
                                        ; ***************************************************************
                                                .SBTTL SCOPE SERVICE ROUTINE
                                        ; ***************************************************************

                                        ;THIS UTILITY IS CALLED BY AN IOT=SCOPE INSTRUCTION AT THE END
                                        ;OF EACH TEST IN THE COMPREHENSIVE INSTRUCTION TEST AND COM-
                                        ;BINED INSTRUCTION EXERCISER TEST SECTIONS OF THE PROGRAM.
                                        ;IT IS DESIGNED TO IMPLEMENT THE CONSOLE SWITCH OPTIONS DEFINED
                                        ;BELOW:

                                        ;       SW14 = 1        LOOP ON CURRENT TEST

                                        ;       SW11 = 1        INHIBIT SUB-TEST ITERATIONS

                                        ;       SW10 = 1        LOOP ON TEST SELECTED BY SR<09:00>


065260  005137  066702          SCOPEA: COM     @#SCOFLG        ;THESE TWO ILSTRUCTIONS ARE
065264  000002                          RTI                     ;USED IN THE BASIC TESTS TO
                                                                ;VERIFY THE IOT LINKAGE

065266  112760  000377  070162  SCOPEB: MOVB    #377,STAB1(R0)  ;SET FLAG IN MISSED TEST TABLE
065274  032737  040000  177570          BIT     #SW14,@#SR      ;LOOP ON CURRENT TEST ?
065302  001403                          BEQ     2$              ;BR IF NO - SW14=0
065304  013716  066654          1$:     MOV     @#RETURN,(SP)   ;SET UP RTN PC ON STK TC LOOP
065310  000002                          RTI                     ;RETURN TO CURRENT TEST
065312  032737  002000  177570  2$:     BIT     #SW10,@#SR      ;LOOP ON SELECTED TEST ?
065320  001412                          BEQ     3$              ;BR IF NO - SW10=0
065322  013737  177570  066700          MOV     @#SR,@#SELTST   ;GET CONTENTS OF SWITCHES
065330  042737  176000  066700          BIC     #176000,@#SELTST;MASK OUT SR<15:10>
065336  020037  066700                  CMP     R0,@#SELTST     ;IS THIS THE SELECTED TEST ?
065342  001760                          BEQ     1$              ;BR IF YES
065344  000407                          BR      4$              ;GO EXIT TO NEXT TEST
065346  032737  004000  177570  3$:     BIT     #SW11,@#SR      ;INHIBIT ITERATIONS ?
065354  001003                          BNE     4$              ;BR IF YES - SW11=1
065356  005337  066664                  DEC     @#ITCNT         ;COUNT ONE TIME
065362  001350                          BNE     1$              ;BR IF NOT DONE - DO IT AGIN
065364  013737  066662  066664  4$:     MOV     @#ICOUNT,@#ITCNT ;RESET ITERATION COUNTER
065372  011637  066654                  MOV     (SP),@#RETURN   ;SET UP NEW SCOPE RETURN
065376  000002                          RTI                     ;RETURN TO DO NEXT SEQ. TEST
```

```
                                        ; ***************************************************************
                                                .SBTTL ERROR SERVICE ROUTINE
                                        ; ***************************************************************

                                        ;THIS UTILITY IS CALLED BY AN ERRORX = EMTX INSTRUCTION OF THE
                                        ;FOLLOWING FORMAT:

                                        ;       E'N:    ERRORX
                                        ;               R'N

                                        ;       WHERE: X REPRESENTS THE CODING OF THE LOW BYTE IN THE EMT
                                        ;               AND INDICATES THE NO. OF COLUMNS TO BE PRINTED:

                                        ;                       X=0     ALL 8 COLUMNS
                                        ;                         7     1ST SEVEN COLUMNS
                                        ;                         6     1ST SIX COLUMNS
                                        ;                         5     1ST FIVE COLUMNS
                                        ;                         4     1ST FOUR COLUMNS
                                        ;                         3     1ST THREE COLUMNS
                                        ;                         2     1ST TWO COLUMNS
                                        ;                         1     1ST COLUMN ONLY

                                        ;               R'N IS THE ADDRESS WHERE CONTROL IS RETURNED AFTER
                                        ;               THE ERROR SERVICE IF SW09=1 (LOOP ON HARD ERROR).
                                        ;               IF SWITCH 09 IS RESET CONTROL ISRETURNED TO
                                        ;               E'N+4.

                                        ;IT IS DESIGNED TO SERVICE THE SWITCH OPTIONS DEFINED BELOW:

                                        ;               SW15=1  HALT ON ERROR - TESTED  AFTER
                                        ;                       PRINTING - DEPRESSING CONTINUE RESUMES NORMAL
                                        ;                       EXECUTION

                                        ;               SW13=1  INHIBIT ALL ERROR PRINTOUTS EXCEPT:

                                        ;                       1)BELL ON ERROR
                                        ;                       2)FAULT #
                                        ;                       3)INTRODUCTORY MESSAGE
                                        ;                       4)ANY CATASTROPHIC ERROR MESSAGE


                                        ;               SW09=1  LOCK ON HARD ERRORS

                                        ;THIS UTILITY ALSO CALLS THE OTA (OCTAL TO ASCII) AND TYPE (PRINT)
                                        ;UTILITIES TO FORMAT AND REPORT THE ERRORS

065400  005137  066676          ERRA:   COM     @#ERRFLG                ;THESE TWO INSTRUCTIONS ARE USED
065404  000002                          RTI                     ;IN THE BASIC TESTS TO VERIFY THE EMT

065406  022737  177777  066666  ERRB:   CMP     #-1,@#ERRCNT    ;ERROR COUNT = 177777 ??
065414  001402                          BEQ     1$              ;BR IF YES - FREEZE ERRCNT
065416  005237  066665                  INC     @#ERRCNT        ;COUNT THIS ERROR
065422  010246                  1$:     MOV     R2,-(SP)        ;SAVE R2 ON THE STACK
065424  016602  000002                  MOV     2(SP),R2        ;GET THE PC+2 OF ERROR CALL
065430  011237  066656                  MOV     (R2),@#ERRTN    ;GET THE ERROR LOOP ADDRESS
```

```
065434  014237  066640                  MOV     -(R2),@#COLCNT   ;GET THE ERROR EMT CALL
065440  042737  177770  066640          BIC     #177770,@#COLCNT ;MASK OUT BITS (15:03)
065446  032737  020000  177570  3$:     BIT     #SW13,@#SR       ;INHIBIT ERROR PRINTOUT ?
065454  001103                          BNE     6$               ;BR IF YES
065456  005737  066716                  TST     @#ERFLG1         ;ERROR HEADER PRINTED FLAG SET ??
065462  001006                          BNE     4$               ;BR IF IT IS-PRINTER HEADER ONCE PER PASS
065464  104400                          TYPE                     ;CALL THE TYPE UTILITY
065466  066732                          ERHDR1                   ;ADDR OF ERROR HEADER MSG 1
065470  104400                          TYPE                     ;CALL THE TYPE UTILITY
065472  067034                          ERHDR2                   ;ADDR OF ERROR HEADER MSG2
065474  005137  066716                  COM     @#ERFLG1         ;FLAG THAT THE HEADER WAS PRINTED ONCE
065500  104400                  4$:     TYPE                     ;START WITH A CR / LF
065502  066726                          CRLF
065504  004737  065746                  JSR     PC,@#8$          ;GO OUTPUT COLUMN ONE
065510  022737  000001  066640          CMP     #1,@#COLCNT      ;WAS IT AN ERROR1 CALL ?
065516  001460                          BEQ     5$               ;BR IF YES

065520  016602  000004                  MOV     4(SP),R2         ;GET THE ERROR PSW
065524  004737  065746                  JSR     PC,@#8$          ;GO OUTPUT COLUMN TWO
065530  022737  000002  066640          CMP     #2,@#COLCNT      ;WAS IT AN ERROR2 CALL ?
065536  001450                          BEQ     5$               ;BR IF YES

065540  010602                          MOV     SP,R2            ;GET THE CONTENTS OF THE SP
065542  005722                          TST     (R2)+            ;CORRECT IT
065544  004737  065746                  JSR     PC,@#8$          ;GO OUTPUT COLUMN 3
065550  022737  000003  066640          CMP     #3,@#COLCNT      ;WAS IT AN ERROR3 CALL ?
065556  001440                          BEQ     5$               ;BR IF YES

065560  010002                          MOV     R0,R2            ;GET THE TEST # IN R0
065564  004737  065746                  JSR     PC,@#8$          ;GO OUTPUT COLUMN 4
065566  022737  000004  066640          CMP     #4,@#COLCNT      ;WAS IT AN ERROR4 CALL ?
065574  001431                          BEQ     5$               ;BR IF YES

065576  010102                          MOV     R1,R2            ;GET THE COPY OF THE INSTRUCTION
065600  004737  065746                  JSR     PC,@#8$          ;GO OUTPUT COLUMN 5
065604  022737  000005  066640          CMP     #5,@#COLCNT      ;WAS IT AN ERROR5 CALL ?
065612  001422                          BEQ     5$               ;BR IF YES

065614  012602                          MOV     (SP)+,R2         ;GET THE ORIGINAL R2 OFF STACK
065616  004737  065746                  JSR     PC,@#8$          ;GO OUTPUT COLUMN 6
065622  010246                          MOV     R2,-(SP)         ;MAINTAIN COMPATABILITY
065624  022737  000006  066640          CMP     #6,@#COLCNT      ;WAS IT AN ERROR6 CALL ?
065632  001412                          BEQ     5$               ;BR IF YES

065634  010302                          MOV     R3,R2            ;GET THE CONTENTS OF R3
065636  004737  065746                  JSR     PC,@#8$          ;GO OUTPUT COLUMN 7
065642  022737  000007  066640          CMP     #7,@#COLCNT      ;WAS IT AN ERROR7 CALL ?
065650  001403                          BEQ     5$               ;BR IF YES

065652  010402                          MOV     R4,R2            ;GET THE CONTENTS OF R4
065654  004737  065746                  JSR     PC,@#8$          ;GO OUTPUT COLUMN 8
065660  104400                  5$:     TYPE                     ;CALL THE TYPE UTILITY
065662  066726                          CRLF                     ;ADDRESS OF THE CR / LF MESSAGE
065664  012602                  6$:     MOV     (SP)+,R2         ;RESTORE THE INTEGRITY OF R2
065666  032737  002000  177570          BIT     #SW10,@#SR       ;LOOP ON SELECTED TEST ???
065674  001012                          BNE     7$               ;BR IF YES - SW09 PART OF TEST NO.
```

```
065676  032737  001000  177570          BIT     #SW09,@#SR      ;LOOP ON HARD ERRORS ???
065704  001406                          BEQ     7$              ;BR IF NOT - REWARD TO THE FIRST
                                                                ;MAINTENANCE MAN WHO CALLS THE
                                                                ;AUTHOR OF THIS PROGRAM IN
                                                                ;MARLBORO,MASS.
065706  013716  066656                  MOV     @#ERRTN,(SP)    ;PUT ERROR RETURN ADDR ON STACK
065712  042766  000020  000002          BIC     #20,2(SP)       ;CLEAR "T" BIT ON THE STACK IN CASE
                                                                ;THIS ERROR OCCURRED IN "T" BIT TESTS
065720  000002                          RTI                     ;RETURN TO LOOP ON THIS ERROR CALL
065722  005737  177570          7$:     TST     @#SR            ;HALT AFTER PRINTING ???
065726  100001                          BPL     .+4             ;BR IF NOT
065730  000000                          HALT                    ;DEPRESS CONTINUE TO RESUME TEST
                                                                ;AFTER THE HALT THE ADDRESS DISPLAY
                                                                ;CONTAINS #(7$+10) AND THE DATA DISP-
                                                                ;LAY CONTAINS THE NUMBER OF THE FAIL-
                                                                ;ING TEST
065732  062716  000002                  ADD     #2,(SP)         ;MOVE RETURN PC AROUND RN
065736  042766  000020  000002          BIC     #20,2(SP)       ;CLEAR "T" BIT ON STACK IN CASE THIS
                                                                ;ERROR OCCURRED IN "T" BIT TESTS
065744  000002                          RTI                     ;RETURN TO INSTRUCTION AFTER ERROR

                                        ;CONVERSION AND OUTPUT CALLS

065746  004737  065760          8$:     JSR     PC,@#OTA                ;CONVERT [R2] TO SIX ASCII CHARS.
065752  104400                          TYPE                    ;CALL THE TYPE UTILITY
065754  067136                          DIGITS                  ;ADDRESS OF THE ASCII BUFFER
065756  000207                          RTS     PC              ;RETURN TO CALLER ABOVE
```

```
                                        ; ***************************************************************
                                                .SBTTL OCTAL TO ASCII CONVERSION ROUTINE
                                        ; ***************************************************************

                                        ;THIS ROUTINE CONVERTS THE 16 BIT OCTAL NUMBER IN R2 TO ITS 6 CHAR.
                                        ;ASCII EQUIVALENT AND STORES THE CHARACTERS IN AN EIGHT CHAR. BUFFER
                                        ;THAT STARTS AT THE ADDRESS TAGGED "DIGITS" - THE 7TH AND 8TH CHAR.
                                        ;POSITIONS ARE LOADED WITH A SPACE CHAR. FOLLOWED BY A ZERO TERMINATOR
                                        ;BYTE - THE ROUTINE IS CALLED VIA A "JSR  PC,OTA"

065760  004737  066146          OTA:    JSR     PC,@#SAVR               ;GO SAVE THE REGISTERS R0 THRU R5
065764  012704  067136                  MOV     #DIGITS,R4      ;SET UP R4 TO POINT TO ASCII BUFFER
065770  005003                          CLR     R3              ;INITIALIZE R3 FOR USE AS INDEX REG.
                                                                ;TO ASCII CONVERSION TABLE
065772  010201                          MOV     R2,R1           ;SAVE ORIGINAL NUMBER IN R1
065774  006302                  1$:     ASL     R2              ;MOST SIGNIFICANT BIT GOES INTO "C"
065776  006103                          ROL     R3              ;R3 CONTAINS THE MOST SIGNIFICANT BIT
066000  012700  000006                  MOV     #6,R0           ;COUNT SIX DIGITS CONVERSION
066004  000404                          BR      3$              ;CONVERT AND LOAD THE 1ST DIGIT
066006  006302                  2$:     ASL     R2              ;SHIFT BITS OUT OF R2 INTO "C"
066010  006103                          ROL     R3              ;SHIFT "C" INTO THE LSB POS. OF R3
066012  005301                          DEC     R1              ;COUNT ONE BIT SHIFTED
066014  001374                          BNE     2$              ;BR UNTIL 3 BITS SHIFTED
066016  012701  000003          3$:     MOV     #3,R1           ;INITIALIZE BIT SHIFT COUNTER
066022  116324  066644                  MOVB    DIGTAB(R3),(R4)+;MOVE CHAR. TO DIGIT BUFFER
066026  005003                          CLR     R3              ;CLEAR INDEX TO CONVERSION TABLE
066030  005300                          DEC     R0              ;COUNT ONE CHAR.
066032  001365                          BNE     2$              ;BR UNTIL 6 CHARS CONVERTED
066034  004737  066166                  JSR     PC,@#RESTR      ;GO RESTORE THE REGS
066040  000207                          RTS     PC              ;RETURN TO CALLER
```

```
                                        ; ***************************************************************
                                                .SBTTL PRINT SUBROUTINE
                                        ; ***************************************************************

                                        ;THIS ROUTINE IS CALLED TO PRINT ALL ASCII MESSAGES - IT IS CALLED VIA
                                        ;A TYPE = TRAP = 104400 INSTRUCTION AS SHOWN BELOW:

                                                ;TYPE
                                                ;ADDP

                                                ;WHERE "ADDR" IS THE STARTING ADDRESS OF THE MESSAGE BUFFER
                                                ;TO BE PRINTED - THE SUBROUTINE WILL CONTINUE TO PRINT CHAR-
                                                ;ACTERS UNTIL IT FINDS A "000" BYTE TERMINATOR

                                        ;IF FILLER CHARACTERS ARE REQUIRED THE LOCATION TAGGED "FILLS" MUST
                                        ;CONTAIN THE FOLLOWING INFORMATION:

                                                ;FILLS - ODD BYTE = NO. OF FILLERS REQUIRED
                                                ;FILLS - EVEN BYTE = FILLER CHARACTER DESIRED

                                                ;THE DEFAULT VALUE OF FILLS IS 0,0

066042  005137  066674          PRINA:  COM     @#PRIFLG                ;THESE TWO INSTRUCTIONS ARE
066046  000002                          RTI                     ;USED BY THE BASIC TESTS TO VERIFY
                                                                ;THE TRAP INSTRUCTION

066050  010046                  PRINT:  MOV     R0,-(SP)        ;SAVE R0 ON THE STACK
066052  017600  000002                  MOV     @2(SP),R0       ;SET R0 TO POINT TO THE MESSAGE BUFFER
066056  062766  000002  000002          ADD     #2,2(SP)        ;ADJUST THE RETURN PC TO POINT TO THE
                                                                ;INSTRUCTION FOLLOWING THE CALL
066064  112046                  1$:     MOVB    (R0)+,-(SP)     ;PUSH CHAR. TO BE TYPED ON THE STACK
                                                                ;AND UPDATE THE BUFFER POINTER
066066  001003                          BNE     2$              ;BRANCH IF NOT A 000 TERMINATOR
066070  005726                          TST     (SP)+           ;POP TERMINATOR OFF THE STACK
066072  012600                          MOV     (SP)+,R0        ;RESTORE THE ORIGINAL R0
066074  000002                          RTI                     ;RETURN TO CALLER
066076  004737  066130          2$:     JSR     PC,@#5$         ;GO TYPE THE CHARACTER
066102  122726  000012          3$:     CMPB    #12,(SP)+       ;WAS CHAR TYPED A LINE FEED ?
066106  001366                          BNE     1$              ;BRANCH IF NOT
066110  013746  066660                  MOV     @#FILLS,-(SP)   ;GET THE FILLER COUNT AND CHARACTER
066114  105366  000001          4$:     DECB    1(SP)           ;COUNT ONE FILLER OUT
066120  002770                          BLT     3$              ;BR IF NO MORE FILLERS NEEDED
066122  004737  066130                  JSR     PC,@#5$         ;GO TYPE THE FILLER
066126  000772                          BR      4$              ;GO COUNT AND TEST FILLER COUNT

066130  105737  177564          5$:     TSTB    @#XCSR          ;OUTPUT DEVICE READY
066134  100375                          BPL     5$              ;BRANCH BACK IF NOT READY - NOTE THE
                                                                ;PROGRAM WILL HANG HERE IN THE EVENT THAT
                                                                ;THE DL11 READY LOGIC FAILS DURING RUN
066136  116637  000002  177566          MOVB    2(SP),@#XDBR    ;OUTPUT THE CHARACTER
066144  000207                          RTS     PC              ;RETURN TO CALLER
```

```
                                        ; ***************************************************************
                                                .SBTTL SAVE REGISTER SUBROUTINE
                                        ; ***************************************************************

                                        ;THIS ROUTINE IS CALLED BY THE "OTA" UTILITY AND WILL SAVE GENERAL
                                        ;REGISTERS R0 THRU R5 ON THE PROCESSOR STACK

066146  010546                          SAVR:   MOV     R5,-(SP)        ;PUSH R5 ON THE STACK
066150  010446                                  MOV     R4,-(SP)        ;PUSH R4
066152  010346                                  MOV     R3,-(SP)        ;PUSH R3
066154  010246                                  MOV     R2,-(SP)        ;PUSH R2
066156  010146                                  MOV     R1,-(SP)        ;PUSH R1
066160  010046                                  MOV     R0,-(SP)        ;PUSH R0
066162  016607  000014                          MOV     14(SP),PC       ;RETURN TO THE INSTRUCTION THAT
                                                                        ;FOLLOWS THE "JSR PC,SAVR" CALL
```

```
                                        ; ***************************************************************
                                                .SBTTL RESTORE REGISTERS SUB-ROUTINE
                                        ; ***************************************************************

                                        ;THIS ROUTINE COMPLEMENTS THE SAVE REGISTER ROUTINE AND WILL RESTORE
                                        ;GENERAL REGISTERS R0 THRU R5 FROM THE STACK - IT IS CALLED VIA A
                                        ;JSR    PC,RESTR.

066166  012666  000014          RESTR:  MOV     (SP)+,14(SP)    ;REPOSITION THE RETURN PC ON THE STACK
066172  012600                          MOV     (SP)+,R0        ;RESTORE R0 - R5
066174  012601                          MOV     (SP)+,R1
066176  012602                          MOV     (SP)+,R2
066200  012603                          MOV     (SP)+,R3
066202  012604                          MOV     (SP)+,R4
066204  012605                          MOV     (SP)+,R5
066206  000207                          RTS     PC              ;RETURN TO THE INSTRUCTION THAT
                                                                ;FOLLOWS THE "JSR RESTR" CALL
```

```
                                        ; ***********************************************************************
                                                .SBTTL ROUTINES TO CHECK FOR AND FLAG 11/40 OPTIONS
                                        ; ***********************************************************************

066210  005737  066670          TSTOPT: TST     @#PASCNT        ;1ST PASS ??
066214  001027                          BNE     1$              ;BR IF NOT
066216  005037  066636                  CLR     @#OPTION        ;CLEAR THE OPTION FLAG WORD
066222  032737  010000  177570          BIT     #SW12,@#SR      ;INHIBIT PRINTING ??
066230  001002                          BNE     .+6             ;BR IF YES
066232  104400                          TYPE                    ;TYPE OPTIONS AVAIL. HEADER
066234  067270                          OPT1
066236  004737  066276                  JSR     PC,@#CHKKT      ;GO TEST FOR KT11-D OPTION
066242  004737  066352                  JSR     PC,@#CHKKJ      ;GO TEST FOR KJ11-A OPTION
066246  004737  066426                  JSR     PC,@#CHKKF      ;GO TEST FOR KE11-F OPTION
066252  004737  066504                  JSR     PC,@#CHKKE      ;GO TEST FOR KE11-E OPTION
066256  004737  066562                  JSR     PC,@#CHKKW      ;GO TEST FOR KW11-L OPTION
066262  005737  066636                  TST     @#OPTION        ;ANY OPTIONS FOUND
066266  001002                          BNE     1$              ;BR IF YES
066270  104400                          TYPE                    ;GO TYPE "NONE"
066272  067423                          OPT7
066274  000207                  1$:     RTS     PC              ;RETURN TO "CIT" START-UP

066276  013704  000004          CHKKT:  MOV     @#4,R4          ;SAVE THE TIMEOUT VECTOR
066302  012737  066340  000004          MOV     #1$,@#4         ;GO TO 1$ IF TRAP OCCURS
066310  005737  177572                  TST     @#177572        ;REFERENCE KT11 SR0
066314  052737  000200  066636          BIS     #200,@#OPTION   ;SET BIT7 IF KT IS THERE
066322  032737  010000  177570          BIT     #SW12,@#SR      ;INHIBIT PRINTING ?
066330  001002                          BNE     .+6             ;BR IF YES
066332  104400                          TYPE                    ;GO TYPE "KT11-D"
066334  067334                          OPT2
066336  000402                          BR      2$
066340  062706  000004          1$:     ADD     #4,SP           ;FIX UP THE SP
066344  010437  000004          2$:     MOV     R4,@#4          ;RESTORE THE TIMEOUT VECTOR
066350  000207                          RTS     PC              ;RETURN TO TSTOPT ROUTINE

066352  013704  000004          CHKKJ:  MOV     @#4,R4          ;SAVE THE TIMEOUT VECTOR
066356  012737  066414  000004          MOV     #1$,@#4         ;GO TO 1$ IF TRAP OCCURS
066364  005737  177774                  TST     @#177774        ;REFERENCE KJ11 REG.
066370  052737  000004  066636          BIS     #4,@#OPTION     ;SET BIT2 IF KJ IS THERE
066376  032737  010000  177570          BIT     #SW12,@#SR      ;INHIBIT PRINTING ?
066404  001002                          BNE     .+6             ;BR IF YES
066406  104400                          TYPE                    ;GO TYPE "KJ11-A"
066410  067347                          OPT3
066412  000402                          BR      2$
066414  062706  000004          1$:     ADD     #4,SP           ;FIX UP THE SP
066420  010437  000004          2$:     MOV     R4,@#4          ;RESTORE THE TIMEOUT VECTOR
066424  000207                          RTS     PC              ;RETURN TO TSTOPT ROUTINE

066426  013704  000010          CHKKF:  MOV     @#10,R4         ;SAVE THE RSVD INSTR VECTOR
066432  012737  066472  000010          MOV     #1$,@#10        ;GO TO 1$ IF TRAP OCCURS
066440  012702  067602                  MOV     #MBUF0,R2       ;SET UP FOR FADD TRY
066444  075002                          FADD    R2              ;TEST FOR THE KE11-F OPTION
066446  052737  000002  066636          BIS     #2,@#OPTION     ;SET BIT1 IF IT RESPONDS
066454  032737  010000  177570          BIT     #SW12,@#SR      ;INHIBIT PRINTING ?
066462  001002                          BNE     .+6             ;BR IF YES
066464  104400                          TYPE                    ;GO TYPE "KE11-F"
```

```
066466  067362                          OPT4
066470  000402                          BR      2$
066472  062706  000004          1$:     ADD     #4,SP           ;FIX UP THE SP
066476  010437  000010          2$:     MOV     R4,@#10         ;RESTORE THE RSVD INSTR VECTOR
066502  000207                          RTS     PC              ;RETURN TO TSTOPT ROUTINE

066504  013704  000010          CHKKE:  MOV     @#10,R4         ;SAVE THE RSVD INSTR VECTOR
066510  012737  066550  000010          MOV     #1$,@#10        ;GO TO 1$ IF TRAP OCCURS
066516  005001                          CLR     R1              ;SET UP TO TRY ASH INSTR.
066520  005002                          CLR     R2
066522  072201                          ASH     R1,R2           ;TRY A KE INSTR
066524  052737  000001  066636          BIS     #1,@#OPTION     ;SET BIT0 IF KE IS THERE
066532  032737  010000  177570          BIT     #SW12,@#SR      ;INHIBIT PRINTING ?
066540  001002                          BNE     .+6             ;BR IF YES
066542  104400                          TYPE                    ;GO TYPE "KE11-E"
066544  067375                          OPT5
066546  000402                          BR      2$
066550  062706  000004          1$:     ADD     #4,SP           ;FIX UP THE SP
066554  010437  000010          2$:     MOV     R4,@#10         ;RESTORE THE RSVD INSTR VECTOR
066560  000207                          RTS     PC              ;RETURN TO TSTOPT ROUTINE

066562  013704  000004          CHKKW:  MOV     @#4,R4          ;SAVE THE TIMEOUT VECTOR
066566  012737  066624  000004          MOV     #1$,@#4         ;GO TO 1$ IF TRAP OCCURS
066574  005737  177546                  TST     @#177546        ;REFERENCE KW11-L CSR
066600  052737  100000  066636          BIS     #100000,@#OPTION;SET BIT15 IF KW IS THERE
066606  032737  010000  177570          BIT     #SW12,@#SR      ;INHIBIT PRINTING ?
066614  001002                          BNE     .+6             ;BR IF YES
066616  104400                          TYPE                    ;GO TYPE "KW11-L"
066620  067410                          OPT6
066622  000402                          BR      2$
066624  062706  000004          1$:     ADD     #4,SP           ;FIX UP THE SP
066630  010437  000004          2$:     MOV     R4,@#4          ;RESTORE THE TIMEOUT VECTOR
066634  000207                          RTS     PC              ;RETURN TO TSTOPT ROUTINE
```

```
                                ;FLAGS, CONSTANTS, AND VARIABLES

066636  000000                  OPTION: 0                       ;SET UP ON ENTRY TO "CIT" SECTION TO
                                                                ;SPECIFY OPTIONS INSTALLED:
                                                                ;BIT15=1 KW11-L INSTALLED
                                                                ;BIT07=1 KT11-D INSTALLED
                                                                ;BIT02=1 KJ11-A INSTALLED
                                                                ;BIT01=1 KE11-F INSTALLED
                                                                ;BIT00=1 KE11-E INSTALLED
066640  000000                  COLCNT: 0                       ;USED BY ERROR SERVICE TO STORE COLUMN COUNT
066642  000000                  BPTLOC: 0                       ;STORES 16 USER DEFINED MAINTENANCE
                                                                ;BREAKPOINTS
066644  030460                  DIGTAB: "01                     ;OCTAL TO ASCII CONVERSION TABLE
066646  031462                          "23
066650  032464                          "45
066652  033466                          "67
066654  000000                  RETURN: 0                       ;USED BY SCOPE TO STORE RETURN ADDRESS
066656  000000                  ERRTN:  0                       ;USED BY ERROR SERV. TO STORE ERROR RETURN ADDR.
066660  002400                  FILLS:  02400                   ;STORES FILL CHAR AND FILL COUNT
066662  000001                  ICOUNT: 1                       ;ITERATION COUNTERS
066664  000001                  ITCNT:  1
066666  000000                  ERRCNT: 0                       ;STORES TOTAL ERROR COUNT
066670  000000                  PASCNT: 0                       ;STORES TOTAL NO. OF PASSES
066672  000000                  PFCNT:  0                       ;KEEPS COUNT OF # OF PWRFAILS
066674  000000                  PRIFLG: 0                       ;FLAG USED BY BASIC TESTS FOR TRAP TEST
066676  000000                  ERRFLG: 0                       ;FLAG USED BY BASIC TESTS FOR EMT TEST
066700  000000                  SELTST: 0                       ;STORES SR<8:0> FOR LOOP ON SELECTED TEST
066702  000000                  SCOFLG: 0                       ;USED BY BASIC TESTS FOR IOT TEST
066704  000000                  FIRST:  0                       ;CONTAINS FIRST TEST # LOGGED IN MISSED TEST TABLE
066706  000000                  LAST:   0                       ;CONTAINS LAST TEST # LOGGED IN MISSED TEST TABLE
066710  000000                  MISFLG: 0                       ;FLAGS MISSED TEST ERROR HEADER PRINTED
066712  000000                  RSVFLG: 0                       ;FLAG USED BY BASIC TEST OF RSVD INSTR TRAP
066714  000000                  BERFLG: 0                       ;FLAG USED BY BASIC TEST OF BUS ERROR TRAPS
066716  000000                  ERFLG1: 0                       ;ALLOWS ONLY 1 ERROR HEADER PER PASS
066720  000000                  CATERR: 0                       ;FLAGS USED BY BUS ERROR AND RSVD INSTR TRAP
                                                                ;SERVICE ROUTINES
066722  000000                  ONCE:   0                       ;FLAGS PROGRAM TITLE HAS BEEN PRINTED
```

```
                                        ;MESSAGE TABLES

                                        .EVEN
066724  000007                          BELL:   7
066726  005015                          CRLF:   5015
066730  000000                                  0
066732                                  ERHDR1:
066732  005015  024040  041520          .ASCIZ  <15><12>  (PC)    (PS)    (SP)    TEST    (IR)    DEST    WAS     S / B '
066740  020051  020040  024040
066746  051520  020051  020040
066754  024040  050123  020051
066762  020040  052040  051505
066770  020124  020040  024040
066776  051111  020051  020040
067004  042040  051505  020124
067012  020040  053440  051501
067020  020040  020040  051440
067026  027440  041040  000040
067034                                  ERHDR2:
067034  005015  024040  033522          .ASCIZ <15><12>' (R7)    (PSW)   (R6)    (R0)    (R1)    (R2)    (R3)    (R4)'<15><12>
067042  020051  020040  024040
067050  051520  024527  020040
067056  024040  033122  020051
067064  020040  024040  030122
067072  020051  020040  024040
067100  030522  020051  020040
067106  024040  031122  020051
067114  020040  024040  031522
067122  020051  020040  024040
067130  032122  006451  000012
067136  030060  030060  030060          DIGITS: .ASCIZ  '000000  '
067144  020040     000
067147     015  050012  051501          EOP1:   .ASCIZ  <15><12>'PASCNT = '
067154  047103  020124  020075
067162     000
067163     040  050040  041506          PFMESS: .ASCIZ  '  PFCNT = '
067170  052116  036440  000040
067176  020040  051105  041522          EOP2:   .ASCIZ '  ERRCNT = '
067204  052116  036440  000040
067212  005015  041104  042521          IDENT1: .ASCIZ <15><12>'DBQEA-B   KD11-A DIAGNOSTIC   VERSION 001'<15><12>
067220  026501  020102  020040
067226  042113  030461  040455
067234  042040  040511  047107
067242  051517  044524  020103
067250  020040  042526  051522
067256  047511  020116  030060
067264  006461  000012
067270  005015  042120  030520          OPT1:   .ASCIZ  <15><12>'PDP11/40 INTERNAL OPTIONS FOUND'<15><12>
067276  027461  030064  044440
067304  052116  051105  040516
067312  020114  050117  044524
067320  047117  020123  047506
067326  047125  006504  000012
067334  005015  052113  030461          OPT2:   .ASCIZ  <15><12>'KT11-D'<15><12>
067342  042055  005015     000
067347     015  045412  030512          OPT3:   .ASCIZ  <15><12>'KJ11-A'<15><12>
```

```
 27037  067354  026461  006501  000012
 27038  067362  005015  042513  030461  OPT4:   .ASCIZ  <15><12>'KE11-F'<15><12>
 27039  067370  043055  005015     000
 27040  067375     015  045412  030505  OPT5:   .ASCIZ  <15><12>'KE11-E'<15><12>
 27041  067402  026461  006505  000012
 27042  067410  005015  053513  030461  OPT6:   .ASCIZ  <15><12>'KW11-L'<15><12>
 27043  067416  046055  005015     000
 27044  067423     015  047012  047117  OPT7:   .ASCIZ  <15><12>'NONE FOUND'
 27045  067430  020105  047506  047125
 27046  067436  000104
 27047  067440  005015  047520  042527  PFMSG:  .ASCIZ <15><12>'POWER' <15><12>
 27048  067446  006522  000012
 27049  067452  005015  051124  050101  BEMSG:  .ASCIZ <15><12>'TRAPPED TO 4 PC = '
 27050  067460  042520  020104  047524
 27051  067466  032040  050040  020103
 27052  067474  020075     000
 27053  067477     015  046412  051511  MISHDR: .ASCIZ <15><12>'MISSED TESTS'<15><12>
 27054  067504  042523  020104  042524
 27055  067512  052123  006523  000012
 27056  067520  005015  051124  050101  RSMSG:  .ASCIZ <15><12>'TRAPPED TO 10 PC = '
 27057  067526  042520  020104  047524
 27058  067534  030440  020060  041520
 27059  067542  036440  000040
 27060                                  .EVEN
```

```
                                        ;COMMON DATA STRUCTURES AND MISCELLANEOUS TABLES

067546  177400                          OBUF:   177400                  ;DL11 OUTPUT TEST BUFFER
067550  177400                                  177400
067552  177400                                  177400
067554  177400                                  177400

067556  000004                          IBUF:   .BLKW   4               ;DL11 INPUT TEST BUFFER

067566  067612                          ATA:    DWTA
067570  070136                                  DWTB
067572  070152                                  DBTA
067574  070156                                  DBTB
067576  067602                                  MBUF0
067600  067606                                  MBUF1

067602  000000                          MBUF0:  0
067604  000000                                  0
067606  000000                          MBUF1:  0
067610  000000                                  0
067612  000000                          DWTA:   0
067614  177777                                  -1
067616  177400                                  177400
067620  000377                                  377
067622  125252                                  125252
067624  052525                                  052525

                                        ;THIS TABLE OF 8 ENTRIES IS USED BY THE ALU ADD TEST IN THE
                                        ;COMBINED INSTRUCTION TESTS

067626  000000                          ALUADD: 000000                  ;NULL
067630  000000                                  000000                  ;SRC OP1
067632  000000                                  000000                  ;DST OP1
067634  000000                                  000000                  ;ANS1
067636  177777                                  177777                  ;SRC OP2
067640  177777                                  177777                  ;DST OP2
067642  177776                                  177776                  ;ANS2
067644  125252                                  125252                  ;SRC OP3
067646  052525                                  052525                  ;DST OP3
067650  177777                                  177777                  ;ANS3
067652  052525                                  052525                  ;SRC OP4
067654  125252                                  125252                  ;DST OP4
067656  177777                                  177777                  ;ANS4
067660  125252                                  125252                  ;SRC OP5
067662  125252                                  125252                  ;DST OP5
067664  052524                                  052524                  ;ANS5
067666  052525                                  052525                  ;SRC OP6
067670  052525                                  052525                  ;DST OP6
067672  125252                                  125252                  ;ANS6
067674  052525                                  052525                  ;SRC OP7
067676  125253                                  125253                  ;DST OP7
067700  000000                                  000000                  ;ANS7
067702  125253                                  125253                  ;SRC OP8
067704  052525                                  052525                  ;DST OP8
067706  000000                                  000000                  ;ANS8
```

```
27117
27118                                   ;THIS TABLE OF 8 ENTRIES IS USED BY THE ALU "AND" TESTS IN THE
27119                                   ;COMBINED INSTRUCTION EXERCISER TESTS
27120
27121  067710  000000                   ANDTAB: 000000                  ;NULL ENTRY
27122  067712  000000                           000000                  ;SRC OP1
27123  067714  000000                           000000                  ;DEST OP1
27124  067716  000000                           000000                  ;ANS1
27125  067720  177777                           177777                  ;SRC OP2
27126  067722  177777                           177777                  ;DST OP2
27127  067724  000000                           000000                  ;ANS2
27128  067726  000000                           000000                  ;SRC OP3
27129  067730  177777                           177777                  ;DST OP3
27130  067732  177777                           177777                  ;ANS3
27131  067734  177777                           177777                  ;SRC OP4
27132  067736  000000                           000000                  ;DST OP4
27133  067740  000000                           000000                  ;ANS4
27134  067742  125252                           125252                  ;SRC OP5
27135  067744  125252                           125252                  ;DST OP5
27136  067746  000000                           000000                  ;ANS5
27137  067750  052525                           052525                  ;SRC OP6
27138  067752  052525                           052525                  ;DST OP6
27139  067754  000000                           000000                  ;ANS6
27140  067756  125252                           125252                  ;SRC OP7
27141  067760  052525                           052525                  ;DST OP7
27142  067762  052525                           052525                  ;ANS7
27143  067764  052525                           052525                  ;SRC OP8
27144  067766  125252                           125252                  ;DST OP8
27145  067770  125252                           125252                  ;ANS8
27146
27147                                   ;THIS TABLE OF 8 ENTRIES IS USED BY THE ALU "OR" TEST IN THE
27148                                   ;COMBINED INSTRUCTION EXERCISER TEST
27149
27150  067772  000000                   ORTAB:  000000                  ;NULL ENTRY
27151  067774  000000                           000000                  ;SRC OP1
27152  067776  000000                           000000                  ;DEST OP1
27153  070000  000000                           000000                  ;ANS1
27154  070002  177777                           177777                  ;SRC OP2
27155  070004  177777                           177777                  ;DST OP2
27156  070006  177777                           177777                  ;ANS2
27157  070010  000000                           000000                  ;SRC OP3
27158  070012  177777                           177777                  ;DST OP3
27159  070014  177777                           177777                  ;ANS3
27160  070016  177777                           177777                  ;SRC OP4
27161  070020  000000                           000000                  ;DST OP4
27162  070022  177777                           177777                  ;ANS4
27163  070024  125252                           125252                  ;SRC OP5
27164  070026  125252                           125252                  ;DST OP5
27165  070030  125252                           125252                  ;ANS5
27166  070032  052525                           052525                  ;SRC OP6
27167  070034  052525                           052525                  ;DST OP6
27168  070036  052525                           052525                  ;ANS6
27169  070040  125252                           125252                  ;SRC OP7
27170  070042  052525                           052525                  ;DST OP7
27171  070044  177777                           177777                  ;ANS7
27172  070046  052525                           052525                  ;SRC OP8
```

```
070050  125252                          125252                  ;DST OP8
070052  177777                          177777                  ;ANS8


                                ;THIS TABLE OF 8 ENTRIES IS USED BYTHE ALU SUB TEST IN THE
                                ;COMBINED INSTRUCTION EXERCISER TESTS

070054  000000                  ALLSUB: 000000                  ;NULL
070056  000000                          000000                  ;SRC OP1
070060  000000                          000000                  ;DST OP1
070062  000000                          000000                  ;ANS1
070064  177777                          177777                  ;SRC OP2
070066  177777                          177777                  ;DST OP2
070070  000000                          000000                  ;ANS2
070072  125252                          125252                  ;SRC OP3
070074  052525                          052525                  ;DST OP3
070076  125253                          125253                  ;ANS3
070100  052525                          052525                  ;SRC OP4
070102  125252                          125252                  ;DST OP4
070104  052525                          052525                  ;ANS4
070106  125252                          125252                  ;SRC OP5
070110  125252                          125252                  ;DST OP5
070112  000000                          000000                  ;ANS5
070114  052525                          052525                  ;SRC OP6
070116  052525                          052525                  ;DST OP6
070120  000000                          000000                  ;ANS6
070122  052525                          052525                  ;SRC OP7
070124  125253                          125253                  ;DST OP7
070126  052526                          052526                  ;ANS7
070130  125253                          125253                  ;SPC OP8
070132  052525                          052525                  ;DST OP8
070134  125252                          125252                  ;ANS8

070136  000000                  DWTB:   0
070140  000001                          1
070142  000400                          400
070144  177401                          177401
070146  052526                          52526
070150  125253                          125253
                                .EVEN
070152                          DBTA:
070152     000     377     252  .BYTE   000,377,252,125
070155     125
070156                          DBTB:
070156     000     001     120  .BYTE   000,001,120,253
070161     253
070162  001022                  STAB1:  .BLKB   530.            ;RESERVE 530. BYTE TABLE FOR
                                                                ;LOGGING ANY MISSED TESTS
071204  000000                  STAB2:  0

        000001                  .END
```

ALUADD	067626	25914	25916	27091#										
ALUSUB	070054	25983	25985	27180#										
ANDTAB	067710	26056	26058	27121#										
ATA	067566	5387	5487	5499	5530	5593	5624	5704	5741	5776	5789	5816	5828	5856
		14183	14195	14228	14240	14270	14283	14313	14325	14355	14368	14398	14434	14471
		14508	14545	14591	14637	14638	14653	14683	14684	14699	14729	14775	14821	14822
		14837	14867	14868	14883	14914	14953	14992	15031	16078	16091	16164	16177	16246
		16700	16715	16756	16771	16810	16826	16866	16882	17142	17157	17198	17213	17252
		17268	17308	17324	17565	17618	17667	17717	17839	17914	18324	18329	18415	18420
		18499	18614	20474	20551	20629	27070#							
A0012	003354	4451	4456#											
A0013	003414	4488	4493#											
A002	001006	2998#	3002											
A0021	003764	4707	4711#											
A0022	004034	4746	4751#											
A0023	004102	4785	4790#											
A0024	004154	4823	4828#											
A0032	004526	5040	5045#											
A0033	004576	5078	5083#											
A0034	004646	5115	5120#											
A0035	004716	5153	5158#											
A0036	004762	5190	5195#											
A0037	005036	5229	5234#											
A0040	005122	5271	5276#											
A0041	005174	5310	5315#											
A0042	005262	5352	5360#											
A0046	005512	5494	5499#											
A0050	005622	5561	5566#											
A0053	006004	5665	5671#											
A0054	006064	5707	5713#											
A0056	006214	5783	5789#											
A0057	006272	5823	5828#											
A0062	006502	5934	5940#											
A0063	006556	5975	5980#											
A0072	007176	6221	6227#											
A0074	007302	6289	6294#											
A0077	007514	6405	6411#											
A0100	007600	6452	6457#											
A0101	007704	6506	6511#											
A0102	010010	6560	6565#											
A0103	010112	6614	6619#											
A0104	010230	6671	6677#											
A0105	010320	6714	6720#											
A0106	010410	6757	6763#											
A0107	010500	6799	6805#											
A0110	010566	6841	6847#											
A0111	010654	6884	6890#											
A0112	010744	6926	6932#											
A0113	011034	6969	6975#											
A0114	011112	7011	7016#											
A0115	011170	7052	7057#											
A0116	011256	7096	7101#											
A0117	011356	7151	7156#											
A0124	011704	7331	7339#											
A0125	011744	7369	7374#											
A0126	012020	7403	7412#											

A0127	012110	7449	7455#
A0130	012206	7486	7497#
A0131	012334	7551	7556#
A0132	012412	7580	7591#
A0133	012530	7637	7644#
A0136	012766	7761	7766#
A0140	013156	7843	7849#
A015	001256	3324	3329#
A0160	014252	8423	8428#
A0162	014354	8500	8505#
A017	001340	3395	3400#
A020	001372	3432	3437#
A021	001422	3468	3473#
A0224	015724	9616	9621#
A0226	016036	9696	9701#
A023	001512	3539	3544#
A0230	016156	9781	9786#
A0232	016352	9889	9894#
A0234	016504	9975	9980#
A0235	016564	10022	10027#
A0236	016644	10071	10076#
A0237	017006	10146	10151#
A0240	017062	10192	10197#
A0241	017142	10238	10243#
A0242	017222	10284	10289#
A0243	017300	10330	10335#
A0244	017354	10376	10381#
A0245	017434	10422	10427#
A0246	017514	10468	10473#
A0247	017572	10514	10519#
A0250	017652	10560	10565#
A0251	017730	10605	10610#
A0252	020010	10650	10655#
A0253	020066	10695	10700#
A0254	020146	10740	10745#
A0255	020226	10785	10790#
A0256	020306	10830	10835#
A0257	020366	10876	10881#
A0260	020450	10922	10927#
A0261	020530	10968	10973#
A0262	020612	11014	11019#
A0263	020674	11060	11065#
A0264	020750	11102	11107#
A0265	021040	11150	11155#
A0266	021120	11192	11197#
A0267	021212	11240	11245#
A0270	021272	11282	11287#
A0271	021364	11330	11335#
A0272	021440	11371	11376#
A0273	021526	11418	11423#
A0274	021616	11465	11470#
A0275	021674	11509	11514#
A0276	021752	11553	11557#
A0277	022026	11595	11599#
A0300	022106	11638	11642#
A0301	022164	11682	11686#

A0302	022242	11725	11729#
A0303	022322	11768	11772#
A0304	022400	11811	11815#
A0305	022460	11854	11858#
A0306	022534	11896	11900#
A0307	022612	11939	11943#
A0310	022672	11982	11986#
A0311	022746	12025	12029#
A0312	023026	12069	12073#
A0313	023106	12113	12117#
A0314	023162	12157	12161#
A0315	023242	12200	12204#
A0316	023320	12243	12247#
A0317	023400	12285	12289#
A032	001720	3751	3756#
A0320	023456	12328	12332#
A0321	023536	12371	12375#
A0322	023616	12414	12418#
A0323	023674	12456	12460#
A0324	023750	12499	12504#
A0325	024032	12546	12551#
A0326	024112	12591	12595#
A0327	024170	12634	12638#
A033	001762	3790	3795#
A0330	024264	12684	12688#
A0331	024344	12729	12733#
A0332	024424	12773	12777#
A0333	024506	12817	12821#
A0334	024600	12864	12868#
A0335	024662	12908	12912#
A0336	024740	12951	12955#
A0337	025020	12995	12999#
A034	002024	3827	3832#
A0340	025102	13039	13043#
A0341	025160	13083	13087#
A0342	025242	13127	13131#
A0343	025324	13171	13175#
A0344	025402	13215	13219#
A0345	025464	13259	13263#
A0346	025[illegible]44	13303	13307#
A0347	025626	13346	13350#
A0350	025[illegible]06	13390	13394#
A0351	025770	13434	13438#
A0352	026052	13478	13482#
A0353	026132	13521	13525#
A0354	026214	13566	13571#
A0355	026274	13610	13615#
A0356	026354	13655	13660#
A0357	026434	13699	13704#
A0360	026514	13743	13748#
A0361	026576	13786	13791#
A0363	026730	13866	13871#
A0365	027062	13945	13950#
A0367	027214	14024	14029#
A0371	027346	14105	14110#
A0372	027432	14149	14154#

A0373	027506	14190	14195#
A0374	027576	14235	14240#
A0375	027662	14278	14283#
A0376	027740	14320	14325#
A0377	030024	14363	14368#
A0404	030352	14553	14561#
A0405	030444	14599	14607#
A0406	030540	14645	14653#
A0407	030634	14691	14699#
A041	002172	3982	3987#
A0410	030730	14737	14745#
A0411	031022	14783	14791#
A0412	031114	14829	14837#
A0413	031210	14875	14883#
A0420	031542	15077	15082#
A0421	031622	15122	15127#
A0422	031706	15167	15172#
A0423	031772	15212	15217#
A0424	032050	15257	15262#
A0425	032134	15303	15308#
A0426	032222	15349	15354#
A0427	032310	15395	15400#
A0430	032372	15444	15449#
A0431	032452	15492	15497#
A0432	032536	15540	15545#
A0433	032622	15588	15593#
A0434	032706	15636	15641#
A0435	032770	15682	15687#
A0436	033054	15727	15732#
A0437	033140	15771	15776#
A0440	033224	15816	15821#
A0441	033304	15860	15865#
A0442	033372	15904	15909#
A0443	033462	15949	15954#
A0444	033570	16000	16005#
A0445	033650	16042	16048#
A0446	033732	16085	16091#
A0447	034014	16128	16134#
A0450	034074	16171	16177#
A0453	034306	16295	16300#
A0454	034376	16344	16349#
A0455	034466	16392	16397#
A0456	034556	16441	16446#
A0457	034646	16490	16495#
A046	002374	4138	4143#
A0460	034750	16545	16550#
A0461	035052	16600	16605#
A0462	035154	16655	16660#
A0463	035260	16710	16715#
A0464	035364	16766	16771#
A0465	035470	16821	16826#
A0466	035574	16877	16882#
A0467	035700	16932	16937#
A0470	036002	16987	16992#
A0471	036104	17042	17047#
A0472	036206	17097	17102#

A0473	036310	17152	17157#
A0474	036414	17208	17213#
A0475	036520	17263	17268#
A0476	036624	17319	17324#
A0477	036732	17375	17380#
A0500	037026	17425	17430#
A0501	037122	17475	17480#
A0502	037216	17525	17530#
A0503	037312	17575	17580#
A0504	037420	17628	17633#
A0505	037514	17678	17683#
A0506	037610	17728	17733#
A0515	040224	17999	18004#
A0516	040306	18046	18051#
A0521	040474	18162	18167#
A0522	040552	18203	18208#
A0524	040702	18285	18291#
A0525	040766	18330	18335#
A0526	041050	18376	18381#
A0527	041134	18421	18426#
A0537	041672	18737	18742#
A0540	041750	18781	18786#
A0541	042034	18825	18830#
A0542	042112	18869	18874#
A0543	042176	18914	18919#
A0544	042274	18963	18968#
A0545	042356	19008	19013#
A0546	042440	19053	19058#
A0547	042522	19097	19102#
A0550	042606	19141	19146#
A0551	042666	19186	19191#
A0552	042754	19231	19236#
A0553	043034	19276	19281#
A0554	043122	19321	19326#
A0555	043210	19366	19371#
A0556	043276	19411	19416#
A0557	043362	19457	19462#
A0560	043446	19502	19507#
A0561	043534	19547	19552#
A0562	043614	19591	19596#
A0563	043704	19636	19641#
A0564	043764	19680	19685#
A0565	044046	19724	19729#
A0566	044130	19768	19773#
A0567	044212	19812	19817#
A0570	044274	19857	19862#
A0571	044362	19902	19907#
A0572	044446	19946	19951#
A0573	044534	19991	19996#
A0574	044626	20037	20042#
A0575	044720	20083	20088#
A0576	045012	20129	20134#
A0577	045104	20175	20180#
A0600	045174	20222	20227#
A0601	045266	20269	20274#
A0602	045356	20315	20320#

```
A0617   046376          20814   20823#
A0620   046442          20855   20864#
A0621   046506          20895   20904#  20912
A0622   046564          20942   20951#
A0623   046630          20992#  21006
A0624   046716          21045#  21054
A0625   047002          21090   21095#
A0626   047060          21133   21142#
A0627   047124          21183#  21197
A0630   047212          21234#  21243
A0631   047270          21274   21280#
A0632   047344          21320   21326#
A0633   047426          21376#  21385
A0634   047512          21427#  21436
A0635   047566          21463   21471#
A0636   047644          21502   21512#
A0637   047722          21548   21556#
A0640   047770          21586   21594#
A0641   050040          21626   21634#
A0642   050110          21675#  21684
A0643   050170          21721#
A0644   050260          21769#  21778
A0645   050342          21810   21815#
A0646   050414          21857#  21866
A0650   050520          21934#  21938
A0655   051010          22125   22135#
A0656   051116          22183   22193#
A0657   051230          22242   22252#
A0660   051334          22296   22306#
A0661   051444          22348   22368#
A0662   051602          22420   22440#
A0663   051726          22481   22488#
A0666   052160          22551   22560   22567#
A0667   052276          22587   22602#
A0670   052406          22642   22648#
A0671   052522          22693   22699#
A0672   052662          22736   22760#
A0673   053066          22813   22837#
A0674   053260          22877   22893#
A0675   053402          22911   22927#
A0676   053524          22945   22961#
A0677   053646          22979   22995#
A0700   053770          23013   23029#
A0701   054112          23047   23063#
A0702   054226          23079   23095#
A0703   054342          23111   23127#
A0704   054470          23146   23162#
A0705   054604          23178   23194#
A0706   054720          23211   23224#
A0707   055044          23246   23259#
A0710   055162          23279   23292#
A0711   055300          23312   23325#
A0712   055416          23345   23358#
A0713   055534          23378   23391#
A0714   055700          23419   23437#
A0715   056116          23469   23498#
```

```
A0716   056300          23552   23561#
A0717   056372          23591   23603#
A0720   056512          23646   23657#
A0721   056604          23683   23691#
A0722   056664          23708   23716#
A0723   056744          23733   23741#
A0724   057034          23772   23783#
A0725   057154          23795   23827#
A0726   057270          23838   23869#
A0727   057412          23882   23918#
A0730   057602          23938   23985#
A0731   057754          23999   24046#
A0732   060036          24060   24074#
A0733   060132          24093   24106#
A0734   060232          24126   24139#
A0735   060326          24172   24183#
A0736   060404          24210   24221#
A0737   060462          24247   24257#
A0740   060540          24284   24297#
A0741   060646          24335   24350#
A0742   060754          24389   24404#
A0743   061072          24444   24459#
A0744   061200          24496   24509#
A0745   061270          24540   24553#
A0746   061354          24584   24597#
A0747   061442          24628   24641#
A0750   061530          24672   24685#
A0751   061616          24715   24728#
A0752   061674          24757   24770#
A0753   061762          24801   24814#
A0754   062040          24843   24856#
A1007   063754          25848   25856   25858#
A1014   064314          26197   26204#
A1015   064360          26249   26256#
BEGIN   003034           4161#  26308
BELL    066724          26984#
BEMSG   067452          26526   27049#
BERFLG  066714           7795*   7801*  26517*  26976#
BERR    065160           7849   22488   22493   23824   23866   23911   23929   23982   24043   24081   24113   24146   26520#
BETST   065152           7792   26517#
BPTLOC  066642           5262    6392    7675    8827    9961   11451   12850   14223   15983   17611   18948   20390   21756
                        23141   24537   25763   26954#
BT001   001000           2974#   4154    4161   26385   26465   26536
BT002   001004           2974    2996#
BT003   001016           2998    3025#   3032
BT004   001032           3028    3052#   3061
BT005   001050           3057    3081#   3090
BT006   001066           3086    3110#   3117
BT007   001100           3114    3137#   3146
BT010   001114           3142    3166#   3175
BT011   001132           3172    3199#   3209
BT012   001152           3206    3229#   3238
BT013   001172           3235    3258#   3269
BT014   001216           3266    3290#   3299
BT015   001240           3296    3319#   3327   3334
BT016   001266           3331    3355#   3366
```

BT017	001312	3363	3386#	3398	3405
BT020	001352	3402	3425#	3435	3441
BT021	001402	3438	3461#	3471	3478
BT022	001434	3475	3499#	3509	
BT023	001460	3506	3529#	3542	3549
BT024	001524	3546	3570#	3579	
BT025	001550	3576	3601#	3609	
BT026	001570	3606	3629#	3637	
BT027	001610	3634	3658#	3666	
BT030	001630	3663	3687#	3695	
BT031	001650	3692	3715#	3723	
BT032	001670	3720	3744#	3754	3761
BT033	001732	3758	3783#	3793	3800
BT034	001774	3797	3820#	3830	3837
BT035	002036	3834	3857#	3866	
BT036	002056	3863	3886#	3895	
BT037	002076	3892	3915#	3924	
BT040	002116	3921	3944#	3955	
BT041	002144	3952	3974#	3985	3992
BT042	002204	3989	4013#	4023	
BT043	002224	4020	4043#	4054	
BT044	002246	4051	4074#		
BT045	002274	4081	4084	4103#	4113
BT046	002322	4110	4119#	4141	4147
B0024	004164	4829	4834#		
B0077	007524	6412	6417#		
B0100	007612	6458	6463#		
B0101	007716	6512	6517#		
B0102	010022	6566	6571#		
B0103	010124	6620	6625#		
B0116	011270	7102	7108#		
B0117	011370	7157	7163#		
B0126	012042	7414	7420#		
B0130	012230	7499	7505#		
B0132	012434	7593	7599#		
B0133	012546	7645	7651#		
B0230	016224	9803	9808#		
B0236	016712	10093	10098#		
B0264	020762	11108	11113#		
B0266	021132	11198	11203#		
B0270	021304	11288	11293#		
B0272	021452	11377	11382#		
B0327	024202	12639	12644#		
B0457	034660	16496	16501#		
B0460	034762	16551	16556#		
B0461	035064	16606	16611#		
B0462	035166	16661	16666#		
B0463	035272	16716	16721#		
B0464	035376	16772	16777#		
B0465	035502	16827	16832#		
B0466	035606	16883	16888#		
B0467	035710	16938	16943#		
B0470	036012	16993	16998#		
B0471	036114	17048	17053#		
B0472	036216	17103	17108#		
B0473	036322	17158	17163#		

```
B0474   036426          17214   17219#
B0475   036532          17269   17274#
B0476   036636          17325   17330#
B0621   046522          20907   20912#
B0623   046644          20995   21000#
B0625   047016          21098   21103#
B0627   047140          21186   21191#
B0636   047670          21519   21524#
B0637   047736          21559   21564#
B0640   050004          21597   21601#
B0642   050134          21682   21688#
B0643   050176          21721   21725#
B0644   050304          21776   21782#
B0646   050440          21864   21870#
B0655   051024          22138   22143#
B0656   051132          22196   22201#
B0657   051244          22254   22261#
B0660   051350          22308   22315#
B0661   051432          22349*  22360#  22378
B0662   051570          22421*  22432#  22450
B0663   051740          22486   22492#
B0670   052426          22649   22656#
B0671   052542          22700   22707#
B0672   052702          22762   22768#
B0673   053106          22839   22845#
B0706   054730          23222   23228#
B0707   055054          23257   23263#
B0710   055172          23290   23296#
B0711   055310          23323   23329#
B0712   055426          23356   23362#
B0713   055544          23389   23395#
B0714   055714          23431   23444#
B0715   056136          23501   23507#
B0717   056412          23605   23611#
B0720   056530          23659   23665#
B0721   056616          23689   23696#
B0722   056676          23714   23721#
B0723   056756          23739   23746#
B0727   057404          23881   23893   23914#
B0732   060042          24066   24077#
B0733   060136          24094   24109#
B0734   060236          24127   24142#
B0740   060554          24295   24298   24303#
B0741   060672          24351   24360#
B0742   061000          24405   24414#
B0743   061116          24460   24469#
B1007   063766          25860   25864#
CATERR  066720          26448   26450*  26467*  26520   26522*  26539*  26978#
CHKKE   066504          26868   26916#
CHKKF   066426          26867   26902#
CHKKJ   066352          26866   26889#
CHKKT   066276          26865   26876#
CHKKW   066562          26869   26931#
CITST   013522           7999    8014#
CLMT    003632           4631    4639#
COLCNT  066640          26646*  26647*  26660   26665   26671   26676   26681   26687   26692   26953#
```

CRLF	066726	26294	26361	26461	26532	26658	26698	26985#					
C0100	007624	6464	6469#										
C0101	007730	6518	6523#										
C0102	010034	6572	6577#										
C0103	010136	6626	6631#										
C0116	011300	7109	7114#										
C0117	011400	7164	7169#										
C0130	012246	7506	7512#										
C0132	012452	7600	7606#										
C0230	016236	9809	9814#										
C0236	016724	10099	10104#										
C0636	047656	21513	21518#										
C0643	050212	21733#											
C0655	051034	22144	22149#										
C0656	051142	22202	22207#										
C0657	051260	22250	22269#										
C0660	051364	22304	22323#										
C0661	051466	22371	22378#										
C0662	051624	22443	22450#										
C0672	052734	22758	22766	22769	22775	22780#							
C0673	053140	22835	22843	22846	22852	22857#							
C0714	055722	23439	23442	23448#									
C0715	056152	23471	23514#										
C0717	056430	23612	23618#										
C0720	056542	23666	23672#										
C0727	057426	23919	23923#										
C0732	060050	24072	24075	24081#									
C0733	060144	24104	24107	24113#									
C0734	060244	24137	24140	24146#									
DBTA	070152	5622	6664	6677	6750	6763	7087	7095	18082	18118	18155	18167	18196	18208
		18239	18277	18322	18368	18413	18458	18497	20354	20395	20433	20472	20511	20550
		20589	20628	20778	27072	27213#								
DBTB	070156	6707	6720	6792	6805	6876	6961	7227	7296	27073	27216#			
DIGITS	067136	26278	26284	26292	26359	26459	26530	26727	26743	27011#				
DIGTAB	066644	26756	26956#											
DMRET	062104	24868#												
DONE1	064560	26303	26308#											
DWTA	067612	4816	4818	5184	5265	5269	5304	5308	5383	5485	5526	5588	5698	5740
		5775	5815	5890	6445	6446	6457	6463	6499	6500	6501	6511	6517	6553
		6554	6555	6565	6571	6607	6608	6619	6625	7004	7016	7045	7057	12626
		14182	14227	14269	14312	14354	14433	14470	14507	14544	14590	14636	14682	14728
		14774	14820	14866	14913	14952	14991	15030	15850	16284	16333	16380	16429	16479
		16534	16588	16643	16699	16755	16809	16865	16921	16976	17030	17085	17141	17197
		17251	17307	17364	17414	17463	17513	17564	17617	17666	17716	19537	19581	19670
		19714	19758	19802	19847	19936	19981	25335	27070	27081#				
DWTB	070136	5222	5224	5855	6833	6918	7142	7150	7193	7261	15806	27071	27206#	
D0655	051050	22133	22157#											
D0656	051156	22191	22215#											
D0661	051454	22368	22369	22370	22373#									
D0662	051612	22440	22441	22442	22445#									
ENDPS	064372	26267#												
EOP1	067147	26274	27013#											
EOP2	067176	26280	27018#											
ERFLG1	066716	26650	26656*	26977#										
ERHDR1	066732	26653	26987#											
ERHDR2	067034	26655	26999#											

```
ERRA     065400      7716   26637#
ERRB     065406      8016   26640#
ERRCNT   066666      4157   26281   26362   26364*  26378   26380*  26462   26464*  26533   26535*  26640   26642*  26965#
ERRFLG   066676      7718*   7723*  26637*  26969#
ERROR = 104000       2928#   7721    9482    9515    9618    9624    9659    9698    9705    9741    9783    9789    9805
                     9811    9817    9852    9891    9897    9933    9977    9983   10024   10030   10073   10079   10095
                    10101   10107   10148   10154   10194   10200   10240   10246   10286   10292   10332   10338   10378
                    10384   10424   10430   10470   10476   10516   10522   10568   10613   10658   10703   10748   10793
                    10839   10885   10931   10977   11023   11069   11117   11159   11207   11249   11297   11339   11386
                    11427   11473   11517   11560   11602   11645   11689   11732   11775   11818   11861   11903   11946
                    11989   12032   12076   12120   12164   12207   12250   12292   12335   12378   12421   12463   12508
                    12555   12599   12648   12692   12737   12781   12825   12872   12916   12959   13003   13047   13091
                    13135   13179   13223   13267   13311   13354   13398   13442   13486   13529   13568   13574   13612
                    13618   13657   13663   13701   13707   13745   13751   13795   13833   13875   13911   13954   13991
                    14033   14069   14113   14157   14192   14237   14280   14322   14365   14407   14444   14481   14518
                    14557   14603   14649   14695   14741   14787   14833   14879   14925   14964   15003   15042   15079
                    15085   15124   15130   15169   15175   15214   15220   15259   15266   15305   15312   15351   15358
                    15397   15404   15446   15452   15494   15500   15542   15548   15590   15596   15638   15644   15691
                    15736   15780   15824   15868   15912   15958   16009   16045   16088   16131   16174   16218   16256
                    16305   16354   16402   16451   16506   16561   16616   16671   16726   16782   16837   16893   16948
                    17003   17058   17113   17168   17224   17279   17335   17385   17435   17485   17535   17585   17638
                    17688   17738   17775   17812   17849   17887   17924   17963   18007   18054   18092   18127   18164
                    18205   18249   18288   18339   18385   18430   18469   18508   18548   18586   18624   18662   18701
                    18745   18789   18833   18877   18923   18971   19016   19061   19105   19150   19195   19240   19285
                    19330   19375   19420   19466   19511   19555   19599   19644   19688   19732   19776   19820   19865
                    19910   19955   20000   20046   20092   20138   20184   20231   20278   20324   20363   20405   20444
                    20483   20522   20561   20600   20639   20676   20714   20750   20789   22146   22154   22204   22212
                    22256   22266   22310   22320   22514   22536   22563   22653   22704   22773   22850   24300   24346
                    24357   24400   24411   24455   24466   25929   25998   26071   26141   26199   26251
ERROR1= 104001       2929#
ERROR2= 104002       2930#
ERROR3= 104003       2931#
ERROR4= 104004       2932#
ERROR5= 104005       2933#   8061    8092    8097    8102    8107    8139    8168    8198    8229    8261    8294    8326
                     8357    8394    8425    8434    8471    8502    8511    8542    8575    8606    8638    8670    8702
                     8734    8767    8800    8836    8869    8898    8932    8965    8998    9029    9062    9094    9126
                     9159    9192    9223    9256    9289    9321    9353    9386    9419    9451    9547    9579   10562
                    10607   10652   10697   10742   10787   10832   10878   10924   10970   11016   11062   11104   11110
                    11152   11194   11200   11242   11284   11290   11332   11373   11379   11420   11467   11511   11555
                    11597   11640   11684   11727   11770   11813   11856   11898   11941   11984   12027   12071   12115
                    12159   12202   12245   12287   12330   12373   12416   12458   12501   12548   12593   12636   12641
                    12686   12731   12775   12819   12866   12910   12953   12997   13041   13085   13129   13173   13217
                    13261   13305   13348   13392   13436   13480   13523   13788   13868   13947   14026   14107   14151
                    14198   14243   14286   14328   14371   14564   14610   14656   14702   14748   14794   14840   14886
                    15684   15729   15773   15818   15862   15906   15951   16002   16051   16094   16137   16180   16297
                    16346   16394   16443   16492   16498   16547   16553   16602   16608   16657   16663   16712   16718
                    16768   16774   16823   16829   16879   16885   16934   16940   16989   16995   17044   17050   17099
                    17105   17154   17160   17210   17216   17265   17271   17321   17327   17377   17427   17477   17527
                    17577   17630   17680   17730   18001   18048   18170   18211   18294   18332   18378   18423   18739
                    18783   18827   18871   18916   18965   19010   19055   19099   19143   19188   19233   19278   19323
                    19368   19413   19459   19504   19549   19593   19638   19682   19726   19770   19814   19859   19904
                    19948   19993   20039   20085   20131   20177   20224   20271   20317   21468   21476   21509   21515
                    21521   21553   21561   21591   21598   21631   21639   21672   21680   21685   21718   21722   21730
                    21766   21774   21779   21812   21821   21853   21862   21867   22131   22140   22189   22198   22248
                    22302   22355   22363   22382   22427   22435   22454   23558   23600   23608   23615   23654   23662
                    23669   23693   23718   23743   23780   24069   24078   24101   24110   24134   24143   24180   24218
```

```
                        24255   24292   24506   24550   24594   24638   24682   24725   24767   24811   24853   24908   24944
                        24981   25016   25052   25090   25128   25163   25198   25234   25271   25306   25344   25380   25415
                        25450   25488   25526   25563   25598   25633   25667   25701   25737   25777   25810   25861
ERROR6= 104006           2934#  20819   20828   20860   20869   20900   20909   20915   20947   20956   20988   20997   21003
                        21007   21041   21050   21055   21086   21091   21100   21106   21138   21147   21179   21188   21194
                        21198   21230   21239   21244   21276   21285   21289   21322   21331   21335   21368   21372   21381
                        21387   21419   21423   21432   21438   21899   21947   21950   21985   22022   22059   22096   22375
                        22447   22489   22599   22645   22696   22756   22764   22777   22833   22841   22854   22890   22924
                        22958   22992   23026   23060   23092   23124   23159   23191   23225   23260   23293   23326   23359
                        23392   23440   23445   23803   23812   23821   23846   23855   23863   23890   23899   23908   23949
                        23959   23969   23979   24010   24020   24030   24040
ERROR7= 104007           2935#  22392   22464   23503   23510   23517   23523   23529   23926
ERRTN   066656          26645*  26707   26961#
EX002   001010           3000#
E0001   003050           4186#
E0002   003066           4210    4214#
E0003   003102           4240#
E0004   003120           4263    4267#
E0005   003142           4292    4296#
E0006   003162           4323#
E0007   003222           4357#
E001    001002           2976#
E0010   003260           4389#
E0011   003316           4422#
E0014   003454           4529#
E0015   003512           4562#
E0016   003560           4599#
E0017   003626           4634#
E0020   003716           4674    4677#
E0025   004236           4873#
E0026   004306           4908#
E0027   004346           4941#
E003    001026           3025    3026    3027    3030#
E0030   004412           4975#
E0031   004462           5010#
E004    001044           3054    3055    3056    3059#
E0042   005256           5357#
E0043   005322           5392#
E0044   005374           5427#
E0045   005442           5462#
E0047   005566           5535#
E005    001062           3083    3084    3085    3088#
E0050   005616           5563#
E0051   005664           5599#
E0052   005732           5633#
E0055   006140           5751#
E006    001074           3116#
E0060   006346           5865#
E0061   006422           5900#
E0064   006626           6017#
E0065   006670           6050#
E0066   006732           6083#
E0067   007000           6117#
E007    001110           3144#
E0070   007050           6151#
E0071   007114           6185#
```

```
E0072   007172          6224#
E0073   007236          6258#
E0075   007356          6332#
E0076   007430          6368#
E010    001126          3171    3174#
E011    001146          3205    3208#
E0116   011252          7098#
E0117   011352          7153#
E012    001166          3237#
E0120   011450          7203#
E0121   011522          7237#
E0122   011574          7271#
E0123   011646          7306#
E0127   012126          7460#
E013    001212          3268#
E0131   012330          7553#
E0133   012542          7648#
E0134   012630          7690#
E0135   012702          7726#
E0136   012762          7763#
E0137   013060          7804#
E014    001234          3298#
E0140   013150          7831    7845#
E0141   013236          7884#
E0142   013276          7917#
E0143   013340          7950#
E0145   013670          8055    8056    8057    8058    8061#
E0147   013760          8136    8139#
E0150   014002          8168#
E0151   014026          8195    8198#
E0152   014050          8229#
E0153   014074          8258    8261#
E0154   014116          8294#
E0155   014142          8323    8326#
E0156   014164          8357#
E0157   014224          8386    8394#
E016    001306          3360    3361    3362    3365#
E0161   014326          8463    8471#
E0163   014412          8542#
E0164   014440          8572    8575#
E0165   014466          8603    8606#
E0166   014512          8638#
E0167   014536          8667    8670#
E0170   014562          8702#
E0171   014606          8734#
E0172   014634          8764    8767#
E0173   014662          8797    8800#
E0174   014722          8833    8836#
E0175   014750          8866    8869#
E0176   014772          8898#
E0177   015020          8929    8932#
E0200   015046          8962    8965#
E0201   015074          8995    8998#
E0202   015120          9029#
E0203   015144          9059    9062#
E0204   015170          9094#
```

```
E0205   015214          9126#
E0206   015240          9159#
E0207   015266          9189    9192#
E0210   015310          9223#
E0211   015336          9253    9256#
E0212   015364          9286    9289#
E0213   015412          9318    9321#
E0214   015436          9350    9353#
E0215   015462          9386#
E0216   015506          9419#
E0217   015532          9451#
E022    001454          3503    3504    3505    3508#
E0220   015554          9482#
E0221   015602          9512    9515#
E0222   015626          9544    9547#
E0223   015652          9579#
E0225   015766          9659#
E0227   016104          9741#
E0231   016302          9852#
E0232   001520          3548#
E0233   016416          9933#
E024    001544          3578#
E025    001564          3605    3608#
E026    001604          3633    3636#
E027    001624          3665#
E030    001644          3694#
E031    001664          3722#
E035    002052          3865#
E036    002072          3894#
E0362   026656         13833#
E0364   027004         13911#
E0366   027142         13991#
E037    002112          3923#
E0370   027270         14069#
E040    002140          3954#
E0400   030100         14407#
E0401   030152         14444#
E0402   030220         14481#
E0403   030266         14518#
E0414   031272         14925#
E0415   031346         14964#
E0416   031420         15003#
E0417   031472         15042#
E042    002220          4022#
E043    002242          4053#
E044    002270          4083#
E045    002316          4112#
E0451   034154         16218#
E0452   034226         16256#
E0507   037662         17775#
E0510   037724         17812#
E0511   037770         17849#
E0512   040034         17887#
E0513   040100         17924#
E0514   040146         17963#
E0517   040356         18092#
```

```
E0520   040424          18127#
E0523   040626          18249#
E0530   041216          18469#
E0531   041272          18508#
E0532   041342          18548#
E0533   041412          18586#
E0534   041464          18624#
E0535   041536          18662#
E0536   041612          18701#
E0603   045430          20363#
E0604   045510          20405#
E0605   045560          20444#
E0606   045632          20483#
E0607   045704          20522#
E0610   045756          20561#
E0611   046032          20600#
E0612   046106          20639#
E0613   046152          20676#
E0614   046224          20714#
E0615   046270          20750#
E0616   046342          20789#
E0647   050462          21899#  21904
E0651   050606          21980   21981   21982   21985#
E0652   050644          22017   22018   22019   22022#
E0653   050702          22054   22055   22056   22059#
E0654   050740          22091   22092   22093   22096#
E0663   051734          22489#
E0664   052010          22514#
E0665   052056          22536#
E0667   052272          22599#
E0674   053254          22890#
E0675   053376          22924#
E0676   053520          22958#
E0677   053642          22992#
E0700   053764          23026#
E0701   054106          23060#
E0702   054222          23092#
E0703   054336          23124#
E0704   054464          23159#
E0705   054600          23191#
E0706   054724          23225#
E0707   055050          23260#
E0710   055166          23293#
E0711   055304          23326#
E0712   055422          23359#
E0713   055540          23392#
E0716   056274          23558#
E0721   056612          23693#
E0722   056672          23718#
E0723   056752          23743#
E0724   057030          23780#
E0735   060322          24174   24180#
E0736   060400          24212   24218#
E0737   060456          24255#
E0744   061174          24506#
E0745   061264          24550#
```

```
E0746   061350          24594#
E0747   061436          24638#
E0750   061524          24682#
E0751   061612          24725#
E0752   061670          24767#
E0753   061756          24811#
E0754   062034          24853#
E0755   062144          24908#
E0756   062210          24944#
E0757   062254          24981#
E0760   062314          25016#
E0761   062354          25052#
E0762   062420          25090#
E0763   062464          25128#
E0764   062524          25163#
E0765   062564          25198#
E0766   062624          25234#
E0767   062670          25271#
E0770   062730          25306#
E0771   062774          25344#
E0772   063034          25380#
E0773   063074          25415#
E0774   063134          25450#
E0775   063200          25488#
E0776   063244          25526#
E0777   063310          25554   25563#
E1000   063350          25596   25598#
E1001   063410          25631   25633#
E10012  003350           4453#
E10013  003410           4490#
E1002   063446          25667#
E10021  003760           4706    4709#
E10022  004030           4748#
E10023  004076           4787#
E10024  004150           4825#
E1003   063504          25701#
E10032  004522           5042#
E10033  004572           5080#
E10034  004642           5117#
E10035  004712           5155#
E10036  004756           5192#
E10037  005032           5231#
E1004   063550          25729   25737#
E10040  005116           5273#
E10041  005170           5312#
E10046  005506           5496#
E1005   063630          25773   25777#
E10053  006000           5668#
E10054  006060           5710#
E10056  006210           5786#
E10057  006266           5825#
E1006   063672          25810#  25814
E10062  006476           5937#
E10063  006552           5977#
E1007   063762          25859   25861#
E10074  007276           6291#
```

E10077	007510	6408#			
E1010	064032	25929#			
E10100	007574	6454#			
E10101	007700	6508#			
E10102	010004	6562#			
E10103	010106	6616#			
E10104	010224	6674#			
E10105	010314	6717#			
E10106	010404	6760#			
E10107	010474	6802#			
E1011	064110	25998#			
E10110	010562	6844#			
E10111	010650	6887#			
E10112	010740	6929#			
E10113	011030	6972#			
E10114	011106	7013#			
E10115	011164	7054#			
E10116	011264	7105#			
E10117	011364	7160#			
E1012	064166	26071#			
E10124	011700	7336#			
E10125	011740	7371#	7374		
E10126	012014	7409#			
E1013	064244	26141#			
E10130	012202	7494#	7505		
E10132	012406	7588#	7599		
E1014	064306	26199#			
E10146	013712	8092#			
E1015	064352	26251#			
E1015M	001252	3326#			
E10160	014246	8425#			
E10162	014350	8502#			
E1017	001334	3392	3393	3394	3397#
E1020	001366	3434#			
E1021	001416	3470#			
E10224	015720	9613	9614	9615	9618#
E10226	016032	9693	9694	9695	9698#
E1023	001506	3536	3537	3538	3541#
E10230	016152	9778	9779	9780	9783#
E10232	016346	9886	9887	9888	9891#
E10234	016500	9972	9973	9974	9977#
E10235	016560	10019	10020	10021	10024#
E10236	016640	10068	10069	10070	10073#
E10237	017002	10143	10144	10145	10148#
E10240	017056	10189	10190	10191	10194#
E10241	017136	10235	10236	10237	10240#
E10242	017216	10281	10282	10283	10286#
E10243	017274	10327	10328	10329	10332#
E10244	017350	10373	10374	10375	10378#
E10245	017430	10419	10420	10421	10424#
E10246	017510	10465	10466	10467	10470#
E10247	017566	10511	10512	10513	10516#
E10250	017646	10557	10558	10559	10562#
E10251	017724	10602	10603	10604	10607#
E10252	020004	10647	10648	10649	10652#
E10253	020062	10692	10693	10694	10697#

E10254	020142	10737	10738	10739	10742#
E10255	020222	10782	10783	10784	10787#
E10256	020302	10827	10828	10829	10832#
E10257	020362	10873	10874	10875	10878#
E10260	020444	10919	10920	10921	10924#
E10261	020524	10965	10966	10967	10970#
E10262	020606	11011	11012	11013	11016#
E10263	020670	11057	11058	11059	11062#
E10264	020744	11104#			
E10265	021034	11152#			
E10266	021114	11194#			
E10267	021206	11242#			
E10270	021266	11284#			
E10271	021360	11332#			
E10272	021434	11373#			
E10273	021522	11420#			
E10274	021612	11462	11463	11464	11467#
E10275	021670	11506	11507	11508	11511#
E10276	021746	11550	11551	11552	11555#
E10277	022022	11592	11593	11594	11597#
E10300	022102	11635	11636	11637	11640#
E10301	022160	11679	11680	11681	11684#
E10302	022236	11722	11723	11724	11727#
E10303	022316	11765	11766	11767	11770#
E10304	022374	11808	11809	11810	11813#
E10305	022454	11851	11852	11853	11856#
E10306	022530	11893	11894	11895	11898#
E10307	022606	11936	11937	11938	11941#
E10310	022666	11979	11980	11981	11984#
E10311	022742	12022	12023	12024	12027#
E10312	023022	12066	12067	12068	12071#
E10313	023102	12110	12111	12112	12115#
E10314	023156	12154	12155	12156	12159#
E10315	023236	12197	12198	12199	12202#
E10316	023314	12240	12241	12242	12245#
E10317	023374	12282	12283	12284	12287#
E1032	001714	3753#			
E10320	023452	12325	12326	12327	12330#
E10321	023532	12368	12369	12370	12373#
E10322	023612	12411	12412	12413	12416#
E10323	023670	12453	12454	12455	12458#
E10324	023744	12496	12497	12498	12501#
E10325	024026	12543	12544	12545	12548#
E10326	024106	12588	12589	12590	12593#
E10327	024164	12631	12632	12633	12636#
E1033	001756	3792#			
E10330	024260	12681	12682	12683	12686#
E10331	024340	12726	12727	12728	12731#
E10332	024420	12770	12771	12772	12775#
E10333	024502	12814	12815	12816	12819#
E10334	024574	12861	12862	12863	12866#
E10335	024656	12905	12906	12907	12910#
E10336	024734	12948	12949	12950	12953#
E10337	025014	12992	12993	12994	12997#
E1034	002020	3829#			
E10340	025076	13036	13037	13038	13041#

E10341	025154	13080	13081	13082	13085#
E10342	025236	131[illegible]	13125	13126	13129#
E10343	025320	131[illegible]8	13169	13170	13173#
E10344	025376	13212	13213	13214	13217#
E10345	025460	13256	13257	13258	13261#
E10346	025540	13300	13301	13302	13305#
E10347	025622	13343	13344	13345	13348#
E10350	025702	13387	13388	13389	13392#
E10351	025764	13431	13432	13433	13436#
E10352	026046	13475	13476	13477	13480#
E10353	026126	13518	13519	13520	13523#
E10354	026210	13563	13564	13565	13568#
E10355	026270	13607	13608	13609	13612#
E10356	026350	13652	13653	13654	13657#
E10357	026430	13696	13697	13698	13701#
E10360	026510	13740	13741	13742	13745#
E10361	026572	13788#			
E10363	026724	13868#			
E10365	027056	13947#			
E10367	027210	14026#			
E10371	027342	14102	14103	14104	14107#
E10372	027426	14146	14147	14148	14151#
E10373	027502	14192#			
E10374	027572	14237#			
E10375	027656	14280#			
E10376	027734	14322#			
E10377	030020	14365#			
E10404	030342	14557#			
E10405	030434	14603#			
E10406	030530	14649#			
E10407	030624	14695#			
E1041	002166	3984#			
E10410	030720	14741#			
E10411	031012	14787#			
E10412	031104	14833#			
E10413	031200	14879#			
E10420	031536	15074	15075	15076	15079#
E10421	031616	15119	15120	15121	15124#
E10422	031702	15164	15165	15166	15169#
E10423	031766	15209	15210	15211	15214#
E10424	032044	15254	15255	15256	15259#
E10425	032130	15300	15301	15302	15305#
E10426	032216	15346	15347	15348	15351#
E10427	032304	15392	15393	15394	15397#
E10430	032366	15441	15442	15443	15446#
E10431	032446	15489	15490	15491	15494#
E10432	032532	15537	15538	15539	15542#
E10433	032616	15585	15586	15587	15590#
E10434	032702	15633	15634	15635	15638#
E10435	032764	15679	15680	15681	15684#
E10436	033050	15724	15725	15726	15729#
E10437	033134	15768	15769	15770	15773#
E10440	033220	15813	15814	15815	15818#
E10441	033300	15857	15858	15859	15862#
E10442	033366	15901	15902	15903	15906#
E10443	033456	15946	15947	15948	15951#

```
E10444  033564          15997   15998   15999   16002#
E10445  033644          16045#
E10446  033726          16088#
E10447  034010          16131#
E10450  034070          16174#
E10453  034302          16292   16293   16294   16297#
E10454  034372          16341   16342   16343   16346#
E10455  034462          16389   16390   16391   16394#
E10456  034552          16438   16439   16440   16443#
E10457  034642          16487   16488   16489   16492#
E1046   002370           4140#
E10460  034744          16542   16543   16544   16547#
E10461  035046          16597   16598   16599   16602#
E10462  035150          16652   16653   16654   16657#
E10463  035254          16707   16708   16709   16712#
E10464  035360          16763   16764   16765   16768#
E10465  035464          16818   16819   16820   16823#
E10466  035570          16874   16875   16876   16879#
E10467  035674          16929   16930   16931   16934#
E10470  035776          16984   16985   16986   16989#
E10471  036100          17039   17040   17041   17044#
E10472  036202          17094   17095   17096   17099#
E10473  036304          17149   17150   17151   17154#
E10474  036410          17205   17206   17207   17210#
E10475  036514          17260   17261   17262   17265#
E10476  036620          17316   17317   17318   17321#
E10477  036726          17372   17373   17374   17377#
E10500  037022          17422   17423   17424   17427#
E10501  037116          17472   17473   17474   17477#
E10502  037212          17522   17523   17524   17527#
E10503  037306          17572   17573   17574   17577#
E10504  037414          17625   17626   17627   17630#
E10505  037510          17675   17676   17677   17680#
E10506  037604          17725   17726   17727   17730#
E10515  040220          17996   17997   17998   18001#
E10516  040302          18043   18044   18045   18048#
E10521  040470          18164#
E10522  040546          18205#
E10524  040676          18288#
E10525  040762          18332#
E10526  041044          18378#
E10527  041130          18423#
E10537  041666          18734   18735   18736   18739#
E10540  041744          18778   18779   18780   18783#
E10541  042030          18822   18823   18824   18827#
E10542  042106          18866   18867   18868   18871#
E10543  042172          18911   18912   18913   18916#
E10544  042270          18960   18961   18962   18965#
E10545  042352          19005   19006   19007   19010#
E10546  042434          19050   19051   19052   19055#
E10547  042516          19094   19095   19096   19099#
E10550  042602          19138   19139   19140   19143#
E10551  042662          19183   19184   19185   19188#
E10552  042750          19228   19229   19230   19233#
E10553  043030          19273   19274   19275   19278#
E10554  043116          19318   19319   19320   19323#
```

```
E10555  043204          19363   19364   19365   19368#
E10556  043272          19408   19409   19410   19413#
E10557  043356          19454   19455   19456   19459#
E10560  043442          19499   19500   19501   19504#
E10561  043530          19544   19545   19546   19549#
E10562  043610          19588   19589   19590   19593#
E10563  043700          19633   19634   19635   19638#
E10564  043760          19677   19678   19679   19682#
E10565  044042          19721   19722   19723   19726#
E10566  044124          19765   19766   19767   19770#
E10567  044206          19809   19810   19811   19814#
E10570  044270          19854   19855   19856   19859#
E10571  044356          19899   19900   19901   19904#
E10572  044442          19943   19944   19945   19948#
E10573  044530          19988   19989   19990   19993#
E10574  044622          20034   20035   20036   20039#
E10575  044714          20080   20081   20082   20085#
E10576  045006          20126   20127   20128   20131#
E10577  045100          20172   20173   20174   20177#
E10600  045170          20219   20220   20221   20224#
E10601  045262          20266   20267   20268   20271#
E10602  045352          20312   20313   20314   20317#
E10617  046370          20819#
E10620  046434          20860#
E10621  046500          20900#
E10622  046576          20947#
E10623  046622          20988#
E10624  046710          21041#
E10625  046764          21086#
E10626  047052          21138#
E10627  047116          21179#
E10630  047204          21230#
E10631  047262          21276#
E10632  047336          21322#
E10633  047412          21368#
E10634  047476          21419#
E10635  047562          21468#
E10636  047640          21509#  21518
E10637  047716          21553#
E10640  047764          21591#
E10641  050034          21631#
E10642  050104          21672#
E10643  050164          21718#
E10644  050254          21766#
E10645  050336          21807   21810   21812#
E10646  050410          21848   21851   21853#
E10650  050542          21947#
E10655  051002          22131#
E10656  051110          22189#
E10657  051222          22248#
E10660  051326          22302#
E10661  051424          22355#
E10662  051562          22427#
E10666  052154          22563#
E10670  052402          22645#
E10671  052516          22696#
```

```
E10672  052654          22756#
E10673  053060          22833#
E10714  055706          23440#
E10715  056130          23503#
E10717  056366          23600#
E10720  056506          23654#
E10725  057100          23803#
E10726  057214          23846#
E10727  057330          23890#
E10730  057504          23949#
E10731  057656          24010#
E10732  060030          24069#
E10733  060124          24101#
E10734  060224          24134#
E10740  060532          24292#
E10741  060640          24346#
E10742  060746          24400#
E10743  061064          24455#
E20012  003360           4459#
E20013  003420           4496#
E2002   001014           3004#
E20021  003772           4715#
E20022  004042           4755#
E20023  004110           4793#
E20024  004160           4831#
E20032  004532           5048#
E20033  004602           5086#
E20034  004652           5123#
E20035  004722           5161#
E20036  004770           5199#
E20037  005044           5238#
E20040  005130           5280#
E20041  005202           5319#
E20046  005520           5502#
E20053  006010           5674#
E20054  006070           5716#
E20056  006222           5792#
E20057  006300           5831#
E20062  006510           5943#
E20063  006564           5984#
E20074  007310           6298#
E20077  007520           6414#
E20100  007606           6460#
E20101  007712           6514#
E20102  010016           6568#
E20103  010120           6622#
E20104  010236           6680#
E20105  010326           6723#
E20106  010416           6766#
E20107  010506           6808#
E20110  010574           6850#
E20111  010662           6893#
E20112  010752           6935#
E20113  011042           6978#
E20114  011120           7019#
E20115  011176           7060#
```

```
E20116  011274          7111#
E20117  011374          7166#
E20124  011710          7342#
E20125  011752          7377#
E20126  012036          7417#
E20130  012224          7502#
E20132  012430          7596#
E20146  013720          8097#
E2015   001262          3333#
E20160  014270          8434#
E20162  014370          8511#
E2017   001346          3404#
E2020   001376          3440#
E2021   001430          3477#
E20224  015730          9624#
E20226  016044          9705#
E20230  016162          9789#
E20232  016356          9897#
E20234  016510          9983#
E20235  016570         10030#
E20236  016650         10079#
E20237  017012         10154#
E20240  017066         10200#
E20241  017146         10246#
E20242  017226         10292#
E20243  017304         10338#
E20244  017360         10384#
E20245  017440         10430#
E20246  017520         10476#
E20247  017576         10522#
E20250  017656         10568#
E20251  017734         10613#
E20252  020014         10658#
E20253  020072         10703#
E20254  020152         10748#
E20255  020232         10793#
E20256  020314         10839#
E20257  020374         10885#
E20260  020456         10931#
E20261  020536         10977#
E20262  020620         11023#
E20263  020702         11069#
E20264  020756         11110#
E20265  021046         11159#
E20266  021126         11200#
E20267  021220         11249#
E20270  021300         11290#
E20271  021372         11339#
E20272  021446         11379#
E20273  021534         11427#
E20274  021622         11473#
E20275  021700         11517#
E20276  021756         11560#
E20277  022032         11602#
E20300  022112         11645#
E20301  022170         11689#
```

```
E20302  022246          11732#
E20303  022326          11775#
E20304  022404          11818#
E20305  022464          11861#
E20306  022540          11903#
E20307  022616          11946#
E20310  022676          11989#
E20311  022752          12032#
E20312  023032          12076#
E20313  023112          12120#
E20314  023166          12164#
E20315  023246          12207#
E20316  023324          12250#
E20317  023404          12292#
E2032   001726           3760#
E20320  023462          12335#
E20321  023542          12378#
E20322  023622          12421#
E20323  023700          12463#
E20324  023756          12508#
E20325  024040          12555#
E20326  024120          12599#
E20327  024176          12641#
E2033   001770           3799#
E20330  024272          12692#
E20331  024352          12737#
E20332  024432          12781#
E20333  024514          12825#
E20334  024606          12872#
E20335  024670          12916#
E20336  024746          12959#
E20337  025026          13003#
E2034   002032           3836#
E20340  025110          13047#
E20341  025166          13091#
E20342  025250          13135#
E20343  025332          13179#
E20344  025410          13223#
E20345  025472          13267#
E20346  025552          13311#
E20347  025634          13354#
E20350  025714          13398#
E20351  025776          13442#
E20352  026060          13486#
E20353  026140          13529#
E20354  026220          13574#
E20355  026300          13618#
E20356  026360          13663#
E20357  026440          13707#
E20360  026520          13751#
E20361  026604          13795#
E20363  026736          13875#
E20365  027070          13954#
E20367  027222          14033#
E20371  027352          14113#
E20372  027436          14157#
```

```
E20373  027514          14198#
E20374  027604          14243#
E20375  027670          14286#
E20376  027746          14328#
E20377  030032          14371#
E20404  030360          14564#
E20405  030452          14610#
E20406  030546          14656#
E20407  030642          14702#
E2041   002200           3991#
E20410  030734          14748#
E20411  031026          14794#
E20412  031122          14840#
E20413  031216          14886#
E20420  031546          15085#
E20421  031626          15130#
E20422  031712          15175#
E20423  031776          15220#
E20424  032056          15266#
E20425  032142          15312#
E20426  032230          15358#
E20427  032316          15404#
E20430  032376          15452#
E20431  032456          15500#
E20432  032542          15548#
E20433  032626          15596#
E20434  032712          15644#
E20435  032776          15691#
E20436  033062          15736#
E20437  033146          15780#
E20440  033230          15824#
E20441  033310          15868#
E20442  033376          15912#
E20443  033470          15958#
E20444  033576          16009#
E20445  033656          16051#
E20446  033740          16094#
E20447  034020          16137#
E20450  034102          16180#
E20453  034316          16305#
E20454  034406          16354#
E20455  034476          16402#
E20456  034566          16451#
E20457  034654          16498#
E2046   002402           4146#
E20460  034756          16553#
E20461  035060          16608#
E20462  035162          16663#
E20463  035266          16718#
E20464  035372          16774#
E20465  035476          16829#
E20466  035602          16885#
E20467  035704          16940#
E20470  036006          16995#
E20471  036110          17050#
E20472  036212          17105#
```

```
E20473  036316          17160#
E20474  036422          17216#
E20475  036526          17271#
E20476  036632          17327#
E20477  036742          17385#
E20500  037036          17435#
E20501  037132          17485#
E20502  037226          17535#
E20503  037322          17585#
E20504  037430          17638#
E20505  037524          17688#
E20506  037620          17738#
E20515  040230          18007#
E20516  040312          18054#
E20521  040502          18170#
E20522  040560          18211#
E20524  040710          18294#
E20525  040774          18339#
E20526  041056          18385#
E20527  041142          18430#
E20537  041676          18745#
E20540  041754          18789#
E20541  042040          18833#
E20542  042116          18877#
E20543  042204          18923#
E20544  042300          18971#
E20545  042362          19016#
E20546  042444          19061#
E20547  042526          19105#
E20550  042614          19150#
E20551  042674          19195#
E20552  042762          19240#
E20553  043042          19285#
E20554  043130          19330#
E20555  043216          19375#
E20556  043304          19420#
E20557  043370          19466#
E20560  043454          19511#
E20561  043540          19555#
E20562  043620          19599#
E20563  043710          19644#
E20564  043770          19688#
E20565  044052          19732#
E20566  044134          19776#
E20567  044216          19820#
E20570  044300          19865#
E20571  044366          19910#
E20572  044454          19955#
E20573  044542          20000#
E20574  044634          20046#
E20575  044726          20092#
E20576  045020          20138#
E20577  045112          20184#
E20600  045202          20231#
E20601  045274          20278#
E20602  045364          20324#
```

E20617	046406	20823	20824	20825	20828#
E20620	046452	20864	20865	20866	20869#
E20621	046516	20904	20905	20906	20909#
E20622	046574	20951	20952	20953	20956#
E20623	046640	20992	20993	20994	20997#
E20624	046726	21045	21046	21047	21050#
E20625	046774	21081	21091#	21103	
E20626	047070	21142	21143	21144	21147#
E20627	047134	21183	21184	21185	21188#
E20630	047222	21234	21235	21236	21239#
E20631	047300	21280	21281	21282	21285#
E20632	047354	21326	21327	21328	21331#
E20633	047420	21363	21366	21372#	
E20634	047504	21414	21417	21423#	
E20635	047576	21476#			
E20636	047652	21515#			
E20637	047732	21556	21557	21558	21561#
E20640	050000	21594	21595	21596	21598#
E20641	050050	21639#			
E20642	050120	21680#			
E20643	050172	21713	21722#		
E20644	050270	21774#			
E20645	050352	21821#			
E20646	050424	21862#			
E20650	050550	21935	21950#		
E20655	051020	22135	22136	22137	22140#
E20656	051126	22193	22194	22195	22198#
E20657	051240	22256#			
E20660	051344	22310#			
E20661	051436	22363#			
E20662	051574	22435#			
E20670	052422	22653#			
E20671	052536	22704#			
E20672	052674	22764#			
E20673	053100	22841#			
E20714	055716	23445#			
E20715	056144	23510#			
E20717	056406	23608#			
E20720	056524	23662#			
E20725	057120	23812#			
E20726	057234	23855#			
E20727	057350	23899#			
E20730	057524	23959#			
E20731	057676	24020#			
E20732	060044	24078#			
E20733	060140	24110#			
E20734	060240	24143#			
E20740	060550	24300#			
E20741	060666	24357#			
E20742	060774	24411#			
E20743	061112	24466#			
E30024	004172	4838#			
E30077	007532	6421#			
E30100	007620	6466#			
E30101	007724	6520#			
E30102	010030	6574#			

```
E30103  010132          6628#
E30126  012046          7423#
E30130  012242          7509#
E30132  012446          7603#
E30146  013726          8102#
E30230  016220          9800    9801    9802    9805#
E30236  016706         10090   10091   10092   10095#
E30264  020770         11117#
E30266  021140         11207#
E30270  021312         11297#
E30272  021460         11386#
E30327  024210         12648#
E30457  034670         16506#
E30460  034772         16561#
E30461  035074         16616#
E30462  035176         16671#
E30463  035302         16726#
E30464  035406         16782#
E30465  035512         16837#
E30466  035616         16893#
E30467  035720         16948#
E30470  036022         17003#
E30471  036124         17058#
E30472  036226         17113#
E30473  036332         17168#
E30474  036436         17224#
E30475  036542         17279#
E30476  036646         17335#
E30621  046530         20915#
E30623  046652         21003#
E30624  046736         21055#
E30625  047012         21095   21096   21097   21100#
E30627  047146         21194#
E30631  047306         21271   21274   21289#
E30632  047362         21317   21320   21335#
E30633  047436         21376   21377   21378   21381#
E30634  047522         21427   21428   21429   21432#
E30636  047664         21521#
E30642  050130         21685#
E30643  050206         21730#
E30644  050300         21761   21779#
E30646  050434         21867#
E30655  051030         22146#
E30656  051136         22204#
E30657  051254         22266#
E30660  051360         22320#
E30661  051462         22375#
E30662  051620         22447#
E30672  052722         22773#
E30673  053126         22850#
E30715  056162         23517#
E30717  056424         23615#
E30720  056536         23669#
E30725  057140         23821#
E30726  057254         23863#
E30727  057370         23908#
```

```
E30730  057544          23969#
E30731  057716          24030#
E40100  007632           6473#
E40101  007736           6527#
E40102  010042           6581#
E40103  010144           6635#
E40130  012256           7516#
E40132  012462           7610#
E40146  013734           8107#
E40230  016232           9811#
E40236  016720          10101#
E40623  046662          21007#
E40625  047024          21106#
E40633  047446          21387#
E40634  047532          21438#
E40655  051044          22154#
E40656  051152          22212#
E40661  051500          22382#
E40662  051636          22454#
E40672  052730          22746   22777#
E40673  053134          22823   22854#
E40715  056174          23523#
E40727  057434          23926#
E40730  057566          23979#
E40731  057740          24040#
E50230  016244           9817#
E50236  016732          10107#
E50661  051516          22392#
E50662  051654          22464#
E50715  056206          23529#
FILLS   066660          26807   26962#
FIRST   066704           4665   26346   26972#
F0661   051506          22379   22387#
F0662   051644          22451   22459#
F0715   056170          23483   23521#
G0661   051522          22388   22395#
G0662   051660          22460   22467#
G0715   056202          23492   23527#
H0715   056212          23505   23508   23512   23519   23525   23532#
IBUF    067556           7971    7992   27068#
ICOUNT  066662           4155*  26295*  26583   26963#
IDENT1  067212           8028   27020#
INIT    003000           4144    4154#
ITCNT   066664           4156*  22632*  22683*  26296*  26581*  26583*  26964#
IO001   003046           4184#
IO002   003062           4210#
IO003   003100           4238#
IO004   003114           4263#
IO005   003136           4292#
IO006   003160           4321#
IO007   003214           4352#
IO010   003252           4384#
IO011   003310           4417#
IO012   003342           4449#
IO013   003402           4486#
IO014   003444           4523#
```

```
I0015   003500          4556#
I0016   003544          4593#
I0017   003612          4628#
I002    001012          2996    3002#
I0020   003706          4672#
I0021   003750          4704#
I0022   004022          4744#
I0023   004072          4783#
I0024   004144          4821#
I0025   004226          4868#
I0026   004274          4902#
I0027   004340          4936#
I0030   004400          4969#
I0031   004450          5004#
I0032   004516          5038#
I0033   004566          5076#
I0034   004636          5113#
I0035   004706          5151#
I0036   004752          5188#
I0037   005026          5227#
I004    001034          3054#
I0040   005110          5269#
I0041   005162          5308#
I0042   005240          5349#
I0043   005312          5387#
I0044   005360          5421#
I0045   005430          5456#
I0046   005500          5491#
I0047   005552          5530#
I005    001052          3083#
I0050   005612          5558    5561#
I0051   005652          5593#
I0052   005722          5628#
I0053   005770          5662#
I0054   006046          5704#
I0055   006126          5745#
I0056   006176          5780#
I0057   006260          5820#
I006    001070          3112#
I0060   006336          5860#
I0061   006412          5895#
I0062   006464          5931#
I0063   006544          5973#
I0064   006620          6013#
I0065   006660          6046#
I0066   006722          6079#
I0067   006764          6111#
I007    001104          3140#
I0070   007034          6145#
I0071   007104          6180#
I0072   007152          6216#
I0073   007226          6254#
I0074   007266          6287#
I0075   007344          6326#
I0076   007414          6362#
I0077   007500          6403#
```

```
I010     001120          3169#
I0100    007570          6450#
I0101    007674          6504#
I0102    010000          6558#
I0103    010102          6612#
I0104    010212          6668#
I0105    010302          6711#
I0106    010372          6754#
I0107    010462          6796#
I011     001136          3202#
I0110    010550          6838#
I0111    010636          6881#
I0112    010726          6923#
I0113    011016          6966#
I0114    011100          7008#
I0115    011156          7049#
I0116    011242          7093#
I0117    011342          7148#
I012     001156          3232#
I0120    011434          7197#
I0121    011506          7231#
I0122    011560          7265#
I0123    011632          7300#
I0124    011676          7334#
I0125    011734          7369#
I0126    012012          7407#
I0127    012106          7453#
I013     001200          3262#
I0130    012200          7492#
I0131    012320          7548#
I0132    012404          7586#
I0133    012526          7642#
I0134    012620          7685#
I0135    012672          7721#
I0136    012752          7749     7758#
I0137    013046          7790     7799#
I014     001230          3294#
I0140    013136          7838#
I0141    013224          7877#    7881
I0142    013270          7912#
I0143    013332          7945#
I0145    013656          8052     8055#
I0147    013754          8132     8136#
I015     001246          3322#
I0150    014000          8164     8167#
I0151    014022          8191     8195#
I0152    014046          8223     8227#
I0153    014070          8254     8258#
I0154    014114          8288     8292#
I0155    014136          8319     8323#
I0156    014162          8351     8355#
I0157    014204          8382     8386#
I016     001274          3358#
I0160    014244          8419     8423#
I0161    014310          8459     8463#
I0162    014346          8496     8500#
```

```
IO163   014410          8536    8540#
IO164   014434          8567    8572#
IO165   014462          8598    8603#
IO166   014510          8631    8636#
IO167   014532          8663    8667#
IO17    001322          3390#
IO170   014560          8695    8700#
IO171   014604          8727    8732#
IO172   014630          8759    8764#
IO173   014656          8792    8797#
IO174   014716          8825    8833#
IO175   014744          8861    8866#
IO176   014770          8892    8896#
IO177   015014          8924    8929#
IO20    001362          3430#
IO200   015042          8957    8962#
IO201   015070          8990    8995#
IO202   015116          9022    9027#
IO203   015140          9055    9059#
IO204   015166          9087    9092#
IO205   015212          9119    9124#
IO206   015236          9152    9157#
IO207   015262          9184    9189#
IO21    001412          3466#
IO210   015306          9217    9221#
IO211   015332          9248    9253#
IO212   015360          9281    9286#
IO213   015406          9313    9318#
IO214   015432          9346    9350#
IO215   015460          9379    9384#
IO216   015504          9412    9417#
IO217   015530          9444    9449#
IO22    001436          3501#
IO220   015552          9476    9480#
IO221   015576          9507    9512#
IO222   015622          9540    9544#
IO223   015650          9572    9577#
IO224   015706          9604    9611#
IO225   015762          9649    9656#
IO226   016020          9684    9691#
IO227   016100          9730    9738#
IO23    001474          3534#
IO231   016276          9842    9849#
IO232   016334          9877    9884#
IO233   016412          9922    9930#
IO234   016466          9959    9970#
IO235   016546         10009   10017#
IO237   016770         10133   10141#
IO24    001534          3574#
IO240   017044         10179   10187#
IO241   017124         10225   10233#
IO242   017204         10271   10279#
IO243   017262         10317   10325#
IO244   017336         10363   10371#
IO245   017416         10409   10417#
IO246   017476         10455   10463#
```

```
I0247   017554          10501   10509#
I025    001552           3603#
I0250   017634          10548   10555#
I0251   017712          10593   10600#
I0252   017772          10638   10645#
I0253   020050          10683   10690#
I0254   020130          10728   10735#
I0255   020210          10773   10780#
I0256   020270          10818   10825#
I0257   020350          10864   10871#
I026    001572           3631#
I0260   020432          10910   10917#
I0261   020512          10956   10963#
I0262   020574          11002   11009#
I0263   020656          11048   11055#
I0264   020740          11093   11100#
I0265   021030          11140   11148#
I0266   021110          11182   11190#
I0267   021202          11230   11238#
I027    001616           3661#
I0270   021262          11272   11280#
I0271   021354          11320   11328#
I0272   021430          11362   11369#
I0273   021516          11409   11416#
I0274   021600          11450   11460#
I0275   021656          11496   11504#
I0276   021734          11541   11548#
I0277   022010          11584   11590#
I030    001636           3690#
I0300   022070          11626   11633#
I0301   022146          11670   11677#
I0302   022224          11713   11720#
I0303   022304          11756   11763#
I0304   022362          11799   11806#
I0305   022442          11842   11849#
I0306   022516          11885   11891#
I0307   022574          11927   11934#
I031    001656           3718#
I0310   022654          11970   11977#
I0311   022730          12013   12020#
I0312   023010          12057   12064#
I0313   023070          12101   12108#
I0314   023144          12145   12152#
I0315   023224          12188   12195#
I0316   023302          12231   12238#
I0317   023362          12273   12280#
I032    001710           3749#
I0320   023440          12316   12323#
I0321   023520          12359   12366#
I0322   023600          12402   12409#
I0323   023656          12444   12451#
I0324   023732          12487   12494#
I0325   024014          12533   12541#
I0326   024074          12579   12586#
I0327   024152          12623   12629#
I033    001752           3788#
```

```
I0330   024246          12672   12679#
I0331   024326          12717   12724#
I0332   024406          12761   12768#
I0333   024470          12905   12812#
I0334   024562          12849   12859#
I0335   024644          12896   12903#
I0336   024722          12940   12946#
I0337   025002          12983   12990#
I034    002014           3825#
I0340   025064          13027   13034#
I0341   025142          13071   13078#
I0342   025224          13115   13122#
I0343   025306          13159   13166#
I0344   025364          13203   13210#
I0345   025446          13247   13254#
I0346   025526          13291   13298#
I0347   025610          13334   13341#
I035    002046           3861#
I0350   025670          13378   13385#
I0351   025752          13422   13429#
I0352   026034          13466   13473#
I0353   026114          13509   13516#
I0354   026176          13554   13561#
I0355   026256          13598   13605#
I0356   026336          13643   13650#
I0357   026416          13687   13694#
I036    002066           3890#
I0360   026476          13731   13738#
I0361   026562          13775   13783#
I0362   026646          13819   13827#
I0363   026714          13856   13863#
I0364   026774          13898   13905#
I0365   027046          13934   13942#
I0366   027132          13977   13985#
I0367   027200          14014   14021#
I037    002106           3919#
I0370   027260          14056   14063#
I0371   027330          14092   14100#
I0372   027414          14136   14144#
I0373   027474          14180   14187#
I0374   027564          14222   14232#
I0375   027646          14267   14275#
I0376   027726          14310   14317#
I0377   030010          14352   14360#
I040    002130           3949#
I0400   030070          14395   14402#
I0401   030142          14431   14439#
I0402   030210          14468   14475#
I0403   030256          14505   14512#
I0404   030326          14542   14550#
I0405   030420          14588   14596#
I0406   030514          14634   14642#
I0407   030610          14680   14688#
I041    002156           3979#
I0410   030724          14726   14734#
I0411   030776          14772   14780#
```

```
IO412   031070          14818   14826#
IO413   031164          14864   14872#
IO414   031260          14911   14919#
IO415   031334          14950   14958#
IO416   031406          14989   14997#
IO417   031460          15028   15036#
IO42    002212           4017#
IO420   031524          15065   15072#
IO421   031604          15109   15117#
IO422   031670          15154   15162#
IO423   031754          15199   15207#
IO424   032032          15244   15252#
IO425   032116          15290   15298#
IO426   032204          15336   15344#
IO427   032272          15382   15390#
IO43    002234           4048#
IO430   032354          15430   15439#
IO431   032434          15478   15487#
IO432   032520          15526   15535#
IO433   032604          15574   15583#
IO434   032670          15622   15631#
IO435   032752          15669   15677#
IO436   033036          15714   15722#
IO437   033122          15759   15766#
IO44    002260           4078#
IO440   033206          15803   15811#
IO441   033266          15847   15855#
IO442   033354          15891   15899#
IO443   033444          15935   15944#
IO444   033552          15982   15995#
IO445   033634          16032   16039#
IO446   033716          16075   16082#
IO447   034000          16118   16125#
IO45    002306           4107#
IO450   034060          16161   16168#
IO451   034142          16205   16212#
IO452   034214          16243   16250#
IO453   034270          16280   16290#
IO454   034360          16329   16339#
IO455   034450          16377   16387#
IO456   034540          16426   16436#
IO457   034630          16475   16485#
IO46    002352           4131#
IO460   034732          16530   16540#
IO461   035034          16585   16595#
IO462   035136          16640   16650#
IO463   035242          16695   16705#
IO464   035346          16751   16761#
IO465   035452          16806   16816#
IO466   035556          16862   16872#
IO467   035662          16917   16927#
IO470   035764          16972   16982#
IO471   036066          17027   17037#
IO472   036170          17082   17092#
IO473   036272          17137   17147#
IO474   036376          17193   17203#
```

I0475	036502	17248	17258#
I0476	036606	17304	17314#
I0477	036712	17360	17370#
I0500	037006	17410	17420#
I0501	037102	17460	17470#
I0502	037176	17510	17520#
I0503	037272	17560	17570#
I0504	037400	17610	17623#
I0505	037474	17663	17673#
I0506	037570	17713	17723#
I0507	037652	17762	17769#
I0510	037714	17799	17806#
I0511	037760	17836	17843#
I0512	040024	17874	17881#
I0513	040070	17911	17918#
I0514	040134	17950	17957#
I0515	040206	17986	17994#
I0516	040270	18032	18041#
I0517	040350	18079	18087#
I0520	040416	18115	18122#
I0521	040462	18152	18159#
I0522	040540	18193	18200#
I0523	040616	18236	18243#
I0524	040666	18274	18282#
I0525	040752	18319	18327#
I0526	041036	18365	18373#
I0527	041120	18410	18418#
I0530	041204	18455	18463#
I0531	041260	18494	18502#
I0532	041332	18534	18542#
I0533	041402	18572	18580#
I0534	041454	18610	18618#
I0535	041526	18648	18656#
I0536	041600	18687	18695#
I0537	041654	18724	18732#
I0540	041732	18768	18776#
I0541	042016	18812	18820#
I0542	042074	18856	18864#
I0543	042160	18901	18909#
I0544	042256	18947	18958#
I0545	042340	18995	19003#
I0546	042422	19040	19048#
I0547	042504	19085	19092#
I0550	042570	19128	19136#
I0551	042650	19173	19181#
I0552	042736	19218	19226#
I0553	043016	19263	19271#
I0554	043104	19308	19316#
I0555	043172	19353	19361#
I0556	043260	19398	19406#
I0557	043344	19444	19452#
I0560	043430	19490	19497#
I0561	043516	19534	19542#
I0562	043576	19578	19586#
I0563	043666	19622	19631#
I0564	043746	19667	19675#

I0565	044030	19711	19719#	
I0566	044112	19755	19763#	
I0567	044174	19799	19807#	
I0570	044256	19844	19852#	
I0571	044344	19889	19897#	
I0572	044430	19933	19941#	
I0573	044516	19978	19986#	
I0574	044610	20023	20032#	
I0575	044702	20069	20078#	
I0576	044774	20115	20124#	
I0577	045066	20161	20170#	
I0600	045156	20208	20217#	
I0601	045250	20255	20264#	
I0602	045340	20302	20310#	
I0603	045422	20351	20358#	
I0604	045500	20389	20399#	
I0605	045550	20430	20438#	
I0606	045622	20469	20477#	
I0607	045674	20508	20516#	
I0610	045746	20547	20555#	
I0611	046020	20586	20594#	
I0612	046074	20625	20633#	
I0613	046142	20663	20670#	
I0614	046214	20700	20708#	
I0615	046260	20737	20744#	
I0616	046332	20775	20783#	
I0617	046366	20812	20817#	
I0620	046432	20853	20858#	
I0621	046476	20893	20898#	
I0622	046554	20940	20945#	
I0623	046620	20981	20986#	
I0624	046706	21034	21039#	
I0625	046762	21080	21084#	
I0626	047050	21131	21136#	
I0627	047114	21172	21177#	
I0630	047202	21223	21228#	
I0631	047256	21269	21274#	
I0632	047332	21315	21320#	
I0633	047406	21361	21366#	
I0634	047472	21412	21417#	
I0635	047560	21461	21466#	
I0636	047636	21500	21507#	
I0637	047714	21546	21551#	
I0640	047762	21584	21589#	
I0641	050032	21623	21629#	
I0642	050102	21664	21670#	
I0643	050162	21710	21716#	
I0644	050252	21755	21764#	
I0645	050332	21804	21810#	
I0646	050404	21845	21851#	
I0647	050472	21894	21897	21904#
I0650	050526	21928	21932	21938#
I0651	050574	21973	21978#	
I0652	050632	22010	22015#	
I0653	050670	22047	22052#	
I0654	050726	22084	22089#	

```
I0655   051000          22121   22129#
I0656   051106          22179   22187#
I0657   051220          22237   22246#
I0660   051324          22291   22300#
I0661   051420          22345   22352#
I0662   051556          22417   22424#
I0663   051722          22475   22484#
I0664   052002          22502   22509#
I0665   052046          22524   22531#
I0666   052142          22545   22557#
I0667   052256          22580   22593#
I0670   052362          22631   22638#
I0671   052476          22682   22689#
I0672   052642          22733   22752#  22761
I0673   053046          22810   22829#  22838
I0674   053240          22872   22884#
I0675   053362          22906   22918#
I0676   053504          22940   22952#
I0677   053626          22974   22986#
I0700   053750          23008   23020#
I0701   054072          23042   23054#
I0702   054206          23076   23086#
I0703   054322          23108   23118#
I0704   054450          23140   23153#
I0705   054564          23175   23185#
I0706   054706          23206   23218#
I0707   055032          23241   23253#
I0710   055150          23276   23286#
I0711   055266          23309   23319#
I0712   055404          23342   23352#
I0713   055522          23375   23385#
I0714   055672          23414   23434#
I0715   056106          23463   23495#
I0716   056272          23550   23556#
I0717   056356          23587   23596#
I0720   056476          23642   23650#
I0721   056600          23680   23687#
I0722   056660          23705   23712#
I0723   056740          23730   23737#
I0724   057022          23769   23777#
I0732   060022          24062   24066#
I0733   060120          24091   24098#
I0734   060220          24123   24131#
I0735   060314          24169   24177#
I0736   060372          24207   24215#
I0737   060450          24244   24252#
I0740   060530          24281   24286   24290#
I0741   060622          24332   24339#
I0742   060730          24386   24393#
I0743   061046          24439   24448#
I0744   061172          24500*  24503#
I0745   061262          24544*  24547#
I0746   061346          24588*  24591#
I0747   061434          24632*  24635#
I0750   061522          24676*  24679#
I0751   061610          24719*  24722#
```

I0752	061666	24761#	24764#	
I0753	061754	24805#	24808#	
I0754	062032	24847#	24850#	
I0755	062142	24898	24902	24906#
I0756	062206	24933	24938	24942#
I0757	062252	24970	24975	24979#
I0760	062312	25006	25010	25014#
I0761	062352	25042	25046	25050#
I0762	062416	25079	25084	25088#
I0763	062462	25117	25122	25126#
I0764	062522	25153	25157	25161#
I0765	062562	25188	25192	25196#
I0766	062622	25224	25228	25232#
I0767	062666	25260	25265	25269#
I0770	062726	25296	25300	25304#
I0771	062772	25333	25338	25342#
I0772	063032	25370	25374	25378#
I0773	063072	25405	25409	25413#
I0774	063132	25440	25444	25448#
I0775	063176	25477	25482	25486#
I0776	063242	25515	25520	25524#
I0777	063306	25552	25557	25561#
I1000	063346	25588	25592	25596#
I1001	063406	25623	25627	25631#
I1002	063444	25658	25662	25665#
I1003	063502	25692	25696	25699#
I1004	063546	25726	25731	25735#
I1005	063626	25762	25770	25775#
I1006	063700	25802	25807	25814#
I1007	063744	25843	25847	25852#
I1010	064020	25922#		
I1011	064076	25991#		
I1012	064154	26064#		
I1013	064232	26134#		
I1014	064300	26193#		
I10146	013710	8086	8090#	
I1015	064344	26245#		
I10230	016140	9768	9776#	
I10236	016626	10058	10066#	
I10725	057076	23798	23801#	
I10726	057212	23841	23844#	
I10727	057326	23885	23888#	
I10730	057500	23942	23946#	
I10731	057652	24003	24007#	
I20146	013716	8090	8095#	
I20230	016206	9793	9798#	
I20236	016674	10082	10088#	
I20725	057116	23807	23810#	
I20726	057232	23850	23853#	
I20727	057346	23894	23897#	
I20730	057520	23952	23956#	
I20731	057672	24013	24017#	
I30146	013724	8095	8100#	
I30725	057134	23816	23819#	
I30726	057250	23858	23861#	
I30727	057364	23903	23906#	

```
I30730  057540          23962   23966#
I30731  057712          24023   24027#
I40146  013732           8100    8105#
I40730  057560          23972   23976#
I40731  057732          24033   24037#
JMP3    046660          20983   21000   21006#
JMP3A   046734          21036   21054#
JMP5    047156          21174   21191   21198#
JMP5A   047232          21225   21244#
JMP7    047444          21366   21385#
JMP7A   047530          21417   21436#
JSR3    050126          21667   21684#
JSR7    050432          21851   21866#
LAST    066706          26267*  26347   26973#
LKCSR = 177546           2941#  22479   22505   22527   22549   22584   22876   22910   22944   22978   23012   23046   23210
                        23245   23417   23466
LOGICA  064550          26304#
L1010   064002          25915#  25925   25933   25936
L1011   064060          25984#  25994   26002   26005
L1012   064136          26057#  26067   26075   26078
L1013   064214          26127#  26137   26145   26148
MBUFO   067602           4379    4381*   4412    4414*   4518    4551    4589    4624    4667    4672    4699    4704    4739
                         4744    4778    4790    4862    4868*   4897    4902*   4965    4969*   4998    5000    5415    5417
                         5450    5589    5656    5658    5699    5700    5739    5745*   5774    5780*   5890*   5891    5926*
                         5927    5940    5967    5973    6007    6013    6042    6046    6075    6079    6106    6111*   6140
                         6145*   6249    6254    6282    6287    6321    6357    6358    6662    6705    6748    6790    6831
                         6847    6874    6890    6916    6919    6932    6959    6962    6975    7191    7197*   7225    7231*
                         7259    7265*   7294    7300*   7828*   7829*   9770    9792    9808    9814    9845    9880    9925
                        10061   10083   10098   10104   10136   10365   10411   10457   10503   10819   10865   10911   10957
                        11003   11049   11094   11107   11141   11183   11185   11197   11231   11233   11273   11275   11287
                        11321   11323   11363   11376   11410   12488   12534   12580   12624   12638   12673   12718   12762
                        12806   12853   12897   12941   12984   13028   13072   13116   13160   13204   13248   13292   13335
                        13379   13423   13467   13510   13776   13778   13785   13820   13822   13857   13865   13899   13935
                        13937   13944   13978   13980   14015   14023   14057   14271*  14277   14356*  14362   14397   14435*
                        14469   14506   14543   14561   14589   14607   14635   14681   14727   14730   14773   14776   14819
                        14865   14912   14915   14951   14954   14990   15029   15247   15293   15339   15385   15670   15715
                        15760   15892   15936   15986   16033   16048   16076   16119   16121   16162   16206   16208   16244
                        16283   16332   16379   16428   16478   16495   16533   16550   16587   16605   16642   16660   16698
                        16754   16808   16864   16920   16922   16975   16977   17029   17031   17084   17086   17140   17196
                        17250   17306   17363   17365   17413   17415   17462   17464   17512   17514   17563   17616   17665
                        17715   17763   17800   17837   17875   17877   17912   17953   18237   18275   18291   18320   18366
                        18370   18411   18456   18460   18495   18535   18573   18611   18649   18652   18688   18691   19129
                        19174   19219   19264   19309   19354   19399   19445   19491   19934   19979   20024   20070   20116
                        20162   20209   20256   20303   20393   20431   20470   20509   20512   20548   20587   20590   20626
                        20664   20701   20704   20738   20776   20779   23475*  23497*  23500   24936   24973   25082   25120
                        25262   25479   25517   26386*  26387*  26904   27074   27077#
MBUF1   067606           4588    4623    5525    5530*   5925    6661    6704    6747    6789   14555*  14560   14601*  14606
                        14647*  14652   14693*  14698   14739*  14744   14785*  14790   14831*  14836   14877*  14882   15894
                        15938   15988   17951   19625   19892   20026   20072   20118   20164   20211   20258   20305   23476*
                        23507   23514*  23794   23806   23837   23849   24472*  24473*  24862   24863   27075   27079#
MISFLG  066710          26351   26355*  26974#
MISHDR  067477          26354   27053#
MISS    064564          26269   26342#
MT      003642           4641#   4643
OBUF    067546           7972    7993   27063#
ONCE    066722           4159    8024    8026*  26299   26980#
```

OPTION	066636	22476	22503	22525	22546	22581	22873	22907	22941	22975	23009	23043	23207	23242
		23415	23464	24441	24581	24625	24669	24712	24798	26860*	26870	26879*	26892*	26906*
		26921*	26934*	26946#										
OPT1	067270	26864	27028#											
OPT2	067334	26883	27034#											
OPT3	067347	26896	27036#											
OPT4	067362	26910	27038#											
OPT5	067375	26925	27040#											
OPT6	067410	26938	27042#											
OPT7	067423	26873	27044#											
ORTAB	067772	26126	26128	27150#										
OTA	065760	26276	26282	26288	26357	26457	26528	26725	26742#					
00145	013674	8059	8064#											
00146	013740	8105	8110#											
00147	013764	8137	8142#											
00150	014006	8167	8170#											
00151	014032	8196	8201#											
00152	014054	8227	8232#											
00153	014100	8259	8264#											
00154	014122	8292	8297#											
00155	014146	8324	8329#											
00156	014170	8355	8360#											
00157	014230	8390	8397#											
00160	014274	8430	8437#											
00161	014332	8467	8474#											
00162	014374	8507	8514#											
00163	014416	8540	8545#											
00164	014444	8573	8577#											
00165	014472	8604	8609#											
00166	014516	8636	8641#											
00167	014542	8668	8673#											
00170	014566	8700	8705#											
00171	014612	8732	8737#											
00172	014640	8765	8770#											
00173	014666	8798	8803#											
00174	014726	8834	8839#											
00175	014754	8867	8872#											
00176	014776	8896	8901#											
00177	015024	8930	8935#											
00200	015052	8963	8968#											
00201	015100	8996	9001#											
00202	015124	9027	9032#											
00203	015150	9060	9065#											
00204	015174	9092	9097#											
00205	015220	9124	9129#											
00206	015244	9157	9162#											
00207	015272	9190	9195#											
00210	015314	9221	9226#											
00211	015342	9254	9259#											
00212	015370	9287	9292#											
00213	015416	9319	9324#											
00214	015442	9351	9356#											
00215	015466	9384	9389#											
00216	015512	9417	9422#											
00217	015536	9449	9454#											
00220	015560	9480	9485#											

00221	015606	9513	9518#
00222	015632	9545	9550#
00223	015656	9577	9582#
00224	015734	9622	9627#
00225	015772	9657	9662#
00226	016050	9703	9708#
00227	016110	9739	9744#
00230	016250	9815	9820#
00231	016306	9850	9855#
00232	016362	9895	9900#
00233	016422	9931	9936#
00234	016514	9981	9986#
00235	016574	10028	10033#
00236	016736	10105	10110#
00237	017016	10152	10157#
00240	017072	10198	10203#
00241	017152	10244	10249#
00242	017232	10290	10295#
00243	017310	10336	10341#
00244	017364	10382	10387#
00245	017444	10428	10433#
00246	017524	10474	10479#
00247	017602	10520	10525#
00250	017662	10566	10571#
00251	017740	10611	10616#
00252	020020	10656	10661#
00253	020076	10701	10706#
00254	020156	10746	10751#
00255	020236	10791	10796#
00256	020320	10836	10842#
00257	020400	10882	10888#
00260	020462	10928	10934#
00261	020542	10974	10980#
00262	020624	11020	11026#
00263	020706	11066	11072#
00264	020774	11114	11120#
00265	021052	11156	11162#
00266	021144	11204	11210#
00267	021224	11246	11252#
00270	021316	11294	11300#
00271	021376	11336	11342#
00272	021464	11383	11389#
00273	021540	11424	11430#
00274	021626	11471	11476#
00275	021704	11515	11520#
00276	021762	11558	11563#
00277	022036	11600	11605#
00300	022116	11643	11648#
00301	022174	11687	11692#
00302	022252	11730	11735#
00303	022332	11773	11778#
00304	022410	11816	11821#
00305	022470	11859	11864#
00306	022544	11901	11906#
00307	022622	11944	11949#
00310	022702	11987	11992#

00311	022756	12030	12035#
00312	023036	12074	12079#
00313	023116	12118	12123#
00314	023172	12162	12167#
00315	023252	12205	12210#
00316	023330	12248	12253#
00317	023410	12290	12295#
00320	023466	12333	12338#
00321	023546	12376	12381#
00322	023626	12419	12424#
00323	023704	12461	12466#
00324	023762	12505	12511#
00325	024044	12552	12558#
00326	024124	12596	12602#
00327	024214	12645	12651#
00330	024276	12689	12695#
00331	024356	12734	12740#
00332	024436	12778	12784#
00333	024520	12822	12828#
00334	024612	12869	12875#
00335	024674	12913	12919#
00336	024752	12956	12962#
00337	025032	13000	13006#
00340	025114	13044	13050#
00341	025172	13088	13094#
00342	025254	13132	13138#
00343	025336	13176	13182#
00344	025414	13220	13226#
00345	025476	13264	13270#
00346	025556	13308	13314#
00347	025640	13351	13357#
00350	025720	13395	13401#
00351	026002	13439	13445#
00352	026064	13483	13489#
00353	026144	13526	13532#
00354	026224	13572	13577#
00355	026304	13616	13621#
00356	026364	13661	13666#
00357	026444	13705	13710#
00360	026524	13749	13754#
00361	026610	13792	13798#
00362	026662	13830	13836#
00363	026742	13872	13878#
00364	027010	13908	13914#
00365	027074	13951	13957#
00366	027146	13988	13994#
00367	027226	14030	14036#
00370	027274	14066	14072#
00371	027356	14111	14116#
00372	027442	14155	14160#
00373	027520	14196	14201#
00374	027610	14241	14246#
00375	027674	14284	14289#
00376	027752	14326	14331#
00377	030036	14369	14374#
00400	030104	14405	14410#

00401	030156	14442	14447#
00402	030224	14478	14484#
00403	030272	14515	14521#
00404	030364	14562	14567#
00405	030456	14608	14613#
00406	030552	14654	14659#
00407	030646	14700	14705#
00410	030740	14746	14751#
00411	031032	14792	14797#
00412	031126	14838	14843#
00413	031222	14884	14889#
00414	031276	14922	14928#
00415	031352	14961	14967#
00416	031424	15000	15006#
00417	031476	15039	15045#
00420	031552	15083	15088#
00421	031632	15128	15133#
00422	031716	15173	15178#
00423	032002	15218	15223#
00424	032062	15263	15269#
00425	032146	15309	15315#
00426	032234	15355	15361#
00427	032322	15401	15407#
00430	032402	15450	15455#
00431	032462	15498	15503#
00432	032546	15546	15551#
00433	032632	15594	15599#
00434	032716	15642	15647#
00435	033002	15688	15694#
00436	033066	15733	15739#
00437	033152	15777	15783#
00440	033234	15822	15827#
00441	033314	15866	15871#
00442	033402	15910	15915#
00443	033474	15955	15961#
00444	033602	16006	16012#
00445	033662	16049	16054#
00446	033744	16092	16097#
00447	034024	16135	16140#
00450	034106	16178	16183#
00451	034160	16215	16221#
00452	034232	16253	16259#
00453	034322	16301	16308#
00454	034412	16350	16357#
00455	034502	16398	16405#
00456	034572	16447	16454#
00457	034674	16502	16509#
00460	034776	16557	16564#
00461	035100	16612	16619#
00462	035202	16667	16674#
00463	035306	16722	16729#
00464	035412	16778	16785#
00465	035516	16833	16840#
00466	035622	16889	16896#
00467	035724	16944	16951#
00470	036026	16999	17006#

00471	036130	17054	17061#
00472	036232	17109	17116#
00473	036336	17164	17171#
00474	036442	17220	17227#
00475	036546	17275	17282#
00476	036652	17331	17338#
00477	036746	17381	17388#
00500	037042	17431	17438#
00501	037136	17481	17488#
00502	037232	17531	17538#
00503	037326	17581	17588#
00504	037434	17634	17641#
00505	037530	17684	17691#
00506	037624	17734	17741#
00507	037666	17772	17778#
00510	037730	17809	17815#
00511	037774	17846	17852#
00512	040040	17884	17890#
00513	040104	17921	17927#
00514	040152	17960	17966#
00515	040234	18005	18010#
00516	040316	18052	18057#
00517	040362	18090	10095#
00520	040430	18125	18130#
00521	040506	18168	18173#
00522	040564	18209	18214#
00523	040632	18246	18252#
00524	040714	18292	18297#
00525	041000	18336	18343#
00526	041062	18382	18388#
00527	041146	18427	18433#
00530	041222	18466	18472#
00531	041276	18505	18511#
00532	041346	18545	19551#
00533	041416	18583	18589#
00534	041470	18621	18627#
00535	041542	18659	18665#
00536	041616	18698	18704#
00537	041702	18743	18748#
00540	041760	18787	18792#
00541	042044	18831	18836#
00542	042122	18875	18880#
00543	042210	18920	18926#
00544	042304	18969	18974#
00545	042366	19014	19019#
00546	042450	19059	19064#
00547	042532	19103	19108#
00550	042620	19147	19153#
00551	042700	19192	19198#
00552	042766	19237	19243#
00553	043046	19282	19288#
00554	043134	19327	19333#
00555	043222	19372	19377#
00556	043310	19417	19423#
00557	043374	19463	19469#
00560	043460	19508	19514#

```
00561   043544          19553   19558#
00562   043624          19597   19602#
00563   043714          19642   19647#
00564   043774          19686   19691#
00565   044056          19730   19735#
00566   044140          19774   19778#
00567   044222          19818   19823#
00570   044304          19863   19868#
00571   044372          19908   19913#
00572   044460          19952   19958#
00573   044546          19997   20003#
00574   044640          20043   20049#
00575   044732          20089   20095#
00576   045024          20135   20141#
00577   045116          20181   20187#
00600   045206          20228   20234#
00601   045300          20275   20281#
00602   045370          20321   20327#
00603   045434          20361   20366#
00604   045514          20402   20408#
00605   045564          20441   20447#
00606   045636          20480   20486#
00607   045710          20519   20525#
00610   045762          20558   20564#
00611   046036          20597   20603#
00612   046112          20636   20642#
00613   046156          20673   20679#
00614   046230          20711   20717#
00615   046274          20747   20753#
00616   046346          20786   20792#
00617   046412          20821   20826   20831#
00620   046456          20862   20867   20872#
00621   046534          20902   20913   20918#
00622   046600          20949   20954   20959#
00623   046666          20990   21001   21005   21012#
00624   046742          21043   21048   21052   21058#
00625   047030          21088   21093   21104   21109#
00626   047074          21140   21145   21150#
00627   047162          21181   21192   21196   21201#
00630   047236          21232   21237   21241   21247#
00631   047312          21278   21283   21287   21293#
00632   047366          21324   21329   21333   21339#
00633   047452          21370   21374   21379   21383   21390#
00634   047536          21421   21425   21430   21434   21441#
00635   047604          21473   21480#
00636   047672          21525#
00637   047740          21565#
00640   050006          21602#
00641   050056          21636   21644#
00642   050136          21677   21690#
00643   050214          21727   21735#
00644   050306          21771   21784#
00645   050360          21817   21825#
00646   050442          21859   21872#
00647   050474          21901   21906#
00650   050554          21945   21949   21952#
```

```
00651   050612          21983   21988#
00652   050650          22020   22025#
00653   050706          22057   22062#
00654   050744          22094   22099#
00655   051052          22150   22158#
00656   051160          22208   22216#
00657   051262          22262   22270#
00660   051366          22316   22324#
00661   051524          22358   22366   22385   22397#
00662   051662          22430   22438   22457   22469#
00663   051750          22477   22495#
00664   052014          22504   22511   22517#
00665   052062          22526   22533   22539#
00666   052200          22547   22572#
00667   052322          22582   22608#
00670   052436          22659#
00671   052552          22710#
00672   052756          22786#
00673   053162          22863#
00674   053304          22874   22899#
00675   053426          22908   22933#
00676   053550          22942   22967#
00677   053672          22976   23001#
00700   054014          23010   23035#
00701   054136          23044   23069#
00702   054252          23101#
00703   054366          23133#
00704   054514          23168#
00705   054630          23200#
00706   054754          23208   23234#
00707   055100          23243   23269#
00710   055216          23302#
00711   055334          23335#
00712   055452          23368#
00713   055570          23401#
00714   055736          23416   23452#
00715   056244          23465   23539#
00716   056310          23564#
00717   056436          23621#
00720   056544          23674#
00721   056624          23699#
00722   056704          23724#
00723   056764          23749#
00724   057046          23787#
00725   057162          23825   23830#
00726   057276          23867   23872#
00727   057446          23912   23931#
00730   057620          23983   23992#
00731   057772          24044   24053#
00732   060056          24083#
00733   060156          24116#
00734   060256          24149#
00735   060334          24186#
00736   060412          24224#
00737   060470          24260#
00740   060570          24307#
```

```
00741   060674          24348   24362#
00742   061002          24402   24416#
00743   061120          24442   24457   24471#
00744   061212          24514#
00745   061302          24558#
00746   061366          24582   24602#
00747   061454          24626   24646#
00750   061542          24670   24690#
00751   061630          24713   24733#
00752   061706          24775#
00753   061774          24799   24819#
00754   062052          24861#
00755   062150          24911#
00756   062214          24947#
00757   062260          24984#
00760   062320          25019#
00761   062360          25055#
00762   062424          25093#
00763   062470          25131#
00764   062530          25166#
00765   062570          25201#
00766   062630          25237#
00767   062674          25274#
00770   062734          25309#
00771   063000          25347#
00772   063040          25383#
00773   063100          25418#
00774   063140          25453#
00775   063204          25491#
00776   063250          25529#
00777   063314          25566#
01000   063354          25601#
01001   063414          25636#
01002   063452          25670#
01003   063510          25704#
01004   063554          25740#
01005   063634          25780#
01006   063706          25812   25819#
01007   063770          25866#
01010   064046          25917   25938#
01011   064124          25986   26007#
01012   064202          26059   26080#
01013   064260          26129   26150#
01014   064324          26202   26205   26209#
01015   064370          26254   26257   26261#
PASCNT  066670          26270*  26275   26858   26966#
PC     =%000007          2700*   2905*   5561*   7334*   7369*   8029*  24066*  25735*  26269*  26276*  26282*  26288*  26304*
                        26357*  26369*  26457*  26528*  26659*  26664*  26670*  26675*  26680*  26685*  26691*  26696*  26725*
                        26728*  26742*  26760*  26761*  26804*  26810*  26818*  26832*  26851*  26865*  26866*  26867*  26868*
                        26869*  26874*  26887*  26900*  26914*  26929*  26942*
PDWN    064706           8020   26375#  26389
PFCNT   066672          26285   26287   26377*  26967#
PFMESS  067163          26290   27016#
PFMSG   067440          26394   27047#
PFRET   064524          26297#  26395   26[illegible]  26537
PRIFLG  066674           7682*   7687*  26297   26790*  26968#
```

```
PRINA    066042      7680   26790#
PRINT    066050      8018   26794#
PSW    = 177776      2910#   3291    3319    3355    3386    3501*   3529    3570    3574    3603    3631    37      3745*
                     3783    3784*   3820    3821*   3944    3974    4289*   4318*   4346    7404*   7412    7416*   7450*
                     7455    7459*   7489*   7497    7501*   7508*   7515*   7583*   7591    7595*   7602*   7609*   7639*
                     7644    7647*   8030*   8388    8392*   8428    8432*   9465    8469*   8505    8509*   22243*  22252
                    22297*  22306   22373   22445   22554*  22590*  22606*  22634*  22640   22656*  22685*  22691   22707*
                    22748*  22754*  22781*  22825*  22831*  22858*  22881*  22897*  22915*  22931*  22949*  22965*  22983*
                    22999*  23017*  23033*  23051*  23067*  23083*  23099*  23115*  23131*  23150*  23166*  23182*  23198*
                    23215*  23232*  23250*  23267*  23283*  23300*  23316*  23333*  23349*  23366*  23382*  23399*  23424*
                    23434*  23474*  23495*  23533*  26384*
PUP      064746     26375   26384#
RCSR   = 177560      2945#   7835    7968
RDBR   = 177562      2946#
RESTR    066166     26760   26844#
RETURN   066654      8031*  24868*  26570   26584*  26960#
RSERR    065050      7766   26448#
RSMSG    067520     26454   27056#
RSVFLG   066712      7754*   7760*  26445*  26975#
RSVTST   065042      7751   26445#
R0     =%000000      2898#   3112*   3137*   3140    3166*   3169*   3199*   3202*   3203*   3229*   3232*   3234*   3258*
                     3259*   3262*   3264*   3265*   3291*   3294*   3319*   3322*   3329    3355*   3358*   3386*   3387*
                     3390*   3400*   3401*   3425*   3430*   3437*   3461*   3462*   3466*   3473*   3474*   3529*   3531*
                     3534*   3544*   3545*   3570*   3571*   3658*   3661    3687*   3690    3715*   3718    3744*   3749
                     3756*   3757*   3783*   3788    3795*   3796*   3820*   3825    3832*   3833*   3857*   3858    3861
                     3886*   3890    3915*   3919    3944*   3945*   3949    3974*   3975*   3979    3987*   3988*   4013*
                     4017*   4019    4043*   4044*   4045    4048*   4050    4075*   4078*   4080    4103*   4107*   4109
                     4119*   4120    4131*   4132*   4133*   4134*   4135*   4136*   4181*   4207*   4235*   4260*   4288*
                     4317*   4344*   4378*   4411*   4443*   4480*   4517*   4550*   4586*   4621*   4663*   4664*   4666
                     4697*   4698*   4737*   4738*   4776*   4777*   4814*   4815*   4860*   4861*   4895*   4896*   4929*
                     4930*   4962*   4963*   4996*   4997*   5031*   5032*   5069*   5070*   5106*   5107*   5144*   5145*
                     5182*   5183*   5220*   5221*   5260*   5261*   5302*   5303*   5341*   5342*   5380*   5381*   5413*
                     5414*   5448*   5449*   5483*   5484*   5523*   5524*   5556*   5557*   5586*   5587*   5620*   5621*
                     5654*   5655*   5696*   5697*   5737*   5738*   5772*   5773*   5812*   5813*   5852*   5853*   5885*
                     5886*   5922*   5923*   5965*   5966*   6005*   6006*   6039*   6040*   6072*   6073*   6104*   6105*
                     6138*   6139*   6172*   6173*   6207*   6208*   6247*   6248*   6280*   6281*   6319*   6320*   6354*
                     6355*   6390*   6391*   6442*   6443*   6496*   6497*   6550*   6551*   6604*   6605*   6659*   6660*
                     6702*   6703*   6745*   6746*   6787*   6788*   6829*   6830*   6872*   6873*   6914*   6915*   6957*
                     6958*   7000*   7001*   7041*   7042*   7082*   7083*   7137*   7138*   7189*   7190*   7223*   7224*
                     7257*   7258*   7292*   7293*   7327*   7328*   7363*   7364*   7398*   7399*   7444*   7445*   7482*
                     7483*   7539*   7540*   7576*   7577*   7633*   7634*   7673*   7674*   7712*   7713*   7747*   7748*
                     7788*   7789*   7826*   7827*   7869*   7870*   7905*   7906*   7938*   7939*   7966*   7967*   8051*
                     8085*   8131*   8163*   8190*   8222*   8253*   8287*   8318*   8350*   8381*   8418*   8458*   8495*
                     8535*   8566*   8597*   8630*   8662*   8694*   8726*   8758*   8791*   8824*   8860*   8891*   8923*
                     8956*   8989*   9021*   9054*   9086*   9118*   9151*   9183*   9216*   9247*   9280*   9312*   9345*
                     9378*   9411*   9443*   9475*   9506*   9539*   9571*   9603*   9648*   9683*   9729*   9767*   9841*
                     9876*   9921*   9958*  10008*  10057*  10132*  10178*  10224*  10270*  10316*  10362*  10408*  10454*
                    10500*  10547*  10592*  10637*  10682*  10727*  10772*  10817*  10863*  10909*  10955*  11001*  11047*
                    11092*  11139*  11181*  11229*  11271*  11319*  11361*  11408*  11449*  11495*  11540*  11583*  11625*
                    11669*  11712*  11755*  11798*  11841*  11884*  11926*  11969*  12012*  12056*  12100*  12144*  12187*
                    12230*  12272*  12315*  12358*  12401*  12443*  12486*  12532*  12578*  12622*  12671*  12716*  12760*
                    12804*  12848*  12895*  12939*  12982*  13026*  13070*  13114*  13158*  13202*  13246*  13290*  13333*
                    13377*  13421*  13465*  13508*  13553*  13597*  13642*  13686*  13730*  13774*  13818*  13855*  13897*
                    13933*  13976*  14013*  14055*  14091*  14135*  14179*  14221*  14266*  14309*  14351*  14394*  14430*
                    14467*  14504*  14541*  14587*  14633*  14679*  14725*  14771*  14817*  14863*  14910*  14949*  14988*
                    15027*  15064*  15108*  15153*  15198*  15243*  15289*  15335*  15381*  15429*  15477*  15525*  15573*
```

```
                    15621*  15668*  15713*  15758*  15802*  15846*  15890*  15934*  15981*  16031*  16074*  16117*  16160*
                    16204*  16242*  16279*  16328*  16376*  16425*  16474*  16529*  16584*  16639*  16694*  16750*  16805*
                    16861*  16916*  16971*  17026*  17081*  17136*  17192*  17247*  17303*  17359*  17409*  17459*  17509*
                    17559*  17609*  17662*  17712*  17761*  17764   17769   17798*  17801   17806   17835*  17838   17843
                    17873*  17876   17881   17910*  17913   17918   17949*  17952   17957   17985*  18031*  18078*  18114*
                    18151*  18192*  18235*  18273*  18318*  18364*  18409*  18454*  18493*  18533*  18571*  18609*  18647*
                    18686*  18723*  18767*  18811*  18855*  18900*  18946*  18994*  19039*  19084*  19127*  19172*  19217*
                    19262*  19307*  19352*  19397*  19443*  19489*  19533*  19577*  19621*  19666*  19710*  19754*  19798*
                    19843*  19888*  19932*  19977*  20022*  20068*  20114*  20160*  20207*  20254*  20301*  20350*  20388*
                    20429*  20468*  20507*  20546*  20585*  20624*  20662*  20699*  20736*  20774*  20811*  20852*  20878*
                    20939*  20980*  21033*  21079*  21130*  21171*  21222*  21268*  21314*  21360*  21411*  21460*  21499*
                    21531*  21569*  21622*  21663*  21709*  21754*  21803*  21844*  21893*  21927*  21972*  22009*  22046*
                    22083*  22120*  22178*  22236*  22290*  22344*  22416*  22474*  22501*  22523*  22544*  22579*  22630*
                    22681*  22732*  22809*  22871*  22905*  22939*  22973*  23007*  23041*  23075*  23107*  23139*  23174*
                    23205*  23240*  23275*  23308*  23341*  23374*  23413*  23462*  23549*  23586*  23596   23641*  23650
                    23658   23679*  23687   23704*  23712   23729*  23768*  23777   23793*  23836*  23880*  23937*  23998*
                    24007   24017   24027   24037   24059*  24089*  24122*  24168*  24206*  24243*  24280*  24290   24331*
                    24385*  24438*  24494*  24535*  24580*  24624*  24668*  24711*  24755*  24797*  24841*  24897*  24906
                    24932*  24942   24969*  25005*  25041*  25078*  25116*  25152*  25187*  25223*  25259*  25269   25295*
                    25304   25332*  25369*  25378   25404*  25439*  25476*  25514*  25551*  25587*  25622*  25657*  25691*
                    25725*  25761*  25801*  25842*  25913*  25982*  26055*  26125*  26186*  26238*  26267   26346*  26349
                    26356   26365   26367*  26567*  26576   26674   26749*  26758*  26794   26795*  26798   26802*  26831
                    26845*
R0001   003044       4182#   4187
R0002   003060       4208#   4215
R0003   003076       4236#   4241
R0004   003112       4261#   4268
R0005   003130       4289#   4297
R0006   003152       4318#   4324
R0007   003206       4348#   4358
R0010   003242       4381#   4390
R0011   003300       4414#   4423
R0012   003336       4446#   4454    4460
R0013   003376       4483#   4491    4497
R0014   003440       4520#   4530
R0015   003474       4553#   4563
R0016   003536       4590#   4600
R0017   003604       4625#   4635
R0020   003702       4669#   4678
R0021   003744       4701#   4710    4716
R0022   004016       4741#   4749    4756
R0023   004066       4780#   4788    4794
R0024   004136       4818#   4826    4832    4840
R0025   004222       4865#   4875
R0026   004266       4899#   4909
R0027   004332       4933#   4942
R0030   004374       4966#   4976
R0031   004436       5000#   5011
R0032   004510       5035#   5043    5049
R0033   004560       5073#   5081    5087
R0034   004630       5110#   5118    5124
R0035   004700       5148#   5156    5162
R0036   004750       5186#   5193    5201
R0037   005024       5225#   5232    5240
R0040   005106       5267#   5274    5282
R0041   005160       5306#   5313    5321
```

R0042	005230	5345#	5358			
R0043	005306	5384#	5393			
R0044	005350	5417#	5428			
R0045	005422	5452#	5463			
R0046	005470	5487#	5497	5503		
R0047	005546	5527#	5536			
R0050	005604	5558#	5564			
R0051	005646	5590#	5600			
R0052	005716	5625#	5634			
R0053	005760	5658#	5669	5675		
R0054	006036	5700#	5711	5717		
R0055	006122	5742#	5752			
R0056	006166	5776#	5787	5793		
R0057	006250	5816#	5826	5832		
R0060	006332	5857#	5866			
R0061	006406	5892#	5901			
R0062	006454	5927#	5938	5944		
R0063	006536	5969#	5978	5985		
R0064	006612	6009#	6018			
R0065	006654	6043#	6051			
R0066	006716	6076#	6084			
R0067	006760	6108#	6118			
R0070	007026	6142#	6152			
R0071	007076	6176#	6186			
R0072	007140	6211#	6225			
R0073	007222	6251#	6259			
R0074	007262	6284#	6292	6299		
R0075	007336	6323#	6333			
R0076	007404	6358#	6369			
R0077	007472	6399#	6409	6415	6422	
R0100	007560	6446#	6455	6461	6467	6475
R0101	007662	6500#	6509	6515	6521	6529
R0102	007766	6554#	6563	6569	6575	6583
R0103	010072	6608#	6617	6623	6629	6637
R0104	010200	6664#	6675	6681		
R0105	010270	6707#	6718	6724		
R0106	010360	6750#	6761	6767		
R0107	010450	6792#	6803	6809		
R0110	010540	6834#	6845	6851		
R0111	010626	6877#	6888	6894		
R0112	010714	6919#	6930	6936		
R0113	011004	6962#	6973	6979		
R0114	011070	7004#	7014	7020		
R0115	011146	7045#	7055	7061		
R0116	011222	7086#	7099	7106	7112	
R0117	011322	7141#	7154	7161	7167	
R0120	011430	7194#	7204			
R0121	011502	7228#	7238			
R0122	011554	7262#	7272			
R0123	011626	7297#	7307			
R0124	011666	7330#	7337	7343		
R0125	011730	7366#	7372	7378		
R0126	011772	7401#	7410	7418	7424	
R0127	012066	7447#	7461			
R0130	012146	7485#	7495	7503	7510	7517
R0131	012276	7542#	7554			

R0132	012352	7579#	7589	7597	7604	7611
R0133	012502	7636#	7649			
R0134	012576	7679#	7691			
R0135	012650	7715#	7727			
R0136	012742	7753#				
R0137	013036	7794#				
R0140	013126	7834#	7847			
R0141	013214	7873#	7885			
R0142	013264	7909#	7918			
R0143	013324	7942#	7951			
R0145	013654	8053#	8062			
R0146	013706	8088#	8093	8098	8103	8108
R0147	013752	8134#	8140			
R0150	013776	8166#	8169			
R0151	014020	8193#	8199			
R0152	014044	8225#	8230			
R0153	014066	8256#	8262			
R0154	014112	8290#	8295			
R0155	014134	8321#	8327			
R0156	014160	8353#	8358			
R0157	014202	8384#	8395			
R0160	014242	8421#	8426	8435		
R0161	014306	8461#	8472			
R0162	014344	8498#	8503	8512		
R0163	014406	8538#	8543			
R0164	014430	8569#	8576			
R0165	014456	8600#	8607			
R0166	014504	8633#	8639			
R0167	014530	8665#	8671			
R0170	014554	8697#	8703			
R0171	014600	8729#	8735			
R0172	014624	8761#	8768			
R0173	014652	8794#	8801			
R0174	014712	8830#	8837			
R0175	014740	8863#	8870			
R0176	014766	8894#	8899			
R0177	015010	8926#	8933			
R0200	015036	8959#	8966			
R0201	015064	8992#	8999			
R0202	015112	9024#	9030			
R0203	015136	9057#	9063			
R0204	015162	9089#	9095			
R0205	015206	9121#	9127			
R0206	015232	9154#	9160			
R0207	015256	9186#	9193			
R0210	015304	9219#	9224			
R0211	015326	9250#	9257			
R0212	015354	9283#	9290			
R0213	015402	9315#	9322			
R0214	015430	9348#	9354			
R0215	015454	9381#	9387			
R0216	015500	9414#	9420			
R0217	015524	9446#	9452			
R0220	015550	9478#	9483			
R0221	015572	9509#	9516			
R0222	015620	9542#	9548			

R0223	015644	9574#	9580		
R0224	015676	9607#	9619	9625	
R0225	015754	9653#	9660		
R0226	016014	9688#	9699	9706	
R0227	016072	9734#	9742		
R0231	016270	9846#	9853		
R0232	016330	9881#	9892	9898	
R0233	016404	9926#	9934		
R0234	016456	9966#	9978	9984	
R0235	016536	10013#	10025	10031	
R0237	016760	10137#	10149	10155	
R0240	017036	10183#	10195	10201	
R0241	017114	10229#	10241	10247	
R0242	017174	10275#	10287	10293	
R0243	017254	10321#	10333	10339	
R0244	017330	10367#	10379	10385	
R0245	017406	10413#	10425	10431	
R0246	017466	10459#	10471	10477	
R0247	017546	10505#	10517	10523	
R0250	017624	10551#	10563	10569	
R0251	017702	10596#	10608	10614	
R0252	017762	10641#	10653	10659	
R0253	020040	10686#	10698	10704	
R0254	020120	10731#	10743	10749	
R0255	020200	10776#	10788	10794	
R0256	020260	10821#	10833	10840	
R0257	020340	10867#	10879	10886	
R0260	020422	10913#	10925	10932	
R0261	020502	10959#	10971	10978	
R0262	020564	11005#	11017	11024	
R0263	020646	11051#	11063	11070	
R0264	020730	11096#	11105	11111	11118
R0265	021016	11143#	11153	11160	
R0266	021100	11186#	11195	11201	11208
R0267	021172	11234#	11243	11250	
R0270	021252	11276#	11285	11291	11298
R0271	021344	11324#	11333	11340	
R0272	021420	11365#	11374	11380	11387
R0273	021506	11412#	11421	11428	
R0274	021572	11456#	11468	11474	
R0275	021650	11500#	11512	11518	
R0276	021724	11544#	11556	11561	
R0277	022002	11587#	11598	11603	
R0300	022060	11629#	11641	11646	
R0301	022136	11673#	11685	11690	
R0302	022214	11716#	11728	11733	
R0303	022274	11759#	11771	11776	
R0304	022352	11802#	11814	11819	
R0305	022432	11845#	11857	11862	
R0306	022512	11888#	11899	11904	
R0307	022564	11930#	11942	11947	
R0310	022644	11973#	11985	11990	
R0311	022722	12016#	12028	12033	
R0312	023000	12060#	12072	12077	
R0313	023060	12104#	12116	12121	
R0314	023136	12148#	12160	12165	

R0315	023214	12191#	12203	12208	
R0316	023272	12234#	12246	12251	
R0317	023352	12276#	12288	12293	
R0320	023430	12319#	12331	12336	
R0321	023510	12362#	12374	12379	
R0322	023570	12405#	12417	12422	
R0323	023650	12447#	12459	12464	
R0324	023724	12490#	12502	12509	
R0325	024004	12537#	12549	12556	
R0326	024064	12582#	12594	12600	
R0327	024144	12626#	12637	12642	12649
R0330	024236	12675#	12687	12693	
R0331	024316	12720#	12732	12738	
R0332	024376	12764#	12776	12782	
R0333	024460	12808#	12820	12826	
R0334	024552	12855#	12867	12873	
R0335	024634	12899#	12911	12917	
R0336	024716	12943#	12954	12960	
R0337	024772	12986#	12998	13004	
R0340	025054	13030#	13042	13048	
R0341	025134	13074#	13086	13092	
R0342	025214	13118#	13130	13136	
R0343	025276	13162#	13174	13180	
R0344	025356	13206#	13218	13224	
R0345	025436	13250#	13262	13268	
R0346	025516	13294#	13306	13312	
R0347	025600	13337#	13349	13355	
R0350	025660	13381#	13393	13399	
R0351	025742	13425#	13437	13443	
R0352	026024	13469#	13481	13487	
R0353	026106	13512#	13524	13530	
R0354	026166	13557#	13569	13575	
R0355	026246	13601#	13613	13619	
R0356	026326	13646#	13658	13664	
R0357	026406	13690#	13702	13708	
R0360	026466	13734#	13746	13752	
R0361	026552	13779#	13789	13796	
R0362	026636	13823#	13834		
R0363	026704	13859#	13869	13876	
R0364	026764	13901#	13912		
R0365	027036	13938#	13948	13955	
R0366	027122	13981#	13992		
R0367	027170	14017#	14027	14034	
R0370	027250	14059#	14070		
R0371	027320	14096#	14108	14114	
R0372	027404	14140#	14152	14158	
R0373	027464	14183#	14193	14199	
R0374	027554	14228#	14238	14244	
R0375	027632	14270#	14281	14287	
R0376	027716	14313#	14323	14329	
R0377	027774	14355#	14366	14372	
R0400	030060	14398#	14408		
R0401	030126	14434#	14445		
R0402	030200	14471#	14482		
R0403	030246	14508#	14519		
R0404	030314	14545#	14558	14565	

R0405	030406	14591#	14604	14611	
R0406	030500	14637#	14650	14657	
R0407	030574	14683#	14696	14703	
R0410	030670	14729#	14742	14749	
R0411	030762	14775#	14788	14795	
R0412	031054	14821#	14834	14841	
R0413	031150	14867#	14880	14887	
R0414	031244	14914#	14926		
R0415	031320	14953#	14965		
R0416	031374	14992#	15004		
R0417	031446	15031#	15043		
R0420	031516	15068#	15080	15086	
R0421	031576	15113#	15125	15131	
R0422	031660	15158#	15170	15176	
R0423	031744	15203#	15215	1522.	
R0424	032024	15248#	15260	15267	
R0425	032106	15294#	15306	15313	
R0426	032174	15340#	15352	15359	
R0427	032262	15386#	15398	15405	
R0430	032342	15434#	15447	15453	
R0431	032422	15482#	15495	15501	
R0432	032504	15530#	15543	15549	
R0433	032570	15578#	15591	15597	
R0434	032654	15626#	15639	15645	
R0435	032744	15673#	15685	15692	
R0436	033026	15718#	15730	15737	
R0437	033114	15763#	15774	15781	
R0440	033200	15807#	15819	15825	
R0441	033260	15851#	15863	15869	
R0442	033342	15895#	15907	15913	
R0443	033430	15939#	15952	15959	
R0444	033534	15989#	16003	16010	
R0445	033624	16035#	16046	16052	
R0446	033704	16078#	16089	16095	
R0447	033766	16121#	16132	16138	
R0450	034046	16164#	16175	16181	
R0451	034130	16208#	16219		
R0452	034202	16246#	16257		
R0453	034260	16285#	16298	16306	
R0454	034350	16334#	16347	16355	
R0455	034436	16381#	16395	16403	
R0456	034526	16430#	16444	16452	
R0457	034620	16480#	16493	16499	16507
R0460	034722	16535#	16548	16554	16562
R0461	035022	16589#	16603	16609	16617
R0462	035124	16644#	16658	16664	16672
R0463	035230	16700#	16713	16719	16727
R0464	035334	16756#	16769	16775	16783
R0465	035436	16810#	16824	16830	16838
R0466	035542	16866#	16880	16886	16894
R0467	035650	16922#	16935	16941	16949
R0470	035752	16977#	16990	16996	17004
R0471	036052	17031#	17045	17051	17059
R0472	036154	17086#	17100	17106	17114
R0473	036260	17142#	17155	17161	17169
R0474	036364	17198#	17211	17217	17225

R0475	036466	17252#	17266	17272	17280
R0476	036572	17308#	17322	17328	17336
R0477	036700	17365#	17378	17386	
R0500	036774	17415#	17428	17436	
R0501	037066	17464#	17478	17486	
R0502	037162	17514#	17528	17536	
R0503	037260	17565#	17578	17586	
R0504	037366	17618#	17631	17639	
R0505	037460	17667#	17681	17689	
R0506	037554	17717#	17731	17739	
R0507	037644	17765#	17776		
R0510	037706	17802#	17813		
R0511	037750	17839#	17850		
R0512	040014	17877#	17888		
R0513	040060	17914#	17925		
R0514	040130	17954#	17964		
R0515	040200	17990#	18002	18008	
R0516	040260	18036#	18049	18055	
R0517	040342	18083#	18093		
R0520	040410	18119#	18128		
R0521	040452	18155#	18165	18171	
R0522	040526	18196#	18206	18212	
R0523	040612	18240#	18250		
R0524	040660	18278#	18289	18295	
R0525	040742	18323#	18333	18340	
R0526	041026	18369#	18379	18386	
R0527	041110	18414#	18424	18431	
R0530	041174	18459#	18470		
R0531	041250	18498#	18509		
R0532	041324	18538#	18549		
R0533	041374	18576#	18587		
R0534	041444	18614#	18625		
R0535	041516	18652#	18663		
R0536	041570	18691#	18702		
R0537	041644	18728#	18740	18746	
R0540	041724	18772#	18784	18790	
R0541	042006	18816#	18828	18834	
R0542	042066	18860#	18872	18876	
R0543	042150	18905#	18917	18924	
R0544	042250	18954#	18966	18972	
R0545	042330	18999#	19011	19017	
R0546	042414	19044#	19056	19062	
R0547	042476	19089#	19100	19106	
R0550	042560	19132#	19144	19151	
R0551	042642	19177#	19189	19196	
R0552	042726	19222#	19234	19241	
R0553	043010	19267#	19279	19286	
R0554	043074	19312#	19324	19331	
R0555	043162	19357#	19369	19376	
R0556	043250	19402#	19414	19421	
R0557	043334	19448#	19460	19467	
R0560	043422	19494#	19505	19512	
R0561	043506	19538#	19550	19556	
R0562	043570	19582#	19594	19600	
R0563	043652	19626#	19639	19645	
R0564	043740	19671#	19683	19689	

```
R0565   044022          19715#  19727   19733
R0566   044104          19759#  19771   19777
R0567   044166          19803#  19815   19821
R0570   044250          19848#  19860   19866
R0571   044232          19893#  19905   19911
R0572   044420          19937#  19949   19956
R0573   044506          19982#  19994   20001
R0574   044574          20027#  20040   20047
R0575   044666          20073#  20086   20093
R0576   044760          20119#  20132   20139
R0577   045052          20165#  20178   20185
R0600   045144          20212#  20225   20232
R0601   045234          20259#  20272   20279
R0602   045326          20306#  20318   20325
R0603   045412          20354#  20364
R0604   045470          20395#  20406
R0605   045536          20433#  20445
R0606   045606          20472#  20484
R0607   045660          20511#  20523
R0610   045732          20550#  20562
R0611   046004          20589#  20601
R0612   046060          20628#  20640
R0613   046134          20666#  20677
R0614   046204          20704#  20715
R0615   046252          20740#  20751
R0616   046316          20778#  20790
R0617   046360          20814#  20820   20829
R0620   046424          20855#  20861   20870
R0621   046470          20895#  20901   20910   20916
R0622   046546          20942#  20948   20957
R0623   046612          20983#  20989   20998   21004   21008
R0624   046700          21036#  21042   21051   21056
R0625   046754          21081#  21087   21092   21101   21107
R0626   047042          21133#  21139   21148
R0627   047106          21174#  21180   21189   21195   21199
R0630   047174          21225#  21231   21240   21245
R0631   047250          21271#  21277   21286   21290
R0632   047324          21317#  21323   21332   21336
R0633   047400          21363#  21369   21373   21382   21388
R0634   047464          21414#  21420   21424   21433   21439
R0635   047552          21463#  21469   21477
R0636   047620          21502#  21510   21516   21522
R0637   047706          21548#  21554   21562
R0640   047754          21586#  21592   21599
R0641   050022          21625#  21632   21640
R0642   050072          21666#  21673   21681   21686
R0643   050152          21712#  21719   21723   21731
R0644   050242          21760#  21767   21775   21780
R0645   050322          21806#  21813   21822
R0646   050374          21847#  21855   21863   21868
R0647   050454          21896#  21900
R0650   050506          21930#  21948   21951
R0651   050566          21975#  21986
R0652   050624          22012#  22023
R0653   050662          22049#  22060
R0654   050720          22086#  22097
```

R0655	050760	22123#	22132	22141	22147	22155	
R0656	051066	22181#	22190	22199	22205	22213	
R0657	051174	22239#	22249	22259	22267		
R0660	051276	22293#	22303	22313	22321		
R0661	051406	22348#	22356	22364	22376	22383	22393
R0662	051544	22420#	22428	22436	22448	22455	22465
R0663	051710	22480#	22490				
R0664	052000	22507#	22515				
R0665	052044	22529#	22537				
R0666	052114	22551#	22564				
R0667	052226	22585#	22600				
R0670	052346	22634#	22646	22654			
R0671	052462	22685#	22697	22705			
R0672	052572	22736#	22757	22765	22774	22778	
R0673	052776	22813#	22834	22842	22851	22855	
R0674	053224	22879#	22891				
R0675	053346	22913#	22925				
R0676	053470	22947#	22959				
R0677	053612	22981#	22993				
R0700	053734	23015#	23027				
R0701	054056	23049#	23061				
R0702	054172	23081#	23093				
R0703	054306	23113#	23125				
R0704	054434	23148#	23160				
R0705	054550	23180#	23192				
R0706	054672	23213#	23226				
R0707	055016	23248#	23261				
R0710	055134	23281#	23294				
R0711	055252	23314#	23327				
R0712	055370	23347#	23360				
R0713	055506	23380#	23393				
R0714	055632	23421#	23441	23446			
R0715	056020	23473#	23504	23511	23518	23524	23530
R0716	056266	23553#	23559				
R0717	056324	23589#	23601	23609	23616		
R0720	056456	23645#	23655	23663	23670		
R0721	056564	23683#	23694				
R0722	056644	23708#	23719				
R0723	056724	23733#	23744				
R0724	057000	23771#	23781				
R0732	060014	24063#	24070	24079			
R0733	060112	24095#	24102	24111			
R0734	060212	24128#	24135	24144			
R0735	060272	24171#	24181				
R0736	060350	24209#	24219				
R0737	060426	24246#	24256				
R0740	060504	24283#	24293	24301			
R0741	060604	24334#	24347	24358			
R0742	060710	24388#	24401	24412			
R0743	061026	24443#	24456	24467			
R0744	061162	24499#	24507	24511			
R0745	061252	24543#	24551	24555			
R0746	061336	24587#	24595	24599			
R0747	061424	24631#	24639	24643			
R0750	061512	24675#	24683	24687			
R0751	061600	24718#	24726	24730			

R0752	061656	24760#	24768	24772
R0753	061744	24804#	24812	24816
R0754	062022	24846#	24854	24858
R0755	062124	24900#	24909	
R0756	062164	24935#	24945	
R0757	062230	24972#	24982	
R0760	062274	25008#	25017	
R0761	062334	25044#	25053	
R0762	062374	25081#	25091	
R0763	062440	25119#	25129	
R0764	062504	25155#	25164	
R0765	062544	25190#	25199	
R0766	062604	25226#	25235	
R0767	062650	25263#	25272	
R0770	062710	25298#	25307	
R0771	062754	25336#	25345	
R0772	063014	25372#	25381	
R0773	063054	25407#	25416	
R0774	063114	25442#	25451	
R0775	063160	25480#	25489	
R0776	063224	25518#	25527	
R0777	063270	25555#	25564	

R1	=%000001	2899#	3426*	3427*	3430	3463*	3466	3530*	3534	3746*	3749	3785*	3788	3822*
		3825	3858*	3861	3887*	3890	3916*	3919	3946*	3949*	3951	3976*	3979*	3981
		4014*	4017	4045*	4048	4074*	4078	4104*	4107	4120*	4121*	4122	4131	4157*
		4158*	4159	4639*	4641*	4642	7749*	7790*	7874*	7880*	7976*	7980*	8052*	8086*
		8132*	8164*	8191*	8223*	8254*	8288*	8319*	8351*	8382*	8419*	8459*	8496*	8536*
		8567*	8598*	8631*	8663*	8695*	8727*	8759*	8792*	8825*	8861*	8892*	8924*	8957*
		8990*	9022*	9055*	9087*	9119*	9152*	9184*	9217*	9248*	9281*	9313*	9346*	9379*
		9412*	9444*	9476*	9507*	9540*	9572*	9604*	9649*	9684*	9730*	9768*	9793*	9842*
		9877*	9922*	9959*	10009*	10058*	10082*	10133*	10179*	10225*	10271*	10317*	10363*	10409*
		10455*	10501*	10548*	10593*	10638*	10683*	10728*	10773*	10818*	10864*	10910*	10956*	11002*
		11048*	11093*	11140*	11182*	11230*	11272*	11320*	11362*	11409*	11450*	11496*	11541*	11584*
		11626*	11670*	11713*	11756*	11799*	11842*	11885*	11927*	11970*	12013*	12057*	12101*	12145*
		12188*	12231*	12273*	12316*	12359*	12402*	12444*	12487*	12533*	12579*	12623*	12672*	12717*
		12761*	12805*	12849*	12896*	12940*	12983*	13027*	13071*	13115*	13159*	13203*	13247*	13291*
		13334*	13378*	13422*	13466*	13509*	13554*	13598*	13643*	13687*	13731*	13775*	13819*	13856*
		13898*	13934*	13977*	14014*	14056*	14092*	14136*	14180*	14222*	14267*	14310*	14352*	14395*
		14431*	14468*	14505*	14542*	14588*	14634*	14680*	14726*	14772*	14818*	14864*	14911*	14950*
		14989*	15028*	15065*	15109*	15154*	15199*	15244*	15290*	15336*	15382*	15430*	15478*	15526*
		15574*	15622*	15669*	15714*	15759*	15803*	15847*	15891*	15935*	15982*	16032*	16075*	16118*
		16161*	16205*	16243*	16280*	16329*	16377*	16426*	16475*	16530*	16585*	16640*	16695*	16751*
		16806*	16862*	16917*	16972*	17027*	17082*	17137*	17193*	17248*	17304*	17360*	17410*	17460*
		17510*	17560*	17610*	17663*	17713*	17762*	17799*	17836*	17874*	17911*	17950*	17986*	18032*
		18079*	18115*	18152*	18193*	18236*	18274*	18319*	18365*	18410*	18455*	18494*	18534*	18572*
		18610*	18648*	18687*	18724*	18768*	18812*	18856*	18901*	18947*	18995*	19040*	19085*	19128*
		19173*	19218*	19263*	19308*	19353*	19398*	19444*	19490*	19534*	19578*	19622*	19667*	19711*
		19755*	19799*	19844*	19889*	19933*	19978*	20023*	20069*	20115*	20161*	20208*	20255*	20302*
		20351*	20389*	20430*	20469*	20508*	20547*	20586*	20625*	20663*	20700*	20737*	20775*	20812*
		20853*	20893*	20940*	20981*	21034*	21080*	21131*	21172*	21223*	21269*	21315*	21361*	21412*
		21461*	21500*	21546*	21584*	21623*	21664*	21710*	21755*	21804*	21845*	21894*	21928*	21973*
		22010*	22047*	22084*	22121*	22179*	22237*	22291*	22345*	22417*	22475*	22502*	22524*	22545*
		22580*	22631*	22682*	22733*	22810*	22872*	22906*	22940*	22974*	23008*	23042*	23076*	23108*
		23140*	23175*	23206*	23241*	23276*	23309*	23342*	23375*	23414*	23463*	23550*	23587*	23642*
		23680*	23705*	23730*	23769*	23798*	23807*	23816*	23841*	23850*	23858*	23885*	23894*	23903*
		23942*	23952*	23962*	23972*	24003*	24013*	24023*	24033*	24062*	24091*	24123*	24169*	24207*

		24244*	24281*	24332*	24386*	24439*	24498*	24500	24509*	24510	24542*	24544	24553*	24554
		24586*	24588	24597*	24598	24630*	24632	24641*	24642	24674*	24676	24685*	24686	24717*
		24719	24728*	24729	24759*	24761	24770*	24771	24803*	24805	24814*	24815	24845*	24847
		24856*	24857	24898*	24933*	24970*	25006*	25042*	25079*	25117*	25153*	25188*	25224*	25260*
		25296*	25333*	25370*	25405*	25440*	25477*	25515*	25552*	25588*	25623*	25658*	25692*	25726*
		25762*	25802*	25843*	25918*	25922	25987*	25991	26060*	26064	26130*	26134	26187*	26193
		26204*	26239*	26245	26258*	26297*	26298*	26299	26347*	26365	26679	26746*	26753*	26755*
		26830	26846*	26918*	26920									
R1000	063330	25590#	25599											
R1001	063370	25625#	25634											
R1002	063430	25660#	25668											
R1003	063466	25694#	25702											
R1004	063524	25728#	25738											
R1005	063602	25767#	25778											
R1006	063650	25804#	25811											
R1007	063722	25845#	25862											
R1010	064042	25930	25935#											
R1011	064120	25999	26004#											
R1012	064176	26072	26077#											
R1013	064254	26142	26147#											
R1014	064274	26190#	26200	26207										
R1015	064340	26242#	26252	26259										
R10230	016130	9772#	9784	9790										
R10236	016616	10062#	10074	10080										
R10725	057066	23797#	23804											
R10726	057202	23840#	23847											
R10727	057316	23884#	23891											
R10730	057470	23942#	23950											
R10731	057642	24003#	24011											
R2	=%000002	2900#	4122*	4123*	4124	4132	4345*	4379*	4384	4388	4412*	4417	4421	4445*
		4482*	4518*	4520*	4523*	4525	4528	4551*	4553*	4556*	4558	4561	4588*	4590*
		4595	4598	4623*	4625*	4630	4633	4640*	4642	4667*	4669*	4699*	4701*	4711
		4714	4739*	4741*	4751	4754	4778*	4780*	4783	4790	4816*	4828	4834	4837
		4839*	4862*	4865*	4870	4873	4897*	4899*	4904	4907	4931*	4965*	4966*	4971
		4974	4998*	5001*	5006	5009	5034*	5072*	5108*	5146*	5184*	5188	5195	5198
		5200*	5222*	5234	5237	5239*	5265*	5276	5279	5281*	5304*	5315	5318	5320*
		5355*	5356*	5382*	5415*	5418*	5423	5426	5450*	5452	5458	5461	5486*	5525*
		5527*	5531	5534	5589*	5590*	5593*	5595	5598	5623*	5656*	5659*	5664	5667
		5671	5699*	5701*	5706	5709	5713	5739*	5742*	5747	5750	5774*	5777*	5782
		5785	5814*	5854*	5889*	5925*	5928*	5933	5936	5967*	5970*	5980	5983	6007*
		6010*	6042*	6043*	6075*	6076*	6106*	6108*	6113	6116	6140*	6142*	6147	6150
		6175*	6218*	6219	6220	6223	6249*	6251*	6282*	6284*	6294	6297	6321*	6323*
		6326*	6328	6331	6357*	6359*	6364	6367	6397*	6398	6407	6417	6420	6445*
		6447	6469	6472	6474*	6499*	6523	6526	6528*	6553*	6577	6580	6582*	6607*
		6609	6631	6634	6636*	6661*	6665*	6670	6673	6704*	6708*	6713	6716	6747*
		6751*	6756	6759	6789*	6793*	6798	6801	6831*	6834	6840	6843	6874*	6877
		6883	6886	6916*	6920*	6925	6928	6959*	6963*	6968	6971	7002*	7043*	7089*
		7101	7104	7108	7144*	7156	7159	7163	7191*	7194*	7199	7202	7225*	7228*
		7233	7236	7259*	7262*	7267	7270	7294*	7297*	7302	7305	7412*	7413	7416
		7455*	7456	7459	7497*	7498	7501	7508	7515	7591*	7592	7595	7602	7609
		7644*	7647	7835*	7838	7839	7840	7841	7845	7871*	7873*	7877	7883	7907*
		7909*	7912	7916	7940*	7942*	7945	7949	7968*	7969	7970	7974*	7977*	7978
		7986	7990*	8388*	8389	8392	8428*	8429	8432	8465*	8466	8469	8505*	8506
		8509	9606*	9652*	9733*	9770*	9772*	9776*	9786	9792*	9794*	9798*	9814	9845*
		9846*	9849*	9880*	9881*	9884*	9894	9925*	9926*	9930*	9965*	10012*	10061*	10062*
		10066*	10076	10083*	10084*	10088*	10104	10136*	10137*	10141*	10151	10181*	10227*	10273*

10319*	10365*	10367*	10371*	10381	10411*	10413*	10427	10457*	10459*	10463*	10473	10503*
10505*	10509*	10519	10549*	10594*	10639*	10684*	10729*	10774*	10819*	10821*	10825*	10835
10838	10865*	10867*	10871*	10881	10884	10911*	10913*	10917*	10927	10930	10957*	10959*
10963*	10973	10976	11003*	11005*	11009*	11019	11022	11049*	11051*	11055*	11065	11068
11094*	11096	11097*	11113	11116	11141*	11143	11144*	11155	11158	11183*	11186	11231*
11234	11273*	11276	11321*	11324	11363*	11365	11366*	11382	11395	11410*	11412	11413*
11423	11426	11454*	11497*	11542*	11585*	11627*	11671*	11714*	11757*	11800*	11843*	11886*
11928*	11971*	12014*	12058*	12102*	12146*	12189*	12232*	12274*	12317*	12360*	12403*	12445*
12488*	12490*	12494	12504	12507	12534*	12537*	12541	12551	12554	12580*	12582*	12586*
12595	12598	12624*	12626*	12629*	12638	12644	12647	12673*	12675*	12679*	12688	12691
12718*	12720*	12724*	12733	12736	12762*	12764*	12768*	12777	12780	12806*	12808*	12812*
12821	12824	12853*	12855*	12859*	12868	12871	12897*	12899*	12903*	12912	12915	12941*
12943*	12946*	12955	12958	12984*	12986*	12990*	12999	13002	13028*	13030*	13034*	13043
13046	13072*	13074*	13078*	13087	13090	13116*	13118*	13122*	13131	13134	13160*	13162*
13166*	13175	13178	13204*	13206*	13210*	13219	13222	13248*	13250*	13254*	13263	13266
13292*	13294*	13298*	13307	13310	13335*	13337*	13341*	13350	13353	13379*	13381*	13385*
13394	13397	13423*	13425*	13429*	13438	13441	13467*	13469*	13473*	13482	13485	13510*
13512*	13516*	13525	13528	13555*	13599*	13644*	13688*	13732*	13776*	13779	13820*	13823
13857*	13859	13860*	13871	13874	13899*	13901	13902*	13907	13910	13935*	13938	13978*
13981	14015*	14017	14018*	14029	14032	14057*	14059	14060*	14065	14068	14093*	14137*
14181*	14226*	14268*	14311*	14353*	14432*	14469*	14472*	14475*	14477	14480	14506*	14509*
14512*	14514	14517	14543*	14546	14547*	14552	14556	14589*	14592	14593*	14598	14602
14635*	14639*	14644	14648	14681*	14685*	14690	14694	14727*	14731*	14736	14740	14745
14773*	14777*	14782	14786	14791	14819*	14823*	14828	14832	14865*	14869*	14874	14878
14912*	14916*	14921	14924	14951*	14955*	14960	14963	14990*	14994*	14999	15002	15029*
15033*	15038	15041	15067*	15112*	15156*	15201*	15247*	15248*	15252*	15262	15265	15293*
15294*	15298*	15306	15311	15339*	15340*	15344*	15354	15357	15385*	15386*	15390*	15400
15403	15432*	15480*	15528*	15576*	15624*	15670*	15673*	15677*	15687	15690	15715*	15718*
15722*	15732	15735	15760*	15763*	15766*	15776	15779	15804*	15848*	15892*	15936*	15940*
15944*	15954	15957	15986*	15990*	15991	16005	16008	16033*	16035	16036*	16041	16044
16076*	16079*	16084	16087	16119*	16122*	16127	16130	16134	16162*	16165*	16170	16173
16206*	16209*	16214	16217	16244*	16247*	16252	16255	16283*	16285	16286*	16300	16304
16332*	16334	16335*	16349	16353	16379*	16381	16382*	16383*	16397	16401	16428*	16430
16431*	16432*	16446	16450	16478*	16480	16481*	16501	16505	16532*	16535	16536*	16556
16560	16587*	16589	16590*	16591*	16611	16615	16642*	16644	16645*	16646*	16666	16670
16698*	16701*	16721	16725	16754*	16757*	16777	16781	16808*	16811*	16812*	16832	16836
16864*	16867*	16868*	16888	16892	16920*	16923*	16937	16943	16947	16975*	16978*	16992
16998	17002	17029*	17032*	17033*	17047	17053	17057	17084*	17087*	17088*	17102	17108
17112	17140*	17143*	17163	17167	17196*	17199*	17219	17223	17250*	17253*	17254*	17274
17278	17306*	17309*	17310*	17330	17334	17363*	17366*	17380	17384	17413*	17416*	17430
17434	17462*	17465*	17466*	17480	17484	17512*	17515*	17516*	17530	17534	17563*	17566*
17580	17584	17616*	17619*	17633	17637	17665*	17668*	17669*	17683	17687	17715*	17718*
17719*	17733	17737	17763*	17765	17766*	17771	17774	17800*	17802	17803*	17808	17811
17837*	17840*	17845	17848	17875*	17878*	17883	17886	17912*	17915*	17920	17923	17951*
17954*	17959	17962	17987*	18033*	18080*	18116*	18153*	18194*	18237*	18240*	18243*	18245
18248	18275*	18278*	18279	18284	18287	18320*	18323*	18335	18338	18366*	18369*	18375
18381	18384	18411*	18414*	18426	18429	18456*	18459*	18465	18468	18495*	18498*	18504
18507	18535*	18538	18539*	18544	18547	18573*	18576	18577*	18582	18585	18611*	18615*
18620	18623	18649*	18653*	18658	18661	18688*	18692*	18697	18700	18725*	18769*	18813*
18857*	18902*	18922	18951*	18996*	19041*	19086*	19129*	19132*	19136*	19146	19149	19174*
19177*	19181*	19191	19194	19219*	19222*	19226*	19236	19239	19264*	19267*	19271*	19281
19284	19309*	19312*	19316	19326	19329	19354*	19357*	19361	19371	19374	19399*	19402*
19406	19416	19419	19445*	19448*	19452	19462	19465	19491*	19494*	19497	19507	19510
19535*	19579*	19623*	19668*	19712*	19756*	19800*	19845*	19890*	19934*	19937*	19941*	19951
19954	19979*	19982*	19986*	19996	19999	20024*	20028*	20032*	20042	20045	20070*	20074*
20078*	20088	20091	20116*	20120*	20124	20134	20137	20162*	20166*	20170	20180	20183

		20209*	20213*	20217	20227	20230	20256*	20260*	20264	20274	20277	20303*	20307*	20310
		20320	20323	20352*	20393*	20396*	20399*	20401	20404	20431*	20434*	20435	20440	20443
		20470*	20473*	20479	20482	20509*	20513*	20518	20521	20548*	20552*	20557	20560	20587*
		20591*	20596	20599	20626*	20630*	20635	20638	20664*	20666	20667*	20672	20675	20701*
		20705*	20710	20713	20738*	20740	20741*	20746	20749	20776*	20780*	20785	20788	20814*
		20817	20855*	20858	20895*	20898	20912	20942*	20945	20983*	20996	21000	21036*	21039
		21081*	21084	21103	21133*	21136	21174*	21177	21191	21225*	21228	21271*	21274	21317*
		21320	21363*	21366	21414*	21417	21463*	21466	21502*	21507	21548*	21551	21586*	21589
		21626*	21629	21667*	21670	21713*	21716	21761*	21764	21807*	21810	21848*	21851	21896*
		21904*	21930*	21938*	21944	21975*	21978*	22012*	22015*	22049*	22052*	22086*	22089*	22373*
		22380*	22390*	22445*	22452*	22462*	22479*	22484	22505*	22509	22513	22527*	22531	22535
		22549*	22557*	22559	22562	22569*	22584*	22589*	22593*	22598*	22602*	22633*	22635*	22641
		22644*	22657*	22684*	22686*	22692	22695*	22708*	22735*	22739*	22742	22750*	22755*	22760*
		22782*	22812*	22816*	22819	22827*	22832*	22837*	22859*	22876*	22884*	22889*	22893*	22910*
		22918*	22923*	22927*	22944*	22952*	22957*	22961*	22978*	22986*	22991*	22995*	23012*	23020*
		23025*	23029*	23046*	23054*	23059*	23063*	23078*	23086*	23091*	23095*	23110*	23118*	23123*
		23127*	23145*	23153*	23158*	23162*	23177*	23185*	23190*	23194*	23210*	23218*	23224*	23228*
		23245*	23253*	23259*	23263*	23278*	23286*	23292*	23296*	23311*	23319*	23325*	23329*	23344*
		23352*	23358*	23362*	23377*	23385*	23391*	23395*	23417*	23425*	23426*	23427	23437*	23444*
		23466*	23486*	23487*	23488	23499*	23516*	23521*	23527*	23644*	23658	23774*	23777*	23794*
		23797	23815	23837*	23840	23857	23881*	23884	23902	23940*	23943	23953	23963	23973
		24001*	24004	24014	24024	24034	24174*	24177	24212*	24215	24248*	24252	24936*	24942*
		24973*	24979*	25014*	25050*	25088*	25126*	25161*	25262*	25269*	25554*	25561	25928*	25997*
		26070*	26140*	26188*	26190	26206*	26240*	26242	26256*	26275*	26281*	26287*	26302*	26304
		26356*	26455*	26456	26527*	26643	26644*	26645	26646	26663*	26668*	26669	26674*	26679*
		26684*	26686	26690*	26695*	26699*	26746	26747*	26751*	26829	26847*	26904*	26905*	26919*
		26920*												
R20230	016166	9787	9792#	9806	9812	9818								
R20236	016654	10077	10082#	10096	10102	10108								
R20725	057104	23806#	23813											
R20726	057220	23849#	23856											
R20727	057334	23893#	23900											
R20730	057510	23952#	23960											
R20731	057662	24013#	24021											
R3	=%000003	2901#	4124*	4125*	4126	4133	4349*	4352*	4354	4388*	4421*	4446*	4449	4456
		4483*	4486	4493	4528*	4561*	4598*	4633*	4665*	4666*	4714*	4754*	4837*	4873*
		4907*	4933*	4936*	4938	4974*	5009*	5035*	5038*	5045	5073*	5076*	5083	5110*
		5113*	5120	5148*	5151*	5158	5198*	5224*	5227	5237*	5279*	5318*	5354*	5384*
		5387*	5389	5417*	5421*	5426*	5452*	5453*	5456*	5461*	5488*	5491*	5493	5534*
		5598*	5625*	5628*	5630	5667*	5709*	5750*	5785*	5817*	5820*	5822	5857*	5860*
		5862	5892*	5895*	5897	5936*	5983*	6116*	6150*	6176*	6177*	6180*	6182	6223*
		6297*	6331*	6367*	6407*	6420*	6447*	6450	6457	6472*	6501*	6504	6511	6526*
		6555*	6558	6565	6580*	6609*	6612	6619	6634*	6662*	6668*	6673*	6705*	6711*
		6716*	6748*	6754*	6759*	6790*	6796*	6801*	6834*	6835*	6838*	6843*	6847	6877*
		6878*	6881*	6886*	6890	6919*	6923*	6928*	6932	6962*	6966*	6971*	6975	7005*
		7008*	7010	7046*	7049*	7051	7087*	7093	7095	7104*	7142*	7148	7150	7159*
		7202*	7236*	7270*	7305*	7883*	7916*	7949*	7971*	7986*	7992*	7995	8001*	8003*
		9607*	9611*	9621	9653*	9656*	9687*	9688*	9691*	9701	9734*	9738*	9966*	9970*
		9980	10013*	10017*	10027	10183*	10187*	10197	10229*	10233*	10243	10275*	10279*	10289
		10321*	10325*	10335	10551*	10555*	10565	10596*	10600*	10610	10641*	10645*	10655	10686*
		10690*	10700	10731*	10735*	10745	10776*	10780*	10790	10838*	10884*	10930*	10976*	11022*
		11068*	11096*	11100*	11107	11116*	11143*	11148*	11158*	11186*	11190*	11197	11206*	11234*
		11238*	11248*	11276*	11280*	11287	11296*	11324*	11328*	11338*	11365*	11369*	11376	11385*
		11412*	11416*	11426*	11456*	11460	11470	11500*	11504	11514	11544*	11548*	11557	11587*
		11590*	11599	11629*	11633*	11642	11673*	11677*	11686	11716*	11720*	11729	11759*	11763*
		11772	11802*	11806*	11815	11845*	11849*	11858	11888*	11891*	11900	11930*	11934*	11943

		11973*	11977*	11986	12016*	12020*	12029	12060*	12064*	12073	12104*	12108*	12117	12148*
		12152*	12161	12191*	12195*	12204	12234*	12238*	12247	12276*	12280*	12289	12319*	12323*
		12332	12362*	12366*	12375	12405*	12409*	12418	12447*	12451*	12460	12507*	12554*	12598*
		12647*	12691*	12736*	12780*	12824*	12871*	12915*	12958*	13002*	13046*	13090*	13134*	13178*
		13222*	13266*	13310*	13353*	13397*	13441*	13485*	13528*	13557*	13561*	13571	13601*	13605*
		13615	13646*	13650*	13660	13690*	13694*	13704	13734*	13738*	13748	13779*	13783*	13785
		13794*	13823*	13827*	13832*	13859*	13863*	13865	13874*	13901*	13905*	13910*	13938*	13942*
		13944	13953*	13981*	13985*	13990*	14017*	14021*	14023	14032*	14059*	14063*	14068*	14096*
		14100*	14110	14140*	14144*	14154	14184*	14187*	14189	14229*	14232*	14234	14272*	14275*
		14314*	14317*	14319	14357*	14360*	14396*	14399*	14402*	14404	14436*	14439*	14441	14480*
		14517*	14546*	14550*	14555	14556*	14560*	14561	14592*	14596*	14601	14602*	14606*	14607
		14638*	14642*	14647	14648*	14652*	14653	14684*	14688*	14693	14694*	14698*	14699	14730*
		14734*	14739	14740*	14744*	14745	14776*	14780*	14785	14786*	14790*	14791	14822*	14826*
		14831	14832*	14836*	14837	14868*	14872*	14877	14878*	14882*	14883	14915*	14919*	14924*
		14954*	14958*	14963*	14993*	14997*	15002*	15032*	15036*	15041*	15068*	15072*	15082	15113*
		15117*	15127	15158*	15162*	15172	15203*	15207*	15217	15265*	15311*	15357*	15403*	15434*
		15435	15439*	15449	15482*	15483	15487*	15497	15530*	15535*	15545	15578*	15583*	15593
		15626*	15631*	15641	15690*	15735*	15779*	15807*	15811*	15821	15851*	15855*	15865	15895*
		15899*	15909	15957*	15991*	15995*	16008*	16044*	16087*	16130*	16173*	16217*	16255*	16285*
		16290*	16303*	16304*	16334*	16339*	16352*	16353*	16381*	16387*	16400*	16401*	16430*	16436*
		16449*	16450*	16480*	16485*	16495	16504*	16505*	16535*	16540*	16550	16559*	16560*	16589*
		16595*	16605	16614*	16615*	16644*	16650*	16660	16669*	16670*	16700*	16705*	16715	16724*
		16725*	16756*	16761*	16771	16780*	16781*	16810*	16816*	16826	16835*	16836*	16866*	16872*
		16882	16891*	16892*	16922*	16927*	16937	16946*	16947*	16977*	16982*	16992	17001*	17002*
		17031*	17037*	17047	17056*	17057*	17086*	17092*	17102	17111*	17112*	17142*	17147*	17157
		17166*	17167*	17198*	17203*	17213	17222*	17223*	17252*	17258*	17268	17277*	17278*	17308*
		17314*	17324	17333*	17334*	17365*	17370*	17383*	17384*	17415*	17420*	17433*	17434*	17464*
		17470*	17483*	17484*	17514*	17520*	17533*	17534*	17565*	17570*	17583*	17584*	17618*	17623*
		17636*	17637*	17667*	17673*	17686*	17687*	17717*	17723*	17736*	17737*	17774*	17811*	17848*
		17886*	17923*	17962*	17990*	17994*	18004	18036*	18037*	18041*	18051	18083*	18084*	18087*
		18089	18119*	18122*	18124	18156*	18159*	18161	18197*	18200*	18202	18248*	18279*	18282*
		18287*	18291	18324*	18327*	18329	18338*	18370*	18373*	18375	18384*	18415*	18418*	18420
		18429*	18460*	18463*	18468*	18499*	18502*	18507*	18537*	18542	18547*	18575*	18580	18585*
		18613*	18618	18623*	18651*	18656	18661*	18690*	18695	18700*	18728*	18732*	18742	18772*
		18776*	18786	18816*	18820*	18830	18860*	18864*	18874	18905*	18909	18919	18922*	18954*
		18958	18968	18999*	19003	19013	19044*	19048	19058	19089*	19092	19102	19149*	19194*
		19239*	19284*	19329*	19374*	19419*	19465*	19510*	19538*	19542*	19552	19582*	19586*	19596
		19626*	19631*	19641	19671*	19675*	19685	19715*	19719	19729	19759*	19763	19773	19803*
		19807	19817	19848*	19852	19862	19893*	19897	19907	19954*	19999*	20045*	20091*	20137*
		20183*	20230*	20277*	20323*	20355*	20358*	20360	20404*	20435*	20438*	20443*	20474*	20477*
		20482*	20512*	20516*	20521*	20551*	20555*	20560*	20590*	20594*	20599*	20629*	20633*	20638*
		20666*	20670*	20675*	20704*	20708*	20713*	20740*	20744*	20749*	20779*	20783*	20788*	22125*
		22129*	22143	22153*	22183*	22187*	22201	22211*	22252*	22253	22265*	22306*	22307	22319*
		22347*	22349	22387	22419*	22421	22459	22513*	22535*	22562*	22652*	22703*	22740*	22744*
		22772*	22817*	22821*	22849*	23423*	23436*	23438	23467*	23478*	23479	23498*	23515*	23522*
		23528*	23590*	23618	23923*	24177*	24344*	24355*	24398*	24409*	24453*	24464*	25082*	25088
		25196	25232	25304*	25335*	25342	25378*	25413*	25448*	25479*	25486*	25517*	25524*	25768*
		25775*	25805*	25814*	25919*	25922*	25924	25988*	25991*	25993	26061*	26064*	26066	26131*
		26134*	26136	26190*	26193*	26196	26242*	26245*	26248	26690	26744*	26748*	26752*	26756
		26757*	26828	26848*										
R30725	057124	23815#	23822											
R30726	057240	23857#	23864											
R30727	057354	23902#	23909											
R30730	057530	23962#	23970											
R30731	057702	24023#	24031											
R4	=%000004	2902#	4126*	4127*	4128	4134	4347*	4354	4380*	4384	4413*	4417	4444*	4446

4456	4481*	4483	4493	4519*	4523	4525	4552*	4558	4587*	4595	4622*	4630
4668*	4669	4700*	4701	4711	4740*	4751	4779*	4817*	4834	4839	4863*	4864*
4870	4898*	4904	4932*	4964*	4971	4999*	5006	5033*	5045	5071*	5083	5109*
5120	5147*	5158	5185*	5195	5200	5223*	5234	5239	5266*	5276	5281	5305*
5315	5320	5344*	5351	5383*	5389	5416*	5423	5451*	5458	5485*	5493	5526*
5531	5588*	5595	5622*	5630	5657*	5662	5664	5698*	5706	5740*	5747	5775*
5782	5815*	5822	5855*	5862	5887*	5888*	5897	5924*	5926	5933	5968*	5969
5970	5980	6008*	6010	6041*	6043	6074*	6107*	6113	6141*	6147	6174*	6182
6209*	6220	6250*	6251	6283*	6294	6322*	6328	6356*	6364	6395*	6400	6417
6444*	6469	6474	6498*	6523	6528	6552*	6577	6582	6606*	6631	6636	6663*
6670	6706*	6713	6749*	6756	6791*	6798	6832*	6840	6875*	6883	6917*	6925
6960*	6968	7003*	7010	7044*	7051	7085*	7101	7140*	7156	7192*	7199	7226*
7233	7260*	7267	7295*	7302	7872*	7877	7908*	7912	7941*	7945	7972*	7977
7993*	7995	8002*	8004*	9605*	9651*	9686*	9732*	9771*	9844*	9879*	9894	9924*
9964*	9980	10011*	10027	10060*	10076	10098	10135*	10151	10182*	10197	10228*	10243
10274*	10289	10320*	10321	10335	10366*	10381	10412*	10427	10458*	10473	10504*	10505
10519	10550*	10565	10595*	10610	10640*	10655	10685*	10700	10730*	10745	10775*	10790
10820*	10835	10866*	10881	10912*	10927	10958*	10973	11004*	11019	11050*	11065	11095*
11113	11142*	11155	11184*	11203	11232*	11245	11274*	11293	11322*	11335	11364*	11382
11411*	11423	11455*	11470	11498*	11499*	11500	11514	11543*	11557	11586*	11599	11628*
11642	11672*	11686	11715*	11729	11758*	11772	11801*	11815	11844*	11858	11887*	11900
11929*	11943	11972*	11986	12015*	12029	12059*	12073	12103*	12117	12147*	12161	12190*
12204	12233*	12247	12275*	12289	12318*	12332	12361*	12375	12404*	12418	12446*	12460
12489*	12504	12535*	12536*	12551	12591*	12595	12625*	12644	12674*	12688	12719*	12733
12763*	12777	12807*	12821	12854*	12868	12898*	12912	12942*	12955	12985*	12999	13029*
13043	13073*	13087	13117*	13131	13161*	13175	13205*	13219	13249*	13263	13293*	13307
13336*	13350	13380*	13394	13424*	13438	13468*	13482	13511*	13525	13556*	13571	13600*
13615	13645*	13660	13689*	13704	13733*	13748	13777*	13791	13821*	13829	13858*	13871
13900*	13907	13936*	13950	13979*	13987	14016*	14029	14058*	14065	14094*	14110	14138*
14154	14182*	14189	14227*	14234	14269*	14271	14277	14312*	14319	14354*	14356	14362
14397*	14404	14433*	14435	14441	14470*	14477	14507*	14514	14544*	14552	14590*	14598
14636*	14644	14682*	14690	14728*	14736	14774*	14782	14820*	14828	14866*	14874	14913*
14921	14952*	14960	14991*	14999	15030*	15038	15066*	15072	15082	15110*	15127	15155*
15172	15200*	15217	15245*	15262	15291*	15308	15337*	15354	15383*	15400	15433*	15449
15481*	15497	15529*	15545	15577*	15593	15625*	15641	15671*	15687	15716*	15732	15761*
15776	15805*	15821	15849*	15865	15893*	15909	15937*	15954	15987*	16005	16034*	16041
16077*	16084	16120*	16127	16163*	16170	16207*	16214	16245*	16252	16281*	16282*	16300
16330*	16331*	16349	16378*	16397	16427*	16446	16475*	16477*	16501	16531*	16532*	16556
16586*	16611	16641*	16666	16696*	16697*	16721	16752*	16753*	16777	16807*	16832	16863*
16888	16918*	16919*	16943	16973*	16974*	16998	17028*	17053	17083*	17108	17138*	17139*
17163	17194*	17195*	17219	17249*	17274	17305*	17330	17361*	17362*	17380	17411*	17412*
17430	17461*	17480	17511*	17530	17561*	17562*	17580	17614*	17615*	17633	17664*	17683
17714*	17733	17764*	17771	17801*	17808	17838*	17845	17876*	17883	17913*	17920	17952*
17959	17988*	18004	18034*	18051	18081*	18089	18117*	18124	18154*	18161	18195*	18202
18238*	18245	18276*	18284	18321*	18335	18367*	18381	18412*	18426	18457*	18465	18496*
18504	18536*	18544	18574*	18582	18612*	18620	18650*	18658	18689*	18697	18726*	18742
18770*	18786	18814*	18830	18858*	18874	18903*	18919	18952*	18954	18968	18997*	19013
19042*	19044	19058	19087*	19102	19130*	19146	19175*	19191	19220*	19236	19265*	19291
19310*	19326	19355*	19371	19400*	19416	19446*	19462	19492*	19507	19536*	19552	19580*
19596	19624*	19641	19669*	19685	19713*	19715	19729	19757*	19759	19773	19801*	19803
19817	19846*	19848	19862	19891*	19907	19935*	19951	19980*	19996	20025*	20042	20071*
20088	20117*	20134	20163*	20180	20210*	20213	20227	20257*	20274	20304*	20320	20353*
20360	20394*	20401	20432*	20440	20471*	20479	20510*	20518	20549*	20557	20588*	20596
20627*	20635	20665*	20670	20672	20702*	20710	20739*	20744	20746	20777*	20785	21466*
21504*	21507*	21518	21551*	21589*	21629*	21670*	21716*	21764*	21810*	21851*	22123*	22143
22152*	22181*	22201	22210*	22240*	22253	22264*	22294*	22307	22318*	22346*	22354	22362

		22374	22381	22391	22395	22418*	22426	22434	22446	22453	22463	22467	22506*	22509
		22528*	22550*	22559	22586*	22595*	22651*	22702*	22771*	22848*	22880*	22886*	22914*	22920*
		22948*	22954*	22982*	22988*	23016*	23022*	23050*	23056*	23082*	23088*	23114*	23120*	23149*
		23155*	23181*	23187*	23214*	23220*	23249*	23255*	23282*	23288*	23315*	23321*	23348*	23354*
		23381*	23387*	23422*	23429*	23477*	23481*	23485*	23490*	23589*	23598	23603	23645*	23652
		23657	23682*	23691	23696	23707*	23716	23721	23732*	23741	23746	23771*	23779	23783
		23844*	23853*	23861*	23985*	23986*	23989	24046*	24047*	24050	24090*	24114	24124*	24147
		24171*	24179	24183	24209*	24217	24221	24246*	24254	24257	24334*	24342	24343*	24353
		24354*	24388*	24396	24397*	24407	24408*	24443*	24451	24452*	24462	24463*	25196*	25232*
		25342*	25844*	25845	25858	25864	25927*	25996*	26069*	26139*	26189*	26196	26241*	26248
		26695	26743*	26756*	26827	26849*	26876*	26886	26889*	26899	26902*	26913	26916*	26929
		26931*	26941											
R40730	057550	23972*	23980											
R40731	057722	24033*	24041											
R5	=%000005	2903*	4128*	4129*	4135	4346*	4348*	4352	4589*	4593*	4624*	4628*	4818*	4821
		4828	5000*	5004*	5343*	5345	5360	5487*	5491	5499	5558*	5561	5624*	5628
		5658*	5662*	5671	5700*	5704*	5713	5741*	5745	5776*	5780	5789	5816*	5820
		5828	5856*	5860	5891*	5895	5927*	5931*	5940	5969*	5973	6009*	6013	6210*
		6211	6227	6358*	6362*	6396*	6399	6411	6446*	6450	6463	6500*	6504	6517
		6554*	6558	6571	6608*	6612	6625	6664*	6668	6677	6707*	6711	6720	6750*
		6754	6763	6792*	6796	6805	6833*	6838	6876*	6981	6918*	6923	6961*	6966
		7004*	7008	7016	7045*	7049	7057	7094*	7086	7114	7139*	7141	7169	7193*
		7197	7227*	7231	7261*	7265	7296*	7300	7329*	7330	7339	7365*	7366	7400*
		7401	7420	7446*	7447	7484*	7485	7541*	7542	7556	7578*	7579	7635*	7636
		7651	7678*	7679	7714*	7715	7750*	7753	7791*	7794	7833*	7834	7973*	7987*
		7991*	7997*	9701*	9702*	11185*	11187*	11203	11206	11233*	11235*	11245	11248	11275*
		11277*	11293	11296	11323*	11325*	11335	11338	13778*	13780*	13791	13794	13822*	13824*
		13829	13832	13937*	13939*	13950	13953	13980*	13982*	13987	13990	14095*	14100	14139*
		14144	14183*	14187	14195	14228*	14232	14240	14270*	14275	14283	14313*	14317	14325
		14355*	14360	14368	14398*	14402	14434*	14439	14471*	14475	14508*	14512	14545*	14550
		14591*	14596	14637*	14642	14683*	14688	14729*	14734	14775*	14780	14821*	14826	14867*
		14872	14914*	14919	14953*	14958	14993*	14993	14997	15031*	15032	15036	15111*	15113
		15117	15157*	15162	15202*	15207	15246*	15252	15292*	15298	15338*	15344	15384*	15390
		15435*	15439	15483*	15487	15531*	15535	15579*	15583	15627*	15631	15672*	15677	15717*
		15722	15762*	15766	15806*	15811	15850*	15851	15855	15894*	15896*	15899	15938*	15939*
		15944	15988*	15989*	15995	16035*	16039*	16048	16078*	16082*	16091	16121*	16125*	16134
		16164*	16168*	16177	16208*	16212*	16246*	16250*	16284*	16290	16333*	16339	16380*	16387
		16429*	16436	16479*	16485	16534*	16540	16588*	16595	16643*	16650	16699*	16705	16755*
		16761	16809*	16816	16865*	16872	16921*	16927	16976*	16982	17030*	17037	17085*	17092
		17141*	17147	17197*	17203	17251*	17258	17307*	17314	17364*	17370	17414*	17420	17463*
		17470	17513*	17520	17564*	17570	17617*	17623	17666*	17673	17716*	17723	17765*	17769*
		17802*	17806*	17839*	17843*	17877*	17881*	17914*	17918*	17953*	17957*	17989*	17994	18035*
		18041	18082*	18087	18118*	18122	18155*	18159	18167	18196*	18200	18208	18239*	18243
		18277*	18282	18322*	18327	18368*	18373	18413*	18418	18458*	18463	18497*	18502	18538*
		18542*	18576*	18580*	18614*	18618*	18652*	18656*	18691*	18695*	18727*	18732	18771*	18776
		18815*	18820	18859*	18864	18904*	18909	18953*	18958	18998*	19003	19043*	19048	19088*
		19092	19131*	19136	19176*	19191	19221*	19226	19266*	19271	19311*	19316	19356*	19361
		19401*	19406	19447*	19452	19493*	19497	19537*	19542	19581*	19586	19625*	19627*	19631
		19670*	19675	19714*	19719	19758*	19763	19802*	19807	19847*	19852	19892*	19894*	19897
		19936*	19941	19981*	19986	20026*	20027*	20032	20072*	20073*	20078	20118*	20119*	20124
		20164*	20165*	20170	20211*	20212*	20217	20258*	20259*	20264	20305*	20306*	20310	20354*
		20358	20395*	20399	20433*	20438	20472*	20477	20511*	20516	20550*	20555	20589*	20594
		20628*	20633	20703*	20708	20778*	20783	21462*	21472	21479	21501*	21524	21547*	21564
		21585*	21601	21624*	21625	21635	21642	21665*	21666	21676	21688	21711*	21712	21726
		21733	21759*	21760	21770	21782	21805*	21806	21816	21823	21846*	21847	21858	21870
		21931*	21934*	22122*	22124	22149	22152	22157	22180*	22182	22207	22210	22215	22238*

		22239	22261	22264	22269	22292*	22293	22315	22318	22323	22348*	22387	22390	22420*
		22459	22462	22478*	22480	22492	22548*	22553	22570	22583*	22585	22605	22640*	22648
		22652	22691*	22699	22703	22734*	22738	22780	22811*	22815	22857	22875*	22879	22896
		22909*	22913	22930	22943*	22947	22964	22977*	22981	22998	23011*	23015	23032	23045*
		23049	23066	23077*	23081	23098	23109*	23113	23130	23144*	23148	23165	23176*	23180
		23197	23209*	23213	23231	23244*	23248	23266	23277*	23281	23299	23310*	23314	23332
		23343*	23347	23365	23376*	23380	23398	23418*	23421	23448	23468*	23473	23532	23551*
		23553	23561	23538*	23599	23607	23614	23619	23643*	23653	23661	23668	23672	23681*
		23692	23697	23706*	23717	23722	23731*	23742	23747	23770*	23773	23784	23797*	23801*
		23806*	23810*	23815*	23819*	23840*	23844	23849*	23853	23857*	23861	23884*	23888	23893*
		23897	23902*	23906	23939*	23948	23958	23968	23978	23987	24000*	24009	24019	24029
		24039	24048	24061*	24068	24074	24077	24092*	24100	24106	24109	24125*	24133	24139
		24142	24170*	24173	24184	24208*	24211	24222	24245*	24249	24258	24282*	24283	24305
		24333*	24345	24356	24360	24387*	24399	24410	24414	24440*	24454	24465	24469	24495*
		24499	24513	24536*	24543	24557	24583*	24587	24601	24627*	24631	24645	24671*	24675
		24689	24714*	24718	24732	24756*	24760	24774	24800*	24804	24818	24842*	24846	24860
		24899*	24900	24934*	24935	24971*	24972	25007*	25008	25043*	25044	25080*	25081	25118*
		25119	25120*	25126	25154*	25155	25189*	25190	25225*	25226	25261*	25263	25297*	25298
		25334*	25336	25371*	25372	25406*	25407	25441*	25442	25478*	25480	25516*	25518	25553*
		25555	25589*	25590	25624*	25625	25659*	25660	25693*	25694	25727*	25728	25766*	25767
		25803*	25804	25848*	25914*	25915	25916	25918	25919	25924	25927	25928	25932	25935
		25983*	25984	25985	25987	25988	25993	25996	25997	26001	26004	26056*	26057	26058
		26060	26061	26066	26069	26070	26074	26077	26126*	26127	26128	26130	26131	26136
		26139	26140	26144	26147	26826	26850*							
SAVR	066146	26742	26826#											
SCOFLG	066702	7543*	7550*	26563*	26971#									
SCOPE =	000004	2924#	7548	8064	8110	8142	8170	8201	8232	8264	8297	8329	8360	8397
		8437	8474	8514	8545	8577	8609	8641	8673	8705	8737	8770	8803	8839
		8872	8901	8935	8968	9001	9032	9065	9097	9129	9162	9195	9226	9259
		9292	9324	9356	9389	9422	9454	9485	9518	9550	9582	9627	9662	9708
		9744	9820	9855	9900	9936	9986	10033	10110	10157	10203	10249	10295	10341
		10387	10433	10479	10525	10571	10616	10661	10706	10751	10796	10842	10888	10934
		10980	11026	11072	11120	11162	11210	11252	11300	11342	11389	11430	11476	11520
		11563	11605	11648	11692	11735	11778	11821	11864	11906	11949	11992	12035	12079
		12123	12167	12210	12253	12295	12338	12381	12424	12466	12511	12558	12602	12651
		12695	12740	12784	12828	12875	12919	12962	13006	13050	13094	13138	13182	13226
		13270	13314	13357	13401	13445	13489	13532	13577	13621	13666	13710	13754	13798
		13836	13878	13914	13957	13994	14036	14072	14116	14160	14201	14246	14289	14331
		14374	14410	14447	14484	14521	14567	14613	14659	14705	14751	14797	14843	14889
		14928	14967	15006	15045	15088	15133	15178	15223	15269	15315	15361	15407	15455
		15503	15551	15599	15647	15694	15739	15783	15827	15871	15915	15961	16012	16054
		16097	16140	16183	16221	16259	16308	16357	16405	16454	16509	16564	16619	16674
		16729	16785	16840	16896	16951	17006	17061	17116	17171	17227	17282	17338	17388
		17438	17488	17538	17588	17641	17691	17741	17778	17815	17852	17890	17927	17966
		18010	18057	18095	18130	18173	18214	18252	18297	18343	18388	18433	18472	18511
		18551	18589	18627	18665	18704	18748	18792	18836	18880	18926	18974	19019	19064
		19108	19153	19198	19243	19288	19333	19377	19423	19469	19514	19558	19602	19647
		19691	19735	19778	19823	19868	19913	19958	20003	20049	20095	20141	20187	20234
		20281	20327	20366	20408	20447	20486	20525	20564	20603	20642	20679	20717	20753
		20792	20831	20872	20918	20959	21012	21058	21109	21150	21201	21247	21293	21339
		21390	21441	21480	21525	21565	21602	21644	21690	21735	21784	21825	21872	21906
		21952	21988	22025	22062	22099	22158	22216	22270	22324	22397	22469	22495	22517
		22539	22572	22608	22659	22710	22786	22863	22899	22933	22967	23001	23035	23069
		23101	23133	23168	23200	23234	23269	23302	23335	23368	23401	23452	23539	23564
		23621	23674	23[illegible]99	23724	23749	23787	23830	23872	23931	23992	24053	24083	24116
		24149	24186	24224	24260	24307	24362	24416	24471	24514	24558	24602	24646	24690

		24733 24775 24819 24861 24911 24947 24984 25019 25055 25093 25131 25166 25201
		25237 25274 25309 25347 25383 25418 25453 25491 25529 25566 25601 25636 25670
		25704 25740 25780 25819 25866 25938 26007 26080 26150 26209 26261
SCOPEA	065260	7544 26563#
SCOPEB	065266	8014 26567#
SELTST	066700	26574* 26575* 26576 26970#
S081	050532	21941# 22089
S082	050536	21939 21944#
S083	050724	21941 22087#
SP	=X000006	2904# 3290* 4143 4154* 4161* 5343 5345* 5346* 5349* 5351 5354 5355 5360*
		6210 6211* 6212* 6213 6216* 6218 6227* 6396 6397 6399* 6400* 6403 6411
		7084 7086* 7088* 7089 7090 7093* 7108 7114* 7139 7141* 7143* 7144 7145
		7148* 7163 7169* 7329 7330* 7331* 7339 7365 7366* 7374 7400 7401* 7402*
		7403* 7420 7446 7447* 7448* 7449* 7484 7485* 7488* 7505 7512 7541 7542*
		7556* 7578 7579* 7582* 7599 7606 7635 7636* 7651* 7678 7679* 7714 7715*
		7750 7753* 7791 7794* 7833 7834* 21462 21471 21472 21475 21479* 21501 21503*
		21512 21524* 21547 21564* 21585 21601* 21624 21625* 21634 21635 21638 21642* 21665
		21666* 21675 21676 21679 21688* 21711 21712* 21725 21726 21729 21733* 21759 21760*
		21769 21770 21773 21782* 21805 21806* 21815 21816 21820 21823* 21846 21847* 21857
		21858 21861 21870* 22122 22124* 22126* 22149 22153 22157* 22180 22182* 22184* 22207
		22211 22215* 22238 22239* 22241* 22242* 22261 22265 22269* 22292 22293* 22295* 22296*
		22315 22319 22323* 22346 22354* 22362* 22374* 22378 22380 22381* 22391* 22395* 22418
		22426* 22434* 22446* 22450 22452 22453* 22463* 22467* 22478 22480* 22492* 22548 22553*
		22570* 22583 22585* 22605* 22734 22738* 22761 22768 22772 22780* 22811 22815* 22838
		22845 22849 22857* 22875 22879* 22896* 22909 22913* 22930* 22943 22947* 22964* 22977
		22981* 22998* 23011 23015* 23032* 23045 23049* 23066* 23077 23081* 23098* 23109 23113*
		23130* 23144 23148* 23165* 23176 23180* 23197* 23209 23213* 23231* 23244 23248* 23266*
		23277 23281* 23299* 23310 23314* 23332* 23343 23347* 23365* 23376 23380* 23398* 23418
		23421* 23448* 23468 23473* 23532* 23551 23553* 23561* 23588 23593* 23596* 23599* 23604
		23607* 23614* 23619* 23643 23647* 23650* 23653* 23661* 23665 23668* 23672* 23681 23684*
		23687 23692* 23697* 23706 23709* 23712 23717* 23722* 23731 23734* 23737 23742* 23747*
		23770 23773* 23784* 23827* 23869* 23918 23920* 23923 23924* 23939 23943* 23946* 23948*
		23953* 23956* 23958* 23963* 23966* 23968* 23973* 23976* 23978* 23985 23987* 23988* 23989*
		24000 24004* 24007* 24009* 24014* 24017* 24019* 24024* 24027* 24029* 24034* 24037* 24039*
		24046 24048* 24049* 24050* 24061 24063* 24068* 24074* 24077* 24092 24095* 24100* 24106*
		24109* 24125 24128* 24133* 24139* 24142* 24170 24173* 24184* 24208 24211* 24222* 24245
		24249* 24258* 24282 24283* 24285* 24286* 24297 24305* 24333 24336* 24339* 24344 24345*
		24350 24355 24356* 24360* 24387 24390* 24393* 24398 24399* 24404 24409 24410* 24414*
		24440 24445* 24448* 24453 24454* 24459 24464 24465* 24469* 24495 24499* 24513* 24536
		24543* 24557* 24583 24587* 24601* 24627 24631* 24645* 24671 24675* 24689* 24714 24718*
		24732* 24756 24760* 24774* 24800 24804* 24818* 24842 24846* 24860* 24899 24900* 24901*
		24902* 24934 24935* 24937* 24938* 24971 24972* 24974* 24975* 25007 25008* 25009* 25010*
		25043 25044* 25045* 25046* 25080 25081* 25083* 25084* 25118 25119* 25121* 25122* 25154
		25155* 25156* 25157* 25189 25190* 25191* 25192* 25225 25226* 25227* 25228* 25261 25263*
		25264* 25265* 25297 25298* 25299* 25300* 25334 25336* 25337* 25338* 25371 25372* 25373*
		25374* 25406 25407* 25408* 25409* 25441 25442* 25443* 25444* 25478 25480* 25481* 25482*
		25516 25518* 25519* 25520* 25553 25555* 25556* 25557* 25589 25590* 25591* 25592* 25624
		25625* 25626* 25627* 25659 25660* 25661* 25662* 25693 25694* 25695* 25696* 25727 25728*
		25729* 25730* 25731* 25766 25767* 25769* 25770* 25803 25804* 25806* 25807* 25844 25845*
		25846* 25847* 25858* 25864* 26385* 26402* 26403* 26455 26465* 26527 26536* 26570* 26584
		26643* 26644 26663 26668 26684 26686* 26699 26707* 26708* 26718* 26719* 26794* 26795
		26796* 26798* 26801 26802 26805 26807* 26808* 26817 26826* 26827* 26828* 26829* 26830*
		26831* 26832 26844* 26845 26846 26847 26848 26849 26850 26885* 26898* 26912* 26927*
		26940*
SR	= 177570	2909# 8022 26271 26342 26344 26391 26451 26523 26568 26572 26574 26579 26648
		26700 26702 26711 26861 26880 26893 26907 26922 26935

```
STAB1   070162          4639    4664*   4698*   4738*   4777*   4815*   4861*   4896*   4930*   4963*   4997*   5032*   5070*
                        5107*   5145*   5183*   5221*   5261*   5303*   5342*   5381*   5414*   5449*   5484*   5524*   5557*
                        5587*   5621*   5655*   5697*   5738*   5773*   5813*   5853*   5886*   5923*   5966*   6006*   6040*
                        6073*   6105*   6139*   6173*   6208*   6248*   6281*   6320*   6355*   6391*   6443*   6497*   6551*
                        6605*   6660*   6703*   6746*   6788*   6830*   6873*   6915*   6958*   7001*   7042*   7083*   7138*
                        7190*   7224*   7258*   7293*   7328*   7364*   7399*   7445*   7483*   7540*   7577*   7634*   7674*
                        7713*   7748*   7789*   7827*   7870*   7906*   7939*   7967*   26349   26567*  27219#
STAB2   071204          4640    27221#
STACKL= 001000          2951#   3290    4143
SW09  = 001000          2920#   26702
SW10  = 002000          2919#   26572   26700
SW11  = 004000          2918#   26579
SW12  = 010000          2917#   8022    26271   26342   26391   26451   26523   26861   26880   26893   26907   26922   26935
SW13  = 020000          2916#   26344   26648
SW14  = 040000          2915#   26568
SW15  = 100000          2914#
TBSER   065026          24866   26402#
TSET    062070          24866#
TSTOPT  066210          8029    26858#
TYPE  = 104400          2939#   7685    8027    26273   26277   26279   26283   26289   26291   26293   26353   26358   26360
                        26393   26453   26458   26460   26525   26529   26531   26652   26654   26657   26697   26726   26863
                        26872   26882   26895   26909   26924   26937
T0001   003040          4181#
T0002   003054          4184    4207#
T0003   003072          4212    4235#
T0004   003106          4238    4260#
T0005   003124          4265    4288#
T0006   003146          4294    4317#
T0007   003166          4321    4344#
T0010   003226          4355    4378#
T0011   003264          4386    4411#
T0012   003322          4419    4443#
T0013   003364          4457    4480#
T0014   003424          4494    4517#
T0015   003460          4526    4550#
T0016   003516          4559    4586#
T0017   003564          4596    4621#
T0020   003652          4663#
T0021   003722          4675    4697#
T0022   003776          4712    4737#
T0023   004046          4752    4776#
T0024   004114          4791    4814#
T0025   004200          4835    4860#
T0026   004244          4871    4895#
T0027   004312          4905    4929#
T0030   004352          4939    4962#
T0031   004416          4972    4996#
T0032   004466          5007    5031#
T0033   004536          5046    5069#
T0034   004606          5084    5106#
T0035   004656          5121    5144#
T0036   004726          5159    5182#
T0037   004776          5196    5220#
T0040   005052          5235    5260#
T0041   005136          5277    5302#
T0042   005210          5316    5341#
```

F10


```
T0043   005264          5380#
T0044   005326          5390    5413#
T0045   005400          5424    5448#
T0046   005446          5459    5483#
T0047   005524          5500    5523#
T0050   005572          5532    5556#
T0051   005624          5566    5586#
T0052   005670          5596    5620#
T0053   005736          5631    5654#
T0054   006014          5672    5696#
T0055   006074          5714    5737#
T0056   006144          5748    5772#
T0057   006226          5790    5812#
T0060   006304          5829    5852#
T0061   006352          5863    5885#
T0062   006426          5898    5922#
T0063   006514          5941    5965#
T0064   006570          5981    6005#
T0065   006632          6015    6039#
T0066   006674          6048    6072#
T0067   006736          6081    6104#
T0070   007004          6114    6138#
T0071   007054          6148    6172#
T0072   007120          6183    6207#
T0073   007200          6247#
T0074   007242          6256    6280#
T0075   007314          6295    6319#
T0076   007362          6329    6354#
T0077   007434          6365    6390#
T0100   007536          6418    6442#
T0101   007640          6470    6496#
T0102   007744          6524    6550#
T0103   010050          6578    6604#
T0104   010152          6632    6659#
T0105   010242          6678    6702#
T0106   010332          6721    6745#
T0107   010422          6764    6787#
T0110   010512          6806    6829#
T0111   010600          6848    6872#
T0112   010666          6891    6914#
T0113   010756          6933    6957#
T0114   011046          6976    7000#
T0115   011124          7017    7041#
T0116   011202          7058    7082#
T0117   011302          7137#
T0120   011402          7189#
T0121   011454          7200    7223#
T0122   011526          7234    7257#
T0123   011600          7268    7292#
T0124   011652          7303    7327#
T0125   011714          7340    7363#
T0126   011756          7375    7398#
T0127   012052          7421    7444#
T0130   012132          7457    7482#
T0131   012262          7513    7539#
T0132   012336          75'6#
```

```
T0133   012466          7607    7633#
T0134   012550          7673#
T0135   012634          7688    7712#
T0136   012706          7724    7747#   7764
T0137   013002          7788#   7805
T0140   013064          7802    7826#
T0141   013[illegible]2         7869#
T0142   013242          7879    7905#
T0143   013302          7914    7938#
T0144   013344          7947    7966#   7984    8006
T0145   013644          8051#
T0146   013676          8085#
T0147   013742          8131#
T0150   013766          8163#
T0151   014010          8190#
T0152   014034          8222#
T0153   014056          8253#
T0154   014102          8287#
T0155   014124          8318#
T0156   014150          8350#
T0157   014172          8381#
T0160   014232          8418#
T0161   014276          8458#
T0162   014334          8495#
T0163   014376          8535#
T0164   014420          8566#
T0165   014446          8597#
T0166   014474          8630#
T0167   014520          8662#
T0170   014544          8694#
T0171   014570          8726#
T0172   014614          8758#
T0173   014642          8791#
T0174   014670          8824#
T0175   014730          8860#
T0176   014756          8891#
T0177   015000          8923#
T0200   015026          8956#
T0201   015054          8989#
T0202   015102          9021#
T0203   015126          9054#
T0204   015152          9086#
T0205   015176          9118#
T0206   015222          9151#
T0207   015246          9183#
T0210   015274          9216#
T0211   015316          9247#
T0212   015344          9280#
T0213   015372          9312#
T0214   015420          9345#
T0215   015444          9378#
T0216   015470          9411#
T0217   015514          9443#
T0220   015540          9475#
T0221   015562          9506#
T0222   015610          9539#
```

```
T0223   015634          9571#
T0224   015660          9603#
T0225   015736          9648#
T0226   015774          9683#
T0227   016052          9729#
T0230   016112          9767#
T0231   016252          9841#
T0232   016310          9876#
T0233   016364          9921#
T0234   016424          9958#
T0235   016516         10008#
T0236   016576         10057#
T0237   016740         10132#
T0240   017020         10178#
T0241   017074         10224#
T0242   017154         10270#
T0243   017234         10316#
T0244   017312         10362#
T0245   017366         10408#
T0246   017446         10454#
T0247   017526         10500#
T0250   017604         10547#
T0251   017664         10592#
T0252   017742         10637#
T0253   020022         10682#
T0254   020100         10727#
T0255   020160         10772#
T0256   020240         10817#
T0257   020322         10863#
T0260   020402         10909#
T0261   020464         10955#
T0262   020544         11001#
T0263   020626         11047#
T0264   020710         11092#
T0265   020776         11139#
T0266   021054         11181#
T0267   021146         11229#
T0270   021226         11271#
T0271   021320         11319#
T0272   021400         11361#
T0273   021466         11408#
T0274   021542         11449#
T0275   021630         11495#
T0276   021706         11540#
T0277   021764         11583#
T0300   022040         11625#
T0301   022120         11669#
T0302   022176         11712#
T0303   022254         11755#
T0304   022334         11798#
T0305   022412         11841#
T0306   022472         11884#
T0307   022546         11926#
T0310   022624         11969#
T0311   022704         12012#
T0312   022760         12056#
```

```
T0313   023040          12100#
T0314   023120          12144#
T0315   023174          12187#
T0316   023254          12230#
T0317   023332          12272#
T0320   023412          12315#
T0321   023470          12358#
T0322   023550          12401#
T0323   023630          12443#
T0324   023706          12486#
T0325   023764          12532#
T0326   024046          12578#
T0327   024126          12622#
T0330   024216          12671#
T0331   024300          12716#
T0332   024360          12760#
T0333   024440          12804#
T0334   024522          12848#
T0335   024614          12895#
T0336   024676          12939#
T0337   024754          12982#
T0340   025034          13026#
T0341   025116          13070#
T0342   025174          13114#
T0343   025256          13158#
T0344   025340          13202#
T0345   025416          13246#
T0346   025500          13290#
T0347   025560          13333#
T0350   025642          13377#
T0351   025722          13421#
T0352   026004          13465#
T0353   026066          13508#
T0354   026146          13553#
T0355   026226          13597#
T0356   026306          13642#
T0357   026366          13686#
T0360   026446          13730#
T0361   026526          13774#
T0362   026612          13818#
T0363   026664          13855#
T0364   026744          13897#
T0365   027012          13933#
T0366   027076          13976#
T0367   027150          14013#
T0370   027230          14055#
T0371   027276          14091#
T0372   027360          14135#
T0373   027444          14179#
T0374   027522          14221#
T0375   027612          14266#
T0376   027676          14309#
T0377   027754          14351#
T0400   030040          14394#
T0401   030106          14430#
T0402   030160          14467#
```

```
T0403   030226          14504#
T0404   030274          14541#
T0405   030366          14587#
T0406   030460          14633#
T0407   030554          14679#
T0410   030650          14725#
T0411   030742          14771#
T0412   031034          14817#
T0413   031130          14863#
T0414   031224          14910#
T0415   031300          14949#
T0416   031354          14988#
T0417   031426          15027#
T0420   031500          15064#
T0421   031554          15108#
T0422   031634          15153#
T0423   031720          15198#
T0424   032004          15243#
T0425   032064          15289#
T0426   032150          15335#
T0427   032236          15381#
T0430   032324          15429#
T0431   032404          15477#
T0432   032464          15525#
T0433   032550          15573#
T0434   032634          15621#
T0435   032720          15668#
T0436   033004          15713#
T0437   033070          15758#
T0440   033154          15802#
T0441   033236          15846#
T0442   033316          15890#
T0443   033404          15934#
T0444   033476          15981#
T0445   033604          16031#
T0446   033664          16074#
T0447   033746          16117#
T0450   034026          16160#
T0451   034110          16204#
T0452   034162          16242#
T0453   034234          16279#
T0454   034324          16328#
T0455   034414          16376#
T0456   034504          16425#
T0457   034574          16474#
T0460   034676          16529#
T0461   035000          16584#
T0462   035102          16639#
T0463   035204          16694#
T0464   035310          16750#
T0465   035414          16805#
T0466   035520          16861#
T0467   035624          16916#
T0470   035726          16971#
T0471   036030          17026#
T0472   036132          17081#
```

```
T0473   036234          17136#
T0474   036340          17192#
T0475   036444          17247#
T0476   036550          17303#
T0477   036654          17359#
T0500   036750          17409#
T0501   037044          17459#
T0502   037140          17509#
T0503   037234          17559#
T0504   037330          17609#
T0505   037436          17662#
T0506   037532          17712#
T0507   037626          17761#
T0510   037670          17798#
T0511   037732          17835#
T0512   037776          17873#
T0513   040042          17910#
T0514   040106          17949#
T0515   040154          17985#
T0516   040236          18031#
T0517   040320          18078#
T0520   040364          18114#
T0521   040432          18151#
T0522   040510          18192#
T0523   040566          18235#
T0524   040634          18273#
T0525   040716          18318#
T0526   041002          18364#
T0527   041064          18409#
T0530   041150          18454#
T0531   041224          18493#
T0532   041300          18533#
T0533   041350          18571#
T0534   041420          18609#
T0535   041472          18647#
T0536   041544          18686#
T0537   041620          18723#
T0540   041704          18767#
T0541   041762          18811#
T0542   042046          18855#
T0543   042124          18900#
T0544   042212          18946#
T0545   042306          18994#
T0546   042370          19039#
T0547   042452          19084#
T0550   042534          19127#
T0551   042622          19172#
T0552   042702          19217#
T0553   042770          19262#
T0554   043050          19307#
T0555   043136          19352#
T0556   043224          19397#
T0557   043312          19443#
T0560   043376          19489#
T0561   043462          19533#
T0562   043546          19577#
```

T0563	043626	19621#
T0564	043716	19666#
T0565	043776	19710#
T0566	0[illegible]60	19754#
T0567	044142	19798#
T0570	044224	19843#
T0571	044306	19888#
T0572	044374	19932#
T0573	044462	19977#
T0574	044550	20022#
T0575	044642	20068#
T0576	044734	20114#
T0577	045026	20160#
T0600	045120	20207#
T0601	045210	20254#
T0602	045302	20301#
T0603	045372	20350#
T0604	045436	20388#
T0605	045516	20429#
T0606	045566	20468#
T0607	045640	20507#
T0610	045712	20546#
T0611	045764	20585#
T0612	046040	20624#
T0613	046114	20662#
T0614	046160	20699#
T0615	046232	20736#
T0616	046276	20774#
T0617	046350	20811#
T0620	046414	20852#
T0621	046460	20878#
T0622	046536	20939#
T0623	046602	20980#
T0624	046670	21033#
T0625	046744	21079#
T0626	047032	21130#
T0627	047076	21171#
T0630	047164	21222#
T0631	047240	21268#
T0632	047314	21314#
T0633	047370	21360#
T0634	047454	21411#
T0635	047540	21460#
T0636	047606	21499#
T0637	047674	21531#
T0640	047742	21569#
T0641	050010	21622#
T0642	050060	21663#
T0643	050140	21709#
T0644	050216	21754#
T0645	050310	21803#
T0646	050362	21844#
T0647	050444	21893#
T0650	050476	21927#
T0651	050556	21972#
T0652	050614	22009#

```
T0653   050652          22046#
T0654   050710          22083#
T0655   050746          22120#
T0656   051054          22178#
T0657   051162          22236#
T0660   051264          22290#
T0661   051370          22344#
T0662   051526          22416#
T0663   051664          22474#
T0664   051752          22501#
T0665   052016          22523#
T0666   052064          22544#
T0667   052202          22579#
T0670   052324          22630#
T0671   052440          22681#
T0672   052554          22732#
T0673   052760          22809#
T0674   053164          22871#
T0675   053306          22905#
T0676   053430          22939#
T0677   053552          22973#
T0700   053674          23007#
T0701   054016          23041#
T0702   054140          23075#
T0703   054254          23107#
T0704   054370          23139#
T0705   054516          23174#
T0706   054632          23205#
T0707   054756          23240#
T0710   055102          23275#
T0711   055220          23308#
T0712   055336          23341#
T0713   055454          23374#
T0714   055572          23413#
T0715   055740          23462#
T0716   056246          23549#
T0717   056312          23586#
T0720   056440          23641#
T0721   056546          23679#
T0722   056626          23704#
T0723   056706          23729#
T0724   056766          23768#
T0725   057050          23793#
T0726   057164          23836#
T0727   057300          23880#  23927
T0730   057450          23937#
T0731   057622          23998#
T0732   057774          24059#
T0733   060060          24089#
T0734   060160          24122#
T0735   060260          24168#
T0736   060336          24206#
T0737   060414          24243#
T0740   060472          24280#
T0741   060572          24331#
T0742   060676          24385#
```

```
T0743   061004          24438#
T0744   061136          24494#
T0745   061214          24535#
T0746   061304          24580#
T0747   061370          24624#
T0750   061456          24668#
T0751   061544          24711#
T0752   061632          24755#
T0753   061710          24797#
T0754   061776          24841#
T0755   062112          24897#
T0756   062152          24932#
T0757   062216          24969#
T0760   062262          25005#
T0761   062322          25041#
T0762   062362          25078#
T0763   062426          25116#
T0764   062472          25152#
T0765   062532          25187#
T0766   062572          25223#
T0767   062632          25259#
T0770   062676          25295#
T0771   062736          25332#
T0772   063002          25369#
T0773   063042          25404#
T0774   063102          25439#
T0775   063142          25476#
T0776   063206          25514#
T0777   063252          25551#
T1000   063316          25587#
T1001   063356          25622#
T1002   063416          25657#
T1003   063454          25691#
T1004   063512          25725#
T1005   063556          25761#
T1006   063636          25801#
T1007   063710          25842#
T1010   063772          25913#
T1011   064050          25982#
T1012   064126          26055#
T1013   064204          26125#
T1014   064262          26186#
T1015   064326          26238#
XCSR  = 177564           2947#   7871    7907    7940   22633   22684   22735   22812   23078   23110   23145   23177   23278
                        23311   23344   23377   23467   26813
XDBR  = 177566           2948#  26817#
.     = 071206           2577#   2606    2613    2620    2622    2629    2636    2643    2650    2652    2654    2656    2658
                         2660    2662    2664    2666    2668    2670    2672    2674    2676    2678    2680    2682    2684
                         2686    2688    2690    2692    2694    2696    2698    2701    2703    2705    2707    2709    2711
                         2713    2715    2717    2719    2721    2723    2725    2727    2729    2731    2733    2735    2737
                         2739    2741    2743    2745    2747    2749    2751    2753    2755    2757    2759    2761    2763
                         2765    2767    2769    2771    2773    2775    2777    2779    2781    2783    2785    2787    2789
                         2791    2793    2795    2797    2799    2801    2803    2805    2807    2809    2811    2813    2815
                         2817    2819    2821    2823    2825    2827    2829    2831    2833    2835    2837    2839    2841
                         2843    2845    2847    2849    2851    2853    2855    2857    2859    2861    2863    2865    2867
                         2869    2871    2873    2875    2877    2879    2881    2883    2885    2887    2889    2949#   4149#
```

5263	6393	7676	8828	9962	11452	12851	14224	15984	17612	18949	20391	21757
22596	22887	22921	22955	22989	23023	23057	23089	23121	23142	23156	23188	23221
23256	23289	23322	23355	23388	24538	25764	26712	26862	26881	26894	26908	26923
26936	27068#	27219#										

```
COMMEN      1#
ENDCOM      1#
ESCAPE      1#
GETPRI      1#
GETSWR      1#
MULT        1#
NEWTST      1#
POP         1#
PUSH        1#
REPORT      1#
SETPRI      1#
SETUP       1#
SKIP        1#
SLASH       1#
STARS       1#
SWRSU       1#
TYPBIN      1#
TYPDEC      1#
TYPNAM      1#
TYPNUM      1#
TYPOCS      1#
TYPOCT      1#
TYPTXT      1#
$$ESCA      1#
$$NEWT      1#
$$SKIP      1#
.EQUAT      1#
.HERDE      1#
.KT11       1#
.SETUP      1#
.SWRHI      1#
.$ACTI      1#
.$APTB      1#
.$APTH      1#
.$APTY      1#
.$ASTA      1#
.$CATC      1#
.$CMTA      1#
.$DB2D      1#
.$DB2O      1#
.$DIV       1#
.$EOP       1#
.$ERRO      1#
.$ERRT      1#
.$MULT      1#
.$POWE      1#
.$RAND      1#
.$RDDE      1#
.$RDOC      1#
.$READ      1#
.$R2AZ      1#
.$SAVE      1#
.$SB2D      1#
.$SB2O      1#
.$SCOP      1#
.$SIZE      1#
```

```
.SSUPR      1#
.STRAP      1#
.STYPB      1#
.STYPD      1#
.STYPE      1#
.STYPO      1#
.S4DCA      1#
.1170       1#
```

ADC	3203	3265	3401	3474	3545	3757	3796	3833	3988	12195	12238	12280	13254	13298	13341
ADD	6326	6362	14100	14144	14187	14232	14275	14317	14360	14402	14439	14475	14512	14550	14596
	14642	14688	14734	14780	14826	14872	14919	14958	14997	15036	23827	23869	23920	23924	23986
	24047	25126	25232	25922	26193	26245	26402	26718	26796	26885	26898	26912	26927	26940	
ASH	26920														
ASL	5038	5076	11934	11977	12020	12990	13034	13078	26747	26751					
ASRB	11280	11328	11369	11416											
BCC	3028	3086	5078	5153	8323	8355	8386	9657	9739	9850	9931	9975	10022	10071	10093
	10146	10192	10376	10560	10740	10830	11060	11150	11240	11330	11418	11465	11509	11553	11595
	11768	11854	11896	11982	12025	12113	12157	12200	12285	12328	12371	12414	12499	12546	12591
	12634	12817	12908	12951	13039	13083	13171	13215	13259	13346	13390	13434	13478	13610	13699
	13743	14149	15077	15167	15257	15349	15444	15492	15588	15636	15727	15771	15860	15904	16295
	16344	16490	16545	16710	16766	16932	16987	17152	17208	17375	17425	17575	17628	17999	18781
	18869	18963	19053	19097	19186	19276	19366	19411	19502	19591	19680	19768	19857	19902	19991
	20083	20129	20222	20315	20823	20904	20992	21095	21183	21280	21376	21559	21980	22054	22196
	22371														
BCS	3057	3172	3206	3363	3395	3506	3539	5040	5115	8058	8105	8463	9616	9696	9781
	9803	9889	10238	10284	10330	10422	10468	10514	10605	10650	10695	10785	10876	10922	10968
	11014	11102	11192	11282	11371	11638	11682	11725	11811	11939	12069	12243	12456	12684	12729
	12773	12864	12995	13127	13303	13521	13566	13655	14105	15122	15212	15303	15395	15540	15682
	15816	15949	16000	16392	16441	16600	16655	16821	16877	17042	17097	17263	17319	17475	17525
	17678	17728	18046	18737	18825	18914	19008	19141	19231	19321	19457	19547	19636	19724	19812
	19946	20037	20175	20269	20864	20951	21045	21142	21234	21326	21427	21597	22017	22091	22138
	22443														
BEQ	3026	3084	3114	3142	3235	3266	3331	3402	3438	3468	3475	3546	3576	3605	3633
	3663	3751	3758	3797	3834	3863	3952	3982	3989	4020	4051	4081	4110	4138	4144
	4238	4263	4355	4386	4451	4457	4494	4526	4559	4596	4631	4674	4706	4712	4746
	4752	4785	4791	4829	4835	4871	4905	4939	4972	5007	5046	5084	5121	5159	5196
	5235	5263	5271	5277	5310	5316	5352	5390	5424	5459	5500	5532	5596	5631	5665
	5672	5707	5714	5748	5783	5790	5823	5829	5863	5898	5934	5941	5975	5981	6048
	6114	6148	6183	6221	6289	6295	6329	6365	6393	6405	6412	6418	6452	6458	6464
	6470	6506	6512	6518	6524	6560	6566	6572	6578	6614	6620	6626	6632	6671	6678
	6714	6721	6757	6764	6799	6806	6841	6848	6884	6891	6926	6933	6969	6976	7011
	7017	7052	7058	7096	7102	7109	7151	7157	7164	7200	7234	7268	7303	7340	7375
	7414	7421	7457	7499	7506	7513	7551	7593	7600	7607	7645	7676	7688	7724	7761
	7802	7879	7914	7947	8055	8090	8390	8430	8467	8507	8828	9622	9694	9703	9787
	9809	9815	9887	9895	9962	9981	10020	10028	10077	10099	10105	10144	10152	10198	10236
	10244	10282	10290	10328	10336	10382	10420	10428	10466	10474	10512	10520	10558	10566	10611
	10648	10656	10701	10738	10746	10783	10791	10828	10836	10882	10920	10928	10974	11012	11020
	11058	11066	11108	11114	11156	11198	11204	11246	11288	11294	11336	11377	11383	11424	11452
	11471	11507	11515	11558	11600	11636	11643	11687	11730	11766	11773	11816	11852	11859	11894
	11901	11944	11980	11987	12030	12067	12074	12111	12118	12162	12198	12205	12248	12283	12290
	12333	12369	12376	12412	12419	12454	12461	12505	12544	12552	12596	12639	12645	12682	12689
	12734	12778	12815	12822	12851	12869	12906	12913	12949	12956	13000	13037	13044	13088	13125
	13132	13169	13176	13220	13257	13264	13308	13344	13351	13395	13432	13439	13476	13483	13519
	13526	13564	13572	13616	13653	13661	13705	13749	13786	13792	13830	13866	13872	13908	13945
	13951	13988	14024	14030	14066	14111	14147	14155	14190	14196	14224	14235	14241	14278	14284
	14320	14326	14363	14369	14405	14442	14478	14515	14553	14562	14599	14608	14645	14654	14691
	14700	14737	14746	14783	14792	14829	14838	14875	14884	14922	14961	15000	15039	15083	15128
	15165	15173	15210	15218	15263	15309	15347	15355	15393	15401	15450	15498	15538	15546	15586
	15594	15634	15642	156[illegible]	15688	15733	15769	15777	15814	15822	15866	15902	15910	15947	15955
	15984	15998	16006	16042	16049	16085	16092	16128	16135	16171	16178	16215	16253	16293	16301
	16342	16350	16398	16447	16488	16496	16502	16543	16551	16557	16606	16612	16661	16667	16708
	16716	16722	16764	16772	16778	16827	16833	16883	16889	16930	16938	16944	16985	16993	16999
	17048	17054	17103	17109	17150	17158	17164	17206	17214	17220	17269	17275	17325	17331	17373
	17381	17423	17431	17481	17531	17573	17581	17612	17626	17634	17684	17734	17772	17809	17846

	17884	17921	17960	17997	18005	18052	18090	18125	18162	18168	18203	18209	18246	18285	18292
	18330	18336	18376	18382	18421	18427	18466	18505	18545	18583	18621	18659	18698	18735	18743
	18787	18823	18831	18875	18912	18920	18949	18969	19006	19014	19059	19095	19103	19139	19147
	19192	19229	19237	19282	19319	19327	19372	19417	19455	19463	19500	19508	19545	19553	19597
	19634	19642	19686	19722	19730	19774	19810	19818	19863	19900	19908	19944	19952	19997	20035
	20043	20089	20135	20173	20181	20228	20267	20275	20313	20321	20361	20391	20402	20441	20480
	20519	20558	20597	20636	20673	20711	20747	20786	20866	20913	20953	21001	21047	21104	21144
	21192	21236	21328	21429	21473	21513	21519	21557	21636	21677	21727	21757	21771	21817	21859
	21935	21945	22019	22093	22144	22150	22194	22202	22208	22254	22262	22308	22316	22369	22379
	22388	22451	22460	22533	22560	22642	22649	22693	22700	22762	22769	22839	22846	23142	23439
	23501	23508	23605	23612	23659	24351	24405	24442	24460	24538	25764	25917	25925	25986	25994
	26059	26067	26129	26137	26197	26249	26286	26303	26350	26363	26366	26379	26463	26534	26569
	26573	26577	26641	26661	26666	26672	26677	26682	26688	26693	26703				
BGE	8540	8572	8603	8636											
BGT	8797	8833	8866	8896	8929	8962	8995	9027							
BHI	9221	9253	9286	9318											
BHIS	9480	9512													
BIC	6145	6180	6216	8003	8004	18820	18864	19226	19271	19631	19675	20032	20078	22567	22569
	22598	22602	22644	22657	22695	22708	22760	22837	22889	22893	22923	22927	22957	22961	22991
	22995	23025	23029	23059	23063	23091	23095	23123	23127	23158	23162	23190	23194	23224	23228
	23259	23263	23292	23296	23325	23329	23358	23362	23391	23395	23426	23487	26064	26403	26575
	26647	26708	26719												
BIS	6111	16304	16353	16401	16450	16505	16560	16615	16670	16725	16781	16836	16892	16947	17002
	17057	17112	17167	17223	17278	17334	17384	17434	17484	17534	17584	17637	17687	17737	18732
	18776	19136	19181	19542	19586	19941	19986	22557	22593	22635	22686	22884	22918	22952	22986
	23020	23054	23086	23118	23153	23185	23218	23253	23286	23319	23352	23385	23425	23478	23486
	26134	26879	26892	26906	26921	26934									
BISB	20358	20399	20438	20477	20516	20555	20594	20633	20670	20708	20744	20783	22750	22827	24942
BIT	5262	6254	6287	6392	7675	8022	8927	9961	11451	12850	14223	15983	17611	18909	18948
	18958	19316	19361	19719	19763	20124	20170	20390	21756	22509	22531	22641	22692	23141	23712
	23918	24297	24441	24537	24625	24669	24712	24793	25763	26271	26342	26344	26391	26451	26523
	26568	26572	26579	26648	26700	26702	26861	26880	26893	26907	26922	26935			
BLE	9059	9092	9124	9157	9189										
BLO	9544	9577													
BLOS	9350	9384	9417	9449											
BLT	8667	8700	8732	8764	26809										
BMI	3025	3083	3432	4707	5190	5229	7979	8056	8095	9613	9778	9800	9972	10068	10090
	10189	10281	10373	10465	10557	10602	10692	10782	10827	10873	10965	11011	11462	11550	11592
	11679	11722	11808	11851	11936	12022	12066	12154	12240	12325	12368	12411	12496	12588	12631
	12726	12770	12861	12905	12992	13080	13124	13212	13300	13387	13431	13475	13607	13696	13740
	14102	15074	15119	15254	15300	15441	15489	15537	15633	15724	15768	15857	15901	16389	16438
	16597	16652	16818	16874	17039	17094	17260	17316	17472	17522	17675	17725	18043	18778	18866
	18960	19050	19094	19183	19273	19363	19408	19499	19588	19677	19765	19854	19899	19988	20080
	20126	20219	20312	20826	20907	20995	21098	21186	21283	21379	21556	21983	22057	22[illegible]93	22368
	22743	22820	23428	23480	23489	24582	26205	26257							
BNE	3055	3205	3296	3324	3361	3393	3504	3537	3692	3720	3790	3827	3892	3921	4160
	4184	4210	4419	4488	4643	6015	6081	6256	7830	7881	7981	7988	7996	7998	8023
	8025	8136	8167	9614	9779	9801	9973	10069	10091	10190	10374	10603	10693	10874	10966
	11463	11551	11593	11680	11723	11809	11937	12023	12155	12241	12326	12497	12589	12632	12727
	12771	12862	12993	13081	13213	13301	13388	13608	13697	13741	14103	15075	15120	15255	15301
	15442	15490	15725	15858	16390	16439	16598	16653	16819	16875	17040	17095	17261	17317	17473
	17523	17676	17726	18044	18779	18867	18961	19051	19184	19274	19364	19409	19589	19678	19766
	19855	19989	20081	20127	20220	20825	20906	20994	21097	21185	21282	21378	21595	21982	22056
	22136	22441	22511	22596	22745	22822	22887	22921	22955	22989	23023	23057	23089	23121	23156
	23188	23221	23256	23289	23322	23355	23388	23430	23482	23491	23666	23919	24298	24511	24555
	24599	24626	24643	24670	24687	24713	24730	24772	24799	24816	24858	26272	26300	26343	26345

	26352	26388	26392	26449	26452	26521	26524	26580	26582	26649	26651	26701	26754	26759	26800
	26806	26859	26862	26871	26881	26894	26908	26923	26936						
BPL	3054	3171	3360	3392	3503	3536	4292	4321	4675	4823	8195	8227	9693	9886	10019
	10143	10235	10327	10419	10511	10647	10737	10919	11057	11506	11635	11765	11893	11979	12110
	12197	12282	12453	12543	12681	12814	12948	13036	13168	13256	13343	13518	13563	13652	14146
	15164	15209	15346	15392	15585	15679	15813	15946	15997	16292	16341	16497	16542	16707	16763
	16929	16984	17149	17205	17372	17422	17572	17625	17996	18734	18822	18911	19005	19138	19228
	19318	19454	19544	19633	19721	19809	19943	20034	20172	20266	20867	20954	21048	21145	21237
	21329	21430	21594	22020	22094	22135	22440	22477	22504	22526	22547	22582	22874	22908	22942
	22976	23010	23044	23208	23243	23416	23465	26712	26814						
BPT	23556	24098	24131												
BR	2974	2996	2998	3002	3032	3061	3090	3117	3146	3175	3209	3238	3269	3299	3327
	3334	3366	3398	3405	3435	3441	3471	3478	3509	3542	3549	3579	3606	3609	3634
	3637	3666	3695	3723	3754	3761	3793	3800	3830	3837	3866	3895	3924	3955	3985
	3992	4023	4054	4084	4113	4141	4147	4187	4212	4215	4241	4265	4268	4294	4297
	4324	4358	4390	4423	4454	4460	4491	4497	4530	4563	4600	4635	4678	4710	4716
	4749	4756	4788	4794	4826	4832	4840	4875	4909	4942	4976	5011	5043	5049	5081
	5087	5118	5124	5156	5162	5193	5201	5232	5240	5274	5282	5313	5321	5358	5393
	5428	5463	5494	5497	5503	5536	5564	5600	5634	5669	5675	5711	5717	5752	5787
	5793	5826	5832	5866	5901	5938	5944	5978	5985	6018	6051	6084	6118	6152	6186
	6225	6259	6292	6299	6333	6369	6409	6415	6422	6455	6461	6467	6475	6509	6515
	6521	6529	6563	6569	6575	6583	6617	6623	6629	6637	6675	6681	6718	6724	6761
	6767	6803	6809	6845	6851	6888	6894	6930	6936	6973	6979	7014	7020	7055	7061
	7099	7106	7112	7154	7161	7167	7204	7238	7272	7307	7337	7343	7372	7378	7410
	7418	7424	7461	7495	7503	7510	7517	7554	7589	7597	7604	7611	7649	7691	7727
	7764	7805	7843	7847	7885	7918	7951	7984	7999	8006	8059	8137	8196	8259	8324
	8423	8500	8573	8604	8668	8765	8798	8834	8867	8930	8963	8996	9060	9190	9254
	9287	9319	9351	9513	9545	20821	20862	20902	20949	20990	21005	21043	21052	21088	21090
	21093	21140	21181	21196	21232	21241	21278	21287	21324	21333	21370	21374	21383	21421	21425
	21434	21682	21721	21776	21864	21897	21901	21932	21939	21941	21949	22133	22191	22250	22304
	22358	22366	22385	22430	22438	22457	22486	22746	22758	22766	22775	22823	22835	22843	22852
	23222	23257	23290	23323	23356	23389	23431	23442	23483	23492	23505	23512	23519	23525	23689
	23714	23739	23825	23867	23912	23983	24044	24072	24075	24104	24107	24137	24140	24295	24348
	24402	24457	25631	25773	25812	25856	25859	25860	25933	25936	26002	26005	26075	26078	26145
	26148	26202	26207	26254	26259	26368	26382	26469	26541	26578	26750	26811	26884	26897	26911
	26926	26939													
BVC	3056	3362	3394	3505	3538	8258	8292	10329	10513	10604	10694	10739	10784	10875	10967
	11013	11059	11767	11853	11938	11981	12068	12112	12199	12370	12816	12907	12994	13038	13126
	13170	13258	13433	13654	14148	15635	15770	15903	19096	19501	19901	20314	20824	20905	20993
	21096	21184	21281	21377	21596	21981	22055	22137	22442						
BVS	3027	3085	8057	8100	9615	9695	9780	9802	9888	9974	10021	10070	10092	10145	10191
	10237	10283	10375	10421	10467	10559	10649	10829	10921	11464	11508	11552	11594	11637	11681
	11724	11810	11895	12024	12156	12242	12284	12327	12413	12455	12498	12545	12590	12633	12683
	12728	12772	12863	12950	13082	13214	13302	13345	13389	13477	13520	13565	13609	13698	13742
	14104	15076	15121	15166	15211	15256	15302	15348	15394	15443	15491	15539	15587	15681	15726
	15815	15859	15948	15999	16294	16343	16391	16440	16489	16544	16599	16654	16709	16765	16820
	16876	16931	16986	17041	17096	17151	17207	17262	17318	17374	17424	17474	17524	17574	17627
	17677	17727	17998	18045	18736	18780	18824	18868	18913	18962	19007	19052	19140	19185	19230
	19275	19320	19365	19410	19456	19546	19590	19635	19679	19723	19767	19811	19856	19945	19990
	20036	20082	20128	20174	20221	20268	20865	20952	21046	21143	21235	21327	21428	21558	22018
	22092	22195	22370	25596											
CCC	3081	3110	3138	3167	3200	3230	3260	3356	3388	3428	3464	3499	3532	3601	3659
	3747	3859	4015	4046	4076	4105	4182	4261	4319	4382	4447	4521	4554	4591	4626
	4670	4702	4742	4781	4866	4900	4934	4967	5002	5036	5111	5186	5225	5267	5306
	5347	5385	5419	5454	5489	5528	5559	5591	5626	5660	5702	5743	5778	5818	5858
	5893	5929	5971	6044	6109	6143	6178	6214	6285	6324	6360	6401	6448	6502	6556

	6610	6666	6709	6752	6794	6836	6879	6921	6964	7006	7047	7091	7146	7195	7229
	7263	7298	7332	7367	7405	7490	7546	7584	7683	7719	7756	7797	7836	7875	7910
	7943	8053	8461	8498	8538	8569	8600	8633	8665	8697	8729	8761	8794	8830	8863
	8894	8926	8959	8992	9024	9057	9089	9121	9154	9186	9219	9250	9283	9315	9348
	9321	9414	9446	9478	9509	9542	9574	9608	9654	9735	9773	9795	9847	9927	9967
	10014	10063	10085	10138	10184	10230	10276	10322	10368	10414	10460	10506	10552	10597	10642
	10687	10732	10777	10822	10868	10914	10960	11006	11052	11098	11145	11188	11278	11367	11457
	11501	11545	11588	11630	11674	11717	11760	11803	11846	11889	11931	11974	12017	12061	12105
	12149	12192	12235	12277	12320	12363	12406	12448	12491	12538	12583	12627	12676	12721	12765
	12809	12856	12900	12944	12987	13031	13075	13119	13163	13207	13251	13295	13338	13382	13426
	13470	13513	13558	13602	13647	13691	13735	13781	13825	13861	13903	13940	13983	14019	14061
	14097	14141	14185	14230	14273	14315	14358	14400	14437	14473	14510	14548	14594	14640	14686
	14732	14778	14824	14870	14917	14956	14995	15034	15069	15114	15159	15204	15249	15295	15341
	15387	15436	15484	15532	15580	15628	15674	15719	15764	15808	15852	15897	15941	15992	16037
	16080	16123	16166	16210	16248	16287	16336	16384	16433	16482	16537	16592	16647	16702	16758
	16813	16869	16924	16979	17034	17089	17144	17200	17255	17311	17367	17417	17467	17517	17567
	17620	17670	17720	17767	17804	17841	17879	17916	17955	17991	18038	18085	18120	18157	18198
	18241	18280	18325	18371	18416	18461	18500	18540	18578	18616	18654	18693	18729	18773	18817
	18861	18906	18955	19000	19045	19090	19133	19178	19223	19268	19313	19358	19403	19449	19495
	19539	19583	19628	19672	19716	19760	19804	19849	19895	19938	19983	20029	20075	20121	20167
	20214	20261	20308	20356	20397	20436	20475	20514	20553	20592	20631	20668	20706	20742	20781
	20856	20943	21037	21134	21226	21318	21415	21464	21505	21549	21627	21668	21714	21762	21808
	21849	21903	21937	22013	22087	22185	22298	22350	22482	22507	22529	22555	22591	22687	22826
	22882	22916	22950	22984	23018	23052	23084	23116	23151	23183	23216	23251	23284	23317	23350
	23383	23432	23493	23554	23594	23648	23685	23710	23735	23775	23799	23808	23817	23842	23851
	23859	23886	23895	23904	23944	23954	23964	23974	24005	24015	24025	24035	24064	24096	24129
	24175	24213	24250	24287	24337	24391	24446	24501	24545	24589	24633	24677	24720	24762	24806
	24848	24903	24939	24976	25011	25047	25085	25123	25158	25193	25229	25266	25301	25339	25375
	25410	25445	25483	25521	25558	25593	25628	25665	25732	25771	25808	25849	25920	25989	26062
	26132	26191	26243												
CLC	8353														
CLN	8225														
CLR	3112	3137	3166	3199	3229	3258	3294	3322	3387	3425	3426	3461	3463	3531	3571
	3887	3915	3945	3946	3975	3976	4013	4014	4043	4158	4289	4318	4348	4349	4481
	4520	4553	4740	4741	4779	4780	4863	4865	4932	4966	4999	5004	5384	5418	5453
	5488	5527	5590	5625	5659	5701	5742	5777	5817	5857	5887	5892	5928	6009	6076
	6108	6176	6283	6284	6359	7005	7046	7194	7228	7262	7297	7404	7448	7489	7543
	7545	7583	7638	7681	7682	7717	7718	7754	7795	7828	7873	7909	7990	8015	8030
	9605	9651	9688	9734	9771	9844	9881	9926	10182	10183	10366	10367	10595	10685	10866
	10958	11455	11456	11498	11543	11548	11586	11590	11672	11715	11801	11888	11929	12015	12016
	12147	12148	12233	12318	12447	12489	12490	12535	12581	12586	12625	12629	12719	12763	12854
	12943	12985	13073	13074	13205	13206	13293	13380	13512	14094	14184	14229	14272	14314	14357
	14399	14436	14472	14509	14547	14593	14639	14685	14731	14777	14823	14869	14916	14955	14994
	15033	15066	15068	15110	15245	15246	15248	15291	15433	15481	15673	15716	15807	15849	16281
	16286	16303	16330	16335	16352	16378	16382	16400	16427	16431	16449	16476	16481	16504	16531
	16536	16559	16586	16590	16614	16641	16645	16669	16696	16701	16724	16752	16757	16780	16807
	16811	16835	16863	16867	16891	16918	16923	16946	16973	16978	17001	17028	17032	17056	17083
	17087	17111	17138	17143	17166	17194	17199	17222	17249	17253	17277	17305	17309	17333	17361
	17366	17383	17411	17416	17433	17461	17465	17483	17511	17515	17533	17561	17566	17583	17614
	17619	17636	17664	17668	17686	17714	17718	17736	17766	17803	17840	17878	17915	17954	17990
	18034	18036	18081	18083	18156	18195	18240	18278	18323	18369	18414	18459	18498	18539	18577
	18615	18653	18692	18770	18771	18772	18858	18859	18860	18998	19175	19176	19177	19265	19266
	19267	19447	19580	19582	19669	19671	20355	20396	20434	20473	20513	20552	20591	20630	20667
	20705	20741	20780	21503	22243	22568	22586	22589	22590	22604	22606	22656	22707	22739	22740
	22755	22781	22782	22784	22816	22817	22832	22858	22859	22861	22880	22895	22897	22914	22929
	22931	22948	22963	22965	22982	22997	22999	23016	23031	23033	23050	23065	23067	23082	23097

	23099	23114	23129	23131	23149	23164	23166	23181	23196	23198	23214	23230	23232	23249	23265
	23267	23282	23298	23300	23315	23331	23333	23348	23364	23366	23381	23397	23399	23422	23423
	23434	23437	23444	23450	23475	23476	23477	23485	23495	23498	23499	23515	23516	23521	23522
	23527	23528	23533	23535	23537	23785	23946	23956	23966	23976	23988	24049	24304	24336	24343
	24354	24397	24408	24452	24463	24497	24541	24585	24629	24673	24716	24758	24802	24844	26187
	26188	26189	26239	26240	26241	26298	26386	26744	26757	26860	26918	26919			
CLRB	13694	13738	13783	13827	13863	13905									
CLV	8290														
CLZ	8166														
CMP	3574	3603	3631	3661	3690	3718	3749	3788	3825	3861	3890	3919	3951	3981	4080
	4109	4143	4159	4354	4384	4417	4449	4456	4486	4493	4525	4558	4595	4630	4642
	4711	4751	4790	4828	4834	4870	4904	4971	5006	5045	5083	5120	5158	5195	5234
	5276	5315	5351	5389	5423	5458	5493	5499	5531	5595	5630	5664	5671	5706	5713
	5747	5782	5789	5822	5828	5862	5897	5933	5940	5973	5980	6013	6046	6079	6113
	6147	6182	6220	6294	6328	6364	6411	6417	6457	6463	6469	6511	6517	6523	6565
	6571	6577	6619	6625	6631	6670	6677	6713	6720	6756	6763	6798	6805	6840	6847
	6883	6890	6925	6932	6968	6975	7010	7016	7051	7057	7095	7101	7108	7150	7156
	7163	7199	7233	7267	7302	7339	7374	7413	7420	7456	7498	7505	7592	7599	7877
	7912	7945	8389	8429	9814	9894	9980	10027	10076	10098	10104	10151	10197	10243	10289
	10335	10381	10427	10473	10519	10565	10610	10655	10700	10745	10790	10835	10881	10927	10973
	11019	11065	11107	11113	11155	11197	11203	11245	11287	11293	11335	11376	11382	11423	11470
	11514	11557	11599	11642	11686	11729	11772	11815	11858	11900	11943	11986	12029	12073	12117
	12161	12204	12247	12289	12332	12375	12418	12460	12504	12551	12595	12638	12644	12688	12733
	12777	12821	12868	12912	12955	12999	13043	13087	13131	13175	13219	13263	13307	13350	13394
	13438	13482	13525	13571	13615	13660	13704	13748	13785	13791	13829	13865	13871	13907	13944
	13950	13987	14023	14029	14065	14110	14154	14189	14195	14234	14240	14277	14283	14319	14325
	14362	14368	14404	14441	14477	14514	14552	14561	14598	14607	14644	14653	14690	14699	14736
	14745	14782	14791	14828	14837	14874	14883	14921	14960	14999	15038	15082	15127	15172	15217
	15262	15308	15354	15400	15449	15497	15545	15593	15641	15687	15732	15776	15821	15865	15909
	15954	16005	16041	16048	16084	16091	16127	16134	16170	16177	16214	16252	16300	16349	16397
	16446	16495	16501	16550	16556	16605	16611	16660	16666	16715	16721	16771	16777	16826	16832
	16882	16888	16937	16943	16992	16998	17047	17053	17102	17108	17157	17163	17213	17219	17268
	17274	17324	17330	17380	17430	17480	17530	17580	17633	17683	17733	17771	17808	17845	17883
	17920	17959	18004	18051	18089	18124	18161	18167	18202	18208	18245	18284	18291	18329	18335
	18375	18381	18420	18426	18465	18504	18544	18582	18620	18658	18697	18742	18786	18830	18874
	18919	18968	19003	19013	19048	19058	19092	19102	19146	19191	19236	19281	19326	19371	19406
	19416	19452	19462	19497	19507	19552	19596	19641	19685	19729	19773	19807	19817	19852	19862
	19897	19907	19951	19996	20042	20088	20134	20180	20217	20227	20264	20274	20310	20320	20360
	20401	20440	20479	20518	20557	20596	20635	20672	20710	20746	20785	20912	21000	21103	21191
	21472	21512	21518	21635	21676	21726	21770	21816	21858	22143	22149	22201	22207	22253	22261
	22307	22315	22378	22387	22450	22459	22559	22648	22699	22761	22768	22838	22845	23604	23611
	23658	23687	24350	24404	24459	24510	24554	24598	24642	24686	24729	24771	24815	24857	25916
	25924	25935	25985	25993	26004	26058	26066	26077	26128	26136	26147	26196	26248	26299	26362
	26365	26378	26462	26533	26576	26640	26660	26665	26671	26676	26681	26687	26692		
CMPB	6403	6450	6504	6558	6612	7995	26349	26805							
COM	3169	3202	3234	3259	3264	3358	3390	3400	3427	3437	3462	3473	3544	3756	3795
	3832	3987	4044	4121	4123	4125	4127	4129	4136	4864	4868	5888	6177	7550	7687
	7723	7760	7801	8026	9702	11499	11633	11677	12536	12679	12724	16282	16331	16383	16432
	16477	16532	16591	16646	16697	16753	16812	16868	16919	16974	17033	17088	17139	17195	17254
	17310	17362	17412	17466	17516	17562	17615	17669	17719	18037	18084	23436	23497	23514	26355
	26445	26517	26563	26637	26656	26790									
DEC	4936	4969	7829	7880	7980	7987	7997	11806	11849	11891	12859	12903	12946	22595	22744
	22821	22886	22920	22954	22988	23022	23056	23088	23120	23155	23187	23220	23255	23288	23321
	23354	23387	23429	23481	23490	26206	26258	26387	26581	26753	26758				
DECB	5349	26808													
EMT	2928	2929	2930	2931	2932	2933	2934	2935							

FADD	26905														
HALT	2607	2614	2621	2623	2630	2637	2644	2651	2653	2655	2657	2659	2661	2663	2665
	2667	2669	2671	2673	2675	2677	2679	2681	2683	2685	2687	2689	2691	2693	2695
	2697	2699	2702	2704	2706	2708	2710	2712	2714	2716	2718	2720	2722	2724	2726
	2728	2730	2732	2734	2736	2738	2740	2742	2744	2746	2748	2750	2752	2754	2756
	2758	2760	2762	2764	2766	2768	2770	2772	2774	2776	2778	2780	2782	2784	2786
	2788	2790	2792	2794	2796	2798	2800	2802	2804	2806	2808	2810	2812	2814	2816
	2818	2820	2822	2824	2826	2828	2830	2832	2834	2836	2838	2840	2842	2844	2846
	2848	2850	2852	2854	2856	2858	2860	2862	2864	2866	2868	2870	2872	2874	2876
	2878	2880	2882	2884	2886	2888	2890	2976	3000	3004	3030	3059	3088	3116	3144
	3174	3208	3237	3268	3298	3326	3333	3365	3397	3404	3434	3440	3470	3477	3508
	3541	3548	3578	3608	3636	3665	3694	3722	3753	3760	3792	3799	3829	3836	3865
	3894	3923	3954	3984	3991	4022	4053	4083	4112	4140	4146	4186	4214	4240	4267
	4296	4323	4357	4389	4422	4453	4459	4490	4496	4529	4562	4599	4634	4677	4709
	4715	4748	4755	4787	4793	4825	4831	4838	4874	4908	4941	4975	5010	5042	5048
	5080	5086	5117	5123	5155	5161	5192	5199	5231	5238	5264	5273	5280	5312	5319
	5357	5392	5427	5462	5496	5502	5535	5563	5599	5633	5668	5674	5710	5716	5751
	5786	5792	5825	5831	5865	5900	5937	5943	5977	5984	6017	6050	6083	6117	6151
	6185	6224	6258	6291	6298	6332	6368	6394	6408	6414	6421	6454	6460	6466	6473
	6508	6514	6520	6527	6562	6568	6574	6581	6616	6622	6628	6635	6674	6680	6717
	6723	6760	6766	6802	6808	6844	6850	6887	6893	6929	6935	6972	6978	7013	7019
	7054	7060	7098	7105	7111	7153	7160	7166	[illegible]	7237	7271	7306	7336	7342	7371
	7377	7409	7417	7423	7460	7494	7502	7509	7516	7553	7568	7596	7603	7610	7648
	7677	7690	7726	7763	7804	7846	7884	7917	7950	7983	8005	8829	9963	11453	12852
	14225	15985	17613	18950	20392	21758	23143	23914	23915	23916	24539	25765	26381	26468	26540
	26713														
INC	4902	5356	11720	11763	12768	12812	21934	24509	24553	24597	24641	24685	24728	24770	24814
	24856	26204	26256	26270	26364	26367	26377	26380	26464	26535	26642				
INCB	26450	26467	26522	26539											
ICT	2924	7492	7586	7642											
JMP	20817	20858	20898	20945	20986	21039	21084	21136	21177	21228	21274	21320	21366	21417	23888
	23897	23906	24215	25561	26308	26395	26466	26537							
JSR	7369	8029	21466	21507	21551	21589	21629	21670	21716	21764	21810	21851	24066	24177	26269
	26276	26282	26288	26304	26357	26457	26528	26659	26664	26670	26675	26680	26685	26691	26696
	26725	26742	26760	26804	26810	26865	26866	26867	26868	26869					
MARK	22352	22424	25852												
MOV	2700	3232	3262	3290	3291	3319	3355	3386	3430	3466	3501	3529	3530	3534	3570
	3658	3687	3715	3744	3745	3746	3783	3784	3785	3820	3821	3822	3857	3858	3886
	3916	3944	3949	3974	3979	4045	4074	4075	4103	4104	4119	4120	4122	4124	4126
	4128	4154	4155	4156	4157	4161	4181	4207	4235	4260	4288	4317	4344	4345	4346
	4347	4352	4378	4379	4380	4381	4388	4411	4412	4413	4414	4421	4443	4444	4445
	4446	4480	4482	4483	4517	4518	4519	4523	4528	4550	4551	4552	4556	4561	4586
	4587	4588	4589	4590	4598	4621	4622	4623	4624	4625	4633	4639	4640	4641	4663
	4665	4666	4667	4668	4669	4697	4699	4700	4701	4714	4737	4739	4754	4776	4778
	4814	4816	4817	4818	4837	4839	4860	4862	4873	4895	4897	4898	4899	4907	4929
	4931	4933	4962	4964	4965	4974	4996	4998	5000	5001	5009	5031	5033	5034	5035
	5069	5071	5072	5073	5106	5108	5109	5110	5144	5146	5147	5148	5182	5184	5185
	5198	5200	5220	5222	5223	5224	5237	5239	5260	5265	5266	5279	5281	5302	5304
	5305	5318	5320	5341	5343	5344	5345	5346	5354	5355	5360	5380	5382	5383	5387
	5413	5415	5416	5417	5421	5426	5448	5450	5451	5452	5456	5461	5483	5485	5486
	5487	5491	5523	5525	5526	5530	5534	5556	5558	5561	5586	5588	5589	5593	5598
	5620	5622	5623	5624	5628	5654	5656	5657	5658	5662	5667	5696	5698	5699	5700
	5704	5709	5737	5739	5740	5741	5745	5750	5772	5774	5775	5776	5780	5785	5812
	5814	5815	5816	5820	5852	5854	5855	5856	5860	5885	5889	5890	5891	5895	5922
	5924	5925	5926	5927	5931	5936	5965	5967	5968	5969	5970	5983	6005	6007	6008
	6010	6039	6041	6042	6043	6072	6074	6075	6104	6106	6107	6116	6138	6140	6141

6142	6150	6172	6174	6175	6207	6209	6210	6211	6212	6218	6223	6227	6247	6249
6250	6251	6280	6282	6297	6319	6321	6322	6323	6331	6354	6356	6357	6358	6367
6390	6395	6396	6397	6399	6400	6407	6420	6442	6444	6445	6446	6447	6472	6474
6496	6498	6499	6500	6501	6526	6528	6550	6552	6553	6554	6555	6580	6582	6604
6606	6607	6608	6609	6634	6636	6659	6661	6662	6663	6664	6665	6673	6702	6704
6705	6706	6707	6708	6716	6745	6747	6748	6749	6750	6751	6759	6787	6789	6790
6791	6792	6793	6801	6829	6831	6832	6833	6834	6835	6843	6872	6874	6875	6876
6877	6878	6886	6914	6916	6917	6918	6919	6920	6928	6957	6959	6960	6961	6962
6963	6971	7000	7002	7003	7004	7041	7043	7044	7045	7082	7084	7085	7086	7087
7088	7089	7104	7114	7137	7139	7140	7141	7142	7143	7144	7159	7169	7189	7191
7192	7193	7202	7223	7225	7226	7227	7236	7257	7259	7260	7261	7270	7292	7294
7295	7296	7305	7327	7329	7330	7331	7363	7365	7366	7398	7400	7401	7402	7403
7412	7416	7444	7446	7447	7449	7450	7455	7459	7482	7484	7485	7486	7487	7488
7497	7501	7508	7515	7539	7541	7542	7544	7556	7576	7578	7579	7580	7581	7582
7591	7595	7602	7609	7633	7635	7636	7637	7639	7644	7647	7651	7673	7678	7679
7680	7712	7714	7715	7716	7747	7749	7750	7751	7752	7753	7766	7767	7788	7790
7791	7792	7793	7794	7826	7831	7832	7833	7834	7835	7849	7850	7869	7871	7872
7874	7883	7905	7907	7908	7916	7938	7940	7941	7942	7949	7966	7968	7971	7972
7973	7974	7976	7991	7992	7993	8014	8016	8017	8018	8019	8020	8021	8031	8051
8052	8085	8086	8131	8132	8163	8164	8190	8191	8222	8223	8253	8254	8287	8288
8318	8319	8350	8351	8381	8382	8388	8392	8418	8419	8428	8432	8458	8459	8465
8469	8495	8496	8505	8509	8535	8536	8566	8567	8597	8598	8630	8631	8662	8663
8694	8695	8726	8727	8758	8759	8791	8792	8824	8825	8860	8861	8891	8892	8923
8924	8956	8957	8989	8990	9021	9022	9054	9055	9086	9087	9118	9119	9151	9152
9183	9184	9216	9217	9247	9248	9280	9281	9312	9313	9345	9346	9378	9379	9411
9412	9443	9444	9475	9476	9506	9507	9539	9540	9571	9572	9603	9604	9606	9607
9648	9649	9652	9653	9683	9684	9686	9687	9701	9729	9730	9732	9733	9767	9768
9770	9772	9792	9793	9794	9841	9842	9845	9846	9876	9877	9879	9880	9921	9922
9924	9925	9958	9959	9964	9965	9966	10008	10009	10011	10012	10013	10057	10058	10060
10061	10062	10082	10083	10084	10132	10133	10135	10136	10137	10178	10179	10181	10224	10225
10227	10228	10229	10270	10271	10273	10274	10275	10316	10317	10319	10320	10321	10362	10363
10365	10408	10409	10411	10412	10413	10454	10455	10457	10458	10459	10500	10501	10503	10504
10505	10547	10548	10549	10550	10551	10592	10593	10594	10596	10637	10638	10639	10640	10641
10682	10683	10684	10686	10727	10728	10729	10730	10731	10772	10773	10774	10775	10776	10817
10818	10819	10820	10821	10838	10863	10864	10865	10867	10884	10909	10910	10911	10912	10913
10930	10955	10956	10957	10959	10976	11001	11002	11003	11004	11005	11022	11047	11048	11049
11050	11051	11068	11092	11093	11094	11095	11096	11097	11116	11139	11140	11141	11142	11143
11144	11158	11181	11182	11183	11184	11185	11186	11187	11206	11229	11230	11231	11232	11233
11234	11235	11248	11271	11272	11273	11274	11275	11276	11277	11296	11319	11320	11321	11322
11323	11324	11325	11338	11361	11362	11363	11364	11365	11366	11385	11408	11409	11410	11411
11412	11413	11426	11449	11450	11454	11495	11496	11497	11500	11540	11541	11542	11544	11583
11584	11585	11587	11625	11626	11627	11628	11629	11669	11670	11671	11673	11712	11713	11714
11716	11755	11756	11757	11758	11759	11798	11799	11800	11802	11841	11842	11843	11844	11845
11884	11885	11886	11887	11926	11927	11928	11930	11969	11970	11971	11972	11973	12012	12013
12014	12056	12057	12058	12059	12060	12100	12101	12102	12103	12104	12144	12145	12146	12187
12188	12189	12190	12191	12230	12231	12232	12234	12272	12273	12274	12275	12276	12315	12316
12317	12319	12358	12359	12360	12361	12362	12401	12402	12403	12404	12405	12443	12444	12445
12446	12486	12487	12488	12507	12532	12533	12534	12537	12554	12578	12579	12580	12582	12598
12622	12623	12624	12626	12647	12671	12672	12673	12674	12675	12691	12716	12717	12718	12720
12736	12760	12761	12762	12764	12780	12804	12805	12806	12807	12808	12824	12848	12849	12853
12855	12871	12895	12896	12897	12898	12899	12915	12939	12940	12941	12942	12958	12982	12983
12984	12986	13002	13026	13027	13028	13029	13030	13046	13070	13071	13072	13090	13114	13115
13116	13117	13118	13134	13158	13159	13160	13161	13162	13178	13202	13203	13204	13222	13246
13247	13248	13249	13250	13266	13290	13291	13292	13294	13310	13333	13334	13335	13336	13337
13353	13377	13378	13379	13381	13397	13421	13422	13423	13424	13425	13441	13465	13466	13467
13468	13469	13485	13508	13509	13510	13511	13528	13553	13554	13555	13556	13557	13597	13598

13599	13600	13601	13642	13643	13644	13645	13646	13686	13687	13688	13689	13690	13730	13731
13732	13733	13734	13774	13775	13776	13777	13778	13779	13780	13794	13818	13819	13820	13821
13822	13823	13824	13832	13855	13856	13857	13858	13859	13860	13874	13897	13898	13899	13900
13901	13902	13910	13933	13934	13935	13936	13937	13938	13939	13953	13976	13977	13978	13979
13980	13981	13982	13990	14013	14014	14015	14016	14017	14018	14032	14055	14056	14057	14058
14059	14060	14068	14091	14092	14093	14095	14096	14135	14136	14137	14138	14139	14140	14179
14180	14181	14182	14183	14221	14222	14226	14227	14228	14266	14267	14268	14269	14270	14271
14309	14310	14311	14312	14313	14351	14352	14353	14354	14355	14356	14394	14395	14396	14397
14398	14430	14431	14432	14433	14434	14435	14467	14468	14469	14470	14471	14480	14504	14505
14506	14507	14508	14517	14541	14542	14543	14544	14545	14546	14555	14556	14560	14587	14588
14589	14590	14591	14592	14601	14602	14606	14633	14634	14635	14636	14637	14638	14647	14648
14652	14679	14680	14681	14682	14683	14684	14693	14694	14698	14725	14726	14727	14728	14729
14730	14739	14740	14744	14771	14772	14773	14774	14775	14776	14785	14786	14790	14817	14818
14819	14820	14821	14822	14831	14832	14836	14863	14864	14865	14866	14867	14868	14877	14878
14882	14910	14911	14912	14913	14914	14915	14924	14949	14950	14951	14952	14953	14954	14963
14988	14989	14990	14991	14992	14993	15002	15027	15028	15029	15030	15031	15032	15041	15064
15065	15067	15108	15109	15111	15112	15113	15153	15154	15155	15156	15157	15158	15198	15199
15200	15201	15202	15203	15243	15244	15247	15265	15289	15290	15292	15293	15294	15311	15335
15336	15337	15338	15339	15340	15357	15381	15382	15383	15384	15385	15386	15403	15429	15430
15432	15434	15435	15477	15478	15480	15482	15483	15525	15526	15528	15529	15530	15531	15573
15574	15576	15577	15578	15579	15621	15622	15624	15625	15626	15627	15668	15669	15670	15671
15672	15690	15713	15714	15715	15717	15718	15735	15758	15759	15760	15761	15762	15763	15779
15802	15803	15804	15805	15806	15846	15847	15848	15850	15851	15890	15891	15892	15893	15894
15895	15896	15934	15935	15936	15937	15938	15939	15940	15957	15981	15982	15986	15987	15988
15989	15990	15991	16008	16031	16032	16033	16034	16035	16036	16044	16074	16075	16076	16077
16078	16079	16087	16117	16118	16119	16120	16121	16122	16130	16160	16161	16162	16163	16164
16165	16173	16204	16205	16206	16207	16208	16209	16217	16242	16243	16244	16245	16246	16247
16255	16279	16280	16283	16284	16285	16290	16328	16329	16332	16333	16334	16339	16376	16377
16379	16380	16381	16387	16425	16426	16428	16429	16430	16436	16474	16475	16478	16479	16480
16485	16529	16530	16533	16534	16535	16540	16584	16585	16587	16588	16589	16595	16639	16640
16642	16643	16644	16650	16694	16695	16698	16699	16700	16705	16750	16751	16754	16755	16756
16761	16805	16806	16808	16809	16810	16816	16861	16862	16864	16865	16866	16872	16916	16917
16920	16921	16922	16927	16971	16972	16975	16976	16977	16982	17026	17027	17029	17030	17031
17037	17081	17082	17084	17085	17086	17092	17136	17137	17140	17141	17142	17147	17192	17193
17196	17197	17198	17203	17247	17248	17250	17251	17252	17258	17303	17304	17306	17307	17308
17314	17359	17360	17363	17364	17365	17370	17409	17410	17413	17414	17415	17420	17459	17460
17462	17463	17464	17470	17509	17510	17512	17513	17514	17520	17559	17560	17563	17564	17565
17570	17609	17610	17616	17617	17618	17623	17662	17663	17665	17666	17667	17673	17712	17713
17715	17716	17717	17723	17761	17762	17763	17764	17765	17769	17774	17798	17799	17800	17801
17802	17806	17811	17835	17836	17837	17838	17839	17843	17848	17873	17874	17875	17876	17877
17881	17886	17910	17911	17912	17913	17914	17918	17923	17949	17950	17951	17952	17953	17957
17962	17985	17986	17987	17988	17989	18031	18032	18033	18035	18078	18079	18080	18082	18114
18115	18116	18117	18118	18119	18151	18152	18153	18154	18155	18192	18193	18194	18196	18197
18235	18236	18237	18238	18239	18248	18273	18274	18275	18276	18277	18279	18287	18318	18319
18320	18321	18322	18324	18338	18364	18365	18366	18367	18368	18370	18384	18409	18410	18411
18412	18413	18415	18429	18454	18455	18456	18457	18458	18460	18468	18493	18494	18495	18496
18497	18499	18507	18533	18534	18535	18536	18537	18538	18547	18571	18572	18573	18574	18575
18576	18585	18609	18610	18611	18612	18613	18614	18623	18647	18648	18649	18650	18651	18652
18661	18686	18687	18688	18689	18690	18691	18700	18723	18724	18725	18726	18727	18728	18767
18768	18769	18811	18812	18813	18814	18815	18816	18855	18856	18857	18900	18901	18902	18903
18904	18905	18922	18946	18947	18951	18952	18953	18954	18994	18995	18996	18997	18999	19039
19040	19041	19042	19043	19044	19084	19085	19086	19087	19088	19089	19127	19128	19129	19130
19131	19132	19149	19172	19173	19174	19194	19217	19218	19219	19220	19221	19222	19239	19262
19263	19264	19284	19307	19308	19309	19310	19311	19312	19329	19352	19353	19354	19355	19356
19357	19374	19397	19398	19399	19400	19401	19402	19419	19443	19444	19445	19446	19448	19465
19489	19490	19491	19492	19493	19494	19510	19533	19534	19535	19536	19537	19538	19577	19578

19579	19581	19621	19622	19623	19624	19625	19626	19627	19666	19667	19668	19670	19710	19711
19712	19713	19714	19715	19754	19755	19756	19757	19758	19759	19798	19799	19800	19801	19802
19803	19843	19844	19845	19846	19847	19848	19888	19889	19890	19891	19892	19893	19894	19932
19933	19934	19935	19936	19937	19954	19977	19978	19979	19980	19981	19982	19999	20022	20023
20024	20025	20026	20027	20028	20045	20068	20069	20070	20071	20072	20073	20074	20091	20114
20115	20116	20117	20118	20119	20120	20137	20160	20161	20162	20163	20164	20165	20166	20183
20207	20208	20209	20210	20211	20212	20213	20230	20254	20255	20256	20257	20258	20259	20260
20277	20301	20302	20303	20304	20305	20306	20307	20323	20350	20351	20352	20353	20354	20388
20389	20393	20394	20395	20404	20429	20430	20431	20432	20433	20435	20443	20468	20469	20470
20471	20472	20474	20482	20507	20508	20509	20510	20511	20512	20521	20546	20547	20548	20549
20550	20551	20560	20585	20586	20587	20588	20589	20590	20599	20624	20625	20626	20627	20628
20629	20638	20662	20663	20664	20665	20666	20675	20699	20700	20701	20702	20703	20704	20713
20736	20737	20738	20739	20740	20749	20774	20775	20776	20777	20778	20779	20788	20811	20812
20814	20852	20853	20855	20878	20893	20895	20939	20940	20942	20980	20981	20983	21033	21034
21036	21079	21080	21081	21130	21131	21133	21171	21172	21174	21222	21223	21225	21268	21269
21271	21314	21315	21317	21360	21361	21363	21411	21412	21414	21460	21461	21462	21463	21479
21499	21500	21501	21502	21504	21524	21531	21546	21547	21548	21564	21569	21584	21585	21586
21601	21622	21623	21624	21625	21626	21642	21663	21664	21665	21666	21667	21688	21709	21710
21711	21712	21713	21733	21754	21755	21759	21760	21761	21782	21803	21804	21805	21806	21807
21823	21844	21845	21846	21847	21848	21870	21893	21894	21896	21927	21928	21930	21931	21972
21973	21975	22009	22010	22012	22046	22047	22049	22083	22084	22086	22120	22121	22122	22123
22124	22125	22126	22152	22153	22157	22178	22179	22180	22181	22182	22183	22184	22210	22211
22215	22236	22237	22238	22239	22240	22241	22242	22252	22264	22265	22269	22290	22291	22292
22293	22294	22295	22296	22297	22306	22318	22319	22323	22344	22345	22346	22347	22348	22349
22354	22362	22373	22374	22380	22381	22390	22391	22395	22416	22417	22418	22419	22420	22421
22426	22434	22445	22446	22452	22453	22462	22463	22467	22474	22475	22478	22479	22480	22481
22488	22492	22493	22501	22502	22505	22506	22513	22523	22524	22527	22528	22535	22544	22545
22548	22549	22550	22551	22552	22553	22554	22562	22570	22579	22580	22583	22584	22585	22587
22588	22603	22605	22630	22631	22632	22633	22634	22640	22651	22652	22681	22682	22683	22684
22685	22691	22702	22703	22732	22733	22734	22735	22736	22737	22738	22748	22754	22771	22772
22780	22783	22809	22810	22811	22812	22813	22814	22815	22825	22831	22848	22849	22857	22860
22871	22872	22875	22876	22877	22878	22879	22881	22894	22896	22905	22906	22909	22910	22911
22912	22913	22915	22928	22930	22939	22940	22943	22944	22945	22946	22947	22949	22962	22964
22973	22974	22977	22978	22979	22980	22981	22983	22996	22998	23007	23008	23011	23012	23013
23014	23015	23017	23030	23032	23041	23042	23045	23046	23047	23048	23049	23051	23064	23066
23075	23076	23077	23078	23079	23080	23081	23083	23096	23098	23107	23108	23109	23110	23111
23112	23113	23115	23128	23130	23139	23140	23144	23145	23146	23147	23148	23150	23163	23165
23174	23175	23176	23177	23178	23179	23180	23182	23195	23197	23205	23206	23209	23210	23211
23212	23213	23215	23229	23231	23240	23241	23244	23245	23246	23247	23248	23250	23264	23266
23275	23276	23277	23278	23279	23280	23281	23283	23297	23299	23308	23309	23310	23311	23312
23313	23314	23316	23330	23332	23341	23342	23343	23344	23345	23346	23347	23349	23363	23365
23374	23375	23376	23377	23378	23379	23380	23382	23396	23398	23413	23414	23417	23418	23419
23420	23421	23424	23448	23449	23462	23463	23466	23467	23468	23469	23470	23471	23472	23473
23474	23532	23534	23536	23549	23550	23551	23552	23553	23561	23562	23586	23587	23588	23589
23590	23591	23592	23593	23596	23598	23599	23603	23607	23614	23618	23619	23641	23642	23643
23644	23645	23646	23647	23650	23652	23653	23657	23661	23668	23672	23679	23680	23681	23682
23683	23684	23691	23692	23696	23697	23704	23705	23706	23707	23708	23709	23716	23717	23721
23722	23729	23730	23731	23732	23733	23734	23741	23742	23746	23747	23768	23769	23770	23771
23772	23773	23774	23779	23783	23784	23793	23794	23795	23797	23798	23806	23807	23815	23816
23824	23836	23837	23838	23840	23841	23849	23850	23857	23858	23866	23880	23881	23882	23884
23885	23893	23894	23902	23903	23911	23923	23929	23937	23938	23939	23940	23942	23943	23948
23952	23953	23958	23962	23963	23968	23972	23973	23978	23982	23985	23987	23989	23998	23999
24000	24001	24003	24004	24007	24009	24013	24014	24017	24019	24023	24024	24027	24029	24033
24034	24037	24039	24043	24046	24048	24050	24059	24060	24061	24062	24063	24068	24074	24077
24081	24089	24090	24091	24092	24093	24094	24095	24100	24106	24109	24113	24114	24122	24123
24124	24125	24126	24127	24128	24133	24139	24142	24146	24147	24168	24169	24170	24171	24172

	24173	24174	24179	24183	24184	24206	24207	24208	24209	24210	24211	24212	24217	24221	24222
	24243	24244	24245	24246	24247	24248	24249	24254	24257	24258	24280	24281	24282	24283	24284
	24285	24286	24303	24305	24331	24332	24333	24334	24335	24339	24342	24344	24345	24353	24355
	24356	24360	24385	24386	24387	24388	24389	24390	24393	24396	24398	24399	24407	24409	24410
	24414	24438	24439	24440	24443	24444	24445	24449	24451	24453	24454	24462	24464	24465	24469
	24472	24473	24494	24495	24496	24498	24499	24500	24513	24535	24536	24540	24542	24543	24544
	24557	24580	24583	24584	24586	24587	24588	24601	24624	24627	24628	24630	24631	24632	24645
	24668	24671	24672	24674	24675	24676	24689	24711	24714	24715	24717	24718	24719	24732	24755
	24756	24757	24759	24760	24761	24774	24797	24800	24801	24803	24804	24805	24818	24841	24842
	24843	24845	24846	24847	24860	24862	24863	24866	24867	24868	24897	24898	24899	24900	24901
	24902	24932	24933	24934	24935	24936	24937	24938	24969	24970	24971	24972	24973	24974	24975
	25005	25006	25007	25008	25009	25010	25041	25042	25043	25044	25045	25046	25078	25079	25080
	25081	25082	25083	25084	25116	25117	25118	25119	25120	25121	25122	25152	25153	25154	25155
	25156	25157	25187	25188	25189	25190	25191	25192	25223	25224	25225	25226	25227	25228	25259
	25260	25261	25262	25263	25264	25265	25269	25295	25296	25297	25298	25299	25300	25304	25332
	25333	25334	25335	25336	25337	25338	25342	25369	25370	25371	25372	25373	25374	25404	25405
	25406	25407	25408	25409	25439	25440	25441	25442	25443	25444	25476	25477	25478	25479	25480
	25481	25482	25514	25515	25516	25517	25518	25519	25520	25551	25552	25553	25554	25555	25556
	25557	25587	25588	25589	25590	25591	25592	25622	25623	25624	25625	25626	25627	25657	25658
	25659	25660	25661	25662	25691	25692	25693	25694	25695	25696	25725	25726	25727	25728	25729
	25730	25731	25761	25762	25766	25767	25768	25769	25770	25801	25802	25803	25804	25805	25806
	25807	25842	25843	25844	25845	25846	25847	25848	25858	25864	25913	25914	25918	25919	25927
	25928	25982	25983	25987	25988	25996	25997	26055	26056	26060	26061	26069	26070	26125	26126
	26130	26131	26139	26140	26186	26190	26238	26242	26267	26275	26281	26287	26295	26296	26297
	26302	26346	26347	26356	26375	26376	26384	26385	26389	26390	26455	26465	26527	26536	26570
	26574	26583	26584	26643	26644	26645	26646	26663	26668	26674	26679	26684	26686	26690	26695
	26699	26707	26743	26746	26749	26755	26794	26795	26802	26807	26826	26827	26828	26829	26830
	26831	26832	26844	26845	26846	26847	26848	26849	26850	26876	26877	26886	26889	26890	26899
	26902	26903	26904	26913	26916	26917	26928	26931	26932	26941					
MOVB	4593	4628	4664	4698	4738	4777	4815	4861	4896	4930	4963	4997	5032	5070	5107
	5145	5183	5221	5261	5303	5342	5381	5414	5449	5484	5524	5557	5587	5621	5655
	5697	5738	5773	5813	5853	5886	5923	5966	6006	6040	6073	6105	6139	6173	6208
	6248	6281	6320	6355	6391	6443	6497	6551	6605	6660	6668	6703	6711	6746	6754
	6788	6796	6830	6838	6873	6881	6915	6923	6958	6966	7001	7008	7042	7049	7083
	7093	7138	7148	7190	7197	7224	7231	7258	7265	7293	7300	7328	7364	7399	7445
	7483	7540	7577	7634	7674	7713	7748	7789	7827	7870	7906	7939	7967	7977	7986
	8001	8002	17994	18041	18087	18122	18159	18200	18243	18282	18327	18373	18418	18463	18502
	18542	18580	18618	18656	18695	23844	23853	23861	25378	26567	26756	26798	26817		
NEG	10187	10233	10279	10325	10371	10417	10463	10509	16039	16082	16125	16168	16212	16250	25050
NEGB	13561	13605	13650	13942	13985	14021	14063	23801	23810	23819	25524				
NOP	7451	21942	25816	25817	26305	26306	26307								
RESET	22638	22689	26301												
ROL	5113	5151	12064	12108	12152	13122	13166	13210	26748	26752					
ROR	10555	10600	10645	10690	10735	10780	10825	10871	10917	10963	11009	11055	25413	25486	
RORB	11100	11148	11190	11238	25448										
RTI	7407	7453	23828	23870	23921	23990	24051	26446	26518	26564	26571	26585	26638	26710	26721
	26791	26803													
RTS	7334	22129	22187	25735	26369	26728	26761	26818	26851	26874	26887	26900	26914	26929	26942
RTT	22246	22300	24288	24904	24940	24977	25012	25048	25086	25124	25159	25194	25230	25267	25302
	25340	25376	25411	25446	25484	25522	25559	25594	25629	25663	25697	25733	25772	25809	25850
	26404														
SBC	12323	12366	12409	12451	13385	13429	13473	13516							
SCC	3052	3292	3320	3629	3947	3977	4350	6011	6077	6252	7640	8088	8384	8421	9689
	9882	20815	20896	20984	21082	21175	21272	21364	21587	21976	22050	22127	22244	22422	22636
	22749	25699													
SEC	5074	5149	8321	92[illegible]1	9382	9510	9575	11146	11236	11326	11414				

SEN	4290	4819	8193	8601	8730	9155	10598	10688	10869	10961	11932	12988	18774	18862	18956
	19179	19269	19359	19584	19673	19761	19984	20076	20122						
SEV	8256	8570	8698	8831	9122	12018	12150	13076	13208						
SEZ	3688	3716	3786	3823	3888	3917	4208	4236	4415	4484	8134	8864	9090	9284	9415
	10323	10507	13736												
SOB	21904	21938	21978	22015	22052	22083	25775	25814							
SUB	15439	15487	15535	15583	15631	15677	15722	15766	15811	15855	15899	15944	15995	23777	25088
	25196	25991													
SWAB	9970	10017	10066	10088	10141	25161									
SXT	9611	9656	9691	9738	9776	9798	9849	9884	9930	24979	25014				
TRAP	2939														
TST	3140	3329	4019	4050	4672	4704	4744	4783	4821	4938	6213	6219	6398	7090	7145
	7512	7606	7799	7838	7839	7840	7841	7845	8024	8466	8506	9621	9786	9808	11460
	11504	12494	12541	21471	21475	21634	21638	21675	21679	21725	21729	21769	21773	21815	21820
	21857	21861	21944	22476	22484	22503	22525	22546	22581	22873	22907	22941	22975	23009	23043
	23207	23242	23415	23438	23464	23500	23507	23665	23737	24252	24290	24906	25915	25932	25984
	26001	26057	26074	26127	26144	26285	26351	26448	26456	26520	26650	26669	26711	26801	26858
	26870	26878	26891	26933											
TSTB	5188	5227	5269	5308	7969	7970	7978	22742	22819	23427	23479	23488	24581	26813	
WAIT	22752	22829													
XOR	4017	4048	4078	4107	4131	4132	4133	4134	4135	15072	15117	15162	15207	15252	15298
	15344	15390													
.ASCIZ	26988	27000	27011	27013	27016	27018	27020	27028	27034	27036	27038	27040	27042	27044	27047
	27049	27052	27056												
.BLKB	27219														
.BLKW	27068														
.BYTE	27214	27217													
.ENABL	1	2575													
.END	27223														
.EVEN	26983	27060	27212												
.LIST	1														
.MACRO	1														
.NLIST	1														
.PAGE	2891	2952	2978	3006	3034	3063	3092	3119	3148	3177	3211	3240	3272	3301	3337
	3368	3407	3443	3480	3511	3551	3582	3610	3639	3668	3696	3725	3764	3801	3838
	3867	3896	3926	3956	3994	4025	4056	4085	4115	4150	4199	4217	4242	4270	4[illegible]
	4326	4359	4391	4425	4462	4499	4532	4567	4602	4645	4679	4719	4758	4796	4842
	4877	4911	4944	4978	5013	5051	5088	5126	5164	5202	5242	5284	5323	5362	5395
	5430	5465	5505	5538	5568	5602	5636	5678	5719	5754	5794	5834	5867	5903	5946
	5987	6020	6053	6086	6120	6154	6188	6229	6261	6301	6335	6372	6424	6477	6531
	6585	6639	6682	6725	6768	6811	6853	6896	6938	6981	7021	7063	7117	7171	7205
	7239	7273	7309	7345	7380	7426	7463	7520	7557	7614	7654	7693	7728	7769	7808
	7851	7887	7920	7952	8010	8033	8067	8113	8145	8172	8204	8235	8267	8300	8331
	8363	8400	8440	8477	8517	8548	8579	8612	8644	8676	8708	8740	8773	8806	8842
	8873	8905	8938	8971	9002	9036	9068	9100	9132	9165	9198	9229	9262	9294	9327
	9359	9392	9424	9457	9488	9521	9552	9585	9630	9665	9711	9747	9823	9858	9903
	9939	9989	10036	10113	10160	10206	10252	10298	10344	10390	10436	10482	10528	10573	10618
	10663	10708	10753	10798	10844	10890	10936	10982	11028	11074	11121	11163	11211	11253	11301
	11343	11390	11431	11477	11522	11565	11607	11651	11694	11737	11780	11823	11866	11908	11951
	11994	12037	12081	12125	12169	12212	12254	12297	12340	12383	12425	12468	12514	12560	12604
	12653	12698	12742	12786	12830	12877	12921	12964	13008	13052	13096	13140	13184	13228	13272
	13315	13359	13403	13447	13490	13534	13578	13623	13668	13711	13756	13800	13837	13879	13915
	13958	13995	14037	14073	14117	14161	14203	14248	14291	14333	14376	14412	14449	14486	14523
	14569	14615	14661	14707	14753	14799	14845	14891	14930	14969	15008	15046	15090	15135	15180
	15225	15271	15317	15363	15410	15458	15506	15554	15602	15650	15695	15740	15784	15828	15872
	15916	15962	16013	16056	16099	16142	16185	16223	16261	16310	16358	16407	16456	16511	16566

	16621	16676	16731	16787	16842	16898	16953	17008	17063	17118	17173	17229	17284	17340	17390
	17440	17490	17540	17590	17643	17693	17743	17779	17817	17854	17892	17929	17967	18013	18060
	18096	18131	18174	18215	18253	18298	18344	18389	18434	18473	18515	18552	18591	18628	18667
	18705	18749	18793	18837	18881	18927	18975	19020	19065	19109	19154	19199	19244	19289	19334
	19378	19424	19470	19515	19559	19603	19648	19692	19736	19779	19824	19869	19914	19959	20004
	20050	20096	20142	20188	20235	20282	20330	20368	20409	20448	20487	20526	20565	20604	20643
	20680	20718	20754	20793	20834	20875	20921	20962	21015	21061	21112	21153	21204	21250	21296
	21342	21393	21442	21481	21528	21566	21604	21645	21691	21736	21785	21826	21875	21909	21954
	21991	22028	22065	22102	22160	22218	22272	22326	22398	22470	22497	22519	22540	22574	22609
	22661	22712	22789	22867	22901	22935	22969	23003	23037	23071	23103	23135	23170	23201	23236
	23271	23304	23337	23370	23405	23453	23541	23623	23675	23700	23725	23750	23789	23832	23876
	23933	23994	24055	24085	24118	24150	24188	24225	24262	24308	24364	24417	24472	24515	24560
	24604	24648	24691	24735	24777	24821	24865	24913	24949	24986	25021	25057	25095	25133	25168
	25203	25239	25276	25311	25349	25385	25420	25455	25493	25531	25566	25603	25638	25672	25706
	25742	25782	25821	25871	25940	26013	26083	26158	26210	26263	26309	26371	26407	26472	26546
	26590	26732	26768	26819	26836	26854	26944	26981	27061						
.REM	1														
.SBTTL	2580	2957	2979	3007	3035	3064	3093	3120	3149	3178	3212	3241	3273	3302	3338
	3369	3408	3444	3481	3512	3552	3583	3611	3640	3669	3697	3726	3765	3802	3839
	3868	3897	3927	3957	3995	4026	4057	4086	4116	4164	4190	4218	4243	4271	4300
	4327	4360	4392	4426	4463	4500	4533	4568	4603	4646	4680	4720	4759	4797	4843
	4878	4912	4945	4979	5014	5052	5089	5127	5165	5203	5243	5285	5324	5363	5396
	5431	5466	5506	5539	5569	5603	5637	5679	5720	5755	5795	5835	5868	5904	5947
	5988	6021	6054	6087	6121	6155	6189	6230	6262	6302	6336	6373	6425	6478	6532
	6586	6640	6683	6726	6769	6812	6854	6897	6939	6982	7022	7064	7118	7172	7206
	7240	7274	7310	7346	7381	7427	7464	7521	7558	7615	7655	7694	7729	7770	7809
	7852	7888	7921	7953	8034	8068	8114	8146	8173	8205	8236	8268	8301	8332	8364
	8401	8441	8478	8518	8549	8580	8613	8645	8677	8709	8741	8774	8807	8843	8874
	8906	8939	8972	9003	9037	9069	9101	9133	9166	9199	9230	9263	9295	9328	9360
	9393	9425	9458	9489	9522	9553	9586	9631	9666	9712	9748	9824	9859	9304	9940
	9990	10037	10114	10161	10207	10253	10299	10345	10391	10437	10483	10529	10574	10619	10664
	10709	10754	10799	10845	10891	10937	10983	11029	11075	11122	11164	11212	11254	11302	11344
	11391	11432	11478	11523	11566	11608	11652	11695	11738	11781	11824	11867	11909	11952	11995
	12038	12082	12126	12170	12213	12255	12298	12341	12384	12426	12469	12515	12561	12605	12654
	12699	12743	12787	12831	12878	12922	12965	13009	13053	13097	13141	13185	13229	13273	13316
	13360	13404	13448	13491	13535	13579	13624	13669	13712	13757	13801	13838	13880	13916	13959
	13996	14038	14074	14118	14162	14204	14249	14292	14334	14377	14413	14450	14487	14524	14570
	14616	14662	14708	14754	14800	14846	14892	14931	14970	15009	15047	15091	15136	15181	15226
	15272	15318	15364	15411	15459	15507	15555	15603	15651	15696	15741	15785	15829	15873	15917
	15963	16014	16057	16100	16143	16186	16224	16262	16311	16359	16408	16457	16512	16567	16622
	16677	16732	16788	16843	16899	16954	17009	17064	17119	17174	17230	17285	17341	17391	17441
	17491	17541	17591	17644	17694	17744	17780	17818	17855	17893	17930	17968	18014	18061	18097
	18132	18175	18216	18254	18299	18345	18390	18435	18474	18516	18553	18592	18629	18668	18706
	18750	18794	18838	18882	18928	18976	19021	19066	19110	19155	19200	19245	19290	19335	19379
	19425	19471	19516	19560	19604	19649	19693	19737	19780	19825	19870	19915	19960	20005	20051
	20097	20143	20189	20236	20283	20331	20369	20410	20449	20488	20527	20566	20605	20644	20681
	20719	20755	20794	20835	20876	20922	20963	21016	21062	21113	21154	21205	21251	21297	21343
	21394	21443	21482	21529	21567	21605	21646	21692	21737	21786	21827	21876	21910	21955	21992
	22029	22066	22103	22161	22219	22273	22327	22399	22471	22498	22520	22541	22575	22610	22662
	22713	22790	22868	22902	22936	22970	23004	23038	23072	23104	23136	23171	23202	23237	23272
	23305	23338	23371	23406	23454	23546	23568	23624	23676	23701	23726	23751	23790	23833	23877
	23934	23995	24056	24086	24119	24151	24189	24226	24263	24309	24365	24418	24476	24516	24561
	24605	24649	24692	24736	24778	24822	24871	24914	24950	24987	25022	25058	25096	25134	25169
	25204	25240	25277	25312	25350	25386	25421	25456	25494	25532	25569	25604	25639	25673	25707
	25743	25783	25822	25872	25941	26014	26084	26159	26211	26264	26310	26312	26314	26372	26399
	26408	26473	26547	26591	26733	26769	26820	26837	26855						

```
.MAIN.  MACY11 27(732)  15-OCT-76  14:58  PAGE 771
DBQEAB.CMB      CROSS REFERENCE TABLE -- PERMANENT SYMBOLS



% ERRORS DETECTED:  0
 DEFAULT GLOBALS GENERATED:  0

 *,DBQEAB.SEQ/SOL/CRF/PAGNUM/NL:TOC/DS:ERFZ=DSKM:SYSMAC.CO,DSKZ:DBQEAB.CMB
 RUN-TIME: 102 168 46 SECONDS
 RUN-TIME RATIO: 581/318=1.8
 CORE USED:  51K  (101 PAGES)
```

Spooler runtime [illegible] Seconds, [illegible] VPS, [illegible] disk reads, 4 disk writes, 767 pages