

# IP11/IP300

PROCESS CONTROL SUBSYSTEMS  
MD-11-DVPCA-A

EP-DVPCA-A-DL-A  
COPYRIGHT © 1977  
FICHE 1 OF 1

DEC 1977  
**digital**  
MADE IN USA

The main body of the document consists of a grid of 48 small, faint diagrams or data tables arranged in 8 rows and 6 columns. Each cell contains a small schematic or data set, likely related to process control subsystems. The diagrams are too faint to read clearly but appear to be organized in a structured manner, possibly representing different components or stages of a control system.

IDENTIFICATION

SEQ 0001

PRODUCT CODE:       MAINDEC-11-DVPCA-A-D  
PRODUCT NAME:       PROCESS CONTROL SUBSYSTEMS - FIELD TEST  
PRODUCT DATE:       NOVEMBER 1977  
MAINTAINER:         DIAGNOSTIC ENGINEERING

The information in this document is subject to change without notice and should not be construed as a commitment by Digital Equipment Corporation. Digital Equipment Corporation assumes no responsibility for any errors that may appear in this manual.

The software described in this document is furnished to the purchaser under a license for use on a single computer system and can be copied (with inclusion of Digital's copyright notice) only for use in such system, except as may otherwise be provided in writing by Digital.

Digital Equipment Corporation assumes no responsibility for the use or reliability of its software on equipment that is not supplied by Digital.

Copyright (C) 1977 Digital Equipment Corporation

1	DOCUMENT
340	TRAP CATCHER
349	STARTING ADDRESS(ES)
360	BASIC DEFINITIONS
470	BIT DEFINITIONS
481	COMMON TAGS
602	ERROR POINTER TABLE
702	INITIALIZE THE COMMON TAGS
736	DIAGNOSTICS MONITOR
737	TYPE PROGRAM NAME
818	DIGITAL MODULE MONITOR
880	SET SOFTWARE SWITCH REGISTER
888	AUTO TEST MONITOR
981	END OF PASS ROUTINE
1008	LOOP TEST
1063	MODULE TEST
1112	MAP OF DBUS
1172	IOCM TEST
1426	DIGITAL MODUL TEST ,M5010
1453	DIGITAL MODULE TEST ,M5013
1541	DIGITAL MODULE TEST ,M6010
1589	DIGITAL MODULE TEST , M6012,M6013
1632	DIGITAL MODULE TEST ,M6011
1692	DIGITAL MODULE TEST ,M5011
1804	DIGITAL MODULE TEST ,M5012
1924	SUBROUTINES
2231	SCOPE HANDLER ROUTINE
2287	TTY INPUT ROUTINE
2361	READ AN OCTAL NUMBER FROM THE TTY
2414	ERROR HANDLER ROUTINE
2455	ERROR MESSAGE TYPEOUT ROUTINE
2502	TYPE ROUTINE
2572	CONVERT BINARY TO DECIMAL AND TYPE ROUTINE
2639	BINARY TO OCTAL (ASCII) AND TYPE
2716	SAVE AND RESTORE R0-R5 ROUTINES
2761	TRAP DECODER
2784	TRAP TABLE
2804	POWER DOWN AND UP ROUTINES

1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55  
56

.SBTTL DOCUMENT

;\*\*\*\*\*

.REM -

1.0 ABSTRACT

\*\*\*\*\*

THIS PROGRAM IS A DIAGNOSTIC TOOL FOR TESTING THE ENTIRE FAMILY OF PCS MODULES. THE PROGRAM IS INTENDED TO BE USE BY FIELD ENGINEERING AND MANUFACTURING. BY USING THIS PROGRAM AN OPERATOR IS ABLE TO CHECK THE IOCM, AND ANY DIGITAL OR ANALOG MODULE. SINCE THE ASSUMPTION IS MADE THAT ALL OUTPUT MODULES ARE CONNECTED TO THE CUSTOMERS WIRING DURING THE TEST OF OUTPUT MODULES THE DISABLE BIT IS SET. THIS DIAGNOSTIC WILL NOT CHECK THE PART OF HARDWARE THAT IS INTERFACING DIGITAL OR ANALOG MODULES WITH CUSTOMERS WIRING (DRIVING TRANSISTOR, ISOLATING TRANSFORMERS, PHOTO-COUPPLERS ECT). THIS DIAGNOSTIC DOES NOT REQUIRE ANY EXTERNAL DEVICES OR SPECIAL CONNECTIONS.

2.0 HARDWARE REQUIREMENTS

\*\*\*\*\*

1. LSI 11 WITH 16K OF MEMORY OR ANY PDP11 CPU WITH UNIBUS BRIDGE INTERFACE.
2. CONSOLE TERMINAL
3. FLOPPY DISC OR SOME OTHER INPUT DEVICE
4. IOCM (M7458)

3.0 PROGRAM CONSIDERATION

\*\*\*\*\*

3.1 CPU COMPATIBILITY

THIS PROGRAM CAN BE USED BY THE LSI 11 OR BY THE PDP-11 /04, 05, 10, 20, 34, 35, 40, 45, 50 & 70 IF UNIBUS BRIDGE MODULE IS USED.

3.2 XXDP

THIS PROGRAM CAN BE CHAINED BY XXDP & WILL NOT OVERLAY THE LOADER

CHAIN MODE OPERATION

1. THE INPUT DIALOGUE WITH AN OPERATOR IS BYPASSED
2. THE SUBSYSTEM IS MAPPED IN MEMORY
3. THE SYSTEM TEST IS AUTOMATICALLY EXECUTED

NORMAL OPERATION

1. START AT LOC 204
2. SELECT TEST
3. PROGRAM RUNS AND GOES BACK TO MONITOR

3.3 ACT/APT

THIS PROGRAM IS ACT COMPATIBLE TO THE EXTENT THAT APT HOOKS

57  
58  
59  
60  
61  
62  
63  
64  
65  
66  
67  
68  
69  
70  
71  
72  
73  
74  
75  
76  
77  
78  
79  
80  
81  
82  
83  
84  
85  
86  
87  
88  
89  
90  
91  
92  
93  
94  
95  
96  
97  
98  
99  
100  
101  
102  
103  
104  
105  
106  
107  
108  
109  
110  
111  
112

WILL BE IN THE PROGRAM & WILL WORK THRU THE "UPTON INTERFACE"

3.4 EXECUTION TIME

MOST INDIVIDUAL TESTS TAKE LESS THEN 1 SEC. THE ONESHOT MODULE TEST TAKES 15 SEC. THE SYSTEM TEST EXECUTION TIME DEPENDS ON THE NUMBER AND TYPE OF I/O MODULES.

3.5 DEFAULT ADDRESSES & VECTORS

THE FOLLOWING IS A LIST OF THE DEFAULT ADDRESSES & VECTORS OF ALL HARDWARE TO BE USED AND THEIR CORRESPONDING MEMORY LOCATIONS. IN THE CASE THAT THE IOCM IS SET TO AN ADDRESS OTHER THAN 171000 THESE LOCATIONS MUST BE CHANGED.

BASE: .WORD 171000 ;FIRST ADDRESS OF I/OADDRESS BLOCK  
CSR: .WORD 171377 ;ADDRESS OF IOCM CSR REGISTER  
IAR: .WORD 171376 ; " IAR REGISTER  
VECTO: .WORD 234 ; INTERRUPT VECTOR OF IOCM  
VECTOR: .WORD 236 ; INTERRUPT VECTOR+2 OF IOCM

4.0 OPERATING PROCEDURE

\*\*\*\*\*

4.1 PROGRAM LOADING

THE PROGRAM CAN BE LOADED FROM PAPER TAPE OR FLOPPY DISK USING STANDARD PROCEDURES.

4.2 PROGRAM STARTING

LOCATION 200 - STARTING ADDRESS TO RUN THE DIAGNOSTICS MONITOR. THE PROGRAM WILL PRINT OPTIONS AVAILABLE TO THE OPERATOR.

LOCATION 204 - STARTING ADDRESS OF MONITOR WITHOUT PRINTING OPERATOR'S OPTIONS.

4.3 INPUT DIALOGUE

IF AN OPERATOR STARTS THE PROGRAM AT LOCATION 204 HE CAN SELECT ONE OF FOLLOWING OPTIONS:

4.3.1 S-SYSTEM TEST

THIS OPTION OF THE PROGRAM WILL MAP ALL THE ANALOG AND DIGITAL MODULES CONNECTED TO THE IOCM AND BUILD A TABLE OF THEM IN MEMORY. THEN IT WILL PICK UP EACH ONE AND RUN THE APPROPRIATE TESTS. IF SWITCH 14 IN THE SOFTWARE SWITCH REGISTER IS SET , IT WILL LOOP ON CURRENT TEST UNTIL OPERATOR TYPES CONTROL C. AFTER THE SELECTED # OF PASSES, THE PROGRAM WILL PRINT PASS COUNT UNLESS SWITCH 13 IS SET.

4.3.2 M - MAP OF DBUS

113  
114  
115  
116  
117  
118  
119  
120  
121  
122  
123  
124  
125  
126  
127  
128  
129  
130  
131  
132  
133  
134  
135  
136  
137  
138  
139  
140  
141  
142  
143  
144  
145  
146  
147  
148  
149  
150  
151  
152  
153  
154  
155  
156  
157  
158  
159  
160  
161  
162  
163  
164  
165  
166  
167  
168

THIS OPTION ALLOWS AN OPERATOR TO CHECK WHICH I/O MODULE ARE CONNECTED TO THE IOCM. IT CHECKS ALL ADDRESSES BETWEEN 171000 AND 171375. FOR ADDRESSES THAT ANSWER, IT CHECKS THE GENERIC CODE AND TYPES THE ADDRESS AND INTERFACE TYPE.

4.3.3 D - TEST DIGITAL MODULE

THIS TEST WILL EXERCISE THE DIGITAL MODULE AT THE ADDRESS SPECIFIED BY THE OPERATOR. FOLLOWING IS A DESCRIPTION OF THE DIGITAL MODULE TESTS FOR EACH MODULE TYPE. EACH TEST IS RUN AS MANY TIMES AS SELECTED BY THE L OPTION AND THE PASS COUNT IS PRINTED.

M5010:

1. SET D BIT
2. CHECK THAT ALL BITS ARE ZERO
3. SET T BIT
4. CHECK THAT ALL BITS ARE ONES
5. SET C BIT

M5011:

1. SET DBIT AND TBIT
2. CHECK IF INPUTS ARE ALL ONES
3. CLEAR TBIT
4. CHECK IF INPUTS ARE ALL ZEROS
5. CLEAR ALL INTERRUPTS
6. SET TBIT
7. ENABLE INTERRUPT
8. CHECK IF INTERRUPT OCCURRED
9. CHECK IF INPUTS ARE ALL ONES
10. CHECK IF COS REGISTERS ARE ALL ONES
11. SET RIF BIT
12. CLEAR ALL COS REGISTERS
13. CHECK IF THEY ARE CLEAR
14. CLEAR T BIT
15. CHECK IF INTERRUPT OCCURED
16. CHECK IF ALL INPUTS ARE ZERO
17. RUN STEP 10 TO 13
18. CLEAR ALL INTERRUPTS

M5012:

1. SET DBIT
2. CHECK IF ALL BITS ARE ZERO
3. SET TBIT
4. CHECK IF ALL BITS ARE ONE
5. CLEAR T BIT
6. CLEAR ALL INTERRUPTS
7. SET T BIT
8. ENABLE INTERRUPT
9. CHECK IF INTERRUPT OCCURRED

169  
170  
171  
172  
173  
174  
175  
176  
177  
178  
179  
180  
181  
182  
183  
184  
185  
186  
187  
188  
189  
190  
191  
192  
193  
194  
195  
196  
197  
198  
199  
200  
201  
202  
203  
204  
205  
206  
207  
208  
209  
210  
211  
212  
213  
214  
215  
216  
217  
218  
219  
220  
221  
222  
223  
224

10. SET RIF BIT
11. CLEAR INTERRUPT
12. CHECK IF INTERRUPTS ARE CLEAR
13. CLEAR T BIT
14. RUN STEP 9 TO 12
15. CLEAR ALL INTERRUPTS

5013:

1. SET DBIT
2. CHECK IF ALL BITS ARE ZERO
3. SET TBIT
4. TEST IF ALL BITS ARE ONE
5. CLEAR T BIT
6. CLEAR ALL INTERRUPTS
7. SET T BIT
8. ENABLE INTERRUPT
9. CHECK IF INTERRUPT OCCURED
10. SET RIF BIT
11. CLEAR INTERRUPT
12. CHECK IF INTERRUPT IS CLEAR
13. CLEAR T BIT
14. RUN STEP 9 TO 12
15. CLEAR ALL INTERRUPTS

M6010:

1. SET D BIT
2. CLEAR ALL 4 BYTES OF I/O REGISTER
3. SET DATA PATTERN 125 IN FIRST BYTE
4. CHECK IF IT IS SET
5. CHECK IF OTHER BYTES ARE ZERO
6. DO THE SAME WITH DATA 252 , 377 , 000
7. DO THE SAME WITH OTHER BYTES

M6011:

THE LINE CLOCK MUST BE ENABLE

1. SET D BIT
2. SET DATA PATTERN 252 AT MUT
3. CHECK IF IT IS SET
4. WAIT UP TO 10 SEC
5. DATA SHOULD BE CLEAR
6. REPEAT STEP 2 TO 5 WITH DATA EQUAL TO 125

M6012:

M6013:

1. SET D BIT
2. SET OUTPUT REGISTER TO FOLLOWING DATA PATTERN  
0, 377, 252, 125
3. CHECK IF IT IS SET

225  
226  
227  
228  
229  
230  
231  
232  
233  
234  
235  
236  
237  
238  
239  
240  
241  
242  
243  
244  
245  
246  
247  
248  
249  
250  
251  
252  
253  
254  
255  
256  
257  
258  
259  
260  
261  
262  
263  
264  
265  
266  
267  
268  
269  
270  
271  
272  
273  
274  
275  
276  
277  
278  
279  
280

4.3.4 I - TEST IOCM

THIS TEST WILL EXERCISE ALL THE FEATURES OF THE IOCM. THE FOLLOWING IS A DESCRIPTION OF ALL THE TESTS.  
THIS TEST IS RUN AS MANY TIMES AS SELECTED AND THE PASS COUNT IS TYPED

- TST1: CHECKS IF EACH BIT OF THE IOCM IS CLEARED BY THE CBIT
- TST2: CHECKS IF THE INTERRUPT ENABLE BIT (EBIT) CAN BE SET AND CLEARED
- TST3: CHECKS IF THE MAINTENANCE BIT (MBIT) CAN BE SET AND CLEARED
- TST4: CHECKS IF THE DISABLE BIT (DBIT) CAN BE SET AND CLEARED  
CHECKS IF DBIT GENERATES CLEAR
- TST5: CHECKS IF THE TEST BIT (TBIT) CAN BE SET AND CLEARED
- TST6: CHECKS IF THE GENERIC CODE BIT (GBIT) CAN BE SET AND CLEARED
- TST7: CHECKS IF THE RIF BIT (RBIT) CAN BE SET AND CLEARED
- TST10: CHECKS DBUS DATA PATHS IN A MAINTENANCE MODE. IF THE MBIT IS SET AND THE CPU ADDRESSES ANY LOCATION BETWEEN 171000 AND 171375 IT SHOULD READ BACK THE LOWER BYTE OF THE MODULE ADDRESS.
- TST11: CHECKS MAINTENANCE INTERRUPT. IF THE MBIT & EBIT ARE SET, THE IOCM WILL GENERATE AN INTERRUPT WITH VECTOR 234. THE IAR (171376) HAS THE LOWER BYTE OF CSR ADDRESS (377).

4.3.5 W -WRAP AROUND TEST

THIS OPTION ALLOWS THE FIELD ENGINEER TO CONNECT MODULE M6010 TO EITHER M5010 OR M5011. THEN IT WRAPS AROUND A SET OF DATA PATTERNS( 125, 252, 377, 0 IF SWITCH 14 IN THE SOFTWARE SWITCH REGISTER IS SET , IT WILL LOOP ON THIS TEST UNTIL THE OPERATOR TYPES CONTROL C. EVERY SELECTED # OF PASSES IT WILL PRINT PASS COUNT UNLESS SWITCH 13 IS SET. ERRORS WILL BE PRINTED INDICATING GOOD DATA, BAD DATA AND THE PASS # AT WHICH IT OCCURRED.

4.3.6 F -FIELD TEST

THE PURPOSE OF THIS TEST IS:  
A. TO OUTPUT ANY SELECTED DATA PATTERN TO AN OUTPUT MODULE SPECIFIED BY OPERATOR.  
B. TO MONITOR DATA FROM AN INPUT MODULE SPECIFIED BY OPERATOR.

WARNING: THE FIELD ENGINEER MUST REALIZE THAT THIS IS THE ONLY TEST THAT PERMITS HIM TO OUTPUT DATA TO THE CUSTOMER'S WIRING. THERE WILL BE VOLTAGE APPLIED TO CUSTOMER EQUIPMENT CONNECTED TO THE OUTPUT MODULE UNDER TEST. THEREFORE PRECAUTIONS MUST BE TAKEN THAT AN ERRONEOUS OUTPUT WILL NOT CAUSE DAMAGE TO THE FIELD EQUIPMENT AND THAT ALL TESTING IS CONDUCTED WITH THE CUSTOMERS KNOWLADGE



281  
282  
283  
284  
285  
286  
287  
288  
289  
290  
291  
292  
293  
294  
295  
296  
297  
298  
299  
300  
301  
302  
303  
304  
305  
306  
307  
308  
309  
310  
311  
312  
313  
314  
315  
316  
317  
318  
319  
320  
321  
322  
323  
324  
325  
326  
327  
328  
329  
330  
331  
332  
333  
334  
335  
336

PROCEDURE:

USER SELECTS THE ADDRESS OF THE MODULE UNDER TEST.  
IF IT IS AN OUTPUT MODULE THEN:

USER SELECTS AND OUTPUTS A DATA PATTERN, ONE BYTE AT A TIME,  
TO THE MODULE. TYPE CONTROL/C TO ABORT TEST.  
AFTER ALL BYTES OF MODULE HAS BEEN SELECTED, USER MUST TYPE CONTROL/C  
TO GO BACK TO MONITOR.

EXAMPLE:

TYPE ADDRESS OF MUT 171XXX  
TYPE ONE BYTE DATA PATTERN YYY  
(WHERE YYY IS A 8 BIT DATA PATTERN TO OUTPUT.  
ALSO, THE REQUEST FOR DATA FOR OUTPUT WILL BE REPEATED UP TO  
4 TIMES DEPENDENT UPON MODULE TYPE)

IF IT IS AN INPUT MODULE THEN:

THE TEST MONITORS AND PRINTS DATA FROM MODULE INPUTS.  
IT PRINTS EVERY BYTE ADDRESS OF THE MODULE WITH ITS  
CONTENT DURING THE FIRST PASS AND IT CONTINUES TO  
MONITOR THE DATA WITHOUT PRINTING IT UNLESS A CHANGE  
IN THE DATA OCCURED. MUST TYPE CONTROL/C TO RETURN TO MONITOR.

EXAMPLE:

TYPE ADDRESS OF MUT 171XXX  
171XXX : YYY  
(WHERE YYY IS THE 8 BITS OF DATA READ FROM THE MODULE.  
THE SECOND LINE OF THE MESSAGE WILL BE REPEATED  
UP TO 4 TIMES, WITH INCREMENTING ADDRESS,  
DEPENDING UPON MODULE TYPE.

4. 3. 7 L - SET PASS COUNT

TYPE THE OCTAL NUMBER OF ITERATIONS FOR ALL TESTS.  
DEFAULT NUMBER IS 1.  
MAXIMUM NUMBER IS 177777

4. 3. 7 T - SET SOFTWARE SWITCH REGISTER

TYPE THE OCTAL NUMBER TO BE LOADED TO SWREG  
100000 - HALT ON ERROR  
40000 - LOOP ON TEST  
20000 - INHIBIT ERROR AND END OF PASS PRINT  
10000 - LOOP ON ERROR

4. 3. 8 CONTROL C

TYPING CONTROL C CAUSES THE PRESENT TEST TO BE ABORTED  
AND PROGRAM RETURNS TO THE MONITOR.  
IN SOME CASES IT MAY TAKE UP TO 20 SECONDS FOR THIS TO  
HAPPEN.

```
337
338
339
340      .SBTTL  TRAP CATCHER
341
342      . =0
343      ;*ALL UNUSED LOCATIONS FROM 4 - 776 CONTAIN A ". +2, HALT"
344      ;*SEQUENCE TO CATCH ILLEGAL TRAPS AND INTERRUPTS
345      ;*LOCATION 0 CONTAINS 0 TO CATCH IMPROPERLY LOADED VECTORS
346      . =174
347      000174 000000  DISPREG: .WORD 0          ;; SOFTWARE DISPLAY REGISTER,
348      000176 000000  SWREG:   .WORD 0          ;; SOFTWARE SWITCH REGISTER
349      .SBTTL  STARTING ADDRESS(ES)
350      000200 000137 002362  JMP      @#START ;; JUMP TO STARTING ADDRESS OF PROGRAM
351      . =100
352      000100 012350  NOCLK
353      . =102
354      000102 000340  #PR7
355      . =42
356      000042 000000  HALT
357      . =204
358      000204 000137 002640  JMP      SETCLK
359      . =1100
360      .SBTTL  BASIC DEFINITIONS
361
362      ;*INITIAL ADDRESS OF THE STACK POINTER *** 1100 ***
363      001100  STACK= 1100
364      EQUIV  EMT,ERROR      ;; BASIC DEFINITION OF ERROR CALL
365      EQUIV  IOT,SCOPE     ;; BASIC DEFINITION OF SCOPE CALL
366
367      ;*MISCELLANEOUS DEFINITIONS
368      000011  HT= 11          ;; CODE FOR HORIZONTAL TAB
369      000012  LF= 12          ;; CODE FOR LINE FEED
370      000015  CR= 15          ;; CODE FOR CARRIAGE RETURN
371      000200  CRLF= 200       ;; CODE FOR CARRIAGE RETURN-LINE FEED
372      177776  PS= 177776     ;; PROCESSOR STATUS WORD
373      EQUIV  PS,PSW
374      177774  STKLMT= 177774  ;; STACK LIMIT REGISTER
375      177772  PIRQ= 177772   ;; PROGRAM INTERRUPT REQUEST REGISTER
376      177570  DSWR= 177570   ;; HARDWARE SWITCH REGISTER
377      177570  DDISP= 177570  ;; HARDWARE DISPLAY REGISTER
378
379      ;*GENERAL PURPOSE REGISTER DEFINITIONS
380      000000  R0= %0          ;; GENERAL REGISTER
381      000001  R1= %1          ;; GENERAL REGISTER
382      000002  R2= %2          ;; GENERAL REGISTER
383      000003  R3= %3          ;; GENERAL REGISTER
384      000004  R4= %4          ;; GENERAL REGISTER
385      000005  R5= %5          ;; GENERAL REGISTER
386      000006  R6= %6          ;; GENERAL REGISTER
387      000007  R7= %7          ;; GENERAL REGISTER
388      000006  SP= %6         ;; STACK POINTER
389      000007  PC= %7         ;; PROGRAM COUNTER
390
391      ;*PRIORITY LEVEL DEFINITIONS
392      000000  PRO= 0          ;; PRIORITY LEVEL 0
```

BASIC DEFINITIONS

393	000040	PR1=	40	::	PRIORITY LEVEL 1
394	000100	PR2=	100	::	PRIORITY LEVEL 2
395	000140	PR3=	140	::	PRIORITY LEVEL 3
396	000200	PR4=	200	::	PRIORITY LEVEL 4
397	000240	PR5=	240	::	PRIORITY LEVEL 5
398	000300	PR6=	300	::	PRIORITY LEVEL 6
399	000340	PR7=	340	::	PRIORITY LEVEL 7

;"SWITCH REGISTER" SWITCH DEFINITIONS

401		SW15=	100000
402	100000	SW14=	40000
403	040000	SW13=	20000
404	020000	SW12=	10000
405	010000	SW11=	4000
406	004000	SW10=	2000
407	002000	SW09=	1000
408	001000	SW08=	400
409	000400	SW07=	200
410	000200	SW06=	100
411	000100	SW05=	40
412	000040	SW04=	20
413	000020	SW03=	10
414	000010	SW02=	4
415	000004	SW01=	2
416	000002	SW00=	1
417	000001	. EQUIV	SW09, SW9
418		. EQUIV	SW08, SW8
419		. EQUIV	SW07, SW7
420		. EQUIV	SW06, SW6
421		. EQUIV	SW05, SW5
422		. EQUIV	SW04, SW4
423		. EQUIV	SW03, SW3
424		. EQUIV	SW02, SW2
425		. EQUIV	SW01, SW1
426		. EQUIV	SW00, SW0

;"DATA BIT DEFINITIONS (BIT00 TO BIT15)

428		BIT15=	100000
429		BIT14=	40000
430	100000	BIT13=	20000
431	040000	BIT12=	10000
432	020000	BIT11=	4000
433	010000	BIT10=	2000
434	004000	BIT09=	1000
435	002000	BIT08=	400
436	001000	BIT07=	200
437	000400	BIT06=	100
438	000200	BIT05=	40
439	000100	BIT04=	20
440	000040	BIT03=	10
441	000020	BIT02=	4
442	000010	BIT01=	2
443	000004	BIT00=	1
444	000002	. EQUIV	BIT09, BIT9
445	000001	. EQUIV	BIT08, BIT8
446		. EQUIV	BIT07, BIT7
447			
448			

BASIC DEFINITIONS

```
449 .EQUIV BIT06,BIT6
450 .EQUIV BIT05,BIT5
451 .EQUIV BIT04,BIT4
452 .EQUIV BIT03,BIT3
453 .EQUIV BIT02,BIT2
454 .EQUIV BIT01,BIT1
455 .EQUIV BIT00,BIT0
456
457 ;*BASIC "CPU" TRAP VECTOR ADDRESSES
458 000004 ERRVEC= 4 ;:TIME OUT AND OTHER ERRORS
459 000010 RESVEC= 10 ;:RESERVED AND ILLEGAL INSTRUCTIONS
460 000014 TBITVEC=14 ;:"T" BIT
461 000014 TRTVEC= 14 ;:TRACE TRAP
462 000014 BPTVEC= 14 ;:BREAKPOINT TRAP (BPT)
463 000020 IOTVEC= 20 ;:INPUT/OUTPUT TRAP (IOT) **SCOPE**
464 000024 PWRVEC= 24 ;:POWER FAIL
465 000030 EMTVEC= 30 ;:EMULATOR TRAP (EMT) **ERROR**
466 000034 TRAPVEC=34 ;:"TRAP" TRAP
467 000060 TKVEC= 60 ;:TTY KEYBOARD VECTOR
468 000064 TPVEC= 64 ;:TTY PRINTER VECTOR
469 000240 PIRQVEC=240 ;:PROGRAM INTERRUPT REQUEST VECTOR
470 .SBTTL BIT DEFINITIONS
471 000200 FBIT=BIT7 ;:FLAG BIT
472 000100 EBIT=BIT6 ;:INTERRUPT ENABLE
473 000040 MBIT=BIT5 ;:MAINTENANCE INTERRUPT
474 000020 DBIT=BIT4 ;:I/O DISABLE BIT
475 000010 TBIT=BIT3 ;:TEST BIT, INVERTS I/O BITS
476 000004 GBIT=BIT2 ;:GENERIC CODE ENABLE
477 000002 CBIT=BIT1 ;:CLEAR I/O
478 000001 RBIT=BIT0 ;:RIF BIT, CLEARS I/O INTERRUPT
479
480
```

```
481 .SBTTL COMMON TAGS
482
483 ;*****
484 ;*THIS TABLE CONTAINS VARIOUS COMMON STORAGE LOCATIONS
485 ;*USED IN THE PROGRAM.
486
487 001100 . =1100
488 001100 $CMTAG: . WORD 0 ; START OF COMMON TAGS
489 001100 $PASS: . WORD 0 ; CONTAINS PASS COUNT
490 001102 000 $TSTNM: . BYTE 0 ; CONTAINS THE TEST NUMBER
491 001103 000 $SERFLG: . BYTE 0 ; CONTAINS ERROR FLAG
492 001104 000000 $SICNT: . WORD 0 ; CONTAINS SUBTEST ITERATION COUNT
493 001106 000000 $SLPADR: . WORD 0 ; CONTAINS SCOPE LOOP ADDRESS
494 001110 000000 $SLPERR: . WORD 0 ; CONTAINS SCOPE RETURN FOR ERRORS
495 001112 000000 $SERTTL: . WORD 0 ; CONTAINS TOTAL ERRORS DETECTED
496 001114 000 $SITEMB: . BYTE 0 ; CONTAINS ITEM CONTROL BYTE
497 001115 001 $SERMAX: . BYTE 1 ; CONTAINS MAX. ERRORS PER TEST
498 001116 000000 $SERRPC: . WORD 0 ; CONTAINS PC OF LAST ERROR INSTRUCTION
499 001120 000000 $SGADR: . WORD 0 ; CONTAINS ADDRESS OF 'GOOD' DATA
500 001122 000000 $SBDADR: . WORD 0 ; CONTAINS ADDRESS OF 'BAD' DATA
501 001124 000000 $SGDDAT: . WORD 0 ; CONTAINS 'GOOD' DATA
502 001126 000000 $SBDDAT: . WORD 0 ; CONTAINS 'BAD' DATA
503 001130 000000 . WORD 0 ; RESERVED--NOT TO BE USED
504 001132 000000 . WORD 0
505 001134 000 $SAUTOB: . BYTE 0 ; AUTOMATIC MODE INDICATOR
506 001135 000 $SINTAG: . BYTE 0 ; INTERRUPT MODE INDICATOR
507 001136 000000 . WORD 0
508 001140 177570 $SWR: . WORD DSWR ; ADDRESS OF SWITCH REGISTER
509 001142 177570 $DISPLAY: . WORD DDISP ; ADDRESS OF DISPLAY REGISTER
510 001144 177560 $TKS: 177560 ; TTY KBD STATUS
511 001146 177562 $TKB: 177562 ; TTY KBD BUFFER
512 001150 177564 $TPS: 177564 ; TTY PRINTER STATUS REG. ADDRESS
513 001152 177566 $TPB: 177566 ; TTY PRINTER BUFFER REG. ADDRESS
514 001154 000 $NULL: . BYTE 0 ; CONTAINS NULL CHARACTER FOR FILLS
515 001155 002 $FILLS: . BYTE 2 ; CONTAINS # OF FILLER CHARACTERS REQUIRED
516 001156 012 $FILLC: . BYTE 12 ; INSERT FILL CHARS. AFTER A "LINE FEED"
517 001157 000 $STPFLG: . BYTE 0 ; "TERMINAL AVAILABLE" FLAG (BIT<07>=0=YES)
518 001160 000000 $SREGAD: . WORD 0 ; CONTAINS THE ADDRESS FROM
519 ; WHICH ($SREGO) WAS OBTAINED
520 001162 000000 $SREGO: . WORD 0 ; CONTAINS (($SREGAD)+0)
521 001164 000000 $SREG1: . WORD 0 ; CONTAINS (($SREGAD)+2)
522 001166 000000 $SREG2: . WORD 0 ; CONTAINS (($SREGAD)+4)
523 001170 000000 $SREG3: . WORD 0 ; CONTAINS (($SREGAD)+6)
524 001172 000000 $ESCAPE: 0 ; ESCAPE ON ERROR ADDRESS
525 001174 077 $QUES: . ASCII /?/ ; QUESTION MARK
526 001175 015 $CRLF: . ASCII <15> ; CARRIAGE RETURN
527 001176 000012 $LF: . ASCIIZ <12> ; LINE FEED
528 ;*****
529 001200 000120 $ATABL: . BLKW 80. ; TABLE A=ADDRESSES OF I/O MODULES
530 001440 000120 $BTABL: . BLKW 80. ; TABLE B=GENERIC CODES OF THIS MODULES
531 001700 000141 $GENER: . WORD 141 ; GENERIC CODE FOR NONISOLATED DC 32 BITS IN
532 001702 000121 . WORD 121 ; GENERIC CODE FOR NONISOLATED DC 16 BITS IN
533 001704 000122 . WORD 122 ; GENERIC CODE FOR ISOLATED DC 16 BITS IN
534 001706 000101 . WORD 101 ; GENERIC CODE FOR AC 8 BITS IN
535 001710 000041 . WORD 41 ; GENERIC CODE FOR NONISOLATED DC 32 BITS OUT
536 001712 000021 . WORD 21 ; GENERIC CODE FOR ONESHOT 16 BITS OUT
```

537	001714	000001	. WORD	1	; GENERIC CODE FOR ISOLATED DC 8 BITS OUT
538	001716	000002	. WORD	2	; GENERIC CODE FOR AC 8 BITS OUT
539	001720	000000	. WORD	0	
540	001722	005010	MUT: . WORD	5010	
541	001724	005011	. WORD	5011	
542	001726	005012	. WORD	5012	
543	001730	005013	. WORD	5013	
544	001732	006010	. WORD	6010	
545	001734	006011	. WORD	6011	
546	001736	006012	. WORD	6012	
547	001740	006013	. WORD	6013	
548	001742	006672	MODUL: . WORD	M5010	; THIS TABLE HAS ADDRESSES OF I/O SUBROUTINE
549	001744	010322	. WORD	M5011	
550	001746	011152	. WORD	M5012	
551	001750	006774	. WORD	M5013	
552	001752	007440	. WORD	M6010	
553	001754	010024	. WORD	M6011	
554	001756	007632	. WORD	M6012	
555	001760	007632	. WORD	M6013	
556	001762	000000	. WORD	0	
557	001764	000000	ANSW: . WORD	0	
558	001766	000000	YLOOP: . WORD	0	
559	001770	000000	DBUFF: . WORD	0	
560	001772	000000	. WORD	0	
561	001774	125	PATT: . BYTE	125	
562	001775	252	. BYTE	252	
563	001776	377	. BYTE	377	
564	001777	000	. BYTE	0	
565	002000	000042	XXDP: . WORD	42	
566	002002	000000	SMUT: . WORD	0	
567	002004	000000	BYTNUM: . WORD	0	; NUMBER OF BITES OF I/O
568	002006	000000	TADDR: . WORD	0	; ADDRESS OF MUT
569	002010	000000	TADDR1: . WORD	0	
570	002012	000000	TBADDR: . WORD	0	
571	002014	000000	COSADR: . WORD	0	; SECEND ADDRESS OF COS MODULE
572	002016	000000	DMUT: . WORD	0	; DIGITAL MODULE UNDER TEST
573	002020	000000	LONGIN: . WORD	0	
574	002022	000000	TNUMB: . WORD	0	
575	002024	177546	CLKADR: . WORD	177546	
576	002026	171377	CSR: . WORD	171377	
577	002030	171376	IAR: . WORD	171376	
578	002032	000234	VECTO: . WORD	234	
579	002034	000236	VECTORA: . WORD	236	
580	002036	000000	VECT1: . WORD	0	
581	002040	000000	VECT1A: . WORD	0	
582	002042	171000	BASE: . WORD	171000	; FIRST I/O
583	002044	000000	CLK: . WORD	0	
584	002046	000000	TEMP: . WORD	0	
585	002050	000000	TEMP1: . WORD	0	
586	002052	000000	TEMP3: . WORD	0	
587	002054	000000	TEMP4: . WORD	0	
588	002056	000000	PASS: . WORD	0	
589	002060	000001	PASCNT: . WORD	1	
590	002062	000100	CLKVC: . WORD	100	
591	002064	000102	CLKVCA: . WORD	102	
592	002066	011640	MOD: . WORD	F5010	

593	002070	011640	. WORD	F5011
594	002072	011652	. WORD	F5012
595	002074	011664	. WORD	F5013
596	002076	011676	. WORD	F6010
597	002100	011732	. WORD	F6011
598	002102	011716	. WORD	F6012
599	002104	011716	. WORD	F6013
600	002106	000000	. WORD	0
601	002110	000060	KBVEC: . WORD	60

ERROR POINTER TABLE

602  
603  
604  
605  
606  
607  
608  
609  
610  
611  
612  
613  
614  
615  
616  
617  
618  
619  
620  
621  
622  
623  
624  
625  
626  
627  
628  
629  
630  
631  
632  
633  
634  
635  
636  
637  
638  
639  
640  
641  
642  
643  
644  
645  
646  
647  
648  
649  
650  
651  
652  
653  
654  
655  
656  
657

.SBTTL ERROR POINTER TABLE

;\*THIS TABLE CONTAINS THE INFORMATION FOR EACH ERROR THAT CAN OCCUR.  
;\*THE INFORMATION IS OBTAINED BY USING THE INDEX NUMBER FOUND IN  
;\*LOCATION \$ITEMB. THIS NUMBER INDICATES WHICH ITEM IN THE TABLE IS PERTINENT.  
;\*NOTE1: IF \$ITEMB IS 0 THE ONLY PERTINENT DATA IS (\$ERRPC).  
;\*NOTE2: EACH ITEM IN THE TABLE CONTAINS 4 POINTERS EXPLAINED AS FOLLOWS:

;\* EM ;;POINTS TO THE ERROR MESSAGE  
;\* DH ;;POINTS TO THE DATA HEADER  
;\* DT ;;POINTS TO THE DATA  
;\* DF ;;POINTS TO THE DATA FORMAT

\$ERRTB:

EM1  
DH1  
DT1  
0  
EM2  
DH1  
DT1  
0  
EM3  
0  
0  
0  
EM4  
DH1  
DT1  
0  
EM5  
DH5  
DT5  
0  
EM6  
DH1  
DT1  
0  
EM7  
DH7  
DT7  
0  
EM10  
0  
0  
0  
EM11  
DH7  
DT7  
0  
EM12  
DH5  
DT5  
0  
EM13

002112  
002112 016230  
002114 016340  
002116 022024  
002120 000000  
002122 016257  
002124 016340  
002126 022024  
002130 000000  
002132 016371  
002134 000000  
002136 000000  
002140 000000  
002142 016422  
002144 016340  
002146 022024  
002150 000000  
002152 016450  
002154 016470  
002156 022040  
002160 000000  
002162 016523  
002164 016340  
002166 022024  
002170 000000  
002172 016572  
002174 016607  
002176 022004  
002200 000000  
002202 016657  
002204 000000  
002206 000000  
002210 000000  
002212 016712  
002214 016607  
002216 022004  
002220 000000  
002222 016750  
002224 016470  
002226 022040  
002230 000000  
002232 017000



658	002234	000000	0
659	002236	000000	0
660	002240	000000	0
661	002242	017046	EM14
662	002244	000000	0
663	002246	000000	0
664	002250	000000	0
665	002252	017111	EM15
666	002254	000000	0
667	002256	000000	0
668	002260	000000	0
669	002262	017154	EM16
670	002264	000000	0
671	002266	000000	0
672	002270	000000	0
673	002272	016572	EM17
674	002274	016607	DH7
675	002276	021734	DT17
676	002300	000000	0
677	002302	017217	EM20
678	002304	016607	DH7
679	002306	021754	DT20
680	002310	000000	0
681	002312	017251	EM21
682	002314	017313	DH21
683	002316	022054	DT21
684	002320	000000	0
685	002322	017337	EM22
686	002324	000000	0
687	002326	000000	0
688	002330	000000	0
689	002332	017413	EM23
690	002334	017450	DH23
691	002336	021774	DT23
692	002340	000000	0
693	002342	017541	EM24
694	002344	000000	0
695	002346	000000	0
696	002350	000000	0
697	002352	020356	EM25
698	002354	000000	0
699	002356	000000	0
700	002360	000000	0

ERROR POINTER TABLE

```

701 002362          START:
702          .SBTTL  INITIALIZE THE COMMON TAGS
703          ;;CLEAR THE COMMON TAGS (%CMTAG) AREA
704 002362 012706 001100      MOV    #SCMTAG,R6    ;;FIRST LOCATION TO BE CLEARED
705 002366 005026          CLR    (R6)+        ;;CLEAR MEMORY LOCATION
706 002370 022706 001140      CMP    #SWR,R6    ;;DONE?
707 002374 001374          BNE    .-6          ;;LOOP BACK IF NO
708 002376 012706 001100      MOV    #STACK,SP   ;;SETUP THE STACK POINTER
709          ;;INITIALIZE A FEW VECTORS
710 002402 012737 013670 000020  MOV    #SCOPE,@#IOTVEC ;;IOT VECTOR FOR SCOPE ROUTINE
711 002410 012737 000340 000022  MOV    #340,@#IOTVEC+2 ;;LEVEL 7
712 002416 012737 014514 000030  MOV    #ERROR,@#EMTVEC ;;EMT VECTOR FOR ERROR ROUTINE
713 002424 012737 000340 000032  MOV    #340,@#EMTVEC+2 ;;LEVEL 7
714 002432 012737 015770 000034  MOV    #STRAP,@#TRAPVEC ;;TRAP VECTOR FOR TRAP CALLS
715 002440 012737 000340 000036  MOV    #340,@#TRAPVEC+2;LEVEL 7
716 002446 013737 004264 004256  MOV    SENDCT,%EOPCT ;;SETUP END-OF-PROGRAM COUNTER
717 002454 005037 001172          CLR    %ESCAPE     ;;CLEAR THE ESCAPE ON ERROR ADDRESS
718 002460 112737 000001 001115  MOVB  #1,%SERMAX   ;;ALLOW ONE ERROR PER TEST
719 002466 012737 002466 001110  MOV    #,%SLPERR   ;;SETUP THE ERROR LOOP ADDRESS
720          ;;SIZE FOR A HARDWARE SWITCH REGISTER. IF NOT FOUND OR IT IS
721          ;;EQUAL TO A "-1", SETUP FOR A SOFTWARE SWITCH REGISTER.
722 002474 013746 000004          MOV    @#ERRVEC,-(SP) ;;SAVE ERROR VECTOR
723 002500 012737 002534 000004  MOV    #64%,@#ERRVEC ;;SET UP ERROR VECTOR
724 002506 012737 177570 001140  MOV    #DSWR,SWR   ;;SETUP FOR A HARDWARE SWICH REGISTER
725 002514 012737 177570 001142  MOV    #DDISP,DISPLAY ;;AND A HARDWARE DISPLAY REGISTER
726 002522 022777 177777 176410  CMP    #-1,@SWR   ;;TRY TO REFERENCE HARDWARE SWR
727 002530 001012          BNE    66$        ;;BRANCH IF NO TIMEOUT TRAP OCCURRED
728          ;;AND THE HARDWARE SWR IS NOT = -1
729 002532 000403          BR    65$        ;;BRANCH IF NO TIMEOUT
730 002534 012716 002542          64$: MOV    #65%,(SP)   ;;SET UP FOR TRAP RETURN
731 002540 000002          RTI
732 002542 012737 000176 001140  65$: MOV    #SWREG,SWR  ;;POINT TO SOFTWARE SWR
733 002550 012737 000174 001142  MOV    #DISPREG,DISPLAY
734 002556 012637 000004          66$: MOV    (SP)+,@#ERRVEC ;;RESTORE ERROR VECTOR
735

```

```
736 .SBTTL DIAGNOSTICS MONITOR
737 .SBTTL TYPE PROGRAM NAME
738 ;;TYPE THE NAME OF THE PROGRAM IF FIRST PASS
739 002562 005227 177777 INC #-1 ;;FIRST TIME?
740 002566 001024 BNE 67$ ;;BRANCH IF NO
741 002570 022737 004300 000042 CMP #SENDAD,@#42 ;;ACT-11?
742 002576 001420 BEQ 67$ ;;BRANCH IF YES
743 002600 104401 002606 TYPE ,68$ ;;TYPE ASCIZ STRING
744 002604 000415 BR 67$ ;;GET OVER THE ASCIZ
745 ;;68$: .ASCIZ <CRLF>/DIGITAL IO SYSTEM TEST/<CRLF>
746 002640 67$:
747 002640 SETCLK:
748 002640 013746 000004 MOV ERRVEC,-(SP) ;;PUSH ERRVEC ON STACK
749 002644 012737 002662 000004 MOV #1$,ERRVEC
750 002652 052777 000100 177144 BIS #BIT6,@CLKADR ;ENABLE LINE CLOCK INTERRUPT FOR UNIBUS COMPUTERS
751 002660 000401 BR 2$
752 002662 022626 1$: CMP (SP)+,(SP)+ ;TRAP IF LSI11
753 002664 2$:
754 002664 012637 000004 MOV (SP)+,ERRVEC ;;POP STACK INTO ERRVEC
755 002670 012706 001100 MOV #1100,R6
756 002674 005777 177100 TST @XXDP
757 002700 001402 BEQ 4$
758 002702 000137 003612 JMP AUTO
759 002706 4$:
760 002706 012777 012550 177174 MOV #KBINT,@KBVEC
761 002714 152777 000100 176222 BISB #BIT6,@$TKS ;ENABLE KB INTERRUPT
762 002722 012746 000000 MOV #PRO,-(SP) ;SET PSW TO PRIORITY 0
763 002726 012746 002734 MOV #64$,-(SP)
764 002732 000002 RTI
765 002734 000240 64$: NOP
766 002736 104401 017607 TYPE ,M13 ;TEST OPTIONS
767 002742 104401 017631 TYPE ,M14 ;S - SYSTEM TEST
768 002746 104401 017652 TYPE ,M15 ;D - DIGITAL MODULE TEST
769 002752 104401 017721 TYPE ,M17 ;M - MAP OF DBUS DEVICES
770 002756 104401 017774 TYPE ,M19 ;I - IOCM TEST
771 002762 104401 020022 TYPE ,M21 ;T - SET SWREG
772 002766 104401 020230 TYPE ,M24 ;F - FIELD TEST
773 002772 104401 020250 TYPE ,M25 ;W - WRAP AROUND TEST
774 002776 104401 020267 TYPE ,M26 ;L - LOAD LOOP COUNT
775
```

```

776 003002 012706 001100 MONIT: MOV #1100,R6 ;SET STACK
777 003006 142777 000100 176130 BICB #BIT6,%STKS ;DISABLE KB INTERRUPT
778 003014 104401 021114 TYPE ,MASS12 ;TYPE TEST OPTION TO RUN
779 003020 104406 RDCHR
780 003022 012600 MOV (SP)+,RO ;;POP STACK INTO RO
781 003024 110037 021315 MOVB RO,MASS18
782 003030 104401 021315 TYPE ,MASS18 ;ECHO CHARACTER
783 003034 022700 000123 CMP #123,RO ;IS IT S?
784 003040 001002 BNE 1$ ;STAR AUTO TEST
785 003042 000137 003612 JMP AUTO
786 003046 022700 000104 1$: CMP #104,RO ;D ?
787 003052 001002 BNE 2$
788 003054 000137 003222 JMP DIGIT ;START DIGITAL MODULE TEST
789 003060 022700 000101 2$: CMP #101,RO ;A ?
790 003064 001002 BNE 3$
791 003066 000137 011150 JMP ANALOG ;START ANALOG MODULE TEST
792 003072 022700 000115 3$: CMP #115,RO ;M ?
793 003076 001002 BNE 4$
794 003100 000137 005054 JMP MAPE ;MAP THE SYSTEM
795 003104 022700 000130 4$: CMP #130,RO ;X ?
796 003110 001002 BNE 5$
797 003112 000137 011634 JMP EXERC ;START EXERCISER
798 003116 022700 000111 5$: CMP #111,RO ;I ?
799 003122 001002 BNE 6$
800 003124 000137 005302 JMP IOCM ;TEST IOCM
801 003130 022700 000124 6$: CMP #124,RO ;T ?
802 003134 001002 BNE 7$
803 003136 000137 003564 JMP SWREGS ;SET SOFTWARE SWITCH REG.
804 003142 022700 000106 7$: CMP #106,RO ;F ?
805 003146 001002 BNE 8$
806 003150 000137 004610 JMP FIELD ;START FIELD TEST
807 003154 022700 000127 8$: CMP #127,RO ;W ?
808 003160 001002 BNE 9$
809 003162 000137 004314 JMP LOOP ;WRAP AROUND TEST
810 003166 022700 000114 9$: CMP #114,RO ;LOAD LOOP COUNT
811 003172 001007 BNE 10$
812 003174 104401 020321 TYPE ,M27 ;NUMBER OF ITERATIONS =
813 003200 104410 RDOCT
814 003202 012637 002060 MOV (SP)+,PASCNT ;;POP STACK INTO PASCNT
815 003206 000137 003002 JMP MONIT
816 003212 104401 020013 10$: TYPE ,M20 ;?
817 003216 000137 003002 JMP MONIT ;OPERATOR TYPED WRONG CHARACTER
  
```

```

818          . SBTTL DIGITAL MODULE MONITOR
819 003222    DIGIT:
820 003222    012777 012550 176660    MOV    #KBINT,@KBVEC
821 003230    152777 000100 175706    BISB   #BIT6,@$TKS    ;ENABLE KB INTERRUPT
822 003236    104401 021144          TYPE   ,MASS13       ;TYPE ADDRESS OF MUT
823 003242    104410          RDOCT
824 003244    012637 002006          MOV    (SP)+,TADDR    ;;POP STACK INTO TADDR
825 003250    013746 000004          MOV    ERRVEC,-(SP)   ;SAVE ERROR VECTOR
826 003254    012737 003550 000004    MOV    #5$,ERRVEC     ;SET LOC 4
827 003262    105777 176540          TSTB  @CSR           ;MAKE SURE IOCM IS OK
828 003266    001404          BEQ   17$
829 003270    104010          ERROR 10           ;TEST ABORTED, IOCM ERROR
830 003272    012637 000004          MOV    (SP)+,ERRVEC  ;;POP STACK INTO ERRVEC
831 003276    000207          RTS   PC
832 003300    112777 000004 176520 17$:  MOVB  #GBIT,@CSR     ;SET GENERIC BIT
833 003306    117700 176474          MOVB  @TADDR,R0      ;R0=GENERIC CODE OF MUT
834 003312    012701 001742          MOV   #MODUL,R1     ;ADDRESS OF TEST
835 003316    012703 001722          MOV   #MUT,R3
836 003322    012702 001700          MOV   #GENER,R2     ;TABLE OF GENERIC CODES
837 003326    020022          3$:  CMP   R0,(R2)+
838 003330    001067          BNE   1$
839 003332    011337 002002          MOV   (R3),$MUT
840 003336    152777 000002 176462    BISB  #CBIT,@CSR     ;SET C BIT
841 003344    005037 001766          CLR   YLOOP         ;WAIT
842 003350    005237 001766          64$: INC   YLOOP
843 003354    023727 001766 000007    CMP   YLOOP,#7
844 003362    001372          BNE   64$
845 003364    152777 000002 176434    BISB  #CBIT,@CSR     ;DO IT AGAIN
846 003372    005037 001766          CLR   YLOOP         ;WAIT
847 003376    005237 001766          65$: INC   YLOOP
848 003402    023727 001766 000007    CMP   YLOOP,#7
849 003410    001372          BNE   65$
850 003412    011137 002016          MOV   (R1),DMUT
851 003416    005037 002056          9$:  CLR   PASS
852 003422    004777 176370          4$:  JSR  PC,@DMUT        ;TEST MODULE
853 003426    004737 012446          JSR  PC,CNTRC       ;CONTROL C?
854 003432    005237 002056          2$:  INC   PASS
855 003436    023737 002060 002056    CMP   PASCNT,PASS
856 003444    001366          BNE   4$
857 003446    032737 020000 000176    BIT   #BIT13,SWREG  ;INHIBIT PRINT ?
858 003454    001005          BNE   7$
859 003456    013746 002060          MOV   PASCNT,-(SP)  ;;SAVE PASCNT FOR TYPEOUT
860 003462    104402          TYPOC                ;;GO TYPE--OCTAL ASCII(ALL DIGITS)
861 003464    104401 017515          TYPE  ,M11          ;# OF PASSES
862 003470    032737 040000 000176 7$:  BIT   #BIT14,SWREG  ;LOOP ?
863 003476    001347          BNE   9$
864 003500    104401 021221          TYPE  ,MASS15       ;END OF MODULE TEST
865 003504    000137 003002          JMP  MONIT
866 003510    062701 000002          1$:  ADD  #2,R1
867 003514    062703 000002          ADD  #2,R3
868 003520    005712          TST  (R2)
869 003522    001301          BNE  3$
870 003524    104401 021060          TYPE  ,MASS11       ;UNKNOWN GENERIC CODE
871 003530    010046          MOV  R0,-(SP)       ;;SAVE R0 FOR TYPEOUT
872 003532    104402          TYPOC                ;;GO TYPE--OCTAL ASCII(ALL DIGITS)
873 003534    104401 020417          TYPE  ,MASS0        ;CR,LF
  
```

DIGITAL MODULE MONITOR

SEQ 0021

874	003540	012637	000004		MOV	(SP)+,ERRVEC	;RESTORE ERRVEC
875	003544	000137	003002		JMP	MONIT	
876	003550	022626		55:	CMP	(SP)+,(SP)+	;RESTORE STACK POINTER
877	003552	104024			ERROR	24	;MODULE NOT RESPONDING
878	003554	012637	000004		MOV	(SP)+,ERRVEC	
879	003560	000137	003002		JMP	MONIT	

SET SOFTWARE SWITCH REGISTER

SEQ 0022

```
880          .SBTTL SET SOFTWARE SWITCH REGISTER
881
882 003564 104401 020041      SWREGS: TYPE ,M22          ;SWICHES OPTIONS
883 003570 104401 020216      TYPE ,M23          ;SW REG =
884 003574 104410              RDOCT
885 003576 012637 000176      MOV (SP)+,SWREG      ;;POP STACK INTO SWREG
886 003602 104401 020417      TYPE ,MASSO          ;CR,LF
887 003606 000137 003002      JMP MONIT
```

```
888 .SBTTL AUTO TEST MONITOR
889
890
891 ;*****
892 ;THIS PART OF A PROGRAM IS A MONITOR FOR AUTOMATIC TEST.
893 ;FIRST IT TEST IOCM. THEN IT GENERATES A TABLE AND B TABLE.
894 ;THEN IT TESTS EACH INDIVIDUAL I/O MODULE CONNECTED TO DBUS.
895 ;REGISTERS RO & R1 SERVE AS THE POINTERS FOR MUT
896
897 ;*****
898 003612 005037 002056 AUTO: CLR PASS
899 003616 012777 012550 176264 MOV #KBINT,@KBVEC
900 003624 152777 000100 175312 BISB #BIT6,@$TKS ;ENABLE KB INTERRUPT
901 003632 004737 005414 JSR PC,TIOCM
902 003636 105777 176164 TSTB @CSR ;MAKE SURE IOCM IS OK
903 003642 001402 BEQ 7$
904 003644 104010 ERROR 10 ;TEST ABORTED
905 003646 000207 RTS PC
906 003650 013746 000004 7$: MOV @#ERRVEC,-(SP) ;SAVE ERROR VECTOR
907 003654 012737 003766 000004 MOV #1$,ERRVEC ;SET ERROR VECTOR
908 003662 013700 002042 MOV BASE,RO ;RO=171000
909 003666 112777 000004 176132 MOVB #GBIT,@CSR ;SET GENERIC CODE ENABLE
910 003674 012702 001200 MOV #ATABL,R2
911 003700 012705 001440 MOV #BTABL,R5
912 003704 111001 5$: MOVB (RO),R1 ;R1=GENERIC CODE,READ GENERIC CODE
913 003706 042701 177400 BIC #177400,R1
914 003712 004737 012200 JSR PC,TABLE ;FIND WHAT I/O IT IS
915 003716 C90164 003722 JMP 3$(R4)
916 003722 000410 3$: BR 10$
917 003724 000407 BR 10$
918 003726 000410 BR 12$
919 003730 000410 BR 13$
920 003732 000404 BR 10$
921 003734 000405 BR 12$
922 003736 000405 BR 13$
923 003740 000404 BR 13$
924 003742 000403 BR 13$
925 003744 005200 10$: INC RO
926 003746 005200 11$: INC RO
927 003750 005200 12$: INC RO
928 003752 005200 13$: INC RO
929 003754 020037 002030 CMP RO,IAR
930 003760 001351 BNE 5$
931 003762 005012 CLR (R2)
932 003764 000406 BR 6$
933 003766 022626 1$: CMP (SP)+,(SP)+
934 003770 005200 INC RJ
935 003772 020037 002030 CMP RO,IAR
936 003776 001342 BNE 5$
937 004000 005015 CLR (R5)
938 004002 012637 000004 6$: MOV (SP)+,@#ERRVEC ;START TESTING INDIVIDUAL I/O
939 004006 142777 000004 176012 BICB #GBIT,@CSR ;CLEAR G BIT
940 004014 004737 005414 25$: JSR PC,TIOCM
941 004020 005000 CLR RO
942 004022 005001 22$: CLR R1
943 004024 026061 001440 001700 23$: CMP BTABL(RO),GENER(R1)
```



```

944 004032 001416          BEQ      21$
945 004034 062701 000002    ADD      #2, R1
946 004040 005761 001700    TST     GENER(R1)
947 004044 001367          BNE     23$
948 004046 104401 021060    TYPE    , MASS11          ; UNKNOWN GENERIC CODE
949 004052 016046 001440    MOV     BTABL(RO), -(SP)  ; SAVE BTABL(RO) FOR TYPEOUT
950 004056 104402          TYPOC          ; GO TYPE--OCTAL ASCII(ALL DIGITS)
951 004060 104401 020417    TYPE    , MASS0
952 004064 000137 003002    JMP     MONIT
953 004070 016137 001742 002016 21$: MOV     MODUL(R1), DMUT
954 004076 016037 001200 002006    MOV     ATABL(RO), TADDR
955 004104 016137 001722 002002    MOV     MUT(R1), $MUT
956 004112 010146          MOV     R1, -(SP)        ; PUSH R1 ON STACK
957 004114 010046          MOV     RO, -(SP)        ; PUSH RO ON STACK
958 004116 004777 175674    JSR     PC, @DMUT        ; TEST THIS MODULE
959 004122 012600          MOV     (SP)+, RO        ; POP STACK INTO RO
960 004124 012601          MOV     (SP)+, R1        ; POP STACK INTO R1
961 004126 062700 000002    ADD     #2, RO
962 004132 005760 001440    TST     BTABL(RO)
963 004136 001331          BNE     22$
964 004140 005237 002056    INC     PASS            ; INC PASS COUNT
965 004144 004737 012446    JSR     PC, CNTRC        ; CONTROL C ?
966 004150 023737 002060 002056    CMP     PASCNT, PASS     ; IS IT 1000 PASSES
967 004156 001316          BNE     25$
968 004160 005037 002056    CLR     PASS
969 004164 032737 020000 000176    BIT     #BIT13, SWREG    ; INHIBIT PRINT
970 004172 001005          BNE     20$
971 004174 013746 002060    MOV     PASCNT, -(SP)    ; SAVE PASCNT FOR TYPEOUT
972 004200 104402          TYPOC          ; GO TYPE--OCTAL ASCII(ALL DIGITS)
973 004202 104401 017515    TYPE    , M11            ; # OF PASSES COMPLETED
974 004206 032737 040000 000176 20$: BIT     #BIT14, SWREG    ; DO WE LOOP ON TESTS
975 004214 001277          BNE     25$
976 004216 005777 175556    26$: TST     @XXDP
977 004222 001004          BNE     27$
978 004224 104401 021271    24$: TYPE    , MASS17        ; END OF SYSTEM TEST
979 004230 000137 003002    JMP     MONIT
980 004234          27$:
981          .SBTTL  END OF PASS ROUTINE
982
983          ; *****
984          ; *INCREMENT THE PASS NUMBER ($PASS)
985          ; *IF THERES A MONITOR GO TO IT
986          ; *IF THERE ISN'T JUMP TO 200
987
988          SEOP:
989          SCOPE
990          CLR     $STNM          ; ZERO THE TEST NUMBER
991          INC     $PASS          ; INCREMENT THE PASS NUMBER
992          BIC     #100000, $PASS ; DON'T ALLOW A NEG. NUMBER
993          DEC     (PC)+          ; LOOP?
994          SEOPCT: .WORD 1
995          BGT     $DOAGN          ; YES
996          MOV     (PC)+, @ (PC)+ ; RESTORE COUNTER
997          SENDCT: .WORD 1
998          SEOPCT
999          $GET42: MOV     @#42, RO          ; GET MONITOR ADDRESS
  
```

1000	004274	001405		BEQ	\$DOAGN	:: BRANCH IF NO MONITOR
1001	004276	000005		RESET		:: CLEAR THE WORLD
1002	004300	004710	SENDAD:	JSR	PC.(R0)	:: GO TO MONITOR
1003	004302	000240		NOP		:: SAVE ROOM
1004	004304	000240		NOP		:: FOR
1005	004306	000240		NOP		:: ACT11
1006	004310		\$DOAGN:			
1007	004310	000137	000200	JMP	@#200	:: RETURN

```

1008          .SBTTL LOOP TEST
1009
1010          ; THIS TEST ENABLE FIELD ENGINEER TO CONNECT OUTPUT MODULE TO INPUT MODULE
1011          ; OUTPUT TEST PATTERNS AND READ THEM BACK
1012          ;
1013          ;
1014 004314 104401 021515          LOOP: TYPE , MASS23          ; CONNECT OUTPUT TO INPUT MODULE
1015 004320 012777 012550 175562 MOV #KBINT, @KBVEC
1016 004326 152777 000100 174610 BISB #BIT6, @STKS          ; ENABLE KB INTERRUPT
1017 004334 104401 021430          TYPE , MASS21          ; TYPE ADDRESS OF OUTPUT MUT
1018 004340 104410          RDOCT
1019 004342 012637 002006          MOV (SP)+, TADDR          ;; POP STACK INTO TADDR
1020 004346 104401 021463          TYPE , MASS22          ; TYPE ADDRESS OF INPUT MUT
1021 004352 104410          RDOCT
1022 004354 012637 002050          MOV (SP)+, TEMP1          ;; POP STACK INTO TEMP1
1023 004360 112777 000004 175440 MOVB #GBIT, @CSR          ; SET GENERIC BIT
1024 004366 117700 175414          MOVB @TADDR, RO          ; GENERIC CODE OF OUTPUT MUT
1025 004372 020027 000041          CMP RO, #41          ; IS IT M6010?
1026 004376 001047          BNE 1$
1027 004400 117701 175444          MOVB @TEMP1, R1          ; GENERIC CODE OF INPUT MUT
1028 004404 020127 000141          CMP R1, #141          ; IS IT M5010?
1029 004410 001403          BEQ 2$
1030 004412 020127 000121          CMP R1, #121          ; IS IT M5011?
1031 004416 001042          BNE 6$
1032 004420 005037 002056          2$: CLR PASS
1033 004424 004737 013042          3$: JSR PC, LOPTST          ; TEST SUBROUTINE
1034 004430 004737 012360          JSR PC, CLRINT          ; CLEAR ALL INTERRUPTS
1035 004434 004737 012446          JSR PC, CNTRC          ; CONTROL-C?
1036 004440 005237 002056          INC PASS
1037 004444 023737 002060 002056 CMP PASCNT, PASS
1038 004452 001364          BNE 3$
1039 004454 032737 020000 000176 BIT #BIT13, SWREG          ; INHIBIT PRINTOUT
1040 004462 001005          BNE 5$
1041 004464 013746 002060          MOV PASCNT, -(SP)          ;; SAVE PASCNT FOR TYPEOUT
1042 004470 104402          TYPOC          ;; GO TYPE--OCTAL ASCII (ALL DIGITS)
1043 004472 104401 017515          TYPE , M11          ; PASSES COMPLETED
1044 004476 032737 040000 000176 5$: BIT #BIT14, SWREG          ; LOOP
1045 004504 001345          BNE 2$
1046 004506 104401 021556          TYPE , MASS25          ; END OF LOOP TEST
1047 004512 000137 003002          JMP MONIT
1048 004516 104401 021601          1$: TYPE , MASS26          ; WRONG MODULE - OUTPUT MUST BE M6010
1049 004522 000402          BR 4$
1050 004524 104401 021650          6$: TYPE , MASS28          ; WRONG MODULE- INPUT MUST BE EITHER M5010 OR M5011
1051 004530          4$:
1052 004530 152777 000002 175270 BISB #CBIT, @CSR          ; SET C BIT
1053 004536 005037 001766          CLR YLOOP          ; WAIT
1054 004542 005237 001766          64$: INC YLOOP
1055 004546 023727 001766 000007 CMP YLOOP, #7
1056 004554 001372          BNE 64$
1057 004556 152777 000002 175242 BISB #CBIT, @CSR          ; DO IT AGAIN
1058 004564 005037 001766          CLR YLOOP          ; WAIT
1059 004570 005237 001766          65$: INC YLOOP
1060 004574 023727 001766 000007 CMP YLOOP, #7
1061 004602 001372          BNE 65$
1062 004604 000137 003002          JMP MONIT
  
```

```

1063          .SETTL  MODULE TEST
1064
1065          ; THIS TEST ENABLE FIELD ENGINEER TO SELECT AND OUTPUT ANY DATA
1066          ; PATTERN TO OUTPUT MODULES, MONITOR AND PRINT DATA FROM INPUT MODULES
1067          ;
1068          ;
1069 004610 104401 021144          FIELD: TYPE , MASS13          ; TYPE ADDRESS OF MUT
1070 004614 012777 012550 175266  MOV          #KBINT, @KBVEC
1071 004622 152777 000100 174314  BISB          #BIT6, @STKS          ; ENABLE KB INTERRUPT
1072 004630 104410          RDOCT
1073 004632 012637 002006          MOV          (SP)+, TADDR          ;; POP STACK INTO TADDR
1074 004636 013746 000004          MOV          ERRVEC, -(SP)          ; SAVE ERROR VECTOR
1075 004642 012737 005040 000004  MOV          #5$, ERRVEC          ; SET LOC 4
1076 004650 112777 000004 175150  MOVB          #GBIT, @CSR          ; SET GENERIC BIT
1077 004656 117700 175124          MOVB          @TADDR, R0          ; GENERIC CODE OF MUT
1078 004662 042700 177400          BIC          #177400, R0
1079 004666 012701 002066          MOV          #MOD, R1          ; ADDRESS OF TEST
1080 004672 012702 001700          MOV          #GENER, R2          ; TABLE OF GENERIC CODES
1081 004676 020022          3$: CMP          R0, (R2)+
1082 004700 001037          BNE          2$
1083 004702 152777 000002 175116  BISB          #CBIT, @CSR          ; SET C BIT
1084 004710 005037 001766          CLR          YLOOP          ; WAIT
1085 004714 005237 001766          64$: INC          YLOOP
1086 004720 023727 001766 000007  CMP          YLOOP, #7
1087 004726 001372          BNE          64$
1088 004730 152777 000002 175070  BISB          #CBIT, @CSR          ; DO IT AGAIN
1089 004736 005037 001766          CLR          YLOOP          ; WAIT
1090 004742 005237 001766          65$: INC          YLOOP
1091 004746 023727 001766 000007  CMP          YLOOP, #7
1092 004754 001372          BNE          65$
1093 004756 011137 002016          MOV          (R1), DMUT
1094 004762 004777 175030          JSR          PC, @DMUT          ; TEST MODULE
1095 004766 104401 021362          TYPE          , MASS20          ; TYPE CONTROL-C TO RETURN TO MONITOR
1096 004772 004737 012446          1$: JSR          PC, CNTRC          ; CONTROL-C ?
1097 004776 000775          BR          1$
1098 005000 062701 000002          2$: ADD          #2, R1
1099 005004 062703 000002          ADD          #2, R3
1100 005010 005712          TST          (R2)
1101 005012 001331          BNE          3$
1102 005014 104401 021060          TYPE          , MASS11          ; UNKNOWN GENERIC CODE
1103 005020 010046          MOV          R0, -(SP)          ;; SAVE R0 FOR TYPEOUT
1104 005022 104402          TYPOC          ; GO TYPE--OCTAL ASCII (ALL DIGITS)
1105 005024 104401 020417          TYPE          , MASS0          ; CR, LF
1106 005030 012637 000004          MOV          (SP)+, ERRVEC          ; RESTORE ERRVEC
1107 005034 000137 003002          JMP          MONIT
1108 005040 022626          5$: CMP          (SP)+, (SP)+          ; RESTORE STACK POINTER
1109 005042 104024          ERROR 24          ; MODULE NOT RESPONDING
1110 005044 012637 000004          MOV          (SP)+, ERRVEC
1111 005050 000137 003002          JMP          MONIT
  
```

```
1112 . SBTTL MAP OF DBUS
1113 ; ; *****
1114 ; THIS TEST WILL LIST ALL I/O INTERFACES CONNECTED TO IOCM
1115 ; IT WILL ALSO LIST QBUS ADDRESSES
1116 ; ; *****
1117
1118
1119
1120
1121
1122
1123
1124
1125 005054 013746 000004 MAPE: MOV @#ERRVEC, -(SP) ;SAVE ERROR VECTOR
1126 005060 012737 005260 000004 MOV #1$, ERRVEC ;SET ERROR VECTOR
1127 005066 012777 012550 175014 MOV #KBINT, @KBVEC
1128 005074 152777 000100 174042 BISB #BIT6, @STKS ;ENABLE KB INTERRUPT
1129 005102 013700 002042 MOV BASE, RO ;RO=171000
1130 005106 112777 000004 174712 MOVB #GBIT, @CSR ;SET GENERIC CODE ENABLE
1131 005114 111001 5$: MOVB (RO), R1 ;R1=GENERIC CODE, READ GENERIC CODE
1132 005116 042701 177400 BIC #177400, R1
1133 005122 004737 012154 JSR PC, GENCOD ;FIND WHAT I/O IT IS
1134 005126 104401 020422 TYPE , MASS2 ;ADDRESS
1135 005132 010046 MOV RO, -(SP) ;SAVE RO FOR TYPEOUT
1136 005134 104402 TYPOC ;GO TYPE--OCTAL ASCII(ALL DIGITS)
1137 005136 000164 005142 JMP 3$(R4)
1138 005142 104401 020434 3$: TYPE , MASS3 ;M5010
1139 005146 000434 BR 10$
1140 005150 104401 020503 TYPE , MASS4 ;M5011
1141 005154 000431 BR 10$
1142 005156 104401 020552 TYPE , MASS5 ;M5012
1143 005162 000430 BR 12$
1144 005164 104401 020616 TYPE , MASS6 ;M5013
1145 005170 000426 BR 13$
1146 005172 104401 020650 TYPE , MASS7 ;M6010
1147 005176 000420 BR 10$
1148 005200 104401 020720 TYPE , MASS8 ;M6011
1149 005204 000417 BR 12$
1150 005206 104401 020761 TYPE , MASS9 ;M6012
1151 005212 000415 BR 13$
1152 005214 104401 021025 TYPE , MASS10 ;M6013
1153 005220 000412 BR 13$
1154 005222 104401 021060 TYPE , MASS11 ;UNKNOWN GENERIC CODE
1155 005226 010146 MOV R1, -(SP) ;SAVE R1 FOR TYPEOUT
1156 005230 104402 TYPOC ;GO TYPE--OCTAL ASCII(ALL DIGITS)
1157 005232 104401 020417 TYPE , MASS0 ;CR, LF
1158 005236 000403 BR 13$
1159 005240 005200 10$: INC RO ;INC ADDRESS BY APPROPRIATE NUMBER OF BYTES
1160 005242 005200 11$: INC RO
1161 005244 005200 12$: INC RO
1162 005246 005200 13$: INC RO
1163 005250 020037 002030 CMP RO, IAR ;LAST ADDRESS ?
1164 005254 001317 BNE 5$ ;NO, DO IT AGAIN
1165 005256 000405 BR 6$
1166 005260 022626 1$: CMP (SP)+, (SP)+ ;HERE IF ADDRESS IS NOT RESPONDING
1167 005262 005200 INC RO ;INC ADDRESS
```

1168	005264	020037	002030		CMP	RD, IAR	; LAST ONE ?
1169	005270	001311			BNE	55	
1170	005272	012637	000004	65:	MOV	(SP)+, @#ERRVEC	; RESTORE ERROR VECTOR
1171	005276	000137	003002		JMP	MONIT	

1172  
1173  
1174  
1175  
1176  
1177  
1178  
1179  
1180

.SBTTL IOCM TEST

;;\*\*\*\*\*

; THIS PART OF DIAGNOSTIC TEST THE IOCM  
; IT HAS 9 TESTS. IT CHECKS IF ALL THE BITS OF THE IOCM  
; CAN BE SET AND CLEAR , CHECKS MAINTENANCE  
; INTERRUPT AND CHECKS ALL ADDRESSES IN MAINTENANCE MODE

```
1181 ; ;*****  
1182 005302 005037 002056 IOCM: CLR PASS  
1183 005306 013746 000004 MOV ERRVEC, -(SP) ; ; PUSH ERRVEC ON STACK  
1184 005312 012777 012550 174570 MOV #KBINT, @KBVEC  
1185 005320 152777 000100 173616 BISB #BIT6, @STKS ; ; ENABLE KB INTERRUPT  
1186 005326 004737 005414 15: JSR PC, TIOCM ; ; TEST IOCM  
1187 005332 005237 002056 INC PASS  
1188 005336 023737 002060 002056 CMP PASCNT, PASS ; ; 1000 PASSES DONE ?  
1189 005344 001370 BNE 1$  
1190 005346 032737 020000 000176 BIT #BIT13, SWREG ; ; INHIBIT PRINT  
1191 005354 001005 BNE 2$  
1192 005356 013746 002060 MOV PASCNT, -(SP) ; ; SAVE PASCNT FOR TYPEOUT  
1193 005362 104402 TYPOC ; ; GO TYPE--OCTAL ASCII(ALL DIGITS)  
1194 005364 104401 017515 TYPE , M11 ; ; # OF PASSES  
1195 005370 032737 040000 000176 2$: BIT #BIT14, SWREG ; ; LOOP ON TEST?  
1196 005376 001353 BNE 1$  
1197 005400 104401 021246 TYPE , MASS16 ; ; IOCM TEST PASSED  
1198 005404 012637 000004 MOV (SP)+, ERRVEC ; ; POP STACK INTO ERRVEC
```



MAIN. MACY11 30(1046) 25-OCT-77 10:10 PAGE 30  
DVPCAR.P11 25-OCT-77 10:02 IOCM TEST

G 3

SEQ 0032

1199 005410 000137 003002 JMP MONIT

```
1200 ; THIS TEST CHECKS IF EACH BIT OF CSR
1201 ; IS CLEAR BY CBIT
1202 005414 T10CM:
1203 ; ; *****
1204 005414 000004 TST1: SCOPE
1205 005416 112737 000001 002022 MOVB #1, TNUMB
1206 005424 012737 005540 000004 MOV #10$, ERRVEC
1207 005432 112777 000074 174366 MOVB #74, @CSR ; SET ALL BITS
1208 005440 152777 000002 174360 BISB #CBIT, @CSR ; SET C BIT
1209 005446 005037 001766 CLR YLOOP ; WAIT
1210 005452 005237 001766 64$: INC YLOOP
1211 005456 023727 001766 000007 CMP YLOOP, #7
1212 005464 001372 BNE 64$
1213 005466 152777 000002 174332 BISB #CBIT, @CSR ; DO IT AGAIN
1214 005474 005037 001766 CLR YLOOP ; WAIT
1215 005500 005237 001766 65$: INC YLOOP
1216 005504 023727 001766 000007 CMP YLOOP, #7
1217 005512 001372 BNE 65$
1218 005514 117737 174306 001126 MOVB @CSR, $BDDAT ; STORE CONTENTS OF CSR IN BDDAT
1219 005522 005037 001124 CLR $GDDAT
1220 005526 005737 001126 TST $BDDAT ; IS CSR CLEAR
1221 005532 001405 BEQ 2$ ; YES
1222 005534 104001 ERROR 1 ; CBIT NOT CLEARING IOCM
1223 005536 000207 RTS PC ; FATAL ERROR RETURN TO MONITOR
1224 005540 104003 10$: ERROR 3 ; IOCM NOT RESPONDING
1225 005542 022626 CMP (SP)+, (SP)+ ; RESTORE STACK
1226 005544 000207 RTS PC
1227 005546 2$:
```

```
1228 ; THIS TEST CHECKS E BIT
1229 ; ;*****
1230 005546 000004 TST2: SCOPE
1231 005550 112737 000002 002022 MOV #2, TNUMB
1232 005556 012737 000100 001124 MOV #EBIT, $GDDAT ; SET TESTED BIT
1233 005564 113737 017512 016326 MOV M7, EM2X ; SET EBIT IN ERROR MESSAGE
1234 005572 004737 012230 JSR PC, BITSET
1235 005576 104002 ERROR 2 ; BIT IS NOT SETTING
1236 005600 005037 001124 CLR $GDDAT
1237 005604 004737 012230 JSR PC, BITSET
1238 005610 104002 ERROR 2
1239
1240 ; THIS TEST CHECKS MBIT
1241 ; ;*****
1242 005612 000004 TST3: SCOPE
1243 005614 112737 000003 002022 MOV #3, TNUMB
1244 005622 012737 000240 001124 MOV #MBIT!#FBIT, $GDDAT ; SET MAINTENANCE BIT
1245 005630 113737 017507 016326 MOV M6, EM2X ; SET ERROR MESSAGE
1246 005636 004737 012230 JSR PC, BITSET
1247 005642 104002 ERROR 2 ; BIT NOT SETTING
1248 005644 005037 001124 CLR $GDDAT
1249 005650 004737 012230 JSR PC, BITSET,
1250 005654 104002 ERROR 2 ; BIT NOT CLEARING
1251
1252 ; THIS TEST CHECKS DBIT
1253 ; ;*****
1254 TST4: SCOPE
1255 005656 000004 MOV #4, TNUMB
1256 005660 112737 000004 002022 MOV #DBIT, $GDDAT
1257 005666 012737 000020 001124 MOV M5, EM2X ; FIX ERROR MESSAGE
1258 005674 113737 017504 016326 JSR PC, BITSET ; SET D BIT
1259 005702 004737 012230 ERROR 2 ; BIT NOT SETTING
1260 005706 104002 CLR $GDDAT
1261 005710 005037 001124 JSR PC, BITSET
1262 005714 004737 012230 ERROR 2 ; BIT NOT CLEARING
1263 005720 104002 MOV #74, @CSR ; SET FEW BITS AT CSR
1264 005722 112777 000074 174076 BICB #DBIT, @CSR ; CLEAR DBIT
1265 005730 142777 000020 174070 CLR YLOOP ; WAIT
1266 005736 005037 001766 64$: INC YLOOP
1267 005742 005237 001766 64$: CMP YLOOP, #7
1268 005746 023727 001766 000007 BNE 64$
1269 005754 001372 MOV @CSR, $GDDAT
1270 005756 117737 174044 001124 BITB #177, $GDDAT
1271 005764 132737 000177 001124 BEQ 1$ ; CHECK IF DBIT CLEARING CLEARS CSR
1272 005772 001401 ; CLEARING DBIT DOES NOT CLEAR CSR
1273 005774 104016 ERROR 16
1274 005776 15$: BISB #CBIT, @CSR ; SET C BIT
1275 005776 152777 000002 174022 CLR YLOOP ; WAIT
1276 006004 005037 001766 65$: INC YLOOP
1277 006010 005237 001766 65$: CMP YLOOP, #7
1278 006014 023727 001766 000007 BNE 65$
1279 006022 001372 BISB #CBIT, @CSR ; DO IT AGAIN
1280 006024 152777 000002 173774 CLR YLOOP ; WAIT
1281 006032 005037 001766 66$: INC YLOOP
1282 006036 005237 001766 66$: CMP YLOOP, #7
1283 006042 023727 001766 000007
```

```
1284 006050 001372          BNE      66$
1285
1286
1287
1288          ; THIS TEST CHECKS TBIT
1289          ; ; *****
1289 006052 000004          TST5:  SCOPE
1290 006054 112737 000005 002022      MOVB   #5, TNUMB
1291 006062 012737 000010 001124      MOV    #TBIT, $GDDAT
1292 006070 113737 017501 016326      MOVB  M4, EM2X          ; SET ERROR MESSAGE
1293 006076 004737 012230          JSR    PC, BITSET       ; SET AND CHECK T BIT
1294 006102 104002          ERROR 2                ; BIT IS NOT SETTING
1295 006104 005037 001124          CLR   $GDDAT
1296 006110 004737 012230          JSR   PC, BITSET       ; CLEAR T BIT
1297 006114 104002          ERROR 2                ; BIT NOT CLEAR
1298 006116 004737 012360          JSR   PC, CLRINT       ; CLEAR ALL INTERRUPT CAUSED BY T BIT
1299
1300          ; THIS TEST CHECKS GBIT
1301          ; ; *****
1302 006122 000004          TST6:  SCOPE
1303 006124 112737 000006 002022      MOVB   #6, TNUMB
1304 006132 012737 000004 001124      MOV    #GBIT, $GDDAT
1305 006140 113737 017476 016326      MOVB  M3, EM2X          ; FIX ERPOR MESSAGE
1306 006146 004737 012230          JSR    PC, BITSET       ; SET AND CHECK G BIT
1307 006152 104002          ERROR 2                ; BIT NOT SETTING
1308 006154 005037 001124          CLR   $GDDAT
1309 006160 004737 012230          JSR   PC, BITSET       ; CLEAR G BIT
1310 006164 104002          ERROR 2                ; BIT'S NOT CLEARING
1311
1312
1313          ; THIS TEST CHECKS RBIT
1314          ; ; *****
1315 006166 000004          TST7:  SCOPE
1316 006170 112737 000007 002022      MOVB   #7, TNUMB
1317 006176 012737 000001 001124      MOV    #RBIT, $GDDAT
1318 006204 113737 017474 016326      MOVB  M2, EM2X          ; SET ERROR MESSAGE
1319 006212 004737 012230          JSR    PC, BITSET       ; SET BIT
1320 006216 104002          ERROR 2                ; BIT IS NOT SETTING
1321 006220 005037 001124          CLR   $GDDAT
1322 006224 004737 012230          JSR   PC, BITSET       ; CLEAR BIT
1323 006230 104002          ERROR 2                ; BIT IS NOT CLEAR
```

```
1324  
1325 ; *****  
1326 ; THIS TEST CHECKS ALL BITS OF DBUS IN A MAINTENANCE MODE.  
1327 ; IF MBIT IS SET AND CPU ADDRESSES ANY LOCATION BETWEEN  
1328 ; 171000 AND 171375 IT SHOULD READ BACK A LOWER  
1329 ; BYTE OF AN ADDRESS.  
1330 ; *****  
1331 ; *****  
1332 ; *****  
1333 ; *****  
1334 ; *****  
1335 006232 000004 TST10: SCOPE  
1336 006234 112737 000010 002022 MOVB #10, TNUMB  
1337 006242 112777 000040 173556 MOVB #MBIT, @CSR ; SET MAINTENANCE MODE  
1338 006250 013700 002042 MOV BASE, R0  
1339 006254 005001 CLR R1  
1340 006256 005037 001124 CLR $GDDAT  
1341 006262 005037 001126 CLR $BDDAT  
1342 006266 111001 15: MOVB (R0), R1 ; READ FIRST ADDRESS  
1343 006270 042701 177400 BIC #177400, R1  
1344 006274 120001 CMPB R0, R1 ; CHECK IF DBUS=ADDRESS  
1345 006276 001405 BEQ 2$  
1346 006300 110037 001124 MOVB R0, $GDDAT  
1347 006304 110137 001126 MOVB R1, $BDDAT  
1348 006310 104004 ERROR 4 ; DBUS BIT STACK  
1349 006312 005200 25: INC R0  
1350 006314 122700 000376 CMPB #376, R0 ; IS IT THE LAST ADDRESS  
1351 006320 001362 BNE 1$  
1352 006322 152777 000002 173476 BISB #CBIT, @CSR ; SET C BIT  
1353 006330 005037 001766 CLR YLOOP ; WAIT  
1354 006334 005237 001766 64$: INC YLOOP  
1355 006340 023727 001766 000007 CMP YLOOP, #7  
1356 006346 001372 BNE 64$  
1357 006350 152777 000002 173450 BISB #CBIT, @CSR ; DO IT AGAIN  
1358 006356 005037 001766 CLR YLOOP ; WAIT  
1359 006362 005237 001766 65$: INC YLOOP  
1360 006366 023727 001766 000007 CMP YLOOP, #7  
1361 006374 001372 BNE 65$
```

```
1362
1363 ;*****
1364 ; THIS TEST WILL CHECK MAINTENANCE INTERRUPT
1365 ; IF MBIT & EBIT ARE SET IOCM WILL GENERATE AN INTERRUPT
1366 ; AT LOCATION 234 AND IAR WILL HAVE LOWER BYTE
1367 ; OF CSR ADDRESS
1368
1369 ;*****
1370 ;*****
1371 ;*****
1372 ;*****
1373 006376 000004 TST11: SCOPE
1374 006400 112737 000011 002022 MOVB #11, TNUMB
1375 006406 012777 006502 173416 MOV #5$, @VECTO ; SET VECTOR ADDRESS
1376 006414 012777 000340 173412 MOV #PR7, @VECTOA ; SET VECTOR+2 ADDRESS
1377 006422 013746 000004 MOV ERRVEC, -(SP) ; PUSH ERRVEC ON STACK
1378 006426 012737 006664 000004 MOV #8$, ERRVEC
1379 006434 012746 000000 MOV #PR0, -(SP) ; SET PSW TO PRIORITY 0
1380 006440 012746 006446 MOV #64$, -(SP)
1381 006444 000002 RTI
1382 006446 000240 64$: NOP
1383 006450 112777 000140 173350 1$: MOVB #EBIT!#MBIT, @CSR; START INTERRUPT
1384 006456 005037 001766 CLR YLOOP ; WAIT
1385 006462 005237 001766 65$: INC YLOOP
1386 006466 023727 001766 177777 CMP YLOOP, #-1
1387 006474 001372 BNE 65$
1388 006476 104014 ERROR 14 ; NO INTERRUPT
1389 006500 000431 BR 6$
1390 006502 022626 5$: CMP (SP)+, (SP)+ ; INTERRUPT WORKED
1391 006504 117737 173320 002046 MOVB @IAR, TEMP ; READ ADDRESS OF INTERRUPTING MODULE
1392 006512 122737 000377 002046 CMPB #377, TEMP ; IAR SHOULD HAVE ALL ONES
1393 006520 001407 BEQ 7$
1394 006522 012737 000377 001124 MOV #377, $GDDAT
1395 006530 013737 002046 001126 MOV TEMP, $BDDAT
1396 006536 104006 ERROR 6 ; WRONG PATTERN IN IAR
1397 006540 152777 000001 173260 7$: BISB #RBIT, @CSR
1398 006546 105777 173254 TSTB @CSR ; CLEAR INTERRUPT
1399 006552 132777 000200 173246 BITB #FBIT, @CSR ; CHECK IF INTERRUPT CLEAR
1400 006560 001401 BEQ 6$
1401 006562 104015 ERROR 15 ; RIF BIT NOT CLEARING INTERRUPT
1402 006564 65$:
1403 006564 152777 000002 173234 BISB #CBIT, @CSR ; SET C BIT
1404 006572 005037 001766 CLR YLOOP ; WAIT
1405 006576 005237 001766 66$: INC YLOOP
1406 006602 023727 001766 000007 CMP YLOOP, #7
1407 006610 001372 BNE 66$
1408 006612 152777 000002 173206 BISB #CBIT, @CSR ; DO IT AGAIN
1409 006620 005037 001766 CLR YLOOP ; WAIT
1410 006624 005237 001766 67$: INC YLOOP
1411 006630 023727 001766 000007 CMP YLOOP, #7
1412 006636 001372 BNE 67$
1413 006640 012637 000004 MOV (SP)+, ERRVEC ; POP STACK INTO ERRVEC
1414 006644 012746 000000 MOV #PR0, -(SP) ; SET PSW TO PRIORITY 0
1415 006650 012746 006656 MOV #68$, -(SP)
1416 006654 000002 RTI
1417 006656 000240 68$: NOP
```

1418 006660 000004  
1419 006662 000207  
1420  
1421 006664 022626  
1422 006666 104022  
1423 006670 000735  
1424

SCOPE  
RTS PC  
8\$: CMP (SP)+, (SP)+  
ERROR 22  
BR 6\$

; ADDRESS TEST WITH MBIT SET NOT WORKING

1425  
1426  
1427  
1428  
1429  
1430  
1431  
1432  
1433  
1434  
1435  
1436  
1437  
1438  
1439  
1440  
1441  
1442  
1443  
1444  
1445  
1446  
1447  
1448  
1449  
1450  
1451

006672

006672

006702

006710

006716

006724

006730

006736

006744

006752

006756

006764

006770

006772

000004

112737

152777

112737

012737

004737

152777

112737

012737

004737

142777

004737

000004

000207

000012

000020

000000

000004

011746

000010

000377

000004

011746

000010

012360

002022

173116

001124

002004

002004

173070

001124

002004

011746

173042

.SBTTL DIGITAL MODUL TEST ,M5010

;;\*\*\*\*\*

; THIS TEST WILL CHECK M5010 MODULE  
; 32 BIT NONISOLATED DC SENSE

;;\*\*\*\*\*

M5010:

;;\*\*\*\*\*

TST12:

SCOPE

MOV

#12, TNUMB

BISB

#DBIT, @CSR

; SET DISABLE BIT

MOV

#0, %GDDAT

; SET WHAT DATA SHOULD BE

MOV

#4, BYTNUM

; SET NUMBER OF BYTES

JSR

PC, TSTBYT

; CHECK IF DATA IS CORRECT

BISB

#TBIT, @CSR

MOV

#377, %GDDAT

; SET WHAT DATA SHOULD BE

MOV

#4, BYTNUM

; SET NUMBER OF BYTES

JSR

PC, TSTBYT

; CHECK IF DATA IS CORRECT

BICB

#TBIT, @CSR

JSR

PC, CLRINT

SCOPE

RTS

PC



```

1452
1453 .SBTTL DIGITAL MODULE TEST ,M5013
1454 ; ;*****
1455 ; ;*****
1456 ; ;*****
1457 ; ;*****
1458 ; ;*****
1459 ; ;*****
1460 ; ;*****
1461 ; ;*****
1462 ; ;*****
1463 006774 M5013:
1464 ; ;*****
1465 006774 000004 TST13: SCOPE
1466 006776 112737 000013 002022 MOVB #13,TNUMB
1467 007004 152777 000020 173014 BISB #DBIT,@CSR ;SET DISABLE BIT
1468 007012 112737 000000 001124 MOVB #0,$GDDAT ;SET WHAT DATA SHOULD BE
1469 007020 012737 000001 002004 MOV #1,BYTNUM ;SET NUMBER OF BYTES
1470 007026 004737 011746 JSR PC,TSTBYT ;CHECK IF DATA IS CORRECT
1471
1472 007032 152777 000010 172766 BISB #TBIT,@CSR ;SET COMPLIM BIT
1473 007040 004737 012360 JSR PC,CLRINT
1474 007044 112737 000377 001124 MOVB #377,$GDDAT ;SET WHAT DATA SHOULD BE
1475 007052 012737 000001 002004 MOV #1,BYTNUM ;SET NUMBER OF BYTES
1476 007060 004737 011746 JSR PC,TSTBYT ;CHECK IF DATA IS CORRECT
1477 007064 142777 000010 172734 BICB #TBIT,@CSR
1478 007072 004737 012360 JSR PC,CLRINT
1479
1480
1481 007076 012746 000000 MOV #PRO,-(SP) ;SET PSW TO PRIORITY 0
1482 007102 012746 007110 MOV #64$,-(SP)
1483 007106 000002 RTI
1484 007110 000240 64$: NOP
1485 007112 012777 007210 172712 MOV #5$,@VECTO ;SET INTERRUPTVECTOR ADDRESS
1486 007120 012777 000340 172706 MOV #PR7,@VECTOA
1487 007126 152777 000010 172672 BISB #TBIT,@CSR ;START INTERRUPT
1488 007134 152777 000100 172664 BISB #EBIT,@CSR ;ENABLE INTERRUPT
1489 007142 005037 001766 CLR YLOOP ;WAIT
1490 007146 005237 001766 65$: INC YLOOP
1491 007152 023727 001766 177777 CMP YLOOP,#-1
1492 007160 001372 BNE 65$
1493 007162 104005 ERROR 5 ;NO INTERRUPT
1494 007164 142777 000100 172634 7$: BICB #EBIT,@CSR ;CLEAR CSR
1495 007172 142777 000010 172626 BICB #TBIT,@CSR
1496 007200 004737 012360 JSR PC,CLRINT ;CLEAR ALL INTERRUPT
1497 007204 000004 SCOPE
1498 007206 000207 RTS PC ;RETURN TO MONITOR
1499
1500 007210 022626 5$: CMP (SP)+,(SP)+ ;RESET STACK
1501 007212 005037 002050 CLR TEMP1
1502 007216 013704 000004 MOV ERRVEC,R4
1503 007222 012737 007430 000004 MOV #4$,ERRVEC
1504 007230 117737 172574 002046 6$: MOVB @IAR,TEMP ;CHECK WHICH I/O INTERRUPTED
1505 007236 152777 000001 172562 BISB #RBIT,@CSR ;HERE IF INTERRUPT
1506 007244 123737 002046 002006 CMPB TEMP,TADR ;IS IT MUT
1507 007252 001414 BEQ 2$

```

1508	007254	053737	002042	002046		BIS	BASE, TEMP	; ASSEMBLE ADDRESS OF INTERRUPTING MODULE
1509	007262	105777	172560			TSTB	@TEMP	
1510	007266	005237	002050			INC	TEMP1	; LOOP NO MORE THEN 400 TIMES
1511	007272	022737	000400	002050		CMP	#400, TEMP1	
1512	007300	001353				BNE	6\$	
1513	007302	104005				ERROR 5		; NO INTERRUPT
1514	007304	105777	172476		2\$:	TSTB	@TADDR	; CLEAR INTERRUPT
1515	007310	132777	000200	172510		BITB	#FBIT, @CSR	; CHECK IF INTERRUPT CLEAR
1516	007316	001413				BEQ	8\$	
1517	007320	117737	172504	002046		MOVB	@IAR, TEMP	
1518	007326	023737	002046	002006		CMP	TEMP, TADDR	
1519	007334	001002				BNE	9\$	
1520	007336	104015				ERROR 15		; RIF BIT NOT CLEARING INTERRUPT
1521	007340	000430				BR	3\$	
1522	007342	004737	012360		9\$:	JSR	PC, CLRINT	
1523	007346	132777	000010	172452	8\$:	BITB	#TBIT, @CSR	
1524	007354	001422				BEQ	3\$	
1525	007356	012746	000000			MOV	#PRD, -(SP)	; SET PSW TO PRIORITY 0
1526	007362	012746	007370			MOV	#66\$, -(SP)	
1527	007366	000002				RTI		
1528	007370	000240			66\$:	NOP		
1529	007372	142777	000010	172426		BICB	#TBIT, @CSR	; CHECK IF CLEARING TBIT CAUSE INTERRUPT
1530	007400	005037	001766			CLR	YLOOP	; WAIT
1531	007404	005237	001766		67\$:	INC	YLOOP	
1532	007410	023727	001766	177777		CMP	YLOOP, #-1	
1533	007416	001372				BNE	67\$	
1534	007420	104005				ERROR 5		; NO INTERRUPT
1535	007422	010437	000004		3\$:	MOV	R4, ERRVEC	
1536	007426	000656				BR	7\$	
1537	007430	022626			4\$:	CMP	(SP)+, (SP)+	
1538	007432	104005				ERROR 5		; NO INTERRUPT
1539	007434	000137	007304			JMP	2\$	
1540								

1541  
1542  
1543  
1544  
1545  
1546  
1547  
1548  
1549  
1550  
1551  
1552  
1553  
1554  
1555  
1556  
1557  
1558  
1559  
1560  
1561  
1562  
1563  
1564  
1565  
1566  
1567  
1568  
1569  
1570  
1571  
1572  
1573  
1574  
1575  
1576  
1577  
1578  
1579  
1580  
1581  
1582  
1583  
1584  
1585  
1586  
1587  
1588

.SBTTL DIGITAL MODULE TEST ,M6010  
; ; \*\*\*\*\*

; THIS TEST CHECKS M6010 MODULE  
; 32 BIT NONISOLATED DC OUT

; ; \*\*\*\*\*

M6010:  
; ; \*\*\*\*\*

```
TST14: SCOPE
MOV B #14, TNUMB
BISB #DBIT, @CSR ; SET D BIT
MOV TADDR, R0
CLRB (R0)+ ; CLEAR ALL FOUR BYTES OF I/O REGISTER
CLRB (R0)+
CLRB (R0)+
CLRB (R0)+
CLR R0
45: CLR R1
CLR DBUFF ; CLEAR IMIGE OF I/O REGISRERS
CLR DBUFF+2
35: MOV B PATT(R1), DBUFF(R0); SET DATA PATTERN IN IMIGE
MOV TADDR, TEMP
ADD R0, TEMP
MOV B PATT(R1), @TEMP ; SET DATA IN I/O REG
CLR R2
25: MOV TADDR, TEMP1
ADD R2, TEMP1
MOV B @TEMP1, $BDDAT ; READ I/O REGISTER
CMPB $BDDAT, DBUFF(R2); IS DATA OK?
BEQ 15
MOV B DBUFF(R2), $GDDAT
ERROR 17 ; DATA ERROR
15: INC R2
CMP #4, R2 ; TEST IF OTHER BYTES ARE OK
BNE 25
INC R1 ; LAST PATTERN?
CMP #4, R1 ; TEST NEXT DATA PATTERN
BNE 35
INC R0
CMP #4, R0 ; LAST BYTE?
BNE 45 ; NO. TEST NEXT BYTE
SCOPE
RTS PC
```

1589  
1590  
1591  
1592  
1593  
1594  
1595  
1596  
1597  
1598  
1599  
1600  
1601  
1602  
1603  
1604  
1605  
1606  
1607  
1608  
1609  
1610  
1611  
1612  
1613  
1614  
1615  
1616  
1617  
1618  
1619  
1620  
1621  
1622  
1623  
1624  
1625  
1626  
1627  
1628  
1629  
1630  
1631

007632  
007632  
  
007632 000004  
007634 112737 000015 002022  
007642 152777 000020 172156  
007650 012737 000125 001124  
007656 012737 000001 002004  
007664 004737 012112  
007670 012737 000001 002004  
007676 004737 011746  
  
007702 012737 000252 001124  
007710 012737 000001 002004  
007716 004737 012112  
007722 012737 000001 002004  
007730 004737 011746  
  
007734 012737 000377 001124  
007742 012737 000001 002004  
007750 004737 012112  
007754 012737 000001 002004  
007762 004737 011746  
  
007766 012737 000000 001124  
007774 012737 000001 002004  
010002 004737 012112  
010006 012737 000001 002004  
010014 004737 011746  
010020 000004  
010022 000207

```
. SBTTL DIGITAL MODULE TEST , M6012,M6013
; ;*****
; THIS TEST CHECKS MODULES M6012 AND M6013
; 8 BIT AC AND DC OUT
; ;*****

M6012:
M6013:
; ;*****
TST15: SCOPE
        MOVB    #15, TNUMB
        BISB    #DBIT, @CSR
        MOV     #125, $GDDAT ; SET DATA PATTERN
        MOV     #1, BYTNUM  ; SET NUMBER OF BYTES
        JSR     PC, SETBYT  ; SET DATA IN I/O MODULE
        MOV     #1, BYTNUM
        JSR     PC, TSTBYT  ; TEST IF DATA IS SET CORRECTLY

        MOV     #252, $GDDAT ; SET DATA PATTERN
        MOV     #1, BYTNUM  ; SET NUMBER OF BYTES
        JSR     PC, SETBYT  ; SET DATA IN I/O MODULE
        MOV     #1, BYTNUM
        JSR     PC, TSTBYT  ; TEST IF DATA IS SET CORRECTLY

        MOV     #377, $GDDAT ; SET DATA PATTERN
        MOV     #1, BYTNUM  ; SET NUMBER OF BYTES
        JSR     PC, SETBYT  ; SET DATA IN I/O MODULE
        MOV     #1, BYTNUM
        JSR     PC, TSTBYT  ; TEST IF DATA IS SET CORRECTLY

        MOV     #0, $GDDAT  ; SET DATA PATTERN
        MOV     #1, BYTNUM  ; SET NUMBER OF BYTES
        JSR     PC, SETBYT  ; SET DATA IN I/O MODULE
        MOV     #1, BYTNUM
        JSR     PC, TSTBYT  ; TEST IF DATA IS SET CORRECTLY
        SCOPE
        RTS     PC
```

```
1632 .SBTTL DIGITAL MODULE TEST ,M6011
1633 ;*****
1634
1635 ;THIS TEST CHECKS MODULE M6011
1636 ;ONE SHOT DC OUT
1637 ;*****
1638
1639
1640 010024 M6011:
1641 ;*****
1642 010024 000004 TST16: SCOPE
1643 010026 112737 000016 002022 MOV #16, TNUMB
1644 010034 013737 002006 002010 MOV TADDR, TADDR1
1645 010042 005237 002010 INC TADDR1
1646 010046 152777 000020 171752 BLSB #DBIT, @CSR
1647 010054 005037 002044 CLR CLK ;CLEAR CLOCK COUNTER
1648 010060 012777 012352 171774 MOV #COUNT, @CLKVC ;SET LOC 100- CLOCK VECTOR
1649 010066 012777 000340 171770 MOV #PR7, @CLKVCA ;SET LOC 102
1650 010074 012746 000000 MOV #PR0, -(SP) ;SET PSW TO PRIORITY 0
1651 010100 012746 010106 MOV #64$, -(SP)
1652 010104 000002 RTI
1653 010106 000240 64$: NOP
1654 010110 012737 000252 001124 MOV #252, $GDDAT ;SET DATA PATTERN
1655 010116 012737 000002 002004 MOV #2, BYTNUM ;SET NUMBER OF BYTES
1656 010124 004737 012112 JSR PC, SETBYT ;SET DATA IN I/O MODULE
1657 010130 012737 000002 002004 MOV #2, BYTNUM
1658 010136 004737 011746 JSR PC, TSTBYT ;TEST IF DATA IS SET CORRECTLY
1659 010142 005001 CLR R1
1660 010144 005201 115: INC R1 ;CHECK IF LINE CLOCK IS INTERRUPTING
1661 010146 001376 BNE 115
1662 010150 005737 002044 TST CLK
1663 010154 001010 BNE 15
1664 010156 104025 ERROR 25 ;LINE CLOCK ISN'T INTERRUPTING
1665 010160 000453 BR M6011B
1666 010162 105777 171620 25: TSTB @TADDR
1667 010166 001003 BNE 15
1668 010170 105777 171614 TSTB @TADDR1
1669 010174 001410 BEQ M6011A
1670 010176 022737 001131 002044 15: CMP #601., CLK ;WAIT 10SEC
1671 010204 001366 BNE 25
1672 010206 005037 001124 CLR $GDDAT
1673 010212 004737 012030 JSR PC, TSTONE ;PATTERN SHOULD BE CLEAR
1674 010216 M6011A:
1675 010216 005037 002044 CLR CLK ;CLEAR CLOCK COUNTER
1676 010222 012737 000125 001124 MOV #125, $GDDAT ;SET DATA PATTERN
1677 010230 012737 000002 002004 MOV #2, BYTNUM ;SET NUMBER OF BYTES
1678 010236 004737 012112 JSR PC, SETBYT ;SET DATA IN I/O MODULE
1679 010242 012737 000002 002004 MOV #2, BYTNUM
1680 010250 004737 011746 JSR PC, TSTBYT ;TEST IF DATA IS SET CORRECTLY
1681 010254 105777 171526 25: TSTB @TADDR
1682 010260 001003 BNE 15
1683 010262 105777 171522 TSTB @TADDR1
1684 010266 001410 BEQ M6011B
1685 010270 022737 001131 002044 15: CMP #601., CLK ;WAIT 10 SEC
1686 010276 001366 BNE 25
1687 010300 005037 001124 CLR $GDDAT
```

1688	010304	004737	012030		JSR	PC, TSTONE	; PATTERN SHOULD BE CLEAR
1689	010310	000004		M6011B:	SCOPE		
1690	010312	012777	012350	171542	MOV	#NOCLK, @CLKVC	; RESTORE CLOCK VECTOR
1691	010320	000207			RTS	PC	

.SBTTL DIGITAL MODULE TEST ,M5011

;;\*\*\*\*\*

;THIS TEST CHECKS M5011 MODULE  
;16 BIT CHANGE OF STATE SENSE

;;\*\*\*\*\*

M5011:

;;\*\*\*\*\*

TST17: SCOPE

MOV #17, TNUMB  
MOV TADDR, COSADR  
ADD #2, COSADR  
BISB #DBIT!#TBIT, @CSR; SET DISABLE BIT AND TBIT  
MOVB #377, %GDDAT ; SET WHAT DATA SHOULD BE  
MOV #2, BYTNUM ; SET NUMBER OF BYTES  
JSR PC, TSTBYT ; CHECK IF DATA IS CORRECT

BICB #TBIT, @CSR ; CLEAR COMPLIM BIT  
MOVB #0, %GDDAT ; SET WHAT DATA SHOULD BE  
MOV #2, BYTNUM ; SET NUMBER OF BYTES  
JSR PC, TSTBYT ; CHECK IF DATA IS CORRECT  
JSR PC, CLRINT  
MOV #PRO, -(SP) ; SET PSW TO PRIORITY 0  
MOV #64\$, -(SP)

RTI  
64\$: NOP  
MOV #1\$, @VECTO ; SET INTERRUPT VECTOR  
MOV #PR7, @VECTORA  
BISB #TBIT, @CSR ; START INTERRUPT  
BISB #EBIT, @CSR ; ENABLE INTERRUPT  
CLR YLOOP ; WAIT

65\$: INC YLOOP  
CMP YLOOP, #-1  
BNE 65\$

ERROR 5 ; NO INTERRUPT  
2\$: BICB #EBIT, @CSR ; CLEAR CSR  
BICB #TBIT, @CSR  
JSR PC, CLRINT ; CLEAR ALL INTERRUPTS

SCOPE  
RTS PC ; RETURN TO MONITOR

1\$: CMP (SP)+, (SP)+ ; ADJUST STOCK POINTER  
CLR TEMP1  
MOV ERRVEC, R4

7\$: MOV #10\$, ERRVEC  
MOVB @IAR, TEMP ; FIND WHICH I/O INTERRUPTED  
CMPB TEMP, TADDR ; IS IT MUT  
BEQ 8\$ ; YES

BIS BASE, TEMP ; ASSEMBLE ADDRESS OF INTERRUPTING MODULE  
BISB #RBIT, @CSR ; CLEAR INTERRUPT

TSTB @TEMP  
INC TEMP1

1692  
1693  
1694  
1695  
1696  
1697  
1698  
1699  
1700  
1701  
1702 010322  
1703  
1704 010322 000004  
1705 010324 112737 000017 002022  
1706 010332 013737 002006 002014  
1707 010340 062737 000002 002014  
1708 010346 152777 000030 171452  
1709 010354 112737 000377 001124  
1710 010362 012737 000002 002004  
1711 010370 004737 011746  
1712  
1713 010374 142777 000010 171424  
1714 010402 112737 000000 001124  
1715 010410 012737 000002 002004  
1716 010416 004737 011746  
1717 010422 004737 012360  
1718 010426 012746 000000  
1719 010432 012746 010440  
1720 010436 000002  
1721 010440 000240  
1722 010442 012777 010540 171362  
1723 010450 012777 000340 171356  
1724 010456 152777 000010 171342  
1725 010464 152777 000100 171334  
1726 010472 005037 001766  
1727 010476 005237 001766  
1728 010502 023727 001766 177777  
1729 010510 001372  
1730 010512 104005  
1731 010514 142777 000100 171304  
1732 010522 142777 000010 171276  
1733 010530 004737 012360  
1734 010534 000004  
1735 010536 000207  
1736  
1737 010540 022626  
1738 010542 005037 002050  
1739 010546 013704 000004  
1740 010552 012737 011140 000004  
1741 010560 117737 171244 002046  
1742 010566 123737 002046 002006  
1743 010574 001421  
1744 010576 053737 002042 002046  
1745 010604 152777 000001 171214  
1746 010612 105777 171230  
1747 010616 005237 002050

1748	010622	022737	000400	002050		CMP	#400, TEMP1	
1749	010630	001353				BNE	7\$	
1750	010632	104005				ERROR 5		; NO INTERRUPT
1751	010634	000137	010514			JMP	2\$	
1752	010640	142777	000100	171160	8\$:	BICB	#EBIT, @CSR	
1753	010646	112737	000377	001124		MOVB	#377, \$GDDAT	
1754	010654	117737	171134	001126		MOVB	@COSADR, \$BDDAT	; TEST COS REGISTER
1755	010662	123737	001124	001126		CMPB	\$GDDAT, \$BDDAT	; IS IT ALL ONES
1756	010670	001401				BEQ	3\$	
1757	010672	104020				ERROR 20		; COS REGISTER ERROR
1758	010674	152777	000001	171124	3\$:	BISB	#RBIT, @CSR	
1759	010702	105777	171106			TSTB	@COSADR	; CLEAR INTERRUPT
1760	010706	005037	001124			CLR	\$GDDAT	
1761	010712	117737	171076	001126		MOVB	@COSADR, \$BDDAT	
1762	010720	001401				BEQ	4\$	
1763	010722	104013				ERROR 13		; RIF BIT NOT CLEARING FF
1764	010724	005237	002014		4\$:	INC	COSADR	
1765	010730	005237	002006			INC	TADDR	; TEST NEXT BYTE
1766	010734	117737	171070	002046		MOVB	@IAR, TEMP	
1767	010742	123737	002046	002006		CMPB	TEMP, TADDR	; CHECK IF IT INTERRUPTED
1768	010750	001403				BEQ	11\$	
1769	010752	104005				ERROR 5		; NO INTERRUPT
1770	010754	000137	010514			JMP	2\$	
1771	010760	112737	000377	001124	11\$:	MOVB	#377, \$GDDAT	
1772	010766	117737	171022	001126		MOVB	@COSADR, \$BDDAT	; CHECK IF COS REGISTER IS ALL ONES
1773	010774	123737	001124	001126		CMPB	\$GDDAT, \$BDDAT	
1774	011002	001401				BEQ	5\$	
1775	011004	104020				ERROR 20		; COS REGISTER ERROR
1776	011006	152777	000001	171012	5\$:	BISB	#RBIT, @CSR	
1777	011014	105777	170774			TSTB	@COSADR	; CLEAR INTERRUPT
1778	011020	005037	001124			CLR	\$GDDAT	
1779	011024	117737	170764	001126		MOVB	@COSADR, \$BDDAT	
1780	011032	001401				BEQ	6\$	
1781	011034	104013				ERROR 13		; RIF BIT NOT CLEARING FF
1782	011036	005337	002014		6\$:	DEC	COSADR	
1783	011042	005337	002006			DEC	TADDR	; RESET ADDRESS
1784	011046	004737	012360			JSR	PC, CLRINT	; CLEAR REMAINING INTERRUPTS
1785	011052	132777	000010	170746		BITB	#TBIT, @CSR	; CHECK IF CLEARING T BIT CAUSE INTERRUPT
1786	011060	001615				BEQ	2\$	
1787	011062	012746	000000			MOV	#PRO, -(SP)	; SET PSW TO PRIORITY 0
1788	011066	012746	011074			MOV	#66\$, -(SP)	
1789	011072	000002				RTI		
1790	011074	000240			66\$:	NOP		
1791	011076	142777	000010	170722		BICB	#TBIT, @CSR	; CLEAR INPUTS
1792	011104	152777	000100	170714		BISB	#EBIT, @CSR	
1793	011112	005037	001766			CLR	YLOOP	; WAIT
1794	011116	005237	001766		67\$:	INC	YLOOP	
1795	011122	023727	001766	177777		CMP	YLOOP, #-1	
1796	011130	001372				BNE	67\$	
1797	011132	104005				ERROR 5		; NO INTERRUPT
1798	011134	000137	010514			JMP	2\$	
1799								
1800	011140	022626			10\$:	CMP	(SP)+, (SP)+	; RESET STACK POINTER
1801	011142	104005				ERROR 5		; NO INTERRUPT
1802	011144	000137	010514			JMP	2\$	



```
1803 011150 000240 ANALOG: NOP
1804 .SBTTL DIGITAL MODULE TEST ,M5012
1805
1806 ;*****
1807
1808 ;THIS TEST CHECKS M5012 MODULE
1809 ;ISOLATED 16 BIT DC INPUT
1810
1811 ;*****
1812
1813 011152 M5012:
1814 ;*****
1815 011152 000004 TST20: SCOPE
1816 011154 012737 000020 002022 MOV #20, TNUMB
1817 011162 152777 000020 170636 BISB #DBIT, @CSR
1818 011170 112737 000000 001124 MOVB #0, $GDDAT ;SET WHAT DATA SHOULD BE
1819 011176 012737 000002 002004 MOV #2, BYTNUM ;SET NUMBER OF BYTES
1820 011204 004737 011746 JSR PC, TSTBYT ;CHECK IF DATA IS CORRECT
1821
1822 011210 152777 000010 170610 BISB #TBIT, @CSR
1823 011216 112737 000377 001124 MOVB #377, $GDDAT ;SET WHAT DATA SHOULD BE
1824 011224 012737 000002 002004 MOV #2, BYTNUM ;SET NUMBER OF BYTES
1825 011232 004737 011746 JSR PC, TSTBYT ;CHECK IF DATA IS CORRECT
1826 011236 142777 000010 170562 BICB #TBIT, @CSR
1827 011244 004737 012360 JSR PC, CLRINT
1828
1829 011250 012746 000000 MOV #PRO, -(SP) ;SET PSW TO PRIORITY 0
1830 011254 012746 011262 MOV #64$, -(SP)
1831 011260 000002 RTI
1832 011262 000240 64$: NOP
1833 011264 012777 011362 170540 MOV #6$, @VECTO ;SET INTERRUPT VECTOR
1834 011272 012777 000340 170534 MOV #PR7, @VECTOA
1835 011300 152777 000100 170520 BISB #EBIT, @CSR ;ENABLE INTERRUPT
1836 011306 152777 000010 170512 BISB #TBIT, @CSR ;START INTERRUPT
1837 011314 005037 001766 CLR YLOOP ;WAIT
1838 011320 005237 001766 65$: INC YLOOP
1839 011324 023727 001766 177777 CMP YLOOP, #-1
1840 011332 001372 BNE 65$
1841 011334 104005 ERROR 5 ;NO INTERRUPT
1842 011336 142777 000100 170462 7$: BICB #EBIT, @CSR ;CLEAR CSR
1843 011344 142777 000010 170454 BICB #TBIT, @CSR
1844 011352 004737 012360 JSR PC, CLRINT ;CLEAR ALL INTERRUPT
1845 011356 000004 SCOPE
1846 011360 000207 RTS PC ;RETURN TU MONITOR
1847
1848 011362 022626 6$: CMP (SP)+, (SP)+ ;RESET STACK POINTER
1849 011364 005037 002050 CLR TEMP1
1850 011370 013704 000004 MOV ERRVEC, R4
1851 011374 012737 011626 000004 MOV #4$, ERRVEC
1852 011402 117737 170422 002046 3$: MOVB @IAR, TEMP ;FIND WHICH I/O INTERRUPTED
1853 011410 152777 000001 170410 BISB #RBIT, @CSR
1854 011416 123737 002046 002006 CMPB TEMP, TADDR ;IS IT MUT
1855 011424 001415 BEQ 2$ ;YES
1856 011426 053737 002042 002046 BIS BASE, TEMP ;ASSEMBLE ADDRESS OF INTERRUPTING I/O
1857 011434 105777 170406 TSTB @TEMP ;CLEAR INTERRUPT
1858 011440 005237 002050 INC TEMP1
```

1859	011444	022737	000400	002050		CMP	#400, TEMP1	
1860	011452	001353				BNE	3%	
1861	011454	104005				ERROR 5		; NO INTERRUPT
1862	011456	000727				BR	7%	
1863	011460	105777	170322		2%:	TSTB	@TADDR	; CLEAR INTERRUPT
1864	011464	005237	002006			INC	TADDR	
1865	011470	152777	000001	170330		BISB	#RBIT, @CSR	
1866	011476	105777	170304			TSTB	@TADDR	; CLEAR INTERRUPT IN NEXT BYTE
1867	011502	005337	002006			DEC	TADDR	
1868	011506	132777	000200	170312		BITB	#FBIT, @CSR	; CHECK IF INTERRUPT CLEAR
1869	011514	001413				BEQ	8%	
1870	011516	117737	170306	002046		MOVB	@IAR, TEMP	
1871	011524	123737	002046	002006		CMPB	TEMP, TADDR	
1872	011532	001002				BNE	9%	
1873	011534	104015				ERROR	15	; RIF BIT IS NOT CLEARING INTERRUPT
1874	011536	000430				BR	5%	
1875	011540	004737	012360		9%:	JSR	PC, CLRINT	; CLEAR ALL REMINDING INTERRUPTS
1876	011544	132777	000010	170254	8%:	BITB	#TBIT, @CSR	
1877	011552	001422				BEQ	5%	
1878	011554	012746	000000			MOV	#PRO, -(SP)	; SET PSW TO PRIORITY 0
1879	011560	012746	011566			MOV	#66%, -(SP)	
1880	011564	000002				RTI		
1881	011566	000240			66%:	NOP		
1882	011570	142777	000010	170230		BICB	#TBIT, @CSR	; CHECK IF CLEARING T BIT CAUSE INTERRUPT
1883	011576	005037	001766			CLR	YLOOP	; WAIT
1884	011602	005237	001766		67%:	INC	YLOOP	
1885	011606	023727	001766	177777		CMP	YLOOP, #-1	
1886	011614	001372				BNE	67%	
1887	011616	104005				ERROR 5		; NO INTERRUPT
1888	011620	010437	000004		5%:	MOV	R4, ERRVEC	
1889	011624	000644				BR	7%	
1890								
1891	011626	022626			4%:	CMP	(SP)+, (SP)+	; RESET STACK
1892	011630	104005				ERROR 5		; NO INTERRUPT
1893	011632	000772				BR	5%	

MAIN. MACY11 30(1046) 25-OCT-77 10:10 PAGE 48  
DVPCAR. P11 25-OCT-77 10:02 DIGITAL MODULE TEST ,M5012

L 4

SEQ 0050

1894 011634 000137 003002 EXERC: JMP MONIT

1895	011640				F5010:			
1896	011640				F5011:			
1897	011640	012737	000004	002004	MOV	#4,BYTNUM		;# OF BYTES PER MODULE
1898	011646	004737	012724		JSR	PC,MONDAT		;SUBROUTINE TO MONITOP DATA CONTINUOUSLY
1899								
1900	011652				F5012:			
1901	011652	012737	000002	002004	MOV	#2,BYTNUM		;# OF BYTES PER MODULE
1902	011660	004737	012724		JSR	PC,MONDAT		
1903								
1904	011664				F5013:			
1905	011664	012737	000001	002004	MOV	#1,BYTNUM		;# OF BYTES PER MODULE
1906	011672	004737	012724		JSR	PC,MONDAT		
1907								
1908	011676				F6010:			
1909	011676	012737	000004	002004	MOV	#4,BYTNUM;MODULE IS 4 BYTE LONG		
1910	011704	012700	000004		MOV	#4,RO ;SET A BYTE COUNTER		
1911	011710	004737	012654		JSR	PC,SETPTN		
1912	011714	000207			RTS	PC		
1913								
1914	011716				F6012:			
1915	011716				F6013:			
1916	011716	012737	000001	002004	MOV	#1,BYTNUM		
1917	011724	004737	012654		JSR	PC,SETPTN		;ROUTINE TO OUTPUT ANY PATTERN TOOUT MODULE
1918	011730	000207			RTS	PC		
1919								
1920	011732				F6011:			
1921	011732	012737	000002	002004	MOV	#2,BYTNUM		;MODULE IS 2 BYTE LONG
1922	011740	004737	012654		JSR	PC,SETPTN		
1923	011744	000207			RTS	PC		

```

1924          .SBTTL  SUBROUTINES
1925          ;THIS SUBROUTINE IS USED TO CHECK IF
1926          ;A BITE OF DATA IN $GDDAT=$BDDAT.
1927          ;IT CHECKS AS MANY BYTES AS SPECIFIED
1928          ;BY      BYTNUM
1929
1930          TSTBYT:
1931 011746      MOV      BYTNUM, -(SP)      ;; PUSH BYTNUM ON STACK
1932 011752      MOV      TADDR, -(SP)    ;; PUSH TADDR ON STACK
1933 011756      MOVB     @TADDR, $BDDAT  ;; MOV DATA TO BDDAT
1934 011764      CMPB    $GDDAT, $BDDAT  ;; IS DATA OK
1935 011772      BEQ      1$
1936 011774      MOV      TADDR, TBADDR
1937 012002      ERROR   7
1938 012004      1$:    INC      TADDR      ; NEXT BYTE
1939 012010      DEC      BYTNUM
1940 012014      BNE     2$
1941 012016      MOV     (SP)+, TADDR    ;; POP STACK INTO TADDR
1942 012022      MOV     (SP)+, BYTNUM   ;; POP STACK INTO BYTNUM
1943 012026      RTS      PC
1944
1945          TSTONE:
1946 012030      MOV      BYTNUM, -(SP)    ;; PUSH BYTNUM ON STACK
1947 012034      MOV      TADDR, -(SP)    ;; PUSH TADDR ON STACK
1948 012040      MOVB     @TADDR, $BDDAT  ;; MOV DATA TO BDDAT
1949 012046      CMPB    $GDDAT, $BDDAT  ;; IS DATA OK
1950 012054      BEQ      1$
1951 012056      MOV      TADDR, TBADDR
1952 012064      ERROR   11
1953 012066      1$:    INC      TADDR      ; NEXT BYTE
1954 012072      DEC      BYTNUM
1955 012076      BNE     2$
1956 012100      MOV     (SP)+, TADDR    ;; POP STACK INTO TADDR
1957 012104      MOV     (SP)+, BYTNUM   ;; POP STACK INTO BYTNUM
1958 012110      RTS      PC
  
```

```

1959                                     ; THIS SUBROUTINE IS USED TO SET AS MANY
1960                                     ; BYTES AS SPECIFIED BY BYTNUM IN MUT
1961
1962 012112                               SETBYT:
1963 012112 013746 002004                 MOV    BYTNUM, -(SP)    ;; PUSH BYTNUM ON STACK
1964 012116 013746 002006                 MOV    TADDR, -(SP)   ;; PUSH TADDR ON STACK
1965 012122 113777 001124 167656 1$:     MOVB   $GDDAT, @TADDR  ; SET DATA IN MUT
1966 012130 005237 002006                 INC    TADDR
1967 012134 005337 002004                 DEC    BYTNUM
1968 012140 001370                         BNE    1$
1969 012142 012637 002006                 MOV    (SP)+, TADDR   ;; POP STACK INTO TADDR
1970 012146 012637 002004                 MOV    (SP)+, BYTNUM  ;; POP STACK INTO BYTNUM
1971 012152 000207                         RTS    PC

```

```
1972
1973
1974
1975 012154 005004
1976 012156 012703 001700
1977 012162 022301
1978 012164 001404
1979 012166 062704 000006
1980 012172 005713
1981 012174 001372
1982 012176 000207
1983
1984
1985
1986
1987 012200 005004
1988 012202 012703 001700
1989 012206 022301
1990 012210 001404
1991 012212 062704 000002
1992 012216 005713
1993 012220 001372
1994 012222 010022
1995 012224 010125
1996 012226 000207

; THESE TWO SUBROUTINES ARE USED IN MAPPING THE SYSTEM

GENCOD: CLR R4
MOV #GENER, R3
3$: CMP (R3)+, R1
BEQ 1$
ADD #6, R4
TST (R3)
BNE 3$
1$: RTS PC

TABLE: CLR R4
MOV #GENER, R3
3$: CMP (R3)+, R1
BEQ 1$
ADD #2, R4
TST (R3)
BNE 3$
1$: MOV R0, (R2)+
MOV R1, (R5)+
RTS PC
```

```

1997                                     ; THIS SUBROUTINE CHECKS IF A BIT GET SET AND CLEAR IN CSR
1998
1999 012230 113777 001124 167570 BITSET: MOVB  $GDDAT, @CSR      ; LOAD TESTED BIT
2000 012236 005037 001126                CLR  $BDDAT
2001 012242 005037 001766                CLR  YLOOP          ; WAIT
2002 012246 005237 001766                64$: INC  YLOOP
2003 012252 023727 001766 000007        CMP  YLOOP, #7
2004 012260 001372                BNE  64$
2005 012262 117737 167540 001126        MOVB @CSR, $BDDAT    ; READ CSR
2006 012270 023727 002022 000005        CMP  TNUMB, #5
2007 012276 001003                BNE  2$
2008 012300 142737 000200 001126        BICB #FBIT, $BDDAT
2009 012306 123737 001124 001126        2$: CMPB $GDDAT, $BDDAT ; COMPARE THEME
2010 012314 001002                BNE  1$
2011 012316 062716 000002                ADD  #2, (SP)       ; NO ERROR
2012 012322 000337 001124                1$: SWAB $GDDAT
2013 012326 000337 001126                SWAB $BDDAT
2014 012332 042737 177400 001126        BIC  #177400, $BDDAT
2015 012340 042737 177400 001124        BIC  #177400, $GDDAT
2016 012346 000207                RTS  PC
2017
2018                                     ; THIS IS INTERRUPT RUTINE FOR LINE CLOCK
2019                                     ; WHEN DIAGNOSTIC DOES NOT USE IT
2020
2021 012350                NOCLK:
2022 012350 000002                RTI
2023
2024                                     ; THIS IS INTERRUPT RUTINE FOR CLOCK TO COUNT TICKS
2025
2026 012352 005237 002044                COUNT: INC  CLK
2027 012356 000002                RTI
2028

```



```

2029                                     ; THIS SUBROUTINE CLEARS UNEXPECTED INTERRUPTS FROM DBUS
2030 012360 005037 002052          CLRINT: CLR      TEMP3
2031 012364 005037 002054          CLR      TEMP4
2032 012370 132777 000200 167430 2$: BITB    #FBIT, @CSR      ; IS INTERRUPT PENDING?
2033 012376 001422                   BEQ      1$              ; NO
2034 012400 117737 167424 002052    MOVB    @IAR, TEMP3
2035 012406 053737 002042 002052    BIS     BASE, TEMP3
2036 012414 152777 000001 167404    BISB   #RBIT, @CSR
2037 012422 105777 167424          TSTB   @TEMP3
2038 012426 005237 002054          INC     TEMP4
2039 012432 032737 000400 002054    BIT     #BIT8, TEMP4
2040 012440 001753                   BEQ     2$
2041 012442 104023                   ERROR   23              ; UNABLE TO CLEAR INTERRUPT
2042 012444 000207          1$:      RTS     PC
2043
2044
2045                                     ; THIS SUBROUTINE CHECKS FOR CONTROL C
2046
2047
2048 012446 117746 166474          CNTRC: MOVB    @$TKB, -(SP)
2049 012452 042716 000200          BIC     #BIT7, (SP)      ; CLEAR PARITY BIT
2050 012456 122716 000003          CMPB   #3, (SP)        ; CONTROL C?
2051 012462 001030                   BNE     1$              ; NO
2052 012464 152777 000002 167334    BISB   #CBIT, @CSR      ; SET C BIT
2053 012472 005037 001766          CLR     YLOOP          ; WAIT
2054 012476 005237 001766          64$:   INC     YLOOP
2055 012502 023727 001766 000007    CMP     YLOOP, #7
2056 012510 001372                   BNE     64$
2057 012512 152777 000002 167306    BISB   #CBIT, @CSR      ; DO IT AGAIN
2058 012520 005037 001766          CLR     YLOOP          ; WAIT
2059 012524 005237 001766          65$:   INC     YLOOP
2060 012530 023727 001766 000007    CMP     YLOOP, #7
2061 012536 001372                   BNE     65$
2062 012540 000137 003002          JMP     MONIT
2063 012544 005726          1$:   TST     (SP)+
2064 012546 000207          RTS     PC
2065
2066
2067 012550 004737 012446          KBINT: JSR     PC, CNTRC
2068 012554 000002          RTI

```

MAIN. MACY11 30(1046) 25-OCT-77 10:10 PAGE 55  
 DVPCAR. P11 25-OCT-77 10:02 SUBROUTINES

SEQ 0057

```

2069                                     ; THIS SUBROUTINE IS USED IN THE LOOP TEST
2070                                     ; AND IT IS SIMILAR TO THE TSTBYT ROUTINE
2071
2072 012556                                CHKBYT:
2073 012556 013746 002050                 MOV     TEMP1, -(SP)           ;; PUSH TEMP1 ON STACK
2074 012562 013746 002004                 MOV     BYTNUM, -(SP)        ;; PUSH BYTNUM ON STACK
2075 012566 117737 167256 001126 2$:     MOV     @TEMP1, $BDDAT       ; READ DATA FROM INPUT MODULE
2076 012574 123737 001124 001126         CMP     $GDDAT, $BDDAT
2077 012602 001410                         BEQ     1$
2078 012604 013737 002006 002012         MOV     TADDR, TBADDR
2079 012612 012637 002004                 MOV     (SP)+, BYTNUM       ;; POP STACK INTO BYTNUM
2080 012616 012637 002050                 MOV     (SP)+, TEMP1       ;; POP STACK INTO TEMP1
2081 012622 000207                         RTS     PC                   ; ERROR
2082 012624 005237 002050 1$:           INC     TEMP1                ; GO TO NEXT BYTE
2083 012630 005337 002004                 DEC     BYTNUM
2084 012634 001354                         BNE     2$
2085 012636 012637 002004                 MOV     (SP)+, BYTNUM       ;; POP STACK INTO BYTNUM
2086 012642 012637 002050                 MOV     (SP)+, TEMP1       ;; POP STACK INTO TEMP1
2087 012646 062716 000002                 ADD     #2, (R6)           ; BYPASS ERROR IN MAINLINE CODE
2088 012652 000207                         RTS     PC
2089

```

```

2090                                     ; THIS SUBROUTINE ALLOWS FIELD ENGINEER TO SELECT ANY
2091                                     ; DATA PATTERN FOR OUTPUT MODULES
2092
2093
2094 012654 142777 000020 167144 SETPTN: BICB   #DBIT,@CSR
2095 012662 142777 000004 167136 BICB   #GBIT,@CSR
2096 012670 104401 021323          1$: TYPE   ,MASS19          ; SELECT A DATA PATTERN
2097 012674 104410 RDOCT
2098 012676 012637 001124          MOV   (SP)+,$GDDAT      ;; POP STACK INTO $GDDAT
2099 012702 113777 001124 167076 MOVB  $GDDAT,@TADDR    ; OUTPUT PATTERN TO MODULE
2100 012710 005237 002006          INC   TADDR
2101 012714 005337 002004          DEC   BYTNUM
2102 012720 001363          BNE   1$
2103 012722 000207          RTS    PC
2104
2105                                     ; THIS SUBROUTINE IS USED IN FIELD TEST TO CONTINUOUSLY
2106                                     ; MONITOR DATA FROM INPUT MODULE. DATA IS PRINTED ONLY
2107                                     ; DURING FIRST PASS UNLESS THERE IS A CHANGE IN THE DATA
2108 012724 005001          MONDAT: CLR   R1          ; CLEAR PASS REGISTER
2109 012726 013700 002004          6$: MOV   BYTNUM,R0      ; # OF BYTES PER MODULE
2110 012732 005300          5$: DEC   R0
2111 012734 117737 167046 001124 1$: MOVB  @TADDR,$GDDAT    ; STORE DATA
2112 012742 005701          TST   R1          ; IS IT FIRST PASS?
2113 012744 001016          BNE   4$          ; NO
2114 012746 117760 167034 001770 2$: MOVB  @TADDR,DBUFF(R0)    ; STORE DATA IN TABLE
2115 012754 013746 002006          MOV   TADDR,-(SP)      ; SAVE TADDR FOR TYPEOUT
2116 012760 104402          TYPOC          ; GO TYPE--OCTAL ASCII(ALL DIGITS)
2117 012762 104401 021645          TYPE  ,MASS27      ; COLON & TAB
2118 012766 013746 001124          MOV   $GDDAT,-(SP)    ; SAVE $GDDAT FOR TYPEOUT
2119 012772 104402          TYPOC          ; GO TYPE--OCTAL ASCII(ALL DIGITS)
2120 012774 104401 020417          TYPE  ,MASS0      ; CR & LF
2121 013000 000404          BR    3$
2122 013002 123760 001124 001770 4$: CMPB  $GDDAT,DBUFF(R0)    ; ANY CHANGE IN DATA ?
2123 013010 001356          BNE   2$          ; YES
2124 013012 005237 002006          3$: INC   TADDR      ; GO TO NEXT BYTE IN MODULE
2125 013016 005700          TST   R0          ; LAST BYTE IN MODULE ?
2126 013020 001344          BNE   5$          ; NO
2127 013022 163737 002004 002006 SUB   BYTNUM,TADDR    ; RESTORE ADDRESS OF MUT
2128 013030 004737 012446          JSR   PC,CNTRC      ; TYPE CONTROL C TO RETURN TO MONITOR
2129 013034 012701 000001          MOV   #1,R1        ; NEW PASS
2130 013040 000732          BR    6$

```

```

2131
2132 ; THIS SUBROUTINE IS USED TO WRAP AROUND DATA "LOOP TEST"
2133
2134
2135 013042          LOPTST:
2136 013042 152777 000002 166756  BISB  #CBIT, @CSR  ; SET C BIT
2137 013050 005037 001766          CLR  YLOOP      ; WAIT
2138 013054 005237 001766          64$: INC  YLOOP
2139 013060 023727 001766 000007  CMP  YLOOP, #7
2140 013066 001372          BNE  64$
2141 013070 152777 000002 166730  BISB  #CBIT, @CSR  ; DO IT AGAIN
2142 013076 005037 001766          CLR  YLOOP      ; WAIT
2143 013102 005237 001766          65$: INC  YLOOP
2144 013106 023727 001766 000007  CMP  YLOOP, #7
2145 013114 001372          BNE  65$
2146 013116 020127 000141          CMP  R1, #141 ; IS IT M5010?
2147 013122 001131          BNE  1$          ; YES
2148 013124 012737 000125 001124  MOV  #125, $GDDAT
2149 013132 012737 000004 002004  MOV  #4, BYTNUM
2150 013140 004737 012112          JSR  PC, SETBYT  ; OUTPUT DATAT PATTERN
2151 013144 005037 001766          CLR  YLOOP      ; WAIT
2152 013150 005237 001766          66$: INC  YLOOP
2153 013154 023727 001766 001777  CMP  YLOOP, #1777
2154 013162 001372          BNE  66$
2155 013164 012737 000004 002004  MOV  #4, BYTNUM
2156 013172 004737 012556          JSR  PC, CHKBYT  ; COMPARE DATA
2157 013176 104021          ERROR  21
2158 013200 012737 000252 001124  MOV  #252, $GDDAT
2159 013206 012737 000004 002004  MOV  #4, BYTNUM
2160 013214 004737 012112          JSR  PC, SETBYT  ; OUTPUT DATAT PATTERN
2161 013220 005037 001766          CLR  YLOOP      ; WAIT
2162 013224 005237 001766          67$: INC  YLOOP
2163 013230 023727 001766 001777  CMP  YLOOP, #1777
2164 013236 001372          BNE  67$
2165 013240 012737 000004 002004  MOV  #4, BYTNUM
2166 013246 004737 012556          JSR  PC, CHKBYT  ; COMPARE DATA
2167 013252 104021          ERROR  21
2168 013254 012737 000377 001124  MOV  #377, $GDDAT
2169 013262 012737 000004 002004  MOV  #4, BYTNUM
2170 013270 004737 012112          JSR  PC, SETBYT  ; OUTPUT DATAT PATTERN
2171 013274 005037 001766          CLR  YLOOP      ; WAIT
2172 013300 005237 001766          68$: INC  YLOOP
2173 013304 023727 001766 001777  CMP  YLOOP, #1777
2174 013312 001372          BNE  68$
2175 013314 012737 000004 002004  MOV  #4, BYTNUM
2176 013322 004737 012556          JSR  PC, CHKBYT  ; COMPARE DATA
2177 013326 104021          ERROR  21
2178 013330 012737 000000 001124  MOV  #0, $GDDAT
2179 013336 012737 000004 002004  MOV  #4, BYTNUM
2180 013344 004737 012112          JSR  PC, SETBYT  ; OUTPUT DATAT PATTERN
2181 013350 005037 001766          CLR  YLOOP      ; WAIT
2182 013354 005237 001766          69$: INC  YLOOP
2183 013360 023727 001766 001777  CMP  YLOOP, #1777
2184 013366 001372          BNE  69$
2185 013370 012737 000004 002004  MOV  #4, BYTNUM
2186 013376 004737 012556          JSR  PC, CHKBYT  ; COMPARE DATA
  
```

2187	013402	104021			ERROR	21	
2188	013404	000530			BR	25	
2189	013406						
2190	013406	012737	000125	001124	15: MOV	#125, \$GDDAT	
2191	013414	012737	000002	002004	MOV	#2, BYTNUM	
2192	013422	004737	012112		JSR	PC, SETBYT	; OUTPUT DATAT PATTERN
2193	013426	005037	001766		CLR	YLOOP	; WAIT
2194	013432	005237	001766		705: INC	YLOOP	
2195	013436	023727	001766	001777	CMP	YLOOP, #1777	
2196	013444	001372			BNE	705	
2197	013446	012737	000002	002004	MOV	#2, BYTNUM	
2198	013454	004737	012556		JSR	PC, CHKBYT	; COMPARE DATA
2199	013460	104021			ERROR	21	
2200	013462	012737	000252	001124	MOV	#252, \$GDDAT	
2201	013470	012737	000002	002004	MOV	#2, BYTNUM	
2202	013476	004737	012112		JSR	PC, SETBYT	; OUTPUT DATAT PATTERN
2203	013502	005037	001766		CLR	YLOOP	; WAIT
2204	013506	005237	001766		715: INC	YLOOP	
2205	013512	023727	001766	001777	CMP	YLOOP, #1777	
2206	013520	001372			BNE	715	
2207	013522	012737	000002	002004	MOV	#2, BYTNUM	
2208	013530	004737	012556		JSR	PC, CHKBYT	; COMPARE DATA
2209	013534	104021			ERROR	21	
2210	013536	012737	000377	001124	MOV	#377, \$GDDAT	
2211	013544	012737	000002	002004	MOV	#2, BYTNUM	
2212	013552	004737	012112		JSR	PC, SETBYT	; OUTPUT DATAT PATTERN
2213	013556	005037	001766		CLR	YLOOP	; WAIT
2214	013562	005237	001766		725: INC	YLOOP	
2215	013566	023727	001766	001777	CMP	YLOOP, #1777	
2216	013574	001372			BNE	725	
2217	013576	012737	000002	002004	MOV	#2, BYTNUM	
2218	013604	004737	012556		JSR	PC, CHKBYT	; COMPARE DATA
2219	013610	104021			ERROR	21	
2220	013612	012737	000000	001124	MOV	#0, \$GDDAT	
2221	013620	012737	000002	002004	MOV	#2, BYTNUM	
2222	013626	004737	012112		JSR	PC, SETBYT	; OUTPUT DATAT PATTERN
2223	013632	005037	001766		CLR	YLOOP	; WAIT
2224	013636	005237	001766		735: INC	YLOOP	
2225	013642	023727	001766	001777	CMP	YLOOP, #1777	
2226	013650	001372			BNE	735	
2227	013652	012737	000002	002004	MOV	#2, BYTNUM	
2228	013660	004737	012556		JSR	PC, CHKBYT	; COMPARE DATA
2229	013664	104021			ERROR	21	
2230	013666	000207			25: RTS	PC	

SCOPE HANDLER ROUTINE

```
2231 . SBTTL SCOPE HANDLER ROUTINE
2232
2233 ; *****
2234 ; *THIS ROUTINE CONTROLS THE LOOPING OF SUBTESTS. IT WILL INCREMENT
2235 ; *AND LOAD THE TEST NUMBER($TSTNM) INTO THE DISPLAY REG. (DISPLAY<7: 0>)
2236 ; *AND LOAD THE ERROR FLAG ($ERFLG) INTO DISPLAY<15: 08>
2237 ; *THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
2238 ; *SW09=1 LOOP ON ERROR
2239 ; *CALL
2240 ; * SCOPE ; ; SCOPE=10T
2241
2242 013670 $SCOPE:
2243 ; #####START OF CODE FOR THE XOR TESTER#####
2244 013670 000416 $XTSTR: BR 6$ ; ; IF RUNNING ON THE "XOR" TESTER CHANGE
2245 ; ; THIS INSTRUCTION TO A "NOP" (NOP=240)
2246 013672 013746 000004 MOV @#ERRVEC, -(SP) ; ; SAVE THE CONTENTS OF THE ERROR VECTOR
2247 013676 012737 013716 000004 MOV #5$, @#ERRVEC ; ; SET FOR TIMEOUT
2248 013704 005737 177060 TST @#177060 ; ; TIME OUT ON XOR?
2249 013710 012637 000004 MOV (SP)+, @#ERRVEC ; ; RESTORE THE ERROR VECTOR
2250 013714 000421 BR $SVLAD ; ; GO TO THE NEXT TEST
2251 013716 022626 5$: CMP (SP)+, (SP)+ ; ; CLEAR THE STACK AFTER A TIME OUT
2252 013720 012637 000004 MOV (SP)+, @#ERRVEC ; ; RESTORE THE ERROR VECTOR
2253 013724 000407 BR 7$ ; ; LOOP ON THE PRESENT TEST
2254 013726 6$: #####END OF CODE FOR THE XOR TESTER#####
2255 013726 105737 001103 2$: TSTB $ERFLG ; ; HAS AN ERROR OCCURRED?
2256 013732 001412 BEQ $SVLAD ; ; BR IF NO
2257 013734 032777 001000 165176 BIT #BIT09, @SWR ; ; LOOP ON ERROR?
2258 013742 001404 BEQ 4$ ; ; BR IF NO
2259 013744 013737 001110 001106 7$: MOV $LPERR, $LPADR ; ; SET LOOP ADDRESS TO LAST SCOPE
2260 013752 000415 BR $OVER
2261 013754 105037 001103 4$: CLRB $ERFLG ; ; ZERO THE ERROR FLAG
2262 013760 105237 001102 $SVLAD: INCB $TSTNM ; ; COUNT TEST NUMBERS
2263 013764 011637 001106 MOV (SP), $LPADR ; ; SAVE SCOPE LOOP ADDRESS
2264 013770 011637 001110 MOV (SP), $LPERR ; ; SAVE ERROR LOOP ADDRESS
2265 013774 005037 001172 CLR $ESCAPE ; ; CLEAR THE ESCAPE FROM ERROR ADDRESS
2266 014000 112737 000001 001115 MOVB #1, $EMAX ; ; ONLY ALLOW ONE(1) ERROR ON NEXT TEST
2267 014006 013777 001102 165126 $OVER: MOV $TSTNM, @DISPLAY ; ; DISPLAY TEST NUMBER
2268 014014 013716 001106 MOV $LPADR, (SP) ; ; FUDGE RETURN ADDRESS
2269 014020 000002 RTI ; ; FIXES PS
2270 014022 $SW08TBL:
2271 014022 005416 . WORD TST1+2 ; ; STARTING ADDRESS OF TEST 1
2272 014024 005550 . WORD TST2+2 ; ; STARTING ADDRESS OF TEST 2
2273 014026 005614 . WORD TST3+2 ; ; STARTING ADDRESS OF TEST 3
2274 014030 005660 . WORD TST4+2 ; ; STARTING ADDRESS OF TEST 4
2275 014032 006054 . WORD TST5+2 ; ; STARTING ADDRESS OF TEST 5
2276 014034 006124 . WORD TST6+2 ; ; STARTING ADDRESS OF TEST 6
2277 014036 006170 . WORD TST7+2 ; ; STARTING ADDRESS OF TEST 7
2278 014040 006234 . WORD TST10+2 ; ; STARTING ADDRESS OF TEST 10
2279 014042 006400 . WORD TST11+2 ; ; STARTING ADDRESS OF TEST 11
2280 014044 006674 . WORD TST12+2 ; ; STARTING ADDRESS OF TEST 12
2281 014046 006776 . WORD TST13+2 ; ; STARTING ADDRESS OF TEST 13
2282 014050 007442 . WORD TST14+2 ; ; STARTING ADDRESS OF TEST 14
2283 014052 007634 . WORD TST15+2 ; ; STARTING ADDRESS OF TEST 15
2284 014054 010026 . WORD TST16+2 ; ; STARTING ADDRESS OF TEST 16
2285 014056 010324 . WORD TST17+2 ; ; STARTING ADDRESS OF TEST 17
2286 014060 011154 . WORD TST20+2 ; ; STARTING ADDRESS OF TEST 20
```

```

2287 .SBTTL TTY INPUT ROUTINE
2288
2289 ;:*****
2290 .ENABL LSB
2291
2292 .DSABL LSB
2293
2294
2295 ;:*****
2296 ;*THIS ROUTINE WILL INPUT A SINGLE CHARACTER FROM THE TTY
2297 ;*CALL:
2298 ;* RDCHR ;: INPUT A SINGLE CHARACTER FROM THE TTY
2299 ;* RETURN HERE ;: CHARACTER IS ON THE STACK
2300 ;* ;: WITH PARITY BIT STRIPPED OFF
2301 ;
2302
2303 014062 011646 SRDCHR: MOV (SP),-(SP) ;: PUSH DOWN THE PC
2304 014064 016666 000004 000002 MOV 4(SP),2(SP) ;: SAVE THE PS
2305 014072 105777 165046 15: TSTB @STKS ;: WAIT FOR
2306 014076 100375 BPL 1$ ;: A CHARACTER
2307 014100 117766 165042 000004 MOVB @STKB,4(SP) ;: READ THE TTY
2308 014106 042766 177600 000004 BIC #C<177>,4(SP) ;: GET RID OF JUNK IF ANY
2309 014114 026627 000004 000023 CMP 4(SP),#23 ;: IS IT A CONTROL-S?
2310 014122 001013 BNE 3$ ;: BRANCH IF NO
2311 014124 105777 165014 25: TSTB @STKS ;: WAIT FOR A CHARACTER
2312 014130 100375 BPL 2$ ;: LOOP UNTIL ITS THERE
2313 014132 117746 165010 MOVB @STKB,-(SP) ;: GET CHARACTER
2314 014136 042716 177600 BIC #C177,(SP) ;: MAKE IT 7-BIT ASCII
2315 014142 022627 000021 CMP (SP)+,#21 ;: IS IT A CONTROL-Q?
2316 014146 001366 BNE 2$ ;: IF NOT DISCARD IT
2317 014150 000750 BR 1$ ;: YES, RESUME
2318 014152 026627 000004 000140 35: CMP 4(SP),#140 ;: IS IT UPPER CASE?
2319 014160 002407 BLT 4$ ;: BRANCH IF YES
2320 014162 026627 000004 000175 CMP 4(SP),#175 ;: IS IT A SPECIAL CHAR?
2321 014170 003003 BGT 4$ ;: BRANCH IF YES
2322 014172 042766 000040 000004 BIC #40,4(SP) ;: MAKE IT UPPER CASE
2323 014200 000002 45: RTI ;: GO BACK TO USER
2324 ;:*****
2325 ;*THIS ROUTINE WILL INPUT A STRING FROM THE TTY
2326 ;*CALL:
2327 ;* RDLIN ;: INPUT A STRING FROM THE TTY
2328 ;* RETURN HERE ;: ADDRESS OF FIRST CHARACTER WILL BE ON THE STACK
2329 ;* ;: TERMINATOR WILL BE A BYTE OF ALL 0'S
2330
2331 014202 010346 SRDLIN: MOV R3,-(SP) ;: SAVE R3
2332 014204 012703 014310 15: MOV #STTYIN,R3 ;: GET ADDRESS
2333 014210 022703 014320 25: CMP #STTYIN+8.,R3 ;: BUFFER FULL?
2334 014214 101405 BLOS 4$ ;: BR IF YES
2335 014216 104406 RDCHR ;: GO READ ONE CHARACTER FROM THE TTY
2336 014220 112613 MOVB (SP)+,(R3) ;: GET CHARACTER
2337 014222 122713 000177 105: CMPB #177,(R3) ;: IS IT A RUBOUT
2338 014226 001003 BNE 3$ ;: SKIP IF NOT
2339 014230 104401 001174 45: TYPE ,SQUES ;: TYPE A '?'
2340 014234 000763 BR 1$ ;: CLEAR THE BUFFER AND LOOP
2341 014236 111337 014306 35: MOVB (R3),9$ ;: ECHO THE CHARACTER
2342 014242 104401 014306 TYPE ,9$

```

```

2343 014246 122723 000015      CMPB   #15,(R3)+      ;;CHECK FOR RETURN
2344 014252 001356              BNE    2$            ;;LOOP IF NOT RETURN
2345 014254 105063 177777      CLRB   -1(R3)        ;;CLEAR RETURN (THE 15)
2346 014260 104401 001176      TYPE   , $LF         ;;TYPE A LINE FEED
2347 014264 012603              MOV    (SP)+,R3      ;;RESTORE R3
2348 014266 011646              MOV    (SP),-(SP)    ;;ADJUST THE STACK AND PUT ADDRESS OF THE
2349 014270 016666 000004 000002  MOV    4(SP),2(SP)   ;; FIRST ASCII CHARACTER ON IT
2350 014276 012766 014310 000004  MOV    #$TTYIN,4(SP)
2351 014304 000002              RTI                    ;;RETURN
2352 014306 000          9$:   .BYTE   0            ;;STORAGE FOR ASCII CHAR. TO TYPE
2353 014307 000          .BYTE   0            ;;TERMINATOR
2354 014310 000010          $TTYIN: .BLKB   8      ;;RESERVE 8 BYTES FOR TTY INPUT
2355 014320 052536 005015 000  $CNTLU: .ASCIZ  / U/<15><12>  ;;CONTROL "U"
2356 014325 136 006507 000012  $CNTLG: .ASCIZ  / G/<15><12>  ;;CONTROL "G"
2357 014332 005015 053523 020122  $MSWR:  .ASCIZ  <15><12>/SWR = /
2358 014340 020075 000
2359 014343 040 047040 053505  $MNEW:  .ASCIZ  / NEW = /
2360 014350 036440 000040
2361
2362      .SBTTL  READ AN OCTAL NUMBER FROM THE TTY
2363      ;;*****
2364      ;;*THIS ROUTINE WILL READ AN OCTAL (ASCII) NUMBER FROM THE TTY AND
2365      ;;*CHANGE IT TO BINARY.
2366      ;;*THE INPUT CHARACTERS WILL BE CHECKED TO INSURED THEY ARE LEGAL
2367      ;;*OCTAL DIGITS. IF AN ILLEGAL CHARACTER IS READ A "?" WILL BE TYPED
2368      ;;*FOLLOWED BY A CARRIAGE RETURN-LINE FEED. THE COMPLETE NUMBER MUST
2369      ;;*THEN BE RETYPED. THE INPUT IS TERMINATED BY TYPING A CARRIAGE RETURN.
2370      ;;*CALL:
2371      ;;*      RDOCT          ;;READ AN OCTAL NUMBER
2372      ;;*      RETURN HERE    ;;LOW ORDER BITS ARE ON TOP OF THE STACK
2373      ;;*                    ;;HIGH ORDER BITS ARE IN $HIOCT
2374
2375 014354 011646          $RDOCT: MOV    (SP),-(SP)   ;;PROVIDE SPACE FOR THE
2376 014356 016666 000004 000002  MOV    4(SP),2(SP)   ;;INPUT NUMBER
2377 014364 010046          MOV    R0,-(SP)     ;;PUSH R0 ON STACK
2378 014366 010146          MOV    R1,-(SP)     ;;PUSH R1 ON STACK
2379 014370 010246          MOV    R2,-(SP)     ;;PUSH R2 ON STACK
2380 014372 104407          1$:   RDLIN        ;;READ AN ASCII LINE
2381 014374 012600          MOV    (SP)+,R0     ;;GET ADDRESS OF 1ST CHARACTER
2382 014376 010037 014502  MOV    R0,$5         ;;AND SAVE IT
2383 014402 005001          CLR    R1           ;;CLEAR DATA WORD
2384 014404 005002          CLR    R2
2385 014406 112046          2$:   MOVB   (R0)+,-(SP)  ;;PICKUP THIS CHARACTER
2386 014410 001420          BEQ   3$            ;;IF ZERO GET OUT
2387 014412 122716 000060  CMPB   #'0,(SP)      ;;MAKE SURE THIS CHARACTER
2388 014416 003026          BGT   4$            ;;IS AN OCTAL DIGIT
2389 014420 122716 000067  CMPB   #'7,(SP)
2390 014424 002423          BLT   4$
2391 014426 006301          ASL   R1             ;;*2
2392 014430 006102          ROL   R2
2393 014432 006301          ASL   R1             ;;*4
2394 014434 006102          ROL   R2
2395 014436 006301          ASL   R1             ;;*8
2396 014440 006102          ROL   R2
2397 014442 042716 177770  BIC   #7,(SP)        ;;STRIP THE ASCII JUNK
2398 014446 062601          ADD   (SP)+,R1      ;;ADD IN THIS DIGIT
  
```



```
2399 014450 000756 BR 2$ ;; LOOP
2400 014452 005726 3$: TST (SP)+ ;; CLEAN TERMINATOR FROM STACK
2401 014454 010166 000012 MOV R1,12(SP) ;; SAVE THE RESULT
2402 014460 010237 014512 MOV R2,$HIOCT
2403 014464 012602 MOV (SP)+,R2 ;; POP STACK INTO R2
2404 014466 012601 MOV (SP)+,R1 ;; POP STACK INTO R1
2405 014470 012600 MOV (SP)+,R0 ;; POP STACK INTO R0
2406 014472 000002 RTI ;; RETURN
2407 014474 005726 4$: TST (SP)+ ;; CLEAN PARTIAL FROM STACK
2408 014476 105010 CLR (R0) ;; SET A TERMINATOR
2409 014500 104401 TYPE ;; TYPE UP THRU THE BAD CHAR.
2410 014502 000000 5$: .WORD 0
2411 014504 104401 001174 TYPE , $QUES ;; "?" "CR" & "LF"
2412 014510 000730 BR 1$ ;; TRY AGAIN
2413 014512 000000 $HIOCT: .WORD 0 ;; HIGH ORDER BITS GO HERE
2414 .SBTTL ERROR HANDLER ROUTINE
2415
2416 ;; *****
2417 ;; *THIS ROUTINE WILL INCREMENT THE ERROR FLAG AND THE ERROR COUNT,
2418 ;; *SAVE THE ERROR ITEM NUMBER AND THE ADDRESS OF THE ERROR CALL
2419 ;; *AND GO TO $ERRTYP ON ERROR
2420 ;; *THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
2421 ;; *SW15=1 HALT ON ERROR
2422 ;; *SW13=1 INHIBIT ERROR TYPEOUTS
2423 ;; *SW09=1 LOOP ON ERROR
2424 ;; *CALL
2425 ;; * ERROR N ;; ERROR=EMT AND N=ERROR ITEM NUMBER
2426
2427 014514 $ERROR:
2428 014514 105237 001103 7$: INCB $ERFLG ;; SET THE ERROR FLAG
2429 014520 001775 BEQ 7$ ;; DON'T LET THE FLAG GO TO ZERO
2430 014522 013777 001102 164412 MOV $TSTNM,@DISPLAY ;; DISPLAY TEST NUMBER AND ERROR FLAG
2431 014530 005237 001112 INC $ERTTL ;; INC THE ERROR COUNT
2432 014534 011637 001116 MOV (SP), $ERRPC ;; GET ADDRESS OF ERROR INSTRUCTION
2433 014540 162737 000002 001116 SUB #2, $ERRPC
2434 014546 117737 164344 001114 MOV @ $ERRPC, $ITEMB ;; STRIP AND SAVE THE ERROR ITEM CODE
2435 014554 032777 020000 164356 BIT #BIT13, @SWR ;; SKIP TYPEOUT IF SET
2436 014562 001004 BNE 20$ ;; SKIP TYPEOUTS
2437 014564 004737 014646 JSR PC, $ERRTYP ;; GO TO USER ERROR ROUTINE
2438 014570 104401 001175 TYPE , $CRLF
2439 014574 20$:
2440 014574 005777 164340 2$: TST @SWR ;; HALT ON ERROR
2441 014600 100001 BPL 3$ ;; SKIP IF CONTINUE
2442 014602 000000 HALT ;; HALT ON ERROR!
2443 014604 032777 001000 164326 3$: BIT #BIT09, @SWR ;; LOOP ON ERROR SWITCH SET?
2444 014612 001402 BEQ 4$ ;; BR IF NO
2445 014614 013716 001110 MOV $LPERR, (SP) ;; FUDGE RETURN FOR LOOPING
2446 014620 005737 001172 4$: TST $ESCAPE ;; CHECK FOR AN ESCAPE ADDRESS
2447 014624 001402 BEQ 5$ ;; BR IF NONE
2448 014626 013716 001172 MOV $ESCAPE, (SP) ;; FUDGE RETURN ADDRESS FOR ESCAPE
2449 014632 5$:
2450 014632 022737 004300 000042 CMP # $SENDAD, @ #42 ;; ACT-11 AUTO-ACCEPT?
2451 014640 001001 BNE 6$ ;; BRANCH IF NO
2452 014642 000000 HALT ;; YES
2453 014644 6$:
2454 014644 000002 RTI ;; RETURN
```

2455  
2456  
2457  
2458  
2459  
2460  
2461  
2462 014646  
2463 014646 104401 001175  
2464 014652 010046  
2465 014654 005000  
2466 014656 153700 001114  
2467 014662 001004  
2468  
2469 014664 013746 001116  
2470  
2471 014670 104402  
2472 014672 000426  
2473 014674 005300  
2474 014676 006300  
2475 014700 006300  
2476 014702 006300  
2477 014704 062700 002112  
2478 014710 012037 014720  
2479 014714 001404  
2480 014716 104401  
2481 014720 000000  
2482 014722 104401 001175  
2483 014726 012037 014736  
2484 014732 001404  
2485 014734 104401  
2486 014736 000000  
2487 014740 104401 001175  
2488 014744 011000  
2489 014746 001004  
2490 014750 012600  
2491 014752 104401 001175  
2492 014756 000207  
2493 014760  
2494 014760 013046  
2495 014762 104402  
2496 014764 005710  
2497 014766 001770  
2498 014770 104401 014776  
2499 014774 000771  
2500 014776 020040 000  
2501 015002

.SBTTL ERROR MESSAGE TYPEOUT ROUTINE

;;\*\*\*\*\*  
;\*THIS ROUTINE USES THE "ITEM CONTROL BYTE" (\$ITEMB) TO DETERMINE WHICH  
;\*ERROR IS TO BE REPORTED. IT THEN OBTAINS, FROM THE "ERROR TABLE" (\$ERRTB),  
;\*AND REPORTS THE APPROPRIATE INFORMATION CONCERNING THE ERROR.

\$ERRTYP:  
TYPE , \$CRLF ;;"CARRIAGE RETURN" & "LINE FEED"  
MOV RO, -(SP) ;;SAVE RO  
CLR RO ;;PICKUP THE ITEM INDEX  
BISB @#\$ITEMB, RO  
BNE 1\$ ;; IF ITEM NUMBER IS ZERO, JUST  
; ;TYPE THE PC OF THE ERROR  
MOV \$ERRPC, -(SP) ;;SAVE \$ERRPC FOR TYPEOUT  
; ;ERROR ADDRESS  
TYPOC ;;GO TYPE--OCTAL ASCII(ALL DIGITS)  
BR 6\$ ;;GET OUT  
1\$: DEC RO ;;ADJUST THE INDEX SO THAT IT WILL  
ASL RO ;; WORK FOR THE ERROR TABLE  
ASL RO  
ASL RO  
ADD #\$ERRTB, RO ;;FORM TABLE POINTER  
MOV (RO)+, 2\$ ;;PICKUP "ERROR MESSAGE" POINTER  
BEQ 3\$ ;;SKIP TYPEOUT IF NO POINTER  
TYPE ;;TYPE THE "ERROR MESSAGE"  
2\$: .WORD 0 ;;"ERROR MESSAGE" POINTER GOES HERE  
TYPE , \$CRLF ;;"CARRIAGE RETURN" & "LINE FEED"  
3\$: MOV (RO)+, 4\$ ;;PICKUP "DATA HEADER" POINTER  
BEQ 5\$ ;;SKIP TYPEOUT IF 0  
TYPE ;;TYPE THE "DATA HEADER"  
4\$: .WORD 0 ;;"DATA HEADER" POINTER GOES HERE  
TYPE , \$CRLF ;;"CARRIAGE RETURN" & "LINE FEED"  
5\$: MOV (RO), RO ;;PICKUP "DATA TABLE" POINTER  
BNE 7\$ ;;GO TYPE THE DATA  
6\$: MOV (SP)+, RO ;;RESTORE RO  
TYPE , \$CRLF ;;"CARRIAGE RETURN" & "LINE FEED"  
7\$: RTS PC ;;RETURN  
MOV @ (RO)+, -(SP) ;;SAVE @ (RO)+ FOR TYPEOUT  
TYPOC ;;GO TYPE--OCTAL ASCII(ALL DIGITS)  
TST (RO) ;;IS THERE ANOTHER NUMBER?  
BEQ 6\$ ;;BR IF NO  
TYPE , 8\$ ;;TYPE TWO(2) SPACES  
BR 7\$ ;;LOOP  
8\$: .ASCIZ / / ;;TWO(2) SPACES  
.EVEN

.SBTTL TYPE ROUTINE

;;\*\*\*\*\*  
;\*ROUTINE TO TYPE ASCIZ MESSAGE. MESSAGE MUST TERMINATE WITH A 0 BYTE.  
;\*THE ROUTINE WILL INSERT A NUMBER OF NULL CHARACTERS AFTER A LINE FEED.  
;\*NOTE1: \$NULL CONTAINS THE CHARACTER TO BE USED AS THE FILLER CHARACTER.  
;\*NOTE2: \$FILLS CONTAINS THE NUMBER OF FILLER CHARACTERS REQUIRED.  
;\*NOTE3: \$FILLC CONTAINS THE CHARACTER TO FILL AFTER.  
;\*

2502  
2503  
2504  
2505  
2506  
2507  
2508  
2509  
2510

```

2511 ;*CALL:
2512 ;*1) USING A TRAP INSTRUCTION
2513 ;* TYPE ,MESADR ; MESADR IS FIRST ADDRESS OF AN ASCIZ STRING
2514 ;*OR
2515 ;* TYPE
2516 ;* MESADR
2517 ;*
2518
2519 015002 105737 001157 $TYPE: TSTB $TFPLG ; IS THERE A TERMINAL?
2520 015006 100002 BPL 1$ ; BR IF YES
2521 015010 000000 HALT ; HALT HERE IF NO TERMINAL
2522 015012 000407 BR 3$ ; LEAVE
2523 015014 010046 1$: MOV RO, -(SP) ; SAVE RO
2524 015016 017600 000002 MOV @2(SP), RO ; GET ADDRESS OF ASCIZ STRING
2525 015022 112046 2$: MOV B (RO)+, -(SP) ; PUSH CHARACTER TO BE TYPED ONTO STACK
2526 015024 001005 BNE 4$ ; BR IF IT ISN'T THE TERMINATOR
2527 015026 005726 TST (SP)+ ; IF TERMINATOR POP IT OFF THE STACK
2528 015030 012600 60$: MOV (SP)+, RO ; RESTORE RO
2529 015032 062716 000002 3$: ADD #2, (SP) ; ADJUST RETURN PC
2530 015036 000002 RTI ; RETURN
2531 015040 122716 000011 4$: CMPB #HT, (SP) ; BRANCH IF <HT>
2532 015044 001430 BEQ 8$
2533 015046 122716 000200 CMPB #CRLF, (SP) ; BRANCH IF NOT <CRLF>
2534 015052 001006 BNE 5$
2535 015054 005726 TST (SP)+ ; POP <CR><LF> EQUIV
2536 015056 104401 TYPE ; TYPE A CR AND LF
2537 015060 001175 $CRLF
2538 015062 105037 015216 CLR B $CHARCNT ; CLEAR CHARACTER COUNT
2539 015066 000755 BR 2$ ; GET NEXT CHARACTER
2540 015070 004737 015152 5$: JSR PC, $TYPE C ; GO TYPE THIS CHARACTER
2541 015074 123726 001156 6$: CMPB $FILLC, (SP)+ ; IS IT TIME FOR FILLER CHARS. ?
2542 015100 001350 BNE 2$ ; IF NO GO GET NEXT CHAR.
2543 015102 013746 001154 MOV $NULL, -(SP) ; GET # OF FILLER CHARS. NEEDED
2544 ; AND THE NULL CHAR.
2545 015106 105366 000001 7$: DECB 1(SP) ; DOES A NULL NEED TO BE TYPED?
2546 015112 002770 BLT 6$ ; BR IF NO--GO POP THE NULL OFF OF STACK
2547 015114 004737 015152 JSR PC, $TYPE C ; GO TYPE A NULL
2548 015120 105337 015216 DECB $CHARCNT ; DO NOT COUNT AS A COUNT
2549 015124 000770 BR 7$ ; LOOP
2550
2551 ; HORIZONTAL TAB PROCESSOR
2552
2553 015126 112716 000040 8$: MOV B #' , (SP) ; REPLACE TAB WITH SPACE
2554 015132 004737 015152 9$: JSR PC, $TYPE C ; TYPE A SPACE
2555 015136 132737 000007 015216 BIT B #7, $CHARCNT ; BRANCH IF NOT AT
2556 015144 001372 BNE 9$ ; TAB STOP
2557 015146 005726 TST (SP)+ ; POP SPACE OFF STACK
2558 015150 000724 BR 2$ ; GET NEXT CHARACTER
2559 015152 105777 163772 $TYPE C: TSTB @ $TPS ; WAIT UNTIL PRINTER IS READY
2560 015156 100375 BPL $TYPE C
2561 015160 116677 000002 163764 MOV B 2(SP), @ $TPB ; LOAD CHAR TO BE TYPED INTO DATA REG.
2562 015166 122766 000015 000002 CMPB #CR, 2(SP) ; IS CHARACTER A CARRIAGE RETURN?
2563 015174 001003 BNE 1$ ; BRANCH IF NO
2564 015176 105037 015216 CLR B $CHARCNT ; YES--CLEAR CHARACTER COUNT
2565 015202 000406 BR $TYPE X ; EXIT
2566 015204 122766 000012 000002 1$: CMPB #LF, 2(SP) ; IS CHARACTER A LINE FEED?
  
```

```

2567 015212 001402          BEQ     STYPEX      ;; BRANCH IF YES
2568 015214 105227          INCB    (PC)+      ;; COUNT THE CHARACTER
2569 015216 000000          $CHARCNT: .WORD 0  ;; CHARACTER COUNT STORAGE
2570 015220 000207          $TYPEX: RTS     PC
2571
2572          .SBTTL  CONVERT BINARY TO DECIMAL AND TYPE ROUTINE
2573
2574          ;; *****
2575          ;; *THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 5-DIGIT
2576          ;; *SIGNED DECIMAL (ASCII) NUMBER AND TYPE IT. DEPENDING ON WHETHER THE
2577          ;; *NUMBER IS POSITIVE OR NEGATIVE A SPACE OR A MINUS SIGN WILL BE TYPED
2578          ;; *BEFORE THE FIRST DIGIT OF THE NUMBER. LEADING ZEROS WILL ALWAYS BE
2579          ;; *REPLACED WITH SPACES.
2580          ;; *CALL:
2581          ;; *     MOV     NUM, -(SP)      ;; PUT THE BINARY NUMBER ON THE STACK
2582          ;; *     TYPDS      ;; GO TO THE ROUTINE
2583
2584          $TYPDS:
2585          015222 010046      MOV     R0, -(SP)      ;; PUSH R0 ON STACK
2586          015224 010146      MOV     R1, -(SP)      ;; PUSH R1 ON STACK
2587          015226 010246      MOV     R2, -(SP)      ;; PUSH R2 ON STACK
2588          015230 010346      MOV     R3, -(SP)      ;; PUSH R3 ON STACK
2589          015232 010546      MOV     R5, -(SP)      ;; PUSH R5 ON STACK
2590          015234 012746 020200  MOV     #20200, -(SP)  ;; SET BLANK SWITCH AND SIGN
2591          015240 016605 000020  MOV     20(SP), R5     ;; GET THE INPUT NUMBER
2592          015244 100004      BPL     1$             ;; BR IF INPUT IS POS.
2593          015246 005405      NEG     R5             ;; MAKE THE BINARY NUMBER POS.
2594          015250 112766 000055 000001  MOVB    #'-, 1(SP)     ;; MAKE THE ASCII NUMBER NEG.
2595          015256 005000      1$:    CLR     R0             ;; ZERO THE CONSTANTS INDEX
2596          015260 012703 015436      MOV     #5DBLK, R3     ;; SETUP THE OUTPUT POINTER
2597          015264 112723 000040      MOVB    #' , (R3)+     ;; SET THE FIRST CHARACTER TO A BLANK
2598          015270 005002      2$:    CLR     R2             ;; CLEAR THE BCD NUMBER
2599          015272 016001 015426      MOV     $DTBL(R0), R1  ;; GET THE CONSTANT
2600          015276 160105      3$:    SUB     R1, R5     ;; FORM THIS BCD DIGIT
2601          015300 002402      BLT     4$             ;; BR IF DONE
2602          015302 005202      INC     R2             ;; INCREASE THE BCD DIGIT BY 1
2603          015304 000774      BR      3$
2604          015306 060105      4$:    ADD     R1, R5     ;; ADD BACK THE CONSTANT
2605          015310 005702      TST     R2             ;; CHECK IF BCD DIGIT=0
2606          015312 001002      BNE     5$             ;; FALL THROUGH IF 0
2607          015314 105716      TSTB   (SP)           ;; STILL DOING LEADING 0'S?
2608          015316 100407      BMI     7$             ;; BR IF YES
2609          015320 106316      5$:    ASLB   (SP)           ;; MSD?
2610          015322 103003      BCC     6$             ;; BR IF NO
2611          015324 116663 000001 177777  MOVB    1(SP), -1(R3)  ;; YES--SET THE SIGN
2612          015332 052702 000060      6$:    BIS     #'0, R2     ;; MAKE THE BCD DIGIT ASCII
2613          015336 052702 000040      7$:    BIS     #' , R2     ;; MAKE IT A SPACE IF NOT ALREADY A DIGIT
2614          015342 110223      MOVB    R2, (R3)+     ;; PUT THIS CHARACTER IN THE OUTPUT BUFFER
2615          015344 005720      TST     (R0)+         ;; JUST INCREMENTING
2616          015346 020027 000010      CMP     R0, #10       ;; CHECK THE TABLE INDEX
2617          015352 002746      BLT     2$             ;; GO DO THE NEXT DIGIT
2618          015354 003002      BGT     8$             ;; GO TO EXIT
2619          015356 010502      MOV     R5, R2         ;; GET THE LSD
2620          015360 000764      BR      6$             ;; GO CHANGE TO ASCII
2621          015362 105726      8$:    TSTB   (SP)+     ;; WAS THE LSD THE FIRST NON-ZERO?
2622          015364 100003      BPL     9$             ;; BR IF NO

```

MAIN. MACY11 30(1046) 25-OCT-77 10:10 PAGE 66  
 DVPCAR. P11 25-OCT-77 10:02

CONVERT BINARY TO DECIMAL AND TYPE ROUTINE

SEQ 0068

```

2623 015366 116663 177777 177776      MOVB   -1(SP),-2(R3)  ;;YES--SET THE SIGN FOR TYPING
2624 015374 105013      95:   CLRB   (R3)      ;;SET THE TERMINATOR
2625 015376 012605      MOV    (SP)+,R5      ;;POP STACK INTO R5
2626 015400 012603      MOV    (SP)+,R3      ;;POP STACK INTO R3
2627 015402 012602      MOV    (SP)+,R2      ;;POP STACK INTO R2
2628 015404 012601      MOV    (SP)+,R1      ;;POP STACK INTO R1
2629 015406 012600      MOV    (SP)+,R0      ;;POP STACK INTO R0
2630 015410 104401 015436      TYPE   ,SDBLK        ;;NOW TYPE THE NUMBER
2631 015414 016666 000002 000004      MOV    2(SP),4(SP)   ;;ADJUST THE STACK
2632 015422 012616      MOV    (SP)+,(SP)    ;;
2633 015424 000002      RTI                                ;;RETURN TO USER
2634 015426 023420      SDBLK: 10000.
2635 015430 001750      1000.
2636 015432 000144      100.
2637 015434 000012      10.
2638 015436 000004      SDBLK: .5LKW 4
2639                                .SBTTL BINARY TO OCTAL (ASCII) AND TYPE
2640
2641                                ;;*****
2642                                ;;*THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 6-DIGIT
2643                                ;;*OCTAL (ASCII) NUMBER AND TYPE IT.
2644                                ;;*$TYPOS---ENTER HERE TO SETUP SUPPRESS ZEROS AND NUMBER OF DIGITS TO TYPE
2645                                ;;*CALL:
2646                                ;;*   MOV    NUM,-(SP)      ;;NUMBER TO BE TYPED
2647                                ;;*   TYPOS      ;;CALL FOR TYPEOUT
2648                                ;;*   .BYTE  N      ;;N=1 TO 6 FOR NUMBER OF DIGITS TO TYPE
2649                                ;;*   .BYTE  M      ;;M=1 OR 0
2650                                ;;*                               ;;1=TYPE LEADING ZEROS
2651                                ;;*                               ;;0=SUPPRESS LEADING ZEROS
2652                                ;;*
2653                                ;;*$STYPON---ENTER HERE TO TYPE OUT WITH THE SAME PARAMETERS AS THE LAST
2654                                ;;*$TYPOS OR $TYPOC
2655                                ;;*CALL:
2656                                ;;*   MOV    NUM,-(SP)      ;;NUMBER TO BE TYPED
2657                                ;;*   TYPON      ;;CALL FOR TYPEOUT
2658                                ;;*
2659                                ;;*$STYPOC---ENTER HERE FOR TYPEOUT OF A 16 BIT NUMBER
2660                                ;;*CALL:
2661                                ;;*   MOV    NUM,-(SP)      ;;NUMBER TO BE TYPED
2662                                ;;*   TYPOC      ;;CALL FOR TYPEOUT
2663
2664 015446 017646 000000      $TYPOS: MOV    @2(SP),-(SP)  ;;PICKUP THE MODE
2665 015452 116637 000001 015671      MOVB   1(SP),%OFILL  ;;LOAD ZERO FILL SWITCH
2666 015460 112637 015673      MOVB   (SP)+,%OMODE+1 ;;NUMBER OF DIGITS TO TYPE
2667 015464 062716 000002      ADD    #2,(SP)      ;;ADJUST RETURN ADDRESS
2668 015470 000406      BR     $TYPON
2669 015472 112737 000001 015671      $TYPOC: MOVB   #1,%OFILL  ;;SET THE ZERO FILL SWITCH
2670 015500 112737 000006 015673      MOVB   #6,%OMODE+1  ;;SET FOR SIX(6) DIGITS
2671 015506 112737 000005 015670      $TYPON: MOVB   #5,%OCNT   ;;SET THE ITERATION COUNT
2672 015514 010346      MOV    R3,-(SP)     ;;SAVE R3
2673 015516 010446      MOV    R4,-(SP)     ;;SAVE R4
2674 015520 010546      MOV    R5,-(SP)     ;;SAVE R5
2675 015522 113704 015673      MOVB   %OMODE+1,R4  ;;GET THE NUMBER OF DIGITS TO TYPE
2676 015526 005404      NEG    R4
2677 015530 062704 000006      ADD    #6,R4        ;;SUBTRACT IT FOR MAX. ALLOWED
2678 015534 110437 015672      MOVB   R4,%OMODE    ;;SAVE IT FOR USE

```

```

2679 015540 113704 015671          MOVB  $OFILL,R4      ;; GET THE ZERO FILL SWITCH
2680 015544 016605 000012          MOV   12(SP),R5     ;; PICKUP THE INPUT NUMBER
2681 015550 005003                   CLR   R3            ;; CLEAR THE OUTPUT WORD
2682 015552 006105          1$:  ROL   R5            ;; ROTATE MSB INTO "C"
2683 015554 000404                   BR    3$           ;; GO DO MSB
2684 015556 006105          2$:  ROL   R5            ;; FORM THIS DIGIT
2685 015560 006105                   ROL   R5
2686 015562 006105                   ROL   R5
2687 015564 010503                   MOV   R5,R3
2688 015566 006103          3$:  ROL   R3            ;; GET LSB OF THIS DIGIT
2689 015570 105337 015672          DECB  $OMODE       ;; TYPE THIS DIGIT?
2690 015574 100016                   BPL  7$           ;; BR IF NO
2691 015576 042703 177770          BIC   #177770,R3  ;; GET RID OF JUNK
2692 015602 001002                   BNE  4$           ;; TEST FOR 0
2693 015604 005704                   TST  R4           ;; SUPPRESS THIS 0?
2694 015606 001403                   BEQ  5$           ;; BR IF YES
2695 015610 005204          4$:  INC   R4           ;; DON'T SUPPRESS ANYMORE 0'S
2696 015612 052703 000060          BIS   #'0,R3     ;; MAKE THIS DIGIT ASCII
2697 015616 052703 000040          5$:  BIS   #' ,R3   ;; MAKE ASCII IF NOT ALREADY
2698 015622 110337 015666          MOVB  R3,8$      ;; SAVE FOR TYPING
2699 015626 104401 015666          TYPE ,8$        ;; GO TYPE THIS DIGIT
2700 015632 105337 015670          7$:  DECB  $OCNT    ;; COUNT BY 1
2701 015636 003347                   BGT  2$           ;; BR IF MORE TO DO
2702 015640 002402                   BLT  6$           ;; BR IF DONE
2703 015642 005204                   INC  R4           ;; INSURE LAST DIGIT ISN'T A BLANK
2704 015644 000744                   BR   2$          ;; GO DO THE LAST DIGIT
2705 015646 012605          6$:  MOV   (SP)+,R5  ;; RESTORE R5
2706 015650 012604                   MOV   (SP)+,R4    ;; RESTORE R4
2707 015652 012603                   MOV   (SP)+,R3    ;; RESTORE R3
2708 015654 016666 000002 000004  MOV   2(SP),4(SP) ;; SET THE STACK FOR RETURNING
2709 015662 012616                   MOV   (SP)+,(SP)
2710 015664 000002                   RTI                    ;; RETURN
2711 015666 000          8$:  .BYTE  0          ;; STORAGE FOR ASCII DIGIT
2712 015667 000          .BYTE  0          ;; TERMINATOR FOR TYPE ROUTINE
2713 015670 000          $OCNT: .BYTE  0    ;; OCTAL DIGIT COUNTER
2714 015671 000          $OFILL: .BYTE  0   ;; ZERO FILL SWITCH
2715 015672 000000          $OMODE: .WORD  0    ;; NUMBER OF DIGITS TO TYPE
2716          .SBTTL  SAVE AND RESTORE R0-R5 ROUTINES
2717
2718          ;; *****
2719          ;*SAVE R0-R5
2720          ;*CALL:
2721          ;*   SAVREG
2722          ;*UPON RETURN FROM $SAVREG THE STACK WILL LOOK LIKE:
2723          ;*
2724          ;*TOP---(+16)
2725          ;* +2---(+18)
2726          ;* +4---R5
2727          ;* +6---R4
2728          ;* +8---R3
2729          ;*+10---R2
2730          ;*+12---R1
2731          ;*+14---R0
2732
2733 015674          $SAVREG:
2734 015674 010046          MOV   R0,-(SP)    ;; PUSH R0 ON STACK

```

```

2735 015676 010146          MOV      R1, -(SP)          ;; PUSH R1 ON STACK
2736 015700 010246          MOV      R2, -(SP)          ;; PUSH R2 ON STACK
2737 015702 010346          MOV      R3, -(SP)          ;; PUSH R3 ON STACK
2738 015704 010446          MOV      R4, -(SP)          ;; PUSH R4 ON STACK
2739 015706 010546          MOV      R5, -(SP)          ;; PUSH R5 ON STACK
2740 015710 016646 000022    MOV      22(SP), -(SP)      ;; SAVE PS OF MAIN FLOW
2741 015714 016646 000022    MOV      22(SP), -(SP)      ;; SAVE PC OF MAIN FLOW
2742 015720 016646 000022    MOV      22(SP), -(SP)      ;; SAVE PS OF CALL
2743 015724 016646 000022    MOV      22(SP), -(SP)      ;; SAVE PC OF CALL
2744 015730 000002          RTI
2745
2746                          ;*RESTORE RO-R5
2747                          ;*CALL:
2748                          ;* RESREG
2749                          $RESREG:
2750 015732 012666 000022    MOV      (SP)+, 22(SP)      ;; RESTORE PC OF CALL
2751 015736 012666 000022    MOV      (SP)+, 22(SP)      ;; RESTORE PS OF CALL
2752 015742 012666 000022    MOV      (SP)+, 22(SP)      ;; RESTORE PC OF MAIN FLOW
2753 015746 012666 000022    MOV      (SP)+, 22(SP)      ;; RESTORE PS OF MAIN FLOW
2754 015752 012605          MOV      (SP)+, R5          ;; POP STACK INTO R5
2755 015754 012604          MOV      (SP)+, R4          ;; POP STACK INTO R4
2756 015756 012603          MOV      (SP)+, R3          ;; POP STACK INTO R3
2757 015760 012602          MOV      (SP)+, R2          ;; POP STACK INTO R2
2758 015762 012601          MOV      (SP)+, R1          ;; POP STACK INTO R1
2759 015764 012600          MOV      (SP)+, R0          ;; POP STACK INTO R0
2760 015766 000002          RTI
2761                          .SBTTL TRAP DECODER
2762
2763                          ;*****
2764                          ;*THIS ROUTINE WILL PICKUP THE LOWER BYTE OF THE "TRAP" INSTRUCTION
2765                          ;*AND USE IT TO INDEX THROUGH THE TRAP TABLE FOR THE STARTING ADDRESS
2766                          ;*OF THE DESIRED ROUTINE. THEN USING THE ADDRESS OBTAINED IT WILL
2767                          ;*GO TO THAT ROUTINE.
2768
2769 015770 010046          $TRAP: MOV      R0, -(SP)          ;; SAVE R0
2770 015772 016600 000002    MOV      2(SP), R0          ;; GET TRAP ADDRESS
2771 015776 005740          TST      -(R0)              ;; BACKUP BY 2
2772 016000 111000          MOV      (R0), R0          ;; GET RIGHT BYTE OF TRAP
2773 016002 006300          ASL      R0                  ;; POSITION FOR INDEXING
2774 016004 016000 016024    MOV      $TRPAD(R0), R0     ;; INDEX TO TABLE
2775 016010 000200          RTS      R0                  ;; GO TO ROUTINE
2776
2777
2778                          ;; THIS IS USE TO HANDLE THE "GETPRI" MACRO
2779
2780 016012 011646          $TRAP2: MOV      (SP), -(SP)  ;; MOVE THE PC DOWN
2781 016014 016666 000004 000002  MOV      4(SP), 2(SP)      ;; MOVE THE PSW DOWN
2782 016022 000002          RTI                          ;; RESTORE THE PSW
2783
2784                          .SBTTL TRAP TABLE
2785
2786                          ;*THIS TABLE CONTAINS THE STARTING ADDRESSES OF THE ROUTINES CALLED
2787                          ;*BY THE "TRAP" INSTRUCTION.
2788
2789                          ; ROUTINE
2790                          ; -----

```

```

2791 016024 016012 STRPAD: . WORD $TRAP2
2792 016026 015002 $TYPE ;;CALL=TYPE TRAP+1(104401) TTY TYPEOUT ROUTINE
2793 016030 015472 $TYPOC ;;CALL=TYPOC TRAP+2(104402) TYPE OCTAL NUMBER (WITH LEADING ZEROS)
2794 016032 015446 $TYPOS ;;CALL=TYPOS TRAP+3(104403) TYPE OCTAL NUMBER (NO LEADING ZEROS)
2795 016034 015506 $TYPON ;;CALL=TYPON TRAP+4(104404) TYPE OCTAL NUMBER (AS PER LAST CALL)
2796 016036 015222 $TYPDS ;;CALL=TYPDS TRAP+5(104405) TYPE DECIMAL NUMBER (WITH SIGN)
2797
2798
2799 016040 014062 $RDCHR ;;CALL=RDCHR TRAP+6(104406) TTY TYPEIN CHARACTER ROUTINE
2800 016042 014202 $RDLIN ;;CALL=RDLIN TRAP+7(104407) TTY TYPEIN STRING ROUTINE
2801 016044 014354 $RDOCT ;;CALL=RDOCT TRAP+10(104410) READ AN OCTAL NUMBER FROM TTY
2802 016046 015674 $SAVREG ;;CALL=SAVREG TRAP+11(104411) SAVE R0-R5 ROUTINE
2803 016050 015732 $RESREG ;;CALL=RESREG TRAP+12(104412) RESTORE R0-R5 ROUTINE
2804 . SBTTL POWER DOWN AND UP ROUTINES
2805
2806 ;;*****
2807 ;POWER DOWN ROUTINE
2808 016052 012737 016212 000024 $PWRDN: MOV $SILLUP, @#PWRVEC ;;SET FOR FAST UP
2809 016060 012737 000340 000026 MOV #340, @#PWRVEC+2 ;;PRIO: 7
2810 016066 010046 MOV R0, -(SP) ;;PUSH R0 ON STACK
2811 016070 010146 MOV R1, -(SP) ;;PUSH R1 ON STACK
2812 016072 010246 MOV R2, -(SP) ;;PUSH R2 ON STACK
2813 016074 010346 MOV R3, -(SP) ;;PUSH R3 ON STACK
2814 016076 010446 MOV R4, -(SP) ;;PUSH R4 ON STACK
2815 016100 010546 MOV R5, -(SP) ;;PUSH R5 ON STACK
2816 016102 017746 163032 MOV @SWR, -(SP) ;;PUSH @SWR ON STACK
2817 016106 010637 016216 MOV SP, $SAVR6 ;;SAVE SP
2818 016112 012737 016124 000024 MOV $PWRUP, @#PWRVEC ;;SET UP VECTOR
2819 016120 000000 HALT
2820 016122 000776 BR -2 ;;HANG UP
2821
2822 ;;*****
2823 ;POWER UP ROUTINE
2824 016124 012737 016212 000024 $PWRUP: MOV $SILLUP, @#PWRVEC ;;SET FOR FAST DOWN
2825 016132 013706 016216 MOV $SAVR6, SP ;;GET SP
2826 016136 005037 016216 CLR $SAVR6 ;;WAIT LOOP FOR THE TTY
2827 016142 005237 016216 15: INC $SAVR6 ;;WAIT FOR THE INC
2828 016146 001375 BNE 15 ;;OF WORD
2829 016150 012677 162764 MOV (SP)+, @SWR ;;POP STACK INTO @SWR
2830 016154 012605 MOV (SP)+, R5 ;;POP STACK INTO R5
2831 016156 012604 MOV (SP)+, R4 ;;POP STACK INTO R4
2832 016160 012603 MOV (SP)+, R3 ;;POP STACK INTO R3
2833 016162 012602 MOV (SP)+, R2 ;;POP STACK INTO R2
2834 016164 012601 MOV (SP)+, R1 ;;POP STACK INTO R1
2835 016166 012600 MOV (SP)+, R0 ;;POP STACK INTO R0
2836 016170 012737 016052 000024 MOV $PWRDN, @#PWRVEC ;;SET UP THE POWER DOWN VECTOR
2837 016176 012737 000340 000026 MOV #340, @#PWRVEC+2 ;;PRIO: 7
2838 016204 104401 TYPE ;;REPORT THE POWER FAILURE
2839 016206 016220 $PWRMG: . WORD $POWER ;;POWER FAIL MESSAGE POINTER
2840 016210 000002 RTI
2841 016212 000000 $SILLUP: HALT ;;THE POWER UP SEQUENCE WAS STARTED
2842 016214 000776 BR -2 ;;BEFORE THE POWER DOWN WAS COMPLETE
2843 016216 000000 $SAVR6: 0 ;;PUT THE SP HERE
2844 016220 005015 047520 042527 $POWER: . ASCII <15><12>"POWER"
2845 016226 000122 . EVEN
2846

```



MAIN. MACY11 30(1046) 25-OCT-77 10:10 PAGE 70  
 DVPCAR. P11 25-OCT-77 10:02 POWER DOWN AND UP ROUTINES

SEQ 0072

2847	016230	041103	052111	047040	EM1:	. ASCIZ /CBIT NOT CLEARING IOCM/
2848	016236	052117	041440	042514		
2849	016244	051101	047111	020107		
2850	016252	047511	046503	000		
2851	016257	111	041517	020115	EM2:	. ASCII /IOCM TEST/<15><12>
2852	016264	042524	052123	005015		
2853	016272	051503	020122	040504	EM2Y:	. ASCII /CSR DATA ERROR WHEN TESTING /
2854	016300	040524	042440	051122		
2855	016306	051117	053440	042510		
2856	016314	020116	042524	052123		
2857	016322	047111	020107			
2858	016326	020040	044502	020124	EM2X:	. ASCIZ / BIT /<15><12>
2859	016334	006440	000012			
2860	016340	041520	052011	052123	DH1:	. ASCIZ /PC TST# GDDAT BDDAT PASS./
2861	016346	004443	042107	040504		
2862	016354	004524	042102	040504		
2863	016362	004524	040520	051523		
2864	016370	000				
2865	016371	111	041517	020115	EM3:	. ASCIZ /IOCM IS NOT RESPONDING/<15><12>
2866	016376	051511	047040	052117		
2867	016404	051040	051505	047520		
2868	016412	042116	047111	006507		
2869	016420	000012				
2870	016422	041104	051525	041040	EM4:	. ASCIZ /DBUS BIT IS FAILING/<15><12>
2871	016430	052111	044440	020123		
2872	016436	040506	046111	047111		
2873	016444	006507	000012			
2874	016450	047516	044440	052116	EM5:	. ASCIZ /NO INTERRUPT /<15><12>
2875	016456	051105	052522	052120		
2876	016464	006440	000012			
2877	016470	041520	052011	052123	DH5:	. ASCIZ /PC TST# MODULE ADDR PASS/
2878	016476	004443	047515	052504		
2879	016504	042514	020040	040440		
2880	016512	042104	004522	040520		
2881	016520	051523	000			
2882	016523	127	047522	043516	EM6:	. ASCIZ /WRONG PATTERN IN IAR AFTER INTERRUPT/<15><12>
2883	016530	050040	052101	042524		
2884	016536	047122	044440	020116		
2885	016544	040511	020122	043101		
2886	016552	042524	020122	047111		
2887	016560	042524	051122	050125		
2888	016566	006524	000012			
2889	016572				EM17:	
2890	016572	040504	040524	042440	EM7:	. ASCIZ /DATA ERROR/<15><12>
2891	016600	051122	051117	005015		
2892	016606	000				
2893	016607	120	004503	047515	DH7:	. ASCIZ /PC MODULE ADDRESS TST# GDDAT BDDAT PASS/
2894	016614	052504	042514	040411		
2895	016622	042104	042522	051523		
2896	016630	052011	052123	004443		
2897	016636	042107	040504	004524		
2898	016644	042102	040504	004524		
2899	016652	040520	051523	000		
2900	016657	124	051505	020124	EM10:	. ASCIZ /TEST ABORTED, IOCM ERROR/<15><12>
2901	016664	041101	051117	042524		
2902	016672	026104	044440	041517		

2903	016700	020115	051105	047522	
2904	016706	006522	000012		
2905	016712	040504	040524	047040	EM11: .ASCIZ /DATA NOT CLEAR AFTER 10 SEC/<15><12>
2906	016720	052117	041440	042514	
2907	016726	051101	040440	052106	
2908	016734	051105	030440	020060	
2909	016742	042523	006503	000012	
2910	016750	047111	042524	051122	EM12: .ASCIZ /INTERRUPT TOO LATE /<15><12>
2911	016756	050125	020124	047524	
2912	016764	020117	040514	042524	
2913	016772	020040	006440	000012	
2914	017000	044522	020106	044502	EM13: .ASCIZ /RIF BIT NOT CLEARING COS REGISTERS /<15><12>
2915	017006	020124	047516	020124	
2916	017014	046103	040505	044522	
2917	017022	043516	041440	051517	
2918	017030	051040	043505	051511	
2919	017036	042524	051522	006440	
2920	017044	000012			
2921	017046	047516	044440	052116	EM14: .ASCIZ /NO INTERRUPT IN MAINTENANCE MODE/<15><12>
2922	017054	051105	052522	052120	
2923	017062	044440	020116	040515	
2924	017070	047111	042524	040516	
2925	017076	041516	020105	047515	
2926	017104	042504	005015	000	
2927	017111	122	043111	041040	EM15: .ASCIZ /RIF BIT ISN'T CLEARING INTERRUPT/<15><12>
2928	017116	052111	044440	047123	
2929	017124	052042	041440	042514	
2930	017132	051101	047111	020107	
2931	017140	047111	042524	051122	
2932	017146	050125	006524	000012	
2933	017154	046103	040505	044522	EM16: .ASCIZ /CLEARING DBIT ISN'T CLEARING CSR/<15><12>
2934	017162	043516	042040	044502	
2935	017170	020124	051511	021116	
2936	017176	020124	046103	040505	
2937	017204	044522	043516	041440	
2938	017212	051123	005015	000	
2939	017217	103	051517	051040	EM20: .ASCIZ /COS REGISTER DATA ERROR/<15><12>
2940	017224	043505	051511	042524	
2941	017232	020122	040504	040524	
2942	017240	042440	051122	051117	
2943	017246	005015	000		
2944	017251	114	047517	020120	EM21: .ASCIZ /LOOP ERROR ON 6010-5010 OR 5011/<15><12>
2945	017256	051105	047522	020122	
2946	017264	047117	033040	030460	
2947	017272	026460	030065	030061	
2948	017300	047440	020122	030065	
2949	017306	030461	005015	000	
2950	017313	120	004503	042107	DH21: .ASCIZ /PC GDDAT BDDAT PASS/
2951	017320	040504	004524	042102	
2952	017326	040504	004524	040520	
2953	017334	051523	000		
2954	017337	101	042104	042522	EM22: .ASCIZ /ADDRESS TEST WITH MBIT SET ISN'T WORKING /<15><12>
2955	017344	051523	052040	051505	
2956	017352	020124	044527	044124	
2957	017360	046440	044502	020124	
2958	017366	042523	020124	051511	

2959	017374	023516	020124	047527				
2960	017402	045522	047111	020107				
2961	017410	005015	000					
2962	017413	125	040516	046102	EM23:	. ASCIZ	/UNABLE TO CLEAR INTERRUPT /<15><12>	
2963	017420	020105	047524	041440				
2964	017426	042514	051101	044440				
2965	017434	052116	051105	052522				
2966	017442	052120	006440	000012				
2967	017450	041520	052011	052123	DH23:	. ASCIZ	/PC TST# IAR/	
2968	017456	004443	040511	000122				
2969	017464	006516	000012		M1:	. ASCIZ	/N/<15><12>	
2970	017470	006531	000012		M0:	. ASCIZ	/Y/<15><12>	
2971	017474	000122			M2:	. ASCIZ	/R/	
2972	017476	020107	000		M3:	. ASCIZ	/G /	
2973	017501	124	000040		M4:	. ASCIZ	/T /	
2974	017504	020104	000		M5:	. ASCIZ	/D /	
2975	017507	115	000040		M6:	. ASCIZ	/M /	
2976	017512	020105	000		M7:	. ASCIZ	/E /	
2977	017515	040	040520	051523	M11:	. ASCIZ	/ PASSES COMPLETED/<15><12>	
2978	017522	051505	041440	046517				
2979	017530	046120	052105	042105				
2980	017536	005015	000					
2981	017541	115	042117	046125	EM24:	. ASCIZ	/MODULE UNDER TEST IS NOT RESPONDING/<15><12>	
2982	017546	020105	047125	042504				
2983	017554	020122	042524	052123				
2984	017562	044440	020123	047516				
2985	017570	020124	042522	050123				
2986	017576	047117	044504	043516				
2987	017604	005015	000					
2988	017607	015	052012	051505	M13:	. ASCIZ	<15><12>/TEST OPTIONS: /<15><12>	
2989	017614	020124	050117	044524				
2990	017622	047117	035123	005015				
2991	017630	000						
2992	017631	123	020040	054523	M14:	. ASCIZ	/S SYSTEM TEST/<15><12>	
2993	017636	052123	046505	052040				
2994	017644	051505	006524	000012				
2995	017652	020104	042040	043511	M15:	. ASCIZ	/D DIGITAL MODULE/<15><12>	
2996	017660	052111	046101	046440				
2997	017666	042117	046125	006505				
2998	017674	000012						
2999	017676	020101	040440	040516	M16:	. ASCIZ	/A ANALOG MODULE/<15><12>	
3000	017704	047514	020107	047515				
3001	017712	052504	042514	005015				
3002	017720	000						
3003	017721	115	020040	040515	M17:	. ASCIZ	/M MAP OF DBUS INTERFACES/<15><12>	
3004	017726	020120	043117	042040				
3005	017734	052502	020123	047111				
3006	017742	042524	043122	041501				
3007	017750	051505	005015	000				
3008	017755	130	020040	054105	M18:	. ASCIZ	/X EXERCIZER/<15><12>	
3009	017762	051105	044503	042532				
3010	017770	006522	000012					
3011	017774	020111	044440	041517	M19:	. ASCIZ	/I IOCM TEST/<15><12>	
3012	020002	020115	042524	052123				
3013	020010	005015	000					
3014	020013	040	020040	006477	M20:	. ASCIZ	/ ?/<15><12>	

3015	020020	000012				
3016	020022	020124	051440	052105	M21:	. ASCIZ /T SET SWREG/<15><12>
3017	020030	051440	051127	043505		
3018	020036	005015	000			
3019	020041	061	030060	030060	M22:	. ASCII /100000 HALT ON ERROR/<15><12>
3020	020046	020060	020040	040510		
3021	020054	052114	047440	020116		
3022	020062	051105	047522	006522		
3023	020070	012				
3024	020071	064	030060	030060		. ASCII /40000 LOOP ON TEST/<15><12>
3025	020076	020040	020040	047514		
3026	020104	050117	047440	020116		
3027	020112	042524	052123	005015		
3028	020120	030062	030060	020060		. ASCIZ /20000 INHIBIT ERROR & EOP PRINT/<15><12>
3029	020126	020040	044440	044116		
3030	020134	041111	052111	042440		
3031	020142	051122	051117	023040		
3032	020150	042440	050117	050040		
3033	020156	044522	052116	005015		
3034	020164	000				
3035	020165	061	030060	030060		. ASCIZ /10000 LOOP ON ERROR/<15><12>
3036	020172	020040	020040	047514		
3037	020200	050117	047440	020116		
3038	020206	051105	047522	006522		
3039	020214	000012				
3040	020216	005015	053523	042522	M23:	. ASCIZ <15><12>/SWREG =/
3041	020224	020107	000075			
3042	020230	020106	043040	042511	M24:	. ASCIZ /F FIELD TEST/<15><12>
3043	020236	042114	052040	051505		
3044	020244	006524	000012			
3045	020250	020127	046040	047517	M25:	. ASCIZ /W LOOP TEST/<15><12>
3046	020256	020120	042524	052123		
3047	020264	005015	000			
3048	020267	114	020040	047514	M26:	. ASCIZ /L LOAD ITERATION COUNT/<15><12>
3049	020274	042101	044440	042524		
3050	020302	040522	044524	047117		
3051	020310	041440	052517	052116		
3052	020316	005015	000			
3053	020321	116	046525	042502	M27:	. ASCIZ /NUMBER OF ITERATIONS(OCT) = /
3054	020326	020122	043117	044440		
3055	020334	042524	040522	044524		
3056	020342	047117	024123	041517		
3057	020350	024524	036440	000040		
3058	020356	044514	042516	041440	EM25:	. ASCIZ /LINE CLOCK IS NOT INTERRUPTING/<15><12>
3059	020364	047514	045503	044440		
3060	020372	020123	047516	020124		
3061	020400	047111	042524	051122		
3062	020406	050125	044524	043516		
3063	020414	005015	000			
3064	020417	015	000012		MASS0:	. ASCIZ <15><12>
3065	020422	042101	051104	051505	MASS2:	. ASCIZ /ADDRESS /
3066	020430	020123	000040			
3067	020434	020040	046440	030065	MASS3:	. ASCIZ / M5010 NONISOLATED 32 BIT DC INPUT/<15><12>
3068	020442	030061	047040	047117		
3069	020450	051511	046117	052101		
3070	020456	042105	031440	020062		

MAIN. MACY11 30(1046) 25-OCT-77 10:10 PAGE 74  
 DVPCAR. P11 25-OCT-77 10:02 POWER DOWN AND UP ROUTINES

SEQ 0076

3071	020464	044502	020124	041504	
3072	020472	044440	050116	052125	
3073	020500	005015	000		
3074	020503	040	020040	032515	MASS4: .ASCIZ / M5011 NONISOLATED 16 BIT DC INPUT/<15><12>
3075	020510	030460	020061	047516	
3076	020516	044516	047523	040514	
3077	020524	042524	020104	033061	
3078	020532	041040	052111	042040	
3079	020540	020103	047111	052520	
3080	020546	006524	000012		
3081	020552	020040	046440	030065	MASS5: .ASCIZ / M5012 ISOLATED 16 BIT DC INPUT/<15><12>
3082	020560	031061	044440	047523	
3083	020566	040514	042524	020104	
3084	020574	033061	041040	052111	
3085	020602	042040	020103	047111	
3086	020610	052520	006524	000012	
3087	020616	020040	046440	030065	MASS6: .ASCIZ / M5013 8 BIT AC INPUT/<15><12>
3088	020624	031461	034040	041040	
3089	020632	052111	040440	020103	
3090	020640	047111	052520	006524	
3091	020646	000012			
3092	020650	020040	046440	030066	MASS7: .ASCIZ / M6010 NONISOLATED 32 BIT DC OUTPUT/<15><12>
3093	020656	030061	047040	047117	
3094	020664	051511	046117	052101	
3095	020672	042105	031440	020062	
3096	020700	044502	020124	041504	
3097	020706	047440	052125	052520	
3098	020714	006524	000012		
3099	020720	020040	046440	030066	MASS8: .ASCIZ / M6011 16 BIT ONESHOT OUTPUT/<15><12>
3100	020726	030461	030440	020066	
3101	020734	044502	020124	047117	
3102	020742	051505	047510	020124	
3103	020750	052517	050124	052125	
3104	020756	005015	000		
3105	020761	040	020040	033115	MASS9: .ASCIZ / M6012 ISOLATED 8 BIT DC OUTPUT/<15><12>
3106	020766	030460	020062	051511	
3107	020774	046117	052101	042105	
3108	021002	034040	041040	052111	
3109	021010	042040	020103	052517	
3110	021016	050124	052125	005015	
3111	021024	000			
3112	021025	040	020040	033115	MASS10: .ASCIZ / M6013 8 BIT AC OUTPUT/<15><12>
3113	021032	030460	020063	020070	
3114	021040	044502	020124	041501	
3115	021046	047440	052125	052520	
3116	021054	006524	000012		
3117	021060	005015	020040	052440	MASS11: .ASCIZ <15><12>/ UNKNOWN GENERIC CODE /
3118	021066	045516	047516	047127	
3119	021074	043440	047105	051105	
3120	021102	041511	041440	042117	
3121	021110	020105	000040		
3122	021114	005015	044127	041511	MASS12: .ASCIZ <15><12>/WHICH TEST OPTION ? /
3123	021122	020110	042524	052123	
3124	021130	047440	052120	047511	
3125	021136	020116	020077	000040	
3126	021144	054524	042520	040440	MASS13: .ASCIZ /TYPE ADDRESS OF MUT /

MAIN. MACY11 30(1046) 25-OCT-77 10:10 PAGE 75  
 DVPCAR.P11 25-OCT-77 10:02 POWER DOWN AND UP ROUTINES

SEQ 0077

3127	021152	042104	042522	051523	
3128	021160	047440	020106	052515	
3129	021166	020124	020040	000040	
3130	021174	047111	042524	051122	MASS14: .ASCIZ /INTERRUPT TOO LATE/<15><12>
3131	021202	050125	020124	047524	
3132	021210	020117	040514	042524	
3133	021216	005015	000		
3134	021221	105	042116	047440	MASS15: .ASCIZ /END OF MODULE TEST/<15><12>
3135	021226	020106	047515	052504	
3136	021234	042514	052040	051505	
3137	021242	006524	000012		
3138	021246	047105	020104	043117	MASS16: .ASCIZ /END OF IOCM TEST/<15><12>
3139	021254	044440	041517	020115	
3140	021262	042524	052123	005015	
3141	021270	000			
3142	021271	105	042116	047440	MASS17: .ASCIZ /END OF AUTO TEST/<15><12>
3143	021276	020106	040440	052125	
3144	021304	020117	042524	052123	
3145	021312	005015	000		
3146	021315	040	020040	005015	MASS18: .ASCIZ / /<15><12>
3147	021322	000			
3148	021323	124	050131	020105	MASS19: .ASCIZ /TYPE ONE BYTE DATA PATTERN /
3149	021330	047117	020105	054502	
3150	021336	042524	042040	052101	
3151	021344	020101	040520	052124	
3152	021352	051105	020116	020040	
3153	021360	000040			
3154	021362	054524	042520	041440	MASS20: .ASCIZ /TYPE CONTROL-C TO RETURN TO MONITOR/<15><12>
3155	021370	047117	051124	046117	
3156	021376	041455	052040	020117	
3157	021404	042522	052524	047122	
3158	021412	052040	020117	047515	
3159	021420	044516	047524	006522	
3160	021426	000012			
3161	021430	054524	042520	040440	MASS21: .ASCIZ /TYPE ADDRESS OF OUTPUT MUT/
3162	021436	042104	042522	051523	
3163	021444	047440	020106	052517	
3164	021452	050124	052125	046440	
3165	021460	052125	000		
3166	021463	124	050131	020105	MASS22: .ASCIZ /TYPE ADDRESS OF INPUT MUT/
3167	021470	042101	051104	051505	
3168	021476	020123	043117	044440	
3169	021504	050116	052125	046440	
3170	021512	052125	000		
3171	021515	103	047117	042516	MASS23: .ASCIZ /CONNECT OUTPUT TO INPUT MODULE/<15><12>
3172	021522	052103	047440	052125	
3173	021530	052520	020124	047524	
3174	021536	044440	050116	052125	
3175	021544	046440	042117	046125	
3176	021552	006505	000012		
3177	021556	047105	020104	043117	MASS25: .ASCIZ /END OF LOOP TEST/<15><12>
3178	021564	046040	047517	020120	
3179	021572	042524	052123	005015	
3180	021600	000			
3181	021601	127	047522	043516	MASS26: .ASCIZ /WRONG MODULE-OUTPUT MUST BE M6010/<15><12>
3182	021606	046440	042117	046125	

3183 021614 026505 052517 050124  
3184 021622 052125 046440 051525  
3185 021630 020124 042502 046440  
3186 021636 030066 030061 005015  
3187 021644 000  
3188 021645 072 000011  
3189 021650 051127 047117 020107  
3190 021656 047515 052504 042514  
3191 021664 044455 050116 052125  
3192 021672 046440 051525 020124  
3193 021700 042502 042440 052111  
3194 021706 042510 020122 032515  
3195 021714 030460 020060 051117  
3196 021722 046440 030065 030461  
3197 021730 005015 000  
3198 021734  
3199 021734 001116 002002 002050  
3200 021742 002022 001124 001126  
3201 021750 002056 000000  
3202 021754 001116 002002 002014  
3203 021762 002022 001124 001126  
3204 021770 002056 000000  
3205 021774 001116 002022 002052  
3206 022002 000000  
3207 022004 001116 002002 002012  
3208 022012 002022 001124 001126  
3209 022020 002056 000000  
3210 022024 001116 002022 001124  
3211 022032 001126 002056 000000  
3212 022040 001116 002022 002002  
3213 022046 002006 002056 000000  
3214 022054 001116 001124 001126  
3215 022062 002056 000000  
3216 000001

MASS27: .ASCIZ /: /  
MASS28: .ASCIZ /WRONG MODULE-INPUT MUST BE EITHER M5010 OR M5011/<15><12>

.EVEN  
DT17: .WORD \$ERRPC, \$MUT, TEMP1, TNUMB, \$GDDAT, \$BDDAT, PASS,  
DT20: .WORD \$ERRPC, \$MUT, COSADR, TNUMB, \$GDDAT, \$BDDAT, PASS,  
DT23: .WORD \$ERRPC, TNUMB, TEMP3,  
DT7: .WORD \$ERRPC, \$MUT, TBADDR, TNUMB, \$GDDAT, \$BDDAT, PASS,  
DT1: .WORD \$ERRPC, TNUMB, \$GDDAT, \$BDDAT, PASS,  
DT5: .WORD \$ERRPC, TNUMB, \$MUT, TADDR, PASS,  
DT21: .WORD \$ERRPC, \$GDDAT, \$BDDAT, PASS.  
.END

ANALOG	011150	791	1803#											
ANSW	001764	557#												
ATABL	001200	529#	910	954										
AUTO	003612	758	785	898#										
BASE	002042	582#	908	1129	1338	1508	1744	1856	2035					
BITSET	012230	1234	1237	1246	1249	1259	1262	1293	1296	1306	1309	1319	1322	1999#
BIT0 =	000001	455#	478											
BIT00 =	000001	445#	455											
BIT01 =	000002	444#	454											
BIT02 =	000004	443#	453											
BIT03 =	000010	442#	452											
BIT04 =	000020	441#	451											
BIT05 =	000040	440#	450											
BIT06 =	000100	439#	449											
BIT07 =	000200	438#	448											
BIT08 =	000400	437#	447											
BIT09 =	001000	436#	446	2257	2443									
BIT1 =	000002	454#	477											
BIT10 =	002000	435#												
BIT11 =	004000	434#												
BIT12 =	010000	433#												
BIT13 =	020000	432#	857	969	1039	1190	2435							
BIT14 =	040000	431#	862	974	1044	1195								
BIT15 =	100000	430#												
BIT2 =	000004	453#	476											
BIT3 =	000010	452#	475											
BIT4 =	000020	451#	474											
BIT5 =	000040	450#	473											
BIT6 =	000100	449#	472	750	761	777	821	900	1016	1071	1128	1185		
BIT7 =	000200	448#	471	2049										
BIT8 =	000400	447#	2039											
BIT9 =	001000	446#												
BPTVEC =	000014	462#												
BTABL	001440	530#	911	943	949	962								
BYTNUM	002004	567#	1441*	1446*	1469*	1475*	1606*	1608*	1613*	1615*	1619*	1621*	1626*	1628*
		1655*	1657*	1677*	1679*	1710*	1715*	1819*	1824*	1897*	1901*	1905*	1909*	1916*
		1921*	1931	1939*	1942*	1946	1954*	1957*	1963	1967*	1970*	2074	2079*	2083*
		2085*	2101*	2109	2127	2149*	2155*	2159*	2165*	2169*	2175*	2179*	2185*	2191*
		2197*	2201*	2207*	2211*	2217*	2221*	2227*						
CBIT =	000002	477#	840	845	1052	1057	1083	1088	1208	1213	1275	1280	1352	1357
		1403	1408	2052	2057	2136	2141							
CHKBYT	012556	2072#	2156	2166	2176	2186	2198	2208	2218	2228				
CLK	002044	583#	1647*	1662	1670	1675*	1685	2026*						
CLKADR	002024	575#	750*											
CLKVC	002062	590#	1648*	1690*										
CLKVCA	002064	591#	1649*											
CLRINT	012360	1034	1298	1449	1473	1478	1496	1522	1717	1733	1784	1827	1844	1875
		2030#												
CNTRC	012446	853	965	1035	1096	2048#	2067	2128						
COSADR	002014	571#	1706*	1707*	1754	1759	1761	1764*	1772	1777	1779	1782*	3202	
COUNT	012352	1648	2026#											
CR =	000015	370#	2562	2572										
CRLF =	000200	371#	746	2533	2572									
CSR	002026	576#	827	832*	840*	845*	902	909*	939*	1023*	1052*	1057*	1076*	1083*
		1088*	1130*	1207*	1208*	1213*	1218	1264*	1265*	1270	1275*	1280*	1337*	1352*
		1357*	1383*	1397*	1398	1399	1403*	1408*	1439*	1444*	1448*	1467*	1472*	1477*











T10CM	005414	901	940	1186	1202#									
TKVEC =	000060	467#												
TNUMB	002022	574#	1205*	1231*	1243*	1256*	1290*	1303*	1316*	1336*	1374*	1438*	1466*	1553*
		1603*	1643*	1705*	1816*	2006	3199	3202	3205	3207	3210	3212		
TPVEC =	000064	468#												
TRAPVE=	000034	466#	714*	715*										
TRTVEC=	000014	461#												
TSTBYT	011746	1442	1447	1470	1476	1609	1616	1622	1629	1658	1680	1711	1716	1820
		1825	1930#											
TSTONE	012030	1673	1688	1945#										
TST1	005414	1204#	2271											
TST10	006232	1335#	2278											
TST11	006376	1373#	2279											
TST12	006672	1437#	2280											
TST13	006774	1465#	2281											
TST14	007440	1552#	2282											
TST15	007632	1602#	2283											
TST16	010024	1642#	2284											
TST17	010322	1704#	2285											
TST2	005546	1230#	2272											
TST20	011152	1815#	2286											
TST3	005612	1242#	2273											
TST4	005656	1255#	2274											
TST5	006052	1289#	2275											
TST6	006122	1302#	2276											
TST7	006166	1715#	2277											
TYPDS =	104405	2796#												
TYPE =	104401	743	766	767	768	769	770	771	772	773	774	778	782	812
		816	822	861	864	870	873	882	883	886	948	951	973	978
		1014	1017	1020	1043	1046	1048	1050	1069	1095	1102	1105	1134	1138
		1140	1142	1144	1146	1148	1150	1152	1154	1157	1194	1197	2096	2117
		2120	2339	2342	2346	2409	2411	2438	2463	2480	2482	2485	2487	2491
		2498	2536	2630	2699	2792#	2838							
TYPOC =	104402	860	872	950	972	1042	1104	1136	1156	1193	2116	2119	2471	2495
		2793#												
TYPON =	104404	2795#												
TYPOS =	104403	2794#												
VECTO	002032	578#	1375*	1485*	1722*	1833*								
VECTQA	002034	579#	1376*	1486*	1723*	1834*								
VECT1	002036	580#												
VECT1A	002040	581#												
XXDP	002000	565#	756	976										
YLOOP	001766	558#	841*	842*	843	846*	847*	848	1053*	1054*	1055	1058*	1059*	1060
		1084*	1085*	1086	1089*	1090*	1091	1209*	1210*	1211	1214*	1215*	1216	1266*
		1267*	1268	1276*	1277*	1278	1281*	1282*	1283	1353*	1354*	1355	1358*	1359*
		1360	1384*	1385*	1386	1404*	1405*	1406	1409*	1410*	1411	1489*	1490*	1491
		1530*	1531*	1532	1726*	1727*	1728	1793*	1794*	1795	1837*	1838*	1839	1883*
		1884*	1885	2001*	2002*	2003	2053*	2054*	2055	2058*	2059*	2060	2137*	2138*
		2139	2142*	2143*	2144	2151*	2152*	2153	2161*	2162*	2163	2171*	2172*	2173
		2181*	2182*	2183	2193*	2194*	2195	2203*	2204*	2205	2213*	2214*	2215	2223*
		2224*	2225											
SAUTOB	001134	505#												
SBODAR	001122	500#												
SBDDAT	001126	502#	1218*	1220	1341*	1347*	1395*	1571*	1572	1754*	1755	1761*	1772*	1773
		1779*	1933*	1934	1948*	1949	2000*	2005*	2008*	2009	2013*	2014*	2075*	2076
		3199	3202	3207	3210	3214								





MAIN. MACY11 30(1046) 25-OCT-77 10:10 PAGE 86  
DVPCAR. P11 25-OCT-77 10:02

CROSS REFERENCE TABLE -- USER SYMBOLS

SEQ 0087

= 022066	342#	346#	351#	353#	355#	357#	359#	487#	528	529#	530#	707	719
	746#	1008	2270	2290	2354#	2355	2361	2414	2455	2501#	2572	2638#	2820
	2842	3198#											

ABS. 022066 000

ERRORS DETECTED: 0

DVPCAR. BIN. DVPCAR. SEQ/CRF=DVPCAR. P11  
RUN-TIME: 17 9 .9 SECONDS  
RUN-TIME RATIO: 441/28=15.6  
CORE USED: 24K (47 PAGES)