

Micro Fiche Scan

Name of device(s) tested:

DJ11

Test description:

DJ11 MODULE

MAINDEC Number or Package Identifier (after SEP 1977):

CXDJAL0

Fiche Document Part Number:

AH-E723L-MC

Fiche preparation date unknown, using copyright year:

1982

Image resolution:

8-bit gray levels, max. quality for archiving

COPYRIGHT (C) 73-82 by d|i|g|i|t|a|l

.REM %

IDENTIFICATION

PRODUCT CODE: AC-E721L-MC

PRODUCT NAME: CXDJALO DJ11 MODULE

DATE: JUNE 1981

MAINTAINER: DEC/X11 SUPPORT GROUP

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS MANUAL.

THE SOFTWARE DESCRIBED IN THIS DOCUMENT IS FURNISHED TO THE PURCHASER UNDER A LICENSE FOR USE ON A SINGLE COMPUTER SYSTEM AND CAN BE COPIED (WITH INCLUSION OF DIGITALS COPYRIGHT NOTICE) ONLY FOR USE IN SUCH SYSTEM, EXCEPT AS MAY OTHERWISE BE PROVIDED IN WRITING BY DIGITAL.

DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL.

COPYRIGHT (C) 1973,1982 DIGITAL EQUIPMENT CORPORATION

%

REM %  
1.

### ABSTRACT

THIS MODULE EXERCISES ANY COMBINATION OF ONE TO SIXTEEN LINES ON ANY COMBINATION OF FROM ONE TO FOUR DJ11 ASYNCHRONOUS, SIXTEEN LINE COMMUNICATION DEVICES. 65 CHARACTERS ARE TRANSMITTED ON EACH DJ11 UNDER INTERRUPT CONTROL. TRANSMISSION OF THE 65TH CHARACTER CAUSES A RECEIVER BUFFER FULL INTERRUPT ON THE DJ11. THE ROUTINE DISABLES INTERRUPTS ON THE RESPECTIVE DJ11 AND EMPTIES THE HARDWARE SILO INTO A SOFTWARE BUFFER. THE DATA IS CHECKED, THEN INTERRUPTS ARE REENABLED AND TRANSMISSION RESUMED FOR THE GIVEN DJ11. AS EACH LINE FINISHES TRANSMISSION OF THE FULL 8-BIT COUNT PATTERN, IT IS DISABLED. THUS, THERE ARE TIMEW WHEN ONLY A SUBSET OF THE SELECTED LINES ARE ACTUALLY RUNNING. WHEN ALL LINES ON A DJ11 HAVE TRANSMITTED THE ENTIRE COUNT PATTERN, THEY ARE ALL REENABLED AND THE PATTERN TRANSMISSION IS RESTARTED. A PASS IS DEFINED AS 200 (OCTAL) TRANSMISSIONS OF 65 CHARACTERS EACH ON EACH ACTIVE DJ11. THE MODULE ASSUMES THAT ALL SIXTEEN LINES WILL BE EXERCISED AND WILL BE SENDING 8 BIT CHARACTERS. SEE "OPERATION OPTIONS" BELOW FOR NECESSARY CHANGES REQUIRED FOR OTHER CONFIGURATIONS.

A BACKGROUND "WATCHDOG TIMER" IS ALSO RUN BY THE MODULE TO ALLOW DETECTION OF THE "DEVICE HUNG" CONDITION (AN EXPECTED INTERRUPT THAT FAILED TO OCCUR). THE TIMER IS SET TO RUN LONGER THAN THE LONGEST POSSIBLE MODULE PASS TIME, AND ON A HEAVILY LOADED SYSTEM WILL IN FACT TAKE A LONG TIME TO TIMEOUT (I.E. 10-15 MINUTES). WHEN THE "DEVICE HUNG" CONDITION IS DETECTED, A "DEVICE HUNG" MESSAGE IS OUTPUT AND THE MODULE IS THEN DROPPED. THIS PREVENTS A LONG RUN FROM BEING PERMANENTLY UNABLE TO RELOCATE DUE TO A "LOST" INTERRUPT.

### 2. REQUIREMENTS

HARDWARE: DJ11 SIXTEEN LINE ASYNCHRONOUS COMMUNICATION DEVICE.

STORAGE:: DJA REQUIRES:

1. DECIMAL WORDS: 01169
2. OCTAL WORDS: 02217
3. OCTAL BYTES: 04436

### 3. PASS DEFINITION

ONE PASS OF THE DJA MODULE CONSISTS OF TRANSMITTING, RECEIVING, AND CHECKING 8320. CHARACTERS PER DJ11.

### 4. EXECUTION TIMES

WORST CASE (1 LINE ONLY ON EACH OF 4 DJ11'S AT 75 BAUD) TAKES APPROXIMATELY 3 MINUTES PER PASS. RUNNING ALL LINES (DEFAULT CASE) WILL CAUSE SEVERAL PASSES PER MINUTE TO BE COMPLETED.

### 5. CONFIGURATION REQUIREMENTS

DEFAULT PARAMETERS:

BR1: 5  
DEVICE COUNT(DVID1): 1

REQUIRED PARAMETERS:

FIRST DEVICE ADDRESS: THE FIRST DEVICE REGISTER ADDRESS  
MUST BE SPECIFIED.

VECTOR: THE VECTOR ADDRESS OF THE FIRST DJ11 MUST BE GIVEN

DVID1: IF MORE THAN 1 UNIT IS BEING RUN, VALUE MUST BE GIVEN  
(4 UNITS MAX)

6. DEVICE/OPTION SETUP

ALL SIXTEEN LINES OPERATIONAL (DEFAULT) OR ALL SELECTED LINES OPERATIONAL  
(IF NOT ALL LINES SELECTED).

7. MODULE OPERATION

A. INITIALIZE FIRST VALUES TO BE TRANSMITTED FRO EACH LINE  
(SET TO ZERO).

B. INITIALIZE INTERNAL QUEUES AND PARAMETERS, SETUP LINKAGE OF DEVICE  
VECTORS TO LINKAGE TABLE, AND INITIALIZE SELECTED DJ11'S  
VIA SETTING 'MOS CLEAR'.

C. SET TRANSMITTER INTERRUPT ENABLE AND SILO FULL INTERRUPT ENABLE,  
THEN SET TRANSMITTER ENABLE FOR ALL SELECTED LINES ON EACH  
SELECTED DJ11. COUNT DJ11'S SELECTED AS THEY GET TURNED ON.

D. INITIALIZE WATCHDOG TIMER, WHICH RUNS VIA A SET OF 'BREAK'  
LOOPS. THE LOOP MONITORS THE COUNT OF ACTIVE DJ11'S. IF THE DJ11  
COUNT GOES TO ZERO BEFORE THE TIMER TIMES OUT, AN END OF PASS CALL  
IS MADE. (WHICH WILL EVENTUALLY CAUSE THE MODULE TO BE RESTARTED  
AT STEP B). IF THE TIMER TIMES OUT BEFORE THE DJ11 ACTIVE  
COUNT GOES TO ZERO, A 'DEVICE HUNG' MESSAGE IS OUTPUT AND  
THE MODULE IS DROPPED.

E. WHEN A TRANSMIT INTERRUPT OCCURS, TRANSMIT INTERRUPT ENABLE IS  
TURNED OFF FOR THAT DJ11, A UNIT IDENTIFICATION IS SAVED IN  
THE MODULE'S TRANSMIT QUEUE, AND THE MODULE PIRQ'S. WHEN THE MONITOR  
RETURNS TO THE TRANSMIT ISR, THE NEXT CHARACTER FOR THE  
INTERRUPTING LINE IS TRANSMITTED. IF THE CHARACTER TRANSMITTED  
WAS 377 (OCTAL), THEN THAT LINE IS DISABLED FROM BEING  
RUN UNTIL ALL THE OTHER LINES HAVE ALSO REACHED THE MAX VALUE  
(ACTUALLY, IT WON'T BE DISABLED UNTIL THE NEXT 65 CHARACTER  
TRANSMISSION ON THIS DJ11). IF ALL LINES ARE DISABLED,  
THE SELECTED LINES GET REENABLED. IF 65 (DECIMAL) CHARACTERS  
HAVE BEEN TRANSMITTED, THE TRANSMITTER IS DISABLED BY CLEARING THE  
TRANSMITTER CONTROL REGISTER. IF LESS THAN 65 CHARACTERS HAVE  
BEEN TRANSMITTED, TRANSMIT INTERRUPT ENABLE IS REENABLED. THE  
TRANSMITTER SERVICE THEN EXITS.

F. WHEN 65 CHARACTERS HAVE BEEN TRANSMITTED ON A GIVEN DJ11, A  
RECEIVER BUFFER ('SILO') FULL INTERRUPT SHOULD OCCUR. THE  
MODULE THEN DISABLES THE 'SILO FULL' INTERRUPT, QUEUES A  
UNIT IDENTIFICATION IN IT'S RECEIVER QUEUE, AND PIRQ'S. WHEN THE  
MONITOR RETURNS TO THE RECEIVER SERVICE, THE MODULE DUMPS  
THE CONTENTS OF THE HARDWARE SILO OF THE INTERRUPTING DJ11 INTO A  
SOFTWARE BUFFER AND CHECKS THE DATA. IF THE REQUIRED NUMBER OF  
TRANSMISSIONS (STORED IN ENDSL) HAVE BEEN PERFORMED BY THIS



DJ11, IT IS TURNED OFF AND THE DJ11 ACTIVE COUNT IS DECREMENTED. IF NOT ALL DONE, THE RECEIVER DATA TABLE IS RESYNCD TO MATCH THE TRANSMITTER TABLE AND THE DJ11 IS REENABLED TO TRANSMIT ANOTHER 65 CHARACTERS. WHEN THE DJ11 ACTIVE COUNT GOES TO 0, THE WATCHDOG TIMER WILL DETECT IT AND ISSUE AN END OF PASS (SEE STEP D).

THE SELECTED LINES GET REENABLED. IF 65 (DECIMAL) CHARACTERS

8. OPERATION OPTIONS

A. TO MAKE THE TIME INTERVAL BETWEEN ENDPAS STATEMENTS LONGER OR SHORTER, EITHER INCREASE OR DECREASE THE 'ENDSEL' WORD.

B. TO EXERCISE A CONFIGURATION OF LINES OTHER THAN ALL SIXTEEN AT ONCE, CHANGE THE APPROPRIATE BITS OF THE 'XMITEN' WORD FOR THE SELECTED DJ11 AND THE SAME BITS OF THE 'XMTSEL' WORD. A ONE INDICATES THAT THE LINE IS TO BE EXERCISED, A ZERO INDICATES THAT THE LINE IS OFF.

C. MEANING OF SR1

1. FOR 5 BIT DATA SET BIT 2 (SR1=000004)  
FOR 6 BIT DATA SET BIT 1 (SR1=000002)  
FOR 7 BIT DATA SET BIT 0 (SR1=000001)  
FOR 8 BIT DATA SET NO BITS (SR1=000000)  
DEFAULT VALUE IS 8 BIT DATA LENGTH  
CHECK HARDWARE STRAPPING TO DETERMINE SR1 SETTING
2. ITERATION COUNT - USED TO ADJUST PASS TIME TO BAUD RATE  
FOR 75 BAUD SET BIT 5  
FOR 110 BAUD SET BIT 6  
FOR 134.5 BAUD SET BIT 7  
FOR 150 BAUD SET BIT 8  
FOR 300 BAUD SET BIT 9  
FOR 600 BAUD SET BIT 10  
FOR 1200 BAUD SET BIT 11  
FOR 1800 BAUD SET BIT 12  
FOR 2400 BAUD SET BIT 13  
FOR 4800 BAUD SET BIT 14  
FOR 9600 BAUD SET BIT 15 OR NO BITS (5-15=0)

9. NON STANDARD PRINTOUTS

THERE ARE 2 SPECIAL MESSAGES WHICH MAY BE PRINTED OUT. THEY ARE:

'UNIT DROPPED'- THIS INDICATES THAT A DJ11 WHICH HAS JUST PREVIOUSLY REPORTED A FAILURE HAS BEEN DROPPED. DJ11'S ARE DROPPED IF 'BUSY CLEAR' FAILS TO CLEAR WHEN THEY ARE INITIALIZED.

'UNIT HUNG'- THIS INDICATES THAT THE MODULE'S WATCHDOG TIMER HAS TIMED OUT BEFORE THE DJ11 DEVICE ACTIVE COUNT WENT TO ZERO. THIS OCCURS WHEN AN EXPECTED TRANSMITTER OR RECEIVER INTERRUPT FAILS TO OCCUR ON ONE OR MORE DJ11'S.

\*\*\*\*\*  
\* EDIT: BY: DATE: REASON: \*

```
*
*      003      R. GAUDIN      19-JUN-81      ADD ERROR PRINTOUT WHEN THE      *
*                                                    VECTOR + ADDR LOCS. ARE ZERO. *
*
*****
```

%

```
.SBTTL MODULE HEADER
000000' IOMOD <DJAL >,0,0,5,,0,36
000000' MODULE 140000,DJAL,0,0,5,,0,36,,,,,
; .TITLE DJAL DEC/X11 SYSTEM EXERCISER MODULE
DDXCOM VERSION 6.2 23-APR-81
.LIST BIN
*****
000000' BEGIN:
000000' 045104 046101 040 MODNAM: .ASCII /DJAL / ;MODULE NAME.
000005' 000 XFLAG: .BYTE OPEN ;USED TO KEEP TRACK OF WBUFF USAGE
000006' 000000 ADDR: 0+0 ;1ST DEVICE ADDR.
000010' 000000 VECTOR: 0+0 ;1ST DEVICE VECTOR.
000012' 240 BR1: .BYTE PRTY5+0 ;1ST BR LEVEL.
000013' 000 BR2: .BYTE PRTY+0 ;2ND BR LEVEL.
000014' 000001 DVID1: +1 ;DEVICE INDICATOR 1.
000016' 000000 SR1: OPEN ;SWITCH REGISTER 1
000020' 000000 SR2: OPEN ;SWITCH REGISTER 2
000022' 000000 SR3: OPEN ;SWITCH REGISTER 3
000024' 000000 SR4: OPEN ;SWITCH REGISTER 4
*****
000026' 140000 STAT: 140000 ;STATUS WORD.
000030' 002056' INIT: START ;MODULE START ADDR.
000032' 000224' SPOINT: MODSP ;MODULE STACK POINTER.
000034' 000000 PASCNT: 0 ;PASS COUNTER.
000036' 000000 ICOUNT: 0 ;# OF ITERATIONS PER PASS=0
000040' 000000 SOFCNT: 0 ;LOC TO COUNT ITERATIONS
000042' 000000 HRDCNT: 0 ;LOC TO SAVE TOTAL SOFT ERRORS
000044' 000000 SOFPAS: 0 ;LOC TO SAVE TOTAL HARD ERRORS
000046' 000000 HRDPAS: 0 ;LOC TO SAVE SOFT ERRORS PER PASS
000050' 000000 SYSCNT: 0 ;LOC TO SAVE HARD ERRORS PER PASS
000052' 000000 RANNUM: 0 ;# OF SYS ERRORS ACCUMULATED
000054' 000000 CONFIG: ;HOLDS RANDOM # WHEN RAND MACRO IS CALLED
000056' 000000 RES1: 0 ;RESERVED FOR MONITOR USE
000060' 000000 RES2: 0 ;RESERVED FOR MONITOR USE
000062' 000000 SVR0: OPEN ;LOC TO SAVE R0.
000064' 000000 SVR1: OPEN ;LOC TO SAVE R1.
000066' 000000 SVR2: OPEN ;LOC TO SAVE R2.
000070' 000000 SVR3: OPEN ;LOC TO SAVE R3.
000072' 000000 SVR4: OPEN ;LOC TO SAVE R4.
000074' 000000 SVR5: OPEN ;LOC TO SAVE R5.
000076' 000000 SVR6: OPEN ;LOC TO SAVE R6.
000100' 000000 CSRA: OPEN ;ADDR OF CURRENT CSR.
000102' SBADR: ;ADDR OF GOOD DATA, OR
000102' 000000 ACSR: OPEN ;CONTENTS OF CSR.
000104' WASADR: ;ADDR OF BAD DATA, OR
000104' 000000 ASTAT: OPEN ;STATUS REG CONTENTS.
000106' ERRTYP: ;TYPE OF ERROR
000106' 000000 ASB: OPEN ;EXPECTED DATA.
000110' 000000 AWAS: OPEN ;ACTUAL DATA.
000112' 002440' RSTRT: RESTRT ;RESTART ADDRESS AFTER END OF PASS
000114' 000000 WDTO: OPEN ;WORDS TO MEMORY PER ITERATION
000116' 000000 WDFR: OPEN ;WORDS FROM MEMORY PER ITERATION
000120' 000000 INTR: OPEN ;# OF INTERRUPTS PER ITERATION
000122' 000036 IDNUM: 36 ;MODULE IDENTIFICATION NUMBER=36
000040 .REPT SPSIZ ;MODULE STACK STARTS HERE.
```



.NLIST  
.WORD 0  
.LIST  
.ENDR

000224'

MODSP:

\*\*\*\*\*

281  
282  
283  
284  
285  
286  
287  
288  
289  
290  
291  
292  
293  
294  
295  
296  
297  
298  
299  
300  
301  
302  
303  
304  
305  
306  
307  
308  
309  
310  
311  
312  
313  
314  
315  
316  
317  
318  
319  
320  
321  
322  
323  
324  
325  
326  
327  
328  
329  
330

:+  
: THE NEXT LOCATION CONTAINS A NUMBER THAT CAN BE EXAMINED IN CORE TO BE  
: SURE THAT THE LISTING AND ACTUAL CODE ARE THE SAME. THIS LOCATION IS TO  
: BE INCREMENTED EACH TIME THE SOURCE CODE IS UPDATED. LOCATION 'MODREV'  
: IS NOT USED BY THE PROGRAM.  
:-

000224' 000005

MODREV: 1+1+1+1+0

\*\*\*\*\*

.SBTTL SOME VARIABLES AND CONSTANTS UNIQUE TO THIS ROUTINE

DJLINK: JSR R5,RCVINT ;UNIT 0 RECEIVER  
0  
JSR R5,XMTINT ;UNIT 0 TRANSMITTER  
0  
JSR R5,RCVINT ;UNIT 1 RECEIVER  
10  
JSR R5,XMTINT ;UNIT 1 TRANSMITTER  
10  
JSR R5,RCVINT ;UNIT 2 RECEIVER  
20  
JSR R5,XMTINT ;UNIT 2 TRANSMITTER  
20  
JSR R5,RCVINT ;UNIT 3 RECEIVER  
30  
JSR R5,XMTINT ;UNIT 3 TRANSMITTER  
30

OPEN=0

XMTTBL: .BLKW 32.

:A TABLE FOR RECORDING CHARACTERS WHICH HAVE  
:BEEN TRANSMITTED

RCVTBL: .BLKW 64.

:A TABLE FOR RECORDING CHARACTERS WHICH YOU  
:EXPECT TO RECEIVE

SILO: .BLKW 260.

:A BUFFER AREA TO STORE THE DATA RECORDED IN  
:THE DJ'S RECEIVER SILO

XQ: .BLKW 4.

:A QUEUE FOR SAVING THE DEVICE OFFSET WHILE A  
:TRANSMIT INTERRUPT IS IN 'PIRQ'

RQ: .BLKW 4.

:A QUEUE FOR SAVING THE DEVICE OFFSET WHILE A  
:RECEIVER INTERRUPT IS IN 'PIRQ'

ERRQ: .BLKW 16.

ERRQI: OPEN

ERRQO: OPEN

001702' 000101 000101 000101 XCNT: .WORD 101,101,101,101

:NUMBER OF CHARACTERS LEFT TO BE TRANSMITTED DURING

001710' 000101

:THIS INTERRUPT. A WORD FOR EACH DEVICE



```

331
332 001712' 000101 000101 000101 RCNT:.WORD 101,101,101,101 ;NUMBER OF CHARACTERS TO BE PROCESSED BY THE
333 001720' 000101 ;RECEIVE ROUTINE. A WORD FOR EACH DEVICE
334
335
336
337 001722' 000200 000200 000200 ENDCNT:.WORD 200,200,200,200 ;NUMBER OF '65 CHARACTER CHUNKS'
338 001730' 000200 ;TO BE PROCESSED BY THE MODULE PER PASS
339
340
341 001732' 177777 177777 177777 XMTSEL: .WORD 177777,177777,177777,177777 ;LINES TO BE RUN
342 001740' 177777
343
344 001742' 177777 177777 177777 XMITEN:.WORD 177777,177777,177777,177777 ;WORD USED TO FILL TRANSMITTER COMMAND
345 001750' 177777 ;REGISTER 16XXX2,CORRESPONDS TO
346 ;A ONE FOR EACH ACTIVE LINE
347
348
349 001752' 000000 000000 000000 XMITSV: .WORD 0,0,0,0 ;SAVE LINES ACTIVATED IN CASE OF HANG
350 001760' 000000
351
352
353
354
355
356
357 001762' 001616' XPNTW: XQ ;POINTERS USED FOR THE BOOKKEEPING OF
358 001764' 001616' XPNTR: XQ ;THE TRANSMIT QUEUE
359 001766' 001626' RPNTW: RQ ;POINTERS USED FOR THE BOOKKEEPING OF
360 001770' 001626' RPNTR: RQ ;THE RECEIVE QUEUE
361
362 001772' 000000 I: 000 ;TEMPORARY STORAGE LOCATION,USED DURING RECEIVE DATA CHE
363 001774' 000001 SELMSK: 1 ;MASK TO CHECK FOR UNIT SELECTED
364 001776' 000000 SELECT: 0
365 002000' 100000 EXPLIN: 100000 ;USED DURING INITIALIZATION,THE ONE REPRESENTS THE
366 ;DONE BIT IN THE EXPECTED RECEIVE DATA TABLE
367 002002' 000200 ENDSEL: 200 ;REFILL OF 'ENDSEL' WORD AFTER ENDPASS
368 002004' 000101 CNTSEL: 101 ;REFILL OF 'RCNT' AND 'XCNT' AFTER AN INTERRUPT SERVICE
369 ;NOT VARIABLE SINCE 65. CHARS REQD TO GET SILO FULL INT
370 002006' 000000 VCT: OPEN ;HOLDS VECTOR ADDRESS DURING SETUP ERROR PRINTOUT
371 002010' 000000 LINK: OPEN ;HOLDS LINK ADDRESS DURING SETUP ERROR PRINTOUT
372 002012' 000000 SCSR: OPEN
373 002014' 000000 ENDFLG: OPEN ;NUMBER OF DJ11'S STILL RUNNING
374 002016' 000110 TIME: 110 ;WATCHDOG TIMER OUTER LOOP VALUE
375 002020' 000000 TIMER: 0
376 002022' 000000 TIME1: 0
377 002024' 000000 MASK: 0 ;-DATA BIT LENGTH (5-8) MASK
378 002026' 000000 CHAR: 0 ;-TEMP HOLDING FOR MASK & ITERATION COUNT &
379 ;-DATA COMPARSION DURING TEST.
380 002030' 017000 TMETBL: 17000 ;-9600 BPS VARIABLE
381 002032' 011700 11700 ;-4800 BPS ITERATION
382 002034' 006000 6000 ;-2400 BPS COUNTS
383 002036' 005100 5100 ;-1800 BPS PER
384 002040' 003000 3000 ;-1200 BPS LINE
385 002042' 001600 1600 ;-600 BPS SPEEDS
386 002044' 000750 750 ;-300 BPS

```





|     |         |        |         |         |         |                   |                 |  |  |
|-----|---------|--------|---------|---------|---------|-------------------|-----------------|--|--|
| 443 | 002300* | 066767 | 177476  | 175530  |         | ADD               | ENDSEL,ICONT    |  | :YUP - SET ADDITIONAL COUNT                    |
| 444 | 002306* | 062767 | 000101  | 175604  |         | ADD               | #65.,INTR       |  | :65 MORE TRUPS                                 |
| 445 | 002314* | 062767 | 000100  | 175572  |         | ADD               | #64.,WDTO       |  | :64. MORE WORDS TO                             |
| 446 | 002322* | 062767 | 000100  | 175566  |         | ADD               | #64.,WDFR       |  | :64. MORE WORDS FROM                           |
| 447 | 002330* | 000761 |         |         |         | BR                | 11\$            |  | :GO CHECK FOR MORE                             |
| 448 | 002332* | 012767 | 100000  | 177440  | 9\$:    | MOV               | #100000,EXPLIN  |  | :SETUP TO PRESET THE RECEIVE TABLE             |
| 449 | 002340* | 012704 | 000406* |         |         | MOV               | #RCVTBL,R4      |  | :GET START ADDRESS OF RECEIVE TABLE            |
| 450 | 002344* | 016724 | 177430  |         | 5\$:    | MOV               | EXPLIN,(R4)+    |  | :LOAD RECEIVE TABLE WITH A DONE BIT AND LINE # |
| 451 | 002350* | 105267 | 177425  |         |         | INCB              | EXPLIN+1        |  | :INCREMENT TO THE NEXT LINE NUMBER             |
| 452 | 002354* | 042767 | 070000  | 177416  |         | BIC               | #070000,EXPLIN  |  | :MAKE SURE LINE # NEVER GREATER THAN FIFTEEN   |
| 453 | 002362* | 020427 | 000606* |         |         | CMP               | R4,#SILO        |  | :SEE IF DONE PRESETTING                        |
| 454 | 002366* | 103766 |         |         |         | BLO               | 5\$             |  | :BRANCH BACK IF NOT                            |
| 455 | 002370* | 012767 | 177400  | 177430  |         | MOV               | #177400,CHAR    |  | :-PRESET MASK FOR 8 BIT DATA                   |
| 456 | 002376* | 016767 | 175414  | 177420  |         | MOV               | SR1,MASK        |  | :-GET OPERATOR INPUT                           |
| 457 | 002404* | 042767 | 177770  | 177412  |         | BIC               | #177770,MASK    |  | :-ELIMINATE ITERATION BAUD COUNT               |
| 458 | 002412* | 005767 | 177406  |         |         | TST               | MASK            |  | :8-BIT   |
| 459 | 002416* | 001405 |         |         |         | BEQ               | 7\$             |  | :MK001   |
| 460 | 002420* | 006267 | 177402  |         | 6\$:    | ASR               | CHAR            |  | :-SHIFT TO RIGHT-                              |
| 461 | 002424* | 006267 | 177374  |         |         | ASR               | MASK            |  | :-SIZE MASK.                                   |
| 462 | 002430* | 001373 |         |         |         | BNE               | 6\$             |  | :-DONE?  |
| 463 | 002432* | 116767 | 177370  | 177364  | 7\$:    | MOVB              | CHAR,MASK       |  | :-SAVE IT.                                     |
| 464 | 002440* | 005767 | 177332  |         | RESTRT: | TST               | SELECT          |  | :ANY DJ'S SELECTED?                            |
| 465 | 002444* | 001404 |         |         |         | BEQ               | 1\$             |  | :BR IF NO                                      |
| 466 | 002446* | 032767 | 177760  | 177322  |         | BIT               | #177760, SELECT |  | :UNITS OTHER THAN 0-3 SELECTED?                |
| 467 | 002454* | 001402 |         |         |         | BEQ               | 2\$             |  | :NO- OK  |
| 468 | 002456* |        |         |         | 1\$:    |                   |                 |  |  |
| 469 | 002456* | 104410 | 000000* |         |         | ENDS\$,BEGIN      |                 |  | :UNIT SELECTION (DVID1) INCORRECT              |
| 470 | 002462* | 012767 | 001616* | 177272  | 2\$:    | MOV               | #XQ,XPNTW       |  | :SETUP QUEUE POINTERS                          |
| 471 | 002470* | 012767 | 001616* | 177266  |         | MOV               | #XQ,XPNTR       |  |  |
| 472 | 002476* | 012767 | 001626* | 177262  |         | MOV               | #RQ,RPNTW       |  |  |
| 473 | 002504* | 012767 | 001626* | 177256  |         | MOV               | #RQ,RPNTR       |  |  |
| 474 | 002512* | 012767 | 001636* | 177156  |         | MOV               | #ERRQ,ERRQI     |  |  |
| 475 | 002520* | 012767 | 001636* | 177152  |         | MOV               | #ERRQ,ERRQO     |  |  |
| 476 | 002526* | 005067 | 177262  |         |         | CLR               | ENDFLG          |  |  |
| 477 | 002532* | 012701 | 000226* |         |         | MOV               | #DJLINK,R1      |  | :GET ADDRESS OF DJ'S LINKING TABLE             |
| 478 | 002536* | 016700 | 175246  |         |         | MOV               | VECTOR,R0       |  | :GET VECTOR ADDRESS                            |
| 479 | 002542* | 001403 |         |         |         | BEQ               | 3\$             |  | :BR IF VECTOR = ZERO                           |
| 480 | 002544* | 016705 | 175236  |         |         | MOV               | ADDR,R5         |  | :GET CSR ADDRESS                               |
| 481 | 002550* | 001005 |         |         |         | BNE               | 4\$             |  | :BR IF ADDR NOT = ZERO                         |
| 482 | 002552* |        |         |         | 3\$:    |                   |                 |  |  |
| 483 | 002552* | 104401 | 000000* | 004461* |         | MSG\$,BEGIN,NOVEC |                 |  | :ASCII MESSAGE CALL                            |
| 484 | 002560* | 104410 | 000000* |         |         | ENDS\$,BEGIN      |                 |  | :DROP MODULE                                   |
| 485 | 002564* | 012767 | 000001  | 177202  | 4\$:    | MOV               | #1,SELMSK       |  | :RG03  |
| 486 | 002572* | 036767 | 177176  | 177176  | NXTDEV: | BIT               | SELMSK,SELECT   |  | :HAS THIS DEVICE BEEN SELECTED?                |
| 487 | 002600* | 001530 |         |         |         | BEQ               | 1\$             |  | :NO- BRANCH                                    |
| 488 | 002602* | 010120 |         |         |         | MOV               | R1,(R0)+        |  | :YES- LOAD RCV INT VECTOR                      |
| 489 | 002604* | 116720 | 175202  |         |         | MOVB              | BR1,(R0)+       |  | :LOAD RCV BR                                   |
| 490 | 002610* | 105020 |         |         |         | CLRB              | (R0)+           |  |  |
| 491 | 002612* | 062701 | 000006  |         |         | ADD               | #6,R1           |  |  |
| 492 | 002616* | 010120 |         |         |         | MOV               | R1,(R0)+        |  | :LOAD XMT INT VECTOR                           |
| 493 | 002620* | 116720 | 175166  |         |         | MOVB              | BR1,(R0)+       |  | :LOAD XMT BR                                   |
| 494 | 002624* | 105020 |         |         |         | CLRB              | (R0)+           |  |  |
| 495 | 002626* | 062701 | 000006  |         |         | ADD               | #6,R1           |  |  |
| 496 | 002632* | 004767 | 001340  |         |         | JSR               | PC,TBLSNC       |  | :SYNCH RCV AND XMT TABLES                      |
| 497 | 002636* | 012715 | 000014  |         |         | MOV               | #14,(R5)        |  | :CLEAR DJ BUFFER AND UARTS                     |
| 498 | 002642* | 012704 | 000010  |         |         | MOV               | #10,R4          |  | :SETUP WAIT LOOP COUNTER                       |

```
499 002646* 032715 000020      10$: BIT      #20,(R5)          ;'BUSY CLEAR' GONE LOW YET?
500 002652* 001456              BEQ      11$          ;YES- BRANCH
501 002654* 104407 000000*      BREAK$,BEGIN        ;TEMPORARY RETURN TO MONITOR....
502 002660* 104407 000000*      BREAK$,BEGIN        ;THEN CONTINUE AT NEXT INSTRUCTION.
503 002664* 005304              DEC      R4          ;WAIT LOOP COUNTER
504 002666* 001367              BNE     10$          ;LOOP IF NOT TIMED OUT
505 002670* 010167 177114        MOV     R1,LINK      ;SAVE INFO DURING ERROR (CAN BE DONE
506 002674* 010067 177106        MOV     R0,VCT       ;SINCE THIS IS A SEQUENTIAL LOOP
507 002700* 010567 177106        MOV     R5,SCSR      ;AND INFO NOT USED ELSEWHERE)
508 002704* 046767 177064 177064 BIC     SELMSK,SELECT ;CLEAR UNIT SELECTED BIT - DROP UNIT
509 002712* 010567 175162        MOV     R5,CSRA      ;SETUP FOR ERROR PRINTOUT
510 002716* 011567 175160        MOV     @R5,ACSR
511 002722* 005015              CLR     @R5          ;DISABLE UNIT
512 002724* 012767 000016 175154 MOV     #16,ERRTYP   ;BUSY STUCK
513                                     ;*****
514 002732* 104405 000000* 000000 HRDR$,BEGIN,NULL    ;BUSY CLEAR DIDN'T CLEAR IN TIME
515                                     ;*****
516 002740* 104403 000000* 004422* MSGN$,BEGIN,DROPM   ;ASCII MESSAGE CALL WITH COMMON HEADER
517                                     ;'UNIT DROPPED'
518 002746* 016767 177044 177044 MOV     TIME,TIMER   ;RESET TIMER DUE TO PRINTOUT DELAY
519 002754* 005767 177016        TST     SELECT       ;ANY DJ'S STILL SELECTED?
520 002760* 001002              BNE     12$          ;YES- BRANCH
521 002762* 104410 000000*      ENDS$,BEGIN        ;ALL UNITS DROPPED
522 002766* 016701 177016      12$: MOV     LINK,R1
523 002772* 016700 177010        MOV     VCT,R0
524 002776* 016705 177010        MOV     SCSR,R5
525 003002* 062705 000010        ADD     #10,R5
526 003006* 000433              BR      2$
527 003010* 012715 050405      11$: MOV     #50405,(R5)   ;TURN ON RCVR AND XMIT ENABLE
528 003014* 010503              MOV     R5,R3
529 003016* 166703 174764        SUB     ADDR,R3
530 003022* 006203              ASR     R3
531 003024* 006203              ASR     R3          ;GET OFFSET (UNIT # TIMES 2)
532 003026* 016363 001732* 001742* MOV     XMTSEL(R3),XMITEN(R3)
533 003034* 016363 001742* 001752* MOV     XMITEN(R3),XMITSV(R3) ;SAVE IN CASE OF HANG TO SHOW ACTIVE LINES
534 003042* 016365 001742* 000004 MOV     XMITEN(R3),4(R5) ;TURN ON XMTR
535 003050* 005267 176740        INC     ENDFLG      ;COUNT UNITS RUNNING
536 003054* 062705 000010        ADD     #10,R5
537 003060* 000406              BR      2$
538 003062* 062701 000014      1$: ADD     #14,R1
539 003066* 062700 000010        ADD     #10,R0
540 003072* 062705 000010        ADD     #10,R5
541 003076* 006367 176672      2$: ASL     SELMSK      ;NEXT UNIT
542 003102* 026727 176666 000020 CMP     SELMSK,#20   ;DONE?
543 003110* 002630              BLT     NXTDEV      ;NO- LOOP
544 003112* 016767 176700 176700 MOV     TIME,TIMER
545 003120* 005067 176676        CLR     TIME1       ;YES- DELAY
546 003124*              3$:
547 003124* 104407 000000*      BREAK$,BEGIN        ;TEMPORARY RETURN TO MONITOR....
548 003130* 104407 000000*      BREAK$,BEGIN        ;THEN CONTINUE AT NEXT INSTRUCTION.
549 003134* 005767 176654        TST     ENDFLG      ;DJ11'S DONE?
550 003140* 001004              BNE     4$          ;NO- BRANCH
551 003142* 104413 000000*      ENDITS$,BEGIN      ;SIGNAL END OF ITERATION.
552                                     ;MONITOR SHALL TEST END OF PASS
553 003146* 000167 177266        JMP     RESTRT      ;NEXT ITERATION ;DRB001
554 003152* 005367 176644      4$: DEC     TIME1      ;COUNT TIMER
```



```

555 003156* 001362          BNE      3$                ;TO CATCH
556 003160* 005367 176634  DEC      TIMER            ;HUNG DJ11'S
557 003164* 001357          BNE      3$
558 003166* 104403 000000* 004426* MSGNS$,BEGIN,HUNG      ;ASCII MESSAGE CALL WITH COMMON HEADER
559 003174* 016705 174606  MOV      ADDR,R5
560 003200* 012767 000001 176566  MOV      #1,SELMSK
561 003206* 036767 176562 176562 5$:  BIT      SELMSK,SELECT
562 003214* 001401          BEQ      6$                ;BRANCH IF NOT SELECTED
563 003216* 005015          CLR      @R5              ;IF SELECTED CLEAR THE CSR
564 003220* 062705 000010 6$:  ADD      #10,R5          ;NEXT CSR ADDRESS
565 003224* 006367 176544  ASL      SELMSK          ;NEXT UNIT SELECT BIT
566 003230* 026727 176540 000020  CMP      SELMSK,#20      ;ALL UNITS CHECKED?
567 003236* 002763          BLT      5$                ;BRANCH IF NOT
568 003240* 104410 000000*  ENDS$.BEGIN          ;DJ11 HUNG
569
570          ;ROUTINE TO HANDLE TRANSMITTER INTERRUPTS
571 003244* 010246  XMTINT: MOV      R2,-(SP)          ;SAVE REG 2 ON STACK
572 003246* 011502          MOV      (R5),R2          ;GET OFFSET INTO R2
573 003250* 066702 174532  ADD      ADDR,R2          ;FORM DEVICE ADDRESS
574 003254* 042712 040000  BIC      #040000,(R2)    ;TURN OFF XMT INT ENABLE WHILE YOU SERVICE
575 003260* 011577 176476  MOV      (R5),@XPNTW      ;SAVE OFFSET IN QUEUE
576 003264* 062767 000002 176470  ADD      #2,XPNTW        ;INCREMENT IN POINTER
577 003272* 026727 176464 001626*  CMP      XPNTW,#XQ+10    ;TIME TO WRAP?
578 003300* 001003          BNE      1$                ;NO
579 003302* 012767 001616* 176452  MOV      #XQ,XPNTW        ;YES
580 003310* 012602 1$:  MOV      (SP)+,R2          ;RESTORE R2
581 003312* 012605          MOV      (SP)+,R5          ;RESTORE R5
582
583 003314* 000004 000000* 003322*  PIRQ$,BEGIN,XMTRTN      ; QUEUE UP TO CONTINUE AT XMTRTN AND RTI
584
585
586 003322* 017703 176436  XMTRTN: MOV      @XPNTW,R3          ;GET OFFSET
587 003326* 062767 000002 176430  ADD      #2,XPNTW        ;INCREMENT OUT POINTER
588 003334* 026727 176424 001626*  CMP      XPNTW,#XQ+10    ;TIME TO WRAP?
589 003342* 001003          BNE      1$                ;NO
590 003344* 012767 001616* 176412  MOV      #XQ,XPNTW        ;YES
591 003352* 010302 1$:  MOV      R3,R2          ;GET READY- COPY OFFSET
592 003354* 066702 174426  ADD      ADDR,R2          ;TO FORM DEVICE ADDRESS
593 003360* 005712          TST      (R2)            ;XMT READY BIT SET?
594 003362* 100422          BMI      XMTOK          ;BR IF OK
595 003364* 010267 174510  MOV      R2,CSRA          ;STORE COMMAND REGISTER ADDRESS
596 003370* 011267 174506  MOV      (R2),ACSR        ;STORE CONTENTS OF COMMAND REGISTER
597 003374* 012767 000011 174504  MOV      #11,ERRRYP      ;ILLEGAL INTERRUPT
598
599 003402* 104405 000000* 000000  HRDRS$,BEGIN,NULL      ;XMIT READY NOT SET ON XMIT INTERRUPT
600
601 003410* 016767 176402 176402  MOV      TIME,TIMER      ;RESET TIMER DUE TO MESSAGE PRINTOUT DELAY
602 003416* 052777 040000 174454  BIS      #040000,@CSRA    ;BETTER REENABLE TRANSMITTERS
603 003424* 104400 000000*  EXITS$,BEGIN          ;EXIT TO MONITOR. MODULE WAIT FOR INTERRUPT.
604
605 003430* 010300  XMTOK: MOV      R3,R0          ;PREPARE A ONE WORD OFFSET
606 003432* 006200          ASR      R0              ;BEGIN THE OFFSET WITH ONE SHIFT
607 003434* 006200          ASR      R0              ;COMPLETE THE OFFSET WITH 2ND SHIFT
608 003436* 006303          ASL      R3              ;OFFSET OF 20 TIMES UNIT #
609 003440* 116204 000007  MORXMT: MOV      7(R2),R4      ;PUT LINE # IN R4
610 003444* 042704 177760  BIC      #177760,R4      ;PURGE LEFTOVER DATA FROM R4

```

```

611 003450* 060304          ADD      R3,R4          ;FORM UNIQUE LINE/CHAR OFFSET
612 003452* 116467 000306* 176346  MOVB     XMTTBL(R4),CHAR ;--TEMP HLD CHAR
613 003460* 146767 176340 176340  BICB     MASK,CHAR      ;--FOR MASKING
614 003466* 116762 176334 000006  MOVB     CHAR,6(R2)     ;--TRANSMIT CHARACTER
615 003474* 105264 000306*      INCB     XMTTBL(R4)     ;ADVANCE TO NEXT CHARACTER
616 003500* 001016      BNE      DECCNT        ;AVOID NEXT SECTION OF CODE
617                                ;IF SENT CHARS NOT WRAPPED TO ZERO
618 003502* 012701 000001      MOV      #1,R1          ;BIT POSITION OF THE ONE IS SAME AS XMT LINE #
619 003506* 042704 177760      BIC      #177760,R4     ;LEAVE ONLY LINE # IN R4
620 003512* 001403      BEQ      LINOFF        ;LINE 0 IS DONE,TURN IT OFF
621 003514* 006301      1$:     ASL      R1          ;SHIFT XMT BIT TO NEXT XMTTER LINE POSITION
622 003516* 005304      DEC      R4          ;DECREMENT ACTUAL LINE NUMBER
623 003520* 001375      BNE      1$           ;BRANCH BACK IF NOT DONE
624 003522* 040160 001742*     LINOFF: BIC      R1,XMITEN(R0) ;TURN OFF THE INDIVIDUAL XMTTER LINE
625 003526* 001003      BNE      DECCNT        ;ARE ALL LINES DONE NOW?
626 003530* 016060 001732* 001742*  MOV      XMTSEL(R0),XMITEN(R0) ;IF YES, RESET ENABLE WORD
627 003536* 005360 001702*     DECCNT: DEC      XCNT(R0)   ;DECREMENT CHARACTER COUNT
628 003542* 003403      BLE      OFF          ;HAVE YOU SENT 65? BR IF YES
629 003544* 005712      TST      (R2)         ;ADDITIONAL XMTTRS READY
630 003546* 100734      BMI      MORXMT       ;BR IF YES
631 003550* 000407      BR      XMTOUT        ;GO OUT AND WAIT FOR ANOTHER LINE TO INT
632 003552* 005062 000004      OFF:   CLR      4(R2)   ;TURN OFF XMTTER
633 003556* 016760 176222 001702*  MOV      CNTSEL,XCNT(R0) ;RESET CHAR COUNT
634 003564* 104400 000000*     EXIT$,BEGIN ;EXIT TO MONITOR. MODULE WAIT FOR INTERRUPT.
635 003570* 052712 040000     XMTOUT: BIS      #040000,(R2) ;ENABLE MORE XMITR INTERRUPTS
636 003574* 104400 000000*     EXIT$,BEGIN ;EXIT TO MONITOR. MODULE WAIT FOR INTERRUPT.
637
638                                ;ROUTINE TO HANDLE RECEIVER INTERRUPTS
639 003600* 010246     RCVINT: MOV      R2,-(SP)   ;SAVE R2 ON STACK
640 003602* 011502      MOV      (R5),R2      ;GET OFFSET
641 003604* 066702 174176      ADD      ADDR,R2      ;FORM DEVICE ADDRESS
642 003610* 042712 010000      BIC      #010000,(R2)  ;TURN OFF INTERRUPTS
643 003614* 011577 176146      MOV      (R5),@RPNTW   ;SAVE OFFSET IN QUEUE
644 003620* 062767 000002 176140  ADD      #2,RPNTW      ;INCREMENT WRITE POINTER
645 003626* 026727 176134 001636*  CMP      RPNTW,#RQ+10 ;TIME TO WRAP?
646 003634* 001003      BNE      1$           ;NO
647 003636* 012767 001626* 176122  MOV      #RQ,RPNTW     ;YES
648 003644* 012602      1$:     MOV      (SP)+,R2    ;RESTORE R2
649 003646* 012605      MOV      (SP)+,R5     ;RESTORE R5
650
651 003650* 000004 000000* 003656*  PIRQ$,BEGIN,RCVRTN ; QUEUE UP TO CONTINUE AT RCVRTN AND RTI
652
653                                ;-----
654 003656* 017703 176106     RCVRTN: MOV      @RPNTR,R3 ;GET OFFSET
655 003662* 062767 000002 176100  ADD      #2,RPNTR      ;INCREMENT READ POINTER
656 003670* 026727 176074 001636*  CMP      RPNTR,#RQ+10 ;TIME TO WRAP?
657 003676* 001003      BNE      1$           ;NO
658 003700* 012767 001626* 176062  MOV      #RQ,RPNTR     ;YES
659 003706* 010300      1$:     MOV      R3,RC      ;GET OFFSET AGAIN
660 003710* 006200      ASR      R0          ;FORM A ONE WORD
661 003712* 006200      ASR      R0          ;INDEX
662 003714* 010302     PASSED: MOV      R3,R2   ;GET READY
663 003716* 065702 174064      ADD      ADDR,R2      ;TO FORM DEVICE ADDRESS
664 003722* 032712 020000      BIT      #020000,(R2) ;SEE IF BUFFER SILO FULL SET
665 003726* 001022      BNE      CONT1       ;CONTINUE IF OK
666 003730* 010267 174144      MOV      R2,CSRA      ;STORE COMMAND REGISTER ADDRESS

```



```

667 003734* 011267 174142      MOV      (R2),ACSR      ;STORE CONTENTS OF COMMAND REGISTER
668 003740* 012767 000011 174140  MOV      #11,ERRTYP    ;ILLEGAL INTERRUPT
669                                     ;*****
670 003746* 104405 000000* 000000  HRDR$,BEGIN,NULL      ;FALSE INTERRUPT
671                                     ;*****
672 003754* 016767 176036 176036  MOV      TIME,TIMER    ;RESET TIMER DUE TO MESSAGE PRINTOUT DELAY
673 003762* 052777 010000 174110  BIS      #010000,@CSRA ;BETTER ENABLE RECEIVER BEFORE LEAVING
674 003770* 104400 000000*      EXITS$,BEGIN          ;EXIT TO MONITOR. MODULE WAIT FOR INTERRUPT.
675
676 003774* 010304      CONT1: MOV      R3,R4      ;BEGIN TO FORM
677 003776* 006304      ASL      R4            ;A NEW OFFSET
678 004000* 006304      ASL      R4            ;INTO EXPECTED RECEIVE DATA TABLE
679 004002* 010405      MOV      R4,R5        ;BETTER SAVE IT
680 004004* 006304      ASL      R4            ;SO YOU CAN FORM A SILO OFFSET
681 004006* 006304      ASL      R4
682 004010* 060004      ADD      R0,R4        ;OFFSET = 202(OCTAL) TIMES UNIT#
683 004012* 062704 000606*      ADD      #SILO,R4    ;FORM SILO BASE OFFSET
684 004016* 010401      MOV      R4,R1        ;REMEMBER FIRST SILO WORD ADDRESS
685 004020* 016224 000002      NOTDUN: MOV     2(R2),(R4)+ ;MOVE DATA FROM DJ TO SILO BUFFER
686 004024* 005360 001712*      DEC      RCNT(R0)    ;DECREMENT # OF CHARACTERS RECEIVED
687 004030* 003373      BGT      NOTDUN      ;BR IF NOT RECEIVED 65 YET
688 004032* 016760 175746 001712*  MOV     CNTSEL,RCNT(R0) ;RESET RECEIVE COUNT
689 004040* 062705 000406*      ADD      #RCVTBL,R5  ;FORM OFFSET INTO EXP RECV DATA TABLE
690 004044* 010567 175722      MOV      R5,I        ;SAVE IT IN 'I' AS AN INDEX
691                                     ;(RCVTBL BASE ADDRESS FOR THIS UNIT)
692 004050* 116105 000001      NXTCHR: MOV     1(R1),R5 ;GET LINE NUMBER FROM DATA WORD
693 004054* 042705 177760      BIC      #177760,R5   ;MASK SO HAVE ONLY LINE #
694 004060* 006305      ASL      R5            ;MAKE LINE# EVEN WORD BOUNDARY
695 004062* 066705 175704      ADD      I,R5        ;FORM EXPECTED DATA ADDRESS
696 004066* 011567 175734      MOV      (R5),CHAR    ;-TEMP HLDING FOR BIT SIZING
697 004072* 146767 175726 175726  BICB     MASK,CHAR     ;-CHECK ONLY STRAPPED BITS
698 004100* 026721 175722      CMP      CHAR,(R1)+   ;-COMPARE EXPECTED VS ACTUAL DATA
699 004104* 001066      BNE      DATERR      ;BR IF BAD DATA
700 004106* 105215      DONE:  INCB     (R5)    ;INCREMENT EXPECTED DATA
701 004110* 020104      CMP      R1,R4        ;HAVE YOU FINISHED ENTIRE BUFFER?
702 004112* 103756      BLO      NXTCHR      ;GO BACK IF NOT
703 004114* 005360 001722*      DEC      ENDCNT(R0)
704 004120* 003011      BGT      1$          ;
705 004122* 012760 000001 001722*  MOV     #1,ENDCNT(R0) ;
706 004130* 042712 050405      BIC      #050405,(R2) ;TURN OFF DJ11 ;MK001
707 004134* 005367 175654      DEC      ENDFLG
708 004140* 104400 000000*      EXITS$,BEGIN        ;EXIT TO MONITOR. MODULE WAIT FOR INTERRUPT.
709 004144* 010205      1$:  MOV      R2,R5        ;COPY CSR ADDRESS TO R5
710 004146* 004767 000024      JSR      PC,TBLSNC   ;SYNCH RCV AND XMT TABLES
711 004152* 052712 050000      BIS      #50000,(R2) ;NO- ENABLE SILO FULL INT AND XMTR INT
712 004156* 016062 001742* 000004  MOV     XMITEN(R0),4(R2) ;TURN XMITTERS BACK ON
713 004164* 016060 001742* 001752*  MOV     XMITEN(R0),XMITSV(R0) ;SAVE INDICATOR OF LINES ACTIVATED
714 004172* 104400 000000*      EXITS$,BEGIN        ;EXIT TO MONITOR. MODULE WAIT FOR INTERRUPT.
715
716                                     ;SYNCHRONIZE RECEIVER AND TRANSMITTER TABLES FOR ONE UNIT
717                                     ;WHOSE CSR ADDRESS IS IN R5
718 004176* 010546      TBLSNC: MOV     R5,-(SP) ;CSR ADDRESS
719 004200* 166716 173602      SUB     ADDR,(SP)
720 004204* 006316      ASL     (SP)          ;GET OFFSET (UNIT # TIMES 20 OCTAL)
721 004206* 011646      MOV     (SP),-(SP)    ;COPY OFFSET
722 004210* 006316      ASL     (SP)          ;OFFSET INTO RCV TABLE (UNIT # TIMES 40)

```

```
723 004212' 062716 000406' ADD #RCVTBL,(SP)
724 004216' 062766 000306' 000002 ADD #XMTTBL,2(SP)
725 004224' 012746 000020 MOV #16,-(SP) ;COUNTER
726 004230' 117676 000004 000002 1$: MOVB @4(SP),@2(SP) ;MOVE XMIT TABLE CONTENTS INTO DATA
727 ;PORTION OF RCV TABLE
728
729 004236' 005266 000004 INC 4(SP)
730 004242' 062766 000002 000002 ADD #2,2(SP)
731 004250' 005316 DEC (SP)
732 004252' 001366 BNE 1$
733 004254' 022626 CMP (SP)+,(SP)+ ;FIX SP
734 004256' 005726 TST (SP)+
735 004260' 000207 RTS PC
736
737 ;ERROR HANDLER FOR DATA ERRORS
738 004262' 010267 173612 DATERR: MOV R2,CSRA ;STORE COMMAND REGISTER ADDRESS
739 004266' 010567 173610 MOV R5,SBADR ;STORE ADDRESS OF TEST DATA
740 004272' 005741 TST -(R1) ;RESET R1 BACK TO THE ADDRESS OF THE FAIL DATA
741 004274' 010167 173604 MOV R1,WASADR ;STORE ADDRESS OF XMITTED DATA
742 004300' 011567 173602 MOV (R5),ASB ;STORE EXPECTED RECEIVE DATA
743 004304' 012167 173600 MOV (R1)+,AWAS ;STORE ACTUAL RECEIVED DATA AND RESET R1 TO RIGH
744 004310' 016702 175362 MOV ERRQ1,R2
745 004314' 146767 175504 173564 BICB MASK,ASB ;-MASK OUT STRAPPED OFF BITS
746 004322' 010022 MOV R0,(R2)+
747 004324' 010122 MOV R1,(R2)+
748 004326' 010422 MOV R4,(R2)+
749 004330' 010522 MOV R5,(R2)+
750 004332' 020227 001676' CMP R2,#ERRQ+32.
751 004336' 103402 BLO 1$
752 004340' 012702 001636' MOV #ERRQ,R2
753 004344' 010267 175326 1$: MOV R2,ERRQ1
754 ;*****
755 004350' 104404 000000' DATERR$,BGIN ;DATA ERROR!!!
756 ;*****
757 004354' 016767 175436 175436 MOV TIME,TIMER ;RESET TIMER DUE TO PRINTOUT DELAY
758 004362' 016702 175312 MOV ERRQ0,R2
759 004366' 012200 MOV (R2)+,R0
760 004370' 012201 MOV (R2)+,R1
761 004372' 012204 MOV (R2)+,R4
762 004374' 012205 MOV (R2)+,R5
763 004376' 020227 001676' CMP R2,#ERRQ+32.
764 004402' 103402 BLO 2$
765 004404' 012702 001636' MOV #ERRQ,R2
766 004410' 010267 175264 2$: MOV R2,ERRQ0
767 004414' 016702 173460 MOV CSRA,R2
768 004420' 000632 BR DONE ;NOW CONTINUE CHECKING DATA
769
770 004422' 004432' DROPM: DROP
771 004424' 177777 -1
772 004426' 004447' HUNGM: HUNG
773 004430' 177777 -1
774
775 004432' 047125 052111 042040 DROP: .ASCIZ /UNIT DROPPED/
776 004440' 047522 050120 042105
777 004446' 000
778 004447' 125 044516 020124 HUNG: .ASCIZ /UNIT HUNG/
```



|     |         |        |        |        |
|-----|---------|--------|--------|--------|
| 779 | 004454' | 052510 | 043516 | 000    |
| 780 | 004461' | 045    | 045104 | 020101 |
| 781 | 004466' | 047515 | 052504 | 042514 |
| 782 | 004474' | 020072 | 042526 | 052103 |
| 783 | 004502' | 051117 | 025440 | 040440 |
| 784 | 004510' | 042104 | 020122 | 046040 |
| 785 | 004516' | 041517 | 027123 | 044040 |
| 786 | 004524' | 053101 | 020105 | 047516 |
| 787 | 004532' | 020124 | 042502 | 047105 |
| 788 | 004540' | 046040 | 040517 | 042504 |
| 789 | 004546' | 027104 | 000045 |        |
| 790 |         |        |        |        |
| 791 | 000001  |        |        |        |

NOVEC: .ASCIZ /%DJA MODULE: VECTOR + ADDR LOCS. HAVE NOT BEEN LOADED.%/

.EVEN  
.END

|         |         |      |      |      |      |      |      |      |      |      |     |     |     |     |  |
|---------|---------|------|------|------|------|------|------|------|------|------|-----|-----|-----|-----|--|
| ACSR    | 000102R | 263# | 510* | 596* | 667* |      |      |      |      |      |     |     |     |     |  |
| ADDR    | 000006R | 229# | 480  | 529  | 559  | 573  | 592  | 641  | 663  | 719  |     |     |     |     |  |
| ADDR22= | 001000  | 281# |      |      |      |      |      |      |      |      |     |     |     |     |  |
| APTPRE= | 000200  | 281# |      |      |      |      |      |      |      |      |     |     |     |     |  |
| ASB     | 000106R | 267# | 742* | 745* |      |      |      |      |      |      |     |     |     |     |  |
| ASTAT   | 000104R | 265# |      |      |      |      |      |      |      |      |     |     |     |     |  |
| AUTO =  | 000010  | 281# |      |      |      |      |      |      |      |      |     |     |     |     |  |
| AWAS    | 000110R | 268# | 743* |      |      |      |      |      |      |      |     |     |     |     |  |
| BEGIN   | 000000R | 226# | 440  | 469  | 483  | 484  | 501  | 502  | 514  | 516  | 521 | 547 | 548 | 551 |  |
|         |         | 558  | 568  | 583  | 599  | 603  | 634  | 636  | 651  | 670  | 674 | 708 | 714 | 755 |  |
| BIT0 =  | 000001  | 281# |      |      |      |      |      |      |      |      |     |     |     |     |  |
| BIT1 =  | 000002  | 281# |      |      |      |      |      |      |      |      |     |     |     |     |  |
| BIT10 = | 002000  | 281# |      |      |      |      |      |      |      |      |     |     |     |     |  |
| BIT11 = | 004000  | 281# |      |      |      |      |      |      |      |      |     |     |     |     |  |
| BIT12 = | 010000  | 281# |      |      |      |      |      |      |      |      |     |     |     |     |  |
| BIT13 = | 020000  | 281# |      |      |      |      |      |      |      |      |     |     |     |     |  |
| BIT14 = | 040000  | 281# |      |      |      |      |      |      |      |      |     |     |     |     |  |
| BIT15 = | 100000  | 281# |      |      |      |      |      |      |      |      |     |     |     |     |  |
| BIT2 =  | 000004  | 281# |      |      |      |      |      |      |      |      |     |     |     |     |  |
| BIT3 =  | 000010  | 281# |      |      |      |      |      |      |      |      |     |     |     |     |  |
| BIT4 =  | 000020  | 281# |      |      |      |      |      |      |      |      |     |     |     |     |  |
| BIT5 =  | 000040  | 281# |      |      |      |      |      |      |      |      |     |     |     |     |  |
| BIT6 =  | 000100  | 281# |      |      |      |      |      |      |      |      |     |     |     |     |  |
| BIT7 =  | 000200  | 281# |      |      |      |      |      |      |      |      |     |     |     |     |  |
| BIT8 =  | 000400  | 281# |      |      |      |      |      |      |      |      |     |     |     |     |  |
| BIT9 =  | 001000  | 281# |      |      |      |      |      |      |      |      |     |     |     |     |  |
| BREAKS= | 104407  | 281# | 501  | 502  | 547  | 548  |      |      |      |      |     |     |     |     |  |
| BR1     | 000012R | 231# | 489  | 493  |      |      |      |      |      |      |     |     |     |     |  |
| BR2     | 000013R | 232# |      |      |      |      |      |      |      |      |     |     |     |     |  |
| BTODS = | 104421  | 281# |      |      |      |      |      |      |      |      |     |     |     |     |  |
| CAPRES= | 000004  | 281# |      |      |      |      |      |      |      |      |     |     |     |     |  |
| CDATAS= | 104412  | 281# |      |      |      |      |      |      |      |      |     |     |     |     |  |
| CHAR    | 002026R | 378# | 455* | 460* | 463  | 612* | 613* | 614  | 696* | 697* | 698 |     |     |     |  |
| CKHNGS= | 000001  | 281# |      |      |      |      |      |      |      |      |     |     |     |     |  |
| CLKPRE= | 000001  | 281# |      |      |      |      |      |      |      |      |     |     |     |     |  |
| CLKSPS= | 104422  | 281# |      |      |      |      |      |      |      |      |     |     |     |     |  |
| CNTSEL  | 002004R | 368# | 424  | 425  | 633  | 688  |      |      |      |      |     |     |     |     |  |
| CONFIG  | 000056R | 251# |      |      |      |      |      |      |      |      |     |     |     |     |  |
| CONT1   | 003774R | 665  | 676# |      |      |      |      |      |      |      |     |     |     |     |  |
| CSRA    | 000100R | 261# | 509* | 595* | 602* | 666* | 673* | 738* | 767  |      |     |     |     |     |  |
| DATCKS= | 104411  | 281# |      |      |      |      |      |      |      |      |     |     |     |     |  |
| DATERR  | 004262R | 699  | 738# |      |      |      |      |      |      |      |     |     |     |     |  |
| DATERS= | 104404  | 281# | 755  |      |      |      |      |      |      |      |     |     |     |     |  |
| DECCNT  | 003536R | 616  | 625  | 627# |      |      |      |      |      |      |     |     |     |     |  |
| DJLINK  | 000226R | 294# | 477  |      |      |      |      |      |      |      |     |     |     |     |  |
| DONE    | 004106R | 700# | 768  |      |      |      |      |      |      |      |     |     |     |     |  |
| DROP    | 004432R | 770  | 775# |      |      |      |      |      |      |      |     |     |     |     |  |
| DROPM   | 004422R | 516  | 770# |      |      |      |      |      |      |      |     |     |     |     |  |
| DVID1   | 000014R | 233# | 402  | 417  | 438  |      |      |      |      |      |     |     |     |     |  |
| ECCMEM= | 000100  | 281# |      |      |      |      |      |      |      |      |     |     |     |     |  |
| ENDCNT  | 001722R | 337# | 426* | 703* | 705* |      |      |      |      |      |     |     |     |     |  |
| ENDFLG  | 002014R | 373# | 476* | 535* | 549  | 707* |      |      |      |      |     |     |     |     |  |
| ENDITS= | 104413  | 281# | 551  |      |      |      |      |      |      |      |     |     |     |     |  |
| ENDSEL  | 002002R | 367# | 416* | 420* | 432  | 443  |      |      |      |      |     |     |     |     |  |
| ENDS =  | 104410  | 281# | 440  | 469  | 484  | 521  | 568  |      |      |      |     |     |     |     |  |
| ERRQ    | 001636R | 323# | 474  | 475  | 750  | 752  | 763  | 765  |      |      |     |     |     |     |  |







|         |           |      |      |      |      |      |      |     |     |     |
|---------|-----------|------|------|------|------|------|------|-----|-----|-----|
| TIME1   | 002022R   | 376# | 545* | 554* |      |      |      |     |     |     |
| TMETBL  | 002030R   | 380# | 410  |      |      |      |      |     |     |     |
| TRPDFD= | 000023    | 281# |      |      |      |      |      |     |     |     |
| USTACK= | 000001    | 281# |      |      |      |      |      |     |     |     |
| VCT     | 002006R   | 370# | 506* | 523  |      |      |      |     |     |     |
| VECTOR  | 000010R   | 230# | 478  |      |      |      |      |     |     |     |
| WASADR  | 000104R   | 264# | 741* |      |      |      |      |     |     |     |
| WDFR    | 000116R   | 271# | 401* | 446* |      |      |      |     |     |     |
| WDTO    | 000114R   | 270# | 400* | 445* |      |      |      |     |     |     |
| XCNT    | 001702R   | 327# | 425* | 627* | 633* |      |      |     |     |     |
| XFLAG   | 000005R   | 228# |      |      |      |      |      |     |     |     |
| XMITEN  | 001742R   | 344# | 532* | 533  | 534  | 624* | 626* | 712 | 713 |     |
| XMITSV  | 001752R   | 349# | 533* | 713* |      |      |      |     |     |     |
| XMTINT  | 003244R   | 296  | 300  | 304  | 308  | 571# |      |     |     |     |
| XMTOK   | 003430R   | 594  | 605# |      |      |      |      |     |     |     |
| XMTOUT  | 003570R   | 631  | 635# |      |      |      |      |     |     |     |
| XMTRTN  | 003322R   | 583  | 586# |      |      |      |      |     |     |     |
| XMTSEL  | 001732R   | 341# | 532  | 626  |      |      |      |     |     |     |
| XMTTBL  | 000306R   | 313# | 404  | 612  | 615* | 724  |      |     |     |     |
| XPNTR   | 001764R   | 358# | 471* | 586  | 587* | 588  | 590* |     |     |     |
| XPNTW   | 001762R   | 357# | 470* | 575* | 576* | 577  | 579* |     |     |     |
| XQ      | 001616R   | 319# | 357  | 358  | 470  | 471  | 577  | 579 | 588 | 590 |
| .       | = 004552R | 313# | 315# | 317# | 319# | 321# | 323# |     |     |     |

. ABS. 000000 000  
 004552 001

ERRORS DETECTED: 0  
 DEFAULT GLOBALS GENERATED: 0

DE2:XDJALO,DE2:XDJALO.SEQ/NL:TOC/SOL/CRF/DOC=DDXCOM,XDJALO  
 RUN-TIME: 1 2 .3 SECONDS  
 RUN-TIME RATIO: 12/4=2.5  
 CORE USED: 10K (20 PAGES)

DOCUMENT PAGES: 20