

The main body of the document consists of a 10x10 grid of small, illegible data tables or charts. Each cell in the grid appears to contain a small table with multiple columns and rows of text, likely representing test results or system data. The text is too small and faded to be read accurately.

.REM 2

IDENTIFICATION

PRODUCT CODE: AC-F238B-MC  
PRODUCT NAME: CVKDABO PDT11/150 SYSTEM EXERCISER  
PRODUCT DATE: NOV 1978  
MAINTAINER: DIAGNOSTIC ENGINEERING

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS DOCUMENT.

NO RESPONSIBILITY IS ASSUMED FOR THE USE OR RELIABILITY OF SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL OR ITS AFFILIATED COMPANIES.

COPYRIGHT (C) 1978, 1979 BY DIGITAL EQUIPMENT CORPORATION

THE FOLLOWING ARE TRADEMARKS OF DIGITAL EQUIPMENT CORPORATION:

DIGITAL	FDP	UNIBUS	MASSBUS
DEC	DECUS	DECTAPE	

TABLE OF CONTENTS

1.0	GENERAL PROGRAM INFORMATION.
1.1	PROGRAM PURPOSE (ABSTRACT).
1.2	SYSTEM REQUIREMENTS.
1.3	RELATED DOCUMENTS AND STANDARDS.
1.4	DIAGNOSTIC HIERARCHY PREREQUISITES.
1.5	ASSUMPTIONS.
1.6	RUNNING SYSTEMS PROGRAMS.
2.0	OPERATING INSTRUCTIONS.
2.1	LOADING AND STARTING PROCEDURES.
2.2	SPECIAL ENVIRONMENTS.
2.3	OPERATIONAL SWITCH SETTINGS
2.4	PROGRAM OPTIONS.
2.5	EXECUTION TIMES.
2.6	POWER FAIL.
2.7	COMPATABILITY TESTING.
2.8	COPY UTILITY.
3.0	ERROR INFORMATION.
3.1	ERROR REPORTING PROCEDURE.
3.2	ERROR HALTS.
4.0	PROGRESS & PERFORMANCE REPORTS.
5.0	DEVICE INFORMATION TABLES.
6.0	DEVICE CONNECTOR LAYOUT.
7.0	SUMMARY OF TESTS.

1.0      GENERAL PROGRAM INFORMATION.  
-----

1.1      PROGRAM PURPOSE (ABSTRACT).

THE PDT-11/150 SYSTEM EXERCISER TESTS THE PROCESSORS ABILITY TO OPERATE ALL ITS PERIPHERALS IN INTERRUPT MODE AT THE SAME TIME WITH EMPHASIS ON THE DISK SUBSYSTEMS.

IT SHOULD BE NOTED THAT IT IS NOT A DIAGNOSTIC OF THE PERIPHERALS BUT A SERIES OF SYSTEM INTERACTION TESTS.

THE PROGRAM IS DEFAULTED TO EXERCISE THE CLUSTER TERMINALS & THE COMM PORT IN INTERNAL LOOPBACK (MAINT) MODE .  
THE DEFAULT CAN BE CHANGED TO EXERCISE ANY OF THE CLUSTER TERMINALS AND/OR THE COMM PORT IN EXTERNAL LOOPBACK.  
SEE PROGRAM OPTIONS SEC. 2.4.

TESTING OF THE ACTUAL CLUSTER TERMINALS OR COMM DEVICE IS NOT PERFORMED. THESE DEVICES CAN ONLY BE TESTED EITHER IN EXT. OR INT. LOOPBACK.

THE PRINTER LOGIC WILL BE EXERCISED IF SIZING DETERMINES IT TO BE PRESENT OR IF DATA TERM RDY IS ASSERTED ON ITS CONNECTOR.

THE CONSOLE TERMINAL IS NOT TESTED.

AFTER THE MEMORY HAS BEEN TESTED & ALL THE PERIPHERALS ARE BEING EXERCISED & INTERRUPTING AT RANDOM, THE DISK SUBSYSTEM TESTS WILL BEGIN.  
SEE TEST SUMMARY SEC. 7.0.

NOTE: IF RUNNING UNDER APT, THE SYNC COMM LOGIC WILL BE TESTED ONLY ON THE 1<sup>ST</sup> PASS. THIS IS SO APT 'BREAKS' SO NOT CAUSE FALSE SYNC COMM ERRORS.

THE PROGRAM CONTAINS A UTILITY WHICH CAN COPY THE SYSTEM EXERCISER DISK FROM DX0 ONTO A SCRATCH DISK IN DX1.  
THIS ENABLES THE OPERATOR TO CREATE BACKUP COPIES OF THE EXERCISER DISK.  
SEE SECTION 2.8.

THE PROGRAM ALSO CONTAINS A COMPATABILITY TESTING OPTION.  
SEE SEC. 2.7.

## 1.2 SYSTEM REQUIREMENTS.

### HARDWARE REQUIREMENTS:

PDT-11/150 SYSTEM  
8K MEMORY - MINIMUM  
CONSOLE TERMINAL  
EXTERNAL LOOPBACK CONNECTORS (OPTIONAL) FOR COMM & CLUSTER TERMINAL PORTS.  
(SEE PROGRAM OPTIONS SEC. 2.4.)  
VT-100 CONSOLE MUST BE SETUP FOR JUMP SCROLL.

### SOFTWARE REQUIREMENTS:

THIS EXERCISER IS DESIGNED TO RUN IN ANY OF THE FOLLOWING WAYS:

STAND ALONE  
WITH APT MONITOR  
WITH RT-11 MONITOR

IT IS NOT DESIGNED TO RUN WITH THE DIAGNOSTIC SUPERVISOR.

## 1.3 RELATED DOCUMENTS AND STANDARDS.

DIAGNOSTIC ENGINEERING STANDARDS AND CONVENTIONS	175-003-009-02
APT	MD-11-DZZMA
SYSMAC	MD-11-DZQAC

## 1.4 DIAGNOSTIC HIERARCHY PREREQUISITES

THIS EXERCISER ASSUMES THAT THE POWER UP SELF TEST RUNS ERROR FREE.

## 1.5 ASSUMPTIONS

THIS EXERCISER ASSUMES THAT THE OPERATOR HAS MODIFIED THE DEVICE MAP (\$DEVN) AT LOC. 1246 IF THE DEFAULTS DO NOT AGREE WITH THE ACTUAL SYSTEM CONFIGURATION. SEE PROGRAM OPTIONS SEC. 2.4.  
THE PROGRAM ALSO ASSUMES THE SOFTWARE SWITCH REGISTER IS PROPERLY SET UP (SWREG) AT LOC. 176. SEE SEC. 2.3.

## 1.6 RUNNING SYSTEMS PROGRAMS

UNLESS THE SYSTEMS PROGRAMS ARE KNOWN TO INITIALIZE THE BAUD RATES OF EACH DEVICE THRU THE PARAMETER REGISTER, THE OPERATOR SHOULD POWER DOWN & UP AGAIN WHEN FINISHED RUNNING THIS EXERCISER. THIS IS TO RESTORE THE PDT-11/150 TO ITS DEFAULT BAUD RATES. OTHERWISE, THE DEVICES WILL ATTEMPT TO RUN AT WHATEVER BAUD RATES WERE LAST USED BY THIS EXERCISER.

2.0 OPERATING INSTRUCTIONS.

2.1 LOADING AND STARTING PROCEDURES.

USE STANDARD PROCEDURE FOR PDP-11 ABSOLUTE BINARY FORMATTED PAPER TAPE.  
THE PROGRAM WILL AUTO-START AFTER LOADING.

THE SYSTEM EXERCISER DISK WILL AUTO-START AFTER BOOTING.

EXAMPLE OF STARTUP ASSUMING PRINTER NOT PRESENT, 24K MEMORY,  
& TERM #2 NOT TO BE TESTED, COMM PORT EXT. LOOPBACK, TERM 1 & 3 INT. LOOPBACK.  
(20007 IN \$DEVN, SEE SEC. 1.5):

CVKDAB PDT-11/150 SYSTEM EXERCISER

SWR = 000000 NEW = 110000 <CR> (HALT ON ERR, ENABLE PERFORMANCE REPORTS)

DEVN = 000017 NEW - <CR> (KEEP DEFAULTS)

24K MEMORY PRESENT  
PRINTER NOT PRESENT  
TERM #2 TESTING DROPPED

INSERT SCRATCH DISKS, TYPE 'P' FOR NORMAL TESTING  
'240G' FOR NORMAL RESTARTS  
'250G' TO COPY SYS EXERCISER DISK  
'260G' FOR COMPATABILITY PASS 1: WRITE  
'270G' FOR PASS 2: READ

(PROGRAM HALTS & WAITS FOR 'P' & CONTINUES....ABOVE NOTE & HALT OMITTED UNDER APT)

THE PROGRAM WILL BEGIN ACTUAL TESTING AT THIS POINT. (SEE SUMMARY OF TESTS SEC. 7.0)

DURING THE TESTS, THE PROGRAM WILL PRINT PROGRESS REPORTS (SEE SEC. 4.1) IF  
BIT 12 IS SET IN THE SWREG (SEE SEC 2.3).  
END OF PASS & TOTAL ERROR COUNT IS PRINTED AT THE CONCLUSION OF TESTING.  
THE PROGRAM JUMPS TO THE BEGINNING & THE ABOVE SEQUENCE IS REPEATED UNTIL HALTED.

## 2.2 SPECIAL ENVIRONMENTS.

THIS DIAGNOSTIC FOLLOWS THE STANDARD PROCEDURE FOR RUNNING UNDER APT, RT-11 MONITORS, AS DESCRIBED IN THEIR RESPECTIVE PROCEDURES MANUAL AND SYSMAC PACKAGE.

## 2.3 OPERATIONAL SWITCH SETTINGS

THIS PROGRAM SUPPORTS THE DYNAMIC LOADING OF THE SOFTWARE SWITCH REGISTER (SWREG AT LOC. 176) FROM THE CONSOLE. THIS CAN BE ACCOMPLISHED BY DOING THE FOLLOWING:

- 1) TYPE CONTROL G <^G>; THIS WILL ALLOW THE CONSOLE TO ENTER DATA INTO LOC. 176 AT SELECTED POINTS WITHIN THE PROGRAM.
- 2) THE MACHINE WILL THEN TYPE: ' SWR=XXXXXX NEW=' (XXXXXX IS THE OCTAL CONTENTS OF THE SOFTWARE SWITCH REGISTER.)
- 3) AFTER THE 'NEW=' HAS BEEN TYPED THEN THE OPERATOR CAN DO ONE OF THE FOLLOWING AT THE CONSOLE:
  - A) TYPE A NUMBER TO BE LOADED INTO LOC. 176 FOLLOWED BY A <CR>. (ONLY NUMBERS BETWEEN 0-7 WILL BE ACCEPTED). LEADING ZEROS NEED NOT BE TYPED, AND IF MORE THAN 6 DIGITS ARE TYPED THE LAST 6 WILL BE USED. IF A <CR> IS THE FIRST KEY DEPRESSED THE SOFTWARE SWITCH REGISTER CONTENTS WILL NOT BE CHANGED.
  - B) IF A CONTROL U <^U> IS DEPRESSED THEN THE PROGRAM WILL SEND YOU BACK TO STEP 3.
  - C) IF THE INPUT CHARACTER IS NOT ONE OF THE CHARACTERS MENTIONED ABOVE THEN A QUESTION MARK (?) WILL BE TYPED FOLLOWED BY A CARRAGE RETURN AND A LINE FEED SEQUENCE THEN PROCEED FROM STEP 3 (ERASING ALL PREVIOUS INPUT).
- 4) THE DIAGNOSTIC WILL CONTINUE ON TYPING <CR>.

### SOFTWARE SWITCH REGISTER OPTIONS (SWREG)

-----

BIT 15 SET = 100000 = HALT ON ERROR  
13 SET = 20000 = INHIBIT ERROR TYPEOUTS  
12 SET = 10000 = ENABLE PERFORMANCE REPORTS  
10 SET = 2000 = BELL ON ERROR

## 2.4 PROGRAM OPTIONS.

A DEVICE MAP (\$DEVN) AT LOCATION 1246 (ENTERED BY A CONTROL-G & CONTROL-C) IS EXAMINED BY THE PROGRAM TO DETERMINE THE METHOD OF TESTING THE CLUSTER TERMINALS & THE COMM PORT.

THE DEFAULT VALUE = 000017 (INTERNAL LOOPBACK FOR COMM PORT & CLUSTER TERMINALS) IT CAN BE CHANGED TO DO THE FOLLOWING:

\$DEVN (LOC 1246) ENTERED BY CONTROL-G & C

BIT 15 SET=	100000=	DROP PRINTER TESTS	
4 SET=	40000=	DROP CLUSTER TERM #3 TESTS	
13 SET=	20000=		#2
12 SET=	10000=		#1
11 SET=	4000=	DROP ASYNC COMM TESTS	
10 SET=	2000=	DROP SYNC COMM TESTS	
9 SET=	1000=	DROP DRIVE 1 TESTS	
8 SET=	400=	DROP DRIVE 0 TESTS	
7 SET=	200=	DROP CLOCK TESTS	
BIT 3 SET=	10=	INT. LOOPBACK (MAINT MODE) FOR COMM PORT	(DEFAULT)
2 SET=	4=	INT. LOOPBACK (MAINT MODE) FOR TERM #1	(DEFAULT)
1 SET=	2=	INT. LOOPBACK (MAINT MODE) FOR #2	(DEFAULT)
0 SET	1=	INT. LOOPBACK (MAINT MODE) FOR #3	(DEFAULT)
BIT 3 CLR=		EXT. LOOPBACK FOR COMM PORT.	
BIT 2 CLR=		EXT. LOOPBACK FOR TERM #1.	
BIT 1 CLR=		EXT. LOOPBACK FOR TERM #2.	
BIT 0 CLR=		EXT. LOOPBACK FOR TERM #3.	

### NOTES:

1. THE CONSOLE IS NOT TESTED.
2. BITS 15-7 SETTINGS WILL OVERRIDE BIT 3-0 SETTINGS.
3. THE PRINTER LOGIC WILL BE TESTED IF BIT 15 = 0 & THE DATA TERM READY IS ASSERTED ON THE CONNECTOR. (A PHYSICAL PRINTER IS NOT REQ'D)
4. A VT-50,52 MAY BE USED INSTEAD OF A PRINTER FOR A VISUAL CHECK.



2.5 EXECUTION TIMES.  
-----

ASSUMING ALL DEVICES & 2 DISK SUBSYSTEMS PRESENT:

1<sup>ST</sup> PASS:

25 - 30 SEC TO STARTUP CLOCK, PRINTER, COMM DEVICE & CLUSTER TERMINALS.  
5 MIN TO WRITE, READ & DATA COMPARE ON TRACKS 0-4, 40-44, 72-76(10) ON BOTH DRIVES.  
5 - 60 SEC TO DO 10 RANDOM SEEKS ON EACH DISK BETWEEN 1<sup>ST</sup> 5 TRACKS.

SUBSEQUENT PASSES:

30 SEC TO STARTUP CLOCK, PRINTER, COMM DEVICE & CLUSTER TERMINALS.  
20 MIN TO WRITE, READ & DATA COMPARE ALL TRACKS ON BOTH DISKS.  
5 MIN TO DO 500 RANDOM SEEKS ON EACH DISK BETWEEN ALL TRACKS.

2.6 POWER FAIL  
-----

THERE IS NO POWER FAIL AUTO-RESTART CAPABILITY IN THE PDT-11.

2.7 COMPATABILITY TESTING  
-----

PASS 1: ENTERED FROM A '260G'.  
WILL WRITE ALL TRACKS & SECTORS ON SELECTED DRIVES  
& HALT AFTER AN OPERATOR PROMPT. TYPING 'P' WILL BEGIN PASS 2.

PASS 2: ENTERED BY A 'P' AFTER THE ABOVE HALT, OR A '270G'.  
WILL PERFORM SEQUENTIAL & RANDOM READS ONLY, ON THE SELECTED DRIVES.

2.8 COPY UTILITY  
-----

TO PROVIDE BACKUP DISKS, A UTILITY IS PROVIDED IN THE PROGRAM TO COPY  
THE SYSTEM EXERCISER DISK FROM DX0 TO DX1 IN THE FOLLOWING WAY:

1. BOOT THE EXERCISER NORMALLY FROM DX0.
2. ALLOW THE PROGRAM TO HALT AFTER THE WARNING MESSAGE TO USE SCRATCH DISKS.
3. AT THIS POINT, DO A '250G' TO ENTER THE COPY UTILITY.
4. THE OPERATOR WILL BE PROMPTED TO USE A SCRATCH DISK IN DX1 & TYPE 'P' TO PROCEED.
5. WHEN COMPLETED, THERE WILL BE A VERIFYING MESSAGE.  
THE OPERATOR CAN THEN DO A 'P' TO COPY ANOTHER IN THE SAME MANNER,  
OR A '240G' TO BEGIN NORMAL TESTING. (OPERATOR WILL BE PROMPTED)
6. THE COPY UTILITY CAN BE ENTERED AT ANY TIME BY DOING A 'BREAK' & '250G'.

3.0 ERROR INFORMATION.  
-----

3.1 ERROR REPORTING PROCEDURE.  
-----

TYPICAL ERROR PRINTOUTS ARE SHOWN BELOW:

TERM #3	DATA COMP	ERR	EXPECT	RECD
ERROR #	ERR PC			
000011	006516		000200	000100

DX1 SOFT ERR - DATA COMP								
DXTST #	ERR PC	RXCS	RXES	RXSA	EXPECT	RECD	#	RETRIES
000003	010636	100337	000230	003405	100520	100120		4

DX0 HARD ERR - AFTER WRITE CMD								
ERROR #	DXTST #	ERR PC	RXCS	RXES	TRACK	SECTOR	#	RETRIES
000016	000001	011246	100337	000230	59	18		10

WHERE ALL VALUES TYPED ARE OCTAL EXCEPT :  
#RETRIES, TRACK, & SECTOR WHICH ARE IN DECIMAL.

BITS 15,13, & 10 OF THE SWITCH REGISTER (SWREG) CONTROL THE SEQUENCE OF EVENTS AFTER AN ERROR IS CAUGHT.

BIT 15 SET: CAUSES THE PROGRAM TO HALT IN THE ERROR ROUTINE.  
IF THE PROGRAM IS CONTINUED, IT WILL PROCEED FROM WHERE IT HALTED.

BIT 13 SET: DISABLES THE PRINTING OF THE ERROR MESSAGE.

BIT 10 SET: CAUSES THE BELL TO RING ON ERROR.

THE ERROR ROUTINE SUPPORTS THE CONTROL G <^G> FUNCTION.  
REFER TO SECTION 2.3 FOR DETAILS.

NOTE: SINCE THERE ARE NO SPECIFIC TEST NUMBERS, APT WILL REPORT ALL ERRORS AS TEST 0 ERRORS.

3.2 ERROR HALTS.  
-----

THE ONLY HALT IN THE EXERCISER IS IN THE ERROR ROUTINE, AND IS EXECUTED ONLY IF BIT 15 OF THE SWITCH REGISTER (SWREG) IS SET WHEN AN ERROR OCCURS.

4.0 PROGRESS & PERFORMANCE REPORTS

THE FOLLOWING REPORTS ARE ENABLED BIT 12 SET IN THE SWITCH REGISTER (SWREG LOC 176)  
& WILL APPEAR FOLLOWING LOADING & STARTING AS DESCRIBED  
IN SECTION 2.1 (ASSUMING ALL DEVICES ARE TO BE TESTED & NO ERRORS):

MEM TESTS DONE (ALL MEMORY FROM LOCATION 0 TO THE BEGINNING OF THE  
MONITOR/ABS LOADER HAS BEEN TESTED.)

CLOCK RUNNING (100 INTERRUPTS HAVE BEEN DETECTED BEFORE EXERCISING THE NEXT DEVICE.  
THE CLOCK CONTINUES RUNNING IN INTERRUPT MODE.)

PRINTER RUNNING (5 LINES HAVE BEEN PRINTED WITH ERROR BIT CHECKING ONLY.  
THE PRINTER RUNS CONTINUOUSLY IN INTERRUPT MODE AT 9600 BAUD.  
ITS ACTUAL PERFORMANCE IS A VISUAL CHECK IF PRINTER CONNECTED.  
NO OTHER CHECKING PERFORMED IF EXTERNAL LOOPBACK USED.)

SYNC COMM DONE (CHARACTERS 0 THRU 377 HAVE BEEN TRANSMITTED & RECEIVED WITH ODD PARITY ENABLED.  
INTERRUPTS ARE THEN DISABLED & THE SYNC COMM IS NO LONGER EXERCISED.  
THIS IS SO THAT THE ASYNC COMM CAN BE EXERCISED  
FOR THE DURATION OF THE PASS.)

ASYNC COMM RUNNING (CHARS 0 THRU 377 HAVE BEEN TRANSMITTED & RECEIVED BEFORE  
EXERCISING THE NEXT DEVICE.  
IT CONTINUES RUNNING IN INTERRUPT MODE AT 9600 BAUD  
WITH ODD PARITY ENABLED & REPEATS THE 0 THRU 377 CYCLE)

TERM #1 RUNNING (CHARACTERS 0 THRU 377 HAVE BEEN TRANSMITTED  
& RECEIVED BEFORE EXERCISING THE NEXT DEVICE.  
THE TERMINAL KEEPS RUNNING CONTINUOUSLY AT 2400 BAUD  
IN INTERRUPT MODE & REPEATS THE 0 THRU 377 CYCLE)

TERM #2 RUNNING (SAME AS #1)  
TERM #3 RUNNING (SAME AS #1)

DX0 TRK 0 DONE (DRIVE 0, TRACK 0 IS WRITTEN WITH A DATA PATTERN, READ & DATA COMPARE PERFORMED)  
DX1 TRK 0 DONE (DRIVE 1, TRACK 0 IS WRITTEN WITH A DATA PATTERN, READ & DATA COMPARE PERFORMED)  
DX0 TRK 1 DONE (ETC)  
DX1 TRK 1 DONE (ETC UNTIL...)  
DX0 DATA PATT DONE (ALL TRACKS HAVE BEEN WRITTEN WITH A DATA PATTERN IN INTERRUPT MODE.)  
DX1 DATA PATT DONE (SAME AS DX0)  
(FOR 1'ST PASS TRACKS 0-4, 40-44, 72-76(10) DONE ONLY.)


DX0 RANDOM SEEKS DONE (500 RANDOM SEEKS WITH READ & DATA COMPARE HAVE BEEN PERFORMED ON DRIVE 0 )  
DX1 RANDOM SEEKS DONE (SAME AS DX0....10 RANDOM SEEKS ONLY FOR 1'ST PASS QUICK VERIFY)

END OF PASS #1 TOTAL ERRORS: 0  
TOTAL SOFT ERRORS: 0

TOTAL ERRORS THIS PASS: 0  
SOFT ERRORS THIS PASS: 0 (...& ENTIRE PROCESS REPEATS)


5.0 DEVICE REGISTERS.

PARAMETER REGISTER:




LINE CLOCK:

VECTOR: 100



CONSOLE: ADDR: 177560-177566 VECTOR: 60/64  
 CLUSTER #1: 176500-176506 300/304  
 #2: 176510-176516 310/314  
 #3: 176520-176526 320/324



PRINTER:

VECTOR: 200

	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
PRS	ERR								PRIN	PRIN							177514
									RDY	IE							
PRB																	177516
																	PRINTER DATA BUFFER (WRITE ONLY)

ASYNCR MODEM:

VECTOR: 330/334

	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
RCSR	DSI	RING	CTS	CAR		SEC	DSET		RCVR	RCVR	DSET		SEC	RTS	DTR		176610
				DET		REC	RDY		DONE	IE	IE		XMIT				
RBUF	ERR	OR	FR	PAR													176612
		ERR	ERR	ERR													RECEIVER DATA BUFFER
XCSR									XMIT	XMIT						BRK	176614
									RDY	IE							
XBUF																	176616
																	TRANSMITTER DATA BUFFER (WRITE ONLY)

SYNC MODEM:

VECTOR: 340/344


	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
RCSR	DSC	RING	CTS	CAR	REC	SEC	DSET	STRP	RCVR	RCVR	DSET	SRCH	SEC	RTS	DTR		176620
				DET	ACT	REC	RDY	SYNC	DONE	IE	IE	SYNC	XMIT				
RBUF	ERR	OR		PAR													176622 (RD ONLY)
		ERR		ERR													RECEIVER DATA BUFFER
PCSR		SYNC			WORD	PAR	EVEN										176622 (WR ONLY)
		CHAR			LENGTH	IE	PAR										SYNC REG
XCSR	DNA		MA	MA		MAST	XMIT	XMIT	DNA	SEND	H/F						176624
			MODE	CLK		RST	RDY	IE	IE		DUP						
XBUF																	176626
																	TRANSMITTER DATA BUFFER (WRITE ONLY)

DISK:

VECTOR: 264

	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
RXC5 ERR									CTL	DRV		UNIT		FUNCTION		GO
									DONE	IE		SEL				
RXIB	DATA BUFFER															
RXC5									DRV		DEL	RNF	CRC	LOST	INV	ID
									RDY		DATA			DATA	ADDR	
RX A	TRACK 0 - 114(8)							SECTOR 1 - 32(8)								

6.0 DEVICE CONNECTOR LAYOUT



7.0 SUMMARY OF TESTS (SEE PROGRAM LISTING FOR ADDT'L DETAILS ON SPECIFIC TESTS)

PHASE 1

MEMORY TESTS A. LOC 0 THRU END OF PROGRAM IS TESTED FOR TIMEOUT.  
B. END OF PROGRAM TO BOTTOM OF MONITOR/ABS LOADER  
IS TESTED WITH A 1010 & 0101 PATTERN.  
C. IF 28K PRESENT, MEMORY FROM 28K TO 30K IS SIMILARLY TESTED.

PHASE 2

ALL AVAILABLE PERIPHERALS ARE EXERCISED CONTINUOUSLY IN INTERRUPT MODE.

SEE SECTION 2.4 FOR DETAILS OF SETTING UP THE DEVICE MAP (\$DEVN) FOR DEVICE TO BE TESTED.  
SEE SECTION 4.1 FOR DETAILS ON PROGRESS REPORTS.

START LINE CLOCK	INTERRUPTS ARE DETECTED.
START PRINTER	CONTINUOUS LINES ARE PRINTED.
START SYNC COMM PORT	CHARS 27 THRU 377 " " " " " " " " 1 PASS ONLY
START ASYNC COMM PORT	CHARS J THRU 377 TESTED CONTINUOUSLY.
START CLUSTER TERMINAL #1	CHARS 0 THRU 377 ARE XMITTED, REC'D & TESTED.
START CLUSTER TERMINAL #2	SAME
START CLUSTER TERMINAL #3	SAME

PHASE 3

WHILE THE ABOVE DEVICES ARE INTERRUPTING RANDOMLY, DISK SUBSYSTEM TESTS BEGIN:

FILL & EMPTY BUFFER TESTS ARE PERFORMED TO VERIFY THAT NO  
CABLE CROSS-TALK PROBLEMS EXIST BEFORE BEGINNING ACTUAL  
DATA TRANSFERS TO THE DISK SURFACE.

DX0 & DX1 DATA PATTERN: WRITE, READ & DATA COMPARE 1'ST 10 TRACKS ON 1'ST PASS.  
ALL TRACKS ON SUBSEQUENT PASSES.

DX0 & DX1 RANDOM SEEKS: READ & DATA COMPARE.  
20 SEEKS ON 1'ST 10 TRACKS ON 1'ST PASS.  
500 SEEKS ON ALL TRACKS ON SUBSEQUENT PASSES.

DX0 INITIALIZE, RESTORE, WRITE DELETED DATA, READ STATUS, & INVALID ADDRESS TESTS.

NOTE:

1. RECOVERY IS PERFORMED (RESTORE COMMAND) AFTER ANY RNF ERROR ON WRITE OR READ.
2. DATA IS TESTED AFTER A HARD CRC ERROR ON A READ TO TEST WHETHER DATA CRC ERROR OR CRC ERROR.

%

```

669
670
671 .TITLE PDT-11 EXERCISER
672 .*COPYRIGHT (C) 1978
673 .*DIGITAL EQUIPMENT CORP.
674 .*MAYNARD, MASS. 01754
675 .*
676 .*PROGRAM BY GARY PAPAIZIAN
677 .*
678 .*THIS PROGRAM WAS ASSEMBLED USING THE PDP-11 MAINDEC SYSMAC
679 .*PACKAGE (MAINDEC-11-DZQAC-C3), JAN 19, 1977.
680 .*
681 .SBTTL OPERATIONAL SWITCH SETTINGS
682
683 .      SWITCH      USE
684 .      -----      ---
685 .      15          HALT ON ERROR
686 .      13          INHIBIT ERROR TYPEOUTS
687 .      12          ENABLE PERFORMANCE REPORTS
688 .      10          BELL ON ERROR
689 .
690
691
692
693 .SBTTL BASIC DEFINITIONS
694
695 .*INITIAL ADDRESS OF THE STACK POINTER *** 1100 ***
696 001100 STACK= 1100
697 .EQUIV EMT,ERROR      ;;BASIC DEFINITION OF ERROR CALL
698 .EQUIV IOT,SCOPE      ;;BASIC DEFINITION OF SCOPE CALL
699
700 .*MISCELLANEOUS DEFINITIONS
701 000011 HT= 11      ;;CODE FOR HORIZONTAL TAB
702 000012 LF= 12      ;;CODE FOR LINE FEED
703 000015 CR= 15      ;;CODE FOR CARRIAGE RETURN
704 000200 CRLF= 200    ;;CODE FOR CARRIAGE RETURN-LINE FEED
705 177776 PS= 177776  ;;PROCESSOR STATUS WORD
706 .EQUIV PS,PSW
707 177774 STKLMT= 177774 ;;STACK LIMIT REGISTER
708 177772 PIRQ= 177772  ;;PROGRAM INTERRUPT REQUEST REGISTER
709 177570 DSWR= 177570  ;;HARDWARE SWITCH REGISTER
710 177570 DDISP= 177570 ;;HARDWARE DISPLAY REGISTER
711
712 .*GENERAL PURPOSE REGISTER DEFINITIONS
713 000000 R0= %0      ;;GENERAL REGISTER
714 000001 R1= %1      ;;GENERAL REGISTER
715 000002 R2= %2      ;;GENERAL REGISTER
716 000003 R3= %3      ;;GENERAL REGISTER
717 000004 R4= %4      ;;GENERAL REGISTER
718 000005 R5= %5      ;;GENERAL REGISTER
719 000006 R6= %6      ;;GENERAL REGISTER
720 000007 R7= %7      ;;GENERAL REGISTER
721 000006 SP= %6      ;;STACK POINTER
722 000007 PC= %7      ;;PROGRAM COUNTER
723
724 .*PRIORITY LEVEL DEFINITIONS

```



725	000000	PR0=	0	::PRIORITY LEVEL 0
726	000040	PR1=	40	::PRIORITY LEVEL 1
727	000100	PR2=	100	::PRIORITY LEVEL 2
728	000140	PR3=	140	::PRIORITY LEVEL 3
729	000200	PR4=	200	::PRIORITY LEVEL 4
730	000240	PR5=	240	::PRIORITY LEVEL 5
731	000300	PR6=	300	::PRIORITY LEVEL 6
732	000340	PR7=	340	::PRIORITY LEVEL 7

733

734 :\*'SWITCH REGISTER' SWITCH DEFINITIONS

735	100000	SW15=	100000
736	040000	SW14=	40000
737	020000	SW13=	20000
738	010000	SW12=	10000
739	004000	SW11=	4000
740	002000	SW10=	2000
741	001000	SW09=	1000
742	000400	SW08=	400
743	000200	SW07=	200
744	000100	SW06=	100
745	000040	SW05=	40
746	000020	SW04=	20
747	000010	SW03=	10
748	000004	SW02=	4
749	000002	SW01=	2
750	000001	SW00=	1

751 .EQUIV SW09,SW9

752 .EQUIV SW08,SW8

753 .EQUIV SW07,SW7

754 .EQUIV SW06,SW6

755 .EQUIV SW05,SW5

756 .EQUIV SW04,SW4

757 .EQUIV SW03,SW3

758 .EQUIV SW02,SW2

759 .EQUIV SW01,SW1

760 .EQUIV SW00,SW0

761

762 :\*DATA BIT DEFINITIONS (BIT00 TO BIT15)

763	100000	BIT15=	100000
764	040000	BIT14=	40000
765	020000	BIT13=	20000
766	010000	BIT12=	10000
767	004000	BIT11=	4000
768	002000	BIT10=	2000
769	001000	BIT09=	1000
770	000400	BIT08=	400
771	000200	BIT07=	200
772	000100	BIT06=	100
773	000040	BIT05=	40
774	000020	BIT04=	20
775	000010	BIT03=	10
776	000004	BIT02=	4
777	000002	BIT01=	2
778	000001	BIT00=	1

779 .EQUIV BIT09,BIT9

780 .EQUIV BIT08,BIT8

```
781 .EQUIV BIT07,BIT7
782 .EQUIV BIT06,BIT6
783 .EQUIV BIT05,BIT5
784 .EQUIV BIT04,BIT4
785 .EQUIV BIT03,BIT3
786 .EQUIV BIT02,BIT2
787 .EQUIV BIT01,BIT1
788 .EQUIV BIT00,BIT0
789
790 ;*BASIC "CPU" TRAP VECTOR ADDRESSES
791 000004 ERRVEC= 4 ;:TIME OUT AND OTHER ERRORS
792 000010 RESVEC= 10 ;:RESERVED AND ILLEGAL INSTRUCTIONS
793 000014 TBITVEC=14 ;: 'T' BIT
794 000014 TRTVEC= 14 ;:TRACE TRAP
795 000014 BPTVEC= 14 ;:BREAKPOINT TRAP (BPT)
796 000020 IOTVEC= 20 ;:INPUT/OUTPUT TRAP (IOT) **SCOPE**
797 000024 PWRVEC= 24 ;:POWER FAIL
798 000030 EMTVEC= 30 ;:EMULATOR TRAP (EMT) **ERROR**
799 000034 TRAPVEC=34 ;: 'TRAP' TRAP
800 000060 TKVEC= 60 ;:TTY KEYBOARD VECTOR
801 000064 TPVEC= 64 ;:TTY PRINTER VECTOR
802 000240 PIRQVEC=240 ;:PROGRAM INTERRUPT REQUEST VECTOR
803
804
805
806
807
```

```
*****
;* PDT-11/150 DEVICE VECTORS
*****
```

```
810
811 000200 PRVEC- 200 ;:PRINTER
812
813 000100 CLKVEC- 100 ;:LINE CLOCK
814
815 000330 AMRVEC= 330 ;:ASYNC MODEM RECVR
816 000334 AMXVEC= 334 ;: XMITR
817
818 000340 SMRVEC= 340 ;:SYNC MODEM RECVR
819 000344 SMXVEC- 344 ;: XMITR
820
821 000264 RXVEC= 264 ;:DISK
822
823 000300 TK1VEC= 300 ;:CLUSTER TERM #1 VECTORS
824 000304 TP1VEC= 304
825 000310 TK2VEC= 310 ;: #2
826 000314 TP2VEC- 314 ;:
827 000320 TK3VEC- 320 ;: #3
828 000324 TP3VEC 324
```

```

829
830
831      :*****
832      :      PDT-11/150 DEVICE REGISTERS
833      :*****
834      177420      PARAM= 177420      ;PARAMETER REGISTER      (WRITE ONLY)
835
836      177546      CLK= 177546      ;LINE CLOCK
837
838      177514      PRS= 177514      ;PRINTER STATUS REG
839      177516      PRB= 177516      ;      BUFFER      (WRITE ONLY)
840
841      176610      AMRC= 176610      ;ASYNC MODEM RECVR STATUS REG
842      176612      AMRB= 176612      ;      BUFFER
843      176614      AMXC= 176614      ;      XMITR STATUS REG
844      176616      AMXB= 176616      ;      BUFFER      (WRITE ONLY)
845
846      176620      SMRC= 176620      ;SYNC MODEM RECVR STATUS REG
847      176622      SMRB= 176622      ;      BUFFER      (READ ONLY)
848      176622      SMPAR= 176622      ;      PARAMETER REG      (WRITE ONLY)
849      176624      SMXC= 176624      ;      XMITR STATUS REG
850      176626      SMXB= 176626      ;      BUFFER      (WRITE ONLY)
851
852      177170      RXCS= 177170      ;DISK CSR
853      177172      RXDB= 177172      ;      DATA BUFF
854      177172      RXES= 177172      ;      ERROR & STATUS REG
855      177174      RXSA= 177174      ;      TRK & SECTOR ADDR REG
856
857      176500      TK1S= 176500      ;CLUSTER TERMINAL #1
858      176502      TK1B= 176502
859      176504      TP1S= 176504
860      176506      TP1B= 176506
861
862      176510      TK2S= 176510      ;      #2
863      176512      TK2B= 176512
864      176514      TP2S= 176514
865      176516      TP2B= 176516
866
867      176520      TK3S= 176520      ;      #3
868      176522      TK3B= 176522
869      176524      TP3S= 176524
870      176526      TP3B= 176526
  
```

```
871  
872  
873  
874  
875  
876  
877  
878  
879  
880  
881  
882  
883  
884  
885  
886  
887  
888  
889  
890  
891  
892  
893  
894  
895  
896  
897  
898  
899  
900  
901  
902  
903  
904  
905  
906  
907  
908  
909  
910  
911  
912  
913  
914  
915  
916  
917  
918  
919  
920  
921  
922  
923  
924  
925  
926
```

```
*****  
* PARAMETER REGISTER EQUATES WRITE ONLY  
*****  
:BIT 14-12 PORT SELECT  
:  
:CONSOL= 10000 ;SELECT CONSOLE TERMINAL  
:CT1= 0 ; CLUSTER TERMINAL #1  
:CT2= 50000 ; #2  
:CT3= 60000 ; #3  
:PRT= 20000 ; PRINTER PORT  
:AMOD= 30000 ; ASYNC COMM PORT  
:ULITE= 40000 ; USER LIGHTS  
:  
:BIT 11-8 BAUD RATE (DELTA = 400)  
:  
:B50= 0 ;50 BAUD  
:B75= 400 ;75  
:B110= 1000 ;110  
:B134= 1400 ;134.5  
:B150= 2000 ;150  
:B300= 2400 ;300  
:B600= 3000 ;600  
:B1200= 3400 ;1200  
:B1800= 4000 ;1800  
:B2000= 4400 ;2000  
:B2400= 5000 ;2400 (CLUSTER DEFAULT)  
:B3600= 5400 ;3600  
:B4800= 6000 ;4800  
:B7200= 6400 ;7200  
:B9600= 7000 ;9600 (PRINTER & ASYNC DEFAULT)  
:B19200= 7400 ;19200  
:  
:IF 110 BAUD SELECTED, 2 STOP BITS ARE ASSUMED.  
:  
:BITS 4-5 PARITY CONTROL  
:  
:EPAR= 60 ;EVEN PARITY ENABLE  
:OPAR= 20 ;ODD PARITY ENABLE (DEFAULT)  
:  
:BITS 3-2 CHARACTER LENGTH (DELTA = 4)  
:  
:CHAR5= 0 ;5 BITS/CHAR  
:CHAR6= 4 ;6  
:CHAR7= 10 ;7  
:CHAR8= 14 ;8 (PRINTER, TERMINAL, MODEM DEFAULT)  
:  
:BIT 1 MAINTENANCE BIT  
:  
:MAINT= BIT1 ;ENABLE MAINT MODE  
:PRINTER & DISK DO NOT HAVE MAINT MODE  
:  
:*****
```

```
927          : *      ASYNC MODEM BIT DEFINITIONS
928          : :*****
929
930          : RCSR
931          :
932          100000 DSI= BIT15      : DATA SET INTERRUPT
933          040000 RING= BIT14     : RING
934          020000 CTS= BIT13      : CLEAR TO SEND
935          010000 CDET= BIT12     : CARRIER DETECTED
936          002000 SREC= BIT10     : SECONDARY RECD/SUPERVISORY RECD
937          001000 DSRDY= BIT9     : DATA SET RDY
938          000200 DONE= BIT7      : RECVR DONE
939          000100 IE= BIT6        : RECVR IE
940          000040 DSIE= BIT5      : DATA SET IE
941          000010 SXMIT= BIT3     : SECONDARY XMIT/SUPERV XMIT
942          000004 RTS= BIT2       : REQ TO SEND
943          000002 DTR= BIT1       : DATA TERMINAL RDY
944
945          : RBUF
946          :
947          100000 ERR= BIT15       : ERROR
948          040000 ORERR= BIT14    : OVERRUN ERROR
949          020000 FRERR= BIT13    : FRAMING ERROR
950          010000 PARERR= BIT12   : PARITY ERROR
951
952          : XCSR
953          :
954          000200 RDY- BIT7        : XMIT RDY
955          000100 IE- BIT6        : XMIT IE
956          000001 BREAK- BIT0     : BREAK
957
```

```

958
959
960      :*****
961      :*      SYNC MODEM BIT DEFINITIONS
962      :*****
963      :RCSR
964      :
965      100000 DSC= BIT15      :DATA SET CHANGE
966      040000 RING= BIT14      :RING
967      020000 CTS= BIT13      :CLEAR TO SEND
968      010000 CDET= BIT12      :CARRIER DETECTED
969      004000 RACT= BIT11      :RECVR ACTIVE (SYNC DETECT)
970      002000 SREC= BIT10      :SECONDARY RECD/SUPERVISORY RECD
971      001000 DSRDY= BIT9      :DATA SET RDY
972      000400 STSYN= BIT8      :STRIP SYNC
973      000200 DONE= BIT7      :RECVR DONE
974      000100 E= BIT6      :RECVR IE
975      000040 DSIE= BIT5      :DATA SET IE
976      000020 SRSYN= BIT4      :SEARCH SYNC
977      000010 SXMIT= BIT3      :SECONDARY XMIT/SUPERV XMIT
978      000004 RTS= BIT2      :REQ TO SEND
979      000002 DTR= BIT1      :DATA TERMINAL RDY
980
981      :RBUF
982      :
983      100000 ERR= BIT15      :ERROR
984      040000 ORERR= BIT14      :OVERRUN ERROR
985      010000 PARERR= BIT12      :PARITY ERROR
986
987      :PARCSR PARAMETER CONT REG
988      :
989      :BIT 14 SYNC CHAR
990      :
991      000000 SYNC2= 0      :2 SYNC CHARS (DEFAULT)
992      040000 SYNC1= BIT14      :1
993
994      :BITS 10-11 WORD LENGTH
995      :
996      000000 CHR5= 0      :5 BITS/CHAR
997      002000 CHR6= 2000      :6
998      004000 CHR7= 4000      :7
999      006000 CHR8= 6000      :8 (DEFAULT)
1000
1001      :BITS 8-9 PARITY CONTROL
1002      :
1003      001400 ENVPAR= 1400      :ENABLE EVEN PARITY
1004      001000 ODDPAR= 1000      :ENABLE ODD PARITY (DEFAULT)
1005
1006      :XCSR
1007      :
1008      100000 DNA BIT15      :DATA NOT AVAIL
1009      010000 MM= BIT12      :MAINT MODE
1010      004000 MCLK= BIT11      :MAINT CLOCK
1011      000400 MR= BIT8      :MASTER RESET
1012      000200 RDY= BIT7      :XMIT RDY
1013      000100 IE= BIT6      :XMIT IE
  
```

```

1014      000040      DNAIE= BIT5      ;DATA NOT AVAIL IE
1015      000020      SEND= BIT4      ;SEND
1016      000010      HFDUP= BIT3      ;1=HALF DUPLEX, 0=FULL DUPLEX (DEFAULT = 0 FOR TESTS)
1017
1018
1019
1020
1021      ;*****
1022      ;DISK BIT DEFINITIONS
1023      ;*****
1024
1025      ;RXCS
1026      ;
1027      100000      ERR= BIT15      ;ERROR
1028      000200      DONE= BIT7      ;CONTR RDY
1029      000100      IE= BIT6      ;DRIVE IE
1030      000020      DX1= BIT4      ;UNIT SELECT: 0=DX0, 1=DX1
1031      000020      USEL= BIT4      ;UNIT SELECT
1032
1033      ;FUNCTIONS (INCLUDES BIT0 = GO)
1034
1035      000001      FBUF= 1      ;FILL BUFFER
1036      000003      EBUF= 3      ;EMPTY BUFFER
1037      000005      WSEC= 5      ;WRITE SECTOR
1038      000007      RSEC= 7      ;READ SECTOR
1039      000011      INITAL= 11      ;INITIALIZE
1040      000013      RSTAT= 13      ;READ STATUS
1041      000015      WDDSEC= 15      ;WRITE DELETED DATA SECTOR
1042      000017      RESTOR= 17      ;RESTORE TO TRACK 0
1043
1044      ;RXES: ERROR & STATUS
1045      ;
1046      000200      RDY= BIT7      ;DRIVE RDY
1047      000040      DD= BIT5      ;DELETED DATA DET.
1048      000020      RNF= BIT4      ;RECORD NOT FOUND
1049      000010      CRC= BIT3      ;CRC ERROR
1050      000004      LDATA= BIT2      ;LOST DATA
1051      000002      INVADR= BIT1      ;INVALID ADDR
1052      000001      ID= BIT0      ;INITIALIZE DONE
1053
1054

```

```

1055
1056
1057
1058
1059
1060
1061 000174 000174
1062 000176 000000
1063
1064 000100 000100
1065 000102 000102
1066 000102 000002
1067
1068 000200 000200
1069 000137 000137 003174
1070
1071 000240 000240
1072 000137 000137 003174
1073
1074 000250 000250
1075 000137 000137 003156
1076 000260 000260
1077 000137 000137 003136
1078 000270 000270
1079 000137 000137 003144
1080
1081
1082
1083 001000
1084
1085
1086
1087
1088
1089 001000
1090 000024 000024
1091 000024 000200
1092 000044 000044
1093 000044 001000
1094 001000
1095
1096
1097
1098
1099 001000
1100 001000 000000
1101 001002 001170
1102 001004 000024
1103 001006 000226
1104 001010 000000
1105 001012 000030

:*****
:* SWITCH REGISTER
:*****

DISPREG:  =174 .WORD 0 ;SOFTWARE DISPLAY REG
SWREG:  =174 .WORD 0 ;SOFTWARE SWITCH REG

          =100
          102 ;SETUP CLOCK VECTOR AREA TO DO RTI
          2 ;IF ENABLED

          =200
          JMP START ;USE ONLY ONCE. WILL BE OVERLAID BY
          ;PRINTER VECTOR ADDR.

          =240
          JMP START ;RESTART ADDR

          =250
          JMP START3 ;ENTER HERE FOR COPY UTILITY

          =260
          JMP START1 ;COMPATABILITY PASS 1

          =270
          JMP START2 ; PASS 2

          =1000
          SBTTL APT PARAMETER BLOCK

:*****
:SET LOCATIONS 24 AND 44 AS REQUIRED FOR APT
:*****
          .SX= ;:SAVE CURRENT LOCATION
          =24 ;:SET POWER FAIL TO POINT TO START OF PROGRAM
          200 ;:FOR APT START UP
          -44 ;:POINT TO APT INDIRECT ADDRESS PNTR.
          $APTHDR ;:POINT TO APT HEADER BLOCK
          -.SX ;:RESET LOCATION COUNTER

:*****
:SETUP APT PARAMETER BLOCK AS DEFINED IN THE APT-PDP11 DIAGNOSTIC
:INTERFACE SPEC.

$APTHD:
$HIBTS: .WORD 0 ;:TWO HIGH BITS OF 18 BIT MAILBOX ADDR.
$MADR: .WORD $MAIL ;:ADDRESS OF APT MAILBOX (BITS 0-15)
$STMT: .WORD 20. ;:RUN TIM OF LONGEST TEST
$PASTM: .WORD 150. ;:RUN TIME IN SECS. OF 1ST PASS ON 1 UNIT (QUICK VERIFY)
$UNITM: .WORD 0 ;:ADDITIONAL RUN TIME (SECS) OF A PASS FOR EACH ADDITIONAL UNIT
          .WORD $ETEND-$MAIL/2 ;:LENGTH MAILBOX-ETABLE(WORDS)
    
```



1106  
1107  
1108  
1109  
1110  
1111  
1112  
1113  
1114  
1115  
1116  
1117  
1118  
1119  
1120  
1121  
1122  
1123  
1124  
1125  
1126  
1127  
1128  
1129  
1130  
1131  
1132  
1133  
1134  
1135  
1136  
1137  
1138  
1139  
1140  
1141  
1142  
1143  
1144  
1145  
1146  
1147  
1148  
1149  
1150  
1151  
1152  
1153  
1154  
1155  
1156  
1157  
1158  
1159  
1160  
1161

001100  
001100 000000  
001102 000  
001103 000  
001104 000000  
001106 000000  
001110 000000  
001112 000000  
001114 000  
001115 001  
001116 000000  
001120 000000  
001122 000000  
001124 000000  
001126 000000  
001130 000000  
001132 000000  
001134 000  
001135 000  
001136 000000  
001140 177570  
001142 177570  
001144 177560  
001146 177562  
001150 177564  
001152 177566  
001154 000  
001155 002  
001156 012  
001157 000  
001160 177607  
001164 077  
001165 015  
001166 000012

000377

```
.SBTTL COMMON TAGS

:*****
:*THIS TABLE CONTAINS VARIOUS COMMON STORAGE LOCATIONS
:*USED IN THE PROGRAM.

      . =1100
$CMTAG:      ;; START OF COMMON TAGS
      .WORD 0
$TSTNM: .BYTE 0      ;; CONTAINS THE TEST NUMBER
$ERFLG: .BYTE 0      ;; CONTAINS ERROR FLAG
$ICNT:  .WORD 0      ;; CONTAINS SUBTEST ITERATION COUNT
$LPADR: .WORD 0      ;; CONTAINS SCOPE LOOP ADDRESS
$LPERR: .WORD 0      ;; CONTAINS SCOPE RETURN FOR ERRORS
$ERTTL: .WORD 0      ;; CONTAINS TOTAL ERRORS DETECTED
$ITEMB: .BYTE 0      ;; CONTAINS ITEM CONTROL BYTE
$ERMAX: .BYTE 1      ;; CONTAINS MAX. ERRORS PER TEST
$ERRPC: .WORD 0      ;; CONTAINS PC OF LAST ERROR INSTRUCTION
$GDADR: .WORD 0      ;; CONTAINS ADDRESS OF 'GOOD' DATA
$BDADR: .WORD 0      ;; CONTAINS ADDRESS OF 'BAD' DATA
$GDDAT: .WORD 0      ;; CONTAINS 'GOOD' DATA
$BDDAT: .WORD 0      ;; CONTAINS 'BAD' DATA
      .WORD 0      ;; RESERVED--NOT TO BE USED
      .WORD 0
$AUTOB: .BYTE 0      ;; AUTOMATIC MODE INDICATOR
$INTAG: .BYTE 0      ;; INTERRUPT MODE INDICATOR
      .WORD 0
SWR:     .WORD DSWR      ;; ADDRESS OF SWITCH REGISTER
DISPLAY: .WORD DDISP    ;; ADDRESS OF DISPLAY REGISTER
$TKS:    177560          ;; TTY KBD STATUS
$TKB:    177562          ;; TTY KBD BUFFER
$TPS:    177564          ;; TTY PRINTER STATUS REG. ADDRESS
$TPB:    177566          ;; TTY PRINTER BUFFER REG. ADDRESS
$NULL:   .BYTE 0        ;; CONTAINS NULL CHARACTER FOR FILLS
$FILLS:  .BYTE 2        ;; CONTAINS # OF FILLER CHARACTERS REQUIRED
$FILLC:  .BYTE 12       ;; INSERT FILL CHARS. AFTER A 'LINE FEED'
$TPFLG:  .BYTE 0        ;; 'TERMINAL AVAILABLE' FLAG (BIT<07>=0=YES)
$BELL:   .ASCIZ <207><377><377> ;; CODE FOR BELL
$QUES:   .ASCII  /?/    ;; QUESTION MARK
$CRLF:   .ASCII <15>    ;; CARRIAGE RETURN
$LF:     .ASCIZ <12>    ;; LINE FEED

:*****
.SBTTL APT MAILBOX-ETABLE

:*****
.EVEN
$MAIL:      ;; APT MAILBOX
$MSGTY: .WORD AMSGTY  ;; MESSAGE TYPE CODE
$FATAL: .WORD AFATAL  ;; FATAL ERROR NUMBER
$TESTN: .WORD ATESTN  ;; TEST NUMBER
$PASS:  .WORD APASS   ;; PASS COUNT
$DEVCT: .WORD ADEVCT  ;; DEVICE COUNT
$UNIT:  .WORD AUNIT   ;; I/O UNIT NUMBER
$MSGAD: .WORD AMSGAD  ;; MESSAGE ADDRESS
$MSGLG: .WORD AMSGLG  ;; MESSAGE LENGTH
$ETABLE:      ;; APT ENVIRONMENT TABLE
```

1162	001210	000	\$ENV:	.BYTE	AENV	::ENVIRONMENT BYTE
1163	001211	000	\$ENVM:	.BYTE	AENVM	::ENVIRONMENT MODE BITS
1164	001212	000000	\$SWREG:	.WORD	ASWREG	::APT SWITCH REGISTER
1165	001214	000000	\$USWR:	.WORD	AUSWR	::USER SWITCHES
1166	001216	000000	\$CPUOP:	.WORD	ACPUOP	::CPU TYPE,OPTIONS
1167			.*			BITS 15-11=CPU TYPE
1168			.*			11/04=01,11/05=02,11/20=03,11/40=04,11/45-05
1169			.*			11/70=06,PDQ=07,Q=10
1170			.*			BIT 10=REAL TIME CLOCK
1171			.*			BIT 9=FLOATING POINT PROCESSOR
1172			.*			BIT 8=MEMORY MANAGEMENT
1173	001220	000	\$MAMS1:	.BYTE	AMAMS1	::HIGH ADDRESS,M.S. BYTE
1174	001221	000	\$MTYP1:	.BYTE	AMTYP1	::MEM. TYPE,BLK#1
1175			.*			MEM.TYPE BYTE -- (HIGH BYTE)
1176			.*			900 NSEC CORE=001
1177			.*			300 NSEC BIPOLAR=002
1178			.*			500 NSEC MOS=003
1179	001222	000000	\$MADR1:	.WORD	AMADR1	::HIGH ADDRESS,BLK#1
1180			.*			MEM.LAST ADDR.=3 BYTES,THIS WORD AND LOW OF 'TYPE' ABOVE
1181	001224	000	\$MAMS2:	.BYTE	AMAMS2	::HIGH ADDRESS,M.S. BYTF
1182	001225	000	\$MTYP2:	.BYTE	AMTYP2	::MEM. TYPE,BLK#2
1183	001226	000000	\$MADR2:	.WORD	AMADR2	::MEM.LAST ADDRESS,BLK#2
1184	001230	000	\$MAMS3:	.BYTE	AMAMS3	::HIGH ADDRESS,M.S.BYTE
1185	001231	000	\$MTYP3:	.BYTE	AMTYP3	::MEM. TYPE,BLK#3
1186	001232	000000	\$MADR3:	.WORD	AMADR3	::MEM.LAST ADDRESS,BLK#3
1187	001234	000	\$MAMS4:	.BYTE	AMAMS4	::HIGH ADDRESS,M.S.BYTE
1188	001235	000	\$MTYP4:	.BYTE	AMTYP4	::MEM. TYPE,BLK#4
1189	001236	000000	\$MADR4:	.WORD	AMADR4	::MEM.LAST ADDRESS,BLK#4
1190	001240	000300	\$VECT1:	.WORD	AVECT1	::INTERRUPT VECTOR#1,BUS PRIORITY#1
1191	001242	000000	\$VECT2:	.WORD	AVECT2	::INTERRUPT VECTOR#2BUS PRIORITY#2
1192	001244	176500	\$BASE:	.WORD	ABASE	::BASE ADDRESS OF EQUIPMENT UNDER TEST
1193	001246	000017	\$DEVN:	.WORD	ADEVN	::DEVICE MAP
1194	001250		\$ETEND:			
1195			.MEXIT			

1196  
1197  
1198  
1199  
1200  
1201  
1202  
1203  
1204  
1205  
1206  
1207  
1208  
1209  
1210  
1211  
1212  
1213  
1214  
1215  
1216  
1217  
1218  
1219  
1220  
1221  
1222  
1223  
1224  
1225  
1226  
1227  
1228  
1229  
1230  
1231  
1232  
1233  
1234  
1235  
1236  
1237  
1238  
1239  
1240  
1241  
1242  
1243  
1244  
1245  
1246  
1247  
1248  
1249  
1250  
1251

001250

001250 020456 023074 023502

001256 023776

001260 020456 023074 023502

001266 023776

001270 020475 023120 023512

001276 023776

001300 020456 023074 023502

001306 023776

001310 020475 023120 023512

001316 023776

001320 020517 023055 023474

001326 023776

001330 020563 023162 023526

001336 023776

001340 020606 023213 023536

001346 023776

001350 020634 023213 023550

001356 023776

001360 020662 023213 023562

001366 023776

001370 020710 023213 023574

001376 023776

001400 020741 023213 023574

001406 023776

001410 020771 023250 023606

001416 023776

.SBTTL ERROR POINTER TABLE

:\*THIS TABLE CONTAINS THE INFORMATION FOR EACH ERROR THAT CAN OCCUR.  
:\*THE INFORMATION IS OBTAINED BY USING THE INDEX NUMBER FOUND IN  
:\*LOCATION \$ITEMB. THIS NUMBER INDICATES WHICH ITEM IN THE TABLE IS PERTINENT.  
:\*NOTE1: IF \$ITEMB IS 0 THE ONLY PERTINENT DATA IS (\$ERRPC).  
:\*NOTE2: EACH ITEM IN THE TABLE CONTAINS 4 POINTERS EXPLAINED AS FOLLOWS:

:\* EM ::POINTS TO THE ERROR MESSAGE  
:\* DH ::POINTS TO THE DATA HEADER  
:\* DT ::POINTS TO THE DATA  
:\* DF ::POINTS TO THE DATA FORMAT

\$ERRTB:  
:GLOBAL DATA  
:ERR 1 EM1,DH2,DT2,DF  
:ERR 2 EM1,DH2,DT2,DF  
:ERR 3 EM2,DH3,DT3,DF  
:ERR 4 EM1,DH2,DT2,DF  
:ERR 5 EM2,DH3,DT3,DF  
:ERR 6 EM3,DH1,DT1,DF  
:ERR 7 EM4,DH4,DT4,DF  
:ERR 10 EM5,DH5,DT5,DF  
:ERR 11 EM6,DH5,DT6,DF  
:ERR 12 EM7,DH5,DT7,DF  
:ERR 13 EM8,DH5,DT8,DF  
:ERR 14 EM9,DH5,DT8,DF  
:ERR 15 EM10,DH6,DT9,DF  
:ERR 16

1252	001420	021016	023315	023624	EM11,DH7,DT10,DF1
1253	001426	024004			
1254					:ERR 17
1255	001430	021016	023315	023624	EM11,DH7,DT10,DF1
1256	001436	024004			
1257					:ERR 20
1258	001440	021034	023315	023624	EM13,DH7,DT10,DF1
1259	001446	024004			
1260					:ERR 21
1261	001450	021065	023315	023624	EM14,DH7,DT10,DF1
1262	001456	024004			
1263					:ERR 22
1264	001460	021116	023404	023646	EM15,DH8,DT11,DF2
1265	001466	024014			
1266					:ERR 23
1267	001470	021147	023404	023646	EM16,DH8,DT11,DF2
1268	001476	024014			
1269					:ERR 24
1270	001500	021200	023315	023670	EM17,DH7,DT12,DF1
1271	001506	024004			
1272					:ERR 25
1273	001510	021200	023315	023670	EM17,DH7,DT12,DF1
1274	001516	024004			
1275					:ERR 26
1276	001520	021216	023315	023670	EM19,DH7,DT12,DF1
1277	001526	024004			
1278					:ERR 27
1279	001530	021247	023315	023670	EM20,DH7,DT12,DF1
1280	001536	024004			
1281					:ERR 30
1282	001540	021300	023404	023712	EM21,DH8,DT13,DF2
1283	001546	024014			
1284					:ERR 31
1285	001550	021331	023404	023712	EM22,DH8,DT13,DF2
1286	001556	024014			
1287					:ERR 32
1288	001560	021362	023055	023474	EM23,DH1,DT1,DF
1289	001566	023776			
1290					:ERR 33
1291	001570	021373	023162	023526	EM24,DH4,DT4,DF
1292	001576	023776			
1293					:ERR 34
1294	001600	021410	023055	023474	EM25,DH1,DT1,DF
1295	001606	023776			
1296					:ERR 35
1297	001610	021425	023055	023474	EM26,DH1,DT1,DF
1298	001616	023776			
1299					:ERR 36
1300	001620	021442	023055	023474	EM27,DH1,DT1,DF
1301	001626	023776			

1302					:ERR 37	
1303	001630	021457	023055	023474		EM28,DH1,DT1,DF
1304	001636	023776				
1305					:ERR 40	
1306	001640	021476	023055	023474		EM29,DH1,DT1,DF
1307	001646	023776				
1308					:ERR 41	
1309	001650	021516	023250	023734		EM30,DH6,DT14,DF
1310	001656	023776				
1311					:ERR 42	
1312	001660	021527	023250	023734		EM31,DH6,DT14,DF
1313	001666	023776				
1314					:ERR 43	
1315	001670	021540	023055	023474		EM32,DH1,DT1,DF
1316	001676	023776				
1317					:ERR 44	
1318	001700	021603	023055	023474		EM33,DH1,DT1,DF
1319	001706	023776				
1320					:ERR 45	
1321	001710	021644	023055	023474		EM34,DH1,DT1,DF
1322	001716	023776				
1323					:ERR 46	
1324	001720	021516	023250	023734		EM30,DH6,DT14,DF
1325	001726	023776				
1326					:ERR 47	
1327	001730	021516	023250	023734		EM30,DH6,DT14,DF
1328	001736	023776				
1329					:ERR 50	
1330	001740	021516	023250	023734		EM30,DH6,DT14,DF
1331	001746	023776				
1332					:ERR 51	
1333	001750	021516	023250	023734		EM30,DH6,DT14,DF
1334	001756	023776				
1335					:ERR 52	
1336	001760	021703	023250	023606		EM35,DH6,DT9,DF
1337	001766	023776				
1338					:ERR 53	
1339	001770	021750	023404	023646		EM36,DH8,DT11,DF2
1340	001776	024014				
1341					:ERR 54	
1342	002000	022017	023250	023606		EM37,DH6,DT9,DF
1343	002006	023776				
1344					:ERR 55	
1345	002010	022043	023250	023606		EM38,DH6,DT9,DF
1346	002016	023776				
1347					:ERR 56	
1348	002020	021516	023250	023734		EM30,DH6,DT14,DF
1349	002026	023776				
1350					:ERR 57	
1351	002030	022111	023250	023606		EM39,DH6,DT9,DF
1352	002036	023776				
1353					:ERR 60	
1354	002040	021516	023250	023734		EM30,DH6,DT14,DF
1355	002046	023776				
1356					:ERR 61	
1357	002050	022141	023250	023606		EM40,DH6,DT9,DF

1358	002056	023776				
1359					:ERR 62	
1360	002060	022204	023250	023606		EM41,DH6,DT9,DF
1361	002066	023776				
1362					:ERR 63	
1363	002070	022240	023250	023606		EM42,DH6,DT9,DF
1364	002076	023776				
1365					:ERR 64	
1366	002100	022261	023315	023624		EM43,DH7,DT10,DF1
1367	002106	024004				
1368					:ERR 65	
1369	002110	022261	023315	023624		EM43,DH7,DT10,DF1
1370	002116	024004				
1371					:ERR 66	
1372	002120	022313	023315	023624		EM45,DH7,DT10,DF1
1373	002126	024004				
1374					:ERR 67	
1375	002130	022313	023315	023624		EM45,DH7,DT10,DF1
1376	002136	024004				
1377					:ERR 70	
1378	002140	022344	023315	023670		EM47,DH7,DT12,DF1
1379	002146	024004				
1380					:ERR 71	
1381	002150	022344	023315	023670		EM47,DH7,DT12,DF1
1382	002156	024004				
1383					:ERR 72	
1384	002160	022376	023315	023670		EM49,DH7,DT12,DF1
1385	002166	024004				
1386					:ERR 73	
1387	002170	022376	023315	023670		EM49,DH7,DT12,DF1
1388	002176	024004				
1389					:ERR 74	
1390	002200	022427	023250	023606		EM51,DH6,DT9,DF
1391	002206	023776				
1392					:ERR 75	
1393	002210	022453	023250	023734		EM52,DH6,DT14,DF
1394	002216	023776				
1395					:ERR 76	
1396	002220	022477	023213	023752		EM53,DH5,DT15,DF
1397	002226	023776				
1398					:ERR 77	
1399	002230	022477	023213	023764		EM53,DH5,DT16,DF
1400	002236	023776				

1401					
1402					: ERRORS FOR COPY UTILITY
1403					
1404					:ERR 100
1405	002240	021034	023250	023734	EM13,DH6,DT14,DF
1406	002246	023776			
1407					:ERR 101
1408	002250	021200	023250	023734	EM17,DH6,DT14,DF
1409	002256	023776			
1410					:ERR 102
1411	002260	022546	023250	023734	EM54,DH6,DT14,DF
1412	002266	023776			
1413					:ERR 103
1414	002270	021216	023250	023734	EM19,DH6,DT14,DF
1415	002276	023776			
1416					
1417					:BAD SECTOR/TRACK TABLE FULL ERRORS
1418					
1419					:ERR 104
1420	002300	022563	000000	000000	EM55,0,0,0
1421	002306	000000			
1422					:ERR 105
1423	002310	022620	000000	000000	EM56,0,0,0
1424	002316	000000			
1425					
1426					:CRC ERRORS
1427					
1428					:ERR 106
1429	002320	022655	023315	023624	EM57,DH7,DT10,DF1
1430	002326	024004			
1431					:ERR 107
1432	002330	022676	023404	023646	EM58,DH8,DT11,DF2
1433	002336	024014			
1434					:ERR 110
1435	002340	022717	000000	000000	EM59,0,0,0
1436	002346	000000			
1437					:ERR 111
1438	002350	022755	023315	023670	EM60,DH7,DT12,DF1
1439	002356	024004			
1440					:ERR 112
1441	002360	022776	023404	023712	EM61,DH8,DT13,DF2
1442	002366	024014			
1443					:ERR 113
1444	002370	023017	000000	000000	EM62,0,0,0
1445	002376	000000			

```

1446
1447
1448
1449
1450 002400 000000
1451 002402 000000
1452 002404 000000
1453 002406 000000
1454 002410 000000
1455 002412 000000
1456 002414 000000
1457 002416 000000
1458 002420 000000
1459 002422 000000
1460 002424 000100
1461 002624 000012
1462
1463
1464
1465
1466
1467
1468 002650 000000
1469 002652 000000
1470 002654 000000
1471 002656 000000
1472 002660 000000
1473 002662 000000
1474 002664 000000
1475 002666 000000
1476 002670 000000
1477 002672 000000
1478 002674 000100
1479 003074 000012
1480
1481 003120 000000
1482
1483
1484
1485
1486
1487
1488 003122 000000
1489 003124 000000
1490
1491 003126 000000
1492
1493 003130 000000
1494 003132 000000
1495 003134 000000
1496
1497

```

```

:*****
:REGISTERS & BUFFERS FOR DX0 TESTS
:*****
DOPAT: 0           ;DX0 PATT TEST DONE FLAG
DOCNT: 0           ;DX0 RANDOM SEEK COUNTER
DOERR: 0           ;DX0 RCSR ERR COUNTER
DOTRK: 0           ;DX0 TRACK
DOSEC: 0           ;DX0 SECTOR
DOCMER: 0          ;DX0 DATA COMPARE ERROR FLAG
DOCERR: 0          ;DX0 TOTAL DATA COMP ERROR CT
DOEXP: 0           ;DX0 EXPECTED DATA
DOREC: 0           ;DX0 RECEIVED DATA
DOCRC: 0           ;DX0 CRC ERROR FLAG
DOBUF: .BLKW 100  ;DX0 DATA BUFFER
DOBAD: .BLKW 10.  ;DX0 BAD TRK/SEC TABLE

:*****
:REGISTERS & BUFFERS FOR DX1 TESTS
:*****
D1PAT: 0           ;DX1 PATT TEST DONE FLAG
D1CNT: 0           ;DX1 RANDOM SEEK COUNTER
D1ERR: 0           ;DX1 RCSR ERR COUNTER
D1TRK: 0           ;DX1 TRACK
D1SEC: 0           ;DX1 SECTOR
D1CMER: 0          ;DX1 DATA COMPARE ERROR FLAG
D1CERR: 0          ;DX1 TOTAL DATA COMPARE ERROR CT
D1EXP: 0           ;DX1 EXPECTED DATA
D1REC: 0           ;DX1 RECEIVED DATA
D1CRC: 0           ;DX1 CRC ERROR FLAG
D1BUF: .BLKW 100  ;DX1 DATA BUFFER
D1BAD: .BLKW 10.  ;DX1 BAD TRK/SEC TABLE

DXTST: 0           ;1 = DATA PATT TEST
                       ;2 = RANDOM SFEK TEST
                       ;3 = INITIALIZE TEST
                       ;4 = RESTORE TEST
                       ;5 = WRITE DELETED DATA TEST
                       ;6 = INVALID ADDRESS TEST

FIN: 0             ;COMMON FLG FOR DX0 & DX1 FOR TRK/SEC FINISHED
MAXTRK: 0          ;MAX TRACK #
                       ;0 FOR 1ST PASS, 114 FOR SUBSEQUENT PASSES. SET AT START.
                       ;# OF RANDOM SEEKS TO BE PERFORMED.
MAXSK: 0           ;10 FOR 1ST PASS, 500 FOR SUBSEQUENT PASSES. SET AT EOP.
                       ;0 - NORM TEST 1 = COPY UTILITY ACTIVE
COPFLG: 0          ;1 COMPAT TESTS, PASS 1
COMP1: 0           ;1 PASS 2
COMP2: 0

```



```

1498 .SBTTL PROGRAM
1499
1500 003136 005237 003132 START1: INC COMP1 ;COMPAT PASS 1
1501 003142 000424 BR S1
1502
1503 003144 005237 003134 START2: INC COMP2 ;COMPAT PASS 2
1504 003150 005037 003132 CLR COMP1
1505 003154 000421 BR S2
1506
1507 003156 005237 003130 START3: INC COPFLG ;COPY UTILITY
1508 003162 005037 003132 CLR COMP1
1509 003166 005037 003134 CLR COMP2
1510 003172 000414 BR S3
1511
1512 003174 012737 000102 000100 START: MOV #CLKVEC+2,CLKVEC ;DO RTI IF CLOCK INTERR
1513 003202 012737 000002 000102 MOV #RTI,CLKVEC+2
1514
1515 003210 005037 003132 CLR COMP1 ;NORMAL TESTING
1516 003214 005037 003134 S1: CLR COMP2
1517 003220 005037 003130 S2: CLR COPFLG
1518
1519 003224 012706 001100 S3: MOV #STACK,SP ;SETUP STACK POINIER
1520 003230 042777 000100 175706 BIC #100,@$TKS ;DISABLE ANYTTY INTERRUPTS
1521 ;TO RT-11 MONITOR
1522 ;DISABLE INTERRUPTS
1523 003236 106427 ;MTPS #PR4
1524 003240 000200 .WORD 106427
1525 003242 013737 000042 004464 MOV 42,HLD42 ;SAVE
1526 003250 123727 001210 000001 CMPB $ENV,#1 ;APT?
1527 003256 001402 BEQ 2$ ;BR IF YES
1528 003260 005037 000042 CLR 42 ;ELSE CLR SO WE CAN USE SOFTSWR
1529 003264
1530 2$:
1531 .SBTTL INITIALIZE THE COMMON TAGS
1532 ;;CLEAR THE COMMON TAGS ($CMTAG) AREA
1533 003264 012706 001100 MOV #CMTAG,R6 ;;FIRST LOCATION TO BE CLEARED
1534 003270 005026 CLR (R6)+ ;;CLEAR MEMORY LOCATION
1535 003272 022706 001140 CMP #SWR,R6 ;;DONE?
1536 003276 001374 BNE -6 ;;LOOP BACK IF NO
1537 003300 012706 001100 MOV #STACK,SP ;;SETUP THE STACK POINTER
1538 ;;INITIALIZE A FEW VECTORS
1539 003304 012737 025416 000030 MOV #ERROR,@EMTVEC ;;EMT VECTOR FOR ERROR ROUTINE
1540 003312 012737 000340 000032 MOV #340,@EMTVEC+2 ;;LEVEL 7
1541 003320 012737 026450 000034 MOV #TRAP,@TRAPVEC ;;TRAP VECTOR FOR TRAP CALLS
1542 003326 012737 000340 000036 MOV #340,@TRAPVEC+2;LEVEL 7
1543 ;;SIZE FOR A HARDWARE SWITCH REGISTER. IF NOT FOUND OR IT IS
1544 ;;EQUAL TO A '-1', SETUP FOR A SOFTWARE SWITCH REGISTER.
1545 003334 013746 000004 MOV @ERRVEC,-(SP) ;;SAVE ERROR VECTOR
1546 003340 012737 003374 000004 MOV #64$,@ERRVEC ;;SET UP ERROR VECTOR
1547 003346 012737 177570 001140 MOV #DSWR,SWR ;;SETUP FOR A HARDWARE SWICH REGISTER
1548 003354 012737 177570 001142 MOV #DDISP,DISPLAY ;;AND A HARDWARE DISPLAY REGISTER
1549 003362 022777 177777 175550 CMP #-1,@SWR ;;TRY TO REFERENCE HARDWARE SWR
1550 BNE 66$ ;;BRANCH IF NO TIMEOUT TRAP OCCURRED
1551 003372 000403 BR 65$ ;;AND THE HARDWARE SWR IS NOT = -1
1552 003374 012716 003402 64$: MOV #C5$, (SP) ;;BRANCH IF NO TIMEOUT
1553 003400 000002 RTI ;;SET UP FOR TRAP RETURN
    
```

```

1554 003402 012737 000176 001140 65$: MOV #SWREG,SWR ;;POINT TO SOFTWARE SWR
1555 003410 012737 000174 001142 MOV #DISPREG,DISPLAY
1556 003416 012637 000004 66$: MOV (SP)+,@#ERRVEC ;;RESTORE ERROR VECTOR
1557
1558 003422 005037 001176 CLR $PASS ;;CLEAR PASS COUNT
1559 003426 132737 000200 001211 BITB #APTSIZE,$ENVM ;;TEST USER SIZE UNDER APT
1560 003434 001403 BEQ 67$ ;;YES,USE NON-APT SWITCH
1561 003436 012737 001212 001140 MOV #SWREG,SWR ;;NO,USE APT SWITCH REGISTER
1562 003444
1563 67$:
1564 .SBTTL TYPE PROGRAM NAME
1565 003444 005227 177777 ;;TYPE THE NAME OF THE PROGRAM IF FIRST PASS
1566 003450 001046 INC #-1 ;;FIRST TIME?
1567 003452 104401 003520 BNE 68$ ;;BRANCH IF NO
1568 .SBTTL GET VALUE FOR SOFTWARE SWITCH REGISTER
1569 003456 005737 000042 TYPE ,69$ ;;TYPE ASCIZ STRING
1570 003462 001012 TST @#42 ;;ARE WE RUNNING UNDER XXDP/ACT?
1571 003464 123727 001210 000001 BNE 70$ ;;BRANCH IF YES
1572 003472 001406 CMPB $ENV,#1 ;;ARE WE RUNNING UNDER APT?
1573 003474 023727 001140 000176 BEQ 70$ ;;BRANCH IF YES
1574 003502 001005 CMP SWR,#SWREG ;;SOFTWARE SWITCH REG SELECTED?
1575 003504 104406 BNE 71$ ;;BRANCH IF NO
1576 003506 000403 GTSWR ;;GET SOFT-SWR SETTINGS
1577 003510 112737 000001 001134 70$: MOVB #1,$AUTOB ;;SET AUTO-MODE INDICATOR
1578 003516 71$:
1579 003516 000423 BR 68$ ;;GET OVER THE ASCIZ
1580 .:69$: .ASCIZ <CRLF>*CVKDAB PDT-11/150 SYSTEM EXERCISER*<CRLF>
1581 003566 68$:
1582 003566 005737 003130 TST COPFLG ;;COPY UTILITY?
1583 003572 001057 BNE LOOP ;;BR IF YES
1584
1585 003574 005737 003132 TST COMP1 ;;COMPAT PASS 1?
1586 003600 001054 BNE LOOP ;;BR IF YES
1587 003602 005737 003134 TST COMP2 ;;COMPAT PASS 2?
1588 003606 001051 BNE LOOP ;;BR IF YES
1589
1590 003610 012737 000004 003124 MOV #4,MAXTRK ;;TRK 0-4, 40-44, 72-76(10) FOR 1'ST PASS
1591 003616 012737 000012 003126 MOV #10.,MAXSK ;;10 RANDOM SEEKS FOR 1'ST PASS
1592
1593 003624 005037 025766 CLR TERR ;;TOTAL ERR CT
1594 003630 005037 025770 CLR TSERR ;;TOTAL SOFT ERR CT FOR EOP TYPEOUT
1595
1596 003634 052737 000006 176610 BIS #<RTS!DTR>,AMRC
1597 003642 042737 000006 176610 BIC #<RTS.DTR>,AMRC ;;DTR MUST BE TOGGLED.
  
```

```

1598
1599 003650 005227 177777          INC      #-1          ;1'ST TIME?
1600 003654 001005          BNE      4$          ;BR IF NO
1601 003656 123727 001210 000001      CMPB     $ENV,#1     ;APT?
1602 003664 001401          BEQ      4$          ;BR IF YES
1603 003666 104412          GTDEVM          ;SHOW CURRENT DEVM & GET NEW
1604
1605 003670 004737 010342          4$:     JSR      PC,SIZE ;SEE WHO IS ON THE SYSTEM
1606 003674 123727 001210 000001      CMPB     $ENV,#1     ;ARE WE RUNNING UNDER APT?
1607 003702 001413          BEQ      LOOP        ;BR IF YES & DONT HALT
1608 003704 032737 001000 001246      BIT      #1000,$DEVM ;DX0 THERE?
1609 003712 001404          BEQ      1$          ;BR IF YES
1610 003714 032737 000400 001246      BIT      #400,$DEVM ;DX1 THERE?
1611 003722 001003          BNE      LOOP        ;BR IF NO
1612 003724 104401 017351          1$:     TYPE     ,WARNING ;INSERT SCRATCH DISKS
1613 003730 000000          HALT
1614
1615
1616 003732 012706 001100          LOOP:   MOV      #1100,SP ;LOOP HERE AFTER EOP & RESET STACK
1617
1618 003736 004737 011566          JSR      PC,TIMER1   ;TIMER TO ALLOW 'P' TO PRINT BEFORE RESET
1619
1620 003742 000005          RESET
1621 003744 042737 000100 177546      BIC      #IE,CLK     ;RESET SETS CLK IE. DONT ALLOW YET
1622
1623          ;MTPS      #PRO          ;ALLOW INTERRUPTS
1624 003752 106427          .WORD   106427
1625 003754 000000          PRO
1626
1627 003756 052737 000006 176610      BIS      #<RTS!DTR>,AMRC ;TO CONDITION ALL TERMINALS &
1628          ;COMM PORT TO OPERATE IN EXT LOOPBACK MODE.
1629          ;NO HARM IF LOOPBACK NOT USED.
1630 003764 004737 011566          JSR      PC,TIMER1   ;TIMER TO ALLOW PREV XFRS TO FINISH
1631
1632 003770 005037 025772          CLR      PERR        ;PASS ERR COUNT FOR EOP TYPEOUT
1633 003774 005037 025774          CLR      PSERR       ;PASS SOFT ERR COUNT FOR EOP TYPEOUT
1634
1635 004000 004737 011664          JSR      PC,CLRBAD   ;CLEAR BAD SECTOR/TRACK TABLES
1636
1637 004004 005737 003132          TST      COMP1        ;COMPAT PASS 1?
1638 004010 001004          BNE      1$          ;BR IF YES
1639 004012 005737 003134          TST      COMP2        ;COMPAT PASS 2?
1640 004016 001001          BNE      1$          ;BR IF YES
1641 004020 000405          BR       2$          ;ELSE TEST FOR COPY
1642
1643 004022 012737 000114 003124 1$:     MOV      #114,MAXTRK
1644 004030 000137 006256          JMP      DXTS+1      ;COMPATABILITY TESTING
1645
1646 004034 005737 003130          2$:     TST      COPFLG      ;COPY UTILITY?
1647 004040 001402          BEQ      MEMTST      ;BR IF NO...NORMAL TESTING
1648 004042 000137 016354          JMP      COPY        ;ELSE GO COPY
1649

```

```

1650 .SBTTL PROGRAM
1651 :*****
1652 :      MEMORY TESTS
1653 :
1654 :MEMORY FROM 0 TO THE LAST LOC OF PROGRAM (LSTAD) IS TESTED FOR TIMEOUT.
1655 :MEMORY FROM 'LSTAD' TO THE BOTTOM OF THE RT11 MONITOR/ABS LOADER
1656 :IS TESTED BY A PASS OF A 1010 PATT FOLLOWED BY A PASS OF 0101 PATTERN.
1657 :IF THE SYSTEM HAS A 28K MEMORY, 28K TO 30K WILL BE TESTED SIMILARLY.
1658 :*****
1659
1660 004046 004737 011102 MEMTST: JSR    PC,EXAMKB
1661
1662 004052 012737 012142 000004 MOV    #INTSRV,ERRVEC ;SETUP TIMEOUT TRAP ADDR
1663 004060 012737 000200 000006 MOV    #200,ERRVEC+2
1664
1665 004066 013703 010766 MOV    MAXMEM,R3
1666 004072 162703 000300 SUB    #300,R3 ;TEST ONLY AS FAR AS ABS LOADER IF NOT RT-11
1667
1668 004076 005004 CLR    R4 ;ADDR POINTER
1669 004100 005037 012150 1$: CLR    INTFLG
1670 004104 005714 TST    (R4) ;TEST LOCS 0 THRU END OF PGM.
1671 004106 005737 012150 TST    INTFLG ;TIMEOUT?
1672 004112 001403 BEQ    2$ ;BR IF NO
1673 004114 010437 004462 MOV    R4,ADDR ;FOR ERR TYP
1674 004120 104001 ERROR 1 ;TIMEOUT ON READ
1675 004122 062704 000002 2$: ADD    #2,R4 ;BUMP ADDR
1676 004126 020427 026532 CMP    R4,#LSTAD ;AT END?
1677 004132 001362 BNE    1$ ;BR IF NO
1678
1679 004134 005037 004454 CLR    MEMCT
1680 004140 012737 125252 004460 MOV    #125252,PAT ;DATA PATT FOR 1'ST PASS
1681 004146 012704 026532 8$: MOV    #LSTAD,R4 ;ADDR POINTER. R/W LOCS LSTAD THRU
1682 ;BOT OF RT11 OR BOT OF ABS LOADER
1683 004152 005037 012150 3$: CLR    INTFLG
1684 004156 013714 004460 MOV    PAT,(R4) ;WRITE
1685 004162 005737 012150 TST    INTFLG ;TIMEOUT?
1686 004166 001403 BEQ    4$ ;BR IF NO
1687 004170 010437 004462 MOV    R4,ADDR ;FOR ERR TYP
1688 004174 104002 ERROR 2 ;TIMEOUT ON WRITE
1689 004176 011437 004456 4$: MOV    (R4),MEMHLD ;READ
1690 004202 023737 004456 004460 CMP    MEMHLD,PAT ;COMPARE
1691 004210 001403 BEQ    6$
1692 004212 010437 004462 MOV    R4,ADDR ;FOR ERR TYP
1693 004216 104003 ERROR 3 ;COMPARE ERROR
1694
1695 004220 062704 000002 6$: ADD    #2,R4 ;BUMP POINTER
1696 004224 023727 004464 001000 CMP    HLD42,#1000 ;RT11 IF LOC 42 = 1000
1697 004232 001403 BEQ    7$ ;BR IF RT11
1698
1699 004234 020403 CMP    R4,R3 ;ELSE AT BOT OF ABS LOADER?
1700 004236 001345 BNE    3$ ;BR IN NO
1701 004240 000403 BR     5$ ;ELSE EXIT
    
```



```
1758 ;:*****
1759
1760 004466 032737 000200 001246 CLKTST: BIT #BIT7,$DEV0 ;DROP TEST?
1761 004474 001031 BNE PRTST ;BR IF YES
1762 004476 012737 012142 000100 MOV #INTSRV,CLKVEC ;SETUP VECTOR AREA
1763 004504 012737 000200 000102 MOV #200,CLKVEC+2 ;LOCKOUT OTHER INTER.
1764 004512 005037 012150 CLR INTFLG
1765 004516 052737 000100 177546 BIS #IE,CLK ;SET CLOCK LOOSE!
1766
1767 004524 004537 011316 JSR R5,TIMER ;SEE IF INTFLG GOES TO 100
1768 004530 012150 INTFLG
1769 004532 000100 100
1770 004534 104032 ERROR 32 ;CLK NOT RESPONDING
1771 004536 000410 BR PRTST
1772
1773 004540 032777 010000 174372 BIT #BIT12,@SWR ;SKIP TYPEOUT IF NOT SET
1774 004546 001404 BEQ PRTST
1775 004550 104401 017244 TYPE ,CLOCK
1776 004554 104401 017670 TYPE ,RJN
```

```

1777
1778
1779          :*****
1780          :          START PRINTER
1781          :*****
1782 004560 032737 100000 001246 PRTST: BIT    #BIT15,$DEVM    ;DROP TEST?
1783 004566 001056          BNE    SMTST          ;BR IF YES
1784 004570 005737 010744          TST    PRPRES          ;PRINTER THERE?
1785 004574 001453          BEQ    SMTST          ;BR IF NO
1786
1787 004576 012737 027014 177420 2$:  MOV    #<PRT!B9600!CHAR8>,PARAM    ;SETUP BAUD RATE & CHAR LENGTH
1788 004604 012737 012152 000200      MOV    #PRSRV,PRVEC    ;ELSE SETUP PRINTER VECTOR
1789 004612 012737 000200 000202      MOV    #200,PRVEC+2    ;LOCKOUT INTERR
1790
1791 004620 005037 012300          CLR    LINCT          ;CLEAR LINE CTR
1792 004624 012737 000015 012276      MOV    #CR,PRCHR      ;CHAR TO BE PRINTED
1793          ;'DEL' (177) CAN BE USED TO CLR PRINTER BUFF
1794 004632 052737 000100 177514      BIS    #IE,PRS        ;SET PRINTER LOOSE!
1795          ;WILL PRINT CONTINUOUS 132 COLUMN LINES
1796          ;EA BEGINNING WITH ASCII 40 THRU 176
1797 004640 004537 011316          JSR    R5,TIMER       ;SEE IF LINCT GOES TO 5
1798 004644 012300          LINCT
1799 004646 000005          5
1800 004650 104033          ERROR 33             ;PRINTER NOT RESPONDING
1801 004652 000424          BR    SMTST
1802
1803 004654 005737 010746          TST    PRPORT        ;EXT LOOPBACK MODE?
1804 004660 001403          BEQ    3$            ;BR IF NO
1805 004662 042737 000100 177514      BIC    #IE,PRS        ;ELSE SHUT DOWN PRINTER
1806
1807 004670 032777 010000 174242 3$:  BIT    #BIT12,@SWR    ;SKIP TYPEOUT IF NOT SET
1808 004676 001412          BEQ    SMTST
1809 004700 104401 017204          TYPE  ,PRINT
1810 004704 005737 010746          TST    PRPORT        ;EXT LOOPBACK MODE?
1811 004710 001403          BEQ    4$            ;BR IF NO
1812 004712 104401 017215          TYPE  ,PORT
1813 004716 000402          BR    SMTST
1814 004720 104401 017670          4$: TYPE  ,RUN
    
```

```

1815
1816
1817
1818
1819
1820 004724 032737 002000 001246 SMTST: BIT #BIT10,$DEV  :DROP TEST?
1821 004732 001402 BEQ 8$ :BR IF NO
1822 004734 000137 005200 JMP AMTST :ELSE JUMP TEST
1823
1824 004740 123727 001210 000001 8$: CMPB $EN' #1 :UNDER APT?
1825 004746 001003 BNE 9$ :BR IF NO
1826 004750 005737 001176 TST $PASS :ELSE 1'ST PASS?
1827 004754 001111 BNE AMTST :EXIT TEST IF NO
1828
1829 004756 005037 012772 9$: CLR LSTCHR :LAST CHAR FLAG FOR XMIT
1830 004762 052737 000400 176024 BIS #MR,SMXC :MASTER RESET
1831 004770 052737 004000 176624 BIS #MCLK,SMXC :MAINT CLOCK
1832
1833 004776 032737 000010 001246 BIT #BIT3,$DEV :EXT LOOPBACK?
1834 005004 001403 BEQ 1$ :BR IF YES
1835 005006 052737 014000 176624 BIS #<MM!MCLK>,SMXC :ELSE SET MAINT MODE FOR INT. LOOPBACK
1836 005014 012737 007026 176622 1$: MOV #<CHR8!ODDPAR!026>,SMPAR :SETUP SYNC PARAMETER REGISTER
1837 005022 052737 000026 176620 BIS #<RTS!DTR!SR SYN>,SMRC :SET REQ TO SEND, DATA TERM RDY
1838 :& SEARCH SYNC
1839 005030 052737 000020 176624 BIS #SEND,SMXC :ENABLE XMIT SEND
1840 005036 012737 000026 176624 MOV #026,SMXB :XMIT SYNC CHAR
1841
1842 005044 004537 011600 JSR R5,TIMER? :WAIT FOR DONE
1843 005050 176620 SMRC
1844 005052 000200 DONE
1845 005054 104045 ERROR 45 :NO DONE
1846 005056 000435 BR 5$ :EXIT
1847
1848 005060 013737 176622 012702 MOV SMRB,COMHLD :READ WORD
1849 005066 023727 012702 000026 CMP COMHLD,#026 :IS IT SYNC CHAR?
1850 005074 001402 BEQ 4$ :BR IF YES
1851 005076 104006 ERROR 6 :DID NOT REC SYNC CHAR
1852 005100 000424 BR 5$ :EXIT
1853
1854 005102 004537 011272 4$: JSR R5,SETVEC :SETUP VECTOR AREA
1855 005106 000340 SMRVEC
1856 005110 012774 SMRSRV
1857 005112 012704 SMXSRY
    
```



```
1858  
1859 005114 012737 000027 012700      MOV    #027,COMCHR      ;1'ST CHAR TO BE XMITTED  
1860 005122 052737 000100 176620      BIS    #IE,SMRC        ;SET SYNC MODEM LOOSE!  
1861 005130 052737 000100 176624      BIS    #IE,SMXC  
1862  
1863 005136 004537 011316      JSR    R5,TIMER        ;SEE IF COMCHR GOES TO ALL 1'S (DONE)  
1864 005142 012700  
1865 005144 177777      COMCHR  
177777  
1866 005146 104037      ERROR  37              ;SYNC COMM NOT RESPONDING  
1867 005150 000240      NOP  
1868  
1869 005152 012737 000400 176624 5$:  MOV    #MR,SMXC        ;MASTER RESET  
1870 005160 032777 010000 173752      BIT    #BIT12,@SWR     ;DO TYPEOUT IF SET  
1871 005166 001404      BEQ    AMTST           ;EXIT IF NOT  
1872 005170 104401 017155      TYPE  ,SCOM  
1873 005174 104401 017756      TYPE  ,DUN
```

```

1874
1875
1876          ;:*****
1877          ;: START ASYNC COMM PORT
1878          ;:*****
1879 005200 032737 004000 001246 AMTST: BIT    #BIT11,$DEV  ;DROP TEST?
1880 005206 001054          BNE    CL1TST  ;BR IF YES
1881
1882 005210 032737 000010 001246          BIT    #BIT3,$DEV  ;EXT LOOPBACK?
1883 005216 001404          BEQ    1$      ;BR IF YES
1884 005220 012737 037036 177420          MOV    #<AMOD!B9600!OPAR!CHAR8!MAINT> ,PARAM ;ELSE SET FOR INT LOOPBACK
1885 005226 000403          BR     3$
1886 005230 012737 037034 177420 1$: MOV    #<AMOD!B9600!OPAR!CHAR8> ,PARAM ;WAKE UP AMOD IF JUST DID SMOD
1887 005236 052737 000006 176610 3$: BIS    #<RTS!DTR> ,AMRC ;SET REQ TO SEND & DATA TERM RDY
1888
1889 005244 004537 011272          JSR    R5,SETVEC ;SETUP VECTOR AREA
1890 005250 000330          AMRVEC
1891 005252 012622          AMRSRV
1892 005254 012604          AMXSRV
1893
1894 005256 005037 012700          CLR    COMCHR ;CHAR TO BE XMITTED
1895 005262 013737 176612 012702          MOV    AMRB,COMHLD ;CLR OUT ANY PREVIOUS STORED WORD
1896 005270 052737 00010C 176610          BIS    #IE,AMRC ;SET ASYNC MODEM LOOSE!
1897 005276 052737 000100 176614          BIS    #IE,AMXC
1898
1899 005304 004537 011316          JSR    R5,TIMER ;SEE IF COMCHR GOES TO 377
1900 005310 012700          COMCHR
1901 005312 000377          377
1902 005314 104040          ERROR 40 ;ASYNC COMM NOT RESPONDING
1903 005316 000410          BR     CL1TST
1904
1905 005320 032777 010000 173612          BIT    #BIT12,@SWR ;SKIP TYPEOUT IF NOT SET
1906 005326 001404          BEQ    CL1TST
1907 005330 104401 017170          TYPE  ,ACOM
1908 005334 104401 017670          TYPE  ,RUN
    
```

```

1909
1910
1911      :*****
1912      :      START CLUSTER TERMINAL #1
1913      :*****
1914 005340 005737 010742      CL1TST: TST      CLPRES      ;OPTION PRESENT?
1915 005344 001002              BNE          1$      ;BR IF YES
1916 005346 000137 006014      JMP          DXTST0
1917
1918 005352 032737 004000 001246 1$: BIT      #4000,$DEV      ;DROP ASYNC?
1919 005360 001406              BEQ          4$      ;BR IF NO
1920 005362 042737 000006 176610 BIC      #<RTS!DTR> ,AMRC ;MUST BE TOGGLED
1921 005370 052737 000006 176610 BIS      #<RTS!DTR> ,AMRC ;PRIME IT
1922
1923 005376 032737 010000 001246 4$: BIT      #BIT12,$DEV      ;DROP TEST?
1924 005404 001051              BNE          CL2TST  ;BR IF YES
1925
1926 005406 032737 000001 001246 BIT      #BIT0,$DEV      ;TERM #1 SET FOR EXT LOOPBACK?
1927 005414 001404              BEQ          2$      ;BR IF YES
1928 005416 012737 005016 177420 MOV      #<CT1!B2400!CHAR8!MAINT> ,PARAM ;ELSE SET FOR INT LOOPBACK
1929 005424 000403              BR          3$
1930 005426 012737 005014 177420 2$: MOV      #<CT1!B2400!CHAR8> ,PARAM ;SETUP FOR EXT LOOPBACK
1931
1932 005434 004537 011272      3$: JSR      R5,SETVEC ;SETUP INTERR VECTORS
1933 005440 000300              TK1VEC
1934 005442 012322              TK1SRV
1935 005444 012304              TP1SRV
1936
1937 005446 005037 012400      CLR      T1CHR      ;CHAR TO BE XMITTED
1938 005452 013737 176502 012402 MOV      TK1B,T1HLD ;READ CHAR (CLEAR STALE DATA)
1939 005460 052737 000100 176500 BIS      #IE,TK1S ;SET CLUSTER TERM #1 LOOSE!
1940 005466 052737 000100 176504 BIS      #IE,TP1S
1941
1942 005474 004537 011316      JSR      R5,TIMER ;SEE IF T1CHR GOES TO 377
1943 005500 012400              T1CHR
1944 005502 000377              377
1945 005504 104034      ERROR 34 ;CLUSTER TERM 1 NOT RESPONDING
1946 005506 000410      BR      CL2TST
1947
1948 005510 032777 010000 173422 BIT      #BIT12,@SWR ;SKIP TYPEOUT IF NOT SET
1949 005516 001404              BEQ      CL2TST
1950 005520 104401 017122      TYPE ,CLT1
1951 005524 104401 017670      TYPE ,RUN
    
```

```

1952
1953
1954
1955
1956
1957 005530 032737 020000 001246 CL2TST: BIT #BIT13,$DEV  ;DROP TEST?
1958 005536 001051 BNE CL3TST ;BR IF YES
1959
1960 005540 032737 000002 001246 BIT #BIT1,$DEV ;TERM #2 SET FOR EXT LOOPBACK?
1961 005546 001404 BEQ 1$ ;BR IF YES
1962 005550 012737 055016 177420 MOV #<CT2!B2400!CHAR8!MAINT> ,PARAM ;ELSE SET FOR INT LOOPBACK
1963 005556 000403 BR 2$
1964 005560 012737 055014 177420 1$: MOV #<CT2!B2400!CHAR8> ,PARAM ;SETUP FOR EXT LOOPBACK
1965
1966 005566 004537 011272 2$: JSR R5,SETVEC ;SETUP INTERR VECTORS
1967 005572 000310 TK2VEC
1968 005574 012422 TK2SRV
1969 005576 012404 TP2SRV
1970
1971 005600 005037 012500 CLR T2CHR ;CHAR TO BE XMITTED
1972 005604 013737 176512 012502 MOV TK2B,T2HLD ;READ CHAR (CLEAR STALE DATA)
1973 005612 052737 000100 176510 BIS #IE,TK2S ;SET CLUSTER TERM #2 LOOSE.
1974 005620 052737 000100 176514 BIS #IE,TP2S
1975
1976 005626 004537 011316 JSR R5,TIMER ;SEE IF T2CHR GOES TO 377
1977 005632 012500 T2CHR
1978 005634 000377 377
1979 005636 104035 ERROR 35 ;CLUSTER TERM 2 NOT RESPONDING
1980 005640 000410 BR CL3TST
1981
1982 005642 032777 010000 173270 BIT #BIT12,@SWR ;SKIP TYPEOUT IF NOT SET
1983 005650 001404 BEQ CL3TST
1984 005652 104401 017133 TYPE ,CLT2
1985 005656 104401 017670 TYPE ,RUN
    
```

```

1986
1987
1988
1989
1990
1991 005662 032737 040000 001246 CL3TST: BIT #BIT14,$DEV  ;DROP TEST?
1992 005670 001051 BNE DXTST0 ;BR IF YES
1993
1994 005672 032737 000004 001246 BIT #BIT2,$DEV ;TERM #3 SET FOR EXT LOOPBACK?
1995 005700 001404 BEQ 1$ ;BR IF YES
1996 005702 012737 065016 177420 MOV #<CT3!B2400!CHAR8!MAINT> ,PARAM ;ELSE SET FOR INT LOOPBACK
1997 005710 000403 BR 2$
1998 005712 012737 065014 177420 1$: MOV #<CT3!B2400.CHAR8> ,PARAM ;SETUP FOR EXT LOOPBACK
1999
2000 005720 004537 011272 2$: JSR R5,SETVEC ;SETUP INTERR VECTORS
2001 005724 000320 TK3VEC
2002 005726 012522 TK3SRV
2003 005730 012504 TP3SRV
2004
2005 005732 005037 012600 CLR T3CHR ;CHAR TO BE XMITTED
2006 005736 013737 176522 012602 MOV TK3B,T3HLD ;READ CHAR (CLEAR STALE DATA)
2007 005744 052737 000100 176520 BIS #IE,TK3S ;SET CLUSTER TERM #3 LOOSE.
2008 005752 052737 000100 176524 BIS #IE,TP3S
2009
2010 005760 004537 011316 JSR R5,TIMER ;SEE IF T3CHR GOES TO 377
2011 005764 012600 T3CHR
2012 005766 000377 377
2013 005770 104036 ERROR 36 ;CLUSTER TERM 3 NOT RESPONDING
2014 005772 000410 BR DXTST0
2015
2016 005774 032777 010000 173136 BIT #BIT12,@SWR ;SKIP TYPEOUT IF NOT SET
2017 006002 001404 BEQ DXTST0
2018 006004 104401 017144 TYPE ,CLT3
2019 006010 104401 017670 TYPE ,RUN
    
```

```

2020
2021
2022          :*****
2023          :          FILL & EMPTY BUFFER TEST
2024          :*****
2025          :A FILL BUFFER COMMAND IS ISSUED WITH ALTERNATING WORDS OF ALL 0'S & ALL 1'S.
2026          :AN EMPTY BUFFER COMMAND IS ISSUED TO FILL 'DOBUF'.
2027          :UPON COMPLETION, DOBUF IS CHECKED FOR ALTERNATING WORDS OF ALL 0'S & ALL 1'S.
2028          :ERRORS IN THIS TEST MAY INDICATE CABLE CROSS-TALK INTERFERENCE.
2029          :*****
2030 006014 005037 003120          DXTST0: CLR          DXTST          :0 = DXTST0
2031
2032 006020 032737 000400 001246          BIT          #BIT8,$DEV          :DROP DX0 TESTS?
2033 006026 001404          BEQ          7$          :BR IF NO
2034 006030 032737 001000 001246          BIT          #BIT9,$DEV          :DROP DX1 TESTS?
2035 006036 001107          BNE          DXTST1          :BR IF YES
2036
2037 006040 004537 011600          7$: JSR          R5,TIMER2          :WAIT FOR DISK DONE
2038 006044 177170          RXCS
2039 006046 000200          DONE
2040 006050 104075          ERROR          7$          :NO DONE
2041 006052 000474          BR          8$          :EXIT
2042
2043 006054 012737 000011 177170          MOV          #INITAL,RXCS          :DO AN INITIALIZE COMMAND
2044
2045 006062 004537 011600          JSR          R5,TIMER2          :WAIT FOR DONE
2046 006066 177170          RXCS
2047 006070 000200          DONE
2048 006072 104075          ERROR          7$          :NO DONE
2049 006074 000463          BR          8$
2050
2051 006076 012700 000100          MOV          #100,R0          :FILL BUFFER
2052 006102 005001          CLR          R1          :WORD CT
2053 006104 012737 000001 177170          MOV          #FBUF,RXCS          :ISSUE FILL BUFF COMMAND
2054 006112 010137 177172          1$: MOV          R1,RXDB
2055 006116 005101          COM          R1          :COMPLEMENT WORD
2056 006120 005300          DEC          R0          :DONE ALL 100 WORDS?
2057 006122 001373          BNE          1$          :BR IF NO
2058
2059 006124 004537 011600          JSR          R5,TIMER2          :WAIT FOR DISK DONE
2060 006130 177170          RXCS
2061 006132 000200          DONE
2062 006134 104075          ERROR          7$          :NO DONE
2063 006136 000442          BR          8$          :EXIT
2064
2065
2066 006140 012700 000100          MOV          #100,R0          :EMPTY BUFFER
2067 006144 012701 002424          MOV          #DOBUF,R1          :WORD CT
2068 006150 012737 000003 177170          MOV          #EBUF,RXCS          :BUFFER ADDR
2069 006156 013721 177172          2$: MOV          RXDB,(R1)+          :ISSUE EMPTY BUFF COMMAND
2070 006162 005300          DEC          R0          :STORE WORD
2071 006164 001374          BNE          2$          :DONE?
                                :BR IF NO
    
```

```

2072
2073 006166 004537 011600      JSR      R5,TIMER2      ;WAIT FOR DISK DONE
2074 006172 177170              RXCS
2075 006174 000200              DONE
2076 006176 104075      ERROR 75      ;NO DONE
2077 006200 000421      BR      8$      ;EXIT
2078
2079
2080 006202 012701 002424      MOV      #DOBUF,R1      ;CHECK IT
2081 006206 012137 006250      3$: MOV      (R1)+,EBHLD  ;BUFFER ADDR
2082 006212 001401              BEQ      4$      ;STORE IT
2083 006214 104076      ERROR 76      ;BR IF ZERO
2084
2085 006216 012137 006250      4$: MOV      (R1)+,EBHLD  ;WORD NOT ALL ZEROS
2086 006222 023727 006250 177777  CMP      EBHLD,#-1      ;ALL 1'S?
2087 006230 001401              BEQ      5$      ;BR IF YES
2088 006232 104077      ERROR 77      ;WORD NOT ALL ONES
2089
2090 006234 020127 002624      5$: CMP      R1,#DOBUF+200 ;END OF DOBUFF?
2091 006240 001362              BNE      3$      ;BR IF NO
2092 006242 000405              BR      DXTST1      ;GO TO NXT TST
2093
2094 006244 000137 010200      8$: JMP      EOP      ;EXIT ALL DISK TESTS
2095
2096 006250 000000      EBHLD: 0      ;STORAGE      FOR ERROR REPORT
2097 006252 000000      EXPO: 0      ;EXPECT 0'S    FOR ERROR REPORT
2098 006254 177777      EXP1: -1     ;EXPECT 1'S    FOR ERROR REPORT
  
```

```

2099
2100
2101
2102
2103
2104
2105
2106
2107
2108
2109
2110
2111
2112
2113 006256 012737 000001 003120 DXTST1: MOV #1,DXTST ;1 - DATA PATT TESTS
2114
2115 006264 005037 002406 CLR D0TRK ;STARTING TRACK
2116 006270 005037 002656 CLR D1TRK
2117
2118 006274 005037 002400 12$: CLR DOPAT ;INIT DX0 FLAGS
2119 006300 005037 002404 CLR DOERR
2120 006304 005037 002414 CLR DOCERR
2121 006310 012737 000001 002410 MOV #1,D0SEC
2122
2123 006316 005037 002650 CLR D1PAT ;INIT DX1 FLAGS
2124 006322 005037 002654 CLR D1ERR
2125 006326 005037 002664 CLR D1CERR
2126 006332 012737 000001 002660 MOV #1,D1SEC
2127
2128 006340 032737 000400 001246 BIT #BIT8,$DEV0 ;DROP DX0 TESTS?
2129 006346 001031 BNE 2$ ;BR IF YES
2130
2131 006350 012737 013074 000264 MOV #RXSRV,RXVEC ;SETUP VECTOR AREA
2132 006356 012737 000200 000266 MOV #200,RXVEC+2
2133
2134 006364 005737 003134 1$: TST COMP2 ;DOING COMPAT PASS 2?
2135 006370 001404 BEQ 10$ ;BR IF NO
2136 006372 012737 013566 013174 MOV #DORSEC,DODISP ;ELSE DO READS ONLY
2137 006400 000403 BR 7$
2138
2139 006402 012737 013212 013174 10$: MOV #D0FBUF,DODISP ;DO NORMAL TESTING
2140 006410 005037 003122 7$: CLR FIN ;DO DX1 WHEN SET
2141 006414 052737 000100 177170 BIS #IE,RXCS ;LET INTERRUPTS LOOSE!
2142
2143 006422 004737 011402 JSR PC,TIMD0
2144 006426 104041 ERROR 41 ;DX0 NOT GETTING TRACK DONE FLAG
2145 006430 000240 NOP
2146
2147 006432 032737 001000 001246 2$: BIT #BIT9,$DEV0 ;DROP DX1 TESTS?
2148 006440 001031 BNE 4$ ;BR IF YES
2149
2150 006442 012737 013074 000264 MOV #RXSRV,RXVEC ;SETUP VECTOR AREA
2151 006450 012737 000200 000266 MOV #200,RXVEC+2
    
```



```

2152
2153 006456 005737 003134      3$:   TST      COMP2      ;DOING COMPAT PASS 2?
2154 006462 001404              BEQ      11$         ;BR IF NO
2155 006464 012737 015352 013202   MOV     #D1RSEC,D1DISP ;ELSE DO READ ONLY
2156 006472 000403              BR       8$
2157
2158 006474 012737 014776 013202 11$:   MOV     #D1FBUF,D1DISP ;DO NORMAL TESTING
2159 006502 005037 003122      8$:   CLR      FIN         ;GO BACK TO DX0 WHEN SET
2160 006506 052737 000120 177170   BIS     #<IE.DX1>,RXCS ;LET INTERRUPTS LOOSE.
2161
2162 006514 004737 011476              JSR     PC,TIMD1
2163 006520 104042              ERROR   42          ;DX1 NOT GETTING TRACK DONE FLAG
2164 006522 000240              NOP
2165
2166 006524 032737 000400 001246 4$:   BIT     #BIT8,$DEV0   ;DROP DX0?
2167 006532 001007              BNE     5$           ;BR IF YES
2168 006534 005737 002400              TST     D0PAT        ;ELSE IS DX0 ALL DONE?
2169 006540 001004              BNE     5$           ;BR IF YES
2170 006542 005737 011474              TST     D0TMO        ;TIMEOUT?
2171 006546 001706              BEQ     1$           ;BR IF NO
2172 006550 000717              BR      7$           ;ELSE CONT LAST COMMAND
2173
2174 006552 032737 001000 001246 5$:   BIT     #BIT9,$DEV0   ;DROP DX1?
2175 006560 001007              BNE     6$           ;BR IF YES
2176 006562 005737 002650              TST     D1PAT        ;ELSE IS DX1 ALL DONE?
2177 006566 001004              BNE     6$           ;BR IF YES
2178 006570 005737 011564              TST     D1TMO        ;TIMEOUT?
2179 006574 001730              BEQ     3$           ;BR IF NO
2180 006576 000741              BR      8$           ;ELSE CONT LAST COMMAND
2181
2182 006600 005737 003132      6$:   TST     COMP1       ;DOING COMPAT PASS 1?
2183 006604 001402              BEQ     13$          ;BR IF NO
2184 006606 000137 010200              JMP     EOP          ;ELSE ALL DONE
2185
2186 006612 005737 001176      13$:  TST     $PASS        ;1'ST PASS?
2187 006616 001035              BNE     DXTST2      ;BR IF NO
2188
2189 006620 023727 003124 000004   CMP     MAXTRK,#4    ;JUST DID 5 OUTER TRACKS?
2190 006626 001012              BNE     14$          ;BR IF NO
2191 006630 012737 000050 002406   MOV     #40,,D0TRK   ;ELSE SETUP FOR 5 MIDDLE TRKS
2192 006636 012737 000050 002656   MOV     #40,,D1TRK
2193 006644 012737 000054 003124   MOV     #44,,MAXTRK
2194 006652 000610              BR      12$
2195
2196 006654 023727 003124 000054 14$:  CMP     MAXTRK,#44.  ;JUST DID 5 MIDDLE TRACKS?
2197 006662 001013              BNE     DXTST2      ;BR IF NO, MUST BE ALL DONE
2198 006664 012737 000110 002406   MOV     #72,,D0TRK   ;ELSE SETUP FOR 5 INNER TRKS
2199 006672 012737 000110 002656   MOV     #72,,D1TRK
2200 006700 012737 000114 003124   MOV     #76,,MAXTRK
2201 006706 000137 006274              JMP     12$
2202

```

```

2203
2204
2205          :*****
2206          :          START DX0 & DX1 RANDOM SEEKS
2207          :
2208          :RANDOM SEEKS ARE PERFORMED ON EACH DISK.
2209          :DATA IS READ & VERIFIED TO BE CORRECT FROM THE PREVIOUS TEST.
2210          :HARD ERRORS ARE THOSE ERRORS AFTER 10 MORE RETRIES.
2211          :1'ST PASS PERFORMS 20 RANDOM SEEKS ON 1'ST 5 TRACKS.
2212          :SUBSEQUENT PASSES PERFORMS 500 RANDOM SEEKS BETWEEN ALL TRACKS.
2213          :*****
2214 006712 012737 000002 003120 DXTST2: MOV    #2,DXTST      ;2 = RANDOM SEEK TESTS
2215 006720 012737 000004 003124      MOV    #4,MAXTRK    ;INIT TO GO FROM TRKS 0-4
2216
2217 006726 005037 002404          CLR    DOERR        ;INIT DX0 FLAGS
2218 006732 005037 002414          CLR    DOCERR
2219 006736 005037 002402          CLR    DOCNT
2220
2221 006742 005037 002654          CLR    D1ERR        ;INIT DX1 FLAGS
2222 006746 005037 002664          CLR    D1CERR
2223 006752 005037 002652          CLR    D1CNT
2224
2225 006756 032737 000400 001246      BIT    #BIT8,$DEV   ;DROP DX0 TESTS?
2226 006764 001041          BNE    2$          ;BR IF YES
2227
2228 006766 005037 011072          1$:  CLR    LOLIM
2229 006772 013737 003124 011074      MOV    MAXTRK,HILIM
2230 007000 004737 010770          JSR    PC,RAND
2231 007004 010137 002406          MOV    R1,DOTRK    ;GET RANDOM TRACK #
2232
2233 007010 005237 011072          INC    LOLIM
2234 007014 012737 000032 011074      MOV    #32,HILIM
2235 007022 004737 010770          JSR    PC,RAND
2236 007026 010137 002410          MOV    R1,DOSEC    ;GET RANDOM SECTOR #
2237
2238 007032 004537 011754          JSR    R5,CKOBAD   ;SEE IF THIS TRK/SEC FLAGGED BAD
2239 007036 000753          BR     1$         ;BR IF RETURN HERE
2240
2241 007040 012737 013566 013174      MOV    #DORSEC,DODISP ;SET DISPATCH TABLE TO POINT TO
2242          ;READ SECTOR HANDLER.
2243 007046 005037 003122          CLR    FIN
2244 007052 052737 000100 177170      BIS    #IE,RXCS    ;DO DX1 WHEN SET
2245          ;LET INTERRUPTS LOOSE!
2246 007060 004737 011402          JSR    PC,TIMDO
2247 007064 104041          ERROR 41
2248 007066 000240          NOP
    
```

```

2249
2250 007070 032737 001000 001246 2$: BIT #BIT9,$DEV  ;DROP DX1 TESTS?
2251 007076 001041 BNE 4$ ;BR IF YES
2252
2253 007100 005037 011072 3$: CLR LOLIM
2254 007104 013737 003124 011074 MOV MAXTRK,HILIM
2255 007112 004737 010770 JSR PC,RAND
2256 007116 010137 002656 MOV R1,D1TRK ;GET RANDOM TRACK #
2257
2258 007122 005237 011072 INC LOLIM
2259 007126 012737 000032 011074 MOV #32,HILIM
2260 007134 004737 010770 JSR PC,RAND
2261 007140 010137 002660 MOV R1,D1SEC ;GET RANDOM SECTOR #
2262
2263 007144 004537 012066 JSR R5,CK1BAD ;SEE IF THIS TRK/SEC FLAGGED BAD
2264 007150 000753 BR 3$ ;BR IF RETURN HERE
2265
2266 007152 012737 015352 013202 MOV #D1RSEC,D1DISP ;SET DISPATCH TABLE TO POINT TO
2267 ;READ SECTOR HANDLER.
2268 007160 005037 003122 CLR FIN ;GO BACK TO DX0 WHEN SET
2269 007164 052737 000120 177170 BIS #<IE!DX1>,RXCS ;LET INTERRUPTS LOOSE!
2270
2271 007172 004737 011476 JSR PC,TIMD1
2272 007176 104042 ERROR 42 ;DX1 NOT GETTING DONE FLAG
2273 007200 000240 NOP
2274
2275 007202 032737 000400 001246 4$: BIT #BIT8,$DEV ;DROP DX0?
2276 007210 001004 BNE 5$ ;BR IF YES
2277 007212 023737 002402 003126 CMP DOCNT,MAXSK ;DID ALL SEEKS?
2278 007220 001262 BNE 1$ ;BR IF NO
2279
2280 007222 032737 001000 001246 5$: BIT #BIT9,$DEV ;DROP DX1?
2281 007230 001004 BNE 6$ ;BR IF YES
2282 007232 023737 002652 003126 CMP D1CNT,MAXSK ;DID ALL SEEKS?
2283 007240 001317 BNE 3$ ;BR IF NO
2284
2285 007242 005737 003134 6$: TST COMP2 ;DOING COMPAT PASS 2?
2286 007246 001402 BEQ DX1ST3 ;BR IF NO
2287 007250 000137 010200 JMP EOP ;ELSE ALL DONE
2288
    
```

```

2289
2290
2291
2292
2293
2294
2295
2296
2297
2298
2299 007254 032737 000400 001246 DXTST3: BIT #BIT8,$DEV0 ;DROP DX0 TESTS?
2300 007262 001062 BNE DXTST4 ;BR IF YES
2301
2302 007264 012737 000003 003120 MOV #3,DXTST ;3 = INIT TEST
2303 007272 005037 002404 CLR DOERR ;FLAGS
2304 007276 005037 002414 CLR DOCERR
2305
2306 007302 *7 014632 013174 MOV #DOINIT,DODISP ;SET DISPATCH TABLE TO GO TO INIT HANDLER
2307
2308 007310 J5037 003122 CLR FIN
2309 007314 J52737 000100 177170 BIS #IE,RXCS ;LET LOOSE
2310
2311 007322 004737 011402 JSR PC,TIMD0
2312 007326 104046 ERROR 46 ;DX0 HUNG ON INITIALIZE COMMAND
2313 007330 000437 BR DXTST4
2314
2315 007332 005737 177170 TST RXCS ;ERROR?
2316 007336 100001 BPL 1$ ;BR IF NO
2317 007340 104063 ERROR 63 ;INIT COMMAND ERROR
2318
2319 007342 032737 000001 177172 1$: BIT #ID,RXES ;INIT DONE BIT SET?
2320 007350 001001 BNE 2$ ;BR IF YES
2321 007352 104055 ERROR 55 ;INIT DONE NOT SET
2322
2323 007354 005037 002404 2$: CLR DOERR
2324 007360 005037 002414 CLR DOCERR
2325 007364 012737 000001 002406 MOV #1,DOTRK ;EXP TRK & SEC
2326 007372 012737 000001 002410 MOV #1,DOSEC
2327
2328 007400 012737 014046 013174 MOV #DOEBUF,DODISP ;SETUP DISPATCH TABLE TO
2329 ;EMPTY BUFFER & VERIFY DATA
2330 007406 005037 003122 CLR FIN
2331 007412 052737 000100 177170 BIS #IE,RXCS ;LET LOOSE
2332
2333 007420 004737 011402 JSR PC,TIMD0
2334 007424 104056 ERROR 56 ;DX0 HUNG ON EMPTY BUFF COMMAND
2335 007426 000240 NOP
    
```

```

2336
2337
2338
2339
2340
2341
2342
2343
2344 007430 032737 000400 001246 DXTST4: BIT #BIT8,$DEV8 ;DROP DX0 TESTS?
2345 007436 001121 BNE DXTST5 ;BR IF YES
2346
2347 007440 012737 000004 003120 MOV #4,DXTST ;4 = RESTORE TEST
2348 007446 012737 014656 013174 MCV #DORREST,DODISP ;SETUP DISPATCH TABLE
2349 007454 005037 003122 CLR FIN
2350 007460 052737 000100 177170 BIS #IE,RXCS
2351
2352 007466 004737 011402 JSR PC,TIMD0
2353 007472 104047 ERROR 47 ;DX0 HUNG ON RESTORE COMMAND
2354 007474 000431 BR 2$
2355
2356 007476 005737 177170 TST RXCS ;ERROR?
2357 007502 100001 BPL 1$ ;BR IF NO
2358 007504 104054 ERROR 54 ;DX0 RESTORE COMMAND ERROR
2359
2360 007506 005037 002406 1$: CLR DOPTRK ;CHK FOR RECORD NOT FOUND (RNF)
2361 007512 012737 000001 002410 MOV #1,DOSEC ;SET TRK/SEC. SHOULD NOT MOVE
2362 ;LOGIC THINKS ITS ALREADY THERE.
2363 007520 005037 002404 CLR DOERR
2364 007524 005037 002414 CLR DOCERR
2365 007530 005037 003122 CLR FIN
2366 007534 012737 013566 013174 MOV #DORSEC,DODISP ;SETUP TO READ SECTOR
2367 007542 052737 000100 177170 BIS #IE,RXCS ;LET INTERR LOOSE
2368
2369 007550 004737 011402 JSR PC,TIMD0
2370 007554 104041 ERROR 41 ;DX0 HUNG ON READ CMD
2371 007556 000240 NOP
2372
2373 007560 032737 001000 001246 2$: BIT #BIT9,$DEV8 ;DROP DX1 TESTS?
2374 007566 001045 BNE DXTST5 ;BR IF YES
2375
2376 007570 012737 014674 013202 MOV #D1REST,D1DISP ;REPEAT FOR DX1
2377 007576 005037 003122 CLR FIN
2378 007602 052737 000120 177170 BIS #<IE!DX1>,RXCS ;LET INTERR LOOSE
2379
2380 007610 004737 011476 JSR PC,TIMD1
2381 007614 104042 ERROR 42 ;DX1 HUNG ON RESTORE CMD
2382 007616 000431 BR DXTST5
2383
2384 007620 005737 177170 TST RXCS ;ERROR?
2385 007624 100001 BPL 3$ ;BR IF NO
2386 007626 104074 ERROR 74 ;DX1 RESTORE CMD ERROR
  
```

```

2387
2388 007630 005037 002656 3$: CLR D1TRK ;READ TO CHECK FOR RNF
2389 007634 012737 000001 002660 MOV #1,D1SEC
2390 007642 005037 002654 CLR D1ERR
2391 007646 005037 002664 CLR D1CERR
2392 007652 005037 003122 CLR FIN
2393 007656 012737 015352 013202 MOV #D1RSEC,D1DISP ;SETUP TO READ SECTOR
2394 007664 052737 000120 177170 BIS #<IE!DX1>,RXCS ;LET INTERR LOOSE
2395
2396 007672 004737 011476 JSR PC,TIMD1
2397 007676 104042 ERROR 42 ;DX1 HUNG ON READ CMD
2398 007700 000240 NOP
2399
2400
2401
2402 ;:*****
2403 ; WRITE SECTOR WITH DELETED DATA MARK TEST
2404 ;:
2405 ; THIS TEST VERIFIES THAT THE WRITE DELETED DATA COMMAND CAN BE ISSUED
2406 ; & THAT THE 'DELETED DATA' BIT 5 IS SET IN RXCS AFTER READY IS RECV'D.
2407 ; HARD ERRORS ARE THOSE ERRORS AFTER 10 MORE RETRIES.
2408 ;:*****
2409
2410 007702 032737 000400 001246 DXTST5: BIT #BIT8,$DEVM ;DROP DX0 TESTS?
2411 007710 001043 BNE DXTST6 ;BR IF YES
2412
2413 007712 012737 000005 003120 MOV #5,DXTST ;5 = WR DEL DATA TEST
2414 007720 005037 002404 CLR DOERR
2415 007724 005037 002414 CLR DOCERR
2416
2417 007730 012737 013212 013174 MOV #DOFBUF,DODISP ;SETUP DISPATCH TABLE
2418
2419 007736 005037 003122 CLR FIN
2420 007742 052737 000100 177170 BIS #IE,RXCS ;LET LOOSE
2421
2422 007750 004737 011402 JSR PC,TIMD0
2423 007754 104050 ERROR 50 ;DX0 HUNG ON WRITE DEL DATA CMD
2424 007756 000420 BR DXTST6
2425
2426 007760 012737 014712 013174 MOV #DOSTAT,DODISP ;SETUP DISPATCH TABLE
2427
2428 007766 005037 003122 CLR FIN
2429 007772 052737 000100 177170 BIS #IE,RXCS ;LET LOOSE
2430
2431 010000 004737 011402 JSR PC,TIMD0
2432 010004 104051 ERROR 51 ;DX0 HUNG ON READ STATUS
2433 010006 000404 BR DXTST6
2434
2435 010010 005737 177170 TST RXCS ;ERROR?
2436 010014 100001 BPL .+4 ;BR IF NO
2437 010016 104057 ERROR 57 ;READ STATUS ERROR
    
```

2438  
 2439  
 2440  
 2441  
 2442  
 2443  
 2444  
 2445  
 2446  
 2447  
 2448  
 2449  
 2450  
 2451  
 2452  
 2453  
 2454  
 2455  
 2456  
 2457  
 2458  
 2459  
 2460  
 2461  
 2462  
 2463  
 2464  
 2465  
 2466  
 2467  
 2468  
 2469  
 2470  
 2471  
 2472  
 2473  
 2474  
 2475  
 2476  
 2477  
 2478  
 2479  
 2480  
 2481  
 2482  
 2483  
 2484  
 2485  
 2486  
 2487

```

:*****
:      INVALID ADDRESS TESTS
:*****
:A WRITE SECTOR COMMAND IS ISSUED TO INVALID TRACK 115(8)
:& RXCS IS CHECKED FOR THE INVALID ADDR BIT 1 TO BE SET AFTER RDY.
:THE ABOVE IS REPEATED FOR INVALID SECTOR 33(8).
:*****
    
```

```

010020 032737 000400 001246 DXTST6: BIT #BIT8,$DEV  ;DROP DXC TESTS?
010026 001062 BNE 4$ ;BR IF YES

010030 005037 010176 CLR INVCT
010034 012737 000006 003120 MOV #6,DXTST ;6 = INV ADDR TESTS
010042 012737 000115 002406 MOV #115,DOTRK
010050 012737 000001 002410 MOV #1,D0SEC
010056 012737 046401 177174 MOV #46401,RXSA ;INVALID TRACK

010064 012737 014730 013174 1$: MOV #D0INV,DODISP ;SETUP DISPATCH TABLE

010072 005037 003122 CLR FIN
010076 052737 000100 177170 BIS #IE,RXCS ;LET LOOSE

010104 004737 011402 JSR PC,TIMDO
010110 104060 ERROR 60 ;DXC HUNG ON INVALID ADDR
010112 000432 BR EOP

010114 032737 000002 177172 BIT #INVADR,RXES ;INV ADDR BIT SET?
010122 001002 BNE 2$ ;BR IF YES
010124 104061 ERROR 61 ;INVALID ADDR BIT NOT SET
010126 000404 BR 3$

010130 005737 177170 2$: TST RXCS ;ERROR BIT SET?
010134 100401 BMI 3$ ;BR IF YES
010136 104062 ERROR 62 ;ERROR BIT NOT SET

010140 005737 010176 3$: TST INVCT ;DID WE JUST DO INV SECTOR?
010144 001013 BNE 4$ ;BR IF YES...DONE

010146 005237 010176 INC INVCT
010152 005037 002406 CLR DOTRK
010156 012737 000033 002410 MOV #33,D0SEC
010164 012737 000033 177174 MOV #33,RXSA ;INVALID SECTOR
010172 000734 BR 1$ ;REPEAT FOR INVALID SECTOR

010174 000401 4$: BR .+4

010176 000000 INVCT: 0 ;0 DOING INVALID TRACK
;1 DOING INVALID SECTOR
    
```

```
2488  
2489  
2490  
2491  
2492 010200 005237 001176  
2493 010204 104401 017764  
2494 010210 013746 001176  
2495 010214 104405  
2496 010216 104401 020001  
2497 010222 013746 025766  
2498 010226 104405  
2499 010230 104401 020030  
2500 010234 013746 025770  
2501 010240 104405  
2502 010242 104401 020064  
2503 010246 013746 025772  
2504 010252 104405  
2505 010254 104401 020121  
2506 010260 013746 025774  
2507 010264 104405  
2508 010266 104401 010336  
2509 010272 012737 000114 003124  
2510 010300 012737 000764 003126  
2511  
2512 010306 005737 003132  
2513 010312 001407  
2514 010314 104401 020350  
2515 010320 000000  
2516 010322 005037 003132  
2517 010326 005237 003134  
2518 010332 000137 003732  
2519  
2520 010336 377 377 000 NULL: .BYTE -1,-1,0  
2521 010342 .EVEN  
2522
```

```
*****  
: END OF PASS  
*****  
EOP: INC $PASS ;PASS CTR  
TYPE ,ENDPAS  
MOV $PASS,-(SP) ;;SAVE $PASS FOR TYPEOUT  
TYPDS ;;GO TYPE--DECIMAL ASCII WITH SIGN  
TYPE ,MSG1  
MOV TERR,-(SP) ;;SAVE TERR FOR TYPEOUT  
TYPDS ;;GO TYPE--DECIMAL ASCII WITH SIGN  
TYPE ,MSG2  
MOV TSERR,-(SP) ;;SAVE TSERR FOR TYPEOUT  
TYPDS ;;GO TYPE--DECIMAL ASCII WITH SIGN  
TYPE ,MSG3  
MOV PERR,-(SP) ;;SAVE PERR FOR TYPEOUT  
TYPDS ;;GO TYPE--DECIMAL ASCII WITH SIGN  
TYPE ,MSG4  
MOV PSERR,-(SP) ;;SAVE PSERR FOR TYPEOUT  
TYPDS ;;GO TYPE--DECIMAL ASCII WITH SIGN  
TYPE ,NULL ;NULL CHAR  
MOV #114,MAXTRK ;FOR ALL SUBSEQUENT PASSES  
MOV #500,MAXSK  
TST COMP1 ;COMPAT PASS 1?  
BEQ 1$ ;BR IF NO  
TYPE ,COMPAT ;DONE MSG  
HALT  
CLR COMP1  
INC COMP2  
1$: JMP LOOP ;REPEAT  
;NULL CHAR STRING
```



```

2523
2524           .SBTTL PROGRAM SUBROUTINES
2525
2526
2527 010342 012737 012142 000004 SIZE:  MOV   #INTSRV,ERRVEC ;SETUP TIMEOUT TRAP ADDR
2528 010350 012737 000200 000006      MOV   #200,ERRVEC+2 ;LOCKOUT INTERR
2529 010356 005037 012150              CLR   INTFLG
2530
2531 010362 012700 017776              MOV   #17776,R0      ;SIZE MEM. START WITH 4K
2532 010366 005001              CLR   R1            ;MEM MAP, 1=4K, 2=8K, ETC
2533 010370 005037 012150              CLR   INTFLG
2534
2535 010374 005710              1$:   TST   (R0)
2536 010376 005737 012150              TST   INTFLG      ;GOT TIMEOUT INTERR?
2537 010402 001007              BNE   2$          ;BR IF YES
2538 010404 005201              INC   R1
2539 010406 020027 157776              CMP   R0,#157776  ;DONE 28K MEM?
2540 010412 001403              BEQ   2$
2541 010414 062700 020000              ADD   #20000,R0   ;GO TO NEXT 4K
2542 010420 000765              BR    1$
2543
2544 010422 010037 010766              2$:   MOV   R0,MAXMEM   ;SAVE
2545 010426 162737 020000 010766      SUB   #20000,MAXMEM ;GO BACK TO LAST VALID BLOCK
2546 010434 006301              ASL   R1           ;MULT BY 2
2547 010436 016137 010746 010446      MOV   MEMTBL-2(R1),3$
2548 010444 104401
2549 010446 000000              3$:   .WORD 0          ;MEM SIZE
2550 010450 104401 017314              TYPE ,MEM
2551
2552 010454 005000              CLR   R0
2553 010456 005037 012150              CLR   INTFLG
2554 010462 012700 176500              MOV   #TK1S,R0    ;SETUP CLUSTER CSR ADDR
2555 010466 005710              4$:   TST   (R0)      ;DARE IT TO TIMEOUT
2556 010470 005737 012150              TST   INTFLG     ;DID IT?
2557 010474 001011              BNE   6$         ;BR IF YES
2558 010476 020027 176520              CMP   R0,#TK3S   ;DID ALL 3?
2559 010502 001403              BEQ   5$         ;BR IF YES
2560 010504 062700 000010              ADD   #10,R0     ;ELSE DO NEXT
2561 010510 000766              BR    4$
2562
2563 010512 005237 010742              5$:   INC   CLPRES    ;OPTION PRESENT
2564 010516 000406              BR    7$         ;ALL 3 MUST RESPOND
2565
2566 010520 005037 010742              6$:   CLR   CLPRES    ;OPTION NOT PRESENT
2567 010524 104401 017102              TYPE ,CLOPT
2568 010530 104401 017334              TYPE ,NOTPRES
2569
2570 010534 012737 000006 000004 7$:   MOV   #ERRVEC+2,ERRVEC ;RESET TMO VECTOR
2571 010542 005037 000006              CLR   ERRVEC+2
    
```

```

2572
2573 010546 005000          CLR    R0
2574 010550 012701 000200  MOV    #BIT7,R1
2575
2576 010554 030137 001246  8$:    BIT    R1,$DEV    ;DEVICE DROPPED?
2577 010560 001006          BNE    10$           ;BR IF YES
2578 010562 000241          9$:    CLC
2579 010564 006301          ASL
2580 010566 103424          BCS    R1           ;BR IF ALL BITS TESTED
2581 010570 062700 000002  ADD    #2,R0        ;ELSE BUMP INDEX
2582 010574 000767          BR     8$
2583
2584 010576 016037 010616 010606 10$:   MOV    12$(R0),11$
2585 010604 104401
2586 010606 000000          11$:   .WORD 0           ;DEVICE TO BE DROPPED
2587 010610 104401 017647  TYPE   .DROP
2588 010614 000762          BR     9$
2589
2590 010616 017244          12$:   CLOCK
2591 010620 017232          DRVO
2592 010622 017237          DRV1
2593 010624 017155          SCOM
2594 010626 017170          ACOM
2595 010630 017122          CLT1
2596 010632 017133          CLT2
2597 010634 017144          CLT3
2598 010636 017204          PRINT
2599
2600 010640 005037 010744          13$:   CLR    PRPRES
2601 010644 005037 010746          CLR    PRPORT
2602 010650 005737 177514          TST    PRS           ;SEE IF PRINTER ERR
2603 010654 100027          BPL    16$           ;BR IF NO
2604
2605 010656 032737 000010 001246  BIT    #BIT3,$DEV    ;COMM PORT IN EXT LOOPBACK?
2606 010664 001405          BEQ    15$           ;BR IF YES
2607
2608 010666 104401 017204          14$:   TYPE   .PRINT
2609 010672 104401 017334          TYPE   .NOTPRES
2610 010676 000420          BR     17$
2611
2612 010700 012737 037034 177420 15$:   MOV    #<AMOD!B9600!OPAP.CHAR8>,PARAM
2613 010706 042737 000006 176610  BIC    #<RTS.DTR>,AMRC ;MUST BE TOGGLED
2614 010714 052737 000006 176610  BIS    #<RTS.DTR>,AMRC
2615 010722 005737 177514          TST    PRS           ;NOW ANY ERRORS?
2616 010726 100757          BMI    14$          ;BR IF YES
2617 010730 005237 010746          INC    PRPORT
2618 010734 005237 010744          16$:   INC    PRPRES      ;PRINTER PRESENT
2619
2620 010740 000207          17$:   RTS    PC
    
```

```

2621
2622 010742 000000          CLPRES: 0          ;CLUSTER PRESENT = NON-ZERO
2623 010744 000000          PRPRES: 0          ;PRINTER PRESENT = NON-ZERO
2624 010746 000000          PRPORT: 0         ;1 = PRINTER ENABLED THRU LOOPBACK
2625
2626 010750 017253          MEMTBL: M4K        ;MSG ADDRESSES
2627 010752 017257          M8K
2628 010754 017263          M12K
2629 010756 017270          M16K
2630 010760 017275          M20K
2631 010762 017302          M24K
2632 010764 017307          M30K
2633
2634 010766 000000          MAXMEM: 0         ;MAX MEMORY
2635
2636
2637
2638
2639
2640
2641 010770 013700 011100  RAND:  MOV      LONUM,R0
2642 010774 013701 011076      MOV      HINUM,R1
2643 011000 012702 177771      MOV      #-7,R2
2644 011004 006300          1$:  ASL      R0
2645 011006 006101          ROL      R1          ;ROTATE CARRY TO R1
2646 011010 005202          INC      R2          ;DONE?
2647 011012 001374          BNE     1$          ;BR IN NO
2648 011014 063700 011100      ADD     LONUM,R0    ;ADD NUMBER TO MAKE X 129
2649 011020 005501          ADC     R1
2650 011022 063701 011076      ADD     HINUM,R1    ;ADD NUMBER TO MAKE X 129
2651 011026 062700 001057      ADD     #1057,R0    ;ADD LO CONSTANT
2652 011032 005501          ADC     R1
2653 011034 062701 047401      ADD     #47401,R1   ;ADD HI CONSTANT
2654 011040 010037 011100      MOV     R0,LONUM
2655 011044 010137 011076      MOV     R1,HINUM
2656
2657 011050 042701 177400          BIC     #177400,R1  ;SCALE TO BE WITHIN LIMITS
2658 011054 020137 011072          CMP     R1,LOLIM    ;SAVE LO BYTE ONLY
2659 011060 103743          BLO     RAND        ;BR IF N < LOLIM
2660 011062 020137 011074          CMP     R1,HILIM
2661 011066 101340          BHI     RAND        ;BR IF N > HILIM
2662 011070 000207          RTS     PC          ;ELSE EXIT WITH R1  N
2663
2664 011072 000000          LOLIM:  0
2665 011074 000000          HILIM:  0
2666
2667 011076 176543          HINUM:  .WORD 176543
2668 011100 123456          LONUM:  .WORD 123456
2669
2670
2671 011102 123727 001210 000001 EXAMKB: CMPB     $ENV,#1    ;APT?
2672 011110 001401          BEQ     1$          ;BR IF YES
2673 011112 104407          CKSWR
2674 011114 000207          1$:  RTS     PC
    
```



```

2721 *****
2722 * ROUTINE TO SET 2 CONSECUTIVE INTERRUPT VECTORS
2723 * 3 ARGUMENTS ARE PASSED THRU R5:
2724 * VECTOR ADDRESS
2725 * INTERRUPT SERVICE ROUTINE ADDRESS FOR RECVR
2726 * INTERRUPT SERVICE ROUTINE ADDRESS FOR XMITTER.
2727 * PRIORITY WILL BE SET TO DISABLE FURTHUR INTERR.
2728 *****
2729
  
```

```

2730 011272 010046 SETVEC: MOV R0, -(SP) ;SAVE
2731 011274 012500 MOV (R5)+, R0 ;GET VECTOR ADDR
2732 011276 012520 MOV (R5)+, (R0)+ ;PUT SERV ROUTINE ADDR THERE
2733 011300 012720 000200 MOV #200, (R0)+ ;DISABLE INTERR
2734 011304 012520 MOV (R5)+, (R0)+ ;GET XMIT SERV ADDR NEXT
2735 011306 012710 000200 MOV #200, (R0)
2736 011312 012600 MOV (SP)+, R0 ;RESTORE
2737 011314 000205 RTS R5
  
```

```

2738
2739
2740
2741
2742
2743 *****
2744 *WATCHDOG TIMER TO PREVENT DEVICES FROM ENTERING AN ENDLESS WAIT LOOP
2745 *RETURN IF TIMED OUT
2746 *RETURN +4 IF NOT TIMED OUT & JUMP OVER ERROR
2747 *****
2748
  
```

```

2749 011316 012537 011376 TIMER: MOV (R5)+, FLGHL ;GET FLAG
2750 011322 012537 011400 MOV (R5)+, CTHLD ;GET COUNT THAT FLAG SHOULD GO TO
2751
2752 011326 012701 000010 MOV #10, R1
2753 011332 012700 177777 4$: MOV #-1, R0
2754 011336 027737 000034 011400 1$: CMP @FLGHL, CTHLD ;RESPONDING?
2755 011344 001411 BEQ 2$ ;BR IF YES
2756 011346 004737 011102 JSR PC, EXAMKB
2757 011352 005300 DEC R0 ;ELSE DEC COUNTER
2758 011354 001370 BNE 1$ ;BR IF NOT TIMED OUT
2759 011356 005237 001200 INC $DEVCT ;FOR APT
2760 011362 005301 DEC R1
2761 011364 001362 BNE 4$
2762 011366 000402 BR .+6 ;ELSE TIMED OUT
2763
2764 011370 062705 000004 2$: ADD #4, R5 ;JUMP OVER ERROR ON RETURN
2765 011374 000205 RTS R5
2766
  
```

```

2767 011376 000000 FLGHL: 0 ;FLAG
2768 011400 000000 CTHLD: 0 ;COUNT THAT FLAG MUST REACH
2769
  
```

```

2770
2771
2772
2773
2774
2775
2776 011402 005037 011474
2777 011406 012737 000010 011472
2778 011414 012737 177777 011470
2779 011422 005737 003122
2780 011426 001015
2781 011430 004737 011102
2782 011434 005337 011470
2783 011440 001370
2784 011442 005237 001200
2785 011446 005337 011472
2786 011452 001360
2787 011454 005237 011474
2788 011460 000402
2789
2790 011462 062716 000004
2791 011466 000207
2792
2793 011470 000000
2794 011472 000000
2795 011474 000000
2796
2797
2798
2799
2800
2801
2802
2803
2804 011476 005037 011564
2805 011502 012737 000010 011472
2806 011510 012737 177777 011470
2807 011516 005737 003122
2808 011522 001015
2809 011524 004737 011102
2810 011530 005337 011470
2811 011534 001370
2812 011536 005237 001200
2813 011542 005337 011472
2814 011546 001360
2815 011550 005237 011564
2816 011554 000402
2817
2818 011556 062716 000004
2819 011562 000207
2820
2821 011564 000000
2822

```

```

*****
;WATCHDOG TIMER TO PREVENT DX0 FROM ENTERING AN ENDLESS WAIT LOOP
;RETURN IF TIMED OUT
;RETURN +4 IF NOT TIMED OUT & JUMP OVER ERROR
*****
TIMDO: CLR DOTMO
MOV #10,CTREG1
4$: MOV #-1,CTREG
1$: TST FIN ;FINISHED?
BNE 2$ ;BR IF YES
JSR PC,EXAMKB
DEC CTREG ;ELSE DEC CTR
BNE 1$ ;BR IF NOT TIMED OUT
INC $DEVCT ;FOR APT
DEC CTREG1
BNE 4$
INC DOTMO ;SET FLAG
BR .+5 ;TIMED OUT

2$: ADD #4,(SP) ;BUMP RET
RTS PC

CTREG: 0
CTREG1: 0
DOTMO: 0 ;1 = TIMEOUT OCCURED

```

```

*****
;WATCHDOG TIMER TO PREVENT DX1 FROM ENTERING AN ENDLESS WAIT LOOP
;RETURN IF TIMED OUT
;RETURN +4 IF NOT TIMED OUT & JUMP OVER ERROR
*****
TIMD1: CLR D1TMO
MOV #10,CTREG1
4$: MOV #-1,CTREG
1$: TST FIN ;FINISHED?
BNE 2$ ;BR IF YES
JSR PC,EXAMKB
DEC CTREG ;ELSE DEC CTR
BNE 1$ ;BR IF NOT TIMED OUT
INC $DEVCT ;FOR APT
DEC CTREG1
BNE 4$
INC D1TMO ;SET FLAG
BR .+6 ;TIMED OUT

2$: ADD #4,(SP) ;BUMP RET
RTS PC

D1TMO: 0 ;1 = TIMEOUT OCCURED

```

```

2823
2824
2825
2826
2827 011566 012700 177777
2828 011572 005300
2829 011574 001376
2830 011576 000207
2831
2832
2833
2834
2835
2836
2837
2838 011600 012537 011660
2839 011604 012537 011662
2840
2841 011610 012701 000010
2842 011614 012700 177777
2843 011620 033777 011662 000032
2844 011626 001011
2845 011630 004737 011102
2846 011634 005300
2847 011636 001370
2848 011640 005237 001200
2849 011644 005301
2850 011646 001362
2851 011650 000402
2852
2853 011652 062705 000004
2854 011656 000205
2855
2856 011660 000000
2857 011662 000000
2858
2859
2860
2861
2862
2863
2864 011664 012700 002624
2865 011670 005020
2866 011672 020027 002650
2867 011676 001374
2868
2869 011700 012700 003074
2870 011704 005020
2871 011706 020027 003120
2872 011712 001374
2873
2874 011714 000207
2875

```

```

*****
:
:   GENERAL TIMER
:
*****
TIMER1: MOV    #-1,R0
        DEC    R0
        BNE    -2
        RTS    PC

*****
:WATCHDOG TIMER TO PREVENT DEVICES FROM ENTERING AN ENDLESS WAIT LOOP
:RETURN IF TIMED OUT
:RETURN +4 IF NOT TIMED OUT & JUMP OVER ERROR
:
*****
TIMER2: MOV    (R5)+,REGHLD ;GET REG
        MOV    (R5)+,BITHLD ;GET BIT TO BE TESTED
        MOV    #10,R1
4$:     MOV    #-1,R0
1$:     BIT    BITHLD,@REGHLD ;BIT THERE?
        BNE    2$ ;BR IF YES
        JSR    PC,EXAMKB
        DEC    R0 ;ELSE DEC COUNTER
        BNE    1$ ;BR IF NOT TIMED OUT
        INC    $DEVCT ;FOR APT
        DEC    R1
        BNE    4$
        BR    .+6 ;ELSE TIMED OUT
2$:     ADD    #4,R5 ;JUMP OVER ERROR ON RETURN
        RTS    R5

REGHLD: 0 ;DEVICE REG
BITHLD: 0 ;DEV REG BIT TO BE TESTED

*****
:ROUTINE TO CLEAR BOTH BAD TRACK/SECTOR TABLES
:
*****
CLRBAD: MOV    #DOBAD,R0
1$:     CLR    (R0)+
        CMP    R0,#DOBAD+20.
        BNE    1$

2$:     MOV    #D1BAD,R0
        CLR    (R0)+
        CMP    R0,#D1BAD+20.
        BNE    2$

        RTS    PC

```

```

2876
2877
2878
2879
2880 011716 010046 LDOBAD: MOV R0,-(SP) ;SAVE
2881
2882 011720 012700 002624
2883 011724 005710 1$: TST #DOBAD,R0 ;ENTRY PRESENT?
2884 011726 001003 BNE 2$ ;BR IF YES
2885 011730 013710 177174 MOV RXSA,(R0) ;ELSE STORE BAD RXSA IN TABLE
2886 011734 000405 BR 3$ ;EXIT
2887
2888 011736 005720 2$: TST (R0)+ ;BUMP PTR
2889 011740 020027 002650 CMP R0,#DOBAD+20. ;AT END OF TABLE?
2890 011744 001367 BNE 1$ ;BR IF NO
2891 011746 104104 ERROR 104 ;10 BAD SECTORS...REPLACE
2892 011750 012600 3$: MOV (SP)+,R0 ;RESTORE
2893 011752 000207 RTS PC
2894
2895
2896
2897
2898
2899
2900
2901
2902
2903
2904 011754 010046 CKOBAD: MOV R0,-(SP) ;SAVE
2905 011756 010146 MOV R1,-(SP)
2906
2907 011760 013701 002406 MOV D0TRK,R1
2908 011764 000301 SWAB R1
2909 011766 053701 002410 BIS D0SEC,R1
2910
2911 011772 012700 002624
2912 011776 020027 002650 1$: MOV #DOBAD,R0
2913 012002 001405 CMP R0,#DOBAD+20. ;END OF TABLE?
2914 012004 005710 BEQ 2$ ;BR IF YES
2915 012006 001403 TST (R0) ;ELSE ANY ENTRY?
2916 012010 022001 BEQ 2$ ;BR IF NO
2917 012012 001371 CMP (R0)+,R1 ;ELSE COMPARE?
2918 012014 000402 BNE 1$ ;BR IF NO
2919 BR 3$ ;ELSE DONT BUMP RET ADDR
2920 012016 062705 00000? 2$: ADD #2,R5 ;BUMP RET ADDR
2921 012022 012601 3$: MOV (SP)+,R1 ;RESTORE
2922 012024 012600 MOV (SP)+,R0
2923 012026 000205 RTS R5

```



```

2924
2925
2926
2927
2928 012030 010046 LD1BAD: MOV R0,-(SP) ;SAVE
2929
2930 012032 012700 003074
2931 012036 005710 1$: MOV #D1BAD,R0
2932 012040 001003 BNE (R0) ;ENTRY PRESENT?
2933 012042 013710 177174 MOV 2$ ;BR IF YES
2934 012046 000405 BR RXSA,(R0) ;ELSE STORE BAD RXSA IN TABLE
2935
2936 012050 005720 2$: TST (R0)+ ;BUMP PTR
2937 012052 020027 003120 CMP R0,#D1BAD+20. ;AT END OF TABLE?
2938 012056 001367 BNE 1$ ;BR IF NO
2939 012060 104105 ERROR 105 ;10 BAD SECTORS...REPLACE
2940 012062 012600 3$: MOV (SP)+,R0 ;RESTORE
2941 012064 000207 RTS PC
2942
2943
2944
2945
2946
2947
2948
2949
2950
2951
2952 012066 010046 CK1BAD: MOV R0,-(SP) ;SAVE
2953 012070 010146 MOV R1,-(SP)
2954
2955 012072 013701 002656 MOV D1TRK,R1
2956 012076 000301 SWAB R1
2957 012100 053701 002660 BIS D1SEC,R1
2958
2959 012104 012700 003074
2960 012110 020027 003120 1$: MOV #D1BAD,R0
2961 012114 001405 CMP R0,#D1BAD+20. ;END OF TABLE?
2962 012116 005710 BEQ 2$ ;BR IF YES
2963 012120 001403 TST (R0) ;ELSE ANY ENTRY?
2964 012122 022001 BEQ 2$ ;BR IF NO
2965 012124 001371 CMP (R0)+,R1 ;FLSE COMPARE?
2966 012126 000402 BNE 1$ ;BR IF NO
2967 BR 3$ ;ELSE DONT BUMP RET ADDR
2968 012130 062705 000002 2$: ADD #2,R5 ;BUMP RET ADDR
2969 012134 012601 3$: MOV (SP)+,R1 ;RESTORE
2970 012136 012600 MOV (SP)+,R0
2971 012140 000205 RTS R5
2972

```

```

*****
:CHECK DX1 BAD TRACK/SECTOR TABLE BEFORE DOING RANDOM SEEKS.
:IF TRK/SEC IN TABLE, RETURN TO RE-CALCULATE NEW TRACK & SECTOR.
*****

```

```

2973 .SBTTL INTERRUPT HANDLERS
2974 :*****
2975 : GENERAL SERVICE ROUTINE TO BUMP 'INTFLG'
2976 : CALLING ROUTINE WILL KNOW WHAT TO DO
2977 :*****
2978
2979 012142 005237 012150 INTSRV: INC INTFLG
2980 012146 000002 RTI
2981 012150 000000 INTFLG: 0
2982
2983
2984 :*****
2985 :PRINTER INTERRUPT HANDLER: VALUES FROM 40 THRU 176.
2986 :*****
2987
2988 012152 013737 177514 012302 PRSRV: MOV PRS,SPRS ;STORE
2989 012160 005737 012302 TST SPRS ;ERROR?
2990 012164 100002 BPL 1$ ;BR IF NO
2991 012166 104007 ERROR 7 ;PRINTER STATUS ERROR
2992 012170 000002 RTI
2993
2994 012172 013737 012276 177516 1$: MOV PRCHR,PRB ;ELSE PRINT CHAR
2995 012200 023727 012276 000015 CMP PRCHR,#CR ;JUST DID CR?
2996 012206 001413 BEQ 2$ ;BR IF YES
2997 012210 023727 012276 000012 CMP PRCHR,#LF ;JUST DID LF?
2998 012216 001413 BEQ 3$ ;BR IF YES
2999 012220 023727 012276 000176 CMP PRCHR,#176 ;JUST DID LAST CHAR?
3000 012226 001413 BEQ 4$ ;BR IF YES
3001 012230 005237 012276 INC PRCHR ;ELSE BUMP CHAR FOR NEXT INTERRUPT
3002 012234 000417 BR 5$ ;EXIT
3003
3004 012236 012737 000012 012276 2$: MOV #LF,PRCHR ;DO LF NEXT
3005 012244 000413 BR 5$
3006 012246 012737 000040 012276 3$: MOV #40,PRCHR ;DO SPACE NEXT
3007 012254 000407 BR 5$
3008 012256 012737 000015 012276 4$: MOV #CR,PRCHR ;DO CR NEXT & START OVER
3009 012264 005237 012300 INC LINCT
3010 012270 005237 001200 INC $DEVCT ;FOR APT
3011 012274 000002 5$: RTI
3012
3013 012276 000000 PRCHR: 0 ;CHAR TO BE PRINTED
3014 012300 000000 LINCT: 0 ;LINE CTR
3015 012302 000000 SPRS: 0 ;STORE PRINTER CSR
  
```

3016  
 3017  
 3018  
 3019  
 3020  
 3021  
 3022  
 3023  
 3024  
 3025  
 3026  
 3027  
 3028  
 3029  
 3030  
 3031  
 3032  
 3033  
 3034  
 3035  
 3036  
 3037  
 3038  
 3039  
 3040  
 3041  
 3042  
 3043  
 3044  
 3045  
 3046  
 3047  
 3048  
 3049  
 3050  
 3051  
 3052  
 3053  
 3054  
 3055  
 3056  
 3057  
 3058  
 3059  
 3060  
 3061  
 3062  
 3063  
 3064  
 3065  
 3066  
 3067  
 3068

\*\*\*\*\*  
 :CLUSTER TERMINAL #1 INTERRUPT HANDLER: LOOP VALUES 0 THRU 377.  
 \*\*\*\*\*

```

TP1SRV: BIC      #IE,TP1S      ;DISABLE INTER, RECV'R WILL TURN BACK ON
          MOV      T1CHR,TP1B   ;PRINT CHAR
          RTI

TK1SRV: MOV      TK1B,T1HLD     ;STORE CHAR
          CMP      T1HLD,T1CHR  ;OK?
          BEQ      1$           ;BR IF YES
          ERROR    10          ;CHAR COMP ERROR

1$:      CMP      T1CHR,#377    ;LAST CHAR?
          BEQ      2$           ;BR IF YES
          INC      T1CHR        ;ELSE BUMP
          BR       3$

2$:      CLR      T1CHR        ;START OVER
          INC      $DEVCT       ;FOR APT
          BIS      #IE,TP1S     ;ALLOW PRINTER INTERR
          RTI

T1CHR:  0
T1HLD:  0
    
```

\*\*\*\*\*  
 :CLUSTER TERMINAL #2 INTERRUPT HANDLER: LOOP VALUES 0 THRU 377.  
 \*\*\*\*\*

```

TP2SRV: BIC      #IE,TP2S      ;DISABLE INTER, RECV'R WILL TURN BACK ON
          MOV      T2CHR,TP2B   ;PRINT CHAR
          RTI

TK2SRV: MOV      TK2B,T2HLD     ;STORE CHAR
          CMP      T2HLD,T2CHR  ;OK?
          BEQ      1$           ;BR IF YES
          ERROR    11          ;CHAR COMP ERROR

1$:      CMP      T2CHR,#377    ;LAST CHAR?
          BEQ      2$           ;BR IF YES
          INC      T2CHR        ;ELSE BUMP
          BR       3$

2$:      CLR      T2CHR        ;START OVER
          INC      $DEVCT       ;FOR APT
          BIS      #IE,TP2S     ;ALLOW PRINTER INTERR
          RTI

T2CHR:  0
T2HLD:  0
    
```

INTERRUPT HANDLERS

3069  
3070  
3071  
3072  
3073  
3074  
3075  
3076  
3077  
3078  
3079  
3080  
3081  
3082  
3083  
3084  
3085  
3086  
3087  
3088  
3089  
3090  
3091  
3092  
3093  
3094  
3095  
3096  
3097  
3098  
3099  
3100  
3101  
3102  
3103  
3104  
3105  
3106  
3107  
3108  
3109  
3110  
3111  
3112  
3113  
3114  
3115  
3116  
3117  
3118  
3119  
3120  
3121

012504 042737 000100 176524  
012512 013737 012600 176526  
012520 000002  
012522 013737 176522 012602  
012530 023737 012602 012600  
012536 001401  
012540 104012  
012542 023727 012600 000377  
012550 001403  
012552 005237 012600  
012556 000404  
012560 005037 012600  
012564 005237 001200  
012570 052737 000100 176524  
012576 000002  
012600 000000  
012602 000000  
012604 042737 000100 176614  
012612 013737 012700 176616  
012620 000002  
012622 013737 176612 012702  
012630 023737 012702 012700  
012636 001401  
012640 104013  
012642 023727 012700 000377  
012650 001403  
012652 005237 012700  
012656 000404  
012660 005037 012700  
012664 005237 001200  
012670 052737 000100 176614  
012676 000002  
012700 000000  
012702 000000

\*\*\*\*\*  
:CLUSTER TERMINAL #3 INTERRUPT HANDLER: LOOP VALUES 0 THRU 377.  
\*\*\*\*\*

TP3SRV: BIC #IE,TP3S ;DISABLE INTER, RECV'R WILL TURN BACK ON  
MOV T3CHR,TP3B ;PRINT CHAR  
RTI  
TK3SRV: MOV TK3B,T3HLD ;STORE CHAR  
CMP T3HLD,T3CHR ;OK?  
BEQ 1\$ ;BR IF YES  
ERROR 12 ;CHAR COMP ERROR  
1\$: CMP T3CHR,#377 ;LAST CHAR?  
BEQ 2\$ ;BR IF YES  
INC T3CHR ;ELSE BUMP  
BR 3\$  
2\$: CLR T3CHR ;START OVER  
INC \$DEVCT ;FOR APT  
3\$: BIS #IE,TP3S ;ALLOW PRINTER INTERR  
RTI  
T3CHR: 0 ;CHAR TO XMITT  
T3HLD: 0 ;REC'D CHAR

\*\*\*\*\*  
:ASYNC COMM PORT INTERRUPT HANDLER: LOOP VALUES 0 THRU 377.  
\*\*\*\*\*

AMXSRV: BIC #IE,AMXC ;DISABLE INTER, RECV'R WILL TURN BACK ON  
MOV COMCHR,AMXB ;XMITT CHAR  
RTI  
AMRSRV: MOV AMRB,COMHLD ;STORE CHAR  
CMP COMHLD,COMCHR ;OK?  
BEQ 1\$ ;BR IF YES  
ERROR 13 ;CHAR COMPARE ERROR  
1\$: CMP COMCHR,#377 ;LAST CHAR?  
BEQ 2\$ ;BR IF YES  
INC COMCHR ;ELSE BUMP  
BR 3\$  
2\$: CLR COMCHR ;START OVER  
INC \$DEVCT ;FOR APT  
3\$: BIS #IE,AMXC ;ALLOW XMIT INTERR  
RTI  
COMCHR: 0 ;XMIT CHAR  
COMHLD: 0 ;REC'D CHAR

3122  
3123  
3124  
3125  
3126  
3127  
3128  
3129  
3130  
3131  
3132  
3133  
3134  
3135  
3136  
3137  
3138  
3139  
3140  
3141  
3142  
3143  
3144  
3145  
3146  
3147  
3148  
3149  
3150  
3151  
3152  
3153  
3154  
3155  
3156  
3157  
3158  
3159  
3160  
3161  
3162  
3163  
3164  
3165  
3166  
3167  
3168

```

:*****
:SYNC COMM PORT INTERRUPT HANDLER: LOOP VALUES 27 THRU 377.
:*****
SMXSRV: BIC      #IE,SMXC      ;DISABLE INTER, RECV'R WILL TURN BACK ON
        MOV      COMCHR,SMXB   ;XMITT CHAR
        CMP      COMCHR,#377   ;LAST CHAR?
        BNE     2$            ;BR IF NO
        TST     LSTCHR
        BNE     1$
        INC     LSTCHR
        BIS     #IE,SMXC      ;ALLOW RDY INTR SO CAN SHUT DOWN FAST
        INC     $DEVCT        ;FOR APT
        RTI
1$:     BIC      #SEND,SMXC    ;NO MORE TO SEND
        INC     $DEVCT        ;FOR APT
2$:     RTI
LSTCHR: 0                      ;SET WHEN LAST CHAR XMIT
SMRSRV: MOV      SMRB,COMHLD   ;STORE CHAR
        CMPB    COMHLD,#026   ;IGNORE SYNC CHARS
        BEQ     4$
        CMP     COMHLD,COMCHR ;OK?
        BEQ     1$           ;BR IF YES
        ERROR   14          ;CHAR COMPARE ERROR
1$:     CMP     COMCHR,#377   ;LAST CHAR?
        BEQ     2$           ;BR IF YES
        INC     COMCHR        ;ELSE BUMP
        BR     3$
2$:     MOV     #-1,COMCHR    ;INDICATE DONE
        BIC     #IE,SMRC     ;ALL DONE
        INC     $DEVCT        ;FOR APT
        BR     4$
3$:     BIS     #IE,SMXC      ;ALLOW XMIT INTERR
4$:     RTI

```

3169  
 3170  
 3171  
 3172  
 3173  
 3174  
 3175  
 3176  
 3177  
 3178  
 3179  
 3180  
 3181  
 3182  
 3183  
 3184  
 3185  
 3186  
 3187  
 3188  
 3189  
 3190  
 3191  
 3192  
 3193  
 3194  
 3195  
 3196  
 3197  
 3198  
 3199  
 3200  
 3201  
 3202  
 3203  
 3204  
 3205  
 3206  
 3207

013074 105737 177170  
 013100 100413  
 013102 013737 177170 013204  
 013110 013737 177172 013206  
 013116 013737 177174 013210  
 013124 104015  
 013126 000002  
 013130 005737 177170  
 013134 100011  
 013136 013737 177170 013204  
 013144 013737 177172 013206  
 013152 013737 177174 013210  
 013160 032737 000020 177170  
 013166 001003  
 013170 000177 000000  
 013174 000000  
 013176 000177 000000  
 013202 000000  
 013204 000C00  
 013206 000000  
 013210 000000

```

:*****
:          DISK INTERRUPT HANDLERS
: ALL DISK INTERRUPTS ENTER THRU RXSRV & DISPATCH TO THE
: CURRENT SERVICE ROUTINE POINTED TO BY:
:          DODISP FOR DX0 INTERRUPTS
:          D1DISP FOR DX1 INTERRUPTS
: WILL GENERALLY BE IN THE ORDER OF SERVICE ROUTINES BELOW.
:*****
    
```

```

RXSRV:  TSTB   RXCS      :CONTR RDY?
        BMI    1$       :BR IF YES
        MOV   RXCS,SRXCS :ELSE SAVE FOR ERROR TYPEOUTS
        MOV   RXES,SRXES
        MOV   RXSA,SRXSA
        ERROR 15       :UNEXPECTED INTERRUPT
        RTI                :GO BACK

1$:    TST    RXCS      :ERROR?
        BPL    2$       :BR IF NO

        MOV   RXCS,SRXCS :ELSE SAVE FOR ERROR TYPEOUTS
        MOV   RXES,SRXES
        MOV   RXSA,SRXSA

2$:    BIT    #USEL,RXCS :CHECK UNIT SELECT BIT
        BNE    D1INT    :BR IF INTER FROM DX1

        JMP    @DODISP  :ELSE DISPATCH TO DX0 SERVICE ROUTINE
DODISP: 0

D1INT:  JMP    @D1DISP  :DX1 INTERRUPT DISPATCH
D1DISP: 0

SRXCS:  0      :SAVE RXCS
SRXES:  0      :SAVE RXES
SRXSA:  0      :SAVE RXSA
    
```

```

3208
3209
3210
3211
3212
3213
3214 013212 012703 000100 DOFBUF: MOV #100,R3 ;WORD CT
3215 013216 013701 002406 MOV D0TRK,R1
3216 013222 000301 SWAB R1
3217 013224 053701 002410 BIS D0SEC,R1
3218 013230 012737 013256 013174 MOV #DOWSEC,DODISP ;POINT TO WRITE SECTOR AFTER RTI
3219 013236 012737 000101 177170 MOV #<FBUF!IE>,RXCS ;ISSUE FILL BUFFER CMD
3220 013244 010137 177172 1$: MOV R1,RXDB ;FILL ENTIRE SECTOR WITH ITS ADDRESS
3221 013250 005303 DEC R3
3222 013252 001374 BNE 1$
3223 013254 000002 RTI
3224
3225
3226
3227
3228
3229
3230
3231
3232
3233 013256 013701 002406 DOWSEC: MOV D0TRK,R1
3234 013262 000301 SWAB R1
3235 013264 053701 002410 BIS D0SEC,R1
3236 013270 010137 177174 MOV R1,RXSA ;LOAD TRACK & SECTOR ADDR
3237 013274 012737 013332 013174 MOV #DOWCHK,DODISP ;POINT TO WRITE CHECK HANDLER
3238 013302 023727 003120 000005 CMP DXTST,#5
3239 013310 001004 BNE 1$
3240 013312 012737 000115 177170 MOV #<WDDSEC!IE>,RXCS ;ONLY FOR WRITE DELETED DATA TEST
3241 013320 000403 BR 2$
3242 013322 012737 000105 177170 1$: MOV #<WSEC!IE>,RXCS ;ISSUE WRITE SECTOR COMMAND
3243 013330 000002 2$: RTI
3244

```

```

3245
3246
3247
3248
3249
3250
3251
3252
3253 013332 005737 177170
3254 013336 100024
3255 013340 023727 002404 000012
3256 013346 001072
3257 013350 004737 011716
3258 013354 032737 000020 013206
3259 013362 001410
3260 013364 104064
3261 013366 012737 013444 013174
3262 013374 012737 000117 177170
3263 013402 000002
3264
3265 013404 104016
3266 013406 000416
3267
3268 013410 005737 002404
3269 013414 001413
3270 013416 005237 025770
3271 013422 005237 025774
3272 013426 032737 000020 013206
3273 013434 001402
3274 013436 104065
3275 013440 000401
3276 013442 104017
3277
3278 013444 005037 002404
3279 013450 023727 002410 000031
3280 013456 001004
3281 013460 012737 000002 002410
3282 013466 000407
3283 013470 023727 002410 000032
3284 013476 001405
3285 013500 062737 000002 002410
3286 013506 000137 013212
3287
3288 013512 012737 000001 002410
3289 013520 005037 002404
3290 013524 005037 002412
3291 013530 000137 013566
3292
3293 013534 005237 002404
3294 013540 032737 000020 013206
3295 013546 001757
3296 013550 012737 013212 013174
3297 013556 012737 000117 177170
3298 013564 000002
3299
3300

```

```

*****
;HANDLER TO WRITE CHECK ON DX0.
;WILL GO TO FILL BUFFER TO DO SAME SECTOR ON SOFT ERROR
;OR NEXT SECTOR ON NO ERROR OR HARD ERROR.
;WILL GO TO READ SECTOR AFTER ALL SECTORS ON TRACK ARE WRITTEN.
;A RESTORE IS PERFORMED AFTER ANY SEEK ERROR (RNF).
*****
DOWCHK: TST      RXCS      ;ERROR?
        BPL      1$        ;BR IN NC
        CMP      DOERR,#10. ;10 ERRORS?
        BNF      6$        ;BR IF NO & TRY AGAIN
        JSR      PC,LDOBAD  ;LOAD BAD TRK/SEC TABLE
        BIT      #RNF,SRXES ;SEEK ERROR?
        BEQ      7$        ;BR IF NO
        ERROR    64        ;HARD SEEK ERROR WRITE SECTOR
        MOV      #2$,DODISP ;GO TO 2$ AFTER RESTORE
        MOV      #<RESTOR!IE>,RXCS
        RTI
7$:      ERROR    16        ;HARD ERROR WRITE SECTOR
        BR       2$        ;GO TO NEXT SECTOR
1$:      TST      DOERR     ;ANY PREV ERRORS?
        BEQ      2$        ;BR IF NO
        INC      TSERR     ;TOTAL SOFT ERR CT
        INC      PSERR     ;PASS SOFT ERR CT
        BIT      #RNF,SRXES ;SEEK ERROR?
        BEQ      8$        ;BR IF NO
        ERROR    65        ;SOFT SEEK ERROR WRITE SECTOR
        BR       2$
8$:      ERROR    17        ;SOFT ERROR WRITE SECTOR
2$:      CLR      DOERR     ;LAST ODD SECTOR?
        CMP      DOSEC,#31  ;BR IF NO
        BNE      3$        ;ELSE DO EVEN SECTORS NOW
        MOV      #2,DOSEC
        BR       4$
3$:      CMP      DOSEC,#32 ;LAST EVEN SECTOR?
        BEQ      5$        ;BR IF YES
        ADD      #2,DOSEC   ;ELSE BUMP SECTOR
        JMP      DOFBUF    ;GO TO FILL BUFFER & DO ANOTHER
5$:      MOV      #1,DOSEC  ;ALL SECTORS DONE...CHECK DATA
        CLR      DOERR
        CLR      DCCMER
        JMP      DORSEC    ;GO TO READ SECTOR HANDLER
6$:      INC      DOERR
        BIT      #RNF,SRXES ;SEEK ERROR?
        BEQ      4$        ;BR IN NO
        MOV      #DOFBUF,DODISP ;GOTO FILL BUFF AFTER RESTORE
        MOV      #<RESTOR!IE>,RXCS
        RTI

```



```

3301
3302
3303
3304
3305 013566 013701 002406 DORSEC: MOV D0TRK,R1
3306 013572 000301 SWAB R1
3307 013574 053701 002410 BIS D0SEC,R1
3308 013600 010137 177174 MOV R1,RXSA ;LOAD TRK & SECTOR ADDR
3309
3310 013604 012737 013622 013174 MOV #DORCHK,DODISP ;POINT TO READ CHECK HANDLER
3311 013612 012737 000107 177170 MOV #<RSEC!IE>,RXCS ;ISSUE READ SECTOR COMMAND
3312 013620 000002 RTI
3313
3314
3315
3316
3317
3318
3319
3320
3321
3322
3323 013622 005737 177170 DORCHK: TST RXCS ;ERROR?
3324 013626 100054 BPL 1$ ;BR IF NO
3325 013630 023727 002404 000012 CMP DOERR,#10. ;10 ERRORS?
3326 013636 001415 BEQ 3$ ;BR IF YES
3327 013640 005237 002404 INC DOERR ;ELSE DO AGAIN
3328 013644 032737 000020 013206 BIT #RNF,SRXES ;SEEK ERROR?
3329 013652 001745 BEQ DORSEC ;BR IF NO
3330 013654 012737 013566 013174 MOV #DORSEC,DODISP ;ELSE DO RESTORE & RET TO RD SEC
3331 013662 012737 000117 177170 MOV #<RESTOR!IE>,RXCS
3332 013670 000002 RTI
3333
3334 013672 004737 011716 3$: JSR PC,!DOBAD ;LOAD BAD TRK/SEC TABLE
3335 013676 032737 000020 013206 BIT #RNF,SRXES ;SEEK ERROR?
3336 013704 001410 BEQ 7$ ;BR IF NO
3337 013706 104066 ERROR 66 ;SEEK ERROR READ SECTOR
3338
3339 013710 012737 014610 013174 MOV #DONEXT,DODISP ;DO RESTORE
3340 013716 012737 000117 177170 MOV #<RESTOR.IE>,RXCS
3341 013724 000002 RTI
3342
3343 013726 032737 000010 013206 7$: BIT #CRC,SRXES ;CRC ERROR?
3344 013734 001404 BEQ 10$ ;BR IF NO
3345 013736 005237 002422 INC D0CRC ;ELSE SET FLAG
3346 013742 104106 ERROR 106 ;HARD CRC ERROR
3347 013744 000423 BR 2$ ;& GO TO EMP BUFF TO CHK DATA
3348
3349 013746 005037 002422 10$: CLR D0CRC
3350 013752 104020 ERROR 20 ;HARD READ ERROR
3351 013754 000137 014610 JMP DONEXT
    
```

```

3352
3353 013760 005737 002404 1$: TST DOERR ;ANY PREV ERRORS?
3354 013764 001413 BEQ 2$ ;BR IF NO
3355 013766 005237 025770 INC TSERR ;TOTAL SOFT ERR CT
3356 013772 005237 025774 INC PSERR ;PASS SOFT ERR CT
3357 013776 032737 000020 013206 BIT #RNF,SRXES ;SEEK ERROR?
3358 014004 001402 BEQ 9$ ;BR IF NO
3359 014006 104067 ERROR 67 ;SEEK ERROR READ SECTOR
3360 014010 000401 BR 2$
3361 014012 104021 9$: ERROR 21 ;SOFT ERROR READ SECTOR
3362
3363 014014 005037 002404 2$: CLR DOERR
3364 014020 023727 003120 000005 CMP DXTST,#5 ;DOING WRITE DELETED DATA TESTS?
3365 014026 001005 BNE 6$ ;BR IF NO
3366 014030 032737 000040 177172 BIT #DD,RXES ;'DELETED DATA' SET?
3367 014036 001001 BNE 6$ ;BR IF YES
3368 014040 104052 ERROR 52 ;DD NOT SET
3369
3370 014042 000137 014046 6$: JMP DC'BUF ;GO TO EMPTY BUFFER
3371
3372
3373
3374
3375
3376
3377
3378 ;*****
3379 ; HANDLER TO EMPTY THE DRIVE BUFFER FOR DXO
3380 ; & POINT TO THE CHECK DATA HANDLER.
3381 ;*****
3382 014046 012703 000100 DOEBUF: MOV #100,R3 ;WORD CT
3383 014052 012701 002424 MOV #DOBUF,R1 ;BUFFER ADDRESS
3384 014056 012737 014104 013174 MOV #DOCDAT,DODISP ;POINT TO CHK DATA AFT INTER.
3385 014064 012737 000103 177170 MOV #<EBUF!IE>,RXCS ;ISSUE EMPTY BUFFER CMD
3386 014072 013721 177172 1$: MOV RXDB,(R1)+ ;GET WORD & STORE IT
3387 014076 005303 DEC R3
3388 014100 001374 BNE 1$
3389 014102 000002 RTI
3390
3391
    
```

```
3392
3393
3394
3395
3396
3397
3398
3399 014104 005037 002412
3400 014110 012703 000100
3401 014114 013701 002406
3402 014120 000301
3403 014122 053701 002410
3404 014126 012702 002424
3405 014132 020112
3406 014134 001407
3407 014136 010137 002416
3408 014142 011237 00242C
3409 014146 005237 002412
3410 014152 000405
3411
3412 014154 005303
3413 014156 001403
3414 014160 062702 000002
3415 014164 000762
3416
3417 014166 005737 002412
3418 014172 001421
3419 014174 005737 002422
3420 014200 001402
3421 014202 104107
3422 014204 000431
3423
3424 014206 023727 002414 000012
3425 014214 001033
3426 014216 023727 003120 000003
3427 014224 001002
3428 014226 104053
3429 014230 000417
3430
3431 014232 104022
3432 014234 000415
3433
3434 014236 005737 002422
3435 014242 001402
3436 014244 104110
3437 014246 000410
3438
3439 014250 005737 002414
3440 014254 001405
3441 014256 005237 025770
3442 014262 005237 025774
3443 014266 104023

:*****
: HANDLER TO CHECK DATA AFTER EMPTY BUFFER CMD ON DX0.
: WILL GO TO NEXT SECTOR HANDLER WHEN NO ERR OR HARD ERR.
: OR TO READ SECTOR (SAME) WHEN SOFT ERR.
: THIS ROUTINE IS ALSO ENTERED FROM A CRC ERROR FROM A READ COMMAND.
:*****
DOCDAT: CLR      DOCMER
          MOV     #100,R3      ;WORD CTR
          MOV     D0TRK,R1
          SWAB    R1
          BIS     D0SEC,R1     ;R1 NOW HAS EXPECTED DATA
          MOV     #D0BUF,R2    ;GET BUFFER ADDR
1$:      CMP     R1,(R2)       ;COMPARE OK?
          BEQ     2$           ;BR IF YES
          MOV     R1,D0EXP     ;ELSE SAVE
          MOV     (R2),D0REC
          INC     DOCMER
          BR     3$
2$:      DEC     R3
          BEQ     3$
          ADD     #2,R2
          BR     1$
3$:      TST     DOCMER       ;ANY COMP ERR?
          BEQ     4$           ;BR IF NO
          TST     D0CRC       ;HERE FROM CRC ERROR?
          BEQ     14$          ;BR IF NO
          ERROR  107          ;DATA CRC ERROR
          BR     5$
14$:     CMP     D0CERR,#10.   ;ELSE, 10 ERRS YET?
          BNE     7$           ;BR IF NO
          CMP     DXTST,#3     ;DOING INIT TEST?
          BNE     8$           ;BR IN NO
          ERROR  53           ;INITIALIZE ERROR
          BR     5$
8$:      ERROR  22           ;HARD ERROR DATA COMPARE
          BR     5$
4$:      TST     D0CRC       ;HERE FROM CRC ERROR?
          BEQ     15$          ;BR IF NO
          ERROR  110          ;CRC ERR WITH DATA OK
          BR     5$
15$:     TST     D0CERR       ;ANY PREV ERR?
          BEQ     5$           ;BR IF NO
          INC     TSERR       ;TOTAL SOFT ERR CT
          INC     PSERR       ;PASS SOFT ERR CT
          ERROR  23           ;SOFT ERROR DATA COMP
```

```

3444
3445 014270 005037 002414      5$:   CLR   DOCERR
3446 014274 005037 002422           CLR   DOCRC
3447 014300 000137 014610           JMP   DONEXT
3448
3449 014304 005237 002414      7$:   INC   DOCERR
3450 014310 023727 003120 000003  CMP   DXST,#3      ;DOING INIT TEST?
3451 014316 001402           BEQ   12$          ;BR IF YES
3452 014320 000137 013566           JMP   DORSEC      ;ELSE READ SECTOR OVER AGAIN
3453
3454 014324 000137 014746     12$:   JMP   DODUN      ;ALL DONE
3455
3456
3457
3458
3459
3460
3461
3462
3463
3464
3465 014330 005037 002404     DONXT1: CLR   DOERR
3466 014334 005037 002412           CLR   DOCMER
3467 014340 023727 002410 000031  CMP   DOSEC,#31   ;LAST ODD SECTOR?
3468 014346 001004           BNE   1$          ;BR IF NO
3469 014350 012737 000002 002410  MOV   #2,DOSEC    ;ELSE DO EVEN SECTORS NOW
3470 014356 000407           BR    2$
3471 014360 023727 002410 000032 1$:   CMP   DOSEC,#32   ;LAST EVEN SECTOR?
3472 014366 001405           BEQ   3$          ;BR IF YES
3473 014370 062737 000002 002410  ADD   #2,DOSEC    ;ELSE BUMP SECTOR
3474 014376 000137 013566     2$:   JMP   DORSEC      ;GO READ SECTOR
3475
3476 014402 032777 010000 164530 3$:   BIT   #BIT12,@SWR ;SKIP TYPEOUT IF NOT SET
3477 014410 001411           BEQ   6$
3478 014412 104401 017232           TYPE  ,DRVO
3479 014416 104401 017705           TYPE  ,TRK
3480 014422 013746 002406           MOV   DOTRK,-(SP) ;:SAVE DOTRK FOR TYPEOUT
3481 014426 104405           TYPDS ;:GO TYPE--DECIMAL ASCII WITH SIGN
3482 014430 104401 017756           TYPE  ,DUN
3483 014434 005237 003122     6$:   INC   FIN        ;SETUP TO GO TO DX1
3484 014440 023737 002406 003124  CMP   DOTRK,MAXTRK ;:LAST TRACK?
3485 014446 001406           BEQ   4$          ;BR IF YES
3486 014450 005237 002406           INC   DOTRK      ;BUMP TRACK
3487 014454 012737 000001 002410  MOV   #1,DOSEC    ;INIT SECTOR
3488 014462 000414           BR    5$
3489
3490 014464 032777 010000 164446 4$:   BIT   #BIT12,@SWR ;SKIP TYPEOUT IF NOT SET
3491 014472 001406           BEQ   7$
3492 014474 104401 017232           TYPE  ,DRVO
3493 014500 104401 017712           TYPE  ,PATT
3494 014504 104401 017756           TYPE  ,DUN
3495 014510 005237 002400     7$:   INC   DOPAT      ;PATT DONE FLAG
3496 014514 042737 000100 177170 5$:   BIC   #IE,RXCS   ;DISABLE DX0 INTERRUPTS
3497 014522 000002           RTI
    
```

3498  
3499  
3500  
3501  
3502  
3503  
3504  
3505  
3506  
3507  
3508  
3509  
3510  
3511  
3512  
3513  
3514  
3515  
3516  
3517  
3518  
3519  
3520  
3521  
3522  
3523  
3524  
3525  
3526

014524 005037 002404  
014530 005037 002412  
014534 005237 003122  
014540 005237 002402  
014544 023737 002402 003126  
014552 001012  
014554 032777 010000 164356  
014562 001406  
014564 104401 017232  
014570 104401 017725  
014574 104401 017756  
014600 042737 000100 177170 \$:  
014606 000002  
  
  
  
  
  
  
  
  
  
  
014610 023727 003120 000001  
014616 001644  
014620 023727 003120 000002  
014626 001736  
014630 000446

\*\*\*\*\*  
:HANDLER TO SETUP TO GO TO NEXT RANDOM TRACK/SECTOR FOR DX0.  
\*\*\*\*\*

```
DONXT2: CLR      DOERR  
        CLR      DOCMER  
        INC      FIN          ;SETUP TO GO TO DX1  
        INC      DDCNT  
        CMP      DDCNT,MAXSK ;DID ALL SEEKS?  
        BNE      1$          ;BR IF NO  
        BIT      #BIT12,@SWR ;SKIP TYPEOUT IF NOT SET  
        BEQ      1$  
        TYPE     ,DRV0  
        TYPE     ,RANDOM  
        TYPE     ,DUN  
        BIC      #IE,RXCS    ;DISABLE DX0 INTERRUPTS  
        RTI
```

```
DONEXT: CMP      DXTST,#1  
        BEQ      DONXT1  
        CMP      DXTST,#2  
        BEQ      DONXT2  
        BR       DODUN
```

```
3527
3528
3529      :*****
3530      :HANDLER TO SETUP INITIALIZE COMMAND TEST
3531      :*****
3532 014632 012737 046032 177174 DOINIT: MOV      #46032,RXSA      ;TRY TO FAKE DRIVE TO GO TO TRK 76 SEC 26
3533                                     ;INIT SHOULD GO TO TRK 1, SEC 1.
3534 014640 012737 014746 013174         MOV      #DODUN,DODISP ;POINT TO DONE HANDLER
3535 014646 012737 000111 177170         MOV      #<INITAL!IE>,RXCS ;DO INIT COMMAND
3536 014654 000002
3537
3538
3539      :*****
3540      :HANDLERS TO SETUP RESTORE COMMAND TEST
3541      :*****
3542
3543 014656 012737 014746 013174 DOREST: MOV      #DODUN,DODISP ;POINT TO DONE HANDLER
3544 014664 012737 000117 177170         MOV      #<RESTOR!IE>,RXCS
3545 014672 000002
3546
3547 014674 012737 014762 013202 DIREST: MOV      #D1DUN,D1DISP
3548 014702 012737 000137 177170         MOV      #<RESTOR!IE!DX1>,RXCS
3549 014710 000002
3550
3551      :*****
3552      :HANDLER TO SETUP READ STATUS COMMAND TEST
3553      :*****
3554
3555 014712 012737 014746 013174 DOSTAT: MOV      #DODUN,DODISP ;POINT TO DONE
3556 014720 012737 000113 177170         MOV      #<RSTAT!IE>,RXCS ;DO READ STATUS COMMAND
3557 014726 000002
3558
3559      :*****
3560      :HANDLER TO START INVALID ADDRESS TESTS
3561      :*****
3562
3563 014730 012737 014746 013174 DUINV:  MOV      #DODUN,DODISP ;POINT TO DONE
3564 014736 012737 000105 177170         MOV      #<WSEC!IE>,RXCS ;DO WRITE SECTOR COMMAND
3565 014744 000002
3566
3567
3568      :*****
3569      :HANDLERS TO FINISH INITIALIZE, RESTORE, WRITE DELETED DATA,
3570      :READ STATUS & INVALID ADDRESS TESTS.
3571      :*****
3572
3573 014746 005237 003122 DODUN:  INC      FIN      ;SET DONE FLAG
3574 014752 042737 000100 177170         BIC      #IE,RXCS      ;DISABLE FURTHUR DX0 INTERRUPTS
3575 014760 000002
3576
3577 014762 005237 003122 D1DUN:  INC      FIN
3578 014766 042737 000120 177170         BIC      #<IE!DX1>,RXCS
3579 014774 000002
3580
```

```

3581
3582
3583
3584
3585
3586
3587
3588 014776 012703 00010C D1FBUF: MOV #100,R3 ;WORD CT
3589 015002 013701 002656 MOV D1TRK,R1
3590 015006 000301 SWAB R1
3591 015010 053701 002660 BIS D1SEC,R1
3592
3593 015014 005737 003132 TST COMP1 ;DONT SET BIT15 IN COMPATABILITY TESTS
3594 015020 001005 BNE 2$
3595 015022 005737 003134 TST COMP2
3596 015026 001002 BNE 2$
3597 015030 052701 100000 BIS #BIT15,R1 ;TO DISTINGUISH DX1 DATA FROM DX0 DATA
3598
3599 015034 012737 015062 013202 2$: MOV #D1WSEC,D1DISP ;POINT TO WRITE SECTOR AFTER R1I
3600 015042 012737 000121 177170 MOV #<FBUF!IE!DX1>,RXCS ;ISSUE FILL BUFFER CMD
3601 015050 010137 177172 1$: MOV R1,RXDB ;FILL ENTIRE SECTOR WITH ITS ADDRESS
3602 015054 005303 DEC R3 ;& BIT 15 SET
3603 015056 001374 BNE 1$
3604 015060 000002 RTI
3605
3606
3607
3608
3609
3610
3611 015062 013701 002656 D1WSEC: MOV D1TRK,R1
3612 015066 000301 SWAB R1
3613 015070 053701 002660 BIS D1SEC,R1
3614 015074 010137 177174 MOV R1,RXSA ;LOAD TRACK & SECTOR ADDR
3615 015100 012737 015116 013202 MOV #D1WCHK,D1DISP ;POINT TO WRITE CHECK HANDLER
3616 015106 012737 000125 177170 MOV #<WSEC!IE!DX1>,RXCS ;ISSUE WRITE SECTOR COMMAND
3617 015114 000002 RTI
3618

```

```
3619
3620
3621
3622
3623
3624
3625
3626
3627 015116 005737 177170          D1WCHK: TST      RXCS      ;ERROR?
3628 015122 100024          BPL      1$           ;BR IN NC
3629 015124 023727 002654 000012  CMP      D1ERR,#10.   ;10 ERRORS?
3630 015132 001072          BNE      6$           ;BR IF NO & TRY AGAIN
3631 015134 004737 012030          JSR      PC,LD1BAD    ;LOAD BAD TRK/SEC TABLE
3632 015140 032737 000020 013206  BIT      #RNF,SRXES  ;SEEK ERROR?
3633 015146 001410          BEQ      7$           ;BR IF NO
3634 015150 104070          ERROR   70           ;SEEK ERROR WRITE SECTOR
3635 015152 012737 015230 013202  MOV      #2$,D1DISP  ;RET TO 2$ AFT RESTORE
3636 015160 012737 000137 177170  MOV      #<RESTOR!IE!DX1>,RXCS
3637 015166 000002          RTI
3638
3639 015170 104024          7$:  ERROR   24       ;ERROR WRITE SECTOR
3640 015172 000416          BR      2$           ;GO TO NEXT SECTOR
3641
3642 015174 005737 002654          1$:  TST      D1ERR    ;ANY PREV ERRORS?
3643 015200 001413          BEQ      2$           ;BR IF NO
3644 015202 005237 025770          INC      TSERR      ;TOTAL SOFT ERR CT
3645 015206 005237 025774          INC      PSERR      ;PASS SOFT ERR CT
3646 015212 032737 000020 013206  BIT      #RNF,SRXES  ;SEEK ERROR?
3647 015220 001402          BEQ      8$           ;BR IF NO
3648 015222 104071          ERROR   71           ;SEEK ERROR WRITE SECTOR
3649 015224 000401          BR      2$           ;SEEK ERROR WRITE SECTOR
3650 015226 104025          8$:  ERROR   25       ;ERROR WRITE SECTOR
3651
3652 015230 005037 002654          2$:  CLR      D1ERR    ;LAST ODD SECTOR?
3653 015234 023727 002660 000031  CMP      D1SEC,#31   ;BR IF NO
3654 015242 001004          BNE      3$           ;ELSE DO EVEN SECTORS NOW
3655 015244 012737 000002 002660  MOV      #2,D1SEC
3656 015252 000407          BR      4$           ;LAST EVEN SECTOR?
3657 015254 023727 002660 000032  3$:  CMP      D1SEC,#32 ;BR IF YES
3658 015262 001405          BEQ      5$           ;ELSE BUMP SECTOR
3659 015264 062737 000002 002660  ADD      #2,D1SEC    ;GO TO FILL BUFFER & DO ANOTHER
3660 015272 000137 014776          4$:  JMP      D1FBUF
3661
3662 015276 012737 000001 002660  5$:  MOV      #1,D1SEC   ;ALL SECTORS DONE...CHECK DATA
3663 015304 005037 002654          CLR      D1ERR
3664 015310 005037 002662          CLR      D1CMER
3665 015314 000137 015352          JMP      D1RSEC     ;GO TO READ SECTOR HANDLER
3666
3667 015320 005237 002654          6$:  INC      D1ERR
3668 015324 032737 000020 013206  BIT      #RNF,SRXES  ;SEEK ERROR?
3669 015332 001757          BEQ      4$           ;BR IF NO
3670 015334 012737 014776 013202  MOV      #D1FBUF,D1DISP ;RET TO FILL BUFF AFT RESTORE
3671 015342 012737 000137 177170  MOV      #<RESTOR!IE.DX1>,RXCS
3672 015350 000002          RTI
3673
3674
```



```

3675 ;HANDLER TO READ A SECTOR ON DX1 & POINT TO CHECK.
3676 ;:*****
3677
3678 015352 013701 002656 D1RSEC: MOV D1TRK,R1
3679 015356 000301 SWAB R1
3680 015360 053701 002660 BIS D1SEC,R1
3681 015364 010137 177174 MOV R1,RXSA ;LOAD TRK & SECTOR ADDR
3682
3683 015370 012737 015406 013202 MOV #D1RCHK,D1DISP ;POINT TO READ CHECK HANDLER
3684 015376 012737 000127 177170 MOV #<RSEC!IE!DX1>,RXCS ;ISSUE READ SECTOR COMMAND
3685 015404 000002 RTI
3686
3687
3688
3689 ;:*****
3690 ;HANDLER TO READ CHECK ON DX1.
3691 ;WILL GO TO NEXT SECTOR/TRK IF HARD ERROR.
3692 ;WILL GO TO EMPTY BUFFER IF NO ERROR OR SOFT ERROR.
3693 ;WILL GO TO READ SECTOR (SAME) ON ERROR.
3694 ;A RESTORE IS PERFORMED AFTER ANY SEEK ERROR (RNF).
3695 ;:*****
3696
3697 015406 005737 177170 D1RCHK: TST RXCS ;ERROR?
3698 015412 100054 BPL 1$ ;BR IF NO
3699 015414 023727 002654 000012 CMP D1ERR,#10. ;10 ERRORS?
3700 015422 001415 BEQ 3$ ;BR IF YES
3701 015424 005237 002654 INC D1ERR ;ELSE TRY AGAIN
3702 015430 032737 000020 013206 BIT #RNF,SRXES ;SEEK ERROR?
3703 015436 001745 BEQ D1RSEC ;BR IF NO
3704 015440 012737 015352 013202 MOV #D1RSEC,D1DISP ;ELSE DO RESTORE & RET TO RD SEC
3705 015446 012737 000137 177170 MOV #<RESTOR!IE!DX1>,RXCS
3706 015454 000002 RTI
3707
3708 015456 004737 012030 3$: JSR PC,!D1BAD ;LOAD BAD TRK/SEC TABLE
3709 015462 032737 000020 013206 BIT #RNF,SRXES ;SEEK ERROR?
3710 015470 001410 BEQ 7$ ;BR IF NO
3711 015472 104072 ERROR 72 ;SEEK ERROR READ SECTOR
3712
3713 015474 012737 016342 013202 MOV #D1NEXT,D1DISP ;DO RESTORE
3714 015502 012737 000137 177170 MOV #<RESTOR!IE!DX1>,RXCS
3715 015510 000002 RTI
3716
3717 015512 032737 000010 013206 7$: BIT #CRC,SRXES ;CRC ERROR?
3718 015520 001404 BEQ 10$ ;BR IF NO
3719 015522 005237 002672 INC D1CRC ;ELSE SET FLAG
3720 015526 104111 ERROR 111 ;HARD CRC ERROR
3721 015530 000423 BR 2$ ;& GO TO EMP BUFF TO CHK DATA
3722
3723 015532 005037 002672 10$: CLR D1CRC
3724 015536 104026 ERROR 26 ;HARD READ ERROR
3725 015540 000137 016342 JMP D1NEXT

```

```

3726
3727 015544 005737 002654      1$:   TST      D1ERR      ;ANY PREV ERRORS?
3728 015550 001413              BEQ      2$           ;BR IF NO
3729 015552 005237 025770      INC      TSERR        ;TOTAL SOFT ERR CT
3730 015556 005237 025774      INC      PSERR        ;PASS SOFT ERR CT
3731 015562 032737 000020 013206 BIT      #RNF,SRXES   ;SEEK ERROR?
3732 015570 001402              BEQ      9$           ;BR IF NO
3733 015572 104073              ERROR   73           ;SEEK ERROR READ SECTOR
3734 015574 000401              BR       2$           ;
3735 015576 104027      9$:   ERROR   27           ;SOFT ERROR READ SECTOR
3736
3737 015600 005037 002654      2$:   CLR      D1ERR      ;
3738 015604 000137 015610      JMP      D1EBUF      ;GO TO EMPTY BUFFER
3739
3740
3741
3742
3743
3744
3745
3746
3747
3748
3749
3750 015610 012703 000100      D1EBUF: MOV      #100,R3      ;WORD CT
3751 015614 012701 002674      MOV      #D1BUF,R1      ;BUFFER ADDRESS
3752 015620 012737 015646 013202 MOV      #D1CDAT,D1DISP ;POINT TO CHK DATA AFT INTER.
3753 015626 012737 000123 177170 MOV      #<EBUF!IE.DX1>,RXCS ;ISSUE EMPTY BUFFER CMD
3754 015634 013721 177172      1$:   MOV      RXDB,(R1)+ ;GET WORD & STORE IT
3755 015640 005303              DEC      R3
3756 015642 001374              BNE     1$
3757 015644 000002              RTI
3758

```

```
3759  
3760  
3761  
3762  
3763  
3764  
3765  
3766 015646 005037 002662  
3767 015652 012703 000100  
3768 015656 013701 002656  
3769 015662 000301  
3770 015664 053701 002660  
3771  
3772 015670 005737 003132  
3773 015674 001005  
3774 015676 005737 003134  
3775 015702 001002  
3776 015704 052701 100000  
3777  
3778 015710 012702 002674  
3779 015714 020112  
3780 015716 001407  
3781 015720 010137 002666  
3782 015724 011237 002670  
3783 015730 005237 002662  
3784 015734 000405  
3785 015736 005303  
3786 015740 001403  
3787 015742 062702 000002  
3788 015746 000762  
3789  
3790 015750 005737 002662  
3791 015754 001413  
3792 015756 005737 002672  
3793 015762 001402  
3794 015764 104112  
3795 015766 000423  
3796 015770 023727 002664 0000^2  
3797 015776 001025  
3798 016000 104030  
3799 016002 000415  
3800  
3801 016004 005737 002672  
3802 016010 001402  
3803 016012 104113  
3804 016014 000410  
3805 016016 005737 002664  
3806 016022 001405  
3807 016024 005237 025770  
3808 016030 005237 025774  
3809 016034 104031
```

```
*****  
: HANDLER TO CHECK DATA AFTER EMPTY BUFFER CMD ON DX1.  
: WILL GO TO NEXT SECTOR HANDLER WHEN NO ERR OR HARD ERR.  
: OR TO READ SECTOR (SAME) WHEN SOFT ERR.  
: THIS ROUTINE IS ALSO ENTERED FROM A CRC ERROR FROM A READ COMMAND.  
: *****  
D1CDAT: CLR      D1CMER  
        MOV      #100,R3      ;WORD CTR  
        MOV      D1TRK,R1  
        SWAB     R1  
        BIS      D1SEC,R1  
  
        TST      COMP1      ;DONT SET BIT15 IN COMPATABILITY TESTS  
        BNE     6$  
        TST      COMP2  
        BNE     6$  
        BIS      #BIT15,R1  ;TO DISTINGUISH DX1 DATA FROM DX0 DATA  
  
6$:    MOV      #D1BUF,R2      ;GET BUFFER ADDR  
1$:    CMP      R1,(R2)      ;COMPARE OK?  
        BEQ     2$          ;BR IF YES  
        MOV      R1,D1EXP  
        MOV      (R2),D1REC  ;ELSE SAVE  
        INC     D1CMER  
        BR     3$  
  
2$:    DEC      R3  
        BEQ     3$  
        ADD     #2,R2  
        BR     1$  
  
3$:    TST      D1CMER      ;ANY COMP ERR?  
        BEQ     4$          ;BR IF NO  
        TST      D1CRC      ;HERE FROM CRC ERROR?  
        BEQ     14$        ;BR IF NO  
        ERROR   112        ;DATA CRC ERROR  
        BR     5$  
  
14$:   CMP      D1CERR,#10.  ;ELSE, 10 ERRS YET?  
        BNE     7$          ;BR IF NO  
        ERROR   30         ;HARD ERROR DATA COMP  
        BR     5$  
  
4$:    TST      D1CRC      ;HERE FROM CRC ERROR?  
        BEQ     15$        ;BR IF NO  
        ERROR   113        ;CRC ERR WITH DATA OK  
        BR     5$  
  
15$:   TST      D1CERR      ;ANY ERR?  
        BEQ     5$  
        INC     TSERR      ;TOTAL SOFT ERR CT  
        INC     PSERR      ;PASS SOFT ERR CT  
        ERROR   31         ;SOFT ERROR DATA COMP
```

```

3810
3811 016036 005037 002664      5$:   CLR   D1CERR
3812 016042 005037 002672      CLR   D1CRC
3813 016046 000137 016342      JMP   D1NEXT
3814
3815 016052 005237 002664      7$:   INC   D1CERR
3816 016056 000137 015352      JMP   D1RSEC      ;READ SECTOR OVER AGAIN
3817
3818
3819
3820
3821
3822
3823
3824
3825
3826 016062 005037 002654      D1NXT1: CLR   D1ERR
3827 016066 005037 002662      CLR   D1CMER
3828 016072 023727 002660 000031      CMP   D1SEC,#31      ;LAST ODD SECTOR?
3829 016100 001004      BNE   1$             ;BR IF NO
3830 016102 012737 000002 002660      MOV   #2,D1SEC      ;ELSE DO EVEN SECTORS NOW
3831 016110 000407      BR    2$
3832 016112 023727 002660 000032 1$:   CMP   D1SEC,#32      ;LAST EVEN SECTOR?
3833 016120 001405      BEQ   3$             ;BR IF YES
3834 016122 062737 000002 002660      ADD   #2,D1SEC      ;ELSE BUMP SECTOR
3835 016130 000137 015352      2$:   JMP   D1RSEC      ;GO READ SECTOR
3836
3837 016134 032777 010000 162776 3$:   BIT   #BIT12,@SWR   ;SKIP TYPEOUT IF NOT SET
3838 016142 001411      BEQ   6$
3839 016144 104401 017237      TYPE  ,DRV1
3840 016150 104401 017705      TYPE  ,TRK
3841 016154 013746 002656      MOV   D1TRK,-(SP)   ;;SAVE D1TRK FOR TYPEOUT
3842 016160 104405      TYPDS ;;GO TYPE--DECIMAL ASCII WITH SIGN
3843 016162 104401 017756      TYPE  ,DUN
3844 016166 005237 003122      6$:   INC   FIN           ;SETUP TO GO TO DX0
3845 016172 023737 002656 003124      CMP   D1TRK,MAXTRK ;LAST TRACK?
3846 016200 001406      BEQ   4$             ;BR IF YES
3847 016202 005237 002656      INC   D1TRK         ;BUMP TRACK
3848 016206 012737 000001 002660      MOV   #1,D1SEC      ;INIT SECTOR
3849 016214 000414      BR    5$
3850
3851 016216 032777 010000 162714 4$:   BIT   #BIT12,@SWR   ;SKIP TYPEOUT IF NOT SET
3852 016224 001406      BEQ   7$
3853 016226 104401 017237      TYPE  ,DRV1
3854 016232 104401 017712      TYPE  ,PATT
3855 016236 104401 017756      TYPE  ,DUN
3856 016242 005237 002650      7$:   INC   D1PAT        ;PATT DONE FLAG
3857 016246 042737 000120 177170 5$:   BIC   #<IE.DX1>,RXCS ;DISABLE DX1 INTERRUPTS
3858 016254 000002      RTI
3859

```

3860  
3861  
3862  
3863  
3864  
3865  
3866  
3867  
3868  
3869  
3870  
3871  
3872  
3873  
3874  
3875  
3876  
3877  
3878  
3879  
3880  
3881  
3882  
3883  
3884  
3885

016256 005037 002654  
016262 005037 002662  
016266 005237 003122  
016272 005237 002652  
016276 023737 002652 003126  
016304 001012  
016306 032777 010000 162624  
016314 001406  
016316 104401 017237  
016322 104401 017725  
016326 104401 017756  
016332 042737 000120 177170  
016340 000002  
  
016342 023727 003120 000001  
016350 001644  
016352 000741

\*\*\*\*\*  
HANDLER TO SETUP TO GO TO NEXT RANDOM TRACK/SECTOR FOR DX1.  
\*\*\*\*\*

```
D1NX12: CLR      D1ERR
          CLR      D1CMER
          INC      FIN          ;SETUP TO GO TO DX0
          INC      D1CNT
          CMP      D1CNT,MAXSK ;DID ALL SEEKS?
          BNE     1$          ;BR IF NO
          BIT     #BIT12,@SWR ;SKIP TYPEOUT IF NOT SET
          BEQ     1$
          TYPE    ,DRV1
          TYPE    ,RANDOM
          TYPE    ,DUN
          BIC     #<IE.DX1>,RXCS ;DISABLE DX1 INTERRUPTS
          RTI
```

```
D1NEXT: CMP      DXTST,#1
          BEQ     D1NXT1
          BR      D1NXT2
```

```

3886
3887
3888
3889
3890
3891
3892
3893
3894
3895 016354 005037 003130
3896 016360 104401 020155
3897 016364 000000
3898
3899 016366 004737 016674
3900
3901 016372 005037 016666
3902 016376 012737 000001 016670
3903 016404 012737 000001 016672
3904 016412 105737 177170
3905 016416 100375
3906
3907 016420 004537 016744
3908 016424 000007
3909
3910 016426 005737 177170
3911 016432 100011
3912 016434 005237 016666
3913 016440 023727 016666 000012
3914 016446 001364
3915 016450 104100
3916 016452 000000
3917 016454 000776
3918
3919 016456 005037 016666
3920 016462 004537 017004
3921 016466 002424
3922
3923 016470 004537 016744
3924 016474 000025
3925
3926 016476 005737 177170
3927 016502 100011
3928 016504 005237 016666
3929 016510 023727 016666 000012
3930 016516 001364
3931 016520 104101
3932 016522 000000
3933 016524 000776

```

```

:*****
:THE FOLLOWING CODE, UP TO THE PROGRAM MESSAGES, IS A UTILITY TO COPY
:THE DISKETTE CONTAINING ONLY THE BOOT & THE EXERCISER FROM DX0 TO DX1.
:THE OPERATOR CAN TYPE 'P' TO DO ANOTHER COPY OR
:TYPE '240G' TO ENTER NORMAL TESTING.
:ENTIRE CODE, INCLUDING TEXT & ERROR TABLE, IS 400(10) WORDS.
:*****
COPY:  CLR      COPFLG      ;DONT NEED FLAG ANY MORE
      TYPE     .COPMSG     ;INSERT SCRATCH IN DX1 & TYPE P
      HALT                               ;WAIT FOR PROCEED
      JSR      PC,GETSEC   ;CALCULATE MAX SECTORS TO BE COPIED
      CLR      ERFLG      ;INITIALIZE
      MOV      #1,TRACK
      MOV      #1,SECT
      TSTB     RXCS       ;DONE? (CTL RDY)
      BPL      .-4        ;BR IF NO & TRY AGAIN
1$:   JSR      R5,RDWR     ;READ DX0
      RSEC
      TST      RXCS       ;ERROR?
      BPL      2$        ;BR IF NO
      INC      ERFLG
      CMP      ERFLG,#10. ;10 ERRORS?
      BNE      1$        ;BR IF NO & TRY AGAIN
      ERROR   100        ;HARD ERR READ SECTOR DX0
      HALT
      BR       .-2       ;FORCE A RESTART FROM 250
2$:   CLR      FRFLG
      JSR      R5,EBUFF   ;EMPTY BUFFER INTO DOBUF
      DOBUF
3$:   JSR      R5,RDWR     ;WRITE DX1
      <WSEC!DX1>
      TST      RXCS       ;ERROR?
      BPL      4$        ;BR IF NO
      INC      ERFLG
      CMP      ERFLG,#10. ;10 ERRORS?
      BNE      3$        ;BR IF NO & TRY AGAIN
      ERROR   101        ;ERROR WRITE SECTOR
      HALT
      BR       .-2       ;FORCE RESTART AT 250

```

```

3934
3935 016526 005037 016666      4$: CLR ERFLG
3936 016532 004537 016744      JSR R5,RDWR ;READ DX1
3937 016536 000027              <RSEC!DX1>
3938
3939 016540 005737 177170      TST RXCS ;ERROR?
3940 016544 100011      BPL 5$ ;BR IF NO
3941 016546 005237 016666      INC ERFLG
3942 016552 023727 016666 000012  CMP ERFLG,#10. ;10 ERRORS?
3943 016560 001362      BNE 4$ ;BR IF NO & TRY AGAIN
3944 016562 104103      ERROR 103 ;HARD ERR READ SECTOR DX1
3945 016564 000000      HALT
3946 016566 000776      BR -.2 ;FORCE 250 RESTART
3947
3948 016570 004537 017004      5$: JSR R5,EBUFF ;EMPTY BUFFER INTO D1BUF
3949 016574 002674              D1BUF
3950
3951 016576 004737 017046      JSR PC,DATCHK ;COMPARE DOBUF WITH D1BUF
3952
3953 016602 005237 016664      INC SECCNT ;TOTAL DONE
3954
3955 016606 023737 016664 016662  CMP SECCNT,MAXSEC ;DID TOTAL # SECTORS?
3956 016614 001415      BEQ 8$ ;BR IF YES
3957
3958 016616 023727 016672 000032  CMP SECT,#32 ;ELSE DID WE DO LAST SECTOR ON TRACK?
3959 016624 001403      BEQ 6$ ;BR IF YES
3960 016626 005237 016672      INC SECT ;ELSE BUMP & DO ANOTHER
3961 016632 000672      BR 1$
3962
3963 016634 005237 016670      6$: INC TRACK ;BUMP TRK
3964 016640 012737 000001 016672  MOV #1,SECT ;INIT SECTOR
3965 016646 000664      BR 1$ ;& DO ANOTHER
3966
3967 016650 104401 020256      8$: TYPE .COPDUN ;DONE MSG
3968 016654 000000      HALT
3969 016656 000137 016354      JMP COPY ;DO AGAIN IF 'P' TYPED
3970
3971 016662 000000      MAXSEC: 0 ;TOTAL # SECTORS TO READ FROM DX0
3972 016664 000000      SECCNT: 0 ;TOTAL # SECTORS WRITTEN TO DX1
3973 016666 000000      ERFLG: 0
3974 016670 000000      TRACK: 0
3975 016672 000000      SECT: 0
  
```

```

3976
3977
3978
3979
3980
3981 016674 012700 026532
3982 016700 006200
3983 016702 005500
3984 016704 062700 000377
3985 016710 042700 000377
3986
3987 016714 000300
3988 016716 006300
3989 016720 006300
3990
3991 016722 062700 000074
3992 016726 062700 000010
3993
3994 016732 010037 016662
3995
3996
3997 016736 005037 016664
3998 016742 000207
3999
4000
4001
4002
4003
4004
4005
4006 016744 013700 016670
4007 016750 000300
4008 016752 053700 016672
4009 016756 010037 177174
4010 016762 012537 177170
4011 016766 004537 011600
4012 016772 177170
4013 016774 000200
4014 016776 104075
4015 017000 000000
4016 017002 000205
4017

```

```

:*****
:ROUTINE TO CALCULATE THE MAX # OF SECTORS TO READ FROM DX0
:*****
GETSEC: MOV    #LSTAD,RO      ;GET MAX ADDR
        ASR    RO           ;GET WORD CT
        ADC    RO           ;DONT LOOSE ANY
        ADD    #377,RO
        BIC    #377,RO      ;ROUND OFF TO NEAREST WHOLE WORD
        SWAB   RO
        ASL    RO
        ASL    RO          ;DIVIDE BY 100(8) FOR SECTOR CT.
        ADD    #<15.*4>,RO ;ADD SECTOR CT FOR BLOCKS 0 - 14 OF DX0
        ADD    #8.,RO      ;2 MORE BLOCKS (NECESSARY FUDGE FACTOR)
        MOV    RC,MAXSEC   ;SAVE
                                ;THIS IS THE MAX SECTORS WE WILL READ OFF DX0
                                ;& WRITE TO DX1 STARTING AT TRK 1, SECT 1
                                ;CCUNT OF TOTAL SECTORS WRITTEN TO DX1
        CLR    SECCNT
        RTS    PC
:*****
:ROUTINE TO READ OF WRITE DX0 OR DX1
:R5 POINTS TO THE COMMAND & DISK #
:*****
RDWR:  MOV    TRACK,RO
        SWAB   RO
        BIS    SECT,RO
        MOV    RO,RXSA      ;LOAD TRK/SEC
        MOV    (R5)+,RXLS   ;ISSUE COMMAND
        JSR    R5,TIMER2    ;WAIT FOR DONE
                                ;
        RXCS
        DONE
        ERROR  75          ;NO DONE
        HALT
        RTS    R5

```



```
4018
4019
4020      ;*****
4021      ;ROUTINE TO EMPTY BUFFER INTO DOBUF OR D1BUF
4022      ;R5 POINTS TO IT
4023      ;*****
4024      017004 012700 000100      EBUFF:  MOV      #100,R0          ;WD CT
4025      017010 012501              MOV      (R5)+,R1          ;BUFFER ADDR
4026      017012 012737 000003 177170  MOV      #EBUF,RXCS      ;ISSUE EMPTY BUFFER COMMAND
4027      017020 013721 177172      1$:  MOV      RXDB,(R1)+      ;PUT IT IN TABLE
4028      017024 005300              DEC      R0
4029      017026 001374              BNE     1$
4030      017030 004537 011600      JSR     R5,TIMER2        ;WAIT FOR DONE
4031      017034 177170              RXCS
4032      017036 000200              DONE
4033      017040 104075              ERROR   75              ;NO DONE
4034      017042 000000              HALT
4035      017044 000205              RTS      R5
4036
4037
4038      ;*****
4039      ;ROUTINE TO COMPARE DOBUF WITH D1BUF
4040      ;*****
4041
4042      017046 012700 000100      DATCHK: MOV      #100,R0          ;WD CT
4043      017052 012701 002424      MOV      #DOBUF,R1
4044      017056 012702 002674      MOV      #D1BUF,R2
4045      017062 022122              1$:  CMP      (R1)+,(R2)+      ;COMPARE?
4046      017064 001403              BEQ     2$              ;BR IF YES
4047      017066 104102              ERROR   102            ;MISCOMPARE
4048      017070 000000              HALT
4049      017072 000776              BR      .-2
4050
4051      017074 005300      2$:  DEC      R0
4052      017076 001371              BNE     1$
4053      017100 000207              RTS      PC
4054
```

4055  
4056  
4057  
4058  
4059  
4060  
4061  
4062

.SBTTL PROGRAM MESSAGES

::\*\*\*\*\*  
: MESSAGES & ERROR FORMATS  
:\*\*\*\*\*

.NLIST BEX

017102	041600	052514	052123	CLOPT:	.ASCIZ	<CRLF>/CLUSTER OPTION/		
017122	052200	051105	020115	CLT1:	.ASCIZ	<CRLF>/TERM #1/		
017133	200	042524	046522	CLT2:	.ASCIZ	<CRLF>/TERM #2/		
017144	052200	051105	020115	CLT3:	.ASCIZ	<CRLF>/TERM #3/		
017155	200	054523	041516	SCOM:	.ASCIZ	<CRLF>/SYNC COMM/		
017170	040600	054523	041516	ACOM:	.ASCIZ	<CRLF>/ASYN COMM/		
017204	050200	044522	052116	PRINT:	.ASCIZ	<CRLF>/PRINTER/		
017215	040	047520	052122	PORT:	.ASCIZ	/ PORT TESTED/		
017232	042200	030130	000	DRV0:	.ASCIZ	<CRLF>/DX0/		
017237	200	054104	000061	DRV1:	.ASCIZ	<CRLF>/DX1/		
017244	041600	047514	045503	CLOCK:	.ASCIZ	<CRLF>/CLOCK/		
017253	200	045464	000	M4K:	.ASCIZ	<CRLF>/4K/		
017257	200	045470	000	M8K:	.ASCIZ	<CRLF>/8K/		
017263	200	031061	000113	M12K:	.ASCIZ	<CRLF>/12K/		
017270	030600	045466	000	M16K:	.ASCIZ	<CRLF>/16K/		
017275	200	030062	000113	M20K:	.ASCIZ	<CRLF>/20K/		
017302	031200	045464	000	M24K:	.ASCIZ	<CRLF>/24K/		
017307	200	030063	000113	M30K:	.ASCIZ	<CRLF>/30K/		
017314	046440	046505	051117	MEM:	.ASCIZ	/ MEMORY PRESENT/		
017334	047040	052117	050040	NOTPRES:	.ASCIZ	/ NOT PRESENT/		
017351	200	044412	051516	WARNING:	.ASCII	<CRLF><LF>/INSERT SCRATCH DISKS, TYPE 'P' FOR NORMAL TESTING/		
017434	023600	032062	043460		.ASCII	<CRLF>/'240G' FOR NORMAL RESTARTS/		
017467	200	031047	030065		.ASCII	<CRLF>/'250G' TO COPY SYS EXERCISER DISK/		
017531	200	031047	030066		.ASCII	<CRLF>/'260G' FOR COMPATABILITY PASS 1: WRITE/		
017600	023600	033462	043460		.ASCII	<CRLF>/'270G' FOR COMPATABILITY PASS 2: READ/		
017647	040	042524	052123	DROP:	.ASCIZ	/ TESTING DROPPED/		
017670	051040	047125	044516	RUN:	.ASCIZ	/ RUNNING/		
017701	040	045517	000	OK:	.ASCIZ	/ OK/		
017705	040	051124	000113	TRK:	.ASCIZ	/ TRK/		
017712	042040	052101	020001	PATT:	.ASCIZ	/ DATA PATT/		
017725	040	040522	042116	RANDOM:	.ASCIZ	/ RANDOM SEEKS/		
017743	200	042515	020115	MEMORY:	.ASCIZ	<CRLF>/MEM TESTS/		
017756	042040	047117	000105	DUN:	.ASCIZ	/ DONE/		
017764	005200	047105	020104	ENDPAS:	.ASCIZ	<CRLF><LF>/END PASS #/		
020001	011	047524	040524	MSG1:	.ASCIZ	/ TOTAL ERRORS: /		
020030	004600	004411	047524	MSG2:	.ASCIZ	<CRLF>/	TOTAL SOFT ERRORS:	/
020064	005200	004411	052011	MSG3:	.ASCIZ	<CRLF><LF>/	TOTAL ERRORS THIS PASS:/	
020121	200	004411	051411	MSG4:	.ASCIZ	<CRLF>/	SOFT ERRORS THIS PASS:/	
020155	200	047503	054520	COPMSG:	.ASCII	<CRLF>/COPY DX0 TO DX1/		
020175	200	047111	042523		.ASCII	<CRLF>/INSERT SCRATCH DISK IN DX1, TYPE 'P' TO PROCEED/		
020256	042200	047117	027105	COPDUN:	.ASCIZ	<CRLF>/DONE...TYPE 'P' TO DO AGAIN OR '240G' FOR NORMAL TESTING/		
020350	005200	047503	050115	COMPAT:	.ASCII	<CRLF><LF>/COMPATABILITY PASS 1 (WRITE) DONE/		
020413	200	047504	023440		.ASCIZ	<CRLF>/DO 'P' FOR PASS 2 (READ)/		
020445	200	042504	046526	DEVM:	.ASCIZ	<CRLF>/DEVM - /		
020456	042515	047515	054522	EM1:	.ASCIZ	/MEMORY TIMEOUT/		

020475	115	046505	042040	EM2:	.ASCIZ	/MEM DATA COMP ERR/
020517	123	047131	020103	EM3:	.ASCIZ	/SYNC COMM DID NOT RECEIVE SYNC CHAR/
020563	120	044522	052116	EM4:	.ASCIZ	/PRINTER STATUS ERR/
020606	042524	046522	021440	EM5:	.ASCIZ	/TERM #1 DATA COMP ERR/
020634	042524	046522	021440	EM6:	.ASCIZ	/TERM #2 DATA COMP ERR/
020662	042524	046522	021440	EM7:	.ASCIZ	/TERM #3 DATA COMP ERR/
020710	051501	047131	020103	EM8:	.ASCIZ	/ASYNC COMM DATA COMP ERR/
020741	123	047131	020103	EM9:	.ASCIZ	/SYNC COMM DATA COMP ERR/
020771	125	042516	050130	EM10:	.ASCIZ	/UNEXP DISK INTERRUPT/
021016	054104	020060	051127	EM11:	.ASCIZ	/DX0 WRITE ERR/
021034	054104	020060	040510	EM13:	.ASCIZ	/DX0 HARD ERR - READ SECT/
021065	104	030130	051440	EM14:	.ASCIZ	/DX0 SOFT ERR - READ SECT/
021116	054104	020060	040510	EM15:	.ASCIZ	/DX0 HARD ERR - DATA COMP/
021147	104	030130	051440	EM16:	.ASCIZ	/DX0 SOFT ERR - DATA COMP/
021200	054104	020061	051127	EM17:	.ASCIZ	/DX1 WRITE ERR/
021216	054104	020061	040510	EM19:	.ASCIZ	/DX1 HARD ERR - READ SECT/
021247	104	030530	051440	EM20:	.ASCIZ	/DX1 SOFT ERR - READ SECT/
021300	054104	020061	040510	EM21:	.ASCIZ	/DX1 HARD ERR - DATA COMP/
021331	104	030530	051440	EM22:	.ASCIZ	/DX1 SOFT ERR - DATA COMP/
021362	046103	020113	052510	EM23:	.ASCIZ	/CLK HUNG/
021373	120	044522	052116	EM24:	.ASCIZ	/PRINTER HUNG/
021410	042524	046522	021440	EM25:	.ASCIZ	/TERM #1 HUNG/
021425	124	051105	020115	EM26:	.ASCIZ	/TERM #2 HUNG/
021442	042524	046522	021440	EM27:	.ASCIZ	/TERM #3 HUNG/
021457	123	047131	020103	EM28:	.ASCIZ	/SYNC COMM HUNG/
021476	051501	047131	020103	EM29:	.ASCIZ	/ASYNC COMM HUNG/
021516	054104	020060	052510	EM30:	.ASCIZ	/DX0 HUNG/
021527	104	030530	044040	EM31:	.ASCIZ	/DX1 HUNG/
021540	054523	041516	041440	EM32:	.ASCIZ	/SYNC COMM - DATA NOT AVAIL NOT SET/
021603	123	047131	020103	EM33:	.ASCIZ	/SYNC COMM - RECVR ACTIVE NOT SET/
021644	054523	041516	041440	EM34:	.ASCIZ	/SYNC COMM - RECVR DONE NOT SET/
021703	104	030130	023440	EM35:	.ASCIZ	/DX0 'DEL DATA' BIT 5 NOT SET IN RXES/
021750	054104	020060	047111	EM36:	.ASCIZ	/DX0 INIT CMD DID NOT READ TRK 1, SEC 1/
022017	104	030130	051040	EM37:	.ASCIZ	/DX0 RESTORE CMD ERR/
022043	104	030130	023440	EM38:	.ASCIZ	/DX0 'INIT DONE' BIT 0 NOT SET IN RXES/
022111	104	030130	051040	EM39:	.ASCIZ	/DX0 READ STATUS CMD ERR/
022141	104	030130	044440	EM40:	.ASCIZ	/DX0 INV ADDR BIT 1 NOT SET IN RXES/
022204	054104	020060	051105	EM41:	.ASCIZ	/DX0 ERR BIT NOT SET IN RXCS/
022240	054104	020060	047111	EM42:	.ASCIZ	/DX0 INIT CMD ERR/
022261	104	030130	051440	EM43:	.ASCIZ	/DX0 SEEK ERR - WRITE SECT/
022313	104	030130	051440	EM45:	.ASCIZ	/DX0 SEEK ERR - PEAD SECT/
022344	054104	020061	042523	EM47:	.ASCIZ	/DX1 SEEK ERR - WRITE SECT/
022376	054104	020061	042523	EM49:	.ASCIZ	/DX1 SEEK ERR - READ SECT/
022427	104	030530	051040	EM51:	.ASCIZ	/DX1 RESTORE CMD ERR/
022453	104	051511	020113	EM52:	.ASCIZ	/DISK 'DONE' NOT SET/
022477	106	046111	020114	EM53:	.ASCIZ	/FILL & EMPTY BUFF TEST... DATA MISCOMP/
022546	040504	040524	046440	EM54:	.ASCIZ	/DATA MISCOMP/
022563	122	050105	040514	EM55:	.ASCIZ	/REPLACE DX0...10 BAD SECTORS/
022620	042522	046120	041501	EM56:	.ASCIZ	/REPLACE DX1...10 BAD SECTORS/
022655	104	030130	044040	EM57:	.ASCIZ	/DX0 HARD CRC ERR/
022676	054104	020060	040504	EM58:	.ASCIZ	/DX0 DATA CRC ERR/
022717	104	030130	050040	EM59:	.ASCIZ	/DX0 PREV CRC ERR WITH DATA OK/
022755	104	030530	044040	EM60:	.ASCIZ	/DX1 HARD CRC ERR/
022776	054104	020061	040504	EM61:	.ASCIZ	/DX1 DATA CRC ERR/
023017	104	030530	050040	EM62:	.ASCIZ	/DX1 PREV CRC ERR WITH DATA OK/

023055	105	051122	051117	DH1:	.ASCIZ	/ERROR	#	ERR PC/										
023074	051105	047522	020122	DH2:	.ASCIZ	/ERROR	#	ERR PC	ADDR/									
023120	051105	047522	020122	DH3:	.ASCIZ	/ERROR	#	ERR PC	ADDR	EXPECT	RECDV/							
023162	051105	047522	020122	DH4:	.ASCIZ	/ERROR	#	ERR PC	PR STATUS/									
023213	105	051122	051117	DH5:	.ASCIZ	/ERROR	#	ERR PC	EXPECT	RECDV/								
023250	051105	047522	020122	DH6:	.ASCIZ	/ERROR	#	DXTST#	ERR PC	RXCS	RXES	RXSA/						
023315	105	051122	051117	DH7:	.ASCIZ	/ERROR	#	DXTST#	ERR PC	RXCS	RXES	TRACK	SECTOR	#	RETRIE			
023404	054104	051524	020124	DH8:	.ASCIZ	/DXTST	#	ERR PC	RXCS	RXES	RXSA	EXPECT	RECVD	#	RETRIES			

023474 .EVEN

023474	025764	001116	000000	DT1:	.WORD	ERRNUM,\$ERRPC,0												
023502	025764	001116	004462	DT2:	.WORD	ERRNUM,\$ERRPC,ADDR,0												
023512	025764	001116	004462	DT3:	.WORD	ERRNUM,\$ERRPC,ADDR,PAT,MEMHLD,0												
023526	025764	001116	012302	DT4:	.WORD	ERRNUM,\$ERRPC,SPRS,0												
023536	025764	001116	012400	DT5:	.WORD	ERRNUM,\$ERRPC,T1CHR,T1HLD,0												
023550	025764	001116	012500	DT6:	.WORD	ERRNUM,\$ERRPC,T2CHR,T2HLD,0												
023562	025764	001116	012600	DT7:	.WORD	ERRNUM,\$ERRPC,T3CHR,T3HLD,0												
023574	025764	001116	012700	DT8:	.WORD	ERRNUM,\$ERRPC,COMCHR,COMHLD,0												
023606	025764	003120	001116	DT9:	.WORD	ERRNUM,DXTST,\$ERRPC,SRXCS,SRXES,SRXSA,0												
023624	025764	003120	001116	DT10:	.WORD	ERRNUM,DXTST,\$ERRPC,SRXCS,SRXES,DOTRK,DOSEC,DOERR,0												
023646	003120	001116	177170	DT11:	.WORD	DXTST,\$ERRPC,RXCS,RXES,RXSA,DOEXP,DORÉC,DOCERR,0												
023670	025764	003120	001116	DT12:	.WORD	ERRNUM,DXTST,\$ERRPC,SRXCS,SRXES,D1TRK,D1SEC,D1ERR,0												
023712	003120	001116	177170	DT13:	.WORD	DXTST,\$ERRPC,RXCS,RXES,RXSA,D1EXP,D1REC,D1CERR,0												
023734	025764	003120	001116	DT14:	.WORD	ERRNUM,DXTST,\$ERRPC,RXCS,RXES,RXSA,0												
023752	025764	001116	006252	DT15:	.WORD	ERRNUM,\$ERRPC,EXPO,EBHLD,0												
023764	025764	001116	006254	DT16:	.WORD	ERRNUM,\$ERRPC,EXP1,EBHLD,0												

023776	000000			DF:	.WORD	0												
024000	000000				.WORD	0												
024002	000000				.WORD	0												

024004	000000			DF1:	.WORD	0												
024006	000000				.WORD	0												
024010	000400				.WORD	400												
024012	000401				.WORD	401												

024014	000000			DF2:	.WORD	0												
024016	000000				.WORD	0												
024020	000000				.WORD	0												
024022	000400				.WORD	400												

.LIST BEX

```

4063 .SBTTL TYPE ROUTINE
4064
4065 ;:*****
4066 ;*ROUTINE TO TYPE ASCIZ MESSAGE. MESSAGE MUST TERMINATE WITH A 0 BYTE.
4067 ;*THE ROUTINE WILL INSERT A NUMBER OF NULL CHARACTERS AFTER A LINE FEED.
4068 ;*NOTE1: $NULL CONTAINS THE CHARACTER TO BE USED AS THE FILLER CHARACTER.
4069 ;*NOTE2: $FILLS CONTAINS THE NUMBER OF FILLER CHARACTERS REQUIRED.
4070 ;*NOTE3: $FILLC CONTAINS THE CHARACTER TO FILL AFTER.
4071 ;*
4072 ;*CALL:
4073 ;*1) USING A TRAP INSTRUCTION
4074 ;* TYPE ,MESADR ;:MESADR IS FIRST ADDRESS OF AN ASCIZ STRING
4075 ;*OR
4076 ;* TYPE
4077 ;* MESADR
4078 ;*
4079
4080 024024 105737 001157 $TYPE: TSTB $TPFLG ;:IS THERE A TERMINAL?
4081 024030 100002 BPL 1$ ;:BR IF YES
4082 024032 000000 HALT ;:HALT HERE IF NO TERMINAL
4083 024034 000430 BR 3$ ;:LEAVE
4084 024036 010046 1$: MOV R0,-(SP) ;:SAVE R0
4085 024040 017600 000002 MOV @2(SP),R0 ;:GET ADDRESS OF ASCIZ STRING
4086 024044 122737 000001 001210 CMPB #APTENV,$ENV ;:RUNNING IN APT MODE
4087 024052 001011 BNE 62$ ;:NO,GO CHECK FOR APT CONSOLE
4088 024054 132737 000100 001211 BITB #APTPOOL,$ENVM ;:SPOOL MESSAGE TO APT
4089 024062 001405 BEQ 62$ ;:NO,GO CHECK FOR CONSOLE
4090 024064 010037 024074 MOV R0,61$ ;:SETUP MESSAGE ADDRESS FOR APT
4091 024070 004737 025156 JSR PC,$ATY3 ;:SPOOL MESSAGE TO APT
4092 024074 000000 61$: .WORD 0 ;:MESSAGE ADDRESS
4093 024076 132737 000040 001211 62$: BITB #APTCSUP,$ENVM ;:APT CONSOLE SUPPRESSED
4094 024104 001003 BNE 60$ ;:YES,SKIP TYPE OUT
4095 024106 112046 2$: MOV (R0)+,-(SP) ;:PUSH CHARACTER TO BE TYPED ONTO STACK
4096 024110 001005 BNE 4$ ;:BR IF IT ISN'T THE TERMINATOR
4097 024112 005726 TST (SP)+ ;:IF TERMINATOR POP IT OFF THE STACK
4098 024114 012600 60$: MOV (SP)+,R0 ;:RESTORE R0
4099 024116 062716 000002 3$: ADD #2,(SP) ;:ADJUST RETURN PC
4100 024122 000002 RTI ;:RETURN
4101 024124 122716 000011 4$: CMPB #HT,(SP) ;:BRANCH IF <HT>
4102 024130 001430 BEQ 8$
4103 024132 122716 000200 CMPB #CRLF,(SP) ;:BRANCH IF NOT <CRLF>
4104 024136 001006 BNE 5$
4105 024140 005726 TST (SP)+ ;:POP <CR><LF> EQUIV
4106 024142 104401 TYPE ;:TYPE A CR AND LF
4107 024144 001165 $CRLF
4108 024146 105037 024302 CLRB $CHARCNT ;:CLEAR CHARACTER COUNT
4109 024152 000755 BR 2$ ;:GET NEXT CHARACTER
4110 024154 004737 024236 5$: JSR PC,$TYPEC ;:GO TYPE THIS CHARACTER
4111 024160 123726 001156 6$: CMPB $FILLC,(SP)+ ;:IS IT TIME FOR FILLER CHARS.?
4112 024164 001350 BNE 2$ ;:IF NO GO GET NEXT CHAR.
4113 024166 013746 001154 MOV $NULL,-(SP) ;:GET # OF FILLER CHARS. NEEDED
4114 ;:AND THE NULL CHAR.
4115 024172 105366 000001 7$: DECB 1(SP) ;:DOES A NULL NEED TO BE TYPED?
4116 024176 002770 BLT 6$ ;:BR IF NO--GO POP THE NULL OFF OF STACK
4117 024200 004737 024236 JSR PC,$TYPEC ;:GO TYPE A NULL
4118 024204 105337 024302 DECB $CHARCNT ;:DO NOT COUNT AS A COUNT

```

```

4119 024210 000770          BR      7$          ;;LOOP
4120
4121          ;HORIZONTAL TAB PROCESSOR
4122
4123 024212 112716 000040      8$:      MOVB   #' (SP)          ;;REPLACE TAB WITH SPACE
4124 024216 004737 024236      9$:      JSR    PC,$TYPEC          ;;TYPE A SPACE
4125 024222 132737 000007 024302      BITB   #7,$CHARCNT          ;;BRANCH IF NOT AT
4126 024230 001372          BNE    9$          ;;TAB STOP
4127 024232 005726          TST    (SP)+          ;;POP SPACE OFF STACK
4128 024234 000724          BR     2$          ;;GET NEXT CHARACTER
4129 024236 105777 154706      $TYPEC: TSTB   @2$TPS          ;;WAIT UNTIL PRINTER IS READY
4130 024242 100375          BPL    $TYPEC
4131 024244 116677 000002 154700      MOVB   2(SP),@2$TPB          ;;LOAD CHAR TO BE TYPED INTO DATA REG.
4132 024252 122766 000015 000002      CMPB   #CR,2(SP)          ;;IS CHARACTER A CARRIAGE RETURN?
4133 024260 001003          BNE    1$          ;;BRANCH IF NO
4134 024262 105037 024302      CLRB   $CHARCNT          ;;YES--CLEAR CHARACTER COUNT
4135 024266 000406          BR     $TYPEX          ;;EXIT
4136 024270 122766 000012 000002 1$:      CMPB   #LF,2(SP)          ;;IS CHARACTER A LINE FEED?
4137 024276 001402          BEQ    $TYPEX          ;;BRANCH IF YES
4138 024300 105227          INCB   (PC)+          ;;COUNT THE CHARACTER
.139 024302 000000          $CHARCNT: .WORD 0          ;;CHARACTER COUNT STORAGE
4140 024304 000207          $TYPEX: RTS      PC
4141
    
```

```

4142      .SBTTL  TTY INPUT ROUTINE
4143
4144      ::*****
4145      .ENABL  LSB
4146
4147      ::*****
4148      ::*SOFTWARE SWITCH REGISTER CHANGE ROUTINE.
4149      ::*ROUTINE IS ENTERED FROM THE TRAP HANDLER, AND WILL
4150      ::*SERVICE THE TEST FOR CHANGE IN SOFTWARE SWITCH REGISTER TRAP CALL
4151      ::*WHEN OPERATING IN TTY FLAG MODE.
4152      024306 022737 000176 001140 $CKSWR: CMP      #SWREG,SWR      ;; IS THE SOFT-SWR SELECTED?
4153      024314 001114          BNE      15$          ;; BRANCH IF NO
4154      024316 105777 154622          TSTB     @STKS          ;; CHAR THERE?
4155      024322 100111          BPL      15$          ;; IF NO, DON'T WAIT AROUND
4156      024324 117746 154616          MOVB    @STKB,-(SP)      ;; SAVE THE CHAR
4157      024330 042716 177600          BIC     #^C177,(SP)    ;; STRIP-OFF THE ASCII
4158      024334 022726 000007          CMP     #7,(SP)+      ;; IS IT A CONTROL G?
4159      024340 001102          BNE     15$          ;; NO, RETURN TO USER
4160      024342 123727 001134 000001  CMPB    $AUTOB,#1     ;; ARE WE RUNNING IN AUTO-MODE?
4161      024350 001476          BEQ     15$          ;; BRANCH IF YES
4162
4163      024352 104401 025120          $GTSWR: TYPE    , $CNTLG      ;; ECHO THE CONTROL-G (^G)
4164      024356 104401 025125          TYPE    , $MSWR        ;; TYPE CURRENT CONTENTS
4165      024362 013746 000176          MOV     SWREG,-(SP)    ;; SAVE SWREG FOR TYPEOUT
4166      024366 104402          TYPOC          ;; GO TYPE--OCTAL ASCII(ALL DIGITS)
4167      024370 104401 025136          TYPE    , $MNEW      ;; PROMPT FOR NEW SWR
4168      024374 005046          19$:  CLR     -(SP)      ;; CLEAR COUNTER
4169      024376 005046          CLR     -(SP)      ;; THE NEW SWR
4170      024400 105777 154540          7$:  TSTB    @STKS      ;; CHAR THERE?
4171      024404 100375          BPL     7$          ;; IF NOT TRY AGAIN
4172
4173      024406 117746 154534          MOVB    @STKB,-(SP)  ;; PICK UP CHAR
4174      024412 042716 177600          BIC     #^C177,(SP)  ;; MAKE IT 7-BIT ASCII
4175
4176      024416 021627 000003          CMP     (SP),#3      ;; IS IT A CONTROL-C?
4177      024422 001015          BNE     9$          ;; BRANCH IF NOT
4178      024424 104401 025106          TYPE    , $CNTLC     ;; YES, ECHO CONTROL-C (^C)
4179      024430 062706 000006          ADD     #6,SP        ;; CLEAN UP STACK
4180      024434 123727 001135 000001  CMPB    $INTAG,#1    ;; REENABLE TTY KEYBOARD INTERRUPTS?
4181      024442 001003          BNE     8$          ;; BRANCH IF NO
4182      024444 012777 000100 154472  MOV     #100,@STKS   ;; ALLOW TTY KEYBOARD INTERRUPTS
4183      024452 000137 011116          8$:  JMP     GT$DEV     ;; CONTROL-C RESTART
4184
4185
4186      024456 021627 000025          9$:  CMP     (SP),#25   ;; IS IT A CONTROL-U?
4187      024462 001005          BNE     10$         ;; BRANCH IF NOT
4188      024464 104401 025113          TYPE    , $CNTLU     ;; YES, ECHO CONTROL-U (^U)
4189      024470 062706 000006          20$: ADD     #6,SP        ;; IGNORE PREVIOUS INPUT
4190      024474 000737          BR      19$         ;; LET'S TRY IT AGAIN
4191
4192
4193      024476 021627 000015          10$: CMP     (SP),#15   ;; IS IT A <CR>?
4194      024502 001022          BNE     16$         ;; BRANCH IF NO
4195      024504 005766 000004          TST     4(SP)        ;; YES, IS IT THE FIRST CHAR?
4196      024510 001403          BEQ     17$         ;; BRANCH IF YES
4197      024512 016677 000002 154420  MOV     2(SP),@SWR    ;; SAVE NEW SWR

```

```

4198 024520 062706 000006      11$:  ADD      #6,SP      ;;CLEAR UP STACK
4199 024524 104401 001165      14$:  TYPE      ,SCLRF   ;;ECHO <CR> AND <LF>
4200 024530 123727 001135 000001  CMPB     $INTAG,#1    ;;RE-ENABLE TTY KBD INTERRUPTS?
4201 024536 001003                BNE      15$         ;;BRANCH IF NOT
4202 024540 012777 000100 154376  MOV      #100,@$TKS   ;;RE-ENABLE TTY KBD INTERRUPTS
4203 024546 000002                RTI                     ;;RETURN
4204 024550 004737 024236      15$:  RTI                     ;;RETURN
4205 024554 021627 000060      16$:  JSR      PC,$TYPEC  ;;ECHO CHAR
4206 024560 002420                CMP      (SP),#60     ;;CHAR < 0?
4207 024562 021627 000067                BLT      18$         ;;BRANCH IF YES
4208 024566 003015                CMP      (SP),#67     ;;CHAR > 7?
4209 024570 042726 000060                BGT      18$         ;;BRANCH IF YES
4210 024574 005766 000002                BIC      #60,(SP)+    ;;STRIP-OFF ASCII
4211 024600 001403                TST      2(SP)        ;;IS THIS THE FIRST CHAR
4212 024602 006316                BEQ      17$         ;;BRANCH IF YES
4213 024604 006316                ASL      (SP)        ;;NO, SHIFT PRESENT
4214 024606 006316                ASL      (SP)        ;;CHAR OVER TO MAKE
4215 024610 005266 000002      17$:  INC      2(SP)        ;;ROOM FOR NEW ONE.
4216 024614 056616 177776                BIS      -2(SP),(SP)  ;;KEEP COUNT OF CHAR
4217 024620 000667                BR       7$          ;;SET IN NEW CHAR
4218 024622 104401 001164      18$:  TYPE      ,SQUES   ;;GET THE NEXT ONE
4219 024626 000720                BR       20$         ;;TYPE ?<CR><LF>
4220                .DSABL  LSB        ;;SIMULATE CONTROL-U
    
```

```

4221
4222
4223
4224
4225
4226
4227
4228
4229
4230
    ;*****
    ;*THIS ROUTINE WILL INPUT A SINGLE CHARACTER FROM THE TTY
    ;*CALL:
    ;*      RDCHR          ;;INPUT A SINGLE CHARACTER FROM THE TTY
    ;*      RETURN HERE   ;;CHARACTER IS ON THE STACK
    ;*                   ;;WITH PARITY BIT STRIPPED OFF
    ;
    
```

```

4231 024630 011646 000004 000002 $RDCHR: MOV      (SP),-(SP)  ;;PUSH DOWN THE PC
4232 024632 016666 000004 000002  MOV      4(SP),2(SP)  ;;SAVE THE PS
4233 024640 105777 154300      1$:  TSTB     @$TKS      ;;WAIT FOR
4234 024644 100375                BPL      1$          ;;A CHARACTER
4235 024646 117766 154274 000004  MOVB     @$TKB,4(SP)  ;;READ THE TTY
4236 024654 042766 177600 000004  BIC      #^C<177>,4(SP) ;;GET RID OF JUNK IF ANY
4237 024662 026627 000004 000023  CMP      4(SP),#23   ;;IS IT A CONTROL-S?
4238 024670 001013                BNE      3$         ;;BRANCH IF NO
4239 024672 105777 154246      2$:  TSTB     @$TKS      ;;WAIT FOR A CHARACTER
4240 024676 100375                BPL      2$         ;;LOOP UNTIL ITS THERE
4241 024700 117746 154242  MOVB     @$TKB,-(SP)  ;;GET CHARACTER
4242 024704 042716 177600  BIC      #^C177,(SP)  ;;MAKE IT 7-BIT ASCII
4243 024710 022627 000021  CMP      (SP)+,#21   ;;IS IT A CONTROL-Q?
4244 024714 001366                BNE      2$         ;;IF NOT DISCARD IT
4245 024716 000750                BR       1$         ;;YES, RESUME
4246 024720 026627 000004 000140  3$:  CMP      4(SP),#140  ;;IS IT UPPER CASE?
4247 024726 002407                BLT      4$         ;;BRANCH IF YES
4248 024730 026627 000004 000175  CMP      4(SP),#175  ;;IS IT A SPECIAL CHAR?
4249 024736 003003                BGT      4$         ;;BRANCH IF YES
4250 024740 042766 000040 000004  BIC      #40,4(SP)   ;;MAKE IT UPPER CASE
4251 024746 000002      4$:  RTI                     ;;GO BACK TO USER
    
```

```

4252
4253
    ;*****
    ;*THIS ROUTINE WILL INPUT A STRING FROM THE TTY
    
```



```

4254          ;*CALL:
4255          ;*      RDLIN          ;;INPUT A STRING FROM THE TTY
4256          ;*      RETURN HERE  ;;ADDRESS OF FIRST CHARACTER WILL BE ON THE STACK
4257          ;*                                     ;;TERMINATOR WILL BE A BYTE OF ALL 0'S
4258
4259 024750 010346 $RDLIN: MOV      R3,-(SP)          ;;SAVE R3
4260 024752 012703 025076 1$:      MOV      #$TTYIN,R3      ;;GET ADDRESS
4261 024756 022703 025106 2$:      CMP      #$TTYIN+8.,R3    ;;BUFFER FULL?
4262 024762 101415      BLOS     4$                    ;;BR IF YES
4263 024764 104410      RDCHR   (SP)+,(R3)          ;;GO READ ONE CHARACTER FROM THE TTY
4264 024766 112613      MOVB    #3,(R3)            ;;GET CHARACTER
4265 024770 122713 000003      CMPB    #10$,R3          ;;IS IT A CONTROL-C?
4266 024774 001005      BNE     10$                    ;;BRANCH IF NO
4267 024776 104401 025106      TYPE    ,%CNTLC          ;;TYPE A CONTROL-C (^C)
4268 025002 012603      MOV      (SP)+,R3          ;;RESTORE R3
4269 025004 000137 011116      JMP     GT$DEV          ;;GOTO CONTROL-C RESTART
4270 025010 122713 000177      0$:    CMPB    #177,(R3)        ;;IS IT A RUBOUT
4271 025014 001003      BNE     3$                    ;;SKIP IF NOT
4272 025016 104401 001164      4$:    TYPE    ,%QUES          ;;TYPE A '?'
4273 025022 000753      BR      1$                    ;;CLEAR THE BUFFER AND LOOP
4274 025024 111337 025074      3$:    MOVB   (R3),9$          ;;ECHO THE CHARACTER
4275 025030 104401 025074      TYPE    ,9$
4276 025034 122723 000015      CMPB   #15,(R3)+        ;;CHECK FOR RETURN
4277 025040 001346      BNE     2$                    ;;LOOP IF NOT RETURN
4278 025042 105063 177777      CLRB   -1(R3)          ;;CLEAR RETURN (THE 15)
4279 025046 104401 001166      TYPE    ,%LF           ;;TYPE A LINE FEED
4280 025052 012603      MOV     (SP)+,R3        ;;RESTORE R3
4281 025054 011646      MOV     (SP),-(SP)      ;;ADJUST THE STACK AND PUT ADDRESS OF THE
4282 025056 016666 000004 000002  MOV     4(SP),2(SP)    ;;FIRST ASCII CHARACTER ON IT
4283 025064 012766 025076 000004  MOV     #$TTYIN,4(SP)
4284 025072 000002      RTI
4285 025074 000      9$:    .BYTE   0          ;;RETURN
4286 025075 000      .BYTE   0          ;;STORAGE FOR ASCII CHAR. TO TYPE
4287 025076 000010      $TTYIN: .BLKB  8.    ;;TERMINATOR
4288 025106 041536 005015 000      $CNTLC: .ASCIZ  /^C/<15><12>  ;;RESERVE 8 BYTES FOR TTY INPUT
4289 025113 0136 006525 000012      $CNTLU: .ASCIZ  /^U/<15><12>  ;;CONTROL 'C'
4290 025120 043536 005015 000      $CNTLG: .ASCIZ  /^G/<15><12>  ;;CONTROL 'U'
4291 025125 015 051412 051127      $MSWR:  .ASCIZ  <15><12>/SWR - /  ;;CONTROL 'G'
4292 025132 036440 000040
4293 025136 020040 042516 020127      $MNEW:  .ASCIZ  / NEW = /
4294 025144 020075 000
4295 025150      .EVEN
    
```

```

4296 .SBTTL APT COMMUNICATIONS ROUTINE
4297
4298
4299 025150 112737 000001 025414 $ATY1: MOVB #1,$FFLG ;;TO REPORT FATAL ERROR
4300 025156 112737 000001 025412 $ATY3: MOVB #1,$MFLG ;;TO TYPE A MESSAGE
4301 025164 000403 BR $ATYC
4302 025166 112737 000001 025414 $ATY4: MOVB #1,$FFLG ;;TO ONLY REPORT FATAL ERROR
4303 025174 $ATYC:
4304 025174 010046 MOV R0,-(SP) ;;PUSH R0 ON STACK
4305 025176 010146 MOV R1,-(SP) ;;PUSH R1 ON STACK
4306 025200 105737 025412 TSTB $MFLG ;;SHOULD TYPE A MESSAGE?
4307 025204 001450 BEQ 5$ ;;IF NOT: BR
4308 025206 122737 000001 001210 CMPSB #APTENV,$ENV ;;OPERATING UNDER APT?
4309 025214 001031 BNE 3$ ;;IF NOT: BR
4310 025216 132737 000100 001211 BITB #APTSPOOL,$ENVM ;;SHOULD SPOOL MESSAGES?
4311 025224 001425 BEQ 3$ ;;IF NOT: BR
4312 025226 017600 000004 MOV @4(SP),R0 ;;GET MESSAGE ADDR.
4313 025232 062766 000002 000004 ADD #2,4(SP) ;;BUMP RETURN ADDR.
4314 025240 005737 001170 1$: TST $MSGTYPE ;;SEE IF DONE W/ LAST XMISSION?
4315 025244 001375 BNE 1$ ;;IF NOT: WAIT
4316 025246 010037 001204 MOV R0,$MSGAD ;;PUT ADDR IN MAILBOX
4317 025252 105720 2$: TSTB (R0)+ ;;FIND END OF MESSAGE
4318 025254 001376 BNE 2$
4319 025256 163700 001204 SUB $MSGAD,R0 ;;SUB START OF MESSAGE
4320 025262 006200 ASR R0 ;;GET MESSAGE LNGTH IN WORDS
4321 025264 010037 001206 MOV R0,$MSGGLT ;;PUT LENGTH IN MAILBOX
4322 025270 012737 000004 001170 MOV #4,$MSGTYPE ;;TELL APT TO TAKE MSG.
4323 025276 000413 BR 5$
4324 025300 017637 000004 025324 3$: MOV @4(SP),4$ ;;PUT MSG ADDR IN JSR LINKAGE
4325 025306 062766 000002 000004 ADD #2,4(SP) ;;BUMP RETURN ADDRESS
4326 025314 013746 177776 MOV 177776,-(SP) ;;PUSH 177776 ON STACK
4327 025320 004737 024024 JSP PC,$TYPE ;;CALL TYPE MACRO
4328 025324 000000 4$: .WORD 0
4329 025326 5$:
4330 025326 105737 025414 10$: TSTB $FFLG ;;SHOULD REPORT FATAL ERROR?
4331 025332 001416 BEQ 12$ ;;IF NOT: BR
4332 025334 005737 001210 TST $ENV ;;RUNNING UNDER API?
4333 025340 001413 BEQ 12$ ;;IF NOT: BR
4334 025342 005737 001170 11$: TST $MSGTYPE ;;FINISHED LAST MESSAGE?
4335 025346 001375 BNE 11$ ;;IF NOT: WAIT
4336 025350 017637 000004 001172 MOV @4(SP),$FATAL ;;GET ERROR #
4337 025356 062766 000002 000004 ADD #2,4(SP) ;;BUMP RETURN ADDR.
4338 025364 005237 001170 INC $MSGTYPE ;;TELL APT TO TAKE ERROR
4339 025370 105037 025414 12$: CLRB $FFLG ;;CLEAR FATAL FLAG
4340 025374 105037 025413 CLRB $LFLG ;;CLEAR LOG FLAG
4341 025400 105037 025412 CLRB $MFLG ;;CLEAR MESSAGE FLAG
4342 025404 012601 MOV (SP)+,R1 ;;POP STACK INTO R1
4343 025406 012600 MOV (SP)+,R0 ;;POP STACK INTO R0
4344 025410 000207 RTS PC ;;RETURN
4345 025412 000 $MFLG: .BYTE 0 ;;MESSG. FLAG
4346 025413 000 $LFLG: .BYTE 0 ;;LOG FLAG
4347 025414 000 $FFLG: .BYTE 0 ;;FATAL FLAG
4348 025416 .EVEN
4349 000200 APTSIZE=200
4350 000001 APTENV=001
4351 000100 APTSPOOL=100

```

PDT-11 EXERCISER  
CVKDAB.P11 17-NOV-78 10:00  
MACY11 30G(1063) 17-NOV-78 10:00  
APT COMMUNICATIONS ROUTINE

H 8

PAGE 98

SEQ 0098

4352

000040

APTSUP=040

```
4353 .SBTTL ERROR HANDLER ROUTINE
4354
4355 ;*****
4356 ;*THIS ROUTINE WILL INCREMENT THE ERROR FLAG AND THE ERROR COUNT,
4357 ;*SAVE THE ERROR ITEM NUMBER AND THE ADDRESS OF THE ERROR CALL
4358 ;*AND GO TO MYTYPE ON ERROR
4359 ;*THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
4360 ;*SW15=1 HALT ON ERROR
4361 ;*SW13=1 INHIBIT ERROR TYPEOUTS
4362 ;*SW10=1 BELL ON ERROR
4363 ;*CALL
4364 ;* ERROR N ;;ERROR=EMT AND N=ERROR ITEM NUMBER
4365
4366 $ERROR:
4367 025416 104407 CKSWR ;;TEST FOR CHANGE IN SOFT-SWR
4368 025420 105237 001103 7$: INCB $ERFLG ;;SET THE ERROR FLAG
4369 025424 001775 BEQ 7$ ;;DON'T LET THE FLAG GO TO ZERO
4370 025426 013777 001102 153506 MOV $STNM,@DISPLAY ;;DISPLAY TEST NUMBER AND ERROR FLAG
4371 025434 032777 002000 153476 BIT #BIT10,@SWR ;;BELL ON ERROR?
4372 025442 001402 BEQ 1$ ;;NO - SKIP
4373 025444 104401 001160 TYPE ,SBELL ;;RING BELL
4374 025450 005237 001112 1$: INC $ERTTL ;;COUNT THE NUMBER OF ERRORS
4375 025454 011637 001116 MOV (SP),$ERRPC ;;GET ADDRESS OF ERROR INSTRUCTION
4376 025460 162737 000002 001116 SUB #2,$ERRPC
4377 025466 117737 153424 001114 MOVB @$ERRPC,$ITEMB ;;STRIP AND SAVE THE ERROR ITEM CODE
4378 025474 032777 020000 153436 BIT #BIT13,@SWR ;;SKIP TYPEOUT IF SET
4379 025502 001004 BNE 20$ ;;SKIP TYPEOUTS
4380 025504 004737 025732 JSR PC,MYTYPE ;;GO TO USER ERROR ROUTINE
4381 025510 104401 001165 TYPE ,SRLF
4382 025514
4383 025514 122737 000001 001210 20$: CMPB #APTENV,$ENV ;;RUNNING IN APT MODE
4384 025522 001007 BNE 2$ ;;NO,SKIP APT ERROR REPORT
4385 025524 113737 001114 025536 MOVB $ITEMB,21$ ;;SET ITEM NUMBER AS ERROR NUMBER
4386 025532 004737 025166 JSR PC,$ATY4 ;;REPORT FATAL ERROR TO APT
4387 025536 000 21$: .BYTE 0
4388 025537 000 .BYTE 0
4389 025540 000777 22$: BR 22$ ;;APT ERROR LOOP
4390 025542 005777 153372 2$: TST @SWR ;;HALT ON ERROR
4391 025546 100002 BPL 3$ ;;SKIP IF CONTINUE
4392 025550 000000 HALT ;;HALT ON ERROR!
4393 025552 104407 CKSWR ;;TEST FOR CHANGE IN SOFT-SWR
4394 025554
4395 025554 000002 3$: RTI ;;RETURN
```

```

4396          .SBTTL  ERROR MESSAGE TYPEOUT ROUTINE
4397
4398          ;*****
4399          ;*THIS ROUTINE USES THE 'ITEM CONTROL BYTE' ($ITEMB) TO DETERMINE WHICH
4400          ;*ERROR IS TO BE REPORTED. IT THEN OBTAINS, FROM THE 'ERROR TABLE' ($ERRTB),
4401          ;*AND REPORTS THE APPROPRIATE INFORMATION CONCERNING THE ERROR.
4402
4403          $ERRTYP:
4404          TYPE      , $CRLF          ;:'CARRIAGE RETURN' & 'LINE FEED'
4405          MOV      RO,-(SP)         ;:SAVE RO
4406          CLR      RO              ;:PICKUP THE ITEM INDEX
4407          BISB    @#$ITEMB,RO
4408          BNE     1$              ;:IF ITEM NUMBER IS ZERO, JUST
4409                                     ;:TYPE THE PC OF THE ERROR
4410          MOV     $ERRPC,-(SP)      ;:SAVE $ERRPC FOR TYPEOUT
4411                                     ;:ERROR ADDRESS
4412          TYPOC
4413          BR      10$              ;:GO TYPE--OCTAL ASCII(ALL DIGITS)
4414          1$:    DEC     RO          ;:GET OUT
4415          ASL     RO              ;:ADJUST THE INDEX SO THAT IT WILL
4416          ASL     RO              ;:      WORK FOR THE ERROR TABLE
4417          ASL     RO
4418          ADD     # $ERRTB,RO       ;:FORM TABLE POINTER
4419          MOV     (RO)+,2$         ;:PICKUP 'ERROR MESSAGE' POINTER
4420          BEQ     3$              ;:SKIP TYPEOUT IF NO POINTER
4421          TYPE
4422          2$:    .WORD 0           ;:TYPE THE 'ERROR MESSAGE'
4423          TYPE
4424          3$:    MOV     (RO)+,4$   ;:'ERROR MESSAGE' POINTER GOES HERE
4425          BEQ     5$              ;:'CARRIAGE RETURN' & 'LINE FEED'
4426          TYPE
4427          4$:    .WORD 0           ;:PICKUP 'DATA HEADER' POINTER
4428          TYPE
4429          5$:    MOV     (RO)+,4$   ;:SKIP TYPEOUT IF 0
4430          MOV     R1,-(SP)         ;:TYPE THE 'DATA HEADER'
4431          MOV     (R1)+,R1         ;:'DATA HEADER' POINTER GOES HERE
4432          BEQ     9$              ;:'CARRIAGE RETURN' & 'LINE FEED'
4433          MOV     (R1)+,R1         ;:SAVE R1
4434          TSTB   (R1)+            ;:PICKUP 'DATA TABLE' POINTER
4435          BNE     7$              ;:BR IF NO DATA TO BE TYPED
4436          MOV     @ (R1)+,-(SP)    ;:PICKUP 'DATA FORMAT' POINTER
4437          TYPOC
4438          BR      8$              ;:'OCTAL' OR 'DECIMAL'
4439          6$:    TSTB   (R1)+
4440          BNE     7$              ;:BR IF DECIMAL
4441          MOV     @ (R1)+,-(SP)    ;:SAVE @ (R1)+ FOR TYPEOUT
4442          TYPOC
4443          BR      8$              ;:GO TYPE--OCTAL ASCII(ALL DIGITS)
4444          7$:    MOV     @ (R1)+,-(SP)
4445          TYPDS
4446          8$:    TST     (R1)
4447          BEQ     9$              ;:SAVE @ (R1)+ FOR TYPEOUT
4448          TYPE   ,11$             ;:GO TYPE--DECIMAL ASCII WITH SIGN
4449          BR      6$              ;:IS THERE ANOTHER NUMBER?
4450          9$:    MOV     (SP)+,R1   ;:BR IF NO
4451          MOV     (SP)+,RO         ;:TYPE TWO(2) SPACES
4452          TYPE   , $CRLF          ;:LOOP
4453          RTS     PC
4454          11$:   .ASCIIZ / /
4455          .EVEN

```

```
4452
4453
4454
4455 025732 113737 001114 025764 MYTYPE: MOVB $ITEMB,ERRNUM ;FOR ERROR TYPEOUT
4456 025740 013737 013210 001174 MOV SRXSA,$TESTN ;FOR APT
4457 ;APT PRINTS $TESTN & $FATAL IN THAT ORDER.
4458 ;$TESTN WILL BE FLOPPY RXSA
4459 ;$FATAL IS ERR #
4460 025746 004737 025556 JSR PC,$ERRTYP ;TYPE ERR MSG
4461 025752 005237 025766 INC TERR
4462 025756 005237 025772 INC PERR
4463 025762 000207 RTS PC
4464
4465 025764 000000 ERRNUM: 0 ;FOR ERR TYPEOUT
4466
4467 025766 000000 TERR: 0 ;TOTAL ERROR COUNT
4468 025770 000000 SERR: 0 ;TOTAL SOFT ERR COUNT
4469 025772 000000 PERR: 0 ;PASS ERR COUNT
4470 025774 000000 PSERR: 0 ;PASS SOFT ERR COUNT... ALL FOR EOP TYPEOUT
```

4471  
4472  
4473  
4474  
4475  
4476  
4477  
4478  
4479  
4480  
4481  
4482  
4483  
4484  
4485  
4486  
4487  
4488  
4489  
4490  
4491  
4492  
4493  
4494  
4495  
4496  
4497  
4498  
4499  
4500  
4501  
4502  
4503  
4504  
4505  
4506  
4507  
4508  
4509  
4510  
4511  
4512  
4513  
4514  
4515  
4516  
4517  
4518  
4519  
4520  
4521  
4522  
4523  
4524  
4525  
4526

025776  
025776 010046  
026000 010146  
026002 010246  
026004 010346  
026006 010546  
026010 012746 020200  
026014 016605 000020  
026020 100004  
026022 005405  
026024 112766 000055 000001  
026032 005000  
026034 012703 026212  
026040 112723 000040  
026044 005002  
026046 016001 026202  
026052 160105  
026054 002402  
026056 005202  
026060 000774  
026062 060105  
026064 005702  
026066 001002  
026070 105716  
026072 100407  
026074 106316  
026076 103003  
026100 116663 000001 177777  
026106 052702 000060  
026112 052702 000040  
026116 110223  
026120 005720  
026122 020027 000010  
026126 002746  
026130 003002  
026132 010502  
026134 000764  
026136 105726  
026140 100003  
026142 116663 177777 177776  
026150 105013  
026152 012605  
026154 012603  
026156 012602

```
.SBTTL CONVERT BINARY TO DECIMAL AND TYPE ROUTINE
:*****
:*THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 5-DIGIT
:*SIGNED DECIMAL (ASCII) NUMBER AND TYPE IT. DEPENDING ON WHETHER THE
:*NUMBER IS POSITIVE OR NEGATIVE A SPACE OR A MINUS SIGN WILL BE TYPED
:*BEFORE THE FIRST DIGIT OF THE NUMBER. LEADING ZEROS WILL ALWAYS BE
:*REPLACED WITH SPACES.
:*CALL:
:*      MOV      NUM,-(SP)      ;;PUT THE BINARY NUMBER ON THE STACK
:*      TYPDS      ;;GO TO THE ROUTINE
$TYPDS:
MOV      R0,-(SP)      ;;PUSH R0 ON STACK
MOV      R1,-(SP)      ;;PUSH R1 ON STACK
MOV      R2,-(SP)      ;;PUSH R2 ON STACK
MOV      R3,-(SP)      ;;PUSH R3 ON STACK
MOV      R5,-(SP)      ;;PUSH R5 ON STACK
MOV      #20200,-(SP)    ;;SET BLANK SWITCH AND SIGN
MOV      20(SP),R5      ;;GET THE INPUT NUMBER
BPL      1$            ;;BR IF INPUT IS POS.
NEG      R5            ;;MAKE THE BINARY NUMBER POS.
MOVB     #'-,1(SP)      ;;MAKE THE ASCII NUMBER NEG.
1$:      CLR      R0      ;;ZERO THE CONSTANTS INDEX
MOV      #$DBLK,R3      ;;SETUP THE OUTPUT POINTER
MOVB     #' ,(R3)+      ;;SET THE FIRST CHARACTER TO A BLANK
2$:      CLR      R2      ;;CLEAR THE BCD NUMBER
MOV      $DTBL(R0),R1    ;;GET THE CONSTANT
3$:      SUB      R1,R5    ;;FORM THIS BCD DIGIT
BIT      4$            ;;BR IF DONE
INC      R2            ;;INCREASE THE BCD DIGIT BY 1
BR       3$
4$:      ADD      R1,R5    ;;ADD BACK THE CONSTANT
TST      R2            ;;CHECK IF BCD DIGIT=0
BNE      5$            ;;FALL THROUGH IF 0
TSTB     (SP)          ;;STILL DOING LEADING 0'S?
BMI      7$            ;;BR IF YES
5$:      ASLB     (SP)      ;;MSD?
BCC      6$            ;;BR IF NO
MOVB     1(SP),-1(R3)    ;;YES--SET THE SIGN
6$:      BIS      #'0,R2    ;;MAKE THE BCD DIGIT ASCII
7$:      BIS      #' ,R2    ;;MAKE IT A SPACE IF NOT ALREADY A DIGIT
MOVB     R2,(R3)+      ;;PUT THIS CHARACTER IN THE OUTPUT BUFFER
TST      (R0)+          ;;JUST INCREMENTING
CMP      R0,#10        ;;CHECK THE TABLE INDEX
BLT      2$            ;;GO DO THE NEXT DIGIT
BGT      8$            ;;GO TO EXIT
MOV      R5,R2          ;;GET THE LSD
BR       6$            ;;GO CHANGE TO ASCII
8$:      TSTB     (SP)+      ;;WAS THE LSD THE FIRST NON-ZERO?
BPL      9$            ;;BR IF NO
MOVB     -1(SP),-2(R3)   ;;YES--SET THE SIGN FOR TYPING
9$:      CLRB     (R3)      ;;SET THE TERMINATOR
MOV      (SP)+,R5      ;;POP STACK INTO R5
MOV      (CP)+,R3      ;;POP STACK INTO R3
MOV      (SP)+,R2      ;;POP STACK INTO R2
```

```

4527 026160 012601          MOV      (SP)+,R1      ;;POP STACK INTO R1
4528 026162 012600          MOV      (SP)+,R0      ;;POP STACK INTO R0
4529 026164 104401 026212  TYPE      $DBLK      ;;NOW TYPE THE NUMBER
4530 026170 016666 000002 000004  MOV      2(SP),4(SP)   ;;ADJUST THE STACK
4531 026176 012616          MOV      (SP)+,(SP)
4532 026200 000002          RTI                ;;RETURN TO USER
4533 026202 023420          $DTBL: 10000.
4534 026204 001750          1000.
4535 026206 000144          100.
4536 026210 000012          10.
4537 026212 000004          $DBLK: .BLKW 4
  
```



4538  
4539  
4540  
4541  
4542  
4543  
4544  
4545  
4546  
4547  
4548  
4549  
4550  
4551  
4552  
4553  
4554  
4555  
4556  
4557  
4558  
4559  
4560  
4561  
4562  
4563  
4564  
4565  
4566  
4567  
4568  
4569  
4570  
4571  
4572  
4573  
4574  
4575  
4576  
4577  
4578  
4579  
4580  
4581  
4582  
4583  
4584  
4585  
4586  
4587  
4588  
4589  
4590  
4591  
4592  
4593

026222 017646 000000  
026226 116637 000001 026445  
026234 112637 026447  
026240 062716 000002  
026244 000406  
026246 112737 000001 026445  
026254 112737 000006 026447  
026262 112737 000005 026444  
026270 010346  
026272 010446  
026274 010546  
026276 113704 026447  
026302 005404  
026304 062704 000006  
026310 110437 026446  
026314 113704 026445  
026320 016605 000012  
026324 005003  
026326 006105  
026330 000404  
026332 006105  
026334 006105  
026336 006105  
026340 010503  
026342 006103  
026344 105337 026446  
026350 109016  
026352 042703 177770  
026356 001002  
026360 005704  
026362 001403

```
.SBTTL BINARY TO OCTAL (ASCII) AND TYPE
*****
*THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 6-DIGIT
*OCTAL (ASCII) NUMBER AND TYPE IT.
*$TYPOS---ENTER HERE TO SETUP SUPPRESS ZEROS AND NUMBER OF DIGITS TO TYPE
*CALL:
*   MOV     NUM,-(SP)      ;;NUMBER TO BE TYPED
*   TYPOS   ;;CALL FOR TYPEOUT
*   .BYTE  N              ;;N=1 TO 6 FOR NUMBER OF DIGITS TO TYPE
*   .BYTE  M              ;;M=1 OR 0
*                               ;;1=TYPE LEADING ZEROS
*                               ;;0=SUPPRESS LEADING ZEROS
*$TYPON---ENTER HERE TO TYPE OUT WITH THE SAME PARAMETERS AS THE LAST
*$TYPOS OR $TYPOC
*CALL:
*   MOV     NUM,-(SP)      ;;NUMBER TO BE TYPED
*   TYPON   ;;CALL FOR TYPEOUT
*$TYPOC---ENTER HERE FOR TYPEOUT OF A 16 BIT NUMBER
*CALL:
*   MOV     NUM,-(SP)      ;;NUMBER TO BE TYPED
*   TYPOC   ;;CALL FOR TYPEOUT
*$TYPOS: MOV     @ (SP),-(SP)  ;;PICKUP THE MODE
        MOV     1(SP), $OFILL  ;;LOAD ZERO FILL SWITCH
        MOV     (SP)+, $OMODE+1 ;;NUMBER OF DIGITS TO TYPE
        ADD     #2, (SP)      ;;ADJUST RETURN ADDRESS
        BR     $TYPON
*$TYPOC: MOV     #1, $OFILL   ;;SET THE ZERO FILL SWITCH
        MOV     #6, $OMODE+1  ;;SET FOR SIX(6) DIGITS
*$TYPON: MOV     #5, $OCNT    ;;SET THE ITERATION COUNT
        MOV     R3,-(SP)      ;;SAVE R3
        MOV     R4,-(SP)      ;;SAVE R4
        MOV     R5,-(SP)      ;;SAVE R5
        MOV     $OMODE+1, R4  ;;GET THE NUMBER OF DIGITS TO TYPE
        NEG     R4
        ADD     #6, R4        ;;SUBTRACT IT FOR MAX. ALLOWED
        MOV     R4, $OMODE    ;;SAVE IT FOR USE
        MOV     $OFILL, R4    ;;GET THE ZERO FILL SWITCH
        MOV     12(SP), R5    ;;PICKUP THE INPUT NUMBER
        CLR     R3           ;;CLEAR THE OUTPUT WORD
1$:     ROL     R5           ;;ROTATE MSB INTO 'C'
        BR     3$           ;;GO DO MSB
2$:     ROL     R5           ;;FORM THIS DIGIT
        ROL     R5
        ROL     R5
3$:     MOV     R5, R3
        ROL     R3           ;;GET LSB OF THIS DIGIT
        DECB   $OMODE       ;;TYPE THIS DIGIT?
        BPL    7$           ;;BR IF NO
        BIC   #177770, R3   ;;GET RID OF JUNK
        BNE   4$           ;;TEST FOR 0
        TST   R4           ;;SUPPRESS THIS 0?
        BEQ   5$           ;;BR IF YES
```

4594	026364	005204		4\$:	INC	R4	::DON'T SUPPRESS ANYMORE 0'S
4595	026366	052703	000060		BIS	#'0,R3	::MAKE THIS DIGIT ASCII
4596	026372	052703	000040	5\$:	BIS	#',R3	::MAKE ASCII IF NOT ALREADY
4597	026376	110337	026442		MOVB	R3,8\$	::SAVE FOR TYPING
4598	026402	104401	026442		TYPE	,8\$	::GO TYPE THIS DIGIT
4599	026406	105337	026444	7\$:	DECB	\$OCNT	::COUNT BY 1
4600	026412	003347			BGT	2\$	::BR IF MORE TO DO
4601	026414	002402			BLT	6\$	::BR IF DONE
4602	026416	005204			INC	R4	::INSURE LAST DIGIT ISN'T A BLANK
4603	026420	000744			BR	2\$	::GO DO THE LAST DIGIT
4604	026422	012605		6\$:	MOV	(SP)+,R5	::RESTORE R5
4605	026424	012604			MOV	(SP)+,R4	::RESTORE R4
4606	026426	012603			MOV	(SP)+,R3	::RESTORE R3
4607	026430	016666	000002 000004		MOV	2(SP),4(SP)	::SET THE STACK FOR RETURNING
4608	026436	012616			MOV	(SP)+,(SP)	
4609	026440	000002			RTI		::RETURN
4610	026442	000		8\$:	.BYTE	0	::STORAGE FOR ASCII DIGIT
4611	026443	000			.BYTE	0	::TERMINATOR FOR TYPE ROUTINE
4612	026444	000		\$OCNT:	.BYTE	0	::OCTAL DIGIT COUNTER
4613	026445	000		\$OFILL:	.BYTE	0	::ZERO FILL SWITCH
4614	026446	000000		\$UMODE:	.WORD	0	::NUMBER OF DIGITS TO TYPE

4615  
4616  
4617  
4618  
4619  
4620  
4621  
4622  
4623 026450 010046  
4624 026452 016600 000002  
4625 026456 005740  
4626 026460 111000  
4627 026462 006300  
4628 026464 016000 026504  
4629 026470 000200  
4630  
4631  
4632  
4633  
4634 026472 011646  
4635 026474 016666 000004 000002  
4636 026502 000002  
4637  
4638  
4639  
4640  
4641  
4642  
4643  
4644  
4645 026504 026472  
4646 026506 024024  
4647 026510 026246  
4648 026512 026222  
4649 026514 026262  
4650 026516 025776  
4651  
4652 026520 024356  
4653  
4654 026522 024306  
4655 026524 024630  
4656 026526 024750  
4657 026530 011116  
4658  
4659 026532  
4660  
4661  
4662 003174

.SBTTL TRAP DECODER

```

:*****
:*THIS ROUTINE WILL PICKUP THE LOWER BYTE OF THE 'TRAP' INSTRUCTION
:*AND USE IT TO INDEX THROUGH THE TRAP TABLE FOR THE STARTING ADDRESS
:*OF THE DESIRED ROUTINE. THEN USING THE ADDRESS OBTAINED IT WILL
:*GO TO THAT ROUTINE.

```

```

$TRAP: MOV    R0,-(SP)      ;;SAVE R0
        MOV    2(SP),R0    ;;GET TRAP ADDRESS
        TST   -(R0)        ;;BACKUP BY 2
        MOVB  (R0),R0      ;;GET RIGHT BYTE OF TRAP
        ASL   R0           ;;POSITION FOR INDEXING
        MOV   $TRPAD(R0),R0 ;;INDEX TO TABLE
        RTS   R0           ;;GO TO ROUTINE

```

;;THIS IS USE TO HANDLE THE 'GETPRI' MACRO

```

$TRAP2: MOV   (SP),-(SP)   ;;MOVE THE PC DOWN
        MOV   4(SP),2(SP)  ;;MOVE THE PSW DOWN
        RTI                      ;;RESTORE THE PSW

```

.SBTTL TRAP TABLE

```

:*THIS TABLE CONTAINS THE STARTING ADDRESSES OF THE ROUTINES CALLED
:*BY THE 'TRAP' INSTRUCTION.

```

```

:      ROUTINE
:      -----
$TRPAD: .WORD  $TRAP2
        $TYPE  ;;CALL=TYPE      TRAP+1(104401)  TTY TYPEOUT ROUTINE
        $TYPOC ;;CALL=TYPOC    TRAP+2(104402)  TYPE OCTAL NUMBER (WITH LEADING ZEROS)
        $TYPOS ;;CALL=TYPOS    TRAP+3(104403)  TYPE OCTAL NUMBER (NO LEADING ZEROS)
        $TYPON ;;CALL=TYPON    TRAP+4(104404)  TYPE OCTAL NUMBER (AS PER LAST CALL)
        $TYPDS ;;CALL=TYPDS    TRAP+5(104405)  TYPE DECIMAL NUMBER (WITH SIGN)

        $GTSWR ;;CALL=GTSWR    TRAP+6(104406)  GET SOFT-SWR SETTING

        $CKSWR ;;CALL=CKSWR    TRAP+7(104407)  TEST FOR CHANGE IN SOFT-SWR
        $RDCHR ;;CALL=RDCHR    TRAP+10(104410) TTY TYPEIN CHARACTER ROUTINE
        $RDLIN ;;CALL=RDLIN    TRAP+11(104411) TTY TYPEIN STRING ROUTINE
        GT$DEV ;;CALL=GTDEVM   TRAP+12(104412) ^C WILL OPEN UP $DEVM

```

```

LSTAD:      ;MAX ADDR FOR 8K WITH APT = 37400
            ;MAX ADDR FOR 8K NO APT BUT TO SAVE ABS LOADER = 37500
.END      START

```

ABASE = 176500	669#	1151	1192						
ACDW1 = 000000	1151								
ACDW2 = 000000	1151								
ACQM 017170	1907	2594	4062#						
ACPUOP= 000000	1151	1166							
ADDR 004462	1673*	1687*	1692*	1720*	1725*	1753#	4062		
ADDW0 = 000000	1151								
ADDW1 = 000000	1151								
ADDW10= 000000	1151								
ADDW11= 000000	1151								
ADDW12= 000000	1151								
ADDW13= 000000	1151								
ADDW14= 000000	1151								
ADDW15= 000000	1151								
ADDW2 = 000000	1151								
ADDW3 = 000000	1151								
ADDW4 = 000000	1151								
ADDW5 = 000000	1151								
ADDW6 = 000000	1151								
ADDW7 = 000000	1151								
ADDW8 = 000000	1151								
ADDW9 = 000000	1151								
ADEVCT= 000000	1151	1157							
ADEVN = 000017	669#	1151	1193						
AENV = 000000	1151	1162							
AENVN = 000000	1151	1163							
AFATAL= 000000	1151	1154							
AMADR1= 000000	1151	1179							
AMADR2= 000000	1151	1183							
AMADR3= 000000	1151	1186							
AMADR4= 000000	1151	1189							
AMAMS1= 000000	1151	1173							
AMAMS2= 000000	1151	1181							
AMAMS3= 000000	1151	1184							
AMAMS4= 000000	1151	1187							
AMOD = 030000	883#	1884	1886	2612					
AMRB = 176612	842#	1895	3105						
AMRC = 176610	841#	1596*	1597*	1627*	1887*	1896*	1920*	1921*	2613* 2614*
AMRSRV 012622	1891	3105#							
AMRVEC= 000330	815#	1890							
AMSGAD= 000000	1151	1159							
AMSGLG= 000000	1151	1160							
AMSGTY= 000000	1151	1153							
AMTST 005200	1822	1827	1871	1879#					
AMTYP1= 000000	1151	1174							
AMTYP2= 000000	1151	1182							
AMTYP3= 000000	1151	1185							
AMTYP4= 000000	1151	1188							
AMXB = 176616	844#	3102*							
AMXC = 176614	843#	1897*	3101*	3117*					
AMXSRV 012604	1892	3101#							
AMXVEC= 000334	816#								
APASS - 000000	1151	1156							
APRIOR= 000000	1151								
APTCSU- 000040	4093	4352#							
APTENV- 000001	4086	4308	4350#	4383					



CHAR6 = 000004	915#																
CHAR7 = 000010	916#																
CHAR8 = 000014	917#	1787	1884	1886	1928	1930	1962	1964	1996	1998	2612						
CHR5 = 000000	996#																
CHR6 = 002000	997#																
CHR7 = 004000	998#																
CHR8 = 006000	999#	1836															
CKSWR = 104407	2673	4367	4393	4654#													
CKOBAD 011754	2238	2904#															
CK1BAD 012066	2263	2952#															
CLK = 177546	836#	1621*	1765*														
CLKTST 004466	1741	1744	1760#														
CLKVEC= 000100	813#	1512*	1513*	1762*	1763*												
CLOCK 017244	1775	2590	4062#														
CLOPT 017102	2567	4062#															
CLPRES 010742	1914	2563*	2566*	2622#													
CLRBAD 011664	1635	2864#															
CLT1 017122	1950	2595	4062#														
CLT2 017133	1984	2596	4062#														
CLT3 017144	2018	2597	4062#														
CL1TST 005340	1880	1903	1906	1914#													
CL2TST 005530	1924	1946	1949	1957#													
CL3TST 005662	1958	1980	1983	1991#													
COMCHR 012700	1859*	1864	1894*	1900	3102	3106	3110	3112*	3115*	3120#	3128	3129	3152				
	3156	3158*	3161*	4062													
COMHLD 012702	1848*	1849	1895*	3105*	3106	3121#	3149*	3150	3152	4062							
COMPAT 020350	2514	4062#															
COMP1 003132	1494#	1500*	1504*	1508*	1515*	1585	1637	2182	2512	2516*	3593	3772					
COMP2 003134	1495#	1503*	1509*	1516*	1587	1639	2134	2153	2285	2517*	3595	3774					
CONSOL= 010000	878#																
COPDUN 020256	3967	4062#															
COPFLG 003130	1493#	1507*	1517*	1582	1646	3895*											
COPMSG 020155	3896	4062#															
COPY 016354	1648	3895#	3969														
CR = 000015	703#	1792	2995	3008	4132	4142											
CRC = 000010	1049#	3343	3717														
CRLF = 000200	704#	1581	4062	4103	4142												
CTHLD 011400	2750*	2754	2768#														
CTREG 011470	2778*	2782*	2793#	2806*	2810*												
CTREG1 011472	2777*	2785*	2794#	2805*	2813*												
CTS = 020000	934#	967#															
CT1 = 000000	879#	1928	1930														
CT2 = 050000	880#	1962	1964														
CT3 = 060000	881#	1996	1998														
DATCHK 017046	3951	4042#															
DD 000040	1047#	3366															
DDISP - 177570	710#	1134	1547														
DEVN 020445	2680	4062#															
DF 023776	1213	1216	1219	1222	1225	1228	1231	1234	1237	1240	1243	1246	1249				
	1288	1291	1294	1297	1300	1303	1306	1309	1312	1315	1318	1321	1324				
	1327	1330	1333	1336	1342	1345	1348	1351	1354	1357	1360	1363	1390				
	1393	1396	1399	1405	1408	1411	1414	4062#									
DF1 024004	1252	1255	1258	1261	1270	1273	1276	1279	1366	1369	1372	1375	1378				
	1381	1384	1387	1429	1438	4062#											
DF2 024014	1264	1267	1282	1285	1339	1432	1441	4062#									
DH1 023055	1228	1288	1294	1297	1300	1303	1306	1315	1318	1321	4062#						

DH2	023074	1213	1216	1222	4062#											
DH3	023120	1219	1225	4062#												
DH4	023162	1231	1291	4062#												
DH5	023213	1234	1237	1240	1243	1246	1396	1399	4062#							
DH6	023250	1249	1309	1312	1324	1327	1330	1333	1336	1342	1345	1348	1351	1354		
		1357	1360	1363	1390	1393	1405	1408	1411	1414	4062#					
DH7	023315	1252	1255	1258	1261	1270	1273	1276	1279	1366	1369	1372	1375	1378		
		1381	1384	1387	1429	1438	4062#									
DH8	023404	1264	1267	1282	1285	1339	1432	1441	4062#							
DISPLA	001142	1134#	1547*	1555*	4370*											
DISPRE	000174	1061#	1555													
DNA	= 100000	1008#														
DNAIE	= 000040	1014#														
DONE	= 000200	938#	973#	1028#	1844	2039	2047	2061	2075	4013	4032					
DROP	017647	2587	4062#													
DRVO	017232	2591	3478	3492	3511	4062#										
DRV1	017237	2592	3839	3853	3873	4062#										
DSC	= 100000	965#														
DSI	= 100000	932#														
DSIE	= 000040	940#	975#													
DSRDY	= 001000	937#	971#													
DSWR	= 177570	709#	1133	1546												
DTR	= 000002	943#	979#	1596	1597	1627	1837	1887	1920	1921	2613	2614				
DT1	023474	1228	1288	1294	1297	1300	1303	1306	1315	1318	1321	4062#				
DT10	023624	1252	1255	1258	1261	1366	1369	1372	1375	1429	4062#					
DT11	023646	1264	1267	1339	1432	4062#										
DT12	023670	1270	1273	1276	1279	1378	1381	1384	1387	1438	4062#					
DT13	023712	1282	1285	1441	4062#											
DT14	023734	1309	1312	1324	1327	1330	1333	1348	1354	1393	1405	1408	1411	1414		
		4062#														
DT15	023752	1396	4062#													
DT16	023764	1399	4062#													
DT2	023502	1213	1216	1222	4062#											
DT3	023512	1219	1225	4062#												
DT4	023526	1231	1291	4062#												
DT5	023536	1234	4062#													
DT6	023550	1237	4062#													
DT7	023562	1240	4062#													
DT8	023574	1243	1246	4062#												
DT9	023606	1249	1336	1342	1345	1351	1357	1360	1363	1390	4062#					
DUN	017756	1743	1873	3482	3494	3513	3843	3855	3875	4062#						
DXTST	003120	1481#	2030*	2113*	2214*	2302*	2347*	2413*	2451*	3238	3364	3426	3450	3521		
		3523	3882	4062												
DXTST0	006014	1916	1992	2014	2017	2030#										
DXTST1	006256	1644	2035	2092	2113#											
DXTST2	006712	2187	2197	2214#												
DXTST3	007254	2286	2299#													
DXTST4	007430	2300	2313	2344#												
DXTST5	007702	2345	2374	2382	2410#											
DXTST6	010020	2411	2424	2433	2447#											
DX1	= 000020	1030#	2160	2269	2378	2394	3548	3578	3600	3616	3636	3671	3684	3705		
		3714	3753	3857	3876	3924	3937									
DOBAD	002624	1461#	2864	2866	2882	2889	2911	2912								
DOBUF	002424	1460#	2067	2080	2090	3383	3404	3921	4043							
DOCDAT	014104	3384	3399#													
DOCERR	002414	1456#	2120*	2218*	2304*	2324*	2364*	2415*	3424	3439	3445*	3449*	4062			



























.\$APT8	669#	1148#
.\$APTH	669#	1084
.\$APTY	669#	4296
.\$CATC	669#	
.\$CMTA	669#	1106
.\$SEOP	669#	
.\$ERRO	669#	4353
.\$ERRT	669#	4396
.\$READ	669#	4142
.\$SCOP	669#	
.\$STRAP	669#	4615
.\$TYPD	669#	4471
.\$TYPE	669#	4063
.\$TYPO	669#	4538

. ABS. 026532 000 CON RO ABS GBL I

ERRORS DETECTED: 0

Z:CVKDAB/I,Z:CVKDAB.SEQ/CRF/SOL-CVKDAB.P11  
RUN-TIME: 22 13 1 SECONDS  
RUN-TIME RATIO: 129/37-3.4  
CORE USED: 24K (47 PAGES)