

IDENTIFICATION

B 1

SEQ 0001

PRODUCT CODE: AC-B100A-MC
PRODUCT NAME: CVMNFA0 MINC-11 SIZER PROG
DATE: AUGUST 1978
MAINTAINER: DIAGNOSTIC ENGINEERING

COPYRIGHT (C) 1978
DIGITAL EQUIPMENT CORPORATION, MAYNARD, MASS.

THIS SOFTWARE IS FURNISHED UNDER A LICENSE FOR USE ONLY ON A SINGLE COMPUTER SYSTEM AND MAY BE COPIED ONLY WITH THE INCLUSION OF THE ABOVE COPYRIGHT NOTICE. THIS SOFTWARE, OR ANY OTHER COPIES THEREOF, MAY NOT BE PROVIDED OR OTHERWISE MADE AVAILABLE TO ANY OTHER PERSON EXCEPT FOR USE ON SUCH SYSTEM AND TO ONE WHO AGREES TO THESE LICENSE TERMS. TITLE TO AND OWNERSHIP OF THE SOFTWARE SHALL AT ALL TIMES REMAIN IN DEC.

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION.

DEC ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT WHICH IS NOT SUPPLIED BY DEC.

TABLE OF CONTENTS

1.0	ABSTRACT
2.0	REQUIREMENTS
2.1	EQUIPMENT
2.2	STORAGE
3.0	LOADING PROCEDURE
4.0	STARTING PROCEDURE
4.1	PROGRAM START
5.0	SOFTWARE SWITCH REGISTER
5.1	CONTROL
6.0	ERROR REPORTING
7.0	MISCELLANEOUS
7.1	MINC-11 BUS ADDRESS MODIFICATION
7.2	XXDP/APT NOTES
7.3	POWER FAIL
7.4	MULTIPLE MINC-11 OPTION INTERFACE
7.5	RESTRICTIONS
8.0	EXECUTION TIME
9.0	EXAMPLE REPORT
10.0	LISTING

1.0 ABSTRACT

THE PURPOSE OF THE MINC-11 SIZER PROGRAM IS TO VERIFY THE CONFIGURATION OF THE MINC-11 HARDWARE. THE PROGRAM IS TO BE USED TO VERIFY THE CORRECT POSITION OF ANALOG CHANNELS, DEVICE ADDRESS AND VECTOR SWITCHES. THE PROGRAM SIZES THE NUMBER OF MINC-11 OPTIONS AND REPORTS THEIR EXISTANCE, BUS AND VECTOR ADDRESSES. TWO ADDITIONAL REPORTS ARE MADE IF REQUESTED. THE FIRST IS THE MODE OF THE MNCAD (A/D) CHANNELS. THE SECOND IS THE ADDRESS USAGE MAP WHICH IS USEFUL IN DETECTING A INCORRECT ADDRESS SWITCH SETTING. TOTAL PROGRAM CONTROL IS ACCOMPLISHED THRU THE CONSOLE TERMINAL VIA THE PROVISIONS OF SECTION 5.

2.0 REQUIREMENTS

2.1 EQUIPMENT

1. PDP11/03 COMPUTER OR LSI-11 PROCESSOR
2. DLV11 WITH I/O TERMINAL (LA36, VT100, ETC.)
3. MINC-11 SYSTEM

2.2 STORAGE

THE PROGRAM USES THE LOWER 4K OF MEMORY.

3.0 LOADING PROCEDURE <XXDP>

1. ENSURE THAT THE DIAGNOSTIC LOAD MEDIA IS INSTALLED IN DRIVE 0.
2. BOOT THE MEDIA BY TYPING '173000G' IF IN THE ODT MICRO-CODE STATE OR CYCLING THE POWER 'ON-OFF' SWITCH.
3. UPON SUCCESSFUL BOOTING OF THE LOAD MEDIA, THE XXDP MONITOR WILL IDENTIFY ITSELF AND INFORM THE OPERATOR OF THE OPERATING OPTIONS THAT MAYBE SELECTED.
4. THE OPERATOR SHOULD TYPE 'R VMNF??' FOLLOWED BY A 'RETURN' THE XXDP MONITOR WILL LOAD THE PROGRAM INTO MEMORY AND START THE PROGRAM AT LOCATION 200.

4.0 STARTING PROCEDURE

1. THE PROGRAM WILL RESPOND BY TYPING THE PROGRAM TITLE.
2. THE PROGRAM WILL NOW ASK IF THE OPERATOR WANTS THE REPORT OF THE MODES OF THE MNCAD (A/D) CHANNELS.
3. THE PROGRAM WILL NOW ASK IF THE OPERATOR WANTS THE REPORT OF THE ADDRESS USAGE MAP.
4. THE PROGRAM WILL THEN SIZE THE MINC-11 SYSTEM AND REPORT THE DEVICE BUS AND VECTOR ADDRESSES AND SELECTED REPORTS.

4.1 PROGRAM START

200

STARTING ADDRESS OF THE PROGRAM

5.0 SOFTWARE SWITCH REGISTER

NONE

5.1 PROGRAM CONTROL

THE SIZING MAYBE STOPPED BY TYPING THE 'CONTROL & C' KEYS. THIS OPERATION WILL STOP THE PROGRAM AND ENABLE THE OPERATOR TO SELECT DIFFERENT PROGRAM REPORT'S.

6.0 ERROR REPORTING

NONE, NO ERROR MESSAGES ARE REPORTED.

7.0 MISCELLANEOUS

7.1 MINC-11 BUS ADDRESS MODIFICATION

MODIFY LOCATION '\$BASE' (LOC. 1240) IF BASE BUS ADDRESS IS NOT 171000.

7.2 XXDP/APT NOTES

THIS PROGRAM IS CHAINABLE UNDER XXDP (REQUIRES 8K OR MORE). WHEN RUN IN 'CHAIN' MODE, THE PROGRAM WILL REQUIRE THE OPERATOR TO PERFORM INITIAL SETUP OPERATIONS. THE SIZER PROGRAM SHOULD NOT BE INCLUDED IN A 'CHAIN' THAT LOOPS TO THE STARTING FILE. THIS PROGRAM DOES SUPPORT 'APT' BUT HAS NOT BEEN RUN UNDER IT.

7.3 POWER FAIL

A POWER FAILURE WILL CAUSE A RESTART MESSAGE ON POWER UP AT WHICH TIME THE PROGRAM IS RESTARTED (ONLY ON SYSTEMS WITH NON-VOLATILE MEMORY AND WITH APPROPRIATE HARDWARE).

7.4 MULTIPLE MINC-11 OPTION INTERFACE TESTING

THIS PROGRAM DOES 'AUTO-SIZE' THE NUMBER OF MINC-11 OPTIONS CONNECTED. THE PROGRAM WILL SIZE SEQUENTIALLY UP TO:

4	MNCAD (A/D)'S
8	MNCKW (CLOCK)'S
8	MNCAA (D/A)'S
8	MNCDO (DIGITAL OUT)'S
8	MNCDI (DIGITAL IN)'S

EACH MINC-11 OPTION MUST BE CONFIGURED WITH CONTIGUOUS BUS ADDRESSES.

7.5 RESTRICTIONS

ALL USER CONNECTIONS MUST BE REMOVED.

8.0 EXECUTION TIME

DEPENDANT UPON TERMINAL SPEED AND REPORTS SELECTED.

A 'TYPICAL' SIZER REPORT FOR A SYSTEM WITH THE FOLLOWING:

171000	MNCAD	171020	MNCKW
171060	MNCAA	171160	MNCDI
171260	MNCDO	171420	IBV-11
173000-173776	BOOT-STRAP PROM		
176500-176526	SLU 0, 1, AND 2		
177170	RX01 DISK SUB-SYSTEM		
177560-177566	CONSOLE TERMINAL		

DO YOU WANT THE MNCAD (A/D) CHANNEL MODE REPORT ?

TYPE 'Y' FOR YES = Y

DO YOU WANT THE MEMORY USAGE MAP REPORT ?

TYPE 'Y' FOR YES = Y

;MNCAD AT ADDRESS = 171000 VECTOR = 400

0 - 7 SINGLE ENDED

10 - 13 DIFFERENTIAL

14 - 17 DIFFERENTIAL

20 - 23 DIFFERENTIAL

;MNCKW AT ADDRESS = 171020 VECTOR = 400

;MNCAA AT ADDRESS = 171060 VECTOR = ** DOES NOT EXIST **

;MNCDI AT ADDRESS = 171160 VECTOR = 130

;MNCDO AT ADDRESS = 171260 VECTOR = 340

OF ;MNCAD 1 ;MNCKW 1 ;MNCAA 1 ;MNCDI 1 ;MNCDO 1

MNC11 MEMORY USAGE MAP (EACH BIT = 2 ADDRESSES)

ADDR	000/400	100/500	200/600	300/700
170000	0000000000000000	0000000000000000	0000000000000000	0000000000000000
170400	0000000000000000	0000000000000000	0000000000000000	0000000000000000
171000	10001000000001100	00000000000001100	00000000000001000	0000000000000000
171400	00001100000000000	00000000000000000	00000000000000000	00000000000000000
172000	00000000000000000	00000000000000000	00000000000000000	00000000000000000
172400	00000000000000000	00000000000000000	00000000000000000	00000000000000000
173000	11111111111111111	11111111111111111	11111111111111111	11111111111111111
173400	11111111111111111	11111111111111111	11111111111111111	11111111111111111
174000	00000000000000000	00000000000000000	00000000000000000	00000000000000000
174400	00000000000000000	00000000000000000	00000000000000000	00000000000000000
175000	00000000000000000	00000000000000000	00000000000000000	00000000000000000
175400	00000000000000000	00000000000000000	00000000000000000	00000000000000000
176000	00000000000000000	00000000000000000	00000000000000000	00000000000000000
176400	00000000000000000	11111100000000000	00000000000000000	00000000000000000
177000	00000000000000000	00000000000000010	00000000000000000	00000000000000000
177400	00000000000000000	00000000000001100	00000000000000000	00000000000000000

END PASS # 1

TABLE OF CONTENTS

13	BASIC DEFINITIONS
18	TRAP CATCHER
39	ACT11 HOOKS
41	APT PARAMETER BLOCK
42	COMMON TAGS
(2)	APT MAILBOX-ETABLE
(1)	ERROR POINTER TABLE
79	INITIAL START-UP,HOUSEKEEPING, AND DIALOGUE
81	INITIALIZE THE COMMON TAGS
102	TYPE PROGRAM NAME
254	END OF PASS ROUTINE
519	TTY INPUT ROUTINE
520	TYPE ROUTINE
522	BINARY TO OCTAL (ASCII) AND TYPE
523	CONVERT BINARY TO DECIMAL AND TYPE ROUTINE
524	BINARY TO ASCII AND TYPE ROUTINE
525	APT COMMUNICATIONS ROUTINE
527	TRAP DECODER
(3)	TRAP TABLE

```

12      .TITLE MAINDEC-11-DVMNF-A      MINC-11 OPTION SIZER PROGRAM
(1)    .*COPYRIGHT (C) 1978
(1)    .*DIGITAL EQUIPMENT CORP.
(1)    .*MAYNARD, MASS. 01754
(1)    .*
(1)    .*PROGRAM BY R SHOOP
(1)    .*
(1)    .*THIS PROGRAM WAS ASSEMBLED USING THE PDP-11 MAINDEC SYSMAC
(1)    .*PACKAGE (MAINDEC-11-DZQAC-C3), JAN 19, 1977.
(1)    .*
13      .SBTTL BASIC DEFINITIONS
(1)
(1)    .*INITIAL ADDRESS OF THE STACK POINTER *** 1100 ***
(1)    001100  STACK= 1100
(1)    .EQUIV EMT,ERROR      ;;BASIC DEFINITION OF ERROR CALL
(1)    .EQUIV IOT,SCOPE     ;;BASIC DEFINITION OF SCOPE CALL
(1)
(1)    .*MISCELLANEOUS DEFINITIONS
(1)    000011  HT= 11      ;;CODE FOR HORIZONTAL TAB
(1)    000012  LF= 12      ;;CODE FOR LINE FEED
(1)    000015  CR= 15      ;;CODE FOR CARRIAGE RETURN
(1)    000200  CRLF= 200   ;;CODE FOR CARRIAGE RETURN-LINE FEED
(1)    177776  PS= 177776  ;;PROCESSOR STATUS WORD
(1)    .EQUIV PS,PSW
(1)    177774  STKLMT= 177774 ;;STACK LIMIT REGISTER
(1)    177772  PIRQ= 177772 ;;PROGRAM INTERRUPT REQUEST REGISTER
(1)    177570  DSWR= 177570 ;;HARDWARE SWITCH REGISTER
(1)    177570  DDISP= 177570 ;;HARDWARE DISPLAY REGISTER
(1)
(1)    .*GENERAL PURPOSE REGISTER DEFINITIONS
(1)    000000  R0= %0      ;;GENERAL REGISTER
(1)    000001  R1= %1      ;;GENERAL REGISTER
(1)    000002  R2= %2      ;;GENERAL REGISTER
(1)    000003  R3= %3      ;;GENERAL REGISTER
(1)    000004  R4= %4      ;;GENERAL REGISTER
(1)    000005  R5= %5      ;;GENERAL REGISTER
(1)    000006  R6= %6      ;;GENERAL REGISTER
(1)    000007  R7= %7      ;;GENERAL REGISTER
(1)    000006  SP= %6      ;;STACK POINTER
(1)    000007  PC= %7      ;;PROGRAM COUNTER
(1)
(1)    .*PRIORITY LEVEL DEFINITIONS
(1)    000000  PR0= 0      ;;PRIORITY LEVEL 0
(1)    000040  PR1= 40     ;;PRIORITY LEVEL 1
(1)    000100  PR2= 100    ;;PRIORITY LEVEL 2
(1)    000140  PR3= 140    ;;PRIORITY LEVEL 3
(1)    000200  PR4= 200    ;;PRIORITY LEVEL 4
(1)    000240  PR5= 240    ;;PRIORITY LEVEL 5
(1)    000300  PR6= 300    ;;PRIORITY LEVEL 6
(1)    000340  PR7= 340    ;;PRIORITY LEVEL 7
(1)
(1)    .*'SWITCH REGISTER' SWITCH DEFINITIONS
(1)    100000  SW15= 100000
(1)    040000  SW14= 40000

```



```
(1) 020000 SW13= 20000
(1) 010000 SW12= 10000
(1) 004000 SW11= 4000
(1) 002000 SW10= 2000
(1) 001000 SW09= 1000
(1) 000400 SW08= 400
(1) 000200 SW07= 200
(1) 000100 SW06= 100
(1) 000040 SW05= 40
(1) 000020 SW04= 20
(1) 000010 SW03= 10
(1) 000004 SW02= 4
(1) 000002 SW01= 2
(1) 000001 SW00= 1
(1) .EQUIV SW09,SW9
(1) .EQUIV SW08,SW8
(1) .EQUIV SW07,SW7
(1) .EQUIV SW06,SW6
(1) .EQUIV SW05,SW5
(1) .EQUIV SW04,SW4
(1) .EQUIV SW03,SW3
(1) .EQUIV SW02,SW2
(1) .EQUIV SW01,SW1
(1) .EQUIV SW00,SW0
(1)
(1) ;*DATA BIT DEFINITIONS (BIT00 TO BIT15)
(1) 100000 BIT15= 100000
(1) 040000 BIT14= 40000
(1) 020000 BIT13= 20000
(1) 010000 BIT12= 10000
(1) 004000 BIT11= 4000
(1) 002000 BIT10= 2000
(1) 001000 BIT09= 1000
(1) 000400 BIT08= 400
(1) 000200 BIT07= 200
(1) 000100 BIT06= 100
(1) 000040 BIT05= 40
(1) 000020 BIT04= 20
(1) 000010 BIT03= 10
(1) 000004 BIT02= 4
(1) 000002 BIT01= 2
(1) 000001 BIT00= 1
(1) .EQUIV BIT09,BIT9
(1) .EQUIV BIT08,BIT8
(1) .EQUIV BIT07,BIT7
(1) .EQUIV BIT06,BIT6
(1) .EQUIV BIT05,BIT5
(1) .EQUIV BIT04,BIT4
(1) .EQUIV BIT03,BIT3
(1) .EQUIV BIT02,BIT2
(1) .EQUIV BIT01,BIT1
(1) .EQUIV BIT00,BIT0
(1)
(1) ;*BASIC 'CPU' TRAP VECTOR ADDRESSES
```

```
(1) 000004 ERRVEC= 4 ;;TIME OUT AND OTHER ERRORS
(1) 000010 RESVEC= 10 ;;RESERVED AND ILLEGAL INSTRUCTIONS
(1) 000014 TBITVEC=14 ;;'T' BIT
(1) 000014 TRTVEC= 14 ;;TRACE TRAP
(1) 000014 BPTVEC= 14 ;;BREAKPOINT TRAP (BPT)
(1) 000020 IOTVEC= 20 ;;INPUT/OUTPUT TRAP (IOT) **SCOPE**
(1) 000024 PWRVEC= 24 ;;POWER FAIL
(1) 000030 EMTVEC= 30 ;;EMULATOR TRAP (EMT) **ERROR**
(1) 000034 TRAPVEC=34 ;;'TRAP' TRAP
(1) 000060 TKVEC= 60 ;;TTY KEYBOARD VECTOR
(1) 000064 TPVEC= 64 ;;TTY PRINTER VECTOR
(1) 000240 PIRQVEC=240 ;;PROGRAM INTERRUPT REQUEST VECTOR
14 171000 ABASE= 171000
15 000100 .=100
16 000100 000104 000200 000002 .WORD 104,200,2 ;B EVENT VECTOR
17
18 .SBTTL TRAP CATCHER
19
20 000000 .=0
21 ;*ALL UNUSED LOCATIONS FROM 4-776 CONTAIN A ".+2"
22 ;*AND "JSR PC,RO" SEQUENCE TO CATCH ILLEGAL INTERRUPTS.
23 ;*AND INTERRUPTS TO THE WRONG VECTOR.
24 ;*LOCATION 0 CONTAINS A 0 TO CATCH IMPROPERLY LOADED
25 ;*VECTORS.
35
36 000200 .=200
37 000200 000137 001324 JMP BEGIN ;START ADDRESS
```



```
39          .SBTTL ACT11 HOOKS
(1)
(2)          ::*****
(1)          ;HOOKS REQUIRED BY ACT11
(1)          000204      $SVPC=.          ;SAVE PC
(1)          000046      .=46
(1) 000046 002644      $ENDAD          ;;1)SET LOC.46 TO ADDRESS OF $ENDAD IN .$EOP
(1)          000052      .=52
(1) 000052 000000      .WORD 0          ;;2)SET LOC.52 TO ZERO
(1)          000204      .= $SVPC          ;; RESTORE PC
(1)          40          .=1000
(1)          41          .SBTTL APT PARAMETER BLOCK
(1)
(2)          ::*****
(1)          ;SET LOCATIONS 24 AND 44 AS REQUIRED FOR APT
(2)          ::*****
(1)          001000      .$X=.          ;;SAVE CURRENT LOCATION
(1)          000024      .=24          ;;SET POWER FAIL TO POINT TO START OF PROGRAM
(1) 000024 000200      200          ;;FOR APT START UP
(1)          000044      .=44          ;;POINT TO APT INDIRECT ADDRESS PNTR.
(1) 000044 001000      $APTHDR      ;;POINT TO APT HEADER BLOCK
(1)          001000      .=.$X          ;;RESET LOCATION COUNTER
(2)          ::*****
(1)          ;SETUP APT PARAMETER BLOCK AS DEFINED IN THE APT-PDP11 DIAGNOSTIC
(1)          ;INTERFACE SPEC.
(1)
(1) 001000      $APTHD:
(1) 001000 000000      $HIBTS: .WORD 0          ;;TWO HIGH BITS OF 18 BIT MAILBOX ADDR.
(1) 001002 001164      $MBADR: .WORD $MAIL      ;;ADDRESS OF APT MAILBOX (BITS 0-15)
(1) 001004 002260      $TSTM: .WORD 1200.      ;;RUN TIM OF LONGEST TEST
(1) 001006 000764      $PASTM: .WORD 500.      ;;RUN TIME IN SECS. OF 1ST PASS ON 1 UNIT (QUICK VERIFY)
(1) 001010 003244      $UNITM: .WORD 1700.      ;;ADDITIONAL RUN TIME (SECS) OF A PASS FOR EACH ADDITIONAL UNIT
(1) 001012 000031      .WORD $ETEND-$MAIL/2 ;;LENGTH MAILBOX-ETABLE(WORDS)
```

42

.SBTTL COMMON TAGS

(1)

(2)

(1)

(1)

(1)

(1)

(1)

(1)

(1)

(1)

(1)

(1)

(1)

(1)

(1)

(1)

(1)

(1)

(1)

(1)

(1)

(1)

(1)

(1)

(1)

(1)

(1)

(1)

(1)

(1)

(1)

(1)

(1)

(1)

(1)

(1)

(2)

(2)

(2)

(3)

(2)

(2)

(2)

(2)

(2)

(2)

(2)

(2)

(2)

(2)

::*****
:*THIS TABLE CONTAINS VARIOUS COMMON STORAGE LOCATIONS
:*USED IN THE PROGRAM.

.=1100

\$CMTAG: ;:START OF COMMON TAGS

.WORD 0 ;:CONTAINS THE TEST NUMBER

\$.STNM: .BYTE 0 ;:CONTAINS ERROR FLAG

\$.ERFLG: .BYTE 0 ;:CONTAINS SUBTEST ITERATION COUNT

\$.ICNT: .WORD 0 ;:CONTAINS SCOPE LOOP ADDRESS

\$.LPADR: .WORD 0 ;:CONTAINS SCOPE RETURN FOR ERRORS

\$.LPERR: .WORD 0 ;:CONTAINS TOTAL ERRORS DETECTED

\$.ERTTL: .WORD 0 ;:CONTAINS ITEM CONTROL BYTE

\$.ITEMB: .BYTE 0 ;:CONTAINS MAX. ERRORS PER TEST

\$.ERMAX: .BYTE 1 ;:CONTAINS PC OF LAST ERROR INSTRUCTION

\$.ERRPC: .WORD 0 ;:CONTAINS ADDRESS OF 'GOOD' DATA

\$.GDADR: .WORD 0 ;:CONTAINS ADDRESS OF 'BAD' DATA

\$.BDADR: .WORD 0 ;:CONTAINS 'GOOD' DATA

\$.GDDAT: .WORD 0 ;:CONTAINS 'BAD' DATA

\$.BDDAT: .WORD 0 ;:RESERVED--NOT TO BE USED

.WORD 0 ;:RESERVED--NOT TO BE USED

\$.AUTOB: .BYTE 0 ;:AUTOMATIC MODE INDICATOR

\$.INTAG: .BYTE 0 ;:INTERRUPT MODE INDICATOR

.WORD 0 ;:RESERVED--NOT TO BE USED

\$.SWR: .WORD DSWR ;:ADDRESS OF SWITCH REGISTER

\$.DISPLAY: .WORD DDISP ;:ADDRESS OF DISPLAY REGISTER

\$.TKS: 177560 ;:TTY KBD STATUS

\$.TKB: 177562 ;:TTY KBD BUFFER

\$.TPS: 177564 ;:TTY PRINTER STATUS REG. ADDRESS

\$.TPB: 177566 ;:TTY PRINTER BUFFER REG. ADDRESS

\$.NULL: .BYTE 0 ;:CONTAINS NULL CHARACTER FOR FILLS

\$.FILLS: .BYTE 2 ;:CONTAINS # OF FILLER CHARACTERS REQUIRED

\$.FILLC: .BYTE 12 ;:INSERT FILL CHARS. AFTER A 'LINE FEED'

\$.TPFLG: .BYTE 0 ;:'TERMINAL AVAILABLE' FLAG (BIT<07>=0=YES)

\$.QUES: .ASCII /?/ ;:QUESTION MARK

\$.CRLF: .ASCII <15> ;:CARRIAGE RETURN

\$.LF: .ASCII <12> ;:LINE FEED

::*****

.SBTTL APT MAILBOX-ETABLE

::*****

.EVEN

\$.MAIL: ;:APT MAILBOX

\$.MSGTY: .WORD AMSGTY ;:MESSAGE TYPE CODE

\$.FATAL: .WORD AFATAL ;:FATAL ERROR NUMBER

\$.TESTN: .WORD ATESTN ;:TEST NUMBER

\$.PASS: .WORD APASS ;:PASS COUNT

\$.DEVCT: .WORD ADEVCT ;:DEVICE COUNT

\$.UNIT: .WORD AUNIT ;:I/O UNIT NUMBER

\$.MSGAD: .WORD AMSGAD ;:MESSAGE ADDRESS

\$.MSGLG: .WORD AMSGLG ;:MESSAGE LENGTH


```
(2) 001204          $ETABLE:          ;;APT ENVIRONMENT TABLE
(2) 001204          $ENV: .BYTE   AENV          ;;ENVIRONMENT BYTE
(2) 001205          $ENVM: .BYTE   AENVM         ;;ENVIRONMENT MODE BITS
(2) 001206          $$WREG: .WORD   ASWREG        ;;APT SWITCH REGISTER
(2) 001210          $USWR: .WORD   AUSWR         ;;USER SWITCHES
(2) 001212          $CPUOP: .WORD   ACPUOP        ;;CPU TYPE,OPTIONS
(2)                : *          BITS 15-11=CPU TYPE
(2)                : *          11/04=01,11/05=02,11/20=03,11/40=04,11/45=05
(2)                : *          11/70=06,PDQ=07,Q=10
(2)                : *          BIT 10=REAL TIME CLOCK
(2)                : *          BIT 9=FLOATING POINT PROCESSOR
(2)                : *          BIT 8=MEMORY MANAGEMENT
(2) 001214          $MAMS1: .BYTE   AMAMS1        ;;HIGH ADDRESS,M.S. BYTE
(2) 001215          $MTYP1: .BYTE   AMTYP1        ;;MEM. TYPE,BLK#1
(2)                : *          MEM.TYPE BYTE -- (HIGH BYTE)
(2)                : *          900 NSEC CORE=001
(2)                : *          300 NSEC BIPOLAR=002
(2)                : *          500 NSEC MOS=003
(2) 001216          $MADR1: .WORD   AMADR1        ;;HIGH ADDRESS,BLK#1
(2)                : *          MEM.LAST ADDR.=3 BYTES,THIS WORD AND LOW OF 'TYPE' ABOVE
(2) 001220          $MAMS2: .BYTE   AMAMS2        ;;HIGH ADDRESS,M.S. BYTE
(2) 001221          $MTYP2: .BYTE   AMTYP2        ;;MEM. TYPE,BLK#2
(2) 001222          $MADR2: .WORD   AMADR2        ;;MEM.LAST ADDRESS,BLK#2
(2) 001224          $MAMS3: .BYTE   AMAMS3        ;;HIGH ADDRESS,M.S.BYTE
(2) 001225          $MTYP3: .BYTE   AMTYP3        ;;MEM. TYPE,BLK#3
(2) 001226          $MADR3: .WORD   AMADR3        ;;MEM.LAST ADDRESS,BLK#3
(2) 001230          $MAMS4: .BYTE   AMAMS4        ;;HIGH ADDRESS,M.S.BYTE
(2) 001231          $MTYP4: .BYTE   AMTYP4        ;;MEM. TYPE,BLK#4
(2) 001232          $MADR4: .WORD   AMADR4        ;;MEM.LAST ADDRESS,BLK#4
(2) 001234          $VECT1: .WORD   AVECT1        ;;INTERRUPT VECTOR#1,BUS PRIORITY#1
(2) 001236          $VECT2: .WORD   AVECT2        ;;INTERRUPT VECTOR#2BUS PRIORITY#2
(2) 001240          $BASE: .WORD   ABASE         ;;BASE ADDRESS OF EQUIPMENT UNDER TEST
(2) 001242          $DEVN: .WORD   ADEVN         ;;DEVICE MAP
(2) 001244          $CDW1: .WORD   ACDW1         ;;CONTROLLER DESCRIPTION WORD#1
(2) 001246          $ETEND:
(2)                .MEXIT
```

```

(1)          .SBTTL  ERROR POINTER TABLE
(1)
(1)          ;*THIS TABLE CONTAINS THE INFORMATION FOR EACH ERROR THAT CAN OCCUR.
(1)          ;*THE INFORMATION IS OBTAINED BY USING THE INDEX NUMBER FOUND IN
(1)          ;*LOCATION $ITEMB. THIS NUMBER INDICATES WHICH ITEM IN THE TABLE IS PERTINENT.
(1)          ;*NOTE1:      IF $ITEMB IS 0 THE ONLY PERTINENT DATA IS ($ERRPC).
(1)          ;*NOTE2:      EACH ITEM IN THE TABLE CONTAINS 4 POINTERS EXPLAINED AS FOLLOWS:
(1)
(1)          ;*      EM      ;;POINTS TO THE ERROR MESSAGE
(1)          ;*      DH      ;;POINTS TO THE DATA HEADER
(1)          ;*      DT      ;;POINTS TO THE DATA
(1)          ;*      DF      ;;POINTS TO THE DATA FORMAT
(1)
(1)          $ERRTB:
(1)          ;NO ERRORS ARE REPORTED
(1)
(1)          43
(1)          44
(1)          45
(1)          46 001246 000020      KWOFF: 20      ;OFFSET FROM $BASE VALUE TO KW ADDRESS.
(1)          47 001250 000060      AAOFF: 60      ;OFFSET FROM $BASE VALUE TO AA ADDRESS
(1)          48 001252 000160      DIOFF: 160     ;OFFSET FROM $BASE VALUE TO DI ADDRESS
(1)          49 001254 000260      DOOFF: 260     ;OFFSET FROM $BASE VALUE TO DO ADDRESS
(1)          50
(1)          51          ;PROGRAM CREATES THESE ADDRESSES FROM THE VALUE OF $BASE PLUS THE OFFSET FOR THAT DEVICE
(1)          52
(1)          53 001256 171000      ADBASE: 171000
(1)          54 001260 171020      KWBASE: 171020
(1)          55 001262 171060      AABASE: 171060
(1)          56 001264 171160      DIBASE: 171160
(1)          57 001266 171260      DOBASE: 171260
(1)          58
(1)          59          ;COUNT OF EACH UNIT FOUND
(1)          60
(1)          61 001270 000000      ADCNT: 0
(1)          62 001272 000000      KWCNT: 0
(1)          63 001274 000000      AACNT: 0
(1)          64 001276 000000      DICNT: 0
(1)          65 001300 000000      DOCNT: 0
(1)          66
(1)          67          ;MISC. TEMP LOCATIONS
(1)          68 001302 000000      VADR: 0
(1)          69 001304 000000      VECT: 0
(1)          70 001306 000000      TEMP: 0
(1)          71 001310 000000      NBEXT: 0
(1)          72 001312 010114      OUTADR: ADRPOK      ;ADDRESS VALUE FOR MEMORY USAGE
(1)          73 001314 000000      FLAGMP: 0           ;NON-ZERO INDICATES MEMORY USAGE MAP IS WANTED
(1)          74 001316 000000      FLAGAD: 0           ;NON-ZERO INDICATES THE A/D CHANNEL MODES BE REPORTED
(1)          75 001320 000000      SWREG: 0            ;HERE BECAUSE OF SYSMAC
(1)          76 001322 000000      DISPRE: 0           ;HERE BECAUSE OF SYSMAC

```



```

79          .SBTTL          INITIAL START-UP,HOUSEKEEPING, AND DIALOGUE
80 001324 000005 BEGIN: RESET
81          .SBTTL          INITIALIZE THE COMMON TAGS
(1)          ;;CLEAR THE COMMON TAGS ($CMTAG) AREA
(1) 001326 012706 001100 MOV    #CMTAG,R6          ;;FIRST LOCATION TO BE CLEARED
(1) 001332 005026 CLR    (R6)+              ;;CLEAR MEMORY LOCATION
(1) 001334 022706 001140 CMP    #SWR,R6 ;;DONE?
(1) 001340 001374 BNE    -6                ;;LOOP BACK IF NO
(1) 001342 012706 001100 MOV    #STACK,SP          ;;SETUP THE STACK POINTER
(1)          ;;INITIALIZE A FEW VECTORS
(1) 001346 012737 010036 000034 MOV    #STRAP,@#TRAPVEC ;;TRAP VECTOR FOR TRAP CALLS
(1) 001354 012737 000340 000036 MOV    #340,@#TRAPVEC+2;LEVEL 7
(1) 001362 013737 002612 002604 MOV    $ENDCT,$EOPCT    ;;SETUP END-OF-PROGRAM COUNTER
(2)          ;;SIZE FOR A HARDWARE SWITCH REGISTER. IF NOT FOUND OR IT IS
(2)          ;;EQUAL TO A '-1', SETUP FOR A SOFTWARE SWITCH REGISTER.
(2) 001370 013746 000004 MOV    @#ERRVEC,-(SP)    ;;SAVE ERROR VECTOR
(2) 001374 012737 001430 000004 MOV    #64$,@#ERRVEC    ;;SET UP ERRVEC VECTOR
(2) 001402 012737 177570 001140 MOV    #DSWR,SWR        ;;SETUP FOR A HARDWARE SWICH REGISTER
(2) 001410 012737 177570 001142 MOV    #DDISP,DISPLAY   ;;AND A HARDWARE DISPLAY REGISTER
(2) 001416 022777 177777 177514 CMP    #-1,@SWR         ;;TRY TO REFERENCE HARDWARE SWR
(2) 001424 001012 BNE    66$              ;;BRANCH IF NO TIMEOUT TRAP OCCURRED
(2)          ;;AND THE HARDWARE SWR IS NOT = -1
(2) 001426 000403 BR     65$                ;;BRANCH IF NO TIMEOUT
(2) 001430 012716 001436 64$: MOV    #65$,(SP)          ;;SET UP FOR TRAP RETURN
(2) 001434 000002 RTI
(2) 001436 012737 001320 001140 65$: MOV    #SWREG,SWR        ;;POINT TO SOFTWARE SWR
(2) 001444 012737 001322 001142 MOV    #DISPREG,DISPLAY
(2) 001452 012637 000004 66$: MOV    (SP)+,@#ERRVEC    ;;RESTORE ERROR VECTOR
(1)
(2) 001456 005037 001172 CLR    $PASS            ;;CLEAR PASS COUNT
(2) 001462 132737 000200 001205 BITB   #APTSIZE,$ENVM    ;;TEST USER SIZE UNDER APT
(2) 001470 001403 BEQ    67$                ;;YES,USE NON-APT SWITCH
(2) 001472 012737 001206 001140 MOV    #SSWREG,SWR      ;;NO,USE APT SWITCH REGISTER
(2) 001500 67$:
82 001500 012737 005046 006560 MOV    #5046,$TYPE
83 001506 012737 012746 006562 MOV    #12746,$TYPE+2
84 001514 012737 006572 006564 MOV    # $TYPE+12,$TYPE+4
85 001522 012737 000002 006566 MOV    #RTI,$TYPE+6
86 001530 004737 005656 JSR    PC,$TKINT        ;;INIT THE TKB
87 001534 013737 001240 001256 MOV    $BASE,ADBASE    ;;GET INITIAL BASE
88 001542 013737 001256 001260 MOV    ADBASE,KWBASE   ;;GET KW BASE
89 001550 063737 001246 001260 ADD    KWOFF,KWBASE    ;;UPDATE KW ADDRESS
90 001556 013737 001256 001262 MOV    ADBASE,AABASE   ;;GET AA BASE
91 001564 063737 001250 001262 ADD    AAOFF,AABASE    ;;UPDATE AA ADDRESS
92 001572 013737 001256 001264 MOV    ADBASE,DIBASE   ;;GET DI BASE
93 001600 063737 001252 001264 ADD    DIOFF,DIBASE    ;;UPDATE DI ADDRESS
94 001606 013737 001256 001266 MOV    ADBASE,DOBASE   ;;GET DO BASE
95 001614 063737 001254 001266 ADD    DOOFF,DOBASE    ;;UPDATE DO ADDRESS
96 001622 005037 001270 CLR    ADCNT           ;;CLEAR THE UNIT COUNTERS
97 001626 005037 001272 CLR    KWCNT
98 001632 005037 001274 CLR    AACNT
99 001636 005037 001276 CLR    DICNT
100 001642 005037 001300 CLR    DOCNT

```

```

102      .SBTTL  TYPE PROGRAM NAME
(1)      ;;TYPE THE NAME OF THE PROGRAM IF FIRST PASS
(1) 001646 005227 177777      INC      #-1          ;;FIRST TIME?
(1) 001652 001036             BNE      68$          ;;BRANCH IF NO
(1) 001654 022737 002644 000042  CMP      #$ENDAD,@#42  ;;ACT-11?
(1) 001662 001432             BEQ      68$          ;;BRANCH IF YES
(1) 001664 104401 001672      TYPE     ,69$        ;;TYPE ASCIZ STRING
(1) 001670 000427             BR       68$          ;;GET OVER THE ASCIZ
(1)      ;;69$: .ASCIZ <CRLF>#MD-11-DVMNF-A  MINC-11 OPTION SIZER PROGRAM#<CRLF>
(1)      68$:
103 001750 105737 001205      TSTB    $ENVM        ;CHECK APT MODE?
104 001754 001042             BNE     LOOP         ;BR IF YES
105 001756 005737 000042      TST     CHAIN        ;CHECK XXDP/ACT MODE?
106 001762 001405             BEQ     1$           ;BR IF NOT
107 001764 104401 004664      TYPE    ,SETMNC      ;TELL OPER. ABOUT SETUP STUFF
108 001770 104407             RDCHR   ;GET A CHAR
109 001772 012600             MOV     (SP)+,R0     ;READ WHATEVER CHARACTER
110 001774 000432             BR      LOOP         ;RUN TEST WHEN OPER IS READY
111 001776 104401 004262      1$:     TYPE    ,QUESAD ;ASK OPERATOR ABOUT A/D MODE
112 002002 104407             RDCHR   ;GET OPER INPUT
113 002004 012600             MOV     (SP)+,R0     ;
114 002006 042700 177600      BIC     #177600,R0   ;MASK OFF JUNK
115 002012 005037 001316      CLR     FLAGAD       ;INIT THE EXPANDED A/D REPORT
116 002016 122700 000131      CMPB   #'Y,R0       ;CHECK IF 'Y'
117 002022 001002             BNE     2$           ;BR IF NOT
118 002024 005237 001316      INC     FLAGAD       ;SET EXPANDED A/D REPORT
119 002030 104401 004373      2$:     TYPE    ,QUESMP ;ASK OPERATOR ABOUT MEMORY USAGE MAP
120 002034 104407             RDCHR   ;GET OPER INPUT
121 002036 012600             MOV     (SP)+,R0     ;
122 002040 042700 177600      BIC     #177600,R0   ;MASK OFF JUNK
123 002044 005037 001314      CLR     FLAGMP       ;INIT THE MEMORY USAGE REPORT
124 002050 122700 000131      CMPB   #'Y,R0       ;CHECK IF 'Y'
125 002054 001002             BNE     LOOP         ;BR IF NOT
126 002056 005237 001314      INC     FLAGMP       ;SET MEMORY USAGE FLAG
127
128      ;NOW VERIFY THE MNCAD MODULES
129 002062 004537 002700      LOOP:   JSR     R5,TEST ;CHECK THE MNCAD'S
130 002066 003456             ADGO    ;ADDRESS OF INTR. STARTUP
131 002070 001256             ADBASE  ;STARTING A/D ADDRESS
132 002072 000004             4      ;OFFSET TO NEXT UNIT
133 002074 004030             ADPRI   ;A/D MESSAGE POINTER
134 002076 000004             4      ;MAX. # OF A/D'S ON A SYSTEM
135 002100 001270             ADCNT   ;# OF A/D'S FOUND ON SYSTEM
136
137 002102 004537 002700      ;NOW VERIFY THE MNCKW MODULES
138 002106 003474             JSR     R5,TEST     ;CHECK THE MNCKW'S
139 002110 001260             KWGO    ;ADDRESS OF INTR. STARTUP
140 002112 000004             KWBASE  ;STARTING K/W ADDRESS
141 002114 004042             4      ;OFFSET TO NEXT UNIT
142 002116 000010             KWPRI   ;KW MESSAGE POINTER
143 002120 001272             8.     ;MAX. # OF KW ON A SYSTEM
           KWCNT      ;# OF KW FOUND ON SYSTEM

```



```

145      ;NOW VERIFY THE MNCAA MODULES
146 002122 004537 002700      JSR      R5,TEST      ;CHECK THE MNCAA
147 002126 000000              0      ;NO INTR. STARTUP
148 002130 001262              AABASE ;STARTING AA ADDRESS
149 002132 000010              10     ;OFFSET TO NEXT UNIT
150 002134 004054              AAPRI  ;AA MESSAGE POINTER
151 002136 000010              8.     ;MAX. # OF AA ON A SYSTEM
152 002140 001274              AACNT  ;# OF AA FOUND ON SYSTEM
153      ;NOW VERIFY THE MNCDI MODULES
154 002142 004537 002700      JSR      R5,TEST      ;CHECK THE MNCDI
155 002146 003534              DIGO   ;INTR. STARTUP ADDRESS
156 002150 001264              DIBASE ;STARTING DI ADDRESS
157 002152 000010              10     ;OFFSET TO NEXT UNIT
158 002154 004066              DIPRI  ;DI MESSAGE POINTER
159 002156 000010              8.     ;MAX. # OF DI ON A SYSTEM
160 002160 001276              DICNT  ;# OF DI FOUND ON SYSTEM
161      ;NOW VERIFY THE MNCDO MODULES
162 002162 004537 002700      JSR      R5,TEST      ;CHECK THE MNCDO
163 002166 003560              DOGO   ;INTR. STARTUP ADDRESS
164 002170 001266              DOBASE ;STARTING DO ADDRESS
165 002172 000004              4      ;OFFSET TO NEXT UNIT
166 002174 004100              DOPRI ;DO MESSAGE POINTER
167 002176 000010              8.     ;MAX. # OF DO ON A SYSTEM
168 002200 001300              DOCNT  ;# OF DO FOUND ON SYSTEM
169      ;NOW REPORT THE TOTAL COUNT OF EACH MINC-11 MODULE
170
171 002202 104401 001161      TYPE    ,SRLF      ;FRESH LINE
172 002206 104401 004141      TYPE    ,NIPRI     ;TELL THE #
173 002212 104401 004030      TYPE    ,ADPRI     ;A/D
174 002216 013746 001270      MOV     ADCNT,-(SP)
175 002222 104403              TYPOS
176 002224 001 000          .BYTE  1,0
177 002226 104401 004042      TYPE    ,KWPRI     ;KW
178 002232 013746 001272      MOV     KWCNT,-(SP)
179 002236 104403              TYPOS
180 002240 002 000          .BYTE  2,0
181 002242 104401 004054      TYPE    ,AAPRI     ;AA
182 002246 013746 001274      MOV     AACNT,-(SP)
183 002252 104403              TYPOS
184 002254 002 000          .BYTE  2,0
185 002256 104401 004066      TYPE    ,DIPRI     ;DI
186 002262 013746 001276      MOV     DICNT,-(SP)
187 002266 104403              TYPOS
188 002270 002 000          .BYTE  2,0
189 002272 104401 004100      TYPE    ,DOPRI     ;DO
190 002276 013746 001300      MOV     DOCNT,-(SP)
191 002302 104403              TYPOS
192 002304 002 000          .BYTE  2,0
193 002306 000240              NOP
194 002310 000240              NOP
195 002312 000240              NOP
196 002314 000240              NOP

```

```

198          ;DETERMINE IF THE MEMORY USAGE MAP SHOULD BE REPORTED
199 002316 105737 001205      TSTB  $ENVM      ;TEST IF APT
200 002322 001006             BNE   1$          ;BR IF YES
201 002324 005737 000042      TST   @#42       ;TEST IF XXDP
202 002330 001003             BNE   1$          ;BR IF YES
203 002332 005737 001314      TST   FLAGMP     ;TEST IF OPER. ASKED FOR MAP
204 002336 001002             BNE   2$          ;BR IF YES
205 002340 000137 002566      1$:  JMP   $EOP      ;BYPASS REPORT
206 002344 005037 001314      2$:  CLR   FLAGMP     ;ENSURE ONLY THE 1ST PASS IT'S REPORTED
207 002350 104401 004474      TYPE  ,MNCMAP    ;INFORM THE OPER. THE HEADER
208 002354 013746 000004      MOV   ERRVEC,-(SP) ;SAVE CURRENT BUS TRAP VALUE
209 002360 012700 170000      MOV   #170000,R0  ;GET 1ST ADDRESS TO MAP
210 002364 010037 001312      MOV   R0,OUTADR   ;AND SAVE FOR TYPEOUT
211 002370 012701 100000      MOV   #BIT15,R1   ;PRIME THE ROTATING POINTER
212 002374 005002             CLR   R2          ;CLEAR TEMP MASK
213 002376 012703 010114      MOV   #ADRPOK,R3  ;LOAD MAP BLOCK POINTER
214 002402 012737 002546 000004 3$:  MOV   #4$,ERRVEC  ;LOAD ADDRESS TIMEOUT RETURN
215 002410 005710             TST   (R0)        ;TEST THE ADDRESS
216 002412 050102             BIS   R1,R2       ;IF NO TIMEOUT-MARK A 1
217 002414 062700 000002      ADD   #2,R0       ;UPDATE ADDRESS
218 002420 005710             TST   (R0)        ;TEST THE ADDRESS
219 002422 050102             BIS   R1,R2       ;IF NO TIMEOUT-MARK A 1
220 002424 062700 000002      ADD   #2,R0       ;UPDATE ADDRESS
221 002430 000257             CCC                ;ENSURE CLEAR CARRY
222 002432 006001             ROR   R1          ;MOVE RIGHT
223 002434 103365             BCC   3$         ;BR IF MORE BITS LEFT
224 002436 010223             MOV   R2,(R3)+    ;SAVE IN MAP BLOCKS
225 002440 005002             CLR   R2          ;CLEAR MASK
226 002442 012701 100000      MOV   #BIT15,R1   ;LOAD ROTATING BIT
227 002446 022703 010314      CMP   #ADRTOP,R3 ;CHECK IF MAP BLOCKS FILLED
228 002452 001356             BNE   3$         ;BR IF NOT
229          ;NOW REPORT THE MEMORY MAP
230 002454 012700 010114      MOV   #ADRPOK,R0  ;LOAD MEMORY MAP POINTER
231 002460 104401 001161      5$:  TYPE  ,SCLRF    ;REPORT ADDRESS
232 002464 013746 001312      MOV   OUTADR,-(SP)
233 002470 104402             TYPDC
234 002472 104401 004205      TYPE  ,SPACE1
235 002476 004737 002554      JSR   PC,OUTBIN   ;OUTPUT BINARY BITS
236 002502 004737 002554      JSR   PC,OUTBIN
237 002506 004737 002554      JSR   PC,OUTBIN
238 002512 004737 002554      JSR   PC,OUTBIN
239 002516 062737 000400 001312 4$:  ADD   #400,OUTADR ;UPDATE ADDRESS VALUE
240 002524 022700 010314      CMP   #ADRTOP,R0 ;TEST IF FINISHED
241 002530 001353             BNE   5$         ;BR IF NOT
242 002532 012637 000004      MOV   (SP)+,ERRVEC ;RESTORE BUS TRAP VECTOR
243 002536 104401 001161      TYPE  ,SCLRF
244 002542 000137 002566      JMP   $EOP
245          ;RETURN TO HERE UPON MEMORY TIME-OUT
246 002546 062716 000002      4$:  ADD   #2,(SP)  ;ADJUST RETURN ADDRESS
247 002552 000002             RTI
248          ;SUBROUTINE TO REPORT I/O FORMAT MESSAGES
249 002554 012046      OUTBIN: MOV (R0)+,-(SP)
250 002556 104406             TYPBN
251 002560 104401 004205      TYPE  ,SPACE1   ;INSERT A SPACE

```


252 002564 000207 RTS PC

```

254          .SBTTL  END OF PASS ROUTINE
(1)
(2)          ::*****
(1)          ::*INCREMENT THE PASS NUMBER ($PASS)
(1)          ::*TYPE 'END PASS #XXXXX' (WHERE XXXXX IS A DECIMAL NUMBER)
(1)          ::*IF THERES A MONITOR GO TO IT
(1)          ::*IF THERE ISN'T JUMP TO LOOP
(1)
(1)          $EOP:
(2)          002566 000240      NOP
(1)          002570 005237 001172  INC      $PASS      ;;INCREMENT THE PASS NUMBER
(1)          002574 042737 100000 001172  BIC      #100000,$PASS  ;;DON'T ALLOW A NEG. NUMBER
(1)          002602 005327      DEC      (PC)+      ;;LOOP?
(1)          002604 000001      $EOPCT: .WORD 1
(1)          002606 003022      BGT      $DOAGN      ;;YES
(1)          002610 012737      MOV      (PC)+,@(PC)+  ;;RESTORE COUNTER
(1)          002612 000001      $ENDCT: .WORD 1
(1)          002614 002604      $EOPCT
(1)          002616 104401 002663  TYPE      ,SENDMG      ;;TYPE 'END PASS #'
(2)          002622 013746 001172  MOV      $PASS,-(SP)  ;;SAVE $PASS FOR TYPEOUT
(2)          002626 104405      TYPDS      ;;GO TYPE--DECIMAL ASCII WITH SIGN
(1)          002630 104401 002660  TYPE      ,$ENULL      ;;TYPE A NULL CHARACTER
(1)          002634 013700 000042  $GET42: MOV      @#42,R0  ;;GET MONITOR ADDRESS
(1)          002640 001405      BEQ      $DOAGN      ;;BRANCH IF NO MONITOR
(1)          002642 000005      RESET      ;;CLEAR THE WORLD
(1)          002644 004710      $ENDAD: JSR      PC,(R0)  ;;GO TO MONITOR
(1)          002646 000240      NOP      ;;SAVE ROOM
(1)          002650 000240      NOP      ;;FOR
(1)          002652 000240      NOP      ;;ACT11
(1)          002654      $DOAGN:
(1)          002654 000137      JMP      @(PC)+      ;;RETURN
(1)          002656 002062      $RTNAD: .WORD  LOOP
(1)          002660 377 377 000  $ENULL: .BYTE  -1,-1,0  ;;NULL CHARACTER STRING
(1)          002663 015 042412 042116  $ENDMG: .ASCIZ  <15><12>/END PASS #/
(1)          002670 050040 051501 020123
(1)          002676 000043

```



```

256                                     ;SUBROUTINE TO VERIFY THE BASE AND VECTOR ADDRESSES
257
258 002700 012537 003222      TEST:  MOV      (R5)+,67$      ;GET INTR. STARTUP ADDRESS
259 002704 013537 001126      MOV      @(R5)+,$BDDAT    ;GET ADDRESS
260 002710 012537 001302      MOV      (R5)+,VADR      ;GET ADDRESS OFFSET
261 002714 012537 003036      MOV      (R5)+,70$      ;GET NAME POINTER
262 002720 012537 001306      MOV      (R5)+,TEMP      ;GET MAX # OF UNITS
263 002724 013746 000004      MOV      @#ERRVEC,-(SP)  ;SAVE ERRVEC
264 002730 005037 001310      CLR      NBEXT          ;CLEAR COUNTER
265                                     ;ADDRESS THE DEVICE TO VERIFY IT EXISTS
266 002734 012737 003140 000004 1$:  MOV      #2$,ERRVEC      ;SET UP TIME-OUT RETURN
267 002742 005777 176160      TST      @SBDDAT        ;ADDRESS THE UNIT
268                                     ;NOW CAUSE AN INTR. AND FIND THE VECTOR
269 002746 005037 001304 000004 60$: CLR      VECT          ;CLEAR VECTOR FLAG
270 002752 012737 003224      MOV      #IOTRD,ERRVEC  ;SET UP INTELL. TRAP RETURN
271 002760 005737 003222      TST      67$           ;TEST IF NON-INTR DEVICE
272 002764 001414              BEQ      65$           ;BR IF NOT INTR. DEVICE
273 002766 004737 003306      JSR      PC,FIXVCT      ;LOAD VECTOR TRAP
274 002772 004777 000224      JSR      PC,@67$       ;GO PRIME THE DEVICE
275 002776 012700 000000      MOV      #0,R0         ;PRIME A COUNTER
276 003002 005046              CLR      -(SP)         ;LOWER
277 003004 012746 003012      MOV      #66$,-(SP)    ;PS
278 003010 000002              RTI
279 003012 005300 66$:  DEC      R0             ;DELAY
280 003014 001376              BNE      66$           ;SOME TIME
281 003016 005077 176104 65$:  CLR      @SBDDAT        ;LONG ENOUGH DELAY
282                                     ;REPORT THE ADDRESS AND VECTOR VALUES ON FIRST PASS
283 003022 005737 001172      TST      $PASS         ;CHECK IF FIRST
284 003026 001033              BNE      73$           ;BR IF NOT
285 003030 104401 001161      TYPE    ,$CRLF         ;ENSURE FRESH LINE
286 003034 104401              TYPE    ;REPORT THE NAME
287 003036 000000 70$:  0             ;ADDRESS OF MESSAGE POINTER
288 003040 104401 004147      TYPE    ,ATPRI         ;TYPE ADDRESS STARTUP
289 003044 013746 001126      MOV      $BDDAT,-(SP)  ;GET ADDRESS
290 003050 104403              TYPOS   ;REPORT IT
291 003052      006      001      .BYTE    6,1
292 003054 104401 004165      TYPE    ,VTPRI         ;TYPE VECTOR STATUP
293 003060 005737 001304      TST      VECT          ;CHECK IF INTR OCCURRED
294 003064 001003              BNE      71$           ;BR IF YES
295 003066 104401 004112      TYPE    ,NOPRI         ;TELL OPER. NONE
296 003072 000404              BR      72$
297 003074 013746 001304 71$:  MOV      VECT,-(SP)    ;GET VECTOR VALUE
298 003100 104403              TYPOS   ;REPORT IT
299 003102      003      001      .BYTE    3,1
300                                     ;SENSE IF A/D IF SO CHECK OPERATOR INPUT ABOUT CHANNEL MODE REPORT
301 003104 005737 001316 72$:  TST      FLAGAD        ;IS CHANNEL MODE REPORT ENABLED?
302 003110 001402              BEQ      73$           ;BR IF NOT
303 003112 004737 003620      JSR      PC,TCHANL     ;REPORT THE CONFIGURATION

```

```

305                                     ;BUMP THE COUNTER AND TEST IF FINISHED?
306 003116 005237 001310                73$: INC NBEXT ;INCREMENT UNIT COUNTER
307 003122 005337 001306                DEC TEMP ;REACHED MAX?
308 003126 001424                        BEQ 4$ ;:REACHED MAX NO OF UNIT'S
309 003130 063737 001302 001126        ADD VADR,$BDDAT ;GET NEXT UNIT
310 003136 000676                        BR 1$ ;:TRY NEXT UNIT
311                                     ;COME HERE UPON ADDRESS TIME-OUT
312 003140 022626                2$: CMP (SP)+,(SP)+ ;POP 2 WORDS OFF STACK
313 003142 005737 001310                TST NBEXT ;CHECK IF ANY UNITS
314 003146 001014                        BNE 4$ ;BR IF SOME
315 003150 005737 001172                TST $PASS ;TEST IF FIRST PASS
316 003154 001011                        BNE 4$ ;BR IF NOT FIRST
317 003156 013737 003036 003172        MOV 70$,76$ ;GET DEVICE MESSAGE POINTER
318 003164 104401 001161                TYPE , $CRLF
319 003170 104401                        TYPE ;TELL OPER. IT'S NOT THERE
320 003172 000000                76$: 0
321 003174 104401 004112                TYPE ,NOPRI ;TELL OPER. NONE FOUND
322 003200 000240                4$: NOP
323 003202 000240                        NOP
324 003204 013735 001310                MOV NBEXT,@(R5)+ ;SAVE THE # OF UNITS FOUND
325 003210 012637 000004                MOV (SP)+,ERRVEC ;RESTORE ERRVEC
326 003214 005037 001316                CLR FLAGAD ;CLEAR EXPANDED A/D REPORT FLAG
327 003220 000205                        RTS R5
328 003222 003456                67$: ADGO ;ADDRESS TO DEVICE PRIMER
329
330                                     ;INTELLIGENT INTERRUPT HANDLER
331 003224 011637 003304                IOTRD: MOV (SP),TRTO ;GET ADDRESS
332 003230 162737 000004 003304        SUB #4,TRTO ;ADJUST VALUE
333 003236 023727 003304 001000        CMP TRTO,#1000 ;CHECK IF VECTOR OR FATAL TRAP
334 003244 003402                        BLE 2$ ;BR IF VECTOR
335 003246 000000                1$: HALT ;FATAL BUS TRAP IN PROGRAM
336 003250 000776                        BR 1$
337 003252 013737 003304 001304        2$: MOV TRTO,VECT ;LOAD VECTOR
338 003260 005077 175642                CLR @ $BDDAT ;CLEAR CURRENT UNIT STATUS
339 003264 022626                        CMP (SP)+,(SP)+
340 003266 000240                        NOP
341 003270 000240                        NOP
342 003272 000002                        RTI ;EXIT
343 003274 000240                        NOP
344 003276 000240                        NOP
345 003300 000240                        NOP
346 003302 000240                        NOP
347 003304 000000                TRTO: 0

```



```

349      ;SUBROUTINE TO LOAD INTELLIGENT TRAP CATCHER
350 003306 012700 000020  FIXVCT: MOV #20,R0      ;LOAD STARTING ADDRESS
351 003312 012701 000022      MOV #22,R1      ;LOAD STARTING POINTER
352 003316 012702 004700      MOV #4700,R2    ;LOAD 'BAD INSTR'
353 003322 005037 000000      CLR @#0        ;CLEAR LOC. 0
354 003326 005037 000002      CLR @#2        ;CLEAR LOC. 2
355 003332 005037 000010      CLR @#10       ;CLEAR LOC. 10
356 003336 005037 000012      CLR @#12       ;CLEAR LOC. 12
357 003342 022700 000060  1$:  CMP #60,R0      ;TEST IF TKB VECTOR
358 003346 001432          BEQ 3$          ;BR IF YES
359 003350 022700 000100      CMP #100,R0    ;TEST IF LINE INTR. <B EVENT>
360 003354 001425          BEQ 2$          ;BR IF YES
361 003356 022700 000040      CMP #40,R0     ;TEST FOR XXDP FLAG VECTOR
362 003362 001422          BEQ 2$          ;BR IF YES
363 003364 022700 000200      CMP #200,R0   ;TEST IF STARTING ADDRESS
364 003370 001421          BEQ 3$          ;BR IF YES
365 003372 022700 000034      CMP #34,R0    ;TEST IF TRAP VECTOR
366 003376 001414          BEQ 2$          ;BR IF YES
367 003400 000240          NOP
368 003402 000240          NOP
369 003404 000240          NOP
370 003406 000240          NOP
371 003410 000240          NOP
372 003412 010120      MOV R1,(R0)+    ;LOAD POINTER
373 003414 010220      MOV R2,(R0)+    ;LOAD 'BAD'
374 003416 022121      CMP (R1)+,(R1)+ ;BUMP POINTER
375 003420 020027 001000      CMP R0,#1000  ;DONE ?
376 003424 001346          BNE 1$          ;BR IF NOT
377 003426 000207          RTS PC          ;RETURN
378 003430 022020  2$:  CMP (R0)+,(R0)+  ;BUMP
379 003432 022121      CMP (R1)+,(R1)+
380 003434 022020  3$:  CMP (R0)+,(R0)+
381 003436 022121      CMP (R1)+,(R1)+
382 003440 000740          BR 1$
383 003442 000240          NOP
384 003444 000240          NOP
385 003446 000240          NOP
386 003450 000240          NOP
387 003452 000240          NOP
388 003454 000240          NOP

```

```

390
391 003456 012777 000101 175442 ;SUBROUTINE TO PRIME THE MNCAD
ADGO: MOV #101,@$BDDAT ;ENABLE INTR. AND START CONVERSION
392 003464 000240 NOP
393 003466 000240 NOP
394 003470 000240 NOP
395 003472 000207 RTS PC ;EXIT
396 ;SUBROUTINE TO PRIME THE MNCKW
KWGO: MOV $BDDAT,R0 ;GET ADDR.
397 003474 013700 001126 INC R0
398 003500 005200 INC R0 ;MAKE ADDRESS OF CLOCK PRESET BUFFER
399 003502 005200 MOV #-1,(R0) ;LOAD CLOCK PRESET
400 003504 012710 177777 MOV #161,@$BDDAT ;LOAD RATE, INTR ENABLE AND GO
401 003510 012777 000161 175410 BIS #BIT8,@$BDDAT ;LOAD MAINT CLOCK
402 003516 052777 000400 175402 RTS PC ;EXIT
403 003524 000207 NOP
404 003526 000240 NOP
405 003530 000240 NOP
406 003532 000240
407 ;SUBROUTINE TO PRIME THE MNCDI
DIGO: MOV #102,@$BDDAT ;LOAD INTR. ENABLE AND MODE
408 003534 012777 000102 175364 BIS #4200,@$BDDAT ;LOAD MAINT. STROBE
409 003542 052777 004200 175356 RTS PC ;EXIT
410 003550 000207 NOP
411 003552 000240 NOP
412 003554 000240 NOP
413 003556 000240
414 ;SUBROUTINE TO PRIME THE MNCDO
DOGO: MOV $BDDAT,R0 ;GET ADDRESS
415 003560 013700 001126 ADD #3,R0 ;MAKE OUTPUT DATA POINTER
416 003564 062700 000003 CLRB (R0) ;ENABLE MAINT. STROBE
417 003570 105010 SUB #2,R0 ;MAKE HIGH BYTE STATUS ADDRESS
418 003572 162700 000002 MOVB #BIT0,(R0) ;MAINT. STROBE
419 003576 112710 000001 BIS #BIT6,@$BDDAT ;ENABLE INTR.
420 003602 052777 000100 175316 RTS PC ;EXIT
421 003610 000207 NOP
422 003612 000240 NOP
423 003614 000240 NOP
424 003616 000240 NOP

```



```

426 ;SUB-ROUTINE TO TYPE OUT A/D CONFIGURATION
427
428 003620 104401 001161 TCHANL: TYPE , $CRLF
429 003624 000240 NOP
430 003626 000240 NOP
431 003630 000240 NOP
432 003632 013702 001126 MOV $BDDAT,R2
433 003636 062702 000002 ADD #2,R2 ;MAKE CONVERTED VALUE ADDRESS
434 003642 011201 MOV (R2),R1 ;ENSURE A/D FLAG IS CLEARED
435 003644 005001 CLR R1
436 003646 000240 NOP
437 003650 005277 175252 2$: INC @ $BDDAT ;START A CONVERSION
438 003654 105777 175246 3$: TSTB @ $BDDAT ;WAIT FOR CONVERSION TO FINISH
439 003660 100375 BPL 3$
440 003662 011200 MOV (R2),R0 ;GET RESULTS
441 003664 104401 004202 TYPE ,SSPACE ;MOVE IT OVER SOME
442 003670 010146 MOV R1,-(SP) ;SAVE R1 FOR TYPEOUT
(1) 003672 104403 TYPOS ;GO TYPE--OCTAL ASCII
(1) 003674 002 .BYTE 2 ;TYPE 2 DIGIT(S)
(1) 003675 000 .BYTE 0 ;SUPPRESS LEADING ZEROS
443 003676 104401 004207 TYPE ,MDASH ;TYPE A DASH
444 003702 062701 000003 ADD #3,R1 ;ADD 3 TO CHANNEL FOR DIFFERENTIAL
445 003706 042700 007777 BIC #7777,R0 ;IS CHANNEL SINGLE ENDED
446 003712 001002 BNE 5$ ;CHANNEL IS NOT SINGLE ENDED
447 003714 062701 000004 ADD #4,R1 ;ADD 4 CHANNELS FOR SINGLE ENDED
448 003720 022701 000100 5$: CMP #100,R1 ;IS CHANNEL > LAST POSSIBLE CHANNEL
449 003724 101002 BHI 6$ ;:NO
450 003726 012701 000077 MOV #77,R1 ;YES, SET TO LAST CHANNEL
451 003732 6$: MOV R1,-(SP) ;:SAVE R1 FOR TYPEOUT
(1) 003732 010146 TYPOS ;:GO TYPE--OCTAL ASCII
(1) 003734 104403 .BYTE 2 ;:TYPE 2 DIGIT(S)
(1) 003736 002 .BYTE 0 ;:SUPPRESS LEADING ZEROS
(1) 003737 000 .BYTE 0 ;:IS CHANNEL SINGLE ENDED?
452 003740 005700 TST R0 ;:NO
453 003742 001003 BNE 7$ ;:TYPE SINGLE ENDED MESSAGE
454 003744 104401 004213 TYPE ,MSE ;:GO TEST MORE CHANNELS
455 003750 000410 BR 9$ ;:IS CHANNEL DIFFERENTIAL?
456 003752 022700 020000 7$: CMP #BIT13,R0 ;:NO, MUST HAVE PREAMP
457 003756 001003 BNE 8$ ;:TYPE DIFFERENTIAL MESSAGE
458 003760 104401 004232 TYPE ,MDIF ;:GO TEST MORE CHANNELS
459 003764 000402 BR 9$ ;:TYPE PREAMP MESSAGE
460 003766 104401 004251 8$: TYPE ,MPRMP ;:SET CHANNEL TO NEXT SET OF CHANNELS
461 003772 005201 9$: INC R1 ;:DONE?
462 003774 022701 000100 CMP #100,R1 ;:YES
463 004000 001412 BEQ 10$ ;:GET CHANNEL
464 004002 010100 MOV R1,R0 ;:PUT CHANNEL NUMBER IN HIGH BYTE
465 004004 000300 SWAB R0 ;:SET STATUS ENABLE BIT
466 004006 052700 000010 BIS #BIT3,R0 ;:LOAD INTO A/D STATUS REGISTER
467 004012 010077 175110 MOV R0,@ $BDDAT ;:IS NON-EXISTENT CHANNEL BIT SET?
468 004016 032777 000002 175102 BIT #BIT1,@ $BDDAT ;:NO
469 004024 001711 BEQ 2$
470 004026 000207 10$: RTS PC

```

```

472                                     ;ASCII MESSAGES
473 004030 020040 046473 041516 ADPRI: .ASCIZ / ;MNCAD /
      004036 042101 000040
474 004042 020040 046473 041516 KWPRI: .ASCIZ / ;MNCKW /
      004050 053513 000040
475 004054 020040 046473 041516 AAPRI: .ASCIZ / ;MNCAA /
      004062 040501 000040
476 004066 020040 046473 041516 DIPRI: .ASCIZ / ;MNCDI /
      004074 044504 000040
477 004100 020040 046473 041516 DOPRI: .ASCIZ / ;MNCDO /
      004106 047504 000040
478 004112 025040 020052 042040 NOPRI: .ASCIZ / ** DOES NOT EXIST **/
      004120 042517 020123 047516
      004126 020124 054105 051511
      004134 020124 025052 000
479 004141 043 047440 020106 NIPRI: .ASCIZ /# OF /
      004146 000
480 004147 101 020124 042101 ATPRI: .ASCIZ /AT ADDRESS = /
      004154 051104 051505 020123
      004162 020075 000
481 004165 040 020040 042526 VTPRI: .ASCIZ / VECTOR = /
      004172 052103 051117 036440
      004200 000040
482 004202 004411 000 SSPACE: .ASCIZ / /
483 004205 040 000 SPACE1: .ASCIZ / /
484 004207 040 020055 000 MDASH: .ASCIZ / - /
485 004213 040 044523 043516 MSE: .ASCIZ / SINGLE ENDED/<200>
      004220 042514 042440 042116
      004226 042105 000200
486 004232 042040 043111 042506 MDIF: .ASCIZ / DIFFERENTIAL/<200>
      004240 042522 052116 040511
      004246 100114 000
487 004251 040 051120 040505 MPRMP: .ASCIZ / PREAMP/<200>
      004256 050115 000200
488 004262 042200 020117 047531 QUESAD: .ASCII <200>\DO YOU WANT THE MNCAD (A/D) CHANNEL MODE REPORT ?\
      004270 020125 040527 052116
      004276 052040 042510 046440
      004304 041516 042101 024040
      004312 027501 024504 041440
      004320 040510 047116 046105
      004326 046440 042117 020105
      004334 042522 047520 052122
      004342 037440
489 004344 004600 052011 050131 .ASCIZ <200>\ TYPE 'Y' FOR YES = \
      004352 020105 054442 020042
      004360 047506 020122 042531
      004366 020123 020075 000
490 004373 200 047504 054440 QUESMP: .ASCII <200>\DO YOU WANT THE MEMORY USAGE MAP REPORT ?\
      004400 052517 053440 047101
      004406 020124 044124 020105
      004414 042515 047515 054522
      004422 052440 040523 042507
      004430 046440 050101 051040
      004436 050105 051117 020124

```


491	004444	077		
	004445	200	004411	054524
	004452	042520	021040	021131
	004460	043040	051117	054440
	004466	051505	036440	000040
492	004474	046600	047111	026503
	004502	030461	046440	046505
	004510	051117	020131	051525
	004516	043501	020105	040515
	004524	004520	042450	041501
	004532	020110	044502	020124
	004540	020075	020062	042101
	004546	051104	051505	042523
	004554	024523	200	
493	004557	040	042101	051104
	004564	020011	020040	030040
	004572	030060	032057	030060
	004600	020040	020040	020040
	004606	020040	020040	030061
	004614	027460	030065	060
494	004621	040	020040	020040
	004626	020040	020040	031040
	004634	030060	033057	030060
	004642	020040	020040	020040
	004650	020040	020040	030063
	004656	027460	030067	000060
495	004664	015	012	012
496	004667	117	042520	040522
	004674	047524	004522	004455
	004702	046120	040505	042523
	004710	042040	020117	044124
	004716	020105	047506	046114
	004724	053517	047111	035107
497	004732	015	012	012
498	004735	122	046505	053117
	004742	020105	044124	020105
	004750	052503	052123	046517
	004756	051105	041440	047117
	004764	042516	052103	047511
	004772	051516	043040	047522
	005000	020115	040505	044103
	005006	021040	044515	041516
	005014	030455	021061	047440
	005022	052120	047511	116
499	005027	015	012	
500	005031	115	041516	042101
	005036	024040	027501	024504
	005044	004411	042523	020124
	005052	051106	047117	020124
	005060	040520	042516	020114
	005066	053523	052111	044103
	005074	051505	052040	020117
	005102	044124	020105	052042
	005110	051505	021124	050040

.ASCIZ <200>\ TYPE 'Y' FOR YES = \

MNCMAP: .ASCII <200>\MINC-11 MEMORY USAGE MAP (EACH BIT = 2 ADDRESSES)\<200>

.ASCII \ ADDR 000/400 100/500\

.ASCIZ \ 200/600 300/700\

SETMNC: .BYTE 15,12,12
.ASCII /OPERATOR - PLEASE DO THE FOLLOWING: /

.BYTE 15,12,12
.ASCII /REMOVE THE CUSTOMER CONNECTIONS FROM EACH 'MINC-11' OPTION/

.BYTE 15,12
.ASCII \MNCAD (A/D) SET FRONT PANEL SWITCHES TO THE 'TEST' POSITION\

	005116	051517	052111	047511		
	005124	116				
501	005125	015	012		.BYTE 15,12	
502	005127	115	041516	053513	.ASCII \MNCKW (CLOCK)	PULL OUT 'ST1' AND 'ST2' SWITCHES\
	005134	024040	046103	041517		
	005142	024513	004411	052520		
	005150	046114	047440	052125		
	005156	021040	052123	021061		
	005164	040440	042116	021040		
	005172	052123	021062	051440		
	005200	044527	041524	042510		
	005206	123				
503	005207	015	012		.BYTE 15,12	
504	005211	011	004411	047101	.ASCII \	AND ROTATE FULLY CLOCKWISE\
	005216	020104	047522	040524		
	005224	042524	043040	046125		
	005232	054514	041440	047514		
	005240	045503	044527	042523		
505	005246	015	012		.BYTE 15,12	
506	005250	047115	042103	020111	.ASCII \MNCDI (DIGITAL IN)	SET 'DATA' SWITCH TO THE '-' POSITION\
	005256	042050	043511	052111		
	005264	046101	044440	024516		
	005272	051411	052105	021040		
	005300	040504	040524	020042		
	005306	053523	052111	044103		
	005314	052040	020117	044124		
	005322	020105	026442	020042		
	005330	047520	044523	044524		
	005336	047117				
507	005340	015	012		.BYTE 15,12	
508	005342	046123	020125	004460	.ASCII \SLU 0	INSTALL 'SLU TEST CONNECTOR'\
	005350	004411	047111	052123		
	005356	046101	020114	051442		
	005364	052514	052040	051505		
	005372	020124	047503	047116		
	005400	041505	047524	021122		
509	005406	015	012		.BYTE 15,12	
510	005410	046123	020125	004461	.ASCII \SLU 1	INSTALL 'SLU TEST CONNECTOR'\
	005416	004411	047111	052123		
	005424	046101	020114	051442		
	005432	052514	052040	051505		
	005440	020124	047503	047116		
	005446	041505	047524	021122		
511	005454	015	012		.BYTE 15,12	
512	005456	046123	020125	004462	.ASCII \SLU 2	INSTALL 'SLU TEST CONNECTOR'\
	005464	004411	047111	052123		
	005472	046101	020114	051442		
	005500	052514	052040	051505		
	005506	020124	047503	047116		
	005514	041505	047524	021122		
513	005522	015	012	012	.BYTE 15,12,12	
514	005525	104	050105	042522	.ASCIIZ \DEPRESS A KEY ON THE CONSOLE TERMINAL WHEN READY. \	
	005532	051523	040440	045440		
	005540	054505	047440	020116		

005546	044124	020105	047503
005554	051516	046117	020105
005562	042524	046522	047111
005570	046101	053440	042510
005576	020116	042522	042101
005604	027131	000040	

515
516
517

.EVEN

```

519      .SBTTL  TTY INPUT ROUTINE
(1)
(2)      ::*****
(1)      .ENABL  LSB
(1) 005610 000000 $TKCNT: .WORD 0      ;;NUMBER OF ITEMS IN QUEUE
(1) 005612 000000 $TKQIN: .WORD 0      ;;INPUT POINTER
(1) 005614 000000 $TKQOUT: .WORD 0     ;;OUTPUT POINTER
(1) 005616 000040 $TKQSRT: .BLKB 32.   ;;TTY KEYBOARD QUEUE
(1)      $TKQEND=.
(1)
(1)      ;*TK INITIALIZE ROUTINE
(1)      ;*THIS ROUTINE WILL INITIALIZE THE TTY KEYBOARD INPUT QUEUE
(1)      ;*SETUP THE INTERRUPT VECTOR AND TURN ON THE KEYBOARD INTERRUPT
(1)
(1)      ;*CALL:
(1)      ;*      JSR      PC,$TKINT
(1)      ;*      RETURN
(1)
(1) 005656 005037 005610 $TKINT: CLR $TKCNT      ;;CLEAR COUNT OF ITEMS IN QUEUE
(1) 005662 012737 005616 005612 MOV # $TKQSRT,$TKQIN ;;MOVE THE STARTING ADDRESS OF THE
(1) 005670 013737 005612 005614 MOV $TKQIN,$TKQOUT   ;;QUEUE INTO THE INPUT & OUTPUT POINTERS.
(1) 005676 012737 005726 000060 MOV # $TKSRV,@ $TKVEC ;;INITIALIZE THE KEYBOARD VECTOR
(1) 005704 012737 000200 000062 MOV #200,@ $TKVEC+2  ;;'BR' LEVEL 4
(1) 005712 005777 173230 TST @ $TKB      ;;CLEAR DONE FLAG
(1) 005716 012777 000100 173220 MOV #100,@ $TKS      ;;ENABLE TTY KEYBOARD INTERRUPT
(1) 005724 000207 RTS PC      ;;RETURN TO CALLER
(1)
(1)      ;*TK SERVICE ROUTINE
(1)      ;*THIS ROUTINE WILL SERVICE THE TTY KEYBOARD INTERRUPT
(1)      ;*BY READING THE CHARACTER FROM THE INPUT BUFFER AND PUTTING
(1)      ;*IT IN THE QUEUE.
(1)      ;*IF THE CHARACTER IS A "CONTROL-C" (^C) $TKINT IS CALLED AND
(1)      ;*UPON RETURN EXIT IS MADE TO THE "CONTROL-C" RESTART ADDRESS (BEGIN)
(1)
(1) 005726 117746 173214 $TKSRV: MOVB @ $TKB,-(SP) ;;PICKUP THE CHARACTER
(1) 005732 042716 177600 BIC #^C177,(SP) ;;STRIP THE JUNK
(1) 005736 021627 000003 CMP (SP),#3 ;;IS IT A CONTROL C?
(1) 005742 001007 BNE 1$ ;;BRANCH IF NO
(1) 005744 104401 006516 TYPE , $CNTLC ;;TYPE A CONTROL-C (^C)
(1) 005750 004737 005656 JSR PC,$TKINT ;;INIT THE KEYBOARD
(1) 005754 005726 TST (SP)+ ;;CLEAN UP STACK
(1) 005756 000137 001324 JMP BEGIN ;;CONTROL C RESTART
(1)
(1) 005762 1$:
(1) 005762 022737 000040 005610 CMP #32.,$TKCNT ;;IS THE QUEUE FULL?
(1) 005770 001004 BNE 3$ ;;BRANCH IF NO
(1) 005772 104401 006512 TYPE , $BELL ;;RING THE TTY BELL
(1) 005776 005726 TST (SP)+ ;;CLEAN CHARACTER OFF OF STACK
(1) 006000 000451 BR 5$ ;;EXIT
(1) 006002 021627 000023 3$: CMP (SP),#23 ;;IS IT A CONTROL-S?
(1) 006006 001021 BNE 32$ ;;BRANCH IF NO
(1) 006010 005077 173130 CLR @ $TKS ;;DISABLE TTY KEYBOARD INTERRUPTS
(1) 006014 005726 TST (SP)+ ;;CLEAN CHAR OFF STACK
(1) 006016 105777 173122 31$: TSTB @ $TKS ;;WAIT FOR A CHAR

```



```

(1) 006022 100375          BPL      31$          ;;LOOP UNTIL ITS THERE
(1) 006024 117746 173116  MOVB     @STKB, -(SP)  ;;GET THE CHARACTER
(1) 006030 042716 177600  BIC     #'C177, (SP)  ;;MAKE IT 7-BIT ASCII
(1) 006034 022627 000021  CMP     (SP)+, #21    ;;IS IT A CONTROL-Q?
(1) 006040 001366          BNE     31$          ;;BRANCH IF NO
(1) 006042 012777 000100 173074  MOV     #100, @STKS   ;;REENABLE TTY KEYBOARD INTERRUPTS
(1) 006050 000002          RTI                    ;;RETURN
(1) 006052 005237 005610 32$:    INC     $TKCNT       ;;COUNT THIS CHARACTER
(1) 006056 021627 000140  CMP     (SP), #140   ;;IS IT UPPER CASE?
(1) 006062 002405          BLT     4$           ;;BRANCH IF YES
(1) 006064 021627 000175  CMP     (SP), #175   ;;IS IT A SPECIAL CHAR?
(1) 006070 003002          BGT     4$           ;;BRANCH IF YES
(1) 006072 042716 000040  BIC     #40, (SP)    ;;MAKE IT UPPER CASE
(1) 006076 112677 177510 4$:    MOVB     (SP)+, @STKQIN  ;;AND PUT IT IN QUEUE
(1) 006102 005237 005612  INC     $TKQIN       ;;UPDATE THE POINTER
(1) 006106 023727 005612 005656  CMP     $TKQIN, #STKQEND  ;;GO OFF THE END?
(1) 006114 001003          BNE     5$           ;;BRANCH IF NO
(1) 006116 012737 005616 005612  MOV     #STKQSRT, $TKQIN  ;;RESET THE POINTER
(1) 006124 000002          5$:    RTI                    ;;RETURN

```

(1) .DSABL LSB

(1) *****
(1) *THIS ROUTINE WILL INPUT A SINGLE CHARACTER FROM THE TTY

```

(1) *CALL:
(1) * RDCHR          ;;GET A CHARACTER FROM THE QUEUE
(1) * RETURN HERE   ;;CHARACTER IS ON THE STACK
(1) *              ;;WITH PARITY BIT STRIPPED OFF
(1) *
(1) *

```

```

(1) 006126 011646          $RDCHR: MOV     (SP), -(SP)  ;;PUSH DOWN THE PC AND
(1) 006130 016666 000004 000002  MOV     4(SP), 2(SP)  ;;THE PS
(1) 006136 005066 000004  CLR     4(SP)         ;;GET READY FOR A CHARACTER
(2) 006142 005046          CLR     -(SP)        ;;PUT NEW PS ON STACK
(2) 006144 012746 006152  MOV     #64$, -(SP)   ;;PUT NEW PC ON STACK
(2) 006150 000002          RTI                    ;;POP NEW PC AND PS

```

```

(2) 006152          64$:
(1) 006152 005737 005610 1$:    TST     $TKCNT       ;;WAIT ON A CHARACTER
(1) 006156 001775          BEQ     1$           ;;
(1) 006160 005337 005610  DEC     $TKCNT       ;;DECREMENT THE COUNTER
(1) 006164 117766 177424 000004  MOVB     @STKQOUT, 4(SP)  ;;GET ONE CHARACTER
(1) 006172 005237 005614  INC     $TKQOUT      ;;UPDATE THE POINTER
(1) 006176 023727 005614 005656  CMP     $TKQOUT, #STKQEND  ;;DID IT GO OFF OF THE END?
(1) 006204 001003          BNE     2$           ;;BRANCH IF NO
(1) 006206 012737 005616 005614  MOV     #STKQSRT, $TKQOUT  ;;RESET THE POINTER
(1) 006214 000002          2$:    RTI                    ;;RETURN

```

(2) *****
(1) *THIS ROUTINE WILL INPUT A STRING FROM THE TTY
(1) *CALL:
(1) * RDLIN ;;INPUT A STRING FROM THE TTY
(1) * RETURN HERE ;;ADDRESS OF FIRST CHARACTER WILL BE ON THE STACK
(1) * ;;TERMINATOR WILL BE A BYTE OF ALL 0'S
(1) *

(1)	006216	010346			\$RDLIN:	MOV	R3,-(SP)	::SAVE R3
(1)	006220	005046				CLR	-(SP)	::CLEAR THE RUBOUT KEY
(1)	006222	012703	006452		1\$:	MOV	#\$TTYIN,R3	::GET ADDRESS
(1)	006226	022703	006512		2\$:	CMP	#\$TTYIN+32.,R3	::BUFFER FULL?
(1)	006232	101456				BLOS	4\$::BR IF YES
(1)	006234	104407				RDCHR		::GO READ ONE CHARACTER FROM THE TTY
(1)	006236	112613				MOVB	(SP)+,(R3)	::GET CHARACTER
(1)	006240	122713	000177		10\$:	CMPB	#177,(R3)	::IS IT A RUBOUT
(1)	006244	001022				BNE	5\$::BR IF NO
(1)	006246	005716				TST	(SP)	::IS THIS THE FIRST RUBOUT?
(1)	006250	001007				BNE	6\$::BR IF NO
(1)	006252	112737	000134	006450		MOVB	#'\,9\$::TYPE A BACK SLASH
(1)	006260	104401	006450			TYPE	,9\$	
(1)	006264	012716	177777			MOV	#-1,(SP)	::SET THE RUBOUT KEY
(1)	006270	005303			6\$:	DEC	R3	::BACKUP BY ONE
(1)	006272	020327	006452			CMP	R3,#\$TTYIN	::STACK EMPTY?
(1)	006276	103434				BLO	4\$::BR IF YES
(1)	006300	111337	006450			MOVB	(R3),9\$::SETUP TO TYPEOUT THE DELETED CHAR.
(1)	006304	104401	006450			TYPE	,9\$::GO TYPE
(1)	006310	000746				BR	2\$::GO READ ANOTHER CHAR.
(1)	006312	005716			5\$:	TST	(SP)	::RUBOUT KEY SET?
(1)	006314	001406				BEQ	7\$::BR IF NO
(1)	006316	112737	000134	006450		MOVB	#'\,9\$::TYPE A BACK SLASH
(1)	006324	104401	006450			TYPE	,9\$	
(1)	006330	005016				CLR	(SP)	::CLEAR THE RUBOUT KEY
(1)	006332	122713	000025		7\$:	CMPB	#25,(R3)	::IS CHARACTER A CTRL U?
(1)	006336	001003				BNE	8\$::BR IF NO
(1)	006340	104401	006523			TYPE	,\$CNTLU	::TYPE A CONTROL 'U'
(1)	006344	000726				BR	1\$::GO START OVER
(1)	006346	122713	000022		8\$:	CMPB	#22,(R3)	::IS CHARACTER A '^R'?
(1)	006352	001011				BNE	3\$::BRANCH IF NO
(1)	006354	105013				CLRB	(R3)	::CLEAR THE CHARACTER
(1)	006356	104401	001161			TYPE	,\$CRLF	::TYPE A 'CR' & 'LF'
(1)	006362	104401	006452			TYPE	,\$TTYIN	::TYPE THE INPUT STRING
(1)	006366	000717				BR	2\$::GO PICKUP ANOTHER CHARACTER
(1)	006370	104401	001160		4\$:	TYPE	,\$QUES	::TYPE A '?'
(1)	006374	000712				BR	1\$::CLEAR THE BUFFER AND LOOP
(1)	006376	111337	006450		3\$:	MOVB	(R3),9\$::ECHO THE CHARACTER
(1)	006402	104401	006450			TYPE	,9\$	
(1)	006406	122723	000015			CMPB	#15,(R3)+	::CHECK FOR RETURN
(1)	006412	001305				BNE	2\$::LOOP IF NOT RETURN
(1)	006414	105063	177777			CLRB	-1(R3)	::CLEAR RETURN (THE 15)
(1)	006420	104401	001162			TYPE	,\$LF	::TYPE A LINE FEED
(1)	006424	005726				TST	(SP)+	::CLEAN RUBOUT KEY FROM THE STACK
(1)	006426	012603				MOV	(SP)+,R3	::RESTORE R3
(1)	006430	011646				MOV	(SP),-(SP)	::ADJUST THE STACK AND PUT ADDRESS OF THE
(1)	006432	016666	000004	000002		MOV	4(SP),2(SP)	::FIRST ASCII CHARACTER ON IT
(1)	006440	012766	006452	000004		MOV	#\$TTYIN,4(SP)	
(1)	006446	000002				RTI		::RETURN
(1)	006450	000			9\$:	.BYTE	0	::STORAGE FOR ASCII CHAR. TO TYPE
(1)	006451	000				.BYTE	0	::TERMINATOR
(1)	006452	000040			\$TTYIN:	.BLKB	32.	::RESERVE 32. BYTES FOR TTY INPUT
(1)	006512	177607	000377		\$BELL:	.ASCIZ	<207><377><377>	::CODE FOR BELL
(1)	006516	041536	005015	000	\$CNTLC:	.ASCIZ	/^C/<15><12>	::CONTROL 'C'


```

(1) 006523 136 006525 000012 $CNTLU: .ASCIZ / ^U/<15><12> ::CONTROL 'U'
(1) 006530 043536 005015 000 $CNTLG: .ASCIZ / ^G/<15><12> ::CONTROL 'G'
(1) 006535 015 051412 051127 $MSWR: .ASCIZ <15><12>/SWR = /
(1) 006542 036440 000040
(1) 006546 020040 042516 020127 $MNEW: .ASCIZ / NEW = /
(1) 006554 020075 000
(1) 006560 .EVEN
520 .SBTTL TYPE ROUTINE
(1)
(2) ::*****
(1) *ROUTINE TO TYPE ASCIZ MESSAGE. MESSAGE MUST TERMINATE WITH A 0 BYTE.
(1) *THE ROUTINE WILL INSERT A NUMBER OF NULL CHARACTERS AFTER A LINE FEED.
(1) *NOTE1: $NULL CONTAINS THE CHARACTER TO BE USED AS THE FILLER CHARACTER.
(1) *NOTE2: $FILLS CONTAINS THE NUMBER OF FILLER CHARACTERS REQUIRED.
(1) *NOTE3: $FILLC CONTAINS THE CHARACTER TO FILL AFTER.
(1) *
(1) *CALL:
(1) *1) USING A TRAP INSTRUCTION
(1) * TYPE ,MESADR ::MESADR IS FIRST ADDRESS OF AN ASCIZ STRING
(1) *OR
(1) * TYPE
(1) * MESADR
(1) *
(1) 006560 105737 001157 $TYPE: TSTB $TPFLG ::IS THERE A TERMINAL?
(1) 006564 100002 BPL 1$ ::BR IF YES
(1) 006566 000000 HALT ::HALT HERE IF NO TERMINAL
(1) 006570 000430 BR 3$ ::LEAVE
(1) 006572 010046 1$: MOV R0,-(SP) ::SAVE R0
(1) 006574 017600 000002 MOV @2(SP),R0 ::GET ADDRESS OF ASCIZ STRING
(1) 006600 122737 000001 001204 CMPB #APTENV,$ENV ::RUNNING IN APT MODE
(1) 006606 001011 BNE 62$ ::NO,GO CHECK FOR APT CONSOLE
(1) 006610 132737 000100 001205 BITB #APTPOOL,$ENVM ::SPOOL MESSAGE TO APT
(1) 006616 001405 BEQ 62$ ::NO,GO CHECK FOR CONSOLE
(1) 006620 010037 006630 MOV R0,61$ ::SETUP MESSAGE ADDRESS FOR APT
(1) 006624 004737 007576 JSR PC,$ATY3 ::SPOOL MESSAGE TO APT
(1) 006630 000000 61$: .WORD 0 ::MESSAGE ADDRESS
(1) 006632 132737 000040 001205 62$: BITB #APTCSUP,$ENVM ::APT CONSOLE SUPPRESSED
(1) 006640 001003 BNE 60$ ::YES,SKIP TYPE OUT
(1) 006642 112046 2$: MOVB (R0)+,-(SP) ::PUSH CHARACTER TO BE TYPED ONTO STACK
(1) 006644 001005 BNE 4$ ::BR IF IT ISN'T THE TERMINATOR
(1) 006646 005726 TST (SP)+ ::IF TERMINATOR POP IT OFF THE STACK
(1) 006650 012600 60$: MOV (SP)+,R0 ::RESTORE R0
(1) 006652 062716 000002 3$: ADD #2,(SP) ::ADJUST RETURN PC
(1) 006656 000002 RTI ::RETURN
(1) 006660 122716 000011 4$: CMPB #HT,(SP) ::BRANCH IF <HT>
(1) 006664 001430 BEQ 8$
(1) 006666 122716 000200 CMPB #CRLF,(SP) ::BRANCH IF NOT <CRLF>
(1) 006672 001006 BNE 5$
(1) 006674 005726 TST (SP)+ ::POP <CR><LF> EQUIV
(1) 006676 104401 TYPE ::TYPE A CR AND LF
(1) 006700 001161 $CRLF
(1) 006702 105037 007036 CLRB $CHARCNT ::CLEAR CHARACTER COUNT
(1) 006706 000755 BR 2$ ::GET NEXT CHARACTER

```

```

(1) 006710 004737 006772      5$:   JSR   PC,$TYPEC      ;;GO TYPE THIS CHARACTER
(1) 006714 123726 001156      6$:   CMPB  $FILLC,(SP)+   ;;IS IT TIME FOR FILLER CHARS.?
(1) 006720 001350                BNE   2$                ;;IF NO GO GET NEXT CHAR.
(1) 006722 013746 001154      MOV   $NULL,-(SP)      ;;GET # OF FILLER CHARS. NEEDED
(1)                                ;;AND THE NULL CHAR.
(1) 006726 105366 000001      7$:   DECB  1(SP)        ;;DOES A NULL NEED TO BE TYPED?
(1) 006732 002770                BLT   6$                ;;BR IF NO--GO POP THE NULL OFF OF STACK
(1) 006734 004737 006772      JSR   PC,$TYPEC      ;;GO TYPE A NULL
(1) 006740 105337 007036      DECB  $CHARCNT       ;;DO NOT COUNT AS A COUNT
(1) 006744 000770                BR    7$                ;;LOOP

                                ;HORIZONTAL TAB PROCESSOR

(1) 006746 112716 000040      8$:   MOVB  #' ,(SP)    ;;REPLACE TAB WITH SPACE
(1) 006752 004737 006772      9$:   JSR   PC,$TYPEC   ;;TYPE A SPACE
(1) 006756 132737 000007 007036 BITB  #7,$CHARCNT     ;;BRANCH IF NOT AT
(1) 006764 001372                BNE   9$                ;;TAB STOP
(1) 006766 005726                TST   (SP)+            ;;POP SPACE OFF STACK
(1) 006770 000724                BR    2$                ;;GET NEXT CHARACTER
(1) 006772 105777 172152      $TYPEC: TSTB @ $TPS    ;;WAIT UNTIL PRINTER IS READY
(1) 006776 100375                BPL   $TYPEC
(1) 007000 116677 000002 172144 MOVB  2(SP),@$TPB     ;;LOAD CHAR TO BE TYPED INTO DATA REG.
(1) 007006 122766 000015 000002 CMPB  #CR,2(SP)      ;;IS CHARACTER A CARRIAGE RETURN?
(1) 007014 001003                BNE   1$                ;;BRANCH IF NO
(1) 007016 105037 007036      CLRB  $CHARCNT       ;;YES--CLEAR CHARACTER COUNT
(1) 007022 000406                BR    $TYPEX           ;;EXIT
(1) 007024 122766 000012 000002 1$:   CMPB  #LF,2(SP)     ;;IS CHARACTER A LINE FEED?
(1) 007032 001402                BEQ   $TYPEX           ;;BRANCH IF YES
(1) 007034 105227                INCB  (PC)+            ;;COUNT THE CHARACTER
(1) 007036 000000      $CHARCNT: .WORD 0    ;;CHARACTER COUNT STORAGE
(1) 007040 000207      $TYPEX: RTS   PC
  
```



```

522      .SBTTL BINARY TO OCTAL (ASCII) AND TYPE
(1)
(2)      ::*****
(1)      ::THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 6-DIGIT
(1)      ::OCTAL (ASCII) NUMBER AND TYPE IT.
(1)      ::$TYPOS---ENTER HERE TO SETUP SUPPRESS ZEROS AND NUMBER OF DIGITS TO TYPE
(1)      ::CALL:
(1)      ::      MOV      NUM,-(SP)      ::NUMBER TO BE TYPED
(1)      ::      TYPOS      ::CALL FOR TYPEOUT
(1)      ::      .BYTE  N      ::N=1 TO 6 FOR NUMBER OF DIGITS TO TYPE
(1)      ::      .BYTE  M      ::M=1 OR 0
(1)      ::      ::1=TYPE LEADING ZEROS
(1)      ::      ::0=SUPPRESS LEADING ZEROS
(1)      ::$TYPON---ENTER HERE TO TYPE OUT WITH THE SAME PARAMETERS AS THE LAST
(1)      ::$TYPOS OR $TYPOC
(1)      ::CALL:
(1)      ::      MOV      NUM,-(SP)      ::NUMBER TO BE TYPED
(1)      ::      TYPON      ::CALL FOR TYPEOUT
(1)      ::$TYPOC---ENTER HERE FOR TYPEOUT OF A 16 BIT NUMBER
(1)      ::CALL:
(1)      ::      MOV      NUM,-(SP)      ::NUMBER TO BE TYPED
(1)      ::      TYPOC      ::CALL FOR TYPEOUT
(1) 007042 017646 000000      $TYPOS: MOV      @ (SP),-(SP)      ::PICKUP THE MODE
(1) 007046 116637 000001 007265      MOVVB  1(SP), $OFILL      ::LOAD ZERO FILL SWITCH
(1) 007054 112637 007267      MOVVB  (SP)+, $OMODE+1    ::NUMBER OF DIGITS TO TYPE
(1) 007060 062716 000002      ADD      #2, (SP)      ::ADJUST RETURN ADDRESS
(1) 007064 000406      BR      $TYPON
(1) 007066 112737 000001 007265      $TYPOC: MOVVB  #1, $OFILL      ::SET THE ZERO FILL SWITCH
(1) 007074 112737 000006 007267      MOVVB  #6, $OMODE+1      ::SET FOR SIX(6) DIGITS
(1) 007102 112737 000005 007264      $TYPON: MOVVB  #5, $OCNT      ::SET THE ITERATION COUNT
(1) 007110 010346      MOV      R3, -(SP)      ::SAVE R3
(1) 007112 010446      MOV      R4, -(SP)      ::SAVE R4
(1) 007114 010546      MOV      R5, -(SP)      ::SAVE R5
(1) 007116 113704 007267      MOVVB  $OMODE+1, R4      ::GET THE NUMBER OF DIGITS TO TYPE
(1) 007122 005404      NEG      R4
(1) 007124 062704 000006      ADD      #6, R4      ::SUBTRACT IT FOR MAX. ALLOWED
(1) 007130 110437 007266      MOVVB  R4, $OMODE      ::SAVE IT FOR USE
(1) 007134 113704 007265      MOVVB  $OFILL, R4      ::GET THE ZERO FILL SWITCH
(1) 007140 016605 000012      MOV      12(SP), R5      ::PICKUP THE INPUT NUMBER
(1) 007144 005003      CLR      R3      ::CLEAR THE OUTPUT WORD
(1) 007146 006105      1$: ROL      R5      ::ROTATE MSB INTO 'C'
(1) 007150 000404      BR      3$      ::GO DO MSB
(1) 007152 006105      2$: ROL      R5      ::FORM THIS DIGIT
(1) 007154 006105      ROL      R5
(1) 007156 006105      ROL      R5
(1) 007160 010503      MOV      R5, R3
(1) 007162 006103      3$: ROL      R3      ::GET LSB OF THIS DIGIT
(1) 007164 105337 007266      DECB  $OMODE      ::TYPE THIS DIGIT?
(1) 007170 100016      BPL      7$      ::BR IF NO
(1) 007172 042703 177770      BIC  #177770, R3      ::GET RID OF JUNK
(1) 007176 001002      BNE  4$      ::TEST FOR 0

```



```

(1) 007352 000774          BR      3$
(1) 007354 060105          4$: ADD    R1,R5      ;;ADD BACK THE CONSTANT
(1) 007356 005702          TST    R2          ;;CHECK IF BCD DIGIT=0
(1) 007360 001002          BNE    5$          ;;FALL THROUGH IF 0
(1) 007362 105716          TSTB   (SP)        ;;STILL DOING LEADING 0'S?
(1) 007364 100407          BMI    7$          ;;BR IF YES
(1) 007366 106316          5$: ASLB   (SP)        ;;MSD?
(1) 007370 103003          BCC    6$          ;;BR IF NO
(1) 007372 116663 000001 177777 MOVB   1(SP),-1(R3) ;;YES--SET THE SIGN
(1) 007400 052702 000060          6$: BIS    #'0,R2   ;;MAKE THE BCD DIGIT ASCII
(1) 007404 052702 000040          7$: BIS    #' ,R2   ;;MAKE IT A SPACE IF NOT ALREADY A DIGIT
(1) 007410 110223          MOVB   R2,(R3)+   ;;PUT THIS CHARACTER IN THE OUTPUT BUFFER
(1) 007412 005720          TST    (R0)+      ;;JUST INCREMENTING
(1) 007414 020027 000010          CMP    R0,#10    ;;CHECK THE TABLE INDEX
(1) 007420 002746          BLT    2$          ;;GO DO THE NEXT DIGIT
(1) 007422 003002          BGT    8$          ;;GO TO EXIT
(1) 007424 010502          MOV    R5,R2      ;;GET THE LSD
(1) 007426 000764          BR     6$          ;;GO CHANGE TO ASCII
(1) 007430 105726          8$: TSTB   (SP)+   ;;WAS THE LSD THE FIRST NON-ZERO?
(1) 007432 100003          BPL    9$          ;;BR IF NO
(1) 007434 116663 177777 177776 MOVB   -1(SP),-2(R3) ;;YES--SET THE SIGN FOR TYPING
(1) 007442 105013          9$: CLRB   (R3)      ;;SET THE TERMINATOR
(3) 007444 012605          MOV    (SP)+,R5   ;;POP STACK INTO R5
(3) 007446 012603          MOV    (SP)+,R3   ;;POP STACK INTO R3
(3) 007450 012602          MOV    (SP)+,R2   ;;POP STACK INTO R2
(3) 007452 012601          MOV    (SP)+,R1   ;;POP STACK INTO R1
(3) 007454 012600          MOV    (SP)+,R0   ;;POP STACK INTO R0
(1) 007456 104401 007504          TYPE   ,SDBLK     ;;NOW TYPE THE NUMBER
(1) 007462 016666 000002 000004 MOV    2(SP),4(SP) ;;ADJUST THE STACK
(1) 007470 012616          MOV    (SP)+,(SP)
(1) 007472 000002          RTI
(1) 007474 023420          $DTBL: 10000.
(1) 007476 001750          1000.
(1) 007500 000144          100.
(1) 007502 000012          10.
(1) 007504 000004          $DBLK: .BLKW 4
524 .SBTTL BINARY TO ASCII AND TYPE ROUTINE
(1)
(2) ;;*****
(1) ;;*THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 16-BIT
(1) ;;*BINARY-ASCII NUMBER AND TYPE IT.
(1) ;;*CALL:
(1) ;;*   MOV    NUMBER,-(SP)  ;;NUMBER TO BE TYPED
(1) ;;*   TYPBN      ;;TYPE IT
(1)
(1) 007514 010146          $TYPBN: MOV    R1,-(SP) ;;SAVE R1 ON THE STACK
(1) 007516 016601 000006          MOV    6(SP),R1   ;;GET THE INPUT NUMBER
(1) 007522 000261          SEC          ;;SET 'C' SO CAN KEEP TRACK OF THE NUMBER OF BITS
(1) 007524 112737 000060 007566 1$: MOVB   #'0,$BIN   ;;SET CHARACTER TO AN ASCII '0'.
(1) 007532 006101          ROL    R1          ;;GET THIS BIT
(1) 007534 001406          BEQ    2$          ;;DONE?
(1) 007536 105537 007566          ADCB   $BIN       ;;NO--SET THE CHARACTER EQUAL TO THIS BIT
(1) 007542 104401 007566          TYPE   ,SBIN     ;;GO TYPE THIS BIT
(1) 007546 000241          CLC          ;;CLEAR 'C' SO CAN KEEP TRACK OF BITS

```

```

(1) 007550 000765          BR      1$          ;;GO DO THE NEXT BIT
(1) 007552 012601          MOV     (SP)+,R1      ;;POP THE STACK INTO R1
(1) 007554 016666 000002 000004 2$:    MOV     2(SP),4(SP)   ;;ADJUST THE STACK
(1) 007562 012616          MOV     (SP)+,(SP)
(1) 007564 000002          RTI                    ;;RETURN TO USER
(1) 007566 000          000          $BIN:  .BYTE 0,0      ;;STORAGE FOR ASCII CHAR. AND TERMINATOR
525          .SBTTL  APT COMMUNICATIONS ROUTINE
(1)
(2)
(1) 007570 112737 000001 010034 $ATY1: MOVB  #1,$FFLG  ;;TO REPORT FATAL ERROR
(1) 007576 112737 000001 010032 $ATY3: MOVB  #1,$MFLG  ;;TO TYPE A MESSAGE
(1) 007604 000403          BR      $ATYC
(1) 007606 112737 000001 010034 $ATY4: MOVB  #1,$FFLG  ;;TO ONLY REPORT FATAL ERROR
(2) 007614
(3) 007614 C10046          MOV     R0,-(SP)     ;;PUSH R0 ON STACK
(3) 007616 010146          MOV     R1,-(SP)     ;;PUSH R1 ON STACK
(1) 007620 105737 010032          TSTB   $MFLG        ;;SHOULD TYPE A MESSAGE?
(1) 007624 001450          BEQ    5$           ;;IF NOT: BR
(1) 007626 122737 000001 001204 CMPB   #APTENV,$ENV  ;;OPERATING UNDER APT?
(1) 007634 001031          BNE   3$           ;;IF NOT: BR
(1) 007636 132737 000100 001205 BITB   #APTSPOOL,$ENVM ;;SHOULD SPOOL MESSAGES?
(1) 007644 001425          BEQ    3$           ;;IF NOT: BR
(1) 007646 017600 000004          MOV     @4(SP),R0    ;;GET MESSAGE ADDR.
(1) 007652 062766 000002 000004 ADD     #2,4(SP)      ;;BUMP RETURN ADDR.
(1) 007660 005737 001164          1$:    TST     $MSGTYPE  ;;SEE IF DONE W/ LAST XMISSION?
(1) 007664 001375          BNE   1$           ;;IF NOT: WAIT
(1) 007666 010037 001200          MOV     R0,$MSGAD    ;;PUT ADDR IN MAILBOX
(1) 007672 105720          2$:    TSTB   (R0)+      ;;FIND END OF MESSAGE
(1) 007674 001376          BNE   2$
(1) 007676 163700 001200          SUB     $MSGAD,R0    ;;SUB START OF MESSAGE
(1) 007702 006200          ASR    R0           ;;GET MESSAGE LNGTH IN WORDS
(1) 007704 010037 001202          MOV     R0,$MSGGLT   ;;PUT LENGTH IN MAILBOX
(1) 007710 012737 000004 001164 MOV     #4,$MSGTYPE  ;;TELL APT TO TAKE MSG.
(1) 007716 000413          BR      5$
(1) 007720 017637 000004 007744 3$:    MOV     @4(SP),4$    ;;PUT MSG ADDR IN JSR LINKAGE
(1) 007726 062766 000002 000004 ADD     #2,4(SP)      ;;BUMP RETURN ADDRESS
(3) 007734 013746 177776          MOV     177776,-(SP) ;;PUSH 177776 ON STACK
(1) 007740 004737 006560          JSR    PC,$TYPE     ;;CALL TYPE MACRO
(1) 007744 000000          4$:    .WORD 0
(1) 007746          5$:
(1) 007746 105737 010034          10$:   TSTB   $FFLG        ;;SHOULD REPORT FATAL ERROR?
(1) 007752 001416          BEQ    12$         ;;IF NOT: BR
(1) 007754 005737 001204          TST    $ENV        ;;RUNNING UNDER APT?
(1) 007760 001413          BEQ    12$         ;;IF NOT: BR
(1) 007762 005737 001164          11$:   TST     $MSGTYPE  ;;FINISHED LAST MESSAGE?
(1) 007766 001375          BNE   11$         ;;IF NOT: WAIT
(1) 007770 017637 000004 001166 MOV     @4(SP),$FATAL ;;GET ERROR #
(1) 007776 062766 000002 000004 ADD     #2,4(SP)      ;;BUMP RETURN ADDR.
(1) 010004 005237 001164          INC    $MSGTYPE     ;;TELL APT TO TAKE ERROR
(1) 010010 105037 010034          12$:   CLRB   $FFLG        ;;CLEAR FATAL FLAG
(1) 010014 105037 010033          CLRB   $LFLG        ;;CLEAR LOG FLAG
(1) 010020 105037 010032          CLRB   $MFLG        ;;CLEAR MESSAGE FLAG
(3) 010024 012601          MOV     (SP)+,R1    ;;POP STACK INTO R1
(3) 010026 012600          MOV     (SP)+,R0    ;;POP STACK INTO R0

```


(1)	010030	000207	RTS	PC	::RETURN
(1)	010032	000	\$MFLG: .BYTE	0	::MESSG. FLAG
(1)	010033	000	\$LFLG: .BYTE	0	::LOG FLAG
(1)	010034	000	\$FFLG: .BYTE	0	::FATAL FLAG
(1)		010036	.EVEN		
(1)		000200	APTSIZE=200		
(1)		000001	APTENV=001		
(1)		000100	APTSPOOL=100		
(1)		000040	APTCSUP=040		

```

527      .SBTTL  TRAP DECODER
(1)
(2)      ;*****
(1)      ;*THIS ROUTINE WILL PICKUP THE LOWER BYTE OF THE "TRAP" INSTRUCTION
(1)      ;*AND USE IT TO INDEX THROUGH THE TRAP TABLE FOR THE STARTING ADDRESS
(1)      ;*OF THE DESIRED ROUTINE. THEN USING THE ADDRESS OBTAINED IT WILL
(1)      ;*GO TO THAT ROUTINE.
(1)
(1) 010036 010046      $TRAP:  MOV    R0,-(SP)      ;;SAVE R0
(1) 010040 016600 000002      MOV    2(SP),R0      ;;GET TRAP ADDRESS
(1) 010044 005740      TST    -(R0)        ;;BACKUP BY 2
(1) 010046 111000      MOVB   (R0),R0      ;;GET RIGHT BYTE OF TRAP
(1) 010050 006300      ASL    R0           ;;POSITION FOR INDEXING
(1) 010052 016000 010072      MOV    $TRPAD(R0),R0 ;;INDEX TO TABLE
(1) 010056 000200      RTS    R0          ;;GO TO ROUTINE
(1)
(1)      ;;THIS IS USE TO HANDLE THE "GETPRI" MACRO
(1)
(1) 010060 011646      $TRAP2: MOV   (SP),-(SP)  ;;MOVE THE PC DOWN
(1) 010062 016666 000004 000002      MOV   4(SP),2(SP)    ;;MOVE THE PSW DOWN
(1) 010070 000002      RTI                    ;;RESTORE THE PSW
(1)
(3)      .SBTTL  TRAP TABLE
(3)
(3)      ;*THIS TABLE CONTAINS THE STARTING ADDRESSES OF THE ROUTINES CALLED
(3)      ;*BY THE "TRAP" INSTRUCTION.
(3)
(3)      ;      ROUTINE
(3)      ;      -----
(3) 010072 010060      $TRPAD: .WORD  $TRAP2
(3) 010074 006560      $TYPE   ;;CALL=TYPE      TRAP+1(104401)  TTY TYPEOUT ROUTINE
(3) 010076 007066      $TYPOC  ;;CALL=TYPOC     TRAP+2(104402)  TYPE OCTAL NUMBER (WITH LEADING ZEROS)
(3) 010100 007042      $TYPOS  ;;CALL=TYPOS     TRAP+3(104403)  TYPE OCTAL NUMBER (NO LEADING ZEROS)
(3) 010102 007102      $TYPON  ;;CALL=TYPON     TRAP+4(104404)  TYPE OCTAL NUMBER (AS PER LAST CALL)
(3) 010104 007270      $TYPDS  ;;CALL=TYPDS     TRAP+5(104405)  TYPE DECIMAL NUMBER (WITH SIGN)
(3) 010106 007514      $TYPBN  ;;CALL=TYPBN     TRAP+6(104406)  TYPE BINARY (ASCII) NUMBER
(1)
(1)
(3) 010110 006126      $RDCHR  ;;CALL=RDCHR     TRAP+7(104407)  TTY TYPEIN CHARACTER ROUTINE
(3) 010112 006216      $RDLIN  ;;CALL=RDLIN     TRAP+10(104410) TTY TYPEIN STRING ROUTINE
528
529      ;MEMORY USAGE MAP BLOCK
530 010114 000100      ADRPOK: .BLKW  100
531 010314 000000      ADRTOP: 0          ;LAST LOCATION USED BY PROGRAM
532
533      .END
    
```


AABASE	001262	55#	90*	91*	148			
AACNT	001274	63#	98*	152	182			
AAOFF	001250	47#	91					
AAPRI	004054	150	181	475#				
ABASE =	171000	14#	42					
ACDW1 =	000000	42						
ACDW2 =	000000	42						
ACPUOP=	000000	42						
ADBASE	001256	53#	87*	88	90	92	94	131
ADCNT	001270	61#	96*	135	174			
ADDW0 =	000000	42						
ADDW1 =	000000	42						
ADDW10=	000000	42						
ADDW11=	000000	42						
ADDW12=	000000	42						
ADDW13=	000000	42						
ADDW14=	000000	42						
ADDW15=	000000	42						
ADDW2 =	000000	42						
ADDW3 =	000000	42						
ADDW4 =	000000	42						
ADDW5 =	000000	42						
ADDW6 =	000000	42						
ADDW7 =	000000	42						
ADDW8 =	000000	42						
ADDW9 =	000000	42						
ADEVCT=	000000	42						
ADEVN =	000000	42						
ADGO	003456	130	328	391#				
ADPRI	004030	133	173	473#				
ADRP0K	010114	72	213	230	530#			
ADRTOP	010314	227	240	531#				
AENV =	000000	42						
AENVN =	000000	42						
AFATAL=	000000	42						
AMADR1=	000000	42						
AMADR2=	000000	42						
AMADR3=	000000	42						
AMADR4=	000000	42						
AMAMS1=	000000	42						
AMAMS2=	000000	42						
AMAMS3=	000000	42						
AMAMS4=	000000	42						
AMSGAD=	000000	42						
AMSGLG=	000000	42						
AMSGTY=	000000	42						
AMTYP1=	000000	42						
AMTYP2=	000000	42						
AMTYP3=	000000	42						
AMTYP4=	000000	42						
APASS =	000000	42						
APRIOR=	000000	42						
APTCSU=	000040	520	525#					
APTENV=	000001	520	525#					

APTSIZ=	000200	81	525#		
APTSPO=	000100	520	525#		
ASWREG=	000000	42			
ATESTN=	000000	42			
ATPRI	004147	288	480#		
AUNIT =	000000	42			
AUSWR =	000000	42			
AVECT1=	000000	42			
AVECT2=	000000	42			
BEGIN	001324	37	80#	519	
BIT0 =	000001	13#	419		
BIT00 =	000001	13#			
BIT01 =	000002	13#			
BIT02 =	000004	13#			
BIT03 =	000010	13#			
BIT04 =	000020	13#			
BIT05 =	000040	13#			
BIT06 =	000100	13#			
BIT07 =	000200	13#			
BIT08 =	000400	13#			
BIT09 =	001000	13#			
BIT1 =	000002	13#	468		
BIT10 =	002000	13#			
BIT11 =	004000	13#			
BIT12 =	010000	13#			
BIT13 =	020000	13#	456		
BIT14 =	040000	13#			
BIT15 =	100000	13#	211	226	
BIT2 =	000004	13#			
BIT3 =	000010	13#	466		
BIT4 =	000020	13#			
BIT5 =	000040	13#			
BIT6 =	000100	13#	420		
BIT7 =	000200	13#			
BIT8 =	000400	13#	402		
BIT9 =	001000	13#			
BPTVEC=	000014	13#			
CHAIN	000042	33#	105		
CR =	000015	13#	520		
CRLF =	000200	13#	102	520	
DDISP =	177570	13#	42	81	
DIBASE	001264	56#	92*	93*	156
DICNT	001276	64#	99*	160	186
DIGO	003534	155	408#		
DIOFF	001252	48#	93		
DIPRI	004066	158	185	476#	
DISPLA	001142	42#	81*		
DISPRE	001322	76#	81		
DOBASE	001266	57#	94*	95*	164
DOCNT	001300	65#	100*	168	190
DOGO	003560	163	415#		
DOOFF	001254	49#	95		
DOPRI	004100	166	189	477#	
DSWR =	177570	13#	42	81	

