

The main body of the page is a large grid of approximately 15 columns and 20 rows of small tables. Each of these small tables contains various symbols, letters, and numbers, which appear to be part of a control logic or data table for the TSV05 system. The text is too small to read individually, but the overall structure is a dense array of data points.



TSV05

TSV05 CTRL LT2  
CVTSBCO

COPYRIGHT (c) 1982-84  
AH-T096C-MC  
FICHE 02 OF 02

APR 1985

digital

Made In USA



.REM

## IDENTIFICATION

PRODUCT ID: AC-T095C-MC  
PRODUCT TITLE: CVTSBCO TSV05 CTRL LT2  
DECO/DEPO: 1.0  
DEPARTMENT: COMPUTER SPECIAL SYSTEMS/PPG  
DATE: JUNE 4, 1984

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS DOCUMENT.

NO RESPONSIBILITY IS ASSUMED FOR THE USE OR RELIABILITY OF SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL OR ITS AFFILIATED COMPANIES.

COPYRIGHT (C) 1982, 1984 BY DIGITAL EQUIPMENT CORPORATION

THE FOLLOWING ARE TRADEMARKS OF DIGITAL EQUIPMENT CORPORATION:

DIGITAL  
DEC

PDP  
DECUS

UNIBUS  
DECTAPE

MASSBUS

## TABLE OF CONTENTS

1.0	GENERAL INFORMATION
1.1	PROGRAM ABSTRACT
1.2	SYSTEM REQUIREMENTS
1.3	RELATED DOCUMENTS AND STANDARDS
1.4	DIAGNOSTIC HIERARCHY PREREQUISITES
1.5	ASSUMPTIONS
2.0	OPERATING INSTRUCTIONS
2.1	COMMANDS
2.2	SWITCHES
2.3	FLAGS
2.4	HARDWARE QUESTIONS
2.5	SOFTWARE QUESTIONS
2.6	EXTENDED P-TABLE DIALOGUE
2.7	QUICK STARTUP PROCEDURE
3.0	ERROR INFORMATION
4.0	PERFORMANCE AND PROGRESS REPORTS
5.0	DEVICE INFORMATION TABLES
6.0	TEST SUMMARIES
7.0	MAINTENANCE HISTORY

## 1.0 GENERAL INFORMATION

### 1.1 PROGRAM ABSTRACT

THIS IS A PDP-11/23 RESIDENT DIAGNOSTIC WHICH CHECKS THE FUNCTIONALITY OF A TSV05 MAGTAPE SUBSYSTEM WHILE CONNECTED TO A PDP-11/23 SYSTEM (Q-BUS). THE PROGRAM PROVIDES ERROR MESSAGES WHICH IDENTIFY FAILING FUNCTIONS THAT AID IN THE REPAIR OF THE DEVICE. THIS DIAGNOSTIC CONSIST OF TWELVE TEST. TEST 1-9 ARE EXECUTED IN SEQUENCE. TEST 10-12 ARE STAND ALONE TEST WHICH ALLOW THE OPERATOR TO PERFORM SPECIFIC FUNCTIONAL TEST ON SCOPE LOOPS ON CERTAIN FUNCTIONS.

THIS DIAGNOSTIC HAS BEEN WRITTEN FOR USE WITH THE DIAGNOSTIC RUNTIME SERVICES SOFTWARE (SUPERVISOR). THESE SERVICES PROVIDE THE INTERFACE TO THE OPERATOR AND TO THE SOFTWARE ENVIRONMENT. THIS PROGRAM CAN BE USED WITH XXDP+, ACT, APT, SLIDE AND PAPER TAPE. FOR A COMPLETE DESCRIPTION OF THE RUNTIME SERVICES, REFER TO THE XXDP+ USER'S MANUAL. THERE IS A BRIEF DESCRIPTION OF THE RUNTIME SERVICES IN SECTION 2 OF THIS DOCUMENT.

### 1.2 SYSTEM REQUIREMENTS

PDP-11/23 PROCESSOR AND MEMORY  
CAUTION:DIAGNOSTIC REQUIRES 32K WORDS OF MEMORY  
(28K USEABLE AND 4K RESERVED FOR I/O PAGE)  
TSV05 MAGTAPE SUBSYSTEM (DRIVE AND CONTROLLER)  
CONSOLE TERMINAL  
PDP-11 DIAGNOSTIC SUPERVISOR (MSAAA.SYS VERSION 34 OR LATER)  
PDP-11 DIAGNOSTIC LOADER/MONITOR (XXDP+)

### 1.3 RELATED DOCUMENTS AND STANDARDS

#### DIGITAL EQUIPMENT CORPORATION DOCUMENTS:

1. CHBUS XXDP+ USERS GUIDE; DOCUMENT NUMBER AC-F348E-MC  
DATE: 14 JULY 1980.
2. TSV05 TRANSPORT SUBSYSTEM USER'S GUIDE; DOCUMENT NUMBER EK-TSV05-UG-001  
DATE: AUGUST 1982
3. TSV05 TRANSPORT SUBSYSTEM TECHNICAL MANUAL; DOCUMENT NUMBER EK-TSV05-TM-001  
DATE: AUGUST 1982
4. TSV05 TRANSPORT SUBSYSTEM INSTALLATION MANUAL; DOCUMENT NUMBER EK-TSV05-IN-001  
DATE: AUGUST 1982

## 1.4 DIAGNOSTIC HIERARCHY PREREQUISITES

FUNCTIONAL PDP-11/23 CENTRAL PROCESSOR AND MEMORY  
 FUNCTIONAL CONSOLE TERMINAL  
 FUNCTIONAL STANDALONE DIAGNOSTIC SUPERVISOR  
 FUNCTIONAL DIAGNOSTIC LOADER/MONITOR (XXDP.)

## 1.5 ASSUMPTIONS

ALL HARDWARE EXCEPT THE HARDWARE UNDER TEST IS ASSUMED TO WORK PROPERLY OR FALSE ERRORS CAN BE REPORTED.  
 THE TAPE BEING USED ON THE TS05 TRANSPORT IS A KNOWN GOOD REEL OF TAPE.  
 CVTSAA HAS RUN SUCESSFULLY.

## 2.0 OPERATING INSTRUCTIONS

THIS SECTION CONTAINS A BRIEF DESCRIPTION OF THE RUNTIME SERVICES. FOR DETAILED INFORMATION, REFER TO THE XXDP. USER'S MANUAL (CHQUS).

## 2.1 COMMANDS

THERE ARE ELEVEN LEGAL COMMANDS FOR THE DIAGNOSTIC RUNTIME SERVICES (SUPERVISOR). THIS SECTION LISTS THE COMMANDS AND GIVES A VERY BRIEF DESCRIPTION OF THEM. THE XXDP. USER'S MANUAL HAS MORE DETAILS.

COMMAND	EFFECT
-----	-----
START	START THE DIAGNOSTIC FROM AN INITIAL STATE
RESTART	START THE DIAGNOSTIC WITHOUT INITIALIZING
CONTINUE	CONTINUE AT TEST THAT WAS INTERRUPTED (AFTER ↑C)
PROCEED	CONTINUE FROM AN ERROR HALT
EXIT	RETURN TO XXDP. MONITOR (XXDP. OPERATION ONLY!)
ADD	ACTIVATE A UNIT FOR TESTING (ALL UNITS ARE CONSIDERED TO BE ACTIVE AT START TIME)
DROP	DEACTIVATE A UNIT
PRINT	PRINT STATISTICAL INFORMATION (IF IMPLEMENTED BY THE DIAGNOSTIC - SECTION 4.0)
DISPLAY	TYPE A LIST OF ALL DEVICE INFORMATION
FLAGS	TYPE THE STATE OF ALL FLAGS (SEE SECTION 2.3)
ZFLAGS	CLEAR ALL FLAGS (SEE SECTION 2.3)

A COMMAND CAN BE RECOGNIZED BY THE FIRST THREE CHARACTERS. SO YOU MAY, FOR EXAMPLE, TYPE "STA" INSTEAD OF "START".

## 2.1.1 OPERATOR COMMANDS

THE TSV05 DIAGNOSTIC IS A PDP-11/23 DIAGNOSTIC SUPERVISOR COMPATIBLE PROGRAM. ALL LOADING AND RUNTIME INSTRUCTIONS CAN BE REFERENCED IN THE CHQUS XXDP. USERS GUIDE, DOCUMENT NUMBER AC-F348E-MC. THE USER ENTRY IS IN QUOTES.

## BOOT THE DIAGNOSTIC MEDIA

```
.R VTSB??
DIAG. RUN-TIME SERVICES REV D. APR 79
CVTSB-A-0
****TSV05 LOGIC DIAGNOSTIC****
UNIT IS TSV05
>DR
```

## 2.2 SWITCHES

THERE ARE SEVERAL SWITCHES WHICH ARE USED TO MODIFY SUPERVISOR OPERATION. THESE SWITCHES ARE APPENDED TO THE LEGAL COMMANDS. ALL OF THE LEGAL SWITCHES ARE TABULATED BELOW WITH A BRIEF DESCRIPTION OF EACH. IN THE DESCRIPTIONS BELOW, A DECIMAL NUMBER IS DESIGNATED BY "DDDDD".

SWITCH	EFFECT
----- /TESTS:LIST	----- EXECUTE ONLY THOSE TESTS SPECIFIED IN THE LIST. LIST IS A STRING OF TEST NUMBERS, FOR EXAMPLE - /TESTS:1:5:7-10. THIS LIST WILL CAUSE TESTS 1,5,7,8,9,10 TO BE RUN. ALL OTHER TESTS WILL NOT BE RUN.
/PASS:DDDDD	EXECUTE DDDDD PASSES (DDDDD = 1 TO 64000)
/FLAGS:FLGS	SET SPECIFIED FLAGS. FLAGS ARE DESCRIBED IN SECTION 2.3.
/EOP:DDDDD	REPORT END OF PASS MESSAGE AFTER EVERY DDDDD PASSES ONLY. (DDDDD = 1 TO 64000)
/UNITS:LIST	TEST/ADD/DROP ONLY THOSE UNITS SPECIFIED IN THE LIST. LIST EXAMPLE - /UNITS:0:5:10-12 USE UNITS 0,5,10,11,12 (UNIT NUMBERS = 0-63)

## EXAMPLE OF SWITCH USAGE:

```
START/TESTS:1-5/PASS:1000/EOP:100
```

THE EFFECT OF THIS COMMAND WILL BE: 1) TESTS 1 THROUGH 5 WILL BE EXECUTED, 2) ALL UNITS WILL TESTED 1000 TIMES AND 3) THE END OF PASS MESSAGES WILL BE PRINTED AFTER EACH 100 PASSES ONLY. A SWITCH CAN BE RECOGNIZED BY THE FIRST THREE CHARACTERS. YOU MAY, FOR EXAMPLE, TYPE "/TES:1-5" INSTEAD OF "/TESTS:1-5".

BELOW IS A TABLE THAT SPECIFIES WHICH SWITCHES CAN BE USED BY EACH COMMAND.

	TESTS	PASS	FLAGS	EOP	UNITS
START	X	X	X	X	X
RESTART	X	X	X	X	X
CONTINUE		X	X	X	
PROCEED			X		
DROP					X
ADD					X
PRINT					
DISPLAY					X
FLAGS					
ZFLAGS					
EXIT					

### 2.3 FLAGS

FLAGS ARE USED TO SET UP CERTAIN OPERATIONAL PARAMETERS SUCH AS LOOPING ON ERROR. ALL FLAGS ARE CLEARED AT STARTUP AND REMAIN CLEARED UNTIL EXPLICITLY SET USING THE FLAGS SWITCH. FLAGS ARE ALSO CLEARED AFTER A START COMMAND UNLESS SET USING THE FLAG SWITCH. THE ZFLAGS COMMAND MAY ALSO BE USED TO CLEAR ALL FLAGS. WITH THE EXCEPTION OF THE START AND ZFLAGS COMMANDS, NO COMMANDS AFFECT THE STATE OF THE FLAGS; THEY REMAIN SET OR CLEARED AS SPECIFIED BY THE LAST FLAG SWITCH.

FLAG	EFFECT
MOE	HALT ON ERROR - CONTROL IS RETURNED TO RUNTIME SERVICES COMMAND MODE
LOE	LOOP ON ERROR
IER*	INHIBIT ALL ERROR REPORTS
IBR*	INHIBIT ALL ERROR REPORTS EXCEPT FIRST LEVEL (FIRST LEVEL CONTAINS ERROR TYPE, NUMBER, PC, TEST AND UNIT)
IXE*	INHIBIT EXTENDED ERROR REPORTS (THOSE CALLED BY PRINTX MACRO'S)
PRI	DIRECT MESSAGES TO LINE PRINTER
PNT	PRINT TEST NUMBER AS TEST EXECUTES
BOE	"BELL" ON ERROR
UAM	UNATTENDED MODE (NO MANUAL INTERVENTION)
ISR	INHIBIT STATISTICAL REPORTS (DOES NOT APPLY TO DIAGNOSTICS WHICH DO NOT SUPPORT STATISTICAL REPORTING)
IDR	INHIBIT PROGRAM DROPPING OF UNITS
ADR	EXECUTE AUTODROP CODE
LOT	LOOP ON TEST

\*ERROR MESSAGES ARE DESCRIBED IN SECTION 3.1



SEE THE XXDP+ USER'S MANUAL FOR MORE DETAILS ON FLAGS. YOU MAY SPECIFY MORE THAN ONE FLAG WITH THE FLAG SWITCH. FOR EXAMPLE, TO CAUSE THE PROGRAM TO LOOP ON ERROR, INHIBIT ERROR REPORTS AND TYPE A "BELL" ON ERROR, YOU MAY USE THE FOLLOWING STRING:

```
/FLAGS:LOE:IER:BOE
```

#### 2.4 HARDWARE QUESTIONS

WHEN A DIAGNOSTIC IS STARTED, THE RUNTIME SERVICES WILL PROMPT THE USER FOR HARDWARE INFORMATION BY TYPING "CHANGE HW (L) ?" YOU MUST ANSWER "Y" AFTER A START COMMAND UNLESS THE HARDWARE INFORMATION HAS BEEN "PRELOADED" USING THE SETUP UTILITY (SEE CHAPTER 14 OF THE XXDP+ USER'S MANUAL). WHEN YOU ANSWER THIS QUESTION WITH A "Y", THE RUNTIME SERVICES WILL ASK FOR THE NUMBER OF UNITS (IN DECIMAL).

AFTER INITIAL STARTING OF THE PROGRAM (START COMMAND TO THE DIAGNOSTIC SUPERVISOR), THE PROGRAM WILL ISSUE THE "CHANGE HW?" QUESTION TO ASK IF THE HARDWARE PARAMETERS ARE TO BE CHANGED (BY THE OPERATOR).

ON A "N" (NO) RESPONSE TO THE "CHANGE HW?" QUESTION, THE DIAGNOSTIC WILL RUN USING THE DEFAULT VALUES FOR ALL QUESTIONS. THE DEFAULT ADDRESS AND VECTOR ARE:

```
TSBA/TSDB = 172520, VECTOR = 224
```

ON A "Y" (YES) RESPONSE TO THE QUESTION, THE FOLLOWING QUESTIONS WILL THEN BE ASKED TO ALLOW THE OPERATOR TO SELECT THE UNITS TO BE TESTED. A VALUE, IF PRESENT, LOCATED TO THE LEFT OF THE QUESTION MARK IS THE DEFAULT VALUE THAT WILL BE TAKEN IF ONLY A CARRIAGE RETURN IS TYPED AS A RESPONSE. A "(D)" IN A QUESTION INDICATES THAT A DECIMAL NUMBER IS REQUIRED AS A RESPONSE. AN "(O)" INDICATES AN OCTAL NUMBER IS BEING SOLICITED. AN "(L)" INDICATES THAT A LOGICAL RESPONSE IS TO BE MADE: "Y" FOR YES, "N" FOR NO.

```
# UNITS (D) ? <ENTER THE NUMBER OF M7196 CONTROLLERS  
PRESENT TO BE TESTED>
```

```
UNIT 0
```

```
DEVICE ADDRESS (O) 172520 ? <ENTER THE ADDRESS OF THE  
TSBA/TSDB REGISTER>
```

```
VECTOR (O) 224 ? <ENTER ADDRESS OF INTERRUPT  
VECTOR>
```

THE ADDRESS AND VECTOR QUESTIONS WILL BE ASKED FOR EACH OF THE NUMBER OF UNITS (CONTROLLERS) SPECIFIED IN THE "# UNITS?" QUESTION. LOGICAL UNIT NUMBERS ARE ASSIGNED IN ORDER, BEGINNING AT 0. UP TO FOUR UNITS CAN BE SELECTED FOR TESTING AS FOLLOWS:  
UP TO 4 TSV05 CONTROLLERS PER 11/23 AND UP TO 2 DRIVES PER CONTROLLER

## 2.5 SOFTWARE QUESTIONS

AFTER YOU HAVE ANSWERED THE HARDWARE QUESTIONS OR AFTER A RESTART OR CONTINUE COMMAND, THE RUNTIME SERVICES WILL ASK FOR SOFTWARE PARAMETERS. THESE PARAMETERS WILL GOVERN SOME DIAGNOSTIC SPECIFIC OPERATION MODES. YOU WILL BE PROMPTED BY "CHANGE SW (L) ?" IF YOU WISH TO CHANGE ANY PARAMETERS, ANSWER BY TYPING "Y". THE SOFTWARE QUESTIONS AND THE DEFAULT VALUES ARE DESCRIBED IN THE NEXT PARAGRAPH(S).

THE FOLLOWING QUESTIONS ARE ASKED ON A START, RESTART, OR CONTINUE. THEY ALLOW FLEXIBILITY IN THE WAY THE PROGRAM BEHAVES.

CHANGE SW (L) ? <TYPE Y TO CAUSE THE FOLLOWING  
QUESTIONS TO BE ASKED>

INHIBIT ITERATIONS (L) N ? <TYPE "Y" TO PREVENT MULTIPLE  
ITERATIONS OF CERTAIN TESTS.  
THIS CAUSES EACH TEST PASS TO  
RUN AS QUICKLY AS POSSIBLE.  
ONLY QUICK-RUNNING LOGIC  
TESTS USE MULTIPLE  
ITERATIONS.>

## 2.6 EXTENDED P-TABLE DIALOGUE

WHEN YOU ANSWER THE HARDWARE QUESTIONS, YOU ARE BUILDING ENTRIES IN A TABLE THAT DESCRIBES THE DEVICES UNDER TEST. THE SIMPLEST WAY TO BUILD THIS TABLE IS TO ANSWER ALL QUESTIONS FOR EACH UNIT TO BE TESTED. IF YOU HAVE A MULTIPLEXED DEVICE SUCH AS A MASS STORAGE CONTROLLER WITH SEVERAL DRIVES OR A COMMUNICATION DEVICE WITH SEVERAL LINES, THIS BECOMES TEDIOUS SINCE MOST OF THE ANSWERS ARE REPETITIOUS.

TO ILLUSTRATE A MORE EFFICIENT METHOD, SUPPOSE YOU ARE TESTING A DEVICE, THE XY11. SUPPOSE THIS DEVICE CONSISTS OF A CONTROL MODULE WITH EIGHT UNITS (SUB-DEVICES) ATTACHED TO IT. THESE UNITS ARE DESCRIBED BY THE OCTAL NUMBERS 0 THROUGH 7. THERE IS ONE HARDWARE PARAMETER THAT CAN VARY AMONG UNITS CALLED THE Q-FACTOR. THIS Q-FACTOR MAY BE 0 OR 1. BELOW IS A SIMPLE WAY TO BUILD A TABLE FOR ONE XY11 WITH EIGHT UNITS.

# UNITS (0) ? 8<CR>

UNIT 1  
CSR ADDRESS (0) ? 160000<CR>  
SUB-DEVICE # (0) ? 0<CR>  
Q-FACTOR (0) 0 ? 1<CR>

UNIT 2  
CSR ADDRESS (0) ? 160000<CR>  
SUB-DEVICE # (0) ? 1<CR>  
Q-FACTOR (0) 1 ? 0<CR>

UNIT 3  
CSR ADDRESS (0) ? 160000<CR>  
SUB-DEVICE # (0) ? 2<CR>  
Q-FACTOR (0) 0 ? <CR>

UNIT 4  
CSR ADDRESS (0) ? 160000<CR>  
SUB-DEVICE # (0) ? 3<CR>  
Q-FACTOR (0) 0 ? <CR>

UNIT 5  
CSR ADDRESS (0) ? 160000<CR>  
SUB-DEVICE # (0) ? 4<CR>  
Q-FACTOR (0) 0 ? <CR>

UNIT 6  
CSR ADDRESS (0) ? 160000<CR>  
SUB-DEVICE # (0) ? 5<CR>  
Q-FACTOR (0) 0 ? <CR>

UNIT 7  
CSR ADDRESS (0) ? 160000<CR>  
SUB-DEVICE # (0) ? 6<CR>  
Q-FACTOR (0) 0 ? 1<CR>

UNIT 8  
CSR ADDRESS (0) 160000<CR>  
SUB-DEVICE # (0) ? 7<CR>  
Q-FACTOR (0) 1 ? <CR>

NOTICE THAT THE DEFAULT VALUE FOR THE Q-FACTOR CHANGES WHEN A NON-DEFAULT RESPONSE IS GIVEN. BE CAREFUL WHEN SPECIFYING MULTIPLE UNITS!

AS YOU CAN SEE FROM THE ABOVE EXAMPLE, THE HARDWARE PARAMETERS DO NOT VARY SIGNIFICANTLY FROM UNIT TO UNIT. THE PROCEDURE SHOWN IS NOT VERY EFFICIENT.

THE RUNTIME SERVICES CAN TAKE MULTIPLE UNIT SPECIFICATIONS HOWEVER.  
LET'S BUILD THE SAME TABLE USING THE MULTIPLE SPECIFICATION  
FEATURE.

```

# UNITS (0) ? 8<CR>

UNIT 1
CSR ADDRESS (0) ? 160000<CP>
SUB-DEVICE # (0) ? 0,1<CR>
Q-FACTOR (0) 0 ? 1,0<CR>

UNIT 3
CSR ADDRESS (0) ? 160000<CR>
SUB-DEVICE # (0) ? 2-5<CR>
Q-FACTOR (0) 0 ? 0<CR>

UNIT 7
CSR ADDRESS (0) ? 160000<CR>
SUB-DEVICE # (0) ? 6,7<CR>
Q-FACTOR (0) 0 ? 1<CR>

```

AS YOU CAN SEE IN THE ABOVE DIALOGUE, THE RUNTIME SERVICES WILL BUILD AS MANY ENTRIES AS IT CAN WITH THE INFORMATION GIVEN IN ANY ONE PASS THROUGH THE QUESTIONS. IN THE FIRST PASS, TWO ENTRIES ARE BUILT SINCE TWO SUB-DEVICES AND Q-FACTORS WERE SPECIFIED. THE SERVICES ASSUME THAT THE CSR ADDRESS IS 160000 FOR BOTH SINCE IT WAS SPECIFIED ONLY ONCE. IN THE SECOND PASS, FOUR ENTRIES WERE BUILT. THIS IS BECAUSE FOUR SUB-DEVICES WERE SPECIFIED. THE "-" CONSTRUCT TELLS THE RUNTIME SERVICES TO INCREMENT THE DATA FROM THE FIRST NUMBER TO THE SECOND. IN THIS CASE, SUB-DEVICES 2, 3, 4 AND 5 WERE SPECIFIED. (IF THE SUB-DEVICE WERE SPECIFIED BY ADDRESSES, THE INCREMENT WOULD BE BY 2 SINCE ADDRESSES MUST BE ON AN EVEN BOUNDARY.) THE CSR ADDRESSES AND Q-FACTORS FOR THE FOUR ENTRIES ARE ASSUMED TO BE 160000 AND 0 RESPECTIVELY SINCE THEY WERE ONLY SPECIFIED ONCE. THE LAST TWO UNITS ARE SPECIFIED IN THE THIRD PASS.

THE WHOLE PROCESS COULD HAVE BEEN ACCOMPLISHED IN ONE PASS AS SHOWN BELOW.

```

# UNITS (0) ? 8<CR>

UNIT 1
CSR ADDRESS (0) ? 160000<CR>
SUB-DEVICE # (0) ? 0-7<CR>
Q-FACTOR (0) 0 ? 0,1,0,...,1,1<CR>

```

AS YOU CAN SEE FROM THIS EXAMPLE, NULL REPLIES (COMMAS ENCLOSING A NULL FIELD) TELL THE RUNTIME SERVICES TO REPEAT THE LAST REPLY.

## 2.7 QUICK START-UP PROCEDURE (XXDP.)

TO START-UP THIS PROGRAM:

1. BOOT XXDP.
2. GIVE THE DATE AND ANSWER THE LSI AND 50HZ (IF THERE IS A CLOCK) QUESTIONS
3. TYPE "R NAME", WHERE NAME IS THE NAME OF THE BIN OR BIC FILE FOR THIS PROGRAM
4. TYPE "START"
5. ANSWER THE "CHANGE HW" QUESTION WITH "Y"
6. ANSWER ALL THE HARDWARE QUESTIONS
7. ANSWER THE "CHANGE SW" QUESTION WITH "N"

WHEN YOU FOLLOW THIS PROCEDURE YOU WILL BE USING ONLY THE DEFAULTS FOR FLAGS AND SOFTWARE PARAMETERS. THESE DEFAULTS ARE DESCRIBED IN SECTIONS 2.3 AND 2.5.

## 3.0 ERROR INFORMATION

## 3.1 TYPES OF ERROR MESSAGES

THERE ARE THREE LEVELS OF ERROR MESSAGES THAT MAY BE ISSUED BY A DIAGNOSTIC: GENERAL, BASIC AND EXTENDED. GENERAL ERROR MESSAGES ARE ALWAYS PRINTED UNLESS THE "IER" FLAG IS SET (SECTION 2.3). THE GENERAL ERROR MESSAGE IS OF THE FORM:

```
NAME TYPE NUMBER ON UNIT NUMBER TST NUMBER PC:XXXXXX  
ERROR MESSAGE
```

WHERE: NAME = DIAGNOSTIC NAME  
TYPE = ERROR TYPE (SYS FATAL, DEV FATAL, HARD OR SOFT)  
NUMBER = ERROR NUMBER  
UNIT NUMBER = 0 - N (N IS LAST UNIT IN PTABLE)  
TST NUMBER = TEST AND SUBTEST WHERE ERROR OCCURRED  
PC:XXXXXX = ADDRESS OF ERROR MESSAGE CALL

BASIC ERROR MESSAGES ARE MESSAGES THAT CONTAIN SOME ADDITIONAL INFORMATION ABOUT THE ERROR. THESE ARE ALWAYS PRINTED UNLESS THE "IER" OR "IBR" FLAGS ARE SET (SECTION 2.3). THESE MESSAGES ARE PRINTED AFTER THE ASSOCIATED GENERAL MESSAGE.

EXTENDED ERROR MESSAGES CONTAIN SUPPLEMENTARY ERROR INFORMATION SUCH AS REGISTER CONTENTS OR GOOD/BAD DATA. THESE ARE ALWAYS PRINTED UNLESS THE "IER", "IBR" OR "IXR" FLAGS ARE SET (SECTION 2.3). THESE MESSAGES ARE PRINTED AFTER THE ASSOCIATED GENERAL ERROR MESSAGE AND ANY ASSOCIATED BASIC ERROR MESSAGES.

## 3.2 SPECIFIC ERROR MESSAGES

BELOW ARE SAMPLE ERROR MESSAGES. EACH ERROR MESSAGE REPRESENTS DIFFERENT TYPES OF ERRORS DETECTED BY THIS DIAGNOSTIC.

## ERROR MESSAGE EXAMPLE 1

THIS ERROR IS INDICATIVE OF AN INCORRECT REGISTER OR STATUS WORD RETURNED TO THE DIAGNOSTIC. THE FIRST PART DEFINES THE TEST FUNCTION AND UNIT THAT FAILED. THE SECOND PART PROVIDES THE REGISTER BITS AND THEIR MNEMONICS FOR THE INCORRECT REGISTER OR STATUS WORDS. THE THIRD PART IS THE EXPECTED AND RECEIVED DATA.

TST: 016 FIFO EXERCISER TEST  
CVTSB HRD ERR 01610 ON UNIT 00 TST 016 SUB 002 PC: 040624  
FIFO STATUS (IN WORD 9) INCORRECT AFTER WRITE FIFO

TAPE BUS SIGNALS IN WORD #8: - DESIGNATOR <BIT #>  
PARERR<15> IEOT <12> IFMK <9> IRDY<6> IRWD<2>  
IRESV2<14> IIDENT<11> IHER <8> IONL<5> IFBY<1>  
IRESV1<13> ICER <10> ISPEED<7> ILDP<4> IFPT<0>

TAPE BUS SIGNALS IN WORD #9:  
DATMIS<7> ILW<6> OUTRDY<5> INRDY<4>

MESSAGE BUFFER ADDRESS = 047352

MESSAGE BUFFER CONTENTS:

WORD #0	EXPD: 100020	RECV: 100020	XOR: 000000
WORD #1	EXPD: 000012	RECV: 000012	XOR: 000000
WORD #2	EXPD: 000000	RECV: 000000	XOR: 000000
WORD #3	EXPD: 000010	RECV: 000010	XOR: 000000
WORD #4	EXPD: 000000	RECV: 000000	XOR: 000000
WORD #5	EXPD: 000000	RECV: 000000	XOR: 000000
WORD #6	EXPD: 000000	RECV: 000000	XOR: 000000
WORD #7	EXPD: 000000	RECV: 000000	XOR: 000000
WORD #8	EXPD: 070217	RECV: 070217	XOR: 000000
WORD #9	EXPD: 000074	RECV: 000034	XOR: 000040

## ERROR MESSAGE EXAMPLE 2

THIS ERROR SHOWS A FATAL FUNCTION ERROR FROM THE TAPE DRIVE. IN THIS INSTANCE A UNRECOVERABLE ERROR OCCURED WHICH INDICATES THAT THE CONTROLLER MAY BE DEFECTIVE.

CVTSB HRD ERR 00159 ON UNIT 00 TST 001 SUB 005 PC: 026202  
TSSR NOT CORRECT AFTER SPACE RECORDS COMMAND

TSSR = 100214

TSSR BITS SET: SC,SSR

TERMINATION CLASS CODE = UNRECOVERABLE ERROR

PACKET ADDRESS = 026420

PACKET WORD # = 140010

PACKET WORD # = 000010

PACKET WORD # = 000000

PACKET WORD # = 000024

## ERROR MESSAGE EXAMPLE 3

THIS ERROR SHOWS THAT THE MOTION BIT DID NOT GET SET WHILE DOING A REWIND WITH EXTENDED FEATURES MODE ENABLED.

CVTSB MRD ERR 00121 ON UNIT 00 TST 001 SUB 002 FC. 023306  
MOT BIT (XST0) NOT SET DURING REWIND (EXTENDED FEATURES MODE)  
EXPD: 000312 RECV: 000112 XOR: 000200

## 4.0 PERFORMANCE AND PROGRESS REPORTS

AT THE END OF EACH PASS, THE PASS COUNT IS GIVEN ALONG WITH THE TOTAL NUMBER OF ERRORS REPORTED SINCE THE DIAGNOSTIC WAS STARTED. THE "EOP" SWITCH CAN BE USED TO CONTROL HOW OFTEN THE END OF PASS MESSAGE IS PRINTED. SECTION 2.2 DESCRIBES SWITCHES.

## SUCCESSFUL RUN EXAMPLE (PDP-11/23)

DR>STA/FLA:PN1:HOE:UAM

UNITS (D) ? 1

UNIT 0

DEVICE ADDRESS (0) 172520 ? <CR>

VECTOR (0) 224 ? <CR>

CHANGE SW (L) ? N<CR>

THE ABOVE COMMAND WILL START THE DIAGNOSTIC. THE COMMAND HAS THREE SWITCHES ON WHICH ARE "PRINT EACH TEST NBR AS EXECUTED", "HALT ON ERROR" AND "RUN IN UNATTENDED MODE".

NOTE: THE UAM FLAG SHOULD BE USED TO PREVENT TEST 10-12 FROM BEING EXECUTED UNLESS THE OPERATOR WANTS THESE SPECIFIC TEST

TST: 001 INITIALIZE #3 TEST  
TST: 002 BASIC WRITE SUBSYSTEM MEMORY TEST  
TST: 003 DMA MEMORY ADDRESSING TEST  
TST: 004 RAM EXERCISER TEST  
TST: 005 FIFO EXERCISER TEST  
TST: 006 STATIC TRANSPORT BUS CHECK  
TST: 007 TRANSPORT BUS INTERFACE CHECK VIA LOOPBACK TEST  
TST: 008 READ/WRITE DATA PARITY CHECK TEST  
TST: 009 MISCELLANEOUS LOGIC CHECKS TEST  
TST: 010 STAND-ALONE MANUAL INTERVENTION NOT EXECUTED TEST  
TST: 011 STAND-ALONE CONFIGURATION TYPEOUT NOT EXECUTED TEST  
TST: 012 STAND-ALONE SCOPE LOOPS NOT EXECUTED TEST

0 ERRORS

NOTE: THE DIAGNOSTIC WILL RUN CONTINUOUSLY UNLESS A PASS LIMIT HAS BEEN SPECIFIED WITH THE "/PASS:" SWITCH.

PROGRAM RUN TIMES

THE AVERAGE RUN TIMES OF THE PROGRAM ARE LISTED BELOW. THESE FIGURES ARE TO BE USED AS A GUIDE. THE TIMING WAS DONE ON A PDP-11/23 PROCESSOR WITH A LA-34 CONSOLE.

THE PROGRAM RUNS IN TWO MODES; NO ITERATIONS AND DEFAULT MODE. IN THE NO ITERATIONS MODE, EACH TEST IS RUN ONCE, WITH NO ITERATIONS. IN THE DEFAULT MODE EACH TEST IS REPEATED BY THE NUMBER OF TIMES INDICATED BY THE ITERATION COUNT. NO ITERATIONS MODE IS SELECTED BY ANSWERING THE INHIBIT ITERATIONS QUESTION WITH A "Y" (YES).

TEST NUMBER	N/I SECS.	ITER SECS	DEF SECS.
1	15	50	35
2	1	6	5
3	1	1	0
4	110	540	430
5	1	10	9
6	10	120	110
7	1	3	2
8	15	15	12
9	17	17	13

THE TIMES REQUIRED TO RUN TESTS 1 THROUGH 9 IN ONE COMMAND:

Q.V. 2 MINS 19 SECONDS  
 DEFAULT 11 MINS 35 SECONDS



## 5.0 DEVICE INFORMATION TABLES

WHENEVER THE PROGRAM IS STARTED, VIA THE STA(RT) COMMAND, THE SUPERVISOR REQUESTS THE FOLLOWING P-TABLES PARAMETER CHANGES:

CHANGE MW (L) ?

# UNITS (D) ? <ENTER THE NUMBER OF M7196 CONTROLLERS  
PRESENT TO BE TESTED>

UNIT 0

DEVICE ADDRESS (O) 172520 ? <ENTER THE ADDRESS OF THE  
TSBA/TSDB REGISTER>

VECTOR (O) 224 ? <ENTER ADDRESS OF INTERRUPT  
VECTOR>

THE ADDRESS AND VECTOR QUESTIONS WILL BE ASKED FOR EACH OF THE NUMBER OF UNITS (CONTROLLERS) SPECIFIED IN THE "# UNITS?" QUESTION. LOGICAL UNIT NUMBERS ARE ASSIGNED IN ORDER, BEGINNING AT 0. UP TO FOUR UNITS CAN BE SELECTED FOR TESTING.

IN ADDITION, ON A START, RESTART OR CONTINUE THE SUPERVISOR REQUESTS CHANGES TO THE SOFTWARE OPERATING PARAMETERS, AS FOLLOWS:

CHANGE SW (L) ?

6.0 TEST SUMMARIES

TEST 1: INITIALIZE AFTER WRITE CHARACTERISTICS

TEST DESCRIPTION:

THIS TEST VERIFIES THAT A HARDWARE INITIALIZE COMMAND INVOKED AFTER A WRITE CHARACTERISTICS COMMAND SETS UP THE COMMAND, MESSAGE AND CHARACTERISTIC IMAGE BLOCKS IN THE CONTROLLER RAM CORRECTLY.

TEST 2: BASIC WRITE SUBSYSTEM MEMORY COMMAND

THIS TEST VERIFIES THAT THE WRITE SUBSYSTEM MEMORY COMMAND WITH A BSEL0 SELECT CODE OF 0 (NO-OP) EXECUTES CORRECTLY. IT ALSO VERIFIES THAT A WRITE SUBSYSTEM MEMORY COMMAND WITH A NON-ZERO MODE FIELD IS REJECTED. THE TEST FURTHER VERIFIES MICROPROGRAM COMMAND DECODING AND HANDLING SEQUENCES.

TEST 3: DMA MEMORY ADDRESSING

THIS TEST VERIFIES THAT THE CONTROLLER CAN PROPERLY ADDRESS AND ACCESS ALL AVAILABLE CPU MEMORY (OTHER THAN THAT OCCUPIED BY THE DIAGNOSTIC AND DIAGNOSTIC SUPERVISOR CODE) FOR BOTH READING (DATI) AND WRITING (DATO). VERIFIED ARE THE LSI-11 BUS DRIVERS FOR ALL AVAILABLE ADDRESS LINES. UP TO THIS POINT ONLY 16 BITS HAVE BEEN USED FOR DMA TRANSFERS.

\*\*\*\*\*  
CAUTION

THE LSI BUS DRIVERS FOR ALL AVAILABLE ADDRESS LINES ARE ONLY CHECKED WHEN RUNNING ON A 11/238 SYSTEM WITH MORE THAN 128K WORDS OF MEMORY!

\*\*\*\*\*

TEST 4: RAM EXERCISER TEST

THIS TEST USES THE READ AND WRITE RAM (BOTH SINGLE AND 256 LOCATIONS) SELECT CODES OF THE WRITE SUBSYSTEM MEMORY COMMAND TO EXERCISE THE CONTROLLER'S RAM MEMORY AND DMA LOGIC

TEST 5: EXTENDED FEATURES SWITCH AND TIMERS A,B

TEST DESCRIPTION:

THIS TEST VERIFIES THE INVERT EXTENDED FEATURES FUNCTION CAN LOGICALLY INVERT THE EXTENDED FEATURES SWITCH AND THAT THE INTERNAL TIMERS A AND B OPERATE CORRECTLY.

## TEST 6: FIFO EXERCISER

## TEST DESCRIPTION:

THIS TEST USES THE WRITE SUBSYSTEM MEMORY COMMAND TO VERIFY THE CONTROLLER'S FIFO AND ASSOCIATED STATUS AND CONTROL LOGIC.

## TEST 7: STATIC TRANSPORT BUS INTERFACE TEST

## TEST DESCRIPTION:

WRITE TO TSSR REGISTER TO SOFT INITIALIZE THE CONTROLLER  
DO WRITE CHARACTERISTICS TO CHECK FOR EXTENDED FEATURES SWITCH  
IF EXTENDED FEATURES HARDWARE SWITCH CLEAR THEN:  
DO WRITE SUBSYSTEM WRITE MISCELLANEOUS TO SET EXTENDED FEATURES.  
DO WRITE CHARACTERISTICS TO SELECT RESERVED UNIT 7  
DO A WRITE SUBSYSTEM READ STATUS  
IF ANY TRANSPORT INTERFACE SIGNALS ARE ASSERTED THEN PRINT ERROR

## TEST 8: TRANSPORT BUS INTERFACE LOOPBACK TEST

## TEST DESCRIPTION:

THIS TEST VERIFIES THE CONTROLLER'S TRANSPORT BUS DRIVERS, RECEIVERS, AND SIGNAL LOOPBACK LOGIC. NOTE THAT THE STATIC TRANSPORT BUS TEST MUST HAVE RUN CORRECTLY FOR THIS TEST TO PROVIDE MEANINGFUL RESULTS.

## TEST 9: READ/WRITE DATA PARITY TEST

## TEST DESCRIPTION:

THIS TEST VERIFIES THAT THE WRITE DATA PARITY GENERATOR AND THE READ DATA PARITY CHECKER OPERATE PROPERLY. THE TRANSPORT BUS SIGNAL LOOPBACK MODE IS ENABLED AND A SET WRONG PARITY FUNCTION IS EXECUTED. THEN VARIOUS WRITE SUBSYSTEM MEMORY FUNCTIONS ARE PERFORMED TO WRITE DATA TO AND FROM THE FIFO IN LOOPBACK MODE. THE PROGRAM THEN CHECKS TO INSURE A READ DATA PARITY ERROR OCCURRED.  
A RESET FIFO IS DONE AND THE READ DATA PARITY ERROR BIT IS AGAIN TESTED TO INSURE IT CLEARED. FINALLY A CLEAR WRONG PARITY FUNCTION IS DONE AND IT IS VERIFIED THE DATA WORD CAN PASS IN LOOPBACK MODE WITHOUT SETTING READ DATA PARITY ERROR.

## TEST 10: MANUAL INTERVENTION

THE MANUAL INTERVENTION TEST IS A STANDALONE ROUTINE (NOT REALLY A "TEST") THAT ALLOWS THE OPERATOR TO CHECK OUT VARIOUS ELEMENTS AND FUNCTIONS OF THE SUBSYSTEM THAT CANNOT BE MANIPULATED BY THE PROGRAM ALONE. WHEN THIS ROUTINE IS STARTED, IT FIRST PRINTS OUT A MENU OF SELECTABLE SUBTESTS AND THEN WAITS FOR THE OPERATOR TO TYPE IN A SELECTION CODE. THE ONLY WAYS TO EXIT THIS ROUTINE AND RETURN TO THE DIAGNOSTIC SUPERVISOR ARE BY TYPING <CTRL-C> OR SELECTING CODE 6. SELECTION CODES AND SUBROUTINES ARE:

CODE	ROUTINE
0	HELP. PRINTS THIS MENU.
1	TURN ON ALL M7196 LED INDICATORS
2	TURN OFF ALL M7196 LED INDICATORS
3	OFFLINE/OFFLINE ATTENTION TEST
4	WRITE-PROTECT TEST
5	PRINT EXTENDED TRANSPORT STATUS
6	EXIT (RETURN TO SUPERVISOR)

## TEST 11: CONFIGURATION TYPEOUT

THIS IS A STANDALONE ROUTINE THAT PRINTS OUT ON THE CONSOLE TERMINAL THE CONFIGURATION OF THE M7196 MODULE AND TSV05 SUBSYSTEM. SPECIFICALLY, THE FOLLOWING INFORMATION IS PRESENTED:

- 1.0 STATE OF THE EXTENDED FEATURES SWITCH ON THE M7196: ON (EXTENDED FEATURES ENABLED) OR OFF (EXTENDED FEATURES DISABLED).
- 2.0 STATE OF THE BUFFERING ENABLE SWITCH ON THE M7196: ON (BUFFERING ENABLED) OR OFF (BUFFERING DISABLED).
- 3.0 MICROCODE REVISION LEVEL OF THE M7196.
- 4.0 NUMBER OF TAPE TRANSPORTS CONNECTED TO THE CONTROLLER.
- 5.0 UNIT SELECT CODE AND STATE (ONLINE/OFFLINE, WRITE ENABLED/PROTECTED) OF EACH CONNECTED TRANSPORT. IN ADDITION, THE PROGRAM WILL INDICATE, FOR EACH ON-LINE TRANSPORT, WHETHER OR NOT IT IS EQUIPPED WITH THE EXTENDED TAPE STATUS READOUT FEATURE.

## TEST 12: SCOPE LOOPS

THIS IS A STANDALONE ROUTINE PROVIDING A NUMBER OF TIGHT "SCOPE LOOPS" USEFUL FOR DEBUGGING BASIC REGISTER ACCESS PROBLEMS WITH THE M7196 MODULE. THESE SCOPE LOOPS CAN BE USED WHEN THE NORMAL "LOOP ON ERROR" OR "LOOP ON TEST (SUBTEST)" FACILITIES DON'T SEEM TO ALLOW THE OPERATOR TO ZERO IN A PROBLEM IN THE EARLY TESTS (I.E. THE HARDWARE MAY NOT BE RESPONDING TO A REGISTER ACCESS, CAUSING A BUS ERROR TRAP, EVEN THOUGH THE DEVICE ADDRESS SELECTED BY THE PROGRAM MATCHES THE CONFIGURATION SET UP IN THE HARDWARE DIP SWITCHES). THE FOLLOWING MENU OF SCOPE LOOPS ARE AVAILABLE:

CODE	SCOPE LOOP
0	HELP. PRINT THIS MENU.
1	TSBA READ ACCESS
2	TSSR READ ACCESS
3	INITIALIZE (TSSR WRITE ACCESS)
4	TSDB HIGH BYTE WRITE ACCESS
5	TSDB LOW BYTE WRITE ACCESS
6	TSDB MAINTENANCE-MODE WORD WRITE ACCESS
7	TSDBX (TSSR HIGH BYTE) WRITE ACCESS (EXTENDED FEATURES SWITCH MUST BE ON TO USE SELECTION CODE 7)
8	EXIT (RETURN TO SUPERVISOR)

FOR SCOPE LOOPS THAT WRITE INTO REGISTERS, THE PROGRAM PROMPTS THE OPERATOR FOR THE DATA TO BE WRITTEN, LIMITS ON THE DATA PATTERNS ARE 0-377. TYPING <RETURN> CAUSES AN EXIT FROM THE SCOPE LOOP BACK TO MENU LEVEL.

## 7.0 MAINTENANCE HISTORY

REVISION A - MARCH 1982

REVISION B - APRIL 1983

MODIFIED THE DIAGNOSTIC TO HANDLE 11/23A'S WITH MORE THAN 256KB OF MEMORY. CHANGED TEST 3 SUBTEST 3 SO IT WON'T TRY TO CREATE NON-EXISTANT MEMORY ADDRESS (NXM).

REVISION C - JUNE 1984

MINOR CHANGES FOR "ORION" CPU  
ELIMINATED CPU TYPE IDENTIFICATION MESSAGE.

```

2          .TITLE  TSV2 - PROGRAM HEADER
3          .SBTTL  PROGRAM HEADER
4
10         .MCALL  SVC
11 000000  SVC          ; INITIALIZE SUPERVISOR MACROS
12         .ENABLE LC
13         .NLIST  BEX,CND
19 000000  .ENABL  ABS,AMA
20         .=2000
21 002000  BGNMOD  TSV2
   002000
22
23         ;**
24         ; THE PROGRAM HEADER IS THE INTERFACE BETWEEN
25         ; THE DIAGNOSTIC PROGRAM AND THE SUPERVISOR.
26         ; -
27
28 002000  POINTER BGNSW,BGNSFT,BGNAU,BGNDU,BGNRPT
29 002000  HEADER  CVTSB,C,0,655.,0
   002000  L$NAME::          ;DIAGNOSTIC NAME
   002000      103        .ASCII /C/
   002001      126        .ASCII /V/
   002002      124        .ASCII /T/
   002003      123        .ASCII /S/
   002004      102        .ASCII /B/
   002005      000        .BYTE  0
   002006      000        .BYTE  0
   002007      000        .BYTE  0
   002010  L$REV::          ;REVISION LEVEL
   002010      103        .ASCII /C/
   002011  L$DEPO::        ;0
   002011      060        .ASCII /O/
   002012  L$UNIT::        ;NUMBER OF UNITS
   002012  000000        .WORD  0
   002014  L$TIML::        ;LONGEST TEST TIME
   002014  001217        .WORD  655.
   002016  L$HPCP::        ;PTR. TO H.W. QUES.
   002016  101322        .WORD  L$HARD
   002020  L$SPCP::        ;PTR. TO S.W. QUES.
   002020  101454        .WORD  L$SOFT
   002022  L$HPTP::        ;PTR. TO DEF. H.W. PTABLE
   002022  002156        .WORD  L$HW
   002024  L$SPTP::        ;PTR. TO S.W. PTABLE
   002024  002166        .WORD  L$SW
   002026  L$LADP::        ;DIAG. END ADDRESS
   002026  102004        .WORD  L$LAST
   002030  L$STA::        ;RESERVED FOR APT STATS
   002030  000000        .WORD  0
   002032  L$CO::         .WORD  0
   002032  000000
   002034  L$DTYP::        ;DIAGNOSTIC TYPE
   002034  000000        .WORD  0
   002036  L$APT::        ;APT EXPANSION
   002036  000000        .WORD  0
   002040  L$DTP::        ;PTR. TO DISPATCH TABLE
   002040  002124        .WORD  L$DISPATCH
   002042  L$PRIO::       ;DIAGNOSTIC RUN PRIORITY

```

TSV2 - PROGRAM HEADER MACRO M1113 14-JUN-84 15:55  
 PROGRAM HEADER

SEQ 0021

002042	000000		.WORD	0	
002044		L\$ENVI::	.WORD	0	;FLAGS DESCRIBE HOW IT WAS SETUP
002044	000000		.WORD	0	
002046		L\$EXP1::	.WORD	0	;EXPANSION WORD
002046	000000		.WORD	0	
002050		L\$MREV::	.WORD	0	;SVC REV AND EDIT #
002050	003		.BYTE	C\$REVISION	
002051	003		.BYTE	C\$EDIT	
002052		L\$EF::	.WORD	0	;DIAG. EVENT FLAGS
002052	000000		.WORD	0	
002054	000000		.WORD	0	
002056		L\$SPC::	.WORD	0	
002056	000000		.WORD	0	
002060		L\$DEVP::	.WORD	L\$DVTYP	; POINTER TO DEVICE TYPE LIST
002060	003402		.WORD	L\$DVTYP	
002062		L\$REPP::	.WORD	L\$RPT	;PTR. TO REPORT CODE
002062	022620		.WORD	L\$RPT	
002064		L\$EXP4::	.WORD	0	
002064	000000		.WORD	0	
002066		L\$EXPS::	.WORD	0	
002066	000000		.WORD	0	
002070		L\$AUT::	.WORD	L\$AU	;PTR. TO ADD UNIT CODE
002070	022306		.WORD	L\$AU	
002072		L\$DUT::	.WORD	L\$DU	;PTR. TO DROP UNIT CODE
002072	022404		.WORD	L\$DU	
002074		L\$LUN::	.WORD	0	;LUN FOR EXERCISERS TO FILL
002074	000000		.WORD	0	
002076		L\$DESP::	.WORD	L\$DESC	;PTR. TO DIAG. DESCRIPTION
002076	003410		.WORD	L\$DESC	
002100		L\$LOAD::	EMT	E\$LOAD	;GENERATE SPECIAL AUTOLOAD EMT
002100	104035		EMT	E\$LOAD	
002102		L\$ETP::	.WORD	0	;PTR. TO ERR TBL
002102	000000		.WORD	0	
002104		L\$ICP::	.WORD	L\$INIT	;PTR. TO INIT CODE
002104	021512		.WORD	L\$INIT	
002106		L\$CCP::	.WORD	L\$CLEAN	;PTR. TO CLEAN-UP CODE
002106	022572		.WORD	L\$CLEAN	
002110		L\$ACP::	.WORD	L\$AUTO	;PTR. TO AUTO CODE
002110	022512		.WORD	L\$AUTO	
002112		L\$PRT::	.WORD	L\$PROT	;PTR. TO PROTECT TABLE
002112	021502		.WORD	L\$PROT	
002114		L\$TEST::	.WORD	0	;TEST NUMBER
002114	000000		.WORD	0	
002116		L\$DLY::	.WORD	0	;DELAY COUNT
002116	000000		.WORD	0	
002120		L\$HIME::	.WORD	0	;PTR. TO HIGH MEM
002120	000000		.WORD	0	

.SBTTL DISPATCH TABLE

31  
32  
33  
34  
35  
36  
37  
38

\*\*\*  
; THE DISPATCH TABLE CONTAINS THE STARTING ADDRESS OF EACH TEST.  
; IT IS USED BY THE SUPERVISOR TO DISPATCH TO EACH TEST.  
\*\*

002122 000014  
002124 023402  
002126 024366  
002130 026360  
002132 031754  
002134 034544  
002136 040336  
002140 050450  
002142 051730  
002144 062556  
002146 066626  
002150 074470  
002152 077642

DISPATCH 12  
.WORD 12  
L#DISPATCH:;  
.WORD T1  
.WORD T2  
.WORD T3  
.WORD T4  
.WORD T5  
.WORD T6  
.WORD T7  
.WORD T8  
.WORD T9  
.WORD T10  
.WORD T11  
.WORD T12



```
40 .SBTTL DEFAULT HARDWARE P TABLE
41
42 ;**
43 ; THE DEFAULT HARDWARE P-TABLE CONTAINS DEFAULT VALUES OF
44 ; THE TEST-DEVICE PARAMETERS. THE STRUCTURE OF THIS TABLE
45 ; IS IDENTICAL TO THE STRUCTURE OF THE RUN-TIME P TABLE.
46 ;
47 002154 BGNHW DFPTBL ;DEFAULT HARD-P-TABLE
   002154 000003 .WORD L10000-L$HW/2
   002156 L$HW::
   002156 DFPTBL::
48
49 002156 172520 .WORD 172520 ; 1ST (OF 2) REGISTERS.
50 002160 000224 .WORD 224 ; INTERRUPT VECTOR
51 002162 000200 .WORD PRI04 ; INTERRUPT PRIORITY.
52 002164 ENDPHW
   002164 L10000:
```

```

54          .SBTTL  SOFTWARE P-TABLE
55
56          ;**
57          ; THE SOFTWARE P-TABLE CONTAINS THE VALUES OF THE PROGRAM
58          ; PARAMETERS THAT CAN BE CHANGED BY THE OPERATOR.
59          ;--
60 002164          BGNSW  SFPTBL
   002164 000004    .WORD  L10001-L$SW/2
   002166          L$SW::
   002166          SFPTBL::
61
62 002166 000000    TRANSTST:: .WORD  0      ; ENABLE TEST OF TRANSPORT(S) IF =1
63 002170 000000    NOITS::   .WORD  0      ; INHIBIT ITERATION OPTION.
64                                     ; ... 0 = ITERATE.
65                                     ; ...NZ = INHIBIT ITERATE.
66 002172 000017    LERRMAX::  .WORD  15.    ; LOCAL (PER TEST) ERROR LIMIT
67 002174 000310    GERRMAX::  .WORD  200.   ; GLOBAL (PER UNIT) ERROR LIMIT
68 002176          ENDSW
   002176          L10001:
69
70 002176          ENDMOD

```

7  
8  
13  
19  
20 002176  
002176  
21  
22  
23  
24  
25  
26  
27  
28  
32 002176

.TITLE TSV3 - GLOBAL AREAS  
.SBTTL GLOBAL EQUATES SECTION

BGNMOD TSV3

TSV3::

.SBTTL GLOBAL EQUATES SECTION

;;  
; THE GLOBAL EQUATES SECTION CONTAINS PROGRAM EQUATES THAT  
; ARE USED IN MORE THAN ONE TEST.  
;

EQUALS ; GET STANDARD EQUATES.

; BIT DIFINITIONS

100000	BIT15== 100000
040000	BIT14== 40000
020000	BIT13== 20000
010000	BIT12== 10000
004000	BIT11== 4000
002000	BIT10== 2000
001000	BIT09== 1000
000400	BIT08== 400
000200	BIT07== 200
000100	BIT06== 100
000040	BIT05== 40
000020	BIT04== 20
000010	BIT03== 10
000004	BIT02== 4
000002	BIT01== 2
000001	BIT00== 1

001000	BIT9== BIT09
000400	BIT8== BIT08
000200	BIT7== BIT07
000100	BIT6== BIT06
000040	BIT5== BIT05
000020	BIT4== BIT04
000010	BIT3== BIT03
000004	BIT2== BIT02
000002	BIT1== BIT01
000001	BIT0== BIT00

; EVENT FLAG DEFINITIONS  
; EF32:EF17 RESERVED FOR SUPERVISOR TO PROGRAM COMMUNICATION

000040	EF.START== 32.	; START COMMAND WAS ISSUED
000037	EF.RESTART== 31.	; RESTART COMMAND WAS ISSUED
000036	EF.CONTINUE== 30.	; CONTINUE COMMAND WAS ISSUED
000035	EF.NEW== 29.	; A NEW PASS HAS BEEN STARTED
000034	EF.PWR== 28.	; A POWER-FAIL/POWER-UP OCCURRED

; PRIORITY LEVEL DEFINITIONS

```
000340      PRI07.. 340
000300      PRI06.. 300
000240      PRI05.. 240
000200      PRI04.. 200
000140      PRI03.. 140
000100      PRI02.. 100
000040      PRI01.. 40
000000      PRI00.. 0
```

:OPERATOR FLAG BITS

```
00004      EVL..      4
000010     LOT..     10
000020     ADR..     20
000040     IDU..     40
000100     ISR..    100
000200     UAM..    200
000400     BOE..    400
001000     PNT..   1000
002000     PRI..   2000
004000     IXE..   4000
010000     IBE..  10000
020000     IER..  20000
040000     LOE..  40000
100000     MOE.. 100000
```

33  
34 002176

```
000250
177572
177574
177576
172516
```

```
KT11 ..
SBTTL MEMORY MANAGEMENT DEFINITIONS
;*KT11 VECTOR ADDRESS
MMVEC= 250
;*KT11 STATUS REGISTER ADDRESSES
SR0= 177572
SR1= 177574
SR2= 177576
SR3= 172516
. IF NB
;*USER "I" PAGE DESCRIPTOR REGISTERS
UIPDR0= 177600
UIPDR1= 177602
UIPDR2= 177604
UIPDR3= 177606
UIPDR4= 177610
UIPDR5= 177612
UIPDR6= 177614
UIPDR7= 177616
. IF NB
;*USER "D" PAGE DESCRIPTOR REGISTORS
UDPDR0= 177620
UDPDR1= 177622
UDPDR2= 177624
UDPDR3= 177626
UDPDR4= 177630
UDPDR5= 177632
UDPDR6= 177634
UDPDR7= 177636
.ENDC
```

:DEFINE MEMORY MANAGEMENT REGISTERS

;\*USER "I" PAGE ADDRESS REGISTERS

UIPAR0= 177640  
UIPAR1= 177642  
UIPAR2= 177644  
UIPAR3= 177646  
UIPAR4= 177650  
UIPAR5= 177652  
UIPAR6= 177654  
UIPAR7= 177656

.IF NB

;\*USER "D" PAGE ADDRESS REGISTERS

UDPAR0= 177660  
UDPAR1= 177662  
UDPAR2= 177664  
UDPAR3= 177666  
UDPAR4= 177670  
UDPAR5= 177672  
UDPAR6= 177674  
UDPAR7= 177676

.ENDC

.ENDC

.IF NB

;\*SUPERVISOR "I" PAGE DESCRIPTOR REGISTERS

SIPDR0= 172200  
SIPDR1= 172202  
SIPDR2= 172204  
SIPDR3= 172206  
SIPDR4= 172210  
SIPDR5= 172212  
SIPDR6= 172214  
SIPDR7= 172216

.IF NB

;\*SUPERVISOR "D" PAGE DESCRIPTOR REGISTERS

SOPDR0= 172220  
SOPDR1= 172222  
SOPDR2= 172224  
SOPDR3= 172226  
SOPDR4= 172230  
SOPDR5= 172232  
SOPDR6= 172234  
SOPDR7= 172236

.ENDC

;\*SUPERVISOR "I" PAGE ADDRESS REGISTERS

SIPAR0= 172240  
SIPAR1= 172242  
SIPAK2= 172244  
SIPAR3= 172246  
SIPAR4= 172250  
SIPAR5= 172252  
SIPAR6= 172254  
SIPAR7= 172256

.IF NB

;\*SUPERVISOR "D" PAGE ADDRESS REGISTERS

SOPAR0= 172260  
SOPAR1= 172262  
SOPAR2= 172264  
SOPAR3= 172266

```

SDPAR4= 172270
SDPAR5= 172272
SDPAR6= 172274
SDPAR7= 172276
.ENDC
.ENDC
;=KERNEL "I" PAGE DESCRIPTOR REGISTERS
172300 KIPDR0= 172300
172302 KIPDR1= 172302
172304 KIPDR2= 172304
172306 KIPDR3= 172306
172310 KIPDR4= 172310
172312 KIPDR5= 172312
172314 KIPDR6= 172314
172316 KIPDR7= 172316
.IF NB
;=KERNEL "D" PAGE
DESCRIPTOR REGISTERS
KDPDR0= 172320
KDPDR1= 172322
KDPDR2= 172324
KDPDR3= 172326
KDPDR4= 172330
KDPDR5= 172332
KDPDR6= 172334
KDPDR7= 172336
.ENDC
;=KERNEL "I" PAGE ADDRESS REGISTERS
172340 KIPAR0= 172340
172342 KIPAR1= 172342
172344 KIPAR2= 172344
172346 KIPAR3= 172346
172350 KIPAR4= 172350
172352 KIPAR5= 172352
172354 KIPAR6= 172354
172356 KIPAR7= 172356
.IF NB
;=KERNEL "D" PAGE ADDRESS REGISTERS
KDPAR0= 172360
KDPAR1= 172362
KDPAR2= 172364
KDPAR3= 172366
KDPAR4= 172370
KDPAR5= 172372
KDPAR6= 172374
KDPAR7= 172376
.ENDC

```

```

39          .SBTTL  TSV05 REGISTER AND PACKET DEFINITIONS
40
41          ;
42          ; SOME GENERAL EQUATES.
43          ;
44
45          000004  ERRVEC==      4          ; POINTER TO ERROR VECTOR FOR BUS TIME OUT.
46          000060  TTIVEC==     60          ; INTERRUPT VECTOR FOR CONSOLE INPUT
47          177560  TTICSR==    177560       ; BUS ADDRESS OF CONSOLE INPUT
48          177562  TTIBFR==    177562       ; CONSOLE INPUT DATA BUFFER
49          177520  BDVPCR==    177520       ; BDV11 PAGE CONTROL REGISTER
50
51          ;
52          ; BIT DEFINITIONS FOR TSSR REGISTER
53          ;
54
55          100000  SC=      BIT15          ; SPECIAL CONDITION
56          040000  BIE=     BIT14          ; BUS INTERFACE ERROR
57          020000  SCE=     BIT13          ; SANITY CHECK ERROR
58          010000  RMR=     BIT12          ; MODIFICATION REFUSED
59          004000  NXM=     BIT11          ; NONEXISTANT MEMORY ERROR
60          002000  NBA=     BIT10          ; NEED BUFFER ADDRESS
61          001400  HIADDR= BIT9:BIT8       ; EXTENDED ADDRESS BITS
62          000200  SSR=     BIT7           ; SUB SYSTEM READY
63          000100  OFL=     BIT6           ; OFF LINE BIT
64          000060  FATERR= BIT4:BIT5       ; FATAL TERMINATION ERROR CODES
65          000016  TERCLS= BIT3:BIT2:BIT1  ; TERMINATION CODES
66
67          ;
68          ;
69          ; BIT DEFINITIONS FOR EXTENDED STATUS REGISTER 0
70          ; (XST0)
71          ;
72          ;
73
74          100000  XSOTMK= BIT15          ; TAPE MARK DETECTED
75          040000  XSORLS= BIT14          ; RECORD LENGTH SHORT
76          020000  XSOLET= BIT13          ; LOGICAL END OF TAPE
77          010000  XSORLL= BIT12          ; RECORD LENGTH LONG
78          004000  XSOWLE= BIT11          ; WRITE LOCK ERROR
79          002000  XSONEF= BIT10          ; NON EXECUTABLE FUNCTION
80          001000  XSOILC= BIT9           ; ILLEGAL COMMAND
81          000400  XSOILA= BIT8           ; ILLEGAL ADDRESS
82          000200  XSOMOT= BIT7          ; TAPE IN MOTION
83          000100  XSOONL= BIT6          ; TRANSPORT ON LINE
84          000040  XSOIE=  BIT5          ; INTERRUPT ENABLE
85          000020  XSOVCK= BIT4          ; VOLUME CHECK BIT
86          000010  XSOPED= BIT3          ; PHASE ENCODED DRIVE
87          000004  XSOMLK= BIT2          ; WRITE LOCKED
88          000002  XS0BOT= BIT1          ; BEGINNING OF TAPE
89          000001  XS0EOT= BIT0          ; END OF TAPE

```

```

91          ;*
92          ;BIT DEFINITIONS FOR EXTENDED STATUS REGISTER 1
93          ;(XST1)
94          ;-
95          100000 X1.DLT = BIT15          ;DATA LATE
96          040000 X1.SPARE= BIT14         ;NOT USED
97          020000 X1.COR = BIT13         ;CORRECTABLE DATA ERROR
98          017375 X1.MBZ = BIT12*BIT11*BIT10*BIT9*BIT7*BIT6*BIT5*BIT4*BIT3*BIT2*BIT0 ;ALWAYS 0
99          000400 X1.RBP = BIT8          ;READ BUS PARITY ERROR
100         000002 X1.UNC = BIT1          ;UNCORRECTABLE DATA OR HARD ERROR
101
102          ;*
103          ;BIT DEFINITIONS FOR EXTENDED STATUS REGISTER 2
104          ;(XST2)
105          ;-
106         100000 X2.OPM = BIT15         ;OPERATION IN PROGRESS (TAPE MOVING)
107         040000 X2.RCE = BIT14         ;RAM CHECKSUM ERROR
108         035400 X2.SPARE= BIT13*BIT12*BIT11*BIT9*BIT8 ;NOT USED BY TSV05 (ALWAYS=0)
109         002000 X2.WCF = BIT10        ;WRITE CLOCK FAILURE (FIFO NOT EMPTIED BY TRANSPORT)
110         000200 X2.EXTF = BIT7        ;IF WRITE CHAR CMD THEN = EXTENDED FEATURES ENABLED
111         000100 X2.BUFE = BIT6        ;IF WRITE CHAR CMD THEN = BUFFERING ENABLED
112         000077 X2.REV = 000077      ;IF WRITE CHAR CMD THEN = MICROCODE REVISION LEVEL
113         000007 X2.UNIT = BIT2*BIT1*BIT0 ;IF GET STATUS THEN = CURRENTLY SELECTED UNIT NO.
114
115          ;*
116          ;BIT DEFINITIONS FOR EXTENDED STATUS REGISTER 3
117          ;(XST3)
118          ;-
119         177400 X3.MDE = 177400      ;MICRO-DIAGNOSTIC ERROR CODE
120         000200 X3.SPARE= BIT7        ;NOT USED BY TSV05
121         000100 X3.OPI = BIT6        ;OPERATION INCOMPLETE
122         000040 X3.REV = BIT5        ;REVERSE
123         000020 X3.TRF = BIT4        ;TRANSPORT RESPONSE FAILURE
124         000010 X3.DCK = BIT3        ;DENSITY CHECK
125         000006 X3.MBZ =BIT2*BIT1    ;NOT USED ALWAYS 0
126         000001 X3.RIB = BIT0        ;REVERSE INTO BOT
127
128          ;*
129          ;BIT DEFINITIONS FOR EXTENDED STATUS REGISTER 4
130          ;(XST4)
131          ;-
132         100000 X4.HSP = BIT15         ;HIGH SPEED
133         040000 X4.RCE = BIT14         ;RETRY COUNT EXCEEDED
134         020000 X4.TSM = BIT13        ;TRANSPORT SPECIAL MODE
135         017400 X4.MBZ = BIT12*BIT11*BIT10*BIT9*BIT8 ;NOT USED ALWAYS 0
136         000377 X4.WRC = 000377      ;WRITE RETRY COUNT FIELD
137
138          ;*
139          ;
140          ;TSSR TERMINATION CODES (BIT 0-2)
141          ;
142          ;-
143
144         000006 TSREJ= 3*2           ;COMMAND REJECTED
145         000006 UNREC= 6            ;UNRECOVERABLE ERROR

```



```

147      ;*
148      ;
149      ;DEVICE REGISTER OFFSETS
150      ;
151      ;
152      ;
153      000000      TSBA== 0
154      000000      TSDB== 0          ;TSDB/TSBA REGISTER
155      000001      TSBAH== 1
156      000001      TSDBH== 1        ;TSDB/TSBA REGISTER HIGH BYTE
157      000002      TSSR== 2         ;TSSR REGISTER
158      000003      TSSRH== 3        ;TSSR REGISTER HIGH BYTE
159      ;
160      ;*
161      ; TSDB ADDRESS BIT DEFINITIONS
162      ;
163      000003      A1716 = BIT1+BIT0 ;ADDRESS BITS 17:16 ARE IN 1:0
164      ;
165      ;*
166      ; COMMAND DEFINITIONS
167      ;-
168      000017      P.GETSTAT      = 17 ;GET STATUS
169      000013      P.INIT        = 13 ;INITIALIZE
170      000012      P.CONTROL     = 12 ;CONTROL COMMANDS
171      000011      P.FORMAT      = 11 ;FORMAT
172      000010      P.POSITION    = 10 ;POSITION
173      000006      P.WRTSUB      = 6  ;SUBSYSTEM WRITE
174      000005      P.WRITE       = 5  ;WRITE
175      000004      P.WRTCHAR     = 4  ;WRITE CHARACTERISTICS
176      000001      P.READ        = 1  ;READ
177      ;
178      ;*
179      ; COMMAND PACKET HEADER WORD BIT DEFINITIONS
180      ;-
181      100000      P.ACK          = BIT15 ;BUFFER AVAIL FOR CONTROLLER
182      040000      P.CVC         = BIT14 ;CLEAR VOLUME CHECK
183      020000      P.OPP         = BIT13 ;REVERSE SEQUENCE OF DATA BITS
184      010000      P.SMB         = BIT12 ;SWAP BYTES IN MEMORY
185      007400      P.MODE        = BIT11!BIT10!BIT9!BIT8 ;EXTENDED COMMAND MODE FIELD
186      000200      P.IE          = BIT7  ;INTERRUPT ENABLE
187      000140      P.FMT         = BIT6!BIT5 ;PACKET HEADER TYPE (ALWAYS=0)
188      000037      P.CMD         = 37   ;MAJOR COMMAND FIELD
189      ;
190      ;*
191      ; CONTROL COMMAND MODE CODES
192      ;-
192      000000      PC.RELEASE    = 0*256. ;RELEASE BUFFER
193      000400      PC.REWIND     = 1*256. ;REWIND
194      001000      PC.NOOP       = 2*256. ;NO-OP
195      002000      PC.IEREW      = 4*256. ;REWIND IMMEDIATE INTERRUPT
196      002400      PC.ERASE      = 5*256. ;SECURITY ERASE

```

```

198      ;*
199      ; CONTROLLER RAM DEFINITIONS
200      ;-
201      000167      RMCHBEG = 167      ; CHARACTERISTICS IO DATA BEGIN RAM ADDRESS
202      000200      RMCHEND = 200      ; CHARACTERISTICS IO DATA END RAM ADDRESS
203      000201      RMPKTBEG = 201      ; COMMAND PACKET BEGIN RAM ADDRESS
204      000210      RMPKTEND = 210      ; COMMAND PACKET END RAM ADDRESS
205      000215      RMMSGBEG = 215      ; MESSAGE BUFFER BEGIN RAM ADDRESS
206      000234      RMMSGEND = 234      ; MESSAGE BUFFER END RAM ADDRESS
207      ;*
208      ;
209      ; REGISTER DEFINITIONS IN THE MESSAGE BUFFER
210      ;
211      ;-
212
213      000006      XST0 = 6      ; EXTENDED STATUS REGISTER 0 (WORD 4)
214      000010      XST1 = 8      ; EXTENDED STATUS REGISTER 1 (WORD 5)
215      000012      XST2 = 10      ; EXTENDED STATUS REGISTER 2 (WORD 6)
216      000014      XST3 = 12      ; EXTENDED STATUS REGISTER 3 (WORD 7)
217      000016      XST4 = 14      ; EXTENDED STATUS REGISTER 4 (WORD 8)
218
219      ;*
220      ;
221      ; OFFSETS TO WORD LOCATIONS IN PACKET DEFINITIONS
222      ;
223      ;-
224
225      000002      PKLOW = 2      ; LOW ORDER CHARACTERISTIC DATA POINTER
226      000004      PKHI = 4      ; HIGH ORDER CHARACTERISTIC DATA POINTER
227      000006      PKBCNT = 6      ; NUMBER OF BYTES IN DATA PACKET
228
229      000010      EXBCNT = 10      ; NUMBER OF BYTES IN EXTENDED DATA PACKET
230
231      ;*
232      ; DATA PACKET OFFSETS FOR WRITE SUBSYSTEM COMMAND
233      ;-
234      000000      BSELO = 0      ; BYTE 0
235      000001      BSEL1 = 1      ; BYTE 1
236      000002      SEL2 = 2      ; WORD 2
237      000004      SELDATA = 4      ; WORD 3

```

```

239      ;*
240      ;BSEL0 SELECT CODES FOR WRITE SUBSYSTEM COMMAND
241      ;-
242      000000      PW.NOP          = 0          ;NO-OP
243      000001      PW.RDRAM       = 1          ;READ RAM
244      000002      PW.WTRAM       = 2          ;WRITE RAM
245      000003      PW.RFIFO       = 3          ;READ FIFO
246      000004      PW.WFIFO       = 4          ;WRITE FIFO
247      000005      PW.ROSTAT      = 5          ;READ STATUS
248      000006      PW.WCTL        = 6          ;WRITE TAPE CONTROL
249      000007      PW.WFMT        = 7          ;WRITE TAPE FORMAT
250      000010      PW.WMISC       = 10         ;WRITE MISCELLANEOUS
251      000011      PW.WNPR        = 11         ;WRITE NPR CONTROL
252      000020      PW.D22         = 20         ;DO MICROTEST 22
253      000021      PW.D11         = 21         ;DO MICROTEST 11
254      000022      PW.D13         = 22         ;DO MICROTEST 13
255      000023      PW.NO1311      = 23         ;DISABLE MICROTEST 11 AND 13
256      000024      PW.RDXT        = 24         ;READ EXT. TAPE STATUS (NOT SUPPORTED BY ALL TRANSPORTS
257
258      ;*
259      ;BSEL1 CODES FOR WRITE TAPE CONTROL
260      ;-
261      000200      WC.IFAD         = BIT7       ;IFAD - FORMATTER ADDRESS
262      000100      WC.IOTAD        = BIT6       ;ITAD0 - TRANSPORT ADDRESS BIT 0
263      000040      WC.I1TAD        = BIT5       ;ITAD1 - TRANSPORT ADDRESS BIT 1
264      000020      WC.ISRESV       = BIT4       ;IRESV5 - RESERVED #5
265      000010      WC.IREW         = BIT3       ;IREW - REWIND
266      000004      WC.IRWU         = BIT2       ;IRWU - REWIND AND UNLOAD
267      000002      WC.IFEN         = BIT1       ;IFEN - FORMATTER ENABLE
268      000001      WC.IGO          = BIT0
269
270      ;*
271      ;BSEL1 CODES FOR WRITE FORMAT
272      ;-
273      000200      WF.IHISP         = BIT7       ;IHISP - HIGH SPEED
274      000100      WF.IWRT         = BIT6       ;IWRT - WRITE
275      000040      WF.IREV         = BIT5       ;IREV - REVERSE
276      000020      WF.IWFM         = BIT4       ;IWFM - WRITE FILE MARK
277      000010      WF.IEDIT        = BIT3       ;IEDIT - EDIT
278      000004      WF.IERASE       = BIT2       ;IERASE - ERASE
279      000002      WF.I3RESV       = BIT1       ;IRESV3 - RESERVED #3
280      000001      WF.I4RESV       = BIT0       ;IRESV4 - RESERVED #4
281
282      ;*
283      ;BSEL1 CODES FOR WRITE MISCELLANEOUS SUBCOMMAND
284      ;-
285      000200      MS.EXT           = BIT7       ;INVERT SENSE OF EXTENDED FEATURES SWITCH
286      000020      MS.RSFIFO        = BIT4       ;RESET FIFO AND INPUT PARITY ERRORR
287      000010      MS.RSTAPE        = BIT3       ;RESET TAPE STATUS IN 2 FLIP-FLOPS
288      000006      MS.ATTN          = BIT2:BIT1  ;ATTENTION TRIGGER FIELD
289      000001      MS.RSD           = BIT0       ;RESET TIMER A,B THEN DELAY TIMES IN SEL2

```

```

291      ;
292      ; MS.ATTN SUBCODES
293      ;
294      000000      MSA.NOP = 0*2      ;NO-OP (NOTHING TRIGGERED)
295      000002      MSA.VOL = 1*2      ;SIMULATE ON-LINE/OFF-LINE TRANSITION
296      000004      MSA.NRAM= 2*2      ;FORCE NON-FATAL RAM ERROR (FORCES ERRCODE 54)
297      000006      MSA.FRAME= 3*2     ;FORCE FATAL RAM ERROR (CAUSES SCE TO SET)
298      ;
299      ; WRITE SUBSYSTEM WRITE NPR BSEL1 BIT DEFINITIONS
300      ;
301      000200      NP.IR      = BIT7      ;INTERRUPT REQUEST (0-1 TRANSITION)
302      000100      NP.OUT     = BIT6      ;TAPE DATA DIRECTION OUT (0= IN)
303      000040      NP.LOOP    = BIT5      ;ENABLE TRANSPORT LOOPBACK
304      000020      NP.WRP     = BIT4      ;WRITE CORRECT PARITY (SET=0 TO WRITE WRONG)
305      ;
306      ; READ STATUS MESSAGE BUFFER BIT DEFINITIONS
307      ;
308      ;
309      000200      S2.DIM      = BIT7      ;WORD #9 BYTE 2 DATA IN MISS
310      000100      S2.ILW     = BIT6      ;ILW H
311      000040      S2.OUTRDY   = BIT5      ;OUT RDY H
312      000020      S2.INRDY   = BIT4      ;IN RDY H
313      000010      S2.ATIMR   = BIT3      ;TIMER A FLAG H
314      000004      S2.BTIMR   = BIT2      ;TIMER B FLAG H
315      000003      S2.UNDEF    = BIT1.BITO ;(UNDEFINED)
316      100000      S1.PARIN    = BIT15     ;WORD #8 BYTE 1 PARIN H
317      040000      S1.I2RESV   = BIT14     ;IRESV2
318      020000      S1.I1RESV   = BIT13     ;IRESV1
319      010000      S1.IEOT     = BIT12     ;IEOT L
320      004000      S1.IIDENT   = BIT11     ;IIDENT H
321      002000      S1.ICER     = BIT10     ;ICER H
322      001000      S1.IFMK     = BIT9      ;IFMK H
323      000400      S1.IHER     = BIT8      ;IHER H
324      000200      S0.ISPEED   = BIT7      ;WORD #8 BYTE 0 ISPEED H
325      000100      S0.IRDY     = BIT6      ;IRDY L
326      000040      S0.IONL     = BIT5      ;IONL L
327      000020      S0.ILDP     = BIT4      ;ILDP L
328      000010      S0.IDBY     = BIT3      ;IDBY L
329      000004      S0.IRWD     = BIT2      ;IRWD L
330      000002      S0.IFBY     = BIT1      ;IFBY L
331      000001      S0.IFPT     = BIT0      ;IFPT L

```

```

333             .SBTTL SPECIAL MACROS AND OPDEFS.
334
335             ;+
336             ;SAVE GENERAL REGS 1 TO 5
337             ;-
338
339             .MACRO SAVREG
340             JSR     RS,REGSAV
341             .ENDM
342
343             ;+
344             ; MACRO TO FORCE AN ERROR
345             ;
346             .MACRO FORCERROR TAG,NOTSSR
347             .NLIST
348             .IIF NDF LISTALL, .NLIST
349             .LIST
350             .IF B NOTSSR
351             MOV     TSSR(R5),R1      ;READ TSSR
352             .ENDC
353             MOV     FORCER,FORCER   ;IS FORCER SET? (LEAVE C BIT ALONE)
354             BNE    TAG              ;BR IF YES
355             .NLIST
356             .IIF NDF LISTALL, .LIST
357             .LIST
358             .ENDM
359
360             ;+
361             ; MACRO TO FORCE AN EXIT TO AVOID SECTION ITERATIONS
362             ; WILL EXIT TO A LABEL IF FORCER IS NEGATIVE
363             ; SO TO FORCE ERRORS AND EXIT ON 1 ERROR SET
364             ; FORCER TO 177777
365             ; TO FORCE ERRORS AND ITERATIONS SET FORCER TO 1
366             ;-
367             .MACRO FORCEEXIT TAG
368             .NLIST
369             .IIF NDF LISTALL, .NLIST
370             .LIST
371             MOV     FORCER,FORCER   ;IS FORCER NEGATIVE?
372             BMI    TAG              ;BR IF YES
373             .NLIST
374             .IIF NDF LISTALL, .LIST
375             .LIST
376             .ENDM
377             ;+
378             ; MACRO TO INCREMENT ERROR COUNTS
379             ;-
380             .MACRO NEXT.ERRNO
381             .NLIST
382             ;;;.IIF NDF LISTALL, .NLIST
383             ERRNO=ERRNO+1
384             ;;;.IIF NDF LISTALL, .LIST
385             .LIST
386             .ENDM

```

17,

```
388      ;*
389      ;MACRO TO PERFORM XOR
390      ;
391      ;
392      .MACRO XOR      A,B
393      MOV      A,-(SP)
394      BIC      B,(SP)
395      BIC      A,B
396      BIS      (SP),B
397      .ENDM
398
399      000000      EN=0      ; INITIALIZE ERROR NUMBER
400      .SBTTL FORCER - FORCE ERROR FLAG
401
402      ;
403      ; THE FOLLOWING LOCATIONS MAY BE PATCHED BY THE USER
404      ; TO OBTAIN THE RESULTS DESCRIBED FOR EACH.
405      ;
406
407 002176 000000 FORCER::      0      ; FORCE TYPE ALL HARD ERRORS (THE ONES CALLED
408      ; - BY THE MACRO "IFERROR"). AN ERROR NEED NOT
409      ; - EXIST, JUST ASSUME AND TYPE THE MESSAGE.
```

## .SBTTL GLOBAL DATA SECTION

```

411
412
413      ;**
414      ;THE GLOBAL DATA SECTION CONTAINS DATA THAT ARE USED
415      ;IN MORE THAN ONE TEST.
416      ;--
417
418      ;
419      ;THE FOLLOWING DATA ARE SET FOR EACH UNIT AT INIT TIME.
420      ;SINGLE UNIT DEFAULTS (LISTED) ARE IN THE DEFAULT P-TABLE.
421      ;
422 002200 000000 EPRTSW::      .WORD 0      ;PRINT SWITCH
423 002202 000000 UNITN::      .WORD 0      ;UNIT # UNDER TEST.
424 002204 000000 QVP::        .WORD 0      ;QUICK VERIFY FLAG.
425 002206 000000 CSRADDR::    .WORD 0      ;ADDRESS OF CSR FOR CURRENT DEVICE
426 002210 000224 IVEC::        .WORD 224    ;INTERRUPT VECTOR
427 002212 000200 IPRI::        .WORD PRI04  ;INTERRUPT PRIORITY.
428 002214 000000 TSTCNT::    .WORD 0      ;NUMBER OF TESTS RUN IN THIS PASS
429 002216 000000 LOOPCNT::   .WORD 0      ;REMAINING ITERATION COUNT FOR TEST
430 002220 000000 DEVCNT::    .WORD 0      ;NUMBER OF DEVICE UNDER TEST
431 002222 000000 FATFLG::    .WORD 0      ;SET IF FATAL ERROR IS DETECTED IN TEST
432 002224 000000 INTRECV::   .WORD 0      ;SET IF TAPE INTERRUPT WAS RECEIVED
433 002226 000000 EXTFEA::    .WORD 0      ;EXTENDED FEATURES SOFTWARE SW 0-OFF;1-ON
434 002230 000000 BENBSW::    .WORD 0      ;BUFFER ENABLE SWITCH SW 0-OFF;1-ON
435 002232 000000 EXPD::      .WORD 0      ;EXPECTED RAM DATA FOR PRAMPKT ROUTINE
436 002234 000000 RECV::      .WORD 0      ;RECEIVED RAM DATA FOR PRAMPKT ROUTINE
437 002236 000000 ERRMI::     .WORD 0      ;HIGH ADDRESS MEMORY ERROR
438 002240 000000 ERRLO::     .WORD 0      ;LOW ADDRESS MEMORY ERROR
439 002242 000000 RAMDATA::   .BLKW 16.    ;DATA READ FROM RAM PACKET OR MESSAGE BUF AREA
440 002302 000000 RAMSIZ::   .WORD 0      ;RAM DATA SIZE FOR PRAMPKT ROUTINE
441 002304 000000 RCVHIADD:: .WORD 0      ;RECEIVED BUFFER HIGH ADDRESS
442 002306 000000 RCVLOADD:: .WORD 0      ;RECEIVED BUFFER LOW ADDRESS
443 002310 000000 COUNT::    .WORD 0      ;TEST COUNT PATTERN
444 002312 000000 DATA::    .WORD 0      ;TEST DATA
445 002314 000000 TSTFLAG::  .WORD 0      ;TEST FLAG WORD
446 002316 000000 TSTPTR::   .WORD 0      ;TSTBLK POINTER
447 002320 000000 PRMNO::    .WORD 0      ;PRINT ROUTINE TEMP
448 002322 000000 EXPMSG::   .BLKB 100.   ;EXPECTED MESSAGE BUFFER DATA
449 002466 000000 RECMSG::   .BLKB 100.   ;RECEIVED MESSAGE BUFFER DATA
450 002632 000000 TMPBFR::   .BLKB 80.    ;TEMPORARY STORAGE FOR PRINT

```

```

452          .SBTTL  TSTBLK - TEST DATA TABLE
453
454          ;*
455          ; THIS TABLE CONTAINS TEST DATA USED IN SEVERAL TESTS
456          ;
457          ; IN SEQUENCE THE DATA IS:
458          ;
459          ;
460          ;     ALL ZEROS
461          ;     ALL ONES
462          ;     WALKING ONES
463          ;     WALKING ZEROS
464          ;     ALTERNATING ONES AND ZEROS
465          ;
466          ; -
467
468 002752
469 002752 000000
470 002754 177777
471 002756 000001
472 002760 000002
473 002762 000004
474 002764 000010
475 002766 000020
476 002770 000040
477 002772 000100
478 002774 000200
479 002776 000400
480 003000 001000
481 003002 002000
482 003004 004000
483 003006 010000
484 003010 020000
485 003012 040000
486 003014 100000
487 003016 177776
488 003020 177775
489 003022 177773
490 003024 177767
491 003026 177757
492 003030 177737
493 003032 177677
494 003034 177577
495 003036 177377
496 003040 176777
497 003042 175777
498 003044 173777
499 003046 167777
500 003050 157777
501 003052 137777
502 003054 077777
503 003056 125252
504 003060 052525
505          003062

          TSTBLK:
          .WORD 0          ; ALL ZEROS
          .WORD 177777    ; ALL ONES
          .WORD BIT0      ; DATA FOR WALKING ONES
          .WORD BIT1
          .WORD BIT2
          .WORD BIT3
          .WORD BIT4
          .WORD BIT5
          .WORD BIT6
          .WORD BIT7
          .WORD BIT8
          .WORD BIT9
          .WORD BIT10
          .WORD BIT11
          .WORD BIT12
          .WORD BIT13
          .WORD BIT14
          .WORD BIT15
          .WORD †CBIT0    ; DATA FOR WALKING ZEROS
          .WORD †CBIT1
          .WORD †CBIT2
          .WORD †CBIT3
          .WORD †CBIT4
          .WORD †CBIT5
          .WORD †CBIT6
          .WORD †CBIT7
          .WORD †CBIT8
          .WORD †CBIT9
          .WORD †CBIT10
          .WORD †CBIT11
          .WORD †CBIT12
          .WORD †CBIT13
          .WORD †CBIT14
          .WORD †CBIT15
          .WORD 125252    ; ALTERNATING ONES, ZEROS
          .WORD 052525    ; ALTERNATING ONES, ZERO OPPOSITE FROM ABOVE

          TBLEND = .

```



```

507          .SBTTL GLOBAL ENVIRONMENT STORAGE
508
509          ;STORAGE FOR DEVICE REGISTERS
510          ;
511 003062 000000 100000 000000 DUMMY: 0,100000,0,0 ;DUMMY DEVICE REGISTERS..
512 003072 000000 000000 000000      0,0,0,0,0,0,0,0
513          ;...FOR MULTI-UNIT CHECKOUT.
514
515 003112 000000 DUFFLG::      .WORD 0 ;"DROPPED UNIT FLAG
516          ;INHIBITS CODE IN "CLEAN UP"
517 003114 000000 NODEV::      .WORD 0 ;FLAG TO SAY NO DEVICE.
518
519 003116 000000 TEMP1::      .WORD 0 ;SOME TEMP LOCATIONS.
520 003120 000000 TEMP2::      .WORD 0
521 003122 000000 XXCOMM::     .WORD 0 ;XXDP+ COMM BLOCK POINTER.
522 003124 000000 FREE::      .WORD 0 ;1ST FREE MEMORY ADDRESS
523 003126 000000 FRESIZ::     .WORD 0 ;...AND SIZE (IN WORDS).
524 003130 000000 FREEMI: .WORD 0 ;LAST WORD IN FREE SPACE
525 003132 000000 KTFLG::      .WORD 0 ;KT11, MEM AVAIL FLAG
526          ;- .WORD 0 = <24K OR NO KT
527          ;- NZ = >24K AND KT.
528 003134 000000 KTENABLE::   .WORD 0 ;SET BY TEST ROUTINES TO FLAG >28K UNDER TEST
529 003136 000000 NXMFLG::    .WORD 0 ;SET IF WE CAN TEST CLEARED OTHERWISE
530 003140 000000 NXMLO::     .WORD 0 ;NXM LO ADDRESS BITS
531 003142 000000 NXMHI::     .WORD 0 ;NXM HI ADDRESS BITS FOR DAL'S 16 21
532 003144 000000 T23A:      .WORD 0 ;11/23A FLAG
533 003146 000000 T23B:      .WORD 0 ;11/23B FLAG
534 003150 000000 T38FIG::    .WORD 0 ;TEST 38 FLAG +0
535 003152 002000 PST32W::    .WORD 2000 ;32W BLOCK ADDRESS FOR 32K START
536 003154 000000 SIFLAG::    .WORD 0
537 003156 000000 BADDAT:    .WORD 0 ;ACTUAL DATA
538 003160 000000 GDDAT::    .WORD 0 ;EXPECTED DATA
539 003162 000000 LOOPFL::   .WORD 0
540 003164 CTAB::      .WORD 0 ;CONFIGURATION TABLES.
541 003164 CTABM::    .WORD 0 ;CONFIG WORK
542 003166 .WORD 0
543 003170 .WORD 0
544 003172 .WORD 0
545 003174 177777 .WORD -1 ;END OF MEM TABLE.
546 003176
547          CTABE::
548          ;ERROR STATISTICS TABLE (1 WORD PER UNIT), 64 UNITS MAX:
549          ;
550          ; 0 = UNIT NOT TESTED
551          ; 100000 = UNIT ONLINE, NO ERRORS
552          ; 10XXXX = UNIT ONLINE, ENCOUNTERED XXXX ERRORS
553          ; 160000 = UNIT DROPPED, NON-EXISTENT DEVICE REGISTER
554          ; 160001 = UNIT DROPPED, NOT IDLE AT START
555          ; 14XXXX = UNIT DROPPED, ENCOUNTERED XXXX ERRORS
556 003176 ERTABL:      .BLKW 64.
557 003376 000000 ERTABE:      .WORD 0
558
559 003400 000000 SKIPT:      .WORD 0 ;1=SKIP SUBTEST 0=NO SKIP OF SUBTEST
    
```

```

561 .SBTTL GLOBAL TEXT MESSAGES
562 ;*
563 ; THE GLOBAL TEXT SECTION CONTAINS FORMAT STATEMENTS,
564 ; MESSAGES, AND ASCII INFORMATION THAT ARE USED IN
565 ; MORE THAN ONE TEST.
566 ; -
567 ;*
568 ; NAMES OF DEVICES SUPPORTED
569 ; -
570 003402 DEVTYP <TSV05>
003402 L#DVTYP::
003402 124 123 126 .ASCIZ /TSV05/
.EVEN

571 ;*
579 ; TEST DESCRIPTION
580 ; -
581 DESCRIPT <**** TSV05 LOGIC DIAGNOSTIC - REPLACE M7196 IF ERROR ****>
582 003410 L#DESC::
003410 052 052 052 .ASCIZ /**** TSV05 LOGIC DIAGNOSTIC - REPLACE M7196 IF ERROR ****/
003410 .EVEN

583 ;*
597 ; BIT TO ASCII CONVERSION FOR TSSR REGISTER
598 ; -
599 TSSRBIT:: .WORD 10,20,30,40,50,60,70,80
600 .WORD 90,100,110,120,130,140,150,160
601 003502 003542 003545 003551 10: .ASCIZ 'SC'
602 003522 003603 003607 003613 20: .ASCIZ 'BIE'
603 003542 123 103 000 30: .ASCIZ 'SCE'
604 003545 102 111 105 40: .ASCIZ 'RMR'
605 003551 123 103 105 50: .ASCIZ 'NDM'
606 003555 122 115 122 60: .ASCIZ 'MBA'
607 003561 116 130 115 70: .ASCIZ 'BIT9'
608 003565 116 102 101 80: .ASCIZ 'BIT8'
609 003571 102 111 124 90: .ASCIZ 'SSR'
610 003576 102 111 124 100: .ASCIZ 'OFL'
611 003603 123 123 122 110: .ASCIZ 'BITS'
612 003607 117 106 114 120: .ASCIZ 'BIT4'
613 003613 102 111 124 130: .ASCIZ 'BIT3'
614 003620 102 111 124 140: .ASCIZ 'BIT2'
615 003625 102 111 124 150: .ASCIZ 'BIT1'
616 003632 102 111 124 160: .ASCIZ 'BIT0'
617 003637 102 111 124 .EVEN
618 003644 102 111 124 SFIERR: .ASCIZ 'TSSR ERROR AFTER SOFT INIT'
619 .EVEN
620 003652 124 123 123 SFHERR: .ASCIZ 'TSSR ERROR AFTER BUS RESET'
621 003705 124 123 123 NDR: .ASCIZ / NON-EXISTANT DEVICE REGISTER/
622 003740 040 040 116 NDRX: .ASCIZ /#A ADDRESS; #06/
623 003777 045 101 040 TSSX: .ASCIZ /#A TSBA,TSSR EXP'D; #06#A,#06#N/
624 004020 045 101 040 .ASCIZ /#A TSBA,TSSR REC'D; #06#A,#06/
625 004060 045 101 040 FUSI: .ASCIZ /#A#A/
626 004117 045 116 045 USI: .ASCIZ / UNEXPECTED INTERRUPT/
627 004123 040 040 125 NSI: .ASCIZ / INTERRUPT EXPECTED, NOT RECEIVED/
628 004152 040 040 111 FNOINTR: .ASCII /#A#A/
629 004215 045 116 045 NOINTR: .ASCIZ / NO INTERRUPT WAS GENERATED/
630 004221 040 040 116 IFAULT: .ASCIZ / INTERRUPT FAULT/
631 004256 040 040 111

```

```

632 004300      045      101      040  INTX:  .ASCIZ  /#A CPU PC; #06#A TSBA; #06/
633 004335      040      040      042  NOINIT: .ASCIZ  / "BUS-INIT" DIDN'T INITIALIZE CONTROLLER/
634 004407      040      040      042  NSINIT: .ASCIZ  / "SOFT-INIT" DIDN'T INITIALIZE THE DPU/
635 004457      040      040      042  BRINIT: .ASCIZ  / "BUS-RESET" DIDN'T INITIALIZE THE DPU/
636 004527      000      000      000  NUL:    .ASCIZ  //
637 004530      045      116      000  NULCR:  .ASCIZ  /#N/
638 004533      045      101      040  EXPGOT: .ASCIZ  '#A EXP'D; #06#A, REC'D; #06/
639 004567      045      116      045  EXPGT2: .ASCIZ  /#A EXP'D; #06#A, #06#A REC'D; #0#A, #06/
640 004643      045      101      040  DUAD12: .ASCIZ  /#A REG(W) WRITTEN TO; #06#A REG(R) READ; EXP'D; #06#A, REC'D; #06/
641 004745      122      101      115  PKTRAM: .ASCIZ  'RAM Contents Do Not Match Packet Sent'
642 005013      040      040      103  SCHE:   .ASCIZ  / CONFIG DOESN'T MATCH MFG. MASTER/
643 005056      127      122      111  WRTHSG: .ASCIZ  'WRITE CHARACTERISTICS Failed'
644 005113      124      123      123  WRTERR: .ASCIZ  'TSSR Incorrect After WRITE Command, More Bits Set Than SSR'
645 005206      124      123      123  RDERR:  .ASCIZ  'TSSR Incorrect After READ Command, More Bits Set Than SSR'
646 005300      106      101      124  SCHERR: .ASCIZ  'FATAL ERROR IN SUBTEST - CHECK TAPE,CABLES,TRANSPORT etc.'
647 005372      105      122      122  RETERR: .ASCIZ  'ERROR IN SUBTEST - WRITE DATA RETRY FIVE TIMES FAILED'
648 005460      045      116      045  NOMEM:  .ASCIZ  '#A ***** NO NXM ADDRESS--CANNOT TEST NXM TIMEOUT. *****N'
649 005554      045      116      045  M8186:  .ASCIZ  '#A *****/***** 11/23A SYSTEM *****N'
650 005645      045      116      045  M8189:  .ASCIZ  '#A *****/***** 11/23B SYSTEM *****N'

```

```

651 .EVEN
652 .SBTTL GLOBAL ERROR REPORT SECTION
653
654
655 ;**
656 ; THE GLOBAL ERROR REPORT SECTION CONTAINS THE PRINTB AND PRINTX
657 ; CALLS THAT ARE USED IN MORE THAN ONE TEST.
658 ; ASCII TEXT STRINGS ARE FOUND IN THE GLOBAL TEXT SECTION.
659 ;--

```

```

659 005736      005736      005736      005736      005736      005736      005736      005736
660 005736      013746      003114      005736      012746      003777      005746      012746      000002      005752      010600      005754      104415      005756      062706      000006      005762      004737      005770
661 005762      004737      005770
662 005766      005766      005766      005766      104423

```

```

663
664
665
666
667 005770      005727
668 005772      000000
669 005774      001402
670 005776      004777      177770
671 006002      006002      012746      004530      006006      012746      000001      006012      010600      006014      104415      006016      062706      000004      006022      000207

```

```

;--
BGNMSG  NXRERR          ;NON-EXISTANT DEVICE REGISTER.
NXRERR: PRINTX  @NXRX,NODEV ;NODEV = NEXM ADDRESS.
        MOV     NODEV,-(SP)
        MOV     @NXRX,-(SP)
        MOV     @2,-(SP)
        MOV     SP,R0
        TRAP   C#PNTX
        ADD     @6,SP
        JSR    PC,EXTEND   ; PRINT EXTENSION IF REQUIRED.
        ENDMMSG
L10002: TRAP     C#MSG
;
; THIS ROUTINE APPENDS A UNIQUE EXTENSION (IF REQUIRED)
; TO ANY OF THE ABOVE ERROR SIGNATURES.
;
EXTEND: TST     (PC).
EXTA:   0
        BEQ    1#
        JSR    PC,BEXTA   ; APPEND EXTENSION TEXT.
1#:    PRINTX  @NULCR
        MOV     @NULCR,-(SP)
        MOV     @1,-(SP)
        MOV     SP,R0
        TRAP   C#PNTX
        ADD     @4,SP
        RTS    PC

```

```

674 .SBTTL PRITSSR - PRINT TSSR CONTENTS
675
676 ;*
677 ;
678 ;ROUTINE TO DISPLAY THE CONTENTS, AND BIT DEFINITIONS, OF
679 ;THE TSSR REGISTER. THIS ROUTINE IS NORMALLY CALLED ONLY
680 ;BY A MESSAGE PRINTING ROUTINE
681 ;
682 ;INPUTS:
683 ;
684 ; R1 CONTENTS OF TSSR
685 ;
686 ;SUBORDINATE ROUTINES:
687 ;
688 ; CHKAMB CHECK FOR AMBIGUOUS CONTENTS
689 ;
690 ;-
691
692 PRITSSR:
693 SAVREG ;SAVE GENERAL REGISTERS
694 MOV R1,R4 ;SAVE THE TSSR CONTENTS
695 PRINTB @TSSRFOR,R4 ;PRINT THE CONTENTS OF TSSR
696 MOV R4,-(SP)
697 MOV @TSSRFOR,-(SP)
698 MOV @2,-(SP)
699 MOV SP,R0
700 TRAP C@PNTB
701 ADD @6,SP
702 MOV R4,R0 ;GET TSSR BACK FOR CHKAMB
703 JSR PC,CHKAMB ;ARE CONTENTS AMBIGUOUS ?
704 BCS 5@ ;BRANCH IF NOT
705 PRINTX @AMBTSSR ;SHOW CONTENTS ARE AMBIGUOUS
706 MOV @AMBTSSR,-(SP)
707 MOV @1,-(SP)
708 MOV SP,R0
709 TRAP C@PNTX
710 ADD @4,SP
711 5@: MOV R4,R3 ;CONTENTS OF TSSR
712 BIC @HIADDR!FATERR!TERCLS,R3 ;CLEAR ALL MULTIPLE BIT FIELDS
713 BEQ 20@ ;NO BITS ARE SET
714 MOV @TMPBFR,R2 ;TEMPORARY ASCII BUFFER
715 MOV @TSSRBIT,R1 ;ASCII EQUIVALENT OF BITS
716 10@: TST R3 ;REMAINING BITS TO CONVERT
717 BEQ 15@ ;BRANCH WHEN ALL ARE DONE
718 CLC ;CLEAR CARRY FOR SHIFT
719 ROL R3 ;SHIFT NEXT BIT TO CARRY
720 BCC 13@ ;BRANCH IF BIT NOT SET
721 MOV (R1),R0 ;POINTER TO BIT DEFINITION
722 11@: MOVB (R0),.(R2), ;MOVE ASCII TO BUFFER
723 BNE 11@ ;MOVE ALL BITS
724 MOVB @',,-1(R2) ;INSERT A COMMA TO TERMINATE
725 13@: TST (R1), ;POINT TO NEXT DESCRIPTION
726 BR 10@ ;GET THE REMAINING BITS
727 15@: CLRB -(R2) ;TERMINATE THE LINE
728 PRINTX @TSSDEF,@TMPBFR ;PRINT THE BIT DEFINITIONS
729 MOV @TMPBFR,-(SP)
730 MOV @TSSDEF,-(SP)
    
```

TSV3 - GLOBAL AREAS MACRO M1113 14-JUN-84 15:55  
 PRITSSR - PRINT TSSR CONTENTS

SEQ 0043

	006170	012746	000002		MOV	#2,-(SP)	
	006174	010600			MOV	SP,R0	
	006176	104415			TRAP	C:PNTX	
	006200	062706	000006		ADD	#6,SP	
710							
719	006204	010403		204:	MOV	R4,R3	;GET THE TSSR CONTENTS
720	006206	042703	177761		BIC	#1:CTERCLS,R3	;CLEAR ALL BUT TERMINATION
721	006212	016303	006676		MOV	TCOCOD(R3),R3	;GET THE TERMINATION CODE MEANING
722	006216				PRINTX	#TCOASC,R3	;PRINT THE TERMINATION CODE
	006216	010346			MOV	R3,-(SP)	
	006220	012746	006476		MOV	#TCOASC,-(SP)	
	006224	012746	000002		MOV	#2,-(SP)	
	006230	010600			MOV	SP,R0	
	006232	104415			TRAP	C:PNTX	
	006234	062706	000006		ADD	#6,SP	
723	006240	010403			MOV	R4,R3	;TSSR CONTENTS AGAIN
724	006242	042703	177717		BIC	#1:CFATERR,R3	;CLEAR ALL BUT FATAL TERMINATION
725	006246	001416			BEQ	254	;DON'T PRINT IF ZERO
726	006250	006203			ASR	R3	
727	006252	006203			ASR	R3	
728	006254	006203			ASR	R3	;ALINE TERMINATION CODE FOR INDEX
729	006256	016303	007236		MOV	TSFCOD(R3),R3	;GET THE FATAL TERMINATION CODE
730	006262				PRINTX	#TFCASC,R3	;PRINT THE FATAL TERMINATION CODE
	006262	010346			MOV	R3,-(SP)	
	006264	012746	006537		MOV	#TFCASC,-(SP)	
	006270	012746	000002		MOV	#2,-(SP)	
	006274	010600			MOV	SP,R0	
	006276	104415			TRAP	C:PNTX	
	006300	062706	000006		ADD	#6,SP	
731	006304	042704	176377	254:	BIC	#1:CHIADDR,R4	;CLEAR ALL BUT EXTENDED ADDRESS
732	006310	001411			BEQ	304	;DON'T PRINT IF ZERO
733	006312				PRINTX	#TEXASC,R4	;PRINT THE EXTENDED ADDRESS BITS
	006312	010446			MOV	R4,-(SP)	
	006314	012746	006435		MOV	#TEXASC,-(SP)	
	006320	012746	000002		MOV	#2,-(SP)	
	006324	010600			MOV	SP,R0	
	006326	104415			TRAP	C:PNTX	
	006330	062706	000006		ADD	#6,SP	
734	006334	013703	002200	304:	MOV	EPRTSW,R3	;PRINT MESSAGE BUFFER ADDRESS
735	006340				PRINTX	R3	;PRINT PROPER MESSAGE
	006340	010346			MOV	R3,-(SP)	
	006342	012746	000001		MOV	#1,-(SP)	
	006346	010600			MOV	SP,R0	
	006350	104415			TRAP	C:PNTX	
	006352	062706	000004		ADD	#4,SP	
736	006356	000207			RTS	PC	;RETURN TO CALLER

743	006360				EPRT2:				
744	006360	045	116	045	EPRT1:	.ASCIZ	'#NSA *****REPLACE M7196*****'		
745									
755	006415	045	116	045	TSSRFOR:	.ASCIZ	'#NSA TSSR = #06'		
756	006435	045	116	045	TEXASC:	.ASCIZ	'#NSA Extended Address Bits = #06'		
757	006476	045	116	045	TCOASC:	.ASCIZ	'#NSA Termination Class Code = #T'		
758	006537	045	116	045	TFCASC:	.ASCIZ	'#NSA Fatal Termination Class Code = #T'		
759	006606	045	116	045	TSSDEF:	.ASCIZ	'#NSA TSSR Bits Set: #T'		
760	006635	045	116	045	AMBTSSR:	.ASCIZ	'#NSA TSSR Contents Are Ambiguous'		
761						.EVEN			
762	006676	006716	006741	006767	TCOCOD:	.WORD	1#,2#,3#,4#,5#,6#,7#,8#		
763	006716	116	157	162	1#:	.ASCIZ	'Normal Termination'		
764	006741	124	145	162	2#:	.ASCIZ	'Termination Condition'		
765	006767	124	141	160	3#:	.ASCIZ	'Tape Status Alert'		
766	007011	106	165	156	4#:	.ASCIZ	'Function Reject'		
767	007031	122	145	143	5#:	.ASCIZ	'Recoverable Error - Tape Position One Record Down'		
768	007113	122	145	143	6#:	.ASCIZ	'Recoverable Error - Tape Was Not Moved'		
769	007162	125	156	162	7#:	.ASCIZ	'Unrecoverable Error'		
770	007206	106	141	164	8#:	.ASCIZ	'Fatal Controller Error'		
771						.EVEN			
772									
773	007236	007246	007302	007313	TSFCOD:	.WORD	1#,2#,3#,4#		
774	007246	111	156	164	1#:	.ASCIZ	'Internal Diagnostic Failure'		
775	007302	122	145	163	2#:	.ASCIZ	'Reserved'		
776	007313	102	165	163	3#:	.ASCIZ	'Bus Interface or Sanity Check Error'		
777	007357	122	145	163	4#:	.ASCIZ	'Reserved'		
778						.EVEN			

```

780 .SBTTL PRIPKT PRINT THE ADDRESS/CONTENTS OF COMMAND PACKET
781
782
783 ;*
784 ;THIS ROUTINE PRINTS THE ADDRESS AND CONTENTS OF A COMMAND PACKET.
785 ;THIS ROUTINE IS NORMALLY ONLY CALLED FROM A PRINT ROUTINE.
786 ;
787 ;INPUT:
788 ;
789 ; R0 NUMBER OF WORDS IN PACKET
790 ; R3 HIGH ORDER COMMAND PACKET ADDRESS
791 ; R4 ADDRESS OF COMMAND PACKET
792 ;
793 ; NOTE: R3 IS IGNORED IF THE KTENABLE FLAG IS CLEAR.
794 ;
795 007370 PRIPKT:
796 007370 SAVREG ;SAVE THE REGISTERS
797 007374 010005 MOV R0,R5 ;SAVE NO. OF WORDS IN PACKET
798 007376 005737 003134 TST KTENABLE ;ABOVE 28K UNDER TEST?
799 007402 001001 BNE 10$ ;BR IF YES
800 007404 005003 CLR R3 ;SET HIGH ORDER ADDRESS TO 0
801 007406 010301 10$: MOV R3,R1 ;COPY HIGH ORDER ADDRESS
802 007410 010400 MOV R4,R0 ;GET LOWER ADDRESS
803 007412 006100 ROL R0 ;SHIFT BIT 15 INTO C BIT
804 007414 006101 ROL R1 ;AND INTO HIGH ORDER.
805 007416 PRINTB #PKTADD,R1,R4 ;PRINT PACKET ADDRESS
007416 010446 MOV R4,-(SP)
007420 010146 MOV R1,-(SP)
007422 012746 007554 MOV #PKTADD,-(SP)
007426 012746 000003 MOV #3,-(SP)
007432 010600 MOV SP,R0
007434 104414 TRAP C:PNTB
007436 062706 000010 ADD #10,SP
806 007442 010300 15$: MOV R3,R0 ;GET HIGH ORDER ADDRESS
807 007444 001404 BEQ 20$ ;BR IF NOT ABOVE 28K.
808 007446 010401 MOV R4,R1 ;GET LOW ORDER ADDRESS
809 007450 004737 017316 JSR PC,SETMAP ;SETUP PAR6 MAPPING FOR 18 BIT ADDRESS
810 007454 010004 MOV R0,R4 ;GET RETURNED PAR6 ADDRESS BIAS
811 007456 005001 20$: CLR R1 ;SAVE WORD NUMBER
812 007460 012402 25$: MOV (R4)+,R2 ;GET PACKET CONTENTS
813 007462 PRINTB #PKTFRM,R1,R2 ;PRINT THE DATA
007462 010246 MOV R2,-(SP)
007464 010146 MOV R1,-(SP)
007466 012746 007516 MOV #PKTFRM,-(SP)
007472 012746 000003 MOV #3,-(SP)
007476 010600 MOV SP,R0
007500 104414 TRAP C:PNTB
007502 062706 000010 ADD #10,SP
814 007506 005201 INC R1 ;NEXT WORD NUMBER
815 007510 020105 CMP R1,R5 ;DONE ALL PACKET WORDS?
816 007512 002762 BLT 25$ ;LOOP TILL ALL DONE
817 007514 000207 RTS PC ;RETURN
818
819 007516 045 116 045 PKTFRM: .ASCIZ '#N$A Packet Word #01$A = #06'
820 007554 045 116 045 PKTADD: .ASCIZ '#N$A Packet Address = #01$05'
821 .EVEN

```

```

823                               .SBTTL   PRIBXOR - PRINT EXPD, RECV AND XOR BYTE
824
825                               ;*
826                               ;PRINT EXPECTED DATA, RECEIVED DATA, AND XOR OF THE DATA BYTE
827                               ;THIS ROUTINE IS NORMALLY CALLED ONLY FOR PRINT ROUTINES.
828                               ;
829                               ;INPUTS:
830                               ;
831                               ;       R1       RECEIVED DATA
832                               ;       R2       EXPECTED DATA
833                               ;
834                               ;OUTPUT:
835                               ;
836                               ;       R0       XOR OF EXPECTED/RECEIVED DATA
837                               ;-
838 007612                       PRIBXOR::
839 007612                        SAVREG                       ;SAVE THE REGISTERS
840 007616   010203               MOV       R2,R3               ;EXPECTED DATA
841 007620                       XOR       R1,R3               ;FORM THE EXCLUSIVE OR
842 007630   012700   177400       MOV       #C<377>,R0       ;BYTE MASK
843 007634   040001               BIC       R0,R1               ;SAVE LOW BYTE RECV
844 007636   040002               BIC       R0,R2               ;SAVE LOW BYTE EXPD
845 007640   040003               BIC       R0,R3               ;SAVE LOW BYTE XOR
846 007642                       PRINTB   #XORFOR,R2,R1,R3 ;PRINT THE MESSAGE
                              MOV       R3,-(SP)
                              MOV       R1,-(SP)
                              MOV       R2,-(SP)
                              MOV       #XORFOR,-(SP)
                              MOV       #4,-(SP)
                              MOV       SP,R0
                              TRAP      C#PNTB
                              ADD       #12,SP
847 007670   010300               MOV       R3,R0               ;R0 HAS XOR ON RETURN
848 007672   000207               RTS       PC                 ;RETURN TO CALLER
849
850 007674       045       116       045   XORFOR:            .ASCIZ   '#N#A EXPD: #03#A RECV: #03#A XOR: #03
851                               .EVEN
852                               .SBTTL   PRIXOR - PRINT EXPD, RECV AND XOR
853                               ;*
854                               ;
855                               ;PRINT EXPECTED DATA, RECEIVED DATA, AND XOR OF THE TWO
856                               ;THIS ROUTINE IS NORMALLY CALLED ONLY FOR PRINT ROUTINES.
857                               ;
858                               ;INPUTS:
859                               ;
860                               ;       R1       RECEIVED DATA
861                               ;       R2       EXPECTED DATA
862                               ;
863                               ;OUTPUT:
864                               ;
865                               ;       R0       XOR OF EXPECTED/RECEIVED DATA
866                               ;-
867 007742                       PRIXOR::
868 007742                        SAVREG                       ;SAVE THE REGISTERS
869 007746   010203               MOV       R2,R3               ;EXPECTED DATA
870 007750                       XOR       R1,R3               ;FORM THE EXCLUSIVE OR
871 007760                       PRINTB   #XORFOR,R2,R1,R3 ;PRINT THE MESSAGE

```



007760	010346				MOV	R3, -(SP)	
007762	010146				MOV	R1, -(SP)	
007764	010246				MOV	R2, -(SP)	
007766	012746	010012			MOV	#XORFOR, -(SP)	
007772	012746	000004			MOV	#4, -(SP)	
007776	010600				MOV	SP, R0	
010000	104414				TRAP	C#PNTB	
010002	062706	000012			ADD	#12, SP	
872	010006	010300			MOV	R3, R0	;R0 HAS XOR ON RETURN
873	010010	000207			RTS	PC	;RETURN TO CALLER
874							
875	010012	045	116	045	XORFOR:	.ASCIZ	'#N#A EXPD: #06#A RECV: #0#A XOR: #06'
876						.EVEN	

```

878                    .SBTTL   PRIEQU    PRINT BIT NUMBERS AS ASCII EQUIVALENT
879
880                    ;*
881                    ;
882                    ;ROUTINE TO CONVERT BIT VALUES TO ASCII AND PRINT THE STRING
883                    ;THIS ROUTINE IS NORMALLY CALLED FROM A PRINT ROUTINE
884                    ;
885                    ;INPUTS:
886                    ;
887                    ;        R0        OCTAL VALUE TO CONVERT
888                    ;        R1        TABLE OF POINTERS TO ASCII EQUIVALENT
889                    ;
890                    ;
891
892 010060             PRIEQU:
893 010060                    SAVREG                                ;SAVE THE REGISTERS
894 010064    000207        RTS        PC                            ;RETURN TO CALLER
895
896                    .SBTTL   PRIRAM   - PRINT RAM ADDRESS
897                    ;*
898                    ;
899                    ;PRINT CONTROLLER RAM ADDRESS.
900                    ;THIS ROUTINE IS NORMALLY CALLED ONLY FROM PRINT ROUTINES.
901                    ;
902                    ;INPUTS:
903                    ;
904                    ;        R4        RAM ADDRESS
905                    ;
906                    ;
907 010066             PRIRAM:
908 010066                    SAVREG                                ;SAVE R1-R5 UNTIL NEXT RETURN
909 010072                    PRINTB    #RAMFOR,R4                ;PRINT RAM ADDRESS IN ERROR
                             MOV        R4,-(SP)
                             MOV        #RAMFOR,-(SP)
                             MOV        #2,-(SP)
                             MOV        SP,R0
                             TRAP      C#PNTB
                             ADD        #6,SP
910 010114    000207        RTS        PC                            ;RETURN
911
912 010116        045        116        045   RAMFOR: .ASCIZ '##A CONTROLLER RAM ADDRESS = #06'
913                           .EVEN
  
```

```

915          .SBTTL  PRIADD  PRINT MEMORY ERROR ADDRESS
916          ;*
917          ;
918          ;PRINT MEMORY ADDRESS
919          ;THIS ROUTINE IS NORMALLY CALLED ONLY FROM PRINT ROUTINES.
920          ;
921          ; IMPLICIT INPUTS
922          ;
923          ;     ERRHI  - HIGH ORDER ADDRESS
924          ;     ERRLO  - LOW ORDER ADDRESS
925          ;
926          ;
927 010160    PRIADD:
928 010160          SAVREG          ;SAVE R1-R5 UNTIL NEXT RETURN
929 010164    013700 002236        MOV     ERRHI,R0          ;GET HIGH ADDRESS
930 010170    013701 002240        MOV     ERRLO,R1          ;GET LOW ADDRESS
931 010174    010102                MOV     R1,R2          ;COPY LOW ADDRESS
932 010176    006101                ROL     R1          ;SHIFT BIT 15 TO C BIT
933 010200    006100                ROL     R0          ;SHIFT INTO HIGH ORDER
934 010202                PRINTB  #PRIA0,R0,R2      ;PRINT MEMORY ADDRESS IN ERROR
          010202    010246        MOV     R2,-(SP)
          010204    010046        MOV     R0,-(SP)
          010206    012746 010230    MOV     #PRIA0,-(SP)
          010212    012746 000003    MOV     #3,-(SP)
          010216    010600        MOV     SP,R0
          010220    104414        TRAP   C#PNTB
          010222    062706 000010    ADD     #10,SP
935 010226    000207                RTS      PC          ;RETURN
936
937 010230    045      116      045  PRIA0: .ASCIZ  '#N#A MEMORY ERROR ADDRESS = #01#05'
938          .EVEN
939
940          .SBTTL  PRITADD - PPINT MEMORY TEST ADDRESS
941          ;*
942          ;
943          ;PRINT MEMORY ADDRESS
944          ;THIS ROUTINE IS NORMALLY CALLED ONLY FROM PRINT ROUTINES.
945          ;
946          ; IMPLICIT INPUTS
947          ;
948          ;     ERRHI  - HIGH ORDER ADDRESS
949          ;     ERRLO  - LOW ORDER ADDRESS
950          ;
951          ;
952 010274    PRITADD:
953 010274          SAVREG          ;SAVE R1-R5 UNTIL NEXT RETURN
954 010300    013702 002236        MOV     ERRHI,R2          ;GET HIGH ADDRESS
955 010304    013701 002240        MOV     ERRLO,R1          ;GET LOW ADDRESS
956          ;MOV     R1,R2          ;COPY LOW ADDRESS
957          ;ROL     R1          ;SHIFT BIT 15 TO C BIT
958          ;ROL     R0          ;SHIFT INTO HIGH ORDER
959 010310                PRINTB  #PRIT0,R1          ;PRINT MEMORY ADDRESS LOW IN ERROR
          010310    010146        MOV     R1,-(SP)
          010312    012746 010356    MOV     #PRIT0,-(SP)
          010316    012746 000002    MOV     #2,-(SP)
          010322    010600        MOV     SP,R0
          010324    104414        TRAP   C#PNTB

```

```

960 010326 062706 000006      ADD    #6,SP
010332      PRINTB  #PRIT1,R2      ;PRINT MEMORY ADDRESS HIGH IN ERROR
010332 010246      MOV    R2,-(SP)
010334 012746 010421      MOV    #PRIT1,-(SP)
010340 012746 000002      MOV    #2,-(SP)
010344 010600      MOV    SP,R0
010346 104414      TRAP  C#PNTB
961 010350 062706 000006      ADD    #6,SP
010354 000207      RTS    PC      ;RETURN
962
963 010356      045      116      045 PRIT0: .ASCIZ '###A MEMORY TEST ADDRESS LOW = #06
964 010421      045      116      045 PRIT1: .ASCIZ '###A MEMORY TEST ADDRESS HIGH = #06
965      .EVEN

```

TSV3 - GLOBAL AREAS MACRO M1113 14-JUN-84 15:55  
 SPACE SPACE RECORDS (FORWARD AND REVERSE) COMMAND

SEQ 0051

```

967 .SBTTL SPACE - SPACE RECORDS (FORWARD AND REVERSE) COMMAND
968
969 ;*
970 ;
971 ;ROUTINE TO ISSUE A SPACE RECORDS
972 ;COMMAND (FORWARD OR REVERSE)
973 ;
974 ;INPUT:
975 ;
976 ; R3 NUMBER OF RECORDS TO BE SPACED OVER
977 ; BIT15 CONTROLS DIRECTION
978 ; BIT15 = 0 IS FORWARD
979 ; BIT15 = 1 IS REVERSE
980 ; R5 FIRST DEVICE UNIBUS ADDRESS
981 ;
982 ; REQUIRES A WRITE CHARACTERISTICS DONE PREVIOUSLY
983 ;
984 ;OUTPUT:
985 ;
986 ; CARRY SET - SPACE RECORDS COMMAND OK
987 ; CLR - SPACE RECORDS FAILED
988 ;
989 ;
990 ; R0 THE CONTENTS OF R4 IS MOVED TO R0
991 ;
992 ;
993 ;IMPLICIT OUTPUT:
994 ;
995 ; TAPE HAS BEEN MOVED
996 ;
997 ;SIDE EFFECTS:
998 ;
999 ;
1000 ;
1001 ;
1002 010466 SPACE:: SAVREG ;SAVE THE GENERAL REGISTERS
1003 010466 MOV #500.,SDELAY ;SET UP DELAY
1004 010472 012737 000764 010660 MOV #140010,80# ;SET UP COMMAND, SPACE FORWARD
1005 010500 012737 140010 010650 TST R3 ;CHECK FOR DIRECTION
1006 010506 005703 BMI 5# ;BR, IF REVERSE INDICATED
1007 010510 100403 MOV R3,90# ;LOAD UP NUMBER OF RECORDS TO SPACE
1008 010512 010337 010652 BR 10# ;GO DO COMMAND
1009 010516 000407 5#: BIC #BIT15,R3 ;CLEAR DIRECTION BIT
1010 010520 042703 100000 MOV R3,90# ;LOAD UP NUMBER OF RECORDS TO SPACE
1011 010524 010337 010652 BIS #BIT8,80# ;SET REVERSE BIT IN COMMAND PACKET
1012 010530 052737 000400 010650 10#: MOV #80#,R4 ;SET UP R4 WITH PACKET ADDRESS
1013 010536 012704 010650 MOV R4,TSDB(R5) ;SEND OUT COMMAND
1014 010542 010465 000000 15#: JSR PC,WAITF ;WAIT FOR SSR
1015 010546 004737 016250 BCS 20# ;BR, IF SSR IS SET AND OK
1016 010552 103420 DELAY 250 ;DELAY ABOUT .25 SECONDS
1017 010554 MOV #250,(PC).
010554 012727 000250 .WORD 0
010560 000000 MOV L#DLY,(PC).
010562 013727 002116 .WORD 0
010566 000000 DEC -6(PC)
010570 005367 177772 BNE .-4
010574 001375

```

```

010576 005367 177756          DEC    -22(PC)
010602 001367          BNE    .-20
1018 010604 005337 010660    DEC    SDELAY          ;BUMP DELAY COUNTER DOWN
1019 010610 001356          BNE    15             ;BR, IF MORE DELAY
1020 010612 000411          BR     60             ;BR IF TROUBLE CARRY = CLEAR
1021 010614 016501 000002    20:   MOV    TSSR(R5),R1 ;READ TSSR
1022 010620 012702 000200    MOV    @SSR,R2        ;SET UP EXPECTED
1023 010624 020201          25:   CMP    R2,R1        ;ARE THEY OK
1024 010626 001401          BEQ    40             ;BR, IF EQUAL = OK
1025 010630 000402          BR     60             ;TROUBLE EXIT
1026 010632 000261          40:   SEC                    ;SET CARRY NO TROUBLE
1027 010634 000401          BR     70             ;EXIT
1028 010636 000241          60:   CLC                    ;CARRY CLEAR = ERROR
1029 010640          70:
1030 010640 010400          MOV    R4,R0          ;PASS PACKET ADDRESS
1031 010642 000207          RTS    PC             ;RETURN
1032
1033
1034
1035          ;PACKET FOR SPACE COMMAND
1036
1037          ;
1038          010650          .=<.10>E177770
1039
1040          ;
1041          ;COMMAND WORD
1042 010650 000000    80:   .WORD
1043          ;NUMBER OF RECORDS TO BE SPACED OVER WORD
1044 010652 000000    90:   .WORD
1045 010654 000000          .WORD
1046 010656 000000          .WORD
1047 010660 000000    SDELAY: .WORD 0          ;DELAY COUNTER
1048          .EVEN
1049          .SBTTL WRCHR WRITE CHARACTERISTICS COMMAND
    
```

```

1051 ;
1052 ;ROUTINE TO ISSUE A WRITE CHARACTERISTICS
1053 ;COMMAND SO THAT OTHER COMMANDS WILL BE ACCEPTED
1054 ;
1055 ;INPUT:
1056 ; R4 ADDRESS OF PACKET FROM TEST
1057 ; R5 FIRST DEVICE UNIBUS ADDRESS
1058 ; REQUIRES A CALL TO SOFINIT BE DONE PREVIOUSLY
1059 ;
1060 ;OUTPUT:
1061 ; R0 TSSR CONTENTS
1062 ; CARRY SET - WRITE CHARACTERISTICS COMMAND OK
1063 ; CLR - WRITE CHARACTERISTICS FAILED
1064 ;
1065 ;IMPLICIT OUTPUT:
1066 ;
1067 ; MESSAGE BUFFER AND OTHER BUFFERS ALL SET UP
1068 ; SOFTWARE SWITCHES SET AS FOLLOWS:
1069 ; EXTFEA = EXTENDED FEATURES PRESENT
1070 ; BENBSW = BUFFER ENABLE SWITCH ON OR OFF
1071 ;
1072 ;SIDE EFFECTS:
1073 ;
1074 010662 WRTCHR::
1075 010662 SAVREG ;SAVE THE GENERAL REGISTERS
1076 010666 005037 002230 CLR BENBSW ;CLEAR BUFFER ENABLE SWITCH
1077 010672 005037 002226 CLR EXTFEA ;CLEAR EXTENDED FEATURES SW SWITCH
1078 010676 010465 000000 104: MOV R4,TS08(R5) ;SEND OUT COMMAND
1079 010702 004737 016336 JSR PC,CHKTSSR ;WAIT FOR SSR
1080 010706 103401 BCS 204 ;BR, IF SSR IS SET AND OK
1081 010710 000435 BR 604 ;BR IF TROUBLE CARRY = CLEAR
1082 010712 016501 000002 204: MOV TSSR(R5),R1 ;READ TSSR
1083 010716 012702 000200 MOV #SSR,R2 ;SET UP EXPECTED
1084 010722 032701 000100 BIT #OFL,R1 ;WAS OFF LINE SET IN TSSR
1085 010726 001402 BEQ 254 ;BR, IF NO OFL SET
1086 010730 052702 000100 BIS #OFL,R2 ;MAKE THEM LOOK ALIKE
1087 010734 020201 254: CMP R2,R1 ;ARE THEY OK
1088 010736 001401 BEQ 404 ;BR, IF EQUAL = OK
1089 010740 000421 BR 604 ;TROUBLE EXIT
1090 010742 062704 000010 404: ADD #8,R4 ;POINT TO WRT CHARA DATA PACKET
1091 010746 011403 MOV (R4),R3 ;GET ADDRESS OF MESSAGE BUFFER
1092 010750 032763 000200 000012 BIT #X2.EXTF,XST2(R3) ;EXTENDED FEATURES BIT SET?
1093 010756 001402 BEQ 454 ;BR IF NO
1094 010760 005237 002226 INC EXTFEA ;SET EXTENDED FEATURES SW SWITCH
1095 010764 454:
1096 010764 032763 000100 000012 BIT #X2.BUFE,XST2(R3) ;BUFFER ENABLE SWITCH SET
1097 010772 001402 BEQ 504 ;BR, IF SWITCH NOT SET
1098 010774 005237 002230 INC BENBSW ;SET SOFTWARE SWITCH FOR ENABLED
1099 011000 504:
1100 011000 000261 SEC ;SET CARRY NO TROUBLE
1101 011002 000401 BR 704 ;EXIT
1102 011004 000241 604: CLC ;CARRY CLEAR = ERROR
1103 011006 016500 000002 704: MOV TSSR(R5),R0 ;RETURN TSSR CONTENTS
1104 011012 000207 RTS PC ;RETURN
    
```

```

1106
1107
1108
1109
1110
1111
1112
1113
1114
1115
1116
1117
1118
1119
1120
1121
1122
1123
1124
1125
1126
1127
1128
1129
1130
1131
1132
1133 011014
1134 011014
1135 011020 012704 011110
1136 011024 010465 000000
1137 011030 012703 000550
1138 011034 004737 016250
1139 011040 103417
1140 011042
    011042 012727 000372
    011046 000000
    011050 013727 002116
    011054 000000
    011056 005367 177772
    011062 001375
    011054 005367 177756
    011070 001367
1141 011072 005303
1142 011074 001357
1143 011076 000241
1144 011100 010400
1145 011102 000207
1146
1148      011110
1150 011110
1151 011110 102010
1152 011112 000000
    
```

```

.SBTTL REWIND POSITION TAPE (REWIND) COMMAND
;
; THIS ROUTINE WILL REWIND THE SELECTED TAPE.
;
; CAUTION: THE ROUTINE DOES NOT WAIT FOR BOT
; TO ARRIVE. ALSO THE CALLER MUST CHECK FOR
; SSR TO SET IN THE TSSR
;
; CALLING SEQUENCE:
;
; DO A SOFT INIT
; DO A WRITE CHARACTERISTICS
; JSR PC,REWIND
;
; INPUT:
;
; R5 FIRST DEVICE UNIBUS ADDRESS
;
; OUTPUT
;
; R0 THE CONTENTS OF R4 IS PASSED TO R0
;
; -
REWIND::
    SAVREG                                ;SAVE R1-R5 UNTIL NEXT RETURN
    MOV @RMPACK,R4                        ;GET PACKET ADDRESS
    MOV R4,TSDB(R5)                       ;SEND PACKET ADDRESS TO EXECUTE
    MOV @360.,R3                           ;ENOUGH TIME FOR 2400' REEL TO REWIND
    JSR PC,WAITF                           ;WAIT FOR SSR TO SET
    BCS 204                                ;LEAVE WHEN SSR IS SET
    DELAY 250.                             ;WAIT FOR .25 SECONDS
    MOV @250.,(PC).
    .WORD 0
    MOV L1DLY,(PC).
    .WORD 0
    DEC -6(PC)
    BNE .-4
    DEC -22(PC)
    BNE .-20
    DEC R3                                ;BUMP COUNTER DOWN
    BNE 104                                ;KEEP GOING
    CLC                                    ;CLEAR CARRY TO SET ERROR
    MOV R4,R0                              ;PASS THE PACKET ADDRESS
    RTS PC                                  ;RETURN
;
; RMPACK: .=<..10>&177770
; .WORD 102010 ;POSTION COMMAND (REWIND)
; .WORD 0 ;NOT USED
    
```



1154  
1155  
1156  
1157  
1158  
1159  
1160  
1161  
1162  
1163  
1164  
1165  
1166  
1167  
1168  
1169  
1170  
1171  
1172  
1173  
1174  
1175  
1176  
1177  
1178  
1179  
1180  
1181  
1182  
1183  
1184  
1185  
1186  
1187  
1188  
1189  
1190  
1191  
1192  
1193  
1194  
1195  
1196  
1197  
1198  
1199  
1200  
1201  
1202  
1203  
1204  
1205

.SBTTL CKRAM - COMPARE RAM TO I/O PACKET

;  
; ROUTINE TO READ THE FIRST 8 BYTES FROM RAM  
; MEMORY AND COMPARE THIS DATA TO A COMMAND PACKET.  
;  
; INPUT:  
;  
; R4 ADDRESS OF THE COMMAND PACKET  
; R5 FIRST DEVICE UNIBUS ADDRESS  
;  
; OUTPUT:  
;  
; CARRY SET - RAM MATCHES PACKET  
; CLR - RAM DOES NOT MATCH PACKET  
;  
; IMPLICIT OUTPUT:  
;  
; THE TABLE RAMDATA IS FILLED WITH THE  
; DATA HELD IN RAM.  
; RAMSIZ IS SET TO 8. FOR PRAMPKT ROUTINE  
;  
; SIDE EFFECTS:  
;  
; THE SUBSYSTEM IS LEFT IN MAINTENANCE MODE  
;  
;

CKRAM::

SAVREG ;SAVE THE GENERAL REGISTERS  
MOV #RAMDATA,R1 ;ADDRESS TO SAVE THE RAM DATA  
MOV #RMPKTBEG,R2 ;BYTE ADDRESS OF FIRST RAM DATA  
CLR R3 ;CLEAR THE ERROR FLAG  
JSR PC,CHKTSSR ;WAIT FOR SSR  
MOVB #0,TSDB(R5) ;SET MAINTENANCE MODE  
10: JSR PC,CHKTSSR ;WAIT FOR SSR TO SET  
MOV R2,TSDB(R5) ;SELECT NEXT RAM ADDRESS  
JSR PC,CHKTSSR ;WAIT FOR SSR TO SET  
MOVB TSBA(R5),(R1) ;READ THE RAM DATA  
CMPB (R1),.(R4) ;COMPARE TO EXPECTED  
BEQ 20: ;BRANCH IF OK  
INC R3 ;SET ERROR FLAG  
20: INC R2 ;ADDRESS OF NEXT RAM LOCATION  
CMP R2,#RMPKTEND ;REACHED END YET ?  
BLE 10: ;BRANCH TILL ALL READ  
TST R3 ;WAS AN ERROR FOUND ?  
BEQ 30: ;BRANCH IF NOT  
CLC ;CLEAR CARRY TO SHOW ERROR  
BR 50: ;AND EXIT  
30: SEC ;SHOW GOOD COMPARE  
50: MOV #8.,RAMSIZ ;SETUP RAMSIZ FOR PRAMPKT ROUTINE  
RTS PC ;RETURN

002242  
000201  
016336  
000000 000000  
016336 10:  
000000  
016336  
000000  
122124  
001401  
005203  
005202 20:  
000210  
003761  
005703  
001402  
000401  
000261 30:  
000010 002302 50:  
000207

```

1207          .SBTTL CKRAM2 - COMPARE RAM TO I/O CHARACTERISTICS DATA
1208          ;*
1209          ;
1210          ;ROUTINE TO READ THE FIRST 8 OR 10 BYTES FROM RAM
1211          ;MEMORY AND COMPARE THIS DATA TO A CHARACTERISTICS DATA BLOCK.
1212          ;
1213          ;INPUT:
1214          ;
1215          ;      P4      ADDRESS OF THE CHARACTERISTICS DATA
1216          ;      R5      FIRST DEVICE UNIBUS ADDRESS
1217          ;
1218          ;OUTPUT:
1219          ;
1220          ;      CARRY   SET - RAM MATCHES PACKET
1221          ;             CLR - RAM DOES NOT MATCH PACKET
1222          ;
1223          ;IMPLICIT OUTPUT:
1224          ;
1225          ;      THE TABLE RAMDATA IS FILLED WITH THE
1226          ;      DATA HELD IN RAM.
1227          ;      RAMSIZ IS SET TO 8. OR 10. FOR PRAMPKT ROUTINE
1228          ;
1229          ;SIDE EFFECTS:
1230          ;
1231          ;      THE SUBSYSTEM IS LEFT IN MAINTENANCE MODE
1232          ;-
1233          CKRAM2::
1234          SAVREG          ;SAVE THE GENERAL REGISTERS
1235          MOV             #RAMDATA,R1      ;ADDRESS TO SAVE THE RAM DATA
1236          MOV             #RMCHBEG,R2     ;BYTE ADDRESS OF FIRST RAM DATA
1237          CLR            R3              ;CLEAR THE ERROR FLAG
1238          JSR            PC,CHKTSSR       ;WAIT FOR SSR
1239          MOV            #0,TSDB(R5)     ;SET MAINTENANCE MODE
1240          JSR            PC,CHKTSSR       ;WAIT FOR SSR TO SET
1241          MOV            R2,TSDB(R5)     ;SELECT NEXT RAM ADDRESS
1242          JSR            PC,CHKTSSR       ;WAIT FOR SSR TO SET
1243          MOV            TSBA(R5),(R1)   ;READ THE RAM DATA
1244          CMPB           (R1),*(R4)     ;COMPARE TO EXPECTED
1245          BEQ            20$            ;BRANCH IF OK
1246          INC            R3              ;SET ERROR FLAG
1247          INC            R2              ;ADDRESS OF NEXT RAM LOCATION
1248          MOV            #8.,RAMSIZ      ;ASSUME EXTFEA NOT SET
1249          TST            EXTFEA          ;IS THE SOFTWARE EXTENDED FEATURES SET
1250          BEQ            25$            ;BR, IF NOT SET
1251          MOV            #10.,RAMSIZ     ;SET RAMSIZ FOR EXTEND FEATURES
1252          CMP            R2,#RMCHEND     ;AT END OF EXTENDED BUFFER
1253          BLE            10$            ;BR, IF NOT AT END YET
1254          BR             27$            ;AT END BRANCH
1255          CMP            R2,#RMCHEND-2   ;REACHED END YET ?
1256          BLE            10$            ;BRANCH TILL ALL READ
1257          TST            R3              ;WAS AN ERROR FOUND ?
1258          BEQ            30$            ;BRANCH IF NOT
1259          CLC              ;CLEAR CARRY TO SHOW ERROR
1260          BR             50$            ;AND EXIT
1261          SEC              ;SHOW GOOD COMPARE
1262          RTS             PC             ;RETURN

```

```

1264 .SBTTL CKMSG - COMPARE WRITE CHAR. MESSAGE BUFFERS
1265 ;*
1266 ;
1267 ;ROUTINE TO COMPARE A WRITE CHARACTERISTICS EXPD AND RECV
1268 ;BUFFER. THE EXPECTED AND RECEIVED BUFFERS ARE STORED FOR
1269 ;ERROR PRINT ROUTINES.
1270 ;
1271 ;INPUT:
1272 ;
1273 ; R0 RECV MESSAGE BUFFER HIGH ORDER ADDRESS
1274 ; R1 RECV MESSAGE BUFFER LOW ORDER ADDRESS
1275 ; R2 EXPD MESSAGE BUFFER ADDRESS
1276 ;OUTPUT:
1277 ;
1278 ; CARRY SET - MESSAGE BUFFERS MATCH
1279 ; CLR -MESSAGE BUFFERS DON'T MATCH
1280 ;
1281 ;IMPLICIT OUTPUT:
1282 ;
1283 ; EXPMSG BUFFER IS SET TO EXPD DATA
1284 ; RECVMSG BUFFER IS SET TO RECV DATA
1285 ; RCVHIADD SET TO HIGH ORDER ADDRESS OF RECV
1286 ; RCVLOADD SET TO LOW ORDER ADDRESS OF RECV
1287 ;
1288 ;-
1289 CKMSG::
1290 SAVREG ;SAVE R1-R5 UNTIL NEXT RETURN
1291 MOV R0,RCVHIADD ;SAVE RECV HIGH ADDRESS
1292 MOV R1,RCVLOADD ;SAVE RECV LOW ADDRESS
1293 TST KTENABLE ;TESTING ABOVE 28K?
1294 BEQ 10; ;BR IF NO
1295 JSR PC,SETMAP ;RETURN ADDRESS BIASED TO PAR6 IN R0
1296 MOV R0,R1 ;GET RETURNED ADDRESS BIASED TO PAR6
1297 10;: CLR R4 ;WORD IN BUFFER
1298 CLR R3 ;CLEAR ERROR SEEN FLAG
1299 MOV R2,R5 ;GET EXPD BUFFER ADDRESS
1300 15;: MOV (R2),EXPMSG(R4) ;SAVE EXPD FOR ERROR REPORT
1301 MOV (R1),RECVMSG(R4) ;SAVE RECV FOR ERROR REPORT
1302 CMP (R2),.(R1) ;EXPD EQUAL RECV?
1303 BEQ 25; ;BR IF YES
1304 INC R3 ;SET ERROR SEEN FLAG
1305 25;: ADD @2,R4 ;POINT TO NEXT WORD ADDRESS
1306 CMP R4,#14 ;DONE FIRST 7 WORDS?
1307 BLE 15; ;BR IF NO
1308 BIT @X2.EXTF,XST2(R5) ;IS EXTENDED FEATURES SET IN EXPD?
1309 BEQ 50; ;BR IF NO
1310 CMP R4,#16 ;DONE EXTENDED FEATURES WORD?
1311 BLE 15; ;BR IF NO
1312 50;: TST R3 ;ANY ERRORS SEEN?
1313 BEQ 55; ;BR IF NO
1314 CLC ;SET FAILURE
1315 BR 60; ;
1316 55;: SEC ;SET SUCCESS
1317 60;: RTS PC ;RETURN

```

```

1319
1320
1321
1322
1323
1324
1325
1326
1327
1328
1329
1330
1331
1332
1333
1334
1335
1336
1337
1338
1339
1340
1341 011500
1342 011500
1343 011504 020327 000144
1344 011510 003412
1345 011512 012703 000144
1346 011516
      011516 012746 011632
      011522 012746 000001
      011526 010600
      011530 104417
      011532 062706 000004
1347 011536 010037 002304
1348 011542 010137 002306
1349 011546 005737 003134
1350 011552 001403
1351 011554 004737 017316
1352 011560 010001
1353 011562 005004
1354 011564 005005
1355 011566 111264 002322
1356 011572 111164 002466
1357 011576 122221
1358 011600 001401
1359 011602 005205
1360 011604 062704 000001
1361 011610 020403
1362 011612 002001
1363 011614 000764
1364 011616 005705
1365 011620 001402
1366 011622 000241
1367 011624 000401
1368 011626 000261
1369 011630 000207
    
```

```

.SBTTL CKMSG2 - COMPARE EXPD RECV MESSAGE BUFFERS
;
; ROUTINE TO COMPARE AN EXPECTED AND RECEIVED MESSAGE
; BUFFER. THE EXPECTED AND RECEIVED BUFFERS ARE STORED FOR
; ERROR PRINT ROUTINES.
;
; INPUT:
; R0 RECV MESSAGE BUFFER HIGH ORDER ADDRESS
; R1 RECV MESSAGE BUFFER LOW ORDER ADDRESS
; R2 EXPD MESSAGE BUFFER ADDRESS
; R3 NUMBER OF BYTES TO COMPARE
;
; OUTPUT:
; CARRY SET - MESSAGE BUFFERS MATCH
; CLR - MESSAGE BUFFERS DON'T MATCH
;
; IMPLICIT OUTPUT:
; EXPMSG BUFFER IS SET TO EXPD DATA
; RECVMSG BUFFER IS SET TO RECV DATA
; RCVHIADD SET TO HIGH ORDER ADDRESS OF RECV
; RCVLOADD SET TO LOW ORDER ADDRESS OF RECV
;
CKMSG2::
    SAVREG ;SAVE R1-R5 UNTIL NEXT RETURN
    CMP R3,#RECVMSG-EXPMSG,#00 ;IS COUNT ABOVE MAX ALLOWED?
    BLE 5# ;000 BR IF NO
    MOV #RECVMSG-EXPMSG,R3,#00
    PRINTF #DEBUGMSG ;000
    MOV #DEBUGMSG,-(SP)
    MOV #1,-(SP)
    MOV SP,R0
    TRAP C#PNTF
    ADD #4,SP
5#: MOV R0,RCVHIADD ;SAVE RECV HIGH ADDRESS
    MOV R1,RCVLOADD ;SAVE RECV LOW ADDRESS
    TST KTENABLE ;TESTING ABOVE 28K?
    BEQ 10# ;BR IF NO
    JSR PC,SETMAP ;RETURN ADDRESS BIASED TO PAR6 IN R0
    MOV R0,R1 ;GET RETURNED ADDRESS BIASED TO PAR6
10#: CLR R4 ;WORD IN BUFFER
    CLR R5 ;CLEAR ERROR SEEN FLAG
15#: MOVB (R2),EXPMSG(R4) ;SAVE EXPD FOR ERROR REPORT
    MOVB (R1),RECVMSG(R4) ;SAVE RECV FOR ERROR REPORT
    CMPB (R2)*,(R1)* ;EXPD EQUAL RECV?
    BEQ 25# ;BR IF YES
    INC R5 ;SET ERROR SEEN FLAG
25#: ADD #1,R4 ;POINT TO NEXT BYTE
    CMP R4,R3 ;DONE ALL BYTES?
    BGE 50# ;BR IF YES
    BR 15# ;DO NEXT BYTE
50#: TST R5 ;ANY ERRORS SEEN?
    BEQ 55# ;BR IF NO
    CLC ;SET FAILURE
    BR 60#
55#: SEC ;SET SUCCESS
60#: RTS PC ;RETURN
    
```

```

1371 011632      120      122      117  DEBUGMSG: .ASCIZ 'PROGRAM INTERNAL ERROR -CKMSG2 MESSAGE BUFFER EXCEEDED :000
1372 011722      045      116      045  FERCM:  .ASCII /MMA ***/
1373 011733      040      040      124  ERCM.   .ASCIZ / TSSR ERROR CODE REC'D * /
1374 011766      056      056      056  SIMSG:  .ASCIZ /.... AFTER DOING SOFT INIT/
1375 012021      124      105      123  TINERR: .ASCIZ /TEST: .../
1376
1377
1378
1379
1380
1381
1382
1383
1384
1385
1386
1387
1388
1389
1390
1391 012034      004737  006024  BGNMSG  SFIMSG
      012034      SFIMSG::
1392 012034      004737  006024  JSR     PC,PRITSSR      ;PRINT CONTENTS OF TSSR REGISTER
1393 012040      004737  017202  JSR     PC,CKDROP      ;DROP UNIT, IF ALLOWED
1394 012044      012044      ENDMSG
      012044      L10003:
      012044  104423  TRAP   CMSG
1395
1396
1397
1398
1399
1400
1401
1402
1403
1404
1405
1406
1407 012046      004737  006024  BGNMSG  PKTSSR
      012046      PKTSSR::
1408 012046      004737  006024  JSR     PC,PRITSSR      ;PRINT THE CONTENTS OF TSSR REGISTER
1409 012052      012700  000004  MOV     #4,R0          ;NO. OF WORDS IN PACKET
1410 012056      004737  007370  JSR     PC,PRIPKT      ;PRINT THE CONTENTS OF COMMAND PACKET
1411 012062      012062      ENDMSG
      012062      L10004:
      012062  104423  TRAP   CMSG

```

TSV3 - GLOBAL AREAS MACRO M1113 14-JUN-84 15:55  
 CKMSG2 - COMPARE EXPD RECV MESSAGE BUFFERS

SEQ 0060

```

1413 ;*
1414 ;PRINT ROUTINE TO PRINT THE CONTENTS OF
1415 ;TSSR AND A GET STATUS COMMAND PACKET.
1416 ;
1417 ;INPUTS:
1418 ;
1419 ;       R1       TSSR CONTENTS
1420 ;       R4       ADDRESS OF COMMAND PACKET
1421 ;
1422 012064      BGNMSG  PKTGETS
      012064
1423 012064 004737 006024      PKTGETS::
1424 012070 012700 000002      JSR       PC,PRITSSR      ;PRINT THE CONTENTS OF TSSR REGISTER
1425 012074 004737 007370      MOV       #2,R0      ;NO. OF WORDS IN GET STATUS PACKET
1426 012100      JSR       PC,PRIPKT      ;PRINT THE CONTENTS OF COMMAND PACKET
      012100      ENDMSG
      012100 104423      L10005:
                          TRAP       C#MSG
1427 ;*
1428 ;PRINT TSSR ERRORS FOR INITIALIZATION TESTS
1429 ;
1430 ;INPUTS:
1431 ;       R1       TSSR CONTENTS
1432 ;       R4       ADDRESS OF COMMAND PACKET
1433 ;-
1434 012102      BGNMSG  SFFMSG
      012102
1435 012102 004737 006024      SFFMSG::
1436 012106      JSR       PC,PRITSSR      ;PRINT CONTENTS OF TSSR REGISTER
      012106      ENDMSG
      012106 104423      L10006:
                          TRAP       C#MSG
                          .SBTTL    PKTMES - PRINT TSSR AND MESSAGE BUFFER
1437 ;*
1438 ;PRINT ROUTINE TO PRINT THE CONTENTS OF TSSR AND MESSAGE
1439 ;BUFFER FOR ERROR REPORTS
1440 ;
1441 ;INPUTS:
1442 ;
1443 ;       R1       CONTENTS OF TSSR
1444 ;       R2       LOW ORDER MESSAGE BUFFER
1445 ;       R3       HIGH ORDER MESSAGE BUFFER ADDRESS
1446 ;       NOTE: R3 IS IGNORED IF KTENABLE FLAG IS CLEAR
1447 ;-
1448 ;
1449 012110      BGNMSG  PKTMES
      012110
1450 012110 004737 006024      PKTMES::
1451 012114 010200      JSR       PC,PRITSSR      ;PRINT CONTENTS OF TSSR
1452 012116 010301      MOV       R2,R0      ;LOW ORDER ADDRESS
1453 012120 004737 014242      MOV       R3,R1      ;HIGH ORDER ADDRESS
1454 012124      JSR       PC,PRMESS      ;PRINT THE MESSAGE BUFFER
      012124      ENDMSG
      012124 104423      L10007:
                          TRAP       C#MSG

```

```

1456          .SBTTL  ADDSSR  PRINT TEST ADDRESS AND TSSR
1457          ;*
1458          ;PRINT ROUTINE TO PRINT THE CONTENTS OF
1459          ;TSSR AND A MEMORY TEST ADDRESS
1460          ;
1461          ;INPUTS:
1462          ;
1463          ;      R5      FIRST DEVICE UNIBUS ADDRESS
1464          ;      ERRHI   HIGH ORDER MEMORY TEST ADDRESS
1465          ;      ERRLO   LOW ORDER MEMORY TEST ADDRESS
1466          ;
1467          ;
1468 012126          BGNMSG  ADDSSR
1469 012126          ADDSSR::
1470 012126 004737 010274      JSR      PC,PRITADD      ;PRINT MEMORY TEST ADDRESS
1471 012132 016501 000002      MOV      TSSR(R5),R1      ;GET CURRENT TSSR
1472 012136 004737 006024      JSR      PC,PRITSSR      ;PRINT THE CONTENTS OF TSSR REGISTER
1473 012142          ENDMSG
1474 012142          L10010:
1475 012142 104423          TRAP      C#MSG
1476          ;
1477          .SBTTL  MSGEXP - PRINT WRITE CHAR. EXPD-RCV MESSAGE BUFFERS
1478          ;*
1479          ;PRINT ROUTINE TO PRINT WRITE CHARACTERISTIC MESSAGE BUFFER
1480          ;
1481          ;IMPLICIT INPUTS:
1482          ;
1483          ;      EXPMSG  - EXPECTED MESSAGE BUFFER
1484          ;      RECVMSG - RECEIVED MESSAGE BUFFER
1485          ;      RCVHIADD- RECEIVED MESSAGE BUFFER HIGH ORDER ADDRESS
1486          ;      RCVLOADD- RECEIVED MESSAGE BUFFER LOW ORDER ADDRESS
1487          ;
1488          ;
1489 012144          BGNMSG  MSGEXP
1490 012144          MSGEXP::
1491 012144 012700 000007      MOV      #7,R0      ;ASSUME NO EXT FEATURES
1492 012150 005737 002226      TST      EXTFEA      ;EXT FEATURES SET?
1493 012154 001402          BEQ      5#      ;BR IF NO
1494 012156 012700 000010      MOV      #8.,R0      ;EXT FEATURE BUFFER IS 8 WORDS
1495 012162 004737 014552      JSR      PC,PRMSGEXP      ;PRINT EXPD/RCV MESSAGE BUFFERS
1496 012166          ENDMSG
1497 012166          L10011:
1498 012166 104423          TRAP      C#MSG

```

< 5

```

1494 .SBTTL FIFEXP - PRINT FIFO EXP/RECV DATA
1495
1496 :
1497 :PRINT ROUTINE TO PRINT FIFO EXP/RECV DATA
1498 :
1499 : R1 - BYTE COUNT
1500 :
1501 :IMPLICIT INPUTS:
1502 :
1503 : EXPMSG - EXPECTED MESSAGE BUFFER (CONTAINS FIFO DATA ONLY)
1504 : RECMSG - RECEIVED MESSAGE BUFFER (CONTAINS FIFO DATA ONLY)
1505 :
1506 012170 BGNMSG FIFEXP
012170 FIFEXP::
1507 012170 PRINTX #FIF1MSG,R1 ;PRINT BYTES TRANSFERRED
012170 010146 MOV R1,-(SP)
012172 012746 012242 MOV #FIF1MSG,-(SP)
012176 012746 000002 MOV #2,-(SP)
012202 010600 MOV SP,R0
012204 104415 TRAP C#PNTX
012206 062706 000006 ADD #6,SP
1508 012212 PRINTX #FIF2MSG ;PRINT HEADER MSG
012212 012746 012311 MOV #FIF2MSG,-(SP)
012216 012746 000001 MOV #1,-(SP)
012222 010600 MO' SP,R0
012224 104415 TRAP C#PNTX
012226 062706 000004 ADD #4,SP
1509 012232 010100 MOV R1,R0 ;GET BYTE COUNT
1510 012234 004737 015122 JSR PC,PRBYTEXP ;PRINT FIFO BYTES IN ERROR
1511 012240 ENDMSG
012240 L10012:
012240 104423 TRAP C#MSG
1512 012242 045 116 045 FIF1MSG: .ASCIZ '#N#A NUMBER OF BYTES TRANSFERRED = #D2'
1513 012311 045 116 045 FIF2MSG: .ASCIZ '#N#A FIFO DATA BYTES IN ERROR:'
1514 .EVEN
  
```



```

1516 .SBTTL MSGSTAT - PRINT STATUS HEADER AND MESSAGE BUFFERS
1517 ;*
1518 ;PRINT ROUTINE TO PRINT MESSAGE BUFFER EXPD/RCV
1519 ;
1520 ;
1521 ;IMPLICIT INPUTS:
1522 ;
1523 ; EXPMSG - EXPECTED MESSAGE BUFFER
1524 ; RECMSG - RECEIVED MESSAGE BUFFER
1525 ; RCVHIADD- RECEIVED MESSAGE BUFFER HIGH ORDER ADDRESS
1526 ; RCVLOADD- RECEIVED MESSAGE BUFFER LOW ORDER ADDRESS
1527 ;
1528 ;
1529 012350 BGNMSG MSGSTAT
012350 MSGSTAT::
1530 012350 012701 012412 MOV #STATCOD,R1 ;ASCII ADDRESS TABLE
1531 012354 012100 10#: MOV (R1),R0 ;DONE ALL MSG LINES?
1532 012356 001410 BEQ 20# ;BR IF YES
1533 012360 PRINTX R0 ;PRINT STATUS BIT NAMES
012360 010046 MOV R0,-(SP)
012362 012746 000001 MOV #1,-(SP)
012366 010600 MOV SP,R0
012370 104415 TRAP C#PNTX
012372 062706 000004 ADD #4,SP
1534 012376 000766 BR 10# ;DO ANOTHER MSG LINE
1535 012400 012700 000012 20#: MOV #10,R0 ;NUMBER OF WORDS IN A READ STATUS BUFFER
1536 012404 004737 014552 JSR PC,PRMSGEXP ;PRINT EXPD/RCV MESSAGE BUFFERS
1537 012410 ENDMMSG
012410 L10013:
012410 104423 TRAP C#MSG
1538
1539 012412 012430 012472 012563 STATCOD: .WORD 1#,2#,3#,4#,5#,6#,0
1540 012430 045 116 045 1#: .ASCIZ 'ANSA Tape Bus Signals in Word #8:'
1541 012472 045 116 045 2#: .ASCIZ 'ANSA PARERR<15> IEOT <12> IFMK <9> IRDY<6> IRWD<2>'
1542 012563 045 116 045 3#: .ASCIZ 'ANSA IRESV2<14> IIDENT<11> IHER <8> IONL<5> IFBY<1>'
1543 012654 045 116 045 4#: .ASCIZ 'ANSA IRESV1<13> ICER <10> ISPEED<7> ILDP<4> IFPT<0>'
1544 012745 045 116 045 5#: .ASCIZ 'ANSA Tape Bus Signals in Word #9:'
1545 013007 045 116 045 6#: .ASCIZ 'ANSA DATMIS<7> ILW<6> OUTRDY<5> INRDY<4>'
1546 .EVEN
1547

```

```

1549                                     .SBTTL MSGLOOP - PRINT LOOPBACK HEADER AND MESSAGE BUFFERS
1550                                     ;*
1551                                     ;
1552                                     ;PRINT ROUTINE TO PRINT MESSAGE BUFFER EXPD/RCV
1553                                     ;
1554                                     ;IMPLICIT INPUTS:
1555                                     ;
1556                                     ;   EXPMSG - EXPECTED MESSAGE BUFFER
1557                                     ;   RECMMSG - RECEIVED MESSAGE BUFFER
1558                                     ;   RCVHIADD- RECEIVED MESSAGE BUFFER HIGH ORDER ADDRESS
1559                                     ;   RCVLOADD- RECEIVED MESSAGE BUFFER LOW ORDER ADDRESS
1560                                     ;-
1561 013064                               BGNMSG MSGLOOP
1561 013064                               MSGLOOP::
1562 013064 012701 013126                10$: MOV    #LOOPCOD,R1      ;ASCII ADDRESS TABLE
1563 013070 012100                       MOV    (R1)+,R0      ;DONE ALL MSG LINES?
1564 013072 001410                       BEQ    20$          ;BR IF YES
1565 013074                               PRINTX R0          ;PRINT STATUS BIT NAMES
1565 013074 010046                       MOV    R0,-(SP)
1565 013076 012746 000001                MOV    #1,-(SP)
1565 013102 010600                       MOV    SP,R0
1565 013104 104415                       TRAP   C#PNTX
1565 013106 062706 000004                ADD    #4,SP
1566 013112 000766                       BR     10$        ;DO ANOTHER MSG LINE
1567 013114 012700 000012                20$: MOV    #10.,R0    ;NUMBER OF WORDS IN A READ STATUS BUFFER
1568 013120 004737 014552                JSR    PC,PRMSGEXP ;PRINT EXPD/RCV MESSAGE BUFFERS
1569 013124                               ENDMSG
1569 013124                               L10014:
1569 013124 104423                       TRAP   C#MSG
1570
1571 013126 013146 013221 013320        LOOPCOD: .WORD 1$,2$,3$,4$,5$,6$,7$,0
1572 013146 045 116 045 1$: .ASCIZ 'NSA Tape Bus Loopback Signals in Word #8:'
1573 013221 045 116 045 2$: .ASCIZ 'NSA PARERR<15> IRESV2<14> IRESV1<13>'
1574 013320 045 116 045 3$: .ASCIZ 'NSA IHISP=>IEOT<12> IWRT=>IIDENT<11> IREV =>ICER <10>'
1575 013417 045 116 045 4$: .ASCIZ 'NSA IWMF =>IFMK<09> IEDIT=>IHER <08> IFAD =>ISPEED<07>'
1576 013516 045 116 045 5$: .ASCIZ 'NSA ITADO=>IRDY<06> ITAD1=>IONL <05> IERASE=>ILDOP <04>'
1577 013615 045 116 045 6$: .ASCIZ 'NSA IREW =>IDBY<03> IRWU =>IRWD <02> IFEN =>IFBY <01>'
1578 013714 045 116 045 7$: .ASCIZ 'NSA IGO =>IFPT<00>'
1579                                     .EVEN

```

1581				.SBTTL MSGSUB PRINT WRITE SUBSYSTEM MESSAGE BUFFER
1582				;
1583				;
1584				;PRINT ROUTINE TO PRINT MESSAGE BUFFER EXPD/RCV
1585				;
1586				;
1587				;IMPLICIT INPUTS:
1588				;
1589				EXPMSG - EXPECTED MESSAGE BUFFER
1590				RCVMSG - RECEIVED MESSAGE BUFFER
1591				RCVHIADD- RECEIVED MESSAGE BUFFER HIGH ORDER ADDRESS
1592				RCVLOADD- RECEIVED MESSAGE BUFFER LOW ORDER ADDRESS
1593				;
1594	013742			BGNMSG MSGSUB
	013742			MSGSUB:;
1595	013742	012700	000012	MOV @10.,R0 ;SIZE OF WRITE SUBSYSTEM BUFFER
1596	013746	004737	014552	JSR PC,PRMSGEXP ;PRINT EXPD/RCV MESSAGE BUFFERS
1597	013752			ENDMSG
	013752			L10015:
	013752	104423		TRAP C#MSG
1598				
1599				.SBTTL MEMADD - PRINT MEMORY ADDRESS DATA ERROR
1600				;
1601				;
1602				;PRINT ROUTINE TO PRINT MEMORY ADDRESS DATA COMPARE ERROR
1603				;
1604				;IMPLICIT INPUTS:
1605				;
1606				ERRHI - MEMORY ERROR HIGH ORDER ADDRESS
1607				ERRLO - MEMORY ERROR LOW ORDER ADDRESS
1608				EXP - EXPECTED DATA
1609				RCV - RECEIVED DATA
1610				;
1611	013754			BGNMSG MEMADD
	013754			MEMADD:;
1612	013754	004737	010160	JSR PC,PRIADD ;PRINT MEMORY ADDRESS IN ERROR
1613	013760	013701	002232	MOV EXPD,R1 ;GET EXPD DATA
1614	013764	013702	002234	MOV RECV,R2 ;GET RECEIVED DATA
1615	013770	004737	007742	JSR PC,PRIXOR ;PRINT EXPD/RCV
1616	013774			ENDMSG
	013774			L10016:
	013774	104423		TRAP C#MSG

```

1618 .SBTTL PRAMPKT - PRINT RAM AND PACKET DATA
1619 ;
1620 ;PRINT ROUTINE TO DISPLAY RAM/PACKET DATA
1621 ;WHEN THE RAM DATA DOES NOT MATCH.
1622 ;
1623 ;INPUTS:
1624 ;
1625 ; R4 POINTER TO COMMAND PACKET
1626 ;IMPLICIT INPUTS:
1627 ; RAMDATA DATA AS READ FROM THE RAM
1628 ; RAMSIZ NUMBER OF BYTES IN PACKET
1629 ; IF RAMSIZ=0 THEN DEFAULT TO 8.
1630 ;
1631 ;IMPLICIT OUTPUTS:
1632 ; RAMSIZ SET TO 0
1633 ;
1634 PRAMPKT:
1635 SAVREG ;SAVE R1-R5 UNTIL NEXT RETURN
1636 MOV #RAMDATA,R1 ;DATA FROM THE RAM
1637 CLR R2 ;INIT BYTE NUMBER
1638 54: CMB (R1),.(R4). ;COMPARE EXPECTED, RECEIVED
1639 BNE 74 ;BR IF NO MATCH
1640 FORCERROR 74,NOTSSR
1641 BR 104 ;BBD
1642 74: MOVB -1(R1),R5 ;GET RECV RAM DATA
1643 MOVB -1(R4),R3 ;GET EXPD PACKET DATA
1644 XOR R5,R3 ;XOR EXPD/RECV
1645 BIC #177400,R3 ;LOW BYTE ONLY
1646 MOVB -1(R1),RECV ;GET RECEIVED RAM DATA
1647 MOVB -1(R4),EXPD ;GET EXPECTED RAM DATA
1648 PRINTB #RAMASC,R2,RECV,EXPD,R3
1649 MOV R3,-(SP)
1650 MOV EXPD,-(SP)
1651 MOV RECV,-(SP)
1652 MOV R2,-(SP)
1653 MOV #RAMASC,-(SP)
1654 MOV #5,-(SP)
1655 MOV SP,R0
1656 TRAP C@PNTB
1657 ADD #14,SP
1658 104: INC R2 ;UPDATE BYTE COUNT
1659 TST RAMSIZ ;DEFAULT TO 8.?
1660 BEQ 154 ;BR IF YES
1661 CMP R2,RAMSIZ ;DONE ALL BYTES?
1662 BLE 54 ;BR IF NO
1663 BR 254 ;
1664 154: CMP R2,#8. ;DONE DEFAULT NUMBER OF BYTES?
1665 BLT 54 ;BR IF NO
1666 254: CLR RAMSIZ ;SET DEFAULT RAMSIZ
1667 RTS PC ;RETURN
1668 ;
1669 045 116 045 RAMASC: .ASCIZ '##A BYTE: #02#A RAM: #03#A Packet: #03#A XOR:#03'
1670 .EVEN
1671

```

```

1663 .SBTTL PRMESS - PRINT CONTENTS OF MESSAGE BUFFER
1664 ;
1665 ; THIS ROUTINE PRINTS THE CONTENTS OF
1666 ; THE 7 OR 8 WORD MESSAGE BUFFER RETURNED BY THE TSV-05.
1667 ;
1668 ; INPUT:
1669 ; R0 LOW ORDER ADDRESS OF MESSAGE BUFFER
1670 ; R1 HIGH ORDER ADDRESS OF MESSAGE BUFFER
1671 ; NOTE: R1 IS IGNORED IF KTENABLE FLAG IS CLEAR
1672 ; THIS ROUTINE IS NORMALLY CALLED FROM A PRINT ROUTINE
1673 ;
1674 PRMESS: SAVREG ;SAVE THE REGISTERS
1675 MOV R0,R5 ;SAVE LOW ORDER ADDRESS
1676 TST KTENABLE ;ADDRESS ABOVE 28K?
1677 BNE 101 ;BR IF YES
1678 CLR R1 ;SET HIGH ORDER ADDRESS TO 0
1679 101: MOV R1,R3 ;SAVE HIGH ORDER ADDRESS
1680 ROL R0 ;SHIFT BIT15 TO C BIT
1681 ROL R1 ;SHIFT TO HIGH ORDER FOR PRINTOUT
1682 PRINTX @PROASC,R1,R5 ;PRINT MESSAGE BUFFER ADDRESS
1683 MOV R5,-(SP)
1684 MOV R1,-(SP)
1685 MOV @PROASC,-(SP)
1686 MOV @3,-(SP)
1687 MOV SP,R0
1688 TRAP CIPNTX
1689 ADD #10,SP
1690 PRINTX @PRIASC ;PRINT HEADER FOR CONTENTS
1691 MOV @PRIASC,-(SP)
1692 MOV #1,-(SP)
1693 MOV SP,R0
1694 TRAP CIPNTX
1695 ADD #4,SP
1696 CLR R4 ;NUMBER OF THE NEXT WORD
1697 MOV R5,R1 ;COPY LOW ORDER ADDRESS
1698 MOV R3,R0 ;COPY HIGH ORDER ADDRESS
1699 BEQ 201 ;BR IF NOT ABOVE 28K
1700 JSR PC,SETHAP ;SETUP PAR ADDRESS IN R0
1701 MOV R0,R5 ;GET PAR FORMAT ADDRESS ABOVE 28K
1702 201: PRINTX @PRASC,R4,(R5) ;PRINT THE CONTENTS OF MEMORY BUFFER
1703 MOV (R5),-(SP)
1704 MOV R4,-(SP)
1705 MOV @PRASC,-(SP)
1706 MOV @3,-(SP)
1707 MOV SP,R0
1708 TRAP CIPNTX
1709 ADD #10,SP
1710 INC R4 ;NUMBER OF THE NEXT
1711 CMP R4,#7 ;DONE ALL YET ?
1712 BGT 501 ;BRANCH IF ALL DONE
1713 BLT 201 ;PRINT FIRST 7 WORDS
1714 BIT #X2.EXTF,XST2(R3),EXTENDED FEATUTES ON ?
1715 BNE 201 ;PRINT EXTENDED STATUS WORD
1716 501: RTS PC ;RETURN
1717 045 PROASC: .ASCIZ 'ANSA Message Buffer Address = #01#05'
1718 045 PRIASC: .ASCIZ 'ANSA Message Buffer Contents:'
1719 045 PRASC: .ASCIZ 'ANSA Word#D1#A: #0'

```

```

1702          .EVEN
1703          .SBITL PRMSGEXP - PRINT EXPD/RCV MESSAGE BUFFERS
1704          ;*
1705          ;ROUTINE TO PRINT EXPECTED AND RECEIVED MESSAGE BUFFERS
1706          ;      RO      - NUMBER OF WORDS IN BUFFER
1707          ;IMPLICIT INPUTS:
1708          ;      EXPMSG  - EXPECTED MESSAGE BUFFER
1709          ;      RECMMSG - RECEIVED MESSAGE BUFFER
1710          ;      RCVHIADD- RECEIVED MESSAGE BUFFER HIGH ORDER ADDRESS
1711          ;      RCVLOADD- RECEIVED MESSAGE BUFFER LOW ORDER ADDRESS
1712          ;
1713          PRMSGEXP::
1714          SAVREG          ;SAVE R1-R5 UNTIL NEXT RETURN
1715          MOV            R0,R5          ;SAVE NUMBER OF WORDS
1716          MOV            RCVLOADD,R0   ;GET RECV LOW ADDRESS
1717          MOV            R0,R4          ;COPY LOW ADDRESS
1718          MOV            RCVHIADD,R1   ;GET RECV HIGH ADDRESS
1719          ROL            R0             ;SHIFT BIT15 TO C BIT
1720          ROL            R1             ;SHIFT TO HIGH ORDER FOR PRINTOUT
1721          PRINTX        @PRMSG0,R1,R4  ;PRINT MESSAGE BUFFER ADDRESS
1722          MOV            R4,-(SP)
1723          MOV            R1,-(SP)
1724          MOV            @PRMSG0,-(SP)
1725          MOV            @3,-(SP)
1726          MOV            SP,R0
1727          TRAP          C:PNTX
1728          ADD            @10,SP
1729          PRINTX        @PRMSG1          ;PRINT HEADER FOR CONTENTS
1730          MOV            @PRMSG1,-(SP)
1731          MOV            @1,-(SP)
1732          MOV            SP,R0
1733          TRAP          C:PNTX
1734          ADD            @4,SP
1735          CLR            R4             ;NUMBER OF THE CURRENT WORD
1736          MOV            @EXPMSG,R1     ;GET EXPD BUFFER ADDRESS
1737          MOV            @RECMMSG,R2   ;GET RECV BUFFER ADDRESS
201:          MOV            (R1),R0      ;GET EXPD
1738          MOV            (R2),R3      ;GET RECV
1739          XOR            R0,R3         ;XOR EXPD/RCV
1740          PRINTX        @PRMSG2,R4,(R1),.(R2),.R3
1741          MOV            R3,-(SP)
1742          MOV            (R2),.-.(SP)
1743          MOV            (R1),.-.(SP)
1744          MOV            R4,-(SP)
1745          MOV            @PRMSG2,-(SP)
1746          MOV            @5,-(SP)
1747          MOV            SP,R0
1748          TRAP          C:PNTX
1749          ADD            @14,SP
1750          INC            R4             ;NUMBER OF THE NEXT
1751          CMP            R4,R5         ;DONE ALL YET?
1752          BGE            501          ;BR IF YES
1753          BR            201          ;DO ANOTHER
1754          RTS            PC           ;RETURN
1755          045          PRMSG0: .ASCIZ  '##A Message Buffer Address = #01#05'
1756          045          PRMSG1: .ASCIZ  '##A Message Buffer Contents:'
1757          045          PRMSG2: .ASCIZ  '##A WORD #02#A EXPD: #06#A RECV: #06#A XOR: #0#A'

```

```

1739 .EVEN
1740 .SBTTL PRBYTEXP - PRINT ERROR BYTES IN EXP/REC MESSAGE BUFFER
1741 ;*
1742 ;
1743 ;ROUTINE TO PRINT ERROR BYTES IN MESSAGE BUFFERS
1744 ; ONLY THE FIRST 8 ERRORS ENCOUNTERED ARE PRINTED DUE TO SCREEN SPACE
1745 ;
1746 ; RO - NUMBER OF BYTES IN BUFFER
1747 ;
1748 ;IMPLICIT INPUTS:
1749 ;
1750 ; EXPMSG - EXPECTED MESSAGE BUFFER
1751 ; RECMMSG - RECEIVED MESSAGE BUFFER
1752 ;-
1753 PRBYTEXP::
1753 015127 SAVREG ;SAVE R1-R5 UNTIL NEXT RETURN
1754 015122 MOV RO,R5 ;SAVE NUMBER OF BYTES
1755 015126 010005 CLR PRMNO ;INIT ERROR COUNT
1756 015130 005037 002320 CLR R4 ;NUMBER OF THE CURRENT BYTE
1757 015134 005004 MOV #EXPMSG,R1 ;GET EXPD BUFFER ADDRESS
1758 015136 012701 002322 MOV #RECMMSG,R2 ;GET RECV BUFFER ADDRESS
1759 015142 012702 002466 20: MOVB (R1),R0 ;GET EXPD BYTE
1760 015146 111100 BIC #C<377>,R0 ;CLEAR UPPER BYTE
1761 015150 042700 177400 MOVB R0,PRBEXP ;SAVE FOR ERROR REPORT
1762 015154 110037 015470 MOVB (R2),R3 ;GET RECV BYTE
1763 015160 111203 BIC #C<377>,R3 ;CLEAR UPPER BYTE
1764 015162 042703 177400 MOVB R3,PRBREC ;FOR ERROR REPORT
1765 015166 110337 015472 XOR R0,R3 ;XOR EXPD/RECV
1766 015172 CMPB (R1),R3 ;EXPD = RECV?
1767 015202 122122 BEQ 30: ;BR IF YES
1768 015204 001431 INC PRMNO ;UPDATE ERROR COUNT
1769 015206 005237 002320 CMP PRMNO,#8. ;PRINTED 8?
1770 015212 023727 002320 000010 BHI 30: ;BR IF YES
1771 015220 101023 27: PRINTX #PRBMSG,R4,PRBEXP,PRBREC,R3
1772 015222 010346 MOV R3,-(SP)
1773 015224 013746 015472 MOV PRBREC,-(SP)
1774 015230 013746 015470 MOV PRBEXP,-(SP)
1775 015234 010446 MOV R4,-(SP)
1776 015236 012746 015336 MOV #PRBMSG,-(SP)
1777 015242 012746 000005 MOV #5,-(SP)
1778 015246 010600 MOV SP,R0
1779 015250 104415 TRAP C:PNTX
1780 015252 062706 000014 ADD #14,SP
1781 015256 000404 FORCEXIT 50: ;880
1782 015266 000404 BR 35: ;880
1783 015270 30: FORCERROR 27:,NOTSSR ;880
1784 015270 35: ;880
1785 015300 INC R4 ;NUMBER OF THE NEXT
1786 015300 005204 CMP R4,R5 ;DONE ALL YET?
1787 015302 020405 BGE 50: ;BR IF YES
1788 015304 002001 BR 20: ;DO ANOTHER
1789 015306 000717 50: PRINTX #PRBTOT,PRMNO ;PRINT TOTAL ERROR COUNT
1790 015310 013746 002320 MOV PRMNO,-(SP)
1791 015314 012746 015423 MOV #PRBTOT,-(SP)
1792 015320 012746 000002 MOV #2,-(SP)
1793 015324 010600 MOV SP,R0

```

```

015326 104415 TPAP C#PNTX
015330 062706 000006 ADG #6.SP
1783 015334 000207 RTS PC ;RETURN
1784
1785 015336 045 116 045 PRBMSG: .ASCIZ '##A BYTE #02#A EXPD: #03#A RECV: #03#A XOR: #03'
1786 015423 045 116 045 PRBTOT: .ASCIZ '##A NUMBER OF BYTES IN ERROR = #02'
1787
1788 015470 000000 PRBEXP: .WORD 0 ;EXPD
1789 015472 000000 PRBREC: .WORD 0 ;RECV
1790
1791 ;*
1792 ;
1793 ;PRINT ROUTINE TO DISPLAY EXPD/RECV DATA
1794 ;
1795 ;INPUTS:
1796 ;
1797 ; R1 RECEIVED DATA
1798 ; R2 EXPECTED DATA
1799 ;
1800 ;
1801
1802 015474 BGNMSG EXPREC
015474 EXPREC:: JSR PC,PRIXOR ;PRINT THE DATA
1803 015474 004737 007742 ENDMSG
1804 015500 L10017:
015500 TRAP C#MSG
015500 104423 .SBTTL EXPBREC - PRINT EXPD/RECV BYTE DATA
1805
1806 ;*
1807 ;
1808 ;PRINT ROUTINE TO DISPLAY BYTE EXPD/RECV DATA
1809 ;
1810 ;
1811 ;INPUTS:
1812 ;
1813 ; R1 RECEIVED DATA BYTE
1814 ; R2 EXPECTED DATA BYTE
1815 ;
1816 ;-
1817
1818 015502 BGNMSG EXPBREC
015502 EXPBREC:: JSR PC,PRIBXOR ;PRINT THE DATA
1819 015502 004737 007612 ENDMSG
1820 015506 L10020:
015506 TRAP C#MSG
015506 104423
1821
1822 ;*
1823 ;
1824 ;PRINT ROUTINE TO DISPLAY RAM/PACKET DATA
1825 ;
1826 ;
1827 ;INPUTS:
1828 ;
1829 ; R4 POINTER TO COMMAND PACKET
1830 ;
1831 ;
  
```



```

1832      ;IMPLICIT INPUTS:
1833      ;
1834      ;       RAMDATA      DATA AS READ FROM THE RAM
1835      ;       RAMSIZ      NUMBER OF BYTES IN PACKET
1836      ;                       IF RAMSIZ=0 THEN DEFAULT TO 8.
1837      ;
1838      ;IMPLICIT OUTPUTS:
1839      ;
1840      ;       RAMSIZ  SET TO 0
1841      ;
1842      ;
1843      ;       BGNMSG  RAMERR
1844      ;       RAMERR: JSR   PC,PRAMPKT      ;PRINT RAM/PACKET DATA
1845      ;               ENDMSG
1846      ;       L10021: TRAP  C#MSG
1847      ;               .SBTTL  RAMTADD - PRINT TEST ADDRESS, RAM AND PACKET DATA
1848      ;
1849      ;
1850      ;PRINT ROUTINE TO DISPLAY RAM/PACKET DATA
1851      ;
1852      ;INPUTS:
1853      ;
1854      ;       R4      POINTER TO COMMAND PACKET
1855      ;
1856      ;IMPLICIT INPUTS:
1857      ;
1858      ;       RAMDATA      DATA AS READ FROM THE RAM
1859      ;       RAMSIZ      NUMBER OF BYTES IN PACKET
1860      ;                       IF RAMSIZ=0 THEN DEFAULT TO 8.
1861      ;       ERRHI      HIGH ORDER TEST ADDRESS
1862      ;       ERRLO      LOW ORDER TEST ADDRESS
1863      ;
1864      ;IMPLICIT OUTPUTS:
1865      ;
1866      ;       RAMSIZ  SET TO 0
1867      ;
1868      ;
1869      ;       BGNMSG  RAMTADD
1870      ;       RAMTADD: JSR   PC,PRITADD      ;PRINT TEST ADDRESS
1871      ;               JSR   PC,PRAMPKT      ;PRINT RAM/PACKET DATA
1872      ;               ENDMSG
1873      ;       L10022: TRAP  C#MSG
1874      ;               .SBTTL  RAMEXP - PRINT RAM EXPD/RECV DATA
1875      ;
1876      ;
1877      ;PRINT ROUTINE TO DISPLAY EXPD/RECV DATA
1878      ;
1879      ;INPUTS:
1880      ;
1881      ;       R1      RECEIVED DATA
1882      ;       R2      EXPECTED DATA

```

```

1883      ;      R4      CONTROLLER RAM ADDRESS
1884      ;
1885
1886 015530      BGNMSG  RAMEXP
1887 015530      RAMEXP::
1887 015530 042701 177400      BIC      @C<377>,R1      ;SAVE EXPD RAM DATA BYTE
1888 015534 042702 177400      BIC      @C<377>,R2      ;SAVE EXPD RAM DATA BYTE
1889 015540 004737 010066      JSR      PC,PRIRAM      ;PRINT THE RAM ADDRESS
1890 015544 004737 007742      JSR      PC,PRIXOR      ;PRINT THE DATA
1891 015550      ENDMSG
1891 015550      L10023:
1891 015550 104423      TRAP      C#MSG
1892
1893      .SBTTL  TIMEXP - PRINT TIMER A,B AND EXP/REC
1894      ;*
1895      ;
1896      ;PRINT ROUTINE TO DISPLAY EXPD/RECV DATA
1897      ;AND TIMER A,B HEADER MESSAGE
1898      ;
1899      ;INPUTS:
1900      ;
1901      ;      R1      RECEIVED DATA
1902      ;      R2      EXPECTED DATA
1903      ;-
1904
1905 015552      BGNMSG  TIMEXP
1906 015552      TIMEXP::
1906 015552      PRINTX  @TIMSGO      ;PRINT HEADER
1906 015552 012746 015600      MOV      @TIMSGO,-(SP)
1906 015556 012746 000001      MOV      #1,-(SP)
1906 015562 010600      MOV      SP,R0
1906 015564 104415      TRAP      C#PNTX
1906 015566 062706 000004      ADD      #4,SP
1907 015572 004737 007742      JSR      PC,PRIXOR      ;PRINT THE DATA
1908 015576      ENDMSG
1908 015576      L10024:
1908 015576 104423      TRAP      C#MSG
1909
1910 015600      045      116      045  TIMSGO: .ASCIZ  'TIMER A STATUS IS IN BIT 3/TIMER B STATUS IS IN BIT 2'
1911      .EVEN
1912      .SBTTL  BADSSR - PRINT TSSR ERRORS ON DATA TRANSFERS
1913      ;*
1914      ;
1915      ;PRINT ROUTINE FOR TSSR ERRORS ON DATA TRANSFERS
1916      ;
1917      ;INPUTS:
1918      ;
1919      ;      R1      CONTENTS OF TSSR
1920      ;      R2      DATA WRITTEN (8 BITS)
1921      ;
1922      ;-
1923
1924
1925 015700      BGNMSG  BADSSR
1926 015700      BADSSR::
1926 015700 010246      MOV      R2,-(SP)      ;SAVE DATA TRANSFERRED
1927 015702 042702 177400      BIC      @177400,R2      ;GET JUST ONE BYTE

```

```

1928 015706          PRINTB  #XFERASC,R2
      015706 010246    MOV      R2,-(SP)
      015710 012746 015740  MOV      #XFERASC,-(SP)
      015714 012746 000002  MOV      #2,-(SP)
      015720 010600    MOV      SP,R0
      015722 104414    TRAP     C#PNTB
      015724 062706 000006  ADD      #6,SP
1929 015730 012602    MOV      (SP),R2          ;RESTORE R2
1930 015732 004737 006024  JSR      PC,PRITSSR      ;DECODE TSSR CONTENTS
1931 015736          ENDMSG
      015736          L10025:
      015736 104423    TRAP     C#MSG
1932 015740 045      116  045  XFERASC: .ASCIZ  '#N#A Data Transferred = #03'

```

```

1934      .SBTTL GLOBAL SUBROUTINES SECTION
1935
1936      ;**
1937      ; THE GLOBAL SUBROUTINES SECTION CONTAINS THE SUBROUTINES
1938      ; THAT ARE USED IN MORE THAN ONE TEST.
1939      ;
1940      ;       .SBTTL SOFINIT - SOFT INITIALIZE OF CONTROLLER
1941
1942      ;*
1943      ;
1944      ;ROUTINE TO DO A SOFT INITIALIZE OF THE CONTROLLER
1945      ;BY WRITING INTO THE TSSR REGISTER. AFTER THE INIT,
1946      ;THE TSSR REGISTER IS TESTED FOR ERRORS. ANY ERRORS
1947      ;DETECTED SHOULD BE TREATED AS DEVICE FATAL ERRORS.
1948      ;
1949      ;INPUTS:
1950      ;
1951      ;       R5       ADDRESS OF FIRST REGISTER
1952      ;
1953      ;OUTPUTS:
1954      ;
1955      ;       R0       CONTENTS OF TSSR, IF ERROR
1956      ;       CARRY   SET IF INIT WAS OKAY
1957      ;               CLEAR IF FATAL ERROR
1958      ;
1959      ;CALLING SEQUENCE:
1960      ;
1961      ;       MOV      #ADDRESS,R5
1962      ;       JSR      PC,SOFINIT
1963      ;       BCS      CONTINUE
1964      ;       ERRDF                    ;REPORT FATAL ERROR
1965      ;
1966      ;-
1967
1968 015774 SOFINIT::
1969 015774      SAVREG                    ; SAVE THE REGISTERS
1970 016000      MOV      #0,TSSR(R5)      ; DO THE INIT.
1971 016006      JSR      PC,WAITF        ; WAIT FOR SSR
1972 016012      MOV      TSSR(R5),R0    ;GET THE TSSR REGISTER
1973 016016      MOV      R0,R4          ;TSSR CONTENTS
1974 016020      BIC      #+C<HIADDR!OFL>,R4
1975 016024      BIS      #SSR!NBA,R4   ;R4 HAS EXPECTED CONTENTS
1976 016030      CMP      R4,R0         ;ONLY EXPECTED BITS SET ?
1977 016032      BEQ      5$            ;BRANCH IF OKAY
1978 016034      CLC                    ;CLEAR THE CARRY FOR ERROR
1979 016036      BR      10$            ;GO TO EXIT
1980 016040      5$:   SEC              ;SET THE CARRY BIT
1981 016042      10$:  RTS      PC       ;RETURN TO CALLER
    
```

```

1983 .SBTTL CHKAMB - CHECK TSSR FOR AMBIGUITY
1984
1985
1986
1987 ; THIS ROUTINE TESTS THE CONTENTS OF THE TSSR REGISTER
1988 ; FOR AMBIGUITY
1989
1990 ; INPUT:
1991
1992 ; R0 CONTENTS OF TSSR
1993
1994 ; OUTPUT:
1995
1996 ; R0 CONTENTS OF TSSR
1997
1998 ; CARRY SET - NO AMBIGUITY
1999 ; CLR AMBIGUOUS CONTENTS
2000
2001
2002
2003 CHKAMB: SAVREG ; SAVE THE GENERAL REGISTERS
2004 016044 MOV R0,R4 ; CONTENTS OF TSSR
2005 016050 010004 BIT #SC,R0 ; IS BIT 15 SET ?
2006 016052 032700 100000 BNE 5# ; BRANCH IF YES
2007 016056 001004 BIT #C<NBA!OFL!SSR!HIADDR>,R0 ; ANY OTHER BITS SET ?
2008 016060 032700 174077 BNE 40# ; MUST BE AN ERROR
2009 016064 001023 BR 45# ; RETURN WITH SUCCESS
2010 016066 000424 5#: BIT #SSR,R0 ; IS READY BIT SET ?
2011 016070 032700 000200 BNE 10# ; BRANCH IF READY BIT IS SET.
2012 016074 001011 BIT #BIT5,R0 ; IS FATAL ERROR BIT SET ?
2013 016076 032700 000040 BEQ 40# ; ERROR IF NOT
2014 016102 001414 BIC #CTERCLS,R4 ; CLEAR ALL BUT TERMINATION CODE
2015 016104 042704 177761 CMP R4,#16 ; ALL THREE BITS MUST BE SET
2016 016110 020427 000016 BNE 40# ; ERROR IF NOT SET
2017 016114 001007 BR 45# ; OK IF ALL ARE SET
2018 016116 000410 10#: BIT #BIT5,R0 ; IS FATAL ERROR BIT SET ?
2019 016120 032700 000040 BEQ 45# ; ERROR IF BIT IS SET WITH SSR
2020 016124 001405 BIT #BIT2!BIT1,R0 ; IS THIS A FUNCTION REJECT
2021 016126 032700 000006 BNE 45# ; BR, IF TSSR IS OK
2022 016132 001002 40#: CLC ; AMBIGUOUS CONTENTS
2023 016134 000241 BR 50#
2024 016136 000401 45#: SEC ; SHOW SUCCESS - NO AMBIGUITY
2025 016140 000261 50#: RTS PC ; RETURN TO CALLER
2026 016142 000207

```

```

2028      .SBTTL ENAIN,DSBINT  ENABLE/DISABLE INTERRUPTS
2029      ;
2030      ; DEFAULT DISPLAY INTERRUPT HANDLERS.
2031      ; IF DISPLAY TIME-OUT, REPORT DEV FATAL, AND ABORT PASS.
2032      ; OTHERWISE, SAVE DPU REGISTERS AND DISMISS.
2033      ;
2034      ;
2035      ; BIT DEFINITIONS FOR "INTMASK" AND "INTFLAG" BYTES:
2036      ;
2037      ;       IOKCKIN=BIT7   ; DON'T CHECK FOR BAD INTERRUPTS -- TEST WILL.
2038      ;       IOKSTP=BIT0   ; EXPECT "STOP" INTERRUPT.
2039      ;
2040      ; INTERRUPT MASK -- SAYS EXPECTING INTERRUPTS
2041      ENAIN 016144      000      INTMASK:      .BYTE 0
2042      ; INTERRUPT FLAG -- SAYS WE GOT ONE (IF POSITIVE)
2043      ENAIN 016145      000      INTFLAG:     .BYTE 0
2044      ;
2045      ; SAVED INTERRUPT VECTOR:
2046      ENAIN 016146      000000    INTVEC:      .WORD 0
2047      ; SAVE CPU PC
2048      ENAIN 016150      000000    INTCPC:     .WORD 0
2049      ;
2050      ; SUBROUTINE TO ENABLE INTERRUPTS:
2051      ENAIN 016152      010046      ENAIN:      MOV      RO,-(SP)      ;SAVE RO
2052      ENAIN 016154      013700      002210      MOV      IVEC,RO      ;GET POINTER TO VECTORS
2053      ENAIN 016160      012720      016216      MOV      @INTR,(RO)+  ;SET UP INTERRUPT VECTOR
2054      ENAIN 016164      012720      000340      MOV      @PRI07,(RO)+
2055      ENAIN 016170      012600      MOV      (SP)+,RO      ;RESTORE RO
2056      ENAIN 016172      011646      MOV      (SP),-(SP)
2057      ENAIN 016174      012766      000000      000002      MOV      @0,2(SP)      ;SET CPU TO LEVEL 0
2058      ENAIN 016202      000002      RTI
2059      ;
2060      ; SUBROUTINE TO DISABLE INTERRUPTS (RAISE PRIORITY TO LEVEL 7)
2061      ENAIN 016204      011646      DSBINT:     MOV      (SP),-(SP)
2062      ENAIN 016206      012766      000340      000002      MOV      @PRI07,2(SP)
2063      ENAIN 016214      000002      RTI
2064      ;
2065      ;
2066      ENAIN 016216      016216      BGNSRV     INTR      ;DEFINE INTERRUPT ENTRY
2067      ENAIN 016216      012737      000001      002224      INTR::     MOV      @1,INTRECV    ;SET FLAG TO SHOW INTERRUPT RECEIVED
2068      ENAIN 016224      105037      016145      CLR      INTFLAG      ;CLEAR FLAG TO SAY WE GOT INTERRUPT
2069      ENAIN 016230      132737      000001      016144      BIT      @IOKSTP,INTMASK ;EXPECTING STOP INTERRUPT?
2070      ENAIN 016236      001003      BNE      1$           ;BR IF YES
2071      ENAIN 016240      152737      000001      016145      BIS      @IOKSTP,INTFLAG ;NO. SET THE ERROR FLAG.
2072      ;
2073      ; SAVE REGISTERS, MSG BUFFER, ETC.
2074      ENAIN 016246      1$:
2075      ENAIN 016246      016246      ENDSRV
2076      ENAIN 016246      000002      L10026:    RTI

```

```

2077          .SBTTL WAITF - WAIT FOR SUBSYSTEM READY
2078          ;
2079          ; SUBROUTINE TO WAIT FOR THE SUBSYSTEM READY FLAG
2080          ;
2081          ; INPUTS:
2082          ;
2083          ;     R5     ADDRESS OF FIRST DEVICE REGISTER
2084          ;
2085          ; OUTPUTS:
2086          ;
2087          ;     R0     CONTENTS OF LAST TSSR READ
2088          ;     CARRY  SET - READY BIT SET
2089          ;           CLR - TIMEOUT WAITING FOR READY
2090          ;
2091          WAITF:: BR      1$          ;NOP WHEN SUPER FIXED
2092          016250 000401          ; DO A SUPVSR BREAK FIRST.
                016252 104422
                016254 012746 011000
2093          016254 012746 011000 1$:  MOV    #11000,-(SP)  ;25-APRIL-83 REV B - 1100 MSEC TIMER
2094          016260 016500 000002 2$:  MOV    TSSR(R5),R0  ;READ THE TSSR REGISTER
2095          016264 105700          ;TEST FOR READY BIT SET
2096          ;
2097          016266 100420          BMI    3$          ; EXIT ON STOP FLAG.
2098          016270          DELAY 1          ; WAIT 100 USEC
                016270 012727 000001  MOV    #1,(PC)+
                016274 000000          .WORD 0
                016276 013727 002116  MOV    L#DLY,(PC)+
                016302 000000          .WORD 0
                016304 005367 177772  DEC    -6(PC)
                016310 001375          BNE    -.4
                016312 005367 177756  DEC    -22(PC)
                016316 001367          BNE    -.20
2099          016320 005316          DEC    (SP)          ;REDUCE DELAY COUNT
2100          016322 001356          BNE    2$          ;RETRY UNTIL TIMER EXPIRES
2101          016324 000241          CLC          ; C = 0, CONTROLLER STILL RUNNING...
2102          016326 000401          BR      4$          ;...OR HUNG-UP AFTER 300 MSEC.
2103          016330 000261          3$:  SEC          ; C = 1, CONTROLLER IS STOPPED.
2104          016332 005326          4$:  DEC    (SP)+      ;RESTORE STACK WITHOUT CHANGING CARRY BIT
2105          016334 000207          RTS    PC

```

```

2107 .SBTTL CHKTSSR - CHECK TSSR FOR READY
2108 ;*
2109 ; THIS ROUTINE WAITS FOR READY IN THE TSSR
2110 ; AND TESTS FOR AMBIGUOUS BIT SETTINGS IN TSSR.
2111 ;
2112 ; INPUT:
2113 ; R5 ADDRESS OF CSR REGISTERS
2114 ;
2115 ; OUTPUT:
2116 ; R0 CONTENTS OF TSSR
2117 ; CARRY SET - OKAY
2118 ; CLR - NOT READY AMBIGUOUS, OR SC SET
2119 ;
2120 CHKTSSR:
2121 016336 004737 016250 JSR PC, WAITF ; WAIT FOR READY
2122 016342 103014 BCC 20$ ; BRANCH IF TIME OUT
2123 016344 004737 016044 JSR PC, CHKAMB ; TSSR AMBIGUOUS?
2124 016350 103006 BCC 10$ ; BR IF YES
2125 016352 032700 100000 BIT #SC, R0 ; SPECIAL CONDITION SET?
2126 016356 001405 BEQ 15$ ; BR IF NO
2127 016360 032700 074000 BIT #<SCE!BIE!RMR!NXM>, R0 ; ANY ERROR BITS SET?
2128 016364 001402 BEQ 15$ ; BR IF NO
2129 016366 000241 10$: CLC ; SET FAILURE
2130 016370 000401 BR 20$ ;
2131 016372 000261 15$: SEC ; SET SUCCESS
2132 016374 000207 20$: RTS PC ; RETURN TO CALLER
2133 .SBTTL XNXM - CHECK FOR NONEXISTENT MEMORY
2134 ;*
2135 ; ROUTINE TO TEST FOR A NEXM IN THE RANGE (R1) THRU (R2).
2136 ; ON RETURN, IF "C" = 1, (R1) = NEXM ADDRESS.
2137 ; "C" = 0, ALL ADDRESSES OK.
2138 ;
2139 ; CALL: MOV ADR1, R1
2140 ; MOV ADR2, R2
2141 ; JSR PC, NXM
2142 ; RETURN ; TEST "C" AND PROCEED.
2143 016376 012737 016430 000004 XNXM: MOV #2$, @#4 ; SET BUSERR VECTOR.
2144 016404 012737 000200 000006 MOV #PRI04, @#6
2145 016412 005003 CLR R3 ; FLAG.
2146 016414 005711 1$: TST (R1) ; TEST THE ADDRESS(ES).
2147 ; IF ANY TRAP, CONTINUE AT 2$.
2148 016416 020102 CMP R1, R2 ; OTHERWISE, CONTINUE HERE.
2149 016420 001407 BEQ 3$ ; BR IF FINISHED (NO NEXM'S).
2150 016422 062701 000002 ADD #2, R1 ; SET NEXT ADDRESS...
2151 016426 000772 BR 1$ ; ...AND CONTINUE.
2152 016430 005103 2$: COM R3 ; GO+ ONE, SET FLAG...
2153 016432 012716 016440 MOV #3$, (SP)
2154 016436 000002 RTI ; ...AND DISMISS INTERRUPT...
2155 016440 3$: CLRVEC #4 ; ...AND GIVE BACK THE VECTOR.
2156 016440 012700 000004 MOV #4, R0
2157 016444 104436 TRAP C#CVEC
2158 016446 005703 TST R3 ; DID WE CATCH ONE ??
2159 016450 001401 BEQ .+4 ; NO, "C" = 0, SKIP NEXT.
2158 016452 000261 SEC ; YES, "C" = 1, (R1) = NEXM ADDR.
2159 016454 000207 RTS PC
    
```



2161  
 2162  
 2163  
 2164  
 2165  
 2166  
 2167  
 2168  
 2169 016456  
 2170 016456 005737 002170  
 2171 016462 001006  
 2172 016464 005737 002204  
 2173 016470 100403  
 2174 016472 005337 002216  
 2175 016476 001002  
 2176 016500 000241  
 2177 016502 000401  
 2178 016504 000261  
 2179 016506 000207  
 2180  
 2181  
 2182  
 2183  
 2184  
 2185  
 2186  
 2187  
 2188  
 2189  
 2190  
 2191  
 2192  
 2193  
 2194  
 2195  
 2196  
 2197  
 2198  
 2199  
 2200  
 2201  
 2202  
 2203  
 2204  
 2205  
 2206  
 2207 016510  
 2208 016510 010046  
 2209 016512 005037 003154  
 2210 016516 005037 016756  
 2211 016522 005037 005772  
 2212 016526 105037 016144  
 2213 016532 013700 002202  
 2214 016536 006300  
 2215 016540 005737 003114  
 2216 016544 001430  
 2217 016546 100010

```

.SBTTL TSTLOOP - CHECK ITERATION COUNT
;
; SUBROUTINE TO EXECUTE TEST ITERATIONS.
; EXIT WITH "C" SET IF LOOPS ALLOWED AND LOOP COUNT NON-ZERO.
; LOOP COUNTER IS SET BY "BEGIN.TEST" MACRO.
;
; CALL: LOOPTO ARG
;
TSTLOOP::
    TST     NOITS           ; ITERATIONS INHIBITED?
    BNE     1#             ; YES.
    TST     QVP            ; NO.
    BMI     1#             ; LOOPS DISALLOWED IN QUICK PASS.
    DEC     LOOPCNT        ; BUMP LOOP COUNTER.
    BNE     2#
1#:      CLC                ; LOOP DISALLOWED, OR DONE.
        BR      3#
2#:      SEC                ; LOOP ENABLED.
3#:      RTS     PC

.SBTTL TSTSETUP - PRINT TEST NAME AND INIT ERROR COUNTS
;
; PRINT THE NUMBER AND NAME OF EACH TEST AS WE GO ALONG.
; INCREMENT "TESTK" TO INDICATE THE NUMBER OF TESTS
; IN THE CURRENT RUN SEQUENCE.
; CLEAR THE ERROR COUNTER AND SIGNATURE EXTENSION FLAGS.
;
; INPUT:
;
;     R0     POINTER TO TEST ID ASCIZ STRING
;
; OUTPUT:
;
;     R5     ADDRESS OF FIRST DEVICE REGISTER
;
; IMPLICIT OUTPUTS:
;
;     TSTCNT UPDATED TO COUNT TESTS PERFORMED SINCE START OR RESTART
;
; SIDE EFFECTS:
;
;     INTERRUPT LEVEL IS RASIED TO LEVEL OF
;     THE DEVICE UNDER TEST
;
;
TSTSETUP::
    MOV     R0, -(SP)      ; SAVE THE TEST ID MESSAGE
    CLR     SIFLAG        ; CLEAR "SOFT INIT" FLAG
    CLR     ERRK          ; CLEAR LOCAL ERROR COUNTER.
    CLR     EXTA          ; CLEAR ERROR EXTENSION FLAG.
    CLR     INTMASK       ; CLEAR INTERRUPT MASK (CHECK ERROR)
    MOV     UNITN, R0     ; GET THE UNIT NUMBER,
    ASL     R0            ; ... AND MAKE IT A WORD OFFSET.
    TST     NODEV         ; DID STA.TUP FIND THE DEVICE?
    BEQ     4#           ; BR IF YES
    BPL     3#           ; BR IF NOT IDLE
    
```

```

2218 016550 052760 160000 003176 BIS @160000,ERTABL(R0) ; FLAG ERROR IN THE ERROR TABLE
2219 016556 104455 ERROF 1,NXR,NXRERR ; NO DEVICE HERE PRINT IT
016556 104455 TRAP CIEROF
016560 000001 .WORD 1
016562 003740 .WORD NXR
016564 005736 .WORD NXRERR
2220 016566 000407 BR 2;
2221 016570 052760 160001 003176 3: BIS @160001,ERTABL(R0) ; FLAG ERROR IN THE ERROR TABLE
2222 016576 104455 ERROF 2,NOINIT ; DEVICE NOT IDLE
016576 104455 TRAP CIEROF
016600 000002 .WORD 2
016602 004335 .WORD NOINIT
016604 000000 .WORD 0
2223 016606 012737 177777 003112 2: MOV @-1,DUFLG ; DROP THE UNIT
2224 016614 013700 002202 DODU UNITN
016614 013700 MOV UNITN,R0
016620 104451 TRAP CIDODU
2225 016622 DOCLN ; ABORT THE PASS
016622 104444 TRAP CIDCLN
2226 016624 000423 BR 5;
2227
2228 016626 4: RFLAGS R0 ; GET THE OPERATOR FLAGS.
016626 104421 TRAP CIRFLA
2229 016630 032700 001000 BIT @PNT,R0 ; PRINT THE TEST NUMBERS?
2230 016634 001412 BEQ 1; ; BR IF NO
2231 016636 011600 MOV (SP),R0 ;GET THE ID MESSAGE
2232 016640 PRINTF @TNAM,R0 ;DISPLAY THE TEST ID
016640 010046 MOV R0,-(SP)
016642 012746 016704 MOV @TNAM,-(SP)
016646 012746 000002 MOV @2,-(SP)
016652 010600 MOV SP,R0
016654 104417 TRAP CIPNTF
016656 062706 000006 ADD @6,SP
2233 016662 005237 002214 1: INC TSTCNT ; BUMP TEST COUNTER.
2234 016666 SETPRI IPRI ;PRIORITY THAT OF DEVICE
016666 013700 002212 MOV IPRI,R0
016672 104441 TRAP CISPRI
2235 016674 005726 5: TST (SP); ;FIX UP THE STACK
2236 016676 013705 002206 MOV CSRADDR,R5 ; ADDRESS OF TSV REGISTERS ON UNIBUS
2237 016702 000207 RTS PC
2238 016704 045 123 045 TNAM: .ASCIZ 'AS#T#A Test'
2239 .EVEN
2240 .SBTTL TSTEND - PRINT ERRORS RECEIVED
2241 ;
2242 ; AT END OF EACH TEST, PRINT THE NUMBER OF ERRORS RECEIVED
2243 ; IF NORMAL ERROR REPORTING IS DISABLED (FLA:IER).
2244 ;
2245 TSTEND: RFLAGS R0
016720 104421 TRAP CIRFLA
2246 016722 030027 020000 BIT R0,@IER
2247 016726 001412 BEQ 1; ; BR IF "IER" NOT SET.
2248 016730 PRINTF @ESUM,ERRK ; PRINT ERROR COUNT.
016730 013746 016756 MOV ERRK,-(SP)
016734 012746 016760 MOV @ESUM,-(SP)
016740 012746 000002 MOV @2,-(SP)
016744 010600 MOV SP,R0
016746 104417 TRAP CIPNTF

```



```

2256                                     .SBTTL  INCERK  - INCREMENT LOCAL ERROR COUNT
2257                                     ;
2258                                     ; ROUTINES TO INCREMENT LOCAL ERROR COUNT AND CHECK FOR LIMIT:
2259                                     ;
2260 017044 005237 016756  INCERK: INC  ERRK      ; INCREMENT LOCAL ERROR COUNT
2261 017050 010046        MOV  RO,-(SP) ; SAVE RO
2262 017052 013700 002202  MOV  UNITN,RO ; GET UNIT NUMBER,
2263 017056 006300        ASL  RO      ; ... AND MAKE IT A WORD OFFSET.
2264 017060 062700 003176  ADD  @ERTABL,RO ; RO GETS ADDRESS OF ERROR TABLE ENTRY.
2265 017064 005210        INC  (RO)   ; INCREMENT THE DEVICE ERROR COUNT
2266 017066 032710 007777  BIT  @7777,(RO) ; DID WE OVERFLOW THE FIELD?
2267 017072 001001        BNE  1$    ; BR IF NO.
2268 017074 005310        DEC  (RO)   ; YES -- BACK IT UP TO 7777.
2269 017076 012600 1$:    MOV  (SP)+,RO ; RESTORE RO
2270 017100 000207        RTS  PC     ; RETURN TO CALLER.
2271
2272 017102 010046        CKEMAX: MOV  RO,-(SP) ; SAVE RO
2273 017104 013700 002202  MOV  UNITN,RO ; GET UNIT NUMBER
2274 017110 006300        ASL  RO      ; ... AND MAKE IT A WORD OFFSET
2275 017112 016000 003176  MOV  ERTABL(RO),RO ; GET ERROR TABLE ENTRY
2276 017116 042700 170000  BIC  @170000,RO ; EXTRACT ERROR COUNT FIELD
2277 017122 020037 002174  CMP  RO,GERRMAX ; IS GLOBAL LIMIT EXCEEDED FOR THIS UNIT?
2278 017126 103004        BHS  1$    ; BR IF YES
2279 017130 023737 016756 002172  CMP  ERRK,LERRMAX ; IS LOCAL LIMIT EXCEEDED FOR THIS TEST?
2280 017136 103417        BLO  2$    ; BR IF NO
2281 017140 1$:          RFLAGS RO    ; GET OPERATOR FLAGS
2282 017140 104421        TRAP C#RFLA
2283 017142 032700 000040  BIT  @IDU,RO    ; IS DROPPING INHIBITED?
2284 017146 001013        BNE  2$    ; BR IF YES.
2285 017150 012737 177777 003112  MOV  #-1,DUFLG ; NO -- DROP THE UNIT
2286 017156 104455        ERRDF 4,EMAXDU
2287 017160 000004        TRAP C#ERDF
2288 017162 016777        .WORD 4
2289 017164 000000        .WORD EMAXDU
2290 017166 000000        .WORD 0
2291 017166 013700 002202  DODU UNITN
2292 017172 104451        MOV  UNITN,RO
2293 017174 000000        TRAP C#DODU
2294 017174 104444        DOCLN TRAP C#DCLN
2295 017176 012600 2$:    MOV  (SP)+,RO ; RESTORE RO
2296 017200 000207        RTS  PC     ; RETURN TO CALLER

```

```

2291          .SBTTL CKDROP - CHECK IF UNIT SHOULD BE DROPPED
2292          ;
2293          ; CHECK IF UNIT SHOULD BE DROPPED
2294          ;
2295 017202 010046 CKDROP: MOV      RO, -(SP)
2296 017204          FORCERROR 1$, NOTSSR
2297 017214          RFLAGS  RO
          017214 104421 TRAP    C$F LA
2298 017216 032700 000C40 BIT    #IDU, RO
2299 017222 001010 BNE    1$
2300 017224 011600 MOV    (SP), RO
2301 017226 012737 177777 003112 MOV    #-1, DUFLG
2302 017234          DODU    UNITN
          017234 013700 002202 MOV    UNITN, RO
          017240 104451 TRAP    C$DODU
2303 017242          DOCLN          ; ABORT THE PASS
          017242 104444 TRAP    C$DCLN
2304 017244 012600 1$: MOV    (SP)+, RO
2305 017246 000207 RTS    PC
2306
2307          .SBTTL CONFIG - DETERMINE CONFIGURATION OF SYSTEM
2308          ;
2309          ; SUBROUTINE - DETERMINE CONFIGURATION OF TSV05 SYSTEM.
2310          ;
2311          ;
2312 017250          CONFIG:
2313 017250 004737 015774 JSR    PC, SOFINIT
2314 017254 000207 RTS    PC
2315          .SBTTL KTON, KTOFF - ENABLE/DISABLE MEMORY MANAGEMENT
2316          ;
2317          ; SUBROUTINE - ENABLE MEM MGT.
2318          ;
2319 017256 005737 003132 KTON: TST    KTFLG          ; GOT KT?
2320 017262 001403 BEQ    1$          ; NO.
2321 017264 012737 000001 177572 MOV    #1, SRO          ; YES. ENABLE KT11.
2322 017272 000207 1$: RTS    PC
2323
2324          ;
2325          ; SUBROUTINE - DISABLE MEM MGT.
2326          ;
2327 017274 005737 003132 KTOFF: TST    KTFLG          ; GOT KT11?
2328 017300 001405 BEQ    1$          ; NO.
2329 017302 000240 NOP
2330 017304 000240 NOP
2331 017306 012737 000000 177572 MOV    #0, SRO          ; DISABLE KT.
2332 017314 000207 1$: RTS    PC

```

2334  
2335  
2336  
2337  
2338  
2339  
2340  
2341  
2342  
2343  
2344  
2345  
2346  
2347  
2348  
2349  
2350  
2351  
2352  
2353 017316  
2354 017316  
2355 017322 005737 003132  
2356 017326 001433  
2357 017330 010102  
2358 000006  
2359  
2360  
2361  
2362 017362 042701 000177  
2363 017366 020137 003132  
2364 017372 103011  
2365 017374 010137 172354  
2366 017400 042702 160000  
2367 017404 062702 140000  
2368 017410 010200  
2369 017412 000261  
2370 017414 000401  
2371 017416 000241  
2372 017420 000207  
2373  
2374  
2375  
2376  
2377  
2378  
2379  
2380  
2381  
2382  
2383  
2384  
2385  
2386  
2387  
2388 017422  
2389 017422  
2390 017426 004737 017274

```

.SBTTL SETMAP - SETUP PAR6 MAPPING

;*
; THIS ROUTINE SETS UP KERNEL PAR6 TP HANDLE
; AN 18 BIT ADDRESS. THE OFFSET INTO THE PAGE
; IS RETURNED BIASED TO PAR6.
;
; INPUTS:
;
; R0 HIGH ORDER ADDRESS BITS
; R1 LOW ORDER ADDRESS BITS
;
; OUTPUTS:
;
; R0 OFFSET INTO BLOCK WITH PAR6 BIAS (I.E. THE ADDRESS)
; CARRY SET IF SUCCESS
; CLR IF ERROR
;
;--
SETMAP:
  SAVREG ;SAVE R1-R4 UNTIL NEXT RETURN
  TST KTF LG ;SYSTEM HAVE ABOVE 28K?
  BEQ 10$ ;BR IF NO
  MOV R1,R2 ;SAVE LOW ORDER BITS
  .REPT 6
  ASR R0 ;CONVERT WORD ADDRESS TO 32W BLOCKS
  ROR R1 ;MAKE IT DOUBLE PRECISION
  .ENDR
  BIC #177,R1 ;ALINE FOR LOWER 4K BOUNDARY
  CMP R1,KTF LG ;HIGHER THAN EXISTING MEMORY?
  BHIS 10$ ;BR IF YES
  MOV R1,#KIPAR6 ;SETUP MAPPING REGISTER PAR6
  BIC #160000,R2 ;SETUP DISPLACEMENT IN PAGE
  ADD #140000,R2 ;ADD IN PAR6 BIAS
  MOV R2,R0 ;RETURN IN R0
  SEC ;SET SUCCESS
  BR 15$ ;
10$: CLC ;SET FAILURE
15$: RTS PC ;RETURN
.SBTTL FILLMEM - FILL MEMORY WITH BACKGROUND PATTERN

;*
; FILL MEMORY WITH A BACKGROUND PATTERN
;
; INPUTS:
;
; R0 = BACKGROUND PATTERN
; FREE = FIRST LOCATION AVAILABLE TO DIAGNOSTIC
; KTF LG = SET TO HIGHEST MEMORY LOCATION IF > 28K.
;
; OUTPUTS:
;
; NONE
;
;--
FILLMEM:
  SAVREG ;SAVE R1-R5 UNTIL NEXT RETURN
  JSR PC,KTOFF ;DISABLE KT.

```

TSV3 - GLOBAL AREAS MACRO M1113 14-JUN-84 15:55  
 FILLMEM - FILL MEMORY WITH BACKGROUND PATTERN

SEQ 0085

2391	017432	010003			MOV	R0,R3		;COPY TEST PATTERN
2392	017434	013701	003124		MOV	FREE,R1		;GET FIRST FREE LOCATION
2393	017440	013702	003126		MOV	FRESIZ,R2		;SIZE OF FREE SPACE BELOW 28K.
2394	017444	010321		10#:	MOV	R3,(R1)+		;STORE A BACKGROUND WORD
2395	017446	005302			DEC	R2		;DONE ALL MEMORY IN FREE SPACE?
2396	017450	003375			BGT	10#		;BR IF NO
2397	017452	005737	003132		TST	KTFLG		; GOT KT?
2398	017456	001477			BEQ	55#		; NO. GET OUT.
2399	017460	004737	017256		JSR	PC,KTON		; YES. ENABLE KT.
2400	017464	005000			CLR	R0		;HIGH ORDER ADDRESS START
2401	017466	013701	003152		MOV	PST32W,R1		;GET >28K START ADDRESS (IN 32W BLOCKS)
2402		000006			.REPT	6		
2403					CLC			;CLEAR C BIT
2404					ROL	R1		;CONVERT BLOCKS TO WORDS
2405					ROL	R0		;MAKE IT DOUBLE PRECISION
2406					.ENDR			
2407	017536	004737	017316		JSR	PC,SETMAP		;SETUP PAR6 MAPPING REGISTER
2408	017542	010320		30#:	MOV	R3,(R0)+		;STORE TEST PATTERN IN >28K ADDRESS
2409	017544	020027	160000		CMP	R0,#160000		;END OF PAR6 MAPPING AREA?
2410	017550	103774			BLO	30#		;BR IF NO
2411	017552	162700	020000		SUB	#20000,R0		;BACKUP INTO PAR6 MAPPING BEGIN
2412	017556	062737	000200	172354	ADD	#200,#KIPAR6		;POINT TO NEXT 4K BLOCK >28K.
2413	017564	023737	172354	003132	CMP	#KIPAR6,KTFLG		;END OF MEMORY?
2414	017572	001427			BEQ	50#		;BR IF YES
2415	017574	005737	003144		TST	T23A		;11/23A?
2416	017600	001407			BEQ	35#		;NO KEEP GOING
2417	017602	013704	177572		MOV	SRO,R4		;GET SRO CONTENTS
2418	017606	042704	177761		BIC	#177761,R4		;CLEAR ALL BUT PAGE NUMBER
2419	017612	022704	000016		CMP	#16,R4		;SEE IF PAGE 7
2420	017616	001415			BEQ	50#		;EXIT IF THERE
2421	017620	005737	003146	35#:	TST	T23B		;11/23B?
2422	017624	001410			BEQ	45#		;NO KEEP GOING
2423	017626	023727	172354	007600	CMP	#KIPAR6,#7600		;REACHED 18 BITS?
2424	017634	103001			BHIS	40#		;YES
2425	017636	000403			BR	45#		;NO KEEP GOING
2426	017640	012737	000020	172516	40#:	MOV	#20,SR3	;SET 22 BIT RELOCATION
2427	017646	000137	017542		45#:	JMP	30#	;KEEP GOING ON ETC.
2428	017652	004737	017274		50#:	JSR	PC,KTOFF	; DISABLE KT.
2429	017656	000207			55#:	RTS	PC	

```

2431          .SBTTL  CMPMEM  COMPARE MEMORY TO BACKGROUND PATTERN
2432          ;
2433          ; COMPARE MEMORY WITH A BACKGROUND PATTERN
2434          ;
2435          ; INPUTS:
2436          ;
2437          ;   R0 = BACKGROUND PATTERN
2438          ;   FREE  = FIRST LOCATION AVAILABLE TO DIAGNOSTIC
2439          ;   KTFLG = SET TO HIGHEST MEMORY LOCATION IF > 28K.
2440          ;
2441          ; OUTPUTS:
2442          ;
2443          ;   CARRY - SET IF NO ERROR
2444          ;   CARRY - CLR IF ERROR
2445          ;
2446          ; IMPLICIT OUTPUTS:
2447          ;
2448          ;   ERRHI - ERROR HIGH ADDRESS
2449          ;   ERRLO - ERROR LOW ADDRESS
2450          ;   EXPD  - EXPECTED DATA
2451          ;   RECV  - RECEIVED DATA
2452          ;
2453          ; CMPMEM:
2454          ;   SAVREG          ;SAVE R1-R5 UNTIL NEXT RETURN
2455          ;   MOV R0,R3      ;COPY TEST PATTERN
2456          ;   JSR PC,KTOFF  ;DISABLE KT.
2457          ;   MOV FREE,R1   ;GET FIRST FREE LOCATION
2458          ;   MOV FRESIZ,R2 ;SIZE OF FREE SPACE BELOW 28K.
2459          ;   CMP R3,(R1)   ;FREE SPACE LOCATION EQUAL TO EXPD?
2460          ;   BEQ 15$      ;BR IF YES
2461          ;   MOV R1,ERRLO  ;SAVE ADDRESS IN ERROR
2462          ;   CLR ERRHI    ;NO HIGH ADDRESS
2463          ;   MOV R3,EXPD   ;SAVE EXPD FOR ERROR REPORT
2464          ;   MOV (R1),RECV ;SAVE RECV FOR ERROR REPORT
2465          ;   BR 50$       ;
2466          ;   TST (R1)+    ;POINT TO NEXT ADDRESS
2467          ;   DEC R2       ;DONE ALL MEMORY IN FREE SPACE?
2468          ;   BGT 10$     ;BR IF NO
2469          ;   TST KTFLG   ; GOT KT?
2470          ;   BEQ 55$    ; NO. GET OUT.
2471          ;   JSR PC,KTON  ; YES. ENABLE KT.
2472          ;   CLR R0      ;HIGH ORDER ADDRESS START
2473          ;   MOV PST32W,R1 ;GET >28K START ADDRESS (IN 32W BLOCKS)
2474          ;   .REPT 6
2475          ;   ROL R1      ;CONVERT BLOCKS TO WORDS
2476          ;   ROL R0      ;MAKE IT DOUBLE PRECISION
2477          ;   .ENDR
2478          ;   BIC @177,R1  ;ALINE 4K BOUNDARY
2479          ;   MOV R0,-(SP) ;SAVE HIGH ORDER
2480          ;   MOV R1,-(SP) ;SAVE LOW ORDER
2481          ;   JSR PC,SETMAP ;SETUP PAR6 MAPPING REGISTER
2482          ;   MOV R0,R4    ;COPY ADDRESS BIASED TO PAR6
2483          ;   MOV (SP)+,R1 ;RESTORE LOW ORDER IN NON PAR6 FORMAT
2484          ;   MOV (SP)+,R0 ;RESTORE HIGH ORDER IN NON PAR6 FORMAT
2485          ;   CMP R3,(R4)  ;ABOVE 28K LOCATION EQUAL EXPD?
2486          ;   BEQ 32$     ;BR IF YES
2487          ;   MOV R0,ERRHI ;SAVE HIGH ORDER IN ERROR
  
```



```

2488 020040 010137 002240      MOV      R1,ERRLO      ;SAVE LOW ORDER IN ERROR
2489 020044 010337 002232      MOV      R3,EXPD      ;SAVE EXPD FOR ERROR REPORT
2490 020050 011437 002234      MOV      (R4),RECV    ;SAVE RECV FOR ERROR REPORT
2491 020054 000421              BR       50$          ;
2492 020056 062701 000002      32$:    ADD      #2,R1    ;UPDATE NON PAR6 ADDRESS
2493 020062 005500              ADC      R0           ;MAKE IT DOUBLE PRECISION ADD
2494 020064 062704 000002      ADD      #2,R4        ;UPDATE PAR FORMAT ADDRESS
2495 020070 020427 160000      CMP      R4,#160000   ;END OF PAR6 MAPPING AREA?
2496 020074 103755              BLO     30$          ;BR IF NO
2497 020076 162704 020000      SUB      #20000,R4    ;BACKUP INTO PAR6 MAPPING BEGIN
2498 020102 062737 000200 172354  ADD      #200,#KIPAR6 ;POINT TO NEXT 4K BLOCK >28K.
2499 020110 023737 172354 003132  CMP      #KIPAR6,KTFLG ;END OF MEMORY?
2500 020116 101744              BLOS   30$          ;BR IF NO
2501 020120 004737 017274      50$:    JSR      PC,KTOFF   ;TURN OFF MEMORY MAPPING
2502 020124 000241              CLC                    ;SET FAILURE
2503 020126 000403              BR       60$          ;
2504 020130 004737 017274      55$:    JSR      PC,KTOFF   ;TURN OFF MEMORY MAPPING
2505 020134 000261              SEC                    ;SET SUCCESS
2506 020136 000207      60$:    RTS      PC
2507              .SBTTL  REGSAV - SAVE R1-R5 ON STACK
2508              ;*
2509              ;
2510              ;ROUTINE TO
2511              ;SAVE R1 THROUGH R5 ON THE STACK
2512              ;
2513              ;CALLING SEQUENCE:
2514              ;
2515              ;      JSR      R5,REGSAV
2516              ;
2517              ;THIS IS A COOROUTINE WHICH TRANSFER CONTROL BACK TO
2518              ;THE CALLING ROUTINE. AT THE END OF THE CALLING ROUTINE,
2519              ;THE RTS PC RETURNS CONTROL TO THIS ROUTINE TO RESTORE
2520              ;REGISTERS.
2521              ;
2522              ;THIS ROUTINE SHOULD ONLY BE CALLED FROM ROUTINES WHICH ARE
2523              ;CALLED VIA A JSR PC INSTRUCTION
2524              ;
2525              ;-
2526              ;
2527              REGSAV:
2528              MOV      R4,-(SP)
2529              MOV      R3,-(SP)
2530              MOV      R2,-(SP)
2531              MOV      R1,-(SP)
2532              MOV      R5,-(SP)
2533              MOV      10.(SP),R5
2534              JSR      PC,#(SP)+
2535              MOV      (SP)+,R1
2536              MOV      (SP)+,R2
2537              MOV      (SP)+,R3
2538              MOV      (SP)+,R4
2539              MOV      (SP)+,R5
2540              RTS      PC

```

17

```

2542 .SBTTL GETPAT GET 8 BIT PATTERN FROM OPERATOR
2543 ;*
2544 ;ROUTINE TO REQUEST AN 8 BIT DATA PATTERN FROM THE OPERATOR
2545 ;
2546 ;INPUTS: NONE.
2547 ;
2548 ;OUTPUTS:
2549 ; RO OCTAL NUMBER FROM THE OPERATOR
2550 ;
2551 ;CALLING SEQUENCE:
2552 ; JSR PC,GETPAT
2553 ;
2554 020174 GETPAT::
2555 020174 SAVREG ;SAVE THE GENERAL REGISTERS
2556 020200 1$: GMANID DATASC,PATDAT,0,377,0,377,NO
020200 104443 TRAP C$GMAN
020202 000406 BR 10000$
020204 020230 .WORD PATDAT
020206 000022 .WORD T$CODE
020210 020232 .WORD DATASC
020212 000377 .WORD 377
020214 000000 .WORD T$LOLIM
020216 000377 .WORD T$HILIM
020220 10000$:
2557 020220 BNCOMPLETE 1$ ;RETRY IF ERROR
020220 103367 BCC 1$
2558 020222 013700 020230 MOV PATDAT,RO ;DATA PATTERN FROM OPERATOR
2559 020226 000207 RTS PC ;RETURN TO CALLER
2560 ;
2561 ;*
2562 ;LOCAL DATA AREA
2563 ;-
2564
2565 020230 000000 PATDAT: .WORD 0 ;TEMPORARY STORAGE FOR DATA
2566 020232 105 116 124 DATASC: .ASCIZ 'ENTER DATA PATTERN'
2567 .EVEN

```

```

2569 .SBTTL GETSEL - ISSUE MENU AND GET OPERATOR RESPONSE
2570 ;*
2571 ;ROUTINE TO ISSUE A MENU AND GET THE OPERATOR'S RESPONSE.
2572 ;
2573 ;INPUTS:
2574 ; R0 ADDRESS OF ASCIZ STRING OF MENU
2575 ; R1 MAXIMUM ALLOWABLE OPERATOR RESPONSE
2576 ;
2577 ;OUTPUTS:
2578 ; R0 NUMBER OF THE OPERATOR'S SELECTION
2579 ;-
2580 GETSEL::
2581 SAVREG ;SAVE GENERAL REGISTERS
2582 MOV R0,R2 ;SAVE THE MENU ADDRESS
2583 MOV R2,R3 ;START OF MENU STRING
2584 TST (R3) ;END OF ASCII ?
2585 BEQ 3$ ;BRANCH IF ALL LINES DISPLAYED
2586 PRINTF #SELASC,(R3) ;DISPLAY THE MENU
      MOV (R3),-(SP)
      MOV #SELASC,-(SP)
      MOV #2,-(SP)
      MOV SP,R0
      TRAP C#PNTF
      ADD #6,SP
      BR 2$
2587 3$: GMANID MENASC,MENRES,D,-1,0,-1,NO
2588 TRAP C#GMAN
      BR 10001$
      .WORD MENRES
      .WORD T#CODE
      .WORD MENASC
      .WORD -1
      .WORD T#LOLIM
      .WORD T#HILIM
10001$: BNCOMPLETE 1$ ;RETRY IF ERROR
      BCC 1$
2590 MOV MENRES,R0 ;GET THE OPERATOR'S REPLY
2591 CMP R0,R1 ;COMPARE TO MAXIMUM ALLOWED
2592 BLOS 5$ ;BRANCH IF OK
2593 PRINTF #MENERR ;DISPLAY ERROR MESSAGE
      MOV #MENERR,-(SP)
      MOV #1,-(SP)
      MOV SP,R0
      TRAP C#PNTF
      ADD #4,SP
      BR 1$ ;RETRY
2594 5$: RTS PC ;RETURN TO CALLER
2595 045 MENERR: .ASCIZ '#N#A *** Menu Selection Too Large ***'
2596 045 SELASC: .ASCIZ '#N#T'
2597 164 MENASC: .ASCIZ 'Enter Menu Selection: '
2598 .EVEN
2599 MENRES: .WORD 0
2600

```

```

2602                   .SBTTL  CHKMAN  - CHECK MANUAL INTERVENTION LEGALITY
2603                   ;*
2604                   ;ROUTINE TO TEST FOR MANUAL INTERVENTION LEGALITY.
2605                   ;INPUT:
2606                   ;
2607                   ;      NONE.
2608                   ;
2609                   ;OUTPUT:
2610                   ;
2611                   ;      CARRY   0        MANUAL INTERVENTION NOT ALLOWED
2612                   ;             1        MANUAL INTERVENTION IS OK
2613                   ;
2614                   ;SIDE EFFECTS:
2615                   ;
2616                   ;      A MESSAGE IS DISPLAYED WARNING THAT TEST IS
2617                   ;      NOT EXECUTED IF MANUAL INTERVENTION IS NOT
2618                   ;      ALLOWED.
2619                   ;
2620                   ;
2621                   ;
2622                   ;-
2623                   CHKMAN::
2624                    020500            SAVREG                   ;SAVE THE REGISTERS
2625                    020500            MANUAL                 ;SEE IF MANUAL INTERVENTION OK
2626                    020504   104450    TRAP    C$MANI
2627                    020506            BCOMplete 1$           ;BRANCH IF ALLOWED
2628                    020506   103411    BCS     1$
2629                    020510            PRINTF #NOMAN           ;PRINT THE WARNING MESSAGE
2630                    020510   012746   020534   MOV     #NOMAN,-(SP)
2631                    020514   012746   000001   MOV     #1,-(SP)
2632                    020520   010600            MOV     SP,R0
2633                    020522   104417            TRAP   C$PNTF
2634                    020524   062706   000004   ADD     #4,SP
2635                    020530   000241            CLC               ;CLEAR CARRY FOR ERROR
2636                    020532   000207   1$:   RTS     PC               ;RETURN
2637                    020534    045       116     045   NOMAN: .ASCIZ  '###A *** Manual Intervention not Allowed - Test Aborted ***'
2638                    020534                                    .even

```

```

2635          .SBTTL  ENVIRN  SETUP FREE DIAGNOSTIC SPACE
2636          ;
2637          ; SUBROUTINE TO SET-UP VARIOUS ENVIRONMENTAL PARAMETERS.
2638          ;
2639 020630      ENVIRN: MEMORY R0
                TRAP      C$MEM
2640 020630 104431      MOV      R0,FREE          ; GET 1ST FREE ADDRESS...
2641 020632 010037 003124      ADD      #2,FREE
2642 020636 062737 000002 003124      MOV      (R0),FRESIZ      ;...AND WORD COUNT.
2643 020644 011037 003126      SUB      #4,FRESIZ
2644 020650 162737 000004 003126      MOV      L$UNIT,R2      ; GET NUMBER OF UNITS
2645 020656 013702 002012      SUB      #7,FRESIZ      ; TAKE AWAY 7 WORDS PER UNIT
2646 020662 162737 000007 003126 10$: DEC      R2
2647 020670 005302      BNE      10$
2648 020672 001373      MOV      FREE,R0          ;GET FIRST FREE ADDRESS
2649 020674 013700 003124      ADD      FRESIZ,R0      ;POINT TO LAST FREE ADDRESS
2650 020700 063700 003126      SUB      #2,R0          ;BACKUP 1 WORD
2651 020704 162700 000002      MOV      R0,FREEHI      ;STORE LAST FREE ADDRESS
2652 020710 010037 003130      NOP
2653 020714 000240      ;*****
2654 020716 012701 177520      MOV      #BDVPCR,R1      ;GET BDV11 PCR ADDRESS
2655 020722 010102      MOV      R1,R2          ;COPY TO R2
2656 020724 062702 000002      ADD      #2,R2          ;SET THE RANGE
2657 020730 004737 016376      JSR      PC,XNXM        ;SEE IF WE HAVE ONE
2658 020734 103001      BCC      15$           ;OK TO SET FLAGS
2659 020736 000423      BR       40$           ;RETURN WITH FLAGS CLEAR
2660 020740 013701 177520 15$: MOV      BDVPCR,R1      ;SAVE PCR CONTENTS
2661 020744 062701 000001      ADD      #1,R1          ;ADD ONE TO IT
2662 020750 012702 177520      MOV      #BDVPCR,R2      ;GET BDV11 PCR ADDRESS
2663 020754 005212      INC      (R2)          ;TRY TO WRITE TO IT
2664 020756 013703 177520      MOV      BDVPCR,R3      ;GET RESULTS
2665 020762 020103      CMP      R1,R3          ;DID IT CHANGE?
2666 020764 001006      BNE      20$           ;NO, MUST BE 11/23B
2667 020766 005237 003144      INC      T23A          ;SET THE FLAG
2668 020772 042737 170000 002120      BIC      #170000,L$HIME ;SUPERVISOR COULD BE WRONG
2669          ;
2670 021000      PRINTF #M8186      ;TELL THE SYSTEM TYPE
2671 021002 005237 003146 20$: BR       40$           ;RETURN
2672          ;
2673          ; PRINTF #M8189      ;TELL THE SYSTEM TYPE
2674 021006 40$:
2675 021006 000207      RTS      PC          ;RETURN

```

```

2677 .SBTTL KTINIT SETUP KT11 MEMORY MANAGEMENT REGISTERS
2678 ;
2679 ;
2680 ;ROUTINE TO INIT KT 11
2681 ;
2682 ;
2683
2684 KTINIT:
2685 021010 005037 003132 CLR KFLG ; INIT >28K MEMORY FLAG
2686 021014 005037 003134 CLR KENABLE ; INIT TEST >28K FLAG
2687 021020 023727 002120 001577 CMP L#HIME,#1577 ; GOT ENOUGH MEMORY (>28K)?
2688 021026 101444 BLOS 9# ; NO.
2689 021030 013700 000004 MOV @ERRVEC,R0 ; SAVE OLD ERR VEC PTR.
2690 021034 012737 021126 000004 MOV #21,@ERRVEC ; SET ERR VEC PTR.
2691 021042 005737 177572 TST @SRO ; GOT KT11?
2692 021046 000240 NOP ; (TRAP IF NO).
2693 021050 013737 002120 003132 MOV L#HIME,KFLG ; YES. SET KT FLAG.
2694 021056 042737 000177 003132 BIC #177,KFLG ;
2695 021064 010037 000004 MOV R0,@ERRVEC ; RESTORE OLD ERR VEC PTR.
2696 021070 005000 CLR R0 ; R0 = AR DATA.
2697 021072 012701 172340 MOV @KIPAR,R1 ; R1 = KI REGS PTR.
2698 021076 012761 077406 177740 1#: MOV #77406,-40(R1) ; SET DESCRIPTOR REG.
2699 021104 010021 MOV R0,(R1) ; SET KIPAR REG.
2700 021106 062700 000200 ADD #200,R0 ; BUMP AR DATA BY "4K".
2701 021112 020027 002000 CMP R0,#2000 ; AT "I/O"?
2702 021116 001367 BNE 1# ; NO.
2703 021120 012741 177600 MOV #177600,-(R1) ; YES. SET KTPAR7 FOR I/O.
2704 021124 000405 BR 9#
2705
2706 021126 012716 021134 2#: MOV #61,(SP) ; SET UP RETURN
2707 021132 000002 RTI ; RTI TO NEXT LOCATION
2708
2709 021134 010037 000004 6#: MOV R0,@ERRVEC ; RESTORE OLD ERR VEC PTR.
2710
2711 021140 000207 9#: RTS PC
    
```

```

2713
2714
2715
2716
2717
2718
2719
2720
2721
2722
2723
2724
2725
2726 021142
2727
2728 021142 005737 002226
2729 021146 001020
2730 021150 012737 100206 021214
2731 021156 012737 021224 021216
2732 021164 012737 000006 021222
2733 021172 012737 100010 021224
2734 021200 012704 021214
2735 021204 004737 010662
2736 021210 000207
2737
2738
2739
2740
2741
2742 021214 000000
2743 021216 000000
2744 021220 000000
2745 021222 000000
2746
2747
2748
2749 021224 000000
2750 021226 000000
2751 021230 000000
2752
2753
2754
2755
2756
2757
2758
2759
2760
2761
2762
2763 021232
2764
2765 021232
2766 021236 005037 005136
2767 021242 005037 003140
2768 021246 005037 003142
2769 021252 005737 003146

;
; SUBROUTINE TO SET EXTENDED FEATURES SWITCH
;
; Requires that SOFINIT and WRTCHR have been done previous to call.
;
; INPUTS:
; R5 CURRENT UNIT NUMBER
; OUTPUTS:
; The Extended Features Switch is set.
;
;
INVERT::
TST EXTFEA ; IS SWITCH SET?
BNE 18 ; YES, EXIT STAGE RIGHT!(or the next one outa town!)
MOV @100206,CHDPKT ; WRT SUB-SYS MEM CMD
MOV @WSMBK,CHDPKT*2 ; MSG BUF ADDR
MOV @6,CHDPKT*6 ; BYTE COUNT
MOV @100010,WSMBK ; INVERT THE SWITCH
MOV @CHDPKT,R4 ; SET CHDPKT INTO R4
JSR PC,WRTCHR ; DO IT
RTS PC ; RETURN

;
; COMMAND PACKET.
;
; * <..*3>E177774 ;MUST BE ON MOD 4 BOUNDARY.
;
CHDPKT:: 0 ;1ST WORD IS TS05 COMMAND.
0 ;2ND WORD IS THE BUFFER LOW ADDRESS.
0 ;3RD WORD IS THE BUFFER HIGH ADDRESS.
0 ;4TH WORD IS THE BYTE/RECORD/FILE COUNT.

;
; WRITE SUB-SYSTEM MEMORY CHARACTERISTIC BLOCK.
;
WSMBK:: 0 ;1ST WORD:: SEL 0
0 ;2ND WORD:: SEL 2
0 ;3RD WORD:: SEL 4
.EVEN

;
; SUBROUTINE TO CHECK WETHER OR NOT WE'LL TEST NXM
;
; INPUTS:
; OUTPUTS:
; The NXMFLG is set if we can test.
; The NXMLO and NXMHI addresses are setup.
;-

MEMCK::
SAVREG ;SAVE THE REGISTERS
CLR NXMFLG ;CLEAR THE FLAG
CLR NXMLO ;CLEAR THE TEST ADDRESS LO
CLR NXMHI ;CLEAR THE TEST ADDRESS HI
TST T238 ;IS IT A 11/238?

```

```

2770 021256 001407          BEQ      1#          ;NO
2771 021260 023727 002120 007777    CMP      L#HIME,#07777 ; GREATER THAN 128K
2772 021266 103406          BLO      2#          ; NO
2773 021270 004737 021406          JSR      PC,NXMTST   ;SETUP THE ADDRESS
2774 021274 ^00427          BR       13#         ;SET THE FLAG AND EXIT
2775 021276 005737 003144          TST      T23A       ;IS IT A 11/23A?
2776 021302 001413          BEQ      4#          ;NO
2777 021304 023727 002120 005777 2# :    CMP      L#HIME,#5777 ;GREATER THAN 96K
2778 021312 101023          BHI      14#         ;YES,23A/23B WITH 128K MEMORY
2779 021314 023727 002120 003777    CMP      L#HIME,#3777 ;GREATER THAN 64K BUT LESS THAN 92K?
2780 021322 103403          BLO      4#          ;NO, CHECK 24K
2781 021324 004737 021406          JSR      PC,NXMTST   ;SETUP THE ADDRESS
2782 021330 000411          BR       13#         ;SET THE FLAG AND EXIT
2783 021332 023727 002120 001577 4# :    CMP      L#HIME,#1577 ;GREATER THAN 24K BUT LESS THAN 64K?
2784 021340 103410          BLO      14#         ;NO, TELL THEM AND EXIT WITH FLAG CLEAR
2785 021342 004737 021406          JSR      PC,NXMTST   ;SETUP THE ADDRESS
2786 021346 062737 000077 003142    ADD      #77,NXMHI   ;FOOL THE 11/02 & 11/03
2787 021354 005237 003136          INC      NXMFLG     ;SET THE FLAG
2788 021360 000411          BR       15#         ;EXIT
2789 021362 000410          BR       14#         ;NOP FOR PRINTOUT
2790 021364          PRINTF  #NOMEM     ;TELL THEM & EXIT ***NO PRINT*****
      021364 012746 005460          MOV      #NOMEM,-(SP)
      021370 012746 000001          MOV      #1,-(SP)
      021374 010600          MOV      SP,R0
      021376 104417          TRAP    C#PNTF
      021400 062706 000004          ADD      #4,SP
2791 021404 000207          15# :    RTS      PC          ;RETURN
2792
2793
2794          ;
2795          ; SUBROUTINE TO SETUP THE NXM ADDRESS FOR TESTING
2796          ;
2797          ; OUTPUTS: NXMLO,NXMHI          ;SETUP WITH NXM ADDRESS
2798          ;
2799          ;-
2800 021406 013701 002120    NXMTST: MOV      L#HIME,R1          ;GET TOP OF MEMORY
2801 021412 062701 000200    ADD      #200,R1          ;MAKE IT I/O BLOCK OR OTHER NXM
2802 021416 042701 000177    BIC      #177,R1
2803 021422 010102          MOV      R1,R2          ;RESAVE RESULTS
2804          000006          .REPT    6
2805          ASL      R1          ;PUT IN PLACE FOR XFER
2806          .ENDR
2807 021440 010137 003140    MOV      R1,NXMLO        ;SAVE TEST ADDRESS LOW
2808          000012          .REPT    10
2809          ASR      R2          ;PUT IN PLACE FOR XFER
2810          .ENDR
2811 021470 042702 177700    BIC      #177700,R2      ;DON'T WANT ILA!
2812 021474 010237 003142    MOV      R2,NXMHI        ;SAVE TEST ADDRESS HIGH
2813 021500 000207          RTS      PC          ;RETURN
2814
2815 021502          ENDMOD

```



TSV4 - MISCELLANEOUS SECTIONS MACRO M1113 14-JUN-84 15:55  
KTINIT - SETUP KT11 MEMORY MANAGEMENT REGISTERS

SEQ 0095

7 .TITLE TSV4 MISCELLANEOUS SECTIONS

8  
9 021502 BGNMOD TSV4

021502 TSV4::

10  
16  
17  
18  
19

20 021502 .SBTTL PROTECTION TABLE  
021502 BGNPROT

21 021502 17777 177777 17777 L#PROT: .WORD -1. -1. -1. 1 ;NO DEVICE PROTECTION REQUIRED.  
22 021512 ENDPROT

```

24          .SBTTL INITIALIZE SECTION
25
26          ;**
27          ;THE INITIALIZE SECTION CONTAINS THE CODING THAT IS PERFORMED
28          ;AT THE BEGINNING OF EACH PASS.
29
30          ;IF "START" OR "RESTART", SET QUICK-PASS FLAG AND BUS-INIT.
31          ;IF "CONTINUE", NOTHING IS REQUIRED.
32
33          ;--
34          ;*
35          ;INSERT TEMPORARY JUMP TO ODT
36          ;
37          BGNINIT
38          L$INIT::
39          40$: CLR      EXTFEA
40          CLR      NXMFLG
41          MOV      #EPRT1,EPRTSW      ;SET UP PRIMARY MESSAGE FOR REPLACEMENT
42          CLR      SIFLAG              ;CLEAR "SOFT INIT" FLAG
43          CLR      KTENABLE            ;CLEAR TEST ABOVE 28K FLAG
44          CLR      RAMSIZ              ;CLEAR RAM SIZE FOR RAMERR ROUTINE
45          READEF  #EF.CONTINUE
46          MOV      #EF.CONTINUE,RO
47          TRAP    C$REFG
48          BNCOMPLETE 1$
49          BCC     1$
50          CMP     UNITN,L$UNIT          ;UNIT IN RANGE?
51          BHIS   4$                     ;BR IF NO.
52          TST    DUFLAG                 ;DROPPED UNIT?
53          BMI    NXTU                   ;BR IF YES
54          MOV    UNITN,R1
55          ASL    R1
56          TST    ERTABL(R1)
57          BEQ    SETU
58          BIT    #BIT14,ERTABL(R1)      ;DROPPED?
59          BNE    NXTU
60          EXIT   INIT                    ;DO NOTHING IF "CONTINUE".
61          TRAP  C$EXIT
62          .WORD  L10030-.
63          1$:  READEF #EF.NEW
64          MOV    #EF.NEW,RO
65          TRAP  C$REFG
66          BNCOMPLETE NXTU                ;TAKE NEXT UNIT IF NOT NEW PASS.
67          BCC   NXTU
68          READEF #EF.START
69          MOV    #EF.START,RO
70          TRAP  C$REFG
71          BCOMPLETE 2$
72          BCS   2$
73          READEF #EF.RESTART
74          MOV    #EF.RESTART,RO
75          TRAP  C$REFG
76          BNCOMPLETE 31$
77          BCC   31$
78          2$:  BRESET
79          TRAP  C$RESET
80
81          ;1ST PASS, BUS-INIT...
82          ;BUS RESET.

```

65	021654	005037	002214		CLR	TSTCNT		;NUMBER OF TESTS RUN IN PASS
66	021660	005037	002222		CLR	FATFLG		;CLEAR FATAL ERROR COUNT
67	021664	005037	003144		CLR	T23A		;CLEAR 11/23A FLAG
68	021670	005037	003146		CLR	T23B		;CLEAR 11/23B FLAG
69					MOV	#340,-(SP)		
70					MOV	#20,-(SP)		;RETURN TO DEBUGGER
71					JMP	0.ODT		;ENTER THE DEBUGGER
72	021674	005037	003400		CLR	SKIPT		;CLEAR THE SUBTEST "SKIPPER"
73	021700			20:				
74	021700	012737	177777	002204	MOV	#-1,QVP		;...QUICK VERIFY...
75	021706	004737	020630		JSR	PC,ENVIRN		;SET ENVIRONMENT.
76	021712	004737	021010		JSR	PC,KTINIT		;INITIALIZE KT MEMORY MANAGEMENT
77	021716	012700	003176		MOV	#ERTABL,RO		
78	021722	005020		30:	CLR	(RO),		;CLEAR THE ERROR TABLE
79	021724	020027	003376		CMP	RO,#ERTABE		
80	021730	103774			BLO	30:		
81	021732	000404			BR	4:		
82	021734	005037	002204	31:	CLR	QVP		
83	021740	000137	022010		JMP	PASRPT		;GO REPORT THE STATUS
84								
85	021744			4:				
86	021744	012737	177777	002202	NEWPAS:	MOV	#-1,UNITN	;INIT UNIT NUMBER...
87	021752	005037	002220		CLR	DEV CNT		;CLEAR COUNT OF DEVICES RUNNING
88	021756			NXTU:	BREAK			
		104422			TRAP	C#BRK		
89	021760	005237	002202		INC	UNITN		;...AND SET NEXT UNIT NUMBER.
90	021764	023737	002202	002012	CMP	UNITN,L#UNIT		
91	021772	103423			BLO	SETU		
92	021774	012737	177777	003112	MOV	#-1,DUFLG		
93	022002	000401			BR	11:		
94	022004				DOCLN			;ABORT, NO MORE UNITS.
		104444			TRAP	C#DCLN		
95	022006	000240		11:	NOP			
96	022010			PASRPT:				
97	022010	023727	002012	000001	CMP	L#UNIT,#1		;HOW MANY UNITS SELECTED?
98	022016	101752			BLOS	NEWPAS		;BR IF ONLY 1
99	022020	005737	002220		TST	DEV CNT		;ARE ANY STILL RUNNING?
100	022024	001747			BEQ	NEWPAS		;BR IF NO
101	022026				RFLAGS	RC		
		104421			TRAP	C#RFLA		
102	022030	032700	000100		BIT	#ISR,RO		;SHOULD WE PRINT STATISTICS
103	022034	001343			BNE	NEWPAS		;BR IF NO
104								
105	022036				DORPT			
		104424			TRAP	C#DRPT		
106	022040	000741			BR	NEWPAS		
107	022042			10:				
108								
109	022042			SETU:	GPHARD	UNITN,RO		;GET UNIT N P-TABLE POINTER.
		013700	002202		MOV	UNITN,RO		
		104442			TRAP	C#GPHRD		
110	022050				BNCOMPLETE	NXTU		;BR IF UNIT NOT AVAILABLE.
		103342			BCC	NXTU		
111	022052	005037	003112		CLR	DUFLG		;CLEAR "DROPPED" FLAG.
112	022056	005237	002220		INC	DEV CNT		
113	022062	012001			MOV	(RO),R1		;GET 1ST REGISTER ADDRESS.
114	022064	010137	002206		MOV	R1,CSRADDR		;ADDRESS OF REGISTERS OF UNIT UNDER TEST

```

115
116 022070 012001          MOV      (R0),R1          ;GET VECTOR ADDRESS.
117                      ;MOV      (R0),R2          ;GET INTERRUPT PRIORITY
118                      ;MOV      R2,IPRI         ;SET INTERRUPT PRIORITY.
119 022072 010137 002210    MOV      R1,IVEC         ;SET INTERRUPT VECTOR POINTER...
120 022076 012721 016216    MOV      @INTR,(R1)+    ;...VECTOR...
121 022102 013721 002212    MOV      IPRI,(R1)+    ;...AND PRIORITY.
122
123 022106                  1$:
124                      ;          TST      QVP          ;1ST PASS ??
125                      ;          BEQ      5$          ;NO, SKIP THE PASS 1 STUFF.
126
127                      ;
128                      ;1ST PASS, CHECK THAT DEVICE ADDRESSES ARE VALID, AND
129                      ;THAT THE DISPLAY STATUS IS PROPERLY INITIALIZED.
130                      ;
131 022106 013701 002202    MOV      UNITN,R1
132 022112 006301          ASL      R1
133 022114 052761 100000 003176  BIS      @BIT15,ERTABL(R1) ;SAY DEVICE RUNNING
134 022122 005037 005772    CLR      EXTA          ;CLEAR ERROR EXTENSION FLAG.
135 022126 023727 002012 000001  CMP      L$UNIT,#1     ;ARE WE TESTING MULTIPLE UNITS?
136 022134 101416          BLOS    10$          ;BR IF NO.
137 022136          RFLAGS  R0          ;YES -- GET OPERATOR FLAGS.
138 022140 032700 001000    TRAP    C$RFLA
139 022144 001412          BIT      @PNT,R0      ;SHOULD WE PRINT UNIT #?
140 022146          BEQ      10$          ;BR IF NOT.
141 022146          PRINTF  @PUNIT,UNITN ;PRINT THE UNIT #
142 022146 013746 002202    MOV      UNITN,-(SP)
143 022152 012746 022240    MOV      @PUNIT,-(SP)
144 022156 012746 000002    MOV      @2,-(SP)
145 022162 010600          MOV      SP,R0
146 022164 104417          TRAP    C$PNTF
147 022166 062706 000006    ADD      @6,SP
148 022172          10$:
149 022172 005037 003114    CLR      NODEV
150 022176 013701 002206    MOV      CSRADDR,R1   ;ADDRESS OF FIRST REGISTER
151 022202 010102          MOV      R1,R2       ;START OF REGISTERS
152 022204 062702 000002    ADD      @TSSR,R2    ;ADDRESS OF TSSR REGISTER
153 022210 004737 016376    JSR      PC,XNXM     ;TEST BOTH CONTRLLER REGISTERS...
154 022214 103005          BCC     2$          ;...AND BR IF ALL OK.
155 022216 010137 003114    MOV      R1,NODEV    ;FLAG DEVICE AS NON-EXISTENT
156 022222 012737 177777 003112  MOV      @-1,DUFLG   ;DROP THIS UNIT.
157 022230          2$:
158 022230          ;
159 022230          ;FINALLY, SET CPU PRIORITY AND WE'RE DONE.
160 022230          5$:
161 022230 012700 000000    SETPRI  @PRI00        ;ENABLE INTERRUPTS.
162 022234 104441          MOV      @PRI00,R0
163 022236          TRAP    C$SPRI
164 022236          ENDINIT
165 022236          L10030:
166 022236 104411          TRAP    C$INIT
167 022240 045 116 045 PUNIT: .ASCIZ  /##### TESTING UNIT #02#A #####/
168 022240          .EVEN

```

.SBTTL ADD AND DROP UNITS SECTIONS

```

160
161
162
163
164
165
166
167 022306
    022306
168 022306 010001
169 022310 006301
170 022312 052761 100000 003176
171 022320 042761 040000 003176
172 022326
    022326 010046
    022330 012746 022354
    022334 012746 000002
    022340 010600
    022342 104417
    022344 062706 000006
173 022350
    022350 000167
    022352 000026
174 022354 045 116 045 1$:
175
176
177 022402
    022402
    022402 104452
178
179
180
181
182
183
184
185
186
187
188
189 022404
    022404
190 022404 012737 177777 003112
191 022412 010001
192 022414 006301
193 022416 052761 140000 003176
194 022424 000240 000240 000240
195 022432
    022432 010046
    022434 012746 022460
    022440 012746 000002
    022444 010600
    022446 104417
    022450 062706 000006
196 022454
    022454 000167
    022456 000030

; **
; THE ADD-UNIT SECTION CONTAINS THE CODING THAT CAUSES A DEVICE
; TO BE (A) ADDED TO THE TEST LIST FOR THE FIRST TIME,
; OR (B) RE-INSERTED IF IT HAD BEEN PREVIOUSLY DROPPED.
; -
BGNAU
L$AU::
MOV R0,R1 ; GET UNIT TO BE ADDED (R0)
ASL R1 ; MAKE IT A WORD INDEX
BIS #100000,ERTABL(R1) ; SET THE "ACTIVE" BIT
BIC #40000,ERTABL(R1) ; CLEAR THE "DROPPED" BIT
PRINTF #1$,R0
MOV RO,-(SP)
MOV #1$,-(SP)
MOV #2,-(SP)
MOV SP,R0
TRAP C$PNTF
ADD #6,SP
EXIT AU
.WORD J$JMP
.WORD L10031-2-
.ASCIZ /$N$A UNIT $D$A ADDED/
.EVEN

ENDAU ; UNUSED.
L10031: TRAP C$AU

; **
; THE DROP-UNIT SECTION CONTAINS THE CODING THAT CAUSES A DEVICE
; TO BE REMOVED FROM THE TEST LIST.
;
; SUPVSR DOES THE "DROPPING". THIS IS JUST TO TELL THE MAN.
; "DROPPED" UNITS ARE RE-SELECTED ON OPERATOR "STA" OR "ADD"
; COMMAND, OTHERWISE REMAIN INACTIVE. THE "DISPLAY" COMMAND
; WILL PRINT ALL DROPPED UNITS, AND THE P-TABLES OF THOSE
; WHICH ARE STILL ACTIVE.
; UPON ENTRY, R0 CONTAINS THE UNIT TO BE DROPPED.
BGNDU
L$DU::
MOV #-1,DUFLG
MOV R0,R1
ASL R1
BIS #140000,ERTABL(R1) ; SAY DROPPED
240,240,240 ; ??????????
PRINTF #1$,R0
MOV RO,-(SP)
MOV #1$,-(SP)
MOV #2,-(SP)
MOV SP,R0
TRAP C$PNTF
ADD #6,SP
EXIT DU
.WORD J$JMP
.WORD L10032-2 .

```

```

197 022460      045      116      045 1$: .ASCIZ /%N% A UNIT %D% A DROPPED/
198                                     .EVEN
199 022510                                     ENDDU
    022510      L10052:
    022510      104453      TRAP      C%D%U

200                                     ;**
201                                     ; AUTO-DROP CODE SECTION.
202                                     ;
203 022512      BGNAUTO
    022512      L$AUTO::
204 022512      013705      002206      MOV      CSRADDR,R5      ;POINT TO DEVICE REGISTER
205 022516      012703      000550      MOV      #360.,R3      ;ENOUGH TIME FOR 2400' REEL TO REWIND
206 022522      004737      016250      10$: JSR      PC,WAITF      ;WAIT FOR SSR TO SET
207 022526      103420      DELAY     250.          ;LEAVE WHEN SSR IS SET
208 022530      012727      000372      MOV      #250.,(PC).    ;WAIT FOR .25 SECONDS
    022534      000000      .WORD     0
    022536      013727      002116      MOV      L$DLY,(PC).
    022542      000000      .WORD     0
    022544      005367      177772      DEC      -6(PC)
    022550      001375      BNE      .-4
    022552      005367      177756      DEC      -22(PC)
    022556      001367      BNE      .-20
209 022560      005303      DEC      R3            ;BUMP COUNTER DOWN
210 022562      001357      BNE      10$          ;KEEP GOING
211 022564      004737      017202      JSR      PC,CKDROP     ;TRY AND DROP UNIT
212 022570      20$:
213 022570      ENDAUTO      ; UNUSED.
    022570      L10033:
    022570      104461      TRAP      C$AUTO

```

```

215 .SBTTL CLEAN UP AND REPORT CODING SECTIONS
216
217
218 ;**
219 ; THE CLEANUP CODING SECTION CONTAINS THE CODING THAT IS
220 ; EXECUTED AT THE END OF EACH PASS (OR SUB-PASS).
221 ; USE TO RETURN DEVICE UNDER TEST TO A NEUTRAL STATE.
222 ;
222 022572 BGNCLN
222 022572 L$CLEAN::
223 022572 013705 002206 MOV CSRADDR,R5 ;POINT TO DEVICE REGISTER
224 022576 005737 003112 TST DUFLG ;"DROPPED" FLAG IS SET ON...
225 022602 100405 BMI 1$ ;...AND GROSS CONTROLLER FAULT...
226 ;...DON'T TRY TO XCT CLEANUP CODE.
227
228 022604 012765 000000 000002 MOV #0,TSSR(R5) ;DO SOFT INIT
229 022612 004737 016250 JSR PC,WAITF
230
231 022616 1$:
231 022616 2$: ENDCLN
231 022616 L10034: TRAP C$CLEAN
232 ;**
233 ; THE REPORT CODING SECTION CONTAINS THE
234 ; "PRINTS" CALLS THAT GENERATE STATISTICAL REPORTS.
235 ;-
236 022620 BGNRPT
236 022620 L$RPT::
237 022620 PRINTS #DEVSUM
237 022620 012746 023062 MOV #DEVSUM,-(SP)
237 022624 012746 000001 MOV #1,-(SP)
237 022630 010600 MOV SP,R0
237 022632 104416 TRAP C$PNTS
237 022634 062706 000004 ADD #4,SP
238 022640 010246 MOV R2,-(SP)
239 022642 010346 MOV R3,-(SP)
240 022644 010446 MOV R4,-(SP)
241 022646 012704 003176 MOV #ERTABL,R4 ; GET START OF ERROR TABLE.
242 022652 005003 CLR R3 ; CLEAR UNIT NUMBER
243 022654 011402 1$: MOV (R4),R2 ; GET ERROR TABLE ENTRY & TEST IT.
244 022656 001467 BEQ 4$ ; ZERO IF UNIT NOT RUN
245 022660 100066 BPL 4$
246 022662 032702 040000 BIT #EIT14,R2 ; WAS UNIT DROPPED?
247 022666 001015 BNE 2$ ; BR IF YES
248 022670 042702 170000 BIC #1C7777,R2 ; GET ERROR COUNT FIELD
249 022674 PRINTS #DEVONL,R3,R2 ; PRINT
249 022674 010246 MOV R2,-(SP)
249 022676 010346 MOV R3,-(SP)
249 022700 012746 023117 MOV #DEVONL,-(SP)
249 022704 012746 000003 MOV #3,-(SP)
249 022710 010600 MOV SP,R0
249 022712 104416 TRAP C$PNTS
249 022714 062706 000010 ADD #10,SP
250 022720 000446 BR 4$
251 022722 020227 160000 2$: CMP R2,#160000 ; WAS UNIT NON-EXISTENT?
252 022726 001012 BNE 3$ ; BR IF NO
253 022730 PRINTS #DEVNXR,R3
253 022730 010346 MOV R3,-(SP)
253 022732 012746 023167 MOV #DEVNXR,-(SP)
    
```

```

022736 012746 000002      MOV      #2,-(SP)
022742 010600      MOV      SP,R0
022744 104416      TRAP     C#PNTS
022746 062706 000006      ADD      #6,SP
254 022752 000431      BR       4#
255 022754 020227 160001      3#:     CMP      R2,#160001      ; WAS UNIT NOT READY AT STARTUP?
256 022760 001012      BNE     30#                ; BR IF NO.
257 022762      PRINTS  #DEVNRD,R3
022762 010346      MOV      R3,-(SP)
022764 012746 023251      MOV      #DEVNRD,-(SP)
022770 012746 000002      MOV      #2,-(SP)
022774 010600      MOV      SP,R0
022776 104416      TRAP     C#PNTS
023000 062706 000006      ADD      #6,SP
258 023004 000414      BR       4#
259 023006 042702 170000      30#:    BIC      #+C7777,R2
260 023012      PRINTS  #DEVDR0,R3,R2
023012 010246      MOV      R2,-(SP)
023014 010346      MOV      R3,-(SP)
023016 012746 023332      MOV      #DEVDR0,-(SP)
023022 012746 000003      MOV      #3,-(SP)
023026 010600      MOV      SP,R0
023030 104416      TRAP     C#PNTS
023032 062706 000010      ADD      #10,SP
261 023036 062704 000002      4#:     ADD      #2,R4
262 023042 005203      INC      R3
263 023044 020427 003376      CMP      R4,#ERTABE
264 023050 103701      BLO     1#
265 023052 012604      MOV      (SP)+,R4
266 023054 012603      MOV      (SP)+,R3
267 023056 012602      MOV      (SP)+,R2
268 023060      ENDRPT      ; UNUSED.
023060      L10035:
023060 104425      TRAP     C#RPT
269
270 023062      045      116      045  DEVSUM: .ASCIZ  /#MADEVICE STATUS SUMMARY:#N/
271 023117      045      101      040  DEVONL: .ASCIZ  /#A UNIT #D3#A ONLINE, ERRORS = #D#N/
272 023167      045      101      040  DEVNXR: .ASCIZ  /#A UNIT #D3#A DROPPED, NON-EXISTENT REGISTER#N/
273 023251      045      101      040  DEVNRD: .ASCIZ  /#A UNIT #D3#A DROPPED, NOT READY AT STARTUP#N/
274 023332      045      101      040  DEVDR0: .ASCIZ  /#A UNIT #D3#A DROPPED, ERRORS = #D#N/
275
276
277 023402      ENDMOD
278

```



TSV5 HARDWARE TESTS MACRO M1113 14 JUN-84 15:55  
CLEAN-UP AND REPORT CODING SECTIONS

SEQ 0103

1  
2  
9  
10 023402  
023402  
16  
24

.TITLE TSV5 - HARDWARE TESTS

BGNMOD TSV5  
TSV5::

TSV5 - HARDWARE TESTS MACRO M1113 14-JUN-84 15:55  
 TEST 1: INITIALIZE AFTER WRITE CHARACTERISTICS

SEQ 0104

```

26          .SBTTL TEST 1: INITIALIZE AFTER WRITE CHARACTERISTICS
27
28          ;* TEST DESCRIPTION:
29
30          ; This test verifies that a Hardware Initialize command
31          ; invoked after a Write Characteristics command sets up
32          ; the Command, Message and Characteristic image blocks
33          ; in the controller ram correctly.
34
35          ; TEST STEPS:
36
37          ; REPEAT FOR LOOPCNT
38          ; BEGIN
39          ; Do WRITE CHARACTERISTICS command.
40          ; If the NBA bit in the TSSR register is NOT=0 then Print Error.
41          ; Write to TSSR register to soft initialize the controller
42          ; If controller RAM 310-377 NOT=0 then Print Error
43          ; END
44
45
46
47 023402          BGNTST
48 023402
53 023402 012700 024042          MOV     @TST13ID,R0          ;ASCII MESSAGE TO IDENTIFY TEST
54 023406 004737 016510          JSR     PC,TSTSETUP          ;DO INITIAL TEST SETUP
55 023412 012737 000012 002216          MOV     @10.,LOOPCNT          ;PERFORM 10 ITERATIONS
56 023420          T13LOOP:
57 023420 004737 024316          JSR     PC,T13REST          ;SET PACKET TO START-UP VALUES
58
59 023424 012703 002764          MOV     @TSTBLK+10.,R3          ;START OF TEST DATA
60 023430 012704 024000          MOV     @T13PACKET,R4          ;GET THE ADDRESS OF COMMAND PACKET
61 023434 012764 000010 000006          MOV     @8.,PKBCNT(R4)          ;START WITH MINIMUM ALLOWABLE VALUE
62 023442          5$:
63 023442 004737 015774          JSR     PC,SOFINIT          ;WRITE TO TSSR TO SOFT INITIALIZE
64 023446 103405          BCS     10$          ;BR IF SOFT INIT OKAY
65 023450 010001          MOV     R0,R1          ;SAVE CONTENTS OF TSSR
66 023452          ERRDF  ERRNO,SFIERR,SFIMSG          ;DEVICE FATAL DURING INIT
67          023452 104455          TRAP   C$ERDF
68          023454 000144          .WORD 100
69          023456 003652          .WORD SFIERR
70          023460 012034          .WORD SFIMSG
67
68          ;Do WRITE CHARACTERISTICS command.
69 023462 005037 002222          10$: CLR     FATFLG          ;CLEAR FATAL ERROR FLAG
70 023466 010465 000000          MOV     R4,TSDB(R5)          ;SET THE PACKET ADDRESS TO EXECUTE
71 023472 004737 016336          JSR     PC,CHKTSSR          ;WAIT FOR SSR TO SET
72 023476          FORCERROR 12$          ;SSDFORCE ERROR IF FORCER=1
73 023512 103407          BCS     15$          ;BR IF CARRY SET (GOOD RETURN)
74 023514 010001          MOV     R0,R1          ;SAVE CONTENTS OF TSSR
75 023516          NEXT.ERRNO
76 023516          12$: ERRDF  ERRNO,T13SSR,PKTSSR          ;DEVICE FATAL SSR FAILED TO SET
77          023516 104455          TRAP   C$ERDF
78          023520 000145          .WORD 101
79          023522 024227          .WORD T13SSR
80          023524 012046          .WORD PKTSSR
77 023526 005237 002222          15$: INC     FATFLG          ;SET FATAL ERROR FLAG
78 023532          CKLOOP          ;LOOP ON ERROR, IF FLAG SET

```

```

      023532 104406
79 023534 016501 000002      MOV    TSSR(R5),R1      ;GET THE CONTENTS OF TSSR      TRAP    C0CLP1
80 023540 012702 000200      MOV    #SSR,R2        ;EXPECTED CONTENTS OF TSSR
81 023544 032701 000100      BIT    #OFL,R1        ;IS OFF-LINE BIT SET ?
82 023550 001402              BEQ    250             ;BRANCH IF NOT OFF-LINE
83 023552 052702 000100      BIS    #OFL,R2        ;SET OFF-LINE IN EXPECTED DATA
84
85                          ;If the NBA bit in the TSSR register is NOT=0 then Print Error.
86 023556              250:
87 023556              FORCERROR    270             ;BBD
88 023572 020201              CMP    R2,R1          ;DOES EXPECTED MATCH RECEIVED ?
89 023574 001404              BEQ    300             ;OKAY IF MATCH
90 023576              NEXT,ERRNO
91 023576 270:              ERRNO ERRNO,T13NBA,PKTSSR ;NBA NOT ZERO
      023576 104456              TRAP    C0ERRNO
      023600 000146              .WORD  102
      023602 024154              .WORD  T13NBA
      023604 012046              .WORD  PKTSSR
92 023606 300:              CKLOOP              ;LOOP ON ERROR ?
      023606 104406              TRAP    C0CLP1
93
94                          ;Write to TSSR register to soft initialize the controller
95 023610 400:              JSR    PC,SOFINIT     ;WRITE TO TSSR TO SOFT INITIALIZE
96 023610 004737 015774      FORCERROR    420             ;BBD
97 023614              BCS    500             ;BR IF SOFT INIT OKAY
98 023630 103405              MOV    R0,R1          ;SAVE CONTENTS OF TSSR
99 023632 010001              NEXT,ERRNO
100 023634 420:              ERRDF  ERRNO,SFIERR,SFIMSG ;DEVICE FATAL DURING INIT
      023634 104455              TRAP    C0ERRDF
      023636 000147              .WORD  103
      023640 003652              .WORD  SFIERR
      023642 012034              .WORD  SFIMSG
102
103                          ;If controller RAM 310-377 NOT=0 then Print Error
104 023644 012704 000310      500:              MOV    #310,R4        ;START WITH LOC 310
105 023650 005002              CLR    R2             ;MEMORY EXPECTED SHOULD BE 000000
106 023652 105065 000000      CLRB   TSD0(R5)       ;SET MAINTENANCE MODE
107 023656 004737 016336      JSR    PC,CHKTSSR     ;WAIT FOR SSR READY
108 023662 010465 000000      600:              MOV    R4,TSD0(R5)    ;SELECT RAM ADDRESS
109 023666 004737 016336      JSR    PC,CHKTSSR     ;WAIT FOR SSR READY
110 023672 116501 000000      MOVB   TSDA(R5),R1    ;READ LOC CONTENTS
111 023676              FORCERROR    620,NOTSSR ;BBD
112 023706 120102              CMPB   R1,R2          ;CHECK MEMORY FOR 000000
113 023710 001406              BEQ    700             ;BRANCH IF DATA OKAY
114 023712              NEXT,ERRNO
115 023712 620:              ERRDF  ERRNO,T13MEM,RAMEXP ;MEMORY NOT ZERO AFTER INIT.
      023712 104455              TRAP    C0ERRDF
      023714 000150              .WORD  104
      023716 024115              .WORD  T13MEM
      023720 015530              .WORD  RAMEXP
116 023722 005237 002222      700:              INC    FATFLG         ;SET THE FATAL ERROR FLAG
117 023726 700:              CKLOOP
      023726 104406              TRAP    C0CLP1
118 023730              ESCAPE  TST           ;EXIT ON FATAL ERROR
      023730 104410              TRAP    C0ESCAPE
      023732 000432              .WORD  L10036

```







TSVS - HARDWARE TESTS MACRO M1113 14-JUN-84 15:55  
TEST 2: BASIC WRITE SUBSYSTEM MEMORY COMMAND

SEQ 0109

```
273 024642 005737 002222           TST      FATFLG           ;ANY FATAL ERRORS ?
274 024646 001402                    BEQ      60$             ;BRANCH IF NOT
275 024650 004737 017202           JSR      PC,CKDROP      ;TRY TO DROP THE UNIT
276 024654                    60$:
277                                ;
278                                ;
279                                ;TEST 2, SUBTEST 2
280                                ;
281                                ;CHECK THAT NON-ZERO MODE BITS BEING SET CAUSE
282                                ;WRITE SUBSYSTEM MEMORY COMMAND TO BE REJECTED
283                                ;
284                                ;
285                                ;
286 024654                    BGNSUB           ;//////////////// BEGIN SUBTEST //////////////////
024654                                        T2.2:
024654 104402                                TRAP     C#BSUB
287
288 024656                    SETPRI   #PRI00           ;LOWER PRIORITY TO ALLOW INTERRUPTS
024656 012700 000000                                MOV      #PRI00,R0
024662 104441                                TRAP     C#SPRI
289 024664 012704 025540           5$:   MOV      #T14PK2,R4           ;GET THE ADDRESS OF COMMAND PACKET
290 024670 004737 026246           JSR      PC,T14REST      ;RESTORE PACKET TO STARTING VALUES
291 024674 004737 026304           JSR      PC,T14RST       ;RESTORE PACKET TO STARTING VALUES
292 024700                    BGNSEG           ;>>>>>>>>>>>>> BEGIN SEGMENT >>>>>>>>>>>>
024700 104404                                TRAP     C#BSEG
293
294 024702 004737 015774           JSR      PC,SOFINIT      ;DO SOFT INIT OF CONTROLLER
295 024706 103405                    BCS     10$             ;BR IF SOFT INIT = OK
299 024710 010001                    MOV     R0,R1           ;SAVE CONTENTS OF TSSR
300 024712                    ERRDF   ERRNO,SFIERR,SFIMSG ;DEVICE FATAL ERROR DURING INIT
024712 104455                                TRAP     C#ERDF
024714 000317                                .WORD   207
024716 003652                                .WORD   SFIERR
024720 012034                                .WORD   SFIMSG
301 024722                    10$:
302 024722 004737 010662           JSR      PC,WRTCHR       ;ISSUE WRITE CHARACTERISTICS
303 024726 103405                    BCS     11$             ;BR, IF COMMAND ISSUED OK
307 024730 010001                    MOV     R0,R1           ;SAVE CONTENTS OF TSSR
308 024732                    ERMRD   ERRNO,WRTMSG,SFIMSG ;WRITE SUBSYSTEM MEMORY FAILED
024732 104456                                TRAP     C#ERM RD
024734 000320                                .WORD   208
024736 005056                                .WORD   WRTMSG
024740 012034                                .WORD   SFIMSG
309 024742                    11$:
310 024742 005037 002224           CLR      INTRECV         ;CLEAR INTERRUPT RECEIVED FLAG
311 024746 012704 025120           MOV     #T14PACKET,R4    ;SET-UP WITH WRT SUBSYS MEM PACKET
312 024752 052714 007000           BIS     #007000,(R4)     ;NON-ZERO COMMAND MODE BITS
313 024756 010465 000000           MOV     R4,TSDB(R5)      ;SET THE PACKET ADDRESS
314 024762 004737 016250           JSR      PC,WAITF        ;WAIT FOR SSR TO SET
315 024766 103405                    BCS     15$             ;BR IF CARRY SET (GOOD RETURN)
316 024770 010001                    MOV     R0,R1           ;SAVE CONTENTS OF TSSR
320 024772                    ERRDF   ERRNO,T14SSR,PKTSSR ;DEVICE FATAL SSR FAILED TO SET
024772 104455                                TRAP     C#ERDF
024774 000321                                .WORD   209
024776 025733                                .WORD   T14SSR
025000 012046                                .WORD   PKTSSR
321 025002                    15$:   CKLOOP           ;LOOP ON ERROR, IF FLAG SET
```





```

369 025136          T14BFR: .BLKW  128.          ;MESSAGE BUFFER
370
371
373          025540          T14PK2:  .=<.*10>E1777?0
375 025540          ;COMMAND PACKET FOR TEST
376 025540 100204          ;WRITE CHARA. MEM. CMND., WITH IE, ACK
377 025542 025550          ;ADDRESS OF SELECT DATA BLOCK
378 025544 000000          ;WORD 0
379 025546 000010          ;WORD 8.          ;STARTING VALUE OF BLOCK SIZE
380
381
382 025550          T14DTA:          ;SELECT DATA BLOCK
383 025550 025136          ;WORD  T14BFR          ;ADDRESS OF MESSAGE BUFFER
384 025552 000000          ;WORD  0
385 025554 000400          ;WORD 256.          ;LENGTH OF MESSAGE BUFFER
386 025556 000000 000000          ;WORD 0,0
387
388
389          ;*
390          ;LOCAL TEXT MESSAGES FOR TEST
391          ;-
392
393 025562 127 122 111 T14NBA: .ASCIZ 'WRITE SUBSYSTEM MEMORY Command Not Accepted'
394 025636 127 122 111 T142REJ: .ASCIZ 'WRITE SUBSYSTEM MEMORY Not Rejected With Non-Zero Mode Field'
395 025733 103 157 156 T14SSR: .ASCIZ 'Contents of TSSR Incorrect After WRITE SUBSYSTEM MEMORY'
396 026023 105 170 160 T14NINT: .ASCIZ 'Expected Interrupt Not Received On WRITE SUBSYSTEM MEMORY'
397 026115 111 156 143 T14TSBA: .ASCIZ 'Incorrect TSBA Address After WRITE SUBSYSTEM MEMORY'
398 026201 102 141 163 TST14ID: .ASCIZ 'Basic WRITE SUBSYSTEM MEMORY Command'
399          .EVEN
400
401
402          ;*
403          ;
404          ;ROUTINE TO RESTORE COMMAND PACKET TO START-UP (DEFAULT) VALUES
405          ;WRITE SUBSYSTEM MEMORY COMMAND
406          ;
407          ;-
408
409 026246          T14REST:
410 026246          SAVREG          ;SAVE THE REGISTERS
411 026252 012701 025120          MOV      #T14PACKET,R1          ;START OF THE PACKET
412 026256 012721 100206          MOV      #100206,(R1)+          ;WRITE SUBSYSTEM MEM. WITH ACK, IE
413 026262 012721 025130          MOV      #T14DATA,(R1)+          ;ADDRESS OF DATA BLOCK
414 026266 005021          CLR      (R1)+          ;EXTENDED ADDRESS
415 026270 012721 000006          MOV      #6,(R1)+          ;SIZE OF DATA BLOCK IN BYTES
416 026274 005021          CLR      (R1)+          ;CLEAR BSEL0 AND BSEL1
417 026276 005021          CLR      (R1)+          ;CLEAR SEL2
418 026300 005011          CLR      (R1)          ;CLEAR DATA AREA
419 026302 000207          RTS      PC          ;RETURN
420
421
422 026304          T14RST:
423 026304          SAVREG          ;SAVE THE REGISTERS
424 026310 012701 025540          MOV      #T14PK2,R1          ;START OF THE PACKET
425 026314 012721 100204          MOV      #100204,(R1)+          ;WRITE CHARA. WITH ACK, IE
426 026320 012721 025550          MOV      #T14DTA,(R1)+          ;ADDRESS OF CHARAISTICS DATA BLOCK
427 026324 005021          CLR      (R1)+          ;EXTENDED ADDRESS

```

TSV5 - HARDWARE TESTS MACRO M1113 14-JUN-84 15:55  
 TEST 2: BASIC WRITE SUBSYSTEM MEMORY COMMAND

SEQ 0112

428	026326	012721	000010	MOV	#8.,(R1).	;SIZE OF DATA BLOCK IN BYTES
429	026332	012721	025136	MOV	#T14BFR,(R1).	;MESSAGE BUFFER ADDRESS
430	026336	005021		CLR	(R1).	
431	026340	012721	000400	MOV	#256.,(R1).	;LENGTH OF MESSAGE BUFFER
432	026344	005021		CLR	(R1).	
433	026346	005011		CLR	(R1)	
434	026350	005037	025136	CLR	T14BFR	;CLEAR 1ST LOC IN MESSAGE BUFFER
435	026354	000207		RTS	PC	;RETURN
436	026356			ENDTST		
	026356					L10037:
	026356	104401				TRAP C#ETST

TSV5 HARDWARE TESTS MACRO M1113 14-JUN-84 15:55  
 TEST 2: BASIC WRITE SUBSYSTEM MEMORY COMMAND

SEQ 0113

```

438
439
440
441
442
443
444
445
446
447
448
449
450
451
452
453
454
455
456
457
458
459
460
461
462
463
464
465 026360
026360
470 026360 012700 030430
471 026364 004737 016510
472 026370 012737 000012 002216
473 026376 005237 003150
474 026402 004737 021232
475
476 026406
477
478
479
480
481
482
483
484
485
486
487
488
489
490
491
492
493
494
495
496
497

          .SBTTL TEST 3: DMA MEMORY ADDRESSING
          ;**
          ; TEST 3
          ;
          ; TEST DESCRIPTION
          ;
          ; This test verifies that the controller can properly address and
          ; access all available CPU memory (other than that occupied by the
          ; diagnostic and diagnostic supervisor code) for both reading (DATI)
          ; and writing (DATO). Verified are the LSI-11 Bus drivers for all
          ; available address lines. Up to this point only 16 bits have been
          ; used for DMA transfers.
          ;
          ; TEST STEPS
          ;
          ; REPEAT FROM 1 TO LOOPCNT
          ; BEGIN
          ; Do Subtest 1 - Verify GET STATUS selected locations
          ; Do Subtest 2 - Verify message packets selected locations
          ; Do Subtest 3 - Verify Characteristic data selected locations
          ; Do Subtest 4 - Verify NXM to selected invalid addresses
          ; END
          ;--

          BGNTST
          ;
          ; T3:
          ; ASCII MESSAGE TO IDENTIFY TEST
          ; DO INITIAL TEST SETUP
          ; PERFORM 10 ITERATIONS
          ; SET TEST FLAG
          ; CHECK MEMORY

          T12LOOP:
          ; LOOP ON TEST LABEL

          .SBTTL TEST 3: SUBTEST 1: GET STATUS SELECTED LOCATIONS
          ;**
          ; TEST 3: SUBTEST 1:
          ;
          ; SUBTEST DESCRIPTION:
          ;
          ; This subtest verifies the controller can fetch a get status
          ; command from all available memory locations.
          ; Two word blocks are tested one at a time by first setting
          ; all available memory to a background pattern of 125252.
          ; A Get Status command is then executed to various addresses in
          ; each available memory 4k word block. The various addresses
          ; are determined by floating a 1 then a 0 through the address bits.
          ;
          ; TEST STEPS:
          ;
          ; BEGIN
          ; Write to TSSR to soft initialize
          ; Do a WRITE CHARACTERISTICS to setup a message buffer
  
```

```

498      : REPEAT FOR SELECTED VALID ADDRESSES IN DIAGNOSTIC FREE SPACE AND ABOVE 32K
499      : BEGIN
500      :     Get a valid modulo 4 test address
501      :     Do a GET STATUS command from the test address
502      :     END
503      : END
504      :
505
506 026406      BGNSUB      ;//////////////// BEGIN SUBTEST //////////////////
      026406      T3.1:
      026406 104402      TRAP      C#BSUB
507
508
509      ;Write to TSSR to soft initialize
510 026410 004737 015774      JSR      PC,SOFINIT      ;DO SOFT INIT OF CONTROLLER
511 026414 103405      BCS      15$      ;BR IF SOFT INIT = OK
512 026416      NEXT.ERRNO
513 026416 010001      MOV      R0,R1      ;SAVE CONTENTS OF TSSR
514 026420      ERRDF      ERRNO,SFIERR,SFIMSG      ;DEVICE FATAL ERROR DURING INIT
      026420 104455      TRAP      C#ERDF
      026422 000455      .WORD      301
      026424 003652      .WORD      SFIERR
      026426 012034      .WORD      SFIMSG
515
516      ;Do a WRITE CHARACTERISTICS to setup a message buffer
517 026430 15$:
518 026430 012704 030220      MOV      @T12PACKET,R4      ;GET THE ADDRESS OF COMMAND PACKET
519 026434 004737 031600      JSR      PC,T12SWRT      ;RESTORE PACKET TO STARTING VALUES
520 026440 005037 003134      CLR      KTENABLE      ;TURN OFF KT-11
521 026444 010465 000000      MOV      R4,TSDB(R5)      ;SET THE PACKET ADDRESS
522 026450 004737 016336      JSR      PC,CHKTSSR      ;WAIT FOR SSR TO SET
523 026454      FORCERROR      17$
524 026470 103405      BCS      20$      ;BR IF SSR SET IN CHKTSSR
525 026472 010001      MOV      R0,R1      ;SAVE CONTENTS OF TSSR
526 026474      NEXT.ERRNO
527 026474 17$:      ERRDF      ERRNO,T12WRTSSR,PKTSSR      ;DEVICE FATAL SSR FAILED TO SET
      026474 104455      TRAP      C#ERDF
      026476 000456      .WORD      302
      026500 030532      .WORD      T12WRTSSR
      026502 012046      .WORD      PKTSSR
528
529      ;Verify a Get Status can be fetched from each address
530      ;Get a valid modulo-4 test address
531      ;Do a GET STATUS command from the test address
532 026504 005037 002222      20$:      CLR      FATFLG      ;CLEAR FATAL ERROR FLAG
533 026510 005037 030270      CLR      T12KT      ;TEST ABOVE 28K SWITCH
534 026514 012702 030274      MOV      @T12BLK,R2      ;POINT TO TEST PATTERN TABLE
535 026520      T121LOOP:
536 026520 005037 003134      CLR      KTENABLE      ;TURN OFF ABOVE 28K TEST FLAG
537 026524 012201      MOV      (R2)+,R1      TEST PATTERN ADDRESS
538 026526 005000      CLR      R0      . SURE NO TEST ABOVE 28K
539 026530 005737 030270      TST      T12KT      ;TEST ABOVE 28K THIS TIME?
540 026534 001407      BEQ      25$      ;BR IF NO
541 026536 016200 177776      MOV      -2(R2),R0      ;GET TEST PATTERN AGAIN
542 026542 042700 177774      BIC      @C<A1716>,R0      ;SAVE 18 BIT ADDRESS ONLY
543 026546 012737 000001 003134      MOV      @1,KTENABLE      ;TURN ON ABOVE 28K TEST FLAG
544 026554 004737 031276      25$:      JSR      PC,T12CONVERT      ;CONVERT TEST PATTERN TO TEST ADDRESS
    
```

```

545 026560 103034          BCC      65$          ;BR IF INVALID PACKET ADDRESS
546 026562 013704 030264  MOV     T12LOADD,R4      ;COPY CURRENT PACKET LOW ADDRESS
547 026566 013703 030262  MOV     T12HIADD,R3      ;COPY CURRENT PACKET HIGH ADDRESS
548 026572 004737 031646  JSR     PC,T12SETGET     ;SETUP CURRENT PACKET TO GET STATUS
549 026576 042703 177774  BIC     #1C<A1716>,R3    ;SAVF ADDRESS BITS 17+16
550 026602 050304          BIS     R3,R4            ;SETUP 18 BIT PACKET ADDRESS
551 026604 004737 017274  JSR     PC,KTOFF         ;TURN OFF KT-11
552 026610 010465 000000  MOV     R4,TSD8(R5)      ;SET THE PACKET ADDRESS TO EXECUTE
553 026614 004737 016336  JSR     PC,CHKTSSR       ;WAIT FOR SSR TO SET
554 026620          FORCERROR      32$
555 026634 103405          BCS     40$             ;BR IF SSR SET IN CHKTSSR
556 026636 010001          MOV     R0,R1           ;SAVE CONTENTS OF TSSR
557 026640          NEXT.ERRNO
558 026640          32$:      ERROF      ERRNO,T12GETSSR,PKTGETS ;DEVICE FATAL SSR FAILED TO SET
                                TRAP      C1ERDF
                                .WORD    303
                                .WORD    T12GETSSR
                                .WORD    PKTGETS
559 026650          40$:      CKLOOP          ;LOOP ON ERROR, IF FLAG SET
                                TRAP      C1CLP1
560 026652          65$:
561 026652          FORCEEXIT      80$
562 026662 020227 030426  CMP     R2,#T12TBE       ;DONE ALL TSTBLK TEST PATTERNS?
563 026666 103002          BHIS    70$             ;BR IF YES
564 026670 000137 026520  JMP     T121LOOP         ;DO ANOTHER MODULO 4 ADDRESS
565 026674 005737 030270  70$:   TST     T12KT        ;DONE ABOVE 28K TESTING TOO?
566 026700 003012          BGT     80$             ;BR IF YES
567 026702 005737 003132  TST     KTFLG            ;ANY MEMORY ABOVE 28K ON SYSTEM?
568 026706 001407          BEQ     80$             ;BR IF NO
569 026710 012737 000001 030270  MOV     #1,T12KT         ;SET SWITCH
570 026716 012702 030274  MOV     #T12BLK,R2       ;RESET TEST PATTERN TABLE
571 026722 000137 026520  JMP     T121LOOP         ;DO ABOVE 28K TESTING
572 026726 004737 017274  80$:   JSR     PC,KTOFF         ;TURN OFF KT11
573 026732          ENDSUB          ;////////////////// END SUBTEST ////////////////////
                                L10043:
                                TRAP      C1ESUB
574 026734 005737 002222  TST     FATFLG           ;ANY FATAL ERRORS ?
575 026740 001402          BEQ     100$           ;BRANCH IF NOT
576 026742 004737 017202  JSR     PC,CKDROP        ;TRY TO DROP THE UNIT
577 026746          100$:

```

.SBTTL TEST 3: SUBTEST 2: MESSAGE PACKETS TO SELECTED LOCATIONS

```

580          ;**
581          ; TEST 3: SUBTEST 2:
582          ;
583          ; SUBTEST DESCRIPTION:
584          ;
585          ; This subtest verifies the controller can deposit message packets
586          ; to all available memory locations.
587          ; Write Characteristic commands are executed with message
588          ; buffer addresses set to various addresses in each available
589          ; memory location.
590          ; The various addresses are determined by floating a 1 then a 0
591          ; through the address bits.
592          ;
593          ; TEST STEPS:
594          ;

```

TSVS - HARDWARE TESTS MACRO M1113 14-JUN-84 15:55  
 TEST 3: SUBTEST 2: MESSAGE PACKETS TO SELECTED LOCATIONS

SEQ 0116

```

595      ; BEGIN
596      ;   Write to TSSR to soft initialize
597      ;   Do a WRITE CHARACTERISTICS to setup a message buffer to compare
598      ;
599      ; REPEAT FOR SELECTED ADDRESSES IN DIAGNOSTIC FREE SPACE AND ABOVE 32K
600      ; BEGIN
601      ;   Get a valid modulo-4 test address
602      ;   Set the packet message buffer to the TEST ADDRESS
603      ;   Do a WRITE CHARACTERISTICS
604      ;   Restore the test message buffer to background pattern
605      ;
606      ; END
607      ;
608      ;
609      ; BGNSUB                               ;//////////////// BEGIN SUBTEST //////////////////
610      ;                                     ;T3.2:
611      ;                                     ;TRAP      C#BSUB
612      ;
613      ;Write to TSSR to soft initialize
614      ;JSR      PC,SOFINIT                   ;DO SOFT INIT OF CONTROLLER
615      ;BCS      15#                          ;BR IF SOFT INIT = OK
616      ;NEXT.ERRNO
617      ;MOV      R0,R1                         ;SAVE CONTENTS OF TSSR
618      ;ERRDF   ERRNO,SFIERR,SFIMSG          ;DEVICE FATAL ERROR DURING INIT
619      ;                                     ;TRAP      C#ERDF
620      ;                                     ;.WORD    304
621      ;                                     ;.WORD    SFIERR
622      ;                                     ;.WORD    SFIMSG
623      ;
624      ;Do a WRITE CHARACTERISTICS to setup a message buffer to compare
625      ;15#:
626      ;MOV      #T12PACKET,R4                ;GET THE ADDRESS OF COMMAND PACKET
627      ;JSR      PC,T12SWRT                   ;SET PACKET TO WRITE CHARACTERISTICS
628      ;JSR      PC,KTOFF                     ;TURN OFF KT-11
629      ;MOV      R4,TSD8(R5)                 ;SET THE PACKET ADDRESS
630      ;JSR      PC,CHKTSSR                   ;WAIT FOR SSR TO SET
631      ;FORCERROR 17#
632      ;BCS      20#                          ;BR IF SSR SET IN CHKTSSR
633      ;MOV      R0,R1                         ;SAVE CONTENTS OF TSSR
634      ;NEXT.ERRNO
635      ;17#: ERRDF ERRNO,T12WRTSSR,PKTSSR    ;DEVICE FATAL SSR FAILED TO SET
636      ;                                     ;TRAP      C#ERDF
637      ;                                     ;.WORD    305
638      ;                                     ;.WORD    T12WRTSSR
639      ;                                     ;.WORD    PKTSSR
640      ;
641      ;Get a valid modulo-4 test address
642      ;Set the packet message buffer to the test address
643      ;Do a WRITE CHARACTERISTICS
644      ;20#: CLR      FATFLG                   ;CLEAR FATAL ERROR FLAG
645      ;MOV      #T12BLK,R3                   ;POINT TO TEST PATTERN TABLE
646      ;T122LOOP:
647      ;MOV      (R3)+,R1                     ;GET TEST PATTERN ADDRESS
648      ;MOV      R1,R0                         ;GET ADDRESS ALL "18 BITS"
649      ;BIC      #177774,R0                  ;LEAVE ONLY A17 AND A16
650      ;BIC      #3,R1                        ;GET RID OF A17 AND A16

```

TSV5 - HARDWARE TESTS MACRO M1113 14-JUN-84 15:55  
 TEST 3: SUBTEST 2: MESSAGE PACKETS TO SELECTED LOCATIONS

SEQ 0117

```

642 027070 004737 031276      JSR    PC,T12CONVERT      ;CONVERT TEST PATTERN TO TEST ADDRESS
643 027074 103402              BCS    25$                ;BR IF VALID MESSAGE BUFFER ADDRESS
644 027076 000137 027174              JMP    150$               ;GET ANOTHER TEST PATTERN TO TRY
645 027102 012704 030220      25$:  MOV    @T12PACKET,R4    ;SET THE COMMAND PACKET ADDRESS
646 027106 004737 031600      JSR    PC,T12SWRT        ;SETUP T12PACKET TO WRITE CHAR.
647 027112 013737 030264 030230  MOV    T12LOADD,T12DATA  ;SETUP LOW ORDER MESSAGE BUFFER ADD.
648 027120 013737 030262 030232  MOV    T12HIADD,T12DATA+2 ;SETUP HIGH ORDER MESSAGE BUFFER ADD.
649 027126 004737 017274      JSR    PC,K1OFF          ;TURN OFF KT-11
650 027132 010465 000000      MOV    R4,TSDB(R5)      ;SET THE PACKET ADDRESS TO EXECUTE
651 027136 004737 016336      JSR    PC,CHKTSSR       ;WAIT FOR SSR TO SET
652 027142              FORCERROR 32$
653 027156 103405              BCS    50$                ;BR IF SSR SET IN CHKTSSR
654 027160 010001              MOV    R0,R1            ;SAVE CONTENTS OF TSSR
655 027162              NEXT.ERRNO
656 027162 32$:  ERRDF  ERRNO,T12WRTSSR,PKTSSR ;DEVICE FATAL SSR FAILED TO SET
        027162 104455              TRAP   C$ERDF
        027164 000462              .WORD  306
        027166 030532              .WORD  T12WRTSSR
        027170 012046              .WORD  PKTSSR
657 027172 50$:  CKLOOP              ;LOOP ON ERROR, IF FLAG SET
        027172 104406              TRAP   C$CLP1
658 027174 150$:
659 027174              FORCEXIT 160$
660 027204 020327 030426      CMP    R3,@T12TBE        ;DONE ALL TST12BLK TEST PATTERNS?
661 027210 103002              BHIS   160$              ;BR IF YES
662 027212 000137 027054      JMP    T122LOOP          ;DO ANOTHER MODULO 4 ADDRESS
663 027216 004737 017274      160$: JSR    PC,K1OFF          ;TURN OFF KT11
664 027222              ENDSUB                  ;////////////////// END SUBTEST ////////////////////
        027222              L10044:
        027222 104403              TRAP   C$ESUB
665 027224 005737 002222      TST    FATFLG            ;ANY FATAL ERRORS ?
666 027230 001402              BEQ    180$              ;BRANCH IF NOT
667 027232 004737 017202      JSR    PC,CKDROP        ;TRY TO DROP THE UNIT
668 027236 180$:

```

.SBTTL TEST 3: SUBTEST 3: CHARACTERISTIC DATA SELECTED LOCATIONS

```

; **
; TEST 3: SUBTEST 3:
;
; SUBTEST DESCRIPTION:
;
; This subtest verifies the controller can fetch a
; Write Characteristics data block from all available
; memory locations.
; Write Characteristics commands are executed with
; characteristic data blocks at various memory addresses.
; The various memory addresses are determined by floating
; a 1 then a 0 through the address bits.
;
; TEST STEPS:
;
; BEGIN
; Write to TSSR to soft initialize
;
; REPEAT FOR SELECTED VALID ADDRESSES IN DIAGNOSTIC FREE SPACE AND ABOVE 32K

```

669  
670  
671  
672  
673  
674  
675  
676  
677  
678  
679  
680  
681  
682  
683  
684  
685  
686  
687  
688  
689  
690  
691

TSVS HARDWARE TESTS MACRO M1113 14 JUN 84 15:55  
 TEST 3: SUBTEST 3: CHARACTERISTIC DATA SELECTED LOCATIONS

SEQ 0118

```

692          :          BEGIN
693          :          Get a valid test address
694          :          Set the test packet characteristic data pointer to the
695          :          test address.
696          :          Store expected characteristic data in test address block
697          :          Do a WRITE CHARACTERISTIC command
698          :          END
699          :          END
700          :
701          :
702 027236      BGNSUB          ;//////////////// BEGIN SUBTEST //////////////////
          027236          T3.3:
          027236 104402          TRAP      C#BSUB
703
704
705          ;Write to TSSR to soft initialize
706 027240 004737 015774      JSR      PC,SOFINIT          ;DO SOFT INIT OF CONTROLLER
707 027244 103405          BCS      20;          ;BR IF SOFT INIT = OK
708 027246          NEXT.ERRNO
709 027246 010001          MOV      R0,R1          ;SAVE CONTENTS OF TSSR
710 027250          ERROF      ERRNO,SFIERR,SFIMSG ;DEVICE FATAL ERROR DURING INIT
          027250 104455          TRAP      C#EROF
          027252 000463          .WORD    307
          027254 003652          .WORD    SFIERR
          027256 012034          .WORD    SFIMSG
711
712          ;Get a valid test address
713 027260 005037 002222      20;:   CLR      FATFLG          ;CLEAR FATAL ERROR FLAG
714 027264 005037 030270      CLR      T12KT          ;TEST ABOVE 20K SWITCH
715 027270 012703 030274      MOV      @T12BLK,R3    ;POINT TO TEST PATTERN TABLE
716 027274          T123LOOP:
717 027274 005037 003134      CLR      KTENABLE          ;TURN OFF ABOVE 20K TEST FLAG
718 027300 012301          MOV      (R3),R1          ;GET TEST PATTERN ADDRESS
719 027302 010100          MOV      R1,R0          ;GET ADDRESS ALL "18 BITS"
720 027304 042700 177774      BIC      @177774,R0    ;LEAVE ONLY A17 AND A16
721 027310 042701 000003      BIC      @3,R1          ;GET RID OF A17 AND A16
722 027314 005737 030270      TST      T12KT          ;TEST ABOVE 20K THIS TIME?
723 027320 001407          BEQ      25;          ;BR IF NO
724 027322 016300 177776      MOV      -2(R3),R0    ;GET TEST PATTERN AGAIN
725 027326 042700 177774      BIC      @C<A1716>,R0 ;SAVE 18 BIT ADDRESS ONLY
726 027332 012737 000001 003134      MOV      @1,KTENABLE    ;TURN ON ABOVE 20K TEST FLAG
727 027340 004737 031276      25;:   JSR      PC,T12CONVERT ;CONVERT TEST PATTERN TO TEST ADDRESS
728 027344 103402          BCS      30;          ;BR IF VALID TEST ADDRESS
729 027346 000137 027450      JMP      60;          ;GET NEXT TEST PATTERN
730
731          ;Set the test packet characteristic data pointer to the test address
731 027352 012704 030220      30;:   MOV      @T12PACKET,R4 ;GET THE ADDRESS OF COMMAND PACKET
732 027356 004737 031600      JSR      PC,T12SWRT    ;RESTORE PACKET TO STARTING VALUES
733 027362 013764 030264 000002      MOV      T12LOADD,PKLOW(R4) ;STORE CHAR. DATA PTR LOW ADDRESS
734 027370 013764 030262 000004      MOV      T12HIADD,PKHI(R4) ;STORE CHAR. DATA PTR HIGH ADDRESS
735 027376 004737 031710      JSR      PC,T12CHAR    ;STORE EXPECTED DATA IN DATA BLOCK
736
737          ;Do a WRITE CHARACTERISTIC command
737 027402 004737 017274      JSR      PC,KTOFF          ;TURN OFF KT-11
738 027406 010465 000000      MOV      R4,TSDB(R5)    ;SET THE PACKET ADDRESS TO EXECUTE
739 027412 004737 016336      JSR      PC,CHKTSSR    ;WAIT FOR SSR TO SET
740 027416          FORCERROR      32;
741 027432 103405          BCS      40;          ;BR IF SSR SET IN CHKTSSR
742 027434 010001          MOV      R0,R1          ;SAVE CONTENTS OF TSSR

```



TSVS HARDWARE TESTS MACRO M1113 14-JUN-84 15:55  
 TEST 3: SUBTEST 3: CHARACTERISTIC DATA SELECTED LOCATIONS

SE0 0119

```

743 027436
744 027436 320: NEXT,ERRNO
      027435 104455 ERRDF ERRNO,T12WRTSSR,PKTSSR ;DEVICE FATAL SSR FAILED TO SET
      027440 000464 TRAP C0ERRDF
      027442 030532 .WORD 308
      027444 012046 .WORD T12WRTSSR
      .WORD PKTSSR
745 027446 400: CKLOOP ;LOOP ON ERROR, IF FLAG SET
      027446 104406 TRAP C0CLP1
746 027450 600:
747 027450 020327 030426 CMP R3,@T12TBE ;DONE ALL TSTBLK TEST PATTERNS?
748 027454 103002 BHIS 650 ;BR IF YES
749 027456 000137 027274 JMP T123LOOP ;DO ANOTHER MODULO- 4 ADDRESS
750 027462 005737 030270 650: TST T12KT ;DONE ABOVE 28K TESTING TOO?
751 027466 003012 BGT 700 ;BR IF YES
752 027470 005737 003132 TST KTFLG ;ANY MEMORY ABOVE 28K ON SYSTEM?
753 027474 001407 BEQ 700 ;BR IF NO
754 027476 012737 000001 030270 MOV @1,T12KT ;SET SWITCH
755 027504 012703 030274 MOV @T12BLK,R3 ;RESET TEST PATTERN TABLE
756 027510 000137 027274 JMP T123LOOP ;DO ABOVE 28K TESTING
757 027514 004737 017274 700: JSR PC,KTOFF ;TURN OFF KT11
758 027520 ENDSUB ;////////// END SUBTEST ////////////
      027520 L10045: TRAP C0ESUB
      027520 104403
759 027522 005737 002222 TST FATFLG ;ANY FATAL ERRORS ?
760 027526 001402 BEQ 750 ;BRANCH IF NOT
761 027530 004737 017202 JSR PC,CKDROP ;TRY TO DROP THE UNIT
762 027534 750:
763
764 .SBTTL TEST 3: SUBTEST 4: NXM TO SELECTED INVALID ADDRESSES
765
766 ;*
767 ; TEST 3: SUBTEST 4:
768 ;
769 ; SUBTEST DESCRIPTION:
770 ;
771 ; This subtest verifies the NXM error bit in the TSSR
772 ; register is set when attempting to fetch data (a characteristic
773 ; data block) from selected nonexistent locations.
774 ; If NXM fails to set it is likely that an LSI-11 Bus driver is
775 ; failing to assert an address line.
776 ; Addresses tested include all combinations of high-order address
777 ; bits (i.e bits 16-21).
778 ; *****
779 ; CAUTION
780 ;
781 ; The LSI BUS drivers for all available address lines(16-21)
782 ; are only checked when running on a 11/238 system with more than
783 ; 128K words of memory!
784 ; *****
785 ; TEST STEPS:
786 ;
787 ; BEGIN
788 ; Write to TSSR to soft initialize
789 ; Do a write characteristic command
790 ; Invert the extended features switch
791 ;
792 ; REPEAT FOR SELECTED NON-EXISTENT MEMORY ADDRESSES

```

```

793          :          BEGIN
794          :          Get an invalid test address
795          :          Set the test packet characteristic data pointer to the
796          :          test address.
797          :          Do a WRITE CHARACTERISTIC command
798          :          If TSSR register NXM bit not set then print error message
799          :          END
800          :          END
801          :
802          :
803 027534      BGNSUB          ;//////////////// BEGIN SUBTEST //////////////////
      027534          T3.4:          TRAP      C1BSUB
      027534 104402
804
805
806 027536 005737 003144      TST      T23A          ;26-APR-83 REV B - CHK FOR 23A CPU
807 027542 001406          BEQ      5#          ;26-APR-83 REV B - BR, IF NOT 23A
808 027544 023727 002120 007777  CMP      L#TIME,07777 ;26-APR-83 REV B - CHK FOR > 256KB
809 027552 103402          BLO      5#          ;26-APR-83 REV B - BR, IF < 256KB
810 027554 000137 030146      JMP      NOEXTF      ;26-APR-83 REV B   JMP OVER 256KB
811 027560          S#:
812 027560 005737 003136      TST      NXMFLG      ;GOT ENOUGH MEMORY?
813 027564 001002          BNE      10#         ;IF SET STAY
814 027566 000137 030146      JMP      NOEXTF      ;LEAVE IF NOT SET
815
816          ;Write to TSSR to soft initialize
817
818 027572 004737 015774      10#:   JSR      PC,SOFINIT      ;DO SOFT INIT OF CONTROLLER
819 027576 103405          BCS      11#         ;BR IF SOFT INIT - OK
820 027600          NEXT.ERRNO
821 027600 010001          MOV      R0,R1      ;SAVE CONTENTS OF TSSR
822 027602          ERROF   ERRNO,SFIERR,SFIMSG ;DEVICE FATAL ERROR DURING INIT
      027602 104455          TRAP      C1ERDF
      027604 000465          .WORD    309
      027606 003652          .WORD    SFIERR
      027610 012034          .WORD    SFIMSG
823
824          ;Do a WRITE CHARACTERISTIC command so to invert switch
825
826 027612      11#:   CKLOOP          ;LOOP IF SELECTED
      027612 104406          TRAP      C1CLP1
827 027614 012704 030220      MOV      @T12PACKET,R4 ;GET THE ADDRESS OF COMMAND PACKET
828 027620 004737 031600      JSR      PC,T12SWRT ;RESTORE PACKET TO STARTING VALUES
829 027624 005037 003134      CLR      KTENABLE ;TURN OFF KT-11
830 027630 010465 000000      MOV      R4,TSDB(R5) ;SET THE PACKET ADDRESS
831 027634 004737 016336      JSR      PC,CHKTSSR ;WAIT FOR SSR TO SET
832 027640          FORCERROR 15#
833 027654 103405          BCS      17#         ;BR IF SSR SET IN CHKTSSR
834 027656 010001          MOV      R0,R1      ;SAVE CONTENTS OF TSSR
835 027660          NEXT.ERRNO
836 027660      15#:   ERROF   ERRNO,T12WRTSSR,PKTSSR ;DEVICE FATAL SSR FAILED TO SET
      027660 104455          TRAP      C1ERDF
      027662 000466          .WORD    310
      027664 030532          .WORD    T12WRTSSR
      027666 012046          .WORD    PKTSSR
837 027670      17#:   CKLOOP          ;LOOP IF SELECTED
      027670 104406          TRAP      C1CLP1

```

TSVS - HARDWARE TESTS MACRO M1113 14-JUN-84 15:55  
 TEST 3: SUBTEST 4: NXM TO SELECTED INVALID ADDRESSES

SEQ 0121

```

838 027672 004737 021142          JSR    PC,INVERT          ;INVERT THE SWITCH
839
840          ;Get an invalid test address
841
842 027676 005037 002222          20$:   CLR    FATFLG          ;CLEAR FATAL ERROR FLAG
843 027702          25$:
844 027702 013737 003142 030262          MOV    NXMHI,T12HIADD        ;SAVE TEST ADDRESS HIGH
845 027710 013737 003140 030264          MOV    NXML0,T12LOADD        ;SAVE TEST ADDRESS LOW
846 027716          T124LOOP:
847
848          ;Set the test packet characteristics data pointer to the
849          ; test address.
850
851 027716 012704 030220          30$:   MOV    @T12PACKET,R4        ;GET THE ADDRESS OF COMMAND PACKET
852 027722 004737 031600          JSR    PC,T12SWRT            ;RESTORE PACKET TO STARTING VALUES
853 027726 013764 030264 000002          MOV    T12LOADD,PKLOW(R4)    ;STORE CHAR. DATA PTR LOW ADDRESS
854 027734 013764 030262 000004          MOV    T12HIADD,PKHI(R4)     ;STORE CHAR. DATA PTR HIGH ADDRESS
855
856          ;Do a WRITE CHARACTERISTIC command
857 027742 004737 017274          JSR    PC,KTOFF              ;TURN OFF KT-11
858 027746 010465 000000          MOV    R4,TSDB(R5)           ;SET THE PACKET ADDRESS TO EXECUTE
859 027752 004737 016250          JSR    PC,WAITF              ;WAIT FOR SSR TO SET
860 027756          FORCERROR          32$
861 027772 103407          BCS    40$                    ;BR IF SSR SET IN CHKTSSR
862 027774 010001          MOV    R0,R1                 ;SAVE CONTENTS OF TSSR
863 027776          NEXT.ERRNO
864 027776          32$:   ERROF   ERRNO,T12WRTSSR,PKTSSR ;DEVICE FATAL SSR FAILED TO SET
      TRAP    C#ERDF
      .WORD   311
      .WORD   T12WRTSSR
      .WORD   PKTSSR
      027776 104455
      030000 000467
      030002 030532
      030004 012046
865 030006 005237 002222          INC    FATFLG                ;SET FATAL ERROR FLAG
866 030012          40$:   CKLOOP              ;LOOP ON ERROR, IF FLAG SET
      TRAP    C#CLP1
      030012 104406
      FORCERROR          45$,NOTSSR
867 030014          ESCAPE  SUB                  ;BY-PASS SUBTEST IF FATAL ERROR
      TRAP    C#ESCAPE
      .WORD   L10046-.
868 030024          030024 104410
      030026 000124
869          ;If TSSR register NXM bit not set then print error message
870 030030          45$:
871 030030 016501 000002          MOV    TSSR(R5),R1           ;GET TSSR CONTENTS
872 030034          FORCERROR          52$
873 030050 032701 004000          BIT    @NXM,R1               ;NXM SET?
874 030054 001012          BNE    60$                    ;BR IF YES
875 030056          NEXT.ERRNO
876 030056 013737 030264 002240          52$:   MOV    T12LOADD,ERRLO        ;MEMORY TEST ADDRESS LOW
877 030064 013737 030262 002236          MOV    T12HIADD,ERRHI        ;MEMORY TEST ADDRESS HIGH
878 030072          ERRMRD   ERRNO,T12NXM,ADSSR ;REPORT ADDRESS AND TSSR ERROR
      TRAP    C#ERHRD
      .WORD   312
      .WORD   T12NXM
      .WORD   ADSSR
      030072 104456
      030074 000470
      030076 031167
      030100 012126
879
880 030102          60$:   CKLOOP              ;LOOP ON ERROR, IF FLAG SET
      TRAP    C#CLP1
      030102 104406
      FORCEXIT          90$
881 030104          TST    T23A
882 030114 005737 003144          ;IS IT A 11/23A?

```

```

883 030120 001012      BNE      90$      ;YES WERE DONE
884 030122 013700 030262  MOV      T12HIADD,RO ;GET CURRENT HIGH ADDRESS
885 030126 005200      65$: INC      RO      ;GET NEXT ADDRESS
886 030130 020027 000077  CMP      RO,#77    ;DONE A21-A16?
887 030134 101004      BHI      90$      ;BR IF YES
888 030136 010037 030262  75$: MOV      RO,T12HIADD ;SETUP NEW HIGH ORDER ADDRESS
889 030142 000137 027716  JMP      T124LOOP ;DO ANOTHER NON-EXISTENT ADDRESS
890 030146
891 030146
892 030146 004737 017274      JSR      PC,KTOFF ;TURN OFF KT11
893 030152      ENDSUB ;////////////////// END SUBTEST ////////////////////
      030152      L10046: TRAP      C$ESUB
      030152 104403
894 030154 005737 002222      TST      FATFLG ;ANY FATAL ERRORS ?
895 030160 001402      BEQ      100$    ;BRANCH IF NOT
896 030162 004737 017202      JSR      PC,CKDROP ;TRY TO DROP THE UNIT
897 030166 004737 016456 100$: JSR      PC,TSTLOOP ;SHOULD WE DO ITERATIONS?
898 030172 103002      BCC      105$    ;BR IF NO
899 030174 000137 026406  JMP      T12LOOP ;LOOP UNTIL ITERATION COUNT DONE
900 030200
901 030200 004737 017274      JSR      PC,KTOFF ;TURN OFF MEMORY MANAGEMENT
902 030204 005037 003150  CLR      T3BFLG ;CLEAR TEST FLAG
903 030210      EXIT      TST ;ALL DONE THIS TEST
      030210 104432      TRAP      C$EXIT
      030212 001540      .WORD    L10042-.

904
905
906
907 ;*
908 ;LOCAL STORAGE FOR THIS TEST
909 ;
911      .=<..*10>&177770
913 030220 T12PACKET: ;COMMAND PACKET FOR TEST
914 030220 100004      .WORD    100004 ;WRITE CHARACTERISTICS COMMAND, WITH ACK
915 030222 030230      .WORD    T12DATA ;ADDRESS OF CHARACTERISTICS BLOCK
916 030224 000000      .WORD    0
917 030226 000010      .WORD    8. ;STARTING VALUE OF BLOCK SIZE
918
919 030230 T12DATA: ;CHARACTERISTICS DATA BLOCK
920 030230 030242      .WORD    T12BFR ;LOW ADDRESS OF MESSAGE BUFFER
921 030232 000000      .WORD    0 ;HIGH ORDER OF MESSAGE BUFFER
922 030234 000016      .WORD    14. ;LENGTH OF MESSAGE BUFFER
923 030236 000000 000000      .WORD    0,0
924
925 030242 T12BFR: .BLKW 8. ;MESSAGE BUFFER
926
927 030262 000000 T12HIADD: .WORD 0 ;HIGH ADDRESS
928 030264 000000 T12LOADD: .WORD 0 ;LOW ADDRESS
929 030266 000000 T12PAR6: .WORD 0 ;ADDRESS IN PAR FORMAT
930 030270 000000 T12KT: .WORD 0 ;TEST ABOVE 28K SWITCH
931 030272 000000 T124TST: .WORD 0 ;ADDRESS TEST BIT
932
933 ;*
934 ;
935 ;TABLE OF ADDRESSES
936 ;
937 030274 000001 T12BLK: .WORD 000001
    
```

TSV5 - HARDWARE TESTS MACRO M1113 14-JUN-84 15:55  
 TEST 3: SUBTEST 4: NXM TO SELECTED INVALID ADDRESSES

SEQ 0123

938	030276	000002	.WORD	000002
939	030300	000003	.WORD	000003
940	030302	000005	.WORD	000005
941	030304	000006	.WORD	000006
942	030306	000007	.WORD	000007
943	030310	000011	.WORD	000011
944	030312	000012	.WORD	000012
945	030314	000013	.WORD	000013
946	030316	000021	.WORD	000021
947	030320	000022	.WORD	000022
948	030322	000023	.WORD	000023
949	030324	000041	.WORD	000041
950	030326	000042	.WORD	000042
951	030330	000043	.WORD	000043
952	030332	000101	.WORD	000101
953	030334	000102	.WORD	000102
954	030336	000103	.WORD	000103
955	030340	000201	.WORD	000201
956	030342	000202	.WORD	000202
957	030344	000203	.WORD	000203
958	030346	000401	.WORD	000401
959	030350	000402	.WORD	000402
960	030352	000403	.WORD	000403
961	030354	001001	.WORD	001001
962	030356	001002	.WORD	001002
963	030360	001003	.WORD	001003
964	030362	002001	.WORD	002001
965	030364	002002	.WORD	002002
966	030366	002003	.WORD	002003
967	030370	004001	.WORD	004001
968	030372	004002	.WORD	004002
969	030374	004003	.WORD	004003
970	030376	010001	.WORD	010001
971	030400	010002	.WORD	010002
972	030402	010003	.WORD	010003
973	030404	020001	.WORD	020001
974	030406	020002	.WORD	020002
975	030410	020003	.WORD	020003
976	030412	040001	.WORD	040001
977	030414	040002	.WORD	040002
978	030416	040003	.WORD	040003
979	030420	100001	.WORD	100001
980	030422	100002	.WORD	100002
981	030424	100003	.WORD	100003
982	030426	177777	.WORD	177777

T12TBE: .WORD 177777

```

;
;LOCAL TEXT MESSAGES FOR TEST
;

```

987	030430	104	115	101	TST12ID:	.ASCIZ	'DMA Memory Addressing'
988	030456	103	157	156	T12GETSSR:	.ASCIZ	'Contents of TSSR Incorrect After GET STATUS'
989	030532	103	157	156	T12WRTSSR:	.ASCIZ	'Contents of TSSR Incorrect After WRITE CHARACTERISTICS'
990	030621	115	145	163	T12MSGBUF:	.ASCIZ	'Message Buffer Contents Incorrect After WRITE CHARACTERISTICS'
991	030717	102	141	143	T12BKGDND:	.ASCIZ	'Background Pattern Disturbed By WRITE CHARACTERISTICS'
992	031005	105	170	160	T12NINT:	.ASCIZ	'Expected Interrupt Not Received On WRITE CHARACTERISTICS'
993	031076	127	162	151	T12DPR:	.ASCIZ	'Write Characteristic data in ram does not match expected'
994	031167	124	123	123	T12NXM:	.ASCIZ	'TSSR NXM bit failed to set when non-existent memory address specifi

ed'

```

995 .EVEN
996
997
998
999
1000 ;*
1001 ; ROUTINE TO CONVERT A TEST PATTERN TO A VALID ADDRESS IN DIAGNOSTIC FREE SPACE
1002 ; DIAGNOSTIC FREE SPACE IS BETWEEN THE END OF THE DIAGNOSTIC AND THE
1003 ; BEGINNING OF THE SUPERVISOR. THIS IS ALWAYS BELOW 24K.
1004 ; IF MEMORY ABOVE 28K SPECIFIED (VIA R1) THEN PAR 6 IS SET
1005 ; TO THE RELOCATION BASE.
1006
1007 ; INPUTS:
1008 ; R0 HIGH ORDER ADDRESS BITS
1009 ; R1 LOW ORDER ADDRESS BITS
1010
1011 ; OUTPUTS:
1012 ; T12PAR6 = ADDRESS BIASED TO PAR6 IF >28K UNDER TEST
1013 ; T12HIADD = HIGH ORDER ADDRESS IN NON PAR6 FORMAT
1014 ; T12LOADD = LOW ORDER ADDRESS IN NON PAR6 FORMAT
1015 ; C BIT = 1 IF GOOD ADDRESS RETURNED
1016 ; C BIT = 0 IF TEST PATTERN DID NOT YIELD A VALID ADDRESS
1017
1017 031276 T12CONVERT:
1018 031276 SAVREG ;SAVE R1-R5 UNTIL NEXT RETURN
1019 031302 005037 030264 CLR T12LOADD ;CLEAR LOW ADDRESS
1020 031306 005037 030262 CLR T12HIADD ;CLEAR HIGH ADDRESS
1021 031312 005037 030266 CLR T12PAR6 ;CLEAR PAR6 BIASED ADDRESS
1022 031316 042701 170000 BIC #C<7777>,R1 ;FORCE TO LOWER 12 BITS OF ADDRESS
1023 031322 010005 MOV R0,R5 ;SAVE HIGH ORDER ADDRESS BITS
1024 031324 004737 017274 JSR PC,KTOFF ;SHUTOFF MEMORY MANAGEMENT
1025 031330 013702 003124 MOV FREE,R2 ;GET FIRST FREE ADDRESS
1026 031334 062702 000020 ADD #16.,R2 ;IN CASE TEST PATTERN=0
1027 031340 060102 ADD R1,R2 ;ADD IN TEST PATTERN
1028 031342 042702 000003 BIC #3,R2 ;MAKE IT MODULO-4
1029 031346 013703 003130 25+: MOV FREEHI,R3 ;GET LAST FREE ADDRESS
1030 031352 162703 000020 SUB #16.,R3 ;SAVE AT LEAST 8 WORDS (IN CASE MESSAGE BUFFER)
1031 031356 010237 030264 MOV R2,T12LOADD ;SAVE POSSIBLE LOW ADDRESS
1032 031362 010237 030266 MOV R2,T12PAR6 ;SAVE IT IN PAR6 BIASED TOO
1033 031366 020203 CMP R2,R3 ;IS THIS ADDRESS ABOVE FREE SPACE?
1034 031370 101007 BHI 35+ ;BR IF YES
1035 031372 020237 003124 CMP R2,FREE ;IS IT IN FREE SPACE?
1036 031376 103007 BHIS 50+ ;BR IF YES- ITS GOOD
1037 031400 005737 003134 TST KTENABLE ;TESTING ABOVE 28K?
1038 031404 001004 BNE 50+ ;BR IF YES
1039 031406 000424 BR 90+ ;BR IF NOT IN FREE SPACE
1040 031410 162702 000020 35+: SUB #16.,R2 ;FORCE FIT THE TEST PATTERN
1041 031414 000754 BR 25+ ;TRY THIS TEST PATTERN ADDRESS
1042 031416
1043 031416 005737 003134 50+: TST KTENABLE ;TESTING ABOVE 28K?
1044 031422 001420 BEQ 100+ ;BR IF NO
1045 031424 005737 003132 TST KTF LG ;ANY MEMORY ABOVE 28K?
1046 031430 001413 BEQ 90+ ;BR IF NO
1047 031432 004737 017256 JSR PC,KTON ;TURN ON MEMORY MANAGEMENT
1048 031436 010500 MOV R5,R0 ;GET HIGH ORDER ADDRESS
1049 031440 010037 030262 MOV R0,T12HIADD ;SAVE POSSIBLE HIGH ADDRESS
1050 031444 010201 MOV R2,R1 ;GET COMPUTED LOW ORDER ADDRESS
1051 031446 004737 017316 JSR PC,SETMAP ;RETURN PAR6 BIASED ADDRESS IN R0

```

TSV5 - HARDWARE TESTS MACRO M1113 14-JUN-84 15:55  
 TEST 3: SUBTEST 4: NXM TO SELECTED INVALID ADDRESSES

SEQ 0125

```

1052 031452 010037 030266          MOV    R0,T12PAR6      ;COPY PAR6 BIASED ADDRESS
1053 031456 103403          BCS    105$           ;BR IF VALID ADDRESS
1054 031460 000241          90$:  CLC              ;CLR C BIT FOR FAILURE
1055 031462 000401          BR     105$           ;
1056 031464 000261          100$: SEC             ;SET SUCCESS
1057 031466 000207          105$: RTS            PC      ;RETURN
1058
1059
1060
1061
1062
1063
1064
1065
1066
1067
1068
1069
1070
1071
1072
1073
1074
1075
1076
1077
1078
1079
1080
1081
1082
1083
1084
1085
1086 031470
1087 031470
1088 031474 012701 002242          MOV    #RAMDATA,R1    ;SAVE THE GENERAL REGISTERS
1089 031500 012702 000201          MOV    #RMPKTBEG,R2   ;ADDRESS TO SAVE THE RAM DATA
1090 031504 005003          CLR    R3              ;BYTE ADDRESS OF FIRST RAM DATA
1091 031506 004737 016336          JSR    PC,CHKTSSR     ;CLEAR THE ERROR FLAG
1092 031512 112765 000000 000000 10$:  MOVB   #0,TSDB(R5)    ;WAIT FOR SSR
1093 031520 004737 016336          JSR    PC,CHKTSSR     ;SET MAINTENANCE MODE
1094 031524 010265 000000          MOV    R2,TSDB(R5)   ;WAIT FOR SSR TO SET
1095 031530 004737 016336          JSR    PC,CHKTSSR     ;SELECT NEXT RAM ADDRESS
1096 031534 116511 000000          MOVB   TSBA(R5),(R1)  ;WAIT FOR SSR TO SET
1097 031540 122124          CMPB   (R1)+,(R4)+    ;READ THE RAM DATA
1098 031542 001401          BEQ    20$           ;COMPARE TO EXPECTED
1099 031544 005203          INC    R3              ;BRANCH IF OK
1100 031546 005202          INC    R2              ;SET ERROR FLAG
1101 031550 020227 000203 20$:  CMP    R2,#RMPKTBEG+2 ;ADDRESS OF NEXT RAM LOCATION
1102 031554 002761          BLT    10$           ;DONE 2 BYTES?
1103 031556 005703          TST    R3              ;BR IF NO
1104 031560 001402          BEQ    30$           ;WAS AN ERROR FOUND ?
1105 031562 000241          CLC              ;BRANCH IF NOT
1106 031564 000401          BR     50$           ;CLEAR CARRY TO SHOW ERROR
1107 031566 000261          30$:  SEC             ;AND EXIT
1108 031570 012737 000002 002302 50$:  MOV    #2,RAMSIZ     ;SHOW GOOD COMPARE
                                ;SETUP RAMSIZ

```

```

1109 031576 000207          RTS      PC          ;RETURN
1110
1111      ;*
1112      ;
1113      ;ROUTINE TO SETUP PACKET TO WRITE CHARACTERISTICS
1114      ;-
1115
1116 031600      T12SWRT:
1117 031600          SAVREG          ;SAVE THE REGISTERS
1118 031604 012701 030220      MOV      #T12PACKET,R1      ;START OF THE PACKET
1119 031610 012721 100004      MOV      #100004,(R1)+      ;WRITE CHARACTERISTICS WITH ACK
1120 031614 012721 030230      MOV      #T12DATA,(R1)+      ;ADDRESS OF CHAR DATA BLOCK
1121 031620 005021          CLR      (R1)+          ;EXTENDED ADDRESS
1122 031622 012721 000010      MOV      #8,(R1)+          ;SIZE OF DATA BLOCK IN BYTES
1123 031626 012721 030242      MOV      #T12BFR,(R1)+      ;ADDRESS OF MESSAGE BUFFER
1124 031632 005021          CLR      (R1)+          ;
1125 031634 012721 000016      MOV      #14,(R1)+         ;LENGTH OF MESSAGE BUFFER
1126 031640 005021          CLR      (R1)+          ;
1127 031642 005011          CLR      (R1)           ;
1128 031644 000207          RTS      PC          ;RETURN
1129
1130      ;*
1131      ;ROUTINE TO SETUP A GET STATUS COMMAND PACKET AT CURRENT PACKET ADDRESS
1132      ;
1133      ;      R3      HIGH ORDER PACKET ADDRESS
1134      ;      R4      LOW ORDER PACKET ADDRESS
1135      ;      NOTE: R3 IS IGNORED IF KTENABLE FLAG CLEAR
1136      ;
1137      ;
1138
1139 031646      T12SETGET:
1140 031646          SAVREG          ;SAVE THE REGISTERS
1141 031652 010401          MOV      R4,R1          ;GET LOW ORDER ADDRESS
1142 031654 005737 003134      TST      KTENABLE        ;TESTING ABOVE 28K?
1143 031660 001404          BEQ      10$          ;BR IF NO
1144 031662 010300          MOV      R3,R0          ;GET HIGH ORDER ADDRESS
1145 031664 004737 017316      JSR      PC,SETMAP        ;RETURN ADDRESS BIASED TO PAR6 IN R0
1146 031670 010001          MOV      R0,R1          ;GET ADDRESS
1147 031672 012700 000017      10$:  MOV      #P.GETSTATUS,R0  ;GET STATUS COMMAND CODE NO IE
1148 031676 052700 100000      BIS      #P.ACK,R0        ;SET ACK
1149 031702 010021          MOV      R0,(R1)+        ;STORE GET STATUS IN PACKET
1150 031704 005021          CLR      (R1)+          ;CLEAR UNUSED WORD
1151 031706 000207          RTS      PC          ;RETURN
1152
1153
1154      ;*
1155      ;ROUTINE TO SETUP A CHARACTERISTIC DATA BLOCK AT A TEST ADDRESS
1156      ;
1157      ;
1158      ;-
1159 031710      T12CHAR:
1160 031710          SAVREG          ;SAVE R1-R5 UNTIL NEXT RETURN
1161 031714 012700 030230      MOV      #T12DATA,R0      ;GET T12PACKET DATA POINTER
1162 031720 013701 030264      MOV      T12LOAD,R1       ;ASSUME NOT ABOVE 28K
1163 031724 005737 003134      TST      KTENABLE        ;TESTING ABOVE 28K?
1164 031730 001402          BEQ      10$          ;BR IF NO
1165 031732 013701 030266      MOV      T12PAR6,R1       ;SET TEST ADDRESS ABOVE 28K

```



TSVS - HARDWARE TESTS MACRO M1113 14-JUN-84 15:55  
TEST 3: SUBTEST 4: NXM TO SELECTED INVALID ADDRESSES

SEQ 0127

```
1166 031736 012021      10$:  MOV      (R0)+,(R1)+  ;STORE DATA WORD 1
1167 031740 012021      MOV      (R0)+,(R1)+  ;STORE DATA WORD 2
1168 031742 012021      MOV      (R0)+,(R1)+  ;STORE DATA WORD 3
1169 031744 012021      MOV      (R0)+,(R1)+  ;STORE DATA WORD 4
1170 031746 012021      MOV      (R0)+,(R1)+  ;STORE DATA WORD 5
1171 031750 000207      RTS      PC           ;RETURN
1172
1173 031752      ENDTST
      031752
      031752 104401
```

L10042: TRAP C#ETST

```

1175
1176
1177
1178
1179
1180
1181
1182
1183
1184 031754
      031754
1185
1186
1191 031754 005737 002214
1192 031760 001402
1193 031762 005237 003400
1194 031766 012700 034413
1195 031772 004737 016510
1196 031776 012737 000005 002216
1197 032004
1198
1199
1200
1201
1202
1203
1204
1205
1206 032004
      032004
      032004 104402
1207 032006
      032006 012700 000000
      032012 104441
1208 032014 005737 003400
1209 032020 001402
1210 032022 000137 032304
1211 032026 004737 034432
1212 032032 004737 034504
1213 032036 004737 015774
1214 032042 103405
1218 032044 010001
1219 032046
      032046 104455
      032050 000621
      032052 003652
      032054 012034
1220 032056
1221 032056 012704 033330
1222 032062 004737 010662
1223 032066 103405
1227 032070 010001
1228 032072
      032072 104456
      032074 000622
      032076 005056
      032100 012034

      .SBTTL TEST 4: RAM EXERCISER TEST
      ;*
      ; THIS TEST USES THE READ AND WRITE RAM (BOTH SINGLE AND 256
      ; LOCATIONS) SELECT CODES OF THE WRITE SUBSYSTEM MEMORY COMMAND
      ; TO EXERCISE THE CONTROLLER'S RAM MEMORY AND DMA LOGIC
      ;
      ;-
      BGNTST
      T4::
10$: TST TSTCNT ;CHECK FOR RUN MODE
      BEQ 10$ ;BR, IF NOT ONLY PROGRAM RUN
      INC SKIPT ;SET SKIP SW
10$: MOV #TST15ID,RO ;ASCIT MESSAGE TO IDENTIFY TEST
      JSR PC,TSTSETUP ;DO INITIAL TEST SETUP
      MOV #5,LOOPCNT ;PERFORM 5 ITERATIONS
T15LOOP:
      ;
      ; TEST 4, SUBTEST 1
      ;
      ; THIS SUBTEST WRITES THE ADDRESS (8 BITS) INTO THE
      ; RAM MEMORY SINGLE WORD (8 BITS) MODE
      ;-
      BGNSUB ;////////// BEGIN SUBTEST ////////////
      T4.1:
      TRAP C#BSUB
      ;LOWER PRIORITY TO ALLOW INTERRUPTS
      MOV #PRI00,RO
      TRAP C#SPRI
10$: TST SKIPT ;SHOULD WE SKIP THIS SUBTEST
      BEQ 10$ ;BR, IF NOW SKIP REQUIRED
      JMP 50$ ;SKIP SUBTEST
10$: JSR PC,T15REST ;SET COMMAND PACKET
      JSR PC,T15RT2 ;SET UP OTHER COMMAND PACKET
      JSR PC,SOFINIT ;DO INITIALIZE ON CONTROLLER
      BCS 20$ ;BR IF INIT WAS OK
      MOV RO,R1 ;CONTENTS OF TSSR REGISTER
      ERRDF ERRNO,SFIERR,SFIMSG ;FATAL ERROR TSSR WAS NOT OK
      TRAP C#ERDF
      .WORD 401
      .WORD SFIERR
      .WORD SFIMSG
20$: MOV #T15PACKET,R4 ;SUBROUTINE NEEDS PACKET ADDRESS
      JSR PC,WRTCHR ;ISSUE WRITE CHARACTERISTICS
      BCS 23$ ;BR, IF COMMAND ISSUED OK
      MOV RO,R1 ;SAVE CONTENTS OF TSSR
      ERRHRD ERRNO,WRTMSG,SFIMSG ;WRITE CHARACTERISTIC FAILED
      TRAP C#ERHRD
      .WORD 402
      .WORD WRTMSG
      .WORD SFIMSG

```

```

1229 032102 012703 000400      23$:  MOV    #256.,R3          ;STARTING ADDRESS FOR RAM WRITE
1230 032106 112737 000001 034041  MOVB   #1.T15BS1        ;SIZE OF TRANSFER
1231 032114 112737 000002 034040  MOVB   #2.T15BS0        ;WRITE RAM "COMMAND"
1232 032122                                25$:
1233 032122 010337 034042          MOV    R3,T15S2          ;ADDRESS FOR RAM
1234 032126 012704 034030          MOV    #T15PK2,R4        ;WRITE SUBSYS MEM PACKET
1235 032132 110337 034044          MOVB   R3,T15S3          ;DATA FOR WRITE (ADDRESS)
1236 032136 010465 000000          MOV    R4,TSDB(R5)       ;ISSUE COMMAND
1237 032142 004737 016336          JSR    PC,CHKTSSR        ;WAIT FOR SSR
1238 032146 103407                                BCS   30$                ;BR, IF NO ERROR
1239 032150 010001                                MOV    R0,R1              ;ERROR, SAVE TSSR
1243 032152                                ERRHRD ERRNO,T15SSR,PKTSSR ;TSSR NOT CORRECT AFTER WRITE SUB MEM
                                TRAP   C$ERHRD
                                .WORD   403
                                .WORD   T15SSR
                                .WORD   PKTSSR
1244 032162                                ESCAPE SUB                ;DON'T CONTINUE IF ERROR ON WRITE
                                TRAP   C$ESCAPE
                                .WORD   L10050-.
1245 032166      30$:  CKLOOP          ;SCOPE LOOP
                                TRAP   C$CLP1
1246
1247
1248 032170 005203                                INC    R3                  ;NEXT ADDRESS
1249 032172 020327 010000          CMP    R3,#10000         ;END OF RAM MEMORY CHECK
1250 032176 001351                                BNE   25$                ;LOOP TILL ALL RAM WRITTEN
1251 032200 005002                                CLR   R2                  ;CLEAR OUT R2 HIGH BITS
1252 032202 005303                                DEC   R3                  ;SET BACK TO 7777
1253 032204 110337 034044      40$:  MOVB   R3,T15S3          ;GET DATA PATTERN BACK IN SHAPE
1254 032210 010337 034042          MOV    R3,T15S2          ;ADDRESS FOR RAM READ
1255 032214 112737 000001 034040  MOVB   #1.T15BS0        ;READ RAM COMMAND
1256 032222 010465 000000          MOV    R4,TSDB(R5)       ;SEND OUT PACKET ADDRESS TO CONTR.
1257 032226 004737 016336          JSR    PC,CHKTSSR        ;WAIT FOR READY, NON-AMBIGUOUS
1258 032232 103405                                BCS   43$                ;BR, IF NO PROBLEM
1259 032234 010001                                MOV    R0,R1              ;SAVE TSSR
1263 032236                                ERRDF  ERRNO,T15SSR,PKTSSR ;TSSR NOT CORRECT
                                TRAP   C$ERDF
                                .WORD   404
                                .WORD   T15SSR
                                .WORD   PKTSSR
1264 032246      43$:  CKLOOP          ;SCOPE LOOP
                                TRAP   C$CLP1
1265 032250 013701 033372          MOV    T15BFR+20,R1      ;GET RAM READ DATA
1266 032254 010302                                MOV    R3,R2              ;SET UP FOR COMPARE
1267 032256 120102                                CMPB  R1,R2              ;CHECK WITH DATA WRITTEN
1268 032260 001404                                BEQ   45$                ;BR IF OK, DATA IN = DATA OUT
1272 032262                                ERRHRD ERRNO,T15AM4,EXPBREC ;WRITTEN DATA NOT = TO READ
                                TRAP   C$ERHRD
                                .WORD   405
                                .WORD   T15AM4
                                .WORD   EXPBREC
1273 032272      45$:  CKLOOP          ;SCOPE LOOP
                                TRAP   C$CLP1
1274 032274 005303                                DEC   R3                  ;DROP DATA COUNTER (PATTERN)
1275 032276 020327 000377          CMP    R3,#255.         ;AT BOTTOM YET
1276 032302 001340                                BNE   40$                ;BR, IF MORE TO CHECK
1277 032304      50$:  CKLOOP          ;SCOPE LOOP

```



1326										
1327	032450	005203			INC	R3				;NEXT ADDRESS
1328	032452	020327	010000		CHP	R3,#10000				;END OF RAM MEMORY CHECK
1329	032456	001357			BNE	301				;BR, MORE RAM TO GO
1330	032460	005303			DEC	R3				;SET BACK TO 7777
1331	032462	005002			CLR	R2				;SET TO ALL ZEROS
1332	032464	112737	000001	034040	MOVB	#1,T15B50				;READ RAM COMMAND
1333	032472	010337	034042		MOV	R3,T15S2				;ADDRESS TO BE READ TO PACKET DATA
1334	032476	010465	000000		MOV	R4,TSD8(R5)				;SEND OUT PACKET ADDRESS
1335	032502	004737	016336		JSR	PC,CHKTSSR				;WAIT FOR SSR TO SET
1336	032506	103405			BCS	411				;BR, IF ALL IS WELL
1337	032510	010001			MOV	R0,R1				;SAVE TSSR
1341	032512				ERRHRD	ERRNO,T15SSR,PKTSSR				;TSSR NOT CORRECT
	032512	104456							TRAP	C1ERRRD
	032514	000631							.WORD	409
	032516	034046							.WORD	T15SSR
	032520	012046							.WORD	PKTSSR
1342	032522				411:	CKLOOP				;SCOPE LOOP
	032522	104406							TRAP	C1CLP1
1343	032524	013701	033372		MOV	T15BFR+20,R1				;PICK UP READ DATA
1344	032530	120102			CHPB	R1,R2				;BOTH SHOULD BE 00000000 BINARY
1345	032532	001404			BEQ	421				;BR, IF DATA IS GOOD
1349	032534				ERRHRD	ERRNO,T15AM3,EXPBREC				;CHARACTERISTICS DATA NOT CORRECT
	032534	104456							TRAP	C1ERRRD
	032536	000632							.WORD	410
	032540	034223							.WORD	T15AM3
	032542	015502							.WORD	EXPBREC
1350	032544				421:	CKLOOP				;SCOPE LOOPER
	032544	104406							TRAP	C1CLP1
1351	032546	012702	000377		MOV	#000377,R2				;SET ALL ONES WORD
1352	032552	112737	000002	034040	MOVB	#2,T15B50				;WRITE RAM COMMAND
1353	032560	112737	000377	034044	MOVB	#000377,T15S3				;ALL ONES PATTERN
1354	032566	010465	000000		MOV	R4,TSD8(R5)				;PASS PACKET ADDRESS TO CONTR.
1355	032572	004737	016336		JSR	PC,CHKTSSR				;WAIT FOR SSR
1356	032576	103405			BCS	431				;BR, IF OK (NO ERROR)
1357	032600	010001			MOV	R0,R1				;SAVE TSSR
1361	032602				ERRHRD	ERRNO,T15SSR,PKTSSR				;TSSR NOT CORRECT
	032602	104456							TRAP	C1ERRRD
	032604	000633							.WORD	411
	032606	034046							.WORD	T15SSR
	032610	012046							.WORD	PKTSSR
1362	032612				431:	CKLOOP				;SCOPE LOOP
	032612	104406							TRAP	C1CLP1
1363	032614	112737	000001	034040	MOVB	#1,T15B50				;SET UP FOR RAM READ
1364	032622	010465	000000		MOV	R4,TSD8(R5)				;ISSUE RAM READ
1365	032626	004737	016336		JSR	PC,CHKTSSR				;WAIT FOR SSR TO SET
1366	032632	103405			BCS	441				;BR, IF OK (NO ERROR)
1367	032634	010001			MOV	R0,R1				;SAVE TSSR
1371	032636				ERRDF	ERRNO,T15SSR,PKTSSR				;TSSR NOT CORRECT
	032636	104455							TRAP	C1ERDF
	032640	000634							.WORD	412
	032642	034046							.WORD	T15SSR
	032644	012046							.WORD	PKTSSR
1372	032646	013701	033372		441:	MOV	T15BFR+20,R1			;PICK UP REC'D DATA
1373	032652	120102			CHPB	R1,R2				;CHECK WITH DATA WRITTEN
1374	032654	001404			BEQ	451				;BR IF OK, DATA IN = DATA OUT
1378	032656				ERRHRD	ERRNO,T15AM2,EXPBREC				;WRITTEN DATA NOT = TO READ

TSV5 HARDWARE TESTS MACRO M1113 14 JUN-84 15:55  
 TEST 4: RAM EXERCISER TEST

SEQ 0132

```

032656 104456                                TRAP  C1ERHRD
032660 000635                                .WORD 413
032662 034122                                .WORD T15AM2
032664 015502                                .WORD EXPBREC
1379 032666 451: CKLOOP                       ;SCOPE LOOP
032666 104406                                TRAP  C1CLP1
1380 032670 005303                            ;DROP RAM ADDRESS POINTER
1381 032672 020327 000377                    ;AT START YET
1382 032676 001271                            ;BR, IF MORE RAM TO CHECK
1383
1384 032700                                ENDSUB                                ;////////////////////// END SUBTEST ////////////////////////
032700                                L10051:
032700 104403                                TRAP  C1ESUB
1385
1386 032702                                BGNSUB                                ;////////////////////// BEGIN SUBTEST ////////////////////////
032702                                T4.3:
032702 104402                                TRAP  C1BSUB
1387
1388
1389
1390
1391
1392
1393
1394
1395 032704 005737 003400                    ;:
1396 032710 001402                            ;TEST 4, SUBTEST 3
1397 032712 000137 033306                    ;:
1398 032716 004737 034432                    ;:
1399 032722 004737 034504                    ;:
1400 032726 004737 015774                    ;:
1401 032732 103405                            ; THIS SUBTEST WRITES RAM WITH ALL ONES
1405 032734 010001                            ; THEN WALKS AN ALL ZEROS WORD DOWN THROUGH MEMORY
1406 032736                                ;:
032736 104455                                TST  SKIPT                            ;CHECK RUN MODE
032740 000636                                BEQ  101                               ;BR, IF NO SKIP
032742 003652                                JMP  501                              ;SKIP SUBTEST
032744 012034                                101: JSR  PC,T15REST                   ;RESTORE PACKET FOR WRITE CHARA
1407 032746 012704 033330                    ;RESTORE PACKET FOR WRT SUB SYS MEM
1408 032752 004737 010662                    ;DO INITIALIZE ON CONTROLLER
1410 032756 103405                            ;BR IF INIT WAS OK
1414 032760 010001                            ;CONTENTS OF TSSR REGISTER
1415 032762                                ;FATAL ERROR TSSR WAS NOT OK
032762 104456                                TRAP  C1ERDF
032764 000637                                .WORD 414
032766 005056                                .WORD SFIERR
032770 012034                                .WORD SFIMSG
201: 1416 032772 112737 000001 034041          ;SUBROUTINE NEEDS PACKET ADDRESS
1417 032772 112737 000001 034041          ;ISSUE WRITE CHARACTERISTICS
1418 033000 012704 034030                    ;BR, IF COMMAND ISSUED OK
1419 033004 012703 000400                    ;SAVE CONTENTS OF TSSR
1420 033010 112737 000002 034040          ;WRITE CHARACTERISTICSC FAILED
1421 033016 112737 000377 034044          TRAP  C1ERHRD
1422 033024 010377 034042                    .WORD 415
1423 033030 010465 000000                    .WORD WRTMSG
1424 033034 004737 016336                    .WORD SFIMSG
251: 1416 032772 112737 000001 034041          MOV  #1,T15S1                          ;SET SIZE TO 1 BYTE
1417 032772 112737 000001 034041          MOV  #1,T15S1                          ;SET NEW PACKET ADDRESS
1418 033000 012704 034030                    MOV  #256,R3                           ;STARTING ADDRESS IN RAM
1419 033004 012703 000400                    MOV  #2,T15S0                          ;WRITE RAM COMMAND
1420 033010 112737 000002 034040          MOV  #377,T15S3                        ;SET DATA TO 377
1421 033016 112737 000377 034044          MOV  R3,T15S2                          ;ADDRESS TO PACKET DATA AREA
1422 033024 010377 034042                    MOV  R4,T5DB(R5)                       ;SEND OUT PACKET ADDRESS
1423 033030 010465 000000                    JSR  PC,CHKTSSR                        ;WAIT FOR SSR
1424 033034 004737 016336

```

1425	033040	103405			BCS	33:			;BR, IF NO PROBLEM		
1426	033042	010001			MOV				;SAVE TSSR		
1430	033044				ERRHRD				;TSSR NOT CORRECT		
	033044	104456								TRAP	C:ERHRD
	033046	000640								.WORD	416
	033050	034046								.WORD	T15SSR
	033052	012046								.WORD	PKTSSR
1431	033054					33:	CKLOOP		;SCOPE LOOP		
	033054	104406								TRAP	C:CLP1
1432											
1433											
1434	033056	005203			INC		R3		;NEXT ADDRESS		
1435	033060	020327	010000		CMP		R3,#10000		;END OF RAM MEMORY CHECK		
1436	033064	001357			BNE		30:		;BR, MORE RAM TO GO		
1437	033066	005303			DEC		R3		;SET BACK TO 777		
1438	033070	112702	000377		MOVB		#377,R2		;SET TO ALL ONES		
1439	033074	112737	000001	034040	MOVB		#1,T15B50		;READ RAM COMMAND		
1440	033102	010337	034042		MOV		R3,T1552		;ADDRESS TO BE READ TO PACKET DATA		
1441	033106	010465	000000		MOV		R4,TSDB(R5)		;SEND OUT PACKET ADDRESS		
1442	033112	004737	016336		JSR		PC,CHKTSSR		;WAIT FOR SSR TO SET		
1443	033116	103405			BCS		41:		;BR, IF ALL IS WELL		
1444	033120	010001			MOV		R0,R1		;SAVE TSSR		
1448	033122				ERRHRD		ERRNO,T15SSR,PKTSSR		;TSSR NOT CORRECT		
	033122	104456								TRAP	C:ERHRD
	033124	000641								.WORD	417
	033126	034046								.WORD	T15SSR
	033130	012046								.WORD	PKTSSR
1449	033132					41:	CKLOOP		;SCOPE LOOP		
	033132	104406								TRAP	C:CLP1
1450	033134	013701	033372		MOV		T15BFR+20,R1		;PICK UP READ DATA		
1451	033140	120102			CMPB		R1,R2		;BOTH SHOULD BE 11111111 BINARY		
1452	033142	001404			BEQ		42:		;BR, IF DATA IS GOOD		
1456	033144				ERRHRD		ERRNO,T15AM3,EXPBREC		;CHARACTERISTICS DATA NOT CORRECT		
	033144	104456								TRAP	C:ERHRD
	033146	000642								.WORD	418
	033150	034223								.WORD	T15AM3
	033152	015502								.WORD	EXPBREC
1457	033154	012702	000377		MOV		#000377,R2		;SET ALL ONES WORD		
1458	033160	012737	000002	034040	MOVB		#2,T15B50		;WRITE RAM COMMAND		
1459	033166	112737	000377	034044	MOVB		#000377,T1553		;ALL ONES PATTERN		
1460	033174	010465	000000		MOV		R4,TSDB(R5)		;PASS PACKET ADDRESS TO CONTR.		
1461	033200	004737	016336		JSR		PC,CHKTSSR		;WAIT FOR SSR		
1462	033204	103405			BCS		43:		;BR, IF OK (NO ERROR)		
1463	033206	010001			MOV		R0,R1		;SAVE TSSR		
1467	033210				ERRHRD		ERRNO,T15SSR,PKTSSR		;TSSR NOT CORRECT		
	033210	104456								TRAP	C:ERHRD
	033212	000643								.WORD	419
	033214	034046								.WORD	T15SSR
	033216	012046								.WORD	PKTSSR
1468	033220					43:	CKLOOP		;SCOPE LOOP		
	033220	104406								TRAP	C:CLP1
1469	033222	112737	000001	034040	MOVB		#1,T15B50		;SET UP FOR RAM READ		
1470	033230	010465	000000		MOV		R4,TSDB(R5)		;ISSUE RAM READ		
1471	033234	004737	016336		JSR		PC,CHKTSSR		;WAIT FOR SSR TO SET		
1472	033240	103405			BCS		44:		;BR, IF OK (NO ERROR)		
1473	033242	010001			MOV		R0,R1		;SAVE TSSR		
1477	033244				ERRHRD		ERRNO,T15SSR,PKTSSR		;TSSR NOT CORRECT		

TSVS - HARDWARE TESTS MACRO M1113 14-JUN-84 15:55  
 TEST 4: RAM EXERCISER TEST

SEQ 0134

```

033244 104456                                TRAP      C$ERHRD
033246 000644                                .WORD    420
033250 034046                                .WORD    T15SSR
033252 012046                                .WORD    PKTSSR
1478 033254 013701 033372    44:      MOV      T15BFR+20,R1    ;PICK UP REC'D DATA
1479 033260 120102                CMPB    R1,R2          ;CHECK WITH DATA WRITTEN
1480 033262 001404                BEQ     45:            ;BR IF OK, DATA IN = DATA OUT
1484 033264                ERRHRD  ERRNO,T15AM2,EXPBREC ;WRITTEN DATA NOT = TO READ
033264 104456                                TRAP      C$ERHRD
033266 000645                                .WORD    421
033270 034122                                .WORD    T15AM2
033272 015502                                .WORD    EXPBREC
1485 033274                45:      CKLOOP          ;SCOPE LOOP
033274 104406                                TRAP      C$CLP1
1486 033276 005303                DEC     R3             ;DROP RAM ADDRESS POINTER
1487 033300 020327 000377        CMP     R3,#255.      ;AT START YET
1488 033304 001271                BNE    40:            ;BR, IF MORE RAM TO CHECK
1489
1490 033306                50:
1491 033306                ENDSUB              ;////////////////// END SUBTEST ////////////////////
033306                                L10052:
033306 104403                                TRAP      C$ESUB
1492
1493 033310 004737 016456                JSR     PC,TSTLOOP   ;DO WE NEED TO ITERATE TEST ?
1494 033314 103002                BCC    63:            ;BRANCH IF NOT
1495 033316 000137 032004        JMP     T15LOOP      ;EXECUTE AGAIN
1496 033322                63:      EXIT      TST        ;ALL DONE THIS TEST
033322 104432                                TRAP      C$EXIT
033324 001216                                .WORD    L10047-.
1497
1498
1499
1500
1502                033330
1504 033330                T15PACKET:         .=<..*10>&177770
1505 033330 100204                .WORD    100204      ;COMMAND PACKET FOR TEST
1506 033332 033340                .WORD    T15DATA     ;WRITE CHARACTERISTICS COMMAND, WITH IE, ACK
1507 033334 000000                .WORD    0           ;ADDRESS OF CHARACTERISTICS BLOCK
1508 033336 000010                .WORD    8.         ;STARTING VALUE OF BLOCK SIZE
1509 033340                T15DATA:           ;CHARACTERISTICS DATA BLOCK
1510 033340 033352                .WORD    T15BFR      ;ADDRESS OF MESSAGE BUFFER
1511 033342 000000                .WORD    0
1512 033344 000400                .WORD    256.        ;LENGTH OF MESSAGE BUFFER
1513 033346 000000 000000        .WORD    0,0
1514 033352                T15BFR: .BLKW 150.  ;MESSAGE BUFFER
1515
1516                ;WRITE SUBSYSTEM MEMORY COMMAND PACKET
1517
1519                034030
1521 034030                T15PK2:           .=<..*10>&177770
1522 034030 100206                .WORD    100206     ;WRITE SUB SYS MEM COMMAND, IE AND ACK
1523 034032 034040                .WORD    T15BF2     ;ADDRESS OF SELECT BLOCK DATA
1524 034034 000000                .WORD    0
1525 034036 000006                .WORD    6.         ;SIZE OF DATA PACKET
1526
1527                .EVEN
1528 034040                T15BF2:

```



```

1529 034040      000          T15B50: .BYTE 0          ;BSELO AREA
1530 034041      000          T15B51: .BYTE 0          ;BSEL1 AREA
1531 034042    000000          T15S2:  .WORD 0          ;SEL 2 ARFA
1532 034044    000000          T15S3:  .WORD 0          ;DATA AREA
1533
1534
1535
1536
1537
1538              ;*
1539              ;LOCAL TEXT MESSAGES FOR TEST
1540              ;-
1541 034046      127      122      111  T15SSR: .ASCIZ 'WRITE SUBSYSTEM MEMORY Command Not Accepted'
1542 034122      127      122      111  T15AM2: .ASCIZ 'WRITE SUBSYSTEM MEMORY COMMAND Failed On All Ones Word Read Back'
1543 034223      127      122      111  T15AM3: .ASCIZ 'WRITE SUBSYSTEM MEMORY COMMAND Failed On All Zeros Word Read Back'
1544 034325      127      122      111  T15AM4: .ASCIZ 'WRITE SUBSYSTEM MEMORY COMMAND Failed On Address Test'
1545 034413      122      101      115  TST15ID: .ASCIZ 'RAM Exerciser'
1546
1547
1548              ;*
1549              ;ROUTINE TO RESTORE COMMAND PACKET TO START-UP (DEFAULT) VALUES
1550              ;WRITE SUBSYSTEM MEMORY COMMAND
1551              ;
1552              ;-
1553
1554 034432          T15REST:
1555 034432          SAVREG          ;SAVE THE REGISTERS
1556 034436    012701    033330      MOV      #T15PACKET,R1          ;START OF THE PACKET
1557 034442    012721    100204      MOV      #100204,(R1)+          ;WRITE SUBSYSTEM MEM. WITH ACK, IE
1558 034446    012721    033340      MOV      #T15DATA,(R1)+          ;ADDRESS OF CHARAISTICS DATA BLOCK
1559 034452    005021          CLR      (R1)+          ;EXTENDED ADDRESS
1560 034454    012721    000010      MOV      #8,(R1)+          ;SIZE OF DATA BLOCK IN BYTES
1561 034460    012721    033352      MOV      #T15BFR,(R1)+          ;ADDRESS OF MESSAGE BUFFER
1562 034464    005021          CLR      (R1)+
1563 034466    012721    000400      MOV      #256,(R1)+          ;LENGTH OF MESSAGE BUFFER
1564 034472    005021          CLR      (R1)+
1565 034474    005011          CLR      (R1)
1566 034476    005037    033352      CLR      T15BFR          ;CLEAR 1ST LOC IN MESSAGE BUFFER
1567 034502    000207          RTS      PC          ;RETURN
1568
1569
1570 034504          T15RT2:
1571 034504          SAVREG          ;SAVE THE REGISTERS
1572 034510    012701    034030      MOV      #T15PK2,R1          ;START OF THE PACKET
1573 034514    012721    100206      MOV      #100206,(R1)+          ;WRITE SUBSYSTEM MEM. WITH ACK, IE
1574 034520    012721    034040      MOV      #T15BF2,(R1)+          ;ADDRESS OF DATA BLOCK
1575 034524    005021          CLR      (R1)+          ;EXTENDED ADDRESS
1576 034526    012721    000006      MOV      #6,(R1)+          ;SIZE OF DATA BLOCK IN BYTES
1577 034532    005021          CLR      (R1)+
1578 034534    005021          CLR      (R1)+
1579 034536    005011          CLR      (R1)
1580 034540    000207          RTS      PC          ;RETURN
1581 034542          ENDTST
          034542
          034542    104401          L10047: TRAP C$ETST
    
```

```

1583 .SBTTL TEST 5: EXTENDED FEATURES SWITCH AND TIMERS A,B
1584 ;**
1585 ; TEST DESCRIPTION:
1586 ;
1587 ; This test verifies the Invert Extended Features function
1588 ; can logically invert the Extended features switch and
1589 ; that the internal timers A and B operate correctly.
1590 ;
1591 ; TEST STEPS:
1592 ;
1593 ; REPEAT FOR LOOPCNT
1594 ; BEGIN
1595 ; Do Subtest 1 - Verify Extended Features Switch
1596 ; Do Subtest 2 - Verify Timers A,B
1597 ; END
1598 ;
1599 ;
1600 ;
1601 034544 BGNTST
1602 034544
1606 034544 012700 036622 MOV #TST16ID,R0 ;ASCII MESSAGE TO IDENTIFY TEST
1607 034550 004737 016510 JSR PC,TSTSETUP ;DO INITIAL TEST SETUP
1608 034554 012737 000012 002216 MOV #10.,LOOPCNT ;PERFORM 10 ITERATIONS
1609 034562 T16LOOP:
1610 ;
1611 .SBTTL TEST 5: SUBTEST 1: VERIFY EXTENDED FEATURES TEST
1612 ;**
1613 ; TEST 5: SUBTEST 1:
1614 ;
1615 ; SUBTEST DESCRIPTION:
1616 ;
1617 ; This subtest verifies that the Invert Sense of Extended features
1618 ; Switch function (Write Subsystem Memory,Write Misc command)
1619 ; operates properly.
1620 ; First the state of the Extended Features switch is read in the
1621 ; message packet supplied by the write characteristics command.
1622 ; Then, the sense of the switch is logically inverted.
1623 ; A Write characteristics command is executed and it is verified
1624 ; that the Extended status register (XST4) is returned when
1625 ; in Extended mode, and not returned if not in extended mode.
1626 ; The subtest also verifies that specifying a Message Buffer
1627 ; address with any of bits 21-19 ,set will cause the command to
1628 ; be rejected.
1629 ;
1630 ;
1631 ; TEST STEPS:
1632 ;
1633 ;
1634 ; BEGIN
1635 ; Write to TSSR register to soft initialize the controller
1636 ; Do WRITE CHARACTERISTICS to check for Extended Features Switch
1637 ; IF Extended Features Hardware Switch CLEAR
1638 ; THEN
1639 ; (* Verify Extended Features switch can be Inverted to SET *)
1640 ; Do Write Subsystem Write Miscellaneous to SET Extended Features.
1641 ; DO a WRITE CHARACTERISTICS with an extended characteristic word
1642 ; Compare the controller ram to the extended characteristic word

```

```

1643      ;           If Data word in controller ram NOT= to word sent Then Print Error
1644      ;           If Message Buffer Data Length NOT= 12. Then Print Error
1645      ;           ELSE
1646      ;           (* Verify Extended Features switch can be Inverted to CLEAR *)
1647      ;           Do Write Subsystem Write Miscellaneous to CLEAR Extended Features.
1648      ;           Do a WRITE CHARACTERISTICS without an extended characteristic word
1649      ;           If Message Buffer Data Length NOT= 10. Then Print Error
1650      ;           END-IF
1651      ;           (* Verify Function Reject when Message Buffer 21-19 are non-zero *)
1652      ;           Write to TSSR register to soft initialize the controller
1653      ;           REPEAT FOR MESSAGE BUFFER ADDRESS bits <21:19> FROM 0 TO 7
1654      ;           DO a WRITE CHARACTERISTICS with a message address bit<21:19> non-zero
1655      ;           If TSSR termination code NOT= Function Reject Then Print Error
1656      ;           END-REPEAT
1657      ;           END
1658      ;           --
1659      034562      BGNSUB                               ;////////// BEGIN SUBTEST //////////
1660      034562      ;                                     T5.1:
1661      034562      104402                               TRAP      C#BSUB

1662      034564      5#:
1663      ;           Write to TSSR register to soft initialize the controller
1664      034564      004737 015774      JSR      PC,SOFINIT      ;WRITE TO TSSR TO SOFT INITIALIZE
1665      034570      103405      BCS      10#             ;BR IF SOFT INIT OKAY
1666      034572      010001      MOV      R0,R1          ;SAVE CONTENTS OF TSSR
1667      034574      ;           ERRDF  ERRNO,SFIERR,SFIMSG      ;DEVICE FATAL DURING INIT
1668      034574      104455      ;                                     TRAP      C#ERDF
1669      034576      000764      ;                                     .WORD    500
1670      034600      003652      ;                                     .WORD    SFIERR
1671      034602      012034      ;                                     .WORD    SFIMSG

1668      ;           Do WRITE CHARACTERISTICS to check for Extended Features Switch
1669      034604      004737 037770      10#:     JSR      PC,T16REST      ;RESTORE PACKET DEFAULTS
1670      034610      005037 002222      CLR      FATFLG         ;CLEAR FATAL ERROR FLAG
1671      034614      012704 040150      MOV      @T16PACKET,R4  ;GET THE ADDRESS OF COMMAND PACKET
1672      034620      004737 010662      JSR      PC,WRTCHR      ;DO WRITE CHARACTERISTICS COMMAND
1673      034624      ;           FORCERROR 12#             ;GOODFORCE ERROR IF FORCER=1
1674      034640      103407      BCS      15#             ;BR IF CARRY SET (GOOD RETURN)
1675      034642      010001      MOV      R0,R1          ;SAVE CONTENTS OF TSSR
1676      034644      ;           NEXT.ERRNO
1677      034644      12#:     ERRDF  ERRNO,T16SSR,PKTSSR      ;DEVICE FATAL SSR FAILED TO SET
1678      034644      104455      ;                                     TRAP      C#ERDF
1679      034646      000765      ;                                     .WORD    501
1680      034650      036672      ;                                     .WORD    T16SSR
1681      034652      012046      ;                                     .WORD    PKTSSR

1678      034654      005237 002222      15#:     INC      FATFLG         ;SET FATAL ERROR FLAG
1679      034660      034660      104406      15#:     CKLOOP          ;LOOP ON ERROR, IF FLAG SET
1680      ;           ;                                     TRAP      C#CLP1

1680      ;           If Extended Features Hardware Switch Clear then:
1681      ;           (* Verify Extended Features switch can be Inverted to SET *)
1682      ;           REPEAT FOR TEST PATTERNS IN TSTBLK TABLE
1683      ;           MOV      @T16BFR,R1      ;MESSAGE BUFFER ADDRESS
1684      034662      012701 040172      MOV      @T16BFR,R1      ;MESSAGE BUFFER ADDRESS
1685      034666      032761 000200 000012      BIT      @X2.EXTF,XST2(R1) ;EXTENDED FEATURES SWITCH CLEAR?
1686      034674      001402      BEQ      20#             ;BR IF YES
1687      034676      000137 035246      JMP      200#           ;
1688      034702      012703 002764      20#:     MOV      @TSTBLK+10.,R3 ;START OF TEST DATA
    
```

```

1689 ; Do Write Subsystem Write Miscellaneous to SET Extended Features.
1690
1691 034706 004737 040130 JSR PC,T16SEXT ;SETUP PACKET FOR WRITE MISC INVERT
1692 034712 012704 040220 MOV #T16PK2,R4 ;GET WRITE SUBSYSTEM COMMAND PACKET
1693 034716 010465 000000 MOV R4,TSDB(R5) ;SET THE PACKET ADDRESS TO EXECUTE
1694 034722 004737 016336 JSR PC,CHKTSSR ;WAIT FOR SSR TO SET
1695 034726 FORCERROR 32$ ;BDFORCE ERROR IF FORCER=1
1696 034742 103407 BCS 40$ ;BR IF CARRY SET (GOOD RETURN)
1697 034744 010001 MOV R0,R1 ;SAVE CONTENTS OF TSSR
1698 034746 NEXT.ERRNO
1699 034746 32$: ERRDF ERRNO,T162SSR,PKTSSR ;DEVICE FATAL SSR FAILED TO SET
    TRAP C#ERDF
    .WORD 502
    .WORD T162SSR
    .WORD PKTSSR
    034746 104455
    034750 000766
    034752 036727
    034754 012046
1700 034756 005237 002222 INC FATFLG ;SET FATAL ERROR FLAG
1701 034762 40$: CKLOOP ;LOOP ON ERROR, IF FLAG SET
    TRAP C#CLP1
    034762 104406
1702
1703 ; DO a WRITE CHARACTERISTICS with an extended characteristic word
1704 034764 012737 125252 002312 MOV #125252,DATA ;SETUP TEST DATA FOR EXTENDED WORD
1705 034772 012704 040150 MOV #T16PACKET,R4 ;GET THE ADDRESS OF COMMAND PACKET
1706 034776 012764 000020 000006 MOV #16.,PKBCNT(R4) ;STORE MESSAGE PACKET SIZE
1707 035004 013737 002312 040170 MOV DATA,T16DATA+10 ;STORE TEST DATA IN EXTENDED WORD
1708 035012 004737 010662 JSR PC,WRTCHR ;DO WRITE CHARACTERISTICS COMMAND
1709 035016 FORCERROR 42$ ;BDFORCE ERROR IF FORCER=1
1710 035032 103407 BCS 50$ ;BR IF CARRY SET (GOOD RETURN)
1711 035034 010001 MOV R0,R1 ;SAVE CONTENTS OF TSSR
1712 035036 NEXT.ERRNO
1713 035036 42$: ERRDF ERRNO,T16SSR,PKTSSR ;DEVICE FATAL SSR FAILED TO SET
    TRAP C#ERDF
    .WORD 503
    .WORD T16SSR
    .WORD PKTSSR
    035036 104455
    035040 000767
    035042 036672
    035044 012046
1714 035046 005237 002222 INC FATFLG ;SET FATAL ERROR FLAG
1715 035052 50$: CKLOOP ;LOOP ON ERROR, IF FLAG SET
    TRAP C#CLP1
    035052 104406
1716 ; If the TSBA Address Register NOT= Expected Then Print Error
1717 035054 016501 000000 MOV TSBA(R5),R1 ;GET TSBA REGISTER CONTENTS
1718 035060 012702 040172 MOV #T16BFR,R2 ;START OF THE DATA BUFFER
1719 035064 062702 000020 62$: ADD #16.,R2 ;EXPECTED CONTENTS OF TSBA
1720 035070 FORCERROR 72$,NOTSSR ;BDFORCE ERROR IF FORCER=1
1721 035100 020102 CMP R1,R2 ;COMPARE EXPECTED TO RECEIVED
1722 035102 001404 BEQ 80$ ;ERROR IF NOT EQUAL
1723 035104 NEXT.ERRNO
1724 035104 72$: ERRHRD ERRNO,T16TSBA,EXPREC ;PRINT THE ERROR & EXPD/RECV
    TRAP C#ERHRD
    .WORD 504
    .WORD T16TSBA
    .WORD EXPREC
    035104 104456
    035106 000770
    035110 037040
    035112 015474
1725 035114 80$: CKLOOP ;LOOP ON ERROR, IF FLAG SET
    TRAP C#CLP1
    035114 104406
1726 ; Compare the controller ram to the extended characteristic word
1727 ; If Data word in controller ram NOT= to word sent Then Print Error
1728 035116 012704 040160 MOV #T16DATA,R4 ;GET CHARACTERISTIC DATA ADDRESS
1729 035122 004737 011224 JSR PC,CKRAM2 ;DOES RAM DATA EQUAL DATA SENT?
1730 035126 FORCERROR 92$ ;BDFORCE ERROR IF FORCER=1
    
```

```

1731 035142 103404          BCS      100$          ;BR IF YES
1732 035144                NEXT.ERRNO
1733 035144          92$:  ERRHRD  ERRNO,PKTRAM,RAMERR          ;REPORT THE RAM ERROR(S)
                                TRAP      C$ERHRD
                                .WORD     505
                                .WORD     PKTRAM
                                .WORD     RAMERR
                                TRAP      C$CLP1
                                035144 104456
                                035146 000771
                                035150 004745
                                035152 015510
1734 035154          100$:  CKLOOP          ;LOOP ON ERROR, IF FLAG SET
                                TRAP      C$CLP1
                                035154 104406
;      If Message Buffer Data Length NOT= 12. Then Print Error
1736 035156 012702 040172      MOV      #T16BFR,R2          ;GET MESSAGE BUFFER ADDRESS
1737 035162 016201 000002      MOV      2(R2),R1          ;GET RECV DATA FIELD LENGTH
1738 035166 012702 000014      MOV      #12.,R2          ;GET EXPD DATA FIELD LENGTH
1739 035172                FORCERROR 112$,NOTSSR          ;GOODFORCE ERROR IF FORCER=1
1740 035202 020102          CMP      R1,R2          ;COMPARE EXPECTED TO RECEIVED
1741 035204 001404          BEQ     120$          ;ERROR IF NOT EQUAL
1742 035206                NEXT.ERRNO
1743 035206          112$:  ERRHRD  ERRNO,T16LEN,EXPREC          ;PRINT THE ERROR & EXPD/RECV
                                TRAP      C$ERHRD
                                .WORD     506
                                .WORD     T16LEN
                                .WORD     EXPREC
                                TRAP      C$CLP1
                                035206 104456
                                035210 000772
                                035212 037142
                                035214 015474
1744 035216          120$:  CKLOOP          ;LOOP ON ERROR, IF FLAG SET
                                TRAP      C$CLP1
                                035216 104406
1745
1746 035220 004737 015774          JSR     PC,SOFINIT          ;WRITE TO TSSR TO SOFT INITIALIZE
1747 035224 103405          BCS     125$          ;BR IF SOFT INIT OKAY
1748 035226 010001          MOV     R0,R1          ;SAVE CONTENTS OF TSSR
1749 035230          ERRDF  ERRNO,SFIERR,SFIMSG          ;DEVICE FATAL DURING INIT
                                TRAP      C$ERDF
                                .WORD     506
                                .WORD     SFIERR
                                .WORD     SFIMSG
                                035230 104455
                                035232 000772
                                035234 003652
                                035236 012034
1750 035240          125$:  CKLOOP          ;LOOP IF SELECTED
                                TRAP      C$CLP1
                                035240 104406
1751 035242 000137 035426          JMP     300$          ;
1752
1753          ;      (* Verify Extended Features switch can be Inverted to CLEAR *)
1754 035246          200$:  ;
                                Do Write Subsystem Write Miscellaneous to CLEAR Extended Features.
1756 035246 004737 040130          JSR     PC,T16SEXT          ;SETUP PACKET FOR WRITE MISC INVERT
1757 035252 012704 040220          MOV     #T16PK2,R4          ;GET WRITE SUBSYSTEM COMMAND PACKET
1758 035256 010465 000000          MOV     R4,TSDB(R5)          ;SET THE PACKET ADDRESS TO EXECUTE
1759 035262 004737 016336          JSR     PC,CHKTSSR          ;WAIT FOR SSR TO SET
1760 035266          FORCERROR 232$          ;GOODFORCE ERROR IF FORCER=1
1761 035302 103407          BCS     240$          ;BR IF CARRY SET (GOOD RETURN)
1762 035304 010001          MOV     R0,R1          ;SAVE CONTENTS OF TSSR
1763 035306          NEXT.ERRNO
1764 035306          232$:  ERRDF  ERRNO,T162SSR,PKTSSR          ;DEVICE FATAL SSR FAILED TO SET
                                TRAP      C$ERDF
                                .WORD     507
                                .WORD     T162SSR
                                .WORD     PKTSSR
                                035306 104455
                                035310 000773
                                035312 036727
                                035314 012046
1765 035316 005237 002222          INC     FATFLG          ;SET FATAL ERROR FLAG
1766 035322          240$:  CKLOOP          ;LOOP ON ERROR, IF FLAG SET
                                TRAP      C$CLP1
                                035322 104406
1767

```

```

1768      ; DO a WRITE CHARACTERISTICS without an extended characteristic word
1769 035324 012704 040150      MOV #T16PACKET,R4      ;GET THE ADDRESS OF COMMAND PACKET
1770 035330 012764 000016 000006      MOV #14.,PKBCNT(R4)    ;STORE MESSAGE PACKET SIZE
1771 035336 004737 010662      JSR PC,WRTCHR          ;DO WRITE CHARACTERISTICS COMMAND
1772 035342      FORCERROR 242$      ;BDFORCE ERROR IF FORCER=1
1773 035356 103407      BCS 250$              ;BR IF CARRY SET (GOOD RETURN)
1774 035360 010001      MOV RO,R1              ;SAVE CONTENTS OF TSSR
1775 035362      NEXT.ERRNO
1776 035362 242$: ERRDF ERRNO,T16SSR,PKTSSR      ;DEVICE FATAL SSR FAILED TO SET
      TRAP C$ERDF
      .WORD 508
      .WORD T16SSR
      .WORD PKTSSR
1777 035372 005237 002222      INC FATFLG            ;SET FATAL ERROR FLAG
1778 035376 250$: CKLOOP      ;LOOP ON ERROR, IF FLAG SET
      TRAP C$CLP1
1779      ; If Message Buffer Data Length NOT= 10. Then Print Error
1780 035400 013701 040174      MOV T16FR+2,R1        ;GET RECV DATA FIELD LENGTH
1781 035404 012702 000012      MOV #10.,R2          ;GET EXPD DATA FIELD LENGTH
1782 035410 020102      CMP R1,R2            ;COMPARE EXPECTED TO RECEIVED
1783 035412 001404      BEQ 270$            ;ERROR IF NOT EQUAL
1784 035414      NEXT.ERRNO
1785 035414 262$: ERRHRD ERRNO,T16LEN,EXPREC      ;PRINT THE ERROR & EXPD/RECV
      TRAP C$ERRRD
      .WORD 509
      .WORD T16LEN
      .WORD EXPREC
1786 035424 270$: CKLOOP      ;LOOP ON ERROR, IF FLAG SET
      TRAP C$CLP1
1787
1788
1789      ; (* Verify Function Reject when Message Buffer 21-19 are non-zero *)
1790      ; Write to TSSR register to soft initialize the controller
1791 035426 300$:
1792      ; REPEAT FOR MESSAGE BUFFER ADDRESS bits <21:19> FROM 0 TO 7
1793 035426 012737 000001 002312 320$: MOV #1,DATA          ;START AT BITS<21:19>=001
1794      ; DO a WRITE CHARACTERISTICS with a message address bit<21:19> non-zero
1795 035434 325$:
1796 035434 012704 040150      MOV #T16PACKET,R4      ;GET THE ADDRESS OF COMMAND PACKET
1797 035440 012764 000016 000006      MOV #14.,PKBCNT(R4)    ;STORE MESSAGE PACKET SIZE
1798 035446 013700 002312      MOV DATA,RO          ;GET TEST DATA
1799      .REPT 3
1800      ASL RO              ;SHIFT INTO BITS 21:19
1801      .ENDR
1802 035460 010037 040162      MOV RO,T16DATA+2      ;STORE BUFFER ADDRESS BITS 21:19
1803 035464 010465 000000      MOV R4,TSDB(R5)       ;SET THE PACKET ADDRESS TO EXECUTE
1804 035470 004737 016250      JSR PC,WAITF          ;WAIT FOR SSR
1805 035474      FORCERROR 342$      ;BDFORCE ERROR IF FORCER=1
1806 035510 103407      BCS 350$              ;BR IF CARRY SET (GOOD RETURN)
1807 035512 010001      MOV RO,R1              ;SAVE CONTENTS OF TSSR
1808 035514      NEXT.ERRNO
1809 035514 342$: ERRDF ERRNO,T16SSR,PKTSSR      ;DEVICE FATAL SSR FAILED TO SET
      TRAP C$ERDF
      .WORD 510
      .WORD T16SSR
      .WORD PKTSSR
1810 035524 005237 002222      INC FATFLG            ;SET FATAL ERROR FLAG
  
```

```

1811 035530      350$: CKLOOP                      ;LOOP ON ERROR, IF FLAG SET
      035530 104406                                TRAP      C#CLP1
1812
1813           ; If TSSR termination code NOT= Function Reject Then Print Error
1814 035532 016501 000002      MOV      TSSR(R5),R1      ;GET RECV TSSR
1815 035536 010102      MOV      R1,R2          ;COPY RECV TSSR
1816 035540 042702 000016      BIC      @TERCLS,R2      ;CLEAR TC<2:0> EXPD
1817 035544 052702 000006      BIS      @TSREJ,R2      ;SET EXPD TC<2:0>= FUNCTION REJECT
1818 035550      FORCERROR 352$,NOTSSR          ;BDFORCE ERROR IF FORCER=1
1819 035560 020102      CMP      R1,R2          ;EXPD EQUAL RECV?
1820 035562 001404      BEQ     360$          ;BR IF YES
1821 035564      NEXT.ERRNO
1822 035564      352$: ERRHRD ERRNO,T16REJ,PKTSSR ;DEVICE FATAL SSR FAILED TO SET
      035564 104456                                TRAP      C#ERHRD
      035566 000777                                .WORD    511
      035570 037254                                .WORD    T16REJ
      035572 012046                                .WORD    PKTSSR
1823 035574      360$: CKLOOP                      ;LOOP ON ERROR, IF FLAG SET
      035574 104406                                TRAP      C#CLP1
1824 035576      FORCEXIT 370$
1825 035606 005237 002312      INC      DATA          ;GET NEXT TST PATTERN
1826 035612 023727 002312 000007      CMP     DATA,#7      ;DONE ALL DATA?
1827 035620 101002      BHI     370$          ;BR IF YES
1828 035622 000137 035434      JMP     325$          ;DO ANOTHER TEST PATTERN
1829           ;
1830 035626      370$:
1831 035626      ENDSUB                                ;////////// END SUBTEST ////////////
      035626                                L10054:
      035626 104403                                TRAP      C#ESUB
1832
1833 035630 005737 002222      TST     FATFLG          ;ANY FATAL ERRORS ?
1834 035634 001402      BEQ     460$          ;BRANCH IF NOT
1835 035636 004737 017202      JSR     PC,CKDROP      ;TRY TO DROP THE UNIT
1836 035642      460$:
1837
1838
1839
1840
1841
1842           .SBTTL TEST 5: SUBTEST 2: VERIFY TIMERS A,B
1843
1844           ;**
1845           ; TEST 5: SUBTEST 2:
1846           ;
1847           ; SUBTEST DESCRIPTION:
1848           ;
1849           ; This subtest verifies that timers A,B can be reset
1850           ; and that Timer A is twice the frequency of Timer B.
1851           ; Timer A has a period of 25 microseconds and Timer B
1852           ; has a period of 50 microseconds. The timers are
1853           ; checked at 1, 28, 53, and 78 microseconds.
1854           ;
1855           ; TEST STEPS:
1856           ;
1857           ;
1858           ; Write to TSSR register to soft initialize the controller
1859           ; Do WRITE CHARACTERISTICS to setup a Message Buffer
  
```

```

1860      ;      (* Verify Timers A,B after RESET TIMER with 0 microsecond delay *)
1861      ;      Do a Write Control RESET TIMER with 1 microsecond delay
1862      ;      Do a Write Subsystem READ STATUS
1863      ;      If Timer A NOT= 0 Then Print Error
1864      ;      If Timer B NOT= 0 Then Print Error
1865      ;      (* Verify Timers A,B after RESET TIMER with 28 microsecond delay *)
1866      ;      Do a Write Control RESET TIMER with 28 microsecond delay
1867      ;      If Timer A NOT= 1 Then Print Error
1868      ;      If Timer B NOT= 1 Then Print Error
1869      ;      Do a Write Control RESET TIMER with 53 microsecond delay
1870      ;      If Timer A NOT= 0 Then Print Error
1871      ;      If Timer B NOT= 1 Then Print Error
1872      ;      Do a Write Control RESET TIMER with 78 microsecond delay
1873      ;      If Timer A NOT= 1 Then Print Error
1874      ;      If Timer B NOT= 0 Then Print Error
1875      ;--
1876 035642      BGNSUB      ;//////////////// BEGIN SUBTEST //////////////////
      035642      T5.2:
      035642 104402      TRAP      C#BSUB
1877      ;      Write to TSSR register to soft initialize the controller
1878 035644      5$:
1879 035644 004737 015774      JSR      PC,SOFINIT      ;WRITE TO TSSR TO SOFT INITIALIZE
1880 035650 103405      BCS      10$      ;BR IF SOFT INIT OKAY
1881 035652 010001      MOV      R0,R1      ;SAVE CONTENTS OF TSSR
1882 035654      ERRDF      ERRNO,SFIERR,SFIMSG      ;DEVICE FATAL DURING INIT
      035654 104455      TRAP      C#ERDF
      035656 000777      .WORD      511
      035660 003652      .WORD      SFIERR
      035662 012034      .WORD      SFIMSG
1883      ;      Do WRITE CHARACTERISTICS to setup a Message Buffer
1884 035664 004737 037770      10$:      JSR      PC,T16REST      ;RESTORE PACKET DEFAULTS
1885 035670 005037 002222      CLR      FATFLG      ;CLEAR FATAL ERROR FLAG
1886 035674 012704 040150      MOV      #T16PACKET,R4      ;GET THE ADDRESS OF COMMAND PACKET
1887 035700 012764 000010 000006      MOV      #8.,PKBCNT(R4)      ;MESSAGE PACKET SIZE NO EXTEND
1888 035706 004737 010662      JSR      PC,WRTCHR      ;DO WRITE CHARACTERISTICS COMMAND
1889 035712      FORCERROR      12$      ;BDFORCE ERROR IF FORCER=1
1890 035726 103407      BCS      15$      ;BR IF CARRY SET (GOOD RETURN)
1891 035730 010001      MOV      R0,R1      ;SAVE CONTENTS OF TSSR
1892 035732      NEXT.ERRNO
1893 035732      12$:      ERRDF      ERRNO,T16SSR,PKTSSR      ;DEVICE FATAL SSR FAILED TO SET
      035732 104455      TRAP      C#ERDF
      035734 001000      .WORD      512
      035736 036672      .WORD      T16SSR
      035740 012046      .WORD      PKTSSR
1894 035742 005237 002222      INC      FATFLG      ;SET FATAL ERROR FLAG
1895 035746      15$:      CKLOOP      ;LOOP ON ERROR, IF FLAG SET
      035746 104406      TRAP      C#CLP1
1896      ;
1897      ;      (* Verify Timers A,B after RESET TIMER with 1 microsecond delay *)
1898      ;      Do a Write Control RESET TIMER with 1 microsecond delay
1899 035750 012700 000001      MOV      #MS.RSD,R0      ;RESET TIMER COMMAND
1900 035754 013701 036612      MOV      T16D01,R1      ;1 MICROSECOND DELAY
1901 035760 004737 040102      JSR      PC,T16WMISC      ;SETUP T16PK2 COMMAND PACKET
1902 035764 012704 040220      MOV      #T16PK2,R4      ;GET WRITE SUBSYSTEM COMMAND PACKET
1903 035770 010465 000000      MOV      R4,TSDB(R5)      ;SET THE PACKET ADDRESS TO EXECUTE
1904 035774 004737 016336      JSR      PC,CHKTSSR      ;WAIT FOR SSR TO SET
1905 036000      FORCERROR      32$      ;BDFORCE ERROR IF FORCER=1

```



```

1906 036014 103407          BCS      40$          ;BR IF CARRY SET (GOOD RETURN)
1907 036016 010001          MOV      RO,R1         ;SAVE CONTENTS OF TSSR
1908 036020                NEXT.ERRNO
1909 036020 32$:          ERRDF  ERRNO,T162SSR,PKTSSR ;DEVICE FATAL SSR FAILED TO SET
                                TRAP      C$ERDF
                                .WORD     513
                                .WORD     T162SSR
                                .WORD     PKTSSR
                                036020 104455
                                036022 001001
                                036024 036727
                                036026 012046
1910 036030 005237 002222          INC      FATFLG        ;SET FATAL ERROR FLAG
1911 036034 104406          40$:          CKLOOP          ;LOOP ON ERROR, IF FLAG SET
                                TRAP      C$CLP1
1912                ;          If Timer A NOT= 0 Then Print Error
1913                ;          If Timer B NOT= 0 Then Print Error
1914 036036 005002          CLR      R2            ;INIT EXPD
1915 036040 042702 000010          BIC     #S2.ATIM,R2    ;TIMER A EXPD=0
1916 036044 042702 000004          BIC     #S2.BTIM,R2    ;TIMER B EXPD=0
1917 036050 012700 040212          MOV     #T16BFSTA,R0   ;GET RECV READ STATUS
1918 036054 016001 000002          MOV     2(RO),R1      ;GET RECV BYTE 2
1919 036060 042701 177763          BIC     #C<S2.ATIM!S2.BTIM>,R1 ;SAVE TIMER A:B RECV ONLY
1920 036064          FORCERROR 72$,NOTSSR ;000
1921 036074 020201          CMP     R2,R1         ;EXPD EQUAL RECV?
1922 036076 001404          BEQ    80$           ;BR IF YES
1923 036100                NEXT.ERRNO
1924 036100 72$:          ERRHRD  ERRNO,T16T01,TIMEXP ;REPORT ERROR
                                TRAP      C$ERHRD
                                .WORD     514
                                .WORD     T16T01
                                .WORD     TIMEXP
                                036100 104456
                                036102 001002
                                036104 037371
                                036106 015552
1925 036110 80$:          CKLOOP          ;LOOP ON ERROR, IF FLAG SET
                                TRAP      C$CLP1
1926                ;
1927                ;          Do a Write Control RESFT TIMER with 28 microsecond delay
1928 036112 012700 000001          MOV     #MS.RSD,R0     ;RESET TIMER COMMAND
1929 036116 013701 036614          MOV     T16D28,R1     ;28 MICROSECOND DELAY
1930 036122 004737 040102          JSR    PC,T16MMISC    ;SETUP T16PK2 COMMAND PACKET
1931 036126 012704 040220          MOV     #T16PK2,R4    ;GET WRITE SUBSYSTEM COMMAND PACKET
1932 036132 010465 000000          MOV     R4,TSDB(R5)   ;SET THE PACKET ADDRESS TO EXECUTE
1933 036136 004737 016336          JSR    PC,CHKTSSR     ;WAIT FOR SSR TO SET
1934 036142          FORCERROR 112$ ;000FORCE ERKOR IF FORCER=1
1935 036156 103407          BCS     120$          ;BR IF CARRY SET (GOOD RETURN)
1936 036160 010001          MOV     RO,R1         ;SAVE CONTENTS OF TSSR
1937 036162                NEXT.ERRNO
1938 036162 112$:          ERRDF  ERRNO,T162SSR,PKTSSR ;DEVICE FATAL SSR FAILED TO SET
                                TRAP      C$ERDF
                                .WORD     515
                                .WORD     T162SSR
                                .WORD     PKTSSR
                                036162 104455
                                036164 001003
                                036166 036727
                                036170 012046
1939 036172 005237 002222          INC      FATFLG        ;SET FATAL ERROR FLAG
1940 036176 104406          120$:         CKLOOP          ;LOOP ON ERROR, IF FLAG SET
                                TRAP      C$CLP1
1941                ;          If Timer A NOT= 1 Then Print Error
1942                ;          If Timer B NOT= 1 Then Print Error
1943 036200 005002          CLR      R2            ;INIT EXPD
1944 036202 052702 000010          BIS     #S2.ATIM,R2    ;TIMER A EXPD=1
1945 036206 052702 000004          BIS     #S2.BTIM,R2    ;TIMER B EXPD=1
1946 036212 012700 040212          MOV     #T16BFSTA,R0   ;GET RECV READ STATUS
1947 036216 016001 000002          MOV     2(RO),R1      ;GET RECV BYTE 2

```

```

1948 036222 042701 177763      BIC    @*C<S2.ATIM!S2.BTIM>,R1 ;SAVE TIMER A:B RECV ONLY
1949 036226                    FORCERROR 1724,NOTSSR ;BDD
1950 036236 020201            CMP    R2,R1 ;EXPD EQUAL RECV?
1951 036240 0C1404            BEQ    1804 ;BR IF YES
1952 036242                    NEXT.ERRNO
1953 036242 1724:           ERRNO  ERRNO.T16T28.TIMEXP ;REPORT ERROR
                                TRAP    CIERHRO
                                .WORD   516
                                .WORD   T16T28
                                .WORD   TIMEXP
                                TRAP    C1CLP1
                                036242 104456
                                036244 001004
                                036246 037470
                                036250 015552
1954 036252 1804:           CKLOOP ;LOOP ON ERROR, IF FLAG SET
                                TRAP    C1CLP1
                                036252 104406
1955
1956 ; Do a Write Control RESET TIMER with 53 microsecond delay
1957 036254 012700 000001      MOV    @MS.RSD,R0 ;RESET TIMER COMMAND
1958 036260 013701 036616      MOV    T16D53,R1 ;53 MICROSECOND DELAY
1959 036264 004737 040102      JSR    PC,T16MMISC ;SETUP T16PK2 COMMAND PACKET
1960 036270 012704 040220      MOV    @T16PK2,R4 ;GET WRITE SUBSYSTEM COMMAND PACKET
1961 036274 010465 000000      MOV    R4,TSDB(R5) ;SET THE PACKET ADDRESS TO EXECUTE
1962 036300 004737 016336      JSR    PC,CHKTSSR ;WAIT FOR SSR TO SET
1963 036304                    FORCERROR 2124 ;BDDFORCE ERROR IF FORCER=1
1964 036320 103407            BCS    2204 ;BR IF CARRY SET (GOOD RETURN)
1965 036322 0:0001            MOV    R0,R1 ;SAVE CONTENTS OF TSSR
1966 036324                    NEXT.ERRNO
1967 036324 2124:           ERRDF  ERRNO.T162SSR.PKTSSR ;DEVICE FATAL SSR FAILED TO SET
                                TRAP    CIERDF
                                .WORD   517
                                .WORD   T162SSR
                                .WORD   PKTSSR
                                036324 104455
                                036326 001005
                                036330 036727
                                036332 012046
1968 036334 005237 002222      INC    FATFLG ;SET FATAL ERROR FLAG
1969 036340 2204:           CKLOOP ;LOOP ON ERROR, IF FLAG SET
                                TRAP    C1CLP1
                                036340 104406
1970 ; If Timer A NOT= 0 Then Print Error
1971 ; If Timer B NOT= 1 Then Print Error
1972 036342 005002            CLR    R2 ;INIT EXPD
1973 036344 042702 000010      BIC    @S2.ATIM,R2 ;TIMER A EXPD=0
1974 036350 052702 000004      BIS    @S2.BTIM,R2 ;TIMER B EXPD=1
1975 036354 012700 040212      MOV    @T16BFSTA,R0 ;GET RECV READ STATUS
1976 036360 016001 000002      MOV    2(R0),R1 ;GET RECV BYTE 2
1977 036364 042701 177763      BIC    @*C<S2.ATIM!S2.BTIM>,R1 ;SAVE TIMER A:B RECV ONLY
1978 036370                    FORCERROR 2724,NOTSSR ;BDD
1979 036400 020201            CMP    R2,R1 ;EXPD EQUAL RECV?
1980 036402 001404            BEQ    2804 ;BR IF YES
1981 036404                    NEXT.ERRNO
1982 036404 2724:           ERRNO  ERRNO.T16T53.TIMEXP ;REPORT ERROR
                                TRAP    CIERHRO
                                .WORD   518
                                .WORD   T16T53
                                .WORD   TIMEXP
                                TRAP    C1CLP1
                                036404 104456
                                036406 001006
                                036410 037570
                                036412 015552
1983 036414 2804:           CKLOOP ;LOOP ON ERROR, IF FLAG SET
                                TRAP    C1CLP1
                                036414 104406
1984 ; Do a Write Control RESET TIMER with 78 microsecond delay
1985 036416 012700 000001      MOV    @MS.RSD,R0 ;RESET TIMER COMMAND
1986 036422 013701 036620      MOV    T16D78,R1 ;78 MICROSECOND DELAY
1987 036426 004737 040102      JSR    PC,T16MMISC ;SETUP T16PK2 COMMAND PACKET
1988 036432 012704 040220      MOV    @T16PK2,R4 ;GET WRITE SUBSYSTEM COMMAND PACKET
1989 036436 010465 000000      MOV    R4,TSDB(R5) ;SET THE PACKET ADDRESS TO EXECUTE

```

```

1990 036442 004737 016336      JSR      PC,CHKTSSR      ;WAIT FOR SSR TO SET
1991 036446                    FORCERROR 3128          ;BDDFORCE ERROR IF FORCER=1
1992 036462 103407            BCS      3208          ;BR IF CARRY SET (GOOD RETURN,
1993 036464 010001            MOV      R0,R1         ;SAVE CONTENTS OF TSSR
1994 036466                    NEXT,ERRNO
1995 036466 3128:  ERRDF  ERRNO,T162SSR,PKTSSR ;DEVICE FATAL SSR FAILED TO SET
      036466 104455                    TRAP      C#ERRDF
      036470 001007                    .WORD    519
      036472 036727                    .WORD    T162SSR
      036474 012046                    .WORD    PKTSSR
1996 036476 005237 002222      INC      FATFLG        ;SET FATAL ERROR FLAG
1997 036502 3208:  CKLOOP                    ;LOOP ON ERROR, IF FLAG SET
      036502 104406                    TRAP      C#CLP1
1998                    ; If Timer A NOT= 1 Then Print Error
1999                    ; If Timer B NOT= 0 Then Print Error
2000 036504 005002            CLR      R2             ;INIT EXPD
2001 036506 052702 000010      BIS     @S2.ATIM,R2    ;TIMER A EXPD=1
2002 036512 042702 000004      BIC     @S2.BTIM,R2    ;TIMER B EXPD=0
2003 036516 012700 040212      MOV     @T16BFSTA,R0   ;GET RECV READ STATUS
2004 036522 016001 000002      MOV     2(R0),R1       ;GET RECV BYTE 2
2005 036526 042701 177763      BIC     @?C<S2.ATIM!S2.BTIM>,R1 ;SAVE TIMER A:B RECV ONLY
2006 036532                    FORCERROR 3728,NOTSSR ;BDD
2007 036542 020201            CMP     R2,R1          ;EXPD EQUAL RECV?
2008 036544 001404            BEQ     3808          ;BR IF YES
2009 036546                    NEXT,ERRNO
2010 036546 3728:  ERRMRO ERRNO,T16T78,TIMEXP ;REPORT ERROR
      036546 104456                    TRAP      C#ERRMRO
      036550 001010                    .WORD    520
      036552 037670                    .WORD    T16T78
      036554 015552                    .WORD    TIMEXP
2011 036556 3808:  CKLOOP                    ;LOOP ON ERROR, IF FLAG SET
      036556 104406                    TRAP      C#CLP1
2012
2013 036560                    ENDSUB
      036560                    ;////////// END SUBTEST //////////
      036560 104403                    L10055:
      036560                    TRAP      C#ESUB
2014
2015 036562 005737 002222      TST     FATFLG        ;ANY FATAL ERRORS ?
2016 036566 001402            BEQ     4608          ;BRANCH IF NOT
2017 036570 004737 017202      JSR     PC,CKDROP     ;TRY TO DROP THE UNIT
2018 036574 004737 016456      4608:  JSR     PC,TSTLOOP ;SHOULD WE DO ITERATIONS?
2019 036600 103002            BCC     4658          ;BR IF NO
2020 036602 000137 034562      JMP     T16LOOP       ;LOOP UNTIL ITERATIONS DONE
2021 036606 4658:
2022
2023
2024 036606                    EXIT  TST
      036606 104432                    TRAP      C#EXIT
      036610 001524                    .WORD    L10053
2025
2026
2027
2028                    ;*
2029                    ;LOCAL STORAGE FOR THIS TEST
2030                    ;-
2030 036612 000001            T16001: .WORD    1
2031 036614 000040            T16028: .WORD    40
2032 036616 000076            T16053: .WORD    76
      ;1 MICROSECOND DELAY (ACTUALLY .8 MIC)
      ;28 MICROSECOND DELAY (.8 MICROS PER)
      ;53 MICROSECOND
    
```

```

2033 036620 000142          T16078:          .WOPD  142          ;78 MICROSECOND
2034                          ;*
2035                          ;LOCAL TEXT MESSAGES FOR TEST
2036                          ;
2037
2038 036622      105      170      164  TST16ID:          .ASCIZ  'Extended Features Switch and Timers A,B'
2039 036672      127      122      111  T165SR: .ASCIZ  'WRITE CHARACTERISTICS Failed'
2040 036727      127      122      111  T162SSR: .ASCIZ  'WRITE SUBSYSTEM (Write Miec) Failed'
2041 036773      127      122      111  T163SSR: .ASCIZ  'WRITE SUBSYSTEM (Read Status) Failed'
2042 037040      102      165      163  T16TSBA: .ASCIZ  'Bus Address Register (TSBA) Incorrect after Write Characteristics'
2043 037142      104      141      164  T16LEN: .ASCIZ  'Data Field Length in Message Buffer Incorrect after Write Characteristics'
2044 037254      124      123      123  T16REJ: .ASCIZ  'TSSR Function Reject Not Returned when Non-Existent Buffer Address Specifie
d
2045 037371      124      151      155  T16T01: .ASCIZ  'Timer A,B Incorrect after Reset Timer with 1 microsecond Delay'
2046 037470      124      151      155  T16T28: .ASCIZ  'Timer A,B Incorrect after Reset Timer with 28 microsecond Delay'
2047 037570      124      151      155  T16T53: .ASCIZ  'Timer A,B Incorrect after Reset Timer with 53 microsecond Delay'
2048 037670      124      151      155  T16T78: .ASCIZ  'Timer A,B Incorrect after Reset Timer with 78 microsecond Delay'
2049                          .EVEN
2050
2051                          ;*
2052                          ; SET DEFAULT PACKET
2053                          ;-
2054 037770          T16REST:
2055 037770      012700      040150          MOV      @T16PACKET,R0          ;PACKET ADDRESS
2056 037774      012720      100004          MOV      @100004,(R0).         ;WRITE CHARACTERISTICS WITH ACK
2057 040000      012720      040160          MOV      @T16DATA,(R0).       ;ADDRESS OF CHAR DATA BLOCK
2058 040004      005020                          CLR      (R0).                 ;EXTENDED ADDRESS
2059 040006      012720      000012          MOV      @10.,(R0).           ;SIZE OF MESSAGE PACKET
2060 040012      012720      040172          MOV      @T16BFR,(R0).        ;MESSAGE BUFFER ADDRESS
2061 040016      005020                          CLR      (R0).                 ;CLEAR EXTENDED BUFFER ADDRESS
2062 040020      012720      000024          MOV      @20.,(R0).           ;LENGTH OF MESSAGE BUFFER
2063 040024      005020                          CLR      (R0).                 ;CLEAR ESS,ENB,EAI,ERI
2064 040026      005010                          CLR      (R0)                  ;CLEAR EXTENDED FEATURES WORD
2065 040030      005037      040172          CLR      T16BFR                ;CLEAR 1ST LOCATION IN MESSAGE BUFFER
2066 040034      000207                          RTS      PC                     ;
2067
2068                          ;*
2069                          ; CLEAR MESSAGE BUFFER
2070                          ;-
2071 040036          T16CLRBUF:
2072 040036          SAVREG          ;SAVE R1-R5 UNTIL NEXT RETURN
2073 040042      012701      040172          MOV      @T16BFR,R1           ;GET MESSAGE BUFFER ADDRESS
2074 040046      012702      000026          MOV      @T16BEND-T16BFR,R2  ;SIZE OF MESSAGE BUFFER IN BYTES
2075 040052      105021          104:  CLR      (R1).               ;CLEAR A BYTE
2076 040054      005302          DEC      R2                    ;DONE?
2077 040056      003375          BGT     104                    ;BR IF NO
2078 040060      000207          RTS      PC                     ;RETURN
2079
2080                          ;*
2081                          ; SETUP T16PK2 PACKET FOR READ STATUS
2082                          ;-
2083 040062          T16SRD:
2084 040062      004737      040036          JSR      PC,T16CLRBUF          ;CLEAR MESSAGE BUFFER
2085 040066      012700      040230          MOV      @T16DT2,R0           ;WRITE SUBSYSTEM DATA BUFFER
2086 040072      112720      000005          MOVB   @PW.RDSTATUS,(R0).     ;STORE READ STATUS COMMAND IN BSEL0
2087 040076      105010                          CLR      (R0)                  ;CLEAR BSEL1
2088 040100      000207          RTS      PC                     ;RETURN
2089
    
```

```

2090
2091
2092
2093
2094
2095
2096
2097
2098 040102
2099 040102
2100 040106 004737 040036
2101 040112 012702 040230
2102 040116 112722 000010
2103 040122 110022
2104 040124 110112
2105 040126 000207
2106
2107
2108
2109 040130
2110 040130 012700 040230
2111 040134 112720 000010
2112 040140 112710 000200
2113 040144 000207
2114
2115
2116
2117
2119 040150
2121
2122
2123
2124 040150
2125 040150 100004
2126 040152 040160
2127 040154 000000
2128 040156 000012
2129
2130 040160
2131 040160 040172
2132 040162 000000
2133 040164 000024
2134 040166 000000
2135 040170 000000
2136
2137
2138
2139
2140 040172
2141 040172 000000
2142 040174 000000
2143 040176 000000
2144 040200 000000
2145 040202 000000
2146 040204 000000
2147 040206 000000
2148 040210 000000

;
; SETUP T16PK2 PACKET FOR WRITE MISC.
;
; INPUT:
; R0 CONTAINS WRITE MISC FUNCTION CODE (BSEL1)
; R1 CONTAINS DELAY (TIMES 800 NS) FOR BSEL2
;
; T16WMISC:
; SAVREG ;SAVE R1-R5 UNTIL NEXT RETURN
; JSR PC,T16CLRBUF ;CLEAR MESSAGE BUFFER
; MOV #T16DT2,R2 ;WRITE SUBSYSTEM DATA BUFFER
; MOVB #PW.WMISC,(R2)+ ;STORE WRITE MISCELLANEOUS IN BSEL0
; MOVB R0,(R2)+ ;STORE WRITE MISC CODE IN BSEL1
; MOVB R1,(R2)+ ;STORE DELAY (RESET TIMER) IN BSEL2
; RTS PC ;RETURN
;
; SETUP T16PK2 PACKET FOR WRITE MISC. INVERT EXTENDED FEATURES SWITCH
;
; T16SEXT:
; MOV #T16DT2,R0 ;WRITE SUBSYSTEM DATA BUFFER
; MOVB #PW.WMISC,(R0)+ ;STORE WRITE MISCELLANEOUS IN BSEL0
; MOVB #MS.EXT,(R0) ;STORE INVERT EXTENDED FEATURES IN BSEL1
; RTS PC ;RETURN
;
; .=<.10>&177770
;
; WRITE CHARACTERISTICS COMMAND PACKET
;
; T16PACKET:
; .WORD 100004 ;COMMAND PACKET FOR TEST
; .WORD T16DATA ;WRITE CHARACTERISTICS COMMAND, WITH ACK
; .WORD 0 ;ADDRESS OF CHARACTERISTICS BLOCK
; .WORD 10. ;MESSAGE PACKET SIZE
;
; T16DATA:
; .WORD T168FR ;CHARACTERISTICS DATA BLOCK
; .WORD 0 ;ADDRESS OF MESSAGE BUFFER
; .WORD 20. ;LENGTH OF MESSAGE BUFFER
; .WORD 0 ;ESS,ENB,EAI,ERI
; .WORD 0 ;EXTENDED FEATURES WORD
;
; MESSAGE BUFFER
;
; T168FR:
; .WORD 0 ;BEGIN MESSAGE BUFFER
; .WORD 0 ;MESSAGE TYPE
; .WORD 0 ;DATA FIELD LENGTH
; .WORD 0 ;RBPGR
; .WORD 0 ;XST0
; .WORD 0 ;XST1
; .WORD 0 ;XST2
; .WORD 0 ;XST3
; .WORD 0 ;XST4 (ALWAYS PRESENT FOR WRITE SUBSYSTEM

```

```
2149 040212          T16BFSTA: .BLKB 6.          ;READ STATUS AND WRITE FIFO BUFFER
2150 040220          T16BEND:          ;END OF MESSAGE BUFFER
2151                  ;
2152                  ;WRITE SUBSYSTEM READ STATUS COMMAND PACKET
2153                  ;
2157 040220          T16PK2:          ;
                .WORD  P.WRTSUB!P.ACK      ;WRITE SUBSYSTEM WITH ACK
2158 040220 100006    .WORD  T16DT2        ;LOW ADDRESS OF DATA BLOCK
2159 040222 040230    .WORD  0            ;HIGH ADDRESS OF DATA BLOCK
2160 040224 000000    .WORD  10.         ;MINIMUM MESSAGE PACKET SIZE
2161 040226 000012    .WORD
2162
2163 040230          T16DT2:          ;DATA BLOCK
2164 040230          .BYTE  0            ;BSELO
2165 040231          .BYTE  0            ;BSEL1
2166 040232 000000    .WORD  0            ;SEL2
2167 040234          .BLKB  64.         ;WRITE FIFO DATA OUTPUT BUFFER
2168
2169
2170 040334          ENDTST
                040334
                040334 104401          L10053: TRAP C$ETST
```

```

2172 .SBTTL TEST 6: FIFO EXERCISFR
2173 ;**
2174 ; TEST DESCRIPTION:
2175 ;
2176 ; This test uses the Write Subsystem Memory command to
2177 ; verify the controller's FIFO and associated status and
2178 ; control logic.
2179 ;
2180 ; TEST STEPS:
2181 ;
2182 ; REPEAT FOR LOOPCNT
2183 ; BEGIN
2184 ; Do Subtest 1 - FIFO Initialize status test
2185 ; Do Subtest 2 - FIFO Write Single Byte test
2186 ; Do Subtest 3 - FIFO Write Multiple Bytes test
2187 ; Do Subtest 4 - FIFO Verify ILW Status test
2188 ; Do Subtest 5 - FIFO Input Ready test
2189 ; Do Subtest 6 - FIFO Verify Reset FIFO test
2190 ; END
2191 ;
2192 ;
2193 ;
2194 040336 BGNTST
2199 040336 012700 046566 MOV #TST17ID,RO ;ASCII MESSAGE TO IDENTIFY TEST
2200 040342 004737 016510 JSR PC,TSTSETUP ;DO INITIAL TEST SETUP
2201 040346 012737 000012 002216 MOV #10,,LOOPCNT ;PERFORM 10 ITERATIONS
2202 040354 004737 017274 JSR PC,KTOFF ;SHUT OFF MEMORY MANAGEMENT
2203 040360 005037 003134 CLR KTENABL ;REALLY SHUT DOWN KT-11
2204 040364 T17LOOP:
2205 ;
2206 ;
2207 ;
2208 .SBTTL TEST 6: SUBTEST 1: FIFO INITIALIZE STATUS TEST
2209 ;**
2210 ; TEST 6: SUBTEST 1:
2211 ;
2212 ; SUBTEST DESCRIPTION:
2213 ;
2214 ; This test verifies, by using the Read Status select code,
2215 ; that the FIFO status is in the correct initial state after
2216 ; the controller is initialized (Input Ready TRUE,
2217 ; Output Ready and Data In Miss FALSE). These status
2218 ; signals are checked by the controller's self-test
2219 ; sequence, so this subtest is actually more of a partial
2220 ; check of the Read Status function than the FIFO status.
2221 ;
2222 ; TEST STEPS:
2223 ;
2224 ; BEGIN
2225 ; Write to TSSR to soft initialize
2226 ; Do a WRITE CHARACTERISTICS to setup a message buffer
2227 ; Do a WRITE SUBSYSTEM Read Status
2228 ; If Input Ready NOT=1 Then Print Error
2229 ; If Output Ready NOT=0 Then Print Error
2230 ; If Data In Miss NOT=0 Then Print Error
2231 ; END

```

```

2232
2233 040364          BGNSUB          ;//////////////// BEGIN SUBTEST //////////////////
      040364          T6.1:          TRAP      C#BSUB
      040364 104402
2234
2235          ; Write to TSSR register to soft initialize the controller
2236 040366          5$:
2237 040366 004737 015774          JSR      PC,SOFINIT          ;WRITE TO TSSR TO SOFT INITIALIZE
2238 040372 103405          BCS      10$          ;BR IF SOFT INIT OKAY
2239 040374 010001          MOV      R0,R1          ;SAVE CONTENTS OF TSSR
2240 040376          ERRDF  ERRNO,SFIERR,SFIMSG          ;DEVICE FATAL DURING INIT
      040376 104455          TRAP      C#ERDF
      040400 001130          .WORD    600
      040402 003652          .WORD    SFIERR
      040404 012034          .WORD    SFIMSG
2241          ; Do a WRITE CHARACTERISTICS to setup a message buffer
2242 040406 005037 002222          10$: CLR      FATFLG          ;CLEAR FATAL ERROR FLAG
2243 040412 012704 050160          MOV      #T17PACKET,R4          ;GET THE ADDRESS OF COMMAND PACKET
2244 040416 004737 010662          JSR      PC,WRTCHR          ;DO WRITE CHARACTERISTICS COMMAND
2245 040422          FORCERROR 42$          ;BDFORCE ERROR IF FORCER=1
2246 040436 103407          BCS      50$          ;BR IF CARRY SET (GOOD RETURN)
2247 040440 010001          MOV      R0,R1          ;SAVE CONTENTS OF TSSR
2248 040442          NEXT.ERRNO
2249 040442          42$: ERRDF  ERRNO,T17SSR,PKTSSR          ;DEVICE FATAL SSR FAILED TO SET
      040442 104455          TRAP      C#ERDF
      040444 001131          .WORD    601
      040446 046605          .WORD    T17SSR
      040450 012046          .WORD    PKTSSR
2250 040452 005237 002222          INC      FATFLG          ;SET FATAL ERROR FLAG
2251 040456          50$: CKLOOP          ;LOOP ON ERROR, IF FLAG SET
      040456 104406          TRAP      C#CLP1
2252
2253          ; Do a Write Subsystem READ STATUS
2254 040460 004737 047744          JSR      PC,T17SRD          ;SETUP PACKET FOR READ STATUS
2255 040464 012704 050330          MOV      #T17PK2,R4          ;GET WRITE SUBSYSTEM COMMAND PACKET
2256 040470 010465 000000          MOV      R4,TSD8(R5)          ;SET THE PACKET ADDRESS TO EXECUTE
2257 040474 004737 016336          JSR      PC,CHKTSSR          ;WAIT FOR SSR TO SET
2258 040500          FORCERROR 62$          ;BDFORCE ERROR IF FORCER=1
2259 040514 103407          BCS      70$          ;BR IF CARRY SET (GOOD RETURN)
2260 040516 010001          MOV      R0,R1          ;SAVE CONTENTS OF TSSR
2261 040520          NEXT.ERRNO
2262 040520          62$: ERRDF  ERRNO,T173SSR,PKTSSR          ;DEVICE FATAL SSR FAILED TO SET
      040520 104455          TRAP      C#ERDF
      040522 001132          .WORD    602
      040524 046706          .WORD    T173SSR
      040526 012046          .WORD    PKTSSR
2263 040530 005237 002222          INC      FATFLG          ;SET FATAL ERROR FLAG
2264 040534          70$: CKLOOP          ;LOOP ON ERROR, IF FLAG SET
      040534 104406          TRAP      C#CLP1
2265          ; Set WORDS 0-7 of expd message buffer = to rcv since not testing
2266 040536 004737 050126          JSR      PC,T17SETEXP          ;SET WORDS 0-7 EXPD=RCV
2267 040542 012701 046362          MOV      #T17EXSTA,R1          ;GET EXPECTED READ STATUS
2268 040546 012702 050222          MOV      #T17BFSTA,R2          ;GET RCV READ STATUS
2269 040552 012221          MOV      (R2), (R1)          ;SET EXPD WORD #8 = RCV TEMP
2270 040554 011211          MOV      (R2), (R1)          ;SET EXPD WORD #9 = RCV TEMP
2271 040556 052711 000020          BIS      #S2.INRDY,(R1)          ;SET EXP INPUT READY= TRUE
2272 040562 042711 000040          BIC      #S2.OUTRDY,(R1)          ;SET EXP OUTPUT READY= FALSE

```



TSV5 HARDWARE TESTS MACRO M1113 14-JUN-84 15:55  
 TEST 6: SUBTEST 1: FIFO INITIALIZE STATUS TEST

SEQ 0151

```

2273 040566 042711 000200      BIC      #S2.DIM,(R1)      ;SET EXP DATA IN MISS = FALSE
2274      :      If Input Ready NOT=1 then Print Error
2275      :      If Output Ready NOT=0 or Data in Miss NOT=0 Then Print Error
2276 040572 005000      CLP      R0      ;HIGH RECV ADDRESS FOR CKMSG2
2277 040574 012701 050202      MOV      #T17BFR,R1      ;LOW RECV ADDRESS FOR CKMSG2
2278 040600 012702 046342      MOV      #T17EXP,R2      ;EXPD ADDRESS
2279 040604 012703 000024      MOV      #20.,R3      ;NUMBER OF BYTES TO COMPARE
2280 040610 004737 011500      JSR      PC,CKMSG2      ;EXPD EQUAL RECV?
2281 040614      FORCERROR      82$,NOTSSR      ;88D
2282 040624 103404      BCS      90$      ;BR IF YES
2283 040626      NEXT.ERRNO
2284 040626      82$:      ERRHRD ERRNO,T171CMP,MSGSTAT      ;REPORT ERROR
      040626 104456      TRAP      C#ERHRD
      040630 001133      .WORD      603
      040632 047125      .WORD      T171CMP
      040634 012350      .WORD      MSGSTAT
2285 040636      90$:      CKLOOP      ;LOOP ON ERROR, IF FLAG SET
      040636 104406      TRAP      C#CLP1
2286
2287 040640      ENDSUB      ;////////////////// END SUBTEST ////////////////////
      040640      L10057:
      040640 104403      TRAP      C#ESUB
2288
2289 040642 005737 002222      TST      FATFLG      ;ANY FATAL ERRORS ?
2290 040646 001402      BEQ      160$      ;BRANCH IF NOT
2291 040650 004737 017202      JSR      PC,CKDROP      ;TRY TO DROP THE UNIT
2292 040654      160$:
2293
2294      .SBTTL TEST 6: SUBTEST 2: FIFO WRITE SINGLE BYTE TEST
2295
2296      ;**
2297      ; TEST 6: SUBTEST 2:
2298      ;
2299      ; SUBTEST DESCRIPTION:
2300      ;
2301      ; This subtest verifies the ability of the FIFO to correctly
2302      ; pass a single data byte from input to output. For each
2303      ; of 256 data values (0-377 octal) the following is done:
2304      ; 1. Initial FIFO status is checked
2305      ; 2. The Write FIFO function, specifying a count of
2306      ; one byte to be written is executed.
2307      ; 3. Read Status is executed and FIFO status is checked.
2308      ; 4. Read FIFO is executed and the data and final status
2309      ; is checked.
2310      ;
2311      ; TEST STEPS:
2312      ;
2313      ; BEGIN
2314      ; Write to TSSR to soft initialize
2315      ; Do a WRITE CHARACTERISTICS to setup a message buffer
2316      ; Do a Write Subsystem READ STATUS
2317      ; If Input Ready NOT=1 Then Print Error
2318      ; If Output Ready NOT=0 Then Print Error
2319      ; If Data In Miss NOT=0 Then Print Error
2320      ;
2321      ; REPEAT FOR DATA FROM 0 TO 377 OCTAL
2322      ; BEGIN

```

```

2323 : Do a Write Subsystem WRITE NPR to set tape direction out
2324 : Do a Write Subsystem WRITE FIFO with byte count equal to 1
2325 : Do a Write Subsystem READ STATUS
2326 : If Input Ready NOT=1 Then Print Error
2327 : If Output Ready NOT=1 Then Print Error
2328 : If Data In Miss NOT=0 Then Print Error
2329 : Do Write Subsystem READ FIFO with byte count equal to 1
2330 : If Data read from FIFO NOT= to Data sent Then Print Error
2331 : Do a Write Subsystem READ STATUS
2332 : If Input Ready NOT=1 Then Print Error
2333 : If Output Ready NOT=0 Then Print Error
2334 : If Data In Miss NOT=0 Then Print Error
2335 : END
2336 : END
2337 :
2338 040654 BGNSUB ;//////////////// BEGIN SUBTEST //////////////////
      040654 ; T6.2:
      040654 104402 TRAP C#BSUB

2339 :
2340 : Write to TSSR register to soft initialize the controller
2341 040656 5$:
2342 040656 004737 015774 JSR PC,SOFINIT ;WRITE TO TSSR TO SOFT INITIALIZE
2343 040662 103405 BCS 10$ ;BR IF SOFT INIT OKAY
2344 040664 010001 MOV R0,R1 ;SAVE CONTENTS OF TSSR
2345 040666 ERRDF ERRNO,SFIERR,SFIMSG ;DEVICE FATAL DURING INIT
      040666 104455 TRAP C#ERDF
      040670 001133 .WORD 603
      040672 003652 .WORD SFIERR
      040674 012034 .WORD SFIMSG

2346 : Do a WRITE CHARACTERISTICS to setup a message buffer
2347 040676 005037 002222 10$: CLR FATFLG ;CLEAR FATAL ERROR FLAG
2348 040702 012704 050160 MOV @T17PACKET,R4 ;GET THE ADDRESS OF COMMAND PACKET
2349 040706 004737 010662 JSR PC,WRTCHR ;DO WRITE CHARACTERISTICS COMMAND
2350 040712 FORCERROR 42$ ;SDFORCE ERROR IF FORCER=1
2351 040726 103407 BCS 50$ ;BR IF CARRY SET (GOOD RETURN)
2352 040730 010001 MOV R0,R1 ;SAVE CONTENTS OF TSSR
2353 040732 NEXT.ERRNO
2354 040732 42$: ERRDF ERRNO,T17SSR,PKTSSR ;DEVICE FATAL SSR FAILED TO SET
      040732 104455 TRAP C#ERDF
      040734 001134 .WORD 604
      040736 046605 .WORD T17SSR
      040740 012046 .WORD PKTSSR

2355 040742 005237 002222 INC FATFLG ;SET FATAL ERROR FLAG
2356 040746 50$: CKLOOP ;LOOP ON ERROR, IF FLAG SET
      040746 104406 TRAP C#CLP1

2357 : Do a Write Subsystem READ STATUS
2358 040750 004737 047744 JSR PC,T17SRD ;SETUP PACKET FOR READ STATUS
2359 040754 012704 050330 MOV @T17PK2,R4 ;GET WRITE SUBSYSTEM COMMAND PACKET
2360 040760 010465 000000 MOV R4,TSDB(R5) ;SET THE PACKET ADDRESS TO EXECUTE
2361 040764 004737 016336 JSR PC,CHKTSSR ;WAIT FOR SSR TO SET
2362 040770 FORCERROR 62$ ;SDFORCE ERROR IF FORCER=1
2363 041004 103407 BCS 70$ ;BR IF CARRY SET (GOOD RETURN)
2364 041006 010001 MOV R0,R1 ;SAVE CONTENTS OF TSSR
2365 041010 NEXT.ERRNO
2366 041010 62$: ERRDF ERRNO,T173SSR,PKTSSR ;DEVICE FATAL SSR FAILED TO SET
      041010 104455 TRAP C#ERDF
      041012 001135 .WORD 605
  
```

```

041014 046706                                .WORD T173SSR
041016 012046                                .WORD PKTSSR
2367 041020 005237 002222                    INC FATFLG ;SET FATAL ERROR FLAG
2368 041024 104406 70$: CKLOOP ;LOOP ON ERROR, IF FLAG SET
041024 104406                                TRAP C$CLP1
2369 ; Set WORDS 0-7 of expd message buffer = to recv since not testing
2370 041026 004737 050126                    JSR PC,T17SETEXP ;SET WORDS 0-7 EXPD=RCV
2371 041032 012701 046362                    MOV #T17EXSTA,R1 ;GET EXPECTED READ STATUS
2372 041036 012702 050222                    MOV #T17BFSTA,R2 ;GET RCV READ STATUS
2373 041042 012221                            MOV (R2)+,(R1)+ ;SET EXPD WORD #8 = RCV TEMP
2374 041044 011211                            MOV (R2),(R1) ;SET EXPD WORD #9 = RCV TEMP
2375 041046 052711 000020                    BIS #S2.INRDY,(R1) ;SET EXP INPUT READY= TRUE
2376 041052 042711 000040                    BIC #S2.OUTRDY,(R1) ;SET EXP OUTPUT READY= FALSE
2377 041056 042711 000200                    BIC #S2.DIM,(R1) ;SET EXP DATA IN MISS = FALSE
2378 ; If Input Ready NOT=1 then Print Error
2379 ; If Output Ready NOT=0 or Data in Miss NOT=0 Then Print Error
2380 041062 005000                            CLR R0 ;HIGH RCV ADDRESS FOR CKMSG2
2381 041064 012701 050202                    MOV #T17BFR,R1 ;LOW RCV ADDRESS FOR CKMSG2
2382 041070 012702 046342                    MOV #T17EXP,R2 ;EXPD ADDRESS
2383 041074 012703 000024                    MOV #20.,R3 ;NUMBER OF BYTES TO COMPARE
2384 041100 004737 011500                    JSR PC,CKMSG2 ;EXPD EQUAL RCV?
2385 041104 FORCERROR 82$,NOTSSR ;SSD
2386 041114 103404                            BCS 90$ ;BR IF YES
2387 041116 NEXT.ERRNO
2388 041116 82$: ERRMRD ERRNO,T171CMP,MSGSTAT ;REPORT ERROR
041116 104456                                TRAP C$ERRMRD
041120 001136                                .WORD 606
041122 047125                                .WORD T171CMP
041124 012350                                .WORD MSGSTAT
2389 041126 104406 90$: CKLOOP ;LOOP ON ERROR, IF FLAG SET
041126 104406                                TRAP C$CLP1
2390 ; Repeat for DATA from 0 to 377
2391 ;
2392 041130 012737 000000 002312            100$: MOV #0,DATA ;GET FIRST DATA
2393 041136 ; ;REPEAT LABEL
2394 ; Do a Write Subsystem WRITE NPR to set tape direction out
2395 041136 012700 000100                    MOV #NP.OUT,R0 ;SET TAPE DIRECTION OUT
2396 041142 004737 050006                    JSR PC,T17SNPR ;SETUP T17PK2 FOR WRITE NPR
2397 041146 012704 050330                    MOV #T17PK2,R4 ;GET WRITE SUBSYSTEM COMMAND PACKET
2398 041152 010465 000000                    MOV R4,TSDB(R5) ;SET THE PACKET ADDRESS TO EXECUTE
2399 041156 004737 016336                    JSR PC,CHKTSSR ;WAIT FOR SSR TO SET
2400 041162 FORCERROR 102$ ;SSDFORCE ERROR IF FORCER=1
2401 041176 103407                            BCS 105$ ;BR IF CARRY SET (GOOD RETURN)
2402 041200 010001                            MOV R0,R1 ;SAVE CONTENTS OF TSSR
2403 041202 NEXT.ERRNO
2404 041202 102$: ERRDF ERRNO,T174SSR,PKTSSR ;DEVICE FATAL SSR FAILED TO SET
041202 104455                                TRAP C$ERRDF
041204 001137                                .WORD 607
041206 046753                                .WORD T174SSR
041210 012046                                .WORD PKTSSR
2405 041212 005237 002222                    INC FATFLG ;SET FATAL ERROR FLAG
2406 041216 104406 105$: CKLOOP ;LOOP ON ERROR, IF FLAG SET
041216 104406                                TRAP C$CLP1
2407 ; Do a Write Subsystem WRITE FIFO with byte count equal to 1
2408 041220 012700 000001                    MOV #1,R0 ;WRITE 1 BYTE
2409 041224 012701 002312                    MOV #DATA,R1 ;FIFO WRITE DATA ADDRESS
2410 041230 004737 050032                    JSR PC,T17WFIF ;SETUP T17PK2 FOR WRITE FIFO

```

```

2411 041234 012704 050330      MOV    @T17PK2,R4      ;GET WRITE SUBSYSTEM COMMAND PACKET
2412 041240 010465 000000      MOV    R4,TSDB(R5)    ;SET THE PACKET ADDRESS TO EXECUTE
2413 041244 004737 016336      JSR    PC,CHKTSSR     ;WAIT FOR SSR TO SET
2414 041250                      FORCERROR 107$        ;$$$FORCE ERROR IF FORCER=1
2415 041264 103407          BCS    110$          ;BR IF CARRY SET (GOOD RETURN)
2416 041266 010001          MOV    R0,R1         ;SAVE CONTENTS OF TSSR
2417 041270                      NEXT.ERRNO
2418 041270 107$:          ERRDF  ERRNO,T175SSR,PKTSSR ;DEVICE FATAL SSR FAILED TO SET
                                TRAP    C$ERDF
                                .WORD  608
                                .WORD  T175SSR
                                .WORD  PKTSSR
2419 041300 005237 002222      INC    FATFLG        ;SET FATAL ERROR FLAG
2420 041304 110$:          CKLOOP          ;LOOP ON ERROR, IF FLAG SET
                                TRAP    C$CLP1
2421
2422          ;          Do a Write Subsystem READ STATUS
2423 041306 004737 047744      JSR    PC,T17SRD     ;SETUP PACKET FOR READ STATUS
2424 041312 012704 050330      MOV    @T17PK2,R4    ;GET WRITE SUBSYSTEM COMMAND PACKET
2425 041316 010465 000000      MOV    R4,TSDB(R5)    ;SET THE PACKET ADDRESS TO EXECUTE
2426 041322 004737 016336      JSR    PC,CHKTSSR     ;WAIT FOR SSR TO SET
2427 041326                      FORCERROR 112$        ;$$$FORCE ERROR IF FORCER=1
2428 041342 103407          BCS    120$          ;BR IF CARRY SET (GOOD RETURN)
2429 041344 010001          MOV    R0,R1         ;SAVE CONTENTS OF TSSR
2430 041346                      NEXT.ERRNO
2431 041346 112$:          ERRDF  ERRNO,T173SSR,PKTSSR ;DEVICE FATAL SSR FAILED TO SET
                                TRAP    C$ERDF
                                .WORD  609
                                .WORD  T173SSR
                                .WORD  PKTSSR
2432 041356 005237 002222      INC    FATFLG        ;SET FATAL ERROR FLAG
2433 041362 120$:          CKLOOP          ;LOOP ON ERROR, IF FLAG SET
                                TRAP    C$CLP1
2434          ;          Set WORDS 0-7 of expd message buffer = to recv since not testing
2435 041364 004737 050126      JSR    PC,T17SETEXP  ;SET WORDS 0-7 EXPD=RECV
2436 041370 012701 046362      MOV    @T17EXSTA,R1  ;GET EXPECTED READ STATUS
2437 041374 012702 050222      MOV    @T17BFSTA,R2  ;GET RECV READ STATUS
2438 041400 012221          MOV    (R2)+,(R1)+   ;SET EXPD WORD #8 = RECV TEMP
2439 041402 011211          MOV    (R2),(R1)     ;SET EXPD WORD #9 = RECV TEMP
2440 041404 052711 000020      BIS    #S2.INRDY,(R1) ;SET EXP INPUT READY= 1
2441 041410 052711 000040      BIS    #S2.OUTRDY,(R1) ;SET EXP OUTPUT READY= 1
2442 041414 042711 000200      BIC    #S2.DIM,(R1)  ;SET EXP DATA IN MISS = 0
2443          ;          If Input Ready NOT=1 then Print Error
2444          ;          If Output Ready NOT=1 or Data in Miss NOT=0 Then Print Error
2445 041420 005000          CLR    R0           ;HIGH RECV ADDRESS FOR CKMSG2
2446 041422 012701 050202      MOV    @T17BFR,R1    ;LOW RECV ADDRESS FOR CKMSG2
2447 041426 012702 046342      MOV    @T17EXP,R2    ;EXPD ADDRESS
2448 041432 012703 000024      MOV    #20.,R3       ;NUMBER OF BYTES TO COMPARE
2449 041436 004737 011500      JSR    PC,CKMSG2     ;EXPD EQUAL RECV?
2450 041442                      FORCERROR 132$,NOTSSR ;$$$
2451 041452 103404          BCS    140$          ;BR IF YES
2452 041454                      NEXT.ERRNO
2453 041454 132$:          ERRHRD ERRNO,T173CMP,MSGSTAT ;REPORT ERROR
                                TRAP    C$ERHRD
                                .WORD  610
                                .WORD  T173CMP
                                .WORD  MSGSTAT
041454 104456
041456 001142
041460 047303
041462 012350

```

```

2454 041464      140$: CKLOOP                ;LOOP ON ERROR, IF FLAG SET
      041464 104406                        TRAP          C$CLP1
2455
2456           ; Do Write Subsystem READ FIFO with byte count equal to 1
2457 041466 012700 000001      MOV      #1,R0                ;SET READ BYTE COUNT
2458 041472 004737 050066      JSR      PC,T17RFIF          ;SETUP T17PK2 FOR READ FIFO
2459 041476 012704 050330      MOV      #T17PK2,R4         ;GET WRITE SUBSYSTEM COMMAND PACKET
2460 041502 010465 000000      MOV      R4,TSDB(R5)        ;SET THE PACKET ADDRESS TO EXECUTE
2461 041506 004737 016336      JSR      PC,CHKTSSR         ;WAIT FOR SSR TO SET
2462 041512                        FORCERROR 142$                ;BDDFORCE ERROR IF FORCER=1
2463 041526 103407      BCS     150$                ;BR IF CARRY SET (GOOD RETURN)
2464 041530 010001      MOV      R0,R1              ;SAVE CONTENTS OF TSSR
2465 041532      NEXT.ERRNO
2466 041532      142$: ERRDF  ERRNO,T176SSR,PKTSSR ;DEVICE FATAL SSR FAILED TO SET
      041532 104455                        TRAP          C$ERDF
      041534 001143                        .WORD        611
      041536 047062                        .WORD        T176SSR
      041540 012046                        .WORD        PKTSSR
2467 041542 005237 002222      INC      FATFLG             ;SET FATAL ERROR FLAG
2468 041546      150$: CKLOOP                ;LOOP ON ERROR, IF FLAG SET
      041546 104406                        TRAP          C$CLP1
2469           ; Set WORDS 0-7 of expd message buffer = to recv since not testing
2470 041550 004737 050126      JSR      PC,T17SETEXP       ;SET WORDS 0-7 EXPD=RCV
2471 041554 012701 046362      MOV      #T17EXSTA,R1      ;GET EXPECTED READ STATUS
2472 041560 012702 050222      MOV      #T17BFSTA,R2     ;GET RCV READ STATUS
2473 041564 013721 002312      MOV      DATA,(R1)+       ;SET EXPD WORD #8 = COUNT DATA
2474 041570 011211      MOV      (R2),(R1)         ;SET EXPD WORD #9 = RCV (NOT TESTING)
2475           ; If Data read from FIFO NOT= to Data sent Then Print Error
2476           ; The data is in WORD #8 of the message buffer
2477 041572 005000      CLR      R0                ;HIGH RCV ADDRESS FOR CKMSG2
2478 041574 012701 050202      MOV      #T17BFR,R1        ;LOW RCV ADDRESS FOR CKMSG2
2479 041600 012702 046342      MOV      #T17EXP,R2        ;EXPD ADDRESS
2480 041604 012703 000022      MOV      #18.,R3           ;NUMBER OF BYTES TO COMPARE
2481 041610 004737 011500      JSR      PC,CKMSG2         ;EXPD EQUAL RCV?
2482 041614      FORCERROR 152$,NOTSSR     ;BDD
2483 041624 103404      BCS     160$                ;BR IF YES
2484 041626      NEXT.ERRNO
2485 041626      152$: ERRHRD  ERRNO,T172CMP,MSGSUB ;REPORT ERROR
      041626 104456                        TRAP          C$ERHPD
      041630 001144                        .WORD        612
      041632 047207                        .WORD        T172CMP
      041634 013742                        .WORD        MSGSUB
2486 041636      160$: CKLOOP                ;LOOP ON ERROR, IF FLAG SET
      041636 104406                        TRAP          C$CLP1
2487
2488           ; Do a Write Subsystem READ STATUS
2489 041640 004737 047744      JSR      PC,T17SRD         ;SETUP PACKET FOR READ STATUS
2490 041644 012704 050330      MOV      #T17PK2,R4         ;GET WRITE SUBSYSTEM COMMAND PACKET
2491 041650 010465 000000      MOV      R4,TSDB(R5)        ;SET THE PACKET ADDRESS TO EXECUTE
2492 041654 004737 016336      JSR      PC,CHKTSSR         ;WAIT FOR SSR TO SET
2493 041660      FORCERROR 162$                ;BDDFORCE ERROR IF FORCER=1
2494 041674 103407      BCS     170$                ;BR IF CARRY SET (GOOD RETURN)
2495 041676 010001      MOV      R0,R1              ;SAVE CONTENTS OF TSSR
2496 041700      NEXT.ERRNO
2497 041700      162$: ERRDF  ERRNO,T173SSR,PKTSSR ;DEVICE FATAL SSR FAILED TO SET
      041700 104455                        TRAP          C$ERDF
      041702 001145                        .WORD        613

```

```

041704 046706 .WORD T173SSR
041706 012046 .WORD PKTSSR
2498 041710 005237 002222 INC FATFLG ;SET FATAL ERROR FLAG
2499 041714 104406 170$: CKLOOP ;LOOP ON ERROR, IF FLAG SET
; TRAP C$CLP1
; Set WORDS 0-7 of expd message buffer = to recv since not testing
2500 ; JSR PC,T17SETEXP ;SET WORDS 0-7 EXPD=RCV
2501 041716 004737 050126 MOV #T17EXSTA,R1 ;GET EXPECTED READ STATUS
2502 041722 012701 046362 MOV #T17BFSTA,R2 ;GET RCV READ STATUS
2503 041726 012702 050222 MOV (R2)+,(R1)+ ;SET EXPD WORD #8 = RCV TEMP
2504 041732 012221 MOV (R2),(R1) ;SET EXPD WORD #9 = RCV TEMP
2505 041734 011211 BIS #S2.INRDY,(R1) ;SET EXP INPUT READY= 1
2506 041736 052711 000020 BIC #S2.OUTRDY,(R1) ;SET EXP OUTPUT READY= 0
2507 041742 042711 000040 BIC #S2.DIM,(R1) ;SET EXP DATA IN MISS = 0
2508 041746 042711 000200
2509 ; If Input Ready NOT=1 then Print Error
2510 ; If Output Ready NOT=0 or Data in Miss NOT=0 Then Print Error
2511 041752 005000 CLR R0 ;HIGH RCV ADDRESS FOR CKMSG2
2512 041754 012701 050202 MOV #T17BFR,R1 ;LOW RCV ADDRESS FOR CKMSG2
2513 041760 012702 046342 MOV #T17EXP,R2 ;EXPD ADDRESS
2514 041764 012703 000024 MOV #20.,R3 ;NUMBER OF BYTES TO COMPARE
2515 041770 004737 011500 JSR PC,CKMSG2 ;EXPD EQUAL RCV?
2516 041774 FORCERROR 172$,NOTSSR ;$D
2517 042004 103404 BCS 180$ ;BR IF YES
2518 042006 NEXT.ERRNO
2519 042006 172$: ERRHRD ERRNO,T174CMP,MSGSTAT ;REPORT ERROR
; TRAP C$ERHRD
; .WORD 614
; .WORD T174CMP
; .WORD MSGSTAT
2520 042016 180$: CKLOOP ;LOOP ON ERROR, IF FLAG SET
; TRAP C$CLP1
2521 042020 FORCEEXIT 205$ ;$D
2522 042030 005237 002312 INC DATA ;GET NEXT TEST DATA
2523 042034 023727 002312 000377 CMP DATA,#377 ;DONE 0 TO 377?
2524 042042 101002 BHI 205$ ;BR IF YES
2525 042044 000137 041136 JMP 100$ ;DO ANOTHER TEST PATTERN
2526 042050 205$:
2527
2528 042050 ENDSUB ;////////// END SUBTEST //////////
; L10060:
; TRAP C$ESUB
2529 042050 104403
2530 042052 005737 002222 TST FATFLG ;ANY FATAL ERRORS ?
2531 042056 001402 BEQ 260$ ;BRANCH IF NOT
2532 042060 004737 017202 JSR PC,CKDROP ;TRY TO DROP THE UNIT
2533 042064 260$:
2534
2535 .SBTTL TEST 6: SUBTEST 3: FIFO WRITE MULTIPLE BYTES TEST
2536
2537 ;**
2538 ; TEST 6: SUBTEST 3:
2539 ;
2540 ; SUBTEST DESCRIPTION:
2541 ;
2542 ; This subtest verifies the ability of the FIFO to correctly
2543 ; pass a multiple data bytes from input to output.
2544 ; The following sequence is done with various data patterns

```

```

2545      ;          and byte counts from 2 to 64.
2546      ;          1. Initial FIFO status is checked
2547      ;          2. The Write FIFO function.
2548      ;          3. Read Status is executed and FIFO status is checked
2549      ;          4. Read FIFO is executed and the data and final status
2550      ;          is checked
2551      ;
2552      ; TEST STEPS:
2553      ;
2554      ; BEGIN
2555      ;     Write to TSSR to soft initialize
2556      ;     Do a WRITE CHARACTERISTICS to setup a message buffer
2557      ;     Do a Write Subsystem READ STATUS
2558      ;     IF Input Ready NOT=1 Then Print Error
2559      ;     IF Output Ready NOT=0 Then Print Error
2560      ;     IF Data In Miss NOT=0 Then Print Error
2561      ;     IF Last Word NOT=0 Then Print Error
2562      ; REPEAT FOR DATA 0 TO 377, 377 TO 0, FLOATING 1'S,0'S AND ALL 1'S/0 S
2563      ; REPEAT FOR BYTE COUNT 2 TO 64 DECIMAL
2564      ; BEGIN
2565      ;     Do a Write Subsystem WRITE DPR to set tape direction out
2566      ;     Do a Write Subsystem WRITE FIFO
2567      ;     Do a Write Subsystem READ STATUS
2568      ;     IF Input Ready NOT=1 Then Print Error
2569      ;     IF Output Ready NOT=1 Then Print Error
2570      ;     IF Data In Miss NOT=0 Then Print Error
2571      ;     IF Last Word NOT=0 Then Print Error
2572      ;     Do Write Subsystem READ "IFO
2573      ;     IF Data read from FIFO NOT= to Data sent Then Print Error
2574      ;     Do a Write Subsystem READ STATUS
2575      ;     IF Input Ready NOT=1 Then Print Error
2576      ;     IF Output Ready NOT=0 Then Print Error
2577      ;     IF Data In Miss NOT=0 Then Print Error
2578      ;     IF Last Word NOT=0 Then Print Error
2579      ; END
2580      ; END
2581      ;
2582      ; BGNSUB          ;////////// BEGIN SUBTEST ////////////
2583      ;                ; T6.3:          TRAP C#BS'B
2584      ;
2585      ; Write to TSSR register to soft initialize the controller
2586      ; 51:
2587      ; JSR PC,SOFINIT          ;WRITE TO TSSR TO SOFT INITIALIZE
2588      ; BCS 101                ;BR IF SOFT INIT OKAY
2589      ; MOV R0,R1              ;SAVE CONTENTS OF TSSR
2590      ; ERROF ERRNO,SFIERR,SFIMSG ;DEVICE FATAL DURING INIT
2591      ;                                TRAP C#EROF
2592      ;                                .WORD 614
2593      ;                                .WORD SFIERR
2594      ;                                .WORD SFIMSG
2595      ;
2596      ; Do a WRITE CHARACTERISTICS to setup a message buffer
2597      ; 101:
2598      ; CLR FATFLG              ;CLEAR FATAL ERROR FLAG
2599      ; MOV @T17PACKET,R4       ;GET THE ADDRESS OF COMMAND PACKET
2600      ; JSR PC,WRTCHR           ;DO WRITE CHARACTERISTICS COMMAND
2601      ; FORCERROR 421           ;BDFORCE ERROR IF FORCER=1
2602      ; BCS 501                ;BR IF CARRY SET (GOOD RETURN)

```

```

2596 042140 010001          MOV     R0,R1          ;SAVE CONTENTS OF TSSR
2597 042142          NEXT.ERRNO
2598 042142          424:  ERRDF  ERRNO,T17SSR,PKTSSR ;DEVICE FATAL SSR FAILED TO SET
      042142 104455          TRAP  C1ERDF
      042144 001147          .WORD 615
      042146 046605          .WORD T17SSR
      042150 012046          .WORD PKTSSR
2599 042152 005237 002222  INC     FATFLG        ;SET FATAL ERROR FLAG
2600 042156          504:  CKLOOP          ;LOOP ON ERROR, IF FLAG SET
      042156 104406          TRAP  C1CLP1
2601          ; Do a Write Subsystem READ STATUS
2602 042160 004737 047744  JSR     PC,T17SRD     ;SETUP PACKET FOR READ STATUS
2603 042164 012704 050330  MOV     @T17PK2,R4    ;GET WRITE SUBSYSTEM COMMAND PACKET
2604 042170 010465 000000  MOV     R4,TSDB(R5)   ;SET THE PACKET ADDRESS TO EXECUTE
2605 042174 004737 016336  JSR     PC,CHKTSSR    ;WAIT FOR SSR TO SET
2606 042200          FORCERROR 624        ;BDDFORCE ERROR IF FORCER=1
2607 042214 103407          BCS     704          ;BR IF CARRY SET (GOOD RETURN)
2608 042216 010001          MOV     R0,R1          ;SAVE CONTENTS OF TSSR
2609 042220          NEXT.ERRNO
2610 042220          624:  ERRDF  ERRNO,T173SSR,PKTSSR ;DEVICE FATAL SSR FAILED TO SET
      042220 104455          TRAP  C1ERDF
      042222 001150          .WORD 616
      042224 046706          .WORD T173SSR
      042226 012046          .WORD PKTSSR
2611 042230 005237 002222  INC     FATFLG        ;SET FATAL ERROR FLAG
2612 042234          704:  CKLOOP          ;LOOP ON ERROR, IF FLAG SET
      042234 104406          TRAP  C1CLP1
2613          ; Set WORDS 0-7 of expd message buffer = to recv since not testing
2614 042236 004737 050126  JSR     PC,T17SETEXP  ;SET WORDS 0-7 EXPD=RECV
2615 042242 012701 046362  MOV     @T17EXSTA,R1  ;GET EXPECTED READ STATUS
2616 042246 012702 050222  MOV     @T17BFSTA,R2  ;GET RECV READ STATUS
2617 042252 012221          MOV     (R2),.(R1)    ;SET EXPD WORD #8 = RECV TEMP
2618 042254 011211          MOV     (R2),.(R1)    ;SET EXPD WORD #9 = RECV TEMP
2619 042256 052711 000020  BIS     @S2.INRDY,(R1) ;SET EXP INPUT READY= 1
2620 042262 042711 000040  BIC     @S2.OUTRDY,(R1) ;SET EXP OUTPUT READY= 0
2621 042266 042711 000200  BIC     @S2.DIM,(R1)  ;SET EXP DATA IN MISS = 0
2622 042272 042711 000100  BIC     @S2.ILW,(R1)  ;SET EXP LAST WORD (ILW)=0
2623          ; If Input Ready NOT=1 then Print Error
2624          ; If Output Ready NOT=0 or Data in Miss NOT=C Then Print Error
2625          ; If Last Word NOT=0 Then Print Error
2626 042276 005000          CLR     R0            ;HIGH RECV ADDRESS FOR CKMSG2
2627 042300 012701 050202  MOV     @T17BFR,R1    ;LOW RECV ADDRESS FOR CKMSG2
2628 042304 012702 046342  MOV     @T17EXP,R2    ;EXPD ADDRESS
2629 042310 012703 000024  MOV     @20.,R3       ;NUMBER OF BYTES TO COMPARE
2630 042314 004737 011500  JSR     PC,CKMSG2     ;EXPD EQUAL RECV?
2631 042320          FORCERROR 824,NOTSSR ;BDD
2632 042330 103404          BCS     904          ;BR IF YES
2633 042332          NEXT.ERRNO
2634 042332          824:  ERRHRD  ERRNO,T171CMP,MSGSTAT ;REPORT ERROR
      042332 104456          TRAP  C1ERHRD
      042334 001151          .WORD 617
      042336 047125          .WORD T171CMP
      042340 012350          .WORD MSGSTAT
2635 042342          904:  CKLOOP          ;LLOP ON ERROR, IF FLAG SET
      042342 104406          TRAP  C1CLP1
2636
2637

```



```

2638
2639 ; REPEAT FOR BYTE COUNT 2 TO 64 DECIMAL
2640 ; TSTFLAG =1 FOR INCREMENT TEST PATTERN
2641 ; =2 FOR DECREMENT TEST PATTERN
2642 ; =3 FOR TSTBLK TABLE PATTERN
2643 042344 012737 000001 002314      MOV     #1,TSTFLAG      ;TEST PATTERN FLAG
2644 042352      954:      MOV     #2,COUNT      ;GET FIRST BYTE COUNT
2645 042352 012737 000002 002310
2646 042360      1004:
2647 ; Do a Write Subsystem WRITE NPR to set tape direction out
2648 042360 012700 000100      MOV     @NP.OUT,R0      ;SET TAPE DIRECTION OUT
2649 042364 004737 050006      JSR     PC,T17SNPR      ;SETUP T17PK2 FOR WRITE NPR
2650 042370 012704 050330      MOV     @T17PK2,R4      ;GET WRITE SUBSYSTEM COMMAND PACKET
2651 042374 010465 000000      MOV     R4,TSD8(R5)     ;SET THE PACKET ADDRESS TO EXECUTE
2652 042400 004737 016336      JSR     PC,CHKTSSR      ;WAIT FOR SSR TO SET
2653 042404      FORCERROR 1024      ;GOODFORCE ERROR IF FORCER=1
2654 042420 103407      BCS     1054           ;BR IF CARRY SET (GOOD RETURN)
2655 042422 010001      MOV     R0,R1           ;SAVE CONTENTS OF TSSR
2656 042424      NEXT.ERRNO
2657 042424 1024:      ERRODF  ERRNO,T174SSR,PKTSSR ;DEVICE FATAL SSR FAILED TO SET
      042424 104455      TRAP   C#ERDF
      042426 001152      .WORD  618
      042430 046753      .WORD  T174SSR
      042432 012046      .WORD  PKTSSR
2658 042434 005237 002222      INC     FATFLG          ;SET FATAL ERROR FLAG
2659 042440 1054:      CKLOOP                ;LOOP ON ERROR, IF FLAG SET
      042440 104406      TRAP   C#CLP1
2660 ; Do a Write Subsystem WRITE FIFO
2661 042442 004737 050106      JSR     PC,T17CLEXP     ;CLEAR EXPD BUFFER
2662 042446 012701 046464      MOV     @T17WFDATA,R1  ;EXPD WRITE FIFO DATA BUFFER
2663 042452 013702 002310      MOV     COUNT,R2       ;TEST PATTERN SIZE
2664 042456 022737 000001 002314      CMP     #,TSTFLAG      ;INCREMENT PATTERN THIS TIME THRU?
2665 042464 001005      BNE     1154           ;BR IF NO
2666 042466 005000      CLR     R0             ;INCREMENT TEST PATTERN
2667 042470 110021 1104:      MOVB   R0,(R1)        ;STORE INCREMENT TEST BYTE
2668 042472 005200      INC     R0             ;SET NEXT PATTERN
2669 042474 005302      DEC     R2             ;DONE?
2670 042476 003374      BGT     1104           ;BR IF NO
2671 042500 022737 000002 002314 1154:      CMP     #2,TSTFLAG     ;DECREMENT PATTERN THIS TIME THRU?
2672 042506 001006      BNE     1254           ;BR IF NO
2673 042510 012700 000377      MOV     #377,R0        ;DECREMENT TEST PATTERN
2674 042514 110021 1204:      MOVB   R0,(R1)        ;STORE DECREMENT TEST BYTE
2675 042516 005300      DEC     R0             ;SET NEXT PATTERN
2676 042520 005302      DEC     R2             ;DONE?
2677 042522 003374      BGT     1204           ;BR IF NO
2678 042524 022737 000003 002314 1254:      CMP     #3,TSTFLAG     ;TSTBLK PATTERNS THIS TIME THRU?
2679 042532 001005      BNE     1354           ;BR IF NO
2680 042534 012700 002752      MOV     @TSTBLK,R0     ;FLOAT 1'S/0'S ETC. TEST TABLE
2681 042540 112021 1304:      MOVB   (R0),(R1)      ;STORE A TSTBLK BYTE
2682 042542 005302      DEC     R2             ;DONE?
2683 042544 003375      BGT     1304           ;BR IF NO
2684 042546      1354:
2685 042546 013700 002310      MOV     COUNT,R0       ;FIFO BYTE COUNT
2686 042552 012701 046464      MOV     @T17WFDATA,R1  ;FIFO WRITE DATA ADDRESS
2687 042556 004737 050032      JSR     PC,T17WFIF     ;SETUP T17PK2 FOR WRITE FIFO
2688 042562 012704 050330      MOV     @T17PK2,R4     ;GET WRITE SUBSYSTEM COMMAND PACKET
2689 042566 010465 000000      MOV     R4,TSD8(R5)    ;SET THE PACKET ADDRESS TO EXECUTE
  
```

```

2690 042572 004737 016336      JSR      PC,CHKTSSR      ;WAIT FOR SSR TO SET
2691 042576                    FORCERROR      142#      ;BDFORCE ERROR IF FORCER=1
2692 042612 103407            BCS      150#          ;BR IF CARRY SET (GOOD RETURN)
2693 042614 010001            MOV      R0,R1         ;SAVE CONTENTS OF TSSR
2694 042616                    NEXT.ERRNO
2695 042616 142# :          ERRDF  ERRNO,T175SSR,PKTSSR ;DEVICE FATAL SSR FAILED TO SET
                                TRAP      C#ERDF
                                .WORD    619
                                .WORD    T175SSR
                                .WORD    PKTSSR
                                042616 104455
                                042620 001153
                                042622 047016
                                042624 012046
2696 042626 005237 002222      INC      FATFLG        ;SET FATAL ERROR FLAG
2697 042632 150# :          CKLOOP      ;LOOP ON ERROR, IF FLAG SET
                                TRAP      C#CLP1
                                042632 104406
2698
2699 ;          Do a Write Subsystem READ STATUS
2700 042634 004737 047744      JSR      PC,T17SRD     ;SETUP PACKET FOR READ STATUS
2701 042640 012704 050330      MOV      #T17PK2,R4   ;GET WRITE SUBSYSTEM COMMAND PACKET
2702 042644 010465 000000      MOV      R4,TSDB(R5)  ;SET THE PACKET ADDRESS TO EXECUTE
2703 042650 004737 016336      JSR      PC,CHKTSSR   ;WAIT FOR SSR TO SET
2704 042654                    FORCERRUR      157#      ;BDFORCE ERROR IF FORCER=1
2705 042670 103407            BCS      160#          ;BR IF CARRY SET (GOOD RETURN)
2706 042672 010001            MOV      R0,R1         ;SAVE CONTENTS OF TSSR
2707 042674                    NEXT.ERRNO
2708 042674 157# :          ERRDF  ERRNO,T173SSR,PKTSSR ;DEVICE FATAL SSR FAILED TO SET
                                TRAP      C#ERDF
                                .WORD    620
                                .WORD    T173SSR
                                .WORD    PKTSSR
                                042674 104455
                                042676 001154
                                042700 046706
                                042702 012046
2709 042704 005237 002222      INC      FATFLG        ;SET FATAL ERROR FLAG
2710 042710 160# :          CKLOOP      ;LOOP ON ERROR, IF FLAG SET
                                TRAP      C#CLP1
                                042710 104406
2711
2712 ;          Set WORDS 0-7 of expd message buffer = to recv since not testing
2713 042712 004737 050126      JSR      PC,T17SETEXP  ;SET WORDS 0-7 EXPD=RECV
2714 042716 012701 046362      MOV      #T17EXSTA,R1 ;GET EXPECTED READ STATUS
2715 042722 012702 050222      MOV      #T17BFSTA,R2 ;GET RECV READ STATUS
2716 042726 012221            MOV      (R2), (R1)    ;SET EXPD WORD #8 = RECV TEMP
2717 042730 011211            MOV      (R2), (R1)    ;SET EXPD WORD #9 = RECV TEMP
2718 042732 052711 000020      BIS      #S2.INRDY,(R1) ;SET EXP INPUT READY= 1
2719 042736 052711 000040      BIS      #S2.OUTRDY,(R1) ;SET EXP OUTPUT READY= 1
2720 042742 042711 000200      BIC      #S2.DIM,(R1)  ;SET EXP DATA IN MISS = 0
2721 042746 042711 000100      BIC      #S2.ILW,(R1) ;SET EXP LAST WORD (ILW)=0
2722 ;          If Input Ready NOT=1 then Print Error
2723 ;          If Output Ready NOT=1 or Data in Miss NOT=0 Then Print Error
2724 042752 005000            CLR      R0            ;HIGH RECV ADDRESS FOR CKMSG2
2725 042754 012701 050202      MOV      #T17BFR,R1   ;LOW RECV ADDRESS FOR CKMSG2
2726 042760 012702 046342      MOV      #T17EXP,R2   ;EXPD ADDRESS
2727 042764 012703 000024      MOV      #20,,R3      ;NUMBER OF BYTES TO COMPARE
2728 042770 004737 011500      JSR      PC,CKMSG2    ;EXPD EQUAL RECV?
2729 042774                    FORCERROR      162#,NOTSSR ;BDF
2730 043004 103404            BCS      170#          ;BR IF YES
2731 043006                    NEXT.ERRNO
2732 043006 162# :          ERRHRD  ERRNO,T173CMP,MSGSTAT ;REPORT ERROR
                                TRAP      C#ERHRD
                                .WORD    621
                                .WORD    T173CMP
                                .WORD    MSGSTAT
                                043006 104456
                                043010 001155
                                043012 047303
                                043014 012350

```

```

2733 043016          170$: CKLOOP          ;LOOP ON ERROR, IF FLAG SET
      043016 104406          TRAP          C$CLP1
2734
2735          ; Do Write Subsystem READ FIFO
2736 043020 013700 002310  MOV      COUNT,R0          ;SET READ BYTE COUNT
2737 043024 004737 050066  JSR      PC,T17RFIF        ;SETUP T17PK2 FOR READ FIFO
2738 043030 012704 050330  MOV      @T17PK2,R4        ;GET WRITE SUBSYSTEM COMMAND PACKET
2739 043034 010465 000000  MOV      R4,TSDB(R5)      ;SET THE PACKET ADDRESS TO EXECUTE
2740 043040 004737 016336  JSR      PC,CHKTSSR       ;WAIT FOR SSR TO SET
2741 043044          FORCERROR 172$          ;BDFORCE ERROR IF FORCER=1
2742 043060 103407          BCS      180$            ;BR IF CARRY SET (GOOD RETURN)
2743 043062 010001          MOV      R0,R1            ;SAVE CONTENTS OF TSSR
2744 043064          NEXT.ERRNO
2745 043064          172$: ERDF      ERRNO,T176SSR,PKTSSR ;DEVICE FATAL SSR FAILED TO SET
      043064 104455          TRAP          C$ERDF
      043066 001156          .WORD      622
      043070 047062          .WORD      T176SSR
      043072 012046          .WORD      PKTSSR
2746 043074 005237 002222  INC      FATFLG          ;SET FATAL ERROR FLAG
2747 043100          180$: CKLOOP          ;LOOP ON ERROR, IF FLAG SET
      043100 104406          TRAP          C$CLP1
2748
2749          ; If Data read from FIFO NOT= to Data sent Then Print Error
2750 043102 005000          CLR      R0              ;HIGH RECV ADDRESS FOR CKMSG2
2751 043104 012702 046464  MOV      @T17WFDATA,R2    ;GET EXPECTED ADDRESS FOR CKMSG2
2752 043110 012701 050222  MOV      @T17BFSTA,R1     ;GET RECEIVED ADDRESS FOR CKMSG2
2753 043114 013703 002310  MOV      COUNT,R3        ;NUMBER OF BYTES TO COMPARE
2754 043120 004737 011500  JSR      PC,CKMSG2       ;EXPD EQUAL RECV?
2755 043124          FORCERROR 192$,NOTSSR    ;BDF
2756 043134 103406          BCS      200$            ;BR IF YES
2757 043136          NEXT.ERRNO
2758 043136 013701 002310  192$: MOV      COUNT,R1    ;GET BYTE COUNT
2759 043142          ERRHRD  ERRNO,T175CMP,FIFEXP ;REPORT ERROR
      043142 104456          TRAP          C$ERHRD
      043144 001157          .WORD      623
      043146 047452          .WORD      T175CMP
      043150 012170          .WORD      FIFEXP
2760 043152          200$: CKLOOP          ;LOOP ON ERROR, IF FLAG SET
      043152 104406          TRAP          C$CLP1
2761
2762          ; Do Write Subsystem READ STATUS
2763 043154 004737 047744  JSR      PC,T17SRD        ;SETUP PACKET FOR READ STATUS
2764 043160 012704 050330  MOV      @T17PK2,R4        ;GET WRITE SUBSYSTEM COMMAND PACKET
2765 043164 010465 000000  MOV      R4,TSDB(R5)      ;SET THE PACKET ADDRESS TO EXECUTE
2766 043170 004737 016336  JSR      PC,CHKTSSR       ;WAIT FOR SSR TO SET
2767 043174          FORCERROR 212$          ;BDFORCE ERROR IF FORCER=1
2768 043210 103407          BCS      220$            ;BR IF CARRY SET (GOOD RETURN)
2769 043212 010001          MOV      R0,R1            ;SAVE CONTENTS OF TSSR
2770 043214          NEXT.ERRNO
2771 043214          212$: ERDF      ERRNO,T173SSR,PKTSSR ;DEVICE FATAL SSR FAILED TO SET
      043214 104455          TRAP          C$ERDF
      043216 001160          .WORD      624
      043220 046706          .WORD      T173SSR
      043222 012046          .WORD      PKTSSR
2772 043224 005237 002222  INC      FATFLG          ;SET FATAL ERROR FLAG
2773 043230          220$: CKLOOP          ;LOOP ON ERROR, IF FLAG SET
      043230 104406          TRAP          C$CLP1

```

```

2774      ;      Set WORDS 0-7 of expd message buffer = to recv since not testing
2775 043232 004737 050126      JSR      PC,T17SETEXP      ;SET WORDS 0-7 EXPD=RCV
2776 043236 012701 046362      MOV      #T17EXSTA,R1      ;GET EXPECTED READ STATUS
2777 043242 012702 050222      MOV      #T17BFSTA,R2      ;GET RCV READ STATUS
2778 043246 012221              MOV      (R2)+,(R1)+      ;SET EXPD WORD #8 = RCV TEMP
2779 043250 011211              MOV      (R2),(R1)        ;SET EXPD WORD #9 = RCV TEMP
2780 043252 052711 000020      BIS      #S2.INRDY,(R1)    ;SET EXP INPUT READY= 1
2781 043256 042711 000040      BIC      #S2.OTRDY,(R1)    ;SET EXP OUTPUT READY= 0
2782 043262 042711 000200      BIC      #S2.DIM,(R1)      ;SET EXP DATA IN MISS = 0
2783 043266 042711 000100      BIC      #S2.ILW,(R1)      ;SET EXP LAST WORD (ILW)=0
2784      ;
2785      ;      If Input Ready NOT=1 then Print Error
2786 043272 005000              CLR      R0                ;HIGH RCV ADDRESS FOR CKMSG2
2787 043274 012701 050202      MOV      #T17BFR,R1        ;LOW RCV ADDRESS FOR CKMSG2
2788 043300 012702 046342      MOV      #T17EXP,R2        ;EXPD ADDRESS
2789 043304 012703 000024      MOV      #20.,R3           ;NUMBER OF BYTES TO COMPARE
2790 043310 004737 011500      JSR      PC,CKMSG2         ;EXPD EQUAL RCV?
2791 043314              FORCERROR      232$,NOTSSR    ;BBD
2792 043324 103404              BCS      240$             ;BR IF YES
2793 043326              NEXT.ERRNO
2794 043326 232$:      ERRHRD  ERRNO,T174CMP,MSGSTAT ;REPORT ERROR
                TRAP      C#ERRRD
                .WORD    625
                .WORD    T174CMP
                .WORD    MSGSTAT
2795 043336 240$:      CKLOOP              ;LOOP ON ERROR, IF FLAG SET
                TRAP      C#CLP1
2796 043340              FORCEEXIT      250$      ;BBD
2797 043350 005237 002310      INC      COUNT            ;GET NEXT BYTE COUNT
2798 043354 023727 002310 000077      CMP      COUNT,#77        ;DONE 0 TO 77
2799 043362 101002              BHI      250$             ;BR IF YES
2800 043364 000137 042360      JMP      100$             ;DO ANOTHER BYTE COUNT
2801 043370 005237 002314 250$:      INC      TSTFLAG          ;GET NEXT TEST PATTERN CODE
2802 043374 023727 002314 000003      CMP      TSTFLAG,#3       ;DONE INC,DEC,TSTBLK PATTERNS?
2803 043402 101002              BHI      255$             ;BR IF YES
2804 043404 000137 042352      JMP      95$              ;DO ANOTHER TEST PATTERN
2805 043410 255$:      ENDSUB
                ;////////// END SUBTEST //////////
                L10061:
                TRAP      C#ESUB
2807
2808 043412 005737 002222      TST      FATFLG           ;ANY FATAL ERRORS ?
2809 043416 001402              BEQ      260$             ;BRANCH IF NOT
2810 043420 004737 017202      JSR      PC,CKDROP        ;TRY TO DROP THE UNIT
2811 043424 260$:

```

.SBTTL TEST 6: SUBTEST 4: FIFO Verify ILW Status

```

2812
2813
2814
2815      ;**
2816      ; TEST 6: SUBTEST 4:
2817
2818      ; SUBTEST DESCRIPTION:
2819
2820      ;
2821      ; This subtest verifies that reading the FIFO when it is
2822      ; empty causes the Last Word (ILW) status to assert.
2823

```

```

2824      ;
2825      ; TEST STEPS:
2826      ;
2827      ; BEGIN
2828      ;       Write to TSSR to soft initialize
2829      ;       Do Write Subsystem READ FIFO with byte count equal to 1
2830      ;       Do a Write Subsystem READ STATUS
2831      ;       If Input Ready NOT=1 Then Print Error
2832      ;       If Output Ready NOT=0 Then Print Error
2833      ;       If Data In Miss NOT=0 Then Print Error
2834      ;       If Last Word (ILW) NOT=1 Then Print Error
2835      ;       END
2836      ;
2837      043424      BGNSUB      ;//////////////// BEGIN SUBTEST //////////////////
          043424      T6.4:      TRAP      C#BSUB
          043424      104402
2838
2839      ;       Write to TSSR register to soft initialize the controller
2840      043426      5%:
2841      043426      004737      015774      JSR      PC,SOFINIT      ;WRITE TO TSSR TO SOFT INITIALIZE
2842      043432      103405      BCS      10%      ;BR IF SOFT INIT OKAY
2843      043434      010001      MOV      R0,R1      ;SAVE CONTENTS OF TSSR
2844      043436      104455      ERDF     ERRNO,SFIERR,SFIMSG ;DEVICE FATAL DURING INIT
          043436      104455      TRAP      C#ERDF
          043440      001161      .WORD    625
          043442      003652      .WORD    SFIERR
          043444      012034      .WORD    SFIMSG
2845      ;       Do a WRITE CHARACTERISTICS to setup a message buffer
2846      043446      005037      002222      10%:    CLR      FATFLG      ;CLEAR FATAL ERROR FLAG
2847      043452      012704      050160      MOV      @T17PACKET,R4 ;GET THE ADDRESS OF COMMAND PACKET
2848      043456      004737      010662      JSR      PC,WRTCHR      ;DO WRITE CHARACTERISTICS COMMAND
2849      043462      103407      FORCERROR 42%      ;BDFORCE ERROR IF FORCER=1
2850      043476      103407      BCS      50%      ;BR IF CARRY SET (GOOD RETURN)
2851      043500      010001      MOV      R0,R1      ;SAVE CONTENTS OF TSSR
2852      043502      NEXT.ERRNO
2853      043502      42%:    ERDF     ERRNO,T17SSR,PKTSSR ;DEVICE FATAL SSR FAILED TO SET
          043502      104455      TRAP      C#ERDF
          043504      001162      .WORD    626
          043506      046605      .WORD    T17SSR
          043510      012046      .WORD    PKTSSR
2854      043512      005237      002222      INC      FATFLG      ;SET FATAL ERROR FLAG
2855      043516      50%:    CKLOOP      ;LOOP ON ERROR, IF FLAG SET
          043516      104406      TRAP      C#CLP1
2856
2857      ;       Do Write Subsystem READ FIFO with byte count equal to 1
2858      043520      012700      000001      MOV      #1,R0      ;SET READ BYTE COUNT
2859      043524      004737      050066      JSR      PC,T17RFIF      ;SETUP T17PK2 FOR READ FIFO
2860      043530      012704      050330      MOV      @T17PK2,R4 ;GET WRITE SUBSYSTEM COMMAND PACKET
2861      043534      010465      000000      MOV      R4,TSDB(R5) ;SET THE PACKET ADDRESS TO EXECUTE
2862      043540      004737      016336      JSR      PC,CHKTSSR      ;WAIT FOR SSR TO SET
2863      043544      103407      FORCERROR 142%      ;BDFORCE ERROR IF FORCER=1
2864      043560      103407      BCS      150%      ;BR IF CARRY SET (GOOD RETURN)
2865      043562      010001      MOV      R0,R1      ;SAVE CONTENTS OF TSSR
2866      043564      NEXT.ERRNO
2867      043564      142%:    ERDF     ERRNO,T176SSR,PKTSSR ;DEVICE FATAL SSR FAILED TO SET
          043564      104455      TRAP      C#ERDF
          043566      001163      .WORD    627

```

TSV5 HARDWARE TESTS MACRO M1113 14-JUN-84 15:55  
 TEST 6: SUBTEST 4: FIFO VERIFY ILW STATUS

SEQ 0164

```

043570 047062 .WORD T176SSR
043572 012046 .WORD PKTSSR
2868 043574 005237 002222 INC FATFLG ;SET FATAL ERROR FLAG
2869 043600 104406 150$: CKLOOP ;LOOP ON ERROR, IF FLAG SET
; TRAP C$CLP1
2870
2871 ; Do a Write Subsystem READ STATUS
2872 043602 004737 047744 JSR PC,T17SRD ;SETUP PACKET FOR READ STATUS
2873 043606 012704 050330 MOV #T17PK2,R4 ;GET WRITE SUBSYSTEM COMMAND PACKET
2874 043612 010465 000000 MOV R4,TSDB(R5) ;SET THE PACKET ADDRESS TO EXECUTE
2875 043616 004737 016336 JSR PC,CHKTSSR ;WAIT FOR SSR TO SET
2876 043622 FORCERROR 162$ ;BDDFORCE ERROR IF FORCER=1
2877 043636 103407 BCS 170$ ;BR IF CARRY SET (GOOD RETURN)
2878 043640 010001 MOV R0,R1 ;SAVE CONTENTS OF TSSR
2879 043642 NEXT.ERRNO
2880 043642 162$: ERRDF ERRNO,T173SSR,PKTSSR ;DEVICE FATAL SSR FAILED TO SET
; TRAP C$ERDF
043642 104455 .WORD 628
043644 001164 .WORD T173SSR
043646 046706 .WORD PKTSSR
043650 012046
2881 043652 005237 002222 INC FATFLG ;SET FATAL ERROR FLAG
2882 043656 104406 170$: CKLOOP ;LOOP ON ERROR, IF FLAG SET
; TRAP C$CLP1
2883 ; Set WORDS 0-7 of expd message buffer = to recv since not testing
2884 043660 004737 050126 JSR PC,T17SETEXP ;SET WORDS 0-7 EXPD=RECV
2885 043664 012701 046362 MOV #T17EXSTA,R1 ;GET EXPECTED READ STATUS
2886 043670 012702 050222 MOV #T17BFSTA,R2 ;GET RECV READ STATUS
2887 043674 012221 MOV (R2)+,(R1)+ ;SET EXPD WORD #8 = RECV TEMP
2888 043676 011211 MOV (R2),(R1) ;SET EXPD WORD #9 = RECV TEMP
2889 043700 052711 000020 BIS #S2.INRDY,(R1) ;SET EXP INPUT READY= 1
2890 043704 042711 000040 BIC #S2.OUTRDY,(R1) ;SET EXP OUTPUT READY= 0
2891 043710 042711 000200 BIC #S2.DIM,(R1) ;SET EXP DATA IN MISS = 0
2892 043714 052711 000100 BIS #S2.ILW,(R1) ;SET EXP LAST WORD (ILW)=1
2893 ; If Input Ready NOT=1 then Print Error
2894 ; If Output Ready NOT=0 or Data in Miss NOT=0 Then Print Error
2895 ; If Last Word (ILW) NOT=1 Then Print Error
2896 043720 005000 CLR R0 ;HIGH RECV ADDRESS FOR CKMSG2
2897 043722 012701 050202 MOV #T17BFR,R1 ;LOW RECV ADDRESS FOR CKMSG2
2898 043726 012702 046342 MOV #T17EXP,R2 ;EXPD ADDRESS
2899 043732 012703 000024 MOV #20.,R3 ;NUMBER OF BYTES TO COMPARE
2900 043736 004737 011500 JSR PC,CKMSG2 ;EXPD EQUAL RECV?
2901 043742 FORCERROR 172$,NOTSSR ;BDD
2902 043752 103404 BCS 180$ ;BR IF YES
2903 043754 NEXT.ERRNO
2904 043754 172$: ERRHRD ERRNO,T176CMP,MSGSTAT ;REPORT ERROR
; TRAP C$ERHRD
043754 104456 .WORD 629
043756 001165 .WORD T176CMP
043760 047526 .WORD MSGSTAT
043762 012350
2905 043764 104406 180$: CKLOOP ;LOOP ON ERROR, IF FLAG SET
; TRAP C$CLP1
2906
2907 043766 ENDSUB ;////////// END SUBTEST ////////////
043766 L10062:
043766 104403 TRAP C$ESUB
2908
2909 043770 005737 002222 TST FATFLG ;ANY FATAL ERRORS ?

```

```

2910 043774 001402          BEQ      260$          ;BRANCH IF NOT
2911 043776 004737 017202    JSP      PC,CKDROP          ;TRY TO DROP THE UNIT
2912 044002          260$:
2913
2914
2915          .SBTTL TEST 6: SUBTEST 5: FIFO Verify Input Ready
2916
2917          ;**
2918          ; TEST 6: SUBTEST 5:
2919          ;
2920          ; SUBTEST DESCRIPTION:
2921          ;
2922          ; This subtest verifies that writing 64. bytes into the FIFO
2923          ; without reading any out causes the Input Ready status to
2924          ; negate. The Subtest then verifies that writing a 65th byte
2925          ; into the FIFO causes the Data In Miss status to assert.
2926          ; Next it is verified that the original 64 bytes can be read
2927          ; out correctly and that the data has not been corrupted.
2928          ;
2929          ; TEST STEPS:
2930          ;
2931          ; BEGIN
2932          ; Write to TSSR to soft initialize
2933          ; Do a WRITE CHARACTERISTICS to setup a message buffer
2934          ; Do a Write Subsystem WRITE NPR to set tape direction out
2935          ; Do a Write Subsystem WRITE FIFO 64. bytes incrementing pattern
2936          ; Do a Write Subsystem READ STATUS
2937          ; If Input Ready NOT=0 Then Print Error
2938          ; If Output Ready NOT=1 Then Print Error
2939          ; If Data In Miss NOT=0 Then Print Error
2940          ; Do a Write Subsystem WRITE FIFO 1 byte for a total of 65. written
2941          ; Do a Write Subsystem READ STATUS
2942          ; If Input Ready NOT=0 Then Print Error
2943          ; If Output Ready NOT=1 Then Print Error
2944          ; If Data In Miss NOT=1 Then Print Error
2945          ; Do Write Subsystem READ FIFO
2946          ; If Data read from FIFO NOT= to Data sent Then Print Error
2947          ; Do a Write Subsystem READ STATUS
2948          ; If Input Ready NOT=1 Then Print Error
2949          ; If Output Ready NOT=0 Then Print Error
2950          ; If Data In Miss NOT=1 Then Print Error
2951          ; END
2952          ;---
2953 044002          BGNSUB          ;////////// BEGIN SUBTEST ////////////
          044002          T6.5:
          044002 104402          TRAP      C$BSUB
2954
2955          ; Write to TSSR register to soft initialize the controller
2956 044004          5$:
2957 044004 004737 015774    JSR      PC,SOFINIT          ;WRITE TO TSSR TO SOFT INITIALIZE
2958 044010 103405          BCS      10$          ;BR IF SOFT INIT OKAY
2959 044012 010001          MOV      R0,R1          ;SAVE CONTENTS OF TSSR
2960 044014          ERROF      ERRNO,SFIERR,SFIMSG          ;DEVICE FATAL DURING INIT
          044014 104455          TRAP      C$ERDF
          044016 001165          .WORD    629
          044020 003652          .WORD    SFIERR
          044022 012034          .WORD    SFIMSG
  
```

```

2961      ; Do a WRITE CHARACTERISTICS to setup a message buffer
2962 044024 005037 002222 10$: CLR FATFLG ;CLEAR FATAL ERROR FLAG
2963 044030 012704 050160 MOV #T17PACKET,R4 ;GET THE ADDRESS OF COMMAND PACKET
2964 044034 004737 010662 JSR PC,WRTCHR ;DO WRITE CHARACTERISTICS COMMAND
2965 044040 FORCERROR 42$ ;BDFORCE ERROR IF FORCER=1
2966 044054 103407 BCS 50$ ;BR IF CARRY SET (GOOD RETURN)
2967 044056 010001 MOV R0,R1 ;SAVE CONTENTS OF TSSR
2968 044060 NEXT.ERRNO
2969 044060 42$: ERRDF ERRNO,T17SSR,PKTSSR ;DEVICE FATAL SSR FAILED TO SET
      TRAP C$ERDF
      .WORD 630
      .WORD T17SSR
      .WORD PKTSSR
2970 044070 005237 002222 INC FATFLG ;SET FATAL ERROR FLAG
2971 044074 50$: CKLOOP ;LOOP ON ERROR, IF FLAG SET
      TRAP C$CLP1
2972
2973      ; Do a Write Subsystem WRITE NPR to set tape direction out
2974 044076 012700 000100 100$: MOV #NP.OUT,R0 ;SET TAPE DIRECTION OUT
2975 044102 004737 050006 JSR PC,T17SNPR ;SETUP T17PK2 FOR WRITE NPR
2976 044106 012704 050330 MOV #T17PK2,R4 ;GET WRITE SUBSYSTEM COMMAND PACKET
2977 044112 010465 000000 MOV R4,TSDB(R5) ;SET THE PACKET ADDRESS TO EXECUTE
2978 044116 004737 016336 JSR PC,CHKTSSR ;WAIT FOR SSR TO SET
2979 044122 FORCERROR 102$ ;BDFORCE ERROR IF FORCER=1
2980 044136 103407 BCS 105$ ;BR IF CARRY SET (GOOD RETURN)
2981 044140 010001 MOV R0,R1 ;SAVE CONTENTS OF TSSR
2982 044142 NEXT.ERRNO
2983 044142 102$: ERRDF ERRNO,T174SSR,PKTSSR ;DEVICE FATAL SSR FAILED TO SET
      TRAP C$ERDF
      .WORD 631
      .WORD T174SSR
      .WORD PKTSSR
2984 044152 005237 002222 INC FATFLG ;SET FATAL ERROR FLAG
2985 044156 105$: CKLOOP ;LOOP ON ERROR, IF FLAG SET
      TRAP C$CLP1
2986
2987      ; Do a Write Subsystem WRITE FIFO 64. bytes incrementing pattern
2988 044160 012737 000100 002310 MOV #64.,COUNT ;WRITE 64 BYTES
2989 044166 012701 046464 MOV #T17WFDATA,R1 ;EXPD WRITE FIFO DATA BUFFER
2990 044172 012702 000100 MOV #64.,R2 ;TEST PATTERN SIZE
2991 044176 005000 CLR R0 ;INCREMENT TEST PATTERN
2992 044200 110021 110$: MOV#B R0,(R1)+ ;STORE INCREMENT TEST BYTE
2993 044202 005200 INC R0 ;SET NEXT PATTERN
2994 044204 005302 DEC R2 ;DONE?
2995 044206 003374 BGT 110$ ;BR IF NO
2996 044210 013700 002310 MOV COUNT,R0 ;FIFO BYTE COUNT
2997 044214 012701 046464 MOV #T17WFDATA,R1 ;FIFO WRITE DATA ADDRESS
2998 044220 004737 050032 JSR PC,T17WFIF ;SETUP T17PK2 FOR WRITE FIFO
2999 044224 012704 050330 MOV #T17PK2,R4 ;GET WRITE SUBSYSTEM COMMAND PACKET
3000 044230 010465 000000 MOV R4,TSDB(R5) ;SET THE PACKET ADDRESS TO EXECUTE
3001 044234 004737 016336 JSR PC,CHKTSSR ;WAIT FOR SSR TO SET
3002 044240 FORCERROR 142$ ;BDFORCE ERROR IF FORCER=1
3003 044254 103407 BCS 150$ ;BR IF CARRY SET (GOOD RETURN)
3004 044256 010001 MOV R0,R1 ;SAVE CONTENTS OF TSSR
3005 044260 NEXT.ERRNO
3006 044260 142$: ERRDF ERRNO,T175SSR,PKTSSR ;DEVICE FATAL SSR FAILED TO SET
      TRAP C$ERDF
  
```



```

044262 001170 .WORD 632
044264 047016 .WORD T175SSR
044266 012046 .WORD PKTSSR
3007 044270 005237 002222 INC FATFLG ;SET FATAL ERROR FLAG
3008 044274 104406 150$: CKLOOP ;LOOP ON ERROR, IF FLAG SET
                                TRAP C$CLP1
3009
3010 ; Do a Write Subsystem READ STATUS
3011 ; If Input Ready NOT=0 Then Print Error
3012 ; If Output Ready NOT=1 Then Print Error
3013 ; If Data In Miss NOT=0 Then Print Error
3014 044276 004737 047744 JSR PC,T17SRD ;SETUP PACKET FOR READ STATUS
3015 044302 012704 050330 MOV @T17PK2,R4 ;GET WRITE SUBSYSTEM COMMAND PACKET
3016 044306 010465 000000 MOV R4,TSDB(R5) ;SET THE PACKET ADDRESS TO EXECUTE
3017 044312 004737 016336 JSR PC,CHKTSSR ;WAIT FOR SSR TO SET
3018 044316 FORCERROR 157$ ;BDFORCE ERROR IF FORCER=1
3019 044332 103407 BCS 160$ ;BR IF CARRY SET (GOOD RETURN)
3020 044334 0:0001 MOV R0,R1 ;SAVE CONTENTS OF TSSR
3021 044336 NEXT.ERRNO
3022 044336 104455 157$: ERRDF ERRNO,T173SSR,PKTSSR ;DEVICE FATAL SSR FAILED TO SET
                                TRAP C$ERDF
                                .WORD 633
                                .WORD T173SSR
                                .WORD PKTSSR
3023 044346 005237 002222 INC FATFLG ;SET FATAL ERROR FLAG
3024 044352 104406 160$: CKLOOP ;LOOP ON ERROR, IF FLAG SET
                                TRAP C$CLP1
3025 ; Set WORDS 0-7 of expd message buffer = to recv since not testing
3026 044354 004737 050126 JSR PC,T17SETEXP ;SET WORDS 0-7 EXPD=RECV
3027 044360 012701 046362 MOV @T17EXSTA,R1 ;GET EXPECTED READ STATUS
3028 044364 012702 050222 MOV @T17BFSTA,R2 ;GET RECV READ STATUS
3029 044370 012221 MOV (R2)+,(R1)+ ;SET EXPD WORD #8 = RECV TEMP
3030 044372 011211 MOV (R2),(R1) ;SET EXPD WORD #9 = RECV TEMP
3031 044374 042711 000020 BIC #S2.INRDY,(R1) ;SET EXP INPUT READY= 0
3032 044400 052711 000040 BIS #S2.OUTRDY,(R1) ;SET EXP OUTPUT READY= 1
3033 044404 042711 000200 BIC #S2.DIM,(R1) ;SET EXP DATA IN MISS = 0
3034 044410 005000 CLR R0 ;HIGH RECV ADDRESS FOR CKMSG2
3035 044412 012701 050202 MOV @T17BFR,R1 ;LOW RECV ADDRESS FOR CKMSG2
3036 044416 012702 046342 MOV @T17EXP,R2 ;EXPD ADDRESS
3037 044422 012703 000024 MOV @20.,R3 ;NUMBER OF BYTES TO COMPARE
3038 044426 004737 011500 JSR PC,CKMSG2 ;EXPD EQUAL RECV?
3039 044432 FORCERROR 162$,NOTSSR ;BDF
3040 044442 103404 BCS 170$ ;BR IF YES
3041 044444 NEXT.ERRNO
3042 044444 104456 162$: ERRHRD ERRNO,T173CMP,MSGSTAT ;REPORT ERROR
                                TRAP C$ERHRD
                                .WORD 634
                                .WORD T173CMP
                                .WORD MSGSTAT
3043 044454 012350 170$: CKLOOP ;LOOP ON ERROR, IF FLAG SET
                                TRAP C$CLP1
3044
3045
3046 ; Do a Write Subsystem WRITE FIFO 1 byte for a total of 65. written
3047 044456 012700 000001 MOV @1,R0 ;FIFO BYTE COUNT
3048 044462 012701 046464 MOV @T17WFDATA,R1 ;FIFO WRITE DATA ADDRESS
3049 044466 004737 050032 JSR PC,T17WFIF ;SETUP T17PK2 FOR WRITE FIFO

```

```

3050 044472 012704 050330      MOV      #T17PK2,R4      ;GET WRITE SUBSYSTEM COMMAND PACKET
3051 044476 010465 00000C      MOV      R4,TSDB(R5)    ;SET THE PACKET ADDRESS TO EXECUTE
3052 044502 004737 016336      JSR      PC,CHKTSSR     ;WAIT FOR SSR TO SET
3053 044506                FORCERROR 172$         ;$$$FORCE ERROR IF FORCER=1
3054 044522 103407                BCS      180$         ;BR IF CARRY SET (GOOD RETURN)
3055 044524 010001                MOV      R0,R1         ;SAVE CONTENTS OF TSSR
3056 044526                NEXT.ERRNO
3057 044526 172$:      ERRDF  ERRNO,T175SSR,PKTSSR ;DEVICE FATAL SSR FAILED TO SET
                                TRAP      C$ERDF
                                .WORD    635
                                .WORD    T175SSR
                                .WORD    PKTSSR
3058 044536 005237 002222      INC      FATFLG        ;SET FATAL ERROR FLAG
3059 044542 180$:      CKLOOP                    ;LOOP ON ERROR, IF FLAG SET
                                TRAP      C$CLP1
3060
3061                ;      Do a Write Subsystem READ STATUS
3062                ;      If Input Ready NOT=0 Then Print Error
3063                ;      If Output Ready NOT=1 Then Print Error
3064                ;      If Data In Miss NOT=1 Then Print Error
3065 044544 004737 047744      JSR      PC,T17SRD     ;SETUP PACKET FOR READ STATUS
3066 044550 012704 050330      MOV      #T17PK2,R4    ;GET WRITE SUBSYSTEM COMMAND PACKET
3067 044554 010465 000000      MOV      R4,TSDB(R5)  ;SET THE PACKET ADDRESS TO EXECUTE
3068 044550 004737 016336      JSR      PC,CHKTSSR     ;WAIT FOR SSR TO SET
3069 044564                FORCERROR 187$         ;$$$FORCE ERROR IF FORCER=1
3070 044600 103407                BCS      190$         ;BR IF CARRY SET (GOOD RETURN)
3071 044602 010001                MOV      R0,R1         ;SAVE CONTENTS OF TSSR
3072 044604                NEXT.ERRNO
3073 044604 187$:      ERRDF  ERRNO,T173SSR,PKTSSR ;DEVICE FATAL SSR FAILED TO SET
                                TRAP      C$ERDF
                                .WORD    636
                                .WORD    T173SSR
                                .WORD    PKTSSR
3074 044614 005237 002222      INC      FATFLG        ;SET FATAL ERROR FLAG
3075 044620 190$:      CKLOOP                    ;LOOP ON ERROR, IF FLAG SET
                                TRAP      C$CLP1
3076                ;      Set WORDS 0-7 of expd message buffer = to recv since not testing
3077 044622 004737 050126      JSR      PC,T17SETEXP  ;SET WORDS 0-7 EXPD=RCV
3078 044626 012701 046362      MOV      #T17EXSTA,R1 ;GET EXPECTED READ STATUS
3079 044632 012702 050222      MOV      #T17BFSTA,R2 ;GET RECV READ STATUS
3080 044635 012221                MOV      (R2)+,(R1)+   ;SET EXPD WORD #8 = RECV TEMP
3081 044640 011211                MOV      (R2),(R1)     ;SET EXPD WORD #9 = RECV TEMP
3082 044642 042711 000020      BIC      #S2.INRDY,(R1) ;SET EXP INPUT READY= 0
3083 044646 052711 000040      BIS      #S2.OTRDY,(R1) ;SET EXP OUTPUT READY= 1
3084 044652 052711 000200      BIS      #S2.DIM,(R1) ;SET EXP DATA IN MISS = 1
3085 044656 005000                CLP      R0            ;HIGH RECV ADDRESS FOR CKMSG2
3086 044660 012701 050202      MOV      #T17BFR,R1   ;LOW RECV ADDRESS FOR CKMSG2
3087 044664 012702 046342      MOV      #T17EXP,R2   ;EXPD ADDRESS
3088 044670 012703 000024      MOV      #20.,R3      ;NUMBER OF BYTES TO COMPARE
3089 044674 004737 011500      JSR      PC,CKMSG2    ;EXPD EQUAL RECV?
3090 044700                FORCERROR 192$,NOTSSR ;$$$
3091 044710 103404                BCS      200$         ;BR IF YES
3092 044712                NEXT.ERRNO
3093 044712 192$:      ERRHRD ERRNO,T173CMP,MSGSTAT ;REPORT ERROR
                                TRAP      C$ERHRD
                                .WORD    537
                                .WORD    T173CMP
044712 104456
044714 001175
044716 047303

```

```

044720 012350
3094 044722 200$: CKLOOP ;LOOP ON ERROR, IF FLAG SET .WORD MSGSTAT
044722 104406 TRAP C$CLP1
3095 ; Do Write Subsystem READ FIFO
3096 044724 013700 002310 MOV COUNT,R0 ;SET READ BYTE COUNT
3097 044730 004737 050066 JSR PC,T17RFIF ;SETUP T17PK2 FOR READ FIFO
3098 044734 012704 050330 MOV #T17PK2,R4 ;GET WRITE SUBSYSTEM COMMAND PACKET
3099 044740 010465 000000 MOV R4,TSDB(R5) ;SET THE PACKET ADDRESS TO EXECUTE
3100 044744 004737 016336 JSR PC,CHKTSSR ;WAIT FOR SSR TO SET
3101 044750 FORCERROR 212$ ;BDDFORCE ERROR IF FORCER=1
3102 044764 103407 BCS 220$ ;BR IF CARRY SET (GOOD RETURN)
3103 044766 010001 MOV R0,R1 ;SAVE CONTENTS OF TSSR
3104 044770 NEXT.ERRNO
3105 044770 212$: ERRDF ERRNO,T176SSR,PKTSSR ;DEVICE FATAL SSR FAILED TO SET
044770 104455 TRAP C$ERDF
044772 001176 .WORD 638
044774 047062 .WORD T176SSR
044776 012046 .WORD PKTSSR
3106 045000 005237 002222 INC FATFLG ;SET FATAL ERROR FLAG
3107 045004 220$: CKLOOP ;LOOP ON ERROR, IF FLAG SET .WORD MSGSTAT
045004 104406 TRAP C$CLP1
3108 ;
3109 ; If Data read from FIFO NOT= to Data sent Then Print Error
3110 045006 005000 CLR R0 ;HIGH RECV ADDRESS FOR CKMSG2
3111 045010 012702 046464 MOV #T17WFDATA,R2 ;GET EXPECTED ADDRESS FOR CKMSG2
3112 045014 012701 050222 MOV #T17BFSTA,R1 ;GET RECEIVED ADDRESS FOR CKMSG2
3113 045020 013703 002310 MOV COUNT,R3 ;NUMBER OF BYTES TO COMPARE
3114 045024 004737 011500 JSR PC,CKMSG2 ;EXPD EQUAL RECV?
3115 045030 FORCERROR 232$,NOTSSR ;BDD
3116 045040 103406 BCS 240$ ;BR IF YES
3117 045042 NEXT.ERRNO
3118 045042 013701 002310 232$: MOV COUNT,R1 ;GET BYTE COUNT
3119 045046 ERRHRD ERRNO,T175CMP,FIFEXP ;REPORT ERROR
045046 104456 TRAP C$ERHRD
045050 001177 .WORD 639
045052 047452 .WORD T175CMP
045054 012170 .WORD FIFEXP
3120 045056 240$: CKLOOP ;LOOP ON ERROR, IF FLAG SET .WORD MSGSTAT
045056 104406 TRAP C$CLP1
3121 ;
3122 ; Do a Write Subsystem READ STATUS
3123 ; If Input Ready NOT=1 Then Print Error
3124 ; If Output Ready NOT=0 Then Print Error
3125 ; If Data In Miss NOT=1 Then Print Error
3126 045060 004737 047744 JSR PC,T17SRD ;SETUP PACKET FOR READ STATUS
3127 045064 012704 050330 MOV #T17PK2,R4 ;GET WRITE SUBSYSTEM COMMAND PACKET
3128 045070 010465 000000 MOV R4,TSDB(R5) ;SET THE PACKET ADDRESS TO EXECUTE
3129 045074 004737 016336 JSR PC,CHKTSSR ;WAIT FOR SSR TO SET
3130 045100 FORCERROR 252$ ;BDDFORCE ERROR IF FORCER=1
3131 045114 103407 BCS 260$ ;BR IF CARRY SET (GOOD RETURN)
3132 045116 010001 MOV R0,R1 ;SAVE CONTENTS OF TSSR
3133 045120 NEXT.ERRNO
3134 045120 252$: ERRDF ERRNO,T173SSR,PKTSSR ;DEVICE FATAL SSR FAILED TO SET
045120 104455 TRAP C$ERDF
045122 001200 .WORD 640
045124 046706 .WORD T173SSR
045126 012046 .WORD PKTSSR

```

```

3135 045130 005237 002222      INC      FATFLG      ;SET FATAL ERROR FLAG
3136 045134 2601:  CKLOOP      ;LOOP ON ERROR, IF FLAG SET
                                TRAP      C1CLP1
3137      :      Set WORDS 0-7 of expd message buffer = to recv since not testing
3138 045136 004737 050126      JSR      PC,T17SETEXP ;SET WORDS 0-7 EXPD=RECV
3139 045142 012701 046362      MOV      @T17EXSTA,R1 ;GET EXPECTED READ STATUS
3140 045146 012702 050222      MOV      @T17BFSTA,R2 ;GET RECV READ STATUS
3141 045152 012221      MOV      (R2),.(R1). ;SET EXPD WORD 08 = RECV TEMP
3142 045154 011211      MOV      (R2),(R1) ;SET EXPD WORD 09 = RECV TEMP
3143 045156 052711 000020      BIS      @S2.INRDY,(R1) ;SET EXP INPUT READY= 1
3144 045162 042711 000040      BIC      @S2.OUTRDY,(R1) ;SET EXP OUTPUT READY= 0
3145 045166 052711 000200      BIS      @S2.DIM,(R1) ;SET EXP DATA IN MISS = 1
3146 045172 105000      CLR      R0 ;HIGH RECV ADDRESS FOR CKMSG2
3147 045174 012701 050202      MOV      @T17BFR,R1 ;LOW RECV ADDRESS FOR CKMSG2
3148 045200 012702 046342      MOV      @T17EXP,R2 ;EXPD ADDRESS
3149 045204 012703 000024      MOV      @20.,R3 ;NUMBER OF BYTES TO COMPARE
3150 045210 004737 011500      JSR      PC,CKMSG2 ;EXPD EQUAL RECV?
3151 045214      FORCERROR 2721,NOTSSR ;BEO
3152 045224 103404      BCS      2801 ;BR IF YES
3153 045226      NEXT,ERRNO
3154 045226 2721:  ERRNO  ERRNO,T174CMP,MSGSTAT ;REPORT ERROR
                                TRAP      C1ERRNO
                                .WORD    641
                                .WORD    T174CMP
                                .WORD    MSGSTAT
3155 045236 2801:  CKLOOP      ;LOOP ON ERROR, IF FLAG SET
                                TRAP      C1LLP1
3156      :
3157 045240      ENDSUB      ;////////// END SUBTEST ///////////
                                L10063:
                                TRAP      C1ESUB
3158 045242 005737 002222      TST      FATFLG      ;ANY FATAL ERRORS ?
3159 045246 001402      BEQ      3001 ;BRANCH IF NOT
3160 045250 004737 017202      JSR      PC,CKDROP ;TRY TO DROP THE UNIT
3161 045254 3001:
3162
3163
3164
3165
3166      .SBTTL TEST 6: SUBTEST 6: FIFO Verify Reset FIFO Test
3167
3168
3169 ;**
3170 ; TEST 6: SUBTEST 6:
3171 ; SUBTEST DESCRIPTION:
3172 ;
3173 ; This subtest verifies that the Reset FIFO function within
3174 ; the Write Miscellaneous Control 1 function initializes
3175 ; the FIFO to correct initial status. The following steps
3176 ; are performed:
3177 ; 1. Reset an already initialized FIFO and check for
3178 ; proper status.
3179 ; 2. Write a varying number of bytes (1-65.) into the
3180 ; FIFO and verify that after each block of bytes is
3181 ; written the FIFO can be reset to it's initial
3182 ; state.
3183 ;

```

```

3184 ; TEST STEPS:
3185 ;
3186 ; BEGIN
3187 ;   Write to TSSR to soft initialize
3188 ;   Do a WRITE CHARACTERISTICS to setup a message buffer
3189 ;   Do a Write Subsystem Write Misc to Reset FIFO
3190 ;   Do a Write Subsystem READ STATUS
3191 ;   If all Tape Status 2 (ICER,IFMK,IMER) Flip-Flop
3192 ;     signals NOT=0 Then Print Error
3193 ;   Do a Write Subsystem WRITE NPR to set tape direction out
3194 ;
3195 ; REPEAT FOR BYTE COUNT 1 TO 65.
3196 ; BEGIN
3197 ;   Do a Write Subsystem WRITE FIFO with the current byte count
3198 ;   Do a Write Subsystem Write Misc to Reset FIFO
3199 ;   Do a Write Subsystem READ STATUS
3200 ;   If all Tape Status 2 (ICER,IFMK,IMER) Flip-Flop
3201 ;     signals NOT=0 Then Print Error
3202 ;
3203 ; END
3204 045254          BGNSUB                ;////////// BEGIN SUBTEST ////////////
      045254          ;                                     T6.6:
      045254 104402          TRAP          C18SUB
3205 ;
3206 ;   Write to TSSR register to soft initialize the controller
3207 045256          58:
3208 045256 004737 015774    JSR          PC,SOFINIT          ;WRITE TO TSSR TO SOFT INITIALIZE
3209 045262 103405          BCS          108          ;BR IF SOFT INIT OKAY
3210 045264 010001          MOV          R0,R1          ;SAVE CONTENTS OF TSSR
3211 045266          ERRDF          ERRNO,SFIERR,SFIMSG ;DEVICE FATAL DURING INIT
      045266 104455          ;                                     TRAP          C18ERDF
      045270 001201          ;                                     .WORD          641
      045272 003652          ;                                     .WORD          SFIERR
      045274 012034          ;                                     .WORD          SFIMSG
3212 ;   Do a WRITE CHARACTERISTICS to setup a message buffer
3213 045276 005037 002222    108:    CLR          FATFLG          ;CLEAR FATAL ERROR FLAG
3214 045302 012704 050160    MOV          @T17PACKET,R4 ;GET THE ADDRESS OF COMMAND PACKET
3215 045306 004737 010662    JSR          PC,WRTCHR          ;DO WRITE CHARACTERISTICS COMMAND
3216 045312          FORCERROR          428          ;BDDFORCE ERROR IF FORCER=1
3217 045326 103407          BCS          508          ;BR IF CARRY SET (GOOD RETURN)
3218 045330 010001          MOV          R0,R1          ;SAVE CONTENTS OF TSSR
3219 045332          NEXT,ERRNO
3220 045332          428:    ERRDF          tERRNO,T17SSR,PKTSSR ;DEVICE FATAL SSR FAILED TO SET
      045332 104455          ;                                     TRAP          C18ERDF
      045334 001202          ;                                     .WORD          642
      045336 046605          ;                                     .WORD          T17SSR
      045340 012046          ;                                     .WORD          PKTSSR
3221 045342 005237 002222    INC          FATFLG          ;SET FATAL ERROR FLAG
3222 045346          508:    CKLOOP          ;LOOP ON ERROR, IF FLAG SET
      045346 104406          ;                                     TRAP          C1CLP1
3223 ;   Do a Write Subsystem Write Misc to Reset FIFO
3224 045350          JSR          PC,T17RSFIF          ;SETUP PKT FOR WRITE MISC RESET FIFO
3225 045354 012704 050330    MOV          @T17PK2,R4 ;GET WRITE SUBSYSTEM COMMAND PACKET
3226 045360 010465 000000    MOV          R4,TSDB(R5) ;SET THE PACKET ADDRESS TO EXECUTE
3227 045364 004737 016336    JSR          PC,CHKTSSR          ;WAIT FOR SSR TO SET
3228 045370          FORCERROR          628          ;BDDFORCE ERROR IF FORCER=1
3229 045404 103407          BCS          708          ;BR IF CARRY SET (GOOD RETURN)

```

0.4.

```

3230 045406 010001      MOV      R0,R1      ;SAVE CONTENTS OF TSSR
3231 045410            NEXT.ERRNO
3232 045410 620:      ERROF  ERRNO,T172SSR,PKTSSR ;DEVICE FATAL SSR FAILED TO SET
                                TRAP      C1ERDF
                                .WORD    643
                                .WORD    T172SSR
                                .WORD    PKTSSR
      045410 104455
      045412 001203
      045414 046642
      045416 012046
3233 045420 005237 002222      INC      FATFLG      ;SET FATAL ERROR FLAG
3234 045424 700:      CKLOOP      ;LOOP ON ERROR, IF FLAG SET
                                TRAP      C1CLP1
      045424 104406
3235
3236      ;      Do a Write Subsystem READ STATUS
3237      ;      If all Tape Status 2 (ICER,IFMK,IHER) flip-flop
3238      ;      signals NOT=0 Then Print Error
3239 045426 004737 047744      JSR      PC,T17SRD      ;SETUP PACKET FOR READ STATUS
3240 045432 012704 050330      MOV      @T17PK2,R4      ;GET WRITE SUBSYSTEM COMMAND PACKET
3241 045436 010465 000000      MOV      R4,TSDB(R5)      ;SET THE PACKET ADDRESS TO EXECUTE
3242 045442 004737 016336      JSR      PC,CHKTSSR      ;WAIT FOR SSR TO SET
3243 045446      FORCERROR 770      ;BDDFORCE ERROR IF FORCER=1
3244 045462 103407      BCS      800      ;BR IF CARRY SET (GOOD RETURN)
3245 045464 010001      MOV      R0,R1      ;SAVE CONTENTS OF TSSR
3246 045466      NEXT.ERRNO
3247 045466 770:      ERROF  ERRNO,T173SSR,PKTSSR ;DEVICE FATAL SSR FAILED TO SET
                                TRAP      C1ERDF
                                .WORD    644
                                .WORD    T173SSR
                                .WORD    PKTSSR
      045466 104455
      045470 001204
      045472 046706
      045474 012046
3248 045476 005237 002222      INC      FATFLG      ;SET FATAL ERROR FLAG
3249 045502 800:      CKLOOP      ;LOOP ON ERROR, IF FLAG SET
                                TRAP      C1CLP1
      045502 104406
3250 045504 004737 050126      JSR      PC,T17SETEXP      ;SET WORDS 0-7 EXPD=RECV (NOT TESTING)
3251 045510 012701 046362      MOV      @T17EXSTA,R1      ;GET EXPECTED READ STATUS
3252 045514 012702 050222      MOV      @T17BFSTA,R2      ;GET RECV READ STATUS
3253 045520 011211      MOV      (R2),(R1)      ;SET EXPD WORD #8 = RECV TEMP
3254 045522 042711 002000      BIC      #S1.ICER,(R1)      ;SET EXPD ICER =0
3255 045526 042711 001000      BIC      #S1.IFMK,(R1)      ;SET EXPD IFMK =0
3256 045532 042711 000400      BIC      #S1.IHER,(R1)      ;SET EXPD IHER =0
3257 045536 016261 000002 000002      MOV      2(R2),2(R1)      ;SET EXPD WORD #9 = RECV (NOT TESTING)
3258 045544 005000      CLR      R0      ;HIGH RECV ADDRESS FOR CKMSG2
3259 045546 012701 050202      MOV      @T17BFR,R1      ;LOW RECV ADDRESS FOR CKMSG2
3260 045552 012702 046342      MOV      @T17EXP,R2      ;EXPD ADDRESS
3261 045556 012703 000024      MOV      #20,,R3      ;NUMBER OF BYTES TO COMPARE
3262 045562 004737 011500      JSR      PC,CKMSG2      ;EXPD EQUAL RECV?
3263 045566      FORCERROR 920,NOTSSR      ;BDD
3264 045576 103404      BCS      1000      ;BR IF YES
3265 045600      NEXT.ERRNO
3266 045600 920:      ERROF  ERRNO,T177CMP,MSGSTAT ;REPORT ERROR
                                TRAP      C1ERROD
                                .WORD    645
                                .WORD    T177CMP
                                .WORD    MSGSTAT
      045600 104456
      045602 001205
      045604 047634
      045606 012350
3267 045610 1000:      CKLOOP      ;LOOP ON ERROR, IF FLAG SET
      045610 104406      TRAP      C1CLP1
3268
3269      ;      Do a Write Subsystem WRITE NPR to set tape direction out
3270 045612 012700 000100      MOV      #NPR,OUT,R0      ;SET TAPE DIRECTION OUT
3271 045616 004737 050006      JSR      PC,T17SNPR      ;SETUP T17PK2 FOR WRITE NPR
  
```

TSV5 - HARDWARE TESTS MACRO M1113 14-JUN-84 15:55  
 TEST 6: SUBTEST 6: FIFO VERIFY RESET FIFO TEST

SEQ 0173

```

3272 045622 012704 050330      MOV      @T17PK2,R4      ;GET WRITE SUBSYSTEM COMMAND PACKET
3273 045626 010465 000000      MOV      R4,TSDB(R5)    ;SET THE PACKET ADDRESS TO EXECUTE
3274 045632 004737 016336      JSR      PC,CHKTSSR     ;WAIT FOR SSR TO SET
3275 045636                    FORCERROR      112#      ;BDDFORCE ERROR IF FORCER=1
3276 045652 103407                    BCS      120#          ;BR IF CARRY SET (GOOD RETURN)
3277 045654 010001                    MOV      R0,R1         ;SAVE CONTENTS OF TSSR
3278 045656                    NEXT.ERRNO
3279 045656 112#:  ERRDF  ERRNO,T174SSR,PKTSSR ;DEVICE FATAL SSR FAILED TO SET
                                TRAP      C#ERDF
                                .WORD    646
                                .WORD    T174SSR
                                .WORD    PKTSSR
3280 045666 005237 002222      INC      FATFLG        ;SET FATAL ERROR FLAG
3281 045672 120#:  CKLOOP                    ;LOOP ON ERROR, IF FLAG SET
                                TRAP      C#CLP1
3282
3283 ;      Setup incrementing pattern in FIFO data buffer
3284 045674 012701 046362      MOV      @T17EXSTA,R1   ;EXPD WRITE FIFO DATA BUFFER
3285 045700 012702 000100      MOV      #64.,R2       ;TEST PATTERN SIZE
3286 045704 005000                    CLR      R0             ;INCREMENT TEST PATTERN
3287 045706 110021 130#:  MOVB     R0,(R1).       ;STORE INCREMENT TEST BYTE
3288 045710 005200                    INC      R0             ;SET NEXT PATTERN
3289 045712 005302                    DEC      R2             ;DONE?
3290 045714 003374                    BGT     130#           ;BR IF NO
3291
3292 ; REPEAT FOR BYTE COUNT 1 TO 65.
3293 045716 012737 000001 002310  MOV      #1,COUNT      ;GET FIRST BYTE COUNT
3294 ; Do a Write Subsystem WRITE FIFO with the current byte count
3295 045724 150#:  MOV      COUNT,R0      ;REPEAT LOOP LABEL
3296 045724 013700 002310      MOV      COUNT,R0      ;FIFO BYTE COUNT
3297 045730 012701 046362      MOV      @T17EXSTA,R1  ;FIFO WRITE DATA ADDRESS
3298 045734 004737 050032      JSR      PC,T17WFIF    ;SETUP T17PK2 FOR WRITE FIFO
3299 045740 012704 050330      MOV      @T17PK2,R4    ;GET WRITE SUBSYSTEM COMMAND PACKET
3300 045744 010465 000000      MOV      R4,TSDB(R5)   ;SET THE PACKET ADDRESS TO EXECUTE
3301 045750 004737 016336      JSR      PC,CHKTSSR    ;WAIT FOR SSR TO SET
3302 045754                    FORCERROR      152#      ;BDDFORCE ERROR IF FORCER=1
3303 045770 103407                    BCS      160#          ;BR IF CARRY SET (GOOD RETURN)
3304 045772 010001                    MOV      R0,R1         ;SAVE CONTENTS OF TSSR
3305 045774                    NEXT.ERRNO
3306 045774 152#:  ERRDF  ERRNO,T175SSR,PKTSSR ;DEVICE FATAL SSR FAILED TO SET
                                TRAP      C#ERDF
                                .WORD    647
                                .WORD    T175SSR
                                .WORD    PKTSSR
3307 046004 005237 002222      INC      FATFLG        ;SET FATAL ERROR FLAG
3308 046010 160#:  CKLOOP                    ;LOOP ON ERROR, IF FLAG SET
                                TRAP      C#CLP1
3309
3310 ; Do a Write Subsystem Write Misc to Reset FIFO
3311 046012 004737 047764      JSR      PC,T17RSFIF   ;SETUP PKT FOR WRITE MISC RESET FIFO
3312 046016 012704 050330      MOV      @T17PK2,R4    ;GET WRITE SUBSYSTEM COMMAND PACKET
3313 046022 010465 000000      MOV      R4,TSDB(R5)   ;SET THE PACKET ADDRESS TO EXECUTE
3314 046026 004737 016336      JSR      PC,CHKTSSR    ;WAIT FOR SSR TO SET
3315 046032                    FORCERROR      162#      ;BDDFORCE ERROR IF FORCER=1
3316 046046 103407                    BCS      170#          ;BR IF CARRY SET (GOOD RETURN)
3317 046050 010001                    MOV      R0,R1         ;SAVE CONTENTS OF TSSR
3318 046052                    NEXT.ERRNO

```

```

3319 046052          162$:  ERRDF  ERRNO,T172SSR,PKTSSR  ;DEVICE FATAL SSR FAILED TO SET
      046052 104455                                     TRAP  C$ERDF
      046054 001210                                     .WORD 648
      046056 046642                                     .WORD T172SSR
      046060 012046                                     .WORD PKTSSR
3320 046062 005237 002222          170$:  INC  FATFLG  ;SET FATAL ERROR FLAG
3321 046066          170$:  CKLOOP ;LOOP ON ERROR, IF FLAG SET
      046066 104406                                     TRAP  C$CLP1
3322
3323 ; Do a Write Subsystem READ STATUS
3324 ; If all Tape Status 2 (ICER,IFMK,IHER) flip-flop
3325 ; signals NOT=0 Then Print Error
3326 046070 004737 047744          JSR  PC,T17SRD  ;SETUP PACKET FOR READ STATUS
3327 046074 012704 050330          MOV  #T17PK2,R4 ;GET WRITE SUBSYSTEM COMMAND PACKET
3328 046100 010465 000000          MOV  R4,TSD8(R5) ;SET THE PACKET ADDRESS TO EXECUTE
3329 046104 004737 016336          JSR  PC,CHKTSSR ;WAIT FOR SSR TO SET
3330 046110          FORCERROR 177$ ;BDDFORCE ERROR IF FORCER=1
3331 046124 103407          BCS  180$ ;BR IF CARRY SET (GOOD RETURN)
3332 046126 010001          MOV  R0,R1 ;SAVE CONTENTS OF TSSR
3333 046130          NEXT.ERRNO
3334 046130          177$:  ERRDF  ERRNO,T173SSR,PKTSSR ;DEVICE FATAL SSR FAILED TO SET
      046130 104455                                     TRAP  C$ERDF
      046132 001211                                     .WORD 649
      046134 046706                                     .WORD T173SSR
      046136 012046                                     .WORD PKTSSR
3335 046140 005237 002222          180$:  INC  FATFLG  ;SET FATAL ERROR FLAG
3336 046144          180$:  CKLOOP ;LOOP ON ERROR, IF FLAG SET
      046144 104406                                     TRAP  C$CLP1
3337 046146 004737 050126          JSR  PC,T17SETEXP ;SET WORDS 0-7 EXPD=RECV (NOT TESTING)
3338 046152 012701 046362          MOV  #T17EXSTA,R1 ;GET EXPECTED READ STATUS
3339 046156 012702 050222          MOV  #T17BFSTA,R2 ;GET RECV READ STATUS
3340 046162 011211          MOV  (R2),(R1) ;SET EXPD WORD #8 = RECV TEMP
3341 046164 042711 002000          BIC  #S1.ICER,(R1) ;SET EXPD ICER =0
3342 046170 042711 001000          BIC  #S1.IFMK,(R1) ;SET EXPD IFMK =0
3343 046174 042711 000400          BIC  #S1.IHER,(R1) ;SET EXPD IHER =0
3344 046200 016261 000002 000002  MOV  2(R2),2(R1) ;SET EXPD WORD #9 = RECV (NOT TESTING)
3345 046206 005000          CLR  R0 ;HIGH RECV ADDRESS FOR CKMSG2
3346 046210 012701 050202          MOV  #T17BFR,R1 ;LOW RECV ADDRESS FOR CKMSG2
3347 046214 012702 046342          MOV  #T17EXP,R2 ;EXPD ADDRESS
3348 046220 012703 000024          MOV  #20.,R3 ;NUMBER OF BYTES TO COMPARE
3349 046224 004737 011500          JSR  PC,CKMSG2 ;EXPD EQUAL RECV?
3350 046230          FORCERROR 192$,NOTSSR ;BDD
3351 046240 103404          BCS  200$ ;BR IF YES
3352 046242          NEXT.ERRNO
3353 046242          192$:  ERRHRD  ERRNO,T177CMP,MSGSTAT ;REPORT ERROR
      046242 104456                                     TRAP  C$ERHRD
      046244 001212                                     .WORD 650
      046246 047634                                     .WORD T177CMP
      046250 012350                                     .WORD MSGSTAT
3354 046252          200$:  CKLOOP ;LOOP ON ERROR, IF FLAG SET
      046252 104406                                     TRAP  C$CLP1
3355
3356
3357 046254          250$:  FORCEEXIT 260$
3358 046254          INC  COUNT ;GET NEXT BYTE COUNT
3359 046264 005237 002310          CMP  COUNT,#65 ;DONE ALL BYTES?
3360 046270 023727 002310 000101

```



TSV5 - HARDWARE TESTS MACRO M1113 14-JUN-84 15:55  
 TEST 6: SUBTEST 6: FIFO VERIFY RESET FIFO TEST

SEQ 0175

```

3361 046276 101002          BHI 260$          ;BR IF YES
3362 046300 000137 045724    JMP 150$          ;DO ANOTHER BYTE COUNT
3363 046304          260$:
3364
3365 046304          ENDSUB          ;////////// END SUBTEST //////////
      046304          L10064:
      046304 104403          TRAP C#ESUB
3366
3367 046306 005737 002222    TST FATFLG       ;ANY FATAL ERRORS ?
3368 046312 001402          BEQ 300$         ;BRANCH IF NOT
3369 046314 004737 017202    JSR PC,CKDROP   ;TRY TO DROP THE UNIT
3370 046320 004737 016456    JSR PC,TSTLOOP  ;DO ITERATIONS?
3371 046324 103002          BCC 305$        ;BR IF NO
3372 046326 000137 040364    JMP T17LOOP     ;LOOP UNTIL ITERATIONS DONE
3373 046332          305$:
3374
3375 046332          EXIT TST          ;////////// EXIT TEST //////////
      046332 104432          TRAP C#EXIT
      046334 002112          .WORD L10056
3376
3377
3378
3379          ;*
3380          ;LOCAL STORAGE FOR THIS TEST
3381          ;
3382
3383 046336          T17MSK:          ;MASK OF UNTESTED BITS IN READ STATUS BYTES
3384          ;UNTESTED BITS ARE SET TO 1
3385 046336          377          .BYTE ↑C<000>    ;BYTE 0 MASK
3386 046337          037          .BYTE ↑C<340>    ;BYTE 1 MASK (PARERR,IRESV2,IRESV1)
3387 046340          360          .BYTE ↑C<017>    ;BYTE 2 (TIMER A,TIMER B,UNDEFINED<1:0>)
3388 046341          000          .BYTE 0          ;MAKE IT EVEN
3389
3390 046342          T17EXP:          ;BEGIN EXPECTED DATA BUFFER
3391 046342 000000          .WORD 0          ;MESSAGE TYPE
3392 046344 000000          .WORD 0          ;DATA FIELD LENGTH
3393 046346 000000          .WORD 0          ;RBPCR
3394 046350 000000          .WORD 0          ;XST0
3395 046352 000000          .WORD 0          ;XST1
3396 046354 000000          .WORD 0          ;XST2
3397 046356 000000          .WORD 0          ;XST3
3398 046360 000000          .WORD 0          ;XST4 (ALWAYS PRESENT FOR WRITE SUB.)
3399 046362          T17EXSTA: .BLKB 66. ;EXPECTED READ STATUS AND WRITE FIFO DATA
3400 046464          T17XEND:          ;END EXPECTED DATA BUFFER
3401
3402 046464          T17WFDATA: .BLKB 66. ;WRITE FIFO EXPECTED DATA BUFFER
3403
3404
3405          ;*
3406          ;LOCAL TEXT MESSAGES FOR TEST
3407          ;-
3408 046566          106          111          106 TST17ID: .ASCIZ 'FIFO Exerciser'
3409 046605          127          122          111 T17SSR: .ASCIZ 'WRITE CHARACTERISTICS Failed'
3410 046642          127          122          111 T172SSR: .ASCIZ 'WRITE SUBSYSTEM (Write Misc) Failed'
3411 046706          127          122          111 T173SSR: .ASCIZ 'WRITE SUBSYSTEM (Read Status) Failed'
3412 046753          127          122          111 T174SSR: .ASCIZ 'WRITE SUBSYSTEM (Write Npr) Failed'
3413 047016          127          122          111 T175SSR: .ASCIZ 'WRITE SUBSYSTEM (Write FIFO) Failed'

```

```

3414 047062      127      122      111  T176SSR:.ASCIZ 'WRITE SUBSYSTEM (Read FIFO) Failed'
3415 047125      106      111      106  T171CMP:.ASCIZ 'FIFO Status in WORD #9 Incorrect after Initialize
3416 047207      122      145      141  T172CMP:.ASCIZ 'Read FIFO Data not equal to Write FIFO , Data is in WORD #8'
3417 047303      105      111      106  T173CMP:.ASCIZ 'FIFO Status (In WORD #9) Incorrect after WRITE FIFO'
3418 047367      106      111      106  T174CMP:.ASCIZ 'FIFO Status (In WORD #9) Incorrect after READ FIFO'
3419 047452      122      145      141  T175CMP:.ASCIZ 'Read FIFO Data not equal to Write FIFO Data'
3420 047526      106      111      106  T176CMP:.ASCIZ 'FIFO Status (In WORD #9) Incorrect after READ FIFO from an Empty FIFO'
3421 047634      106      111      106  T177CMP:.ASCIZ 'FIFO Status (In WORD #9) Incorrect after RESET FIFO'
3422                                     .EVEN
3423
3424
3425                                     ;*
3425                                     ; CLEAR MESSAGE BUFFER
3426
3427 047720                                     ;
3427 047720                                     ; T17CLRBUF:
3428 047720                                     ; SAVREG                                     ; SAVE R1-R5 UNTIL NEXT RETURN
3429 047724      012701      050202      MOV          #T17BFR,R1                       ; GET MESSAGE BUFFER ADDRESS
3430 047730      012702      000120      MOV          #T17BEND-T17BFR,R2              ; SIZE OF MESSAGE BUFFER IN BYTES
3431 047734      105021      CLRB         (R1)+                             ; CLEAR A BYTE
3432 047736      005302      DEC          R2                               ; DONE?
3433 047740      003375      BGT         10#                             ; BR IF NO
3434 047742      000207      RTS          PC                             ; RETURN
3435
3436
3437                                     ;*
3437                                     ; SETUP T17PK2 PACKET FOR READ STATUS
3438
3439 047744                                     ;
3439 047744      004737      047720      JSR          PC,T17CLRBUF                    ; CLEAR MESSAGE BUFFER
3440 047750      012700      050340      MOV          #T17DT2,R0                       ; WRITE SUBSYSTEM DATA BUFFER
3441 047754      112720      000005      MOVB        #PW.RDSTATUS,(R0)+              ; STORE READ STATUS COMMAND IN BSEL0
3442 047760      105010      CLRB         (R0)                             ; CLEAR BSEL1
3443 047762      000207      RTS          PC                             ; RETURN
3444
3445
3446                                     ;*
3447                                     ; SETUP T17PK2 PACKET FOR WRITE MISC RESET FIFO
3448
3449 047764                                     ;
3449 047764      004737      047720      JSR          PC,T17CLRBUF                    ; CLEAR MESSAGE BUFFER
3450 047770      012700      050340      MOV          #T17DT2,R0                       ; WRITE SUBSYSTEM DATA BUFFER
3451 047774      112720      000010      MOVB        #PW.WMISC,(R0)+                 ; STORE WRITE MISCELLANEOUS IN BSEL0
3452 050000      112710      000030      MOVB        #MS.RSFIF!MS.RSTAP,(R0)        ; STORE BSEL1 CLEAR FIFO CODES
3453 050004      000207      RTS          PC                             ; RETURN
3454
3455
3456                                     ;*
3457                                     ; SETUP T17PK2 PACKET FOR WRITE NPR
3458
3459                                     ;
3459                                     ; INPUT:
3460                                     ; RO CONTAINS BSEL1 NPR DATA
3461
3462                                     ;
3462                                     ; SETS NP.WRP SINCE IF 0 IT WRITES WRONG PARITY.
3463
3464 050006                                     ;
3464 050006      004737      047720      JSR          PC,T17CLRBUF                    ; CLEAR MESSAGE BUFFER
3465 050012      012701      050340      MOV          #T17DT2,R1                       ; WRITE SUBSYSTEM DATA BUFFER
3466 050016      112721      000011      MOVB        #PW.WNPR,(R1)+                 ; STORE WRITE NPR IN BSEL0
3467 050022      052700      000020      BIS         #NP.WRP,R0                       ; DON'T WRITE WRONG PARITY
3468 050026      110011      MOVB        R0,(R1)                         ; STORE NPR DATA IN BSEL1
3469 050030      000207      RTS          PC                             ; RETURN

```

TSV5 HARDWARE TESTS MACRO M1113 14-JUN-84 15:55  
 TEST 6: SUBTEST 6: FIFO VERIFY RESET FIFO TEST

SEQ 0177

```

3471
3472
3473      ;*
3474      ; SETUP T17PK2 PACKET FOR WRITE FIFO
3475      ;
3476      ; INPUT:
3477      ;       R0 CONTAINS BYTE COUNT
3478      ;       R1 CONTAINS DATA PATTERN BLOCK ADDRESS
3479      ;-
3479 050032 T17W IF:
3480 050032      SAVREG                               ;SAVE R1-R5 UNTIL NEXT RETURN
3481 050036 004737 047720      JSR      PC,T17CLRBUF      ;CLEAR MESSAGE BUFFER
3482 050042 012702 050340      MOV      @T17DT2,R2      ;WRITE SUBSYSTEM DATA BUFFER
3483 050046 112722 000004      MOVB   @PW.WFIFO,(R2)+   ;STORE WRITE FIFO IN BSEL0
3484 050052 110022              MOVB   R0,(R2)+         ;STORE BYTE COUNT IN BSEL1
3485 050054 005022              CLR      (R2)+         ;CLEAR SEL2 (UNUSED)
3486 050056 112122 10$:      MOVB   (R1)+,(R2)+       ;STORE DATA PATTERN BYTE
3487 050060 005300              DEC      R0                ;DONE ALL BYTES?
3488 050062 003375              BGT     10$             ;BR IF NO
3489 050064 000207              RTS      PC                ;RETURN
3490
3491
3492      ;*
3493      ; SETUP T17PK2 PACKET FOR READ FIFO
3494      ;
3495      ; INPUT:
3496      ;       R0 CONTAINS SEL2 BYTE COUNT
3497      ;-
3497 050066 T17RFIF:
3498 050066 004737 047720      JSR      PC,T17CLRBUF      ;CLEAR MESSAGE BUFFER
3499 050072 012701 050340      MOV      @T17DT2,R1      ;WRITE SUBSYSTEM DATA BUFFER
3500 050076 112721 000003      MOVB   @PW.RFIFO,(R1)+   ;STORE READ FIFO IN BSEL0
3501 050102 110021              MOVB   R0,(R1)+         ;STORE BYTE COUNT IN BSEL1
3502 050104 000207              RTS      PC                ;RETURN
3503
3504      ;*
3505      ; CLEAR EXPECTED DATA MESSAGE BUFFER
3506      ;-
3506 050106 T17CLEXP:
3507 050106 012701 046342      MOV      @T17EXP,R1      ;GET EXPD ADDRESS
3508 050112 012700 000122      MOV      @T17EXEND-T17EXP,R0 ;GET EXPD SIZE
3509 050116 105021 10$:      CLRB   (R1)+         ;CLEAR A BYTE
3510 050120 005300              DEC      R0                ;DONE?
3511 050122 003375              BGT     10$             ;BR IF NO
3512 050124 000207              RTS      PC                ;RETURN
3513
3514
3515      ;*
3516      ;Set WORDS 0-7 of expd message buffer = to recv since not testing
3517      ;-
3517 050126 T17SETEXP:
3518 050126 012702 046342      MOV      @T17EXP,R2      ;GET EXPD
3519 050132 012703 050202      MOV      @T17BFR,R3     ;GET READ STATUS RECV BUFFER
3520 050136 012700 000010      MOV      @8.,R0         ;SET WORDS 0-7 EXP=RECV
3521 050142 012322 5$:      MOV      (R3)+,(R2)+     ;SET EXPD=RECV
3522 050144 005300              DEC      R0                ;DONE WORDS 0-7 WORDS?
3523 050146 003375              BGT     5$              ;BR IF NO
3524 050150 000207              RTS      PC                ;RETURN
3525
3527      ;       .=<.>10>&177770
3529      ;

```

```

3530 ;WRITE CHARACTERISTICS COMMAND PACKET
3531 ;
3532 050160 T17PACKET: ;COMMAND PACKET FOR TEST
3533 050160 100004 .WORD 100004 ;WRITE CHARACTERISTICS COMMAND, WITH ACK
3534 050162 050170 .WORD T17DATA ;ADDRESS OF CHARACTERISTICS BLOCK
3535 050164 000000 .WORD 0
3536 050166 000012 .WORD 10. ;MINIMUM MESSAGE PACKET SIZE
3537
3538 050170 T17DATA: ;CHARACTERISTICS DATA BLOCK
3539 050170 050202 .WORD T17BFR ;ADDRESS OF MESSAGE BUFFER
3540 050172 000000 .WORD 0
3541 050174 000024 .WORD 20. ;LENGTH OF MESSAGE BUFFER
3542 050176 000000 .WORD 0 ;ESS,ENB,EAI,ERI
3543 050200 000000 .WORD 0 ;EXTENDED FEATURES UNIT NO. ETC.
3544
3545 ;MESSAGE BUFFER FOR ALL TEST 6 COMMANDS
3546
3547 T17BFR: ;BEGIN MESSAGE BUFFER
3548 050202 .WORD 0 ;MESSAGE TYPE
3549 050202 000000 .WORD 0 ;DATA FIELD LENGTH
3550 050204 000000 .WORD 0 ;RBPGR
3551 050206 000000 .WORD 0 ;XST0
3552 050210 000000 .WORD 0 ;XST1
3553 050212 000000 .WORD 0 ;XST2
3554 050214 000000 .WORD 0 ;XST3
3555 050216 000000 .WORD 0 ;XST4 (ALWAYS PRESENT FOR WRITE SUBSYSTEM
3556 050220 000000 .WORD 0 ;READ S,ATUS AND WRITE FIFO BUFFER
3557 050222 T17BFSTA: .BLKB 64. ;END OF MESSAGE BUFFER
3558 050322 T17BEND:
3559 ;
3560 ;WRITE SUBSYSTEM READ STATUS COMMAND PACKET
3561 ;
3562
3563 050330 .=<..+10>&177770
3564
3565 050330 T17PK2: ;WRITE SUBSYSTEM WITH ACK
3566 050330 100006 .WORD P.WRTSUB!P.ACK ;LOW ADDRESS OF DATA BLOCK
3567 050332 050340 .WORD T17DT2 ;HIGH ADDRESS OF DATA BLOCK
3568 050334 000000 .WORD 0 ;MINIMUM MESSAGE PACKET SIZE
3569 050336 000012 .WORD 10.
3570
3571 050340 T17DT2: ;DATA BLOCK
3572 050340 000 .BYTE 0 ;BSELO
3573 050341 000 .BYTE 0 ;BSEL1
3574 050342 000000 .WORD 0 ;SEL2
3575 050344 .BLKB 66. ;WRITE FIFO DATA OUTPUT BUFFER
3576
3577 050446 ENDTST
3578 050446 L10056: TRAP C#ETST
3579 050446 104401
3580 ;
3581 ;.SBTTL TEST 7: STATIC TRANSPORT BUS INTERFACE TEST
3582 ;
3583 ;*
3584 ; TEST DESCRIPTION:
3585 ;
3586 ; TEST STEPS:
3587 ;
3588 ; REPEAT FOR LOOPCNT
    
```

```

3587      ; BEGIN
3588      ; Write to TSSR register to soft initialize the controller
3589      ; Do WRITE CHARACTERISTICS to check for Extended Features Switch
3590      ; If Extended Features Hardware Switch Clear then:
3591      ;   Do Write Subsystem Write Miscellaneous to Set Extended Features.
3592      ; Do WRITE CHARACTERISTICS to select reserved unit 7
3593      ; Do a Write Subsystem READ STATUS
3594      ; If any transport interface signals are asserted then Print Error
3595      ; END
3596      ;
3597      ;
3598      ;
3599 050450      BGNTST
050450
3604 050450 012700 051156      MOV      #TST18ID,R0      ;ASCII MESSAGE TO IDENTIFY TEST
3605 050454 004737 016510      JSR      PC,TSTSETUP      ;DO INITIAL TEST SETUP
3606 050460 012737 000012 002216      MOV      #10.,LOOPCNT      ;PERFORM 10 ITERATIONS
3607 050466      T18LOOP:
3608      ; Write to TSSR register to soft initialize the controller
3609 050466      5$:
3610 050466 004737 015774      JSR      PC,SOFINIT      ;WRITE TO TSSR TO SOFT INITIALIZE
3611 050472 103405      BCS     10$              ;BR IF SOFT INIT OKAY
3612 050474 010001      MOV      R0,R1          ;SAVE CONTENTS OF TSSR
3613 050476      ERROF  ERRNO,SFIERR,SFIMSG      ;DEVICE FATAL DURING INIT
050476 104455      TRAP     C$ERDF
050500 001274      .WORD   700
050502 003652      .WORD   SFIERR
050504 012034      .WORD   SFIMSG
3614
3615      ; Do WRITE CHARACTERISTICS to check for Extended Features Switch
3616 050506 005037 002222      10$: CLR      FATFLG      ;CLEAR FATAL ERROR FLAG
3617 050512 012704 051640      MOV      #T18PACKET,R4      ;GET THE ADDRESS OF COMMAND PACKET
3618 050516 004737 010662      JSR      PC,WRTPCHR      ;DO WRITE CHARACTERISTICS COMMAND
3619 050522      FORCERROR 12$          ;$$$FORCE ERROR IF FORCER=1
3620 050536 103407      BCS     15$              ;BR IF CARRY SET (GOOD RETURN)
3621 050540 010001      MOV      R0,R1          ;SAVE CONTENTS OF TSSR
3622 050542      NEXT.ERRNO
3623 050542      12$: ERROF  ERRNO,T18SSR,PKTSSR      ;DEVICE FATAL SSR FAILED TO SET
050542 104455      TRAP     C$ERDF
050544 001275      .WORD   701
050546 051215      .WORD   T18SSR
050550 012046      .WORD   PKTSSR
3624 050552 005237 002222      INC      FATFLG          ;SET FATAL ERROR FLAG
3625 050556      15$: CKLOOP          ;LOOP ON ERROR, IF FLAG SET
050556 104406      TRAP     C$CLP1
3626
3627      ; If Extended Features Hardware Switch Clear then:
3628      ;   Do Write Subsystem Write Miscellaneous to Set Extended Features.
3629 050560 012701 051662      MOV      #T18BFR,R1      ;MESSAGE BUFFER ADDRESS
3630 050564 032761 000200 000012      BIT      #X2.EXTF,XST2(R1) ;EXTENDED FEATURES SWITCH SET?
3631 050572 001026      BNE     30$              ;BR IF YES
3632 050574 004737 051506      JSR      PC,T18SMISC      ;SETUP PACKET FOR WRITE MISCELLANEOUS
3633 050600 012704 051710      MOV      #T18PK2,R4      ;GET WRITE SUBSYSTEM COMMAND PACKET
3634 050604 010465 000000      MOV      R4,TSDB(R5)      ;SET THE PACKET ADDRESS TO EXECUTE
3635 050610 004737 016336      JSR      PC,CHKTSSR      ;WAIT FOR SSR TO SET
3636 050614      FORCERROR 22$          ;$$$FORCE ERROR IF FORCER=1
3637 050630 103407      BCS     30$              ;BR IF CARRY SET (GOOD RETURN)

```

TSV5 - HARDWARE TESTS MACRO M1113 14-JUN-84 15:55  
 TEST 7: STATIC TRANSPORT BUS INTERFACE TEST

SEQ 0180

```

3638 050632 010001          MOV     R0,R1          ;SAVE CONTENTS OF TSSR
3639 050634                NEXT.ERRNO
3640 050634 22$:          ERRDF  ERRNO,T182SSR,PKTSSR ;DEVICE FATAL SSR FAILED TO SET
                                TRAP     C#ERDF
                                .WORD    702
                                .WORD    T182SSR
                                .WORD    PKTSSR
3641 050644 005237 002222    INC     FATFLG          ;SET FATAL ERROR FLAG
3642 050650 30$:          CKLOOP          ;LOOP ON ERROR, IF FLAG SET
                                TRAP     C#CLP1
3643
3644
3645 ;          Do WRITE CHARACTERISTICS to select reserved unit 7
3646 050652 005037 002222    CLR     FATFLG          ;CLEAR FATAL ERROR FLAG
3647 050656 012704 051640    MOV     @T18PACKET,R4   ;GET THE ADDRESS OF COMMAND PACKET
3648 050662 004737 010662    JSR     PC,WRTCHR       ;DO WRITE CHARACTERISTICS COMMAND
3649 050666                FORCERROR 42$          ;BDFORCE ERROR IF FORCER=1
3650 050702 103407                BCS     50$          ;BR IF CARRY SET (GOOD RETURN)
3651 050704 010001          MOV     R0,R1          ;SAVE CONTENTS OF TSSR
3652 050706                NEXT.ERRNO
3653 050706 42$:          ERRDF  ERRNO,T18SSR,PKTSSR ;DEVICE FATAL SSR FAILED TO SET
                                TRAP     C#ERDF
                                .WORD    703
                                .WORD    T18SSR
                                .WORD    PKTSSR
3654 050716 005237 002222    INC     FATFLG          ;SET FATAL ERROR FLAG
3655 050722 50$:          CKLOOP          ;LOOP ON ERROR, IF FLAG SET
                                TRAP     C#CLP1
3656
3657 ;          Clear message buffer
3658 050724 012701 051662    MOV     @T18BFR,R1     ;GET MESSAGE BUFFER ADDRESS
3659 050730 013700 051654    MOV     T18DATA+4,R0   ;SIZE OF MESSAGE BUFFER IN BYTES
3660 050734 105021 60$:          CLRB    (R1)+          ;CLEAR A BYTE
3661 050736 005300                DEC     R0             ;DONE?
3662 050740 003375                BGT     60$          ;BR IF NO
3663 ;          Do a Write Subsystem READ STATUS
3664 050742 004737 051466    JSR     PC,T18SRD      ;SETUP PACKET FOR READ STATUS
3665 050746 012704 051710    MOV     @T18PK2,R4     ;GET WRITE SUBSYSTEM COMMAND PACKET
3666 050752 010465 000000    MOV     R4,TSDB(R5)    ;SET THE PACKET ADDRESS TO EXECUTE
3667 050756 004737 016336    JSR     PC,CHKTSSR     ;WAIT FOR SSR TO SET
3668 050762                FORCERROR 62$          ;BDFORCE ERROR IF FORCER=1
3669 050776 103407                BCS     70$          ;BR IF CARRY SET (GOOD RETURN)
3670 051000 010001          MOV     R0,R1          ;SAVE CONTENTS OF TSSR
3671 051002                NEXT.ERRNO
3672 051002 62$:          ERRDF  ERRNO,T183SSR,PKTSSR ;DEVICE FATAL SSR FAILED TO SET
                                TRAP     C#ERDF
                                .WORD    704
                                .WORD    T183SSR
                                .WORD    PKTSSR
3673 051012 005237 002222    INC     FATFLG          ;SET FATAL ERROR FLAG
3674 051016 70$:          CKLOOP          ;LOOP ON ERROR, IF FLAG SET
                                TRAP     C#CLP1
3675
3676
3677 ;          Set first 8 words of expd message buffer = to rcv since not testing
3678 ;          Set unused bits in Read Status expd equal rcvd
3679 051020 004737 051530    JSR     PC,T18SETEXP   ;SET SOME EXPD TO RECV

```

```

3680      ;      If any transport interface signals are asserted then Print Error
3681 051024 005000      CLR      R0      ;HIGH RECV ADDRESS FOR CKMSG2
3682 051026 012701 051662      MOV      @T18BFR,R1      ;LOW RECV ADDRESS FOR CKMSG2
3683 051032 012702 051126      MOV      @T18EXP,R2      ;EXPD ADDRESS
3684 051036 012703 000012      MOV      @10.,R3      ;NUMBER OF WORDS TO COMPARE
3685 051042 004737 011500      JSR      PC,CKMSG2      ;EXPD EQUAL RECV?
3686 051046      FORCERROR      82$,NOTSSR      ;8SD
3687 051056 103404      BCS      90$      ;BR IF YES
3688 051060      NEXT.ERRNO
3689 051060 82$:      ERRHRD      ERRNO,T18CMP,MSGSTAT      ;REPORT ERROR
      051060 104456      TRAP      C#ERRHRD
      051062 001301      .WORD      705
      051064 051363      .WORD      T18CMP
      051066 012350      .WORD      MSGSTAT
3690 051070 90$:      CKLOOP      ;LOOP ON ERROR, IF FLAG SET
      051070 104406      TRAP      C#CLP1
3691
3692 051072 005737 002222      TST      FATFLG      ;ANY FATAL ERRORS ?
3693 051076 001402      BEQ      160$      ;BRANCH IF NOT
3694 051100 004737 017202      JSR      PC,CKDROP      ;TRY TO DROP THE UNIT
3695 051104 004737 016456 160$:      JSR      PC,TSTLOOP      ;DO ITERATIONS?
3696 051110 103002      BCC      165$      ;BR IF NO
3697 051112 000137 050466 165$:      JMP      T18LOOP      ;LOOP UNTIL ITERATIONS DONE
3698 051116
3699 051116      EXIT      TST
      051116 104432      TRAP      C#EXIT
      051120 000606      .WORD      L10065-.
3700
3701
3702      ;*
3703      ;LOCAL STORAGE FOR THIS TEST
3704      ;-
3705
3706 051122      T18MSK:      ;MASK OF UNUSED BITS IN READ STATUS BYTES
3707 051122      377      .BYTE      †C<000>      ;BYTE 0 MASK
3708 051123      037      .BYTE      †C<340>      ;BYTE 1
3709 051124      100      .BYTE      †C<277>      ;BYTE 2
3710 051125      000      .BYTE      0      ;MAKE IT EVEN
3711
3712 051126      T18EXP:      ;EXPECTED DATA BUFFER
3713 051126 000000      .WORD      0      ;MESSAGE TYPE
3714 051130 000000      .WORD      0      ;DATA FIELD LENGTH
3715 051132 000000      .WORD      0      ;RBPCR
3716 051134 000000      .WORD      0      ;XST0
3717 051136 000000      .WORD      0      ;XST1
3718 051140 000000      .WORD      0      ;XST2
3719 051142 000000      .WORD      0      ;XST3
3720 051144 000000      .WORD      0      ;XST4 (ALWAYS PRESENT FOR WRITE SUB)
3721 051146 000000      .WORD      0      ;READ STATUS BYTE 1/0
3722 051150 000000      .WORD      0      ;READ STATUS BYTE 2
3723
3724 051152      377      020      T18XS:      .BYTE      377,020      ;READ STATUS BYTE 0/1 EXPECTED BASE
3725 051154 000000      .WORD      0      ;READ STATUS BYTE 2 EXPECTED BASE
3726
3727      ;*
3728      ;LOCAL TEXT MESSAGES FOR TEST
3729      ;-

```

```

3730
3731 051156      123      164      141  TST18ID:      .ASCIZ 'Static Transport Bus Interface
3732 051215      127      122      111  T18SSR: .ASCIZ 'WRITE CHARACTERISTICS Failed'
3733 051252      127      122      111  T182SSR: .ASCIZ 'WRITE SUBSYSTEM (Write Misc) Failed'
3734 051316      127      122      111  T183SSR: .ASCIZ 'WRITE SUBSYSTEM (Read Status) Failed'
3735 051363      124      162      141  T18CMP: .ASCIZ 'Transport Bus Interface Signals NOT Negated After Unit 7 Selected
3736
3737
3738
3739           ;+
3739           ; SETUP T18PK2 PACKET FOR READ STATUS
3740           ;-
3741 051466      T18SRD:
3742 051466          SAVREG          ;SAVE R1-R5 UNTIL NEXT RETURN
3743 051472      012700  051720      MOV      @T18DT2,R0          ;WRITE SUBSYSTEM DATA BUFFER
3744 051476      112720  000005      MOVB     @PW.RDSTATUS,(R0)+ ;STORE READ STATUS COMMAND IN BSELO
3745 051502      105010      CLRB     (R0)              ;CLEAR BSEL1
3746 051504      000207      RTS      PC                ;RETURN
3747
3748
3749           ;+
3749           ; SETUP T18PK2 PACKET FOR WRITE MISC.
3750           ;-
3751 051506      T18SMISC:
3752 051506          SAVREG          ;SAVE R1-R5 UNTIL NEXT RETURN
3753 051512      012700  051720      MOV      @T18DT2,R0          ;WRITE SUBSYSTEM DATA BUFFER
3754 051516      112720  000010      MOVB     @PW.WMISC,(R0)+    ;STORE WRITE MISCELLANEOUS IN BSELO
3755 051522      112710  000200      MOVB     @MS.EXT,(R0)     ;STORE INVERT EXTENDED FEATURES IN BSEL1
3756 051526      000207      RTS      PC                ;RETURN
3757
3758
3759           ;+
3759           ;Set first 8 words of expd message buffer = to rcv since not testing
3760           ; Set unused bits in Read Status expd equal rcvd
3761           ;-
3762 051530      T18SETEXP:
3763 051530      012702  051126      MOV      @T18EXP,R2        ;GET EXPD
3764 051534      012703  051662      MOV      @T188FR,R3       ;GET READ STATUS RECV BUFFER
3765 051540      012700  000010      MOV      @8.,R0          ;SET FIRST 8 WORDS EXP=RCV
3766 051544      012322      S#:    MOV      (R3)+,(R2)+   ;SET EXPD=RCV
3767 051546      005300      DEC      R0              ;DONE FIRST 8 WORDS?
3768 051550      003375      BGT     S#              ;BR IF NO
3769 051552      012701  051122      MOV      @T18MSK,R1       ;GET UNUSED BIT MASK
3770 051556      013712  051152      MOV      T18XS,(R2)       ;SETUP BASE EXPECTED BYTE 1/0
3771 051562      013762  051154  000002      MOV      T18XS+2,2(R2)    ;SETUP BASE EXPECTED BYTE 2
3772 051570      011300      MOV      (R3),R0         ;GET RECV BYTE 1 AND BYTE 0
3773 051572      041100      BIC     (R1),R0          ;CLEAR ALL BUT UNUSED
3774 051574      040012      BIC     R0,(R2)          ;CLEAR UNUSED IN EXP
3775 051576      050012      BIS     R0,(R2)          ;SET UNUSED EXPD=RCV FOR COMPARE
3776 051600      016300  000002      MOV      2(R3),R0        ;GET RECV BYTE 2
3777 051604      046100  000002      BIC     2(R1),R0         ;CLEAR ALL BUT UNUSED
3778 051610      040062  000002      BIC     R0,2(R2)         ;CLEAR UNUSED IN EXPD
3779 051614      050062  000002      BIS     R0,2(R2)         ;SET UNUSED EXPD=RCV FOR COMPARE
3780 051620      105062  000003      CLRB    3(R2)           ;CLEAR EXPD BYTE 3 (UNUSED)
3781 051624      105063  000003      CLRB    3(R3)           ;CLEAR RECV BYTE 3 (UNUSED)
3782 051630      000207      RTS      PC                ;RETURN
3783
3785           051640          .<.>10>E177770
3787
3788           ;WRITE CHARARACTERISTICS COMMAND PACKET

```



```

3789
3790 051640          T18PACKET:          ;COMMAND PACKET FOR TEST
3791 051640 100004   .WORD 100004       ;WRITE CHARACTERISTICS COMMAND, WITH ACK
3792 051642 051650   .WORD T18DATA     ;ADDRESS OF CHARACTERISTICS BLOCK
3793 051644 000000   .WORD 0
3794 051646 000012   .WORD 10.          ;MESSAGE PACKET MINIMUM SIZE
3795
3796 051650          T18DATA:          ;CHARACTERISTICS DATA BLOCK
3797 051650 051662   .WORD T18BFR       ;ADDRESS OF MESSAGE BUFFER
3798 051652 000000   .WORD 0
3799 051654 000024   .WORD 20.         ;LENGTH OF MESSAGE BUFFER
3800 051656 000000   .WORD 0           ;ESS,END,EAI,ERI
3801 051660 000007   .WORD 7           ;SELECT RESERVED UNIT 7
3802
3803
3804 051662          T18BFR:          ;MESSAGE BUFFER
3805 051662 000000   .WORD 0           ;MESSAGE TYPE
3806 051664 000000   .WORD 0           ;DATA FIELD LENGTH
3807 051666 000000   .WORD 0           ;RSPCR
3808 051670 000000   .WORD 0           ;XS10
3809 051672 000000   .WORD 0           ;XS11
3810 051674 000000   .WORD 0           ;XS12
3811 051676 000000   .WORD 0           ;XS13
3812 051700 000000   .WORD 0           ;XS14 (ALWAYS PRESENT FOR WRITE SUBSYSTEM
3813 051702 000000   .WORD 0           ;READ STATUS BYTE 1/0 RETURNED
3814 051704 000000   .WORD 0           ;READ STATUS BYTE 2
3815
3816          ;WRITE SUBSYSTEM READ STATUS COMMAND PACKET
3817          ;
3819          .*. .10>E177770
3821 051710          T18PK2:          ;WRITE SUBSYSTEM WITH ACK
3822 051710 100006   .WORD P.WRTSUB!P.ACK ;LOW ADDRESS OF DATA BLOCK
3823 051712 051720   .WORD T18OT2       ;HIGH ADDRESS OF DATA BLOCK
3824 051714 000000   .WORD 0           ;BUFFER EXTENT
3825 051716 000010   .WORD 8.
3826
3827 051720          T18OT2:          ;DATA BLOCK
3828 051720          .BYTE 0           ;BSELO
3829 051721          .BYTE 0           ;BSEL1
3830 051722 000000   .WORD 0           ;SEL2
3831 051724 000000   .WORD 0           ;DATA
3832
3833
3834 051726          ENDTST
3834 051726          L10065: TRAP COETST
3834 051726 104401
3835          .SBTTL TEST 8: TRANSPORT BUS INTERFACE LOOPBACK TEST
3836
3837          ; TEST DESCRIPTION:
3838          ;
3839          ; This test verifies the controller's Transport Bus
3840          ; drivers, receivers, and signal loopback logic. Note
3841          ; that the Static Transport Bus test must have run
3842          ; correctly for this test to provide meaningful results.
3843          ;
3844          ; TEST STEPS:
3845          ;

```

```

3846      REPEAT FOR LOOPCNT
3847      BEGIN
3848          Do Subtest 1      Loopback Control signals test
3849          Do Subtest 2      Loopback Read/Write signals test
3850          Do Subtest 3      Loopback Write Strobe test
3851          Do Subtest 4      Loopback Read Strobe test
3852      END
3853
3854
3855
3856 051730      BGNTEST
3857 051730
3861 051730 012700 060142      MOV      @TST19ID,R0      ;ASCII MESSAGE TO IDENTIFY TEST
3862 051734 004737 016510      JSR      PC,TSTSETUP      ;DO INITIAL TEST SETUP
3863 051740 012737 000012 002216  MOV      @10.,LOOPCNT      ;PERFORM 10 ITERATIONS
3864 051746      T19LOOP:
3865
3866          .SBTTL TEST 8: SUBTEST 1: LOOPBACK CONTROL SIGNAL TEST
3867
3868      ;**
3869      ; TEST 8: SUBTEST 1:
3870      ;
3871      ; SUBTEST DESCRIPTION:
3872      ;
3873      ; This subtest verifies the Transport Control loopback
3874      ; path can transmit and receive correctly. The
3875      ; control signals are all loopback signals other
3876      ; than the read/write data (IM<7:0> and IR<7:0>).
3877      ;
3878      ; TEST STEPS:
3879      ;
3880      ; The loopback signals IFAD,ITAD0,ITAD1 are the tape unit select
3881      ; lines. Since reserved unit 7 must remain selected these signals
3882      ; are always set low. This further means the signals they drive
3883      ; (ISPEED,TRDY,IONL) are only tested in the low state.
3884      ;
3885      ; BEGIN
3886      ; Write to TSSR register to soft initialize the controller
3887      ; Do WRITE CHARACTERISTICS to check for Extended Features Switch
3888      ; If Extended Features Hardware Switch Clear then:
3889      ; Do Write Subsystem Write Miscellaneous to Set Extended Features.
3890      ; Do WRITE CHARACTERISTICS to select reserved unit 7 and setup BUFFER
3891      ; Do a Write Subsystem WRITE NPR to set tape direction out and Loopback
3892      ; Do Write Subsystem Write Control to CLEAR loopback signals group 1.
3893      ; Do Write Subsystem Write Format to CLEAR loopback signals group 2.
3894      ; (the loopback signals have to be cleared here due to the flip-flops
3895      ; that are set on a 1 to 0 transition (IHER,IFMK,ICER))
3896      ; Do a Write Subsystem Write Misc to Reset Tape Status F-FLOPS
3897      ; Do a Write Subsystem READ STATUS
3898      ; If all Tape Status 2 (ICER,IFMK,IHER) flip-flop
3899      ; signals NOT=0 Then Print Error
3900
3901      ; REPEAT FOR ALL TEST PATTERNS IN TSTBLK TABLE
3902      ; BEGIN
3903      ; Do Write Subsystem Write Control to Drive loopback signals group 1.
3904      ; Do Write Subsystem Write Format to Drive loopback signals group 2.
3905      ; Do a Write Subsystem READ STATUS
    
```

```

3906      ;      IF loopback data NOT= data sent Then Print Error
3907      ;      Do a Write Subsystem Write Misc to Reset Tape Status F FLOPS
3908      ;      Do a Write Subsystem READ STATUS
3909      ;      IF all Tape Status 2 (ICER,IFMK,IMER) #1 p flop
3910      ;      signals NOT=0 Then Print Error
3911      ;      END
3912      ;
3913 051746      BGNSUB      ;//////////////// BEGIN SUBTEST //////////////////
      051746      ;      T8.1:
      051746 1044C2      TRAP      C10SUB
3914
3915      ;      Write to TSSR register to soft initialize the controller
3916 051750      58:
3917 051750 004737 015774      JSR      PC,SOFINIT      ;WRITE TO TSSR TO SOFT INITIALIZE
3918 051754 103405      BCS      108      ;BR IF SOFT INIT OKAY
3919 051756 010001      MOV      R0,R1      ;SAVE CONTENTS OF TSSR
3920 051760      ERROF      ERRNO,SFIERR,SFIMSG      ;DEVICE FATAL DURING INIT
      051760 104455      TRAP      C1ERDF
      051762 001440      .WORD      800
      051764 003652      .WORD      SFIERR
      051766 012034      .WORD      SFIMSG
3921      ;      Do WRITE CHARACTERISTICS to check for Extended Features Switch
3922 051770 005037 002222      108:      CLR      FATFLG      ;CLEAR FATAL ERROR FLAG
3923 051774 012704 062270      MOV      @T19PACKET,R4      ;GET THE ADDRESS OF COMMAND PACKET
3924 052000 004737 010662      JSR      PC,WRTCHR      ;DO WRITE CHARACTERISTICS COMMAND
3925 052004      FORCERROR      128      ;BDDFORCE ERROR IF FORCER=1
3926 052020 103407      BCS      158      ;BR IF CARRY SET (GOOD RETURN)
3927 052022 010001      MOV      R0,R1      ;SAVE CONTENTS OF TSSR
3928 052024      NEXT.ERRNO
3929 052024      128:      ERROF      ERRNO,T19SSR,PKTSSR      ;DEVICE FATAL SSR FAILED TO SET
      052024 104455      TRAP      C1ERDF
      052026 001441      .WORD      801
      052030 060203      .WORD      T19SSR
      052032 012046      .WORD      PKTSSR
3930 052034 005237 002222      158:      INC      FAIFLG      ;SET FATAL ERROR FLAG
3931 052040      CKLOOP      ;LOOP ON ERROR, IF FLAG SET
      052040 104406      TRAP      C1CLP1
3932      ;      IF Extended Features Hardware Switch Clear then:
3933      ;      Do Write Subsystem Write Miscellaneous to Set Extended Features.
3934 052042 012701 062312      MOV      @T19BFR,R1      ;MESSAGE BUFFER ADDRESS
3935 052046 032761 000200 000012      BIT      @X2.EXTF,XST2(R1)      ;EXTENDED FEATURES SWITCH SET?
3936 052054 001026      BNE      308      ;BR IF YES
3937 052056 004737 062142      JSR      PC,T19SEXT      ;SETUP PACKET FOR WRITE MISC INVERT
3938 052062 012704 062440      MOV      @T19PK2,R4      ;GET WRITE SUBSYSTEM COMMAND PACKET
3939 052066 010465 000000      MOV      R4,TSDB(R5)      ;SET THE PACKET ADDRESS TO EXECUTE
3940 052072 004737 016336      JSR      PC,CHKTSSR      ;WAIT FOR SSR TO SET
3941 052076      FORCERROR      228      ;BDDFORCE ERROR IF FORCER=1
3942 052112 103407      BCS      308      ;BR IF CARRY SET (GOOD RETURN)
3943 052114 010001      MOV      R0,R1      ;SAVE CONTENTS OF TSSR
3944 052116      NEXT.ERRNO
3945 052116      228:      ERROF      ERRNO,T192SSR,PKTSSR      ;DEVICE FATAL SSR FAILED TO SET
      052116 104455      TRAP      C1ERDF
      052120 001442      .WORD      802
      052122 060240      .WORD      T192SSR
      052124 012046      .WORD      PKTSSR
3946 052126 005237 002222      308:      INC      FATFLG      ;SET FATAL ERROR FLAG
3947 052132      CKLOOP      ;LOOP ON ERROR, IF FLAG SET
    
```

```

052132 104406                                     TRAP C#CLP1
3948 ; Do WRITE CHARACTERISTICS to select reserved unit 7
3949 052134 005037 002222 CLR FATFLG ;CLEAR FATAL ERROR FLAG
3950 052140 012704 062270 MOV #T19PKET,R4 ;GET THE ADDRESS OF COMMAND PACKET
3951 052144 004737 010662 JSR PC,WRCHR ;DO WRITE CHARACTERISTICS COMMAND
3952 052150 FORCERROR 42# ;BDFORCE ERROR IF FORCER=1
3953 052164 103407 BCS 50# ;BR IF CARRY SET (GOOD RETURN)
3954 052166 010001 MOV R0,R1 ;SAVE CONTENTS OF TSSR
3955 052170 NEXT,ERRNO
3956 052170 42# : ERRDF ERRNO,T19SSR,PKTSSR ;DEVICE FATAL SSR FAILED TO SET
                                     TRAP C#ERDF
                                     .WORD 803
                                     .WORD T19SSR
                                     .WORD PKTSSR
052170 104455
052172 001443
052174 060203
052176 012046
3957 052200 005237 002222 INC FATFLG ;SET FATAL ERROR FLAG
3958 052204 50# : CKLOOP ;LOOP ON ERROR, IF FLAG SET
                                     TRAP C#CLP1
3959 ; Do a Write Subsystem WRITE NPR to set tape direction out and Loopback
3960 052206 012700 000100 MOV #NP.OUT,R0 ;SET TAPE DIRECTION OUT
3961 052212 052700 000040 BIS #NP.LOOP,R0 ;SET LOOPBACK ENABLE
3962 052216 004737 062002 JSR PC,T19SNPR ;SETUP T19PK2 FOR WRITE NPR
3963 052222 012704 062440 MOV #T19PK2,R4 ;GET WRITE SUBSYSTEM COMMAND PACKET
3964 052226 010465 000000 MOV R4,TSDB(R5) ;SET THE PACKET ADDRESS TO EXECUTE
3965 052232 004737 016336 JSR PC,CHKTSSR ;WAIT FOR SSR TO SET
3966 052236 FORCERROR 62# ;BDFORCE ERROR IF FORCER=1
3967 052252 103407 BCS 70# ;BR IF CARRY SET (GOOD RETURN)
3968 052254 010001 MOV R0,R1 ;SAVE CONTENTS OF TSSR
3969 052256 NEXT,ERRNO
3970 052256 62# : ERRDF ERRNO,T194SSR,PKTSSR ;DEVICE FATAL SSR FAILED TO SET
                                     TRAP C#ERDF
                                     .WORD 804
                                     .WORD T194SSR
                                     .WORD PKTSSR
052256 104455
052260 001444
052262 060351
052264 012046
3971 052266 005237 002222 INC FATFLG ;SET FATAL ERROR FLAG
3972 052272 70# : CKLOOP ;LOOP ON ERROR, IF FLAG SET
                                     TRAP C#CLP1
052272 104406
3973 ; Do Write Subsystem Write Control to CLEAR loopback signals group 1.
3974 ; Do Write Subsystem Write Format to CLEAR loopback signals group 2.
3975 ; (the loopback signals have to be cleared here due to the flip-flops
3976 ; that are set on a 1 to 0 transition (IHER,IFMK,ICER))
3977 052274 005000 CLR R0 ;WRITE 0'S
3978 052276 042700 000200 BIC #WC.IFAD,R0 ;IFAD MUST ALWAYS =0
3979 052302 042700 000100 BIC #WC.IOTAD,R0 ;ITADO MUST ALWAYS =0
3980 052306 042700 000040 BIC #WC.IITAD,R0 ;ITADI MUST ALWAYS =0
3981 052312 004737 062102 JSR PC,T19WCTL ;SETUP PACKET FOR WRITE CONTROL
3982 052316 012704 062440 MOV #T19PK2,R4 ;GET WRITE SUBSYSTEM COMMAND PACKET
3983 052322 010465 000000 MOV R4,TSDB(R5) ;SET THE PACKET ADDRESS TO EXECUTE
3984 052326 004737 016336 JSR PC,CHKTSSR ;WAIT FOR SSR TO SET
3985 052332 FORCERROR 82# ;BDFORCE ERROR IF FORCER=1
3986 052346 103407 BCS 90# ;BR IF CARRY SET (GOOD RETURN)
3987 052350 010001 MOV R0,R1 ;SAVE CONTENTS OF TSSR
3988 052352 NEXT,ERRNO
3989 052352 82# : ERRDF ERRNO,T197SSR,PKTSSR ;DEVICE FATAL SSR FAILED TO SET
                                     TRAP C#ERDF
                                     .WORD 805
                                     .WORD T197SSR
                                     .WORD PKTSSR
052352 104455
052354 001445
052356 060523
052360 012046

```

```

3990 052362 005237 002222          INC    FATFLG          ;SET FATAL ERROR FLAG
3991 052366          90$:  CKLOOP          ;LOOP ON ERROR, IF FLAG SET
                                TRAP    C:CLP1
3992 052370 005000          CLR    RO              ;SET FORMAT DRIVE DATA=0
3993 052372 004737 062122          JSR    PC,T19WFMT      ;SETUP PACKET FOR WRITE FORMAT
3994 052376 012704 062440          MOV    @T19PK2,R4      ;GET WRITE SUBSYSTEM COMMAND PACKET
3995 052402 010465 000000          MOV    R4,TSDB(R5)     ;SET THE PACKET ADDRESS TO EXECUTE
3996 052406 004737 016336          JSR    PC,CHKTSSR      ;WAIT FOR SSR TO SET
3997 052412          FORCERROR 102$      ;GOODFORCE ERROR IF FORCER=1
3998 052426 103407          BCS    110$           ;BR IF CARRY SET (GOOD RETURN)
3999 052430 010001          MOV    RO,R1          ;SAVE CONTENTS OF TSSR
4000 052432          NEXT.ERRNO
4001 052432          102$: ERRDF  ERRNO,T198SSR,PKTSSR ;DEVICE FATAL SSR FAILED TO SET
                                TRAP    C:ERDF
                                .WORD  806
                                .WORD  T198SSR
                                .WORD  PKTSSR
4002 052442 005237 002222          INC    FATFLG          ;SET FATAL ERROR FLAG
4003 052446          110$: CKLOOP          ;LOOP ON ERROR, IF FLAG SET
                                TRAP    C:CLP1
4004          ; Do a Write Subsystem Write Misc to Reset Tape Status F-FLOPS
4005 052450 004737 061760          JSR    PC,T19RSFIF     ;SETUP PKT FOR WRITE MISC Reset Tape Status F-FLOPS
4006 052454 012704 062440          MOV    @T19PK2,R4      ;GET WRITE SUBSYSTEM COMMAND PACKET
4007 052460 010465 000000          MOV    R4,TSDB(R5)     ;SET THE PACKET ADDRESS TO EXECUTE
4008 052464 004737 016336          JSR    PC,CHKTSSR      ;WAIT FOR SSR TO SET
4009 052470          FORCERROR 122$      ;GOODFORCE ERROR IF FORCER=1
4010 052504 103407          BCS    130$           ;BR IF CARRY SET (GOOD RETURN)
4011 052506 010001          MOV    RO,R1          ;SAVE CONTENTS OF TSSR
4012 052510          NEXT.ERRNO
4013 052510          122$: ERRDF  ERRNO,T192SSR,PKTSSR ;DEVICE FATAL SSR FAILED TO SET
                                TRAP    C:ERDF
                                .WORD  807
                                .WORD  T192SSR
                                .WORD  PKTSSR
4014 052520 005237 002222          INC    FATFLG          ;SET FATAL ERROR FLAG
4015 052524          130$: CKLOOP          ;LOOP ON ERROR, IF FLAG SET
                                TRAP    C:CLP1
4016          ; Do a Write Subsystem READ STATUS
4017          ; If all Tape Status 2 (ICER,IFMK,IMER) flip-flop
4018          ; signals NOT=0 Then Print Error
4019 052526 004737 061740          JSR    PC,T19SRD       ;SETUP PACKET FOR READ STATUS
4020 052532 012704 062440          MOV    @T19PK2,R4      ;GET WRITE SUBSYSTEM COMMAND PACKET
4021 052536 010465 000000          MOV    R4,TSDB(R5)     ;SET THE PACKET ADDRESS TO EXECUTE
4022 052542 004737 016336          JSR    PC,CHKTSSR      ;WAIT FOR SSR TO SET
4023 052546          FORCERROR 132$      ;GOODFORCE ERROR IF FORCER=1
4024 052562 103407          BCS    140$           ;BR IF CARRY SET (GOOD RETURN)
4025 052564 010001          MOV    RO,R1          ;SAVE CONTENTS OF TSSR
4026 052566          NEXT.ERRNO
4027 052566          132$: ERRDF  ERRNO,T193SSR,PKTSSR ;DEVICE FATAL SSR FAILED TO SET
                                TRAP    C:ERDF
                                .WORD  808
                                .WORD  T193SSR
                                .WORD  PKTSSR
4028 052576 005237 002222          INC    FATFLG          ;SET FATAL ERROR FLAG
4029 052602          140$: CKLOOP          ;LOOP ON ERROR, IF FLAG SET
                                TRAP    C:CLP1
4030 052604 004737 062200          JSR    PC,T19SETEXP    ;SET WORDS 0-7 EXPD=RECV (NOT TESTING)

```

```

4031 052610 012701 060042      MOV      @T19EXSTA,R1      ;GET EXPECTED READ STATUS
4032 052614 012702 062332      MOV      @T19BFSTA,R2     ;GET RECV READ STATUS
4033 052620 011211              MOV      (R2),(R1)        ;SET EXPD WORD #8 = RECV TEMP
4034 052622 042711 002000      BIC      @S1.ICER,(R1)    ;SET EXPD ICER =0
4035 052626 042711 001000      BIC      @S1.IFMK,(R1)   ;SET EXPD IFMK =0
4036 052632 042711 000400      BIC      @S1.IHER,(R1)   ;SET EXPD IHER =0
4037 052636 016261 000002 000002  MOV      2(R2),2(R1)     ;SET EXPD WORD #9 = RECV (NOT TESTING)
4038 052644 005000              CLR      R0              ;HIGH RECV ADDRESS FOR CKMSG2
4039 052646 012701 062312      MOV      @T19BFR,R1      ;LOW RECV ADDRESS FOR CKMSG2
4040 052652 012702 060022      MOV      @T19EXP,R2      ;EXPD ADDRESS
4041 052656 012703 000024      MOV      @20.,R3         ;NUMBER OF BYTES TO COMPARE
4042 052662 004737 011500      JSR      PC,CKMSG2       ;EXPD EQUAL RECV?
4043 052666              FORCERROR 152$,NOTS:A    ;BBD
4044 052676 103404              BCS     160$            ;BR IF YES
4045 052700              NEXT.ERRNO
4046 052700 152$:  ERRHRD  ERRNO,T197CMP,MSGLOOP ;REPORT ERROR
                                TRAP      C1ERHRD
                                .WORD    809
                                .WORD    T197CMP
                                .WORD    MSGLOOP
4047 052710 160$:  CKLOOP              ;LOOP ON ERROR, IF FLAG SET
                                TRAP      C1CLP1
                                .WORD    104456
                                .WORD    001451
                                .WORD    061243
                                .WORD    013064
4048 052710 104406              ; REPEAT FOR ALL TEST PATTERNS IN TSTBLK TABLE
4049 052712 005037 057754      CLR      T19PREV         ;INIT 1-0 TRANSITION FLAG
4050 052716 012703 002752      MOV      @TSTBLK,R3      ;GET FIRST PATTERN ADDRESS
4051 052722 012300 200$:  MOV      (R3),R0         ;GET A TEST PATTERN
4052 052724 010337 002316      MOV      R3,TSTPTR       ;SAVE POINTER INTO TSTBLK
4053 052730 042700 000200      BIC      @WC.IFAD,R0     ;IFAD MUST ALWAYS =0
4054 052734 042700 000100      BIC      @WC.IOTAD,R0    ;ITADO MUST ALWAYS =0
4055 052740 042700 000040      BIC      @WC.IITAD,R0    ;ITAD1 MUST ALWAYS =0
4056 052744 010037 002312      MOV      R0,DATA        ;SET DATA PATTERN
4057              ; Do Write Subsystem Write Control to Drive loopback signals group 1.
4058              ;BBD CALL T19CNVT TO SETUP WRITE CONTROL PATTERN
4059 052750 013700 002312      MOV      DATA,R0       ;GET TEST PATTERN
4060 052754 004737 062224      JSR      PC,T19CNVT     ;CONVERT PATTERN TO CONTROL DRIVE MASK
4061              ;R0 CONTAINS WRITE CONTROL DATA HERE
4062 052760 004737 062102      JSR      PC,T19WCTL     ;SETUP PACKET FOR WRITE CONTROL
4063 052764 012704 062440      MOV      @T19PK2,R4     ;GET WRITE SUBSYSTEM COMMAND PACKET
4064 052770 010465 000000      MOV      R4,TSD8(R5)    ;SET THE PACKET ADDRESS TO EXECUTE
4065 052774 004737 016336      JSR      PC,CHKTSSR     ;WAIT FOR SSR TO SET
4066 053000              FORCERROR 212$          ;BBDFORCE ERROR IF FORCER=1
4067 053014 103407              BCS     220$            ;BR IF CARRY SET (GOOD RETURN)
4068 053016 010001              MOV      R0,R1          ;SAVE CONTENTS OF TSSR
4069 053020              NEXT.ERRNO
4070 053020 212$:  ERRDF  ERRNO,T197SSR,PKTSSR ;DEVICE FATAL SSR FAILED TO SET
                                TRAP      C1ERDF
                                .WORD    810
                                .WORD    T197SSR
                                .WORD    PKTSSR
4071 053030 005237 002222      INC      FATFLG         ;SET FATAL ERROR FLAG
4072 053034 220$:  CKLOOP              ;LOOP ON ERROR, IF FLAG SET
                                TRAP      C1CLP1
                                .WORD    104406
4073              ; Do Write Subsystem Write Format to Drive loopback signals group 2.
4074              ;BBD CALL T19CNVT TO SETUP WRITE CONTROL PATTERN
4075              ;BBD
4076 053036 013700 002312      MOV      DATA,R0       ;GET TEST PATTERN
4077 053042 004737 062224      JSR      PC,T19CNVT     ;CONVERT PATTERN TO FORMAT DRIVE MASK

```

```

4078 053046 000300          SWAB    R0          ;WRITE FORMAT DATA RETURNED IN HIGH BYTE
4079 053050 004737 062122    JSR     PC,T19WFMT  ;SETUP PACKET FOR WRITE FORMAT
4080 053054 012704 062440    MOV     #T19PK2,R4  ;GET WRITE SUBSYSTEM COMMAND PACKET
4081 053060 010465 000000    MOV     R4,TSDB(R5) ;SET THE PACKET ADDRESS TO EXECUTE
4082 053064 004737 016336    JSR     PC,CHKTSSR  ;WAIT FOR SSR TO SET
4083 053070          FORCERROR 232#      ;BDDFORCE ERROR IF FORCER=1
4084 053104 103407          BCS     240#        ;BR IF CARRY SET (GOOD RETURN)
4085 053106 010001          MOV     R0,R1       ;SAVE CONTENTS OF TSSR
4086 053110          NEXT.ERRNO
4087 053110          232#: ERRDF   ERRNO,T198SSR,PKTSSR ;DEVICE FATAL SSR FAILED TO SET
                                TRAP    C#ERDF
                                .WORD   811
                                .WORD   T198SSR
                                .WORD   PKTSSR
                                4088 053120 005237 002222          INC     FATFLG      ;SET FATAL ERROR FLAG
                                4089 053124          240#: CKLOOP      ;LOOP ON ERROR, IF FLAG SET
                                                TRAP    C#CLP1
; Do a Write Subsystem READ STATUS
4091 053126 004737 061740    JSR     PC,T19SRD   ;SETUP PACKET FOR READ STATUS
4092 053132 012704 062440    MOV     #T19PK2,R4  ;GET WRITE SUBSYSTEM COMMAND PACKET
4093 053136 010465 000000    MOV     R4,TSDB(R5) ;SET THE PACKET ADDRESS TO EXECUTE
4094 053142 004737 016336    JSR     PC,CHKTSSR  ;WAIT FOR SSR TO SET
4095 053146          FORCERROR 252#      ;BDDFORCE ERROR IF FORCER=1
4096 053162 103407          BCS     260#        ;BR IF CARRY SET (GOOD RETURN)
4097 053164 010001          MOV     R0,R1       ;SAVE CONTENTS OF TSSR
4098 053166          NEXT.ERRNO
4099 053166          252#: ERRDF   ERRNO,T193SSR,PKTSSR ;DEVICE FATAL SSR FAILED TO SET
                                                TRAP    C#ERDF
                                                .WORD   812
                                                .WORD   T193SSR
                                                .WORD   PKTSSR
                                4100 053176 005237 002222          INC     FATFLG      ;SET FATAL ERROR FLAG
                                4101 053202          260#: CKLOOP      ;LOOP ON ERROR, IF FLAG SET
                                                TRAP    C#CLP1
; If loopback data NOT= data sent Then Print Error
4103 053204 004737 062200    JSR     PC,T19SETEXP ;SET WORDS 0-7 EXPD=RCV (NOT TESTING)
4104 053210 012701 060042    MOV     #T19EXSTA,R1 ;GET EXPECTED READ STATUS
4105 053214 012702 062332    MOV     #T19BFSTA,R2 ;GET RCV READ STATUS
4106 053220 013711 002312    MOV     DATA,(R1)   ;SET EXPD WORD #8 TO TEST DATA FIRST
4107 053224 013700 057754    MOV     T19PREV,R0   ;GET PREVIOUS DATA PATTERN
4108 053230 013703 002312    MOV     DATA,R3     ;GET CURRENT PATTERN
4109 053234 012704 000400    MOV     #S1.IHER,R4  ;SETUP IHER EXPECTED
4110 053240 040411          BIC     R4,(R1)      ;SET EXPD IHER =0
4111 053242 030400          BIT     R4,R0        ;PREVIOUS =1?
4112 053244 001403          BEQ     275#         ;BR IF NO
4113 053246 030403          BIT     R4,R3        ;CURRENT =0?
4114 053250 001001          BNE     275#         ;BR IF NO
4115 053252 050411          BIS     R4,(R1)      ;SET EXPD IHER =1
4116 053254 012704 001000          275#: MOV     #S1.IFMK,R4 ;SETUP IFMK EXPECTED
4117 053260 040411          BIC     R4,(R1)      ;SET EXPD IFMK =0
4118 053262 030400          BIT     R4,R0        ;PREVIOUS =1?
4119 053264 001403          BEQ     280#         ;BR IF NO
4120 053266 030403          BIT     R4,R3        ;CURRENT =0?
4121 053270 001001          BNE     280#         ;BR IF NO
4122 053272 050411          BIS     R4,(R1)      ;SET EXPD IFMK =1
4123 053274 012704 002000          280#: MOV     #S1.ICER,R4 ;SETUP ICER EXPECTED
4124 053300 040411          BIC     R4,(R1)      ;SET EXPD ICER =0

```

```

4125 053302 030400          BIT      R4,R0          ;PREVIOUS =1?
4126 053304 001403          BEQ     285$          ;BR IF NO
4127 053306 030403          BIT     R4,R3          ;CURRENT =0?
4128 053310 001001          BNE    285$          ;BR IF NO
4129 053312 050411          BIS    R4,(R1)        ;SET EXPD ICER =1
4130 053314 011100          285$: MOV    (R1),R0      ;GET EXPD WORD
4131          ; If previous IIDENT=1 and current is IIDENT=1 then EXPD= 0 else 1
4132 053316 012704 004000      MOV    #S1.IIDENT,R4   ;IIDENT
4133 053322 050400          BIS    R4,R0          ;ASSUME EXPD=1
4134 053324 030437 057754      BIT    R4,T19PREV     ;PREVIOUS IIDENT=1?
4135 053330 001403          BEQ    288$          ;BR IF NO
4136 053332 030403          BIT    R4,R3          ;IS CURRENT IIDENT=1?
4137 053334 001401          BEQ    288$          ;BR IF NO
4138 053336 040400          BIC    R4,R0          ;SET EXPD=0
4139 053340 052700 040000      288$: BIS    #S1.I2RES,R0 ;IRESV2 EXPD ALWAYS=1
4140 053344 052700 020000      BIS    #S1.I1RES,R0   ;IRESV1 EXPD ALWAYS=1
4141 053350 042700 100000      BIC    #S1.PARERR,R0  ;IGNORE PARERR
4142 053354 032712 100000      BIT    #S1.PARERR,(R2); IS PARERR SET IN RECV?
4143 053360 001402          BEQ    290$          ;BR IF NO
4144 053362 052700 100000      BIS    #S1.PARERR,R0  ;SET IN EXPD
4145 053366 010011          290$: MOV    R0,(R1)    ;SETUP FINAL EXPD IN WORD #8
4146 053370 016261 000002 000002 MOV    2(R2),2(R1)    ;SET EXPD WORD #9 = RECV (NOT TESTING)
4147 053376 005000          CLR    R0            ;HIGH RECV ADDRESS FOR CKMSG2
4148 053400 012701 062312      MOV    #T19BFR,R1     ;LOW RECV ADDRESS FOR CKMSG2
4149 053404 012702 060022      MOV    #T19EXP,R2     ;EXPD ADDRESS
4150 053410 012703 000024      MOV    #20,R3         ;NUMBER OF BYTES TO COMPARE
4151 053414 004737 011500      JSR    PC,CKMSG2      ;EXPD EQUAL RECV?
4152 053420          FORCERROR 302$,NOTSSR ;BBD
4153 053430 103404          BCS    310$          ;BR IF YES
4154 053432          NEXT.ERRNO
4155 053432          302$: ERHRD  ERRNO,T198CMP,MSGLOOP ;REPORT ERROR
          TRAP    C$ERHRD
          .WORD   813
          .WORD   T198CMP
          .WORD   MSGLOOP
4156 053442          310$: CKLOOP          ;LOOP ON ERROR, IF FLAG SET
          TRAP    C$CLP1
4157          ; Do a Write Subsystem Write Misc to Reset Tape Status F-FLOPS
4158 053444 004737 061760      JSR    PC,T19RSFIF    ;SETUP PKT FOR WRITE MISC Reset STATUS
4159 053450 012704 062440      MOV    #T19PK2,R4     ;GET WRITE SUBSYSTEM COMMAND PACKET
4160 053454 010465 000000      MOV    R4,TSDB(R5)    ;SET THE PACKET ADDRESS TO EXECUTE
4161 053460 004737 016336      JSR    PC,CHKTSSR     ;WAIT FOR SSR TO SET
4162 053464          FORCERROR 322$          ;BBDFORCE ERROR IF FORCER=1
4163 053500 103407          BCS    330$          ;BR IF CARRY SET (GOOD RETURN)
4164 053502 010001          MOV    R0,R1         ;SAVE CONTENTS OF TSSR
4165 053504          NEXT.ERRNO
4166 053504          322$: ERDF  ERRNO,T192SSR,PKTSSR ;DEVICE FATAL SSR FAILED TO SET
          TRAP    C$ERDF
          .WORD   814
          .WORD   T192SSR
          .WORD   PKTSSR
4167 053514 005237 002222          INC    FATFLG        ;SET FATAL ERROR FLAG
4168 053520          330$: CKLOOP          ;LOOP ON ERROR, IF FLAG SET
          TRAP    C$CLP1
4169          ; Do a Write Subsystem READ STATUS
4170 053522 004737 061740      JSR    PC,T19SRD     ;SETUP PACKET FOR READ STATUS
4171 053526 012704 062440      MOV    #T19PK2,R4     ;GET WRITE SUBSYSTEM COMMAND PACKET

```



J15

```

4172 053532 010465 000000      MOV      R4,TSDB(R5)      ;SET THE PACKET ADDRESS TO EXECUTE
4173 053536 004737 016336      JSR      PC,CHKTSSR      ;WAIT FOR SSR TO SET
4174 053542                    FORCERROR 342$          ;GOODFORCE ERROR IF FORCER=1
4175 053556 103407                    BCS      350$          ;BR IF CARRY SET (GOOD RETURN)
4176 053560 010001                    MOV      R0,R1          ;SAVE CONTENTS OF TSSR
4177 053562                    NEXT.ERRNO
4178 053562 342$:  ERRDF  ERRNO,T193SSR,PKTSSR ;DEVICE FATAL SSR FAILED TO SET
                                TRAP      C#ERDF
                                .WORD    815
                                .WORD    T193SSR
                                .WORD    PKTSSR
                                053562 104455
                                053564 001457
                                053566 060304
                                053570 012046
4179 053572 005237 002222      INC      FATFLG          ;SET FATAL ERROR FLAG
4180 053576 350$:  CKLOOP                    ;LOOP ON ERROR, IF FLAG SET
                                TRAP      C#CLP1
4181 053600 004737 062200      JSR      PC,T19SETEXP    ;SET WORDS 0-7 EXPD=RCV (NOT TESTING)
4182 053604 012701 060042      MOV      #T19EXSTA,R1    ;GET EXPECTED READ STATUS
4183 053610 012702 062332      MOV      #T198FSTA,R2    ;GET RCV READ STATUS
4184 053614 011211                    MOV      (R2),(R1)       ;SET EXPD WORD #8 = RCV TEMP
4185 053616 042711 002000      BIC      #S1.ICER,(R1)    ;SET EXPD ICER =0
4186 053622 042711 001000      BIC      #S1.IFMK,(R1)    ;SET EXPD IFMK =0
4187 053626 042711 000400      BIC      #S1.IHER,(R1)    ;SET EXPD IHER =0
4188 053632 016261 000002 000002  MOV      2(R2),2(R1)      ;SET EXPD WORD #9 = RCV (NOT TESTING)
4189 053640 005000                    CLR      R0              ;HIGH RCV ADDRESS FOR CKMSG2
4190 053642 012701 062312      MOV      #T198FR,R1       ;LOW RCV ADDRESS FOR CKMSG2
4191 053646 012702 060022      MOV      #T19EXP,R2       ;EXPD ADDRESS
4192 053652 012703 000024      MOV      #20.,R3          ;NUMBER OF BYTES TO COMPARE
4193 053656 004737 011500      JSR      PC,CKMSG2        ;EXPD EQUAL RCV?
4194 053662                    FORCERROR 362$,NOTSSR    ;GOOD
4195 053672 103404                    BCS      370$          ;BR IF YES
4196 053674                    NEXT.ERRNO
4197 053674 362$:  ERRHRD  ERRNO,T197CMP,MSGSTAT ;REPORT ERROR
                                TRAP      C#ERRRD
                                .WORD    816
                                .WORD    T197CMP
                                .WORD    MSGSTAT
                                053674 104456
                                053676 001460
                                053700 061243
                                053702 012350
4198 053704 370$:  CKLOOP                    ;LOOP ON ERROR, IF FLAG SET
                                TRAP      C#CLP1
                                053704 104406
4199
4200 053706 013737 002312 057754  MOV      DATA,T19PREV    ;SETUP PREVIOUS DATA FOR EXPD CALC.
4201 053714 013703 002316      MOV      TSTPTR,R3        ;RESTORE CURRENT TSTBLK POINTER
4202 053720 020327 003062      CMP      R3,#TBLEND       ;END OF TSTBLK?
4203 053724 103002                    BHS      400$          ;BR IF YES
4204 053726 000137 052722      JMP      200$            ;DO NEXT TSTBLK PATTERN
4205 053732 400$:
4206
4207 053732                    ENDSUB                    ;////////// END SUBTEST //////////
                                L10067:
                                TRAP      C#ESUB
                                053732 104403
4208
4209 053734 005737 002222      TST      FATFLG          ;ANY FATAL ERRORS ?
4210 053740 001402                    BEQ      460$          ;BRANCH IF NOT
4211 053742 004737 017202      JSR      PC,CKDROP        ;TRY TO DROP THE UNIT
4212 053746 460$:
4213
4214
4215
4216

```

4217  
 4218  
 4219  
 4220  
 4221  
 4222  
 4223  
 4224  
 4225  
 4226  
 4227  
 4228  
 4229  
 4230  
 4231  
 4232  
 4233  
 4234  
 4235  
 4236  
 4237  
 4238  
 4239  
 4240  
 4241  
 4242  
 4243  
 4244  
 4245  
 4246  
 4247  
 4248  
 4249  
 4250  
 4251  
 4252  
 4253  
 4254  
 4255  
 4256  
 4257  
 4258  
 4259  
 4260  
 4261  
 4262  
 4263  
 4264  
 4265  
 4266  
 4267

.SBTTL TEST 8: SUBTEST 2: LOOPBACK READ/WRITE SIGNALS TEST

```

; **
; TEST 8: SUBTEST 2:
; SUBTEST DESCRIPTION:
;
; This subtest verifies the Read/Write data loopback path.
; The Read/Write data signals are IR<7:0> and IW<7:0>
; respectively.
; TEST STEPS:
;
; REPEAT FOR ALL TEST PATTERNS IN TSTBLK TABLE
; BEGIN
; Write to TSSR register to soft initialize the controller
; Do WRITE CHARACTERISTICS to check for Extended Features Switch
; If Extended Features Hardware Switch Clear then:
;   Do Write Subsystem Write Miscellaneous to Set Extended Features.
; Do WRITE CHARACTERISTICS to select reserved unit 7 and setup BUFFER
; Do a Write Subsystem WRITE NPR to set tape direction out and Loopback
; Do a WRITE NPR to set loopback and tape direction OUT
; Do a WRITE FIFO with byte count equal to 1 and Tape direction OUT
; Do a READ FIFO with tape direction OUT to load tape out write latch
; Do a WRITE NPR to set loopback and tape direction IN
; Do a WRITE FIFO with byte count equal to 1 and Tape direction IN
;   to strobe loopback data into FIFO.
; Do a READ FIFO with tape direction IN to read data
; If Data read from FIFO NOT= to Data sent Then Print Error
; Do a Write Subsystem READ STATUS
; If Input Ready NOT=1 Then Print Error
; If Output Ready NOT=0 Then Print Error
; If Data In Miss NOT=0 Then Print Error
; END
; --
; BGNSUB ;//////////////// BEGIN SUBTEST //////////////////
; T8.2: TRAP C#BSUB
; Write to TSSR register to soft initialize the controller
; 54:
; JSR PC,SOFINIT ;WRITE TO TSSR TO SOFT INITIALIZE
; BCS 104 ;BR IF SOFT INIT OKAY
; MOV R0,R1 ;SAVE CONTENTS OF TSSR
; ERDF ERRNO,SFIERR,SFIMSG ;DEVICE FATAL DURING INIT
; TRAP C#ERDF
; .WORD 816
; .WORD SFIERR
; .WORD SFIMSG
; Do WRITE CHARACTERISTICS to check for Extended Features Switch
; 104: CLR FATFLG ;CLEAR FATAL ERROR FLAG
; MOV #T19PACKET,R4 ;GET THE ADDRESS OF COMMAND PACKET
; JSR PC,WRTCHR ;DO WRITE CHARACTERISTICS COMMAND
; FORCERROR 124 ;SDFORCE ERROR IF FORCER=1
; BCS 154 ;BR IF CARRY SET (GOOD RETURN)
; MOV R0,R1 ;SAVE CONTENTS OF TSSR

```



```

4268 054024          NEXT.ERRNO
4269 054024          12$:  ERRDF  ERRNO,T19SSR,PKTSSR      ;DEVICE FATAL SSR FAILED TO SET
      054024 104455          TRAP  C$ERDF
      054026 001461          .WORD  817
      054030 060203          .WORD  T19SSR
      054032 012046          .WORD  PKTSSR
4270 054034 005237 002222      INC  FATFLG          ;SET FATAL ERROR FLAG
4271 054040          15$:  CKLOOP          ;LOOP ON ERROR, IF FLAG SET
      054040 104406          TRAP  C$CLP1
4272          ;      If Extended Features Hardware Switch Clear then:
4273          ;      Do Write Subsystem Write Miscellaneous to Set Extended Features.
4274 054042 012701 062312      MOV  #T19BFR,R1      ;MESSAGE BUFFER ADDRESS
4275 054046 032761 000200 000012  BIT  #X2.EXTF,XST2(R1) ;EXTENDED FEATURES SWITCH SET?
4276 054054 001026          BNE  30$            ;BR IF YES
4277 054056 004737 062142      JSR  PC,T19SEXT      ;SETUP PACKET FOR WRITE MISC INVERT
4278 054062 012704 062440      MOV  #T19PK2,R4      ;GET WRITE SUBSYSTEM COMMAND PACKET
4279 054066 010465 000000      MOV  R4,TSDB(R5)    ;SET THE PACKET ADDRESS TO EXECUTE
4280 054072 004737 016336      JSR  PC,CHKTSSR      ;WAIT FOR SSR TO SET
4281 054076          FORCERROR 22$          ;BDFORCE ERROR IF FORCER=1
4282 054112 103407          BCS  30$            ;BR IF CARRY SET (GOOD RETURN)
4283 054114 010001          MOV  R0,R1            ;SAVE CONTENTS OF TSSR
4284 054116          NEXT.ERRNO
4285 054116          22$:  ERRDF  ERRNO,T192SSR,PKTSSR      ;DEVICE FATAL SSR FAILED TO SET
      054116 104455          TRAP  C$ERDF
      054120 001462          .WORD  818
      054122 060240          .WORD  T192SSR
      054124 012046          .WORD  PKTSSR
4286 054126 005237 002222      INC  FATFLG          ;SET FATAL ERROR FLAG
4287 054132          30$:  CKLOOP          ;LOOP ON ERROR, IF FLAG SET
      054132 104406          TRAP  C$CLP1
4288          ;      Do WRITE CHARACTERISTICS to select reserved unit 7
4289 054134 012704 062270      MOV  #T19PACKET,R4  ;GET THE ADDRESS OF COMMAND PACKET
4290 054140 004737 010662      JSR  PC,WRTCHR      ;DO WRITE CHARACTERISTICS COMMAND
4291 054144          FORCERROR 42$          ;BDFORCE ERROR IF FORCER=1
4292 054160 103407          BCS  50$            ;BR IF CARRY SET (GOOD RETURN)
4293 054162 010001          MOV  R0,R1            ;SAVE CONTENTS OF TSSR
4294 054164          NEXT.ERRNO
4295 054164          42$:  ERRDF  ERRNO,T19SSR,PKTSSR      ;DEVICE FATAL SSR FAILED TO SET
      054164 104455          TRAP  C$ERDF
      054166 001463          .WORD  819
      054170 060203          .WORD  T19SSR
      054172 012046          .WORD  PKTSSR
4296 054174 005237 002222      INC  FATFLG          ;SET FATAL ERROR FLAG
4297 054200          50$:  CKLOOP          ;LOOP ON ERROR, IF FLAG SET
      054200 104406          TRAP  C$CLP1
4298
4299
4300          ; REPEAT FOR ALL TEST PATTERNS IN TSTBLK TABLE
4301 054202 012703 002752      MOV  #TSTBLK,R3      ;GET FIRST PATTERN ADDRESS
4302 054206 012337 002312      100$: MOV  (R3)+,DATA      ;GET A TEST PATTERN
4303 054212 042737 177400 002312  BIC  #+C<377>,DATA  ;DATA IS BYTE
4304 054220 010337 002316      MOV  R3,TSTPTR      ;SETUP CURRENT TSTBLK POINTER
4305          ;      Do a WRITE NPR to set loopback and tape direction OUT
4306 054224 012700 000100      MOV  #NP.OUT,R0     ;SET TAPE DIRECTION OUT
4307 054230 052700 000040      BIS  #NP.LOOP,R0    ;SET LOOPBACK
4308 054234 004737 062002      JSR  PC,T19SNPR     ;SETUP T19PK2 FOR WRITE NPR
4309 054240 012704 062440      MOV  #T19PK2,R4      ;GET WRITE SUBSYSTEM COMMAND PACKET
  
```

```

4310 054244 010465 000000      MOV      R4,TSDB(R5)      ;SET THE PACKET ADDRESS TO EXECUTE
4311 054250 004737 016336      JSR      PC,CHKTSSR      ;WAIT FOR SSR TO SET
4312 054254          FORCERROR      102$      ;BDDFORCE ERROR IF FORCER=1
4313 054270 103407          BCS      105$      ;BR IF CARRY SET (GOOD RETURN)
4314 054272 010001          MOV      R0,R1      ;SAVE CONTENTS OF TSSR
4315 054274          NEXT,ERRNO
4316 054274 102$:      ERRDF      ERRNO,T194SSR,PKTSSR      ;DEVICE FATAL SSR FAILED TO SET
                                TRAP      C$ERDF
                                .WORD      820
                                .WORD      T194SSR
                                .WORD      PKTSSR
                                054274 104455
                                054276 001464
                                054300 060351
                                054302 012046
4317 054304 005237 002222      INC      FATFLG      ;SET FATAL ERROR FLAG
4318 054310 105$:      CKLOOP      ;LOOP ON ERROR, IF FLAG SET
                                TRAP      C$CLP1
                                ; Do a WRITE FIFO with byte count equal to 1 and Tape direction OUT
4319          ;
4320 054312 012700 000001      MOV      #1,R0      ;WRITE 1 BYTE
4321 054316 012701 002312      MOV      #DATA,R1      ;FIFO WRITE DATA ADDRESS
4322 054322 004737 062046      JSR      PC,T19WFIF      ;SETUP T19PK2 FOR WRITE FIFO
4323 054326 012704 062440      MOV      >T19PK2,R4      ;GET WRITE SUBSYSTEM COMMAND PACKET
4324 054332 010465 000000      MOV      R4,TSDB(R5)      ;SET THE PACKET ADDRESS TO EXECUTE
4325 054336 004737 016336      JSR      PC,CHKTSSR      ;WAIT FOR SSR TO SET
4326 054342          FORCERROR      107$      ;BDDFORCE ERROR IF FORCER=1
4327 054356 103407          BCS      110$      ;BR IF CARRY SET (GOOD RETURN)
4328 054360 010001          MOV      R0,R1      ;SAVE CONTENTS OF TSSR
4329 054362          NEXT,ERRNO
4330 054362 107$:      ERRDF      ERRNO,T195SSR,PKTSSR      ;DEVICE FATAL SSR FAILED TO SET
                                TRAP      C$ERDF
                                .WORD      821
                                .WORD      T195SSR
                                .WORD      PKTSSR
                                054362 104455
                                054364 001465
                                054366 060414
                                054370 012046
4331 054372 005237 002222      INC      FATFLG      ;SET FATAL ERROR FLAG
4332 054376 110$:      CKLOOP      ;LOOP ON ERROR, IF FLAG SET
                                TRAP      C$CLP1
                                ; Do a READ FIFO with tape direction OUT to load tape out write latch
4333          ;
4334 054400 012700 000001      MOV      #1,R0      ;SET READ BYTE COUNT
4335 054404 004737 062026      JSR      PC,T19RFIF      ;SETUP T19PK2 FOR READ FIFO
4336 054410 012704 062440      MOV      #T19PK2,R4      ;GET WRITE SUBSYSTEM COMMAND PACKET
4337 054414 010465 000000      MOV      R4,TSDB(R5)      ;SET THE PACKET ADDRESS TO EXECUTE
4338 054420 004737 016336      JSR      PC,CHKTSSR      ;WAIT FOR SSR TO SET
4339 054424          FORCERROR      122$      ;BDDFORCE ERROR IF FORCER=1
4340 054440 103407          BCS      130$      ;BR IF CARRY SET (GOOD RETURN)
4341 054442 010001          MOV      R0,R1      ;SAVE CONTENTS OF TSSR
4342 054444          NEXT,ERRNO
4343 054444 122$:      ERRDF      ERRNO,T196SSR,PKTSSR      ;DEVICE FATAL SSR FAILED TO SET
                                TRAP      C$ERDF
                                .WORD      822
                                .WORD      T196SSR
                                .WORD      PKTSSR
                                054444 104455
                                054446 001466
                                054450 060460
                                054452 012046
4344 054454 005237 002222      INC      FATFLG      ;SET FATAL ERROR FLAG
4345 054460 130$:      CKLOOP      ;LOOP ON ERROR, IF FLAG SET
                                TRAP      C$CLP1
                                ; Do a WRITE NPR to set loopback and tape direction IN
4346          ;
4347 054462 005000          CLR      R0      ;CLR NP.OUT TO SET TAPE DIRECTION IN
4348 054464 052700 000040          BIS      #NP.LOOP,R0      ;SET LOOPBACK
4349 054470 004737 062002      JSR      PC,T19SNPR      ;SETUP T19PK2 FOR WRITE NPR
4350 054474 012704 062440      MOV      #T19PK2,R4      ;GET WRITE SUBSYSTEM COMMAND PACKET
4351 054500 010465 000000      MOV      R4,TSDB(R5)      ;SET THE PACKET ADDRESS TO EXECUTE

```

```

4352 054504 004737 016336      JSR      PC,CHKTSSR      ;WAIT FOR SSR TO SET
4353 054510                    FORCERROR      142$      ;BDFORCE ERROR IF FORCER=1
4354 054524 103407            BCS      150$          ;BR IF CARRY SET (GOOD RETURN)
4355 054526 010001            MOV      R0,R1         ;SAVE CONTENTS OF TSSR
4356 054530                    NEXT.ERRNO
4357 054530 142$:            ERDF      ERRNO,T194SSR,PKTSSR ;DEVICE FATAL SSR FAILED TO SET
                                TRAP      C$ERDF
                                .WORD      823
                                .WORD      T194SSR
                                .WORD      PKTSSR
                                054530 104455
                                054532 001467
                                054534 060351
                                054536 012046
4358 054540 005237 002222      INC      FATFLG        ;SET FATAL ERROR FLAG
4359 054544 150$:            CKLOOP          ;LOOP ON ERROR, IF FLAG SET
                                TRAP      C$CLP1
                                054544 104406
;
; Do a WRITE FIFO with byte count equal to 1 and Tape direction IN
4361 054546 012700 000001      MOV      #1,R0         ;WRITE 1 BYTE
4362 054552 012701 002312      MOV      #DATA,R1     ;FIFO WRITE DATA ADDRESS
4363 054556 004737 062046      JSR      PC,T19WFIF    ;SETUP T19PK2 FOR WRITE FIFO
4364 054562 012704 062440      MOV      #T19PK2,R4    ;GET WRITE SUBSYSTEM COMMAND PACKET
4365 054566 010465 000000      MOV      R4,TSDB(R5)  ;SET THE PACKET ADDRESS TO EXECUTE
4366 054572 004737 016336      JSR      PC,CHKTSSR    ;WAIT FOR SSR TO SET
4367 054576                    FORCERROR      162$      ;BDFORCE ERROR IF FORCER=1
4368 054612 103407            BCS      170$          ;BR IF CARRY SET (GOOD RETURN)
4369 054614 010001            MOV      R0,R1         ;SAVE CONTENTS OF TSSR
4370 054616                    NEXT.ERRNO
4371 054616 162$:            ERDF      ERRNO,T195SSR,PKTSSR ;DEVICE FATAL SSR FAILED TO SET
                                TRAP      C$ERDF
                                .WORD      824
                                .WORD      T195SSR
                                .WORD      PKTSSR
                                054616 104455
                                054620 001470
                                054622 060414
                                054624 012046
4372 054626 005237 002222      INC      FATFLG        ;SET FATAL ERROR FLAG
4373 054632 170$:            CKLOOP          ;LOOP ON ERROR, IF FLAG SET
                                TRAP      C$CLP1
                                054632 104406
;
; Do a READ FIFO with tape direction IN to read data
4375
; If Data read from FIFO NOT= to Data sent Then Print Error
4376 054634 012700 000001      MOV      #1,R0         ;SET READ BYTE COUNT
4377 054640 004737 062026      JSR      PC,T19RFIF    ;SETUP T19PK2 FOR READ FIFO
4378 054644 012704 062440      MOV      #T19PK2,R4    ;GET WRITE SUBSYSTEM COMMAND PACKET
4379 054650 010465 000000      MOV      R4,TSDB(R5)  ;SET THE PACKET ADDRESS TO EXECUTE
4380 054654 004737 016336      JSR      PC,CHKTSSR    ;WAIT FOR SSR TO SET
4381 054660                    FORCERROR      182$      ;BDFORCE ERROR IF FORCER=1
4382 054674 103407            BCS      190$          ;BR IF CARRY SET (GOOD RETURN)
4383 054676 010001            MOV      R0,R1         ;SAVE CONTENTS OF TSSR
4384 054700                    NEXT.ERRNO
4385 054700 182$:            ERDF      ERRNO,T196SSR,PKTSSR ;DEVICE FATAL SSR FAILED TO SET
                                TRAP      C$ERDF
                                .WORD      825
                                .WORD      T196SSR
                                .WORD      PKTSSR
                                054700 104455
                                054702 001471
                                054704 060460
                                054706 012046
4386 054710 005237 002222      INC      FATFLG        ;SET FATAL ERROR FLAG
4387 054714 190$:            CKLOOP          ;LOOP ON ERROR, IF FLAG SET
                                TRAP      C$CLP1
                                054714 104406
4388 054716 004737 062200      JSR      PC,T19SETEXP  ;SET WORDS 0-7 EXPD=RECV (NOT TESTING)
4389 054722 012701 060042      MOV      #T19EXSTA,R1 ;GET EXPECTED READ STATUS
4390 054726 012702 062332      MOV      #T19BFSTA,R2 ;GET RECV READ STATUS
4391 054732 013711 002312      MOV      DATA,(R1)   ;SET EXPD WORD #8 = DATA
4392 054736 016261 000002 000002 MOV      2(R2),2(R1)  ;SET EXPD WORD #9 = RECV (NOT TESTING)
4393 054744 005000            CLR      R0           ;HIGH RECV ADDRESS FOR CKMSG2
    
```

```

4394 054746 012701 062312      MOV      0T19BFR,R1      ;LOW RECV ADDRESS FOR CKMSG2
4395 054752 012702 060022      MOV      0T19EXP,R2     ;EXPD ADDRESS
4396 054756 012703 000022      MOV      0;B.,R3       ;NUMBER OF BYTES TO COMPARE
4397 054762 004737 011500      JSR      PC,CKMSG2     ;EXPD EQUAL RECV?
4398 054766                FORCERROR      2020,NOTSSR ;BBD
4399 054776 103404                BCS      2100         ;BR IF YES
4400 055000                NEXT.ERRNO
4401 055000 2020:  ERRNO  ERRNO,T199CMP,MSGSUB ;REPORT ERROR
                                TRAP      CIERMRO
                                .WORD    026
                                .WORD    T199CMP
                                .WORD    MSGSUB
                                TRAP      C1CLP1
                                055000 104456
                                055002 001472
                                055004 061420
                                055006 013742
4402 055010 2100:  CKLOOP          ;LOOP ON ERROR, IF FLAG SET
                                TRAP      C1CLP1
                                055010 104406
4403                ; Do a Write Subsystem READ STATUS
4404                ; IF Input Ready NOT=1 Then Print Error
4405                ; IF Output Ready NOT=0 Then Print Error
4406                ; IF Data In Miss NOT=0 Then Print Error
4407 055012 004737 061740      JSR      PC,T19SRD     ;SETUP PACKET FOR READ STATUS
4408 055016 012704 062440      MOV      0T19PK2,R4    ;GET WRITE SUBSYSTEM COMMAND PACKET
4409 055022 010465 000000      MOV      R4,TSDB(R5)  ;SET THE PACKET ADDRESS TO EXECUTE
4410 055026 004737 016336      JSR      PC,CHKSSR    ;WAIT FOR SSR TO SET
4411 055032                FORCERROR      2120         ;BBDFORCE ERROR IF FORCER=1
4412 055046 103407                BCS      2200         ;BR IF CARRY SET (GOOD RETURN)
4413 055050 010001                MOV      R0,R1       ;SAVE CONTENTS OF TSSR
4414 055052                NEXT.ERRNO
4415 055052 2120:  ERRDF  ERRNO,T193SSR,PXTSSR ;DEVICE FATAL SSR FAILED TO SET
                                TRAP      CIERDF
                                .WORD    027
                                .WORD    T193SSR
                                .WORD    PXTSSR
                                055052 104455
                                055054 001473
                                055056 060304
                                055060 012046
4416 055062 005237 002222      INC      FATFLG       ;SET FATAL ERROR FLAG
4417 055066 2200:  CKLOOP          ;LOOP ON ERROR, IF FLAG SET
                                TRAP      C1CLP1
                                055066 104406
4418 055070 004737 062200      JSR      PC,T19SETEXP  ;SET WORDS 0-7 EXPD=RECV (NOT TESTING)
4419 055074 012701 060042      MOV      0T19EXSTA,R1 ;GET EXPECTED READ STATUS
4420 055100 012702 062332      MOV      0T19BFSTA,R2 ;GET RECV READ STATUS
4421 055104 012221                MOV      (R2),.(R1).  ;SET EXPD WORD 08 = RECV TEMP
4422 055106 011211                MOV      (R2),.(R1)  ;SET EXPD WORD 09 = RECV TEMP
4423 055110 052711 000020      BIS      0S2.INRDY,(R1) ;SET EXP INPUT READY= 1
4424 055114 042711 000040      BIC      0S2.OUTRDY,(R1) ;SET EXP OUTPUT READY= 0
4425 055120 042711 000200      BIC      0S2.DIM,(R1) ;SET EXP DATA IN MISS = 0
4426 055124 005000                CLR      R0          ;HIGH RECV ADDRESS FOR CKMSG2
4427 055126 012701 062312      MOV      0T19BFR,R1   ;LOW RECV ADDRESS FOR CKMSG2
4428 055132 012702 060022      MOV      0T19EXP,R2   ;EXPD ADDRESS
4429 055136 012703 000024      MOV      020.,R3     ;NUMBER OF BYTES TO COMPARE
4430 055142 004737 011500      JSR      PC,CKMSG2    ;EXPD EQUAL RECV?
4431 055146                FORCERROR      2320,NOTSSR ;BBD
4432 055156 103404                BCS      2400         ;BR IF YES
4433 055160                NEXT.ERRNO
4434 055160 2320:  ERRNO  ERRNO,T196CMP,MSGSTAT ;REPORT ERROR
                                TRAP      CIERMRO
                                .WORD    028
                                .WORD    T196CMP
                                .WORD    MSGSTAT
                                055160 104456
                                055162 001474
                                055164 061160
                                055166 012350
4435 055170 2400:  CKLOOP          ;LOOP ON ERROR, IF FLAG SET
                                TRAP      C1CLP1
                                055170 104406

```

```

4434
4435
4436
4439 055172          FORCEEXIT          2550          ;END
4440 055202 013703 002316      MOV      TSTPTR,R3          ;RESTORE CURRENT TSTBLK POINTER
4441 055206 020327 003062      CMP      R3,0TBLEND        ;END OF TSTBLK?
4442 055212 103002          BHS      2550              ;BR IF YES
4443 055214 000137 054206      JMP      1000              ;DO ANOTHER TSTBLK PATTERN
4444 055220          2550:
4445
4446 055220          ENDSUB                      ;////////// END SUBTEST //////////
4447 055220          L10070:                     TRAP      CIESUB
4448 055220 104403
4447 055222 005737 002222      TST      FATFLG           ;ANY FATAL ERRORS ?
4449 055226 001402          BEQ      2600              ;BRANCH IF NOT
4450 055230 004737 017202      JSR      PC,CXDROP         ;TRY TO DROP THE UNIT
4451 055234          2600:
4452
4453
4454          .SBTTL TEST 0: SUBTEST 3: LOOPBACK WRITE STROBE TEST
4455
4456          ;**
4457          ; TEST 0: SUBTEST 3:
4458          ;
4459          ; SUBTEST DESCRIPTION:
4460          ;
4461          ; This subtest verifies the Write Strobe loopback path
4462          ; can strobe data from the FIFO to the Data lines.
4463          ; The signal IRESV3 drives IWSTR (write strobe) to write
4464          ; data from the FIFO to the tape data out latch.
4465          ;
4466          ; TEST STEPS:
4467          ;
4468          ; REPEAT FOR ALL TEST PATTERNS IN TSTBLK TABLE
4469          ; BEGIN
4470          ; Write to TSSR register to soft initialize the controller
4471          ; Do WRITE CHARACTERISTICS to check for Extended Features Switch
4472          ; If Extended Features Hardware Switch Clear then:
4473          ; Do Write Subsystem Write Miscellaneous to Set Extended Features.
4474          ; Do WRITE CHARACTERISTICS to select reserved unit 7 and setup BUFFER
4475          ; Do a Write Subsystem WRITE NPR to set tape direction out and Loopback
4476          ; Do a WRITE NPR to set loopback and tape direction OUT
4477          ; Do a WRITE FORMAT to set IRESV3==>IWSTR = 1
4478          ; Do a WRITE FIFO with byte count equal to 1 and Tape direction OUT
4479          ; Do a WRITE FORMAT to set IRESV3==>IWSTR = 0 to load write data latch
4480          ; Do a WRITE FORMAT to set IRESV3==>IWSTR = 1
4481          ; Do a WRITE NPR to set loopback and tape direction IN
4482          ; Do a WRITE FIFO with byte count equal to 1 and Tape direction IN
4483          ; to strobe loopback data into FIFO.
4484          ; Do a READ FIFO with tape direction IN to read data
4485          ; If Data read from FIFO NOT= to Data sent Then Print Error
4486          ;
4487          ; END
4488          ;
4489 055234          BGNSUB                      ;////////// BEGIN SUBTEST //////////
4490 055234          T8.3:
    
```

```

055234 104402                                     TRAP  C18SUB
4490                                     ; Write to TSSR register to soft initialize the controller
4491 055236                                     ;
4492 055236 004737 015774                       JSR    PC,SOFINIT      ;WRITE TO TSSR TO SOFT INITIALIZE
4493 055242 103405                               BCS    101             ;BR IF SOFT INIT OKAY
4494 055244 010001                               MOV    R0,R1          ;SAVE CONTENTS OF TSSR
4495 055246                                     ERROF  ERRNO,SFIERR,SFIMSG ;DEVICE FATAL DURING INIT
                                     TRAP  C1ERDF
                                     .WORD 828
055246 104455                                     .WORD SFERR
055250 001474                                     .WORD SFIMSG
055252 003652
055254 012034
4496                                     ; Do WRITE CHARACTERISTICS to check for Extended Features Switch
4497 055256 005037 002222                       101:   CLR    FATFLG      ;CLEAR FATAL ERROR FLAG
4498 055262 012704 062270                       MOV    @T19PACKET,R4 ;GET THE ADDRESS OF COMMAND PACKET
4499 055266 004737 010662                       JSR    PC,WRTCHR      ;DO WRITE CHARACTERISTICS COMMAND
4500 055272                                     FORCERROR 121         ;BDFORCE ERROR IF FORCER=1
4501 055306 103407                               BCS    151             ;BR IF CARRY SET (GOOD RETURN)
4502 055310 010001                               MOV    R0,R1          ;SAVE CONTENTS OF TSSR
4503 055312                                     NEXT.ERRNO
4504 055312                                     121:   ERROF  ERRNO,T19SSR,PKTSSR ;DEVICE FATAL SSR FAILED TO SET
                                     TRAP  C1ERDF
                                     .WORD 829
055312 104455                                     .WORD T19SSR
055314 001475                                     .WORD PKTSSR
055316 060203
055320 012046
4505 055322 005237 002222                       151:   INC    FATFLG      ;SET FATAL ERROR FLAG
4506 055326                                     CKLOOP ;LOOP ON ERROR, IF FLAG SET
055326 104406                                     TRAP  C1CLP1
4507                                     ; If Extended Features Hardware Switch Clear then:
4508                                     ; Do Write Subsystem Write Miscellaneous to Set Extended Features.
4509 055330 012701 062312                       MOV    @T19BFR,R1    ;MESSAGE BUFFER ADDRESS
4510 055334 032761 000200 000012             BIT    @X2.EXTF,XST2(R1) ;EXTENDED FEATURES SWITCH SET?
4511 055342 001026                               BNE    301             ;BR IF YES
4512 055344 004737 062142                       JSR    PC,T19SEXT    ;SETUP PACKET FOR WRITE MISC INVERT
4513 055350 012704 062440                       MOV    @T19PK2,R4    ;GET WRITE SUBSYSTEM COMMAND PACKET
4514 055354 010465 000000                       MOV    R4,TSDB(R5)   ;SET THE PACKET ADDRESS TO EXECUTE
4515 055360 004737 016336                       JSR    PC,CHKTSSR    ;WAIT FOR SSR TO SET
4516 055364                                     FORCERROR 221         ;BDFORCE ERROR IF FORCER=1
4517 055400 103407                               BCS    301             ;BR IF CARRY SET (GOOD RETURN)
4518 055402 010001                               MOV    R0,R1          ;SAVE CONTENTS OF TSSR
4519 055404                                     NEXT.ERRNO
4520 055404                                     221:   ERROF  ERRNO,T192SSR,PKTSSR ;DEVICE FATAL SSR FAILED TO SET
                                     TRAP  C1ERDF
055404 104455                                     .WORD 830
055406 001476                                     .WORD T192SSR
055410 060240                                     .WORD PKTSSR
055412 012046
4521 055414 005237 002222                       301:   INC    FATFLG      ;SET FATAL ERROR FLAG
4522 055420                                     CKLOOP ;LOOP ON ERROR, IF FLAG SET
055420 104406                                     TRAP  C1CLP1
4523                                     ; Do WRITE CHARACTERISTICS to select reserved unit 7
4524 055422 012704 062270                       MOV    @T19PACKET,R4 ;GET THE ADDRESS OF COMMAND PACKET
4525 055426 004737 010662                       JSR    PC,WRTCHR      ;DO WRITE CHARACTERISTICS COMMAND
4526 055432                                     FORCERROR 421         ;BDFORCE ERROR IF FORCER=1
4527 055446 103407                               BCS    501             ;BR IF CARRY SET (GOOD RETURN)
4528 055450 010001                               MOV    R0,R1          ;SAVE CONTENTS OF TSSR
4529 055452                                     NEXT.ERRNO
4530 055452                                     421:   ERROF  ERRNO,T19SSR,PKTSSR ;DEVICE FATAL SSR FAILED TO SET
055452 104455                                     TRAP  C1ERDF

```



E 16

```

055454 001477 .WORD 831
055456 060203 .WORD T1955R
055460 012046 .WORD PKT55R
4531 055462 005237 002222 INC FATFLG ;SET FATAL ERROR FLAG
4532 055466 104406 508: CKLOOP ;LOOP ON ERROR, IF FLAG SET
; TRAP C:CLP1
4533
4534 ; REPEAT FOR ALL TEST PATTERNS IN TSTBLK TABLE
4535 055470 012703 002752 MOV #TSTBLK,R3 ;GET FIRST PATTERN ADDRESS
4536 055474 012337 002312 1008: MOV (R3),DATA ;GET A TEST PATTERN
4537 055500 042737 177400 002312 BIC #C<377>,DATA ;DATA IS BYTE
4538 055506 010337 002316 MOV R3,TSTPTR ;SETUP CURRENT TSTBLK POINTER
4539 ; Do a WRITE NPR to set loopback and tape direction OUT
4540 055512 012700 000100 MOV #NP.OUT,R0 ;SET TAPE DIRECTION OUT
4541 055516 052700 000040 BIS #NP.LOOP,R0 ;SET LOOPBACK
4542 055522 004737 062002 JSR PC,T19SNPR ;SETUP T19PK2 FOR WRITE NPR
4543 055526 012704 062440 MOV #T19PK2,R4 ;GET WRITE SUBSYSTEM COMMAND PACKET
4544 055532 010465 000000 MOV R4,TSDB(R5) ;SET THE PACKET ADDRESS TO EXECUTE
4545 055536 004737 016336 JSR PC,CHKTSSR ;WAIT FOR SSR TO SET
4546 055542 FORCERROR 1028 ;BDFORCE ERROR IF FORCER=1
4547 055556 103407 BCS 1058 ;BR IF CARRY SET (GOOD RETURN)
4548 055560 010001 MOV R0,R1 ;SAVE CONTENTS OF TSSR
4549 055562 NEXT.ERRNO
4550 055562 1028: ERDF ERRNO,T19455R,PKT55R ;DEVICE FATAL SSR FAILED TO SET
; TRAP C:ERDF
055562 104455 .WORD 832
055564 001500 .WORD T19455R
055566 060351 .WORD PKT55R
055570 012046 .WORD PKT55R
4551 055572 005237 002222 INC FATFLG ;SET FATAL ERROR FLAG
4552 055576 104406 1058: CKLOOP ;LOOP ON ERROR, IF FLAG SET
; TRAP C:CLP1
4553 ; Do a WRITE FORMAT to set IRESV3==>IWSTR = 1
4554 055600 012700 000002 MOV #WF.ISRES,R0 ;IRESV3==>IWSTR=1
4555 055604 004737 062122 JSR PC,T19WFMT ;SETUP T19PK2 FOR WRITE FORMAT
4556 055610 012704 062440 MOV #T19PK2,R4 ;GET WRITE SUBSYSTEM COMMAND PACKET
4557 055614 010465 000000 MOV R4,TSUB(R5) ;SET THE PACKET ADDRESS TO EXECUTE
4558 055620 004737 016336 JSR PC,CHKTSSR ;WAIT FOR SSR TO SET
4559 055624 FORCERROR 1128 ;BDFORCE ERROR IF FORCER=1
4560 055640 103407 BCS 1208 ;BR IF CARRY SET (GOOD RETURN)
4561 055642 010001 MOV R0,R1 ;SAVE CONTENTS OF TSSR
4562 055644 NEXT.ERRNO
4563 055644 1128: ERDF ERRNO,T19855R,PKT55R ;DEVICE FATAL SSR FAILED TO SET
; TRAP C:ERDF
055644 104455 .WORD 833
055646 001501 .WORD T19855R
055650 060572 .WORD PKT55R
055652 012046 .WORD PKT55R
4564 055654 005237 002222 INC FATFLG ;SET FATAL ERROR FLAG
4565 055660 104406 1208: CKLOOP ;LOOP ON ERROR, IF FLAG SET
; TRAP C:CLP1
4566 ; Do a WRITE FIFO with byte count equal to 1 and Tape direction OUT
4567 055662 012700 000001 MOV #1,R0 ;WRITE 1 BYTE
4568 055666 012701 002312 MOV #DATA,R1 ;FIFO WRITE DATA ADDRESS
4569 055672 004737 062046 JSR PC,T19WFIF ;SETUP T19PK2 FOR WRITE FIFO
4570 055676 012704 062440 MOV #T19PK2,R4 ;GET WRITE SUBSYSTEM COMMAND PACKET
4571 055702 010465 000000 MOV R4,TSDB(R5) ;SET THE PACKET ADDRESS TO EXECUTE
4572 055706 004737 016336 JSR PC,CHKTSSR ;WAIT FOR SSR TO SET
4573 055712 FORCERROR 1328 ;BDFORCE ERROR IF FORCER=1

```

```

4574 055726 103407      BCS      140$      ;BR IF CARRY SET (GOOD RETURN)
4575 055730 010001      MOV      R0,R1    ;SAVE CONTENTS OF TSSR
4576 055732              NEXT.ERRNO
4577 055732              132$:  ERRDF   ERRNO,T195SSR,PKTSSR ;DEVICE FATAL SSR FAILED TO SET
                                TRAP      C$ERDF
                                .WORD    834
                                .WORD    T195SSR
                                .WORD    PKTSSR
4578 055742 005237 002222      INC      FATFLG   ;SET FATAL ERROR FLAG
4579 055746 055746 104406      140$:  CKLOOP    ;LOOP ON ERROR, IF FLAG SET
                                TRAP      C$CLP1
;
4580              ; Do a WRITE FORMAT to set IRESV3==>IWSTR = 0
4581 055750 005000      CLR      R0       ;SET IRESV3==>IWSTR=0
4582 055752 004737 062122      JSR      PC,T19WFMT ;SETUP T19PK2 FOR WRITE FORMAT
4583 055756 012704 062440      MOV      @T19PK2,R4 ;GET WRITE SUBSYSTEM COMMAND PACKET
4584 055762 010465 000000      MOV      R4,TSDB(R5) ;SET THE PACKET ADDRESS TO EXECUTE
4585 055766 004737 016336      JSR      PC,CHKTSSR ;WAIT FOR SSR TO SET
4586 055772              FORCERROR 152$      ;BDFORCE ERROR IF FORCER=1
4587 056006 103407      BCS      160$      ;BR IF CARRY SET (GOOD RETURN)
4588 056010 010001      MOV      R0,R1    ;SAVE CONTENTS OF TSSR
4589 056012              NEXT.ERRNO
4590 056012              152$:  ERRDF   ERRNO,T198SSR,PKTSSR ;DEVICE FATAL SSR FAILED TO SET
                                TRAP      C$ERDF
                                .WORD    835
                                .WORD    T198SSR
                                .WORD    PKTSSR
4591 056022 005237 002222      INC      FATFLG   ;SET FATAL ERROR FLAG
4592 056026 056026 104406      160$:  CKLOOP    ;LOOP ON ERROR, IF FLAG SET
                                TRAP      C$CLP1
;
4593              ; Do a WRITE FORMAT to set IRESV3==>IWSTR = 1
4594 056030 012700 000002      MOV      @WF.I3RES,R0 ;IRESV3==>IWSTR=1
4595 056034 004737 062122      JSR      PC,T19WFMT ;SETUP T19PK2 FOR WRITE FORMAT
4596 056040 012704 062440      MOV      @T19PK2,R4 ;GET WRITE SUBSYSTEM COMMAND PACKET
4597 056044 010465 000000      MOV      R4,TSDB(R5) ;SET THE PACKET ADDRESS TO EXECUTE
4598 056050 004737 016336      JSR      PC,CHKTSSR ;WAIT FOR SSR TO SET
4599 056054              FORCERROR 172$      ;BDFORCE ERROR IF FORCER=1
4600 056070 103407      BCS      180$      ;BR IF CARRY SET (GOOD RETURN)
4601 056072 010001      MOV      R0,R1    ;SAVE CONTENTS OF TSSR
4602 056074              NEXT.ERRNO
4603 056074              172$:  ERRDF   ERRNO,T198SSR,PKTSSR ;DEVICE FATAL SSR FAILED TO SET
                                TRAP      C$ERDF
                                .WORD    836
                                .WORD    T198SSR
                                .WORD    PKTSSR
4604 056104 005237 002222      INC      FATFLG   ;SET FATAL ERROR FLAG
4605 056110 056110 104406      180$:  CKLOOP    ;LOOP ON ERROR, IF FLAG SET
                                TRAP      C$CLP1
4606              ;
4607              ; Do a WRITE NPR to set loopback and tape direction IN
4608 056112 005000      CLR      R0       ;CLR NP.OUT TO SET TAPE DIRECTION IN
4609 056114 052700 000040      BIS      @NP.LOOP,R0 ;SET LOOPBACK
4610 056120 004737 062002      JSR      PC,T19SNPR ;SETUP T19PK2 FOR WRITE NPR
4611 056124 012704 062440      MOV      @T19PK2,R4 ;GET WRITE SUBSYSTEM COMMAND PACKET
4612 056130 010465 000000      MOV      R4,TSDB(R5) ;SET THE PACKET ADDRESS TO EXECUTE
4613 056134 004737 016336      JSR      PC,CHKTSSR ;WAIT FOR SSR TO SET
4614 056140              FORCERROR 182$      ;BDFORCE ERROR IF FORCER=1
4615 056154 103407      BCS      190$      ;BR IF CARRY SET (GOOD RETURN)
    
```

```

4616 056156 010001          MOV     R0,R1          ;SAVE CONTENTS OF TSSR
4617 056160                NEXT.ERRNO
4618 056160 1824:  ERRDF  ERRNO,T194SSR,PKTSSR ;DEVICE FATAL SSR FAILED TO SET
                                TRAP  C1ERDF
                                .WORD 837
                                .WORD T194SSR
                                .WORD PKTSSR
                                056160 104455
                                056162 001505
                                056164 060351
                                056166 012046
4619 056170 005237 002222  INC     FATFLG        ;SET FATAL ERROR FLAG
4620 056174 1904:  CKLOOP        ;LOOP ON ERROR, IF FLAG SET
                                TRAP  C1CLP1
                                056174 104406
; Do a WRITE FIFO with byte count equal to 1 and Tape direction IN
4621                MOV     #1,R0          ;WRITE 1 BYTE
4622 056176 012700 000001  MOV     #DATA,R1      ;FIFO WRITE DATA ADDRESS
4623 056202 012701 002312  JSR     PC,T19WFIF    ;SETUP T19PK2 FOR WRITE FIFO
4624 056206 004737 062046  MOV     #T19PK2,R4    ;GET WRITE SUBSYSTEM COMMAND PACKET
4625 056212 012704 062440  MOV     R4,TSDB(R5)   ;SET THE PACKET ADDRESS TO EXECUTE
4626 056216 010465 000000  JSR     PC,CHKTSSR    ;WAIT FOR SSR TO SET
4627 056222 004737 016336  FORCERROR 2024        ;BDDFORCE ERROR IF FORCER=1
4628 056226                BCS     2104          ;BR IF CARRY SET (GOOD RETURN)
4629 056242 103407                MOV     R0,R1          ;SAVE CONTENTS OF TSSR
4630 056244 010001  NEXT.ERRNO
4631 056246 2024:  ERRDF  ERRNO,T195SSR,PKTSSR ;DEVICE FATAL SSR FAILED TO SET
                                TRAP  C1ERDF
                                .WORD 838
                                .WORD T195SSR
                                .WORD PKTSSR
                                056246 104455
                                056250 001506
                                056252 060414
                                056254 012046
4633 056256 005237 002222  INC     FATFLG        ;SET FATAL ERROR FLAG
4634 056262 2104:  CKLOOP        ;LOOP ON ERROR, IF FLAG SET
                                TRAP  C1CLP1
                                056262 104406
; Do a READ FIFO with tape direction IN to read data
4635                MOV     #1,R0          ;SET READ BYTE COUNT
4636 056264 012700 000001  JSR     PC,T19RFIF    ;SETUP T19PK2 FOR READ FIFO
4637 056270 004737 062026  MOV     #T19PK2,R4    ;GET WRITE SUBSYSTEM COMMAND PACKET
4638 056274 012704 062440  MOV     R4,TSDB(R5)   ;SET THE PACKET ADDRESS TO EXECUTE
4639 056300 010465 000000  JSR     PC,CHKTSSR    ;WAIT FOR SSR TO SET
4640 056304 004737 016336  FORCERROR 2224        ;BDDFORCE ERROR IF FORCER=1
4641 056310                BCS     2304          ;BR IF CARRY SET (GOOD RETURN)
4642 056324 103407                MOV     R0,R1          ;SAVE CONTENTS OF TSSR
4643 056326 010001  NEXT.ERRNO
4644 056330 2224:  ERRDF  ERRNO,T196SSR,PKTSSR ;DEVICE FATAL SSR FAILED TO SET
                                TRAP  C1ERDF
                                .WORD 839
                                .WORD T196SSR
                                .WORD PKTSSR
                                056330 104455
                                056332 001507
                                056334 060460
                                056336 012046
4646 056340 005237 002222  INC     FATFLG        ;SET FATAL ERROR FLAG
4647 056344 2304:  CKLOOP        ;LOOP ON ERROR, IF FLAG SET
                                TRAP  C1CLP1
                                056344 104406
; If Data read from FIFO NOT= to Data sent Then Print Error
4648                JSR     PC,T19SETEXP    ;SET WORDS 0-7 EXPD=RECV (NOT TESTING)
4649 056346 004737 062200  MOV     #T19EXSTA,R1  ;GET EXPECTED READ STATUS
4650 056352 012701 060042  MOV     #T19BFSTA,R2  ;GET RECV READ STATUS
4651 056356 012702 062332  MOV     DATA,(R1)    ;SET EXPD WORD #8 = DATA
4652 056362 013711 002312  MOV     2(R2),2(R1)   ;SET EXPD WORD #9 = RECV (NOT TESTING)
4653 056366 016261 000002 000002  CLR     R0            ;HIGH RECV ADDRESS FOR CKMSG2
4654 056374 005000                MOV     #T19BFR,R1    ;LOW RECV ADDRESS FOR CKMSG2
4655 056376 012701 062312  MOV     #T19EXP,R2    ;EXPD ADDRESS
4656 056402 012702 060022  MOV     #18.,R3       ;NUMBER OF BYTES TO COMPARE
4657 056406 012703 000022

```

```

4658 056412 004737 011500      JSR      PC,CKMSG2      ;EXPD EQUAL RECV?
4659 056416                    FORCERROR      242$,NOTSSR ;$$$
4660 056426 103404            BCS      250$          ;BR IF YES
4661 056430                    NEXT,ERRNO
4662 056430 242$:            ERPHRD  ERRNO,T19WSTR,MSGSUB ;REPORT ERROR
                                TRAP      C#ERMRD
                                .WORD     840
                                .WORD     T19WSTR
                                .WORD     MSGSUB
4663 056440 250$:            CKLOOP          ;LOOP ON ERROR, IF FLAG SET
                                TRAP      C#CLP1
                                .WORD     1
4664 056430 104456
4665 056432 001510
4666 056434 061503
4667 056436 013742
4666 056442                    FORCEXTT      255$          ;$$$
4667 056452 013703 002316      MOV      TSTPTR,R3      ;RESTORE CURRENT TSTBLK POTNTER
4668 056456 020327 003062      CMP      R3,#TBLEND     ;END OF TSTBLK?
4669 056462 103002            BHIS     255$          ;BR IF YES
4670 056464 000137 055474      JMP      100$          ;DO ANOTHER TSTBLK PATTERN
4671 056470 255$:
4672
4673 056470                    ENDSUB          ;////////// END SUBTEST //////////
                                L10071:
                                TRAP      C#ESUB
4674 056470 104403
4674 056472 005737 002222      TST      FATFLG        ;ANY FATAL ERRORS ?
4675 056476 001402            BEQ      260$          ;BRANCH IF NOT
4676 056500 004737 017202      JSR      PC,CKDROP     ;TRY TO DROP THE UNIT
4677 056504 260$:
4678 056504                    .SBTTL  TEST 8: SUBTEST 4 LOOPBACK READ STROBE TEST
4679
4680
4681 ;**
4682 ; TEST 8: SUBTEST 4:
4683 ;
4684 ; SUBTEST DESCRIPTION:
4685 ;
4686 ;       This subtest verifies the Read Strobe loopback path
4687 ;       can strobe the data from the Data lines to the FIFO.
4688 ;       The signal IRESV4 drives IRSTR (read strobe) to write
4689 ;       from the data lines to the FIFO.
4690 ;
4691 ; TEST STEPS:
4692 ;
4693 ; REPEAT FOR ALL TEST PATTERNS IN TSTBLK TABLE
4694 ; BEGIN
4695 ;       Write to TSSR register to soft initialize the controller
4696 ;       Do WRITE CHARACTERISTICS to check for Extended Features Switch
4697 ;       If Extended Features Hardware Switch Clear then:
4698 ;       Do Write Subsystem Write Miscellaneous to Set Extended Features.
4699 ;       Do WRITE CHARACTERISTICS to select reserved unit 7 and setup BUFFER
4700 ;       Do a Write Subsystem WRITE NPR to set tape direction out and Loopback
4701 ;       Do a WRITE NPR to set loopback and tape direction OUT
4702 ;       Do a WRITE FORMAT to set IRESV4==>IRSTR = 1
4703 ;       Do a WRITE FIFO with byte count equal to 1 and Tape direction OUT
4704 ;       Do a READ FIFO with tape direction OUT to load tape out write latch
4705 ;       Do a WRITE NPR to set loopback and tape direction IN
4706 ;       Do a WRITE FORMAT to set IRESV4==>IRSTR = 0 to write loop data to FIFO
4707 ;

```

```

4708      ; Do a WRITE FORMAT to set IRESV4=>IRSTR = 1
4709      ; (to strobe loopback data into FIFO.)
4710      ; Do a READ FIFO with tape direction IN to read data
4711      ; If Data read from FIFO NOT= to Data sent Then Print Error
4712      ; END
4713      ;
4714 056504      BGNSUB      ;//////////////// BEGIN SUBTEST //////////////////
      056504      ;
      056504 104402      ;
4715      ; Write to TSSR register to soft initialize the controller
4716 056506      5$:
4717 056506 004737 015774      JSR      PC,SOFINIT      ;WRITE TO TSSR TO SOFT INITIALIZE
4718 056512 103405      BCS      10$      ;BR IF SOFT INIT OKAY
4719 056514 010001      MOV      R0,R1      ;SAVE CONTENTS OF TSSR
4720 056516      ERRDF      ERRNO,SFIERR,SFIMSG      ;DEVICE FATAL DURING INIT
      056516 104455      ;
      056520 001510      ;
      056522 003652      ;
      056524 012034      ;
4721      ; Do WRITE CHARACTERISTICS to check for Extended Features Switch
4722 056526 005037 002222      10$: CLR      FATFLG      ;CLEAR FATAL ERROR FLAG
4723 056532 012704 062270      MOV      @T19PACKET,R4      ;GET THE ADDRESS OF COMMAND PACKET
4724 056536 004737 010662      JSR      PC,WRTCHR      ;DO WRITE CHARACTERISTICS COMMAND
4725 056542      FORCERROR      12$      ;BDFORCE ERROR IF FORCER=1
4726 056556 103407      BCS      15$      ;BR IF CARRY SET (GOOD RETURN)
4727 056560 010001      MOV      R0,R1      ;SAVE CONTENTS OF TSSR
4728 056562      NEXT.ERRNO
4729 056562      12$: ERRDF      ERRNO,T19SSR,PKTSSR      ;DEVICE FATAL SSR FAILED TO SET
      056562 104455      ;
      056564 001511      ;
      056566 060203      ;
      056570 012046      ;
4730 056572 005237 002222      INC      FATFLG      ;SET FATAL ERROR FLAG
4731 056576      15$: CKLOOP      ;LOOP ON ERROR, IF FLAG SET
      056576 104406      ;
4732      ; If Extended Features Hardware Switch Clear then:
4733      ; Do Write Subsystem Write Miscellaneous to Set Extended Features.
4734 056600 012701 062312      MOV      @T19BFR,R1      ;MESSAGE BUFFER ADDRESS
4735 056604 032761 000200 000012      BIT      @X2.EXTF,XST2(R1)      ;EXTENDED FEATURES SWITCH SET?
4736 056612 001026      BNE      30$      ;BR IF YES
4737 056614 004737 062142      JSR      PC,T19SEXT      ;SETUP PACKET FOR WRITE MISC INVERT
4738 056620 012704 062440      MOV      @T19PK2,R4      ;GET WRITE SUBSYSTEM COMMAND PACKET
4739 056624 010465 000000      MOV      R4,TSDB(R5)      ;SET THE PACKET ADDRESS TO EXECUTE
4740 056630 004737 016336      JSR      PC,CHKTSSR      ;WAIT FOR SSR TO SET
4741 056634      FORCERROR      22$      ;BDFORCE ERROR IF FORCER=1
4742 056650 103407      BCS      30$      ;BR IF CARRY SET (GOOD RETURN)
4743 056652 010001      MOV      R0,R1      ;SAVE CONTENTS OF TSSR
4744 056654      NEXT.ERRNO
4745 056654      22$: ERRDF      ERRNO,T192SSR,PKTSSR      ;DEVICE FATAL SSR FAILED TO SET
      056654 104455      ;
      056656 001512      ;
      056660 060240      ;
      056662 012046      ;
4746 056664 005237 002222      INC      FATFLG      ;SET FATAL ERROR FLAG
4747 056670      30$: CKLOOP      ;LOOP ON ERROR, IF FLAG SET
      056670 104406      ;
4748      ; Do WRITE CHARACTERISTICS to select reserved unit 7

```

J1\*

```

4749 056672 012704 062270      MOV      #T19PK2,R4      ;GET THE ADDRESS OF COMMAND PACKET
4750 056676 004737 010662      JSR      PC,WRTCHR      ;DO WRITE CHARACTERISTICS COMMAND
4751 056702                    FORCERROR      42$      ;GOODFORCE ERROR IF FORCER=1
4752 056716 103407                    BCS      50$      ;BR IF CARRY SET (GOOD RETURN)
4753 056720 010001                    MOV      R0,R1      ;SAVE CONTENTS OF TSSR
4754 056722                    NEXT.ERRNO
4755 056722      42$:      ERRDF      ERRNO,T19SSR,PKTSSR      ;DEVICE FATAL SSR FAILED TO SET
                                TRAP      C$ERDF
                                .WORD      843
                                .WORD      T19SSR
                                .WORD      PKTSSR
                                056722 104455
                                056724 001513
                                056726 060203
                                056730 012046
4756 056732 005237 002222      INC      FATFLG      ;SET FATAL ERROR FLAG
4757 056736      50$:      CKLOOP      ;LOOP ON ERROR, IF FLAG SET
                                TRAP      C$CLP1
                                056736 104406
4758
4759      ; REPEAT FOR ALL TEST PATTERNS IN TSTBLK TABLE
4760 056740 012703 002752      MOV      #TSTBLK,R3      ;GET FIRST PATTERN ADDRESS
4761 056744 012337 002312      100$:      MOV      (R3),DATA      ;GET A TEST PATTERN
4762 056750 042737 177400      BIC      #C<377>,DATA      ;DATA IS BYTE
4763 056756 010337 002316      MOV      R3,TSTPTR      ;SETUP CURRENT TSTBLK POINTER
4764                    ; Do a WRITE NPR to set loopback and tape direction OUT
4765 056762 012700 000100      MOV      #NP.OUT,R0      ;SET TAPE DIRECTION OUT
4766 056766 052700 000040      BIS      #NP.LOOP,R0      ;SET LOOPBACK
4767 056772 004737 062002      JSR      PC,T19SNPR      ;SETUP T19PK2 FOR WRITE NPR
4768 056776 012704 062440      MOV      #T19PK2,R4      ;GET WRITE SUBSYSTEM COMMAND PACKET
4769 057002 010465 000000      MOV      R4,TSDB(R5)      ;SET THE PACKET ADDRESS TO EXECUTE
4770 057006 004737 016336      JSR      PC,CHKTSSR      ;WAIT FOR SSR TO SET
4771 057012                    FORCERROR      102$      ;GOODFORCE ERROR IF FORCER=1
4772 057026 103407                    BCS      105$      ;BR IF CARRY SET (GOOD RETURN)
4773 057030 010001                    MOV      R0,R1      ;SAVE CONTENTS OF TSSR
4774 057032                    NEXT.ERRNO
4775 057032      102$:      ERRDF      ERRNO,T194SSR,PKTSSR      ;DEVICE FATAL SSR FAILED TO SET
                                TRAP      C$ERDF
                                .WORD      844
                                .WORD      T194SSR
                                .WORD      PKTSSR
                                057032 104455
                                057034 001514
                                057036 060351
                                057040 012046
4776 057042 005237 002222      INC      FATFLG      ;SET FATAL ERROR FLAG
4777 057046      105$:      CKLOOP      ;LOOP ON ERROR, IF FLAG SET
                                TRAP      C$CLP1
                                057046 104406
4778      ; Do a WRITE FORMAT to set IRESV4==>IRSTR = 1
4779 057050 012700 000001      MOV      #WF.IARES,R0      ;IRESV4==>IRSTR=1
4780 057054 004737 062122      JSR      PC,T19WFM      ;SETUP T19PK2 FOR WRITE FORMAT
4781 057060 012704 062440      MOV      #T19PK2,R4      ;GET WRITE SUBSYSTEM COMMAND PACKET
4782 057064 010465 000000      MOV      R4,TSDB(R5)      ;SET THE PACKET ADDRESS TO EXECUTE
4783 057070 004737 016336      JSR      PC,CHKTSSR      ;WAIT FOR SSR TO SET
4784 057074                    FORCERROR      112$      ;GOODFORCE ERROR IF FORCER=1
4785 057110 103407                    BCS      120$      ;BR IF CARRY SET (GOOD RETURN)
4786 057112 010001                    MOV      R0,R1      ;SAVE CONTENTS OF TSSR
4787 057114                    NEXT.ERRNO
4788 057114      112$:      ERRDF      ERRNO,T198SSR,PKTSSR      ;DEVICE FATAL SSR FAILED TO SET
                                TRAP      C$ERDF
                                .WORD      845
                                .WORD      T198SSR
                                .WORD      PKTSSR
                                057114 104455
                                057116 001515
                                057120 060572
                                057122 012046
4789 057124 005237 002222      INC      FATFLG      ;SET FATAL ERROR FLAG
4790 057130      120$:      CKLOOP      ;LOOP ON ERROR, IF FLAG SET
                                TRAP      C$CLP1
                                057130 104406

```

```

4791 ; Do a WRITE FIFO with byte count equal to 1 and Tape direction OUT
4792 057132 012700 000001 MOV #1,R0 ;WRITE 1 BYTE
4793 057136 012701 002312 MOV #DATA,R1 ;FIFO WRITE DATA ADDRESS
4794 057142 004737 062046 JSR PC,T19WFIF ;SETUP T19PK2 FOR WRITE FIFO
4795 057146 012704 062440 MOV #T19PK2,R4 ;GET WRITE SUBSYSTEM COMMAND PACKET
4796 057152 010465 000000 MOV R4,TSDB(R5) ;SET THE PACKET ADDRESS TO EXECUTE
4797 057156 004737 016336 JSR PC,CHKTSSR ;WAIT FOR SSR TO SET
4798 057162 FORCERROR 132$ ;BDFORCE ERROR IF FORCER=1
4799 057176 103407 BCS 140$ ;BR IF CARRY SET (GOOD RETURN)
4800 057200 010001 MOV R0,R1 ;SAVE CONTENTS OF TSSR
4801 057202 NEXT.ERRNO
4802 057202 132$: ERRDF ERRNO,T195SSR,PKTSSR ;DEVICE FATAL SSR FAILED TO SET
                                TRAP C#ERDF
                                .WORD 846
                                .WORD T195SSR
                                .WORD PKTSSR
4803 057212 005237 002222 INC FATFLG ;SET FATAL ERROR FLAG
4804 057216 104406 140$: CKLOOP ;LOOP ON ERROR, IF FLAG SET
                                TRAP C#CLP1
4805 ; Do a READ FIFO with tape direction OUT to load tape out write latch
4806 057220 012700 000001 MOV #1,R0 ;SET READ BYTE COUNT
4807 057224 004737 062026 JSR PC,T19RFIF ;SETUP T19PK2 FOR READ FIFO
4808 057230 012704 062440 MOV #T19PK2,R4 ;GET WRITE SUBSYSTEM COMMAND PACKET
4809 057234 010465 000000 MOV R4,TSDB(R5) ;SET THE PACKET ADDRESS TO EXECUTE
4810 057240 004737 016336 JSR PC,CHKTSSR ;WAIT FOR SSR TO SET
4811 057244 FORCERROR 152$ ;BDFORCE ERROR IF FORCER=1
4812 057260 103407 BCS 160$ ;BR IF CARRY SET (GOOD RETURN)
4813 057262 010001 MOV R0,R1 ;SAVE CONTENTS OF TSSR
4814 057264 NEXT.ERRNO
4815 057264 152$: ERRDF ERRNO,T196SSR,PKTSSR ;DEVICE FATAL SSR FAILED TO SET
                                TRAP C#ERDF
                                .WORD 847
                                .WORD T196SSR
                                .WORD PKTSSR
4816 057274 005237 002222 INC FATFLG ;SET FATAL ERROR FLAG
4817 057300 104406 160$: CKLOOP ;LOOP ON ERROR, IF FLAG SET
                                TRAP C#CLP1
4818 ; Do a WRITE NPR to set loopback and tape direction IN
4819 057302 005000 CLR R0 ;CLR NP.OUT TO SET TAPE DIRECTION IN
4820 057304 052700 000040 BIS #NP.LOOP,R0 ;SET LOOPBACK
4821 057310 004737 062002 JSR PC,T19SNPR ;SETUP T19PK2 FOR WRITE NPR
4822 057314 012704 062440 MOV #T19PK2,R4 ;GET WRITE SUBSYSTEM COMMAND PACKET
4823 057320 010465 000000 MOV R4,TSDB(R5) ;SET THE PACKET ADDRESS TO EXECUTE
4824 057324 004737 016336 JSR PC,CHKTSSR ;WAIT FOR SSR TO SET
4825 057330 FORCERROR 182$ ;BDFORCE ERROR IF FORCER=1
4826 057344 103407 BCS 190$ ;BR IF CARRY SET (GOOD RETURN)
4827 057346 010001 MOV R0,R1 ;SAVE CONTENTS OF TSSR
4828 057350 NEXT.ERRNO
4829 057350 182$: ERRDF ERRNO,T194SSR,PKTSSR ;DEVICE FATAL SSR FAILED TO SET
                                TRAP C#ERDF
                                .WORD 848
                                .WORD T194SSR
                                .WORD PKTSSR
4830 057360 005237 002222 INC FATFLG ;SET FATAL ERROR FLAG
4831 057364 104406 190$: CKLOOP ;LOOP ON ERROR, IF FLAG SET
                                TRAP C#CLP1
4832 ; Do a WRITE FORMAT to set IRESV4==>IRSTR = 0

```

TSV5 HARDWARE TESTS MACRO M1113 14-JUN-84 15:55  
 TEST 8: SUBTEST 4 LOOPBACK READ STROBE TEST

SEQ 0206

```

4833 057366 005000 CLR R0 ;SET IRESV4==>IRSTR=0
4834 057370 004737 062122 JSR PC,T19WFMT ;SETUP T9PK2 FOR WRITE FORMAT
4835 057374 012704 062440 MOV #T19PK2,R4 ;GET WRITE SUBSYSTEM COMMAND PACKET
4836 057400 010465 000000 MOV R4,TSDB(R5) ;SET THE PACKET ADDRESS TO EXECUTE
4837 057404 004737 016336 JSR PC,CHKTSSR ;WAIT FOR SSR TO SET
4838 057410 FORCERROR 202$ ;GOODFORCE ERROR IF FORCER=1
4839 057424 103407 BCS 210$ ;BR IF CARRY SET (GOOD RETURN)
4840 057426 010001 MOV RO,R1 ;SAVE CONTENTS OF TSSR
4841 057430 NEXT.ERRNO
4842 057430 202$: ERDF ERRNO,T198SSR,PKTSSR ;DEVICE FATAL SSR FAILED TO SET
      057430 104455 TRAP C$ERDF
      057432 001521 .WORD 849
      057434 060572 .WORD T198SSR
      057436 012046 .WORD PKTSSR
4843 057440 005237 002222 INC FATFLG ;SET FATAL ERROR FLAG
4844 057444 210$: CKLOOP ;LOOP ON ERROR, IF FLAG SET
      057444 104406 TRAP C$CLP1
4845 ; Do a WRITE FORMAT to set IRESV4==>IRSTR = 1
4846 057446 01270C 000001 MOV #WF.I4RES,RO ;IRESV4==>IRSTR=1
4847 057452 004737 062122 JSR PC,T19WFMT ;SETUP T9PK2 FOR WRITE FORMAT
4848 057456 012704 062440 MOV #T19PK2,R4 ;GET WRITE SUBSYSTEM COMMAND PACKET
4849 057462 010465 000000 MOV R4,TSDB(R5) ;SET THE PACKET ADDRESS TO EXECUTE
4850 057466 004737 016336 JSR PC,CHKTSSR ;WAIT FOR SSR TO SET
4851 057472 FORCERROR 222$ ;GOODFORCE ERROR IF FORCER=1
4852 057506 103407 BCS 230$ ;BR IF CARRY SET (GOOD RETURN)
4853 057510 010001 MOV RO,R1 ;SAVE CONTENTS OF TSSR
4854 057512 NEXT.ERRNO
4855 057512 222$: ERDF ERRNO,T198SSR,PKTSSR ;DEVICE FATAL SSR FAILED TO SET
      057512 104455 TRAP C$ERDF
      057514 001522 .WORD 850
      057516 060572 .WORD T198SSR
      057520 012046 .WORD PKTSSR
4856 057522 005237 002222 INC FATFLG ;SET FATAL ERROR FLAG
4857 057526 230$: CKLOOP ;LOOP ON ERROR, IF FLAG SET
      057526 104406 TRAP C$CLP1
4858 ; Do a READ FIFO with tape direction IN to read data
4859 057530 012700 000001 MOV #1,RO ;SET READ BYTE COUNT
4860 057534 004737 062026 JSR PC,T19RFIF ;SETUP T19PK2 FOR READ FIFO
4861 057540 012704 062440 MOV #T19PK2,R4 ;GET WRITE SUBSYSTEM COMMAND PACKET
4862 057544 010465 000000 MOV R4,TSDB(R5) ;SET THE PACKET ADDRESS TO EXECUTE
4863 057550 004737 016336 JSR PC,CHKTSSR ;WAIT FOR SSR TO SET
4864 057554 FORCERROR 282$ ;GOODFORCE ERROR IF FORCER=1
4865 057570 103407 BCS 290$ ;BR IF CARRY SET (GOOD RETURN)
4866 057572 010001 MOV RO,R1 ;SAVE CONTENTS OF TSSR
4867 057574 NEXT.ERRNO
4868 057574 282$: ERDF ERRNO,T196SSR,PKTSSR ;DEVICE FATAL SSR FAILED TO SET
      057574 104455 TRAP C$ERDF
      057576 001523 .WORD 851
      057600 060460 .WORD T196SSR
      057602 012046 .WORD PKTSSR
4869 057604 005237 002222 INC FATFLG ;SET FATAL ERROR FLAG
4870 057610 290$: CKLOOP ;LOOP ON ERROR, IF FLAG SET
      057610 104406 TRAP C$CLP1
4871 ; If Data read from FIFO NOT= to Data sent Then Print Error
4872 057612 004737 062200 JSR PC,T19SETEXP ;SET WORDS 0-7 EXPD=RCV (NOT TESTING)
4873 057616 012701 060042 MOV #T19EXSTA,R1 ;GET EXPECTED READ STATUS
4874 057622 012702 062332 MOV #T19BFSTA,R2 ;GET RCV READ STATUS

```



TSV5 - HARDWARE TESTS MACRO M1113 14-JUN-84 15:55  
 TEST 8: SUBTEST 4 LOOPBACK READ STROBE TEST

SEQ 0207

```

4875 057626 013711 002312      MOV      DATA,(R1)          ;SET EXPD WORD #8 = DATA
4876 057632 016261 000002 000002  MOV      2(R2),2(R1)        ;SET EXPD WORD #9 = RECV (NOT TESTING)
4877 057640 005000              CLR      R0                 ;HIGH RECV ADDRESS FOR CKMSG2
4878 057642 012701 062312      MOV      @T19BFR,R1         ;LOW RECV ADDRESS FOR CKMSG2
4879 057646 012702 060022      MOV      @T19EXP,R2        ;EXPD ADDRESS
4880 057652 012703 000022      MOV      @18.,R3           ;NUMBER OF BYTES TO COMPARE
4881 057656 004737 011500      JSR      PC,CKMSG2         ;EXPD EQUAL RECV?
4882 057662              FORCERROR 302$,NOTSSR      ;BBD
4883 057672 103404              BCS     310$              ;BR IF YES
4884 057674              NEXT.ERRNO
4885 057674 302$:  ERRHRD  ERRNO,T19RSTR,MSGSUB ;REPORT ERROR
                                TRAP     C$ERHRD
                                .WORD   852
                                .WORD   T19RSTR
                                .WORD   MSGSUB
4886 057674 104456
4887 057676 001524
4888 057700 061610
4889 057702 013742
4886 057704 310$:  CK_OOP              ;LOOP ON ERROR, IF FLAG SET
4887 057704 104406              TRAP     C$CLP1
4888
4889 057706              FORCEEXIT 355$            ;BBD
4890 057716 013703 002316      MOV      TSTPTR,R3         ;RESTORE CURRENT TSTBLK POINTER
4891 057722 020327 003062      CMP      R3,@TBLEND        ;END OF TSTBLK?
4892 057726 103002              BHS     355$              ;BR IF YES
4893 057730 000137 056744      JMP      100$              ;DO ANOTHER TSTBLK PATTERN
4894 057734 355$:
4895
4896 057734              ENDSUB                  ;////////// END SUBTEST //////////
4897 057734              L10072:
4898 057734 104403              TRAP     C$ESUB
4899 057736 005737 002222      TST      FATFLG           ;ANY FATAL ERRORS ?
4899 057742 001402              BEQ     360$              ;BRANCH IF NOT
4900 057744 004737 017202      JSR      PC,CKDROP        ;TRY TO DROP THE UNIT
4901 057750 360$:
4902
4903 057750              EXIT  TST                ;////////// EXIT TEST //////////
4904 057750 104432              TRAP     C$EXIT
4905 057752 002602              .WORD   L10066
4906
4907 ;*
4908 ;LOCAL STORAGE FOR THIS TEST
4909 ;-
4910 057754 000000      T19PREV:  .WORD  0          ;DRIVE SIGNAL 1-0 TRANSITION FLAG
4911 ;*
4912 ; LOOPBACK DRIVE SIGNAL TABLE
4913 ; THIS TABLE IS USED BY T19CNVT TO SETUP
4914 ; A DRIVE PATTERN FROM THE TEST DATA INPUT PATTERN.
4915 ;
4916 ; WRITE CONTROL SIGNALS ARE OF FORM WC.XXX
4917 ; WRITE FORMAT SIGNALS ARE OF FORM WF.XXXX
4918 ;-
4919 057756      T19FCTL:  ;WRITE CONTROL DRIVE SIGNALS
4920 057756 000001      WC.IGO    ;IGO==>IFPT  DATA<0>
4921 057760 000002      WC.IFEN   ;IFEN==>IFBY  DATA<1>
4922 057762 000004      WC.IRWU   ;IRWU==>IRWD  DATA<2>

```

```

4923 057764 000010 WC.IREW ;IREW==>IDBY DATA<3>
4924 057766 002000 WF.IERASE*256. ;IFAD==>ILDY DATA<4>
4925 057770 000040 WC.I1TAD ;ITAD1==>IOML DATA<5>
4926 057772 000100 WC.IOTAD ;ITAD0==>IRDY DATA<6>
4927 057774 000200 WC.IFAD ;IERASE==>ISPEED DATA<7>
4928 057776 004000 WF.IEDIT*256. ;IEDIT==>IMER DATA<8>
4929 060000 010000 WF.IWFM*256. ;IWFM==>IFPK DATA<9>
4930 060002 020000 WF.IREV*256. ;IREV==>ICER DATA<10>
4931 060004 040000 WF.IWRT*256. ;IWRT==>IIDENT DATA<11>
4932 060006 100000 WF.IHISP*256. ;IHISP==>IEOT DATA<12>
4933 060010 000000 .WORD 0 ;IRESV2 (UNUSED)DATA<13>
4934 060012 000000 .WORD 0 ;IRESV1 (UNUSED)DATA<14>
4935 060014 000000 .WORD 0 ;PARERR (UNTESTED)DATA<15>
4936
4937 060016 T19MSK: ;MASK OF UNTESTED BITS IN READ STATUS BYTES
4938 ;UNTESTED BITS ARE SET TO 1
4939 060016 377 .BYTE +C<000> ;BYTE 0 MASK
4940 060017 037 .BYTE +C<340> ;BYTE 1 MASK (PARERR,IRESV2,IRESV1)
4941 060020 360 .BYTE +C<017> ;BYTE 2 (TIMER A,TIMER B,UNDEFINED<1:0>)
4942 060021 000 .BYTE 0 ;MAKE IT EVEN
4943
4944 060022 T19EXP: ;BEGIN EXPECTED DATA BUFFER
4945 060022 000000 .WORD 0 ;MESSAGE TYPE
4946 060024 000000 .WORD 0 ;DATA FIELD LENGTH
4947 060026 000000 .WORD 0 ;RBPGR
4948 060030 000000 .WORD 0 ;XST0
4949 060032 000000 .WORD 0 ;XST1
4950 060034 000000 .WORD 0 ;XST2
4951 060036 000000 .WORD 0 ;XST3
4952 060040 000000 .WORD 0 ;XST4 (ALWAYS PRESENT FOR WRITE SUB.)
4953 060042 T19EXSTA: .BLKB 64. ;EXPECTED READ STATUS AND WRITE FIFO DATA
4954 060142 T19XEND: ;END EXPECTED DATA BUFFER
4955
4956 ;LOCAL TEXT MESSAGES FOR TEST
4957
4958
4959 060142 124 162 141 TST19ID: .ASCIZ 'Transport Bus Interface Loopback
4960 060203 127 122 111 T19SSR: .ASCIZ 'WRITE CHARACTERISTICS Failed'
4961 060240 127 122 111 T192SSR: .ASCIZ 'WRITE SUBSYSTEM (Write Misc) Failed'
4962 060304 127 122 111 T193SSR: .ASCIZ 'WRITE SUBSYSTEM (Read Status) Failed'
4963 060351 127 122 111 T194SSR: .ASCIZ 'WRITE SUBSYSTEM (Write Npr) Failed'
4964 060414 127 122 111 T195SSR: .ASCIZ 'WRITE SUBSYSTEM (Write FIFO) Failed'
4965 060460 127 122 111 T196SSR: .ASCIZ 'WRITE SUBSYSTEM (Read FIFO) Failed'
4966 060523 127 122 111 T197SSR: .ASCIZ 'WRITE SUBSYSTEM (Write Control) Failed'
4967 060572 127 122 111 T198SSR: .ASCIZ 'WRITE SUBSYSTEM (Write Format) Failed'
4968 060640 106 111 106 T191CMP: .ASCIZ 'FIFO Status in WORD #9 Incorrect after Initialize'
4969 060722 122 145 141 T192CMP: .ASCIZ 'Read FIFO Data not equal to Write FIFO , Data is in WORD #8'
4970 061016 124 141 160 T193CMP: .ASCIZ 'Tape Status 2 (in WORD #8) Incorrect after RESET TAPE'
4971 061104 122 145 141 T195CMP: .ASCIZ 'Read FIFO Data not equal to Write FIFO Data'
4972 061160 106 111 106 T196CMP: .ASCIZ 'FIFO Status (in WORD #9) Incorrect after READ FIFO'
4973 061243 124 141 160 T197CMP: .ASCIZ 'Tape Status 2 (in WORD #8) Incorrect after RESET TAPE'
4974 061331 103 157 156 T198CMP: .ASCIZ 'Control Signal Loopback Data Error, Data is in WORD #8'
4975 061420 122 145 141 T199CMP: .ASCIZ 'Read/Write Loopback Data Error, Data is in WORD #8'
4976 061503 114 157 157 T19WSTR: .ASCIZ 'Loopback Data Error when strobed by Write strobe, Data is in WORD #8'
4977 061610 114 157 157 T19RSTR: .ASCIZ 'Loopback Data Error when strobed by Read Strobe, Data is in WORD #8'
4978
4979 .EVEN

```

```

4980
4981
4982 ; CLEAR MESSAGE BUFFER
4983
4984 061714
4985 061714
4986 061720 012701 062312
4987 061724 012702 000120
4988 061730 105021
4989 061732 005302
4990 061734 003375
4991 061736 000207
4992
4993
4994 ; SETUP T19PK2 PACKET FOR READ STATUS
4995
4996 061740
4997 061740 004737 061714
4998 061744 012700 062450
4999 061750 112720 000005
5000 061754 105010
5001 061756 000207
5002
5003
5004 ; SETUP T19PK2 PACKET FOR WRITE MISC Reset Tape Status F-FLOPS
5005
5006 061760
5007 061760 004737 061714
5008 061764 012700 062450
5009 061770 112720 000010
5010 061774 112710 000030
5011 062000 000207
5012
5013
5014 ; SETUP T19PK2 PACKET FOR WRITE NPR
5015
5016 ; INPUT:
5017 ; RO CONTAINS BSEL1 NPR DATA
5018
5019 ; SETS NP.WRP SINCE IF 0 IT WRITES WRONG PARITY.
5020
5021 062002
5022 062002 004737 061714
5023 062006 012701 062450
5024 062012 112721 000011
5025 062016 052700 000020
5026 062022 110011
5027 062024 000207
5028
5029
5030 ; SETUP T19PK2 PACKET FOR READ FIFO
5031
5032 ; INPUT:
5033 ; RO CONTAINS SEL2 BYTE COUNT
5034
5035 062026
5036 062026 004737 061714

```

```

; T19CLRBUF:
; SAVE R1-R5 UNTIL NEXT RETURN
; GET MESSAGE BUFFER ADDRESS
; SIZE OF MESSAGE BUFFER IN BYTES
; CLEAR A BYTE
; DONE?
; BR IF NO
; RETURN
SAVREG
MOV @T19BFR,R1
MOV @T19BEND-T19BFR,R2
101: CLRB (R1).
DEC R2
BGT 101
RTS PC

; T19SRD:
; CLEAR MESSAGE BUFFER
; WRITE SUBSYSTEM DATA BUFFER
; STORE READ STATUS COMMAND IN BSEL0
; CLEAR BSEL1
; RETURN
JSR PC,T19CLRBUF
MOV @T19DT2,RO
MOVB @PW.RDSTATUS,(RO).
CLRB (RO)
RTS PC

; T19RSFIF:
; CLEAR MESSAGE BUFFER
; WRITE SUBSYSTEM DATA BUFFER
; STORE WRITE MISCELLANEOUS IN BSEL0
; STORE BSEL1 CLEAR FIFO CODES
; RETURN
JSR PC,T19CLRBUF
MOV @T19DT2,RO
MOVB @PW.WMISC,(RO).
MOVB @MS.RSFIF!MS.RSTAP,(RO)
RTS PC

; T19SNPR:
; CLEAR MESSAGE BUFFER
; WRITE SUBSYSTEM DATA BUFFER
; STORE WRITE NPR IN BSEL0
; DON'T WRITE WRONG PARTY
; STORE NPR DATA IN BSEL1
; RETURN
JSR PC,T19CLRBUF
MOV @T19DT2,R1
MOVB @PW.WNPR,(R1).
BIS @NP.WRP,RO
MOVB RO,(R1)
RTS PC

; T19RFIF:
; CLEAR MESSAGE BUFFER

```

```

5037 062032 012701 062450      MOV      #T19DT2,R1      ;WRITE SUBSYSTEM DATA BUFFER
5038 062036 112721 000003      MOVB     #PW.RFIFO,(R1). ;STORE READ FIFO IN BSELO
5039 062042 110021              MOVB     RO,(R1).       ;STORE BYTE COUNT IN BSEL1
5040 062044 000207              RTS      PC             ;RETURN
5041                          ;*
5042                          ; SETUP T19PK2 PACKET FOR WRITE FIFO
5043                          ;
5044                          ; INPUT:
5045                          ; RO CONTAINS BYTE COUNT
5046                          ; R1 CONTAINS DATA PATTERN BLOCK ADDRESS
5047                          ;
5048 062046      T19WFIF:
5049 062046      SAVREG                    ;SAVE R1-R5 UNTIL NEXT RETURN
5050 062052 004737 061714      JSR      PC,T19CLRBUF    ;CLEAR MESSAGE BUFFER
5051 062056 012702 062450      MOV      #T19DT2,R2      ;WRITE SUBSYSTEM DATA BUFFER
5052 062062 112722 000004      MOVB     #PW.WFIFO,(R2). ;STORE WRITE FIFO IN BSELO
5053 062066 110022              MOVB     RO,(R2).       ;STORE BYTE COUNT IN BSEL1
5054 062070 005022              CLR      (R2).         ;CLEAR SEL2 (UNUSED)
5055 062072 112122      101:  MOVB     (R1).,(R2).    ;STORE DATA PATTERN BYTE
5056 062074 005300              DEC      RO            ;DONE ALL BYTES?
5057 062076 003375              BGT     101            ;BR IF NO
5058 062100 000207              RTS      PC             ;RETURN
5059                          ;*
5060                          ; SETUP T19PK2 FOR WRITE CONTROL
5061                          ;
5062                          ; INPUT:
5063                          ; RO CONTAINS DRIVING DATA PATTERN
5064                          ;
5065 062102      T19WCTL:
5066 062102 004737 061714      JSR      PC,T19CLRBUF    ;CLEAR MESSAGE BUFFER
5067 062106 012701 062450      MOV      #T19DT2,R1      ;WRITE SUBSYSTEM DATA BUFFER
5068 062112 112721 000006      MOVB     #PW.WCTL,(R1). ;STORE WRITE CONTROL IN BSELO
5069 062116 110021              MOVB     RO,(R1).       ;STORE DATA WORD IN BSEL1
5070 062120 000207              RTS      PC             ;RETURN
5071                          ;*
5072                          ; SETUP T19PK2 FOR WRITE FORMAT TRANSPORT REGISTER
5073                          ;
5074                          ; INPUT:
5075                          ; RO CONTAINS DRIVING DATA PATTERN
5076                          ;
5077 062122      T19WFMT:
5078 062122 004737 061714      JSR      PC,T19CLRBUF    ;CLEAR MESSAGE BUFFER
5079 062126 012701 062450      MOV      #T19DT2,R1      ;WRITE SUBSYSTEM DATA BUFFER
5080 062132 112721 000007      MOVB     #PW.WFMT,(R1). ;STORE WRITE FORMAT IN BSELO
5081 062136 110021              MOVB     RO,(R1).       ;STORE DATA WORD IN BSEL1
5082 062140 000207              RTS      PC             ;RETURN
5083                          ;*
5084                          ; SETUP T19PK2 PACKET FOR WRITE MISC. INVERT EXTENDED FEATURES SWITCH
5085                          ;
5086 062142      T19SEXT:
5087 062142 012700 062450      MOV      #T19DT2,RO      ;WRITE SUBSYSTEM DATA BUFFER
5088 062146 112720 000010      MOVB     #PW.WMISC,(RO). ;STORE WRITE MISCELLANEOUS IN BSELO
5089 062152 112710 000200      MOVB     #MS.EXT,(RO)   ;STORE INVERT EXTENDED FEATURES IN BSEL1
5090 062156 000207              RTS      PC             ;RETURN
5091                          ;*
5092                          ; CLEAR EXPECTED DATA MESSAGE BUFFER
5093                          ;

```

5094 062160  
5095 062160 012701 060022  
5096 062164 012700 000120  
5097 062170 105021  
5098 062172 005300  
5099 062174 003375  
5100 062176 000207  
5101  
5102  
5103  
5104  
5105 062200  
5106 062200 012702 060022  
5107 062204 012703 062312  
5108 062210 012700 000010  
5109 062214 012322  
5110 062216 005300  
5111 062220 003375  
5112 062222 000207  
5113  
5114  
5115  
5116  
5117  
5118  
5119  
5120  
5121  
5122  
5123  
5124  
5125  
5126  
5127  
5128  
5129  
5130 062224  
5131 062224 012701 057756  
5132 062230 005002  
5133 062234 012703 000020  
5134 062236 006000  
5135 062242 103001  
5136 062244 051102  
5137 062250 005721  
5138 062252 005303  
5139 062254 010200  
5140 062256 000207  
5141  
5142  
5143  
5144  
5145  
5147 062270  
5149  
5150  
5151  
5152 062270

```

T19CLEXP:
      MOV     #T19EXP,R1      ;GET EXPD ADDRESS
      MOV     #T19XEND-T19EXP,R0 ;GET EXPD SIZE
10$:  CLR     (R1)+           ;CLEAR A BYTE
      DEC     R0              ;DONE?
      BGT     10$            ;BR IF NO
      RTS     PC              ;RETURN

; *
; Set WORDS 0-7 of expd message BUFFER = to recv since not testing
; -
T19SETEXP:
      MOV     #T19EXP,R2      ;GET EXPD
      MOV     #T19BFR,R3      ;GET READ STATUS RECV BUFFER
      MOV     #8.,R0          ;SET WORDS 0-7 EXP=RECV
5$:   MOV     (R3)+,(R2)+     ;SET EXPD=RECV
      DEC     R0              ;DONE WORDS 0-7 WORDS?
      BGT     5$             ;BR IF NO
      RTS     PC              ;RETURN

; *
; CONVERT A TEST PATTERN DATA WORD TO LOOPBACK DRIVE SIGNALS
; INPUTS:
;       R0      TEST PATTERN
; IMPLICIT INPUTS:
;       T19BCTL - CONTAINS WRITE CONTROL / WRITE FORMAT CONVERSION BITS
; OUTPUTS:
;       R0      - LOW BYTE CONTAINS WRITE CONTROL DATA
;               - HIGH BYTE CONTAINS WRITE FORMAT DATA
; -
T19CNVT:
      SAVREG
      MOV     #T19BCTL,R1     ;SAVE R1-R5 UNTIL NEXT RETURN
      CLR     R2              ;CONVERSION TABLE ADDRESS
      MOV     #16.,R3         ;INIT RESULT OF CONVERSION
      MOV     R0              ;BIT COUNT
10$:  ROR     R0               ;IS THIS BIT EQUAL TO 1?
      BCC     20$            ;BR IF NO
      BIS     (R1),R2         ;SET CONVERTED BIT
20$:  TST     (R1)+           ;POINT TO NEXT BIT IN CONVERSION TABLE
      DEC     R3              ;DONE?
      BGT     10$            ;BR IF NO
      MOV     R2,R0           ;COPY RESULT
      RTS     PC              ;RETURN

      .=<.>10>&177770

; WRITE CHARACTERISTICS COMMAND PACKET
;
T19PACKET:
      ;COMMAND PACKET FOR TEST

```

TSV5 - HARDWARE TESTS MACRO M1113 14-JUN-84 15:55  
 TEST 8: SUBTEST 4 LOOPBACK READ STROBE TEST

SEQ 0212

```

5153 062270 100004 .WORD 100004 ;WRITE CHARACTERISTICS COMMAND, WITH ACK
5154 062272 062300 .WORD T19DATA ;ADDRESS OF CHARACTERISTICS BLOCK
5155 062274 000000 .WORD 0
5156 062276 000012 .WORD 10. ;MINIMUM MESSAGE PACKET SIZE
5157
5158 062300 T19DATA: ;CHARACTERISTICS DATA BLOCK
5159 062300 062312 .WORD T19BFR ;ADDRESS OF MESSAGE BUFFER
5160 062302 000000 .WORD 0
5161 062304 000024 .WORD 20. ;LENGTH OF MESSAGE BUFFER
5162 062306 000000 .WORD 0 ;ESS,ENB,EAI,ERI
5163 062310 000007 .WORD 7 ;EXTENDED FEATURES UNIT NO.
5164
5165
5166 ;MESSAGE BUFFER FOR ALL TEST 8 COMMANDS
5167
5168 062312 T19BFR: ;BEGIN MESSAGE BUFFER
5169 062312 000000 .WORD 0 ;MESSAGE TYPE
5170 062314 000000 .WORD 0 ;DATA FIELD LENGTH
5171 062316 000000 .WORD 0 ;RBPGR
5172 062320 000000 .WORD 0 ;XST0
5173 062322 000000 .WORD 0 ;XST1
5174 062324 000000 .WORD 0 ;XST2
5175 062326 000000 .WORD 0 ;XST3
5176 062330 000000 .WORD 0 ;XST4 (ALWAYS PRESENT FOR WRITE SUBSYSTEM
5177 062332 T19BFSTA: .BLKB 64. ;READ STATUS AND WRITE FIFO BUFFER
5178 062432 T19BEND: ;END OF MESSAGE BUFFER
5179
5180 ;WRITE SUBSYSTEM READ STATUS COMMAND PACKET
5181
5183 062440 ;
5185 062440 T19PK2: .=<.10>&177770
5186 062440 100006 .WORD P.WRTSUB!P.ACK ;WRITE SUBSYSTEM WITH ACK
5187 062442 062450 .WORD T19DT2 ;LOW ADDRESS OF DATA BLOCK
5188 062444 000000 .WORD 0 ;HIGH ADDRESS OF DATA BLOCK
5189 062446 000012 .WORD 10. ;MINIMUM MESSAGE PACKET SIZE
5190
5191 062450 T19DT2: ;DATA BLOCK
5192 062450 000 .BYTE 0 ;BSELO
5193 062451 000 .BYTE 0 ;BSEL1
5194 062452 000000 .WORD 0 ;SEL2
5195 062454 .BLKB 64. ;WRITE FIFO DATA OUTPUT BUFFER
5196
5197
5198 062554 ENDTST
062554 L10066: TRAP C1ETST
062554 104401
5199 .SBTTL TEST 9: READ/WRITE DATA PARITY TEST
5200
5201 ;**
5202 ; TEST DESCRIPTION:
5203 ;
5204 ; This test verifies that the Write Data Parity generator
5205 ; and the Read Data Parity checker operate properly. The
5206 ; Transport Bus signal loopback mode is enabled and a
5207 ; Set Wrong parity function is executed. Then various
5208 ; Write Subsystem Memory functions are performed to
5209 ; write data to and from the FIFO in loopback mode.
5209 ; The program then checks to insure a Read Data parity

```

```

5210 ; error occurred.
5211 ; A Reset FIFO is done and the Read Data parity
5212 ; error bit is again tested to insure it cleared.
5213 ; Finally a Clear wrong parity function is done
5214 ; and it is verified the data word can pass in loopback
5215 ; mode without setting Read Data parity error.
5216 ;
5217 ; TEST STEPS:
5218 ;
5219 ; REPEAT FOR LOOPCNT
5220 ; BEGIN
5221 ; Write to TSSR register to soft initialize the controller
5222 ; Do WRITE CHARACTERISTICS to check for Extended Features Switch
5223 ; If Extended Features Hardware Switch Clear then:
5224 ; Do Write Subsystem Write Miscellaneous to Set Extended Features.
5225 ; Do WRITE CHARACTERISTICS to select reserved unit 7 and setup BUFFER
5226 ; REPEAT FOR ALL TEST PATTERNS IN TSTBLK TABLE
5227 ; BEGIN
5228 ; (* Verify Write Wrong Parity Sets Parity Error *)
5229 ; Do a WRITE NPR to set loopback and tape direction OUT
5230 ; and SET Write Wrong Parity.
5231 ; Do a WRITE FORMAT to set IRESV4==>IRSTR = 1 (sets read strobe high)
5232 ; Do a WRITE FIFO with byte count equal to 1 and Tape direction OUT
5233 ; Do a READ FIFO with tape direction OUT to load tape out write latch
5234 ; (this is when wrong parity (IWP) is set)
5235 ; Do a WRITE FORMAT to set IRESV4==>IRSTR = 0 (sets read strobe low)
5236 ; (Read Strobe sets PAR IN H [Parity Error])
5237 ; Do a WRITE FORMAT to set IRESV4==>IRSTR = 1 (sets read strobe high)
5238 ; Do a Write Subsystem READ STATUS
5239 ; If Read Data parity error NOT=1 Then Print Error
5240 ; Do a Write Misc to RESET FIFO
5241 ; Do a Write Subsystem READ STATUS
5242 ; If Read Data parity error NOT=0 Then Print Error
5243 ;
5244 ; (* Verify Data can be transferred without a Parity Error *)
5245 ; Do a WRITE FORMAT to set IRESV4==>IRSTR = 1 (sets read strobe high)
5246 ; Do a WRITE NPR to set loopback and tape direction OUT
5247 ; and CLEAR Write Wrong Parity.
5248 ; Do a WRITE FIFO with byte count equal to 1 and Tape direction OUT
5249 ; Do a READ FIFO with tape direction OUT to load tape out write latch
5250 ; Do a WRITE FORMAT to set IRESV4==>IRSTR = 0 (sets read strobe low)
5251 ; (Read Strobe should NOT set PAR IN H [Parity Error] here)
5252 ; Do a WRITE FORMAT to set IRESV4==>IRSTR = 1 (sets read strobe high)
5253 ; Do a Write Subsystem READ STATUS
5254 ; If Read Data parity error NOT=0 Then Print Error
5255 ;
5256 ; END
5257 ;
5258 ;
5259 ;
5260 062556 BGNTST
5261 062556
5265 062556 012700 065142 MOV #TST20ID,R0 ;ASCII MESSAGE TO IDENTIFY TEST
5266 062562 004737 016510 JSR PC,TSTSETUP ;DO INITIAL TEST SETUP
5267 062566 012737 000012 002216 MOV #10,,LOOPCNT ;PERFORM 10 ITERATIONS
5268 062574 T20LOOP:
5269

```

```

5270 062574          BGN5UB          ;//////////////// BEGIN SUBTEST //////////////////
      062574          T9.1:
      062574 104402          TRAP      C#BSUB
5271          ;          Write to TSSR register to soft initialize the controller
5272 062576          5#:
5273 062576 004737 015774      JSR      PC,SOFINIT          ;WRITE TO TSSR TO SOFT INITIALIZE
5274 062602 103405          BCS      10#          ;BR IF SOFT INIT OKAY
5275 062604 010001          MOV      R0,R1          ;SAVE CONTENTS OF TSSR
5276 062606          ERRDF   ERRNO,SFIERR,SFIMSG          ;DEVICE FATAL DURING INIT
      062606 104455          TRAP      C#ERDF
      062610 001604          .WORD   900
      062612 003652          .WORD   SFIERR
      062614 012034          .WORD   SFIMSG
5277          ;          Do WRITE CHARACTERISTICS to check for Extended Features Switch
5278 062616 005037 002222      10#:  CLR      FATFLG          ;CLEAR FATAL ERROR FLAG
5279 062622 012704 066340      MOV      #T20PACKET,R4          ;GET THE ADDRESS OF COMMAND PACKET
5280 062626 004737 010662      JSR      PC,WRTCHR          ;DO WRITE CHARACTERISTICS COMMAND
5281 062632          FORCERROR 12#          ;BDFORCE ERROR IF FORCER=1
5282 062646 103407          BCS      15#          ;BR IF CARRY SET (GOOD RETURN)
5283 062650 010001          MOV      R0,R1          ;SAVE CONTENTS OF TSSR
5284 062652          NEXT.ERRNO
5285 062652          12#:  ERRDF   ERRNO,T20SSR,PKTSSR          ;DEVICE FATAL SSR FAILED TO SET
      062652 104455          TRAP      C#ERDF
      062654 001605          .WORD   901
      062656 065171          .WORD   T20SSR
      062660 012046          .WORD   PKTSSR
5286 062662 005237 002222      15#:  INC      FATFLG          ;SET FATAL ERROR FLAG
5287 062666          CKLOOP          ;LOOP ON ERROR, IF FLAG SET
      062666 104406          TRAP      C#CLP1
5288          ;          If Extended Features Hardware Switch Clear then:
5289          ;          Do Write Subsystem Write Miscellaneous to Set Extended Features.
5290 062670 012701 066362      MOV      #T20BFR,R1          ;MESSAGE BUFFER ADDRESS
5291 062674 032761 000200 000012  BIT      #X2.EXTF,XST2(R1)          ;EXTENDED FEATURES SWITCH SET?
5292 062702 001026          BNE      30#          ;BR IF YES
5293 062704 004737 066256      JSR      PC,T20SEXT          ;SETUP PACKET FOR WRITE MISC INVERT
5294 062710 012704 066510      MOV      #T20PK2,R4          ;GET WRITE SUBSYSTEM COMMAND PACKET
5295 062714 010465 000000      MOV      R4,TSD8(R5)          ;SET THE PACKET ADDRESS TO EXECUTE
5296 062720 004737 016336      JSR      PC,CHKTSSR          ;WAIT FOR SSR TO SET
5297 062724          FORCERROR 22#          ;BDFORCE ERROR IF FORCER=1
5298 062740 103407          BCS      30#          ;BR IF CARRY SET (GOOD RETURN)
5299 062742 010001          MOV      R0,R1          ;SAVE CONTENTS OF TSSR
5300 062744          NEXT.ERRNO
5301 062744          22#:  ERRDF   ERRNO,T202SSR,PKTSSR          ;DEVICE FATAL SSR FAILED TO SET
      062744 104455          TRAP      C#ERDF
      062746 001606          .WORD   902
      062750 065226          .WORD   T202SSR
      062752 012046          .WORD   PKTSSR
5302 062754 005237 002222      30#:  INC      FATFLG          ;SET FATAL ERROR FLAG
5303 062760          CKLOOP          ;LOOP ON ERROR, IF FLAG SET
      062760 104406          TRAP      C#CLP1
5304          ;          Do WRITE CHARACTERISTICS to select reserved unit 7
5305 062762 012704 066340      MOV      #T20PACKET,R4          ;GET THE ADDRESS OF COMMAND PACKET
5306 062766 004737 010662      JSR      PC,WRTCHR          ;DO WRITE CHARACTERISTICS COMMAND
5307 062772          FORCERROR 42#          ;BDFORCE ERROR IF FORCER=1
5308 063006 103407          BCS      50#          ;BR IF CARRY SET (GOOD RETURN)
5309 063010 010001          MOV      R0,R1          ;SAVE CONTENTS OF TSSR
5310 063012          NEXT.ERRNO

```



```

5311 063012          42$:  ERRDF  ERRNO,T20SSR,PKTSSR      ;DEVICE FATAL SSR FAILED TO SET
      063012 104455                                     TRAP      C#ERDF
      063014 001607                                     .WORD    903
      063016 065171                                     .WORD    T20SSR
      063020 012046                                     .WORD    PKTSSR
5312 063022 005237 002222          INC      FATFLG      ;SET FATAL ERROR FLAG
5313 063026          50$:  CKLOOP      ;LOOP ON ERROR, IF FLAG SET
      063026 104406                                     TRAP      C#CLP1

5314
5315
5316          ; REPEAT FOR ALL TEST PATTERNS IN TSTBLK TABLE
5317 063030 012703 002752          MOV      #TSTBLK,R3      ;GLT FIRST PATTERN ADDRESS
5318 063034 012337 002312          100$:  MOV      (R3)+,DATA      ;GET A TEST PATTERN
5319 063040 042737 177400 002312  BIC      #C<377>,DATA      ;DATA IS BYTE
5320 063046 010337 002316          MOV      R3,TSTPTR      ;SETUP CURRENT TSTBLK POINTER
5321          ; Do a WRITE NPR to set loopback and tape direction OUT and
5322          ; and SET Write Wrong Parity.
5323 063052 012700 000100          MOV      #NP.OUT,R0      ;SET TAPE DIRECTION OUT
5324 063056 052700 000040          BIS      #NP.LOOP,R0      ;SET LOOPBACK
5325 063062 042700 000020          BIC      #NP.WRP,R0      ;SET WRITE WRONG PARITY (INVERTED)
5326 063066 004737 066126          JSR      PC,T20WNPTR      ;SETUP T20PK2 FOR WRITE NPR
5327 063072 012704 066510          MOV      #T20PK2,R4      ;GET WRITE SUBSYSTEM COMMAND PACKET
5328 063076 010465 000000          MCV     R4,TSDB(R5)      ;SET THE PACKET ADDRESS TO EXECUTE
5329 063102 004737 016336          JSR      PC,CHKTSSR      ;WAIT FOR SSR TO SET
5330 063106          FORCERROR 102$      ;BADFORCE ERROR IF FORCER=1
5331 063122 103407          BCS     105$      ;BR IF CARRY SET (GOOD RETURN)
5332 063124 010001          MOV     R0,R1      ;SAVE CONTENTS OF TSSR
5333 063126
5334 063126          102$:  ERRDF  ERRNO,T204SSR,PKTSSR      ;DEVICE FATAL SSR FAILED TO SET
      063126 104455                                     TRAP      C#ERDF
      063130 001610                                     .WORD    904
      063132 065337                                     .WORD    T204SSR
      063134 012046                                     .WORD    PKTSSR
5335 063136 005237 002222          INC      FATFLG      ;SET FATAL ERROR FLAG
5336 063142          105$:  CKLOOP      ;LOOP ON ERROR, IF FLAG SET
      063142 104406                                     TRAP      C#CLP1

5337          ; Do a WRITE FORMAT to set IRESV4==>IRSTR = 1 (sets read strobe high)
5338 063144 012700 000001          MOV      #WF.I4RES,R0      ;IRESV4==>IRSTR = 1
5339 063150 004737 066222          JSR      PC,T20WFMT      ;SETUP T20PK2 FOR WRITE FORMAT
5340 063154 012704 066510          MOV      #T20PK2,R4      ;GET WRITE SUBSYSTEM COMMAND PACKET
5341 063160 010465 000000          MOV      R4,TSDB(R5)      ;SET THE PACKET ADDRESS TO EXECUTE
5342 063164 004737 016336          JSR      PC,CHKTSSR      ;WAIT FOR SSR TO SET
5343 063170          FORCERROR 112$      ;BADFORCE ERROR IF FORCER=1
5344 063204 103407          BCS     120$      ;BR IF CARRY SET (GOOD RETURN)
5345 063206 010001          MOV     R0,R1      ;SAVE CONTENTS OF TSSR
5346 063210
5347 063210          112$:  ERRDF  ERRNO,T208SSR,PKTSSR      ;DEVICE FATAL SSR FAILED TO SET
      063210 104455                                     TRAP      C#ERDF
      063212 001611                                     .WORD    905
      063214 065511                                     .WORD    T208SSR
      063216 012046                                     .WORD    PKTSSR
5348 063220 005237 002222          INC      FATFLG      ;SET FATAL ERROR FLAG
5349 063224          120$:  CKLOOP      ;LOOP ON ERROR, IF FLAG SET
      063224 104406                                     TRAP      C#CLP1

5350          ; Do a WRITE FIFO with byte count equal to 1 and Tape direction OUT
5351 063226 012700 000001          MOV      #1,R0      ;WRITE 1 BYTE
5352 063232 012701 002312          MOV      #DATA,R1      ;FIFO WRITE DATA ADDRESS
    
```

```

5353 063236 004737 066166      JSR    PC,T20WFIF      ;SETUP T20PK2 FOR WRITE FIFO
5354 063242 012704 066510      MOV    #T20PK2,R4     ;GET WRITE SUBSYSTEM COMMAND PACKET
5355 063246 010465 000000      MOV    R4,TSDB(R5)   ;SET THE PACKET ADDRESS TO EXECUTE
5356 063252 004737 016336      JSR    PC,CHKTSSR    ;WAIT FOR SSR TO SET
5357 063256          FORCERROR 152$ ;BDFORCE ERROR IF FORCER=1
5358 063272 103407          BCS    160$         ;BR IF CARRY SET (GOOD RETURN)
5359 063274 010001          MOV    R0,R1        ;SAVE CONTENTS OF TSSR
5360 063276          NEXT.ERRNO
5361 063276          152$: ERRDF  ERRNO,T205SSR,PKTSSR ;DEVICE FATAL SSR FAILED TO SET
          063276 104455          TRAP    C$ERDF
          063300 001612          .WORD  906
          063302 065402          .WORD  T205SSR
          063304 012046          .WORD  PKTSSR
5362 063306 005237 002222      INC    FATFLG        ;SET FATAL ERROR FLAG
5363 063312          160$: CKLOOP      ;LOOP ON ERROR, IF FLAG SET
          063312 104406          TRAP    C$CLP1
5364          ; Do a READ FIFO with tape direction OUT to load tape out write latch
5365          ; (this is when wrong parity (IWP) is set)
5366 063314 012700 000001      MOV    #1,R0         ;SET READ BYTE COUNT
5367 063320 004737 066146      JSR    PC,T20RFIF    ;SETUP T20PK2 FOR READ FIFO
5368 063324 012704 066510      MOV    #T20PK2,R4     ;GET WRITE SUBSYSTEM COMMAND PACKET
5369 063330 010465 000000      MOV    R4,TSDB(R5)   ;SET THE PACKET ADDRESS TO EXECUTE
5370 063334 004737 016336      JSR    PC,CHKTSSR    ;WAIT FOR SSR TO SET
5371 063340          FORCERROR 172$ ;BDFORCE ERROR IF FORCER=1
5372 063354 103407          BCS    180$         ;BR IF CARRY SET (GOOD RETURN)
5373 063356 010001          MOV    R0,R1        ;SAVE CONTENTS OF TSSR
5374 063360          NEXT.ERRNO
5375 063360          172$: ERRDF  ERRNO,T206SSR,PKTSSR ;DEVICE FATAL SSR FAILED TO SET
          063360 104455          TRAP    C$ERDF
          063362 001613          .WORD  907
          063364 065446          .WORD  T206SSR
          063366 012046          .WORD  PKTSSR
5376 063370 005237 002222      INC    FATFLG        ;SET FATAL ERROR FLAG
5377 063374          180$: CKLOOP      ;LOOP ON ERROR, IF FLAG SET
          063374 104406          TRAP    C$CLP1
5378          ; Do a WRITE FORMAT to set IRESV4==>IRSTR = 0 (sets read strobe low)
5379          ; (Read Strobe sets PAR IN H [Parity Error])
5380 063376 005000          CLR    R0           ;IRESV4==>IRSTR = 0
5381 063400 004737 066222      JSR    PC,T20WFMT    ;SETUP T20PK2 FOR WRITE FORMAT
5382 063404 012704 066510      MOV    #T20PK2,R4     ;GET WRITE SUBSYSTEM COMMAND PACKET
5383 063410 010465 000000      MOV    R4,TSDB(R5)   ;SET THE PACKET ADDRESS TO EXECUTE
5384 063414 004737 016336      JSR    PC,CHKTSSR    ;WAIT FOR SSR TO SET
5385 063420          FORCERROR 192$ ;BDFORCE ERROR IF FORCER=1
5386 063434 103407          BCS    200$         ;BR IF CARRY SET (GOOD RETURN)
5387 063436 010001          MOV    R0,R1        ;SAVE CONTENTS OF TSSR
5388 063440          NEXT.ERRNO
5389 063440          192$: ERRDF  ERRNO,T208SSR,PKTSSR ;DEVICE FATAL SSR FAILED TO SET
          063440 104455          TRAP    C$ERDF
          063442 001614          .WORD  908
          063444 065511          .WORD  T208SSR
          063446 012046          .WORD  PKTSSR
5390 063450 005237 002222      INC    FATFLG        ;SET FATAL ERROR FLAG
5391 063454          200$: CKLOOP      ;LOOP ON ERROR, IF FLAG SET
          063454 104406          TRAP    C$CLP1
5392          ; Do a WRITE FORMAT to set IRESV4==>IRSTR = 1 (sets read strobe high)
5393 063456 012700 000001      MOV    #WF.I4RES,R0   ;IRESV4==>IRSTR = 1
5394 063462 004737 066222      JSR    PC,T20WFMT    ;SETUP T20PK2 FOR WRITE FORMAT
    
```

```

5395 063466 012704 066510      MOV      #T20PK2,R4      ;GET WRITE SUBSYSTEM COMMAND PACKET
5396 063472 010465 000000      MOV      R4,TSDB(R5)    ;SET THE PACKET ADDRESS TO EXECUTE
5397 063476 064737 016336      JSR      PC,CHKTSSR     ;WAIT FOR SSR TO SET
5398 063502                    FORCERROR 212$          ;@@DFORCE ERROR IF FORCER=1
5399 063516 103407                    BCS      220$          ;BR IF CARRY SET (GOOD RETURN)
5400 063520 010001                    MOV      R0,R1         ;SAVE CONTENTS OF TSSR
5401 063522                    NEXT.ERRNO
5402 063522 212$:  ERRDF  ERRNO,T208SSR,PKTSSR ;DEVICE FATAL SSR FAILED TO SET
                    TRAP      C$ERDF
                    .WORD     909
                    .WORD     T208SSR
                    .WORD     PKTSSR
5403 063532 005237 002222      INC      FATFLG        ;SET FATAL ERROR FLAG
5404 063536 220$:  CKLOOP                    ;LOOP ON ERROR, IF FLAG SET
                    TRAP      C$CLP1
5405                    ; Do a Write Subsystem READ STATUS
5406 063540 004737 066106      JSR      PC,T20SRD     ;SETUP PACKET FOR READ STATUS
5407 063544 012704 066510      MOV      #T20PK2,R4    ;GET WRITE SUBSYSTEM COMMAND PACKET
5408 063550 010465 000000      MOV      R4,TSDB(R5)  ;SET THE PACKET ADDRESS TO EXECUTE
5409 063554 004737 016336      JSR      PC,CHKTSSR     ;WAIT FOR SSR TO SET
5410 063560                    FORCERROR 232$          ;@@DFORCE ERROR IF FORCER=1
5411 063574 103407                    BCS      240$          ;BR IF CARRY SET (GOOD RETURN)
5412 063576 010001                    MOV      R0,R1         ;SAVE CONTENTS OF TSSR
5413 063600                    NEXT.ERRNO
5414 063600 232$:  ERRDF  ERRNO,T203SSR,PKTSSR ;DEVICE FATAL SSR FAILED TO SET
                    TRAP      C$ERDF
                    .WORD     910
                    .WORD     T203SSR
                    .WORD     PKTSSR
5415 063610 005237 002222      INC      FATFLG        ;SET FATAL ERROR FLAG
5416 063614 240$:  CKLOC                    ;LOOP ON ERROR, IF FLAG SET
                    TRAP      C$CLP1
5417                    ; If Read Data parity error NOT=1 Then Print Error
5418 063616 004737 066314      JSR      PC,T20SETEXP  ;SET WORDS 0-7 EXPD=RECV (NOT TESTING)
5419 063622 012701 065042      MOV      #T20EXSTA,R1 ;GET EXPECTED READ STATUS
5420 063626 012702 066402      MOV      #T20BFSTA,R2 ;GET RECV READ STATUS
5421 063632 011211                    MOV      (R2),(R1)     ;SET EXPD WORD #8 = RECV TEMP
5422 063634 016261 000002 000002  MOV      2(R2),2(R1)   ;SET EXPD WORD #9 = RECV (NOT TESTED)
5423 063642 052711 100000                    BIS      #S1.PARERR,(R1) ;SET EXP PAR ERR =1
5424 063646 005000                    CLR      R0            ;HIGH RECV ADDRESS FOR CKMSG2
5425 063650 012701 066362      MOV      #T20BFR,R1   ;LOW RECV ADDRESS FOR CKMSG2
5426 063654 012702 065022      MOV      #T20EXP,R2   ;EXPD ADDRESS
5427 063660 012703 000024      MOV      #20.,R3      ;NUMBER OF BYTES TO COMPARE
5428 063664 004737 011500      JSR      PC,CKMSG2    ;EXPD EQUAL RECV?
5429 063670                    FORCERROR 252$,NOTSSR ;@@
5430 063700 103404                    BCS      260$          ;BR IF YES
5431 063702                    NEXT.ERRNO
5432 063702 252$:  ERRHRD ERRNO,T20SWP,MSGSTAT ;REPORT ERROR
                    TRAP      C$ERHRD
                    .WORD     911
                    .WORD     T20SWP
                    .WORD     MSGSTAT
5433 063712 260$:  CKLOOP                    ;LOOP ON ERROR, IF FLAG SET
                    TRAP      C$CLP1
5434                    ; Do a Write Misc to RESET FIFO
5435 063714 012700 000020      MOV      #MS.RSFIF,R0 ;SET RESET FIFO COMMAND
5436 063720 004737 066242      JSR      PC,T20WMISC  ;SETUP T20PK2 FOR WRITE MISC

```

```

5437 063724 012704 066510      MOV      @T20PK2,R4      ;GET WRITE SUBSYSTEM COMMAND PACKET
5438 063730 010465 000000      MOV      R4,TSDB(R5)    ;SET THE PACKET ADDRESS TO EXECUTE
5439 063734 004737 016336      JSR      PC,CHKTSSR     ;WAIT FOR SSR TO SET
5440 063740                      FORCERROR 282$         ;BDDFORCE ERROR IF FORCER=1
5441 063754 103407                      BCS      290$         ;BR IF CARRY SET (GOOD RETURN)
5442 063756 010001                      MOV      R0,R1        ;SAVE CONTENTS OF TSSR
5443 063760                      NEXT.ERRNO
5444 063760 282$:  ERRDF  ERRNO,T202SSR,PKTSSR ;DEVICE FATAL SSR FAILED TO SET
                                TRAP      C$ERDF
                                .WORD     912
                                .WORD     T202SSR
                                .WORD     PKTSSR
5445 063770 005237 002222      INC      FATFLG        ;SET FATAL ERROR FLAG
5446 063774 063774 104406 290$:  CKLOOP          ;LOOP ON ERROR, IF FLAG SET
                                TRAP      C$CLP1
5447 :                               ; Do a Write Subsystem READ STATUS
5448 :                               ; If Read Data parity error NOT=0 Then Print Error
5449 063776 004737 066314      JSR      PC,T20SETEXP   ;SET WORDS 0-7 EXPD=RECV (NOT TESTING)
5450 064002 012701 065042      MOV      @T20EXSTA,R1  ;GET EXPECTED READ STATUS
5451 064006 012702 066402      MOV      @T20BFSTA,R2  ;GET RECV READ STATUS
5452 064012 011211                      MOV      (R2),(R1)     ;SET EXPD WORD #8 = RECV TEMP
5453 064014 016261 000002 000002 MOV      2(R2),2(R1)    ;SET EXPD WORD #9 = RECV (NOT TESTED)
5454 064022 042711 100000      BIC      @S1.PARERR,(R1) ;SET EXP PAR ERR =0
5455 064026 005000                      CLR      R0           ;HIGH RECV ADDRESS FOR CKMSG2
5456 064030 012701 066362      MOV      @T20BFR,R1    ;LOW RECV ADDRESS FOR CKMSG2
5457 064034 012702 045022      MOV      @T20EXP,R2    ;EXPD ADDRESS
5458 064040 012703 000024      MOV      @20.,R3       ;NUMBER OF BYTES TO COMPARE
5459 064044 004737 011500      JSR      PC,CKMSG2     ;EXPD EQUAL RECV?
5460 064050                      FORCERROR 302$,NOTSSR ;BDD
5461 064060 103404                      BCS      320$         ;BR IF YES
5462 064062                      NEXT.ERRNO
5463 064062 302$:  ERRHRD  ERRNO,T20RSF,MSGSTAT ;REPORT ERROR
                                TRAP      C$ERHRD
                                .WORD     913
                                .WORD     T20RSF
                                .WORD     MSGSTAT
5464 064072 064072 104406 320$:  CKLOOP          ;LOOP ON ERROR, IF FLAG SET
                                TRAP      C$CLP1
5465 :                               ; (* Verify Data can be transferred without a Parity Error *)
5466 :                               ; Do a WRITE FORMAT to set IRESV4==>IRSTR = 1 (sets read strobe high)
5467 064074 012700 000001      MOV      @WF.I4RES,R0  ;IRESV4==>IRSTR = 1
5468 064100 004737 066222      JSR      PC,T20WFMT    ;SETUP T20PK2 FOR WRITE FORMAT
5469 064104 012704 066510      MOV      @T20PK2,R4    ;GET WRITE SUBSYSTEM COMMAND PACKET
5470 064110 010465 000000      MOV      R4,TSDB(R5)  ;SET THE PACKET ADDRESS TO EXECUTE
5471 064114 004737 016336      JSR      PC,CHKTSSR     ;WAIT FOR SSR TO SET
5472 064120                      FORCERROR 332$         ;BDDFORCE ERROR IF FORCER=1
5473 064134 103407                      BCS      340$         ;BR IF CARRY SET (GOOD RETURN)
5474 064136 010001                      MOV      R0,R1        ;SAVE CONTENTS OF TSSR
5475 064140                      NEXT.ERRNO
5476 064140 332$:  ERRDF  ERRNO,T208SSR,PKTSSR ;DEVICE FATAL SSR FAILED TO SET
                                TRAP      C$ERDF
                                .WORD     914
                                .WORD     T208SSR
                                .WORD     PKTSSR
5477 064150 005237 002222      INC      FATFLG        ;SET FATAL ERROR FLAG
5478 064154 064154 104406 340$:  CKLOOP          ;LOOP ON ERROR, IF FLAG SET
                                TRAP      C$CLP1

```

```

5479 : Do a WRITE NPR to set loopback and tape direction OUT and
5480 : and CLEAR Write Wrong Parity.
5481 064156 012700 000100 MOV @NP.OUT,R0 ;SET TAPE DIRECTION OUT
5482 064162 052700 000040 BIS @NP.LOOP,R0 ;SET LOOPBACK
5483 064166 052700 000020 BIS @NP.WRP,R0 ;CLEAR WRITE WRONG PARITY (INVERTED)
5484 064172 004737 066126 JSR PC,T20WNP ;SETUP T20PK2 FOR WRITE NPR
5485 064176 012704 066510 MOV @T20PK2,R4 ;GET WRITE SUBSYSTEM COMMAND PACKET
5486 064202 010465 000000 MOV R4,TSDB(R5) ;SET THE PACKET ADDRESS TO EXECUTE
5487 064206 004737 016336 JSR PC,CHKTSSR ;WAIT FOR SSR TO SET
5488 064212 FORCERROR 352: ;BDFORCE ERROR IF FORCER=1
5489 064226 103407 BCS 360: ;BR IF CARRY SET (GOOD RETURN)
5490 064230 010001 MOV R0,R1 ;SAVE CONTENTS OF TSSR
5491 064232 NEXT.ERRNO
5492 064232 352: ERDF ERRNO,T204SSR,PKTSSR ;DEVICE FATAL SSR FAILED TO SET
      TRAP C1ERDF
      .WORD 915
      .WORD T204SSR
      .WORD PKTSSR
5493 064242 005237 002222 INC FATFLG ;SET FATAL ERROR FLAG
5494 064246 360: CKLOOP ;LOOP ON ERROR, IF FLAG SET
      TRAP C1CLP1
5495 : Do a WRITE FIFO with byte count equal to 1 and Tape direction OUT
5496 064250 012700 000001 MOV @1,R0 ;WRITE 1 BYTE
5497 064254 012701 002312 MOV @DATA,R1 ;FIFO WRITE DATA ADDRESS
5498 064260 004737 066166 JSR PC,T20WFIF ;SETUP T20PK2 FOR WRITE FIFO
5499 064264 012704 066510 MOV @T20PK2,R4 ;GET WRITE SUBSYSTEM COMMAND PACKET
5500 064270 010465 000000 MOV R4,TSDB(R5) ;SET THE PACKET ADDRESS TO EXECUTE
5501 064274 004737 016336 JSR PC,CHKTSSR ;WAIT FOR SSR TO SET
5502 064300 FORCERROR 372: ;BDFORCE ERROR IF FORCER=1
5503 064314 103407 BCS 380: ;BR IF CARRY SET (GOOD RETURN)
5504 064316 010001 MOV R0,R1 ;SAVE CONTENTS OF TSSR
5505 064320 NEXT.ERRNO
5506 064320 372: ERDF ERRNO,T205SSR,PKTSSR ;DEVICE FATAL SSR FAILED TO SET
      TRAP C1ERDF
      .WORD 916
      .WORD T205SSR
      .WORD PKTSSR
5507 064330 005237 002222 INC FATFLG ;SET FATAL ERROR FLAG
5508 064334 380: CKLOOP ;LOOP ON ERROR, IF FLAG SET
      TRAP C1CLP1
5509 : Do a READ FIFO with tape direction OUT to load tape out write latch
5510 064336 012700 000001 MOV @1,R0 ;SET READ BYTE COUNT
5511 064342 004737 066146 JSR PC,T20RFIF ;SETUP T20PK2 FOR READ FIFO
5512 064346 012704 066510 MOV @T20PK2,R4 ;GET WRITE SUBSYSTEM COMMAND PACKET
5513 064352 010465 000000 MOV R4,TSDB(R5) ;SET THE PACKET ADDRESS TO EXECUTE
5514 064356 004737 016336 JSR PC,CHKTSSR ;WAIT FOR SSR TO SET
5515 064362 FORCERROR 392: ;BDFORCE ERROR IF FORCER=1
5516 064376 103407 BCS 400: ;BR IF CARRY SET (GOOD RETURN)
5517 064400 010001 MOV R0,R1 ;SAVE CONTENTS OF TSSR
5518 064402 NEXT.ERRNO
5519 064402 392: ERDF ERRNO,T206SSR,PKTSSR ;DEVICE FATAL SSR FAILED TO SET
      TRAP C1ERDF
      .WORD 917
      .WORD T206SSR
      .WORD PKTSSR
5520 064412 005237 002222 INC FATFLG ;SET FATAL ERROR FLAG
5521 064416 400: CKLOOP ;LOOP ON ERROR, IF FLAG SET
  
```

```

064416 104406                                     TRAP C$CLP1
5522 ; Do a WRITE FORMAT to set IRESV4==>IRSTR = 0 (sets read strobe low)
5523 ; (Read Strobe sets PAR IN H [Parity Error])
5524 064420 005000 CLR R0 ; IRESV4==>IRSTR = 0
5525 064422 004737 066222 JSR PC,T20WFMT ; SETUP T20PK2 FOR WRITE FORMAT
5526 064426 012704 066510 MOV @T20PK2,R4 ; GET WRITE SUBSYSTEM COMMAND PACKET
5527 064432 010465 000000 MOV R4,TSD8(R5) ; SET THE PACKET ADDRESS TO EXECUTE
5528 064436 004737 016336 JSR PC,CHKTSSR ; WAIT FOR SSR TO SET
5529 064442 FORCERROR 412$ ; BDDFORCE ERROR IF FORCER=1
5530 064456 103407 BCS 420$ ; BR IF CARRY SET (GOOD RETURN)
5531 064460 010001 MOV R0,R1 ; SAVE CONTENTS OF TSSR
5532 064462 NEXT.ERRNO
5533 064462 412$: ERRDF ERRNO,T208SSR,PKTSSR ; DEVICE FATAL SSR FAILED TO SET
                                     TRAP C$ERDF
                                     .WORD 918
                                     .WORD T208SSR
                                     .WORD PKTSSR
064462 104455
064464 J01626
064466 065511
064470 012046
5534 064472 005237 002222 INC FATFLG ; SET FATAL ERROR FLAG
5535 064476 420$: CKLOOP ; LOOP ON ERROR, IF FLAG SET
064476 104406 TRAP C$CLP1
5536 ; Do a WRITE FORMAT to set IRESV4==>IRSTR = 1 (sets read strobe high)
5537 064500 012700 000001 MOV @WF.I4RES,R0 ; IRESV4==>IRSTR = 1
5538 064504 004737 066222 JSR PC,T20WFMT ; SETUP T20PK2 FOR WRITE FORMAT
5539 064510 012704 066510 MOV @T20PK2,R4 ; GET WRITE SUBSYSTEM COMMAND PACKET
5540 064514 010465 000000 MOV R4,TSD8(R5) ; SET THE PACKET ADDRESS TO EXECUTE
5541 064520 004737 016336 JSR PC,CHKTSSR ; WAIT FOR SSR TO SET
5542 064524 FORCERROR 432$ ; BDDFORCE ERROR IF FORCER=1
5543 064540 103407 BCS 440$ ; BR IF CARRY SET (GOOD RETURN)
5544 064542 010001 MOV R0,R1 ; SAVE CONTENTS OF TSSR
5545 064544 NEXT.ERRNO
5546 064544 432$: ERRDF ERRNO,T208SSR,PKTSSR ; DEVICE FATAL SSR FAILED TO SET
                                     TRAP C$ERDF
                                     .WORD 919
                                     .WORD T208SSR
                                     .WORD PKTSSR
064544 104455
064546 001627
064550 065511
064552 012046
5547 064554 005237 002222 INC FATFLG ; SET FATAL ERROR FLAG
5548 064560 440$: CKLOOP ; LOOP ON ERROR, IF FLAG SET
064560 104406 TRAP C$CLP1
5549
5550 ; Do a Write Subsystem READ STATUS
5551 064562 004737 066106 JSR PC,T20SRD ; SETUP PACKET FOR READ STATUS
5552 064566 012704 066510 MOV @T20PK2,R4 ; GET WRITE SUBSYSTEM COMMAND PACKET
5553 064572 010465 000000 MOV R4,TSD8(R5) ; SET THE PACKET ADDRESS TO EXECUTE
5554 064576 004737 016336 JSR PC,CHKTSSR ; WAIT FOR SSR TO SET
5555 064602 FORCERROR 452$ ; BDDFORCE ERROR IF FORCER=1
5556 064616 103407 BCS 460$ ; BR IF CARRY SET (GOOD RETURN)
5557 064620 010001 MOV R0,R1 ; SAVE CONTENTS OF TSSR
5558 064622 NEXT.ERRNO
5559 064622 452$: ERRDF ERRNO,T203SSR,PKTSSR ; DEVICE FATAL SSR FAILED TO SET
                                     TRAP C$ERDF
                                     .WORD 920
                                     .WORD T203SSR
                                     .WORD PKTSSR
064622 104455
064624 001630
064626 065272
064630 012046
5560 064632 005237 002222 INC FATFLG ; SET FATAL ERROR FLAG
5561 064636 460$: CKLOOP ; LOOP ON ERROR, IF FLAG SET
064636 104406 TRAP C$CLP1
5562 . If Read Data parity error NOT=0 Then Print Error

```

```

5563 064640 004737 066314      JSR      PC,T20SETEXP      ;SET WORDS 0-7 EXPD=RECV (NOT TESTING)
5564 064644 012701 065042      MOV      @T20EXSTA,R1     ;GET EXPECTED READ STATUS
5565 064650 012702 066402      MOV      @T20BFSTA,R2    ;GET RECV READ STATUS
5566 064654 011211              MOV      (R2),(R1)        ;SET EXPD WORD #8 = RECV TEMP
5567 064656 016261 000002 000002  MOV      2(R2),2(R1)      ;SET EXPD WORD #9 = RECV (NOT TESTED)
5568 064664 042711 100000      BIC      @S1.PARERR,(R1) ;SET EXP PAR ERR =0
5569 064670 005000              CLR      R0              ;HIGH RECV ADDRESS FOR CKMSG2
5570 064672 012701 066362      MOV      @T20BFR,R1      ;LOW RECV ADDRESS FOR CKMSG2
5571 064676 012702 065022      MOV      @T20EXP,R2      ;EXPD ADDRESS
5572 064702 012703 000024      MOV      @20.,R3         ;NUMBER OF BYTES TO COMPARE
5573 064706 004737 011500      JSR      PC,CKMSG2       ;EXPD EQUAL RECV?
5574 064712              FORCERROR 472$,NOTSSR    ;BBD
5575 064722 103404              BCS      480$           ;BR IF YES
5576 064724              NEXT.ERRNO
5577 064724 472$:  ERRMRD  ERRNO,T20CWP,MSGSTAT ;REPORT ERROR
                    TRAP      C$ERRMRD
                    .WORD     921
                    .WORD     T20CWP
                    .WORD     MSGSTAT
5578 064734 480$:  CKLOOP              ;LOOP ON ERROR, IF FLAG SET
                    TRAP      C$CLP1
5579 064736              FORCEEXIT 555$
5580 064746 013703 002316      MOV      TSTPTR,R3       ;BBD
5581 064752 020327 003062      CMP      R3,@TBLEND     ;RESTORE CURRENT TSTBLK POINTER
5582 064756 103002              BHS      555$           ;END OF TSTBLK?
5583 064760 000137 063034      JMP      100$           ;BR IF YES
5584 064764              ;DO ANOTHER TSTBLK PATTERN
5585 064764 555$:
5586 064764              ENDSUB
                    ;////////// END SUBTEST //////////
                    L10074:
                    TRAP      C$ESUB
5588 064766 005737 002222      TST      FATFLG         ;ANY FATAL ERRORS ?
5589 064772 001402              BEQ      560$           ;BRANCH IF NOT
5590 064774 004737 017202      JSR      PC,CKDROP      ;TRY TO DROP THE UNIT
5591 065000 560$:
5592 065000 004737 016456      JSR      PC,TSTLOOP     ;DO ITERATIONS?
5593 065004 103002              BCC      565$           ;BR IF NO
5594 065006 000137 050466      JMP      T18LOOP        ;LOOP UNTIL ITERATIONS DONE
5595 065012 565$:
5596 065012              EXIT      TST
                    ;////////// EXIT TEST //////////
                    TRAP      C$EXIT
                    .WORD     L10073-.
5598
5599
5600
5601      ; LOCAL STORAGE FOR THIS TEST
5602
5603
5604
5605 065016  T20MSK:
5606
5607 065016 377      .BYTE   +C<000>
5608 065017 037      .BYTE   +C<340>
5609 065020 360      .BYTE   +C<017>
5610 065021 000      .BYTE   0
                    ;MASK OF UNTESTED BITS IN READ STATUS
                    ;UNTESTED BITS ARE SET TO 1
                    ;BYTE 0 MASK
                    ;BYTE 1 MASK (PARERR,IRESV2,IRESV1)
                    ;BYTE 2 (TIMER A,TIMER B,UNDEFINED<1:0>)
                    ;MAKE IT EVEN

```

```

5611
5612 065022          T20EXP:          ;BEGIN EXPECTED DATA BUFFER
5613 065022 000000          .WORD 0          ;MESSAGE TYPE
5614 065024 000000          .WORD 0          ;DATA FIELD LENGTH
5615 065026 000000          .WORD 0          ;RBPGR
5616 065030 000000          .WORD 0          ;XST0
5617 065032 000000          .WORD 0          ;XST1
5618 065034 000000          .WORD 0          ;XST2
5619 065036 000000          .WORD 0          ;XST3
5620 065040 000000          .WORD 0          ;XST4 (ALWAYS PRESENT FOR WRITE SUB.)
5621 065042          T20EXSTA: .BLKB 64.      ;EXPECTED READ STATUS AND WRITE FIFO DATA
5622 065142          T20XEND:          ;END EXPECTED DATA BUFFER
5623
5624          ;*
5625          ;LOCAL TEXT MESSAGES FOR TEST
5626          ;
5627 065142          122          145          141 TST20ID: .ASCIZ 'Read/Write Data Parity'
5628 065171          127          122          111 T20SSR: .ASCIZ 'WRITE CHARACTERISTICS Failed'
5629 065226          127          122          111 T202SSR: .ASCIZ 'WRITE SUBSYSTEM (Write Misc) Failed'
5630 065272          127          122          111 T203SSR: .ASCIZ 'WRITE SUBSYSTEM (Read Status) Failed'
5631 065337          127          122          111 T204SSR: .ASCIZ 'WRITE SUBSYSTEM (Write Npr) Failed'
5632 065402          127          122          111 T205SSR: .ASCIZ 'WRITE SUBSYSTEM (Write FIFO) Failed'
5633 065446          127          122          111 T206SSR: .ASCIZ 'WRITE SUBSYSTEM (Read FIFO) Failed'
5634 065511          127          122          111 T208SSR: .ASCIZ 'WRITE SUBSYSTEM (Write Format) Failed'
5635 065557          122          145          141 T20SMP: .ASCIZ 'Read Data Parity Error (PARERR) Failed to Set after Write Wrong Parity'
5636 065666          122          145          141 T20RSF: .ASCIZ 'Read Data Parity Error (PARERR) Failed to Clear after RESET FIFO'
5637 065767          122          145          141 T20CMP: .ASCIZ 'Read Data Parity Error (PARERR) occurred in Data Loopback'
5638          .EVEN
5639
5640          ;*
5641          ; CLEAR MESSAGE BUFFER
5642          ;-
5643 066062          T20CLRBUF:          ;
5644 066062          SAVREG          ;SAVE R1-R5 UNTIL NEXT RETURN
5645 066066 012701 066362          MOV #T20BFR,R1          ;GET MESSAGE BUFFER ADDRESS
5646 066072 012702 000120          MOV #T20BEND-T20BFR,R2      ;SIZE OF MESSAGE BUFFER IN BYTES
5647 066076 105021          104: CLR R1          ;CLEAR A BYTE
5648 066100 005302          DEC R2          ;DONE?
5649 066102 003375          BGT 104          ;BR IF NO
5650 066104 000207          RTS PC          ;RETURN
5651
5652          ;*
5653          ; SETUP T20PK2 PACKET FOR READ STATUS
5654          ;-
5655 066106          T20SRD:          ;
5656 066106 004737 066062          JSR PC,T20CLRBUF          ;CLEAR MESSAGE BUFFER
5657 066112 012700 066520          MOV #T20DT2,R0          ;WRITE SUBSYSTEM DATA BUFFER
5658 066116 112720 000005          MOVB #PW.RDSTATUS,(R0).    ;STORE READ STATUS COMMAND IN BSEL0
5659 066122 105010          CLRB (R0)          ;CLEAR BSEL1
5660 066124 000207          RTS PC          ;RETURN
5661
5662          ;*
5663          ; SETUP T20PK2 PACKET FOR WRITE NPR
5664          ;
5665          ;
5666          ; INPJ:
5667          ; RO CONTAINS BSEL1 NPR DATA

```



```

5668 ;
5669 ;
5670 066126 ; T20WNPR:
5671 066126 004737 066062 JSR PC,T20CLRBUF ;CLEAR MESSAGE BUFFER
5672 066132 012701 066520 MOV #T20DT2,R1 ;WRITE SUBSYSTEM DATA BUFFER
5673 066136 112721 000011 MOVB #PW.WNPR,(R1). ;STORE WRITE NPR IN BSELO
5674 066142 110011 MOVB RO,(R1) ;STORE NPR DATA IN BSEL1
5675 066144 000207 RTS PC ;RETURN
5676 ;
5677 ;*
5678 ; SETUP T20PK2 PACKET FOR READ FIFO
5679 ;
5680 ; INPUT:
5681 ; RO CONTAINS SEL2 BYTE COUNT
5682 ;-
5683 066146 ; T20RFIF:
5684 066146 004737 066062 JSR PC,T20CLRBUF ;CLEAR MESSAGE BUFFER
5685 066152 012701 066520 MOV #T20DT2,R1 ;WRITE SUBSYSTEM DATA BUFFER
5686 066156 112721 000003 MOVB #PW.RFIFO,(R1). ;STORE READ FIFO IN BSELO
5687 066162 110021 MOVB RO,(R1). ;STORE BYTE COUNT IN BSEL1
5688 066164 000207 RTS PC ;RETURN
5689 ;
5690 ;*
5691 ; SETUP T20PK2 PACKET FOR WRITE FIFO
5692 ;
5693 ; INPUT:
5694 ; RO CONTAINS BYTE COUNT
5695 ; R1 CONTAINS DATA PATTERN BLOCK ADDRESS
5696 ;-
5696 066166 ; T20WFIF:
5697 066166 SAVREG ;SAVE R1-R5 UNTIL NEXT RETURN
5698 066172 004737 066062 JSR PC,T20CLRBUF ;CLEAR MESSAGE BUFFER
5699 066176 012702 066520 MOV #T20DT2,R2 ;WRITE SUBSYSTEM DATA BUFFER
5700 066202 112722 000004 MOVB #PW.WFIFO,(R2). ;STORE WRITE FIFO IN BSELO
5701 066206 110022 MOVB RO,(R2). ;STORE BYTE COUNT IN BSEL1
5702 066210 005022 CLR (R2). ;CLEAR SEL2 (UNUSED)
5703 066212 112122 101: MOVB (R1).,(R2). ;STORE DATA PATTERN BYTE
5704 066214 005300 DEC RO ;DONE ALL BYTES?
5705 066216 003375 BGT 101 ;BR IF NO
5706 066220 000207 RTS PC ;RETURN
5707 ;
5708 ;*
5709 ; SETUP T20PK2 FOR WRITE FORMAT TRANSPORT REGISTER
5710 ;
5711 ; INPUT:
5712 ; RO CONTAINS DRIVING DATA PATTERN
5713 ;-
5714 066222 ; T20WFMT:
5715 066222 004737 066062 JSR PC,T20CLRBUF ;CLEAR MESSAGE BUFFER
5716 066226 012701 066520 MOV #T20DT2,R1 ;WRITE SUBSYSTEM DATA BUFFER
5717 066232 112721 000007 MOVB #PW.WFMT,(R1). ;STORE WRITE FORMAT IN BSELO
5718 066236 110021 MOVB RO,(R1). ;STORE DATA WORD IN BSEL1
5719 066240 000207 RTS PC ;RETURN
5720 ;
5721 ;*
5722 ; SETUP T20PK2 PACKET FOR WRITE MISC.
5723 ;
5724 ; RO CONTAINS WRITE MISC DATA
  
```

```

5725 066242          T20WMISC:
5726 066242 012701 066520      MOV      #T20DT2,R1      ;WRITE SUBSYSTEM DATA BUFFER
5727 066246 112721 000010      MOVB     #PW.WMISC,(R1)+ ;STORE WRITE MISCELLANEOUS IN BSEL0
5728 066252 110011              MOVB     RO,(R1)         ;STORE INVERT EXTENDED FEATURES IN BSEL1
5729 066254 000207              RTS      PC             ;RETURN
5730
5731                  ;*
5732                  ; SETUP T20PK2 PACKET FOR WRITE MISC. INVERT EXTENDED FEATURES SWITCH
5733 066256          T20SEXT:
5734 066256 012700 066520      MOV      #T20DT2,RO      ;WRITE SUBSYSTEM DATA BUFFER
5735 066262 112720 000010      MOVB     #PW.WMISC,(RO)+ ;STORE WRITE MISCELLANEOUS IN BSEL0
5736 066266 112710 000200      MOVB     #MS.EXT,(RO)    ;STORE INVERT EXTENDED FEATURES IN BSEL1
5737 066272 000207              RTS      PC             ;RETURN
5738
5739                  ;*
5740                  ; CLEAR EXPECTED DATA MESSAGE BUFFER
5741 066274          T20CLEXP:
5742 066274 012701 065022      MOV      #T20EXP,R1      ;GET EXPD ADDRESS
5743 066300 012700 000120      MOV      #T20EXEND-T20EXP,RO ;GET EXPD SIZE
5744 066304 105021              CLRB    (R1)+           ;CLEAR A BYTE
5745 066306 005300              DEC     RO              ;DONE?
5746 066310 003375              BGT     10$            ;BR IF NO
5747 066312 000207              RTS      PC             ;RETURN
5748
5749                  ;*
5750                  ;Set WORDS 0-7 of expd message BUFFER = to recv since not testing
5751
5752 066314          T20SETEXP:
5753 066314 012702 065022      MOV      #T20EXP,R2      ;GET EXPD
5754 066320 012703 066362      MOV      #T20BFR,R3      ;GET READ STATUS RECV BUFFER
5755 066324 012700 000010      MOV      #B.,RO          ;SET WORDS 0-7 EXP=RECV
5756 066330 012322              MOV      (R3)+,(R2)+     ;SET EXPD=RECV
5757 066332 005300              DEC     RO              ;DONE WORDS 0-7 WORDS?
5758 066334 003375              BGT     5$             ;BR IF NO
5759 066336 000207              RTS      PC             ;RETURN
5760
5761
5762
5766
5767                  ;
5768                  ;WRITE CHARACTERISTICS COMMAND PACKET
5769 066340          T20PACKET:
5770 066340 100004              .WORD   100004          ;COMMAND PACKET FOR TEST
5771 066342 066350              .WORD   T20DATA        ;WRITE CHARACTERISTICS COMMAND, WITH ACK
5772 066344 000000              .WORD   0               ;ADDRESS OF CHARACTERISTICS BLOCK
5773 066346 000012              .WORD   10.            ;MINIMUM MESSAGE PACKET SIZE
5774
5775 066350          T20DATA:
5776 066350 066362              .WORD   T20BFR          ;CHARACTERISTICS DATA BLOCK
5777 066352 000000              .WORD   0               ;ADDRESS OF MESSAGE BUFFER
5778 066354 000024              .WORD   20.            ;LENGTH OF MESSAGE BUFFER
5779 066356 000000              .WORD   0               ;ESS,ENB,EAI,ERI
5780 066360 000007              .WORD   7               ;EXTENDED FEATURES UNIT NO.
5781
5782
5783                  ;MESSAGE BUFFER FOR ALL TEST 17 COMMANDS
5784

```

5785 066362  
 5786 066362 000000  
 5787 066364 000000  
 5788 066366 000000  
 5789 066370 000000  
 5790 066372 000000  
 5791 066374 000000  
 5792 066376 000000  
 5793 066400 000000  
 5794 066402  
 5795 066502  
 5796  
 5797  
 5798  
 5800 066510  
 5802 066510  
 5803 066510 100006  
 5804 066512 066520  
 5805 066514 000000  
 5806 066516 000012  
 5807  
 5808 066520  
 5809 066520 000  
 5810 066521 000  
 5811 066522 000000  
 5812 066524  
 5813  
 5814  
 5815 066624  
 066624  
 066624 104401  
 5816  
 5817  
 5818  
 5819  
 5820  
 5821  
 5822  
 5823  
 5824  
 5825  
 5826  
 5827  
 5828  
 5829  
 5830  
 5831  
 5832  
 5833  
 5834  
 5835  
 5836  
 5837  
 5838  
 5839  
 5840  
 5841

```

T20BFR:          ;BEGIN MESSAGE BUFFER
                  ;MESSAGE TYPE
                  ;DATA FIELD LENGTH
                  ;RBPCR
                  ;XST0
                  ;XST1
                  ;XST2
                  ;XST3
                  ;XST4 (ALWAYS PRESENT FOR WRITE SUBSYSTEM
T20BFSTA: .BLKB 64. ;READ STATUS AND WRITE FIFO BUFFER
T20BEND:         ;END OF MESSAGE BUFFER
;
;WRITE SUBSYSTEM READ STATUS COMMAND PACKET
;
;      .=<.10>&177770
T20PK2:
                  .WORD  P.WRTSUB!P.ACK      ;WRITE SUBSYSTEM WITH ACK
                  .WORD  T20DT2             ;LOW ADDRESS OF DATA BLOCK
                  .WORD  0                   ;HIGH ADDRESS OF DATA BLOCK
                  .WORD  10.                ;MINIMUM MESSAGE PACKET SIZE
T20DT2:
                  ;DATA BLOCK
                  .BYTE  0                   ;BSEL0
                  .BYTE  0                   ;BSEL1
                  .WORD  0                   ;SEL2
                  .BLKB  64.                ;WRITE FIFO DATA OUTPUT BUFFER
;
;      ENDTST
;
;      L10073:      TRAP      C$ETST
;
;      .SBTTL  TEST 10: MANUAL INTERVENTION
;
;THE MANUAL INTERVENTION TEST IS A STANDALONE ROUTINE (NOT REALLY A "TEST")
;THAT ALLOWS THE OPERATOR TO CHECK OUT VARIOUS ELEMENTS AND FUNCTIONS OF
;THE SUBSYSTEM THAT CANNOT BE MANIPULATED BY THE PROGRAM ALONE. WHEN
;THIS ROUTINE IS STARTED, IT FIRST PRINTS OUT A MENU OF SELECTABLE
;SUBTESTS AND THEN WAITS FOR THE OPERATOR TO TYPE IN A SELECTION CODE.
;THE ONLY WAYS TO EXIT THIS ROUTINE AND RETURN TO THE DIAGNOSTIC SUPERVISOR
;ARE BY TYPING <CTRL-C> OR SELECTING CODE 7.
;SELECTION CODES AND SUBROUTINES ARE:
;
;      CODE  ROUTINE
;
;      0     HELP. PRINTS THIS MENU.
;      1     TURN ON ALL M7196 LED INDICATORS
;      2     TURN OFF ALL M7196 LED INDICATORS
;      3     OFFLINE/ONLINE ATTENTION TEST
;      4     WRITE-PROTECT TEST
;      5     INITIATE TRANSPORT SERVO EXERCISER
;      6     PRINT EXTENDED TRANSPORT STATUS
;      7     EXIT (RETURN TO SUPERVISOR)
;
;EACH MENU ITEM CORRESPONDS TO A SUBTEST, AS FOLLOWS:
;

```

```
5842 ;
5843 ;
5844 ; PRINTS OUT THE MENU ON THE CONSOLE TERMINAL
5845 ;
5846 ;
5847 ; CAUSES ALL THREE LED INDICATORS ON THE M7196 MODULE
5848 ; TO BE ILLUMINATED. AFTER INITIATING THIS ROUTINE, THE OPERATOR
5849 ; SHOULD OBSERVE THE LED'S AND VERIFY THAT THEY ARE INDEED ALL LIT.
5850 ; THIS ROUTINE FIRST USES THE WRITE SUBSYSTEM MEMORY COMMAND TO
5851 ; SET THE FORCE WRONG PARITY FLIP-FLOP, WHICH SERVES TO DRIVE THE
5852 ; "PROCESSOR NOT OK" LED. THEN IT ENTERS A LOOP THAT CONTINUALLY
5853 ; WRITES THE LOW BYTE OF TSDB AND READS THE TSSR. THESE LATTER TWO
5854 ; OPERATIONS WILL CAUSE THE "NOT SSR" AND "DRIVING BUS" LED'S TO
5855 ; GLOW -- THEY ARE NOT REALLY LIT AT ALL TIMES BUT SHOULD APPEAR
5856 ; REASONABLY VISIBLE.
5857 ;
5858 ;
5859 ; INITIALIZES THE CONTROLLER TO CAUSE ALL LED'S TO
5860 ; EXTINGUISH.
5861 ;
5862 ;
5863 ;
5864 ;
5865 ; THIS ROUTINE INITIALIZES THE CONTROLLER, ISSUES A
5866 ; WRITE CHARACTERISTICS COMMAND TO ENABLE ATTENTION INTERRUPTS,
5867 ; ISSUES A MESSAGE BUFFER RELEASE COMMAND, PRINTS A MESSAGE ON THE
5868 ; CONSOLE TERMINAL. INSTRUCTING THE OPERATOR TO TOGGLE THE ON-LINE
5869 ; SWITCH ON THE TRANSPORT, THEN WAITS FOR AN ATTENTION INTERRUPT.
5870 ; EACH TIME THE TRANSPORT TRANSITIONS FROM ON-LINE TO OFF-LINE OR
5871 ; VICE-VERSA, AN ATTENTION INTERRUPT SHOULD BE GENERATED. THE PROGRAM
5872 ; WILL REPORT THE INTERRUPT AND THE CURRENT STATE OF THE TRANSPORT.
5873 ; THE OPERATOR SHOULD VERIFY THAT THE REPORTED STATE MATCHES THE
5874 ; STATE INDICATED BY THE LED ON THE FRONT PANEL OF THE TRANSPORT.
5875 ; IN ADDITION, WHEN THE TRANSPORT IS PLACED OFF-LINE, THE PROGRAM
5876 ; ISSUES A SEQUENCE OF TAPE-MOTION COMMANDS (READ, WRITE, POSITION, ETC.
5877 ; AND VERIFIES THAT, FOR EACH COMMAND, FUNCTION REJECT TERMINATION
5878 ; RESULTS, ALONG WITH THE NON-EXECUTABLE FUNCTION (NEF) ERROR BIT BEING
5879 ; SET.
5880 ;
5881 ; THIS ROUTINE INSTRUCTS THE OPERATOR TO MOUNT A SCRATCH
5882 ; TAPE REEL THAT DOES NOT HAVE A WRITE-ENABLE RING INSTALLED. THEN
5883 ; WAITS FOR THE OPERATOR TO RESPOND THAT THIS HAS BEEN ACCOMPLISHED.
5884 ; UPON THE RESPONSE, THE PROGRAM VERIFIES THAT THE TRANSPORT SHOWS
5885 ; A WRITE-PROTECTED STATUS, THEN ATTEMPTS TO WRITE DATA ON THE
5886 ; TAPE AND EXPECTS THE APPROPRIATE ERROR TERMINATION INDICATING THAT
5887 ; THE WRITE FUNCTION COULD NOT BE PERFORMED BECAUSE THE REEL IS
5888 ; WRITE-PROTECTED. IF THE APPROPRIATE TERMINATION IS NOT RECEIVED,
5889 ; AN ERROR IS REPORTED.
5890 ;
5891 ;
5892 ;
5893 ; INSTRUCTS THE OPERATOR TO PLACE THE TAPE TRANSPORT(S)
5894 ; ON-LINE (IF ANY ARE OFF-LINE) THEN ATTEMPTS TO PERFORM AN EXTENDED
5895 ; STATUS READOUT. FOR EACH TRANSPORT EQUIPPED WITH THIS FEATURE,
5896 ; THE PROGRAM FORMATS AND PRINTS OUT THE RESULTING STATUS. IF THE
5897 ; TRANSPORT IS NOT EQUIPPED WITH THIS FEATURE, A MESSAGE INDICATING
5898 ; SUCH IS ISSUED.
```

```

5899      ;
5900      ;
5901      ;
5902      ;
5903 066626      BGNTST
5904 066626
5908 066626      RFLAGS R0      ;GET OPERATOR FLAGS      T10::
5909 066626      104421      ;BR, IF OK TO RUN      TRAP      C#RFLA
5910 066630      001403      BEQ      21#      ;"TEST NOT EXECUTED"
5911 066632      012700      072210      MOV      #T38NE,R0      ;JUMP IF NOT FIRST TEST
5912 066636      000402      BR      3#
5913 066640      012700      073325      21#:      MOV      #T38ID,R0      ;TEST ID MESSAGE
5914 066644      004737      016510      3#:      JSR      PC,TSTSETUP      ;DO THE COMMON SETUP
5915 066650      004737      020500      JSR      PC,CHKMAN      ;IS MANUAL INTERVENTION ALLOWED?
5916 066654      103402      BCS      22#      ;BR, IF MANUAL INTER ALLOWED
5917 066656      000137      071410      JMP      64#      ;JUMP IF NOT ALLOWED
5918 066662
5922 066662      005037      002222      22#:      CLR      FATFLG      ;CLEAR THE FATAL ERROR FLAG
5923 066666      012737      176750      2#:      MOV      #65000.,T38DLY      ;SET UP DELAY COUNTER
5924 066674      004737      015774      071422      5#:      JSR      PC,SOFINIT      ;DO A SOFT INIT
5925 066700      103427      BCS      23#      ;BRANCH IF OK
5926 066702      010001      MOV      R0,R1      ;CONTENTS OF TSSR REGISTER
5927 066704      032701      000200      BIT      #SSR,R1      ;CHECK FOR TSSR SET
5928 066710      001023      BNE      23#      ;KEEP GOING IF NOT SET
5929 066712      DELAY      250      ;CALL DELAY ROUTINE
5930 066712      012727      000250      MOV      #250,(PC)+
5931 066716      000000      .WORD      0
5932 066720      013727      002116      MOV      L#DLY,(PC)+
5933 066724      000000      .WORD      0
5934 066726      005367      177772      DEC      -6(PC)
5935 066732      001375      BNE      -.4
5936 066734      005367      177756      DEC      -22(PC)
5937 066740      001367      BNE      -.20
5938 066742      005337      071422      DEC      T38DLY      ;BUMP COUNTER DOWN
5939 066746      001352      BNE      5#      ;BR, IF MORE TIME LEFT
5940 066750      ERRDF      ERRNO,SFIERR,SFIMSG      ;REPORT FATAL ERROR
5941 066750      104455      TRAP      C#ERRDF
5942 066752      001751      .WORD      1001
5943 066754      003652      .WORD      SFIERR
5944 066756      012034      .WORD      SFIMSG
5945 066760      012700      073352      23#:      MOV      #MIMENU,R0      ;MENU OF MANUAL INTERVENTIONS
5946 066764      012701      000006      MOV      #6,R1      ;MAXIMUM ALLOWED SELECTION
5947 066770      004737      020256      JSR      PC,GETSEL      ;GO GET THE OPERATORS SELECTION
5948 066774      010004      MOV      R0,R4      ;GET NUMBER FROM ROUTINE
5949 066776      006304      ASL      R4      ;CONVERT TO WORD OFFSET
5950 067000      000174      067004      JMP      #6*(R4)      ;JUMP TO PROPER LOOP
5951 067004      066662      6#:      .WORD      2#      ;RETYPE THE MENU
5952 067006      067022      .WORD      10#      ; 1 TURN ON LED'S
5953 067010      067304      .WORD      15#      ; 2 TURN OFF LED'S
5954 067012      067536      .WORD      20#      ; 3 ONLINE ATTENTION
5955 067014      070172      .WORD      25#      ; 4 WRITE PROTECT
5956 067016      071126      .WORD      35#      ; 5 EXTENDED TRANSPORT STATUS
5957 067020      071404      .WORD      63#      ; 6 LEAVE THE TEST
5958 067022      073221      10#:      PRINTF      #T38MS2      ;TELL OPERATOR TO CNTRL-C FOR EXIT
5959 067026      012746      000001      MOV      #T38MS2,-(SP)
5960 067026      012746      MOV      #1,-(SP)

```

```

067032 010600                                MOV    SP,R0
067034 104417                                TRAP   C#PNTF
067036 062706 000004                          ADD    #4,SP
5947 067042 004737 073756                    JSR    PC,T38REST ;SET PACKET TO INITIAL VALUES
5948 067046 004737 015774                    JSR    PC,SOFINIT ;DO SOFT INIT OF CONTROLLER
5949 067052 103405                            BCS    100# ;BR IF SOFT INIT = OK
5953 067054 010001                            MOV    R0,R1 ;SAVE CONTENTS OF TSSR
5954 067056                                ERRDF  ERRNO,SFIERR,SFIMSG ;DEVICE FATAL ERROR DURING INIT
067056 104455                                TRAP   C#ERDF
067060 001752                                .WORD 1002
067062 003652                                .WORD SFIERR
067064 012034                                .WORD SFIMSG
5955 067066 013737 002202 072150 100# :     MOV    UNITN,T38DSW ;SET UNIT NUMBER
5956
5957 067074 012704 072130                    MOV    #T38PK2,R4 ;SUBROUTINE NEEDS PACKET ADDRESS
5958 067100 004737 010662                    JSR    PC,WRTCHR ;ISSUE WRITE CHARACTERISTICS
5959 067104 103405                            BCS    110# ;BR, IF COMMAND ISSUED OK
5963 067106 010001                            MOV    R0,R1 ;SAVE CONTENTS OF TSSR
5964 067110                                ERRMRD ERRNO,WRTMSG,SFIMSG ;WRITE CHARACTERISTIC FAILED
067110 104456                                TRAP   C#ERMRD
067112 001753                                .WORD 1003
067114 005056                                .WORD WRTMSG
067116 012034                                .WORD SFIMSG
5965 067120
5966 067120 112737 000000 071441 110# :     MOVB   #0,T38BS1 ;CLEAR BIT #4
5967 067126 112737 000011 071440            MOVB   #11,T38BS0 ;WRITE MISC COMMAND
5968 067134 012704 071430                    MOV    #T38PACKET,R4 ;SET UP NEW WRT. SUBSYS MEM. COMMAND
5969
5970 ;NOTE: THIS COMMAND TURNS ON THE PROCESSOR FAIL LED
5971 ;
5972 067140 010465 000000                    MOV    R4,TSDB(R5) ;SET THE PACKET ADDRESS
5973 067144 004737 016336                    JSR    PC,CHKTSSR ;WAIT FOR SSR TO SET
5974 067150 103405                            BCS    150# ;BR IF CARRY SET (GOOD RETURN)
5975 067152 010001                            MOV    R0,R1 ;SAVE CONTENTS OF TSSR
5979 067154                                ERRDF  ERRNO,T38SSR,PKTSSR ;DEVICE FATAL SSR FAILED TO SET
067154 104455                                TRAP   C#ERDF
067156 001754                                .WORD 1004
067160 072626                                .WORD T38SSR
067162 012046                                .WORD PKTSSR
5980 067164                                150# :     CKLOOP ;LOOP ON ERROR, IF FLAG SET
067164 104406                                TRAP   C#CLP1
5981 067166                                SETPRI #PRI07 ;RAISE THE PRIORITY
067166 012700 000340                            MOV    #PRI07,R0
067172 104441                                TRAP   C#SPRI
5982 067174 005037 071414                    CLR    TTION2 ;ASSUME INTERRUPTS ARE ENABLED
5983 067200 032737 000100 177560            BIT    #100,#TTICSR ;ARE TTI INTERRUPTS ON ?
5984 067206 001005                            BNE    701# ;BRANCH IF YES
5985 067210 005237 071414                    INC    TTION2 ;FLAG SET IF INTERRUPTS OFF
5986 067214 052737 000100 177560            BIS    #100,#TTICSR ;ENABLE INTERRUPTS
5987 067222 012701 000060 701# :     MOV    #TTIVEC,R1 ;START OF TTI VECTORS
5988 067226 011137 071416                    MOV    (R1),TVSAV2 ;SAVE THE CURRENT TTI VECTOR
5989 067232 012721 070710                    MOV    #590#,(R1) ;SET NEW INTERRUPT ROUTINE
5990 067236 011137 071420                    MOV    (R1),TPSAV2 ;SAVE THE VECTOR PRIORITY
5991 067242 012711 000340                    MOV    #PRI07,(R1) ;USE PRIORITY SEVEN
5992 067246                                SETPRI #PRI00 ;LOWER INTERRUPT BR LEVEL
067246 012700 000000                            MOV    #PRI00,R0
067252 104441                                TRAP   C#SPRI

```

```

5993 067254 012701 177777      MOV      # 1,R1      ;DATA TO WRITE TO TSD8
5994 067260 000240      12$:  NOP          ;ALLOW OPERATOR TO TYPE ↑C
5995 067262 012702 001750      MOV      #1000.,R2   ;SET-UP INNER LOOP
5996 067266 110165 000000      14$:  MOVB     R1,TSD8(R5,  ;WRITE DATA TO TSD8
5997 067272 016500 000002      MOV      TSSR(R5),R0 ;READ TSSR
5998 067276 005302      DEC      R2          ;REDUCE INNER COUNT
5999 067300 001372      BNE     14$         ;LOOP TILL EXPIRES
6000 067302 000766      BR      12$         ;LOOP UNTIL HALTED
6001
6002 067304      15$:  PRINTF   #T38MS2   ;TYPE CNTL C TO EXIT
      067304 012746 073221      MOV      #T38MS2,-(SP)
      067310 012746 000001      MOV      #1,-(SP)
      067314 010600      MOV      SP,R0
      067316 104417      TRAP    C$PNTF
      067320 062706 000004      ADD     #4,SP
6003 067324 004737 015774      JSR     PC,SOFINIT   ;DO SOFT INIT OF CONTROLLER
6004 067330 103405      BCS     200$        ;BR IF SOFT INIT = OK
6008 067332 010001      MOV     R0,R1       ;SAVE CONTENTS OF TSSR
6009 067334      ERRDF  ERRNO,SFIERR,SFIMSG ;DEVICE FATAL ERROR DURING INIT
      067334 104455      TRAP    C$ERDF
      067336 001755      .WORD  1005
      067340 003652      .WORD  SFIERR
      067342 012034      .WORD  SFIMSG
6010 067344      200$:
6011 067344 013737 002202 072150      MOV     UNITN,T38DSW ;SET UNIT NUMBER
6012 067352 012704 072130      MOV     #T38PK2,R4   ;SUBROUTINE NEEDS PACKET ADDRESS
6013 067356 004737 010662      JSR     PC,WRTCHR    ;ISSUE WRITE CHARACTERISTICS
6014 067362 103405      BCS     210$        ;BR, IF COMMAND ISSUED OK
6018 067364 010001      MOV     R0,R1       ;SAVE CONTENTS OF TSSR
6019 067366      ERRHRD ERRNO,WRTMSG,SFIMSG ;WRITE CHARACTERISTIC FAILED
      067366 104456      TRAP    C$ERHRD
      067370 001756      .WORD  1006
      067372 005056      .WORD  WRTMSG
      067374 012034      .WORD  SFIMSG
6020 ;*****
6021 ;
6022 ; THIS WRITE SUB-SYSTEM MEMORY COMMAND JUST HOLDS THE LEDS OFF
6023 ;
6024 ;*****
6025 067376      210$:
6026 067376 112737 000000 071441      MOVB   #0,T388S1    ;CLEAR BIT #4
6027 067404 112737 000025 071440      MOVB   #25,T388S0   ;STOP DRIVE TEST 22
6028 067412 012704 071430      MOV     #T38PACKET,R4 ;SET UP NEW WRT. SUBSYS MEM. COMMAND
6029 067416 010465 000000      MOV     R4,TSD8(R5)  ;SET THE PACKET ADDRESS
6030 067422 004737 016336      JSR     PC,CHKTSSR   ;WAIT FOR SSR TO SET
6031 067426 103405      BCS     250$        ;BR IF CARRY SET (GOOD RETURN)
6032 067430 010001      MOV     R0,R1       ;SAVE CONTENTS OF TSSR
6036 067432      ERRDF  ERRNO,T38SSR,PKTSSR ;DEVICE FATAL SSR FAILED TO SET
      067432 104455      TRAP    C$ERDF
      067434 001757      .WORD  1007
      067436 072626      .WORD  T38SSR
      067440 012046      .WORD  PKTSSR
6037 067442      250$:  CKLOOP      ;LOOP ON ERROR, IF FLAG SET
      067442 104406      TRAP    C$CLP1
6038 067444      SETPRI  #PRI07     ;RAISE THE PRIORITY
      067444 012700 000340      MOV     #PRI07,R0
      067450 104441      TRAP    C$SPRI

```

6039	067452	005037	071414		CLR	TTION2		;ASSUME INTERRUPTS ARE ENABLED
6040	067456	032737	000100	177560	BIT	#100,#TTICSR		;ARE TTI INTERRUPTS ON ?
6041	067464	001005			BNE	710\$		;BRANCH IF YES
6042	067466	005237	071414		INC	TTION2		;FLAG SET IF INTERRUPTS OFF
6043	067472	052737	000100	177560	BIS	#100,#TTICSR		;ENABLE INTERRUPTS
6044	067500	012701	000060	710\$:	MOV	#TTIVEC,R1		;START OF TTI VECTORS
6045	067504	011137	071416		MOV	(R1),TVSAV2		;SAVE THE CURRENT TTI VECTOR
6046	067510	012721	070710		MOV	#590\$(R1),		;SET NEW INTERRUPT ROUTINE
6047	067514	011137	071420		MOV	(R1),TPSAV2		;SAVE THE VECTOR PRIORITY
6048	067520	012711	000340		MOV	#PRI07,(R1)		;USE PRIORITY SEVEN
6049	067524				SETPRI	#PRI00		;LOWER INTERRUPT BR LEVEL
	067524	012700	000000				MOV	#PRI00,R0
	067530	104441					TRAP	C\$SPRI
6050	067532	000240		260\$:	NOP			;ALLOW CNTL C
6051	067534	000776			BR	260\$		;LOOP UNTIL STOPPED
6052								
6053								
6054	067536			20\$:	PRINTF	#T38MS2		;TELL'EM WHAT TO TYPE
	067536	012746	073221				MOV	#T38MS2,-(SP)
	067542	012746	000001				MOV	#1,-(SP)
	067546	010600					MOV	SP,R0
	067550	104417					TRAP	C\$PNTF
	067552	062706	000004				ADD	#4,SP
6055	067556				SETPRI	#PRI00		;LOWER PRIORITY TO ALLOW INTERRUPTS
	067556	012700	000000				MOV	#PRI00,R0
	067562	104441					TRAP	C\$SPRI
6056	067564	005037	002224		CLR	INTRECV		;CLEAR INTERRUPT RECEIVED FLAG
6057	067570	004737	015774		JSR	PC,SOFINIT		;DO SOFT INIT OF CONTROLLER
6058	067574	103405			BCS	300\$		;BR IF SOFT INIT = OK
6062	067576	010001			MOV	R0,R1		;SAVE CONTENTS OF TSSR
6063	067600				ERRDF	ERRNO,SFIERR,SFIMSG		;DEVICE FATAL ERROR DURING INIT
	067600	104455					TRAP	C\$ERDF
	067602	001760					.WORD	1008
	067604	003652					.WORD	SFIERR
	067606	012034					.WORD	SFIMSG
6064	067610			300\$:	MOV	UNITN,T38DSW		;SET UNIT NUMBER IN PACKET
6065	067610	013737	002202	072150	MOV	#BITS,T38EAI		;ENABLE ATTENTION INTERRUPTS
6066	067616	012737	000040	072146	MOV	#T38PK2,R4		;SUBROUTINE NEEDS PACKET ADDRESS
6067	067624	012704	072130		JSR	PC,WRTCHR		;ISSUE WRITE CHARACTERISTICS
6068	067630	004737	010662		BCS	310\$		;BR, IF COMMAND ISSUED OK
6069	067634	103405			MOV	R0,R1		;SAVE CONTENTS OF TSSR
6073	067636	010001			ERRMRD	ERRNO,WRTMSG,SFIMSG		;WRITE CHARACTERISTICSC FAILED
6074	067640						TRAP	C\$ERMRD
	067640	104456					.WORD	1009
	067642	001761					.WORD	WRTMSG
	067644	005056					.WORD	SFIMSG
	067646	012034					.WORD	SFIMSG
6075	067650			310\$:	MOV	#T38PK3,R4		;SET UP NEW PACKET FOR MESS BUF REL
6076	067650	012704	072160		MOV	R4,TSDB(R5)		;MESSAGE BUFFER RELEASE,ACK,CVC=1 CMD
6077	067654	010465	000000		JSR	PC,WAITF		;WAIT FOR SSR TO SET
6078	067660	004737	016250		CLR	R2		;MAKE SURE ALL IS CLEAR
6079	067664	005002			MOV	TSSR(R5),R1		;GET TSSR STATUS
6080	067666	016501	000002		BIT	#OFL,R1		;IS OFL SET
6081	067672	032701	000100		BEQ	320\$		;BR, IF OFL IS NOT SET
6082	067676	001402			BIS	#OFL,R2		;SET OFL IN EXPECTED
6083	067700	052702	000100		BIS	#SSR,R2		;SET UP EXPECTED
6084	067704	052702	000200	320\$:				



```

6085 067710 020201          CMP      R2,R1          ;IS EVERYTHING OK
6086 067712 001404          BEQ      350$          ;BR, IF ALL IS WELL
6090 067714          ERRHRD  ERRNO,T38SST,PKTSSR ;DEVICE FATAL SSR FAILED TO SET
        067714 104456          TRAP    C$ERHRD
        067716 001762          .WORD  1010
        067720 073036          .WORD  T38SST
        067722 012046          .WORD  PKTSSR
6091 067724          350$:  CKLOOP          ;LOOP ON ERROR, IF FLAG SET
        067724 104406          TRAP    C$CLP1
6092 067726          PRINTF  #T38MS1        ;TELL OPERATOR TO TOGGLE SWITCH
        067726 012746 073126          MOV     #T38MS1,-(SP)
        067732 012746 000001          MOV     #1,-(SP)
        067736 010600          MOV     SP,R0
        067740 104417          TRAP    C$PNTF
        067742 062706 000004          ADD     #4,SP
6093 067746          PRINTF  #T38MS2        ;TELL OPERATOR TO DO ^C TO EXIT
        067746 012746 073221          MOV     #T38MS2,-(SP)
        067752 012746 000001          MOV     #1,-(SP)
        067756 010600          MOV     SP,R0
        067760 104417          TRAP    C$PNTF
        067762 062706 000004          ADD     #4,SP
6094 067766          SETPRI  #PRI07        ;RAISE THE PRIORITY
        067766 012700 000340          MOV     #PRI07,R0
        067772 104441          TRAP    C$SPRI
6095 067774 005037 071414          CLR     TTION2        ;ASSUME INTERRUPTS ARE ENABLED
6096 070000 032737 000100 177560          BIT     #100,#TTICSR ;ARE TTI INTERRUPTS ON ?
6097 070006 001005          BNE     720$          ;BRANCH IF YES
6098 070010 005237 071414          INC     TTION2        ;FLAG SET IF INTERRUPTS OFF
6099 070014 052737 000100 177560          BIS     #100,#TTICSR ;ENABLE INTERRUPTS
6100 070022 012701 000060          MOV     #TTIVEC,R1    ;START OF TTI VECTORS
6101 070026 011137 071416          MOV     (R1),TVSAV2   ;SAVE THE CURRENT TTI VECTOR
6102 070032 012721 070710          MOV     #590$,(R1); ;SET NEW INTERRUPT ROUTINE
6103 070036 011137 071420          MOV     (R1),TPSAV2   ;SAVE THE VECTOR PRIORITY
6104 070042 012711 000340          MOV     #PRI07,(R1)  ;USE PRIORITY SEVEN
6105 070046          SETPRI  #PRI00        ;LOWER INTERRUPT BR LEVEL
        070046 012700 000000          MOV     #PRI00,R0
        070052 104441          TRAP    C$SPRI
6106 070054 000240          360$:  NOP              ;ALLOW CONTROL C
6107 070056 005737 002224          TST     INTRECV       ;DID AN INTERRUPT OCCUR ?
6108 070062 001001          BNE     370$          ;BRANCH IF YES
6109 070064 000773          BR      360$          ;WAIT SOME MORE FOR INTERRUPT
6110 070066          370$:  PRINTF  #T38INT        ;"INTERRUPT RECEIVED"
        070066 012746 072716          MOV     #T38INT,-(SP)
        070072 012746 000001          MOV     #1,-(SP)
        070076 010600          MOV     SP,R0
        070100 104417          TRAP    C$PNTF
        070102 062706 000004          ADD     #4,SP
6111 070106 016501 000002          MOV     TSSR(R5),R1   ;READ TSSR STATUS
6112 070112 032701 000100          BIT     #OFL,R1       ;CHECK THE OFF-LINE BIT
6113 070116 001011          BNE     380$          ;BR, IF DRIVE IS OFF-LINE
6114 070120          PRINTF  #T38ONL        ;"DRIVE IS NOW ON-LINE"
        070120 012746 072746          MOV     #T38ONL,-(SP)
        070124 012746 000001          MOV     #1,-(SP)
        070130 010600          MOV     SP,R0
        070132 104417          TRAP    C$PNTF
        070134 062706 000004          ADD     #4,SP
6115 070140 000410          BR      390$          ;ALMOST DONE

```

ML

```

6116 070142          380$: PRINTF  @T380FL          ;"DRIVE IS NOW OFF-LINE"
      070142 012746 073002          MOV          @T380FL,-(SP)
      070146 012746 000001          MOV          @1,-(SP)
      070152 010600          MOV          SP,R0
      070154 104417          TRAP         C@PNTF
      070156 062706 000004          ADD          @4,SP
6117 070162          390$: CLR          INTRECV          ;CLEAR INTERRUPT FLAG
6118 070166 000137 067610          JMP          500$          ;TRY AGAIN
6119 070172          25$: GMANIL  T38MSG,T38DAT, 1,NO      ;WAIT FOR OPERATOR TO MOUNT TAPE
      070172 104443          TRAP         C@GMAN
      070174 000404          BR          10000$
      070176 073754          .WORD      T38DAT
      070200 000120          .WORD      T@CODE
      070202 073265          .WORD      T38MSG
      070204 177777          .WORD      -1
      070206          10000$:
6120 070206          BNCOMPLETE 25$          ;RETRY IF ERROR
      070206 103371          BCC         25$
6121 070210 005737 073754          TST         T38DAT          ;DID OPERATOR SAY 'YES' ?
6122 070214 001002          BNE         27$          ;BRANCH IF YES
6123 070216 000137 066662          JMP          2$          ;RETURN TO MAIN MENU
6124 070222          27$:
6125 070222 004737 015774          JSR         PC,SOFINIT          ;DO SOFT INIT OF CONTROLLER
6126 070226 103405          BCS         400$          ;BR IF SOFT INIT = OK
6130 070230 010001          MOV         R0,R1          ;SAVE CONTENTS OF TSSR
6131 070232          ERRDF  ERRNO,SFIERR,SFIMSG      ;DEVICE FATAL ERROR DURING INIT
      070232 104455          TRAP         C@ERDF
      070234 001763          .WORD      1011
      070236 003652          .WORD      SFICRR
      070240 012034          .WORD      SFIMSG
6132 070242          400$: CKLOOP          ;LOOP IF SELECTED
      070242 104406          TRAP         C@CLP1
6133 070244 013737 002202 072150      MOV         UNITN,T380SW          ;SET UNIT NUMBER
6134 070252 012704 072130      MOV         @T38PK2,R4          ;SUBROUTINE NEEDS PACKET ADDRESS
6135 070256 004737 010662          JSR         PC,WRTCHR          ;ISSUE WRITE CHARACTERISTICS
6136 070262 103405          BCS         410$          ;BR, IF COMMAND ISSUED OK
6140 070264 010001          MOV         R0,R1          ;SAVE CONTENTS OF TSSR
6141 070266          ERRHRD  ERRNO,WRTMSG,SFIMSG      ;WRITE CHARACTERISTIC FAILED
      070266 104456          TRAP         C@ERRRD
      070270 001764          .WORD      1012
      070272 005056          .WORD      WRTMSG
      070274 012034          .WORD      SFIMSG
6142 070276          410$: CKLOOP          ;LOOP IF SELECTED
      070276 104406          TRAP         C@CLP1
6143 070300 013701 071454          MOV         T38BFR+6,R1          ;PICK UP XSTO CONTENTS
6144 070304 010102          MOV         R1,R2          ;SET UP EXPECTED
6145 070306 052702 000004          BIS         @BIT2,R2          ;SET UP THE WRITE LOCKED BIT
6146 070312 020102          CMP         R1,R2          ;ARE THEY CORRECT
6147 070314 001406          BEQ         430$          ;BR, IF ALL IS WELL (OK)
6151 070316          ERRHRD  ERRNO,T38WRL,EXPREC      ;"WRITE LOCKED BIT IS NOT SET ETC."
      070316 104456          TRAP         C@ERRRD
      070320 001765          .WORD      1013
      070322 072444          .WORD      T38WRL
      070324 015474          .WORD      EXPREC
6152 070326 005237 002222          INC         FATFLG          ;SET FATAL FLAG
6153 070332          430$: CKLOOP          ;LOOP IF SELECTED
      070332 104406          TRAP         C@CLP1

```

```

6154 070334 005737 002222          TST      FATFLG          ;WAS THE DRIVE NOT WRITE LOCKED
6155 070340 071402                BEQ      435$           ;BR, IF FLAG NOT SET
6156 070342 000137 066662          JMP      2$            ;RE-WRITE MENU
6157 070346 017737 112552 072202 435$: MOV      @FREE,T38WR     ;SET UP WRITE BUFFER ADDRESS
6158 070354 012704 072200          MOV      @T38PK4,R4    ;GET PACKET ADDRESS
6159 070360 010465 000000          MOV      R4,T38DB(R5)  ;SET THE PACKET ADDRESS
6160 070364 004737 016250          JSR      PC,WAIF       ;WAIT FOR SSR TO SET
6161 070370 016501 000002          MOV      TSSR(R5),R1   ;GET TSSR
6162 070374 012702 100206          MOV      @SC!SSR!BIT1!BIT2,R2 ;SET UP EXPECTED
6163 070400 020102                CMP      R1,R2         ;ARE THEY EQUAL (CORRECT)
6164 070402 001404                BEQ      440$           ;BR, IF CORRECT STATUS
6168 070404                ERRHRD  ERRNO,T38WRT,PKTSSR ;"TSSR INCORRECT AFTER WRITE COMMAND
                                TRAP      C$ERHRD
                                .WORD    1014
                                .WORD    T38WRT
                                .WORD    PKTSSR
                                070404 104456
                                070406 001766
                                070410 072360
                                070412 012046
6169 070414                440$:  CKLOOP          ;LOOP ON ERROR, IF FLAG SET
                                TRAP      C$CLP1
                                070414 104406
6170 070416 013701 071454          MOV      T388FR+6,R1   ;READ XST0 CONTENTS
6171 070422 010102                MOV      R1,R2         ;SET UPR EXPECTED
6172 070424 052702 004000          BIS      @BIT11,R2     ;SET THE WRITE LOCK ERROR BIT (XST0)
6173 070430 020102                CMP      R1,R2         ;WAS THE BIT SET
6174 070432 001404                BEQ      450$           ;BR, IF IT WAS (GOOD)
6178 070434                ERRHRD  ERRNO,T38WLE,EXPREC ;"WRITE LOCK ERROR BIT NOT SET"
                                TRAP      C$ERHRD
                                .WORD    1015
                                .WORD    T38WLE
                                .WORD    EXPREC
                                070434 104456
                                070436 001767
                                070440 072505
                                070442 015474
6179 070444                450$:  CKLOOP          ;LOOP IF SELECTED
                                TRAP      C$CLP1
                                070444 104406
6180 070446 000137 066662          JMP      2$            ;GO BACK TO MENU
6181
6182
6183
6184
6185 070452
6186 070452                30$:  PRINTB  @T38MS3          ;"EXE ANY OTHER MENU SELECTION TO STOP
                                MOV      @T38MS3,-(SP)
                                MOV      @1,-(SP)
                                MOV      SP,R0
                                TRAP      C$PNTB
                                ADD      @4,SP
                                070452 012746 072265
                                070456 012746 000001
                                070462 010600
                                070464 104414
                                070466 062706 000004
6187 070472 004737 073756          JSR      PC,T38REST    ;SET PACKET TO INITIAL VALUES
6188 070476 004737 015774          JSR      PC,SOFINIT    ;DO SOFT INIT OF CONTROLLER
6189 070502 103405                BCS     500$           ;BR IF SOFT INIT = OK
6193 070504 010001                MOV      R0,R1         ;SAVE CONTENTS OF TSSR
6194 070506                ERRDF  ERRNO,SFIERR,SFIMSG ;DEVICE FATAL ERROR DURING INIT
                                TRAP      C$ERDF
                                .WORD    1016
                                .WORD    SFIERR
                                .WORD    SFIMSG
                                070506 104455
                                070510 001770
                                070512 003652
                                070514 012034
6195 070516 013737 002202 072150 500$: MOV      UNITN,T38DSW   ;SET UNIT NUMBER
6196 070524 012704 072130          MOV      @T38PK2,R4   ;SUBROUTINE NEEDS PACKET ADDRESS
6197 070530 004737 010662          JSR      PC,WRTCHR     ;ISSUE WRITE CHARACTERISTICS
6198 070534 103405                BCS     510$           ;BR, IF COMMAND ISSUED OK
6202 070536 010001                MOV      R0,R1         ;SAVE CONTENTS OF TSSR
6203 070540                ERRHRD  ERRNO,WRTMSG,SFIMSG ;WRITE CHARACTERISTIC FAILED
    
```

	070540	104456							TRAP	C1EPHRD
	070542	001771							.WORD	1017
	070544	005056							.WORD	WRMSG
	070546	012034							.WORD	3FMSG
6204	070550				510:					
6205	070550	112737	000000	071441		MOVB	#0,T388S1	;CLEAR BIT #4		
6206	070556	112737	000020	071440		MOVB	#20,T388S0	;EXECUTE DRIVE TEST 22		
6207	070564	012704	071430			MOV	#T38PACKET,R4	;SET UP NEW WRT. SUBSYS MEM. COMMAND		
6208	070570	010465	000000			MOV	R4,TSDB(R5)	;SET THE PACKET ADDRESS		
6209	070574	004737	016336			JSR	PC,CHKTSSR	;WAIT FOR SSR TO SET		
6210	070600	103405				BCS	550:	;BR IF CARRY SET (GOOD RETURN)		
6211	070602	010001				MOV	RO,R1	;SAVE CONTENTS OF TSSR		
6215	070604					ERRDF	ERRNO,T38SSR,PKTSSR	;DEVICE FATAL SSR FAILED TO SET		
	070604	104455							TRAP	C1ERDF
	070606	001772							.WORD	1018
	070610	072626							.WORD	T38SSR
	070612	012046							.WORD	PKTSSR
6216	070614					550:	CKLOOP	;LOOP ON ERROR, IF FLAG SET		
	070614	104406							TRAP	C1CLP1
6217	070616						SETPRI	#PRI07	;RAISE THE PRIORITY	
	070616	012700	000340						MOV	#PRI07,RO
	070622	104441							TRAP	C1SPRI
6218	070624	005037	071414			CLR	TTION2	;ASSUME INTERRUPTS ARE ENABLED		
6219	070630	032737	000100	177560		BIT	#100,#0TTICSR	;ARE TTI INTERRUPTS ON ?		
6220	070636	001005				BNE	555:	;BRANCH IF YES		
6221	070640	005237	071414			INC	TTION2	;FLAG SET IF INTERRUPTS OFF		
6222	070644	052737	000100	177560		BIS	#100,#0TTICSR	;ENABLE INTERRUPTS		
6223	070652	012701	000060			555:	MOV	#TTIVEC,R1	;START OF TTI VECTORS	
6224	070656	011137	071416			MOV	(R1),TVSAV2	;SAVE THE CURRENT TTI VECTOR		
6225	070662	012721	070710			MOV	#590,(R1)	;SET NEW INTERRUPT ROUTINE		
6226	070666	011137	071420			MOV	(R1),TPSAV2	;SAVE THE VECTOR PRIORITY		
6227	070672	012711	000340			MOV	#PRI07,(R1)	;USE PRIORITY SEVEN		
6228	070676					SETPRI	#PRI00	;LOWER INTERRUPT BR LEVEL		
	070676	012700	000000						MOV	#PRI00,RO
	070702	104441							TRAP	C1SPRI
6229	070704	000240				560:	NOP	;LOOP AWHILE		
6230	070706	000776					BR	560:	;STAY IN "TIGHT" LOOP	
6231										
6232										
6233										
6234										
6235	070710	010046				590:	MOV	RO, -(SP)	;SAVE WORK REGISTER	
6236	070712	113700	177562			MOVB	#0TTIBFR,RO	;GET THE OPERATOR INPUT		
6237	070716	042700	000200			BIC	#200,RO	;STRIP OFF PARITY BIT		
6238	070722	122700	000015			CHPB	#15,RO	;IS IT A CARRIAGE RETURN ?		
6239	070726	001075				BNE	591:	;JUST EXIT IF NOT		
6240	070730	012766	066662	000002		MOV	#2,2(SP)	;RETURN TO MASTER MENU		
6241	070736	005066	000004			CLR	4(SP)	;FORCE PRIORITY 0		
6242	070742	013737	071416	000060		MOV	TVSAV2,#TTIVEC	;RESTORE VECTOR		
6243	070750	013737	071420	000062		MOV	TPSAV2,#TTIVEC+2	;RESTORE SUPER PRIORITY		
6244	070756	112737	000025	071440		MOVB	#25,T388S0	;STOP DRIVE TEST 22		
6245	070764	112737	000000	071441		MOVB	#0,T388S1	;CLEAR BS1		
6246	070772	012704	071430			MOV	#T38PACKET,R4	;SET UP NEW WRT. SUBSYS MEM. COMMAND		
6247	070776	010465	000000			MOV	R4,TSDB(R5)	;SET THE PACKET ADDRESS		
6248	071002	012737	176750	071422		MOV	#65000.,T38DLY	;SET UP DELAY COUNTER		
6249	071010	004737	016250			592:	JSR	PC,WAIF	;DO A WAIT FOR SSR	
6250	071014	016501	000002			MOV	TSSR(R5),R1	;CONTENTS OF TSSR REGISTER		

6251	071020	032701	000200		BIT	#SSR,R1		;	CHECK FOR TSSR SET			
6252	071024	001017			BNE	5954		;	KEEP GOING IF NOT SET			
6253	071026				DELAY	250		;	CALL DELAY ROUTINE			
	071026	012727	000250							MOV	#250,(PC).	
	071032	000000								.WORD	0	
	071034	013727	002116							MOV	L8DLY,(PC).	
	071040	000000								.WORD	0	
	071042	005367	177772							DEC	-6(PC,	
	071046	001375								BNE	.-4	
	071050	005367	177756							DEC	-22(PC)	
	071054	001367								BNE	. 20	
6254	071056	005337	071422		DEC	T38DLY		;	BUMP COUNTER DOWN			
6255	071062	001352			BNE	5924		;	BR, IF MORE TIME LEFT			
6256	071064	004737	016336	5954:	JSR	PC,CHKTSSR		;	WAIT FOR SSR TO SET			
6257	071070	103405			BCS	5804		;	BR IF CARRY SET (GOOD RETURN)			
6258	071072	010001			MOV	R0,R1		;	SAVE CONTENTS OF TSSR			
6262	071074				ERRDF	ERRNO,T38SSR,PKTSSR		;	DEVICE FATAL SSR FAILED TO SET			
	071074	104455								TRAP	C1ERRDF	
	071076	001773								.WORD	1019	
	071100	072626								.WORD	T38SSR	
	071102	012046								.WORD	PKTSSR	
6263	071104			5804:	CKLOOP			;	LOOP ON ERROR, IF FLAG SET			
	071104	104406								TRAP	C1CLP1	
6264	071106	005737	071414		TST	TTION2		;	ARE SUPER INTERRUPTS ENABLED			
6265	071112	001403			BEQ	5914		;	BR, IF YES			
6266	071114	042737	000100	177560	BIC	#100,B0TTICSR		;	RESTORE REGISTER			
6267	071122	012600			MOV	(SP)+,R0		;	RESTORE REGISTER			
6268	071124	000002			RTI			;	RETURN			
6269	071126			354:								
6270	071126	004737	073756		JSR	PC,T38REST		;	SET PACKET TO INITIAL VALUES			
6271	071132	004737	015774		JSR	PC,SOFINIT		;	DO SOFT INIT OF CONTROLLER			
6272	071136	103405			BCS	6004		;	BR IF SOFT INIT = OK			
6276	071140	010001			MOV	R0,R1		;	SAVE CONTENTS OF TSSR			
6277	071142				ERRDF	ERRNO,SFIERR,SFIMSG		;	DEVICE FATAL ERROR DURING INIT			
	071142	104455								TRAP	C1ERRDF	
	071144	001774								.WORD	1020	
	071146	003652								.WORD	SFIERR	
	071150	012034								.WORD	SFIMSG	
6278	071152			6004:	CKLOOP			;	LOOP IF SELECTED			
	071152	104406								TRAP	C1CLP1	
6279	071154	012701	071446		MOV	#T388FR,R1		;	ADDRESS OF MESSAGE BUFFER			
6280	071160	012702	125252		MOV	#125252,R2		;	ALTERNATING 1'S AND 0'S			
6281												
6282	071164	010221			MOV	R2,(R1)+		;	CLEAR OUT THE MESSAGE BUFFER			
6283	071166	022701	072122		CMP	#T38EB,R1		;	END OF BUFFER YET			
6284	071172	001401			BEQ	6054		;	BR, IF AT END OF BUFFER			
6285	071174	000773			BR	6014		;	NOT AT END KEEP GOING			
6286	071176	013737	002202	072150	MOV	UNITN,T38DSW		;	SET UNIT NUMBER			
6287	071204	012704	072130		MOV	#T38PK2,R4		;	SUBROUTINE NEEDS PACKET ADDRESS			
6288	071210	004737	010662		JSR	PC,WRTCHR		;	ISSUE WRITE CHARACTERISTICS			
6289	071214	103405			BCS	6104		;	BR, IF COMMAND ISSUED OK			
6293	071216	010001			MOV	R0,R1		;	SAVE CONTENTS OF TSSR			
6294	071220				ERRHRD	ERRNO,WRTMSG,SFIMSG		;	WRITE CHARACTERISTIC FAILED			
	071220	104456								TRAP	C1ERRHRD	
	071222	001775								.WORD	1021	
	071224	005056								.WORD	WRTMSG	
	071226	012034								.WORD	SFIMSG	

```

6295 071230          6104:  CKLOOP          ;LOOP IF SELECTED
      071230 104406          TRAP      C1CLP1
6296 071232 112737 000000 071441      MOVB   #0,T388S1      ;CLEAR BIT #4
6297 071240 112737 000024 071440      MOVB   #24,T388S0    ;READ EXTENDED DRIVE STATUS
6298 071246 012704 071430          MOV    #T38PACKET,R4 ;SET UP NEW WRT. SUBSYS MEM. COMMAND
6299 071252 010465 000000          MOV    R4,T50B(R5)   ;SET THE PACKET ADDRESS
6300 071256 012737 000144 071422      MOV    #100.,T38DLY  ;SET UP DELAY ROUTINE
6301 071264 004737 016250 6204:  JSR    PC,WAITF      ;WAIT AWHILE FOR SSR TO SET
6302 071270 016501 000002          MOV    T55R(R5),R1  ;SEE IF IT REALLY DID
6303 071274 032701 000200          BIT    #55R,R1      ;JUST CHECK THAT BIT
6304 071300 001017          BNE   6304          ;BR. IF SSR IS SET
6305 071302          DELAY  250      ;DELAY ABOUT .25 SEC
      071302 012727 000250          MOV    #250,(PC).
      071306 000000          .WORD 0
      071310 013727 002116          MOV    L#DLY,(PC).
      071314 000000          .WORD 0
      071316 005367 177772          DEC    -6(PC)
      071322 001375          BNE   .-4
      071324 005367 177756          DEC    -22(PC)
      071330 001367          BNE   .-20
6306 071332 005337 071422          DEC    T38DLY
6307 071336 001352          BNE   6204
6308 071340 004737 016336 6304:  JSR    PC,CHKTSSR   ;START DELAY COUNT DOWN
6309 071344 103405          BCS   6504          ;BR. IF COUNTER IS NOT AT DONE
6310 071346 010001          MOV    R0,R1        ;WAIT FOR SSR TO SET
6314 071350          ERRDF  ERRNO,T38SSR,PKTSSR ;BR IF CARRY SET (GOOD RETURN)
      071350 104455          TRAP  C1ERDF        ;SAVE CONTENTS OF T55R
      071352 001776          .WORD 1022          ;DEVICE FATAL SSR FAILED TO SET
      071354 072626          .WORD T38SSR
      071356 012046          .WORD PKTSSR
6315 071360          6504:  CKLOOP          ;LOOP ON ERROR. IF FLAG SET
      071360 104406          TRAP  C1CLP1
6316 071362 012700 071466          MOV    #T38BFR+20,R0 ;MESSAGE BUFFER ADDRESS
6317 071366 005001          CLR   R1            ;NO HIGH ORDER ADDRESS BITS
6318 071370 005037 003134          CLR   KTENABLE     ;NO KT11 STUFF EITHER
6319 071374 004737 074014          JSR   PC,T38MBP     ;GO PRINT MESSAGE BUFFER CONTENTS
6320 071400 000137 066662          JMP   24            ;GO BACK TO MENU
6321
6322
6323 071404 000137 000200 634:  JMP   200           ;REALLY RETURN TO THE SUPERVISOR
6324 071410          644:  EXIT   TST         ;LEAVE TEST
      071410 104432          TRAP  C1EXIT
      071412 003054          .WORD L10075
6325
6326          ;*
6327          ;LOCAL TEXT MESSAGES FOR TEST
6328          ;-
6329
6330          ;LOCAL STORAGE FOR THIS TEST
6331          ;
6332          ;*
6333          ;LOCAL STORAGE FOR THIS TEST
6334          ;-
6335
6336 071414 000000          TTION2: .WORD 0      ;WORD SET IF SUPERVISOR TTI INTER OFF
6337 071416 000000          TVSAV2: .WORD 0     ;SAVE TTI VECTOR
6338 071420 000000          TPSAV2: .WORD 0     ;SAVE TTI PRIORITY

```

6339					
6340	071422	000000	T38DLY: .WORD	0	;DELAY COUNTER FOR TEST1
6342		071430		.=<..10>&177770	
6344	071430		T38PACKET:		;COMMAND PACKET FOR TEST
6345	071430	140006	.WORD	140006	;WRITE SUBSYSTEM MEM. CMD, ACK,CVC=1
6346	071432	071440	.WORD	T38TAD	;ADDRESS OF CHARACTERISTICS BLOCK
6347	071434	000000	.WORD	0	
6348	071436	000012	.WORD	10.	;STARTING VALUE OF BLOCK SIZE
6349	071440		T38TAD:		;CHARACTERISTICS DATA BLOCK
6350	071440	000	T38S0: .BYTE	0	;BSELO BYTE
6351	071441	000	T38S1: .BYTE	0	;BSEL1 BYTE
6352	071442	000000	T38S2: .WORD	0	;BSEL1 WORD
6353	071444	000000	.WORD	0	;DATA
6354	071446		T38BFR: .BLKW	150.	;MESSAGE BUFFER
6355	072122	000000	T38EB: .WORD		;END OF BUFFER ADDRESS
6356					
6357					
6359		072130		.=<..10>&177770	
6361	072130		T38PK2:		;COMMAND PACKET FOR TEST
6362	072130	140004	.WORD	140004	;WRITE CHARA. MEM. CMD., ACK,CVC=1
6363	072132	072140	.WORD	T38DTA	;ADDRESS OF SELECT DATA BLOCK
6364	072134	000000	.WORD	0	
6365	072136	000012	.WORD	10.	;STARTING VALUE OF BLOCK SIZE
6366					
6367					
6368	072140		T38DTA:		;SELECT DATA BLOCK
6369	072140	071446	.WORD	T38BFR	;ADDRESS OF MESSAGE BUFFER
6370	072142	000000	.WORD	0	
6371	072144	000400	.WORD	256.	;LENGTH OF MESSAGE BUFFER
6372	072146	000000	T38EAI: .WORD	0	;EAI BIT WORD
6373	072150	000000	T38DSW: .WORD	0	;DRIVE SELECT WORD ETC
6375		072160		.=<..10>&177770	
6377	072160	140212	T38PK3: .WORD	140212	;MESSAGE BUFFER RELEASE COMMAND
6378	072162	000000	.WORD	0	;NOT USED
6379	072164	000000	.WORD	0	;NOT USED
6380	072166	000000	.WORD	0	;NOT USED
6381	072170	000000	.WORD	0	;NOT USED
6382					
6383			;WRITE TAPE PACKET		
6384					
6386		072200		.=<..10>&177770	
6388	072200	140005	T38PK4: .WORD	140005	;WRITE, ACK, CVC=1 COMMAND
6389	072202	000000	T38WR: .WORD	0	;ADDRESS OF WRITE BUFFER
6390	072204	000000	.WORD	0	;MORE ADDRESS OF WRITE BUFFER
6391	072206	000400	T38SIZ: .WORD	256.	;SIZE OF RECORD
6392					
6393					
6394					
6395					
6396					
6397			;LOCAL TEXT MESSAGES FOR TEST		
6398					
6399					
6400					
6401					
6402					
6403					

```

6404 072210      123      164      141 T38NE: .ASCIZ 'Stand-alone Manual Intervention Not Executed'
6405 072265      045      116      045 T38MS3: .ASCIZ 'MNSA Type <RETURN> To Stop Servo Exerciser, Return To Menu'
6406 072360      124      123      123 T38WRT: .ASCIZ 'TSSR Not Correct After WRITE, With WRITE PROTECT On'
6407 072444      127      122      111 T38WRL: .ASCIZ 'WRITE LOCKED Bit Not Set In XSTO'
6408 072505      127      122      111 T38MLE: .ASCIZ 'WRITE LOCK ERROR Bit Not Set In XSTO'
6409 072552      127      122      111 T38NBA: .ASCIZ 'WRITE SUBSYSTEM MEMORY Command Not Accepted'
6410 072626      103      157      156 T38SSR: .ASCIZ 'Contents of TSSR Incorrect After WRITE SUBSYSTEM MEMORY'
6411 072716      045      116      045 T38INT: .ASCIZ 'MNSA Interrupt Received'
6412 072746      045      116      045 T38ONL: .ASCIZ 'MNSA Drive Is Now ON-LINE'
6413 073002      045      116      045 T38OFL: .ASCIZ 'MNSA Drive Is Now OFF-LINE'
6414 073036      103      157      156 T38SST: .ASCIZ 'Contents Of TSSR Incorrect After MESSAGE BUFFER RELEASE'
6415 073126      045      116      045 T38MS1: .ASCIZ 'MNSAToggle ON-LINE Switch to Generate ATTENTION Interrupts'
6416 073221      045      116      045 T38MS2: .ASCIZ 'MNSA Type RETURN To Return To Menu'
6417 073265      111      163      040 T38MSG: .ASCIZ 'Is Write-Protected Tape Mounted'
6418 073325      115      141      156 T38ID: .ASCIZ 'Manual Intervention'
6419              .EVEN
6420 073352      073376      073450      073476 MIMENU: .WORD 1#,2#,3#,4#,5#,6#
6421 073366      073645      073710      073753 .WORD 8#,9#,10#,0
6422
6423 073376      012      123      105 1#: .ASCIZ '<12>' SELECT OPERATION FROM FOLLOWING OPTIONS:'
6424 073450      012      011      060 2#: .ASCIZ '<12>' 0 Display This Menu'
6425 073476      011      061      011 3#: .ASCIZ ' 1 Turn On All M7196 LED's'
6426 073530      011      062      011 4#: .ASCIZ ' 2 Turn Off All M7196 LED's'
6427 073563      011      063      011 5#: .ASCIZ ' 3 Offline/Online Attention'
6428 073617      011      064      011 6#: .ASCIZ ' 4 Write Protect Test'
6429 073645      011      065      011 8#: .ASCIZ ' 5 Print Extended Transport Status'
6430 073710      011      066      011 9#: .ASCIZ ' 6 Return to Diagnostic Supervisor'
6431 073753      000              10#: .ASCIZ ''
6432              .EVEN
6433
6434 ;*
6435 ;LOCAL STORAGE FOR THIS TEST
6436 ;-
6437
6438 073754      000000      T38DAT: .WORD 0 ;LOGICAL RESPONSE TO QUESTION
6439 073756      T38REST:
6440 073756      SAVREG
6441 073762      012701      071430      MOV #T38PACKET,R1 ;SAVE THE REGISTERS
6442 073766      012721      140206      MOV #140206,(R1) ;START OF THE PACKET
6443 073772      012721      071440      MOV #T38TAD,(R1) ;WRITE SUBSYSTEM MEM. WITH ACK.CVC-1
6444 073776      005021      CLR (R1) ;ADDRESS OF DATA BLOCK
6445 074000      012721      000006      MOV #6,(R1) ;EXTENDED ADDRESS
6446 074004      005021      CLR (R1) ;SIZE OF DATA BLOCK IN BYTES
6447 074006      005021      CLR (R1) ;CLEAR BSELO AND BSEL1
6448 074010      005011      CLR (R1) ;CLEAR SEL2
6449 074012      000207      CLR (R1) ;CLEAR DATA AREA
6450              RTS PC ;RETURN
6451
6452 ;*
6453 ;
6454 ;THIS ROUTINE PRINTS THE CONTENTS OF
6455 ;THE 256 BYTE MESSAGE BUFFER RETURNED BY THE
6456 ;TSV-05.
6457 ;
6458 ;INPUT:
6459 ;
6460 ; R0 LOW ORDER ADDRESS OF MESSAGE BUFFER
    
```



```

6461      ;      R1      HIGH ORDER ADDRESS OF MESSAGE BUFFER
6462      ;      NOTE: R1 IS IGNORED IF KTENABLE FLAG IS CLEAR
6463      ;
6464      ;
6465      ;
6466      ;
6467 074014 T38MBP:
6468 074014      SAVREG      ;SAVE THE REGISTERS
6469 074020 010005      MOV      R0,R5      ;SAVE LOW ORDER ADDRESS
6470 074022 005737 003134      TST      KTENABLE      ;ADDRESS ABOVE 28K?
6471 074026 001001      BNE      9104      ;BR IF YES
6472 074030 005000      CLR      R1      ;SET HIGH ORDER ADDRESS TO 0
6473 074032 010100      9104:  MOV      R1,R3      ;SAVE HIGH ORDER ADDRESS
6474 074034 005100      ROL      R0      ;SHIFT BIT15 TO C BIT
6475 074036 006101      ROL      R1      ;SHIFT TO HIGH ORDER FOR PRINTOUT
6476 074040      PRINTX     #T38AS0,R1,R5 ;PRINT MESSAGE BUFFER ADDRESS
        MOV      R5,-(SP)
        MOV      R1,-(SP)
        MOV      #T38AS0,-(SP)
        MOV      #3,-(SP)
        MOV      SP,R0
        TRAP     C:PNTX
        ADD      #10,SP
        074040 010546
        074042 010146
        074044 012746 074316
        074050 012746 000003
        074054 010600
        074056 104415
        074060 062706 000010
6477 074064      PRINTX     #T38AS1      ;PRINT HEADER FOR CONTENTS
        MOV      #T38AS1,-(SP)
        MOV      #1,-(SP)
        MOV      SP,R0
        TRAP     C:PNTX
        ADD      #4,SP
        074064 012746 074363
        074070 012746 000001
        074074 010600
        074076 104415
        074100 062706 000004
6478 074104 010501      MOV      R5,R1      ;COPY LOW ORDER ADDRESS
6479 074106 010300      MOV      R3,R0      ;COPY HIGH ORDER ADDRESS
6480 074110 001403      BEQ      9134      ;BR IF NOT ABOVE 28K
6481 074112 004737 017316      JSR      PC,SETMAP      ;SETUP PAR ADDRESS IN R0
6482 074116 010005      MOV      R0,R5      ;GET PAR FORMAT ADDRESS ABOVE 28K
6483 074120 010537 074464      9134:  MOV      R5,T38CNT      ;HOLD ADDRESS
6484 074124 011504      9114:  MOV      (R5),R4      ;GET BUFFER ENTRY
6485 074126 022704 125252      CMP      #125252,R4      ;CHECK FOR NO LOAD CONDITION
6486 074132 001417      BEQ      9124      ;BR, IF BUFFER WASN'T LOADED
6487 074134 010403      MOV      R4,R3      ;MAKE COPY
6488 074136 042704 170377      BIC      #170377,R4      ;ONLY BITS 11,10,9 AND 8 ARE SAVED
6489 074142 000241      CLC
        ;CLEAR CARRY
6490 074144 006004      ROR      R4      ;11 TO 10 BIT POSITION
6491 074146 006004      ROR      R4      ;10 TO 9 BIT POSITION
6492 074150 006004      ROR      R4      ;9 TO 8 BIT POSITION
6493 074152 006004      ROR      R4      ;8 TO 7 BIT POSITION
6494 074154 042703 177760      BIC      #177760,R3      ;ONLY BITS 3,2,1 AND 0 ARE SAVED
6495 074160 060403      ADD      R4,R3      ;"OR'EM TOGETHER
6496 074162 010325      MOV      R3,(R5)      ;PUT BACK IN BUFFER
6497 074164 020527 072122      CMP      R5,#T38EB      ;END OF BUFFER YET
6498 074170 001355      BNE      9114      ;BR, IF NOT AT END YET
6499 074172 013705 074464      9124:  MOV      T38CNT,R5      ;PUT ADDRESS BACK
6500 074176 012704 000001      MOV      #1,R4      ;START BYTE NUMBER AT ONE
6501 074202      9154:  PRINTX     #T38ASN,R4,(R5)      ;PRT MEM BUFFER W/NEWLINE
        MOV      (R5),-(SP)
        MOV      R4,-(SP)
        MOV      #T38ASN,-(SP)
        MOV      #3,-(SP)
        074202 012546
        074204 010446
        074206 012746 074440
        074212 012746 000003

```

```

074216 010600
074220 104415
074222 062706 000010
6502 074226 005037 074464 CLR T38CNT ;CLEAR COUNTER
6503 074232 000412 BR 921$ ;SKIP OTHER PRINT
6504 074234 920$: PRINTX @T38ASC,R4,(R5). ;PRINT THE CONTENTS OF MEMORY BUFFER
074234 012546 MOV (R5),-(SP)
074236 010446 MCV R4,-(SP)
074240 012746 074421 MOV @T38ASC,-(SP)
074244 012746 000003 MOV @3,-(SP)
074250 010600 MOV SP,R0
074252 104415 TRAP C$PNTX
074254 062706 000010 ADD #10,SP
6505 074260 005237 074464 921$: INC T38CNT ;BUMP COUNTER
6506 074264 005204 INC R4 ;NUMBER OF THE NEXT
6507 074266 020427 000200 CMP R4,#128. ;DONE ALL YET ?
6508 074272 003010 BGT 50$ ;BRANCH IF ALL DONE
6509 074274 023727 074464 000004 CMP T38CNT,#4 ;DONE FOUR YET
6510 074302 001401 BEQ 925$ ;BR, IF THREE DONE
6511 074304 000753 BR 920$ ;KEEP GOING
6512 074306 005037 074464 925$: CLR T38CNT ;CLEAR COUNTER
6513 074312 000733 BR 915$ ;PRINT WITH NEW LINE
6514 074314 000207 50$: RTS PC ;RETURN
6515
6516 074316 045 116 045 T38AS0: .ASCIZ 'MMSA Message Buffer Address = #01#05'
6517 074363 045 116 045 T38AS1: .ASCIZ 'MMSA Message Buffer Contents:'
6518 074421 045 101 040 T38ASC: .ASCIZ '#A #D4#A: #03'
6519 074440 045 116 045 T38ASN: .ASCIZ 'MMSA Bytes#D4#A: #03'
6520 .EVEN
6521 074464 000000 T38CNT: .WORD ;COUNTER FOR PRINT
6522 074466 .ENDTST
074466
074466 104401 L10075: TRAP C$ETST
6523 .SBTTL TEST 11: CONFIGURATION TYPEOUT
6524
6525 ;THIS IS A STANDALONE ROUTINE THAT PRINTS OUT ON THE CONSOLE TERMINAL
6526 ;THE CONFIGURATION OF THE M7196 MODULE AND TSV05 SUBSYSTEM. SPECIFICALLY,
6527 ;THE FOLLOWING INFORMATION IS PRESENTED:
6528 ;
6529 ;
6530 ; 1.0 STATE OF THE EXTENDED FEATURES SWITCH ON THE M7196: ON (EXTENDED
6531 ; FEATURES ENABLED) OR OFF (EXTENDED FEATURES DISABLED).
6532 ;
6533 ; 2.0 STATE OF THE BUFFERING ENABLE SWITCH ON THE M7196: ON
6534 ; (BUFFERING ENABLED) OR OFF (BUFFERING DISABLED).
6535 ;
6536 ; 3.0 MICROCODE REVISION LEVEL OF THE M7196.
6537 ;
6538 ; 4.0 NUMBER OF TAPE TRANSPORTS CONNECTED TO THE CONTROLLER.
6539 ;
6540 ; 5.0 UNIT SELECT CODE AND STATE (ONLINE/OFFLINE, WRITE ENABLED/PROTECTED)
6541 ; OF EACH CONNECTED TRANSPORT. IN ADDITION, THE PROGRAM WILL INDICATE,
6542 ; FOR EACH ON-LINE TRANSPORT, WHETHER OR NOT IT IS EQUIPPED WITH THE
6543 ; EXTENDED TAPE STATUS READOUT FEATURE.
6544 ;
6545 ;
6546 ;THE OPERATOR IS EXPECTED TO READ THE PRINTOUT AND VERIFY THAT IT MATCHES

```

```

6547 ;THE ACTUAL CONFIGURATION AT HAND. IF, FOR EXAMPLE, THE PROGRAM INDICATES
6548 ;THAT IT "SEES" TWO TRANSPORTS CONNECTED WHEN IN FACT ONLY ONE IS PRESENT,
6549 ;THE OPERATOR MUST INTERPRET THIS AS AN ERROR AND ATTEMPT TO FIND THE
6550 ;CAUSE (BAD CABLE, FAULTY UNIT-SELECT DECODING IN THE TRANSPORT, ETC.).
6551 ;[SINCE THE CONTROLLER CAN ONLY ACCESS UNIT 0 IF IT IS IN "STANDARD"
6552 ;MODE, THE PROGRAM WILL FORCE THE MODULE INTO EXTENDED MODE VIA THE
6553 ;WRITE SUBSYSTEM MEMORY COMMAND IN ORDER TO SCAN FOR CONNECTED TRANSPORTS.]
6554 ;
6555 ;
6556 ;THIS ROUTINE, WHEN ITS ACTIONS ARE COMPLETED, WILL EXIT BACK TO THE
6557 ;DIAGNOSTIC SUPERVISOR SO THAT IF ADDITIONAL UNITS (CONTROLLERS) ARE
6558 ;SELECTED (E.G., FROM THE INITIAL STARTUP DIALOG), THE ROUTINE WILL BE
6559 ;REENTERED SO THAT THEIR CONFIGURATIONS CAN BE PRINTED.
6560 ;
6561 074470 BGNTST
6562 074470
6563 074470
6564 074470 104421
6565 074472 001403
6566 074474 012700 076463
6567 074500 000402
6568 074502 012700 077612
6569 074506 004737 016510
6570 074512 004737 020500
6571 074516 103402
6572 074520 000137 075700
6573 074524 004737 015774
6574 074530 103405
6575 074532 010001
6576 074534 104455
6577 074536 002115
6578 074540 003652
6579 074542 012034
6580 074544 104406
6581 074546 013737 002202 076430
6582 074554 012704 076410
6583 074560 004737 010662
6584 074564 103405
6585 074566 010001
6586 074570 104456
6587 074572 002116
6588 074574 005056
6589 074576 012034
6590 074600 104406
6591 074602 013701 075740
6592 074606 012746 077331
6593 074612 012746 000001
6594 074616 010600
6595 074620 104415
6596 074622 062706 000004
6597 074626 032701 000200

```

```

;GET OPERATOR FLAGS
;BR, IF OK TO RUN
;'TEST NOT EXECUTED"
;JUMP OUT OF TEST IF NOT
;TEST ID MESSAGE
;DO THE COMMON SETUP
;IS MANUAL INTERVENTION ALLOWED?
;BR, IF MANUAL INTERVENTION ALLOWED
;JUMP TO OUT IF NOT
;DO SOFT INIT OF CONTROLLER
;BR IF SOFT INIT = OK
;SAVE CONTENTS OF TSSR
;DEVICE FATAL ERROR DURING INIT
;LOOP IF SELECTED
;SET UNIT NUMBER
;SUBROUTINE NEEDS PACKET ADDRESS
;ISSUE WRITE CHARACTERISTICS
;BR, IF COMMAND ISSUED OK
;SAVE CONTENTS OF TSSR
;WRITE CHARACTERISTIC FAILED
;LOOP IF SELECTED
;GET XST2 STATUS FROM MESSAGE BUFFER
;"STATE OF EXTENDED FEATURES SW ="
;CHECK STATE OF E.F.S.

```

```

6597 074632 001011          BNE      100$          ;BR, IF EXT. FEA. SW. IS ON
6598 074634          PRINTX  #T390FF        ;" OFF"
        074634 012746 077455          MOV      #T390FF,-(SP)
        074640 012746 000001          MOV      #1,-(SP)
        074644 010600          MOV      SP,R0
        074646 104415          TRAP    C#PNTX
        074650 062706 000004          ADD     #4,SP
6599 074654 000410          BR       110$          ;SKIP OTHER PRINT STATEMENT
6600 074656          PRINTX  #T390N        ;" ON "
        074656 012746 077464          MOV      #T390N,-(SP)
        074662 012746 000001          MOV      #1,-(SP)
        074666 010600          MOV      SP,R0
        074670 104415          TRAP    C#PNTX
        074672 062706 000004          ADD     #4,SP
6601 074676          PRINTX  #T39SBS       ;"STATE OF BUFFERING SWITCH ="
        074676 012746 077403          MOV      #T39SBS,-(SP)
        074702 012746 000001          MOV      #1,-(SP)
        074706 010600          MOV      SP,R0
        074710 104415          TRAP    C#PNTX
        074712 062706 000004          ADD     #4,SP
6602 074716 032701 000100          BIT     #BIT6,R1      ;CHECK STATE OF BUFFERING SW
6603 074722 001011          BNE     120$          ;BR, IF BUFFERING IS ON
6604 074724          PRINTX  #T390FF        ;" OFF"
        074724 012746 077455          MOV      #T390FF,-(SP)
        074730 012746 000001          MOV      #1,-(SP)
        074734 010600          MOV      SP,R0
        074736 104415          TRAP    C#PNTX
        074740 062706 000004          ADD     #4,SP
6605 074744 000410          BR       130$          ;SKIP OTHER PRINT STATEMENT
6606 074746          PRINTX  #T390N        ;" ON "
        074746 012746 077464          MOV      #T390N,-(SP)
        074752 012746 000001          MOV      #1,-(SP)
        074756 010600          MOV      SP,R0
        074760 104415          TRAP    C#PNTX
        074762 062706 000004          ADD     #4,SP
6607 074766 042701 177700          BIC     #177700,R1    ;ONLY LEAVE MICROCODE REV LEVEL
6608 074772 010137 077550          MOV     R1,T39RL      ;LOAD UP REV LEVEL
6609 074776          PRINTX  #T39MCL,T39RL ;"MICROCODE REVISION LEVEL =000XXX"
        074776 013746 077550          MOV     T39RL,-(SP)
        075002 012746 077473          MOV     #T39MCL,-(SP)
        075006 012746 000002          MOV     #2,-(SP)
        075012 010600          MOV     SP,R0
        075014 104415          TRAP    C#PNTX
        075016 062706 000006          ADD     #6,SP
6610 075022 004737 015774          JSR     PC,SOFINIT    ;DO SOFT INIT OF CONTROLLER
6611 075026 103405          BCS     140$          ;BR IF SOFT INIT = OK
6615 075030 010001          MOV     R0,R1         ;SAVE CONTENTS OF TSSR
6616 075032          ERRDF  ERRNO,SFIERR,SFIMSG ;DEVICE FATAL ERROR DURING INIT
        075032 104455          TRAP    C#ERRDF
        075034 002117          .WORD  1103
        075036 003652          .WORD  SFIERR
        075040 012034          .WORD  SFIMSG
6617 075042          CKLOOP          ;LOOP IF SELECTED
        075042 104406          TRAP    C#CLP1
6618 075044 013737 002202 076430          MOV     UNITN,T39DSW ;SET UNIT NUMBER
6619 075052 012704 076410          MOV     #T39PK2,R4   ;SUBROUTINE NEEDS PACKET ADDRESS
6620 075056 004737 010662          JSR     PC,WATCHR    ;ISSUE WRITE CHARACTERISTICS

```

```

6621 075062 103405          BCS      150$          ;BR, IF COMMAND ISSUED OK
6625 075064 010001          MOV      RO,R1         ;SAVE CONTENTS OF TSSR
6626 075066          ERRHRD   ERRNO,WRTMSG,SFIMSG ;WRITE CHARACTERISTISC FAILED
                                TRAP      C$ERHRD
                                .WORD     1104
                                .WORD     WRTMSG
                                .WORD     SFIMSG
6627 075076          150$:   CKLOOP          ;LOOP IF SELECTED
                                TRAP      C$CLP1
6628 075100 005737 002226          TST      EXTFEA        ;CHECK FOR EXTENDED FEATURES SW SWITCH
6629 075104 001036          BNE      174$          ;BR IF SWITCH IS ON
6630 075106 112737 000200 075721  MOVB     #200,T39BS1   ;WRITE MISCELLANEOUS CONT/READ STATUS
6631 075114 112737 000010 075720  MOVB     #10,T39BS0   ;FUNCTION SELECTION BIT (TURN ON EXTFEA HW SWITCH)
6632 075122 012704 075710          MOV      #T39PACKET,R4 ;WRITE SUBSYS MEM PACKET
6633 075126 010465 000000          MOV      R4,TSDB(R5)  ;ISSUE COMMAND
6634 075132 004737 016336          JSR      PC,CHKTSSR   ;WAIT FOR SSR
6635 075136 103405          BCS      160$          ;BR, IF NO ERROR
6636 075140 010001          MOV      RO,R1         ;ERROR, SAVE TSSR
6640 075142          ERRHRD   ERRNO,T39NBA,PKTSSR ;TSSR NOT CORRECT AFTER WRT. MISCELLANEOUS
                                TRAP      C$ERHRD
                                .WORD     1105
                                .WORD     T39NBA
                                .WORD     PKTSSR
6641 075152          160$:   CKLOOP          ;LOOP IF SELECTED
                                TRAP      C$CLP1
6642 075154 012704 076410          MOV      #T39PK2,R4   ;SUBROUTINE NEEDS PACKET ADDRESS
6643          ;*****
6644          ;
6645          ;WRITE CHARACTERISTICS COMMAND (CALL TO WRTCHR)
6646          ;
6647          ;*****
6648          ;
6649 075160 004737 010662          JSR      PC,WRTCHR    ;ISSUE WRITE CHARACTERISTICS
6650 075164 103405          BCS      170$          ;BR, IF COMMAND ISSUED OK
6654 075166 010001          MOV      RO,R1         ;SAVE CONTENTS OF TSSR
6655 075170          ERRHRD   ERRNO,WRTMSG,SFIMSG ;WRITE CHARACTERISTISC FAILED
                                TRAP      C$ERHRD
                                .WORD     1106
                                .WORD     WRTMSG
                                .WORD     SFIMSG
6656 075200          170$:   CKLOOP          ;SCOPE LOOP
                                TRAP      C$CLP1
6657 075202 005037 002202          CLR      UNITN        ;SET TO DRIVE 0
6658 075206 013737 002202 076430 174$:   MOV      UNITN,T39DSW  ;SET UNIT NUMBER
6659 075214 012704 076410 175$:   MOV      #T39PK2,R4   ;SUBROUTINE NEEDS PACKET ADDRESS
6660 075220 004737 010662          JSR      PC,WRTCHR    ;ISSUE WRITE CHARACTERISTICS
6661 075224 103405          BCS      180$          ;BR, IF COMMAND ISSUED OK
6665 075226 010001          MOV      RO,R1         ;SAVE CONTENTS OF TSSR
6666 075230          ERRHRD   ERRNO,WRTMSG,SFIMSG ;WRITE CHARACTERISTISC FAILED
                                TRAP      C$ERHRD
                                .WORD     1107
                                .WORD     WRTMSG
                                .WORD     SFIMSG
6667 075240          180$:   CKLOOP          ;LOOP IF SELECTED
                                TRAP      C$CLP1
6668          ;
6669 075242 016501 000002          190$:   MOV      TSSR(R5),R1 ;GET TSSR STATUS

```

```

6670 075246 032701 000100      BIT      #OFL,R1      ;CHECK FOR OFF-LINE
6671 075252 001414      BEQ      200$        ;BR, IF DRIVE IS ON-LINE
6672 075254      PRINTX   #T390F2,UNITN ;"DRIVE NUMBER XX IS OFF-LINE"
                                MOV      UNITN,-(SP)
                                MOV      #T390F2,-(SP)
                                MOV      #2,-(SP)
                                MOV      SP,R0
                                TRAP     C$PNTX
                                ADD      #6,SP
6673 075300 000137 075634      JMP      250$        ;DO NOT TRY TO GET ANYMORE INFO.
6674 075304      PRINTX   #T390N2,UNITN ;"DRIVE NUMBER XX IS ON-LINE"
                                MOV      UNITN,-(SP)
                                MOV      #T390N2,-(SP)
                                MOV      #2,-(SP)
                                MOV      SP,R0
                                TRAP     C$PNTX
                                ADD      #6,SP
                                MOV      T398FR+6,R1
                                BIT      #BIT2,R1
                                BNE      210$
6675 075330 013701 075734      MOV      T398FR+6,R1 ;READ EXTENDED STATUS (XSTO)
6676 075334 032701 000004      BIT      #BIT2,R1   ;IS DRIVE WRITE PROTECTED
6677 075340 001013      BNE      210$        ;BR, IF WRITE PROTECTED
6678 075342      PRINTX   #T39WPN,UNITN ;"DRIVE NUMBER IS NOT WRT PRO"
                                MOV      UNITN,-(SP)
                                MOV      #T39WPN,-(SP)
                                MOV      #2,-(SP)
                                MOV      SP,R0
                                TRAP     C$PNTX
                                ADD      #6,SP
                                BR      220$
6679 075366 000412      BR      220$        ;SKIP OVER
6680 075370      PRINTX   #T39WRT,UNITN ;"DRIVE NUMBER XX IS WRT PRO"
                                MOV      UNITN,-(SP)
                                MOV      #T39WRT,-(SP)
                                MOV      #2,-(SP)
                                MOV      SP,R0
                                TRAP     C$PNTX
                                ADD      #6,SP
6681 075414 012737 125252 076026 220$: MOV      #125252,T398FR+100 ;SET 1 LOC TO KNOWN VALUE
6682 075422 112737 000000 075721      MOV@    #0,T398S1    ;EXTENDED TAPE STATUS
6683 075430 112737 000024 075720      MOV@    #24,T398S0   ;EXTENDED TAPE STATUS
6684 075436 012704 075710      MOV     #T39PACKET,R4 ;WRITE SUBSYS MEM PACKET
6685 075442 010465 000000      MOV     R4,TSD8(R5)  ;ISSUE COMMAND
6686 075446 012737 000144 075704      MOV     #100.,T39DLY ;SET UP DELAY ROUTINE
6687 075454 004737 016250      JSR     PC,WAITF     ;WAIT AWHILE FOR SSR TO SET
6688 075460 016501 000002      MOV     TSSR(R5),R1 ;SEE IF IT REALLY DID
6689 075464 032701 000200      BIT     #SSR,R1     ;JUST CHECK THAT BIT
6690 075470 001017      BNE     225$        ;BR, IF SSR IS SET
6691 075472      DELAY   250        ;DELAY ABOUT .25 SEC
                                MOV     #250,(PC)+
                                .WORD   0
                                MOV     L$DLY,(PC)+
                                .WORD   0
                                DEC     -6(PC)
                                BNE     -.4
                                DEC     -22(PC)
                                BNE     -.20
6692 075522 005337 075704      DEC     T39DLY      ;START DELAY COUNT DOWN
6693 075526 001352      BNE     222$        ;BR, IF COUNTER IS NOT AT DONE
6694 075530 004737 016336      JSR     PC,CHKTSSR ;WAIT FOR SSR

```

```

6695 075534 103405          BCS      2304          ;BR, IF NO ERROR
6696 075536 000001          MOV      RO,R1        ;ERROR, SAVE TSSR
6700 075540          ERRMRD   ERRNO,T39NBA,PKTSSR ;TSSR NOT CORRECT AFTER WRT. MISCELLANEOUS
                                TRAP      C#ERRMRD
                                .WORD    1108
                                .WORD    T39NBA
                                .WORD    PKTSSR
6701 075550          2304:   CKLOOP          ;LOOP IF SELECTED
                                TRAP      C#CLP1
6702 075552 023727 076026 125252  CMP      T39BFR,100,#125252 ;DID LOC GET OVER WRITTEN
6703 075560 001013          BNE     2404          ;BR, IF IT DIDN'T GET ETC.
6704 075562          PRINTX  #T39ETN,UNITN ;"DRIVE DOESN'T HAVE EXT TAPE STATUS
                                MOV      UNITN,-(SP)
                                MOV      #T39ETN,-(SP)
                                MOV      #2,-(SP)
                                MOV      SP,R0
                                TRAP     C#PNTX
                                ADD     #6,SP
6705 075606 000412          BR      2504          ;SKIP OVER
6706 075610          2404:   PRINTX  #T39ETS,UNITN ;"DRIVE HAS EXT TAPE STATUS"
                                MOV      UNITN,-(SP)
                                MOV      #T39ETS,-(SP)
                                MOV      #2,-(SP)
                                MOV      SP,R0
                                TRAP     C#PNTX
                                ADD     #6,SP
6707 075634 005237 002202          2504:   INC      UNITN          ;BUMP DRIVE NUMBER
6708 075640 023727 002202 000003  CMP     UNITN,#3      ;AT END OF DRIVES YET
6709 075646 001402          BEQ     634          ;BR, IF NO MORE DRIVES
6710 075650 000137 075206          JMP     1754          ;DO NEXT DRIVE
6711 075654          634:   PRINTX  #T39NFL          ;NEW LINE
                                MOV      #T39NFL,-(SP)
                                MOV      #1,-(SP)
                                MOV      SP,R0
                                TRAP     C#PNTX
                                ADD     #4,SP
6712 075674 000137 000200          JMP     200          ;RETURN TO SUPERVISOR
6713 075700          644:   EXIT    TST          ;EXIT THIS SECTION
                                TRAP     C#EXIT
                                .WORD    L10076-.
6714          ;*
6715          ;LOCAL TEXT MESSAGES FOR TEST
6716          ;-
6717          ;LOCAL STORAGE FOR THIS TEST
6718          ;-
6719          ;
6720          ;
6721 075704 000000          T39DLY: .WORD    0          ;DELAY COUNTER FOR TEST
6723          .<.10>E177770
6725 075710          T39PACKET: ;COMMAND PACKET FOR TEST
6726 075710 140006          .WORD    140006          ;WRITE SUBSYSTEM MEM. CMD, ACK,CVC=1
6727 075712 075720          .WORD    T39TAD          ;ADDRESS OF CHARACTERISTICS BLOCK
6728 075714 000000          .WORD    0
6729 075716 000012          .WORD    10.            ;STARTING VALUE OF BLOCK SIZE
6730 075720          T39TAD: ;CHARACTERISTICS DATA BLOCK
6731 075720 000          T39B50: .BYTE    0
6732 075721 000          T39B51: .BYTE    0

```

```

6733 075722 000000 T39852: .WORD 0 ;BSEL1 WORD
6734 075724 000000 .WORD 0 ;DATA
6735 075726 T398FR: .BLKW 150. ;MESSAGE BUFFER
6736
6737
6739 076410 .=<. *10>E177770
6741 076410 T39PK2: ;COMMAND PACKET FOR TEST
6742 076410 140004 .WORD 140004 ;WRITE CHARA. MEM. CMND., ACK,CVC=1
6743 076412 076420 .WORD T39DTA ;ADDRESS OF SELECT DATA BLOCK
6744 076414 000000 .WORD 0
6745 076416 000012 .WORD 10. ;STARTING VALUE OF BLOCK SIZE
6746
6747
6748 076420 T39DTA: ;SELECT DATA BLOCK
6749 076420 075726 .WORD T398FR ;ADDRESS OF MESSAGE BUFFER
6750 076422 000000 .WORD 0
6751 076424 000400 .WORD 256. ;LENGTH OF MESSAGE BUFFER
6752 076426 000000 T39EAI: .WORD 0 ;EAI BIT WORD
6753 076430 000000 T39DSW: .WORD 0 ;DRIVE SELECT WORD ETC
6755 076440 .=<. *10>E177770
6757 076440 T39PK3: .WORD 140012 ;MESSAGE BUFFER RELEASE COMMAND
6758 076442 000000 .WORD 0 ;NOT USED
6759
6760 ;WRITE TAPE PACKET
6761
6763 076450 .=<. *10>E177770
6765 076450 T39PK4: .WORD 140005 ;WRITE, ACK, CVC=1 COMMAND
6766 076452 000000 T39WR: .WORD 0 ;ADDRESS OF WRITE BUFFER
6767 076454 000000 .WORD 0 ;MORE ADDRESS OF WRITE BUFFER
6768 076456 000400 T39SIZ: .WORD 256. ;SIZE OF RECORD
6769
6770
6771
6772
6773
6774 ;*
6775 ;LOCAL TEXT MESSAGES FOR TEST
6776 ;-
6777
6778
6779
6780 076460 045 116 000 T39NFL: .ASCIZ '#N'
6781 076463 123 164 141 T39NE: .ASCIZ 'Stand-alone Configuration Typeout Not Executed'
6782 076542 045 116 045 T39ETS: .ASCIZ '#N#A Extended Tape Status Available, Drive Number #D2'
6783 076631 045 116 045 T39ETN: .ASCIZ '#N#A Extended Tape Status NOT Available, Drive Number #D2'
6784 076724 045 116 045 T39OF2: .ASCIZ '#N#A Drive Number #D2#A Is Off-Line'
6785 076770 045 116 045 T39ON2: .ASCIZ '#N#A Drive Number #D2#A Is On-Line'
6786 077033 045 116 045 T39WRT: .ASCIZ '#N#A Drive Number #D2#A Is Write Protected'
6787 077106 045 116 045 T39WPN: .ASCIZ '#N#A Drive Number #D2#A Is NOT Write Protected'
6788 077165 127 122 111 T39NBA: .ASCIZ 'WRITE SUBSYSTEM MEMORY Command Not Accepted'
6789 077241 103 157 156 T39SSR: .ASCIZ 'Contents of TSSR Incorrect After WRITE SUBSYSTEM MEMORY'
6790
6791 077331 045 116 045 T39SFS: .ASCIZ '#N#A State Of Extended Features Switch ='
6792 077403 045 116 045 T39SBS: .ASCIZ '#N#A State Of Buffering Switch ='
6793 077455 045 101 040 T39OFF: .ASCIZ '#A OFF'
6794 077464 045 101 040 T39ON: .ASCIZ '#A ON'
6795 077473 045 116 045 T39MCL: .ASCIZ '#N#A M7196 Microcode Revision Level =#D2'
    
```



```

6796
6797 077550 000000      T39RL: .EVEN
6798                    .WORD 0
6799                    .EVEN
6800                    .EVEN
6801
6802                    ;*
6803                    ;LOCAL STORAGE FOR THIS TEST
6804                    ;-
6805 077552 000000      T39DAT: .WORD 0          ;LOGICAL RESPONSE TO QUESTION
6806 077554            T39REST:
6807 077554            SAVREG          ;SAVE THE REGISTERS
6808 077560 012701 075710      MOV      #T39PACKET,R1      ;START OF THE PACKET
6809 077564 012721 140006      MOV      #140006,(R1).    ;WRITE SUBSYSTEM MEM. WITH ACK,CYC=1
6810 077570 012721 075720      MOV      #T39TAD,(R1).    ;ADDRESS OF DATA BLOCK
6811 077574 005021            CLR      (R1).            ;EXTENDED ADDRESS
6812 077576 012721 000006      MOV      #6,(R1).        ;SIZE OF DATA BLOCK IN BYTES
6813 077602 005021            CLR      (R1).            ;CLEAR BSEL0 AND BSEL1
6814 077604 005021            CLR      (R1).            ;CLEAR SEL2
6815 077606 005011            CLR      (R1).            ;CLEAR DATA AREA
6816 077610 000207            RTS      PC              ;RETURN
6817
6818                    ;*
6819                    ;LOCAL TEXT MESSAGES FOR TEST
6820                    ;-
6821
6822 077612      103      157      156  TST39ID: .ASCIZ 'Configuration Typeout'
6823
6824 077640            .EVEN
6825 077640            ENDTST
6826
6827
6828
6829
6830
6831
6832
6833
6834
6835
6836
6837
6838
6839
6840
6841
6842
6843
6844
6845
6846
6847
6848
6849
6850

```

L10076: TRAP C#ETST

```

.SBTTL TEST 12: SCOPE LOOPS

```

THIS IS A STANDALONE ROUTINE PROVIDING A NUMBER OF TIGHT "SCOPE LOOPS" USEFUL FOR DEBUGGING BASIC REGISTER ACCESS PROBLEMS WITH THE M7196 MODULE. THESE SCOPE LOOPS CAN BE USED WHEN THE NORMAL "LOOP ON ERROR" OR "LOOP ON TEST (SUBTEST)" FACILITIES DON'T SEEM TO ALLOW THE OPERATOR TO ZERO IN A PROBLEM IN THE EARLY TESTS (I.E. THE HARDWARE MAY NOT BE RESPONDING TO A REGISTER ACCESS, CAUSING A BUS ERROR TRAP, EVEN THOUGH THE DEVICE ADDRESS SELECTED BY THE PROGRAM MATCHES THE CONFIGURATION SET UP IN THE HARDWARE DIP SWITCHES). THE FOLLOWING MENU OF SCOPE LOOPS ARE AVAILABLE:

CODE	SCOPE LOOP
0	HELP. PRINT THIS MENU.
1	TSBA READ ACCESS
2	TSSR READ ACCESS
3	INITIALIZE (TSSR WRITE ACCESS)
4	TSDB HIGH BYTE WRITE ACCESS

6851 :  
6852 :  
6853 :  
6854 :  
6855 :  
6856 :  
6857 :  
6858 :  
6859 :  
6860 :  
6861 :  
6862 :  
6863 :

5 TSD8 LOW BYTE WRITE ACCESS  
6 TSD8 MAINTENANCE-MODE WORD WRITE ACCESS  
7 TSD8X (TSSR HIGH BYTE) WRITE ACCESS  
(EXTENDED FEATURES SWITCH MUST BE ON  
TO USE SELECTION CODE 7)  
8 EXIT (RETURN TO SUPERVISOR)

FOR SCOPE LOOPS THAT WRITE INTO REGISTERS, THE PROGRAM PROMPTS  
THE OPERATOR FOR THE DATA TO BE WRITTEN. TYPING <RETURN> CAUSES  
AN EXIT FROM THE SCOPE LOOP BACK TO MENU LEVEL.

```

6865 077642          BGNTST
      077642
6870 077642          RFLAGS R0          ;GET OPERATOR FLAGS          T12::
      077642 104421          ;BR, IF OK TO RUN          TRAP C0RFLA
6871 077644 001403    BEQ 10          ;"TEST NOT EXECUTED"
6872 077646 012700 101235 MOV #T4ONE,R0  ;JUST EXIT IF NOT
6873 077652 000402    BR 1000          ;TEST ID MESSAGE
6874 077654 012700 101302 10: MOV #TST40ID,R0 ;DO THE COMMON SETUP
6875 077660 004737 016510 1000: JSR PC,TSTSETUP ;SEE IF MANUAL INTERVENTION ALLOWED
6876 077664 004737 020500 JSR PC,CHKMAN  ;CARRY SET IF INTERVENTION ALLOWED
6877 077670 103402    BCS 20          ;EXIT IF NO MANUAL INTERVENTION
6878 077672 000137 100356 JMP 640          ;DO A SOFT INIT
6879 077676 004737 015774 20: JSR PC,SOFINIT ;BRANCH IF OK
6880 077702 103405    BCS 50          ;CONTENTS OF TSSR REGISTER
6881 077704 010001    MOV R0,R1       ;REPORT FATAL ERROR
6885 077706          ERRDF ERRNO,SFIERR,SFIMSG
      077706 104455          TRAP C0ERDF
      077710 002261          .WORD 1201
      077712 003652          .WORD SFIERR
      077714 012034          .WORD SFIMSG
6886 077716 012700 100374 50: MOV #SCHMENU,R0 ;MENU OF SCOPE LOOP SELECTIONS
6887 077722 012701 000010 MOV #8,R1       ;MAXIMUM ALLOWED SELECTION
6888 077726 004737 020256 JSR PC,GETSEL  ;GO GET THE OPERATORS SELECTION
6889 077732 005700    TST R0          ;WAS ZERO SPECIFIED ?
6890 077734 001760    BEQ 20          ;REPEAT MENU IF YES.
6891 077736 020027 000007 CMP R0,#7      ;EXTENDED TSSR ?
6892 077742 001015    BNE 30          ;BRANCH IF NOT
6893 077744 005737 002226 TST EXTFEA    ;CHECK FOR EXTENDED FEATURES SET
6894 077750 001012    BNE 30          ;BR, IF IT IS ON
6895 077752          PRINTF #EXFMSG ;WARN OPERATOR EXTENDED FEATURES CLEAR
      077752 012746 101157          MOV #EXFMSG,-(SP)
      077756 012746 000001          MOV #1,-(SP)
      077762 010600          MOV SP,R0
      077764 104417          TRAP C0PNTF
      077766 062706 000004          ADD #4,SP
6896 077772 000137 077676 30: JMP 20          ;GO BACK TO BASIC MENU
6897 077776 010004    MOV R0,R4       ;SAVE THE MENU SELECTION
6898 100000          SETPRI #PRI07 ;RAISE THE PRIORITY
      100000 012700 000340          MOV #PRI07,R0
      100004 104441          TRAP C0SPRI
6899 100006 005037 100366 CLR TTION      ;ASSUME INTERRUPTS ARE ENABLED
6900 100012 032737 000100 177560 BIT #100,#TTICSR ;ARE TTI INTERRUPTS ON ?
6901 100020 001005    BNE 40          ;BRANCH IF YES

```

```

6902 100022 005237 100366      INC      TTION      ;FLAG SET IF INTERRUPTS OFF
6903 100026 052737 000100 177560 41:  BIS      @100,@TTICSR ;ENABLE I'INTERRUPTS
6904 100034 012701 000060      MOV      @TTIVEC,R1 ;START OF TTI VECTORS
6905 100040 011137 100370      MOV      (R1),TVECSAV ;SAVE THE CURRENT TTI VECTOR
6906 100044 012721 100270      MOV      @60,(R1);  ;SET NEW INTERRUPT ROUTINE
6907 100050 011137 100372      MOV      (R1),TPRISAV ;SAVE THE VECTOR PRIORITY
6908 100054 012711 000340      MOV      @PRI07,(R1) ;USE PRIORITY SEVEN
6909 100060      SETPRI @PRI00      ;LOWER INTERRUPT BR LEVEL
        100060 012700 000000      MOV      @PRI00,R0
        100064 104441      TRAP      C1SPRI
6910 100066 006304      ASL      R4          ;CONVERT TO WORD OFFSET
6911 100070 000174 100074      JMP      @61(R4)    ;JUMP TO PROPER LOOP
6912 100074 077676      .WORD   21         ;RETYPE THE MENU
6913 100076 100116      .WORD   101        ;TSBA READ ACCESS
6914 100100 100126      .WORD   151        ;TSSR READ ACCESS
6915 100102 100140      .WORD   201        ;TSSR WRITE ACCESS
6916 100104 100160      .WORD   251        ;TSDB HIGH BYTE WRITE ACCESS
6917 100106 100204      .WORD   301        ;TSDB LOW BYTE WRITE ACCESS
6918 100110 100230      .WORD   351        ;TSDB MAINTENANCE MODE
6919 100112 100250      .WORD   401        ;TSDBX WRITE ACCESS
6920 100114 100362      .WORD   651        ;LEAVE THE TEST
6921
6922
6923 100116 105065 000000      101:  CLRB   TSDB(R5) ;ENTER MAINTENANCE MODE
6924 100122 011500      121:  MOV    (R5),R0    ;READ TSBA REGISTER
6925 100124 000776      BR     121         ;LOOP UNTIL HALTED
6926
6927
6928 100126 012703 000002      151:  MOV    @TSSR,R3    ;ADDRESS OF TSSR REGISTER
6929 100132 060503      ADD   R5,R3        ;POINT TO TSV05'S REGISTERS
6930 100134 011300      181:  MOV    (R3),R0    ;READ TSSR REGISTER
6931 100136 000776      BR     181        ;LOOP UNTIL STOPPED
6932
6933 100140 004737 020174      201:  JSR   PC,GETPAT   ;READ THE DATA PATTERN
6934 100144 010001      MOV   R0,R1        ;DATA PATTERN FOR LOOP
6935 100146 012703 000002      MOV   @TSSR,R3    ;ADDRESS OF TSSR
6936 100152 060503      ADD   R5,R3        ;POINT TO TSV05'S REGISTERS
6937 100154 010113      221:  MOV   R1,(R3)     ;WRITE DATA TO TSSR
6938 100156 000776      BR    221         ;LOOP
6939
6940
6941 100160 105065 000000      251:  CLRB   TSDB(R5)   ;ENTER MAINTENANCE MODE
6942 100164 004737 020174      JSR   PC,GETPAT   ;READ THE DATA PATTERN
6943 100170 010001      MOV   R0,R1        ;DATA PATTERN FOR LOOP
6944 100172 012703 000001      MOV   @TSDBH,R3   ;ADDRESS OF HIGH BYTE OF TSDB
6945 100176 060503      ADD   R5,R3        ;POINT TO TSV05'S REGISTERS
6946 100200 110113      271:  MOVB  R1,(R3)     ;WRITE THE DATA TO TSDB, HIGH BYTE
6947 100202 000776      BR    271        ;LOOP UNTIL STOPPED
6948
6949
6950 100204 105065 000000      301:  CLRB   TSDB(R5)   ;ENTER MAINTENANCE MODE
6951 100210 004737 020174      JSR   PC,GETPAT   ;READ THE DATA PATTERN
6952 100214 010001      MOV   R0,R1        ;DATA PATTERN FOR LOOP
6953 100216 012703 000000      MOV   @TSDB,R3    ;ADDRESS OF TSSR
6954 100222 060503      ADD   R5,R3        ;POINT TO TSV05'S REGISTERS
6955 100224 110113      321:  MOVB  R1,(R3)     ;WRITE DATA TO TSSR, LOW BYTE
6956 100226 000776      BR    321        ;LOOP UNTIL HALTED BY OPERATOR

```

TSV5 - HARDWARE TESTS    MACRO M1113    14-JUN-84 15:55  
 TEST 12: SCOPE LOOPS

SEQ 0250

```

6957
6958 100230 004737 020174      35$: JSR   PC,GETPAT      ;READ THE DATA PATTERN
6959 100234 010001              MOV   R0,R1           ;DATA PATTERN FOR LOOP
6960 100236 012703 000000      MOV   @TSD8,R3       ;SELECT TSD8
6961 100242 060503              ADD   R5,R3          ;POINT TO TSV05'S REGISTERS
6962 100244 010113      37$: MOV   R1,(R3)     ;WRITE THE DATA PATTERN
6963
6964 100246 000776              BR    37$           ;LOOP UNTIL HALTED
6965
6966 100250 004737 020174      40$: JSR   PC,GETPAT      ;READ THE DATA PATTERN
6967 100254 010001              MOV   R0,R1           ;SAVE THE DATA PATTERN
6968 100256 012703 000003      MOV   @TSSRH,R3      ;BYTE ADDRESS OF TSSR, HIGH BYTE
6969 100262 060503              ADD   R5,R3          ;POINT TO TSV05'S REGISTERS
6970 100264 110113      42$: MOVB  R1,(R3)     ;WRITE THE DATA TO REGISTER
6971 100266 000776              BR    42$           ;LOOP UNTIL HALTED
6972
6973
6974
6975      ;*
6976      ;PROCESS CONSOLE INTERRUPTS
6977      ;
6978 100270 010046      60$: MOV   R0,-(SP)      ;SAVE WORK REGISTER
6979 100272 113700      MOVB  @TTIBFR,R0     ;GET THE OPERATOR INPUT
6980 100276 042700      BIC   @200,R0       ;STRIP OFF PARITY BIT
6981 100302 122700      CHPB  @15,R0        ;IS IT A CARRIAGE RETURN ?
6982 100306 001021      BNE   61$          ;JUST EXIT IF NOT
6983 100310 012766 077676 000002  MOV   @2$,2(SP)     ;RETURN TO MASTER MENU
6984 100316 005066      CLR   4(SP)         ;FORCE PRIORITY ZERO
6985 100322 013737 100370 000060  MOV   TVECSAV,@TTIVEC ;RESTORE SUPERVISOR VECTOR
6986 100330 013737 100372 000062  MOV   TPRISAV,@TTIVEC+2 ;RESTORE SUPERVISOR PRIORITY
6987 100336 055737 100366      TST   TTION         ;ARE SUPERVISOR INTERRUPTS ENABLED ?
6988 100342 001403      BEQ   61$          ;BRANCH IF YES
6989 100344 042737 000100 177560  BIC   @100,@TTICSR  ;TURN OFF TTI INTERRUPTS
6990 100352 012600      61$: MOV   (SP)+,R0     ;RESTORE REGISTER
6991 100354 000002      RTI                ;RETURN FROM INTERRUPT
6992
6993 100356      64$:
6994 100356      63$: EXIT   TST      ;EXIT THE TEST
        100356 104432              TRAP   C$EXIT
        100360 000736              .WORD  L10077-.
6995 100362 000137 000200      65$: JMP    200        ;RETURN TO SUPERVISOR
6996
6997
6998      ;*
6999      ;LOCAL STORAGE FOR THIS TEST
7000      ;-
7001 100366 000000      TTION: .WORD  0      ;WORD SET IF SUPERVISOR TTI INTER OFF
7002 100370 000000      TVECSAV: .WORD  0    ;SAVE TTI VECTOR
7003 100372 000000      TPRISAV: .WORD  0    ;SAVE TTI PRIORITY
7004
7005
7006      ;*
7007      ;MENU FOR OPERATOR INPUT FOR SCOPE LOOPS
7008      ;-
7009
7010      .EVEN
7011 100374 100426 100501 100527  SCMENU: .WORD  1$,2$,3$,4$,5$,6$

```

```

7012 100410 100700 100736 101004 .WORD 7,8,9,10,11,12,0
7013
7014
7015 100426 012 123 105 1: .ASCIZ <12>'SELECT SCOPE LOOP FROM FOLLOWING OPTIONS:
7016 100501 012 011 060 2: .ASCIZ <12>' 0 Display This Menu'
7017 100527 011 061 011 3: .ASCIZ ' 1 TSBA Read Access'
7018 100553 011 062 011 4: .ASCIZ ' 2 TSSR Read Access'
7019 100577 011 063 011 5: .ASCIZ ' 3 Initialize (TSSR Write Access)'
7020 100641 011 064 011 6: .ASCIZ ' 4 TSDB High Byte Write Access'
7021 100700 011 065 011 7: .ASCIZ ' 5 TSDB Low Byte Write Access'
7022 100736 011 066 011 8: .ASCIZ ' 6 TSDB Maintenance Mode Write Access'
7023 101004 011 067 011 9: .ASCIZ ' 7 TSDBX (TSSR High Byte) Write Access'
7024 101053 011 070 011 10: .ASCIZ ' 8 Return to Diagnostic Supervisor'
7025 101116 000 11: .ASCIZ ''
7026 101117 124 171 160 12: .ASCIZ 'Type RETURN To Stop Scope Loops'
7027 101157 045 116 045 EXFMSG: .ASCIZ 'NSA *** Extended Features Switch Not On ***'
7028 101235 123 164 141 T4ONE: .ASCIZ 'Stand-alone Scope Loops Not Executed'
7029 101302 123 143 157 TST40ID: .ASCIZ 'Scope Loops'
7030 .EVEN
7031 101316 .ENDTST
101316 L10077: TRAP C#ETST
101316 104401
7032 101320 .ENDMOD

```

```

1          .TITLE  TSV6 - PARAMETER CODING
7
12
18
19 101320  BGNMOD  TSV6
101320  TSV6::
20
21          .SBTTL  HARDWARE PARAMETER CODING SECTION
22
23          ;**
24          ; THE HARDWARE PARAMETER CODING SECTION CONTAINS MACROS
25          ; THAT ARE USED BY THE SUPERVISOR TO BUILD P-TABLES.  THE
26          ; MACROS ARE NOT EXECUTED AS MACHINE INSTRUCTIONS BUT ARE
27          ; INTERPRETED BY THE SUPERVISOR AS DATA STRUCTURES.  THE
28          ; MACROS ALLOW THE SUPERVISOR TO ESTABLISH COMMUNICATIONS
29          ; WITH THE OPERATOR.
30          ;--
31 101320  BGNHRD
101320 000010  .WORD  L10100-L#HARD/2
101322  L#HARD::
32
33 101322  GPRMA  HPM1,0,0,160010,177776,YES      ;GET TSBA/TSDB REGISTER ADDRESS.
101322 000031  .WORD  T#CODE
101324 101342  .WORD  HPM1
101326 160010  .WORD  T#LOLIM
101330 177776  .WORD  T#HILIM
34 101332  GPRMA  HPM2,2,0,0,776,YES              ;GET VECTOR ADDRESS.
101332 001031  .WORD  T#CODE
101334 101376  .WORD  HPM2
101336 000000  .WORD  T#LOLIM
101340 000776  .WORD  T#HILIM
35          ;GPRMD  HPM3,4,0,340,0,7,YES          ;GET INTERRUPT PRIORITY.
36 101342  ENDRD
          .EVEN
          L10100:
37 101342  104    105    126  HPM1:  .ASCIZ  'DEVICE ADDRESS (TSBA/TSDB) '
38 101376  111    116    124  HPM2:  .ASCIZ  'INTERRUPT VECTOR '
39 101422  111    116    124  HPM3:  .ASCIZ  'INTERRUPT PRIORITY '
40          .EVEN

```

```

42          .SBTTL  SOFTWARE PARAMETER CODING SECTION
43
44          ;**
45          ; THE SOFTWARE PARAMETER CODING SECTION CONTAINS MACROS
46          ; THAT ARE USED BY THE SUPERVISOR TO BUILD P-TABLES.  THE
47          ; MACROS ARE NOT EXECUT'D AS MACHINE INSTRUCTIONS BUT ARE
48          ; INTERPRETED BY THE SUPERVISOR AS DATA STRUCTURES.  THE
49          ; MACROS ALLOW THE SUPERVISOR TO ESTABLISH COMMUNICATIONS
50          ; WITH THE OPERATOR.
51          ;--
52 101452      BGNSFT
53 101452      000003      .WORD L10101-L$SOFT/2
54 101454      L$SOFT::
55          ; GPRML  SPM1,0,-1,YES          ; GET TRANSPORT TEST FLAG.
56          ; GPRML  SPM4,2,-1,YES         ; GET ITERATION CONTROL.
57 101454      001130      .WORD  T$CODE
58 101456      101512      .WORD  SPM4
59 101460      177777      .WORD  -1
60          ; GPRMD  SPM6,4,D,7777,0,7777,YES ; GET LOCAL ERROR LIMIT
61          ; GPRMD  SPM7,6,D,7777,0,7777,YES ; GET GLOBAL ERROR LIMIT
62 101462      ENDSFT
63          .EVEN
64
65          L10101:
66 101462      105      116      101  SPM1:  .ASCIZ  'ENABLE TRANSPORT TESTS '
67 101512      111      116      110  SPM4:  .ASCIZ  'INHIBIT ITERATIONS '
68 101542      120      105      122  SPM6:  .ASCIZ  'PER TEST ERROR LIMIT '
69 101572      120      105      122  SPM7:  .ASCIZ  'PER UNIT ERROR LIMIT '
70          .SBTTL  PATCH AREA
71
72          ;
73          ; FINALLY A GENEROUS PATCH AREA.
74          ;
75          ; AND AN ADJUSTMENT TO ACCOUNT FOR THE "LASTAD BIT7" HACK
76          ; DESCRIBED IN "SUPPRG.MEM" (FOR REV C).
77          ;
78          PATCH::
79          .BLKW  32.
80          .=.!377*1
81 102000      102000      LASTAD          ;SET LAST USED ADDRESS.
82          .EVEN
83          .WORD  0
84          .WORD  0
85          L$LAST::
86          ENDMOD
87          .END

```

ADSSR 012126 G  
ADR = 000020 G  
AMBTSS 006635  
ASSEMB= 000010  
A1716 = 000003  
BADDAT 003156 G  
BADSSR 015700 G  
BDVPCR= 177520 G  
BENBSW 002230 G  
BIE = 040000  
BIT0 = 000001 G  
BIT00 = 000001 G  
BIT01 = 000002 G  
BIT02 = 000004 G  
BIT03 = 000010 G  
BIT04 = 000020 G  
BIT05 = 000040 G  
BIT06 = 000100 G  
BIT07 = 000200 G  
BIT08 = 000400 G  
BIT09 = 001000 G  
BIT1 = 000002 G  
BIT10 = 002000 G  
BIT11 = 004000 G  
BIT12 = 010000 G  
BIT13 = 020000 G  
BIT14 = 040000 G  
BIT15 = 100000 G  
BIT2 = 000004 G  
BIT3 = 000010 G  
BIT4 = 000020 G  
BIT5 = 000040 G  
BIT6 = 000100 G  
BIT7 = 000200 G  
BIT8 = 000400 G  
BIT9 = 001000 G  
BOE = 000400 G  
BRINIT 004457  
BSELO = 000000  
BSEL1 = 000001  
CHKAMB 016044  
CHKMAN 020500 G  
CHKTSS 016336  
CKDROP 017202  
CKEMAX 017102  
CKMSG 011360 G  
CKMSG2 011500 G  
CKRAM 011114 G  
CKRAM2 011224 G  
CMPKPT 021214 G  
CMPMEM 017660  
CONFIG 017250  
COUNT 002310 G  
CSRADD 002206 G  
CTAB 003164 G  
CTABE 003176 G  
CTABM 003164 G

C#AU = 000052  
C#AUTO= 000061  
C#BRK = 000022  
C#BSEG= 000004  
C#BSUB= 000002  
C#CEFG= 000045  
C#CLCK= 000062  
C#CLEA= 000012  
C#CLOS= 000035  
C#CLP1= 000006  
C#CVEC= 000036  
C#DCLN= 000044  
C#DODU= 000051  
C#DRPT= 000024  
C#DU = 000053  
C#EDIT= 000003  
C#ERDF= 000055  
C#ERHR= 000056  
C#ERRO= 000060  
C#ERSF= 000054  
C#ERSO= 000057  
C#ESCA= 000010  
C#ESEG= 000005  
C#ESUB= 000003  
C#ETST= 000001  
C#EXIT= 000032  
C#GETB= 000026  
C#GETW= 000027  
C#GMAN= 000043  
C#GPHR= 000042  
C#GPLO= 000030  
C#GPRI= 000040  
C#INIT= 000011  
C#INLP= 000020  
C#MANI= 000050  
C#MEM = 000031  
C#MSG = 000023  
C#OPEN= 000034  
C#PNTB= 000014  
C#PNTF= 000017  
C#PNTS= 000016  
C#PNTX= 000015  
C#QIO = 000377  
C#ROBU= 000007  
C#REFG= 000047  
C#RESE= 000033  
C#REVI= 000003  
C#RFLA= 000021  
C#RPT = 000025  
C#SEFG= 000046  
C#SPRI= 000041  
C#SVEC= 000037  
C#TPRI= 000013  
DATA 002312 G  
DATASC 020232  
DEBUGM 011632  
DEVcnt 002220 G

DEVDR0 023332  
DEVNR0 023251  
DEVNXR 023167  
DEVONL 023117  
DEVSUM 023062  
DFPTBL 002156 G  
DIAGMC= 000000  
DICEB = 000001  
DSBINT 016204  
DUAD12 004643  
DUFLG 003112 G  
DUMMY 003062  
EF.CON= 000036 G  
EF.NEW= 000035 G  
EF.PWR= 000034 G  
EF.RES= 000037 G  
EF.STA= 000040 G  
EMAXDU 016777  
EN = 000000  
ENAINI 016152  
ENVIRN 020630  
EPRTSW 002200 G  
EPRT1 006360  
EPRT2 006360  
ERCM 011733  
ERRHI 002236 G  
ERRK 016756  
ERRLO 002240 G  
ERRNO = 002261  
ERRVEC= 000004 G  
ERTABE 003376  
ERTABL 003176  
ESUM 016760  
EVL = 000004 G  
EXBCNT= 000010  
EXFMSG 101157  
EXPBRE 015502 G  
EXPD 002232 G  
EXPBOT 004533  
EXPOT2 004567  
EXPMSG 002322 G  
EXPREC 015474 G  
EXTA 005772  
EXTEND 005770  
EXTFEA 002226 G  
E#END = 002100  
E#LOAD= 000035  
FATERR= 000060  
FATFLG 002222 G  
FERCM 011722  
FIFEXP 012170 G  
FIF1MS 012242  
FIF2MS 012311  
FILLME 017422  
FNOINT 004215  
FORCER 002176 G  
FREE 003124 G

FREEHI 003130  
FRESIZ 003126 G  
FUSI 004117  
F#AU = 000015  
F#AUTO= 000020  
F#BGN = 000040  
F#CLEA= 000007  
F#DU = 000016  
F#END = 000041  
F#HARD= 000004  
F#HW = 000003  
F#INIT= 000006  
F#JMP = 000050  
F#MOD = 000000  
F#MSG = 000011  
F#PRU1= 000021  
F#PWR = 000017  
F#RPT = 000012  
F#SEG = 000003  
F#SOFT= 000005  
F#SRV = 000010  
F#SUB = 000002  
F#SW = 000014  
F#TEST= 000001  
GDDAT 003160 G  
GERRMA 002174 G  
GETPAT 020174 G  
GETSEL 020256 G  
G#CNT0= 000200  
G#DELM= 000372  
G#DISP= 000003  
G#EXCP= 000400  
G#HILI= 000002  
G#LOLI= 000001  
G#NO = 000000  
G#OFFS= 000400  
G#OFSI= 000376  
G#PRMA= 000001  
G#PRMD= 000002  
G#PRML= 000000  
G#RADA= 000140  
G#RADB= 000000  
G#RADD= 000040  
G#RADL= 000120  
G#RADO= 000020  
G#XFER= 000004  
G#YES = 000010  
HIADDR= 001400  
HOE = 100000 G  
HPM1 101342  
HPM2 101376  
HPM3 101422  
IBE = 010000 G  
IDU = 000040 G  
IER = 020000 G  
IFALT 004256  
INCERK 017044

INTCPC 016150  
INTFLA 016145  
INTMAS 016144  
INTR 016216 G  
INTREC 002224 G  
INTVEC 016146  
INTX 004300  
INVERT 021142 G  
IOKCKI= 000200  
IOKSTP= 000001  
IPRI 002212 G  
ISR = 000100 G  
IVC 002210 G  
IXE = 004000 G  
I#AU = 000041  
I#AUTO= 000041  
I#CLN = 000041  
I#DU = 000041  
I#HRD = 000041  
I#INIT= 000041  
I#MOD = 000041  
I#MSG = 000041  
I#PROT= 000040  
I#PTAB= 000041  
I#PWR = 000041  
I#RPT = 000041  
I#SEG = 000041  
I#SETU= 000041  
I#SFT = 000041  
I#SRV = 000041  
I#SUB = 000041  
I#TST = 000041  
J#JMP = 000167  
KIPAR0= 172340  
KIPAR1= 172342  
KIPAR2= 172344  
KIPAR3= 172346  
KIPAR4= 172350  
KIPAR5= 172352  
KIPAR6= 172354  
KIPAR7= 172356  
KIPDR0= 172300  
KIPDR1= 172302  
KIPDR2= 172304  
KIPDR3= 172306  
KIPDR4= 172310  
KIPDR5= 172312  
KIPDR6= 172314  
KIPDR7= 172316  
KTENAB 003134 G  
KTFLG 003132 G  
KINIT 021010  
KTOFF 017274  
KTON 017256  
LERRMA 002172 G  
LERRNO= 000000  
LISTAL= 000001



LOE = 040000 G  
 LOOPCN 002216 G  
 LOOPCO 013126  
 LOOPFL 003162 G  
 LOT = 000010 G  
 L\$ACP 002110 G  
 L\$APT 002036 G  
 L\$AU 022306 G  
 L\$AUT 002070 G  
 L\$AUTO 022512 G  
 L\$CCP 002106 G  
 L\$CLEA 022572 G  
 L\$CO 002032 G  
 L\$DEPO 002011 G  
 L\$DESC 003410 G  
 L\$DESP 002076 G  
 L\$DEVP 002060 G  
 L\$DISP 002124 G  
 L\$DLY 002116 G  
 L\$DTP 002040 G  
 L\$DTYP 002034 G  
 L\$DU 022404 G  
 L\$DUT 002072 G  
 L\$DVTY 003402 G  
 L\$EF 002052 G  
 L\$ENVI 002044 G  
 L\$ETP 002102 G  
 L\$EXP1 002046 G  
 L\$EXP4 002064 G  
 L\$EXPS 002066 G  
 L\$HARD 101322 G  
 L\$HIME 002120 G  
 L\$HPCP 002016 G  
 L\$HPTP 002022 G  
 L\$HW 002156 G  
 L\$ICP 002104 G  
 L\$INIT 021512 G  
 L\$LADP 002026 G  
 L\$LAST 102004 G  
 L\$LOAD 002100 G  
 L\$LUN 002074 G  
 L\$MREV 002050 G  
 L\$NAME 002000 G  
 L\$PRIO 002042 G  
 L\$PROT 021502 G  
 L\$PRT 002112 G  
 L\$REPP 002062 G  
 L\$REV 002010 G  
 L\$RPT 022620 G  
 L\$SOFT 101454 G  
 L\$SPC 002056 G  
 L\$SPCP 002020 G  
 L\$SPTP 002024 G  
 L\$STA 002030 G  
 L\$SW 002166 G  
 L\$TEST 002114 G  
 L\$TIML 002014 G

L\$UNIT 002012 G  
 L10000 002164  
 L10001 002176  
 L10002 005766  
 L10003 012044  
 L10004 012062  
 L10005 012100  
 L10006 012106  
 L10007 012124  
 L10010 012142  
 L10011 012166  
 L10012 012240  
 L10013 012410  
 L10014 013124  
 L10015 013752  
 L10016 013774  
 L10017 015500  
 L10020 015506  
 L10021 015514  
 L10022 015526  
 L10023 015550  
 L10024 015576  
 L10025 015736  
 L10026 016246  
 L10030 022236  
 L10031 022402  
 L10032 022510  
 L10033 022570  
 L10034 022616  
 L10035 023060  
 L10036 024364  
 L10037 026356  
 L10040 024640  
 L10041 025104  
 L10042 031752  
 L10043 026732  
 L10044 027222  
 L10045 027520  
 L10046 030152  
 L10047 034542  
 L10050 032306  
 L10051 032700  
 L10052 033306  
 L10053 040334  
 L10054 035626  
 L10055 036560  
 L10056 050446  
 L10057 040640  
 L10060 042050  
 L10061 043410  
 L10062 043766  
 L10063 045240  
 L10064 046304  
 L10065 051726  
 L10066 062554  
 L10067 053732  
 L10070 055220

L10071 056470  
 L10072 057734  
 L10073 066624  
 L10074 064764  
 L10075 074466  
 L10076 077640  
 L10077 101316  
 L10100 101342  
 L10101 101462  
 MEMADD 013754 G  
 MEMCK 021232 G  
 MENASC 020447  
 MENERR 020374  
 MENRES 020476  
 MINENU 03352  
 MMVEC = 000250  
 MSA.FR = 000006  
 MSA.NO = 000000  
 MSA.NR = 000004  
 MSA.VO = 000002  
 MSGEXP 012144 G  
 MSGLOO 013064 G  
 MSGSTA 012350 G  
 MSGSUB 013742 G  
 MS.ATT = 000006  
 MS.EXT = 000200  
 MS.RSD = 000001  
 MS.RSF = 000020  
 MS.RST = 000010  
 M8186 005554  
 M8189 005645  
 NBA = 002000  
 NEMPAS 021744  
 NODEV 003114 G  
 NOEXTF 030146  
 NOINIT 004335  
 NOINTR 004221  
 NOITS 002170 G  
 NOMAN 020534  
 NOMEM 005460  
 NP.IR = 000200  
 NP.LOO = 000040  
 NP.OUT = 000100  
 NP.WRP = 000020  
 NSI 004152  
 NSINIT 004407  
 NUL 004527  
 NULCR 004530  
 NXM = 004000  
 NXMFLG 003136 G  
 NXMHI 003142 G  
 NXMLO 003140 G  
 NXMTST 021406  
 NXR 003740  
 NXRERR 005736 G  
 NXRX 003777  
 NXTU 021756

OFL = 000100  
 ONEFIL = 000000  
 O\$APTS = 000000  
 O\$AU = 000001  
 O\$BGNR = 000001  
 O\$BGNS = 000001  
 O\$DU = 000001  
 O\$ERRT = 000000  
 O\$GNSW = 000001  
 O\$POIN = 000001  
 O\$SETU = 000000  
 PASRPT 022010  
 PATCH 101622 G  
 PATDAT 020230  
 PC.ERA = 002400  
 PC.IER = 002000  
 PC.NOO = 001000  
 PC.REL = 000000  
 PC.REW = 000400  
 PKBCNT = 000006  
 PKHI = 000004  
 PKLOW = 000002  
 PKTADD 007554  
 PKTFRM 007516  
 PKTGET 012064 G  
 PKTMES 012110 G  
 PKTRAM 004745 G  
 PKTSSR 012046 G  
 PNT = 001000 G  
 PRAMPK 013776  
 PRASC 014523  
 PRBEXP 015470  
 PRBMSG 015336  
 PRBREC 015472  
 PRBTOT 015423  
 PRBYTE 015122 G  
 PRI = 002000 G  
 PRIADD 010160  
 PRIAO 010230  
 PRIBXO 007612 G  
 PRIEQU 010060  
 PRIPKT 007370 G  
 PRIRAM 010066  
 PRITAD 010274  
 PRITSS 006024  
 PRITO 010356  
 PRIT1 010421  
 PRIXOR 007742 G  
 PRIOO = 000000 G  
 PRIO1 = 000040 G  
 PRIO2 = 000100 G  
 PRIO3 = 000140 G  
 PRIO4 = 000200 G  
 PRIO5 = 000240 G  
 PRIO6 = 000300 G  
 PRIO7 = 000340 G  
 PRMESS 014242

PRMNO 002320 G  
 PRMSGE 014552 G  
 PRMSGO 014732  
 PRMSG1 014777  
 PRMSG2 015035  
 PROASC 014420  
 PRIASC 014465  
 PST32W 003152 G  
 PUNIT 022240  
 PW.D11 = 000021  
 PW.D13 = 000022  
 PW.D22 = 000020  
 PW.NOP = 000000  
 PW.NO1 = 000023  
 PW.RDE = 000024  
 PW.RDR = 000001  
 PW.RDS = 000005  
 PW.RFI = 000003  
 PW.WCT = 000006  
 PW.WFI = 000004  
 PW.WFM = 000007  
 PW.WMI = 000010  
 PW.WNP = 000011  
 PW.WTR = 000002  
 P.ACK = 100000  
 P.CMD = 000037  
 P.CONT = 000012  
 P.CVC = 040000  
 P.FMT = 000140  
 P.FORM = 000011  
 P.GETS = 000017  
 P.IE = 000200  
 P.INIT = 000013  
 P.MODE = 007400  
 P.OPP = 020000  
 P.POSI = 000010  
 P.READ = 000001  
 P.SWB = 010000  
 P.WRIT = 000005  
 P.WRTC = 000004  
 P.WRTS = 000006  
 QVP 002204 G  
 RAMASC 014156  
 RAMDAT 002242 G  
 RAMERR 015510 G  
 RAMEXP 015530 G  
 RAMFOR 010116  
 RAMSIZ 002302 G  
 RAMTAD 015516 G  
 RCVHIA 002304 G  
 RCVLOA 002306 G  
 RDERR 005206  
 RECMSG 002466 G  
 RECV 002234 G  
 REGSAV 020140  
 RETERR 005372  
 REWIND 011014 G

TSV6 - PARAMETER CODING MACRO M1113 14-JUN-84 15:55  
SYMBOL TABLE

SEQ 0256

RMCHBE= 000167	S1.IID= 004000	TST40I 101302	T10 066626 G	T158FR 033352
RMCYEN= 000200	S1.IIR= 020000	TSV2 002000 G	T11 074470 G	T158F2 034040
RMMSGB= 000215	S1.I2R= 040000	TSV3 002176 G	T12 077642 G	T158S0 034040
RMMSGE= 000234	S1.PAR= 100000	TSV4 021502 G	T12BFR 030242	T158S1 034041
RMPKTB= 000201	S2.ATI= 000010	TSV5 023402 G	T12BKG 030717	T15DAT 033340
RMPKTE= 000210	S2.BTI= 000004	TSV6 101320 G	T12BLK 030274	T15L00 032004
RMR = 010000	S2.DIM= 000200	TTIBFR= 177562 G	T12CHA 031710	T15PAC 033330
RMPACK 011110	S2.ILW= 000100	TTICSR= 177560 G	T12CKR 031470 G	T15PK2 034030
SC = 100000	S2.INR= 000020	TTION 100366	T12CON 031276	T15RES 034432
SCE = 020000	S2.OUT= 000040	TTION2 071414	T12DAT 030230	T15RT2 034504
SCHERR 005300	S2.UND= 000003	TTIVEC= 000060 G	T12DPR 031076	T15SSR 034046
SCHE 005013	TBLEND= 003062 G	TVECSA 100370	T12GET 030456	T15S2 034042
SCMENU 100374	TCOASC 006476	TVSAV2 071416	T12HIA 030262	T15S3 034044
SDELAY 010660	TCOCOD 006676	T#ARGC= 000001	T12KT 030270	T16BEN 040220
SELASC 020442	TEMP1 003116 G	T#CODE= 001130	T12LOA 030264	T16BFR 040172
SELDAT= 000004	TEMP2 003120 G	T#ERRN= 002261	T12L00 026406	T16BFS 040212
SEL2 = 000002	TERCLS= 000016	T#EXCP= 000000	T12MSG 030621	T16CLR 040036
SEMAP 017316	TESTNO= 000014	T#FLAG= 000040	T12NIN 031005	T16DAT 040160
SETU 022042	TEXASC 006435	T#GMAN= 000000	T12NXM 031167	T16DT2 040230
SFFMSG 012102 G	TFCASC 006537	T#HILI= 000776	T12PAC 030220	T16D01 036612
SFHERR 003705	TIMEXP 015552 G	T#LAST= 000001	T12PAR 030266	T16D28 036614
SFIERR 003652	TIMSGO 015600	T#LOLI= 000000	T12SET 031646	T16D53 036616
SFIMSG 012034 G	TINERR 012021	T#LSYM= 010000	T12SWR 031600	T16D78 036620
SFPTBL 002166 G	TMPBFR 002632 G	T#LTNO= 000014	T12TBE 030426	T16LEN 037142
SIFLAG 003154 G	TNAM 016704	T#NEST= 177777	T12WRT 030532	T16L00 034562
SIMSG 011766	TPRISA 100372	T#NS0 = 000000	T12L0 026520	T16PAC 040150
SKIPT 003400	TPSAV2 071420	T#NS1 = 000005	T122L0 027054	T16PK2 040220
SOFINI 015774 G	TRANST 002166 G	T#NS2 = 000002	T123L0 027274	T16REJ 037254
SPACE 010466 G	TSBA = 000000 G	T#NS3 = 000003	T124L0 027716	T16RES 037770
SPM1 101462	TSBAH = 000001 G	T#PTNU= 000000	T124TS 030272	T16SEX 040130
SPM4 101512	TSDB = 000000 G	T#SAVL= 177777	T13BFR 024022	T16SRD 040062
SPM6 101542	TSDBH = 000001 G	T#SEGL= 177777	T13DAT 024010	T16SSR 036672
SPM7 101572	TSFCOD 007236	T#SEKO= 010000	T13L00 023420	T16TSB 037040
SRO = 177572	TSREJ = 000006	T#SUBN= 000000	T13MEM 024115	T16T01 037371
SR1 = 177574	TSSDEF 006606	T#TAGL= 177777	T13NBA 024154	T16T28 037470
SR2 = 177576	TSSR = 000002 G	T#TAGN= 010102	T13PAC 024000	T16T53 037570
SR3 = 172516	TSSRBI 003502 G	T#TEMP= 000000	T13RES 024316	T16T78 037670
SSR = 000200	TSSRFO 006415	T#TEST= 000014	T13SSR 024227	T16WMI 040102
STATCO 012412	TSSRH = 000003 G	T#TSTM= 177777	T14BFR 025136	T162SS 036727
SVCGBL= 000000	TSSX 004020	T#TSTS= 000001	T14BS0 025130	T163SS 036773
SVCINS= 000000	TSTBLK 002752 G	T##AU = 010031	T14BS1 025131	T17BEN 050322
SVCSUB= 000001	TSTCNT 002214 G	T##AUT= 010033	T14BS2 025132	T17BFR 050202
SVCTAG= 000000	TSTEND 016720	T##CLE= 010034	T14DAT 025130	T17BFS 050222
SVCTST= 000001	TSTFLA 002314 G	T##DU = 010032	T14DTA 025550	T17CLE 050106
S#LSYM= 010000	TSTL00 016456 G	T##HAR= 010100	T14L00 024404	T17CLR 047720
SO.IDB= 000010	TSTPTR 002316 G	T##HW = 010000	T14NBA 025562	T17DAT 050170
SO.IFB= 000002	TSTSET 016510 G	T##INI= 010030	T14NIN 026023	T17DT2 050340
SO.IFP= 000001	TST12I 030430	T##MSG= 010025	T14PAC 025120	T17EXE 046464
SO.ILD= 000020	TST13I 024042	T##PRO= 010027	T14PK2 025540	T17EXP 046342
SO.ION= 000040	TST14I 026201	T##RPT= 010035	T14RES 026246	T17EXS 046362
SO.IRD= 000100	TST15I 034413	T##SEG= 010000	T14RST 026304	T17L00 040364
SO.IRW= 000004	TST16I 036622	T##SOF= 010101	T14SSR 025733	T17MSK 046336
SO.ISP= 000200	TST17I 046566	T##SRV= 010026	T14TSB 026115	T17PAC 050160
S1.ICE= 002000	TST18I 051156	T##SUB= 010074	T142RE 025636	T17PK2 050330
S1.IEO= 010000	TST19I 060142	T##SW = 010001	T15AM2 034122	T17RFI 050066
S1.IFM= 001000	TST20I 065142	T##TES= 010077	T15AM3 034223	T17RSF 047764
S1.IHE= 000400	TST39I 077612	T1 023402 G	T15AM4 034325	T17SET 050126



TSV6 - PARAMETER CODING MACRO M1113 14 JUN-84 15:55  
SYMBOL TABLE

SEQ 0258

X3.MBZ= 000006	X3.REV= 000040	X3.TRF= 000020	X4.MBZ= 017400	X4.TSM= 020000
X3.MDE= 177400	X3.RIB= 000001	X4.HSP= 100000	X4.RCE= 040000	X4.WRC= 000377
X3.OPI= 000100	X3.SPA= 000200			

. ABS. 102004 000  
000000 001

ERRORS DETECTED: 0

VIRTUAL MEMORY USED: 31032 WORDS ( 122 PAGES)

DYNAMIC MEMORY: 20614 WORDS ( 79 PAGES)

ELAPSED TIME: 00:46:12

CVTSBC,CVTSBC.LST/-SP=SVC/ML,TSV1B,TSV22B,TSV3B,TSV4,TSV55B,TSV6