

DHU11

DHU-11 FUNC TST PART2
CZDHVBO

COPYRIGHT (c) 1983-84
AH-T797B-MC
FICHE 01 OF 02

JUL 1984
digital
Made In USA

This microfiche card contains a grid of 14 columns and 24 rows of frames. Each frame is a small, square image, likely a scan of a document page. The text within the frames is too small and blurry to be legible, but the overall layout is a structured grid of information. The card is dark, and the frames are arranged in a regular pattern across the surface.

DHU11

DHU-11 FUNC TST PART2
CZDHSVBO

COPYRIGHT (c) 1983-84
AH-T797B-MC
FICHE 02 OF 02

JUL 1984
digital
Made In USA

.REM 6

IDENTIFICATION

PRODUCT CODE: AC T796B MC
PRODUCT NAME: CZDHVBO DMU 11 FUNC TST PART2
PRODUCT DATE: 3 MARCH 1984
MAINTAINER: ENE - DIAGNOSTICS GROUP
AUTHOR: ANTHONY HART
MODIFIED BY: ANTHONY HART

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS DOCUMENT.

NO RESPONSIBILITY IS ASSUMED FOR THE USE OR RELIABILITY OF SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL OR ITS AFFILIATED COMPANIES.

COPYRIGHT (C) 1984 BY DIGITAL EQUIPMENT CORPORATION
THE FOLLOWING ARE TRADEMARKS OF DIGITAL EQUIPMENT CORPORATION:

DIGITAL
DEC

PDP
DECUS

UNIBUS
DECTAPE

MASSBUS

***** MODIFICATION HISTORY *****

ORIGINAL RELEASE:	15 DEC 83	ANTHONY HART
VERSION 80	3-MAR-84	ANTHONY HART

THE FOLLOWING MODIFICATIONS HAVE BEEN MADE TO THE OLD CZDHVA:

THE HARDWARE QUESTION "TYPE OF LOOPBACK" HAS BEEN ALTERED TO INCLUDE THE STAGGERED LOOPBACK CONNECTORS ON THE DMU11 DISTRIBUTION PANEL (M3029).

THE HARDWARE QUESTION "BR LEVEL" HAS BEEN REMOVED.

THE MODEM SIGNAL TESTS THAT WERE IN THE OLD VERSION (CZDHVA0) HAVE NOW BEEN REMOVED TO PART CZDHV. THEY WERE TESTS: 16 THRU 23. IN CZDHVA0.

THE FOLLOWING NEW TESTS HAVE BEEN ADDED TO THIS PART:

- TEST 13 - RXTIMER REGISTER TEST
- TEST 14 - TX_ACTION FIFO TEST
- TEST 15 - TX_FIFO TEST

TABLE OF CONTENTS

- 1.0 GENERAL PROGRAM CONSIDERATIONS
- 1.1 PROGRAM ABSTRACT
- 1.2 SYSTEM REQUIREMENTS
- 1.3 RELATED DOCUMENTS AND STANDARDS
- 1.4 DIAGNOSTIC HIERARCHY PREREQUISITES
- 2.0 OPERATING INSTRUCTIONS
- 2.1 COMMANDS
- 2.2 SWITCHES
- 2.3 FLAGS
- 2.4 EXTENDED COMMAND SYNTAX
- 2.4.1 START COMMAND
- 2.4.1.1 TESTS SWITCH (/TESTS:<TEST-LIST>)
- 2.4.1.2 PASS SWITCH (/PASS:<PASS-CNT>)
- 2.4.1.3 FLAGS SWITCH (/FLAGS:<FLAG-LIST>)
- 2.4.1.4 END OF PASS SWITCH (/EOP:<INCR>)
- 2.4.1.5 EFFECT OF START COMMAND
- 2.4.2 RESTART COMMAND
- 2.4.2.1 TESTS, PASS, AND FLAGS SWITCHES
- 2.4.2.2 UNITS SWITCH (/UNITS:<UNIT-LIST>)
- 2.4.2.3 EFFECT OF RESTART COMMAND
- 2.4.3 CONTINUE COMMAND
- 2.4.3.1 FLAG SWITCH (/FLAGS:<FLAG-LIST>)
- 2.4.3.2 EFFECT OF CONTINUE COMMAND
- 2.4.4 PROCEED COMMAND
- 2.4.4.1 FLAGS SWITCH (/FLAGS:<FLAG-LIST>)
- 2.4.4.2 EFFECT OF PROCEED COMMAND
- 2.4.5 ADD COMMAND
- 2.4.6 EFFECT OF ADD COMMAND
- 2.4.7 DROP COMMAND
- 2.4.8 EFFECT OF DROP COMMAND
- 2.4.9 PRINT COMMAND
- 2.4.9.1 EFFECT OF PRINT COMMAND
- 2.4.10 DISPLAY COMMAND
- 2.4.10.1 EFFECT OF DISPLAY COMMAND
- 2.4.11 FLAGS COMMAND
- 2.4.11.1 EFFECT OF FLAGS COMMAND
- 2.4.12 ZFLAGS COMMAND
- 2.4.13 ZFLAGS COMMAND
- 2.4.14 CONTROL CHARACTERS
- 2.5 HARDWARE QUESTIONS
- 2.6 SOFTWARE QUESTIONS
- 2.7 EXTENDED P-TABLE DIALOGUE
- 2.8 QUICK START-UP PROCEDURE (XXDP*)
- 3.0 ERROR INFORMATION
- 3.1 TYPES OF ERROR MESSAGES
- 3.2 SPECIFIC ERROR MESSAGES
- 4.0 PERFORMANCE AND PROGRESS REPORTS
- 5.0 TEST SUMMARIES
- 6.0 EXAMPLE ERROR FREE PASS

1.0 GENERAL PROGRAM CONSIDERATIONS

1.1 PROGRAM ABSTRACT

CZDHVBO IS PART OF THE DHU-11 FUNCTIONAL VERIFICATION TEST. THIS PART OF THE TEST VERIFIES THAT THE MAJOR COMMUNICATIONS FUNCTIONS OF THE BOARD ARE FUNCTIONING CORRECTLY. THIS PROGRAM DOES NOT PERFORM EXTENSIVE DATA TRANSMISSION AND RECEPTION TESTS.

THIS DIAGNOSTIC HAS BEEN WRITTEN FOR USE WITH THE DIAGNOSTIC RUNTIME SERVICES SOFTWARE (SUPERVISOR). THESE SERVICES PROVIDE THE INTERFACE TO THE OPERATOR AND TO THE SOFTWARE ENVIRONMENT. THIS PROGRAM CAN BE USED WITH XXDP+, ACT, APT, SLIDE AND PAPER TAPE. FOR A COMPLETE DESCRIPTION OF THE RUNTIME SERVICES, REFER TO THE XXDP+ USER'S MANUAL. THERE IS A BRIEF DESCRIPTION OF THE RUNTIME SERVICES IN THE OPERATING INSTRUCTIONS-COMMANDS OF THIS DOCUMENT.

1.2 SYSTEM REQUIREMENTS

THE FOLLOWING HARDWARE IS REQUIRED TO RUN THE DHU FVT:

- 0 UNIBUS PROCESSOR WITH AT LEAST 32K BYTES OF MEMORY.
- 0 DHU BOARDS INSTALLED ON THE UNIBUS.
- 0 APPROPRIATE PROGRAM LOAD DEVICE SUPPORTING XXDP+ MEDIA OR A DOWN LINE LOADING SYSTEM.

1.3 RELATED DOCUMENTS AND STANDARDS

- 0 XXDP+ USER'S MANUAL - DESCRIBES THE RUNNING OF DIAGNOSTICS UNDER THE XXDP+ MONITOR.

1.4 DIAGNOSTIC HIERARCHY PREREQUISITES

THE PROCESSOR, THE UNIBUS, THE SYSTEM MEMORY, THE CONSOLE TERMINAL AND THE LOAD MEDIA ARE ASSUMED TO HAVE BEEN TESTED AND FOUND WORKING BEFORE THIS PROGRAM IS RUN.

2.0 OPERATING INSTRUCTIONS

THIS SECTION CONTAINS A BRIEF DESCRIPTION OF THE RUNTIME SERVICES.
FOR DETAILED INFORMATION, REFER TO THE XXDP+ USER'S MANUAL (CHQUS).

2.1 COMMANDS

THERE ARE ELEVEN LEGAL COMMANDS FOR THE DIAGNOSTIC RUNTIME SERVICES
(SUPERVISOR). THIS SECTION LISTS THE COMMANDS AND GIVES A VERY
BRIEF DESCRIPTION OF THEM. THE XXDP+ USER'S MANUAL HAS MORE DETAILS.

COMMAND	EFFECT
START	START THE DIAGNOSTIC FROM AN INITIAL STATE
RESTART	START THE DIAGNOSTIC WITHOUT INITIALIZING
CONTINUE	CONTINUE AT TEST THAT WAS INTERRUPTED (AFTER +C)
PROCEED	CONTINUE FROM AN ERROR HALT
EXIT	RETURN TO XXDP+ MONITOR (XXDP+ OPERATION ONLY!)
ADD	ACTIVATE A UNIT FOR TESTING (ALL UNITS ARE CONSIDERED TO BE ACTIVE AT START TIME)
DROP	DEACTIVATE A UNIT
PRINT	PRINT STATISTICAL INFORMATION (IF IMPLEMENTED BY THE DIAGNOSTIC - SEE PERFORMANCE AND PROGRESS REPORTS SECTION OF THIS DOCUMENT)
DISPLAY	TYPE A LIST OF ALL DEVICE INFORMATION
FLAGS	TYPE THE STATE OF ALL FLAGS (SEE FLAGS SECTION)
ZFLAGS	CLEAR ALL FLAGS (SEE FLAGS SECTION)

A COMMAND CAN BE RECOGNIZED BY THE FIRST THREE CHARACTERS. SO
YOU MAY, FOR EXAMPLE, TYPE "STA" INSTEAD OF "START".
MORE INFORMATION CAN BE FOUND WITHIN THE SECTION LABELLED
EXTENDED COMMAND SYNTAX

2.2 SWITCHES

THERE ARE SEVERAL SWITCHES WHICH ARE USED TO MODIFY SUPERVISOR OPERATION. THESE SWITCHES ARE APPENDED TO THE LEGAL COMMANDS. ALL OF THE LEGAL SWITCHES ARE TABULATED BELOW WITH A BRIEF DESCRIPTION OF EACH. IN THE DESCRIPTIONS BELOW, A DECIMAL NUMBER IS DESIGNATED BY "DDDD".

SWITCH	EFFECT
/TESTS:LIST	EXECUTE ONLY THOSE TESTS SPECIFIED IN THE LIST. LIST IS A STRING OF TEST NUMBERS, FOR EXAMPLE - /TESTS:1:5:7-10. THIS LIST WILL CAUSE TESTS 1,5,7,8,9,10 TO BE RUN. ALL OTHER TESTS WILL NOT BE RUN.
/PASS:DDDD	EXECUTE DDDDD PASSES (DDDD = 1 TO 64000)
/FLAGS:FLGS	SET SPECIFIED FLAGS. SEE THE FLAGS SECTION OF THIS DOCUMENT.
/EOP:DDDD	REPORT END OF PASS MESSAGE AFTER EVERY DDDDD PASSES ONLY. (DDDD = 1 TO 64000)
/UNITS:LIST	TEST/ADD/DROP ONLY THOSE UNITS SPECIFIED IN THE LIST. LIST EXAMPLE - /UNITS:0:5:10-12 USE UNITS 0,5,10,11,12 (UNIT NUMBERS = 0-63)

EXAMPLE OF SWITCH USAGE:

START/TESTS:1-5/PASS:1000/EOP:100

THE EFFECT OF THIS COMMAND WILL BE: 1) TESTS 1 THROUGH 5 WILL BE EXECUTED, 2) ALL UNITS WILL TESTED 1000 TIMES AND 3) THE END OF PASS MESSAGES WILL BE PRINTED AFTER EACH 100 PASSES ONLY. A SWITCH CAN BE RECOGNIZED BY THE FIRST THREE CHARACTERS. YOU MAY, FOR EXAMPLE, TYPE "/TES:1-5" INSTEAD OF "/TESTS:1-5".

BELOW IS A TABLE THAT SPECIFIES WHICH SWITCHES CAN BE USED BY EACH COMMAND.

	TESTS	PASS	FLAGS	EOP	UNITS
START	X	X	X	X	X
RESTART	X	X	X	X	X
CONTINUE		X	X	X	
PROCEED			X		
DROP					X
ADD					X
PRINT					
DISPLAY					X
FLAGS					
ZFLAGS					
EXIT					

2.3 FLAGS

FLAGS ARE USED TO SET UP CERTAIN OPERATIONAL PARAMETERS SUCH AS LOOPING ON ERROR. ALL FLAGS ARE CLEARED AT STARTUP AND REMAIN CLEARED UNTIL EXPLICITLY SET USING THE FLAGS SWITCH. FLAGS ARE ALSO CLEARED AFTER A START COMMAND UNLESS SET USING THE FLAG SWITCH. THE ZFLAGS COMMAND MAY ALSO BE USED TO CLEAR ALL FLAGS. WITH THE EXCEPTION OF THE START AND ZFLAGS COMMANDS, NO COMMANDS AFFECT THE STATE OF THE FLAGS; THEY REMAIN SET OR CLEARED AS SPECIFIED BY THE LAST FLAG SWITCH.

FLAG	EFFECT
MOE	HALT ON ERROR - CONTROL IS RETURNED TO RUNTIME SERVICES COMMAND MODE
LOE	LOOP ON ERROR
IER*	INHIBIT ALL ERROR REPORTS
IBR*	INHIBIT ALL ERROR REPORTS EXCEPT FIRST LEVEL (FIRST LEVEL CONTAINS ERROR TYPE, NUMBER, PC, TEST AND UNIT)
IXR*	INHIBIT EXTENDED ERROR REPORTS (THOSE CALLED BY PRINTX MACRO'S)
PRI	DIRECT MESSAGES TO LINE PRINTER
PNT	PRINT TEST NUMBER AS TEST EXECUTES
BOE	"BELL" ON ERROR
UAM	UNATTENDED MODE (NO MANUAL INTERVENTION)
ISR	INHIBIT STATISTICAL REPORTS (DOES NOT APPLY TO DIAGNOSTICS WHICH DO NOT SUPPORT STATISTICAL REPORTING)
IDR	INHIBIT PROGRAM DROPPING OF UNITS
ADR	EXECUTE AUTODROP CODE
LOT	LOOP ON TEST
EVL	EXECUTE EVALUATION (ON DIAGNOSTICS WHICH HAVE EVALUATION SUPPORT)

*SEE THE ERROR INFORMATION SECTION OF THIS DOCUMENT.

SEE THE XXDP* USER'S MANUAL FOR MORE DETAILS ON FLAGS. YOU MAY SPECIFY MORE THAN ONE FLAG WITH THE FLAG SWITCH. FOR EXAMPLE, TO CAUSE THE PROGRAM TO LOOP ON ERROR, INHIBIT ERROR REPORTS AND TYPE A "BELL" ON ERROR, YOU MAY USE THE FOLLOWING STRING:

/FLAGS:LOE:IER:BOE

2.4 EXTENDED COMMAND SYNTAX

2.4.1 START COMMAND -

```
*****  
STA(RT)/TESTS:<TEST-LIST>/PASS:<PASS-CNT>/FLAGS:  
<FLAG-LIST>/EOP:<INCR>  
*****
```

2.4.1.1 TESTS SWITCH (/TESTS:<TEST-LIST>) -

<TEST-LIST> IS A SEQUENCE OF DECIMAL NUMBERS (1:2 ETC.) OR RANGES OF DECIMAL NUMBERS (1-5:8-10 ETC.), SEPERATED BY COLONS, THAT SPECIFY THE TESTS TO BE EXECUTED. TESTS WILL BE EXECUTED IN NUMERICAL ORDER REGARDLESS OF THE ORDER OF SPECIFICATION. THE DEFAULT IS TO EXECUTE ALL TESTS. ON THIS AND ALL SWITCHES, THE ANGLE BRACKETS <> ARE PUNCTUATION USED IN THE DEFINITION ONLY, AND ARE NOT TO BE TYPED BY THE OPERATOR. SEE EXAMPLE AT END OF "EFFECT OF START COMMAND" SECTION.

2.4.1.2 PASS SWITCH (/PASS:<PASS-CNT>) -

<PASS-CNT> IS A DECIMAL NUMBER INDICATING THE DESIRED NUMBER OF PASSES. A PASS IS DEFINED AS THE EXECUTION OF THE FULL DIAGNOSTIC (ALL SELECTED TESTS). THE DEFAULT IS NON-ENDING EXECUTION. IN THIS CASE, EXIT FROM THE PROGRAM IS ACCOMPLISHED EITHER BY TYPING A CONTROL/C OR BY OCCURANCE OF AN ERROR WITH THE HALT ON ERROR FLAG BEING SET. THE EXIT IS A RETURN TO COMMAND MODE. SEE EXAMPLE AT END OF "EFFECT OF START COMMAND" SECTION.

2.4.1.3 FLAGS SWITCH (/FLAGS:<FLAG-LIST>) -

<FLAG-LIST> IS A SEQUENCE OF ELEMENTS OF THE FORM <FLAG>, <FLAG=1>, OR <FLAG=0>, SEPERATED BY COLONS, WHERE <FLAG> HAS ONE OF THE FOLLOWING VALUES:

HOE	HALT ON ERROR, CAUSING COMMAND MODE TO BE ENTERED WHEN AN ERROR IS ENCOUNTERED.
LOE	LOOP ON ERROR, CAUSING THE DIAGNOSTIC TO LOOP CONTINUOUSLY WITHIN THE SMALLEST DEFINED BLOCK OF CODING (SEGMENT, SUBTEST, OR TEST) CONTAINING THE ERROR.
IER	INHIBIT ERROR REPORTING.
IBE	INHIBIT BASIC ERROR REPORTS.
IXE	INHIBIT EXTENDED ERROR REPORTS.
PRI	DIRECT ALL MESSAGES TO A LINE PRINTER.
PNT	PRINT NUMBER OF TEST BEING EXECUTED.
BOE	BELL ON ERROR (NOT RELATED TO BELL PROMPTING).
UAM	RUN IN UNATTENDED MODE, BYPASSING MANUAL INTERVENTION (ILLEGAL FOR THIS DIAGNOSTIC).
ISR	INHIBIT STATISTICAL REPORTS.

IDU INHIBIT DROPPING OF UNITS BY DIAGNOSTIC.
(HAS NO EFFECT IN THIS DIAGNOSTIC.)
LOT LOOP ON TEST.
THE FLAGS NAMED OR EQUATED TO 1 ARE SET, THOSE EQUATED TO 0 ARE
CLEARED. A FLAG NOT SPECIFIED IS CLEARED. IF THE FLAGS SWITCH IS NOT
GIVEN ALL FLAGS ARE CLEARED. SEE EXAMPLE AT END OF "EFFECT OF START
COMMAND" SECTION.

2.4.1.4 END OF PASS SWITCH (/EOP:<INCR>) -

<INCR> IS A DECIMAL NUMBER INDICATING HOW OFTEN (IN TERMS OF
PASSES) IT IS DESIRED THAT THE END OF PASS MESSAGE BE PRINTED. THE
DEFAULT IS AT THE END OF EVERY PASS. SEE EXAMPLE AT END OF "EFFECT OF
START COMMAND" SECTION.

2.4.1.5 EFFECT OF START COMMAND -

THE EFFECT OF THE START COMMAND IS TO INITIATE THE HARDWARE
PARAMETER DIALOGUE, THE SOFTWARE PARAMETER DIALOGUE, THE
INITIALIZATION QUESTIONS, AND THEN THE DIAGNOSTIC COMMENCES TESTING.

THE HARDWARE PARAMETER DIALOGUE COMMENCES WITH THE QUESTION "0
UNITS (D) ?" TO WHICH THE OPERATOR SHOULD REPLY WITH THE NUMBER OF
UNITS TO BE TESTED. FOLLOWING THIS ARE THE QUESTIONS WHEREBY THE
P-TABLES THEMSELVES ARE BUILT. EACH P-TABLE IS A CORE-RESIDENT TABLE
CONTAINING ALL THE HARDWARE INFORMATION FOR ONE COMPLETE UNIT. EACH
QUESTION IS FOLLOWED BY THE RESPONSE RADIX (D FOR DECIMAL, B FOR
BINARY, O FOR OCTAL, L FOR YES/NO) IN PARENTHESES AND THE DEFAULT
VALUE AFTER THE PARENTHESES. FOR THE ACTUAL HARDWARE P-TABLE
QUESTIONS SEE THE "HARDWARE PARAMETERS" SECTION.

FOLLOWING THE HARDWARE QUESTIONS ARE THE SOFTWARE QUESTIONS TO
BUILD THE SOFTWARE TABLES, WHICH DEFINE OPERATING PARAMETERS OF THE
DIAGNOSTIC PROGRAM. THESE QUESTIONS ARE DESCRIBED IN THE "SOFTWARE
PARAMETERS" SECTION.

EXAMPLE:

STA/TESTS:1:3-4:/PASS:3/FLAGS:IER:HOE=1

THIS COMMAND WILL CAUSE THREE PASSES TO BE MADE, WITH EACH PASS
CONSISTING OF TESTS 1,3, AND 4. THERE IS NO DIFFERENCE BETWEEN SAYING
<FLAG> AND SAYING <FLAG=1>. THE NOTATION <FLAG=0> IS MEANINGFUL ONLY
ON A COMMAND OTHER THAN START TO CLEAR A FLAG THAT WAS PREVIOUSLY SET.
NOTE THAT ON ALL COMMANDS ONLY THE FIRST THREE LETTERS ARE SCANNED.

2.4.2 RESTART COMMAND -

RES(TART)/TESTS:<TEST-LIST>/PASS:<PASS-CNT>/FLAGS:
<FLAG-LIST>/UNITS:<UNIT-LIST>

2.4.2.1 TESTS, PASS, AND FLAGS SWITCHES

<TEST-LIST>, <PASS CNT>, AND <FLAG LIST> ARE AS IN THE START COMMAND.

2.4.2.2 UNITS SWITCH (/UNITS:<UNIT-LIST>) - <UNIT-LIST> IS A SEQUENCE OF DECIMAL NUMBERS (0,1 ETC.) OR RANGES OF DECIMAL NUMBERS (0-5, 8-10 ETC.) THAT SPECIFY THE UNITS TO BE TESTED. THE NUMBERS ARE SEPARATED BY COLONS. THE NUMBERS MAY RANGE FROM 0 THRU N-1 (N IS THE NUMBER OF UNITS SPECIFIED IN THE PREVIOUS START COMMAND). THE NUMBER INDICATES THE POSITION OF THE P-TABLE AS THE DATA WAS ENTERED DURING THE HARDWARE DIAGLOGUE. THE UNITS WHICH ARE SELECTED MUST NOT HAVE BEEN DROPPED BY THE DROP COMMAND. SEE THE DISCUSSION OF ADD AND DROP COMMANDS BELOW. DEFAULT IS TO TEST ALL UNITS WHICH HAVE NOT BEEN DROPPED BY A DROP COMMAND.

2.4.2.3 EFFECT OF RESTART COMMAND -

THE RESTART COMMAND DIFFERS FROM THE START COMMAND IN THAT THE P-TABLES FROM THE PREVIOUS START COMMAND (THERE MUST HAVE BEEN ONE) ARE USED, INSTEAD OF NEW ONES BEING BUILT. THE UNITS SWITCH SHOULD NOT BE USED WITH THIS PROGRAM. THE SOFTWARE DIALOGUE MAY OPTIONALLY BE REEXECUTED (OPERATOR WILL BE ASKED). THE COMMAND CAN BE USED AFTER COMMAND MODE HAS BEEN REENTERED IN ANY OF THE THREE NORMAL WAYS: A) THE REQUESTED NUMBER OF PASSES HAVE BEEN MADE, B) AN ERROR WAS ENCOUNTERED WITH THE HALT ON ERROR FLAG SET, OR C) A CONTROL/C WAS ENTERED BY THE OPERATOR.

2.4.3 CONTINUE COMMAND -

CON(TINUE)/PASS:<PASS-CNT>/FLAGS:<FLAG-LIST>

2.4.3.1 FLAG SWITCH (/FLAGS:<FLAG-LIST>) -

<FLAG-LIST> IS SAME AS IN THE START COMMAND, BUT UNSPECIFIED FLAGS RETAIN THEIR CURRENT VALUE.

2.4.3.2 EFFECT OF CONTINUE COMMAND

CONTINUE MUST FOLLOW A START OR RESTART, AND COMMAND MODE MUST HAVE BEEN ENTERED DUE TO A HALT ON ERROR OR A CONTROL/C. THE EFFECT OF THE COMMAND IS TO GO TO THE BEGINNING OF THE TEST THAT WAS BEING EXECUTED WHEN THE HALT OR CONTROL/C TOOK PLACE. SOFTWARE DIALOGUE MAY OPTIONALLY BE REEXECUTED. HARDWARE PARAMETERS MAY NOT BE CHANGED.

2.4.4 PROCEED COMMAND

PRO(CEED)/FLAGS:<FLAG-LIST>

2.4.4.1 FLAGS SWITCH (/FLAGS:<FLAG-LIST>) -

<FLAG-LIST> IS AS IN THE START COMMAND, BUT UNSPECIFIED FLAGS RETAIN THEIR CURRENT VALUE.

2.4.4.2 EFFECT OF PROCEED COMMAND -

PROCEED MUST FOLLOW A START, RESTART, OR CONTINUE. COMMAND MODE MUST HAVE BEEN ENTERED VIA A HALT ON ERROR. THE EFFECT OF THE COMMAND IS TO BEGIN EXECUTION AT THE LOCATION FOLLOWING THE ERROR CALL. NEITHER HARDWARE NOR SOFTWARE PARAMETERS MAY BE ALTERED.

2.4.5 ADD COMMAND -

ADD/UNITS:<UNIT-LIST>

2.4.6 EFFECT OF ADD COMMAND -

THE UNITS SPECIFIED ARE ADDED TO THE TEST SEQUENCE. EACH UNIT MUST HAVE A P-TABLE IN MEMORY DUE TO AN EARLIER HARDWARE DIALOGUE. THIS COMMAND MUST BE FOLLOWED BY A RESTART OR CONTINUE. THE UNITS SWITCH MUST BE SPECIFIED. THE ADD COMMAND IS MEANINGFUL ONLY FOR UNITS THAT WERE PREVIOUSLY DROPPED.

2.4.7 DROP COMMAND -

DRO(P)/UNITS:<UNIT LIST>

2.4.8 EFFECT OF DROP COMMAND
THE UNITS SPECIFIED WILL BE DROPPED FROM TESTING. THE UNITS
WILL BE RESELECTED ONLY BY THE EXECUTION OF AN ADD OR START
COMMAND. THE UNITS SWITCH MUST BE ENTERED. THIS COMMAND
MUST BE FOLLOWED BY A RESTART OR A CONTINUE COMMAND.

2.4.9 PRINT COMMAND

PRI(NT)

2.4.9.1 EFFECT OF PRINT COMMAND -
THE TOTAL NUMBER OF ERRORS FOR EACH UNIT SINCE THE LAST
START OR RESTART COMMAND ARE PRINTED. THE ISR (INHIBIT
STATISTICAL REPORTING) FLAG IS CLEARED.

2.4.10 DISPLAY COMMAND -

DIS(PLAY)/UNITS:<UNIT-LIST>

2.4.10.1 EFFECT OF DISPLAY COMMAND -
THE HARDWARE P-TABLE FOR THE TEST STATION IS PRINTED IN THE
FORMAT IN WHICH IT WAS ENTERED.

2.4.11 FLAGS COMMAND -

FLA(GS)

2.4.11.1 EFFECT OF FLAGS COMMAND -
THE CURRENT SETTINGS OF ALL FLAGS ARE PRINTED.

2.4.12 ZFLAGS COMMAND -

ZFL(AGS)

2.4.13 ZFLAGS COMMAND -

ALL FLAGS ARE CLEARED.

2.4.14 CONTROL CHARACTERS -

- C A CONTROL/C (C) ENTERED DURING THE EXECUTION OF A DIAGNOSTIC CAUSES A RETURN TO COMMAND MODE.
- Z A CONTROL/Z (Z) ENTERED DURING ONE OF THE TWO OPERATOR DIALOGUES-- HARDWARE P-TABLE DIALOGUE OR SOFTWARE P-TABLE DIALOGUE CAUSES THE DEFAULTS TO BE TAKEN FOR THE REMAINDER OF THAT DIALOGUE.
- O A CONTROL/O (O) ENTERED DURING THE EXECUTION OF A DIAGNOSTIC CAUSES ALL TELETYPE OUTPUT TO BE SURPRESSED FOR THE REMAINDER OF THE DIAGNOSTIC OR UNTIL ANOTHER CONTROL/O IS TYPED, WHICH RESTORES NORMAL TELETYPE OUTPUT.

2.5 HARDWARE QUESTIONS

WHEN A DIAGNOSTIC IS STARTED, THE RUNTIME SERVICES WILL PROMPT THE USER FOR HARDWARE INFORMATION BY TYPING "CHANGE HW (L) ?" YOU MUST ANSWER "Y" AFTER A START COMMAND UNLESS THE HARDWARE INFORMATION HAS BEEN "PRELOADED" USING THE SETUP UTILITY (SEE CHAPTER 6 OF THE XXDP. USER'S MANUAL). WHEN YOU ANSWER THIS QUESTION WITH A "Y", THE RUNTIME SERVICES WILL ASK FOR THE NUMBER OF UNITS (IN DECIMAL). YOU WILL THEN BE ASKED THE FOLLOWING QUESTIONS FOR EACH UNIT.

1. CSR ADDRESS - THIS QUESTION REQUESTS THE CSR ADDRESS OF THE SPECIFIED DMU-11. THE DEFAULT ANSWER FOR THIS QUESTION IS ADDRESS 160460 (OCTAL).
2. INTERRUPT VECTOR ADDRESS - THIS QUESTION REQUESTS THE INTERRUPT VECTOR ADDRESS OF THE SPECIFIED DMU-11. THE DEFAULT ANSWER IS 310 (OCTAL).
3. ACTIVE LINES BIT MAP - THIS QUESTION REQUESTS AN OCTAL BIT MAP OF THE SERIAL COMMUNICATION LINES ON THE DMU11 WHICH ARE BEING SELECTED FOR TESTING. IF THE BIT IN THE BIT MAP IS SET WHICH CORRESPONDS TO A PARTICULAR LINE (I.E. BIT 5 FOR LINE 5) THAT LINE WILL BE TESTED BY THE FVT.
4. TYPE OF LOOPBACK (1=INTERNAL, 2=H3029 OR H3277) - THIS QUESTION REQUESTS THE TYPE OF LOOPBACK TO BE USED WHEN TESTING THE DMU-11. THE FOLLOWING TYPES ARE SUPPORTED:
 - 0 INTERNAL - ONLY INTERNAL UART LOOPBACK IS TO BE USED IN TESTING THE DMU-11.
 - 0 H3029 OR H3277 - STAGGERED LOOPBACK CONNECTORS ARE PROVIDED ON THE DMU11 DISTRIBUTION PANEL (H3029) IF THIS DISTRIBUTION PANEL IS NOT PRESENT THEN H3277 STAGGERED BERG CONNECTOR(S) MUST BE INSTALLED ON THE BERG CONNECTOR SOCKETS OF THE DMU11.
 - 0 H325 - SINGLE LINE, 25 PIN LOOPBACK CONNECTORS (TYPE H325) ARE INSTALLED ON THE LINES TO BE TESTED.

2.6 SOFTWARE QUESTIONS

AFTER YOU HAVE ANSWERED THE HARDWARE QUESTIONS OR AFTER A RESTART OR CONTINUE COMMAND, THE RUNTIME SERVICES WILL ASK FOR SOFTWARE PARAMETERS. THESE PARAMETERS WILL GOVERN SOME DIAGNOSTIC SPECIFIC OPERATION MODES. YOU WILL BE PROMPTED BY "CHANGE SW (L) ?" IF YOU WISH TO CHANGE ANY PARAMETERS, ANSWER BY TYPING "Y". THE SOFTWARE QUESTIONS AND THE DEFAULT VALUES ARE DESCRIBED IN THE NEXT PARAGRAPH(S).

1. REPORT UNIT NUMBER AS EACH UNIT IS TESTED - THIS QUESTION ASKS WHETHER THE PROGRAM SHOULD REPORT THE NUMBER OF THE UNIT WHICH IT IS TESTING AS IT BEGINS TO TEST THAT UNIT.
2. EXTENDED ERROR REPORTING - THIS QUESTION ASKS WHETHER EXTENDED ERROR INFORMATION IS REQUIRED OTHER THAN THE "TEST FAILED" MESSAGE, ON EACH ERROR REPORTED. THE DEFAULT IS "NO" I.E. ONLY A MESSAGE REPORTING THE FACT THAT THE TEST FAILED WILL BE PRINTED.
3. NUMBER OF INDIVIDUAL DATA ERRORS TO REPORT ON A LINE - THIS QUESTION IS ASKED ONLY IF THE PREVIOUS QUESTION WAS ANSWERED "YES". THE QUESTION ASKS FOR THE NUMBER OF DATA ERRORS WHICH SHOULD BE REPORTED INDIVIDUALLY BY THIS PROGRAM FOR EACH LINE FOR EACH TRANSMISSION TEST. ERRORS WHICH ARE NOT REPORTED INDIVIDUALLY ARE REPORTED IN SUMMARY ERROR REPORTS.

2.7 EXTENDED P-TABLE DIALOGUE

WHEN YOU ANSWER THE HARDWARE QUESTIONS, YOU ARE BUILDING ENTRIES IN A TABLE THAT DESCRIBES THE DEVICES UNDER TEST. THE SIMPLEST WAY TO BUILD THIS TABLE IS TO ANSWER ALL QUESTIONS FOR EACH UNIT TO BE TESTED. IF YOU HAVE A MULTIPLEXED DEVICE SUCH AS A MASS STORAGE CONTROLLER WITH SEVERAL DRIVES OR A COMMUNICATION DEVICE WITH SEVERAL LINES, THIS BECOMES TEDIOUS SINCE MOST OF THE ANSWERS ARE REPETITIOUS.

TO ILLUSTRATE A MORE EFFICIENT METHOD, SUPPOSE YOU ARE TESTING A FICTIONAL DEVICE, THE XY11. SUPPOSE THIS DEVICE CONSISTS OF A CONTROL MODULE WITH EIGHT UNITS (SUB-DEVICES) ATTACHED TO IT. THESE UNITS ARE DESCRIBED BY THE OCTAL NUMBERS 0 THROUGH 7. THERE IS ONE HARDWARE PARAMETER THAT CAN VARY AMONG UNITS CALLED THE Q-FACTOR. THIS Q-FACTOR MAY BE 0 OR 1. BELOW IS A SIMPLE WAY TO BUILD A TABLE FOR ONE XY11 WITH EIGHT UNITS.

* UNITS (0) ? 8<CR>

UNIT 1

CSR ADDRESS (0) ? 160000<CR>

SUB-DEVICE # (0) ? 0<CR>

Q-FACTOR (0) 0 ? 1<CR>

UNIT 2

CSR ADDRESS (0) ? 160000<CR>

SUB-DEVICE # (0) ? 1<CR>

Q FACTOR (0) 1 ? 0<CR>

UNIT 3

CSR ADDRESS (0) ? 160000<CR>

SUB-DEVICE # (0) ? 2<CR>

Q-FACTOR (0) 0 ? <CR>

UNIT 4

CSR ADDRESS (0) ? 160000<CR>

SUB-DEVICE # (0) ? 3<CR>

Q-FACTOR (0) 0 ? <CR>

UNIT 5

CSR ADDRESS (0) ? 160000<CR>

SUB-DEVICE # (0) ? 4<CR>

Q-FACTOR (0) 0 ? <CR>

UNIT 6

CSR ADDRESS (0) ? 160000<CR>

SUB-DEVICE # (0) ? 5<CR>

Q-FACTOR (0) 0 ? <CR>

UNIT 7

CSR ADDRESS (0) ? 160000<CR>

SUB-DEVICE # (0) ? 6<CR>

Q FACTOR (0) 0 ? 1<CR>

```
UNIT 8
CSR ADDRESS (0) 160000<CR>
SUB-DEVICE # (0) ? 7<CR>
Q-FACTOR (0) 1 ? <CR>
```

NOTICE THAT THE DEFAULT VALUE FOR THE Q-FACTOR CHANGES WHEN A NON-DEFAULT RESPONSE IS GIVEN. BE CAREFUL WHEN SPECIFYING MULTIPLE UNITS!

AS YOU CAN SEE FROM THE ABOVE EXAMPLE, THE HARDWARE PARAMETERS DO NOT VARY SIGNIFICANTLY FROM UNIT TO UNIT. THE PROCEDURE SHOWN IS NOT VERY EFFICIENT.

THE RUNTIME SERVICES CAN TAKE MULTIPLE UNIT SPECIFICATIONS HOWEVER. LET'S BUILD THE SAME TABLE USING THE MULTIPLE SPECIFICATION FEATURE.

```
# UNITS (0) ? 8<CR>
```

```
UNIT 1
CSR ADDRESS (0) ? 160000<CR>
SUB-DEVICE # (0) ? 0,1<CR>
Q-FACTOR (0) 0 ? 1,0<CR>
```

```
UNIT 3
CSR ADDRESS (0) ? 160000<CR>
SUB-DEVICE # (0) ? 2-5<CR>
Q-FACTOR (0) 0 ? 0<CR>
```

```
UNIT 7
CSR ADDRESS (0) ? 160000<CR>
SUB-DEVICE # (0) ? 6,7<CR>
Q-FACTOR (0) 0 ? 1<CR>
```

AS YOU CAN SEE IN THE ABOVE DIALOGUE, THE RUNTIME SERVICES WILL BUILD AS MANY ENTRIES AS IT CAN WITH THE INFORMATION GIVEN IN ANY ONE PASS THROUGH THE QUESTIONS. IN THE FIRST PASS, TWO ENTRIES ARE BUILT SINCE TWO SUB-DEVICES AND Q-FACTORS WERE SPECIFIED. THE SERVICES ASSUME THAT THE CSR ADDRESS IS 160000 FOR BOTH SINCE IT WAS SPECIFIED ONLY ONCE. IN THE SECOND PASS, FOUR ENTRIES WERE BUILT. THIS IS BECAUSE FOUR SUB-DEVICES WERE SPECIFIED. THE "-" CONSTRUCT TELLS THE RUNTIME SERVICES TO INCREMENT THE DATA FROM THE FIRST NUMBER TO THE SECOND. IN THIS CASE, SUB-DEVICES 2, 3, 4 AND 5 WERE SPECIFIED. (IF THE SUB-DEVICE WERE SPECIFIED BY ADDRESSES, THE INCREMENT WOULD BE BY 2 SINCE ADDRESSES MUST BE ON AN EVEN BOUNDARY.) THE CSR ADDRESSES AND Q-FACTORS FOR THE FOUR ENTRIES ARE ASSUMED TO BE 160000 AND 0 RESPECTIVELY SINCE THEY WERE ONLY SPECIFIED ONCE. THE LAST TWO UNITS ARE SPECIFIED IN THE THIRD PASS.

THE WHOLE PROCESS COULD HAVE BEEN ACCOMPLISHED IN ONE PASS AS SHOWN BELOW.

```
# UNITS (0) ? 8<CR>
```

```
UNIT 1
```

CSR ADDRESS (0) ? 160000<CR>
SUB-DEVICE # (0) ? 0 7<CR>
Q-FACTOR (0) 0 ? 0.1,0....1.1<CR>

AS YOU CAN SEE FROM THIS EXAMPLE, NULL REPLIES (COMMAS ENCLOSING
A NULL FIELD) TELL THE RUNTIME SERVICES TO REPEAT THE LAST REPLY.

2.8 QUICK START-UP PROCEDURE (XXDP.)

TO START UP THIS PROGRAM:

1. BOOT XXDP.
2. GIVE THE DATE AND ANSWER THE LSI/UNIBUS AND 50HZ (IF THERE IS A CLOCK) QUESTIONS. NOTE, NOT ALL VERSIONS OF XXDP. ASK FOR THE CLOCK FREQUENCY
3. TYPE "R NAME", WHERE NAME IS THE NAME OF THE BIN OR BIC FILE FOR THIS PROGRAM
4. TYPE "START"
5. ANSWER THE "CHANGE HW" QUESTION WITH "Y"
6. ANSWER ALL THE HARDWARE QUESTIONS
7. ANSWER THE "CHANGE SW" QUESTION WITH "N"

WHEN YOU FOLLOW THIS PROCEDURE YOU WILL BE USING ONLY THE
DEFAULTS FOR FLAGS AND SOFTWARE PARAMETERS. FOR DEFAULT INFORMATION
SEE THE SECTIONS WITHIN THIS DOCUMENT ON FLAGS, AND HARDWARE QUESTIONS.

3.0 ERROR INFORMATION

3.1 TYPES OF ERROR MESSAGES

THERE ARE THREE LEVELS OF ERROR MESSAGES THAT MAY BE ISSUED BY A DIAGNOSTIC: GENERAL, BASIC AND EXTENDED. GENERAL ERROR MESSAGES ARE ALWAYS PRINTED UNLESS THE "IER" FLAG IS SET (SEE THE FLAGS SECTION OF THIS DOCUMENT).

THE GENERAL ERROR MESSAGE IS OF THE FORM:

NAME TYPE NUMBER ON UNIT NUMBER TST NUMBER PC:XXXXXX
ERROR MESSAGE

WHERE: NAME = DIAGNOSTIC NAME
TYPE = ERROR TYPE (SYS FATAL, DEV FATAL, HARD OR SOFT)
NUMBER = ERROR NUMBER
UNIT NUMBER = 0 - N (N IS LAST UNIT IN PTABLE)
TST NUMBER = TEST AND SUBTEST WHERE ERROR OCCURRED
PC:XXXXXX = ADDRESS OF ERROR MESSAGE CALL

BASIC ERROR MESSAGES ARE MESSAGES THAT CONTAIN SOME ADDITIONAL INFORMATION ABOUT THE ERROR. THESE ARE ALWAYS PRINTED UNLESS THE "IER" OR "IBR" FLAGS ARE SET (SEE THE FLAGS SECTION OF THIS DOCUMENT). THESE MESSAGES ARE PRINTED AFTER THE ASSOCIATED GENERAL MESSAGE.

EXTENDED ERROR MESSAGES CONTAIN SUPPLEMENTARY ERROR INFORMATION SUCH AS REGISTER CONTENTS OR GOOD/BAD DATA. THESE ARE ALWAYS PRINTED UNLESS THE "IER", "IBR" OR "IXR" FLAGS ARE SET (SEE THE FLAGS SECTION OF THIS DOCUMENT). THESE MESSAGES ARE PRINTED AFTER THE ASSOCIATED GENERAL ERROR MESSAGE AND ANY ASSOCIATED BASIC ERROR MESSAGES.

3.2 SPECIFIC ERROR MESSAGES

THIS PROGRAM IS INTENDED TO PROVIDE A GO/NOGO INDICATION OF THE FUNCTIONALITY OF THE DMU-11 BOARDS. TO EXECUTE THE PROGRAM IN THIS MODE THE OPERATOR NEED ONLY ANSWER THE "EXTENDED ERROR REPORTING" SOFTWARE QUESTION WITH "NO". THE PROGRAM WILL THEN ONLY PRINT THE NAME OF THE FAILING TEST THE TEST AND ERROR NUMBERS. FOR A LIST OF THE TEST NAMES IN THIS PROGRAM SEE THE TEST SUMMARIES SECTION OF THIS DOCUMENT. AN EXAMPLE OF SUCH A AN ERROR MESSAGE IS THE FOLLOWING:

```
CZDHV DVC FTL ERR 04106 ON UNIT 00 TST 003 SUB 000 PC: XXXXXX  
DMA_ABORT BIT TEST FAILED
```

THIS ERROR INDICATES THAT A FATAL ERROR WAS ENCOUNTERED DURING THE TEST WHICH TESTS THE DMA_ABORT BIT.

IF THE OPERATOR HAD REQUESTED EXTENDED ERROR REPORTING THE SAME ERROR WOULD BE REPORTED AS FOLLOWS:

```
CZDHV DVC FTL ERR 04106 ON UNIT 00 TST 003 SUB C00 PC: XXXXXX  
DMA_ABORT BIT TEST FAILED  
DMA_START BIT FOUND SET AFTER DMA ABORTED ON LINE: 8
```

4.0 PERFORMANCE AND PROGRESS REPORTS

AT THE END OF EACH PASS, THE PASS COUNT IS GIVEN ALONG WITH THE TOTAL NUMBER OF ERRORS REPORTED SINCE THE DIAGNOSTIC WAS STARTED. THE "EOP" SWITCH CAN BE USED TO CONTROL HOW OFTEN THE END OF PASS MESSAGE IS PRINTED. FOR FUTHER INFORMATION SEE THE SWITCHES SECTION OF THIS DOCUMENT.

5.0 TEST SUMMARIES

THE FOLLOWING ARE INCLUDED WITHIN CZDHVB:

1. DEVICE REGISTER ACCESS TEST - VERIFIES THAT THE UUT REGISTERS WILL RESPOND WITH THE CORRECT UNIBUS HANDSHAKING SIGNALS. VERIFIES THAT THE UUT IS AT THE CORRECT ADDRESS.
2. DMA.START TEST - VERIFIES THAT EACH DMA START BIT WILL INITIATE A DMA TRANSMISSION ON A LINE
3. DMA.ABORT TEST - VERIFIES THAT EACH DMA ABORT BIT WILL STOP A DMA TRANSMISSION, RETURN A TX.ACTION AND SUCCESSFULLY RESTART THE DMA.
4. DMA.ERROR TEST - VERIFIES THAT THE DMA ERROR BIT IN THE CSR REPORTS DMA ERRORS CORRECTLY WHEN THEY OCCUR.
5. O.AUTO INACTIVE TEST - VERIFIES THAT THE DUT WILL NOT RESPOND TO INCOMING XON AND XOFF CHARACTERS WHEN O.AUTO IS CLEAR.
6. O.AUTO ACTIVE TEST - VERIFIES THAT THE DUT RESPONDS CORRECTLY TO INCOMING FLOW CONTROL CHARACTERS WHEN ACTIVE
7. I.AUTO INACTIVE TEST - VERIFIES THAT THE DUT WILL NOT GENERATE XON AND XOFF CHARACTERS IN RESPONSE TO THE APPROPRIATE FIFO CONDITIONS WHEN I.AUTO IS INACTIVE.
8. I.AUTO ACTIVE TEST - VERIFIES THAT THE DUT WILL GENERATE XON AND XOFF CHARACTERS IN RESPONSE TO THE APPROPRIATE FIFO CONDITIONS WHEN I.AUTO IS ACTIVE.
9. FIFO DATA TEST - VERIFIES THAT THE FIFO WILL HOLD 256 CHARACTERS WITHOUT CORRUPTING DATA.
10. FIFO 3/4 LEVEL INACTIVE TEST - VERIFIES THAT THE 3/4 LEVEL ALARM DOES NOT BECOME ACTIVE BELOW THE 3/4 LEVEL.
11. FIFO 3/4 LEVEL ACTIVE TEST - VERIFIES THAT THE 3/4 LEVEL ALARM BECOMES ACTIVE WHEN THE FIFO IS 3/4 FULL.
12. FIFO 3/4 LEVEL ACTIVE/INACTIVE TEST - VERIFIES THAT THE 3/4 LEVEL ALARM, ONCE ACTIVATED, REMAINS ACTIVE UNTIL THE FIFO IS REDUCED BELOW THE 1/2 LEVEL.
13. FIFO 1/2 LEVEL TEST - VERIFIES THAT THE FIFO 1/2 LEVEL ALARM SYSTEM BECOMES ACTIVE AND INACTIVE AT THE CORRECT LEVELS.
14. RXTIMER TEST - VERIFIES THAT THE HOLD OFF TIMER FOR RX INTERRUPTS IS OPERATING CORRECTLY, AND THAT THE 3/4 FULL LEVEL OVERRIDES THE TIMER.

15. TX ACTION FIFO TEST - VERIFIES THAT THE TX ACTION FIFO CAN HOLD 16 UNIQUE TX-ACTIONS, AND THAT ONLY ONE TX INTERRUPT OCCURS FOR ALL 16 TX-ACTIONS.
16. TX FIFO TEST - VERIFIES THAT THE FIFO WILL 64 UNIQUE CHARACTERS AND ALSO THAT ONLY ONE INTERRUPT OCCURS FOR ALL 64 CHARACTERS.
17. BREAK GENERATION TEST - VERIFIES THAT ALL SERIAL TRANSMIT LINES CAN GENERATE A BREAK BY SETTING THE BRK BIT IN THE ASSOCIATED LNCTRL REGISTER.
18. NO OVERRUN ERROR TEST - VERIFIES THAT THE DUT WILL NOT REPORT DATA OVERRUN ERRORS WHEN THEY DO NOT OCCUR.
19. OVERRUN ERROR TEST - VERIFIES THAT THE DUT WILL REPORT DATA OVERRUN ERRORS WHEN THEY OCCUR.
20. REPORT BMP CODES TEST - THIS PSEUDO TEST REPORTS THE FIRST 32 CHARACTERS WHICH WERE DISCOVERED IN THE FIFO DURING THE EXECUTION OF THE OTHER TESTS. THIS AVOIDS INTERRUPTION OF THE OTHER TESTS BY THESE CODES IF THEY ARE NOT CRITICAL TO THE PERFORMANCE OF THE TESTS.

6.0 EXAMPLE ERROR FREE PASS

THE FOLLOWING IS AN EXAMPLE OF AN ERROR FREE PASS DIALOGUE:

```
.R CZDHSV0
CZDHSV0.BIN
DRS
CZDHSV-B-0
DHU-11 FUNC TST PART2
UNIT IS DHU-11
RESTRT ADDR: 147670
DR>STA/PAS:1

CHANGE HW (L) ? Y

# UNITS (D) ? 2

UNIT 0
CSR ADDRESS: (0) 160460 ? +Z

UNIT 1
CSR ADDRESS: (0) 160460 ? 160500
INTERRUPT VECTOR ADDRESS: (0) 310 ? 320
ACTIVE LINE BIT MAP: (0) 177777 ? <CR>
TYPE OF LOOPBACK (1=INTERNAL, 2=H3029 OR H3277): (0) 2 ? 1

CHANGE SW (L) ? Y

REPORT UNIT NUMBER AS EACH UNIT IS TESTED: (L) Y ? <CR>
EXTENDED ERROR REPORTING: (L) N ? <CR>

TESTING UNIT : 0

TESTING UNIT : 1

CZDHSV EOP      1
  0 TOTAL ERRS

DR>
```

```

1050          .LIST SEQ,LOC,RIN,MEB
1051          .NLIST CND
1059
1060
1061          .SBTTL PROGRAM HEADER
1062
1063
1064          .MCALL SVC
1065 000000    SVC                                ; INITIALIZE SUPERVISOR MACROS
1066
1067          ;*****
1068          ; IF STRUCTURED MACROS ARE TO BE USED, ADD ".MCALL STRUCT" AND "STRUCT"
1069          ; TO INITIALIZE THE STRUCTURED MACROS.
1070
1071          000001 SVCINS= 1          ; LIST INSTRUCTIONS, SHIFTED RIGHT
1072          000001 SVCTST= 1         ; LIST TEST TAGS, SHIFTED RIGHT
1073          000001 SVCSUB= 1        ; LIST SUBTEST TAGS, SHIFTED RIGHT
1074          000001 SVCGBL= 1       ; LIST GLOBAL TAGS, SHIFTED RIGHT
1075          000001 SVCTAG= 1       ; LIST OTHER TAGS, SHIFTED RIGHT
1076
1077          ; CHANGE THE VALUES OF THE SVC... SYMBOLS TO BE ZERO IF YOU WISH
1078          ; TO ALIGN THE MACRO CALLS AND THEIR EXPANSIONS. CHANGE THE
1079          ; SYMBOLS TO BE MINUS-ONE TO NOT LIST THE EXPANSIONS. YOU MAY
1080          ; CHANGE THE SYMBOLS AT ANY POINT IN YOUR PROGRAM.
1081          ;*****
1082
1083 000000    .ENABL ABS
1084          ;.ENABL AMA
1085          "          2000
1086
1087 002000    BGNMOD
1088
1089          ;**
1090          ; THE PROGRAM HEADER IS THE INTERFACE BETWEEN
1091          ; THE DIAGNOSTIC PROGRAM AND THE SUPERVISOR.
1092          ;--
1093
1094 002000    POINTER BGNRPT,BGNSW,BGNSFT,BGNDU,ERRTBL
1095
1112
1113 002000    HEADER CZDHY.B.0.22.0,PRI07
1114
1115          L$NAME::
1116          .ASCII /C/
1117          .ASCII /Z/
1118          .ASCII /D/
1119          .ASCII /M/
1120          .ASCII /V/
1121          .BYTE 0
1122          .BYTE 0
1123          .BYTE 0
1124
1125          L$REV::
1126          .ASCII /B/
1127
1128          L$DEPO::
1129          .ASCII /0/
1130
1131          L$UNIT::
1132          .WORD 0
1133
1134          L$TIML::

```

002014 000022
 002016
 002016 035156
 002020
 002020 035404
 002022
 002022 002176
 002024
 002024 002210
 002026
 002026 035706
 002030
 002030 000C00
 002032
 002032 000000
 002034
 002034 000000
 002036
 002036 000000
 002040
 002040 002124
 002042
 002042 000340
 002044
 002044 000000
 002046
 002046 000000
 002050
 002050 003
 002051 003
 002052
 002052 000000
 002054 000000
 002056
 002056 000000
 002060
 002060 004120
 002062
 002062 020030
 002064
 002064 000000
 002066
 002066 000000
 002070
 002070 000000
 002072
 002072 020704
 002074
 002074 000000
 002076
 002076 004130
 002100
 002100 104035
 002102
 002102 004050
 002104
 002104 020044

L\$MPCP:: .WORD 22
 L\$SPCP:: .WORD L\$HARD
 L\$MPTP:: .WORD I \$SOFT
 L\$SPTP:: .WORD L\$HW
 L\$LADP:: .WORD L\$SW
 L\$STA:: .WORD L\$LAST
 L\$CO:: .WORD 0
 L\$DTYP:: .WORD 0
 L\$APT:: .WORD 0
 L\$DTP:: .WORD 0
 L\$PRIO:: .WORD L\$DISPATCH
 L\$ENVI:: .WORD PRI07
 L\$EXP1:: .WORD 0
 L\$MREV:: .WORD 0
 .BYTE C\$REVISION
 .BYTE C\$EDIT
 L\$EF:: .WORD 0
 .WORD 0
 L\$SPC:: .WORD 0
 L\$DEVP:: .WORD L\$DVTYP
 L\$REPP:: .WORD L\$RPT
 L\$EXP4:: .WORD 0
 L\$EXP5:: .WORD 0
 L\$AUT:: .WORD 0
 L\$DUT:: .WORD L\$DU
 L\$LUN:: .WORD 0
 L\$DESP:: .WORD L\$DESC
 L\$LOAD:: .WORD L\$LOAD
 L\$ETP:: .WORD L\$ERRTBL
 L\$ICP:: .WORD L\$INIT

002106
 002106 020666
 002110
 002110 020664
 002112
 002112 020036
 002114
 002114 000000
 002116
 002116 000000
 002120
 002120 000000

1114

L\$CCP::
 L\$ACP:: .WORD L\$CLEAN
 L\$PRT:: .WORD L\$AUTO
 L\$TEST:: .WORD L\$PROT
 L\$DLY:: .WORD 0
 L\$HIME:: .WORD 0

1126
1127
1128
1129
1130
1131
1132
1133

.SBTTL DISPATCH TABLE

; THE DISPATCH TABLE CONTAINS THE STARTING ADDRESS OF EACH TEST.
; IT IS USED BY THE SUPERVISOR TO DISPATCH TO EACH TEST.
*-

DISPATCH 20

002122
002122 000024
002124
002124 021022
002126 021304
002130 021710
002132 022346
002134 022674
002136 023474
002140 024274
002142 024716
002144 025410
002146 025716
002150 026226
002152 026726
002154 027424
002156 030102
002160 031152
002162 031740
002164 032766
002166 033412
002170 034130
002172 035074
1134

.WORD 20
L\$DISPATCH::
.WORD T1
.WORD T2
.WORD T3
.WORD T4
.WORD T5
.WORD T6
.WORD T7
.WORD T8
.WORD T9
.WORD T10
.WORD T11
.WORD T12
.WORD T13
.WORD T14
.WORD T15
.WORD T16
.WORD T17
.WORD T18
.WORD T19
.WORD T20

1149
1150
1151
1152
1153
1154
1155
1156
1157
1158
1159

.SBTTL DEFAULT HARDWARE P TABLE

```

; **
; THE DEFAULT HARDWARE P-TABLE CONTAINS DEFAULT VALUES OF
; THE TEST-DEVICE PARAMETERS. THE STRUCTURE OF THIS TABLE
; IS IDENTICAL TO THE STRUCTURE OF THE HARDWARE P TABLES.
; AND IS USED AS A "TEMPLATE" FOR BUILDING THE P-TABLES.
; -
    
```

1160 002174
002174 000004
002176
002176

BGNHW DFPTBL

.WORD L10000 L\$HW/2
L\$HW::
DFPTBL::

1161
1162 002176 160460
1163 002200 000310
1164 002202 177777
1165 002204 002
1166
1167 002206
002206

```

.WORD 160460 ;DEFAULT CSR ADDRESS
.WORD 310 ;DEFAULT VECTOR ADDRESS
.WORD 177777 ;DEFAULT ACTIVE LINES BIT MAP
.BYTE 2 ;DEFAULT LOOPBACK MODE
.EVEN
ENDHW
    
```

L10000:

1176
 1177
 1178
 1179
 1180
 1181
 1182
 1183
 1184
 1185
 1186
 1187
 1188
 1189
 1190
 1191
 1192

002206
 002206 000002
 002210
 002210
 002210
 000020
 000000
 002214
 002214

.SBTTL SOFTWARE P TABLE

```

; **
; THE SOFTWARE TABLE CONTAINS VARIOUS DATA USED BY THE
; PROGRAM AS OPERATIONAL PARAMETERS. THESE PARAMETERS ARE
; SET UP AT ASSEMBLY TIME AND MAY BE VARIED BY THE OPERATOR
; AT RUN TIME.
; --
    
```

BGNSW SFPTBL

.WORD L10001-L\$SW/2
 L\$SW::
 SFPTBL::

OPTION:: .WORD 20
 NDERPT:: .WORD 0

;BIT MAP OF PROGRAM CONTROL FLAGS
 ;DEFAULT NUMBER OF INDIVIDUAL DATA ERPORS TO RPT.

ENDSW

L10001:

1201
 1202
 1203
 1213
 1214
 1215
 1216
 1217
 1218
 1219
 1220
 1221
 1222
 1223
 1224
 1225
 1226
 1227
 1228
 1229
 1230
 1231
 1232
 1233
 1234
 1235
 1236
 1237
 1238
 1239
 1240
 1241
 1256 002214

.SBTTL GLOBAL EQUATES SECTION

```

; **
; THE GLOBAL EQUATES SECTION CONTAINS PROGRAM EQUATES THAT
; ARE USED IN MORE THAN ONE TEST.
; --
    
```

```

000020          NUMLNS==20      ;NUMBER OF LINES ON DMU11 IS 8.
177777          MAPLNS==177777 ;BIT MAP OF LINES ON DMU11.

;***** DEVICE REGISTER OFFSETS FROM THE CSR'S ADDRESS *****
000000          CSRO==0        ;CSR REGISTER OFFSET FROM THE CSR ADDRESS
000002          RBUFO==2       ;RECEIVE REGISTER OFFSET FROM THE CSR ADDRESS
000002          RXTIMO==2      ;RECIEVE TIMER REGISTER OFFSET FROM THE CSR ADDRESS
000004          LPRO==4        ;LINE PARAMETER REGISTER OFFSET FROM THE CSR ADDRESS
000006          FLSO==6        ;FIFOSIZE/STATUS REGISTER OFFSET FROM THE CSR ADDRESS
000006          FDATO==6       ;FIFODATA REGISTER OFFSET FROM THE CSR ADDRESS
000010          LNCTRO==10     ;LINE CONTROL REGISTER OFFSET FROM THE CSR ADDRESS
000012          TXAD10==12     ;TRANSMIT ADDRESS 1 REGISTER OFFSET FROM THE CSR ADDRESS
000014          TXAD20==14     ;TRANSMIT ADDRESS 2 REGISTER OFFSET FROM THE CSR ADDRESS
000016          TXBFCO==16     ;TRANSMIT COUNT REGISTER OFFSET FROM THE CSR ADDRESS

;***** EQUATES USED WITH RESPECT TO THE RX BUFFER *****
000020          RXBETX==16.    ;LEVEL OF RX BUFFER AT WHICH TO RE-ENABLE TRANSMISSION.
000030          RXBDTX==24.    ;LEVEL OF RX BUFFER AT WHICH TO DISABLE TRANSMISSION.
000100          RXBFUL==64.    ;TOTAL CHARACTER CAPACITY OF THE RX BUFFER.
    
```

EQUALS

; BIT DIFINITIONS

```

100000          BIT15== 100000
040000          BIT14== 40000
020000          BIT13== 20000
010000          BIT12== 10000
004000          BIT11== 4000
002000          BIT10== 2000
001000          BIT09== 1000
000400          BIT08== 400
000200          BIT07== 200
000100          BIT06== 100
000040          BIT05== 40
000020          BIT04== 20
000010          BIT03== 10
000004          BIT02== 4
000002          BIT01== 2
000001          BIT00== 1

001000          BIT9== BIT09
000400          BIT8== BIT08
000200          BIT7== BIT07
000100          BIT6== BIT06
    
```



```

000040          BITS== BIT05
000020          BIT4== BIT04
000010          BIT3== BIT03
000004          BIT2== BIT02
000002          BIT1== BIT01
000001          BIT0== BIT00
;
; EVENT FLAG DEFINITIONS
; EF32:EF17 RESERVED FOR SUPERVISOR TO PROGRAM COMMUNICATION
;
000040          EF.START==      32.          ; START COMMAND WAS ISSUED
000037          EF.RESTART==    31.          ; RESTART COMMAND WAS ISSUED
000036          EF.CONTINUE==   30.          ; CONTINUE COMMAND WAS ISSUED
000035          EF.NEW==        29.          ; A NEW PASS HAS BEEN STARTED
000034          EF.PWR==        28.          ; A POWER FAIL/POWER-UP OCCURRED
;
; PRIORITY LEVEL DEFINITIONS
;
000340          PRI07== 340
000300          PRI06== 300
000240          PRI05== 240
000200          PRI04== 200
000140          PRI03== 140
000100          PRI02== 100
000040          PRI01== 40
000000          PRI00== 0
;
; OPERATOR FLAG BITS
;
000004          EVL==          4
000010          LOT==         10
000020          ADR==         20
000040          IDU==         40
000100          ISR==        100
000200          UAM==        200
000400          BOE==        400
001000          PNT==       1000
002000          PRI==       2000
004000          IXE==       4000
010000          IBE==      10000
020000          IER==      20000
040000          LOE==      40000
100000          HOE==     100000

```

1266
1267
1268
1269
1270
1271
1272
1273
1274
1275
1276
1277
1278
1279 002214 000200
1280 002216 000204
1281 002220 177777
1282 002222 000
1283 002223 004
1284 002224 000000
1285
1286
1287
1288
1289 002226
1290 002226 160020
1291 002230 160022
1292 002232 160024
1293 002234 160026
1294
1295 002236 160030
1296 002240 160032
1297 002242 160034
1298 002244 160036
1299
1300
1301
1302
1303 002246 000000
1304 002250 000000
1305 002252 000000
1306 002254 000001
1307 002256 000000
1308 002260 031463
1309 002262 146314
1310 002264 000000
1311 002266 000000
1312 002270 000000
1313 002272 000000
1314 002274 000000
1315 002276 000000
1316 002300 000000
1317 002302 000000
1318
1319
1320
1321 002304 177546
1322 002306 000300

.SBTTL GLOBAL DATA SECTION

; THE GLOBAL DATA SECTION CONTAINS DATA THAT ARE USED
; IN MORE THAN ONE TEST.

; UNIT VARIABLE AREA

RXVECA:: .WORD 200 ;RX VECTOR ADDRESS.
TXVECA:: .WORD 204 ;TX VECTOR ADDRESS.
ACTLNS:: .WORD 177777 ;ACTIVE LINE BIT MAP.
LOPBCK:: .BYTE 0 ;LOOPBACK MODE
BRLEVL:: .BYTE 4 ;INTERRUPT BUS REQUEST LEVEL
UNITN:: .WORD 0 ;UNIT NUMBER.

; DEVICE REGISTER ADDRESS TABLE

DRADRT::
CSRA:: .WORD 160020 ;DMU-11 CSR ADDRESS.
RXTMA:: RBUFA:: .WORD 160022 ;DMU-11 RECIEVE BUFFER/TIMER ADDRESS.
LPRA:: .WORD 160024 ;DMU-11 LINE PARAMETER REGISTER ADDRESS.
FDATA:: FLSA:: .WORD 160026 ;DMU-11 FIFO SIZE/LINE STATUS REGISTER ADDRESS.
;AND FIFO DATA REGISTER ADDRESS.
LNCTRA:: .WORD 160030 ;DMU-11 LINE CONTROL REGISTER ADDRESS.
TXAD1A:: .WORD 160032 ;DMU-11 TRANSMIT BUFFER 1 REGISTER ADDRESS
TXAD2A:: .WORD 160034 ;DMU-11 TRANSMIT BUFFER 2 REGISTER ADDRESS
TXBFCA:: .WORD 160036 ;DMU-11 TRANSMIT BUFFER COUNT REGISTER ADDRESS

; ASSORTED GLOBAL VARIABLES:

BUFPTR:: .WORD 0 ;STORAGE FOR RECEIVE CHARACTER BUFFER POINTER.
CTRLCF:: .WORD 0 ;STORAGE FOR THE CONTROL-C FLAG.
EXOERR:: .WORD 0 ; "EXIT ON ERROR" FLAG.
TSTNUM:: .WORD 1 ;STORAGE FOR THE TEST NUMBER.
IESTAT:: .WORD 0 ;STORAGE FOR STATES OF THE OUT INT ENABLE BITS.
LGRP1M:: .WORD 31463 ;BIT MAP OF LINES IN LINE GROUP I.
LGRP2M:: .WORD 146314 ;BIT MAP OF LINES IN LINE GROUP II.
PASCNT:: .WORD 0 ;STO'G FOR PASS COUNT USED IN ROM VERSION# TST.
RXINTC:: .WORD 0 ;STORAGE FOR RECEIVER INTERRUPT FLAGS.
RXINTF:: .WORD 0 ;STORAGE FOR RECEIVER INTERRUPT FLAGS.
TXINTC:: .WORD 0 ;STORAGE FOR TRANSMIT INTERRUPT COUNT.
TXINTF:: .WORD 0 ;STORAGE FOR TRANSMIT INTERRUPT FLAGS.
TP4VEC:: .WORD 0 ;STORAGE FOR THE NORMAL 004 TRAP VECTOR.
TP4FLG:: .WORD 0 ;FLAGS SET WHEN AN EXPECTED 004 TRAP OCCURS.
WORD1:: .WORD 0 ;LOCATION FOR PASSING INDIRECT PARAMETERS.

; LINE TIME CLOCK VARIABLES AND STORAGE.

CLKCSR:: .WORD 177546 ;CSR ADDRESS OF THE LTC.
CLKBRL:: .WORD PRI06 ;INTERRUPT PRIORITY LEVEL OF THE LTC.

```

1323 002310 000100          CLKVEC:: .WORD 100      ;INTERRUPT VECTOR ADDRESS OF THE LTC.
1324 002312 000074          CLKHRZ:: .WORD 60.      ;INTERRUPT FREQUENCY OF THE LTC.
1325 002314 000000          TIMER1:: .WORD 0       ;HARDWARE CLOCK COUNTER #1.
1326 002316 000000          TIMER2:: .WORD 0       ;HARDWARE CLOCK COUNTER #2.
1327 002320 000170          TIMER3:: .WORD 120.    ;HARDWARE BREAK COUNTER LOCATION.
1328 002322 000170          BCOUNT:: .WORD 120.    ;BREAK COUNT VALUE IN CLOCK TICKS.
1329 002324 000021          MSTICK:: .WORD 17.     ;NUMBER OF MILLI-SECONDS PER LTC TICK.
1330 002326 000062          MSLCNT:: .WORD 62      ;LOOP COUNT (USED BY MSLOOP) TO DELAY 1 MS.
1331
1332
1333 ;*****
1334 ; MEMORY MANAGEMENT VARIABLES AND FLAGS.
1335 ;*****
1335 002330 177572          MMSRO:: .WORD 177572    ;ADDRESS OF MEM MGT STATUS REGISTER #0.
1336 002332 000000          MMPRES:: .WORD 0       ;MEM MGT PRESENT FLAG (0 IF MM NOT PRESENT).
1337 002334 000000          MMENAB:: .WORD 0       ;MEM MGT ENABLED FLAG (0 IF MM NOT ENABLED).
1338
1339 ;*****
1340 ; TABLE OF WORDS WITH CORRESPONDING BIT SET FOR GENERATION OF BIT MAPS.
1341 ;*****
1342 002336 000001          BITTBL:: .WORD 1        ;BIT 0 SET.
1343 002340 000002          .WORD 2              ;BIT 1 SET.
1344 002342 000004          .WORD 4              ;BIT 2 SET.
1345 002344 000010          .WORD 10             ;BIT 3 SET.
1346 002346 000020          .WORD 20             ;BIT 4 SET.
1347 002350 000040          .WORD 40             ;BIT 5 SET.
1348 002352 000100          .WORD 100            ;BIT 6 SET.
1349 002354 000200          .WORD 200            ;BIT 7 SET.
1350 002356 000400          .WORD 400            ;BIT 8 SET.
1351 002360 001000          .WORD 1000           ;BIT 9 SET.
1352 002362 002000          .WORD 2000           ;BIT 10 SET.
1353 002364 004000          .WORD 4000           ;BIT 11 SET.
1354 002366 010000          .WORD 10000          ;BIT 12 SET.
1355 002370 020000          .WORD 20000          ;BIT 13 SET.
1356 002372 040000          .WORD 40000          ;BIT 14 SET.
1357 002374 100000          .WORD 100000         ;BIT 15 SET.
1358
1359 ;*****
1360 ;* GPR SAVE AREAS ZERO AND ONE.
1361 ;*****
1362 002376
1363 002376 000000          GPRSOB:: .WORD 0          ;BASE OF GPR SAVE AREA NUMBER ZERO.
1364 002400 000000          .WORD 0              ;WORD 1. STORAGE FOR R1.
1365 002402 000000          .WORD 0              ;WORD 2. STORAGE FOR R2.
1366 002404 000000          .WORD 0              ;WORD 3. STORAGE FOR R3.
1367 002406 000000          .WORD 0              ;WORD 4. STORAGE FOR R4.
1368 .WORD 0              ;WORD 5. STORAGE FOR R5.
1369 ;*****
1370 ; STORAGE AREA FOR THE BMP CODE QUEUE.
1371 ;*****
1371 002410 000000          BMPCQP:: .WORD 0          ;POINTER USED TO ACCESS THE NEXT CELL IN QUE.
1372 002412          BMPCQB:: .BLKW 64.      ;STORAGE FOR 32 CELLS, TEST# PLUS BMP CODE.
1373 002612          BMPCQE::              ;LAST ADDRESS PLUS 2 OF THE BMP CODE QUEUE.
1374
1375 ;*****
1376 ; STORAGE AREA FOR ERROR SUMMARY TABLE AND FLAGS.
1377 ;*****
1378 002612 000000          ERSMRF:: .WORD 0          ;ERROR SUMMARY FLAGS.
1379 002614          ERCNTB:: .BLKW 16      ;TABLE OF ERROR COUNTS.
    
```

1380
1381
1382
1383
1384 002650
1385 002650
1386 003250
1387 003450
1388 003650
1389 003650
1390
1391
1392
1393
1394 003710
1395
1396
1397
1398
1399
1400
1401
1402 003750
1403 003750 000000
1404 003752 000002
1405 003754 000004
1406 003756 000006
1407 003760 000010
1408 003762 000012
1409 003764 000014
1410 003766 000016
1411 003770 000020
1412 003772 000022
1413 003774 000024
1414 003776 000026
1415 004000 000030
1416 004002 000032
1417 004004 000034
1418 004006 000036
1419 004010
1420
1421
1422
1423
1424
1425
1426 004010
1427 004010 000
1428 004011 001
1429 004012 002
1430 004013 003
1431 004014 004
1432 004015 005
1433 004016 006
1434 004017 007
1435 004020 010
1436 004021 011

```
*****
; GENERAL TABLE AND BUFFER AREA--513 WORDS.
*****
BUFBAS:: ;BASE OF MEMORY BUFFER.
ERLTBL:: .BLKW 128. ;FIRST HALF OF GENERAL TABLE OR BUFFER.
DUFMID:: .BLKW 64. ;SECOND HALF OF GENERAL TABLE OR BUFFER.
BUF3QT:: .BLKW 64. ;LAST QUARTER OF THE BUFFER AREA.
BUFEND:: ;END OF GENERAL PURPOSE MEMORY BUFFER.
ENDETB:: .BLKW 16. ;BUFFER OVERFLOW SPACE.

*****
; RECEPTION TABLE OF COUNTERS
*****
RXCNTB:: .BLKW 16. ;RECEPTION CHARACTER COUNTERS TABLE.

*****
;* TABLE FOR STORAGE OF RX/TX LINE NUMBER ASSOCIATIONS.
;* THE ASSOCIATIONS ARE STORED AS LINE NUMBER TIMES 2 FOR USE AS OFFSETS
;* WHEN ACCESSING A TABLE OF WORDS.
;* NOTE: DO NOT WRITE A NON-ZERO VALUE INTO THE UPPER BYTE OF ANY ENTRY.
*****
TXRXLB:: ;BASE OF TX/RX LINE NUMBER ASSOCIATION TABLE.
        .WORD 0 ;TX/RX LINE OFFSET FOR RX/TX LINE 0.
        .WORD 2. ;TX/RX LINE OFFSET FOR RX/TX LINE 1.
        .WORD 4. ;TX/RX LINE OFFSET FOR RX/TX LINE 2.
        .WORD 6. ;TX/RX LINE OFFSET FOR RX/TX LINE 3.
        .WORD 8. ;TX/RX LINE OFFSET FOR RX/TX LINE 4.
        .WORD 10. ;TX/RX LINE OFFSET FOR RX/TX LINE 5.
        .WORD 12. ;TX/RX LINE OFFSET FOR RX/TX LINE 6.
        .WORD 14. ;TX/RX LINE OFFSET FOR RX/TX LINE 7.
        .WORD 16. ;TX/RX LINE OFFSET FOR RX/TX LINE 8.
        .WORD 18. ;TX/RX LINE OFFSET FOR RX/TX LINE 9.
        .WORD 20. ;TX/RX LINE OFFSET FOR RX/TX LINE 10.
        .WORD 22. ;TX/RX LINE OFFSET FOR RX/TX LINE 11.
        .WORD 24. ;TX/RX LINE OFFSET FOR RX/TX LINE 12.
        .WORD 26. ;TX/RX LINE OFFSET FOR RX/TX LINE 13.
        .WORD 28. ;TX/RX LINE OFFSET FOR RX/TX LINE 14.
        .WORD 30. ;TX/RX LINE OFFSET FOR RX/TX LINE 15.
TXRXLE:: ;END OF TX/RX LINE NUMBER ASSOCIATION TABLE.
        .EVEN ;GUARANTEE THAT NEXT TABLE IS ON WORD BOUNDARY.

*****
;* TABLE FOR STORAGE OF RX/TX LINE NUMBER ASSOCIATIONS.
;* THE ASSOCIATIONS ARE STORED AS LINE NUMBERS WHICH CAN BE USED AS SUCH OR
;* AS OFFSETS WHEN ACCESSING A TABLE OF BYTES.
*****
TXRLNB:: ;BASE OF TX/RX LINE NUMBER ASSOCIATION TABLE.
        .BYTE 0 ;TX/RX LINE FOR RX/TX LINE 0.
        .BYTE 1. ;TX/RX LINE FOR RX/TX LINE 1.
        .BYTE 2 ;TX/RX LINE FOR RX/TX LINE 2.
        .BYTE 3. ;TX/RX LINE FOR RX/TX LINE 3.
        .BYTE 4. ;TX/RX LINE FOR RX/TX LINE 4.
        .BYTE 5. ;TX/RX LINE FOR RX/TX LINE 5.
        .BYTE 6. ;TX/RX LINE FOR RX/TX LINE 6.
        .BYTE 7. ;TX/RX LINE FOR RX/TX LINE 7.
        .BYTE 8. ;TX/RX LINE FOR RX/TX LINE 8.
        .BYTE 9. ;TX/RX LINE FOR RX/TX LINE 9.
```

1437 004022 012
 1438 004023 013
 1439 004024 014
 1440 004025 015
 1441 004026 016
 1442 004027 017
 1443 004030
 1444
 1445
 1446
 1447
 1448
 1449
 1450
 1451
 1452 004030
 1453 004030 004
 1454 004031 006
 1455 004032 000
 1456 004033 002
 1457 004034 014
 1458 004035 016
 1459 004036 010
 1460 004037 012
 1461 004040 024
 1462 004041 026
 1463 004042 020
 1464 004043 022
 1465 004044 034
 1466 004045 036
 1467 004046 030
 1468 004047 032
 1469
 1482 004050
 004050
 004050 000000
 004052 000000
 004054 000000
 004056 000000
 1483
 1484

```

        .BYTE 10.          ;TX/RX LINE FOR RX/TX LINE 10.
        .BYTE 11.          ;TX/RX LINE FOR RX/TX LINE 11.
        .BYTE 12.          ;TX/RX LINE FOR RX/TX LINE 12.
        .BYTE 13.          ;TX/RX LINE FOR RX/TX LINE 13.
        .BYTE 14.          ;TX/RX LINE FOR RX/TX LINE 14.
        .BYTE 15.          ;TX/RX LINE FOR RX/TX LINE 15.
TXRLNE: .EVEN              ;END OF TX/RX LINE NUMBER ASSOCIATION TABLE.
;*****
; * TABLE OF TX/RX LINE NUMBER ASSOCIATIONS IN STAGGERED LOOPBACK.
; * THE ASSOCIATIONS ARE STORED AS LINE NUMBER TIMES 2 FOR USE AS OFFSETS
; * WHEN ACCESSING A TABLE OF WORDS.
; * THIS IS A TABLE OF DATA FOR READING ONLY. USE TO LOAD THE ABOVE TABLE.
; * NOTE: MUST CONVERT FROM BYTES TO WORDS WHEN LOADING ABOVE TABLE.
;*****
STGTRB: .EVEN              ;BASE OF STAGGERED TX/RX LINE NUMBER TABLE.
        .BYTE 4.          ;TX/RX LINE OFFSET FOR RX/TX LINE 0.
        .BYTE 6.          ;TX/RX LINE OFFSET FOR RX/TX LINE 1.
        .BYTE 0.          ;TX/RX LINE OFFSET FOR RX/TX LINE 2.
        .BYTE 2.          ;TX/RX LINE OFFSET FOR RX/TX LINE 3.
        .BYTE 12.         ;TX/RX LINE OFFSET FOR RX/TX LINE 4.
        .BYTE 14.         ;TX/RX LINE OFFSET FOR RX/TX LINE 5.
        .BYTE 8.          ;TX/RX LINE OFFSET FOR RX/TX LINE 6.
        .BYTE 10.         ;TX/RX LINE OFFSET FOR RX/TX LINE 7.
        .BYTE 20.         ;TX/RX LINE OFFSET FOR RX/TX LINE 8.
        .BYTE 22.         ;TX/RX LINE OFFSET FOR RX/TX LINE 9.
        .BYTE 16.         ;TX/RX LINE OFFSET FOR RX/TX LINE 10.
        .BYTE 18.         ;TX/RX LINE OFFSET FOR RX/TX LINE 11.
        .BYTE 28.         ;TX/RX LINE OFFSET FOR RX/TX LINE 12.
        .BYTE 30.         ;TX/RX LINE OFFSET FOR RX/TX LINE 13.
        .BYTE 24.         ;TX/RX LINE OFFSET FOR RX/TX LINE 14.
        .BYTE 26.         ;TX/RX LINE OFFSET FOR RX/TX LINE 15.
        .EVEN              ;GUARANTEE THAT NEXT TABLE IS ON WORD BOUNDARY.
ERRTBL
ERRTYP: .WORD 0
ERRNBR: .WORD 0
ERRMSG: .WORD 0
ERRBLK: .WORD 0
.EVEN
    
```

L\$ERRTBL::

1486
 1487
 1488
 1489
 1490
 1491
 1492
 1493
 1494
 1495
 1496
 1497
 1498
 1499
 1500
 1501
 1502
 1503
 1504
 1505
 1506
 1507
 1508
 1509
 1510
 1511
 1512
 1513
 1514
 1515
 1516
 1517
 1518
 1519
 1520
 1521
 1522

```
.SBTTL GPR HANDLING ROUTINES FOR SUBROUTINE CALLS.
;*****
;* THERE ARE 4 ROUTINES AND MACRO DEFINITIONS USED FOR THE HANDLING OF
;* GPR VALUES DURING SUBROUTINE CALLS WITHIN THIS PROGRAM. THE FOUR
;* ROUTINES/MACRO CALLS HAVE THE FOLLOWING NAMES:
;*
;* SAVE - MACRO DEFINITION USED AT THE BEGINNING OF A SUBROUTINE TO
;* SAVE THE GPR CONTENTS FOR LATER RESTORATION.
;* PASS - MACRO DEFINITION USED AT THE END OF A SUBROUTINE TO RESTORE
;* THE PREVIOUSLY SAVED GPR CONTENTS AND TO LEAVE THE CONTENTS
;* OF THE SPECIFIED GPR(S) INTACT (NOT RESTORED).
;* PREGOS - SUBROUTINE WHICH IS CALLED FROM THE SAVE AND PASS MACRO
;* EXPANSIONS WHICH ACTUALLY PERFORMS THE ACTIONS ON THE GPRS.
;*
;* DURING A SUBROUTINE WHICH USES THESE GPR SAVE ROUTINES THE VALUES
;* OF THE GPRS ARE STORED ON THE STACK IN THE FOLLOWING STACK FRAME:
;*
;*      SP      -> RET PC INTO PREGOS ROUTINE.
;*      SP+2    -> GPR R0 CONTENTS.
;*      SP+4    -> GPR R1 CONTENTS.
;*      SP+6    -> GPR R2 CONTENTS.
;*      SP+8    -> GPR R3 CONTENTS.
;*      SP+10   -> GPR R4 CONTENTS.
;*      SP+12   -> GPR R5 CONTENTS.
;*      SP+14   -> RET PC INTO CALLER OF SUB'TNE WHICH CALLED PREGOS.
;*
;* EACH LEVEL OF SUB'TNE CALLING USES 8 WORDS OF STACK OVERHEAD.
;* THE SAVE AND PASS MACROS CAN ALSO BE USED IN "STRAIGHT LINE CODE"
;* TO SAVE AND RESTORE THE GPR VALUES. IN ANY CASE, AFTER THE
;* ISSUING OF A PASS CALL THE GPRS WILL BE RESTORED TO THE VALUES
;* THEY HAD PRIOR TO THE LAST SAVE CALL (EXCEPT FOR THE EXCEPTED,
;* OR PASSED INTACT, GPRS SPECIFIED AS PARAMETERS TO THE PASS CALL)
;* AND THE SP WILL ALSO BE RESTORED TO ITS CONDITION BEFORE THE LAST
;* SAVE CALL. THE PROGRAMMER MUST BE SURE THAT THE SP HAS THE SAME
;* VALUE WHEN THE PASS MACRO IS CALLED AS IT HAD IMMEDIATELY AFTER
;* THE SAVE MACRO WAS CALLED.
;*****
```

1524
1525
1526
1527
1528
1529
1530
1531
1532
1533
1534
1535
1536
1537
1538

.SBTTL GPR FRAME ACCESS EQUATES

;***
;EQUATES THAT ALLOW ACCESS TO THE STACK FRAME. THESE ARE THE
;OFFSETS INTO THE STACK FOR REGISTERS SAVED DURING THE PREG05
;ROUTINE.
;---

000036	LPCSLT==	36	;OFFSET FOR LAST RETURN PC.
000016	PCSLOT==	16	;OFFSET FOR RETURN PC.
000014	R5SLOT==	14	;OFFSET FOR R5.
000012	R4SLOT==	12	;OFFSET FOR R4.
000010	R3SLOT==	10	;OFFSET FOR R3.
000006	R2SLOT==	6	;OFFSET FOR R2.
000004	R1SLOT==	4	;OFFSET FOR R1.
000002	ROSLOT==	2	;OFFSET FOR R0.

1540
1541
1542
1543
1544
1545
1546
1547
1548
1549
1550
1551
1552
1553
1554
1555
1556
1557
1558
1559
1560
1561
1562
1563

.SBTTL GLOBAL MACRO DEFINITION SAVE
:*****
: * THIS MACRO IS USED AT THE BEGINNING OF A SUBROUTINE TO SAVE THE
: * CONTENTS OF THE GPRS R0 THRU R5.
: *
: * INPUTS: SP - UNCHANGED SINCE SUBROUTINE WAS ENTERED
: * R5SLOT - OFFSET TO STACK SLOT FOR R5 (EQUATED TO 14 OCTAL)
: *
: * OUTPUTS: GPR SAVE AREA ON THE STACK IS LOADED WITH THE CONTENTS OF GPRS
: * TOP OF STACK LOADED WITH THE RETURN ADDRESS INTO PREG05
: *
: * CALLING SEQUENCE: SAVE
: *
: * COMMENTS: NO ARGUMENTS ARE ALLOWED.
: * THE PASS MACRO SHOULD BE CALLED TO RESTORE THE GPR VALUES.
: *
: * SUBORDINATE ROUTINES CALLED: PREG05.
:*****
: .MACRO SAVE
: .LIST JSR R5,PREG05 ;CALL REGISTER SAVE SUBRT.
: .NLIST
: .ENDM SAVE

1565
1566
1567
1568
1569
1570
1571
1572
1573
1574
1575
1576
1577
1578
1579
1580
1581
1582
1583
1584
1585
1586
1587
1588
1589
1590
1591
1592
1593
1594
1595
1596
1597
1598
1599
1600
1601
1602
1603
1604
1605
1606
1607
1608
1609
1610
1611
1612

```

.SBTTL GLOBAL MACRO DEFINITION - PASS -
;*****
;* THIS MACRO IS USED IN CONJUNCTION WITH THE SAVE MACRO. IT IS
;* CALLED AT END OF A SUBROUTINE TO PASS PARAMETERS IN GPRS BACK TO THE
;* CALLING ROUTINE BY ALTERING THE GPR SAVE AREA ON THE STACK AND THEN
;* RETURNING TO PREG05 TO RESTORE THE GPRS TO THEIR SAVED VALUES.
;*
;* INPUTS: ONLY ALLOWED ARGUMENTS ARE "R0" THRU "R5".
;* ROSLOT THRU R5SLOT MUST BE EQUATED TO THEIR RESPECTIVE GPR SAVE
;* SLOT OFFSETS BEFORE CALLING THIS MACRO.
;*
;* OUTPUTS: THE GPR VALUES ARE PUT IN THEIR RESPECTIVE SLOTS ON THE STACK.
;*
;* CALLING SEQUENCE: PASS R0,R1,...
;*
;* COMMENTS: ANY COMBINATION OF GPR ARGUMENTS MAY BE LISTED IN ANY ORDER.
;* FOR EXAMPLE, THE FOLLOWING ARE LEGAL:
;* PASS R1
;* PASS R4,R0,R2
;* THE GPRS LISTED AS ARGUMENTS WILL BE PASSED INTACT TO THE
;* CALLING ROUTINE, ALL OTHER GPRS WILL BE RESTORED.
;* THE SP MUST BE AT ITS ORIGINAL VALUE WHEN PASS IS CALLED.
;*
;* THE MACRO CALL
;* PASS R0,R3
;* EXPANDS INTO THE FOLLOWING ASSEMBLY CODE:
;* MOV R0,ROSLOT(SP) ;PUT R0 IN STACK SLOT.
;* MOV R3,R3SLOT(SP) ;PUT R3 IN STACK SLOT.
;* JSR PC,8(SP)+ ;RETURN TO PREG05 SUBRT.
;* IN THIS EXAMPLE GPRS R1, R2, R4, AND R5 WILL BE RESTORED TO
;* THEIR VALUES CONTAINED IN THE STACK FRAME AND R0 AND R3
;* WILL BE LEFT AT THEIR VALUES PRIOR TO THIS PASS CALL.
;*
;* SUBORDINATE ROUTINES CALLED: (PREGRT - LABEL WITHIN PREG05, VALUE ON STACK.)
;*****

.MACRO PASS A,B,C,D,E,F
.IRP X,<A,B,C,D,E,F>
.IF NB,X
.LIST
MOV X,X'SLOT(SP) ;PUT X IN STACK SLOT.
.NLIST
.ENDC
.ENDM
.LIST
.NLIST
.ENDM PASS

```



```

1668
1676
1677
1678
1679
1680
1681
1682
1683
1684
1685
1686
1687 004120
      004120
      004120    104    110    125
      004123    055    061    061
      004126    000

1688
1694
1695
1696
1697 004130
      004130
      004130    104    110    125
      004133    055    061    061
      004136    040    106    125
      004141    116    103    040
      004144    124    123    124
      004147    040    120    101
      004152    122    124    062
      004155    000

1698
1699
1706
    
```

.SBTTL GLOBAL TEXT SECTION

```

; **
; THE GLOBAL TEXT SECTION CONTAINS FORMAT STATEMENTS,
; MESSAGES, AND ASCII INFORMATION THAT ARE USED IN
; MORE THAN ONE TEST.
; --

;
; NAMES OF DEVICES SUPPORTED BY PROGRAM
;
      DEVTYP <DHU-11>

L$DVTYP::
      .ASCIZ /DHU-11/

      .EVEN

; TEST DESCRIPTION
;
      DESCRIPT <DHU 11 FUNC TST PART2>

L$DESC::
      .ASCIZ /DHU-11 FUNC TST PAR

      .EVEN
    
```

T2/

```

1715
1716      .MLIST BIN
1717
1718
1719      ; ***** FORMAT STATEMENTS USED IN PRINT CALLS *****
1720
1721
1722 004156 EF0503:: .ASCIZ /#T#N/
1723 004163 EF1601:: .ASCIZ /#A #T#A, TEST ABORTED #N/
1724 004215 EF5801:: .ASCIZ /#A      RXTIMER VALUE USED WAS :#D3#A (D)#N/
1725 004270 EF5901:: .ASCIZ /#A      EXPECTED :#D3#A(D)#N/
1726 004320 EF5902:: .ASCIZ /#A      ACTUAL   :#D3#A(D)#N/
1727 004350 EF6401:: .ASCIZ /#A      #D2#N/
1728 004417 EF7801:: .ASCIZ /#T#A ON LINE #D2#A DECIMAL.#N/
1729 004455 EF9001:: .ASCIZ /#A UNEXPECTED #T#A FOUND IN RECEIVE CHAR FIFO:#N/
1730 004537 EF9002:: .ASCIZ /#A      CODE IS ASSOCIATED WITH LINE: #D2#N/
1731 004611 EF9003:: .ASCIZ /#A      CODE IS: #D3#N/
1732 004640 EF9004:: .ASCIZ /#A      #T#A VALUE: #D3#N/
1733 004670 EF9005:: .ASCIZ /#A      #T#A VALUE: NONE#N/
1734 004721 EF9006:: .ASCIZ /#A #T#A #D2#A(D)#N/
1735 004745 EF9010:: .ASCIZ /#A      NUMBER OF ERRORS DETECTED ON LINE #D2#A IS #D5#N/
1736 005034 EF9019:: .ASCIZ /#A #T#A #D6#N/
1737 005053 EF9301:: .ASCIZ /#A #T#D2#A(D). BMP CODE REPORTED :#D3#A(D)#N/
1738 005131 EF9302:: .ASCIZ /#A OVERFLOW OCCURRED (MORE THAN 31 BMP CODES FOUND IN QUEUE)#N/
1739 005231 MFUNIT:: .ASCIZ /#N#A TESTING UNIT :#D4#N/
1740      .EVEN
1741      .LIST BIN
    
```

```
1750
1751 .NLIST BIN
1752
1753
1754 ;***** GLOBAL ERROR MESSAGES *****
1755
1756 005262 EM0103:: .ASCIZ /DEVICE REGISTER ACCESS ERRORS/
1757 005320 EM1601:: .ASCIZ /TIMEOUT OCCURRED WAITING FOR MASTER RESET TO CLEAR/
1758 005403 EM4001:: .ASCIZ /DMA_START BIT TEST FAILED/
1759 005435 EM4002:: .ASCIZ /DMA_START BIT BAD ON LINE: /
1760 005471 EM4101:: .ASCIZ /DMA_ABORT BIT TEST FAILED/
1761 005523 EM4102:: .ASCIZ /DMA_ABORT BIT BAD ON LINE: /
1762 005557 EM4103:: .ASCIZ /DMA_START BIT FOUND SET AFTER DMA ABORTED ON LINE: /
1763 005643 EM4201:: .ASCIZ /DMA_ERROR BIT TEST FAILED/
1764 005675 EM4202:: .ASCIZ /DMA_ERROR BIT BAD/
1765 005717 EM4901:: .ASCIZ /OAUTO (INACTIVE) BIT TEST FAILED/
1766 005760 EM4902:: .ASCIZ / OAUTO BIT BAD ON LINE: /
1767 006012 EM5001:: .ASCIZ /OAUTO (ACTIVE) BIT TEST FAILED/
1768 006051 EM5101:: .ASCIZ /IAUTO (INACTIVE) TEST FAILED/
1769 006106 EM5102:: .ASCIZ /IAUTO BIT FOUND SET ON LINE: /
1770 006144 EM5103:: .ASCIZ /IAUTO BIT BAD ON LINE: /
1771 006174 EM5201:: .ASCIZ /IAUTO (ACTIVE) TEST FAILED/
1772 006227 EM5202:: .ASCIZ /IAUTO BIT FOUND CLR ON LINE: /
1773 006265 EM5301:: .ASCIZ /FIFO VALID DATA TEST FAILED/
1774 006321 EM5302:: .ASCIZ /FIFO BAD, DATA FIELD CORRUPTED, TEST USED LINE:/
1775 006401 EM5303:: .ASCIZ /BMP CODE FOUND IN FIFO, TEST INVAILEDATED/
1776 006452 EM5401:: .ASCIZ \FIFO 3/4 ALARM (INACTIVE) TEST FAILED\
1777 006520 EM5402:: .ASCIZ /FIFO BAD, ALARM SIGNAL DEFECTIVE/
1778 006561 EM5501:: .ASCIZ \FIFO 3/4 ALARM (ACTIVE) TEST FAILED\
1779 006625 EM5601:: .ASCIZ \FIFO 3/4 ALARM (ACTIVE/INACTIVE) TEST FAILED\
1780 006702 EM5701:: .ASCIZ \FIFO 1/2 LEVEL (ACTIVE/INACTIVE) TEST FAILED\
1781 006757 EM5801:: .ASCIZ /RXTIMER TEST FAILED/
1782 007003 EM5802:: .ASCIZ /RXTIMER BAD, RX-INT DELAYED BY WRONG NUMBER OF MILLISECONDS/
1783 007077 EM5803:: .ASCIZ \RXTIMER BAD, RX-INT DIDN'T OCCUR IMMEDIATELY WITH RXFIFO 3/4 FULL\
1784 007201 EM5804:: .ASCIZ /RXTIMER BAD, RX-INT OCCURED WITH RXTIMER VALUE ZERO/
1785 007265 EM5805:: .ASCIZ /RXTIMER BAD, TIME-OUT OCCURED WAITING FOR RX-INT/
1786 007346 EM5901:: .ASCIZ / TX-ACTION FIFO TEST FAILED/
1787 007402 EM5902:: .ASCIZ / TX_ACTION FIFO BAD, TX-ACTION RECIEVED FROM THE WRONG LINE/
1788 007476 EM5903:: .ASCIZ / TX_ACTION FIFO BAD, INCORRECT NUMBER OF TX-ACTIONS FOUND/
1789 007570 EM5904:: .ASCIZ / TX_ACTION FIFO BAD, TX-ACTION FIFO WOULD NOT EMPTY/
1790 007654 EM5905:: .ASCIZ / TX_INTERRUPT OCCURED AFTER THE TX_ACTION FIFO HAD BEEN EMPTIED/
1791 007754 EM6001:: .ASCIZ /TX FIFO TEST FAILED/
1792 010000 EM6002:: .ASCIZ /INCORRECT VALUE IN FIFOSIZE REG/
1793 010040 EM6003:: .ASCIZ /MORE THAN ONE TX-INT OCCURED, FROM A FULL TXFIFO/
1794 010120 EM6004:: .ASCIZ /TX FIFO BAD, RECIEVED CHAR INCORRECT/
1795 010165 EM6005:: .ASCIZ /TX FIFO BAD, CHARACTER RECIEVED ON WRONG LINE/
1796 010243 EM6006:: .ASCIZ /TX FIFO BAD, TOO FEW CHARS RECIEVED/
1797 010307 EM6401:: .ASCIZ /BREAK GENERATION TEST FAILED/
1798 010344 EM6402:: .ASCIZ / BREAK NOT RECEIVED ON LINE(S):/
1799 010405 EM6601:: .ASCIZ /NO OVERRUN ERROR TEST FAILED/
1800 010442 EM6602:: .ASCIZ / OVERRUN ERROR REPORTED WHEN NONE FORCED/
1801 010514 EM6701:: .ASCIZ /OVERRUN ERROR TEST FAILED/
1802 010546 EM6702:: .ASCIZ / NO OVERRUN ERROR REPORTED, OVERRUN FORCED/
1803 010623 EM9009:: .ASCIZ /EXPECTED OR CORRECT/
1804 010647 EM9010:: .ASCIZ /ACTUAL OR MEASURED /
1805 010673 EM9014:: .ASCIZ /SUMMARY REPORTS FOR LINES WITH EXCESSIVE NUMBERS OF ERRORS:/
1806 010767 EM9017:: .ASCII / FIFO WILL NOT PURGE (DATA.VALID STUCK SET),/
```

```
1807 011044 .ASCIZ / REMAINDER OF TEST SKIPPED./
1808 011100 EM9026:: .ASCIZ / LPR CONTENTS: /
1809 011124 EM9104:: .ASCIZ / UNEXPECTED DATA FOUND IN FIFO FROM LINE: /
1810 011200 EM9301:: .ASCIZ /BMP CODES WERE REPORTED DURING THIS DIAGNOSTIC/
1811 011257 EM9302:: .ASCIZ /BMP CODE FOUND IN TEST /
1812 011307 EM9303:: .ASCIZ /THE LAST BMP CODE WAS FOUND IN TEST /
1813 011354 EM9304:: .ASCIZ /UNEXPECTED BMP CODES FOUND DURING THIS PASS/
1814 .EVEN
1815 .LIST BIN
```

1824
1825
1826
1827
1828
1829
1830
1831
1832

.SBTTL GLOBAL ERROR REPORT SECTION

; THE GLOBAL ERROR REPORT SECTION CONTAINS MESSAGE PRINTING AREAS
; USED BY MORE THAN ONE TEST TO OUTPUT ADDITIONAL ERROR INFORMATION. PRINTB
; (BASIC) AND PRINTX (EXTENDED) CALLS ARE USED TO CALL PRINT SERVICES.
;--


```

1874 011542          004736          63:  PASS          ;RESTORE THE GPR CONTENTS.
      011542          ;RETURN TO PREG05 SUBRT.
1875 011544          ENDMSG          JSR          PC,@(SP)+
      011544          104423          L10002: TRAP      C$MSG
      011544
1876 011546          045          101          102  MSG1:: .ASCIZ /#ABUS TIME-OUT TRAP CAUSED BY READ ATTEMPT.#N/
1877 011551          125          123          040
      011554          124          111          115
      011557          105          055          117
      011562          125          124          040
      011565          124          122          101
      011570          120          040          103
      011573          101          125          123
      011576          105          104          040
      011601          102          131          040
      011604          122          105          101
      011607          104          040          101
      011612          124          124          105
      011615          115          120          124
      011620          056          045          116
      011623          000
1878 011624          045          101          102  MSG2:: .ASCIZ /#ABUS TIME OUT TRAP CAUSED BY WRITE ATTEMPT.#N/
      011627          125          123          040
      011632          124          111          115
      011635          105          055          117
      011640          125          124          040
      011643          124          122          101
      011646          120          040          103
      011651          101          125          123
      011654          105          104          040
      011657          102          131          040
      011662          127          122          111
      011665          124          105          040
      011670          101          124          124
      011673          105          115          120
      011676          124          056          045
      011701          116          000
1879 011703          045          101          104  MSG3:: .ASCIZ /#ADMU MAY BE AT THE WRONG UNIBUS ADDRESS.#N#N/
      011706          110          125          040
      011711          115          101          131
      011714          040          102          105
      011717          040          101          124
      011722          040          124          110
      011725          105          040          127
      011730          122          117          116
      011733          107          040          125
      011736          116          111          102
      011741          125          123          040
      011744          101          104          104
      011747          122          105          123
      011752          123          056          045
      011755          116          045          116
      011760          000
1880
1881

```

.EVEN

1883
 1884
 1885
 1886
 1887
 1888
 1889
 1890
 1891
 1892
 1893
 1894
 1895
 1896
 1897
 1898
 1899
 1900
 1901
 1902
 1903
 1904
 1905
 1906
 1907
 1908
 1909
 1910
 1911

011762
 011762
 011762 012700 000100
 011766 046700 170216
 011772 001011
 011774
 011774 010146
 011776 012746 004156
 012002 012746 000002
 012006 010600
 012010 104414
 012012 062706 000006
 012016
 012016
 012016 104423

```
.SBTTL GLOBAL ERROR REPORTING ROUTINE ERO503 -
*****
; * THIS IS AN ERROR REPORTING SUBROUTINE WHICH PRINTS AN ADDITIONAL ERROR
; * MESSAGE WHOSE ADDRESS IS PASSED AS AN INPUT PARAMETER, PROVIDED
; * EXTENDED ERROR REPORTING HAS BEEN REQUESTED.
; *
; * INPUTS: R1 - ADDRESS OF THE MESSAGE TO PRINT.
; *
; * OUTPUTS: A MESSAGES IS PRINTED AT THE OPERATOR CONSOLE.
; *
; * CALLING SEQUENCE: LOAD THE ADDRESS OF THE MESSAGE IN R1.
; * INCLUDE THE LABEL "ER0503" AS THE MESSAGE POINTER
; * PARAMETER IN THE DIAG SUPER ERROR REPORT MACRO CALL.
; *
; * COMMENTS: THE MESSAGE IS PRINTED AS BASIC ERROR INFORMATION.
; *
; * SUBORDINATE ROUTINES USED: NONE.
*****
```

BGNMSG ERO503

ER0503::


```
MOV #BIT06,R0 ;TRY TO CLEAR THE
BIC OPTION,R0 ;EXT'D ERROR REPORTING FLAG
BNE 2$ ;EXIT IF FLAG NOT SET.
```

```
PRINTB #EF0503,R1 ;PRINT THE MESSAGE.
```

```
MOV R1,-(SP)
MOV #EF0503,(SP)
MOV #2,-(SP)
MOV SP,R0
TRAP C$PNTB
ADD #6,SP
```

2\$: ENDMSG

```
L10003:
TRAP C$MSG
```



1913
1914
1915
1916
1917
1918
1919
1920
1921
1922
1923
1924
1925
1926
1927
1928
1929
1930
1931
1932
1933
1934
1935 012020
012020
1936 012020
012020 004567 172034
1937
1938 012024 012700 000100
1939 012030 046700 170154
1940 012034 001024
1941
1942
1943 012036
012036 010146
012040 012746 004156
012044 012746 000002
012050 010600
012052 104414
012054 062706 000006
1944
1945 012060 016702 171770
1946 012064
012064 010246
012066 012746 004163
012072 012746 000002
012076 010600
012100 104414
012102 062706 000006
1947
1948 012106
012106 004736
1949 012110
012110
012110 104423

```

.SBTTL GLOBAL ERROR REPORTING ROUTINE - ER1603 -
;*****
;* THIS ERROR REPORTING ROUTINE IS USED TO PRINT OUT A BASIC ERROR
;* MESSAGE, ALONG WITH A MESSAGE INFORMING THE OPERATOR WHICH TEST IS
;* ABOUT TO BE ABORTED, PROVIDED EXTENDED ERROR INFORMATION HAS BEEN
;* REQUESTED, OTHERWISE ONLY A "TEST FAILURE" MESSAGE WILL BE PRINTED.
;*
;* INPUTS: R1 - CONTAINS THE ADDRESS OF THE MESSAGE TO BE PRINTED,
;* ERRMSG - CONTAINS THE ADDRESS OF THE MESSAGE THAT INDICATES
;* THE TEST THAT IS BEING PERFORMED, EG DMA, BREAK ETC.
;*
;* OUTPUTS: MESSAGES ARE PRINTED AT THE OPERATORS CONSOLE.
;* "TESTNAME TEST ABORTED"
;*
;* CALLING SEQUENCE: INCLUDE THE LABEL "ER1603" AS THE MESSAGE POINTER
;* PARAMETER IN THE DRS ERROR REPORT MACRO CALL.
;*
;* COMMENTS:
;*
;* SUBORDINATE ROUTINES CALLED: NONE.
;*****
          BGNMSG ER1603
          SAVE                                ER1603::
          JSR R5,PREG05                       ;SAVE THE CONTENTS OF THE GPRS.
          ;CALL REGISTER SAVE SUBRT.
          MOV #BIT06,R0                       ;TRY TO CLEAR THE
          BIC OPTION,R0                       ;EXT'D ERROR REPORTING FLAG
          BNE 2$                              ;EXIT IF FLAG NOT SET.

          PRINTB #EF0503,R1                   ;PRINT BASIC MESSAGE ON OPERATORS CONSOLE.
          MOV R1,(SP)
          MOV #EF0503,-(SP)
          MOV #2,(SP)
          MOV SP,R0
          TRAP C$PNTB
          ADD #6,SP

          MOV ERRMSG,R2                       ;GET THE "TEST MESSAGE".
          PRINTB #EF1601,R2                   ;PRINT "TEST ABORTED" MESSAGE.
          MOV R2,-(SP)
          MOV #EF1601,-(SP)
          MOV #2,-(SP)
          MOV SP,R0
          TRAP C$PNTB
          ADD #6,SP

2$:      PASS                                ;RESTORE THE CONTENTS OF THE GPRS.
          JSR PC,@(SP)                        ;RETURN TO PREG05 SUBRT.

          ENDMSG

          L10004:
          TRAP C$MSG
    
```

1951
1952
1953
1954
1955
1956
1957
1958
1959
1960
1961
1962
1963
1964
1965
1966
1967
1968
1969
1970
1971
1972

```
.SBTTL GLOBAL ERROR REPORTING ROUTINE ER5801 -
*****
; * THIS IS AN ERROR REPORTING ROUTINE WHICH PRINTS THE MESSAGE PASSED
; * AS A PARAMETER IN R1, AND THE RXTIMER VALUE IN R2, PROVIDED
; * EXTENDED ERROR REPORTING HAS BEEN REQUESTED.
; * THIS ROUTINE IS USED BY THE RXTIMER TEST.
; *
; * INPUTS: R1 - ADDRESS OF THE MESSAGE TO PRINT.
; * R2 RXTIMER VALUE.
; *
; * OUTPUTS: THE MESSAGE FOLLOWED BY THE RXTIMER VALUE ARE PRINTED AT
; * THE OPERATOR CONSOLE.
; *
; * CALLING SEQUENCE: INCLUDE THE LABEL ER5801 AS THE MESSAGE POINTER
; * PARAMETER IN THE DRS ERROR REPORT MACRO CALL.
; *
; * COMMENTS: THE MESSAGE IS PRINTED AS BASIC ERROR INFORMATION AND THE
; * RXTIMER VALUE IS PRINTED AS A 3 DIGIT DECIMAL NUMBER.
; *
; * SUBORDINATE ROUTINES USED: NONE.
*****
```

1973 012112
012112
1974 012112 032767 000100 170070
1975 012120 001422
1976
1977 012122
012122 010146
012124 012746 004156
012130 012746 000002
012134 010600
012136 104414
012140 062706 000006
1978 012144
012144 010246
012146 012746 004215
012152 012746 000002
012156 010600
012160 104414
012162 062706 000006
1979 012166
012166
012166 104423

```
BGNMSG ER5801
BIT #BIT06.OPTION ;HAS EXTENDED ERROR REPORTING BEEN REQUESTED ?
BEQ 2# ;EXIT WITH "TEST FAILED" MESSAGE IF NOT.

PRINTB #EF0503,R1
MOV R1,-(SP)
MOV #EF0503,-(SP)
MOV #2,-(SP)
MOV SP,R0
TRAP C$PNTB
ADD #6,SP

PRINTB #EF5801,R2
MOV R2,(SP)
MOV #EF5801,-(SP)
MOV #2,(SP)
MOV SP,R0
TRAP C$PNTB
ADD #6,SP

2#: ENDMSG
L10005: TRAP C$MSG
```

```

1981 .SBTTL GLOBAL ERROR REPORTING ROUTINE - ER5901 -
1982 ,*****
1983 :* THIS IS AN ERROR REPORTING ROUTINE WHICH PRINTS AN ADDITIONAL
1984 :* MESSAGE IN ADDITION TO THE "TEST FAILED" MESSAGE AND ALSO A
1985 :* MESSAGE SHOWING THE EXPECTED VALUE OF A PIECE OF DATA AND THE
1986 :* ACTUAL VALUE OF THAT DATA. THE DATA IS PRINTED AS A 3 DIGIT
1987 :* DECIMAL NUMBER.
1988 :*
1989 :* INPUTS : R1 - EXPECTED VALUE OF DATA.
1990 :* R2 - ACTUAL VALUE OF DATA.
1991 :* R3 - ADDRESS OF THE MESSAGE TO PRINT.
1992 :*
1993 :* OUTPUTS : MESSAGES ARE PRINTED AT THE OPERATORS CONSOLE.
1994 :*
1995 :* CALLING SEQUENCE: INCLUDE THE LABEL "ER5901" AS THE MESSAGE POINTER
1996 :* PARAMETER IN THE DRS ERROR REPORT MACRO CALL.
1997 :*
1998 :* COMMENTS :
1999 :*
2000 :* SUBORDINATE ROUTINES USED : NONE.
2001 :*****
2002
2003 012170 BGNMSG ER5901
2004 012170 ER5901::
2005 012170 004567 171664 SAVE JSR ;SAVE THE GPR CONTENTS.
;R5,PREG05 ;CALL REGISTER SAVE SUBRT.
2006
2007 012174 032767 000100 170006 BIT #BIT06,OPTION ;EXIT THE ROUTINE IF EXTENDED
2008 012202 001433 BEQ 60# ;ERROR REPORTING IS NOT REQUESTED.
2009
2010 ;*
2011 ;* REPORT EXTENDED ERROR INFORMATION
2012 ;*
2013
2014 012204 PRINTB #EF0503,R3 ;PRINT THE MESSAGE.
012204 010346
012206 012746 004156 MOV R3,-(SP)
012212 012746 000002 MOV #EF0503,(SP)
012216 010600 MOV #2,-(SP)
012220 104414 MOV SP,R0
012222 062706 000006 TRAP C$PNTB
2015 012226 PRINTX #EF5901,R1 ;PRINT THE "EXPECTED VALUE" MESSAGE.
012226 010146 ADD #6,SP
012230 012746 004270 MOV R1,-(SP)
012234 012746 000002 MOV #EF5901,-(SP)
012240 010600 MOV #2,-(SP)
012242 104415 MOV SP,R0
012244 062706 000006 TRAP C$PNTX
2016 012250 PRINTX #EF5902,R2 ;PRINT THE "ACTUAL VALUE" MESSAGE.
012250 010246 ADD #6,SP
012252 012746 004320 MOV R2,(SP)
012256 012746 000002 MOV #EF5902,-(SP)
012262 010600 MOV #2,-(SP)
012264 104415 MOV SP,R0
012266 062706 000006 TRAP C$PNTX
2017 ADD #6,SP

```

2018 012272
012272 004736
2019
2020 012274
012274
012274 104423

60\$: PASS
ENDMSG

JSR ;RESTORE THE GPR CONTENTS.
PC,8(SP)+ ;RETURN TO PREG05 SUBRT.

L10006: TRAP C\$MSG

2022
2023
2024
2025
2026
2027
2028
2029
2030
2031
2032
2033
2034
2035
2036
2037
2038
2039
2040
2041
2042
2043
2044
2045
2046
2047
2048
2049
2050
2051
2052
2053
2054
2055
2056
2057
2058

012276
012276
012276 032767 000100 167704
012304 001434
012306
012306 010446
012310 010346
012312 012746 004417
012316 012746 000003
012322 010600
012324 104414
012326 062706 000010
012332
012332 010146
012334 012746 004270
012340 012746 000002
012344 010600
012346 104415
012350 062706 000006
012354
012354 010246
012356 012746 004320
012362 012746 000602
012366 010600
012370 104415
012372 062706 000006

```
.SBTTL GLOBAL ERROR REPORTING ROUTINE - ER6001 -
;*****
;* THIS IS AN ERROR REPORTING ROUTINE WHICH PRINTS OUT A MESSAGE
;* AT THE CONSOLE INFORMING THE OPERATOR OF AN ERROR ON A PARTICULAR
;* LINE. THE ROUTINE ALSO PRINTS OUT A MESSAGE INFORMING THE OPERATOR
;* OF WHAT DATA WAS "EXPECTED" AND WHAT "ACTUAL" DATA WAS FOUND, IN THE
;* FORM OF A 3 DIGIT DECIMAL NUMBER.
;* IF EXTENDED ERROR REPORTING HAS NOT BEEN REQUESTED THEN ONLY THE
;* "TEST FAILED" MESSAGE WILL BE PRINTED.
;*
;* INPUTS : R1 - EXPECTED DATA
;* R2 - ACTUAL DATA
;* R3 - ADDRESS OF THE MESSAGE TO PRINT
;* R4 - LINE NUMBER ON WHICH THE ERROR OCCURED
;*
;* OUTPUTS : MESSAGES ARE PRINTED AT THE OPERATOR CONSOLE
;* " MESSAGE' ON LINE #"
;* "EXPECTED : " ##
;* " ACTUAL : " ##
;*
;* CALLING SEQUENCE : INCLUDE THE LABEL "ER6001" AS THE ERROR ROUTINE
;* POINTER PARAMETER IN THE DRS ERROR REPORT MACRO CALL.
;*
;* SUBORDINATE ROUTINES CALLED : NONE
;*****
```

BGNMSG ER6001

ER6001::

```
BIT #BIT06,OPTION ;EXIT THE ROUTINE IF EXTENDED
BEQ 601 ;ERROR REPORTING IS NOT REQUESTED.
```

```
; REPORT EXTENDED ERROR INFORMATION
```

```
PRINTB #EF7801,R3,R4 ;PRINT THE MESSAGE WITH THE LINE NUMBER.
```

```
MOV R4,-(SP)
MOV R3,-(SP)
MOV #EF7801,-(SP)
MOV #3,-(SP)
MOV SP,R0
TRAP CIPNTB
ADD #10,SP
```

```
PRINTX #EF5901,R1 ;PRINT THE "EXPECTED" DATA MESSAGE.
```

```
MOV R1,-(SP)
MOV #EF5901,-(SP)
MOV #2,-(SP)
MOV SP,R0
TRAP CIPNTX
ADD #6,SP
```

```
PRINTX #EF5902,R2 ;PRINT THE "ACTUAL" DATA MESSAGE.
```

```
MOV R2,-(SP)
MOV #EF5902,-(SP)
MOV #2,-(SP)
MOV SP,R0
TRAP CIPNTX
ADD #6,SP
```

2059 012376
012376
012376 104423

504: ENDMSG

L10007: TRAP C1MSG

2061
2062
2063
2064
2065
2066
2067
2068
2069
2070
2071
2072
2073
2074
2075
2076
2077
2078
2079
2080
2081
2082
2083
2084
2085
2086
2087
2088
2089
2090
2091
2092
2093
2094
2095
2096
2097
2098
2099
2100
2101
2102
2103
2104

012400
012400
012400 004567 171454
012404 032767 000100 167576
012412 001433
012414 005002
012416 012703 000020
012422 010146
012424 012746 004156
012430 012746 000002
012434 010600
012436 104414
012440 062706 000006
012444 000241
012446 006205
012450 103011
012452 010246
012454 012746 004350
012460 012746 000002
012464 010600
012466 104414

```
.SBTTL GLOBAL ERROR REPORTING ROUTINE ER6401 -
;*****
;* THIS IS AN ERROR REPORTING SUBROUTINE WHICH PRINTS ADDITIONAL ERROR
;* INFORMATION AFTER THE ERROR MESSAGE HEADER, PROVIDED EXTENDED ERROR
;* REPORTING HAS BEEN ENABLED.
;* THIS SUBROUTINE IS PASSED A GPR CONTAINING FLAGS WHICH INDICATE
;* THE LINE(S) FOR WHICH THE ERROR CONDITION SHOULD BE REPORTED.
;*
;* INPUTS: R1 ADDRESS OF THE MESSAGE TO BE PRINTED BY THIS ROUTINE.
;* R5 - CONTAINS THE ERROR FLAGS, (1 FLAG PER LINE).
;*
;* OUTPUTS: MESSAGES ARE PRINTED AT THE OPERATOR CONSOLE.
;*
;* CALLING SEQUENCE: LOAD THE ADDRESS OF THE MESSAGE IN R1.
;* INCLUDE THE LABEL "ER6401" AS THE MESSAGE POINTER
;* PARAMETER IN THE DIAG SUPER ERROR REPORT MACRO CALL.
;*
;* COMMENTS: THE OUTPUT FORMAT OF THIS MESSAGE IS:
;* TEXT MESSAGE
;* @NN
;* @NN
;* WHERE EACH "@NN" IS THE NUMBER OF A LINE WITH THE ERROR.
;*
;* SUBORDINATE ROUTINES USED: NONE.
;*****
```

```
BGNMSG ER6401
SAVE ER6401::
JSR R5,PREG05 ;SAVE THE CONTENTS OF THE GPRS.
;CALL REGISTER SAVE SUBRT.

;*
;* EXIT THE TEST IF EXTENDED ERROR REPORTING HAS NOT BEEN ENABLED
;*
BIT #BIT06,OPTION ;EXIT WITH TEST FAILURE MESSAGE IF
BEQ 608 ;NO EXTENDED ERROR REPORTING HAS BEEN REQUESTED
;DURING THE SOFTWARE QUESTIONS.

CLR R2 ;CLEAR LINE NUMBER TO ZERO.
MOV #NUMLNS,R3 ;SET UP MAX LINE COUNT.
PRINTB #EF0503,R1 ;PRINT MESSAGE.

MOV R1,-(SP)
MOV #EF0503,-(SP)
MOV #2,-(SP)
MOV SP,R0
TRAP C:PNTB
ADD #6,SP

21: CLC ;CLEAR CARRY.
ASR R5 ;SHIFT FLAG OUT INTO CARRY BIT.
BCC 41 ;SKIP ERROR REPORT IF CLEAR.
PRINTB #EF6401,R2 ;PRINT MESSAGE.

MOV R2,-(SP)
MOV #EF6401,-(SP)
MOV #2,-(SP)
MOV SP,R0
TRAP C:PNTB
```

012470 062706 000006
2105 012474 005202
2106 012476 020302
2107 012500 001362
2108 012502
012502 004736
2109 012504
012504
012504 104423

4\$: INC R2
CMP R3,R2
BNE 2\$
60\$: PASS
ENDMSG

JSR

; INCREMENT LINE COUNT. ADD 06,SP
; CHECK IF MAX LINE COUNT EXCEEDED.
; LOOP IF NOT DONE.
; RESTORE THE SAVED CONTENTS OF THE GPRS.
PC,0(SP)+ ; RETURN TO PREG05 SUBRT.

L10010:
TRAP C\$MSG

```

2111 .SBTTL GLOBAL ERROR REPORTING ROUTINE ER7801
2112 ;*****
2113 ;* THIS IS AN ERROR REPORTING SUBROUTINE WHICH PRINTS AN ADDITIONAL ERROR
2114 ;* MESSAGE WHOSE ADDRESS IS PASSED AS AN INPUT PARAMETER. A LINE NUMBER
2115 ;* IS INCLUDED AT THE END OF THE MESSAGE. THE MESSAGE IS PRINTED ONLY IF
2116 ;* EXTENDED ERROR REPORTING IS REQUESTED.
2117 ;*
2118 ;* INPUTS: R1 - ADDRESS OF THE MESSAGE TO PRINT.
2119 ;* R3 - NUMBER OF LINE ON WHICH ERROR OCCUPED.
2120 ;*
2121 ;* OUTPUTS: A MESSAGES IS PRINTED AT THE OPERATOR CONSOLE.
2122 ;*
2123 ;* CALLING SEQUENCE: LOAD THE ADDRESS OF THE MESSAGE IN R1.
2124 ;* LOAD THE LINE NUMBER INTO R3.
2125 ;* INCLUDE THE LABEL "ER7801" AS THE MESSAGE POINTER
2126 ;* PARAMETER IN THE DIAG SUPER ERROR REPORT MACRO CALL.
2127 ;*
2128 ;* COMMENTS: THE MESSAGE IS PRINTED AS BASIC ERROR INFORMATION.
2129 ;*
2130 ;* SUBORDINATE ROUTINES USED: NONE.
2131 ;*****
2132
2133 012506 BGNMSG ER7801
2134 012506 ER7801::
2135
2136 ;*
2137 ; EXIT IF EXTENDED ERROR REPORTING HAS NOT BEEN ENABLED
2138 012506 032767 000100 167474 BIT #BIT06,OPTION ;EXIT WITH TEST FAILURE MESSAGE IF
2139 012514 001412 BEQ 2$ ;NO EXTENDED ERROR REPORTING HAS BEEN REQUESTED
2140 ; DURING THE SOFTWARE QUESTIONS.
2141
2142 012516 PRINTB #EF7801,R1,R3 ;PRINT THE MESSAGE.
2143 012516 010346 MOV R3,-(SP)
2144 012520 010146 MOV R1,-(SP)
2145 012522 012746 004417 MOV #EF7801,(SP)
2146 012526 012746 000003 MOV #3,-(SP)
2147 012532 010600 MOV SP,R0
2148 012534 104414 TRAP C$PNTB
2149 012536 062706 000010 ADD #10,SP
2150
2151 2$: ENDMSG
2152
2153 L10011:
2154 012542 TRAP C$MSG
2155 012542 104423

```

2146
2147
2148
2149
2150
2151
2152
2153
2154
2155
2156
2157
2158
2159
2160
2161
2162
2163
2164
2165

```
.SBTTL GLOBAL ERROR REPORTING ROUTINE ER9001 -
*****
; * THIS IS AN ERROR REPORTING SUBROUTINE WHICH REPORTS AN UNEXPECTED
; * CODE WHICH HAS BEEN FOUND IN THE DUT CSR. THIS CODE CAN BE A BMP
; * CODE, A SELF-TEST CODE, OR A MODEM STATUS CODE.
; *
; * INPUTS: R1 - ADDRESS OF MESSAGE TO PRINT FIRST.
; * R2 - SINGLE BYTE CODE WHICH HAS BEEN READ FROM THE DUT.
; * R4 - LINE NUMBER ASSOCIATED WITH THE CODE.
; *
; * OUTPUTS: A MESSAGES IS PRINTED AT THE OPERATOR CONSOLE.
; *
; * CALLING SEQUENCE: INCLUDE THE LABEL "ER9001" AS THE MESSAGE POINTER
; * PARAMETER IN THE DIAG SUPER ERROR REPORT MACRO CALL.
; *
; * COMMENTS: THE MESSAGE IS PRINTED AS BASIC AND EXTENDED ERROR INFORMATION.
; *
; * SUBORDINATE ROUTINES USED: NONE.
*****
```

2166 012544
012544

BGNMSG ER9001

ER9001::

2167
2168
2169
2170

```
; *
; * EXIT IF EXTENDED ERROR REPORTING HAS NOT BEEN ENABLED
; *
```

2171 012544 032767 000100 167436
2172 012552 001433

```
BIT #BIT06,OPTION ;EXIT WITH TEST FAILURE MESSAGE IF
BEQ 2# ;NO EXTENDED ERROR REPORTING HAS BEEN REQUESTED
;DURING THE SOFTWARE QUESTIONS.
```

2173
2174
2175

```
PRINTB #EF9001,R1 ;REPORT TYPE OF CODE FOUND.
```

012554 010146
012554 012746 004455
012562 012746 000002
012566 010600
012570 104414
012572 062706 000006

```
MOV R1,(SP)
MOV #EF9001,(SP)
MOV #2,(SP)
MOV SP,R0
TRAP C$PNTB
ADD #6,SP
```

2176

```
PRINTX #EF9002,R4 ;REPORT THE LINE NUMBER OF THE CODE.
```

012576 010446
012600 012746 004537
012604 012746 000002
012610 010600
012612 104415
012614 062706 000006

```
MOV R4,-(SP)
MOV #EF9002,-(SP)
MOV #2,-(SP)
MOV SP,R0
TRAP C$PNTX
ADD #6,SP
```

2177

```
PRINTX #EF9003,R2 ;REPORT THE CODE WHICH WAS FOUND.
```

012620 010246
012622 012746 004611
012626 012746 000002
012632 010600
012634 104415
012636 062706 000006

```
MOV R2,(SP)
MOV #EF9003,(SP)
MOV #2,(SP)
MOV SP,R0
TRAP C$PNTX
ADD #6,SP
```

2178

2179 012642
012642
012642 104423

2# : ENDMSG

```
L10012: TRAP C$MSG
```

```

2181 .SBTTL GLOBAL ERROR REPORTING ROUTINE - ER9002 -
2182 ;*****
2183 ;* THIS IS AN ERROR REPORTING SUBROUTINE WHICH IS INTENDED FOR USE IN THE
2184 ;* TRANSMISSION AND RECEPTION TESTS. IT REPORTS THE TYPE OF ERROR WHICH
2185 ;* HAS OCCURRED WHEN INCORRECT DATA IS RECEIVED FROM THE DUT. THIS
2186 ;* ROUTINE ALSO REPORTS THE READ AND EXPECTED DATA VALUES.
2187 ;*
2188 ;* INPUTS: R1 - ADDRESS OF MESSAGE TO PRINT FIRST.
2189 ;* R2 - DATA BYTE READ FROM THE DUT.
2190 ;* R3 - LINE NUMBER MULTIPLIED BY 2.
2191 ;* R4 - EXPECTED DATA BYTE, BIT 15 SET IF "NONE".
2192 ;*
2193 ;* OUTPUTS: A MESSAGES IS PRINTED AT THE OPERATOR CONSOLE.
2194 ;*
2195 ;* CALLING SEQUENCE: INCLUDE THE LABEL "ER9002" AS THE MESSAGE POINTER
2196 ;* PARAMETER IN THE DIAG SUPER ERROR REPORT MACRO CALL.
2197 ;*
2198 ;* COMMENTS: THE MESSAGE IS PRINTED AS BASIC AND EXTENDED ERROR INFORMATION.
2199 ;*
2200 ;* SUBORDINATE ROUTINES USED: PRTLPR.
2201 ;*****
2202
2203 012644 BGNMSG ER9002
2204 012644
2205
2206 ER9002::
2207 ;*
2208 ;* EXIT IF EXTENDED ERROR REPORTING HAS NOT BEEN ENABLED
2209 ;*
2210 BIT #BIT06,OPTION ;EXIT WITH TEST FAILURE MESSAGE IF
2211 BEQ 62$ ;NO EXTENDED ERROR REPORTING HAS BEEN REQUESTED
2212 ;* DURING THE SOFTWARE QUESTIONS.
2213
2214 ASR R3 ;CALCULATE THE LINE NUMBER.
2215 BIC #177400,R2 ;MASK OUT ALL BUT DATA IN READ CHAR.
2216 PRINTB #EF9006,R1,R3 ;PRINT THE FIRST LINE OF THE MESSAGE.
2217
2218 MOV R3,-(SP)
2219 MOV R1,-(SP)
2220 MOV #EF9006,(SP)
2221 MOV #3,-(SP)
2222 MOV SP,R0
2223 TRAP C$PNTB
2224 ADD #10,SP
2225
2226 PRINTX #EF9004,#EM9010,R2 ;PRINT ACTUAL DATA.
2227
2228 MOV R2,-(SP)
2229 MOV #EM9010,(SP)
2230 MOV #EF9004,-(SP)
2231 MOV #3,(SP)
2232 MOV SP,R0
2233 TRAP C$PNTX
2234 ADD #10,SP
2235
2236 TST R4 ;CHECK FOR "NONE" CODE SET IN EXPECTED DATA.
2237 BMI 2$ ;BRANCH TO PRINT "NONE" MESSAGE IF FLAG SET.
2238 PRINTX #EF9004,#EM9009,R4 ;PRINT EXPECTED DATA.
2239
2240 MOV R4,(SP)
2241 MOV #EM9009,(SP)
2242 MOV #EF9004,-(SP)
2243 MOV #3,(SP)

```

```
012756 010600
012760 104415
012762 062706 000010
2219 012766 000412
2220 012770
012770 012746 010623
012774 012746 004670
013000 012746 000002
013004 010600
013006 104415
013010 062706 000006
2221 013014 004767 002266
2222 013020
013020
013020 104423

2$: BR 60$ ;EXIT THIS ROUTINE.
PRINTX #EF9005,#EM9009 ;PRINT MESSAGE INDICATING NO EXPECTED DATA.

60$: JSR PC,PRTLPR ;PRINT CONTENTS OF THE LPR REGISTER.
62$: ENDMSG

MOV SP,R0
TRAP C#PNTX
ADD #10,SP

MOV #EM9009,(SP)
MOV #EF9005,(SP)
MOV #2,-(SP)
MOV SP,R0
TRAP C#PNTX
ADD #6,SP

L10013: TRAP C#MSG
```

2224
2225
2226
2227
2228
2229
2230
2231
2232
2233
2234
2235
2236
2237
2238
2239
2240
2241
2242
2243
2244
2245
2246 013022
013022
2247 013022 012700 000100
2248 013026 046700 167156
2249 013032 001040
2250 013034
013034 012746 010673
013040 012746 004156
013044 012746 000002
013050 010600
013052 104414
013054 062706 000006
2251 013060 005002
2252 013062 016703 167524
2253 013066 005004
2254 013070 000241
2255 013072 006003
2256 013074 103013
2257 013076
013076 016446 002614
013102 010246
013104 012746 004745
013110 012746 000003
013114 010600
013116 104415
013120 062706 000010
2258 013124 012405
2259 013126 005202
2260 013130 005703
2261 013132 001356
2262 013134
013134
013134 104423

```
.SBTTL GLOBAL ERROR REPORTING ROUTINE - ER9004 -
;*****
; THIS IS AN ERROR REPORTING SUBROUTINE WHICH REPORTS ERROR SUMMARIES
; FOR LINES WHICH HAVE EXCEEDED THE SPECIFIED MAXIMUM NUMBER OF
; INDIVIDUAL RECEPTION ERRORS, PROVIDED EXTENDED ERROR REPORTING HAS
; BEEN REQUESTED BY THE OPERATOR.
;
; INPUTS:      R1 - ADDRESS OF MESSAGE TO PRINT FIRST.
;              ERCNTB - LABEL AT BASE OF LINE ERROR COUNTERS TABLE.
;              ERSRFR - "REPORT ERROR SUMMARY FOR LINE" FLAGS.
;
; OUTPUTS:     A MESSAGE IS PRINTED AT THE OPERATOR CONSOLE.
;
; CALLING SEQUENCE:  INCLUDE THE LABEL "ER9004" AS THE MESSAGE POINTER
;                    PARAMETER IN THE DIAG SUPER ERROR REPORT MACRO CALL.
;
; COMMENTS:     THE MESSAGE IS PRINTED AS BASIC AND EXTENDED ERROR INFORMATION.
;              THE CONTENTS OF GPR'S R2, R3, R4, AND R5 ARE DESTROYED.
;
; SUBORDINATE ROUTINES USED: NONE.
;*****
```

```
BGNMSG ER9004
ER9004::
MOV #BIT06,R0 ;TRY TO CLEAR THE
BIC OPTION,R0 ;EXT'D ERROR REPORTING FLAG
BNE 6$ ;EXIT IF FLAG NOT SET.
PRINTB #EF0503,#EM9014 ;REPORT THE SECONDARY ERROR MESSAGE.
MOV #EM9014,-(SP)
MOV #EF0503,-(SP)
MOV #2,-(SP)
MOV SP,R0
TRAP C$PNTB
ADD #6,SP

CLR R2 ;CLEAR THE LINE COUNTER.
MOV ERSRFR,R3 ;GET THE ERROR SUMMARY FLAGS.
CLR R4 ;CLEAR "LINE COUNTER TIMES 2" OFFSET.
2$: CLC ;CLEAR THE CARRY FOR THE FOLLOWING ROTATE.
ROR R3 ;SHIFT ANOTHER ERROR SUMMARY FLAG INTO CARRY.
BCC 4$ ;SKIP PRINTING MESSAGE IF FLAG FOR LINE CLEAR.
PRINTX #EF9010,R2,ERCNTB(R4)
MOV ERCNTB(R4),(SP)
MOV R2,-(SP)
MOV #EF9010,-(SP)
MOV #3,-(SP)
MOV SP,R0
TRAP C$PNTX
ADD #10,SP

4$: MOV (R4)+,R5 ;INCREMENT THE LINE OFFSET BY 2.
INC R2 ;INCREMENT THE LINE COUNTER.
TST R3 ;CHECK THE ERROR SUMMARY FLAGS.
BNE 2$ ;IF MORE FLAGS SET, LOOP TO DO OTHER LINES.

6$: ENDMMSG
L10014: TRAP C$MSG
```

2264
2265
2266
2267
2268
2269
2270
2271
2272
2273
2274
2275
2276
2277
2278
2279
2280
2281
2282

```
.SBT1L GLOBAL ERROR REPORTING ROUTINE ER9101
;*****
;* THIS IS A GENERAL ERROR REPORTING SUBROUTINE WHICH REPORTS A MESSAGE
;* WHICH TAKES A SINGLE, 2 DIGIT DECIMAL ARGUMENT AFTER THE END OF AN
;* ASCII MESSAGE.
;*
;* INPUTS: R1 - VALUE TO BE PRINTED AFTER MSG AS 2 DECIMAL DIGITS.
;* R2 - ADDRESS OF MESSAGE TO PRINT FIRST.
;*
;* OUTPUTS: A MESSAGES IS PRINTED AT THE OPERATOR CONSOLE.
;*
;* CALLING SEQUENCE: INCLUDE THE LABEL "ER9101" AS THE MESSAGE POINTER
;* PARAMETER IN THE DIAG SUPER ERROR REPORT MACRO CALL.
;*
;* COMMENTS: THE MESSAGE IS PRINTED AS BASIC ERROR INFORMATION.
;*
;* SUBORDINATE ROUTINES USED: NONE.
;*****
```

2283 013136
013136

BGNMSG ER9101

ER9101::

2284
2285 013136 012700 000100
2286 013142 046700 167042
2287 013146 001012

```
MOV #BIT06,R0 ;TRY TO CLEAR THE
BIC OPTION,R0 ;EXT'D ERROR REPORTING FLAG
BNE 2$ ;EXIT IF FLAG NOT SET.
```

2288
2289

2290 013150
013150 010146
013152 010246
013154 012746 004721
013160 012746 000003
013164 010600
013166 104414
013170 062706 000010

```
PRINTB #EF9006,R2,R1 ;REPORT THE STRING FOLLOWED BY THE NUMBER.
```

```
MOV R1,(SP)
MOV R2,(SP)
MOV #EF9006,(SP)
MOV #3,(SP)
MOV SP,R0
TRAP C$PNTB
ADD #10,SP
```

2291

2292 013174
013174
013174 104423

2\$: ENDMSG

L10015:

```
TRAP C$MSG
```


2294
2295
2296
2297
2298
2299
2300
2301
2302
2303
2304
2305
2306
2307
2308
2309
2310
2311
2312
2313
2314
2315 013176
013176
2316 013176 004567 170656
013176
2317
2318 013202 012700 000100
2319 013206 046700 166776
2320 013212 001064
2321
2322 013214
013214 010146
013216 012746 004156
013222 012746 000002
013226 010600
013230 104414
013232 062706 000006
2323 013236 012703 002412
2324 013242 012705 011257
2325 013246 012301
2326 013250 012304
2327 013252 004767 000056
2328 013256 020302
2329 013260 103772
2330
2331
2332
2333
2334
2335
2336 013262 020227 002606
2337 013266 001036
2338 013270 005762 000002
2339 013274 001433
2340 013276 012301
2341 013300 011304
2342 013302 012705 011307

```
.SBTTL GLOBAL ERROR REPORTING ROUTINE - ER9301 -
;*****
; THIS IS AN ERROR REPORTING SUBROUTINE WHICH PRINTS ANY BMP CODES
; THAT ARE FOUND IN THE BMP CODE QUEUE, TOGETHER WITH THE NUMBER OF
; THE TEST THAT WAS EXECUTING AT THE TIME THE BMP CODE WAS LOGGED.
; PROVIDED EXTENDED ERROR REPORTING HAS BEEN ENABLED.
;
; INPUTS:      R1 - THE ADDRESS OF THE FIRST MESSAGE TO BE REPORTED.
;              R2 - THE ADDRESS OF THE NEXT EMPTY CELL IN THE QUEUE.
;
; OUTPUTS:     THE TEST NUMBER FOLLOWED BY THE BMP CODE ARE PRINTED AT THE
;              OPERATOR CONSOLE.
;
; CALLING SEQUENCE:  INCLUDE THE LABEL "ER9301" AS THE MESSAGE POINTER
;                    PARAMETER IN THE DIAG SUPER ERROR REPORT MACRO CALL.
;
; COMMENTS:     THE MESSAGE IS PRINTED AS BASIC ERROR INFORMATION.
;
; SUBORDINATE ROUTINES USED: NONE.
;*****
                BGNMSG ER9301
                ER9301::
                SAVE                ;SAVE THE GPRS ON THE STACK.
                JSR R5,PREG05      ;CALL REGISTER SAVE SUBRT.
                MOV #BIT06,R0      ;TRY TO CLEAR THE
                BIC OPTION,R0      ;EXT'D ERROR REPORTING FLAG
                BNE 60$            ;EXIT IF FLAG NOT SET.
                PRINTB #EF0503,R1  ;REPORT UNEXPECTED BMP CODES FOUND
                MOV R1,-(SP)
                MOV #EF0503,(SP)
                MOV #2,(SP)
                MOV SP,R0
                TPAP C$PNTB
                ADD #6,SP
                MOV #BMPQ08,R3     ;GET THE START ADDRESS OF THE BMP CODE QUEUE.
                MOV #EM9302,R5     ;GET THE MESSAGE TO BE REPORTED.
2$:             MOV (R3)+,R1       ;GET THE NUMBER OF THE TEST THAT WAS EXECUTING.
                MOV (R3)+,R4       ;GET BMP CODE THAT WAS REPORTED OFF THE QUEUE.
                JSR PC,50$         ;GO REPORT THE BMP CODE.
                CMP R3,R2         ;CHECK IF ALL CODES HAVE BEEN REPORTED.
                BLO 2$            ;IF IT IS NOT THE LAST BMP CODE THEN LOOP.
;
; CHECK IF OVERFLOW HAS OCCURRED.
; THE CONDITIONS FOR OVERFLOW ARE: THE POINTER CONTAINS THE ADDRESS OF THE
; LAST CELL IN THE QUEUE, AND A BMP CODE HAS ALREADY BEEN WRITTEN INTO THAT
; CELL.
;
                CMP R2,#BMPQ0E-4  ;CHECK IF THE POINTER IS AT THE LAST LOCATION.
                BNE 60$           ;EXIT IF NOT AT THE LAST LOCATION.
                TST 2(R2)         ;CHECK FOR A BMP CODE IN THE LAST CELL
                BEQ 60$           ;EXIT IF NO OVERFLOW HAS OCCURED, CELL EMPTY.
                MOV (R3)+,R1     ;GET THE TEST NUMBER OFF THE QUEUE.
                MOV (R3),R4      ;GET THE BMP CODE OFF THE QUEUE.
                MOV #EM9303,R5   ;SELECT THE MESSAGE TO BE REPORTED.
```


2353
2361
2362
2363
2364
2365
2366

.SBTTL GLOBAL SUBROUTINES SECTION

;++
; THE GLOBAL SUBROUTINES SECTION CONTAINS THE SUBROUTINES
; THAT ARE USED IN MORE THAN ONE TEST.
;--

2368
2369
2370
2371
2372
2373
2374
2375
2376
2377
2378
2379
2380
2381
2382
2383
2384
2385
2386
2387
2388
2389
2390
2391
2392
2393
2394
2395
2396 013370
013370 004567 170464
2397
2398
2399
2400
2401
2402
2403 013374 010400
2404 013376 005100
2405 013400 040002
2406 013402 016705 166650
2407
2408
2409
2410
2411
2412
2413 013406 000241
2414 013410 006003
2415 013412 103006
2416 013414 010577 166606
2417 013420 011100
2418 013422 040400
2419 013424 050200
2420 013426 010011
2421 013430 005205
2422 013432 005703
2423 013434 001365

```

.SBTTL GLOBAL SUBROUTINE                                ALTFLD
... ..
; - ALTER DEVICE REGISTER FIELDS ROUTINE -
; THIS SUBROUTINE ALTERS THE SPECIFIED FIELD OF THE SPECIFIED DEVICE
; REGISTER FOR THE SPECIFIED LINES. THIS ROUTINE CAN BE USED TO SET
; OR CLEAR BITS WITHIN SELECTED FIELDS OF SELECTED REGISTERS.
; USE EXAMPLES:  SET RX.BAUD.RATE FIELDS ON LINES 3 AND 6.
;                CLEAR TX.DMA BITS ON ALL LINES.
;
; INPUTS:  R1 - ADDRESS OF THE REGISTERS TO ALTER.
;          R2 - BIT FIELDS SET TO DESIRED STATES.
;          R3 - BIT MAP OF LINES FOR WHICH TO ALTER REGISTER.
;          R4 - MASK OF BITS TO ALTER (1 INDICATES CHANGE BIT).
;          CSRA - CONTAINS THE ADDRESS OF THE DEVICE CSR.
;          IESTAT - SAVED STATES OF THE INTERRUPT ENABLE BITS.
;
; OUTPUTS:  DEVICE REGISTERS - SPECIFIED REGISTER FIELDS ALTERED.
;          CSR IND.ADR.REG FIELD - DESTROYED.
;
; CALLING SEQUENCE:  JSR  PC,ALTFLD
;
; COMMENTS:  THIS ROUTINE READS THE SPECIFIED REGISTERS FOR ALL LINES
;            WITH NUMBERS LOWER THAN THE HIGHEST SPECIFIED LINE.
;            THIS ROUTINE DOES NOT READ THE CSR.
;
; SUBROUTINES CALLED:  NONE.
; - - - - -
ALTFLD:: SAVE
;          JSR  R5,PREG05 ;SAVE CONTENTS OF GPRS R0 THRU R5.
;          ;CALL REGISTER SAVE SUBRT.
;
; SET UP TO LOOP FOR EACH LINE:
;   PREPARE THE WORD TO BE ORED INTO THE REGISTER CONTENTS.
;   SET UP THE WORD TO WRITE INTO THE IND.ADR.REG FIELD OF THE CSR.
;
;   MOV  R4,R0 ;CALCULATE THE NEW CONTENTS OF THE
;   COM  R0 ; REGISTER FIELDS WHICH ARE TO BE
;   BIC  R0,R2 ; ALTERED BY THIS ROUTINE.
;   MOV  IESTAT,R5 ;SET UP TO WRITE IND.ADR.REG FIELD TO 0.
;
; LOOP ONCE FOR EACH LINE, ALTERING THE SPECIFIED FIELD IN THE SPECIFIED
; REGISTER IF THE LINE HAS BEEN SELECTED FOR ALTERING.
; EXIT THE LOOP IF NO MORE LINES TO ALTER, OR IF WE HAVE ALTERED THE MAX
; ALLOWABLE NUMBER OF LINES (AS SPECIFIED BY NUMLNS).
;
;   CLC
;   ROR  R3 ;PREPARE FOR ROTATE, "TST R5" DOES THIS BELOW.
;   BCC  41 ;GET THE LINE SELECT BIT FOR THIS LINE.
;           ;SKIP SETUP IF LINE IS NOT SELECTED.
;   MOV  R5,DCSRA ;SET OUT CSR IND.ADR.REG FIELD TO THIS LINE.
;   MOV  (R1),R0 ;GET THE PRESENT CONTENTS OF THE REG TO ALTER.
;   BIC  R4,R0 ;CLEAR THE BIT FIELDS WE ARE TO ALTER.
;   BIS  R2,R0 ;OR IN THE NEW STATES OF THE FIELDS.
;   MOV  R0,(R1) ;WRITE THE NEW REGISTER CONTENTS TO THE REG.
;   INC  R5 ;SET LINE NUMBER TO THE NEXT LINE.
;   TST  R3 ;CHECK FOR UNHANDLED LINES, CLEAR CARRY FLAG.
;   BNE  21 ;LOOP IF SELECTED LINE(S) IS NOT HANDLED.
;
; 21:
;
; 41:

```


2428
 2429
 2430
 2431
 2432
 2433
 2434
 2435
 2436
 2437
 2438
 2439
 2440
 2441
 2442
 2443
 2444
 2445
 2446
 2447
 2448
 2449
 2450
 2451
 2452
 2453 013442
 013442 004567 170412
 2454 013446 126727 166550 000002
 2455 013454 001411
 2456
 2457
 2458
 2459 013456 005005
 2460 013460 010565 003750
 2461 013464 005205
 2462 013466 005205
 2463 013470 020527 000040
 2464 013474 002771
 2465 013476 000411
 2466
 2467
 2468
 2469 013500 012701 004030
 2470 013504 012702 003750
 2471 013510 112122
 2472 013512 105022
 2473 013514 020227 004010
 2474 013520 002773
 2475
 2476
 2477
 2478 013522 012701 003750
 2479 013526 012702 004010
 2480 013532 012103
 2481 013534 006203
 2482 013536 110322
 2483 013540 020127 004010

```

.SBTTL GLOBAL SUBROUTINE
ASLNTL
;*****
;* - SETUP ASSOCIATED LINE NUMBER TABLES ROUTINE -
;* THIS ROUTINE SETS UP THE TWO TABLES WHICH ARE CONTAIN INFORMATION
;* ABOUT THE TX/RX LINE WHICH IS ASSOCIATED WITH A PARTICULAR RX/TX
;* LINE. ONE TABLE IS A TABLE OF WORDS WHICH CONTAINS WORD OFFSET
;* VALUES AND THE OTHER TABLE IS A TABLE OF BYTES WHICH CONTAINS
;* LINE NUMBER VALUES.
;*
;* INPUTS: LOPBCK - STORAGE FOR THE TYPE OF LOOPBACK ON THE DUT.
;* NUMLNS - EQUATED TO THE NUMBER OF LINES ON THE DUT.
;* STGTRB - LABEL AT BASE OF STAGGERED LINE ASSOCIATION TBL.
;* TXRLNB - LABEL AT BASE OF BYTE TX/RX LINE NUMBER TABLE.
;* TXRXLB - LABEL AT BASE OF WORD TX/RX LINE NUMBER TABLE.
;* TXRXLE - LABEL AT END OF WORD TX/RX LINE NUMBER TABLE.
;*
;* OUTPUTS: TXRXL, TXRLN - TABLES INITIALIZED FOR SELECTED LOOPBACK.
;*
;* CALLING SEQUENCE: JSR PC.ASLNTL
;*
;* COMMENTS:
;*
;* SUBORDINATE ROUTINES CALLED: NONE.
;*****
ASLNTL:: SAVE ;SAVE CONTENTS OF GPRS R0 THRU R5.
R5,PREG05 ;CALL REGISTER SAVE SUBRT.
CMPB LOPBCK,#2 ;TEST FOR STAGGERED LOOPBACK.
BEQ 4$ ;GO SET UP STAGGERED TABLE IF STAGGERED LPBCK.
;
; SET UP THE WORD TABLE FOR NON-STAGGERED LOOPBACK.
;-
2$: CLR R5 ;CLEAR THE LINE COUNTER
MOV R5, TXRXLB(R5) ;SET UP A WORD OF THE TABLE.
INC R5
INC R5 ;SET LINE COUNTER TO NEXT LINE OFFSET.
CMP R5,#2*NUMLNS ;TEST FOR ALL LINES DONE.
BLT 2$ ;LOOP UNTIL ALL LINES DONE.
BR 8$ ;GO SET UP THE BYTE TABLE.
;
; SET UP THE WORD TABLE FOR STAGGERED LOOPBACK.
;-
4$: MOV #STGTRB,R1 ;SET UP THE SOURCE POINTER.
MOV #TXRXLB,R2 ;SET UP THE DESTINATION POINTER.
6$: MOVB (R1)+,(R2)+ ;MOVE A BYTE INTO THE TABLE.
CLRB (R2)+ ;CLEAR THE UPPER BYTE OF WORD TABLE ENTRY.
CMP R2,#TXRXLE ;COMPARE POINTER WITH END ADR OF TABLE.
BLT 6$ ;LOOP IF NOT AT END YET.
;
; SET UP THE BYTE TABLE BASED ON THE WORD ASSOCIATION TABLE.
;-
8$: MOV #TXRXLB,R1 ;SET UP THE SOURCE POINTER.
MOV #TXRLNB,R2 ;SET UP THE DESTINATION POINTER.
10$: MOV (R1)+,R3 ;GET THE WORD OFFSET VALUE FROM WORD TABLE.
ASR R3 ;DIVIDE BY 2 TO GET LINE NUMBER VALUE.
MOVB R3,(R2)+ ;LOAD THE BYTE LINE NUMBER INTO TABLE.
CMP R1,#TXRXLE ;COMPARE SOURCE POINTER WITH ADR OF TABLE END.

```

2484 013544 002772
2485
2486 013546
013546 004736
2487 013550 000207

BLT 10\$;LOOP IF NOT AT END OF TABLE YET.
60\$: PASS ;RESTORE GPRS.
RTS PC JSR PC,B(SP)+ ;RETURN TO PREG05 SUBRT.

```

2489 .SBTTL GLOBAL SUBROUTINE CALMSL
2490 :* *****
2491 :* - CALIBRATE MILLI SECOND LOOP COUNT SUBROUTINE *****
2492 :* THIS SUBROUTINE CALIBRATES THE TIMING LOOP WHICH IS USED IN THE MSLOOP
2493 :* ROUTINE. THIS SUBROUTINE CALCULATES A VALUE FOR THE MSLCNT VARIABLE
2494 :* WHICH IS THE NUMBER OF SOFTWARE LOOPS WHICH TAKES 1 MS TO EXECUTE IN
2495 :* THE MSLOOP ROUTINE. THIS ROUTINE CALIBRATES THE COUNT BY USING THE
2496 :* LINE TIME CLOCK (LTC), SO IF NO LTC IS AVAILABLE THE DEFAULT VALUE FOR
2497 :* THE DELAY COUNT MUST BE USED.
2498 :*
2499 :*
2500 :* INPUTS: MSLCNT - DEFAULT 1 MS DELAY LOOP COUNT VALUE, OR
2501 :* VALUE FROM PREVIOUS CALIBRATION.
2502 :* MSTICK - NUMBER OF MS PER LTC CLOCK TICK.
2503 :* TIMER1 - TIMER COUNTER CHANGED BY LTC INTERRUPT SERVICE RTN.
2504 :* CLKHRZ - NUMBER OF LTC CLICKS PER SECOND (50 OR 60).
2505 :*
2506 :* OUTPUTS: CARRY - SET IF LTC IS AVAILABLE, AND NEW CALIBRATION PERFORMED.
2507 :* MSLCNT - NEW 1 MS DELAY LOOP COUNT VALUE IF LTC AVAILABLE, OR
2508 :* UNCHANGED IF NO LTC IS AVAILABLE.
2509 :*
2510 :* CALLING SEQUENCE: JSR PC,CALMSL
2511 :*
2512 :* COMMENTS:
2513 :*
2514 :* SUBORDINATE ROUTINES CALLED: UNSDIV,OOPS.
2515 :*
2516 :* *****
2517 013552 CALMSL:: SAVE ;SAVE CONTENTS OF GPRS R0 THRU R5.
013552 004567 170302 JSR R5,PREGOS ;CALL REGISTER SAVE SUBRT.
2518 013556 005067 000210 CLR 62# ;CLEAR THE 2ND TIME FLAG.
2519 :*
2520 :* SYNCHRONIZE WITH THE LTC.
2521 :*
2522 013562 012705 000001 2# : MOV #1,R5 ;SET OUTER LOOP COUNTER TO 1 LOOP.
2523 : ;INCREASE THE VALUE LOADED INTO THIS COUNTER IF THE <<<
2524 : ;FOLLOWING LOOP FAILS ON FUTURE, FASTER PROCESSORS. <<<
2525 013566 005000 CLR R0 ;CLEAR THE WAIT FOR CLOCK INT COUNTER.
2526 013570 012767 000001 166516 MOV #1,TIMER1 ;SET UP COUNT OF 1 TO SYNCH WITH LTC.
2527 013576 005767 166512 4# : TST TIMER1 ;CHECK FOR COUNTER HAVING GONE TO ZERO.
2528 013602 001410 BEQ 6# ;JUMP OUT OF LOOP IF LTC HAS INTERRUPTED.
2529 013604 005200 INC R0 ;COUNT THIS ITERATION OF THE INNER LOOP.
2530 013606 001373 BNE 4# ;LOOP IF COUNTER HAS NOT TURNED OVER.
2531 013610 005305 DEC R5 ;DECREMENT THE INNER LOOP COUNTER.
2532 013612 003371 BGT 4# ;LOOP IF OUTER LOOP COUNT NOT UP.
2533 :*
2534 :* IF WE GOT NO LTC INTERRUPT, INDICATE THAT THERE IS NO LTC AVAILABLE.
2535 :* LTC MUST BE FLAKEY, OR NOT REALLY AN LTC AT ALL.
2536 :*
2537 013614 005067 166472 CLR CLKHRZ ;CLEAR LTC FREQUENCY WORD TO INDICATE NO LTC.
2538 013620 000241 CLC ;INDICATE FAILURE FOR RETURN.
2539 013622 000461 BR 60# ;BYPASS THE FOLLOWING CALIBRATION PROCEDURES.
2540 :*
2541 :* WE ARE NOW SYNCHRONIZED WITH THE LTC.
2542 :* SET UP FOR THE CALIBRATION LOOP.
2543 :*
2544 013624 012704 002314 6# : MOV #TIMER1,R4 ;WILL TEST TIMER1 IN THE LOOP BELOW.

```



```
2545 013630 005001          CLR    R1          ;CLEAR THE OUTER LOOP COUNTER.
2546 013632 005002          CLR    R2          ;INDICATE TO CHECK ALL BITS OF TIMER1.
2547 013634 005003          CLR    R3          ;INDICATE TO CHECK FOR TIMER1 CLEAR.
2548 013636 012714 000001    MOV    #1,(R4)     ;LOAD TIMER1 WITH COUNT OF 1.
2549
2550 013642 016705 166460    8$:   MOV    MSLCNT,R5 ;LOAD MS LOOP COUNT.
2551 013646 011400          10$:  MOV    (R4),R0     ;GET THE TIMER1 VALUE.
2552 013650 010067 000120    MOV    R0,64#     ;SAVE WORD (LIKE IN THE REAL LOOP).
2553 013654 040200          BIC    R2,R0      ;LEAVE ALL THE BITS.
2554 013656 020003          CMP    R0,R3      ;COMPARE AGAINST ZERO.
2555 013660 000261          SEC                ;SET CARRY IN CASE OF SUCCESS.
2556 013662 001406          BEQ    12#        ;EXIT LOOP IF TIMER1 HAS CLEARED.
2557 013664 005305          DEC    R5         ;COUNT DOWN THE INSIDE MS LOOP COUNT.
2558 013666 001367          BNE    10#        ;LOOP IF MS NOT UP.
2559 013670 005301          DEC    R1         ;DECREMENT THE MS TIME COUNT.
2560 013672 001363          BNE    8#         ;KEEP LOOPING.
2561 013674 004767 001160    JSR    PC,00PS    ;WE OVERFLOWED, SOMETHING IS WRONG, ABORT.
2562
2563 ;*
2564 ; WE HAVE NOW HAVE LOOP COUNT INFORMATION FOR ONE CLOCK TICK.
2565 ; WE HAVE NEGATIVE OF NUMBER OF OUTER LOOPS IN R1, EACH IS MSLCNT INNER LOOPS.
2566 ; WE HAVE THE PORTION OF THE LAST OUTER LOOP NOT EXECUTED, IN R5.
2567 ; NOW WE CALCULATE THE TOTAL NUMBER OF INNER LOOPS EXECUTED.
2568 013700 005401          ;-
2569 013702 016702 166420    12$:  NEG    R1         ;GET NUMBER OF OUTER LOOPS.
2570 013706 010203          MOV    MSLCNT,R2  ;GET THE NUMBER OF INNER LOOPS PER OUTER LOOP.
2571 013710 160502          MOV    R2,R3      ;COPY NUMBER OF LOOPS FOR MULTIPLY.
2572 013712 010204          SUB    R5,R2      ;CALC # OF INNER LOOPS DONE IN LAST OUTER LOOP
2573 013714 005005          MOV    R2,R4      ; AND ADD TO ACCUMULATOR LSWORD.
2574 013716 005301          CLR    R5         ;CLEAR ACCUMULATOR MSWORD.
2575 013720 100403          14$:  DEC    R1         ;CHECK R1 FOR 0 CONDITION
2576 013722 060304          BMI    16#        ; SKIP MULTIPLICATION IF ZERO
2577 013724 005505          ADD    R3,R4      ;MULTIPLY NUMBER OF INNER
2578 013726 000773          ADC    R5         ; LOOPS PER OUTER LOOP BY
2579 ;*
2580 ; DIVIDE THE TOTAL NUMBER OF INNER LOOPS BY THE NUMBER OF MS PER LTC TICK.
2581 ;-
2582 013730 016701 166370    16$:  MOV    MSTICK,R1  ;# OF MS PER LTC TICK IS DIVISOR.
2583 013734 010403          MOV    R4,R3      ;LSWORD OF LOOP COUNT IS LSWORD OF DIVIDEND.
2584 013736 010502          MOV    R5,R2      ;MSWORD OF LOOP COUNT IS MSWORD OF DIVIDEND.
2585 013740 004767 003336    JSR    PC,UNSDIV  ;DIVIDE NUMBER OF LOOPS BY MS PER LTC TICK.
2586 013744 103402          BCS    18#        ;BYPASS OOPS IF WE'RE OK.
2587 013746 004767 001106    JSR    PC,00PS    ;CLOCK ROUTINES ARE NOT LONG ENOUGH, OR BUG.
2588 013752 010167 166350    18$:  MOV    R1,MSLCNT ;SET NEW VALUE FOR MS LOOP COUNT.
2589 013756 005167 000010    COM    62#        ;SET THE 2ND ITERATION FLAGS IF 1ST ITERATION.
2590 013762 001277          BNE    2#         ;BRANCH IF ONLY ONE ITERATION DONE.
2591 013764 000261          SEC                ;SET THE SUCCESS FLAG FOR EXIT.
2592
2593 013766          60$:  PASS          ;RESTORE GPRS,
2594 013766 004736          RTS    PC        ;RETURN TO PREG05 SUBRT.
2595 013770 000207          JSR    PC,00PS    ; CARRY - SUCCESS FLAG. SET IF SUCCESS.
2596 013772 000000          62$:  .WORD    0
2597 013774 000000          64$:  .WORD    0
;2ND CALIBRATION ITERATION FLAGS.
;DUMMY WORD FOR STORAGE OF THE READ WORD.
```

```

2599 .SBTTL GLOBAL SUBROUTINE                                CHKBMP
2600 ;** *****
2601 ;* - CHECK IF CHARACTER IS A BMP CODE
2602 ;* THIS SUBROUTINE IS USED TO CHECK FOR BMP CODES.
2603 ;* IF A BMP CODE IS DETECTED, IT WILL BE SAVED ON THE QUEUE TO BE REPORTED
2604 ;* LATER. THE CARRY IS USED AS A FLAG TO INDICATE A CODE HAS BEEN FOUND.
2605 ;*
2606 ;* INPUTS:      R2 - CONTAINS THE DATA TO BE CHECKED.
2607 ;*
2608 ;* OUTPUTS:     R1 - CONTAINS THE MESSAGE TO BE REPORTED.
2609 ;* ERRBLK - CONTAINS THE ERROR REPORTING ROUTINE.
2610 ;* CARRY BIT IS USED TO INDICATE A BMP CODE FOUND, CARRY SET.
2611 ;*
2612 ;* CALLING SEQUENCE:  JSR    PC,CHKBMP
2613 ;*
2614 ;* COMMENTS:
2615 ;*
2616 ;* SUBORDINATE ROUTINES CALLED: SAVBMP.
2617 ;-- *****
2618
2619 013776 013776 004567 170056      CHKBMP:: SAVE
2620 014002 012700 170301          JSR    R5,PREG05 ;SAVE CONTENTS OF GPRS R0 THRU R5.
2621 014006 040200                MOV    #170301,R0 ;R5,PREG05 ;CALL REGISTER SAVE SUBRT.
2622 014010 001011                BIC    R2,R0 ;SET UP THE FLAGS OF A BMP CODE.
2623 014012 004767 002462        BNE    2$ ;TRY TO CLEAR THE BMP CODE FLAGS.
2624 014016 012701 006401        JSR    PC,SAVBMP ;IF NOT A BMP CODE, EXIT WITH FAILURE.
2625 014022 012767 012020 170026 MOV    #EM5303,R1 ;SAVE THE BMP CODE ON THE QUEUE.
2626 014030 000261                MOV    #ER1603,ERRBLK ;PASS THE MESSAGE TO BE REPORTED.
2627 014032 000401                SEC    ;SELECT THE CORRECT ERROR REPORTING ROUTINE.
2628 014034 000241                BR    60$ ;PASS FLAG TO INDICATE SUCCESS, BMP CODE FOUND.
2629 014036 010166 000004        2$:   CLC    ;EXIT.
2630 014036 004736                60$:  PASS   R1 ;PASS FLAG TO INDICATE FAILURE.
2631 ;* R1,R1SL0T(SP) ;RESTORE GPRS, EXCEPT
2632 014044 000207                MOV    R1,R1SL0T(SP) ;PUT R1 IN STACK SLOT.
2633 ;* JSR    PC,B(SP) ;RETURN TO PREG05 SUBRT.
2634 ;* R1 - CONTAINS THE ADDRESS OF ERROR MESSAGE.
2635 ;* CARRY BIT - SET INDICATES SUCCESS.
2636 RTS    PC

```

2634
2635
2636
2637
2638
2639
2640
2641
2642
2643
2644
2645
2646
2647
2648
2649
2650
2651
2652
2653
2654
2655
2656
2657
2658
2659
2660
2661
2662
2663
2664
2665
2666
2667
2668
2669
2670
2671
2672
2673
2674
2675
2676
2677
2678
2679
2680
2681
2682
2683
2684
2685
2686
2687
2688
2689

014046			
014046	004567	170006	
014052	010204		
014054	005204		
014056	006304		
014060	006304		
014062	160104		
014064	012701	000005	
014070	010203		
014072	005002		
014074	004767	003202	
014100	010302		
014102	010305		
014104	160103		
014106	060105		
014110	062705	000002	
014114	020504		
014116	002402		
014120	020304		
014122	002417		

```

.SBTTL GLOBAL SUBROUTINE                                CKRXTM
; * *****
; * - CHECK RX-INT DELAY TIME
; * THIS SUBROUTINE IS USED IN THE RXTIMER TEST AND IT CHECKS THAT THE
; * RX-INT WAS DELAYED BY +/- 20% OF THE VALUE SET IN THE RXTIMER REG.
; * IF THE ACTUAL DELAY TIME IS NOT WITHIN THIS MARGIN THEN AN ERROR
; * IS REPORTED.
; *
; * INPUTS:      R1 - REMAINING NUMBER OF MILLI SECS OF THE TIME OUT VALUE
; *              THE TIME-OUT VALUE BEING 4*(RXTIMER VALUE + 1).
; *              R2 - RXTIMER VALUE.
; *              ERRNBR - SET TO ERROR NUMBER OF FIRST ERROR IN THIS ROUTINE.
; *              ERRBLK - SET UP BY THIS ROUTINE.
; *              EXOERR - "EXIT ON ERROR" FLAG.
; *
; * OUTPUTS:     ERRBLK - MAY BE ALTERED.
; *              EXOERR - "EXIT ON ERROR" FLAG SET IF AN ERROR DETECTED AND
; *                      EXTENDED ERROR REPORTING NOT REQUESTED.
; *
; * CALLING SEQUENCE:  JSR    PC,CKRXTM
; *
; * COMMENTS:      THIS ROUTINE REPORTS ONE ERROR WITH THE NUMBER IN ERRNBR.
; *
; * SUBORDINATE ROUTINES USED: ER5901,UNSDIV.
; * *****
CKRXTM:: SAVE
; *
; * JSR    R5,PREG05 ;CALL REGISTER SAVE SUBRT.
; * MOV    R2,R4    ;COPY THE RXTIMER VALUE.
; * INC    R4       ;CALCULATE THE TIME-OUT VALUE,
; * ASL    R4       ; AS 4*(RXTIMER VALUE+1)
; * ASL    R4
; * SUB    R1,R4    ;CALCULATE THE NUMBER OF MS THE RX-INT WAS DELAYED.
; *
; * CALCULATE 20% OF THE RXTIMER VALUE.
; *
; * MOV    #5,R1    ;PASS THE DIVISOR TO THE SUBR.
; * MOV    R2,R3    ;LOAD THE RXTIMER VALUE INTO THE LSW OF THE DIVIDEND.
; * CLR    R2       ;CLEAR THE MSW OF THE DIVIDEND.
; * JSR    PC,UNSDIV ;DIVIDE THE RXTIMER VALUE BY 5.
; * MOV    R3,R2    ;RESTORE THE RXTIMER VALUE.
; * MOV    R3,R5    ;COPY THE RXTIMER VALUE.
; * SUB    R1,R3    ;REDUCE IT BY 20% TO OBTAIN THE LOLIMIT OF THE
; *              ;PERMISSIBLE TIME DELAY.
; * ADD    R1,R5    ;INCREASE THE RXTIMER VALUE BY 20% AND ADD A
; * ADD    #2,R5    ;FURTHER 2 MS TO OBTAIN THE HILIMIT OF THE
; *              ;PERMISSIBLE TIME DELAY.
; *
; * CHECK IF THE RX-INT OCCURED WITHIN THE CALCULATED PERMISSIBLE LIMITS.
; *
; * CMP    R5,R4    ;COMPARE HILIM WITH ACTUAL RX-INT DELAY.
; * BLT    #2       ;REPORT THE ERROR IF THE DELAY WAS TOO LONG.
; * CMP    R3,R4    ;COMPARE LOLIM WITH ACTUAL RX-INT DELAY.
; * BLT    #60      ;AVOID ERROR IF DELAY WAS WITHIN THE LIMITS.
; *
; * REPORT THE ERROR, INCORRECT DELAY ON RX INT.
; *
; *

```


2704
2705
2706
2707
2708
2709
2710
2711
2712
2713
2714
2715
2716
2717
2718
2719
2720
2721
2722
2723
2724
2725
2726
2727 014166
014166 004567 167666
2728 014172 005067 166102
2729 014176 011011
2730 014200 005767 166074
2731 014204 000261
2732 014206 001401
2733 014210 000241
2734 014212
014212 004736
2735 014214 000207

```

.SBTTL GLOBAL SUBROUTINE                                CKTRAP
;*****
;* CHECK TRAP ROUTINE -
;* THIS SUBROUTINE IS USED TO CHECK FOR A BUS TIME OUT TRAP (004 TRAP)
;* WHICH IS CAUSED BY AN ACCESS TO A NON EXISTENT MEMORY OR I/O LOCATION.
;* IF THE TRAP DOES NOT OCCUR, THIS ROUTINE RETURNS A SUCCESS INDICATION.
;*
;* INPUTS:      R0  SOURCE ADDRESS FOR MOVE.
;*              R1  DESTINATION ADDRESS FOR MOVE.
;*              (R0) - SOURCE FOR THE MOVE.
;*
;* OUTPUTS:     (R1) - WRITTEN TO THE CONTENTS OF (R0).
;*              CARRY FLAG - SET ON RETURN IF NO 004 TRAP DETECTED.
;*              TP4FLG - NONZERO IF TRAP OCCURRED, CLEARED OTHERWISE.
;*
;* CALLING SEQUENCE:  JSR    PC,CKTRAP
;*
;* COMMENTS:      IF THIS SUBROUTINE CAUSES A TRAP, EITHER THE ADDRESS WHICH
;*                IS LABELED ADRPTR WILL BE THE TRAP PC ADDRESS ON THE STACK.
;*
;* SUBORDINATE ROUTINES CALLED: NONE.
;*****
CKTRAP:: SAVE
                CLR    TP4FLG      JSR    R5,PREGOS      ;SAVE CONTENTS OF GPRS R0 THRU R5.
                MOV    (R0),(R1)   ;CLEAR THE 004 TRAP FLAGS.
                TST    TP4FLG      ;PERFORM THE MOVE IN QUESTION.
                SEC    60$         ;CHECK FOR OCCURENCE OF TRAP.
                BEQ    60$         ;INDICATE SUCCESS.
                CLC    60$         ;EXIT WITH SUCCESS IF TRAP DID NOT OCCUR.
                PASS   60$         ;INDICATE FAILURE.
                RTS    PC          JSR    PC,B(SP)        ;RESTORE GPRS.
                ;RETURN TO PREGOS SUBRT.

```

2737
2738
2739
2740
2741
2742
2743
2744
2745
2746
2747
2748
2749
2750
2751
2752
2753
2754
2755
2756
2757
2758
2759
2760
2761
2762
2763
2764
2765 014216
014216 004567 167636
2766
2767
2768
2769
2770 014222 004767 002054
2771 014226 103002
2772
2773
2774
2775 014230 004767 001134
2776
2777 014234
2778 014234
014234 004736
2779
2780 014236 000207

```
.SBTTL GLOBAL SUBROUTINE CLNRST
*****
; * - CLEAN RESET OF THE DEVICE UNDER TEST -
; * THIS SUBROUTINE IS USED TO RESET THE DUT TO A KNOWN STATE.
; * THE DUT'S SELF-TEST IS SKIPPED, AND THE FIFO IS PURGED OF ANY ERROR
; * CODES, ETC.
; * IF THE RESET DOES NOT SUCCESSFULLY COMPLETE, THEN THE CARRY BIT IS
; * PASSED BACK TO THE CALLING ROUTINE (CLEAR).
; *
; * INPUTS: CSRA - CONTAINS THE ADDRESS OF THE CSR
; * TXBFCA - CONTAINS ADDRESS OF DUT DMA BUFFER COUNT REGISTER.
; * ERRNBR - ERROR NUMBER FOR POSSIBLE ERROR REPORT.
; * ERRTABL - ERR TYP, ERNBR, AND ERRMSG SET UP CORRECTLY.
; *
; * OUTPUTS: THE DUT PERFORMS ITS RESET FUNCTION INTO A KNOWN STATE.
; * CARRY - CLEAR INDICATES THE TEST IS TO BE ABORTED.
; * ERRBLK - VALUE MAY BE DESTROYED.
; * IESTAT - TX AND RX INTERRUPT FLAGS ARE CLEARED.
; * TX AND RX INTERRUPT ENABLE BITS IN THE DUT'S CSR ARE CLEARED.
; *
; * CALLING SEQUENCE: JSR PC,CLNRST
; *
; * COMMENTS: THIS SUBROUTINE CAN REPORT ERRORS WITH NUMBERS ERRNBR.
; * THIS ROUTINE DOES NOT DESTROY THE VALUE OF ERRNBR.
; *
; * SUBORDINATE ROUTINES CALLED: DELAY,MSLGET,PUFIFO,RESETT.
*****
CLNRST:: SAVE JSR ;SAVE CONTENTS OF GPRS R0 THRU R5.
R5,PREG05 ;CALL REGISTER SAVE SUBRT.
; *
; * RESET THE DUT.
; * THIS ROUTINE REPORTS ERRORS WITH NUMBERS FROM ERRNBR THRU ERRNBR+2.
; *
; * JSR PC,RESETT ;RESET THE DUT TO A KNOWN STATE.
; * BCC 60$ ;EXIT ROUTINE WITH ABORT TEST INDICATOR.
; *
; * PURGE THE FIFO OF ERROR CODES. SAVE ANY BMP CODES FOUND.
; *
; * JSR PC,PUFIFO ;PURGE THE FIFO.
; *
60$: PASS JSR ;EXIT THE TEST USING RESETT OR PUFIFO STATUS.
;RESTORE GPRS. PASS THE FOLLOWING INTACT:
PC,@(SP). ;RETURN TO PREG05 SUBRT.
;CARRY BIT: IF CLEAR, THEN ABORT THE TEST.
RTS PC
```

2782
2783
2784
2785
2786
2787
2788
2789
2790
2791
2792
2793
2794
2795
2796
2797

2798 014240
014240 004567 157614
2799 014244 012701 000020
2800 014250 005020
2801 014252 005301
2802 014254 001375
2803 014256
014256 004736
2804 014260 000207

```
.SBTTL GLOBAL SUBROUTINE - CLR16W
; * *****
; * CLEAR SIXTEEN WORDS ROUTINE
; * THIS SUBROUTINE CLEARS 16 WORDS STARTING WITH THE SPECIFIED WORD
; *
; * INPUTS: RO - ADDRESS OF THE FIRST WORD TO CLEAR.
; *
; * OUTPUTS: (RO) TO (RO+15) - 16 WORDS OF MEMORY ARE CLEARED TO 0.
; *
; * CALLING SEQUENCE: JSR PC,CLR16W
; *
; * COMMENTS:
; *
; * SUBORDINATE ROUTINES CALLED: NONE.
; *
; * *****
CLR16W:: SAVE
;SAVE CONTENTS OF GPRS R0 THRU R5.
RS,PREG05 ;CALL REGISTER SAVE SUBRT
MOV #16.,R1 ;SET THE LOOP COUNTER TO 16.
2$: CLR (R0)+ ;CLEAR A WORD OF MEMORY.
DEC R1 ;COUNT THIS LOOP.
BNE 2$ ;LOOP IF NOT 16 WORD CLEARED.
60$: PASS ;RESTORE GPRS.
JSR PC,@(SP)+ ;RETURN TO PREG05 SUBRT.
RTS PC
```

2806
2807
2808
2809
2810
2811
2812
2813
2814
2815
2816
2817
2818
2819
2820
2821
2822
2823
2824
2825
2826
2827
2828
2829
2830
2831
2832
2833
2834
2835

014262
014262 004567 167572
014266 010401
014270 012702 177777
014274 005003
014276 012704 014320
014302 004767 000536
014306 103002
014310 004767 000544
014314
014314 004736
014316 000207
014320 177777

```
.SBTTL GLOBAL SUBROUTINE - DELAY
;*****
;*          - DELAY SUBROUTINE -
;* THIS SUBROUTINE IS USED TO DELAY A VARIABLE NUMBER OF MILLI-SECONDS.
;*
;* INPUTS:      R4 - CONTAINS THE NUMBER OF MS TO DELAY.
;*              MSLCNT.
;*
;* OUTPUTS:     NONE.
;*
;* CALLING SEQUFNCE: JSR PC,DELAY
;*
;* COMMENTS:    IF NO HARDWARE CLOCK INTERRUPTS ARE OCCURING, CONTROL-CS WILL
;*              NOT BE HONORED FOR THE DURATION OF THE DELAY.
;*
;* SUBORDINATE ROUTINES CALLED: NONE.
;*****
DELAY:: SAVE
;SAVE CONTENTS OF GPRS R0 THRU R5.
R5,PREG05 ;CALL REGISTER SAVE SUBRT.
MOV R4,R1 ;PASS NUMBER OF MS DELAY AS TIME-OUT VALUE.
MOV #1,R2 ;TELL MSLOOP ROUTINE TO CHECK ALL BITS.
CLR R3 ;TELL MSLOOP RTN TO CHECK FOR ALL BITS CLEAR.
MOV #62$,R4 ;TELL MSLOOP TO CHECK DUMMY NON ZERO WORD.
JSR PC,MSLOOP ;DELAY THE REQUESTED # OF MS.
BCC 60$ ;EXIT ROUTINE IF WE TIMED-OUT.]
JSR PC,OOPS ;IF NO TIME-OUT, BAD PROGRAM OR HOST MACHINE.
PASS ;RESTORE GPRS.
RTS PC ;RETURN TO PREG05 SUBRT.
PC,8(SP)+
60$: .WORD -1 ;DUMMY, NON-ZERO WORD.
62$: .WORD -1
```


2837
2838
2839
2840
2841
2842
2843
2844
2845
2846
2847
2848
2849
2850
2851
2852
2853
2854
2855
2856
2857
2358
2859
2860
2861
2862
2863
2864
2865
2866
2867 014322
014322 004567 167532
2868 014326 012702 002650
2869 014332 004767 000042
2870 014336 103016
2871
2872
2873
2874
2875 014340 005267 167506
2876 014344 012701 170536
2877 014350 016702 165652
2878 014354 004767 003056
2879 014360 103005
2880 014362 012704 000005
2881 014366 004767 177670
2882 014372 000261
2883 014374
014374 004736
2884 014376 000207

```
.SBTTL GLOBAL SUBROUTINE - DMABUF -
;... *****
;
; DMA FROM ADDR BUFBAS -
; THIS SUBROUTINE INITIATES A DMA FROM THE ADDRESS BUFBAS AND WAITS
; FOR IT TO COMPLETE AND THE LAST CHARACTER TO BE RECIEVED. THE LINE
; ON WHICH TO PERFORM THE DMA AND THE NUMBER OF CHARACTERS TO TRANSMIT
; ARE PASSED AS INPUT PARAMETERS.
;
; INPUTS: R1 LINE NUMBER ON WHICH TO PERFORM THE DMA.
; R3 - NUMBER OF CHARACTERS TO TRANSMIT.
; CSRA - CONTAINS THE ADDRESS OF THE CSR.
; ERRNBR - CONTAINS THE ERROR NUMBER OF THE FIRST ERROR
; IN THIS SUBROUTINE.
;
; OUTPUTS: CARRY - SUCCESS FLAG - SET IF DMA COMPLETED SUCCESSFULLY.
; CLEAR IF DMA START BIT FOUND SET OR
; NO TX-ACTION RECIEVED.
; ERRNBR - CONTENTS ALTERED TO INITIAL ERRNBR * 1.
;
; CALLING SEQUENCE: JSR PC,DMABUF
;
; COMMENTS: THIS ROUTINE RETURNS CARRY CLEAR IF AN ERROR OCCURED, WITH
; THE APPROPRIATE ERROR NUMBER IN ERRNBR. A NON-RELATED TEST
; ERROR SHOULD BE REPORTED, UPON RETURN TO THE TEST, IF THE CARRY
; FLAG IS CLEAR. THIS ROUTINE REPORTS ERRORS,
; INITIAL ERRNBR THRU INITIAL ERRNBR * 1.
;
; SUBORDINATE ROUTINES CALLED: DELAY,DODMA,WAIBIS.
; - - - - -
DMABUF:: SAVE
;
; JSR R5,PREG05 ;CALL REGISTER SAVE SUBRT.
; MOV #BUFBAS,R2 ;PASS THE START ADDR OF THE BUFFER TO TX.
; JSR PC,DODMA ;INITIATE THE DMA.
; BCC 60$ ;RETURN WITH FAILURE IF DMA-START BIT FOUND SET.
;
; ; WAIT FOR THE DMA TO COMPLETE I.E A TX-ACTION BEING RETURNED, AND THEN WAIT
; ; FOR THE LAST CHARACTER TO BE RECIEVED.
; - - - - -
; INC ERRNBR ;SET THE ERROR NUMBER TO INITIAL ERRNBR * 1.
; MOV #170536,R1 ;INDICATE TO TEST BIT15 WITH TIME-OUT OF 350 MS
; MOV CSRA,R2 ;PASS THE ADDR OF THE REG TO TEST.
; JSR PC,WAIBIS ;WAIT FOR THE TX-ACTION.
; BCC 60$ ;RETURN WITH FAILURE IF NO TX-ACTION FOUND.
; MOV #5,R4 ;SET THE DELAY OF 5 MS.
; JSR PC,DELAY ;WAIT FOR THE LAST CHARACTER TO BE RECIEVED.
; SEC ;SET THE CARRY FLAG TO INDICATE SUCCESS.
;
60$: PASS
;
; JSR PC,@(SP) ;RETURN TO PREG05 SUBRT.
; RTS PC ;RETURN.
```

2886
2887
2888
2889
2890
2891
2892
2893
2894
2895
2896
2897
2898
2899
2900
2901
2902
2903
2904
2905
2906
2907
2908
2909
2910
2911
2912
2913
2914
2915
2916 014400
014400 004567 167454
2917 014404 012704 000200
2918
2919
2920
2921
2922
2923
2924
2925
2926
2927
2928 014410
014410 104440
014412 010005
2929 014414
014414 012700 000340
014420 104441
2930 014422 056701 165630
2931 014426 010177 165574
2932 014432 105777 165604
2933 014436 000241
2934 014440 100411
2935 014442 010377 165576
2936 014446 010277 165566
2937 014452 110477 165564

```
.SBTTL GLOBAL SUBROUTINE                                DODMA
;*****
;* - INITIATE DMA TRANSMISSION ROUTINE -
;* THIS ROUTINE WRITES THE DMA PARAMETER TO THE SPECIFIED DEVICE AND
;* INITIATES THE DMA TRANSMISSION.
;*
;* INPUTS:      R1 - LINE NUMBER ON WHICH TO INITIATE THE DMA.
;*              R2 - START ADDRESS OF THE DMA BUFFER (16 BIT VIRTUAL).
;*              R3 - CHARACTER COUNT OF THE DMA BUFFER.
;*              CSRA - CONTAINS ADDRESS OF THE DUT CSR.
;*              IESTAT - STORAGE FOR STATES OF THE INTERRUPT ENABLE BITS.
;*              TXAD1A - CONTAINS ADDRESS OF DMA TX BUFFER ADDRESS REG #1.
;*              TXAD2A - CONTAINS ADDRESS OF DMA TX BUFFER ADDRESS REG #2.
;*              TXBFCA - CONTAINS ADDRESS OF DMA CHARACTER COUNT REGISTER.
;*
;* OUTPUTS:     CARRY - SUCCESS FLAG (SET IF DMA_START FOUND CLEAR).
;*              DUT TBUFFAD1 - LS 16 BITS OF DMA BUFFER ADDRESS (INITIALIZED).
;*              DUT TBUFFAD2 - MS 6 BITS OF DMA BUFFER ADDRESS (INITIALIZED).
;*                      DMA_START BIT SET.
;*              DUT TBUFFCT - DMA BUFFER CHARACTER COUNT (INITIALIZED).
;*
;* CALLING SEQUENCE:  JSR      PC,DODMA
;*
;* COMMENTS:      THIS ROUTINE ASSUMES MEMORY MANAGEMENT IS DISABLED AND
;*                CLEARS THE TWO MSB OF THE DMA ADDRESS, I.E. BITS 0 AND 1
;*                OF THE TBUFFAD2 REG.
;*
;* SUBORDINATE ROUTINES CALLED:  NONE.
;*****
DODMA:: SAVE
;SAVE CONTENTS OF GPRS R0 THRU R5.
;CALL REGISTER SAVE SUBRT.
;PREPARE TO CLEAR UPPER 6 BITS OF DMA BUFF ADR.
        MOV     #200,R4
;
; WRITE THE DMA PARAMETERS OUT TO THE DUT DMA REGISTERS.
; DISABLE INTERRUPTS.
; SET UP DUT CSR IND.ADR.REG FIELD.
; WRITE THE DMA TRANSMIT CHARACTER COUNT.
; WRITE THE LEAST SIGNIFICANT 16 BITS OF THE DMA BUFFER START ADDRESS.
; WRITE THE MOST SIGNIFICANT 6 BITS OF THE ADDRESS.
; SETTING THE DMA_START BIT, AND INITIATING THE DMA TRANSMISSION.
6$:    GETPRI  R5          ;GET THE PRESENT PROCESSOR PRIORITY.
;
;          TRAP     C:CPRI
;          MOV     R0,R5
;          MOV     #PRI07,RO
;          TRAP     C:SPRI
        BIS     IESTAT,R1 ;PREPARE FOR SETUP OF LINE NUMBER IN DUT CSR.
        MOV     R1,@CSRA ;SET UP THE DUT CSR IND.ADR.REG FIELD.
        TSTB   @TXAD2A   ;TEST THE DUT DMA_START BIT.
        CLC
;INDICATE FAILURE IN CASE DMA.HO BIT IS SET.
        BMI    60$       ;EXIT WITH FAILURE IF DMA.HO BIT IS SET.
        MOV     R3,@TXBFCA ;WRITE THE DMA CHARACTER COUNT.
        MOV     R2,@TXAD1A ;WRITE THE LS 16 BITS OF BUFFER ADDRESS.
        MOVB   R4,@TXAD2A ;WRITE MS 6 BITS OF ADR AND START DMA Tx.
```

```
2938 014456          SETPRI R5          ;RESTORE THE PROCESSOR PRIORITY.
      014456 010500
      014460 104441
2939 014462 000261          SEC          ;INDICATE SUCCESS.
2940
2941 014464          601: PASS          ;RESTORE GPRS,
      014464 004736          RTS PC      JSR PC,0(SP). ;RETURN TO PREGOS SUBRT.
2942 014466 000207          ; CARRY - SUCCESS FLAG (SET IF SUCCESS).
```

```

2944 .SBTTL GLOBAL SUBROUTINE FINACT .
2945 ;* *****
2946 ;* - FIND FIRST ACTIVE LINE
2947 ;* THIS SUBROUTINE CALCULATES THE NUMBER OF THE FIRST ACTIVE LINE THAT
2948 ;* IS FOUND IN THE ACTIVE LINE BIT MAP ACTLNS.
2949 ;*
2950 ;* INPUTS: ACTLNS - CONTAINS THE ACTIVE LINE BIT MAP.
2951 ;*
2952 ;* OUTPUTS: R1 - CONTAINS THE NUMBER OF THE FIRST ACTIVE LINE.
2953 ;* R5 - CONTAINS THE BIT MAP REPRESENTATION OF THE ACTIVE LINE.
2954 ;* CARRY SET INDICATES SUCCESS.
2955 ;*
2956 ;* CALLING SEQUENCE: JSR PC,FINACT
2957 ;*
2958 ;* COMMENTS:
2959 ;*
2960 ;* SUBORDINATE ROUTINES CALLED: NONE.
2961 ;*
2962 ;* *****
2963 014470 004567 167364 FINACT:: SAVE JSR ;SAVE CONTENTS OF GPRS R0 THRU R5.
;CALL REGISTER SAVE SUBRT.
2964 ;*
2965 ;* FIND AN ACTIVE LINE ON WHICH TO PERFORM THE TEST.
2966 ;*
2967 014474 005001 CLR R1 ;CLEAR THE LINE NUMBER COUNTER.
2968 014476 012703 000020 MOV #NUMLNS,R3 ;GET MAX LINE NUMBER.
2969 014502 016700 165512 MOV ACTLNS,R0 ;GET THE ACTIVE LINE BIT MAP.
2970 014506 012705 000001 MOV #1,R5 ;SET UP A LINE BIT MASK.
2971 014512 030500 28: BIT R5,R0 ;LOOK FOR AN ACTIVE LINE.
2972 014514 001006 BNE 48 ;BRANCH TO BEGIN TEST IF A LINE HAS BEEN FOUND.
2973 014516 006305 ASL R5 ;SHIFT THE BIT MASK FOR THE NEXT LINE.
2974 014520 005201 INC R1 ;INCREMENT THE LINE NUMBER COUNTER.
2975 014522 020103 CMP R1,R3 ;CHECK IF ALL LINES HAVE BEEN TRIED.
2976 014524 002772 BLT 28 ;LOOP TO TRY THE NEXT LINE.
2977 014526 000241 CLC ;CLEAR CARRY BIT, NO ACTIVE LINE FOUND.
2978 014530 000401 BR 608 ;EXIT WITH FAILURE.
2979 014532 000261 48: SEC ;SET CARRY, SUCCESS.
2980
2981 014534 010166 000004 608: PASS R1,R5 ;RESTORE GPRS, EXCEPT
014534 010566 000014 MOV R1,R1SLOT(SP) ;PUT R1 IN STACK SLOT.
014544 004736 MOV R5,R5SLOT(SP) ;PUT R5 IN STACK SLOT.
JSR PC,B(SP) ;RETURN TO PREGOS SUBRT.
2982 ;R1 - CONTAINS THE NUMBER OF FIRST ACTIVE LINE.
2983 ;R5 - CONTAINS THE BIT MAP OF THE ACTIVE LINE.
2984 ;CARRY - SET INDICATES SUCCESS.
2985 014546 000207 RTS PC

```

2987
2988
2989
2990
2991
2992
2993
2994
2995
2996
2997
2998
2999
3000
3001
3002
3003
3004
3005
3006 014550
014550 004567 167304
3007
3008 014554 012702 002650
3009 014560 005003
3010 014562 110322
3011 014564 005203
3012 014566 020227 003250
3013 014572 103773
3014
3015 014574
014574 004736
3016 014576 000207

```
.SBTTL GLOBAL SUBROUTINE                                INDATP
; * * * * *
; * - INITIALISE DATA PATTERN -
; * THIS SUBROUTINE IS USED TO INITIALISE AN INCREMENTAL BYTE DATA PATTERN
; * IN THE GENERAL BUFFER AREA.
; * THE DATA PATTERN WILL BE SEQUENTIAL FROM 0 TO 255 (DECIMAL).
; *
; * INPUTS:      BUFBAS - ADDRESS OF THE START OF THE GENERAL BUFFER AREA.
; *              BUF MID - ADDRESS OF THE 255 TH LOCATION.
; *
; * OUTPUTS:     THE FIRST 255 LOCATIONS OF THE GENERAL BUFFER AREA CONTAIN DATA
; *
; * CALLING SEQUENCE:  JSR      PC,INDATP
; *
; * COMMENTS:
; *
; * SUBORDINATE ROUTINES CALLED: NONE.
; * * * * *
INDATP:: SAVE
; SAVE CONTENTS OF GPRS R0 THRU R5.
; CALL REGISTER SAVE SUBRT.
;
; INITIALIZE THE DATA PATTERN IN THE GENERAL
; DATA BUFFER TO A 256 BYTE PATTERN.
;
; SELECT THE NEXT CHARACTER.
; CHECK IF WE HAVE 256 DATA PATTERNS.
;
; RESTORE GPRS.
; RETURN TO PREGOS SUBRT.
PC,8(SP).
RTS      PC      JSR
```

```

3018 .SBTTL GLOBAL SUBROUTINE INDTPX
3019 ;* *****
3020 ;* - INITIALISE DATA PATTERN WITHOUT XON OR XOFF -
3021 ;* THIS SUBROUTINE IS USED TO INITIALISE AN INCREMENTAL BYTE DATA PATTERN
3022 ;* IN THE GENERAL BUFFER AREA.
3023 ;* THE DATA PATTERN WILL BE FROM 0 TO 255, BUT WILL EXCLUDE THE FOLLOWING
3024 ;* TWO CHARACTERS; (ASCII DC1, DC3) XON AND XOFF. THIS WILL CAUSE THE
3025 ;* LAST TWO DATA CHARACTERS TO BE THE SAME AS THE FIRST TWO.
3026 ;*
3027 ;* INPUTS:      BUFBAS - ADDRESS OF THE START OF THE GENERAL BUFFER AREA.
3028 ;*             BUFMID - ADDRESS OF THE 255 TH LOCATION.
3029 ;*
3030 ;* OUTPUTS:     THE FIRST 255 LOCATIONS OF THE GENERAL BUFFER AREA CONTAIN DATA
3031 ;*
3032 ;* CALLING SEQUENCE:  JSR      PC,INDTPX
3033 ;*
3034 ;* COMMENTS:
3035 ;*
3036 ;* SUBORDINATE ROUTINES CALLED: NONE.
3037 ;*
3038 ;* - - - - -
3039 014600 014600 004567 167254 INDTPX:: SAVE          ;SAVE CONTENTS OF GPRS R0 THRU R5.
;                               JSR      R5,PREG05          ;CALL REGISTER SAVE SUBRT.
3040 ;*
3041 ;* INITIALIZE THE 256 BYTE DATA PATTERN.
3042 ;* ENSURE THE DATA PATTERN IS FREE FROM XON'S OR XOFF'S TO PREVENT ERRORS.
3043 ;* NOTE: THE FIRST TWO CHARACTERS AND THE LAST TWO CHARACTERS WILL BE THE SAME.
3044 ;*
3045 014604 012702 002650      MOV     #BUFBAS,R2      ;INITIALIZE THE DATA PATTERN IN THE GENERAL
3046 014610 005003      CLR     R3              ; DATA BUFFER TO A 256 BYTE PATTERN.
3047 014612 110322      MOVB   R3,(R2)+      ;
3048 014614 105203      INCB   R3              ;SELECT THE NEXT CHARACTER.
3049 014616 122703 000021  CMPB   #21,R3      ;CHECK FOR AN XON CHARACTER.
3050 014622 001001      BNE    4$          ;BRANCH IF CHAR NOT AN XON.
3051 014624 105203      INCB   R3              ;FORCE THE NEXT CHARACTER.
3052 014626 122703 000023  CMPB   #23,R3      ;CHECK FOR AN XOFF CHARACTER.
3053 014632 001001      BNE    6$          ;BRANCH IF NOT AN XOFF CHARACTER.
3054 014634 105203      INCB   R3              ;FORCE THE NEXT CHARACTER.
3055 014636 020227 003250  CMP     R2,#BFMID      ;CHECK IF WE HAVE 256 DATA PATTERNS.
3056 014642 103763      BLO    2$              ;
3057 ;*
3058 014644 014644 004736      60$:  PASS          ;RESTORE GPRS.
;                               JSR      PC,@(SP)+      ;RETURN TO PREG05 SUBRT.
3059 014646 000207      RTS     PC

```

3061
3062
3063
3064
3065
3066
3067
3068
3069
3070
3071
3072
3073
3074
3075
3076
3077
3078
3079
3080
3081
3082
3083
3084
3085 014650
3086 014654
3087 014660
3088 014662
3089 014666
014666
014672
3090 014674

004567 167204
042701 177760
006301
016100 002336
010066 000002
004736
000207

```
.SBTTL GLOBAL SUBROUTINE LINBIT
; * *****
; * - LINE NUMBER TO BIT MAP CONVERSION SUBROUTINE
; * THIS SUBROUTINE IS USED TO GENERATE A BIT MAP (ONE BIT OF 16 SET)
; * BASED ON A LINE NUMBER (RANGE: 1 TO 16). ONLY THE LS 4 BITS OF THE
; * LINE NUMBER WORD ARE USED, THE OTHERS ARE MASKED OUT (SO UNMASKED
; * MSBYTES OF DUT CSRS CAN BE PASSED TO THIS ROUTINE WITHOUT ERROR).
; *
; * INPUTS: R1 - LINE NUMBER (ONLY LS 4 BITS USED, OTHERS DISREGARDED).
; * BITTBL - BASE LABEL OF A 16 WORD BIT TABLE.
; *
; * OUTPUTS: R0 BIT MAP, BIT CORRESPONDING TO LINE NUMBER IS SET:
; * IF LINE NUMBER IS 3, THEN BIT3 IS SET, ETC.
; *
; * CALLING SEQUENCE: JSR PC,LINBIT
; *
; * COMMENTS: NO CHECKING IS PERFORMED TO VERIFY THAT THE LINE NUMBER IS
; * A LEGAL LINE NUMBER FOR THE DUT (IE - LESS THAN NUMLNS).
; * NOTE: THE LINE NUMBER IS NOT DESTROYED OR ALTERED, SO THIS
; * ROUTINE CAN BE USED EASILY IN LOOPS.
; *
; * SUBORDINATE ROUTINES CALLED: NONE.
; * - - - - -
LINBIT:: SAVE ;SAVE CONTENTS OF GPRS R0 THRU R5.
;CALL REGISTER SAVE SUBRT.
;MASK OUT ALL BUT 4 LSBITS OF THE LINE #.
;MULTIPLY LINE # BY 2 TO GET WORD TABLE OFFSET.
;GET THE SINGLE BIT BIT MAP.
;RESTORE GPRS, EXCEPT THE FOLLOWING.
R0,ROSL0T(SP) ;PUT R0 IN STACK SLOT.
PC,8(SP), ;RETURN TO PREG05 SUBRT.
;R0 BIT MAP WITH LINE # BIT SET.
        JSR      R5,PREG05
        BIC      #177760,R1
        ASL      R1
        MOV      BITTBL(R1),R0
60$:    PASS     R0
        RTS      PC
```

3092
3093
3094
3095
3096
3097
3098
3099
3100
3101
3102
3103
3104
3105
3106
3107
3108 014676
014676 004567 167156
3109 014702 010201
3110 014704 001405
3111
3112 014706 005002
3113 014710 000261
3114
3115 014712 005502
3116 014714 006301
3117 014716 001375
3118
3119 014720
014720 010266 000006
014724 004736
3120 014726 000207

```
.SBTTL GLOBAL SUBROUTINE MAPCNT
; * *****
; * - COUNT BITS IN BIT MAP ROUTINE -
; * THIS SUBROUTINE COUNTS THE NUMBER OF BITS WHICH ARE SET IN A BIT MAP.
; * INPUTS: R2 - THE BIT MAP FOR WHICH TO COUNT THE BITS.
; * OUTPUTS: R2 - COUNT OF THE NUMBER OF BITS THAT WERE SET.
; * CALLING SEQUENCE: JSR PC,MAPCNT
; * COMMENTS:
; * SUBORDINATE ROUTINES CALLED: NONE.
; - *****

MAPCNT:: SAVE
;SAVE CONTENTS OF GPRS R0 THRU R5.
MOV R2,R1 JSR R5,PREG05 ;CALL REGISTER SAVE SUBRT.
BEQ 60$ ;EXIT WITH ZERO IF NO BITS ARE SET IN MAP.

CLR R2 ;CLEAR THE BIT COUNT.
SEC ;COUNT THE LAST BIT TO BE SHIFTED OUT.

2$: ADC R2 ;COUNT THE BIT IF IT WAS SET.
ASL R1 ;SHIFT ANOTHER BIT OUT OF THE MAP.
BNE 2$ ;LOOP IF ALL BITS NOT SHIFTED OUT OF MAP.

60$: PASS R2
MOV ;RESTORE GPRS, EXCEPT THE FOLLOWING:
JSR R2,R2$LOT(SP) ;PUT R2 IN STACK SLOT.
PC,B(SP) ;RETURN TO PREG05 SUBRT.
; R2 - COUNT OF BITS SET IN BIT MAP.
```


3122
3123
3124
3125
3126
3127
3128
3129
3130
3131
3132
3133
3134
3135
3136
3137
3138
3139
3140
3141
3142
3143
3144
3145
3146
3147
3148
3149
3150
3151
3152
3153
3154
3155
3156
3157
3158
3159
3160 014730 004567 167124
3161
3162
3163
3164
3165 014734 005102
3166 014736 040203
3167
3168
3169
3170 014740 005701
3171 014742 001011
3172 014744 011400
3173 014746 010067 000070
3174 014752 040200
3175 014754 020003
3176 014756 000261
3177 014760 001420

```
.SBTTL GLOBAL SUBROUTINE - MSLGET
*****
; * - MILLI SECONDS LOOP WHICH RETURNS READ WORD AND REMAINING TIME
; * THIS SUBROUTINE IS A GENERAL PURPOSE TEST LOOP SUBROUTINE. IT IS USED
; * TO VERIFY THAT A CERTAIN ACTION OCCURS BEFORE A TIME-OUT PERIOD. THE
; * CALLING ROUTINE PASSES IN WHICH BITS SHOULD BE SET AND CLEARED FOR THE
; * DESIRED CONDITION AND THE TIME-OUT VALUE IN MILLI-SECONDS.
; * THIS ROUTINE CHECKS FOR THE DESIRED CONDITION UPON ENTRANCE INTO THE
; * ROUTINE AND THEN ONCE EACH MILLI-SECOND THERE AFTER.
; * UPON RETURN, THE LAST WORD WHICH WAS READ TO CHECK FOR THE CONDITION
; * IS RETURNED BY THIS SUBROUTINE.
; *
; * INPUTS: R1 - TIME-OUT VALUE IN MILLI-SECONDS (UP TO 64K MS).
; * R2 - BIT MAP OF BITS TO TEST (1 INDICATES TO TEST THE BIT).
; * R3 - DESIRED STATES OF THE INDICATED FIELDS IN R2.
; * R4 - ADDRESS OF THE WORD TO TEST.
; * MSLCNT - MILLI SECOND SOFTWARE LOOP COUNT.
; *
; * OUTPUTS: R0 - THE LAST WORD WHICH WAS READ TO CHECK FOR THE CONDITION.
; * R1 - REMAINING NUMBER OF MS IN TIME-OUT TIME.
; * CARRY - SUCCESS FLAG (SET IF CONDITION IS MET BEFORE TIME OUT).
; *
; * CALLING SEQUENCE: JSR PC,MSLGET
; *
; * COMMENTS: THIS ROUTINE WORKS WITH OR WITHOUT A HARDWARE CLOCK, BUT THE
; * CALIBRATION IS ONLY GUARENTEED WHEN A LINE CLOCK IS AVAILABLE
; * ON THE SYSTEM.
; * THIS ROUTINE CAN BE USED AS A DELAY ROUTINE, BY SPECIFYING THE
; * DESIRED DELAY AS THE TIME-OUT AND SPECIFYING A CONDITION TO
; * LOOK FOR WHICH WILL NOT BE MET DURING THE DELAY.
; * IF A TIME-OUT VALUE OF 0 IS SPECIFIED, THIS ROUTINE CHECKS FOR
; * THE DESIRED CONDITION BEFORE RETURNING. IT INDICATES SUCCESS
; * IF THE CONDITION IS MET, FAILURE OTHERWISE.
; *
; * SUBORDINATE ROUTINES CALLED: NONE.
*****
MSLGET:: SAVE ;SAVE CONTENTS OF GPRS R0 THRU R5.
; * JSR R5,PREGOS ;CALL REGISTER SAVE SUBRT.
; *
; * SET UP MASK FOR REMOVING UNUSED BITS IN THE TEST WORD, AND CLEAR UNUSED
; * BITS IN THE DESIRED STATE WORD TO ALLOW DIRECT COMPARISON.
; *
; * COM R2 ;GET MASK OF UNUSED BITS.
; * BIC R2,R3 ;MASK OUT UNUSED BITS IN DESIRED STATE WORD.
; *
; * HANDLE THE TEST AND EXIT IF WE HAVE A 0 TIME-OUT VALUE.
; *
; * TST R1 ;TEST THE TIME-OUT VALUE FOR ZERO.
; * BNE 2$ ;IF NON-ZERO TIME-OUT, GO LOOP AND TEST.
; * MOV (R4),R0 ;GET THE WORD TO TEST BEFORE EXITING.
; * MOV R0,62$ ;SAVE VALUE SO WE CAN RETURN IT.
; * BIC R2,R0 ;MASK OUT UNTESTED BITS OF WORD.
; * CMP R0,R3 ;COMPARE AGAINST DESIRED STATE WORD.
; * SEC ;INDICATE SUCCESS IN CASE WORDS ARE EQUAL.
; * BEQ 6$ ;EXIT WITH SUCCESS IF WORDS ARE EQUAL.
```



```

3209 .SBTTL GLOBAL SUBROUTINE MSLOOP
3210 ;*****
3211 ;* - TEST LOOP SUBROUTINE -
3212 ;* THIS SUBROUTINE IS A GENERAL PURPOSE TEST LOOP SUBROUTINE. IT IS USED
3213 ;* TO VERIFY THAT A CERTAIN ACTION OCCURS BEFORE A TIME-OUT PERIOD. THE
3214 ;* CALLING ROUTINE PASSES IN WHICH BITS SHOULD BE SET AND CLEARED FOR THE
3215 ;* DESIRED CONDITION AND THE TIME-OUT VALUE IN MILLI-SECONDS.
3216 ;* THIS ROUTINE CHECKS FOR THE DESIRED CONDITION UPON ENTRANCE INTO THE
3217 ;* ROUTINE AND THEN ONCE EACH MILLI-SECOND THEREAFTER.
3218 ;*
3219 ;* INPUTS: R1 - TIME-OUT VALUE IN MILLI-SECONDS (UP TO 64K MS).
3220 ;* R2 - BIT MAP OF BITS TO TEST (1 INDICATES TO TEST THE BIT).
3221 ;* R3 - DESIRED STATES OF THE INDICATED FIELDS IN R2.
3222 ;* R4 - ADDRESS OF THE WORD TO TEST.
3223 ;* MSLCNT - MILLI SECOND SOFTWARE LOOP COUNT.
3224 ;*
3225 ;* OUTPUTS: CARRY - SUCCESS FLAG (SET IF CONDITION IS MET BEFORE TIME-OUT).
3226 ;*
3227 ;* CALLING SEQUENCE: JSR PC,MSLOOP
3228 ;*
3229 ;* COMMENTS: THIS ROUTINE WORKS WITH OR WITHOUT A HARDWARE CLOCK, BUT THE
3230 ;* CALIBRATION IS ONLY GUARENTEED WHEN A LINE CLOCK IS AVAIL ABLE
3231 ;* ON THE SYSTEM.
3232 ;* THIS ROUTINE CAN BE USED AS A DELAY ROUTINE, BY SPECIFYING THE
3233 ;* DESIRED DELAY AS THE TIME-OUT AND SPECIFYING A CONDITION TO
3234 ;* LOOK FOR WHICH WILL NOT BE MET DURING THE DELAY.
3235 ;* IF A TIME-OUT VALUE OF 0 IS SPECIFIED, THIS ROUTINE CHECKS FOR
3236 ;* THE DESIRED CONDITION BEFORE RETURNING. IT INDICATES SUCCESS
3237 ;* IF THE CONDITION IS MET, FAILURE OTHERWISE.
3238 ;*
3239 ;* SUBORDINATE ROUTINES CALLED: MSLGET.
3240 ;*****
3241
3242 015044 MSLOOP:: SAVE ;SAVE CONTENTS OF GPRS R0 THRU R5.
015044 004567 167010 JSR R5,PREG05 ;CALL REGISTER SAVE SUBRT.
3243
3244 ;*
3245 ;* CALLING THE MSLGET ROUTINE FROM THE MSLOOP ROUTINE ISOLATES THE CALLER OF
3246 ;* MSLOOP FROM THE RETURNED TEST WORD AND REMAINING TIME-OUT VALUES.
3247 ;*
3248 015050 004767 177654 JSR PC,MSLGET ;CALL THE MULTI-PURPOSE MS LOOP AND SEARCH RTN.
3249
3250 015054 60%: PASS ;RESTORE GPRS.
015054 004736 JSR PC,@(SP). ;RETURN TO PREG05 SUBRT.
3251 015056 000207 RTS PC ;CARRY - SET IF SUCCESS, CLEAR IF TIME OUT.

```

3253
3254
3255
3256
3257
3258
3259
3260
3261
3262
3263
3264
3265
3266
3267
3268
3269
3270
3271
3272 015060
015060 004567 166774
3273
3274 015064
015064 104454
015066 000145
015070 015124
015072 000000
3275
3276 015074
015074 012746 015210
015100 012746 000001
015104 010600
015106 104417
015110 062706 000004
3277 015114
015114 104422
3278 015116 000776
3279 015120
015120 004736
3280 015122 000207
3281
3282 015124 110 117 123
015127 124 040 103
015132 117 115 120
015135 125 124 105
015140 122 040 110
015143 101 122 104
015146 127 101 122
015151 105 040 117
015154 122 040 123
015157 117 106 124
015162 127 101 122
015165 105 040 102
015170 125 107 040
015173 105 116 103
015176 117 125 116
015201 124 105 122

```

.SBTTL GLOBAL SUBROUTINE OOPS
;*****
;* - PROGRAM ABORT SUBROUTINE
;* THIS SUBROUTINE IS USED TO ABORT THE PROGRAM WHEN A FATAL ERROR IS
;* DETECTED IN THE PROGRAM OR THE HOST SYSTEM HARDWARE. AN ERROR MESSAGE
;* IS PRINTED GIVING SOME INFORMATION ABOUT THE NATURE OF THE ABORT.
;*
;* INPUTS: R1 - ERROR CODE GIVING REASON FOR ABORT.
;*
;* OUTPUTS: AN ERROR MESSAGE IS PRINTED.
;* A LIST OF RETURN PC VALUES FOR ALL SUBROUTINE CALLS IS PRINTED.
;*
;* CALLING SEQUENCE: JSR PC,OOPS
;*
;* COMMENTS:
;*
;* SUBORDINATE ROUTINES CALLED: NONE.
;--*****

OOPS:: SAVE ;SAVE CONTENTS OF GPRS R0 THRU R5.
; REPORT "HOST COMPUTER HARDWARE OR SOFTWARE BUG ENCOUNTERED." ERROR.
ERRSF 101,EM0101 ;CALL REGISTER SAVE SUBRT.

; REPORT "PROGRAM HUNG. WAITING FOR A CONTROL-C."
PRINTF #EM0102

MOV #EM0102, (SP)
MOV #1, -(SP)
MOV SP, R0
TRAP C$PNTF
ADD #4, SP
TRAP C$BRK

2$: BREAK ;LOOK FOR OPERATOR CONTROL-C INPUT.
BR 2$ ;INFINITE LOOP.
60$: PASS ;DON'T NEED THIS, BUT SOMEBODY MAY CHANGE THIS
PC, @ (SP). ;RETURN TO PREG05 SUBRT.
RTS PC JSR ; ROUTINE IN THE FUTURE, SO BE CONSISTANT.

EM0101:: .ASCIZ /HOST COMPUTER HARDWARE OR SOFTWARE BUG ENCOUNTERED./

```

	015204	105	104	056
	015207	000		
3283	015210	045	116	045
	015213	101	120	122
	015216	117	107	122
	015221	101	115	040
	015224	110	125	116
	015227	107	054	040
	015232	127	101	111
	015235	124	111	116
	015240	107	040	106
	015243	117	122	040
	015246	101	040	103
	015251	117	116	124
	015254	122	117	114
	015257	055	103	056
	015262	040	074	052
	015265	052	052	052
	015270	052	052	052
	015273	052	052	052
	015276	052	052	052
	015301	045	116	045
3284	015304	116	000	

EM0102:: .ASCIZ /NAPROGRAM HUNG, WAITING FOR A CONTROL-C. <*****N/N/

.EVEN

3286
3287
3288
3289
3290
3291
3292
3293
3294
3295
3296
3297
3298
3299
3300
3301
3302
3303
3304
3305
3306
3307
3308
3309
3310
3311
3312
3313
3314
3315
3316
3317
3318
3319

015306
015306 004567 166546
015312 016701 164710
015316 016702 164710
015322 042703 177760
015326 056703 164724
015332 010311
015334 011204
015336
015336 010446
015340 012746 011100
015344 012746 005034
015350 012746 000003
015354 010600
015356 104415
015360 062706 000010
015364
015364 004736
015366 000207

```
.SBTTL GLOBAL SUBROUTINE - PRTLPR
.....
; * -PRINT THE CONTENTS OF THE LPR.
; * THIS ROUTINE IS USED TO PRINT OUT EXTENDED INFORMATION ON THE
; * CONTENTS OF THE LINE PARAMETER REGISTER (LPR).
; *
; * INPUTS: R3 CONTAINS THE NUMBER OF THE LINE YOU WISH TO EXAMINE.
; * CSRA - CONTAINS THE ADDRESS OF THE DUT'S CSR.
; * IESTAT - CONTAINS THE CURRENT STATUS OF THE TX AND RX INTERRUPT
; * ENABLE BITS IN THE DUT'S CSR.
; * LPRA - CONTAINS THE ADDRESS OF THE DUT'S LPR REGISTER.
; *
; * OUTPUTS: AN EXTENDED INFORMATION MESSAGE IS PRINTED ON THE OPERATORS
; * CONSOLE.
; *
; * CALLING SEQUENCE: JSR PC,PRTLPR
; *
; * COMMENTS: THIS ROUTINE CHANGES THE INDIRECT ADDRESS FIELD OF THE DEVICE
; * UNDER TEST'S CSR.
; *
; * SUBORDINATE ROUTINES CALLED: NONE.
; - - .....
```

```
PRTLPR::SAVE
;SAVE CONTENTS OF GPRS R0 THRU R5.
R5,PREG05 ;CALL REGISTER SAVE SUBRT.
MOV CSRA,R1 ;GET THE CSR ADDRESS.
MOV LPRA,R2 ;GET THE LPR ADDRESS.
BIC #177760,R3 ;CLEAR ANY UNWANTED BITS.
BIS IESTAT,R3 ;SET STATE OF TX AND RX INTERRUPT ENABLE BITS.
MOV R3,(R1) ;SELECT LINE.
MOV (R2),R4 ;GET CONTENTS OF THE LPR.
;PRINT MESSAGE"CONTENTS OF THE LPR:NNNNN"
PRINTX #EF9019,#EM9026,R4;PRINT OUT MESSAGE ON OPERATORS CONSOLE.
MOV R4,-(SP)
MOV #EM9026,-(SP)
MOV #EF9019,(SP)
MOV #3,-(SP)
MOV SP,R0
TRAP C:PNTX
ADD #10,SP

601: PASS ;RESTORE GPRS.
RTS FC JSR PC,B(SP). ;RETURN TO PREG05 SUBRT.
```

```

3321 .SBTTL GLOBAL SUBROUTINE - PUFIFO
3322 ;*****
3323 ;* - PURGE THE FIFO
3324 ;* THIS ROUTINE TRIES TO REMOVE ALL THE CHARACTERS FROM THE FIFO.
3325 ;* ANY BMP CODES THAT ARE FOUND ARE SAVED ON THE BMP CODE QUEUE.
3326 ;*
3327 ;* INPUTS: RBUFA- CONTAINS THE ADDRESS OF THE RECEIVER.
3328 ;*
3329 ;*
3330 ;* OUTPUTS: CARRY BIT - INDICATES THE STATE OF THE FIFO, SET: = PURGED.
3331 ;* BMPCQ - THE CONTENTS OF THE BMP CODE QUEUE MAY BE UPDATED.
3332 ;*
3333 ;* CALLING SEQUENCE: JSR PC,PUFIFO
3334 ;*
3335 ;* COMMENTS:
3336 ;*
3337 ;* SUBORDINATE ROUTINES CALLED: SAVBMP.
3338 ;*****
3339
3340 015370 PUFIFO::SAVE ;SAVE CONTENTS OF GPRS R0 THRU R5.
015370 004567 166464 JSR R5,PREG05 ;CALL REGISTER SAVE SUBRT.
3341 015374 012701 001000 MOV #512.,R1 ;SET MAXIMUM TRY COUNT OF 512.
3342 015400 016704 164624 MOV RBUFA,R4 ;GET ADDRESS OF THE RECEIVER BUFFER REGISTER.
3343
3344 015404 011402 28: MOV (R4),R2 ;GET THE CONTENTS OF THE RECEIVER BUFFER REG.
3345 015406 100016 BPL 68 ;EXIT IF THE FIFO IS EMPTY, DATA_VALID CLR.
3346
3347 ;*
3348 ;* CHECK IF THE READ CHARACTER IS ACTUALLY A BMP CODE.
3349 ;* IF IT IS, THEN SAVE IT ON THE BMP CODE QUEUE TO BE REPORTED LATER.
3350 015410 012700 070000 MOV #70000,R0 ;GENERATE A BIT MAP OF CHAR ERROR BITS
3351 015414 040200 BIC R2,R0 ;WHICH ARE NOT SET FOR CHAR.
3352 015416 001006 BNE 48 ;THROW CHAR AWAY IF NOT BMP OR SELFTEST CODE.
3353
3354 ;*
3355 ;* CHECK IF THE READ DATA IS MODEM STATUS . BMP OR SELFTEST?.
3356 015420 012700 000301 MOV #301,R0 ; CHECK IF BMP.
3357 015424 040200 BIC R2,R0 ;TRY TO CLEAR BMP FLAGS IN THE READ DATA.
3358 015426 001002 BNE 48 ;IF IT IS MODEM OR SELFTEST CODE THROW IT AWAY.
3359 015430 004767 001044 JSR PC,SAVBMP ;SAVE BMP CODE ON THE QUEUE.
3360
3361 015434 005301 48: DEC R1 ;DECREMENT THE TRY COUNT.
3362 015436 001362 BNE 28 ;LOOP TO TRY AGAIN.
3363 015440 000241 CLC ;CLEAR CARRY, TO INDICATE FIFO NOT PURGED.
3364 015442 000401 BR 608 ;EXIT WITH CARRY CLEAR.
3365 015444 000261 68: SEC ;SET CARRY, TO INDICATE FIFO PURGED.
3366
3367 015446 608: PASS ;RESTORE GPRS.
015446 004736 JSR PC,(SP) ;RETURN TO PREG05 SUBRT.
3368
3369 015450 000207 RTS PC ;CARRY BIT, SET INDICATES FIFO PURGED.

```

3371
3372
3373
3374
3375
3376
3377
3378
3379
3380
3381
3382
3383
3384
3385
3386
3387
3388
3389
3390
3391
3392
3393
3394
3395
3396
3397
3398
3399 015452
3400 015452 004567 166402
3401 015456 016746 166370
3402 015462 012705 001000
3403
3404
3405
3406 015466 017702 164536
3407 015472 100063
3408
3409
3410
3411 015474 012700 070000
3412 015500 040200
3413 015502 001012
3414
3415
3416
3417
3418 015504 012767 012544 166344
3419 015512 012700 000300
3420 015516 040200
3421 015520 001003
3422 015522 004767 000752
3423 015526 000430
3424
3425
3426

```
.SBTTL GLOBAL SUBROUTINE PUFIFR
;*****
;* - PURGE FIFO REPORT ANY ERRORS FOUND.
;* THIS ROUTINE REMOVES ALL DATA FROM THE FIFO. ANY BMP CODES THAT ARE
;* FOUND ARE SAVE ON THE QUEUE TO BE REPORTED LATER IN THE BMP REPORT TEST.
;* ANY UNEXPECTED DATA (IE ANY NON-STATUS INFORMATION) THAT ARE FOUND,
;* ARE REPORTED AS AN ERROR.
;* IF THE FIFO WILL NOT PURGE AFTER 512 ATTEMPTS, THEN THE CURRENT TEST
;* THAT CALLED THIS ROUTINE RECEIVES A FAILURE FLAG THAT SHOULD BE USED
;* TO ABORT THE TEST.
;*
;* INPUTS: ERRIBL ERRTYPE, ERRMSG, ERRNBR ARE SET UP CORRECTLY.
;* RBUFA CONTAINS THE ADDRESS OF THE RECEIVER.
;*
;* OUTPUTS: CARRY BIT - ABORT TEST FLAG, CLR = ABORT TEST, SET = OK.
;* ERRBLK - VALUE WILL BE DESTROYED.
;* BMPQOP - THE BMP CODE QUEUE POINTER MAY BE UPDATED.
;* THE CONTENTS OF THE BMP CODE QUEUE MAY BE UPDATED.
;*
;* CALLING SEQUENCE: JSR PC,PUFIFR
;*
;* COMMENTS: THIS ROUTINE REPORTS ERRORS WITH NUMBERS INITIAL ERRNBR
;* THRU TO ERRNBR+2.
;* THE ERRNBR IS RESTORED TO ITS INITIAL VALUE BEFORE RETURNING.
;*
;* SUBORDINATE ROUTINES CALLED: ER1603,ER9001,ER9002,SAVBMP.
;*****
PUFIFR::SAVE
;SAVE CONTENTS OF GPRS R0 THRU R5.
;R5,PREG05 ;CALL REGISTER SAVE SUBRT.
MOV ERRNBR,-(SP) ;SAVE THE CONTENTS OF THE ERROR NUMBER.
MOV #512,R5 ;SET MAXIMUM READ COUNTER TO 2*FIFO SIZE.
;
; READ DATA FROM THE FIFO UNTIL DATA VALID IS CLEAR OF READ COUNTER IS ZERO.
; REPORT ANY BMP OR UNEXPECTED DATA AS ERRORS.
;
24: MOV RBUFA,R2 ;GET THE CONTENTS OF THE RECEIVER BUFFER REG.
BPL B1 ;EXIT IF DATA VALID CLEAR, IE. FIFO PURGED.
;
; CHECK IF READ DATA IS STATUS OR UNEXPECTED CHARACTER.
;
MOV #70000,R0 ;GENERATE A BIT MAP OF CHAR ERROR BITS
BIC R2,R0 ;WHICH ARE NOT SET FOR CHAR.
BNE 48 ;SKIP BMP CHECK IF IT IS UNEXPECTED DATA.
;
; CHECK IF THE READ DATA IS MODEM STATUS, BMP OR SELFTEST?.
; IF IT IS A BMP CODE THEN SAVE IT ON THE QUEUE.
;
MOV #ER9001,ERRBLK ;SET UP THE CORRECT ERROR REPORTING ROUTINE.
MOV #300,R0 ;CHECK IF BMP OR _FTEST?.
BIC R2,R0 ;TRY TO CLEAR BMP _LAGS IN THE READ DATA.
BNE 48 ;SKIP BMP ERROR REPORT IF MODEM OR SELFTEST?.
JSR PC,SAVBMP ;SAVE THE BMP CODE ON THE QUEUE.
BR 68 ;BRANCH TO CHECK READ COUNT.
;
; CHECK IF THE READ DATA IS MODEM, SELFTEST OR UNEXPECTED DATA.
;
```



```

3427 015530 032702 000001      4:  BIT    #BIT0,R2      ;TEST THE MODEM STATUS INDICATION BIT.
3428 015534 001425              BEQ    6:             ;DO NOT REPORT ANY ERROR IF MODEM STATUS.
3429 015536 012701 011124      MOV    #EM9104,R1     ;PASS THE CORRECT ERROR MESSAGE TO REPORT.
3430 015542 010203              MOV    R2,R3         ;EXTRACT THE LINE NUMBER FROM
3431 015544 000303              SWAB   R3            ; THE READ DATA.
3432 015546 042703 177760      BIC    #177760,R3     ;
3433 015552 006303              ASL    R3            ;FORM LINE NUMBER TIMES 2 FOR ER9002 ROUTINE.
3434 015554 052704 100000      BIS    #BIT15,R4     ;SET THE "NONE" EXPECTED MESSAGE FLAG.
3435 015560 005267 166266      INC    ERRNBR        ;SET ERROR NUMBER TO INITIAL ERRBR+1.
3436 015564 012767 012644 166264 MOV    #ER9002,ERRBLK ;SELECT THE CORRECT ERROR REPORTING ROUTINE.
3437                                ;REPORT ERROR "UNEXPECTED DATA FOUND IN FIFO .
3438                                ;ERROR
                                ;          >>>>> ERROR <<<<<<.
                                ;          TRAP    C$ERROR
3439                                ;
3440                                ; EXIT WITH FAILURE IF EXTENDED ERROR REPORTING HAS NOT BEEN ENABLED
3441                                ;
3442 015574 032767 000100 164406  BIT    #BIT06,OPTION ;EXIT WITH TEST FAILURE MESSAGE IF
3443 015602 001415              BEQ    7:             ;NO EXTENDED ERROR REPORTING HAS BEEN REQUESTED
3444                                ; DURING THE SOFTWARE QUESTIONS.
3445                                ;
3446 015604 005367 166242      DEC    ERRNBR        ;RESTORE ERROR NUMBER TO INITIAL ERRNBR.
3447                                ;
3448 015610 005305              6:  DEC    R5          ;DECREMENT READ COUNTER.
3449 015612 001325              BNE    2:            ;LOOP TO READ NEXT CHAR FROM FIFO IF COUNT > 0.
3450                                ;
3451                                ; THE FIFO WILL NOT CLEAR, REPORT THE ERROR AND INDICATE THAT THE TEST IS TO
3452                                ; BE ABORTED.
3453                                ;
3454 015614 062767 000002 166230  ADD    #2,ERRNBR     ;SET ERROR NUMBER TO INITIAL ERRNBR+2.
3455 015622 012767 012020 166226  MOV    #ER1603,ERRBLK ;SELECT THE CORRECT ERROR REPORTING ROUTINE.
3456 015630 012701 010767      MOV    #EM9017,R1     ;PASS THE MESSAGE TO BE REPORTED.
3457                                ;REPORT THE ERROR "FIFO WILL NOT PURGE, (DATA VALID STUCK SET)"
3458                                ; "?????? TEST ABORTED".
3459                                ;          >>>>> ERROR <<<<<<.
3460                                ;          TRAP    C$ERROR
3460 015634 104460              7:  CLC              ;INDICATE THE TEST IS TO BE ABOPTED.
3461 015636 000241              BR     10:           ;EXIT THIS ROUTINE AND ABORT THE CURRENT TEST.
3462 015640 000401              8:  SEC              ;SET THE CARRY, DO NOT ABORT THE TEST.
3463 015642 000261              10: MOV    (SP),ERRNBR ;RESTORE INITIAL ERROR NUMBER.
3464 015644 012667 166202      60: PASS             ;RESTORE GPRS.
3465 015644 012667 166202      JSR                    ;RETURN TO PREG05 SUBRT.
3466 015650 004736              PC,B(SP),           ;CARRY BIT, SET INDICATES FIFO PURCED, DO NOT
3467 015650 004736              ; ABORT THE TEST.
3468 015652 000207      RTS    PC
    
```

```

3471 .SBTTL GLOBAL SUBROUTINE - READBX
3472 ;* *****
3473 ;* - READ CHARACTERS FROM THE FIFO AND CHECKS FOR BMPS AND XONS
3474 ;* THIS SUBROUTINE IS USED IN THE FIHAVL.TST.
3475 ;* IT READS THE SPECIFIED NUMBER OF CHARACTERS FROM THE FIFO AND CHECKS
3476 ;* FOR BMP CODES AND XON CHARACTERS.
3477 ;*
3478 ;* INPUTS: R0 - CONTAINS THE NUMBER OF CHARS TO READ FROM THE FIFO.
3479 ;*
3480 ;* OUTPUTS: R1 - CONTAINS ADDRESS OF ERROR MESSAGE TO BE REPORTED
3481 ;* CLEAR IF NO ERROR FOUND.
3482 ;* CARRY USED TO INDICATE IF FIFO WAS FOUND EMPTY, CARRY CLEAR.
3483 ;*
3484 ;* CALLING SEQUENCE: JSR PC,READ
3485 ;*
3486 ;* COMMENTS:
3487 ;*
3488 ;* SUBORDINATE ROUTINES CALLED: CHKBMP.
3489 ;*
3490 ;* *****
3491 015654 004567 166200 READBX:: SAVE JSR ;SAVE CONTENTS OF GPRS R0 THRU R5.
015654 004567 166200 ;R5,PREGO5 ;CALL REGISTER SAVE SUBRT.
3492 015660 005001 164342 CLR R1 ;CLEAR GPR THAT HOLDS THE ADDRESS OF ERRMSG.
015660 005001 164342 MOV RBUFA,R3 ;GET THE ADDRESS OF THE RECEIVER BUFFER REG.
3493 015662 016703 164342 2: MOV (R3),R2 ;READ A CHARACTER FROM THE FIFO.
015662 016703 164342 BPL 8: ;BRANCH IF FIFO IS EMPTY.
3494 015666 011302
3495 015670 100015
3496
3497
3498 ;*
3499 ;* CHECK IF THE READ CHARACTER IS A BMP CODE.
3500 ;* IF IT IS A BMP CODE SAVE IT ON THE QUEUE TO BE REPORTED LATER, AND
3501 ;* ABORT THE TEST.
3501 015672 004767 176100 JSR PC,CHKBMP ;CHECK IF CHARACTER IS A BMP CODE.
3502 015676 103410 BCS 6: ;BRANCH IF A BMP CODE WAS FOUND.
3503 015700 120227 000021 CMPB R2,#21 ;CHECK IF IT IS AN XON.
3504 015704 001003 BNE 4: ;BRANCH IF NOT AN XON.
3505 015706 012701 006520 MOV #EMS402,R1 ;PASS THE MESSAGE TO BE REPORTED.
3506 015712 000402 BR 6: ;GO EXIT TEST.
3507 015714 005300 4: DEC R0 ;DECREMENT THE READ COUNT.
3508 015716 001363 BNE 2:
3509 015720 000261 6: SEC ;SET CARRY TO INDICATE SUCCESS.
3510 015722 000401 BR 60: ;EXIT
3511 015724 000241 8: CLC ;CLEAR CARRY BIT TO INDICATE FAILURE.
3512
3513 015726 010166 000004 60: PASS R1 ;RESTORE GPRS.
015726 010166 000004 MOV R1,R1SLOT(SP) ;PUT R1 IN STACK SLOT.
015732 004736 JSR PC,#(SP) ;RETURN TO PREGO5 SUBRT.
3514 015734 000207 RTS PC

```

3516
3517
3518
3519
3520
3521
3522
3523
3524
3525
3526
3527
3528
3529
3530
3531
3532
3533
3534
3535
3536
3537
3538
3539
3540
3541
3542
3543
3544
3545
3546
3547
3548
3549 015736
015736 004567 166116
3550 015742 005067 000304
3551 015746 012705 000200
3552 015752 000241
3553 015754 017702 164250
3554 015760 100132
3555
3556
3557
3558 015762 012700 170301
3559 015766 040200
3560 015770 001004
3561 015772 004767 000502
3562 015776 005305
3563 016000 001364
3564
3565
3566
3567 016002 010205
3568 016004 042702 177400
3569 016010 120203
3570 016012 001432
3571 016014 012767 000001 000230

```

.SBTTL GLOBAL SUBROUTINE REPDER
;*****
; - REPORT DATA ERRORS -
; THIS SUBROUTINE IS USED TO REPORT INCORRECT CHARACTERS AND LINE
; NUMBERS IN A WORD OF DATA READ FROM THE RXFIFO. THIS ROUTINE
; CHECKS FOR THE NUMBER OF INDIVIDUAL DATA ERRORS ON A LINE EXCEEDING
; THE REQUESTED AMOUNT AND SETS THE APPROPRIATE ERROR SUMMARY FLAG, IT
; THEN STOPS REPORTING ANY FURTHER ERRORS ON THAT LINE. ANY BMP CODES
; FOUND ARE SAVED ON THE BMP CODE QUEUE TO BE REPORTED LATER AND ANOTHER
; CHARACTER IS READ FROM THE RXFIFO.
;
; INPUTS: R1 - CONTAINS THE NUMBER OF THE UUT.
; R3 - LOW BYTE CONTAINS THE EXPECTED CHAR.
; ERCNTB - ADDRESS OF THE BASE OF THE ERROR SUMMARY TABLE.
; ERRLBK - ADDRESS OF ERROR REPORTING ROUTINE IN ERROR TABLE.
; ERRNBR - SET TO THE ERROR NUMBER OF THE FIRST ERROR IN THIS ROUTINE.
; EXOERR - ADDRESS OF "EXIT ON ERROR" FLAG.
;
; OUTPUTS: CARRY - CLEAR IF RXFIFO WAS EMPTY, SET OTHERWISE.
; ERCNTB - CONTENTS UPDATED TO REFLECT THE CURRENT STATE.
; ERRLBK - CONTENTS MAY BE ALTERED.
; ERSMRF - ERROR SUMMARY FLAGS UPDATED.
; EXOERR - 1 IF AT LEAST ONE ERROR OCCURED.
; 0 IF NO ERRORS OCCURED.
;
; CALLING SEQUENCE: JSR PC,REPDER
;
; COMMENTS: THIS ROUTINE REPORTS ERRORS WITH NUMBERS INITIAL ERRNBR
; THRU INITIAL ERRNBR+1.
;
; SUBORDINATE ROUTINES CALLED: NONE
;-- *****
REPDER:: SAVE
; JSR R5,PREG05 ;CALL REGISTER SAVE SUBRT.
CLR 62 ;CLEAR THE "AN ERROR OCCURED" INDICATOR.
MOV #128,,R5 ;SET THE MAX BMP READ COUNT.
2: CLC ;CLEAR THE CARRY IN CASE THE FIFO IS EMPTY.
MOV BRBUFA,R2 ;READ THE RXFIFO.
BPL 61 ;EXIT THIS SUBROUTINE WITH CARRY CLEAR IF FIFO EMPTY.
;
; CHECK IF THE CHARACTER IS A BMP CODE.
;
MOV #170301,R0 ;SET UP THE BIT MASK FOR A BMP CODE.
BIC R2,R0 ;TRY AND CLEAR THE BIT MASK.
BNE 4 ;AVOID SAVING THE CODE IF IT IS NOT A BMP CODE.
JSR PC,SAVBMP ;SAVE THE BMP CODE ON THE QUEUE.
DEC R5 ;DECREMENT THE MAX BMP READ COUNT.
BNE 2 ;READ ANOTHER CHARACTER FROM THE RXFIFO.
;
; VERIFY THAT THE READ CHARACTER IS CORRECT.
;
4: MOV R2,R5 ;SAVE THE READ DATA.
BIC #177400,R2 ;CLEAR THE CLUTTER FROM THE DATA CHAR.
CMPB R2,R3 ;COMPARE THE READ CHAR WITH THE EXPECTED CHAR.
BEQ 6 ;AVOID THE ERROR REPORT IF THE DATA IS CORRECT.
MOV #1,62 ;INDICATE AN ERROR HAS OCCURED.

```



```
3627 016234 101003          BHI      60$          ;AVOID SETTING THE ERROR SUMMARY FLAG IF THE
3628                                     ;NUMBER OF ERRORS REPORTED IS LESS THAN THE
3629                                     ;NUMBER REQUESTED.
3630 016236 056467 002336 164346      BIS      BITTBL(R4),ERSMRF ;OTHERWISE SET THE APPROIATE ERROR FLAG.
3631
3632 016244 000261          60$:      SEC
3633 016246          61$:      PASS          ;SET THE CARRY FLAG AND INDICATE SUCCESS.
          016246 004736
3634 016250 000207          RTS      PC      JSR      PC,@(SP)+          ;RETURN TO PREG05 SUBRT.
3635 016252 000000          62$:      .WORD    0          ;STRORAGE FOR THE AT LEAST ONE ERROR" INDICATOR.
```

```

3637 .SBTTL GLOBAL SUBROUTINE REPSMR
3638 :* *****
3639 :* - REPORT ERROR SUMMARY ROUTINE -
3640 :* THIS SUBROUTINE REPORTS AN ERROR SUMMARY FOR THOSE LINES WHICH HAVE
3641 :* EXCEEDED THE NUMBER OF INDIVIDUAL ERRORS TO REPORT FOR A SINGLE LINE
3642 :* IN A SINGLE TEST. THIS PARAMETER CAN BE SPECIFIED BY THE OPERATOR IF
3643 :* HE/SHE ANSWERS THE SOFTWARE PARAMETER QUESTIONS.
3644 :*
3645 :* INPUTS: ERCNTB - LABEL AT BASE OF LINE ERROR COUNTERS TABLE.
3646 :* ERRMSG - ADDRESS OF PRIMARY ERROR MESSAGE.
3647 :* ERRNBR - ERROR NUMBER OF ERRORS IN THIS ROUTINE.
3648 :* ERSMRF - "REPORT ERROR SUMMARY FOR LINE" FLAGS.
3649 :*
3650 :* OUTPUTS: ERRBLK - ADDRESS OF ERROR REPORTING ROUTINE (DESTROYED).
3651 :* SUMMARY MESSAGES MAY BE PRINTED AT THE OPERATOR CONSOLE.
3652 :*
3653 :* CALLING SEQUENCE: JSR PC,REPSMR
3654 :*
3655 :* COMMENTS: IF NO LINES HAVE EXCEEDED THE MAXIMUM NUMBER OF INDIVIDUAL
3656 :* ERRORS TO REPORT, NO MESSAGES ARE PRINTED BY THIS ROUTINE.
3657 :* ERROR SUMMARIES IN THIS ROUTINE ARE REPORTED AS ERRORS.
3658 :* THE CONTENTS OF ERRBLK ARE DESTROYED.
3659 :*
3660 :* SUBORDINATE ROUTINES CALLED:
3661 :*
3662 :* *****
3663 016254 REPSMR:: SAVE ;SAVE CONTENTS OF GPRS R0 THRU R5.
016254 004567 165600 JSR R5,PREG05 ;CALL REGISTER SAVE SUBRT.
3664 016260 005767 164326 TST ERSMRF ;CHECK THE "PRINT LINE ERROR SUMMARY" FLAGS.
3665 016264 001404 BEQ 601 ;EXIT WITHOUT ACTION IF NO SUMMARY FLAGS SET.
3666 :*
3667 :* WE HAVE SOME ERROR SUMMARIES TO REPORT.
3668 :*
3669 016266 012767 013022 165562 MOV #ER9004,ERRBLK ;SELECT ERROR REPORTING ROUTINE.
3670 :*
3671 :* REPORT
3672 :* "ERROR SUMMARY REPORT FOR LINES WITH EXCESSIVE NUMBERS OF ERRORS:"
3673 :*
3674 016274 ERROR
016274 104460 TRAP C$ERROR
3675 :*
3676 016276 004736 601: PASS ;RESTORE GPRS.
016276 000207 RTS PC JSR PC,@(SP), ;RETURN TO PREG05 SUBRT.
3677 016300

```

3679
3680
3681
3682
3683
3684
3685
3686
3687
3688
3689
3690
3691
3692
3693
3694
3695
3696
3697
3698
3699
3700
3701
3702
3703
3704 016302
016302 004567 165552
3705 016306 012702 000040
3706
3707
3708
3709
3710
3711 016312 016704 163710
3712 016316 030214
3713 016320 001406
3714 016322 005003
3715 016324 012701 011610
3716 016330 004767 176374
3717 016334 103012
3718
3719
3720
3721
3722
3723
3724 016336 010277 163664
3725 016342 004767 000246
3726
3727
3728
3729
3730
3731 016346 005003
3732 016350 012701 011610
3733 016354 004767 176350
3734 016360 103410

```

.SBTTL GLOBAL SUBROUTINE                                RESETT
;*****
;* - RESET DEVICE UNDER TEST -
;* THIS SUBROUTINE IS USED TO RESET THE DUT TO A KNOWN STATE.
;* IF RESET DOES NOT SUCCESSFULLY COMPLETE, IF TIME-OUT OCCURS, THEN
;* AN ABORT TEST ERROR MESSAGE IS REPORTED.
;*
;* INPUTS:      CSRA  CONTAINS THE ADDRESS OF THE CSR
;*              TXBFCA - CONTAINS ADDRESS OF DUT DMA BUFFER COUNT REGISTER.
;*              ERRCTL - ERR TYP, ERNBR, AND ERRMSG SET UP CORRECTLY.
;*
;* OUTPUTS:     THE DUT PERFORMS ITS RESET FUNCTION INTO A KNOWN STATE.
;*              CARRY - CLEAR INDICATES THE TEST IS TO BE ABORTED.
;*              ERRBLK - VALUE MAY BE DESTROYED.
;*              IESTAT - TX AND RX INTERRUPT FLAGS ARE CLEARED.
;*              TX AND RX INTERRUPT ENABLE BITS IN THE DUT'S CSR ARE CLEARED.
;*
;* CALLING SEQUENCE:  JSR    PC,RESETT
;*
;* COMMENTS:        THIS SUBROUTINE CAN REPORT ERRORS WITH NUMBERS INITIAL ERNBR
;*                  THIS ROUTINE DOES NOT DESTROY THE VALUE OF ERNBR.
;*
;* SUBORDINATE ROUTINES CALLED: DELAY,MSLGET.
;*****
RESETT:: SAVE
;SAVE CONTENTS OF GPRS R0 THRU R5.
;CALL REGISTER SAVE SUBRT.
;SET BIT MASK OF MASTER RESET BIT.
        MOV     #BIT05,R2
;
; TEST THE STATE OF THE MASTER RESET BIT IN THE CSR.
; IF MR IS SET THEN WAIT FOR SELF-TEST TO COMPLETE.
; IF TIME-OUT OCCURS, REPORT THE ERROR AND PASS-OUT ABORT TEST INDICATOR.
;
        MOV     CSRA,R4
        BIT     R2,(R4)
        BEQ     2$
        CLR     R3
        MOV     #5000.,R1
        JSR     PC,MSLGET
        BCC     4$
;GET THE ADDRESS OF THE DUT'S CSR.
;CHECK STATE OF MASTER RESET BIT.
;DON'T DELAY IF MR IS ALREADY CLEAR.
;SET UP DESIRED STATE OF MASTER RESET BIT.
;PASS TIME-OUT VALUE OF 5 SECONDS.
;WAIT FOR SELF-TEST TO COMPLETE, MR CLEAR.
;GO REPORT ERROR IF TIMEOUT OCCURRED.
;
; SET MASTER RESET BIT IN CSR. CLEAR TX AND RX ENABLE BITS, ETC.
; SKIP THE SELFTST.
; TIME-OUT OF 5 SECS, JUST IN CASE THE SELF-TEST EXECUTES.
;
2$:      MOV     R2,BCSRA
        JSR     PC,SKPSTS
;SET MASTER RESET BIT, DISABLE TX AND RX INTS.
;TRY TO SKIP THE SELFTST.
;
; SET SELF-TEST TIME-OUT OF 5 SECONDS, AND WAIT FOR M.R TO CLEAR.
; IF TIME-OUT OCCURS, THEN REPORT THE FATAL ERROR AND PASS-OUT THE ABORT
; TEST INDICATOR.
;
        CLR     R3
        MOV     #5000.,R1
        JSR     PC,MSLGET
        BCS     6$
;SET UP DESIRED STATE OF MASTER RESET BIT.
;PASS TIME-OUT VALUE OF 5 SECONDS.
;WAIT FOR SELF-TEST TO COMPLETE, MR CLEAR.
;SKIP ERROR REPORT IF MR CLEARED IN TIME.

```

```

3735
3736
3737
3738
3739 016362 012701 005320
3740 016366 012767 012020 165462
3741
3742
3743 016374
      016374 104460
3744 016376 000241
3745 016400 000403
3746
3747
3748
3749
3750 016402 005067 163650
3751 016406 000261
3752
3753 016410
      016410 004736
3754
3755 016412 000207
3756
      ;
      ; SET UP ERROR MESSAGE TO REPORT "FATAL ERROR FOUND DURING RESET, TEST ABORTED".
      ; INDICATE TEST IS TO BE ABORTED BY CLEARING THE CARRY BIT.
      ;
      4$:  MOV     #EM1601,R1      ;PASS ERROR MESSAGE TO REPORT.
          MOV     #ER1603,ERRBLK ;PASS ADDRESS OF ERROR HANDLING ROUTINE.
          ;REPORT ERROR "TIME-OUT OCCURRED WAITING FOR MASTER RESET TO CLEAR"
          ; "TEST ABORTED"
          ERROR
          ;
          ; >>>> ERROR <<<<<
          ;
          ; INDICATE TEST IS TO BE ABORTED. TRAP C$ERROR
          ; EXIT THIS SUBROUTINE, ABORT TEST INDICATOR.
          CLC
          BR     60$
      ;
      ; CLEAR TX AND RX INTERRUPT ENABLE STATUS FLAGS IN IESTAT.
      ; EXIT WITH CONTINUE TEST INDICATOR SET (IE,CARR SET).
      ;
      6$:  CLR     IESTAT      ;CLEAR TX AND RX INTERRUPT STATUS FLAGS.
          SEC
          ;INDICATE SUCCESS, CONTINUE TEST.
      ;
      60$: PASS
          ;RESTORE GPRS, PASS THE FOLLOWING INTACT:
          JSR    PC,@(SP)+    ;RETURN TO PREG05 SUBRT.
          ;CARRY BIT: IF CLEAR, INDICATES ABORT TEST.
          RTS     PC
    
```


3758
3759
3760
3761
3762
3763
3764
3765
3766
3767
3768
3769
3770
3771
3772
3773
3774
3775
3776 016414 010046
3777 016416 104440
016416 104440
016420 010046
3778 016422 012700 000340
016422 012700 000340
016426 104441
3779 016430 042767 137777 163620
3780 016436 016777 163614 163562
3781 016444 012600
016444 012600
016446 104441
3782 016450 012600
3783 016452 000207

```
.SBTTL GLOBAL SUBROUTINE                                RXIEO
; * *****
; * - RECEIVER INTERRUPT DISABLE -
; * THIS ROUTINE IS USED TO DISABLE RECEIVER INTERRUPTS IN THE DHU11.
; *
; * INPUTS:      NONE.
; *
; * OUTPUTS:     THE RX.INT.ENBL BIT IS CLEARED IN THE DUT CSR.
; *              IESTST -CONTAINS THE UPDATED STATUS OF THE TX AND RX INTERRUPT
; *              ENABLE BITS.
; *
; * CALLING SEQUENCE:  JSR      PC,RXIEO
; *
; * COMMENTS:     THE CONTENTS OF THE INDIRECT ADDRESS REGISTER FIELD IN
; *              THE DUT CSR ARE DESTROYED.
; *
; * SUBORDINATE ROUTINES CALLED: NONE.
; * *****
RXIEO::  MOV      RO,-(SP)          ;SAVE CONTENTS OF RO ON THE STACK.
        GETPRI -(SP)             ;SAVE PROCESSOR PRIORITY ON STACK.
; *
; *              TRAP      C$GPRI
; *              MOV      RO,(SP)
3778     SETPRI @PRI07           ;IGNORE ANY INTERRUPT THAT MAY BE GENERATED.
; *              MOV      @PRI07,RO
; *              TRAP      C$SPRI
3779     BIC      #137777,IESTAT ;CLEAR RX.INT.ENBL BIT IN IESTAT.
3780     MOV      IESTAT,@CSRA   ;DISABLE RX INTERRUPTS.
3781     SETPRI (SP)+           ;ENABLE INTERRUPTS TO THE PROCESSOR AGAIN.
; *              MOV      (SP)+,RO
; *              TRAP      C$SPRI
; *
; *              MOV      (SP)+,RO ;RESTORE RO.
; *              RTS      PC
```

3785
3786
3787
3788
3789
3790
3791
3792
3793
3794
3795
3796
3797
3798
3799
3800
3801
3802
3803
3804
3805
3806
3807

016454 052767 000100 163574
016462 042767 137677 163566
016470 016777 163562 163530
016476 000207

```

.SBTTL GLOBAL SUBROUTINE - RXIE1 -
; * *****
; * - RECEIVER INTERRUPT ENABLE -
; * THIS ROUTINE IS USED TO ENABLE RECEIVER INTERRUPTS IN THE DHU11.
; *
; * INPUTS: NONE.
; *
; * OUTPUTS: THE RX.INT.ENBL BIT IS SET IN THE DUT CSR.
; * IESTST -CONTAINS THE UPDATED STATUS OF THE TX AND RX INTERRUPT
; * ENABLE BITS.
; *
; * CALLING SEQUENCE: JSR PC,RXIE1
; *
; * COMMENTS: THE CONTENTS OF THE INDIRECT ADDRESS REGISTER FIELD IN
; * THE DUT CSR ARE DESTROYED.
; *
; * SUBORDINATE ROUTINES CALLED: NONE.
; - - *****
RXIE1:: BIS #BIT06,IESTAT ;SET RX.INT.ENBL BIT IN IESTAT.
        BIC #137677,IESTAT ;CLEAR ALL OTHER BITS, EXCEPT TX AND RX I.E.
        MOV IESTAT,@CSRA ;ENABLE RX INTERRUPTS.
        RTS PC

```

3809
3810
3811
3812
3813
3814
3815
3816
3817
3818
3819
3820
3821
3822
3823
3824
3825
3826
3827
3828
3829
3830
3831
3832
3833
3834
3835
3836
3837
3838
3839
3840
3841
3842
3843
3844

016500		
016500	004567	165354
016504	016704	163700
016510	116724	163540
016514	003204	
016516	042702	177400
016522	010224	
016524	020427	002612
016530	103402	
016532	162704	000004
016536	010467	163646
016542		
016542	004736	
016544	000207	

```
.SBTTL GLOBAL SUBROUTINE          - SAVBMP
;.. *****
;#
;#           - SAVE BMP CODES ROUTINE -
;# THIS ROUTINE SAVES THE PARAMETER PASSED IN, ONTO THE BMP CODE QUEUE
;# TOGETHER WITH THE NUMBER OF THE CURRENTLY EXECUTING TEST.
;#
;# INPUTS:      R2 - CONTAINS THE BMP CODE THAT IS TO BE PLACED ON THE QUEUE.
;#              BMPCQP - CONTAINS ADDRESS OF NEXT LOCATION IN THE BMP QUEUE.
;#              BMPCQB - LABEL AT BASE OF THE BMP CODE QUEUE.
;#              BMPCQE - LABEL OF NEXT LOCATION AFTER THE END OF THE BMP QUEUE.
;#              TSTNUM  CONTAINS THE NUMBER OF THE CURRENT TEST.
;#
;# OUTPUTS:     BMPCQP - INCREMENTED BY 4.
;#              THE CONTENTS OF THE BMP CODE QUEUE ARE UPDATED.
;#
;# CALLING SEQUENCE:  JSR      PC,SAVBMP
;#
;# COMMENTS:     IF THE OVERFLOW OCCURS THEN THE LAST LOCATION WILL BE
;#              OVERWRITTEN BY ANY SUBSEQUENT ATTEMPTS TO UPDATE THE QUEUE.
;#
;# SUBORDINATE ROUTINES CALLED: NONE.
;.. *****
SAVBMP:: SAVE
;#
;#              JSR      R5,PREG05          ;SAVE CONTENTS OF GPRS R0 THRU R5.
;#              MOV     BMPCQP,R4          ;CALL REGISTER SAVE SUBRT.
;#              MOV     TSTNUM,(R4).      ;GET THE POINTER TO THE NEXT LOCATION IN QUEUE.
;#              INC     R4                ;SAVE THE CURRENT TEST NUMBER ON THE QUEUE.
;#              BIC     @177400,R2        ;INCREMENT THE POINTER TO GIVE AN EVEN ADDRESS.
;#              MOV     R2,(R4).          ;CLEAR THE UNWANTED BITS FROM THE BMP CODE.
;#              CMP     R4,@BMPCQE        ;SAVE THE BMP CODE ON THE QUEUE.
;#              BLO    2$                ;CHECK IF OVERFLOW WILL OCCUR THE NEXT TIME.
;#              SUB     @4,R4             ;GO SAVE THE POINTER IF WE WILL NOT OVERFLOW.
;#              MOV     R4,BMPCQP         ;RESET THE POINTER TO THE LAST LOCATION IN QUE.
;#              JSR     PC,@BMPCQP        ;SAVE THE POINTER.
;#
;#              PASS
;#              JSR     PC,@BMPCQP        ;RESTORE GPRS.
;#
;#              RTS     PC                ;RETURN TO PREG05 SUBRT
```

3846
 3847
 3848
 3849
 3850
 3851
 3852
 3853
 3854
 3855
 3856
 3857
 3858
 3859
 3860
 3861
 3862
 3863
 3864
 3865
 3866
 3867
 3868
 3869
 3870
 3871
 3872
 3873
 3874
 3875
 3876

016546
 016546 004567 165306
 016552 004767 176072
 016556 010005
 016560 012700 000206
 016564 004767 000762
 016570 012700 177670
 016574 004767 001002
 016600 012704 000012
 016604 004767 175452
 016610
 016610 004736
 016612 000207

```

.SBTTL GLOBAL SUBROUTINE - SETPAR
;*****
;* - SET TX AND CONTROL PARAMETERS -
;* THIS SUBROUTINE IS USED IN THE FIMAVL.TST.
;* IT INITIALISES THE SELECTED LINE TO THE FOLLOWING STATE:
;* INTERNAL LOOPBACK, IAUTO ENABLED, LPR:38.4K, 8 BITS/CHAR, 2 STOP,
;* ODD PARITY.
;*
;* INPUTS: R1 - CONTAINS NUMBER OF THE LINE TO BE INITIALISED.
;*
;* OUTPUTS: LNCTRL AND LPR REGISTERS FOR THE SELECTED LINE ARE DESTROYED.
;*
;* CALLING SEQUENCE: JSR PC,SETPAR
;*
;* COMMENTS:
;*
;* SUBORDINATE ROUTINES CALLED: DELAY,WTWLNC,WTWLPR.
;*****
SETPAR:: SAVE
;SAVE CONTENTS OF GPRS R0 THRU R5.
R5,PREG05 ;CALL REGISTER SAVE SUBRT.
;GET A BIT MAP FOR THIS LINE.
JSR PC,LINBIT
;COPY THE LINE BIT MAP.
MOV R0,R5
;PASS INTERNAL LOPBCK, ENABLE RX AND IAUTO.
MOV #206,R0
;INITIALISE THE LINE CONTROL REGISTER.
JSR PC,WTWLNC
;PASS THE LPR CONTENTS.
MOV #177670,R0
;SET THE LPR CONTENTS TO 38.4K BAUD.
JSR PC,WTWLPR
;PASS DELAY TIME OF 10 MILLI SECONDS.
MOV #10.,R4
;WAIT FOR LNCTRL AND LPR REGS TO BE UPDATED.
JSR PC,DELAY

608: PASS ;RESTORE GPRS.
;RETURN TO PREG05 SUBRT.
RTS PC JSR PC,8(SP)
    
```

3878
 3879
 3880
 3881
 3882
 3883
 3884
 3885
 3886
 3887
 3888
 3889
 3890
 3891
 3892
 3893
 3894
 3895
 3896
 3897
 3898 016614
 016614 004567 165240
 3899 016620 012704 000012
 3900 016624 004767 175432
 3901
 3902
 3903
 3904 016630 012701 000060
 3905
 3906
 3907 016634 012703 052525
 3908 016640 005301
 3909 016642 016704 163360
 3910 016646 010124
 3911 016650 010324
 3912 016652 020467 163366
 3913 016656 103774
 3914 016660 032701 000017
 3915 016664 001365
 3916
 3917 016666
 016666 004736
 3918 016670 000207

```

.SBTTL GLOBAL SUBROUTINE SKPSTS
;*****
;* - SKIP SELFTEST ROUTINE -
;* THIS SUBROUTINE IS USED TO SKIP THE SELFTEST AFTER A DUT RESET HAS BEEN
;* INITIATED. IT MUST BE ENTERED IMMEDIATELY AFTER SETTING THE DUT MASTER
;* RESET ROUTINE OR AFTER THE EXECUTION OF A BUS RESET (BECAUSE OF TIMING
;* CONSIDERATIONS).
;*
;* INPUTS: CSRA - CONTAINS ADDRESS OF THE DUT CSR.
;* TXBFCA - CONTAINS ADDRESS OF DUT DMA BUFFER COUNT REGISTER.
;*
;* OUTPUTS: SKIP SELFTEST CODES ARE WRITTEN TO THE DUT REGISTERS.
;*
;* CALLING SEQUENCE: JSR PC,SKPSTS
;*
;* COMMENTS:
;*
;* SUBORDINATE ROUTINES CALLED: DELAY.
;--*****
SKPSTS:: SAVE JSR ;SAVE CONTENTS OF GPRS R0 THRU R5.
;R5,PREG05 ;CALL REGISTER SAVE SUBRT.
MOV #10,R4 ;PASS DELAY VALUE OF 10 MILLI-SECONDS.
JSR PC,DELAY ;DELAY FOR 10 MILLI-SECONDS.
;
; WRITE SKIP SELF-TEST CODE (52525) TO ALL THE INDEXED DUT REGISTERS.
;
MOV #NUMLNS!BIT05,R1 ;FORM IND.ADR.REG FIELD (PLUS M.R. BIT) WORD.
;THE ABOVE INCLUSION OF THE M.R. BIT IS NECESSARY BECAUSE OF THE
; LACK OF A M.R. BIT WRITE LOCK-OUT ON THE DMU-11.
MOV #52525,R3 ;INITIALISE THE SKIP SELF-TEST CODE.
4: DEC R1 ;SELECT THE NEXT SET OF DEVICE REGISTERS.
MOV CSRA,R4 ;GET THE ADDRESS OF THE CSR OF THE DUT.
MOV R1,(R4). ;SELECT A BANK OF DUT REGISTERS.
6: MOV R3,(R4). ;WRITE THE CODE TO A DUT REGISTER.
CMP R4,TXBFCA ;COMPARE POINTER WITH LAST REGISTER ADDRESS.
BLO 6: ;LOOP IF NOT ALL REGS DONE IN THIS BANK.
BIT #17,R1 ;TEST FOR IND.ADR.REG FIELD DECREMENTED TO 0.
BNE 4: ;LOOP UNTIL ALL REGISTERS CONTAIN THE CODE.
60: PASS ;RESTORE GPRS.
JSR PC,@(SP). ;RETURN TO PREG05 SUBRT.
RTS PC
    
```

3920
 3921
 3922
 3923
 3924
 3925
 3926
 3927
 3928
 3929
 3930
 3931
 3932
 3933
 3934
 3935
 3936
 3937
 3938
 3939
 3940
 3941
 3942
 3943
 3944
 3945
 3946
 3947
 3948
 3949

016672			
016672	004567	165162	
016676	012701	016714	
016702	012767	012020	165146
016710			
016710	104460		
016712	000432		
016714	040	116	117
016717	116	055	122
016722	105	114	101
016725	124	105	104
016730	040	124	105
016733	123	124	040
016736	105	122	122
016741	117	122	040
016744	106	117	125
016747	116	104	040
016752	104	125	122
016755	111	116	107
016760	040	124	105
016763	123	124	040
016766	105	130	105
016771	103	125	124
016774	111	117	116
016777	000		

```

.SBTTL GLOBAL SUBROUTINE - TSABRT
;*****
;* - TEST ABORT ROUTINE -
;* THIS SUBROUTINE IS USED WHEN A NON-TEST RELATED ERROR HAS BEEN FOUND
;* DURING THE EXECUTION OF THE CURRENT TEST.
;* IT IS USED TO INFORM THE OPERATOR THAT THE CURRENT TEST HAS BEEN
;* ABORTED.
;*
;* INPUTS: ERRMSG - CONTAINS THE NAME OF THE CURRENT TEST.
;*          ERRNBR - CONTAINS THE CORRECT ERROR NUMBER.
;*          THE REMAINDER OF THE ERRTB! IS CORRECTLY INITIALISED.
;*
;* OUTPUTS: MESSAGES ARE REPORTED TO THE OPERATOR.
;*
;* CALLING SEQUENCE: JSR PC,TSABRT
;*
;* COMMENTS:
;*
;* SUBORDINATE ROUTINES CALLED: ER1603.
;*****
TSABRT:: SAVE
                JSR R5,PREG05 ;SAVE CONTENTS OF GPRS R0 THRU R5.
                ;CALL REGISTER SAVE SUBRT.
                MOV #28,R1 ;PASS ADDRESS OF FIRST MESSAGE TO BE REPORTED.
                MOV #ER1603,ERRBLK ;SET-UP THE ERROR REPORTING ROUTINE.
                ;
                ; >>>> ERROR <<<<<.
                TRAP C$ERROR
28: BR 608 ;
        .ASCIZ / NON-RELATED TEST ERROR FOUND DURING TEST EXECUTION/

;EVEN
608: PASS
        RTS PC JSR ;RESTORE GPRS.
        ;PC,B(SP). ;RETURN TO PREG05 SUBRT.
    
```

3951
 3952
 3953
 3954
 3955
 3956
 3957
 3958
 3959
 3960
 3961
 3962
 3963
 3964
 3965
 3966
 3967
 3968
 3969
 3970
 3971 017004
 3972 017010
 3973 017012
 3974 017016
 3975 017022
 3976 017024

017004 004567 165050
 017010 010003
 017012 012702 002650
 017016 004767 175356
 017022 004736
 017024 000207

```

.SBTTL GLOBAL SUBROUTINE - TXDATP
; * *****
; * - TRANSMIT DATA PATTERN -
; * THIS SUBROUTINE IS USED IN THE FIHAVL.TST.
; * IT TRANSMITS A SPECIFIED NUMBER OF DATA BYTES ON THE SPECIFIED LINE.
; *
; * INPUTS:      R0 - CONTAINS THE NUMBER OF DATA BYTES TO TX.
; *              R1 - CONTAINS LINE NUMB ON WHICH TRANSMISSION IS TO TAKE PLACE.
; *              BUFBAS TO BUF MID CONTAINS A 256 BYTE DATA PATTERN.
; *
; * OUTPUTS:     DATA IS SENT OUT ON THE SPECIFIED LINE.
; *              CARRY SET = TX SUCCESSFUL.
; *
; * CALLING SEQUENCE:  TXDATP
; *
; * COMMENTS:
; *
; * SUBORDINATE ROUTINES CALLED: DODMA.
; - - *****
TXDATP:: SAVE
; SAVE CONTENTS OF GPRS R0 THRU R5.
; R5, PREG05 ;CALL REGISTER SAVE SUBRT.
        MOV     R0,R3      JSR
; PASS THE NUMBER OF CHARS TO TX.
        MOV     @BUFAS,R2
; PASS THE START OF THE DATA PATTERN TO TX.
        JSR     PC,DODMA   ;TRANSMIT THE DATA PATTERN.
601:    PASS
; RESTORE GPRS.
        JSR     PC,@(SP)+ ;RETURN TO PREG05 SUBRT.
        RTS     PC
    
```

```

3978 .SBTTL GLOBAL SUBROUTINE - TXDSBL
3979 ;* *****
3980 ;* - TRANSMITTER DISABLE -
3981 ;* THIS SUBROUTINE IS USED TO DISABLE TRANSMISSION ON SELECTED LINES BY,
3982 ;* CLEARING THE ASSOCIATED TX.ENABLE BIT ON THE DUT.
3983 ;*
3984 ;* INPUTS: R5 - BIT'S SET CORRESPOND TO LINES ON WHICH TO CLEAR TX.ENABLE.
3985 ;* CSRA - CONTAINS THE ADDRESS OF THE DUT CSR.
3986 ;* IESTAT - CONTAINS THE STATE OF TXIE AND RXIE BITS IN THE CSR.
3987 ;* NUMLNS - EQUATED TO BE THE MAXIMUM NUMBER OF LINES AVAILABLE.
3988 ;* TXAD2A - CONTAINS THE ADDRESS OF THE TBUFAD2 REGISTER.
3989 ;*
3990 ;* OUTPUTS: R5 - BIT'S SET INDICATE THE INITIAL STATES OF ALL TX.ENABLE BITS.
3991 ;* TBUFAD2 - THE STATE OF THE TX.ENABLE BIT MAY BE ALTERED.
3992 ;* THE CONTENTS OF THE IND.ADD.REG FIELD IN THE CSR ARE DESTROYED.
3993 ;*
3994 ;* CALLING SEQUENCE: JSR PC,TXDSBL
3995 ;*
3996 ;* COMMENTS:
3997 ;*
3998 ;* SUBORDINATE ROUTINES CALLED: NONE.
3999 ;* - - - - -
4000
4001 017026 TXDSBL:: SAVE ;SAVE CONTENTS OF GPRS R0 THRU R5.
4002 017026 004567 165026 JSR R5,PREG05 ;CALL REGISTER SAVE SUBRT.
4003 017032 010500 MOV R5,R0 ;COPY BIT MAP OF LINES TO DISABLE TRANSMISSION.
4004 017034 012701 000001 MOV #BIT0,R1 ;INITIALIZE THE SELECTED LINE BIT MASK.
4005 017040 016702 163176 MOV TXAD2A,R2 ;GET THE ADDRESS OF THE TBUFAD2 REGISTER.
4006 017044 005202 INC R2 ;GET THE ADDRESS OF THE MSBYTE OF TBUFAD2 REG.
4007 017046 012703 000020 MOV #NUMLNS,R3 ;GET MAXIMUM LINE NUMBER PLUS ONE.
4008 017052 016704 163200 MOV IESTAT,R4 ;GET THE STATES OF THE INT ENABLE BITS.
4009 017056 005005 CLR R5 ;LOG POSSIBLE TX DISABLED ON ALL LINES.
4010 ;*
4011 ;* SELECT EVERY LINE IN TURN, AND LOG THE STATE OF EACH TX.ENABLE BIT.
4012 017060 010477 163142 2$: MOV R4,BCSRA ;WRITE TO DUT CSR TO SELECT LINE REGISTERS.
4013 017064 105712 TSTB (R2) ;CHECK STATE OF TX.ENABLE BIT ON SELECTED LINE.
4014 017066 100001 BPL 4$ ;SKIP NEXT INSTRUCTION IF TX.ENABLE CLEAR.
4015 017070 050105 BIS R1,R5 ;LOG TX ENABLE BIT SET FOR SELECTED LINE.
4016 ;*
4017 ;* CLEAR TX.ENABLE ON LINES THAT HAVE A CORRESPONDING BIT SET IN THE TX DISABLE
4018 ;* LINE BIT MAP.
4019 ;*
4020 017072 030100 4$: BIT R1,R0 ;CHECK STATE OF DISABLE LINE BIT MAP.
4021 017074 001402 BEQ 6$ ;BRANCH IF THIS LINE TO REMAIN UNALTERED.
4022 017076 142712 000200 BICB #BIT7,(R2) ;CLEAR TX.ENABLE BIT ON SELECTED LINE.
4023 017102 005204 6$: INC R4 ;PREPARE TO SELECT REGISTERS FOR NEXT LINE.
4024 017104 006301 ASL R1 ;SHIFT BIT MAP FOR NEXT LINE.
4025 017106 005303 DEC R3 ;DECREMENT LINE NUMBER.
4026 017110 001363 BNE 2$ ;LOOP TO CHECK NEXT LINE.
4027 ;*
4028 017112 010566 000014 60$: PASS R5 ;RESTORE GPRS,EXCEPT
4029 017116 004736 MOV R5,R5SLOT(SP) ;PUT R5 IN STACK SLOT.
4030 017120 000207 JSR PC,(SP) ;RETURN TO PREG05 SUBRT.
;R5 - PREVIOUS STATES OF ALL TX.ENABLE BITS.
RTS PC

```



```

4032 .SBTTL GLOBAL SUBROUTINE TXENBL
4033 ;* *****
4034 ;* - TRANSMITTER ENABLE -
4035 ;* THIS SUBROUTINE IS USED TO ENABLE TRANSMISSION ON SELECTED LINES BY
4036 ;* SETTING THE ASSOCIATED TX.ENABLE BIT ON THE DUT.
4037 ;*
4038 ;* INPUTS: R5 - BIT'S SET CORRESPOND TO LINES ON WHICH TO SET TX.ENABLE.
4039 ;* CSRA - CONTAINS THE ADDRESS OF THE DUT CSR.
4040 ;* IESTAT - CONTAINS THE STATE OF TXIE AND RXIE BITS IN THE CSR.
4041 ;* NUMLNS - EQUATED TO BE THE MAXIMUM NUMBER OF LINES AVAILABLE.
4042 ;* TXAD2A - CONTAINS THE ADDRESS OF THE TBUFAD2 REGISTER.
4043 ;*
4044 ;* OUTPUTS: R5 - BIT'S SET INDICATE PREVIOUSLY DISABLED LINES.
4045 ;* TBUFAD2 - THE STATE OF THE TX.ENABLE BIT MAY BE ALTERED.
4046 ;* THE CONTENTS OF THE IND.ADD.REG FIELD IN THE CSR ARE DESTROYED.
4047 ;*
4048 ;* CALLING SEQUENCE: JSR PC,TXENBL
4049 ;*
4050 ;* COMMENTS:
4051 ;*
4052 ;* SUBORDINATE ROUTINES CALLED: NONE.
4053 ;*
4054 ;* *****
4055 017122 TXENBL:: SAVE ;SAVE CONTENTS OF GPRS R0 THRU R5.
017122 004567 164732 JSR R5,PREGOS ;CALL REGISTER SAVE SUBRT.
4056 017126 010500 MOV R5,R0 ;COPY BIT MAP OF LINES TO ENABLE.
4057 017130 012701 000001 MOV #BIT0,R1 ;INITIALIZE THE SELECTED LINE BIT MASK.
4058 017134 016702 163102 MOV TXAD2A,R2 ;GET THE ADDRESS OF THE TBUFAD2 REGISTER.
4059 017140 005202 INC R2 ;GET THE ADDRESS OF THE MSBYTE OF TBUFAD2 REG.
4060 017142 012703 000020 MOV #NUMLNS,R3 ;GET MAXIMUM LINE NUMBER.
4061 017146 016704 163104 MOV IESTAT,R4 ;GET THE STATES OF THE INT ENABLE BITS.
4062 017152 005005 CLR R5 ;CLEAR TX.ENABLE BIT LOG OF DISABLED LINES.
4063 ;*
4064 ;* SELECT EVERY LINE IN TURN,AND LOG ANY TX.ENABLE BIT THAT IS CLEAR.
4065 ;*
4066 017154 010477 163046 20: MOV R4,BCSRA ;WRITE TO DUT CSR TO SELECT LINE REGISTERS.
4067 017160 105712 TSTB (R2) ;CHECK STATE OF TX.ENABLE BIT ON SELECTED LINE.
4068 017162 100401 BMI 40 ;SKIP NEXT INSTRUCTION IF TX.ENABLE SET.
4069 017164 050105 BIS R1,R5 ;LOG TX ENABLE BIT CLEAR FOR SELECTED LINE.
4070 ;*
4071 ;* SET TX.ENABLE ON LINES THAT HAVE A CORRESPONDING BIT SET IN THE TX ENABLE
4072 ;* LINE BIT MAP.
4073 ;*
4074 017166 030100 40: BIT R1,R0 ;CHECK STATE OF TX.ENABLE LINE BIT MAP.
4075 017170 001402 BEQ 60 ;BRANCH IF THIS LINE TO REMAIN UNALTERED.
4076 017172 152712 000200 BISB #BIT7,(R2) ;ENABLE TRANSMISSION ON SELECTED LINE.
4077 017176 005204 60: INC R4 ;PREPARE TO SELECT REGISTERS FOR NEXT LINE.
4078 017200 006301 ASL R1 ;SHIFT BIT MAP FOR NEXT LINE.
4079 017202 005303 DEC R3 ;DECREMENT LINE NUMBER.
4080 017204 001363 BNE 20 ;LOOP TO CHECK NEXT LINE.
4081 ;*
4082 017206 010566 000014 60: PASS R5 ;RESTORE GPRS,EXCEPT
017206 010566 000014 MOV R5,R5SLOT(SP) ;PUT R5 IN STACK SLOT.
017212 004736 JSR PC,(SP) ;RETURN TO PREGOS SUBRT.
4083 ;R5 - LINE BIT MAP CORRESPONDING TO THE
4084 ; PREVIOUS LINES THAT WERE DISABLED.
4085 017214 000207 RTS PC

```

```

4087 .SBTTL GLOBAL SUBROUTINE TXIEO -
4088 ;** *****
4089 ;* TRANSMITTER INTERRUPT DISABLE -
4090 ;* THIS ROUTINE IS USED TO DISABLE TRANSMITTER INTERRUPTS IN THE DMU11.
4091 ;*
4092 ;* INPUTS: NONE.
4093 ;*
4094 ;* OUTPUTS: THE TX.INT.ENBL BIT IS CLEARED IN THE DUT CSR.
4095 ;* IESTST -CONTAINS THE UPDATED STATUS OF THE TX AND RX INTERRUPT
4096 ;* ENABLE BITS.
4097 ;*
4098 ;* CALLING SEQUENCE: JSR PC,TXIEO
4099 ;*
4100 ;* COMMENTS: THE CONTENTS OF THE INDIRECT ADDRESS REGISTER FIELD IN
4101 ;* THE DUT CSR ARE DESTROYED.
4102 ;*
4103 ;* SUBORDINATE ROUTINES CALLED: NONE.
4104 ;* - - *****
4105 017216 010046 TXIEO:: MOV RO,-(SP) ;SAVE CONTENTS OF RO ON THE STACK.
4106 017220 104440 GETPRI -(SP) ;SAVE CURRENT PROCESSOR PRIORITY ON THE STACK.
017222 010046 TRAP C$GPRI
4107 017224 SETPRI @PRI07 ;IGNORE ANY INTERRUPTS THAT MAY BE GENERATED.
017224 012700 000340 MOV RO,(SP)
017230 104441 MOV @PRI07,RO
4108 017232 042767 177677 163016 BIC @177677,IESTAT ;CLEAR TX.INT.ENBL BIT IN IESTAT.
4109 017240 016777 163012 162760 MOV IESTAT,BCSRA ;DISABLE TX INTERRUPTS.
4110 017246 SETPRI (SP). ;ENABLE INTERRUPTS TO THE PROCESSOR AGAIN.
017246 012600 MOV (SP).,RO
017250 104441 TRAP C$SPRI
4111 017252 012600 MOV (SP).,RO
4112 017254 000207 RTS PC ;RESTORE RO.

```

4114
4115
4116
4117
4118
4119
4120
4121
4122
4123
4124
4125
4126
4127
4128
4129
4130
4131
4132
4133 017256 052767 040000 162772
4134 017264 042767 137677 162764
4135 017272 016777 162760 162726
4136 017300 000207

```
.SBTTL GLOBAL SUBROUTINE TXIE1
; * *****
; * - TRANSMITTER INTERRUPT ENABLE
; * THIS ROUTINE IS USED TO ENABLE TRANSMITTER INTERRUPTS IN THE DMU11.
; *
; * INPUTS: NONE.
; *
; * OUTPUTS: THE TX.INT.ENBL BIT IS SET IN THE DUT CSR.
; * IESTST -CONTAINS THE UPDATED STATUS OF THE TX AND RX INTERRUPT
; * ENABLE BITS.
; *
; * CALLING SEQUENCE: JSR PC,TXIE1
; *
; * COMMENTS: THE CONTENTS OF THE INDIRECT ADDRESS REGISTER FIELD IN
; * THE DUT CSR ARE DESTROYED.
; *
; * SUBORDINATE ROUTINES CALLED: NONE.
; - *****
TXIE1:: BIS #BIT14,IESTAT ;SET TX.INT.ENBL BIT IN IESTAT.
        BIC #137677,IESTAT ;CLEAR ALL BITS EXCEPT TX RX I.E BITS.
        MOV IESTAT,@CSRA ;ENABLE TX INTERRUPTS.
        RTS PC
```

4138
4139
4140
4141
4142
4143
4144
4145
4146
4147
4148
4149
4150
4151
4152
4153
4154
4155
4156
4157
4158
4159
4160
4161 017302
017302 004567 164552
4162
4163
4164
4165 017306 010204
4166 017310 160104
4167 017312 103403
4168 017314 012701 177777
4169 017320 000442
4170
4171
4172
4173 017322 005004
4174 017324 000241
4175 017326 006001
4176 017330 006004
4177 017332 012700 000020
4178
4179
4180
4181 017336 010246
4182 017340 010346
4183 017342 160403
4184 017344 005602
4185 017346 103402
4186 017350 160102
4187 017352 103003
4188
4189
4190
4191
4192 017354 012603
4193 017356 012602

```
.SBTTL GLOBAL SUBROUTINE - UNSDIV
;+ *****
;+ - UNSIGNED DIVIDE ROUTINE -
;+ THIS SUBROUTINE IS USED TO DIVIDE A 32 BIT UNSIGNED DIVIDEND BY A
;+ 16 BIT UNSIGNED DIVISOR GIVING A 16 BIT QUOTIENT. ALL NUMBERS ARE
;+ CONSIDERED TO BE UNSIGNED. A SUCCESS FLAG IS NOT SET ON RETURN IF
;+ THE QUOTIENT WAS TOO BIG TO BE CONTAINED IN 16 BITS.
;+
;+ INPUTS: R1 - THE DIVISOR, UNSIGNED, 16 BITS.
;+ R2 - MOST SIGNIFICANT WORD OF THE DIVIDEND, UNSIGNED, 16 BITS.
;+ R3 - LEAST SIGNIFICANT WORD OF THE DIVIDEND, UNSIGNED, 16 BITS.
;+
;+ OUTPUTS: R1 - QUOTIENT, UNSIGNED, 16 BITS (177777 IF OVERFLOW).
;+ CARRY - SUCCESS FLAG, SET IF COMPLETE QUOTIENT FITS IN 16 BITS.
;+
;+ CALLING SEQUENCE: JSR PC,UNSDIV
;+
;+ COMMENTS: IF THE DIVISOR IS 0 THE QUOTIENT IS RETURNED AS ALL ONES
;+ (177777) AND THE CARRY IS CLEAR REGARDLESS OF THE DIVIDEND.
;+
;+ SUBORDINATE ROUTINES CALLED: NONE.
;-- *****

UNSDIV:: SAVE JSR ;SAVE CONTENTS OF GPRS R0 THRU R5.
; R5,PREG05 ;CALL REGISTER SAVE SUBRT.
;+
; CHECK FOR QUOTIENT GREATER THAN 16 BITS CONDITION.
;--
MOV R2,R4 ;GET MSW OF DIVIDEND FOR SUBTRACT.
SUB R1,R4 ;SUBTRACT DIVISOR FROM MSW OF DIVIDEND.
BCS 2$ ;IF IT DIDN'T GO, WE HAVE QUOTIENT < 16 BITS.
MOV @-1,R1 ;SET QUOTIENT TO ALL ONES (177777).
BR 60$ ;EXIT WITH CARRY CLEAR.

;+
; SET UP COUNTERS AND VARIOUS WORKING GPRS.
;--
2$: CLR R4 ;CLEAR THE LSW OF THE DIVISOR.
CLC ;CLEAR CARRY FOR THE SHIFT OF THE DIVISOR.
ROR R1 ; DIVISOR BY
ROR R4 ; 2(UNSIGNED)
MOV @16.,R0 ;SET UP INITIAL SHIFT COUNT TO 16.

;+
; THE SUBTRACT AND SHIFT LOOP.
;--
4$: MOV R2,-(SP) ;SAVE MSWORD OF DIVIDEND.
MOV R3,-(SP) ;SAVE LSWORD OF DIVIDEND.
SUB R4,R3 ;LSWORD DIVIDEND - LSWORD OF DIVISOR.
SBC R2 ;MSWORD DIVIDEND - BORROW
BCS 6$ ;IF BORROW FROM BORROW SUBTRACT, IT DIDN'T GO.
SUB R1,R2 ;MSWORD DIVIDEND - MSWORD OF DIVISOR.
BCC 8$ ;IF NO BORROW, IT WENT, CARRY IS CLEAR.

;+
; IT DIDN'T GO, SO WE SHIFT A 1 INTO THE QUOTIENT (COMPLEMENTED LATER).
; CARRY IS SET.
;--
6$: MOV (SP)+,R3 ;RESTORE LSWORD OF DIVIDEND.
MOV (SP)+,R2 ;RESTORE MSWORD OF DIVIDEND.
```

```

4194 017360 000401          BR      10$          ;GOTO SHIFT 1 INTO THE QUOTIENT.
4195
4196          ; IT WENT, SO WE RESTORE THE STACK AND SHIFT A 0 INTO QUOTIENT (WILL BE
4197          ; COMPLEMENTED LATER).  CARRY IS CLEAR.
4198
4199 017362 012626      8$:  MOV      (SP)+,(SP)+      ;POP THE SAVED DIVIDEND OFF OF THE STACK.
4200
4201          ; SHIFT THE RESULT OF THE SUBTRACT ATTEMPT INTO THE QUOTIENT SHIFT REG.
4202
4203 017364 006105      10$:  ROL      R5          ;SHIFT NEXT BIT INTO THE INVERTED QUOTIENT.
4204 017366 000241          CLC          ;DIVIDE THE
4205 017370 006001          ROR      R1          ; DEVISOR BY
4206 017372 006004          ROR      R4          ; 2 (UNSIGNED).
4207 017374 005300          DEC      R0          ;COUNT THIS SHIFT AND SUBTRACT.
4208 017376 001357          BNE     4$          ;LOOP FOR ANOTHER SHIFT & SUB IF NOT DONE.
4209 017400 005105          COM     R5          ;GET QUOTIENT FROM INVERTED QUOTIENT.
4210
4211          ; NOW WE EITHER ROUND UP OR LEAVE QUOTIENT ALONE.
4212
4213 017402 000241          CLC          ;CLEAR THE CARRY FOR THE SHIFT OF THE DIVIDEND.
4214 017404 006103          ROL     R3          ;MULTIPLY LSWORD OF DIVIDEND BY 2, MSWORD IS 0.
4215 017406 103402          BCS    12$         ;IF CARRY FROM SHIFT, ROUND UP.
4216 017410 160403          SUB    R4,R3       ;SUBTRACT DIVISOR FROM DIVIDEND.
4217 017412 103403          BCS    14$         ;IF BORROW, DON'T ROUND UP.
4218
4219          ; ROUND UP, EXTRA SUBTRACT WENT.
4220
4221 017414 005205      12$:  INC     R5          ;INCREMENT THE QUOTIENT BY ONE.
4222 017416 001001          BNE    14$         ;IF NO OVERFLOW, WE LEAVE THE ROUND UP.
4223 017420 005305          DEC     R5          ;DON'T LET ROUNDING CAUSE OVERFLOW.
4224
4225          ; ALL DONE, PASS QUOTIENT AND EXIT.
4226
4227 017422 010501      14$:  MOV     R5,R1       ;PASS QUOTIENT BACK IN R1.
4228 017424 000261          SEC          ;INDICATE NO OVERFLOW.
4229
4230 017426          60$:  PASS    R1          ;RESTORE GPRS. LEAVE THE FOLLOWING INTACT:
          017426 010166 000004      MOV    R1,R1SLOT(SP) ;PUT R1 IN STACK SLOT.
          017432 004736          JSR    PC,@(SP)+   ;RETURN TO PREGOS SUBRT.
4231
4232 017434 000207          RTS    PC          ;R1 - 16 BIT, UNSIGNED QUOTIENT.
          ;CARRY - SET INDICATES NO OVERFLOW (SUCCESS).

```

4234
4235
4236
4237
4238
4239
4240
4241
4242
4243
4244
4245
4246
4247
4248
4249
4250
4251
4252
4253
4254
4255
4256
4257
4258
4259
4260
4261
4262
4263
4264
4265
4266
4267
4268
4269
4270
4271
4272
4273
4274
4275
4276
4277
4278

017436
017436 004567 164416
017442 010204
017444 010102
017446 042701 170000
017452 042702 007777
017456 000302
017460 006202
017462 006202
017464 006202
017466 016202 002336
017472 010203
017474 004767 175230
017500 010002
017502 010266 000006
017506 004736
017510 000207

```
.SBTTL GLOBAL SUBROUTINE - WAIBIS
;*****
;* - WAIT FOR BIT SET ROUTINE -
;* THIS SUBROUTINE WAITS FOR THE SPECIFIED BIT TO BECOME SET. IF THE
;* SPECIFIED BIT GOES TO A SET STATE WITHIN THE SPECIFIED TIME OUT
;* PERIOD A SUCCESS INDICATION IS RETURNED BY THIS ROUTINE.
;* THE LAST VALUE WHICH IS READ LOOKING FOR THE CONDITION IS RETURNED TO
;* ALLOW THE USE OF THIS ROUTINE TO LOOK FOR DESTRUCTIVE READ CONDITIONS.
;*
;* INPUTS: R1 - TIME-OUT VALUE AND BIT NUMBER INDICATION:
;* BITS 15 THRU 12 - NUMBER OF BIT TO TEST (RANGE 0 THRU 15).
;* BITS 11 THRU 0 - TIME-OUT VALUE IN MILLI-SECONDS (4095 MAX).
;* R2 - ADDRESS OF WORD CONTAINING THE BIT TO TEST.
;* MSLCNT.
;*
;* OUTPUTS: R2 - THE LAST WORD WHICH WAS READ TO CHECK FOR THE CONDITION.
;* CARRY - SUCCESS FLAG (CARRY SET IF BIT SET BEFORE TIME-OUT).
;*
;* CALLING SEQUENCE: MOV #130040,R1 ;PASS BIT 11 (13 OCTAL) AND
;* ; 32 (40 OCTAL) MS DELAY.
;* MOV #LABEL,R2 ;TEST BIT IN WORD AT "LABEL".
;* JSR PC,WAIBIS ;WAIT 32 MS FOR BIT 11 TO SET.
;*
;* COMMENTS:
;*
;* SUBORDINATE ROUTINES CALLED: MSLGET.
;*****
```

```
WAIBIS:: SAVE
;SAVE CONTENTS OF GPRS R0 THRU R5.
;R5,PREG05 ;CALL REGISTER SAVE SUBRT.
;SET UP THE ADDRESS PARAMETER FOR MSLGET.
;*****
MOV R2,R4 JSR
MOV R1,R2
BIC #170000,R1 ;SEPERATE DELAY COUNT OUT OF PASSED PARAMETER.
BIC #7777,R2 ;SEPERATE LINE NUMBER FIELD OF PASSED PARAM.
SWAB R2 ;PUT LINE NUMBER FIELD IN LSBYTE.
ASR R2 ;SHIFT THE LINE NUMBER FIELD INTO THE PROPER
ASR R2 ; POSITION TO USE IT AS A WORD TABLE OFFSET
ASR R2 ; FOR THE TABLE LOOKUP OF THE LINE BIT MAP.
MOV BITTBL(R2),R2 ;GET BIT MAP OF LINE TO TEST FROM TABLE.
MOV R2,R3 ;INDICATE THAT THE BIT SHOULD BE SET.
JSR PC,MSLGET ;WAIT FOR THE BIT TO BE SET WITHIN TIME OUT.
; CARRY IS CORRECT UPON MSLGET RETURN.
MOV R0,R2 ;PASS LAST VALUE READ AS OUTPUT PARAMETER.
PASS R2 ;RESTORE GPRS, EXCEPT THE FOLLOWING:
MOV R2,R2SLOT(SP) ;PUT R2 IN STACK SLOT.
JSR PC,@(SP) ;RETURN TO PREG05 SUBRT.
; R2 - LAST VALUE READ LOOKING FOR CONDITION.
; CARRY - SUCCESS FLAG (SET IF BIT FOUND SET).
```

4280
4281
4282
4283
4284
4285
4286
4287
4288
4289
4290
4291
4292
4293
4294
4295
4296
4297
4298
4299 017512
4300 017516
4301 017522
4302 017526
4303 017532
4304 017534
4305 017540
4306 017544
4307
4308 017546
4309 017546
4310 017550

017512 004567 164342
017516 012701 170536
017522 016702 162500
017526 004767 177704
017532 103005
017534 012704 000005
017540 004767 174516
017544 000261
017546 004736
017550 000207

```

.SBTTL GLOBAL SUBROUTINE                                WAITTX
; * *****
; * - WAIT FOR TX TO FINISH
; * THIS SUBROUTINE IS USED IN THE FIHAWL.TST.
; * IT WAITS FOR TRANSMISSION TO COMPLETE IE TX_ACTION. THEN DELAYS
; * FOR 5 MILLISECONDS TO ALLOW TIME FOR THE LAST CHARACTER TO GET INTO
; * THE FIFO.
; *
; * INPUTS:      CSRA  CONTAINS THE ADDRESS OF THE CSR.
; *
; * OUTPUTS:     CARRY - SET INDICATES SUCCESS.
; *
; * CALLING SEQUENCE:  JSR   PC,WAITTX
; *
; * COMMENTS:
; *
; * SUBORDINATE ROUTINES CALLED: DELAY,WAIBIS.
; -- *****
WAITTX:: SAVE
; SAVE CONTENTS OF GPRS R0 THRU R5.
; R5,PREG05 ;CALL REGISTER SAVE SUBRT.
; PASS TIME-OUT VALUE OF 350 MILLI SECS.
; PASS THE ADDRESS OF THE CSR.
; WAIT FOR DMA TO COMPLETE, TX_ACTION SET.
; BRANCH IF NO TX_ACTION, ABORT THE TEST.
; PASS DELAY OF 5 MILLI SECS.
; WAIT FOR LAST CHAR TO ARRIVE IN THE FIFO.
; SET CARRY TO INDICATE SUCCESS.
        MOV     #170536,R1
        MOV     CSRA,R2
        JSR     PC,WAIBIS
        BCC    60$
        MOV     #5,R4
        JSR     PC,DELAY
        SEC
60$:    PASS
; RESTORE GPRS.
; PC,B(SP);
; RETURN TO PREG05 SUBRT.
; PASS THE CARRY BIT. SET INDICATES SUCCESS.
        JSR
        RTS    PC

```

4312
 4313
 4314
 4315
 4316
 4317
 4318
 4319
 4320
 4321
 4322
 4323
 4324
 4325
 4326
 4327
 4328
 4329
 4330
 4331
 4332
 4333
 4334
 4335 017552
 017552 004567 164302
 4336
 4337
 4338
 4339 017556 016701 162454
 4340 017562 010002
 4341 017564 010503
 4342 017566 012704 177777
 4343
 4344
 4345
 4346 017572 004767 173572
 4347
 4348 017576
 017576 004736
 4349 017600 000207

```
.SBTTL GLOBAL SUBROUTINE WTWLNC
.....
; * - LINE CONTROL REGISTER SETUP ROUTINE
; * THIS SUBROUTINE IS USED TO SET THE DEVICE UNDER TEST (DUT) LINE
; * CONTROL REGISTERS (LNCTRL) TO THE SPECIFIED STATE. ONLY THE LNCTRLS
; * FOR THE SPECIFIED LINES ARE ALTERED.
; *
; * INPUTS: R0 - NEW LINE PARAMETERS.
; * R5 - BIT MAP OF LINES TO BE ALTERED.
; * CSRA - CONTAINS ADDRESS OF THE DUT CSR.
; * IESTAT - CONTAINS THE CURRENT STATE OF THE TX AND RX INTERRUPT
; * ENABLE BITS IN THE CSR.
; * LNCTRA CONTAINS ADDRESS OF THE DUT LNCTRL REGISTERS.
; *
; * OUTPUTS: LNCTRL - SPECIFIED DUT LINE CONTROL REGISTERS ARE ALTERED.
; *
; * CALLING SEQUENCE: JSR PC,WTWLNC
; *
; * COMMENTS:
; *
; * SUBORDINATE ROUTINES CALLED: ALTFLD.
; * - - - - -
WTWLNC:: SAVE JSR R5,PREG05 ;SAVE CONTENTS OF GPRS R0 THRU R5.
; * ;CALL REGISTER SAVE SUBRT.
; *
; * SET UP THE PARAMETERS FOR THE CALL TO ALTFLD.
; * - - - - -
; * MOV LNCTRA,R1 ;SET UP THE REGISTER ADDRESS PARAMETER.
; * MOV R0,R2 ;SET UP THE DESIRED REGISTER CONTENTS.
; * MOV R5,R3 ;SET UP THE BIT MAP OF LINES TO ALTER.
; * MOV #-1,R4 ;SELECT ALL REGISTER BITS TO BE ALTERED.
; *
; * CALL THE SUBROUTINE WHICH ALTERS THE REGISTER CONTENTS.
; * - - - - -
; * JSR PC,ALTFLD ;ALTER THE REGISTER CONTENTS.
; *
601: PASS JSR PC,@(SP) ;RESTORE GPRS.
RTS PC JSR PC,@(SP) ;RETURN TO PREG05 SUBRT.
```


4351
 4352
 4353
 4354
 4355
 4356
 4357
 4358
 4359
 4360
 4361
 4362
 4363
 4364
 4365
 4366
 4367
 4368
 4369
 4370
 4371
 4372
 4373
 4374 017602
 017602 004567 164252
 4375
 4376
 4377
 4378 017606 016701 162420
 4379 017612 010002
 4380 017614 010503
 4381 017616 012704 177777
 4382
 4383
 4384
 4385 017622 004767 173542
 4386
 4387 017626
 017626 004736
 4388 017630 000207

```

.SBTTL GLOBAL SUBROUTINE WTWLPR
;*****
;* - LINE PARAMETER REGISTER SETUP ROUTINE -
;* THIS SUBROUTINE IS USED TO SET THE DEVICE UNDER TEST (DUT) LINE
;* PARAMETER REGISTERS (LPR) TO THE SPECIFIED STATE. ONLY THE LPRS FOR
;* THE SPECIFIED LINES ARE ALTERED.
;*
;* INPUTS: R0 - NEW LINE PARAMETERS.
;* R5 - BIT MAP OF LINES TO BE ALTERED.
;* CSRA - CONTAINS ADDRESS OF THE DUT CSR.
;* IESTAT - CONTAINS THE CURRENT STATE OF THE TX AND RX INTERRUPT
;* ENABLE BITS IN THE CSR.
;* LPRA CONTAINS ADDRESS OF THE DUT LPR.
;*
;* OUTPUTS: LPR - SPECIFIED DUT LINE PARAMTER REGISTERS ARE ALTERED.
;*
;* CALLING SEQUENCE: JSR PC,WTWLPR
;*
;* COMMENTS:
;*
;* SUBORDINATE ROUTINES CALLED: ALTFLD.
;*****
WTWLPR:: SAVE JSR R5,PREG05 ;SAVE CONTENTS OF GPRS R0 THRU R5.
; ;CALL REGISTER SAVE SUBRT.
; SET UP THE PARAMETERS FOR THE CALL TO ALTFLD.
;
MOV LPRA,R1 ;SET UP THE REGISTER ADDRESS PARAMETER.
MOV R0,R2 ;SET UP THE DESIRED REGISTER CONTENTS.
MOV R5,R3 ;SET UP THE BIT MAP OF LINES TO ALTER.
MOV #-1,R4 ;SELECT ALL REGISTER BITS TO BE ALTERED.
;
; CALL THE SUBROUTINE WHICH ALTERS THE REGISTER CONTENTS.
;
JSR PC,ALTFLD ;ALTER THE REGISTER CONTENTS.
600: PASS ;RESTORE GPRS.
RTS PC JSR PC,@(SP), ;RETURN TO PREG05 SUBRT.
    
```

4390
4391
4392
4393
4394
4395
4396
4397
4398
4399
4400
4401
4402
4403
4404
4405
4406
4407
4408
4409
4410
4411
4412
4413 017632 005767 162456
4414 017636 001402
4415 017640 005367 162450
4416 017644 005767 162446
4417 017650 001402
4418 017652 005367 162440
4419 017656 005367 162436
4420 017662 001006
4421 017664 016767 162432 162426
4422 017672 010046
4423 017674
017674 104422
4424 017676 012600
4425 017700 000002

```
.SBTTL INTERRUPT SERVICE ROUTINE - CLKINT
;*****
; THIS ROUTINE IS EXECUTED CLKHRZ TIMES PER SECOND. IT DECREASES THE
; TWO TIMER COUNTERS DOWN TO ZERO.
;
; INPUTS:    TIMER1  TIMER COUNTER #1.
;            TIMER2 - TIMER COUNTER #2.
;            TIMER3 - TIMER COUNTER FOR CALL OF BREAK MACRO.
;
; OUTPUTS:   THE 2 TIMER COUNTERS ARE DECREMENTED IF THEY ARE NOT ZERO.
;
; CALLING SEQUENCE:  PUT #CLKINT IN THE CLOCK INTERRUPT VECTOR SLOT.
;                    PUT THE DESIRED TIME PERIOD (SECONDS TIMES CLKHRZ) IN
;                    EITHER TIMER1 OR TIMER2 AND POLL THE RESPECTIVE TIMEP
;                    COUNTER TO DETECT ITS GOING TO 0 ON TIME-OUT.
;
; COMMENTS:  THE 2 COUNTERS WILL NOT WRAPAROUND BUT WILL STOP AT 0. THIS
;            ALLOWS THE DETECTION OF A TIME-OUT ANY TIME AFTER THE TIME-OUT
;            HAS OCCURRED UNTIL THE TIMER COUNTER IS SET TO ANOTHER VALUE.
;
; SUBORDINATE ROUTINES CALLED: NONE.
;-----*****
CLKINT:: TST    TIMER1      ;CHECK FOR TIMER1 AT ZERO.
        BEQ    2$          ;BRANCH TO LEAVE IT AT ZERO IF IT IS ZERO.
        DEC    TIMER1      ;DECREMENT TIME COUNT.
2$:     TST    TIMER2      ;CHECK FOR TIMER2 AT ZERO.
        BEQ    4$          ;BRANCH TO LEAVE IT ALONE IF IT'S ALREADY ZERO.
        DEC    TIMER2      ;DECREMENT TIME COUNT.
4$:     DEC    TIMER3      ;DECREMENT THE BREAK COUNT.
        BNE    60$         ;EXIT IF NOT TIME TO CALL BREAK.
        MOV    BCOUNT,TIMER3 ;SET UP TIME TILL NEXT BREAK.
        MOV    RO,-(SP)    ;SAVE CONTENTS OF RO FROM BREAK MACRO.
        BREAK              ;CHECK FOR OPERATOR CONTROL/C.
                                TRAP    C#BRK
60$:   MOV    (SP),RO      ;RESTORE CONTENTS OF RO.
        RTI
```

4427
4428
4429
4430
4431
4432
4433
4434
4435
4436
4437
4438
4439
4440
4441
4442
4443
4444
4445
4446

```

.SBTTL INTERRUPT SERVICE ROUTINE          RXDECT
; * *****
; *                                     - RX INT DECTION ROUTINE
; * THIS ROUTINE DETECTS AN RX INTERRUPT BY SETTING THE RXINTC WORD TO 1.
; * THIS ROUTINE IS USED IN THE RXTIMER TESTS.
; *
; * INPUTS:      RXINTC - STORGE FOR THE INTERRUPT COUNT.
; *
; * OUTPUTS:     RXINTC - SET TO 1.
; *
; * CALLING SEQUENCE:  PUT THE ADDRESS OF THE LABEL RXDECT IN THE VECTOR
; *                   LOCATION.
; *
; * COMMENTS:     THIS ROUTINE DOES NOT READ THE RXFIFO.
; *
; * SUBORDINATE ROUTINES CALLED: NONE.
; -- *****
RXDECT:: MOV    #1,RXINTC      ;INDICATE THAT AN RX-INT HAS OCCURED.
         RTI

```

017702 012767 000001 162356
017710 000002

```

4448 .SBTTL GLOBAL TRAP SERVICE ROUTINE - TP4RTN
4449 ;*****
4450 ;* BUS TIME-OUT TRAP (004 TRAP) SERVICE ROUTINE -
4451 ;* THIS ROUTINE DETERMINES IF THE 004 TRAP WAS CAUSED BY
4452 ;* AN "EXPECTED" ERROR OR NOT BY EXAMINING THE RETURN PC VALUE ON THE
4453 ;* STACK. IF THE TRAP IS UNEXPECTED, THIS ROUTINE JUMPS TO THE NORMAL
4454 ;* DIAGNOSTIC SUPERVISOR 004 TRAP HANDLING ROUTINE.
4455 ;*
4456 ;*
4457 ;* INPUTS: SP - POINTS TO THE PC WHERE THE TRAP OCCURED.
4458 ;* ADRPTR - LABEL AT THE ADDRESS WHERE "EXPECTED" TRAPS OCCUR.
4459 ;* TP4FLG - 004 TRAP FLAGS.
4460 ;*
4461 ;* OUTPUTS: TP4FLG - BIT 15 IS SET IF "EXPECTED" TRAP OCCURED.
4462 ;*
4463 ;* CALLING SEQUENCE: PUT ADDRESS POINTED TO BY TP4RTN IN 004 VECTOR.
4464 ;* OCCURENCE OF 004 TRAP VECTORS TO THIS ROUTINE.
4465 ;*
4466 ;* COMMENTS: ANY 004 TRAP WHICH OCCURS AT AN ADDRESS OTHER THAN THAT LABELED
4467 ;* ADRPTR WILL BE HANDLED BY THE NORMAL 004 TRAP SERVICE ROUTINE.
4468 ;*
4469 ;* SUBORDINATE ROUTINES CALLED: NONE.
4470 ;*****
4471
4472 017712 021627 014200 TP4RTN:: CMP (SP),#ADRPTR ;COMPARE EXPECTED ADR AGAINST TRAP RET PC.
4473 017716 001402 BEQ 2$ ;IF THEY MATCH, CONTINUE THIS ROUTINE.
4474 017720 000177 162352 JMP @TP4VEC ;IF NOT, JUMP TO NORMAL 004 TRAP SERVICE RTN.
4475 017724 052767 100000 162346 2$: BIS #BIT15,TP4FLG ;SET THE 004 TRAP OCCURED FLAG.
4476 017732 000002 RTI ;ALL DONE, GO BACK TO THE TEST.
    
```

```

4478 .SBTTL INTERRUPT SERVICE ROUTINE TXAINT
4479 ;* *****
4480 ;* - TRANSMIT ACTION INTERRUPT SERVICE ROUTINE
4481 ;* THIS ROUTINE HANDLES A TX INTERRUPT BY COUNTING THE INTERRUPT,
4482 ;* SETTING A FLAG IF THE TX_ACTION BIT IS CLEAR, AND READING THE CSR
4483 ;* UNTIL THE TX_ACTION BIT CLEARS OR THE MAXIMUM READ COUNT IS EXCEEDED.
4484 ;*
4485 ;* INPUTS: CSRA - CONTAINS THE ADDRESS OF THE CSR.
4486 ;* TXINTC - HOLDS THE COUNT OF THE NUMBER OF TX INTERRUPTS.
4487 ;* TXINTF - TX INTERRUPT FLAGS.
4488 ;*
4489 ;* OUTPUTS: TXINTC - CONTAINS THE UPDATED TX INTERRUPT COUNT.
4490 ;* TXINTF - TX INTERRUPT FLAGS (BIT 15 SET IF TX_ACTION CLEAR
4491 ;* BIT 14 SET IF MAX READ COUNT EXCEEDED)
4492 ;*
4493 ;* CALLING SEQUENCE: PUT THE ADDRESS OF THE LABEL TXAINT IN THE VECTOR
4494 ;* LOCATION.
4495 ;*
4496 ;* COMMENTS:
4497 ;*
4498 ;* SUBORDINATE ROUTINES CALLED: NONE
4499 ;*
4500 ;*
4501 ;*
4502 ;*
4502 017734 TXAINT:: SAVE
4503 017734 004567 164120 JSR R5,PREG05 ;CALL REGISTER SAVE SUBRT.
4504 017740 016701 162326 MOV TXINTC,R1 ;GET THE TX INT COUNT.
4505 017744 005201 INC R1 ;INCREMENT THE COUNT.
4506 017746 102001 BVC 2# ;BRANCH IF NO OVERFLOW OCCURED.
4507 017750 005301 DEC R1 ;RESET THE COUNT TO 177777.
4508 017752 010167 162314 2#: MOV R1,TXINTC ;SAVE THE NEW COUNT.
4509 017756 016703 162312 MOV TXINTF,R3 ;GET THE TX-INT FLAGS.
4510 017762 005777 162240 TST @CSRA ;READ THE CSR.
4511 017766 100402 BMI 4# ;AVOID SETTING THE ERROR FLAG IF
4512 ; THERE IS A TX_ACTION.
4513 017770 052703 100000 BIS @BIT15,R3 ;SET THE FLAG.
4514 017774 010367 162274 4#: MOV R3,TXINTF ;UPDATE THE TX-INT FLAGS.
4515 020000 012702 000040 MOV @32.,R2 ;SET THE MAX TX_ACTION READ COUNT.
4516 ;*
4517 ;* READ THE CSR UNTIL THE TX_ACTION FIFO IS EMPTY OR THE MAX READ COUNT
4518 ;* IS EXCEEDED.
4519 ;*
4520 020004 005777 162216 6#: TST @CSRA ;READ THE CSR.
4521 020010 100005 BPL 60# ;EXIT IF TX_ACTION FIFO IS EMPTY.
4522 020012 005302 DEC R2 ;DECREMENT THE MAX READ COUNT.
4523 020014 001373 BNE 6# ;BRANCH TO READ ANOTHER TX_ACTION IF MAX READ
4524 ; COUNT IS NOT EXCEEDED.
4525 020016 052767 040000 162250 60#: BIS @BIT14,TXINTF ;SET THE "MAX TX_ACTION COUNT EXCEEDED" FLAG.
4526 020024 004736 PASS ;*
4527 020026 000002 JSR PC,@(SP). ;RETURN TO PREG05 SUBRT.
RTI

```

4536
4537
4538
4539
4540
4541
4542
4543
4544

.SBTTL REPORT CODING SECTION

; THE REPORT CODING SECTION CONTAINS THE
; "PRINTS" CALLS THAT GENERATE STATISTICAL REPORTS.

4545 020030
020030
4546
4547 020030
020030 000167
020032 000000
4548
4549
4550
4551 020034
020034
020034 104425

BGNRPT

EXIT RPT

.EVEN

ENDRPT

L\$RPT::

.WORD J\$JMP
.WORD L10017-2

L10017:
TRAP C\$RPT

4553
4561
4562
4563
4564
4565
4566
4567
4568 020036
020036
4569
4570 020036 177777
4571 020040 177777
4572 020042 177777
4573
4574 020044
4575

.SBTTL PROTECTION TABLE

; THIS TABLE IS USED BY THE RUNTIME SERVICES
; TO PROTECT THE LOAD MEDIA.
; **

BGNPROT

L#PROT::

-1
1
-1

; OFFSET INTO P-TABLE FOR CSR ADDRESS
; OFFSET INTO P-TABLE FOR MASSBUS ADDRESS
; OFFSET INTO P-TABLE FOR DRIVE NUMBER

ENDPROT

```

4597
4598
4599
4600 .SBTTL INITIALIZE SECTION
4601 ;**
4602 ;*****
4603 ;* THIS SECTION CONTAINS THE CODE WHICH IS PERFORMED AT THE BEGINNING OF
4604 ;* EACH PASS OR AFTER A CONTINUE COMMAND.
4605 ;* THIS CODE PERFORMS THE FOLLOWING ACTIONS:
4606 ;*
4607 ;* MOVES THE INFORMATION HELD IN THE HARDWARE P-TABLE INTO THE GLOBAL
4608 ;* DATA AREA.
4609 ;*
4610 ;*****
4611 ;--
4611 020044 BGNINIT
4611 020044
4612 ;SEE IF PROGRAM JUST STARTED, BR IF YES L$INIT::
4613 020044 012700 000040 READEF @F.START
4613 020044 104447
4614 020052 BCOMPLETE NEWSTA
4614 020052 103416
4615 ;SEE IF PROGRAM JUST RESTARTED, BR IF YES
4616 020054 012700 000037 READEF @EF.RESTART
4616 020054 104447
4617 020062 BCOMPLETE NEWRES
4617 020062 103556
4618 ;SEE IF THIS IS A NEW PASS, BR IF YES
4619 020064 012700 000035 READEF @EF.NEW
4619 020064 104447
4620 020072 BCOMPLETE NEWPAS
4620 020072 103555
4621 ;SEE IF PROGRAM WAS JUST CONTINUED
4622 020074 012700 000036 READEF @EF.CONTINUE
4622 020074 104447
4623 020102 BNCOMPLETE GETPRM
4623 020102 103161
4624 020104 000167 000540 JMP ENDIT
4625 020110
4626 020110 104433 BRESET ;RESET THE BUS TO PREVENT ILLEGAL INTERRUPTS.
4627 ;* TRAP C$RESET
4628 ;*
4629 ;* SET UP FOR LINE TIME CLOCK INTERRUPTS.
4630 ;*
4630 020112 012700 000114 CLOCK L,R1 ;GET THE CLOCK PARAMETERS.
4630 020112 104462
4630 020120 010001
4631 020122 012167 162156 MOV (R1)+,CLKCSR ;STORE CLOCK CSR ADDRESS.
4632 020126 012167 162154 MOV (R1)+,CLKBRL ;STORE CLOCK BUS REQ INT LEVEL.
4633 020132 012167 162152 MOV (R1)+,CLKVEC ;STORE CLOCK INTERRUPT VECTOR.
4634 020136 012167 162150 MOV (R1)+,CLKHRZ ;STORE CLOCK FREQUENCY.
4635 020142 026727 162144 000062 CMP CLKHRZ,#50. ;TEST FOR 50HZ LINE FREQUENCY.
4636 020150 001004 BNE 2$ ;BRANCH IF CLOCK IS NOT 50HZ.

```



```

4637 020152 012767 000024 162144      MOV    #20.,MSTICK      ;INDICATE 20MS PER CLOCK TICK.
4638 020160 000403                    BR      4#
4639 020162 012767 000021 162134 2#:  MOV    #17.,MSTICK      ;INDICATE 17 MS PER CLOCK TICK.
4640 020170 012746 000300 4#:  SETVEC  CLKVEC,#CLKINT,#PRI06 ;INITIALIZE CLOCK INTERRUPT VECTOR.
                                MOV    #PRI06,(SP)
                                MOV    #CLKINT,(SP)
                                MOV    CLKVEC,-(SP)
                                MOV    #3,-(SP)
                                TRAP   C#SVEC
                                ADD    #10,SP
4641 020216 016700 162070      MOV    CLKHRZ,RO      ;INITIALIZE THE BREAK COUNT
4642 020222 006300      ASL    RO              ; TO CAUSE A BREAK
4643 020224 010067 162072      MOV    RO,BCOUNT     ; EVERY 2 SECONDS.
4644 020230 012700 000240      SETPRI #PRI05        ;ALLOW CLOCK INTERRUPTS DISABLE OTHERS.
                                MOV    #PRI05,RO
                                TRAP   C#SPRI
4645
4646      ;+
4647      ; ENABLE THE LINE TIME CLOCK (LTC) CHECKING TO MAKE SURE THAT THE CSR
4648      ; IS ACCESSABLE.
4649      ; FIRST SET UP TO CATCH ANY 004 TRAPS WHICH OCCUR:
4650 020236 016767 157542 162032      MOV    4,TP4VEC      ;SAVE THE EXISTING 004 TRAP VECTOR.
4651 020244 012767 017712 157532      MOV    #TP4RTN,4    ;SET 004 TRAP VECTOR TO OUR SERVICE RTN ADR.
4652
4653      ;+
4654      ; ENABLE LTC CHECKING FOR 004 TRAP IN CASE CSR IS NOT THERE.
4655 020252 005067 162022      CLR    TP4FLG        ;CLEAR THE 004 TRAP FLAG.
4656 020256 012767 000100 162016      MOV    #BIT6,WORD1   ;SET UP TO SET BIT6 OF THE LTC CSR.
4657 020264 012700 002302      MOV    #WORD1,RO     ;SET UP WORD1 AS THE CKTRAP MOVE SOURCE.
4658 020270 016701 162010      MOV    CLKCSR,R1     ;SET UP LTC CSR AS DESTINATION FOR CKTRAP MOVE.
4659 020274 004767 173666      JSR    PC,CKTRAP     ;MOVE AND CHECK FOR TRAP.
4660 020300 016767 161772 157476      MOV    TP4VEC,4      ;RESTORE THE NORMAL 004 TRAP VECTOR.
4661 020306 103403      BCS    6#            ;IF NO TRAP, LTC IS THERE SO CONTINUE.
4662 020310 005067 161776      CLR    CLKHRZ        ;CLEAR LTC FREQUENCY WORD TO INDICATE NO LTC.
4663 020314 000402      BR     8#            ;BYPASS THE FOLLOWING CALIBRATION PROCEDURES.
4664
4665      ;+
4666      ; CALIBRATE THE DELAY ROUTINE MILLI-SECOND DELAY COUNT VALUE.
4667 020316 004767 173230 6#:  JSR    PC,CALMSL
4668
4669      ;+
4670      ; CHECK FOR MEMORY MANAGEMENT PRESENT ON THIS MACHINE.
4671      ; IF MEM MGT IS PRESENT, DISABLE IT.
4672 020322 016767 157456 161746 8#:  MOV    4,TP4VEC      ;SAVE THE EXISTING 004 TRAP VECTOR.
4673 020330 012767 017712 157446      MOV    #TP4RTN,4    ;SET 004 TRAP VECTOR TO OUR SERVICE RTN ADR.
4674 020336 005067 161736      CLR    TP4FLG        ;CLEAR THE 004 TRAP FLAG.
4675 020342 005067 161734      CLR    WORD1         ;PREPARE TO CLEAR THE MEM MGT SRO REGISTER.
4676 020346 012700 002302      MOV    #WORD1,RO     ;SELECT CLEARED WORD AS CKTRAP RTN SOURCE.
4677 020352 016701 161752      MOV    MMSRO,R1      ;SELECT MEM MGT SRO REGISTER AS DESTINATION.
4678 020356 005067 161750      CLR    MMPRES        ;INDICATE NO MEM MGT PRESENT IN CASE IT ISN'T.
4679 020362 005067 161746      CLR    MMENAB        ;INDICATE MEM MGT IS NOT ENABLED.
4680 020366 004767 173574      JSR    PC,CKTRAP     ;CLEAR THE MEM MGT SRO REG AND CHECK FOR TRAP.
4681 020372 016767 161700 157404      MOV    TP4VEC,4      ;RESTORE THE NORMAL 004 TRAP VECTOR.
4682 020400 103003      BCC    10#          ;SKIP INDICATING MEM MGT PRESENT IF IT ISN'T.
4683 020402 012767 000001 161722      MOV    #1,MMPRES     ;INDICATE THAT MEM MGT IS PRESENT.
4684 020410 005067 161650 10#:  CLR    PASCNT        ;CLR COUNTER USED IN REPORTING ROM VERSION.
4685 020414 000167 000006      JMP    NEWPAS        ;SKIP AROUND THE BUS RESET, IT'S BEEN DONE.

```

```

4686
4687 020420      104433      161636      NEWRES: BRESET          ;RESET THE BUS TO PREVENT ILLEGAL INTERRUPTS.
                                TRAP      C$RESET
4688 020422      005067      161636      CLR      PASCNT          ;CLR COUNTER USED IN REPORTING ROM VERSION #.
4689 020426
4690 020426      012767      177777      161570      NEWPAS: MOV      #-1,UNITN ;RESET LOGICAL DEVICE TO -1
4691
4692
4693
4694
4695 020434      005267      161624      ; INCREMENT THE PASS COUNTER, CORRECT FOR ANY OVERFLOW.
4696 020440      001002
4697 020442      005367      161616      ; THIS COUNTER IS USED IN THE ROM VERSION TEST.
4698
4699
4700 020446
4701 020446      005267      161552      ; INCREMENT THE PASS COUNTER.
4702 020452      026767      161546      161332      BNE     GETPRM          ;BRANCH IF WE HAVE NOT YET! OVERFLOWED.
4703 020460      002362
4704
4705 020462
                                DEC     PASCNT          ;SET PASS COUNT TO 177777 OCTAL.
                                ; GET THE HARDWARE PARAMETERS FOR THIS UNIT.
                                GETPRM:
4706 020472      016700      161536      INC     UNITN           ;INCREMENT LOGICAL DEVICE NUMBER
                                CMP     UNITN,L$UNIT        ;SEE IF MAXIMUM UNIT NO. EXCEEDED
                                BGE     NEWPAS            ;BR IF YES
                                GPHARD UNITN,R1          ;GET P-TABLE POINTER INTO R1
                                MOV     UNITN,R0          ;MOV UNITN,R0
                                TRAP   C$GPHRD           ;TRAP C$GPHRD
                                MOV     R0,R1            ;MOV R0,R1
4707 020472      103401
                                BCOMPLETE 30$           ;BR IF DEVICE AVAILABLE
4708 020474      000764      BR     GETPRM          ;SKIP THIS DEVICE          BCS     30$
4709
4710
4711 020476      012167      161524      30$: ;***** HARDWARE PARAMETER MOVING CODE *****
                                MOV     (R1)+,CSRA        ;STORE DHU-11 CSR ADDRESS IN DEV.REG.ADDRESS TABLE
4712 020502      012102
                                MOV     (R1)+,R2          ;GET THE RX INTERRUPT VECTOR ADDRESS.
4713 020504      010267      161504      MOV     R2,RXVECA      ;STORE RX INT VECTOR ADDRESS.
4714 020510      062702      000004      ADD     #4,R2          ;CALCULATE TX INTERRUPT VECTOR ADDRESS.
4715 020514      010267      161476      MOV     R2,TXVECA      ;STORE TX INT VECTOR ADDRESS.
4716 020520      012167      161474      MOV     (R1)+,ACTLNS    ;STORE DHU-11 ACTIVE LINE BIT MAP
4717 020524      111167      161472      MOV     (R1),LOP$CK     ;STORE DHU-11 LOOPBACK MODE
4718
4719
4720
4721
4722 020530      016701      161472      ;+
                                ; CALCULATE DEVICE REGISTER ADDRESSES,AND PUT THEM IN THE
                                ; DEVICE REGISTER ADDRESS TABLE.
                                ;-
4723 020534      005201
                                MOV     CSRA,R1          ;COPY CSR ADDRESS
4724 020536      005201
                                INC     R1              ;INCREMENT CSR ADDRESS
4725 020540      012703      000007      INC     R1              ; COPY BY 2.
4726 020544      012702      002230      MOV     #7,R3          ;SET UP REGISTER COUNT
4727 020550      010122      12$: MOV     @RBUFA,R2      ;GET LOCATION WHERE RBUF ADDRESS GOES IN TABLE
4728 020552      005201
                                MOV     R1,(R2)+        ;STORE REGISTER ADDRESS IN TABLE
4729 020554      005201
                                INC     R1              ;INCREMENT REGISTER ADDRESS
4730 020556      005303
                                INC     R1              ; BY 2,FOR THE NEXT DEVICE REGISTER.
4731 020560      001373
                                DEC     R3              ;DECREMENT REGISTER COUNT
4732
                                BNE     12$             ;LOOP IF NOT DONE
4733
4734
4735
4736 020562      012700      002412      ;+
                                ; INITIALISE THE BMP CODE QUEUE.
                                ;-
4737 020566      012701      002612      MOV     @BMPCQB,R0     ;GET THE START ADDRESS OF THE QUEUE.
                                MOV     @BMPCQE,R1     ;GET THE END ADDRESS OF THE QUEUE.

```

```

INITIALIZE SECTION
4738 020572 010067 161612
4739 020576 005020
4740 020600 020001
4741 020602 103775
4742
4743
4744
4745
4746 020604 032767 000020 161376
4747 020612 001416
4748 020614 026727 161172 000001
4749 020622 003412
4750 020624
    020624 016746 161374
    020630 012746 005231
    020634 012746 000002
    020540 010600
    020642 104417
    020644 062706 000006
4751 020650
4752
4753 020650 005067 161374
4754
4755
4756
4757 020654
    020654 012700 000340
    020660 104441
4758 020662
    020662
    020662 104411
4759
4760 000000

14$: MOV R0,BMPCQP ;SET THE POINTER TO THE START OF THE QUEUE.
     CLR (R0)+ ;CLEAR OUT THE CONTENTS OF THE QUEUE.
     CMP R0,R1 ;CHECK IF END OF QUEUE HAS BEEN REACHED.
     BLO 14$ ;LOOP IF NOT ALL DONE.
;+
; REPORT THE UNIT NUMBER IF THE SOFTWARE P-TABLE QUESTION WAS ANSWERED YES,
; AND THE MAXIMUM UNIT NUMBER IS GREATER THAN 1.
;-
     BIT #BIT4,OPTION ;CHECK IF THE QUESTION WAS ANSWERED YES.
     BEQ 16$ ;SKIP REPORTING UNIT NUMBER IF IT IS DISABLED.
     CMP L$UNIT,#1 ;CHECK MAXIMUM NUMBER OF UNITS SELECTED.
     BLE 16$ ;DO NOT REPORT UNIT NUMBER IF MAX NUMBER < 1.
     PRINTF #MFUNIT,UNITN ;REPORT UNIT NUMBER.
                                MOV UNITN,(SP)
                                MOV #MFUNIT,-(SP)
                                MOV #2,-(SP)
                                MOV SP,R0
                                TRAP C$PNTF
                                ADD #6,SP

16$:
ENDIT: CLR CTRLCF ;CLR THE CTRL-C TEST ABORT FLAG.
;+
; SET THE PROCESSOR PRIORITY TO DISABLE ALL INTERRUPTS.
;-
     SETPRI #PRI07 ;SET PROCESSOR PRIORITY TO 7.
                                MOV #PRI07,R0
                                TRAP C$SPRI

L10021: TRAP C$INIT

TNUM == 0 ;INITIALIZE THE ASSEMBLER TEST NUMBER VARIABLE.

```

4769
4770
4771
4772
4773
4774
4775
4776
4777
4778
4779
4780
4781 020664
020664
4782
4789
4790 020664
020664
020664 104461

.SBTTL AUTODROP SECTION

;++
; THIS CODE IS EXECUTED IMMEDIATELY AFTER THE INITIALIZE CODE IF
; THE "ADR" FLAG WAS SET. THE UNIT(S) UNDER TEST ARE CHECKED TO
; SEE IF THEY WILL RESPOND. THOSE THAT DON'T ARE IMMEDIATELY
; DROPPED FROM TESTING.
;--

BGNAUTO

L\$AUTO::

ENDAUTO

L10022:

TRAP C\$AUTO

4849
4850
4851
4852
4853
4854
4855
4856
4857
4858
4859
4860
4861
4862
4863
4864
4865
4866
4867
4868
4869
4870

020704
020704
020704 010046
020706 012746 020730
020712 012746 000002
020716 010600
020720 104417
020722 062706 000006
020726 000427

020730 045 101 040
020733 125 116 111
020736 124 045 104
020741 066 045 101
020744 040 104 122
020747 117 120 120
020752 105 104 040
020755 106 122 117
020760 115 040 106
020763 125 122 124
020766 110 105 122
020771 040 124 105
020774 123 124 111
020777 116 107 056
021002 045 116 000

021006
021006 000167
021010 000000

021012
021012
021012 104453

.SBTTL DROP UNIT SECTION

; THE DROP-UNIT SECTION CONTAINS THE CODING THAT CAUSES A DEVICE
; TO NO LONGER BE TESTED.
;-

BGNDU

L\$DU::

PRINTF #DROP,RO

;REPORT UNIT THAT HAS BEEN DROPPED.

MOV RO,-(SP)
MOV #DRGP,-(SP)
MOV #2,-(SP)
MOV SP,RO
TRAP C\$PRINTF
ADD #6,SP

BR EDROP

;BRANCH AROUND THE MESSAGE.

DROP: .ASCIZ/##A UNIT##D6##A DROPPED FROM FURTHER TESTING.##N/

EDROP: .EVEN

EXIT DU

.WORD JSJMP
.WORD L10024 2 .

ENDDU

L10024:

TRAP C\$DL

4879
4880
4881
4882
4883
4884
4885
4886
4887
4888
4889
4890
4891
4892
4893
4894
4895
4896
4897

021014
021014
021014 000167
021016 000000
021020
021020
021020 104452

.SBTTL ADD UNIT SECTION

; THE ADD-UNIT SECTION CONTAINS ANY CODE THE PROGRAMMER WISHES
; TO BE EXECUTED IN CONJUNCTION WITH THE ADDING OF A UNIT BACK
; TO THE TEST CYCLE.

BGNAU

L\$AU::

EXIT AU

.WORD J\$JMP
.WORD L10025-2..

.EVEN

ENDAU

L10025:

TRAP C\$AU

```

4899 .SBTTL HARDWARE TEST - ADRA -
4900 ;**
4901 ;*****
4902 ;* - REGISTER ADDRESS TEST -
4903 ;*
4904 ;* THIS TEST VERIFIES THAT THE DEVICE REGISTERS WILL RESPOND TO THE PROPER
4905 ;* UNIBUS HANDSHAKING SIGNALS WHEN ACCESSED. IF THE DHU11 DOES NOT RESPOND
4906 ;* TO THE ACCESS ATTEMPTS (IF THE DHU11 IS AT THE WRONG ADDRESS, FOR EXAMPLE)
4907 ;* THE 004 BUS TIME-OUT TRAP IS DETECTED BY THIS ROUTINE AND AN ERROR
4908 ;* IS REPORTED. THIS TEST IS PERFORMED ON LINE 0 ONLY.
4909 ;*
4910 ;*****
4911 ;
4912 ;
4913 021022 BGNST
4914 021022
4915 000001 TNUM == TNUM + 1 ;INCREMENT THE ASSEMBLY TIME TEST COUNTER.
4916 012767 000001 161224 MOV #TNUM,TSTNUM ;SET UP THE TEST NUMBER. (1)
4917 012767 177777 161212 MOV #-1,CTRLCF ;INDICATE THAT WE ARE IN A TEST.
4918 012767 000145 163006 MOV #101,ERRNBR ;SET THE TEST ERROR NUMBER IN THE TABLE.
4919 012767 005262 163002 MOV #EM0103,ERRMSG ;SET UP THE TEST FAILURE MESSAGE IN THE TABLE.
4920 012767 011430 162776 MOV #ER0101,ERRBLK ;SET-UP THE ERROR ROUTINE IN THE ERROR TABLE.
4921 ;*
4922 ; SET UP TO CATCH ANY 004 TRAPS WHICH OCCUR:
4923 ;
4924 021060 016767 156720 161210 MOV 4,TP4VEC ;SAVE THE EXISTING 004 TRAP VECTOR.
4925 021066 012767 017712 156710 MOV #TP4RTN,4 ;SET 004 TRAP VECTOR TO OUR SERVICE RTN ADR.
4926 021074 005005 CLR R5 ;CLEAR THE ERROR FLAGS.
4927 ;*
4928 ; HERE BEGINS THE LOOP TO TEST THE REGISTERS FOR A LINE.
4929 ; FIRST TEST THE CSR AND SET THE IND.ADR.REG (I.A.R) FIELD.
4930 ;
4931 021076 016700 161124 MOV CSRA,R0 ;SET UP CSR AS THE CKTRAP MOVE SOURCE.
4932 021102 012701 021274 MOV #52,R1 ;SET UP DESTINATION LOCATION FOR CKTRAP MOVE.
4933 021106 004767 173054 JSR PC,CKTRAP ;MOVE AND CHECK FOR TRAP.
4934 021112 103402 BCS 4 ;IF NO TRAP, BYPASS ERROR.
4935 021114 052705 100001 BIS #100001,R5 ;SET FATAL READ ERROR FLAGS.
4936 021120 042767 000017 000146 4: BIC #17,52 ;CLEAR THE I.A.R FIELD OF THE CSR DATA.
4937 021126 010100 MOV R1,R0 ;USE OLD DESTINATION FOR SOURCE OF CKTRAP MOVE.
4938 021130 016701 161072 MOV CSRA,R1 ;SET UP CSR AS THE CKTRAP MOVE DESTINATION.
4939 021134 004767 173026 JSR PC,CKTRAP ;MOVE AND CHECK FOR TRAP.
4940 021140 103403 BCS 6 ;IF NO TRAP, BYPASS ERROR.
4941 021142 052705 100002 BIS #100002,R5 ;SET FATAL WRITE ERROR FLAGS.
4942 021146 000434 BR 40 ;EXIT AND REPORT FATAL ERROR.
4943 ;*
4944 ; NOW, WE TEST EACH REGISTER FOR THIS LINE.
4945 ;
4946 021150 012702 000010 6: MOV #8,R2 ;INIT REGISTER COUNTER TO 8.
4947 021154 016767 161046 000110 MOV CSRA,50 ;INITIALIZE THE REGISTER POINTER.
4948 021162 016700 000104 8: MOV 50,R0 ;SET UP REGISTER AS THE SOURCE FOR CKTRAP MOVE.
4949 021166 012701 021274 MOV #52,R1 ;SET UP LOCAL STORAGE AS THE DES FOR CKTRAP.
4950 021172 004767 172770 JSR PC,CKTRAP ;PERFORM THE MOVE, CHECK FOR TRAP.
4951 021176 103402 BCS 10 ;IF NO TRAP, BYPASS THE SETTING OF ERROR FLACS.
4952 021200 052705 100001 BIS #100001,R5 ;SET FATAL READ ERROR FLAGS.
4953 021204 010100 10: MOV R1,R0 ;USE OLD DEST AS SRC FOR CKTRAP MOVE.
4954 021206 016701 000060 MOV 50,R1 ;SET UP REGISTER AS THE DEST FOR CKTRAP MOVE.

```



```

4955 021212 004767 172750          JSR    PC,CKTRAP      ;PERFORM THE MOVE, CHECK FOR TRAP.
4956 021216 103402                   BCS    12$           ;IF NO TRAP, BYPASS THE SETTING OF ERROR FLAGS.
4957 021220 052705 100002                   BIS    @100002,R5   ;SET FATAL WRITE ERROR FLAGS.
4958 021224 005267 000042          12$:   INC    50$     ;INCREMENT THE REGISTER
4959 021230 005267 000036          INC    50$     ; POINTER BY 2.
4960 021234 005302                   DEC    R2         ;COUNT THE REGISTER.
4961 021236 001351                   BNE    8$         ;LOOP TO TEST THE NEXT REGISTER ADDRESS.
4962
4963
4964
4965
4966
4967
4968 021240 016767 161032 156536 40$:   MOV    TP4VEC,4     ;RESTORE THE NORMAL 004 TRAP VECTOR.
4969 021246 005705                   TST    R5         ;CHECK THE ERROR FLAGS.
4970 021250 100012                   BPL    60$       ;EXIT ROUTINE IF NO ERRORS.
4971
4972
4973
4974 021252
    021252 104460
    ERROR
    TRAP    C$ERROR
4975
4976
4977 021254
    021254 016700 160744          DODU   UNITN      ;DROP THIS UNIT FROM FUTHER TESTING.
    021260 104451                   MOV    UNITN,R0   ;UNITN,R0
4978 021262 005067 160762          CLR    CTRLCF     ;INDICATE NO CTRL-C ABORT FROM TEST.
4979 021266
    021266 104444                   DOCLN  ;ABORT THIS SUB PASS.
    TRAP    C$DCLN
4980 021270 000402          BR     60$
4981
4982
4983 021272 000000          ;***** LOCAL STORAGE. *****
4984 021274 000000          50$:   .WORD 0      ;STORAGE FOR THE SOURCE OR DEST OF THE CKTRAP MOVE.
4985
4986          52$:   .WORD 0      ;STORAGE FOR THE SOURCE OR DEST OF THE CKTRAP MOVE.
4987 021276 005067 160746          ;***** END *****
4988 021302
    021302
    021302 104401          60$:   CLR    CTRLCF     ;INDICATE THAT WE ARE NOT WITHIN A TEST.
    TRAP    C$ETST
    L10026:
    TRAP    C$ETST
    
```

```

4990 .SBTTL  HARDWARE TEST          - DMASTA -
4991 : * *****
4992 : * - DMA START BIT TEST -
4993 : * THIS TEST VERIFIES THAT THE DMA_START BIT IN THE DUT'S LINE CONTROL
4994 : * REGISTERS WILL INITIATE DMA TRANSMISSION ON THE SELECTED LINE.
4995 : * THIS TEST IS PERFORMED IN INTERNAL LOOPBACK, ON ALL ACTIVE LINES.
4996 : *
4997 : - *****
4998 021304      BGNTST
4999 021304      SETPRI  #PRI05          ;ALLOW LTC INTERRUPTS.      T2::
      021304      012700      000240
      021310      104441
5000      000002
      TNUM == TNUM + 1          ;INCREMENT THE ASSEMBLY TIME TEST COUNTER.
5001 021312      012767      000002      160734      MOV      #TNUM,TSTNUM          ;SET UP THE TEST NUMBER.      (40)
5002 021320      012767      177777      160722      MOV      #-1,CTRLCF          ;INDICATE THAT WE ARE IN A TEST.
5003 021326      012767      000001      162514      MOV      #1,ERRTYP          ;SET ERROR TYPE AS FATAL IN ERROR TABLE.
5004 021334      012767      007641      162510      MOV      #4001,ERRNBR          ;SET THE FIRST ERROR NUMBER IN ERROR TABLE.
5005 021342      012767      005403      162504      MOV      #EM4001,ERRMSG          ;SET ERROR MESSAGE ADDRESS IN ERRTABL.
5006 021350      012767      013136      162500      MOV      #ER9101,ERRBLK          ;SELECT THE CORRECT ERROR REPORTING ROUTINE.
5007
5008 : *
5009 : RESET THE DUT TO A KNOWN STATE, REMOVE THE STATUS CODES FROM THE FIFO.
5010 : CLEAR TX AND RX INTERRUPT ENABLE BITS IN THE CSR.
5011 : THIS SUBROUTINE REPORTS ERROR >>>> 4001 <<<<<.
5012 021356      004767      172634
5013 021362      103145
      JSR      PC,CLNRST          ;RESET THE DHU-11, REPORT ANY ERRORS FOUND.
5014      BCC      501
      ;RESET FAILURE?, ABORT THIS TEST.
5015 021364      004767      173160
      JSR      PC,INDATP          ;INITIALISE THE 256 BYTE DATA PATTERN.
5016
5017 : *
5018 : SET INTERNAL LOOPBACK,ENABLE RECEIVER FUNCTIONS ON ALL ACTIVE LINES.
5019 : SET LPR ON ALL LINES TO 38.4K BAUD, 8 BITS PER CHARACTER, ODD PARITY,
5020 : 2 STOP BITS.
5021 : ENABLE TRANSMITTERS ON ALL ACTIVE LINES.
5022 021370      016705      160624
5023 021374      012700      000204
      MOV      ACTLNS,R5          ;PASS THE ACTIVE LINE BIT MAP.
5024 021400      004767      176146
      MOV      #204,R0          ;PASS THE LNCTRL CONTENTS.
      JSR      PC,WTMLNC          ;INITIALISE THE LNCTRL REGISTERS.
5025 021404      012700      177670
      MOV      #177670,R0          ;PASS THE LPR CONTENTS.
5026 021410      004767      176166
      JSR      PC,WTMLPR          ;INITIALISE THE LPR REGISTERS ON ALL LINES.
5027 021414      004767      175502
      JSR      PC,TXENBL          ;ENABLE TRANSMITTERS ON ALL LINES.
5028
5029 : *
5030 : SET-UP OUTER LOOP TO TEST THE DMA_START BIT ON ALL ACTIVE LINES.
5031 021420      016705      160574
5032 021424      005001
      MOV      ACTLNS,R5          ;GET THE ACTIVE LINE BIT MAP.
5033 021426      012767      007642      162416      21:
      CLR      R1          ;CLEAR THE LINE NUMBER COUNTER.
      MOV      #4002,ERRNBR          ;SET THE ERROR NUMBER TO 4002.
5034 021434      000241
      CLC          ;CLEAR THE CARRY BIT PRIOR TO SHIFTING BIT MAP.
5035 021436      006005
      ROR      R5          ;SHIFT THE BIT MAP INTO THE CARRY BIT.
5036 021440      103112
      BCC      141
      ;DO NOT TEST THE LINE IF IT IS INACTIVE.
5037 021442      004767      173722
      JSR      PC,PUFIFO          ;PURGE THE FIFO.
5038 021446      103113
      BCC      501
      ;GO REPORT ERROR IF FIFO WILL NOT CLEAR.
5039
5040 : *
5041 : PERFORM DMA_START BIT TESTING ON EACH LINE INDIVIDUALLY.
5042 : TEST EACH DMA_START BIT BEFORE TX'ING DATA PATTERN, REPORT ERROR IF SET.
5043 : SET DMA_START BIT ON LUT, VERIFY IT IS SET, REPORT ERROR IF CLEAR.
      ; WAIT FOR DMA TO COMPLETE.

```

```

5044
5045
5046
5047 021450 005267 162376
5048 021454 012702 002650
5049 021460 012703 000144
5050 021464 004767 172710
5051 021470 103067
5052
5053
5054
5055
5056 021472 005267 162354
5057 021476 010177 160524
5058 021502 105777 160534
5059 021506 100060
5060
5061
5062
5063 021510 005267 162336
5064 021514 010103
5065 021516 012701 170226
5066 021522 016702 160500
5067 021526 004767 175704
5068 021532 103045
5069 021534 012704 000005
5070 021540 004767 172516
5071 021544 010301
5072
5073
5074
5075
5076 021546 005267 162300
5077 021552 010177 160450
5078 021556 105777 160460
5079 021562 100432
5080
5081
5082
5083
5084
5085 021564 005003
5086 021566 012704 000200
5087 021572 012767 007647 162252 61:
5088 021600 017702 160424
5089 021604 100021
5090 021606 012700 170301
5091 021612 040200
5092 021614 001007
5093 021616 005267 162230
5094 021622 004767 174652
5095 021626 005304
5096 021630 001422
5097 021632 000757
5098 021634 005203
5099 021636 020327 000144
5100 021642 002753

; VERIFY DMA_START BIT IS CLEAR, REPORT ERROR IF SET.
; VERIFY CORRECT NUMBFR OF CHARS WERE RECEIVED, REPORT ERROR IF < EXPECTED.
;
INC ERRNBR ;SET ERROR NUMBER TO 4003.
MOV #BUFBA,R2 ;PASS THE START OF THE DATA PATTERN TO TX.
MOV #100,R3 ;PASS THE LENGTH OF THE DATA PATTERN.
JSR PC,DODMA ;TRANSMIT THE DATA PATTERN.
BCC 121 ;GO REPORT ER:OR IF DMA_START BIT SET.
;
; TEST THE STATE OF THE DMA_START BIT ON THE LINE UNDER TEST.
; REPORT ERROR IF DMA_START BIT IS CLEAR.
;
INC ERRNBR ;INCREMENT ERROR NUMBER TO 4004.
MOV R1,@CSRA ;SELECT THE LINE CURRENTLY UNDER TEST.
TSTB @TXAD2A ;TEST THE STATE OF THE DMA_START BIT.
BPL 121 ;GO REPORT ERROR IF BIT IS CLEAR.
;
; WAIT FOR DMA TRANSMISSION TO COMPLETE.
;
INC ERRNBR ;INCREMENT ERROR NUMBER TO 4005.
MOV R1,R3 ;SAVE THE LINE NUMBER.
MOV #170226,R1 ;TEST BIT 15, TIMEOUT OF 150 MILLI SECS.
MOV CSRA,R2 ;PASS THE ADDRESS OF THE REGISTER TO TEST.
JSR PC,WAIBIS ;WAIT FOR DMA TO COMPLETE.
BCC 101 ;GO REPORT ERROR IF TIMEOUT OCCURRED.
MOV #5,R4 ;PASS DELAY OF 5 MILLI SECS.
JSR PC,DELAY ;WAIT FOR CHAR TO BE RECEIVED AND PROCESSED.
MOV R3,R1 ;RESTORE THE CURRENT LINE NUMBER.
;
; TEST THE STATE OF THE DMA_START BIT ON THE LINE UNDER TEST.
; REPORT ERROR IF DMA_START BIT IS SET.
;
INC ERRNBR ;INCREMENT ERROR NUMBER TO 4006.
MOV R1,@CSRA ;SELECT THE LINE CURRENTLY UNDER TEST.
TSTB @TXAD2A ;TEST THE STATE OF THE DMA_START BIT.
BMI 121 ;GO REPORT ERROR IF BIT IS STILL SET.
;
; VERIFY THE NUMBER OF CHARS RECEIVED = NUMBER OF CHARS EXPECTED.
; REPORT ERROR IF COUNT IS INCORRECT.
; IF MORE THAN 128 BMP CODES ARE FOUND THEN REPORT ERROR AND EXIT TEST.
;
CLR R3 ;CLEAR THE READ COUNTER.
MOV #128,R4 ;SET UP MAX BMP CODE READ COUNT.
MOV #4007,ERRNBR ;SET ERROR NUMBER TO 4007.
MOV @RBUFA,R2 ;READ THE CHARACTER FROM THE FIFO.
BPL 121 ;GO REPORT ERROR IF FIFO EMPTY TOO SOON.
MOV #170301,R0 ;SET-UP BIT MASK OF A BMP CODE.
BIC R2,R0 ;TRY TO CLEAR THE BMP CODE MASK.
BNE 81 ;BRANCH IF NOT A BMP CODE.
INC ERRNBR ;INCREMENT ERROR NUMBER TO 4008.
JSR PC,SAVBMP ;SAVE THE BMP CODE ON THE QUEUE.
DEC R4 ;DECREMENT MAX BMP CODE READ COUNT.
BEQ 501 ;GO REPORT ERROR IF TOO MANY BMP CODES FOUND.
BR 61 ;DO NOT COUNT THE BMP CODE AS A VALID CHAR.
;
; COUNT THIS CHARACTER.
; HAVE WE RECIEVED 100 CHARACTERS?.
; LOOP UNTIL 100 (NON-BMP) CHARS ARE READ.
INC R3
CMP R3,#100.
BLT 61
    
```



```

5128 .SBTTL HARDWARE TEST - DMABRT -
5129 ;* *****
5130 ;* - DMA ABORT/RESTART TEST -
5131 ;* THIS TEST VERIFIES THAT EACH DMA_ABORT BIT WILL CORRECTLY HALT
5132 ;* A DMA TRANSMISSION, AND RETURN A TX_ACTION.
5133 ;* IT WILL ALSO VERIFY THAT THE ABORTED DMA TRANSMISSION CAN BE RESUMMED,
5134 ;* AND THAT A TX_ACTION IS RETURNED UPON COMPLETION.
5135 ;* THIS TEST IS PERFORMED IN INTERNAL LOOPBACK, ON ALL ACTIVE LINES.
5136 ;*
5137 ;*
5138 ;* *****
5138 021710 BGNTST
5139 021710 SETPRI @PRI05 ;ALLOW LTC INTERRUPTS. T3::
5140 021710 012700 000240
5141 021714 104441
5141 021716 012700 000003 160330 TNUM == TNUM + 1 ;INCREMENT THE ASSEMBLY TIME TEST COUNTER.
5142 021724 012767 177777 160316 MOV @TNUM,TSTNUM ;SET UP THE TEST NUMBER. (41)
5143 021732 012767 000001 162110 MOV #-1,CTRLCF ;INDICATE THAT WE ARE IN A TEST.
5144 021740 012767 010005 162104 MOV #1,ERRTYP ;SET ERROR TYPE AS FATAL IN ERROR TABLE.
5145 021746 012767 005471 162100 MOV #4101,ERRNBR ;SET THE FIRST ERROR NUMBER IN ERROR TABLE.
5146 021754 012767 013136 162074 MOV #EM4101,ERRMSG ;SET ERROR MESSAGE ADDRESS IN ERRTBL.
5147 MOV #ER9101,ERRBLK ;SELECT THE CORRECT ERROR REPORTING ROUTINE.
5148 ;*
5149 ; RESET THE DUT TO A KNOWN STATE, REMOVE THE STATUS CODES FROM THE FIFO.
5150 ; CLEAR TX AND RX INTERRUPT ENABLE BITS IN THE CSR.
5151 ; THIS SUBROUTINE REPORTS ERROR >>>> 4101 <<<<.
5152 021762 004767 172230 JSR PC,CLNRST ;RESET THE DMU-11, REPORT ANY ERRORS FOUND.
5153 021766 103164 BCC 60$ ;RESET FAILURE?, ABORT THIS TEST.
5154
5155 021770 004767 172554 JSR PC,INDATP ;INITIALISE 256 BYTE DATA PATTERN.
5156
5157 ;*
5158 ; SET INTERNAL LOOPBACK,ENABLE RECEIVER FUNCTIONS ON ALL ACTIVE LINES.
5159 ; SET LPR ON ALL LINES TO 38.4K BAUD, 8 BITS PER CHARACTER, ODD PARITY,
5160 ; 2 STOP BITS.
5161 ; ENABLE TRANSMITTERS ON ALL ACTIVE LINES.
5162 021774 016705 160220 MOV ACTLNS,R5 ;PASS THE ACTIVE LINE BIT MAP.
5163 022000 012700 000204 MOV #204,R0 ;PASS THE LNCTRL CONTENTS.
5164 022004 004767 175542 JSR PC,WTWLNLC ;INITIALISE THE LNCTRL REGISTERS.
5165 022010 012700 177670 MOV #177670,R0 ;PASS THE LPR CONTENTS.
5166 022014 004767 175562 JSR PC,WTWLPR ;INITIALSE THE LPR REGISTERS ON ALL LINES.
5167 022020 004767 175076 JSR PC,TXENBL ;ENABLE TRANSMITTERS ON ALL LINES.
5168
5169 ;*
5170 ; PERFORM DMA_ABORT BIT TESTING ON EACH INDIVIDUAL (ACTIVE) LINE.
5171 022024 016705 160170
5172 022030 005001
5173 022032 012767 010006 162012 2$: MOV #4102,ERRNBR ;SET THE ERROR NUMBER TO 4102.
5174 022040 000241 CLC ;CLEAR THE CARRY BIT PRIOR TO SHIFTING BIT MAP.
5175 022042 006005 ROR R5 ;SHIFT THE BIT MAP INTO THE CARRY BIT.
5176 022044 103127 BCC 10$ ;DO NOT TEST THE LINE IF IT IS INACTIVE.
5177 022046 004767 173316 JSR PC,PUFIFO ;PURGE THE FIFO.
5178 022052 103130 BCC 50$ ;GO REPORT ERROR IF FIFO WILL NOT CLEAR.
5179
5180 ;*
5181 ; CHECK THE DMA_ABORT BIT BEFORE ENABLING DMA, REPORT ERROR IF SET.
  
```

```

5182 022054 005267 161772      INC      ERRNBR      ;INCREMENT ERROR NUMBER TO 4103.
5183 022060 010177 160142      MOV      R1,@CSRA   ;SELECT THE LINE CURRENTLY UNDER TEST.
5184 022064 032777 000001 160144  BIT      @BIT0,@LNCTRA ;TEST THE STATE OF THE DMA_ABORT BIT.
5185 022072 001105                BNE      6$         ;GO REPORT ERROR IF BIT IS SET.
5186
5187      ;+
5188      ; ENABLE DMA TX ON SELECTED LINE, WAIT FOR DMA TO TX APPROX 1/4 OF DATA.
5189      ; ABORT THE DMA TRANSMISSION. WAIT FOR TX_ACTION TO BE RETURNED.
5190 022074 005267 161752      INC      ERRNBR      ;SET ERROR NUMBER TO 4104.
5191 022100 012702 002650      MOV      @BUFBA,R2  ;PASS THE START OF THE DATA PATTERN TO TX.
5192 022104 012703 000400      MOV      @256.,R3   ;PASS THE LENGTH OF THE DATA PATTERN.
5193 022110 004767 172264      JSR      PC,DODMA   ;TRANSMIT THE DATA PATTERN.
5194 022114 103107                BCC      50$        ;GO REPORT ERROR IF THERE ARE TX PROBLEMS.
5195
5196      ;+
5197      ; WAIT FOR DMA TO TRANSMIT 1/4 OF THE DATA BEFORE ABORTING.
5198 022116 010177 160104      MOV      R1,@CSRA   ;SELECT THE LINE CURRENTLY UNDER TEST.
5199 022122 012704 000050      MOV      @40.,R4    ;PASS THE DELAY TIME OF 40 MILLI SECONDS.
5200 022126 004767 172130      JSR      PC,DELAY   ;WAIT FOR APPROX 1/4 OF DATA TO BE TX'D.
5201 022132 052777 000001 160076  BIS      @BIT0,@LNCTRA ;ABORT THE DMA TRANSMISSION.
5202
5203      ;+
5204      ; WAIT FOR TX_ACTION TO BE RETURNED, REPORT ERROR IF TIME-OUT OCCURS.
5205 022140 005267 161706      INC      ERRNBR      ;INCREMENT ERROR NUMBER TO 4105.
5206 022144 010103                MOV      R1,R3      ;SAVE THE LINE NUMBER.
5207 022146 012701 170012                MOV      @170012,R1 ;TEST BIT 15, TIMEOUT OF 10 MILLI SECS.
5208 022152 016702 160050                MOV      CSRA,R2    ;PASS THE ADDRESS OF THE REGISTER TO TEST.
5209 022156 004767 175254                JSR      PC,WAIBIS  ;WAIT FOR DMA TO COMPLETE.
5210 022162 103050                BCC      4$         ;GO REPORT ERROR IF TIMEOUT OCCURRED.
5211 022164 010301                MOV      R3,R1     ;RESTORE THE CURRENT LINE NUMBER.
5212
5213      ;+
5214      ; VERIFY DMA_START BIT CLEAR, REPORT ERROR IF SET.
5215 022166 005267 161660      INC      ERRNBR      ;INCREMENT ERROR NUMBER TO 4106.
5216 022172 012702 005557      MOV      @EM103,R2  ;SELECT MESSAGE TO BE REPORTED.
5217
5218 022176 010177 160024      MOV      R1,@CSRA   ;"DMA_START BIT FOUND SET AFTER DMA ABORTED".
5219 022202 105777 160034      TSTB    @TXAD2A    ;SELECT THE LINE CURRENTLY UNDER TEST.
5220 022206 100441                BMI      8$         ;TEST THE STATE OF THE DMA_START BIT.
5221
5222      ;+
5223      ; RESUME DMA TRANSMISSION BY CLEARING DMA_ABORT AND SETTING DMA_START.
5224 022210 042777 000001 160020  BIC      @BIT0,@LNCTRA ;CLEAR THE DMA_ABORT BIT.
5225 022216 052777 000200 160016  BIS      @BIT7,@TXAD2A ;SET THE DMA_START BIT.
5226
5227      ;+
5228      ; WAIT FOR DMA TRANSMISSION TO COMPLETE.
5229 022224 005267 161622      INC      ERRNBR      ;INCREMENT ERROR NUMBER TO 4107.
5230 022230 010103                MOV      R1,R3      ;SAVE THE LINE NUMBER.
5231 022232 012701 170536      MOV      @170536,R1 ;TEST BIT 15, TIMEOUT OF 350 MILLI SECS.
5232 022236 016702 157764                MOV      CSRA,R2    ;PASS THE ADDRESS OF THE REGISTER TO TEST.
5233 022242 004767 175170                JSR      PC,WAIBIS  ;WAIT FOR DMA TO COMPLETE.
5234 022246 103016                BCC      4$         ;GO REPORT ERROR IF TIMEOUT OCCURRED.
5235 022250 012704 000002      MOV      @2,R4      ;PASS TIME-OUT OF 2 MILLI SECS.
5236 022254 004767 172002      JSR      PC,DELAY   ;WAIT FOR CHAR TO BE RECEIVED AND PROCESSED.
5237 022260 010301                MOV      R3,R1     ;RESTORE THE CURRENT LINE NUMBER.
5238

```

```

5239                                     ; TEST THE STATE OF THE DMA_ABORT BIT ON THE LINE UNDER TEST.
5240                                     ; REPORT ERROR IF DMA_ABORT BIT IS SET.
5241                                     ;-
5242 022262 005267 161564                INC   ERRNBR           ; INCREMENT ERROR NUMBER TO 4108.
5243 022266 010177 157734                MOV   R1, @CSRA      ; SELECT THE LINE CURRENTLY UNDER TEST.
5244 022272 032777 000001 157736        BIT   @BIT0, @LNCTRA ; TEST THE STATE OF THE DMA_ABORT BIT.
5245 022300 001002                        BNE   6$             ; GO REPORT ERROR IF BIT IS SET.
5246 022302 000410                        BR    10$           ; BRANCH TO CHECK FOR ANY MORE LINES TO TEST.
5247                                     ;+
5248                                     ; REPORT ERROR, SKIP FURTHER TESTING ON THIS LINE.
5249                                     ;-
5250 022304 010301                        4$:   MOV   R3, R1           ; RESTORE THE CURRENT LINE NUMBER.
5251                                     ;-
5252 022306 012702 005523                6$:   MOV   @EM4102, R2 ; PASS THE ERROR MESSAGE TO BE REPORTED.
5253                                     ; "DMA_ABORT BIT BAD ON LINE NN".
5254 022312 104460                        8$:   ERROR                                ; >>>> ERROR <<<<<.
5255                                     TRAP   C$ERROR
5256                                     ;+
5257                                     ; EXIT THE TEST IF EXTENDED ERROR REPORTING HAS NOT BEEN ENABLED
5258                                     ;-
5259 022314 032767 000100 157666        BIT   @BIT06, OPTION ; EXIT WITH TEST FAILURE MESSAGE IF
5260 022322 001406                        BEQ   60$             ; NO EXTENDED ERROR REPORTING HAS BEEN REQUESTED
5261                                     ; DURING THE SOFTWARE QUESTIONS.
5262                                     ;+
5263                                     ; VERIFY ALL ACTIVE LINES HAVE BEEN TESTED.
5264                                     ;-
5265 022324 005201                        10$:  INC   R1             ; INCREMENT THE LINE NUMBER COUNTER.
5266 022326 005705                        TST   R5             ; ARE THERE ANY MORE ACTIVE LINES TO TEST?.
5267 022330 001240                        BNE   2$             ; YES; BRANCH TO TEST THE NEXT LINE.
5268 022332 000402                        BR    60$           ; NO; EXIT THIS TEST.
5269                                     ;-
5270 022334 004767 174332                50$:  JSR   PC, TSABRT   ; REPORT TEST ABORTED. NON-TEST RELATED ERROR.
5271 022340 005067 157704                60$:  CLR   CTRLCF      ; INDICATE THAT WE ARE NOT WITHIN A TEST.
5272                                     ;-
5273 022344                                ENDTST
5274 022344                                L10030:
5275 022344 104401                                TRAP   C$ETST
    
```

```

5275 .SBTTL  HARDWARE TEST          - DMAERR -
5276 :+* *****
5277 :*
5278 :*          - DMA ERROR BIT TEST -
5279 :* THIS TEST VERIFIES THAT THE TX.DMA.ERROR BIT IN THE CSR IS
5280 :* FUNCTIONING CORRECTLY.  THE DMA ERROR IS FORCED BY MAKING THE DUT
5281 :* ATTEMPT TO PERFORM A DMA TRANSFER FROM THE ADDRESS OF ITS OWN CSR.
5282 :* SINCE THE DEVICE CANNOT BE BOTH A BUS MASTER AND SLAVE AT THE SAME
5283 :* TIME, TIMEOUT WILL OCCUR WAITING FOR THE APPROPRIATE HANDSHAKE SIGNAL
5284 :* FROM THE DMA ADDRESS.
5285 :* THIS TEST IS PERFORMED IN INTERNAL LOOPBACK.
5286 :*
5287 :-- *****
5288 022346      BGNTST
5289 022346      T4::
5290 022346      SETPRI  #PRI05          ;ALLOW LTC INTERRUPTS.
5291 022352      104441          MOV      #PRI05,RO
5292 000004          TRAP      C$SPRI
5293 022354      012767 000004 157672  TNUM == TNUM + 1      ;INCREMENT THE ASSEMBLY TIME TEST COUNTER.
5294 022362      012767 177777 157660  MOV      #TNUM,TSTNUM      ;SET UP THE TEST NUMBER. (42)
5295 022370      012767 000001 161452  MOV      #-1,CTRLCF      ;INDICATE THAT WE ARE IN A TEST.
5296 022376      012767 010151 161446  MOV      #1,ERRTYP      ;SET ERROR TYPE AS FATAL IN ERROR TABLE.
5297 022404      012767 005643 161442  MOV      #4201,ERRNBR    ;SET THE FIRST ERROR NUMBER IN ERROR TABLE.
5298 022412      012767 011762 161436  MOV      #EM4201,ERRMSG  ;SET ERROR MESSAGE ADDRESS IN ERRTBL.
5299          MOV      #ER0503,ERRBLK ;SELECT THE CORRECT ERROR REPORTING ROUTINE.
5300 :+
5301 : RESET THE DUT TO A KNOWN STATE, REMOVE THE STATUS CODES FROM THE rIFO.
5302 : CLEAR TX AND RX INTERRUPT ENABLE BITS IN THE CSR.
5303 : THIS SUBROUTINE REPORTS ERROR >>>> 4201 <<<<<.
5304 022420      004767 171572  JSR      PC,CLNRST      ;RESET THE DHU-11, REPORT ANY ERRORS FOUND.
5305 022424      103120          BCC      60$           ;RESET FAILURE?, ABORT THIS TEST.
5306 :+
5307 : SET INTERNAL LOOPBACK,ENABLE RECEIVER FUNCTIONS ON ALL LINES.
5308 : SET LPR ON ALL LINES TO 38.4K BAUD, 8 BITS PER CHARACTER, ODD PARITY,
5309 : 2 STOP BITS.
5310 : ENABLE TRANSMITTERS ON ALL LINES.
5311 :--
5312 022426      004767 172036  JSR      PC,FINACT      ;FIND AN ACTIVE LINE.
5313 022432      103115          BCC      60$           ;EXIT THE TEST IF NO ACTIVE LINES.
5314 022434      010104          MOV      R1,R4          ;SAVE THE LINE NUMBER.
5315 022436      012700 000204  MOV      #204,RO        ;PASS THE LNCTRL CONTENTS.
5316 022442      004767 175104  JSR      PC,WTWLNLC     ;INITIALISE THE LNCTRL REGISTERS.
5317 022446      012700 177670  MOV      #177670,RO     ;PASS THE LPR CONTENTS.
5318 022452      004767 175124  JSR      PC,WTWLPR      ;INITIALSE THE LPR REGISTERS ON THE ACTIVE LINE.
5319 022456      004767 174440  JSR      PC,TXENBL      ;ENABLE TRANSMITTERS ON THE ACTIVE LINE.
5320 :+
5321 : VERIFY THAT THE DMA.START BIT IS CLEAR BEFORE ATTEMPTING THE DMA TRANSFER.
5322 :--
5323 022462      005267 161364  INC      ERRNBR          ;SET THE ERROR NUMBER TO 4202.
5324 022466      032777 000200 157546  BIT      #BIT07,#TXAD2A ;TEST THE DMA START BIT.
5325 022474      001072          BNE      50$           ;BRANCH TO REPORT THE ERROR IF THE BIT IS SET.
5326 :+
5327 : SET UP THE DMA REGISTERS TO PERFORM THE TRANSFER FROM THE ADDRESS OF THE CSR.
5328 :

```



```

5329 022476 016777 157524 157534      MOV      CSRA,@TXAD1A      ;SET UP THE LOW 16 BITS OF THE DMA ADDR.
5330 022504 012777 000001 157532      MOV      #1,@TXBFCA      ;SET UP TO DMA ONE CHARACTER.
5331 022512 112777 000203 157522      MOV      #203,@TXAD2A    ;SET UP THE 2 MSB'S AND INITIATE THE DMA.
5332 022520 012701 170012      MOV      #170012,R1      ;TEST BIT 15, TIME OUT OF 10 MS.
5333 022524 016702 157476      MOV      CSRA,R2         ;INDICATE TO TEST THE CSR.
5334 022530 005267 161316      INC      ERRNBR          ;SET THE ERROR NUMBER TO 4203.
5335 022534 004767 174676      JSR      PC,WAIBIS       ;WAIT FOR A TX-ACTION.
5336 022540 103050      BCC      50$            ;REPORT THE ERROR IF NO TX-ACTION.
5337
5338      ;+
5339      ; VERIFY THAT THE DMA ERROR BIT IS SET AND THE DMA START BIT IS CLEAR.
5340 022542 005267 161304      INC      ERRNBR          ;SET THE ERROR NUMBER TO 4204.
5341 022546 032777 010000 157452      BIT      #BIT12,@CSRA    ;TEST THE DMA-ERROR BIT.
5342 022554 001436      BEQ      2$            ;REPORT THE ERROR IF BIT IS CLEAR.
5343 022556 005267 161270      INC      ERRNBR          ;SET THE ERROR NUMBER TO 4205.
5344 022562 032777 000200 157452      BIT      #BIT07,@TXAD2A  ;TEST THE DMA-START BIT.
5345 022570 001034      BNE      50$            ;REPORT THE ERROR IF THE BIT IS SET.
5346
5347      ;+
5348      ; VERIFY THAT THE DMA ERROR BIT CLEARS WHEN A "GOOD" DMA TRANSFER IS PERFORMED.
5349 022572 010401      MOV      R4,R1          ;SET UP THE ACTIVE LINE NUMBER.
5350 022574 012702 002650      MOV      #8UFBAS,R2     ;SET UP THE START ADDRESS OF THE DMA BUFFER.
5351 022600 012703 000001      MOV      #1,R3          ;SET UP TO DMA ONE CHARACTER.
5352 022604 005267 161242      INC      ERRNBR          ;SET THE ERROR NUMBER TO 4206.
5353 022610 004767 171564      JSR      PC,DODMA       ;START THE DMA.
5354 022614 103022      BCC      50$            ;REPORT THE ERROR IF ONE OCCURED.
5355 022616 012701 170036      MOV      #170036,R1     ;SET UP TO TEST BIT15 WITH TIMEOUT OF 30 MS.
5356 022622 016702 157400      MOV      CSRA,R2         ;INDICATE TO TEST THE CSR.
5357 022626 005267 161220      INC      ERRNBR          ;SET THE ERROR NUMBER TO 4207.
5358 022632 004767 174600      JSR      PC,WAIBIS       ;WAIT FOR A TX-ACTION.
5359 022636 103011      BCC      50$            ;REPORT THE ERROR IF NO TX ACTION OCCURED.
5360 022640 005267 161206      INC      ERRNBR          ;SET THE ERROR NUMBER TO 4208.
5361 022644 032702 010000      BIT      #BIT12,R2      ;TEST THE DMA ERROR BIT OF THE LAST CSR WORD READ.
5362 022650 001406      BEQ      60$            ;EXIT THE TEST IF THE BIT IS CLEAR.
5363
5364      ;+
5365      ; REPORT THE ERROR, DMA ERROR BIT BAD.
5366 022652 012701 005675      2$:      MOV      #EM4202,R1  ;SET THE MESSAGE
5367
5368      ERROR
5369 022660 000402      BR       60$            ;EXIT THE TEST.
5370
5371 022662 004767 174004      50$:     JSR      PC,TSABRT       ;REPORT THE NON-RELATED TEST ERROR.
5372 022666 005067 157356      60$:     CLR      CTRLCF        ;INDICATE THAT WE ARE NOT WITHIN A TEST.
5373
5374 022672      ENDTST
022672
022672 104401
L10031:
TRAP C$ETST

```

5376
 5377
 5378
 5379
 5380
 5381
 5382
 5383
 5384
 5385
 5386
 5387 022674
 022674
 5388 022674 126727 157322 000002
 5389 022702 001402
 5390 022704 000167 000556
 5391 022710
 022710 012700 000240
 022714 104441
 5392 000005
 5393 022716 012767 000005 157330
 5394 022724 012767 177777 157316
 5395 022732 012767 000001 161110
 5396 022740 012767 011445 161104
 5397 022746 012767 005717 161100
 5398 022754 012767 013136 161074
 5399
 5400
 5401
 5402
 5403
 5404 022762 004767 171230
 5405 022766 103402
 5406 022770 000167 000472
 5407
 5408
 5409
 5410 022774 004767 170442
 5411
 5412
 5413
 5414
 5415
 5416
 5417 023000 016705 157214
 5418 023004 012700 000004
 5419 023010 004767 174536
 5420 023014 012705 177777
 5421 023020 012700 177670
 5422 023024 004767 174552
 5423 023030 004767 174066
 5424
 5425
 5426
 5427 023034 012703 100000
 5428 023040 016705 157154
 5429 023044 046705 157212

```

.SBTTL  HARDWARE TEST          - DAUTOI -
;.....
;
;          - DAUTO BIT INACTIVE TEST -
;
; THIS TEST VERIFIES THAT THE DUT'S DAUTO FUNCTION BEHAVES CORRECTLY
; WHEN INACTIVE, IE DAUTO BIT CLEAR.
; THIS TEST WILL ONLY EXECUTE IF STAGGERED LOOPBACK MODE IS SELECTED.
; THE SPECIAL STAGGERED LOOPBACK CONNECTOR MUST BE FITTED.
;.....
          BGNTST
          CMPB  LOPBCK,#2          ;CHECK MODE SELECTED.          TS:
          BEQ   .+6                ;DO NOT EXIT IF STAGGERD LOPBCK MODE SELECTED.
          JMP   601                ;EXIT THIS TEST.
          SETPRI @PRI05            ;ALLOW LTC INTERRUPTS.
                                     MOV   @PRI05,R0
                                     TRAP  C@SPRI
          TNUM == TNUM + 1          ;INCREMENT THE ASSEMBLY TIME TEST COUNTER.
          MOV   @TNUM,TSTNUM        ;SET UP THE TEST NUMBER.          (49)
          MOV   @-1,CTRLCF          ;INDICATE THAT WE ARE IN A TEST.
          MOV   @1,ERRTYP           ;SET ERROR TYPE AS FATAL IN ERROR TABLE.
          MOV   @4901,ERRNBR        ;SET ERROR NUMBER TO 4901.
          MOV   @EM4901,ERRMSG      ;SET ERROR MESSAGE ADDRESS IN ERROR TABLE.
          MOV   @ER9101,ERRBLK     ;SELECT THE CORRECT ERROR REPORTING ROUTINE.
;
; RESET THE DUT TO A KNOWN STATE. REMOVE THE STATUS CODES FROM THE FIFO.
; CLEAR TX AND RX INTERRUPT ENABLE BITS IN THE CSR.
; THIS SUBROUTINE REPORTS ERROR >>>> 4901 <<<<.
;
          JSR   PC,CLRST           ;RESET THE DMU-11, REPORT ANY ERRORS FOUND.
          BCS   .+6                ;DO NOT EXIT IF RESET WAS SUCCESSFUL.
          JMP   608                ;EXIT THIS TEST.
;
; SET-UP THE ASSOCIATED TX/RX LINE NUMBER TABLES.
;
          JSR   PC,ASLNTL          ;INITIALISE THE ASSOCIATED TX/RX TABLES.
;
; SET EXTERNAL LOOPBACK, DISABLE DAUTO AND ENABLE RECEIVER ON ALL ACTIVE LINES.
; SET LPR ON ALL LINES TO 38.4K BAUD, 8 BITS PER CHARACTER, ODD PARITY,
; 2 STOP BITS.
; ENABLE TRANSMITTERS ON ALL LINES.
;
          MOV   ACTLNS,R5          ;PASS THE ACTIVE LINE BIT MAP.
          MOV   #4,R0              ;PASS THE LNCTRL CONTENTS.
          JSR   PC,WTWLNLC         ;INITIALISE THE LNCTRL REGISTERS.
          MOV   @MAPLNS,R5        ;PASS BIT MAP OF ALL LINES.
          MOV   @177670,R0        ;PASS THE LPR CONTENTS.
          JSR   PC,WTWLPR         ;INITIALISE THE LPR REGISTERS ON ALL LINES.
          JSR   PC,TXENBL         ;ENABLE TRANSMITTERS ON ALL LINES.
;
; SET UP OUTER LOOP FOR TESTING ACTIVE LINES IN BOTH LINE GROUPS.
;
          MOV   @100000,R3         ;SET-UP LOOP CONTROL FLAG.
          MOV   ACTLNS,R5          ;GET THE ACTIVE LINE BIT MAP.
          BIC   LGRP2M,R5         ;REMOVE LINES IN GROUP 2.
    
```

```

5430 023050 010567 000404 21:  MOV    R5,451      ;SAVE THE CURRENT LINE GROUP.
5431 023054 005067 000376      CLR    401          ;CLEAR THE LINE NUMBER COUNTER.
5432 023060 016701 000372 41:  MOV    401,R1      ;COPY THE LINE NUMBER.
5433 023064 000241      CLC                ;CLEAR CARRY BIT PRIOR TO SHIFTING BIT MAP.
5434 023066 006005      ROR    R5          ;SHIFT ACTIVE LINE BIT MAP INTO CARRY BIT.
5435 023070 103064      BCC    81          ;SKIP TESTING THIS LINE IF IT IS INACTIVE.
5436
5437
5438
5439
5440 023072 012767 011446 160752
5441 023100 010177 157122
5442 023104 032777 000020 157124
5443 023112 001410
5444 023114 012702 005760
5445
5446 023120
      023120 104460
      MOV    #4902,ERRNBR ;SET THE ERROR NUMBER TO 4902.
      MOV    R1,BCSRA    ;SELECT THE LINE TO BE TESTED.
      BIT    #BIT4,BLNCTRA ;TEST THE STATE OF THE OAUTO BIT.
      BEQ    61          ;SKIP ERROR REPORT IF OAUTO BIT IS CLEAR.
      MOV    #EM4902,R2  ;PASS THE ERROR MESSAGE.
      ERROR ; "OAUTO BIT BAD ON LINE NN"
      ; >>>> ERROR #4902 <<<<<.
      ; TRAP C!ERROR
5447
5448
5449
5450
5451 023122 032767 000100 157060
5452 023130 001556
5453
5454
5455 023132 000443
5456
5457
5458
5459 023134 116177 004010 157064 61:
5460 023142 112777 000023 157064
5461
5462
5463
5464 023150 005267 160676
5465 023154 012701 170012
5466 023160 016702 157042
5467 023164 004767 174246
5468 023170 103134
5469 023172 012704 000005
5470 023176 004767 171060
5471
5472
5473
5474
5475 023202 005267 160644
5476 023206 016701 000244
5477 023212 010177 157010
5478 023216 005777 157020
5479 023222 100407
5480 023224 012702 005760
5481
5482 023230
      023230 104460
      INC    ERRNBR    ;INCREMENT ERROR NUMBER TO 4903.
      MOV    #170012,R1 ;TEST BIT 15, TIMEOUT OF 10 MILLI SECS.
      MOV    CSRA,R2   ;PASS THE ADDRESS OF THE REGISTER TO TEST.
      JSR    PC,WAIBIS ;WAIT FOR TRANSMISSION TO COMPLETE.
      BCC    501       ;ABORT TEST IF TIMEOUT OCCURRED.
      MOV    #5,R4     ;PASS TIME-OUT OF 5 MILLI SECS.
      JSR    PC,DELAY  ;WAIT FOR CHAR TO BE RECEIVED AND PROCESSED.
      ;
      ; TEST THE STATE OF THE TX_ENABLE BIT ON THE LINE UNDER TEST.
      ; REPORT ERROR IF TX_ENABLE BIT IS CLEAR.
      ;
      INC    ERRNBR    ;INCREMENT ERROR NUMBER TO 4904.
      MOV    401,R1    ;GET THE NUMBER OF THE LINE TEST.
      MOV    R1,BCSRA ;SELECT THE LINE CURRENTLY UNDER TEST.
      TST    @TXAD2A  ;TEST THE STATE OF THE TX_ENABLE BIT.
      BMI    81       ;SKIP ERROR REPORT IF BIT IS SET.
      MOV    #EM4902,R2 ;PASS THE MESSAGE TO BE REPORTED.
      ERROR ; "OAUTO BIT BAD ON LINE NN".
      ; >>>> ERROR #4904 <<<<<.
      ; TRAP C!ERROR
5483
5484

```

```

5485 ; EXIT THE TEST IF EXTENDED ERROR REPORTING HAS NOT BEEN ENABLED
5486 ;
5487 023232 032767 000100 156750 BIT #BIT06,OPTION ;EXIT WITH TEST FAILURE MESSAGE IF
5488 023240 001512 BEQ 60# ;NO EXTENDED ERROR REPORTING HAS BEEN REQUESTED
5489 ;DURING THE SOFTWARE QUESTIONS.
5490
5491 023242 005267 000210 8# INC 40# ;INCREMENT THE LINE NUMBER.
5492 023246 005705 TST R5 ;CHECK IF THERE ARE ANY MORE LINES TO TEST.
5493 023250 001303 BNE 4# ;
5494
5495 ;
5496 ; DISABLE TRANSMITTERS ON THE SELECTED LINES IN THE CURRENT LINE GROUP.
5497 023252 016705 000202 MOV 45#,R5 ;RESTORE THE CURRENT LINE ACTIVE LINE GROUP.
5498 023256 004767 173544 JSR PC,TXDSBL ;DISABLE TRANSMITTERS ON THE SELECTED LINES.
5499 023262 016705 000172 MOV 45#,R5 ;GET THE CURRENT ACTIVE LINE GROUP AGAIN.
5500 023266 005067 000164 CLR 40# ;CLEAR THE LINE COUNTER.
5501 023272 012767 011451 160552 10# MOV #4905,ERRNBR ;SET ERROR NUMBER TO 4905.
5502 023300 016701 000152 MOV 40#,R1 ;COPY THE LINE NUMBER.
5503 023304 000241 CLC ;CLEAR CARRY BIT PRIOR TO SHIFTING BIT MAP.
5504 023306 006005 ROR R5 ;SHIFT ACTIVE LINE BIT MAP INTO CARRY BIT.
5505 023310 103041 BCC 12# ;SKIP TESTING THIS LINE IF IT IS INACTIVE.
5506 ;
5507 ; TRANSMIT THE XON (ASCII DC1) ON THE ASSOCIATED LINE.
5508 ;
5509 023312 116177 004010 156706 MOVB TXRLNB(R1),@CSRA ;SELECT THE ASSOCIATED TX LINE.
5510 023320 112777 000021 156706 MOVB #21,@DATA ;TRANSMIT THE XON CHARACTER TO THE LUT.
5511 ;
5512 ; WAIT FOR TRANSMISSION TO COMPLETE.
5513 ;
5514 023326 012701 170012 MOV #170012,R1 ;TEST BIT 15, TIMEOUT OF 10 MILLI SECS.
5515 023332 016702 156670 MOV CSRA,R2 ;PASS THE ADDRESS OF THE REGISTER TO TEST.
5516 023336 004767 174074 JSR PC,WAIBIS ;WAIT FOR TRANSMISSION TO COMPLETE.
5517 023342 103047 BCC 50# ;ABORT TEST IF TIMEOUT OCCURRED.
5518 023344 012704 000005 MOV #5,R4 ;PASS TIME-OUT OF 5 MILLI SECS.
5519 023350 004767 170706 JSR PC,DELAY ;WAIT FOR CHAR TO BE RECEIVED AND PROCESSED.
5520 ;
5521 ; TEST THE STATE OF THE TX_ENABLE BIT ON THE LINE UNDER TEST.
5522 ; REPORT ERROR IF TX_ENABLE BIT IS SET.
5523 ;
5524 023354 005267 160472 INC ERRNBR ;INCREMENT ERROR NUMBER TO 4906.
5525 023360 016701 000072 MOV 40#,R1 ;GET THE NUMBER OF THE LINE UNDER TEST.
5526 023364 010177 156636 MOV R1,@CSRA ;SELECT THE LINE CURRENTLY UNDER TEST.
5527 023370 005777 156646 TST @TXAD2A ;TEST THE STATE OF THE TX_ENABLE BIT.
5528 023374 100007 BPL 12# ;SKIP ERROR REPORT IF BIT IS CLEAR.
5529 023376 012702 005760 MOV #EM4902,R2 ;PASS THE MESSAGE TO BE REPORTED.
5530 ;
5531 023402 ERROR ; "OAUTO BIT BAD ON LINE NN".
5532 023402 104460 ; >>>>> ERROR #4906 <<<<<<.
5533 ; TRAP C#ERROR
5534 ;
5535 ; EXIT THE TEST IF EXTENDED ERROR REPORTING HAS NOT BEEN ENABLED
5536 023404 032767 000100 156576 BIT #BIT06,OPTION ;EXIT WITH TEST FAILURE MESSAGE IF
5537 023412 001425 BEQ 60# ;NO EXTENDED ERROR REPORTING HAS BEEN REQUESTED
5538 ;DURING THE SOFTWARE QUESTIONS.
5539
5540 023414 005267 000036 12# INC 40# ;INCREMENT THE LINE NUMBER.

```



```

5564
5565
5566
5567
5568
5569
5570
5571
5572
5573
5574
5575
5576 023474      BGNTST
      023474
5577 023474      126727 156522 000002      CMPB  LOPBCK,#2      ;CHECK MODE SELECTED.      TG::
5578 023502      001402      BEQ    .+6            ;DO NOT EXIT IF STAGGERD LOPBCK MODE SELECTED.
5579 023504      000167 000556      JMP    608           ;EXIT THIS TEST.
5580 023510      023510 012700 000240      SETPRI #PRI05        ;ALLOW LTC INTERRUPTS.
      023514      104441
5581          000006
5582 023516      012767 000006 156530      TNUM == TNUM + 1      ;INCREMENT THE ASSEMBLY TIME TEST COUNTER.
5583 023524      012767 177777 156516      MOV    #TNUM,TSTNUM   ;SET UP THE TEST NUMBER.      (50)
5584 023532      012767 000001 160310      MOV    #-1,CTRLCF     ;INDICATE THAT WE ARE IN A TEST.
5585 023540      012767 011611 160304      MOV    #1,ERRTYP      ;SET ERROR TYPE AS FATAL IN ERROR TABLE.
5586 023546      012767 006012 160300      MOV    #5001,ERRNBR   ;SET ERROR NUMBER TO 5001.
5587 023554      012767 013136 160274      MOV    #EM5001,ERRMSG ;SET ERROR MESSAGE ADDRESS IN ERROR TABLE.
5588
5589
5590
5591
5592
5593 023562      004767 170430      MOV    #ER9101,ERRBLK ;SELECT THE CORRECT ERROR REPORTING ROUTINE.
5594 023566      103402
5595 023570      000167 000472      JSR    PC,CLRST       ;RESET THE DMU-11, REPORT ANY ERRORS FOUND.
5596
5597
5598
5599 023574      004767 167642      BCS    .+6            ;DO NOT EXIT IF RESET WAS SUCCESSFUL.
5600
5601
5602
5603
5604
5605
5606 023600      016705 156414      JMP    608           ;EXIT THIS TEST.
5607 023604      012700 000024
5608 023610      004767 173736
5609 023614      012705 177777
5610 023620      012700 177670
5611 023624      004767 173752
5612 023630      004767 173266
5613
5614
5615
5616 023634      012703 100000
5617 023640      016705 156354

```

```

5618 023644 046705 156412          BIC    LGRP2M,R5      ;REMOVE LINES IN GROUP 2.
5619 023650 010567 000404          MOV    R5,45$        ;SAVE THE CURRENT LINE GROUP.
5620 023654 005067 000376          CLR    40$           ;CLEAR THE LINE NUMBER COUNTER.
5621 023660 016701 000372          MOV    40$,R1        ;COPY THE LINE NUMBER.
5622 023664 000241                   CLC                    ;CLEAR CARRY BIT PRIOR TO SHIFTING BIT MAP.
5623 023666 006005                   ROR    R5             ;SHIFT ACTIVE LINE BIT MAP INTO CARRY BIT.
5624 023670 103064                   BCC    8$            ;SKIP TESTING THIS LINE IF IT IS INACTIVE.
5625
5626
5627          ; TEST THE STATE OF THE OAUTO BIT ON THE LINE UNDER TEST.
5628          ; REPORT ERROR IF IT IS FOUND CLEAR, AND SKIP FURTHER TESTING OF THAT LINE.
5629 023672 012767 011612 160152          MOV    #5002.,ERRNBR ;SET THE ERROR NUMBER TO 5002.
5630 023700 010177 156322          MOV    R1,@CSRA      ;SELECT THE LINE TO BE TESTED.
5631 023704 032777 000020 156324          BIT    @BIT4,@LNCTRA ;TEST THE STATE OF THE OAUTO BIT.
5632 023712 001010                   BNE    6$            ;SKIP ERROR REPORT IF OAUTO BIT IS SET.
5633 023714 012702 005760          MOV    #EM4902,R2    ;PASS THE ERROR MESSAGE.
5634
5635 023720          ERROR          ; "OAUTO BIT BAD ON LINE NN"
5636 023720 104460          ; >>>> ERROR #5002 <<<<<.
5637          TRAP    C$ERROR
5638
5639          ; EXIT THE TEST IF EXTENDED ERROR REPORTING HAS NOT BEEN ENABLED
5640 023722 032767 000100 156260          BIT    @BIT06,OPTION ;EXIT WITH TEST FAILURE MESSAGE IF
5641 023730 001556                   BEQ    60$           ;NO EXTENDED ERROR REPORTING HAS BEEN REQUESTED
5642          ; DURING THE SOFTWARE QUESTIONS.
5643
5644 023732 000443          BR     8$            ;SKIP FURTHER TESTING OF THIS LINE.
5645
5646          ; TRANSMIT THE XOFF (ASCII DC3) ON THE ASSOCIATED LINE.
5647
5648 023734 116177 004010 156264          MOV    TXRLNB(R1),@CSRA ;SELECT THE ASSOCIATED TX LINE.
5649 023742 112777 000023 156264          MOV    #23,@FDATA    ;TRANSMIT THE XOFF CHARACTER TO THE LUT.
5650
5651          ; WAIT FOR TRANSMISSION TO COMPLETE.
5652
5653 023750 005267 160076          INC    ERRNBR        ;INCREMENT ERROR NUMBER TO 5003.
5654 023754 012701 170012          MOV    #170012,R1    ;TEST BIT 15. TIMEOUT OF 10 MILLI SECS.
5655 023760 016702 156242          MOV    CSRA,R2       ;PASS THE ADDRESS OF THE REGISTER TO TEST.
5656 023764 004767 173446          JSR    PC,WAIBIS     ;WAIT FOR TRANSMISSION TO COMPLETE.
5657 023770 103134                   BCC    50$           ;ABORT TEST IF TIMEOUT OCCURRED.
5658 023772 012704 000005          MOV    #5,R4         ;PASS TIME-OUT OF 5 MILLI SECS.
5659 023776 004767 170260          JSR    PC,DELAY      ;WAIT FOR CHAR TO BE RECEIVED AND PROCESSED.
5660
5661          ; TEST THE STATE OF THE TX_ENABLE BIT ON THE LINE UNDER TEST.
5662          ; REPORT ERROR IF TX_ENABLE BIT IS SET.
5663
5664 024002 005267 160044          INC    ERRNBR        ;INCREMENT ERROR NUMBER TO 5004.
5665 024006 016701 000244          MOV    40$,R1        ;GET THE NUMBER OF THE LINE TEST.
5666 024012 010177 156210          MOV    R1,@CSRA      ;SELECT THE LINE CURRENTLY UNDER TEST.
5667 024016 005777 156220          TST    @TXAD2A       ;TEST THE STATE OF THE TX_ENABLE BIT.
5668 024022 100007                   BPL    8$            ;SKIP ERROR REPORT IF BIT IS CLEAR.
5669 024024 012702 005760          MOV    #EM4902,R2    ;PASS THE MESSAGE TO BE REPORTED.
5670
5671 024030          ERROR          ; "OAUTO BIT BAD ON LINE NN".
5672 024030 104460          ; >>>> ERROR #5004 <<<<<.
          TRAP    C$ERROR
    
```

```

5673
5674
5675
5676 024032 032767 000100 156150
5677 024040 001512
5678
5679
5680 024042 005267 000210
5681 024046 005705
5682 024050 001303
5683
5684
5685
5686 024052 016705 000202
5687 024056 004767 172744
5688 024062 016705 000172
5689 024066 005067 000164
5690 024072 012767 011615 157752
5691 024100 016701 000152
5692 024104 000241
5693 024106 006005
5694 024110 103041
5695
5696
5697
5698 024112 116177 004010 156106
5699 024120 112777 000021 156106
5700
5701
5702
5703 024126 012701 170012
5704 024132 016702 156070
5705 024136 004767 173274
5706 024142 103047
5707 024144 012704 000005
5708 024150 004767 170106
5709
5710
5711
5712
5713 024154 005267 157672
5714 024160 016701 000072
5715 024164 010177 156036
5716 024170 005777 156046
5717 024174 100407
5718 024176 012702 005760
5719
5720 024202
5721 024202 104460
5722
5723
5724
5725 024204 032767 000100 155776
5726 024212 001425
5727
5728
    ;*
    ; EXIT THE TEST IF EXTENDED ERROR REPORTING HAS NOT BEEN ENABLED
    ;*
    ; BIT #BIT06.OPTION ;EXIT WITH TEST FAILURE MESSAGE IF
    ; BEQ 60# ;NO EXTENDED ERROR REPORTING HAS BEEN REQUESTED
    ; ;DURING THE SOFTWARE QUESTIONS.
    ;*
    ; 8# INC 40# ;INCREMENT THE LINE NUMBER.
    ; TST R5 ;CHECK IF THERE ARE ANY MORE LINES TO TEST.
    ; RNE 4#
    ;*
    ; DISABLE TRANSMITTERS ON THE SELECTED LINES IN THE CURRENT LINE GROUP.
    ;*
    ; MOV 45#,R5 ;RESTORE THE CURRENT LINE ACTIVE LINE GROUP.
    ; JSR PC,TXDSBL ;DISABLE TRANSMITTERS ON THE SELECTED LINES.
    ; MOV 45#,R5 ;GET THE CURRENT LINE ACTIVE LINE GROUP AGAIN.
    ; CLR 40# ;CLEAR THE LINE COUNTER.
    ; 10# MOV #5005.,ERRNBR ;SET ERROR NUMBER TO 5005.
    ; MOV 40#,R1 ;COPY THE LINE NUMBER.
    ; CLC ;CLEAR CARRY BIT PRIOR TO SHIFTING BIT MAP.
    ; ROR R5 ;SHIFT ACTIVE LINE BIT MAP INTO CARRY BIT.
    ; BCC 12# ;SKIP TESTING THIS LINE IF IT IS INACTIVE.
    ;*
    ; TRANSMIT THE XON (ASCII DC1) ON THE ASSOCIATED LINE.
    ;*
    ; MOVB TXRLNB(R1),@CSRA ;SELECT THE ASSOCIATED TX LINE.
    ; MOVB #21,@FDATA ;TRANSMIT THE XON CHARACTER TO THE LUT.
    ;*
    ; WAIT FOR TRANSMISSION TO COMPLETE.
    ;*
    ; MOV #170012,R1 ;TEST BIT 15, TIMEOUT OF 10 MILLI SECS.
    ; MOV CSRA,R2 ;PASS THE ADDRESS OF THE REGISTER TO TEST.
    ; JSR PC,WAIBIS ;WAIT FOR DMA TO COMPLETE.
    ; BCC 50# ;ABORT TEST IF TIMEOUT OCCURRED.
    ; MOV #5,R4 ;PASS TIME-OUT OF 5 MILLI SECS.
    ; JSR PC,DELAY ;WAIT FOR CHAR TO BE RECEIVED AND PROCESSED.
    ;*
    ; TEST THE STATE OF THE TX_ENABLE BIT ON THE LINE UNDER TEST.
    ; REPORT ERROR IF TX_ENABLE BIT IS CLEAR.
    ;*
    ; INC ERRNBR ;INCREMENT ERROR NUMBER TO 5006.
    ; MOV 40#,R1 ;GET THE NUMBER OF THE LINE UNDER TEST.
    ; MOV R1,@CSRA ;SELECT THE LINE CURRENTLY UNDER TEST.
    ; TST @TXAD2A ;TEST THE STATE OF THE TX_ENABLE BIT.
    ; BHI 12# ;SKIP ERROR REPORT IF BIT IS SET.
    ; MOV #EM4902,R2 ;PASS THE MESSAGE TO BE REPORTED.
    ; ERROR ; "OAUTO BIT BAD ON LINE NN".
    ; ;>>>> ERROR #5006 <<<<<.
    ; ; TRAP C$ERROR
    ;*
    ; EXIT THE TEST IF EXTENDED ERROR REPORTING HAS NOT BEEN ENABLED
    ;*
    ; BIT #BIT06.OPTION ;EXIT WITH TEST FAILURE MESSAGE IF
    ; BEQ 60# ;NO EXTENDED ERROR REPORTING HAS BEEN REQUESTED
    ; ;DURING THE SOFTWARE QUESTIONS.
    ;*
    
```



```

5729 024214 005267 000036      12$:      INC      40$      ;INCREMENT THE LINE NUMBER,
5730 024220 005705              TST      R5          ;CHECK IF THERE ARE ANY MORE LINES TO TEST.
5731 024222 001323              BNE      10$          ;
5732
5733
5734      ; CHECK LOOP CONTROL FLAG TO DETERMINE IF BOTH SETS OF LINES HAVE BEEN TESTED
5735      ; IF THIS IS THE FIST TIME AROUND, RE-ENABLE TX ON ALL LINES, GENERATE ACTIVE
5736      ; BIT MAP FOR SECOND LINE GROUP.
5737 024224 005703              TST      R3          ;HAVE BOTH LINE GROUPS BEEN TESTED?.
5738 024226 001417              BEQ      60$          ;YES; THEN EXIT THIS TEST.
5739 024230 005003              CLR      R3          ;NO; CLEAR THE LOOP CONTROL FLAG,
5740 024232 012705 177777      MOV      @MAPLNS,R5 ;PASS THE BIT MAP OF ALL AVAILABLE LINE.
5741 024236 004767 172660      JSR      PC, TXENBL ;RE-ENABLE TRANSMISSION ON ALL LINES.
5742 024242 016705 155752      MOV      ACTLNS,R5 ;GET THE ACTIVE LINE BIT MAP.
5743 024246 046705 156006      BIC      LGRP1M,R5 ;REMOVE ALL ACTIVE LINES IN GROUP 1.
5744 024252 000167 177372      JMP      2$          ;ONCE MORE AROUND AND WE ARE DONE.
5745
5746 024256 000000      40$:      .WORD      0      ;STORAGE FOR CURRENT LINE NUMBER.
5747 024260 000000      45$:      .WORD      0      ;STORAGE FOR CURRENT ACTIVE LINE BIT MAP.
5748 024262 004767 172404      50$:      JSR      PC, TSABRT ;REPORT TEST ABORTED, NON-TEST RELATED ERROR.
5749 024266 005067 155756      60$:      CLR      CTRLCF    ;INDICATE THAT WE ARE NOT WITHIN A TEST.
5750
5751 024272              ENDTST
      024272
      024272 104401
                                L10033:
                                TRAP      C$ETST
    
```

5753
 5754
 5755
 5756
 5757
 5758
 5759
 5760
 5761
 5762
 5763
 5764
 5765
 5766
 5767
 5768
 5769
 5770
 5771 024274
 024274
 5772 024274
 024274 012700 000240
 024300 104441
 5773 000007
 5774 024302 012767 000007 155744
 5775 024310 012767 177777 155732
 5776 024316 012767 000001 157524
 5777 024324 012767 011755 157520
 5778 024332 012767 006051 157514
 5779 024340 012767 013136 157510
 5780
 5781
 5782
 5783
 5784
 5785 024346 004767 167644
 5786 024352 103156
 5787
 5788
 5789
 5790
 5791
 5792
 5793 024354 004767 170220
 5794
 5795
 5796
 5797
 5798 024360 016705 155634
 5799 024364 012700 000204
 5800 024370 004767 173156
 5801 024374 012700 177670
 5802 024400 004767 173176
 5803 024404 012704 000012
 5804 024410 004767 167646
 5805
 5806

```

.SBTTL  HARDWARE TEST          - IAUTOI -
;*****
;                                     - IAUTO BIT INACTIVE TEST
;
; THIS TEST VERIFIES THAT THE DUT'S IAUTO FUNCTION BEHAVES CORRECTLY
; WHEN INACTIVE, IE. IAUTO BIT CLEAR.
; ALL ACTIVE LINES ARE TESTED INDIVIDUALLY BY FILLING THE FIFO
; THEN READING THE RECEIVED DATA CHECKING FOR THE PRESENCE OF
; XOFF(ASCII DC3) OR XON (ASCII DC1) CHARACTERS.
; IF ANY ARE FOUND THEN APPROPRIATE ERRORS ARE REPORTED.
; ANY BMP CODES THAT ARE FOUND WILL BE PLACED ON THE BMP CODE QUEUE.
; TO BE REPORTED LATER.
; THE CHARACTERS ARE TRANSMITTED ON ALL ACTIVE LINES, IN INTERNAL
; LOOPBACK MODE.
;*****
BGNTST
                                T7:
SETPRI  #PRIOS                    ;ALLOW LTC INTERRUPTS.
                                MOV     #PRIOS,RC
                                TRAP   C$PRI
TNUM == TNUM + 1                ;INCREMENT THE ASSEMBLY TIME TEST COUNTER.
MOV     #TNUM,TSTNUM            ;SET UP THE TEST NUMBER. (51)
MOV     #-1,CTRLCF              ;INDICATE THAT WE ARE IN A TEST.
MOV     #1,ERRTYP               ;SET ERROR TYPE AS FATAL IN ERROR TABLE.
MOV     #5101,ERRNBR            ;SET ERROR NUMBER TO 5101.
MOV     #EMS101,ERRMSG          ;SET ERROR MESSAGE ADDRESS IN ERROR TABLE.
MOV     #ER9101,ERRBLK         ;SELECT THE CORRECT ERROR REPORTING ROUTINE.
;
; RESET THE DUT TO A KNOWN STATE, REMOVE THE STATUS CODES FROM THE FIFO.
; CLEAR TX AND RX INTERRUPT ENABLE BITS IN THE CSR.
; THIS SUBROUTINE REPORTS ERROR >>>> 5101 <<<<.
;
JSR     PC,CLRST                ;RESET THE DMU-11, REPORT ANY ERRORS FOUND.
BCC     601                      ;EXIT TEST IF FATAL ERROR FOUND.
;
; INITIALIZE THE 256 BYTE DATA PATTERN.
; ENSURE THE DATA PATTERN IS FREE FROM XON'S OR XOFF'S TO PREVENT ERRORS.
; NOTE: THE FIRST TWO CHARACTERS AND THE LAST TWO CHARACTERS WILL BE THE SAME.
;
JSR     PC,INDTPX               ;INITIALISE DATA PATTERN.
;
; SET INTERNAL LOOPBACK, DISABLE IAUTO, ENABLE RECEIVER ON THE SELECTED LINE.
; SET LPR TO 38.4K BAUD, 8 BITS PER CHARACTER, ODD PARITY, 2 STOP BITS.
;
MOV     ACTLNS,R5                ;PASS THE ACTIVE LINE BIT MAP.
MOV     #204,R0                  ;PASS INT'L LOPBCK, ENABLE RX, DISABLE IAUTO.
JSR     PC,WTWLNCR              ;INITIALISE THE LINE CONTROL REGISTER.
MOV     #177670,R0              ;PASS THE LPR CONTENTS.
JSR     PC,WTWLPR               ;SET THE LPR CONTENTS TO 38.4K BAUD.
MOV     #10,R4                  ;PASS DELAY TIME OF 10 MILLI SECONDS.
JSR     PC,DELAY                 ;WAIT FOR LNCTRL AND LPR REGS TO BE UPDATED.
;

```

```

5807 ; SET UP LOOP FOR ALL ACTIVE LINES.
5808 ; TEST THE STATE OF THE IAUTO BIT PRIOR TO TRANSMITTING THE DATA PATTERN.
5809 ; IF THE BIT IS SET, THEN REPORT THE ERROR AND SKIP TRANSMITTING
5810 ; THE DATA PATTERN ON THE SELECTED LINE.
5811 ; TRANSMIT A 256 CHARACTER DATA PATTERN USING DMA, ON A SINGLE CHANNEL
5812 ; EMPTY THE FIFO, AND VERIFY NO XOFF OR XON CHARS WERE FOUND.
5813 ;-
5814 024414 005001          CLR    R1          ;CLEAR THE LINE NUMBER COUNTER.
5815 024416 005067 000264  CLR    55$        ;CLEAR STORAGE FOR LINE NUMBER.
5816 024422 012767 011756 157422 2$:  MOV    #5102.,ERRNBR ;SET THE ERROR NUMBER TO 5102.
5817 024430 004767 170734          JSR    PC,PUFIFO   ;PURGE THE FIFO.
5818 024434 103121          BCC    50$        ;GO REPORT ERROR IF FIFO DID NOT PURGE.
5819 024436 000241          CLC          ;CLEAR CARRY PRIOR TO ROTATING BIT MAP.
5820 024440 006005          ROR    R5          ;ROTATE THE BIT MAP INTO THE CARRY BIT.
5821 024442 103107          BCC    12$        ;BRANCH IF LINE IS INACTIVE.
5822
5823 ;+
5824 ; TEST THE IAUTO BIT ON THE SELECTED ACTIVE LINE.
5825 ; REPORT ERROR IF IT IS SET.
5826 ; DO NOT TRANSMIT THE DATA PATTERN ON THE SELECTED LINE.
5827 ;-
5827 024444 005267 157402          INC    ERRNBR      ;SET ERROR NUMBER TO 5103.
5828 024450 010177 155552          MOV    R1,BCSRA   ;SELECT LINE TO TEST.
5829 024454 032777 000002 155554  BIT    #BIT1,BLNCTRA ;TEST THE STATE OF THE IAUTO BIT ON THIS LINE.
5830 024462 001410          BEQ    4$         ;SKIP ERROR IF IAUTO BIT CLEAR
5831 024464 012702 006106          MOV    #EM5102,R2 ;PASS THE CORRECT ERROR MESSAGE.
5832 024470          ERROR          ;
5833                                >>>> ERROR <<<<<.
5834                                TRAP    C$ERROR
5835
5836 ;+
5837 ; EXIT THE TEST IF EXTENDED ERROR REPORTING HAS NOT BEEN ENABLED
5838 ;-
5837 024472 032767 000100 155510  BIT    #BIT06,OPTION ;EXIT WITH TEST FAILURE MESSAGE IF
5838 024500 001503          BEQ    60$        ;NO EXTENDED ERROR REPORTING HAS BEEN REQUESTED
5839                                ;DURING THE SOFTWARE QUESTIONS.
5840
5841 024502 000467          BR     12$        ;SKIP TRANSMITTING DATA PATTERN.
5842
5843 ;+
5844 ; TRANSMIT DATA PATTERN OF 256 CHARS.
5845 ;-
5846 024504 005267 157342          INC    ERRNBR      ;SET ERROR NUMBER TO 5104.
5847 024510 012702 002650 4$:  MOV    #BUFBAS,R2 ;PASS THE START OF THE DATA PATTERN TO TX.
5848 024514 012703 000400          MOV    #256.,R3   ;PASS THE LENGTH OF THE DATA PATTERN.
5849 024520 004767 167654          JSR    PC,DODMA   ;TRANSMIT THE DATA PATTERN.
5850 024524 103065          BCC    50$        ;ABORT THE TEST IF ERROR FOUND DURING DMA TX.
5851
5852 ;+
5853 ; WAIT FOR DMA TO COMPLETE, THEN WAIT FOR THE LAST CHARACTER PLUS XOFF
5854 ; TO ARRIVE IN THE FIFO.
5855 ;-
5856 024526 005267 157320          INC    ERRNBR      ;SET ERROR NUMBER TO 5105.
5857 024532 012701 170536          MOV    #170536,R1 ;PASS TIME-OUT VALUE OF 350 MILLI SECS.
5858 024536 016702 155464          MOV    CSRA,R2    ;PASS THE ADDRESS OF THE CSR.
5859 024542 004767 172670          JSR    PC,WAIBIS  ;WAIT FOR DMA TO COMPLETE, TX_ACTION SET.
5860 024546 103054          BCC    50$        ;IF NO TX_ACTION WAS RECEIVED, ABORT THE TEST.
5861 024550 012704 000012          MOV    #10.,R4    ;PASS DELAY OF 10 MILLI SECS.
5862 024554 004767 167502          JSR    PC,DELAY   ;WAIT FOR LAST CHAR TO ARRIVE IN THE FIFO.

```



```

5917 .SBTTL  HARDWARE TEST          - IAUTOA -
5918 ;*****
5919 ;*
5920 ;*
5921 ;*
5922 ;*
5923 ;*
5924 ;*
5925 ;*
5926 ;*
5927 ;*
5928 ;*
5929 ;*
5930 ;*
5931 ;*
5932 ;*
5933 ;*
5934 ;*
5935 ;*
5936 ;*
5937 ;*
5938 ;*
5939 ;*
5940 ;*
5941 ;*
5942 ;*
5943 ;*
5944 ;*
5945 ;*
5946 ;*
5947 ;*
5948 ;*
5949 ;*
5950 ;*
5951 ;*
5952 ;*
5953 ;*
5954 ;*
5955 ;*
5956 ;*
5957 ;*
5958 ;*
5959 ;*
5960 ;*
5961 ;*
5962 ;*
5963 ;*
5964 ;*
5965 ;*
5966 ;*
5967 ;*
5968 ;*
5969 ;*
5970 ;*

```

024716				BGNTST	
024716				SETPRI	#PRI05 ;ALLOW LTC INTERRUPTS. T8::
024716	012700	000240			
024722	104441				MOV #PRI05,RO
	000010			TNUM == TNUM + 1	;INCREMENT THE ASSEMBLY TIME TEST COUNTER.
024724	012767	000010	155322	MOV #TNUM,TSTNUM	;SET UP THE TEST NUMBER. (52)
024732	012767	177777	155310	MOV #-1,CTRLCF	;INDICATE THAT WE ARE IN A TEST.
024740	012767	000001	157102	MOV #1,ERRTYP	;SET ERROR TYPE AS FATAL IN ERROR TABLE.
024746	012767	012121	157076	MOV #5201,ERRNBR	;SET ERROR NUMBER TO 5201.
024754	012767	006174	157072	MOV #EM5201,ERRMSG	;SET ERROR MESSAGE ADDRESS IN ERROR TABLE.
024762	012767	013136	157066	MOV #ER9101,ERRBLK	;SELECT THE CORRECT ERROR REPORTING ROUTINE.
					;* RESET THE DUT TO A KNOWN STATE, REMOVE THE STATUS CODES FROM THE FIFO.
					; CLEAR TX AND RX INTERRUPT ENABLE BITS IN THE CSR.
					; THIS SUBROUTINE REPORTS ERROR >>>> 5201 <<<<.
024770	004767	167222		JSR PC,CLNRST	;RESET THE DMU-11, REPORT ANY ERRORS FOUND.
024774	103402			BCS .+6	
024776	000167	000400		JMP 60\$;EXIT TEST IF FATAL ERROR FOUND.
					;* INITIALIZE THE 256 BYTE DATA PATTERN.
					; ENSURE THE DATA PATTERN IS FREE FROM XON'S OR XOFF'S TO PREVENT ERRORS.
					; NOTE: THE FIRST TWO CHARACTERS AND THE LAST TWO CHARACTERS WILL BE THE SAME.
025002	004767	167572		JSR PC,INDTPX	;INITIALISE DATA PATTERN.
					;* SET INTERNAL LOOPBACK, ENABLE IAUTO AND RECEIVER ON THE SELECTED LINE.
					; SET LPR TO 38.4K BAUD, 8 BITS PER CHARACTER, ODD PARITY, 2 STOP BITS.
025006	016705	155206		MOV ACTLNS,R5	;PASS THE ACTIVE LINE BIT MAP.
025012	012700	000206		MOV #206,R0	;PASS INTERNAL LOPBCK, ENABLE RX AND IAUTO.
025016	004767	172530		JSR PC,WTWLNCR	;INITIALISE THE LINE CONTROL REGISTER.
025022	012700	177670		MOV #177670,R0	;PASS THE LPR CONTENTS.
025026	004767	172550		JSR PC,WTWLPR	;SET THE LPR CONTENTS TO 38.4K BAUD.
025032	012704	000012		MOV #10,R4	;PASS DELAY TIME OF 10 MILLI SECONDS.
025036	004767	167220		JSR PC,DELAY	;WAIT FOR LNCTRL AND LPR REGS TO BE UPDATED.
					;* SET UP LOOP FOR ALL ACTIVE LINES.

```

5971 ; TEST THE STATE OF THE OAUTO BIT PRIOR TO TRANSMITTING THE DATA PATTERN.
5972 ; IF THE BIT IS CLEAR, THEN REPORT THE ERROR AND SKIP TRANSMITTING
5973 ; THE DATA PATTERN ON THE SELECTED LINE.
5974 ; TRANSMIT A 224 CHARACTER DATA PATTERN USING DMA, ON A SINGLE CHANNEL
5975 ; EMPTY THE FIFO, AND COUNT THE XOFF AND AN XON CHARS FOUND.
5976 ;
5977 025042 005001          CLR R1          ;CLEAR THE LINE NUMBER COUNTER.
5978 025044 005067 000330 CLR 55$         ;CLEAR STORAGE FOR LINE NUMBER.
5979 025050 012767 012122 156774 2$: MOV #5202,ERRNBR ;SET THE ERROR NUMBER TO 5202.
5980 025056 004767 170306 JSR PC,PUFIFO   ;PURGE THE FIFO.
5981 025062 103143          BCC 50$         ;GO REPORT ERROR IF FIFO DID NOT PURGE.
5982 025064 000241          CLC          ;CLEAR CARRY PRIOR TO ROTATING BIT MAP.
5983 025066 006005          ROR R5         ;ROTATE THE BIT MAP INTO THE CARRY BIT.
5984 025070 103131          BCC 16$         ;BRANCH IF LINE IS INACTIVE.
5985 ;
5986 ;+
5987 ; TEST THE IAUTO BIT ON THE SELECTED ACTIVE LINE.
5988 ; REPORT ERROR IF IT IS CLEAR.
5989 ; DO NOT TRANSMIT THE DATA PATTERN ON THE SELECTED LINE.
5990 025072 005267 156754          INC ERRNBR       ;SET ERROR NUMBER TO 5203.
5991 025076 010177 155124          MOV R1,CSRA     ;SELECT LINE TO TEST.
5992 025102 032777 000002 155126 BIT #BIT1,SLNCTRA ;TEST THE STATE OF THE IAUTO BIT ON THIS LINE.
5993 025110 001010          BNE 4$         ;SKIP ERROR IF IAUTO BIT SET.
5994 025112 012702 006227          MOV #EM5202,R2  ;PASS THE CORRECT ERROR MESSAGE.
5995 ;
5996 025116          ERROR          ; "IAUTO BIT FOUND CLEAR ON LINE NN"
5997 025116 104460          ; >>>> ERROR <<<<<.
5998 ;
5999 ;+
6000 ; EXIT THE TEST IF EXTENDED ERROR REPORTING HAS NOT BEEN ENABLED
6001 025120 032767 000100 155062 BIT #BIT06,OPTION ;EXIT WITH TEST FAILURE MESSAGE IF
6002 025126 001525          BEQ 60$         ;NO EXTENDED ERROR REPORTING HAS BEEN REQUESTED
6003 ;
6004 ;
6005 025130 000511          BR 16$         ;SKIP TRANSMITTING DATA PATTERN.
6006 ;
6007 ;+
6008 ; TRANSMIT DATA PATTERN TO FILL THE FIFO, 223 CHARS + 32 XOFF'S + XON.
6009 ;
6010 025132 005267 156714          INC ERRNBR       ;SET ERROR NUMBER TO 5204.
6011 025136 012702 002650          MOV #BUFBA5,R2  ;PASS THE START OF THE DATA PATTERN TO TX.
6012 025142 012703 000337          MOV #223,R3     ;PASS THE LENGTH OF THE DATA PATTERN.
6013 025146 004767 167226          JSR PC,DODMA   ;TRANSMIT THE DATA PATTERN.
6014 025152 103107          BCC 50$         ;ABORT THE TEST IF ERROR FOUND DURING DMA TX.
6015 ;
6016 ;+
6017 ; WAIT FOR DMA TO COMPLETE, THEN WAIT FOR THE LAST CHARACTER PLUS XOFF
6018 ; TO ARRIVE IN THE FIFO.
6019 ;
6020 025154 005267 156672          INC ERRNBR       ;SET ERROR NUMBER TO 5205.
6021 025160 012701 170454          MOV #170454,R1  ;PASS TIME-OUT VALUE OF 300 MILLI SECS.
6022 025164 016702 155036          MOV CSRA,R2    ;PASS THE ADDRESS OF THE CSR.
6023 025170 004767 172242          JSR PC,WAIBIS ;WAIT FOR DMA TO COMPLETE, TX_ACTION SET.
6024 025174 103076          BCC 50$         ;IF NO TX_ACTION WAS RECEIVED, ABORT THE TEST.
6025 025176 012704 000012          MOV #10,R4     ;PASS DELAY OF 10 MILLI SECS.
6026 025202 004767 167054          JSR PC,DELAY   ;WAIT FOR LAST CHAR TO ARRIVE IN THE FIFO.
    
```

```

6027
6028
6029
6030
6031 025206 005003
6032 025210 005004
6033 025212 005267 156634
6034 025216 012701 000400
6035 025222 017702 155002
6036 025226 100061
6037
6038
6039
6040 025230 012700 170301
6041 025234 040200
6042 025236 001002
6043 025240 004767 171234
6044
6045
6046
6047 025244 120227 000023
6048 025250 001001
6049 025252 005203
6050 025254 120227 000021
6051 025260 001001
6052 025262 005204
6053 025264 005301
6054 025266 001412
6055
6056
6057
6058
6059 025270 020127 000176
6060 025274 001352
6061 025276 010400
6062
6063 025300 012704 000001
6064 025304 004767 166752
6065 025310 010004
6066 025312 000743
6067
6068
6069
6070
6071 025314 005703
6072 025316 001403
6073 025320 020427 000001
6074 025324 001413
6075 025326 005267 156520
6076 025332 016701 000042
6077 025336 012702 006144
6078
6079 025342
        025342 104460
6080
6081
6082

; READ 256 CHARS FROM THE FIFO. COUNT ANY XOFF OR XON CHARS FOUND.
;
; CLEAR XOFF COUNTER.
; CLEAR XON COUNTER.
; INCREMENT ERROR NUMBER TO 5206.
; INITIALISE THE READ COUNTER.
; READ CHAR FROM THE FIFO.
; GO REPORT ERROR IF FIFO EMPTY.
;
; CHECK FOR BMP CODE IN THE FIFO. SAVE ANY FOUND ON THE QUEUE.
;
; SET UP BMP BIT MASK.
; TRY TO CLEAR ALL THE BMP BITS.
; SKIP BMP SAV IF NOT A BMP CODE.
; SAVE THE BMP CODE ON THE QUEUE.
;
; CHECK FOR XOFF AND XON CHARACTERS.
;
; IS IT AN XOFF CHARACTER?
; NO, BRANCH TO SEE IF IT IS AN XON.
; COUNT THE XOFF CHAR.
; IS IT AN XON CHARACTER?
; NO, SKIP THE NEXT INSTRUCTION.
; COUNT THE XON.
; DECREMENT THE READ COUNT.
; BRANCH IF ALL CHARACTERS READ.
;
; CHECK IF THE FIFO HAS BEEN EMPTIED BELOW THE HALF LEVEL. IF IT
; HAS DELAY FOR 1MS TO ALLOW THE XON TO BE GENERATED.
;
; IS THE FIFO LEVEL = 126 ?
; LOOP TO READ THE NEXT CHARACTER IF NOT.
; SAVE THE XON COUNT, ALTHOUGH THERE SHOULDNT
; BE ANY.
; SET THE DELAY TO 1MS.
; PERFORM THE DELAY.
; RESTORE THE XON COUNT.
; LOOP TO READ THE NEXT CHAR.
;
; VERIFY THAT AT LEAST 1 XOFF AND 1 XON WAS FOUND IN THE FIFO.
; REPORT ERROR IF NONE WERE FOUND.
;
; CHECK XOFF COUNT.
; GO REPORT ERROR IF NONE FOUND.
; CHECK XON COUNT = 1.
; SKIP THE ERROR REPORT IF ONE XON WAS FOUND.
; SET ERROR NUMBER TO 5207.
; PASS THE LINE NUMBER TO BE REPORTED.
; PASS THE ERROR MESSAGE TO BE REPORTED.
; "IAUTO BIT BAD ON LINE NN".
;
; >>>> ERROR <<<<<.
; TRAP C$ERROR

; EXIT THE TEST IF EXTENDED ERROR REPORTING HAS NOT BEEN ENABLED
    
```

```
6083
6084 025344 032767 000100 154636      BIT      #BITOC,OPTION ;EXIT WITH TEST FAILURE MESSAGE IF
6085 025352 001413                      BEQ      608      ;NO EXTENDED ERROR REPORTING HAS BEEN REQUESTED
6086                                     ;DURING THE SOFTWARE QUESTIONS.
6087
6088                                     ;
6089                                     ; CHECK IF ALL ACTIVE LINES HAVE BEEN TESTED.
6090 025354 005267 000020      168:      INC      558      ;INCREMENT LINE NUMBER.
6091 025360 016701 000014      MOV      558,R1    ;GET NUMBER OF THE NEXT LINE TO TEST.
6092 025364 005705                      TST      R5        ;ARE THERE ANY MORE ACTIVE LINES TO TEST?.
6093 025366 001230                      BNE     28        ;LOOP TO CHECK NEXT LINE.
6094 025370 000404                      BR      608      ;EXIT TEST.
6095
6096 025372 004767 171274      508:      JSR     PC,TSABRT ;REPORT TEST ABORTED. NON-TEST RELATED ERROR.
6097 025376 000401                      BR      608      ;EXIT THIS TEST.
6098 025400 000000      558:      .WORD  0        ;STORAGE FOR LINE NUMBER.
6099 025402 005067 154642      608:      CLR     CTRLCF    ;INDICATE THAT WE ARE NOT WITHIN A TEST.
6100
6101 025406                      ENDTST
      025406
      025406 104401
```

L10035: TRAP C0ETST


```

6103 .SBTTL  HARDWARE TEST          FIFDAT -
6104 :.....
6105 : - FIFO VALID DATA TEST -
6106 :
6107 :
6108 : THIS TEST VERIFIES THAT THE DUT IS CAPABLE OF HOLDING 256 VALID
6109 : CHARACTERS IN ITS FIFO.
6110 : THE CHARACTERS ARE TRANSMITTED ON THE FIRST AVAILABLE ACTIVE LINE, IN
6111 : INTERNAL LOOPBACK MODE.
6112 : THE DATA FOUND IN THE FIFO IS COMPARED WITH THE EXPECTED DATA, AND ANY
6113 : DISCREPANCIES ARE REPORTED.
6114 : ANY BMP CODE FOUND WILL INVALIDATE THE TEST AND CAUSE IT TO BE ABORTED.
6115 : HOWEVER THE BMP CODE WILL BE PLACED ON THE BMP CODE QUEUE, TO BE
6116 : REPORTED LATER.
6117 :
6118 :.....
6119 025410          BGNTST
        025410
6120 025410          SETPRI  #PRIOS          ;ALLOW LTC INTERRUPTS.      T9:
        025410 012700 000240
        025414 104441
6121          000011
6122 025416 012767 000011 154630          TNUM == TNUM + 1          ;INCREMENT THE ASSEMBLY TIME TEST COUNTER.
6123 025424 012767 177777 154616          MOV  #TNUM,TSTNUM          ;SET UP THE TEST NUMBER.          (53)
6124 025432 012767 000001 156410          MOV  #-1,CTRLCF          ;INDICATE THAT WE ARE IN A TEST.
6125 025440 012767 012265 156404          MOV  #1,ERRTYP          ;SET ERROR TYPE AS FATAL IN ERROR TABLE.
6126 025446 012767 006265 156400          MOV  #5301,ERRNBR          ;SET ERROR NUMBER TO 5301.
6127          MOV  #EM5301,ERRMSG          ;SET ERROR MESSAGE ADDRESS IN ERROR TABLE.
6128 :
6129 : RESET THE DUT TO A KNOWN STATE, REMOVE THE STATUS CODES FROM THE FIFO.
6130 : CLEAR TX AND RX INTERRUPT ENABLE BITS IN THE CSR.
6131 : THIS SUBROUTINE REPORTS ERROR >>>> 5301 <<<<<.
6132 025454 004767 166536          JSR  PC,CLRST          ;RESET THE DHU-11, REPORT ANY ERRORS FOUND.
6133 025460 103113          BCC  608          ;EXIT TEST IF FATAL ERROR FOUND.
6134 :
6135 : FIND AN ACTIVE LINE ON WHICH TO PERFORM THE TEST.
6136 : INITIALISE 256 BYTE DATA PATTERN.
6137 :
6138 025462 004767 167002          JSR  PC,FINACT          ;FIND AN ACTIVE LINE.
6139 025466 103110          BCC  608          ;EXIT IF NO ACTIVE LINES FOUND.
6140 025470 004767 167054          JSR  PC,INDATP          ;INITIALISE THE DATA PATTERN.
6141 :
6142 : TRANSMIT A 265 CHARACTER DATA PATTERN USING DMA, ON A SINGLE CHANNEL
6143 : AT 38.4K BAUD, 8 BITS PER CHARACTER, ODD PARITY, 2 STOP BITS.
6144 :
6145 :
6146 :
6147 : SET INTERNAL LOOPBACK ON THE SELECTED LINE.
6148 : TRANSMIT THE DATA PATTERN ON THE FIRST AVAILABLE ACTIVE LINE.
6149 025474 012700 000204          MOV  #204,R0          ;PASS PARAMETER FOR INTERNAL LOOPBACK, ENABLE RX.
6150 025500 004767 172046          JSR  PC,WTLNC          ;INITIALISE THE LINE CONTROL REGISTER.
6151 025504 012700 177670          MOV  #177670,R0          ;PASS THE LPR CONTENTS.
6152 025510 004767 172066          JSR  PC,WTLPR          ;SET THE LPR CONTENTS TO 38.4K BAUD.
6153 025514 012704 000012          MOV  #10,R4          ;PASS DELAY TIME OF 10 MILLI SECONDS.
6154 025520 004767 166536          JSR  PC,DELAY          ;WAIT FOR LNCTRL AND LPR REGS TO BE UPDATED.
6155 025524 012702 002650          MOV  #BUFBAS,R2          ;PASS THE START OF THE DATA PATTERN TO TX.
6156 025530 012703 000400          MOV  #BUFMID-BUFBAS,R3 ;PASS THE LENGTH OF THE DATA PATTERN.

```

```

6157 025534 005267 156312          INC      ERRNBR      ;SET ERROR NUMBER TO 5302.
6158 025540 004767 166634          JSR      PC,DMA     ;TRANSMIT THE DATA PATTERN.
6159 025544 103057                    BCC      50$        ;ABORT TEST IF ERROR FOUND DURING DMA TX.
6160
6161                                ;*
6162                                ; WAIT FOR DMA TO COMPLETE, THEN WAIT FOR THE LAST CHARACTER TO ARRIVE IN
6163                                ; THE FIFO.
6164 025546 005267 156300          INC      ERRNBR      ;SET ERROR NUMBER TO 5303.
6165 025552 010103                    MOV      R1,R3      ;SAVE THE NUMBER OF THE SELECTED ACTIVE LINE.
6166 025554 012701 170536          MOV      #170536,R1 ;PASS TIME-OUT VALUE OF 350 MILLI SECS.
6167 025560 016702 154442          MOV      CSRA,R2   ;PASS THE ADDRESS OF THE CSR.
6168 025564 004767 171646          JSR      PC,WAIBIS  ;WAIT FOR DMA TO COMPLETE, TX ACTION SET.
6169 025570 103045                    BCC      50$        ;BRANCH IF FIFO EMPTY, ABORT THE TEST.
6170 025572 012704 000005          MOV      #5,R4     ;PASS DELAY OF 5 MILLI SECS.
6171 025576 004767 166460          JSR      PC,DELAY   ;WAIT FOR LAST CHAR TO ARRIVE IN THE FIFO.
6172
6173                                ;*
6174                                ; READ THE FIFO CHECKING FOR DATA CORRUPTION, REPORT ANY ERRORS FOUND.
6175                                ; ABORT THE TEST IF A BMP CODE WAS FOUND IN THE FIFO.
6176 025602 006303                    ;*
6177 025604 005004                    ASL      R3         ;MULTIPLY BY 2.
6178 025606 016705 154416          CLR      R4         ;INITIALISE THE EXPECTED DATA.
6179 025612 012767 012270 156232 2$: MOV      RBUFA,R5   ;GET THE ADDRESS OF THE RECEIVER BUFFER REG.
6180 025620 011502                    MOV      #5304,ERRNBR ;SET UP ERROR NUMBER EACH TIME AROUND LOOP.
6181 025622 100030                    MOV      (R5),R2   ;GET THE ACTUAL DATA FROM THE FIFO.
6182                                BPL      50$        ;ABORT THE TEST IF THE FIFO IS EMPTY.
6183                                ;*
6184                                ; CHECK IF THE READ CHARACTER IS A BMP CODE.
6185                                ; IF IT IS A BMP CODE SAVE IT ON THE QUEUE TO BE REPORTED LATER, AND
6186                                ; ABORT THE TEST.
6187 025624 005267 156222          INC      ERRNBR      ;SET ERROR NUMBER TO 5305.
6188 025630 004767 166142          JSR      PC,CHKBMP ;CHECK IF CHARACTER IS A BMP CODE.
6189 025634 103002                    BCC      4$        ;BRANCH IF NOT A BMP CODE.
6190 025636 104460                    ERROR                                ; >>>> ERROR 5305 <<<<.
6191                                TRAP      C$ERROR
6192 025640 000423                    BR       60$        ;ABORT THIS TEST.
6193
6194 025642 005267 156204          4$: INC      ERRNBR      ;SET ERROR NUMBER TO 5306.
6195 025646 120402                    CMPB    R4,R2      ;COMPARE THE EXPECTED WITH THE ACTUAL DATA.
6196 025650 001412                    BEQ     8$         ;SKIP ERROR REPORT IF DATA IS OK.
6197 025652 012767 012644 156176  MOV      #ER9002,ERRBLK ;SELECT THE CORRECT ERROR REPORTING ROUTINE.
6198 025660 012701 006321          MOV      #EM5302,R1 ;PASS THE MESSAGE TO BE REPORTED.
6199                                ;REPORT THE ERROR "FIFO BAD, DATA FIELD CORRUPTED"
6200 025664 104460          6$: ERROR                                ; >>>> ERROR 5306 <<<<.
6201                                TRAP      C$ERROR
6202
6203                                ;*
6204                                ; EXIT THE TEST IF EXTENDED ERROR REPORTING HAS NOT BEEN ENABLED
6205 025666 032767 000100 154314  ;*
6206 025674 001405                    BIT     #BIT06,OPTION ;EXIT WITH TEST FAILURE MESSAGE IF
6207                                BEQ     60$        ;NO EXTENDED ERROR REPORTING HAS BEEN REQUESTED
6208                                ;DURING THE SOFTWARE QUESTIONS.
6209 025676 105204          8$: INCB    R4         ;INCREMENT THE EXPECTED DATA.
6210 025700 001344                    BNE    2$         ;LOOP IF NOT DONE.
6211 025702 000402                    BR     60$        ;EXIT
    
```

6212
6213 025704 004767 170762 504: JSR PC.TSABRT
6214 025710 005067 154334 604: CLR CTRLCF
6215
6216 025714
025714
025714 104401
ENDTST

;ABORT THE TEST, REASON SHOWN BY ERROR NUMBER.
;INDICATE THAT WE ARE NOT WITHIN A TEST.

L10036: TRAP C\$ETST

613

6218
 6219
 6220
 6221
 6222
 6223
 6224
 6225
 6226
 6227
 6228
 6229
 6230
 6231
 6232
 6233
 6234 025716
 025716
 6235 025716
 025716 012700 000240
 025722 104441
 6236 000012
 6237 025724 012767 000012 154322
 6238 025732 012767 177777 154310
 6239 025740 012767 0000C1 156102
 6240 025746 012767 012431 156076
 6241 025754 012767 006452 156072
 6242 025762 012767 011762 156066
 6243
 6244
 6245
 6246
 6247
 6248 025770 004767 166222
 6249 025774 103111
 6250
 6251
 6252
 6253 025776 004767 166466
 6254 026002 103106
 6255
 6256
 6257
 6258
 6259
 6260
 6261 026004 004767 166570
 6262
 6263
 6264
 6265
 6266
 6267
 6268
 6269
 6270 026010 012700 000206
 6271 026014 004767 171532

```

.SBTTL  HARDWARE TEST      - FI3QLI -
;*****
;          - FIFO 3/4 LEVEL INACTIVE TEST
;
; THIS TEST VERIFIES THAT THE DUT'S FIFO 3/4 LEVEL ALARM SYSTEM
; REMAINS INACTIVE WHILE IT CONTAINS 191 CHARACTERS OR LESS.
; THE TEST LOOKS FOR AN XOFF (ASCII DC3) CHARACTER IN THE FIFO.
; IF ANY XOFF'S ARE FOUND AN ERROR WILL BE REPORTED AND THE TEST ABORTED.
; ANY BMP CODE FOUND WILL INVALIDATE THE TEST AND CAUSE IT TO BE ABORTED.
; HOWEVER THE BMP CODE WILL BE PLACED ON THE BMP CODE QUEUE, TO BE
; REPORTED LATER.
; THE CHARACTERS ARE TRANSMITTED ON THE FIRST AVAILABLE ACTIVE LINE, IN
; INTERNAL LOOPBACK MODE.
;*****
          BGNIST
          SETPRI  #PRI05          ;ALLOW LTC INTERRUPTS.          T10::
;
;          MOV          #PRI05,RO          ;MOV
;          TRAP          C$SPRI          ;TRAP
          TNUM == TNUM + 1          ;INCREMENT THE ASSEMBLY TIME TEST COUNTER.
          MOV          #TNUM,TSTNUM          ;SET UP THE TEST NUMBER.          (54)
          MOV          #-1,CTRLCF          ;INDICATE THAT WE ARE IN A TEST.
          MOV          #1,ERRTYP          ;SET FATAL ERROR TYPE IN ERROR TABLE.
          MOV          ^401,ERRNBR          ;SET ERROR NUMBER TO 5401.
          MOV          #EM5401,ERRMSG          ;SET ERROR MESSAGE ADDRESS IN ERROR TABLE.
          MOV          #ER0503,ERRBLK          ;SELECT THE CORRECT ERPOP REPORTING ROUTINE.
;
; RESET THE DUT TO A KNOWN STATE, REMOVE THE STATUS CODES FROM THE FIFO.
; CLEAR TX AND RX INTERRUPT ENABLE BITS IN THE CSR.
; THIS SUBROUTINE REPORTS ERROR >>>> 5401 <<<<<.
;
          JSR          PC,CLRST          ;RESET THE DHU-11, REPORT ANY ERRORS FOUND.
          BCC          60$          ;EXIT TEST IF FATAL ERROR FOUND.
;
; FIND AN ACTIVE LINE ON WHICH TO PERFORM THE TEST.
;
          JSR          PC,FINACT          ;FIND THE NUMBER OF THE FIRST ACTIVE LINE.
          BCC          60$          ;EXIT IF NO LINES ARE AVAILABLE.
;
; INITIALIZE THE 256 BYTE DATA PATTERN.
; ENSURE THE DATA PATTERN IS FREE FROM XON'S OR XOFF'S TO PREVENT ERRORS.
; NOTE: THE FIRST TWO CHARACTERS AND THE LAST TWO CHARACTERS WILL BE THE SAME.
;
          JSR          PC,INDTPX          ;INITIALISE THE DATA PATTERN.
;
; TRANSMIT A 191 CHARACTER DATA PATTERN USING DMA, ON A SINGLE CHANNEL
; AT 38.4K BAUD, 8 BITS PER CHARACTER, ODD PARITY, 2 STOP BITS.
;
;
; SET INTERNAL LOOPBACK, ENABLE IAUTO AND RX ON THE SELECTED LINE.
; TRANSMIT THE DATA PATTERN ON THE FIRST AVAILABLE ACTIVE LINE.
;
          MOV          #206,RO          ;PASS INTERNAL LOPBCK, ENABLE RX AND IAUTO.
          JSR          PC,WTWLNLC          ;INITILAISE THE LINE CONTRCL REGISTER.
    
```

```

6272 026020 012700 177670      MOV      #177670,R0      ;PASS THE LPR CONTENTS.
6273 026024 004767 171552      JSR      PC,WTWLPR      ;SET THE LPR CONTENTS TO 38.4K BAUD.
6274 026030 012704 000012      MOV      #10.,R4        ;PASS DELAY TIME OF 10 MILLI SECONDS.
6275 026034 004767 166222      JSR      PC,DELAY       ;WAIT FOR LNCTRL AND LPR REGS TO BE UPDATED.
6276 026040 012702 002650      MOV      #8UFBAS,R2     ;PASS THE START OF THE DATA PATTERN TO TX.
6277 026044 012703 000277      MOV      #191.,R3       ;PASS THE LENGTH OF THE DATA PATTERN.
6278 026050 004767 166324      JSR      PC,DDDMA       ;TRANSMIT THE DATA PATTERN.
6279 026054 103057              BCC      50$            ;IF ERROR FOUND DURING DMA THEN ABORT TEST.
6280
6281
6282
6283
6284
6285 026056 005267 155770      INC      ERRNBR         ;SET ERROR NUMBER TO 5402.
6286 026062 012701 170454      MOV      #170454,R1     ;PASS TIME-OUT VALUE OF 300 MILLI SECS.
6287 026066 016702 154134      MOV      CSRA,R2        ;PASS THE ADDRESS OF THE CSR.
6288 026072 004767 171340      JSR      PC,WAIBIS      ;WAIT FOR DMA TO COMPLETE, TX_ACTION SET.
6289 026076 103046              BCC      50$            ;IF FIFO EMPTY, REPORT ERROR, ABORT THE TEST.
6290 026100 012704 000005      MOV      #5,R4          ;PASS DELAY OF 5 MILLI SECS.
6291 026104 004767 166152      JSR      PC,DELAY       ;WAIT FOR LAST CHAR TO ARRIVE IN THE FIFO.
6292
6293
6294
6295
6296
6297
6298
6299
6300 026110 005004              ;READ THE CONTENTS OF THE FIFO. IF ANY OF THE FOLLOWING CONDITIONS OCCUR
6301 026112 016705 154112      ;REPORT THE ERROR AND ABORT THE TEST;
6302 026116 012767 012433 155726 2$:  ; FIFO EMPTY TOO SOON.
6303 026124 011502              ; BMP CODE FOUND.
6304 026126 100032              ; XOFF CODE FOUND.
6305 026130 005204              ; EXTRA (192) CHARACTER FOUND IN FIFO.
6306
6307
6308
6309
6310
6311 026132 005267 155714      CLR      R4              ;CLEAR THE CHARACTER COUNT.
6312 026136 004767 165634      MOV      RBUFA,R5       ;GET THE ADDRESS OF THE RECEIVER BUFFER REG.
6313 026142 103001              MOV      #5403.,ERRNBR  ;SET ERROR NUMBER TO 5403.
6314
6315 026144 000421              MOV      (R5),R2        ;GET THE ACTUAL DATA FROM THE FIFO.
6316
6317
6318
6319
6320 026146 005267 155700      BPL     50$              ;FIFO EMPTY, ABORT TEST.
6321 026152 122702 000023      INC     R4               ;COUNT THE CHARACTER.
6322 026156 001003              ;CHECK IF THE READ CHARACTER IS A BMP CODE.
6323 026160 012701 006520      ; IF IT IS A BMP CODE SAVE IT ON THE QUEUE TO BE REPORTED LATER, AND
6324
6325 026164 000411              ; ABORT THE TEST.
6326
6327 026166 005267 155660      INC     ERRNBR           ;SET ERROR NUMBER TO 5404.
6328 026172 020427 000277      JSR     PC,CHKBMP       ;CHECK IF CHARACTER IS A BMP CODE.
6329
6330
6331
6332
6333
6334
6335
6336
6337
6338
6339
6340
6341
6342
6343
6344
6345
6346
6347
6348
6349
6350
6351
6352
6353
6354
6355
6356
6357
6358
6359
6360
6361
6362
6363
6364
6365
6366
6367
6368
6369
6370
6371
6372
6373
6374
6375
6376
6377
6378
6379
6380
6381
6382
6383
6384
6385
6386
6387
6388
6389
6390
6391
6392
6393
6394
6395
6396
6397
6398
6399
6400
6401
6402
6403
6404
6405
6406
6407
6408
6409
6410
6411
6412
6413
6414
6415
6416
6417
6418
6419
6420
6421
6422
6423
6424
6425
6426
6427
6428
6429
6430
6431
6432
6433
6434
6435
6436
6437
6438
6439
6440
6441
6442
6443
6444
6445
6446
6447
6448
6449
6450
6451
6452
6453
6454
6455
6456
6457
6458
6459
6460
6461
6462
6463
6464
6465
6466
6467
6468
6469
6470
6471
6472
6473
6474
6475
6476
6477
6478
6479
6480
6481
6482
6483
6484
6485
6486
6487
6488
6489
6490
6491
6492
6493
6494
6495
6496
6497
6498
6499
6500
6501
6502
6503
6504
6505
6506
6507
6508
6509
6510
6511
6512
6513
6514
6515
6516
6517
6518
6519
6520
6521
6522
6523
6524
6525
6526
6527
6528
6529
6530
6531
6532
6533
6534
6535
6536
6537
6538
6539
6540
6541
6542
6543
6544
6545
6546
6547
6548
6549
6550
6551
6552
6553
6554
6555
6556
6557
6558
6559
6560
6561
6562
6563
6564
6565
6566
6567
6568
6569
6570
6571
6572
6573
6574
6575
6576
6577
6578
6579
6580
6581
6582
6583
6584
6585
6586
6587
6588
6589
6590
6591
6592
6593
6594
6595
6596
6597
6598
6599
6600
6601
6602
6603
6604
6605
6606
6607
6608
6609
6610
6611
6612
6613
6614
6615
6616
6617
6618
6619
6620
6621
6622
6623
6624
6625
6626
6627
6628
6629
6630
6631
6632
6633
6634
6635
6636
6637
6638
6639
6640
6641
6642
6643
6644
6645
6646
6647
6648
6649
6650
6651
6652
6653
6654
6655
6656
6657
6658
6659
6660
6661
6662
6663
6664
6665
6666
6667
6668
6669
6670
6671
6672
6673
6674
6675
6676
6677
6678
6679
6680
6681
6682
6683
6684
6685
6686
6687
6688
6689
6690
6691
6692
6693
6694
6695
6696
6697
6698
6699
6700
6701
6702
6703
6704
6705
6706
6707
6708
6709
6710
6711
6712
6713
6714
6715
6716
6717
6718
6719
6720
6721
6722
6723
6724
6725
6726
6727
6728
6729
6730
6731
6732
6733
6734
6735
6736
6737
6738
6739
6740
6741
6742
6743
6744
6745
6746
6747
6748
6749
6750
6751
6752
6753
6754
6755
6756
6757
6758
6759
6760
6761
6762
6763
6764
6765
6766
6767
6768
6769
6770
6771
6772
6773
6774
6775
6776
6777
6778
6779
6780
6781
6782
6783
6784
6785
6786
6787
6788
6789
6790
6791
6792
6793
6794
6795
6796
6797
6798
6799
6800
6801
6802
6803
6804
6805
6806
6807
6808
6809
6810
6811
6812
6813
6814
6815
6816
6817
6818
6819
6820
6821
6822
6823
6824
6825
6826
6827
6828
6829
6830
6831
6832
6833
6834
6835
6836
6837
6838
6839
6840
6841
6842
6843
6844
6845
6846
6847
6848
6849
6850
6851
6852
6853
6854
6855
6856
6857
6858
6859
6860
6861
6862
6863
6864
6865
6866
6867
6868
6869
6870
6871
6872
6873
6874
6875
6876
6877
6878
6879
6880
6881
6882
6883
6884
6885
6886
6887
6888
6889
6890
6891
6892
6893
6894
6895
6896
6897
6898
6899
6900
6901
6902
6903
6904
6905
6906
6907
6908
6909
6910
6911
6912
6913
6914
6915
6916
6917
6918
6919
6920
6921
6922
6923
6924
6925
6926
6927
6928
6929
6930
6931
6932
6933
6934
6935
6936
6937
6938
6939
6940
6941
6942
6943
6944
6945
6946
6947
6948
6949
6950
6951
6952
6953
6954
6955
6956
6957
6958
6959
6960
6961
6962
6963
6964
6965
6966
6967
6968
6969
6970
6971
6972
6973
6974
6975
6976
6977
6978
6979
6980
6981
6982
6983
6984
6985
6986
6987
6988
6989
6990
6991
6992
6993
6994
6995
6996
6997
6998
6999
7000
    
```



```

6344 .SBTTL  HARDWARE TEST          - FI3QLA -
6345 :*****
6346 :
6347 :          - FIFO 3/4 LEVEL ACTIVE TEST -
6348 :
6349 :          THIS TEST VERIFIES THAT THE DUT'S FIFO 3/4 LEVEL ALARM SYSTEM:
6350 :          BECOMES ACTIVE WHEN THE FIFO CONTAINS > 192 CHARACTERS.
6351 :          THE TEST COMPARES THE ACTUAL NUMBER OF XOFF (ASCII DC3)
6352 :          CHARACTERS THAT ARE FOUND IN THE FIFO WITH THE EXPECTED NUMBER.
6353 :          AN ERROR WILL BE REPORTED, IF THE COUNTS ARE FOUND TO DIFFER.
6354 :          ANY BMP CODE FOUND WILL INVALIDATE THE TEST AND CAUSE IT TO BE ABORTED.
6355 :          HOWEVER THE BMP CODE WILL BE PLACED ON THE BMP CODE QUEUE, TO BE
6356 :          REPORTED LATER.
6357 :          THE CHARACTERS ARE TRANSMITTED ON THE FIRST AVAILABLE ACTIVE LINE, IN
6358 :          INTERNAL LOOPBACK MODE.
6359 :
6360 :-----
6361 026226          BGNTST
6362 026226          SETPRI  #PRI05          ;ALLOW LTC INTERRUPTS.          T11::
        026226 012700 000240
        026232 104441
6363          000013          MOV          #PRI05,R0
        026234 012767 000013 154012          TNUM == TNUM + 1          ;INCREMENT THE ASSEMBLY TIME TEST COUNTER.
6364 026234 012767 000013 154012          MOV          #TNUM,TSTNUM          ;SET UP THE TEST NUMBER.          (55)
6365 026242 012767 177777 154000          MOV          #-1,CTRLCF          ;INDICATE THAT WE ARE IN A TEST.
6366 026250 012767 000001 155572          MOV          #1,ERRTYP          ;SET ERROR TYPE AS FATAL IN ERROR TABLE.
6367 026256 012767 012575 155566          MOV          #5501,ERRNBR          ;SET ERROR NUMBER TO 5501.
6368 026264 012767 006561 155562          MOV          #EMS501,ERRMSG          ;SET ERROR MESSAGE ADDRESS IN ERROR TABLE.
6369
6370 :
6371 :          ; RESET THE DUT TO A KNOWN STATE, REMOVE THE STATUS CODES FROM THE FIFO.
6372 :          ; CLEAR TX AND RX INTERRUPT ENABLE BITS IN THE CSR.
6373 :          ; THIS SUBROUTINE REPORTS ERROR >>>> 5501 <<<<<.
6374 026272 004767 165720          ;
6375 026276 103402          JSR          PC,CLNRST          ;RESET THE DMU-11, REPORT ANY ERRORS FOUND.
6376 026300 000167 000414          BCS          .+6          ;SKIP EXIT OF TEST IF NO FATAL ERROR FOUND.
6377          JMP          60$          ;EXIT TEST FATAL ERROR FOUND.
6378 :
6379 :          ; FIND AN ACTIVE LINE ON WHICH TO PERFORM THE TEST.
6380 026304 004767 166160          ;
6381 026310 103402          JSR          PC,FINACT          ;FIND AN ACTIVE LINE.
6382 026312 000167 000402          BCS          .+6          ;SKIP EXIT OF TEST IF ACTIVE LINE FOUND.
6383          JMP          60$          ;EXIT TEST.
6384 :
6385 :          ; INITIALIZE THE 256 BYTE DATA PATTERN.
6386 :          ; ENSURE THE DATA PATTERN IS FREE FROM XON'S OR XOFF'S TO PREVENT ERRORS.
6387 :          ; NOTE: THE FIRST TWO CHARACTERS AND THE LAST TWO CHARACTERS WILL BE THE SAME.
6388 026316 004767 166256          ;
6389          JSR          PC,INDTPX          ;INITIALISE DATA PATTERN.
6390 :
6391 :          ; TRANSMIT A 191 CHARACTER DATA PATTERN USING DMA, ON A SINGLE CHANNEL
6392 :          ; AT 38.4K BAUD, 8 BITS PER CHARACTER, ODD PARITY, 2 STOP BITS.
6393 :
6394 :          ;
6395 :          ; SET INTERNAL LOOPBACK, ENABLE IAUTO AND RECEIVER ON THE SELECTED LINE.
6396 :          ; TRANSMIT THE FIRST 191 CHARACTERS ON THE FIRST AVAILABLE ACTIVE LINE.
6397 026322 005267 155524          ;
        2$:          INC          ERRNBR          ;SET ERROR NUMBER TO 5502.
    
```

```

6398 026326 012700 000206      MOV      #206,R0      ;PASS INTERNAL LOPBCK, ENABLE RX AND IAUTO.
6399 026332 004767 171214      JSR      PC,WTWLNC    ;INITIALISE THE LINE CONTROL REGISTER.
6400 026336 012700 177670      MOV      #177670,R0   ;PASS THE LPR CONTENTS.
6401 026342 004767 171234      JSR      PC,WTWLPR    ;SET THE LPR CONTENTS TO 38.4K BAUD.
6402 026346 012704 000012      MOV      #10.,R4      ;PASS DELAY TIME OF 10 MILLI SECONDS.
6403 026352 004767 165704      JSR      PC,DELAY     ;WAIT FOR LNCTRL AND LPR REGS TO BE UPDATED.
6404 026356 010105                MOV      R1,R5        ;COPY THE LINE NUMBER.
6405 026360 012702 002650      MOV      #BUFBAS,R2   ;PASS THE START OF THE DATA PATTERN TO TX.
6406 026364 012703 000277      MOV      #191.,R3     ;PASS THE LENGTH OF THE DATA PATTERN.
6407 026370 004767 166004      JSR      PC,DODMA     ;TRANSMIT THE DATA PATTERN.
6408 026374 103147                BCC      50$          ;ABORT THE TEST IF ERROR FOUND DURING DMA TX.
6409
6410
6411      ;*
6412      ; WAIT FOR DMA TO COMPLETE, THEN WAIT FOR THE LAST CHARACTER TO ARRIVE IN
6413      ; THE FIFO.
6414 026376 005267 155450      INC      ERRNBR       ;SET ERROR NUMBER TO 5503.
6415 026402 012701 170454      MOV      #170454,R1   ;PASS TIME-OUT VALUE OF 300 MILLI SECS.
6416 026406 016702 153614      MOV      CSRA,R2      ;PASS THE ADDRESS OF THE CSR.
6417 026412 004767 171020      JSR      PC,WAIBIS    ;WAIT FOR DMA TO COMPLETE, TX_ACTION SET.
6418 026416 103136                BCC      50$          ;IF NO TX_ACTION WAS RECEIVED, ABORT THE TEST.
6419 026420 012704 000005      MOV      #5,R4        ;PASS DELAY OF 5 MILLI SECS.
6420 026424 004767 165632      JSR      PC,DELAY     ;WAIT FOR LAST CHAR TO ARRIVE IN THE FIFO.
6421
6422      ;*
6423      ; TRANSMIT A NULL CHARACTER WHICH WILL CAUSE AN XOFF TO BE GENERATED.
6424 026430 005267 155416      INC      ERRNBR       ;SET ERROR NUMBER TO 5504.
6425 026434 010501                MOV      R5,R1        ;PASS THE LINE NUMBER.
6426 026436 012702 002650      MOV      #BUFBAS,R2   ;PASS THE START OF THE DATA PATTERN TO TX.
6427 026442 012703 000001      MOV      #1,R3        ;PASS THE NUMBER OF CHARACTERS TO TX.
6428 026446 004767 165726      JSR      PC,DODMA     ;TX A NULL CHARACTER TO CAUSE AN XOFF.
6429 026452 103120                BCC      50$          ;ABORT THE TEST IF ERROR FOUND DURING DMA TX.
6430
6431      ;*
6432      ; WAIT FOR THE DMA TO COMPLETE AND THE LAST CHAR TO ARRIVE IN THE FIFO
6433 026454 005267 155372      INC      ERRNBR       ;SET ERROR NUMBER TO 5505.
6434 026460 012701 170012      MOV      #170012,R1   ;PASS TIME-OUT VALUE OF 10 MILLI SECS.
6435 026464 016702 153536      MOV      CSRA,R2      ;PASS THE ADDRESS OF THE CSR.
6436 026470 004767 170742      JSR      PC,WAIBIS    ;WAIT FOR DMA TO COMPLETE, TX_ACTION SET.
6437 026474 103107                BCC      50$          ;IF NO TX_ACTION WAS RECEIVED, ABORT THE TEST.
6438 026476 012704 000005      MOV      #5,R4        ;PASS DELAY OF 5 MILLI SECS.
6439 026502 004767 165554      JSR      PC,DELAY     ;WAIT FOR XOFF TO GET INTO THE FIFO.
6440
6441      ;*
6442      ; INITIALISE THE 256 BYTE DATA PATTERN TO ALL NULLS.
6443 026506 012702 002650      MOV      #BUFBAS,R2   ;INITIALIZE THE DATA PATTERN TO BE
6444 026512 105022                CLR      (R2)         ; ALL NULLS.
6445 026514 020227 003250      CMP      R2,#BUF MID ;
6446 026520 103774                BLO      4$          ;
6447
6448
6449      ;*
6450      ; TRANSMIT A FURTHER 31 NULL CHARACTERS WHICH WILL CAUSE 31 XOFF'S TO BE
6451      ; GENERATED.
6452 026522 005267 155324      INC      ERRNBR       ;SET ERROR NUMBER TO 5506.
6453 026526 010501                MOV      R5,R1        ;PASS THE LINE NUMBER.
6454 026530 012702 002650      MOV      #BUFBAS,R2   ;PASS THE START OF THE DATA PATTERN TO TX.
    
```



```

6455 026534 012703 000037      MOV    #31.,R3      ;PASS THE LENGTH OF THE DATA PATTERN.
6456 026540 004767 165634      JSR    PC,DODMA     ;TRANSMIT THE DATA PATTERN
6457 026544 103063              BCC    50$          ;ABORT THE TEST IF ERROR FOUND DURING DMA TX.
6458
6459
6460
6461
6462 026546 005267 155300      ;+
        ; WAIT FOR THE XOFF'S AND THE NULL CHARACTERS TO BE RECEIVED.
        ; THERE ARE NOW 255 CHARACTERS IN THE FIFO.
        ;-
6462 026546 005267 155300      INC    ERRNBR       ;SET ERROR NUMBER TO 5507.
6463 026552 012701 170454      MOV    #170454,R1   ;PASS TIME-OUT VALUE OF 300 MILLI SECS.
6464 026556 016702 153444      MOV    CSRA,R2      ;PASS THE ADDRESS OF THE CSR.
6465 026562 004767 170650      JSR    PC,WAIBIS    ;WAIT FOR DMA TO COMPLETE, TX_ACTION SET.
6466 026566 103052              BCC    50$          ;IF NO TX_ACTION WAS RECEIVED, ABORT THE TEST.
6467 026570 012704 000005      MOV    #5,R4        ;PASS DELAY OF 5 MILLI SECS.
6468 026574 004767 165462      JSR    PC,DELAY     ;WAIT FOR XOFF TO GET INTO THE FIFO.
6469
6470
6471
6472
6473 026600 005004              ;+
        ; READ THE FIFO UNTIL EMPTY, COUNTING THE NUMBER OF XOFF CHARACTERS
        ; THAT ARE FOUND.
        ;-
6473 026600 005004              CLR    R4           ;CLEAR CHARACTER COUNTER.
6474 026602 005003              CLR    R3           ;CLEAR THE XOFF FOUND COUNTER.
6475 026604 012701 170001      MOV    #170001,R1   ;INDICATE TO TEST DATA.VALID BIT, TIME-OUT 1MS.
6476 026610 012767 012604 155234 6$:  MOV    #5508.,ERRNBR ;SET UP ERROR NUMBER EACH TIME AROUND THE LOOP.
6477 026616 016702 153406      MOV    RBUFA,R2     ;INDICATE TO CHECK RECEIVE BUFFER REGISTER.
6478 026622 004767 170610      JSR    PC,WAIBIS    ;WAIT FOR RECEIVED CHAR OR TIME-OUT.
6479 026626 103032              BCC    50$          ;GO REPORT ERROR IF FIFO EMPTY.
6480 026630 005204              INC    R4           ;COUNT THE CHARACTER.
6481
6482
6483
6484
6485 026632 005267 155214      ;+
        ; CHECK FOR BMP CODES IN THE FIFO, ABORT THE TEST IF ANY ARE FOUND.
        ; SAVE THE BMP CODE ON THE QUEUE TO BE REPORTED LATER.
        ;-
6485 026632 005267 155214      INC    ERRNBR       ;SET ERROR NUMBER TO 5509.
6486 026636 004767 165134      JSR    PC,CHKBMP    ;CHECK IF WE HAVE GOT A BMP CODE.
6487 026642 103422              BCS    12$         ;GO REPORT THE ERROR IF WE FOUND A BMP CODE.
6488
6489
6490
6491 026644 122702 000023      ;+
        ; CHECK FOR XOFF CHARACTER.
        ;-
6491 026644 122702 000023      8$:  CMPB   #23,R2     ;CHECK IF THE RECEIVED CHARACTER WAS AN XOFF.
6492 026650 001001              BNE    10$         ;BRANCH IF CHARACTER WAS NOT AN XOFF.
6493 026652 005203              INC    R3           ;INCREMENT XOFF FOUND COUNT.
6494
6495
6496
6497 026654 020427 000400      ;+
        ; CHECK IF ALL THE CHARACTERS INCLUDING THE XON HAVE BEEN REMOVED.
        ;-
6497 026654 020427 000400      10$:  CMP    R4,#256.    ;CHECK IF WE HAVE REMOVED ALL THE CHARACTERS.
6498 026660 002753              BLT    6$          ;GO GET THE NEXT CHAR IF WE HAVE NOT FINISHED.
6499
6500
6501
6502
6503
6504 026662 012767 012606 155162      ;+
        ; CHECK IF THE CORRECT NUMBER OF XOFF'S WERE FOUND IN THE FIFO.
        ; REPORT ERROR IF COUNT IS INCORRECT.
        ;-
6504 026662 012767 012606 155162      MOV    #5510.,ERRNBR ;SET UP THE ERROR NUMBER TO 5510.
6505 026670 022703 000040      CMP    #32.,R3     ;COMPARE EXPECTED XOFF COUNT WITH ACTUAL COUNT.
6506 026674 001411              BEQ    60$         ;EXIT TEST IF SUCCESS.
6507 026676 012767 011762 155152      MOV    #ER0503,ERRBLK ;SELECT THE CORRECT ERROR REPORTING ROUTINE.
6508 026704 012701 006520      MOV    #EM5402,R1   ;PASS THE MESSAGE TO BE REPORTED.
6509
6510 026710 104460      12$:  ;REPORT THE ERROR "FIFO BAD, ALARM SIGNAL DEFECTIVE".
        ERROR
        ;
        ; >>>> ERROR <<<<<
        TRAP    C$ERROR

```



```

6518 .SBTTL HARDWARE TEST - FI3QAI -
6519 ;*****
6520 ;*
6521 ;*
6522 ;*
6523 ;* THIS TEST VERIFIES THAT THE DUT'S FIFO 3/4 LEVEL ALARM SYSTEM
6524 ;* BECOMES ACTIVE AND INACTIVE AT THE CORRECT LEVELS.
6525 ;* ANY BMP CODE FOUND WILL INVALIDATE THE TEST AND CAUSE IT TO BE ABORTED.
6526 ;* HOWEVER THE BMP CODE WILL BE PLACED ON THE BMP CODE QUEUE, TO BE
6527 ;* REPORTED LATER.
6528 ;* THE CHARACTERS ARE TRANSMITTED ON THE FIRST AVAILABLE ACTIVE LINE, IN
6529 ;* INTERNAL LOOPBACK MODE.
6530 ;*
6531 ;*****
6532 026726 BGNTST
        026726
6533 026726 SETPRI #PRI05 ;ALLOW LTC INTERRUPTS. T12::
        026726 012700 000240
        026732 104441
6534 000014 MOV #PRI05,R0
6535 026734 012767 000014 153312 TNUM == TNUM + 1 ;INCREMENT THE ASSEMBLY TIME TEST COUNTER
6536 026742 012767 177777 153300 MOV #TNUM,TSTNUM ;SET UP THE TEST NUMBER. (56)
6537 026750 012767 000001 155072 MOV #-1,CTRLCF ;INDICATE THAT WE ARE IN A TEST.
6538 026756 012767 012741 155066 MOV #1,ERRTYP ;SET ERROR TYPE AS FATAL IN ERROR TABLE.
6539 026764 012767 006625 155062 MOV #5601,ERRNBR ;SET ERROR NUMBER TO 5601.
6540 MOV #EM5601,ERRMSG ;SET ERROR MESSAGE ADDRESS IN ERROR TABLE.
6541 ;*
6542 ; RESET THE DUT TO A KNOWN STATE, REMOVE THE STATUS CODES FROM THE FIFO.
6543 ; CLEAR TX AND RX INTERRUPT ENABLE BITS IN THE CSR.
6544 ; THIS SUBROUTINE REPORTS ERROR >>>> 5601 <<<<.
6545 026772 004767 165220 JSR PC,CLNRST ;RESET THE DHU-11, REPORT ANY ERRORS FOUND.
6546 026776 103402 BCS 2$ ;SKIP EXITING TEST A SUCCESSFUL RESET.
6547 027000 000167 000412 JMP 60$ ;EXIT THIS TEST.
6548 027004
6549 2$:
6550 ;*
6551 ; FIND AN ACTIVE LINE ON WHICH TO PERFORM THE TEST.
6552 027004 004767 165460 JSR PC,FINACT ;FIND AN ACTIVE LINE.
6553 027010 103402 BCS .+6 ;SKIP EXIT OF TEST IF ACTIVE LINE FOUND.
6554 027012 000167 000400 JMP 60$ ;EXIT TEST.
6555
6556 ;*
6557 ; INITIALIZE THE 256 BYTE DATA PATTERN.
6558 ; ENSURE THE DATA PATTERN IS FREE FROM XON'S OR XOFF'S TO PREVENT ERRORS.
6559 ; NOTE: THE FIRST TWO CHARACTERS AND THE LAST TWO CHARACTERS WILL BE THE SAME.
6560 027016 004767 165556 JSR PC,INDTPX ;INITIALISE THE DATA PATTERN.
6561
6562 ;*
6563 ; TRANSMIT A 256 CHARACTER DATA PATTERN USING DMA, ON A SINGLE CHANNEL
6564 ; AT 38.4K BAUD, 8 BITS PER CHARACTER, ODD PARITY, 2 STOP BITS.
6565
6566 ;*
6567 ; SET INTERNAL LOOPBACK, ENABLE IAUTO AND RECEIVER ON THE SELECTED LINE.
6568 ; TRANSMIT THE FIRST 191 CHARACTERS ON THE FIRST AVAILABLE ACTIVE LINE.
6569 027022 005267 155024 INC ERRNBR ;SET ERROR NUMBER TO 5602.
6570 027026 012700 000206 MOV #206,R0 ;PASS INTERNAL LOPBCK, ENABLE RX AND IAUTO.
6571 027032 004767 170514 JSR PC,WTWLNLC ;INITILAISE THE LINE CONTROL REGISTER.
    
```

6572	027036	012700	177670	MOV	#177670,R0	;PASS THE LPR CONTENTS.
6573	027042	004767	170534	JSR	PC,WTMLPR	;SET THE LPR CONTENTS TO 38.4K BAUD.
6574	027046	012704	000012	MOV	#10.,R4	;PASS DELAY TIME OF 10 MILLI SECONDS.
6575	027052	004767	165204	JSR	PC,DELAY	;WAIT FOR LNCTRL AND LPR REGS TO BE UPDATED.
6576	027056	010105		MOV	R1,R5	;COPY THE LINE NUMBER.
6577	027060	012702	002650	MOV	#BUFBA5,R2	;PASS THE START OF THE DATA PATTERN TO TX.
6578	027064	012703	000277	MOV	#191.,R3	;PASS THE LENGTH OF THE DATA PATTERN.
6579	027070	004767	165304	JSR	PC,DODMA	;TRANSMIT THE DATA PATTERN.
6580	027074	103146		BCC	508	;EXIT IF ERROR FOUND DURING DMA TX.
6581						
6582						
6583						
6584						
6585	027076	005267	154750			
6586	027102	012701	170454	INC	ERRNBR	;SET ERROR NUMBER TO 5603.
6587	027106	016702	153114	MOV	#170454,R1	;PASS TIME-OUT VALUE OF 300 MILLI SECS.
6588	027112	004767	170320	MOV	CSRA,R2	;PASS THE ADDRESS OF THE CSR.
6589	027116	103135		JSR	PC,WAIBIS	;WAIT FOR DMA TO COMPLETE, TX ACTION SET.
6590	027120	012704	000005	BCC	508	;BRANCH IF FIFO EMPTY, ABORT THE TEST.
6591	027124	004767	165132	MOV	#5,R4	;PASS DELAY OF 5 MILLI SECS.
6592				JSR	PC,DELAY	;WAIT FOR LAST CHAR TO ARRIVE IN THE FIFO.
6593						
6594						
6595						
6596	027130	005267	154716			
6597	027134	010501		INC	ERRNBR	;SET ERROR NUMBER TO 5604.
6598	027136	012702	002650	MOV	R5,R1	;PASS THE LINE NUMBER.
6599	027142	012703	000001	MOV	#BUFBA5,R2	;PASS THE START OF THE DATA PATTERN TO TX.
6600	027146	004767	165226	MOV	#1,R3	;PASS THE NUMBER OF
6601	027152	103117		JSR	PC,DODMA	;TX A NULL CHARACTER TO CAUSE AN XOFF.
6602				BCC	508	;ABORT THE TEST IF ERROR FOUND DURING DMA TX.
6603						
6604						
6605	027154	005267	154672			
6606	027160	012701	170012	INC	ERRNBR	;SET ERROR NUMBER TO 5605.
6607	027164	016702	153036	MOV	#170012,R1	;PASS TIME-OUT VALUE OF 10 MILLI SECS.
6608	027170	004767	170242	MOV	CSRA,R2	;PASS THE ADDRESS OF THE CSR.
6609	027174	103106		JSR	PC,WAIBIS	;WAIT FOR DMA TO COMPLETE, TX ACTION SET.
6610	027176	012704	000005	BCC	508	;IF NO TX ACTION WAS RECEIVED, ABORT THE TEST.
6611	027202	004767	165054	MOV	#5,R4	;PASS DELAY OF 5 MILLI SECS.
6612				JSR	PC,DELAY	;WAIT FOR XOFF TO GET INTO THE FIFO.
6613	027206	010577	153014	MOV	R5,BCSRA	;SELECT THE LINE READY FOR TRANSMISSION.
6614						
6615						
6616						
6617						
6618						
6619						
6620	027212	005005				
6621	027214	005004				
6622	027216	012703	000300	CLR	R5	;CLEAR THE TX FLAG.
6623				CLR	R4	;CLEAR THE CHARACTER COUNTER.
6624	027222	012700	000003	MOV	#192.,R3	;SET UP READ COUNTER FOR THE FIRST 192 CHARS.
6625	027226	012701	170005			
6626	027232	016702	152772	48:	MOV	#5,R0
6627	027236	004767	170174	64:	MOV	#170005,R1
6628	027242	10304E			MOV	RBUFA,R2
					JSR	PC,WAIBIS
					BCC	144
						;EXIT LOOP IF TIME OUT, FIFO EMPTY.

```

6629 027244 005300
6630 027246 005303
6631 027250 005002
6632 027252 052705 100000
6633
6634
6635
6636
6637
6638 027256 012767 012746 154566 8:
6639 027264 004767 164506
6640 027270 103446
6641
6642
6643
6644
6645 027272 122702 000023 108:
6646 027276 001001
6647 027300 005204
6648
6649 027302 005700
6650 027304 001350
6651 027306 005705
6652 027310 100744
6653 027312 112777 000000 152714
6654 027320 010446
6655
6656
6657
6658 027322 005267 154524
6659 027326 012701 170012
6660 027332 016702 152670
6661 027336 004767 170074
6662 027342 103023
6663 027344 012704 000005
6664 027350 004767 164706
6665 027354 012604
6666 027356 000721
6667
6668
6669
6670
6671
6672 027360 012767 012750 154464 14:
6673 027366 020427 000077
6674 027372 001411
6675 027374 012767 011762 154454
6676 027402 012701 006520
6677
6678 027406
6679 027406 104460
6680 027410 000402
6681 027412 004767 167254 50:
6682 027416 005067 152626 60:
6683
6684 027422
    
```

DEC R0 ;DECREMENT READ COUNTER.
 DEC R3 ;DECREMENT CHAR COUNTER.
 BGT 88 ;SKIP DISBL'G TX IF FIRST 192 CHARS NOT READ.
 BIS #BIT15,R5 ;DISABLE ANY FURTHER TRANSMISSIONS.

;
 ; CHECK IF THE READ CHARACTER IS A BMP CODE.
 ; IF IT IS A BMP CODE SAVE IT ON THE QUEUE TO BE REPORTED LATER, AND
 ; ABORT THE TEST.

;
 ; SET UP ERROR NUMBER EACH TIME AROUND LOOP.
 ; CHECK IF CHARACTER IS A BMP CODE.
 ; GO REPORT ERROR AND ABORT TEST IF BMP FOUND.

;
 ; CHECK FOR XOFF CHARACTER, IF ONE IS FOUND, COUNT IT.
 ; TRANSMIT A NULL CHARACTER UNTIL THE FIRST 192 CHARS HAVE BEEN READ.

;
 ; CHECK IF THE RECEIVED CHARACTER WAS AN XOFF.
 ; BRANCH IF CHARACTER WAS NOT AN XOFF.
 ; INCREMENT THE XOFF CHAR FOUND COUNTER.

;
 ; CHECK READ COUNT, TO SEE IF A CHAR CAN BE TX.
 ; BRANCH IF 3 CHARS HAVE NOT YET BEEN READ.
 ; CHECK THE TRANSMISSION ENABLED FLAG.
 ; SKIP TRANSMITTING A CHARACTER IF TX DISABLED.
 ; TX A NULL CHARACTER.
 ; SAVE THE XOFF COUNT ON THE STACK.

;
 ; WAIT FOR THE CHARACTER TO BE RECEIVED BEFORE CONTINUING THE TEST.

;
 ; SET ERROR NUMBER TO 5607.
 ; PASS TIME-OUT VALUE OF 10 MILLI SECS.
 ; PASS THE ADDRESS OF THE CSR.
 ; WAIT FOR DMA TO COMPLETE, TX_ACTION SET.
 ; IF NO TX_ACTION WAS RECEIVED, ABORT THE TEST.
 ; PASS DELAY OF 5 MILLI SECS.
 ; WAIT FOR XOFF TO GET INTO THE FIFO.
 ; RESTORE THE XOFF COUNT.
 ; GO RESET THE READ COUNT AND GET NEXT CHAR.

;
 ; CHECK IF THE CORRECT NUMBER OF XOFF'S WERE FOUND IN THE FIFO
 ; REPORT ERROR IF COUNT IS INCORRECT.

;
 ; SET ERROR NUMBER TO 5608.
 ; COMPARE THE EXPECTED AND ACTUAL XOFF COUNTS.
 ; EXIT TEST IF SUCCESS.
 ; SELECT THE CORRECT ERROR REPORTING ROUTINE.
 ; PASS THE MESSAGE TO BE REPORTED.
 ; REPORT THE ERROR "FIFO BAD, ALARM SIGNAL DEFECTIVE".

;
 ; >>>> ERROR <<<<<.

;
 ; EXIT THIS TEST. TRAP C#ERROR

;
 ; REPORT TEST ABORTED. ERROR # INDICATES FAULT.
 ; INDICATE THAT WE ARE NOT WITHIN A TEST.

ENDTST

027422
027422 104401

L10041: TRAP C#ETST

6686
 6687
 6688
 6689
 6690
 6691
 6692
 6693
 6694
 6695
 6696
 6697
 6698
 6699
 6700 027424
 027424
 6701 027424
 027424 012700 000240
 027430 104441
 5702 000015
 6703 027432 012767 000015 152614
 6704 027440 012767 177777 152602
 6705 027446 012767 000001 154374
 6706 027454 012767 013105 154370
 6707 027462 012767 006702 154364
 6708 027470 012767 011762 154360
 6709
 6710
 6711
 6712
 6713
 6714 027476 004767 164514
 6715 027502 103402
 6716 027504 000167 000364
 6717 027510
 6718
 6719
 6720
 6721 027510 004767 164754
 6722 027514 103167
 6723
 6724
 6725
 6726
 6727
 6728 027516 004767 165056
 6729
 6730
 6731
 6732
 6733
 6734
 6735
 6736
 6737
 6738 027522 005267 154324
 6739 027526 004767 167014

```

.SBTTL  HARDWARE TEST          - FIHAVL -
;*****
;*                                     - FIFO HALF LEVEL ACTIVE/INACTIVE TEST
;*
;*   THIS TEST CHECKS THAT THE DUT'S FIFO HALF LEVEL ALARM SYSTEM
;*   BECOMES ACTIVE AND INACTIVE AT THE CORRECT LEVELS.
;*   ANY BMP CODE FOUND WILL INVALIDATE THE TEST AND CAUSE IT TO BE ABORTED.
;*   HOWEVER THE BMP CODE WILL BE PLACED ON THE BMP CODE QUEUE, TO BE
;*   REPORTED LATER.
;*   THE CHARACTERS ARE TRANSMITTED ON THE FIRST AVAILABLE ACTIVE LINE, IN
;*   INTERNAL LOOPBACK MODE.
;*****
BGNTST
SETPRI  #PRI05                ;ALLOW LTC INTERRUPTS.          T13::
                                MOV      #PRI05,R0
                                TRAP    C$SPRI
TNUM  == TNUM + 1             ;INCREMENT THE ASSEMBLY TIME TEST COUNTER.
MOV    #TNUM,TSTNUM          ;SET UP THE TEST NUMBER.          (57)
MOV    #-1,CTRLCF            ;INDICATE THAT WE ARE IN A TEST.
MOV    #1,ERRTP              ;SET ERROR TYPE AS FATAL IN ERROR TABLE.
MOV    #5701,ERRNBR          ;SET ERROR NUMBER TO 5701.
MOV    #EM5701,ERRMSG        ;SET ERROR MESSAGE ADDRESS IN ERROR TABLE.
MOV    #ER0503,ERRBLK        ;SELECT THE ERROR REPORTING ROUTINE.
;
; RESET THE DUT TO A KNOWN STATE, REMOVE THE STATUS CODES FROM THE FIFO.
; CLEAR TX AND RX INTERRUPT ENABLE BITS IN THE CSR.
; THIS SUBROUTINE REPORTS ERROR >>>> 5701 <<<<<.
;
JSR    PC,CLRST              ;RESET THE DMU-11, REPORT ANY ERRORS FOUND.
BCS    2$                    ;SKIP EXITING TEST A SUCCESSFUL RESET.
JMP    60$                    ;EXIT THIS TEST.
2$:
;
; FIND AN ACTIVE LINE ON WHICH TO PERFORM THE TEST.
;
JSR    PC,FINACT             ;FIND AN ACTIVE LINE.
BCC    60$                    ;EXIT IF NO ACTIVE LINES AVAILABLE.
;
; INITIALIZE THE 256 BYTE DATA PATTERN.
; ENSURE THE DATA PATTERN IS FREE FROM XON'S OR XOFF'S TO PREVENT ERRORS.
; NOTE: THE FIRST TWO CHARACTERS AND THE LAST TWO CHARACTERS WILL BE THE SAME.
;
JSR    PC,INDTPX             ;INITIALISE THE DATA PATTERN.
;
; FILL THE FIFO AND THE UART'S 3 CHAR BUFFER BY TRANSMITTING 225 CHARS
; (IE 225 + 34 XOFF'S). TRANSMIT DATA PATTERN USING DMA, ON A SINGLE CHANNEL
; AT 38.4K BAUD, 8 BITS PER CHARACTER, ODD PARITY, 2 STOP BITS.
;
;
; SET INTERNAL LOOPBACK, ENABLE IAUTO AND RECEIVER ON THE SELECTED LINE.
; TRANSMIT THE 225 CHARACTERS ON THE FIRST AVAILABLE ACTIVE LINE.
;
INC    ERRNBR                 ;SET ERROR NUMBER TO 5702.
JSR    PC,SETPAR             ;SET UP PARAMETERS FOR TRANSMISSION.
    
```

```

6740 027532 012700 000341      MOV    #225.,R0      ;PASS LENGTH OF DATA PATTERN.
6741 027536 004767 167242      JSR    PC,TXDATP     ;TRANSMIT DATA PATTERN.
6742 027542 103152              BCC    50$           ;EXIT IF ERROR FOUND DURING TX.
6743 027544 010105              MOV    R1,R5        ;COPY THE LINE NUMBER.
6744
6745      ;*
6746      ; WAIT FOR DMA TO COMPLETE, THEN WAIT FOR THE LAST CHARACTER TO ARRIVE IN
6747      ; THE FIFO.
6748 027546 005267 154300      INC    ERRNBR        ;SET ERROR NUMBER TO 5703.
6749 027552 004767 167734      JSR    PC,WAITTX     ;WAIT FOR TRANSMISSION TO COMPLETE.
6750 027556 103144              BCC    50$           ;GO REPORT ERROR IF TX FAILED TO COMPLETE.
6751
6752      ;*
6753      ; READ THE FIRST 130 CHARACTERS FROM THE FIFO, IF ANY XON'S ARE FOUND
6754      ; REPORT THE ERROR. IF ANY BMP CODES ARE FOUND THEN SAVE THEM ON THE QUEUE
6755      ; AND ABORT THE TEST.
6756 027560 005267 154266      INC    ERRNBR        ;SET ERROR NUMBER TO 5704.
6757 027564 012700 000202      MOV    #130.,R0     ;PASS THE NUMBER OF CHARS TO READ.
6758 027570 004767 166060      JSR    PC,READBX     ;READ THE FIRST 130 CHARS FROM THE FIFO.
6759 027574 103135              BCC    50$           ;GO REPORT ERROR IF BMP CODE FOUND.
6760 027576 005267 154250      INC    ERRNBR        ;SET ERROR NUMBER TO 5705.
6761 027602 005701              TST    R1            ;CHECK IF AN XON WAS FOUND.
6762 027604 001125              BNE    30$           ;GO REPORT ERROR IF AN XON WAS FOUND.
6763
6764
6765      ;*
6766      ; TRANSMIT A NULL CHARACTER (WHICH CAUSES AN XOFF TO BE GENERATED).
6767 027606 010577 152414      MOV    R5,BCSRA      ;SELECT THE LINE READY FOR TRANSMISSION.
6768 027612 112777 000000 152414      MOVB  #0,BFDATA     ;TRANSMIT A NULL CHARACTER.
6769 027620 005267 154226      INC    ERRNBR        ;SET ERROR NUMBER TO 5706.
6770 027624 004767 167662      JSR    PC,WAITTX     ;WAIT FOR TX TO COMPLETE.
6771 027630 103117              BCC    50$           ;GO REPORT ERROR IF TX DID NOT COMPLETE.
6772
6773      ;*
6774      ; READ THREE CHARACTERS, TO CAUSE THE XON TO BE GENERATED.
6775 027632 005267 154214      INC    ERRNBR        ;SET ERROR NUMBER TO 5707.
6776 027636 012700 000003      MOV    #3,R0        ;SET THE READ COUNT TO 3.
6777 027642 004767 166006      JSR    PC,READBX     ;READ 3 CHARACTERS FROM THE FIFO.
6778 027646 103110              BCC    50$           ;GO REPORT ERROR IF FIFO EMPTY.
6779 027650 005267 154176      INC    ERRNBR        ;SET ERROR NUMBER TO 5708.
6780 027654 005701              TST    R1            ;CHECK IF AN XON WAS FOUND.
6781 027656 001102              BNE    40$           ;GO REPORT ERROR IF AN XON WAS FOUND.
6782
6783      ;*
6784      ; TRANSMIT 62 CHARACTERS TO BRACKET THE XON AND FILL THE FIFO WITH 191 CHARS.
6785 027660 012700 000076      MOV    #62.,R0      ;PASS LENGTH OF DATA PATTERN.
6786 027664 010501              MOV    R5,R1        ;PASS THE LINE NUMBER.
6787 027666 005267 154160      INC    ERRNBR        ;SET ERROR NUMBER TO 5709.
6788 027672 004767 167106      JSR    PC,TXDATP     ;TRANSMIT DATA PATTERN.
6789 027676 103074              BCC    50$           ;EXIT IF ERROR FOUND DURING TX.
6790
6791
6792      ;*
6793      ; WAIT FOR DMA TO COMPLETE, THEN WAIT FOR THE LAST CHARACTER TO ARRIVE IN
6794      ; THE FIFO.
6795 027700 005267 154146      INC    ERRNBR        ;SET ERROR NUMBER TO 5710.
6796 027704 004767 167602      JSR    PC,WAITTX     ;WAIT FOR TX TO COMPLETE.
    
```



```

6797 027710 103067          BCC      50$          ;GO REPORT ERROR IF TX FAILED TO COMPLETE.
6798
6799
6800          ; READ THE FIRST 126 CHARACTERS.
6801          ; READ THE NEXT 4 CHARACTERS AND CHECK IF THEY ARE IN THE FOLLOWING ORDER
6802          ; NULL, XOFF, XON, NULL.
6803 027712 005267 154134      INC      ERRNBR          ;SET ERROR NUMBER TO 5711.
6804 027716 012700 000176      MOV      #126.,R0        ;SET UP READ COUNTER.
6805 027722 004767 165726      JSR      PC,READBX       ;READ THE FIRST 126 CHARS.
6806 027726 103060          BCC      50$          ;GO REPORT THE ERROR IF FIFO EMPTY.
6807 027730 005267 154116      INC      ERRNBR          ;SET ERROR NUMBER TO 5712.
6808 027734 005701          TST      R1              ;CHECK IF AN XON WAS FOUND.
6809 027736 001052          BNE      40$          ;GO REPORT ERROR IF AN XON WAS FOUND.
6810 027740 005267 154106      INC      ERRNBR          ;SET ERROR NUMBER TO 5713.
6811 027744 012701 006520      MOV      #EMS402,R1      ;PASS THE MESSAGE TO BE REPORTED.
6812 027750 016703 152254      MOV      RBUFA,R3        ;GET THE RECEIVER BUFFER ADDRESS.
6813 027754 011302          MOV      (R3),R2         ;READ THE NULL CHARACTER FROM THE FIFO.
6814 027756 120227 000000      CMPB    R2,#000         ;CHECK IF IT IS A NULL CHARACTER.
6815 027762 001040          BNE      40$          ;GO REPORT THE ERROR IF NOT THE SAME.
6816 027764 005267 154062      INC      ERRNBR          ;SET ERROR NUMBER TO 5714.
6817 027770 011302          MOV      (R3),R2         ;READ THE XOFF FROM THE FIFO.
6818 027772 120227 000023      CMPB    R2,#23         ;CHECK IF THE READ CHAR IS AN XOFF.
6819 027776 001032          BNE      40$          ;GO REPORT THE ERROR IF NOT THE SAME.
6820 030000 011302          MOV      (R3),R2         ;READ THE XON FROM THE FIFO.
6821 030002 005267 154044      INC      ERRNBR          ;SET ERROR NUMBER TO 5715.
6822 030006 120227 000021      CMPB    R2,#21         ;CHECK IF THE READ CHARACTER IS AN XON.
6823 030012 001024          BNE      40$          ;GO REPORT THE ERROR IF NOT THE SAME.
6824 030014 005267 154032      INC      ERRNBR          ;SET ERROR NUMBER TO 5716.
6825 030020 011302          MOV      (R3),R2         ;READ THE NULL CHARACTER FROM THE FIFO.
6826 030022 120227 000000      CMPB    R2,#000         ;CHECK IF IT IS A NULL CHARACTER.
6827 030026 001016          BNE      40$          ;GO REPORT THE ERROR IF NOT THE SAME.
6828
6829
6830          ; READ THE REMAINING CHARACTERS FROM THE FIFO.
6831
6832 030030 012700 000075      6$:     MOV      #61.,R0        ;SET UP READ COUNTER.
6833 030034 005267 154012      INC      ERRNBR          ;SET ERROR NUMBER TO 5717.
6834 030040 004767 165610      JSR      PC,READBX       ;READ THE FIRST 61 CHARS.
6835 030044 103011          BCC      50$          ;GO REPORT THE ERROR IF FIFO EMPTY.
6836 030046 005267 154000      INC      ERRNBR          ;SET ERROR NUMBER TO 5718.
6837 030052 005701          TST      R1              ;CHECK IF AN XON WAS FOUND.
6838 030054 001003          BNE      40$          ;GO REPORT ERROR IF AN XON WAS FOUND.
6839 030056 000406          BR       60$          ;EXIT THE TEST.
6840 030060 012701 006520      30$:    MOV      #EMS402,R1    ;SET UP THE MESSAGE
6841
6842 030064          40$:    ERROR          ; "FIFO ALARM SIGNAL DEFECTIVE".
6843 030064 104460          ;          >>>>> ERROR <<<<<<
6844 030066 000402          BR       60$          TRAP      C$ERROR
6845
6845 030070 004767 166576      50$:    JSR      PC,TSABRT     ;REPORT TEST ABORTED. ERROR # INDICATES FAULT.
6846 030074 005067 152150      60$:    CLR      CTRLCF      ;INDICATE THAT WE ARE NOT WITHIN A TEST.
6847
6848 03010C          ENDTST
        030100
        030100 104401          L10042: TRAP      C$ETST
    
```

```

6850 .SBTTL HARDWARE TEST RXTIMER
6851 ;* *****
6852 ;* - RXTIMER REG TEST -
6853 ;* THIS TEST VERIFIES THAT THE RXTIMER DELAYS ANY RX-INTS BY THE
6854 ;* REQUESTED AMOUNT AND THAT WHEN THE RXFIFO IS MORE THAN 3/4 FULL
6855 ;* THE RXTIMER VALUE IS IGNORED AND AN INTERRUPT OCCURS IMMEDIATELY.
6856 ;* DUE TO THE DIFFERENCES IN LTC HANDLING OF DIFFERENT VERSIONS OF
6857 ;* THE DRS AND LTC AVAILABILITY ON DIFFERENT PDP-11 MACHINES THE
6858 ;* RX-INT CAN ONLY BE TIMED TO WITHIN +/- 20% OF THE RXTIMER VALUE.
6859 ;* THIS TEST IS PERFORMED IN INTERNAL LOOPBACK ON THE FIRST ACTIVE LINE.
6860 ;*
6861 ;* *****
6862 ;*
6863 030102 BGNTST
6864 030102 SETPRI #PRI05 ;ALLOW LTC INTERRUPTS. T14::
        030102 012700 000240
        030106 104441
6865 030106 000016 ;INCREMENT ASSEMBLY TIME TEST COUNTER
        MOV #PRI05,RO
        TRAP C$SPRI
6866 030110 012767 000016 152136 TNUM == TNUM + 1
        MOV #TNUM,TSTNUM ;SET UP THE TEST NUMBER.
6867 030116 012767 177777 152124 MOV #-1,CTRLCF ;INDICATE THAT WE ARE IN A TEST.
6868 030124 012767 000001 153715 MOV #1,ERRTYP ;SET ERROR TYPE AS FATAL IN ERROR TABLE.
6869 030132 012767 013251 153712 MOV #5801,ERRNBR ;SET THE ERROR NUMBER TO 5801.
6870 030140 012767 006757 153706 MOV #EM5801,ERRMSG ;SET ERROR MESSAGE ADDRESS IN ERROR TABLE.
6871 030146 005067 152100 CLR EXOERR ;CLEAR THE "EXIT ON ERROR" FLAG.
6872 ;*
6873 ;* RESET THE DEVICE AND LEAVE THE SELFTEST CODES IN THE FIFO.
6874 ;*
6875 030152 004767 166124 JSR PC,RESET ;RESET THE DUT.
6876 030156 103402 BCS .+6 ;CONTINUE IF FIFO PURGED
6877 030160 000167 000732 JMP 60$ ;REPORT THE RESET FAILURE.
6878 ;*
6879 ;* SET UP THE INTERRUPT SERVICE ROUTINE THAT DETECTS THE RX-INT.
6880 ;*
6881 030164 SETVEC RXVECA,#RXDECT,#PRI06
        030164 012746 000300
        030170 012746 017702
        030174 016746 152014
        030200 012746 000003
        030204 104437
        030206 062706 000010
6882 030212 SETPRI #PRI04 ;ALLOW DEVICE INTERRUPTS.
        030212 012700 000200
        030216 104441
6883 030220 005067 152042 CLR RXINTC ;CLEAR THE RX-INT COUNT.
6884 ;*
6885 ;* ENABLE RX-INTS AND WAIT FOR ONE TO OCCUR.
6886 ;*
6887 030224 004767 166224 JSR PC,RXIE1 ;ENABLE RX-INTS.
6888 030230 012704 000005 MOV #5,R4 ;SET THE DELAY OF 5 MILLI SECS.
6889 030234 004767 164022 JSR PC,DELAY ;DELAY WHILE THE INT OCCURS.
6890 030240 064767 166150 JSR PC,RXIE0 ;DISABLE RX-INTS.
6891 030244 005267 153602 INC ERRNBR ;SET THE ERROR NUMBER TO 5802.
6892 030250 005767 152012 TST RXINTC ;TEST IF AN INTERRUPT OCCURED.
6893 030254 001002 BNE .+6 ;CONTINUE IF AN INTERRUPT OCCURED.
6894 030256 000167 000630 JMP 50$ ;REPORT THE ERROR IF NO INTERRUPT.
6895 ;*
    
```

```

6896 ; SET INTERNAL LOOPBACK ON THE FIRST ACTIVE LINE AND ENABLE RECIEVERS. SET UP
6897 ; THE LPR'S TO 38.4K BAUD, 8 BITS/CHARA, ODD PARITY, 2 STOP BITS.
5898 ;
6899 030262 004767 164202 JSR PC,FINACT ;FIND AN ACTIVE LINE FOR THIS TEST.
6900 030266 103402 BCS .+6 ;CONTINUE IF A LINE HAS BEEN FOUND.
6901 030270 000167 000622 JMP 60$ ;EXIT THE TEST IF NO LINES ACTIVE.
6902 030274 012700 000204 MOV #204,R0 ;PASS PARAMETER FOR INTERNAL LOOPBACK,
6903 ;ENABLE RECIEVERS.
6904 030300 004767 167246 JSR PC,WTWLNLC ;INITIALISE THE LINE CONTROL REGS.
6905 030304 012700 177670 MOV #177670,R0 ;PASS THE LPR CONTENTS.
6906 030310 004767 167266 JSR PC,WTWLPR ;SET THE LPR'S TO 38.4K BAUD.
6907 030314 012704 000012 MOV #10,R4 ;PASS DELAY TIME OF 10 MILLI SECS.
6908 030320 004767 163736 JSR PC,DELAY ;WAIT FOR LNCTRL AND LPR REGS TO BE UPDATED.
6909 ;
6910 ;
6911 ; SET UP THE LOOP TO TEST THE RXTIMER WITH DELAYS OF 15,31,63,127 AND 255 MS.
6912 ; DMA 191 CHARACTERS INTO THE FIFO AND THEN ENABLE INTERRUPTS, VERIFY THAT
6913 ; THE INTERRUPT OCCURS WITHIN +/- 20% OF THE RXTIMER VALUE.
6914 030324 010167 000616 ;
6915 030330 012705 000020 MOV R1,70$ ;SAVE THE LINE NUMBER.
6916 030334 012767 013253 MOV #16,R5 ;SET THE FIRST (RXTIMER VALUE + 1).
6917 030342 004767 165022 MOV #5803,ERRNBR ;SET THE ERROR NUMBER TO 5803.
6918 030346 103402 JSR PC,PUFIFO ;PURGE THE RXFIFO.
6919 030350 000167 000536 BCS .+6 ;CONTINUE IF SUCCESSFUL.
6920 030354 016701 000566 JMP 50$ ;REPORT THE ERROR IF FIFO FAILED TO PURGE.
6921 030360 012703 000277 MOV 70$,R1 ;PASS THE LINE NUMBER.
6922 030364 005267 153462 MOV #191,R3 ;PASS THE NUMBER OF CHARS TO DMA.
6923 030370 004767 163726 INC ERRNBR ;SET THE ERROR NUMBER TO 5804.
6924 ; JSR PC,DMABUF ;PERFORM THE DMA FROM ADDR #BUFBAS,T:IS SUBR
6925 030374 103402 ; PRODUCES ERRORS >>>> 5804 THRU 5805 <<<<<.
6926 030376 000167 000510 BCS .+6 ;CONTINUE IF SUCCESSFUL.
6927 ; JMP 50$ ;REPORT THE ERROR IF ONE OCCURED.
6928 ;
6929 ; CALCULATE THE TIME-OUT VALUE FOR THE RX-INT, SET UP THE RXTIMER, AND
6930 ; WAIT FOR THE RX-INT.
6931 030402 010501 ;
6932 030404 006301 MOV R5,R1 ;COPY THE RXTIMER VALUE + 1.
6933 030406 006301 ASL R1 ;MULTIPLY BY 4 TO OBTAIN,
6934 030410 105077 151612 ASL R1 ;THE TIME-OUT FOR THE RX-INT.
6935 ; CLR# @CSRA ;CLEAR THE IND.ADDR.REG BITS OF THE CSR READY,
6936 030414 010500 ; FOR THE WRITE TO THE RXTIMER REG.
6937 030416 005300 MOV R5,R0 ;COPY THE RXTIMER VALUE +1.
6938 030420 110077 151604 DEC R0 ;GET THE RXTIMER VALUE
6939 030424 012704 000002 MOV# R0,@RXTMA ;LOAD THE RXTIMER REG.
6940 030430 004767 163626 MOV #2,R4 ;SET DELAY OF 2 MS.
6941 030434 012702 000001 JSR PC,DELAY ;DELAY TO ALLOW THE RXTIMER VALUE TO UPDATE.
6942 030440 010203 MOV #BIT0,R2 ;INDICATE TO TEST BIT0.
6943 030442 012704 002266 MOV #R2,R3 ;INDICATE TO TEST FOR A "1".
6944 030446 005067 151614 MOV #RXINTC,R4 ;PASS ADDR OF WORD TO TEST.
6945 030452 012767 000100 CLR RXINTC ;CLEAR THE RX-INT COUNT.
6946 030460 016777 151572 MOV #BIT06,IESTAT ;SET THE RX-INT-ENBL BIT IN IESTAT.
6947 030466 004767 164236 MOV IESTAT,@CSRA ;ENABLE RX-INTS.
6948 030472 103415 JSR PC,MSLGET ;WAIT FOR THE INT TO OCCUR.
6949 ; BCS 4$ ;AVOID ERROR REPORT IF THE INTERRUPT OCCURED.
6950 ;
6951 ; REPORT THE TIME-OUT ERROR. >>>> 5806 <<<<<.
6952 030474 010502 ;
        MOV R5,R2 ;PASS THE RXTIMER VALUE TO,
    
```

```

6953 030476 005302          DEC R2          ;THE ERROR REPORTING ROUTINE.
6954 030500 012701 007265  MOV #EM5805,R1 ;PASS THE MESSAGE,
6955                                     ; "RXTIMER BAD, TIME-OUT OCCURED WAITING FOR
6956                                     ; THE RX-INT".
6957
6958 030504          ERRDF 5806,EM5801,ER5801 ;REPORT ERROR 5806.
        030504 104455
        030506 013256          TRAP C$ERDF
        030510 006757          .WORD 5806
        030512 012112          .WORD EM5801
        .WORD ER5801
6959
6960 030514 032767 000100 151466  BIT #BIT06,OPTION ;HAS EXTENDED ERROR REPORTING BEEN REQUESTED ?
6961 030522 001575          BEQ 60$          ;EXIT THE TEST IF IT HASN'T.
6962 030524 000454          BR 6$           ;BRANCH TO TEST ANOTHER RXTIMER VALUE.
6963
        ;*
        ; CHECK THAT THE INTERRUPT OCCURED WITHIN +/- 20% OF THE RXTIMER VALUE.
        ; THIS SUBROUTINE REPORTS ERROR >>>> 5807 <<<<<.
        ;-
6967 030526 012767 013257 153316 4$: MOV #5807.,ERRNBR ;SET THE ERROR NUMBER TO 5807.
6968 030534 010502          MOV R5,R2       ;PASS THE RXTIMER VALUE TO,
6969 030536 005302          DEC R2         ;THE "CHECK TIME" SUBR.
6970 030540 004767 163302  JSR PC,CKRXTM  ;CHECK THE TIME TAKEN AND REPORT ANY ERROR.
6971 030544 005767 151502  TST EXOERR     ;TEST THE "EXIT ON ERROR" FLAG.
6972 030550 001162          BNE 60$       ;EXIT IF SET.
6973 030552 004767 165636  JSR PC,RXIE0   ;DISABLE RX-INTS.
6974
        ;*
        ; DMA ANOTHER CHARACTER TO FILL THE FIFO TO THE 75% LEVEL, AND CHECK THAT THE
        ; RX-INT OCCURS IMMEDIATELY.
        ;-
6978 030556 016701 000364          MOV 70$,R1     ;PASS THE LINE NUMBER.
6979 030562 012703 000001          MOV #1,R3     ;PASS THE NUMBER OF CHARS TO DMA.
6980 030566 005267 153260          INC ERRNBR    ;SET THE ERROR NUMBER TO 5808.
6981 030572 004767 163524          JSR PC,DMABUF ;PERFORM THE DMA FROM ADDR #BUFBAS,THIS SUBR
6982                                     ;PRODUCES ERRORS >>>> 5808 THRU 5809 <<<<<.
6983 030576 103145          BCC 50$       ;REPORT THE ERROR IF ONE OCCURED.
6984 030600 005067 151462          CLR RXINTC   ;CLEAR THE RX-INT COUNT.
6985 030604 012701 000005          MOV #5,R1    ;SET THE TIME-OUT TO 5 MS.
6986 030610 012702 002266          MOV #RXINTC,R2 ;PASS ADDR OF WORD TO TEST.
6987 030614 004767 165634          JSR PC,RXIE1 ;ENABLE INTERRUPTS.
6988 030620 004767 166612          JSR PC,WAIBIS ;WAIT FOR THE INT TO OCCUR.
6989 030624 103414          BCS 6$       ;AVOID THE ERROR IF AN INTERRUPT OCCURED.
6990
        ;*
        ; REPORT THE ERROR, RX-INT DID NOT OCCUR IMMEDIATLEY >>>> 5810 <<<<<.
        ;-
6993 030626 010502          MOV R5,R2     ;PASS THE RXTIMER VALUE.
6994 030630 005302          DEC R2
6995 030632 012701 007077  MOV #EM5803,R1 ;PASS THE MESSAGE,
6996                                     ; "RXTIMER BAD, RX-INT DID NOT OCCUR
6997                                     ; IMMEDIATELY WHEN RXFIFO 3/4 FULL".
6998
6999 030636          ERRDF 5810,EM5801,ER5801 ; REPORT ERROR 5810.
        030636 104455          TRAP C$ERDF
        030640 013262          .WORD 5810
        030642 006757          .WORD EM5801
        030644 012112          .WORD ER5801
7000
7001 030646 032767 000100 151334  BIT #BIT06,OPTION ;HAS EXTENDED ERROR REPORTING BEEN REQUESTED ?
    
```

```

7002 030654 001520          BEQ      60$          ;EXIT THE TEST IF IT HASN'T.
7003
7004
7005          ;*
7006          ; SELECT ANOTHER VALUE FOR THE RXTIMER OR IF ALL VALUES HAVE BEEN TESTED THEN
7007          ; TEST THE RXTIMER WITH INDEFINATE DELAY SET.
7007 030656 004767 165532    6$:      JSR      PC,RXIE0      ;DISABLE INTERRUPTS.
7008 030662 006305          ASL      W5          ;MULTIPLY (RXTIMER VALUE + 1) BY 2.
7009 030664 020527 000400    CMP      R5,#256.    ;HAVE ALL VALUES BEEN TESTED ?
7010 030670 003621          BLE      2$          ;BRANCH AND TEST ANOTHER VALUE IF NOT.
7011
7012          ;*
7013          ; VERIFY THAT WHEN RXTIMER VALUE IS 0 THE INTERRUPT IS DELAYED INDEFINITELY.
7014          ; UNLESS THE PXFIFO IS 75% FULL OR MORE.
7015 030672 012767 013263 153152    MOV      #5811.,ERRNBR ;SET THE ERROR NUMBER TO 5811.
7016 030700 004767 164464    JSR      PC,PUFIFO    ;PURGE THE RXFIFO.
7017 030704 103102          BCC      50$          ;REPORT THE ERROR IF THE FIFO FAILED TO PURGE.
7018 030706 016701 000234    MOV      70$,R1      ;PASS THE LINE NUMBER.
7019 030712 012703 000277    MOV      #191.,R3    ;PASS THE NUMBER OF CHARS TO DMA.
7020 030716 005267 153130    INC      ERRNBR      ;SET THE ERROR NUMBER TO 5812.
7021 030722 004767 163374    JSR      PC,DMABUF    ;PERFORM THE DMA FROM ADDR #BUFBAS,THIS SUBR
7022          ; PRODUCES ERRORS >>>> 5812 THRU 5813 <<<<<.
7023 030726 103071          BCC      50$          ;REPORT THE ERROR IF ONE OCCURED.
7024 030730 012701 001750    MOV      #1750,R1    ;INDICATE TO TEST BIT0 WITH TIME OUT OF 1 SEC.
7025 030734 012702 002266    MOV      #RXINTC,R2  ;PASS THE ADDR OF THE WORD TO TEST.
7026 030740 005067 151322    CLR      RXINTC      ;CLEAR THE RX-INT COUNT.
7027 030744 105077 151256    CLRB     @CSRA        ;CLEAR THE IND.ADDR.REG BITS OF THE CSR READY.
7028          ; FOR THE WRITE TO THE RXTIMER REG.
7029 030750 105077 151254    CLRB     @RXTMA      ;SET THE VALUE 0 IN THE RXTIMER.
7030 030754 012704 000002    MOV      #2,R4       ;SET THE DELAY OF 2 MS.
7031 030760 004767 163276    JSR      PC,DELAY     ;DELAY TO ALLOW THE RXTIMER VALUE TO UPDATE.
7032 030764 004767 165464    JSR      PC,RXIE1     ;ENABLE RX-INTS.
7033 030770 004767 166442    JSR      PC,WAIBIS    ;WAIT FOR THE INTERRUPT TO OCCUR.
7034 030774 103007          BCC      8$          ;AVOID THE ERROR IF NO INTERRUPT.
7035
7036          ;*
7037          ; REPORT THE ERROR, RX-INT OCCURED WITH RXTIMER VALUE ZERO.>>>> 5814 <<<<<.
7038 030776 012701 007201    MOV      #EM5804,R1  ;PASS THE MESSAGE.
7039          ; "RXTIMER BAD, RX-INT OCCURED WITH RXTIMER
7040          ; VALUE ZERO".
7041
7042          ERDF      5814,EM5801,ER0503 ; REPORT ERROP 5814.
7043          TRAP     C#ERDF
7044          .WORD   5814
7045          .WORD   EM5801
7046          .WORD   ER0503
7047
7048          BR      60$          ;EXIT THE TEST.
7049          ;*
7050          ; VERIFY THAT WHEN THE FIFO IS 75% FULL THE INTERRUPT OCURS IMMEDIATELY.
7051          ;*
7052          ;*
7053          ;*
7054 031042 103023    8$:      JSR      PC,RXIE0      ;DISABLE RX-INTS.
7048 031014 004767 165374    MOV      #5815.,ERRNBR ;SET THE ERROR NUMBER TO 5815.
7049 031020 012767 013267 153024    MOV      70$,R1      ;PASS THE LINE NUMBER.
7050 031026 016701 000114    MOV      #1,R3       ;PASS THE NUMBER OF CHARS TO DMA.
7051 031032 012703 000001    JSR      PC,DMABUF    ;PERFORM THE DMA FROM ADDR #BUFBAS,THIS SUBR
7052 031036 004767 163260    ; PRODUCES ERRORS >>>> 5815 THRU 5816 <<<<<.
7053          ; REPORT THE ERROR IF ONE OCCURED.
7054          BCC      50$
    
```

```

7055 031044 005067 151216          CLR    RXINTC          ;CLEAR THE RX-INT COUNT.
7056 031050 012701 000005          MOV    #5,R1          ;SET THE TIME-OUT TO 5 MS.
7057 031054 012702 002266          MOV    #RXINIC,R2     ;PASS ADDR OF WORD TO TEST.
7058 031060 004767 165370          JSR    PC,RXIE1       ;ENABLE INTERRUPTS.
7059 031064 004767 166346          JSR    PC,WAIBIS      ;WAIT FOR THE INT TO OCCUR.
7060 031070 103412          BCS   60$             ;EXIT THE TEST IF AN INTERRUPT OCCURED.
7061
7062          ;*
7063          ; REPORT THE ERROR, RX-INT DID NOT OCCUR IMMEDIATLEY.>>>>> 5817 <<<<<.
7064 031072 005002          CLR    R2             ;PASS THE RXTIMER VALUE.
7065 031074 012701 007077          MOV    #EM5803,R1     ;PASS THE MESSAGE.
7066
7067 031100          ERRDF 5817,EM5801,ER5801 ; REPORT ERROR 5817.
      031100 104455
      031102 013271          TRAP  C$ERDF
      031104 006757          .WORD 5817
      031106 012112          .WORD EM5801
      .WORD ER5801
7068
7069 031110 000402          BR    60$             ;EXIT THE TEST.
7070
7071 031112 004767 165554          50$: JSR    PC,TSABRT   ;REPORT NON-RELATED TEST ERROR.
7072 031116 012700 000340          60$: SETPRI #PRI07     ;DISABLE ALL INTERRUPTS.
      031116 012700 000340
      031122 104441          MOV    #PRI07,R0
7073 031124 004767 165264          JSR    PC,RXIEO       ;DISABLE DEVICE RX-INTS.
7074 031130 016700 151060          CLRVEC RXVECA        ;CLEAR DOWN THE RX VECTOR.
      031130 016700 151060
      031134 104436          MOV    RXVECA,R0
7075 031136 005067 151106          CLR    CTRLCF        ;INDICATE THAT WE ARE NOT WITHIN A TEST.
7076 031142 104432          EXIT TST
      031142 104432
      031144 000004          TRAP  C$EXIT
7077 031146 000000          70$: .WORD 0          ;LOCAL STORAGE FOR LINE NUMBER USED IN THE TEST.
7078 031150          .WORD 0
      031150
      031150 104401          L10043: TRAP  C$ETST
    
```

```

7080 .SBTTL  HARDWARE TEST          - TXACTF -
7081 ;** *****
7082 ;*                               - TX ACTION FIFO TEST -
7083 ;*
7084 ;* THIS TEST VERIFIES THAT THE DUT'S TX-ACTION FIFO CAN CORRECTLY
7085 ;* HOLD 16 TX-ACTIONS.  ONE CHARACTER IS TRANSMITTED ON EACH LINE
7086 ;* USING DMA, THE TX-ACTIONS ARE THEN READ FROM THE FIFO, VERIFYING
7087 ;* THAT THEY ARE IN THE CORRECT ORDER AND THAT THERE ARE 16 OF THEM.
7088 ;* THE TEST ALSO VERIFIES THAT THE DUT WILL NOT SEND TX-INTS AFTER
7089 ;* THE TX ACTION FIFO HAS BEEN EMPTIED.
7090 ;* THIS TEST IS PERFORMED IN INTERNAL LOOPBACK ON ALL LINES.
7091 ;*
7092 ;*
7093 ;*
7094 031152          BGNTST
031152
7095
7096 031152          T15::
031152          SETPRI  #PRI05          ;ALLOW LTC INTERRUPTS.
031156          012700  000240
104441          MOV          #PRI05,R0
TRAP          C$SPRI
7097
7098          000017          TNUM == TNUM + 1          ;INCREMENT ASSEMBLY TIME TEST COUNTER
7099 031160          012767  000017  151066          MOV          #TNUM,TSTNUM          ;SET UP THE TEST NUMBER.
7100 031166          012767  177777  151054          MOV          #-1,CTRLCF          ;INDICATE THAT WE ARE IN A TEST.
7101 031174          012767  000001  152646          MOV          #1,ERRTYP          ;SET ERROR TYPE AS FATAL IN ERROR TABLE.
7102 031202          012767  013415  152642          MOV          #5901,ERRNBR          ;SET THE ERROR NUMBER TO 5901.
7103 031210          012767  007346  152636          MOV          #EM5901,ERRMSG          ;SET ERROR MESSAGE ADDRESS IN ERROR TABLE.
7104 031216          012767  012170  152632          MOV          #ER5901,ERRBLK          ;SET THE ERROR REPORTING ROUTINE.
7105
7106
7107 ;*
7108 ;* RESET THE DUT TO A KNOWN STATE, REMOVE ANY STATUS CODES IN THE FIFO.
7109 ;* CLEAR THE RX AND TX ENABLE BITS IN THE CSR.
7110 ;* THIS SUBROUTINE REPORTS ERROR >>>> 5901 <<<<<.
7111 031224          004767  162766          JSR          PC,CLNRST          ;RESET THE DHU-11 REPORT ANY ERRORS FOUND.
7112 031230          103402          BCS          .+6          ;SKIP EXIT OF TEST IF NO FATAL ERROR FOUND.
7113 031232          000167  000474          JMP          60$          ;EXIT THE TEST IF FATAL ERROR FOUND.
7114
7115
7116 ;*
7117 ;* SET INTERNAL LOOPBACK ON ALL LINES AND ENABLE RECIEVERS.  SET UP THE
7118 ;* LPR'S TO 38.4K BAUD, 8 BITS/CHARA, ODD PARITY, 2 STOP BITS.
7119 031236          012705  177777          MOV          #MAPLNS,R5          ;INDICATE TO SET UP ALL LINES.
7120 031242          012700  000204          MOV          #204,R0          ;PASS PARAMETER FOR INTERNAL LOOPBACK.
7121
7122 031246          004767  166300          JSR          PC,WTWLNCR          ;ENABLE RECIEVERS.
7123 031252          012700  177670          MOV          #177670,R0          ;INITIALISE THE LINE CONTROL REGS.
7124 031256          004767  166320          JSR          PC,WTWLPR          ;PASS THE LPR CONTENTS.
7125 031262          012704  000012          MOV          #10,R4          ;SET THE LPR'S TO 38.4K BAUD.
7126 031266          004767  162770          JSR          PC,DELAY          ;PASS DELAY TIME OF 10 MILLI SECS.
7127
7128
7129 ;*
7130 ;* INITIATE A DMA ON EACH LINE AND WAIT FOR ALL DMA'S TO COMPLETE.
7131 031272          005001          CLR          R1          ;WAIT FOR LNCTRL AND LPR REGS TO BE UPDATED.
7132 031274          012702  002650          MOV          #BUFBAS,R2          ;PASS THE FIRST LINE NUMBER.
7133 031300          012703  000001          MOV          #1,R3          ;PASS THE START OF THE DATA PATTERN TO TX.
;          ;PASS THE LENGTH OF THE DATA PATTERN.

```

```

7134 031304 012704 000005          MOV    #5,R4          ;PASS THE DELAY TIME OF 5 MILLI SECS.
7135 031310 005267 152536          INC    ERRNBR         ;SET THE ERROR NUMBER TO 5902.
7136 031314 004767 163060          JSR    PC,DODMA      ;TRANSMIT THE DATA PATTERN.
7137 031320 103402                   BCS    ,+6           ;CONTINUE IF SUCCESSFUL.
7138 031322 000167 000400          JMP    50$           ;ABORT THE TEST IF ERROR FOUND DURING DMA TX.
7139
7140          ;+
7141          ; WAIT FOR THE DMA TO COMPLEATE BEFORE INITIATING ANOTHER.
7142 031326 004767 162730          JSR    PC,DELAY      ;WAIT 5 MILLI SECS FOR THE DMA TO COMPLEATE.
7143 031332 005201                   INC    R1            ;INCREMENT THE LINE NUMBER.
7144 031334 022701 000020          CMP    #16.,R1      ;BRANCH TO INITIATE ANOTHER DMA IF
7145 031340 001365                   BNE   2$            ;NOT ALL LINES SERVED.
7146
7147          ;+
7148          ; READ THE TX-ACTIONS FROM THE TX_ACTION FIFO AND VERIFY THAT THEY OCCURED
7149          ; IN THE CORRECT ORDER.
7150 031342 005267 152504          INC    ERRNBR         ;SET THE ERROR NUMBER TO 5903.
7151 031346 012703 007402          MOV    #EM5902,R3   ;SET THE ERROR MESSAGE TO,
7152
7153 031352 005001                   CLR    R1            ; "TX-ACTION RECIEVED FROM THE WRONG LINE".
7154 031354 017702 150646          MOV    @CSRA,R2     ;CLEAR THE LINE NUMBER.
7155 031360 100150                   BPL   14$           ;READ THE CSR.
7156 031362 000302                   SWAB  R2            ;BRANCH TO REPORT ERROR >>5904<<, IF NO TX ACT.
7157 031364 042702 177760          BIC    #177760,R2   ;PUT THE TX LINE NUMBER IN THE LOW BYTE.
7158 031370 020201                   CMP    R2,R1        ;CLEAR THE CLUTTER FROM THE LINE NUMBER.
7159
7160 031372 001405                   BEQ   6$            ;COMPARE THE ACTUAL LINE NUMBER OF THE
7161 031374 031374 104460          ERROR                   ;TX-ACTION WITH THE EXPECTED NUMBER.
7162 031376 032767 000100 150604   BIT    @BIT06,OPTION ;SKIP THE ERROR REPORT IF CORRECT.
7163 031404 001552                   BEQ   60$           ;REPORT THE ERROR >>>>> 5903 <<<<<.
7164 031406 005201                   INC    R1            TRAP    C$ERROR
7165 031410 022701 000020          CMP    #16.,R1      ;EXIT IF EXTENDED ERROR REPORTING HAS NOT
7166 031414 001357                   BNE   4$            ;BEEN REQUESTED.
7167
7168          ;+
7169          ; 16 TX-ACTIONS HAVE BEEN READ, THE TX-ACTION BIT SHOULD NOW BE CLEAR.
7170          ; CHECK THAT IT IS CLEAR, IF IT ISN'T THEN COUNT THE NUMBER OF EXTRA
7171          ; TX-ACTIONS RECIEVED AND REPORT THE ERROR.
7172
7173 031416 005777 150604          TST   @CSRA         ;READ THE CSR.
7174 031422 100024                   BPL   10$           ;BRANCH IF THE TX-ACTION BIT IS CLEAR, TO
7175
7176 031424 012767 013421 152420   MOV    #5905.,ERRNBR ;TEST THE TX-INTERRUPTS.
7177 031432 012702 000021                   MOV    #17.,R2     ;SET THE ERROR NUMBER TO 5905.
7178 031436 005777 150564          TST   @CSRA         ;SET R2 TO BE THE NUMBER OF TX ACTIONS FOUND.
7179 031442 100123                   BPL   16$           ;READ THE CSR.
7180
7181 031444 005202                   INC    R2            ;BRANCH AND REPORT ERROR IF THE TX-ACTION FIFO,
7182 031446 022702 000145          CMP    #101.,R2    ;FINALLY CLEARED.
7183 031452 001371                   BNE   8$            ;INCREMENT THE NUMBER OF TX-ACTIONS FOUND.
7184
7185          ;+
7186          ; REPORT THE ERROR "TX-ACTION FIFO WOULD NOT EMPTY"
7187
7188 031454 005267 152372          INC    ERRNBR         ;SET THE ERROR NUMBER TO 5906.
7189 031460 012701 007570          MOV    #EM5904,R1   ;SET THE ERROR MESSAGE TO,
    
```



```

7190
7191 031464 012767 011762 152364      MOV    #EEROS03.ERRBLK ; "TX-ACTION FIFO WOULD NOT EMPTY"
7192 031472 000513                    BR     188              ;SET UP THE ERROR REPORTING ROUTINE.
7193                                     ;GO REPORT THE ERROR.
7194                                     ;
7195                                     ; NOW VERIFY THAT NO TX_INTS OCCUR AFTER THE TX_ACTION FIFO HAS BEEN EMPTIED.
7196                                     ; OF TX_ACTIONS, I.E. NO INTERRUPTS OCCUR WITH THE TX_ACTION BIT CLEAR.
7197                                     ;
7198 031474 005001      108:    CLR     R1              ;PASS THE NUMBER OF THE FIRST LINE
7199
7200                                     ;
7201                                     ; INITIATE A DMA ON ALL LINES AND WAIT FOR ALL DMA'S TO COMPLETE.
7202                                     ;
7203 031476 012767 013423 152346      MOV    #5907.,ERRNBR   ;SET THE ERROR NUMBER TO 5907.
7204 031504 012702 002650              MOV    #BUFBAS.R2     ;PASS THE START OF THE DMA PATTERN TO TX.
7205 031510 012703 000001              MOV    #1.R3          ;PASS THE LENGTH OF THE DATA PATTERN.
7206 031514 004767 162660      128:  JSR    PC,DODMA      ;TRANSMIT THE DATA PATTERNS.
7207 031520 103102                    BCC   508              ;ABORT THE TEST IF ERROR FOUND DURING DMA TX.
7208 031522 005201                    INC   R1              ;INCREMENT THE LINE NUMBER.
7209 031524 022701 000020              CMP   #16.,R1        ;BRANCH TO INITIATE ANOTHER DMA IF.
7210 031530 001371                    BNE  128              ;ALL LINES NOT SERVED.
7211 031532 012704 000144              MOV    #100.,R4      ;SET THE DELAY OF 100 MILLI SECS.
7212 031536 004767 162520              JSR   PC,DELAY       ;WAIT FOR THE DMA'S TO COMPLETE.
7213
7214                                     ;
7215                                     ; SET UP THE INTERRUPT SERVICE ROUTINE THAT WILL READ THE TX_ACTION FIFO
7216                                     ; UNTIL EMPTY AND CHECK FOR ANY SUBSEQUENT INTERRUPTS WITH NO TX_ACTION.
7217                                     ; ENABLE TX INTERRUPTS.
7218 031542 005067 150524              CLR   TXINTC          ;CLEAR THE TX INT COUNTER.
7219 031546 005067 150522              CLR   TXINTF          ;CLEAR THE TX INT FLAGS.
7220
7221                                     ;
7221 031552                    SETVEC TXVECA,#TXAINT,#PRI06
7222 031552 012746 000300              MOV    #PRI06,-(SP)
7223 031556 012746 017734              MOV    #TXAINT,-(SP)
7224 031562 016746 150430              MOV    TXVECA,-(SP)
7225 031566 012746 000003              MOV    #3,-(SP)
7226 031572 104437                    TRAP  C$VEC
7227 031574 062706 000010              ADD   #10,SP
7228 031600                    SETPRI #PRI04          ;ALLOW DEVICE INTERRUPTS.
7229 031600 012700 000200              MOV    #PRI04,R0
7230 031604 104441                    TRAP  C$PRI
7231 031606 004767 165444              JSR   PC,TXIE1       ;ENABLE TX INTERRUPTS.
7232
7233                                     ;
7234                                     ; WAIT FOR THE INTERRUPTS TO OCCUR
7235                                     ;
7236                                     ;
7237 031612 012704 000005              MOV    #5,R4          ;SET THE DELAY FOR 5 MILLI SECS.
7238 031616 004767 162440              JSR   PC,DELAY       ;DELAY FOR 5 MS.
7239
7240                                     ;
7241                                     ; DISABLE INTERRUPTS AND CLEAR DOWN THE INTERRUPT SERVICE ROUTINE.
7242                                     ;
7243 031622                    SETPRI #PRI07          ;DISABLE ALL INTERRUPTS.
7244 031622 012700 000340              MOV    #PRI07,R0
7245 031626 104441                    TRAP  C$PRI
7246 031630 004767 165362              JSR   PC,TXIE0       ;DISABLE DUT TX INTERRUPTS
7247 031634                    CLRVEC TXVECA          ;CLEAR THE TX INT VECTOR
7248 031634 016700 150356              MOV    TXVECA,R0
7249 031640 104436                    TRAP  C$VEC
    
```



```

7269 .SBTTL HARDWARE TEST - TXFIFO -
7270 ;* *****
7271 ;*
7272 ;* - TXFIFO TEST -
7273 ;* THIS TEST IS USED TO VERIFY THAT THE DUT'S TRANSMIT FIFO'S CAN HOLD
7274 ;* 64 CHARACTERS AND THAT ONLY ONE TX INTERRUPT OCCURS FOR ALL 64
7275 ;* CHARACTERS. THE TEST ALSO EXERCISES THE BYTE SWAPPER BY USING
7276 ;* ALTERNATE WORD AND BYTE WRITES TO THE TX FIFO, AS WELL AS CHECKING THAT
7277 ;* THE FIFOSIZE REGISTER REPORTS THE NUMBER OF CHARACTERS IN THE FIFO
7278 ;* CORRECTLY. ANY BMP CODES FOUND ARE SAVED ON THE QUE TO BE REPORTED
7279 ;* LATER.
7280 ;* THE TEST IS PERFORMED IN INTERNAL LOOPBACK ON ALL ACTIVE LINES.
7281 ;* *****
7282 031740 BGNTST
7283 031740 T16::
7284 031740 SETPRI #PRI05 ;ALLOW LTC INTERRUPTS.
7285 031744 012700 000240 ;
7286 031744 104441 ;
7287 031744 000020 ;
7288 031746 012767 000020 150300 TNUM == TNUM + 1 ;INCREMENT ASSEMBLY TIME TEST COUNTER
7289 031754 012767 177777 150266 MOV #TNUM,TSTNUM ;SET UP THE TEST NUMBER.
7290 031762 012767 000001 152060 MOV #-1,CTRLCF ;INDICATE THAT WE ARE IN A TEST.
7291 031770 012767 013561 152054 MOV #1,ERRTYP ;SET ERROR TYPE AS FATAL IN ERROR TABLE.
7292 031776 012767 007754 152050 MOV #6001,ERRNBR ;SET THE ERROR NUMBER TO 6001.
7293 032004 005067 150602 MOV #EM6001,ERRMSG ;SET ERROR MESSAGE ADDRESS IN ERROR TABLE.
7294 032010 005067 150236 CLR ERSMRF ;CLEAR THE ERROR SUMMARY FLAGS.
7295 032014 012700 002614 CLR EXOERR ;CLEAR THE "EXIT ON ERROR" FLAG.
7296 032020 004767 162214 MOV #ERCNTB,R0 ;SET UP THE START ADDRESS FOR THE BLCK.
7297 JSR PC,CLR16W ;CLEAR THE BLOCK OF 16 WORDS.
7298 ;*
7299 ;* RESET THE DUT TO A KNOWN STATE, REMOVE ANY STATUS CODES IN THE FIFO.
7300 ;* CLEAR THE RX AND TX ENABLE BITS IN THE CSR.
7301 ;* THIS SUBROUTINE REPORTS ERROR >>>> 6001 <<<<<.
7302 ;*
7303 JSR PC,CLRST ;RESET THE DMU-11 REPORT ANY ERRORS FOUND.
7304 BCS .+6 ;SKIP EXIT OF TEST IF NO FATAL ERROR FOUND.
7305 JMP 624 ;EXIT THE TEST IF FATAL ERROR FOUND.
7306 ;*
7307 ;* SET INTERNAL LOOPBACK ON ALL ACTIVE LINES AND ENABLE RECIEVERS. SET UP THE
7308 ;* LPR'S TO 38.4K BAUD, 8 BITS/CHARA, ODD PARITY, 2 STOP BITS. DISABLE
7309 ;* TRANSMITTERS ON ALL LINES.
7310 ;*
7311 MOV #MAPLNS,R5 ;INDICATE TO DISABLE ALL LINES.
7312 JSR PC,TXDSBL ;DISABLE TX ON ALL LINES.
7313 MOV ACTLNS,R5 ;INDICATE TO SET UP ACTIVE LINES ONLY.
7314 MOV #204,R0 ;PASS PARAMETER FOR INTERNAL LOOPBACK.
7315 JSR PC,WTWLNCR ;ENABLE RECIEVERS.
7316 MOV #177670,R0 ;INITIALISE THE LINE CONTROL REGS.
7317 JSR PC,WTWLPR ;PASS THE LPR CONTENTS.
7318 MOV #10,R4 ;SET THE LPR'S TO 38.4K BAUD.
7319 JSR PC,DELAY ;PASS DELAY TIME OF 10 MILLI SECS.
7320 ;*
7321 ;* SET UP THE TX INTERRUPT SERVICE ROUTINE AND VECTOR. THE ROUTINE COUNTS
7322 ;* THE NUMBER OF INTERRUPTS AND CHECKS FOR ANY INTERRUPTS OCCURING WITH
7323 ;* NO TX-ACTION.
    
```

```

7323 032102          SETVEC TXVECA,@TXAINT,@PRI06
      032102 012746 000300
      032106 012746 017734
      032112 016746 150100
      032116 012746 000003
      032122 104437
      032124 062706 000010
7324 032130 004767 165122
7325
7326
7327
7328
7329
7330
7331 032134 016705 150060
7332 032140 005001
7333
7334 032142 000241
7335 032144 006005
7336 032146 103067
7337 032150 110177 150052
7338 032154 010103
7339 032156 000303
7340
7341
7342
7343
7344 032160 01270C 000003
7345 032164 010377 150044
7346 032170 105203
7347 032172 110377 150036
7348 032176 062703 000401
7349 032202 005300
7350 032204 001367
7351 032206 005002
7352 032210 117702 150020
7353 032214 122702 000067
7354 032220 001425
7355
7356
7357
7358 032222 010104
7359 032224 012701 000067
7360 032230 010346
7361 032232 012767 013562 151612
7362 032240 012703 010000
7363
7364 032244 012767 012276 151604
7365 032252
      032252 104460
7366 032254 012603
7367 032256 010401
7368 032260 032767 000100 147722
7369 032266 001002
7370 032270 000167 000444
7371
7372

```

```

; SET THE TX INT ENASLE BIT IN THE CSR.
JSR PC,TXIE1
; WRITE 64 CHARACTERS TO ALL TXFIFO'S USING ALTERNATE WORD/BYTE WRITES
; TO EXERSISE THE BYTE SWAPPER. AFTER THE FIRST 9 CHARACTERS HAVE BEEN
; WRITTEN CHECK THAT THE FIFOSIZE REGISTER SHOWS THE CORRECT NUMBER OF
; FREE BYTES IN THE FIFO.
;
; SET UP THE ACTIVE LINE BIT MAP.
MOV ACTLNS,R5
CLR R1
; SET UP THE FIRST LINE NUMBER.
;
; CLEAR THE CARRY BIT READY FOR THE ROTATION.
; ROTATE THE ACTIVE LINE BIT MAP INTO THE CARRY.
; AVOID TESTING THIS LINE IF ITS INACTIVE.
; LOAD THE LINE NUMBER OF THE UUT INTO THE CSR.
; INITIALISE THE DATA PATTERN FOR THIS LINE BY
; PUTTING THE LINE NUMBER IN THE HIBYTE AND
; CLEARING THE LOBYTE.
2: CLC
ROR R5
BCC 10$
MOV R1,@CSRA
MOV R1,R3
SWAB R3
;
; LOAD 9 CHARACTERS INTO THE TXFIFO AND CHECK THE FIFOSIZE REGISTER.
;
; LOOP COUNT.
4$: MOV #3,R0
MOV R3,@FDATA
INCB R3
MOV R3,@FDATA
ADJ #401,R3
DEC R0
BNE 4$
CLR R2
MOV R3,@FSLSA,P2
CMPB #55.,R2
BEQ 6$
; MOVE A WORD OF DATA INTO THE FIFO.
; INCREMENT THE LOBYTE OF THE DATA PATTERN.
; MOVE A BYTE OF DATA INTO THE FIFO.
; INCREMENT THE HIGH AND LOW BYTE OF THE DATA.
; DECREMENT THE LOOP COUNT.
; BRANCH IF NOT ALL 9 CHARACTERS WRITTEN.
; CLEAR THE UPPER AND LOWER BYTE OF R2.
; READ THE FIFOSIZE REGISTER.
; COMPARE THE EXPECTED SIZE WITH THE ACTUAL.
; AVOID THE ERROR REPORT IF THE SIZE IS CORRECT.
; REPORT THE ERROR. INCORRECT VALUE. >>>> 6002 <<<<<.
;
; PASS THE LINE NUMBER TO THE ERROR ROUTINE.
; PASS THE EXPECTED FIFO SIZE.
; SAVE THE DATA PATTERN.
; SET THE ERROR NUMBER TO 6002.
; PASS THE MESSAGE.
; "INCORRECT VALUE IN FIFOSIZE REGISTER".
; SET THE ERROR REPORTING ROUTINE.
MOV R1,R4
MOV #55.,R1
MOV R3,-(SP)
MOV #6002.,ERRNBR
MOV #EM6002,R3
;
; RESTORE THE PATTERN.
; RESTORE THE LINE NUMBER.
; HAS EXTENDED ERROR REPORTING BEEN REQUESTED ?
; CONTINUE IF IT HAS.
; EXIT THE TEST IF IT HASN'T.
MOV (SP),P3
MOV R4,R1
BIT #BIT06,OPTION
BNE 6$
JMP 60$
;
; CONTINUE FILLING UP THE FIFO UNTIL 64 CHARACTERS HAVE BEEN LOADED.

```

```

7373
7374 032274 012700 000022
7375 032300 010377 147730
7376 032304 105203
7377 032306 110377 147722
7378 032312 062703 000401
7379 032316 005300
7380 032320 001367
7381 032322 110377 147706
7382
7383
7384
7385 032326 005705
7386 032330 001402
7387 032332 005201
7388 032334 000702
7389
7390
7391
7392
7393
7394
7395 032336 016705 147656
7396 032342 005001
7397
7398 032344 000241
7399 032346 006005
7400 032350 103157
7401 032352 110177 147650
7402 032356 010103
7403 032360 000303
7404 032362 012767 013563 151462
7405 032370 004767 162774
7406 032374 103151
7407 032376 005067 147670
7408 032402 005067 147666
7409 032406 052777 100000 147626
7410 032414
    032414 012700 000200
    032420 104441
7411 032422 012704 000144
7412 032426 004767 161630
7413 032432
    032432 012700 000240
    032436 104441
7414 032440 042777 100000 147574
7415
7416
7417
7418
7419 032446 005267 151400
7420 032452 005767 147614
7421 032456 001520
7422 032460 005267 151366
7423 032464 005767 147604
7424 032470 100513
7425 032472 022767 000001 147572
    
```

```

;-
6$:  MOV #18.,R0 ;SET UP THE OUTER LOOP.
8$:  MOV R3,@FDATA ;MOVE A WORD OF DATA INTO THE FIFO.
    INCB R3 ;INCREMENT THE LOBYTE OF THE DATA PATTERN.
    MOVB R3,@FDATA ;MOVE A BYTE OF DATA INTO THE FIFO.
    ADD #401,R3 ;INCREMENT THE HIGH AND LOW BYTE OF THE DATA.
    DEC R0 ;DECREMENT THE LOOP COUNT.
    BNE 8$ ;BRANCH IF NOT ALL 54 CHARACTERS WRITTEN.
    MOVB R3,@FDATA ;LOAD THE LAST CHARACTER.

; LOOP UNTIL THE TXFIFO'S ON ALL ACTIVE LINES HAVE BEEN FILLED.
;-
10$: TST R5 ;HAVE ALL FIFOS BEEN FILLED.
    BEQ 12$ ;YES, THEN GO AND TRANSMIT THE CHARACTERS.
    INC R1 ;OTHERWISE SELECT THE NEXT LINE.
    BR 2$ ;AND BRANCH TO TEST IF ITS ACTIVE.

; ENABLE TRANSMISSION ON EACH LINE IN TURN AND WAIT FOR 100 MS TO ALLOW
; ANY INTERRUPTS TO OCCUR BEFORE DISABLING TRANSMISSION. VERIFY THAT ONLY
; INTERRUPT OCCURED AND CHECK THAT THE CHARACTERS WERE TRANSMITTED UNCORRUPTED
; AND ON THE CORRECT LINE.
;-
12$: MOV ACTLNS,R5 ;SET UP THE ACTIVE LINE BIT MAP.
    CLR R1 ;SET UP THE FIRST LINE NUMBER.

14$: CLC ;CLEAR THE CARRY BIT READY FOR THE ROTATION.
    ROR R5 ;ROTATE THE ACTIVE LINE BIT MAP INTO THE CARRY.
    BCC 24$ ;AVOID TESTING THIS LINE IF ITS INACTIVE.
    MOVB R1,@CSRA ;LOAD THE LINE NUMBER OF THE UUT INTO THE CSR.
    MOV R1,R3 ;INITIALISE THE "EXPECTED" DATA PATTERN FOR
    SWAB R3 ;THIS LINE.
    MOV #6003.,ERRNBR ;SET THE ERROR NUMBER TO 6003.
    JSR PC,PUFIFO ;PURGE THE RXFIFO.
    BCC 50$ ;REPORT THE ERROR IF THE FIFO WOULD NOT PURGE.
    CLR TXINTC ;CLEAR THE INTERRUPT COUNT.
    CLR TXINTF ;CLEAR THE INTERRUPT FLAGS.
    BIS #BIT15,@TXAD2A ;ENABLE TRANSMISSION ON THIS LINE.
    SETPRI #PRI04 ;ALLOW DEVICE INTERRUPTS.
                                     MOV #PRI04,R0
                                     TRAP C$SPRI

    MOV #100.,R4 ;SET THE DELAY.
    JSR PC,DELAY ;DELAY FOR 100 MILLI SECS.
    SETPRI #PRI05

    BIC #BIT15,@TXAD2A ;DISABLE TRANSMISSION ON THIS LINE.
                                     MOV #PRI05,R0
                                     TRAP C$SPRI

; VERIFY THAT ONLY ONE INTERRUPT OCCURED AND THAT IT WAS ACCOMPANIED BY
; A CORRESPONDING TX-ACTION.
;-
    INC ERRNBR ;SET THE ERROR NUMBER TO 6004.
    TST TXINTC ;HAS AN INTERRUPT OCCURED ?
    BEQ 50$ ;REPORT THE ERROR IF NO INTERRUPT OCCURED.
    INC ERRNBR ;SET THE ERROR NUMBER TO 6005.
    TST TXINTF ;HAS AN INTERRUPT OCCURED WITHOUT A TX-ACTION ?
    BMI 50$ ;REPORT THE ERROR IF IT HAS.
    CMP #1,TXINTC ;DID ONLY ONE INT OCCUR ?
    
```

```

7426 032500 001424          BEQ      16$          ;AVOID THE ERROR IF ONLY ONE INTERRUPT.
7427                                     ;*
7428                                     ; REPORT THE ERROR, MORE THAN ONE INTERRUPT. >>>> 6006 <<<<<
7429                                     ;
7430 032502 016702 147564      MOV      TXINTC,R2      ;PASS THE ACTUAL NUMBER OF INTERRUPTS.
7431 032506 010104          MOV      R1,R4         ;PASS THE LINE NUMBER.
7432 032510 012701 000001      MOV      #1,R1        ;PASS THE EXPECTED NUMBER OF INTS.
7433 032514 010346          MOV      R3,-(SP)      ;SAVE THE DATA PATTERN.
7434 032516 012703 010040      MOV      #EM6003,R3   ;PASS THE MESSAGE,
7435                                     ; "MORE THAN ONE TX-INT OCCURED FROM A FULL
7436                                     ; TX FIFO".
7437 032522 005267 151324      INC      ERRNBR        ;SET THE ERROR NUMBER TO 6006.
7438 032526 012767 012276 151322  MOV      #ER6001,ERRBLK ;SET UP THE ERROR BLOCK.
7439 032534          ERROR
      032534 104460
7440 032536 012603          MOV      (SP)+,R3      ;RESTORE THE DATA PATTERN. TRAP C$ERROR
7441 032540 010401          MOV      R4,R1        ;RESTORE THE LINE NUMBER.
7442 032542 032767 000100 147440  BIT      #BIT06,OPTION ;HAS EXTENDED ERROR REPORTING BEEN REQUESTED ?
7443 032550 001473          BEQ      60$          ;EXIT THE TEST IF IT HAS.
7444
7445
7446
7447                                     ;*
7448                                     ; READ THE CHARACTERS FROM THE RXFIFO AND VERIFY THEY ARE CORRECT AND WERE
7449                                     ; RECIEVED ON THE CORRECT LINE.
7450                                     ; THIS SUBROUTINE REPORTS ERRORS. >>>> 6007 THRU 6008 <<<<<.
7451 032552 012767 013567 151272 16$:  MOV      #6007.,ERRNBR ;SET UP THE ERROR NUMBER TO 6007.
7452 032560 005000          CLR      R0           ;INITIALISE THE NUMBER OF CHARS READ COUNT.
7453 032562 012704 000025      MOV      #21.,R4     ;SET UP THE OUTER LOOP COUNT.
7454 032566 012702 000003      MOV      #3,R2       ;SET UP THE INNER LOOP COUNT.
7455 032572 004767 163140      JSR      PC,REPDER   ;READ A CHARACTER FROM THE RXFIFO, VERIFY THAT
7456                                     ; IT IS CORRECT AND CAME FROM THE UUT. REPORT
7457                                     ; ANY ERRORS. >>>> 6007 THRU 6008 <<<<<.
7458 032576 103022          BCC      22$          ;BRANCH TO REPORT THE ERROR IF THE FIFO EMPTY.
7459 032600 005767 147446      TST      EXOERR      ;TEST THE "EXIT ON ERROR" FLAG.
7460 032604 001055          BNE      60$          ;EXIT THE TEST IF SET, I.E. AN ERROR OCCURED,
7461                                     ; AND NO EXTENDED ERROR REPORTING WAS REQUESTED.
7462 032606 005200          INC      R0           ;INCREMENT THE READ CHAR COUNT.
7463 032610 105203          INCB    R3           ;INCREMENT THE LOBYTE OF THE DATA PATTERN.
7464 032612 000303          SWAB   R3           ;SWAP BYTES TO PLACE EXPECTED CHAR IN LOBYTE.
7465 032614 005302          DEC      R2         ;DECREMENT THE INNER LOOP COUNTER.
7466 032616 001365          BNE      20$          ;BRANCH TO READ ANOTHER CHAR IF 3 CHARS HAVE
7467                                     ; NOT BEEN READ.
7468 032620 000303          SWAB   R3           ;RESTORE THE DATA BYTES TO THE CORRECT POSITION
7469 032622 005304          DEC      R4         ;DECREMENT THE OUTER LOOP COUNTER.
7470 032624 001360          BNE      18$          ;BRANCH TO READ ANOTHER 3 CHARACTERS IF NOT
7471                                     ; ALL 63 HAVE BEEN READ.
7472 032626 004767 163104      JSR      PC,REPDER   ;READ AND CHECK THE LAST CHARACTER.
7473 032632 103004          BCC      22$          ;BRANCH TO REPORT THE ERROR IF THE FIFO EMPTY.
7474 032634 005767 147412      TST      EXOERR      ;TEST THE "EXIT ON ERROR" FLAG.
7475 032640 001037          BNE      60$          ;EXIT THE TEST IF SET.
7476 032642 000422          BR      24$          ;OTHERWISE GO AND TEST ANOTHER LINE.
7477
7478                                     ;*
7479                                     ; REPORT THE ERROR, NOT ALL CHARACTERS TRANSMITTED. >>>> 6009 <<<<<.
7480 032644 012767 013571 151200 22$:  MOV      #6009.,ERRNBR ;SET THE ERROR NUMBER TO 6009.
7481 032652 012703 010243      MOV      #EM6006,R3   ;PASS THE MESSAGE,
    
```


7511
 7512
 7513
 7514
 7515
 7516
 7517
 7518
 7519
 7520
 7521
 7522 032766
 032766
 7523
 7524 032766 012767 177777 147254
 7525 000021
 7526 032774 012767 000021 147252
 7527 033002 012767 000001 151040
 7528 033010 012767 014401 151034
 7529 033016 012767 010307 151030
 7530
 7531
 7532
 7533
 7534
 7535 033024 004767 161166
 7536 033030 103165
 7537
 7538
 7539
 7540
 7541
 7542 033032 012705 177777
 7543 033036 012700 000200
 7544 033042 004767 164504
 7545 033046 012704 000012
 7546 033052 004767 161204
 7547
 7548
 7549
 7550
 7551 033056 012700 156430
 7552 033062 004767 164514
 7553
 7554
 7555
 7556 033066 016705 147126
 7557 033072 004767 164024
 7558
 7559
 7560
 7561
 7562 033076 005267 150750
 7563 033102 004767 162344
 7564 033106 103136
 7565
 7566

```

.SBTTL  HARDWARE TEST          - BREAKB -
;*****
;*          - BREAK GENERATION TEST -
;* THIS TEST VERIFIES THAT ALL SERIAL TRANSMIT LINES CAN GENERATE A BREAK
;* BY SETTING THE BRK BIT IN THE ASSOCIATED LNCRTL REGISTER.
;* USE OF THE INTERNAL LOOPBACK FEATURE OF THE QUARTS IS MADE TO MINIMISE
;* ANY EXTERNAL EFFECTS CAUSED ON THE SERIAL LINES BY THIS TEST.
;* FRAMING ERROR DETECTION IS USED TO INDICATE THE PRESENCE OF A BREAK.
;* BY SETTING THE APPROPRIATE BIT IN THE RBUF REGISTER.
;*****
                                BGNTST
                                T17::
                                MOV     #-1,CTRLCF      ;INDICATE THAT WE ARE IN A TEST.
                                TNUM  == TNUM + 1      ;INCREMENT THE ASSEMBLY TIME TEST COUNTER.
                                MOV     #TNUM,TSTNUM     ;SET UP THE TEST NUMBER. (64)
                                MOV     #1,ERR'YP      ;SET ERROR TYPE AS FATAL IN ERROR TABLE.
                                MOV     #6401,ERRNBR    ;SET THE FIRST ERPOR NUMBER IN ERROR TABLE.
                                MOV     #EM6401,ERRMSG  ;SET ERROR MESSAGE ADDRESS IN ERRTBL.
;*
;* RESET THE DUT TO A KNOWN STATE, REMOVE THE STATUS CODES FROM THE FIFO.
;* CLEAR TX AND RX INTERRUPT ENABLE BITS IN THE CSR.
;* THIS SUBROUTINE REPORTS ERROR >>>> 6401 <<<<<.
;*****
                                JSR     PC,CLNRST      ;RESET THE DHU-11, REPORT ANY ERRORS FOUND.
                                BCC     60$           ;EXIT TEST IF FATAL ERROR FOUND.
;*
;* SET UP DEVICE UNDER TEST (DUT) TO:
;* DISABLE TRANSMISSION AND RECEPTION INTERRUPTS.
;* DELAY FOR 10 MILLI-SECONDS TO ALLOW TIME TO CLEAR ANY BREAKS.
;*****
                                MOV     #MAPLNS,R5     ;PASS ACTIVE LINE BIT MAP.
                                MOV     #200,R0        ;PASS INTERNAL LOOPBACK MODE.
                                JSR     PC,WTWLNLC     ;SELECT INTERNAL LOOPBACK,DISABLE DMA.
                                MOV     #10.,R4       ;PASS DELAY TIME OF 10 MILLI SECONDS.
                                JSR     PC,DELAY       ;DELAY TO ALLOW ANY BREAKS TO BE CLEARED.
;*
;* SET UP TRANSMISSION AN RECEPTION PARAMETERS FOR ALL LINES.
;* 9600 BAUD,8 CHAR,1 STOPBIT,NO PARITY.
;*****
                                MOV     #156430,R0    ;SET UP BAUD RATE,ETC.
                                JSR     PC,WTWLPRLR    ;SET COMMUNICATION PARAMETERS ON ALL LINES.
;*
;* ENABLE TRANSMITTERS ON ALL ACTIVE LINES.
;*****
                                MOV     ACTLNS,R5     ;PASS ACTIVE LINE BIT MAP.
                                JSR     PC,TXENBL     ;ENABLE TRANSMISSIONS ON ALL LINES.
;*
;* PURGE THE FIFO OF ANY UNWANTED CHARACTERS.
;* THIS ROUTINE REPORTS ERRORS WITH NUMBERS >>>> 6402 THRU 6404 <<<<<.
;*****
                                INC     ERRNBR        ;SET ERROR NUMBER TO 6402.
                                JSR     PC,PUFIFR     ;PURGE FIFO.
                                BCC     60$           ;ABORT TEST IF FIFO WILL NOT CLEAR.
;*
;* VERIFY BREAK GENERATION ON INDIVIDUAL LINES.
    
```



```

7567 ; CLEAR BREAKS ON ALL LINES.
7568 ; DELAY FOR 10 MILLI-SECONDS TO ALLOW TIME FOR ANY BREAKS TO BE CLEARED.
7569 ; SELECT LINE,SET BREAK BIT IN LNCTRL REGISTER.
7570 ; TEST FOR A CHARACTER IN THE FIFO WITH FRAME ERROR.
7571 ;
7572 033110 005002 2$: CLR R2 ;CLEAR LINE COUNTER.
7573 033112 012703 000001 MOV #1,R3 ;SET UP ACTIVE LINE BIT MASK.
7574 033116 030367 147076 4$: BIT R3,ACTLNS ;CHECK IF THIS LINE IS ACTIVE.
7575 033122 001440 BEQ 8$ ;GO SELECT NEXT LINE IF THIS ONE IS INACTIVE.
7576 033124 012700 000200 MOV #200,R0 ;SET UP PARAMETER TO CLEAR BREAK BITS.
7577 033130 004767 164416 JSR PC,WTWLN ;CLEAR BREAK BIT,RESELECT INTERNAL LOOPBACK.
7578 033134 012704 000012 MOV #10.,R4 ;PASS DELAY TIME OF 10 MILLI SECONDS.
7579 033140 004767 161116 JSR PC,DELAY ;DELAY TO ALLOW BREAKS TO BE CLEARED.
7580 ;
7581 ;*
7582 ; SET BREAK BIT ON SELECTED LINE.
7583 ; SET UP PARAMETERS TO TEST FOR THE FRAME ERROR BIT SET IN RBUF.
7584 ; TIME-OUT = 5 MILLI SECONDS.
7585 ; CALL ROUTINE TO CHECK FOR CONDITION FOUND.
7586 033144 010305 6$: MOV R3,R5 ;COPY ACTIVE LINE BIT MASK.
7587 033146 012700 000214 MOV #214,R0 ;SET BREAK,RESELECT LOOPBACK,ENABLE RECEPTION.
7588 033152 004767 164374 JSR PC,WTWLN ;SET BREAK ON SELECTED LINE.
7589 ;*
7590 ; DELAY FOR 5 MS TO ALLOW TIME FOR BREAK TO BE GENERATED AND RECEIVED.
7591 ; VERIFY RECEPTION OF A CHARACTER WITH FRAME ERROR BIT SET.
7592 ;
7593 033156 012704 000005 MOV #5.,R4 ;SET DELAY VALUE TO 5 MILLI SECS.
7594 033162 004767 161074 JSR PC,DELAY ;ALLOW TIME FOR CHARACTER RECEPTION.
7595 033166 017700 147036 MOV @RBUFA,R0 ;GET CHARACTER FROM RBUF REGISTER.
7596 033172 032700 020000 BIT #BIT13,R0 ;CHECK FOR FRAME ERROR BIT.
7597 033176 001012 BNE 8$ ;SKIP ERROR REPORT IF SET.
7598 033200 012701 010344 MOV #EM6402,R1 ;SELECT MESSAGE TO BE PRINTED.
7599 ;REPORT ERROR"BREAK NOT RECEIVED ON LINE #NN"
7600 033204 ERRDF 6405,EM6401,ER6401 ; >>>>> ERROR #6405 <<<<<.
033204 104455 TRAP C$ERDF
033206 014405 .WORD 6405
033210 010307 .WORD EM6401
033212 012400 .WORD ER6401
7601 ;*
7602 ; EXIT THE TEST IF EXTENDED ERROR REPORTING HAS NOT BEEN ENABLED
7603 ;
7604 ;
7605 033214 032767 000100 146766 BIT #BIT06,OPTION ;EXIT WITH TEST FAILURE MESSAGE IF
7606 033222 001470 BEQ 60$ ;NO EXTENDED ERROR REPORTING HAS BEEN REQUESTED
7607 ; DURING THE SOFTWARE QUESTIONS.
7608 ;
7609 033224 006303 8$: ASL R3 ;SHIFT BIT MASK FOR NEXT LINE.
7610 033226 005202 INC R2 ;NEXT LINE
7611 033230 020227 000020 CMP R2,#NUMLNS ;CHECK FOR MAX LINE COUNT.
7612 033234 001330 BNE 4$ ;IF <>,LOOP TO CHECK NEXT LINE
7613 ;*
7614 ; VERIFY BREAK GENERATION ON ALL LINES SIMULTANEOUSLY.
7615 ; CLEAR BREAKS ON ALL LINES.
7616 ; DELAY FOR 10 MILLI-SECONDS TO ALLOW TIME FOR ANY BREAKS TO BE CLEARED.
7617 ; PURGE THE FIFO.
7618 ; SET BREAK BIT IN LNCTRL REGISTERS ON ALL ACTIVE LINES.
7619 ; TEST FOR CHARACTERS IN THE FIFO WITH FRAME ERROR.
    
```



```

7667 .SBTTL HARDWARE TEST
7668 :***** NORERR -
7669 :*****
7670 :* - NO OVERRUN ERROR TEST -
7671 :*
7672 :* THIS TEST VERIFIES THAT THE DUT WILL NOT REPORT DATA OVERRUN
7673 :* ERRORS WHEN THEY DO NOT OCCUR.
7674 :* THIS TEST PUTS 256 CHARACTERS IN THE DUT FIFO PLUS 4 IN EACH ACTIVE
7675 :* UART AND VERIFIES THAT NO OVERRUN ERRORS ARE REPORTED.
7676 :* ANY BMP CODE FOUND WILL INVALIDATE THE TEST AND CAUSE IT TO BE ABORTED.
7677 :* HOWEVER THE BMP CODE WILL BE PLACED ON THE BMP CODE QUEUE, TO BE
7678 :* REPORTED LATER.
7679 :*
7680 :*****
7681 BGNTST
7682 033412 SETPRI #PRIOS ;ALLOW LTC INTERRUPTS. T18::
7683 033412 012700 000240
7684 033416 104441
7685 000022
7686 033420 012767 000022 146626 TNUM == TNUM + 1 ;INCREMENT THE ASSEMBLY TIME TEST COUNTER.
7687 033426 012767 177777 146614 MOV #TNUM,TSTNUM ;SET UP THE TEST NUMBER. (66)
7688 033434 012767 000001 150406 MOV #-1,CTRLCF ;INDICATE THAT WE ARE IN A TEST.
7689 033442 012767 014711 150402 MOV #1,ERRTYP ;SET ERROR TYPE AS FATAL IN ERROR TABLE.
7690 033450 012767 010405 150376 MOV #6601,ERRNBR ;SET ERROR NUMBER TO 6601.
7691 MOV #EM6601,ERRMSG ;SET ERROR MESSAGE ADDRESS IN ERROR TABLE.
7692 :*
7693 :* RESET THE DUT TO A KNOWN STATE, REMOVE THE STATUS CODES FROM THE FIFO.
7694 :* CLEAR TX AND RX INTERRUPT ENABLE BITS IN THE CSR.
7695 :* THIS SUBROUTINE REPORTS ERROR >>>> 6601 <<<<.
7696 :*
7697 JSR PC,CLRST ;RESET THE DHU-11, REPORT ANY ERRORS FOUND.
7698 BCS .+6 ;SKIP EXIT OF TEST IF NO FATAL ERROR FOUND.
7699 JMP 60$ ;EXIT THE TEST, FATAL ERROR WAS FOUND.
7700 :*
7701 :* FIND AN ACTIVE LINE ON WHICH TO PERFORM THE TEST.
7702 :* INITIALIZE THE 256 BYTE DATA PATTERN.
7703 :*
7704 JSR PC,FINACT ;FIND AN ACTIVE LINE.
7705 BCS .+6 ;SKIP EXIT OF TEST IF NO FATAL ERROR FOUND.
7706 JMP 60$ ;EXIT THE TEST, FATAL ERROR WAS FOUND.
7707 JSR PC,INDATP ;INITIALISE DATA PATTERN.
7708 :*
7709 :* TRANSMIT A 265 CHARACTER DATA PATTERN USING DMA, ON A SINGLE CHANNEL
7710 :* AT 38.4K BAUD, 8 BITS PER CHARACTER, ODD PARITY, 2 STOP BITS.
7711 :*
7712 :* SET INTERNAL LOOPBACK ON THE SELECTED LINE.
7713 :* TRANSMIT THE DATA PATTERN ON THE FIRST AVAILABLE ACTIVE LINE.
7714 :*
7715 INC ERRNBR ;SET THE ERROR REPORT NUMBER TO 6602.
7716 MOV #204,R0 ;PASS PARAMETER FOR INTERNAL LOPBCK,ENABLE RX.
7717 JSR PC,WTWLNLC ;INITILAISE THE LINE CONTROL REGISTER.
7718 MOV #177670,R0 ;PASS THE LPR CONTENTS.
7719 JSR PC,WTWLPR ;SET THE LPR CONTENTS TO 38.4K BAUD.
7720 MOV #10,R4 ;PASS DELAY TIME OF 10 MILLI SECONDS.
7721 JSR PC,DELAY ;WAIT FOR LNCTRL AND LPR REGS TO BE UPDATED.
7722 MOV #BUFBAS,R2 ;PASS THE START OF THE DATA PATTERN TO TX.
    
```

```

7721 033546 012703 000400      MOV      #BUF MID BUFBAS,R3 ;PASS THE LENGTH OF THE DATA PATTERN.
7722 033552 004767 160622      JSR      PC,DODMA          ;TRANSMIT THE DATA PATTERN.
7723 033556 103157              BCC      50$              ;EXIT IF ERROR FOUND DURING DMA TX.
7724
7725
7726
7727
7728 033560 005267 150266      ;+
7729 033564 012701 170536      ; WAIT FOR DMA TO COMPLETE. THEN WAIT FOR THE LAST CHARACTER TO ARRIVE IN
7730 033570 016702 146432      ; THE FIFO.
7731 033574 004767 163636      ;-
7732 033600 103146              INC      ERRNBR          ;SET ERROR NUMBER TO 6603.
7733 033602 012704 000005      MOV      #170536,R1      ;PASS TIME-OUT VALUE OF 350 MILLI SECS.
7734 033606 004767 160450      MOV      CSRA,R2         ;PASS THE ADDRESS OF THE CSR.
7735
7736
7737
7738
7739 033612 016705 146402      JSR      PC,WAIBIS        ;WAIT FOR DMA TO COMPLETE, TX_ACTION SET.
7740 033616 012700 000204      BCC      50$             ;ABORT THE TEST IF TIME-OUT ON DMA COMPLETION.
7741 033622 004767 163724      MOV      #5,R4           ;PASS DELAY OF 5 MILLI SECS.
7742 033626 012700 177670      JSR      PC,DELAY         ;WAIT FOR LAST CHAR TO ARRIVE IN THE FIFO.
7743 033632 004767 163744
7744 033636 012704 000012
7745 033642 004767 160414
7746
7747 033646 012702 002650      ;+
7748 033652 012703 000004      ; TRANSMIT 4 CHARACTERS ON EACH ACTIVE LINE.
7749 033656 005001
7750 033660 005267 150166      ;-
7751 033664 010100
7752 033666 006300
7753 033670 036067 002336 146322      MOV      ACTLNS,R5       ;ALTER PARAMETERS FOR ALL ACTIVE LINES.
7754 033676 001403              MOV      #204,R0         ;PASS PARAMETER FOR INTERNAL LOPBCK,ENABLE RX.
7755 033700 004767 160474      JSR      PC,WTWLNCR      ;INITIALISE THE LINE CONTROL REGISTER.
7756 033704 103104              MOV      #177670,R0      ;PASS THE LPR CONTENTS.
7757 033706 005201              JSR      PC,WTWLPR       ;SET THE LPR CONTENTS TO 38.4K BAUD.
7758 033710 020127 000020      MOV      #10.,R4        ;PASS DELAY TIME OF 10 MILLI SECONDS.
7759 033714 002763              JSR      PC,DELAY        ;WAIT FOR LNCTRL AND LPR REGS TO BE UPDATED.
7760
7761 033716 005267 150130      MOV      #BUFBAS,R2      ;PASS THE START OF THE DATA PATTERN TO TX.
7762 033722 012701 170040      MOV      #4,R3           ;PASS THE LENGTH OF THE DATA PATTERN.
7763 033726 016702 146274      CLR      R1              ;CLEAR THE LINE COUNTER.
7764 033732 004767 163500      INC      ERRNBR          ;SET ERROR NUMBER TO 6604.
7765 033736 103067              2$: MOV      R1,R0
7766 033740 012704 000005      ASL      R0              ;CALCULATE THE LINE OFFSET FROM THE LINE #.
7767 033744 004767 160312      BIT      BITTBL(R0),ACTLNS ;TEST FOR THIS LINE BEING ACTIVE.
7768
7769
7770
7771
7772 033750 016702 146244      BEQ      4$              ;SKIP THE TX ON THIS LINE IF IT IS NOT ACTIVE.
7773 033754 004767 160716      JSR      PC,DODMA        ;TRANSMIT THE 5 CHAR DATA PATTERN.
7774 033760 006302              BCC      50$             ;ABORT IF ERROR FOUND DURING DMA TX.
7775 033762 006302              4$: INC      R1           ;INCREMENT THE LINE COUNTER.
7776 033764 012705 000400      CMP      R1,#NUMLNS      ;TEST FOR ALL POSSIBLE LINES HANDLED
7777 033770 060205              BLT      2$              ;LOOP IF NOT ALL LINES HANDLED.
7778
7779
7800
7801
7802
7803
7804
7805
7806
7807
7808
7809
7810
7811
7812
7813
7814
7815
7816
7817
7818
7819
7820
7821
7822
7823
7824
7825
7826
7827
7828
7829
7830
7831
7832
7833
7834
7835
7836
7837
7838
7839
7840
7841
7842
7843
7844
7845
7846
7847
7848
7849
7850
7851
7852
7853
7854
7855
7856
7857
7858
7859
7860
7861
7862
7863
7864
7865
7866
7867
7868
7869
7870
7871
7872
7873
7874
7875
7876
7877
7878
7879
7880
7881
7882
7883
7884
7885
7886
7887
7888
7889
7890
7891
7892
7893
7894
7895
7896
7897
7898
7899
7900
7901
7902
7903
7904
7905
7906
7907
7908
7909
7910
7911
7912
7913
7914
7915
7916
7917
7918
7919
7920
7921
7922
7923
7924
7925
7926
7927
7928
7929
7930
7931
7932
7933
7934
7935
7936
7937
7938
7939
7940
7941
7942
7943
7944
7945
7946
7947
7948
7949
7950
7951
7952
7953
7954
7955
7956
7957
7958
7959
7960
7961
7962
7963
7964
7965
7966
7967
7968
7969
7970
7971
7972
7973
7974
7975
7976
7977
7978
7979
7980
7981
7982
7983
7984
7985
7986
7987
7988
7989
7990
7991
7992
7993
7994
7995
7996
7997
7998
7999
8000

```

```

7778 033772 005004
7779 033774 012767 014716 150050 6$: CLR R4 ;CLEAR THE CHARACTER COUNTER.
7780 034002 017702 146222 MOV #6606.,ERRNBR ;SET UP ERROR NUMBER EACH TIME AROUND LOOP.
7781 034006 100036 MOV #RBUFA,R2 ;READ A CHARACTER FROM THE FIFO.
7782 BPL 10$ ;EXIT THE READ LOOP IF THE FIFO IS EMPTY.
7783
7784 ;+
7785 ; CHECK IF THE READ CHARACTER IS A BMP CODE.
7786 ; IF IT IS A BMP CODE SAVE IT ON THE QUEUE TO BE REPORTED LATER, AND
7787 ; ABORT THE TEST.
7788 034010 004767 157762 JSR PC,CHKBMP ;CHECK IF CHARACTER IS A BMP CODE.
7789 034014 103002 BCC 8$ ;BRANCH IF NOT A BMP CODE.
7790 034016 104460 ERROR ;
7791 034020 000440 BR 60$ ;EXIT THIS TEST. TRAP C$ERROR
7792 034022 005267 150024 8$: INC ERRNBR ;SET ERROR NUMBER TO 6607.
7793 034026 005204 INC R4 ;COUNT THIS CHARACTER.
7794 034030 020405 CMP R4,R5 ;COMPARE # OF CHARS WITH MAX # OF CHARS.
7795 034032 003031 BGT 50$ ;ABORT TEST IF TOO MANY VALID CHARS READ.
7796 034034 032702 040000 BIT #BIT14,R2 ;TEST THE OVERRUN BIT OF THE READ CHAR.
7797 034040 001755 BEQ 6$ ;LOOP TO READ THE NEXT CHAR IF NO ERROR.
7798 034042 005267 150004 INC ERRNBR ;SET ERROR NUMBER TO 6608.
7799 034046 012767 012506 150002 MOV #ER7801,ERRBLK ;SELECT THE CORRECT ERROR REPORTING ROUTINE.
7800 034054 012701 010442 MOV #EM6602,R1 ;PASS THE MESSAGE TO BE REPORTED.
7801 034060 010203 MOV R2,R3
7802 034062 000303 SWAB R3
7803 034064 042703 177760 BIC #177760,R3 ;GET FAILING LINE NUMBER.
7804 ;REPORT "OVERRUN ERROR REPORTED WHEN NONE FORCED, ON LINE NN ..."
7805 034070 104460 ERROR ;
7806 ;+
7807 ; EXIT THE TEST IF EXTENDED ERROR REPORTING HAS NOT BEEN ENABLED
7808 ;+
7809 ;-
7810 034072 032767 000100 146110 BIT #BIT06,OPTION ;EXIT WITH TEST FAILURE MESSAGE IF
7811 034100 001410 BEQ 60$ ;NO EXTENDED ERROR REPORTING HAS BEEN REQUESTED
7812 ; DURING THE SOFTWARE QUESTIONS.
7813
7814 034102 000734 BR 6$ ;LOOP TO READ THE NEXT CHAR.
7815
7816 034104 012767 014721 147740 10$: MOV #6609.,ERRNBR ;SET ERROR NUMBER TO 6609.
7817 034112 020405 CMP R4,R5 ;COMPARE NUMBER OF CHARS READ WITH EXPECTED.
7818 034114 001402 BEQ 60$ ;EXIT TEST WITHOUT ABORT IF CORRECT # OF CHARS.
7819
7820 034116 004767 162550 50$: JSR PC,TSABRT ;ABORT THE TEST, NON-RELATED TEST ERROR FOUND.
7821 034122 005067 146122 60$: CLR CTRLCF ;INDICATE THAT WE ARE NOT WITHIN A TEST.
7822 034126
034126
034126 104401
L10047: TRAP C$ETST
    
```

7824
 7825
 7826
 7827
 7828
 7829
 7830
 7831
 7832
 7833
 7834
 7835
 7836
 7837
 7838 034130
 034130
 7839 034130 012700 000240
 034130 104441
 034134 000023
 7840
 7841 034136 012767 000023 146110
 7842 034144 012767 177777 146076
 7843 034152 012767 000001 147670
 7844 034160 012767 015055 147664
 7845 034166 012767 010514 147660
 7846
 7847
 7848
 7849
 7850
 7851 034174 004767 160016
 7852 034200 103402
 7853 034202 000167 000660
 7854
 7855
 7856
 7857
 7858 034206 004767 160256
 7859 034212 103402
 7860 034214 000167 000646
 7861 034220 004767 160324
 7862
 7863
 7864
 7865
 7866
 7867
 7868
 7869
 7870 034224 005267 147622
 7871 034230 012700 000204
 7872 034234 004767 163312
 7873 034240 012700 177670
 7874 034244 004767 163332
 7875 034250 012704 000012
 7876 034254 004767 160002
 7877 034260 012702 002650

```

.SBTTL HARDWARE TEST - ORERR
.....
- OVERRUN ERROR TEST -
.....
THIS TEST VERIFIES THAT THE DUT WILL REPORT DATA OVERRUN ERRORS WHEN
THEY OCCUR.
THIS TEST PUTS 256 CHARACTERS IN THE DUT FIFO PLUS 5 IN EACH ACTIVE
UART AND VERIFIES THAT OVERRUN ERRORS ARE REPORTED ON ALL ACTIVE LINES.
ANY BMP CODE FOUND WILL INVALIDATE THE TEST AND CAUSE IT TO BE ABORTED.
HOWEVER THE BMP CODE WILL BE PLACED ON THE BMP CODE QUEUE, TO BE
REPORTED LATER.
.....
BGNTST
SETPRI #PRIOS ;ALLOW LTC INTERRUPTS. T19::
MOV #PRIOS,R0
TRAP C:SPRI
TNUM == TNUM + 1 ;INCREMENT THE ASSEMBLY TIME TEST COUNTER.
MOV #TNUM,TSTNUM ;SET UP THE TEST NUMBER. (67)
MOV #1,CTRLCF ;INDICATE THAT WE ARE IN A TEST.
MOV #1,ERRTYP ;SET ERROR TYPE AS FATAL IN ERROR TABLE.
MOV #6701,ERRNBR ;SET ERROR NUMBER TO 6701.
MOV #EM6701,ERRMSG ;SET ERROR MESSAGE ADDRESS IN ERROR TABLE.
;
; RESET THE DUT TO A KNOWN STATE, REMOVE THE STATUS CODES FROM THE FIFO.
; CLEAR TX AND RX INTERRUPT ENABLE BITS IN THE CSR.
; THIS SUBROUTINE REPORTS ERROR >>>> 6701 <<<<.
;
JSR PC,CLRST ;RESET THE DMU-11, REPORT ANY ERRORS FOUND.
BCS .+6 ;SKIP EXIT OF TEST IF NO FATAL ERROR FOUND.
JMP 601 ;EXIT THE TEST, FATAL ERROR WAS FOUND.
;
; FIND AN ACTIVE LINE ON WHICH TO PERFORM THE TEST.
; INITIALIZE THE 256 BYTE DATA PATTERN.
;
JSR PC,FINACT ;FIND AN ACTIVE LINE.
BCS .+6 ;IF ACTIVE LINE IS FOUND, DON'T ABORT TEST.
JMP 601 ;ABORT THE TEST, NO ACTIVE LINES WERE FOUND.
JSR PC,INDATP ;INITIALISE DATA PATTERN.
;
; TRANSMIT A 265 CHARACTER DATA PATTERN USING DMA, ON A SINGLE CHANNEL
; AT 38.4K BAUD, 8 BITS PER CHARACTER, ODD PARITY, 2 STOP BITS.
;
; SET INTERNAL LOOPBACK ON THE SELECTED LINE.
; TRANSMIT THE DATA PATTERN ON THE FIRST AVAILABLE ACTIVE LINE.
;
INC ERRNBR ;SET ERROR NUMBER TO 6702.
MOV #204,R0 ;PASS PARAMETER FOR INTERNAL LOPBCK,ENABLE RX.
JSR PC,WTMLNC ;INITIALISE THE LINE CONTROL REGISTER.
MOV #177670,R0 ;PASS THE LPR CONTENTS.
JSR PC,WTMLPR ;SET THE LPR CONTENTS TO 38.4K BAUD.
MOV #10,R4 ;PASS DELAY TIME OF 10 MILLI SECONDS.
JSR PC,DELAY ;WAIT FOR LNCRTL AND LPR REGS TO BE UPDATED.
MOV #BUFBAS,R2 ;PASS THE START OF THE DATA PATTERN TO TX.
    
```

7878	034264	012703	000400						
7879	034270	004767	160104						
7880	034274	103402							
7881	034276	000167	000560						
7882									
7883									
7884									
7885									
7886	034302	005267	147544						
7887	034306	012701	170536						
7888	034312	016702	145710						
7889	034316	004767	163114						
7890	034322	103402							
7891	034324	000167	000532						
7892	034330	012704	000005						
7893	034334	004767	157722						
7894									
7895									
7896									
7897	034340	016705	145654						
7898	034344	012700	000204						
7899	034350	004767	163176						
7900	034354	012700	177670						
7901	034360	004767	163216						
7902	034364	012704	000012						
7903	034370	004767	157666						
7904									
7905	034374	012702	002650						
7906	034400	012703	000005						
7907	034404	005001							
7908	034406	005267	147440						
7909	034412	010100							
7910	034414	006300							
7911	034416	036067	002336	145574					
7912	034424	001405							
7913	034426	004767	157746						
7914	034432	103402							
7915	034434	000167	000422						
7916	034440	005201							
7917	034442	020127	000020						
7918	034446	002761							
7919									
7920	034450	005267	147376						
7921	034454	012701	170040						
7922	034460	016702	145542						
7923	034464	004767	162746						
7924	034470	103174							
7925	034472	012704	000005						
7926	034476	004767	157560						
7927									
7928									
7929									
7930									
7931	034502	012704	000400						
7932	034506	012767	015062	147336					
7933	034514	017702	145510						
7934	034520	100160							


```

;
; MOV #BUFID BUFBAS,R3 ;PASS THE LENGTH OF THE DATA PATTERN.
; JSR PC,DODMA ;TRANSMIT THE DATA PATTERN.
; BCS .+6 ;IF NO ERROR FOUND DURING DMA TX, DON'T ABORT.
; JMP 50$ ;ABORT TEST, ERROR FOUND DURING DMA TX.
;
; WAIT FOR DMA TO COMPLETE, THEN WAIT FOR THE LAST CHARACTER TO ARRIVE IN
; THE FIFO.
;
; INC ERRNBR ;SET ERROR NUMBER TO 6703.
; MOV #170536,R1 ;PASS TIME-OUT VALUE OF 350 MILLI SECS.
; MOV CSRA,R2 ;PASS THE ADDRESS OF THE CSR.
; JSR PC,WAIBIS ;WAIT FOR DMA TO COMPLETE, TX ACTION SET.
; BCS .+6 ;IF NO TIME-OUT ON DMA COMPLETION, DON'T ABORT.
; JMP 50$ ;ABORT TEST, TIME-OUT ON DMA COMPLETION.
; MOV #5,R4 ;PASS DELAY OF 5 MILLI SECS.
; JSR PC,DELAY ;WAIT FOR LAST CHAR TO ARRIVE IN THE FIFO.
;
; TRANSMIT 5 CHARACTERS ON EACH ACTIVE LINE.
;
; MOV ACTLNS,R5 ;ALTER PARAMETERS FOR ALL ACTIVE LINES.
; MOV #204,R0 ;PASS PARAMETER FOR INTERNAL LOPBCK,ENABLE RX.
; JSR PC,WTWNC ;INITIALISE THE LINE CONTROL REGISTER.
; MOV #177670,R0 ;PASS THE LPR CONTENTS.
; JSR PC,WTWLP ;SET THE LPR CONTENTS TO 38.4K BAUD.
; MOV #10,R4 ;PASS DELAY TIME OF 10 MILLI SECONDS.
; JSR PC,DELAY ;WAIT FOR LNCTRL AND LPR REGS TO BE UPDATED.
;
; MOV #BUFBAS,R2 ;PASS THE START OF THE DATA PATTERN TO TX.
; MOV #5,R3 ;PASS THE LENGTH OF THE DATA PATTERN.
; CLR R1 ;CLEAR THE LINE COUNTER.
; INC ERRNBR ;SET ERROR NUMBER TO 6704.
; MOV R1,R0
; ASL R0 ;CALCULATE LINE OFFSET FROM THE LINE #.
; BIT BITTBL(R0),ACTLNS ;TEST FOR THIS LINE BEING ACTIVE.
; BEQ 4$ ;SKIP THE TX ON THIS LINE IF IT IS NOT ACTIVE.
; JSR PC,DODMA ;TRANSMIT THE 5 CHAR DATA PATTERN.
; BCS .+6 ;IF NO TIME-OUT ON DMA COMPLETION, DON'T ABORT.
; JMP 50$ ;ABORT TEST, TIME-OUT ON DMA COMPLETION.
; INC R1 ;INCREMENT THE LINE NUMBER COUNTER.
; CMP R1,#NUMLNS ;TEST FOR ALL POSSIBLE LINES HANDLED
; BLT 2$ ;LOOP IF NOT ALL LINES HANDLED.
;
; INC ERRNBR ;SET ERROR NUMBER TO 6705.
; MOV #170040,R1 ;PASS TIME-OUT VALUE OF 32 MILLI SECS.
; MOV CSRA,R2 ;PASS THE ADDRESS OF THE CSR.
; JSR PC,WAIBIS ;WAIT FOR A DMA TO COMPLETE, TX ACTION SET.
; BCC 50$ ;ABORT THE TEST IF TIME-OUT ON DMA COMPLETION.
; MOV #5,R4 ;PASS DELAY OF 5 MILLI SECS.
; JSR PC,DELAY ;WAIT FOR LAST CHAR TO ARRIVE IN THE FIFO.
;
; READ 256 CHARS FROM THE FIFO CHECKING FOR BMP CODES.
; ABORT THE TEST IF A BMP CODE WAS FOUND IN THE FIFO.
;
; MOV #256,R4 ;SET UP THE CHARACTER COUNTER.
; MOV #6706,ERRNBR ;SET UP ERROR NUMBER EACH TIME AROUND LOOP.
; MOV BRBUFA,R2 ;READ A CHARACTER FROM THE FIFO.
; BPL 50$ ;ABORT THE TEST IF DATA.VALID IS CLEAR.
    
```

```

7935 034522 005267 147324
7936 034526 004767 157244
7937 034532 103351
7938 034534 005304
7939 034536 001363
7940
7941
7942
7943 034540 005004
7944 034542 012700 003710
7945 034546 004767 157466
7946 034552 012767 015064 147272 8:
7947 034560 017702 145444
7948 034564 100047
7949 034566 004767 157204
7950 034572 103531
7951 034574 005267 147252
7952 034600 010200
7953 034602 000300
7954 034604 042700 177760
7955 034610 006300
7956 034612 042702 007400
7957 034616 036067 002336 145374
7958 034624 001516
7959 034626 005267 147220
7960 034632 005760 003710
7961 034636 001006
7962 034640 020227 140000
7963 034644 001414
7964 034646 056004 002336
7965 034652 000411
7966 034654 026027 003710 000004 10:
7967 034662 002077
7968 034664 032702 040000
7969 034670 001402
7970 034672 056004 002336
7971 034676 005260 003710
7972 034702 000723
7973
7974
7975
7976
7977
7978 034704 005001
7979 034706 012767 015067 147136
7980 034714 036167 002336 145276
7981 034722 001415
7982 034724 026127 003710 000002
7983 034732 002453
7984 034734 036104 002336
7985 034740 001006
7986 034742 005267 147104
7987 034746 026127 003710 000002
7988 034754 001042
7989 034756 062701 000002
7990 034762 020127 000040
7991 034766 002747

```

```

INC ERRNBR ;SET ERROR NUMBER TO 6707.
JSR PC,CHKBMP ;CHECK IF CHARACTER IS A BMP CODE.
BCS 24: ;REPORT ERROR AND ABORT TEST IF A BMP CODE.
DEC R4 ;COUNT THIS CHARACTER.
BNE 6: ;LOOP IF NOT 256 CHARS READ FROM FIFO.

; READ THE REMAINING AND VERIFY 1 OVERRUN PLUS 1 CHAR FROM EACH LINE.

CLR R4 ;CLEAR THE OVERRUN ERROR FLAGS.
MOV #RXCNTB,R0
JSR PC,CLR16W ;CLEAR RX CHAR COUNT TABLE.
MOV #6708,,ERRNBR ;SET UP ERROR NUMBER EACH TIME AROUND LOOP.
MOV #RBUFA,R2 ;READ A CHARACTER FROM THE FIFO.
BPL 14: ;GO ANALYZE THE RESULTS IF ALL CHARS READ.
JSR PC,CHKBMP ;CHECK IF CHAR IS A BMP CODE.
BCS 24: ;REPORT ERROR AND ABORT TEST IF A BMP CODE.
INC ERRNBR ;SET ERROR NUMBER TO 6709.
MOV R2,R0
SWAB R0
BIC #177760,R0 ;CALCULATE THE LINE NUMBER OF THE CHAR.
ASL R0 ;FORM WORD TABLE OFFSET FOR TABLE ACCESS.
BIC #7400,R2 ;REMOVE LINE NUMBER FROM THE READ CHAR.
BIT BITBL(R0),ACTLNS ;TEST FOR ACTIVE LINE.
BEQ 50: ;ABORT TEST IF FOR INACTIVE LINE.
INC ERRNBR ;SET ERROR NUMBER TO 6710.
TST RXCNTB(R0) ;CHECK THE RX CHAR COUNTER FOR THIS LINE.
BNE 10: ;IS THIS FIRST CHAR ON LINE?
CMP R2,#140000 ;YES, TEST FOR NULL CHAR WITH OVERRUN.
BEQ 12: ;IS CHAR A NULL?
BIS BITBL(R0),R4 ;NO, SET THE OVERRUN BIT ERROR FLAG FOR LINE.
BR 12: ;GO COUNT THE CHAR AND CONTINUE.
CMP RXCNTB(R0),#4
BGE 50: ;5TH CHAR ON THIS LINE? YES, ABORT.
BIT #BIT14,R2 ;NO, CHECK OVERRUN BIT.
BEQ 12: ;IS OVERRUN BIT CLEAR? YES, GO COUNT CHAR.
BIS BITBL(R0),R4 ;NO, SET THE OVERRUN BIT ERROR FLAG FOR LINE.
INC RXCNTB(R0) ;COUNT THIS CHARACTER.
BR 8: ;LOOP UNTIL ALL CHARS ARE READ FROM FIFO.

; TEST FOR ABORT CONDITIONS. ONLY NONE ABORT CONDITIONS ARE:
; 1) 2 CHARS RXED ON A LINE AND NO OVERRUN ERROR BIT FAILURE DETECTED.
; 2) 2 TO 4 CHARS RXED ON A LINE AND AN OVERRUN BIT FAILURE DETECTED.

14: CLR R1 ;INITIALIZE LINE LOOP, CLEAR LINE OFFSET.
16: MOV #6711,,ERRNBR ;SET UP ERROR NUMBER EACH TIME AROUND LOOP.
BIT BITBL(R1),ACTLNS
BEQ 18: ;LINE ACTIVE? NO, NEXT LINE.
CMP RXCNTB(R1),#2
BLT 50: ;YES.
BIT BITBL(R1),R4 ;FEWER THAN 2 CHARS RXED? YES, ABORT.
BNE 18: ;NO.
INC ERRNBR ;OVERRUN BIT ERROR FLAG SET? YES, NEXT LINE.
CMP RXCNTB(R1),#2 ;SET LINE NUMBER TO 6712.
BNE 50:
ADD #2,R1 ;NOT 2 CHARS RXED? YES, ABORT. NO, NEXT LINE.
CMP R1,#NUMLNS*2 ;SET LINE OFFSET TO THE NEXT LINE.
BLT 16: ;ALL LINES DONE? NO, LOOP. YES, CONTINUE.

```



```

7992
7993
7994
7995 034770 012767 015071 147054
7996 034776 005001
7997 035000 010102
7998 035002 036104 002336
7999 035006 001415
8000 035010 010103
8001 035012 006203
8002 035014 012767 012506 147034
8003 035022 012701 010546
8004
8005 035026
      035026 104460
8006
8007
8008
8009
8010 035030 032767 000100 145152
8011 035036 001413
8012
8013
8014 035040 010201
8015 035042 046104 002336
8016 035046 001407
8017 035050 062701 000002
8018 035054 000751
8019
8020 035056
8021 035056
      035056 104460
8022 035060 000402
8023
8024 035062 004767 161604
8025 035066 005067 145156
8026
8027 035072
      035072
      035072 104401

;
; CHECK FOR OVERRUN ERROR BIT FAILURES, PRINT ERROR MESSAGE IF FOUND.
;
      MOV    #6713,ERRNBR ;SET UP ERROR NUMBER.
      CLR    R1           ;INITIALIZE LOOP. CLEAR LINE OFFSET.
20$:     MOV    R1,R2     ;COPY THE LINE OFFSET.
          BIT    BITTBL(R1),R4 ;OVERRUN BIT FAILURE FLAGS ARE IN R4.
          BEQ    22$     ;ERROR FLAG CLEAR? YES, NEXT LINE.
          MOV    R1,R3
          ASR    R3      ;CALCULATE LINE NUMBER FROM LINE OFFSET.
          MOV    #ER7801,ERRBLK ;SELECT THE CORRECT ERROR REPORTING ROUTINE.
          MOV    #EM6702,R1 ;PASS THE MESSAGE TO BE REPORTED.
;REPORT "OVERRUN ERROR NOT REPORTED CORRECTLY WHEN FORCED, ON LINE NN ...
      ERROR ;
              >>>> ERROR #6713 <<<<<.
              TRAP    C$ERROR

;
; EXIT THE TEST IF EXTENDED ERROR REPORTING HAS NOT BEEN ENABLED
;
      BIT    #BIT06,OPTION ;EXIT WITH TEST FAILURE MESSAGE IF
      BEQ    60$           ;NO EXTENDED ERROR REPORTING HAS BEEN REQUESTED
                          ;DURING THE SOFTWARE QUESTIONS.
22$:     MOV    R2,R1     ;RESTORE THE LINE OFFSET THAT WAS DESTROYED.
          BIC    BITTBL(R1),R4 ;CLEAR THE LINE ERROR FLAG WE JUST HANDLED.
          BEQ    60$     ;ALL FAILURE BITS HANDLED? YES, EXIT TEST.
          ADD    #2,R1   ;NO, INCREMENT THE LINE OFFSET.
          BR    20$     ;LOOP TO HANDLE THE NEXT LINE.
24$:     ;REPORT "BMP CODE FOUND IN FIFO, TEST INVAILEDATED."
      ERROR ;
              >>>> ERROR <<<<<.
              TRAP    C$ERROR
      BR    60$         ;EXIT THIS TEST.
50$:     JSR    PC,TSABRT ;ABORT THE TEST. ERROR # INDICATES FAULT TYPE.
60$:     CLR    CTRLCF   ;INDICATE THAT WE ARE NOT WITHIN A TEST.

      ENDTST

L10050:
              TRAP    C$ETST
    
```

```

8029
8030 .SBTTL HARDWARE TEST REP8MP -
8031 ;* *****
8032 ;* - REPORT ANY BMP CODES IN THE QUEUE -
8033 ;* THIS IS A PSEUDO-TEST USED TO REPORT ANY BMP CODES THAT WERE FOUND
8034 ;* IN THE DUT'S FIFO DURING PREVIOUS TEST, AND LOGGED IN THE BMP CODE
8035 ;* QUEUE.
8036 ;* IT IS UNLIKELY THAT RUNNING THIS PSEUDO-TEST ALONE WILL PRODUCE ANY
8037 ;* ERROR REPORTS.
8038 ;*
8039 ;* *****
      035074
      035074
8040
8041 035074 000024 TNUM == TNUM + 1 ;INCREMENT THE ASSEMBLY TIME TEST COUNTER.
8042 035102 012767 000024 145152 MOV @TNUM,TSTNUM ;SET UP THE TEST NUMBER. (93)
8043 035110 012767 177777 145140 MOV #-1,CTRLCF ;INDICATE THAT WE ARE IN A TEST.
8044 035114 016702 145274 MOV BMPCQP,R2 ;GET THE CONTENTS OF THE POINTER.
8045 035120 012703 002412 MOV #BMPCQB,R3 ;GET THE START ADDRESS OF THE QUEUE.
8046 035122 020203 CMP R2,R3 ;SEE IF THE POINTER HAS MOVED FROM THE BASE.
8047 BEQ 60$ ;EXIT NO CODES IN THE QUEUE.
8048 ;*
8049 ;* THERE IS AT LEAST ONE BMP CODE IN THE QUEUE. REPORT THE ERROR.
8050 ;*
8051 ;* ;REPORT ERROR BMP CODE FOUND IN TEST NN, BMP CODE:NNNNNN"
8052 035124 012701 011354 MOV #EM9304,R1 ;PASS THE FIRST MESSAGE TO BE REORTED.
8053 035130 104455 ERRDF 9301,EM9301,ER9301 ; >>>> ERROR #9301 <<<<<.
      035132 022125 TRAP C$ERDF
      035134 011200 .WORD 9301
      035136 013176 .WORD EM9301
      .WORD ER9301
8054
8055 035140 012767 002412 145242 MOV #BMPCQB,BMPCQP ;SET POINTER BACK TO THE BEGINING OF THE QUE.
8056
8057 035146 005067 145076 60$: CLR CTRLCF ;INDICATE THAT WE ARE NOT WITHIN A TEST.
8058 035152
      035152 104401
      L10051:
      TRAP C$ETST
    
```

8067
 8068
 8069
 8070
 8071
 8072
 8073
 8074
 8075
 8076
 8077
 8078
 8079
 8080
 8081

.SBTTL HARDWARE PARAMETER CODING SECTION

```

; **
; THE HARDWARE PARAMETER CODING SECTION CONTAINS MACROS
; THAT ARE USED BY THE SUPERVISOR TO BUILD P-TABLES. THE
; MACROS ARE NOT EXECUTED AS MACHINE INSTRUCTIONS BUT ARE
; INTERPRETED BY THE SUPERVISOR AS DATA STRUCTURES. THE
; MACROS ALLOW THE SUPERVISOR TO ESTABLISH COMMUNICATIONS
; WITH THE OPERATOR.
; --
    
```

8082 035154
 035154 000022
 035156

BGNHRD

.WORD L10052 L\$HARD/2
 L\$HARD::

8083
 8093
 8094 035156
 035156 000031
 035160 035222
 035162 160000
 035164 177776

```

;DEVICE CSR ADDRESS QUESTION:
GPRMA HWPTQ1,0,0,160000,177776,YES
    
```

.WORD T\$CODE
 .WORD HWPTQ1
 .WORD T\$LLOLIM
 .WORD T\$HILIM

8095
 8096 035166
 035166 001031
 035170 035240
 035172 000040
 035174 000776

```

;DEVICE INTERRUPT VECTOR QUESTION:
GPRMA HWPTQ2,2,0,40,776,YES
    
```

.WORD T\$CODE
 .WORD HWPTQ2
 .WORD T\$LLOLIM
 .WORD T\$HILIM

8097
 8098 035176
 035176 002032
 035200 035273
 035202 177777
 035204 000000
 035206 177777

```

;ACTIVE LINES BIT MAP QUESTION:
GPRMD HWPTQ3,4,0,MAPLNS,0,177777,YES
    
```

.WORD T\$CODE
 .WORD HWPTQ3
 .WORD MAPLNS
 .WORD T\$LLOLIM
 .WORD T\$HILIM

8099
 R100 035210
 035210 003032
 035212 035321
 035214 000377
 035216 000001
 035220 00000?

```

;TYPE OF LOOPBACK QUESTION:
GPRMD HWPTQ4,6,0,377,1,2,YES
    
```

.WORD T\$CODE
 .WORD HWPTQ4
 .WORD 377
 .WORD T\$LLOLIM
 .WORD T\$HILIM

8101
 8102
 8103 035222

ENDHRD

.EVEN
 L10052:

8104 035222
 8111
 8112 035222 103 123 122
 035225 040 101 104
 035230 104 122 105
 035233 123 123 072
 035236 040 000

HWPTQ1: .ASCIZ /CSR ADDRESS: /

8113	035240	111	116	124	
	035243	105	122	122	HWPTQ2: .ASCIZ /INTERRUPT VECTOR ADDRESS: /
	035246	125	120	124	
	035251	040	126	105	
	035254	103	124	117	
	035257	122	040	101	
	035262	104	104	122	
	035265	105	123	123	
	035270	072	040	000	
8114	035273	101	103	124	HWPTQ3: .ASCIZ /ACTIVE LINE BIT MAP: /
	035276	111	126	105	
	035301	040	114	111	
	035304	116	105	040	
	035307	102	111	124	
	035312	040	115	101	
	035315	120	072	040	
	035320	000			
8115	035321	124	131	120	HWPTQ4: .ASCIZ /TYPE OF LOOPBACK (1=INTERNAL, 2=H3029 OR H3277): /
	035324	105	040	117	
	035327	106	040	114	
	035332	117	117	120	
	035335	102	101	103	
	035340	113	040	050	
	035343	061	075	111	
	035346	116	124	105	
	035351	122	116	101	
	035354	114	054	040	
	035357	062	075	110	
	035362	063	060	062	
	035365	071	040	117	
	035370	122	040	110	
	035373	063	062	067	
	035376	067	051	072	
	035401	000			

8116
8117

.EVEN

```

8126
8127
8128
8129
8130
8131
8132
8133
8134
8135
8136
8137
8138
3139 035402
      035402 000014
      035404
8140
8149
8150 035404
      035404 000130
      035406 035434
      035410 000020
8151
8152 035412
      035412 000130
      035414 035510
      035416 000100
8153
8154
8155
8156 035420
      035420 006044
8157
8158
8159 035422
      035422 001052
      035424 035543
      035426 177777
      035430 000000
      035432 177777
8160
8161
8162
8163 035434
      035434
8164
8165
8172 035434 122 105 120
      035437 117 122 124
      035442 040 125 116
      035445 111 124 040
      035450 116 125 115
      035453 102 105 122
      035456 040 101 123
      035461 040 105 101
      035464 103 110 040

      .SBTTL SOFTWARE PARAMETER CODING SECTION
      ;**
      ; THE SOFTWARE PARAMETER CODING SECTION CONTAINS MACROS
      ; THAT ARE USED BY THE SUPERVISOR TO BUILD P-TABLES. THE
      ; MACROS ARE NOT EXECUTED AS MACHINE INSTRUCTIONS BUT ARE
      ; INTERPRETED BY THE SUPERVISOR AS DATA STRUCTURES. THE
      ; MACROS ALLOW THE SUPERVISOR TO ESTABLISH COMMUNICATIONS
      ; WITH THE OPERATOR.
      ;--
      BGNSFT
      .WORD L10053 L$SOFT/2
      L$SOFT::
      ;UNIT NUMBER PRINTOUT QUESTION:
      GPRML SWPTQ1.0.20.YES
      .WORD T$CODE
      .WORD SWPTQ1
      .WORD 20
      ;EXTENDED ERROR REPORTING QUESTION:
      GPRML SWPTQ2.0.100.YES
      .WORD T$CODE
      .WORD SWPTQ2
      .WORD 100
      ;*
      ; IF EXTENDED ERROR REPORTING IS NOT REQUIRED THEN SKIP THE NEXT QUESTION.
      ;*
      XFERF ENDD
      .WORD T$CODE
      ;NUMBER OF INDIVIDUAL DATA ERRORS TO REPORT ON A LINE QUESTION:
      GPRMD SWPTQ3.2.D.177777.0.177777.YES
      .WORD T$CODE
      .WORD SWPTQ3
      .WORD 177777
      .WORD T$LOLIM
      .WORD T$HILIM
      .EVEN
      ENDD: ENDSFT
      .EVEN
      L10053:
      SWPTQ1: .ASCIZ /REPORT UNIT NUMBER AS EACH UNIT IS TESTED: /
    
```

	035467	125	116	111
	035472	124	040	111
	035475	123	040	124
	035500	105	123	124
	035503	105	104	072
	035506	040	000	
8173	035510	105	130	124
	035513	105	116	104
	035516	105	104	040
	035521	105	122	122
	035524	117	122	040
	035527	122	105	120
	035532	117	122	124
	035535	111	116	107
	035540	072	040	000
8174	035543	116	125	115
	035546	102	105	122
	035551	040	117	106
	035554	040	111	116
	035557	104	111	126
	035562	111	104	125
	035565	101	114	040
	035570	104	101	124
	035573	101	040	105
	035576	122	122	117
	035601	122	123	040
	035604	124	117	040
	035607	122	105	120
	035612	117	122	124
	035615	040	117	116
	035620	040	101	040
	035623	114	111	116
	035626	105	072	040
8175	035631	000		

SWPTQ2: .ASCIZ /EXTENDED ERROR REPORTING: /

SWPTQ3: .ASCIZ /NUMBER OF INDIVIDUAL DATA ERRORS TO REPORT ON A LINE: /

.EVEN

```

8184
8185
8186 035632          $PATCH::
8187 035632          .BLKW  24
8188
8195
8196
8197
8198
8199 035702          LASTAD
                                .EVEN
                                .WORD  0
                                .WORD  0
                                035702 000000
                                035704 000000
8200 035706          L$LAST::
8201 035706          ENDMOD
8202
8203
8204
8205
8206
8207
8208          000001          .END

```

ACTLNS 002220 G	CTRLCF 002250 G	DMABUF 014322 G	EM5804 007201 G	FDATE 000006 G
ADR 000020 G	C\$AU 000052	DODMA 014400 G	EM5805 007265 G	FINACT 014470 G
ADRPTR 014200 G	C\$AUTO 000061	DRADRT 002226 G	EM5901 007346 G	FSLSA 002234 G
ALTFLD 013370 G	C\$BRK 000022	DROP 020730	EM5902 007402 G	FSLSO 000006 G
ASLNTL 013442 G	C\$BSEG 000004	EDROP 021006	EM5903 007476 G	F\$AU 000015
ASSEMB 000010	C\$BSUB 000002	EF.CON 000036 G	EM5904 007570 G	F\$AUTO 000020
BCOUNT 002322 G	C\$CEFG 000045	EF.NEW 000035 G	EM5905 007654 G	F\$BGN 000040
BITTBL 002336 G	C\$CLCK 000062	EF.PWR 000034 G	EM6001 007754 G	F\$CLEA 000007
BIT0 000001 G	C\$CLEA 000012	EF.RES 000037 G	EM6002 010000 G	F\$DU 000016
BIT00 000001 G	C\$CLOS 000035	EF.STA 000040 G	EM6003 010040 G	F\$END 000041
BIT01 000002 G	C\$CLP1 000006	EF0503 004156 G	EM6004 010120 G	F\$HARD 000004
BIT02 000004 G	C\$CVEC 000036	EF1601 004163 G	EM6005 010165 G	F\$HW 000013
BIT03 000010 G	C\$DCLN 000044	EF5801 004215 G	EM6006 010243 G	F\$INIT 000006
BIT04 000020 G	C\$DODU 000051	EF5901 004270 G	EM6401 010307 G	F\$JMP 000050
BIT05 000040 G	C\$DRPT 000024	EF5902 004320 G	EM6402 010344 G	F\$MOD 000000
BIT06 000100 G	C\$DU 000053	EF6401 004350 G	EM6601 010405 G	F\$MSG 000011
BIT07 000200 G	C\$EDIT 000003	EF7801 004417 G	EM6602 010442 G	F\$PROT 000021
BIT08 000400 G	C\$ERDF 000055	EF9001 004455 G	EM6701 010514 G	F\$PWR 000017
BIT09 001000 G	C\$ERHR 000056	EF9002 004537 G	EM6702 010546 G	F\$RPT 000012
BIT1 000002 G	C\$ERR0 000060	EF9003 004611 G	EM9009 010623 G	F\$SEG 000003
BIT10 002000 G	C\$ERSF 000054	EF9004 004640 G	EM9010 010647 G	F\$SOFT 000005
BIT11 004000 G	C\$ERSO 000057	EF9005 004670 G	EM9014 010673 G	F\$SRV 000010
BIT12 010000 G	C\$ESCA 000010	EF9006 004721 G	EM9017 010767 G	F\$SUB 000002
BIT13 020000 G	C\$ESEG 000005	EF9010 004745 G	EM9026 011100 G	F\$SW 000014
BIT14 040000 G	C\$ESUB 000003	EF9019 005034 G	EM9104 011124 G	F\$TEST 000001
BIT15 100000 G	C\$ETST 000001	EF9301 005053 G	EM9301 011200 G	GETPRM 020446
BIT2 000004 G	C\$EXIT 000032	EF9302 005131 G	EM9302 011257 G	GPRS08 002376 G
BIT3 000010 G	C\$GETB 000026	EM0101 015124 G	EM9303 011307 G	G\$CNT0 000200
BIT4 000020 G	C\$GETW 000027	EM0102 015210 G	EM9304 011354 G	G\$DELM 000372
BIT5 000040 G	C\$GMAN 000043	EM0103 015262 G	ENDD 035434	G\$DISP 000003
BIT6 000100 G	C\$GPHR 000042	EM1601 005320 G	ENDET 003650 G	G\$EXCP 000400
BIT7 000200 G	C\$GPLO 000030	EM4001 005403 G	ENDIT 020650	G\$HILI 000002
BIT8 000400 G	C\$GPRI 000040	EM4002 005435 G	ERCNTB 002614 G	G\$LOLI 000001
BIT9 001000 G	C\$INIT 000011	EM4101 005471 G	ERTBL 002650 G	G\$NO 000000
BMPQ8 002412 G	C\$INLP 000020	EM4102 005523 G	ERRBLK 004056 G	G\$OFFS 000400
BMPQ9 002612 G	C\$MANI 000050	EM4103 005557 G	ERRMSG 004054 G	G\$OF SI 000376
BMPQ9 002410 G	C\$MEM 000031	EM4201 005643 G	ERRNBR 004052 G	G\$PRMA 000001
BOE 000400 G	C\$MSG 000023	EM4202 005675 G	ERRTYP 004050 G	G\$PRMD 000002
BRLEVL 002223 G	C\$OPEN 000034	EM4901 005717 G	ERSMRF 002612 G	G\$PRML 000000
BUFBAS 002650 G	C\$PNTB 000014	EM4902 005760 G	ER0101 011430 G	G\$RADA 000140
BUFEND 003650 G	C\$PNTF 000017	EM5001 006012 G	ER0503 011762 G	G\$RADB 000000
BUFMID 003250 G	C\$PNTS 000016	EM5101 006051 G	ER1603 012020 G	G\$RADD 000040
BUFPTR 002246 G	C\$PNTX 000015	EM5102 006106 G	ER5801 012112 G	G\$RADL 000120
BUF3QT 003450 G	C\$QIO 000377	EM5103 006144 G	ER5901 012170 G	G\$RADO 000020
CALMSL 013552 G	C\$RDBU 000007	EM5201 006174 G	ER6001 012276 G	G\$XFER 000004
CHKBMP 013776 G	C\$REFG 000047	EM5202 006227 G	ER6401 012400 G	G\$YES 000010
CKRXTM 014046 G	C\$RESE 000033	EM5301 006265 G	ER7801 012506 G	HELP 000000
CKTRAP 014166 G	C\$REVI 000003	EM5302 006321 G	ER9001 012544 G	HOE 100000 G
CLKBRL 002306 G	C\$RFLA 000021	EM5303 006401 G	ER9002 012644 G	HWPTQ1 035222
CLKCSR 002304 G	C\$RPT 000025	EM5401 006452 G	ER9004 013022 G	HWPTQ2 035240
CLKHRZ 002312 G	C\$SEFG 000046	EM5402 006520 G	ER9101 013136 G	HWPTQ3 035273
CLKINT 017632 G	C\$SPRI 000041	EM5501 006561 G	ER9301 013176 G	HWPTQ4 035321
CLKVEC 002310 G	C\$SVEC 000037	EM5601 006625 G	EVL 000004 G	IBE 010000 G
CLNRST 014216 G	C\$TPRI 000013	EM5701 006702 G	EXOERR 002252 G	IDU 000040 G
CLR16W 014240 G	DELAY 014262 G	EM5801 006757 G	E\$END 002100	IER 020000 G
CSRA 002226 G	DFPTBL 002176 G	EM5802 007003 G	E\$LOAD 000035	IESTAT 002256 G
CSRO 000000 G	DIAGMC 000000	EM5803 007077 G	FDATE 002234 G	INDATP 014550 G

T15	031152 G	T20	035074 G	T8	024716 G	WAIBIS	017436 G	X\$ALWA=	000000
T16	031740 G	T3	021710 G	T9	025410 G	WAITTX	017512 G	X\$FALS=	000040
T17	032766 G	T4	022346 G	UAM	000200 G	WORD1	002302 G	X\$OFFS=	000400
T18	033412 G	T5	022674 G	UNITN	002224 G	WTWLNC	017552 G	X\$TRUE=	000020
T19	034130 G	T6	023474 G	UNSDIV	017302 G	WTWLPR	017602 G	\$PATCH	035632 G
T2	021304 G	T7	024274 G						

. ABS. 035706 000
 000000 001

ERRORS DETECTED: 0

VIRTUAL MEMORY USED: 28661 WORDS (112 PAGES)
 DYNAMIC MEMORY: 20060 WORDS (77 PAGES)
 ELAPSED TIME: 00:05:03
 CZDHV80.BIN,CZDHV80.LST/-SP=SVC34R/ML.CZDHV80.P11