

# RK611

DISKLESS CONTROL PART 2  
CZR6BC0

AH-9102C-MC  
COPYRIGHT © 76-78  
FICHE 1 OF 1

MAR 1978  
**digital**  
MADE IN USA

The image shows a microfiche card with a grid of 14 columns and 12 rows of frames. Each frame contains a small, high-contrast image of a control panel or data display, which is mostly illegible due to the low resolution of the scan. The frames are arranged in a regular grid pattern across the card.

B01

B01Z7ZRBBCSEQ PAGE 1 00010000  
CZR6BC.P11 02-DEC-77 09:22

780223

PDP10E010001

CZR6BCD RK611 DSKLS CTRL PRT2 MACY11 30(1046) 02-D

.REM %

IDENTIFICATION

PRODUCT CODE: AC-9100C-MC  
PRODUCT NAME: CZR6BCD RK611 DSKLS CTRL PRT 2  
DATE: FEB 1978  
MAINTAINER: DIAGNOSTIC GROUP  
AUTHOR: ROY SPITZER

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERROR THAT MAY APPEAR IN THIS DOCUMENT.

THE SOFTWARE DESCRIBED IN THIS DOCUMENT IS FURNISHED UNDER A LICENCE AND MAY ONLY BE USED OR COPIED IN ACCORDANCE WITH THE TERMS OF SUCH LICENSE.

DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR THE USE OF RELIABILITY OF ITS SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL.

COPYRIGHT (C) 1976, 1978 BY DIGITAL EQUIPMENT CORPORATION

1  
UNIVERSITY MICROFILMS  
SERIALS ACQUISITION  
300 N ZEEB RD  
ANN ARBOR MI 48106  
C

0



52  
53  
54  
55  
56  
57  
58  
59  
60  
61  
62  
63  
64  
65  
66  
67  
68  
69  
70  
71  
72  
73  
74  
75  
76  
77  
78  
79  
80  
81  
82  
83  
84  
85  
86  
87  
88  
89  
90  
91  
92  
93  
94  
95  
96  
97  
98  
99  
100  
101  
102  
103  
104  
105  
106  
107

1.0 ABSTRACT

THE RK611 DISKLESS CONTROLLER DIAGNOSTIC: PART 2 TEST THE LOADING OF THE DRIVE BUS MESSAGES BY EXECUTING CLASS A COMMANDS. SOME TESTS EXECUTE COMMANDS PARTIALLY MAINTENANCE MODE AND PARTIALLY AT NORMAL SPEED TO FOOL THE CONTROLLER AND FORCE ERRORS. THIS PROGRAM DOES NOT REQUIRE THE PRESENCE OF AN RK06 DRIVE.

2.0 REQUIREMENTS

2.1 EQUIPMENT

PDP-11 SYSTEM (16K CORE MEMORY)  
CONSOLE TERMINAL  
DECTAPE, PAPER TAPE READER, OR DECDISK  
RK611 CONTROLLER

2.2 PRELIMINARY PROGRAMS

RK611 DISKLESS CONTROLLER DIAGNOSTIC: PART 1  
CZR6ACD

3.0 OPERATING PROCEDURES

3.1 LOADING PROCEDURE

THE PROGRAM CAN BE LOADED FROM PAPER TAPE USING ABSOLUTE LOADER OR FROM ANY MEDIA SUPPORTED BY XXDP.

3.2 STARTING PROCEDURE

LOCATION 200 - START PROGRAM  
LOCATION 204 - RESTART PROGRAM  
LOCATION 214 - REQUEST BUS ADDRESS, VECTOR ADDRESS, AND PRIORITY MODIFICATION

3.3 OPTIONAL SWITCH SETTINGS

SW15 - HALT PROGRAM  
SW14 - LOOP ON TEST  
SW13 - INHIBIT ERROR TYPE OUT  
SW12 - ABORT AFTER 20 ERRORS  
SW11 - INHIBIT ITERATION COUNT  
SW10 - BELL ON ERROR  
SW9 - LOOP ON ERROR  
SW8 - LOOP ON TEST IN SWITCHES 0-7

3.5 RUN TIME

FIRST PASS 7 SECONDS  
SUBSEQUENT PASSES 2 MINUTES

## 4.0 OPERATING PROCEDURES

THE PROGRAM IS EXECUTED BY STARTING AT THE APPROPRIATE ADDRESS.

## 5.0 PROGRAM DESCRIPTION

## \*\*DRIVE MESSAGE LOADING

## TEST 1 FIRST COMMAND IN MAINT MODE

INITIALIZE RK611 WITH CONTROLLER CLEAR. PUT CONTROLLER I MODE. ISSUE SELECT DRIVE. WAIT AND MAKE SURE CSI REMAINS THE SAME. CLOCK IN MESSAGES A AND B. MAKE SURE CORRECT MSG ARE LOADED. CHECKING IS DONE A FIELD AT A TIME.

## TEST 2 DRIVE SELECT BITS LOADING FOR DRIVE MESS.

INITIALIZE RK611 WITH CONTROLLER CLEAR. PUT CONTROLLER DIAGNOSTIC MODE. LOAD COMMAND AND STATUS REGISTER 2 WITH ZERO. LOAD COMMAND AND STATUS REGISTER WITH A SELECT COMMAND. CLOCK IN MESSAGES A AND B INTO SHIFT REGISTER. MAKE SURE CORRECT MESSAGES ARE LOADED. REPEAT FOR DRIVE SELECT = 1-17.

## TEST 3 FORMAT BIT LOADING TO FOR DRIVE MESS.

CLEAR RK611 WITH CONTROLLER CLEAR. PUT CONTROLLER IN DIAGNOSTIC MODE. LOAD COMMAND AND STATUS REGISTER 1 WITH A SELECT COMMAND AND 24 SECTOR MODE FORMAT. MAKE SURE CORRECT MESSAGE IS LOADED.

## TEST 4 HEAD SELECT BITS LOADING FOR DRIVE MESS.

CLEAR RK611 WITH CONTROLLER CLEAR. PUT CONTROLLER IN DIAGNOSTIC MODE. LOAD TRACK ADDRESS WITH ZERO. LOAD COMMAND AND STATUS REGISTER 2 WITH ZERO. LOAD COMMAND AND STATUS REGISTER WITH SELECT COMMAND. CLOCK IN MESSAGE A AND B INTO SHIFT REGISTER. MAKE SURE CORRECT MESSAGE IS LOADED. REPEAT FOR TRACK ADDRESS = 1-7.

## TEST 5 MESSAGE SELECT BITS LOADING FOR DRIVE MESS.

CLEAR RK611 WITH CONTROLLER CLEAR. PUT CONTROLLER IN DIAGNOSTIC MODE AND ZERO IN MESSAGE SELECT BITS. LOAD COMMAND AND STATUS REGISTER 1 WITH A SELECT COMMAND. CL IN MESSAGE A AND B INTO SHIFT REGISTER. MAKE SURE

108  
109  
110  
111  
112  
113  
114  
115  
116  
117  
118  
119  
120  
121  
122  
123  
124  
125  
126  
127  
128  
129  
130  
131  
132  
133  
134  
135  
136  
137  
138  
139  
140  
141  
142  
143  
144  
145  
146  
147  
148  
149  
150  
151  
152  
153  
154  
155  
156  
157  
158  
159  
160  
161  
162  
163

164  
165  
166  
167  
168  
169  
170  
171  
172  
173  
174  
175  
176  
177  
178  
179  
180  
181  
182  
183  
184  
185  
186  
187  
188  
189  
190  
191  
192  
193  
194  
195  
196  
197  
198  
199  
200  
201  
202  
203  
204  
205  
206  
207  
208  
209  
210  
211  
212  
213  
214  
215  
216  
217  
218  
219

CORRECT MESSAGE IS LOADED. REPEAT FOR MESSAGE SELECT =

TEST 6 CLEAR DRIVE COMMAND LOADING FOR DRIVE MESS

CLEAR RK611 WITH CONTROLLER CLEAR. PUT CONTROLLER IN DIAGNOSTIC MODE. LOAD COMMAND AND STATUS REGISTER 1 WITH A DRIVE CLEAR. CLOCK MESSAGE A AND B INTO SHIFT REGISTER. MAKE SURE SHIFT REGISTERS ARE LOADED CORRECTLY. REPEAT FOR 24 SECTOR FORMAT.

TEST 7 UNLOAD COMMAND LOADING FOR DRIVE MESS.

CLEAR RK611 WITH CONTROLLER CLEAR. PUT CONTROLLER IN DIAGNOSTIC MODE. LOAD COMMAND AND STATUS REGISTER 1 WITH AN UNLOAD COMMAND. CLOCK IN MESSAGES A AND B INTO SHIFT REGISTERS. MAKE SURE SHIFT REGISTERS ARE LOADED CORRECT. REPEAT FOR 24 SECTOR FORMAT.

TEST 10 PACK ACKNOWLEDGE COMMAND LOADING FOR DRIVE MESS.

CLEAR RK611 WITH CONTROLLER CLEAR. PUT CONTROLLER IN DIAGNOSTIC MODE. LOAD COMMAND AND STATUS REGISTER 1 WITH A PACK ACKNOWLEDGE. CLOCK MESSAGES A AND B INTO SHIFT REGISTERS. MAKE SURE SHIFT REGISTERS ARE LOADED CORRECT. REPEAT FOR 24 SECTOR FORMAT.

TEST 11 RECALIBRATE COMMAND LOADING FOR DRIVE MESS.

CLEAR RK611 WITH CONTROLLER CLEAR. PUT CONTROLLER IN DIAGNOSTIC MODE. LOAD COMMAND AND STATUS REGISTER 1 WITH A RECALIBRATE. CLOCK MESSAGES A AND B INTO SHIFT REGISTER. MAKE SURE SHIFT REGISTERS ARE LOADED CORRECTLY.

TEST 12 START SPINDLE COMMAND LOADING FOR DRIVE MESS.

CLEAR RK611 WITH CONTROLLER CLEAR. PUT CONTROLLER IN DIAGNOSTIC MODE. LOAD COMMAND AND STATUS REGISTER 1 WITH A START SPINDLE. CLOCK MESSAGES A AND B INTO SHIFT REGISTER. MAKE SURE SHIFT REGISTERS ARE LOADED CORRECTLY.

TEST 13 SEEK AND CYLINDER ADD 0-777 LOADING FOR DRIVE MESS

CLEAR RK611 WITH CONTROLLER CLEAR. PUT CONTROLLER IN DIAGNOSTIC MODE. LOAD ZERO IN CYLINDER ADDRESS. LOAD COMMAND AND STATUS REGISTER 1 WITH A SEEK COMMAND. CLOCK IN MESSAGE A AND B INTO SHIFT REGISTER. MAKE SURE CORRECT MESSAGE IS LOADED. REPEAT FOR CYLINDER = 1-777.

TEST 14 SEEK AND CYLINDER BIT 9 AND RK06 FOR DRIVE MESS.

220  
221  
222  
223  
224  
225  
226  
227  
228  
229  
230  
231  
232  
233  
234  
235  
236  
237  
238  
239  
240  
241  
242  
243  
244  
245  
246  
247  
248  
249  
250  
251  
252  
253  
254  
255  
256  
257  
258  
259  
260  
261  
262  
263  
264  
265  
266  
267  
268  
269  
270  
271  
272  
273  
274  
275

CLEAR RK611 WITH CONTROLLER CLEAR. PUT CONTROLLER IN DIAGNOSTIC MODE. LOAD 1000 IN CYLINDER ADDRESS. LOAD COMMAND AND STATUS REGISTER 1 WITH A SEEK COMMAND. CLOCK IN MESSAGE A AND B INTO SHIFT REGISTERS. MAKE SURE CYLINDER BIT 9 IN MESSAGE IN RESET. REPEAT FOR CYLINDER = 1400.

TEST 15 SEEK AND CYLINDER ADD 0,777-1777 LOADING FOR DRIVE MESS

CLEAR RK611 WITH CONTROLLER CLEAR. PUT CONTROLLER IN DIAGNOSTIC MODE. LOAD 0 IN CYLINDER ADDRESS. LOAD COMMAND AND STATUS REGISTER 1 WITH SEEK COMMAND AND CDT SET. CLOCK IN MESSAGE A AND B INTO SHIFT REGISTER. MAKE SURE CYLINDER CORRECT. REPEAT FOR CYLINDER = 777-1

TEST 16 OFFSET COMMAND LOADING FOR DRIVE MESS.

CLEAR RK611 WITH CONTROLLER CLEAR. PUT CONTROLLER IN DIAGNOSTIC MODE. LOAD OFFSET REGISTER WITH 0. LOAD COMMAND AND STATUS REGISTER 1 WITH AN OFFSET. CLOCK MESSAGES A AND B INTO SHIFT REGISTERS. MAKE SURE SHIFT REGISTERS ARE LOADED CORRECTLY. REPEAT FOR OFFSET REGISTER = 1-377.

TEST 17 CYLINDER ADDRESS LOADING OF DRIVE MESS (PART 1)

CLEAR RK611 WITH CONTROLLER CLEAR. PUT CONTROLLER IN DIAGNOSTIC MODE. LOAD CYLINDER ADDRESS REGISTER WITH 777. LOAD THE OFFSET REG TO 52. LOAD COMMAND AND STATUS REGISTER 1 WITH A SELECT. CLOCK MESSAGES A AND B INTO SHIFT REGISTERS. MAKE SURE SHIFT REGISTERS ARE LOADED CORRECTLY AND THE CYLINDER ADDRESS FIELD IS ZERO IN DRIVE MESSAGE.

TEST 20 CYLINDER ADDRESS LOADING OF DRIVE MESS (PART 2)

CLEAR RK611 WITH CONTROLLER CLEAR. PUT CONTROLLER IN DIAGNOSTIC MODE. LOAD CYLINDER ADDRESS REGISTER WITH 777. LOAD THE OFFSET REG TO 52. LOAD COMMAND AND STATUS REGISTER 1 WITH A PACK ACKNOWLEDGE. CLOCK MESSAGES A AND B INTO SHIFT REGISTERS. MAKE SURE SHIFT REGISTERS ARE LOADED CORRECTLY AND THE CYLINDER ADDRESS FIELD IS ZERO IN DRIVE MESSAGE.

TEST 21 CYLINDER ADDRESS LOADING OF DRIVE MESS (PART 3)

CLEAR RK611 WITH CONTROLLER CLEAR. PUT CONTROLLER IN DIAGNOSTIC MODE. LOAD CYLINDER ADDRESS REGISTER WITH 777. LOAD THE OFFSET REG TO 52. LOAD COMMAND

276  
277  
278  
279  
280  
281  
282  
283  
284  
285  
286  
287  
288  
289  
290  
291  
292  
293  
294  
295  
296  
297  
298  
299  
300  
301  
302  
303  
304  
305  
306  
307  
308  
309  
310  
311  
312  
313  
314  
315  
316  
317  
318  
319  
320  
321  
322  
323  
324  
325  
326  
327  
328  
329  
330  
331

AND STATUS REGISTER 1 WITH A CLEAR DRIVE. CLOCK  
MESSAGES A AND B INTO SHIFT REGISTERS. MAKE SURE  
SHIFT REGISTERS ARE LOADED CORRECTLY AND THE CYLINDER  
ADDRESS FIELD IS ZERO IN DRIVE MESSAGE.

TEST 22 CYLINDER ADDRESS LOADING OF DRIVE MESS (PART 4)

CLEAR RK611 WITH CONTROLLER CLEAR. PUT CONTROLLER IN  
DIAGNOSTIC MODE. LOAD CYLINDER ADDRESS REGISTER  
WITH 777. LOAD THE OFFSET REG TO 52. LOAD COMMAND  
AND STATUS REGISTER 1 WITH AN UNLOAD. CLOCK  
MESSAGES A AND B INTO SHIFT REGISTERS. MAKE SURE  
SHIFT REGISTERS ARE LOADED CORRECTLY AND THE CYLINDER  
ADDRESS FIELD IS ZERO IN DRIVE MESSAGE.

TEST 23 CYLINDER ADDRESS LOADING OF DRIVE MESS (PART 5)

CLEAR RK611 WITH CONTROLLER CLEAR. PUT CONTROLLER IN  
DIAGNOSTIC MODE. LOAD CYLINDER ADDRESS REGISTER  
WITH 777. LOAD THE OFFSET REG TO 52. LOAD COMMAND  
AND STATUS REGISTER 1 WITH A START SPINDLE. CLOCK  
MESSAGES A AND B INTO SHIFT REGISTERS. MAKE SURE  
SHIFT REGISTERS ARE LOADED CORRECTLY AND THE CYLINDER  
ADDRESS FIELD IS ZERO IN DRIVE MESSAGE.

TEST 24 CYLINDER ADDRESS LOADING OF DRIVE MESS (PART 6)

CLEAR RK611 WITH CONTROLLER CLEAR. PUT CONTROLLER IN  
DIAGNOSTIC MODE. LOAD CYLINDER ADDRESS REGISTER  
WITH 777. LOAD THE OFFSET REG TO 52. LOAD COMMAND  
AND STATUS REGISTER 1 WITH A RECALIBRATE. CLOCK  
MESSAGES A AND B INTO SHIFT REGISTERS. MAKE SURE  
SHIFT REGISTERS ARE LOADED CORRECTLY AND THE CYLINDER  
ADDRESS FIELD IS ZERO IN DRIVE MESSAGE.

TEST 25 MESSAGE SELECT BIT CLEARING FOR CLASS A (PART 1)

CLEAR RK611 WITH CONTROLLER CLEAR. PUT CONTROLLER IN  
DIAGNOSTIC MODE WITH MESSAGE SELECT BITS = 17. LOAD  
COMMAND AND STATUS REGISTER 1 WITH A PACK ACKNOWLEDGE.  
CLOCK MESSAGE TO LOAD B SHIFT REG. TIME. MAKE SURE  
MESSAGE SELECT BITS ARE CLEARED.

TEST 26 MESSAGE SELECT BIT CLEARING FOR CLASS A (PART 2)

CLEAR RK611 WITH CONTROLLER CLEAR. PUT CONTROLLER IN  
DIAGNOSTIC MODE WITH MESSAGE SELECT BITS = 17. LOAD  
COMMAND AND STATUS REGISTER 1 WITH A DRIVE CLEAR.  
CLOCK MESSAGE TO LOAD B SHIFT REG. TIME. MAKE SURE  
MESSAGE SELECT BITS ARE CLEARED.



332  
333  
334  
335  
336  
337  
338  
339  
340  
341  
342  
343  
344  
345  
346  
347  
348  
349  
350  
351  
352  
353  
354  
355  
356  
357  
358  
359  
360  
361  
362  
363  
364  
365  
366  
367  
368  
369  
370  
371  
372  
373  
374  
375  
376  
377  
378  
379  
380  
381  
382  
383  
384  
385  
386  
387

TEST 27 MESSAGE SELECT BIT CLEARING FOR CLASS A (PART 3)

CLEAR RK611 WITH CONTROLLER CLEAR. PUT CONTROLLER IN DIAGNOSTIC MODE WITH MESSAGE SELECT BITS = 17. LOAD COMMAND AND STATUS REGISTER 1 WITH AN UNLOAD. CLOCK MESSAGE TO LOAD B SHIFT REG. TIME. MAKE SURE MESSAGE SELECT BITS ARE CLEARED.

TEST 30 MESSAGE SELECT BIT CLEARING FOR CLASS A (PART 4)

CLEAR RK611 WITH CONTROLLER CLEAR. PUT CONTROLLER IN DIAGNOSTIC MODE WITH MESSAGE SELECT BITS = 17. LOAD COMMAND AND STATUS REGISTER 1 WITH A START SPINDLE. CLOCK MESSAGE TO LOAD B SHIFT REG. TIME. MAKE SURE MESSAGE SELECT BITS ARE CLEARED.

TEST 31 MESSAGE SELECT BIT CLEARING FOR CLASS A (PART 5)

CLEAR RK611 WITH CONTROLLER CLEAR. PUT CONTROLLER IN DIAGNOSTIC MODE WITH MESSAGE SELECT BITS = 17. LOAD COMMAND AND STATUS REGISTER 1 WITH A RECALIBRATE. CLOCK MESSAGE TO LOAD B SHIFT REG. TIME. MAKE SURE MESSAGE SELECT BITS ARE CLEARED.

TEST 32 MESSAGE SELECT BIT CLEARING FOR CLASS A (PART 6)

CLEAR RK611 WITH CONTROLLER CLEAR. PUT CONTROLLER IN DIAGNOSTIC MODE WITH MESSAGE SELECT BITS = 17. LOAD COMMAND AND STATUS REGISTER 1 WITH A OFFSET. CLOCK MESSAGE TO LOAD B SHIFT REG. TIME. MAKE SURE MESSAGE SELECT BITS ARE CLEARED.

TEST 33 MESSAGE SELECT BIT CLEARING FOR CLASS A (PART 7)

CLEAR RK611 WITH CONTROLLER CLEAR. PUT CONTROLLER IN DIAGNOSTIC MODE WITH MESSAGE SELECT BITS = 17. LOAD COMMAND AND STATUS REGISTER 1 WITH A SEEK. CLOCK MESSAGE TO LOAD B SHIFT REG. TIME. MAKE SURE MESSAGE SELECT BITS ARE CLEARED.

\*\*DRIVE MESSAGE LOOPBACK AND PARITY GENERATION TESTS

TEST 34 DRIVE MESSAGE LOOPBACK

CLEAR THE RK611 WITH A CONTROLLER CLEAR. PUT CONTROLLER IN DIAGNOSTIC MODE INDICATING MESSAGE 3. LOAD COMMAND STATUS REGISTER FOR DRIVE 5. LOAD COMMAND AND STATUS REGISTER 1 WITH A SELECT COMMAND. CLOCK 4 BITS THROUGH THE DRIVE MESSAGE LOOPBACK. VERIFY THAT BITS ARE INDEED LOOPED BACK.

388  
389  
390  
391  
392  
393  
394  
395  
396  
397  
398  
399  
400  
401  
402  
403  
404  
405  
406  
407  
408  
409  
410  
411  
412  
413  
414  
415  
416  
417  
418  
419  
420  
421  
422  
423  
424  
425  
426  
427  
428  
429  
430  
431  
432  
433  
434  
435  
436  
437  
438  
439  
440  
441  
442  
443  
444  
445  
446  
447  
448  
449  
450  
451  
452  
453  
454  
455  
456  
457  
458  
459  
460  
461  
462  
463  
464  
465  
466  
467  
468  
469  
470  
471  
472  
473  
474  
475  
476  
477  
478  
479  
480  
481  
482  
483  
484  
485  
486  
487  
488  
489  
490  
491  
492  
493  
494  
495  
496  
497  
498  
499  
500

TEST 35 DRIVE MESSAGE SHIFT

CLEAR THE RK611 WITH A CONTROLLER CLEAR. PUT CONTROLLER IN DIAGNOSTIC MODE. LOAD CYLINDER ADDRESS WITH 441. LOAD HEAD ADDRESS WITH 1. LOAD COMMAND AND STATUS REGISTER 1 WITH A SEEK IN 24 SECTOR MODE. CLOCK 8 BITS THROUGH THE DRIVE MESSAGE LOOPBACK. VERIFY THAT BITS ARE SHIFTED PROPERLY.

TEST 36 DRIVE MESSAGE PARITY PRECONDITIONING

CLEAR RK611 WITH CONTROLLER CLEAR. PUT CONTROLLER IN DIAGNOSTIC MODE. LOAD COMMAND AND STATUS REGISTER 1 WITH A SELECT COMMAND. CLOCK ALL 16 BITS THROUGH THE DRIVE MESSAGE LOOPBACK. VERIFY PARITY HAS BEEN PRECONDITIONED PROPERLY. REPEAT FOR BAD PARITY GENERATION.

TEST 37 ODD DRIVE MESSAGE PARITY GENERATION

CLEAR RK611 WITH CONTROLLER CLEAR. PUT CONTROLLER IN DIAGNOSTIC MODE AND MESSAGE SELECT = 1. LOAD COMMAND AND STATUS REGISTER 2 WITH DRIVE SELECT = 1. LOAD COMMAND AND STATUS REGISTER 1 WITH A SELECT COMMAND. VERIFY THAT PARITY HAS BEEN GENERATED CORRECTLY. REPEAT FOR MESSAGE SELECT = DRIVE SELECT = 2-17.

TEST 40 DRIVE MESSAGE PARITY INTERACTION

CLEAR THE RK611 WITH A CONTROLLER CLEAR. PUT CONTROLLER IN DIAGNOSTIC MODE. LOAD COMMAND AND STATUS REGISTER 2 WITH DRIVE SELECT = 1. LOAD COMMAND AND STATUS REGISTER 1 WITH A SELECT COMMAND. VERIFY THAT THE CORRECT PARITY IS GENERATED FOR BOTH MESSAGES. REPEAT FOR MESSAGE SELECT = 1 AND DRIVE SELECT = 0.

TEST 41 EVEN DRIVE MESSAGE PARITY GENERATION

CLEAR RK611 WITH CONTROLLER CLEAR. PUT CONTROLLER IN DIAGNOSTIC MODE AND MESSAGE SELECT = 1 AND BAD PARITY SET. LOAD COMMAND AND STATUS REGISTER 2 WITH DRIVE SELECT = 1. LOAD COMMAND AND STATUS REGISTER 1 WITH A SELECT COMMAND. VERIFY THAT EVEN PARITY IS GENERATED. REPEAT FOR MESSAGE SELECT = DRIVE SELECT = 2-17.

\*\*CLASS A COMMAND EXECUTION

TEST 42 RELEASE COMMAND IN DIAGNOSTIC MODE

444  
445  
446  
447  
448  
449  
450  
451  
452  
453  
454  
455  
456  
457  
458  
459  
460  
461  
462  
463  
464  
465  
466  
467  
468  
469  
470  
471  
472  
473  
474  
475  
476  
477  
478  
479  
480  
481  
482  
483  
484  
485  
486  
487  
488  
489  
490  
491  
492  
493  
494  
495  
496  
497  
498  
499

CLEAR THE RK06 SUBSYSTEM WITH A SUBSYSTEM CLEAR.  
PUT CONTROLLER IN DIAGNOSTIC MODE. LOAD COMMAND AND  
STATUS REGISTER 2 WITH DRIVE SELECT = 10. LOAD  
COMMAND AND STATUS REGISTER 1 WITH A SELECT.  
CLOCK COMMAND TO COMPLETION. MAKE SURE UNIT  
FIELD ERROR DOES NOT SET (SACK HIGH). REPEAT FOR  
DRIVE SELECT = 11-17.

## TEST 43 SELECT COMMAND IN DIAGNOSTIC MODE

CLEAR THE RK06 SUBSYSTEM WITH A SUBSYSTEM CLEAR.  
PUT CONTROLLER IN DIAGNOSTIC MODE. LOAD COMMAND AND  
STATUS REGISTER 2 WITH DRIVE SELECT = 0. LOAD  
COMMAND AND STATUS REGISTER 1 WITH A SELECT.  
CLOCK COMMAND TO COMPLETION. MAKE SURE MESSAGE SHIFT IS  
NOT DONE DURING THE RECEIVE CYCLE OF DRIVE MESSAGE.  
MAKE SURE NO ERRORS SET. REPEAT FOR DRIVE SELECT = 1-7.

## TEST 44 RELEASE COMMAND IN NORMAL MODE

CLEAR THE RK06 SUBSYSTEM WITH A SUBSYSTEM CLEAR.  
LOAD COMMAND AND STATUS REGISTER 2 WITH DRIVE SELECT = 1  
LOAD COMMAND AND STATUS REGISTER 1 WITH A SELECT.  
MAKE SURE NO ERRORS OCCUR. REPEAT FOR DRIVE  
SELECT = 11-17

## TEST 45 INTERRUPT AT COMMAND COMPLETION

CLEAR THE RK06 SUBSYSTEM WITH A SUBSYSTEM CLEAR.  
LOWER PROCESSOR PRIORITY TO ZERO. ISSUE A RELEASE  
COMMAND WITH INTERRUPT ENABLE SET. MAKE SURE  
INTERRUPT OCCURS. LOWER PRIORITY AFTER INTERRUPT  
AND MAKE SURE INTERRUPT HAS CLEARED.

LOWER PROCESSOR PRIORITY TO ZERO. REISSUE RELEASE  
WITH INTERRUPT ENABLE RESET. MAKE SURE NO INTERRUPT  
OCCURS. SET INTERRUPT ENABLE AND MAKE SURE NO  
INTERRUPT OCCURS.

## TEST 46 GO CLEAR OF SILO

CLEAR THE RK06 SUBSYSTEM WITH A SUBSYSTEM CLEAR.  
WRITE ONE WORD INTO THE SILO. ISSUE A RELEASE COMMAND  
WITH INTERRUPT ENABLE RESET. WAIT FOR READY.  
READ THE DATA BUFFER TO MAKE SURE THE SILO HAS BEEN  
CLEARED. (DATA LATE SET AFTER READ OF DATA BUFFER)

## TEST 47 SEEK COMMAND IN DIAGNOSTIC MODE

CLEAR RK06 SUBSYSTEM WITH A SUBSYSTEM CLEAR.

PUT CONTROLLER IN DIAGNOSTIC MODE. ISSUE A SEEK WITH CDT  
24 SECTOR FORMAT TO CYLINDER 1714, HEAD 7, DRIVE 0.  
MAKE SURE NO STATUS BITS ARE SET AND NO ERROR  
BITS ARE SET.

\*\*ERROR AND STATUS BIT FORCING WITH DRIVE MESSAGES

TEST 50 DRIVE STATUS FROM SHIFT REGISTER

CLEAR RK06 SUBSYSTEM WITH A SUBSYSTEM CLEAR. PUT  
RK611 CONTROLLER IN DIAGNOSTIC MODE. ISSUE A SEEK  
TO AN RK06 IN 26 SECTOR FORMAT, CYLINDER 757, HEAD 1,  
DRIVE 0. CLOCK IN DIAGNOSTIC MODE UNTIL PHASE ADDRESS  
6. TURN OFF DIAGNOSTIC MODE AND MAKE SURE SPEED LOSS,  
DRIVE AVAILABLE, VOLUME VALID, OFFSET, DRIVE READY,  
AND WRITE LOCK ARE SET.

TEST 51 DRIVE AVAILABLE SETTING

CLEAR RK06 SUBSYSTEM WITH A SUBSYSTEM CLEAR.  
PUT CONTROLLER IN DIAGNOSTIC MODE. ISSUE A SEEK TO A RK0  
26 SECTOR FORMAT TO CYLINDER 2, HEAD 0, DRIVE 0.  
CLOCK IN DIAGNOSTIC MODE UNTIL PHASE ADDRESS 6.  
TURN OFF DIAGNOSTIC MODE AND MAKE SURE DRIVE  
AVAILABLE SETS.

TEST 52 DRIVE BUS PARITY ERROR

CLEAR RK06 SUBSYSTEM WITH A SUBSYSTEM CLEAR.  
PUT CONTROLLER IN DIAGNOSTIC MODE. ISSUE A SEEK  
TO A RK06, 26 SECTOR FORMAT TO CYLINDER 3, HEAD 0,  
DRIVE 0. CLOCK IN DIAGNOSTIC MODE UNTIL PHASE ADDRESS 6.  
TURN OFF DIAGNOSTIC MODE AND MAKE SURE DRIVE BUS  
PARITY, DRIVE AVAILABLE, AND CONTROLLER ERROR ARE SET.

TEST 53 DRIVE AVAILABLE RESET ERROR

CLEAR RK06 SUBSYSTEM WITH A SUBSYSTEM CLEAR.  
PUT CONTROLLER IN DIAGNOSTIC MODE. ISSUE A SELECT  
TO A RK06, 26 SECTOR FORMAT, AND DRIVE 0.  
CLOCK IN DIAGNOSTIC MODE UNTIL PHASE ADDRESS 6.  
TURN OFF DIAGNOSTIC MODE AND MAKE SURE DRIVE AVAILABLE  
IS RESET AND CONTROLLER ERROR IS SET.

TEST 54 CDT SET DRIVE TYPE

CLEAR RK06 SUBSYSTEM WITH A SUBSYSTEM CLEAR.  
PUT CONTROLLER IN DIAGNOSTIC MODE. ISSUE A SEEK  
WITH CDT SET. 26 SECTOR FORMAT, TO CYLINDER 23,  
HEAD 0, DRIVE 0. CLOCK IN DIAGNOSTIC MODE  
UNTIL PHASE ADDRESS 6. TURN OFF DIAGNOSTIC MODE

500  
501  
502  
503  
504  
505  
506  
507  
508  
509  
510  
511  
512  
513  
514  
515  
516  
517  
518  
519  
520  
521  
522  
523  
524  
525  
526  
527  
528  
529  
530  
531  
532  
533  
534  
535  
536  
537  
538  
539  
540  
541  
542  
543  
544  
545  
546  
547  
548  
549  
550  
551  
552  
553  
554  
555

AND MAKE SURE ONLY DRIVE AVAILIABLE SETS.

TEST 55 CDT SET AND DRIVE TYPE ERROR

CLEAR RK06 SUBSYSTEM WITH A SUBSYSTEM CLEAR.  
PUT CONTROLLER IN DIAGNOSTIC MODE. ISSUE A SEEK  
WITH CDT SET, 26 SECTOR FORMAT, TO CYLINDER 2,  
HEAD 0, DRIVE 0. CLOCK IN DIAGNOSTIC MODE  
UNTIL PHASE ADDRESS 6. TURN OFF DIAGNOSTIC MODE  
AND MAKE SURE DRIVE AVAILIABLE, DRIVE TYPE ERROR,  
AND CONTROLLER ERROR SET.

TEST 56 RK06 AND DRIVE TYPE ERROR

CLEAR RK06 SUBSYSTEM WITH A SUBSYSTEM CLEAR.  
PUT CONTROLLER IN DIAGNOSTIC MODE. ISSUE A SEEK  
TO A RK06, 26 SECTOR FORMAT, TO CYLINDER 23,  
HEAD 0, DRIVE 0. CLOCK IN DIAGNOSTIC MODE  
UNTIL PHASE ADDRESS 6. TURN OFF DIAGNOSTIC  
MODE AND MAKE SURE DRIVE AVAILIABLE, DRIVE TYPE ERROR,  
AND CONTROLLER ERROR SETS.

TEST 57 SPEED LOSS FROM SHIFT REG.

CLEAR RK06 SUBSYSTEM WITH A SUBSYSTEM CLEAR.  
PUT CONTROLLER IN DIAGNOSTIC MODE. ISSUE A SEEK TO A RKO  
26 SECTOR FORMAT, TO CYLINDER 3, HEAD 1, DRIVE 0.  
CLOCK IN DIAGNOSTIC MODE UNTIL PHASE ADDRESS 6. TURN  
OFF DIAGNOSTIC MODE AND MAKE SURE DRIVE AVAILIABLE AND  
SPEED LOSS ARE SET.

TEST 60 DRIVE OFF TRACK FROM SHIFT REG.

CLEAR RK06 SUBSYSTEM WITH A SUBSYSTEM CLEAR.  
PUT CONTROLLER IN DIAGNOSTIC MODE. ISSUE A SEEK TO A RKO  
26 SECTOR FORMAT, TO CYLINDER 3, HEAD 2, DRIVE 0.  
CLOCK IN DIAGNOSTIC MODE UNTIL PHASE ADDRESS 6.  
TURN OFF DIAGNOSTIC MODE AND MAKE SURE DRIVE AVAILIABLE  
AND DRIVE OFF TRACK ARE SET.

TEST 61 WRITE LOCK ERROR FROM SHIFT REG.

CLEAR RK06 SUBSYSTEM WITH A SUBSYSTEM CLEAR.  
PUT CONTROLLER IN DIAGNOSTIC MODE. ISSUE A PACK ACKNOWLE  
TO A RK06, 26 SECTOR FORMAT, WITH CYLINDER 0,  
HEAD 1, DRIVE 0. CLOCK IN DIAGNOSTIC MODE UNTIL  
PHASE ADDRESS 6. TURN OFF DIAGNOSTIC MODE AND MAKE  
SURE SPEED LOSS, WRITE LOCK ERROR AND CONTROLLER ERROR  
ARE SET WITH DRIVE AVAILIABLE RESET.

55  
56  
57  
58  
59  
60  
61  
62  
63  
64  
65  
66  
67  
68  
69  
70  
71  
72  
73  
74  
75  
76  
77  
78  
79  
80  
81  
82  
83  
84  
85  
86  
87  
88  
89  
90  
91  
92  
93  
94  
95  
96  
97  
98  
99  
600  
601  
602  
603  
604  
605  
606  
607  
608  
609  
610  
611

## TEST 62 SEEK INCOMPLETE

CLEAR RK06 SUBSYSTEM WITH A SUBSYSTEM CLEAR.  
PUT CONTROLLER IN DIAGNOSTIC MODE. ISSUE AN UNLOAD  
TO A RK06, 26 SECTOR FORMAT, WITH CYLINDER 0,  
HEAD 1, DRIVE 0. CLOCK IN DIAGNOSTIC MODE UNTIL  
PHASE ADDRESS 6. TURN OFF DIAGNOSTIC MODE AND MAKE  
SURE SPEED LOSS, SEEK INCOMPLETE, AND CONTROLLER ERROR  
ARE SET WITH DRIVE AVAILABLE RESET.

## TEST 63 NON-EXECUTABLE DRIVE FUNCTION FROM SHIFT REG.

CLEAR RK06 SUBSYSTEM WITH A SUBSYSTEM CLEAR  
PUT CONTROLLER IN DIAGNOSTIC MODE. ISSUE  
A DRIVE CLEAR TO A RK06, 26 SECTOR FORMAT,  
WITH CYLINDER 0, HEAD 1, DRIVE 0. CLOCK IN DIAGNOSTIC  
MODE UNTIL PHASE ADDRESS 6. TURN OFF DIAGNOSTIC  
MODE AND MAKE SURE SPEED LOSS, NON-EXECUTABLE DRIVE FUNC  
CONTROLLER ERROR ARE SET WITH DRIVE AVAILABLE RESET.

## TEST 64 AC LOW AND C-D PARITY FROM SHIFT REG.

CLEAR RK06 SUBSYSTEM WITH A SUBSYSTEM CLEAR. PUT RK611  
CONTROLLER IN DIAGNOSTIC MODE. ISSUE A START SPINDLE  
TO AN RK06, IN 24 SECTOR FORMAT, CYLINDER 0, HEAD 0,  
DRIVE 0. CLOCK IN DIAGNOSTIC MODE UNTIL PHASE ADDRESS 6  
TURN OFF DIAGNOSTIC MODE AND MAKE SURE AC LOW, DRIVE  
DETECTED SERCOM PARITY, AND CONTROLLER ERROR SET WITH  
DRIVE AVAILABLE RESET.

## TEST 65 ILLEGAL DISK ADDRESS ERROR FROM SHIFT REG.

CLEAR RK06 SUBSYSTEM WITH A SUBSYSTEM CLEAR. PUT  
RK611 CONTROLLER IN DIAGNOSTIC MODE. ISSUE A RECALIBRAT  
TO AN RK06, IN 26 SECTOR FORMAT, CYLINDER 0, HEAD 1,  
DRIVE 0. CLOCK IN DIAGNOSTIC MODE UNTIL PHASE  
ADDRESS 6. TURN OFF DIAGNOSTIC MODE AND MAKE SURE  
SPEED LOSS, ILLEGAL DISK ADDRESS ERROR, AND CONTROLLER  
ERROR ARE SET WITH DRIVE AVAILABLE RESET.

## TEST 66 IDAE DETECTION IN RK611 CONTROLLER (PART 1)

CLEAR RK06 SUBSYSTEM WITH A SUBSYSTEM CLEAR. PUT  
RK611 CONTROLLER IN DIAGNOSTIC MODE. ISSUE A  
SEEK TO AN RK06 IN 26 SECTOR FORMAT, CYLINDER 1003,  
HEAD 0, DRIVE 0. CLOCK IN DIAGNOSTIC MODE UNTIL  
PHASE ADDRESS 6. TURN OFF DIAGNOSTIC MODE AND MAKE  
SURE DRIVE AVAILABLE, ILLEGAL DISK ADDRESS ERROR,  
AND CONTROLLER ERROR ARE SET.

612  
613  
614  
615  
616  
617  
618  
619  
620  
621  
622  
623  
624  
625  
626  
627  
628  
629  
630  
631  
632  
633  
634  
635  
636  
637  
638  
639  
640  
641  
642  
643  
644  
645  
646  
647  
648  
649  
650  
651  
652  
653  
654  
655  
656  
657  
658  
659  
660  
661  
662  
663  
664  
665  
666  
667

668  
669  
670  
671  
672  
673  
674  
675  
676  
677  
678  
679  
680  
681  
682  
683  
684  
685  
686  
687  
688  
689  
690  
691  
692  
693  
694  
695  
696  
697  
698  
699  
700  
701  
702  
703  
704  
705  
706  
707  
708  
709  
710  
711  
712  
713  
714  
715  
716  
717  
718  
719  
720  
721  
722  
723

## TEST 67 IDAE DETECTION IN RK611 CONTROLLER (PART 2)

CLEAR RK06 SUBSYSTEM WITH A SUBSYSTEM CLEAR. PUT RK611 CONTROLLER IN DIAGNOSTIC MODE. ISSUE A SEEK WITH CDT SET IN 26 SECTOR FORMAT, CYLINDER 1022, HEAD 0, DRIVE 0. CLOCK IN DIAGNOSTIC MODE UNTIL PHASE ADDRESS 6. TURN OFF DIAGNOSTIC MODE AND MAKE SURE DRIVE AVAILABLE AND POSITIONING IN PROGRESS ARE SET WITH ILLEGAL DISK ADDRESS ERROR RESET.

## TEST 70 IDAE DETECTION IN RK611 CONTROLLER (PART 3)

CLEAR RK06 SUBSYSTEM WITH A SUBSYSTEM CLEAR. PUT RK611 CONTROLLER IN DIAGNOSTIC MODE. ISSUE A SEEK TO AN RK06 IN 26 SECTOR FORMAT, CYLINDER 2, HEAD 3, DRIVE 0. CLOCK IN DIAGNOSTIC MODE UNTIL PHASE ADDRESS 6. TURN OFF DIAGNOSTIC MODE AND MAKE SURE DRIVE AVAILABLE, DRIVE OFF TRACK, SPEED LOSS, ILLEGAL DISK ADDRESS ERROR, AND CONTROLLER ERROR ARE SET.

## TEST 71 IDAE DETECTION IN RK611 CONTROLLER (PART 4)

CLEAR RK06 SUBSYSTEM WITH A SUBSYSTEM CLEAR. PUT RK611 CONTROLLER IN DIAGNOSTIC MODE. ISSUE A SEEK TO AN RK06 IN 26 SECTOR FORMAT, CYLINDER 3, HEAD 4, DRIVE 0. CLOCK IN DIAGNOSTIC MODE UNTIL PHASE ADDRESS 6. TURN OFF DIAGNOSTIC MODE AND MAKE SURE DRIVE AVAILABLE, UNSAFE, ILLEGAL DISK ADDRESS ERROR AND CONTROLLER ERROR ARE SET.

## TEST 72 IDAE DETECTION IN RK611 CONTROLLER (PART 5)

CLEAR RK06 SUBSYSTEM WITH A SUBSYSTEM CLEAR. PUT RK611 CONTROLLER IN DIAGNOSTIC MODE. ISSUE A SEEK WITH CDT SET IN 26 SECTOR FORMAT, CYLINDER 23, HEAD 5, DRIVE 0. CLOCK IN DIAGNOSTIC MODE UNTIL PHASE ADDRESS 6. TURN OFF DIAGNOSTIC MODE AND MAKE SURE DRIVE AVAILABLE, UNSAFE, SPEED LOSS, ILLEGAL DISK ADDRESS ERROR, AND CONTROLLER ERROR ARE SET.

## TEST 73 IDAE DETECTION IN RK611 CONTROLLER (PART 6)

CLEAR RK06 SUBSYSTEM WITH A SUBSYSTEM CLEAR. PUT RK611 CONTROLLER IN DIAGNOSTIC MODE. ISSUE A SEEK WITH CDT SET IN 26 SECTOR FORMAT, CYLINDER 23, HEAD 6, DRIVE 0. CLOCK IN DIAGNOSTIC MODE UNTIL PHASE ADDRESS 6. TURN OFF DIAGNOSTIC MODE AND MAKE SURE DRIVE AVAILABLE, UNSAFE, DRIVE OFF TRACK, ILLEGAL DISK ADDRESS ERROR, AND CONTROLLER CLEAR ARE SET.

724  
725  
726  
727  
728  
729  
730  
731  
732  
733  
734  
735  
736  
737  
738  
739  
740  
741  
742  
743  
744  
745  
746  
747  
748  
749  
750  
751  
752  
753  
754  
755  
756  
757  
758  
759  
760  
761  
762  
763  
764  
765  
766  
767  
768  
769  
770  
771  
772  
773  
774  
775  
776  
777  
778  
779

## TEST 74 NON-STANDARD MESSAGE RECEIVING

CLEAR RK06 SUBSYSTEM WITH A SUBSYSTEM CLEAR. PUT RK611 CONTROLLER IN DIAGNOSTIC MODE. ISSUE A SEEK WITH CDT SET IN 24 SECTOR FORMAT, CYLINDER 1757, HEAD 7, DRIVE 1. CLOCK IN DIAGNOSTIC MODE UNTIL PHASE ADDRESS 6. TURN OFF DIAGNOSTIC MODE AND MAKE SURE NO ERRORS SET AND DRIVE STATUS IS NOT REPORTED. REPEAT FOR DRIVES 2 AND 4.

## TEST 75 DRIVE BUS PARITY ON NON-STANDARD MESSAGE

CLEAR THE RK06 SUBSYSTEM WITH A SUBSYSTEM CLEAR. PUT THE RK611 CONTROLLER IN DIAGNOSTIC MODE. ISSUE A SEEK TO AN RK06 IN 26 SECTOR FORMAT, CYLINDER 2, HEAD 0, DRIVE 1. CLOCK IN DIAGNOSTIC MODE UNTIL PHASE ADDRESS 6. TURN OFF DIAGNOSTIC MODE AND MAKE SURE DRIVE BUS PARITY ERROR AND CONTROLLER ERROR SETS.

## TEST 76 NON-EXISTENT DRIVE (DRIVE MESSAGE TIME OUT)

CLEAR THE RK06 SUBSYSTEM WITH A SUBSYSTEM CLEAR. PUT THE RK611 CONTROLLER IN DIAGNOSTIC MODE. ISSUE A SELECT TO AN RK06 IN 26 SECTOR FORMAT, CYLINDER 0, HEAD 0, DRIVE 0. CLOCK IN DIAGNOSTIC MODE UNTIL PHASE ADDRESS 5. TURN OFF DIAGNOSTIC MODE AND MAKE SURE NON-EXISTENT DRIVE AND CONTROLLER ERROR ARE SET. THIS TEST CHECKS NON-EXISTENT DRIVE DUE TO DRIVE MESSAGE TIME OUT.

## TEST 77 NON-EXISTENT DRIVE AND NO SACK

CLEAR THE RK06 SUBSYSTEM WITH A SUBSYSTEM CLEAR. PUT THE RK611 CONTROLLER IN DIAGNOSTIC MODE. ISSUE A SELECT TO AN RK06 IN 26 SECTOR FORMAT, CYLINDER 0, HEAD 0, DRIVE 0. CLOCK IN DIAGNOSTIC MODE UNTIL PHASE ADDRESS 4. TURN OFF DIAGNOSTIC MODE AND MAKE SURE NON-EXISTENT DRIVE AND CONTROLLER ERROR ARE SET.

THIS TEST EXERCISES THE NON-EXISTENT DRIVE LOGIC DUE TO RELEASE BIT RESET AND SACK RESET BUT THE PASSING

OF THIS TEST DOES GUARENTEE THAT THIS SITUATION DID INDEED CAUSE A NON-EXISTENT DRIVE.

## \*\*ILLEGAL FUNCTION CODE TEST

## TEST 100 ILLEGAL FUNCTION CODE

CLEAR RK611 WITH A CONTROLLER CLEAR. ISSUE AN ILLEGAL COMMAND IN NORMAL MODE AND MAKE SURE COMMAND FINISHES



SETTING CONTROLLER READY WITH PROPER ERROR CONDITIONS.

6.0 ERROR REPORTING

THE GENERAL FORMAT OF ERROR REPORTS IS:

OPERATION DESCRIPTION AND ERROR DESCRIPTION

TEST	ERROR	
NUM	PC	
XXXXXX	YYYYYY	
EXPECT	ACTUAL	OTHER PERTENANT
REG	REG	INFORMATION
ZZZZZZ	WWWWW	AAAAAA

NOTE: MOVE THAN ONE SET OF EXPECT/ACTUAL REGISTERS MAY BE  
PRINTED OUT. OTHER PERTENANT INFORMATION MAY CONSIST  
OF MORE THAN ONE WORD.

%

780  
781  
782  
783  
784  
785  
786  
787  
788  
789  
790  
791  
792  
793  
794  
795  
796  
797  
798

```

799      ; *** REV 003 ***
800      .TITLE  CZR6BCD RK611 DSKLS CTRL PRT2
801      .*COPYRIGHT (C) 1976,1977
802      .*DIGITAL EQUIPMENT CORP.
803      .*MAYNARD, MASS. 01754
804      .*
805      .*PROGRAM BY ROY SPITZER
806      .*
807      .*THIS PROGRAM WAS ASSEMBLED USING THE PDP-11 MAINDEC SYSMAC
808      .*PACKAGE (MAINDEC-11-DZQAC-C3), JAN 19, 1977.
809      .*
810      .SBTTL  OPERATIONAL SWITCH SETTINGS
811      .*
812      .*          SWITCH                      USE
813      .*          -----                      -----
814      .*          15                      HALT ON ERROR
815      .*          14                      LOOP ON TEST
816      .*          13                      INHIBIT ERROR TYPEOUTS
817      .*          12                      ABORT PROGRAM AFTER 20 ERRORS
818      .*          11                      INHIBIT ITERATIONS
819      .*          10                      BELL ON ERROR
820      .*          9                       LOOP ON ERROR
821      .*          8                       LOOP ON TEST IN SWR<7:0>
822      .SBTTL  BASIC DEFINITIONS
823
824      .*INITIAL ADDRESS OF THE STACK POINTER *** 1100 ***
825      STACK= 1100
826      .EQUIV  EMT,ERROR          ;;BASIC DEFINITION OF ERROR CALL
827      .EQUIV  IOT,SCOPE         ;;BASIC DEFINITION OF SCOPE CALL
828
829      .*MISCELLANEOUS DEFINITIONS
830      HT= 11                      ;;CODE FOR HORIZONTAL TAB
831      LF= 12                      ;;CODE FOR LINE FEED
832      CR= 15                      ;;CODE FOR CARRIAGE RETURN
833      CRLF= 200                   ;;CODE FOR CARRIAGE RETURN-LINE FEED
834      PS= 177776                  ;;PROCESSOR STATUS WORD
835      .EQUIV  PS,PSW
836      STKLMT= 177774              ;;STACK LIMIT REGISTER
837      PIRQ= 177772               ;;PROGRAM INTERRUPT REQUEST REGISTER
838      DSWR= 177570               ;;HARDWARE SWITCH REGISTER
839      DDISP= 177570              ;;HARDWARE DISPLAY REGISTER
840
841      .*GENERAL PURPOSE REGISTER DEFINITIONS
842      R0= %0                      ;;GENERAL REGISTER
843      R1= %1                      ;;GENERAL REGISTER
844      R2= %2                      ;;GENERAL REGISTER
845      R3= %3                      ;;GENERAL REGISTER
846      R4= %4                      ;;GENERAL REGISTER
847      R5= %5                      ;;GENERAL REGISTER
848      R6= %6                      ;;GENERAL REGISTER
849      R7= %7                      ;;GENERAL REGISTER
850      SP= %6                      ;;STACK POINTER
851      PC= %7                      ;;PROGRAM COUNTER
852
853      .*PRIORITY LEVEL DEFINITIONS
854      PRO= 0                       ;;PRIORITY LEVEL 0

```

855	000040	PR1=	40	::	PRIORITY LEVEL	1
856	000100	PR2=	100	::	PRIORITY LEVEL	2
857	000140	PR3=	140	::	PRIORITY LEVEL	3
858	000200	PR4=	200	::	PRIORITY LEVEL	4
859	000240	PR5=	240	::	PRIORITY LEVEL	5
850	000300	PR6=	300	::	PRIORITY LEVEL	6
861	000340	PR7=	340	::	PRIORITY LEVEL	7

:"SWITCH REGISTER" SWITCH DEFINITIONS

863		SW15=	100000
864	100000	SW14=	40000
865	040000	SW13=	20000
866	020000	SW12=	10000
867	010000	SW11=	4000
868	004000	SW10=	2000
869	002000	SW09=	1000
870	001000	SW08=	400
871	000400	SW07=	200
872	000200	SW06=	100
873	000100	SW05=	40
874	000040	SW04=	20
875	000020	SW03=	10
876	000010	SW02=	4
877	000004	SW01=	2
878	000002	SW00=	1
879	000001	.EQUIV	SW09, SW9
880		.EQUIV	SW08, SW8
881		.EQUIV	SW07, SW7
882		.EQUIV	SW06, SW6
883		.EQUIV	SW05, SW5
884		.EQUIV	SW04, SW4
885		.EQUIV	SW03, SW3
886		.EQUIV	SW02, SW2
887		.EQUIV	SW01, SW1
888		.EQUIV	SW00, SW0

:"DATA BIT DEFINITIONS (BIT00 TO BIT15)

891		BIT15=	100000
892	100000	BIT14=	40000
893	040000	BIT13=	20000
894	020000	BIT12=	10000
895	010000	BIT11=	4000
896	004000	BIT10=	2000
897	002000	BIT09=	1000
898	001000	BIT08=	400
899	000400	BIT07=	200
900	000200	BIT06=	100
901	000100	BIT05=	40
902	000040	BIT04=	20
903	000020	BIT03=	10
904	000010	BIT02=	4
905	000004	BIT01=	2
906	000002	BIT00=	1
907	000001	.EQUIV	BIT09, BIT9
908		.EQUIV	BIT08, BIT8
909		.EQUIV	BIT07, BIT7
910			

```

911 .EQUIV BIT06,BIT6
912 .EQUIV BIT05,BIT5
913 .EQUIV BIT04,BIT4
914 .EQUIV BIT03,BIT3
915 .EQUIV BIT02,BIT2
916 .EQUIV BIT01,BIT1
917 .EQUIV BIT00,BIT0
918
919
920 000004 .#BASIC "CPU" TRAP VECTOR ADDRESSES
921 000010 ERRVEC= 4 ; TIME OUT AND OTHER ERRORS
922 000014 RESVEC= 10 ; RESERVED AND ILLEGAL INSTRUCTIONS
923 000014 TBITVEC=14 ; "T" BIT
924 000014 TRIVVEC= 14 ; TRACE TRAP
925 000014 BPTVEC= 14 ; BREAKPOINT TRAP (BPT)
926 000020 IOTVEC= 20 ; INPUT/OUTPUT TRAP (IOT) **SCOPE**
927 000024 PWRVEC= 24 ; POWER FAIL
928 000030 EMTVEC= 30 ; EMULATOR TRAP (EMT) **ERROR**
929 000034 TRAPVEC=34 ; "TRAP" TRAP
930 000060 TKVEC= 60 ; TTY KEYBOARD VECTOR
931 000064 TPVEC= 64 ; TTY PRINTER VECTOR
932 000240 PIRQVEC=240 ; PROGRAM INTERRUPT REQUEST VECTOR
933 000114 MEMVEC= 114 ; VECTOR FOR MEMORY CHECK ENABLE
934 172100 MEMBAS= 172100 ; BUS ADDRESS FOR MEMORY CHECK ENABLE
935 000001 PAR.EN= 1 ; MEMORY ENABLE PARITY CHECKING
936 120210 AVECT1= 120210 ; DEFINE RK611 VECTOR ADDRESS
937 000005 APRIOR= 5 ; DEFINE RK611 PRIORITY
938 177440 ABASE= 177440 ; DEFINE BASE OF RK611 REGISTERS
939
940 .SBTTL RK611 CONTROLLER REGISTER DEFINITION
941 000000 RKCS1= 0 ; CONTROL AND STATUS REGISTER 1
942 000002 RKWC= 2 ; WORD COUNT REGISTER
943 000004 RKBA= 4 ; BUS ADDRESS REGISTER
944 000006 RKDA= 6 ; DESIRED TRACK SECTOR REGISTER
945 000010 RKCS2= 10 ; CONTROL AND STATUS REGISTER 2
946 000012 RKDS= 12 ; DRIVE STATUS REGISTER
947 000014 RKER= 14 ; ERROR REGISTER
948 000016 RKASOF= 16 ; ATTENTION SUMMARY AND OFFSET REGISTER
949 000020 RKDCYL= 20 ; DESIRED CYLINDER REGISTER
950 000024 RKDB= 24 ; DATA BUFFER
951 000026 RKMR1= 26 ; MAINTENANCE REGISTER 1
952 000034 RKMR2= 34 ; MAINTENANCE REGISTER 2
953 000036 RKMR3= 36 ; MAINTENANCE REGISTER 3
954 000030 RKECPS= 30 ; ECC POSITION INFORMATION
955 000032 RKECPT= 32 ; ECC PATTERN INFORMATION
956 000022 RKSPAR= 22 ; SPARE REGISTER
957
958 .SBTTL DRIVE COMMANDS
959
960 000001 SELDRV= 01 ; SELECT DRIVE
961 000003 PACK= 03 ; PACK ACKNOWLEDGE
962 000005 CLEAR= 05 ; DRIVE CLEAR
963 000007 UNLOAD= 07 ; UNLOAD
964 000011 SRTSPL= 11 ; START SPINDLE
965 000013 RECAL= 13 ; RECALIBRATE
966 000015 OFFSET= 15 ; OFFSET

```

```

967      000017      SEEK= 17      ;SEEK
968      000021      RDATA= 21     ;READ DATA
969      000023      WRDATA= 23    ;WRITE DATA
970      000025      RDHEAD= 25    ;READ HEADER
971      000027      WRHEAD= 27    ;WRITE HEADER AND DATA
972      000031      WRTCHK= 31    ;WRITE CHECK
973      000300      INTR= 300    ;GENERATE INTERRUPT TO CPU
974
975      .SBTTL CONTROL AND STATUS REGISTER 1 BITS
976
977      000001      GO= BIT0      ;GO BIT
978      000100      IE= BIT6      ;INTERRUPT ENABLE
979      000200      ROY= BIT7     ;CONTROLLER READY
980      000400      BA16= BIT8    ;BUS ADDRESS BIT 16
981      001000      BA17= BIT9    ;BUS ADDRESS BIT 17
982      002000      CDT= BIT10   ;CONTROLLER DRIVE TYPE (0=RK06)
983      004000      CTO= BIT11   ;CONTROLLER TIMED OUT WAITING FOR
984                                     ;DRIVE RESPONSE
985      010000      CFMT= BIT12   ;CONTROLLER DRIVE FORMAT (0=26 SECTOR, 1=24 SECTOR)
986      020000      SPAR= BIT13   ;DRIVE BUS PARITY ERROR DETECTED BY CONTROLLER
987      040000      DI= BIT14    ;DRIVE INTERRUPT
988      100000      CERR= BIT15   ;CONTROLLER ERROR
989      100000      CCLR= BIT15   ;CONTROLLER CLEAR
990
991      .SBTTL CONTROL AND STATUS REGISTER 2 BITS
992
993      000007      DRVMSK= 7      ;MASK FOR DRIVE SELECTION CODE
994      000010      RLS= BIT3     ;DESELECT OR RELEASE DRIVE IN BITS 0-2
995      000020      BAI= BIT4     ;BUS ADDRESS INCREMENT INHIBIT
996      000040      SCLR= BIT5    ;CLEAR CONTROLLER AND ALL DRIVES
997      000100      IR= BIT6      ;INPUT READY
998      000200      OR= BIT7      ;OUTPUT READY
999      000400      UFE= BIT8     ;UNIT FIELD ERROR
1000     001000      MDS= BIT9     ;MULTIPLE DRIVE SELECT
1001     002000      PGE= BIT10    ;PROGRAMMING ERROR
1002     004000      NEM= BIT11    ;NON-EXISTENT MEMORY
1003     010000      NED= BIT12    ;NON-EXISTENT DRIVE
1004     020000      UPE= BIT13    ;UNIBUS PARITY ERROR
1005     040000      WCE= BIT14    ;WRITE CHECK ERROR
1006     100000      DLT= BIT15    ;DATA LATE ERROR
1007
1008     .SBTTL ERROR REGISTER BIT DEFINITION
1009
1010     000001      ILF= BIT0      ;ILLEGAL FUNCTION CODE
1011     000002      SKI= BIT1      ;SEEK INCOMPLETE
1012     000004      NXF= BIT2      ;NON-EXECUTABLE DRIVE FUNCTION
1013     000010      DRPAR= BIT3    ;DRIVE DETECTED DRIVE BUS PARITY ERROR
1014     000020      FMTE= BIT4    ;FORMAT ERROR
1015     000040      DTYE= BIT5    ;DRIVE TYPE ERROR
1016     000100      ECH= BIT6      ;ECC HARD
1017     000200      BSE= BIT7      ;BAD SECTOR ERROR
1018     000400      HVRC= BIT8     ;HEADER VRC ERROR
1019     001000      COE= BIT9      ;CYLINDER ADDRESS OVERFLOW ERROR
1020     002000      IOAE= BIT10   ;INVALID DISK ADDRESS ERROR
1021     004000      WLE= BIT11    ;WRITE LOCK ERROR
1022     010000      DTE= BIT12    ;DRIVE TIMING ERROR

```

```

1023      020000      OPI=      BIT13      ; OPERATION (SEARCH) INCOMPLETE
1024      040000      UNS=      BIT14      ; DRIVE UNSAFE
1025      100000      DCK=      BIT15      ; DATA CHECK
1026
1027      .SBTTL      STATUS REGISTER BIT DEFINITION
1028
1029      000001      DRA=      BIT0      ; DRIVE AVAILABLE (CONTROLLER IS SET IF
1030                                     ; THIS BIT IS RESET)
1031      000004      OFST=      BIT2      ; DRIVE OFFSET
1032      000010      ACLO=      BIT3      ; AC LOW
1033      000020      SPDLS=      BIT4      ; SPEED LOSS
1034      000040      DROT=      BIT5      ; DRIVE OFF TRACK
1035      000100      VV=      BIT6      ; VOLUME VALID
1036      000200      DRDY=      BIT7      ; DRIVE READY
1037      000400      DDT=      BIT8      ; DRIVE TYPE (0=RK06)
1038      004000      WRL=      BIT11     ; WRITE LOCK
1039      020000      PIP=      BIT13     ; POSITIONING IN PROGRESS
1040      040000      DSC=      BIT14     ; DRIVE STATUS CHANGE
1041      100000      SVAL=      BIT15     ; STATUS VALID
1042
1043      .SBTTL      MAINTENANCE REGISTER 1 BIT DEFINITION
1044
1045      000017      MESMSK= 17      ; MESSAGE MASK
1046
1047      000020      PAT=      BIT4      ; FORCE EVEN PARITY ON DRIVE MESSAGE LINES
1048      000040      DMD=      BITS      ; DIAGNOSTIC MODE
1049      000100      MSP=      BIT6      ; MAINTENANCE SECTOR PULSE
1050      000200      MIND=      BIT7      ; MAINTENANCE INDEX
1051      000400      MCLK=      BIT8      ; MAINTENANCE CLOCK
1052      001000      MERD=      BIT9      ; MAINTENANCE ENCODED READ DATA
1053      002000      MEWD=      BIT10     ; MAINTENANCE ENCODED WRITE DATA
1054      004000      PCA=      BIT11     ; PRECOMPENSATION ADVANCE
1055      010000      PCD=      BIT12     ; PRECOMPENSATION DELAY
1056      020000      ECCW=      BIT13     ; ECC WORD IS BEING READ OR WRITTEN
1057      040000      WRTGAT= BIT14     ; WRITE GATE
1058      100000      RDGATE= BIT15     ; READ GATE
1059
1060      .SBTTL      TRANSMITTED MESSAGE A
1061
1062      000020      S. SEEK= BIT4      ; SEEK COMMAND
1063      000040      S. RECL= BITS      ; RECALIBRATE COMMAND
1064      000100      S. STSP= BIT6      ; START SPINDLE COMMAND
1065      000200      S. RTC=  BIT7      ; DRIVE RETURN TO CENTERLINE COMMAND
1066      000400      S. CLR=  BIT8      ; CLEAR ERROR AND DSC
1067      001000      S. FMT= BIT9      ; FORMAT
1068      002000      S. UNLD= BIT10     ; UNLOAD
1069      004000      S. PACK= BIT11     ; SET VOLUME VALID (PACK ACKNOWLEDGE)
1070
1071      .SBTTL      TRAP CATCHER
1072      000000      .=0
1073      ; *ALL UNUSED LOCATIONS FROM 4 - 776 CONTAIN A ".+2,HALT"
1074      ; *SEQUENCE TO CATCH ILLEGAL TRAPS AND INTERRUPTS
1075      ; *LOCATION 0 CONTAINS 0 TO CATCH IMPROPERLY LOADED VECTORS
1076      000174      .=174
1077      000174      000000      DISPREG: .WORD 0      ; SOFTWARE DISPLAY REGISTER
1078      000176      000000      SWREG:   .WORD 0      ; SOFTWARE SWITCH REGISTER

```

1079  
1080 000200 000137 004316  
1081 000204 000137 004306  
1082 000214 000214  
1083 000214 000137 004276  
1084  
1085  
1086  
1087  
1088 000220  
1089 000046  
1090 000046 042340  
1091 000052  
1092 000052 000000  
1093 000220  
1094 001000  
1095  
1096  
1097  
1098  
1099  
1100 001000  
1101 000024  
1102 000024 000200  
1103 000044  
1104 000044 001000  
1105 001000  
1106  
1107  
1108  
1109  
1110 001000  
1111 001000 000000  
1112 001002 001214  
1113 001004 000001  
1114 001006 000007  
1115 001010 000007  
1116 001012 000032

```
.SBTTL STARTING ADDRESS(ES)
JMP @*START ;; JUMP TO STARTING ADDRESS OF PROGRAM
JMP RESTRT ;; JUMP TO RESTART ROUTINE
.=214
JMP PARM ;; JUMP TO OPERATOR ASSIGNED PARMETERS
.SBTTL ACT11 HOOKS
;*****
;HOOKS REQUIRED BY ACT11
$SVPC=. ;SAVE PC
.=46
$ENDAD ;;1)SET LOC.46 TO ADDRESS OF $ENDAD IN .SEOP
.=52
.WORD 0 ;;2)SET LOC.52 TO ZERO
.= $SVPC ;; RESTORE PC
.=1000
.SBTTL APT PARAMETER BLOCK
;*****
;SET LOCATIONS 24 AND 44 AS REQUIRED FOR APT
;*****
.$X=. ;;SAVE CURRENT LOCATION
.=24 ;;SET POWER FAIL TO POINT TO START OF PROGRAM
200 ;;FOR APT START UP
.=44 ;;POINT TO APT INDIRECT ADDRESS PNTR.
$APTHDR ;;POINT TO APT HEADER BLOCK
.=.$X ;;RESET LOCATION COUNTER
;*****
;SETUP APT PARAMETER BLOCK AS DEFINED IN THE APT-PDP11 DIAGNOSTIC
;INTERFACE SPEC.
$APTHD:
$HIPTS: .WORD 0 ;;TWO HIGH BITS OF 18 BIT MAILBOX ADDR.
$MBADR: .WORD $MAIL ;;ADDRESS OF APT MAILBOX (BITS 0-15)
$STMT: .WORD 1 ;;RUN TIM OF LONGEST TEST
$PASTM: .WORD 7 ;;RUN TIME IN SECS. OF 1ST PASS ON 1 UNIT (QUICK VERIFY)
$UNITM: .WORD 7 ;;ADDITIONAL RUN TIME (SECS) OF A PASS FOR EACH ADDITIONAL UNIT
.WORD $ETEND-$MAIL/2 ;;LENGTH MAILBOX-ETABLE(WORDS)
```

1117  
1118  
1119  
1120  
1121  
1122  
1123 001100  
1124 001100  
1125 001100 000000  
1126 001102 000  
1127 001103 000  
1128 001104 000000  
1129 001106 000000  
1130 001110 000000  
1131 001112 000000  
1132 001114 000  
1133 001115 001  
1134 001116 000000  
1135 001120 000000  
1136 001122 000000  
1137 001124 000000  
1138 001126 000000  
1139 001130 000000  
1140 001132 000000  
1141 001134 000  
1142 001135 000  
1143 001136 000000  
1144 001140 177570  
1145 001142 177570  
1146 001144 177560  
1147 001146 177562  
1148 001150 177564  
1149 001152 177566  
1150 001154 000  
1151 001155 002  
1152 001156 012  
1153 001157 000  
1154 001160 000000  
1155 001162 000000  
1156 001164 000000  
1157 001166 000000  
1158 001170 000000  
1159 001172 000000  
1160 001174 000000  
1161 001176 000000  
1162 001200 000000  
1163 001202 000000  
1164 001204 177607 000377  
1165 001210 077  
1166 001211 015  
1167 001212 000012  
1168  
1169  
1170  
1171  
1172

.SBTTL COMMON TAGS

```

;*****
;THIS TABLE CONTAINS VARIOUS COMMON STORAGE LOCATIONS
;USED IN THE PROGRAM.

```

```

SCMTAG:      =1100                ;; START OF COMMON TAGS
              .WORD 0
$STNM:       .BYTE 0              ;; CONTAINS THE TEST NUMBER
$ERFLG:      .BYTE 0              ;; CONTAINS ERROR FLAG
$ICNT:       .WORD 0              ;; CONTAINS SUBTEST ITERATION COUNT
$LPADR:      .WORD 0              ;; CONTAINS SCOPE LOOP ADDRESS
$LPERR:      .WORD 0              ;; CONTAINS SCOPE RETURN FOR ERRORS
$ERTTL:      .WORD 0              ;; CONTAINS TOTAL ERRORS DETECTED
$ITEMB:      .BYTE 0              ;; CONTAINS ITEM CONTROL BYTE
$ERMAX:      .BYTE 1              ;; CONTAINS MAX. ERRORS PER TEST
$ERRPC:      .WORD 0              ;; CONTAINS PC OF LAST ERROR INSTRUCTION
$GDADR:      .WORD 0              ;; CONTAINS ADDRESS OF 'GOOD' DATA
$BDADR:      .WORD 0              ;; CONTAINS ADDRESS OF 'BAD' DATA
$GDDAT:      .WORD 0              ;; CONTAINS 'GOOD' DATA
$BDDAT:      .WORD 0              ;; CONTAINS 'BAD' DATA
              .WORD 0              ;; RESERVED--NOT TO BE USED
$AUTOB:      .BYTE 0              ;; AUTOMATIC MODE INDICATOR
$INTAG:      .BYTE 0              ;; INTERRUPT MODE INDICATOR
              .WORD 0
$SWR:        .WORD DSWR           ;; ADDRESS OF SWITCH REGISTER
$DISP:       .WORD DDISP          ;; ADDRESS OF DISPLAY REGISTER
$TKS:        177560               ;; TTY KBD STATUS
$TKB:        177562               ;; TTY KBD BUFFER
$TPS:        177564               ;; TTY PRINTER STATUS REG. ADDRESS
$TPB:        177566               ;; TTY PRINTER BUFFER REG. ADDRESS
$NULL:       .BYTE 0              ;; CONTAINS NULL CHARACTER FOR FILLS
$FILLS:      .BYTE 2              ;; CONTAINS # OF FILLER CHARACTERS REQUIRED
$FILLC:      .BYTE 12            ;; INSERT FILL CHARS. AFTER A "LINE FEED"
$STPFLG:     .BYTE 0              ;; "TERMINAL AVAILABLE" FLAG (BIT<07>=0=YES)
$STMP0:      .WORD 0              ;; USER DEFINED
$STMP1:      .WORD 0              ;; USER DEFINED
$STMP2:      .WORD 0              ;; USER DEFINED
$STMP3:      .WORD 0              ;; USER DEFINED
$STMP4:      .WORD 0              ;; USER DEFINED
$STMP5:      .WORD 0              ;; USER DEFINED
$STMP6:      .WORD 0              ;; USER DEFINED
$STMP7:      .WORD 0              ;; USER DEFINED
$TIMES:      0                    ;; MAX. NUMBFR OF ITERATIONS
$ESCAPE:     0                    ;; ESCAPE ON ERROR ADDRESS
$BELL:       .ASCIZ <207><377><377> ;; CODE FOR BELL
$QUES:       .ASCII /?/           ;; QUESTION MARK
$CRLF:       .ASCII <15>          ;; CARRIAGE RETURN
$LF:         .ASCIZ <12>          ;; LINE FEED
;*****

```

.SBTTL APT MAILBOX-ETABLE

```

;*****
.EVEN

```



1173	001214		\$MAIL:		:: APT MAILBOX
1174	001214	000000	\$MSGTY:	.WORD	AMSGTY
1175	001216	000000	\$FATAL:	.WORD	AFATAL
1176	001220	000000	\$TESTN:	.WORD	ATESTN
1177	001222	000000	\$PASS:	.WORD	APASS
1178	001224	000000	\$DEVCT:	.WORD	ADEVCT
1179	001226	000000	\$UNIT:	.WORD	AUNIT
1180	001230	000000	\$MSGAD:	.WORD	AMSGAD
1181	001232	000000	\$MSGLG:	.WORD	AMSGLG
1182	001234		\$ETABLE:		:: APT ENVIRONMENT TABLE
1183	001234	000	\$ENV:	.BYTE	AENV
1184	001235	000	\$ENVM:	.BYTE	AENVM
1185	001236	000000	\$SWREG:	.WORD	ASWREG
1186	001240	000000	\$USWR:	.WORD	AUSWR
1187	001242	000000	\$CPUOP:	.WORD	ACPUOP
1188			*		BITS 15-11=CPU TYPE
1189			*		11/04=01, 11/05=02, 11/20=03, 11/40=04, 11/45=05
1190			*		11/70=06, PDQ=07, Q=10
1191			*		BIT 10=REAL TIME CLOCK
1192			*		BIT 9=FLOATING POINT PROCESSOR
1193			*		BIT 8=MEMORY MANAGEMENT
1194	001244	000	\$MAMS1:	.BYTE	AMAMS1
1195	001245	000	\$MTYP1:	.BYTE	AMTYP1
1196			*		MEM. TYPE BLK#1
1197			*		MEM. TYPE BYTE -- (HIGH BYTE)
1198			*		900 NSEC CORE=001
1199			*		300 NSEC BIPOLAR=002
1200	001246	000000	\$MADR1:	.WORD	AMADR1
1201			*		500 NSEC MOS=003
1202	001250	000	\$MAMS2:	.BYTE	AMAMS2
1203	001251	000	\$MTYP2:	.BYTE	AMTYP2
1204	001252	000000	\$MADR2:	.WORD	AMADR2
1205	001254	000	\$MAMS3:	.BYTE	AMAMS3
1206	001255	000	\$MTYP3:	.BYTE	AMTYP3
1207	001256	000000	\$MADR3:	.WORD	AMADR3
1208	001260	000	\$MAMS4:	.BYTE	AMAMS4
1209	001261	000	\$MTYP4:	.BYTE	AMTYP4
1210	001262	000000	\$MADR4:	.WORD	AMADR4
1211	001264	120210	\$VECT1:	.WORD	AVECT1
1212	001266	000000	\$VECT2:	.WORD	AVECT2
1213	001270	177440	\$BASE:	.WORD	ABASE
1214	001272	000000	\$DEVN:	.WORD	ADEVN
1215	001274	000000	\$CDW1:	.WORD	ACDW1
1216	001276	000000	\$CDW2:	.WORD	ACDW2
1217	001300		\$ETEND:		:: CONTROLLER DESCRIPTION WORD#1
1218			.MEXIT		:: CONTROLLER DESCRIPTION WORD#2

1219  
1220  
1221  
1222  
1223  
1224  
1225  
1226  
1227  
1228  
1229  
1230  
1231  
1232  
1233  
1234  
1235  
1236  
1237  
1238  
1239  
1240  
1241  
1242  
1243  
1244  
1245  
1246  
1247  
1248  
1249  
1250  
1251  
1252  
1253  
1254  
1255  
1256  
1257  
1258  
1259  
1260  
1261  
1262  
1263  
1264  
1265  
1266  
1267  
1268  
1269  
1270  
1271  
1272  
1273  
1274

.SBTTL ERROR POINTER TABLE

;\*THIS TABLE CONTAINS THE INFORMATION FOR EACH ERROR THAT CAN OCCUR.  
;\*THE INFORMATION IS OBTAINED BY USING THE INDEX NUMBER FOUND IN  
;\*LOCATION \$ITEMB. THIS NUMBER INDICATES WHICH ITEM IN THE TABLE IS PERTINENT.  
;\*NOTE1: IF \$ITEMB IS 0 THE ONLY PERTINENT DATA IS (\$ERRPC).  
;\*NOTE2: EACH ITEM IN THE TABLE CONTAINS 4 POINTERS EXPLAINED AS FOLLOWS:

```

;*      EM      ;;POINTS TO THE ERROR MESSAGE
;*      DH      ;;POINTS TO THE DATA HEADER
;*      DT      ;;POINTS TO THE DATA
;*      DF      ;;POINTS TO THE DATA FORMAT
    
```

\$ERRTB:

```

;EMIN:  ERROR 1: ATTEMPTING TO SET CMD BIT DRIVE MESS A
        0
        DT001
        DF001
;      ERROR 2: ATTEMPTING A SELECT OF DRIVE NUM - CS1 INCORRECT
        EM106
        EM2003
        DT002
        DF002
;      ERROR 3: ATTEMPTING A SELECT OF DRIVE NUM - DRIVE NUM INCORRECT
        EM106
        EM2004
        DT002
        DF002
;      ERROR 4: ATTEMPTING A SELECT OF DRIVE NUM - MESSAGE A INCORRECT
        EM106
        EM2001
        DT002
        DF002
;      ERROR 5: ATTEMPTING A SELECT OF DRIVE NUM - MESSAGE B INCORRECT
        EM106
        EM2002
        DT002
        DF002
;      ERROR 6: ATTEMPTING A SELECT WITH HEAD ADD - CS1 INCORRECT
        EM107
        EM2003
        DT006
        DF006
;      ERROR 7: ATTEMPTING A SELECT WITH HEAD ADD - HEAD INCORRECT
        EM107
        EM2005
        DT006
        DF006
;      ERROR 10: ATTEMPTING A SELECT WITH HEAD ADD - MESSAGE A INCORRECT
        EM107
        EM2001
        DT006
        DF006
;      ERROR 11: ATTEMPTING A SELECT WITH HEAD ADD - MESSAGE B INCORRECT
    
```

```

001300
001300 000000
001302 000000
001304 046520
001306 047154
001310 052410
001312 057141
001314 046540
001316 047210
001320 052410
001322 057204
001324 046540
001326 047210
001330 052410
001332 057063
001334 046540
001336 047210
001340 052410
001342 057112
001344 046540
001346 047210
001350 052514
001352 057141
001354 046562
001356 047244
001360 052514
001362 057255
001364 046562
001366 047244
001370 052514
001372 057063
001374 046562
001376 047244
    
```

1275	001400	052514	EM107
1276	001402	057112	EM2002
1277	001404	046562	DT006
1278	001406	047244	DF006
1279			ERROR 12: ATTEMPTING A SELECT WITH MESS SELECT BITS - CS1 INCORRECT
1280	001410	052611	EM108
1281	001412	057141	EM2003
1282	001414	046604	DT012
1283	001416	047300	DF012
1284			ERROR 13: ATTEMPTING A SELECT WITH MESS SELECT BITS - MR1 INCORRECT
1285	001420	052611	EM108
1286	001422	057322	EM2006
1287	001424	046604	DT012
1288	001426	047300	DF012
1289			ERROR 14: ATTEMPTING A SELECT WITH MESS SELECT BITS - MESS SELECT CODE INCORRECT
1290	001430	052611	EM108
1291	001432	057351	EM2007
1292	001434	046604	DT012
1293	001436	047300	DF012
1294			ERROR 15: ATTEMPTING A SELECT WITH MESS SELECT BITS - MESS A INCORRECT
1295	001440	052611	EM108
1296	001442	057063	EM2001
1297	001444	046604	DT012
1298	001446	047300	DF012
1299			ERROR 16: ATTEMPTING A SELECT WITH MESS SELECT BITS - MESS B INCORRECT
1300	001450	052611	EM108
1301	001452	057112	EM2002
1302	001454	046604	DT012
1303	001456	047300	DF012
1304			ERROR 17: ATTEMPTING A SEEK TO AN RK06 - CS1 INCORRECT
1305	001460	052711	EM109
1306	001462	057141	EM2003
1307	001464	046632	DT017
1308	001466	047334	DF017
1309			ERROR 20: ATTEMPTING A SEEK TO AN RK06 - SEEK BIT IN MESS A NOT SET
1310	001470	052711	EM109
1311	001472	057005	EM2000
1312	001474	046632	DT017
1313	001476	047334	DF017
1314			ERROR 21: ATTEMPTING A SEEK TO AN RK06 - CYLINDER ADD INCORRECT IN MESS B
1315	001500	052711	EM109
1316	001502	057421	EM2008
1317	001504	046632	DT017
1318	001506	047334	DF017
1319			ERROR 22: ATTEMPTING A SEEK TO AN RK06 - MESSAGE A INCORRECT
1320	001510	052711	EM109
1321	001512	057063	EM2001
1322	001514	046632	DT017
1323	001516	047334	DF017
1324			ERROR 23: ATTEMPTING A SEEK TO AN RK06 - MESSAGE B INCORRECT
1325	001520	052711	EM109
1326	001522	057112	EM2002
1327	001524	046632	DT017
1328	001526	046632	DT017
1329			ERROR 24: ATTEMPTING A SEEK WITH CDT SET - CS1 INCORRECT
1330	001530	052764	EM110

1331	001532	057141	EM2003
1332	001534	046632	DT017
1333	001536	047334	DF017
1334			ERROR 25: ATTEMPTING A SEEK TO AN RKK07 - SEEK BIT IN MESS A NOT SET
1335	001540	052764	EM110
1336	001542	057005	EM2000
1337	001544	046632	DT017
1338	001546	047334	DF017
1339			ERROR 26: ATTEMPTING A SEEK WITH CDT SET
1340			CYLINDER ADD INCORRECT IN MESS B
1341	001550	052764	EM110
1342	001552	057421	EM2008
1343	001554	046632	DT017
1344	001556	047334	DF017
1345			ERROR 27: ATTEMPTING A SEEK WITH CDT SET - MESSAGE A INCORRECT
1346	001560	052764	EM110
1347	001562	057063	EM2001
1348	001564	046632	DT017
1349	001566	047334	DF017
1350			ERROR 30: ATTEMPTING A SEEK WITH CDT SET - MESSAGE B INCORRECT
1351	001570	052764	EM110
1352	001572	057112	EM2002
1353	001574	046632	DT017
1354	001576	047334	DF017
1355			ERROR 31: ATTEMPTING OFFSET - CS1 INCORRECT
1356	001600	053041	EM111
1357	001602	057141	EM2003
1358	001604	046654	DT031
1359	001606	047370	DF031
1360			ERROR 32: ATTEMPTING OFFSET - OFFSET BITS INCORRECT
1361	001610	053041	EM111
1362	001612	057472	EM2009
1363	001614	046654	DT031
1364	001616	047370	DF031
1365			ERROR 33: ATTEMPTING OFFSET - MESS A INCORRECT
1366	001620	053041	EM111
1367	001622	057063	EM2001
1368	001624	046654	DT031
1369	001626	047370	DF031
1370			ERROR 34: ATTEMPTING OFFSET - MESS B INCORRECT
1371	001630	053041	EM111
1372	001632	057063	EM2001
1373	001634	046654	DT031
1374	001636	047370	DF031
1375			ERROR 35: ATTEMPTING COMMAND WITH NON-ZERO CYL ADD AND OFFSET-
1376			CS1 INCORRECT
1377	001640	053104	EM112
1378	001642	057141	EM2003
1379	001644	046676	DT035
1380	001646	047424	DF035
1381			ERROR 36: ATTEMPTING COMMAND WITH NON-ZERO CYL ADD AND OFFSET-
1382			DRIVE COMMAND BIT NOT SET IN MESS A
1383	001650	053104	EM112
1384	001652	057005	EM2000
1385	001654	046676	DT035
1386	001656	047424	DF035



1443	001770	053351	EM114	
1444	001772	057063	EM2001	
1445	001774	046722	DT050	
1446	001776	047460	DF050	
1447	:	:	ERROR 51:	ATTEMPTING TO SHIFT DRIVE MESSAGE
1448	:	:		SHIFT REG B INCORRECT
1449	002000	053351	EM114	
1450	002002	057112	EM2002	
1451	002004	046722	DT050	
1452	002006	047460	DF050	
1453	:	:	ERROR 52:	ATTEMPTING TO GENERATE ODD PARITY ON SELECT DRIVE MESSAGE
1454	:	:		PARITY ON MESSAGE A INCORRECT
1455	002010	053414	EM115	
1456	002012	057543	EM2010	
1457	002014	046744	DT052	
1458	002016	047514	DF052	
1459	:	:	ERROR 53:	ATTEMPTING TO GENERATE ODD PARITY ON SELECT DRIVE MESSAGE
1460	:	:		PARITY ON MESSAGE B INCORRECT
1461	002020	053414	EM115	
1462	002022	057605	EM2011	
1463	002024	046744	DT052	
1464	002026	047514	DF052	
1465	:	:	ERROR 54:	ATTEMPTING TO GENERATE ODD PARITY ON SELECT DRIVE MESSAGE
1466	:	:		MESSAGE A INCORRECT
1467	002030	053414	EM115	
1468	002032	057063	EM2001	
1469	002034	046744	DT052	
1470	002036	047514	DF052	
1471	:	:	ERROR 55:	ATTEMPTING TO GENERATE ODD PARITY ON SELECT DRIVE MESSAGE
1472	:	:		MESSAGE B INCORRECT
1473	002040	053414	EM115	
1474	002042	057112	EM2002	
1475	002044	046744	DT052	
1476	002046	047514	DF052	
1477	:	:	ERROR 56:	ATTEMPTING TO GENERATE EVEN PARITY ON SELECT DRIVE MESSAGE
1478	:	:		PARITY ON MESSAGE A INCORRECT
1479	002050	053506	EM116	
1480	002052	057543	EM2010	
1481	002054	046744	DT052	
1482	002056	047514	DF052	
1483	:	:	ERROR 57:	ATTEMPTING TO GENERATE EVEN PARITY ON SELECT DRIVE MESSAGE
1484	:	:		PARITY ON MESSAGE IS INCORRECT
1485	002060	053506	EM116	
1486	002062	057605	EM2011	
1487	002064	046744	DT052	
1488	002066	047514	DF052	
1489	:	:	ERROR 60:	ATTEMPTING TO GENERATE EVEN PARITY ON SELECT DRIVE MESSAGE
1490	:	:		MESSAGE A INCORRECT
1491	002070	053506	EM116	
1492	002072	057063	EM2001	
1493	002074	046744	DT052	
1494	002076	047514	DF052	
1495	:	:	ERROR 61:	ATTEMPTING TO GENERATE EVEN PARITY ON SELECT DRIVE MESSAGE
1496	:	:		MESSAGE B INCORRECT
1497	002100	053506	EM116	
1498	002102	057112	EM2002	

1499	002104	046744	DT052	
1500	002106	047514	DF052	
1501			ERROR 62:	ATTEMPTING COMPLETE EXECUTION OF DESELECT DRIVE IN
1502				MAINT MODE - COMMAND AND STATUS REG 1 INCORRECT.
1503	002110	053601	EM117	
1504	002112	057141	EM2003	
1505	002114	046760	DT062	
1506	002116	047540	DF062	
1507			ERROR 63:	ATTEMPTING COMPLETE EXECUTION OF DESELECT DRIVE IN
1508				MAINT MODE - COMMAND AND STATUS REG 2 INCORRECT.
1509	002120	053601	EM117	
1510	002122	057647	EM2012	
1511	002124	046760	DT062	
1512	002126	047540	DF062	
1513			ERROR 64:	ATTEMPTING COMPLETE EXECUTION OF DESELECT DRIVE IN
1514				MAINT MODE - ERROR REG. INCORRECT.
1515	002130	053601	EM117	
1516	002132	057712	EM2013	
1517	002134	046760	DT062	
1518	002136	047540	DF062	
1519			ERROR 65:	ATTEMPTING COMPLETE EXECUTION OF SELECT DRIVE IN
1520				MAINT MODE - COMMAND AND STATUS REGISTER 1 INCORRECT AT
1521				PHASE ADDRESS 4
1522	002140	053716	EM118	
1523	002142	057736	EM2014	
1524	002144	047004	DT065	
1525	002146	047564	DF065	
1526			ERROR 66:	ATTEMPTING COMPLETE EXECUTION OF SELECT DRIVE IN
1527				MAINT MODE - COMMAND AND STATUS REG 1 INVALID DURING
1528				COMMAND EXECUTION.
1529	002150	053716	EM118	
1530	002152	060024	EM2015	
1531	002154	047004	DT065	
1532	002156	047564	DF065	
1533			ERROR 67:	ATTEMPTING COMPLETE EXECUTION OF SELECT DRIVE IN
1534				MAINT MODE - MAINTENANCE REG 2 UNEXPECTEDLY CHANGED
1535				DURING COMMAND EXECUTION.
1536	002160	053716	EM118	
1537	002162	060116	EM2016	
1538	002164	047014	DT067	
1539	002166	047610	DF067	
1540			ERROR 70:	ATTEMPTING COMPLETE EXECUTION OF SELECT DRIVE IN
1541				MAINT MODE - MAINTENANCE REG 3 UNEXPECTEDLY CHANGED
1542				DURING COMMAND EXECUTION.
1543	002170	053716	EM118	
1544	002172	060216	EM2017	
1545	002174	047014	DT067	
1546	002176	047610	DF067	
1547			ERROR 71:	ATTEMPTING COMPLETE EXECUTION OF SELECT DRIVE IN
1548				MAINT MODE - COMMAND AND STATUS REG 1 INCORRECT.
1549	002200	053716	EM118	
1550	002202	057141	EM2003	
1551	002204	046760	DT062	
1552	002206	047540	DF062	
1553			ERROR 72:	ATTEMPTING COMPLETE EXECUTION OF SELECT DRIVE IN
1554				MAINT MODE - COMMAND AND STATUS REG. 2 INCORRECT.

1555	002210	053716	EM118	
1556	002212	057647	EM2012	
1557	00221 <sup>U</sup>	046760	DT062	
1558	002216	047540	DF062	
1559			ERROR 73:	ATTEMPTING COMPLETE EXECUTION OF SELECT DRIVE IN MAINT MODE - ERROR REGISTER INCORRECT.
1560			:	
1561	002220	053716	EM118	
1562	002222	057712	EM2013	
1563	002224	046760	DT062	
1564	002226	047540	DF062	
1565			ERROR 74:	ATTEMPTING EXECUTION OF DESELECT DRIVE AT NORMAL SPEED - COMMAND AND STATUS REG. 1 INCORRECT.
1566			:	
1567	002230	054031	EM119	
1568	002232	057063	EM2001	
1569	002234	046760	DT062	
1570	002236	047540	DF062	
1571			ERROR 75:	ATTEMPTING EXECUTION OF DESELECT DRIVE AT NORMAL SPEED - COMMAND AND STATUS REG. 2 INCORRECT.
1572			:	
1573	002240	054031	EM119	
1574	002242	057647	EM2012	
1575	002244	046760	DT062	
1576	002246	047540	DF062	
1577			ERROR 76:	ATTEMPTING EXECUTION OF DESELECT DRIVE AT NORMAL SPEED - ERROR REG INCORRECT.
1578			:	
1579	002250	054031	EM119	
1580	002252	057712	EM2013	
1581	002254	046760	DT062	
1582	002256	047540	DF062	
1583			ERROR 77:	ATTEMPTING TO WRITE CS1 IN MAINT MODE - CS1 INCORRECT
1584	002260	054120	EM120	
1585	002262	057141	EM2003	
1586	002264	047004	DT065	
1587	002266	047564	DF065	
1588			ERROR 100:	ATTEMPTING EXECUTION OF DESELECT DRIVE WITH IE SET INTERRUPT DID NOT OCCUR.
1589			:	
1590	002270	054214	EM121	
1591	002272	060316	EM2018	
1592	002274	047030	DT100	
1593	002276	047634	DF100	
1594			ERROR 101:	ATTEMPTING EXECUTION OF DESELECT DRIVE WITH IE SET CS1 INCORRECT AFTER INTERRUPT.
1595			:	
1596	002300	054214	EM121	
1597	002302	060346	EM2019	
1598	002304	046760	DT062	
1599	002306	047540	DF062	
1600			ERROR 102:	ATTEMPTING EXECUTION OF DESELECT DRIVE WITH IE SET CS2 INCORRECT AFTER INTERRUPT.
1601			:	
1602	002310	054214	EM121	
1603	002312	060431	EM2020	
1604	002314	046760	DT062	
1605	002316	047540	DF062	
1606			ERROR 103:	ATTEMPTING EXECUTION OF DESELECT DRIVE WITH IE SET ERROR REGISTER IN CORRECT AFTER INTEPRUPT
1607			:	
1608	002320	054214	EM121	
1609	002322	060514	EM2021	
1610	002324	046760	DT062	



1611	002326	047540	DF062		
1612			ERROR 104:	ATTEMPTING EXECUTION OF DESELECT DRIVE WITH IE SET	
1613			:	INTERRJPT DID NOT CLEAR IN RK611	
1614	002330	054214	EM121		
1615	002332	060565	EM2022		
1616	002334	047030	DT100		
1617	002336	047634	DF100		
1618			ERROR 105:	ATTEMPTING DESELECT COMMAND AFTER WRITING SILO	
1619			:	TO CHECK GO CLEAR-CS2 INCORRECT	
1620			:		
1621	002340	054315	EM122		
1622	002342	057647	EM2012		
1623	002344	046760	DT062		
1624	002346	047540	DF062		
1625			ERROR 106:	ATTEMPTING DESELECT COMMAND AFTER WRITING SILO	
1626			:	TO CHECK GO CLEAR-DATA LATE DID NOT OCCUR WHEN	
1627			:	READING SILO	
1628	002350	054315	EM122		
1629	002352	060626	EM2023		
1630	002354	046760	DT062		
1631	002356	047540	DF062		
1632			ERROR 107:	ATTEMPTING COMPLETE EXECUTION OF SEEK IN MAINT MODE	
1633			:	COMMAND AND STATUS REG 1 INCORRECT AT PHASE ADDRESS 4	
1634	002360	054416	EM123		
1635	002362	057736	EM2014		
1636	002364	047004	DT065		
1637	002366	047564	DF065		
1638			ERROR 110:	ATTEMPTING COMPLETE EXECUTION OF SEEK IN MAINT MODE	
1639			:	COMMAND AND STATUS REG 1 INVALID DURING COMMAND EXECUTION	
1640	002370	054416	EM123		
1641	002372	060024	EM2015		
1642	002374	047004	DT065		
1643	002376	047564	DF065		
1644			:		
1645			ERROR 111:	ATTEMPTING COMPLETE EXECUTION OF SEEK IN MAINT MODE	
1646			:	MAINTENANCE REG 2 UNEXPECTEDLY CHANGED DURING COMMAND EXECUTION	
1647	002400	054416	EM123		
1648	002402	060116	EM2016		
1649	002404	047014	DT067		
1650	002406	047610	DF067		
1651			ERROR 112:	ATTEMPTING COMPLETE EXECUTION OF SEEK IN MAINT MODE	
1652			:	MAINTENANCE REG 3 UNEXPECTEDLY CHANGED DURING COMMAND EXECUTION	
1653	002410	054416	EM123		
1654	002412	060216	EM2017		
1655	002414	047014	DT067		
1656	002416	047610	DF067		
1657			ERROR 113:	ATTEMPTING COMPLETE EXECUTION OF SEEK IN MAINT MODE	
1658			:	COMMAND AND STATUS REG. 1 INCORRECT	
1659	002420	054416	EM123		
1660	002422	057141	EM2003		
1661	002424	046760	DT062		
1662	002426	047540	DF062		
1663			ERROR 114:	ATTEMPTING COMPLETE EXECUTION OF SEEK IN MAINT MODE	
1664			:	COMMAND AND STATUS REG. 2 INCORRECT	
1665	002430	054416	EM123		
1666	002432	057647	EM2012		

1667	002434	046760	DT062	
1668	002436	047540	DF062	
1669			ERROR 115:	ATTEMPTING COMPLETE EXECUTION OF SEEK IN MAINT MODE
1670				ERROR REGISTER INCORRECT
1671	002440	054416	EM123	
1672	002442	057712	EM2013	
1673	002444	046760	DT062	
1674	002446	047540	DF062	
1675			ERROR 116:	ATTEMPTING SELECT DRIVE IN MAINT MODE
1676				COMMAND AND STATUS REG. 1 INCORRECT
1677	002450	054502	EM124	
1678	002452	057141	EM2003	
1679	002454	046520	DT001	
1680	002456	047154	DF001	
1681			ERROR 117:	ATTEMPTING SELECT DRIVE IN MAINT MODE
1682				DRIVE SELECT CODE IN MESSAGE INCORRECT
1683	002460	054502	EM124	
1684	002462	057204	EM2004	
1685	002464	046520	DT001	
1686	002466	047154	DF001	
1687			ERROR 120:	ATTEMPTING SELECT DRIVE IN MAINT MODE
1688				DRIVE COMMAND BITS IN MESSAGE INCORRECT
1689	002470	054502	EM124	
1690	002472	060700	EM2024	
1691	002474	046520	DT001	
1692	002476	047154	DF001	
1693			ERROR 121:	ATTEMPTING SELECT DRIVE IN MAINT MODE
1694				HEAD ADD CODE IN MESSAGE A INCORRECT
1695	002500	054502	EM124	
1696	002502	057255	EM2005	
1697	002504	046520	DT001	
1698	002506	047154	DF001	
1699			ERROR 122:	ATTEMPTING SELECT DRIVE IN MAINT MODE
1700				PARITY BIT IN MESSAGE INCORRECT
1701	002510	054502	EM124	
1702	002512	057543	EM2010	
1703	002514	046520	DT001	
1704	002516	047154	DF001	
1705			ERROR 123:	ATTEMPTING SELECT DRIVE IN MAINT MODE
1706				MESS SELECT CODE IN MESSAGE IN CORRECT
1707	002520	054502	EM124	
1708	002522	057351	EM2007	
1709	002524	046520	DT001	
1710	002526	047154	DF001	
1711			ERROR 124:	ATTEMPTING SELECT DRIVE IN MAINT MODE
1712				CYLINDER AND BITS IN MESSAGE IS INCORRECT
1713	002530	054502	EM124	
1714	002532	057421	EM2008	
1715	002534	046520	DT001	
1716	002536	047154	DF001	
1717			ERROR 125:	ATTEMPTING SELECT DRIVE IN MAINT MODE
1718				PARITY BIT IN MESSAGE IS INCORRECT
1719	002540	054502	EM124	
1720	002542	057605	EM2011	
1721	002544	046520	DT001	
1722	002546	047154	DF001	

1723			:	ERROR 126:	ATTEMPTING COMPLETE EXECUTION OF DESELECT DRIVE IN
1724			:		MAINT MODE - DRIVE STATUS REG INCORRECT
1725	002550	053601	:	EM117	
1726	002552	060750	:	EM2025	
1727	002554	046760	:	DT062	
1728	002556	047540	:	DF062	
1729			:	ERROR 127:	ATTEMPTING EXECUTION OF SELECT DRIVE IN
1730			:		MAINT MODE - DRIVE STATUS REG INCORRECT
1731	002560	053716	:	EM118	
1732	002562	060750	:	EM2025	
1733	002564	046760	:	DT062	
1734	002566	047540	:	DF062	
1735			:	ERROR 130:	ATTEMPTING EXECUTION OF DESELECT DRIVE AT NORMAL
1736			:		SPEED - DRIVE STATUS REG INCORRECT
1737	002570	054031	:	EM119	
1738	002572	060750	:	EM2025	
1739	002574	046760	:	DT062	
1740	002576	047540	:	DF062	
1741			:	ERROR 131:	ATTEMPTING COMPLETE EXECUTION OF SEEK IN MAINT MODE
1742			:		DRIVE STATUS REG INCORRECT
1743	002600	054416	:	EM123	
1744	002602	060750	:	EM2025	
1745	002604	046760	:	DT062	
1746	002606	047540	:	DF062	
1747			:	ERROR 132:	ATTEMPTING TO FORCE DRA,SPDLSS,VV,OFST,DRDY,WRL
1748			:		CONTROLLER READY DID NOT SET
1749	002610	054550	:	EM125	
1750	002612	061010	:	EM2026	
1751	002614	047030	:	DT100	
1752	002616	047634	:	DF100	
1753			:	ERROR 133:	ATTEMPTING TO FORCE DRA,SPDLSS,VV,OFST,DRDY,WRL
1754			:		LOAD STATUS DID NOT LOAD DRIVE STATUS REF
1755	002620	054550	:	EM125	
1756	002622	061045	:	EM2027	
1757	002624	046760	:	DT062	
1758	002626	047540	:	DF062	
1759			:	ERROR 134:	ATTEMPTING TO FORCE DRA,SPDLSS,VV,OFST,DRDY,WRL
1760			:		CS1 INCORRECT
1761	002630	054550	:	EM125	
1762	002632	057141	:	EM2003	
1763	002634	046760	:	DT062	
1764	002636	047540	:	DF062	
1765			:	ERROR 135:	ATTEMPTING TO FORCE DRA,SPDLSS,VV,OFST,DRDY,WRL
1766			:		CS2 INCORRECT
1767	002640	054550	:	EM125	
1768	002642	057647	:	EM2012	
1769	002644	046760	:	DT062	
1770	002646	047540	:	DF062	
1771			:	ERROR 136:	ATTEMPTING TO FORCE DRA,SPDLSS,VV,OFST,DRDY,WL
1772			:		ERROR REG. INCORRECT
1773	002650	054550	:	EM125	
1774	002652	057712	:	EM2013	
1775	002654	046760	:	DT062	
1776	002656	047540	:	DF062	
1777			:	ERROR 137:	ATTEMPTING TO FORCE DRA,SPDLSS,VV,OFST,DRDY,WL
1778			:		DRIVE STATUS REG. INCORRECT

# J03

CZR6BCD RK611 DSKLS CTRL PRT2  
CZR6BC.P11 02-DEC-77 09:22

MACY11 30(1046) 02-DEC-77 09:31 PAGE 35  
ERROR POINTER TABLE

SEQ 0035

1779	002660	054550	EM125	
1780	002662	060750	EM2025	
1781	002664	046760	DT062	
1782	002666	047540	DF062	
1783	:	:	ERROR 140:	ATTEMPTING TO FORCE DRIVE AVAILIABLE
1784	:	:		CS1 INCORRECT
1785	002670	054767	EM126	
1786	002672	057141	EM2003	
1787	002674	046760	DT062	
1788	002676	047540	DF062	
1789	:	:	ERROR 141:	ATTEMPTING TO FORCE DRIVE AVAILABLE
1790	:	:		CS2 INCORRECT
1791	002700	054767	EM126	
1792	002702	057647	EM2012	
1793	002704	046760	DT062	
1794	002706	047540	DF062	
1795	:	:	ERROR 142:	ATTEMPTING TO FORCE DRIVE AVAILIABLE
1796	:	:		DRIVE STATUS REC INCORRECT
1797	002710	054767	EM126	
1798	002712	060750	EM2025	
1799	002714	046760	DT062	
1800	002716	047540	DF062	
1801	:	:	ERROR 143:	ATTEMPTING TO FORCE DRIVE AVAIVABLE
1802	:	:		ERROR REGISTER INCORRECT
1803	002720	054767	EM126	
1804	002722	057712	EM2013	
1805	002724	046760	DT062	
1806	002726	047540	DF062	
1807	:	:	ERROR 144:	ATTEMPTING TO FORCE DRIVE BUS PARITY ERROR DETECTED BY RK611
1808	:	:		CS1 INCORRECT
1809	002730	055034	EM127	
1810	002732	057141	EM2003	
1811	002734	046760	DT062	
1812	002736	047540	DF062	
1813	:	:	ERROR 145:	ATTEMPTING TO FORCE DRIVE BUS PARITY ERROR DETECTED BY RK611
1814	:	:		CS2 INCORRECT
1815	002740	055034	EM127	
1816	002742	057647	EM2012	
1817	002744	046760	DT062	
1818	002746	047540	DF062	
1819	:	:	ERROR 146:	ATTEMPTING TO FORCE DRIVE BUS PARITY ERROR DETECTED BY RK611
1820	:	:		DRIVE STATUS REG INCORRECT
1821	002750	055034	EM127	
1822	002752	060750	EM2025	
1823	002754	046760	DT062	
1824	002756	047540	DF062	
1825	:	:	ERROR 147:	ATTEMPTING TO FORCE DRIVE BUS PARITY ERROR DETECTED BY RK611
1826	:	:		ERROR REC INCORRECT
1827	002760	055034	EM127	
1828	002762	057712	EM2013	
1829	002764	046760	DT062	
1830	002766	047540	DF062	
1831	:	:	ERROR 150:	ATTEMPTING TO FORCE DRIVE AVAILIABLE RESET ERROR
1832	:	:		CS1 INCORRECT
1833	002770	055132	EM128	
1834	002772	057141	EM2003	

1835	002774	046760	DT062	
1836	002776	047540	DF062	
1837			ERROR 151:	ATTEMPTING TO FORCE DRIVE AVAILABLE RESET ERROR
1838				CS2 INCORRECT
1839	003000	055132	EM128	
1840	003002	057647	EM2012	
1841	003004	046760	DT062	
1842	003006	047540	DF062	
1843			ERROR 152:	ATTEMPTING TO FORCE DRIVE AVAILABLE RESET ERROR
1844				DRIVE STATUS REG. INCORRECT
1845	003010	055132	EM128	
1846	003012	060750	EM2025	
1847	003014	046760	DT062	
1848	003016	047540	DF062	
1849			ERROR 153:	ATTEMPTING TO FORCE DRIVE AVAILABLE RESET ERROR
1850				ERROR REG. INCORRECT
1851	003020	055132	EM128	
1852	003022	057712	EM2013	
1853	003024	046760	DT062	
1854	003026	047540	DF062	
1855			ERROR 154:	TESTING CDT SET DRIVE TYPE DETECTION
1856				CS1 INCORRECT
1857	003030	055213	EM129	
1858	003032	057141	EM2003	
1859	003034	046760	DT062	
1860	003036	047540	DF062	
1861			ERROR 155:	TESTING CDT SET DRIVE TYPE DETECTION
1862				CS2 INCORRECT
1863	003040	055213	EM129	
1864	003042	057647	EM2012	
1865	003044	046760	DT062	
1866	003046	047540	DF062	
1867			ERROR 156:	TESTING CDT SET DRIVE TYPE DETECTION
1868				DRIVE STATUS REG INCORRECT
1869	003050	055213	EM129	
1870	003052	060750	EM2025	
1871	003054	046760	DT062	
1872	003056	047540	DF062	
1873			ERROR 157:	TESTING CDT SET DRIVE TYPE DETECTION
1874				ERROR REG INCORRECT
1875	003060	055213	EM129	
1876	003062	057712	EM2013	
1877	003064	046760	DT062	
1878	003066	047540	DF062	
1879			ERROR 160:	ATTEMPTING TO FORCE DRIVE TYPE ERROR ADDRESSING RK06
1880				CS1 INCORRECT
1881	003070	055260	EM130	
1882	003072	057141	EM2003	
1883	003074	046760	DT062	
1884	003076	047540	DF062	
1885			ERROR 161:	ATTEMPTING TO FORCE DRIVE TYPE ERROR ADDRESSING RK06
1886				CS2 INCORRECT
1887	003100	055260	EM130	
1888	003102	057647	EM2012	
1889	003104	046760	DT062	
1890	003106	047540	DF062	

1891			:	ERROR 162:	ATTEMPTING TO FORCE DRIVE TYPE ERROR ADDRESSING RK06
1892			:		DRIVE STATUS REG INCORRECT
1893	003110	055260	:	EM130	
1894	003112	060750	:	EM2025	
1895	003114	046760	:	DT062	
1896	003116	047540	:	DF062	
1897			:	ERROR 163:	ATTEMPTING TO FORCE DRIVE TYPE ERROR ADDRESSING RK06
1898			:		ERROR REG INCORRECT
1899	003120	055260	:	EM130	
1900	003122	057712	:	EM2013	
1901	003124	046760	:	DT062	
1902	003126	047540	:	DF062	
1903			:	ERROR 164:	ATTEMPTING TO FORCE DRIVE TYPE ERROR WITH CTD SET
1904			:		CSI INCORRECT
1905	003130	055342	:	EM131	
1906	003132	057141	:	EM2003	
1907	003134	046760	:	DT062	
1908	003136	047540	:	DF062	
1909			:	ERROR 165:	ATTEMPTING TO FORCE DRIVE TYPE ERROR WITH CDT SET
1910			:		CS2 INCORRECT
1911	003140	055442	:	EM131	
1912	003142	057647	:	EM2012	
1913	003144	046760	:	DT062	
1914	003146	047540	:	DF062	
1915			:	ERROR 166:	ATTEMPTING TO FORCE DRIVE TYPE ERROR WITH CDT SET
1916			:		DRIVE STATUS REG INCORRECT
1917	003150	055342	:	EM131	
1918	003152	060750	:	EM2025	
1919	003154	046760	:	DT062	
1920	003156	047540	:	DF062	
1921			:	ERROR 167:	ATTEMPTING TO FORCE DRIVE TYPE ERROR WITH CDT SET
1922			:		ERROR REG INCORRECT
1923	003160	055342	:	EM131	
1924	003162	057712	:	EM2013	
1925	003164	046760	:	DT062	
1926	003166	047540	:	DF062	
1927			:	ERROR 170:	ATTEMPTING TO FORCE SPEED LOSS
1928			:		CSI INCORRECT
1929	003170	055427	:	EM132	
1930	003172	057141	:	EM2003	
1931	003174	046760	:	DT062	
1932	003176	047540	:	DF062	
1933			:	ERROR 171:	ATTEMPTING TO FORCE SPEED LOSS
1934			:		CS2 INCORRECT
1935	003200	055427	:	EM132	
1936	003202	057647	:	EM2012	
1937	003204	046760	:	DT062	
1938	003206	047540	:	DF062	
1939			:	ERROR 172:	ATTEMPTING TO FORCE SPEED LOSS
1940			:		DRIVE STATUS REG INCORRECT
1941	003210	055427	:	EM132	
1942	003212	060750	:	EM2025	
1943	003214	046760	:	DT062	
1944	003216	047540	:	DF062	
1945			:	ERROR 173:	ATTEMPTING TO FORCE SPEED LOSS
1946			:		ERROR REG. INCORRECT

M03

CZR6BCO RK611 DSKLS CTRL PRT2  
CZR6BC.P11 02-DEC-77 09:22

MACY11 30(1046) 02-DEC-77 09:31 PAGE 38  
ERROR POINTER TABLE

SEQ 0038

1947	003220	055427	EM132	
1948	003222	057712	EM2013	
1949	003224	046760	DT062	
1950	003226	047540	DF062	
1951	:	:	ERROR 174:	ATTEMPTING TO FORCE DRIVE OFF TRACK
1952	:	:		CS1 INCORRECT
1953	003230	055466	EM133	
1954	003232	057141	EM2003	
1955	003234	046760	DT062	
1956	003236	047540	DF062	
1957	:	:	ERROR 175:	ATTEMPTING TO FORCE DRIVE OFF TRACK
1958	:	:		CS2 INCORRECT
1959	003240	055466	EM133	
1960	003242	057647	EM2012	
1961	003244	046760	DT062	
1962	003246	047540	DF062	
1963	:	:	ERROR 176:	ATTEMPTING TO FORCE DRIVE OFF TRACK
1964	:	:		DRIVE STATUS REG INCORRECT
1965	003250	055466	EM133	
1966	003252	060750	EM2025	
1967	003254	046760	DT062	
1968	003256	047540	DF062	
1969	:	:	ERROR 177:	ATTEMPTING TO FORCE DRIVE OFF TRACK
1970	:	:		ERROR REG INCORRECT
1971	003260	055466	EM133	
1972	003262	057712	EM2013	
1973	003264	046760	DT062	
1974	003266	047540	DF062	
1975	:	:	ERROR 200:	ATTEMPTING TO FORCE WRITE LOCK ERROR
1976	:	:		CS1 INCORRECT
1977	003270	055532	EM134	
1978	003272	057141	EM2003	
1979	003274	046760	DT062	
1980	003276	047540	DF062	
1981	:	:	ERROR 201:	ATTEMPTING TO FORCE WRITE LOCK ERROR
1982	:	:		CS2 INCORRECT
1983	003300	055532	EM134	
1984	003302	057647	EM2012	
1985	003304	046760	DT062	
1986	003306	047540	DF062	
1987	:	:	ERROR 202:	ATTEMPTING TO FORCE WRITE LOCK ERROR
1988	:	:		DRIVE STATUS REG INCORRECT
1989	003310	055532	EM134	
1990	003312	060750	EM2025	
1991	003314	046760	DT062	
1992	003316	047540	DF062	
1993	:	:	ERROR 203:	ATTEMPTING TO FORCE WRITE LOCK ERROR
1994	:	:		ERROR REG INCORRECT
1995	003320	055532	EM134	
1996	003322	057712	EM2013	
1997	003324	046760	DT062	
1998	003326	047540	DF062	
1999	:	:	ERROR 204:	ATTEMPTING TO FORCE SEEK INCOMPLETE
2000	:	:		CS1 INCORRECT
2001	003330	055577	EM135	
2002	003332	057141	EM2003	

2003	003334	046760	DT062	
2004	003336	047540	DF062	
2005			ERROR 205:	ATTEMPTING TO FORCE SEEK INCOMPLETE
2006				CS2 INCORRECT
2007	003340	055577	EM135	
2008	003342	057647	EM2012	
2009	003344	046760	DT062	
2010	003346	047540	DF062	
2011			ERROR 206:	ATTEMPTING TO FORCE SEEK INCOMPLETE
2012				DRIVE STATUS REG INCORRECT
2013	003350	055577	EM135	
2014	003352	060750	EM2025	
2015	003354	046760	DT062	
2016	003356	047540	DF062	
2017			ERROR 207:	ATTEMPTING TO FORCE SEEK INCOMPLETE
2018				ERROR REG INCORRECT
2019	003360	055577	EM135	
2020	003362	057712	EM2013	
2021	003364	046760	DT062	
2022	003366	047540	DF062	
2023			ERROR 210:	ATTEMPTING TO FORCE NON-EXECUTABLE FUNCTION
2024				CS1 INCORRECT
2025	003370	055643	EM136	
2026	003372	057141	EM2003	
2027	003374	046760	DT062	
2028	003376	047540	DF062	
2029			ERROR 211:	ATTEMPTING TO FORCE NON-EXECUTABLE FUNCTION
2030				CS2 INCORRECT
2031	003400	055643	EM136	
2032	003402	057647	EM2012	
2033	003404	046760	DT062	
2034	003406	047540	DF062	
2035			ERROR 212:	ATTEMPTING TO FORCE NON-EXECUTABLE FUNCTION
2036				DRIVE STATUS REG INCORRECT
2037	003410	055643	EM136	
2038	003412	060750	EM2025	
2039	003414	046760	DT062	
2040	003416	047540	DF062	
2041			ERROR 213:	ATTEMPTING TO FORCE NON-EXECUTABLE FUNCTION
2042				ERROR REG INCORRECT
2043	003420	055643	EM136	
2044	003422	057712	EM2013	
2045	003424	046760	DT062	
2046	003426	047540	DF062	
2047			ERROR 214:	ATTEMPTING TO FORCE AC JW AND C-D PARITY ERROR
2048				CS1 INCORRECT
2049	003430	055717	EM137	
2050	003432	057141	EM2003	
2051	003434	046760	DT062	
2052	003436	047540	DF062	
2053			ERROR 215:	ATTEMPTING TO FORCE AC LOW AND C-D PARITY ERROR
2054				CS2 INCORRECT
2055	003440	055717	EM137	
2056	003442	057647	EM2012	
2057	003444	046760	DT062	
2058	003446	047540	DF062	



2059	:	:	ERROR 216:	ATTEMPTING TO FORCE AC LOW AND C-D PARITY ERROR
2060	:	:		DRIVE STATUS REG INCORRECT
2061	003450	055717	EM137	
2062	003452	060750	EM2025	
2063	003454	046760	DT062	
2064	003456	047540	DF062	
2065	:	:	ERROR 217:	ATTEMPTING TO FORCE AC LOW AND C-D PARITY ERROR
2066	:	:		ERROR REG INCORRECT
2067	003460	055717	EM137	
2068	003462	057712	EM2013	
2069	003464	046760	DT062	
2070	003466	047540	DF062	
2071	:	:	ERROR 220:	ATTEMPTING TO FORCE ILLEGAL DISK ADDRESS ERROR (DRIVE)
2072	:	:		CS1 INCORRECT
2073	003470	055777	EM138	
2074	003472	057141	EM2003	
2075	003474	046760	DT062	
2076	003476	047540	DF062	
2077	:	:	ERROR 221:	ATTEMPTING TO FORCE ILLEGAL DISK ADDRESS ERROR (DRIVE)
2078	:	:		CS2 INCORRECT
2079	003500	055777	EM138	
2080	003502	057647	EM2012	
2081	003504	046760	DT062	
2082	003506	047540	DF062	
2083	:	:	ERROR 222:	ATTEMPTING TO FORCE ILLEGAL DISK ADDRESS ERROR (DRIVE)
2084	:	:		DRIVE STATUS REG INCORRECT
2085	003510	055777	EM138	
2086	003512	060750	EM2025	
2087	003514	046760	DT062	
2088	003516	047540	DF062	
2089	:	:	ERROR 223:	ATTEMPTING TO FORCE ILLEGAL DISK ADDRESS ERROR (DRIVE)
2090	:	:		ERROR REG INCORRECT
2091	003520	055777	EM138	
2092	003522	057712	EM2013	
2093	003524	046760	DT062	
2094	003526	047540	DF062	
2095	:	:	ERROR 224:	ATTEMPTING TO CLEAR RK611 WITH A CONTROLLER CLEAR
2096	:	:		CS1 INCORRECT
2097	003530	056107	EM139	
2098	003532	057141	EM2003	
2099	003534	047044	DT224	
2100	003536	047674	DF224	
2101	:	:	ERROR 225:	ATTEMPTING TO CLEAR RK611 WITH A CONTROLLER CLEAR
2102	:	:		CS2 INCORRECT
2103	003540	056107	EM139	
2104	003542	057647	EM2012	
2105	003544	047044	DT224	
2106	003546	047674	DF224	
2107	:	:	ERROR 226:	ATTEMPTING TO CLEAR RK611 WITH A CONTROLLER CLEAR
2108	:	:		DRIVE STATUS REG INCORRECT
2109	003550	056107	EM139	
2110	003552	060750	EM2025	
2111	003554	047044	DT224	
2112	003556	047674	DF224	
2113	:	:	ERROR 227:	ATTEMPTING TO CLEAR RK611 WITH A CONTROLLER CLEAR
2114	:	:		ERROR REG INCORRECT

2115	003560	056107	EM139
2116	003562	057712	EM2013
2117	003564	047044	DT224
2118	003566	047674	DF224
2119	:	:	ERROR 230: TESTING ILLEGAL DISK ADDRESS ERROR LOGIC IN RK611
2120	:	:	CSI INCORRECT
2121	003570	056171	EM140
2122	003572	057141	EM2003
2123	003574	047100	DT230
2124	003576	047730	DF230
2125	:	:	ERROR 231: TESTING ILLEGAL DISK ADDRESS ERROR LOGIC IN RK611
2126	:	:	CS2 INCORRECT
2127	003600	056171	EM140
2128	003602	057647	EM2012
2129	003604	047100	DT230
2130	003606	047730	DF230
2131	:	:	ERROR 232: TESTING ILLEGAL DISK ADDRESS ERROR LOGIC IN RK611
2132	:	:	DRIVE STATUS REG INCORRECT
2133	003610	056171	EM140
2134	003612	060750	EM2025
2135	003614	047100	DT230
2136	003616	047730	DF230
2137	:	:	ERROR 233: TESTING ILLEGAL DISK ADDRESS ERROR LOGIC IN RK611
2138	:	:	ERROR REGISTER
2139	003620	056171	EM140
2140	003622	057712	EM2013
2141	003624	047100	DT230
2142	003626	047730	DF230
2143	:	:	ERROR 234: ATTEMPTING TO RECEIVE NON-STANDARD MESSAGES
2144	:	:	CSI INCORRECT
2145	003630	056253	EM141
2146	003632	057141	EM2003
2147	003634	046760	DT062
2148	003636	047540	DF062
2149	:	:	ERROR 235: ATTEMPTING TO RECEIVE NON-STANDARD MESSAGES
2150	:	:	CS2 INCORRECT
2151	003640	056253	EM141
2152	003642	057647	EM2012
2153	003644	046760	DT062
2154	003646	047540	DF062
2155	:	:	ERROR 236: ATTEMPTING TO RECEIVE NON-STANDARD MESSAGES
2156	:	:	DRIVE STATUS REG. INCORRECT
2157	003650	056253	EM141
2158	003652	060750	EM2025
2159	003654	046760	DT062
2160	003656	047540	DF062
2161	:	:	ERROR 237: ATTEMPTING TO RECEIVE NON-STANDARD MESSAGES
2162	:	:	ERROR REG. INCORRECT
2163	003660	056253	EM141
2164	003662	057712	EM2013
2165	003664	046760	DT062
2166	003666	047540	DF062
2167	:	:	ERROR 240: ATTEMPTING TO RECEIVE NON-STANDARD MESSAGES WITH
2168	:	:	BAD PARITY - CSI INCORRECT
2169	003670	056327	EM142
2170	003672	057141	EM2003

2171	003674	046760	DT062	
2172	003676	047540	DF062	
2173			ERROR 241:	ATTEMPTING TO RECEIVE NON-STANDARD MESSAGES WITH
2174				BAD PARITY - CS2 INCORRECT
2175	003700	056327	EM142	
2176	003702	057647	EM2012	
2177	003704	046760	DT062	
2178	003706	047540	DF062	
2179			ERROR 242:	ATTEMPTING TO RECEIVE NON-STANDARD MESSAGES WITH
2180				BAD PARITY - DRIVE STATUS REG. INCORRECT
2181	003710	056327	EM142	
2182	003712	060750	EM2025	
2183	003714	046760	DT062	
2184	003716	047540	DF062	
2185			ERROR 243:	ATTEMPTING TO RECEIVE NON-STANDARD MESSAGES WITH
2186				BAD PARITY - ERROR ERROR INCOMPLETE
2187	003720	056327	EM142	
2188	003722	057712	EM2013	
2189	003724	046760	DT062	
2190	003726	047540	DF062	
2191			ERROR 244:	ATTEMPTING TO FORCE NON-EXISTENT DRIVE (DRIVE BUS TIMEOUT)
2192				CS1 INCORRECT
2193	003730	056425	EM143	
2194	003732	057141	EM2003	
2195	003734	046760	DT062	
2196	003736	047540	DF062	
2197			ERROR 245:	ATTEMPTING TO FORCE NON-EXISTENT DRIVE (DRIVE BUS TIMEOUT)
2198				CS2 INCORRECT
2199	003740	056425	EM143	
2200	003742	057647	EM2012	
2201	003744	046760	DT062	
2202	003746	047540	DF062	
2203			ERROR 246:	ATTEMPTING TO FORCE NON-EXISTENT DRIVE (DRIVE BUS TIMEOUT)
2204				DRIVE STATUS REG INCORRECT
2205	003750	056425	EM143	
2206	003752	060750	EM2025	
2207	003754	046760	DT062	
2208	003756	047540	DF062	
2209			ERROR 247:	ATTEMPTING TO FORCE NON-EXISTENT DRIVE (DRIVE BUS TIMEOUT)
2210				ERROR REG INCORRECT
2211	003760	056425	EM143	
2212	003762	057712	EM2013	
2213	003764	046760	DT062	
2214	003766	047540	DF062	
2215			ERROR 250:	ATTEMPTING TO FORCE NON-EXISTENT DRIVE (NO SACK)
2216				CS1 INCORRECT
2217	003770	056520	EM144	
2218	003772	057141	EM2003	
2219	003774	046760	DT062	
2220	003776	047540	DF062	
2221			ERROR 251:	ATTEMPTING TO FORCE NON-EXISTENT DRIVE (NO SACK)
2222				CS2 INCORRECT
2223	004000	056520	EM144	
2224	004002	057647	EM2012	
2225	004004	046760	DT062	
2226	004006	047540	DF062	

2227			:	ERROR 252: ATTEMPTING TO FORCE NON-EXISTENT DRIVE (NO SACK)
2228			:	DRIVE STATUS REG INCORRECT
2229	004010	056520	:	EM144
2230	004012	060750	:	EM2025
2231	004014	046760	:	DT062
2232	004016	047540	:	DF062
2233			:	ERROR 253: ATTEMPTING TO FORCE NON-EXISTENT DRIVE (NO SACK)
2234			:	ERROR REG INCORRECT
2235	004020	056520	:	EM144
2236	004022	057712	:	EM2013
2237	004024	046760	:	DT062
2238	004026	047540	:	DF062
2239			:	ERROR 254: ATTEMPTING EXECUTION OF DESELECT DRIVE WITH IE RESET
2240			:	UNEXPECTED INTERRUPT OCCURRED
2241	004030	056601	:	EM145
2242	004032	061120	:	EM2028
2243	004034	047030	:	DT100
2244	004036	047634	:	DF100
2245			:	ERROR 255: ATTEMPTING EXECUTION FO DESELECT DRIVE WITH IE RESET
2246			:	INTERRUPT OCCURRED WHEN INTERRUPT ENABLE SET
2247	004040	056601	:	EM145
2248	004042	061156	:	EM2029
2249	004044	047030	:	DT100
2250	004046	047634	:	DF100
2251			:	ERROR 256: ATTEMPTING TO EXECUTE AN ILLEGAL FUNCTION
2252			:	CSI INCORRECT
2253	004050	056666	:	EM146
2254	004052	057141	:	EM2003
2255	004054	047132	:	DT256
2256	004056	047764	:	DF256
2257			:	ERROR 257: ATTEMPTING TO EXECUTE AN ILLEGAL FUNCTION
2258			:	ERROR REG INCORRECT
2259	004060	056666	:	EM146
2260	004062	057712	:	EM2013
2261	004064	047132	:	DT256
2262	004066	047764	:	DF256
2263			:	ERROR 260: ATTEMPTING TO CLEAR ILLEGAL FUNCTION - CSI INCORRECT
2264	004070	056740	:	EM147
2265	004072	057141	:	EM2003
2266	004074	047132	:	DT256
2267	004076	047764	:	DF256
2268			:	ERROR 261: ATTEMPTING TO CLEAR ILLEGAL FUNCTION - ERROR REG INCORRECT
2269	004100	056740	:	EM147
2270	004102	057712	:	EM2013
2271	004104	047132	:	DT256
2272	004106	047764	:	DF256
2273			:	ERROR 262: UNEXPECTED MEMORY PARITY ERROR TRAP
2274	004110	051766	:	EM000
2275	004112	050240	:	DM000C
2276	004114	046514	:	DT000
2277	004116	047150	:	DF000

```

2278      .SBTTL  TEMPORARY STORAGE FOR RK611 CONTROLLER REGISTER
2279
2280 004120 000000 T.CS1: .WORD 0 ;CONTROL AND STATUS REGISTER 1
2281 004122 000000 T.WC: .WORD 0 ;WORD COUNT REGISTER
2282 004124 000000 T.BA: .WORD 0 ;BUS ADDRESS REGISTER
2283 004126 000000 T.DA: .WORD 0 ;DESIRED TRACK SECTOR REGISTER
2284 004130 000000 T.CS2: .WORD 0 ;CONTROL AND STATUS REGISTER 2
2285 004132 000000 T.DS: .WORD 0 ;DRIVE STATUS REGISTER
2286 004134 000000 T.ER: .WORD 0 ;ERROR REGISTER
2287 004136 000000 T.ASOF: .WORD 0 ;ATTENTION SUMMARY AND OFFSET REGISTER
2288 004140 000000 T.DCYL: .WORD 0 ;DESIRED CYLINDER REGISTER
2289 004142 000000 T.DB: .WORD 0 ;DATA BUFFER
2290 004144 000000 T.MR1: .WORD 0 ;MAINTENANCE REGISTER 1
2291 004146 000000 T.MR2: .WORD 0 ;MAINTENANCE REGISTER 2
2292 004150 000000 T.MR3: .WORD 0 ;MAINTENANCE REGISTER 3
2293 004152 000000 T.ECPS: .WORD 0 ;ECC POSITION INFORMATION
2294 004154 000000 T.ECPT: .WORD 0 ;ECC PATTERN INFORMATION
2295 004156 000000 T.SPARE: .WORD 0 ;SPARE REGISTER
2296
2297      .SBTTL  EXPECTED RK611 CONTROLLER REGISTERS
2298
2299 004160 000000 E.CS1: .WORD 0 ;CONTROL AND STATUS REGISTER 1
2300 004162 000000 E.WC: .WORD 0 ;WORD COUNT REGISTER
2301 004164 000000 E.BA: .WORD 0 ;BUS ADDRESS REGISTER
2302 004166 000000 E.DA: .WORD 0 ;DESIRED TRACK SECTOR REGISTER
2303 004170 000000 E.CS2: .WORD 0 ;CONTROL AND STATUS REGISTER 2
2304 004172 000000 E.DS: .WORD 0 ;DRIVE STATUS REGISTER
2305 004174 000000 E.ER: .WORD 0 ;ERROR REGISTER
2306 004176 000000 E.ASOF: .WORD 0 ;ATTENTION SUMMARY AND OFFSET REGISTER
2307 004200 000000 E.DCYL: .WORD 0 ;DESIRED CYLINDER REGISTER
2308 004202 000000 E.DB: .WORD 0 ;DATA BUFFER
2309 004204 000000 E.MR1: .WORD 0 ;MAINTENANCE REGISTER 1
2310 004206 000000 E.MR2: .WORD 0 ;MAINTENANCE REGISTER 2
2311 004210 000000 E.MR3: .WORD 0 ;MAINTENANCE REGISTER 3
2312 004212 000000 E.ECPS: .WORD 0 ;ECC POSITION INFORMATION
2313 004214 000000 E.ECPT: .WORD 0 ;ECC PATTERN INFORMATION
2314 004216 000000 E.SPARE: .WORD 0 ;SPARE REGISTER
2315
2316      .SBTTL  PREVIOUS RK611 CONTROLLER REGISTERS
2317
2318 004220 000000 P.CS1: .WORD 0 ;PREVIOUS COMMAND AND STATUS REG 1
2319 004222 000000 P.CS2: .WORD 0 ;PREVIOUS COMMAND AND STATUS REG 2
2320 004224 000000 P.DS: .WORD 0 ;PREVIOUS DRIVE STATUS REG
2321 004226 000000 P.ER: .WORD 0 ;PREVIOUS ERROR REG
2322 004230 000000 U.MR2: .WORD 0 ;UNSHIFTED MAINTENANCE REG 2
2323 004232 000000 U.MR3: .WORD 0 ;UNSHIFTED MAINTENANCE REG 3

```

```

2324      .SBTTL PROGRAM DEFINED VARIABLES
2325
2326      004234 000210      RKVEC: .WORD 210      ;RK611 VECTOR
2327      004236 000240      RKPRI: .WORD PR5     ;RK611 PRIORITY
2328      004240 000000      SRTFLG: .WORD 0     ;START FLAG
2329                                     ; 0 = 200
2330                                     ; 1 = 214
2331                                     ; -1 = 204
2332      004242 000000      ERRCNT: .WORD 0      ;ERROR COUNT FOR SWITCH 12 ABORT
2333      004244 000000      DRVCOD: .WORD 0      ;DRIVE SELECT CODE
2334      004246 000000      MSGCOD: .WORD 0      ;MESSAGE SELECT CODE
2335      004250 000000      HDCODE: .WORD 0      ;HEAD SELECT CODE
2336      004252 000000      CYLIN: .WORD 0      ;CYLINDER ADD VALUE
2337      004254 000000      OFFVAL: .WORD 0     ;OFFSET VALUE
2338      004256 000000      SFTCNT: .WORD 0     ;SHIFT COUNT FOR DRIVE MESSAGE SHIFTING
2339      004260 000000      PARBIT: .WORD 0     ;PARITY BIT FOR SHIFT
2340      004262 000015      WAITIM: .WORD 15    ;WAITING FOR DESELECT COMMAND
2341      004264 000144      STALL: .WORD 100.   ;STALL TIME FOR MESSAGE TIME OUT (NED)
2342      004266 000000      DRVTYP: .WORD 0     ;DRIVE TYPE INDICATOR
2343      004270 000000      ILLFUN: .WORD 0     ;ILLEGAL FUNCTION CODE
2344      004272 000000      TRAPPC: .WORD 0     ;ADDRESS OF TRAP FROM MEMORY CHECK
2345      004274 000000      SAVSWR: .WORD 0     ;SAVED SWITCH REG FOR POWER FAIL

```

```

2346 .SBTTL PROGRAM SETUP
2347
2348 004276 012737 000001 004240 PARM: MOV #1,SRTFLG ;LOAD START FLAG FOR PARMETER START
2349 004304 000406 BR START1
2350
2351 004306 012737 177777 004240 RESTRT: MOV #-1,SRTFLG ;LOAD START FLAG FOR RESTART
2352 004314 000402 BR START1
2353
2354 004316 005037 004240 START: CLR SRTFLG ;CLEAR START FLAG
2355 004322 000005 START1: RESET ;RESET THE WHOLE SYSTEM
2356 004324 012706 001100 MOV #STACK,SP ;INITIALIZE STACK POINTER
2357 004330 012746 000340 MOV #PR7,-(SP) ;LOAD STACK TO LOCK OUT ALL INTERRUPTS
2358 004334 012746 004342 MOV #15,-(SP) ;LOAD START OF PROGRAM
2359 004340 000002 RTI ;LOAD PSW
2360
2361 004342 1$:
2362 .SBTTL INITIALIZE THE COMMON TAGS
2363 ;;CLEAR THE COMMON TAGS ($CMTAG) AREA
2364 004342 012706 001100 MOV #SCMTAG,R6 ;;FIRST LOCATION TO BE CLEARED
2365 004346 005026 CLR (R6)+ ;;CLEAR MEMORY LOCATION
2366 004350 022706 001140 CMP #SWR,R6 ;;DONE?
2367 004354 001374 BNE -6 ;;LOOP BACK IF NO
2368 004356 012706 001100 MOV #STACK,SP ;;SETUP THE STACK POINTER
2369 ;;INITIALIZE A FEW VECTORS
2370 004362 012737 042512 000020 MOV #SCOPE,#IOTVEC ;;IOT VECTOR FOR SCOPE ROUTINE
2371 004370 012737 000340 000022 MOV #340,#IOTVEC+2 ;;LEVEL 7
2372 004376 012737 043516 000030 MOV #ERROR,#EMTVEC ;;EMT VECTOR FOR ERROR ROUTINE
2373 004404 012737 000340 000032 MOV #340,#EMTVEC+2 ;;LEVEL 7
2374 004412 012737 046424 000034 MOV #TRAP,#TRAPVEC ;;TRAP VECTOR FOR TRAP CALLS
2375 004420 012737 000340 000036 MOV #340,#TRAPVEC+2 ;;LEVEL 7
2376 004426 012737 046272 000024 MOV #SPWRDN,#PWRVEC ;;POWER FAILURE VECTOR
2377 004434 012737 000340 000026 MOV #340,#PWRVEC+2 ;;LEVEL 7
2378 004442 013737 042204 042176 MOV SENDCT,SEOPCT ;;SETUP END-OF-PROGRAM COUNTER
2379 004450 005037 001200 CLR $TIMES ;;INITIALIZE NUMBER OF ITERATIONS
2380 004454 005037 001202 CLR $ESCAPE ;;CLEAR THE ESCAPE ON ERROR ADDRESS
2381 004460 112737 000001 001115 MOVB #1,$ERMAX ;;ALLOW ONE ERROR PER TEST
2382 004466 012737 004466 001106 MOV #,$SLPADR ;;INITIALIZE THE LOOP ADDRESS FOR SCOPE
2383 004474 012737 004474 001110 MOV #,$SLPERR ;;SETUP THE ERROR LOOP ADDRESS
2384 ;;SIZE FOR A HARDWARE SWITCH REGISTER. IF NOT FOUND OR IT IS
2385 ;;EQUAL TO A "-1" SETUP FOR A SOFTWARE SWITCH REGISTER.
2386 004502 013746 000004 MOV #ERRVEC,-(SP) ;;SAVE ERROR VECTOR
2387 004506 012737 004542 000004 MOV #64,$ERRVEC ;;SET UP ERROR VECTOR
2388 004514 012737 177570 001140 MOV #DSWR,SWR ;;SETUP FOR A HARDWARE SWICH REGISTER
2389 004522 012737 177570 001142 MOV #DDISP,DISPLAY ;;AND A HARDWARE DISPLAY REGISTER
2390 004530 022777 177777 174402 CMP #-1,$SWR ;;TRY TO REFERENCE HARDWARE SWR
2391 004536 001012 BNE 65$ ;;BRANCH IF NO TIMEOUT TRAP OCCURRED
2392 ;;AND THE HARDWARE SWR IS NOT = -1
2393 004540 000403 BR 65$ ;;BRANCH IF NO TIMEOUT
2394 004542 012716 004550 64$: MOV #65$,(SP) ;;SET UP FOR TRAP RETURN
2395 004546 000002 RTI
2396 004550 012737 000176 001140 65$: MOV #SWREG,SWR ;;POINT TO SOFTWARE SWR
2397 004556 012737 000174 001142 65$: MOV #DISPREG,DISPLAY
2398 004564 012637 000004 66$: MOV (SP)+,#ERRVEC ;;RESTORE ERROR VECTOR
2399
2400 004570 005037 001222 CLR $PASS ;;CLEAR PASS COUNT
2401 004574 132737 000200 001235 BITB #APTSIZE,$ENVM ;;TEST USER SIZE UNDER APT

```

```

2402 004602 001403      BEQ      F7$      ;; YES, USE NON-APT SWITCH
2403 004604 012737 001236 001140      MOV      #SSWREG, SWR  ;; NO, USE APT SWITCH REGISTER
2404 004612      67$:
2405 004612 005037 004242      CLR      ERRCNT      ; CLEAR ERROR COUNT FOR SWITCH 12 ABORT
2406      .SBTTL  TYPE PROGRAM NAME
2407      ;;TYPE THE NAME OF THE PROGRAM IF FIRST PASS
2408 004616 005227 177777      INC      #-1        ;; FIRST TIME?
2409 004622 001055      BNE      68$        ;; BRANCH IF NO
2410 004624 022737 042340 000042      CMP      #SENDAD, 2#42  ;; ACT-11?
2411 004632 001451      BEQ      68$        ;; BRANCH IF YES
2412 004634 104401 004702      TYPE    69$        ; TYPE ASCIZ STRING
2413      .SBTTL  GET VALUE FOR SOFTWARE SWITCH REGISTER
2414 004640 005737 000042      TST     2#42        ; ARE WE RUNNING UNDER XXDP/ACT?
2415 004644 001012      BNE      70$        ; BRANCH IF YES
2416 004646 123727 001234 000001      CMPB    $ENV, #1     ; ARE WE RUNNING UNDER APT?
2417 004654 001406      BEQ      70$        ; BRANCH IF YES
2418 004656 023727 001140 000176      CMP     SWR, #SWREG  ; SOFTWARE SWITCH REG SELECTED?
2419 004664 001005      BNE      71$        ; BRANCH IF NO
2420 004666 104406      GTSWR                    ; GET SOFT-SWR SETTINGS
2421 004670 000403      BR      71$
2422 004672 112737 000001 001134 70$:      MOVB    #1, $AUTOB   ; SET AUTO-MODE INDICATOR
2423 004700      71$:
2424 004700 000426      BR      68$        ; GET OVER THE ASCIZ
2425      ;;69$: .ASCIZ <CRLF>/RK611 DISKLESS DIAGNOSTIC: PART 2 CZR6BCD/<CRLF>
2426 004756      68$:
2427 004756 022737 000001 004240      CMP     #1, SRTFLG   ; CHECK IF PARAMETER START
2428 004764 001122      BNE     15$         ; NO CONTINUE SETUP
2429 004766 104401 050010      TYPE   OPRO01       ; TYPE "RK611 BUS ADDRESS ( ) ="
2430 004772 013746 001270      MOV     $BASE, -(SP) ; SAVE $BASE FOR TYPEOUT
2431 004776 104402      TYPOC                    ; GO TYPE--OCTAL ASCII(ALL DIGITS)
2432 005000 104401 050037      TYPE   , OPRO02
2433 005004 104412      RDOCT                    ; GET VALUE
2434 005006 012637 001160      MOV     (SP)+, $TMPD
2435 005012 001407      BEQ     7$          ; CHECK IF <CR>
2436 005014 022737 160000 001160      CMP     #160000, $TMPD ; CHECK IF IN I/O PAGE
2437 005022 101361      BHI     5$          ;
2438 005024 013737 001160 001270      MOV     $TMPD, $BASE ; LOAD NEW BUS ADDRESS
2439 005032 104401 050045      TYPE   OPRO03       ; TYPE "RK611 VECTOR ADDRESS ( ) ="
2440 005036 013746 001264      MOV     $VECT1, -(SP)
2441 005042 042716 160000      BIC     #160000, (SP)
2442 005046 104402      TYPOC
2443 005050 104401 050037      TYPE   , OPRO02
2444 005054 104412      RDOCT                    ; GET VALUE
2445 005056 012637 001160      MOV     (SP)+, $TMPD
2446 005062 001412      BEQ     10$         ; CHECK IF <CR>
2447 005064 022737 001000 001160      CMP     #1000, $TMPD ; CHECK IF LEGAL
2448 005072 101757      BLOS    7$          ;
2449 005074 042737 017777 001264      BIC     #17777, $VECT1 ; LOAD NEW VECTOR ADDRESS
2450 005102 053737 001160 001264      BIS     $TMPD, $VECT1
2451 005110 104401 050075      TYPE   OPRO04       ; TYPE "RK611 PRIORITY ( ) ="
2452 005114 005046      CLR     -(SP)        ; MAKE ROOM ON THE STACK
2453 005116 113716 001265      MOVB    $VECT1+1, (SP)
2454 005122 006216      ASR     (SP)         ; SHIFT 5 BITS RIGHT
2455 005124 006216      ASR     (SP)
2456 005126 006216      ASR     (SP)
2457 005130 006216      ASR     (SP)

```



2458	005132	006216			ASR	(SP)	
2459	005134	104402			TYPOC		
2460	005136	104401	050037		TYPE	,OPR002	
2461	005142	104412			RDOCT		;GET VALUE
2462	005144	012637	001160		MOV	(SP)+,\$TMPO	
2463	005150	001430			BEQ	15\$	;CHECK FOR DEFAULT
2464	005152	022737	000007	001160	CMP	#7,\$TMPO	;CHECK IF LEGAL
2465	005160	103753			BLO	10\$	
2466	005162	022737	000004	001160	CMP	#4,\$TMPO	
2467	005170	101347			BHI	10\$	
2468	005172	006337	001160		ASL	\$TMPO	;SHIFT 5 BITS LEFT
2469	005176	006337	001160		ASL	\$TMPO	
2470	005202	006337	001160		ASL	\$TMPO	
2471	005206	006337	001160		ASL	\$TMPO	
2472	005212	006337	001160		ASL	\$TMPO	
2473	005216	042737	160000	001264	BIC	#160000,\$VECT1	;STORE NEW PRIORITY
2474	005224	153737	001160	001265	BISB	\$TMPO,\$VECT1+1	
2475	005232	013737	001264	004234	MOV	\$VECT1,RKVEC	;STORE RK611 VECTOR
2476	005240	042737	160000	004234	BIC	#160000,RKVEC	
2477	005246	113737	001265	004236	MOVB	\$VECT1+1,RKPRI	;STORE RK611 PRIORITY
2478							
2479	005254	004737	042360		NEWPAS: JSR	PC,CHKPAR	;CHECK FOR MEMORY CHECK ENABLE
2480	005260	012746	000340		MOV	#PR7,-(SP)	;LOCK OUT INTERRUPTS
2481	005264	012746	005272		MOV	#TST1,-(SP)	
2482	005270	000002			RTI		

.SBTTL \*\*DRIVE MESSAGE LOADING

```

*****
*TEST 1 FIRST COMMAND IN MAINT MODE
*
* INITIALIZE RK611 WITH CONTROLLER CLEAR. PUT CONTROLLER IN
* MODE. ISSUE SELECT DRIVE. WAIT AND MAKE SURE CS1 REMAINS
* THE SAME. CLOCK IN MESSAGES A AND B. MAKE SURE
* CORRECT MSG ARE LOADED. CHECKING IS DONE A FIELD AT A
* TIME.
*****

```

```

*****
TST1: SCOPE
MOV #100, $TIMES ; DO 100. ITERATIONS
MOV $BASE, R2 ; LOAD RK611 BASE
MOV #CCLR, RKCS1(R2) ; CLEAR RK611
MOV #DMD, RKMR1(R2) ; PUT RK611 IN DIAGNOSTIC MODE
MOV #SELD, RKCS1(R2) ; LOAD CS1 WITH SELECT DRIVE
MOV #15, R0 ; WAIT FOR READY TO SET
1$: DEC R0
BNE 1$
MOV RKCS1(R2), T.CS1 ; STORE COMMAND AND STATUS REG. 1
MOV #SELD, E.CS1 ; LOAD EXPECT CS1
CMP E.CS1, T.CS1 ; CHECK IF CS1 CHANGED
BEQ 2$ ; NO CONTINUE
ERROR 77 ; CS1 INCORRECT
BR TST2 ; GO ON TO NEXT TEST

2$: MOV #3*4+2, R0 ; CLOCK IN DRIVE MESSAGE
3$: MOV #DMD, MCLK, RKMR1(R2)
MOV #DMD, RKMR1(R2)
DEC R0
BNE 3$
MOV RKCS1(R2), T.CS1 ; STORE COMMAND AND STATUS REG. 1
MOV RKMR2(R2), T.MR2 ; STORE MAINT REG. 2
MOV RKMR3(R2), T.MR3 ; STORE MAINT REG. 3
MOV #SELD, E.CS1 ; LOAD EXPECTED CS1
CLR E.MR2 ; LOAD EXPECTED MAINT REG. 2
CLR E.MR3 ; LOAD EXPECTED MAINT REG. 3
CMP E.CS1, T.CS1 ; CHECK COMMAND AND STATUS REG. 1 CORRECT
BEQ 4$ ; YES, CHECK MESSAGES A & B
ERROR 116 ; CS1 INCORRECT
BR TS12 ; GO ON TO NEXT TEST

4$: BIT #17, T.MR2 ; CHECK IF DRIVE SELECT BITS ZERO
BEQ 5$ ; YES, CONTINUE
ERROR 117 ; MESSAGE SELECT BITS NOT ZERO
5$: BIT #7760, T.MR2 ; CHECK IF COMMAND BITS ZERO
BEQ 6$ ; YES, CONTINUE

6$: ERROR 120 ; COMMAND BITS NOT ZERO
BIT #70000, T.MR2 ; CHECK IF HEAD SELECT BITS ZERO
BEQ 7$ ; YES, CONTINUE
ERROR 121 ; HEAD SELECT NOT ZERO
7$: BIT #BIT15, T.MR2 ; CHECK PARITY BIT ON MESS A ZERO
BEQ 8$ ; YES, CONTINUE

```

```

2483
2484
2485
2486
2487
2488
2489
2490
2491
2492
2493
2494
2495 005272 000004
2496 005274 012737 000144 001200
2497 005302 013702 001270
2498 005306 012762 100000 000000
2499 005314 012762 000040 000026
2500 005322 012762 000001 000000
2501 005330 012700 000015
2502 005334 005300
2503 005336 001376
2504 005340 016237 000000 004120
2505 005346 012737 000001 004160
2506 005354 023737 004160 004120
2507 005362 001402
2508 005364 104077
2509 005366 000503
2510
2511 005370 012700 000016
2512 005374 012762 000440 000026
2513 005402 012762 000040 000026
2514 005410 005300
2515 005412 001370
2516 005414 016237 000000 004120
2517 005422 016237 000034 004146
2518 005430 016237 000036 004150
2519 005436 012737 000001 004160
2520 005444 005037 004206
2521 005450 005037 004210
2522 005454 023737 004160 004120
2523 005462 001402
2524 005464 104116
2525 005466 000443
2526
2527 005470 032737 000017 004146
2528 005476 001401
2529 005500 104117
2530 005502 032737 007760 004146
2531 005510 001401
2532
2533 005512 104120
2534 005514 032737 070000 004146
2535 005522 001401
2536 005524 104121
2537 005526 032737 100000 004146
2538 005534 001401

```

```

2539 005536 104122          ERROR 122          ;PARITY ON MESS A NOT ZERO
2540 005540 032737 000017 004150 8$: BIT #17,T.MR3      ;CHECK MESS SELECT BITS ZERO
2541 005546 001401          BEQ 9$           ;YES, CONTINUE
2542 005550 104123          ERROR 123          ;MESSAGE SELECT BITS NOT ZERO
2543 005552 032737 077760 004150 9$: BIT #77760,T.MR3 ;CHECK CYLINDER ADDRESS BUFFER
2544 005560 001401          BEQ 10$          ;YES, CONTINUE
2545 005562 104124          ERROR 124          ;CYLINDER ADD BITS NOT ZERO
2546 005564 032737 100000 004150 10$: BIT #BIT15,T.MR3 ;CHECK PARITY BIT ON MESSAGE B
2547 005572 001401          BEQ TST2         ;YES, GO ON TO NEXT TEST
2548 005574 104125          ERROR 125          ;PARITY ON MESS. B NOT ZERO
2549
2550 *****
2551 *TEST 2          DRIVE SELECT BITS LOADING FOR DRIVE MESS.
2552 *
2553 *          INITIALIZE RK611 WITH CONTROLLER CLEAR. PUT CONTROLLER IN
2554 *          DIAGNOSTIC MODE. LOAD COMMAND AND STATUS REGISTER 2 WITH
2555 *          ZERO. LOAD COMMAND AND STATUS REGISTER WITH A SELECT
2556 *          COMMAND. CLOCK IN MESSAGES A AND B INTO SHIFT REGISTER.
2557 *          MAKE SURE CORRECT MESSAGES ARE LOADED. REPEAT FOR DRIVE
2558 *          SELECT = 1-17.
2559 *
2560 *****
2561 005576 000004          TST2: SCOPE
2562 005600 012737 000144 001200  MOV #100,$TIMES ;DO 100. ITERATIONS
2563 005606 013702 001270          MOV $BASE,R2    ;LOAD RK611 BASE
2564 005612 005037 004244          CLR DRVC00     ;INITIALIZE DRIVE SELECT CODE
2565 005616 012737 000001 004160  MOV #SELDRV,E.CS1 ;LOAD EXPECTED CS1
2566 005624 012737 005632 001110  MOV #1$,$LPERR ;LOAD LOOP ON ERROR LOCATION FOR
2567 ;          SUBTEST LOOP
2568
2569 005632          1$:
2570 005632 012762 100000 000000  MOV #CCLR,RKCS1(R2) ;CLEAR RK611
2571 005640 012762 000040 000026  MOV #DMD,RKMR1(R2) ;PUT RK611 IN DIAGNOSTIC MODE
2572 005646 013762 004244 000010  MOV DRVC00,RKCS2(R2) ;LOAD DRIVE NUMBER
2573 005654 012762 000001 000000  MOV #SELDRV,RKCS1(R2) ;LOAD SELECT COMMAND
2574 005662 012700 000016          MOV #3*4+2,R0   ;CLOCK IN DRIVE MESSAGE
2575 005666 012762 000440 000026 2$: MOV #DMD!MCLK,RKMR1(R2)
2576 005674 012762 000040 000026  MOV #DMD,RKMR1(R2)
2577 005702 005300          DEC R0
2578 005704 001370          BNE 2$
2579 005706 016237 000000 004120  MOV RKCS1(R2),T.CS1 ;STORE COMMAND AND STATUS REG. 1
2580 005714 016237 000034 004146  MOV RKMR2(R2),T.MR2 ;STORE MAINT REG. 2
2581 005722 016237 000036 004150  MOV RKMR3(R2),T.MR3 ;STORE MAINT REG. 3
2582 005730 013737 004244 004206  MOV DRVC00,E.MR2   ;LOAD EXPECTED MAINT REG. 2
2583 005736 005037 004210          CLR E.MR3
2584 005742 023737 004160 004120  CMP E.CS1,T.CS1   ;CHECK IF CS1 CORRECT
2585 005750 001405          BEQ 3$           ;YES, CHECK MESSAGE A&B
2586 005752 104002          ERROR 2
2587 005754 012762 100000 000000  MOV #CCLR,RKCS1(R2) ;CLEAN UP FOR NEXT CONFIGURATION
2588 005762 000426          BR 25$          ;CHECK IF LOOP ON ERROR
2589
2590 005764 013737 004146 001160 3$: MOV T.MR2,$TMP0   ;MASK BITS NOT UNDER TEST
2591 005772 042737 177760 001160  BIC #177760,$TMP0
2592 006000 023737 004244 001160  CMP DRVC00,$TMP0 ;CHECK IF DRIVE SELECT BITS CORRECT
2593 006006 001402          BEQ 4$           ;YES, CHECK MESSAGES A&B
2594 006010 104003          ERROR 3          ;DRIVE SELECT BITS INCORRECT

```

M04

CZR6BC0 RK611 DSKLS CTRL PRT2  
CZR6BC.P11 02-DEC-77 09:22

MACY11 30(1046) 02-DEC-77 09:31 PAGE 51  
T2 DRIVE SELECT BITS LOADING FOR DRIVE MESS.

SEQ 0051

```

2595 006012 000412 BR 25$ ;CHECK IF LOOP ON ERROR
2596
2597 006014 023737 004206 004146 4$: CMP E.MR2,T.MR2 ;CHECK IF MESSAGE A CORRECT
2598 006022 001401 BEQ 5$ ;YES, CHECK MESSAGE B
2599 006024 104004 ERROR 4 ;MESSAGE A INCORRECT
2600 006026 023737 004210 004150 5$: CMP E.MR3,T.MR3 ;CHECK IF MESSAGE B CORRECT
2601 006034 001401 BEQ 25$ ;YES, CHECK IF LOOP ON ERROR
2602 006036 104005 ERROR 5 ;MESSAGE B INCORRECT
2603 006040 104415 25$: SCOPI ;CHECK IF LOOP ON ERROR
2604 006042 005237 004244 INC DRVCOD ;INCREMENT DRIVE SELECT CODE
2605 006046 022737 000017 004244 CMP #17,DRVCOD ;CHECK IF FINISHED
2606 006054 103266 BHIS 1$ ;NO, TRY NEXT CONFIGURATION
2607
2608
2609 *****
2610 *TEST 3 FORMAT BIT LOADING TO FOR DRIVE MESS.
2611 *
2612 * CLEAR RK611 WITH CONTROLLER CLEAR. PUT CONTROLLER IN
2613 * DIAGNOSTIC MODE. LOAD COMMAND AND STATUS REGISTER 1 WITH
2614 * A SELECT COMMAND AND 24 SECTOR MODE FORMAT. MAKE SURE
2615 * CORRECT MESSAGE IS LOADED.
2616 *****
2617 006056 000004 †ST3: SCOPE
2618 006060 012737 000144 001200 MOV #100,$TIMES ;DO 100. ITERATIONS
2619 006066 013702 001270 MOV $BASE,R2 ;LOAD RK611 BASE
2620 006072 012737 052033 001300 MOV #EM100,EMIN ;LOAD ERROR MESSAGE
2621 006100 012762 100000 000000 MOV #CCLR,RKCS1(R2) ;CLEAR RK611
2622 006106 012762 000040 000026 MOV #DMD,RKMR1(R2) ;PUT RK611 IN MAINTENANCE MODE
2623 006114 012762 010001 000000 MOV #CFMT:SELDV,RKCS1(R2) ;LOAD CFMT:SELDV INTO COMMAND AND STATUS REG.
2624 006122 012737 010001 004160 MOV #CFMT:SELDV,E.CS1 ;LOAD EXPECT CS1
2625 006130 012700 000016 MOV #3*4+2,R0 ;CLOCK IN DRIVE MESSAGES
2626 006134 012762 000440 000026 1$: MOV #DMD:MCLK,RKMR1(R2)
2627 006142 012762 000040 000026 MOV #DMD,RKMR1(R2)
2628 006150 005300 R0
2629 006152 001370 BNE 1$
2630 006154 016237 000000 004120 MOV RKCS1(R2),T.CS1 ;STORE COMMAND AND STATUS REG. 1
2631 006162 016237 000034 004146 MOV RKMR2(R2),T.MR2 ;STORE MAINT REG. 2
2632 006170 016237 000036 004150 MOV RKMR3(R2),T.MR3 ;STORE MAINT REG. 3
2633 006176 012737 001000 004206 MOV #S.FMT,E.MR2 ;LOAD EXPECTED MAINT REG. 2
2634 006204 005037 004210 004206 CLR E.MR3 ;LOAD EXPECTED MAINT REG. 3
2635 006210 023737 004160 004120 CMP E.CS1,T.CS1 ;CHECK IF CS1 CORRECT
2636 006216 001410 BEQ 2$ ;YES, CHECK MESSAGE A&B
2637 006220 012737 057141 001302 MOV #EM2003,EMIN+2 ;LOAD ERROR MESSAGE
2638 006226 104001 ERROR 1
2639 006230 012762 100000 000000 MOV #CCLR,RKCS1(R2) ;CLEAN UP FOR NEXT TEST
2640 006236 000431 BR TST4 ;GO ON TO NEXT TEST
2641
2642 006240 032737 001000 004146 2$: BIT #S.FMT,T.MR2 ;CHECK IF S.FMT SET IN MESSAGE A
2643 006246 001005 BNE 3$ ;YES, CHECK MESSAGES A&B
2644 006250 012737 057005 001302 MOV #EM2000,EMIN+2 ;LOAD ERROR MESSAGE
2645 006256 104001 ERROR 1
2646 006260 000420 BR TST4 ;GO ON TO NEXT TEST
2647
2648 006262 023737 004206 004146 3$: CMP E.MR2,T.MR2 ;CHECK IF DRIVE MESSAGE A CORRECT
2649 006270 001404 BEQ 4$ ;YES, CHECK MESSAGE B
2650 006272 012737 057063 001302 MOV #EM2001,EMIN+2 ;LOAD ERROR MESSAGE

```

```

2651 006300 104001          ERROR      1
2652 006302 023737 004210 004150 4$:  CMP      E.MR3,T.MR3      ;CHECK IF DRIVE MESSAGE B CORRECT
2653 006310 001404          BEQ      TST4          ;:YES, GO ON TO NEXT TEST
2654 006312 012737 057112 001302  MOV      #EM2002,EM1N+2 ;LOAD ERROR MESSAGE
2655 006320 104001          ERROR      1
2656
2657
2658
2659
2660
2661
2662
2663
2664
2665
2666
2667
2668 006322 000004          *****
2669 006324 012737 000144 001200  TST4:  SCOPE      HEAD SELECT BITS LOADING FOR DRIVE MESS.
2670 006332 013702 001270          *
2671 006336 005037 004250          *   CLEAR RK611 WITH CONTROLLER CLEAR. PUT CONTROLLER IN
2672 006342 012737 000001 004160          *   DIAGNOSTIC MODE. LOAD TRACK ADDRESS WITH ZERO. LOAD
2673 006350 012737 006356 001110          *   COMMAND AND STATUS REGISTER 2 WITH ZERO. LOAD COMMAND
2674
2675
2676
2677 006356 012762 100000 000000 1$:  MOV      #CCLR,RKCS1(R2) ;CLEAR RK611
2678 006364 012762 000040 000026  MOV      #DMD,RKMR1(R2) ;PUT RK611 IN DIAGNOSTIC MODE
2679 006372 005046          CLR      -(SP)          ;MAKE ROOM ON STACK
2680 006374 003766 004250 000001  MOV      HDCODE,1(SP)   ;LOAD HEAD ADDRESS
2681 006402 012662 000006          MOV      (SP)+,RKDR(R2)
2682 006406 012762 000001 000000  MOV      #SELDV,RKCS1(R2) ;LOAD SELECT COMMAND
2683 006414 012700 000016          MOV      #3*4+2,R0     ;CLOCK IN DRIVE MESSAGE
2684 006420 012762 000440 000026 2$:  MOV      #DMD!MCLK,RKMR1(R2)
2685 006426 012762 000040 000026  MOV      #DMD,RKMR1(R2)
2686 006434 005300          DEC      R0
2687 006436 001370          BNE     2$
2688 006440 016237 000000 004120  MOV      RKCS1(R2),T.CS1 ;STORE COMMAND AND STATUS REG. 1
2689 006446 016237 000034 004146  MOV      RKMR2(R2),T.MR2 ;STORE MAINT REG. 2
2690 006454 016237 000036 004150  MOV      RKMR3(R2),T.MR3 ;STORE MAINT REG. 3
2691 006462 005037 004206          CLR      E.MR2
2692 006466 113737 004250 004207  MOV      HDCODE,E.MR2+1 ;GENERATE EXPECTED MAINT REG. 2
2693 006474 006337 004206          ASL     E.MR2
2694 006500 006337 004206          ASL     E.MR2
2695 006504 006337 004206          ASL     E.MR2
2696 006510 006337 004206          ASL     E.MR2
2697 006514 005037 004210          CLR      E.MR3
2698 006520 023737 004160 004120  CMP      E.CS1,T.CS1   ;LOAD EXPECTED MAINT REG. 3
2699 006526 001405          BEQ     3$             ;CHECK IF CS1 CORRECT
2700 006530 104006          BEQ     3$             ;YES, CHECK MESSAGE A&B
2701 006532 012762 100000 000000  MOV      #CCLR,RKCS1(R2) ;CLEAN UP FOR NEXT CONFIGURATION
2702 006540 000426          BR      25$           ;CHECK IF LOOP ON ERROR
2703
2704 006542 013737 004146 001160 3$:  MOV      T.MR2,$TMPD   ;MASK BITS NOT UNDER TEST
2705 006550 042737 103777 001160  BIC     #103777,$TMPD
2706 006556 023737 004206 001160  CMP      E.MR2,$TMPD   ;CHECK IF HEAD SELECT BITS CORRECT

```

```

2707 006564 001402 BEQ 4$ ;YES, CHECK MESSAGES A&B
2708 006566 104007 ERROR 7 ;HEAD SELECT BITS INCORRECT
2709 006570 000412 BR 25$ ;CHECK IF LOOP ON ERROR
2710
2711 006572 023737 004206 004146 4$: CMP E.MR2,T.MR2 ;CHECK IF MESSAGE A CORRECT
2712 006600 001401 BEQ 5$ ;YES, CHECK MESSAGE B
2713 006602 104010 ERROR 10 ;MESSAGE A INCORRECT
2714 006604 023737 004210 004150 5$: CMP E.MR3,T.MR3 ;CHECK IF MESSAGE B CORRECT
2715 006612 001401 BEQ 25$ ;YES, CHECK IF LOOP ON ERROR
2716 006614 104011 ERROR 11 ;MESSAGE A INCORRECT
2717 006616 104415 25$: SCOPI ;CHECK IF LOOP ON ERROR
2718 006620 005237 004250 INC HDCODE ;INCREMENT HEAD SELECT CODE F
2719 006624 022737 000007 004250 CMP #7,HDCODE ;CHECK IF FINISHED
2720 006632 103251 BHIS 1$ ;NO, TRY NEXT CONFIGURATION
2721
2722 ;*****
2723 ;*TEST 5 MESSAGE SELECT BITS LOADING FOR DRIVE MESS.*
2724 ;*
2725 ;* CLEAR RK611 WITH CONTROLLER CLEAR. PUT CONTROLLER IN
2726 ;* DIAGNOSTIC MODE AND ZERO IN MESSAGE SELECT BITS. LOAD
2727 ;* COMMAND AND STATUS REGISTER 1 WITH A SELECT COMMAND. CLOCK
2728 ;* IN MESSAGE A AND B INTO SHIFT REGISTER. MAKE SURE
2729 ;* CORRECT MESSAGE IS LOADED. REPEAT FOR MESSAGE SELECT = 1-17.*
2730 ;*
2731 ;*****
2732 006634 000004 STS: SCOPE
2733 006636 012737 000144 001200 MOV #100,$TIMES ;DO 100. ITERATIONS
2734 006644 013702 001270 MOV $BASE,R2 ;LOAD RK611 BASE
2735 006650 005037 004246 CLR MSGCOD ;INITIALIZE MESSAGE SELECT
2736 006654 012737 000001 004160 MOV #SELDV,E.CS1 ;LOAD EXPECTED CSI
2737 006662 012737 006670 001110 MOV #1$, $LPERR ;LOAD LOOP ON ERROR LOCATION FOR
2738 ; SUBTEST LOOP
2739
2740 006670 1$: MOV #CCLR,RKCS1(R2) ;CLEAR RK611
2741 006670 012762 100000 000000 MOV MSGCOD,RKMR1(R2) ;LOAD MESSAGE SELECT BITS
2742 006676 013762 004246 000026 BIS #DMD,RKMR1(R2) ;PUT RK611 IN DIAGNOSTIC MODE
2743 006704 052762 000040 000026 MOV #SELDV,RKCS1(R2) ;LOAD SELECT COMMAND
2744 006712 012762 000001 000000 MOV #3*4+2,R0 ;CLOCK IF DRIVE MESSAGE
2745 006720 012700 000016 2$: BIS #MCLK,RKMR1(R2)
2746 006724 052762 000400 000026 BIC #MCLK,RKMR1(R2)
2747 006732 042762 000400 000026 R0
2748 006740 005300 DEC 2$
2749 006742 001370 BNE
2750 006744 016237 000000 004120 MOV RKCS1(R2),T.CS1 ;STORE COMMAND AND STATUS REG. 1
2751 006752 016237 000026 004144 MOV RKMR1(R2),T.MR1 ;STORE MAINTENANCE REG. 1
2752 006760 016237 000034 004146 MOV RKMR2(R2),T.MR2 ;STORE MAINTENANCE REG. 2
2753 006766 016237 000036 004150 MOV RKMR3(R2),T.MR3 ;STORE MAINTENANCE REG. 3
2754 006774 013737 004246 004204 MOV MSGCOD,E.MR1 ;LOAD EXPECTED MAINT REG. 1
2755 007002 052737 002040 004204 BIS #MEWD!DMD,E.MR1
2756 007010 032737 020000 004144 BIT #ECCW,T.MR1
2757 007016 001403 BEQ 10$
2758 007020 052737 020000 004204 BIS #ECCW,E.MR1
2759 007026 005037 004206 10$: CLR E.MR2 ;LOAD EXPECTED MAINT REG. 2
2760 007032 013737 004246 004210 MOV MSGCOD,E.MR3 ;LOAD EXPECTED MAINT REG. 3
2761 007040 023737 004160 004120 CMP E.CS1,T.CS1 ;CHECK IF CSI CORRECT
2762 007046 001405 BEQ 3$ ;YES, CHECK MAINT REG. 1

```

C05

CZR6BCO RK611 DSKLS CTRL PRT2  
CZR6BC.P11 02-DEC-77 09:22

MACY11 30(1046) 02-DEC-77 09:31 PAGE 54  
T5 MESSAGE SELECT BITS LOADING FOR DRIVE MESS.

SEQ 0054

```

2763 007050 104012          ERROR 12          ;CS1 INCORRECT
2764 007052 012762 100000 000000 MOV #CCLR,RKCS1(R2) ;CLEAR UP FOR NEXT CONFIGURATION
2765 007060 000437          BR 25$          ;CHECK IF LOOP ON ERROR
2766
2767 007062 023737 004204 004144 3$: CMP E.MR1,T.MR1 ;CHECK IF MAINT REG. 1 CORRECT
2768 007070 001405          BEQ 4$          ;YES, CHECK MESSAGE A&B
2769 007072 104013          ERROR 13         ;MR1 INCORRECT
2770 007074 012762 100000 000000 MOV #CCLR,RKCS1(R2) ;CLEAR UP FOR NEXT CONFIGURATION
2771 007102 000426          BR 25$          ;CHECK IF LOOP ON ERROR
2772
2773 007104 013737 004150 001160 4$: MOV T.MR3,$TMPD ;MASK BITS NOT UNDER TEST
2774 007112 042737 177760 001160 BIC #177760,$TMPD
2775 007120 023737 004246 001160 CMP MSGCOD,$TMPD ;CHECK IF MESSAGE SELECT CODE CORRECT
2776 007126 001402          BEQ 5$          ;YES, CHECK MESSAGES A&B
2777 007130 104014          ERROR 14         ;MESSAGE SELECT CODE INCORRECT
2778 007132 000412          BR 25$
2779
2780 007134 023737 004206 004146 5$: CMP E.MR2,T.MR2 ;CHECK IF MESSAGE A CORRECT
2781 007142 001401          BEQ 6$          ;YES, CHECK MESSAGE B
2782 007144 104015          ERROR 15         ;MESSAGE A INCORRECT
2783 007146 023737 004210 004150 6$: CMP E.MR3,T.MR3 ;CHECK IF MESSAGE B CORRECT
2784 007154 001401          BEQ 25$         ;YES, CHECK IF LOOP ON ERROR
2785 007156 104016          ERROR 16         ;MESSAGE B INCORRECT
2786 007160 104415          25$: SCOP1 ;CHECK IF LOOP ON ERROR
2787 007162 005237 004246          INC MSGCOD ;INCREMENT MESSAGE SELECT CODE
2788 007166 022737 000017 004246 CMP #17,MSGCOD ;CHECK IF FINISHED
2789 007174 103235          BHS 1$          ;NO, TRY NEXT CONFIGURATION
2790
2791
2792 *****
2793 *TEST 6 CLEAR DRIVE COMMAND LOADING FOR DRIVE MESS
2794 *
2795 * CLEAR RK611 WITH CONTROLLER CLEAR. PUT CONTROLLER IN
2796 * DIAGNOSTIC MODE. LOAD COMMAND AND STATUS REGISTER 1 WITH
2797 * A DRIVE CLEAR. CLOCK MESSAGE A AND B INTO SHIFT REGISTERS.
2798 * MAKE SURE SHIFT REGISTERS ARE LOADED CORRECTLY. REPEAT
2799 * FOR 24 SECTOR FORMAT.
2800 *****
2801 007176 000004          ↑$T6: SCOPE
2802 007200 012737 000144 001200 MOV #100,$TIMES ;DO 100. ITERATIONS
2803 007206 013702 001270          MOV $BASE,R2 ;LOAD RK611 BASE
2804 007212 012737 052121 001300 MOV #EM101,EM1N ;LOAD ERROR MESSAGE
2805 007220 012737 000005 004160 MOV #CLEAR,E.CS1 ;LOAD EXPECTED COMMAND AND STATUS REG. 1
2806 007226 012737 000400 004206 MOV #5,CLR,E.MR2 ;LOAD EXPECTED MAINT. REG. 2
2807 007234 012737 007242 001110 MOV #1$,SLPERR ;LOAD LOOP ON ERROR LOCATION FOR
2808 ; SUBTEST LOOP
2809
2810 007242          1$:
2811 007242 012762 100000 000000 MOV #CCLR,RKCS1(R2) ;CLEAR RK611
2812 007250 012762 000040 000026 MOV #DMD,RKMR1(R2) ;PUT RK611 IN MAINTENANCE MODE
2813 007256 013762 004160 000000 MOV E.CS1,RKCS1(R2) ;LOAD CLEAR INTO COMMAND AND STATUS REG. 1
2814 007264 012700 000016          MOV #3*4+2,R0 ;CLOCK IN DRIVE MESSAGE
2815 007270 012762 000440 000026 2$: MOV #DMD!MCLK,RKMR1(R2)
2816 007276 012762 000040 000026 MOV #DMD,RKMR1(R2)
2817 007304 005300          DEC R0
2818 007306 001370          BNE 2$

```

```

2819 007310 016237 000000 004120      MOV      RKCS1(R2),T.CS1 ;STORE COMMAND AND STATUS REG. 1
2820 007316 016237 000034 004146      MOV      RKMR2(R2),T.MR2 ;STORE MAINTENANCE REG. 2
2821 007324 016237 000036 004150      MOV      RKMR3(R2),T.MR3 ;STORE MAINTENANCE REG. 3
2822 007332 005037 004210      CLR      E.MR3           ;STORE EXPECTED MAINT REG. 3
2823 007336 023737 004160 004120      CMP      E.CS1,T.CS1    ;CHECK IF CS1 CORRECT
2824 007344 001410      BEQ      3$             ;YES, CHECK MESSAGE A&B
2825 007346 012737 057141 001302      MOV      #EM2003,EMIN+2 ;LOAD ERROR MESSAGE
2826 007354 104001      ERROR   1              ;
2827 007356 012762 100000 000000      MOV      #CCLR,RKCS1(R2) ;CLEAN UP FOR NEXT CONFIGURATION
2828 007364 000437      BR       25$           ;CHECK IF LOOP ON ERROR
2829
2830 007366 013737 004146 001160 3$:      MOV      T.MR2,$TMPD    ;MASK BITS NOT UNDER TEST
2831 007374 042737 176377 001160      BIC      #C<S.FMT!S.CLR>,$TMPD
2832 007402 023737 004206 001160      CMP      E.MR2,$TMPD    ;CHECK IF S.CLR AND FORMAT
2833                                     ;BITS IN MESSAGE CORRECT
2834 007410 001405      BEQ      4$             ;YES, CHECK MESSAGE A&B
2835 007412 012737 057005 001302      MOV      #EM2000,EMIN+2 ;LOAD ERROR MESSAGE
2836 007420 104001      ERROR   1              ;
2837 007422 000420      BR       25$           ;CHECK IF LOOP ON ERROR
2838
2839 007424 023737 004206 004146 4$:      CMP      E.MR2,T.MR2    ;CHECK IF DRIVE MESSAGE A CORRECT
2840 007432 001404      BEQ      5$             ;YES, CHECK MESSAGE B
2841 007434 012737 057063 001302      MOV      #EM2001,EMIN+2 ;LOAD ERROR MESSAGE
2842 007442 104001      ERROR   1              ;
2843 007444 023737 004210 004150 5$:      CMP      E.MR3,T.MR3    ;CHECK IF DRIVE MESSAGE B CORRECT
2844 007452 001404      BEQ      25$           ;YES, CHECK IF LOOP ON EROR
2845 007454 012737 057112 001302      MOV      #EM2002,EMIN+2 ;LOAD ERROR MESSAGE
2846 007462 104001      ERROR   1              ;
2847 007464 104415      SCOPE  1              ;CHECK IF LOOP ON ERROR
2848 007466 032737 010000 004160 25$:      BIT      #CFMT,E.CS1    ;CHECK IF ISSUED IN 24 SECTOR FORMAT
2849 007474 001007      BNE     TST7           ;YES, GO ON TO NEXT TEST
2850 007476 052737 010000 004160      BIS      #CFMT,E.CS1    ;INDICATE COMMAND IN 24 SECTOR FORMAT
2851 007504 052737 001000 004206      BIS      #S.FMT,E.MR2
2852 007512 000653      BR       1$            ;REISSUE IN 24 SECTOR FORMAT
2853
2854
2855 *****
2856 *TEST 7 UNLOAD COMMAND LOADING FOR DRIVE MESS.
2857 *
2858 * CLEAR RK611 WITH CONTROLLER CLEAR. PUT CONTROLLER IN
2859 * DIAGNOSTIC MODE. LOAD COMMAND AND STATUS REGISTER 1 WITH
2860 * AN UNLOAD COMMAND. CLOCK IN MESSAGES A AND B INTO SHIFT
2861 * REGISTERS. MAKE SURE SHIFT REGISTERS ARE LOADED CORRECTLY.
2862 * REPEAT FOR 24 SECTOR FORMAT.
2863 *****
2864 007514 000004      TST7:  SCOPE
2865 007516 012737 000144 001200      MOV      #100,$TIMES    ;DO 100. ITERATIONS
2866 007524 013702 001270      MOV      $BASE,R2       ;LOAD RK611 BASE
2867 007530 012737 052170 001300      MOV      #EM102,EMIN    ;LOAD ERROR MESSAGE
2868 007536 012737 000007 004160      MOV      #UNLOAD,E.CS1  ;LOAD EXPECTED COMMAND AND STATUS REG. 1
2869 007544 012737 002000 004206      MOV      #S.UNLD,E.MR2  ;LOAD EXPECTED MAINT. REG. 2
2870 007552 012737 007560 001110      MOV      #1$,SLPERR     ;LOAD LOOP ON ERROR LOCATION FOR
2871                                     ; SUBTEST LOOP
2872
2873 007560      1$:      MOV      #CCLR,RKCS1(R2) ;CLEAR RK611
2874 007560 012762 100000 000000

```



E05

CZR6BC0 RK611 DSKLS CTRL PRT2  
CZR6BC.P11 02-DEC-77 09:22

MACY11 30(1046)  
17

02-DEC-77 09:31 PAGE 56  
UNLOAD COMMAND LOADING FOR DRIVE MESS.

SEQ 0056

```

2875 007566 012762 000040 000026      MOV      #DMD,RKMR1(R2) ;PUT RK611 IN MAINTENANCE MODE
2876 007574 013762 004160 000000      MOV      E.CS1,RKCS1(R2) ;LOAD UNLOAD INTO COMMAND AND STATUS REG. 1
2877 007602 012700 000016      MOV      #3*4+2,PO ;CLOCK IN DRIVE MESSAGE
2878 007606 012762 000440 000026 2$:      MOV      #DMD!MCLK,RKMR1(R2)
2879 007614 012762 000040 000026      MOV      #DMD,RKMR1(R2)
2880 007622 005300      DEC      RO
2881 007624 001370      BNE      2$
2882 007626 016237 000000 004120      MOV      RKCS1(R2),T.CS1 ;STORE COMMAND AND STATUS REG. 1
2883 007634 016237 000034 004146      MOV      RKMR2(R2),T.MR2 ;STORE MAINTENANCE REG. 2
2884 007642 016237 000036 004150      MOV      RKMR3(R2),T.MR3 ;STORE MAINTENANCE REG. 3
2885 007650 005037 004210      CLR      E.MR3 ;STORE EXPECTED MAINT REG. 3
2886 007654 023737 004160 004120      CMP      E.CS1,T.CS1 ;CHECK IF CS1 CORRECT
2887 007662 001410      BEQ      3$ ;YES, CHECK MESSAGE A&B
2888 007664 012737 057141 001302      MOV      #EM2003,EMIN+2 ;LOAD ERROR MESSAGE
2889 007672 104001      ERROR   1
2890 007674 012762 100000 000000      MOV      #CCLR,RKCS1(R2) ;CLEAN UP FOR NEXT CONFIGURATION
2891 007702 000437      BR       25$ ;CHECK IF LOOP ON ERROR
2892
2893 007704 013737 004146 001160 3$:      MOV      T.MR2,$TMPD ;MASK BITS NOT UNDER TEST
2894 007712 042737 174777 001160      BIC      #C<S.FMT!S.UNLD),$TMPD
2895 007720 023737 004206 001160      CMP      E.MR2,$TMPD ;CHECK IF S.UNLD AND FORMAT
2896                                     ;BITS IN MESSAGE CORRECT
2897 007726 001405      BEQ      4$ ;YES, CHECK MESSAGE A&B
2898 007730 012737 057005 001302      MOV      #EM2000,EMIN+2 ;LOAD ERROR MESSAGE
2899 007736 104001      ERROR   1
2900 007740 000427      BR       25$ ;CHECK IF LOOP ON ERROR
2901
2902 007742 023737 004206 004146 4$:      CMP      E.MR2,T.MR2 ;CHECK IF DRIVE MESSAGE A CORRECT
2903 007750 001404      BEQ      5$ ;YES, CHECK MESSAGE B
2904 007752 012737 057063 001302      MOV      #EM2001,EMIN+2 ;LOAD ERROR MESSAGE
2905 007760 104001      ERROR   1
2906 007762 023737 004210 004150 5$:      CMP      E.MR3,T.MR3 ;CHECK IF DRIVE MESSAGE B CORRECT
2907 007770 001404      BEQ      25$ ;YES, CHECK IF LOOP ON EROR
2908 007772 012737 057112 001302      MOV      #EM2002,EMIN+2 ;LOAD ERROR MESSAGE
2909 010000 104001      ERROR   1
2910 010002 104415      SCOP1   ;CHECK IF LOOP ON ERROR
2911 010004 032737 010000 004160 25$:      BIT      #CFMT,E.CS1 ;CHECK IF ISSUED IN 24 SECTOR FORMAT
2912 010012 001007      BNE      TST10 ;YES, GO ON TO NEXT TEST
2913 010014 052737 010000 004160      BIS      #CFMT,E.CS1 ;INDICATE COMMAND IN 24 SECTOR FORMAT
2914 010022 052737 001000 004206      BIS      #S.FMT,E.MR2
2915 010030 000653      BR       1$ ;REISSUE IN 24 SECTOR FORMAT
2916
2917                                     ;*****
2918 :TEST 10 PACK ACKNOWLEDGE COMMAND LOADING FOR DRIVE MESS.
2919 *
2920 *
2921 * CLEAR RK611 WITH CONTROLLER CLEAR. PUT CONTROLLER IN
2922 * DIAGNOSTIC MODE. LOAD COMMAND AND STATUS REGISTER 1 WITH
2923 * A PACK ACKNOWLEDGE. CLOCK MESSAGES A AND B INTO SHIFT
2924 * REGISTERS. MAKE SURE SHIFT REGISTERS ARE LOADED CORRECTLY.
2925 * REPEAT FOR 24 SECTOR FORMAT.
2926 *
2927 :*****
2927 TST10: SCOPE
2928 MOV #100,$TIMES ;DO 100. ITERATIONS
2929 MOV $BASE,R2 ;LOAD RK611 BASE
2930 MOV #EM103,EMIN ;LOAD ERROR MESSAGE

```

F05

CZR6BC0 RK611 DSKLS CTRL PRT2  
CZR6BC.P11 02-DEC-77 09:22

MACY11 30(1046)  
T10

02-DEC-77 09:31 PAGE 57  
PACK ACKNOWLEDGE COMMAND LOADING FOR DRIVE MESS.

SEQ 0057

```

2931 010054 012737 000003 004160      MOV      #PACK,E.CS1      ;LOAD EXPECTED COMMAND AND STATUS REG. 1
2932 010062 012737 004000 004206      MOV      #S.PACK,E.MR2   ;LOAD EXPECTED MAINT. REG. 2
2933 010070 012737 010076 001110      MOV      #1$,SLPERR      ;LOAD LOOP ON ERROR LOCATION FOR
2934                                     ; SUBTEST LOOP
2935
2936 010076                                     1$:      MOV      #CLR,RKCS1(R2)   ;CLEAR RK611
2937 010076 012762 100000 000000      MOV      #DMD,RKMR1(R2)  ;PUT RK611 IN MAINTENANCE MODE
2938 010104 012762 000040 000026      MOV      E.CS1,RKCS1(R2) ;LOAD PACK INTO COMMAND AND STATUS REG. 1
2939 010112 013762 004160 000000      MOV      #3*4+2,RO       ;CLOCK IN DRIVE MESSAGE
2940 010120 012700 000016 000000      MOV      #DMD!MCLK,RKMR1(R2)
2941 010124 012762 000440 000026      2$:      MOV      #DMD,RKMR1(R2)
2942 010132 012762 000040 000026      DEC      RO
2943 010140 005300                                     BNE     2$
2944 010142 001370                                     MOV      RKCS1(R2),T.CS1 ;STORE COMMAND AND STATUS REG. 1
2945 010144 016237 000000 004120      MOV      RKMR2(R2),T.MR2 ;STORE MAINTENANCE REG. 2
2946 010152 016237 000034 004146      MOV      RKMR3(R2),T.MR3 ;STORE MAINTENANCE REG. 3
2947 010160 016237 000036 004150      CLR      E.MR3           ;STORE EXPECTED MAINT REG. 3
2948 010166 005037 004210 000000      CMP      E.CS1,T.CS1     ;CHECK IF CS1 CORRECT
2949 010172 023737 004160 004120      BEQ      3$              ;YES, CHECK MESSAGE A&B
2950 010200 001410                                     MOV      #EM2003,EMIN+2 ;LOAD ERROR MESSAGE
2951 010202 012737 057141 001302      ERROR   1
2952 010210 104001                                     MOV      #CLR,RKCS1(R2) ;CLEAN UP FOR NEXT CONFIGURATION
2953 010212 012762 100000 000000      MOV      25$
2954 010220 000437                                     BR      25$
2955
2956 010222 013737 004146 001160      3$:      MOV      T.MR2,$TMPD     ;MASK BITS NOT UNDER TEST
2957 010230 042737 172777 001160      BIC     #C<S.FMT!S.PACK>,$TMPD
2958 010236 023737 004206 001160      CMP      E.MR2,$TMPD     ;CHECK IF S.PACK AND FORMAT
2959                                     ; BITS IN MESSAGE CORRECT
2960 010244 001405                                     BEQ      4$              ;YES, CHECK MESSAGE A&B
2961 010246 012737 057005 001302      MOV      #EM2000,EMIN+2 ;LOAD ERROR MESSAGE
2962 010254 104001                                     ERROR   1
2963 010256 000420                                     BR      25$
2964                                     ;CHECK IF LOOP ON ERROR
2965
2965 010260 023737 004206 004146      4$:      CMP      E.MR2,T.MR2     ;CHECK IF DRIVE MESSAGE A CORRECT
2966 010266 001404                                     BEQ      5$              ;YES, CHECK MESSAGE B
2967 010270 012737 057063 001302      MOV      #EM2001,EMIN+2 ;LOAD ERROR MESSAGE
2968 010276 104001                                     ERROR   1
2969 010300 023737 004210 004150      5$:      CMP      E.MR3,T.MR3     ;CHECK IF DRIVE MESSAGE B CORRECT
2970 010306 001404                                     BEQ      25$            ;YES, CHECK IF LOOP ON EROR
2971 010310 012737 057112 001302      MOV      #EM2002,EMIN+2 ;LOAD ERROR MESSAGE
2972 010316 104001                                     ERROR   1
2973 010320 104415                                     SCOP1
2974 010322 032737 010000 004160      25$:    BIT      #CFMT,E.CS1     ;CHECK IF ISSUED IN 24 SECTOR FORMAT
2975 010330 001007                                     BNE     TST11           ;YES, GO ON TO NEXT TEST
2976 010332 052737 010000 004160      BIS     #CFMT,E.CS1     ;INDICATE COMMAND IN 24 SECTOR FORMAT
2977 010340 052737 001000 004206      BIS     #S.FMT,E.MR2
2978 010346 000653      BR      1$              ;REISSUE IN 24 SECTOR FORMAT

```

```

2979
2980 *****
2981 *TEST 11 RECALIBRATE COMMAND LOADING FOR DRIVE MESS.
2982 *
2983 * CLEAR RK611 WITH CONTROLLER CLEAR. PUT CONTROLLER IN
2984 * DIAGNOSTIC MODE. LOAD COMMAND AND STATUS REGISTER 1 WITH
2985 * A RECALIBRATE. CLOCK MESSAGES A AND B INTO SHIFT REGISTERS.
2986 * MAKE SURE SHIFT REGISTERS ARE LOADED CORRECTLY.

```

G05

CZR6BC0 RK611 DSKLS CTRL PRT2  
CZR6BC.P11 02-DEC-77 09:22

MACY11 30(1046) 02-DEC-77 09:31 PAGE 58  
T11 RECALIBRAT. COMMAND LOADING FOR DRIVE MESS.

SEQ 0058

```

2987
2988
2989 010350 000004
2990 010352 012737 000144 001200
2991 010360 013702 001270
2992 010364 012737 052306 001300
2993 010372 012762 100000 000000
2994 010400 012762 000040 000026
2995 010406 012762 000013 000000
2996 010414 012737 000013 004160
2997 010422 012700 000016
2998 010426 012762 000440 000026
2999 010434 012762 000040 000026
3000 010442 005300
3001 010444 001370
3002 010446 016237 000000 004120
3003 010454 016237 000034 004146
3004 010462 016237 000036 004150
3005 010470 012737 000040 004206
3006 010476 005037 004210
3007 010502 023737 004160 004120
3008 010510 001410
3009 010512 012737 057141 001302
3010 010520 104001
3011 010522 012762 100000 000000
3012 010530 000431
3013
3014 010532 032737 000040 004146
3015 010540 001005
3016 010542 012737 057005 001302
3017 010550 104001
3018 010552 000420
3019
3020 010554 023737 004206 004146
3021 010562 001404
3022 010564 012737 057063 001302
3023 010572 104001
3024 010574 023737 004210 004150
3025 010602 001404
3026 010604 012737 057112 001302
3027 010612 104001
3028
3029
3030
3031
3032
3033
3034
3035
3036
3037
3038 010614 000004
3039 010616 012737 000144 001200
3040 010624 013702 001270
3041 010630 012737 052355 001300
3042 010636 012762 100000 000000

```

```

;*****
;ST11: SCOPE
MOV #100,$TIMES ;;DO 100. ITERATIONS
MOV $BASE,R2 ;;LOAD RK611 BASE
MOV #EM104,EMIN ;;LOAD ERROR MESSAGE
MOV #CCLR,RKCS1(R2) ;;CLEAR RK611
MOV #DMD,RKMR1(R2) ;;PUT RK611 IN MAINTENANCE MODE
MOV #RECAL,RKCS1(R2) ;;LOAD RECAL INT. COMMAND AND STATUS REG. 1
MOV #RECAL,E.CS1 ;;LOAD EXPECT CSI
MOV #3*4+2,R0 ;;CLOCK IN DRIVE MESSAGES
1$: MOV #DMD,MCLK,RKMR1(R2)
MOV #DMD,RKMR1(R2)
DEC R0
BNE 1$
MOV RKCS1(R2),T.CS1 ;;STORE COMMAND AND STATUS REG. 1
MOV RKMR2(R2),T.MR2 ;;STORE MAINT REG. 2
MOV RKMR3(R2),T.MR3 ;;STORE MAINT REG. 3
MOV #S.RECL,E.MR2 ;;LOAD EXPECTED MAINT REG. 2
CLR E.MR3 ;;LOAD EXPECTED MAINT REG. 3
CMP E.CS1,T.CS1 ;;CHECK IF CSI CORRECT
BEQ 2$ ;;YES CHECK MESSAGE A&B
MOV #EM2003,EMIN+2 ;;LOAD ERROR MESSAGE
ERROR 1
MOV #CCLR,RKCS1(R2) ;;CLEAN UP FOR NEXT TEST
BR TST12 ;;GO ON TO NEXT TEST

2$: BIT #S.RECL,T.MR2 ;;CHECK IF S.RECL SET IN MESSAGE A
BNE 3$ ;;YES CHECK MESSAGES A&B
MOV #EM2000,EMIN+2 ;;LOAD ERROR MESSAGE
ERROR 1
BR TST12 ;;GO ON TO NEXT TEST

3$: CMP E.MR2,T.MR2 ;;CHECK IF DRIVE MESSAGE A CORRECT
BEQ 4$ ;;YES CHECK MESSAGE B
MOV #EM2001,EMIN+2 ;;LOAD ERROR MESSAGE
ERROR 1

4$: CMP E.MR3,T.MR3 ;;CHECK IF DRIVE MESSAGE B CORRECT
BEQ TST12 ;;YES GO ON TO NEXT TEST
MOV #EM2002,EMIN+2 ;;LOAD ERROR MESSAGE
ERROR 1

;*****
;TEST 12 START SPINDLE COMMAND LOADING FOR DRIVE MESS.
;
; CLEAR RK611 WITH CONTROLLER CLEAR. PUT CONTROLLER IN
; DIAGNOSTIC MODE. LOAD COMMAND AND STATUS REGISTER 1 WITH
; A START SPINDLE. CLOCK MESSAGES A AND B INTO SHIFT REGISTERS.
; MAKE SURE SHIFT REGISTERS ARE LOADED CORRECTLY.
;*****
;ST12: SCOPE
MOV #100,$TIMES ;;DO 100. ITERATIONS
MOV $BASE,R2 ;;LOAD RK611 BASE
MOV #EM105,EMIN ;;LOAD ERROR MESSAGE
MOV #CCLR,RKCS1(R2) ;;CLEAR RK611

```

H05

CZR6BCD RK611 DSKLS CTRL PRT2  
CZR6BC.P11 02-DEC-77 09:22

MACY11 30(1046) 02-DEC-77 09:31 PAGE 59  
T12

SEQ 0059

START SPINDLE COMMAND LOADING FOR DRIVE MESS.

```

3043 010644 012762 000040 000026      MOV      #DMD,RKMR1(R2)  ;PUT RK611 IN MAINTENANCE MODE
3044 010652 012762 000011 000000      MOV      #SRTSPL,RKCS1(R2) ;LOAD SRTSPL INTO COMMAND AND STATUS REG. 1
3045 010660 012737 000011 004160      MOV      #SRTSPL,E.CS1    ;LOAD EXPECT CS1
3046 010666 012700 000016 000016      MOV      #3*4+2,R0       ;CLOCK IN DRIVE MESSAGES
3047 010672 012762 000440 000026 1$:      MOV      #DMD!MCLK,RKMR1(R2)
3048 010700 012762 000040 000026      MOV      #DMD,RKMR1(R2)
3049 010706 005300 000000 000000      DEC      R0
3050 010710 001370 000000 000000      BNE     1$
3051 010712 016237 000000 004120      MOV      RKCS1(R2),T.C1    ;STORE COMMAND AND STATUS REG. 1
3052 010720 016237 000034 004146      MOV      RKMR2(R2),T.MR2   ;STORE MAINT REG. 2
3053 010726 016237 000036 004150      MOV      RKMR3(R2),T.MR3   ;STORE MAINT REG. 3
3054 010734 012737 000100 004206      MOV      #S.STSP,E.MR2    ;LOAD EXPECTED MAINT REG. 2
3055 010742 005037 004210 000000      CLR      E.MR3            ;LOAD EXPECTED MAINT REG. 3
3056 010746 023737 004160 004120      CMP      E.CS1,T.CS1      ;CHECK IF CS1 CORRECT
3057 010754 001410 000000 000000      BEQ     2$                ;YES, CHECK MESSAGE A&B
3058 010756 012737 057141 001302      MOV      #EM2003,EMIN+2   ;LOAD ERROR MESSAGE
3059 010764 104001 000000 000000      ERROR   1
3060 010766 012762 100000 000000      MOV      #CCLR,RKCS1(R2)  ;CLEAN UP FOR NEXT TEST
3061 010774 000431 000000 000000      BR      TST13            ;;GO ON TO NEXT TEST
3062
3063 010776 032737 000100 004146 2$:      BIT      #S.STSP,T.MR2    ;CHECK IF S.STSP SET IN MESSAGE A
3064 011004 001005 000000 000000      BNE     3$                ;YES, CHECK MESSAGES A&B
3065 011006 012737 057005 001302      MOV      #EM2000,EMIN+2   ;LOAD ERROR MESSAGE
3066 011014 104001 000000 000000      ERROR   1
3067 011016 000420 000000 000000      BR      TST13            ;;GO ON TO NEXT TEST
3068
3069 011020 023737 004206 004146 3$:      CMP      E.MR2,T.MR2      ;CHECK IF DRIVE MESSAGE A CORRECT
3070 011026 001404 000000 000000      BEQ     4$                ;YES, CHECK MESSAGE B
3071 011030 012737 057063 001302      MOV      #EM2001,EMIN+2   ;LOAD ERROR MESSAGE
3072 011036 104001 000000 000000      ERROR   1
3073 011040 023737 004210 004150 4$:      CMP      E.MR3,T.MR3      ;CHECK IF DRIVE MESSAGE B CORRECT
3074 011046 001404 000000 000000      BEQ     TST13            ;;YES, GO ON TO NEXT TEST
3075 011050 012737 057112 001302      MOV      #EM2002,EMIN+2   ;LOAD ERROR MESSAGE
3076 011056 104001 000000 000000      ERROR   1
3077
3078
3079
3080
3081
3082
3083
3084
3085
3086
3087
3088 011060 000004 000000 000000      *TEST 13      SEEK AND CYLINDER ADD 0-777 LOADING FOR DRIVE MESS
3089 011062 012737 000144 001200      *
3090 011070 013702 001270 000000      *
3091 011074 005037 004252 000000      *
3092 011100 012737 000017 004160      *
3093 011106 012737 011114 001110      *
3094
3095
3096 011114 000000 000000 000000      *
3097 011114 012762 100000 000000      *
3098 011122 012762 000040 000026      *

```

\*\*\*\*\*  
TST13: SCOPE  
MOV #100,\$TIMES ;DO 100. ITERATIONS  
MOV \$BASE,R2 ;LOAD RK611 BASE  
CLR CYLIN ;INITIALIZE CYLINDER  
MOV #SEEK,E.CS1 ;LOAD EXPECTED CS1  
MOV #1\$,SLPEKR ;LOAD LOOP ON ERROR LOCATION FOR  
; SUBTEST LOOP

3099	011130	013762	004252	000020		MOV	CYLIN,RKDCYL(R2)	:LOAD CYLINDER ADDRESS
3100	011136	012762	000017	000000		MOV	#SEEK,RKCS1(R2)	:ISSUE SEEK
3101	011144	012700	000016			MOV	#3*4+2,RO	:CLOCK IN DRIVE MESSAGE
3102	011150	012762	00044C	000026	2\$:	MOV	#DMD:MCLK,RKMR1(R2)	
3103	011156	012762	000040	000026		MOV	#DMD,RKMR1(R2)	
3104	011164	005300				DEC	RC	
3105	011166	001370				BNE	2\$	
3106	011170	016237	000000	004120		MOV	RKCS1(R2),T.CS1	:STORE COMMAND AND STATUS REG. 1
3107	011176	016237	000034	004146		MOV	RKMR2(R2),T.MR2	:STORE MAINT REG. 2
3108	011204	016237	000036	004150		MOV	RKMR3(R2),T.MR3	:STORE MAINT REG. 3
3109	011212	012737	000020	004206		MOV	#S.SEEK,E.MR2	:LOAD EXPECTED MAINT REG. 2
3110	011220	013737	004252	004210		MOV	CYLIN,E.MR3	:GENERATE EXPECTED MAINT REG. 3
3111	011226	006337	004210			ASL	E.MR3	
3112	011232	006337	004210			ASL	E.MR3	
3113	011236	006337	004210			ASL	E.MR3	
3114	011242	006337	004210			ASL	E.MR3	
3115	011246	023737	004160	004120		CMP	E.CS1,T.CS1	:CHECK IF CS1 CORRECT
3116	011254	001405				BEQ	3\$	:YES, CHECK MESSAGE A&B
3117	011256	104017				ERROR	17	
3118	011260	012762	100000	000000		MOV	#CCLR,RKCS1(R2)	:CLEAN UP FOR NEXT CONFIGURATION
3119	011266	000434				BR	25\$	:CHECK IF LOOP ON ERROR
3120								
3121	011270	032737	000020	004146	3\$:	BIT	#S.SEEK,T.MR2	:CHECK IF SEEK COMMAND BIT SET
3122	011276	001002				BNE	4\$	:YES, CHECK CYLINDER ADDRESS BITS
3123	011300	104020				ERROR	20	:SEEK BIT NOT SET
3124	011302	000426				BR	25\$	:CHECK IF LOOP ON ERROR
3125								
3126	011304	013737	004150	001160	4\$:	MOV	T.MR3,\$TMPD	:MASK BITS NOT UNDER TEST
3127	011312	042737	140017	001160		BIC	#140017,\$TMPD	
3128	011320	023737	004210	001160		CMP	E.MR3,\$TMPD	:CHECK IF CYLINDER ADDRESS BITS CORRECT
3129	011326	001402				BEQ	5\$	:YES, CHECK MESSAGES A&B
3130	011330	104021				ERROR	21	:CYLINDER ADDRESS BITS INCORRECT
3131	011332	000412				BR	25\$	:CHECK IF LOOP ON ERROR
3132								
3133	011334	023737	004206	004146	5\$:	CMP	E.MR2,T.MR2	:CHECK IF MESSAGE A CORRECT
3134	011342	001401				BEQ	6\$	:YES, CHECK MESSAGE B
3135	011344	104022				ERROR	22	:MESSAGE A INCORRECT
3136	011346	023737	004210	004150	6\$:	CMP	E.MR3,T.MR3	:CHECK IF MESSAGE B CORRECT
3137	011354	001401				BEQ	25\$	:YES, CHECK IF LOOP ON ERROR
3138	011356	104023				ERROR	23	:MESSAGE B INCORRECT
3139	011360	104415			25\$:	SCOP1		:CHECK IF LOOP ON ERROR
3140	011362	005237	004252			INC	CYLIN	:INCREMENT CYLINDER NUMBER
3141	011366	022737	000777	004252		CMP	#777,CYLIN	:CHECK IF FINISHED
3142	011374	103247				BHIS	1\$	:NO, TRY NEXT CONFIGURATION
3143								

```

*****
*TEST 14      SEEK AND CYLINDER BIT 9 AND RK06 FOR DRIVE MESS.
*
*      CLEAR RK611 WITH CONTROLLER CLEAR.  PUT CONTROLLER IN
*      DIAGNOSTIC MODE.  LOAD 1000 IN CYLINDER ADDRESS.  LOAD
*      COMMAND AND STATUS REGISTER 1 WITH A SEEK COMMAND.
*      CLOCK IN MESSAGE A AND B INTO SHIFT REGISTERS.  MAKE
*      SURE CYLINDER BIT 9 IN MESSAGE IN RESET.  REPEAT FOR
*      CYLINDER = 1400.
*****

```

3154

J05

CZR6BCO RK611 DSKLS CTRL PRT2  
CZR6BC.P11 02-DEC-77 09:22

MACY11 30(1046) 02-DEC-77 09:31 PAGE 61  
T14

SEEK AND CYLINDER BIT 9 AND RK06 FOR DRIVE MESS.

SEQ 0061

```

3155 011376 000004          TST14: SCOPE
3156 011400 012737 000144 001200      MOV      #100.,$TIMES      ;; DO 100. ITERATIONS
3157 011406 013702 001270          MOV      $BASE,R2        ;; LOAD RK611 BASE
3158 011412 012737 001000 004252      MOV      #1000,CYLIN     ;; INITIALIZE CYLINDER
3159 011420 005037 004210          CLR      E.MR3          ;; LOAD EXPECTED
3160 011424 012737 000017 004160      MOV      #SEEK,E.CS1     ;; LOAD EXPECTED CS1
3161 011432 012737 011440 001110      MOV      #1$, $LPERR     ;; LOAD LOOP ON ERROR LOCATION FOR
3162                                     ;; SUBTEST LOOP
3163
3164 011440          1$:
3165 011440 012762 100000 000000      MOV      #CCLR,RKCS1(R2) ; CLEAR RK611
3166 011446 012762 000040 000026      MOV      #DMD,RKMR1(R2) ; PUT RK611 IN MAINT MODE
3167 011454 013762 004252 000020      MOV      CYLIN,RKDCYL(R2) ; LOAD CYLINDER ADDRESS
3168 011462 012762 000017 000000      MOV      #SEEK,RKCS1(R2) ; ISSUE SEEK
3169 011470 012700 000016          MOV      #3*4+2,RO       ; CLOCK IN DRIVE MESSAGE
3170 011474 012762 000440 000026      MOV      #DMD:MCLK,RKMR1(R2)
3171 011482 012762 000040 000026      MOV      #DMD,RKMR1(R2)
3172 011510 005300          DEC      RO
3173 011512 001370          BNE     2$
3174 011514 016237 000000 004120      MOV      RKCS1(R2),T.CS1 ; STORE COMMAND AND STATUS REG. 1
3175 011522 016237 000034 004146      MOV      RKMR2(R2),T.MR2 ; STORE MAINT REG.2
3176 011530 016237 000036 004150      MOV      RKMR3(R2),T.MR3 ; STORE MAINT REG.3
3177 011536 012737 000020 004206      MOV      #S.SEEK,E.MR2   ; LOAD EXPECTED MAINT REG. 2
3178 011544 023737 004160 004120      CMP      E.CS1,T.CS1     ; CHECK IF CS1 CORRECT
3179 011552 001405          BEQ     3$               ; YES, CHECK MESSAGE A&B
3180 011554 104017          ERROR  17
3181 011556 012762 100000 000000      MOV      #CCLR,RKCS1(R2) ; CLEAN UP FOR NEXT CONFIGURATION
3182 011564 000434          BR     25$              ; CHECK IF LOOP ON ERROR
3183
3184 011566 032737 000020 004146      3$: BIT      #S.SEEK,T.MR2 ; CHECK IF SEEK COMMAND BIT SEEK
3185 011574 001002          BNE     4$               ; YES, CHECK CYLINDER ADDRESS BITS
3186 011576 104020          ERROR  20
3187 011600 000426          BR     25$              ; CHECK IF LOOP ON ERROR
3188
3189 011602 013737 004150 001160      4$: MOV      T.MR3,$TMPD   ; MASK BITS NOT UNDER TEST
3190 011610 042737 140017 001160      BIC     #140017,$TMPD
3191 011616 023737 004210 001160      CMP      E.MR3,$TMPD     ; CHECK IF CYLINDER ADDRESS BITS CORRECT
3192 011624 001402          BEQ     5$               ; YES, CHECK MESSAGES A&B
3193 011626 104021          ERROR  21
3194 011630 000412          BR     25$              ; CHECK IF LOOP ON ERROR
3195
3196 011632 023737 004206 004146      5$: CMP      E.MR2,T.MR2   ; CHECK IF MESSAGE A CORRECT
3197 011640 001401          BEQ     6$               ; YES, CHECK MESSAGE B
3198 011642 104022          ERROR  22
3199 011644 023737 004210 004150      6$: CMP      E.MR3,T.MR3   ; CHECK IF MESSAGE IS CORRECT
3200 011652 001401          BEQ     25$              ; YES, CHECK IF LOOP ON ERROR
3201 011654 104023          ERROR  23
3202 011656 104415          25$: SCOP1 ; CHECK IF LOOP ON ERROR
3203 011660 022737 001400 004252      CMP      #1400,CYLIN     ; CHECK IF CYLINDER 1400
3204 011666 001407          BEQ     TST15           ; YES, GO ON TO NEXT TEST
3205 011670 012737 001400 004252      MOV      #1400,CYLIN     ; SET CYLINDER=1400
3206 011676 012737 010000 004210      MOV      #10000,E.MR3    ; LOAD EXPECTED CONFIGUR
3207 011704 000655          BR     1$               ; TRY NEXT CONFIGURATION
3208
3209 ;*****
3210 ;*TEST 15          SEEK AND CYLINDER ADD 0,777-1777 LOADING FOR DRIVE MESS

```

K05

CZR6BCO RK611 DSKLS CTRL PRT2  
CZR6BC.P11 02-DEC-77 09:22

MACY11 30(1046) 02-DEC-77 09:31 PAGE 62  
T15 SEEK AND CYLINDER ADD 0,777-1777 LOADING FOR DRIVE MESS

SEQ 0062

```

3211 : *
3212 : * CLEAR RK611 WITH CONTROLLER CLEAR. PUT CONTROLLER IN
3213 : * DIAGNOSTIC MODE. LOAD 0 IN CYLINDER ADDRESS. LOAD
3214 : * COMMAND AND STATUS REGISTER 1 WITH SEEK COMMAND AND
3215 : * CDT SET. CLOCK IN MESSAGE A AND B INTO SHIFT REGISTER.
3216 : * MAKE SURE CYLINDER CORRECT. REPEAT FOR CYLINDER = 777-1777.
3217 : *
3218 : * *****
3219 011706 000004 TST15: SCOPE
3220 011710 012737 000144 001200 MOV #100, $TIMES ; DO 100 ITERATIONS
3221 011716 013702 001270 MOV $BASE, R2 ; LOAD RK611 BASE
3222 011722 005037 004252 CLR CYLIN ; INITIALIZE CYLINDER
3223 011726 012737 002017 004160 MOV #CDT!SEEK, E.CS1 ; LOAD EXPECTED CS1
3224 011734 012737 011742 001110 MOV #1$, $LPERA ; LOAD LOOP ON ERROR LOCATION FOR
3225 ; SUBTEST LOOP
3226
3227 011742 1$: MOV #CCLR, RKCS1(R2) ; CLEAR RK611
3228 011742 012762 100000 000000 MOV #DMD, RKMR1(R2) ; PUT RK611 IN MAINTENANCE MODE
3229 011750 012762 000040 000026 MOV CYLIN, RKDCYL(R2) ; LOAD CYLINDER ADDRESS
3230 011756 013762 004252 000020 MOV #CDT!SEEK, RKCS1(R2) ; ISSUE SEEK WITH CDT SET
3231 011764 012762 002017 000000 MOV #3*4+2, R0 ; CLOCK IN DRIVE MESSAGE
3232 011772 012700 000016 2$: MOV #DMD!MCLK, RKMR1(R2)
3233 011776 012762 000440 000026 MOV #DMD, RKMR1(R2)
3234 012004 012762 000040 000026 DEC R0
3235 012012 005300 BNE 2$
3236 012014 001370
3237 012016 016237 000000 004120 MOV RKCS1(R2), T.CS1 ; STORE COMMAND AND STATUS REG. 1
3238 012024 016237 000034 004146 MOV RKMR2(R2), T.MR2 ; STORE MAINT REG. 2
3239 012032 016237 000036 004150 MOV RKMR3(R2), T.MR3 ; STORE MAINT REG. 3
3240 012040 012737 000020 004206 MOV #S.SEEK, E.MR2 ; LOAD EXPECTED MAINT REG. 2
3241 012046 013737 004252 004210 MOV CYLIN, E.MR3 ; GENERATE EXPECTED MAINT REG. 3
3242 012054 006337 004210 ASL E.MR3
3243 012060 006337 004210 ASL E.MR3
3244 012064 006337 004210 ASL E.MR3
3245 012070 006337 004210 ASL E.MR3
3246 012074 023737 004160 004120 CMP E.CS1, T.CS1 ; CHECK IF CS1 CORRECT
3247 012102 001405 BEQ 3$ ; YES, CHECK MESSAGE A&B
3248 012104 104024 ERROR 24
3249 012106 012762 100000 000000 MOV #CCLR, RKCS1(R2) ; CLEAN UP FOR NEXT CONFIGURATION
3250 012114 000434 BR 25$ ; CHECK IF LOOP ON ERROR
3251
3252 012116 032737 000020 004146 3$: BIT #S.SEEK, T.MR2 ; CHECK IF SEEK COMMAND BIT SET
3253 012124 001002 BNE 4$ ; YES, CHECK CYLINDER ADDRESS BITS
3254 012126 104025 ERROR 25 ; SEEK BIT NOT SEEK
3255 012130 000426 BR 25$ ; CHECK IF LOOP ON ERROR
3256
3257 012132 013737 004150 001160 4$: MOV T.MR3, $TMP0 ; MASK BITS NOT UNDER TEST
3258 012140 042737 140017 001160 BIC #140017, $TMP0
3259 012146 023737 004210 001160 CMP E.MR3, $TMP0 ; CHECK IF CYLINDER ADDRESS BITS CORRECT
3260 012154 001402 BEQ 5$ ; YES, CHECK MESSAGES A&B
3261 012156 104026 ERROR 26 ; CYLINDER ADDRESS BIT INCORRECT
3262 012160 000412 BR 25$ ; CHECK IF LOOP ON ERROR
3263
3264 012162 023737 004206 004146 5$: CMP E.MR2, T.MR2 ; CHECK IF MESSAGE A CORRECT
3265 012170 001401 BEQ 6$ ; YES, CHECK M MESSAGE B
3266 012172 104027 ERROR 27

```

LOS

CZR6BCD RK611 DSKLS CTRL PRT2  
CZR6BC.P11 02-DEC-77 09:22

MACY11 30(1046) 02-DEC-77 09:31 PAGE 63  
T15 SEEK AND CYLINDER ADD 0,777-1777 LOADING FOR DRIVE MESS

SEQ 0063

```

3267 012174 023737 004210 004150 6$: CMP E.MR3,T.MR3 ;CHECK IF MESSAGE B
3268 012202 001401 BEQ 25$ ;YES, CHECK IF LOOP ON ERROR
3269 012204 104030 ERROR 30 ;MESSAGE B INCORRECT
3270 012206 104415 25$: SCOPI ;CHECK IF LOOP ON ERROR
3271 012210 005737 004252 TST CYLIN ;CHECK IF ZERO
3272 012214 001003 BNE 26$ ;NO, INCREMENT CYLINDER
3273 012216 012737 000776 004252 MOV #776,CYLIN ;NEXT CYLINDER=777
3274 012224 005237 004252 26$: INC CYLIN ;INCREMENT CYLINDER NUMBER
3275 012230 022737 001777 004252 CMP #1777,CYLIN ;CHECK IF FINISHED
3276 012236 103241 BHIS 1$ ;NO, TRY NEXT CONFIGURATION
3277
3278 ;*****
3279 ;*TEST 16 OFFSET COMMAND LOADING FOR DRIVE MESS.
3280 ;*
3281 ;* CLEAR RK611 WITH CONTROLLER CLEAR. PUT CONTROLLER IN
3282 ;* DIAGNOSTIC MODE. LOAD OFFSET REGISTER WITH 0. LOAD
3283 ;* COMMAND AND STATUS REGISTER 1 WITH AN OFFSET. CLOCK
3284 ;* MESSAGES A AND B INTO SHIFT REGISTERS. MAKE SURE SHIFT
3285 ;* REGISTERS ARE LOADED CORRECTLY. REPEAT FOR OFFSET
3286 ;* REGISTER = 1-377.
3287 ;*
3288 ;*****
3289 012240 000004 TST16: SCOPE
3290 012242 012737 000144 001200 MOV #100,$TIMES ;DO 100. ITERATIONS
3291 012250 013702 001270 MOV $BASE,R2 ;LOAD RK611 BASE
3292 012254 005037 004254 CLR OFFVAL ;INITIALIZE OFFSET VALUE
3293 012260 012737 000015 004160 MOV #OFFSET,E.CS1 ;LOAD EXPECTED CS1
3294 012266 005037 004206 CLR E.MR2 ;LOAD EXPECT MAINT REG 2
3295 012272 012737 012300 001110 MOV #1$, $LPERR ;LOAD LOOP ON ERROR LOCATION FOR
3296 ; SUBTEST LOOP
3297
3298 012300 1$: MOV #CCLR,RKCS1(R2) ;CLEAR RK611
3299 012300 012762 100000 000000 MOV #DMD,RKMR1(R2) ;PUT RK611 IN MAINT MODE
3300 012306 012762 000040 000026 MOV OFFVAL,RKASOF(R2) ;LOAD OFFSET VALUE
3301 012314 013762 004254 000016 MOV #OFFSET,RKCS1(R2) ;ISSUE OFFSET
3302 012322 012762 000015 000000 MOV #3*4+2,R0 ;CLOCK IN DRIVE MESSAGE
3303 012330 012700 000016 2$: MOV #DMD!MCLK,RKMR1(R2)
3304 012334 012762 000440 000026 MOV #DMD,RKMR1(R2)
3305 012342 012762 000040 000026 DEC R0
3306 012350 005300 BNE 2$
3307 012352 001370
3308 012354 016237 000000 004120 MOV RKCS1(R2),T.CS1 ;STORE COMMAND AND STATUS REG. 1
3309 012362 016237 000034 004146 MOV RKMR2(R2),T.MR2 ;STORE MAINT REG. 2
3310 012370 016237 000036 004150 MOV RKMR3(R2),T.MR3 ;STORE MAINT REG. 3
3311 012376 005037 004210 CLR E.MR3 ;LOAD EXPECTED MAINT REG. 2
3312 012402 013737 004254 004210 MOV OFFVAL,E.MR3 ;GENERATE EXPECTED MR3
3313 012410 005137 004210 COM E.MR3
3314 012414 042737 177700 004210 BIC #177700,E.MR3
3315 012422 006337 004210 ASL E.MR3
3316 012426 006337 004210 ASL E.MR3
3317 012432 006337 004210 ASL E.MR3
3318 012436 006337 004210 ASL E.MR3
3319 012442 052737 014000 004210 BIS #14000,E.MR3
3320 012450 032737 000200 004254 BIT #BIT7,OFFVAL ;DETERMINE SIGN
3321 012456 001003 BNE 10$
3322 012460 052737 002000 004210 BIS #BIT10,E.MR3

```



M05

CZR6BC0 RK611 DSKLS CTRL PRT2  
CZR6BC.P11 02-DEC-77 09:22

MACY11 30(1046) 02-DEC-77 09:31 PAGE 64  
T16 OFFSET COMMAND LOADING FOR DRIVE MESS.

SEQ 0064

3323	012466	023737	004160	004120	10\$:	CMP	E.CS1,T.CS1	;CHECK IF CS1 CORRECT
3324	012474	001405				BEQ	4\$	;YES, CHECK MESSAGE A&B
3325	012476	104031				ERROR	31	
3326	012500	012762	100000	000000		MOV	#CCLR,RKCS1(R2)	;CLEAN UP FOR NEXT CONFIGURATION
3327	012506	000426				BR	25\$	;CHECK IF LOOP ON ERROR
3328								
3329	012510	013737	004150	001160	4\$:	MOV	T.MR3,\$TMPD	;MASK BITS NOT UNDER TEST
3330	012516	042737	140017	001160		BIC	#140017,\$TMPD	
3331	012524	023737	004210	001160		CMP	E.MR3,\$TMPD	;CHECK IF OFFSET VALUE CORRECT
3332	012532	001402				BEQ	5\$	;YES, CHECK MESSAGES A&B
3333	012534	104032				ERROR	32	;OFFSET VALUE INCORRECT
3334	012536	000412				BR	25\$	;CHECK IF LOOP ON ERROR
3335								
3336	012540	023737	004206	004146	5\$:	CMP	E.MR2,T.MR2	;CHECK IF MESSAGE A CORRECT
3337	012546	001401				BEQ	6\$	;YES, CHECK MESSAGE B
3338	012550	104033				ERROR	33	;MESSAGE A INCORRECT
3339	012552	023737	004210	004150	6\$:	CMP	E.MR3,T.MR3	;CHECK IF MESSAGE B CORRECT
3340	012556	001401				BEQ	25\$	;YES, CHECK IF LOOP ON ERROR
3341	012562	104034				ERROR	34	;MESSAGE B INCORRECT
3342	012564	104415			25\$:	SCOPI		;CHECK IF LOOP ON ERROR
3343	012566	005237	004254			INC	OFFVAL	;INCREMENT OFFSET VALUE
3344	012572	022737	000377	004254		CMP	#377,OFFVAL	;CHECK IF FINISHED
3345	012600	103237				BHIS	1\$	;NO, TRY NEXT CONFIGURATION

```

*****
*TEST 17      CYLINDER ADDRESS LOADING OF DRIVE MESS (PART 1)
*
*      CLEAR RK611 WITH CONTROLLER CLEAR.  PUT CONTROLLER IN
*      DIAGNOSTIC MODE.  LOAD CYLINDER ADDRESS REGISTER
*      WITH 777.  LOAD THE OFFSET REG TO 52.  LOAD COMMAND
*      AND STATUS REGISTER 1 WITH A SELECT.  CLOCK
*      MESSAGES A AND B INTO SHIFT REGISTERS.  MAKE SURE
*      SHIFT REGISTERS ARE LOADED CORRECTLY AND THE CYLINDER
*      ADDRESS FIELD IS ZERO IN DRIVE MESSAGE.
*****

```

```

*****
†ST17:  SCOPE
MOV      #100,$TIMES      ;;DO 100. ITERATIONS
MOV      $BASE,R2        ;;LOAD RK611 BASE
MOV      #1777,CYLIN     ;;LOAD CYLINDER VALUE
MOV      #52,OFFVAL      ;;LOAD OFFSET VALUE
MOV      #SELDRV,E.CS1   ;;LOAD EXPECTED CS1
MOV      #CCLR,RKCS1(R2) ;;CLEAR RK611
MOV      #DMD,RKMR1(R2)  ;;PUT RK611 IN MAINTENANCE MODE
MOV      #1777,RKDCYL(R2) ;;LOAD CYLINDER VALUE
MOV      #52,RKASOF(R2)  ;;LOAD OFFSET VALUE
MOV      #SELDRV,RKCS1(R2) ;;ISSUE SELDRV
MOV      #3*4+2,R0       ;;CLOCK IN DRIVE MESSAGE
1$:      MOV      #DMD!MCLK,RKMR1(R2)
MOV      #DMD,RKMR1(R2)
DEC      R0
BNE      1$
MOV      RKCS1(R2),T.CS1  ;;STORE COMMAND AND STATUS REG. 1
MOV      RKMR2(R2),T.MR2  ;;STORE MAINT REG. 2
MOV      RKMR3(R2),T.MR3  ;;STORE MAINT REG. 3
MOV      #0,E.MR2        ;;LOAD EXPECTED MAINT REG. 2

```

3359	012602	000004						
3360	012604	012737	000144	001200				
3361	012612	013702	001270					
3362	012616	012737	001777	004252				
3363	012624	012737	000052	004254				
3364	012632	012737	000001	004160				
3365	012640	012762	100000	000000				
3366	012646	012762	000040	000026				
3367	012654	012762	001777	000020				
3368	012662	012762	000052	000016				
3369	012670	012762	000001	000000				
3370	012676	012700	000016					
3371	012702	012762	000440	000026	1\$:			
3372	012710	012762	000040	000026				
3373	012716	005300						
3374	012720	001370						
3375	012722	016237	000000	004120				
3376	012730	016237	000034	004146				
3377	012736	016237	000036	004150				
3378	012744	012737	000000	004206				

N05

CZR6BC0 RK611 DSKLS CTRL PRT2  
CZR6BC.P11 02-DEC-77 09:22

MACY11 30(1046)  
T17

02-DEC-77 09:31 PAGE 65  
CYLINDER ADDRESS LOADING OF DRIVE MESS (PART 1)

SEQ 0065

3379	012752	005037	004210		CLR	E.MR3	;LOAD EXPECTED MAINTENANCE REG. 3
3380	012756	023737	004160	004120	CMP	E.CS1,T.CS1	;CHECK IF CS1 CORRECT
3381	012764	001405			BEQ	2\$	;YES, CHECK MESSAGES A&B
3382	012766	104035			ERROR	3\$	
3383	012770	012762	100000	000000	MOV	#CCLR,RKCS1(R2)	;CLEAR CONTROLLER FOR NEXT TEST
3384	012776	000423			BR	TST20	;GO ON TO NEXT TEST
3385							
3386	013000				2\$:		
3387	013000	013737	004150	001160	MOV	T.MR3,\$TMP0	;MASK OUT BITS NOT UNDER TEST
3388	013006	042737	140017	001160	BIC	#140017,\$TMP0	
3389	013014	001402			BEQ	4\$	;CHECK IF CYLINDER ADDRESS ZERO
3390	013016	104037			ERROR	37	;CYLINDER ADDRESS BITS INCORRECT
3391	013020	000412			BR	TST20	;GO ON TO NEXT TEST
3392							
3393	013022	023737	004206	004146	4\$:	CMP	E.MR2,T.MR2
3394	013030	001401			BEQ	5\$	;YES, CHECK MESSAGE B
3395	013032	104040			ERROR	40	;MESS A INCORRECT
3396	013034	023737	004210	004150	5\$:	CMP	E.MR3,T.MR3
3397	013042	001401			BEQ	TST20	;YES, GO ON TO NEXT TEST
3398	013044	104041			ERROR	41	;MESS B INCORRECT
3399							

```

*****
*TEST 20      CYLINDER ADDRESS LOADING OF DRIVE MESS (PART 2)
*
*   CLEAR RK611 WITH CONTROLLER CLEAR.  PUT CONTROLLER IN
*   DIAGNOSTIC MODE.  LOAD CYLINDER ADDRESS REGISTER
*   WITH 777.  LOAD THE OFFSET REG TO 52.  LOAD COMMAND
*   AND STATUS REGISTER 1 WITH A PACK ACKNOWLEDGE.  CLOCK
*   MESSAGES A AND B INTO SHIFT REGISTERS.  MAKE SURE
*   SHIFT REGISTERS ARE LOADED CORRECTLY AND THE CYLINDER
*   ADDRESS FIELD IS ZERO IN DRIVE MESSAGE.
*
*****

```

3400							
3401							
3402							
3403							
3404							
3405							
3406							
3407							
3408							
3409							
3410							
3411							
3412	013046	000004			TST20:	SCOPE	
3413	013050	012737	000144	001200	MOV	#100,\$TIMES	;DO 100. ITERATIONS
3414	013056	013702	001270		MOV	\$BASE,R2	;LOAD RK611 BASE
3415	013062	012737	001777	004252	MOV	#1777,CYLIN	;LOAD CYLINDER VALUE
3416	013070	012737	000052	004254	MOV	#52,OFFVAL	;LOAD OFFSET VALUE
3417	013076	012737	000003	004160	MOV	#PACK,E.CS1	;LOAD EXPECTED CS1
3418	013104	012762	100000	000000	MOV	#CCLR,RKCS1(R2)	;CLEAR RK611
3419	013112	012762	000040	000026	MOV	#DMD,RKMR1(R2)	;PUT RK611 IN MAINTENANCE MODE
3420	013120	012762	001777	000020	MOV	#1777,RKDCYL(R2)	;LOAD CYLINDER VALUE
3421	013126	012762	000052	000016	MOV	#52,RKASOF(R2)	;LOAD OFFSET VALUE
3422	013134	012762	000003	000000	MOV	#PACK,RKCS1(R2)	;ISSUE PACK
3423	013142	012700	000016		MOV	#3*4+2,R0	;CLOCK IN DRIVE MESSAGE
3424	013146	012762	000440	000026	1\$:	MOV	#DMD:MCLK,RKMR1(R2)
3425	013154	012762	000040	000026	MOV	#DMD,RKMR1(R2)	
3426	013162	005300			R0		
3427	013164	001370			BNE	1\$	
3428	013166	016237	000000	004120	MOV	RKCS1(R2),T.CS1	;STORE COMMAND AND STATUS REG. 1
3429	013174	016237	000034	004146	MOV	RKMR2(R2),T.MR2	;STORE MAINT REG. 2
3430	013202	016237	000036	004150	MOV	RKMR3(R2),T.MR3	;STORE MAINT REG. 3
3431	013210	012737	004000	004206	MOV	#S.PACK,E.MR2	;LOAD EXPECTED MAINT REG. 2
3432	013216	005037	004210		CLR	E.MR3	;LOAD EXPECTED MAINTENANCE REG. 3
3433	013222	023737	004160	004120	CMP	E.CS1,T.CS1	;CHECK IF CS1 CORRECT
3434	013230	001405			BEQ	2\$	;YES, CHECK MESSAGES A&B

```

3435 013232 104035          ERROR 35
3436 013234 012762 100000 000000 MOV   #CCLR,RKCS1(R2) ;CLEAR CONTROLLER FOR NEXT TEST
3437 013242 000431          BR    TST21          ;;GO ON TO NEXT TEST
3438
3439 013244          25:
3440 013244 032737 004000 004146 BIT   #S.PACK,T.MR2   ;CHECK IF PACK COMMAND
3441                                ; BIT SET
3442 013252 001002          BNE   35            ;YES, CHECK CYLINDER ADDRESS BITS
3443 013254 104036          ERROR 36            ;S.PACK BIT NOT SET
3444 013256 000423          BR    TST21          ;;GO ON TO NEXT TEST
3445
3446 013260          35:
3447 013260 013737 004150 001160 MOV   T.MR3,$TMPD   ;MASK OUT BITS NOT UNDER TEST
3448 013266 042737 140017 001160 BIC   #140017,$TMPD
3449 013274 001402          BEQ   45            ;CHECK IF CYLINDER ADDRESS ZERO
3450 013276 104037          ERROR 37            ;CYLINDER ADDRESS BITS INCORRECT
3451 013300 000412          BR    TST21          ;;GO ON TO NEXT TEST
3452
3453 013302 023737 004206 004146 45:  CMP   E.MR2,T.MR2   ;CHECK IF MESSAGE A CORRECT
3454 013310 001401          BEQ   55            ;YES, CHECK MESSAGE B
3455 013312 104040          ERROR 40            ;MESS A INCORRECT
3456 013314 023737 004210 004150 55:  CMP   E.MR3,T.MR3   ;CHECK IF MESSAGE B CORRECT
3457 013322 001401          BEQ   TST21        ;YES, GO ON TO NEXT TEST
3458 013324 104041          ERROR 41            ;MESS B INCORRECT
3459
3460 *****
3461 *TEST 21          CYLINDER ADDRESS LOADING OF DRIVE MESS (PART 3)
3462 *
3463 *          CLEAR RK611 WITH CONTROLLER CLEAR. PUT CONTROLLER IN
3464 *          DIAGNOSTIC MODE. LOAD CYLINDER ADDRESS REGISTER
3465 *          WITH 777. LOAD THE OFFSET REG TO 52. LOAD COMMAND
3466 *          AND STATUS REGISTER 1 WITH A CLEAR DRIVE. CLOCK
3467 *          MESSAGES A AND B INTO SHIFT REGISTERS. MAKE SURE
3468 *          SHIFT REGISTERS ARE LOADED CORRECTLY AND THE CYLINDER
3469 *          ADDRESS FIELD IS ZERO IN DRIVE MESSAGE.
3470 *
3471 *****
3472 TST21: SCOPE
3473 013326 000004          MOV   #100,$TIMES   ;;DO 100. ITERATIONS
3474 013330 012737 000144 001200 MOV   $BASE,R2      ;LOAD RK611 BASE
3475 013336 013702 001270          MOV   #1777,CYLIN  ;LOAD CYLINDER VALUE
3476 013342 012737 001777 004252 MOV   #52,OFFVAL   ;LOAD OFFSET VALUE
3477 013350 012737 000052 004254 MOV   #CLEAR,E.CS1 ;LOAD EXPECTED CS1
3478 013364 012762 100000 000000 MOV   #CCLR,RKCS1(R2);CLEAR RK611
3479 013372 012762 000040 000026 MOV   #DMD,RKMR1(R2);PUT RK611 IN MAINTENANCE MODE
3480 013400 012762 001777 000020 MOV   #1777,RKDCYL(R2);LOAD CYLINDER VALUE
3481 013406 012762 000052 000016 MOV   #52,RKASOF(R2);LOAD OFFSET VALUE
3482 013414 012762 000005 000000 MOV   #CLEAR,RKCS1(R2);ISSUE CLEAR
3483 013422 012700 000016          MOV   #3*4+2,RO    ;CLOCK IN DRIVE MESSAGE
3484 013426 012762 000440 000026 15:  MOV   #DMD,MCLK,RKMR1(R2)
3485 013434 012762 000040 000026 MOV   #DMD,RKMR1(R2)
3486 013442 005300          DEC   RO
3487 013444 001370          BNE   15
3488 013446 016237 000000 004120 MOV   RKCS1(R2),T.CS1 ;STORE COMMAND AND STATUS REG. 1
3489 013454 016237 000034 004146 MOV   RKMR2(R2),T.MR2 ;STORE MAINT REG. 2
3490 013462 016237 000036 004150 MOV   RKMR3(R2),T.MR3 ;STORE MAINT REG. 3

```

```

3491 013470 012737 000400 004206 MOV #S.CLR,E.MR2 ;LOAD EXPECTED MAINT REG. 2
3492 013476 005037 004210 CLR E.MR3 ;LOAD EXPECTED MAINTENANCE REG. 3
3493 013502 023737 004160 CMP E.CS1,T.CS1 ;CHECK IF CSI CORRECT
3494 013510 001405 BEQ 25 ;YES, CHECK MESSAGES A&B
3495 013512 104035 ERROR 35
3496 013514 012762 100000 000000 MOV #CCLR,RKCS1(R2) ;CLEAR CONTROLLER FOR NEXT TEST
3497 013522 000431 BR TST22 ;GO ON TO NEXT TEST
3498
3499 013524 25:
3500 013524 032737 000400 004146 BIT #S.CLR.T.MR2 ;CHECK IF CLEAR COMMAND
3501 ; BIT SET
3502 013532 001002 BNE 35 ;YES, CHECK CYLINDER ADDRESS BITS
3503 013534 104036 ERROR 36 ;S.CLR BIT NOT SET
3504 013536 000423 BR TST22 ;GO ON TO NEXT TEST
3505
3506 013540 35:
3507 013540 013737 004150 001160 MOV T.MR3,$TMP0 ;MASK OUT BITS NOT UNDER TEST
3508 013546 042737 140017 001160 BIC #140017,$TMP0
3509 013554 001402 BEQ 45 ;CHECK IF CYLINDER ADDRESS ZERO
3510 013556 104037 ERROR 37 ;CYLINDER ADDRESS BITS INCORRECT
3511 013560 000412 BR TST22 ;GO ON TO NEXT TEST
3512
3513 013562 023737 004206 004146 45: CMP E.MR2,T.MR2 ;CHECK IF MESSAGE A CORRECT
3514 013570 001401 BEQ 55 ;YES, CHECK MESSAGE B
3515 013572 104040 ERROR 40 ;MESS A INCORRECT
3516 013574 023737 004210 004150 55: CMP E.MR3,T.MR3 ;CHECK IF MESSAGE B CORRECT
3517 013602 001401 BEQ TST22 ;YES, GO ON TO NEXT TEST
3518 013604 104041 ERROR 41 ;MESS B INCORRECT
3519
3520
3521
3522
3523
3524
3525
3526
3527
3528
3529
3530
3531
3532
3533
3534
3535
3536
3537
3538
3539
3540
3541
3542
3543
3544
3545
3546

```

```

*****
*TEST 22 CYLINDER ADDRESS LOADING OF DRIVE MESS (PART 4)
*

```

```

* CLEAR RK611 WITH CONTROLLER CLEAR. PUT CONTROLLER IN
* DIAGNOSTIC MODE. LOAD CYLINDER ADDRESS REGISTER
* WITH 777. LOAD THE OFFSET REG TO 52. LOAD COMMAND
* AND STATUS REGISTER 1 WITH AN UNLOAD. CLOCK
* MESSAGES A AND B INTO SHIFT REGISTERS. MAKE SURE
* SHIFT REGISTERS ARE LOADED CORRECTLY AND THE CYLINDER
* ADDRESS FIELD IS ZERO IN DRIVE MESSAGE.
*

```

```

*****
*ST22: SCOPE
MOV #100,$TIMES ;DO 100. ITERATIONS
MOV $BASE,R2 ;LOAD RK611 BASE
MOV #1777,CYLIN ;LOAD CYLINDER VALUE
MOV #52,OFFVAL ;LOAD OFFSET VALUE
MOV #UNLOAD,E.CS1 ;LOAD EXPECTED CSI
MOV #CCLR,RKCS1(R2) ;CLEAR RK611
MOV #DMD,RKMR1(R2) ;PUT RK611 IN MAINTENANCE MODE
MOV #1777,RKDCYL(R2) ;LOAD CYLINDER VALUE
MOV #52,RKASOF(R2) ;LOAD OFFSET VALUE
MOV #UNLOAD,RKCS1(R2) ;ISSUE UNLOAD
MOV #3*4+2,RO ;CLOCK IN DRIVE MESSAGE
15: MOV #DMD,MCLK,RKMR1(R2)
MOV #DMD,RKMR1(R2)
DEC RO

```

3547	013724	001370			BNE	15		
3548	013726	016237	000000	004120	MOV	RKCS1(R2),T.CS1	:STORE COMMAND AND STATUS REG. 1	
3549	013734	016237	000034	004146	MOV	RKMR2(R2),T.MR2	:STORE MAINT REG. 2	
3550	013742	016237	000036	004150	MOV	RKMR3(R2),T.MR3	:STORE MAINT REG. 3	
3551	013750	012737	002000	004206	MOV	#S.UNLD,E.MR2	:LOAD EXPECTED MAINT REG. 2	
3552	013756	005037	004210		CLR	E.MR3	:LOAD EXPECTED MAINTENANCE REG. 3	
3553	013762	023737	004160	004120	CMP	E.CS1,T.CS1	:CHECK IF CSI CORRECT	
3554	013770	001405			BEQ	25	:YES, CHECK MESSAGES A&B	
3555	013772	104035			ERROR	35		
3556	013774	012762	100000	000000	MOV	#CCLR,RKCS1(R2)	:CLEAR CONTROLLER FOR NEXT TEST	
3557	014002	000431			BR	TST23	:GO ON TO NEXT TEST	
3558								
3559	014004				25:			
3560	014004	032737	002000	004146	BIT	#S.UNLD,T.MR2	:CHECK IF UNLOAD COMMAND	
3561							:BIT SET	
3562	014012	001002			BNE	35	:YES, CHECK CYLINDER ADDRESS BITS	
3563	014014	104036			ERROR	36	:S.UNLD BIT NOT SET	
3564	014016	000423			BR	TST23	:GO ON TO NEXT TEST	
3565								
3566	014020				35:			
3567	014020	013737	004150	001160	MOV	T.MR3,\$TMP0	:MASK OUT BITS NOT UNDER TEST	
3568	014026	042737	140017	001160	BIC	#140017,\$TMP0		
3569	014034	001402			BEQ	45	:CHECK IF CYLINDER ADDRESS ZERO	
3570	014036	104037			ERROR	37	:CYLINDER ADDRESS BITS INCORRECT	
3571	014040	000412			BR	TST23	:GO ON TO NEXT TEST	
3572								
3573	014042	023737	004206	004146	45:	CMP	E.MR2,T.MR2	:CHECK IF MESSAGE A CORRECT
3574	014050	001401			BEQ	55	:YES, CHECK MESSAGE B	
3575	014052	104040			ERROR	40	:MESS A INCORRECT	
3576	014054	023737	004210	004150	55:	CMP	E.MR3,T.MR3	:CHECK IF MESSAGE B CORRECT
3577	014062	001401			BEQ	TST23	:YES, GO ON TO NEXT TEST	
3578	014064	104041			ERROR	41	:MESS B INCORRECT	
3579								

```

*****
*TEST 23      CYLINDER ADDRESS LOADING OF DRIVE MESS (PART 5)
*
* CLEAR RK611 WITH CONTROLLER CLEAR.  PUT CONTROLLER IN
* DIAGNOSTIC MODE.  LOAD CYLINDER ADDRESS REGISTER
* WITH 777.  LOAD THE OFFSET REG TO 52.  LOAD COMMAND
* AND STATUS REGISTER 1 WITH A START SPINDLE.  CLOCK
* MESSAGES A AND B INTO SHIFT REGISTERS.  MAKE SURE
* SHIFT REGISTERS ARE LOADED CORRECTLY AND THE CYLINDER
* ADDRESS FIELD IS ZERO IN DRIVE MESSAGE.
*****

```

3580								
3581								
3582								
3583								
3584								
3585								
3586								
3587								
3588								
3589								
3590								
3591								
3592	014066	000004			TST23:	SCOPE		
3593	014070	012737	000144	001200	MOV	#100,\$TIMES	:DO 100. ITERATIONS	
3594	014076	013702	001270		MOV	\$BASE,R2	:LOAD RK611 BASE	
3595	014102	012737	001777	004252	MOV	#1777,CYLIN	:LOAD CYLINDER VALUE	
3596	014110	012737	000052	004254	MOV	#52,OFFVAL	:LOAD OFFSET VALUE	
3597	014116	012737	000011	004160	MOV	#SRTSPL,E.CS1	:LOAD EXPECTED CS1	
3598	014124	012762	100000	000000	MOV	#CCLR,RKCS1(R2)	:CLEAR RK611	
3599	014132	012762	000040	000026	MOV	#DMD,RKMR1(R2)	:PUT RK611 IN MAINTENANCE MODE	
3600	014140	012762	001777	000020	MOV	#1777,RKDCYL(R2)	:LOAD CYLINDER VALUE	
3601	014146	012762	000052	000016	MOV	#52,RKASOF(R2)	:LOAD OFFSET VALUE	
3602	014154	012762	000011	000000	MOV	#SRTSPL,RKCS1(R2)	:ISSUE SRTSPL	

E06

CZR6BCD RK611 OSKLS CTRL PRT2  
CZR6BC.P11 02-DEC-77 09:22

MACY11 30(1046) 02-DEC-77 09:31 PAGE 69  
T23 CYLINDER ADDRESS LOADING OF DRIVE MESS (PART 5)

SEQ 0069

```

3603 014162 012700 000016      MOV      #3*4+2,R0      ;CLOCK IN DRIVE MESSAGE
3604 014166 012762 000440 000026 1$:  MOV      #DMD!MCLK,RKMR1(R2)
3605 014174 012762 000040 000026  MOV      #DMD,RKMR1(R2)
3606 014202 005300      DEC      R0
3607 014204 001370      BNE     1$
3608 014206 016237 000000 004120  MOV      RKCS1(R2),T.CS1 ;STORE COMMAND AND STATUS REG. 1
3609 014214 016237 000034 004146  MOV      RKMR2(R2),T.MR2 ;STORE MAINT REG. 2
3610 014222 016237 000036 004150  MOV      RKMR3(R2),T.MR3 ;STORE MAINT REG. 3
3611 014230 012737 000100 004206  MOV      #S.STSP,E.MR2  ;LOAD EXPECTED MAINT REG. 2
3612 014236 005037 004210      CLR     E.MR3          ;LOAD EXPECTED MAINTENANCE REG. 3
3613 014242 023737 004160 004120  CMP      E.CS1,T.CS1   ;CHECK IF CS1 CORRECT
3614 014250 001405      BEQ     2$            ;YES, CHECK MESSAGES A&B
3615 014252 104035      ERROR   35
3616 014254 012762 100000 000000  MOV      #CCLR,RKCS1(R2) ;CLEAR CONTROLLER FOR NEXT TEST
3617 014262 000431      BR      TST24        ;GO ON TO NEXT TEST
3618
3619 014264      2$:
3620 014264 032737 000100 004146  BIT      #S.STSP,T.MR2 ;CHECK IF SRTSPL COMMAND
3621      ;BIT SET
3622 014272 001002      BNE     3$            ;YES, CHECK CYLINDER ADDRESS BITS
3623 014274 104036      ERROR   36
3624 014276 000423      BR      TST24        ;GO ON TO NEXT TEST
3625
3626 014300      3$:
3627 014300 013737 004150 001160  MOV      T.MR3,$TMP0   ;MASK OUT BITS NOT UNDER TEST
3628 014306 042737 140017 001160  BIC     #140017,$TMP0
3629 014314 001402      BEQ     4$            ;CHECK IF CYLINDER ADDRESS ZERO
3630 014316 104037      ERROR   37
3631 014320 000412      BR      TST24        ;CYLINDER ADDRESS BITS INCORRECT
3632      ;GO ON TO NEXT TEST
3633 014322 023737 004206 004146  4$:  CMP      E.MR2,T.MR2   ;CHECK IF MESSAGE A CORRECT
3634 014330 001401      BEQ     5$            ;YES, CHECK MESSAGE B
3635 014332 104040      ERROR   40
3636 014334 023737 004210 004150  5$:  CMP      E.MR3,T.MR3   ;CHECK IF MESSAGE B CORRECT
3637 014342 001401      BEQ     TST24        ;YES, GO ON TO NEXT TEST
3638 014344 104041      ERROR   41
3639      ;MESS B INCORRECT

```

```

*****
*TEST 24      CYLINDER ADDRESS LOADING OF DRIVE MESS (PART 6)
*
* CLEAR RK611 WITH CONTROLLER CLEAR. PUT CONTROLLER IN
* DIAGNOSTIC MODE. LOAD CYLINDER ADDRESS REGISTER
* WITH 777. LOAD THE OFFSET REG TO 52. LOAD COMMAND
* AND STATUS REGISTER 1 WITH A RECALIBRATE. CLOCK
* MESSAGES A AND B INTO SHIFT REGISTERS. MAKE SURE
* SHIFT REGISTERS ARE LOADED CORRECTLY AND THE CYLINDER
* ADDRESS FIELD IS ZERO IN DRIVE MESSAGE.
*****

```

```

3651
3652 014346 000004      TST24: SCOPE
3653 014350 012737 000144 001200  MOV      #100,$TIMES  ;DO 100. ITERATIONS
3654 014356 013702 001270      MOV      $BASE,R2     ;LOAD RK611 BASE
3655 014362 012737 001777 004252  MOV      #1777,CYLIN  ;LOAD CYLINDER VALUE
3656 014370 012737 000052 004254  MOV      #52,OFFVAL   ;LOAD OFFSET VALUE
3657 014376 012737 000013 004160  MOV      #RECAL,E.CS1 ;LOAD EXPECTED CS1
3658 014404 012762 100000 000000  MOV      #CCLR,RKCS1(R2) ;CLEAR RK611

```

F06

CZR6BCD RK61: DSKLS CTRL FRT2  
CZR6BC.P11 02-DEC-77 09:22

MACY11 30(1046)  
T24

02-DEC-77 09:31 PAGE 70  
CYLINDER ADDRESS LOADING OF DRIVE MESS (PART 6)

SEQ 0070

3659	014412	012762	000040	000026	MOV	#DMD,RKMR1(R2)	;PUT RK611 IN MAINTENANCE MODE
3660	014420	012762	001777	000020	MOV	#1777,RKDCYL(R2)	;LOAD CYLINDER VALUE
3661	014426	012762	000052	000016	MOV	#52,RKASOF(R2)	;LOAD OFFSET VALUE
3662	014434	012762	000013	000000	MOV	#RECAL,RKCS1(R2)	;ISSUE RECAL
3663	014442	012700	000016	000000	MOV	#3*4+2,RO	;CLOCK IN DRIVE MESSAGE
3664	014446	012762	000440	000026	1\$: MOV	#DMD!MCLK,RKMR1(R2)	
3665	014454	012762	000040	000026	MOV	#DMD,RKMR1(R2)	
3666	014462	005300			DEC	RO	
3667	014464	001370			BNE	1\$	
3668	014466	016237	000000	004120	MOV	RKCS1(R2),T.CS1	;STORE COMMAND AND STATUS REG. 1
3669	014474	016237	000034	004146	MOV	RKMR2(R2),T.MR2	;STORE MAINT REG. 2
3670	014502	016237	000036	004150	MOV	RKMR3(R2),T.MR3	;STORE MAINT REG. 3
3671	014510	012737	000040	004206	MOV	#S.RECL,E.MR2	;LOAD EXPECTED MAINT REG. 2
3672	014516	005037	004210		CLR	E.MR3	;LOAD EXPECTED MAINTENANCE REG. 3
3673	014522	023737	004160	004120	CMP	E.CS1,T.CS1	;CHECK IF CS1 CORRECT
3674	014530	001405			BEQ	2\$	;YES, CHECK MESSAGES A&B
3675	014532	104035			ERROR	35	
3676	014534	012762	100000	000000	MOV	#CCLR,RKCS1(R2)	;CLEAR CONTROLLER FOR NEXT TEST
3677	014542	000431			BR	TST25	;GO ON TO NEXT TEST
3678							
3679	014544				2\$: BIT	#S.RECL,T.MR2	;CHECK IF RECAL COMMAND
3680	014544	032737	000040	004146			;BIT SET
3681							
3682	014552	001002			BNE	3\$	;YES, CHECK CYLINDER ADDRESS BITS
3683	014554	104036			ERROR	36	;S.RECL BIT NOT SET
3684	014556	000423			BR	TST25	;GO ON TO NEXT TEST
3685							
3686	014560				3\$: MOV	T.MR3,\$TMP0	;MASK OUT BITS NOT UNDER TEST
3687	014560	013737	004150	001160	BIC	#140017,\$TMP0	
3688	014566	042737	140017	001160	BEQ	4\$	;CHECK IF CYLINDER ADDRESS ZERO
3689	014574	001402			ERROR	37	;CYLINDER ADDRESS BITS INCORRECT
3690	014576	104037			BR	TST25	;GO ON TO NEXT TEST
3691	014600	000412					
3692							
3693	014602	023737	004206	004146	4\$: CMP	E.MR2,T.MR2	;CHECK IF MESSAGE A CORRECT
3694	014610	001401			BEQ	5\$	;YES, CHECK MESSAGE B
3695	014612	104040			ERROR	40	;MESS A INCORRECT
3696	014614	023737	004210	004150	5\$: CMP	E.MR3,T.MR3	;CHECK IF MESSAGE B CORRECT
3697	014622	001401			BEQ	TST25	;YES, GO ON TO NEXT TEST
3698	014624	104041			ERROR	41	;MESS B INCORRECT
3699							
3700							
3701							
3702							
3703							
3704							
3705							
3706							
3707							
3708							
3709							
3710	014626	000004			TST25: SCOPE		
3711	014630	012737	000144	001200	MOV	#100,\$TIMES	;DO 100. ITERATIONS
3712	014636	013702	001270		MOV	\$BASE,R2	;LOAD RK611 BASE
3713	014642	012737	000017	004246	MOV	#17,MSGCOD	;LOAD MESSAGE CODE FOR PRINT OUT
3714	014650	012737	000003	004160	MOV	#PACK,E.CS1	;LOAD EXPECTED CS1

```

*****
*TEST 25 MESSAGE SELECT BIT CLEARING FOR CLASS A (PART 1)
*
* CLEAR RK611 WITH CONTROLLER CLEAR. PUT CONTROLLER IN
* DIAGNOSTIC MODE WITH MESSAGE SELECT BITS = 17. LOAD
* COMMAND AND STATUS REGISTER 1 WITH A PACK ACKNOWLEDGE.
* CLOCK MESSAGE TO LOAD B SHIFT REG. TIME. MAKE SURE
* MESSAGE SELECT BITS ARE CLEARED.
*
*****

```

G06

CZR6BCO RK611 DSKLS CTRL PRT2  
CZR6BC.P11 02-DEC-77 09:22

MACY11 30(1046)  
T25

02-DEC-77 09:31 PAGE 71  
MESSAGE SELECT BIT CLEARING FOR CLASS A (PART 1)

SEQ 0071

```

3715 014656 012762 100000 000000      MOV      #CCLR,RKCS1(R2) ;CLEAR RK611
3716 014664 012762 000057 000026      MOV      #DMD!17,RKMR1(R2) ;PUT RK611 IN MAINTENANCE MODE
3717                                     ; SELECT MESSAGE 17
3718 014672 012762 000003 000000      MOV      #PACK,RKCS1(R2) ;ISSUE PACK
3719 014700 012700 000016 000000      MOV      #3*4+2,R0 ;CLOCK IN DRIVE MESSAGE
3720 014704 052762 000400 000026 1S:      BIS      #MCLK,RKMR1(R2)
3721 014712 042762 000400 000026      BIC      #MCLK,RKMR1(R2)
3722 014720 005300      DEC      R0
3723 014722 001370      BNE      1S
3724 014724 016237 000000 004120      MOV      RKCS1(R2),T.CS1 ;STORE COMMAND AND STATUS REG. 1
3725 014732 016237 000026 004144      MOV      RKMR1(R2),T.MR1 ;STORE MAINTENANCE REG. 1
3726 014740 016237 000034 004146      MOV      RKMR2(R2),T.MR2 ;STORE MAINTENANCE REG.2
3727 014746 016237 000036 004150      MOV      RKMR3(R2),T.MR3 ;STORE MAINTENANCE REG. 3
3728 014754 0 2737 002040 004204      MOV      #MEWD!DMD,E.MR1 ;LOAD EXPECTED MAINT REG. 1
3729 014762 032737 020000 004144      BIT      #ECCW,T.MR1
3730 014770 001403      BEQ      10S
3731 014772 052737 020000 004204      BIS      #ECCW,E.MR1
3732 015000 012737 004000 004206 10S:      MOV      #S.PACK,E.MR2 ;LOAD EXPECTED MAINT REG. 2
3733 015006 005037 004210      CLR      E.MR3 ;LOAD EXPECTED MAINT REG. 3
3734 015012 023737 004160 004120      CMP      E.CS1,T.CS1 ;CHECK IF CS1 CORRECT
3735 015020 001405      BEQ      2S ;YES, CHECK MAINT REG. 1
3736 015022 104042      ERROR   42
3737 015024 012762 100000 000000      MOV      #CCLR,RKCS1(R2) ;CLEAR RK611 CONTROLLER FOR NEXT TEST
3738 015032 000442      BR      TST26 ;GO ON TO NEXT TEST
3739
3740 015034 023737 004204 004144 2S:      CMP      E.MR1,T.MR1 ;CHECK IF MAINT REG. 1 CORRECT
3741 015042 001405      BEQ      3S ;YES, CHECK MESSAGES A&B
3742 015044 104043      ERROR   43 ;MAINT REG. 1 INCORRECT
3743 015046 012762 100000 000000      MOV      #CCLR,RKCS1(R2) ;CLEAR RK611 CONTROLLER FOR NEXT TEST
3744 015054 000431      BR      TST26 ;GO ON TO NEXT TEST
3745
3746 015056                                     3S:
3747 015056 032737 004000 004146      BIT      #S.PACK,T.MR2 ;CHECK IF PACK COMMAND
3748                                     ; BIT SET
3749 015064 001002      BNE      4S ;YES, CHECK MESSAGE SELECT BITS
3750 015066 104044      ERROR   44 ;S.PACK BIT NOT SET
3751 015070 000423      BR      TST26 ;GO ON TO NEXT TEST
3752
3753 015072                                     4S:
3754 015072 013737 004150 001160      MOV      T.MR3,$TMPD ;MASK OUT BITS NOT UNDER TEST
3755 015100 042737 177760 001160      BIC      #177760,$TMPD
3756 015106 001402      BEQ      5S ;CHECK IF MESSAGE SELECT ZERO
3757 015110 104045      ERROR   45 ;MESSAGE SELECT BITS NOT ZERO
3758 015112 000412      BR      TST26 ;GO ON TO NEXT TEST
3759
3760 015114 023737 004206 004146 5S:      CMP      E.MR2,T.MR2 ;CHECK IF MESSAGE A CORRECT
3761 015122 001401      BEQ      6S ;YES, CHECK MESSAGE B
3762 015124 104046      ERROR   46 ;MESSAGE A INCORRECT
3763 015126 023737 004210 004150 6S:      CMP      E.MR3,T.MR3 ;CHECK IF MESSAGE B CORRECT
3764 015134 001401      BEQ      TST26 ;YES, GO ON TO NEXT TEST
3765 015136 104047      ERROR   47 ;MESS B INCORRECT
3766
3767
3768 *****
3769 *TEST 26 MESSAGE SELECT BIT CLEARING FOR CLASS A (PART 2)
3770 *
* CLEAR RK611 WITH CONTROLLER CLEAR. PUT CONTROLLER IN

```



H06

CZR6BCD RK611 DSKLS CTRL PRT2  
CZR6RC.P11 02-DEC-77 09:22

MACY11 30(1046) 02-DEC-77 09:31 PAGE 72  
T26 MESSAGE SELECT BIT CLEARING FOR CLASS A (PART 2)

SEQ 0072

DIAGNOSTIC MODE WITH MESSAGE SELECT BITS = 17. LOAD  
COMMAND AND STATUS REGISTER 1 WITH A DRIVE CLEAR.  
CLOCK MESSAGE TO LOAD B SHIFT REG. TIME. MAKE SURE  
MESSAGE SELECT BITS ARE CLEARED.

```

3771
3772
3773
3774
3775
3776
3777 015140 000004
3778 015142 012737 000144 001200
3779 015150 013702 001270
3780 015154 012737 000017 004246
3781 015162 012737 000005 004160
3782 015170 012762 100000 000000
3783 015176 012762 000057 000026
3784
3785 015204 012762 000005 000000
3786 015212 012700 000016
3787 015216 052762 000400 000026
3788 015224 042762 000400 000026
3789 015232 005300
3790 015234 001370
3791 015236 016237 000000 004120
3792 015244 016237 000026 004144
3793 015252 016237 000034 004146
3794 015260 016237 000036 004150
3795 015266 012737 002040 004204
3796 015274 032737 020000 004144
3797 015302 001403
3798 015304 052737 020000 004204
3799 015312 012737 000400 004206
3800 015320 005037 004210
3801 015324 023737 004160 004120
3802 015332 001405
3803 015334 104042
3804 015336 012762 100000 000000
3805 015344 000442
3806
3807 015346 023737 004204 004144
3808 015354 001405
3809 015356 104043
3810 015360 012762 100000 000000
3811 015366 000431
3812
3813 015370
3814 015370 032737 000400 004146
3815
3816 015376 001002
3817 015400 104044
3818 015402 000423
3819
3820 015404
3821 015404 013737 004150 001160
3822 015412 042737 177760 001160
3823 015420 001402
3824 015422 104045
3825 015424 000412
3826

```

```

*****
↑ST26: SCOPE
MOV #100.,$TIMES ;;DO 100. ITERATIONS
MOV $BASE,R2 ;;LOAD RK611 BASE
MOV #17,$SGCOD ;;LOAD MESSAGE CODE FOR PRINT OUT
MOV #CLEAR,E.CS1 ;;LOAD EXPECTED CSI
MOV #CCLR,RKCS1(R2) ;;CLEAR RK611
MOV #DMD!17,RKMR1(R2) ;;PUT RK611 IN MAINTENANCE MODE
;; SELECT MESSAGE 17
MOV #CLEAR,RKCS1(R2) ;;ISSUE CLEAR
MOV #3*4+2,R0 ;;CLOCK IN DRIVE MESSAGE
1$: BIS #MCLK,RKMR1(R2)
BIC #MCLK,RKMR1(R2)
DEC R0
BNE 1$
MOV RKCS1(R2),T.CS1 ;;STORE COMMAND AND STATUS REG. 1
MOV RKMR1(R2),T.MR1 ;;STORE MAINTENANCE REG. 1
MOV RKMR2(R2),T.MR2 ;;STORE MAINTENANCE REG. 2
MOV RKMR3(R2),T.MR3 ;;STORE MAINTENANCE REG. 3
MOV #EWD!DMD,E.MR1 ;;LOAD EXPECTED MAINT REG. 1
BIT #ECCW,T.MR1
10$: BEQ 10$
BIS #ECCW,E.MR1
MOV #S.CLR,E.MR2 ;;LOAD EXPECTED MAINT REG. 2
CLR E.MR3 ;;LOAD EXPECTED MAINT REG. 3
CMP E.CS1,T.CS1 ;;CHECK IF CS1 CORRECT
BEQ 2$ ;;YES, CHECK MAINT REG. 1
42 ERROR
MOV #CCLR,RKCS1(R2) ;;CLEAR RK611 CONTROLLER FOR NEXT TEST
BR TST27 ;;GO ON TO NEXT TEST
2$: CMP E.MR1,T.MR1 ;;CHECK IF MAINT REG. 1 CORRECT
BEQ 3$ ;;YES, CHECK MESSAGES A&B
43 ERROR ;;MAINT REG. 1 INCORRECT
MOV #CCLR,RKCS1(R2) ;;CLEAR RK611 CONTROLLER FOR NEXT TEST
BR TST27 ;;GO ON TO NEXT TEST
3$: BIT #S.CLR,T.MR2 ;;CHECK IF CLEAR COMMAND
;; BIT SET
BNE 4$ ;;YES, CHECK MESSAGE SELECT BITS
44 ERROR ;;S.CLR BIT NOT SET
BR TST27 ;;GO ON TO NEXT TEST
4$: MOV T.MR3,$TMPD ;;MASK OUT BITS NOT UNDER TEST
BIC #177760,$TMPD
BEQ 5$ ;;CHECK IF MESSAGE SELECT ZERO
45 ERROR ;;MESSAGE SELECT BITS NOT ZERO
BR TST27 ;;GO ON TO NEXT TEST

```

```

3827 015426 023737 004206 004146 5$: CMP E.MR2,T.MR2 ;CHECK IF MESSAGE A CORRECT
3828 015434 001401 BEQ 6$ ;YES, CHECK MESSAGE B
3829 015436 104046 ERROR 46 ;MESSAGE A INCORRECT
3830 015440 023737 004210 004150 6$: CMP E.MR3,T.MR3 ;CHECK IF MESSAGE B CORRECT
3831 015446 001401 BEQ TST27 ;YES, GO ON TO NEXT TEST
3832 015450 104047 ERROR 47 ;MESS B INCORRECT
3833
3834
3835 *****
3836 *TEST 27 MESSAGE SELECT BIT CLEARING FOR CLASS A (PART 3)
3837 *
3838 * CLEAR RK611 WITH CONTROLLER CLEAR. PUT CONTROLLER IN
3839 * DIAGNOSTIC MODE WITH MESSAGE SELECT BITS = 17. LOAD
3840 * COMMAND AND STATUS REGISTER 1 WITH AN UNLOAD.
3841 * CLOCK MESSAGE TO LOAD B SHIFT REG. TIME. MAKE SURE
3842 * MESSAGE SELECT BITS ARE CLEARED.
3843 *****
3844 †ST27: SCOPE
3845 MOV #100,$TIMES ;DO 100. ITERATIONS
3846 MOV $BASE,R2 ;LOAD RK611 BASE
3847 MOV #17,M$GCODE ;LOAD MESSAGE CODE FOR PRINT OUT
3848 MOV #UNLOAD,E.CS1 ;LOAD EXPECTED CS1
3849 MOV #CCLR,RKCS1(R2) ;CLEAR RK611
3850 MOV #DMC!17,RKMR1(R2) ;PUT RK611 IN MAINTENANCE MODE
3851 ; SELECT MESSAGE 17
3852 10V #UNLOAD,RKCS1(R2) ;ISSUE UNLOAD
3853 MOV #3*4+2,R0 ;CLOCK IN DRIVE MESSAGE
3854 1$: BIS #MCLK,RKMR1(R2)
3855 BIC #MCLK,RKMR1(R2)
3856 R0
3857 BNE 1$
3858 MOV RKCS1(R2),T.CS1 ;STORE COMMAND AND STATUS REG. 1
3859 MOV RKMR1(R2),T.MR1 ;STORE MAINTENANCE REG. 1
3860 MOV RKMR2(R2),T.MR2 ;STORE MAINTENANCE REG. 2
3861 MOV RKMR3(R2),T.MR3 ;STORE MAINTENANCE REG. 3
3862 MOV #MEWD!DMC,E.MR1 ;LOAD EXPECTED MAINT REG. 1
3863 BIT #ECCW,T.MR1
3864 BEQ 10$
3865 BIS #ECCW,E.MR1
3866 10$: MOV #S.UNLD,E.MR2 ;LOAD EXPECTED MAINT REG. 2
3867 CLR E.MR3 ;LOAD EXPECTED MAINT REG. 3
3868 CMP E.CS1,T.CS1 ;CHECK IF CS1 CORRECT
3869 BEQ 2$ ;YES, CHECK MAINT REG. 1
3870 015646 104042 ERROR 42
3871 015650 012762 100000 000000 MOV #CCLR,RKCS1(R2) ;CLEAR RK611 CONTROLLER FOR NEXT TEST
3872 015656 000442 BR TST30 ;GO ON TO NEXT TEST
3873
3874 015660 023737 004204 004144 2$: CMP E.MR1,T.MR1 ;CHECK IF MAINT REG. 1 CORRECT
3875 015666 001405 BEQ 3$ ;YES, CHECK MESSAGES A&B
3876 015670 104043 ERROR 43 ;MAINT REG. 1 INCORRECT
3877 015672 012762 100000 000000 MOV #CCLR,RKCS1(R2) ;CLEAR RK611 CONTROLLER FOR NEXT TEST
3878 015700 000431 BR TST30 ;GO ON TO NEXT TEST
3879
3880 015702 032737 002000 004146 3$: BIT #S.UNLD,T.MR2 ;CHECK IF UNLOAD COMMAND
3881 015702 BIT ; BIT SET
3882

```

J06

CZR6BCD RK611 DSKLS CTRL PRT2  
CZR6BC.P11 02-DEC-77 09:22

MACY11 30(1046)  
T27

02-DEC-77 09:31 PAGE 74  
MESSAGE SELECT BIT CLEARING FOR CLASS A (PART 3)

SEQ 0074

```

3883 015710 001002      BNE      4$      ;YES, CHECK MESSAGE SELECT BITS
3884 015712 104044      ERROR    44      ;S.UMLD BIT NOT SET
3885 015714 000423      BR       TST30   ;GO ON TO NEXT TEST
3886
3887 015716                4$:
3888 015716 013737 004150 001160      MOV      T.MR3,$TMO ;MASK OUT BITS NOT UNDER TEST
3889 015724 042737 177760 001160      BIC      #177760,$TMO
3890 015732 001402                BEQ      5$      ;CHECK IF MESSAGE SELECT ZERO
3891 015734 104045      ERROR    45      ;MESSAGE SELECT BITS NOT ZERO
3892 015736 000412      BR       TST30   ;GO ON TO NEXT TEST
3893
3894 015740 023737 004206 004146 5$:      CMP      E.MR2,T.MR2 ;CHECK IF MESSAGE A CORRECT
3895 015746 001401                BEQ      6$      ;YES, CHECK MESSAGE B
3896 015750 104046      ERROR    46      ;MESSAGE A INCORRECT
3897 015752 023737 004210 004150 6$:      CMP      E.MR3,T.MR3 ;CHECK IF MESSAGE B CORRECT
3898 015760 001401                BEQ      TST30   ;YES, GO ON TO NEXT TEST
3899 015762 104047      ERROR    47      ;MESS B INCORRECT
3900
3901
3902
3903
3904
3905
3906
3907
3908
3909
3910
3911 015764 000004      TST30:  SCOPE
3912 015766 012737 000144 001200      MOV      #100,$TIMES ;DO 100. ITERATIONS
3913 015774 013702 001270                MOV      $BASE,R2   ;LOAD RK611 BASE
3914 016000 012737 000017 004246      MOV      #17,$MSGCOD ;LOAD MESSAGE CODE FOR PRINT OUT
3915 016006 012737 000011 004160      MOV      #SRTSPL,E.CS1 ;LOAD EXPECTED CS1
3916 016014 012762 100000 000000      MOV      #CCLR,RKCS1(R2) ;CLEAR RK611
3917 016022 012762 000057 000026      MOV      #DMD!17,RKMR1(R2) ;PUT RK611 IN MAINTENANCE MODE
3918
3919 016030 012762 000011 000000      MOV      #SRTSPL,RKCS1(R2) ;SELECT MESSAGE 17
3920 016036 012700 000016 000000      MOV      #3*4+2,R0   ;ISSUE SRTSPL
3921 016042 052762 000400 000026 1$:      BIS      #MCLK,RKMR1(R2) ;CLOCK IN DRIVE MESSAGE
3922 016050 042762 000400 000026      BIC      #MCLK,RKMR1(R2)
3923 016056 005300      DEC      R0
3924 016060 001370      BNE      1$
3925 016062 016237 000000 004120      MOV      RKCS1(R2),T.CS1 ;STORE COMMAND AND STATUS REG. 1
3926 016070 016237 000026 004144      MOV      RKMR1(R2),T.MR1 ;STORE MAINTENANCE REG. 1
3927 016076 016237 000034 004146      MOV      RKMR2(R2),T.MR2 ;STORE MAINTENANCE REG.2
3928 016104 016237 000036 004150      MOV      RKMR3(R2),T.MR3 ;STORE MAINTENANCE REG. 3
3929 016112 012737 002040 004204      MOV      #MEWD!DMD,E.MR1 ;LOAD EXPECTED MAINT REG. 1
3930 016120 032737 020000 004144      BIT      #ECCW,T.MR1
3931 016126 001403      BEQ      10$
3932 016130 052737 020000 004204      BIS      #ECCW,E.MR1
3933 016136 012737 000100 004206 10$:      MOV      #S.STSP,E.MR2 ;LOAD EXPECTED MAINT REG. 2
3934 016144 005037 004210                CLR      E.MR3      ;LOAD EXPECTED MAINT REG. 3
3935 016150 023737 004160 004120      CMP      E.CS1,T.CS1 ;CHECK IF CS1 CORRECT
3936 016156 001405      BEQ      2$      ;YES, CHECK MAINT REG. 1
3937 016160 104042      ERROR    42
3938 016162 012762 100000 000000      MOV      #CCLR,RKCS1(R2) ;CLEAR RK611 CONTROLLER FOR NEXT TEST

```

```

*****
*TEST 30      MESSAGE SELECT BIT CLEARING FOR CLASS A (PART 4)
*
*      CLEAR RK611 WITH CONTROLLER CLEAR.  PUT CONTROLLER IN
*      DIAGNOSTIC MODE WITH MESSAGE SELECT BITS = 17.  LOAD
*      COMMAND AND STATUS REGISTER 1 WITH A START SPINDLE.
*      CLOCK MESSAGE TO LOAD B SHIFT REG.  TIME.  MAKE SURE
*      MESSAGE SELECT BITS ARE CLEARED.
*****

```

```

3939 016170 000442 BR TST31 ;;GO ON TO NEXT TEST
3940
3941 016172 023737 004204 004144 2$: CMP E.MR1,T.MR1 ;CHECK IF MAINT REG. 1 CORRECT
3942 016200 001405 BEQ 3$ ;YES, CHECK MESSAGES A&B
3943 016202 104043 ERROR 43 ;MAINT REG. 1 INCORRECT
3944 016204 012762 100000 000000 MOV #CCLR,RKCS1(R2) ;CLEAR RK611 CONTROLLER FOR NEXT TEST
3945 016212 000431 BR TST31 ;;GO ON TO NEXT TEST
3946
3947 016214 3$: BIT #S.STSP,T.MR2 ;CHECK IF SRTSPL COMMAND
3948 016214 032737 000100 004146 ; BIT SET
3949
3950 016222 001002 BNE 4$ ;YES, CHECK MESSAGE SELECT BITS
3951 016224 104044 ERROR 44 ;S.STSP BIT NOT SET
3952 016226 000423 BR TST31 ;;GO ON TO NEXT TEST
3953
3954 016230 4$: MOV T.MR3,$TMP0 ;MASK OUT BITS NOT UNDER TEST
3955 016230 013737 004150 001160 BIC #177760,$TMP0
3956 016236 042737 177760 001160 BEQ 5$ ;CHECK IF MESSAGE SELECT ZERO
3957 016244 001402 ERROR 45 ;MESSAGE SELECT BITS NOT ZERO
3958 016246 104045 BR TST31 ;;GO ON TO NEXT TEST
3959 016250 000412
3960
3961 016252 023737 004206 004146 5$: CMP E.MR2,T.MR2 ;CHECK IF MESSAGE A CORRECT
3962 016260 001401 BEQ 6$ ;YES, CHECK MESSAGE B
3963 016262 104046 ERROR 46 ;MESSAGE A INCORRECT
3964 016264 023737 004210 004150 6$: CMP E.MR3,T.MR3 ;CHECK IF MESSAGE B CORRECT
3965 016272 001401 BEQ TST31 ;YES, GO ON TO NEXT TEST
3966 016274 104047 ERROR 47 ;MESS B INCORRECT
3967

```

```

*****
*TEST 31 MESSAGE SELECT BIT CLEARING FOR CLASS A (PART 5)
*
* CLEAR RK611 WITH CONTROLLER CLEAR. PUT CONTROLLER IN
* DIAGNOSTIC MODE WITH MESSAGE SELECT BITS = 17. LOAD
* COMMAND AND STATUS REGISTER 1 WITH A RECALIBRATE.
* CLOCK MESSAGE TO LOAD B SHIFT REG. TIME. MAKE SURE
* MESSAGE SELECT BITS ARE CLEARED.
*****

```

```

3977 *****
3978 016276 000004 TST31: SCOPE
3979 016300 012737 000144 001200 MOV #100,$TIMES ;;DO 100. ITERATIONS
3980 016306 013702 001270 001200 MOV $BASE,R2 ;LOAD RK611 BASE
3981 016312 012737 000017 004246 MOV #17,MSGCOD ;LOAD MESSAGE CODE FOR PRINT OUT
3982 016320 012737 000013 004160 MOV #RECAL,E.CS1 ;LOAD EXPECTED CS1
3983 016326 012762 100000 000000 MOV #CCLR,RKCS1(R2) ;CLEAR RK611
3984 016334 012762 000057 000026 MOV #DMD!17,RKMR1(R2) ;PUT RK611 IN MAINTENANCE MODE
3985 ; SELECT MESSAGE 17
3986 016342 012762 000013 000000 MOV #RECAL,RKCS1(R2) ;ISSUE RECAL
3987 016350 012700 000016 000026 1$: MOV #3*4+2,R0 ;CLOCK IN DRIVE MESSAGE
3988 016354 052762 000400 000026 BIS #MCLK,RKMR1(R2)
3989 016362 042762 000400 000026 BIC #MCLK,RKMR1(R2)
3990 016370 005300 DEC R0
3991 016372 001370 BNE 1$
3992 016374 016237 000000 004120 MOV RKCS1(R2),T.CS1 ;STORE COMMAND AND STATUS REG. 1
3993 016402 016237 000026 004144 MOV RKMR1(R2),T.MR1 ;STORE MAINTENANCE REG. 1
3994 016410 016237 000034 004146 MOV RKMR2(R2),T.MR2 ;STORE MAINTENANCE REG.2

```

L06

CZR6BC0 RK611 DSKLS CTRL PRT2  
CZR6BC.P11 02-DEC-77 09:22

MACY11 30(1046)  
T31

02-DEC-77 09:31 PAGE 76  
MESSAGE SELECT BIT CLEARING FOR CLASS A (PART 5)

SEQ 0076

```

3995 016416 016237 000036 004150      MOV      RKMR3(R2),T.MR3 ;STORE MAINTENANCE REG. 3
3996 016424 012737 002040 004204      MOV      #MEWD!DMD,E.MR1 ;LOAD EXPECTED MAINT REG. 1
3997 016432 032737 020000 004144      BIT      #ECCW,T.MR1
3998 016440 001403 000000 000000      BEQ      10$
3999 016442 052737 020000 004204      BIS      #ECCW,E.MR1
4000 016450 012737 000040 004206 10$:      MOV      #S.RECL,E.MR2 ;LOAD EXPECTED MAINT REG. 2
4001 016456 005037 004210 000000      CLR      E.MR3 ;LOAD EXPECTED MAINT REG. 3
4002 016462 023737 004160 004120      CMP      E.CS1,T.CS1 ;CHECK IF CSI CORRECT
4003 016470 001405 000000 000000      BEQ      2$ ;YES, CHECK MAINT REG. 1
4004 016472 104042 000000 000000      ERROR   42
4005 016474 012762 100000 000000      MOV      #CCLR,RKCS1(R2) ;CLEAR RK611 CONTROLLER FOR NEXT TEST
4006 016502 000442 000000 000000      BR       TST32 ;GO ON TO NEXT TEST
4007
4008 016504 023737 004204 004144 2$:      CMP      E.MR1,T.MR1 ;CHECK IF MAINT REG. 1 CORRECT
4009 016512 001405 000000 000000      BEQ      3$ ;YES, CHECK MESSAGES A&B
4010 016514 104043 000000 000000      ERROR   43 ;MAINT REG. 1 INCORRECT
4011 016516 012762 100000 000000      MOV      #CCLR,RKCS1(R2) ;CLEAR RK611 CONTROLLER FOR NEXT TEST
4012 016524 000431 000000 000000      BR       TST32 ;GO ON TO NEXT TEST
4013
4014 016526 023737 000040 004146 3$:      BIT      #S.RECL,T.MR2 ;CHECK IF RECAL COMMAND
4015 016526 032737 000040 004146      BIT      BIT SET
4016
4017 016534 001002 000000 000000      BNE     4$ ;YES, CHECK MESSAGE SELECT BITS
4018 016536 104044 000000 000000      ERROR   44 ;S.RECL BIT NOT SET
4019 016540 000423 000000 000000      BR       TST32 ;GO ON TO NEXT TEST
4020
4021 016542 013737 004150 001160 4$:      MOV      T.MR3,$TMP0 ;MASK OUT BITS NOT UNDER TEST
4022 016542 042737 177760 001160      BIC     #177760,$TMP0
4023
4024 016556 001402 000000 000000      BEQ     5$ ;CHECK IF MESSAGE SELECT ZERO
4025 016560 104045 000000 000000      ERROR   45 ;MESSAGE SELECT BITS NOT ZERO
4026 016562 000412 000000 000000      BR       TST32 ;GO ON TO NEXT TEST
4027
4028 016564 023737 004206 004146 5$:      CMP      E.MR2,T.MR2 ;CHECK IF MESSAGE A CORRECT
4029 016572 001401 000000 000000      BEQ     6$ ;YES, CHECK MESSAGE B
4030 016574 104046 000000 000000      ERROR   46 ;MESSAGE A INCORRECT
4031 016576 023737 004210 004150 6$:      CMP      E.MR3,T.MR3 ;CHECK IF MESSAGE B CORRECT
4032 016604 001401 000000 000000      BEQ     TST32 ;YES, GO ON TO NEXT TEST
4033 016606 104047 000000 000000      ERROR   47 ;MESS B INCORRECT
4034
4035
4036 *****
4037 *TEST 32 MESSAGE SELECT BIT CLEARING FOR CLASS A (PART 6)
4038 *
4039 * CLEAR RK611 WITH CONTROLLER CLEAR. PUT CONTROLLER IN
4040 * DIAGNOSTIC MODE WITH MESSAGE SELECT BITS = 17. LOAD
4041 * COMMAND AND STATUS REGISTER 1 WITH A OFFSET.
4042 * CLOCK MESSAGE TO LOAD B SHIFT REG. TIME. MAKE SURE
4043 * MESSAGE SELECT BITS ARE CLEARED.
4044 *****
4045 TST32. SCOPE
4046 MOV #100,$TIMES ;DO 100. ITERATIONS
4047 MOV $BASE,R2 ;LOAD RK611 BASE
4048 MOV #17,MSGCOD ;LOAD MESSAGE CODE FOR PRINT OUT
4049 MOV #OFFSET,E.CS1 ;LOAD EXPECTED CS1
4050 MOV #CCLR,RKCS1(R2) ;CLEAR RK611

```

M06

CZR6BCO RK611 DSKLS CTRL PRT2  
CZR6BC.P11 02-DEC-77 09:22

MACY11 30(1046)  
T32

02-DEC-77 09:31 PAGE 77  
MESSAGE SELECT BIT CLEARING FOR CLASS A (PART 6)

SEQ 0077

```

4051 016646 012762 000057 000026      MOV      #DMD!17,RKMR1(R2) ;PUT RK611 IN MAINTENANCE MODE
4052                                     ;      SELECT MESSAGE 17
4053 016654 012762 000015 000000      MOV      #OFFSET,RKCS1(R2) ;      ISSUE OFFSET
4054 016662 012700 000016 000000      MOV      #3*4+2,R0 ;CLOCK IN DRIVE MESSAGE
4055 016666 052762 000400 000026 1$:    BIS      #MCLK,RKMR1(R2)
4056 016674 042762 000400 000026      BIC      #MCLK,RKMR1(R2)
4057 016702 005300      DEC      R0
4058 016704 001370      BNE      1$
4059 016706 016237 000000 004120      MOV      RKCS1(R2),T.CS1 ;STORE COMMAND AND STATUS REG. 1
4060 016714 016237 000026 004144      MOV      RKMR1(R2),T.MR1 ;STORE MAINTENANCE REG. 1
4061 016722 016237 000034 004146      MOV      RKMR2(R2),T.MR2 ;STORE MAINTENANCE REG.2
4062 016730 016237 000036 004150      MOV      RKMR3(R2),T.MR3 ;STORE MAINTENANCE REG. 3
4063 016736 012737 002040 004204      MOV      #MEWD!DMD,E.MR1 ;LOAD EXPECTED MAINT REG. 1
4064 016744 032737 020000 004144      BIT      #ECCW,T.MR1
4065 016752 001403      BEQ      10$
4066 016754 052737 020000 004204      BIS      #ECCW,E.MR1
4067 016762 005037 004206 004210 10$:    CLR      E.MR2 ;LOAD EXPECTED MAINT REG 2
4068 016766 012737 017760 004210      MOV      #17760,E.MR3 ;LOAD EXPECTED MAINT REG 3
4069 016774 023737 004160 004120      CMP      E.CS1,T.CS1 ;CHECK IF CS1 CORRECT
4070 017002 001405      BEQ      2$ ;YES, CHECK MAINT REG. 1
4071 017004 104042      ERROR   42
4072 017006 012762 100000 000000      MOV      #CCLR,RKCS1(R2) ;CLEAR RK611 CONTROLLER FOR NEXT TEST
4073 017014 000434      BR      TST33 ;GO ON TO NEXT TEST
4074
4075 017016 023737 004204 004144 2$:    CMP      E.MR1,T.MR1 ;CHECK IF MAINT REG. 1 CORRECT
4076 017024 001405      BEQ      3$ ;YES, CHECK MESSAGES A&B
4077 017026 104043      ERROR   43 ;MAINT REG. 1 INCORRECT
4078 017030 012762 100000 000000      MOV      #CCLR,RKCS1(R2) ;CLEAR RK611 CONTROLLER FOR NEXT TEST
4079 017036 000423      BR      TST33 ;GO ON TO NEXT TEST
4080
4081 017040      3$:
4082 017040 013737 004150 001160      MOV      T.MR3,$TMPD ;MASK OUT BITS NOT UNDER TEST
4083 017046 042737 177760 001160      BIC      #177760,$TMPD
4084 017054 001402      BEQ      5$ ;CHECK IF MESSAGE SELECT ZERO
4085 017056 104045      ERROR   45 ;MESSAGE SELECT BITS NOT ZERO
4086 017060 000412      BR      TST33 ;GO ON TO NEXT TEST
4087
4088 017062 023737 004206 004146 5$:    CMP      E.MR2,T.MR2 ;CHECK IF MESSAGE A CORRECT
4089 017070 001401      BEQ      6$ ;YES, CHECK MESSAGE B
4090 017072 104046      ERROR   46 ;MESSAGE A INCORRECT
4091 017074 023737 004210 004150 6$:    CMP      E.MR3,T.MR3 ;CHECK IF MESSAGE B CORRECT
4092 017102 001401      BEQ      TST33 ;YES, GO ON TO NEXT TEST
4093 017104 104047      ERROR   47 ;MESS B INCORRECT
4094
4095 *****
4096 *TEST 33 MESSAGE SELECT BIT CLEARING FOR CLASS A (PART 7)
4097 *
4098 * CLEAR RK611 WITH CONTROLLER CLEAR. PUT CONTROLLER IN
4099 * DIAGNOSTIC MODE WITH MESSAGE SELECT BITS = 17. LOAD
4100 * COMMAND AND STATUS REGISTER 1 WITH A SEEK.
4101 * CLOCK MESSAGE TO LOAD B SHIFT REG. TIME. MAKE SURE
4102 * MESSAGE SELECT BITS ARE CLEARED.
4103 *
4104 *****
4105 TST33: SCOPE
4106 017106 000004      MOV      #100,$TIMES ;;DO 100. ITERATIONS

```

N06

CZR6BCO RK611 DSKLS CTRL PRT2  
CZR6BC.P11 02-DEC-77 09:22

MACY11 30(1046)  
T33

02-DEC-77 09:31 PAGE 78  
MESSAGE SELECT BIT CLEARING FOR CLASS A (PART 7)

SEQ 0078

4107	017116	013702	001270			MOV	\$BASE,R2	;LOAD RK611 BASE
4108	017122	012737	000017	004246		MOV	#17,MSGCOD	;LOAD MESSAGE CODE FOR PRINT OUT
4109	017130	012737	000017	004160		MOV	#SEEK,E.CS1	;LOAD EXPECTED CS1
4110	017136	012762	100000	000000		MOV	#CCLR,RKCS1(R2)	;CLEAR RK611
4111	017144	012762	000057	000026		MOV	#DMD!17,RKMR1(R2)	;PUT RK611 IN MAINTENANCE MODE
4112								;SELECT MESSAGE 17
4113	017152	012762	000017	000000		MOV	#SEEK,RKCS1(R2)	;ISSUE SEEK
4114	017160	012700	000016			MOV	#3*4+2,RO	;CLOCK IN DRIVE MESSAGE
4115	017164	052762	000400	000026	1\$:	BIS	#MCLK,RKMR1(R2)	
4116	017172	042762	000400	000026		BIC	#MCLK,RKMR1(R2)	
4117	017200	005300				DEC	RO	
4118	017202	001370				BNE	1\$	
4119	017204	016237	000000	004120		MOV	RKCS1(R2),T.CS1	;STORE COMMAND AND STATUS REG. 1
4120	017212	016237	000026	004144		MOV	RKMR1(R2),T.MR1	;STORE MAINTENANCE REG. 1
4121	017220	016237	000034	004146		MOV	RKMR2(R2),T.MR2	;STORE MAINTENANCE REG.2
4122	017226	016237	000036	004150		MOV	RKMR3(R2),T.MR3	;STORE MAINTENANCE REG. 3
4123	017234	012737	002040	004204		MOV	#MEWD!DMD,E.MR1	;LOAD EXPECTED MAINT REG. 1
4124	017242	032737	020000	004144		BIT	#ECCW,T.MR1	
4125	017250	001403				BEQ	10\$	
4126	017252	052737	020000	004204		BIS	#ECCW,E.MR1	
4127	017260	012737	000020	004206	10\$:	MOV	#S.SEEK,E.MR2	;LOAD EXPECTED MAINT REG. 2
4128	017266	005037	004210			CLR	E.MR3	;LOAD EXPECTED MAINT REG. 3
4129	017272	022737	004160	004120		CMP	E.CS1,T.CS1	;CHECK IF CS1 CORRECT
4130	017300	001405				BEQ	2\$	;YES, CHECK MAINT REG. 1
4131	017302	104042				ERROR	42	
4132	017304	012762	100000	000000		MOV	#CCLR,RKCS1(R2)	;CLEAR RK611 CONTROLLER FOR NEXT TEST
4133	017312	000442				BR	TST34	;GO ON TO NEXT TEST
4134								
4135	017314	023737	004204	004144	2\$:	CMP	E.MR1,T.MR1	;CHECK IF MAINT REG. 1 CORRECT
4136	017322	001405				BEQ	3\$	;YES, CHECK MESSAGES A&B
4137	017324	104043				ERROR	43	;MAINT REG. 1 INCORRECT
4138	017326	012762	100000	000000		MOV	#CCLR,RKCS1(R2)	;CLEAR RK611 CONTROLLER FOR NEXT TEST
4139	017334	000442				BR	TST34	;GO ON TO NEXT TEST
4140								
4141	017336				3\$:			
4142	017336	032737	000020	004146		BIT	#S.SEEK,T.MR	;CHECK IF SEEK COMMAND
4143								;BIT SET
4144	017344	001002				BNE	4\$	;YES, CHECK MESSAGE SELECT BITS
4145	017346	104044				ERROR	44	;S.SEEK BIT NOT SET
4146	017350	000423				BR	TST34	;GO ON TO NEXT TEST
4147								
4148	017352				4\$:			
4149	017352	013737	004150	001160		MOV	T.MR3,\$TMPD	;MASK OUT BITS NOT UNDER TEST
4150	017360	042737	177760	001160		BIC	#177760,\$TMPD	
4151	017366	001402				BEQ	5\$	;CHECK IF MESSAGE SELECT ZERO
4152	017370	104045				ERROR	45	;MESSAGE SELECT BITS NOT ZERO
4153	017372	000412				BR	TST34	;GO ON TO NEXT TEST
4154								
4155	017374	023737	004206	004146	5\$:	CMP	E.MR2,T.MR2	;CHECK IF MESSAGE A CORRECT
4156	017402	001401				BEQ	6\$	;YES, CHECK MESSAGE B
4157	017404	104046				ERROR	46	;MESSAGE A INCORRECT
4158	017406	023737	004210	004150	6\$:	CMP	E.MR3,T.MR3	;CHECK IF MESSAGE B CORRECT
4159	017414	001401				BEQ	TST34	;YES, GO ON TO NEXT TEST
4160	017416	104047				ERROR	47	;MESS B INCORRECT
4161								
4162								

.SBTTL \*\*DRIVE MESSAGE LOOPBACK AND PARITY GENERATION TESTS

```

*****
*TEST 34 DRIVE MESSAGE LOOPBACK
*****
*
* CLEAR THE RK611 WITH A CONTROLLER CLEAR. PUT CONTROLLER
* IN DIAGNOSTIC MODE INDICATING MESSAGE 3. LOAD COMMAND
* STATUS REGISTER FOR DRIVE 5. LOAD COMMAND AND STATUS
* REGISTER 1 WITH A SELECT COMMAND. CLOCK 4 BITS
* THROUGH THE DRIVE MESSAGE LOOPBACK. VERIFY THAT BITS
* ARE INDEED LOOPED BACK.
*****

```

```

4163
4164
4165
4166
4167
4168
4169
4170
4171
4172
4173
4174
4175
4176 017420 000004
4177 017422 012737 000144 001200
4178 017430 013702 001270
4179 017434 012762 100000 000000
4180 017442 005037 004256
4181 017446 012737 000005 004206
4182 017454 012737 000005 004230
4183 017462 012737 000003 004210
4184 017470 012737 000003 004232
4185 017476 012762 000043 000026
4186
4187 017504 012762 000005 000010
4188 017512 012762 000001 000000
4189 017520 012700 000016
4190 017524 052762 000400 000026 1$:
4191 017532 042762 000400 000026
4192 017540 005300
4193 017542 001370
4194 017544 016237 000034 004146
4195 017552 016237 000036 004150
4196 017560 023737 004206 004146
4197 017566 001402
4198 017570 104050
4199 017572 000431
4200
4201 017574 023737 004210 004150 2$:
4202 017602 001402
4203 017604 104051
4204 017606 000423
4205
4206 017610 032737 000001 004210 3$:
4207 017616 001402
4208 017620 000261
4209 017622 000401
4210
4211
4212 017624 000241 4$:
4213 017626 006037 004206 5$:
4214 017632 006037 004210
4215 017636 012700 000004
4216 017642 005237 004256
4217 017646 022737 000004 004256
4218 017654 103323

```

```

*****
*ST34: SCOPE
MOV #100, $TIMES ;DO 100. ITERATIONS
MOV $BASE, R2 ;LOAD RK611 BASE
MOV #CLR, RKCS1(R2) ;CLEAR RK611
CLR SFTCNT ;INITIALIZE SHIFT COUNT
MOV #5, E.MR2 ;LOAD EXPECTED SHIFT REG. A
MOV #5, U.MR2 ;LOAD UNSHIFTED SHIFT REG. A
MOV #3, E.MR3 ;LOAD EXPECTED SHIFT REG. B
MOV #3, U.MR3 ;LOAD UNSHIFTED SHIFT REG. B
MOV #DMD!3, RKMR1(R2) ;PUT RK611 IN MAINT. MODE
; MESSAGE SELECT = 3
MOV #5, RKCS2(R2) ;LOAD DRIVE NUMBER = 5
MOV #SELDRV, RKCS1(R2) ;ISSUE SELECT DRIVE
MOV #3*4+2, R0 ;CLOCK IN MESSAGE
BIS #MCLK, RKMR1(R2) ;ISSUE CLOCKS
BIC #MCLK, RKMR1(R2)
DEC R0
BNE 1$
MOV RKMR2(R2), T.MR2 ;STORE SHIFT REG. A
MOV RKMR3(R2), T.MR3 ;STORE SHIFT REG. B
CMP E.MR2, T.MR2 ;CHECK SHIFT REG A CORRECT
BEQ 2$ ;YES, CHECK SHIFT REG. B
ERROR 50 ;SHIFT REG A INCORRECT
BR TST35 ;GO ON TO NEXT TEST
;CHECK SHIFT REG B CORRECT
CMP E.MR3, T.MR3
BEQ 3$ ;YES, SHIFT A BIT
ERROR 51 ;SHIFT REG B INCORRECT
BR TST35 ;GO ON TO NEXT TEST
;CHECK IF SHIFT BIT = 1
BIT #BIT0, E.MR3
BEQ 4$ ;NO, CLEAR SHIFT BIT
SEC ;SET SHIFT BIT
BR 5$ ;GENERATE EXPECTED SHIFT
; REGISTERS A & B
;CLEAR SHIFT BIT
CLC
ROR E.MR2 ;GENERATE EXPECTED SHIFT REG A
ROR E.MR3 ;GENERATE EXPECTED SHIFT REG B
MOV #4, R0 ;LOAD COUNT FOR 1 BIT SHIFT
INC SFTCNT ;INCREMENT SHIFT BIT COUNT
CMP #4, SFTCNT ;CHECK IF FINISHED
BHS 1$ ;NO, SHIFT IN NEXT BIT

```



4219  
4220  
4221  
4222  
4223  
4224  
4225  
4226  
4227  
4228  
4229  
4230  
4231  
4232  
4233  
4234  
4235  
4236  
4237  
4238  
4239  
4240  
4241  
4242  
4243  
4244  
4245  
4246  
4247  
4248  
4249  
4250  
4251  
4252  
4253  
4254  
4255  
4256  
4257  
4258  
4259  
4260  
4261  
4262  
4263  
4264  
4265  
4266  
4267  
4268  
4269  
4270  
4271  
4272  
4273  
4274

```
*****
*TEST 35 DRIVE MESSAGE SHIFT
*
* CLEAR THE RK611 WITH A CONTROLLER CLEAR. PUT CONTROLLER
* IN DIAGNOSTIC MODE. LOAD CYLINDER ADDRESS WITH 441.
* LOAD HEAD ADDRESS WITH 1. LOAD COMMAND AND STATUS
* REGISTER 1 WITH A SEEK IN 24 SECTOR MODE. CLOCK 8 BITS
* THROUGH THE DRIVE MESSAGE LOOPBACK. VERIFY THAT BITS ARE
* SHIFTED PROPERLY.
*****
```

```
TST35: SCOPE
MOV #100, $TIMES ;DO 100 ITERATIONS
MOV $BASE, R2 ;LOAD RK611 BASE
MOV #CCLR, RKCS1(R2) ;CLEAR RK611
CLR SFTCNT ;INITIALIZE SHIFT COUNT
MOV #S.FMT!S.SEEK!BIT12, E.MR2 ;LOAD EXPECTED SHIFT REG. A
MOV #S.FMT!S.SEEK!BIT12, U.MR2 ;LOAD UNSHIFTED SHIFT REG. A
MOV #11020, E.MR3 ;LOAD EXPECTED SHIFT REG. B
MOV #11020, U.MR3 ;LOAD UNSHIFTED SHIFT REG. B
MOV #DMD, RKMR1(R2) ;PUT RK611 IN MAINT. MODE
MOV #441, RKDCYL(R2) ;LOAD CYLINDER ADD. REG.
MOV #400, RKDA(R2) ;LOAD DISK ADDRESS REG.
MOV #SEEK!CFMT, RKCS1(R2) ;ISSUE SEEK

MOV #3*4+2, R0 ;CLOCK IN MESSAGE
BIS #MCLK, RKMR1(R2) ;ISSUE CLOCKS
BIC #MCLK, RKMR1(R2)
DEC R0
BNE 1$
MOV RKMR2(R2), T.MR2 ;STORE SHIFT REG. A
MOV RKMR3(R2), T.MR3 ;STORE SHIFT REG. B
CM? E.MR2, T.MR2 ;CHECK SHIFT REG. A CORRECT
BEQ 2$ ;YES CHECK SHIFT REG. B
ERROR 50 ;SHIFT REG A INCORRECT
BR TST36 ;GO ON TO NEXT TEST

CMP E.MR3, T.MR3 ;CHECK SHIFT REG B CORRECT
BEQ 3$ ;YES SHIFT A BIT
ERROR 51 ;SHIFT REG B INCORRECT
BR TST36 ;GO ON TO NEXT TEST

BIT #BIT0, E.MR3 ;CHECK IF SHIFT BIT = 1
BEQ 4$ ;NO CLEAR SHIFT BIT
SEC ;SET SHIFT BIT
BR 5$ ;GENERATE EXPECTED SHIFT
; REGISTERS A & B

4$: CLC ;CLEAR SHIFT BIT
5$: ROR E.MR2 ;GENERATE EXPECTED SHIFT REG A
ROR E.MR3 ;GENERATE EXPECTED SHIFT REG B
MOV #4, R0 ;LOAD COUNT FOR 1 BIT SHIFT
INC SFTCNT ;INCREMENT SHIFT BIT COUNT
CMP #8, SFTCNT ;CHECK IF FINISHED
BHS 1$ ;NO, SHIFT IN NEXT BIT
```

4275  
4276  
4277  
4278  
4279  
4280  
4281  
4282  
4283  
4284  
4285  
4286  
4287  
4288  
4289  
4290  
4291  
4292  
4293  
4294  
4295  
4296  
4297  
4298  
4299  
4300  
4301  
4302  
4303  
4304  
4305  
4306  
4307  
4308  
4309  
4310  
4311  
4312  
4313  
4314  
4315  
4316  
4317  
4318  
4319  
4320  
4321  
4322  
4323  
4324  
4325  
4326  
4327  
4328  
4329  
4330

020122 000004  
020124 012737 000144 001200  
020132 013702 001270  
020136 012762 100000 000000  
020144 012762 000040 000026  
020152 012762 000001 000000  
020160 012700 000116  
020164 012762 000440 000026  
020172 012762 000040 000026  
020200 005300  
020202 00170  
020204 016237 000034 004146  
020212 016237 000036 004150  
020220 012737 100000 004206  
020226 012737 100000 004210  
020234 032737 100000 004150  
  
020242 001002  
020244 104052  
020246 000420  
  
020250 032737 100000 004146  
020256 001002  
020260 104053  
020262 000412  
  
020264 023737 004210 004150  
020272 001401  
020274 104054  
020276 023737 004206 004146  
020304 001401  
020306 104055  
020310 012762 100000 000000  
020316 012762 000060 000026  
  
020324 012762 000001 000000  
020332 012700 000116  
020336 012762 000460 000026  
020344 012762 000060 000026  
020352 005300  
  
020354 001370  
020356 016237 000034 004146  
020364 016237 000036 004150  
020372 005037 004206

```
*****  
*TEST 36 DRIVE MESSAGE PARITY PRECONDITIONING  
*  
* CLEAR RK611 WITH CONTROLLER CLEAR. PUT CONTROLLER  
* IN DIAGNOSTIC MODE. LOAD COMMAND AND STATUS REGISTER 1 WITH  
* A SELECT COMMAND. CLOCK ALL 16 BITS THROUGH THE  
* DRIVE MESSAGE LOOPBACK. VERIFY PARITY HAS BEEN PRECONDITIONED  
* PROPERLY. REPEAT FOR BAD PARITY GENERATION.  
*****  
↑ST36: SCOPE  
MOV #100, $TIMES ; DO 100 ITERATIONS  
MOV $BASE, R2 ; LOAD RK611 BASE  
MOV #CCLR, RKCS1(R2) ; CLEAR RK611  
MOV #DMD, RKMR1(R2) ; PUT RK611 IN MAINTENANCE MODE  
MOV #SELDRV, RKCS1(R2) ; ISSUE SELECT DRIVE  
MOV #19.*4+2, R0 ; LOAD DRIVE MESSAGE AND SHIFT  
1$: MOV #DMD!MCLK, RKMR1(R2) ; ALL 16 BITS  
MOV #DMD, RKMR1(R2)  
DEC R0  
BNE 1$  
MOV RKMR2(R2), T.MR2 ; STORE SHIFTED MESSAGE B  
MOV RKMR3(R2), T.MR3 ; STORE SHIFTED MESSAGE A  
MOV #100000, E.MR2 ; LOAD EXPECTED MESSAGE B  
MOV #100000, E.MR3 ; LOAD EXPECTED MESSAGE A  
BIT #BIT15, T.MR3 ; CHECK IF PARITY ON MESSAGE A CORRECT  
BNE 2$ ; YES, CHECK PARITY ON MESSAGE B  
ERROR 52 ; PARITY ON MESSAGE A INCORRECT  
BR 5$ ; TRY EVEN PARITY  
2$: BIT #BIT15, T.MR2 ; CHECK IF PARITY ON MESS B CORRECT  
BNE 3$ ; YES, CHECK MESSAGE A AND B  
ERROR 53 ; PARITY ON MESSAGE B INCORRECT  
BR 5$ ; TRY EVEN PARITY  
3$: CMP E.MR3, T.MR3 ; CHECK IF MESSAGE A CORRECT  
BEQ 4$ ; YES, CHECK MESSAGE B  
ERROR 54 ; MESSAGE A INCORRECT  
4$: CMP E.MR2, T.MR2 ; CHECK IF MESSAGE B CORRECT  
BEQ 5$ ; YES, TRY EVEN PARITY  
ERROR 55 ; MESSAGE B INCORRECT  
5$: MOV #CCLR, RKCS1(R2) ; CLEAR RK611  
MOV #DMD!PAT, RKMR1(R2) ; PUT RK611 MAINTENANCE MODE  
; AND EVEN PARITY  
MOV #SELDRV, RKCS1(R2) ; ISSUE SELECT DRIVE  
MOV #19.*4+2, R0 ; LOAD DRIVE MESSAGE AND SHIFT  
6$: MOV #DMD!PAT!MCLK, RKMR1(R2) ; ALL 16 BITS  
MOV #DMD!PAT, RKMR1(R2)  
DEC R0  
BNE 6$  
MOV RKMR2(R2), T.MR2 ; STORE SHIFTED MESSAGE B  
MOV RKMR3(R2), T.MR3 ; STORE SHIFTED MESSAGE A  
CLR E.MR2 ; LOAD EXPECTED MESSAGE B
```

```

4331 020376 005037 004210          CLR      E.MR3          ;LOAD EXPECTED MESSAGE A
4332 020402 032737 100000 004150  BIT      #BIT15,T.MR3  ;CHECK IF PARITY ON MESSAGE A CORRECT
4333 020410 001402          BEQ      7$            ;YES, CHECK PARITY ON MESSAGE B
4334 020412 104056          ERROR   56            ;PARITY ON MESSAGE A INCORRECT
4335 020414 000420          BR       TST37        ;GO ON TO NEXT TEST
4336
4337 020416 032737 100000 004146 7$:  BIT      #BIT15,T.MR2  ;CHECK IF PARITY ON MESS B CORRECT
4338 020424 001402          BEQ      8$            ;YES, CHECK MESSAGE A AND B
4339 020426 104057          ERROR   57            ;PARITY ON MESSAGE B INCORRECT
4340 020430 000412          BR       TST37        ;GO ON TO NEXT TEST
4341
4342 020432 023737 004210 004150 8$:  CMP      E.MR3,T.MR3   ;CHECK IF MESSAGE A CORRECT
4343 020440 001401          BEQ      9$            ;YES, CHECK MESSAGE B
4344 020442 104060          ERROR   60            ;MESSAGE A INCORRECT
4345 020444 023737 004206 004146 9$:  CMP      E.MR2,T.MR2   ;CHECK IF MESSAGE B CORRECT
4346 020452 001401          BEQ      TST37        ;YES, GO ON TO NEXT TEST
4347 020454 104061          ERROR   61            ;MESSAGE B INCORRECT
4348
4349
4350 *****
4351 *TEST 37          ODD DRIVE MESSAGE PARITY GENERATION
4352 *
4353 *          CLEAR RK611 WITH CONTROLLER CLEAR. PUT CONTROLLER
4354 *          IN DIAGNOSTIC MODE AND MESSAGE SELECT = 1.
4355 *          LOAD COMMAND AND STATUS REGISTER 2 WITH DRIVE
4356 *          SELECT = 1. LOAD COMMAND AND STATUS REGISTER 1 WITH
4357 *          A SELECT COMMAND. VERIFY THAT PARITY HAS BEEN
4358 *          GENERATED CORRECTLY. REPEAT FOR MESSAGE SELECT =
4359 *          DRIVE SELECT = 2-17.
4360 *****
4361 020456 000004          TST37: SCOPE
4362 020460 012737 000144 001200  MOV      #100,$TIMES   ;;DO 100. ITERATIONS
4363 020466 013702 001270          MOV      $BASE,R2     ;LOAD RK611 BASE
4364 020472 012737 000001 004244  MOV      #1,DRVCOD    ;LOAD DRIVE CODE
4365 020500 012737 020506 001110  MOV      #1$, $LPERR  ;LOAD LOOP ON ERROR LOCATION FOR
4366 *          SUBTEST LOOP
4367
4368 020506          1$:
4369 020506 012762 100000 000000  MOV      #CCLR,RKCS1(R2) ;CLEAR RK611
4370 020514 013762 004244 000026  MOV      DRVCOD,RKMR1(R2) ;LOAD MESSAGE SELECT CODE
4371 020522 052762 000040 000026  BIS      #DMD,RKMR1(R2) ;PUT RK611 IN MAINTENANCE MODE
4372 020530 013762 004244 000010  MOV      DRVCOD,RKCS2(R2) ;LOAD DRIVE SELECT CODE
4373 020536 012762 000001 000000  MOV      #SELDRV,RKCS1(R2) ;ISSUE SELECT DRIVE
4374 020544 012700 000116          MOV      #19,*4+2,R0  ;LOAD DRIVE MESSAGE AND SHIFT
4375 020550 052762 000400 000026 2$:  BIS      #MCLK,RKMR1(R2) ; ALL 16 BITS
4376 020556 042762 000400 000026  BIC      #MCLK,RKMR1(R2)
4377 020564 005300          DEC      R0
4378 020566 001370          BNE      2$
4379 020570 016237 000034 004146  MOV      RKMR2(R2),T.MR2 ;STORE SHIFTED MESSAGE B
4380 020576 016237 000036 004150  MOV      RKMR3(R2),T.MR3 ;STORE SHIFTED MESSAGE A
4381 020604 013701 004244          MOV      DRVCOD,R1    ;DETERMINE PARITY
4382 020610 012703 000004          MOV      #4,R3
4383 020614 005004          CLR      R4
4384 020616 006001          3$:  ROR      R1
4385 020620 103001          BCC      4$
4386 020622 005204          INC      R4

```

```

4387 020624 005303          4S:  DEC      R3
4388 020626 001373          BNE      3S
4389 020630 013737 004244 004206  MOV     DRVCOD,E.MR2 ;LOAD EXPECTED SHIFTED REG. B
4390 020636 013737 004244 004210  MOV     DRVCOD,E.MR3 ;LOAD EXPECTED SHIFTED REG. A
4391 020644 005037 004260          CLR     PARBIT
4392 020650 032704 000001          BIT     #BIT0,R4 ;CHECK FOR PARITY ON WORD
4393 020654 001011          BNE     5S ;PARITY ALREADY ODD
4394 020656 012737 100000 004260  MOV     #BIT15,PARBIT ;SET PARITY BIT
4395 020664 052737 100000 004206  BIS     #BIT15,E.MR2
4396 020672 052737 100000 004210  BIS     #BIT15,E.MR3
4397 020700 013737 004150 001160 5S:  MOV     T.MR3,$TMP0 ;MASK ALL BITS EXCEPT PARITY
4398 020706 042737 077777 001160  BIC     #77777,$TMP0
4399 020714 023737 004260 001160  CMP     PARBIT,$TMP0 ;CHECK IF PARITY CORRECT
4400 020722 001402          BEQ     6S ;ON MESSAGE A
4401 020724 104052          ERROR   52 ;PARITY ON MESSAGE A INCORRECT
4402 020726 000426          BR      25S ;CHECK IF LOOP ON ERROR
4403
4404 020730 013737 004146 001160 6S:  MOV     T.MR2,$TMP0 ;MASK ALL BITS EXCEPT PARITY
4405 020736 042737 077777 001160  BIC     #77777,$TMP0
4406 020744 023737 004260 001160  CMP     PARBIT,$TMP0 ;CHECK IF PARITY CORRECT
4407 020752 001402          BEQ     7S ;ON MESSAGE B
4408 020754 104053          ERROR   53 ;PARITY ON MESSAGE B INCORRECT
4409 020756 000412          BR      25S ;CHECK IF LOOP ON ERROR
4410
4411 020760 023737 004210 004150 7S:  CMP     E.MR3,T.MR3 ;CHECK IF MESSAGE A CORRECT
4412 020766 001401          BEQ     6S ;YES, CHECK MESSAGE B
4413 020770 104054          ERROR   54 ;MESSAGE A INCORRECT
4414 020772 023737 004206 004146 8S:  CMP     E.MR2,T.MR2 ;CHECK IF MESSAGE B CORRECT
4415 021000 001401          BEQ     25S ;YES, CHECK IF LOOP ON ERROR
4416 021002 104055          ERROR   55 ;MESSAGE B INCORRECT
4417 021004 104415          SCOPE1 ;CHECK IF LOOP ON ERROR
4418 021006 005237 004244          INC     DRVCOD ;INCREMENT DRIVE SELECT CODE
4419 021012 022737 000017 004244  CMP     #17,DRVCOD ;CHECK IF FINISHED
4420 021020 103232          BHIS   1S ;NO, TRY NEXT CONFIGURATION
4421
4422 *****
4423 *TEST 40 DRIVE MESSAGE PARITY INTERACTION
4424 *
4425 * CLEAR THE RK611 WITH A CONTROLLER CLEAR. PUT CONTROLLER
4426 * IN DIAGNOSTIC MODE. LOAD COMMAND AND STATUS REGISTER 2
4427 * WITH DRIVE SELECT = 1. LOAD COMMAND AND STATUS REGISTER 1
4428 * WITH A SELECT COMMAND. VERIFY THAT THE CORRECT PARITY
4429 * IS GENERATED FOR BOTH MESSAGES. REPEAT FOR MESSAGE
4430 * SELECT = 1 AND DRIVE SELECT = 0.
4431 *
4432 *****
4433 †ST40: SCOPE
4434 021022 000004          MOV     #100,$TIMES ;DO 100. ITERATIONS
4435 021024 012737 000144 001200  MOV     $BASE,R2 ;LOAD RK611 BASE
4436 021032 013702 001270          MOV     #1,DRVCOD ;SET INITIAL DRIVE SELECT CODE
4437 021036 012737 000001 004244  MOV     M$GCODE ;SET INITIAL MESSAGE SELECT CODE
4438 021044 005037 004246          CLR     M$GCODE
4439 021050 012737 100000 004206  MOV     #BIT15,E.MR2 ;LOAD EXPECTED MAINT. REG. 2 (MESS B)
4440 021056 012737 000001 004210  MOV     #BIT0,E.MR3 ;LOAD EXPECTED MAINT. REG. 3 (MESS A)
4441 021064 012737 100000 004260  MOV     #BIT15,PARBIT ;LOAD PARITY FOR MESSAGE B
4442 021072 012737 021100 001110  MOV     #1S,$LPERR ;LOAD LOOP ON ERROR LOCATION FOR
; SUBTEST LOOP

```

```

4443
4444 021109
4445 012762 100000 000000 1$: MOV #CLR,RKCS1(R2) ;CLEAR RK611
4446 013762 004246 000026 MOV MSGCOD,RKMR1(R2) ;LOAD MESSAGE SELECT CODE
4447 052762 000040 000026 BIS #0MD,RKMR1(R2) ;PUT RK611 IN MAINTENANCE MODE
4448 013762 004244 000010 MOV DPVCD,RKCS2(R2) ;LOAD DRIVE SELECT CODE
4449 012762 000001 000000 MOV #SELDIV,RKCS1(R2) ;ISSUE DRIVE SELECT
4450 012700 000116 MOV #19.*4+2,RO ;LOAD DRIVE MESSAGE AND SHIFT
4451 021142 052762 000400 2$: BIS #MCLK,RKMR1(R2) ; ALL 16 BITS
4452 021150 042762 000400 BIC #MCLK,RKMR1(R2)
4453 021156 005300 DEC RO
4454 021160 001370 BNE 2$
4455 021162 016237 000034 004146 MOV RKMR2(R2),T.MR2 ;STORE SHIFTED MESSAGE B
4456 021170 016237 000036 004150 MOV RKMR3(R2),T.MR3 ;STORE SHIFTED MESSAGE A
4457 021176 013737 004150 001160 MOV T.MR3,$TMP0 ;MASK ALL BITS EXCEPT PARITY
4458 021204 042737 077777 001160 BIC #77777,$TMP0
4459 021212 023737 004260 001160 CMP PARBIT,$TMP0 ;CHECK IF PARITY BIT CORRECT
4460 021220 001002 BNE 3$ ; ON MESSAGE A
4461 021222 104052 ERROR 52 ;NO PARITY ON MESSAGE INCORRECT
4462 021224 000426 BR 25$ ;CHECK IF LOOP ON ERROR
4463
4464 021226 013737 004146 001160 3$: MOV T.MR2,$TMP0 ;MASK ALL BITS EXCEPT PARITY
4465 021234 042737 077777 001160 BIC #77777,$TMP0
4466 021242 023737 004260 001160 CMP PARBIT,$TMP0 ;CHECK IF PARITY CORRECT
4467 021250 001402 BEQ 4$ ; MESSAGE B
4468 021252 104053 ERROR 53 ;PARITY ON MESSAGE B INCORRECT
4469 021254 000412 BR 25$ ;CHECK IF LOOP ON ERROR
4470
4471 021256 023737 004210 004150 4$: CMP E.MR3,T.MR3 ;CHECK IF MESSAGE A CORRECT
4472 021264 001401 BEQ 5$ ;YES CHECK IN MESSAGE B CORRECT
4473 021266 104054 ERROR 54 ;MESSAGE A INCORRECT
4474 021270 023737 004206 004146 5$: CMP E.MR2,T.MR2 ;CHECK IF MESSAGE B CORRECT
4475 021276 001401 BEQ 25$ ;YES CHECK IF LOOP ON ERROR
4476 021300 104055 ERROR 55 ;MESSAGE B INCORRECT
4477 021302 104415 25$: SCOP1 ;CHECK IF LOOP ON ERROR
4478 021304 005737 004244 TST DRVCOD ;CHECK IF DRIVE SELECT = 0 (FINISHED)
4479 021310 001416 BEQ TST41 ;YES GO ON TO NEXT TEST
4480 021312 005037 004244 CLR DRVCOD ;SET DRIVE SELECT CODE = 0
4481 021316 012737 000001 004246 MOV #1,MSGCOD ;SET MESSAGE SELECT CODE
4482 021324 012737 000001 004206 MOV #BIT0,E.MR2 ;LOAD EXPECTED MAINT REG 2 (MESS B)
4483 021332 012737 100000 004210 MOV #BIT15,E.MR3 ;LOAD EXPECTED MAINT REG 3 (MESS A)
4484 021340 005037 004260 CLR PARBIT ;LOAD PARITY FOR MESSAGE B
4485 021344 000655 BR 1$ ;TRY SECOND CONFIGURATION

```

```

4486
4487 *****
4488 *TEST 41 EVEN DRIVE MESSAGE PARITY GENERATION
4489 *
4490 *
4491 * CLEAR RK611 WITH CONTROLLER CLEAR. PUT CONTROLLER
4492 * IN DIAGNOSTIC MODE AND MESSAGE SELECT = 1
4493 * AND BAD PARITY SET. LOAD COMMAND AND STATUS
4494 * REGISTER 2 WITH DRIVE SELECT = 1. LOAD COMMAND
4495 * AND STATUS REGISTER SELECT COMMAND. VERIFY THAT
4496 * EVEN PARITY IS GENERATED. REPEAT FOR MESSAGE SELECT =
4497 * DRIVE SELECT = 2-17.
4498 *****

```

```

4499 021346 000004          TST41: SCOPE
4500 021350 012737 000144 001200      MOV    #100, $TIMES      ;; DO 100. ITERATIONS
4501 021356 013702 001270          MOV    $BASE, R2        ;; LOAD RK611 BASE
4502 021362 012737 000001 004244      MOV    #1, DRVCOD       ;; LOAD DRIVE CODE
4503 021370 012737 021376 001110      MOV    #1$, $LPERR     ;; LOAD LOOP ON ERROR LOCATION FOR
4504                                     ;; SUBTEST LOOP
4505
4506 021376          1$:
4507 021376 012762 100000 000000      MOV    #CCLR, RKCS1(R2) ; CLEAR RK611
4508 021404 013762 004244 000026      MOV    DRVCOD, RKMR1(R2) ; LOAD MESSAGE SELECT CODE
4509 021412 052762 000060 000026      BIS    #DMO!PAT, RKMR1(R2) ; PUT RK611 IN MAINTENANCE MODE
4510                                     ; AND SET BAD PARITY
4511 021420 013762 004244 000010      MOV    DRVCOD, RKCS2(R2) ; LOAD DRIVE SELECT CODE
4512 021426 012762 000001 000000      MOV    #SELD, RKCS1(R2) ; ISSUE SELECT DRIVE
4513 021434 012700 000116          MOV    #19, *4+2, R0    ;; LOAD DRIVE MESSAGE AND SHIFT
4514 021440 052762 000400 000026      BIS    #MCLK, RKMR1(R2) ; ALL 16 BITS
4515 021446 042762 000400 000026      BIC    #MCLK, RKMR1(R2)
4516 021454 005300          DEC    R0
4517 021456 001370          BNE    2$
4518 021460 016237 000034 004146      MOV    RKMR2(R2), T.MR2 ; STORE SHIFTED MESSAGE B
4519 021466 016237 000036 004150      MOV    RKMR3(R2), T.MR3 ; STORE SHIFTED MESSAGE A
4520 021474 013701 004244          MOV    DRVCOD, R1      ;; DETERMINE PARITY
4521 021500 012703 000004          MOV    #4, R3
4522 021504 005004          CLR    R4
4523 021506 006001          3$: ROR    R1
4524 021510 103001          BCC    4$
4525 021512 005204          INC    R4
4526 021514 005303          4$: DEC    R3
4527 021516 001373          BNE    3$
4528 021520 013737 004244 004206      MOV    DRVCOD, E.MR2   ;; LOAD EXPECTED SHIFTED REG. B
4529 021526 013737 004244 004210      MOV    DRVCOD, E.MR3   ;; LOAD EXPECTED SHIFTED REG. A
4530 021534 005037 004260          CLR    PARBIT
4531 021540 032704 000001          BIT    #BIT0, R4      ;; CHECK FOR PARITY ON WORD
4532 021544 001411          BEQ    5$             ;; PARITY ALREADY EVEN
4533 021546 012737 100000 004260      MOV    #BIT15, PARBIT ; SET PARITY BIT
4534 021554 052737 100000 004206      BIS    #BIT15, E.MR2
4535 021562 052737 100000 004210      BIS    #BIT15, E.MR3
4536 021570 013737 004150 001160      5$: MOV    T.MR3, $TMPO   ;; MASK ALL BITS EXCEPT PARITY
4537 021576 042737 077777 001160      BIC    #77777, $TMPO
4538 021604 023737 004260 001160      CMP    PARBIT, $TMPO  ;; CHECK IF PARITY CORRECT
4539 021612 001402          BEQ    6$             ;; ON MESSAGE A
4540 021614 104056          ERROR 56             ;; PARITY ON MESSAGE A INCORRECT
4541 021616 000426          BR    25$           ;; CHECK IF LOOP ON ERROR
4542
4543 021620 013737 004146 001160      6$: MOV    T.MR2, $TMPO   ;; MASK ALL BITS EXCEPT PARITY
4544 021626 042737 077777 001160      BIC    #77777, $TMPO
4545 021634 023737 004260 001160      CMP    PARBIT, $TMPO  ;; CHECK IF PARITY CORRECT
4546 021642 001402          BEQ    7$             ;; ON MESSAGE B
4547 021644 104057          ERROR 57             ;; PARITY ON MESSAGE B INCORRECT
4548 021646 000412          BR    25$           ;; CHECK IF LOOP ON ERROR
4549
4550 021650 023737 004210 004150      7$: CMP    E.MR3, T.MR3   ;; CHECK IF MESSAGE A CORRECT
4551 021656 001401          BEQ    8$             ;; YES, CHECK MESSAGE B
4552 021660 104060          ERROR 60             ;; MESSAGE A INCORRECT
4553 021662 023737 004206 004146      8$: CMP    E.MR2, T.MR2   ;; CHECK IF MESSAGE B CORRECT
4554 021670 001401          BEQ    25$           ;; YES, CHECK IF LOOP ON ERROR

```

```

4555 021672 104061
4556 021674 104415
4557 021676 005237 004244
4558 021702 022737 000017 004244
4559 021710 103232
4560
4561
4562
4563
4564
4565
4566
4567
4568
4569
4570
4571
4572
4573
4574
4575
4576 021712 000004
4577 021714 012737 000144 001200
4578 021722 013702 001270
4579 021726 012737 000010 004244
4580 021734 012737 021742 001110
4581
4582
4583 021742
4584 021742 012762 000040 000010
4585 021750 012762 000040 000026
4586 021756 013762 004244 000010
4587 021764 012762 000001 000000
4588 021772 012700 000120
4589 021776 012762 000440 000026
4590 022004 012762 000040 000026
4591 022012 005300
4592 022014 001370
4593 022016 016237 000000 004120
4594 022024 016237 000010 004130
4595 022032 016237 000012 004132
4596 022040 016237 000014 004134
4597 022046 012737 000200 004160
4598 022054 013737 004244 004170
4599 022062 052737 000100 004170
4600 022070 005037 004172
4601 022074 005037 004174
4602 022100 023737 004160 004120
4603 022106 001401
4604 022110 104062
4605 022112 023737 004170 004130
4606 022120 001401
4607 022122 104063
4608 022124 023737 004174 004134
4609 022132 001401
4610 022134 104064

```

```

25$: ERROR 61 ;MESSAGE B INCORRECT
SCOPI ;CHECK IF LOOP ON ERROR
INC DRVCOD ;INCREMENT DRIVE SELECT CODE
CMP #17,DRVCOD ;CHECK IF FINISHED
BHS 15 ;NO, TRY NEXT CONFIGURATION

.SBTTL **CLASS A COMMAND EXECUTION
:*****
: *TEST 42 RELEASE COMMAND IN DIAGNOSTIC MODE
: *
: * CLEAR THE RK06 SUBSYSTEM WITH A SUBSYSTEM CLEAR.
: * PUT CONTROLLER IN DIAGNOSTIC MODE. LOAD COMMAND AND
: * STATUS REGISTER 2 WITH DRIVE SELECT = 10. LOAD
: * COMMAND AND STATUS REGISTER 1 WITH A SELECT.
: * CLOCK COMMAND TO COMPLETION. MAKE SURE UNIT
: * FIELD ERROR DOES NOT SET (SACK HIGH). REPEAT FOR
: * DRIVE SELECT = 11-17.
:*****
†ST42: SCOPE
MOV #100,$TIMES ;DO 100. ITERATIONS
MOV $BASE,R2 ;LOAD RK611 BASE
MOV #10,DRVCOD ;INITIALIZE FOR DESELECT OF DRIVE 0
MOV #15,$LPERR ;LOAD LOOP ON ERROR LOCATION FOR
; SUBTEST LOOP

15: MOV #SCLR,RKCS2(R2) ;CLEAR RK06 SUBSYSTEM
MOV #DMD,RKMR1(R2) ;PUT RK611 IN MAINT MODE
MOV DRVCOD,RKCS2(R2) ;LOAD DRIVE SELECTION
MOV #SELDV,RKCS1(R2) ;ISSUE DESELECT
MOV #20,*4,R0 ;LOAD COUNT TO COMPLETE COMMAND
25: MOV #DMD,MCLK,RKMR1(R2) ;CLOCK THRU COMMAND
MOV #DMD,RKMR1(R2)
DEC R0
BNE 25
MOV RKCS1(R2),T.CS1 ;STORE COMMAND AND STATUS REG. 1
MOV RKCS2(R2),T.CS2 ;STORE COMMAND AND STATUS REG. 2
MOV RKDS(R2),T.DS ;STORE DRIVE STATUS REGISTER
MOV RKER(R2),T.ER ;STORE ERROR REGISTER
MOV #RDY,E.CS1 ;LOAD EXPECTED COMMAND AND STATUS REG. 1
MOV DRVCOD,E.CS2 ;GENERATE EXPECTED COMMAND AND
; STATUS REG. 2
CLR E.DS ;LOAD EXPECTED DRIVE STATUS REGISTER
CLR E.ER ;LOAD EXPECTED ERROR REGISTER
CMP E.CS1,T.CS1 ;CHECK COMMAND AND STATUS REG 1 CORRECT
BEQ 35 ;YES, CHECK CS2
ERROR 62 ;COMMAND AND STATUS REG. 1 INCORRECT
CMP E.CS2,T.CS2 ;CHECK COMMAND AND STATUS REG. 2 CORRECT
BEQ 45 ;YES, CHECK ERROR REGISTER
ERROR 63 ;COMMAND AND STATUS REG. 2 INCORRECT
CMP E.ER,T.ER ;CHECK ERROR REGISTER CORRECT
BEQ 55 ;YES, CHECK DRIVE STATUS REG
ERROR 64 ;ERROR REGISTER INCORRECT

```

```

4611 022136 023737 004172 004132 5$: CMP E.DS,T.DS ;CHECK DRIVE STATUS REG CORRECT
4612 022144 001401 BEQ 6$ ;YES, CHECK IF LOOP ON ERROR
4613 022146 104126 ERROR 126 ;DRIVE STATUS REG INCORRECT
4614 022150 104415 6$: SCOPI ;CHECK IF LOOP ON ERROR
4615 022152 005237 004244 INC DRVCOD ;INCREMENT DRIVE NUMBER
4616 022156 022737 000017 004244 CMP #17,DRVCOD ;CHECK IF ALL DRIVE NUMBERS TESTED
4617 022164 103266 BHIS 1$ ;NO, DO IT FOR NEXT DRIVE NUMBER
4618
4619 *****
4620 ;TEST 43 SELECT COMMAND IN DIAGNOSTIC MODE
4621 ;
4622 ; CLEAR THE RK06 SUBSYSTEM WITH A SUBSYSTEM CLEAR.
4623 ; PUT CONTROLLER IN DIAGNOSTIC MODE. LOAD COMMAND AND
4624 ; STATUS REGISTER 2 WITH DRIVE SELECT = 0. LOAD
4625 ; COMMAND AND STATUS REGISTER 1 WITH A SELECT.
4626 ; CLOCK COMMAND TO COMPLETION. MAKE SURE MESSAGE SHIFT IS
4627 ; NOT DONE DURING THE RECEIVE CYCLE OF DRIVE MESSAGE.
4628 ; MAKE SURE NO ERRORS SET. REPEAT FOR DRIVE SELECT = 1-7.
4629 ;
4630 *****
4631 022166 000004 ST43: SCOPE
4632 022170 012737 000144 001200 MOV #100,$TIMES ;DO 100. ITERATIONS
4633 022176 013702 001270 MOV $BASE,R2 ;LOAD RK611 BASE
4634 022202 005037 004244 CLR DRVCOD ;INITIALIZE FOR SELECT OF DRIVE 0
4635 022206 012737 022214 001110 MOV #1$,SLPERR ;LOAD LOOP ON ERROR LOCATION FOR
4636 ; SUBTEST LOOP
4637
4638 022214 1$: MOV #SCLR,RKCS2(R2) ;CLEAR RK06 SUBSYSTEM
4639 022214 012762 000040 000010 MOV #DMD,RKMR1(R2) ;PUT RK611 IN MAINT MODE
4640 022222 012762 000040 000026 MOV DRVCOD,RKCS2(R2) ;LOAD DRIVE SELECT
4641 022230 013762 004244 000010 MOV #SELDIV,RKCS1(R2) ;ISSUE DRIVE SELECT
4642 022236 012762 000001 000000 MOV #20,*4,R0 ;LOAD COUNT TO DESELECT COMPLETE
4643 022244 012700 000120 2$: MOV #DMD:MCLK,RKMR1(R2) ;CLOCK UNTIL DESELECT FINISHED
4644 022250 012762 000440 000026 MOV #DMD,RKMR1(R2)
4645 022256 012762 000040 000026 DEC R0
4646 022264 005300 BNE 2$
4647 022266 001370 2$: MOV RKCS1(R2),T.CS1 ;STORE COMMAND AND STATUS REG. 1
4648 022270 016237 000000 004120 MOV #SELDIV,E.CS1 ;LOAD EXPECTED COMMAND AND STATUS REG. 1
4649 022276 012737 000001 004160 CMP E.CS1,T.CS1 ;CHECK IF READY RESET
4650 022304 023737 004160 004120 BEQ 3$ ;YES, CONTINUE COMMAND
4651 022312 001402 ERROR 6$ ;COMMAND AND STATUS REG. 1 INCORRECT
4652 022314 104065 BR 25$ ;GO CHECK IF LOOP ON ERROR
4653 022316 000566
4654
4655 022320 013703 004244 3$: MOV DRVCOD,R3 ;GENERATE EXPECTED MAINT REG 3
4656 022324 012701 000003 MOV #3,R1
4657 022330 005000 CLR R0
4658 022332 006003 4$: ROR R3
4659 022334 103001 BCC 5$
4660 022336 005200 INC R0
4661 022340 005301 5$: DEC R1
4662 022342 001373 BNE 4$
4663 022344 013737 004244 004210 MOV DRVCOD,E.MR3
4664 022352 032700 000001 BIT #BIT0,R0
4665 022356 001003 BNE 6$
4666 022360 052737 100000 004210 BIS #BIT15,E.MR3

```



# K07

CZR6BCD RK611 DSKLS CTRL PRT2  
CZR6BC.P11 02-DEC-77 09:22

MACY11 30(1046)  
T43

02-DEC-77 09:31 PAGE 88  
SELECT COMMAND IN DIAGNOSTIC MODE

SEQ 0088

4667	022366	012737	100000	004206	6\$:	MOV	#BIT15,E.MR2	;STORE EXPECTED MAINT REG 2
4668	022374	012701	000003			MOV	#3,R1	;ISSUE 3 CONTR. CLOCKS
4669	022400	012700	000004		7\$:	MOV	#4,RO	
4670	022404	012762	000440	000026	8\$:	MOV	#DMD!MCLK,RKMR1(R2)	
4671	022412	012762	000040	000026		MOV	#DMD,RKMR1(R2)	
4672	022420	005300				DEC	RO	
4673	022422	001370				BNE	8\$	
4674	022424	016237	000000	004120		MOV	RKCS1(R2),T.CS1	;STORE COMMAND AND STATUS REG. 1
4675	022432	016237	000034	004146		MOV	RKMR2(R2),T.MR2	;STORE MAINT REG 2
4676	022440	016237	000036	004150		MOV	RKMR3(R2),T.MR3	;STORE MAINT REG 3
4677	022446	023737	004160	004120		CMP	E.CS1,T.CS1	;CHECK COMMAND AND STATUS REG 1 CORRECT
4678	022454	001402				BEQ	9\$	;YES, CHECK MAINTENANCE REG. 2
4679	022456	104066				ERROR	66	;CS1 INCORRECT
4680	022460	000505				BR	25\$	;CHECK IF LOOP ON ERROR
4681								
4682	022462	023737	004206	004146	9\$:	CMP	E.MR2,T.MR2	;CHECK MAINT REG 2 CORRECT
4683	022470	001402				BEQ	10\$	;YES, CHECK MAINTENANCE REG 3
4684	022472	104067				ERROR	67	;MR2 INCORRECT
4685	022474	000477				BR	25\$	;CHECK IF LOOP ON ERROR
4686								
4687	022476	023737	004210	004150	10\$:	CMP	E.MR3,T.MR3	;CHECK IF MAINT REG 3 CORRECT
4688	022504	001402				BEQ	11\$	;YES, CHECK COMMAND COMPLETE
4689	022506	104070				ERROR	70	;MR3 INCORRECT
4690	022510	000471				BR	25\$	;CHECK IF LOOP ON ERROR
4691								
4692	022512	005301			11\$:	DEC	R1	;CHECK IF COMMAND FINISHED
4693	022514	001331				BNE	7\$	;NO, ISSUE ANOTHER CONTROL CLOCK
4694	022516	012700	000004			MOV	#4,RO	;ISSUE LAST CONTROL CLOCK FOR READY
4695	022522	012762	000440	000026	12\$:	MOV	#DMD!MCLK,RKMR1(R2)	
4696	022530	012762	000040	000026		MOV	#DMD,RKMR1(R2)	
4697	022536	005300				DEC	RO	
4698	022540	001370				BNE	12\$	
4699	022542	016237	000000	004120		MOV	RKCS1(R2),T.CS1	;STORE COMMAND AND STATUS REG. 1
4700	022550	016237	000010	004130		MOV	RKCS2(R2),T.CS2	;STORE COMMAND AND STATUS REG. 2
4701	022556	016237	000012	004132		MOV	RKDS(R2),T.DS	;STORE DRIVE STATUS REGISTER
4702	022564	016237	000014	004134		MOV	RKER(R2),T.ER	;STORE ERROR REGISTER
4703	022572	012737	000200	004160		MOV	#RDY,E.CS1	;LOAD EXPECTED COMMAND AND STATUS REG 1
4704	022600	013737	004244	004170		MOV	DRVCD,E.CS2	;GENERATE EXPECTED COMMAND AND STATUS REG. 2
4705	022606	052737	000100	004170		BIS	#IR,E.CS2	
4706	022614	005037	004172			CLR	E.DS	;LOAD EXPECTED DRIVE STATUS REGISTER
4707	022620	005037	004174			CLR	E.ER	;LOAD EXPECTED ERROR REGISTER
4708	022624	023737	004160	004120		CMP	E.CS1,T.CS1	;CHECK COMMAND AND STATUS REG 1 CORRECT
4709	022632	001401				BEQ	13\$	;YES, CHECK CS2
4710	022634	104071				ERROR	71	;CS1 INCORRECT
4711	022636	023737	004170	004130	13\$:	CMP	E.CS2,T.CS2	;CHECK COMMAND AND STATUS REG 2 CORRECT
4712	022644	001401				BEQ	14\$	;YES, CHECK ERROR REG
4713	022646	104072				ERROR	72	;CS2 INCORRECT
4714	022650	023737	004174	004134	14\$:	CMP	E.ER,T.ER	;CHECK IF ERROR REG CORRECT
4715	022656	001401				BEQ	15\$	;YES, CHECK DRIVE STATUS REG CORRECT
4716	022660	104073				ERROR	73	;ERROR REG INCORRECT
4717	022662	023737	004172	004132	15\$:	CMP	E.DS,T.DS	;CHECK DRIVE STATUS REG CORRECT
4718	022670	001401				BEQ	25\$	;YES, CHECK IF LOOP ON ERROR
4719	022672	104127				ERROR	127	;DRIVE STATUS REGISTER INCORRECT
4720	022674	104415			25\$:	SCOP1		;CHECK IF LOOP ON ERROR
4721	022676	005237	004244			INC	DRVCD	;INCREMENT DRIVE NUMBER
4722	022702	022737	000007	004244		CMP	#7,DRVCD	;CHECK IF ALL DRIVES TESTED

4723 022710 103402  
 4724 022712 000137 022214  
 4725  
 4726  
 4727  
 4728  
 4729  
 4730  
 4731  
 4732  
 4733  
 4734  
 4735  
 4736 022716 000004  
 4737 022720 012737 000144 001200  
 4738 022726 013702 001270  
 4739 022732 012737 000010 004244  
 4740 022740 012737 022746 001110  
 4741  
 4742  
 4743 022746  
 4744 022746 012762 000040 000010  
 4745 022754 013762 004244 000010  
 4746 022762 012762 000001 000000  
 4747 022770 013700 004262  
 4748 022774 105762 000000  
 4749 023000 100402  
 4750 023002 005300  
 4751 023004 001373  
 4752 023006 016237 000000 004120  
 4753 023014 016237 000010 004130  
 4754 023022 016237 000012 004132  
 4755 023030 016237 000014 004134  
 4756 023036 012737 000200 004160  
 4757 023044 013737 004244 004170  
 4758 023052 052737 000100 004170  
 4759 023060 005037 004172  
 4760 023064 005037 004174  
 4761 023070 023737 004160 004120  
 4762 023076 001401  
 4763 023100 104074  
 4764 023102 023737 004170 004130  
 4765 023110 001401  
 4766 023112 104075  
 4767 023114 023737 004174 004134  
 4768 023122 001401  
 4769 023124 104076  
 4770 023126 023737 004172 004132  
 4771 023134 001401  
 4772 023136 104130  
 4773 023140 104415  
 4774 023142 005237 004244  
 4775 023146 022737 000017 004244  
 4776 023154 103274  
 4777  
 4778

```

BLO      TST44      ; YES, GO TO NEXT TEST
JMP      1$        ; TRY NEXT DRIVE

*****
*TEST 44      RELEASE COMMAND IN NORMAL MODE
*
* CLEAR THE RK06 SUBSYSTEM WITH A SUBSYSTEM CLEAR.
* LOAD COMMAND AND STATUS REGISTER 2 WITH DRIVE SELECT = 10.
* LOAD COMMAND AND STATUS REGISTER 1 WITH A SELECT.
* MAKE SURE NO ERRORS OCCUR. REPEAT FOR DRIVE
* SELECT = 11-17
*****
↑ST44:  SCOPE
MOV      #100., $TIMES ; DO 100. ITERATIONS
MOV      $BASE, R2     ; LOAD RK611 BASE
MOV      #10, DRVCOD   ; INITIALIZE FOR DESELECT OF DRIVE 0
MOV      #1$, $LPERR   ; LOAD LOOP ON ERROR LOCATION FOR
                        ; SUBTEST LOOP

1$:      MOV      #SCLR, RKCS2(R2) ; CLEAR RK06 SUBSYSTEM
MOV      DRVCOD, RKCS2(R2) ; LOAD DRIVE SELECTION
MOV      #SELD, RKCS1(R2) ; ISSUE DESELECT
MOV      WAITIM, R0 ; WAIT FOR READY

2$:      TSTB     RKCS1(R2)
BMI      3$
DEC      R0
BNE      2$

3$:      MOV      RKCS1(R2), T.CS1 ; STORE COMMAND AND STATUS REG. 1
MOV      RKCS2(R2), T.CS2 ; STORE COMMAND AND STATUS REG. 2
MOV      RKDS(R2), T.DS ; STORE DRIVE STATUS REGISTER
MOV      RKR(R2), T.ER ; STORE ERROR REG.
MOV      #RDY, E.CS1 ; LOAD EXPECTED COMMAND AND STATUS REG. 1
MOV      DRVCOD, E.CS2 ; GENERATE EXPECTED COMMAND AND STATUS REG. 2
BIS      #IR, E.CS2
CLR      E.DS ; LOAD EXPECTED DRIVE STATUS REG
CLR      E.ER ; LOAD EXPECTED ERROR REG.
CMP      E.CS1, T.CS1 ; CHECK COMMAND AND STATUS REG 1 CORRECT
BEQ      4$ ; YES, CHECK CS2
ERROR    74 ; CS1 INCORRECT
CMP      E.CS2, T.CS2 ; CHECK COMMAND AND STATUS REG 2 CORRECT
BEQ      5$ ; YES, CHECK ERROR REGISTER
ERROR    75 ; CS2 INCORRECT
CMP      E.ER, T.ER ; CHECK ERROR REG CORRECT
BEQ      6$ ; YES, CHECK DRIVE STATUS REG CORRECT
ERROR    76 ; ERROR REG INCORRECT
CMP      E.DS, T.DS ; CHECK DRIVE STATUS REG CORRECT
BEQ      7$ ; YES, CHECK IF LOOP ON ERROR
ERROR    130 ; DRIVE STATUS REGISTER INCORRECT
7$:      SCOPE
INC      DRVCOD ; INCREMENT DRIVE NUMBER
CMP      #17, DRVCOD ; CHECK IF ALL DRIVE NUMBERS TESTED
BHIS    1$ ; NO, DO IT FOR NEXT DRIVE

*****

```

4779  
4780  
4781  
4782  
4783  
4784  
4785  
4786  
4787  
4788  
4789  
4790  
4791  
4792  
4793  
4794  
4795  
4796  
4797  
4798  
4799  
4800  
4801  
4802  
4803  
4804  
4805  
4806  
4807  
4808  
4809  
4810  
4811  
4812  
4813  
4814  
4815  
4816  
4817  
4818  
4819  
4820  
4821  
4822  
4823  
4824  
4825  
4826  
4827  
4828  
4829  
4830  
4831  
4832  
4833  
4834

023156 000004  
023160 012737 000144 001270  
023166 013702 001270  
023172 012762 000040 000010  
023200 012762 000010 000010  
023206 013701 004234  
023212 012721 023274  
023216 012711 000340  
023222 005046  
023224 012746 023232  
023230 000002  
023232  
023232 012762 000101 000000  
023240 013700 004262  
023244 105762 000000  
023250 100402  
023252 005300  
023254 001373  
023256 012746 000340  
023262 012746 023270  
023266 000002  
023270 104100  
023272 000522  
023274 062706 000004  
023300 016237 000000 004120  
023306 016237 000010 004130  
023314 016237 000014 004134  
023322 012737 000300 004160  
023330 012737 000110 004170  
023336 005037 004174  
023342 023737 004160 004120  
023350 001401  
023352 104101  
023354 023737 004170 004130  
023362 001401  
023364 104102  
023366 023737 004174 004134  
023374 001401  
023376 104103

```

*TEST 45      INTERRUPT AT COMMAND COMPLETION
*
* CLEAR THE RK06 SUBSYSTEM WITH A SUBSYSTEM CLEAR.
* LOWER PROCESSOR PRIORITY TO ZERO. ISSUE A RELEASE
* COMMAND WITH INTERRUPT ENABLE SET. MAKE SURE
* INTERRUPT OCCURS. LOWER PRIORITY AFTER INTERRUPT
* AND MAKE SURE INTERRUPT HAS CLEARED.
*
* LOWER PROCESSOR PRIORITY TO ZERO. REISSUE RELEASE
* WITH INTERRUPT ENABLE RESET. MAKE SURE NO INTERRUPT
* OCCURS. SET INTERRUPT ENABLE AND MAKE SURE NO
* INTERRUPT OCCURS.
*
*****
↑ST45: SCOPE
MOV #100, $TIMES ; DO 100. ITERATIONS
MOV $BASE, R2 ; LOAD RK611 BASE
MOV #SCLR, RKCS2(R2) ; CLEAR RK06 SUBSYSTEM
MOV #10, RKCS2(R2) ; SET DESELECT BIT
MOV RKVEC, R1 ; LOAD INTERRUPT VECTOR
MOV #5$, (R1)+
MOV #PR7, (R1)
CLR -(SP) ; LOAD STACK TO ALLOW ALL INTERRUPTS
MOV #64$, -(SP) ; LOAD NEXT ADDRESS
RTI ; CLEAR PSW

64$: MOV #SELDRAV!IE, RKCS1(R2) ; ISSUE SELECT DRIVE
MOV WAITIM, R0 ; WAIT FOR READY
2$: TSTB RKCS1(R2)
BMI 3$
R0
BNE 2$
3$: MOV #PR7, -(SP) ; LOCK OUT INTERRUPTS
MOV #4$, -(SP)
RTI

4$: ERROR 100 ; INTERRUPT DID NOT OCCUR
BR 25$

5$: ADD #4, SP ; ADJUST STACK
MOV RKCS1(R2), T.CS1 ; STORE COMMAND AND STATUS REG. 1
MOV RKCS2(R2), T.CS2 ; STORE COMMAND AND STATUS REG. 2
MOV RKER(R2), T.ER ; STORE ERROR REG.
MOV #RDY!IE, E.CS1 ; LOAD EXPECTED CS1
MOV #IR!10, E.CS2 ; LOAD EXPECTED CS2
CLR E.ER ; LOAD EXPECTED ERROR
CMP E.CS1, T.CS1 ; CHECK IF CS1 CORRECT
BEQ 6$ ; YES, CHECK CS2
ERROR 101 ; CS1 INCORRECT
6$: CMP E.CS2, T.CS2 ; CHECK IF CS2 INCORRECT
BEQ 7$ ; YES, CHECK IF ERROR REG CORRECT
ERROR 102 ; CS2 INCORRECT
7$: CMP E.ER, T.ER ; CHECK IF ERROR REG CORRECT
BEQ 8$ ; YES, CHECK IF INTERRUPT CLEARED
ERROR 103 ; ERROR REG. INCORRECT

```

N07

CZR6BC0 RK611 DSKLS CTRL PRT2  
CZR6BC.P11 02-DEC-77 09:22

MACY11 30(1046) 02-DEC-77 09:31 PAGE 91  
T45 INTERRUPT AT COMMAND COMPLETION

SEQ 0091

```

4835 023400 012777 023512 160626 8$: MOV #10$, @RKVEC ;LOAD VECTOR FOR UNEXPECTED INTERRUPT
4836 023406 005046 ;CLR -(SP) ;LOAD STACK TO ALLOW ALL INTERRUPTS
4837 023410 012746 023416 ;MOV #65$, -(SP) ;LOAD NEXT ADDRESS
4838 023414 000002 ;RTI ;CLEAR PSW
4839
4840 023416 65$: NOP ;WAIT FOR INTERRUPT
4841 023416 000240 ;MOV #15$, @RKVEC ;LOAD VECTOR ADDRESS FOR UNEXPECTED INTERRUPT
4842 023420 012777 023522 160606 ;MOV #10, @KCS2(R2) ;ISSUE DESELECT
4843 023426 012762 000010 000010 ;MOV #SELDRV, @KCS1(R2)
4844 023434 012762 000001 000000 ;MOV WAITIM, @0
4845 023442 013700 ;MOV RKCS1(R2)
4846 023446 105762 000000 9$: TSTB
4847 023452 100402 ;BMI 11$
4848 023454 005300 ;DEC @0
4849 023456 001373 ;BNE 9$
4850 023460 000240 11$: NOP ;WAIT FOR INTERRUPT
4851 023462 012777 023532 160544 ;MOV #20$, @RKVEC ;LOAD VECTOR ADDRESS FOR UNEXPECTED INTERRUPT
4852 023470 012762 000100 000000 ;MOV #IE, @KCS1(R2) ;SET INTERRUPT ENABLE
4853 023476 000240 ;NOP ;ALLOW INTERRUPT TO OCCUR
4854 023500 012746 000340 ;MOV #PR7, -(SP) ;LOCK OUT INTERRUPT
4855 023504 012746 023540 ;MOV #25$, -(SP) ;RESTORE TRAP CATCHER
4856 023510 000002 ;RTI
4857
4858 023512 062706 000004 10$: ADD #4, SP ;ADJUST STACK
4859 023516 104104 ;ERROR 104 ;UNEXPECTED INTERRUPT
4860 023520 000407 ;BR 25$ ;RESTORE TRAP CATCHER
4861
4862 023522 062706 000004 15$: ADD #4, SP ;ADJUST STACK
4863 023526 104254 ;ERROR 254 ;UNEXPECTED INTERRUPT ON DESELECT
4864 023530 000403 ;BR 25$ ;RESTORE TRAP CATCHER
4865
4866 023532 062706 000004 20$: ADD #4, SP ;ADJUST STACK
4867 023536 104255 ;ERROR 255 ;UNEXPECTED INTERRUPT WHEN SETTING
4868 ; INTERRUPT ENABLE
4869 023540 012762 000040 000010 25$: MOV #CLR, @KCS2(R2) ;CLEAR RK06 SUBSYSTEM
4870 023546 013701 004234 ;MOV @RKVEC, @R1 ;RESTORE TRAP CATCHER
4871 023552 010111 ;MOV @R1, @R1
4872 023554 062721 000002 ;ADD #2, @R1+
4873 023560 005011 ;CLR @R1
4874
4875 ;*****
4876 ;*TEST 46 GO CLEAR OF SILO
4877 ;*
4878 ;* CLEAR THE RK06 SUBSYSTEM WITH A SUBSYSTEM CLEAR.
4879 ;* WRITE ONE WORD INTO THE SILO. ISSUE A RELEASE COMMAND
4880 ;* WITH INTERRUPT ENABLE RESET. WAIT FOR READY.
4881 ;* READ THE DATA BUFFER TO MAKE SURE THE SILO HAS BEEN
4882 ;* CLEARED. (DATA LATE SET AFTER READ OF DATA BUFFER)
4883 ;*
4884 ;*****
4885 023562 000004 ;ST46: SCOPE
4886 023564 012737 000144 001200 ;MOV #100, @TIMES ;DO 100. ITERATIONS
4887 023572 013702 001270 ;MOV @BASE, @R2 ;LOAD RK611 BASE
4888 023576 012762 000040 000010 ;MOV #SCLR, @KCS2(R2) ;CLEAR RK06 SUBSYSTEM
4889 023604 005062 000024 ;CLR @RKDB(R2) ;LOAD 1 WORD IN SILO
4890 023610 012762 000010 000010 ;MOV #10, @KCS2(R2) ;LOAD DESELECT DRIVE 0

```

```

4891 023616 012762 000001 000000 MOV #SELDV,RKCS1(R2) ;ISSUE DESELECT
4892 023624 013700 004262 MOV WAITIM,R0 ;WAIT FOR READY
4893 023630 105762 000000 2$: TSTB RKCS1(R2)
4894 023634 100402 BMI 3$
4895 023636 005300 DEC R0
4896 023640 001373 BNE 2$
4897 023642 016237 000000 004120 3$: MOV RKCS1(R2),T.CS1 ;STORE COMMAND AND STATUS REG. 1
4898 023650 016237 000010 004130 MOV RKCS2(R2),T.CS2 ;STORE COMMAND AND STATUS REG. 2
4899 023656 016237 000012 004132 MOV RKDS(R2),T.DS ;STORE DRIVE STATUS REGISTER
4900 023664 016237 000014 004134 MOV RKER(R2),T.ER ;STORE ERROR REGISTER
4901 023672 012737 000200 004160 MOV #RDY,E.CS1 ;LOAD EXPECTED CS1
4902 023700 012737 000110 004170 MOV #IR!10,E.CS2 ;LOAD EXPECTED CS2
4903 023706 005037 004172 CLR E.DS ;LOAD EXPECTED DRIVE STATUS REG
4904 023712 005037 004174 CLR E.ER ;LOAD EXPECTED ERROR REGISTER
4905 023716 023737 004170 004130 CMP E.CS2,T.CS2 ;CHECK IF CS1 CORRECT
4906 023724 001401 BEQ 10$ ;YES, READ WORD FROM SILO
4907 023726 104105 ERROR 105 ;CS2 INCORRECT
4908 023730 005762 000024 10$: TST RKDB(R2) ;READ SILO TO MAKE IT IS CLEAR
4909 023734 016237 000000 004120 MOV RKCS1(R2),T.CS1 ;STORE COMMAND AND STATUS REG. 1
4910 023742 016237 000010 004130 MOV RKCS2(R2),T.CS2 ;STORE COMMAND AND STATUS REG. 2
4911 023750 016237 000014 004134 MOV RKER(R2),T.ER ;STORE ERROR REG.
4912 023756 012737 100200 004160 MOV #CERR!RDY,E.CS1 ;LOAD EXPECTED CS1
4913 023764 012737 100110 004170 MOV #DLT!IR!10,E.CS2 ;LOAD EXPECTED CS2
4914 023772 023737 004170 004130 CMP E.CS2,T.CS2 ;CHECK IF DATA LATE SET
4915 024000 001401 BEQ 11$ ;YES, CLEAR CONTROLLER REG. 1
4916 024002 104106 ERROR 106 ;DATA LATE NOT SET
4917 024004 012762 100000 000000 11$: MOV #CCLR,RKCS1(R2) ;CLEAR RK611 CONTROLLER
4918
4919
4920 ;*****
4921 ;*TEST 47 SEEK COMMAND IN DIAGNOSTIC MODE
4922 ;*
4923 ;* CLEAR RK06 SUBSYSTEM WITH A SUBSYSTEM CLEAR.
4924 ;* PUT CONTROLLER IN DIAGNOSTIC MODE. ISSUE A SEEK WITH CDT SET
4925 ;* 24 SECTOR FORMAT TO CYLINDER 1714, HEAD 7, DRIVE 0.
4926 ;* MAKE SURE NO STATUS BITS ARE SET AND NO ERROR
4927 ;* BITS ARE SET.
4928 ;*
4929 ;*****
4930 024012 000004 000144 001200 †ST47: SCOPE
4931 024014 012737 000144 001200 MOV #100,$TIMES ;DO 100 ITERATIONS
4932 024022 013702 001270 MOV $BASE,R2 ;LOAD RK611 BASE
4933 024026 012762 000040 000010 MOV #SCLR,RKCS2(R2) ;CLEAR RK06 SUBSYSTEM
4934 024034 012762 000040 000026 MOV #DMD,RKMR1(R2) ;PUT RK611 IN MAINT MODE
4935 024042 012762 001714 000020 MOV #1714,RKDCYL(R2) ;LOAD CYLINDER ADDRESS
4936 024050 012762 003400 000006 MOV #3400,RKDA(R2) ;LOAD HEAD 7
4937 024056 012762 012017 000000 MOV #SEEK!CFMT!CDT,RKCS1(R2) ;ISSUE SEEK CDT SET,24 SECTOR
4938 024064 012700 000120 MOV #20,*4,R0 ;LOAD COUNT TO DESELECT DECISION
4939 024070 012762 000440 000026 2$: MOV #DMD!MCLK,RKMR1(R2)
4940 024104 005300 DEC R0
4941 024106 001370 BNE 2$
4942 024110 016237 000000 004120 MOV RKCS1(R2),T.CS1 ;STORE COMMAND AND STATUS REG. 1
4943 024116 012737 012017 004160 MOV #SEEK!CFMT!CDT,E.CS1 ;LOAD EXPECTED COMMAND AND STATUS REG 1
4944 024124 023737 004160 004120 CMP E.CS1,T.CS1 ;CHECK IF READY RESET
4945 024132 001402 BEQ 3$ ;YES, CONTINUE COMMAND
4946 024134 104107 ERROR 107

```

```

4947 024136 000543 BR TST50 ;;GO ON TO NEXT TEST
4948
4949 024140 012737 071020 004210 3$: MOV #5, SEEK!S.FMT!70000 E.MR3 ;LOAD EXPECTED MAINT REG. 3
4950 024146 012737 136300 004206 MOV #136300, E.MR2 ;LOAD EXPECTED MAINT REG. 2
4951 024154 012701 000003 MOV #3, R1 ;ISSUE 3 CONTROL CLOCKS
4952 024160 012700 000004 4$: MOV #4, R0
4953 024164 012762 000440 000026 5$: MOV #DMD!MCLK, RKMR1(R2)
4954 024172 012762 000040 000026 MOV #DMD, RKMR1(R2)
4955 024200 005300 DEC R0
4956 024202 001370 BNE 5$
4957 024204 016237 000000 004120 MOV RKCS1(R2), T.CS1 ;STORE COMMAND AND STATUS REG 1
4958 024212 016237 000034 004146 MOV RKMR2(R2), T.MR2 ;STORE MAINT REG 2
4959 024220 016237 000036 004150 MOV RKMR3(R2), T.MR3 ;STORE MAINT REG 3
4960 024226 023737 004160 004120 CMP E.CS1, T.CS1 ;CHECK COMMAND AND STATUS REG. 1 CORRECT
4961 024234 001402 BEQ 6$ ;YES, CHECK MAINTENANCE REG. 2
4962 024236 104110 ERROR 110 ;CS1 INCORRECT
4963 024240 000502 BR TST50 ;GO TO NEXT TEST
4964
4965 024242 023737 004206 004146 6$: CMP E.MR2, T.MR2 ;CHECK MAINT REG 2 CORRECT
4966 024250 001402 BEQ 7$ ;YES, CHECK MAINTENANCE REG 3
4967 024252 104111 ERROR 111 ;MAINT REG 2 INCORRECT
4968 024254 000474 BR TST50 ;GO TO NEXT TEST
4969
4970 024256 023737 004210 004150 7$: CMP E.MR3, T.MR3 ;CHECK IF MAINT REG 3 CORRECT
4971 024264 001402 BEQ 8$ ;YES, CHECK COMMAND COMPLETE
4972 024266 104112 ERROR 112 ;MR3 INCORRECT
4973 024270 000466 BR TST50 ;GO TO NEXT TEST
4974
4975 024272 005301 8$: DEC R1 ;CHECK IF COI 1AND FINISHED
4976 024274 001331 BNE 4$ ;NO, ISSUE AN THER CONTROL CLOCK
4977
4978 024276 012700 000004 MOV #4, R0 ;ISSUE LAST CONTROL CLOCK FOR READY
4979 024302 012762 000440 000026 9$: MOV #DMD!MCLK, RKMR1(R2)
4980 024310 012762 000040 000026 MOV #DMD, RKMR1(R2)
4981 024316 005300 DEC R0
4982 024320 001370 BNE 9$
4983 024322 016237 000000 004120 MOV RKCS1(R2), T.CS1 ;STORE COMMAND AND STATUS REG. 1
4984 024330 016237 000010 004130 MOV RKCS2(R2), T.CS2 ;STORE COMMAND AND STATUS REG. 2
4985 024336 016237 000012 004132 MOV RKDS(R2), T.DS ;STORE DRIVE STATUS REGISTER
4986 024344 016237 000014 004134 MOV RKER(R2), T.ER ;STORE ERROR REGISTER
4987 024352 012737 012216 004160 MOV #RDY!CFMT!CDT!<SEEK!C<GO>> E.CS1 ;LOAD EXPECTED CS1
4988 024360 012737 000100 004170 MOV #IR, E.CS2 ;LOAD EXPECTED CS2
4989 024366 005037 004172 CLR E.DS ;LOAD EXPECTED DRIVE STATUS REGISTER
4990 024372 005037 004174 CLR E.ER ;LOAD EXPECTED ERROR REGISTER
4991 024376 023737 004160 004120 CMP E.CS1, T.CS1 ;CHECK IF COMMAND AND STATUS REG. 2
4992 024404 001401 BEQ 10$ ;YES, CHECK CS2
4993 024406 104113 ERROR 113 ;CS1 INCORRECT
4994 024410 023737 004170 004130 10$: CMP E.CS2, T.CS2 ;CHECK COMMAND AND STATUS REG. 2 CORRECT
4995 024416 001401 BEQ 11$ ;YES, CHECK ERROR REG
4996 024420 104114 ERROR 114 ;CS2 INCORRECT
4997 024422 023737 004174 004134 11$: CMP E.ER, T.ER ;CHECK ERROR REGISTER
4998 024430 001401 BEQ 12$ ;YES, CHECK DRIVE STATUS REG
4999 024432 104115 ERROR 115 ;ERROR REG. INCORRECT
5000 024434 023737 004172 004132 12$: CMP E.DS, T.DS ;CHECK DRIVE STATUS REGISTER CORRECT
5001 024442 001401 BEQ TST50 ;YES, GO ON TO NEXT TEST
5002 024444 104131 ERROR 131 ;DRIVE STATUS REGISTER INCORRECT

```

.SBTTL \*\*ERROR AND STATUS BIT FORCING WITH DRIVE MESSAGES

\*\*\*\*\*  
TEST 50 DRIVE STATUS FROM SHIFT REGISTER

\* CLEAR RK06 SUBSYSTEM WITH A SUBSYSTEM CLEAR. PUT  
\* RK611 CONTROLLER IN DIAGNOSTIC MODE. ISSUE A SEEK  
\* TO AN RK06 IN 26 SECTOR FORMAT, CYLINDER 757, HEAD 1,  
\* DRIVE 0. CLOCK IN DIAGNOSTIC MODE UNTIL PHASE ADDRESS  
\* 6. TURN OFF DIAGNOSTIC MODE AND MAKE SURE SPEED LOSS,  
\* DRIVE AVAILABLE, VOLUME VALID, OFFSET, DRIVE READY,  
\* AND WRITE LOCK ARE SET.  
\*\*\*\*\*

```

TST50: SCOPE
MOV #100, $TIMES ; DO 100 ITERATIONS
MOV $BASE, R2 ; LOAD RK611 BASE
MOV #SCLR, RKCS2(R2) ; CLEAR RK06 SUBSYSTEM
MOV #DMD, RKMR1(R2) ; PUT RK611 IN MAINT MODE
MOV #757, RKDCYL(R2) ; LOAD CYLINDER ADDRESS
MOV #400, RKDA(R2) ; LOAD HEAD ADD =1
MOV #SEEK, RKCS1(R2) ; ISSUE SEEK
MOV #22, *A+2, R0 ; ISSUE CLOCKS UNTIL PHASE ADDRESS 6
15: MOV #DMD!MCLK, RKMR1(R2)
MOV #DMD, RKMR1(R2)
DEC R0
BNE 15
CLR RKMR1(R2) ; FINISH COMMAND IN NORMAL MODE
MOV WAITIM, R0 ; WAIT FOR FOR READY
25: TSTB RKCS1(R2)
BMI 35
DEC R0
BNE 25
MOV RKCS1(R2), T.CS1 ; STORE COMMAND AND STATUS REG 1
MOV #RDY!SEEK<↑C<GO> E.CS1 ; LOAD EXPECTED CS1
ERROR 132 ; READY NOT SET
BR 105 ; CLEAR RK06 SUBSYSTEM
35: MOV RKCS1(R2), T.CS1 ; STORE COMMAND AND STATUS REG 1
MOV RKCS2(R2), T.CS2 ; STORE COMMAND AND STATUS REG 2
MOV RKDS(R2), T.DS ; STORE DRIVE STATUS REF
MOV RKER(R2), T.ER ; STORE ERROR REG.
MOV #RDY!SEEK<↑C<GO> E.CS1 ; LOAD EXPECT CS1
MOV #IR E.CS2 ; LOAD EXPECTED CS2
MOV #DRA!OFST!SPDLSS!VV!DRDY!WRL!SVAL E.DS ; LOAD EXPECTED DRIVE STATUS
CLR E.ER ; LOAD EXPECTED ERROR REGISTER
BIT #DRA!OFST!SPDLSS!VV!DRDY!WRL T.DS ; CHECK LOAD STATUS SET
BNE 45 ; YES, CHECK REGISTERS
ERROR 133 ; NO BIT IN DRIVE STATUS SET
45: CMP E.CS1, T.CS1 ; CHECK CS1 CORRECT
BEQ 55 ; YES, CONTINUE
ERROR 134 ; CS1 INCORRECT
55: CMP E.CS2, T.CS2 ; CHECK CS2 CORRECT
BEQ 65 ; YES, CONTINUE
ERROR 135 ; CS2, INCORRECT

```

5003					
5004					
5005					
5006					
5007					
5008					
5009					
5010					
5011					
5012					
5013					
5014					
5015					
5016					
5017					
5018	024446	000004			
5019	024450	012737	000144	001200	
5020	024456	013702	001270		
5021	024462	012762	000040	000010	
5022	024470	012762	000040	000026	
5023	024476	012762	000757	000020	
5024	024504	012762	000400	000006	
5025	024512	012762	000017	000000	
5026	024520	012700	000132		
5027	024524	012762	000440	000026	15:
5028	024532	012762	000040	000026	
5029	024540	005300			
5030	024542	001370			
5031	024544	005062	000026		
5032	024550	013700	004262		
5033	024554	105762	000000		25:
5034	024560	100412			
5035	024562	005300			
5036	024564	001370			
5037	024566	016237	000000	004120	
5038	024574	012737	000216	004160	
5039	024602	104132			
5040	024604	000460			
5041					
5042	024606	016237	000000	004120	35:
5043	024614	016237	000010	004130	
5044	024622	016237	000012	004132	
5045	024630	016237	000014	004134	
5046	024636	012737	000216	004160	
5047	024644	012737	000100	004170	
5048	024652	012737	104325	004172	
5049	024660	005037	004174		
5050	024664	032737	004325	004132	
5051	024672	001001			
5052	024674	104133			
5053	024676	023737	004160	004120	45:
5054	024704	001401			
5055	024706	104134			
5056	024710	023737	004170	004130	55:
5057	024716	001401			
5058	024720	104135			

```

5059 024722 023737 004174 004134 6$: CMP E.ER,T.ER ;CHECK ERROR REG CORRECT
5060 024730 001401 BEQ 7$ ;YES CONTINUE
5061 024732 104136 ERROR 136 ;ERROR REG INCORRECT
5062 024734 023737 004172 004132 7$: CMP E.DS,T.DS ;CHECK DRIVE STATUS CORRECT
5063 024742 001401 BEQ 10$ ;CLEAR RK611
5064 024744 104137 ERROR 137 ;DRIVE STATUS INCORRECT
5065 024746 013737 004120 004220 10$: MOV T.CS1,P.CS1 ;STORE PREVIOUS CONTENTS OF
5066 024754 013737 004130 004222 MOV T.CS2,P.CS2 ;COMMAND AND STATUS REG 1
5067 024762 013737 004132 004224 MOV T.DS,P.DS ;COMMAND AND STATUS REG 2
5068 024770 013737 004134 004226 MOV T.ER,P.ER ;DRIVE STATUS REG
5069 ;AND ERROR REG
5070 024776 012762 100000 000000 MOV #CLR,RKCS1(R2) ;CLEAR RK611
5071 025004 016237 000000 004120 MOV RKCS1(R2),T.CS1 ;STORE COMMAND AND STATUS REG 1
5072 025012 016237 000010 004130 MOV RKCS2(R2),T.CS2 ;STORE COMMAND AND STATUS REG 2
5073 025020 016237 000012 004132 MOV RKDS(R2),T.DS ;STORE DRIVE STATUS REG
5074 025026 016237 000014 004134 MOV RKER(R2),T.ER ;STORE ERROR REG
5075 025034 012737 000200 004160 MOV #RDY,E.CS1 ;LOAD EXPECTED CS1
5076 025042 012737 000100 004170 MOV #IR,E.CS2 ;LOAD EXPECTED CS2
5077 025050 005037 004172 CLR E.DS ;LOAD EXPECTED DRIVE STATUS REG
5078 025054 005037 004174 CLR E.ER ;LOAD EXPECTED ERROR REG
5079 025060 023737 004160 004120 CMP E.CS1,T.CS1 ;CHECK COMMAND AND STATUS REG 1 CORRECT
5080 025066 001401 BEQ 11$ ;YES, CHECK CS2
5081 025070 104224 ERROR 224 ;CS1 INCORRECT
5082 025072 023737 004170 004130 11$: CMP E.CS2,T.CS2 ;CHECK COMMAND AND STATUS REG 2 CORRECT
5083 025100 001401 BEQ 12$ ;YES, CHECK DRIVE STATUS REG
5084 025102 104225 ERROR 225 ;CS2 INCORRECT
5085 025104 023737 004172 004132 12$: CMP E.DS,T.DS ;CHECK IF DRIVE STATUS REG CORRECT
5086 025112 001401 BEQ 13$ ;YES, CHECK ERROR REG
5087 025114 104226 ERROR 226 ;ERROR REG INCORRECT
5088 025116 023737 004174 004134 13$: CMP E.ER,T.ER ;CHECK IF ERROR REG CORRECT
5089 025124 001401 BEQ TSTS1 ;YES, GO ON TO NEXT TEST
5090 025126 104227 ERROR 227 ;ERROR REG INCORRECT

```

```

*****
*TEST 51 DRIVE AVAILABLE SETTING
*
* CLEAR RK06 SUBSYSTEM WITH A SUBSYSTEM CLEAR.
* PUT CONTROLLER IN DIAGNOSTIC MODE. ISSUE A SEEK TO A RK06.
* 26 SECTOR FORMAT TO CYLINDER 2, HEAD 0, DRIVE 0.
* CLOCK IN DIAGNOSTIC MODE UNTIL PHASE ADDRESS 6.
* TURN OFF DIAGNOSTIC MODE AND MAKE SURE DRIVE
* AVAILIABLE SETS.
*****

```

```

5091
5092
5093
5094
5095
5096
5097
5098
5099
5100
5101
5102
5103 025130 000004 TSTS1: SCOPE
5104 025132 012737 000144 001200 MOV #100,$TIMES ;DO 100. ITERATIONS
5105 025140 013702 001270 MOV $BASE,R2 ;LOAD RK611 BASE
5106 025144 012762 000040 000010 MOV #CLR,RKCS2(R2) ;CLEAR RK06 SUBSYSTEM
5107 025152 012762 000040 000026 MOV #DMD,RKMR1(R2) ;PUT RK611 IN MAINT MODE
5108 025160 012762 000002 000020 MOV #2,RKDCYL(R2) ;LOAD CYLINDER AND
5109 025166 012762 000000 000006 MOV #0,RKDA(R2) ;LOAD HEAD ADDRESS
5110 025174 012762 000017 000000 MOV #SEEK,RKCS1(R2) ;ISSUE SEEK
5111 025202 012700 000132 MOV #22,*4+2,R0 ;ISSUE CLOCKS UNTIL PHASE ADDRESS 6
5112 025206 012762 000440 000026 1$: MOV #DMD!MCLK,RKMR1(R2)
5113 025214 012762 000040 000026 MOV #DMD,RKMR1(R2)
5114 025222 005300 DEC R0

```



```

S115 025224 001370 BNE 1$
S116 025226 005062 000026 CLR RKMR1(R2) ;FINISH COMMAND IN NORMAL MODE
S117 025232 013700 004262 MOV WAITIM,PO ;WAIT FOR READY
S118 025236 105762 J00000 TSTB WKCS1(R2)
S119 025242 100402 BMI 3$
S120 025244 005300 DEC RC
S121 025246 001373 BNE 2$
S122 025250 016237 000000 004120 3$: MOV RKCS1(R2),T.CS1 ;STORE COMMAND AND STATUS REG 1
S123 025256 016237 000010 004130 MOV RK.S2(R2),T.CS2 ;STORE COMMAND AND STATUS REG 2
S124 025264 016237 000012 004132 MOV RK.DS(R2),T.DS ;STORE DRIVE STATUS REG
S125 025272 016237 000014 004134 MOV RK.ER(R2),T.ER ;STORE ERROR REG
S126 025300 012737 000216 004160 MOV #RDY,SEEK8(<FC<GO>) E.CS1 ;LOAD EXPECTED CS1
S127 025306 012737 000100 004170 MOV #IR,E.CS2 ;LOAD EXPECTED CS2
S128 025314 012737 100001 004172 MOV #SVAL:DRR,E.DS ;LOAD EXPECTED DRIVE STATUS REG
S129 025322 012737 000000 004174 MOV #D.E.ER ;LOAD EXPECTED ERROR REG
S130 025330 023737 004160 004120 CMP E.CS1,T.CS1 ;CHECK COMMAND AND STATUS REG.1 CORRECT
S131 025336 001401 BEQ 4$ ;YES, CONTINUE
S132 025340 104140 ERROR 140
S133 025342 023737 004170 004130 4$: CMP E.CS2,T.CS2 ;CHECK COMMAND AND STATUS REG. 2 CORRECT
S134 025350 001401 BEQ 5$ ;YES, CONTINUE
S135 025352 104141 ERROR 141
S136 025354 023737 004172 004132 5$: CMP E.DS,T.DS ;CHECK DRIVE STATUS REG. CORRECT
S137 025362 001401 BEQ 6$ ;YES, CONTINUE
S138 025364 104142 ERROR 142
S139 025366 023737 004174 004134 6$: CMP E.ER,T.ER ;CHECK ERROR REGISTER CORRECT
S140 025374 001401 BEQ 7$ ;YES, CLEAR RK611
S141 025376 104143 ERROR 143
S142 025400 013737 004120 004220 7$: MOV T.CS1,P.CS1 ;STORE PREVIOUS CONTENTS OF
S143 025406 013737 004130 004222 MOV T.CS2,P.CS2 ;COMMAND AND STATUS REG 1
S144 025414 013737 004132 004224 MOV T.DS,P.DS ;COMMAND AND STATUS REG 2
S145 025422 013737 004134 004226 MOV T.ER,P.ER ;DRIVE STATUS REG
S146 ;AND ERROR REG
S147 025430 012762 100000 000000 MOV #CLR,RKCS1(R2) ;CLEAR RK611
S148 025436 016237 000000 004120 MOV RKCS1(R2),T.CS1 ;STORE COMMAND AND STATUS REG 1
S149 025444 016237 000010 004130 MOV RKCS2(R2),T.CS2 ;STORE COMMAND AND STATUS REG 2
S150 025452 016237 000012 004132 MOV RKDS(R2),T.DS ;STORE DRIVE STATUS REG
S151 025460 016237 000014 004134 MOV RK.ER(R2),T.ER ;STORE ERROR REG
S152 025466 012737 000200 004160 MOV #RDY,E.CS1 ;LOAD EXPECTED CS1
S153 025474 012737 000100 004170 MOV #IR,E.CS2 ;LOAD EXPECTED CS2
S154 025502 005037 004172 CLR E.DS ;LOAD EXPECTED DRIVE STATUS REG
S155 025506 005037 004174 CLR E.ER ;LOAD EXPECTED ERROR REG
S156 025512 023737 004160 004120 CMP E.CS1,T.CS1 ;CHECK COMMAND AND STATUS REG 1 CORRECT
S157 025520 001401 BEQ 11$ ;YES, CHECK CS2
S158 025522 104224 ERROR 224 ;CS1 INCORRECT
S159 025524 023737 004170 004130 11$: CMP E.CS2,T.CS2 ;CHECK COMMAND AND STATUS REG 2 CORRECT
S160 025532 001401 BEQ 12$ ;YES, CHECK DRIVE STATUS REG
S161 025534 104225 ERROR 225 ;CS2 INCORRECT
S162 025536 023737 004172 004132 12$: CMP E.DS,T.DS ;CHECK IF DRIVE STATUS REG CORRECT
S163 025544 001401 BEQ 13$ ;YES, CHECK ERROR REG
S164 025546 104226 ERROR 226 ;ERROR REG INCORRECT
S165 025550 023737 004174 004134 13$: CMP E.ER,T.ER ;CHECK IF ERROR REG CORRECT
S166 025556 001401 BEQ TST52 ;YES, GO ON TO NEXT TEST
S167 025560 104227 ERROR 227 ;ERROR REG INCORRECT
S168
S169
S170 ;*****
; *TEST 52 DRIVE BUS PARITY ERROR

```

```

S171
S172
S173
S174
S175
S176
S177
S178
S179
S180 025562 000004
S181 025564 012737 000144 001200
S182 025572 013702 001270
S183 025576 012762 000040 000010
S184 025604 012762 000040 000026
S185 025612 012762 000003 000020
S186 025620 012762 000000 000006
S187 025626 012762 000017 000000
S188 025634 012700 000132
S189 025640 012762 000440 000026 1S:
S190 025646 012762 000040 000026
S191 025654 005300
S192 025656 001370
S193 025660 005062 000026
S194 025664 013700 004262
S195 025670 105762 000000 2S:
S196 025674 100402
S197 025676 005300
S198 025700 001373
S199 025702 016237 000000 004120 3S:
S200 025710 016237 000010 004130
S201 025716 016237 000012 004132
S202 025724 016237 000014 004134
S203 025732 012737 120216 004160
S204 025740 012737 000100 004170
S205 025746 012737 100001 004172
S206 025754 012737 000000 004174
S207 025762 023737 004160 004120
S208 025770 001401
S209 025772 104144
S210 025774 023737 004170 004130 4S:
S211 026002 001401
S212 026004 104145
S213 026006 023737 004172 004132 5S:
S214 026014 001401
S215 026016 104146
S216 026020 023737 004174 004134 6S:
S217 026026 001401
S218 026030 104147
S219 026032 013737 004120 004220 7S:
S220 026040 013737 004130 004222
S221 026046 013737 004132 004224
S222 026054 013737 004134 004226
S223
S224 026062 012762 100000 000000
S225 026070 016237 000000 004120
S226 026076 016237 000010 004130

```

```

*****
TST52: SCOPE
MOV #100, $TIMES ; DO 100. ITERATIONS
MOV $BASE, R2 ; LOAD RK611 BASE
MOV #SCLR, RKCS2(R2) ; CLEAR RK06 SUBSYSTEM
MOV #DMD, RKMR1(R2) ; PUT RK611 IN MAINT MODE
MOV #3, RKDCYL(R2) ; LOAD CYLINDER AND
MOV #0, RKDA(R2) ; LOAD HEAD ADDRESS
MOV #SEEK, RKCS1(R2) ; ISSUE SEEK
MOV #22, *4+2, R0 ; ISSUE CLOCKS UNTIL PHASE ADDRESS 6
MOV #DMD!MCLK, RKMR1(R2)
MOV #DMD, RKMR1(R2),
R0
DEC R0
BNE 1S
CLR RKMR1(R2) ; FINISH COMMAND IN NORMAL MODE
MOV WAITIM, R0 ; WAIT FOR READY
TSTB RKCS1(R2)
BMI 3S
R0
DEC R0
BNE 2S
MOV RKCS1(R2), T.CS1 ; STORE COMMAND AND STATUS REG 1
MOV RKCS2(R2), T.CS2 ; STORE COMMAND AND STATUS REG 2
MOV RKDS(R2), T.DS ; STORE DRIVE STATUS REG
MOV RKER(R2), T.ER ; STORE ERROR REG
MOV #CERR!SPAR!RDY!SEEK<C<GO>>, E.CS1 ; LOAD EXPECTED CS1
MOV #IR, E.CS2 ; LOAD EXPECTED CS2
MOV #SVAL!DRA, E.DS ; LOAD EXPECTED DRIVE STATUS REG
MOV #0, E.ER ; LOAD EXPECTED ERROR REG
CMP E.CS1, T.CS1 ; CHECK COMMAND AND STATUS REG.1 CORRECT
BEQ 4S ; YES, CONTINUE
ERROR 144
CMP E.CS2, T.CS2 ; CHECK COMMAND AND STATUS REG. 2 CORRECT
BEQ 5S ; YES, CONTINUE
ERROR 145
CMP E.DS, T.DS ; CHECK DRIVE STATUS REG. CORRECT
BEQ 6S ; YES, CONTINUE
ERROR 146
CMP E.ER, T.ER ; CHECK ERROR REGISTER CORRECT
BEQ 7S ; YES, CLEAR RK611
ERROR 147
MOV T.CS1, P.CS1 ; STORE PREVIOUS CONTENTS OF
MOV T.CS2, P.CS2 ; COMMAND AND STATUS REG 1
MOV T.DS, P.DS ; COMMAND AND STATUS REG 2
MOV T.ER, P.ER ; DRIVE STATUS REG
; AND ERROR REG
MOV #CLR, RKCS1(R2) ; CLEAR RK611
MOV RKCS1(R2), T.CS1 ; STORE COMMAND AND STATUS REG 1
MOV RKCS2(R2), T.CS2 ; STORE COMMAND AND STATUS REG 2

```

```

5227 026104 016237 000012 004132 MOV RKDS(R2),T.DS ;STORE DRIVE STATUS REG
5228 026112 016237 000014 004134 MOV RKER(R2),T.ER ;STORE ERROR REG
5229 026120 012737 000200 004160 MOV #RDY,E.CS1 ;LOAD EXPECTED CS1
5230 026126 012737 000100 004170 MOV #IR,E.CS2 ;LOAD EXPECTED CS2
5231 026134 005037 004172 CLR E.DS ;LOAD EXPECTED DRIVE STATUS REG
5232 026140 005037 004174 CLR E.ER ;LOAD EXPECTED ERROR REG
5233 026144 023737 004160 004120 CMP E.CS1,T.CS1 ;CHECK COMMAND AND STATUS REG 1 CORRECT
5234 026152 001401 BEQ 115 ;YES, CHECK CS2
5235 026154 104224 ERROR 224 ;CS1 INCORRECT
5236 026156 023737 004170 004130 115: CMP E.CS2,T.CS2 ;CHECK COMMAND AND STATUS REG 2 CORRECT
5237 026164 001401 BEQ 125 ;YES, CHECK DRIVE STATUS REG
5238 026166 104225 ERROR 225 ;CS2 INCORRECT
5239 026170 023737 004172 004132 125: CMP E.DS,T.DS ;CHECK IF DRIVE STATUS REG CORRECT
5240 026176 001401 BEQ 135 ;YES, CHECK ERROR REG
5241 026200 104226 ERROR 226 ;ERROR REG INCORRECT
5242 026202 023737 004174 004134 135: CMP E.ER,T.ER ;CHECK IF ERROR REG CORRECT
5243 026210 001401 BEQ T53 ;YES, GO ON TO NEXT TEST
5244 026212 104227 ERROR 227 ;ERROR REG INCORRECT
5245
5246 *****
5247 *TEST 53 DRIVE AVAILABLE RESET ERROR
5248 *
5249 * CLEAR RK06 SUBSYSTEM WITH A SUBSYSTEM CLEAR.
5250 * PUT CONTROLLER IN DIAGNOSTIC MODE. ISSUE A SELECT
5251 * TO A RK06 26 SECTOR FORMAT AND DRIVE 0.
5252 * CLOCK IN DIAGNOSTIC MODE UNTIL PHASE ADDRESS 6.
5253 * TURN OFF DIAGNOSTIC MODE AND MAKE SURE DRIVE AVAILIABLE
5254 * IS RESET AND CONTROLLER ERROR IS SET.
5255 *
5256 *****
5257 *ST53: SCOPE
5258 026214 000004 MOV #100,$TIMES ;DO 100. ITERATIONS
5259 026216 012737 000144 001200 MOV $BASE,R2 ;LOAD RK611 BASE
5260 026224 013702 001270 MOV #CLR,RKCS2(R2) ;CLEAR RK06 SUBSYSTEM
5261 026230 012762 000040 000010 MOV #DMD,RKMR1(R2) ;PUT RK611 IN MAINT MODE
5262 026236 012762 000040 000026 MOV #SELDV,RKCS1(R2) ;ISSUE SELDRV
5263 026244 012762 000001 000000 MOV #22,*4+2,R0 ;ISSUE CLOCKS UNTIL PHASE ADDRESS 6
5264 026252 012700 000132 15: MOV #DMD!MCLK,RKMR1(R2)
5265 026256 012762 000440 000026 MOV #DMD,RKMR1(R2)
5266 026264 012762 000040 000026 DEC R0
5267 026272 005300 BNE 15
5268 026274 001370 CLR RKMR1(R2) ;FINISH COMMAND IN NORMAL MODE
5269 026276 005062 000026 MOV WAITIM,R0 ;WAIT FOR READY
5270 026302 013700 004262 25: TSTB RKCS1(R2)
5271 026306 105762 000000 BMI 35
5272 026312 100402 DEC R0
5273 026314 005300 BNE 25
5274 026316 001373 35: MOV RKCS1(R2),T.CS1 ;STORE COMMAND AND STATUS REG 1
5275 026320 016237 000000 004120 MOV RKCS2(R2),T.CS2 ;STORE COMMAND AND STATUS REG 2
5276 026326 016237 000010 004130 MOV RKDS(R2),T.DS ;STORE DRIVE STATUS REG
5277 026334 016237 000012 004132 MOV RKER(R2),T.ER ;STORE ERROR REG
5278 026342 016237 000014 004134 MOV #CERR!RDY!SELDV,<T<GO>>,E.CS1 ;LOAD EXPECTED CS1
5279 026350 012737 100200 004160 MOV #IR,E.CS2 ;LOAD EXPECTED CS2
5280 026356 012737 000100 004170 MOV #SVAL!0,E.DS ;LOAD EXPECTED DRIVE STATUS REG
5281 026364 012737 100000 004172 MOV #0,E.ER ;LOAD EXPECTED ERROR REG
5282 026372 012737 000000 004174 MOV #0,E.ER ;LOAD EXPECTED ERROR REG
5283 026400 023737 004160 004120 CMP E.CS1,T.CS1 ;CHECK COMMAND AND STATUS REG.1 CORRECT

```

```

5283 026406 001401 BEQ 4$ ;YES, CONTINUE
5284 026410 104150 ERR. ? 150
5285 026412 023737 004170 004130 4$: CMP E.CS2,T.CS2 ;CHECK COMMAND AND STATUS REG. 2 CORRECT
5286 026420 001401 BEQ 5$ ;YES, CONTINUE
5287 026422 104151 ERROR 151
5288 026424 023737 004172 004132 5$: CMP E.DS,T.DS ;CHECK DRIVE STATUS REG. CORRECT
5289 026432 001401 BEQ 6$ ;YES, CONTINUE
5290 026434 104152 ERROR 152
5291 026436 023737 004174 004134 6$: CMP E.ER,T.ER ;CHECK ERROR REGISTER CORRECT
5292 026444 001401 BEQ 7$ ;YES, CLEAR RK611
5293 026446 104153 ERROR 153
5294 026450 013737 004120 004220 7$: MOV T.CS1,P.CS1 ;STORE PREVIOUS CONTENTS OF
5295 026456 013737 004130 004222 MOV T.CS2,P.CS2 ;COMMAND AND STATUS REG 1
5296 026464 013737 004132 004224 MOV T.DS,P.DS ;COMMAND AND STATUS REG 2
5297 026472 013737 004134 004226 MOV T.ER,P.ER ;DRIVE STATUS REG
5298 ;AND ERROR REG
5299 026500 012762 100000 000000 MOV #CLR,RKCS1(R2) ;CLEAR RK611
5300 026506 016237 000000 004120 MOV RKCS1(R2),T.CS1 ;STORE COMMAND AND STATUS REG 1
5301 026514 016237 000010 004130 MOV RKCS2(R2),T.CS2 ;STORE COMMAND AND STATUS REG 2
5302 026522 016237 000012 004132 MOV RKDS(R2),T.DS ;STORE DRIVE STATUS REG
5303 026530 016237 000014 074134 MOV RKER(R2),T.ER ;STORE ERROR REG
5304 026536 012737 000200 004160 MOV #RDY,E.CS1 ;LOAD EXPECTED CS1
5305 026544 012737 000100 004170 MOV #IR,E.CS2 ;LOAD EXPECTED CS2
5306 026552 005037 004172 CLR E.DS ;LOAD EXPECTED DRIVE STATUS REG
5307 026556 005037 004174 CLR E.ER ;LOAD EXPECTED ERROR REG
5308 026562 023737 004160 004120 CMP E.CS1,T.CS1 ;CHECK COMMAND AND STATUS REG 1 CORRECT
5309 026570 001401 BEQ 11$ ;YES, CHECK CS2
5310 026572 104224 ERROR 224 ;CS1 INCORRECT
5311 026574 023737 004170 004130 11$: CMP E.CS2,T.CS2 ;CHECK COMMAND AND STATUS REG 2 CORRECT
5312 026602 001401 BEQ 12$ ;YES, CHECK DRIVE STATUS REG
5313 026604 104225 ERROR 225 ;CS2 INCORRECT
5314 026606 023737 004172 004132 12$: CMP E.DS,T.DS ;CHECK IF DRIVE STATUS REG CORRECT
5315 026614 001401 BEQ 13$ ;YES, CHECK ERROR REG
5316 026616 104226 ERROR 226 ;ERROR REG INCORRECT
5317 026620 023737 004174 004134 13$: CMP E.ER,T.ER ;CHECK IF ERROR REG CORRECT
5318 026626 001401 BEQ TST54 ;YES, GO ON TO NEXT TEST
5319 026630 104227 ERROR 227 ;ERROR REG INCORRECT

```

```

*****
*TEST 54 CDT SET DRIVE TYPE
*
* CLEAR RK06 SUBSYSTEM WITH A SUBSYSTEM CLEAR.
* PUT CONTROLLER IN DIAGNOSTIC MODE. ISSUE A SEEK
* WITH CDT SET 26 SECTOR FORMAT, TO CYLINDER 23.
* HEAD 0, DRIVE 0. CLOCK IN DIAGNOSTIC MODE
* UNTIL PHASE ADDRESS 6. TURN OFF DIAGNOSTIC MODE
* AND MAKE SURE ONLY DRIVE AVAILIABLE SETS.
*****

```

```

5320
5321
5322
5323
5324
5325
5326
5327
5328
5329
5330
5331
5332 026632 000004 TST54: SCOPE
5333 026634 012737 000144 001200 MOV #100,$TIMES ;DO 100. ITERATIONS
5334 026642 013702 001270 001200 MOV $BASE,R2 ;LOAD RK611 BASE
5335 026646 012762 000040 000010 MOV #CLR,RKCS2(R2) ;CLEAR RK06 SUBSYSTEM
5336 026654 012762 000040 000026 MOV #DMD,RKMR1(R2) ;PUT RK611 IN MAINT MODE
5337 026662 012762 000023 000020 MOV #23,RKDCYL(R2) ;LOAD CYLINDER AND
5338 026670 012762 000000 000006 MOV #0,RKDA(R2) ;LOAD HEAD ADDRESS

```

5339	026676	012762	002017	000000		MOV	#CDT!SEEK,RKCS1(R2)	;ISSUE CDT!SEEK
5340	026704	012700	000132			MOV	#22.*4+2,RO	;ISSUE CLOCKS UNTIL PHASE ADDRESS 6
5341	026710	012762	000440	000026	1\$:	MOV	#DMD!MCLK,RKMR1(R2)	
5342	026716	012762	000040	000026		MOV	#DMD,RKMR1(R2)	
5343	026724	005300				DEC	RO	
5344	026726	001370				BNE	1\$	
5345	026730	005062	000026			CLR	RKMR1(R2)	;FINISH COMMAND IN NORMAL MODE
5346	026734	013700	004262			MOV	WAITIM,RO	;WAIT FOR READY
5347	026740	105762	000000		2\$:	TSTB	RKCS1(R2)	
5348	026744	100402				BMI	3\$	
5349	026746	005300				DEC	RO	
5350	026750	001373				BNE	2\$	
5351	026752	016237	000000	004120	3\$:	MOV	RKCS1(R2),T.CS1	;STORE COMMAND AND STATUS REG 1
5352	026760	016237	000010	004130		MOV	RKCS2(R2),T.CS2	;STORE COMMAND AND STATUS REG 2
5353	026766	016237	000012	004132		MOV	RKDS(R2),T.DS	;STORE DRIVE STATUS REG
5354	026774	016237	000014	004134		MOV	RKER(R2),T.ER	;STORE ERROR REG
5355	027002	012737	002216	004160		MOV	#CDT!PDY!CDT!SEEK<IC<GO>>,E.CS1	;LOAD EXPECTED CS1
5356	027010	012737	000100	004170		MOV	#IR,E.CS2	;LOAD EXPECTED CS2
5357	027016	012737	100401	004172		MOV	#SVAL!DRA!DOT,E.DS	;LOAD EXPECTED DRIVE STATUS REG
5358	027024	012737	000000	004174		MOV	#D.E.ER	;LOAD EXPECTED ERROR REG
5359	027032	023737	004160	004120		CMP	E.CS1,T.CS1	;CHECK COMMAND AND STATUS REG.1 CORRECT
5360	027040	001401				BEQ	4\$	;YES, CONTINUE
5361	027042	104154				ERROR	154	
5362	027044	023737	004170	004130	4\$:	CMP	E.CS2,T.CS2	;CHECK COMMAND AND STATUS REG. 2 CORRECT
5363	027052	001401				BEQ	5\$	;YES, CONTINUE
5364	027054	104155				ERROR	155	
5365	027056	023737	004172	004132	5\$:	CMP	E.DS,T.DS	;CHECK DRIVE STATUS REG. CORRECT
5366	027064	001401				BEQ	6\$	;YES, CONTINUE
5367	027066	104156				ERROR	156	
5368	027070	023737	004174	004134	6\$:	CMP	E.ER,T.ER	;CHECK ERROR REGISTER CORRECT
5369	027076	001401				BEQ	7\$	;YES, CLEAR RK611
5370	027100	104157				ERROR	157	
5371	027102	013737	004120	004220	7\$:	MOV	T.CS1,P.CS1	;STORE PREVIOUS CONTENTS OF
5372	027110	013737	004130	004222		MOV	T.CS2,P.CS2	COMMAND AND STATUS REG 1
5373	027116	013737	004132	004224		MOV	T.DS,P.DS	COMMAND AND STATUS REG 2
5374	027124	013737	004134	004226		MOV	T.ER,P.ER	DRIVE STATUS REG
5375								AND ERROR REG
5376	027132	012762	100000	000000		MOV	#CLR,RKCS1(R2)	;CLEAR RK611
5377	027140	016237	000000	004120		MOV	RKCS1(R2),T.CS1	;STORE COMMAND AND STATUS REG 1
5378	027146	016237	000010	004130		MOV	RKCS2(R2),T.CS2	;STORE COMMAND AND STATUS REG 2
5379	027154	016237	000012	004132		MOV	RKDS(R2),T.DS	;STORE DRIVE STATUS REG
5380	027162	016237	000014	004134		MOV	RKER(R2),T.ER	;STORE ERROR REG
5381	027170	012737	000200	004160		MOV	#RDY,E.CS1	;LOAD EXPECTED CS1
5382	027176	012737	000100	004170		MOV	#IR,E.CS2	;LOAD EXPECTED CS2
5383	027204	005037	004172			CLR	E.DS	;LOAD EXPECTED DRIVE STATUS REG
5384	027210	005037	004174			CLR	E.ER	;LOAD EXPECTED ERROR REG
5385	027214	023737	004160	004120		CMP	E.CS1,T.CS1	;CHECK COMMAND AND STATUS REG 1 CORRECT
5386	027222	001401				BEQ	11\$	;YES, CHECK CS2
5387	027224	104224				ERROR	224	;CS1 INCORRECT
5388	027226	023737	004170	004130	11\$:	CMP	E.CS2,T.CS2	;CHECK COMMAND AND STATUS REG 2 CORRECT
5389	027234	001401				BEQ	12\$	;YES, CHECK DRIVE STATUS REG
5390	027236	104225				ERROR	225	;CS2 INCORRECT
5391	027240	023737	004172	004132	12\$:	CMP	E.DS,T.DS	;CHECK IF DRIVE STATUS REG CORRECT
5392	027246	001401				BEQ	13\$	;YES, CHECK ERROR REG
5393	027250	104226				ERROR	226	;ERROR REG INCORRECT
5394	027252	023737	004174	004134	13\$:	CMP	E.ER,T.ER	;CHECK IF ERROR REG CORRECT

5395 027260 001401 BEQ TST55 ;: YES, GO ON TO NEXT TEST  
5396 027262 104227 ERROR 227 ;: ERROR REG INCORRECT

\*\*\*\*\*  
: TEST 55 CDT SET AND DRIVE TYPE ERROR  
\*\*\*\*\*

\* CLEAR RK06 SUBSYSTEM WITH A SUBSYSTEM CLEAR  
\* PUT CONTROLLER IN DIAGNOSTIC MODE. ISSUE A SEEK  
\* WITH CDT SET, 26 SECTOR FORMAT, TO CYLINDER 2,  
\* HEAD 0, DRIVE 0. CLOCK IN DIAGNOSTIC MODE  
\* UNTIL PHASE ADDRESS 6. TURN OFF DIAGNOSTIC MODE  
\* AND MAKE SURE DRIVE AVAILIABLE, DRIVE TYPE ERROR,  
\* AND CONTROLLER ERROR SET.  
\*\*\*\*\*

5410	027264	000004			↑TST55: SCOPE	
5411	027266	012737	000144	001200	MOV	#100, \$TIMES ;: DO 100. ITERATIONS
5412	027274	013702	001270		MOV	\$BASE, R2 ;: LOAD RK611 BASE
5413	027300	012762	000040	000010	MOV	#SCLR, RKCS2(R2) ;: CLEAR RK06 SUBSYSTEM
5414	027306	012762	000040	000026	MOV	#DMD, RKMR1(R2) ;: PUT RK611 IN MAINT MODE
5415	027314	012762	000002	000020	MOV	#2, RKDCYL(R2) ;: LOAD CYLINDER AND
5416	027322	012762	000000	000006	MOV	#0, RKDA(R2) ;: LOAD HEAD ADDRESS
5417	027330	012762	002017	000000	MOV	#CDT!SEEK, RKCS1(R2) ;: ISSUE CDT!SEEK
5418	027336	012700	000132		MOV	#22 *4+2, R0 ;: ISSUE CLOCKS UNTIL PHASE ADDRESS 6
5419	027342	012762	000440	000026	1\$: MOV	#DMD!MCLK, RKMR1(R2)
5420	027350	012762	000040	000026	MOV	#DMD, RKMR1(R2)
5421	027356	005300			DEC	R0
5422	027360	001370			BNE	1\$
5423	027362	005062	000026		CLR	RKMR1(R2) ;: FINISH COMMAND IN NORMAL MODE
5424	027366	013700	004262		MOV	WAITIM, R0 ;: WAIT FOR READY
5425	027372	105762	000000		2\$: TSTB	RKCS1(R2)
5426	027376	1J0402			BMI	3\$
5427	027400	005300			DEC	R0
5428	027402	001373			BNE	2\$
5429	027404	016237	000000	004120	3\$: MOV	RKCS1(R2), T.CS1 ;: STORE COMMAND AND STATUS REG 1
5430	027412	016237	000010	004130	MOV	RKCS2(R2), T.CS2 ;: STORE COMMAND AND STATUS REG 2
5431	027420	016237	000012	004132	MOV	RKDS(R2), T.DS ;: STORE DRIVE STATUS REG
5432	027426	016237	000014	004134	MOV	RKER(R2), T.ER ;: STORE ERROR REG
5433	027434	012737	102216	004160	MOV	#CDT!CERR!RDY!CDT!SEEK<↑C<GO>>, E.CS1 ;: LOAD EXPECTED CS1
5434	027442	012737	000100	004170	MOV	#IR, E.CS2 ;: LOAD EXPECTED CS2
5435	027450	012737	100001	004172	MOV	#SVAL!DRA, E.DS ;: LOAD EXPECTED DRIVE STATUS REG
5436	027456	012737	000040	004174	MOV	#DTYE, E.ER ;: LOAD EXPECTED ERROR REG
5437	027464	023737	004160	004120	CMP	E.CS1, T.CS1 ;: CHECK COMMAND AND STATUS REG. 1 CORRECT
5438	027472	001401			BEQ	4\$ ;: YES, CONTINUE
5439	027474	104160			ERROR	160
5440	027476	023737	004170	004130	4\$: CMP	E.CS2, T.CS2 ;: CHECK COMMAND AND STATUS REG. 2 CORRECT
5441	027504	001401			BEQ	5\$ ;: YES, CONTINUE
5442	027506	104161			ERROR	161
5443	027510	023737	004172	004132	5\$: CMP	E.DS, T.DS ;: CHECK DRIVE STATUS REG. CORRECT
5444	027516	001401			BEQ	6\$ ;: YES, CONTINUE
5445	027520	104162			ERROR	162
5446	027522	023737	004174	004134	6\$: CMP	E.ER, T.ER ;: CHECK ERROR REGISTER CORRECT
5447	027530	001401			BEQ	7\$ ;: YES, CLEAR RK611
5448	027532	104163			ERROR	163
5449	027534	013737	004120	004220	7\$: MOV	T.CS1, P.CS1 ;: STORE PREVIOUS CONTENTS OF
5450	027542	013737	004130	004222	MOV	T.CS2, P.CS2 ;: COMMAND AND STATUS REG 1

```

5451 027550 013737 004132 004224      MOV      T.DS,P.DS      ; COMMAND AND STATUS REG 2
5452 027556 013737 004134 004226      MOV      T.ER,P.ER    ; DRIVE STATUS REG
5453                                     ; AND ERROR REG
5454 027564 012762 100000 000000      MOV      #CCLR,RKCS1(R2) ; CLEAR RK611
5455 027572 016237 000000 004120      MOV      RKCS1(R2),T.CS1 ; STORE COMMAND AND STATUS REG 1
5456 027600 016237 000010 004130      MOV      RKCS2(R2),T.CS2 ; STORE COMMAND AND STATUS REG 2
5457 027606 016237 000012 004132      MOV      RKDS(R2),T.DS  ; STORE DRIVE STATUS REG
5458 027614 016237 000014 004134      MOV      RKER(R2),T.ER  ; STORE ERROR REG
5459 027622 012737 000200 004160      MOV      #RDY,E.CS1    ; LOAD EXPECTED CS1
5460 027630 012737 000100 004170      MOV      #IR,E.CS2    ; LOAD EXPECTED CS2
5461 027636 005037 004172      CLR      E.DS         ; LOAD EXPECTED DRIVE STATUS REG
5462 027642 005037 004174      CLR      E.ER         ; LOAD EXPECTED ERROR REG
5463 027646 023737 004160 004120      CMP      E.CS1,T.CS1  ; CHECK COMMAND AND STATUS REG 1 CORRECT
5464 027654 001401 11$      BEQ      11$          ; YES, CHECK CS2
5465 027656 104224 224      ERROR   224          ; CS1 INCORRECT
5466 027660 023737 004170 004130 11$      CMP      E.CS2,T.CS2  ; CHECK COMMAND AND STATUS REG 2 CORRECT
5467 027666 001401 12$      BEQ      12$          ; YES, CHECK DRIVE STATUS REG
5468 027670 104225 225      ERROR   225          ; CS2 INCORRECT
5469 027672 023737 004172 004132 12$      CMP      E.DS,T.DS    ; CHECK IF DRIVE STATUS REG CORRECT
5470 027700 001401 13$      BEQ      13$          ; YES, CHECK ERROR REG
5471 027702 104226 226      ERROR   226          ; ERROR REG INCORRECT
5472 027704 023737 004174 004134 13$      CMP      E.ER,T.ER    ; CHECK IF ERROR REG CORRECT
5473 027712 001401      BEQ      TST56        ; YES, GO ON TO NEXT TEST
5474 027714 104227      ERROR   227          ; ERROR REG INCORRECT

```

```

*****
*TEST 56      RK06 AND DRIVE TYPE ERROR
*
* CLEAR RK06 SUBSYSTEM WITH A SUBSYSTEM CLEAR
* PUT CONTROLLER IN DIAGNOSTIC MODE. ISSUE A SEEK
* TO A RK06, 26 SECTOR FORMAT, TO CYLINDER 23,
* HEAD 0, DRIVE 0. CLOCK IN DIAGNOSTIC MODE
* UNTIL PHASE ADDRESS 6. TURN OFF DIAGNOSTIC
* MODE AND MAKE SURE DRIVE AVAILIABLE, DRIVE TYPE ERROR,
* AND CONTROLLER ERROR SETS.
*

```

```

*****
↑TST56: SCOPE
5488 027716 000004      MOV      #100,$TIMES  ; DO 100. ITERATIONS
5489 027720 012737 000144 001200      MOV      $BASE,R2     ; LOAD RK611 BASE
5490 027726 013702 001270 000040      MOV      #SCLR,RKCS2(R2) ; CLEAR RK06 SUBSYSTEM
5491 027732 012762 000040 000010      MOV      #DMD,RKMR1(R2) ; PUT RK611 IN MAINT MODE
5492 027740 012762 000040 000026      MOV      #23,RKDCYL(R2) ; LOAD CYLINDER FND
5493 027746 012762 000023 000020      MOV      #0,RKDA(R2)   ; LOAD HEAD ADDRESS
5494 027754 012762 000000 000006      MOV      #SEEK,RKCS1(R2) ; ISSUE SEEK
5495 027762 012762 000017 000000      MOV      #22,*4+2,R0   ; ISSUE CLOCKS UNTIL PHASE ADDRESS 6
5496 027770 012700 000132 1$      MOV      #DMD!MCLK,RKMR1(R2)
5497 027774 012762 000440 000026 1$      MOV      #DMD,RKMR1(R2)
5498 030002 012762 000040 000026      DEC      R0
5499 030010 005300      BNE     1$
5500 030012 001370      CLR     1$
5501 030014 005062 000026      CLR     RKMR1(R2)     ; FINISH COMMAND IN NORMAL MODE
5502 030020 013700 004262      MOV     WAITIM,R0     ; WAIT FOR READY
5503 030024 105762 000000 2$      TSTB   RKCS1(R2)
5504 030030 100402 3$      BMI     3$
5505 030032 005300      DEC     R0
5506 0277034 001373      BNE     2$

```

M08

CZR6BC0 RK611 OSKLS CTRL PRT2  
CZR6BC.P11 02-DEC-77 09:22

MACY11 30(1046) 02-DEC-77 09:31 PAGE 103  
T56 RK06 AND DRIVE TYPE ERROR

SEQ 0103

```

5507 030036 016237 000000 004120 3$: MOV RKCS1(R2),T.CS1 ;STORE COMMAND AND STATUS REG 1
5508 030044 016237 000010 004130 MOV RKCS2(R2),T.CS2 ;STORE COMMAND AND STATUS REG 2
5509 030052 016237 000012 004132 MOV RKDS(R2),T.DS ;STORE DRIVE STATUS REG
5510 030060 016237 000014 004134 MOV RKER(R2),T.ER ;STORE ERROR REG
5511 030066 012737 100216 004160 MOV #CERR!RDY!SEEK&<C<GO>> E.CS1 ;LOAD EXPECTED CS1
5512 030074 012737 000100 004170 MOV #IR,E.CS2 ;LOAD EXPECTED CS2
5513 030102 012737 100401 004172 MOV #SVAL!DRA!DOT,E.DS ;LOAD EXPECTED DRIVE STATUS REG
5514 030110 012737 000040 004174 MOV #DTYE,E.ER ;LOAD EXPECTED ERROR REG
5515 030116 023737 004160 004120 CMP E.CS1,T.CS1 ;CHECK COMMAND AND STATUS REG.1 CORRECT
5516 030124 001401 BEQ 4$ ;YES, CONTINUE
5517 030126 104164 ERROR 164
5518 030130 023737 004170 004130 4$: CMP E.CS2,T.CS2 ;CHECK COMMAND AND STATUS REG. 2 CORRECT
5519 030136 001401 BEQ 5$ ;YES, CONTINUE
5520 030140 104165 ERROR 165
5521 030142 023737 004172 004132 5$: CMP E.DS,T.DS ;CHECK DRIVE STATUS REG. CORRECT
5522 030150 001401 BEQ 6$ ;YES, CONTINUE
5523 030152 104166 ERROR 166
5524 030154 023737 004174 004134 6$: CMP E.ER,T.ER ;CHECK ERROR REGISTER CORRECT
5525 030162 001401 BEQ 7$ ;YES, CLEAR RK611
5526 030164 104167 ERROR 167
5527 030166 013737 004120 004220 7$: MOV T.CS1,P.CS1 ;STORE PREVIOUS CONTENTS OF
5528 030174 013737 004130 004222 MOV T.CS2,P.CS2 ;COMMAND AND STATUS REG 1
5529 030202 013737 004132 004224 MOV T.DS,P.DS ;COMMAND AND STATUS REG 2
5530 030210 013737 004134 004226 MOV T.ER,P.ER ;DRIVE STATUS REG
5531 ;AND ERROR REG
5532 030216 012762 100000 000000 MOV #CLR,RKCS1(R2) ;CLEAR RK611
5533 030224 016237 000000 004120 MOV RKCS1(R2),T.CS1 ;STORE COMMAND AND STATUS REG 1
5534 030232 016237 000010 004130 MOV RKCS2(R2),T.CS2 ;STORE COMMAND AND STATUS REG 2
5535 030240 016237 000012 004132 MOV RKDS(R2),T.DS ;STORE DRIVE STATUS REG
5536 030246 016237 000014 004134 MOV RKER(R2),T.ER ;STORE ERROR REG
5537 030254 012737 000200 004160 MOV #RDY,E.CS1 ;LOAD EXPECTED CS1
5538 030262 012737 000100 004170 MOV #IR,E.CS2 ;LOAD EXPECTED CS2
5539 030270 005037 004172 CLR E.DS ;LOAD EXPECTED DRIVE STATUS REG
5540 030274 005037 004174 CLR E.ER ;LOAD EXPECTED ERROR REG
5541 030300 023737 004160 004120 CMP E.CS1,T.CS1 ;CHECK COMMAND AND STATUS REG 1 CORRECT
5542 030306 001401 BEQ 11$ ;YES, CHECK CS2
5543 030310 104224 ERROR 224 ;CS1 INCORRECT
5544 030312 023737 004170 004130 11$: CMP E.CS2,T.CS2 ;CHECK COMMAND AND STATUS REG 2 CORRECT
5545 030320 001401 BEQ 12$ ;YES, CHECK DRIVE STATUS REG
5546 030322 104225 ERROR 225 ;CS2 INCORRECT
5547 030324 023737 004172 004132 12$: CMP E.DS,T.DS ;CHECK IF DRIVE STATUS REG CORRECT
5548 030332 001401 BEQ 13$ ;YES, CHECK ERROR REG
5549 030334 104226 ERROR 226 ;ERROR REG INCORRECT
5550 030336 023737 004174 004134 13$: CMP E.ER,T.ER ;CHECK IF ERROR REG CORRECT
5551 030344 001401 BEQ TST57 ;YES, GO ON TO NEXT TEST
5552 030346 104227 ERROR 227 ;ERROR REG INCORRECT

```

```

*****
*TEST 57 SPEED LOSS FROM SHIFT REG.
*
* CLEAR RK06 SUBSYSTEM WITH A SUBSYSTEM CLEAR.
* PUT CONTROLLER IN DIAGNOSTIC MODE. ISSUE A SEEK TO A RK06.
* 26 SECTOR FORMAT TO CYLINDER 3, HEAD 1, DRIVE 0.
* CLOCK IN DIAGNOSTIC MODE UNTIL PHASE ADDRESS 6. TURN
* OFF DIAGNOSTIC MODE AND MAKE SURE DRIVE AVAILIABLE AND
* SPEED LOSS ARE SET.

```

5553  
5554  
5555  
5556  
5557  
5558  
5559  
5560  
5561  
5562



```

5563 ;*
5564 ;*****
5565 030350 000004 T57: SCOPE
5566 030352 012737 000144 001200 MOV #100, $TIMES ; DO 100. ITERATIONS
5567 030360 013702 001270 MOV $BASE, R2 ; LOAD RK611 BASE
5568 030364 012762 000040 000010 MOV #SCLR, RKCS2(R2) ; CLEAR RK06 SUBSYSTEM
5569 030372 012762 000040 000026 MOV #DMG, RKMR1(R2) ; PUT RK611 IN MAINT MODE
5570 030400 012762 000003 000020 MOV #3, RKDCYL(R2) ; LOAD CYLINDER AND
5571 030406 012762 000400 000006 MOV #400, RKDA(R2) ; LOAD HEAD ADDRESS
5572 030414 012762 000017 000000 MOV #SEEK, RKCS1(R2) ; ISSUE SEEK
5573 030422 012700 000132 MOV #22, *4+2, RO ; ISSUE CLOCKS UNTIL PHASE ADDRESS 6
5574 030426 012762 000440 000026 1$: MOV #DMD!MCLK, RKMR1(R2)
5575 030434 012762 000040 000026 MOV #DMD, RKMR1(R2)
5576 030442 005300 DEC RO
5577 030444 001370 BNE 1$
5578 030446 005062 000026 CLR RKMR1(R2) ; FINISH COMMAND IN NORMAL MODE
5579 030452 013700 004262 MOV WAITIM, RO ; WAIT FOR READY
5580 030456 105762 000000 2$: TSTB RKCS1(R2)
5581 030462 100402 BMI 3$
5582 030464 005300 DEC RO
5583 030466 001373 BNE 2$
5584 030470 016237 000000 004120 3$: MOV RKCS1(R2), T.CS1 ; STORE COMMAND AND STATUS REG 1
5585 030476 016237 000010 004130 MOV RKCS2(R2), T.CS2 ; STORE COMMAND AND STATUS REG 2
5586 030504 016237 000012 004132 MOV RKDS(R2), T.DS ; STORE DRIVE STATUS REG
5587 030512 016237 000014 004134 MOV RKER(R2), T.ER ; STORE ERROR REG
5588 030520 012737 000216 004160 MOV #RDY!SEEK<↑C<GO>>, E.CS1 ; LOAD EXPECTED CS1
5589 030526 012737 000100 004170 MOV #IR, E.CS2 ; LOAD EXPECTED CS2
5590 030534 012737 100021 004172 MOV #SVAL!DRA!SPDLSS, E.DS ; LOAD EXPECTED DRIVE STATUS REG
5591 030542 012737 000000 004174 MOV #J, E.ER ; LOAD EXPECTED ERROR REG
5592 030550 023737 004160 004120 CMP E.CS1, T.CS1 ; CHECK COMMAND AND STATUS REG.1 CORRECT
5593 030556 001401 BEQ 4$ ; YES, CONTINUE
5594 030560 104170 ERROR 170
5595 030562 023737 004170 004130 4$: CMP E.CS2, T.CS2 ; CHECK COMMAND AND STATUS REG. 2 CORRECT
5596 030570 001401 BEQ 5$ ; YES, CONTINUE
5597 030572 104171 ERROR 171
5598 030574 023737 004172 004132 5$: CMP E.DS, T.DS ; CHECK DRIVE STATUS REG. CORRECT
5599 030602 001401 BEQ 6$ ; YES, CONTINUE
5600 030604 104172 ERROR 172
5601 030606 023737 004174 004134 6$: CMP E.ER, T.ER ; CHECK ERROR REGISTER CORRECT
5602 030614 001401 BEQ 7$ ; YES, CLEAR RK611
5603 030616 104173 ERROR 173
5604 030620 013737 004120 004220 7$: MOV T.CS1, P.CS1 ; STORE PREVIOUS CONTENTS OF
5605 030626 013737 004130 004222 MOV T.CS2, P.CS2 ; COMMAND AND STATUS REG 1
5606 030634 013737 004132 004224 MOV T.DS, P.DS ; COMMAND AND STATUS REG 2
5607 030642 013737 004134 004226 MOV T.ER, P.ER ; DRIVE STATUS REG
5608 ; AND ERROR REG
5609 030650 012762 100000 000000 MOV #CCLR, RKCS1(R2) ; CLEAR RK611
5610 030656 016237 000000 004120 MOV RKCS1(R2), T.CS1 ; STORE COMMAND AND STATUS REG 1
5611 030664 016237 000010 004130 MOV RKCS2(R2), T.CS2 ; STORE COMMAND AND STATUS REG 2
5612 030672 016237 000012 004132 MOV RKDS(R2), T.DS ; STORE DRIVE STATUS REG
5613 030700 016237 000014 004134 MOV RKER(R2), T.ER ; STORE ERROR REG
5614 030706 012737 000200 004160 MOV #RDY, E.CS1 ; LOAD EXPECTED CS1
5615 030714 012737 000100 004170 MOV #IR, E.CS2 ; LOAD EXPECTED CS2
5616 030722 005037 004172 CLR E.DS ; LOAD EXPECTED DRIVE STATUS REG
5617 030726 005037 004174 CLR E.ER ; LOAD EXPECTED ERROR REG
5618 030732 023737 004160 004120 CMP E.CS1, T.CS1 ; CHECK COMMAND AND STATUS REG 1 CORRECT

```

5619	030740	001401				BEQ	11\$		:YES, CHECK CS2
5620	030742	104224				ERROR	224		:CS1 INCORRECT
5621	030744	023737	004170	004130	11\$:	CMP	E.CS2,T.CS2		:CHECK COMMAND AND STATUS REG 2 CORRECT
5622	030752	001401				BEQ	12\$		:YES, CHECK DRIVE STATUS REG
5623	030754	104225				ERROR	225		:CS2 INCORRECT
5624	030756	023737	004172	004132	12\$:	CMP	E.DS,T.DS		:CHECK IF DRIVE STATUS REG CORRECT
5625	030764	001401				BEQ	13\$		:YES, CHECK ERROR REG
5626	030766	104226				ERROR	226		:ERROR REG INCORRECT
5627	030770	023737	004174	004134	13\$:	CMP	E.ER,T.ER		:CHECK IF ERROR REG CORRECT
5628	030776	001401				BEQ	TST60		:YES, GO ON TO NEXT TEST
5629	031000	104227				ERROR	227		:ERROR REG INCORRECT

\*\*\*\*\*  
:TEST 60 DRIVE OFF TRACK FROM SHIFT REG.  
\*\*\*\*\*

\* CLEAR RK06 SUBSYSTEM WITH A SUBSYSTEM CLEAR.  
\* PUT CONTROLLER IN DIAGNOSTIC MODE. ISSUE A SEEK TO A RK06,  
\* 26 SECTOR FORMAT TO CYLINDER 3, HEAD 2, DRIVE 0.  
\* CLOCK IN DIAGNOSTIC MODE UNTIL PHASE ADDRESS 6.  
\* TURN OFF DIAGNOSTIC MODE AND MAKE SURE DRIVE AVAILIABLE  
\* AND DRIVE OFF TRACK ARE SET.  
\*\*\*\*\*

5642	031002	000004				TST60:	SCOPE		
5643	031004	012737	000144	001200		MOV	#100,\$TIMES		:DO 100. ITERATIONS
5644	031012	013702	001270			MOV	\$BASE,R2		:LOAD RK611 BASE
5645	031016	012762	000040	000010		MOV	#SCLR,RKCS2(R2)		:CLEAR RK06 SUBSYSTEM
5646	031024	012762	000040	000026		MOV	#DMD,RKMR1(R2)		:PUT RK611 IN MAINT MODE
5647	031032	012762	000003	000020		MOV	#3,RKDCYL(R2)		:LOAD CYLINDER AND
5648	031040	012762	001000	000006		MOV	#1000,RKDA(R2)		:LOAD HEAD ADDRESS
5649	031046	012762	000017	000000		MOV	#SEEK,RKCS1(R2)		:ISSUE SEEK
5650	031054	012700	000132			MOV	#22,*4+2,RO		:ISSUE CLOCKS UNTIL PHASE ADDRESS 6
5651	031060	012762	000440	000026	1\$:	MOV	#DMD!MCLK,RKMR1(R2)		
5652	031066	012762	000040	000026		MOV	#DMD,RKMR1(R2)		
5653	031074	005300				DEC	RO		
5654	031076	001370				BNE	1\$		
5655	031100	005062	000026			CLR	RKMR1(R2)		:FINISH COMMAND IN NORMAL MODE
5656	031104	013700	004262			MOV	WAITIM,RO		:WAIT FOR READY
5657	031110	105762	000000		2\$:	TSTB	RKCS1(R2)		
5658	031114	100402				BMI	3\$		
5659	031116	005300				DEC	RO		
5660	031120	001373				BNE	2\$		
5661	031122	016237	000000	004120	3\$:	MOV	RKCS1(R2),T.CS1		:STORE COMMAND AND STATUS REG 1
5662	031130	016237	000010	004130		MOV	RKCS2(R2),T.CS2		:STORE COMMAND AND STATUS REG 2
5663	031136	016237	000012	004132		MOV	RKDS(R2),T.DS		:STORE DRIVE STATUS REG
5664	031144	016237	000014	004134		MOV	RKER(R2),T.ER		:STORE ERROR REG
5665	031152	012737	000216	004160		MOV	#RDY!SEEK&<↑C<GO>>,E.CS1		:LOAD EXPECTED CS1
5666	031160	012737	000100	004170		MOV	#IR,E.CS2		:LOAD EXPECTED CS2
5667	031166	012737	100041	004172		MOV	#SVAL!DRA!DROT,E.DS		:LOAD EXPECTED DRIVE STATUS REG
5668	031174	012737	000000	004174		MOV	#0,E.ER		:LOAD EXPECTED ERROR REG
5669	031202	023737	004160	004120		CMP	E.CS1,T.CS1		:CHECK COMMAND AND STATUS REG.1 CORRECT
5670	031210	001401				BEQ	4\$		:YES, CONTINUE
5671	031212	104174				ERROR	174		
5672	031214	023737	004170	004130	4\$:	CMP	E.CS2,T.CS2		:CHECK COMMAND AND STATUS REG. 2 CORRECT
5673	031222	001401				BEQ	5\$		:YES, CONTINUE
5674	031224	104175				ERROR	175		

```

5675 031226 023737 004172 004132 5$:  CMP      E.DS,T.DS      ;CHECK DRIVE STATUS REG. CORRECT
5676 031234 001401          BEQ      6$          ;YES, CONTINUE
5677 031236 104176          ERROR 176
5678 031240 023737 004174 004134 6$:  CMP      E.ER,T.ER      ;CHECK ERROR REGISTER CORRECT
5679 031246 001401          BEQ      7$          ;YES, CLEAR RK611
5680 031250 104177          ERROR 177
5681 031252 013737 004120 004220 7$:  MOV      T.CS1,P.CS1    ;STORE PREVIOUS CONTENTS OF
5682 031260 013737 004130 004222    MOV      T.CS2,P.CS2    ;COMMAND AND STATUS REG 1
5683 031266 013737 004132 004224    MOV      T.DS,P.DS     ;COMMAND AND STATUS REG 2
5684 031274 013737 004134 004226    MOV      T.ER,P.ER     ;DRIVE STATUS REG
5685          ;AND ERROR REG
5686 031302 012762 100000 000000    MOV      #CCLR,RKCS1(R2) ;CLEAR RK611
5687 031310 016237 000000 004120    MOV      RKCS1(R2),T.CS1 ;STORE COMMAND AND STATUS REG 1
5688 031316 016237 000010 004130    MOV      RKCS2(R2),T.CS2 ;STORE COMMAND AND STATUS REG 2
5689 031324 016237 000012 004132    MOV      RKDS(R2),T.DS  ;STORE DRIVE STATUS REG
5690 031332 016237 000014 004134    MOV      RKER(R2),T.ER  ;STORE ERROR REG
5691 031340 012737 000200 004160    MOV      #RDY,E.CS1    ;LOAD EXPECTED CS1
5692 031346 012737 000100 004170    MOV      #IR,E.CS2    ;LOAD EXPECTED CS2
5693 031354 005037 004172          CLR      E.DS         ;LOAD EXPECTED DRIVE STATUS REG
5694 031360 005037 004174          CLR      E.ER         ;LOAD EXPECTED ERROR REG
5695 031364 023737 004160 004120    CMP      E.CS1,T.CS1   ;CHECK COMMAND AND STATUS REG 1 CORRECT
5696 031372 001401          BEQ      11$         ;YES, CHECK CS2
5697 031374 104224          ERROR 224          ;CS1 INCORRECT
5698 031376 023737 004170 004130 11$:  CMP      E.CS2,T.CS2   ;CHECK COMMAND AND STATUS REG 2 CORRECT
5699 031404 001401          BEQ      12$         ;YES, CHECK DRIVE STATUS REG
5700 031406 104225          ERROR 225          ;CS2 INCORRECT
5701 031410 023737 004172 004132 12$:  CMP      E.DS,T.DS     ;CHECK IF DRIVE STATUS REG CORRECT
5702 031416 001401          BEQ      13$         ;YES, CHECK ERROR REG
5703 031420 104226          ERROR 226          ;ERROR REG INCORRECT
5704 031422 023737 004174 004134 13$:  CMP      E.ER,T.ER     ;CHECK IF ERROR REG CORRECT
5705 031430 001401          BEQ      TST61       ;YES, GO ON TO NEXT TEST
5706 031432 104227          ERROR 227          ;ERROR REG INCORRECT

```

```

*****
;TEST 61 WRITE LOCK ERROR FROM SHIFT REG.

```

```

;
; CLEAR RK06 SUBSYSTEM WITH A SUBSYSTEM CLEAR.
; PUT CONTROLLER IN DIAGNOSTIC MODE. ISSUE A PACK ACKNOWLEDGE
; TO A RK06, 26 SECTOR FORMAT, WITH CYLINDER 0,
; HEAD 1, DRIVE 0. CLOCK IN DIAGNOSTIC MODE UNTIL
; PHASE ADDRESS 6. TURN OFF DIAGNOSTIC MODE AND MAKE
; SURE SPEED LOSS, WRITE LOCK ERROR AND CONTROLLER ERROR
; ARE SET WITH DRIVE AVAILIABLE RESET.

```

```

*****
TST61: SCOPE

```

```

5720 031434 000004          TST61: SCOPE
5721 031436 012737 000144 001200    MOV      #100,$TIMES   ;DO 100. ITERATIONS
5722 031444 013702 001270          MOV      $BASE,R2     ;LOAD RK611 BASE
5723 031450 012762 000040 000010    MOV      #SCLR,RKCS2(R2) ;CLEAR RK06 SUBSYSTEM
5724 031456 012762 000040 000026    MOV      #DMD,RKMR1(R2) ;PUT RK611 IN MAINT MODE
5725 031464 012762 000000 000020    MOV      #0,RKDCYL(R2) ;LOAD CYLINDER AND
5726 031472 012762 000400 000006    MOV      #400,RKDA(R2) ;LOAD HEAD ADDRESS
5727 031500 012762 000003 000000    MOV      #PACK,RKCS1(R2) ;ISSUE PACK
5728 031506 012700 000132          MOV      #22,*4+2,R0  ;ISSUE CLOCKS UNTIL PHASE ADDRESS 6
5729 031512 012762 000440 000026 1$:  MOV      #DMD!MCLK,RKMR1(R2)
5730 031520 012762 000040 000026    MOV      #DMD,RKMR1(R2)

```

```

5731 031526 005300          DEC      RO
5732 031530 001370          BNE     1$
5733 031532 005062 000026   CLR     RKMR1(R2)      ;FINISH COMMAND IN NORMAL MODE
5734 031536 013700 004262   MOV     WAITIM,RO      ;WAIT FOR READY
5735 031542 105762 000000   TSTB   RKCS1(R2)
5736 031546 100402          BMI     3$
5737 031550 005300          DEC     RO
5738 031552 001373          BNE     2$
5739 031554 016237 000000 004120 3$:  MOV     RKCS1(R2),T.CS1 ;STORE COMMAND AND STATUS REG 1
5740 031562 016237 000010 004130   MOV     RKCS2(R2),T.CS2 ;STORE COMMAND AND STATUS REG 2
5741 031570 016237 000012 004132   MOV     RKDS(R2),T.DS   ;STORE DRIVE STATUS REG
5742 031576 016237 000014 004134   MOV     RKER(R2),T.ER   ;STORE ERROR REG
5743 031604 012737 100202 004160   MOV     #CERR!RDY!PACK&<T.C<GO>>,E.CS1 ;LOAD EXPECTED CS1
5744 031612 012737 000100 004170   MOV     #IR,E.CS2      ;LOAD EXPECTED CS2
5745 031620 012737 100020 004172   MOV     #SVAL!SPDLSS,E.DS ;LOAD EXPECTED DRIVE STATUS REG
5746 031626 012737 004000 004174   MOV     #WLE,E.ER      ;LOAD EXPECTED ERROR REG
5747 031634 023737 004160 004120   CMP     E.CS1,T.CS1    ;CHECK COMMAND AND STATUS REG.1 CORRECT
5748 031642 001401          BEQ     4$             ;YES, CONTINUE
5749 031644 104200          ERROR   200
5750 031646 023737 004170 004130 4$:  CMP     E.CS2,T.CS2    ;CHECK COMMAND AND STATUS REG. 2 CORRECT
5751 031654 001401          BEQ     5$             ;YES, CONTINUE
5752 031656 104201          ERROR   201
5753 031660 023737 004172 004132 5$:  CMP     E.DS,T.DS     ;CHECK DRIVE STATUS REG. CORRECT
5754 031666 001401          BEQ     6$             ;YES, CONTINUE
5755 031670 104202          ERROR   202
5756 031672 023737 004174 004134 6$:  CMP     E.ER,T.ER     ;CHECK ERROR REGISTER CORRECT
5757 031700 001401          BEQ     7$             ;YES, CLEAR RK611
5758 031702 104203          ERROR   203
5759 031704 013737 004120 004220 7$:  MOV     T.CS1,P.CS1    ;STORE PREVIOUS CONTENTS OF
5760 031712 013737 004130 004222   MOV     T.CS2,P.CS2    ;COMMAND AND STATUS REG 1
5761 031720 013737 004132 004224   MOV     T.DS,P.DS     ;COMMAND AND STATUS REG 2
5762 031726 013737 004134 004226   MOV     T.ER,P.ER     ;DRIVE STATUS REG
5763                                ;AND ERROR REG
5764 031734 012762 100000 000000   MOV     #CLR,RKCS1(R2) ;CLEAR RK611
5765 031742 016237 000000 004120   MOV     RKCS1(R2),T.CS1 ;STORE COMMAND AND STATUS REG 1
5766 031750 016237 000010 004130   MOV     RKCS2(R2),T.CS2 ;STORE COMMAND AND STATUS REG 2
5767 031756 016237 000012 004132   MOV     RKDS(R2),T.DS   ;STORE DRIVE STATUS REG
5768 031764 016237 000014 004134   MOV     RKER(R2),T.ER   ;STORE ERROR REG
5769 031772 012737 000200 004160   MOV     #RDY,E.CS1     ;LOAD EXPECTED CS1
5770 032000 012737 000100 004170   MOV     #IR,E.CS2     ;LOAD EXPECTED CS2
5771 032006 005037 004172          CLR     E.DS          ;LOAD EXPECTED DRIVE STATUS REG
5772 032012 005037 004174          CLR     E.ER          ;LOAD EXPECTED ERROR REG
5773 032016 023737 004160 004120   CMP     E.CS1,T.CS1    ;CHECK COMMAND AND STATUS REG 1 CORRECT
5774 032024 001401          BEQ     11$           ;YES, CHECK CS2
5775 032026 104224          ERROR   224           ;CS1 INCORRECT
5776 032030 023737 004170 004130 11$:  CMP     E.CS2,T.CS2    ;CHECK COMMAND AND STATUS REG. 2 CORRECT
5777 032036 001401          BEQ     12$           ;YES, CHECK DRIVE STATUS REG
5778 032040 104225          ERROR   225           ;CS2 INCORRECT
5779 032042 023737 004172 004132 12$:  CMP     E.DS,T.DS     ;CHECK IF DRIVE STATUS REG CORRECT
5780 032050 001401          BEQ     13$           ;YES, CHECK ERROR REG
5781 032052 104226          ERROR   226           ;ERROR REG INCORRECT
5782 032054 023737 004174 004134 13$:  CMP     E.ER,T.ER     ;CHECK IF ERROR REG CORRECT
5783 032062 001401          BEQ     TST62         ;YES, GO ON TO NEXT TEST
5784 032064 104227          ERROR   227           ;ERROR REG INCORRECT
5785
5786

```

::\*\*\*\*\*

5787  
5788  
5789  
5790  
5791  
5792  
5793  
5794  
5795  
5796  
5797  
5798  
5799  
5800  
5801  
5802  
5803  
5804  
5805  
5806  
5807  
5808  
5809  
5810  
5811  
5812  
5813  
5814  
5815  
5816  
5817  
5818  
5819  
5820  
5821  
5822  
5823  
5824  
5825  
5826  
5827  
5828  
5829  
5830  
5831  
5832  
5833  
5834  
5835  
5836  
5837  
5838  
5839  
5840  
5841  
5842

032066 000004  
032070 012737 000144 001200  
032076 013702 001270  
032102 012762 000040 000010  
032110 012762 000040 000026  
032116 012762 000000 000020  
032124 012762 000400 000006  
032132 012762 000007 000000  
032140 012700 000132  
032144 012762 000440 000026  
032152 012762 000040 000026  
032160 005300  
032162 001370  
032164 005062 000026  
032170 013700 004262  
032174 105762 000000  
032200 100402  
032202 005300  
032204 001373  
032206 016237 000000 004120  
032214 016237 000010 004130  
032222 016237 000012 004132  
032230 016237 000014 004134  
032236 012737 00206 004160  
032244 012737 000100 004170  
032252 012737 100020 004172  
032260 012737 000002 004174  
032266 023737 004160 004120  
032274 001401  
032276 104204  
032300 023737 004170 004130  
032306 001401  
032310 104205  
032312 023737 004172 004132  
032320 001401  
032322 104206  
032324 023737 004174 004134  
032332 001401  
032334 104207  
032336 013737 004120 004220  
032344 013737 004130 004222  
032352 013737 004132 004224  
032360 013737 004134 004226  
032366 012762 100000 000000

```

*TEST 62      SEEK INCOMPLETE
*
* CLEAR RK06 SUBSYSTEM WITH A SUBSYSTEM CLEAR.
* PUT CONTROLLER IN DIAGNOSTIC MODE. ISSUE AN UNLOAD
* TO A RK06, 26 SECTOR FORMAT, WITH CYLINDER 0,
* HEAD 1, DRIVE 0, CLOCK IN DIAGNOSTIC MODE UNTIL
* PHASE ADDRESS 6. TURN OFF DIAGNOSTIC MODE AND MAKE
* SURE SPEED LOSS, SEEK INCOMPLETE, AND CONTROLLER ERROR
* ARE SET WITH DRIVE AVAILABLE RESET.
*
*****
↑ST62: SCOPE
MOV #100, $TIMES ; DO 100 ITERATIONS
MOV $BASE, R2 ; LOAD RK611 BASE
MOV #SCLR, RKCS2(R2) ; CLEAR RK06 SUBSYSTEM
MOV #DMD, RKMR1(R2) ; PUT RK611 IN MAINT MODE
MOV #0, RKDCYL(R2) ; LOAD CYLINDER AND
MOV #400, RKDA(R2) ; LOAD HEAD ADDRESS
MOV #UNLOAD, RKCS1(R2) ; ISSUE UNLOAD
MOV #22, *4+2, R0 ; ISSUE CLOCKS UNTIL PHASE ADDRESS 6
1$: MOV #DMD!MCLK, RKMR1(R2)
MOV #DMD, RKMR1(R2)
R0
DEC
BNE 1$
CLR RKMR1(R2) ; FINISH COMMAND IN NORMAL MODE
MOV WAITIM, R0 ; WAIT FOR READY
2$: TSTB RKCS1(R2)
BMI 3$
R0
BNE 2$
3$: MOV RKCS1(R2), T.CS1 ; STORE COMMAND AND STATUS REG 1
MOV RKCS2(R2), T.CS2 ; STORE COMMAND AND STATUS REG 2
MOV RKDS(R2), T.DS ; STORE DRIVE STATUS REG
MOV RKER(R2), T.ER ; STORE ERROR REG
MOV #CERR!RDY!UNLOAD<↑C<GO>>, E.CS1 ; LOAD EXPECTED CS1
MOV #IR, E.CS2 ; LOAD EXPECTED CS2
MOV #SVAL!SPDLSS, E.DS ; LOAD EXPECTED DRIVE STATUS REG
MOV #SKI, E.ER ; LOAD EXPECTED ERROR REG
CMP E.CS1, T.CS1 ; CHECK COMMAND AND STATUS REG. 1 CORRECT
BEQ 4$ ; YES, CONTINUE
4$: ERROR 204
CMP E.CS2, T.CS2 ; CHECK COMMAND AND STATUS REG. 2 CORRECT
BEQ 5$ ; YES, CONTINUE
5$: ERROR 205
CMP E.DS, T.DS ; CHECK DRIVE STATUS REG. CORRECT
BEQ 6$ ; YES, CONTINUE
6$: ERROR 206
CMP E.ER, T.ER ; CHECK ERROR REGISTER CORRECT
BEQ 7$ ; YES, CLEAR RK611
7$: ERROR 207
MOV T.CS1, P.CS1 ; STORE PREVIOUS CONTENTS OF
MOV T.CS2, P.CS2 ; COMMAND AND STATUS REG 1
MOV T.DS, P.DS ; COMMAND AND STATUS REG 2
MOV T.ER, P.ER ; DRIVE STATUS REG
; AND ERROR REG
MOV #CLR, RKCS1(R2) ; CLEAR RK611

```

```

5843 032374 016237 000000 004120 MOV RKCS1(R2),T.CS1 ;STORE COMMAND AND STATUS REG 1
5844 032402 016237 000010 004130 MOV RKCS2(R2),T.CS2 ;STORE COMMAND AND STATUS REG 2
5845 032410 016237 000012 004132 MOV RKDS(R2),T.DS ;STORE DRIVE STATUS REG
5846 032416 016237 000014 004134 MOV RKER(R2),T.ER ;STORE ERROR REG
5847 032424 012737 000200 004160 MOV #RDY,E.CS1 ;LOAD EXPECTED CS1
5848 032432 012737 000100 004170 MOV #IR,E.CS2 ;LOAD EXPECTED CS2
5849 032440 005037 004172 CLR E.DS ;LOAD EXPECTED DRIVE STATUS REG
5850 032444 005037 004174 CLR E.ER ;LOAD EXPECTED ERROR REG
5851 032450 023737 004160 004120 CMP E.CS1,T.CS1 ;CHECK COMMAND AND STATUS REG 1 CORRECT
5852 032456 001401 BEQ 11$ ;YES, CHECK CS2
5853 032460 104224 ERROR 224 ;CS1 INCORRECT
5854 032462 023737 004170 004130 11$: CMP E.CS2,T.CS2 ;CHECK COMMAND AND STATUS REG 2 CORRECT
5855 032470 001401 BEQ 12$ ;YES, CHECK DRIVE STATUS REG
5856 032472 104225 ERROR 225 ;CS2 INCORRECT
5857 032474 023737 004172 004132 12$: CMP E.DS,T.DS ;CHECK IF DRIVE STATUS REG CORRECT
5858 032502 001401 BEQ 13$ ;YES, CHECK ERROR REG
5859 032504 104226 ERROR 226 ;ERROR REG INCORRECT
5860 032506 023737 004174 004134 13$: CMP E.ER,T.ER ;CHECK IF ERROR REG CORRECT
5861 032514 001401 BEQ TST63 ;YES, GO ON TO NEXT TEST
5862 032516 104227 ERROR 227 ;ERROR REG INCORRECT

```

```

5863
5864 *****
5865 *TEST 63 NON-EXECUTABLE DRIVE FUNCTION FROM SHIFT REG.
5866 *
5867 * CLEAR RK06 SUBSYSTEM WITH A SUBSYSTEM CLEAR
5868 * PUT CONTROLLER IN DIAGNOSTIC MODE. ISSUE
5869 * A DRIVE CLEAR TO A RK06, 26 SECTOR FORMAT
5870 * WITH CYLINDER 0, HEAD 1, DRIVE 0. CLOCK IN DIAGNOSTIC
5871 * MODE UNTIL PHASE ADDRESS 6. TURN OFF DIAGNOSTIC
5872 * MODE AND MAKE SURE SPEED LOSS, NON-EXECUTABLE DRIVE FUNCTION, AND
5873 * CONTROLLER ERROR ARE SET WITH DRIVE AVAILABLE RESET.
5874 *
5875 *****

```

```

5876 032520 000004 TST63: SCOPE
5877 032522 012737 000144 001200 MOV #100,$TIMES ;DO 100. ITERATIONS
5878 032530 013702 001270 MOV $BASE,R2 ;LOAD RK611 BASE
5879 032534 012762 000040 000010 MOV #SCLR,RKCS2(R2) ;CLEAR RK06 SUBSYSTEM
5880 032542 012762 000040 000026 MOV #DMD,RKMR1(R2) ;PUT RK611 IN MAINT MODE
5881 032550 012762 000000 000020 MOV #0,RKDCYL(R2) ;LOAD CYLINDER AND
5882 032556 012762 000400 000006 MOV #400,RKDA(R2) ;LOAD HEAD ADDRESS
5883 032564 012762 000005 000000 MOV #CLEAR,RKCS1(R2) ;ISSUE CLEAR
5884 032572 012700 000132 MOV #22,*4+2,R0 ;ISSUE CLOCKS UNTIL PHASE ADDRESS 6
5885 032576 012762 000440 000026 1$: MOV #DMD!MCLK,RKMR1(R2)
5886 032604 012762 000040 000026 MOV #DMD,RKMR1(R2)
5887 032612 005300 DEC R0
5888 032614 001370 BNE 1$
5889 032616 005062 000026 CLR RKMR1(R2) ;FINISH COMMAND IN NORMAL MODE
5890 032622 013700 004262 MOV WAITIM,R0 ;WAIT FOR READY
5891 032626 105762 000000 2$: TSTB RKCS1(R2)
5892 032632 100402 BMI 3$
5893 032634 005300 DEC R0
5894 032636 001373 BNE 2$
5895 032640 016237 000000 004120 3$: MOV RKCS1(R2),T.CS1 ;STORE COMMAND AND STATUS REG 1
5896 032646 016237 000010 004130 MOV RKCS2(R2),T.CS2 ;STORE COMMAND AND STATUS REG 2
5897 032654 016237 000012 004132 MOV RKDS(R2),T.DS ;STORE DRIVE STATUS REG
5898 032662 016237 000014 004134 MOV RKER(R2),T.ER ;STORE ERROR REG

```

```

5899 032670 012737 100204 004160 MOV #CERR!RDY!CLEAR&<+C(GO)> E.CS1 :LOAD EXPECTED CS1
5900 032676 012737 000100 004170 MOV #IR E.CS2 :LOAD EXPECTED CS2
5901 032704 012737 100020 004172 MOV #SVAL!SPOLSS,E.DS :LOAD EXPECTED DRIVE STATUS REG
5902 032712 012737 000004 004174 MOV #NXF E.ER :LOAD EXPECTED ERROR REG
5903 032720 023737 004160 004120 CMP E.CS1,T.CS1 :CHECK COMMAND AND STATUS REG.1 CORRECT
5904 032726 001401 BEQ 4$ :YES, CONTINUE
5905 032730 104210 ERROR 210
5906 032732 023737 004170 004130 4$: CMP E.CS2,T.CS2 :CHECK COMMAND AND STATUS REG. 2 CORRECT
5907 032740 001401 BEQ 5$ :YES, CONTINUE
5908 032742 104211 ERROR 211
5909 032744 023737 004172 004132 5$: CMP E.DS,T.DS :CHECK DRIVE STATUS REG. CORRECT
5910 032752 001401 BEQ 6$ :YES, CONTINUE
5911 032754 104212 ERROR 212
5912 032756 023737 004174 004134 6$: CMP E.ER,T.ER :CHECK ERROR REGISTER CORRECT
5913 032764 001401 BEQ 7$ :YES, CLEAR RK611
5914 032766 104213 ERROR 213
5915 032770 013737 004120 004220 7$: MOV T.CS1,P.CS1 :STORE PREVIOUS CONTENTS OF
5916 032776 013737 004130 004222 MOV T.CS2,P.CS2 :COMMAND AND STATUS REG 1
5917 033004 013737 004132 004224 MOV .DS,P.DS :COMMAND AND STATUS REG 2
5918 033012 013737 004134 004226 MOV T.ER,P.ER :DRIVE STATUS REG
5919 :AND ERROR REG
5920 033020 012762 100000 000000 MOV #CLR RKCS1(R2) :CLEAR RK611
5921 033026 016237 000000 004120 MOV RKCS1(R2),T.CS1 :STORE COMMAND AND STATUS REG 1
5922 033034 016237 000010 004130 MOV RKCS2(R2),T.CS2 :STORE COMMAND AND STATUS REG 2
5923 033042 016237 000012 004132 MOV RKDS(R2),T.DS :STORE DRIVE STATUS REG
5924 033050 016237 000014 004134 MOV RKER(R2),T.ER :STORE ERROR REG
5925 033056 012737 000200 004160 MOV #RDY E.CS1 :LOAD EXPECTED CS1
5926 033064 012737 000100 004170 MOV #IR E.CS2 :LOAD EXPECTED CS2
5927 033072 005037 004172 CLR E.DS :LOAD EXPECTED DRIVE STATUS REG
5928 033076 005037 004174 CLR E.ER :LOAD EXPECTED ERROR REG
5929 033102 023737 004160 004120 CMP E.CS1,T.CS1 :CHECK COMMAND AND STATUS REG 1 CORRECT
5930 BEQ 11$ :YES, CHECK CS2
5931 033112 104224 ERROR 224 :CS1 INCORRECT
5932 033114 023737 004 70 004130 11$: CMP E.CS2,T.CS2 :CHECK COMMAND AND STATUS REG 2 CORRECT
5933 BEQ 12$ :YES, CHECK DRIVE STATUS REG
5934 033124 104225 ERROR 225 :CS2 INCORRECT
5935 033126 023737 004172 004132 12$: CMP E.DS,T.DS :CHECK IF DRIVE STATUS REG CORRECT
5936 033134 001401 BEQ 13$ :YES, CHECK ERROR REG
5937 033136 104226 ERROR 226 :ERROR REG INCORRECT
5938 033140 023737 004174 004134 13$: CMP E.ER,T.ER :CHECK IF ERROR REG CORRECT
5939 033146 001401 BEQ TST64 :YES, GO ON TO NEXT TEST
5940 033150 104227 ERROR 227 :ERROR REG INCORRECT

```

```

*****
:TEST 64 AC LOW AND C-D PARITY FROM SHIFT REG.
:
: CLEAR RK06 SUBSYSTEM WITH A SUBSYSTEM CLEAR, PUT RK611
: CONTROLLER IN DIAGNOSTIC MODE. ISSUE A START SPINDLE
: TO AN RK06, IN 24 SECTOR FORMAT, CYLINDER 0, HEAD 0,
: DRIVE 0. CLOCK IN DIAGNOSTIC MODE UNTIL PHASE ADDRESS 6.
: TURN OFF DIAGNOSTIC MODE AND MAKE SURE AC LOW, DRIVE
: DETECTED SERCOM PARITY, AND CONTROLLER ERROR SET WITH
: DRIVE AVAILABLE RESET.
*****
TST64: SCOPE

```

5953 033152 000004

5955	033154	012737	000144	001200		MOV	#100, \$TIMES	:: DO 100. ITERATIONS
5956	033162	013702	001270			MOV	\$BASE, R2	:: LOAD RK611 BASE
5957	033166	012762	000040	000010		MOV	#SCLR, RKCS2(R2)	:: CLEAR RK06 SUBSYSTEM
5958	033174	012762	000040	000026		MOV	#OMD, RKMR1(R2)	:: PUT RK611 IN MAINT MODE
5959	033202	012762	010011	000000		MOV	#SRTSPL!CFMT, RKCS1(R2)	:: ISSUE SRTSPL!CFMT
5960	033210	012700	000132			MOV	#22, #4+2, R0	:: ISSUE CLOCKS UNTIL PHASE ADDRESS 6
5961	033214	012762	000440	000026	1\$:	MOV	#DMC!MCLK, RKMR1(R2)	
5962	033222	012762	000040	000026		MOV	#OMD, RKMR1(R2)	
5963	033230	005300				DEC	R0	
5964	033232	001370				BNE	1\$	
5965	033234	005062	000026			CLR	RKMR1(R2)	:: FINISH COMMAND IN NORMAL MODE
5966	033240	013700	004262			MOV	WAITIM, R0	:: WAIT FOR READY
5967	033244	105762	000000		2\$:	TSTB	RKCS1(R2)	
5968	033250	100402				BMI	3\$	
5969	033252	005300				DEC	R0	
5970	033254	001373				BNE	2\$	
5971	033256	016237	000000	004120	3\$:	MOV	RKCS1(R2), T.CS1	:: STORE COMMAND AND STATUS REG 1
5972	033264	016237	000010	004130		MOV	RKCS2(R2), T.CS2	:: STORE COMMAND AND STATUS REG 2
5973	033272	016237	000012	004132		MOV	RKDS(R2), T.DS	:: STORE DRIVE STATUS REG
5974	033300	016237	000014	004134		MOV	RKER(R2), T.ER	:: STORE ERROR REG
5975	033306	012737	110210	004160		MOV	#CERR!CFMT!RDY!SRTSPL!CFMT<C<GO>>, E.CS1	:: LOAD EXPECTED CS1
5976	033314	012737	000100	004170		MOV	#IR, E.CS2	:: LOAD EXPECTED CS2
5977	033322	012737	100010	004172		MOV	#SVAL!ACLO, E.DS	:: LOAD EXPECTED DRIVE STATUS REG
5978	033330	012737	000010	004174		MOV	#DRPAR, E.ER	:: LOAD EXPECTED ERROR REG
5979	033336	023737	004160	004120		CMP	E.CS1, T.CS1	:: CHECK COMMAND AND STATUS REG.1 CORRECT
5980	033344	001401				BEQ	4\$	:: YES, CONTINUE
5981	033346	104214				ERROR	214	
5982	033350	023737	004170	004130	4\$:	CMP	E.CS2, T.CS2	:: CHECK COMMAND AND STATUS REG. 2 CORRECT
5983	033356	001401				BEQ	5\$	:: YES, CONTINUE
5984	033360	104215				ERROR	215	
5985	033362	023737	004172	004132	5\$:	CMP	E.DS, T.DS	:: CHECK DRIVE STATUS REG. CORRECT
5986	033370	001401				BEQ	6\$	:: YES, CONTINUE
5987	033372	104216				ERROR	216	
5988	033374	023737	004174	004134	6\$:	CMP	E.ER, T.ER	:: CHECK ERROR REGISTER CORRECT
5989	033402	001401				BEQ	7\$	:: YES, CLEAR RK611
5990	033404	104217				ERROR	217	
5991	033406	013737	004120	004220	7\$:	MOV	T.CS1, P.CS1	:: STORE PREVIOUS CONTENTS OF
5992	033414	013737	004130	004222		MOV	T.CS2, P.CS2	:: COMMAND AND STATUS REG 1
5993	033422	013737	004132	004224		MOV	T.DS, P.DS	:: COMMAND AND STATUS REG 2
5994	033430	013737	004134	004226		MOV	T.ER, P.ER	:: DRIVE STATUS REG
5995								:: AND ERROR REG
5996	033436	012762	100000	000000		MOV	#CCLR, RKCS1(R2)	:: CLEAR RK611
5997	033444	016237	000000	004120		MOV	RKCS1(R2), T.CS1	:: STORE COMMAND AND STATUS REG 1
5998	033452	016237	000010	004130		MOV	RKCS2(R2), T.CS2	:: STORE COMMAND AND STATUS REG 2
5999	033460	016237	000012	004132		MOV	RKDS(R2), T.DS	:: STORE DRIVE STATUS REG
6000	033466	016237	000014	004134		MOV	RKER(R2), T.ER	:: STORE ERROR REG
6001	033474	012737	000200	004160		MOV	#RDY, E.CS1	:: LOAD EXPECTED CS1
6002	033502	012737	000100	004170		MOV	#IR, E.CS2	:: LOAD EXPECTED CS2
6003	033510	005037	004172			CLR	E.DS	:: LOAD EXPECTED DRIVE STATUS REG
6004	033514	005037	004174			CLR	E.ER	:: LOAD EXPECTED ERROR REG
6005	033520	023737	004160	004120		CMP	E.CS1, T.CS1	:: CHECK COMMAND AND STATUS REG 1 CORRECT
6006	033526	001401				BEQ	11\$	:: YES, CHECK CS2
6007	033530	104224				ERROR	224	:: CS1 INCORRECT
6008	033532	023737	004170	004130	11\$:	CMP	E.CS2, T.CS2	:: CHECK COMMAND AND STATUS REG 2 CORRECT
6009	033540	001401				BEQ	12\$	:: YES, CHECK DRIVE STATUS REG
6010	033542	104225				ERROR	225	:: CS2 INCORRECT



```

6011 033544 023737 004172 004132 12$: CMP E.DS,T.DS ;CHECK IF DRIVE STATUS REG CORRECT
6012 033552 001401 BEQ 13$ ;YES CHECK ERROR REG
6013 033554 104226 ERROR 226 ;ERROR REG INCORRECT
6014 033556 023737 004174 004134 13$: CMP E.ER,T.ER ;CHECK IF ERROR REG CORRECT
6015 033564 001401 BEQ TST65 ;YES GO ON TO NEXT TEST
6016 033566 104227 ERROR 227 ;ERROR REG INCORRECT
6017
6018 ;*****
6019 ;*TEST 65 ILLEGAL DISK ADDRESS ERROR FROM SHIFT REG.
6020 ;*
6021 ;* CLEAR RK06 SUBSYSTEM WITH A SUBSYSTEM CLEAR. PUT
6022 ;* RK611 CONTROLLER IN DIAGNOSTIC MODE. ISSUE A RECALIBRATE
6023 ;* TO AN RK06 IN 26 SECTOR FORMAT CYLINDER 0 HEAD 1.
6024 ;* DRIVE 0. CLOCK IN DIAGNOSTIC MODE UNTIL PHASE
6025 ;* ADDRESS 6. TURN OFF DIAGNOSTIC MODE AND MAKE SURE
6026 ;* SPEED LOSS, ILLEGAL DISK ADDRESS ERROR, AND CONTROLLER
6027 ;* ERROR ARE SET WITH DRIVE AVAILABLE RESET.
6028 ;*
6029 ;*****
6030 033570 000004 ;*ST65: SCOPE
6031 033572 012737 000144 001200 MOV #100,$TIMES ;DO 100. ITERATIONS
6032 033600 013702 001270 MOV $BASE,R2 ;LOAD RK611 BASE
6033 033604 012762 000040 000010 MOV $SCLR,RKCS2(R2) ;CLEAR RK06 SUBSYSTEM
6034 033612 012762 000040 000026 MOV #DMD,RKMR1(R2) ;PUT RK611 IN MAINT MODE
6035 033620 012762 000000 000020 MOV #0,RKDCYL(R2) ;LOAD CYLINDER AND
6036 033626 012762 000400 000006 MOV #400,RKDA(R2) ;LOAD HEAD ADDRESS
6037 033634 012762 000013 000000 MOV #RECAL,RKCS1(R2) ;ISSUE RECAL
6038 033642 012700 000132 MOV #22,#4+2,R0 ;ISSUE CLOCKS UNTIL PHASE ADDRESS 6
6039 033646 012762 000440 000026 1$: MOV #DMD!MCLK,RKMR1(R2)
6040 033654 012762 000040 000026 MOV #DMD,RKMR1(R2)
6041 033662 005300 DEC R0
6042 033664 001370 BNE 1$
6043 033666 005062 000026 CLR RKMR1(R2) ;FINISH COMMAND IN NORMAL MODE
6044 033672 013700 004262 MOV WAITIM,R0 ;WAIT FOR READY
6045 033676 105762 000000 23: TSTB RKCS1(R2)
6046 033702 100402 BMI 3$
6047 033704 005300 DEC R0
6048 033706 001373 BNE 2$
6049 033710 016237 000000 004120 3$: MOV RKCS1(R2),T.CS1 ;STORE COMMAND AND STATUS REG 1
6050 033716 016237 000010 004130 MOV RKCS2(R2),T.CS2 ;STORE COMMAND AND STATUS REG 2
6051 033724 016237 000012 004132 MOV RKDS(R2),T.DS ;STORE DRIVE STATUS REG
6052 033732 016237 000014 004134 MOV RKER(R2),T.ER ;STORE ERROR REG
6053 033740 012737 100212 004160 MOV #CERR!RDY!RECAL&T.CS1 ;LOAD EXPECTED CS1
6054 033746 012737 000100 004170 MOV #IR,E.CS2 ;LOAD EXPECTED CS2
6055 033754 012737 100020 004172 MOV #SVAL!SPDLSS,E.DS ;LOAD EXPECTED DRIVE STATUS REG
6056 033762 012737 002000 004174 MOV #IDAE,E.ER ;LOAD EXPECTED ERROR REG
6057 033770 023737 004160 004120 CMP E.CS1,T.CS1 ;CHECK COMMAND AND STATUS REG.1 CORRECT
6058 033776 001401 BEQ 4$ ;YES, CONTINUE
6059 034000 104220 ERROR 220
6060 034002 023737 004170 004130 4$: CMP E.CS2,T.CS2 ;CHECK COMMAND AND STATUS REG. 2 CORRECT
6061 034010 001401 BEQ 5$ ;YES, CONTINUE
6062 034012 104221 ERROR 221
6063 034014 023737 004172 004132 5$: CMP E.DS,T.DS ;CHECK DRIVE STATUS REG. CORRECT
6064 034022 001401 BEQ 6$ ;YES, CONTINUE
6065 034024 104222 ERROR 222
6066 034026 023737 004174 004134 6$: CMP E.ER,T.ER ;CHECK ERROR REGISTER CORRECT

```

```

6067 034034 001401          BEQ      7$                ;YES, CLEAR RK611
6068 034036 104223          ERROR    223
6069 034040 013737 004120 004220 7$:  MOV     T.CS1,P.CS1        ;STORE PREVIOUS CONTENTS OF
6070 034046 013737 004130 004222  MOV     T.CS2,P.CS2        ;COMMAND AND STATUS REG 1
6071 034054 013737 004132 004224  MOV     T.DS,P.DS         ;COMMAND AND STATUS REG 2
6072 034062 013737 004134 004226  MOV     T.ER,P.ER         ;DRIVE STATUS REG
6073                                     ;AND ERROR REG
6074 034070 012762 100000 000000  MOV     #CCLR,RKCS1(R2)    ;CLEAR RK611
6075 034076 016237 000000 004120  MOV     RKCS1(R2),T.CS1    ;STORE COMMAND AND STATUS REG 1
6076 034104 016237 000010 004130  MOV     RKCS2(R2),T.CS2    ;STORE COMMAND AND STATUS REG 2
6077 034112 016237 000012 004132  MOV     RKDS(R2),T.DS     ;STORE DRIVE STATUS REG
6078 034120 016237 000014 004134  MOV     RKER(R2),T.ER     ;STORE ERROR REG
6079 034126 012737 000200 004160  MOV     #RDY,E.CS1        ;LOAD EXPECTED CS1
6080 034134 012737 000100 004170  MOV     #IR,E.CS2         ;LOAD EXPECTED CS2
6081 034142 005037 004172          CLR     E.DS              ;LOAD EXPECTED DRIVE STATUS REG
6082 034146 005037 004174          CLR     E.ER              ;LOAD EXPECTED ERROR REG
6083 034152 023737 004160 004120  CMP     E.CS1,T.CS1        ;CHECK COMMAND AND STATUS REG 1 CORRECT
6084 034160 001401          BEQ     11$                ;YES, CHECK CS2
6085 034162 104224          ERROR    224
6086 034164 023737 004170 004130 11$:  CMP     E.CS2,T.CS2        ;CHECK COMMAND AND STATUS REG 2 CORRECT
6087 034172 001401          BEQ     12$                ;YES, CHECK DRIVE STATUS REG
6088 034174 104225          ERROR    225
6089 034176 023737 004172 004132 12$:  CMP     E.DS,T.DS         ;CHECK IF DRIVE STATUS REG CORRECT
6090 034204 001401          BEQ     13$                ;YES, CHECK ERROR REG
6091 034206 104226          ERROR    226
6092 034210 023737 004174 004134 13$:  CMP     E.ER,T.ER         ;CHECK IF ERROR REG CORRECT
6093 034216 001401          BEQ     TST66              ;YES, GO ON TO NEXT TEST
6094 034220 104227          ERROR    227
6095
6096
6097
6098
6099
6100
6101
6102
6103
6104
6105
6106
6107
6108 034222 000004          †TST66: SCOPE
6109 034224 012737 000144 001200  MOV     #100,$TIMES      ;;DO 100. ITERATIONS
6110 034232 013702 001270          MOV     $BASE,R2        ;LOAD RK611 BASE
6111 034236 012762 000040 000010  MOV     #SCLR,RKCS2(R2) ;CLEAR RK06 SUBSYSTEM
6112 034244 012762 000040 000026  MOV     #DMD,RKMR1(R2)  ;PUT RK611 IN MAINTENANCE MODE
6113 034252 012762 001002 000020  MOV     #1002,RKDCYL(R2);LOAD CYLINDER ADDRESS
6114 034260 012737 001002 004252  MOV     #1002,CYLIN
6115 034266 012737 000000 004250  MOV     #0,HDCODE       ;LOAD HEAD ADDRESS
6116 034274 005046          CLR     -(SP)
6117 034276 113766 004250 000001  MOV     HDCODE,1(SP)
6118 034304 012662 000006          MOV     (SP)+,RKDA(R2)
6119 034310 012737 000006 004266  MOV     #6,DRVTYP       ;LOAD DRIVE TYPE FOR PRINT OUT
6120 034316 012762 000017 000000  MOV     #SEEK,RKCS1(R2) ;ISSUE SEEK TO RK06
6121 034324 012700 000132          MOV     #22,*4+2,R0     ;ISSUE CLOCK TO GET THROUGH PHASE 6
6122 034330 012762 000440 000026 1$:  MOV     #DMD!MCLK,RKMR1(R2)

```

```

*****
*TEST 66          IDAE DETECTION IN RK611 CONTROLLER (PART 1)
*
* CLEAR RK06 SUBSYSTEM WITH A SUBSYSTEM CLEAR. PUT
* RK611 CONTROLLER IN DIAGNOSTIC MODE. ISSUE A
* SEEK TO AN RK06 IN 26 SECTOR FORMAT, CYLINDER 1003.
* HEAD 0, DRIVE 0. CLOCK IN DIAGNOSTIC MODE UNTIL
* PHASE ADDRESS 6. TURN OFF DIAGNOSTIC MODE AND MAKE
* SURE DRIVE AVAILABLE, ILLEGAL DISK ADDRESS ERROR,
* AND CONTROLLER ERROR ARE SET.
*
*****

```

```

*****
†TST66: SCOPE
MOV     #100,$TIMES      ;;DO 100. ITERATIONS
MOV     $BASE,R2        ;LOAD RK611 BASE
MOV     #SCLR,RKCS2(R2) ;CLEAR RK06 SUBSYSTEM
MOV     #DMD,RKMR1(R2)  ;PUT RK611 IN MAINTENANCE MODE
MOV     #1002,RKDCYL(R2);LOAD CYLINDER ADDRESS
MOV     #1002,CYLIN
MOV     #0,HDCODE       ;LOAD HEAD ADDRESS
CLR     -(SP)
MOV     HDCODE,1(SP)
MOV     (SP)+,RKDA(R2)
MOV     #6,DRVTYP       ;LOAD DRIVE TYPE FOR PRINT OUT
MOV     #SEEK,RKCS1(R2) ;ISSUE SEEK TO RK06
MOV     #22,*4+2,R0     ;ISSUE CLOCK TO GET THROUGH PHASE 6
1$:  MOV     #DMD!MCLK,RKMR1(R2)

```

6123	034336	012762	000040	000026		MOV	#DMD,RKMR1(R2)	
6124	034344	005300				DEC	RO	
6125	034346	001370				BNE	1\$	
6126	034350	005062	000026			CLR	RKMR1(R2)	;ALLOW COMMAND TO FINISH
6127	034354	013700	004262			MOV	WAITIM,RO	;LOAD WAIT TIME
6128	034360	105762	000000		2\$:	TSTB	RKCS1(R2)	;WAIT FOR READY
6129	034364	100402				BMI	3\$	
6130	034366	005300				DEC	RO	
6131	034370	001373				BNE	2\$	
6132	034372	016237	000000	004120	3\$:	MOV	RKCS1(R2),T.CS1	;STORE COMMAND AND STATUS REG.1
6133	034400	016237	000010	004130		MOV	RKCS2(R2),T.CS2	;STORE COMMAND AND STATUS REG.2
6134	034406	016237	000012	004132		MOV	RKDS(R2),T.DS	;STORE DRIVE STATUS REG
6135	034414	016237	000014	004134		MOV	RKER(R2),T.ER	;STORE ERROR REG
6136	034422	012737	100216	004160		MOV	#CERR!RDY!<SEEK&T<GO>>,E.CS1	;LOAD EXPECTED CS1
6137								
6138	034430	012737	000100	004170		MOV	#IR,E.CS2	;LOAD EXPECTED COMMAND AND STATUS REG.2
6139	034436	012737	100001	004172		MOV	#SVAL!DRA,E.DS	;LOAD EXPECTED DRIVE STATUS REG
6140	034444	012737	002000	004174		MOV	#IDAE,E.ER	;LOAD EXPECTED ERROR REG
6141	034452	023737	004160	004120		CMP	E.CS1,T.CS1	;CHECK COMMAND AND STATUS REG1 CORRECT
6142	034460	001401				BEQ	4\$	;YES, CHECK CS2
6143	034462	104230				ERROR	230	;CS1 INCORRECT
6144	034464	023737	004170	004130	4\$:	CMP	E.CS2,T.CS2	;CHECK COMMAND AND STATUS REG2 CORRECT
6145	034472	001401				BEQ	5\$	;YES, CHECK DRIVE STATUS REG.
6146	034474	104231				ERROR	231	;CS2 INCORRECT
6147	034476	023737	004172	004132	5\$:	CMP	E.DS,T.DS	;CHECK DRIVE STATUS REG. CORRECT
6148	034504	001401				BEQ	6\$	;YES, CHECK ERROR REG
6149	034506	104232				ERROR	232	;DRIVE STATUS REG. INCORRECT
6150	034510	023737	004174	004134	6\$:	CMP	E.ER,T.ER	;CHECK ERROR REG. CORRECT
6151	034516	001401				BEQ	7\$	;YES, CHECK CONTROLLER CLEAR
6152	034520	104233				ERROR	233	;ERROR REG. INCORRECT
6153	034522	013737	004120	004220	7\$:	MOV	T.CS1,P.CS1	;STORE PREVIOUS VALUES OF
6154	034530	013737	004130	004222		MOV	T.CS2,P.CS2	COMMAND AND STATUS REG.1
6155	034536	013737	004132	004224		MOV	T.DS,P.DS	COMMAND AND STATUS REG.2
6156	034544	013737	004134	004226		MOV	T.ER,P.ER	DRIVE STATUS REG.
6157								ERROR REG.
6158	034552	012762	100000	000000		MOV	#CCLR,RKCS1(R2)	;ISSUE CONTROLLER CLEAR
6159	034560	016237	000000	004120		MOV	RKCS1(R2),T.CS1	;STORE COMMAND AND STATUS REG.1
6160	034566	016237	000010	004130		MOV	RKCS2(R2),T.CS2	;STORE COMMAND AND STATUS REG.2
6161	034574	016237	000012	004132		MOV	RKDS(R2),T.DS	;STORE DRIVE STATUS REG.
6162	034602	016237	000014	004134		MOV	RKER(R2),T.ER	;STORE ERROR REG
6163	034610	012737	000200	004160		MOV	#RDY,E.CS1	;LOAD EXPECTED CS1
6164	034616	012737	000100	004170		MOV	#IR,E.CS2	;LOAD EXPECTED CS2
6165	034624	005037	004172			CLR	E.DS	;LOAD EXPECTED DRIVE STATUS REG.
6166	034630	005037	004174			CLR	E.ER	;LOAD EXPECTED ERROR REG.
6167	034634	023737	004160	004120		CMP	E.CS1,T.CS1	;CHECK COMMAND AND STATUS REG.1 CORRECT
6168	034642	001401				BEQ	10\$	;YES, CHECK CS2
6169	034644	104224				ERROR	224	;CS1 INCORRECT
6170	034646	023737	004170	004130	10\$:	CMP	E.CS2,T.CS2	;CHECK COMMAND AND STATUS REG2 CORRECT
6171	034654	001401				BEQ	11\$	;YES, CHECK DRIVE STATUS REG
6172	034656	104225				ERROR	225	;CS2 INCORRECT
6173	034660	023737	004172	004132	11\$:	CMP	E.DS,T.DS	;CHECK DRIVE STATUS REG CORRECT
6174	034666	001401				BEQ	12\$	;YES, CHECK ERROR REGISTER
6175	034670	104226				ERROR	226	;DRIVE STATUS REG INCORRECT
6176	034672	023737	004174	004134	12\$:	CMP	E.ER,T.ER	;CHECK ERROR REG CORRECT
6177	034700	001401				BEQ	TST67	;YES, GO ON TO NEXT TEST
6178	034702	104227				ERROR	227	;ERROR REG. INCORRECT

```

6179
6180
6181
6182
6183
6184
6185
6186
6187
6188
6189
6190
6191
6192 034704 000004
6193 034706 012737 000144 001200
6194 034714 013702 001270
6195 034720 012762 000040 000010
6196 034726 012762 000040 000026
6197 034734 012762 001022 000020
6198 034742 012737 001022 004252
6199 034750 012737 000000 004250
6200 034756 005046
6201 034760 113766 004250 000001
6202 034766 012662 000006
6203 034772 012737 000007 004266
6204 035000 012762 002017 000000
6205 035006 012700 000132
6206 035012 012762 000440 000026 1$:
6207 035020 012762 000040 000026
6208 035026 005300
6209 035030 001370
6210 035032 005062 000026
6211 035036 013700 004262
6212 035042 105762 000000 2$:
6213 035046 100402
6214 035050 005300
6215 035052 001373
6216 035054 016237 000000 004120 3$:
6217 035062 016237 000010 004130
6218 035070 016237 000012 004132
6219 035076 016237 000014 004134
6220 035104 012737 002216 004160
6221
6222 035112 012737 000100 004170
6223 035120 012737 120401 004172
6224 035126 012737 000000 004174
6225 035134 023737 004160 004120
6226 035142 001401
6227 035144 104230
6228 035146 023737 004170 004130 4$:
6229 035154 001401
6230 035156 104231
6231 035160 023737 004172 004132 5$:
6232 035166 001401
6233 035170 104232
6234 035172 023737 004174 004134 6$:

```

```

*****
*TEST 67 IDAE DETECTION IN RK611 CONTROLLER (PART 2)
*
* CLEAR RK06 SUBSYSTEM WITH A SUBSYSTEM CLEAR. PUT
* RK611 CONTROLLER IN DIAGNOSTIC MODE. ISSUE A SEEK
* WITH CDT SET IN 26 SECTOR FORMAT, CYLINDER 1022, HEAD
* 0, DRIVE 0. CLOCK IN DIAGNOSTIC MODE UNTIL PHASE
* ADDRESS 6. TURN OFF DIAGNOSTIC MODE AND MAKE SURE
* DRIVE AVAILABLE AND POSITIONING IN PROGRESS ARE SET
* WITH ILLEGAL DISK ADDRESS ERROR RESET.
*****
TST67: SCOPE
MOV #100, $TIMES ;DO 100. ITERATIONS
MOV $BASE, R2 ;LOAD RK611 BASE
MOV #SCLR, RKCS2(R2) ;CLEAR RK06 SUBSYSTEM
MOV #DMD, RKMR1(R2) ;PUT RK611 IN MAINTENANCE MODE
MOV #1022, RKDCYL(R2) ;LOAD CYLINDER ADDRESS
MOV #1022, CYLIN
MOV #0, HOCODE ;LOAD HEAD ADDRESS
CLR -(SP)
MOVB HOCODE, 1(SP)
MOV (SP)+, RKDR(R2)
MOV #7, DRVTYP ;LOAD DRIVE TYPE FOR PRINT OUT
MOV #CDT!SEEK, RKCS1(R2) ;ISSUE SEEK TO RK06
MOV #22, #4+2, RD ;ISSUE CLOCK TO GET THROUGH PHASE 6
MOV #DMD!MCLK, RKMR1(R2)
MOV #DMD, RKMR1(R2)
DEC RD
BNE 1$
CLR RKMR1(R2) ;ALLOW COMMAND TO FINISH
MOV WAITIM, RD ;LOAD WAIT TIME
TSTB RKCS1(R2) ;WAIT FOR READY
BMI 3$
DEC RD
BNE 2$
MOV RKCS1(R2), T.CS1 ;STORE COMMAND AND STATUS REG.1
MOV RKCS2(R2), T.CS2 ;STORE COMMAND AND STATUS REG.2
MOV RKDS(R2), T.DS ;STORE DRIVE STATUS REG
MOV RKER(R2), T.ER ;STORE ERROR REG
MOV #CDT!RDY!<SEEK&+C<GO>>, E.CS1 ;LOAD EXPECTED CS1
MOV #IR, E.CS2 ;LOAD EXPECTED COMMAND AND STATUS REG.2
MOV #SVAL!DRA!PIP!DDT, E.DS ;LOAD EXPECTED DRIVE STATUS REG
MOV #0, E.ER ;LOAD EXPECTED ERROR REG
CMP E.CS1, T.CS1 ;CHECK COMMAND AND STATUS REG1 CORRECT
BEQ 4$ ;YES, CHECK CS2
ERROR 230 ;CS1 INCORRECT
CMP E.CS2, T.CS2 ;CHECK COMMAND AND STATUS REG2 CORRECT
BEQ 5$ ;YES, CHECK DRIVE STATUS REG.
ERROR 231 ;CS2 INCORRECT
CMP E.DS, T.DS ;CHECK DRIVE STATUS REG. CORRECT
BEQ 6$ ;YES, CHECK ERROR REG
ERROR 232 ;DRIVE STATUS REG. INCORRECT
CMP E.ER, T.ER ;CHECK ERROR REG. CORRECT

```

6235	035200	001401				BEQ	7\$		;YES, CHECK CONTROLLER CLEAR
6236	035202	104233				ERROR	233		;ERROR REG. INCORRECT
6237	035204	013737	004120	004220	7\$:	MOV	T.CS1,P.CS1		;STORE PREVIOUS VALUES OF
6238	035212	013737	004130	004222		MOV	T.CS2,P.CS2		;COMMAND AND STATUS REG.1
6239	035220	013737	004132	004224		MOV	T.DS,P.DS		;COMMAND AND STATUS REG.2
6240	035226	013737	004134	004226		MOV	T.ER,P.ER		;DRIVE STATUS REG.
6241									;ERROR REG.
6242	035234	012762	100000	000000		MOV	#CCLR,RKCS1(R2)		;ISSUE CONTROLLER CLEAR
6243	035242	016237	000000	004120		MOV	RKCS1(R2),T.CS1		;STORE COMMAND AND STATUS REG.1
6244	035250	016237	000010	004130		MOV	RKCS2(R2),T.CS2		;STORE COMMAND AND STATUS REG.2
6245	035256	016237	000012	004132		MOV	RKDS(R2),T.DS		;STORE DRIVE STATUS REG.
6246	035264	016237	000014	004134		MOV	RKER(R2),T.ER		;STORE ERROR REG
6247	035272	012737	000200	004160		MOV	#RDY,E.CS1		;LOAD EXPECTED CS1
6248	035300	012737	000100	004170		MOV	#IR,E.CS2		;LOAD EXPECTED CS2
6249	035306	005037	004172			CLR	E.DS		;LOAD EXPECTED DRIVE STATUS REG.
6250	035312	005037	004174			CLR	E.ER		;LOAD EXPECTED ERROR REG.
6251	035316	023737	004160	004120		CMP	E.CS1,T.CS1		;CHECK COMMAND AND STATUS REG.1 CORRECT
6252	035324	001401				BEQ	10\$		;YES, CHECK CS2
6253	035326	104224				ERROR	224		;CS1 INCORRECT
6254	035330	023737	004170	004130	10\$:	CMP	E.CS2,T.CS2		;CHECK COMMAND AND STATUS REG2 CORRECT
6255	035336	001401				BEQ	11\$		;YES, CHECK DRIVE STATUS REG
6256	035340	104225				ERROR	225		;CS2 INCORRECT
6257	035342	023737	004172	004132	11\$:	CMP	E.DS,T.DS		;CHECK DRIVE STATUS REG CORRECT
6258	035350	001401				BEQ	12\$		;YES, CHECK ERROR REGISTER
6259	035352	104226				ERROR	226		;DRIVE STATUS REG INCORRECT
6260	035354	023737	004174	004134	12\$:	CMP	E.ER,T.ER		;CHECK ERROR REG CORRECT
6261	035362	001401				BEQ	TST70		;YES, GO ON TO NEXT TEST
6262	035364	104227				ERROR	227		;ERROR REG. INCORRECT

```

*****
*TEST 70 IDAE DETECTION IN RK611 CONTROLLER (PART 3)
*
* CLEAR RK06 SUBSYSTEM WITH A SUBSYSTEM CLEAR. PUT
* RK611 CONTROLLER IN DIAGNOSTIC MODE. ISSUE A SEEK
* TO AN RK06 IN 26 SECTOR FORMAT, CYLINDER 2,
* HEAD 3, DRIVE 0. CLOCK IN DIAGNOSTIC MODE UNTIL
* PHASE ADDRESS 6. TURN OFF DIAGNOSTIC MODE AND MAKE
* SURE DRIVE AVAILABLE, DRIVE OFF TRACK, SPEED LOSS,
* ILLEGAL DISK ADDRESS ERROR, AND CONTROLLER ERROR ARE
* SET.
*****

```

6277	035366	000004				TST70:	SCOPE		
6278	035370	012737	000144	001200		MOV	#100,\$TIMES		;DO 100. ITERATIONS
6279	035376	013702	001270			MOV	\$BASE,R2		;LOAD RK611 BASE
6280	035402	012762	000040	000010		MOV	#SCLR,RKCS2(R2)		;CLEAR RK06 SUBSYSTEM
6281	035410	012762	000040	000026		MOV	#DMD,RKMRI(R2)		;PUT RK611 IN MAINTENANCE MODE
6282	035416	012762	000002	000020		MOV	#2,RKDCYL(R2)		;LOAD CYLINDER ADDRESS
6283	035424	012737	000002	004252		MOV	#2,CYLIN		
6284	035432	012737	000003	004250		MOV	#3,HOCODE		;LOAD HEAD ADDRESS
6285	035440	005046				CLR	-(SP)		
6286	035442	113766	004250	000001		MOVB	HOCODE,1(SP)		
6287	035450	012662	000006			MOV	(SP)+,RKDA(R2)		
6288	035454	012737	000006	004266		MOV	#6,DRVTYP		;LOAD DRIVE TYPE FOR PRINT OUT
6289	035462	012762	000017	000000		MOV	#SEEK,RKCS1(R2)		;ISSUE SEEK TO RK06
6290	035470	012700	000132			MOV	#22,*4+2,R0		;ISSUE CLOCK TO GET THROUGH PHASE 6

6291	035474	012762	000440	000026	1\$:	MOV	#DMD:MCLK,RKMR1(R2)	
6292	035502	012762	000040	000026		MOV	#DMD,RKMR1(R2)	
6293	035510	005300				DEC	RD	
6294	035512	001370				BNE	1\$	
6295	035514	005062	000026			CLR	RKMR1(R2)	;ALLOW COMMAND TO FINISH
6296	035520	013700	004262			MOV	WAITIM,RO	;LOAD WAIT TIME
6297	035524	105762	000000		2\$:	TSTB	RKCS1(R2)	;WAIT FOR READY
6298	035530	100402				BMI	3\$	
6299	035532	005300				DEC	RD	
6300	035534	001373				BNE	2\$	
6301	035536	016237	000000	004120	3\$:	MOV	RKCS1(R2),T.CS1	;STORE COMMAND AND STATUS REG.1
6302	035544	016237	000010	004130		MOV	RKCS2(R2),T.CS2	;STORE COMMAND AND STATUS REG.2
6303	035552	016237	000012	004132		MOV	RKDS(R2),↑.DS	;STORE DRIVE STATUS REG
6304	035560	016237	000014	004134		MOV	RKER(R2),T.ER	;STORE ERROR REG
6305	035566	012737	100216	004160		MOV	#CERR:RDY!<SEEK&↑C<GO>>,E.CS1	;LOAD EXPECTED CS1
6306								
6307	035574	012737	000100	004170		MOV	#IR,E.CS2	;LOAD EXPECTED COMMAND AND STATUS REG.2
6308	035602	012737	100061	004172		MOV	#SVAL:DRA!DROT!SPDLSS,E.DS	;LOAD EXPECTED DRIVE STATUS REG
6309	035610	012737	002000	004174		MOV	#IDAE,E.ER	;LOAD EXPECTED ERROR REG
6310	035616	023737	004160	004120		CMP	E.CS1,T.CS1	;CHECK COMMAND AND STATUS REG1 CORRECT
6311	035624	001401				BEQ	4\$	;YES,CHECK CS2
6312	035626	104230				ERROR	230	;CS1 INCORRECT
6313	035630	023737	004170	004130	4\$:	CMP	E.CS2,T.CS2	;CHECK COMMAND AND STATUS REG2 CORRECT
6314	035636	001401				BEQ	5\$	;YES,CHECK DRIVE STATUS REG.
6315	035640	104231				ERROR	231	;CS2 INCORRECT
6316	035642	023737	004172	004132	5\$:	CMP	E.DS,T.DS	;CHECK DRIVE STATUS REG. CORRECT
6317	035650	001401				BEQ	6\$	;YES,CHECK ERROR REG
6318	035652	104232				ERROR	232	;DRIVE STATUS REG. INCORRECT
6319	035654	023737	004174	004134	6\$:	CMP	E.ER,T.ER	;CHECK ERROR REG. CORRECT
6320	035662	001401				BEQ	7\$	;YES,CHECK CONTROLLER CLEAR
6321	035664	104233				ERROR	233	;ERROR REG. INCORRECT
6322	035666	013737	004120	004220	7\$:	MOV	T.CS1,P.CS1	;STORE PREVIOUS VALUES OF
6323	035674	013737	004130	004222		MOV	T.CS2,P.CS2	COMMAND AND STATUS REG.1
6324	035702	013737	004132	004224		MOV	T.DS,P.DS	COMMAND AND STATUS REG.2
6325	035710	013737	004134	004226		MOV	T.ER,P.ER	DRIVE STATUS REG.
6326								ERROR REG.
6327	035716	012762	100000	000000		MOV	#CLR,RKCS1(R2)	;ISSUE CONTROLLER CLEAR
6328	035724	016237	000000	004120		MOV	RKCS1(R2),T.CS1	;STORE COMMAND AND STATUS REG.1
6329	035732	016237	000010	004130		MOV	RKCS2(R2),T.CS2	;STORE COMMAND AND STATUS REG.2
6330	035740	016237	000012	004132		MOV	RKDS(R2),↑.DS	;STORE DRIVE STATUS REG.
6331	035746	016237	000014	004134		MOV	RKER(R2),T.ER	;STORE ERROR REG
6332	035754	012737	000200	004160		MOV	#RDY,E.CS1	;LOAD EXPECTED CS1
6333	035762	012737	000100	004170		MOV	#IR,E.CS2	;LOAD EXPECTED CS2
6334	035770	005037	004172			CLR	E.DS	;LOAD EXPECTED DRIVE STATUS REG.
6335	035774	005037	004174			CLR	E.ER	;LOAD EXPECTED ERROR REG.
6336	036000	023737	004160	004120		CMP	E.CS1,T.CS1	;CHECK COMMAND AND STATUS REG.1 CORRECT
6337	036006	001401				BEQ	10\$	;YES,CHECK CS2
6338	036010	104224				ERROR	224	;CS1 INCORRECT
6339	036012	023737	004170	004130	10\$:	CMP	E.CS2,T.CS2	;CHECK COMMAND AND STATUS REG2 CORRECT
6340	036020	001401				BEQ	11\$	;YES,CHECK DRIVE STATUS REG
6341	036022	104225				ERROR	225	;CS2 INCORRECT
6342	036024	023737	004172	004132	11\$:	CMP	E.DS,T.DS	;CHECK DRIVE STATUS REG CORRECT
6343	036032	001401				BEQ	12\$	;YES,CHECK ERROR REGISTER
6344	036034	104226				ERROR	226	;DRIVE STATUS REG INCORRECT
6345	036036	023737	004174	004134	12\$:	CMP	E.ER,T.ER	;CHECK ERROR REG CORRECT
6346	036044	001401				BEQ	TST71	;YES,GO ON TO NEXT TEST

6347 036046 104227

ERROR 227 ;ERROR REG. INCORRECT

6348  
6349  
6350  
6351  
6352  
6353  
6354  
6355  
6356  
6357  
6358  
6359  
6360  
6361  
6362  
6363  
6364  
6365  
6366  
6367  
6368  
6369  
6370  
6371  
6372  
6373  
6374  
6375  
6376  
6377  
6378  
6379  
6380  
6381  
6382  
6383  
6384  
6385  
6386  
6387  
6388  
6389  
6390  
6391  
6392  
6393  
6394  
6395  
6396  
6397  
6398  
6399  
6400  
6401  
6402

036050 000004  
036052 012737 000144 001200  
036060 013702 001270  
036064 012762 000040 000010  
036072 012762 000040 000026  
036100 012762 000003 000020  
036106 012737 000003 004252  
036114 012737 000004 004250  
036122 005046  
036124 113766 004250 000001  
036132 012662 000006  
036136 012737 000006 004266  
036144 012762 000017 000000  
036152 012700 000132  
036156 012762 000440 000026 15:  
036164 012762 000040 000026  
036172 005300  
036174 001370  
036176 005062 000026  
036202 013700 004262  
036206 105762 000000 25:  
036212 100402  
036214 005300  
036216 001373  
036220 016237 000000 004120 35:  
036226 016237 000010 004130  
036234 016237 000012 004132  
036242 016237 000014 004134  
036250 012737 100216 004160  
036256 012737 000100 004170  
036264 012737 100001 004172  
036272 012737 042000 004174  
036300 023737 004160 004120  
036306 001401  
036310 104230  
036312 023737 004170 004130 45:  
036320 001401  
036322 104231  
036324 023737 004172 004132 55:  
036332 001401  
036334 104232

\*\*\*\*\*  
\*TEST 71 IDAE DETECTION IN RK611 CONTROLLER (PART 4)  
\*  
\* CLEAR RK06 SUBSYSTEM WITH A SUBSYSTEM CLEAR. PUT  
\* RK611 CONTROLLER IN DIAGNOSTIC MODE. ISSUE A SEEK  
\* TO AN RK06 IN 26 SECTOR FORMAT, CYLINDER 3, HEAD  
\* 4, DRIVE 0. CLOCK IN DIAGNOSTIC MODE UNTIL PHASE  
\* ADDRESS 6. TURN OFF DIAGNOSTIC MODE AND MAKE SURE  
\* DRIVE AVAILABLE, UNSAFE, ILLEGAL DISK ADDRESS ERROR  
\* AND CONTROLLER ERROR ARE SET.  
\*\*\*\*\*

TST71: SCOPE  
MOV #100, \$TIMES ;DO 100. ITERATIONS  
MOV \$BASE, R2 ;LOAD RK611 BASE  
MOV #SCLR, RKCS2(R2) ;CLEAR RK06 SUBSYSTEM  
MOV #DMD, RKMR1(R2) ;PUT RK611 IN MAINTENANCE MODE  
MOV #3, RKDCYL(R2) ;LOAD CYLINDER ADDRESS  
MOV #3, CYLIN  
MOV #4, HDCODE ;LOAD HEAD ADDRESS  
CLR -(SP)  
MOVB HDCODE, 1(SP)  
MOV (SP)+, RKDA(R2)  
MOV #6, DRVTYP ;LOAD DRIVE TYPE FOR PRINT OUT  
MOV #SEEK, RKCS1(R2) ;ISSUE SEEK TO RK06  
MOV #22, \*4+2, R0 ;ISSUE CLOCK TO GET THROUGH PHASE 6  
15: MOV #DMD!MCLK, RKMR1(R2)  
MOV #DMD, RKMR1(R2)  
DEC R0  
BNE 15  
CLR RKMR1(R2) ;ALLOW COMMAND TO FINISH  
MOV WAITIM, R0 ;LOAD WAIT TIME  
25: TSTB RKCS1(R2) ;WAIT FOR READY  
BMI 35  
DEC R0  
BNE 25  
35: MOV RKCS1(R2), T.CS1 ;STORE COMMAND AND STATUS REG.1  
MOV RKCS2(R2), T.CS2 ;STORE COMMAND AND STATUS REG.2  
MOV RKDS(R2), T.DS ;STORE DRIVE STATUS REG  
MOV RKER(R2), T.ER ;STORE ERROR REG  
MOV #CERR!RDY!<SEEK&T<GO>>, E.CS1 ;LOAD EXPECTED CS1  
MOV #IR, E.CS2 ;LOAD EXPECTED COMMAND AND STATUS REG 2  
MOV #SVAL!DRA, E.DS ;LOAD EXPECTED DRIVE STATUS REG  
MOV #UNS!IDAE, E.ER ;LOAD EXPECTED ERROR REG  
CMP E.CS1, T.CS1 ;CHECK COMMAND AND STATUS REG1 CORRECT  
BEQ 45 ;YES, CHECK CS2  
EPROR 230 ;CS1 INCORRECT  
45: CMP E.CS2, T.CS2 ;CHECK COMMAND AND STATUS REG2 CORRECT  
BEQ 55 ;YES, CHECK DRIVE STATUS REG.  
ERROR 231 ;CS2 INCORRECT  
55: CMP E.DS, T.DS ;CHECK DRIVE STATUS REG. CORRECT  
BEQ 65 ;YES, CHECK ERROR REG  
ERROR 232 ;DRIVE STATUS REG. INCORRECT

6403	036336	023737	004174	004134	6S:	CMP	E.ER,T.ER	:CHECK ERROR REG. CORRECT
6404	036344	001401				BEQ	7S	:YES, CHECK CONTROLLER CLEAR
6405	036346	104233				ERROR	233	:ERROR REG. INCORRECT
6406	036350	013737	004120	004220	7S:	MOV	T.CS1,P.CS1	:STORE PREVIOUS VALUES OF
6407	036356	013737	004130	004222		MOV	T.CS2,P.CS2	:COMMAND AND STATUS REG.1
6408	036364	013737	004132	004224		MOV	T.DS,P.DS	:COMMAND AND STATUS REG.2
6409	036372	013737	004134	004226		MOV	T.ER,P.ER	:DRIVE STATUS REG.
6410								:ERROR REG.
6411	036400	012762	100000	000000		MOV	#CCLR,RKCS1(R2)	:ISSUE CONTROLLER CLEAR
6412	036406	016237	000000	004120		MOV	RKCS1(R2),T.CS1	:STORE COMMAND AND STATUS REG.1
6413	036414	016237	000010	004130		MOV	RKCS2(R2),T.CS2	:STORE COMMAND AND STATUS REG.2
6414	036422	016237	000012	004132		MOV	RKDS(R2),T.DS	:STORE DRIVE STATUS REG.
6415	036430	016237	000014	004134		MOV	RKER(R2),T.ER	:STORE ERROR REG
6416	036436	012737	000200	004160		MOV	#ROY,E.CS1	:LOAD EXPECTED CS1
6417	036444	012737	000100	004170		MOV	#IR,E.CS2	:LOAD EXPECTED CS2
6418	036452	005037	004172			CLR	E.DS	:LOAD EXPECTED DRIVE STATUS REG.
6419	036456	005037	004174			CLR	E.ER	:LOAD EXPECTED ERROR REG.
6420	036462	023737	004160	004120		CMP	E.CS1,T.CS1	:CHECK COMMAND AND STATUS REG.1 CORRECT
6421	036470	001401				BEQ	10S	:YES, CHECK CS2
6422	036472	104224				ERROR	224	:CS1 INCORRECT
6423	036474	023737	004170	004130	10S:	CMP	F.CS2,T.CS2	:CHECK COMMAND AND STATUS REG2 CORRECT
6424	036502	001401				BEQ	11S	:YES, CHECK DRIVE STATUS REG
6425	036504	104225				ERROR	225	:CS2 INCORRECT
6426	036506	023737	004172	004132	11S:	CMP	E.DS,T.DS	:CHECK DRIVE STATUS REG CORRECT
6427	036514	001401				BEQ	12S	:YES, CHECK ERROR REGISTER
6428	036516	104226				ERROR	226	:DRIVE STATUS REG INCORRECT
6429	036520	023737	004174	004134	12S:	CMP	E.ER,T.ER	:CHECK ERROR REG CORRECT
6430	036526	001401				BEQ	TCT72	:YES GO ON TO NEXT TEST
6431	036530	104227				ERROR	227	:ERROR REG. INCORRECT

```

*****
*TEST 72      IDAE DETECTION IN RK611 CONTROLLER (PART 5)
*
*      CLEAR RK06 SUBSYSTEM WITH A SUBSYSTEM CLEAR.  PUT
*      RK611 CONTROLLER IN DIAGNOSTIC MODE.  ISSUE A SEEK
*      WITH COT SET IN 26 SECTOR FORMAT, CYLINDER 23, HEAD 5,
*      DRIVE 0.  CLOCK IN DIAGNOSTIC MODE UNTIL PHASE ADDRESS
*      6.  TURN OFF DIAGNOSTIC MODE AND MAKE SURE DRIVE
*      AVAILABLE, UNSAFE, SPEED LOSS, ILLEGAL DISK ADDRESS
*      ERROR, AND CONTROLLER ERROR ARE SET.
*****

```

6445	036532	000004			TST72:	SCOPE		
6446	036534	012737	000144	001200		MOV	#100,\$TIMES	:DO 100. ITERATIONS
6447	036542	013702	001270			MOV	\$BASE,R2	:LOAD RK611 BASE
6448	036546	012762	000040	000010		MOV	#SCLR,RKCS2(R2)	:CLEAR RK06 SUBSYSTEM
6449	036554	012762	000040	000326		MOV	#DMD,RKMR1(R2)	:PUT RK611 IN MAINTENANCE MODE
6450	036562	012762	000023	000020		MOV	#23,RKDCYL(R2)	:LOAD CYLINDER ADDRESS
6451	036570	012737	000023	004252		MOV	#23,CYLIN	
6452	036576	012737	000005	004250		MOV	#5,HDCODE	:LOAD HEAD ADDRESS
6453	036604	005046				CLR	-(SP)	
6454	036606	113766	004250	000001		MOVB	HDCODE,1(SP)	
6455	036614	012662	000006			MOV	(SP)+,RKDA(R2)	
6456	036620	012737	000007	004266		MOV	#7,DRVTYP	:LOAD DRIVE TYPE FOR PRINT OUT
6457	036626	012762	002017	000000		MOV	#COT!SEEK,RKCS1(R2)	:ISSUE SEEK TO RK06
6458	036634	012700	000132			MOV	#22,*4+2,R0	:ISSUE CLOCK TO GET THROUGH PHASE 6



6459	036640	012762	000440	000026	1\$:	MOV	#DMD!MCLK,RKMR1(R2)	
6460	036646	012762	000040	000026		MOV	#DMD,RKMR1(R2)	
6461	036654	005300				DEC	RO	
6462	036656	001370				BNE	1\$	
6463	036660	005062	000026			CLR	RKMR1(R2)	;ALLOW COMMAND TO FINISH
6464	036664	013700	004262			MOV	WAITIM,RO	;LOAD WAIT TIME
6465	036670	105762	000000		2\$:	TSTB	RKCS1(R2)	;WAIT FOR READY
6466	036674	100402				BMI	3\$	
6467	036676	005300				DEC	RO	
6468	036700	001373				BNE	2\$	
6469	036702	016237	000000	004120	3\$:	MOV	RKCS1(R2),T.CS1	;STORE COMMAND AND STATUS REG.1
6470	036710	016237	000010	004130		MOV	RKCS2(R2),T.CS2	;STORE COMMAND AND STATUS REG.2
6471	036716	016237	000012	004132		MOV	RKDS(R2),T.DS	;STORE DRIVE STATUS REG
6472	036724	016237	000014	004134		MOV	RKER(R2),T.ER	;STORE ERROR REG
6473	036732	012737	102216	004160		MOV	#CERR!CDT!RDY!<SEEK&+C<GO>>,E.CS1	;LOAD EXPECTED CS1
6474								
6475	036740	012737	000100	004170		MOV	#IR E.CS2	;LOAD EXPECTED COMMAND AND STATUS REG.2
6476	036746	012737	100421	004172		MOV	#SVAL!DRA!SPDLSS	DDT E.DS ;LOAD EXPECTED DRIVE STATUS REG
6477	036754	012737	042000	004174		MOV	#UNS!IDAE E.ER	;LOAD EXPECTED ERROR REG
6478	036762	023737	004160	004120		CMP	E.CS1,T.CS1	;CHECK COMMAND AND STATUS REG1 CORRECT
6479	036770	001401				BEQ	4\$	;YES, CHECK CS2
6480	036772	104230				ERROR	230	;CS1 INCORRECT
6481	036774	023737	004170	004130	4\$:	CMP	E.CS2,T.CS2	;CHECK COMMAND AND STATUS REG2 CORRECT
6482	037002	001401				BEQ	5\$	;YES, CHECK DRIVE STATUS REG.
6483	037004	104231				ERROR	231	;CS2 INCORRECT
6484	037006	023737	004172	004132	5\$:	CMP	E.DS,T.DS	;CHECK DRIVE STATUS REG. CORRECT
6485	037014	001401				BEQ	6\$	;YES, CHECK ERROR REG
6486	037016	104232				ERROR	232	;DRIVE STATUS REG. INCORRECT
6487	037020	023737	004174	004134	6\$:	CMP	E.ER,T.ER	;CHECK ERROR REG. CORRECT
6488	037026	001401				BEQ	7\$	;YES, CHECK CONTROLLER CLEAR
6489	037030	104233				ERROR	233	;ERROR REG. INCORRECT
6490	037032	013737	004120	004220	7\$:	MOV	T.CS1,P.CS1	;STORE PREVIOUS VALUES OF
6491	037040	013737	004130	004222		MOV	T.CS2,P.CS2	COMMAND AND STATUS REG.1
6492	037046	013737	004132	004224		MOV	T.DS,P.DS	COMMAND AND STATUS REG.2
6493	037054	013737	004134	004226		MOV	T.ER,P.ER	DRIVE STATUS REG.
6494								ERROR REG.
6495	037062	012762	100000	000000		MOV	#CLR,RKCS1(R2)	;ISSUE CONTROLLER CLEAR
6496	037070	016237	000000	004120		MOV	RKCS1(R2),T.CS1	;STORE COMMAND AND STATUS REG 1
6497	037076	016237	000010	004130		MOV	RKCS2(R2),T.CS2	;STORE COMMAND AND STATUS REG.2
6498	037104	016237	000012	004132		MOV	RKDS(R2),T.DS	;STORE DRIVE STATUS REG.
6499	037112	016237	000014	004134		MOV	RKER(R2),T.ER	;STORE ERROR REG
6500	037120	012737	000200	004160		MOV	#RDY,E.CS1	;LOAD EXPECTED CS1
6501	037126	012737	000100	004170		MOV	#IR E.CS2	;LOAD EXPECTED CS2
6502	037134	005037	004172			CLR	E.DS	;LOAD EXPECTED DRIVE STATUS REG.
6503	037140	005037	004174			CLR	E.ER	;LOAD EXPECTED ERROR REG.
6504	037144	023737	004160	004120		CMP	E.CS1,T.CS1	;CHECK COMMAND AND STATUS REG.1 CORRECT
6505	037152	001401				BEQ	10\$	;YES, CHECK CS2
6506	037154	104224				ERROR	224	;CS1 INCORRECT
6507	037156	023737	004170	004130	10\$:	CMP	E.CS2,T.CS2	;CHECK COMMAND AND STATUS REG2 CORRECT
6508	037164	001401				BEQ	11\$	;YES, CHECK DRIVE STATUS REG
6509	037166	104225				ERROR	225	;CS2 INCORRECT
6510	037170	023737	004172	004132	11\$:	CMP	E.DS,T.DS	;CHECK DRIVE STATUS REG CORRECT
6511	037176	001401				BEQ	12\$	;YES, CHECK ERROR REGISTER
6512	037200	104226				ERROR	226	;DRIVE STATUS REG INCORRECT
6513	037202	023737	004174	004134	12\$:	CMP	E.ER,T.ER	;CHECK ERROR REG CORRECT
6514	037210	001401				BEQ	TS'73	;YES,GO ON TO NEXT TEST

E10

CZR6BC0 RK611 DSKLS CTRL PRT2  
CZR6BC.P11 02-DEC-77 09:22

MACY11 30(1046) 02-DEC-77 09:31 PAGE 121  
T72 IDAE DETECTION IN RK611 CONTROLLER (PART 5)

SEQ 0121

6515 037212 104227

ERROR 227 ;ERROR REG. INCORRECT

6516  
6517  
6518  
6519  
6520  
6521  
6522  
6523  
6524  
6525  
6526  
6527  
6528  
6529  
6530  
6531  
6532  
6533  
6534  
6535  
6536  
6537  
6538  
6539  
6540  
6541  
6542  
6543  
6544  
6545  
6546  
6547  
6548  
6549  
6550  
6551  
6552  
6553  
6554  
6555  
6556  
6557  
6558  
6559  
6560  
6561  
6562  
6563  
6564  
6565  
6566  
6567  
6568  
6569  
6570

037214 C00004  
037216 012737 000144 001200  
037224 013702 001270  
037230 012762 000040 000010  
037232 012762 000040 000026  
037244 012762 000023 000020  
037252 012737 000023 004252  
037260 012737 000006 004250  
037266 005046  
037270 113766 004250 000001  
037276 012662 000006  
037302 012737 000007 004266  
037310 012762 002017 000000  
037316 012700 000132  
037322 012762 000440 000026 1\$:  
037330 012762 000040 000026  
037336 005300  
037340 01370  
037342 005062 000026  
037346 013700 004262  
037352 105762 000000 2\$:  
037356 100402  
037360 005300  
037362 001373  
037364 016237 000000 004120 3\$:  
037372 016237 000010 004130  
037400 016237 000012 004132  
037406 016237 000014 004134  
037414 012737 102216 004160  
037422 012737 000100 004170  
037430 012737 100441 004172  
037436 012737 042000 004174  
037444 023737 004160 004120  
037452 001401  
037454 104230  
037456 023737 004170 004130 4\$:  
037464 001401  
037466 104231  
037470 023737 004172 004132 5\$:  
037476 001401  
037500 104232

\*\*\*\*\*  
TEST 73 IDAE DETECTION IN RK611 CONTROLLER (PART 6)  
\*\*\*\*\*  
CLEAR RK06 SUBSYSTEM WITH A SUBSYSTEM CLEAR. PUT  
RK611 CONTROLLER IN DIAGNOSTIC MODE. ISSUE A SEEK  
WITH CDT SET IN 26 SECTOR FORMAT, CYLINDER 23, HEAD 6,  
DRIVE 0. CLOCK IN DIAGNOSTIC MODE UNTIL PHASE ADDRESS  
6. TURN OFF DIAGNOSTIC MODE AND MAKE SURE DRIVE  
AVAILABLE, UNSAFE, DRIVE OFF TRACK, ILLEGAL  
DISK ADDRESS ERROR, AND CONTROLLER CLEAR ARE SET.  
\*\*\*\*\*

ST73: SCOPE  
MOV #100, \$TIMES ;DO 100. ITERATIONS  
MOV \$BASE, R2 ;LOAD RK611 BASE  
MOV #SCLR, RKCS2(R2) ;CLEAR RK06 SUBSYSTEM  
MOV #DMD, RKMR1(R2) ;PUT RK611 IN MAINTENANCE MODE  
MOV #23, RKDCYL(R2) ;LOAD CYLINDER ADDRESS  
MOV #23, CYLIN  
MOV #F, HDPCODE ;LOAD HEAD ADDRESS  
CLR -(SP)  
MOV B HDPCODE, 1(SP)  
MOV (SP)+, RKDA(R2)  
MOV #7, DRVTYP ;LOAD DRIVE TYPE FOR PRINT OUT  
MOV #CDT!SEEK, RKCS1(R2) ;ISSUE SEEK TO RK06  
MOV #22, \*4+2, RD ;ISSUE CLOCK TO GET THROUGH PHASE 6  
MOV #DMD!MCLK, RKMR1(R2)  
MOV #DMD, RKMR1(R2)  
DEC RD  
BNE 1\$  
CLR RKMR1(R2) ;ALLOW COMMAND TO FINISH  
MOV WAITIM, RD ;LOAD WAIT TIME  
TSTB RKCS1(R2) ;WAIT FOR READY  
BMI 3\$  
DEC RD  
BNE 2\$  
MOV RKCS1(R2), T.CS1 ;STORE COMMAND AND STATUS REG.1  
MOV RKCS2(R2), T.CS2 ;STORE COMMAND AND STATUS REG.2  
MOV RKDS(R2), T.DS ;STORE DRIVE STATUS REG  
MOV RKER(R2), T.ER ;STORE ERROR REG  
MOV #CERR!CDT!RDY!<SEEK&+C<GO>>, E.CS1 ;LOAD EXPECTED CS1  
MOV #IR, E.CS2 ;LOAD EXPECTED COMMAND AND STATUS REG.2  
MOV #SVAL!DRA!DROT!DOT, E.DS ;LOAD EXPECTED DRIVE STATUS REG  
MOV #UNS!IDAE, E.ER ;LOAD EXPECTED ERROR REG  
CMP E.CS1, T.CS1 ;CHECK COMMAND AND STATUS REG1 CORRECT  
BEQ 4\$ ;YES, CHECK CS2  
ERROR 230 ;CS1 INCORRECT  
CMP E.CS2, T.CS2 ;CHECK COMMAND AND STATUS REG2 CORRECT  
BEQ 5\$ ;YES, CHECK DRIVE STATUS REG.  
ERROR 231 ;CS2 INCORRECT  
CMP E.DS, T.DS ;CHECK DRIVE STATUS REG. CORRECT  
BEQ 6\$ ;YES, CHECK ERROR REG  
ERROR 232 ;DRIVE STATUS REG. INCORRECT

```

6571 037502 023737 004174 004134 6$: CMP E.ER,T.ER ;CHECK ERROR REG. CORRECT
6572 037510 001401 004174 004134 BEQ 7$ ;YES, CHECK CONTROLER CLEAR
6573 037512 104233 004174 004134 ERROR 233 ;ERROR REG. INCORRECT
6574 037514 013737 004120 004220 7$: MOV T.CS1,P.CS1 ;STORE PREVIOUS VALUES OF
6575 037522 013737 004130 004222 MOV T.CS2,P.CS2 ;COMMAND AND STATUS REG.1
6576 037530 013737 004132 004224 MOV T.DS,P.DS ;COMMAND AND STATUS REG.2
6577 037536 013737 004134 004226 MOV T.ER,P.ER ;DRIVE STATUS REG.
6578 ;ERROR REG.
6579 037544 012762 100000 000000 MOV #CCLR,RKCS1(R2) ;ISSUE CONTROLLER CLEAR
6580 037552 016237 000000 004120 MOV RKCS1(R2),T.CS1 ;STORE COMMAND AND STATUS REG.1
6581 037560 016237 000010 004130 MOV RKCS2(R2),T.CS2 ;STORE COMMAND AND STATUS REG.2
6582 037566 016237 000012 004132 MOV RKDS(R2),T.DS ;STORE DRIVE STATUS REG.
6583 037574 016237 000014 004134 MOV RKER(R2),T.ER ;STORE ERROR REG
6584 037602 012737 000200 004160 MOV #RDY,E.CS1 ;LOAD EXPECTED CS1
6585 037610 012737 000100 004170 MOV #IR,E.CS2 ;LOAD EXPECTED CS2
6586 037616 005037 004172 CLR E.DS ;LOAD EXPECTED DRIVE STATUS REG.
6587 037622 005037 004174 CLR E.ER ;LOAD EXPECTED ERROR REG.
6588 037626 023737 004160 004120 CMP E.CS1,T.CS1 ;CHECK COMMAND AND STATUS REG.1 CORRECT
6589 037634 001401 004174 004130 BEQ 10$ ;YES, CHECK CS2
6590 037636 104224 004174 004130 ERROR 224 ;CS1 INCORRECT
6591 037640 023737 004170 004130 10$: CMP E.CS2,T.CS2 ;CHECK COMMAND AND STATUS REG2 CORRECT
6592 037646 001401 004174 004130 BEQ 11$ ;YES, CHECK DRIVE STATUS REG
6593 037650 104225 004174 004130 ERROR 225 ;CS2 INCORRECT
6594 037652 023737 004172 004132 11$: CMP E.DS,T.DS ;CHECK DRIVE STATUS REG CORRECT
6595 037660 001401 004174 004132 BEQ 12$ ;YES, CHECK ERROR REGISTER
6596 037662 104226 004174 004132 ERROR 226 ;DRIVE STATUS REG INCORRECT
6597 037664 023737 004174 004134 12$: CMP E.ER,T.ER ;CHECK ERROR REG CORRECT
6598 037672 001401 004174 004134 BEQ TST74 ;YES, GO ON TO NEXT TEST
6599 037674 104227 004174 004134 ERROR 227 ;ERROR REG. INCORRECT

```

```

6600
6601 *****
6602 *TEST 74 NON-STANDARD MESSAGE RECEIVING
6603 *
6604 * CLEAR RK06 SUBSYSTEM WITH A SUBSYSTEM CLEAR. PUT
6605 * RK611 CONTROLLER IN DIAGNOSTIC MODE. ISSUE A SEEK
6606 * WITH CDT SET IN 24 SECTOR FORMAT, CYLINDER 1757, HEAD 7,
6607 * DRIVE 1. CLOCK IN DIAGNOSTIC MODE UNTIL PHASE ADDRESS 6.
6608 * TURN OFF DIAGNOSTIC MODE AND MAKE SURE NO ERRORS SET
6609 * AND DRIVE STATUS IS NOT REPORTED. REPEAT FOR DRIVES
6610 * 2 AND 4.
6611 *
6612 *****

```

```

6613 037676 000004 TST74: SCOPE
6614 037700 012737 000144 001200 MOV #100,$TIMES ;DO 100. ITERATIONS
6615 037706 013702 001270 001200 MOV $BASE,R2 ;LOAD RK611 BASE
6616 037712 012737 000001 004244 MOV #1,DRVCOD ;LOAD INITIAL DRIVE CODE
6617 037720 012737 037726 001110 MOV #1$,SLPERR ;LOAD LOOP ON ERROR LOCATION FOR
6618 ; SUBTEST LOOP
6619
6620 037726 1$: MOV #SCLR,RKCS2(R2) ;CLEAR RK06 SUBSYSTEM
6621 037726 012762 000040 000010 MOV #DMD,RKMRI(R2) ;PUT RK611 IN MAINTENANCE MODE
6622 037734 012762 000040 000026 MOV #1757,RKDCYL(R2) ;LOAD CYLINDER ADDRESS REG
6623 037742 012762 001757 000020 MOV #3400,RKDA(R2) ;LOAD HEAD 7
6624 037750 012762 003400 000006 MOV DRVCOD,RKCS2(R2) ;LOAD DRIVE NUMBER
6625 037756 013762 004244 000010 MOV #CDT!SEEK,RKCS1(R2) ;ISSUE A SEEK WITH CDT SET
6626 037764 012762 002017 000000

```

G10

CZF6BCD RK611 DSKLS CTRL PRT2  
CZF6BC.P11 02-DEC-77 09:22

MACY11 30(1046) 02-DEC-77 09:31 PAGE 123  
T74 NON-STANDARD MESSAGE RECEIVING

SEQ 0123

6627	037772	012700	000132			MOV	#22, #4+2, R0	:ISSUE CLOCKS THROUGH PHASE 6
6628	037776	012762	000440	000026	2\$:	MOV	#DMD!MCLK, RKMR1(R2)	
6629	040004	012762	000040	000026		MOV	#DMD, RKMR1(R2)	
6630	040012	005300				DEC	R0	
6631	040014	001370				BNE	2\$	
6632	040016	005062	000026			CLR	RKMR1(R2)	:ALLOW COMMAND TO FINISH
6633	040022	013700	004262			MOV	WAITIM, R0	:LOAD WAIT TIME
6634	040026	105762	000000		3\$:	TSTB	RKCS1(R2)	:WAIT FOR READY
6635	040032	100402				BMI	4\$	
6636	040034	005300				DEC	R0	
6637	040036	001373				BNE	3\$	
6638	040040	016237	000000	004120	4\$:	MOV	RKCS1(R2), T.CS1	:STORE COMMAND AND STATUS REG.1
6639	040046	016237	000010	004130		MOV	RKCS2(R2), T.CS2	:STORE COMMAND AND STATUS REG.2
6640	040054	016237	000012	004132		MOV	RKDS(R2), T.DS	:STORE DRIVE STATUS REG.
6641	040062	016237	000014	004134		MOV	RKER(R2), T.ER	:STORE ERROR REG
6642	040070	012737	002216	004160		MOV	#CDT!RDY! <SEEK&T<GO>>, E.CS1	:LOAD EXPECTED CS1
6643	040076	013737	004244	004170		MOV	DRVCOD, E.CS2	:LOAD EXPECTED CS2
6644	040104	052737	000100	004170		BIS	#IR, E.CS2	
6645	040112	005037	004172			CLR	E.DS	:LOAD EXPECTED DRIVE STATUS REG.
6646	040116	005037	004174			CLR	E.ER	:LOAD EXPECTED ERROR REG.
6647	040122	023737	004160	004120		CMP	E.CS1, T.CS1	:CHECK COMMAND AND STATUS REG.1 CORRECT
6648	040130	001401				BEQ	5\$	:YES, CHECK CS2
6649	040132	104234				ERROR	234	:CS1 INCORRECT
6650	040134	023737	004170	004130	5\$:	CMP	E.CS2, T.CS2	:CHECK COMMAND AND STATUS REG.2 CORRECT
6651	040142	001401				BEQ	6\$	:YES, CHECK DRIVE STATUS REG.
6652	040144	104235				ERROR	235	:CS2 INCORRECT
6653	040146	023737	004172	004132	6\$:	CMP	E.DS, T.DS	:CHECK DRIVE STATUS REG CORRECT
6654	040154	001401				BEQ	7\$	:YES, CHECK ERROR REG
6655	040156	104236				ERROR	236	:DRIVE STATUS REG INCORRECT
6656	040160	023737	004174	004134	7\$:	CMP	E.ER, T.ER	:CHECK IF ERROR CORRECT
6657	040166	001401				BEQ	8\$	:YES, CHECK IF LOOP ON ERROR
6658	040170	104237				ERROR	237	:ERROR REG INCORRECT
6659	040172	104415			8\$:	SCOPE		:CHECK IF LOOP ON ERROR
6660	040174	006337	004244			ASL	DRVCOD	:GENERATE NEXT DRIVE COME
6661	040200	032737	000010	004244		BIT	#BIT3, DRVCOD	:CHECK IF FINISHED
6662	040206	001647				BEQ	1\$	:NO, TRY NEXT COME
6663								
6664								
6665								
6666								
6667								
6668								
6669								
6670								
6671								
6572								
6673								
6674								
6675	040210	000004				↑ST75: SCOPE		
6676	040212	012737	000144	001200		MOV	#100, \$TIMES	:DO 100. ITERATIONS
6677	040220	013702	001270			MOV	\$BASE, R2	:LOAD RK611 BASE
6678	040224	012762	000040	000010		MOV	#SCLR, RKCS2(R2)	:CLEAR RK06 SUBSYSTEM
6679	040232	012762	000040	000026		MOV	#DMD, RKMR1(R2)	:PUT RK611 IN MAINTENANCE MODE
6680	040240	012762	000002	000020		MOV	#2, RKDCYL(R2)	:LOAD CYLINDER ADDRESS REG
6681	040246	012762	000001	000010		MOV	#1, RKCS2(R2)	:LOAD DRIVE NUMBER 1
6682	040254	012762	000017	000000		MOV	#SEEK, RKCS1(R2)	:ISSUE SEEK

```

*****
*TEST 75 DRIVE BUS PARITY ON NON-STANDARD MESSAGE
*
* CLEAR THE RK06 SUBSYSTEM WITH A SUBSYSTEM CLEAR.
* PUT THE RK611 CONTROLLER IN DIAGNOSTIC MODE. ISSUE
* A SEEK TO AN RK06 IN 26 SECTOR FORMAT, CYLINDER 2,
* HEAD 0, DRIVE 1. CLOCK IN DIAGNOSTIC MODE UNTIL
* PHASE ADDRESS 6. TURN OFF DIAGNOSTIC MODE AND MAKE
* SURE DRIVE BUS PARITY ERROR AND CONTROLLER ERROR SETS.
*****

```

H10

CZR68C0 RK611 DSKLS CTRL PRT2  
CZR68C.P11 02-DEC-77 09:22

MACY11 30(1046)  
T75

02-DEC-77 09:31 PAGE 124  
DRIVE BUS PARITY ON NON-STANDARD MESSAGE

SEQ 0124

6683	040262	012700	000132			MOV	#22,*4+2,RO	:ISSUE CLOCKS THROUGH PHASE 6
6684	040266	012762	000440	000026	1\$:	MOV	#DMD:MCLK,RKMR1(R2)	
6685	040274	012762	000040	000026		MOV	#DMD,RKMR1(R2)	
6686	040302	005300				DEC	RO	
6687	040304	001370				BNE	1\$	
6688	040306	005062	000026			CLR	RKMR1(R2)	:ALLOW COMMAND TO FINISH
6689	040312	013700	004262			MOV	WAITIM,RO	:LOAD WAIT TIME
6690	040316	105762	000000		3\$:	TSTB	RKCS1(R2)	:WAIT FOR READY
6691	040322	100402				BMI	4\$	
6692	040324	005300				DEC	RO	
6693	040326	001373				BNE	3\$	
6694	040330	016237	000000	004120	4\$:	MOV	RKCS1(R2),T.CS1	:STORE COMMAND AND STATUS REG.1
6695	040336	016237	000010	004130		MOV	RKCS2(R2),T.CS2	:STORE COMMAND AND STATUS REG.2
6696	040344	016237	000012	004132		MOV	RKDS(R2),T.DS	:STORE DRIVE STATUS REG.
6697	040352	016237	000014	004134		MOV	RKER(R2),T.ER	:STORE ERROR REG.
6698	040360	012737	120216	004160		MOV	#CERR!SPAR!RDY!SEK&1C<GO>,E.CS1	:LOAD EXPECTED CS1
6699	040366	012737	000101	004170		MOV	#IR!1,E.CS2	:LOAD EXPECTED CS1
6700	040374	005037	004172			CLR	E.DS	:LOAD EXPECTED DRIVE STATUS REG.
6701	040400	005037	004174			CLR	E.ER	:LOAD EXPECTED ERROR REG.
6702	040404	023737	004160	004120		CMP	E.CS1,T.CS1	:CHECK COMMAND AND STATUS REG.1 CORRECT
6703	040412	001401				BEQ	5\$	:YES, CHECK CS2
6704	040414	104240				ERROR	240	:CS1 INCORRECT
6705	040416	023737	004170	004130	5\$:	CMP	E.CS2,T.CS2	:CHECK COMMAND AND STATUS REG.2 CORRECT
6706	040424	001401				BEQ	6\$	:YES, CHECK DRIVE STATUS REG
6707	040426	104241				ERROR	241	:CS2 INCORRECT
6708	040430	023737	004172	004132	6\$:	CMP	E.DS,T.DS	:CHECK DRIVE STATUS REG. CORRECT
6709	040436	001401				BEQ	7\$	:YES, CHECK ERROR REG.
6710	040440	104242				ERROR	242	:DRIVE STATUS REG. INCORRECT
6711	040442	023737	004174	004134	7\$:	CMP	E.ER,T.ER	:CHECK ERROR REG CORRECT
6712	040450	001401				BEQ	8\$	:YES, CLEAR RK611
6713	040452	104243				ERROR	243	:ERROR REG. INCORRECT
6714	040454	013737	004120	004220	8\$:	MOV	T.CS1,P.CS1	:STORE PREVIOUS CS1, CS2.
6715	040462	013737	004130	004222		MOV	T.CS2,P.CS2	:DRIVE STATUS REG.,
6716	040470	013737	004132	004224		MOV	T.DS,P.DS	:AND ERROR REG.
6717	040476	013737	004134	004226		MOV	T.ER,P.ER	
6718	040504	012762	100000	000000		MOV	#CCLR,RKCS1(R2)	:CLEAR RK611
6719	040512	016237	000000	004120		MOV	RKCS1(R2),T.CS1	:STORE COMMAND AND STATUS REG.1
6720	040520	016237	000010	004130		MOV	RKCS2(R2),T.CS2	:STORE COMMAND AND STATUS REG.2
6721	040526	016237	000012	004132		MOV	RKDS(R2),T.DS	:STORE DRIVE STATUS REG.
6722	040534	016237	000014	004134		MOV	RKER(R2),T.ER	:STORE ERROR REG.
6723	040542	012737	000200	004160		MOV	#RDY,E.CS1	:LOAD EXPECTED CS1
6724	040550	012737	000100	004170		MOV	#IR,E.CS2	:LOAD EXPECTED CS2
6725	040556	005037	004172			CLR	E.DS	:LOAD EXPECTED DRIVE STATUS REG.
6726	040562	005037	004174			CLR	E.ER	:LOAD EXPECTED ERROR REG.
6727	040566	023737	004160	004120		CMP	E.CS1,T.CS1	:CHECK COMMAND AND STATUS REG.1 CORRECT
6728	040574	001401				BEQ	10\$	:YES, CHECK CS2
6729	040576	104224				ERROR	224	:CS1 INCORRECT
6730	040600	023737	004170	004130	10\$:	CMP	E.CS2,T.CS2	:CHECK COMMAND AND STATUS REG.2 CORRECT
6731	040606	001401				BEQ	11\$	:YES, CHECK DRIVE STATUS REG
6732	040610	104225				ERROR	225	:CS2 INCORRECT
6733	040612	023737	004172	004132	11\$:	CMP	E.DS,T.DS	:CHECK DRIVE STATUS REG CORRECT
6734	040620	001401				BEQ	12\$	:YES, CHECK ERROR REG
6735	040622	104226				ERROR	226	:DRIVE STATUS REG. INCORRECT
6736	040624	023737	004174	004134	12\$:	CMP	E.ER,T.ER	:CHECK ERROR CORRECT
6737	040632	001401				BEQ	TST76	:YES, GO ON TO NEXT TEST
6738	040634	104227				ERROR	227	:ERROR REG INCORRECT

6739  
6740  
6741  
6742  
6743  
6744  
6745  
6746  
6747  
6748  
6749  
6750  
6751  
6752  
6753  
6754  
6755  
6756  
6757  
6758  
6759  
6760  
6761  
6762  
6763  
6764  
6765  
6766  
6767  
6768  
6769  
6770  
6771  
6772  
6773  
6774  
6775  
6776  
6777  
6778  
6779  
6780  
6781  
6782  
6783  
6784  
6785  
6786  
6787  
6788  
6789  
6790  
6791  
6792  
6793  
6794

040636 000004  
040640 012737 000144 001200  
040646 013702 001270  
040652 012762 000040 000010  
040660 012762 000040 000026  
040666 012762 000001 000000  
040674 012700 000124  
040700 012762 000440 000026  
040706 012762 000040 000026  
040714 005300  
040716 001370  
040720 005062 000026  
040724 013700 004262  
040730 105762 000000  
040734 100402  
040736 005300  
040740 001373  
040742 013700 004264  
040746 005300  
040750 001376  
040752 016237 000000 004120  
040760 016237 000010 004130  
040766 016237 000012 004132  
040774 016237 000014 004134  
041002 012737 100200 004160  
041010 032737 020000 004120  
041016 001403  
041020 052737 020000 004160  
041026 012737 010100 004170  
041034 012737 100000 004172  
041042 005037 004174  
041046 023737 004160 004120  
041054 001401  
041056 104244  
041060 023737 004170 004130  
041066 001401  
041070 104245  
041072 023737 004172 004132  
041100 001401  
041102 104246  
041104 023737 004174 004134  
041112 001401

```
*****  
*TEST 76 NON-EXISTENT DRIVE (DRIVE MESSAGE TIME OUT)  
*  
* CLEAR THE RK06 SUBSYSTEM WITH A SUBSYSTEM CLEAR.  
* PUT THE RK611 CONTROLLER IN DIAGNOSTIC MODE. ISSUE  
* A SELECT TO AN RK06 IN 26 SECTOR FORMAT, CYLINDER 0,  
* HEAD 0, DRIVE 0. CLOCK IN DIAGNOSTIC MODE UNTIL  
* PHASE ADDRESS 5. TURN OFF DIAGNOSTIC MODE  
* AND MAKE SURE NON-EXISTENT DRIVE AND CONTROLLER  
* ERROR ARE SET. THIS TEST CHECKS NON-EXISTENT DRIVE  
* DUE TO DRIVE MESSAGE TIME OUT.  
*****  
↑ST76: SCOPE  
MOV #100, $TIMES ; DO 100. ITERATIONS  
MOV $BASE, R2 ; LOAD RK611 BASE  
MOV #SCLR, RKCS2(R2) ; CLEAR RK06 SUBSYSTEM  
MOV #DMD, RKMR1(R2) ; PUT RK611 IN MAINTENANCE MODE  
MOV #SELDRV, RKCS1(R2) ; ISSUE SELECT DRIVE  
MOV #21, #4, R0 ; ISSUE CLOCKS THROUGH PHASE 4  
1$: MOV #DMD, MCLK, RKMR1(R2)  
MOV #DMD, RKMR1(R2)  
DEC R0  
BNE 1$  
CLR RKMR1(R2) ; ALLOW COMMAND TO FINISH  
MOV WAITIM, R0 ; LOAD WAIT TIME  
2$: TSTB RKCS1(R2) ; WAIT FOR READY  
BMI 3$  
DEC R0  
BNE 2$  
3$: MOV STALL, R0 ; STALL 100 USEC FOR MESSAGE TIME OUT  
4$: DEC R0  
BNE 4$  
MOV RKCS1(R2), T.CS1 ; STORE COMMAND AND STATUS REG.1  
MOV RKCS2(R2), T.CS2 ; STORE COMMAND AND STATUS REG.2  
MOV RKDS(R2), T.DS ; STORE DRIVE STATUS REG  
MOV RKR(R2), T.ER ; STORE ERROR REG  
MOV #CERR, RDY, E.CS1 ; LOAD EXPECTED CS1  
BIT #SPAR, T.CS1 ; CHECK FOR BUS PARITY ERROR  
5$: BEQ 5$  
BIS #SPAR, E.CS1 ; PUT BUS PARITY ERROR IN EXPECTED CS1  
MOV #NED, IR, E.CS2 ; LOAD EXPECTED CS2  
MOV #SVAL, E.DS ; LOAD EXPECTED DRIVE STATUS REG.  
CLR E.ER ; LOAD EXPECTED ERROR REG.  
CMP E.CS1, T.CS1 ; CHECK COMMAND AND STATUS REG.1 CORRECT  
BEQ 6$ ; YES, CHECK CS2  
6$: ERROR 244 ; CS1 INCORRECT  
CMP E.CS2, T.CS2 ; CHECK COMMAND AND STATUS REG.2 CORRECT  
BEQ 7$ ; YES, CHECK DRIVE STATUS REG  
7$: ERROR 245 ; CS2 INCORRECT  
CMP E.DS, T.DS ; CHECK DRIVE STATUS REG CORRECT  
BEQ 8$ ; YES, CHECK ERROR REG.  
8$: ERROR 246 ; DRIVE STATUS INCORRECT  
CMP E.ER, T.ER ; CHECK ERROR REG CORRECT  
BEQ 9$ ; YES, ISSUE CONTROLLER CLEAR
```

6795	041114	104247				ERROR	247		:ERROR REG INCORRECT
6796	041116	013737	004120	004220	9\$:	MOV	T.CS1,P.CS1		:STORE PREVIOUS CS1,CS2
6797	041124	013737	004130	004222		MOV	T.CS2,P.CS2		:DRIVE STATUS REG.,
6798	041132	013737	004132	004224		MOV	T.DS,P.DS		:AND ERROR REG.
6799	041140	013737	004134	004226		MOV	T.ER,P.ER		
6800	041146	012762	100000	000000		MOV	#CCLR,RKCS1(R2)		:ISSUE CONTROLLER CLEAR
6801	041154	016237	000000	004120		MOV	RKCS1(R2),T.CS1		:STORE COMMAND AND STATUS REG.1
6802	041162	016237	000010	004130		MOV	RKCS2(R2),T.CS2		:STORE COMMAND AND STATUS REG.2
6803	041170	016237	000012	004132		MOV	RKDS(R2),T.DS		:STORE DRIVE STATUS REG.
6804	041176	016237	000014	004134		MOV	RKER(R2),T.ER		:STORE ERROR REG.
6805	041204	012737	000200	004160		MOV	#RDY,E.CS1		:LOAD EXPECTED CS1
6806	041212	012737	000100	004170		MOV	#IR,E.CS2		:LOAD EXPECTED CS2
6807	041220	005037	004172			CLR	E.DS		:LOAD EXPECTED DRIVE STATUS REG.
6808	041224	005037	004174			CLR	E.ER		:LOAD EXPECTED ERROR REG.
6809	041230	023737	004160	004120		CMP	E.CS1,T.CS1		:CHECK COMMAND AND STATUS REG1 CORRECT
6810	041236	001401				BEQ	10\$		:YES, CHECK CS2
6811	041240	104224				ERROR	224		:CS1 INCORRECT
6812	041242	023737	004170	004130	10\$:	CMP	E.CS2,T.CS2		:CHECK COMMAND AND STATUS REG.2 CORRECT
6813	041250	001401				BEQ	11\$		:YES, CHECK DRIVE STATUS REG.
6814	041252	104225				ERROR	225		:CS2 INCORRECT
6815	041254	023737	004172	004132	11\$:	CMP	E.DS,T.DS		:CHECK DRIVE STATUS REG CORRECT
6816	041262	001401				BEQ	12\$		:YES, CHECK ERROR REG
6817	041264	104226				ERROR	226		:DRIVE STATUS INCORRECT
6818	041266	023737	004174	004134	12\$:	CMP	E.ER,T.ER		:CHECK ERROR REG CORRECT
6819	041274	001401				BEQ	TST77		:YES, GO ON TO NEXT TEST
6820	041276	104227				ERROR	227		:ERROR MESSAGE INCORRECT

```

*****
*TEST 77      NON-EXISTENT DRIVE AND NO SACK
*
* CLEAR THE RK06 SUBSYSTEM WITH A SUBSYSTEM CLEAR.  PUT
* THE RK611 CONTROLLER IN DIAGNOSTIC MODE.  ISSUE A
* SELECT TO AN RK06 IN 26 SECTOR FORMAT, CYLINDER 0,
* HEAD 0, DRIVE 0.  CLOCK IN DIAGNOSTIC MODE UNTIL
* PHASE ADDRESS 4.  TURN OFF DIAGNOSTIC MODE AND MAKE SURE
* NON-EXISTENT DRIVE AND CONTROLLER ERROR ARE SET.
*
* THIS TEST EXERCISES THE NON-EXISTENT DRIVE LOGIC
* DUE TO RELEASE BIT RESET AND SACK RESET BUT THE PASSING
* OF THIS TEST DOES GUARENTEE THAT THIS SITUATION DID
* INDEED CAUSE A NON-EXISTENT DRIVE.
*****

```

6838	041300	000004				TST77:	SCOPE		
6839	041302	012737	000144	001200		MOV	#100,\$TIMES		:DO 100. ITERATIONS
6840	041310	013702	001270			MOV	\$BASE,R2		:LOAD RK611 BASE
6841	041314	012762	000040	000010		MOV	#SCLR,RKCS2(R2)		:CLEAR RK06 SUBSYSTEM
6842	041322	012762	000040	000026		MOV	#DMD,RKMR1(R2)		:PUT RK611 IN MAINTENANCE MODE
6843	041330	012762	000001	000000		MOV	#SELDRV,RKCS1(R2)		:ISSUE SELECT DRIVE
6844	041336	012700	000116			MOV	#19,*4+2,RO		:ISSUE CLOCKS THROUGH PHASE 3
6845	041342	012762	000440	000026	1\$:	MOV	#DMD!MCLK,RKMR1(R2)		
6846	041350	012762	000040	000026		MOV	#DMD,RKMR1(R2)		
6847	041356	005300				DEC	RO		
6848	041360	001370				BNE	1\$		
6849	041362	005062	000026			CLR	RKMR1(R2)		:ALLOW COMMAND TO FINISH
6850	041366	013700	004262			MOV	WAITIM,RO		:LOAD WAIT TIME

K10

CZR6BCO RK611 DSKLS CTRL PRT2  
CZR6BC.P11 02-DEC-77 09:22

MACY11 30(1046) 02-DEC-77 09:31 PAGE 127  
T77 NON-EXISTENT DRIVE AND NO SACK

SEQ 0127

```

6851 041372 105762 000000 3$: TSTB RKCS1(R2) ;WAIT FOR READY
6852 041376 100402 BMI 4$
6853 041400 005300 DEC R0
6854 041402 001373 BNE 3$
6855 041404 016237 000000 004120 4$: MOV RKCS1(R2),T.CS1 ;STORE COMMAND AND STATUS REG.1
6856 041412 016237 000010 004130 MOV RKCS2(R2),T.CS2 ;STORE COMMAND AND STATUS REG.2
6857 041420 016237 000012 004132 MOV RKDS(R2),T.DS ;STORE DRIVE STATUS REG
6858 041426 016237 000014 004134 MOV RKER(R2),T.ER ;STORE ERROR REG
6859 041434 012737 100200 004160 MOV #CERR!RDY,E.CS1 ;LOAD EXPECTED CS1
6860 041442 012737 010100 004170 MOV #NED!IR,E.CS2 ;LOAD EXPECTED CS2
6861 041450 005037 004172 CLR E.DS ;LOAD EXPECTED DRIVE STATUS REG.
6862 041454 005037 004174 CLR E.ER ;LOAD EXPECTED ERROR REG.
6863 041460 023737 004160 004120 CMP E.CS1,T.CS1 ;CHECK COMMAND AND STATUS REG.1 CORRECT
6864 041466 001401 BEQ 5$ ;YES, CHECK CS2
6865 041470 104250 ERROR 250 ;CS1 INCORRECT
6866 041472 023737 004170 004130 5$: CMP E.CS2,T.CS2 ;CHECK COMMAND AND STATUS REG.2 CORRECT
6867 041500 001401 BEQ 6$ ;YES, CHECK DRIVE STATUS REG
6868 041502 104251 ERROR 251 ;CS2 INCORRECT
6869 041504 023737 004172 004132 6$: CMP E.DS,T.DS ;CHECK DRIVE STATUS REG CORRECT
6870 041512 001401 BEQ 7$ ;YES, CHECK ERROR REG.
6871 041514 104252 ERROR 252 ;DRIVE STATUS INCORRECT
6872 041516 023737 004174 004134 7$: CMP E.ER,T.ER ;CHECK ERROR REG CORRECT
6873 041524 001401 BEQ 8$ ;YES, ISSUE CONTROLLER CLEAR
6874 041526 104253 ERROR 253 ;ERROR REG INCORRECT
6875 041530 013737 004120 004220 8$: MOV T.CS1,P.CS1 ;STORE PREVIOUS CS1,CS2
6876 041536 013737 004130 004222 MOV T.CS2,P.CS2 ;DRIVE STATUS REG.,
6877 041544 013737 004132 004224 MOV T.DS,P.DS ;AND ERROR REG.
6878 041552 013737 004134 004226 MOV T.ER,P.ER
6879 041560 012762 100000 000000 MOV #CCLR,RKCS1(R2) ;ISSUE CONTROLLER CLEAR
6880 041566 016237 000000 004120 MOV RKCS1(R2),T.CS1 ;STORE COMMAND AND STATUS REG.1
6881 041574 016237 000010 004130 MOV RKCS2(R2),T.CS2 ;STORE COMMAND AND STATUS REG.2
6882 041602 016237 000012 004132 MOV RKDS(R2),T.DS ;STORE DRIVE STATUS REG.
6883 041610 016237 000014 004134 MOV RKER(R2),T.ER ;STORE ERROR REG.
6884 041616 012737 000200 004160 MOV #RDY,E.CS1 ;LOAD EXPECTED CS1
6885 041624 012737 000100 004170 MOV #IR,E.CS2 ;LOAD EXPECTED CS2
6886 041632 005037 004172 CLR E.DS ;LOAD EXPECTED DRIVE STATUS REG.
6887 041636 005037 004174 CLR E.ER ;LOAD EXPECTED ERROR REG.
6888 041642 023737 004160 004120 CMP E.CS1,T.CS1 ;CHECK COMMAND AND STATUS REG1 CORRECT
6889 041650 001401 BEQ 10$ ;YES, CHECK CS2
6890 041652 104224 ERROR 224 ;CS1 INCORRECT
6891 041654 023737 004170 004130 10$: CMP E.CS2,T.CS2 ;CHECK COMMAND AND STATUS REG.2 CORRECT
6892 041662 001401 BEQ 11$ ;YES, CHECK DRIVE STATUS REG.
6893 041664 104225 ERROR 225 ;CS2 INCORRECT
6894 041666 023737 004172 004132 11$: CMP E.DS,T.DS ;CHECK DRIVE STATUS REG CORRECT
6895 041674 001401 BEQ 12$ ;YES, CHECK ERROR REG
6896 041676 104226 ERROR 226 ;DRIVE STATUS INCORRECT
6897 041700 023737 004174 004134 12$: CMP E.ER,T.ER ;CHECK ERROR REG CORRECT
6898 041706 001401 BEQ TST100 ;YES, GO ON TO NEXT TEST
6899 041710 104227 ERROR 227 ;ERROR MESSAGE INCORRECT

```

.SBTTL \*\*ILLEGAL FUNCTION CODE TEST

```

*****
*TEST 100 ILLEGAL FUNCTION CODE
*
* CLEAR RK611 WITH A CONTROLLER CLEAR. ISSUE AN ILLEGAL

```

6900  
6901  
6902  
6903  
6904  
6905  
6906



```

6907      ;*      COMMAND IN NORMAL MODE AND MAKE SURE COMMAND FINISHES
6908      ;*      SETTING CONTROLLER READY WITH PROPER ERROR CONDITIONS.
6909      ;*
6910      ;*****
6911      041712 000004      †ST100: SCOPE
6912      041714 012737 000764 001200      MOV      #500.,$TIMES      ;:DO 500. ITERATIONS
6913      041722 012737 000033 004270      MOV      #33,ILLFUN      ;:SET ILLEGAL FUNCTION
6914      041730 012737 041736 001110      MOV      #1$, $LPERR      ;:LOAD LOOP ON ERROR LOCATION FOR
6915      ;: SUBTEST LOOP
6916
6917      041736      1$:
6918      041736 012762 100000 000000      MOV      #CCLR,RKCS1(R2) ;:CLEAR RK611 CONTROLLER
6919      041744 013737 004270 004160      MOV      ILLFUN,E.CS1    ;:GENERATE EXPECTED CSI
6920      041752 042737 000001 004160      BIC      #GO,E.CS1
6921      041760 052737 100200 004160      BIS      #CERR!RDY,E.CS1
6922      041766 012737 000001 004174      MOV      #ILF,E.ER      ;:LOAD EXPECTED ERROR REG
6923      041774 012762 000040 000026      MOV      #DMD,RKMR1(R2) ;:PUT RK611 IN DIAGNOSTIC MODE
6924      042002 013762 004270 000000      MOV      ILLFUN,RKCS1(R2) ;:ISSUE ILLEGAL FUNCTION
6925      042010 016237 000000 004120      MOV      RKCS1(R2),T.CS1 ;:STORE COMMAND AND STATUS REG 1
6926      042016 016237 000014 004134      MOV      RKER(R2),↑.ER    ;:STORE ERROR REG
6927      042024 023737 004160 004120      CMP      E.CS1,T.CS1     ;:CHECK IF CSI CORRECT
6928      042032 001401      3$:
6929      042034 104256      ERROR    256             ;:YES, CHECK ERROR REG
6930      042036 023737 004174 004134      3$:      CMP      E.ER,T.ER      ;:CSI INCORRECT AFTER ILL FUNCT
6931      042044 001401      4$:      BEQ      4$             ;:CHECK IF ERROR REG CORRECT
6932      042046 104257      ERROR    257             ;:YES, CLEAR CONTROLLER
6933      042050 012762 100000 000000      4$:      MOV      #CCLR,RKCS1(R2) ;:CLEAR RK611 CONTROLLER
6934      042056 016237 000000 004120      MOV      RKCS1(R2),T.CS1 ;:STORE COMMAND AND STATUS REG. 1
6935      042064 016237 000014 004134      MOV      RKER(R2),↑.ER    ;:STORE ERROR REG
6936      042072 012737 000200 004160      MOV      #RDY,E.CS1      ;:LOAD EXPECTED CSI
6937      042100 005037 004174      CLR      E.ER            ;:LOAD EXPECTED ERROR REG
6938      042104 023737 004160 004120      CMP      E.CS1,T.CS1     ;:CHECK IF CSI CORRECT (CERR CLEAR)
6939      042112 001401      6$:      BEQ      6$             ;:YES, CHECK IF ERROR REG CORRECT
6940      042114 104260      ERROR    260             ;:CONTROL CLEAR DID NOT CLEAR CERR
6941      042116 023737 004174 004134      6$:      CMP      E.ER,T.ER      ;:CHECK IF ILF CLEARED
6942      042124 001401      7$:      BEQ      7$             ;:YES, GO ON TO NEXT CONFIGURATION
6943      042126 104261      ERROR    261             ;:CONTROLLER CLEAR DID NOT CLEAR ILF
6944      042130 104415      7$:      SCOPI
6945      042132 062737 000002 004270      ADD      #2,ILLFUN      ;:CHECK IF LOOP ON ERROR
6946      042140 022737 000041 004270      CMP      #41,ILLFUN      ;:GENERATE NEXT ILLEGAL FUNCTION
6947      042146 101273      BHI      1$             ;:CHECK IF FINISHED
6948      ;:NO, USE NEXT CONFIGURATION

```

.SBTTL END OF PASS ROUTINE

\*\*\*\*\*  
\*INCREMENT THE PASS NUMBER (\$PASS)  
\*TYPE "END PASS #XXXXX TOTAL NUMBER OF ERRORS SINCE LAST REPORT YYYYY"  
\*WHERE XXXXX AND YYYYY ARE DECIMAL NUMBERS  
\*IF THERE'S A MONITOR GO TO IT  
\*IF THERE'S ISN'T JUMP TO NEWPAS

\$EOP:

SCOPE  
CLR \$STNM ; ZERO THE TEST NUMBER  
CLR \$TIMES ; ZERO THE NUMBER OF ITERATIONS  
INC \$PASS ; INCREMENT THE PASS NUMBER  
BIC #10000C,\$PASS ; DON'T ALLOW A NEG. NUMBER  
DEC (PC)+ ; LOOP?  
\$EOPCT: .WORD 1  
BGT \$DOAGN ; YES  
MOV (PC)+,a(PC)+ ; RESTORE COUNTER  
\$ENDCT: .WORD 1  
\$EOPCT  
TYPE 65\$ ; TYPE ASCIZ STRING  
BR 64\$ ; GET OVER THE ASCIZ  
64\$: .ASCIZ <12><15>/END PASS #/  
MOV \$PASS,-(SP) ; SAVE \$PASS FOR TYPEOUT  
; TYPE PASS NUMBER  
; GO TYPE--DECIMAL ASCII WITH SIGN  
TYPE 67\$ ; TYPE ASCIZ STRING  
BR 66\$ ; GET OVER THE ASCIZ  
66\$: .ASCIZ / TOTAL ERRORS SINCE LAST REPORT /  
MOV \$ERTTL,-(SP) ; SAVE \$ERTTL FOR TYPEOUT  
; TOTAL NUMBER OF ERRORS  
; GO TYPE--DECIMAL ASCII WITH SIGN  
TYPE \$CRLF ; TYPE CARRIAGE RETURN, LINE FEED  
CLR \$ERTTL ; CLEAR ERROR TOTAL  
\$GET42: MOV #42,PC ; GET MONITOR ADDRESS  
BEQ \$DOAGN ; BRANCH IF NO MONITOR  
RESET ; CLEAR THE WORLD  
\$ENDAD: JSR PC,(R0) ; GO TO MONITOR  
NOP ; SAVE ROOM  
NOP ; FOR  
NOP ; ACT11  
\$DOAGN: JMP a(PC)+ ; RETURN  
\$RTNAD: .WORD NEWPAS  
\$ENULL: .BYTE -1,-1,0 ; NULL CHARACTER STRING  
.EVEN

.SBTTL CHECK FOR MEMORY CHECK ENABLE OPTION

CHKPAR: MOV #20,\$ERRVEC ; SET VECTOR FOR MEMORY PARITY CHECK  
MOV #PR7,\$ERRVEC+2  
MOV #MEMBAS,R3 ; LOAD REGISTER TO DETERMINE IF  
; MEMORY CHECK ENABLE AVAILIABLE

6949  
6950  
6951  
6952  
6953  
6954  
6955  
6956  
6957  
6958 042150  
6959 042150 000004  
6960 042152 005037 001102  
6961 042156 005037 001200  
6962 042162 005237 001222  
6963 042166 042737 100000 001222  
6964 042174 005327  
6965 042176 000001  
6966 042200 003063  
6967 042202 012737  
6968 042204 000001  
6969 042206 042176  
6970 042210 104401 042216  
6971 042214 000407  
6972  
6973 042234  
6974 042234 013746 001222  
6975  
6976 042240 104405  
6977 042242 104401 042250  
6978 042246 000421  
6979  
6980 042312  
6981 042312 013746 001112  
6982  
6983 042316 104405  
6984 042320 104401 001211  
6985 042324 005037 001112  
6986 042330 013700 000042  
6987 042334 001405  
6988 042336 000005  
6989 042340 004710  
6990 042342 000240  
6991 042344 000240  
6992 042346 000240  
6993 042350  
6994 042350 000137  
6995 042352 005254  
6996 042354 377 377 000  
6997 042360  
6998  
6999  
7000  
7001 042360 012737 042432 000004  
7002 042366 012737 000340 000006  
7003 042374 012703 172100  
7004

```

7005 042400 012704 000020      MOV      #16,R4      ;LOAD COUNT
7006 042404 012723 000001      MOV      #PAR.EN,(R3)+ ;ENABLE MEMORY CHECK
7007 042410 012737 042450 000114 16$: MOV      #MEMERR,MEMVEC ;LOAD MEMORY CHECK VECTOR
7008 042416 012737 000340 000116  MOV      #PR7,MEMVEC+2
7009 042424 005304      DEC      R4          ;CHECK IF FINISHED
7010 042426 001366      BNE     16$         ;NO, SET UP NEXT MEMORY PARITY MODULE
7011 042430 000401      BR      22$         ;RESTORE TRAP VECTOR
7012
7013 042432 022626      CMP      (SP)+,(SP)+ ;ADJUST STACK
7014 042434 012737 000006 000004 22$: MOV      #ERRVEC+2,ERRVEC ;RESTORE TRAP CATCHER
7015 042442 005037 000006      CLR     ERRVEC+2
7016 042446 000207      RTS     PC          ;RETURN
7017
7018      .SBTTL MEMORY CHECK ENABLE TRAP
7019
7020 042450 012737 042464 001202 MEMERR: MOV      #10$, $ESCAPE ;LOAD ESCAPE
7021 042456 011637 004272      MOV      (SP),TRAPPC ;STORE PC
7022 042462 104262      ERROR   262        ;REPORT MEM PARITY ERROR
7023 042464 005037 001202 10$: CLR     $ESCAPE    ;CLEAR ESCAPE
7024 042470 032777 001000 136442  BIT      #SW9,$SWR   ;CHECK IF LOOP ON ERROR
7025 042476 001001      BNE     15$         ;YES, FORCE STACK AND TRY AGAIN
7026 042500 000002      RTI                    ;NO, RETURN
7027
7028 042502 012706 001100 15$: MOV      #STACK,SP ;INITIALIZE STACK
7029 042506 000177 136376      JMP     @SLPERR     ;LOOP ON ERROR
7030
7031      .SBTTL SCOPE HANDLER ROUTINE
7032
7033      ;*****
7034      ;THIS ROUTINE CONTROLS THE LOOPING OF SUBTESTS. IT WILL INCREMENT
7035      ;AND LOAD THE TEST NUMBER($TSTNM) INTO THE DISPLAY REG.(DISPLAY<7:0>)
7036      ;AND LOAD THE ERROR FLAG ($ERFLG) INTO DISPLAY<15:08>
7037      ;THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
7038      ;SW14=1      LOOP ON TEST
7039      ;SW11=1      INHIBIT ITERATIONS
7040      ;SW09=1      LOOP ON ERROR
7041      ;SW08=1      LOOP ON TEST IN SUP<7:0>
7042      ;CALL
7043      ;*      SCOPE      ;;SCOPE=IOT
7044
7045      $$SCOPE:
7046 042512 104407      CKSWR
7047 042514 032777 040000 13641E 1$: BIT      #BIT14,$SWR ;:TEST FOR CHANGE IN SOFT-SWR
7048 042522 001131      BNE     $OVER      ;:LOOP ON PRESENT TEST?
7049      ;*****START OF CODE FOR THE XOR TESTER***** ;:YES IF SW14=1
7050 042524 000416      $XTSTR: BR      6$ ;:IF RUNNING ON THE "XOR" TESTER CHANGE
7051      ;THIS INSTRUCTION TO A "NOP" (NOP=240)
7052 042526 013746 000004      MOV      @#ERRVEC,-(SP) ;:SAVE THE CONTENTS OF THE ERROR VECTOR
7053 042532 012737 042552 000004  MOV      #5$,@#ERRVEC ;:SET FOR TIMEOUT
7054 042540 005737 177060      TST     @#177060 ;:TIME OUT ON XOR?
7055 042544 012637 000004      MOV      (SP)+,@#ERRVEC ;:RESTORE THE ERROR VECTOR
7056 042550 000500      BR      $$VLAD     ;:GO TO THE NEXT TEST
7057 042552 022626 5$: CMP      (SP)+,(SP)+ ;:CLEAR THE STACK AFTER A TIME OUT
7058 042554 012637      MOV      (SP)+,@#ERRVEC ;:RESTORE THE ERROR VECTOR
7059 042560 000440      BR      7$         ;:LOOP ON THE PRESENT TEST
7060 042562      6$: ;*****END OF CODE FOR THE XOR TESTER*****

```

7061	042562	032777	000400	136350		BIT	#BIT08,2SWR	:: LOOP ON SPEC. TEST?
7062	042570	001421				BEQ	25	:: BR IF NO
7063	042572	005046				CLR	-(SP)	:: CLEAR A TEMP. LOCATION
7064	042574	117716	136340			MOVB	2SWR,(SP)	:: PICKUP THE DESIRED TEST NUMBER
7065	042600	001414				BEQ	85	:: BRANCH IF BAD TEST NUMBER IN SWR
7066	042602	022716	000100			CMP	#100,(SP)	:: CHECK THE NUMBER IN THE SWR
7067	042606	002411				BLT	85	:: BRANCH IF TEST NUMBER IS OUT OF RANGE
7068	042610	011637	001102			MOV	(SP), \$STNM	:: UPDATE THE TEST NUMBER
7069	042614	005316				DEC	(SP)	:: BACKUP BY ONE
7070	042616	006316				ASL	(SP)	:: SCALE THE TEST NUMBER AS AN INDEX
7071	042620	062716	043024			ADD	\$\$SW08TBL,(SP)	:: FORM THE ADDRESS OF TEST POINTER
7072	042624	013637	001106			MOV	2(SP)+,\$LPADR	:: SET LOOP ADDRESS TO DESIRED TEST
7073	042630	000466				BR	\$OVER	:: GO LOOP ON THE TEST
7074	042632	005726			85:	TST	(SP)+	:: CLEAN THE BAD TEST NUMBER OFF OF THE STACK
7075	042634	105737	001103		25:	TSTB	\$ERFLG	:: HAS AN ERROR OCCURRED?
7076	042640	001421				BEQ	35	:: BR IF NO
7077	042642	123737	001115	001103		CMPB	\$ERMAX,\$ERFLG	:: MAX. ERRORS FOR THIS TEST OCCURRED?
7078	042650	101015				BHI	35	:: BR IF NO
7079	042652	032777	001000	136260		BIT	#BIT09,2SWR	:: LOOP ON ERROR?
7080	042660	001404				BEQ	45	:: BR IF NO
7081	042662	013737	001110	001106	75:	MOV	\$LPERR,\$LPADR	:: SET LOOP ADDRESS TO LAST SCOPE
7082	042670	000446				BR	\$OVER	
7083	042672	105037	001103		45:	CLRB	\$ERFLG	:: ZERO THE ERROR FLAG
7084	042676	005037	001200			CLR	\$TIMES	:: CLEAR THE NUMBER OF ITERATIONS TO MAKE
7085	042702	000415				BR	15	:: ESCAPE TO THE NEXT TEST
7086	042704	032777	004000	136226	35:	BIT	#BIT11,2SWR	:: INHIBIT ITERATIONS?
7087	042712	001011				ONE	15	:: BR IF YES
7088	042714	005737	001222			TST	\$PASS	:: IF FIRST PASS OF PROGRAM
7089	042720	001406				BEQ	15	:: INHIBIT ITERATIONS
7090	042722	005237	001104			INC	\$ICNT	:: INCREMENT ITERATION COUNT
7091	042726	023737	001200	001104		CMP	\$TIMES,\$ICNT	:: CHECK THE NUMBER OF ITERATIONS MADE
7092	042734	002024				BGE	\$OVER	:: BR IF MORE ITERATION REQUIRED
7093	042736	012737	000001	001104	15:	MOV	#1,\$ICNT	:: REINITIALIZE THE ITERATION COUNTER
7094	042744	013737	043022	001200		MOV	\$MXCNT,\$TIMES	:: SET NUMBER OF ITERATIONS TO DO
7095	042752	105237	001102		\$SVLAD:	INCB	\$STNM	:: COUNT TEST NUMBERS
7096	042756	113737	001102	00.220		MOVB	\$STNM,\$TESTN	:: SET TEST NUMBER IN APT MAILBOX
7097	042764	011637	001106			MOV	(SP),\$LPADR	:: SAVE SCOPE LOOP ADDRESS
7098	042770	011637	001110			MOV	(SP),\$LPERR	:: SAVE ERROR LOOP ADDRESS
7099	042774	005037	001202			CLR	\$ESCAPE	:: CLEAR THE ESCAPE FROM ERROR ADDRESS
7100	043000	112737	000001	001115		MOVB	#1,\$ERMAX	:: ONLY ALLOW ONE(1) ERROR ON NEXT TEST
7101	043006	013777	001102	136126	\$OVER:	MOV	\$STNM,\$DISPLAY	:: DISPLAY TEST NUMBER
7102	043014	013716	001106			MOV	\$LPADR,(SP)	:: FUDGE RETURN ADDRESS
7103	043020	000002				RTI		:: FIXES PS
7104	043022	003720			\$MXCNT:	2000.		:: MAX. NUMBER OF ITERATIONS
7105	043024				\$SW08TBL:			
7106	043024	005274				.WORD	TST1+2	:: STARTING ADDRESS OF TEST 1
7107	043026	005600				.WORD	TST2+2	:: STARTING ADDRESS OF TEST 2
7108	043030	006060				.WORD	TST3+2	:: STARTING ADDRESS OF TEST 3
7109	043032	006324				.WORD	TST4+2	:: STARTING ADDRESS OF TEST 4
7110	043034	006636				.WORD	TST5+2	:: STARTING ADDRESS OF TEST 5
7111	043036	007200				.WORD	TST6+2	:: STARTING ADDRESS OF TEST 6
7112	043040	007516				.WORD	TST7+2	:: STARTING ADDRESS OF TEST 7
7113	043042	010034				.WORD	TST10+2	:: STARTING ADDRESS OF TEST 10
7114	043044	010352				.WORD	TST11+2	:: STARTING ADDRESS OF TEST 11
7115	043046	010616				.WORD	TST12+2	:: STARTING ADDRESS OF TEST 12
7116	043050	011062				.WORD	TST13+2	:: STARTING ADDRESS OF TEST 13

7117 043052 011400  
7118 043054 011710  
7119 043056 012242  
7120 043060 012604  
7121 043062 013050  
7122 043064 013330  
7123 043066 013610  
7124 043070 014070  
7125 043072 014350  
7126 043074 014630  
7127 043076 015142  
7128 043100 015454  
7129 043102 015766  
7130 043104 016300  
7131 043106 016612  
7132 043110 017110  
7133 043112 017422  
7134 043114 017660  
7135 043116 020124  
7136 043120 020460  
7137 043122 021024  
7138 043124 021350  
7139 043126 021714  
7140 043130 022170  
7141 043132 022720  
7142 043134 023160  
7143 043136 023564  
7144 043140 024014  
7145 043142 024450  
7146 043144 025132  
7147 043146 025564  
7148 043150 026216  
7149 043152 026634  
7150 043154 027266  
7151 043156 027720  
7152 043160 030352  
7153 043162 031004  
7154 043164 031436  
7155 043166 032070  
7156 043170 032522  
7157 043172 033154  
7158 043174 033572  
7159 043176 034224  
7160 043200 034706  
7161 043202 035370  
7162 043204 036052  
7163 043206 036534  
7164 043210 037216  
7165 043212 037700  
7166 043214 040212  
7167 043216 040640  
7168 043220 041302  
7169 043222 041714  
7170  
7171  
7172

.WORD TST14+2  
.WORD TST15+2  
.WORD TST16+2  
.WORD TST17+2  
.WORD TST20+2  
.WORD TST21+2  
.WORD TST22+2  
.WORD TST23+2  
.WORD TST24+2  
.WORD TST25+2  
.WORD TST26+2  
.WORD TST27+2  
.WORD TST30+2  
.WORD TST31+2  
.WORD TST32+2  
.WORD TST33+2  
.WORD TST34+2  
.WORD TST35+2  
.WORD TST36+2  
.WORD TST37+2  
.WORD TST40+2  
.WORD TST41+2  
.WORD TST42+2  
.WORD TST43+2  
.WORD TST44+2  
.WORD TST45+2  
.WORD TST46+2  
.WORD TST47+2  
.WORD TST50+2  
.WORD TST51+2  
.WORD TST52+2  
.WORD TST53+2  
.WORD TST54+2  
.WORD TST55+2  
.WORD TST56+2  
.WORD TST57+2  
.WORD TST60+2  
.WORD TST61+2  
.WORD TST62+2  
.WORD TST63+2  
.WORD TST64+2  
.WORD TST65+2  
.WORD TST66+2  
.WORD TST67+2  
.WORD TST70+2  
.WORD TST71+2  
.WORD TST72+2  
.WORD TST73+2  
.WORD TST74+2  
.WORD TST75+2  
.WORD TST76+2  
.WORD TST77+2  
.WORD TST100+2

STARTING ADDRESS OF TEST 14  
STARTING ADDRESS OF TEST 15  
STARTING ADDRESS OF TEST 16  
STARTING ADDRESS OF TEST 17  
STARTING ADDRESS OF TEST 20  
STARTING ADDRESS OF TEST 21  
STARTING ADDRESS OF TEST 22  
STARTING ADDRESS OF TEST 23  
STARTING ADDRESS OF TEST 24  
STARTING ADDRESS OF TEST 25  
STARTING ADDRESS OF TEST 26  
STARTING ADDRESS OF TEST 27  
STARTING ADDRESS OF TEST 30  
STARTING ADDRESS OF TEST 31  
STARTING ADDRESS OF TEST 32  
STARTING ADDRESS OF TEST 33  
STARTING ADDRESS OF TEST 34  
STARTING ADDRESS OF TEST 35  
STARTING ADDRESS OF TEST 36  
STARTING ADDRESS OF TEST 37  
STARTING ADDRESS OF TEST 40  
STARTING ADDRESS OF TEST 41  
STARTING ADDRESS OF TEST 42  
STARTING ADDRESS OF TEST 43  
STARTING ADDRESS OF TEST 44  
STARTING ADDRESS OF TEST 45  
STARTING ADDRESS OF TEST 46  
STARTING ADDRESS OF TEST 47  
STARTING ADDRESS OF TEST 50  
STARTING ADDRESS OF TEST 51  
STARTING ADDRESS OF TEST 52  
STARTING ADDRESS OF TEST 53  
STARTING ADDRESS OF TEST 54  
STARTING ADDRESS OF TEST 55  
STARTING ADDRESS OF TEST 56  
STARTING ADDRESS OF TEST 57  
STARTING ADDRESS OF TEST 60  
STARTING ADDRESS OF TEST 61  
STARTING ADDRESS OF TEST 62  
STARTING ADDRESS OF TEST 63  
STARTING ADDRESS OF TEST 64  
STARTING ADDRESS OF TEST 65  
STARTING ADDRESS OF TEST 66  
STARTING ADDRESS OF TEST 67  
STARTING ADDRESS OF TEST 70  
STARTING ADDRESS OF TEST 71  
STARTING ADDRESS OF TEST 72  
STARTING ADDRESS OF TEST 73  
STARTING ADDRESS OF TEST 74  
STARTING ADDRESS OF TEST 75  
STARTING ADDRESS OF TEST 76  
STARTING ADDRESS OF TEST 77  
STARTING ADDRESS OF TEST 100

\*\*\*\*\*  
:SBTTL LOOP ON INTERNAL ERROR

```

7173 043224 032777 001000 135706 SCOP1$: BIT      #SW9,ASWR      ;CHECK IF LOOP ON ERROR
7174 043232 001405          BEQ      SS          ;NO, CONTINUE
7175 043234 105737 001103          TSTB    $ERFLG     ;CHECK IF ERROR OCCURRED
7176 043240 001402          BEQ      SS          ;NO, CONTINUE
7177 043242 013716 001110          MOV     $LPERR,(SP) ;LOAD ERROR RETURN
7178 043246 000002          SS:     RTI          ;RETURN
7179          .SBTTL    APT COMMUNICATIONS ROUTINE
7180
7181          ;*****
7182 043250 112737 000001 043514 $ATY1:  MOVB    #1,$FFLG  ;; TO REPORT FATAL ERROR
7183 043256 112737 000001 043512 $ATY3:  MOVB    #1,$MFLG  ;; TO TYPE A MESSAGE
7184 043264 000403          BR      $ATYC       ;
7185 043266 112737 000001 043514 $ATY4:  MOVB    #1,$FFLG  ;; TO ONLY REPORT FATAL ERROR
7186 043274          $ATYC:
7187 043274 010046          MOV     RO,-(SP)    ; PUSH RO ON STACK
7188 043276 010146          MOV     R1,-(SP)    ; PUSH R1 ON STACK
7189 043300 105737 043512          TSTB    $MFLG      ; SHOULD TYPE A MESSAGE?
7190 043304 001450          BEQ     SS          ; IF NOT: BR
7191 043306 122737 000001 001234          CMPB    #APTENV,$ENV ; OPERATING UNDER APT?
7192 043314 001031          BNE    SS          ; IF NOT: BR
7193 043316 132737 000100 001235          BITB    #APTSPOOL,$ENVM ; SHOULD SPOOL MESSAGES?
7194 043324 001425          BEQ     SS          ; IF NOT: BR
7195 043326 017600 000004          MOV     #24(SP),RO  ; GET MESSAGE ADDR.
7196 043332 062766 000002 000004          ADD     #24(SP),RO  ; BUMP RETURN ADDR.
7197 043340 005737 001214          1$:     TST     $MSGTYPE ; SEE IF DONE W/ LAST XMISSION?
7198 043344 001375          BNE    SS          ; IF NOT: WAIT
7199 043346 010037 001230          MOV     RO,$MSGAD   ; PUT ADDR IN MAILBOX
7200 043352 105720 2$:     TSTB    (RO)+      ; FIND END OF MESSAGE
7201 043354 001376          BNE    SS          ;
7202 043356 163700 001230          SUB     $MSGAD,RO    ; SUB START OF MESSAGE
7203 043362 006200          ASR     RO          ; GET MESSAGE LGTH IN WORDS
7204 043364 010037 001232          MOV     RO,$MSGGLT  ; PUT LENGTH IN MAILBOX
7205 043370 012737 000004 001214          MOV     #4,$MSGTYPE ; TELL APT TO TAKE MSG.
7206 043376 000413          BR      SS          ;
7207 043400 017637 000004 043424 3$:     MOV     #24(SP),4$   ; PUT MSG ADDR IN JSR LINKAGE
7208 043406 062766 000002 000004          ADD     #24(SP),4$   ; BUMP RETURN ADDRESS
7209 043414 013746 177776          MOV     177776,-(SP) ; PUSH 177776 ON STACK
7210 043420 004737 044200          JSR    PC,$TYPE     ; CALL TYPE MACRO
7211 043424 000000          4$:     .WORD    0
7212 043426          5$:
7213 043426 105737 043514          10$:   TSTB    $FFLG      ; SHOULD REPORT FATAL ERROR?
7214 043432 001416          BEQ     SS          ; IF NOT: BR
7215 043434 005737 001234          TST     $ENV        ; RUNNING UNDER APT?
7216 043440 001413          BEQ     SS          ; IF NOT: BR
7217 043442 005737 001214          11$:   TST     $MSGTYPE   ; FINISHED LAST MESSAGE?
7218 043446 001375          BNE    SS          ; IF NOT: WAIT
7219 043450 017637 000004 001216          MOV     #24(SP),$FATAL ; GET ERROR #
7220 043456 062766 000002 000004          ADD     #24(SP),4$   ; BUMP RETURN ADDR.
7221 043464 005237 001214          INC     $MSGTYPE    ; TELL APT TO TAKE ERROR
7222 043470 105037 043514          12$:   CLRB    $FFLG      ; CLEAR FATAL FLAG
7223 043474 105037 043513          CLRB    $LFLG      ; CLEAR LOG FLAG
7224 043500 105037 043512          CLRB    $MFLG      ; CLEAR MESSAGE FLAG
7225 043504 012601          MOV     (SP)+,R1    ; POP STACK INTO R1
7226 043506 012600          MOV     (SP)+,RO    ; POP STACK INTO RO
7227 043510 000207          RTS     PC          ; RETURN
7228 043512 000          $MFLG: .BYTE    0 ; MESSG. FLAG

```

7229 043513 000  
7230 043514 000  
7231 043516  
7232 000200  
7233 000001  
7234 000100  
7235 000040

\$LFLG: .BYTE 0 :: LOG FLAG  
\$FFLG: .BYTE 0 :: FATAL FLAG  
          EVEN  
APTSIZE=200  
APTENV=001  
APTSPool=100  
APTC SUP=040  
.SBTTL ERROR HANDLER ROUTINE

\*\*\*\*\*  
\* THIS ROUTINE WILL INCREMENT THE ERROR FLAG AND THE ERROR COUNT.  
\* SAVE THE ERROR ITEM NUMBER AND THE ADDRESS OF THE ERROR CALL  
\* AND GO TO TYPERR ON ERROR  
\* THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:  
\* SW15=1 HALT ON ERROR  
\* SW13=1 INHIBIT ERROR TYPEOUTS  
\* SW10=1 BELL ON ERROR  
\* SW09=1 LOOP ON ERROR  
\* CALL  
\* ERROR N ; ; ERROR=EMT AND N=ERROR ITEM NUMBER

7250 043516  
7251 043516 104407  
7252 043520 105237 001103  
7253 043524 001775  
7254 043526 013777 001102 135406  
7255 043534 032777 002000 135376  
7256 043542 001402  
7257 043544 104401 001204  
7258 043550 005237 001112  
7259 043554 011637 001116  
7260 043560 162737 000002 001116  
7261 043566 117737 135324 001114  
7262 043574 032777 020000 135336  
7263 043602 001004  
7264 043604 004737 043716  
7265 043610 104401 001211  
7266 C43614  
7267 043614 122737 000001 001234  
7268 043622 001007  
7269 043624 113737 001114 043636  
7270 043632 004737 043266  
7271 043636 000  
7272 043637 000  
7273 043640 000777  
7274 043642 005777 135272  
7275 043646 100002  
7276 043650 000000  
7277 043652 104407  
7278 043654 032777 001000 135256  
7279 043662 001402  
7280 043664 013716 001110  
7281 043670 007737 001202  
7282 043674 001402  
7283 043676 013716 001202  
7284 043702

\$ERROR:  
7\$ : CKSWR ; ; TEST FOR CHANGE IN SOFT-SWR  
      INCB SERFLG ; ; SET THE ERROR FLAG  
      BEQ 7\$ ; ; DON'T LET THE FLAG GO TO ZERO  
      MOV \$STNM, @DISPLAY ; ; DISPLAY TEST NUMBER AND ERROR FLAG  
      ZTT #BIT10, @SWR ; ; BELL ON ERROR?  
      BEQ 1\$ ; ; NO - SKIP  
      TYPE \$BELL ; ; RING BELL  
1\$ : INC \$ERTTL ; ; COUNT THE NUMBER OF ERRORS  
      MOV (SP), \$ERRPC ; ; GET ADDRESS OF ERROR INSTRUCTIO'  
      SUB #2, \$ERRPC  
      MOVB @ERRPC, \$ITEMB ; ; STRIP AND SAVE THE ERROR ITEM CODE  
      BIT #BIT13, @SWR ; ; SKIP TYPEOUT IF SET  
      BNE 20\$ ; ; SKIP TYPEOUTS  
      JSR PC, TYPERR ; ; GO TO USER ERROR ROUTINE  
      TYPE , \$CRLF  
20\$ : CMPB #APTENV, \$ENV ; ; RUNNING IN APT MODE  
      BNE 2\$ ; ; NO, SKIP APT ERROR REPORT  
      MOVB \$ITEMB, 21\$ ; ; SET ITEM NUMBER AS ERROR NUMBER  
      JSR PC, SATY4 ; ; REPORT FATAL ERROR TO APT  
21\$ : .BYTE 0  
      .BYTE 0  
22\$ : BR 22\$ ; ; APT ERROR LOOP  
2\$ : TST @SWR ; ; HALT ON ERROR  
      BPL 3\$ ; ; SKIP IF CONTINUE  
      HALT ; ; HALT ON ERROR!  
3\$ : BIT #BIT09, @SWR ; ; TEST FOR CHANGE IN SOFT-SWR  
      BEQ 4\$ ; ; LOOP ON ERROR SWITCH SET?  
      MOV \$LPERR, (SP) ; ; BR IF NO  
      TST \$ESCAPE ; ; FUDGE RETURN FOR LOOPING  
      BEQ 5\$ ; ; CHECK FOR AN ESCAPE ADDRESS  
      MOV \$ESCAPE, (SP) ; ; BR IF NONE  
      ; ; FUDGE RETURN ADDRESS FOR ESCAPE  
5\$ :

```

7285 043702 022737 042340 000042      CMP      #SENDAD,0#42      ;;ACT-11 AUTO-ACCEPT?
7286 043710 001001                      BNE      6$              ;;BRANCH IF NO
7287 043712 000000                      HALT                      ;;YES
7288 043714                               6$:
7289 043714 000002                      RTI                       ;;RETURN
7290
7291
7292
7293
7294
7295
7296
7297
7298
7299
7300
7301 043716 104413
7302 043720 113700 001114
7303 043724 042700 177400
7304 043730 005300
7305 043732 006300
7306 043734 006300
7307 043736 006300
7308 043740 062700 001300
7309 043744 012037 043760
7310 043750 001404
7311 043752 104401 001211
7312 043756 104401
7313 043760 000000
7314 043762 012037 043776
7315 043766 001404
7316 043770 104401 001211
7317 043774 104401
7318 043776 000000
7319 044000 012001
7320 044002 001445
7321 044004 005004
7322 044006 012000
7323 044010 012002
7324 044012 104401 001211
7325 044016 112003
7326 044020 10572C
7327 044022 005703
7328 044024 001416
7329 044026 005704
7330 044030 001004
7331 044032 013146
7332 044034 104402
7333 044036 005303
7334 044040 001403
7335 044042 104401 050117
7336 044046 000771
7337 044050 104401 001211
7338 044054 005710
7339 044056 001401
7340 044060 005104

;*****
;SBTTL TYPE ERROR ROUTINE
;*ENTRY JSR PC,TYPERR
;*RETURN RTS PC
;*
;*THIS ROUTINE USES THE "ITEM CONTROL BYTE" ($ITEMB) TO DETERMINE WHICH
;*ERROR IS TO BE REPORTED. IT THEN USES THE "ERROR TABLE" ($ERRTB)
;*ENTRY TO DEFINE WHAT INFORMATION IS TO BE REPORTED CONCERNING
;*THE ERROR.
;*****
TYPERR: SAVREG
        MOVB      $ITEMB,RO      ;ENTER ERROR NUMBER
        BIC      #177400,RO      ;CLEAR UNUSED BITS
        DEC      RO              ;FORM INDEX FOR ERROR TABLE
        ASL      RO
        ASL      RO
        ASL      RO
1$:     ADD      #SERRTB,RO      ;FORM ADDRESS OF ERROR ENTRY
        MOV      (RO)+,2$      ;GET EM POINTER
        BEQ      3$            ;BRANCH IF THERE ISN'T ONE
        TYPE     ,SCRLF        ;TYPE CARRIAGE RETURN LINE FEED
        TYPE     ,EM          ;TYPE ERROR MESSAGE (EM)
2$:     .WORD   0              ;EM POINTER GOES HERE
3$:     MOV      (RO)+,4$      ;GET DH POINTER
        BEQ      5$            ;BRANCH IF THERE ISN'T ONE
        TYPE     ,SCRLF        ;TYPE CR-LF
        TYPE     ,DATA        ;TYPE DATA HEADER
4$:     .WORD   0              ;DH POINTER GOES HERE
5$:     MOV      (RO)+,R1      ;GET DT POINTER
        BEQ      20$          ;BRANCH IF THERE ARE NONE
        CLR      R4           ;RESET INDENT SWITCH
        MOV      (RO)+,RO      ;GET DF POINTER
        MOV      (RO)+,R2      ;STORE NUMBER OF DH'S
        TYPE     ,SCRLF        ;TYPE <CR><LF>
10$:    MOVB      (RO)+,R3      ;GET & STORE NUMBER OF DATA WORDS
        TSTB     (RO)+        ;BUMP PAST FORMAT WORD
        TST      R3           ;TEST IF ANY DATA FOR THIS HEADER
        BEQ      14$          ;NO - SKIP DATA PRINT
        TST      R4           ;CHECK FOR INDENT
        BNE      12$          ;YES, GO INDENT
11$:    MOV      2(R1)+,-(SP)   ;PUT FIRST DATA WORD ON STACK
        TYPOC
        DEC      R3           ;MORE DATA WORDS
        BEQ      13$          ;NO-BRANCH
        TYPE     ,SPACE2      ;TYPE SEPARATORS
        BR       11$          ;LOOP
13$:    TYPE     ,SCRLF        ;TYPE <CR><LF>
        TST      (RO)         ;CHECK IF NEXT HEADER AVAILBLE
        BEQ      14$          ;NO, DO NOT CHANGE INDENT
        COM      R4           ;CHANGE INDENT

```



```

7341 044062 005302          14$: DEC      R2          : MORE DH'S?
7342 044064 003414          BLE      20$          : NO-BRANCH
7343 044066 012037 044106   15$: MOV      (R0)+, 0$   : GET NEXT DH POINTER
7344 044072 001751          BEQ      10$          : IF NO HEADER GO GET DATA
7345 044074 005704          TST      R4          : INDENT?
7346 044076 001402          BEQ      17$          : NO-BRANCH
7347 044100 104401 050117   TYPE     ,SPACE2     : YES-TYPE SPACES
7348 044104 104401          17$: TYPE     : TYPE DH
7349 044106 000000          18$: .WORD    0          : DH POINTER GOES HERE
7350 044110 104401 001211   TYPE     $CRLF      :
7351 044114 000740          BR       10$          : GO TYPE OUT DATA
7352 044116 104414          20$: RESREG          :
7353 044120 005237 004242   INC      ERRCNT      : INCREMENT THE ERROR COUNT
7354 044124 032777 010000 135006 BIT      #SW12, $SWR   : CHECK IF SWITCH 12 SET
7355 044132 001421          BEQ      25$          : NO, RETURN
7356 044134 022737 000024 004242 CMP      #20, $ERRCNT : CHECK IF ERROR THRESHOLD EXCEEDED
7357 044142 103015          BHS     25$          : NO, RETURN
7358 044144 104401 050122   TYPE     ,ABORT     : TYPE "PROGRAM ABORTED BECAUSE ERROR
7359                                : THRESHOLD EXCEEDED"
7360 044150 005737 000042   TST      42          : CHECK IF IN CHAIN MODE
7361 044154 001407          BEQ      22$          : NO, HALT PROCESSOR
7362 044156 012737 000001 042176 MOV      #1, $EOPCT   : FOR PASS COUNT FOR ABORT
7363 044164 012706 001100   MOV     #STACK, SP   : INITIALIZE STACK
7364 044170 000137 042.50   JMP     $EOP         : BRING IN NEXT PROGRAM
7365
7366 044174 000000          22$: HALT          :
7367 044176 000207          25$: RTS      PC      :
7368                                : $BTTL TYPE ROUTINE
7369
7370                                : *****
7371                                : *ROUTINE TO TYPE ASCIZ MESSAGE. MESSAGE MUST TERMINATE WITH A 0 BYTE.
7372                                : *THE ROUTINE WILL INSERT A NUMBER OF NULL CHARACTERS AFTER A LINE FEED.
7373                                : *NOTE1:          $NULL CONTAINS THE CHARACTER TO BE USED AS THE FILLER CHARACTER.
7374                                : *NOTE2:          $FILLS CONTAINS THE NUMBER OF FILLER CHARACTERS REQUIRED.
7375                                : *NOTE3:          $FILLC CONTAINS THE CHARACTER TO FILL AFTER.
7376                                : *
7377                                : *CALL:
7378                                : *1) USING A TRAP INSTRUCTION
7379                                : *      TYPE     ,MESADR          ; MESADR IS FIRST ADDRESS OF AN ASCIZ STRING
7380                                : *OR
7381                                : *      TYPE     MESADR
7382                                : *
7383                                : *
7384
7385 044200 105737 001157   $TYPE: TSTB     $TPFLG   : IS THERE A TERMINAL?
7386 044204 100002          BPL      1$          : BR IF YES
7387 044206 000000          HALT          : HALT HERE IF NO TERMINAL
7388 044210 000430          BR       3$          : LEAVE
7389 044212 010046          1$: MOV      R0, -(SP)   : SAVE R0
7390 044214 017600 000002   MOV     @2(SP), R0   : GET ADDRESS OF ASCIZ STRING
7391 044220 122737 000001 001234 CMPB     #APTENV, $ENV : RUNNING IN APT MODE
7392 044226 001011          BNE     62$          : NO, GO CHECK FOR APT CONSOLE
7393 044230 132737 000100 001235 BITB     #APTPOOL, $ENVM : SPOOL MESSAGE TO APT
7394 044236 001405          BEQ     62$          : NO, GO CHECK FOR CONSOLE
7395 044240 010037 044250   MOV     R0, 61$     : SETUP MESSAGE ADDRESS FOR APT
7396 044244 004737 043256   JSR     PC, $ATY3   : SPOOL MESSAGE TO APT

```

```

7397 044250 000000 000040 001235 61$: WORD 0 ;; MESSAGE ADDRESS
7398 044252 132737 000040 001235 62$: BITB #APTCSUP,$ENVM ;; APT CONSOLE SUPPRESSED
7399 044260 001003 000040 001235 63$: BNE 60$ ;; YES, SKIP TYPE OUT
7400 044262 112046 000040 001235 2$: MOVB (R0)+,-(SP) ;; PUSH CHARACTER TO BE TYPED ONTO STACK
7401 044264 001005 000040 001235 4$: BNE 4$ ;; BR IF IT ISN'T THE TERMINATOR
7402 044266 005726 000040 001235 TST (SP)+ ;; IF TERMINATOR POP IT OFF THE STACK
7403 044270 012600 000040 001235 60$: MOV (SP)+,R0 ;; RESTORE R0
7404 044272 062716 000002 000002 3$: ADD #2,(SP) ;; ADJUST RETURN PC
7405 044276 000002 000002 000011 4$: RTI ;; RETURN
7406 044300 122716 000011 000011 4$: CMPB #HT,(SP) ;; BRANCH IF <HT>
7407 044304 001430 000011 000011 8$: BEQ 8$
7408 044306 122716 000200 000200 CMPB #CRLF,(SP) ;; BRANCH IF NOT 'CRLF'
7409 044312 001006 000200 000200 5$: BNE 5$
7410 044314 005726 000200 000200 TST (SP)+ ;; POP <CR><LF> EQUIV
7411 044316 104401 000200 000200 TYPE ;; TYPE A CR AND LF
7412 044320 001211 000200 000200 $CRLF
7413 044322 105037 044456 044456 CLRB $CHARCNT ;; CLEAR CHARACTER COUNT
7414 044326 000755 044456 044456 BR 2$ ;; GET NEXT CHARACTER
7415 044330 004737 044412 044412 5$: JSR PC,$TYPEC ;; GO TYPE THIS CHARACTER
7416 044334 123726 001156 001156 6$: CMPB $FILLC,(SP)+ ;; IS IT TIME FOR FILLER CHARS.?
7417 044340 001350 001156 001156 2$: BNE 2$ ;; IF NO GO GET NEXT CHAR.
7418 044342 013746 001156 001156 MOV $NULL,-(SP) ;; GET # OF FILLER CHARS. NEEDED
7419 044344 001374 001156 001156 AND THE NULL CHAR.
7420 044346 105366 000001 000001 7$: DECB 1(SP) ;; DOES A NULL NEED TO BE TYPED?
7421 044352 002770 000001 000001 6$: BLT 6$ ;; BR IF NO--GO POP THE NULL OFF OF STACK
7422 044354 004737 044412 044412 JSR PC,$TYPEC ;; GO TYPE A NULL
7423 044360 105337 044456 044456 DECB $CHARCNT ;; DO NOT COUNT AS A COUNT
7424 044364 000770 044456 044456 BR 7$ ;; LOOP
7425
7426 ;HORIZONTAL TAB PROCESSOR
7427
7428 044366 112716 000040 000040 8$: MOVB #' (SP) ;; REPLACE TAB WITH SPACE
7429 044372 004737 044412 044412 9$: JSR PC,$TYPEC ;; TYPE A SPACE
7430 044376 132737 000007 044456 9$: BITB #7,$CHARCNT ;; BRANCH IF NOT AT
7431 044404 001372 000007 044456 9$: BNE 9$ ;; TAB STOP
7432 044406 005726 000007 044456 TST (SP)+ ;; POP SPACE OFF STACK
7433 044410 000724 000007 044456 BR 2$ ;; GET NEXT CHARACTER
7434 044412 105777 134532 $TYPEC: TSTB $STPS ;; WAIT UNTIL PRINTER IS READY
7435 044416 100375 134532 $TYPEC: BPL $TYPEC
7436 044420 116677 000002 134524 MOVB 2(SP),$STPB ;; LOAD CHAR TO BE TYPED INTO DATA REG.
7437 044426 122766 000015 000002 CMPB #CR,2(SP) ;; IS CHARACTER A CARRIAGE RETURN?
7438 044434 001003 000015 000002 1$: BNE 1$ ;; BRANCH IF NO
7439 044436 105037 044456 044456 CLRB $CHARCNT ;; YES--CLEAR CHARACTER COUNT
7440 044442 000406 044456 044456 BR $TYPEX ;; EXIT
7441 044444 122766 000012 000002 1$: CMPB #LF,2(SP) ;; IS CHARACTER A LINE FEED?
7442 044452 001402 000012 000002 BEQ $TYPEX ;; BRANCH IF YES
7443 044454 105227 000012 000002 INCB (PC)+ ;; COUNT THE CHARACTER
7444 044456 000000 $CHARCNT: WORD 0 ;; CHARACTER COUNT STORAGE
7445 044460 000207 $TYPEX: RTS PC
7446
7447 .SBTTL BINARY TO OCTAL (ASCII) AND TYPE
7448
7449 ;*****
7450 ;*THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 6-DIGIT
7451 ;*OCTAL (ASCII) NUMBER AND TYPE IT.
7452 ;*$TYPOS---ENTER HERE TO SETUP SUPPRESS ZEROS AND NUMBER OF DIGITS TO TYPE

```

```

7453      *CALL:
7454      *   MOV      NUM,-(SP)      ;; NUMBER TO BE TYPED
7455      *   TYPOS   TYPOS          ;; CALL FOR TYPEOUT
7456      *   .BYTE  N                ;; N=1 TO 6 FOR NUMBER OF DIGITS TO TYPE
7457      *   .BYTE  M                ;; M=1 OR 0
7458      *                                     ;; 1=TYPE LEADING ZEROS
7459      *                                     ;; 0=SUPPRESS LEADING ZEROS
7460
7461      *$TYPON----ENTER HERE TO TYPE OUT WITH THE SAME PARAMETERS AS THE LAST
7462      *$TYPOS OR $TYPOC
7463      *CALL:
7464      *   MOV      NUM,-(SP)      ;; NUMBER TO BE TYPED
7465      *   TYPON   TYPON          ;; CALL FOR TYPEOUT
7466
7467      *$TYPOC----ENTER HERE FOR TYPEOUT OF A 16 BIT NUMBER
7468      *CALL:
7469      *   MOV      NUM,-(SP)      ;; NUMBER TO BE TYPED
7470      *   TYPOC   TYPOC          ;; CALL FOR TYPEOUT
7471
7472      044462 017646 000000      $TYPOS: MOV      2(SP),-(SP)      ;; PICKUP THE MODE
7473      044466 116637 000001 044705      MOV      1(SP),$OFILL      ;; LOAD ZERO FILL SWITCH
7474      044474 112637 044707      MOV      (SP)+,$SOMODE+1  ;; NUMBER OF DIGITS TO TYPE
7475      044500 062716 000002      ADD      #2,(SP)          ;; ADJUST RETURN ADDRESS
7476      044504 000406      BR      $TYPON
7477      044506 112737 000001 044705      $TYPOC: MOV      #1,$OFILL      ;; SET THE ZERO FILL SWITCH
7478      044514 112737 000006 044707      MOV      #6,$SOMODE+1     ;; SET FOR SIX(6) DIGITS
7479      044522 112737 000005 044704      $TYPON: MOV      #5,$OCNT      ;; SET THE ITERATION COUNT
7480      044530 010346      MOV      R3,-(SP)         ;; SAVE R3
7481      044532 010446      MOV      R4,-(SP)         ;; SAVE R4
7482      044534 010546      MOV      R5,-(SP)         ;; SAVE R5
7483      044536 113704 044707      MOV      $SOMODE+1,R4     ;; GET THE NUMBER OF DIGITS TO TYPE
7484      044542 005404      NEG      R4
7485      044544 062704 000006      ADD      #6,R4            ;; SUBTRACT IT FOR MAX. ALLOWED
7486      044550 110437 044706      MOV      R4,$SOMODE       ;; SAVE IT FOR USE
7487      044554 113704 044705      MOV      $OFILL,R4        ;; GET THE ZERO FILL SWITCH
7488      044560 016605 000012      MOV      12(SP),R5        ;; PICKUP THE INPUT NUMBER
7489      044564 005003      CLR      R3               ;; CLEAR THE OUTPUT WORD
7490      044566 006105      1$:      ROL      R5              ;; ROTATE MSB INTO "C"
7491      044570 000404      BR      3$               ;; GO DO MSB
7492      044572 006105      2$:      ROL      R5              ;; FORM THIS DIGIT
7493      044574 006105      ROL      R5
7494      044576 006105      ROL      R5
7495      044600 010503      MOV      R5,R3
7496      044602 006103      3$:      ROL      R3              ;; GET LSB OF THIS DIGIT
7497      044604 105337 044706      DECB    $SOMODE           ;; TYPE THIS DIGIT?
7498      044610 100016      BPL     7$               ;; BR IF NO
7499      044612 042703 177770      BIC     #177770,R3       ;; GET RID OF JUNK
7500      044616 001002      BNE     4$               ;; TEST FOR 0
7501      044620 005704      TST     R4               ;; SUPPRESS THIS 0?
7502      044622 001403      BEQ     5$               ;; BR IF YES
7503      044624 005204      4$:      INC      R4              ;; DON'T SUPPRESS ANYMORE 0'S
7504      044626 052703 000060      BIS     #'0,R3           ;; MAKE THIS DIGIT ASCII
7505      044632 052703 000040      5$:      BIS     #' ',R3          ;; MAKE ASCII IF NOT ALREADY
7506      044636 110337 044702      MOV      R3,8$           ;; SAVE FOR TYPING
7507      044642 104401 044702      TYPE   8$               ;; GO TYPE THIS DIGIT
7508      044646 105337 044704      7$:      DECB    $OCNT           ;; COUNT BY 1

```

```

7509 044652 003347          BGT      2$          ;; BR IF ORE TO DO
7510 044654 002402          BLT      6$          ;; BR IF DONE
7511 044656 005204          INC      R4          ;; INSURE LAST DIGIT ISN'T A BLANK
7512 044660 000744          BR       2$          ;; GO DO THE LAST DIGIT
7513 044662 012605          6$:     MOV      (SP)+,R5      ;; RESTORE R5
7514 044664 012604          MOV      (SP)+,R4      ;; RESTORE R4
7515 044666 012603          MOV      (SP)+,R3      ;; RESTORE R3
7516 044670 016666 000002 000004 MOV      2(SP),4(SP)    ;; SET THE STACK FOR RETURNING
7517 044676 012616          MOV      (SP)+,(SP)
7518 044700 000002          RTI          ;; RETURN
7519 044702 000          8$:     .BYTE   0          ;; STORAGE FOR ASCII DIGIT
7520 044703 000          .BYTE   0          ;; TERMINATOR FOR TYPE ROUTINE
7521 044704 000          $OCNT: .BYTE   0          ;; OCTAL DIGIT COUNTER
7522 044705 000          $OFILL: .BYTE   0          ;; ZERO FILL SWITCH
7523 044706 000000          $OMODE: .WORD   0          ;; NUMBER OF DIGITS TO TYPE
7524          .SBTTL  CONVERT BINARY TO DECIMAL AND TYPE ROUTINE
7525
7526          ;; *****
7527          ;; *THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 5-DIGIT
7528          ;; *SIGNED DECIMAL (ASCII) NUMBER AND TYPE IT. DEPENDING ON WHETHER THE
7529          ;; *NUMBER IS POSITIVE OR NEGATIVE A SPACE OR A MINUS SIGN WILL BE TYPED
7530          ;; *BEFORE THE FIRST DIGIT OF THE NUMBER. LEADING ZEROS WILL ALWAYS BE
7531          ;; *REPLACED WITH SPACES.
7532          ;; *CALL:
7533          ;; *      MOV      NUM,-(SP)          ;; PUT THE BINARY NUMBER ON THE STACK
7534          ;; *      TYPDS          ;; GO TO THE ROUTINE
7535
7536          $TYPDS:
7537 044710 010046          MOV      R0,-(SP)      ;; PUSH R0 ON STACK
7538 044712 010146          MOV      R1,-(SP)      ;; PUSH R1 ON STACK
7539 044714 010246          MOV      R2,-(SP)      ;; PUSH R2 ON STACK
7540 044716 010346          MOV      R3,-(SP)      ;; PUSH R3 ON STACK
7541 044720 010546          MOV      R5,-(SP)      ;; PUSH R5 ON STACK
7542 044722 012746 020200          MOV      #20200,-(SP)  ;; SET BLANK SWITCH AND SIGN
7543 044726 016605 000020          MOV      20(SP),R5     ;; GET THE INPUT NUMBER
7544 044732 100004          BPL      1$          ;; BR IF INPUT IS POS.
7545 044734 005405          NEG      R5          ;; MAKE THE BINARY NUMBER POS.
7546 044736 112766 000055 000001          MOVB    #'-,1(SP)      ;; MAKE THE ASCII NUMBER NEG.
7547 044744 005000          CLR      R0          ;; ZERO THE CONSTANTS INDEX
7548 044746 012703 045124          MOV      #5DBLK,R3     ;; SETUP THE OUTPUT POINTER
7549 044752 112723 000040          MOVB    #'',(R3)+     ;; SET THE FIRST CHARACTER TO A BLANK
7550 044756 005002          CLR      R2          ;; CLEAR THE BCD NUMBER
7551 044760 016001 045114          MOV      $DTBL(R0),R1  ;; GET THE CONSTANT
7552 044764 160105          3$:     SUB      R1,R5      ;; FORM THIS BCD DIGIT
7553 044766 002402          BLT      4$          ;; BR IF DONE
7554 044770 005202          INC      R2          ;; INCREASE THE BCD DIGIT BY 1
7555 044772 000774          BR       3$
7556 044774 060105          4$:     ADD      R1,R5      ;; ADD BACK THE CONSTANT
7557 044776 005702          TST      R2          ;; CHECK IF BCD DIGIT=0
7558 045000 001002          BNE      5$          ;; FALL THROUGH IF 0
7559 045002 105716          TSTB    (SP)          ;; STILL DOING LEADING 0'S?
7560 045004 100407          BMI      7$          ;; BR IF YES
7561 045006 106316          5$:     ASLB    (SP)          ;; MSD?
7562 045010 103003          BCC      6$          ;; BR IF NO
7563 045012 116663 000001 177777          MOVB    1(SP),-1(R3)   ;; YES--SET THE SIGN
7564 045020 052702 000060          6$:     BIS      #'0,R2   ;; MAKE THE BCD DIGIT ASCII

```

K11

CZR6BC0 RK611 DSCLS CTRL PRT2  
CZR6BC.P11 02-DEC-77 09:22

MACY11 30(1046) 02-DEC-77 09:31 PAGE 140  
CONVERT BINARY TO DECIMAL AND TYPE ROUTINE

SEQ 0140

```

7565 045024 052702 000040      7$:  BIS      #' R2      ;; MAKE IT A SPACE IF NOT ALREADY A DIGIT
7566 045030 110223             MOVB     R2,(R3)+    ;; PUT THIS CHARACTER IN THE OUTPUT BUFFER
7567 045032 005720             TST      (R0)+      ;; JUST INCREMENTING
7568 045034 020027 000010      CMP      R0,#10     ;; CHECK THE TABLE INDEX
7569 045040 002746             BLT      2$         ;; GO DO THE NEXT DIGIT
7570 045042 003002             BGT      8$         ;; GO TO EXIT
7571 045044 010502             MOV      R5,R2      ;; GET THE LSD
7572 045046 000764             BR       6$         ;; GO CHANGE TO ASCII
7573 045050 105726             8$:  TSTB     (SP)+    ;; WAS THE LSD THE FIRST NON-ZERO?
7574 045052 100003             BPL      9$         ;; BR IF NO
7575 045054 116663 177777 177776  MOVB     -1(SP),-2(R3) ;; YES--SET THE SIGN FOR TYPING
7576 045062 105013             9$:  CLRB     (R3)     ;; SET THE TERMINATOR
7577 045064 012605             MOV      (SP)+,R5   ;; POP STACK INTO R5
7578 045066 012603             MOV      (SP)+,R3   ;; POP STACK INTO R3
7579 045070 012602             MOV      (SP)+,R2   ;; POP STACK INTO R2
7580 045072 012601             MOV      (SP)+,R1   ;; POP STACK INTO R1
7581 045074 012600             MOV      (SP)+,R0   ;; POP STACK INTO R0
7582 045076 104401 045124     TYPE     $DBLK      ;; NOW TYPE THE NUMBER
7583 045102 016666 000002 000004  MOV      2(SP),4(SP) ;; ADJUST THE STACK
7584 045110 012616             MOV      (SP)+,(SP)
7585 045112 000002             RTI                      ;; RETURN TO USER
7586 045114 023420             $DTBL: 10000.
7587 045116 001750             1000.
7588 045120 000144             100.
7589 045122 000012             10.
7590 045124 000004             $DBLK: .BLKW 4
7591                                     .SBTTL ITY INPUT ROUTINE
7592
7593                                     ;; *****
7594                                     .ENABL LSB
7595
7596                                     ;; *****
7597                                     ;*SOFTWARE SWITCH REGISTER CHANGE ROUTINE.
7598                                     ;*ROUTINE IS ENTERED FROM THE TRAP HANDLER, AND WILL
7599                                     ;*SERVICE THE TEST FOR CHANGE IN SOFTWARE SWITCH REGISTER TRAP CALL
7600                                     ;*WHEN OPERATING IN TTY FLAG MODE.
7601 045134 022737 000176 001140 $CKSWR: CMP      #SWREG,SWR ;; IS THE SOFT-SWR SELECTED?
7602 045142 001074             BNE     15$         ;; BRANCH IF NO
7603 045144 105777 133774             TSTB     0$TKS     ;; CHAR THERE?
7604 045150 100071             BPL     15$         ;; IF NO, DON'T WAIT AROUND
7605 045152 117746 133770             MOVB     0$TKB,-(SP) ;; SAVE THE CHAR
7606 045156 042716 177600             BIC     #1C177,(SP) ;; STRIP-OFF THE ASCII
7607 045162 022726 000007             CMP      #7,(SP)+   ;; IS IT A CONTROL G?
7608 045166 001062             BNE     15$         ;; NO, RETURN TO USER
7609 045170 123727 001134 000001  CMPB     $AUTOB,#1  ;; ARE WE RUNNING IN AUTO-MODE?
7610 045176 001456             BEQ     15$         ;; BRANCH IF YES
7611
7612 045200 104401 046007             TYPE     .$CNTLG   ;; ECHO THE CONTROL-G (↑G)
7613 045204 104401 046014             TYPE     $MSWR     ;; TYPE CURRENT CONTENTS
7614 045210 013746 000176             MOV      SWREG,-(SP) ;; SAVE SWREG FOR TYPEOUT
7615 045214 104402             TYPOC   ;; GO TYPE--OCTAL ASCII(ALL DIGITS)
7616 045216 104401 046025             TYPE     , $MNEW   ;; PROMPT FOR NEW SWR
7617 045222 005046             19$:  CLR      -(SP)   ;; CLEAR COUNTER
7618 045224 005046             CLR      -(SP)     ;; THE NEW SWR
7619 045226 105777 133712             7$:  TSTB     0$TKS   ;; CHAR THERE?
7620 045232 100375             BPL     7$         ;; IF NOT TRY AGAIN

```

```

7621
7622 045234 117746 133706          MOVB  2$TKB, -(SP)      ;; PICK UP CHAR
7623 045240 042716 177600          BIC   #1C177, (SP)    ;; MAKE IT 7-BIT ASCII
7624
7625
7626
7627 045244 021627 000025          9$:   CMP   (SP), #25      ;; IS IT A CONTROL-U?
7628 045250 001005                    BNE   10$                ;; BRANCH IF NOT
7629 045252 104401 046002          TYPE  $CNTLU           ;; YES, ECHO CONTROL-U (+U)
7630 045256 062706 000006          20$:  ADD   #6, SP        ;; IGNORE PREVIOUS INPUT
7631 045262 000757                    BR    19$                ;; LET'S TRY IT AGAIN
7632
7633
7634 045264 021627 000015          10$:  CMP   (SP), #15      ;; IS IT A <CR>?
7635 045270 001022                    BNE   16$                ;; BRANCH IF NO
7636 045272 005766 000004          TST   4(SP)            ;; YES, IS IT THE FIRST CHAR?
7637 045276 001403                    BEQ   11$                ;; BRANCH IF YES
7638 045300 016677 000002 133632  MOV   2(SP), 2$SWR      ;; SAVE NEW SWR
7639 045306 062706 000006          11$:  ADD   #6, SP        ;; CLEAR UP STACK
7640 045312 104401 001211          14$:  TYPE  $CR LF       ;; ECHO <CR> AND <LF>
7641 045316 123727 001135 000001  CMPB  $INTAG, #1       ;; RE-ENABLE TTY KBD INTERRUPTS?
7642 045324 001003                    BNE   15$                ;; BRANCH IF NOT
7643 045326 012777 000100 133610  MOV   #100, 2$TKS     ;; RE-ENABLE TTY KBD INTERRUPTS
7644 045334 000002                    RTI                          ;; RETURN
7645 045336 004737 044412          16$:  JSR   PC, $TYPEPC    ;; ECHO CHAR
7646 045342 021627 000060          CMP   (SP), #60        ;; CHAR < 0?
7647 045346 002420                    BLT   18$                ;; BRANCH IF YES
7648 045350 021627 000067          CMP   (SP), #67        ;; CHAR > 7?
7649 045354 003015                    BGT   18$                ;; BRANCH IF YES
7650 045356 042726 000060          BIC   #50, (SP)+       ;; STRIP-OFF ASCII
7651 045362 005766 000002          TST   2(SP)            ;; IS THIS THE FIRST CHAR
7652 045366 001403                    BEQ   17$                ;; BRANCH IF YES
7653 045370 006316                    ASL   (SP)              ;; NO, SHIFT PRESENT
7654 045372 006316                    ASL   (SP)              ;; CHAR OVER TO MAKE
7655 045374 006316                    ASL   (SP)              ;; ROOM FOR NEW ONE.
7656 045376 005266 000002          17$:  INC   2(SP)        ;; KEEP COUNT OF CHAR
7657 045402 056616 177776          BIS   -2(SP), (SP)     ;; SET IN NEW CHAR
7658 045406 000707                    BR    7$                ;; GET THE NEXT ONE
7659 045410 104401 001210          18$:  TYPE  $QUES        ;; TYPE ?<CR><LF>
7660 045414 000720                    BR    20$                ;; SIMULATE CONTROL-U
7661
7662 .DSABL  LSB
7663
7664
7665 *****
7666 *THIS ROUTINE WILL INPUT A SINGLE CHARACTER FROM THE TTY
7667 *CALL:
7668 *   RDCHR          ;; INPUT A SINGLE CHARACTER FROM THE TTY
7669 *   RETURN HERE   ;; CHARACTER IS ON THE STACK
7670 *                ;; WITH PARITY BIT STRIPPED OFF
7671
7672 $RDCHR: MOV   (SP), -(SP)      ;; PUSH DOWN THE PC
7673 045420 016666 000004 000002  MOV   4(SP), 2(SP)       ;; SAVE THE PS
7674 045426 105777 133512          1$:   TSTB  2$TKS         ;; WAIT FOR
7675 045432 100375                    BPL   1$                ;; A CHARACTER
7676 045434 117766 133506 000004  MOVB  2$TKB, 4(SP)      ;; READ THE TTY

```

```

7677 045442 042766 177600 000004      BIC      #1C(177),4(SP)  ;; GET RID OF JUNK IF ANY
7678 045450 026627 000004 000023      CMP      4(SP),#23      ;; IS IT A CONTROL-S?
7679 045456 001013          BNE          ;; BRANCH IF NO
7680 045460 105777 133460      2$: TSTB     #STKS        ;; WAIT FOR A CHARACTER
7681 045464 100375          BPL      2$        ;; LOOP UNTIL ITS THERE
7682 045466 117746 133454      MOV      #STKB,-(SP)    ;; GET CHARACTER
7683 045472 042716 177600      BIC      #1C,77,(SP)    ;; MAKE IT 7-BIT ASCII
7684 045476 022627 000021      CMP      (SP)+,#21     ;; IS IT A CONTROL-Q?
7685 045502 001366          BNE      2$        ;; IF NOT DISCARD IT
7686 045504 000750          BR       1$        ;; YES, RESUME
7687 045506 026627 000004 000140      3$: CMP      4(SP),#140   ;; IS IT UPPER CASE?
7688 045514 002407          BLT      4$        ;; BRANCH IF YES
7689 045516 026627 000004 000175      CMP      4(SP),#175   ;; IS IT A SPECIAL CHAR?
7690 045524 003003          BGT      4$        ;; BRANCH IF YES
7691 045526 042766 000040 000004      BIC      #40,4(SP)     ;; MAKE IT UPPER CASE
7692 045534 000002      4$: RTI          ;; GO BACK TO USER
7693          ;; *****
7694          ;; *THIS ROUTINE WILL INPUT A STRING FROM THE TTY
7695          ;; *CALL:
7696          ;; *
7697          ;; *      RDLIN          ;; INPUT A STRING FROM THE TTY
7698          ;; *      RETURN HERE    ;; ADDRESS OF FIRST CHARACTER WILL BE ON THE STACK
7699          ;; *      ;; TERMINATOR WILL BE A BYTE OF ALL 0'S
7700          $RDLIN: MOV      R3,-(SP)    ;; SAVE R3
7701 045540 005046          CLR      -(SP)        ;; CLEAR THE RUBOUT KEY
7702 045542 012703 045772      1$: MOV      #STTYIN,R3    ;; GET ADDRESS
7703 045546 022703 046002      2$: CMP      #STTYIN+8.,R3  ;; BUFFER FULL?
7704 045552 101456          BLOS     4$        ;; BR IF YES
7705 045554 104410          RDCR      ;; GO READ ONE CHARACTER FROM THE TTY
7706 045556 112613          MOV      (SP)+,(R3)    ;; GET CHARACTER
7707 045560 122713 000177      10$: CMP      #177,(R3)     ;; IS IT A RUBOUT
7708 045564 001022          BNE     5$        ;; BR IF NO
7709 045566 005716          TST     (SP)        ;; IS THIS THE FIRST RUBOUT?
7710 045570 001007          BNE     6$        ;; BR IF NO
7711 045572 112737 000134 045770      MOV      #' \,9$      ;; TYPE A BACK SLASH
7712 045600 104401 045770      TYPE     9$
7713 045604 012716 177777      MOV      #-1,(SP)     ;; SET THE RUBOUT KEY
7714 045610 005303      6$: DEC      R3        ;; BACKUP BY ONE
7715 045612 020327 045772      CMP      R3,#STTYIN   ;; STACK EMPTY?
7716 045616 103434          BLO     4$        ;; BR IF YES
7717 045620 111337 045770      MOV      (R3),9$     ;; SETUP TO TYPEOUT THE DELETED CHAR.
7718 045624 104401 045770      TYPE     9$
7719 045630 000746          BR      2$        ;; GO TYPE
7720 045632 005716          TST     (SP)        ;; GO READ ANOTHER CHAR.
7721 045634 001406          BEQ     7$        ;; RUBOUT KEY SET?
7722 045636 112737 000134 045770      MOV      #' \,9$      ;; BR IF NO
7723 045644 104401 045770      TYPE     9$
7724 045650 005016          CLR     (SP)        ;; CLEAR THE RUBOUT KEY
7725 045652 122713 000025      7$: CMP      #25,(R3)   ;; IS CHARACTER A CTRL U?
7726 045656 001003          BNE     8$        ;; BR IF NO
7727 045660 104401 046002      TYPE     $CNTLU      ;; TYPE A CONTROL "U"
7728 045664 000726          BR      1$        ;; GO START OVER
7729 045666 122713 000022      8$: CMP      #22,(R3)   ;; IS CHARACTER A "↑R"?
7730 045672 001011          BNE     3$        ;; BRANCH IF NO
7731 045674 105013          CLRB   (R3)        ;; CLEAR THE CHARACTER
7732 045676 104401 001211      TYPE     $CRLF      ;; TYPE A "CR" & "LF"

```

```

7733 045702 104401 045772          TYPE      $TTYIN          ;; TYPE THE INPUT STRING
7734 045706 000717                    BR          2$          ;; GO PICKUP ANOTHER CHAchter
7735 045710 104401 001210          4$:      TYPE      $QUES          ;; TYPE A '?'
7736 045714 000712                    BR          1$          ;; CLEAR THE BUFFER AND LOOP
7737 045716 111337 045770          3$:      MOV      (R3),9$          ;; ECHO THE CHARACTER
7738 045722 104401 045770          TYPE      9$          ;;
7739 045726 122723 000015          CMP      #15,(R3)+          ;; CHECK FOR RETURN
7740 045732 001305                    BNE      2$          ;; LOOP IF NOT RETURN
7741 045734 105063 177777          CLR      -1(R3)          ;; CLEAR RETURN (THE 15)
7742 045740 104401 001212          TYPE      $LF          ;; TYPE A LINE FEED
7743 045744 005726                    TST      (SP)+          ;; CLEAN RUBOUT KEY FROM THE STACK
7744 045746 012603                    MOV      (SP)+,R3          ;; RESTORE R3
7745 045750 011646                    MOV      (SP),-(SP)          ;; ADJUST THE STACK AND PUT ADDRESS OF THE
7746 045752 016666 000004 000002  MOV      4(SP) 2(SP)          ;; FIRST ASCII CHARACTER ON IT
7747 045760 012766 045772 000004  MOV      $TTYIN,4(SP)
7748 045766 000002                    RTI          ;; RETURN
7749 045770 000          9$:      .BYTE      0          ;; STORAGE FOR ASCII CHAR. TO TYPE
7750 045771 000          .BYTE      0          ;; TERMINATOR
7751 045772 000010                    $TTYIN: .BLKB      8          ;; RESERVE 8 BYTES FOR TTY INPUT
7752 046002 052536 005015 000          $CNTLU: .ASCIZ  /↑U/<15><12>          ;; CONTROL "U"
7753 046007 136 006507 000012          $CNTLG: .ASCIZ  /↑G/<15><12>          ;; CONTROL "G"
7754 046014 005015 053523 020122          $MSWR:  .ASCIZ  <15><12>/SWR = /
7755 046022 020075 000          $MNEW:  .ASCIZ  / NEW = /
7756 046025 040 047040 053505
7757 046032 036440 000040
7758 .SBTTL READ AN OCTAL NUMBER FROM THE TTY
7759
7760 *****
7761 *THIS ROUTINE WILL READ AN OCTAL (ASCII) NUMBER FROM THE TTY AND
7762 *CHANGE IT TO BINARY.
7763 *THE INPUT CHARACTERS WILL BE CHECKED TO INSURED THEY ARE LEGAL
7764 *OCTAL DIGITS. IF AN ILLEGAL CHARACTER IS READ A "?" WILL BE TYPED
7765 *FOLLOWED BY A CARRIAGE RETURN-LINE FEED. THE COMPLETE NUMBER MUST
7766 *THEN BE RETYPED. THE INPUT IS TERMINATED BY TYPING A CARRIAGE RETURN.
7767 *CALL:
7768 *      RDOCT          ;; READ AN OCTAL NUMBER
7769 *      RETURN HERE   ;; LOW ORDER BITS ARE ON TOP OF THE STACK
7770 *                   ;; HIGH ORDER BITS ARE IN $HIOCT
7771
7772 046036 011646 000004 000002  $RDOCT: MOV      (SP),-(SP)          ;; PROVIDE SPACE FOR THE
7773 046040 016666                    MOV      4(SP) 2(SP)          ;; INPUT NUMBER
7774 046046 010046                    MOV      R0,-(SP)          ;; PUSH R0 ON STACK
7775 046050 010146                    MOV      R1,-(SP)          ;; PUSH R1 ON STACK
7776 046052 010246                    MOV      R2,-(SP)          ;; PUSH R2 ON STACK
7777 046054 104411          1$:      RDLIN          ;; READ AN ASCII LINE
7778 046056 012600                    MOV      (SP)+,R0          ;; GET ADDRESS OF 1ST CHARACTER
7779 046060 010037 046164          MOV      R0,5$          ;; AND SAVE IT
7780 046064 005001                    CLR      R1          ;; CLEAR DATA WORD
7781 046066 005002                    CLR      R2
7782 046070 112046          2$:      MOV      (R0)+,-(SP)          ;; PICKUP THIS CHARACTER
7783 046072 001420                    BEQ      3$          ;; IF ZERO GET OUT
7784 046074 122716 000060          CMP      #'0,(SP)          ;; MAKE SURE THIS CHARACTER
7785 046100 003026                    BGT      4$          ;; IS AN OCTAL DIGIT
7786 046102 122716 000067          CMP      #'7,(SP)
7787 046106 002423                    BLT      4$
7788 046110 006301                    ASL      R1          ;; *2

```



7789 046112 006102  
7790 046114 006301  
7791 046116 006102  
7792 046120 006301  
7793 046122 006102  
7794 046124 042716 177770  
7795 046130 062601  
7796 046132 000756  
7797 046134 005726  
7798 046136 010166 000012  
7799 046142 010237 046174  
7800 046146 012602  
7801 046150 012601  
7802 046152 012600  
7803 046154 000002  
7804 046156 005726  
7805 046160 105010  
7806 046162 104401  
7807 046164 000000  
7808 046166 104401 001210  
7809 046172 000730  
7810 046174 000000  
7811  
7812  
7813  
7814  
7815  
7816  
7817  
7818  
7819  
7820  
7821  
7822  
7823  
7824  
7825  
7826  
7827  
7828 046176  
7829 046176 010046  
7830 046200 011146  
7831 046202 011246  
7832 046204 010346  
7833 046206 010446  
7834 046210 010546  
7835 046212 016646 000022  
7836 046216 016646 000022  
7837 046222 016646 000022  
7838 046226 016646 000022  
7839 046232 000002  
7840  
7841  
7842  
7843  
7844 046234

```

ROL R2
ASL R1 ;; *4
ROL R2
ASL R1 ;; *8
ROL R2
BIC #1C7 (SP) ;; STRIP THE ASCII JUNK
ADD (SP), R1 ;; ADD IN THIS DIGIT
BR 2$ LOOP
3$: TST (SP)+ ;; CLEAN TERMINATOR FROM STACK
MOV R1, 12(SP) ;; SAVE THE RESULT
MOV R2, $SHIOCT
MOV (SP)+, R2 ;; POP STACK INTO R2
MOV (SP)+, R1 ;; POP STACK INTO R1
MOV (SP)+, R0 ;; POP STACK INTO R0
RTI RETURN
4$: TST (SP)+ ;; CLEAN PARTIAL FROM STACK
CLRB (R0) ;; SET A TERMINATOR
TYPE ;; TYPE UP THRU THE BAD CHAR.
5$: .WORD 0
TYPE $QUES ;; "?" "CR" & "LF"
BR 1$ ;; TRY AGAIN
$SHIOCT: .WORD 0 HIGH ORDER BITS GO HERE
.SBTTL SAVE AND RESTORE R0-R5 ROUTINES
;*****
;SAVE R0-R5
;CALL:
;* SAVREG
;UPON RETURN FROM $SAVREG THE STACK WILL LOOK LIKE:
;*
;*TOP---(+16)
;* +2---(+18)
;* +4---R5
;* +6---R4
;* +8---R3
;*+10---R2
;*+12---R1
;*+14---R0
$SAVREG:
MOV R0, -(SP) ;; PUSH R0 ON STACK
MOV R1, -(SP) ;; PUSH R1 ON STACK
MOV R2, -(SP) ;; PUSH R2 ON STACK
MOV R3, -(SP) ;; PUSH R3 ON STACK
MOV R4, -(SP) ;; PUSH R4 ON STACK
MOV R5, -(SP) ;; PUSH R5 ON STACK
MOV 22(SP), -(SP) ;; SAVE PS OF MAIN FLOW
MOV 22(SP), -(SP) ;; SAVE PC OF MAIN FLOW
MOV 22(SP), -(SP) ;; SAVE PS OF CALL
MOV 22(SP), -(SP) ;; SAVE PC OF CALL
RTI
;*RESTORE R0-R5
;CALL:
;* RESREG
$RESREG:

```

```

7845 046234 012666 000022      MOV      (SP)+,R2(SP)      ;; RESTORE PC OF CALL
7846 046240 012666 000022      MOV      (SP)+,R3(SP)      ;; RESTORE PS OF CALL
7847 046244 012666 000022      MOV      (SP)+,R2(SP)      ;; RESTORE PC OF MAIN FLOW
7848 046250 012666 000022      MOV      (SP)+,R2(SP)      ;; RESTORE PS OF MAIN FLOW
7849 046254 012605              MOV      (SP)+,R5          ;; POP STACK INTO R5
7850 046256 012604              MOV      (SP)+,R4          ;; POP STACK INTO R4
7851 046260 012603              MOV      (SP)+,R3          ;; POP STACK INTO R3
7852 046262 012602              MOV      (SP)+,R2          ;; POP STACK INTO R2
7853 046264 012601              MOV      (SP)+,R1          ;; POP STACK INTO R1
7854 046266 012600              MOV      (SP)+,R0          ;; POP STACK INTO R0
7855 046270 000002      RTI

```

.SBTTL POWER DOWN AND UP ROUTINES

```

7859 ; *****
7860 ; POWER DOWN ROUTINE
7861 046272 017737 132642 004274 $PWRDN: MOV      JSWR,SAVSWR      ;SAVE SWITCH REG
7862 046300 012737 046320 000024      MOV      #SPWRUP,PWRVEC      ;SET UP VECTOR
7863 046306 012737 000340 000026      MOV      #PR7,PWAVEC+2
7864 046314 000000              HALT
7865 046316 000776              BR      -2                  ;HANG UP

```

```

7867 ; *****
7868 ; POWER UP ROUTINE
7869 046320 005037 046410 046412 $PWRUP: CLR      $PWRCT      ;LOOP LOOP TIMER
7870 046324 012737 000144              MOV      #100,$PWRCT+2
7871 046332 005237 046410 15:      INC      $PWRCT      ;WAIT FOR TELETYPE
7872 046336 001375              BNE     15
7873 046340 005337 046412              DEC     $PWRCT+2
7874 046344 001372              BNE     15
7875 046346 012737 046272 000024      MOV      #SPWRDN,PWRVEC      ;SET UP THE POWER DOWN VECTOR
7876 046354 012737 000340 000026      MOV      #PR7,PWAVEC+2
7877 046362 012706 001100              MOV     #STACK,SP          ;FORCE STACK POINTER
7878 046366 104401 046414              TYPE   $POWER             ;TYPE POWER
7879 046372 004737 042360              JSR    PC,CHKPAP          ;CHECK FOR MEMORY CHECK ENABLE OPTION
7880 046376 013777 004274 132534      MOV     SAVSWR,JSWR       ;RESTORE SWITCH REG
7881 046404 000177 132476              JMP    $SLPADR           ;START TEST AGAIN
7882
7883 04641C 000000 000000 042527 $PWRCT: .WORD 0,0          ;COUNTER FOR TELETYPE
7884 046414 005015 047520 $POWER: .ASCIZ '<15><12>/POWER/'
7885 046422 000122

```

.SBTTL EVEN TRAP DECODER

```

7888 ; *****
7889 ; *THIS ROUTINE WILL PICKUP THE LOWER BYTE OF THE "TRAP" INSTRUCTION
7890 ; *AND USE IT TO INDEX THROUGH THE TRAP TABLE FOR THE STARTING ADDRESS
7891 ; *OF THE DESIRED ROUTINE. THEN USING THE ADDRESS OBTAINED IT WILL
7892 ; *GO TO THAT ROUTINE.
7893
7894
7895 046424 010046 000002 $TRAP: MOV      RO,-(SP)      ;; SAVE RO
7896 046426 016600              MOV     2(SP),RO          ;; GET TRAP ADDRESS
7897 046432 005740              TST    -(RO)             ;; BACKUP BY 2
7898 046434 111000              MOVB   (RO),RO          ;; GET RIGHT BYTE OF TRAP
7899 046436 006300              ASL    RO                ;; POSITION FOR INDEXING
7900 046440 016000 046460      MOV     $TRPAD(RO),RO    ;; INDEX TO TABLE

```

```

7901 046444 000200          RTS      R0          ;;GO TO ROUTINE
7902
7903
7904          ;;THIS IS USE TO HANDLE THE "GETPRI" MACRO
7905
7906 046446 011646          $TRAP2: MOV      (SP),-(SP)      ;;MOVE THE PC DOWN
7907 046450 016666 000004 000002      MOV      4(SF),2(SP)      ;;MOVE THE PSW DOWN
7908 046456 000002          RTI          ;;RESTORE THE PSW
7909
7910          .SBTTL  TRAP TABLE
7911
7912          ;*THIS TABLE CONTAINS THE STARTING ADDRESSES OF THE ROUTINES CALLED
7913          ;*BY THE "TRAP" INSTRUCTION.
7914
7915          ;          ROUTINE
7916          ;          -----
7917 046460 046446          $TRAPAD: .WORD  $TRAP2          TRAP+1(104401)  TTY TYPEOUT ROUTINE
7918 046462 044200          $TYPE      ;;CALL=TYPE          TRAP+2(104402)  TYPE OCTAL NUMBER (WITH LEADING ZEROS)
7919 046464 044506          $TYPOC     ;;CALL=TYPOC         TRAP+3(104403)  TYPE OCTAL NUMBER (NO LEADING ZEROS)
7920 046466 044462          $TYPOS     ;;CALL=TYPOS         TRAP+4(104404)  TYPE OCTAL NUMBER (AS PER LAST CALL)
7921 046470 044522          $TYPON     ;;CALL=TYPON         TRAP+5(104405)  TYPE DECIMAL NUMBFR (WITH SIGN)
7922 046472 044710          $TYPDS     ;;CALL=TYPDS
7923
7924 046474 045204          $GTSWR     ;;CALL=GTSWR          TRAP+6(104406)  GET SOFT SWR SETTING
7925
7926 046476 045134          $CKSWR     ;;CALL=CKSWR          TRAP+7(104407)  TEST FOR CHANGE IN SOFT-SWR
7927 046500 045416          $RDCHR     ;;CALL=RDCHR          TRAP+10(104410) TTY TYPEIN CHARACTER ROUTINE
7928 046502 045536          $RDLIN     ;;CALL=RDLIN          TRAP+11(104411) TTY TYPEIN STRING ROUTINE
7929 046504 046036          $RDOCT     ;;CALL=RDOCT          TRAP+12(104412) READ AN OCTAL NUMBER FROM TTY
7930 046506 046176          $SAVREG    ;;CALL=SAVREG          TRAP+13(104413) SAVE R0-R5 ROUTINE
7931 046510 046234          $RESREG    ;;CALL=RESREG          TRAP+14(104414) RESTORE R0-R5 ROUTINE
7932 046512 043224          $SCOPI$   ;;CALL=SCOPI$          TRAP+15(104415) INTERNAL LOOP ON ERROR

```

SBTTL DATA PRINTED BY ERROR ROUTINES

7933									
7934									
7935	046514	001220	004272		DT000:	.WORD	\$TESTN,TRAPPC		
7936	046520	001220	001116	004160	DT001:	.WORD	\$TESTN,\$ERRPC,E.CS1,T.CS1,E.MR2,T.MR2,E.MR3,T.MR3		
7937	046526	004120	004206	004146					
7938	046534	004210	004150						
7939	046540	001220	001116	004160	DT002:	.WORD	\$TESTN,\$ERRPC,E.CS1,T.CS1,DRVCOD,E.MR2,T.MR2,E.MR3,T.MR3		
7940	046546	004120	004244	004206					
7941	046554	004146	004210	004150					
7942	046562	001220	001116	004160	DT006:	.WORD	\$TESTN,\$ERRPC,E.CS1,T.CS1,HDCODE,E.MR2,T.MR2,E.MR3,T.MR3		
7943	046570	004120	004250	004206					
7944	046576	004146	004210	004150					
7945	046604	001220	001116	004160	DT012:	.WORD	\$TESTN,\$ERRPC,E.CS1,T.CS1,E.MR1,T.MR1,MSGCOD		
7946	046612	004120	004204	004144					
7947	046620	004246							
7948	046622	004206	004146	004210		.WORD	E.MR2,T.MR2,E.MR3,T.MR3		
7949	046630	004150							
7950	046632	001220	001116	004160	DT017:	.WORD	\$TESTN,\$ERRPC,E.CS1,T.CS1,CYLIN,E.MR2,T.MR2,E.MR3,T.MR3		
7951	046640	004120	004252	004206					
7952	046646	004146	004210	004150					
7953	046654	001220	001116	004160	DT031:	.WORD	\$TESTN,\$ERRPC,E.CS1,T.CS1,OFFVAL,E.MR2,T.MR2,E.MR3,T.MR3		
7954	046662	004120	004254	004206					
7955	046670	004146	004210	004150					
7956	046676	001220	001116	004160	DT035:	.WORD	\$TESTN,\$ERRPC,E.CS1,T.CS1,CYLIN,OFFVAL		
7957	046704	004120	004252	004254					
7958	046712	004206	004146	004210		.WORD	E.MR2,T.MR2,E.MR3,T.MR3		
7959	046720	004150							
7960	046722	001220	001116	004230	DT050:	.WORD	\$TESTN,\$ERRPC,U.MR2,U.MR3,SFTCNT,E.MR2,T.MR2,E.MR3,T.MR3		
7961	046730	004232	004256	004206					
7962	046736	004146	004210	004150					
7963	046744	001220	001116	004210	DT052:	.WORD	\$TESTN,\$ERRPC,E.MR3,T.MR3,E.MR2,T.MR2		
7964	046752	004150	004206	004146					
7965	046760	001220	001116	004160	DT062:	.WORD	\$TESTN,\$ERRPC,E.CS1,T.CS1,E.CS2,T.CS2,E.DS,T.DS,E.ER,T.ER		
7966	046766	004120	004170	004130					
7967	046774	004172	004132	004174					
7968	047002	004134							
7969	047004	001220	001116	004160	DT065:	.WORD	\$TESTN,\$ERRPC,E.CS1,T.CS1		
7970	047012	004120							
7971	047014	001220	001116	004206	DT067:	.WORD	\$TESTN,\$ERRPC,E.MR2,T.MR2,E.MR3,T.MR3		
7972	047022	004146	004210	004150					
7973	047030	001220	001116		DT100:	.WORD	\$TESTN,\$ERRPC		
7974	047034	001220	001116	004160	DT126:	.WORD	\$TESTN,\$ERRPC,E.CS1,T.CS1		
7975	047042	004120							
7976	047044	001220	001116	004160	DT224:	.WORD	\$TESTN,\$ERRPC,E.CS1,T.CS1,E.CS2,T.CS2,E.DS,T.DS		
7977	047052	004120	004170	004130					
7978	047060	004172	004132						
7979	047064	004174	004134	004220		.WORD	E.ER,T.ER,P.CS1,P.CS2,P.DS,P.ER		
7980	047072	004222	004224	004226					
7981	047100	001220	001116	004266	DT230:	.WORD	\$TESTN,\$ERRPC,DRV TYP,CYLIN,HDCODE,E.CS1,T.CS1,E.CS2,T.CS2		
7982	047106	004252	004250	004160					
7983	047114	004120	004170	004130					
7984	047122	004172	004132	004174		.WORD	E.DS,T.DS,E.ER,T.ER		
7985	047130	004134							
7986	047132	001220	001116	004160	DT256:	.WORD	\$TESTN,\$ERRPC,E.CS1,T.CS1,E.ER,T.ER,ILLFUN		
7987	047140	004120	004174	004134					
7988	047146	004270							

7989  
7990  
7991 047150 000001  
7992 047152 002 000  
7993 047154 000007  
7994 047156 000 000  
7995 047160 050207  
7996 047162 000 000  
7997 047164 050225  
7998 047166 002 000  
7999 047170 050271  
8000 047172 000 000  
8001 047174 050310  
8002 047176 002 000  
8003 047200 050326  
8004 047202 000 000  
8005 047204 050365  
8006 047206 004 000  
8007 047210 000007  
8008 047212 000 000  
8009 047214 050207  
8010 047216 000 000  
8011 047220 050225  
8012 047222 002 000  
8013 047224 050424  
8014 047226 000 000  
8015 047230 050452  
8016 047232 003 000  
8017 047234 050326  
8018 047236 000 000  
8019 047240 050365  
8020 047242 004 000  
8021 047244 000007  
8022 047246 000 000  
8023 047250 050207  
8024 047252 000 000  
8025 047254 050225  
8026 047256 002 000  
8027 047260 050501  
8028 047262 000 000  
8029 047264 050526  
8030 047266 003 000  
8031 047270 050326  
8032 047272 000 000  
8033 047274 050365  
8034 047276 004 000  
8035 047300 000007  
8036 047302 000 000  
8037 047304 050207  
8038 047306 000 000  
8039 047310 050225  
8040 047312 002 000  
8041 047314 050552  
8042 047316 000 000  
8043 047320 050617  
8044 047322 005 000

.SBTTL DATA FORMATS

DF000: .WORD 1  
.BYTE 2,0  
DF001: .WORD 7 ;ERROR 1  
.BYTE 0,0  
.WORD DH000A  
.BYTE 0,0  
.WORD DH000B  
.BYTE 2,0  
.WORD DH001A  
.BYTE 0,0  
.WORD DH001B  
.BYTE 2,0  
.WORD DH001C  
.BYTE 0,0  
.WORD DH001D  
.BYTE 4,0  
DF002: .WORD 7 ;ERRORS 2-5  
.BYTE 0,0  
.WORD DH000A  
.BYTE 0,0  
.WORD DH000B  
.WORD DH002A  
.BYTE 0,0  
.WORD DH002B  
.BYTE 3,0  
.WORD DH001C  
.BYTE 0,0  
.WORD DH001D  
.BYTE 4,0  
DF006: .WORD 7 ;ERRORS 6-11  
.BYTE 0,0  
.WORD DH000A  
.BYTE 0,0  
.WORD DH000B  
.BYTE 2,0  
.WORD DH006A  
.BYTE 0,0  
.WORD DH006B  
.BYTE 3,0  
.WORD DH001C  
.BYTE 0,0  
.WORD DH001D  
.BYTE 4,0  
DF012: .WORD 7 ;ERRORS12-16  
.BYTE 0,0  
.WORD DH000A  
.BYTE 0,0  
.WORD DH000B  
.BYTE 2,0  
.WORD DH012A  
.BYTE 0,0  
.WORD DH012B  
.BYTE 5,0

8045	047324	050326		.WORD	DH001C	
8046	047326	000	000	.BYTE	0,0	
8047	047330	050365		.WORD	DH001D	
8048	047332	004	000	.BYTE	4,0	
8049	047334	000007		.WORD	7	; ERRORS 17-30
8050	047336	000	000	.BYTE	0,0	
8051	047340	050207		.WORD	DH000A	
8052	047342	000	000	.BYTE	0,0	
8053	047344	050225		.WORD	DH000B	
8054	047346	002	000	.BYTE	2,0	
8055	047350	050665		.WORD	DH017A	
8056	047352	000	000	.BYTE	0,0	
8057	047354	050713		.WORD	DH017B	
8058	047356	003	000	.BYTE	3,0	
8059	047360	050326		.WORD	DH001C	
8060	047362	000	000	.BYTE	0,0	
8061	047364	050365		.WORD	DH001D	
8062	047366	004	000	.BYTE	4,0	
8063	047370	000007		.WORD	7	; ERRORS 31-34
8064	047372	000	000	.BYTE	0,0	
8065	047374	050207		.WORD	DH000A	
8066	047376	000	000	.BYTE	0,0	
8067	047400	050225		.WORD	DH000B	
8068	047402	002	000	.BYTE	2,0	
8069	047404	050737		.WORD	DH031A	
8070	047406	000	000	.BYTE	0,0	
8071	047410	050766		.WORD	DH031B	
8072	047412	003	000	.BYTE	3,0	
8073	047414	050326		.WORD	DH001C	
8074	047416	000	000	.BYTE	0,0	
8075	047420	050365		.WORD	DH001D	
8076	047422	004	000	.BYTE	4,0	
8077	047424	000007		.WORD	7	; ERROR 35-41
8078	047426	000	000	.BYTE	0,0	
8079	047430	050207		.WORD	DH000A	
8080	047432	000	000	.BYTE	0,0	
8081	047434	050225		.WORD	DH000B	
8082	047436	002	000	.BYTE	2,0	
8083	047440	051014		.WORD	DH035A	
8084	047442	000	000	.BYTE	0,0	
8085	047444	051053		.WORD	DH035B	
8086	047446	004	000	.BYTE	4,0	
8087	047450	050326		.WORD	DH001C	
8088	047452	000	000	.BYTE	0,0	
8089	047454	050365		.WORD	DH001D	
8090	047456	004	000	.BYTE	4,0	
8091	047460	000007		.WORD	7	; ERRORS 50 & 51
8092	047462	000	000	.BYTE	0,0	
8093	047464	050207		.WORD	DH000A	
8094	047466	000	000	.BYTE	0,0	
8095	047470	050225		.WORD	DH000B	
8096	047472	002	000	.BYTE	2,0	
8097	047474	051111		.WORD	DH050A	
8098	047476	000	000	.BYTE	0,0	
8099	047500	051137		.WORD	DH050B	
8100	047502	003	000	.BYTE	3,0	

8101	047504	050326	.	WORD	DH001C	
8102	047506	000	000	.BYTE	0,0	
8103	047510	050365	.	WORD	DH001D	
8104	047512	004	000	.BYTE	4,0	
8105	047514	000005		DF052: .WORD	5,0	:ERRORS 52-61
8106	047516	000	000	.BYTE	0,0	
8107	047520	050207	.	WORD	DH000A	
8108	047522	000	000	.BYTE	0,0	
8109	047524	050225	.	WORD	DH000B	
8110	047526	002	000	.BYTE	2,0	
8111	047530	050326	.	WORD	DH001C	
8112	047532	000	000	.BYTE	0,0	
8113	047534	050365	.	WORD	DH001D	
8114	047536	004	000	.BYTE	4,0	
8115	047540	000005		DF062: .WORD	5,0	:ERRORS 62-64
8116	047542	000	000	.BYTE	0,0	
8117	047544	050207	.	WORD	DH000A	
8118	047546	000	000	.BYTE	0,0	
8119	047550	050225	.	WORD	DH000B	
8120	047552	002	000	.BYTE	2,0	
8121	047554	051165	.	WORD	DH062A	
8122	047556	000	000	.BYTE	0,0	
8123	047560	051264	.	WORD	DH062B	
8124	047562	010	000	.BYTE	8,0	
8125	047564	000005		DF065: .WORD	5,0	:ERRORS-65-66
8126	047566	000	000	.BYTE	0,0	
8127	047570	050207	.	WORD	DH000A	
8128	047572	000	000	.BYTE	0,0	
8129	047574	050225	.	WORD	DH000B	
8130	047576	002	000	.BYTE	2,0	
8131	047600	050271	.	WORD	DH001A	
8132	047602	000	000	.BYTE	0,0	
8133	047604	050310	.	WORD	DH001B	
8134	047606	002	000	.BYTE	2,0	
8135	047610	000005		DF067: .WORD	5,0	:ERRORS 67-70
8136	047612	000	000	.BYTE	0,0	
8137	047614	050207	.	WORD	DH000A	
8138	047616	000	000	.BYTE	0,0	
8139	047620	050225	.	WORD	DH000B	
8140	047622	002	000	.BYTE	2,0	
8141	047624	051361	.	WORD	DH067A	
8142	047626	000	000	.BYTE	0,0	
8143	047630	051420	.	WORD	DH067B	
8144	047632	004	000	.BYTE	4,0	
8145	047634	000003		DF100: .WORD	3,0	:ERROR 100
8146	047636	000	000	.BYTE	0,0	
8147	047640	050207	.	WORD	DH000A	
8148	047642	000	000	.BYTE	0,0	
8149	047644	050225	.	WORD	DH000B	
8150	047646	002	000	.BYTE	2,0	
8151	047650	000005		DF126: .WORD	5,0	:ERROR 126
8152	047652	000	000	.BYTE	0,0	
8153	047654	050207	.	WORD	DH000A	
8154	047656	000	000	.BYTE	0,0	
8155	047660	050225	.	WORD	DH000B	
8156	047662	002	000	.BYTE	2,0	

8157	047664	051456		.WORD	DH126A	
8158	047666	000	000	.BYTE	0,0	
8159	047670	051475		.WORD	DH126B	
8160	047672	002	000	.BYTE	2,0	
8161	047674	000007		.WORD	7,0	:ERRORS 224-227
8162	047676	000	000	.BYTE	0,0	
8163	047700	050207		.WORD	DH060A	
8164	047702	000	000	.BYTE	0,0	
8165	047704	050225		.WORD	DH000B	
8166	047706	002	000	.BYTE	2,0	
8167	047710	051165		.WORD	DH062A	
8168	047712	000	000	.BYTE	0,0	
8169	047714	051264		.WORD	DH062B	
8170	047716	010	000	.BYTE	8,0	
8171	047720	051513		.WORD	DH224A	
8172	047722	000	000	.BYTE	0,0	
8173	047724	051546		.WORD	DH224B	
8174	047726	004	000	.BYTE	4,0	
8175	047730	000007		.WORD	7,0	:ERRORS 230-233
8176	047732	000	000	.BYTE	0,0	
8177	047734	050207		.WORD	DH000A	
8178	047736	000	000	.BYTE	0,0	
8179	047740	050225		.WORD	DH000B	
8180	047742	002	000	.BYTE	2,0	
8181	047744	051603		.WORD	DH230A	
8182	047746	000	000	.BYTE	0,0	
8183	047750	051630		.WORD	DH230B	
8184	047752	003	000	.BYTE	3,0	
8185	047754	051165		.WORD	DH062A	
8186	047756	000	000	.BYTE	0,0	
8187	047760	051264		.WORD	DH062B	
8188	047762	010	000	.BYTE	8,0	
8189	047764	000005		.WORD	5,0	:ERROR 256
8190	047766	000	000	.BYTE	0,0	
8191	047770	050207		.WORD	DH000A	
8192	047772	000	000	.BYTE	0,0	
8193	047774	050225		.WORD	DH000B	
8194	047776	002	000	.BYTE	2,0	
8195	050000	051654		.WORD	DH256A	
8196	050002	000	000	.BYTE	0,0	
8197	050004	051720		.WORD	DH256B	
8198	050006	005	000	.BYTE	5,0	



```

8199
8200 .SBTTL ASCII MESSAGES
8201 050010 005015 045522 030466 OPRO01: .ASCIZ '<15><12>/RK611 BUS ADDRESS ('
8202 050016 020061 052502 020123
8203 050024 042101 051104 051505
8204 050032 020123 020050 000
8205 050037 040 020051 020075 OPRO02: .ASCIZ '/ ) = /
8206 050044 000
8207 050045 122 033113 030461 OPRO03: .ASCIZ '/RK611 VECTOR ADDRESS (' /
8208 050052 053040 041505 047524
8209 050060 020122 042101 051104
8210 050066 051505 020123 020050
8211 050074 000
8212 050075 122 033113 030461 OPRO04: .ASCIZ '/RK611 PRIORITY (' /
8213 050102 050040 044522 051117
8214 050110 052111 020131 020050
8215 050116 000
8216 050117 040 000040 SPACE2: .ASCIZ '/ /
8217 050122 005015 051120 043517 ABORT: .ASCIZ '<15><12>/PROGRAM ABORTED BECAUSE ERROR THRESHOLD EXCEEDED/<15><12>'
8218 050130 040522 020115 041101
8219 050136 051117 042524 020104
8220 050144 042502 040503 051525
8221 050152 020105 051105 047522
8222 050160 020122 044124 042522
8223 050166 044123 046117 020104
8224 050174 054105 042503 042105
8225 050202 042105 005015 000

```

				.SBTTL DATA HEADERS					
8226									
8227									
8228	050207	124	051505	020124	DH000A: .ASCIZ	/TEST	ERROR/		
8229	050214	020040	042440	051122					
8230	050222	051117	000						
8231	050225	116	046525	020040	DH000B: .ASCIZ	/NUM	PC/		
8232	050232	020040	050040	000103					
8233	050240	042524	052123	020040	DH000C: .ASCII	/TEST	TRAP/<15><12>		
8234	050246	020040	051124	050101					
8235	050254	005015							
8236	050256	052516	020115	020040		.ASCIZ	/NUM	PC/	
8237	050264	020040	041520	000					
8238	050271	105	050130	041505	DH001A: .ASCIZ	/EXPECT	ACTUAL/		
8239	050276	020124	040440	052103					
8240	050304	040525	000114						
8241	050310	045522	051503	020061	DH001B: .ASCIZ	/RKCS1	RKCS1/		
8242	050316	020040	045522	051503					
8243	050324	000061							
8244	050326	054105	042520	052103	DH001C: .ASCIZ	/EXPECT	ACTUAL EXPECT ACTUAL/		
8245	050334	020040	041501	052524					
8246	050342	046101	020040	054105					
8247	050350	042520	052103	020040					
8248	050356	041501	052524	046101					
8249	050364	000							
8250	050365	115	051505	020123	DH001D: .ASCIZ	/MESS A	MESS A MESS B MESS B/		
8251	050372	020101	046440	051505					
8252	050400	020123	020101	046440					
8253	050406	051505	020123	020102					
8254	050414	046440	051505	020123					
8255	050422	000102							
8256	050424	054105	042520	052103	DH002A: .ASCIZ	/EXPECT	ACTUAL DRIVE/		
8257	050432	020040	041501	052524					
8258	050440	046101	020040	051104					
8259	050446	053111	000105						
8260	050452	045522	051503	020061	DH002B: .ASCIZ	/RKCS1	RKCS1 SELECT/		
8261	050460	020040	045522	051503					
8262	050466	020061	020040	042523					
8263	050474	042514	052103	000					
8264	050501	105	050130	041505	DH006A: .ASCIZ	/EXPECT	ACTUAL HEAD/		
8265	050506	020124	040440	052103					
8266	050514	040525	020114	044040					
8267	050522	040505	000104						
8268	050526	045522	051503	020061	DH006B: .ASCIZ	/RKCS1	RKCS1 ADD/		
8269	050534	020040	045522	051503					
8270	050542	020061	020040	042101					
8271	050550	000104							
8272	050552	054105	042520	052103	DH012A: .ASCIZ	/EXPECT	ACTUAL EXPECT ACTUAL MESS/		
8273	050560	020040	041501	052524					
8274	050566	046101	020040	054105					
8275	050574	042520	052103	020040					
8276	050602	041501	052524	046101					
8277	050610	020040	042515	051523					
8278	050616	000							
8279	050617	122	041513	030523	DH012B: .ASCIZ	/RKCS1	RKCS1 RKMR1 RKMR1 SELECT/		
8280	050624	020040	051040	041513					
8281	050632	030523	020040	051040					





.SBTTL ERROR MESSAGES

8392					
8393					
8394	01.766	047125	054105	042520	EM000: .ASCIZ /UNEXPECTED MEMORY PARITY ENABLE TRAP/
8395	051774	052103	042105	046440	
8396	052002	046505	051117	020131	
8397	052010	040523	044522	054524	
8398	052016	042440	040516	046102	
8399	052024	020105	051124	050101	
8400	052032	000			
8401	052033	101	052124	046505	EM100: .ASCIZ /ATTEMPTING A SELECT IN 24 SECTOR FORMAT IN MAINT MODE/
8402	052040	052120	047111	020107	
8403	052046	020101	042523	042514	
8404	052054	052103	044440	020116	
8405	052062	032062	051440	041505	
8406	052070	047524	020122	047506	
8407	052076	046522	052101	044440	
8408	052104	020116	040515	047111	
8409	052112	020124	047515	042504	
8410	052120	000			
8411	052121	101	052124	046505	EM101: .ASCIZ /ATTEMPTING A DRIVE CLEAR IN MAINT MODE/
8412	052126	052120	047111	020107	
8413	052134	020101	051104	053111	
8414	052142	020105	046103	040505	
8415	052150	020122	047111	046440	
8416	052156	044501	052116	046440	
8417	052164	042117	000105		
8418	052170	052101	042524	050115	EM102: .ASCIZ /ATTEMPTING A UNLOAD IN MAINT MODE/
8419	052176	044524	043516	040440	
8420	052204	052440	046116	040517	
8421	052212	020104	047111	046440	
8422	052220	044501	052116	046440	
8423	052226	042117	000105		
8424	052232	052101	042524	050115	EM103: .ASCIZ /ATTEMPTING A PACK ACKNOWLEDGE IN MAINT MODE/
8425	052240	044524	043516	040440	
8426	052246	050040	041501	020113	
8427	052254	041501	047113	053517	
8428	052262	042514	043504	020105	
8429	052270	047111	046440	044501	
8430	052276	052116	046440	042117	
8431	052304	000105			
8432	052306	052101	042524	050115	EM104: .ASCIZ /ATTEMPTING A RECALIBRATE IN MAINT MODE/
8433	052314	044524	043516	040440	
8434	052322	051040	041505	046101	
8435	052330	041111	040522	042524	
8436	052336	044440	020116	040515	
8437	052344	047111	020124	047515	
8438	052352	042504	000		
8439	052355	101	052124	046505	EM105: .ASCIZ /ATTEMPTING A START SPINDLE/
8440	052362	052120	047111	020107	
8441	052370	020101	052123	051101	
8442	052376	020124	050123	047111	
8443	052404	046104	000105		
8444	052410	052101	042524	050115	EM106: .ASCIZ /ATTEMPTING A SELECT USING ALL DRIVE SELECTION CONFIGS IN MAINT MODE/
8445	052416	044524	043516	040440	
8446	052424	051440	046105	041505	
8447	052432	020124	051525	047111	

8448	052440	020107	046101	020114	
8449	052446	051104	053111	020105	
8450	052454	042523	042514	052103	
8451	052462	047511	020116	047503	
8452	052470	043116	043511	020123	
8453	052476	047111	046440	044501	
8454	052504	052116	046440	042117	
8455	052512	000105			
8456	052514	052101	042524	050115	EM107: .ASCIZ /ATTEMPTING A SELECT USING ALL HEAD ADD CONFIGS IN MAINT MODE/
8457	052522	044524	043516	040440	
8458	052530	051440	046105	041505	
8459	052536	020124	051525	047111	
8460	052544	020107	046101	020114	
8461	052552	042510	042101	040440	
8462	052560	042104	041440	047117	
8463	052566	044506	051507	044440	
8464	052574	020116	040515	047111	
8465	052602	020124	047515	042504	
8466	C-2610	000			
8467	052611	101	052124	046505	EM108: .ASCIZ /ATTEMPTING A SELECT USING ALL MESS SELECT CONFIGS IN MAINT MODE/
8468	052616	052120	047111	020107	
8469	052624	020101	042523	042514	
8470	052632	02103	052440	044523	
8471	052640	043516	040440	046114	
8472	052646	046440	051505	020123	
8473	052654	042523	042514	052103	
8474	052662	041440	047117	044506	
8475	052670	051507	044440	020116	
8476	052676	040515	047111	020124	
8477	052704	047515	042504	000	
8478	052711	101	052124	046505	EM109: .ASCIZ /ATTEMPTING A SEEK TO AN RK06 IN MAINT MODE/
8479	052716	052120	047111	020107	
8480	052724	020101	042523	045505	
8481	052732	052040	020117	047101	
8482	052740	051040	030113	020066	
8483	052746	047111	046440	044501	
8484	052754	052116	046440	042117	
8485	052762	000105			
8486	052764	052101	042524	050115	EM110: .ASCIZ /ATTEMPTING A SEEK WITH CDT SET IN MAINT MODE/
8487	052772	044524	043516	040440	
8488	053000	051440	042505	020113	
8489	053006	044527	044124	041440	
8490	053014	052104	051440	052105	
8491	053022	044440	020116	040515	
8492	053030	047111	020124	047515	
8493	053036	042504	000		
8494	053041	101	052124	046505	EM111: .ASCIZ /ATTEMPTING AN OFFSET IN MAINT MODE/
8495	053046	052120	047111	020107	
8496	053054	047101	047440	043106	
8497	053062	042523	020124	047111	
8498	053070	046440	044501	052116	
8499	053076	046440	042117	000105	
8500	053104	052101	042524	050115	EM112: .ASCII /ATTEMPTING COMMAND WITH NON-ZERO CYLINDER ADDRESS AND/<15><12>
8501	053112	044524	043516	041440	
8502	053120	046517	040515	042116	
8503	053126	053440	052111	020110	

8504	053134	047516	026516	042532	
8505	053142	047522	041440	046131	
8506	053150	047111	042504	020122	
8507	053156	042101	051104	051505	
8508	053164	070123	047101	006504	
8509	053172	012			
8510	053173	116	047117	055055	.ASCIZ /NON-ZERO OFFSET IN MAINTENANCE MODE/
8511	053200	051105	020117	043117	
8512	053206	051506	052105	044440	
8513	053214	020116	040515	047111	
8514	053222	042524	040516	041516	
8515	053230	020105	047515	042504	
8516	053236	000			
8517	053237	101	052124	046505	EM113: .ASCII /ATTEMPTING COMMAND WITH NON-ZERO MESSAGE SELECT CODE/<15><12>
8518	053244	052120	047111	020107	
8519	053252	047503	046515	047101	
8520	053260	020104	044527	044124	
8521	053266	047040	047117	055055	
8522	053274	051105	020117	042515	
8523	053302	051523	043501	020105	
8524	053310	042523	042514	052103	
8525	053316	041440	042117	006505	
8526	053324	012			
8527	053325	111	020116	040515	.ASCIZ /IN MAINTENANCE MODE/
8528	053332	047111	042524	040516	
8529	053340	041516	020105	047515	
8530	053346	042504	000		
8531	053351	101	052124	046505	EM114: .ASCIZ /ATTEMPTING TO SHIFT DRIVE MESSAGES/
8532	053356	052120	047111	020107	
8533	053364	047524	051440	044510	
8534	053372	052106	042040	044522	
8535	053400	042526	046440	051505	
8536	053406	040523	042507	000123	
8537	053414	052101	042524	050115	EM115: .ASCIZ /ATTEMPTING TO GENERATE ODD PARITY ON SELECT DRIVE MESSAGE/
8538	053422	044524	043516	052040	
8539	053430	020117	042507	042516	
8540	053436	040522	042524	047440	
8541	053444	042104	050040	051101	
8542	053452	052111	020131	047117	
8543	053460	051440	046105	041505	
8544	053466	020124	051104	053111	
8545	053474	020105	042515	051523	
8546	053502	043501	000105		
8547	053506	052101	042524	050115	EM116: .ASCIZ /ATTEMPTING TO GENERATE EVEN PARITY ON SELECT DRIVE MESSAGE/
8548	053514	044524	043516	052040	
8549	053522	020117	042507	042516	
8550	053530	040522	042524	042440	
8551	053536	042526	020116	040520	
8552	053544	044522	054524	047440	
8553	053552	020116	042523	042514	
8554	053560	052103	042040	044522	
8555	053566	042526	046440	051505	
8556	053574	040523	042507	000	
8557	053601	101	052124	046505	EM117: .ASCII /ATTEMPTING COMPLETE EXECUTION OF DESELECT DRIVE COMMAND/
8558	053606	052120	047111	020107	
8559	053614	047503	050115	042514	

8560	053622	042524	042530	
8561	053630	042503	042524	
8562	053638	042540	020106	042504
8563	053644	042523	042514	052103
8564	053652	042040	042522	042526
8565	053660	041440	046517	040515
8566	053666	042116		
8567	053670	005015	047111	046440
8568	053676	044501	052116	047105
8569	053704	047101	042503	046440
8570	053712	042117	000105	
8571	053716	052101	042524	050115
8572	053724	044524	043516	041440
8573	053732	046517	046120	052105
8574	053740	020105	054105	041505
8575	053746	052125	047511	020116
8576	053754	043117	051440	046105
8577	053762	041505	020124	051104
8578	053770	053111	020105	047503
8579	053776	046515	047101	104
8580	054003	015	044412	020116
8581	054010	040515	047111	042524
8582	054016	040516	041516	020105
8583	054024	047515	042504	000
8584	054031	101	052124	046505
8585	054036	052120	047111	020107
8586	054044	054105	041505	052125
8587	054052	047511	020116	043117
8588	054060	042040	051505	046105
8589	054066	041505	020124	051104
8590	054074	053111	020105	052101
8591	054102	047040	051117	040515
8592	054110	020114	050123	042505
8593	054116	000104		
8594	054120	052101	042524	050115
8595	054126	044524	043516	052040
8596	054134	020117	051127	052111
8597	054142	020105	047503	046515
8598	054150	047101	020104	047101
8599	054156	020104	052123	052101
8600	054164	051525	051040	043505
8601	054172	020056	020061	047111
8602	054200	046440	044501	052116
8603	054206	046440	042117	000105
8604	054214	052101	042524	050115
8605	054222	044524	043516	042440
8606	054230	042530	052503	044524
8607	054236	047117	047440	020106
8608	054244	042504	042523	042514
8609	054252	052103	042040	044522
8610	054260	042526	053440	052111
8611	054266	020110	047111	042524
8612	054274	051122	050125	020124
8613	054302	047105	041101	042514
8614	054310	051440	052105	000
8615	054315	101	052124	046505

EM118: .ASCII /ATTEMPTING COMPLETE EXECUTION OF SELECT DRIVE COMMAND/

EM119: .ASCIZ /ATTEMPTING EXECUTION OF DESELECT DRIVE AT NORMAL SPEED/

EM120: .ASCIZ ATTEMPTING TO WRITE COMMAND AND STATUS REG. 1 IN MAINT MODE/

EM121: .ASCIZ ATTEMPTING EXECUTION OF DESELECT DRIVE WITH INTERRUPT ENABLE SET/

EM122: .ASCII ATTEMPTING DESELECT COMMAND AFTER WRITING SILO



8616	054322	052120	047111	020107
8617	054330	042504	042523	042514
8618	054336	052103	041440	046517
8619	054344	040515	042116	040440
8620	054352	052106	051105	053440
8621	054360	044522	044524	043516
8622	054366	051440	046111	020117
8623	054374	047524	041440	042510
8624	054402	045503	043344	020117
8625	054410	046103	040505	000122
8626	054416	052101	042524	050115
8627	054424	044524	043516	041440
8628	054432	046517	046120	052105
8629	054440	020105	054105	041505
8630	054446	052125	047511	020116
8631	054454	043117	051440	042505
8632	054462	020113	047111	046440
8633	054470	044501	052116	046440
8634	054476	042117	000105	
8635	054502	052101	042524	050115
8636	054510	044524	043516	051440
8637	054516	046105	041505	020124
8638	054524	051104	053111	020105
8639	054532	047111	046440	044501
8640	054540	052116	046440	042117
8641	054546	000105		
8642	054550	052101	042524	050115
8643	054556	044524	043516	041440
8644	054564	042510	045503	021040
8645	054572	047514	042101	051440
8646	054600	040524	052524	021123
8647	054606	041040	020101	047506
8648	054614	041522	047111	006507
8649	054622	012		
8650	054623	104	044522	042526
8651	054630	040440	040526	046111
8652	054636	040511	046102	026105
8653	054644	051440	042520	042105
8654	054652	046040	051517	026123
8655	054660	053040	046117	046525
8656	054666	020105	040526	044514
8657	054674	026104	005015	
8658	054700	043117	051506	052105
8659	054706	020054	051104	053111
8660	054714	020105	042522	042101
8661	054722	026131	040440	042116
8662	054730	053440	044522	042524
8663	054736	046040	041517	006513
8664	054744	012		
8665	054745	104	044522	042526
8666	054752	051440	040524	052524
8667	054760	020123	042522	027107
8668	054766	000		
8669	054767	101	052124	046505
8670	054774	052120	047111	020107
8671	055002	047524	043040	051117

.ASCIZ /TO CHECK GO CLEAR/

EM123: .ASCIZ /ATTEMPTING COMPLETE EXECUTION OF SEEK IN MAINT MODE

EM124: .ASCIZ /ATTEMPTING SELECT DRIVE IN MAINT MODE

EM125: .ASCII /ATTEMPTING CHECK "LOAD STATUS" BY FORCING/((15)<(12)

.ASCII /DRIVE AVAILIABLE, SPEED LOSS, VOLUME VALID,/((15)<(12)

ASCII /OFFSET, DRIVE READY, AND WRITE LOCK/((15)<(12)

.ASCIZ /DRIVE STATUS REG./

EM126: .ASCIZ /ATTEMPTING TO FORCE DRIVE AVAILIABLE/

8672	055010	042503	042040	044522	
8673	055016	042526	040440	040526	
8674	055024	046111	040511	046102	
8675	055032	000105			
8676	055034	052101	042524	050115	EM127: .ASCII /ATTEMPTING TO FORCE DRIVE BUS PARITY ERROR/<15><12>
8677	055042	044524	043516	052040	
8678	055050	020117	047506	041522	
8679	055056	020105	051104	053111	
8680	055064	020105	052502	020123	
8681	055072	040520	044522	054524	
8682	055100	042440	051122	051117	
8683	055106	005015			
8684	055110	042504	042524	052103	.ASCIZ /DETECTED BY RK611/
8685	055116	042105	041040	020131	
8686	055124	045522	030466	000061	
8687	055132	052101	042524	050115	EM128: .ASCIZ /ATTEMPTING TO FORCE DRIVE AVAILIABLE RESET ERROR
8688	055140	044524	043516	052040	
8689	055146	020117	047506	041522	
8690	055154	020105	051104	053111	
8691	055162	020105	053101	044501	
8692	055170	044514	041101	042514	
8693	055176	051040	051505	052105	
8694	055204	042440	051122	051117	
8695	055212	000			
8696	055213	124	051505	044524	EM129: .ASCIZ /TESTING CDT SET DRIVE TYPE DETECTION/
8697	055220	043516	041440	052104	
8698	055226	051440	052105	042040	
8699	055234	044522	042526	052040	
8700	055242	050131	020105	042504	
8701	055250	042524	052103	047511	
8702	055256	000116			
8703	055260	052101	042524	050115	EM130: .ASCIZ /ATTEMPTING TO FORCE DRIVE TYPE ERROR WITH CDT SET/
8704	055266	044524	043516	052040	
8705	055274	020117	047506	041522	
8706	055302	020105	051104	053111	
8707	055310	020105	054524	042520	
8708	055316	042440	051122	051117	
8709	055324	053440	052111	020110	
8710	055332	042103	020124	042523	
8711	055340	000124			
8712	055342	052101	042524	050115	EM131: .ASCIZ /ATTEMPTING TO FORCE DRIVE TYPE ERROR ADDRESSING RK06
8713	055350	044524	043516	052040	
8714	055356	020117	047506	041522	
8715	055364	020105	051104	053111	
8716	055372	020105	054524	042520	
8717	055400	042440	051122	051117	
8718	055406	040440	042104	042522	
8719	055414	051523	047111	020107	
8720	055422	045522	033060	000	
8721	055427	101	052124	046505	EM132: .ASCIZ /ATTEMPTING TO FORCE SPEED LOSS/
8722	055434	052120	047111	020107	
8723	055442	047524	043040	051117	
8724	055450	042503	051440	042520	
8725	055456	042105	046040	051517	
8726	055464	000123			
8727	055466	052101	042524	050115	EM133: .ASCIZ /ATTEMPTING TO FORCE DRIVE OFF TRACK/

8728	055474	044524	043516	052040	
8729	055502	020117	047506	041522	
8730	055510	020105	051104	053111	
8731	055516	020105	043117	020106	
8732	055524	051124	041501	000113	
8733	055532	052101	042524	050115	EM134: .ASCIZ /ATTEMPTING TO FORCE WRITE LOCK ERROR/
8734	055540	044524	043516	052040	
8735	055546	020117	047506	041522	
8736	055554	020105	051127	052111	
8737	055562	020105	047514	045503	
8738	055570	042440	051122	051117	
8739	055576	000			
8740	055577	101	052124	046505	EM135: .ASCIZ /ATTEMPTING TO FORCE SEEK INCOMPLETE/
8741	055604	052120	047111	020107	
8742	055612	047524	043040	051117	
8743	055620	042503	051440	042505	
8744	055626	020113	047111	047503	
8745	055634	050115	042514	042524	
8746	055642	000			
8747	055643	101	052124	046505	EM136: .ASCIZ /ATTEMPTING TO FORCE NON-EXECUTABLE FUNCTION/
8748	055650	052120	047111	020107	
8749	055656	047524	043040	051117	
8750	055664	042503	047040	047117	
8751	055672	042555	042530	052503	
8752	055700	040524	046102	020105	
8753	055706	052506	041516	044524	
8754	055714	047117	000		
8755	055717	101	052124	046505	EM137: .ASCIZ /ATTEMPTING TO FORCE AC LOW AND C-D PARITY ERROR/
8756	055724	052120	047111	020107	
8757	055732	047524	043040	051117	
8758	055740	042503	040440	020103	
8759	055746	047514	020127	047101	
8760	055754	020104	026503	020104	
8761	055762	040520	044522	054524	
8762	055770	042440	051122	051117	
8763	055776	000			
8764	055777	101	052124	046505	EM138: .ASCII /ATTEMPTING TO FORCE ILLEGAL DISK ADDRESS ERROR
8765	056004	052120	047111	020107	
8766	056012	047524	043040	051117	
8767	056020	042503	044440	046114	
8768	056026	043505	046101	042040	
8769	056034	051511	020113	042101	
8770	056042	051104	051505	020123	
8771	056050	051105	047522	122	
8772	056055	015	043012	047522	ASCIZ <15><12>/FROM DRIVE MESSAGE BITS/
8773	056062	020115	051104	053111	
8774	056070	020105	042515	051523	
8775	056076	043501	020105	044502	
8776	056104	051524	000		
8777	056107	101	052124	046505	EM139: .ASCIZ /ATTEMPTING TO CLEAR RK611 WITH A CONTROLLER CLEAR/
8778	056114	052120	047111	020107	
8779	056122	047524	041440	042514	
8780	056130	051101	051040	033113	
8781	056136	030461	053440	052111	
8782	056144	020110	020101	047503	
8783	056152	052116	047522	046114	

8784	056160	051105	041440	042514	
8785	056166	051101	05 000		
8786	056171	124	051505	044524	EM140: .ASCIZ /TESTING ILLEGAL DISK ADDRESS ERROR LOGIC IN RK611/
8787	056176	043516	044440	046114	
8788	056204	043505	046101	042040	
8789	056212	051511	020113	042101	
8790	056220	051104	051505	020123	
8791	056226	051105	047522	020122	
8792	056234	047514	044507	020103	
8793	056242	047111	051040	033113	
8794	056250	030461	05 000		
8795	056253	101	052124	046505	EM141: .ASCIZ /ATTEMPTING TO RECEIVE NON-STANDARD MESSAGES/
8796	056260	052120	047111	020107	
8797	056266	047524	051040	041505	
8798	056274	044505	042526	047040	
8799	056302	047117	051455	040524	
8800	056310	042116	051101	020104	
8801	056316	042515	051523	043501	
8802	056324	051505	000		
8803	056327	101	052124	046505	EM142: .ASCII /ATTEMPTING TO RECEIVE NON-STANDARD MESSAGES/
8804	056334	052120	047111	020107	
8805	056342	047524	051040	041505	
8806	056350	044505	042526	047040	
8807	056356	047117	051455	040524	
8808	056364	042116	051101	020104	
8809	056372	042515	051523	043501	
8810	056400	051505			
8811	056402	053440	052111	020110	.ASCIZ / WITH PARITY ERROR/
8812	056410	040520	044522	054524	
8813	056416	042440	051122	051117	
8814	056424	000			
8815	056425	101	052124	046505	EM143: .ASCIZ /ATTEMPTING TO FORCE NON-EXISTENT DRIVE (DRIVE BUS TIMEOUT)/
8816	056432	052120	047111	020107	
8817	056440	047524	043040	051117	
8818	056446	042503	047040	047117	
8819	056454	042455	044530	052123	
8820	056462	047105	020124	051104	
8821	056470	053111	020105	042050	
8822	056476	044522	042526	041040	
8823	056504	051523	052040	046511	
8824	056512	047505	052125	000051	
8825	056520	052101	042524	050115	EM144: .ASCIZ /ATTEMPTING TO FORCE NON-EXISTENT DRIVE (NO SACK)/
8826	056526	044524	043516	052040	
8827	056534	020117	047506	041522	
8828	056542	020105	047516	026516	
8829	056550	054105	051511	042524	
8830	056556	052116	042040	044522	
8831	056564	042526	024040	047516	
8832	056572	051440	041501	024513	
8833	056600	000			
8834	056601	101	052124	046505	EM145: .ASCIZ /ATTEMPTING EXECUTION OF DESELECT DRIVE WITH IE RESET/
8835	056606	052120	047111	020107	
8836	056614	054105	041505	052125	
8837	056622	047511	020116	043117	
8838	056630	042040	051505	046105	
8839	056636	041505	020124	051104	

8840	056644	053111	020105	044527	
8841	056652	044124	044440	020105	
8842	056660	042522	042523	000124	
8843	056666	052101	042524	050115	EM146: .ASCIZ /ATTEMPTING TO EXECUTE AN ILLEGAL FUNCTION/
8844	056674	044524	043516	052040	
8845	056702	020117	054105	041505	
8846	056710	052125	020105	047101	
8847	056716	044440	046114	043505	
8848	056724	046101	043040	047125	
8849	056732	052103	047511	000116	
8850	056740	052101	042524	050115	EM147: .ASCIZ /ATTEMPTING TO CLEAR ILLEGAL FUNCTION/
8851	056746	044524	043516	052040	
8852	056754	020117	046103	040505	
8853	056762	020122	046111	042514	
8854	056770	040507	020114	052506	
8855	056776	041516	044524	047117	
8856	057004	000			
8857	057005	104	044522	042526	EM2000: .ASCIZ DRIVE COMMAND BIT DID NOT SET IN DRIVE MESS A/
8858	057012	041440	046517	040515	
8859	057020	042116	041040	052111	
8860	057026	042040	042111	047040	
8861	057034	052117	051440	052105	
8862	057042	044440	020116	051104	
8863	057050	053111	020105	042515	
8864	057056	051523	040440	000	
8865	057063	104	044522	042526	EM2001: .ASCIZ /DRIVE MESS A INCORRECT/
8866	057070	046440	051505	020123	
8867	057076	020101	047111	047503	
8868	057104	051122	041505	000124	
8869	057112	051104	053111	020105	EM2002: .ASCIZ /DRIVE MESS B INCORRECT/
8870	057120	042515	051523	041040	
8871	057126	044440	041516	051117	
8872	057134	042522	052103	000	
8873	057141	103	046517	040515	EM2003: .ASCIZ /COMMAND AND STAU REG. 1 INCORRECT/
8874	057146	042116	040440	042116	
8875	057154	051440	040524	051525	
8876	057162	051040	043505	020056	
8877	057170	020061	047111	047503	
8878	057176	051122	041505	000124	
8879	057204	051104	053111	020105	EM2004: .ASCIZ /DRIVE SELECT CODE IN MESSAGE A INCORRECT/
8880	057212	042523	042514	052103	
8881	057220	041440	042117	020105	
8882	057226	047111	046440	051505	
8883	057234	040523	042507	040440	
8884	057242	044440	041516	051117	
8885	057250	042522	052103	000	
8886	057255	110	040505	020104	EM2005: .ASCIZ /HEAD ADD CODE IN MESSAGE A INCORRECT/
8887	057262	042101	020104	047503	
8888	057270	042504	044440	020116	
8889	057276	042515	051523	043501	
8890	057304	020105	020101	047111	
8891	057312	047503	051122	041505	
8892	057320	000124			
8893	057322	040515	047111	020124	EM2006: .ASCIZ /MAINT REG. 1 INCORRECT/
8894	057330	042522	027107	030440	
8895	057336	044440	041516	051117	

8896	057344	042522	052103	000	
8897	057351	115	051505	020123	EM2007: .ASCIZ /MESS SELECT CODE IN MESSAGE B INCORRECT/
8898	057356	042523	042514	052103	
8899	057364	041440	042117	020105	
8900	057372	047111	046440	051505	
8901	057400	040523	042507	041040	
8902	057406	044440	041516	051117	
8903	057414	042522	052103	000	
8904	057421	103	046131	047111	EM2008: .ASCIZ /CYLINDER ADD BITS IN MESSAGE B INCORRECT/
8905	057426	042504	020122	042101	
8906	057434	020104	044502	051524	
8907	057442	044440	020116	042515	
8908	057450	051523	043501	020105	
8909	057456	020102	047111	047503	
8910	057464	051122	041505	000124	
8911	057472	043117	051506	052105	EM2009: .ASCIZ /OFFSET VALUE BITS IN MESSAGE B INCORRECT/
8912	057500	053040	046101	042525	
8913	057506	041040	052111	020123	
8914	057514	047111	046440	051505	
8915	057522	040523	042507	041040	
8916	057530	044440	041516	051117	
8917	057536	042522	052103	000	
8918	057543	120	051101	052111	EM2010: .ASCIZ /PARITY BIT IN MESSAGE A INCORRECT/
8919	057550	020131	044502	020124	
8920	057556	047111	046440	051505	
8921	057564	040523	042507	040440	
8922	057572	044440	041516	051117	
8923	057600	042522	052103	000	
8924	057605	120	051101	052111	EM2011: .ASCIZ /PARITY BIT IN MESSAGE B INCORRECT/
8925	057612	020131	044502	020124	
8926	057620	047111	046440	051505	
8927	057626	040523	042507	041040	
8928	057634	044440	041516	051117	
8929	057642	042522	052103	000	
8930	057647	103	046517	040515	EM2012: .ASCIZ /COMMAND AND STATUS REG 2 INCORRECT/
8931	057654	042116	040440	042116	
8932	057662	051440	040524	052524	
8933	057670	020123	042522	020107	
8934	057676	020062	047111	047503	
8935	057704	051122	041505	000124	
8936	057712	051105	047522	020122	EM2013: .ASCIZ /ERROR REG INCORRECT/
8937	057720	042522	020107	047111	
8938	057726	047503	051122	041505	
8939	057734	000124			
8940	057736	047503	046515	047101	EM2014: .ASCIZ /COMMAND AND STATUS REG 1 INCORRECT AT PHASE ADDRESS 4/
8941	057744	020104	047101	020104	
8942	057752	052123	052101	051525	
8943	057760	051040	043505	030440	
8944	057766	044440	041516	051117	
8945	057774	042522	052103	040440	
8946	060002	020124	044120	051501	
8947	060010	020105	042101	051104	
8948	060016	051505	020123	000064	
8949	060024	047503	046515	047101	EM2015: .ASCIZ /COMMAND AND STATUS REG 1 INVALID DURING COMMAND EXECUTION/
8950	060032	020104	047101	020104	
8951	060040	052123	052101	051525	

8952	060046	051040	043505	030440	
8953	060054	044440	053116	046101	
8954	060062	042111	042040	051125	
8955	060070	047111	020107	047503	
8956	060076	046515	047101	020104	
8957	060104	054105	041505	052125	
8958	060112	047511	000116		
8959	060116	040515	047111	042524	EM2016: .ASCIZ /MAINTENANCE REG 2 UNEXPECTEDLY CHANGED DURING COMMAND EXECUTION/
8960	060124	040516	041516	020105	
8961	060132	042522	020107	020062	
8962	060140	047125	054105	042520	
8963	060146	052103	042105	054514	
8964	060154	041440	040510	043516	
8965	060162	042105	042040	051125	
8966	060170	047111	020107	047503	
8967	060176	047111	047101	020104	
8968	060204	054105	041505	052125	
8969	060212	047511	000116		
8970	060216	040515	047111	042524	EM2017: .ASCIZ /MAINTENANCE REG 3 UNEXPECTEDLY CHANGED DURING COMMAND EXECUTION/
8971	060224	040516	041516	020105	
8972	060232	042522	020107	020063	
8973	060240	047125	054105	042520	
8974	060246	052103	042105	054514	
8975	060254	041440	040510	043516	
8976	060262	042105	042040	051125	
8977	060270	047111	020107	047503	
8978	060276	046515	047101	020104	
8979	060304	054105	041505	052125	
8980	060312	047511	000116		
8981	060316	047111	042524	051122	EM2018: .ASCIZ /INTERRUPT DID NOT OCCUR/
8982	060324	050125	020124	044504	
8983	060332	020104	047516	020124	
8984	060340	041517	052503	000122	
8985	060346	047503	046515	047101	EM2019: .ASCIZ /COMMAND AND STATUS REG 1 INCORRECT AFTER INTERRUPT/
8986	060354	020104	047101	020104	
8987	060362	052123	052101	051525	
8988	060370	051040	043505	030440	
8989	060376	044440	041516	051117	
8990	060404	042522	052103	040440	
8991	060412	052106	051105	044440	
8992	060420	052116	051105	052522	
8993	060426	052120	000		
8994	060431	103	046517	040515	EM2020: .ASCIZ /COMMAND AND STATUS REG 2 INCORRECT AFTER INTERRUPT/
8995	060436	042116	040440	042116	
8996	060444	051440	040524	052524	
8997	060452	020123	042522	020107	
8998	060460	020062	047111	047503	
8999	060466	051122	041505	020124	
9000	060474	043101	042524	020122	
9001	060502	047111	042524	051122	
9002	060510	050125	000124		
9003	060514	051105	047522	020122	EM2021: .ASCIZ /ERROR REGISTER INCORRECT AFTER INTERRUPT/
9004	060522	042522	044507	052123	
9005	060530	051105	044440	041516	
9006	060536	051117	042522	052103	
9007	060544	040440	052106	051105	

9008	060552	044440	052116	051105	
9009	060560	052522	052120	000	
9010	060565	111	052116	051105	EM2022: .ASCIZ /INTERRUPT DID NOT CLEAR IN RK611/
9011	060572	052522	052120	042040	
9012	060600	042111	047040	052117	
9013	060606	041440	042514	051101	
9014	060614	044440	020116	045522	
9015	060622	030466	000061		
9016	060626	040504	040524	046040	EM2023: .ASCIZ /DATA LATE DID NOT OCCUR WHEN LEAVING SILO/
9017	060634	052101	020105	044504	
9018	060642	020104	047516	020124	
9019	060650	041517	052503	020122	
9020	060656	044127	047105	046040	
9021	060664	040505	044526	043516	
9022	060672	051440	046111	000117	
9023	060700	051104	053111	020105	EM2024: .ASCIZ /DRIVE COMMAND BITS IN MESSAGE INCORRECT/
9024	060706	047503	046515	047101	
9025	060714	020104	044502	051524	
9026	060722	044440	020116	042515	
9027	060730	051523	043501	020105	
9028	060736	047111	047503	051122	
9029	060744	041505	000124		
9030	060750	051104	053111	020105	EM2025: .ASCIZ /DRIVE STATUS REGISTER INCORRECT/
9031	060756	052123	052101	051525	
9032	060764	051040	043505	051511	
9033	060772	042524	020122	047111	
9034	061000	047503	051122	041505	
9035	061006	000124			
9036	061010	047503	052116	047522	EM2026: .ASCIZ /CONTROLLER READY DID NOT SET/
9037	061016	046114	051105	051040	
9038	061024	040505	054504	042040	
9039	061032	042111	047040	052117	
9040	061040	051440	052105	000	
9041	061045	114	040517	020104	EM2027: .ASCIZ /LOAD STATUS DID NOT LOAD DRIVE STATUS REG./
9042	061052	052123	052101	051525	
9043	061060	042040	042111	047040	
9044	061066	052117	046040	040517	
9045	061074	020104	051104	053111	
9046	061102	020105	052123	052101	
9047	061110	051525	051040	043505	
9048	061116	000056			
9049	061120	047125	054105	042520	EM2028: .ASCIZ /UNEXPECTED INTERRUPT OCCURRED/
9050	061126	052103	042105	044440	
9051	061134	052116	051105	052522	
9052	061142	052120	047440	041503	
9053	061150	051125	042522	000104	
9054	061156	047111	042524	051122	EM2029: .ASCIZ /INTERRUPT OCCURRED WHEN INTERRUPT ENABLE SET/
9055	061164	050125	020124	041517	
9056	061172	052503	051122	042105	
9057	061200	053440	042510	020116	
9058	061206	047111	042524	051122	
9059	061214	050125	020124	047105	
9060	061222	041101	042514	051440	
9061	061230	052105	000		
9062		000001			.END



ABASE = 177440	937#	1172	1213	
ABORT = 050122	7358	8217#		
ACDW1 = 000000	1172	1215		
ACDW2 = 000000	1172	1216		
ACLO = 000010	1032#	5977		
ACPUOP = 000000	1172	1187		
ADDW0 = 000000	1172			
ADDW1 = 000000	1172			
ADDW10 = 000000	1172			
ADDW11 = 000000	1172			
ADDW12 = 000000	1172			
ADDW13 = 000000	1172			
ADDW14 = 000000	1172			
ADDW15 = 000000	1172			
ADDW2 = 000000	1172			
ADDW3 = 000000	1172			
ADDW4 = 000000	1172			
ADDW5 = 000000	1172			
ADDW6 = 000000	1172			
ADDW7 = 000000	1172			
ADDW8 = 000000	1172			
ADDW9 = 000000	1172			
ADEVCT = 000000	1172	1178		
ADEVM = 000000	1172	1214		
AENV = 000000	1172	1183		
AENVM = 000000	1172	1184		
AFATAL = 000000	1172	1175		
AMADR1 = 000000	1172	1200		
AMADR2 = 000000	1172	1204		
AMADR3 = 000000	1172	1207		
AMADR4 = 000000	1172	1210		
AMAMS1 = 000000	1172	1194		
AMAMS2 = 000000	1172	1202		
AMAMS3 = 000000	1172	1205		
AMAMS4 = 000000	1172	1208		
AMSGAD = 000000	1172	1180		
AMSGLG = 000000	1172	1181		
AMSGTY = 000000	1172	1174		
AMTYP1 = 000000	1172	1195		
AMTYP2 = 000000	1172	1203		
AMTYP3 = 000000	1172	1206		
AMTYP4 = 000000	1172	1209		
APASS = 000000	1172	1177		
APRIOR = 000005	936#	1172		
APTCSU = 000040	7235#	7398		
APTENV = 000001	7191	7233#	7267	7391
APTSIZ = 000200	2401	7232#		
APTSPO = 000100	7193	7234#	7393	
ASWREG = 000000	1172	1185		
ATESTN = 000000	1172	1176		
AUNIT = 000000	1172	1179		
AUSWR = 000000	1172	1186		
AVECT1 = 120210	935#	1172	1211	
AVECT2 = 000000	1172	1212		
BAI = 000020	995#			
BA16 = 000400	980#			





DH2248 051546  
DH230A 051603  
DH230B 051630  
DH256A 051654  
DH256B 051720  
DI = 040000  
DISPLA 001142  
DISPRE 000174  
DLT = 100000  
DMD = 000040

8173  
8181  
8183  
8195  
8197  
987#  
1145#  
1077#  
1006#  
1048#

8366#  
8371#  
8375#  
8379#  
8385#

2389\* 2797\* 7101\* 7254\*

DRA = 000001  
DRDY = 000200  
DROT = 000040  
DRPAR = 000010  
DRVCOD 004244

2743#  
2999#  
3300#  
3544#  
3602#  
4294#  
4670#  
5028#  
5414#  
5729#  
6040#  
6449#  
6760#  
1029#  
6392#  
1036#  
1034#  
1013#  
2333#  
4418#  
4558#  
4739#  
993#

2499#  
3043#  
3304#  
3545#  
3917#  
4319#  
4671#  
5107#  
5419#  
5730#  
6112#  
6459#  
6761#  
5048#  
6476#  
5048#  
5667#  
5978#  
2564#  
4419#  
4579#  
4745#

2512#  
2812#  
3047#  
3305#  
3599#  
3929#  
4323#  
4695#  
5112#  
5420#  
5802#  
6122#  
6460#  
6842#  
5050#  
6560#  
6308#  
2572#  
4436#  
4586#  
4757#

2513#  
2815#  
3048#  
3366#  
3504#  
3994#  
4324#  
4696#  
5113#  
5492#  
5807#  
6123#  
6533#  
6845#  
5128#  
6560#  
6560#  
2582#  
4448#  
4598#  
4774#

2571#  
2816#  
3098#  
3371#  
3605#  
3996#  
4371#  
4933#  
5184#  
5497#  
5808#  
6196#  
6543#  
6846#  
5275#  
6616#  
4775#

2575#  
2875#  
3102#  
3372#  
3659#  
4051#  
4447#  
4938#  
5189#  
5498#  
5885#  
6206#  
6544#  
6923#  
5357#

2576#  
2878#  
3103#  
3419#  
3664#  
4063#  
4509#  
4939#  
5190#  
5569#  
5885#  
6207#  
6522#

2622#  
2879#  
3166#  
3424#  
3665#  
4111#  
4585#  
4953#  
5261#  
5574#  
5896#  
6281#  
6628#  
5513#

2626#  
2938#  
3170#  
3425#  
3716#  
4123#  
4589#  
4954#  
5264#  
5575#  
5958#  
6291#  
6629#  
5590#

2627#  
2941#  
3171#  
3479#  
3728#  
4185#  
4590#  
4979#  
5285#  
5646#  
5961#  
6292#  
6679#  
5667#

2678#  
2942#  
3223#  
3484#  
3783#  
4240#  
4640#  
4980#  
5336#  
5651#  
5962#  
6291#  
6684#  
6139#

2684#  
2994#  
3233#  
3485#  
3795#  
4290#  
4644#  
5022#  
5341#  
5652#  
5961#  
6375#  
6695#  
6223#

2685#  
2998#  
3234#  
3539#  
3850#  
4293#  
4645#  
5027#  
5342#  
5724#  
6039#  
6376#  
6757#  
6308#

DRVMSK= 000007  
DRV TYP 004266  
DSC = 040000  
DSWR = 177570  
DTE = 010000  
DTYE = 000040  
DT000 046514  
DT001 046520  
DT002 046540  
DT006 046552  
DT012 046604  
DT017 046632  
DT031 046654  
DT035 046676  
DT050 046722  
DT052 046744  
CT062 046760

2342#  
1040#  
638#  
1022#  
1015#  
2276#  
1237#  
1242#  
1262#  
1282#  
1307#  
1358#  
1379#  
1445#  
1457#  
1505#  
1630#  
1787#  
1865#  
1943#  
2021#  
2147#  
2225#

6119#  
2388#  
1144#  
5436#  
7935#  
1679#  
1247#  
1262#  
1287#  
1312#  
1363#  
1385#  
1451#  
1463#  
1511#  
1661#  
1793#  
1871#  
1949#  
2027#  
2153#  
2231#

6203#  
6288#  
6372#  
6456#  
6540#  
7981#  
1685#  
1691#  
1697#  
1703#  
1709#  
1715#  
1721#  
7936#  
1409#  
1415#  
1421#  
1422#  
1427#  
1433#  
1439#  
7945#  
1302#  
1322#  
1327#  
1328#  
1332#  
1337#  
1343#  
1348#  
1353#  
1355#  
1439#  
7950#  
1403#  
7956#  
1475#  
1481#  
1487#  
1493#  
1499#  
7963#  
1581#  
1598#  
1604#  
1610#  
1623#  
1667#  
1673#  
1727#  
1733#  
1739#  
1745#  
1757#  
1763#  
1769#  
1775#  
1781#  
1781#  
1781#  
1781#  
1781#  
1805#  
1811#  
1817#  
1823#  
1829#  
1835#  
1841#  
1847#  
1853#  
1859#  
1877#  
1883#  
1889#  
1895#  
1901#  
1907#  
1913#  
1919#  
1925#  
1931#  
1937#  
1943#  
1949#  
1955#  
1961#  
1967#  
1973#  
1979#  
1985#  
1991#  
1997#  
2003#  
2009#  
2015#  
2021#  
2027#  
2033#  
2039#  
2045#  
2051#  
2057#  
2063#  
2069#  
2075#  
2081#  
2087#  
2093#  
2109#  
2115#  
2121#  
2127#  
2133#  
2139#  
2145#  
2151#  
2157#  
2163#  
2169#  
2175#  
2181#  
2187#  
2193#  
2199#  
2205#  
2211#  
2217#  
2223#



EM141	056253	2145	2151	2157	2163	8795#											
EM142	056327	2169	2175	2181	2187	8803#											
EM143	056425	2193	2199	2205	2211	8815#											
EM144	056523	2217	2223	2229	2235	8825#											
EM145	056601	2241	2247	8834#													
EM146	056666	2253	2259	8843#													
EM147	056740	2264	2269	8850#													
EM2000	057005	1311	1336	1384	1420	2644	2835	2898	2961	3016	3065	8857#					
EM2001	057063	1251	1271	1296	1321	1347	1367	1372	1396	1432	1444	1468	1492	1568			
		2650	2841	2904	2967	3022	3071	8865#									
EM2002	057112	1256	1276	1301	1326	1352	1402	1438	1450	1474	1498	2654	2845	2908			
		2971	3026	3075	8869#												
EM2003	057141	1241	1261	1281	1306	1331	1357	1378	1408	1504	1550	1585	1660	1678			
		1762	1786	1810	1834	1858	1882	1906	1930	1954	1978	2002	2026	2050			
		2074	2098	2122	2146	2170	2194	2218	2254	2265	2637	2825	2888	2951			
		3009	3058	8873#													
EM2004	057204	1246	1684	8879#													
EM2005	057255	1266	1696	8886#													
EM2006	057322	1286	1414	8893#													
EM2007	057351	1291	1426	1708	8897#												
EM2008	057421	316	1342	1390	1714	8904#											
EM2009	057472	362	8911#														
EM2010	057543	1456	1480	1702	8918#												
EM2011	057605	1462	1486	1720	8924#												
EM2012	057647	1510	1556	1574	1622	1666	1768	1792	1816	1840	1864	1888	1912	1936			
		1960	1984	2008	2032	2056	2080	2104	2128	2152	2176	2200	2224	8930#			
EM2013	057712	1516	1562	1580	1672	1774	1804	1828	1852	1876	1900	1924	1948	1972			
		1936	2020	2044	2068	2092	2116	2140	2164	2188	2212	2236	2260	2270			
		8936#															
EM2014	057736	1523	1635	8940#													
EM2015	060024	1530	1641	8949#													
EM2016	060116	1537	1648	8959#													
EM2017	060216	1544	1654	8970#													
EM2018	060316	1591	8981#														
EM2019	060346	1597	8985#														
EM2020	060431	1603	8994#														
EM2021	060514	1609	9003#														
EM2022	060565	1615	9010#														
EM2023	060626	1629	9016#														
EM2024	060700	1690	9023#														
EM2025	060750	1726	1732	1738	1744	1780	1798	1822	1846	1870	1894	1918	1942	1966			
		1990	2014	2038	2062	2086	2110	2134	2158	2182	2206	2230	9030#				
EM2026	061010	1750	9036#														
EM2027	061045	1756	9041#														
EM2028	061120	2242	9049#														
EM2029	061156	2248	9054#														
ERRCNT	004242	2332#	2405#	7353*	7356*	7001*	7002*	7014*	7015*	7052	7053*	7055*	7058*				
ERRVEC =	000004	920#	2386	2387*	2398*												
ERASOF	004176	2306#															
ERBA	004164	2301#															
ERCSI	004160	2299#	2505*	2506	2519*	2522	2565*	2584	2624*	2635	2672*	2698	2736*	2761			
		2805#	2813	2823	2848	2850*	2868*	2876	2886	2911	2913*	2931*	2939	2949			
		2974	2976*	2996*	3007	3045*	3056	3092*	3115	3160*	3178	3223*	3246	3293*			
		3323	3364*	3380	3417*	3433	3477*	3493	3537*	3553	3597*	3613	3657*	3673			
		3714*	3734	3781*	3801	3848*	3868	3915*	3935	3982*	4002	4049*	4069	4109*			
		4129	4597*	4602	4649*	4650	4677	4703*	4708	4756*	4761	4823*	4826	4901*			

		4912*	4943*	4944	4960	4987*	4991	5038*	5046*	5053	5075*	5079	5126*	5130
		5152*	5156	5203*	5207	5229*	5233	528*	5282	5304*	5308	5355*	5359	5381*
		5385	5433*	5437	5459*	5463	5511*	5515	5537*	5541	5588*	5592	5614*	5618
		5665*	5669	5691*	5695	5743*	5747	5769*	5773	5821*	5825	5847*	5851	5899*
		5903	5925*	5929	5975*	5979	6001*	6005	6053*	6057	6079*	6083	6136*	6141
		6163*	6167	6220*	6225	6247*	6251	6305*	6310	6332*	6336	6389*	6394	6416*
		6420	6473*	6478	6500*	6504	6557*	6562	6584*	6588	6642*	6647	6698*	6702
		6723*	6727	6777*	6780*	6784	6805*	6809	6859*	6863	6884*	6888	6919*	6920*
		6921*	6927	6938*	6938	7936	7939	7942	7945	7950	7953	7956	7965	7969
		7974	7976	7981	7986									
E.CS2	004170	2303*	4598*	4599*	4605	4704*	4705*	4711	4757*	4758*	4764	4824*	4829	4902*
		4905	4913*	4914	4988*	4994	5047*	5056	5076*	5082	5127*	5133	5153*	5159
		5204*	5210	5230*	5236	5279*	5285	5305*	5311	5356*	5362	5382*	5388	5434*
		5440	5460*	5466	5512*	5518	5538*	5544	5589*	5595	5615*	5621	5666*	5672
		5692*	5698	5744*	5750	5770*	5776	5822*	5828	5848*	5854	5900*	5906	5926*
		5932	5976*	5982	6002*	6008	6054*	6060	6080*	6086	6138*	6144	6164*	6170
		6222*	6228	6248*	6254	6307*	6313	6333*	6339	6391*	6397	6417*	6423	6475*
		6481	6501*	6507	6559*	6565	6585*	6591	6643*	6644*	6650	6699*	6705	6724*
		6730	6781*	6787	6806*	6812	6860*	6866	6885*	6891	7965	7976	7981	
E.DA	004166	2302*												
E.DB	004202	2308*												
E.DCYL	004200	2307*												
E.DS	004172	2304*	4600*	4611	4706*	4717	4759*	4770	4903*	4989*	5000	5048*	5062	5077*
		5085	5128*	5136	5154*	5162	5205*	5213	5231*	5239	5280*	5288	5306*	5314
		5357*	5365	5383*	5391	5435*	5443	5461*	5469	5513*	5521	5539*	5547	5590*
		5598	5616*	5624	5667*	5675	5693*	5701	5745*	5753	5771*	5779	5823*	5831
		5849*	5857	5901*	5909	5927*	5935	5977*	5985	6003*	6011	6055*	6063	6081*
		6089	6139*	6147	6165*	6173	6223*	6231	6249*	6257	6308*	6316	6334*	6342
		6392*	6400	6418*	6426	6476*	6484	6502*	6510	6560*	6568	6586*	6594	6645*
		6653	6700*	6708	6725*	6733	6782*	6790	6807*	6815	6861*	6869	6886*	6894
		7965	7976	7984										
E.ECPS	004212	2312*												
E.ECPT	004214	2313*												
E.EP	004174	2305*	4601*	4608	4707*	4714	4760*	4767	4825*	4832	4904*	4990*	4997	5049*
		5059	5078*	5088	5129*	5139	5155*	5165	5206*	5216	5232*	5242	5281*	5291
		5307*	5317	5358*	5368	5384*	5394	5436*	5446	5462*	5472	5514*	5524	5540*
		5550	5591*	5601	5617*	5627	5668*	5678	5694*	5704	5746*	5756	5772*	5782
		5824*	5834	5850*	5860	5902*	5912	5928*	5938	5978*	5988	6004*	6014	6056*
		6066	6082*	6092	6140*	6150	6166*	6176	6224*	6234	6250*	6260	6309*	6319
		6335*	6345	6393*	6403	6419*	6429	6477*	6487	6503*	6513	6561*	6571	6587*
		6597	6646*	6656	6701*	6711	6726*	6736	6783*	6793	6808*	6818	6862*	6872
		6887*	6897	6922*	6930	6937*	6941	7965	7979	7984	7986			
E.MR1	004204	2309*	2754*	2755*	2758*	2767	3728*	3731*	3740	3795*	3798*	3807	3862*	3865*
		3874	3929*	3932*	3941	3996*	3999*	4008	4063*	4066*	4075	4123*	4126*	4135
		7945												
E.MR2	004206	2310*	2520*	2582*	2597	2633*	2648	2691*	2692*	2693*	2694*	2695*	2696*	2706
		2711	2759*	2780	2806*	2832	2839	2851*	2869*	2895	2902	2914*	2932*	2958
		2965	2977*	3005*	3020	3054*	3069	3109*	3133	3177*	3196	3240*	3264	3294*
		3336	3378*	3393	3431*	3453	3491*	3513	3551*	3573	3611*	3633	3671*	3693
		3732*	3760	3799*	3827	3866*	3894	3933*	3961	4000*	4028	4067*	4088	4127*
		4155	4181*	4196	4213	4236*	4252	4269*	4299*	4315	4330*	4345	4389*	4395*
		4414	4438*	4474	4482*	4528*	4534*	4553	4667*	4682	4950*	4965	7936	7939
		7942	7948	7950	7953	7958	7960	7963	7971					
E.MR3	004210	2311*	2521*	2583*	2600	2634*	2652	2697*	2714	2760*	2783	2822*	2843	2885*
		2906	2948*	2969	3006*	3024	3055*	3073	3110*	3111*	3112*	3113*	3114*	3128
		3136	3159*	3191	3199	3206*	3241*	3242*	3243*	3244*	3245*	3259	3267	3311*





OPI = 020000	1023#																	
OPR001 050010	2429#	8201#																
OPR002 050037	2432#	2443#	2460	8205#														
OPR003 050045	2439#	8207#																
OPR004 050075	2451#	8212#																
OR = 000200	998#																	
PACK = 000003	961#	2931	3417	3422	3714	3718	5727	5743										
PARBIT 004260	2339#	4391*	4394*	4399	4406	4440*	4459	4466	4484*	4530*	4533*	4538	4545					
PARM 004276	1083#	2348#																
PAR.EN= 000001	934#	7006																
PAT = 000020	1047#	4319	4323	4324	4509													
PCA = 004000	101#																	
PCD = 010000	1055#																	
PGE = 002000	1001#																	
PIP = 020000	1039#	6223																
PIRQ = 177772	837#																	
PIRQVE= 000240	931#																	
PRO = 000000	854#																	
PR1 = 000040	855#																	
PR2 = 000100	856#																	
PR3 = 000140	857#																	
PR4 = 000200	858#																	
PR5 = 000240	859#	2327																
PR6 = 000300	860#																	
PR7 = 000340	861#	2357	2480	4800	4812	4854	7002	7008	7863	7876								
PS = 177776	834#	835																
PSW = 177776	835#																	
PWAVEC= 000024	926#	2376*	2377*	7862*	7863*	7875*	7876*											
P.CS1 004220	2318#	5065*	5142*	5219*	5294*	5371*	5449*	5527*	5604*	5681*	5759*	5837*	5915*					
	5991*	6069*	6153*	6237*	6322*	6406*	6490*	6574*	6714*	6796*	6875*	6979						
P.CS2 004222	2319#	5066*	5143*	5220*	5295*	5372*	5450*	5528*	5605*	5682*	5760*	5838*	5916*					
	5992*	6070*	6154*	6238*	6323*	6407*	6491*	6575*	6715*	6797*	6876*	6979						
P.DS 004224	2320#	5067*	5144*	5221*	5296*	5373*	5451*	5529*	5606*	5683*	5761*	5839*	5917*					
	5993*	6071*	6155*	6239*	6324*	6408*	6492*	6576*	6716*	6798*	6877*	6979						
P.ER 004226	2321#	5068*	5145*	5222*	5297*	5374*	5452*	5530*	5607*	5684*	5762*	5840*	5918*					
	5994*	6072*	6156*	6240*	6325*	6409*	6493*	6577*	6717*	6799*	6878*	6979						
RDCHR = 104410	7705#	7927#																
RDDATA= 000021	968#																	
RDGATE= 100000	1058#																	
RDHEAD= 000025	970#																	
RDLIN = 104411	7777#	7928#																
RDOCT = 104412	2433#	2444#	2461	7929#														
RDY = 000200	979#	4597	4703	4756	4823	4901	4912	4987	5038	5046	5075	5126	5152					
	5203	5229	5278	5304	5355	5381	5433	5459	5511	5537	5588	5614	5665					
	5691	5743	5769	5821	5847	5899	5925	5975	6001	6053	6079	6136	6163					
	6220	6247	6305	6332	6389	6416	6473	6500	6557	6594	6642	6698	6723					
	6777	6805	6859	6884	6921	6936												
	965#	2995	2996	3657	3662	3982	3986	6037	6053									
RECAL = 000013	7352#	7931#																
RESREG= 104414	1081#	2351#																
RESTAT 004306	921#																	
RESVEC= 000010	948#	3301*	3368*	3421*	3481*	3541*	3601*	3661*										
RKASOF= 000016	943#																	
RKBA = 000004	941#	2498*	2500*	2504	2516	2570*	2573*	2579	2587*	2621*	2623*	2630	2639*					
RKCS1 = 000000	2677*	2682*	2688	2701*	2741*	2744*	2750	2764*	2770*	2811*	2813*	2819	2827*					
	2874*	2876*	2882	2890*	2937*	2939*	2945	2953*	2993*	2995*	3002	3011*	3042*					

RKCS2 = 000010

RKDA = 000006

RKDB = 000024  
RKDCYL = 000020

RKDS = 000012

RKECPS = 000030  
RKECPT = 000032  
RKER = 000014

RKMR1 = 000026

3044*	3051	3060*	3097*	3100*	3106	3118*	3165*	3168*	3174	3181*	3228*	3231*
3237	3249*	3299*	3302*	3308	3326*	3365*	3369*	3375	3383*	3418*	3422*	3428
3436*	3478*	3482*	3488	7496*	3538*	3542*	3548	3556*	3598*	3602*	3608	3616*
3658*	3662*	3668	3676*	715*	3718*	3724	3737*	3743*	3782*	3785*	3791	3804*
3810*	3849*	3852*	3858	3871*	3877*	3916*	3919*	3925	3938*	3944*	3983*	3986*
3992	4005*	4011*	4050*	4053*	4059	4072*	4078*	4110*	4113*	4119	4132*	4138*
4179*	4188*	4234*	4243*	4269*	4291*	4318*	4321*	4369*	4373*	4445*	4449*	4507*
4512*	4587*	4593	4642*	4648	4674	4699	4746*	4748	4752	4806*	4808	4820
4844*	4846	4852*	4891*	4893	4897	4909	4917*	4936*	4942	4957	4983	5025*
5033	5037	5042	5070*	5071	5110*	5118	5122	5147*	5148	5187*	5195	5199
5224*	5225	5262*	5270	5274	5299*	5300	5339*	5347	5351	5376*	5377	5417*
5425	5429	5454*	5455	5495*	5503	5507	5532*	5533	5572*	5580	5584	5609*
5610	5649*	5657	5661	5686*	5687	5727*	5735	5739	5764*	5765	5805*	5813
5817	5842*	5843	5883*	5891	5895	5920*	5921	5959*	5967	5971	5996*	5997
6037*	6045	6049	6074*	6075	6120*	6128	6132	6158*	6159	6204*	6212	6216
6242*	6243	6289*	6297	6301	6327*	6328	6373*	6381	6385	6411*	6412	6457*
6465	6469	6495*	6496	6541*	6549	6553	6579*	6580	6626*	6634	6638	6682*
6690	6694	6718*	6719	6758*	6766	6773	6800*	6801	6843*	6851	6855	6879*
6880	6918*	6924*	6925	6933*	6934							
945*	2572*	4187*	4372*	4448*	4511*	4584*	4586*	4594	4639*	4641*	4700	4744*
4745*	4753	4796*	4797*	4821	4843*	4869*	4888*	4890*	4898	4910	4932*	4984
5021*	5043	5072	5106*	5123	5149	5183*	5200	5226	5260*	5275	5301	5335*
5352	5378	5413*	5430	5456	5491*	5508	5534	5568*	5585	5611	5645*	5662
5688	5723*	5740	5766	5801*	5818	5844	5879*	5896	5922	5957*	5972	5998
6033*	6050	6076	6111*	6133	6160	6195*	6217	6244	6280*	6302	6329	6364*
6386	6413	6448*	6470	6497	6532*	6554	6581	6621*	6625*	6639	6678*	6681*
6695	6720	6756*	6774	6802	6841*	6856	6881					
944*	2681*	4242*	4935*	5024*	5109*	5186*	5338*	5416*	5494*	5571*	5648*	5726*
5804*	5882*	6036*	6118*	6202*	6287*	6371*	6455*	6539*	6624*			
950*	4889*	4908										
949*	3099*	3167*	3230*	3367*	3420*	3480*	3540*	3600*	3660*	4241*	4934*	5023*
5108*	5185*	5337*	5415*	5493*	5570*	5647*	5725*	5803*	5881*	6035*	6113*	6197*
6282*	6366*	6450*	6534*	6623*	6680*							
946*	4595	4701	4754	4899	4985	5044	5073	5124	5150	5201	5227	5276
5302	5353	5379	5431	5457	5509	5535	5586	5612	5663	5689	5741	5767
5819	5845	5897	5923	5973	5999	6051	6077	6134	6161	6218	6245	6303
6330	6387	6414	6471	6498	6555	6582	6640	6696	6721	6775	6803	6857
6882												
954*												
955*												
947*	4596	4702	4755	4822	4900	4911	4986	5045	5074	5125	5151	5202
5228	5277	5303	5354	5380	5432	5453	5510	5536	5587	5613	5664	5690
5742	5768	5820	5846	5898	5924	5974	6000	6052	6078	6135	6162	6219
6246	6304	6331	6388	6415	6472	6493	6556	6583	6641	6697	6722	6776
6804	6858	6883	6926	6935								
951*	2499*	2512*	2513*	2571*	2575*	2576*	2622*	2626*	2627*	2678*	2684*	2685*
2742*	2743*	2746*	2747*	2751	2812*	2815*	2816*	2875*	2878*	2879*	2938*	2941*
2942*	2994*	2998*	2999*	3043*	3047*	3048*	3098*	3102*	3103*	3166*	3170*	3171*
3229*	3233*	3234*	3300*	3304*	3305*	3366*	3371*	3372*	3419*	3424*	3425*	3479*
3484*	3485*	3539*	3544*	3545*	3599*	3604*	3605*	3659*	3664*	3665*	3716*	3720*
3721*	3725	3783*	3787*	3788*	3792	3850*	3854*	3855*	3859	3917*	3921*	3922*
3926	3984*	3988*	3989*	3993	4051*	4055*	4056*	4060	4111*	4115*	4116*	4120
4185*	4190*	4191*	4240*	4246*	4247*	4290*	4293*	4294*	4319*	4323*	4324*	4370*
4371*	4375*	4376*	4446*	4447*	4451*	4452*	4508*	4509*	4514*	4515*	4585*	4589*
4590*	4640*	4644*	4645*	4670*	4671*	4695*	4696*	4933*	4938*	4939*	4953*	4954*
4979*	4980*	5022*	5027*	5028*	5031*	5107*	5112*	5113*	5116*	5184*	5189*	5190*



K14

CZR6BCO RK611 DSKLS CTRL PRT2  
CZR6BC.P11 02-DEC-77 09:22

MACY11 30(1046) 02-DEC-77 09:31 PAGE 180  
CROSS REFERENCE TABLE -- USER SYMBOLS

SEQ 0179

SW05	=	000040	874#	884										
SW06	=	000100	873#	883										
SW07	=	000200	872#	882										
SW08	=	000400	871#	881										
SW09	=	001000	870#	880										
SW1	=	000002	888#											
SW10	=	002000	869#											
SW11	=	004000	868#											
SW12	=	010000	867#	7354										
SW13	=	020000	866#											
SW14	=	040000	865#											
SW15	=	100000	864#											
SW2	=	000004	887#											
SW3	=	000010	886#											
SW4	=	000020	885#											
SW5	=	000040	884#											
SW6	=	000100	883#											
SW7	=	000200	882#											
SW8	=	000400	881#											
SW9	=	001000	880#	7024	7173									
S. CLR	=	000400	1066#	2806	2831	3491	3500	3799	3814					
S. FMT	=	001000	1067#	2633	2642	2831	2851	2894	2914	2957	2977	4236	4237	4949
S. PACK	=	004000	1069#	2932	2957	3431	3440	3732	3747					
S. RECL	=	000040	1063#	3005	3014	3671	3680	4000	4015					
S. RTC	=	000200	1065#											
S. SEEK	=	000020	1062#	3109	3121	3177	3184	3240	3252	4127	4142	4236	4237	4949
S. STSP	=	000100	1064#	3054	3063	3611	3620	3933	3948					
S. UNLD	=	002000	1068#	2869	2894	3551	3560	3866	3881					
TBITVE	=	000014	922#											
TKVEC	=	000060	929#											
TPVEC	=	000064	930#											
TRAPPC	=	004272	2344#	7021*	7935									
TRAPVE	=	000034	928#	2374*	2375*									
TRTVEC	=	000014	923#											
TST1	=	005272	2481	2495#	7106									
TST10	=	010032	2912	2927#	7113									
TST100	=	041712	6898	6911#	7169									
TST11	=	010350	2975	2989#	7114									
TST12	=	010614	3012	3018	3025	3038#	7115							
TST13	=	011060	3061	3067	3074	3088#	7116							
TST14	=	011376	3155#	7117										
TST15	=	011706	3204	3219#	7118									
TST16	=	012240	3289#	7119										
TST17	=	012602	3359#	7120										
TST2	=	005576	2509	2525	2547	2561#	7107							
TST20	=	013046	3384	3391	3397	3412#	7121							
TST21	=	013326	3437	3444	3451	3457	3472#	7122						
TST22	=	013606	3497	3504	3511	3517	3532#	7123						
TST23	=	014066	3557	3564	3571	3577	3592#	7124						
TST24	=	014346	3617	3624	3631	3637	3652#	7125						
TST25	=	014626	3677	3684	3691	3697	3710#	7126						
TST26	=	015140	3738	3744	3751	3758	3764	3777#	7127					
TST27	=	015452	3805	3811	3818	3825	3831	3844#	7128					
TST3	=	006056	2617#	7108										
TST30	=	015764	3872	3878	3885	3892	3898	3911#	7129					
TST31	=	016276	3939	3945	3952	3959	3965	3978#	7130					

TST32	016610	4006	4012	4019	4026	4032	4045*	7131										
TST33	017106	4073	4079	4086	4092	4105*	7132											
TST34	017420	4133	4139	4146	4153	4159	4176*	7133										
TST35	017656	4199	4204	4231*	7134													
TST36	020122	4255	4260	4286*	7135													
TST37	020456	4335	4340	4346	4361*	7136												
TST4	006322	2640	2646	2653	2668*	7109												
TST40	021022	4433*	7137															
TST41	021346	4479	4499*	7138														
TST42	021712	4576*	7139															
TST43	022166	4631*	7140															
TST44	022716	4723	4736*	7141														
TST45	023156	4793*	7142															
TST46	023562	4885*	7143															
TST47	024012	4929*	7144															
TST5	006634	2732*	7110															
TST50	024446	4947	4963	4968	4973	5001	5018*	7145										
TST51	025130	5089	5103*	7146														
TST52	025562	5166	5180*	7147														
TST53	026214	5243	5257*	7148														
TST54	026632	5318	5332*	7149														
TST55	027264	5395	5410*	7150														
TST56	027716	5473	5488*	7151														
TST57	030350	5551	5565*	7152														
TST6	007176	2801*	7111															
TST60	031002	5628	5642*	7153														
TST61	031434	5705	5720*	7154														
TST62	032066	5783	5798*	7155														
TST63	032520	5861	5876*	7156														
TST64	033152	5939	5954*	7157														
TST65	033570	6015	6030*	7158														
TST66	034222	6093	6108*	7159														
TST67	034704	6177	6192*	7160														
TST7	007514	2849	2864*	7112														
TST70	035366	6261	6277*	7161														
TST71	036050	6346	6361*	7162														
TST72	036532	6430	6445*	7163														
TST73	037214	6514	6529*	7164														
TST74	037676	6598	6613*	7165														
TST75	040210	6675*	7166															
TST76	040636	6737	6753*	7167														
TST77	041300	6819	6838*	7168														
TYPDS =	104405	6976	6983	7922*														
TYPE =	104401	2412	2429	2432	2439	2443	2451	2460	6970	6977	6984	7257	7265	7311				
		7312	7316	7317	7324	7335	7337	7347	7348	7350	7358	7411	7507	7582				
		7612	7613	7616	7629	7640	7659	7712	7718	7723	7727	7732	7733	7735				
		7738	7742	7806	7808	7878	7918*											
		7264	7301*															
TYPERR	043716	7264	7301*															
TYPOC =	104402	2431	2442	2459	7332	7615	7919*											
TYPON =	104404	7921*																
TYPOS =	104403	7920*																
T.ASOF	004136	2287*																
T.BA	004124	2282*																
T.CS1	004120	2280*	2504*	2506	2516*	2522	2579*	2584	2630*	2635	2688*	2698	2750*	2761				
		2819*	2823	2882*	2886	2945*	2949	3002*	3007	3051*	3056	3106*	3115	3174*				
		3178	3237*	3246	3308*	3323	3375*	3380	3428*	3433	3488*	3493	3548*	3553				

		3608*	3613	3668*	3673	3724*	3734	3791*	3801	3858*	3868	3925*	3935	3992*
		4002	4059*	4069	4119*	4129	4593*	4602	4648*	4650	4674*	4677	4699*	4708
		4752*	4761	4820*	4826	4897*	4909*	4942*	4944	4957*	4960	4983*	4991	5037*
		5042*	5053	5065	5071*	5079	5122*	5130	5142	5148*	5156	5199*	5207	5219
		5225*	5233	5274*	5282	5294	5300*	5308	5351*	5359	5371	5377*	5385	5424*
		5437	5449	5455*	5463	5507*	5515	5527	5533*	5541	5584*	5592	5604	5610*
		5618	5661*	5669	5681	5667*	5695	5739*	5747	5759	5765*	5773	5817*	5825
		5837	5843*	5851	5895*	5903	5915	5921*	5929	5971*	5979	5991	5997*	6005
		6049*	6057	6069	6075*	6083	6132*	6141	6153	6159*	6167	6216*	6225	6237
		6243*	6251	6301*	6310	6322	6328*	6336	6385*	6394	6406	6412*	6420	6469*
		6478	6490	6496*	6504	6553*	6562	6574	6580*	6588	6638*	6647	6694*	6702
		6714	6719*	6727	6773*	6778	6784	6796	6801*	6809	6855*	6863	6875	6880*
		6888	6925*	6927	6934*	6938	7936	7939	7942	7945	7950	7953	7956	7965
		7969	7974	7976	7981	7986								
T. CS2	004130	2284*	4594*	4605	4700*	4711	4753*	4764	4821*	4829	4898*	4905	4910*	4914
		4984*	4994	5043*	5056	5066	5072*	5082	5123*	5133	5143	5149*	5159	5200*
		5210	5220	5226*	5236	5275*	5285	5295	5301*	5311	5352*	5362	5372	5378*
		5388	5430*	5440	5450	5456*	5466	5508*	5518	5528	5534*	5544	5585*	5595
		5605	5611*	5621	5662*	5672	5682	5688*	5698	5740*	5750	5760	5766*	5776
		5818*	5828	5838	5844*	5854	5896*	5906	5916	5922*	5932	5972*	5982	5992
		5998*	6008	6050*	6060	6070	6076*	6086	6133*	6144	6154	6160*	6170	6217*
		6228	6238	6244*	6254	6302*	6313	6323	6329*	6339	6386*	6397	6407	6413*
		6423	6470*	6481	6491	6497*	6507	6554*	6565	6575	6581*	6591	6639*	6650
		6695*	6705	6715	6720*	6730	6774*	6787	6797	6802*	6812	6856*	6866	6876
		6881*	6891	7965	7976	7981								
		2283*												
		2289*												
		2288*												
		2285*												
		5067	4595*	4611	4701*	4717	4754*	4770	4899*	4985*	5000	5044*	5050	5062
		5276*	5073*	5085	5124*	5136	5144	5150*	5162	5201*	5213	5221	5227*	5239
		5457*	5288	5296	5302*	5314	5353*	5365	5373	5379*	5391	5431*	5443	5451
		5675	5469	5509*	5521	5529	5535*	5547	5586*	5598	5606	5612*	5624	5663*
		5857	5683	5689*	5701	5741*	5753	5761	5767*	5779	5819*	5831	5839	5845*
		6071	5897*	5909	5917	5923*	5935	5973*	5985	5993	5999*	6011	6051*	6063
		6303*	6077*	6089	6134*	6147	6155	6161*	6173	6218*	6231	6239	6245*	6257
		6498*	6316	6324	6330*	6342	6387*	6400	6408	6414*	6426	6471*	6484	6492
		6733	6510	6555*	6568	6576	6582*	6594	6640*	6653	6696*	6708	6716	6721*
		7984	6775*	6790	6798	6803*	6815	6857*	6869	6877	6882*	6894	7965	7976
		2293*												
		2294*												
T. ECPS	004152	2286*	4596*	4608	4702*	4714	4755*	4767	4822*	4832	4900*	4911*	4986*	4997
T. ECPT	004154	5045*	5059	5068	5074*	5088	5125*	5139	5145	5151*	5165	5202*	5216	5222
T. ER	004134	5228*	5242	5277*	5291	5297	5303*	5317	5354*	5368	5374	5380*	5394	5432*
		5446	5452	5458*	5472	5510*	5524	5530	5536*	5550	5587*	5601	5607	5613*
		5627	5664*	5678	5684	5690*	5704	5742*	5756	5762	5768*	5782	5820*	5834
		5840	5846*	5860	5898*	5912	5918	5924*	5938	5974*	5988	5994	6000*	6014
		6052*	6066	6072	6078*	6092	6135*	6150	6156	6162*	6176	6219*	6234	6240
		6246*	6260	6304*	6319	6325	6331*	6345	6388*	6403	6409	6415*	6429	6472*
		6487	6493	6499*	6513	6556*	6571	6577	583*	6597	6641*	6656	6697*	6711
		6717	6722*	6736	6776*	6793	6799	6804*	6818	6858*	6872	6878	6883*	6897
		6926*	6930	6935*	6941	7965	7979	7984	7986					
		2290*	2751*	2756	2767	3725*	3729	3740	3792*	3796	3807	3859*	3863	3874
T. MR1	004144	3926*	3930	3941	3993*	3997	4008	4060*	4064	4075	4120*	4124	4135	7945
T. MR2	004146	2291*	2517*	2527	2530	2534	2537	2580*	2590	2597	2631*	2642	2648	2689*
		2704	2711	2752*	2780	2820*	2830	2839	2883*	2893	2902	2946*	2956	2965







\$MAMS4	001260	1208#												
\$MBAOR	001002	1112#												
\$MFLG	043512	7183#	7189	7224*	7228#									
\$MNEW	046025	7616	7756#											
\$MSGAD	001230	1180#	7199*	7202										
\$MSGLG	001232	1181#	7204*											
\$MSGTY	001214	1174#	7197	7205*	7217	7221*								
\$MSWR	046014	7613	7754#											
\$MTYP1	001245	1195#												
\$MTYP2	001251	1203#												
\$MTYP3	001255	1206#												
\$MTYP4	001261	1209#												
\$MXCNT	043022	7094	7104#											
\$NULL	001154	1150#	7418	7447										
\$NWTST=	000001	2485#	2487	2550#	2552	2608#	2610	2657#	2659	2722#	2724	2791#	2793	2854#
		2856	2917#	2919	2980#	2982	3029#	3031	3078#	3080	3144#	3146	3209#	3211
		3278#	3280	3347#	3349	3400#	3402	3460#	3462	3520#	3522	3580#	3582	3640#
		3642	3700#	3702	3767#	3769	3834#	3836	3901#	3903	3968#	3970	4035#	4037
		4095#	4097	4165#	4167	4220#	4222	4276#	4278	4349#	4351	4422#	4424	4487#
		4489	4564#	4566	4619#	4621	4726#	4728	4778#	4780	4875#	4877	4919#	4921
		5006#	5008	5092#	5094	5169#	5171	5246#	5248	5321#	5323	5398#	5400	5476#
		5478	5554#	5556	5631#	5633	5708#	5710	5786#	5788	5864#	5866	5942#	5944
		6018#	6020	6096#	6098	6180#	6182	6264#	6266	6349#	6351	6433#	6435	6517#
		6519	6601#	6603	6664#	6666	6740#	6742	6822#	6824	6903#	6905		
		7479#	7508#	7521#										
\$OCNT	044704	7474#	7478#	7483	7486#	7497#	7523#							
\$OMODE	044706	7048	7073	7082	7092	7101#								
\$OVER	043006	1177#	2400#	6962#	6963#	6974	6996	7088	7105					
\$PASS	001222	1114#												
\$PASTM	001006	7878	7884#											
\$POWER	046414	7869#	7870#	7871#	7873#	7883#								
\$PWRC	046410	2376	7861#	7875										
\$PWROD	046272	7862	7869#											
\$PWUP	046320	1165#	7290	7447	7659	7735	7752	7808	7811					
\$QUES	001210	7672#	7927											
\$RDCHR	045416	7930												
\$RDDEC=	***** U	7700#	7928											
\$RDLIN	045536	7772#	7929											
\$RDOCT	046036	7693#												
\$RDSZ =	000010	7844#	7931											
\$RESRE	046234	6995#												
\$RTNAD	042352	7932												
\$RZA =	***** U	7828#	7930											
\$SAVRE	046176	2370	7045#											
\$SCOPE	042512	2348#	2369	2370	2372	2374	2376	2378	2379	2380	2382	2410	2413	6960
\$SETUP=	000137	7046	7251	7277	7285	7596	7758							
		2348#												
\$STUP =	177777	7056	7095#											
\$SVLAD	042752	1088#	1093											
\$SVPC =	000220	800#	810	814	815	816	817	818	819	820	821	1162	1163	1164
\$SWR =	167400	2379	2380	2382	2383	2496	2562	2618	2669	2733	2802	2865	2928	2990
		3039	3089	3156	3220	3290	3360	3413	3473	3533	3593	3653	3711	3778
		3845	3912	3979	4046	4106	4177	4232	4287	4362	4434	4500	4577	4632
		4737	4794	4886	4930	5019	5104	5181	5258	5333	5411	5489	5566	5643
		5721	5799	5877	5955	6031	6109	6193	6278	6362	6446	6530	6614	6676
		6754	6839	6912	6955	6961	6988	6994	6996	7037	7038	7039	7040	7041







PARGEN	1117#	4363	4501												
POP	932#	7225	7226	7577	7800	7849									
PUSH	932#	7186	7188	7209	7536	7774	7829								
REPORT	932#														
SCOPE	827#	2495	2561	2617	2668	2732	2801	2864	2927	2989	3038	3088	3155	3219	3289
	3359	3412	3472	3532	3592	3652	3710	3777	3844	3911	3978	4045	4105	4176	4231
	4286	4361	4433	4499	4576	4631	4736	4793	4885	4929	5018	5103	5180	5257	5332
	5410	5488	5565	5642	5720	5798	5876	5954	6030	6108	6192	6277	6361	6445	6529
	6613	6675	6753	6838	6911	6959									
SETPRI	932#														
SETTRA	7910#	7919	7920	7921	7922	7924	7926	7927	7928	7929	7930	7931	7932		
SETUP	932#	2361													
SKIP	932#	2509	2525	2547	2640	2646	2653	2849	2912	2975	3012	3018	3025	3061	3067
	3074	3204	3384	3391	3397	3437	3444	3451	3457	3497	3504	3511	3517	3557	3564
	3571	3577	3617	3624	3631	3637	3677	3684	3691	3697	3738	3744	3751	3758	3764
	3805	3811	3818	3825	3831	3872	3878	3885	3892	3898	3939	3945	3952	3959	3965
	4006	4012	4019	4026	4032	4073	4079	4086	4092	4133	4139	4146	4153	4159	4199
	4204	4255	4260	4335	4340	4346	4479	4723	4947	4963	4968	4973	5001	5089	5166
	5243	5318	5395	5473	5551	5628	5705	5783	5861	5939	6015	6093	6177	6261	6346
	6430	6514	6598	6737	6819	6898									
SLASH	932#														
SPACE	932#														
STARS	932#	1086	1037	1099	1106	1119	1168	1171	2485	2494	2550	2560	2608	2616	2657
	2667	2722	2731	2791	2800	2854	2863	2917	2926	2987	2988	3029	3037	3078	3087
	3144	3154	3209	3218	3278	3298	3347	3358	3400	3411	3460	3471	3520	3531	3580
	3591	3640	3651	3700	3709	3767	3776	3834	3843	3901	3910	3968	3977	4035	4044
	4095	4104	4165	4175	4220	4230	4276	4285	4349	4360	4422	4432	4487	4498	4564
	4575	4619	4630	4726	4735	4778	4792	4875	4884	4919	4928	5006	5017	5092	5102
	5169	5179	5246	5256	5321	5331	5398	5409	5476	5487	5554	5564	5631	5641	5708
	5719	5786	5797	5864	5875	5942	5953	6018	6029	6096	6107	6180	6191	6264	6276
	6349	6360	6433	6444	6517	6528	6601	6612	6664	6674	6740	6752	6822	6837	6903
	6910	6951	7033	7170	7181	7238	7291	7300	7370	7449	7526	7593	7596	7664	7693
	7760	7813	7859	7867	7889										
SWRSU	932#	2384#													
TPMTRP	7910#														
TYPBIN	932#														
TYPDEC	932#	6974	6981												
TYPNAM	932#	2406													
TYPNUM	932#														
TYPOCS	932#														
TYPOCT	932#	2430	7614												
TYPTXT	932#	6970	6977												
SSCMRE	1117#														
SSCMTM	1117#	1154	1155	1156	1157	1158	1159	1160	1161						
SSESCA	932#														
SSNEWT	932#	2485	2550	2608	2657	2722	2791	2854	2917	2980	3029	3078	3144	3209	3278
	3347	3400	3460	3520	3580	3640	3700	3767	3834	3901	3968	4035	4095	4165	4220
	4276	4349	4422	4487	4564	4619	4726	4778	4875	4919	5006	5092	5169	5246	5321
	5398	5476	5554	5631	5708	5786	5864	5942	6018	6096	6180	6264	6349	6433	6517
	6601	6664	6740	6822	6903										
SSSET	7910#	7919	7920	7921	7922	7924	7926	7927	7928	7929	7930	7931	7932		
SSSETM	2400#														
SSSKIP	932#	2509	2525	2547	2640	2646	2653	2849	2912	2975	3012	3018	3025	3061	3067
	3074	3204	3384	3391	3397	3437	3444	3451	3457	3497	3504	3511	3517	3557	3564
	3571	3577	3617	3624	3631	3637	3677	3684	3691	3697	3738	3744	3751	3758	3764
	3805	3811	3818	3825	3831	3872	3878	3885	3892	3898	3939	3945	3952	3959	3965

	4006	4012	4019	4026	4032	4073	4079	4086	4092	4133	4139	4146	4153	4159	4199
	4204	4255	4260	4335	4340	4346	4479	4723	4947	4963	4968	4973	5001	5089	5166
	5243	5318	5395	5473	5551	5628	5705	5783	5861	5939	6015	6093	6177	6261	6346
	6430	6514	6598	6737	6819	6898									
.EQUAT	800#	822													
.FEAD	800#														
.SETUP	800#	2348													
.SWRHI	800#	810													
.SWRLO	800#	822#													
.SACT1	800#	1084													
.SAPT8	1169#														
.SAPTH	800#	1095													
.SAPTY	800#	7179													
.SCATC	800#	1070													
.SCMTA	800#	1117													
.SEOP	800#	6949													
.SERRO	800#	7236													
.SERRT	800#														
.SPOWE	800#														
.SROOC	800#	7758													
.SREAD	800#	7591													
.SSAVE	800#	7811													
.SSCOP	800#	7031													
.STRAP	800#	7887													
.STYPD	800#	7524													
.STYPE	800#	7368													
.STYPO	800#	7447													

. ABS. 061233 000

ERRORS DETECTED: 0

RM03:CZR6BC, RM03:CZR6BC.SEQ/SOL/CRF/NL:TOC/DOC=RM03:CZR6BC.P11  
RUN-TIME: 33 29 3 SECONDS  
RUN-TIME RATIO: 1288/65=19.5  
CORE USED: 30K (59 PAGES)

DOCUMENT PAGES: 189