

# RM03,02

FUNCTIONAL TEST 1  
CZRMCB0

AH-A998B-MC  
COPYRIGHT © 1977  
FICHE 1 OF 2

JAN 1978  
**digital**  
MADE IN USA

This image shows a microfiche card with a grid of 15 columns and 12 rows of frames. Each frame contains a small, illegible image or document snippet. The card is dark blue with a lighter blue grid pattern. The text at the top of the card is white and black. The microfiche card is a standard format for storing digital information on a physical medium.

# RM03,02

FUNCTIONAL TEST 1  
CZRMCB0

AH-A998B-MC

COPYRIGHT © 1977

FICHE 2 OF 2

JAN 1978

**digital**

MADE IN USA

This microfiche card contains a grid of frames. The left side of the card is filled with a grid of frames, each containing a small table of data. The data is organized into columns and rows, with some frames containing headers and footers. The right side of the card is mostly blank, with a few faint frames visible at the bottom right corner.

Frame 1	Frame 2	Frame 3	Frame 4	Frame 5	Frame 6	Frame 7	Frame 8	Frame 9	Frame 10
Table 1	Table 2	Table 3	Table 4	Table 5	Table 6	Table 7	Table 8	Table 9	Table 10
Table 11	Table 12	Table 13	Table 14	Table 15	Table 16	Table 17	Table 18	Table 19	Table 20
Table 21	Table 22	Table 23	Table 24	Table 25	Table 26	Table 27	Table 28	Table 29	Table 30
Table 31	Table 32	Table 33	Table 34	Table 35	Table 36	Table 37	Table 38	Table 39	Table 40
Table 41	Table 42	Table 43	Table 44	Table 45	Table 46	Table 47	Table 48	Table 49	Table 50
Table 51	Table 52	Table 53	Table 54	Table 55	Table 56	Table 57	Table 58	Table 59	Table 60
Table 61	Table 62	Table 63	Table 64	Table 65	Table 66	Table 67	Table 68	Table 69	Table 70
Table 71	Table 72	Table 73	Table 74	Table 75	Table 76	Table 77	Table 78	Table 79	Table 80
Table 81	Table 82	Table 83	Table 84	Table 85	Table 86	Table 87	Table 88	Table 89	Table 90
Table 91	Table 92	Table 93	Table 94	Table 95	Table 96	Table 97	Table 98	Table 99	Table 100

.REM \

IDENTIFICATION

PRODUCT CODE:	AC-A997B-MC
PRODUCT NAME:	CZRMCB0 RMO3/RMO2 FUNCTIONAL TEST PART 1
DATE CREATED:	1 AUGUST 77
MAINTAINER:	DIAGNOSTIC GROUP
AUTHOR:	DOUG RIIKONEN

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS MANUAL.

THE SOFTWARE DESCRIBED IN THIS DOCUMENT IS FURNISHED TO THE PURSHASER UNDER A LICENSE FOR USE ON A SINGLE COMPUTER SYSTEM AND CAN BE COPIED (WITH INCLUSION OF DIGITAL'S COPYRIGHT NOTICE) ONLY FOR USE IN SUCH SYSTEM, EXCEPT AS MAY OTHERWISE BE PROVIDED IN WRITING BY DIGITAL.

DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL.

COPYRIGHT (C) 1977, DIGITAL EQUIPMENT CORPORATION

1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55  
56  
57  
58  
59  
60  
61  
62  
63  
64  
65  
66  
67  
68  
69  
70  
71  
72  
73  
74  
75  
76  
77  
78  
79  
80  
81  
82  
83  
84  
85  
86  
87  
88  
89  
90  
91  
92  
93  
94  
95  
96  
97  
98  
99  
100

.PAGE

CONTENTS

1. INTRODUCTION
  1. ABSTRACT
  2. UNIT UNDER TEST
2. OPERATING REQUIREMENTS
  1. HARDWARE REQUIREMENTS
  2. MEDIA REQUIREMENTS
  3. PREREQUISITE DIAGNOSTIC PROGRAMS
3. OPERATING PROCEDURE
  1. LOADING
  2. SWITCH OPTIONS
  3. STARTING
  4. HALTING
  5. RESTARTING
4. OPERATOR INTERFACE
  1. PROGRAM I.D.
  2. CONSOLE DIALOGUE
  3. PROGRESS REPORTS
  4. PERFORMANCE REPORTS
  5. PROGRAM HALTS
  6. ERROR REPORTS
5. ENVIRONMENTAL SUPPORT
  1. PROCESSOR COMPATIBILITY

1100  
1101  
1102  
1103  
1104  
1105  
1106  
1107  
1108  
1109  
1110  
1111  
1112  
1113  
1114  
1115  
1116  
1117  
1118  
1119  
1120  
1121  
1122  
1123  
1124  
1125  
1126  
1127  
1128  
1129  
1130  
1131  
1132  
1133  
1134  
1135  
1136  
1137  
1138  
1139  
1140  
1141  
1142  
1143  
1144  
1145  
1146  
1147  
1148  
1149  
1150  
1151  
1152  
1153  
1154  
1155  
1156  
1157  
1158  
1159  
1160  
1161  
1162  
1163  
1164  
1165  
1166  
1167  
1168  
1169  
1170  
1171  
1172  
1173  
1174  
1175  
1176  
1177  
1178  
1179  
1180  
1181  
1182  
1183  
1184  
1185  
1186  
1187  
1188  
1189  
1190  
1191  
1192  
1193  
1194  
1195  
1196  
1197  
1198  
1199  
1200  
1201  
1202  
1203  
1204  
1205  
1206  
1207  
1208  
1209  
1210  
1211  
1212  
1213  
1214  
1215  
1216  
1217  
1218  
1219  
1220  
1221  
1222  
1223  
1224  
1225  
1226  
1227  
1228  
1229  
1230  
1231  
1232  
1233  
1234  
1235  
1236  
1237  
1238  
1239  
1240  
1241  
1242  
1243  
1244  
1245  
1246  
1247  
1248  
1249  
1250

DO1

CZRMCD RM03/2 FCTNL TST 1  
CZRMCD.P11 23-NOV-77 12:14

MACY11 30(1046) 23-NOV-77 12:25 PAGE 3

SEQ 0003

109

2. DUAL PORT CONFIGURATIONS

110  
111  
112  
113  
114  
115  
116  
117  
118  
119  
120  
121  
122  
123  
124  
125

- 3. MEMORY PARITY HARDWARE
  - 4. MEMORY MANAGEMENT HARDWARE
  - 5. ACT,APT COMPATIBILITY
  - 6. XXDP COMPATIBILITY
  - 7. OPERATING SYSTEM COMPATIBILITY
6. TEST DESCRIPTION

126  
127  
128  
129  
130  
131  
132  
133  
134  
135  
136  
137  
138  
139  
140  
141  
142  
143  
144  
145  
146  
147  
148  
149  
150  
151  
152  
153  
154  
155  
156  
157  
158  
159  
160  
161  
162  
163  
164  
165  
166  
167  
168  
169  
170  
171  
172  
173  
174  
175  
176  
177  
178  
179  
180  
181

## 1.0 INTRODUCTION

## 1.1 ABSTRACT

THE RMO3 SUBSYSTEM FUNCTIONAL TEST IS A STAND ALONE PROGRAM WHICH USES FUNCTIONAL MEANS TO VERIFY THE OPERABILITY OF THE RMO3 DISK SUBSYSTEM. IN PARTICULAR, THE PROGRAM SERVES THE FOLLOWING PURPOSES:

TO EXPLICITLY ESTABLISH CONFIDENCE IN THE BASIC OPERATIONS OF THE DISK DRIVE, INCLUDING MECHANICAL POSITIONING AND DATA TRANSFER OPERATIONS;

TO IMPLICITLY ESTABLISH CONFIDENCE IN THE DRIVE/ADAPTER ELECTRICAL INTERFACE;

TO VERIFY THE FUNCTIONALITY OF THE RMO3 SUBSYSTEM, INCLUDING THE MASSBUS CONTROLLER, MASSBUS ADAPTER AND THE DISK DRIVE.

THE TEST IS COMPRISED OF 3 PARTS, WHICH WOULD NORMALLY BE RUN IN SEQUENCE, STARTING WITH PART 1. BRIEFLY, PART 1 TESTS HOUSEKEEPING AND MECHANICAL POSITIONING OPERATIONS; PART 2 TESTS WRITE, READ AND WRITE CHECK OPERATIONS USING HEADER AND DATA; PART 3 TESTS WRITE, READ AND WRITE CHECK OPERATIONS USING DATA.

## 1.2 UNIT UNDER TEST

THE UNIT UNDER TEST (UUT) IS THE RMO3 DISK SUBSYSTEM WHICH CONSISTS OF THE RHXX MASSBUS CONTROLLER, THE RMO3 MASSBUS ADAPTER AND THE STORAGE MODULE DISK DRIVE. NOTE THAT A DISK PACK IS REQUIRED FOR TESTING AND IS CONSIDERED AN INTEGRAL OF THE STORAGE MODULE DISK DRIVE.

## 2.0 OPERATING REQUIREMENTS

## 2.1 HARDWARE REQUIREMENTS

THE FOLLOWING MINIMUM HARDWARE CONFIGURATION, ASSUMED TO BE OPERATIONAL, IS REQUIRED TO LOAD AND EXECUTE THE RMO3 SUBSYSTEM FUNCTIONAL TEST:

PDP-11 PROCESSOR  
16K MEMORY  
KW11-L OR KW11-P CLOCK  
PROGRAM LOADING DEVICE  
TERMINAL  
RH11 OR RH70 CONTROLLER  
UNIT UNDER TEST,

WHERE THE UNIT UNDER TEST CONSISTS OF ONE TO EIGHT RMO3 ADAPTERS, DISK

GO1

CZRMCD RMO3/2 FCTNL TST 1  
CZRMCD.P11 23-NOV-77 12:14

MACY11 30(1046) 23-NOV-77 12:25 PAGE 6

SEQ 0006

182

DRIVES AND DISK PACKS.



183  
184  
185  
186  
187  
188  
189  
190  
191  
192  
193  
194  
195  
196  
197  
198  
199  
200  
201  
202  
203  
204  
205  
206  
207  
208  
209  
210  
211  
212  
213  
214  
215  
216  
217  
218  
219  
220  
221  
222  
223  
224  
225  
226  
227  
228  
229  
230  
231  
232  
233  
234  
235  
236  
237  
238

2.2 MEDIA REQUIREMENTS

EACH UNIT BEING TESTED MUST BE LOADED WITH A SCRATCH DISK PACK BEFORE TESTING BEGINS ON THAT UNIT. THE PACK MAY BE FORMATTED OR UNFORMATTED, BUT MUST NOT CONTAIN NEEDED INFORMATION BECAUSE THE PACK WILL BE WRITTEN DURING THE TEST.

NOTE

WHEN THE PROGRAM IS LOADED VIA THE RM03, DRIVE 0 IS NOT TESTED UNLESS THE OPERATOR SPECIFICALLY ENTERS THE DRIVE NUMBER DURING CONSOLE DIALOGUE.

2.3 PREREQUISITE DIAGNOSTIC PROGRAMS

RM03 DISKLESS DIAGNOSTIC, CZRMJ-B

3.0 OPERATING PROCEDURE

3.1 LOADING

THE PROGRAM MAY BE LOADED BY EITHER OF THE FOLLOWING MEDIA:  
. PAPER TAPE, USING THE STANDARD PAPER TAPE LOADING PROCEDURE;  
.XXDP MEDIA, USING THE APPROPRIATE LOADING DEVICE.

NOTE

WHEN THE PROGRAM IS LOADED VIA THE RM03, DRIVE 0 IS NOT TESTED UNLESS THE OPERATOR SPECIFICALLY ENTERS THE DRIVE NUMBER DURING CONSOLE DIALOGUE.

3.2 SWITCH OPTIONS

THE FOLLOWING SWITCH OPTIONS ARE PROVIDED TO ENHANCE THE UTILITY OF THE PROGRAM.

101

CZRMCB0 RMO3/2 FCTNL TST 1  
CZRMCB.P11 23-NOV-77 12:14

MACY11 30(1046) 23-NOV-77 12:25 PAGE 8

SEQ 0008

239  
240

SW15 HALT ON ERROR  
SW14 LOOP ON TEST (CURRENTLY BEING EXECUTED)

41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55  
56  
57  
58  
59  
60  
61  
62  
63  
64  
65  
66  
67  
68  
69  
70  
71  
72  
73  
74  
75  
76  
77  
78  
79  
80  
81  
82  
83  
84  
85  
86  
87  
88  
89  
90  
91  
92  
93  
94  
95  
96

SW13 INHIBIT ERROR TYPEOUTS  
SW12 UNUSED  
SW11 INHIBIT TEST ITERATIONS  
SW10 BELL ON ERROR  
SW09 LOOP ON ERROR  
SW08 LOOP ON TEST IN SW07-00

THE LOW ORDER 8 SWITCHES (SW07-SW00), ARE USED IN CONJUNCTION WITH SW08 TO SPECIFY THE OCTAL NUMBER OF THE TEST WHICH THE PROGRAM WILL LOOP ON.

3.3 STARTING

THE PROGRAM STARTS AT LOCATION 200, WHICH PROVIDES WORST CASE TEST CONDITIONS IF RUNNING IN AN AUTOMATIC ENVIRONMENT. IF RUNNING IN A STAND-ALONE ENVIRONMENT, THE PROGRAM USES CONSOLE DIALOGUE TO ALLOW THE OPERATOR TO CONTROL TEST CONDITIONS.

3.4 HALTING

THE PROGRAM CAN BE HALTED BY TYPING CONTROL C FROM THE CONSOLE.

3.5 RESTARTING

THE PROGRAM CAN BE RESTARTED AT ADDRESS 200.

4.0 OPERATOR INTERFACE

4.1 PROGRAM ID

THE PROGRAM TYPES ITS TITLE AND MAINDEC NUMBER THE FIRST TIME IT IS STARTED AFTER BEING LOADED. PROGRAM IDENTIFICATION DOES NOT OCCUR IF THE PROGRAM IS RESTARTED.

4.2 CONSOLE DIALOGUE

WHEN THE PROGRAM IS RUNNING IN STAND ALONE MODE, IT ENTERS A CONSOLE DIALOGUE SEQUENCE AFTER TYPING THE PROGRAM I.D..

THE FIRST QUESTION TYPED OUT IS: "TYPE HELP TEXT (Y OR N)??". IF THE OPERATOR RESPONDS WITH A Y, THE PROGRAM WILL TYPE A BRIEF HELP MESSAGE WHICH WILL LIST SWITCH OPTIONS, ETC.

THE SECOND QUESTION TYPED OUT IS, "CHANGE RM03 UNIBUS ADDRESS OR VECTOR ADDRESS (Y OR N)??". IF THE UNIBUS ADDRESS OF THE RM03 IS NON STANDARD, THE OPERATOR SHOULD RESPOND Y, THEN ANSWER SUBSEQUENT QUESTIONS TO SPECIFY THE UNIBUS ADDRESS, VECTOR ADDRESS AND INTERRUPT PRIORITY. IF THE OPERATOR DOES NOT RESPOND WITH A Y, THE PROGRAM SKIPS TO THE THIRD QUESTION.

THE THIRD QUESTION TYPED OUT IS, "TYPE (A) TO TEST ALL DEVICES, OR TYPE DEVICE NUMBER(S). TERMINATE INPUT WITH CARRIAGE RETURN". IF THE OPERATOR TYPES A, ALL POSSIBLE DEVICES ARE TESTED. OTHERWISE, THE OPERATOR CAN TYPE THE NUMBER(S) OF THE DEVICE(S) HE WANTS TESTED, AND TERMINATE HIS INPUT WITH A CARRIAGE RETURN.

IF THE PROGRAM IS RESTARTED, THE FIRST QUESTION TYPED IS, "USE SAME DEVICES (Y OR N)??". IF THE OPERATOR TYPES Y, THE TEST IS RESTARTED USING THE SAME DEVICES AS THE LAST TIME, OTHERWISE, THE TEST RESTARTS THE DIALOGUE AS IF THE PROGRAM WERE STARTED FOR THE FIRST TIME.

#### 4.3 PROGRESS REPORTS

AN END OF PASS REPORT OCCURS EACH TIME THE PROGRAM IS EXECUTED FOR ALL DEVICES IN THE TEST QUEUE. THE END OF PASS REPORT INCLUDES A MESSAGE AND AN ERROR SUMMARY.

#### 4.4 PERFORMANCE REPORT

NO PERFORMANCE REPORTS ARE GIVEN DURING THE EXECUTION OF THE PROGRAM.

#### 4.5 PROGRAM HALTS

THERE ARE NO SCHEDULED HALTS DURING THE EXECUTION OF THE PROGRAM. PROCESSOR HALTS ARE DUE TO THE TRAP CATCHER.

#### 4.6 ERROR REPORTS

THE FIRST LINE OF THE ERROR REPORT CONTAINS THE NUMBER OF THE UNIT BEING TESTED, THE TEST NUMBER, THE ERROR NUMBER AND THE VALUE OF THE PROGRAM COUNTER WHERE THE ERROR WAS CALLED. THIS LINE IS FOLLOWED BY THE ERROR MESSAGE: ONE OR MORE LINES OF TEXT WHICH GIVE A BRIEF, YET COMPREHENSIVE DESCRIPTION OF THE ERROR. THE ERROR MESSAGE IS NORMALLY FOLLOWED BY ONE OR MORE PAIRS OF LINES CONTAINING DATA HEADERS AND DATA PERTINENT TO THE ERROR, INCLUDING EXPECTED AND ACTUAL TEST RESULTS.

297  
298  
299  
300  
301  
302  
303  
304  
305  
306  
307  
308  
309  
310  
311  
312  
313  
314  
315  
316  
317  
318  
319  
320  
321  
322  
323  
324  
325  
326  
327  
328  
329  
330  
331  
332  
333  
334  
335  
336  
337  
338  
339  
340  
341  
342  
343  
344  
345  
346  
347  
348  
349  
350  
351  
352

353  
354  
355  
356  
357  
358  
359  
360  
361  
362  
363  
364  
365  
366  
367  
368  
369  
370  
371  
372  
373  
374  
375  
376  
377  
378  
379  
380  
381  
382  
383  
384  
385  
386  
387  
388  
389  
390  
391  
392  
393  
394  
395  
396  
397  
398  
399  
400  
401  
402  
403

5.0 ENVIRONMENTAL SUPPORT

5.1 PROCESSOR COMPATIBILITY

THE RMO3 SUBSYSTEM FUNCTIONAL TEST IS EXECUTABLE ON ANY PDP-11 PROCESSOR, PROVIDING PREVIOUSLY MENTIONED HARDWARE REQUIREMENTS ARE MET, AND PROVIDING THAT DATA THROUGHPUT ON THE SYSTEM IS SUFFICIENT TO SUSTAIN DATA TRANSFER OPERATIONS.

5.2 DUAL PORT CONFIGURATIONS

THE RMO3 SUBSYSTEM FUNCTIONAL TEST DOES NOT SPECIFICALLY TEST DUAL PORT LOGIC IN THE RMO3 ADAPTER BUT IS EXECUTABLE ON RMO3 SUBSYSTEMS HAVING THE DUAL PORT OPTION PROVIDING THE DUAL PORT SWITCH IS SET TO THE APPROPRIATE PORT (A OR B).

5.3 MEMORY PARITY HARDWARE

MEMORY PARITY HARDWARE IS NOT USED DURING THE EXECUTION OF THE RMO3 SUBSYSTEM FUNCTIONAL TEST.

5.4 MEMORY MANAGEMENT HARDWARE

MEMORY MANAGEMENT HARDWARE IS NOT USED DURING THE RMO3 SUBSYSTEM FUNCTIONAL TEST. CAPABILITIES OF THE MASSBUS CONTROLLER.

5.5 ACT11, APT11 COMPATIBILITY

THE RMO3 SUBSYSTEM FUNCTIONAL TEST IS COMPATIBLE WITH ACT11 AND APT11 IN BOTH DUMP AND AUTOMATIC MODES. FURTHER, THE PROGRAM WILL EXECUTE A QUICK PASS DURING THE FIRST PASS IN SUPPORT OF QUICK VERIFY MODE.

5.6 XXDP COMPATIBILITY

THE RMO3 SUBSYSTEM FUNCTIONAL TEST IS COMPATIBLE WITH XXDP IN DUMP AND CHAIN MODES, AND PROVIDES MEDIA PROTECTION IN THE CASE WHERE THE RMO3 IS THE XXDP LOADING DEVICE.

MO1

CZRMCD RMO3/2 FCTNL TST 1  
CZRMCD.P11 23-NOV-77 12:14

MACY11 30(1046) 23-NOV-77 12:25 PAGE 12

SEQ 0012

PAGE 8

404  
405  
406  
407  
408  
409

5.7 OPERATING SYSTEM COMPATIBILITY

THE PROGRAM IS NOT COMPATIBLE WITH ANY SOFTWARE OPERATING SYSTEM.

410  
411  
412  
413  
414  
415  
416  
417  
418  
419  
420  
421  
422  
423  
424  
425  
426  
427  
428  
429  
430  
431  
432  
433  
434  
435  
436  
437  
438  
439  
440  
441  
442  
443  
444  
445  
446  
447  
448  
449  
450  
451  
452  
453  
454  
455  
456  
457  
458  
459  
460  
461  
462  
463  
464  
465

6.0 TEST DESCRIPTION

CONTROLLER ACCESS TEST

PURPOSE:

TO VERIFY THAT THE UNIBUS ADDRESS OF THE RM03 SUBSYSTEM IS CORRECT, AS DEFINED AT LOCATION \$BASE.

PROCEDURE:

THE TEST TRIES TO ACCESS ALL MASSBUS CONTROLLER REGISTERS USING THE \$BASE ADDRESS. REGISTER CONTENTS ARE IGNORED DURING THE TEST, AND THE TEST FAILS IF A BUS TIMEOUT OCCURS FOR ANY REGISTER TRANSFER.

IF THE TEST FAILS AND THE PROGRAM IS RUNNING IN A STAND ALONE ENVIRONMENT, I.E.; LOCATION 42 IS 0, THE PROGRAM WILL JUMP TO LOCATION 204 WHICH ALLOWS THE OPERATOR TO CHANGE THE \$BASE ADDRESS VIA CONSOLE DIALOGUE. OTHERWISE, THE PROGRAM ESCAPES TO THE END OF PASS HANDLER.

DEVICE AVAILABLE TEST

PURPOSE:

TO VERIFY THAT THE UNIT UNDER TEST IS AVAILABLE FOR TESTING, AND IS NOT LOCKED OR PROGRAMMED TO THE ALTERNATE PORT.

PROCEDURE:

THIS TEST SELECTS THE DEVICE AND READS CONTROL STATUS REGISTERS 1 AND 2 TO VERIFY THAT THE SELECTED DEVICE IS AVAILABLE FOR TESTING, AS INDICATED BY DVA STATUS, BIT 11 OF RMCS1 AND NED STATUS, BIT 12 OF RMCS2. THE RESULTS OF THE TEST CAN VARY AS FOLLOWS:

.NONEXISTANT DEVICE - THE DEVICE IS NONEXISTENT OR IS LOCKED ON THE ALTERNATE PORT AND IS THEREFORE NOT AVAILABLE FOR TESTING;

.DEVICE NOT AVAILABLE - THE DEVICE EXISTS BUT IS SEIZED BY THE ALTERNATE PORT AND IS NOT AVAILABLE FOR TESTING;

.BUS TIMEOUT - THE MASSBUS CONTROLLER FAILED TO DETECT A

CZRMCB0 RMO3/2 FCTNL TST 1  
CZRMCB.P11 23-NOV-77 12:14

MACY11 30(1046) 23-NOV-77 12:25 PAGE 14

**B02**

SEQ 0014

466

NONEXISTENT DEVICE;



467  
468  
469  
470  
471  
472  
473  
474  
475  
476  
477  
478  
479  
480  
481  
482  
483  
484  
485  
486  
487  
488  
489  
490  
491  
492  
493  
494  
495  
496  
497  
498  
499  
500  
501  
502  
503  
504  
505  
506  
507  
508  
509  
510  
511  
512  
513  
514  
515  
516  
517  
518  
519  
520  
521

.DEVICE AVAILABLE - THE DEVICE IS AVAILABLE FOR TESTING.  
THE PROGRAM JUMPS TO THE SUBPASS HANDLER WHICH SELECTS THE  
NEXT DRIVE TO BE TESTED IF THE DEVICE IS NOT AVAILABLE.

DRIVE TYPE TEST

PURPOSE:

TO VERIFY THAT THE UNIT UNDER TEST IS AN RMO3 SINGLE PORT OR  
DUAL PORT SUBSYSTEM.

PROCEDURE:

THIS TEST READS THE DRIVE TYPE REGISTER, RMDT, OF THE  
SELECTED DEVICE AND VERIFIES THAT THE DEVICE IS A SINGLE PORT OR  
DUAL PORT RMO3 SUBSYSTEM. IF THE SELECTED DEVICE IS NOT AN RMO3,  
THE PROGRAM JUMPS TO THE SUBPASS HANDLER WHICH WILL SELECT THE  
NEXT DEVICE FOR TESTING.

UNIBUS INITIALIZE TEST

PURPOSE:

TO VERIFY THAT ALL APPLICABLE SUBSYSTEM REGISTERS ARE  
INITIALIZED BY THE RESET INSTRUCTION.

PROCEDURE:

NONZERO VALUES ARE WRITTEN IN EACH APPLICABLE REGISTER. A  
RESET INSTRUCTION IS EXECUTED, AND THE REGISTERS ARE TESTED TO  
INSURE THEY WERE INITIALIZED. THIS TEST IS DONE ONCE BECAUSE OF  
APT COMPATIBILITY REQUIREMENTS.

THE FOLLOWING REGISTERS ARE PRESET BEFORE THE INITIALIZE  
OCCURS:

- RMCS1 - 003577
- RMBA - 777776
- RMCS2 - 021037
- RMER1 - 777777

RMER3 - 777777

RMMR - 040001

IN ADDITION, THE DATA BUFFER IS USED TO FORCE DLT, TRE, SC AND OR  
TO A ONE AND TO FORCE IR TO A ZERO.

CONTROLLER CLEAR TEST

PURPOSE:

TO VERIFY THAT APPLICABLE SUBSYSTEM REGISTERS ARE  
INITIALIZED BY A "CONTROLLER CLEAR" OPERATION.

PROCEDURE:

LIKE THE UNIBUS INITIALIZE TEST, THIS TEST WRITES NONZERO  
VALUES IN THOSE REGISTERS WHICH ARE INITIALIZED BY CONTROLLER  
CLEAR. THE SUBSYSTEM IS THEN CLEARED USING A CONTROLLER CLEAR,  
I.E., BIT 5 OF CONTROL STATUS REGISTER 2 (RMCS2), AND EACH  
REGISTER IS READ TO INSURE IT WAS CLEARED.

ERROR CLEAR TEST

PURPOSE:

TO VERIFY THAT ALL APPLICABLE RH70 MASSBUS CONTROLLER STATUS  
AND ERROR CONDITIONS ARE INITIALIZED BY AN ERROR CLEAR OPERATION.

PROCEDURE:

AN "RH70 ERROR CLEAR" OPERATION, I.E., WRITING A ONE IN TRE,  
BIT 14 OF RMCS1 WILL CLEAR THE FOLLOWING STATUS BITS:

- .TRE, BIT 14 OF RMCS1
- .MCPE, BIT 13 OF RMCS1 - READ ONLY
- .DLT, BIT 15 OF RMCS2 - READ ONLY
- .WCE, BIT 14 OF RMCS2 - READ ONLY
- .UPE, BIT 13 OF RMCS2
- .NED, BIT 12 OF RMCS2 - READ ONLY

52  
53  
54  
55  
56  
57  
58  
59  
60  
61  
62  
63  
64  
65  
66  
67  
68  
69  
70  
71  
72  
73  
74  
75  
76  
77

578  
579  
580  
581  
582  
583  
584  
585  
586  
587  
588  
589  
590  
591  
592  
593  
594  
595  
596  
597  
598  
599  
600  
601  
602  
603  
604  
605  
606  
607  
608  
609  
610  
611  
612  
613  
614  
615  
616  
617  
618  
619  
620  
621  
622  
623  
624  
625  
626  
627  
628  
629  
630  
631  
632  
633

.PGE, BIT 10 OF RMCS2 - READ ONLY  
.MXF, BIT 09 OF RMCS2  
.MDPE, BIT 08 OF RMCS2 - READ ONLY

THE TEST SETS UPE AND MXF STATUS BITS, THEN SETS TRE (ERROR CLEAR) AND VERIFIES THAT ALL THE ABOVE STATUS BITS ARE CLEARED.

#### DRIVE STATUS TEST

##### PURPOSE:

TO VERIFY THAT THE STORAGE MODULE DISK DRIVE IS IN A STATE THAT PERMITS FURTHER TESTING.

##### PROCEDURE:

THIS TEST INITIALIZES THE MASSBUS AND EXAMINES STATUS OF THE SELECTED DEVICE FOR THE FOLLOWING CONDITIONS:

.MOL, BIT 12 OF RMDS =1, INDICATING THAT UNIT READY IS ASSERTED BY THE DRIVE;

.WRL, BIT 11 OF RMDS =0, INDICATING THAT THE DRIVE IS NOT IN A WRITE PROTECT STATE;

.DVC, BIT 07 OF RMER3 =0, INDICATING DRIVE FAULT IS UNASSERTED BY THE DRIVE;

.UNS, BIT 14 OF RMER1 SHOULD EQUAL DVC, OTHERWISE AC POWER IS LOW OR A FAILURE HAS OCCURRED WITH UNSAFE STATUS.

#### PRIMARY/SECONDARY ERROR TEST

##### PURPOSE:

TO VERIFY THAT THE RMO3 CAN EXECUTE A COMMAND WITHOUT INCURRING UNEXPECTED ERRORS. PROCEDURE:

THE TEST EXECUTES A PACK ACKNOWLEDGE COMMAND AND MAKES SURE THAT GO RESETS AND THAT THERE ARE NO PARITY ERRORS, ETC. VOLUME VALID STATUS IS IGNORED.

634  
635  
636  
637  
638  
639  
640  
641  
642  
643  
644  
645  
646  
647  
648  
649  
650  
651  
652  
653  
654  
655  
656  
657  
658  
659  
660  
661  
662  
663  
664  
665  
666  
667  
668  
669  
670  
671  
672  
673  
674  
675  
676  
677  
678  
679  
680  
681  
682  
683  
684  
685  
686  
687  
688  
689

DIAGNOSTIC MODE TEST

PURPOSE:

TO VERIFY THAT MAINTENANCE HARDWARE IS OPERATIONAL.

PROCEDURE:

THE TEST THAT DIAGNOSTIC MODE CAN BE SET AND RESET, THEN VERIFIES THAT "MOL, PIP, WRL, SKI, AND DVC" CAN BE CONTROLLED USING MAINTENANCE REGISTER 1.

PACK ACKNOWLEDGE TEST

PURPOSE:

TO VERIFY THAT VOLUME VALID CAN BE SET BY A PACK ACKNOWLEDGE COMMAND, LENDING CREDENCE TO THE EXECUTION OF THE COMMAND AND TO THE STABILITY OF THE UNIT READY SIGNAL FROM THE DRIVE.

PROCEDURE:

A PACK ACKNOWLEDGE COMMAND IS ISSUED TO THE SELECTED DEVICE AND VOLUME VALID STATUS, BIT 10 OF RMD5, IS CHECKED FOR ONE.

RECALIBRATE TEST

PURPOSE:

THE PRIMARY PURPOSE IS TO ASCERTAIN THAT THE DRIVE WILL EXECUTE A RECALIBRATE OPERATION TO THE EXTENT THAT "PIP" AND "SKI" STATUS BECOME UNASSERTED AT THE COMPLETION OF THE RECALIBRATE. THE SECONDARY PURPOSE IS TO PUT THE DRIVE IN A KNOWN STATE SO THAT FURTHER TESTS CAN CHECK FOR UNEXPECTED STATE CHANGES IN THE DRIVE.

PROCEDURE:

THE RECALIBRATE TEST PRESETS THE DISK ADDRESS REGISTER, RMDA, AND THE DESIRED CYLINDER REGISTER, RMDC, TO ZERO, THEN EXECUTES A RECALIBRATE COMMAND. THE TEST VERIFIES THE FOLLOWING CONDITIONS:

.SKI=0, "SEEK ERROR" IS INACTIVE;

690  
691  
692  
693  
694  
695  
696  
697  
698  
699  
700  
701  
702  
703  
704  
705  
706  
707  
708  
709  
710  
711  
712  
713  
714  
715  
716  
717  
718  
719  
720  
721  
722  
723  
724  
725  
726  
727  
728  
729  
730  
731  
732  
733  
734  
735  
736  
737  
738  
739  
740  
741  
742  
743  
744  
745

.PIP=0, "ON CYLINDER" IS ACTIVE, AS INDICATED BY  
"POSITIONING IN PROGRESS" BEING INACTIVE;

.IAE=0, NO "INVALID ADDRESS ERROR" DURING RECALIBRATE;

.OPI=0, NO "OPERATION INCOMPLETE ERROR" INDICATING THAT  
THAT THE DRIVE WAS READY AT THE START OF THE COMMAND AND THAT ON  
CYLINDER STATUS WENT INACTIVE WHEN THE DRIVE RECEIVED THE  
COMMAND;

.ATA=1, ATTENTION IS SET BY RECALIBRATE.

ABORT RECALIBRATE TEST

PURPOSE:

TO VERIFY THAT THE RMO3 INHIBITS A RECALIBRATE WHEN AN ABORT  
CONDITION EXISTS AT THE START OF THE COMMAND.

PROCEDURE:

THE TEST SETS AN ERROR IN THE ERROR REGISTER AND ISSUES A  
RECALIBRATE COMMAND, VERIFYING THAT "PIP" REMAINS INACTIVE.

IVC RECALIBRATE TEST

PURPOSE:

TO VERIFY THAT INVALID COMMAND STATUS, BIT 12 OF RMER2, SETS  
WHEN VOLUME VALID IS INACTIVE DURING A RECALIBRATE COMMAND.

PROCEDURE:

THE PROGRAM SETS AND RESETS DIAGNOSTIC MODE WHICH CAUSES  
VOLUME VALID, BIT 6 OF RMD5 TO RESET. THE PROGRAM THEN EXECUTES  
A RECALIBRATE COMMAND AND VERIFIES THAT "IVC" STATUS SETS AND  
THAT "PIP" REMAINS INACTIVE.

IAE RECALIBRATE TEST

PURPOSE:

746  
747  
748  
749  
750  
751  
752  
753  
754  
755  
756  
757  
758  
759  
760  
761  
762  
763  
764  
765  
766  
767  
768  
769  
770  
771  
772  
773  
774  
775  
776  
777  
778  
779  
780  
781  
782  
783  
784  
785  
786  
787  
788  
789  
790  
791  
792  
793  
794  
795  
796  
797  
798  
799  
800

TO VERIFY THAT INVALID ADDRESS ERROR DOES NOT SET DURING A  
RECALIBRATE COMMAND .

## PROCEDURE:

THE TEST PRESETS THE DISK ADDRESS (RMDA) AND THE DESIRED  
CYLINDER ADDRESS (RMDC) TO ILLEGAL VALUES AND ISSUES A  
RECALIBRATE COMMAND, VERIFYING THAT "IAE" DOES NOT SET DURING THE  
COMMAND.

## RECALIBRATE AT OFFSET

## PURPOSE:

TO VERIFY THAT OFFSET MODE DOES NOT AFFECT RECALIBRATE.  
PROCEDURE:

THE TEST EXECUTES AN OFFSET COMMAND, THEN EXECUTES A  
RECALIBRATE COMMAND AND VERIFIES THAT THERE ARE NO ERRORS DURING  
RECALIBRATE.

## DRIVE CLEAR TEST

## PURPOSE:

TO VERIFY THAT ALL APPLICABLE RMO3 MASSBUS ADAPTER ERROR AND  
STATUS CONDITIONS ARE INITIALIZED BY A "DRIVE CLEAR" COMMAND.

## PROCEDURE:

THIS TEST WRITES ONES IN THOSE MASSBUS ADAPTER BITS WHICH  
ARE INITIALIZED BY DRIVE CLEAR , THEN ISSUES THE DRIVE CLEAR  
COMMAND AND VERIFIES THAT EACH BIT IS CLEARED. ADDITIONALLY  
REGISTERS WHICH ARE NOT AFFECTED BY "DRIVE CLEAR" ARE ALSO PRESET  
AND VERIFIED.

## THE FOLLOWING ITEMS ARE PRESET:

- .RMER1, ERROR REGISTER 1 IS SET TO ALL ONES;
- .DMD, DIAGNOSTIC MODE IS SET;
- .RMER2, ERROR REGISTER 3, IS SET TO ALL ONES.

801  
802  
803  
804  
805  
806  
807  
808  
809  
810  
811  
812  
813  
814  
815  
816  
817  
818  
819  
820  
821  
822  
823  
824  
825  
826  
827  
828  
829  
830  
831  
832  
833  
834  
835  
836  
837  
838  
839  
840  
841  
842  
843  
844  
845  
846  
847  
848  
849  
850  
851  
852  
853  
854  
855  
856

FOLLOWING THE DRIVE CLEAR COMMAND, THE FOLLOWING ITEMS ARE CHECKED:

.RMCS1, IS CHECKED FOR DVA=1, FD-F4 AND GO=0, ALL OTHER BITS ARE DONT CARES;

.RMDS, IS CHECKED FOR 0, EXCEPT FOR MOL DPR, DRY, AND VV WHICH SHOULD BE ONE, AND PGM WHICH IS A DONT CARE.

.RMER1, IS CHECKED FOR 0;

.RMAS, IS CHECKED TO INSURE THE APPROPRIATE ATA BIT IS 0;

.RMMR, IS CHECKED FOR 0, EXCEPT FOR WORD CLOCK, LAST SECTOR, AND LAST SECTOR AND TRACK WHICH ARE DONT CARES;

.RMMR2 IS CHECKED FOR 0, EXCEPT FOR THE TEST BIT WHICH IS ONE, AND REQA, REQB WHICH ARE DONT CARES;

.RMEC2 IS CHECKED FOR 0;

.RMER3 IS CHECKED FOR 0;

NOP TEST

PURPOSE:

TO VERIFY THE EXECUTION OF "NOP" COMMAND.

PROCEDURE:

A NOP COMMAND IS EXECUTED ON THE SELECTED DEVICE AND STATUS IS CHECKED TO VERIFY THAT THERE WERE NO ERRORS OR UNEXPECTED CHANGES IN STATUS.

OFFSET TEST

PURPOSE:

TO VERIFY THE EXECUTION OF "OFFSET" COMMAND.

PROCEDURE:

THE OFFSET COMMAND IS EXECUTED AND THE PROGRAM CHECKS THAT OFFSET STATUS, BIT 0 OF RMDS IS SET AND THAT ATTENTION, BIT 15 OF

J02

CZRMCB0 RM03/2 FCTNL TST 1  
CZRMCB.P11 23-NOV-77 12:14

MACY11 30(1046) 23-NOV-77 12:25 PAGE 22

SEQ 0022

857  
858

RMDS IS ALSO SET. ADDITIONALLY, CONTROLLER, ADAPTER, AND DRIVE  
STATUS IS CHECKED FOR UNEXPECTED CHANGES.



859  
860  
861  
862  
863  
864  
865  
866  
867  
868  
869  
870  
871  
872  
873  
874  
875  
876  
877  
878  
879  
880  
881  
882  
883  
884  
885  
886  
887  
888  
889  
890  
891  
892  
893  
894  
895  
896  
897  
898  
899  
900  
901  
902  
903  
904  
905  
906  
907  
908  
909  
910  
911  
912  
913  
914

GO/ATA TEST

PURPOSE:

TO VERIFY THAT "ATA" WILL RESET WITH "GO" PROVIDING  
COMPOSITE ERROR IS INACTIVE.

PROCEDURE:

ATTENTION, BIT 15 OF RMD5, IS SET USING AN OFFSET COMMAND  
AND RESET USING A NOP COMMAND.

WRITE ATA TEST

PURPOSE:

TO VERIFY THAT ATTENTION CAN BE RESET BY WRITING THE  
ATTENTION SUMMARY REGISTER, RMAS.

PROCEDURE:

ATTENTION IS SET USING AN OFFSET COMMAND AFTER WHICH THE  
PROGRAM WRITES A 0 IN THE ATTENTION SUMMARY REGISTER, VERIFYING  
THAT ATTENTION REMAINS SET. FOLLOWING THAT, THE PROGRAM WRITES A  
1 IN RMAS AND VERIFIES THAT ATTENTION RESETS.

ERROR/ATA TEST

PURPOSE:

TO VERIFY THAT "GO" DOES NOT RESET "ATA" WHEN THERE IS A  
COMPOSITE ERROR.

PROCEDURE:

"ATA" IS SET WITH AN OFFSET COMMAND AFTER WHICH ONE OF THE  
ERROR BITS IS SET. THE PROGRAM THEN ISSUES A NOP COMMAND AND  
VERIFIES THAT THE ATTENTION BIT REMAINS SET.

PROGRAM INTERRUPT TEST

CZRMCO RMO3/2 FCTNL TST 1  
CZRMCO.P11 23-NOV-77 12:14

MACY11 30(1046) 23-NOV-77 12:25 PAGE 24

L02

SEQ 0024

915

PURPOSE:

916  
917  
918  
919  
920  
921  
922  
923  
924  
925  
926  
927  
928  
929  
930  
931  
932  
933  
934  
935  
936  
937  
938  
939  
940  
941  
942  
943  
944  
945  
946  
947  
948  
949  
950  
951  
952  
953  
954  
955  
956  
957  
958  
959  
960  
961  
962  
963  
964  
965  
966  
967  
968  
969  
970  
971

TO VERIFY THAT THE RM03 SUBSYSTEM WILL GENERATE A PROGRAM INTERRUPT WHEN PROCESSOR PRIORITY IS LESS THAN CONTROLLER PRIORITY AND INTERRUPT IS ENABLED.

PROCEDURE:

ATTENTION IS SET USING AN OFFSET COMMAND. WITH INTERRUPT ENABLED AND PROCESSOR PRIORITY SET BELOW CONTROLLER PRIORITY, THE PROGRAM VERIFIES THAT A PROGRAM INTERRUPT OCCURS.

INHIBIT INTERRUPT TEST

PURPOSE:

TO VERIFY THAT A PROGRAM INTERRUPT DOES NOT OCCUR WHEN (1) PROCESSOR AND CONTROLLER PRIORITY ARE THE SAME AND INTERRUPT IS ENABLED OR (2) WHEN PROCESSOR PRIORITY IS LESS THAN CONTROLLER AND INTERRUPTS ARE NOT ENABLED.

PROCEDURE:

ATTENTION IS SET USING AN OFFSET COMMAND WITH THE PRIORITY OF THE PROCESSOR SET EQUAL TO THE PRIORITY OF THE CONTROLLER. INTERRUPT IS ENABLED AND THE TEST VERIFIES THAT A PROGRAM INTERRUPT DOES NOT OCCUR. INTERRUPTS ARE DISABLED AND PROCESSOR PRIORITY IS LOWERED AND THE TEST VERIFIES THAT A PROGRAM INTERRUPT DOES NOT OCCUR.

RETURN TO CENTERLINE TEST

PURPOSE:

TO VERIFY THE EXECUTION OF "RETURN TO CENTERLINE" COMMAND.

PROCEDURE:

THIS TEST ISSUES AN RTC COMMAND AND VERIFIES THAT OFFSET STATUS, BIT 0 OF RMDS IS RESET AND THAT ATTENTION, BIT 15 OF RMDS IS SET. UNEXPECTED STATUS OR ERROR CONDITIONS ARE ALSO VERIFIED.

READ IN PRESET TEST

NO2

CZRMCO RM03/2 FCTNL TST 1  
CZRMCB.P11 23-NOV-77 12:14

MACY11 30(1046) 23-NOV-77 12:25 PAGE 26

SEQ 0026

972  
973

PURPOSE:

974  
975  
976  
977  
978  
979  
980  
981  
982  
983  
984  
985  
986  
987  
988  
989  
990  
991  
992  
993  
994  
995  
996  
997  
998  
999  
1000  
1001  
1002  
1003  
1004  
1005  
1006  
1007  
1008  
1009  
1010  
1011  
1012  
1013  
1014  
1015  
1016  
1017  
1018  
1019  
1020  
1021  
1022  
1023  
1024  
1025  
1026  
1027

TO VERIFY THE EXECUTION OF "READ IN PRESET" COMMAND.

PROCEDURE:

THIS TEST LOADS NON ZERO VALUES IN THOSE ADAPTER REGISTERS WHICH ARE INITIALIZED BY THE READ IN PRESET COMMAND, THEN EXECUTES THE COMMAND AND VERIFIES THE CONTENTS OF EACH REGISTER. THE FOLLOWING REGISTERS ARE CHECKED:

.RMDA THE DISK ADDRESS REGISTER, IS LOADED WITH ALL ONES AND VERIFIED TO BE ZERO AFTER THE RIP COMMAND;

.RMDC THE DESIRED CYLINDER REGISTER, IS LOADED WITH ALL ONES (001777) AND VERIFIED TO BE ZERO AFTER THE RIP COMMAND;

.RMOF THE OFFSET REGISTER, IS PRESET (TO 016000) AND VERIFIED TO BE ZERO AFTER THE TEST;

RMDC CLEAR OFFSET TEST

PURPOSE:

TO VERIFY THAT WRITING THE DESIRED CYLINDER REGISTER (RMDC) WILL CLEAR OFFSET MODE.

PROCEDURE:

OFFSET MODE IS SET USING THE OFFSET COMMAND, THEN RESET BY WRITING RMDC.

ILLEGAL FUNCTION TEST

PURPOSE:

TO VERIFY THAT THE RMO3 SUBSYSTEM DETECTS ALL ILLEGAL FUNCTIONS.

PROCEDURE:

EACH ILLEGAL FUNCTION CODE IS EXECUTED WITH THE PROGRAM VERIFYING THAT "ILLEGAL FUNCTION" STATUS, BIT 0 OF RMER1 IS SET FOR EACH CODE. THE SUBSYSTEM IS INITIALIZED PRIOR TO EACH ILLEGAL FUNCTION TEST.

1028  
1029  
1030  
1031  
1032  
1033  
1034  
1035  
1036  
1037  
1038  
1039  
1040  
1041  
1042  
1043  
1044  
1045  
1046  
1047  
1048  
1049  
1050  
1051  
1052  
1053  
1054  
1055  
1056  
1057  
1058  
1059  
1060  
1061  
1062  
1063  
1064  
1065  
1066  
1067  
1068  
1069  
1070  
1071  
1072  
1073  
1074  
1075  
1076  
1077  
1078  
1079  
1080  
1081  
1082  
1083

INVALID COMMAND TEST

PURPOSE:

TO VERIFY IVC ERROR DETECTION.

PROCEDURE:

THE TEST RESETS VOLUME VALID USING MAINTENANCE UNIT READY, THEN EXECUTES A NOP COMMAND AND VERIFIES THAT IVC IS SET. THE PROCESS IS REPEATED FOR EACH FUNCTION CODE, WITH IVC BEING CHECKED ACCORDING TO THE FUNCTION.

INVALID ADDRESS ERROR TEST

PURPOSE:

TO VERIFY IAE ERROR DETECTION.

PROCEDURE:

THE TEST EXECUTES EACH FUNCTION CODE WITH RMDA, AND RMDC SET TO ILLEGAL ADDRESSES, AND VERIFIES IAE ACCORDING TO THE FUNCTION.

WRITE LOCK ERROR TEST

PURPOSE:

TO VERIFY WLE ERROR DETECTION.

PROCEDURE:

THE TEST SIMULATES WRITE PROTECT USING MAINTENANCE WRITE PROTECT AND VERIFIES WLE ACCORDING TO THE FUNCTION BEING EXECUTED. EACH FUNCTION CODE IS TESTED.

OPI TEST

PURPOSE:

TO VERIFY OPI ERROR DETECTION.

CZRMCB0 RM03/2 FCTNL TST 1  
CZRMCB.P11 23-NOV-77 12:14

MACY11 30(1046) 23-NOV-77 12:25 PAGE 29

003

SEQ 0029

1084  
1085

PROCEDURE:

1086  
1087  
1088  
1089  
1090  
1091  
1092  
1093  
1094  
1095  
1096  
1097  
1098  
1099  
1100  
1101  
1102  
1103  
1104  
1105  
1106  
1107  
1108  
1109  
1110  
1111  
1112  
1113  
1114  
1115  
1116  
1117  
1118  
1119  
1120  
1121  
1122  
1123  
1124  
1125  
1126  
1127  
1128  
1129  
1130  
1131  
1132  
1133  
1134  
1135  
1136  
1137  
1138  
1139  
1140  
1141

THE TEST EXECUTES EACH FUNCTION CODE WITH A SIMULATED DRIVE OFF LINE CONDITION AND VERIFIES OPI STATUS ACCORDINGLY.

ERROR ABORT TESTS

PURPOSE:

TO TEST COMMAND EXECUTION DURING AN ABORT CONDITION.

PROCEDURE:

EACH FUNCTION CODE IS EXECUTED UNDER A SIMULATED UNSAFE CONDITION AND THE TEST VERIFIES THAT GO IS RESET.

RMR TEST

PURPOSE:

TO VERIFY THAT RMR ERROR IS DETECTED.

PROCEDURE:

THE TEST EXECUTES A NOP COMMAND WITH DEBUG CLOCK ENABLED. WITH GO SET, THE TEST WRITES RMCSI, VERIFYING THAT RMR ERROR SETS.

PARITY ERROR TEST

PURPOSE:

TO VERIFY THAT PARITY ERRORS ARE DETECTED.

PROCEDURE:

WITH PAT SET TO CAUSE BAD PARITY ON THE CONTROL BUS, THE TEST WRITES A SHIFTING ONE BIT PATTERN TO RMDA AND VERIFIES THAT AN ERROR IS DETECTED BY THE RMO3 FOR EACH PATTERN.



F03

CZRMCD RMD3/2 FCTNL TST 1  
CZRMCD.P11 23-NOV-77 12:14

MACY11 30(1046) 23-NOV-77 12:25 PAGE 31

SEQ 0031

1142  
1143

ILLEGAL REGISTER TEST

1144  
1145  
1146  
1147  
1148  
1149  
1150  
1151  
1152  
1153  
1154  
1155  
1156  
1157  
1158  
1159  
1160  
1161  
1162  
1163  
1164  
1165  
1166  
1167  
1168  
1169  
1170  
1171  
1172  
1173  
1174  
1175  
1176  
1177  
1178  
1179  
1180  
1181  
1182  
1183  
1184  
1185  
1186  
1187  
1188  
1189  
1190  
1191  
1192  
1193  
1194  
1195  
1196  
1197  
1198

PURPOSE:

TO VERIFY THE DETECTION OF ILLEGAL REGISTER ADDRESSES BY THE RMD3 SUBSYSTEM.

PROCEDURE:

EACH REGISTER ADDRESS IS ACCESSED AND ILLEGAL REGISTER STATUS, BIT 1 OF RMR1 IS CHECKED ACCORDING TO THE ADDRESS USED. NOTE THAT THE EXECUTION OF THIS TEST IS DEPENDENT ON THE REGISTER ADDRESS JUMPER IN THE RH70 CONTROLLER BECAUSE THE RANGE OF ADDRESSES WHICH THE CONTROLLER WILL RESPOND TO IS LIMITED BY THE WAY THE JUMPER IS CUT.

SEEK TESTS

PURPOSE:

THE PURPOSE OF EACH OF THE FOLLOWING SEEK TESTS IS TO VERIFY THE EXECUTION OF SEEK OPERATIONS BY THE RMD3 SUBSYSTEM USING A SET OF ADDRESSES THAT TEST THE ADAPTER/DEVICE INTERFACE AND ELECTROMECHANICAL HEAD POSITIONING HARDWARE.

PROCEDURE:

EACH TEST WILL RECALIBRATE THE DRIVE IF "PIP" OR "SKI" IS ACTIVE. FOLLOWING THAT, THE TEST EXECUTES A SEEK TO A CYLINDER ADDRESS OR SERIES OF ADDRESSES. AT THE COMPLETION OF EACH SEEK OPERATION, SUBSYSTEM STATUS IS STORED AND THE TEST CHECKS FOR PRIMARY ERRORS WHICH PRECLUDE FURTHER ERROR CHECKING. IF THERE ARE NO PRIMARY ERRORS THE TEST CHECKS FOR OPERATIONAL ERRORS AND THEN SECONDARY ERRORS.

SEEK TO LAST CYLINDER

THIS TEST SEEKS TO THE LAST CYLINDER, I.E., CYLINDER 822.

SEEK TO FIRST CYLINDER

THIS TEST SEEKS TO THE FIRST CYLINDER, I.E. CYLINDER 0.

1199  
1200  
1201  
1202  
1203  
1204  
1205  
1206  
1207  
1208  
1209  
1210  
1211  
1212  
1213  
1214  
1215  
1216  
1217  
1218  
1219  
1220  
1221  
1222  
1223  
1224  
1225  
1226  
1227  
1228  
1229  
1230  
1231  
1232  
1233  
1234  
1235  
1236  
1237  
1238  
1239  
1240  
1241  
1242  
1243  
1244  
1245  
1246  
1247  
1248  
1249  
1250  
1251

SEEK PRIME CYLINDERS

THIS TEST SEEKS FORWARD TO EACH PRIME CYLINDER ADDRESS,  
I.E., CYLINDERS 1,2,4,8,....,512.

SEEK ZERO DIFFERENCE

THIS TEST EXECUTES SUCCESSIVE SEEKS TO CYLINDER 0.

SEEK MAXIMUM DIFFERENCE FORWARD

THIS TEST SEEKS TO CYLINDER 0 FOLLOWED BY A SEEK TO THE LAST  
CYLINDER.

SEEK ADJACENT FORWARD

THIS TEST SEEKS TO CYLINDER 0, FOLLOWED BY A SEEK TO THE  
ADJACENT FORWARD CYLINDER, I.E., CYLINDER 1.

SEEK ADJACENT REVERSE

THIS TEST SEEKS TO CYLINDER 1, FOLLOWED BY A SEEK TO THE ADJACENT  
REVERSE CYLINDER, I.E., CYLINDER 0.

SEEK TO INVALID SECTOR

WITH THE OFFSET REGISTER SET FOR 18 BIT FORMAT, THE PROGRAM  
SEEKS TO CYLINDER 0, TRACK 0, FOR EACH INVALID SECTOR ADDRESS AND  
VERIFIES THAT INVALID ADDRESS ERROR SETS FOR EACH SECTOR.

1252  
1253  
1254  
1255  
1256  
1257  
1258  
1259  
1260  
1261  
1262  
1263  
1264  
1265  
1266  
1267  
1268  
1269  
1270  
1271  
1272  
1273  
1274  
1275  
1276  
1277  
1278  
1279  
1280  
1281  
1282  
1283  
1284  
1285  
1286  
1287  
1288  
1289  
1290  
1291  
1292  
1293  
1294  
1295  
1296  
1297  
1298  
1299  
1300  
1301  
1302  
1303  
1304  
1305  
1306  
1307

SEEK TO INVALID TRACK

THE TEST SEEKS TO EACH INVALID TRACK ADDRESS WITH CYLINDER AND SECTOR ADDRESS SET TO 0 AND VERIFIES THAT INVALID ADDRESS ERROR SETS FOR EACH TRACK ADDRESS.

SEEK TO INVALID CYLINDER

THE PROGRAM SEEKS TO EACH INVALID CYLINDER ADDRESS WITH THE SECTOR AND TRACK ADDRESS SET TO 0 AND VERIFIES THAT INVALID ADDRESS ERROR SETS FOR EACH CYLINDER ADDRESS.

IVC SEEK TEST

PURPOSE:

TO VERIFY THAT INVALID COMMAND STATUS, BIT 12 OF RMER2 SETS WHEN VOLUME VALID IS INACTIVE DURING A SEEK COMMAND.

PROCEDURE:

THE TEST RESETS VOLUME VALID BY SETTING AND RESETTING DIAGNOSTIC MODE, THEN EXECUTES A SEEK COMMAND AND VERIFIES THAT "IVC" STATUS IS SET.

ABORT SEEK TEST

PURPOSE:

TO VERIFY THAT THE RMO3 INHIBITS A SEEK WHEN AN ABORT CONDITION EXISTS AT THE START OF THE COMMAND.

PROCEDURE:

THE TEST SETS AN ERROR IN THE ERROR REGISTER AND ISSUES A SEEK COMMAND, VERIFYING THAT "PIP" REMAINS INACTIVE.

CZRMCD RMO3/2 FCTNL TST 1  
CZRMCD.P11 23-NOV-77 12:14

MACY11 30(1046) 23-NOV-77 12:25 PAGE 35

J03

SEQ 0035

1308

SEEK AT OFFSET

1309  
1310  
1311  
1312  
1313  
1314  
1315  
1316  
1317  
1318  
1319  
1320  
1321  
1322  
1323  
1324  
1325  
1326  
1327  
1328  
1329  
1330  
1331  
1332  
1333  
1334  
1335  
1336  
1337  
1338  
1339  
1340  
1341  
1342  
1343  
1344  
1345  
1346  
1347  
1348  
1349  
1350  
1351  
1352  
1353  
1354  
1355  
1356  
1357  
1358  
1359  
1360  
1361  
1362  
1363  
1364

PURPOSE:

TO VERIFY THAT OFFSET MODE DOES NOT CAUSE ERRORS DURING SEEK.

PROCEDURE:

THE TEST EXECUTES AN OFFSET COMMAND THEN EXECUTES A SEEK COMMAND, VERIFYING THE RESULTS OF THE SEEK.

LOOK AHEAD TEST

PURPOSE:

TO INSURE THAT THE SECTOR COUNT WHICH ORIGINATES AT THE DRIVE AND IS VISIBLE THROUGH THE LOOK AHEAD REGISTER (RMLA) IS OPERATIONAL.

PROCEDURE:

WITH THE OFFSET REGISTER SET FOR 16 BIT FORMAT, THE PROGRAM SAMPLES THE LOOK AHEAD REGISTER AND COLLECTS EACH DIFFERENT SAMPLE UNTIL THE VALUE OF THE FIRST SAMPLE IS DETECTED OR UNTIL 33 SAMPLES ARE TAKEN. THE COLLECTION IS THEN TESTED TO DETERMINE THAT THE SECTOR COUNT INCREMENTS CORRECTLY THROUGH THE ENTIRE RANGE OF VALID SECTORS. THE SAME PROCEDURE IS REPEATED FOR 18 BIT FORMAT, WHERE THE LIMIT ON THE NUMBER OF SAMPLES IS 31.

SEARCH EACH SECTOR ON CYLINDER

PURPOSE:

TO VERIFY THE EXECUTION OF SEARCH OPERATIONS WITH NO HEAD MOTION USING THE SECTOR PULSE FOR SECTOR COMPARE.

PROCEDURE:

THE TEST INTIALIZES AND RECALIBRATES THE DRIVE IF "PIP" OR "SKI" IS ACTIVE THEN SEEKS TO CYLINDER 0. THE TEST THEN DOES A SEARCH TO EACH SECTOR AND VERIFIES THAT THE SEARCH COMPLETES WITHOUT ERROR. THIS TEST IS DONE ONCE IN 18 BIT FORMAT AND ONCE

CZRMCB0 RMD3/2 FCTNL TST 1  
CZRMCB.P11 23-NOV-77 12:14

MACY11 30(1046) 23-NOV-77 12:25 PAGE 37

L03

SEQ 0037

1365

IN 16 BOT FORMAT.

1366  
1367  
1368  
1369  
1370  
1371  
1372  
1373  
1374  
1375  
1376  
1377  
1378  
1379  
1380  
1381  
1382  
1383  
1384  
1385  
1386  
1387  
1388  
1389  
1390  
1391  
1392  
1393  
1394  
1395  
1396  
1397  
1398  
1399  
1400  
1401  
1402  
1403  
1404  
1405  
1406  
1407  
1408  
1409  
1410  
1411  
1412  
1413  
1414  
1415  
1416  
1417  
1418  
1419

SEARCH OFF CYLINDER

PURPOSE:

TO VERIFY THE EXECUTION OF A SEARCH COMMAND WITH IMPLIED HEAD MOTION.

PROCEDURE:

THE DRIVE IS RECALIBRATED AND INITIALIZED IF THE DRIVE IS OFF CYLINDER OR HAS A SEEK ERROR. THE PROGRAM THEN EXECUTES AN EXPLICIT SEEK TO CYLINDER 0, FOLLOWED BY A SEARCH TO CYLINDER 822, TRACK 0, SECTOR 0.

SEARCH INVALID SECTOR

PURPOSE:

TO VERIFY THE DETECTION OF AN INVALID SECTOR ADDRESS DURING A SEARCH OPERATION.

PROCEDURE:

THE DRIVE IS RECALIBRATED AND INITIALIZED IF IT IS OFF CYLINDER OR HAS A SEEK ERROR. WITH THE OFFSET REGISTER SET FOR 18 BIT FORMAT, THE PROGRAM EXECUTES A SEARCH TO EACH INVALID SECTOR, I.E., SECTORS 30 AND 31 AND VERIFIES THAT INVALID ADDRESS ERROR SETS FOR EACH SECTOR.

SEARCH INVALID TRACK

PURPOSE:

TO VERIFY THE DETECTION OF AN INVALID TRACK ADDRESS DURING A SEARCH OPERATION.

PROCEDURE:

THE DRIVE IS RECALIBRATED AND INITIALIZED IF IT IS OFF CYLINDER OR HAS A SEEK ERROR. THE PROGRAM EXECUTES A SEARCH TO EACH INVALID TRACK ADDRESS WITH THE CYLINDER ADDRESS 0, AND SECTOR ADDRESS 0 AND VERIFIES THAT INVALID ADDRESS ERROR SETS FOR EACH TRACK.



1420  
1421  
1422  
1423  
1424  
1425  
1426  
1427  
1428  
1429  
1430  
1431  
1432  
1433  
1434  
1435  
1436  
1437  
1438  
1439  
1440  
1441  
1442  
1443  
1444  
1445  
1446  
1447  
1448  
1449  
1450  
1451  
1452  
1453  
1454  
1455  
1456  
1457  
1458  
1459  
1460  
1461  
1462  
1463  
1464  
1465  
1466  
1467  
1468  
1469  
1470  
1471  
1472  
1473  
1474  
1475

SEARCH INVALID CYLINDER

PURPOSE:

TO VERIFY THE DETECTION OF AN INVALID CYLINDER ADDRESS DURING A SEARCH OPERATION.

PROCEDURE:

THE DRIVE IS RECALIBRATED AND INITIALIZED IF IT IS OFF CYLINDER OR HAS A SEEK ERROR. THE PROGRAM THEN EXECUTES A SEARCH TO EACH INVALID CYLINDER ADDRESS AND VERIFIES THAT INVALID ADDRESS ERROR SETS FOR EACH CYLINDER.

IVC SEARCH TEST

PURPOSE:

TO VERIFY THAT INVALID COMMAND STATUS SETS WHEN VOLUME VALID IS INACTIVE DURING A SEARCH COMMAND.

PROCEDURE:

VOLUME VALID IS RESET BY SETTING AND RESETTING DIAGNOSTIC MODE, AFTER WHICH THE TEST EXECUTES A SEARCH COMMAND, VERIFYING THAT "IVC" STATUS SETS.

ABORT SEARCH TEST

PURPOSE:

TO VERIFY THAT THE RMO3 INHIBITS A SEARCH WHEN AN ABORT CONDITION EXISTS AT THE START OF THE COMMAND.

PROCEDURE:

THE TEST SETS AN ERROR IN THE ERROR REGISTER AND ISSUES A SEARCH COMMAND, VERIFYING THAT "PIP" REMAINS INACTIVE.

SEARCH AT OFFSET

CZRMCB0 RMO3/2 FCTNL TST 1  
CZRMCB.P11 23-NOV-77 12:14

MACY11 30(1046) 23-NOV-77 12:25 PAGE 40

804

SEQ 0040

1476

PURPOSE:

1477  
1478  
1479  
1480  
1481  
1482  
1483  
1484  
1485  
1486  
1487  
1488  
1489  
1490  
1491  
1492

TO VERIFY THAT OFFSET MODE DOES NOT CAUSE SEARCH ERRORS.

PROCEDURE:

THE TEST EXECUTES AN OFFSET COMMAND, THEN EXECUTES A SEARCH  
COMMAND, VERIFYING THAT THERE ARE NO ERRORS DURING THE SEARCH.

1493  
1494  
1495  
1496  
1497  
1498  
1499  
1500  
1501  
1502  
1503  
1504  
1505  
1506  
1507  
1508  
1509  
1510  
1511  
1512  
1513  
1514  
1515  
1516  
1517  
1518  
1519  
1520  
1521  
1522  
1523  
1524  
1525  
1526  
1527  
1528  
1529  
1530  
1531  
1532  
1533  
1534  
1535  
1536  
1537  
1538  
1539  
1540  
1541  
1542  
1543  
1544  
1545  
1546  
1547  
1548

000001

001100

000011  
000012  
000015  
000200  
177776

177774  
177772  
177570  
177570

000000  
000001  
000002

```
;PROGRAM REVISION #001
.TITLE CZRMCB0 RMO3/2 FCTNL TST 1
;#COPYRIGHT (C) 1977
;#DIGITAL EQUIPMENT CORP.
;#MAYNARD, MASS. 01754
;*
;*PROGRAM BY DOUG RIIKONEN
;*
;*THIS PROGRAM WAS ASSEMBLED USING THE PDP-11 MAINDEC SYSMAC
;*PACKAGE (MAINDEC-11-DZQAC-C3), JAN 19, 1977.
;*
$TN=1
.SBTTL OPERATIONAL SWITCH SETTINGS
;*
;*      SWITCH          USE
;*      -----          -----
;*      15             HALT ON ERROR
;*      14             LOOP ON TEST
;*      13             INHIBIT ERROR TYPEOUTS
;*      12             ENABLE EXTENDED STATUS
;*      11             INHIBIT ITERATIONS
;*      10             BELL ON ERROR
;*      9              LOOP ON ERROR
;*      8              LOOP ON TEST IN SWR<7:0>
;*      7              TN128
;*      6              TN64
;*      5              TN32
;*      4              TN16
;*      3              TN8
;*      2              TN4
;*      1              TN2
;*      0              TN1
.SBTTL BASIC DEFINITIONS
;*INITIAL ADDRESS OF THE STACK POINTER *** 1100 ***
STACK= 1100
.EQUIV EMT,ERROR      ;;BASIC DEFINITION OF ERROR CALL
.EQUIV IOT,SCOPE      ;;BASIC DEFINITION OF SCOPE CALL
;*MISCELLANEOUS DEFINITIONS
MT= 11                ;;CODE FOR HORIZONTAL TAB
LF= 12                ;;CODE FOR LINE FEED
CR= 15                ;;CODE FOR CARRIAGE RETURN
CRLF= 200             ;;CODE FOR CARRIAGE RETURN-LINE FEED
PS= 177776           ;;PROCESSOR STATUS WORD
.EQUIV PS,PSW
$TKLMT= 177774        ;;STACK LIMIT REGISTER
PIRQ= 177772          ;;PROGRAM INTERRUPT REQUEST REGISTER
DSWR= 177570          ;;HARDWARE SWITCH REGISTER
DDISP= 177570         ;;HARDWARE DISPLAY REGISTER
;*GENERAL PURPOSE REGISTER DEFINITIONS
R0= %0                ;;GENERAL REGISTER
R1= %1                ;;GENERAL REGISTER
R2= %2                ;;GENERAL REGISTER
```

1549	000003	R3=	%3	::	GENERAL REGISTER
1550	000004	R4=	%4	::	GENERAL REGISTER
1551	000005	R5=	%5	::	GENERAL REGISTER
1552	000006	R6=	%6	::	GENERAL REGISTER
1553	000007	R7=	%7	::	GENERAL REGISTER
1554	000006	SP=	%6	::	STACK POINTER
1555	000007	PC=	%7	::	PROGRAM COUNTER

1556  
1557  
1558  
1559  
1560  
1561  
1562  
1563  
1564  
1565  
1566

```

:*PRIORITY LEVEL DEFINITIONS
PRO= 0          :: PRIORITY LEVEL 0
PR1= 40        :: PRIORITY LEVEL 1
PR2= 100       :: PRIORITY LEVEL 2
PR3= 140       :: PRIORITY LEVEL 3
PR4= 200       :: PRIORITY LEVEL 4
PR5= 240       :: PRIORITY LEVEL 5
PR6= 300       :: PRIORITY LEVEL 6
PR7= 340       :: PRIORITY LEVEL 7

```

1567  
1568  
1569  
1570  
1571  
1572  
1573  
1574  
1575  
1576  
1577  
1578  
1579  
1580  
1581  
1582  
1583  
1584  
1585  
1586  
1587  
1588  
1589  
1590  
1591  
1592  
1593  
1594

```

:*"SWITCH REGISTER" SWITCH DEFINITIONS
SW15= 100000
SW14= 40000
SW13= 20000
SW12= 10000
SW11= 4000
SW10= 2000
SW09= 1000
SW08= 400
SW07= 200
SW06= 100
SW05= 40
SW04= 20
SW03= 10
SW02= 4
SW01= 2
SW00= 1
.EQUIV SW09,SW9
.EQUIV SW08,SW8
.EQUIV SW07,SW7
.EQUIV SW06,SW6
.EQUIV SW05,SW5
.EQUIV SW04,SW4
.EQUIV SW03,SW3
.EQUIV SW02,SW2
.EQUIV SW01,SW1
.EQUIV SW00,SW0

```

1595  
1596  
1597  
1598  
1599  
1600  
1601  
1602  
1603  
1604

```

:*DATA BIT DEFINITIONS (BIT00 TO BIT15)
BIT15= 100000
BIT14= 40000
BIT13= 20000
BIT12= 10000
BIT11= 4000
BIT10= 2000
BIT09= 1000
BIT08= 400
BIT07= 200

```

```

1605      000100      BIT06= 100
1606      000040      BIT05= 40
1607      000020      BIT04= 20
1608      000010      BIT03= 10
1609      000004      BIT02= 4
1610      000002      BIT01= 2
1611      000001      BIT00= 1
1612      .EQUIV      BIT09,BIT9
1613      .EQUIV      BIT08,BIT8
1614      .EQUIV      BIT07,BIT7
1615      .EQUIV      BIT06,BIT6
1616      .EQUIV      BIT05,BIT5
1617      .EQUIV      BIT04,BIT4
1618      .EQUIV      BIT03,BIT3
1619      .EQUIV      BIT02,BIT2
1620      .EQUIV      BIT01,BIT1
1621      .EQUIV      BIT00,BIT0
1622
1623      ;*BASIC "CPU" TRAP VECTOR ADDRESSES
1624      000004      ERRVEC= 4          ;; TIME OUT AND OTHER ERRORS
1625      000010      RESVEC= 10         ;; RESERVED AND ILLEGAL INSTRUCTIONS
1626      000014      TBITVEC=14        ;; "T" BIT
1627      000014      TRTVEC= 14         ;; TRACE TRAP
1628      000014      BPTVEC= 14         ;; BREAKPOINT TRAP (BPT)
1629      000020      IOTVEC= 20         ;; INPUT/OUTPUT TRAP (IOT) **SCOPE**
1630      000024      PWRVEC= 24         ;; POWER FAIL
1631      000030      EMTVEC= 30         ;; EMULATOR TRAP (EMT) **ERROR**
1632      000034      TRAPVEC=34        ;; "TRAP" TRAP
1633      000060      TKVEC= 60          ;; TTY KEYBOARD VECTOR
1634      000064      TPVEC= 64          ;; TTY PRINTER VECTOR
1635      000240      PIRQVEC=240        ;; PROGRAM INTERRUPT REQUEST VECTOR
1636
1637      .SBTTL      RMO3 REGISTER BIT DEFINITIONS
1638
1639      ;RMCS1      CONTROL STATUS REGISTER
1640
1641      004000      DVA      =          BIT11      ;DEVICE AVAILABLE-READ ONLY
1642      000040      F4      =          BIT05      ;FUNCTION CODE
1643      000020      F3      =          BIT04      ;FUNCTION CODE
1644      000010      F2      =          BIT03      ;FUNCTION CODE
1645      000004      F1      =          BIT02      ;FUNCTION CODE
1646      000002      F0      =          BIT01      ;FUNCTION CODE
1647      000001      GO      =          BIT00      ;GO BIT
1648      000077      FNCMSK  =          000077    ;FUNCTION CODE MASK
1649
1650      ;FUNCTION CODES (BITS 01-05 OF RMCS1)
1651
1652      000000      NOP      =          000000    ;NOP COMMAND
1653      000002      ILF02   =          000002    ;ILLEGAL COMMAND
1654      000004      SEEK    =          000004    ;SEEK COMMAND
1655      000006      RECAL   =          000006    ;RECALIBRATE COMMAND
1656      000010      DRVCLR  =          000010    ;DRIVE CLEAR COMMAND
1657      000012      RLEASE  =          000012    ;RELEASE COMMAND
1658      000014      OFFSET  =          000014    ;OFFSET COMMAND
1659      000016      RTC     =          000016    ;RETURN TO CENTERLINE COMMAND
1660      000020      RIP     =          000020    ;READ IN PRESET COMMAND

```

1661	000022	PAKACK	=	000022	;PACK ACKNOWLEDGE COMMAND
1662	000022	PACACK	=	PAKACK	
1663	000024	ILF24	=	000024	; ILLEGAL COMMAND
1664	000026	ILF26	=	000026	; ILLEGAL COMMAND
1665	000030	SEARCH	=	000030	;SEARCH COMMAND
1666	000030	ILF30	=	000030	; ILLEGAL COMMAND
1667	000032	ILF32	=	000032	; ILLEGAL COMMAND
1668	000034	ILF34	=	000034	; ILLEGAL COMMAND
1669	000036	ILF36	=	000036	; ILLEGAL COMMAND
1670	000040	ILF40	=	000040	; ILLEGAL COMMAND
1671	000042	ILF42	=	000042	; ILLEGAL COMMAND
1672	000044	ILF44	=	000044	; ILLEGAL COMMAND
1673	000046	ILF46	=	000046	; ILLEGAL COMMAND
1674	000050	WCD	=	000050	;WRITE CHECK DATA COMMAND
1675	000052	WCH	=	000052	;WRITE CHECK HEADER AND DATA
1676	000054	ILF54	=	000054	; ILLEGAL COMMAND
1677	000056	ILF56	=	000056	; ILLEGAL COMMAND
1678	000060	WD	=	000060	;WRITE DATA COMMAND
1679	000062	WH	=	000062	;WRITE HEADER AND DATA COMMAND
1680	000064	ILF64	=	000064	; ILLEGAL COMMAND
1681	000066	ILF66	=	000066	; ILLEGAL COMMAND
1682	000070	RD	=	000070	;READ DATA COMMAND
1683	000072	RH	=	000072	;READ HEADER AND DATA COMMAND
1684	000074	ILF74	=	000074	; ILLEGAL COMMAND
1685	000076	ILF76	=	000076	; ILLEGAL COMMAND
1686					
1687					
1688					
1689	002000	TA4	=	BIT10	; TRACK ADDRESS 4
1690	001000	TA2	=	BIT09	; TRACK ADDRESS 2
1691	000400	TA1	=	BIT08	; TRACK ADDRESS 1
1692	000020	SA16	=	BIT04	; SECTOR ADDRESS 16
1693	000010	SAB	=	BIT03	; SECTOR ADDRESS 8
1694	000004	SA4	=	BIT02	; SECTOR ADDRESS 4
1695	000002	SA2	=	BIT01	; SECTOR ADDRESS 2
1696	000001	SA1	=	BIT00	; SECTOR ADDRESS 1
1697					
1698					
1699					
1700	003400	TADMSK	=	003400	; TRACK ADDRESS MASK
1701	000037	SADMSK	=	000037	; SECTOR ADDRESS MASK
1702					
1703					
1704					
1705	100000	ATA	=	BIT15	; ATTENTION ACTIVE
1706	040000	ERR	=	BIT14	; COMPOSITE ERROR
1707	020000	PIP	=	BIT13	; POSITIONING IN PROGRESS
1708	010000	MOL	=	BIT12	; MEDIUM ON LINE
1709	004000	WRL	=	BIT11	; WRITE LOCK
1710	002000	LBT	=	BIT10	; LAST BLOCK TRANSFERRED
1711	001000	PGM	=	BIT09	; PROGRAMMABLE
1712	000400	DPR	=	BIT08	; DRIVE PRESENT
1713	000200	DRY	=	BIT07	; DRIVE READY
1714	000100	VV	=	BIT06	; VOLUME VALID
1715	000001	OM	=	BIT00	; OFFSET MODE ACTIVE
1716					

```

1717 ;RMR1 ERROR REGISTER #1
1718
1719 100000 DCK = BIT15 ;DATA CHECK ERROR
1720 040000 UNS = BIT14 ;DRIVE UNSAFE
1721 020000 OPI = BIT13 ;OPERATION INCOMPLETE
1722 010000 DTE = BIT12 ;DRIVE TIMING ERROR
1723 004000 WLE = BIT11 ;WRITE LOCK ERROR
1724 002000 IAE = BIT10 ;INVALID ADDRESS ERROR
1725 001000 AOE = BIT09 ;ADDRESS OVERFLOW ERROR
1726 000400 HCRC = BIT08 ;HEADER CRC ERROR
1727 000200 HCE = BIT07 ;HEADER COMPARE ERROR
1728 000100 ECH = BIT06 ;ECC "HARD" ERROR
1729 000040 WCF = BIT05 ;WRITE CLOCK FAILURE
1730 000020 FER = BIT04 ;FORMAT ERROR
1731 000010 PAR = BIT03 ;PARITY ERROR
1732 000004 RMR = BIT02 ;REGISTER MODIFICATION REFUSED
1733 000002 ILR = BIT01 ;ILLEGAL REGISTER
1734 000001 ILF = BIT00 ;ILLEGAL FUNCTION
1735
1736 115760 NDTMSK = DCK!DTE!WLE!AOE!HCRC!HCE!ECH!WCF!FER
1737 ;"NDTMSK" IS USED TO MASK ERROR REGISTER 1 DURING NON - DATA
1738 ;COMMANDS, I.E., HOUSEKEEPING AND POSITIONING COMMANDS
1739
1740 ;RMS ATTENTION SUMMARY REGISTER
1741
1742 000377 ATNMSK = 377 ;MASK FOR ATTENTION BITS
1743
1744 ;RMLA LOOK AHEAD REGISTER
1745
1746 002000 SC4 = BIT10 ;SECTOR COUNT = 16
1747 001000 SC3 = BIT09 ;SECTOR COUNT = 8
1748 000400 SC2 = BIT08 ;SECTOR COUNT = 4
1749 000200 SC1 = BIT07 ;SECTOR COUNT = 2
1750 000100 SC0 = BIT06 ;SECTOR COUNT = 1
1751
1752 003700 SCTMSK = 003700 ;SECTOR COUNT MASK
1753
1754 ;RMMR MAINTENANCE REGISTER
1755
1756 ; WRITE ONLY BITS
1757
1758 100000 DBCK = BIT15 ;DEBUG CLOCK
1759 040000 DBEN = BIT14 ;DEBUG CLOCK ENABLE
1760 020000 DEBL = BIT13 ;DIAGNOSTIC END OF BLOCK
1761 010000 DTO = BIT12 ;DIAGNOSTIC TIMEOUT
1762 004000 MCLK = BIT11 ;MAINTENANCE CLOCK
1763 002000 MRD = BIT10 ;READ DATA
1764 001000 MUR = BIT09 ;UNIT READY
1765 000400 MOC = BIT08 ;ON CYLINDER
1766 000200 MSER = BIT07 ;SEEK ERROR
1767 000100 MDF = BIT06 ;DRIVE FAULT
1768 000040 MS = BIT05 ;SECTOR PULSE
1769 000010 MWP = BIT03 ;WRITE PROTECT
1770 000004 MI = BIT02 ;INDEX PULSE
1771 000002 MSC = BIT01 ;SECTOR COMPARE
1772 000001 DMD = BIT00 ;DIAGNOSTIC MODE

```



```

1773
1774
1775
1776      100000      OCC      =      BIT15      ;OCCUPIED
1777      040000      RG      =      BIT14      ;RUN AND GO
1778      020000      EBL      =      BIT13      ;END OF BLOCK
1779      010000      REX      =      BIT12      ;EXCEPTION
1780      004000      ESRC     =      BIT11      ;ENABLE SEARCH
1781      002000      PLFS     =      BIT10      ;LOOKING FOR SYNC
1782      001000      ECRC     =      BIT09      ;ENABLE CRC OUT
1783      000400      PDA      =      BIT08      ;DATA AREA
1784      000200      PHA      =      BIT07      ;HEADER AREA
1785      000100      CONT     =      BIT06      ;CONTINUE
1786      000040      WC       =      BIT05      ;WORD CLOCK
1787      000020      EECC     =      BIT04      ;ENABLE ECC OUT
1788      000010      MWD      =      BIT03      ;WRITE DATA BIT
1789      000004      LS       =      BIT02      ;LAST SECTOR
1790      000002      LST      =      BIT01      ;LAST SECTOR AND TRACK
1791      000001      DMD      =      BIT00      ;DIAGNOSTIC MODE
1792
1793      ;RMDT  DRIVE TYPE REGISTER
1794
1795      100000      NSA      =      BIT15      ;NOT SECTOR ADDRESSED=0
1796      040000      TAP      =      BIT14      ;TAPE DRIVE = 0
1797      020000      MOH      =      BIT13      ;MOVING HEAD = 1
1798      004000      DRQ      =      BIT11      ;DRIVE REQUEST REQUIRED
1799
1800      020024      SNGPRT   =      020024      ;SINGLE PORT DRIVE TYPE
1801      024024      DULPRT   =      024024      ;DUAL PORT DRIVE TYPE
1802
1803      ;RMOF  OFFSET REGISTER
1804
1805      010000      FMT16    =      BIT12      ;16 BIT WORD FORMAT
1806      004000      ECI      =      BIT11      ;ECC INHIBIT
1807      002000      HCI      =      BIT10      ;HEADER COMPARE INHIBIT
1808      000200      OFD      =      BIT07      ;OFFSET FORWARD
1809
1810
1811      ;RMDC  DESIRED CYLINDER ADDRESS REGISTER
1812      001777      CYLSK    =      1777      ;MASK FOR CYLINDER ADDRESS
1813
1814      ;RMMR2 MAINTENANCE REGISTER #2
1815
1816      ;      READ ONLY BITS
1817      100000      RQA      =      BIT15      ;PORT A REQUEST
1818      040000      RQB      =      BIT14      ;PORT B REQUEST
1819      020000      TAG      =      BIT13      ;TAG CONTROL
1820      010000      TST      =      BIT12      ;COMMAND SEQUENCE TEST BIT
1821      004000      CC       =      BIT11      ;CONTROL OR CYLINDER TAG
1822      002000      CH       =      BIT10      ;CONTROL OR HEAD TAG
1823      001000      BB09     =      BIT09      ;TAG BUS
1824      000400      BB08     =      BIT08      ;TAG BUS
1825      000200      BB07     =      BIT07      ;TAG BUS
1826      000100      BB06     =      BIT06      ;TAG BUS
1827      000040      BB05     =      BIT05      ;TAG BUS
1828      000020      BB04     =      BIT04      ;TAG BUS

```

1829	000010	BB03	=	BIT03	;TAG BUS
1830	000004	BB02	=	BIT02	;TAG BUS
1831	000002	BB01	=	BIT01	;TAG BUS
1832	000001	BB00	=	BIT00	;TAG BUS
1833					
1834					
1835		;RMR2 ERROR REGISTER 2			
1836					
1837	100000	BSE	=	BIT15	;BAD SECTOR ERROR
1838	040000	SKI	=	BIT14	;SEEK INCOMPLETE
1839	020000	OPE	=	BIT13	;OPERATOR PLUG ERROR
1840	010000	IVC	=	BIT12	;INVALID COMMAND ERROR
1841	004000	LSC	=	BIT11	;LOSS OF SYSTEM CLOCK
1842	002000	LBC	=	BIT10	;LOSS OF BIT CLOCK
1843	000200	DVC	=	BIT07	;DEVICE CHECK
1844	000010	DPE	=	BIT03	;DATA PARITY ERROR
1845					
1846		.SBTTL PROGRAM MNEMONICS			
1847					
1848	100000	MSE	=	BIT15	;MANUFACTURING DETECTED SECTOR ERROR
1849	040000	USE	=	BIT14	;USER DETECTED SECTOR ERROR
1850					
1851		.SBTTL RM03 REGISTER INDEX VALUES			
1852					
1853	000000	RMCS1	=	00	;CONTROL STATUS REGISTER
1854	000006	RMDA	=	06	;DISK ADDRESS REGISTER
1855	000012	RMDS	=	12	;DRIVE STATUS REGISTER
1856	000014	RMR1	=	14	;ERROR REGISTER 1
1857	000016	RMAS	=	16	;ATTENTION SUMMARY REGISTER
1858	000020	RMLA	=	20	;LOOK AHEAD REGISTER
1859	000024	RMMR1	=	24	;MAINTENANCE REGISTER
1860	000026	RMDT	=	26	;DRIVE TYPE REGISTER
1861	000030	RMSN	=	30	;SERIAL NUMBER REGISTER
1862	000032	RMOF	=	32	;OFFSET REGISTER
1863	000034	RMDC	=	34	;DESIRED CYLINDER REGISTER
1864	000036	RMCC	=	36	;CURRENT CYLINDER REGISTER
1865	000040	RMMR2	=	40	;MAINTENANCE REGISTER 2
1866	000042	RMR2	=	42	;ERROR REGISTER 2
1867	000044	RMEC1	=	44	;ECC POSITION REGISTER
1868	000046	RMEC2	=	46	;ECC PATTERN REGISTER
1869	000050	ILRG50	=	50	;ILLEGAL REGISTER 50
1870	000052	ILRG52	=	52	;ILLEGAL REGISTER 52
1871	000054	ILRG54	=	54	;ILLEGAL REGISTER 54
1872	000056	ILRG56	=	56	;ILLEGAL REGISTER 56
1873	000060	ILRG60	=	60	;ILLEGAL REGISTER 60
1874	000062	ILRG62	=	62	;ILLEGAL REGISTER 62
1875	000064	ILRG64	=	64	;ILLEGAL REGISTER 64
1876	000066	ILRG66	=	66	;ILLEGAL REGISTER 66
1877	000070	ILRG70	=	70	;ILLEGAL REGISTER 70
1878	000072	ILRG72	=	72	;ILLEGAL REGISTER 72
1879	000074	ILRG74	=	74	;ILLEGAL REGISTER 74
1880	000076	ILRG76	=	76	;ILLEGAL REGISTER 76
1881					
1882					
1883	000077	IDXMSK	=	77	;MASK FOR REGISTER INDEX NUMBER
1884					

```

1885 .SBTTL RH CONTROLLER REGISTER BIT DEFINITIONS
1886
1887 ;RMCS1 CONTROL STATUS REGISTER #1
1888
1889 100000 SC = BIT15 ;SPECIAL CONDITION-READ ONLY
1890 040000 TRE = BIT14 ;TRANSFER ERROR
1891 020000 MCPE = BIT13 ;MASSBUS CONTROL BUS PARITY
1892 ;ERROR-READ ONLY
1893 002000 PSEL = BIT10 ;PORT B SELECT
1894 001000 A17 = BIT09 ;ADDRESS EXTENSION
1895 000400 A16 = BIT08 ;ADDRESS EXTENSION
1896 000200 RDY = BIT07 ;READY-READ ONLY
1897 000100 IE = BIT06 ;INTERRUPT ENABLE
1898
1899 ;RMCS2 RH CONTROL STATUS REGISTER #2
1900
1901 100000 DLT = BIT15 ;DATA LATE-READ ONLY
1902 040000 WCE = BIT14 ;WRITE CHECK ERROR-READ ONLY
1903 020000 UPE = BIT13 ;UNIBUS PARITY ERROR
1904 010000 NED = BIT12 ;NONEXISTANT DRIVE-READ ONLY
1905 004000 NEM = BIT11 ;NONEXISTANT MEMORY-READ ONLY
1906 002000 PGE = BIT10 ;PROGRAM ERROR-READ ONLY
1907 001000 MXF = BIT09 ;MISSED TRANSFER
1908 000400 MDPE = BIT08 ;MASSBUS DATA BUS PARITY
1909 ;ERROR-READ ONLY
1910 000200 OR = BIT07 ;OUTPUT READY-READ ONLY
1911 000100 IR = BIT06 ;INPUT READY-READ ONLY
1912 000040 CLR = BIT05 ;CONTROLLER CLEAR
1913 000020 PAT = BIT04 ;PARITY TEST
1914 000010 BAI = BIT03 ;UNIBUS ADDRESS INCREMENT
1915 ;INHIBIT
1916 000004 U2 = BIT02 ;UNIT SELECT
1917 000002 U1 = BIT01 ;UNIT SELECT
1918 000001 U0 = BIT00 ;UNIT SELECT
1919
1920 ;UNIT SELECT MASK
1921 000007 UNTMSK = 7 ;UNIT SELECT MASK
1922
1923 ;RMCS3 RH70 CONTROL STATUS REGISTER #3
1924 100000 APE = BIT15 ;ADDRESS PARITY ERROR
1925 040000 DPEHI = BIT14 ;DATA PARITY ERROR HIGH WORD
1926 020000 DPELO = BIT13 ;DATA PARITY ERROR LOW WORD
1927 010000 WCEHI = BIT12 ;WRITE CHECK ERROR HIGH WORD
1928 004000 WCELO = BIT11 ;WRITE CHECK ERROR LOW WORD
1929 002000 DBL = BIT10 ;DOUBLE WORD TRANSFER
1930 000100 IE = BIT06 ;INTERRUPT ENABLE
1931 000010 IPCK3 = BIT03 ;INVERT PARITY CHECK
1932 000004 IPCK2 = BIT02 ;INVERT PARITY CHECK
1933 000002 IPCK1 = BIT01 ;INVERT PARITY CHECK
1934 000001 IPCK0 = BIT00 ;INVERT PARITY CHECK
1935 .SBTTL RH CONTROLLER REGISTER INDEX VALUES
1936
1937 000000 RMCS1 = 00 ;CONTROL STATUS REGISTER
1938 000002 RMWC = 02 ;WORD COUNT REGISTER
1939 000004 RMBA = 04 ;BUS ADDRESS REGISTER
1940 000010 RMCS2 = 10 ;CONTROLLER STATUS REGISTER

```

```

1941      000022      RMDB      =      22      ;DATA BUFFER
1942      000050      RMBAE      =      50      ;BUS ADDRESS EXTENSION
1943      000052      RMCS3      =      52      ;CONTROL STATUS REGISTER #3
1944
1945      176700      ABASE      =      176700    ;UNIBUS ADDRESS
1946      120254      AVECT1     =      120254    ;UNIBUS VECTOR ADDRESS AND PRIORITY
1947
1948
1949      .SBTTL TRAP CATCHER
1950
1951      000000      .=0
1952      ;*ALL UNUSED LOCATIONS FROM 4 - 776 CONTAIN A ".+2,HALT"
1953      ;*SEQUENCE TO CATCH ILLEGAL TRAPS AND INTERRUPTS
1954      ;*LOCATION 0 CONTAINS 0 TO CATCH IMPROPERLY LOADED VECTORS
1955      .=174
1956 000174 000000      DISPREG: .WORD 0      ;;SOFTWARE DISPLAY REGISTER
1957 000176 000000      SWREG:   .WORD 0      ;;SOFTWARE SWITCH REGISTER
1958
1959
1960      .SBTTL ACT11 HOOKS
1961
1962      ;*****
1963      ;HOOKS REQUIRED BY ACT11
1964      .SSVPC=.      ;SAVE PC
1965      .=46
1966 000046 042374      $ENDAD      ;;1)SET LOC.46 TO ADDRESS OF $ENDAD IN .SEOP
1967      .=52
1968 000052 000000      .WORD 0      ;;2)SET LOC.52 TO ZERO
1969      .=$SVPC      ;; RESTORE PC
1970
1971      .SBTTL STARTING ADDRESS
1972
1973      ;THE PROGRAM STARTS AT LOCATION 200
1974      =      200
1975 000200 000137 005322      JMP      START      ;JUMP TO START OF PROGRAM
1976
1977      .=1100
1978      .SBTTL APT PARAMETER BLOCK
1979
1980      ;*****
1981      ;SET LOCATIONS 24 AND 44 AS REQUIRED FOR APT
1982      ;*****
1983      .SX=.      ;SAVE CURRENT LOCATION
1984      .=24      ;SET POWER FAIL TO POINT TO START OF PROGRAM
1985 000024 000200      200      ;FOR APT START UP
1986      .=44      ;POINT TO APT INDIRECT ADDRESS PNTR.
1987 000044 001100      $APTHDR   ;POINT TO APT HEADER BLOCK
1988      .=$X      ;RESET LOCATION COUNTER
1989      ;*****
1990      ;SETUP APT PARAMETER BLOCK AS DEFINED IN THE APT-PDP11 DIAGNOSTIC
1991      ;INTERFACE SPEC.
1992
1993 001100      $APTHD:
1994 001100 000000      $SHIBTS: .WORD 0      ;; TWO HIGH BITS OF 18 BIT MAILBOX ADDR.
1995 001102 001222      $MBADR:  .WORD $MAIL   ;; ADDRESS OF APT MAILBOX (BITS 0-15)
1996 001104 000001      $STSM:   .WORD 1      ;; RUN TIM OF LONGEST TEST

```

M04

CZRMCO RM03/2 FCTNL TST 1  
CZRMCB.P11 23-NOV-77 12:14

MACY11 30(1046) 23-NOV-77 12:25 PAGE 51  
APT PARAMETER BLOCK

SEQ 0051

1997 001106 000002  
1998 001110 000002  
1999 001112 000042  
2000 001114

\$PASTM: .WORD 2 ;;RUN TIME IN SECS. OF 1ST PASS ON 1 UNIT (QUICK VERIFY)  
\$UNITM: .WORD 2 ;;ADDITIONAL RUN TIME (SECS) OF A PASS FOR EACH ADDITIONAL UNIT  
\$ETEND-\$MAIL/2 ;;LENGTH MAILBOX-ETABLE(WORDS)  
TAGADR = .

2001  
2002  
2003  
2004  
2005  
2006  
2007 001114  
2008 001114  
2009 001114 000000  
2010 001116 000  
2011 001117 000  
2012 001120 000000  
2013 001122 000000  
2014 001124 000000  
2015 001126 000000  
2016 001130 000  
2017 001131 001  
2018 001132 000000  
2019 001134 000000  
2020 001136 000000  
2021 001140 000000  
2022 001142 000000  
2023 001144 000000  
2024 001146 000000  
2025 001150 000  
2026 001151 000  
2027 001152 000000  
2028 001154 177570  
2029 001156 177570  
2030 001160 177560  
2031 001162 177562  
2032 001164 177564  
2033 001166 177566  
2034 001170 000  
2035 001171 002  
2036 001172 012  
2037 001173 000  
2038 001174 000000  
2039 001176 000000  
2040 001200 000000  
2041 001202 000000  
2042 001204 000000  
2043 001206 000000  
2044 001210 000000  
2045 001212 177607 000377  
2046 001216 077  
2047 001217 015  
2048 001220 000012  
2049  
2050  
2051  
2052  
2053  
2054 001222  
2055 001222 000000  
2056 001224 000000

.SBTTL COMMON TAGS

\*\*\*\*\*  
: THIS TABLE CONTAINS VARIOUS COMMON STORAGE LOCATIONS  
: USED IN THE PROGRAM.

.=TAGADR

SCMTAG: .WORD 0  
STSTNM: .BYTE 0000  
SERFLG: .BYTE 0000  
SICNT: .WORD 0000  
SLPADR: .WORD 0000  
SLPERR: .WORD 0000  
SERTTL: .WORD 0000  
SITEMB: .BYTE 0000  
SERMAX: .BYTE 0001  
SERRPC: .WORD 0000  
SGDADR: .WORD 0000  
SBDADR: .WORD 0000  
SGDDAT: .WORD 0000  
SBDDAT: .WORD 0000  
SAUTOB: .BYTE 0000  
SINTAG: .BYTE 0000  
SWR: .WORD DSWR  
DISPLAY: .WORD DDISP  
STKS: 177560  
STKB: 177562  
STPS: 177564  
STPB: 177566  
SNULL: .BYTE 0  
SFILLS: .BYTE 2  
SFILLC: .BYTE 12  
STPFLG: .BYTE 0  
STMP0: .WORD 0  
STMP1: .WORD 0  
STMP2: .WORD 0  
STMP3: .WORD 0  
STMP4: .WORD 0  
STIMES: 0  
SESCAPE: 0  
SBELL: .ASCIZ <207><377><377>  
SQUES: .ASCII /?/  
SCRLF: .ASCII <15>  
SLF: .ASCIZ <12>

:: START OF COMMON TAGS

:: CONTAINS THE TEST NUMBER  
:: CONTAINS ERROR FLAG  
:: CONTAINS SUBTEST ITERATION COUNT  
:: CONTAINS SCOPE LOOP ADDRESS  
:: CONTAINS SCOPE RETURN FOR ERRORS  
:: CONTAINS TOTAL ERRORS DETECTED  
:: CONTAINS ITEM CONTROL BYTE  
:: CONTAINS MAX. ERRORS PER TEST  
:: CONTAINS PC OF LAST ERROR INSTRUCTION  
:: CONTAINS ADDRESS OF 'GOOD' DATA  
:: CONTAINS ADDRESS OF 'BAD' DATA  
:: CONTAINS 'GOOD' DATA  
:: CONTAINS 'BAD' DATA  
:: RESERVED--NOT TO BE USED  
  
:: AUTOMATIC MODE INDICATOR  
:: INTERRUPT MODE INDICATOR  
  
:: ADDRESS OF SWITCH REGISTER  
:: ADDRESS OF DISPLAY REGISTER  
:: TTY KBD STATUS  
:: TTY KBD BUFFER  
:: TTY PRINTER STATUS REG. ADDRESS  
:: TTY PRINTER BUFFER REG. ADDRESS  
:: CONTAINS NULL CHARACTER FOR FILLS  
:: CONTAINS # OF FILLER CHARACTERS REQUIRED  
:: INSERT FILL CHARS. AFTER A "LINE FEED"  
:: "TERMINAL AVAILABLE" FLAG (BIT<07>=0=YES)  
:: USER DEFINED  
:: USER DEFINED  
:: USER DEFINED  
:: USER DEFINED  
:: USER DEFINED  
:: MAX. NUMBER OF ITERATIONS  
:: ESCAPE ON ERROR ADDRESS  
:: CODE FOR BELL  
:: QUESTION MARK  
:: CARRIAGE RETURN  
:: LINE FEED

.SBTTL APT MAILBOX-ETABLE

\*\*\*\*\*

.EVEN  
SMAIL: ; APT MAILBOX  
SMSGTY: .WORD AMSGTY ; MESSAGE TYPE CODE  
SFATAL: .WORD AFATAL ; FATAL ERROR NUMBER

2057	001226	000000	\$TESTN: .WORD	ATESTN	:: TEST NUMBER
2058	001230	000000	\$PASS: .WORD	APASS	:: PASS COUNT
2059	001232	000000	\$DEVCT: .WORD	ADEVCT	:: DEVICE COUNT
2060	001234	000000	\$UNIT: .WORD	AUNIT	:: I/O UNIT NUMBER
2061	001236	000000	\$MSGAD: .WORD	AMSGAD	:: MESSAGE ADDRESS
2062	001240	000000	\$MSGLG: .WORD	AMSGLG	:: MESSAGE LENGTH
2063	001242		\$ETABLE:		:: APT ENVIRONMENT TABLE
2064	001242	000	\$ENV: .BYTE	AENV	:: ENVIRONMENT BYTE
2065	001243	000	\$ENVM: .BYTE	AENVM	:: ENVIRONMENT MODE BITS
2066	001244	000000	\$SWREG: .WORD	ASWREG	:: APT SWITCH REGISTER
2067	001246	000000	\$USWR: .WORD	AUSWR	:: USER SWITCHES
2068	001250	000000	\$CPUOP: .WORD	ACPUOP	:: CPU TYPE, OPTIONS
2069			::*		BITS 15-11=CPU TYPE
2070			::*		11/04=01, 11/05=02, 11/20=03, 11/40=04, 11/45=05
2071			::*		11/70=06, PDQ=07, Q=10
2072			::*		BIT 10=REAL TIME CLOCK
2073			::*		BIT 9=FLOATING POINT PROCESSOR
2074			::*		BIT 8=MEMORY MANAGEMENT
2075	001252	000	\$MAMS1: .BYTE	AMAMS1	:: HIGH ADDRESS, M.S. BYTE
2076	001253	000	\$MTYP1: .BYTE	AMTYP1	:: MEM. TYPE, BLK#1
2077			::*		MEM. TYPE BYTE -- (HIGH BYTE)
2078			::*		900 NSEC CORE=001
2079			::*		300 NSEC BIPOLAR=002
2080			::*		500 NSEC MOS=003
2081	001254	000000	\$MADR1: .WORD	AMADR1	:: HIGH ADDRESS, BLK#1
2082			::*		MEM. LAST ADDR.=3 BYTES, THIS WORD AND LOW OF "TYPE" ABOVE
2083	001256	000	\$MAMS2: .BYTE	AMAMS2	:: HIGH ADDRESS, M.S. BYTE
2084	001257	000	\$MTYP2: .BYTE	AMTYP2	:: MEM. TYPE, BLK#2
2085	001260	000000	\$MADR2: .WORD	AMADR2	:: MEM. LAST ADDRESS, BLK#2
2086	001262	000	\$MAMS3: .BYTE	AMAMS3	:: HIGH ADDRESS, M.S. BYTE
2087	001263	000	\$MTYP3: .BYTE	AMTYP3	:: MEM. TYPE, BLK#3
2088	001264	000000	\$MADR3: .WORD	AMADR3	:: MEM. LAST ADDRESS, BLK#3
2089	001266	000	\$MAMS4: .BYTE	AMAMS4	:: HIGH ADDRESS, M.S. BYTE
2090	001267	000	\$MTYP4: .BYTE	AMTYP4	:: MEM. TYPE, BLK#4
2091	001270	000000	\$MADR4: .WORD	AMADR4	:: MEM. LAST ADDRESS, BLK#4
2092	001272	120254	\$SVECT1: .WORD	AVECT1	:: INTERRUPT VECTOR#1 BUS PRIORITY#1
2093	001274	000000	\$SVECT2: .WORD	AVECT2	:: INTERRUPT VECTOR#2 BUS PRIORITY#2
2094	001276	176700	\$BASE: .WORD	ABASE	:: BASE ADDRESS OF EQUIPMENT UNDER TEST
2095	001300	000000	\$DEVN: .WORD	ADEVN	:: DEVICE MAP
2096	001302	000000	\$CDW1: .WORD	ACDW1	:: CONTROLLER DESCRIPTION WORD#1
2097	001304	000000	\$CDW2: .WORD	ACDW2	:: CONTROLLER DESCRIPTION WORD#2
2098	001306	000000	\$DDW0: .WORD	ADDW0	:: DEVICE DESCRIPTOR WORD#0
2099	001310	000000	\$DDW1: .WORD	ADDW1	:: DEVICE DESCRIPTOR WORD#1
2100	001312	000000	\$DDW2: .WORD	ADDW2	:: DEVICE DESCRIPTOR WORD#2
2101	001314	000000	\$DDW3: .WORD	ADDW3	:: DEVICE DESCRIPTOR WORD#3
2102	001316	000000	\$DDW4: .WORD	ADDW4	:: DEVICE DESCRIPTOR WORD#4
2103	001320	000000	\$DDW5: .WORD	ADDW5	:: DEVICE DESCRIPTOR WORD#5
2104	001322	000000	\$DDW6: .WORD	ADDW6	:: DEVICE DESCRIPTOR WORD#6
2105	001324	000000	\$DDW7: .WORD	ADDW7	:: DEVICE DESCRIPTOR WORD#7
2106	001326		\$ETEND:		
2107			.MEXIT		
2108					
2109					
2110					
2111					
2112	001326				

;THE REGISTER INPUT BUFFER IS USED FOR  
;STORING DRIVE STATUS  
GETBUF:

```

2113
2114
2115 001326 000000
2116 001330 000000
2117 001332 000000
2118 001334 000000
2119 001336 000000
2120 001340 000000
2121 001342 000000
2122 001344 000000
2123 001346 000000
2124 001350 000000
2125 001352 000000
2126 001354 000000
2127 001356 000000
2128 001360 000000
2129 001362 000000
2130 001364 000000
2131 001366 000000
2132 001370 000000
2133 001372 000000
2134 001374 000000
2135
2136
2137
2138
2139 001376
2140
2141
2142 001376 000000
2143 001400 000000
2144 001402 000000
2145 001404 000000
2146 001406 000000
2147 001410 000000
2148 001412 000000
2149 001414 000000
2150 001416 000000
2151 001420 000000
2152 001422 000000
2153 001424 000000
2154 001426 000000
2155 001430 000000
2156 001432 000000
2157 001434 000000
2158 001436 000000
2159 001440 000000
2160 001442 000000
2161 001444 000000
2162
2163
2164
2165
2166
2167 001446 000012
2168

```

:REGISTER INPUT BUFFER

```

RMCS11: .WORD
RMWCI: .WORD
RMBAI: .WORD
RMDAI: .WORD
RMCS21: .WORD
RMDSI: .WORD
RMER11: .WORD
RMAI: .WORD
RMLAI: .WORD
RMDBI: .WORD
RMMR11: .WORD
RMDTI: .WORD
RMSNI: .WORD
RMOFI: .WORD
RMDCI: .WORD
RMCCI: .WORD
RMMR21: .WORD
RMER21: .WORD
RMEC11: .WORD
RMEC21: .WORD

```

```

:CONTROL STATUS REGISTER
:WORD COUNT REGISTER
:BUS ADDRESS REGISTER
:DISK ADDRESS REGISTER
:CONTROLLER STATUS REGISTER
:DRIVE STATUS REGISTER
:ERROR REGISTER 1
:ATTENTION SUMMARY REGISTER
:LOOK AHEAD REGISTER
:DATA BUFFER
:MAINTENANCE REGISTER #1
:DRIVE TYPE REGISTER
:SERIAL NUMBER REGISTER
:OFFSET REGISTER
:DESIRED CYLINDER REGISTER
:CURRENT CYLINDER REGISTER
:MAINTENANCE REGISTER #2
:ERROR REGISTER 2
:ECC POSITION REGISTER
:ECC PATTERN REGISTER

```

```

:THE REGISTER OUTPUT BUFFER IS USED FOR
:ASSEMBLING DATA GOING TO REGISTER

```

PUTBUF:

:REGISTER OUTPUT BUFFER

```

RMCS10: .WORD
RMWCO: .WORD
RMBAO: .WORD
RMDAO: .WORD
RMCS20: .WORD
RMSO: .WORD
RMER10: .WORD
RMAO: .WORD
RMLAO: .WORD
RMDBO: .WORD
RMMR10: .WORD
RMDTO: .WORD
RMSNO: .WORD
RMOFO: .WORD
RMDCO: .WORD
RMCCO: .WORD
RMMR20: .WORD
RMER20: .WORD
RMEC10: .WORD
RMEC20: .WORD

```

```

:CONTROL STATUS REGISTER
:WORD COUNT REGISTER
:BUS ADDRESS REGISTER
:DISK ADDRESS REGISTER
:CONTROLLER STATUS REGISTER
:DRIVE STATUS REGISTER
:ERROR REGISTER 1
:ATTENTION SUMMARY REGISTER
:LOOK AHEAD REGISTER
:DATA BUFFER
:MAINTENANCE REGISTER #1
:DRIVE TYPE REGISTER
:SERIAL NUMBER REGISTER
:OFFSET REGISTER
:DESIRED CYLINDER REGISTER
:CURRENT CYLINDER REGISTER
:MAINTENANCE REGISTER #2
:ERROR REGISTER 2
:ECC POSITION REGISTER
:ECC PATTERN REGISTER

```

```

: EACH WORD OF THE TEST QUE CONTAINS THE DEVICE NUMBER IN
: THE LOW BYTE AND THE ATTENTION BIT IN THE HIGH BYTE. A ZERO
: WORD IS A BLANK AND REPRESENTS THE END OF THE QUE.

```

```

TSTQUE: .BLKW 10. ;TEST QUE

```



2169  
 2170  
 2171 001472 000000  
 2172  
 2173  
 2174  
 2175 001474 000000  
 2176 001476 000000  
 2177 001500 000000  
 2178 001502 000000  
 2179  
 2180  
 2181  
 2182  
 2183 001504 000027  
 2184  
 2185  
 2186  
 2187  
 2188 001533 000027  
 2189  
 2190  
 2191

```

;MEDIA ENABLE IS SET IF THE BAD SECTOR FILES HAVE BEEN RECOVERED
;FOR THE UNIT UNDER TEST, OTHERWISE IT IS ZERO.
MEDENB: .WORD ;MEDIA ENABLE

;LOCATIONS "ASNDC" AND "ASNDC" CONTAIN THE CYLINDER, TRACK AND SECTOR
;ADDRESS ASSIGNED BY THE BAD SECTOR MODULE.
ASNDC: .WORD ;ASSIGNED DESIRED CYLINDER
ASNDA: .WORD ;ASSIGNED TRACK, AND SECTOR
CLKADR: .WORD ;UNIBUS ADDRESS OF KW11 CLOCK
CLKVCT: .WORD ;VECTOR ADDRESS OF KW11 CLOCK

;THE GET INDEX TABLE CONTAINS A BYTE LIST OF REGISTERS WHICH
;ARE READ BY THE GET SUBROUTINE. THE LIST IS TERMINATED BY
;A NEGATIVE BYTE.
GETINX: .BLKB 23. ;GET INDEX TABLE

;THE PUT INDEX TABLE ICONTAINS A BYTE LIST OF REGISTERS WHICH
;ARE WRITTEN BY THE PUT SUBROUTINE. THE LIST IS TERMINATED BY
;A NEGATIVE BYTE.
PUTINX: .BLKB 23. ;PUT INDEX TABLE

;PUT TAGS HERE
  
```

2192  
2193  
2194  
2195  
2196  
2197  
2198  
2199  
2200  
2201  
2202  
2203  
2204  
2205  
2206  
2207  
2208

001562

.SBTTL ERROR POINTER TABLE

;\*THIS TABLE CONTAINS THE INFORMATION FOR EACH ERROR THAT CAN OCCUR.  
;\*THE INFORMATION IS OBTAINED BY USING THE INDEX NUMBER FOUND IN  
;\*LOCATION \$ITEMB. THIS NUMBER INDICATES WHICH ITEM IN THE TABLE IS PERTINENT.  
;\*NOTE1: IF \$ITEMB IS 0 THE ONLY PERTINENT DATA IS (\$ERRPC).  
;\*NOTE2: EACH ITEM IN THE TABLE CONTAINS 4 POINTERS EXPLAINED AS FOLLOWS:

;\* EM ;;POINTS TO THE ERROR MESSAGE  
;\* DH ;;POINTS TO THE DATA HEADER  
;\* DT ;;POINTS TO THE DATA  
;\* DF ;;POINTS TO THE DATA FORMAT

\$ERRTB:

2209			;ERROR	1	WRONG UNIT SELECTED
2210	001562	070012		EMT1	
2211	001564	074104		EHT1	
2212	001566	074230		EDT1	
2213	001570	074320		EFT1	
2214					
2215					
2216			;ERROR	2	DEVICE WENT UNAVAILABLE
2217	001572	070016		EMT2	
2218	001574	074104		EHT1	
2219	001576	074230		EDT1	
2220	001600	074320		EFT1	
2221					
2222					
2223			;ERROR	3	DEVICE WENT NONEXISTENT
2224	001602	070024		EMT3	
2225	001604	074104		EHT1	
2226	001606	074230		EDT1	
2227	001610	074320		EFT1	
2228					
2229					
2230			;ERROR	4	CONTROLLER NOT READY
2231	001612	070032		EMT4	
2232	001614	074104		EHT1	
2233	001616	074230		EDT1	
2234	001620	074320		EFT1	
2235					
2236					
2237			;ERROR	5	DRIVE NOT READY AND GO NOT RESET
2238	001622	070040		EMT5	
2239	001624	074104		EHT1	
2240	001626	074230		EDT1	
2241	001630	074320		EFT1	
2242					
2243					
2244			;ERROR	6	UNEXPECTED VALUE FOR "ATA" STATUS
2245	001632	070046		EMT6	
2246	001634	074104		EHT1	
2247	001636	074230		EDT1	
2248	001640	074320		EFT1	
2249					
2250					
2251			;ERROR	7	BUS TIMEOUT TRYING TO READ OR WRITE REGISTER
2252	001642	070054		EMT7	
2253	001644	000000		0	
2254	001646	000000		0	
2255	001650	000000		0	
2256					
2257					
2258			;ERROR	10	DRIVE NOT READY BUT GO IS RESET
2259	001652	070062		EMT10	
2260	001654	074104		EHT1	
2261	001656	074230		EDT1	
2262	001660	074320		EFT1	
2263					
2264					

2265			;ERROR	11	GO NOT RESET BUT DRIVE IS READY
2266	001662	070066		EMT11	
2267	001664	074104		EHT1	
2268	001666	074230		EDT1	
2269	001670	074320		EFT1	
2270					
2271					
2272			;ERROR	12	INCORRECT FUNCTION CODE
2273	001672	070072		EMT12	
2274	001674	074104		EHT1	
2275	001676	074230		EDT1	
2276	001700	074320		EFT1	
2277					
2278					
2279			;ERROR	13	PARITY ERROR READING REMOTE REGISTERS
2280	001702	070100		EMT13	
2281	001704	074104		EHT1	
2282	001706	074230		EDT1	
2283	001710	074320		EFT1	
2284					
2285					
2286			;ERROR	14	TRANSFER ERROR IS INCORRECT
2287	001712	070112		EMT14	
2288	001714	074104		EHT1	
2289	001716	074230		EDT1	
2290	001720	074320		EFT1	
2291					
2292					
2293			;ERROR	15	INCORRECT WORD COUNT
2294	001722	070120		EMT15	
2295	001724	074104		EHT1	
2296	001726	074230		EDT1	
2297	001730	074320		EFT1	
2298					
2299					
2300			;ERROR	16	INCORRECT BUS ADDRESS
2301	001732	070126		EMT16	
2302	001734	074104		EHT1	
2303	001736	074230		EDT1	
2304	001740	074320		EFT1	
2305					
2306					
2307			;ERROR	17	INCORRECT LBT STATUS
2308	001742	070136		EMT17	
2309	001744	074104		EHT1	
2310	001746	074230		EDT1	
2311	001750	074320		EFT1	
2312					
2313					
2314			;ERROR	20	INCORRECT AOE
2315	001752	070146		EMT20	
2316	001754	074104		EHT1	
2317	001756	074230		EDT1	
2318	001760	074320		EFT1	
2319					
2320					

2321			;ERROR	21	INCORRECT DISK ADDRESS
2322	001762	070156		EMT21	
2323	001764	074104		EHT1	
2324	001766	074230		EDT1	
2325	001770	074320		EFT1	
2326					
2327					
2328			;ERROR	22	INCORRECT CYLINDER ADDRESS
2329	001772	070166		EMT22	
2330	001774	074104		EHT1	
2331	001776	074230		EDT1	
2332	002000	074320		EFT1	
2333					
2334					
2335			;ERROR	23	INCORRECT WLE STATUS
2336	002002	070176		EMT23	
2337	002004	074104		EHT1	
2338	002006	074230		EDT1	
2339	002010	074320		EFT1	
2340					
2341					
2342			;ERROR	24	INCORRECT UPE STATUS
2343	002012	070206		EMT24	
2344	002014	074104		EHT1	
2345	002016	074230		EDT1	
2346	002020	074320		EFT1	
2347					
2348					
2349			;ERROR	25	INCORRECT WCF STATUS
2350	002022	070216		EMT25	
2351	002024	074104		EHT1	
2352	002026	074230		EDT1	
2353	002030	074320		EFT1	
2354					
2355					
2356			;ERROR	26	INCORRECT WCE STATUS
2357	002032	070226		EMT26	
2358	002034	074104		EHT1	
2359	002036	074230		EDT1	
2360	002040	074320		EFT1	
2361					
2362					
2363			;ERROR	27	INCORRECT MDPE STATUS
2364	002042	070236		EMT27	
2365	002044	074104		EHT1	
2366	002046	074230		EDT1	
2367	002050	074320		EFT1	
2368					
2369					
2370			;ERROR	30	INCORRECT DCK STATUS
2371	002052	070246		EMT30	
2372	002054	074104		EHT1	
2373	002056	074230		EDT1	
2374	002060	074320		EFT1	
2375					
2376					

2377			;ERROR	31	INCORRECT ECH STATUS
2378	002062	070256		EMT31	
2379	002064	074104		EHT1	
2380	002066	074230		EDT1	
2381	002070	074320		EFT1	
2382					
2383					
2384			;ERROR	32	DLT SHOULD NOT BE SET
2385	002072	070266		EMT32	
2386	002074	074104		EHT1	
2387	002076	074230		EDT1	
2388	002100	074320		EFT1	
2389					
2390					
2391			;ERROR	33	MXF SHOULD NOT BE SET
2392	002102	070276		EMT33	
2393	002104	074104		EHT1	
2394	002106	074230		EDT1	
2395	002110	074320		EFT1	
2396					
2397					
2398			;ERROR	34	DTE SHOULD NOT BE SET
2399	002112	070306		EMT34	
2400	002114	074104		EHT1	
2401	002116	074230		EDT1	
2402	002120	074320		EFT1	
2403					
2404					
2405			;ERROR	35	INCORRECT HCRC STATUS
2406	002122	070316		EMT35	
2407	002124	074104		EHT1	
2408	002126	074230		EDT1	
2409	002130	074320		EFT1	
2410					
2411					
2412			;ERROR	36	INCORRECT HCE STATUS
2413	002132	070326		EMT36	
2414	002134	074104		EHT1	
2415	002136	074230		EDT1	
2416	002140	074320		EFT1	
2417					
2418					
2419			;ERROR	37	INCORRECT FER STATUS
2420	002142	070336		EMT37	
2421	002144	074104		EHT1	
2422	002146	074230		EDT1	
2423	002150	074320		EFT1	
2424					
2425					
2426			;ERROR	40	DPE SHOULD NOT BE SET (NOT A DATA COMMAND)
2427	002152	070346		EMT40	
2428	002154	074104		EFT1	
2429	002156	074230		EDT1	
2430	002160	074320		EFT1	
2431					
2432					

2433			;ERROR	41	LOST "MOL" DURING PACK ACKNOWLEDGE
2434	002162	070354		EMT41	
2435	002164	074104		EHT1	
2436	002166	074230		EDT1	
2437	002170	074320		EFT1	
2438					
2439					
2440			;ERROR	42	UNSAFE ERROR DURING PACK ACKNOWLEDGE
2441	002172	070364		EMT42	
2442	002174	074104		EHT1	
2443	002176	074230		EDT1	
2444	002200	074320		EFT1	
2445					
2446					
2447			;ERROR	43	"OPI" ERROR DURING PACK ACKNOWLEDGE
2448	002202	070376		EMT43	
2449	002204	074104		EHT1	
2450	002206	074230		EDT1	
2451	002210	074320		EFT1	
2452					
2453					
2454			;ERROR	44	"RMR" ERROR DURING PACK ACKNOWLEDGE
2455	002212	070406		EMT44	
2456	002214	074104		EHT1	
2457	002216	074230		EDT1	
2458	002220	074320		EFT1	
2459					
2460					
2461			;ERROR	45	"ILR" ERROR DURING PACK ACKNOWLEDGE
2462	002222	070416		EMT45	
2463	002224	074104		EHT1	
2464	002226	074230		EDT1	
2465	002230	074320		EFT1	
2466					
2467					
2468			;ERROR	46	"ILF" ERROR DURING PACK ACKNOWLEDGE
2469	002232	070426		EMT46	
2470	002234	074104		EHT1	
2471	002236	074230		EDT1	
2472	002240	074320		EFT1	
2473					
2474					
2475			;ERROR	47	COMPOSITE ERROR STATUS IS INCORRECT
2476	002242	070436		EMT47	
2477	002244	074104		EHT1	
2478	002246	074230		EDT1	
2479	002250	074320		EFT1	
2480					
2481					
2482			;ERROR	50	PARITY ERROR WRITING REMOTE REGISTERS
2483	002252	070444		EMT50	
2484	002254	074104		EHT1	
2485	002256	074230		EDT1	
2486	002260	074320		EFT1	
2487					
2488					

2489			;ERROR	51	INCORRECT IAE STATUS DURING SEEK COMMAND
2490	002262	070454		EMT51	
2491	002264	074104		EHT1	
2492	002266	074230		EDT1	
2493	002270	074320		EFT1	
2494					
2495					
2496			;ERROR	52	OPI ERROR DURING SEEK - MEDIUM IS NOT ON LINE
2497	002272	070466		EMT52	
2498	002274	074104		EHT1	
2499	002276	074230		EDT1	
2500	002300	074320		EFT1	
2501					
2502					
2503			;ERROR	53	OPI ERROR DURING SEEK - MEDIUM IS ON LINE, ASSUME ON CYLINDER LATCH DIDN'T RESET
2504			;		
2505	002302	070504		EMT53	
2506	002304	074104		EHT1	
2507	002306	074230		EDT1	
2508	002310	074320		EFT1	
2509					
2510					
2511			;ERROR	54	SEEK INCOMPLETE ERROR DURING SEEK COMMAND
2512	002312	070522		EMT54	
2513	002314	074104		EHT1	
2514	002316	074230		EDT1	
2515	002320	074320		EFT1	
2516					
2517					
2518			;ERROR	55	DEVICE CHECK DURING SEEK COMMAND
2519	002322	070532		EMT55	
2520	002324	074104		EHT1	
2521	002326	074230		EDT1	
2522	002330	074320		EFT1	
2523					
2524					
2525			;ERROR	56	PIP IS STILL SET AFTER SEEK - SKI IS RESET
2526	002332	070544		EMT56	
2527	002334	074104		EHT1	
2528	002336	074230		EDT1	
2529	002340	074320		EFT1	
2530					
2531					
2532			;ERROR	57	ATA DID NOT SET DURING SEEK COMMAND
2533	002342	070562		EMT57	
2534	002344	074104		EHT1	
2535	002346	074230		EDT1	
2536	002350	074320		EFT1	
2537					
2538					
2539			;ERROR	60	IVC ERROR DURING SEEK COMMAND - LOST VOLUME VALID
2540			;		
2541	002352	070572		EMT60	
2542	002354	074104		EHT1	
2543	002356	074230		EDT1	
2544	002360	074320		EFT1	



2545					
2546					
2547					
2548					
2549	002362	070610			
2550	002364	074104			
2551	002366	074230			
2552	002370	074320			
2553					
2554					
2555					
2556					
2557	002372	070630			
2558	002374	074104			
2559	002376	074230			
2560	002400	074320			
2561					
2562					
2563					
2564	002402	000000			
2565	002404	000000			
2566	002406	000000			
2567	002410	000000			
2568					
2569					
2570					
2571	002412	070646			
2572	002414	074104			
2573	002416	074230			
2574	002420	074320			
2575					
2576					
2577					
2578	002422	070666			
2579	002424	074104			
2580	002426	074230			
2581	002430	074320			
2582					
2583					
2584					
2585	002432	070706			
2586	002434	074104			
2587	002436	074230			
2588	002440	074320			
2589					
2590					
2591					
2592	002442	070720			
2593	002444	074104			
2594	002446	074230			
2595	002450	074320			
2596					
2597					
2598					
2599	002452	070732			
2600	002454	074104			

;ERROR 61 ERRONEOUS IVC ERROR DURING SEEK COMMAND -  
VOLUME VALID IS STIL SET

EMT61  
EHT1  
EDT1  
EFT1

;ERROR 62 MOL IS ZERO, BUT OPI WAS NOT  
REPORTED DURING SEEK COMMAND

EMT62  
EHT1  
EDT1  
EFT1

;ERROR 63 UNUSED

0  
0  
0  
0

;ERROR 64 DRIVE DID NOT DETECT "IVC" ERROR DURING SEEK

EMT64  
EHT1  
EDT1  
EFT1

;ERROR 65 DRIVE EXECUTED A SEEK WITH ERROR SET

EMT65  
EHT1  
EDT1  
EFT1

;ERROR 66 UNEXPECTED ERROR SET IN RMER1

EMT66  
EHT1  
EDT1  
EFT1

;ERROR 67 UNEXPECTED ERROR SET IN RMER2

EMT67  
EHT1  
EDT1  
EFT1

;ERROR 70 ERRONEOUS "IAE" ERROR DURING RECALIBRATE

EMT70  
EHT1

2601	002456	074230	EDT1	
2602	002460	074320	EFT1	
2603				
2604				
2605			;ERROR 71	"ILF" ERROR DURING RECALIBRATE
2606	002462	070742	EMT71	
2607	002464	074104	EHT1	
2608	002466	074230	EDT1	
2609	002470	074320	EFT1	
2610				
2611				
2612			;ERROR 72	"OPI" ERROR DURING RECALIBRATE DUE TO "MOL" = 0
2613	002472	070752	EMT72	
2614	002474	074104	EHT1	
2615	002476	074230	EDT1	
2616	002500	074320	EFT1	
2617				
2618				
2619			;ERROR 73	"OPI" ERROR DURING RECALIBRATE BECAUSE ON CYLINDER DIDNT DROP
2620			:	
2621	002502	070770	EMT73	
2622	002504	074104	EHT1	
2623	002506	074230	EDT1	
2624	002510	074320	EFT1	
2625				
2626				
2627			;ERROR 74	"IVC" ERROR DURING RECALIBRATE - "VV" = 0
2628	002512	071006	EMT74	
2629	002514	074104	EHT1	
2630	002516	074230	EDT1	
2631	002520	074320	EFT1	
2632				
2633				
2634			;ERROR 75	ERRONEOUS "IVC" ERROR DURING RECALIBRATE - "VV" = 1
2635	002522	071016	EMT75	
2636	002524	074104	EHT1	
2637	002526	074230	EDT1	
2638	002530	074320	EFT1	
2639				
2640				
2641			;ERROR 76	"SKI" ERROR DURING RECALIBRATE
2642	002532	071036	EMT76	
2643	002534	074104	EHT1	
2644	002536	074230	EDT1	
2645	002540	074320	EFT1	
2646				
2647				
2648			;ERROR 77	"DVC" OCCURRED DURING RECALIBRATE
2649	002542	071046	EMT77	
2650	002544	074104	EHT1	
2651	002546	074230	EDT1	
2652	002550	074320	EFT1	
2653				
2654				
2655			;ERROR 100	LOST "MOL" DURING RECALIBRATE - "OPI" = 0
2656	002552	071060	EMT100	

2657	002554	074104	EHT1	
2658	002556	074230	EDT1	
2659	002560	074320	EFT1	
2660				
2661				
2662				
2663	002562	071076	;ERROR 101	LOST "VV" DURING RECALIBRATE - "IVC" = 0
2664	002564	074104	EMT101	
2665	002566	074230	EHT1	
2666	002570	074320	EDT1	
2667			EFT1	
2668				
2669				
2670	002572	071114	;ERROR 102	"ATA" DID NOT SET DURING RECALIBRATE
2671	002574	074104	EMT102	
2672	002576	074230	EHT1	
2673	002600	074320	EDT1	
2674			EFT1	
2675				
2676				
2677	002602	071124	;ERROR 103	"OM" DID NOT RESET DURING RECALIBRATE
2678	002604	074104	EMT103	
2679	002606	074230	EHT1	
2680	002610	074320	EDT1	
2681			EFT1	
2682				
2683				
2684	002612	071136	;ERROR 104	"PIP" IS STIL SET AFTER RECALIBRATE
2685	002614	074104	EMT104	
2686	002616	074230	EHT1	
2687	002620	074320	EDT1	
2688			EFT1	
2689				
2690				
2691	002622	071154	;ERROR 105	UNEXPECTED "ILR" ERROR DURING RECALIBRATE
2692	002624	074104	EMT105	
2693	002626	074230	EHT1	
2694	002630	074320	EDT1	
2695			EFT1	
2696				
2697				
2698	002632	071164	;ERROR 106	UNEXPECTED "RMR" ERROR DURING RECALIBRATE
2699	002634	074104	EMT106	
2700	002636	074230	EHT1	
2701	002640	074320	EDT1	
2702			EFT1	
2703				
2704				
2705	002642	071174	;ERROR 107	"UNS" ERROR DURING RECALIBRATE - AC POWER IS LOW
2706	002644	074104	EMT107	
2707	002646	074230	EHT1	
2708	002650	074320	EDT1	
2709			EFT1	
2710				
2711				
2712	002652	071214	;ERROR 110	CANNOT ACCESS MASSBUS CONTROLLER VIA UNIBUS
			EMT110	

2713	002654	074126	EHT110	
2714	002656	074246	EDT110	
2715	002660	074336	EFT110	
2716				
2717				
2718				;ERROR 111 NONEXISTENT DEVICE
2719	002662	071226	EMT111	
2720	002664	074132	EHT111	
2721	002666	074250	EDT111	
2722	002670	074340	EFT111	
2723				
2724				
2725				;ERROR 112 DEVICE NOT AVAILABLE
2726	002672	071234	EMT112	
2727	002674	074132	EHT111	
2728	002676	074250	EDT111	
2729	002700	074340	EFT111	
2730				
2731				
2732				;ERROR 113 BUS TIMEOUT-NED STATUS FAILURE
2733	002702	071242	EMT113	
2734	002704	000000	0	
2735	002706	000000	0	
2736	002710	000000	0	
2737				
2738				
2739				;ERROR 114 DEVICE NOT AN RM03
2740	002712	071256	EMT114	
2741	002714	074136	EHT114	
2742	002716	074252	EDT114	
2743	002720	074342	EFT114	
2744				
2745				
2746				;ERROR 115 RMCS1 NOT INITIALIZED BY UNIBUS
2747	002722	071264	EMT115	
2748	002724	074104	EHT1	
2749	002726	074230	EDT1	
2750	002730	074320	EFT1	
2751				
2752				
2753				;ERROR 116 RMBA NOT INITIALIZED BY UNIBUS
2754	002732	071274	EMT116	
2755	002734	074104	EHT1	
2756	002736	074230	EDT1	
2757	002740	074320	EFT1	
2758				
2759				
2760				;ERROR 117 RMCS2 NOT INITIALIZED BY UNIBUS
2761	002742	071304	EMT117	
2762	002744	074104	EHT1	
2763	002746	074230	EDT1	
2764	002750	074320	EFT1	
2765				
2766				;ERROR 120 RMER1 NOT INITIALIZED BY UNIBUS
2767				
2768	002752	071314	EMT120	

2769	002754	074104		EHT1	
2770	002756	074230		EDT1	
2771	002760	074320		EFT1	
2772					
2773					
2774			;ERROR	121	RMAS NOT INITIALIZED BY UNIBUS
2775	002762	071324		EMT121	
2776	002764	074104		EHT1	
2777	002766	074230		EDT1	
2778	002770	074320		EFT1	
2779					
2780					
2781			;ERROR	122	RMMR1 NOT INITIALIZED BY UNIBUS
2782	002772	071334		EMT122	
2783	002774	074104		EHT1	
2784	002776	074230		EDT1	
2785	003000	074320		EFT1	
2786					
2787					
2788			;ERROR	123	RMDS NOT INITIALIZED BY UNIBUS
2789	003002	071344		EMT123	
2790	003004	074104		EHT1	
2791	003006	074230		EDT1	
2792	003010	074320		EFT1	
2793					
2794					
2795			;ERROR	124	RMEC2 NOT INITIALIZED BY UNIBUS
2796	003012	071354		EMT124	
2797	003014	074104		EHT1	
2798	003016	074230		EDT1	
2799	003020	074320		EFT1	
2800					
2801					
2802			;ERROR	125	RMMR2 NOT INITIALIZED BY UNIBUS
2803	003022	071364		EMT125	
2804	003024	074104		EHT1	
2805	003026	074230		EDT1	
2806	003030	074320		EFT1	
2807					
2808					
2809			;ERROR	126	RMCS1 NOT CLEARED BY CONTROLLER CLEAR
2810	003032	071374		EMT126	
2811	003034	074104		EHT1	
2812	003036	074230		EDT1	
2813	003040	074320		EFT1	
2814					
2815					
2816			;ERROR	127	RMBA NOT CLEARED BY CONTROLLER CLEAR
2817	003042	071406		EMT127	
2818	003044	074104		EHT1	
2819	003046	074230		EDT1	
2820	003050	074320		EFT1	
2821					
2822					
2823			;ERROR	130	RMCS2 NOT CLEARED BY CONTROLLER CLEAR
2824	003052	071420		EMT130	

2825	003054	074104		EHT1	
2826	003056	074230		EDT1	
2827	003060	074320		EFT1	
2828					
2829					
2830			;ERROR	131	RMER1 NOT CLEARED BY CONTROLLER CLEAR
2831	003062	071432		EMT131	
2832	003064	074104		EHT1	
2833	003066	074230		EDT1	
2834	003070	074320		EFT1	
2835					
2836					
2837			;ERROR	132	RMAS NOT CLEARED BY CONTROLLER CLEAR
2838	003072	071444		EMT132	
2839	003074	074104		EHT1	
2840	003076	074230		EDT1	
2841	003100	074320		EFT1	
2842					
2843					
2844			;ERROR	133	RMMR1 NOT CLEARED BY CONTROLLER CLEAR
2845	003102	071456		EMT133	
2846	003104	074104		EHT1	
2847	003106	074230		EDT1	
2848	003110	074320		EFT1	
2849					
2850					
2851			;ERROR	134	RMDS NOT CLEARED BY CONTROLLER CLEAR
2852	003112	071470		EMT134	
2853	003114	074104		EHT1	
2854	003116	074230		EDT1	
2855	003120	074320		EFT1	
2856					
2857					
2858			;ERROR	135	RMEC2 NOT CLEARED BY CONTROLLER CLEAR
2859	003122	071502		EMT135	
2860	003124	074104		EHT1	
2861	003126	074230		EDT1	
2862	003130	074320		EFT1	
2863					
2864					
2865			;ERROR	136	RMMR2 NOT CLEARED BY CONTROLLER CLEAR
2866	003132	071514		EMT136	
2867	003134	074104		EHT1	
2868	003136	074230		EDT1	
2869	003140	074320		EFT1	
2870					
2871					
2872			;ERROR	137	RMCS1 NOT CLEARED BY ERROR CLEAR
2873	003142	071526		EMT137	
2874	003144	074104		EHT1	
2875	003146	074230		EDT1	
2876	003150	074320		EFT1	
2877					
2878					
2879			;ERROR	140	RMCS2 NOT CLEARED BY ERROR CLEAR
2880	003152	071536		EMT140	

2881	003154	074104		EHT1	
2882	003156	074230		EDT1	
2883	003160	074320		EFT1	
2884					
2885					
2886			;ERROR	141	RMCS1 NOT CLEARED BY DRIVE CLEAR
2887	003162	071546		EMT141	
2888	003164	074104		EHT1	
2889	003166	074230		EDT1	
2890	003170	074320		EFT1	
2891					
2892					
2893			;ERROR	142	RMDS NOT CLEARED BY DRIVE CLEAR
2894	003172	071556		EMT142	
2895	003174	074104		EHT1	
2896	003176	074230		EDT1	
2897	003200	074320		EFT1	
2898					
2899					
2900			;ERROR	143	RMER1 NOT CLEARED BY DRIVE CLEAR
2901	003202	071566		EMT143	
2902	003204	074104		EHT1	
2903	003206	074230		EDT1	
2904	003210	074320		EFT1	
2905					
2906					
2907			;ERROR	144	RMAS NOT CLEARED BY DRIVE CLEAR
2908	003212	071576		EMT144	
2909	003214	074104		EHT1	
2910	003216	074230		EDT1	
2911	003220	074320		EFT1	
2912					
2913					
2914			;ERROR	145	RMMR1 NOT CLEARED BY DRIVE CLEAR
2915	003222	071606		EMT145	
2916	003224	074104		EHT1	
2917	003226	074230		EDT1	
2918	003230	074320		EFT1	
2919					
2920					
2921			;ERROR	146	RMMR2 NOT CLEARED BY DRIVE CLEAR
2922	003232	071616		EMT146	
2923	003234	074104		EHT1	
2924	003236	074230		EDT1	
2925	003240	074320		EFT1	
2926					
2927					
2928			;ERROR	147	RMER2 NOT CLEARED BY DRIVE CLEAR
2929	003242	071626		EMT147	
2930	003244	074104		EHT1	
2931	003246	074230		EDT1	
2932	003250	074320		EFT1	
2933					
2934					
2935			;ERROR	150	RMEC2 NOT CLEARED BY DRIVE CLEAR
2936	003252	071636		EMT150	

2937	003254	074104	EHT1	
2938	003256	074230	EDT1	
2939	003260	074320	EFT1	
2940				
2941				
2942				
2943	003262	071646	;ERROR 151	MEDIUM NOT ON LINE
2944	003264	074104	EMT151	
2945	003266	074230	EHT1	
2946	003270	074320	EDT1	
2947			EFT1	
2948				
2949				
2950	003272	071660	;ERROR 152	DRIVE FAULT
2951	003274	074104	EMT152	
2952	003276	074230	EHT1	
2953	003300	074320	EDT1	
2954			EFT1	
2955				
2956				
2957	003302	071672	;ERROR 153	UNSAFE SHOULD BE SET BECAUSE DVC IS SET
2958	003304	074104	EMT153	
2959	003306	074230	EHT1	
2960	003310	074320	EDT1	
2961			EFT1	
2962				
2963				
2964	003312	071710	;ERROR 154	UNSAFE SHOULD NOT BE SET, AC IS LOW
2965	003314	074104	EMT154	
2966	003316	074230	EHT1	
2967	003320	074320	EDT1	
2968			EFT1	
2969				
2970				
2971	003322	071726	;ERROR 155	VOLUME VALID NOT SET BY PACK ACK
2972	003324	074104	EMT155	
2973	003326	074230	EHT1	
2974	003330	074320	EDT1	
2975			EFT1	
2976				
2977				
2978	003332	071740	;ERROR 156	OFFSET MODE NOT SET BY OFFSET COMMAND
2979	003334	074104	EMT156	
2980	003336	074230	EHT1	
2981	003340	074320	EDT1	
2982			EFT1	
2983				
2984				
2985	003342	071752	;ERROR 157	OFFSET MODE NOT RESET BY RTC COMMAND
2986	003344	074104	EMT157	
2987	003346	074230	EHT1	
2988	003350	074320	EDT1	
2989			EFT1	
2990				
2991				
2992	003352	071764	;ERROR 160	RMOF NOT RESET BY RIP COMMAND
			EMT160	



2993	003354	074104	EHT1	
2994	003356	074230	EDT1	
2995	003360	074320	EFT1	
2996				
2997				
2998				
2999	003362	071774	;ERROR 161	RMDA NOT RESET BY RIP COMMAND
3000	003364	074104	EMT161	
3001	003366	074230	EHT1	
3002	003370	074320	EDT1	
3003			EFT1	
3004				
3005				
3006	003372	072006	;ERROR 162	RMDC NOT RESET BY RIP COMMAND
3007	003374	074104	EMT162	
3008	003376	074230	EHT1	
3009	003400	074320	EDT1	
3010			EFT1	
3011				
3012				
3013			;ERROR 163	DATA WAS ECC CORRECTED BUT DOES NOT COMPARE WITH
3014	003402	073700	;	WRITE BUFFER
3015	003404	074166	EMT336	
3016	003406	074264	EHT336	
3017	003410	074354	EDT336	
3018			EFT336	
3019				
3020				
3021	003412	072030	;ERROR 164	OPI SHOULD NOT BE SET
3022	003414	074104	EMT164	
3023	003416	074230	EHT1	
3024	003420	074320	EDT1	
3025			EFT1	
3026				
3027				
3028	003422	072036	;ERROR 165	IVC SHOULD NOT BE SET
3029	003424	074104	EMT165	
3030	003426	074230	EHT1	
3031	003430	074320	EDT1	
3032			EFT1	
3033				
3034				
3035	003432	072044	;ERROR 166	IAE SHOULD NOT BE SET
3036	003434	074104	EMT166	
3037	003436	074230	EHT1	
3038	003440	074320	EDT1	
3039			EFT1	
3040				
3041				
3042	003442	072052	;ERROR 167	NEM SHOULD NOT BE SET
3043	003444	074104	EMT167	
3044	003446	074230	EHT1	
3045	003450	074320	EDT1	
3046			EFT1	
3047				
3048			;ERROR 170	UNUSED

3049	003452	000000		0	
3050	003454	000000		0	
3051	003456	000000		0	
3052	003460	000000		0	
3053					
3054					
3055			;ERROR	171	"ATA" NOT SET DURING RETURN TO CENTERLINE
3056	003462	072070		EMT171	
3057	003464	074104		EHT1	
3058	003466	074230		EDT1	
3059	003470	074320		EFT1	
3060					
3061					
3062			;ERROR	172	"ATA" NOT SET BY OFFSET COMMAND
3063	003472	072100		EMT172	
3064	003474	074104		EHT1	
3065	003476	074230		EDT1	
3066	003500	074320		EFT1	
3067					
3068					
3069			;ERROR	173	RMER2 NOT INITIALIZED BY UNIBUS INIT
3070	003502	072110		EMT173	
3071	003504	074104		EHT1	
3072	003506	074230		EDT1	
3073	003510	074320		EFT1	
3074					
3075					
3076			;ERROR	174	RMER2 NOT INITIALIZED BY CONTROLLER CLEAR
3077	003512	072120		EMT174	
3078	003514	074104		EHT1	
3079	003516	074230		EDT1	
3080	003520	074320		EFT1	
3081					
3082					
3083			;ERROR	175	SELECTED DEVICE IS IN WRITE PROTECT
3084	003522	072132		EMT175	
3085	003524	074104		EHT1	
3086	003526	074230		EDT1	
3087	003530	074320		EFT1	
3088					
3089					
3090			;ERROR	176	CANNOT SET DIAGNOSTIC MODE
3091	003532	072140		EMT176	
3092	003534	074104		EHT1	
3093	003536	074230		EDT1	
3094	003540	074320		EFT1	
3095					
3096					
3097			;ERROR	177	INCORRECT "MOL" STATUS DURING DIAGNOSTIC MODE
3098	003542	072146		EMT177	
3099	003544	074104		EHT1	
3100	003546	074230		EDT1	
3101	003550	074320		EFT1	
3102					
3103					
3104			;ERROR	200	INCORRECT "PIP" STATUS DURING DIAGNOSTIC MODE

3105	003552	072160		EMT200	
3106	003554	074104		EHT1	
3107	003556	074230		EDT1	
3108	003560	074320		EFT1	
3109					
3110					
3111			;ERROR	201	INCORRECT "WRL" STATUS DURING DIAGNOSTIC MODE
3112	003562	072172		EMT201	
3113	003564	074104		EHT1	
3114	003566	074230		EDT1	
3115	003570	074320		EFT1	
3116					
3117					
3118			;ERROR	202	INCORRECT "SKI" STATUS DURING DIAGNOSTIC MODE
3119	003572	072204		EMT202	
3120	003574	074104		EHT1	
3121	003576	074230		EDT1	
3122	003600	074320		EFT1	
3123					
3124					
3125			;ERROR	203	INCORRECT "DVC" STATUS DURING DIAGNOSTIC MODE
3126	003602	072216		EMT203	
3127	003604	074104		EHT1	
3128	003606	074230		EDT1	
3129	003610	074320		EFT1	
3130					
3131					
3132			;ERROR	204	"VV" WAS NOT RESET BY MAINTENANCE UNIT READY
3133	003612	072230		EMT204	
3134	003614	074104		EHT1	
3135	003616	074230		EDT1	
3136	003620	074320		EFT1	
3137					
3138					
3139			;ERROR	205	SELECTED DEVICE HAS A PERSISTENT "SKI" ERROR
3140	003622	072246		EMT205	
3141	003624	074104		EHT1	
3142	003626	074230		EDT1	
3143	003630	074320		EFT1	
3144					
3145					
3146			;ERROR	206	"LBC" DID NOT SET DURING DIAGNOSTIC MODE
3147	003632	072256		EMT206	
3148	003634	074104		EHT1	
3149	003636	074230		EDT1	
3150	003640	074320		EFT1	
3151					
3152					
3153			;ERROR	207	UNEXPECTED LOSS OF "MOL" - MEDIUM IS OFF LINE
3154	003642	072266		EMT207	
3155	003644	074104		EHT1	
3156	003646	074230		EDT1	
3157	003650	074320		EFT1	
3158					
3159					
3160			;ERROR	210	UNEXPECTED LOSS OF VOLUME VALID - "VV" = 0

3161	003652	072300		EMT210	
3162	003654	074104		EHT1	
3163	003656	074230		EDT1	
3164	003660	074320		EFT1	
3165					
3166					
3167			;ERROR	211	UNEXPECTED MECHANICAL MOTION - "PIP" = 1
3168	003662	072306		EMT211	
3169	003664	074104		EHT1	
3170	003666	074230		EDT1	
3171	003670	074320		EFT1	
3172					
3173					
3174			;ERROR	212	UNEXPECTED DEVICE FAULT - "DVC" = 1
3175	003672	072322		EMT212	
3176	003674	074104		EHT1	
3177	003676	074230		EDT1	
3178	003700	074320		EFT1	
3179					
3180					
3181			;ERROR	213	UNEXPECTED SEEK INCOMPLETE ERROR - "SKI" = 1
3182	003702	072336		EMT213	
3183	003704	074104		EHT1	
3184	003706	074230		EDT1	
3185	003710	074320		EFT1	
3186					
3187					
3188			;ERROR	214	DRIVE EXECUTED A RECALIBRATE WITH ERROR SET
3189	003712	072346		EMT214	
3190	003714	074116		EHT2	
3191	003716	074240		EDT2	
3192	003720	074330		EFT2	
3193					
3194					
3195			;ERROR	215	DRIVE DID NOT DETECT "IVC" ERROR DURING RECALIBRATE
3196	003722	072366		EMT215	
3197	003724	074116		EHT2	
3198	003726	074240		EDT2	
3199	003730	074330		EFT2	
3200					
3201					
3202			;ERROR	216	INCORRECT "IVC" STATUS
3203	003732	072400		EMT216	
3204	003734	074104		EHT1	
3205	003736	074230		EDT1	
3206	003740	074320		EFT1	
3207					
3208					
3209			;ERROR	217	INCORRECT "IAE" STATUS
3210	003742	072410		EMT217	
3211	003744	074104		EHT1	
3212	003746	074230		EDT1	
3213	003750	074320		EFT1	
3214					
3215					
3216			;ERROR	220	INCORRECT "WLE" STATUS

3217	003752	072420		EMT220	
3218	003754	074104		EHT1	
3219	003756	074230		EDT1	
3220	003760	074320		EFT1	
3221					
3222					
3223			; ERROR	221	INCORRECT "OPI" STATUS
3224	003762	072430		EMT221	
3225	003764	074104		EHT1	
3226	003766	074230		EDT1	
3227	003770	074320		EFT1	
3228					
3229					
3230			; ERROR	222	RM03 DID NOT DETECT RMR ERROR
3231	003772	072440		EMT222	
3232	003774	074104		EHT1	
3233	003776	074230		EDT1	
3234	004000	074320		EFT1	
3235					
3236					
3237			; ERROR	223	RM03 DID NOT DETECT PARITY ERROR ON MASSBUS CONTROL BUS
3238	004002	072450		EMT223	
3239	004004	074142		EHT223	
3240	004006	074254		EDT223	
3241	004010	074344		EFT223	
3242					
3243					
3244			; ERROR	224	UNUSED
3245	004012	000000		0	
3246	004014	000000		0	
3247	004016	000000		0	
3248	004020	000000		0	
3249					
3250					
3251			; ERROR	225	UNUSED
3252	004022	000000		0	
3253	004024	000000		0	
3254	004026	000000		0	
3255	004030	000000		0	
3256					
3257					
3258			; ERROR	226	UNUSED
3259	004032	000000		0	
3260	004034	000000		0	
3261	004036	000000		0	
3262	004040	000000		0	
3263					
3264					
3265			; ERROR	227	UNUSED
3266	004042	000000		0	
3267	004044	000000		0	
3268	004046	000000		0	
3269	004050	000000		0	
3270					
3271					
3272			; ERROR	230	UNUSED

3273	004052	000000	0	
3274	004054	000000	0	
3275	004056	000000	0	
3276	004060	000000	0	
3277				
3278				
3279				; ERROR 231 UNUSED
3280	004062	000000	0	
3281	004064	000000	0	
3282	004066	000000	0	
3283	004070	000000	0	
3284				
3285				
3286				; ERROR 232 UNUSED
3287	004072	000000	0	
3288	004074	000000	0	
3289	004076	000000	0	
3290	004100	000000	0	
3291				
3292				
3293				; ERROR 233 UNUSED
3294	004102	000000	0	
3295	004104	000000	0	
3296	004106	000000	0	
3297	004110	000000	0	
3298				
3299				
3300				; ERROR 234 UNUSED
3301	004112	000000	0	
3302	004114	000000	0	
3303	004116	000000	0	
3304	004120	000000	0	
3305				
3306				
3307				; ERROR 235 UNUSED
3308	004122	000000	0	
3309	004124	000000	0	
3310	004126	000000	0	
3311	004130	000000	0	
3312				
3313				
3314				; ERROR 236 UNUSED
3315	004132	000000	0	
3316	004134	000000	0	
3317	004136	000000	0	
3318	004140	000000	0	
3319				
3320				
3321				; ERROR 237 UNUSED
3322	004142	000000	0	
3323	004144	000000	0	
3324	004146	000000	0	
3325	004150	000000	0	
3326				
3327				
3328				; ERROR 240 UNUSED

3329	004152	000000	0	
3330	004154	000000	0	
3331	004156	000000	0	
3332	004160	000000	0	
3333				
3334				
3335				; ERROR 241 UNUSED
3336	004162	000000	0	
3337	004164	000000	0	
3338	004166	000000	0	
3339	004170	000000	0	
3340				
3341				
3342				; ERROR 242 UNUSED
3343	004172	000000	0	
3344	004174	000000	0	
3345	004176	000000	0	
3346	004200	000000	0	
3347				
3348				
3349				; ERROR 243 UNUSED
3350	004202	000000	0	
3351	004204	000000	0	
3352	004206	000000	0	
3353	004210	000000	0	
3354				
3355				
3356				; ERROR 244 UNUSED
3357	004212	000000	0	
3358	004214	000000	0	
3359	004216	000000	0	
3360	004220	000000	0	
3361				
3362				
3363				; ERROR 245 UNUSED
3364	004222	000000	0	
3365	004224	000000	0	
3366	004226	000000	0	
3367	004230	000000	0	
3368				
3369				
3370				; ERROR 246 "ATA" NOT RESET BY GO WHEN "ERR" = 0
3371	004232	072524	EMT246	
3372	004234	074104	EHT1	
3373	004236	074230	EDT1	
3374	004240	074320	EFT1	
3375				
3376				
3377				; ERROR 247 "ATA" NOT RESET BY WRITING RMAS
3378	004242	072534	EMT247	
3379	004244	074104	EHT1	
3380	004246	074230	EDT1	
3381	004250	074320	EFT1	
3382				
3383				
3384				; ERROR 250 "ATA" WAS RESET BY GO WHEN "ERR" = 1

3385	004252	072546		EMT250	
3386	004254	074104		EHT1	
3387	004256	074230		EDT1	
3388	004260	074320		EFT1	
3389					
3390					
3391			;ERROR	251	PROGRAM INTERRUPT WAS NOT GENERATED
3392	004262	072562		EMT251	
3393	004264	074116		EHT2	
3394	004266	074240		EDT2	
3395	004270	074330		EFT2	
3396					
3397					
3398			;ERROR	252	PROGRAM INTERRUPT SHOULD NOT HAVE BEEN GENERATED
3399	004272	072570		EMT252	
3400	004274	074116		EHT2	
3401	004276	074240		EDT2	
3402	004300	074330		EFT2	
3403					
3404					
3405			;ERROR	253	OFFSET MODE WAS NOT RESET BY WRITING RMDC
3406	004302	072576		EMT253	
3407	004304	074104		EHT1	
3408	004306	074230		EDT1	
3409	004310	074320		EFT1	
3410					
3411					
3412			;ERROR	254	INCORRECT "ILF" STATUS
3413	004312	072614		EMT254	
3414	004314	074104		EHT1	
3415	004316	074230		EDT1	
3416	004320	074320		EFT1	
3417					
3418					
3419			;ERROR	255	INCORRECT "ATA" STATUS
3420	004322	072624		EMT255	
3421	004324	074104		EHT1	
3422	004326	074230		EDT1	
3423	004330	074320		EFT1	
3424					
3425					
3426			;ERROR	256	INCORRECT "ILR" STATUS
3427	004332	072634		EMT256	
3428	004334	074154		EHT256	
3429	004336	074254		EDT223	
3430	004340	074344		EFT223	
3431					
3432					
3433			;ERROR	257	INVALID IAE STATUS DURING SEARCH COMMAND
3434	004342	072644		EMT257	
3435	004344	074104		EHT1	
3436	004346	074230		EDT1	
3437	004350	074320		EFT1	
3438					
3439					
3440			;ERROR	260	"IVC" WAS NOT DETECTED DURING SEARCH COMMAND



3441	004352	072656		EMT260	
3442	004354	074104		EHT1	
3443	004356	074230		EDT1	
3444	004360	074320		EFT1	
3445					
3446					
3447			;ERROR	261	DRIVE EXECUTED SEARCH WITH ERROR SET
3448	004362	072670		EMT261	
3449	004364	074104		EHT1	
3450	004366	074230		EDT1	
3451	004370	074320		EFT1	
3452					
3453					
3454			;ERROR	262	"LBC" ERROR NOT SET DURING DIAGNOSTIC MODE
3455	004372	072710		EMT262	
3456	004374	074104		EHT1	
3457	004376	074230		EDT1	
3458	004400	074320		EFT1	
3459					
3460					
3461			;ERROR	263	"SKI" ERROR DURING SEARCH COMMAND
3462	004402	072720		EMT263	
3463	004404	074104		EHT1	
3464	004406	074230		EDT1	
3465	004410	074320		EFT1	
3466					
3467					
3468			;ERROR	264	"IVC" ERROR DURING SEARCH - LOST VOLUME VALID
3469	004412	072730		EMT264	
3470	004414	074104		EHT1	
3471	004416	074230		EDT1	
3472	004420	074320		EFT1	
3473					
3474					
3475			;ERROR	265	ERRONEOUS IVC ERROR DURING SEARCH - VOLUME IS VALID
3476	004422	072750		EMT265	
3477	004424	074104		EHT1	
3478	004426	074230		EDT1	
3479	004430	074320		EFT1	
3480					
3481					
3482			;ERROR	266	DEVICE FAULT (DVC) DURING SEARCH
3483	004432	072770		EMT266	
3484	004434	074104		EHT1	
3485	004436	074230		EDT1	
3486	004440	074320		EFT1	
3487					
3488					
3489			;ERROR	267	SKI SHOULD HAVE BEEN SET BECAUSE CYLINDER ADDRESS IS TOO LARGE
3490			:		
3491	004442	073002		EMT267	
3492	004444	074104		EHT1	
3493	004446	074230		EDT1	
3494	004450	074320		EFT1	
3495					
3496					

3497			;ERROR	270	OPI ERROR DURING SEARCH BECAUSE MOL = 0
3498	004452	073020		EMT270	
3499	004454	074104		EHT1	
3500	004456	074230		EDT1	
3501	004460	074320		EFT1	
3502					
3503					
3504			;ERROR	271	OPI ERROR DURING SEARCH BECAUSE ON CYLINDER
3505			;		DIDN'T DROP
3506	004462	073034		EMT271	
3507	004464	074104		EHT1	
3508	004466	074230		EDT1	
3509	004470	074320		EFT1	
3510					
3511					
3512			;ERROR	272	LOST MOL DURING SEARCH, OPI IS NOT SET
3513	004472	073052		EMT272	
3514	004474	074104		EHT1	
3515	004476	074230		EDT1	
3516	004500	074320		EFT1	
3517					
3518					
3519			;ERROR	273	PIP STIL SET AFTER SEARCH
3520	004502	073070		EMT273	
3521	004504	074104		EHT1	
3522	004506	074230		EDT1	
3523	004510	074320		EFT1	
3524					
3525					
3526			;ERROR	274	PARITY ERROR OCCURRED WHILE WRITING REMOTE
3527			;		REGISTERS BUT MXF DID NOT SET
3528	004512	073106		EMT274	
3529	004514	074104		EHT1	
3530	004516	074230		EDT1	
3531	004520	074320		EFT1	
3532					
3533					
3534			;ERROR	275	MXF ERROR - COMPOSITE ERROR OCCURRED BEFORE DATA
3535			;		COMMAND STARTED
3536	004522	073124		EMT275	
3537	004524	074104		EHT1	
3538	004526	074230		EDT1	
3539	004530	074320		EFT1	
3540					
3541					
3542			;ERROR	276	"OPI" ERROR DURING DATA TRANSFER BECAUSE "MOL" WAS
3543			;		ZERO
3544	004532	073136		EMT276	
3545	004534	074104		EHT1	
3546	004536	074230		EDT1	
3547	004540	074320		EFT1	
3548					
3549					
3550			;ERROR	277	"OPI" ERROR DURING DATA TRANSFER BECAUSE 1) ON
3551			;		CYLINDER DIDN'T DROP OR 2) SEARCH TIMED OUT OR
3552			;		3) RUN TIMED OUT

3553	004542	073152	EMT277	
3554	004544	074104	EHT1	
3555	004546	074230	EDT1	
3556	004550	074320	EFT1	
3557				
3558				
3559			;ERROR 300	"IVC" ERROR DURING DATA TRANSFER BECAUSE VOLUME WAS NOT VALID
3560				
3561	004552	073170	EMT300	
3562	004554	074104	EHT1	
3563	004556	074230	EDT1	
3564	004560	074320	EFT1	
3565				
3566				
3567			;ERROR 301	ERRONEOUS "IVC" ERROR DURING DATA TRANSFER - VOLUME IS VALID
3568				
3569	004562	073210	EMT301	
3570	004564	074104	EHT1	
3571	004566	074230	EDT1	
3572	004570	074320	EFT1	
3573				
3574				
3575			;ERROR 302	"ILR" ERROR DURING DATA TRANSFER
3576	004572	073232	EMT302	
3577	004574	074104	EHT1	
3578	004576	074230	EDT1	
3579	004600	074320	EFT1	
3580				
3581				
3582			;ERROR 303	"ILF" ERROR DURING DATA TRANSFER
3583	004602	073244	EMT303	
3584	004604	074104	EHT1	
3585	004606	074230	EDT1	
3586	004610	074320	EFT1	
3587				
3588				
3589			;ERROR 304	"RMR" ERROR DURING DATA TRANSFER
3590	004612	073256	EMT304	
3591	004614	074104	EHT1	
3592	004616	074230	EDT1	
3593	004620	074320	EFT1	
3594				
3595				
3596			;ERROR 305	INCORRECT "IAE" STATUS DURING DATA TRANSFER
3597	004622	073270	EMT305	
3598	004624	074104	EHT1	
3599	004626	074230	EDT1	
3600	004630	074320	EFT1	
3601				
3602				
3603			;ERROR 306	"SKI" ERROR DURING DATA TRANSFER
3604	004632	073302	EMT306	
3605	004634	074104	EHT1	
3606	004636	074230	EDT1	
3607	004640	074320	EFT1	
3608				

3609				
3610			;ERROR	307 DRIVE DID NOT DETECT SKI ERROR DUE TO CYLINDER
3611	004642	073312		EMT307
3612	004644	074104		EHT1
3613	004646	074230		EDT1
3614	004650	074320		EFT1
3615				
3616				
3617			;ERROR	310 DEVICE FAULT DURING DATA TRANSFER
3618	004652	073332		EMT310
3619	004654	074104		EHT1
3620	004656	074230		EDT1
3621	004660	074320		EFT1
3622				
3623				
3624			;ERROR	311 LOSS OF BIT CLOCK DURING DATA TRANSFER
3625	004662	073344		EMT311
3626	004664	074104		EHT1
3627	004666	074230		EDT1
3628	004670	074320		EFT1
3629				
3630				
3631			;ERROR	312 LOSS OF SYSTEM CLOCK DURING DATA TRANSFER
3632	004672	073356		EMT312
3633	004674	074104		EHT1
3634	004676	074230		EDT1
3635	004700	074320		EFT1
3636				
3637				
3638			;ERROR	313 UNSAFE ERROR DURING DATA TRANSFER (DVC = 0)
3639	004702	073370		EMT313
3640	004704	074104		EHT1
3641	004706	074230		EDT1
3642	004710	074320		EFT1
3643				
3644				
3645			;ERROR	314 DRIVE TIMING ERROR DURING DATA TRANSFER
3646	004712	073410		EMT314
3647	004714	074104		EHT1
3648	004716	074230		EDT1
3649	004720	074320		EFT1
3650				
3651				
3652			;ERROR	315 WRITE LOCK ERROR
3653	004722	073422		EMT315
3654	004724	074104		EHT1
3655	004726	074230		EDT1
3656	004730	074320		EFT1
3657				
3658				
3659			;ERROR	316 ERRONEOUS WRITE LOCK ERROR
3660	004732	073434		EMT316
3661	004734	074104		EHT1
3662	004736	074230		EDT1
3663	004740	074320		EFT1
3664				

3665				
3666			;ERROR	317 HEADER CRC ERROR DURING DATA TRANSFER
3667	004742	073446		EMT317
3668	004744	074104		EHT1
3669	004746	074230		EDT1
3670	004750	074320		EFT1
3671				
3672				
3673			;ERROR	320 FORMAT ERROR DURING DATA TRANSFER
3674	004752	073456		EMT320
3675	004754	074104		EHT1
3676	004756	074230		EDT1
3677	004760	074320		EFT1
3678				
3679				
3680			;ERROR	321 HEADER COMPARE ERROR DURING DATA TRANSFER
3681	004762	073466		EMT321
3682	004764	074104		EHT1
3683	004766	074230		EDT1
3684	004770	074320		EFT1
3685				
3686				
3687			;ERROR	322 HEADER ERRORS SHOULD NOT BE SET
3688	004772	073476		EMT322
3689	004774	074104		EHT1
3690	004776	074230		EDT1
3691	005000	074320		EFT1
3692				
3693				
3694			;ERROR	323 DATA CHECK ERROR DURING DATA TRANSFER
3695	005002	073504		EMT323
3696	005004	074104		EHT1
3697	005006	074230		EDT1
3698	005010	074320		EFT1
3699				
3700				
3701			;ERROR	324 CORRECTABLE DATA CHECK ERROR DURING DATA TRANSFER
3702	005012	073514		EMT324
3703	005014	074104		EHT1
3704	005016	074230		EDT1
3705	005020	074320		EFT1
3706				
3707				
3708			;ERROR	325 UNCORRECTABLE DATA CHECK ERROR DURING DATA TRANSFER
3709	005022	073526		EMT325
3710	005024	074104		EHT1
3711	005026	074230		EDT1
3712	005030	074320		EFT1
3713				
3714				
3715			;ERROR	326 DATA PARITY ERROR DURING READ COMMAND
3716	005032	073540		EMT326
3717	005034	074104		EHT1
3718	005036	074230		EDT1
3719	005040	074320		EFT1
3720				

3721				
3722			;ERROR	327 OFFSET MODE NOT RESET BY WRITE COMMAND
3723	005042	073556		EMT327
3724	005044	074104		EHT1
3725	005046	074230		EDT1
3726	005050	074320		EFT1
3727				
3728				
3729			;ERROR	330 DATA PARITY ERROR DURING WRITE COMMAND
3730	005052	073570		EMT330
3731	005054	074104		EHT1
3732	005056	074230		EDT1
3733	005060	074320		EFT1
3734				
3735				
3736			;ERROR	331 WRITE CLOCK FAILURE DURING WRITE COMMAND
3737	005062	073600		EMT331
3738	005064	074104		EHT1
3739	005066	074230		EDT1
3740	005070	074320		EFT1
3741				
3742				
3743			;ERROR	332 DATA LATE ERROR DURING DATA TRANSFER
3744	005072	073612		EMT332
3745	005074	074104		EHT1
3746	005076	074230		EDT1
3747	005100	074320		EFT1
3748				
3749				
3750			;ERROR	333 PIP STIL SET AFTER DATA TRANSFER - SKI = 0
3751	005102	073624		EMT333
3752	005104	074104		EHT1
3753	005106	074230		EDT1
3754	005110	074320		EFT1
3755				
3756				
3757			;ERROR	334 LOST MOL DURING DATA TRANSFER - OPI = 0
3758	005112	073642		EMT334
3759	005114	074104		EHT1
3760	005116	074230		EDT1
3761	005120	074320		EFT1
3762				
3763				
3764			;ERROR	335 LOST VOLUME VALID DURING DATA TRANSFER - IVC = 0
3765	005122	073660		EMT335
3766	005124	074104		EHT1
3767	005126	074230		EDT1
3768	005130	074320		EFT1
3769				
3770				
3771			;ERROR	336 DATA READ DOES NOT COMPARE WITH DATA WRITTEN
3772	005132	073700		EMT336
3773	005134	074166		EHT336
3774	005136	074264		EDT336
3775	005140	074354		EFT336
3776				

3777					
3778					
3779	005142	073710	;ERROR	337	WRITE CHECK ERROR NOT DETECTED
3780	005144	074200		EMT337	
3781	005146	074274		EHT337	
3782	005150	074364		EDT337	
3783				EFT337	
3784					
3785			;ERROR	340	WRITE CHECK ERROR AT UNEXPECTED ADDRESS
3786	005152	073720		EMT340	
3787	005154	074166		EHT336	
3788	005156	074264		EDT336	
3789	005160	074354		EFT336	
3790					
3791					
3792			;ERROR	341	INCORRECT DATA DURING WRITE CHECK ERROR
3793	005162	073732		EMT341	
3794	005164	074166		EHT336	
3795	005166	074264		EDT336	
3796	005170	074354		EFT336	
3797					
3798					
3799			;ERROR	342	"IVC" ERROR NOT DETECTED DURING DATA TRANSFER
3800	005172	073740		EMT342	
3801	005174	074104		EHT1	
3802	005176	074230		EDT1	
3803	005200	074320		EFT1	
3804					
3805					
3806			;ERROR	343	"FER" NOT DETECTED DURING DATA TRANSFER
3807	005202	073752		EMT343	
3808	005204	074104		EHT1	
3809	005206	074230		EDT1	
3810	005210	074320		EFT1	
3811					
3812					
3813			;ERROR	344	"HCE" NOT DETECTED DURING DATA TRANSFER
3814	005212	073764		EMT344	
3815	005214	074212		EHT344	
3816	005216	074304		EDT344	
3817	005220	074374		EFT344	
3818					
3819					
3820			;ERROR	345	"BSE" NOT DETECTED DURING DATA TRANSFER
3821	005222	073776		EMT345	
3822	005224	074104		EHT1	
3823	005226	074230		EDT1	
3824	005230	074320		EFT1	
3825					
3826					
3827			;ERROR	346	HEADER ERROR WAS DETECTED W/ HCI SET
3828	005232	074006		EMT346	
3829	005234	074104		EHT1	
3830	005236	074230		EDT1	
3831	005240	074320		EFT1	
3832					

```

3833
3834 ;ERROR 347 DATA TRANSFER NOT ABORTED W/ COMP ERROR SET
3835 005242 074022 EMT347
3836 005244 074104 EHT1
3837 005246 074230 EDT1
3838 005250 074320 EFT1
3839
3840
3841

```

```

3842 ;ERROR 350 LOST VOLUME VALID DURING SEARCH - "IVC" = 0
3843 005252 074034 EMT350
3844 005254 074104 EHT1
3845 005256 074230 EDT1
3846 005260 074320 EFT1
3847
3848

```

```

3849 ;ERROR 351 "ATA" DID NOT SET DURING SEARCH
3850 005262 074052 EMT351
3851 005264 074104 EHT1
3852 005266 074230 EDT1
3853 005270 074320 EFT1
3854
3855

```

```

3856 ;ERROR 352 PROGRAM TIMEOUT WHILE TESTING RMLA
3857 005272 074062 EMT352
3858 005274 000000 0
3859 005276 000000 0
3860 005300 000000 0
3861
3862

```

```

3863 ;ERROR 353 LOOK AHEAD TEST FAILS
3864 005302 074066 EMT353
3865 005304 074224 EHT353
3866 005306 074316 EDT353
3867 005310 074404 EFT353
3868
3869

```

```

3870 ;ERROR 354 BSE SHOULD NOT BE SET
3871 005312 074076 EMT354
3872 005314 074104 EHT1
3873 005316 074230 EDT1
3874 005320 074320 EFT1
3875
3876

```

```

3877 ;PUT ERROR TABLE HERE
3878 ;SBTTL ERROR TABLE USAGE
3879 ;THE ERROR TABLE ABOVE CONSISTS OF FOUR WORD ENTRIES FOR EACH ERROR
3880 ;NUMBER, I.E.,
3881 :
3882 :           EMT - ERROR MESSAGE TABLE ADDRESS
3883 :           EHT - ERROR HEADER TABLE ADDRESS
3884 :           EDT - ERROR DATA TABLE ADDRESS
3885 :           EFT - ERROR FORMAT TABLE ADDRESS
3886 :
3887 ;THE EMT ENTRY IS THE ADDRESS OF THE TABLE OF ERROR MESSAGE STRINGS
3888 ;FOR THE PARTICULAR ERROR. EACH ERROR MESSAGE TABLE LISTS THE ADDRESS

```



3889  
3890  
3891  
3892  
3893  
3894  
3895  
3896  
3897  
3898  
3899  
3900  
3901  
3902  
3903  
3904  
3905  
3906  
3907

: OF ONE OR MORE ERROR MESSAGE STRINGS WHICH ARE TO BE FORMATTED AND  
: TYPED BY THE ERROR TYPE SUBROUTINE. IF THE EMT ENTRY IS ZERO, THERE IS  
: NO MESSAGE TO BE TYPED FOR THE ERROR.

: SIMILARLY, THE EHT, EDT, AND EFT ENTRIES ARE ADDRESSES OF TABLES  
: OF HEADER, DATA AND FORMAT INFORMATION FOR A GIVEN ERROR. EACH ENTRY  
: IN THE ERROR HEADER TABLE MAY OR MAY NOT HAVE AN ASSOCIATED LINE OF  
: DATA. HOWEVER, EACH DATA LINE MUST HAVE AN ASSOCIATED FORMAT AND  
: HEADER. THAT IS, A HEADER LINE MAY BE PRINTED WITHOUT ANY DATA,  
: BUT A DATA LINE IS NOT PRINTED WITHOUT A HEADER, AND EACH DATA LINE  
: MUST ALSO HAVE A FORMAT.

: IN SUMMARY,

: EACH NONZERO ENTRY IS THE ADDRESS OF A TABLE,  
: EACH TABLE IS A LIST OF ADDRESSES WHICH DEFINES THE LOCATIONS  
: OF MESSAGE STRINGS, HEADERS, DATA OR FORMAT.

```

3908 .SBTTL START OF PROGRAM
3909
3910
3911 005322 START:
3912
3913 ;CLEAR AND SETUP FOR TEST EXECUTION
3914 005322 000240 NOP
3915 005324 000005 RESET ; INITIALIZE THE SYSTEM
3916 005326 013746 000300 MOV PR6, -(SP) ; PUT NEW PS ON STACK
3917 005332 012746 005340 MOV #64$, -(SP) ; PUT NEW PC ON STACK
3918 005336 000002 RTI ; POP NEW PC AND PS
3919 005340
3920
3921 .SBTTL INITIALIZE THE COMMON TAGS
3922 ;;CLEAR THE COMMON TAGS ($CMTAG) AREA
3923 005340 012706 001114 MOV #SCMTAG, R6 ;; FIRST LOCATION TO BE CLEARED
3924 005344 005026 CLR (R6)+ ;; CLEAR MEMORY LOCATION
3925 005346 022706 001154 CMP #SWR, R6 ;; DONE?
3926 005352 001374 BNE .-6 ;; LOOP BACK IF NO
3927 005354 012706 001100 MOV #STACK, SP ;; SETUP THE STACK POINTER
3928 ;; INITIALIZE A FEW VECTORS
3929 005360 012737 063202 000020 MOV #SCOPE, @IOTVEC ;; IOT VECTOR FOR SCOPE ROUTINE
3930 005366 012737 000340 000022 MOV #340, @IOTVEC+2 ;; LEVEL 7
3931 005374 012737 063704 000030 MOV #ERROR, @EMTVEC ;; EMT VECTOR FOR ERROR ROUTINE
3932 005402 012737 000340 000032 MOV #340, @EMTVEC+2 ;; LEVEL 7
3933 005410 012737 065444 000034 MOV #TRAP, @TRAPVEC ;; TRAP VECTOR FOR TRAP CALLS
3934 005416 012737 000340 000036 MOV #340, @TRAPVEC+2 ;; LEVEL 7
3935 005424 012737 065552 000024 MOV #SPWRON, @PWRVEC ;; POWER FAILURE VECTOR
3936 005432 012737 000340 000026 MOV #340, @PWRVEC+2 ;; LEVEL 7
3937 005440 013737 042240 042232 MOV SENDCT, SEOPCT ;; SETUP END-OF-PROGRAM COUNTER
3938 005446 005037 001206 CLR $TIMES ;; INITIALIZE NUMBER OF ITERATIONS
3939 005452 005037 001210 CLR $ESCAPE ;; CLEAR THE ESCAPE ON ERROR ADDRESS
3940 005456 112737 000001 001131 MOVB #1, $ERMAX ;; ALLOW ONE ERROR PER TEST
3941 005464 012737 005464 001122 MOV #., $LPADR ;; INITIALIZE THE LOOP ADDRESS FOR SCOPE
3942 005472 012737 005472 001124 MOV #., $LPERR ;; SETUP THE ERROR LOOP ADDRESS
3943 ;; SIZE FOR A HARDWARE SWITCH REGISTER, IF NOT FOUND OR IT IS
3944 ;; EQUAL TO A "-1" SETUP FOR A SOFTWARE SWITCH REGISTER.
3945 005500 013746 000004 MOV @ERRVEC, -(SP) ;; SAVE ERROR VECTOR
3946 005504 012737 005540 000004 MOV #65$, @ERRVEC ;; SET UP ERROR VECTOR
3947 005512 012737 177570 001154 MOV #DSWR, SWR ;; SETUP FOR A HARDWARE SWICH REGISTER
3948 005520 012737 177570 001156 MOV #DDISP, DISPLAY ;; AND A HARDWARE DISPLAY REGISTER
3949 005526 022777 177777 173420 CMP #-1, @SWR ;; TRY TO REFERENCE HARDWARE SWR
3950 005534 001012 BNE 67$ ;; BRANCH IF NO TIMEOUT TRAP OCCURRED
3951 ;; AND THE HARDWARE SWR IS NOT = -1
3952 005536 000403 BR 66$ ;; BRANCH IF NO TIMEOUT
3953 005540 012716 005546 65$: MOV #66$, (SP) ;; SET UP FOR TRAP RETURN
3954 005544 000002 RTI
3955 005546 012737 000176 001154 66$: MOV #SWREG, SWR ;; POINT TO SOFTWARE SWR
3956 005554 012737 000174 001156 MOV #DISPREG, DISPLAY
3957 005562 012637 000004 67$: MOV (SP)+, @ERRVEC ;; RESTORE ERROR VECTOR
3958
3959 005566 005037 001230 CLR $PASS ;; CLEAR PASS COUNT
3960 005572 132737 000200 001243 BITB #APTSIZE, $ENVM ;; TEST USER SIZE UNDER APT
3961 005600 001403 BEQ 68$ ;; YES, USE NON-APT SWITCH
3962 005602 012737 001244 001154 MOV #SSWREG, SWR ;; NO, USE APT SWITCH REGISTER
3963 005610 68$:

```

```

3964 .SBTTL TYPE PROGRAM NAME
3965 ;;TYPE THE NAME OF THE PROGRAM IF FIRST PASS
3966 005610 005227 177777 INC #1 ;;FIRST TIME?
3967 005614 001056 BNE 69$ ;;BRANCH IF NO
3968 005616 022737 042374 000042 CMP #SENDAD,2#42 ;;ACT-11?
3969 005624 001452 BEQ 69$ ;;BRANCH IF YES
3970 005626 104401 005674 TYPE 70$ ;;TYPE ASCIZ STRING
3971 .SBTTL GET VALUE FOR SOFTWARE SWITCH REGISTER
3972 005632 005737 000042 TST 2#42 ;;ARE WE RUNNING UNDER XXDP/ACT?
3973 005636 001012 BNE 71$ ;;BRANCH IF YES
3974 005640 123727 001242 000001 CMPB $ENV,#1 ;;ARE WE RUNNING UNDER APT?
3975 005646 001406 BEQ 71$ ;;BRANCH IF YES
3976 005650 023727 001154 000176 CMP SWR,#SWREG ;;SOFTWARE SWITCH REG SELECTED?
3977 005656 001005 BNE 72$ ;;BRANCH IF NO
3978 005660 104407 GTSWR ;;GET SOFT-SWR SETTINGS
3979 005662 000403 BR 72$
3980 005664 112737 000001 001150 71$: MOVB #1,$AUTOB ;;SET AUTO-MODE INDICATOR
3981 005672 000427 72$: BR 69$ ;;GET OVER THE ASCIZ
3982 005672 000427
3983 ;;70$: .ASCIZ <CRLF>@CZRMCB - RMO3/RMO2 FUNCTIONAL TEST, PART 1 @<CRLF>
3984 005752 69$:
3985
3986
3987 ;FIND OUT IF PROGRAM IS RUNNING IN STANDALONE MODE
3988 005752 122737 000077 000041 CMPB #77,2#41 ;;RMO3 IS A XXDP MEDIM ?
3989 005760 001003 BNE 5$ ;;BRANCH IF NOT
3990 005762 104401 067143 TYPE ,XDPMG ;;TYPE THE MESSAGE CHANGE PACK
3991 005766 000000 HALT ;;HALT
3992 005770 5$:
3993 005770 005737 000042 TST 42 ;;IS LOC 42 ZERO ??
3994 005774 001003 BNE 10$ ;;NO - NOT IN STANDALONE
3995 005776 105737 001242 TSTB $ENV ;;IS APT ENVIRONMENT ZERO ??
3996 006002 001451 BEQ STANDALONE ;;YES - PROGRAM IN STANDALONE
3997 006004 10$:
3998
3999 ;PROGRAM NOT RUNNING IN STANDALONE - SEE IF SIZING IS ALLOWED
4000 006004 132737 000200 001243 XSIZ: BITB #BIT7,$ENVM ;;SIZING ALLOWED ??
4001 006012 001043 BNE 20$ ;;NO
4002 ; MOV #377,$DEVN ;;YES - SET DEVICE MAP FOR ALL DEVICES
4003 006014 005037 001300 CLR $DEVN ;;CLEAR THE DEVICE MAP
4004 006020 005001 CLR R1 ;;START FROM DRIVE 0
4005 006022 012704 000001 MOV #BIT0,R4 ;;BIT MAP
4006 006026 013700 001276 MOV $BASE,R0 ;;LOAD THE BASE ADDRESS
4007 006032 012760 000040 000010 15$: MOV #CLR,$MCS2(R0) ;;MASS BUS CLEAR
4008 006040 010160 000010 MOV R1,$MCS2(R0) ;;LOAD THE DRIVE ADDRESS
4009 006044 016003 000010 MOV $MCS2(R0),R3 ;;READ DRIVE STATUS TO SEEE NED BIT
4010 006050 032703 010000 BIT #NED,R3 ;;NED BIT SET ?
4011 006054 001010 BNE 16$ ;;BRANCH IF SO
4012 006056 016003 000000 MOV $MCS1(R0),R3 ;;CHECK THE DVA BIT
4013 006062 032703 004000 BIT #DVA,R3 ;;DRIVE
4014 006066 001403 BEQ 16$ ;;BRANCH IF DRIVE NOT AVAILABLE
4015 006070 050437 001300 BIS R4,$DEVN ;;SET THE BIT MAP
4016 006074 000405 BR 17$ ;;BRANCH NOT TYPE NONE EXIST MESSG
4017 006076 16$:
4018 006076 104401 067230 TYPE ,NOTEX ;;MESSAGE NOT EXIST DRIVE
4019 006102 010146 MOV R1,-(SP) ;;DRIVE NUMBER

```

4020	006104	104403	
4021	006106	006	
4022	006107	000	
4023	006110	005201	
4024	006112	006304	
4025	006114	022701	000007
4026	006120	103344	
4027	006122		
4028			
4029			
4030	006122	000137	006754

	TYPOS		
	.BYTE	6	
	.BYTE	0	
17\$:	INC	R1	: INCREMENT THE DRIVE ADDRESS
	ASL	R4	: SET UP BIT MAP ADDRESS
	CMP	#7, R1	: ALL DRIVES ARE CHECKED ?
	BHIS	15\$	: BRANCH IF NOT
20\$:			
	;GO TO COMMON START CODE		
	JMP	CMNSTART	

```

4031 006126          STANDALONE:
4032 006126 004737 064114      JSR      PC,STKINT      ;INITIALIZE CONSOLE
4033
4034          ;SEE IF THIS IS THE FIRST START AFTER PROGRAM WAS LOADED
4035 006132 005327 000001      DEC      #1            ;FIRST START ??
4036 006136 100024          BPL      10$          ;YES !!
4037
4038
4039          ;SEE IF THE USER WANTS TO KEEP SAME DEVICES FOR TESTING
4040 006140 104401 066452      $$:      TYPE      ,CNSLOO      ;MAINTAIN PREVIOUS PARAMETERS??
4041 006144 104411          RDCHR          ;GET RESPONSE
4042 006146 012637 001176      MOV      (SP)+,$TMP1    ;ECHO RESPONSE
4043 006152 104401 001176      TYPE      $TMP1
4044 006156 123727 001176 000131  CMPB     $TMP1,#'Y      ;YES RESPONSE??
4045 006164 001002          BNE      6$          ;NO!!
4046 006166 000137 007106      JMP      READY        ;KEEP PREVIOUS PARAMETERS
4047 006172 123727 001176 000116 6$:      CMPB     $TMP1,#'N      ;NO RESPONSE??
4048 006200 001420          BEQ      20$          ;GET NEW PARAMETERS
4049 006202 104401 066315      TYPE      ,QSTMRK     ;NOT YES OR NO, TYPE "?"
4050 006206 000754          BR       5$          ;RETRY
4051 006210          10$:
4052
4053          ;SEE IF OPERATOR WANTS HELP FILE
4054 006210 104401 066317      TYPE      ,HELPOST     ;WANT HELP ??
4055 006214 104411          RDCHR          ;GET RESPONSE
4056 006216 012637 001176      MOV      (SP)+,$TMP1    ;SAVE AND ECHO RESPONSE
4057 006222 104401 001176      TYPE      $TMP1
4058 006226 123727 001176 000131  CMPB     $TMP1,#'Y      ;WAS IT A YES RESPONSE ??
4059 006234 001002          BNE      20$          ;NO - DONT TYPE HELP
4060 006236 104401 106126      TYPE      ,HELP        ;YES - TYPE HELP TEXT
4061 006242          20$:
4062
4063          ;SEE IF USER WANTS TO CHANGE RMO3 UNIBUS ADDRESS
4064 006242 104401 066353      TYPE      ,UBUSQST     ;WANT TO CHANGE ADDRESS ??
4065 006246 104411          RDCHR          ;GET RESPONSE
4066 006250 012637 001176      MOV      (SP)+,$TMP1    ;SAVE AND ECHO RESPONSE
4067 006254 104401 001176      TYPE      , $TMP1
4068 006260 104411          RDCHR          ;WAIT ONE MORE CH, OR ANYTHING
4069 006262 005726          TST      (SP)+        ;CLEAR THE STACK
4070 006264 123727 001176 000131  CMPB     $TMP1,#'Y      ;WAS IT A YES RESPONSE ??
4071 006272 001137          BNE      90$          ;NO !!
4072 006274          30$:
4073
4074          ;DIALOGUE TO CHANGE THE UNIBUS ADDRESS, AND INTERRUPT VECTOR
4075 006274 104401 066511      TYPE      ,CNSLO1     ;TYPE CURRENT BUS ADDRESS
4076 006300 013746 001276      MOV      $BASE,-(SP)   ;SAVE $BASE FOR TYPEOUT
4077 006304 104402          TYPOC          ;GO TYPE--OCTAL ASCII(ALL DIGITS)
4078 006306 104401 066306      TYPE      ,CLSPRN
4079 006312 104413          RDOCT
4080 006314 012637 001176      MOV      (SP)+,$TMP1   ;GET NEW BUS ADDRESS
4081 006320 001412          BEQ      50$          ;CARRIAGE RETURN??
4082 006322 022737 160000 001176  CMP      #160000,$TMP1 ;YES-SKIP TO NEXT ENTRY
4083 006330 101403          BLOS     40$          ;BASE ADDRESS IN I/O PAGE??
4084 006332 104401 066536      TYPE      ,CNSLO2     ;YES
4085 006336 000756          BR       30$          ;TYPE WARNING MESSAGE
4086 006340 013737 001176 001276 40$:      MOV      $TMP1,$BASE   ;RETRY
;STORE NEW BUS ADDRESS

```

4087	006346	113737	001272	001176	50\$:	MOVB	\$VECT1,\$TMP1	;TYPE CURRENT VECTOR ADDRESS
4088	006354	105037	001177			CLRB	\$TMP1+1	
4089	006360	104401	066617			TYPE	,CNSLO3	
4090	006364	013746	001176			MOV	\$TMP1,-(SP)	::SAVE \$TMP1 FOR TYPEOUT
4091	006370	104403				TYPOS		::GO TYPE--OCTAL ASCII
4092	006372	003				.BYTE	3	::TYPE 3 DIGIT(S)
4093	006373	000				.BYTE	0	::SUPPRESS LEADING ZEROS
4094	006374	104401	066306			TYPE	,CLSPRN	
4095	006400	104413				RDOCT		;GET NEW VECTOR ADDRESS
4096	006402	012637	001176			MOV	(SP)+,\$TMP1	;CARRIAGE RETURN?
4097	006406	001412				BEQ	70\$	;YES-SKIP TO NEXT ENTRY
4098	006410	022737	001000	001176		CMP	#1000,\$TMP1	;VECTOR ADDRESS < 1000??
4099	006416	101003				BHI	60\$	;YES!!
4100	006420	104401	066647			TYPE	,CNSLO4	;TYPE WARNING MESSAGE
4101	006424	000750				BR	50\$	;RETRY
4102	006426	113737	001176	001272	60\$:	MOVB	\$TMP1,\$VECT1	;STORE NEW VECTOR ADDRESS
4103	006434	113737	001273	001176	70\$:	MOVB	\$VECT1+1,\$TMP1	;TYPE CURRENT PRIORITY
4104	006442	006237	001176			ASR	\$TMP1	
4105	006446	006237	001176			ASR	\$TMP1	
4106	006452	006237	001176			ASR	\$TMP1	
4107	006456	006237	001176			ASR	\$TMP1	
4108	006462	006237	001176			ASR	\$TMP1	
4109	006466	105037	001177			CLRB	\$TMP1+1	
4110	006472	104401	066723			TYPE	,CNSLO5	
4111	006476	013746	001176			MOV	\$TMP1,-(SP)	::SAVE \$TMP1 FOR TYPEOUT
4112	006502	104403				TYPOS		::GO TYPE--OCTAL ASCII
4113	006504	001				.BYTE	1	::TYPE 1 DIGIT(S)
4114	006505	000				.BYTE	0	::SUPPRESS LEADING ZEROS
4115	006506	104401	066306			TYPE	,CLSPRN	
4116	006512	104413				RDOCT		;GET NEW PRIORITY
4117	006514	012637	001176			MOV	(SP)+,\$TMP1	;CARRIAGE RETURN??
4118	006520	001424				BEQ	90\$	;YES-SKIP TO NEXT ENTRY
4119	006522	023727	001176	000007		CMP	\$TMP1,#7	;LEGAL PRIORITY??
4120	006530	002403				BLT	80\$	;YES!!
4121	006532	104401	066757			TYPE	,CNSLO6	;TYPE WARNING MESSAGE
4122	006536	000736				BR	70\$	;RETRY
4123	006540				80\$:			;STORE NEW PRIORITY
4124	006540	006337	001176			ASL	\$TMP1	
4125	006544	006337	001176			ASL	\$TMP1	
4126	006550	006337	001176			ASL	\$TMP1	
4127	006554	006337	001176			ASL	\$TMP1	
4128	006560	006337	001176			ASL	\$TMP1	
4129	006564	113737	001176	001273		MOVB	\$TMP1,\$VECT1+1	
4130	006572				90\$:			
4131								
4132								
4133	006572	005037	001300			CLR	\$DEVN	;CLEAR DEVICE MAP
4134	006576	104401	067004			TYPE	,CNSLO7	;TYPE INPUT INSTRUCTIONS
4135	006602	104401	066311			TYPE	,PROMPT	;TYPE PROMPTING CHARACTER
4136	006606	104411				RDCHR		;GET RESPONSE
4137	006610	012637	001176			MOV	(SP)+,\$TMP1	;ECHO RESPONSE
4138	006614	104401	001176			TYPE	\$TMP1	
4139	006620	023727	001176	000101		CMP	\$TMP1,#'A	;TEST ALL DRIVES??
4140	006626	001021				BNE	110\$	;NO
4141	006630	000137	006004			JMP	XSIZ	;ALTO SIZE
4142	006634	012737	000377	001300		MOV	#377,\$DEVN	;TEST ALL DEVICES

;DIALOGUE TO INPUT DEVICE NUMBERS



```

4165 006754 CMNSTART:
4166
4167 ;ASSEMBLE TEST QUE FROM DEVICE MAP
4168 006754 013700 001300 MOV $DEVN,RO ;RO = DEVICE MAP
4169 006760 012701 001450 MOV #TSTQUE+2,R1 ;R1 = ADDRESS OF FIRST ENTRY IN QUE
4170 006764 010137 001446 MOV R1,TSTQUE ;INITIALIZE ENTRY POINTER
4171 006770 012702 000001 MOV #1,R2 ;R2 = DEVICE POINTER
4172 006774 005003 CLR R3 ;R3 = DEVICE NUMBER
4173 006776 030200 10S: BIT R2,RO ;IS THIS DEVICE IN MAP ??
4174 007000 001406 BEQ 20$ ;NO !!
4175 007002 010311 MOV R3,(R1) ;YES - ENTER DEVICE NUMBER IN QUE
4176 007004 116361 067354 000001 MOV#B ATNTBL(R3),1(R1) ;ENTER ATTENTION BIT IN QUE
4177 007012 062701 000002 ADD #2,R1 ;ADVANCE ENTRY POINTER
4178 007016 006302 20S: ASL R2 ;ADVANCE DEVICE POINTER
4179 007020 105702 TSTB R2 ;DONE ALL DEVICES ??
4180 007022 001402 BEQ 25$ ;YES
4181 007024 005203 INC R3 ;ADVANCE DEVICE NUMBER
4182 007026 000763 BR 10$ ;ENTER NEXT DEVICE
4183 007030 005011 25S: CLR (R1) ;TERMINATE TEST QUE
4184
4185 ;SIZE FOR CLOCK
4186 007032 004737 044704 JSR PC,SIZCLK ;SEE IF CLOCK PRESENT
4187 007036 000403 BR 40$ ;YES - CLOCK IS PRESENT
4188 007040 104000 30S: ERROR ;NO CLOCK
4189 007042 000000 HALT
4190 007044 000775 BR 30$
4191 007046
4192 40S:
4193 .SBTTL GET VALUE FOR SOFTWARE SWITCH REGISTER
4194 007046 005737 000042 TST #42 ;ARE WE RUNNING UNDER XXDP/ACT?
4195 007052 001012 BNE 64$ ;BRANCH IF YES
4196 007054 123727 001242 000001 CMP#B $ENV,#1 ;ARE WE RUNNING UNDER APT?
4197 007062 001406 BEQ 64$ ;BRANCH IF YES
4198 007064 023727 001154 000176 CMP SWR,#SWREG ;SOFTWARE SWITCH REG SELECTED?
4199 007072 001005 BNE 65$ ;BRANCH IF NO
4200 007074 104407 GTSWR ;GET SOFT-SWR SETTINGS
4201 007076 000403 BR 65$
4202 007100 112737 000001 001150 64$: MOV#B #1,$AUTOB ;;SET AUTO-MODE INDICATOR
4203 007106 000240 65$:
4204 007110 004737 064114 READY: NOP ;READY TO START TEST
4205 007114 013746 000300 JSR PC,$TKINT ;INITIALIZE TTY
4206 007120 012746 007126 MOV PR6,-(SP) ;PUT NEW PS ON STACK
4207 007124 000002 MOV #64$,-(SP) ;PUT NEW PC ON STACK
4208 007126 RTI ;POP NEW PC AND PS
4209 007126 117737 172314 001234 64$: MOV#B #TSTQUE,$UNIT ;LOAD UNIT NUMBER
4210 007134 005037 001472 CLR MEDENB ;CLEAR MEDIA ENABLE

```



```

4211 ;*****
4212 ;*TEST 1 CONTROLLER ACCESS TEST
4213 ;*****
4214 †ST1:
4215 007140 000240 NOP ;START OF TEST
4216 007142 012737 007156 001122 MOV #1$, $LPADR
4217 007150 012737 007156 001124 MOV #1$, $LPERR
4218 007156 1S:
4219 007156 012706 001100 MOV #STACK, SP ;INITIALIZE STACK POINTER
4220 007162 013700 001276 MOV $BASE, RO ;RO=UNIBUS ADDRESS
4221 007166 013701 001446 MOV TSTQUE, R1 ;(R1) = DEVICE BEING TESTED
4222 007172 012737 000001 001226 MOV #1, $TESTN ;;SET TEST NUMBER IN APT MAIL BOX
4223 007200 005001 CLR R1
4224 007202 013746 000004 MOV ERRVEC, -(SP) ;;PUSH ERRVEC ON STACK
4225 007206 013746 000006 MOV ERRVEC+2, -(SP) ;;PUSH ERRVEC+2 ON STACK
4226 007212 012737 007304 000004 MOV #3$, ERRVEC
4227 007220 012737 000300 000006 MOV #PR6, ERRVEC+2
4228
4229 007226 110160 000001 MOVB R1, RMCS1+1(RO) ;MOVE HI BYTE TO RMCS1
4230 007232 010160 000002 MOV R1, RMWC(RO) ;MOVE WORD COUNT REGISTER
4231 007236 016002 000002 MOV RMWC(RO), R2
4232 007242 010160 000004 MOV R1, RMA(RO) ;MOVE BUS ADDRESS REGISTER
4233 007246 016002 000004 MOV RMA(RO), R2
4234 007252 010160 000010 MOV R1, RMCS2(RO) ;MOVE CONTROL STATUS REGISTER
4235 007256 016002 000010 MOV RMCS2(RO), R2
4236 007262 010160 000022 MOV R1, RMD(RO) ;MOVE DATA BUFFER
4237 007266 016002 000022 MOV RMD(RO), R2
4238 007272 012637 000006 MOV (SP)+, ERRVEC+2 ;;POP STACK INTO ERRVEC+2
4239 007276 012637 000004 MOV (SP)+, ERRVEC ;;POP STACK INTO ERRVEC
4240 007302 000415 BR 7$ ;NO BUS TIMEOUT OCCURRED
4241
4242 007304 022626 3S: CMP (SP)+, (SP)+ ;ADJUST STACK
4243 007306 012637 000006 MOV (SP)+, ERRVEC+2 ;;POP STACK INTO ERRVEC+2
4244 007312 012637 000004 MOV (SP)+, ERRVEC ;;POP STACK INTO ERRVEC
4245 007316 104110 ERROR 110 ;CANNOT ACCESS MASSBUS CONTROLLER
4246 007320 005737 000042 TST 42 ;STAND ALONE MODE??
4247 007324 001002 BNE 5$ ;NO!!
4248 007326 000137 005322 JMP START ;YES-GO GET $BASE
4249 007332 000137 042204 5$: JMP SEOP ;GO TO END OF PASS HANDLER
4250 007336 7$:
4251
4252 ;*****
4253 ;*TEST 2 DEVICE AVAILABLE TEST
4254 ;*****
4255 †ST2:
4256 007336 000004 SCOPE ;SCOPE CALL
4257 007336 000240 NOP ;START OF TEST
4258 007340 000240 MOV #STACK, SP ;INITIALIZE STACK POINTER
4259 007342 012706 001100 MOV $BASE, RO ;RO=UNIBUS ADDRESS
4260 007346 013700 001276 MOV TSTQUE, R1 ;(R1) = DEVICE BEING TESTED
4261 007352 013701 001446 MOV #2, $TESTN ;;SET TEST NUMBER IN APT MAIL BOX
4262 007356 012737 000002 001226
4263
4264 007364 004737 053360 JSR PC, CNTCLR
4265 007370 000404 BR 2$ ;GO TO 2$ IF NO ERROR
4266 007372 000240 NOP ;RETURN HERE IF ERROR

```

F08

CZRMCOB0 RM03/2 FCTNL TST 1  
CZRMCOB.P11 23-NOV-77 12:14

MACY11 30(1046) 23-NOV-77 12:25 PAGE 96  
T2 DEVICE AVAILABLE TEST

SEQ 0096

```

4267 007374 104000          ERROR          ;ERROR NUMBER DEFINED BY SUB
4268 007376 000137 007516 2$: JMP 7$          ;GO TO 7$ IF ERROR WAS FOUND
4269 007402
4270 007402 013746 000004   MOV ERRVEC, -(SP)  ;; PUSH ERRVEC ON STACK
4271 007406 013746 000006   MOV ERRVEC+2, -(SP) ;; PUSH ERRVEC+2 ON STACK
4272 007412 012737 007502 000004   MOV #5$, ERRVEC
4273 007420 013737 000300 000006   MOV PR6, ERRVEC+2
4274
4275 007426 016037 000000 001176   MOV RMCS1(RO), $TMP1 ;GET DVA STATUS
4276 007434 016037 000010 001174   MOV RMCS2(RO), $TMP0 ;GET NED STATUS
4277 007442 012637 000006   MOV (SP)+, ERRVEC+2  ;; POP STACK INTO ERRVEC+2
4278 007446 012637 000004   MOV (SP)+, ERRVEC    ;; POP STACK INTO ERRVEC
4279 007452 032737 010000 001174   BIT #NED, $TMP0      ;NONEXISTENT DEVICE??
4280 007460 001402          BEQ 3$            ;NO!!
4281 007462 104111          ERROR 111        ;NONEXISTENT DEVICE
4282 007464 000414          BR 7$
4283 007466 032737 004000 001176 3$: BIT #DVA, $TMP1    ;DEVICE AVAILABLE??
4284 007474 001012          BNE 9$          ;YES!!
4285 007476 104112          ERROR 112        ;DEVICE NOT AVAILABLE
4286 007500 000406          BR 7$
4287
4288 007502 022626          5$: CMP (SP)+, (SP)+ ;ADJUST STACK
4289 007504 012637 000006   MOV (SP)+, ERRVEC+2 ;POP STACK INTO ERRVEC+2
4290 007510 012637 000004   MOV (SP)+, ERRVEC   ;POP STACK INTO ERRVEC
4291 007514 104113          ERROR 113        ;BUS TIMEOUT (04 TRAP)
4292 007516 000137 042150 7$: JMP $EOSP
4293
4294 007522          9$:
4295
4296          ;*****
4297          ;*TEST 3          DRIVE TYPE TEST
4298          ;*****
4299          ;*****
4300          ;*TST3:
4301 007522 000004          SCOPE          ;SCOPE CALL
4302 007524 000240          NOP            ;START OF TEST
4303 007526 012706 001100   MOV #STACK, SP   ;INITIALIZE STACK POINTER
4304 007532 013700 001276   MOV $BASE, RO    ;RO=UNIBUS ADDRESS
4305 007536 013701 001446   MOV TSTQUE, R1   ; (R1) = DEVICE BEING TESTED
4306 007542 012737 000003 001226   MOV #3, $TESTN   ;SET TEST NUMBER IN APT MAIL BOX
4307
4308 007550 004737 053360   JSR PC, CNTCLR
4309 007554 000404          BR 2$          ;GO TO 2$ IF NO ERROR
4310 007556 000240          NOP            ;RETURN HERE IF ERROR
4311 007560 104000          ERROR          ;ERROR NUMBER DEFINED BY SUB
4312 007562 000137 007700 2$: JMP 4$          ;GO TO 4$ IF ERROR WAS FOUND
4313 007566
4314 007566 112737 000026 001504   MOV #RMDT, GETINX ;SETUP GET INDEX TABLE
4315 007574 112737 000200 001505   MOV #200, GETINX+1
4316 007602 012737 007704 001354   MOV #5$, RMDTI    ;RMDT INPUT BUFFER = 5$
4317 007610 004737 044216   JSR PC, GET      ;GO GET DRIVE TYPE
4318 007614 000402          BR 3$          ;GO TO 3$ IF NO ERROR
4319 007616 000240          NOP            ;RETURN HERE IF ERROR
4320 007620 104000          ERROR          ;ERROR NUMBER SPECIFIED BY GET
4321 007622 022737 020024 001354 3$: CMP #SNGPRT, RMDTI ;SINGLE PORT RM03??
4322 007630 001425          BEQ 5$          ;YES!!

```

```

4323 007632 022737 024024 001354      CMP      #DULPRT,RMDTI      ;DUAL PORT RM03??
4324 007640 001421                    BEQ      $$                ;YES!!
4325 007642 022737 020025 001354      CMP      #SNGPRT!BIT0,RMDTI ;SINGLE PROT RM02 ?
4326 007650 001415                    BEQ      $$                ;YES
4327 007652 022737 024025 001354      CMP      #DULPRT!BIT0,RMDTI ;DUAL PORT RM02 ?
4328 007660 001411                    BEQ      $$                ;YES
4329 007662 012737 020024 001176      MOV      #SNGPRT,$TMP1
4330 007670 012737 024024 001200      MOV      #DULPRT,$TMP2
4331 007676 104114                    ERROR    114                ;NOT AN RM03
4332 007700 000137 042150      4$:      JMP      $E0SP            ;GO TO SUBPASS HANDLER.
4333
4334 007704      5$:
4335      ;*****
4336      ;*TEST 4          UNIBUS INITIALIZE TEST
4337      ;*****
4338      ;*****
4339      ;ST4:
4340 007704 000004                    SCOPE      ;SCOPE CALL
4341 007706 000240                    NOP        ;START OF TEST
4342 007710 012737 000001 001206      MOV      #1,$TIMES        ;LOAD ITERATION COUNT
4343 007716 012737 007732 001122      MOV      #1,$SLPADR
4344 007724 012737 007732 001124      MOV      #1,$SLPERR
4345 007732      1$:
4346 007732 012706 001100      MOV      #STACK,SP        ;INITIALIZE STACK POINTER
4347 007736 013700 001276      MOV      $BASE,R0         ;R0=UNIBUS ADDRESS
4348 007742 013701 001446      MOV      TSTQUE,R1        ;(R1) = DEVICE BEING TESTED
4349 007746 012737 000004 001226      MOV      #4,$TESTN        ;;SET TEST NUMBER IN APT MAIL BOX
4350
4351
4352 007754 004737 053360      JSR      PC,CNTCLR        ;GO TO 10$ IF NO ERROR
4353 007760 000404      BR      10$              ;RETURN HERE IF ERROR
4354 007762 000240                    NOP        ;ERROR NUMBER DEFINED BY SUB
4355 007764 104000                    ERROR
4356 007766 000137 010570      JMP      220$            ;GO TO 220$ IF ERROR WAS FOUND
4357 007772 012702 000101      10$:      MOV      #65,R2           ;SET OR AND RESET IR
4358 007776 012737 000000 001420      MOV      #0,RMDOB0        ;WRITE ZEROS IN DATA SILO
4359 010004 112737 000022 001533      MOV      #RMOB,PUTINX     ;SETUP REGISTER INDEX
4360 010012 112737 000200 001534      MOV      #200,PUTINX+1
4361 010020      20$:
4362 010020 004737 044466      JSR      PC,PUT          ;GO WRITE REGISTERS VIA PUT SUB
4363 010024 000404      BR      30$            ;GO TO 30$ IF NO ERROR
4364 010026 000240                    NOP        ;RETURN HERE IF ERROR
4365 010030 104000                    ERROR     ;ERROR DEFINED BY PUT SUB
4366 010032 000137 010570      JMP      220$            ;GO TO 220$ IF ERROR WAS FOUND
4367 010036 005302      30$:      DEC      R2              ;DECREMENT COUNT
4368 010040 001367      BNE     20$            ;WRITE SILO AGAIN
4369 010042 012737 177777 001402      MOV      #-1,RMBA0        ;RMBA=ALL ONES
4370 010050 012737 177777 001412      MOV      #-1,RMER10       ;RMER1=ALL ONES
4371 010056 012737 177777 001440      MOV      #-1,RMER20       ;RMER2 = ALL ONES
4372 010064 012737 040001 001422      MOV      #DMD!DBEN,RMMR10 ;SET DIAGNOSTIC MODE
4373 010072 012737 003577 001376      MOV      #003577,RMCS10
4374 010100 012737 021037 001406      MOV      #021037,RMCS20
4375
4376 010106 012702 001533      MOV      #PUTINX,R2       ;R2 = ADDRESS OF INDEX TABLE
4377 010112 112722 000004      MOV      #RMBA,(R2)+
4378 010116 112722 000014      MOV      #RMER1,(R2)+

```

4379	010122	112722	000042			MOVB	#RMR2,(R2)+	
4380	010126	112722	000024			MOVB	#RMR1,(R2)+	
4381	010132	112722	000000			MOVB	#RMCS1,(R2)+	
4382	010136	112722	000010			MOVB	#RMCS2,(R2)+	
4383	010142	112722	000200			MOVB	#200,(R2)+	
4384	010146	004737	044466			JSR	PC,PUT	:GO WRITE REGISTERS VIA PUT SUB
4385	010152	000404				BR	40\$	;GO TO 40\$ IF NO ERROR
4386	010154	000240				NOP		:RETURN HERE IF ERROR
4387	010156	104000				ERROR		:ERROR DEFINED BY PUT SUB
4388	010160	000137	010570			JMP	220\$	;GO TO 220\$ IF ERROR WAS FOUND
4389	010164	000005		40\$:		RESET		:UNIBUS INITIALIZE
4390	010166	004737	064114			JSR	PC,STKINT	:INITIALIZE CONSOLE
4391	010172	111160	000010			MOVB	(R1),RMCS2(R0)	:SELECT DEVICE
4392	010176	004737	044132			JSR	PC,GETSTS	:GO SET UP FOR STATUS FETCH
4393	010202	004737	044216			JSR	PC,GET	:GO READ REGISTERS VIA GET SUB
4394	010206	000403				BR	50\$	;GO TO 50\$ IF NO ERROR
4395	010210	000240				NOP		:RETURN HERE IF ERROR
4396	010212	104000				ERROR		:ERROR DEFINED BY GET SUB
4397	010214	000565				BR	220\$	:SKIP REMAINDER OF TEST
4398								
4399	010216	013737	001326	001142	50\$:	MOV	RMCS1I,\$BDDAT	:VERIFY RMCS1
4400	010224	042737	100000	001142		BIC	#SC,\$BDDAT	:IGNORE SPECIAL CONDITION
4401	010232	012737	004200	001140		MOV	#DVA,RDY,\$GDDAT	:EXPECT DVA & RDY
4402	010240	023737	001140	001142		CMP	\$GDDAT,\$BDDAT	:COMPARE EXPECTED, RECEIVED
4403	010246	001401				BEQ	60\$	:BRANCH IF EQUAL
4404	010250	104115				ERROR	115	:RMCS1 NOT INITIALIZED
4405								
4406	010252	005037	001140		60\$:	CLR	\$GDDAT	:VERIFY RMBA IS ZERO
4407	010256	013737	001332	001142		MOV	RMBAI,\$BDDAT	
4408	010264	001401				BEQ	70\$	:BRANCH IF ZERO
4409	010266	104116				ERROR	116	:RMBA NOT INITIALIZED
4410								
4411	010270	013737	001336	001142	70\$:	MOV	RMCS2I,\$BDDAT	:VERIFY RMCS2
4412	010276	005046				CLR	-(SP)	:EXPECT IR & UNIT NUMBER
4413	010300	111116				MOVB	(R1),(SP)	
4414	010302	052716	000100			BIS	#IR,(SP)	
4415	010306	012637	001140			MOV	(SP)+,\$GDDAT	
4416	010312	023737	001140	001142		CMP	\$GDDAT,\$BDDAT	:COMPARE EXPECTED & RECEIVED
4417	010320	001401				BEQ	90\$	:BRANCH IF EQUAL
4418	010322	104117				ERROR	117	:RMCS2 NOT INITIALIZED
4419								
4420	010324	005037	001140		90\$:	CLR	\$GDDAT	:VERIFY RMR1
4421	010330	013737	001342	001142		MOV	RMR1I,\$BDDAT	
4422	010336	042737	040000	001142		BIC	#UNS,\$BDDAT	:IGNORE UNSAFE
4423	010344	001401				BEQ	110\$	:BRANCH IF ZERO
4424	010346	104120				ERROR	120	:RMR1 NOT INITIALIZED
4425								
4426	010350	013737	001344	001142	110\$:	MOV	RMAI,\$BDDAT	:VERIFY RMAI
4427	010356	005002				CLR	R2	:CLEAR ALL BUT THIS
4428	010360	116102	000001			MOVB	1(R1),R2	:DRIVES ATTENTION BIT
4429	010364	000302				SWAB	R2	
4430	010366	005102				COM	R2	
4431	010370	000240				NOP		
4432	010372	040237	001142			BIC	R2,\$BDDAT	
4433	010376	001401				BEQ	130\$	:BRANCH IF ITS 0
4434	010400	104121				ERROR	121	:RMAI NOT INITIALIZED

```

4435
4436 010402 013737 001352 001142 130$: MOV RMMR1I,$BDDAT ;VERIFY RMMR
4437 010410 042737 000046 001142 BIC #WC!LS!LST,$BDDAT ;IGNORE WORD CLOCK, SCT, TRK
4438 010416 012737 000010 001140 MOV #MWD,$GDDAT ;EXPECT WRITE DATA BIT
4439 010424 023737 001140 001142 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED AND RECEIVED
4440 010432 001401 BEQ 170$ ;BRANCH IF 0
4441 010434 104122 ERROR 122 ;RMMR NOT INITIALIZED
4442
4443 010436 005037 001140 170$: CLR $GDDAT ;EXPECT ZEROS
4444 010442 013737 001374 001142 MOV RMEC2I,$BDDAT ;VERIFY RMEC2=0
4445 010450 001401 BEQ 190$
4446 010452 104124 ERROR 124 ;RMEC2 NOT INITIALIZED
4447
4448 010454 013737 001366 001142 190$: MOV RMMR2I,$BDDAT ;VERIFY RMMR2
4449 010462 042737 140000 001142 BIC #RQA!RQB,$BDDAT
4450 010470 012737 011777 001140 MOV #TST!1777,$GDDAT ;EXPECT TEST,TAG BIT ON
4451 010476 023737 001140 001142 CMP $GDDAT,$BDDAT
4452 010504 001401 BEQ 210$
4453 010506 104125 ERROR 125 ;RMR2 NOT INITIALIZED
4454
4455 010510 005037 001140 210$: CLR $GDDAT ;EXPECT ALL ZEROS
4456 010514 013737 001370 001142 MOV RMR2I,$BDDAT ;VERIFY RMR2
4457 010522 042737 040200 001142 BIC #SKI!DVC,$BDDAT ;IGNORE DEVICE ERRORS
4458 010530 001401 BEQ 215$ ;BRANCH IF OTHER BITS 0
4459 010532 104173 ERROR 173
4460 010534 013737 001340 001142 215$: MOV RMDSI,$BDDAT ;CHECK DRIVE STATUS REGISTER
4461 010542 042737 177177 001142 BIC #TC<DPR!DRY>,$BDDAT
4462 010550 012737 000600 001140 MOV #DPR!DRY,$GDDAT ;EXPECTED STATUS
4463 010556 023737 001142 001140 CMP $BDDAT,$GDDAT ;COMPARE EXPECTED & RECEIVED STATUS
4464 010564 001401 BEQ 220$ ;DRIVE STATUS IS OK
4465 010566 104123 ERROR 123 ;REPORT ERROR IN DRIVE STATUS
4466 010570 220$:
4467
4468
4469
4470 ;*****
4471 ;*TEST 5 CONTROLLER CLEAR TEST
4472 ;*****
4473 †TST5:
4474 010570 000004 SCOPE ;SCOPE CALL
4475 010572 000240 NOP ;START OF TEST
4476 010574 012706 001100 MOV #STACK,SP ;INITIALIZE STACK POINTER
4477 010600 013700 001276 MOV $BASE,R0 ;R0=UNIBUS ADDRESS
4478 010604 013701 001446 MOV TSTQUE,R1 ;(R1) = DEVICE BEING TESTED
4479 010610 012737 000005 001226 MOV #5,$TESTN ;;SET TEST NUMBER IN APT MAIL BOX
4480
4481 010616 004737 053360 JSR PC,CNTCLR
4482 010622 000404 BR 10$ ;GO TO 10$ IF NO ERROR
4483 010624 000240 NOP ;RETURN HERE IF ERROR
4484 010626 104000 ERROR ;ERROR NUMBER DEFINED BY SUB
4485 010630 000137 011126 JMP 80$ ;GO TO 80$ IF ERROR WAS FOUND
4486 010634 012702 000101 10$: MOV #65,R2
4487 010640 012737 000000 001420 MOV #0,RMDB0 ;WRITE ZEROS IN DATA SILO
4488 010646 112737 000022 001533 MOVB #RMDB,PUTINX ;SETUP REGISTER INDEX TABLE
4489 010654 112737 000200 001534 MOVB #200,PUTINX+1
4490 010662

```

JOB

CZRMCO RM03/2 FCTNL TST 1  
CZRMCO.P11 23-NOV-77 12:14

MACY11 30(1046) 23-NOV-77 12:25 PAGE 100  
TS CONTROLLER CLEAR TEST

SEQ 0100

```

4491 010662 004737 044466 JSR PC.PUT ;GO WRITE REGISTERS VIA PUT SUB
4492 010666 000404 BR 30$ ;GO TO 30$ IF NO ERROR
4493 010670 000240 NOP ;RETURN HERE IF ERROR
4494 010672 104000 ERROR ;ERROR DEFINED BY PUT SUB
4495 010674 000137 011126 JMP 80$ ;GO TO 80$ IF ERROR WAS FOUND
4496 010700 005302 30$: DEC R2 ;DECREMENT COUNT
4497 010702 001367 BNE 20$ ;AND WRITE SILO AGAIN IF NOT DONE
4498 010704 012737 177777 001402 MOV #-1,RMBA0
4499 010712 012737 177777 001412 MOV #-1,RMER10
4500 010720 012737 177777 001440 MOV #-1,RMER20
4501 010726 012737 040001 001422 MOV #DMD:DBEN,RMMR10
4502 010734 012737 003577 001376 MOV #003577,RMCS10
4503 010742 012737 021037 001406 MOV #021037,RMCS20
4504 010750 012702 001533 MOV #PUTINX,R2 ;R2 = ADDRESS OF INDEX TABLE
4505 010754 112722 000004 MOVB #RMBR,(R2)+
4506 010760 112722 000014 MOVB #RMER1,(R2)+
4507 010764 112722 000042 MOVB #RMER2,(R2)+
4508 010770 112722 000024 MOVB #RMMR1,(R2)+
4509 010774 112722 000000 MOVB #RMCS1,(R2)+
4510 011000 112722 000010 MOVB #RMCS2,(R2)+
4511 011004 112722 000200 MOVB #200,(R2)+
4512 011010 004737 044466 JSR PC.PUT ;GO WRITE REGISTERS VIA PUT SUB
4513 011014 000404 BR 40$ ;GO TO 40$ IF NO ERROR
4514 011016 000240 NOP ;RETURN HERE IF ERROR
4515 011020 104000 ERROR ;ERROR DEFINED BY PUT SUB
4516 011022 000430 BR 70$
4517
4518 011024 40$:
4519 011024 004737 053360 JSR PC.CNTCLR
4520 011030 000404 BR 50$ ;GO TO 50$ IF NO ERROR
4521 011032 000240 NOP ;RETURN HERE IF ERROR
4522 011034 104000 ERROR ;ERROR NUMBER DEFINED BY SUB
4523 011036 000137 011126 JMP 80$ ;GO TO 80$ IF ERROR WAS FOUND
4524 011042 004737 044132 50$: JSR PC.GETSTS
4525 011046 004737 044216 JSR PC.GET ;GO READ REGISTERS VIA GET SUB
4526 011052 000404 BR 60$ ;GO TO 60$ IF NO ERROR
4527 011054 000240 NOP ;RETURN HERE IF ERROR
4528 011056 104000 ERROR ;ERROR DEFINED BY GET SUB
4529 011060 000137 011126 JMP 80$ ;GO TO 80$ IF ERROR WAS FOUND
4530 60$:
4531 011064 004737 053476 JSR PC.CLRSTS ;GO VERIFY CONTROLLER CLEAR OPERATION
4532 011070 000405 BR 70$ ;GO TO 70$ IF NO ERROR
4533 011072 000240 NOP ;RETURN HERE IF ERROR
4534 011074 104000 ERROR ;ERROR # DEFINED BY CLRSTS SUBROUTINE
4535 011076 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
4536 011100 000137 011126 JMP 80$ ;GO TO 80$ IF ERROR WAS FOUND
4537 70$:
4538 011104 012737 000000 001376 MOV #NOP,RMCS10 ;CHANGE FUNCTION CODE FOR ERROR CHECK
4539 011112 004737 046044 JSR PC,SECERR ;GO CHECK FOR SECONDARY ERRORS
4540 011116 000403 BR 80$ ;GO TO 80$ IF NO ERROR
4541 011120 000240 NOP ;RETURN HERE IF ERROR
4542 011122 104000 ERROR ;ERROR # DEFINED BY SECERR SUBROUTINE
4543 011124 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
4544 80$:
4545
4546 ;*****

```

;\*TEST 6 ERROR CLEAR TEST

\*\*\*\*\*  
†ST6:

```

4547
4548
4549
4550 011126
4551 011126 000004
4552 011130 000240
4553 011132 012706 001100
4554 011136 013700 001276
4555 011142 013701 001446
4556 011146 012737 000006 001226
4557
4558 011154 004737 053360
4559 011160 000404
4560 011162 000240
4561 011164 104000
4562 011166 000137 011332
4563 011172
4564 011172 112737 000000 001533
4565 011200 112737 000200 001534
4566 011206 012737 040000 001376
4567 011214 004737 044466
4568 011220 000403
4569 011222 000240
4570 011224 104000
4571 011226 000441
4572 011230 112737 000000 001504
4573 011236 112737 000010 001505
4574 011244 112737 000200 001506
4575 011252 004737 044216
4576 011256 000403
4577 011260 000240
4578 011262 104000
4579 011264 000422
4580 011266 013737 001326 001142
4581 011274 005037 001140
4582 011300 042737 117777 001142
4583 011306 001401
4584 011310 104137
4585
4586 011312 013737 001336 001142
4587 011320 042737 104377 001142
4588 011326 001401
4589 011330 104140
4590
4591 011332
4592
4593
4594
4595
4596
4597 011332
4598 011332 000004
4599 011334 000240
4600 011336 012706 001100
4601 011342 013700 001276
4602 011346 013701 001446

```

```

; SCOPE CALL
; START OF TEST
; INITIALIZE STACK POINTER
; RO=UNIBUS ADDRESS
; (R1) = DEVICE BEING TESTED
; SET TEST NUMBER IN APT MAIL BOX

; GO TO 10$ IF NO ERROR
; RETURN HERE IF ERROR
; ERROR NUMBER DEFINED BY SUB
; GO TO 50$ IF ERROR WAS FOUND

; SETUP PUT INDEX TABLE
; WRITE TERMINATOR
; RMCS1 OUTPUT BUFFER = TRE
; CALL PUT SUBROUTINE
; GO TO 20$ IF NO ERROR
; RETURN HERE TO REPORT AN ERROR
; ERROR NUMBER DEFINED BY PUT SUB
; SKIP REST OF TEST

; GO READ REGISTERS VIA GET SUB
; GO TO 30$ IF NO ERROR
; RETURN HERE IF ERROR
; ERROR DEFINED BY GET SUB
; SKIP REST OF TEST
; CHECK TRE & MCPE
; EXPECT 0'S
; BRANCH IF TRE & MCPE = 0
; MCPE, OR TRE NOT CLEARED

; CHECK RMCS2
; C<WCE!UPE!NED!PGE!MXF!MDPE>, $BDDAT
; RMCS2 NOT CLEARED

```

\*\*\*\*\*  
;\*TEST 7 DRIVE STATUS TEST

\*\*\*\*\*  
†ST7:

```

; SCOPE CALL
; START OF TEST
; INITIALIZE STACK POINTER
; RO=UNIBUS ADDRESS
; (R1) = DEVICE BEING TESTED

```

```

4603 011352 012737 000007 001226 MOV #7,STESTN ;;SET TEST NUMBER IN APT MAIL BOX
4604
4605 011360 004737 053360 JSR PC,CNTCLR
4606 011364 000404 BR 10$ ;GO TO 10$ IF NO ERROR
4607 011366 000240 NOP ;RETURN HERE IF ERROR
4608 011370 104000 ERROR ;ERROR NUMBER DEFINED BY SUB
4609 011372 000137 011656 JMP 100$ ;GO TO 100$ IF ERROR WAS FOUND
4610 011376 10$:
4611 011376 004737 044132 JSR PC,GETSTS
4612 011402 004737 044216 JSR PC,GET ;GO READ REGISTERS VIA GET SUB
4613 011406 000403 BR 20$ ;GO TO 20$ IF NO ERROR
4614 011410 000240 NOP ;RETURN HERE IF ERROR
4615 011412 104000 ERROR ;ERROR DEFINED BY GET SUB
4616 011414 000520 BR 100$ ;SKIP REST OF TEST
4617 011416 032737 010000 001340 20$: BIT #MOL,RMDSI ;MEDIUM ON LINE??
4618 011424 001016 BNE 30$ ;YES!!
4619 011426 013737 001340 001140 MOV RMDSI,$GDDAT ;EXPECTED STATUS
4620 011434 042737 162000 001140 BIC #ATA!ERR!PIP!LBT,$GDDAT
4621 011442 052737 010000 001140 BIS #MOL,$GDDAT
4622 011450 013737 001340 001142 MOV RMDSI,$BDDAT ;RECEIVED STATUS
4623 011456 104151 ERROR 151 ;MOL STATUS INCORRECT
4624 011460 000462 BR 80$
4625
4626 011462 032737 000200 001370 30$: BIT #DVC,RMER2I ;IS THERE A DEVICE CHECK??
4627 011470 001406 BEQ 50$
4628 011472 013737 001370 001142 MOV RMER2I,$BDDAT ;RECEIVED STATUS
4629 011500 005037 001140 CLR $GDDAT ;EXPECTED STATUS
4630 011504 104152 ERROR 152 ;DRIVE FAULT
4631
4632 011506 032737 000200 001370 50$: BIT #DVC,RMER2I ;WAS DVC SET??
4633 011514 001414 BEQ 60$ ;NO!!
4634 011516 032737 040000 001342 BIT #UNS,RMER1I ;IS UNS SET??
4635 011524 001022 BNE 70$ ;YES!!
4636 011526 013737 001342 001142 MOV RMER1I,$BDDAT ;RECEIVED STATUS
4637 011534 012737 040000 001140 MOV #UNS,$GDDAT ;EXPECTED STATUS
4638 011542 104153 ERROR 153 ;DVC IS SET BUT UNS IS NOT
4639 011544 000412 BR 70$
4640 011546 032737 040000 001342 60$: BIT #UNS,RMER1I ;IS UNS SET??
4641 011554 001406 BEQ 70$ ;NO!!
4642 011556 013737 001342 001142 MOV RMER1I,$BDDAT ;RECEIVED STATUS
4643 011564 005037 001140 CLR $GDDAT ;EXPECTED STATUS
4644 011570 104154 ERROR 154 ;DVC IS NOT SET BUT UNS IS
4645 011572 032737 004000 001340 70$: BIT #WRL,RMDSI ;IS WRITE PROTECT ON??
4646 011600 001414 BEQ 90$ ;NO!!
4647 011602 013737 001340 001140 MOV RMDSI,$GDDAT ;EXPECTED STATUS
4648 011610 042737 166076 001140 BIC #!C!MOL!PGM!DPR!DRY!VV!OM,$GDDAT
4649 011616 013737 001340 001142 MOV RMDSI,$BDDAT ;RECEIVED STATUS
4650 011624 104175 ERROR 175 ;SELECTED DEVICE IN WRITE PROTECT
4651 011626 000137 042150 80$: JMP $EOSP ;SKIP REST OF TEST
4652
4653 011632 032737 040000 001370 90$: BIT #SKI,RMER2I ;IS SKI SET??
4654 011640 001406 BEQ 100$ ;NO!!
4655 011642 013737 001370 001142 MOV RMER2I,$BDDAT ;RECEIVED STATUS
4656 011650 005037 001140 CLR $GDDAT ;EXPECTED STATUS
4657 011654 104205 ERROR 205 ;PERSISTENT SEEK INCOMPLETE ERROR
4658 011656 100$:

```



```
4659
4660
4661
4662
4663 011656
4664 011656 000004
4665 011660 000240
4666 011662 012706 001100
4667 011666 013700 001276
4668 011672 013701 001446
4669 011676 012737 000010 001226
4670
4671 011704 004737 053360
4672 011710 000404
4673 011712 000240
4674 011714 104000
4675 011716 000137 012036
4676 011722
4677 011722 112737 000000 001533
4678 011730 112737 000200 001534
4679 011736 012737 000023 001376
4680 011744 004737 044466
4681 011750 000403
4682 011752 000240
4683 011754 104000
4684 011756 000427
4685 011760 004737 044132
4686 011764 004737 045026
4687 011770 004737 044216
4688 011774 000403
4689 011776 000240
4690 012000 104000
4691 012002 000415
4692 012004
4693 012004 004737 045212
4694 012010 000404
4695 012012 000240
4696 012014 104000
4697 012016 004736
4698 012020 000406
4699 012022
4700 012022 004737 046044
4701 012026 000403
4702 012030 000240
4703 012032 104000
4704 012034 004736
4705 012036
4706
4707
4708
4709
4710 012036
4711 012036 000004
4712 012040 000240
4713 012042 012706 001100
4714 012046 013700 001276

*****
;TEST 10 PRIMARY/SECONDARY ERROR TEST
*****
↑ST10:
SCOPE ;SCOPE CALL
NOP ;START OF TEST
MOV #STACK_SP ;INITIALIZE STACK POINTER
MOV $BASE,R0 ;R0=UNIBUS ADDRESS
MOV TSTQUE,R1 ;(R1) = DEVICE BEING TESTED
MOV #10,$TESTN ;;SET TEST NUMBER IN APT MAIL BOX

JSR PC,CNTCLR
BR 1$ ;GO TO 1$ IF NO ERROR
NOP ;RETURN HERE IF ERROR
ERROR ;ERROR NUMBER DEFINED BY SUB
JMP 5$ ;GO TO 5$ IF ERROR WAS FOUND

1$:
MOVB #RMCSI,PUTINX ;SETUP PUT INDEX TABLE
MOVB #200,PUTINX+1 ;WRITE TERMINATOR
MOV #PAKACK!GO,RMCSI0 ;RMCSI OUTPUT BUFFER = PAKACK!GO
JSR PC,PUT ;CALL PUT SUBROUTINE
BR 2$ ;GO TO 2$ IF NO ERROR
NOP ;RETURN HERE TO REPORT AN ERROR
ERROR ;ERROR NUMBER DEFINED BY PUT SUB
BR 5$ ;SKIP REST OF TEST IF ERROR

2$:
JSR PC,GETSTS ;SETUP FOR STATUS FETCH
JSR PC,TIMOUT ;WAIT FOR COMPLETION OF NOP
JSR PC,GET ;GO READ REGISTERS VIA GET SUB
BR 3$ ;GO TO 3$ IF NO ERROR
NOP ;RETURN HERE IF ERROR
ERROR ;ERROR DEFINED BY GET SUB
BR 5$ ;SKIP REST OF TEST IF ERROR

3$:
JSR PC,PRIERR ;GO CHECK FOR PRIMARY ERRORS
BR 4$ ;GO TO 4$ IF NO ERROR
NOP ;RETURN HERE IF ERROR
ERROR ;ERROR # DEFINED BY PRIERR SUBROUTINE
JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
BR 5$ ;SKIP REST OF TEST IF ERROR

4$:
JSR PC,SECERR ;GO CHECK FOR SECONDARY ERRORS
BR 5$ ;GO TO 5$ IF NO ERROR
NOP ;RETURN HERE IF ERROR
ERROR ;ERROR # DEFINED BY SECERR SUBROUTINE
JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS

5$:
*****
;TEST 11 DIAGNOSTIC MODE TEST
*****
↑ST11:
SCOPE ;SCOPE CALL
NOP ;START OF TEST
MOV #STACK_SP ;INITIALIZE STACK POINTER
MOV $BASE,R0 ;R0=UNIBUS ADDRESS
```

4715	012052	013701	001446			MOV	TSTQUE,R1	;(R1) = DEVICE BEING TESTED
4716	012056	012737	000011	001226		MOV	#11,\$TESTN	;;SET TEST NUMBER IN APT MAIL BOX
4717								
4718	012064	004737	053360			JSR	PC,CNTCLR	
4719	012070	000404				BR	1\$	;GO TO 1\$ IF NO ERROR
4720	012072	000240				NOP		;RETURN HERE IF ERROR
4721	012074	104000				ERROR		;ERROR NUMBER DEFINED BY SUB
4722	012076	000137	013110			JMP	22\$	;GO TO 22\$ IF ERROR WAS FOUND
4723	012102				1\$:			
4724	012102	112737	000024	001533		MOVB	#RMMR1,PUTINX	;SETUP PUT INDEX TABLE
4725	012110	112737	000200	001534		MOVB	#200,PUTINX+1	;WRITE TERMINATOR BYTE
4726	012116	012737	000001	001422		MOV	#DMD,RMMR10	;RMMR1=DMD
4727	012124	004737	044466			JSR	PC,PUT	;GO WRITE RMMR1 VIA SUB
4728	012130	000404				BR	2\$	;GO TO 2\$ IF NO ERROR
4729	012132	000240				NOP		;RETURN HERE IF ERROR
4730	012134	104000				ERROR		;ERROR NUMBER DEFINED BY PUT SUB
4731	012136	000137	013110			JMP	22\$	;GO TO 22\$ IF ERROR WAS FOUND
4732	012142	004737	044132		2\$:	JSR	PC,GETSTS	;SETUP FOR STATUS FETCH
4733	012146	004737	044216			JSR	PC,GET	;GO READ REGISTERS VIA GET SUB
4734	012152	000404				BR	3\$	;GO TO 3\$ IF NO ERROR
4735	012154	000240				NOP		;RETURN HERE IF ERROR
4736	012156	104000				ERROR		;ERROR DEFINED BY GET SUB
4737	012160	000137	013110			JMP	22\$	;GO TO 22\$ IF ERROR WAS FOUND
4738	012164	032737	000001	001352	3\$:	BIT	#DMD,RMMR1I	;IS DIAGNOSTIC MODE SET??
4739	012172	001011				BNE	5\$	;YES!!
4740	012174	012737	000001	001140		MOV	#DMD,\$GDDAT	;EXPECTED STATUS
4741	012202	013737	001352	001142		MOV	RMMR1I,\$BDDAT	;RECEIVED STATUS
4742	012210	104176				ERROR	176	;COULD NOT SET DIAGNOSTIC MODE
4743	012212	000137	013110			JMP	22\$	;SKIP REST OF TEST IF DMD = 0
4744	012216	032737	010000	001340	5\$:	BIT	#MOL,RMDSI	;IS "MOL" = 0 ??
4745	012224	001411				BEQ	6\$	;YES!!
4746	012226	013737	001340	001142		MOV	RMDSI,\$BDDAT	;SETUP BAD DATA FOR TYPEOUT
4747	012234	042737	167777	001142		BIC	#CMOL,\$BDDAT	
4748	012242	005037	001140			CLR	\$GDDAT	;SETUP GOOD DATA FOR TYPEOUT
4749	012246	104177				ERROR	177	;INCORRECT MOL STATUS
4750	012250	032737	020000	001340	6\$:	BIT	#PIP,RMDSI	;IS PIP SET??
4751	012256	001012				BNE	7\$	;YES!!
4752	012260	013737	001340	001142		MOV	RMDSI,\$BDDAT	;SETUP BAD DATA FOR TYPEOUT
4753	012266	042737	157777	001142		BIC	#CPIP,\$BDDAT	
4754	012274	012737	020000	001140		MOV	#PIP,\$GDDAT	;EXPECTED PIP SET
4755	012302	104200				ERROR	200	;INCORRECT PIP STATUS
4756	012304	032737	004000	001340	7\$:	BIT	#WRL,RMDSI	;IS WRITE LOCK OFF??
4757	012312	001411				BEQ	8\$	;YES!!
4758	012314	013737	001340	001142		MOV	RMDSI,\$BDDAT	;SETUP BAD DATA FOR TYPEOUT
4759	012322	042737	173777	001142		BIC	#CWRL,\$BDDAT	
4760	012330	005037	001140			CLR	\$GDDAT	;EXPECTED WRL = 0
4761	012334	104201				ERROR	201	;INCORRECT WRL STATUS
4762	012336	032737	040000	001370	8\$:	BIT	#SKI,RMER2I	;IS SKI = 0
4763	012344	001411				BEQ	9\$	;YES!!
4764	012346	013737	001370	001142		MOV	RMER2I,\$BDDAT	;SETUP BAD DATA FOR TYPEOUT
4765	012354	042737	137777	001142		BIC	#CSKI,\$BDDAT	
4766	012362	005037	001140			CLR	\$GDDAT	;SKI SHOULD BE 0
4767	012366	104202				ERROR	202	;REPORT BAD SKI STATUS
4768	012370	032737	000200	001370	9\$:	BIT	#DVC,RMER2I	;IS DEVICE CHECK = 0??
4769	012376	001411				BEQ	10\$	;YES!!
4770	012400	013737	001370	001142		MOV	RMER2I,\$BDDAT	;SETUP BAD DATA FOR TYPEOUT

4771	012406	042737	177577	001142		BIC	#1CDVC,SBDDAT		
4772	012414	005037	001140			CLR	\$GDDAT		;DVC SHOULD BE 0
4773	012420	104203				ERROR	203		;REPORT BAD DVC STATUS
4774	012422				10\$:				
4775	012423	112737	000024	001533		MOVB	#RMMR1,PUTINX		;SETUP PUT INDEX TABLE
4776	012430	112737	000200	001534		MOVB	#200,PUTINX+1		;WRITE TERMINATOR BYTE
4777	012436	012737	001711	001422		MOV	#DMD!MUR!MOC!MSER!MDF!MWP,RMMR10		;RMMR1=DMD!MUR!MOC!MSER!MDF!MWP
4778	012444	004737	044466			JSR	PC,PUT		;GO WRITE RMMR1 VIA SUB
4779	012450	000404				BR	11\$		;GO TO 11\$ IF NO ERROR
4780	012452	000240				NOP			;RETURN HERE IF ERROR
4781	012454	104000				ERROR			;ERROR NUMBER DEFINED BY PUT SUB
4782	012456	000137	013110			JMP	22\$		;GO TO 22\$ IF ERROR WAS FOUND
4783	012462				11\$:				
4784	012462	004737	044216			JSR	PC,GET		;GO READ REGISTERS VIA GET SUB
4785	012466	000404				BR	12\$	;GO TO 12\$	;IF NO ERROR
4786	012470	000240				NOP			;RETURN HERE IF ERROR
4787	012472	104000				ERROR			;ERROR DEFINED BY GET SUB
4788	012474	000137	013110			JMP	22\$	;GO TO 22\$	;IF ERROR WAS FOUND
4789	012500	032737	000001	001352	12\$:	BIT	#DMD,RMMR11		;IS DIAGNOSTIC MODE SET??
4790	012506	001011				BNE	125\$		;YES!!
4791	012510	012737	000001	001140		MOV	#DMD,\$GDDAT		;EXPECTED STATUS
4792	012516	013737	001352	001142		MOV	RMMR11,SBDDAT		;RECEIVED STATUS
4793	012524	104176				ERROR	176		;COULD NOT SET DIAGNOSTIC MODE
4794	012526	000137	013110			JMP	22\$		;SKIP REST OF TEST IF DMD = 0
4795	012532	032737	010000	001340	125\$:	BIT	#MOL,RMDSI		;IS MOL = 1??
4796	012540	001012				BNE	13\$		;YES!!
4797	012542	013737	001340	001142		MOV	RMDSI,SBDDAT		;SETUP BAD DATA FOR TYPEOUT
4798	012550	042737	167777	001142		BIC	#1CMOL,SBDDAT		
4799	012556	012737	010000	001140		MOV	#MOL,\$GDDAT		;EXPECTED MOL = 1
4800	012564	104177				ERROR	177		;REPORT MOL STATUS ERROR
4801	012566	032737	020000	001340	13\$:	BIT	#PIP,RMDSI		;IS PIP 0 ??
4802	012574	001411				BEQ	14\$		;YES!!
4803	012576	013737	001340	001142		MOV	RMDSI,SBDDAT		;SETUP BAD DATA FOR TYPEOUT
4804	012604	042737	157777	001142		BIC	#1CPIP,SBDDAT		
4805	012612	005037	001140			CLR	\$GDDAT		;EXPECTED PIP STATUS
4806	012616	104200				ERROR	200		;REPORT BAD PIP STATUS
4807	012620	032737	004000	001340	14\$:	BIT	#WRL,RMDSI		;IS WRL SET??
4808	012626	001012				BNE	15\$		;YES!!
4809	012630	013737	001340	001142		MOV	RMDSI,SBDDAT		;SETUP BAD DATA FOR TYPEOUT
4810	012636	042737	173777	001142		BIC	#1CWRL,SBDDAT		
4811	012644	012737	004000	001140		MOV	#WRL,\$GDDAT		;EXPECTED GOOD STATUS
4812	012652	104201				ERROR	201		;REPORT ERROR IN WRL STATUS
4813	012654	032737	040000	001370	15\$:	BIT	#SKI,RMER2I		;IS SKI SET??
4814	012662	001012				BNE	16\$		;YES!!
4815	012664	013737	001370	001142		MOV	RMER2I,SBDDAT		;BAD DATA FOR TYPEOUT
4816	012672	042737	137777	001142		BIC	#1CSKI,SBDDAT		
4817	012700	012737	040000	001140		MOV	#SKI,\$GDDAT		;EXPECTED SKI ON
4818	012706	104202				ERROR	202		
4819	012710	032737	000200	001370	16\$:	BIT	#DVC,RMER2I		;IS DVC SET ??
4820	012716	001012				BNE	17\$		;YES!!
4821	012720	013737	001370	001142		MOV	RMER2I,SBDDAT		;BAD DATA FOR TYPEOUT
4822	012726	042737	177577	001142		BIC	#1CDVC,SBDDAT		
4823	012734	012737	000200	001140		MOV	#DVC,\$GDDAT		;EXPECTED DVC ON
4824	012742	104203				ERROR	203		;REPORT DVC STATUS ERROR
4825	012744	032737	000100	001340	17\$:	BIT	#VV,RMDSI		;MUR SHOULD HAVE RESET VOLUME VALID
4826	012752	001411				BEQ	19\$		;BRANCH IF IT DID

```

4827 012754 013737 001340 001142 MOV RMDSI, $BDDAT ;BAD DATA FOR TYPEOUT
4828 012762 042737 177677 001142 BIC #1CVV, $BDDAT
4829 012770 005037 001140 CLR $GDDAT ;GOOD DATA FOR TYPEOUT
4830 012774 104204 ERROR 204
4831 012776 19$: MOVB #RMCS1, PUTINX ;SETUP PUT INDEX TABLE
4832 012776 112737 000000 001533 MOVB #200, PUTINX+1 ;WRITE TERMINATOR
4833 013004 112737 000200 001534 MOV #DRVCLR!GO, RMCS10 ;RMCS1 OUTPUT BUFFER = DRVCLR!GO
4834 013012 012737 000011 001376 JSR PC, PUT ;CALL PUT SUBROUTINE
4835 013020 004737 044466 BR 20$ ;GO TO 20$ IF NO ERROR
4836 013024 000404 NOP ;RETURN HERE TO REPORT AN ERROR
4837 013026 000240 ERROR ;ERROR NUMBER DEFINED BY PUT SUB
4838 013030 104000 JMP 22$ ;GO TO 22$ IF ERROR WAS FOUND
4839 013032 000137 013110 20$: JSR PC, GET ;GO READ REGISTERS VIA GET SUB
4840 013036 20$: BR 21$ ;GO TO 21$ IF NO ERROR
4841 013036 004737 044216 NOP ;RETURN HERE IF ERROR
4842 013042 000404 ERROR ;ERROR DEFINED BY GET SUB
4843 013044 000240 JMP 22$ ;GO TO 22$ IF ERROR WAS FOUND
4844 013046 104000 21$: BIT #LBC, RMER2I ;IS LBC SET ??
4845 013050 000137 013110 BNE 22$ ;YES!!
4846 013054 032737 002000 001370 MOV RMER2I, $BDDAT ;BAD DATA FOR TYPEOUT
4847 013062 001012 MOV #LBC, $GDDAT ;GOOD DATA FOR TYPEOUT
4848 013064 013737 001370 001142 BIC #LBC, $BDDAT
4849 013072 012737 002000 001140 ERROR 262
4850 013100 042737 002000 001142
4851 013106 104262
4852 013110
4853 ;*****
4854 ;#TEST 12 PACK ACKNOWLEDGE TEST
4855 ;*****
4856 ;TST12:
4857 013110 SCOPE ;SCOPE CALL
4858 013110 000004 NOP ;START OF TEST
4859 013112 000240 MOV #STACK, SP ;INITIALIZE STACK POINTER
4860 013114 012706 001100 MOV $BASE, RO ;RO=UNIBUS ADDRESS
4861 013120 013700 001276 MOV TSTQUE, R1 ;(R1) = DEVICE BEING TESTED
4862 013124 013701 001446 MOV #12, $TESTN ;;SET TEST NUMBER IN APT MAIL BOX
4863 013130 012737 000012 001226 JSR PC, CNTCLR
4864 013136 004737 053360 BR 1$ ;GO TO 1$ IF NO ERROR
4865 013142 000404 NOP ;RETURN HERE IF ERROR
4866 013144 000240 ERROR ;ERROR NUMBER DEFINED BY SUB
4867 013146 104000 JMP 9$ ;GO TO 9$ IF ERROR WAS FOUND
4868 013150 000137 013410 1$: MOVB #RMMR1, PUTINX ;SETUP PUT INDEX TABLE
4869 013154 112737 000024 001533 MOVB #200, PUTINX+1 ;WRITE TERMINATOR BYTE
4870 013154 112737 000200 001534 MOV #DMD, RMMR10 ;RMMR1=DMD
4871 013162 112737 000001 001422 JSR PC, PUT ;GO WRITE RMMR1 VIA SUB
4872 013170 012737 000001 001422 BR 2$ ;GO TO 2$ IF NO ERROR
4873 013176 004737 044466 NOP ;RETURN HERE IF ERROR
4874 013176 004737 044466 ERROR ;ERROR NUMBER DEFINED BY PUT SUB
4875 013202 000404 JMP 9$ ;GO TO 9$ IF ERROR WAS FOUND
4876 013204 000240 2$: MOVB #RMMR1, PUTINX ;SETUP PUT INDEX TABLE
4877 013206 104000 MOVB #200, PUTINX+1 ;WRITE TERMINATOR BYTE
4878 013210 000137 013410 MOV #0, RMMR10 ;RMMR1=0
4879 013214 112737 000024 001533
4880 013214 112737 000024 001533
4881 013222 112737 000200 001534
4882 013230 012737 000000 001422

```

```

4883 013236 004737 044466      JSR    PC,PUT      ;GO WRITE RMMR1 VIA SUB
4884 013242 000404              BR     3$          ;GO TO 3$ IF NO ERROR
4885 013244 000240              NOP                    ;RETURN HERE IF ERROR
4886 013246 104000              ERROR          ;ERROR NUMBER DEFINED BY PUT SUB
4887 013250 000137 013410      JMP     9$          ;GO TO 9$ IF ERROR WAS FOUND
4888 013254              3$:
4889 013254 112737 000000 001533      MOVB   #RMCS1,PUTINX ;SETUP PUT INDEX TABLE
4890 013262 112737 000200 001534      MOVB   #200,PUTINX+1 ;WRITE TERMINATOR
4891 013270 012737 000023 001376      MOV    #PAKACK!GO,RMCS10 ;RMCS1 OUTPUT BUFFER = PAKACK!GO
4892 013276 004737 044466      JSR    PC,PUT      ;CALL PUT SUBROUTINE
4893 013302 000404              BR     4$          ;GO TO 4$ IF NO ERROR
4894 013304 000240              NOP                    ;RETURN HERE TO REPORT AN ERROR
4895 013306 104000              ERROR          ;ERROR NUMBER DEFINED BY PUT SUB
4896 013310 000137 013410      JMP     9$          ;GO TO 9$ IF ERROR WAS FOUND
4897 013314 004737 044132      JSR    PC,GETSTS   ;GO TO 9$ IF ERROR WAS FOUND
4898 013320 004737 045026      JSR    PC,TIMOUT   ;WAIT FOR COMPLETION
4899 013324 004737 044216      JSR    PC,GET      ;GO READ REGISTERS VIA GET SUB
4900 013330 000403              BR     5$          ;GO TO 5$ IF NO ERROR
4901 013332 000240              NOP                    ;RETURN HERE IF ERROR
4902 013334 104000              ERROR          ;ERROR DEFINED BY GET SUB
4903 013336 000424              BR     9$          ;SKIP REMAINDER OF TEST
4904 013340              5$:
4905 013340 004737 045212      JSR    PC,PRIERR   ;GO CHECK FOR PRIMARY ERRORS
4906 013344 000404              BR     6$          ;GO TO 6$ IF NO ERROR
4907 013346 000240              NOP                    ;RETURN HERE IF ERROR
4908 013350 104000              ERROR          ;ERROR # DEFINED BY PRIERR SUBROUTINE
4909 013352 004736              JSR    PC,a(SP)+   ;GO BACK FOR MORE ERROR CHECKS
4910 013354 000415              BR     9$          ;SKIP TO NEXT TEST
4911 013356              6$:
4912 013356 004737 054356      JSR    PC,ACKSTS   ;GO VERIFY PACK ACKNOWLEDGE
4913 013362 000404              BR     7$          ;GO TO 7$ IF NO ERROR
4914 013364 000240              NOP                    ;RETURN HERE IF ERROR
4915 013366 104000              ERROR          ;ERROR # DEFINED BY ACKSTS SUBROUTINE
4916 013370 004736              JSR    PC,a(SP)+   ;GO BACK FOR MORE ERROR CHECKS
4917 013372 000406              BR     9$          ;SKIP TO NEXT TEST
4918 013374              7$:
4919 013374 004737 046044      JSR    PC,SECERR   ;GO CHECK FOR SECONDARY ERRORS
4920 013400 000403              BR     9$          ;GO TO 9$ IF NO ERROR
4921 013402 000240              NOP                    ;RETURN HERE IF ERROR
4922 013404 104000              ERROR          ;ERROR # DEFINED BY SECERR SUBROUTINE
4923 013406 004736              JSR    PC,a(SP)+   ;GO BACK FOR MORE ERROR CHECKS
4924 013410              9$:
4925 013410
4926
4927
4928 ;*****
4929 ;*TEST 13 RECALIBRATE TEST
4930 ;*****
4931 013410      †ST13:
4932 013410 000004              SCOPE          ;SCOPE CALL
4933 013412 000240              NOP            ;START OF TEST
4934 013414 012737 000001 001206      MOV     #1,STIMES ;LOAD ITERATION COUNT
4935 013422 012737 013436 001122      MOV     #1$,SLPADR
4936 013430 012737 013436 001124      MOV     #1$,SLPERR
4937 013436
4938 013436 012706 001100      1$: MOV     #STACK,SP ;INITIALIZE STACK POINTER

```

```

4939 013442 013700 001276      MOV      $BASE,R0      ;R0=UNIBUS ADDRESS
4940 013446 013701 001446      MOV      TSTQUE,R1    ;(R1) = DEVICE BEING TESTED
4941 013452 012737 000013 001226  MOV      #13,$TESTN   ;SET TEST NUMBER IN APT MAIL BOX
4942 013460 004737 043216      JSR      PC,TSTPRP    ;PREPARE DEVICE FOR TEST
4943 013464 050020                .WORD    050020 ;TASK DESCRIPTOR
4944 013466 000404                BR       5$          ;GO TO 5$ IF NO ERROR
4945 013470 000240                NOP                      ;RETURN HERE IF ERROR
4946 013472 104000                ERROR   ;ERROR # DEFINED BY TSTPRP SUBROUTINE
4947 013474 000137 013642      JMP      10$         ;GO TO 10$ IF ERROR WAS FOUND
4948 013500                5$:
4949 013500 112737 000000 001533  MOVB     #RMCS1,PUTINX ;SETUP PUT INDEX TABLE
4950 013506 112737 000200 001534  MOVB     #200,PUTINX+1 ;WRITE TERMINATOR
4951 013514 012737 000007 001376  MOV      #RECAL!GO,RMCS10 ;RMCS1 OUTPUT BUFFER = RECAL!GO
4952 013522 004737 044466      JSR      PC,PUT       ;CALL PUT SUBROUTINE
4953 013526 000404                BR       6$          ;GO TO 6$ IF NO ERROR
4954 013530 000240                NOP                      ;RETURN HERE TO REPORT AN ERROR
4955 013532 104000                ERROR   ;ERROR NUMBER DEFINED BY PUT SUB
4956 013534 000137 013642      JMP      10$         ;GO TO 10$ IF ERROR WAS FOUND
4957 013540 004737 044132 6$:      JSR      PC,GETSTS    ;GO SETUP FOR STATUS FETCH
4958 013544 004737 045026      JSR      PC,TIMOUT    ;WAIT FOR COMPLETION
4959 013550 004737 044216      JSR      PC,GET       ;GO READ REGISTERS VIA GET SUB
4960 013554 000404                BR       7$          ;GO TO 7$ IF NO ERROR
4961 013556 000240                NOP                      ;RETURN HERE IF ERROR
4962 013560 104000                ERROR   ;ERROR DEFINED BY GET SUB
4963 013562 000137 013642      JMP      10$         ;GO TO 10$ IF ERROR WAS FOUND
4964 013566                7$:
4965 013566 004737 045212      JSR      PC,PRIERR    ;GO CHECK FOR PRIMARY ERRORS
4966 013572 000405                BR       8$          ;GO TO 8$ IF NO ERROR
4967 013574 000240                NOP                      ;RETURN HERE IF ERROR
4968 013576 104000                ERROR   ;ERROR # DEFINED BY PRIERR SUBROUTINE
4969 013600 004736      JSR      PC,@(SP)+    ;GO BACK FOR MORE ERROR CHECKS
4970 013602 000137 013642      JMP      10$         ;GO TO 10$ IF ERROR WAS FOUND
4971 013606                8$:
4972 013606 004737 055152      JSR      PC,RCLSTS    ;GO VERIFY RECALIBRATE OPERATION
4973 013612 000405                BR       9$          ;GO TO 9$ IF NO ERROR
4974 013614 000240                NOP                      ;RETURN HERE IF ERROR
4975 013616 104000                ERROR   ;ERROR # DEFINED BY RCLSTS SUBROUTINE
4976 013620 004736      JSR      PC,@(SP)+    ;GO BACK FOR MORE ERROR CHECKS
4977 013622 000137 013642      JMP      10$         ;GO TO 10$ IF ERROR WAS FOUND
4978 013626                9$:
4979 013626 004737 046044      JSR      PC,SECERR    ;GO CHECK FOR SECONDARY ERRORS
4980 013632 000403                BR       10$        ;GO TO 10$ IF NO ERROR
4981 013634 000240                NOP                      ;RETURN HERE IF ERROR
4982 013636 104000                ERROR   ;ERROR # DEFINED BY SECERR SUBROUTINE
4983 013640 004736      JSR      PC,@(SP)+    ;GO BACK FOR MORE ERROR CHECKS
4984 013642                10$:
4985
4986
4987
4988
4989 013642                ;*****
4990 013642 000004                ;TEST 14 ABORT RECALIBRATE TEST
4991 013644 000240                ;*****
4992 013646 012737 000001 001206  TST14:  SCOPE          ;SCOPE CALL
4993 013654 012737 013670 001122  NOP          ;START OF TEST
4994 013662 012737 013670 001124  MOV      #1,$TIMES   ;LOAD ITERATION COUNT
        MOV      #1,$SLPADR
        MOV      #1,$SLPERR

```

```

4995 013670          1S:
4996 013670 012706 001100      MOV    #STACK,SP      ;INITIALIZE STACK POINTER
4997 013674 013700 001276      MOV    $BASE,R0      ;R0=UNIBUS ADDRESS
4998 013700 013701 001446      MOV    TSTQUE,R1     ;(R1) = DEVICE BEING TESTED
4999 013704 012737 000014 001226  MOV    #14,$TESTN    ;;SET TEST NUMBER IN APT MAIL BOX
5000
5001 013712 004737 043216      JSR    PC,TSTPRP     ;PREPARE DEVICE FOR TEST
5002 013716 054130          .WORD 054130 ;TASK DESCRIPTOR
5003 013720 000404          BR     8S           ;GO TO 8S IF NO ERROR
5004 013722 000240          NOP
5005 013724 104000          ERROR
5006 013726 000137 014164      JMP    15S          ;RETURN HERE IF ERROR
                    ;ERROR # DEFINED BY TSTPRP SUBROUTINE
                    ;GO TO 15S IF ERROR WAS FOUND
5007 013732
5008 013732 112737 000014 001533 8S:      MOVVB  #RMER1,PUTINX  ;SETUP PUT INDEX TABLE
5009 013740 112737 000200 001534      MOVVB  #200,PUTINX+1 ;WRITE TERMINATOR BYTE
5010 013746 012737 040000 001412      MOV    #UNS,RMER10   ;RMER1 OUTPUT BUFFER = UNS
5011 013754 004737 044466      JSR    PC,PUT        ;WRITE RMER1 VIA PUT SUB
5012 013760 000404          BR     9S           ;GO TO 9S IF NO ERROR
5013 013762 000240          NOP
5014 013764 104000          ERROR
5015 013766 000137 014164      JMP    15S          ;RETURN HERE TO REPORT ERROR
                    ;ERROR NUMBER DEFINED BY PUT SUB
5016 013772
5017 013772 112737 000000 001533 9S:      MOVVB  #RMCS1,PUTINX  ;SETUP PUT INDEX TABLE
5018 014000 112737 000200 001534      MOVVB  #200,PUTINX+1 ;WRITE TERMINATOR
5019 014006 012737 000007 001376      MOV    #RECAL!GO,RMCS10 ;RMCS1 OUTPUT BUFFER = RECAL!GO
5020 014014 004737 044466      JSR    PC,PUT        ;CALL PUT SUBROUTINE
5021 014020 000404          BR     10S          ;GO TO 10S IF NO ERROR
5022 014022 000240          NOP
5023 014024 104000          ERROR
5024 014026 000137 014164      JMP    15S          ;RETURN HERE TO REPORT AN ERROR
                    ;ERROR NUMBER DEFINED BY PUT SUB
5025 014032 004737 044132 10S:     JSR    PC,GETSTS     ;SETUP FOR STATUS FETCH
5026 014036 004737 044216      JSR    PC,GET        ;GO READ REGISTERS VIA GET SUB
5027 014042 000404          BR     11S          ;GO TO 11S IF NO ERROR
5028 014044 000240          NOP
5029 014046 104000          ERROR
5030 014050 000137 014164      JMP    15S          ;RETURN HERE IF ERROR
                    ;ERROR DEFINED BY GET SUB
5031 014054 032737 020000 001340 11S:     BIT    #PIP,RMDSI    ;DID THE DRIVE RECALIBRATE??
5032 014062 001401          BEQ    12S          ;NO!!
5033 014064 104214          ERROR
5034 014066 004737 045026 12S:     JSR    PC,TIMOUT     ;ERROR SHOULD PREVENT RECALIBRATE
5035 014072 004737 044216      JSR    PC,GET        ;WAIT FOR COMPLETION
5036 014076 000404          BR     13S          ;GO READ REGISTERS VIA GET SUB
5037 014100 000240          NOP
5038 014102 104000          ERROR
5039 014104 000137 014164      JMP    15S          ;GO TO 13S IF NO ERROR
                    ;RETURN HERE IF ERROR
                    ;ERROR DEFINED BY GET SUB
5040 014110
5041 014110 004737 045212 13S:     JSR    PC,PRIERR     ;GO CHECK FOR PRIMARY ERRORS
5042 014114 000405          BR     14S          ;GO TO 14S IF NO ERROR
5043 014116 000240          NOP
5044 014120 104000          ERROR
5045 014122 004736          JSR    PC,@(SP)+    ;RETURN HERE IF ERROR
                    ;ERROR # DEFINED BY PRIERR SUBROUTINE
                    ;GO BACK FOR MORE ERROR CHECKS
5046 014124 000137 014164      JMP    15S          ;GO TO 15S IF ERROR WAS FOUND
5047 014130
5048 014130 004737 061062 14S:     JSR    PC,STCDRVSTS ;GO CHECK FOR CHANGES IN DRIVE STATUS
5049 014134 000405          BR     141S        ;GO TO 141S IF NO ERROR
5050 014136 000240          NOP
                    ;RETURN HERE IF ERROR

```

```

5051 014140 104000 ERROR ; ERROR # DEFINED BY STCDRVSTS SUBROUTINE
5052 014142 004736 JSR PC,@(SP)+ ; GO BACK FOR MORE ERROR CHECKS
5053 014144 000137 014164 JMP 15$ ; GO TO 15$ IF ERROR WAS FOUND
5054 014150
5055 014150 004737 046044 141$: JSR PC,SECERR ; GO CHECK FOR SECONDARY ERRORS
5056 014154 000403 BR 15$ ; GO TO 15$ IF NO ERROR
5057 014156 000240 NOP ; RETURN HERE IF ERROR
5058 014160 104000 ERROR ; ERROR # DEFINED BY SECERR SUBROUTINE
5059 014162 004736 JSR PC,@(SP)+ ; GO BACK FOR MORE ERROR CHECKS
5060 014164
5061
5062
5063 ; *****
5064 ; *TEST 15 IVC RECALIBRATE TEST
5065 ; *****
5066 TST15:
5067 SCOPE ; SCOPE CALL
5068 NOP ; START OF TEST
5069 MOV #1,$TIMES ; LOAD ITERATION COUNT
5070 MOV #1$,$LPADR
5071 MOV #1$,$LPERR
5072 1$: MOV #STACK,SP ; INITIALIZE STACK POINTER
5073 MOV $BASE,$RO ; RO=UNIBUS ADDRESS
5074 MOV TSTQUE,$R1 ; (R1) = DEVICE BEING TESTED
5075 MOV #15,$TESTN ; SET TEST NUMBER IN APT MAIL BOX
5076 JSR PC,$TSTPRP ; PREPARE DEVICE FOR TEST
5077 .WORD 054130 ; TASK DESCRIPTOR
5078 BR 8$ ; GO TO 8$ IF NO ERROR
5079 NOP ; RETURN HERE IF ERROR
5080 ERROR ; ERROR # DEFINED BY TSTPRP SUBROUTINE
5081 JMP 15$ ; GO TO 15$ IF ERROR WAS FOUND
5082
5083 8$: MOV #RMMR1,$PUTINX ; SETUP PUT INDEX TABLE
5084 MOV #200,$PUTINX+1 ; WRITE TERMINATOR BYTE
5085 MOV #DMD,$RMMR10 ; RMMR1=DMD
5086 JSR PC,$PUT ; GO WRITE RMMR1 VIA SUB
5087 BR 9$ ; GO TO 9$ IF NO ERROR
5088 NOP ; RETURN HERE IF ERROR
5089 ERROR ; ERROR NUMBER DEFINED BY PUT SUB
5090 JMP 15$ ; GO TO 15$ IF ERROR WAS FOUND
5091
5092 9$: MOV #RMMR1,$PUTINX ; SETUP PUT INDEX TABLE
5093 MOV #200,$PUTINX+1 ; WRITE TERMINATOR BYTE
5094 MOV #0,$RMMR10 ; RMMR1=0
5095 JSR PC,$PUT ; GO WRITE RMMR1 VIA SUB
5096 BR 10$ ; GO TO 10$ IF NO ERROR
5097 NOP ; RETURN HERE IF ERROR
5098 ERROR ; ERROR NUMBER DEFINED BY PUT SUB
5099 JMP 15$ ; GO TO 15$ IF ERROR WAS FOUND
5100
5101 10$: MOV #RMCS1,$PUTINX ; SETUP PUT INDEX TABLE
5102 MOV #200,$PUTINX+1 ; WRITE TERMINATOR
5103 MOV #RECAL!GO,$RMCS10 ; RMCS1 OUTPUT BUFFER = RECAL!GO
5104 JSR PC,$PUT ; CALL PUT SUBROUTINE
5105 BR 11$ ; GO TO 11$ IF NO ERROR
5106 NOP ; RETURN HERE TO REPORT AN ERROR

```



```

S107 014406 104000          ERROR          ;ERROR NUMBER DEFINED BY PUT SUB
S108 014410 000137 014510    JMP          15$          ;GO TO 15$ IF ERROR WAS FOUND
S109 014414 004737 044132    11$: JSR      PC,GETSTS     ;SETUP FOR STATUS FETCH
S110 014420 004737 045026    JSR      PC,TIMOUT      ;WAIT FOR RECAL TO COMPLETE
S111 014424 004737 044216    JSR      PC,GET         ;GO READ REGISTERS VIA GET SUB
S112 014430 000404          BR          12$          ;GO TO 12$ IF NO ERROR
S113 014432 000240          NOP          ;RETURN HERE IF ERROR
S114 014434 104000          ERROR          ;ERROR DEFINED BY GET SUB
S115 014436 000137 014510    JMP          15$          ;GO TO 15$ IF ERROR WAS FOUND
S116 014442          12$: JSR      PC,PRIERR     ;GO CHECK FOR PRIMARY ERRORS
S117 014442 004737 045212    BR          13$          ;GO TO 13$ IF NO ERROR
S118 014446 000405          NOP          ;RETURN HERE IF ERROR
S119 014450 000240          ERROR          ;ERROR # DEFINED BY PRIERR SUBROUTINE
S120 014452 104000          JSR      PC,@(SP)+      ;GO BACK FOR MORE ERROR CHECKS
S121 014454 004736          JMP          15$          ;GO TO 15$ IF ERROR WAS FOUND
S122 014456 000137 014510    13$: BIT      #IVC,RMER2I ;IVC SHOULD BE SET
S123 014462 032737 010000 001370 BNE      14$          ;IT IS - GO CHECK SECONDARY ERRORS
S124 014470 001001          ERROR          ;IVC NOT SET DURING RECALIBRATE
S125 014472 104215          14$: JSR      PC,SECERR    ;GO CHECK FOR SECONDARY ERRORS
S126 014474          BR          15$          ;GO TO 15$ IF NO ERROR
S127 014474 004737 046044    NOP          ;RETURN HERE IF ERROR
S128 014500 000403          ERROR          ;ERROR # DEFINED BY SECERR SUBROUTINE
S129 014502 000240          JSR      PC,@(SP)+      ;GO BACK FOR MORE ERROR CHECKS
S130 014504 104000          15$:
S131 014506 004736
S132 014510
S133
S134
S135
S136
S137 014510
S138 014510 000004          ;*****
S139 014512 000240          ;TEST 16 IAE RECALIBRATE TEST
S140 014514 012737 000001 001206 ;*****
S141 014522 012737 014536 001122 ;ST16:
S142 014530 012737 014536 001124
S143 014536          SCOPE          ;SCOPE CALL
S144 014536 012706 001100    NOP          ;START OF TEST
S145 014542 013700 001276    MOV      #1,STIMES     ;LOAD ITERATION COUNT
S146 014546 013701 001446    MOV      #1$,SLPADR
S147 014552 012737 000016 001226 MOV      #1$,SLPERR
S148 014560 004737 043216    MOV      #STACK,SP     ;INITIALIZE STACK POINTER
S149 014564 054130          MOV      $BASE,R0      ;R0=UNIBUS ADDRESS
S150 014566 000404          MOV      TSTQUE,R1     ;(R1) = DEVICE BEING TESTED
S151 014570 000240          MOV      #16,$TESTN    ;SET TEST NUMBER IN APT MAIL BOX
S152 014572 104000          JSR      PC,TSTPRP     ;PREPARE DEVICE FOR TEST
S153 014574 000137 014766    .WORD    054130 ;TASK DESCRIPTOR
S154 014600          BR          70$          ;GO TO 70$ IF NO ERROR
S155 014600 012737 177777 001432    NOP          ;RETURN HERE IF ERROR
S156 014606 012737 177777 001404    ERROR          ;ERROR # DEFINED BY TSTPRP SUBROUTINE
S157 014614 012737 000007 001376    JMP          120$       ;GO TO 120$ IF ERROR WAS FOUND
S158 014622 012702 001533          70$: MOV      #-1,RMDCO     ;RMDC WILL BE ALL ONES
S159 014626 112722 000034          MOV      #-1,RMDAO     ;RMDA WILL BE ALL ONES
S160 014632 112722 000006          MOV      #RECAL!GO, RMCS10
S161 014636 112722 000000          MOV      #PUTINX,R2    ;R2 POINTS TO PUT INDEX TABLE
S162 014642 112722 000200          MOVB    #RMDC,(R2)+    ;SETUP PUT INDEX TABLE
          MOVB    #RMDA,(R2)+
          MOVB    #RMCS1,(R2)+
          MOVB    #200,(R2)+

```

```

5163 014646 004737 044466 JSR PC,PUT ;GO WRITE REGISTERS VIA PUT SUB
5164 014652 000404 BR 80$ ;GO TO 80$ IF NO ERROR
5165 014654 000240 NOP ;RETURN HERE IF ERROR
5166 014656 104000 ERROR ;ERROR DEFINED BY PUT SUB
5167 014660 000137 014766 JMP 120$ ;GO TO 120$ IF ERROR WAS FOUND
5168 014664 004737 044132 80$: JSR PC,GETSTS ;SETUP FOR STATUS FETCH
5169 014670 004737 045026 JSR PC,TIMOUT ;WAIT FOR GO TO RESET
5170 014674 004737 044216 JSR PC,GET ;GO READ REGISTERS VIA GET SUB
5171 014700 000404 BR 90$ ;GO TO 90$ IF NO ERROR
5172 014702 000240 NOP ;RETURN HERE IF ERROR
5173 014704 104000 ERROR ;ERROR DEFINED BY GET SUB
5174 014706 000137 014766 JMP 120$ ;GO TO 120$ IF ERROR WAS FOUND
5175 014712 90$:
5176 014712 004737 045212 JSR PC,PRIERR ;GO CHECK FOR PRIMARY ERRORS
5177 014716 000405 BR 100$ ;GO TO 100$ IF NO ERROR
5178 014720 000240 NOP ;RETURN HERE IF ERROR
5179 014722 104000 ERROR ;ERROR # DEFINED BY PRIERR SUBROUTINE
5180 014724 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
5181 014726 000137 014766 JMP 120$ ;GO TO 120$ IF ERROR WAS FOUND
5182 014732 100$:
5183 014732 004737 055152 JSR PC,RCLSTS ;GO VERIFY RECALIBRATE OPERATION
5184 014736 000405 BR 110$ ;GO TO 110$ IF NO ERROR
5185 014740 000240 NOP ;RETURN HERE IF ERROR
5186 014742 104000 ERROR ;ERROR # DEFINED BY RCLSTS SUBROUTINE
5187 014744 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
5188 014746 000137 014766 JMP 120$ ;GO TO 120$ IF ERROR WAS FOUND
5189 014752 110$:
5190 014752 004737 046044 JSR PC,SECERR ;GO CHECK FOR SECONDARY ERRORS
5191 014756 000403 BR 120$ ;GO TO 120$ IF NO ERROR
5192 014760 000240 NOP ;RETURN HERE IF ERROR
5193 014762 104000 ERROR ;ERROR # DEFINED BY SECERR SUBROUTINE
5194 014764 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
5195 014766 120$:
5196
5197 ;*****
5198 ;*TEST 17 RECALIBRATE AT OFFSET
5199 ;*****
5200 †TST17:
5201 014766 000004 SCOPE ;SCOPE CALL
5202 014770 000240 NOP ;START OF TEST
5203 014772 012737 000001 001206 MOV #1,$TIMES ;LOAD ITERATION COUNT
5204 015000 012737 015014 001122 MOV #1,$SLPADR
5205 015006 012737 015014 001124 MOV #1,$SLPERR
5206 015014 1$:
5207 015014 012706 001100 MOV #STACK,SP ;INITIALIZE STACK POINTER
5208 015020 013700 001276 MOV $BASE,R0 ;R0=UNIBUS ADDRESS
5209 015024 013701 001446 MOV TSTQUE,R1 ;(R1) = DEVICE BEING TESTED
5210 015030 012737 000017 001226 MOV #17,$TESTN ;SET TEST NUMBER IN APT MAIL BOX
5211
5212 015036 004737 043216 JSR PC,TSTPRP ;PREPARE DEVICE FOR TEST
5213 015042 050020 .WORD 050020 ;TASK DESCRIPTOR
5214 015044 000404 BR 5$ ;GO TO 5$ IF NO ERROR
5215 015046 000240 NOP ;RETURN HERE IF ERROR
5216 015050 104000 ERROR ;ERROR # DEFINED BY TSTPRP SUBROUTINE
5217 015052 000137 015260 JMP 80$ ;GO TO 80$ IF ERROR WAS FOUND
5218 015056 5$:

```

```

5219 015056 112737 000000 001533 MOVB #RMCS1,PUTINX ;SETUP PUT INDEX TABLE
5220 015064 112737 000200 001534 MOVB #200,PUTINX+1 ;WRITE TERMINATOR
5221 015072 012737 000015 001376 MOV #OFFSET!GO,RMCS10 ;RMCS1 OUTPUT BUFFER = OFFSET!GO
5222 015100 004737 044466 JSR PC,PUT ;CALL PUT SUBROUTINE
5223 015104 000404 BR 10$ ;GO TO 10$ IF NO ERROR
5224 015106 000240 NOP ;RETURN HERE TO REPORT AN ERROR
5225 015110 104000 ERROR ;ERROR NUMBER DEFINED BY PUT SUB
5226 015112 000137 015260 JMP 80$ ;GO TO 80$ IF ERROR WAS FOUND
5227 015116 10$:
5228 015116 112737 000000 001533 MOVB #RMCS1,PUTINX ;SETUP PUT INDEX TABLE
5229 015124 112737 000200 001534 MOVB #200,PUTINX+1 ;WRITE TERMINATOR
5230 015132 012737 000007 001376 MOV #RECAL!GO,RMCS10 ;RMCS1 OUTPUT BUFFER = RECAL!GO
5231 015140 004737 044466 JSR PC,PUT ;CALL PUT SUBROUTINE
5232 015144 000404 BR 20$ ;GO TO 20$ IF NO ERROR
5233 015146 000240 NOP ;RETURN HERE TO REPORT AN ERROR
5234 015150 104000 ERROR ;ERROR NUMBER DEFINED BY PUT SUB
5235 015152 000137 015260 JMP 80$ ;GO TO 80$ IF ERROR WAS FOUND
5236 015156 20$:
5237 015156 004737 044132 JSR PC,GETSTS ;GO TO GETSTS SUBROUTINE
5238 015162 30$:
5239 015162 004737 045026 JSR PC,TIMOUT ;GO TO TIMOUT SUBROUTINE
5240 015166 40$:
5241 015166 004737 044216 JSR PC,GET ;GO READ REGISTERS WITH GET SUBROUTINE
5242 015172 000404 BR 50$ ;GO TO 50$ IF NO ERROR
5243 015174 000240 NOP ;RETURN HERE IF ERROR
5244 015176 104000 ERROR ;ERROR # DEFINED BY GET SUBROUTINE
5245 015200 000137 015260 JMP 80$ ;GO TO 80$ IF ERROR WAS FOUND
5246 015204 50$:
5247 015204 004737 045212 JSR PC,PRIERR ;GO CHECK FOR PRIMARY ERRORS
5248 015210 000405 BR 60$ ;GO TO 60$ IF NO ERROR
5249 015212 000240 NOP ;RETURN HERE IF ERROR
5250 015214 104000 ERROR ;ERROR # DEFINED BY PRIERR SUBROUTINE
5251 015216 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
5252 015220 000137 015260 JMP 80$ ;GO TO 80$ IF ERROR WAS FOUND
5253 015224 60$:
5254 015224 004737 055152 JSR PC,RCLSTS ;GO VERIFY RECALIBRATE OPERATION
5255 015230 000405 BR 70$ ;GO TO 70$ IF NO ERROR
5256 015232 000240 NOP ;RETURN HERE IF ERROR
5257 015234 104000 ERROR ;ERROR # DEFINED BY RCLSTS SUBROUTINE
5258 015236 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
5259 015240 000137 015260 JMP 80$ ;GO TO 80$ IF ERROR WAS FOUND
5260 015244 70$:
5261 015244 004737 046044 JSR PC,SECERR ;GO CHECK FOR SECONDARY ERRORS
5262 015250 000403 BR 80$ ;GO TO 80$ IF NO ERROR
5263 015252 000240 NOP ;RETURN HERE IF ERROR
5264 015254 104000 ERROR ;ERROR # DEFINED BY SECERR SUBROUTINE
5265 015256 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
5266 015260 80$:
5267 ;*****
5268 ;*TEST 20 DRIVE CLEAR TEST
5269 ;*****
5270 †ST20:
5271 015260 SCOPE ;SCOPE CALL
5272 015260 000004 NOP ;START OF TEST
5273 015262 000240 MOV #STACK,SP ;INITIALIZE STACK POINTER
5274 015264 012706 001100

```

```

5275 015270 013700 001276 MOV $BASE,R0 ;RO=UNIBUS ADDRESS
5276 015274 013701 001446 MOV TSTQUE,R1 ;(R1) = DEVICE BEING TESTED
5277 015300 012737 000020 001226 MOV #20,$TESTN ;SET TEST NUMBER IN APT MAIL BOX
5278 015306 004737 043216 JSR PC,TSTPRP ;PREPARE DEVICE FOR TEST
5279 015312 054130 .WORD 054130 ;TASK DESCRIPTOR
5280 015314 000404 BR 2$ ;GO TO 2$ IF NO ERROR
5281 015316 000240 NOP ;RETURN HERE IF ERROR
5282 015320 104000 ERROR ;ERROR # DEFINED BY TSTPRP SUBROUTINE
5283 015322 000137 015530 JMP 21$ ;GO TO 21$ IF ERROR WAS FOUND
5284 015326 2$:
5285 015326 012737 000000 001404 MOV #0,RMDAO
5286 015334 012737 000011 001376 MOV #DRVCLR!GO,RMCS10
5287 015342 012737 177777 001412 MOV #-1,RMER10
5288 015350 012737 177777 001440 MOV #-1,RMER20
5289 015356 042737 004000 001440 BIC #LSC,RMER20 ;DELETE FOR PASS 2 ETCH
5290 015364 012702 001533 MOV #PUTINX,R2 ;R2 POINTS TO INDEX TABLE
5291 015370 112722 000006 MOVB #RMDA,(R2)+ ;RMDA CLEARS LBT
5292 015374 112722 000042 MOVB #RMER2,(R2)+
5293 015400 112722 000014 MOVB #RMER1,(R2)+
5294 015404 112722 000000 MOVB #RMCS1,(R2)+
5295 015410 112722 000200 MOVB #200,(R2)+
5296 015414 004737 044466 JSR PC,PUT ;GO WRITE REGISTERS VIA PUT SUB
5297 015420 000403 BR 3$ ;GO TO 3$ IF NO ERROR
5298 015422 000240 NOP ;RETURN HERE IF ERROR
5299 015424 104000 ERROR ;ERROR DEFINED BY PUT SUB
5300 015426 000440 BR 21$ ;ESCAPE IF ERROR
5301 015430 004737 044132 3$: JSR PC,GETSTS ;SETUP FOR STATUS FETCH
5302 015434 004737 045026 JSR PC,TIMOUT ;WAIT FOR DRIVE CLEAR TO COMPLETE
5303 015440 004737 044216 JSR PC,GET ;GO READ REGISTERS VIA GET SUB
5304 015444 000403 BR 4$ ;GO TO 4$ IF NO ERROR
5305 015446 000240 NOP ;RETURN HERE IF ERROR
5306 015450 104000 ERROR ;ERROR DEFINED BY GET SUB
5307 015452 000426 BR 21$ ;SKIP REMAINDER OF TEST
5308 015454 4$:
5309 015454 004737 045212 JSR PC,PRIERR ;GO CHECK FOR PRIMARY ERRORS
5310 015460 000405 BR 5$ ;GO TO 5$ IF NO ERROR
5311 015462 000240 NOP ;RETURN HERE IF ERROR
5312 015464 104000 ERROR ;ERROR # DEFINED BY PRIERR SUBROUTINE
5313 015466 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
5314 015470 000137 015530 JMP 21$ ;GO TO 21$ IF ERROR WAS FOUND
5315 015474 5$:
5316 015474 004737 056714 JSR PC,DRVSTS ;GO VERIFY DRIVE CLEAR
5317 015500 000405 BR 6$ ;GO TO 6$ IF NO ERROR
5318 015502 000240 NOP ;RETURN HERE IF ERROR
5319 015504 104000 ERROR ;ERROR # DEFINED BY DRVSTS SUBROUTINE
5320 015506 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
5321 015510 000137 015530 JMP 21$ ;GO TO 21$ IF ERROR WAS FOUND
5322 015514 6$:
5323 015514 004737 046044 JSR PC,SECERR ;GO CHECK FOR SECONDARY ERRORS
5324 015520 000403 BR 21$ ;GO TO 21$ IF NO ERROR
5325 015522 000240 NOP ;RETURN HERE IF ERROR
5326 015524 104000 ERROR ;ERROR # DEFINED BY SECERR SUBROUTINE
5327 015526 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
5328 015530 21$:
5329
5330 ;*****

```

```
5331 ;*TEST 21 NOP TEST
5332
5333 ;*****
5334 TST21:
5335 SCOPE ;SCOPE CALL
5336 NOP ;START OF TEST
5337 MOV #STACK,SP ;INITIALIZE STACK POINTER
5338 MOV $BASE,RO ;RO=UNIBUS ADDRESS
5339 MOV TSTQUE,R1 ;(R1) = DEVICE BEING TESTED
5340 MOV #21,$TESTN ;SET TEST NUMBER IN APT MAIL BOX
5341 JSR PC,TSTPRP ;PREPARE DEVICE FOR TEST
5342 .WORD 054130 ;TASK DESCRIPTOR
5343 BR 70$ ;GO TO 70$ IF NO ERROR
5344 NOP ;RETURN HERE IF ERROR
5345 ERROR ;ERROR # DEFINED BY TSTPRP SUBROUTINE
5346 JMP 130$ ;GO TO 130$ IF ERROR WAS FOUND
5347
5348 70$: MOVB #RMCS1,PUTINX ;SETUP PUT INDEX TABLE
5349 MOVB #200,PUTINX+1 ;WRITE TERMINATOR
5350 MOV #NOP!GO,RMCS10 ;RMCS1 OUTPUT BUFFER = NOP!GO
5351 JSR PC,PUT ;CALL PUT SUBROUTINE
5352 BR 80$ ;GO TO 80$ IF NO ERROR
5353 NOP ;RETURN HERE TO REPORT AN ERROR
5354 ERROR ;ERROR NUMBER DEFINED BY PUT SUB
5355 JMP 130$ ;GO TO 130$ IF ERROR WAS FOUND
5356 80$: JSR PC,GETSTS ;SETUP FOR STATUS FETCH
5357 JSR PC,GET ;GO READ REGISTERS VIA GET SUB
5358 BR 90$ ;GO TO 90$ IF NO ERROR
5359 NOP ;RETURN HERE IF ERROR
5360 ERROR ;ERROR DEFINED BY GET SUB
5361 JMP 130$ ;GO TO 130$ IF ERROR WAS FOUND
5362
5363 90$: JSR PC,PRIERR ;GO CHECK FOR PRIMARY ERRORS
5364 BR 100$ ;GO TO 100$ IF NO ERROR
5365 NOP ;RETURN HERE IF ERROR
5366 ERROR ;ERROR # DEFINED BY PRIERR SUBROUTINE
5367 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
5368 JMP 130$ ;GO TO 130$ IF ERROR WAS FOUND
5369
5370 100$: JSR PC,CMPERRSTS ;CHECK ANY ERRORS NOT MASKED
5371 .WORD NDTMSK ;MASK FOR RMER1
5372 .WORD DPE ;MASK FOR RMER2
5373 BR 110$ ;GO TO 110$ IF NO ERROR
5374 NOP ;RETURN HERE IF ERROR
5375 ERROR ;ERROR # DEFINED BY CMPERRSTS SUBROUTINE
5376 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
5377 JMP 130$ ;GO TO 130$ IF ERROR WAS FOUND
5378
5379 110$: JSR PC,STCDRVSTS ;GO CHECK FOR CHANGES IN DRIVE STATUS
5380 BR 120$ ;GO TO 120$ IF NO ERROR
5381 NOP ;RETURN HERE IF ERROR
5382 ERROR ;ERROR # DEFINED BY STCDRVSTS SUBROUTINE
5383 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
5384 JMP 130$ ;GO TO 130$ IF ERROR WAS FOUND
5385
5386 120$: JSR PC,SECERR ;GO CHECK FOR SECONDARY ERRORS
```

```
5387 015750 000403 BR 130$ ;GO TO 130$ IF NO ERROR
5388 015752 000240 NOP ;RETURN HERE IF ERROR
5389 015754 104000 ERROR ;ERROR # DEFINED BY SECERR SUBROUTINE
5390 015756 004736 JSR PC,2(SP)+ ;GO BACK FOR MORE ERROR CHECKS
5391 015760
130$:
;*****
;#TEST 22 OFFSET TEST
;*****
†ST22:
SCOPE ;SCOPE CALL
NOP ;START OF TEST
MOV #STACK,SP ;INITIALIZE STACK POINTER
MOV $BASE,R0 ;R0=UNIBUS ADDRESS
MOV TSTQUE,R1 ;(R1) = DEVICE BEING TESTED
MOV #22,STESTN ;SET TEST NUMBER IN APT MAIL BOX
JSR PC,†STPRP ;PREPARE DEVICE FOR TEST
WORD 054130 ;TASK DESCRIPTOR
BR 40$ ;GO TO 40$ IF NO ERROR
NOP ;RETURN HERE IF ERROR
ERROR ;ERROR # DEFINED BY TSTPRP SUBROUTINE
JMP 100$ ;GO TO 100$ IF ERROR WAS FOUND
40$:
MOVB #RMCS1,PUTINX ;SETUP PUT INDEX TABLE
MOVB #200,PUTINX+1 ;WRITE TERMINATOR
MOV #OFFSET!GO,RMCS10 ;RMCS1 OUTPUT BUFFER = OFFSET!GO
JSR PC,PUT ;CALL PUT SUBROUTINE
BR 50$ ;GO TO 50$ IF NO ERROR
NOP ;RETURN HERE TO REPORT AN ERROR
ERROR ;ERROR NUMBER DEFINED BY PUT SUB
JMP 100$ ;GO TO 100$ IF ERROR WAS FOUND
50$:
JSR PC,GETSTS ;SETUP FOR STATUS FETCH
JSR PC,TIMOUT ;WAIT FOR GO TO RESET
JSR PC,GET ;GO READ REGISTERS VIA GET SUB
BR 60$ ;GO TO 60$ IF NO ERROR
NOP ;RETURN HERE IF ERROR
ERROR ;ERROR DEFINED BY GET SUB
JMP 100$ ;GO TO 100$ IF ERROR WAS FOUND
60$:
JSR PC,PRIERR ;GO CHECK FOR PRIMARY ERRORS
BR 70$ ;GO TO 70$ IF NO ERROR
NOP ;RETURN HERE IF ERROR
ERROR ;ERROR # DEFINED BY PRIERR SUBROUTINE
JSR PC,2(SP)+ ;GO BACK FOR MORE ERROR CHECKS
JMP 100$ ;GO TO 100$ IF ERROR WAS FOUND
70$:
BIT #0M,RMSDI ;OFFSET MODE ON??
BNE 80$ ;YES!!
MOV RMSDI,$BDDAT ;BAD DATA FOR TYPEOUT
BIC #†COM,$BDDAT
MOV #0M,$GDDAT ;GOOD DATA FOR TYPEOUT
ERROR 156 ;OFFSET MODE NOT SET
BIT #ATA,RMSDI ;WAS ATTENTION SET ??
BNE 90$ ;YES!!
MOV RMSDI,$BDDAT ;BAD DATA FOR TYPEOUT
BIC #†CATA,$BDDAT
```

```

5443 016214 012737 100000 001140 MOV #ATA,$GDDAT ;GOOD DATA FOR TYPEOUT
5444 016222 104172 ERROR 172 ;ATTENTION NOT SET
5445 016224 90$: JSR PC,CMPERRSTS ;CHECK ANY ERRORS NOT MASKED
5446 016224 004737 061566 .WORD ND1MSK ;MASK FOR RMR1
5447 016230 115760 .WORD DPE ;MASK FOR RMR2
5448 016232 000010 BR 91$ ;GO TO 91$ IF NO ERROR
5449 016234 000405 NOP ;RETURN HERE IF ERROR
5450 016236 000240 ERROR ;ERROR # DEFINED BY CMPERRSTS SUBROUTINE
5451 016240 104000 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
5452 016242 004736 JMP 100$ ;GO TO 100$ IF ERROR WAS FOUND
5453 016244 000137 016304 91$: JSR PC,STCDRVSTS ;GO CHECK FOR CHANGES IN DRIVE STATUS
5454 016250 004737 061062 BR 92$ ;GO TO 92$ IF NO ERROR
5455 016254 000405 NOP ;RETURN HERE IF ERROR
5456 016256 000240 ERROR ;ERROR # DEFINED BY STCDRVSTS SUBROUTINE
5457 016260 104000 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
5458 016262 004736 JMP 100$ ;GO TO 100$ IF ERROR WAS FOUND
5459 016264 000137 016304 92$: JSR PC,SECERR ;GO CHECK FOR SECONDARY ERRORS
5460 016270 004737 046044 BR 100$ ;GO TO 100$ IF NO ERROR
5461 016274 000403 NOP ;RETURN HERE IF ERROR
5462 016276 000240 ERROR ;ERROR # DEFINED BY SECERR SUBROUTINE
5463 016276 000240 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
5464 016300 104000 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
5465 016302 004736 100$:
5466 016304
5467 016304
5468
5469
5470
5471
5472 016304
5473 016304 000004
5474 016306 000240
5475 016310 012706 001100
5476 016314 013700 001276
5477 016320 013701 001446
5478 016324 012737 000023 001226
5479
5480 016332 004737 043216 JSR PC,TSTPRP ;PREPARE DEVICE FOR TEST
5481 016336 054130 .WORD ;TASK DESCRIPTOR
5482 016340 000404 BR 70$ ;GO TO 70$ IF NO ERROR
5483 016342 000240 NOP ;RETURN HERE IF ERROR
5484 016344 104000 ERROR ;ERROR # DEFINED BY TSTPRP SUBROUTINE
5485 016346 000137 016724 JMP 180$ ;GO TO 180$ IF ERROR WAS FOUND
5486 016352
5487 016352 112737 000000 001533 70$: MOV #RMCS1,PUTINX ;SETUP PUT INDEX TABLE
5488 016360 112737 000200 001534 MOV #200,PUTINX+1 ;WRITE TERMINATOR
5489 016366 012737 000015 001376 MOV #OFFSET!GO,RMCS10 ;RMCS1 OUTPUT BUFFER = OFFSET!GO
5490 016374 004737 044466 JSR PC,PUT ;CALL PUT SUBROUTINE
5491 016400 000404 BR 80$ ;GO TO 80$ IF NO ERROR
5492 016402 000240 NOP ;RETURN HERE TO REPORT AN ERROR
5493 016404 104000 ERROR ;ERROR NUMBER DEFINED BY PUT SUB
5494 016406 000137 016724 JMP 180$ ;GO TO 180$ IF ERROR WAS FOUND
5495 016412 004737 044132 80$: JSR PC,GETSTS ;SETUP FOR STATUS FETCH
5496 016416 004737 044216 JSR PC,GET ;GO READ REGISTERS VIA GET SUB
5497 016422 000404 BR 90$ ;GO TO 90$ IF NO ERROR
5498 016424 000240 NOP ;RETURN HERE IF ERROR

```

```

*****
:TEST 23 GO/ATA TEST
*****
TST23:

```

```

5499 016426 104000 ERROR ;ERROR DEFINED BY GET SUB
5500 016430 000137 016724 JMP 180$ ;GO TO 180$ IF ERROR WAS FOUND
5501 016434 032737 100000 001340 90$: BIT #ATA,RMDSI ;IS ATTENTION SET??
5502 016442 001012 BNE 100$ ;YES!!
5503 016444 012737 100000 001140 MOV #ATA,$GDDAT ;GOOD DATA FOR TYPEOUT
5504 016452 013737 001340 001142 MOV RMDSI,$BDDAT ;BAD DATA FOR TYPEOUT
5505 016460 042737 077777 001142 BIC #CATA,$BDDAT
5506 016466 104172 ERROR 172 ;REPORT ATA NOT SET
5507 016470 100$:
5508 016470 004737 061566 JSR PC,CMPERRSTS ;CHECK ANY ERRORS NOT MASKED
5509 016474 000000 .WORD 0 ;MASK FOR RMER1
5510 016476 000000 .WORD 0 ;MASK FOR RMER2
5511 016500 000405 BR 110$ ;GO TO 110$ IF NO ERROR
5512 016502 000240 NOP ;RETURN HERE IF ERROR
5513 016504 104000 ERROR ;ERROR # DEFINED BY CMPERRSTS SUBROUTINE
5514 016506 004736 JSR PC,(SP)+ ;GO BACK FOR MORE ERROR CHECKS
5515 016510 000137 016724 JMP 180$ ;GO TO 180$ IF ERROR WAS FOUND
5516 016514 110$:
5517 016514 112737 000000 001533 MOVB #RMCSI,PUTINX ;SETUP PUT INDEX TABLE
5518 016522 112737 000200 001534 MOVB #200,PUTINX+1 ;WRITE TERMINATOR
5519 016530 012737 000001 001376 MOV #NOP!GO,RMCSI0 ;RMCSI OUTPUT BUFFER = NOP!GO
5520 016536 004737 044466 JSR PC,PUT ;CALL PUT SUBROUTINE
5521 016542 000404 BR 120$ ;GO TO 120$ IF NO ERROR
5522 016544 000240 NOP ;RETURN HERE TO REPORT AN ERROR
5523 016546 104000 ERROR ;ERROR NUMBER DEFINED BY PUT SUB
5524 016550 000137 016724 JMP 180$ ;GO TO 180$ IF ERROR WAS FOUND
5525 016554 120$:
5526 016554 004737 044216 JSR PC,GET ;GO READ REGISTERS VIA GET SUB
5527 016560 000404 BR 130$ ;GO TO 130$ IF NO ERROR
5528 016562 000240 NOP ;RETURN HERE IF ERROR
5529 016564 104000 ERROR ;ERROR DEFINED BY GET SUB
5530 016566 000137 016724 JMP 180$ ;GO TO 180$ IF ERROR WAS FOUND
5531 016572 130$:
5532 016572 004737 045212 JSR PC,PRIERR ;GO CHECK FOR PRIMARY ERRORS
5533 016576 000405 BR 140$ ;GO TO 140$ IF NO ERROR
5534 016600 000240 NOP ;RETURN HERE IF ERROR
5535 016602 104000 ERROR ;ERROR # DEFINED BY PRIERR SUBROUTINE
5536 016604 004736 JSR PC,(SP)+ ;GO BACK FOR MORE ERROR CHECKS
5537 016606 000137 016724 JMP 180$ ;GO TO 180$ IF ERROR WAS FOUND
5538 016612 032737 100000 001340 140$: BIT #ATA,RMDSI ;IS ATTENTION RESET??
5539 016620 001411 BEQ 150$ ;YES
5540 016622 013737 001340 001142 MOV RMDSI,$BDDAT ;BAD DATA FOR TYPEOUT
5541 016630 042737 077777 001142 BIC #CATA,$BDDAT
5542 016636 005037 001140 CLR $GDDAT ;GOOD DATA FOR TYPEOUT
5543 016642 104246 ERROR 246 ;REPORT ATA NOT RESET
5544 016644 150$:
5545 016644 004737 061566 JSR PC,CMPERRSTS ;CHECK ANY ERRORS NOT MASKED
5546 016650 115760 .WORD NOTMSK ;MASK FOR RMER1
5547 016652 000010 .WORD DPE ;MASK FOR RMER2
5548 016654 000405 BR 160$ ;GO TO 160$ IF NO ERROR
5549 016656 000240 NOP ;RETURN HERE IF ERROR
5550 016660 104000 ERROR ;ERROR # DEFINED BY CMPERRSTS SUBROUTINE
5551 016662 004736 JSR PC,(SP)+ ;GO BACK FOR MORE ERROR CHECKS
5552 016664 000137 016724 JMP 180$ ;GO TO 180$ IF ERROR WAS FOUND
5553 016670 160$:
5554 016670 004737 061062 JSR PC,STCDRVSTS ;GO CHECK FOR CHANGES IN DRIVE STATUS

```



```

5555 016674 000405 BR 170$ ;GO TO 170$ IF NO ERROR
5556 016676 000240 NOP ;RETURN HERE IF ERROR
5557 016700 104000 ERROR ;ERROR # DEFINED BY STCDRVSTS SUBROUTINE
5558 016702 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
5559 016704 000137 016724 JMP 180$ ;GO TO 180$ IF ERROR WAS FOUND
5560 016710 170$: JSR PC,SECERR ;GO CHECK FOR SECONDARY ERRORS
5561 016710 004737 046044 BR 180$ ;GO TO 180$ IF NO ERROR
5562 016714 000403 NOP ;RETURN HERE IF ERROR
5563 016716 000240 ERROR ;ERROR # DEFINED BY SECERR SUBROUTINE
5564 016720 104000 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
5565 016722 004736 180$:
5566 016724
5567
5568
5569
5570
5571 016724
5572 016724 000004
5573 016726 000240
5574 016730 012706 001100
5575 016734 013700 001276
5576 016740 013701 001446
5577 016744 012737 000024 001226
5578
5579 016752 004737 043216 JSR PC,TSTPRP ;PREPARE DEVICE FOR TEST
5580 016756 054130 .WORD 054130 ;TASK DESCRIPTOR
5581 016760 000404 BR 70$ ;GO TO 70$ IF NO ERROR
5582 016762 000240 NOP ;RETURN HERE IF ERROR
5583 016764 104000 ERROR ;ERROR # DEFINED BY TSTPRP SUBROUTINE
5584 016766 000137 017270 JMP 150$ ;GO TO 150$ IF ERROR WAS FOUND
5585 016772 70$:
5586 016772 112737 000000 001533 MOVB #RMCS1,PUTINX ;SETUP PUT INDEX TABLE
5587 017000 112737 000200 001534 MOVB #200,PUTINX+1 ;WRITE TERMINATOR
5588 017006 012737 000015 001376 MOV #OFFSET!GO,RMCS10 ;RMCS1 OUTPUT BUFFER = OFFSET!GO
5589 017014 004737 044466 JSR PC,PUT ;CALL PUT SUBROUTINE
5590 017020 000404 BR 80$ ;GO TO 80$ IF NO ERROR
5591 017022 000240 NOP ;RETURN HERE TO REPORT AN ERROR
5592 017024 104000 ERROR ;ERROR NUMBER DEFINED BY PUT SUB
5593 017026 000137 017270 JMP 150$ ;GO TO 150$ IF ERROR WAS FOUND
5594 017032 004737 044132 80$: JSR PC,GETSTS ;SETUP FOR STATUS FETCH
5595 017036 004737 044216 JSR PC,GET ;GO READ REGISTERS VIA GET SUB
5596 017042 000404 BR 90$ ;GO TO 90$ IF NO ERROR
5597 017044 000240 NOP ;RETURN HERE IF ERROR
5598 017046 104000 ERROR ;ERROR DEFINED BY GET SUB
5599 017050 000137 017270 JMP 150$ ;GO TO 150$ IF ERROR WAS FOUND
5600 017054 032737 100000 001340 90$: BIT #ATA,RMDSI ;IS ATTENTION SET??
5601 017062 001012 BNE 100$ ;YES!!
5602 017064 013737 001340 001142 MOV RMDSI,$BDDAT ;BAD DATA FOR TYPEOUT
5603 017072 042737 077777 001142 BIC #!CATA,$BDDAT
5604 017100 012737 100000 001140 MOV #ATA,$GDDAT ;GOOD DATA FOR TYPEOUT
5605 017106 104172 ERROR 172 ;REPORT ATA NOT SET
5606 017110 116102 000001 100$: MOVB I(R1),R2 ;R2 = ATTENTION BIT
5607 017114 042702 177400 BIC #!CATNMSK,R2 ;CLEAR SIGN EXTENSION
5608 017120 000240 NOP
5609 017122 010237 001414 MOV R2,RMASO ;PUT RMASO BIT IN OUTPUT BUF
5610 017126 112737 000016 001533 MOVB #RMAS,PUTINX ;WRITE REGISTER INDEX IN TABLE

```

```

*****
:TEST 24 WRITE ATA TEST
*****
TST24:

```

```

5611 017134 112737 000200 001534 MOVB #200,PUTINX+1 ;WRITE TERMINATOR
5612 017142 004737 044466 JSR PC,PUT ;GO WRITE REGISTERS VIA PUT SUB
5613 017146 000404 BR 110$ ;GO TO 110$ IF NO ERROR
5614 017150 000240 NOP ;RETURN HERE IF ERROR
5615 017152 104000 ERROR ;ERROR DEFINED BY PUT SUB
5616 017154 000137 017270 JMP 150$ ;GO TO 150$ IF ERROR WAS FOUND
5617 017160 110$: JSR PC,GET ;GO READ REGISTERS VIA GET SUB
5618 017160 004737 044216 BR 120$ ;GO TO 120$ IF NO ERROR
5619 017164 000404 NOP ;RETURN HERE IF ERROR
5620 017166 000240 ERROR ;ERROR DEFINED BY GET SUB
5621 017170 104000 JMP 150$ ;GO TO 150$ IF ERROR WAS FOUND
5622 017172 000137 017270 120$: JSR PC,PRIERR ;GO CHECK FOR PRIMARY ERRORS
5623 017176 BR 130$ ;GO TO 130$ IF NO ERROR
5624 017176 004737 045212 NOP ;RETURN HERE IF ERROR
5625 017202 000405 ERROR ;ERROR # DEFINED BY PRIERR SUBROUTINE
5626 017204 000240 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
5627 017206 104000 JMP 150$ ;GO TO 150$ IF ERROR WAS FOUND
5628 017210 004736 017270 130$: BIT #ATA,RMDSI ;IS ATTENTION RESET??
5629 017212 000137 017270 BEQ 140$ ;YES!!
5630 017216 032737 100000 001340 MOV RMDSI,$BDDAT ;BAD DATA FOR TYPEOUT
5631 017224 001411 BIC #!CATA,$BDDAT ;GOOD DATA FOR TYPEOUT
5632 017226 013737 001340 CLR $GDDAT ;REPORT ATA NOT RESET
5633 017234 042737 077777 001142 ERROR 247
5634 017242 005037 001140 140$: JSR PC,CMPERRSTS ;CHECK ANY ERRORS NOT MASKED
5635 017246 104247 .WORD 0 ;MASK FOR RMR1
5636 017250 .WORD 0 ;MASK FOR RMR2
5637 017250 004737 061566 BR 150$ ;GO TO 150$ IF NO ERROR
5638 017254 000000 NOP ;RETURN HERE IF ERROR
5639 017256 000000 ERROR ;ERROR # DEFINED BY CMPERRSTS SUBROUTINE
5640 017260 000403 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
5641 017262 000240 150$:
5642 017264 104000
5643 017266 004736
5644 017270
5645
5646
5647
5648
5649
5650 017270 000004
5651 017272 000240
5652 017274 012706 001100
5653 017300 013700 001276
5654 017304 013701 001446
5655 017310 012737 000025 001226
5656
5657 017316 004737 043216 JSR PC,TSTPRP ;PREPARE DEVICE FOR TEST
5658 017322 054130 .WORD 054130 ;TASK DESCRIPTOR
5659 017324 000404 BR 70$ ;GO TO 70$ IF NO ERROR
5660 017326 000240 NOP ;RETURN HERE IF ERROR
5661 017330 104000 ERROR ;ERROR # DEFINED BY TSTPRP SUBROUTINE
5662 017332 000137 017662 JMP 160$ ;GO TO 160$ IF ERROR WAS FOUND
5663 017336 70$:
5664 017336 112737 000000 001533 MOVB #RMCS1,PUTINX ;SETUP PUT INDEX TABLE
5665 017344 112737 000200 001534 MOVB #200,PUTINX+1 ;WRITE TERMINATOR
5666 017352 012737 000015 001376 MOV #OFFSET!GO,RMCS10 ;RMCS1 OUTPUT BUFFER = OFFSET!GO

```

```

*****
;TEST 25 ERROR/ATA TEST
*****
TST25:

```

```

5667 017360 004737 044466 JSR PC PUT ;CALL PUT SUBROUTINE
5668 017364 000404 BR 80$ ;GO TO 80$ IF NO ERROR
5669 017366 000240 NOP ;RETURN HERE TO REPORT AN ERROR
5670 017370 104000 ERROR ;ERROR NUMBER DEFINED BY PUT SUB
5671 017372 000137 017662 JMP 160$ ;GO TO 160$ IF ERROR WAS FOUND
5672 017376 004737 044132 80$: JSR PC.GETSTS ;SETUP FOR STATUS
5673 017402 004737 044216 JSR PC.GET ;GO READ REGISTERS VIA GET SUB
5674 017406 000404 BR 90$ ;GO TO 90$ IF NO ERROR
5675 017410 000240 NOP ;RETURN HERE IF ERROR
5676 017412 104000 ERROR ;ERROR DEFINED BY GET SUB
5677 017414 000137 017662 JMP 160$ ;GO TO 160$ IF ERROR WAS FOUND
5678 017420 032737 100000 001340 90$: BIT #ATA,RMDSI ;IS ATA SET??
5679 017426 001012 BNE 100$ ;YES!!
5680 017430 013737 001340 001142 MOV RMDSI,SBDDAT ;BAD DATA FOR TYPEOUT
5681 017436 042737 077777 001142 BIC #+CATA,SBDDAT
5682 017444 012737 100000 001140 MOV #ATA,$GDDAT ;GOOD DATA FOR TYPEOUT
5683 017452 104172 ERROR 172 ;REPORT ATA NOT SET
5684 017454 100$:
5685 017454 112737 000014 001533 MOVB #RMER1,PUTINX ;SETUP PUT INDEX TABLE
5686 017462 112737 000200 001534 MOVB #200,PUTINX+1 ;WRITE TERMINATOR BYTE
5687 017470 012737 040000 001412 MOV #UNS,RMER10 ;RMER1 OUTPUT BUFFER = UNS
5688 017476 004737 044466 JSR PC.PUT ;WRITE RMER1 VIA PUT SUB
5689 017502 000404 BR 110$ ;GO TO 110$ IF NO ERROR
5690 017504 000240 NOP ;RETURN HERE TO REPORT ERROR
5691 017506 104000 ERROR ;ERROR NUMBER DEFINED BY PUT SUB
5692 017510 000137 017662 JMP 160$ ;GO TO 160$ IF ERROR WAS FOUND
5693 017514 110$:
5694 017514 112737 000000 001533 MOVB #RMCS1,PUTINX ;SETUP PUT INDEX TABLE
5695 017522 112737 000200 001534 MOVB #200,PUTINX+1 ;WRITE TERMINATOR
5696 017530 012737 000001 001376 MOV #NOP!GO,RMCS10 ;RMCS1 OUTPUT BUFFER = NOP!GO
5697 017536 004737 044466 JSR PC.PUT ;CALL PUT SUBROUTINE
5698 017542 000404 BR 120$ ;GO TO 120$ IF NO ERROR
5699 017544 000240 NOP ;RETURN HERE TO REPORT AN ERROR
5700 017546 104000 ERROR ;ERROR NUMBER DEFINED BY PUT SUB
5701 017550 000137 017662 JMP 160$ ;GO TO 160$ IF ERROR WAS FOUND
5702 017554 120$:
5703 017554 004737 044216 JSR PC.GET ;GO READ REGISTERS VIA GET SUB
5704 017560 000404 BR 130$ ;GO TO 130$ IF NO ERROR
5705 017562 000240 NOP ;RETURN HERE IF ERROR
5706 017564 104000 ERROR ;ERROR DEFINED BY GET SUB
5707 017566 000137 017662 JMP 160$ ;GO TO 160$ IF ERROR WAS FOUND
5708 017572 032737 100000 001340 130$: BIT #ATA,RMDSI ;IS ATA STILL SET??
5709 017600 001012 BNE 140$ ;YES!!
5710 017602 012737 100000 001140 MOV #ATA,$GDDAT ;GOOD DATA FOR TYPEOUT
5711 017610 013737 001340 001142 MOV RMDSI,SBDDAT ;BAD DATA FOR TYPEOUT
5712 017616 042737 077777 001142 BIC #+CATA,SBDDAT
5713 017624 104250 ERROR 250 ;ATA SHOULD NOT RESET
5714 017626 140$:
5715 017626 004737 061062 JSR PC.STCDRVSTS ;GO CHECK FOR CHANGES IN DRIVE STATUS
5716 017632 000405 BR 150$ ;GO TO 150$ IF NO ERROR
5717 017634 000240 NOP ;RETURN HERE IF ERROR
5718 017636 104000 ERROR ;ERROR # DEFINED BY STCDRVSTS SUBROUTINE
5719 017640 004736 JSR PC.(SP)+ ;GO BACK FOR MORE ERROR CHECKS
5720 017642 000137 017662 JMP 160$ ;GO TO 160$ IF ERROR WAS FOUND
5721 017646 150$:
5722 017646 004737 046044 JSR PC,SECERR ;GO CHECK FOR SECONDARY ERRORS

```

```

5723 017652 000403 BR 160$ ;GO TO 160$ IF NO ERROR
5724 017654 000240 NOP ;RETURN HERE IF ERROR
5725 017656 104000 ERROR ;ERROR # DEFINED BY SECERR SUBROUTINE
5726 017660 004736 JSR PC,2(SP)+ ;GO BACK FOR MORE ERROR CHECKS
5727 017662
5728
5729
5730
5731
5732 017662
5733 017662 000004
5734 017664 000240
5735 017666 012706 001100
5736 017672 013700 001276
5737 017676 013701 001446
5738 017702 012737 000026 001226
5739
5740 017710 004737 043216
5741 017714 054130
5742 017716 000404
5743 017720 000240
5744 017722 104000
5745 017724 000137 020330
5746
5747 017730 113702 001272
5748 017734 042702 177400
5749 017740 011204
5750 017742 016205 000002
5751 017746 012712 020202
5752 017752 012762 000300 000002
5753 017760 113703 001273
5754 017764 042703 177400
5755 017770 000303
5756 017772 005303
5757 017774 100001
5758 017776 005003
5759 020000 042703 177437
5760 020004 000240
5761 020006 012746 000300
5762 020012 012746 020140
5763 020016 010346
5764 020020 012746 020132
5765 020024 012737 177777 001414
5766 020032 112737 000016 001533
5767 020040 112737 000200 001533
5768 020046 004737 044466
5769 020052 000402
5770 020054 000240
5771 020056 104000
5772 020060
5773 020060 112737 000000 001533
5774 020066 112737 000200 001534
5775 020074 012737 000115 001376
5776 020102 004737 044466
5777 020106 000402
5778 020110 000240

160$:
*****
;TEST 26 PROGRAM INTERRUPT TEST
*****
TST26:
SCOPE ;SCOPE CALL
NOP ;START OF TEST
MOV #STACK,SP ;INITIALIZE STACK POINTER
MOV $BASE,R0 ;R0=UNIBUS ADDRESS
MOV TSTQUE,R1 ;(R1) = DEVICE BEING TESTED
MOV #26,$TSTN ;SET TEST NUMBER IN APT MAIL BOX

JSR PC,TSTPRP ;PREPARE DEVICE FOR TEST
WORD 054130 ;TASK DESCRIPTOR
BR 70$ ;GO TO 70$ IF NO ERROR
NOP ;RETURN HERE IF ERROR
ERROR ;ERROR # DEFINED BY TSTPRP SUBROUTINE
JMP 210$ ;GO TO 210$ IF ERROR WAS FOUND

70$:
MOVB $VECT1,R2 ;R2 = RMO3 INTERRUPT ADDRESS
BIC #1C<377>,R2 ;CLEAR SIGN EXTENSION
MOV (R2),R4 ;SAVE HANDLER ADDRESS
MOV 2(R2),R5 ;SAVE HANDLER PRIORITY
MOV #150$,(R2) ;WRITE HANDLER ADDRESS AND
;PRIORITY FOR THIS TEST
MOVB $VECT1+1,R3 ;R3 = RMO3 INTERRUPT LEVEL
BIC #1C<377>,R3 ;CLEAR SIGN EXTENSION
SWAB R3
DEC R3 ;DECREMENT INTERRUPT LEVEL
BPL 80$
CLR R3

80$:
BIC #1CPR7,R3
NOP
MOV #PR6,-(SP) ;;PUSH #PR6 ON STACK
MOV #120$,-(SP) ;;PUSH #120$ ON STACK
MOV R3,-(SP) ;;PUSH R3 ON STACK
MOV #110$,-(SP) ;;PUSH #110$ ON STACK
MOV #-1,RMAS0 ;WRITE ONES IN RMAS TO
MOVB #RMAS,PUTINX ;CLEAR ALL ATTENTIONS
MOV #200,PUTINX
JSR PC,PUT ;GO WRITE REGISTERS VIA PUT SUB
BR 90$ ;GO TO 90$ IF NO ERROR
NOP ;RETURN HERE IF ERROR
ERROR ;ERROR DEFINED BY PUT SUB

90$:
MOVB #RMCS1,PUTINX ;SETUP PUT INDEX TABLE
MOVB #200,PUTINX+1 ;WRITE TERMINATOR
MOV #OFFSET!GO!IE,RMCS10 ;RMCS1 OUTPUT BUFFER = OFFSET!GO!IE
JSR PC,PUT ;CALL PUT SUBROUTINE
BR 100$ ;GO TO 100$ IF NO ERROR
NOP ;RETURN HERE TO REPORT AN ERROR

```

```

5779 020112 104000          ERROR          ;ERROR NUMBER DEFINED BY PUT SUB
5780 020114 004737 045026 100$: JSR      PC,TIMOUT ;WAIT FOR COMPLETION
5781 020120 004737 044132      JSR      PC,GETSTS ;SETUP FOR STATUS
5782 020124 012703 000205      MOV      #205,R3    ;R3=GROSS TIMEOUT
5783 020130 000002          RTI          ;DROP CP PRIORITY
5784 020132 005303          110$: DEC      R3    ;TIMEOUT THE INTERRUPT
5785 020134 100376          BPL      110$
5786          ;TIMEOUT BEFORE INTERRUPT
5787 020136 000002          RTI          ;RAISE CP PRIORITY
5788 020140          120$: JSR      PC,GET    ;GO READ REGISTERS VIA GET SUB
5789 020140 004737 044216      BR      130$ ;GO TO 130$ IF NO ERROR
5790 020144 000404          NOP          ;RETURN HERE IF ERROR
5791 020146 000240          ERROR      ;ERROR DEFINED BY GET SUB
5792 020150 104000          JMP      210$ ;GO TO 210$ IF ERROR WAS FOUND
5793 020152 000137 020330      130$: JSR      PC,PRIERR ;GO CHECK FOR PRIMARY ERRORS
5794 020156 004737 045212      BR      140$ ;GO TO 140$ IF NO ERROR
5795 020156 000405          NOP          ;RETURN HERE IF ERROR
5796 020162 000240          ERROR      ;ERROR # DEFINED BY PRIERR SUBROUTINE
5797 020164 000240          JSR      PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
5798 020166 104000          JMP      210$ ;GO TO 210$ IF ERROR WAS FOUND
5799 020170 004736          140$: ERROR      251 ;REPORT NO INTERRUPT
5800 020172 000137 020330      BR      180$
5801 020176 104251          150$: CMP      (SP)+,(SP)+ ;ADJUST STACK
5802 020200 000423          MOV      #160$,(SP) ;CHANGE RETURN ADDRESS
5803          RTI          ;RAISE CP PRIORITY
5804 020202 022626          160$: JSR      PC,GET    ;GO READ REGISTERS VIA GET SUB
5805 020204 012716 020212      BR      170$ ;GO TO 170$ IF NO ERROR
5806 020210 000002          NOP          ;RETURN HERE IF ERROR
5807 020212 004737 044216      ERROR      ;ERROR DEFINED BY GET SUB
5808 020216 000404          JMP      210$ ;GO TO 210$ IF ERROR WAS FOUND
5809 020220 000240          170$: JSR      PC,PRIERR ;GO CHECK FOR PRIMARY ERRORS
5810 020222 104000          BR      180$ ;GO TO 180$ IF NO ERROR
5811 020224 000137 020330      NOP          ;RETURN HERE IF ERROR
5812 020230 004737 045212      ERROR      ;ERROR # DEFINED BY PRIERR SUBROUTINE
5813 020234 000405          JSR      PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
5814 020236 000240          JMP      210$ ;GO TO 210$ IF ERROR WAS FOUND
5815 020240 104000          180$: JSR      PC,CMPESTS ;CHECK ANY ERRORS NOT MASKED
5816 020242 004736          .WORD   ND1MSK ;MASK FOR RMR1
5817 020244 000137 020330      .WORD   DPE    ;MASK FOR RMR2
5818 020250 000250          BR      190$ ;GO TO 190$ IF NO ERROR
5819 020254 004737 061566      NOP          ;RETURN HERE IF ERROR
5820 020256 000010          ERROR      ;ERROR # DEFINED BY CMPESTS SUBROUTINE
5821 020260 000405          JSR      PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
5822 020262 000240          JMP      210$ ;GO TO 210$ IF ERROR WAS FOUND
5823 020264 104000          190$: JSR      PC,STCDRVSTS ;GO CHECK FOR CHANGES IN DRIVE STATUS
5824 020266 004736          BR      200$ ;GO TO 200$ IF NO ERROR
5825 020270 000137 020330      NOP          ;RETURN HERE IF ERROR
5826 020274 004737 061062      ERROR      ;ERROR # DEFINED BY STCDRVSTS SUBROUTINE
5827 020276 000240          JSR      PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
5828 020280 000137 020330      200$: JSR      PC,@(SP)+
5829 020284 004737 061062
5830 020300 000405
5831 020302 000240
5832 020304 104000
5833 020306 004736

```

```

5835 020310 000137 020330          JMP      210$          ;GO TO 210$ IF ERROR WAS FOUND
5836 020314          200$:          JSR      PC,SECERR    ;GO CHECK FOR SECONDARY ERRORS
5837 020314 004737 046044          BR       210$          ;GO TO 210$ IF NO ERROR
5838 020320 000403          NOP          ;RETURN HERE IF ERROR
5839 020322 000240          ERROR     ;ERROR # DEFINED BY SECERR SUBROUTINE
5840 020324 104000          JSR      PC,@(SP)+   ;GO BACK FOR MORE ERROR CHECKS
5841 020326 004736          210$:      MOV     R4,(R2)
5842 020330 010412          MOV     R5,2(R2)
5843 020332 010562 000002          ;*****
5844          ;*TEST 27 INHIBIT INTERRUPT TEST
5845          ;*****
5846          TST27:
5847 020336          SCOPE          ;SCOPE CALL
5848 020336 000004          NOP          ;START OF TEST
5849 020340 000240          MOV     @STACK,SP   ;INITIALIZE STACK POINTER
5850 020342 012706 001100          MOV     @BASE,R0     ;R0=UNIBUS ADDRESS
5851 020346 013700 001276          MOV     TSTQUE,R1    ; (R1) = DEVICE BEING TESTED
5852 020352 013701 001446          MOV     @27,$TSTN    ; ;SET TEST NUMBER IN APT MAIL BOX
5853 020356 012737 000027 001226          JSR      PC,TSTPRP   ;PREPARE DEVICE FOR TEST
5854          .WORD 054130 ;TASK DESCRIPTOR
5855 020364 004737 043216          BR       70$          ;GO TO 70$ IF NO ERROR
5856 020370 054130          NOP          ;RETURN HERE IF ERROR
5857 020372 000404          ERROR     ;ERROR # DEFINED BY TSTPRP SUBROUTINE
5858 020374 000240          JMP      210$        ;GO TO 210$ IF ERROR WAS FOUND
5859 020376 104000          70$:      MOV     $VECT1,R2    ;R2 = RMO3 INTERRUPT ADDRESS
5860 020400 000137 020670          BIC     @C<37>,R2    ;CLEAR SIGN EXTENSION
5861 020404 113702 001272          MOV     (R2),R4      ;SAVE HANDLER ADDRESS
5862 020410 042702 177400          MOV     2(R2),R5     ;SAVE HANDLER PRIORITY
5863 020414 011204          MOV     #130$(R2)    ;WRITE HANDLER ADDRESS AND
5864 020416 016205 000002          MOV     @PR6,2(R2)   ;PRIORITY FOR THIS TEST
5865 020422 012712 020634          MOV     $VECT1+1,R3 ;R3 = RMO3 INTERRUPT LEVEL
5866 020426 012762 000300 000002          BIC     @C<37>,R3    ;CLEAR SIGN EXTENSION
5867 020434 113703 001273          MOV     @PR6,-(SP)   ;PUSH #PR6 ON STACK
5868 020440 042703 177400          MOV     #180$,-(SP) ;PUSH #180$ ON STACK
5869 020444 012746 000300          MOV     R3,-(SP)    ;PUSH R3 ON STACK
5870 020450 012746 020662          DEC     (SP)
5871 020454 010346          BPL     80$          ;PUSH #120$ ON STACK
5872 020456 005316          CLR     (SP)        ;PUSH R3 ON STACK
5873 020460 100001          BIC     @CPR7,(SP)   ;PUSH #100$ ON STACK
5874 020462 005016          MOV     #120$,-(SP) ;PUSH #100$ ON STACK
5875 020464 042716 177437          MOV     R3,-(SP)    ;PUSH #100$ ON STACK
5876 020470 012746 020622          MOV     @100$,-(SP) ;PUSH #100$ ON STACK
5877 020474 010346          JSR     PC,GETSTS    ;SETUP FOR STATUS
5878 020476 012746 020554          MOV     @RMCS1,PUTINX ;SETUP PUT INDEX TABLE
5879 020502 004737 044132          MOV     #200,PUTINX+1 ;WRITE TERMINATOR
5880 020506 112737 000000 001533          MOV     @OFFSET!GO!IE,RMCS10 ;RMCS1 OUTPUT BUFFER = OFFSET!GO!IE
5881 020514 112737 000200 001534          JSR     PC,PUT       ;CALL PUT SUBROUTINE
5882 020522 012737 000115 001376          BR      90$          ;GO TO 90$ IF NO ERROR
5883 020530 004737 044466          NOP          ;RETURN HERE TO REPORT AN ERROR
5884 020534 000402          ERROR     ;ERROR NUMBER DEFINED BY PUT SUB
5885 020536 000240          90$:      JSR     PC,TIMOUT   ;WAIT FOR GO=0
5886 020540 104000          MOV     #205,R3     ;R3=GROSS TIMER
5887 020542 004737 045026          RTI          ;MAKE PRIORITY=RMO1
5888 020546 012703 000205          100$:     DEC     R3     ;DELAY
5889 020552 000002
5890 020554 005303

```

```

5891 020556 100376          BPL      100$
5892 020560 112737 000000 001533  MOVB   #RMCS1,PUTINX ;SETUP PUT INDEX TABLE
5893 020566 112737 000200 001534  MOVB   #200,PUTINX+1 ;WRITE TERMINATOR
5894 020574 012737 000000 001376  MOV    #NOP,RMCS10 ;RMCS1 OUTPUT BUFFER = NOP
5895 020602 004737 044466          JSR    PC,PUT      ;CALL PUT SUBROUTINE
5896 020606 000402          BR     110$ ;GO TO 110$ IF NO ERROR
5897 020610 000240          NOP
5898 020612 104000          ERROR  ;RETURN HERE TO REPORT AN ERROR
5899 020614 012703 000205 110$:   MOV    #205,R3      ;ERROR NUMBER DEFINED BY PUT SUB
5900 020620 000002          RTI
5901 020622 012712 020636 120$:   MOV    #140$(R2) ;MAKE PRIORITY < RM01
5902 020626 005303 125$:   DEC    R3
5903 020630 100376          BPL    125$
5904 020632 000002          RTI ;NO ERROR
5905 020634 022626 130$:   CMP    (SP)+,(SP)+ ;ADJUST STACK
5906 020636 022626 140$:   CMP    (SP)+,(SP)+ ;ADJUST STACK
5907 020640 012716 020646          MOV    #160$(SP)
5908 020644 000002          RTI
5909 020646          ;
5910 020646 004737 044216 160$:   JSR    PC,GET      ;GO READ REGISTERS VIA GET SUB
5911 020652 000402          BR     170$ ;GO TO 170$ IF NO ERROR
5912 020654 000240          NOP
5913 020656 104000          ERROR  ;RETURN HERE IF ERROR
5914 020660 104252          ERROR  ;ERROR DEFINED BY GET SUB
5915 020662 010412 170$:   ERROR  252 ;SHOULD NOT HAVE INTERRUPT
5916 020664 010562 000002 180$:   MOV    R4,(R2)
5917 020670          MOV    R5,2(R2)
5918          ;
5919          ;*****
5920          ;*TEST 30 RETURN TO CENTERLINE TEST
5921          ;*****
5921 020670          †ST30:
5922 020670 000004          SCOPE ;SCOPE CALL
5923 020672 000240          NOP ;START OF TEST
5924 020674 012706 001100  MOV    #STACK,SP ;INITIALIZE STACK POINTER
5925 020700 013700 001276  MOV    $BASE,R0 ;R0=UNIBUS ADDRESS
5926 020704 013701 001446  MOV    TSTQUE,R1 ;(R1) = DEVICE BEING TESTED
5927 020710 012737 000030 001226  MOV    #30,$TESTN ;SET TEST NUMBER IN APT MAIL BOX
5928 020716 004737 043216  JSR    PC,TSTPRP ;PREPARE DEVICE FOR TEST
5929 020722 054130          .WORD 054130 ;TASK DESCRIPTOR
5930 020724 000404          BR     70$ ;GO TO 70$ IF NO ERROR
5931 020726 000240          NOP ;RETURN HERE IF ERROR
5932 020730 104000          ERROR  ;ERROR # DEFINED BY TSTPRP SUBROUTINE
5933 020732 000137 021212  JMP    150$ ;GO TO 150$ IF ERROR WAS FOUND
5934 020736          ;
5935 020736 112737 000000 001533 70$:   MOVB   #RMCS1,PUTINX ;SETUP PUT INDEX TABLE
5936 020744 112737 000200 001534  MOVB   #200,PUTINX+1 ;WRITE TERMINATOR
5937 020752 012737 000017 001376  MOV    #RTC!GO,RMCS10 ;RMCS1 OUTPUT BUFFER = RTC!GO
5938 020760 004737 044466          JSR    PC,PUT      ;CALL PUT SUBROUTINE
5939 020764 000404          BR     80$ ;GO TO 80$ IF NO ERROR
5940 020766 000240          NOP
5941 020770 104000          ERROR  ;RETURN HERE TO REPORT AN ERROR
5942 020772 000137 021212  JMP    150$ ;GO TO 150$ IF ERROR WAS FOUND
5943 020776 004737 044132 80$:   JSR    PC,GETSTS ;SETUP FOR STATUS FETCH
5944 021002 004737 045026          JSR    PC,TIMOUT ;WAIT FOR RECAL TO COMPLETE
5945 021006 004737 044216          JSR    PC,GET      ;GO READ REGISTERS VIA GET SUB
5946 021012 000404          BR     90$ ;GO TO 90$ IF NO ERROR

```

```

5947 021014 000240      NOP      ;RETURN HERE IF ERROR
5948 021016 104000      ERROR   ;ERROR DEFINED BY GET SUB
5949 021020 000137 021212  JMP     150$ ;GO TO 150$ IF ERROR WAS FOUND
5950 021024          90$:
5951 021024 004737 045212  JSR     PC,PRIERR ;GO CHECK FOR PRIMARY ERRORS
5952 021030 000405          BR     100$ ;GO TO 100$ IF NO ERROR
5953 021032 000240      NOP     ;RETURN HERE IF ERROR
5954 021034 104000      ERROR   ;ERROR # DEFINED BY PRIERR SUBROUTINE
5955 021036 004736      JSR     PC,2(SP)+ ;GO BACK FOR MORE ERROR CHECKS
5956 021040 000137 021212  JMP     150$ ;GO TO 150$ IF ERROR WAS FOUND
5957 021044 032737 000001 001340 100$:  BIT     #OM,RMSI ;OFFSET MODE OFF??
5958 021052 001411          BEQ     110$ ;YES!!
5959 021054 005037 001140      CLR     $GDDAT ;GOOD DATA FOR TYPEOUT
5960 021060 013737 001340 001142  MOV     RMSI,$BDDAT ;BAD DATA FOR TYPEOUT
5961 021066 042737 177776 001142  BIC     #↑COM,$BDDAT
5962 021074 104157          ERROR   157 ;OFFSET MODE NOT RESET
5963 021076 032737 100000 001340 110$:  BIT     #ATA,RMSI ;WAS ATTENTION SET ??
5964 021104 001012          BNE     120$ ;YES!!
5965 021106 013737 001340 001142  MOV     RMSI,$BDDAT ;BAD DATA FOR TYPEOUT
5966 021114 042737 077777 001142  BIC     #↑CATA,$BDDAT
5967 021122 012737 100000 001140  MOV     #ATA,$GDDAT ;GOOD DATA FOR TYPEOUT
5968 021130 104171          ERROR   171 ;"ATA" NOT SET DURING RTC
5969 021132          120$:
5970 021132 004737 061566  JSR     PC,CMPERRSTS ;CHECK ANY ERRORS NOT MASKED
5971 021136 115760          .WORD  ND↑MSK ;MASK FOR RMER1
5972 021140 000010          .WORD  DPE ;MASK FOR RMER2
5973 021142 000405          BR     130$ ;GO TO 130$ IF NO ERROR
5974 021144 000240      NOP     ;RETURN HERE IF ERROR
5975 021146 104000      ERROR   ;ERROR # DEFINED BY CMPERRSTS SUBROUTINE
5976 021150 004736      JSR     PC,2(SP)+ ;GO BACK FOR MORE ERROR CHECKS
5977 021152 000137 021212  JMP     150$ ;GO TO 150$ IF ERROR WAS FOUND
5978 021156          130$:
5979 021156 004737 061062  JSR     PC,STCDRVSTS ;GO CHECK FOR CHANGES IN DRIVE STATUS
5980 021162 000405          BR     140$ ;GO TO 140$ IF NO ERROR
5981 021164 000240      NOP     ;RETURN HERE IF ERROR
5982 021166 104000      ERROR   ;ERROR # DEFINED BY STCDRVSTS SUBROUTINE
5983 021170 004736      JSR     PC,2(SP)+ ;GO BACK FOR MORE ERROR CHECKS
5984 021172 000137 021212  JMP     150$ ;GO TO 150$ IF ERROR WAS FOUND
5985 021176          140$:
5986 021176 004737 046044  JSR     PC,SECERR ;GO CHECK FOR SECONDARY ERRORS
5987 021202 000403          BR     150$ ;GO TO 150$ IF NO ERROR
5988 021204 000240      NOP     ;RETURN HERE IF ERROR
5989 021206 104000      ERROR   ;ERROR # DEFINED BY SECERR SUBROUTINE
5990 021210 004736      JSR     PC,2(SP)+ ;GO BACK FOR MORE ERROR CHECKS
5991 021212          150$:
5992
5993 ;*****
5994 ;*TEST 31 READ IN PRESET TEST
5995 ;*****
5996
5997 †ST31:
5998 021212 000004      SCOPE ;SCOPE CALL
5999 021214 000240      NOP ;START OF TEST
6000 021216 012706 001100  MOV     #STACK,SP ;INITIALIZE STACK POINTER
6001 021222 013700 001276  MOV     $BASE,R0 ;R0=UNIBUS ADDRESS
6002 021226 013701 001446  MOV     TSTQUE,R1 ;(R1) = DEVICE BEING TESTED

```



```

6003 021232 012737 000031 001226 MOV #31,$TESTN ;;SET TEST NUMBER IN APT MAIL BOX
6004
6005 021240 004737 043216 JSR PC,TSTPRP ;PREPARE DEVICE FOR TEST
6006 021244 054130 .WORD 054130 ;TASK DESCRIPTOR
6007 021246 000404 BR 70$ ;GO TO 70$ IF NO ERROR
6008 021250 000240 NOP ;RETURN HERE IF ERROR
6009 021252 104000 ERROR ;ERROR # DEFINED BY TSTPRP SUBROUTINE
6010 021254 000137 021574 JMP 160$ ;GO TO 160$ IF ERROR WAS FOUND
6011 021260
70$:
6012 021260 012702 001533 MOV #PUTINX,R2 ;R2 POINTS TO INDEX TABLE
6013 021264 112722 000006 MOVB #RMDA,(R2)+
6014 021270 112722 000034 MOVB #RMDC,(R2)+
6015 021274 112722 000032 MOVB #RMOF,(R2)+
6016 021300 112722 000000 MOVB #RMCS1,(R2)+
6017 021304 112722 000200 MOVB #200,(R2)+
6018 021310 012737 177777 001404 MOV #-1,RMDAO
6019 021316 012737 177777 001432 MOV #-1,RMDCO
6020 021324 012737 016200 001430 MOV #FMT16!ECI!HCI!OFD,RMOFO
6021 021332 012737 000021 001376 MOV #RIP!GO,RMCS10
6022 021340 004737 044466 JSR PC,PUT ;GO WRITE REGISTERS VIA PUT SUB
6023 021344 000404 BR 80$ ;GO TO 80$ IF NO ERROR
6024 021346 000240 NOP ;RETURN HERE IF ERROR
6025 021350 104000 ERROR ;ERROR DEFINED BY PUT SUB
6026 021352 000137 021574 JMP 160$ ;GO TO 160$ IF ERROR WAS FOUND
6027 021356 004737 044132 80$: JSR PC,GETSTS ;SETUP FOR STATUS FETCH
6028 021362 004737 045026 JSR PC,TIMOUT ;WAIT FOR RIP TO COMPLETE
6029 021366 004737 044216 JSR PC,GET ;GO READ REGISTERS VIA GET SUB
6030 021372 000404 BR 90$ ;GO TO 90$ IF NO ERROR
6031 021374 000240 NOP ;RETURN HERE IF ERROR
6032 021376 104000 ERROR ;ERROR DEFINED BY GET SUB
6033 021400 000137 021574 JMP 160$ ;GO TO 160$ IF ERROR WAS FOUND
6034 021404
90$:
6035 021404 004737 045212 JSR PC,PRIERR ;GO CHECK FOR PRIMARY ERRORS
6036 021410 000405 BR 100$ ;GO TO 100$ IF NO ERROR
6037 021412 000240 NOP ;RETURN HERE IF ERROR
6038 021414 104000 ERROR ;ERROR # DEFINED BY PRIERR SUBROUTINE
6039 021416 004736 JSR PC,(SP)+ ;GO BACK FOR MORE ERROR CHECKS
6040 021420 000137 021574 JMP 160$ ;GO TO 160$ IF ERROR WAS FOUND
6041 021424 013737 001360 001142 100$: MOV RMOFI,$BDDAT ;IS RMOF RESET??
6042 021432 042737 161577 001142 BIC #C<FMT16!ECI!HCI!OFD>,$BDDAT
6043 021440 001403 BEQ 110$ ;YES!!
6044 021442 005037 001140 CLR $GDDAT ;GOOD DATA FOR TYPEOUT
6045 021446 104160 ERROR 160 ;RMOF NOT CLEARED BY RIP
6046 021450 005737 001334 110$: TST RMDAI ;IS RMDA RESET??
6047 021454 001406 BEQ 120$ ;YES!!
6048 021456 013737 001334 001142 MOV RMDAI,$BDDAT ;BAD DATA FOR TYPEOUT
6049 021464 005037 001140 CLR $GDDAT ;GOOD DATA FOR TYPEOUT
6050 021470 104161 ERROR 161 ;RMDA NOT CLEARED BY RIP
6051 021472 005737 001362 120$: TST RMDCI ;IS RMDC RESET??
6052 021476 001406 BEQ 130$ ;YES!!
6053 021500 013737 001362 001142 MOV RMDCI,$BDDAT ;BAD DATA FOR TYPEOUT
6054 021506 005037 001140 CLR $GDDAT ;GOOD DATA FOR TYPEOUT
6055 021512 104162 ERROR 162 ;RMDC NOT CLEARED BY RIP
6056 021514
130$:
6057 021514 004737 061566 JSR PC,CPERRSTS ;CHECK ANY ERRORS NOT MASKED
6058 021520 115760 .WORD ND↑MSK ;MASK FOR RMER1

```

```
6059 021522 000010 .WORD DPE ;MASK FOR RMER2
6060 021524 000405 BR 140$ ;GO TO 140$ IF NO ERROR
6061 021526 000240 NOP ;RETURN HERE IF ERROR
6062 021530 104000 ERROR ;ERROR # DEFINED BY CMPERRSTS SUBROUTINE
6063 021532 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
6064 021534 000137 021574 JMP 160$ ;GO TO 160$ IF ERROR WAS FOUND
6065 021540 140$: JSR PC,STCDRVSTS ;GO CHECK FOR CHANGES IN DRIVE STATUS
6066 021540 004737 061062 BR 150$ ;GO TO 150$ IF NO ERROR
6067 021544 000405 NOP ;RETURN HERE IF ERROR
6068 021546 000240 ERROR ;ERROR # DEFINED BY STCDRVSTS SUBROUTINE
6069 021550 104000 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
6070 021552 004736 021574 JMP 160$ ;GO TO 160$ IF ERROR WAS FOUND
6071 021554 000137 150$: JSR PC,SECERR ;GO CHECK FOR SECONDARY ERRORS
6072 021560 004737 046044 BR 160$ ;GO TO 160$ IF NO ERROR
6073 021560 000403 NOP ;RETURN HERE IF ERROR
6074 021564 000240 ERROR ;ERROR # DEFINED BY SECERR SUBROUTINE
6075 021566 000240 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
6076 021570 104000 160$: JSR PC,SECERR ;GO CHECK FOR SECONDARY ERRORS
6077 021572 004736 BR 160$ ;GO TO 160$ IF NO ERROR
6078 021574 160$: JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
6079
6080
6081
6082
6083 021574
6084 021574 000004
6085 021576 000240
6086 021600 012706 001100
6087 021604 013700 001276
6088 021610 013701 001446
6089 021614 012737 000032 001226
6090
6091 021622 004737 043216 JSR PC,TSTPRP ;PREPARE DEVICE FOR TEST
6092 021626 054130 054130 ;TASK DESCRIPTOR
6093 021630 000404 BR 70$ ;GO TO 70$ IF NO ERROR
6094 021632 000240 NOP ;RETURN HERE IF ERROR
6095 021634 104000 ERROR ;ERROR # DEFINED BY TSTPRP SUBROUTINE
6096 021636 000137 022112 JMP 140$ ;GO TO 140$ IF ERROR WAS FOUND
6097 021642 70$: MOV #RMCS1,PUTINX ;SETUP PUT INDEX TABLE
6098 021642 112737 000000 001533 MOV #200,PUTINX+1 ;WRITE TERMINATOR
6099 021650 112737 000200 001534 MOV #OFFSET!GO,RMCS10 ;RMCS1 OUTPUT BUFFER = OFFSET!GO
6100 021656 012737 000015 001376 JSR PC,PUT ;CALL PUT SUBROUTINE
6101 021664 004737 044466 BR 80$ ;GO TO 80$ IF NO ERROR
6102 021670 000404 BR 80$ ;GO TO 80$ IF NO ERROR
6103 021672 000240 NOP ;RETURN HERE TO REPORT AN ERROR
6104 021674 104000 ERROR ;ERROR NUMBER DEFINED BY PUT SUB
6105 021676 000137 022112 JMP 140$ ;GO TO 140$ IF ERROR WAS FOUND
6106 021702 004737 044132 80$: JSR PC,GETSTS ;SETUP FOR STATUS
6107 021706 004737 044216 JSR PC,GET ;GO READ REGISTERS VIA GET SUB
6108 021712 000404 BR 90$ ;GO TO 90$ IF NO ERROR
6109 021714 000240 NOP ;RETURN HERE IF ERROR
6110 021716 104000 ERROR ;ERROR DEFINED BY GET SUB
6111 021720 000137 022112 JMP 140$ ;GO TO 140$ IF ERROR WAS FOUND
6112 021724 90$: JSR PC,PRIERR ;GO CHECK FOR PRIMARY ERRORS
6113 021724 004737 045212 BR 100$ ;GO TO 100$ IF NO ERROR
6114 021730 000405
```

```

6115 021732 000240      NOP
6116 021734 104000      ERROR
6117 021736 004736      JSR PC,3(SP)+
6118 021740 000137 022112    JMP 140$
6119 021744 032737 000001 001340 100$: BIT #0M,RMSI
6120 021752 001013      BNE 110$
6121 021754 013737 001340 001142    MOV RMSI,$BDDAT
6122 021762 042737 177776 001142    BIC #1COM,$BDDAT
6123 021770 012737 000001 001140    MOV #0M,$GDDAT
6124 021776 104156      ERROR
6125 022000 000444      BR 140$
6126 022002
6127 022002 012737 000000 001432 110$: MOV #0,RMDCO
6128 022010 112737 000034 001533    MOVB #RMDC,PUTINX
6129 022016 112737 000200 001534    MOVB #200,PUTINX+1
6130 022024 004737 044466    JSR PC,PUT
6131 022030 000404      BR 120$
6132 022032 000240      NOP
6133 022034 104000      ERROR
6134 022036 000137 022112    JMP 140$
6135 022042
6136 022042 004737 044216 120$: JSR PC,GET
6137 022046 000404      BR 130$
6138 022050 000240      NOP
6139 022052 104000      ERROR
6140 022054 000137 022112    JMP 140$
6141 022060 032737 000001 001340 130$: BIT #0M,RMSI
6142 022066 001411      BEQ 140$
6143 022070 013737 001340 001142    MOV RMSI,$BDDAT
6144 022076 042737 177776 001142    BIC #1COM,$BDDAT
6145 022104 005037 001140    CLR $GDDAT
6146 022110 104253      ERROR
6147 022112      140$:
6148
6149
6150
6151
6152 022112
6153 022112 000004      TST33:
6154 022114 000240      SCOPE
6155 022116 012706 001100    MOV #STACK,SP
6156 022122 013700 001276    MOV $BASE,R0
6157 022126 013701 001446    MOV TSTQUE,R1
6158 022132 012737 000033 001226    MOV #33,$TESTN
6159
6160 022140 004737 043216    JSR PC,TSTPRP
6161 022144 040000      WORD 040000 ;TASK DESCRIPTOR
6162 022146 000404      BR 5$
6163 022150 000240      NOP
6164 022152 104000      ERROR
6165 022154 000137 022676    JMP 110$
6166 022160 004737 044132 5$: JSR PC,GETSTS
6167 022164 012702 000000    MOV #NOP,R2
6168 022170
6169 022170 004737 053360 10$: JSR PC,CNTCLR
6170 022174 000404      BR 20$

```

```

;RETURN HERE IF ERROR
;ERROR # DEFINED BY PRIERR SUBROUTINE
;GO BACK FOR MORE ERROR CHECKS
;GO TO 140$ IF ERROR WAS FOUND
;OFFSET ON??
;YES
;BAD DATA FOR TYPEOUT
;GOOD DATA FOR TYPEOUT
;OFFSET MODE NOT SET
;SKIP REST OF TEST
;CYLINDER = 0
;SETUP REGISTER INDEX TABLE
;TERMINATE TABLE
;WRITE RMDC USING PUT SUB
;GO TO 120$ IF NO ERROR
;RETURN HERE IF ERROR
;ERROR NUMBER DEFINED BY PUT
;GO TO 140$ IF ERROR
;GO READ REGISTERS VIA GET SUB
;GO TO 130$ IF NO ERROR
;RETURN HERE IF ERROR
;ERROR DEFINED BY GET SUB
;GO TO 140$ IF ERROR WAS FOUND
;DID OFFSET MODE RESET??
;BAD DATA FOR TYPEOUT
;GOOD DATA FOR TYPEOUT
;WRITING RMDC DIDNT CLEAR OM

```

```

*****
;TEST 33 ILLEGAL FUNCTION TEST
*****
TST33:

```

```

;SCOPE CALL
;START OF TEST
;INITIALIZE STACK POINTER
;R0=UNIBUS ADDRESS
;(R1) = DEVICE BEING TESTED
;;SET TEST NUMBER IN APT MAIL BOX
;PREPARE DEVICE FOR TEST
;TASK DESCRIPTOR
;GO TO 5$ IF NO ERROR
;RETURN HERE IF ERROR
;ERROR # DEFINED BY TSTPRP SUBROUTINE
;GO TO 110$ IF ERROR WAS FOUND
;SETUP FOR STATUS
;GO TO 20$ IF NO ERROR

```

```

6171 022176 000240      NOP      ;RETURN HERE IF ERROR
6172 022200 104000      ERROR    ;ERROR NUMBER DEFINED BY SUB
6173 022202 000137 022676  JMP      110$ ;GO TO 110$ IF ERROR WAS FOUND
6174 022206
6175
6176
6177 ;SET DIAGNOSTIC MODE AND DIAGNOSTIC UNIT READY, DIAGNOSTIC ON
        ;CYLINDER
6178 022206 112737 000024 001533  MOVB    #RMMR1,PUTINX ;SETUP PUT INDEX TABLE
6179 022214 112737 000200 001534  MOVB    #200,PUTINX+1 ;WRITE TERMINATOR BYTE
6180 022222 012737 000001 001422  MOV     #DMD,RMMR10    ;RMMR1=DMD
6181 022230 004737 044466      JSR     PC,PUT          ;GO WRITE RMMR1 VIA SUB
6182 022234 000404      BR      30$           ;GO TO 30$ IF NO ERROR
6183 022236 000240      NOP      ;RETURN HERE IF ERROR
6184 022240 104000      ERROR    ;ERROR NUMBER DEFINED BY PUT SUB
6185 022242 000137 022676  JMP      110$ ;GO TO 110$ IF ERROR WAS FOUND
6186 022246
6187
6188 022246 112737 000024 001533  MOVB    #RMMR1,PUTINX ;SETUP PUT INDEX TABLE
6189 022254 112737 000200 001534  MOVB    #200,PUTINX+1 ;WRITE TERMINATOR BYTE
6190 022262 012737 001401 001422  MOV     #DMD!MUR!MOC,RMMR10 ;RMMR1=DMD!MUR!MOC
6191 022270 004737 044466      JSR     PC,PUT          ;GO WRITE RMMR1 VIA SUB
6192 022274 000404      BR      35$           ;GO TO 35$ IF NO ERROR
6193 022276 000240      NOP      ;RETURN HERE IF ERROR
6194 022300 104000      ERROR    ;ERROR NUMBER DEFINED BY PUT SUB
6195 022302 000137 022676  JMP      110$ ;GO TO 110$ IF ERROR WAS FOUND
6196 022306
6197
6198 022306 112737 000000 001533  MOVB    #RMCS1,PUTINX ;SETUP PUT INDEX TABLE
6199 022314 112737 000200 001534  MOVB    #200,PUTINX+1 ;WRITE TERMINATOR
6200 022322 012737 000023 001376  MOV     #PAKACK!GO,RMCS10 ;RMCS1 OUTPUT BUFFER = PAKACK!GO
6201 022330 004737 044466      JSR     PC,PUT          ;CALL PUT SUBROUTINE
6202 022334 000404      BR      40$           ;GO TO 40$ IF NO ERROR
6203 022336 000240      NOP      ;RETURN HERE TO REPORT AN ERROR
6204 022340 104000      ERROR    ;ERROR NUMBER DEFINED BY PUT SUB
6205 022342 000137 022676  JMP      110$ ;GO TO 110$ IF ERROR WAS FOUND
6206 022346
6207 022346 012737 000001 001376  MOV     #GO,RMCS10
6208 022354 050237 001376      BIS     R2,RMCS10    ;WRITE FUNCTION CODE IN BUFFER
6209 022360 012737 106126 001402  MOV     #BUFONE,RMBA0 ;DUMMY BUS ADDRESS
6210 022366 012737 179777 001400  MOV     #<↑C1+1>,RMWCO ;DUMMY WORD COUNT
6211 022374 005037 001404      CLR     RMDA0        ;CLEAR DISK ADDRESS
6212 022400 005037 001432      CLR     RMDCO        ;CLEAR CYLINDER ADDRESS
6213 022404 012737 010000 001430  MOV     #FMT15,RMOFO  ;16 BHT FORMAT
6214 022412 012703 001533      MOV     #PUTINX,R3   ;WRITE REGISTER INDEX TABLE
6215 022416 112723 000004      MOVB    #RMB A,(R3)+
6216 022422 112723 000002      MOVB    #RMC,(R3)+
6217 022426 112723 000032      MOVB    #RMOF,(R3)+
6218 022432 112723 000006      MOVB    #RMDA,(R3)+
6219 022436 112723 000034      MOVB    #RMDC,(R3)+
6220 022442 112723 000000      MOVB    #RMCS1,(R3)+
6221 022446 112713 000200      MOVB    #200,(R3)
6222 022452 004737 044466      JSR     PC,PUT          ;GO WRITE REGISTERS VIA PUT SUB
6223 022456 000404      BR      50$           ;GO TO 50$ IF NO ERROR
6224 022460 000240      NOP      ;RETURN HERE IF ERROR
6225 022462 104000      ERROR    ;ERROR DEFINED BY PUT SUB
6226 022464 000137 022676  JMP      110$ ;GO TO 110$ IF ERROR WAS FOUND

```

```

6227 022470 004737 045026      50$: JSR PC,TIMOUT      ;WAIT FOR GO TO RESET
6228 022474 004737 044216      JSR PC,GET           ;GO READ REGISTERS VIA GET SUB
6229 022500 000404              BR 60$              ;GO TO 60$ IF NO ERROR
6230 022502 000240              NOP                 ;RETURN HERE IF ERROR
6231 022504 104000              ERROR              ;ERROR DEFINED BY GET SUB
6232 022506 000137 022676      JMP 110$           ;GO TO 110$ IF ERROR WAS FOUND
6233 022512 000404              60$: JSR PC,PRIERR      ;GO CHECK FOR PRIMARY ERRORS
6234 022512 004737 045212      BR 70$             ;GO TO 70$ IF NO ERROR
6235 022516 000405              NOP                 ;RETURN HERE IF ERROR
6236 022520 000240              ERROR              ;ERROR # DEFINED BY PRIERR SUBROUTINE
6237 022522 104000              JSR PC,3(SP)+      ;GO BACK FOR MORE ERROR CHECKS
6238 022524 004736              JMP 110$           ;GO TO 110$ IF ERROR WAS FOUND
6239 022526 000137 022676      MOV FNCOTB(R2),SGDDAT ;GET ENTRY FROM FUNCTION CODE TABLE
6240 022532 016237 067254 001140 70$: BIC #1,CILF,SGDDAT
6241 022540 042737 177776 001140      BIC #ERR,RMDSI      ;BAD DATA FOR TYPEOUT
6242 022546 013737 001342 001142      MOV RMDSI,$BDDAT
6243 022554 042737 177776 001142      BIC #1,CILF,$BDDAT
6244 022562 023737 001140 001142      CMP SGDDAT,$BDDAT  ;IS ILF STATUS CORRECT?
6245 022570 001402              BEQ 80$             ;YES!!
6246 022572 104254              ERROR 254          ;REPORT INCORRECT ILF STATUS
6247 022574 000440              BR 110$
6248 022576 016237 067254 001140 80$: MOV FNCOTB(R2),SGDDAT
6249 022604 032737 040000 001340      BIT #ERR,RMDSI      ;WAS AN ERROR DETECTED??
6250 022612 001403              BEQ 90$             ;NO!!
6251 022614 052737 100000 001140      BIS #ATA,SGDDAT     ;YES - ATA SHOULD BE ON
6252 022622 042737 077777 001140 90$: BIC #1,CATA,SGDDAT
6253 022630 013737 001340 001142      MOV RMDSI,$BDDAT    ;GET DRIVE'S ATTENTION
6254 022636 042737 077777 001142      BIC #1,CATA,$BDDAT
6255 022644 023737 001140 001142      CMP SGDDAT,$BDDAT  ;IS ATA STATUS OK??
6256 022652 001402              BEQ 100$            ;YES!!
6257 022654 104255              ERROR 255          ;INCORRECT ATA STATUS
6258 022656 000407              BR 110$
6259 022660 062702 000002      100$: ADD #2,R2        ;GO TO NEXT FUNCTION CODE
6260 022664 022702 000076      CMP #ILF76,R2       ;DONE??
6261 022670 103402              BLO 110$            ;YES!!
6262 022672 000137 022170      JMP 10$             ;TEST NEXT FUNCTION
6263 022676
6264
6265
6266
6267 022676
6268 022676 000004
6269 022700 000240
6270 022702 012706 001100
6271 022706 013700 001276
6272 022712 013701 001446
6273 022716 012737 000034 001226
6274
6275 022724 004737 043216
6276 022730 040000
6277 022732 000404
6278 022734 000240
6279 022736 104000
6280 022740 000137 023422
6281 022744 004737 044132
6282 022750 012702 000000

```

```

110$:
;*****
;TEST 34 INVALID COMMAND TEST
;*****
TST34:

```

```

SCOPE
NOP
MOV #STACK,SP
MOV $BASE,R0
MOV TSTQUE,R1
MOV #34,$TESTN
;SCOPE CALL
;START OF TEST
;INITIALIZE STACK POINTER
;R0=UNIBUS ADDRESS
;(R1) = DEVICE BEING TESTED
;;SET TEST NUMBER IN APT MAIL BOX

```

```

5$: JSR PC,TSTPRP ;PREPARE DEVICE FOR TEST
;WORD 040000 ;TASK DESCRIPTOR
BR 5$ ;GO TO 5$ IF NO ERROR
NOP ;RETURN HERE IF ERROR
ERROR ;ERROR # DEFINED BY TSTPRP SUBROUTINE
JMP 110$ ;GO TO 110$ IF ERROR WAS FOUND
MOV #NOP,R2 ;SETUP FOR STATUS

```

```

6283 022754
6284 022754 004737 053360
6285 022760 000404
6286 022762 000240
6287 022764 104000
6288 022766 000137 023422
6289 022772
6290
6291
6292
6293 022772 112737 000024 001533
6294 023000 112737 000200 001534
6295 023006 012737 000001 001422
6296 023014 004737 044466
6297 023020 000404
6298 023022 000240
6299 023024 104000
6300 023026 000137 023422
6301 023032
6302 023032 112737 000024 001533
6303 023040 112737 000200 001534
6304 023046 012737 001401 001422
6305 023054 004737 044466
6306 023060 000404
6307 023062 000240
6308 023064 104000
6309 023066 000137 023422
6310 023072
6311
6312
6313
6314
6315 023072
6316 023072 012737 000001 001376
6317 023100 050237 001376
6318 023104 012737 106126 001402
6319 023112 012737 177777 001400
6320 023120 005037 001404
6321 023124 005037 001432
6322 023130 012737 010000 001430
6323 023136 012703 001533
6324 023142 112723 000004
6325 023146 112723 000002
6326 023152 112723 000032
6327 023156 112723 000006
6328 023162 112723 000034
6329 023166 112723 000000
6330 023172 112713 000200
6331 023176 004737 044466
6332 023202 000404
6333 023204 000240
6334 023206 104000
6335 023210 000137 023422
6336 023214 004737 045026
6337 023220 004737 044216
6338 023224 000404

10$: JSR PC,CNTCLR
BR 20$ ;GO TO 20$ IF NO ERROR
NOP ;RETURN HERE IF ERROR
ERROR ;ERROR NUMBER DEFINED BY SUB
JMP 110$ ;GO TO 110$ IF ERROR WAS FOUND

20$: ;SET DIAGNOSTIC MODE AND DIAGNOSTIC UNIT READY, DIAGNOSTIC ON
;CYLINDER
MOV #RMMR1,PUTINX ;SETUP PUT INDEX TABLE
MOV #200,PUTINX+1 ;WRITE TERMINATOR BYTE
MOV #DMD,RMMR10 ;RMMR1=DMD
JSR PC,PUT ;GO WRITE RMMR1 VIA SUB
BR 30$ ;GO TO 30$ IF NO ERROR
NOP ;RETURN HERE IF ERROR
ERROR ;ERROR NUMBER DEFINED BY PUT SUB
JMP 110$ ;GO TO 110$ IF ERROR WAS FOUND

30$: MOV #RMMR1,PUTINX ;SETUP PUT INDEX TABLE
MOV #200,PUTINX+1 ;WRITE TERMINATOR BYTE
MOV #DMD!MUR!MOC,RMMR10 ;RMMR1=DMD!MUR!MOC
JSR PC,PUT ;GO WRITE RMMR1 VIA SUB
BR 35$ ;GO TO 35$ IF NO ERROR
NOP ;RETURN HERE IF ERROR
ERROR ;ERROR NUMBER DEFINED BY PUT SUB
JMP 110$ ;GO TO 110$ IF ERROR WAS FOUND

35$:
;VOLUME VALID IS LEFT RESET FOR THE TEST

40$: MOV #GO,RMCS10
BIS R2,RMCS10 ;WRITE FUNCTION CODE IN BUFFER
MOV #BUFONE,RMBA0 ;DUMMY BUS ADDRESS
MOV #<1C1+1>,RMWCO ;DUMMY WORD COUNT
CLR RMDAO ;CLEAR DISK ADDRESS
CLR RMDCO ;CLEAR CYLINDER ADDRESS
MOV #FMT16,RMOFO ;16 BHT FORMAT
MOV #PUTINX,R3 ;WRITE REGISTER INDEX TABLE
MOV #RMBA,(R3)+
MOV #RMWC,(R3)+
MOV #RMOF,(R3)+
MOV #RMDA,(R3)+
MOV #RMDC,(R3)+
MOV #RMCS1,(R3)+
MOV #200,(R3)
JSR PC,PUT ;GO WRITE REGISTERS VIA PUT SUB
BR 50$ ;GO TO 50$ IF NO ERROR
NOP ;RETURN HERE IF ERROR
ERROR ;ERROR DEFINED BY PUT SUB
JMP 110$ ;GO TO 110$ IF ERROR WAS FOUND

50$: JSR PC,TIMOUT ;WAIT FOR GO TO RESET
JSR PC,GET ;GO READ REGISTERS VIA GET SUB
BR 60$ ;GO TO 60$ IF NO ERROR

```

```

6339 023226 000240      NOP      ;RETURN HERE IF ERROR
6340 023230 104000      ERROR    ;ERROR DEFINED BY GET SUB
6341 023232 000137 023422  JMP      110$ ;GO TO 110$ IF ERROR WAS FOUND
6342 023236          60$:      JSR      PC,PRIERR ;GO CHECK FOR PRIMARY ERRORS
6343 023236 004737 045212  BR      70$      ;GO TO 70$ IF NO ERROR
6344 023242 000405          NOP      ;RETURN HERE IF ERROR
6345 023244 000240          ERROR    ;ERROR # DEFINED BY PRIERR SUBROUTINE
6346 023246 104000          JSR      PC,(SP)+ ;GO BACK FOR MORE ERROR CHECKS
6347 023250 004736          JMP      110$    ;GO TO 110$ IF ERROR WAS FOUND
6348 023252 000137 023422  MOV      FNCDTB(R2),SGDDAT ;GET ENTRY FROM FUNCTION CODE TABLE
6349 023256 016237 067254 001140 70$:      BIC      #1CIVC,SGDDAT
6350 023264 042737 167777 001140      MOV      #RMR2I,$BDDAT ;BAD DATA FOR TYPEOUT
6351 023272 013737 001370 001142      BIC      #1CIVC,$BDDAT
6352 023300 042737 167777 001142      CMP      $GDDAT,$BDDAT ;IS IVC STATUS CORRECT?
6353 023306 023737 001140 001142      BEQ      80$      ;YES!!
6354 023314 001402          ERROR    ;REPORT INCORRECT IVC STATUS
6355 023316 104216          BR      110$
6356 023320 000440          MOV      FNCDTB(R2),SGDDAT
6357 023322 016237 067254 001140 80$:      BIT      #ERR,RMDSI ;WAS AN ERROR DETECTED??
6358 023330 032737 040000 001340      BEQ      90$      ;NO!!
6359 023336 001403          BIS      #ATA,SGDDAT ;YES - ATA SHOULD BE ON
6360 023340 052737 100000 001140 90$:      BIC      #1CATA,SGDDAT
6361 023346 042737 077777 001140      MOV      RMDSI,$BDDAT ;GET DRIVE'S ATTENTION
6362 023354 013737 001340 001142      BIC      #1CATA,$BDDAT
6363 023362 042737 077777 001142      CMP      $GDDAT,$BDDAT ;IS ATA STATUS OK??
6364 023370 023737 001140 001142      BEQ      100$     ;YES!!
6365 023376 001402          ERROR    ;INCORRECT ATA STATUS
6366 023400 104255          BR      110$
6367 023402 000407          ADD      #2,R2 ;GO TO NEXT FUNCTION CODE
6368 023404 062702 000002 100$:      CMP      #1LF76,R2 ;DONE??
6369 023410 022702 000076      BLO      110$     ;YES!!
6370 023414 103402          JMP      10$      ;TEST NEXT FUNCTION
6371 023416 000137 022754
6372 023422
6373
6374
6375
6376 023422
6377 023422 000004      SCOPE    ;SCOPE CALL
6378 023424 000240      NOP      ;START OF TEST
6379 023426 012706 001100      MOV      #STACK,SP ;INITIALIZE STACK POINTER
6380 023432 013700 001276      MOV      $BASE,R0 ;R0=UNIBUS ADDRESS
6381 023436 013701 001446      MOV      TSTQUE,R1 ;(R1) = DEVICE BEING TESTED
6382 023442 012737 000035 001226  MOV      #35,$TESTN ;SET TEST NUMBER IN APT MAIL BOX
6383
6384 023450 004737 043216      JSR      PC,TSTPRP ;PREPARE DEVICE FOR TEST
6385 023454 040000      .WORD   040000 ;TASK DESCRIPTOR
6386 023456 000404      BR      5$      ;GO TO 5$ IF NO ERROR
6387 023460 000240          NOP      ;RETURN HERE IF ERROR
6388 023462 104000          ERROR    ;ERROR # DEFINED BY TSTPRP SUBROUTINE
6389 023464 000137 024212  JMP      110$    ;GO TO 110$ IF ERROR WAS FOUND
6390 023470 004737 044132 5$:      JSR      PC,GETSTS ;SETUP FOR STATUS
6391 023474 012702 000000      MOV      #NOP,R2
6392 023500
6393 023500 004737 053360 10$:      JSR      PC,CNTCLR
6394 023504 000404      BR      20$     ;GO TO 20$ IF NO ERROR

```

```

6395 023506 000240      NOP      ;RETURN HERE IF ERROR
6396 023510 104000      ERROR    ;ERROR NUMBER DEFINED BY SUB
6397 023512 000137 024212  JMP     110$ ;GO TO 110$ IF ERROR WAS FOUND
6398 023516
6399
6400 ;SET DIAGNOSTIC MODE AND DIAGNOSTIC UNIT READY, DIAGNOSTIC ON
6401 ;CYLINDER
6402 023516 112737 000024 001533  MOVB   #RMMR1,PUTINX ;SETUP PUT INDEX TABLE
6403 023524 112737 000200 001534  MOVB   #200,PUTINX+1 ;WRITE TERMINATOR BYTE
6404 023532 012737 000001 001422  MOV    #DMD,RMMR10 ;RMMR1=DMD
6405 023540 004737 044466      JSR    PC,PUT ;GO WRITE RMMR1 VIA SUB
6406 023544 000404      BR     30$ ;GO TO 30$ IF NO ERROR
6407 023546 000240      NOP    ;RETURN HERE IF ERROR
6408 023550 104000      ERROR  ;ERROR NUMBER DEFINED BY PUT SUB
6409 023552 000137 024212  JMP     110$ ;GO TO 110$ IF ERROR WAS FOUND
6410 023556
6411 023556 112737 000024 001533  MOVB   #RMMR1,PUTINX ;SETUP PUT INDEX TABLE
6412 023564 112737 000200 001534  MOVB   #200,PUTINX+1 ;WRITE TERMINATOR BYTE
6413 023572 012737 001401 001422  MOV    #DMD!MUR!MOC,RMMR10 ;RMMR1=DMD!MUR!MOC
6414 023600 004737 044466      JSR    PC,PUT ;GO WRITE RMMR1 VIA SUB
6415 023604 000404      BR     35$ ;GO TO 35$ IF NO ERROR
6416 023606 000240      NOP    ;RETURN HERE IF ERROR
6417 023610 104000      ERROR  ;ERROR NUMBER DEFINED BY PUT SUB
6418 023612 000137 024212  JMP     110$ ;GO TO 110$ IF ERROR WAS FOUND
6419 023616
6420
6421 ;SET VOLUME VALID BEFORE ISSUING FUNCTION CODE BEING TESTED
6422 023616 112737 000000 001533  MOVB   #RMCS1,PUTINX ;SETUP PUT INDEX TABLE
6423 023624 112737 000200 001534  MOVB   #200,PUTINX+1 ;WRITE TERMINATOR
6424 023632 012737 000023 001376  MOV    #PAKACK!GO,RMCS10 ;RMCS1 OUTPUT BUFFER = PAKACK!GO
6425 023640 004737 044466      JSR    PC,PUT ;CALL PUT SUBROUTINE
6426 023644 000404      BR     40$ ;GO TO 40$ IF NO ERROR
6427 023646 000240      NOP    ;RETURN HERE TO REPORT AN ERROR
6428 023650 104000      ERROR  ;ERROR NUMBER DEFINED BY PUT SUB
6429 023652 000137 024212  JMP     110$ ;GO TO 110$ IF ERROR WAS FOUND
6430 023656
6431 023656 012737 000001 001376  MOV    #GO,RMCS10
6432 023664 050237 001376      BIS    R2,RMCS10 ;WRITE FUNCTION CODE IN BUFFER
6433 023670 012737 106126 001402  MOV    #BUFONE,RMBA0 ;DUMMY BUS ADDRESS
6434 023676 012737 177777 001400  MOV    #<↑C1+1>,RMWCO ;DUMMY WORD COUNT
6435 023704 012737 177777 001404  MOV    #-1,RMDA0 ;USE INVALID DISK ADDRESS
6436 023712 012737 177777 001432  MOV    #-1,RMDC0 ;USE INVALID CYLINDER ADDRESS
6437 023720 012737 010000 001430  MOV    #FMT16,RMOFO ;16 BIT FORMAT
6438 023726 012703 001533  MOV    #PUTINX,R3 ;WRITE REGISTER INDEX TABLE
6439 023732 112723 000004  MOVB   #RMBA,(R3)+
6440 023736 112723 000002  MOVB   #RMWC,(R3)+
6441 023742 112723 000032  MOVB   #RMOF,(R3)+
6442 023746 112723 000006  MOVB   #RMDA,(R3)+
6443 023752 112723 000034  MOVB   #RMDC,(R3)+
6444 023756 112723 000000  MOVB   #RMCS1,(R3)+
6445 023762 112713 000200  MOVB   #200,(R3)
6446 023766 004737 044466      JSR    PC,PUT ;GO WRITE REGISTERS VIA PUT SUB
6447 023772 000404      BR     50$ ;GO TO 50$ IF NO ERROR
6448 023774 000240      NOP    ;RETURN HERE IF ERROR
6449 023776 104000      ERROR  ;ERROR DEFINED BY PUT SUB
6450 024000 000137 024212  JMP     110$ ;GO TO 110$ IF ERROR WAS FOUND

```



F11

CZRMCB0 RMO3/2 FCTNL TST 1  
CZRMCB.P11 23-NOV-77 12:14

MACY11 30(1046) 23-NOV-77 12:25 PAGE 135  
T35 INVALID ADDRESS ERROR TEST

SEQ 0135

```

6451 024004 004737 045026      50$: JSR    PC,TIMOUT      ;WAIT FOR GO TO RESET
6452 024010 004737 044216      JSR    PC,GET          ;GO READ REGISTERS VIA GET SUB
6453 024014 000404              BR     60$            ;GO TO 60$ IF NO ERROR
6454 024016 000240              NOP                    ;RETURN HERE IF ERROR
6455 024020 104000              ERROR                ;ERROR DEFINED BY GET SUB
6456 024022 000137 024212      JMP    110$           ;GO TO 110$ IF ERROR WAS FOUND
6457 024026                    60$:
6458 024026 004737 045212      JSR    PC,PRIERR      ;GO CHECK FOR PRIMARY ERRORS
6459 024032 000405              BR     70$            ;GO TO 70$ IF NO ERROR
6460 024034 000240              NOP                    ;RETURN HERE IF ERROR
6461 024036 104000              ERROR                ;ERROR # DEFINED BY PRIERR SUBROUTINE
6462 024040 004736              JSR    PC,2(SP)+      ;GO BACK FOR MORE ERROR CHECKS
6463 024042 000137 024212      JMP    110$           ;GO TO 110$ IF ERROR WAS FOUND
6464 024046 016237 067254 001140 70$: MOV    FNCDTB(R2),SGDDAT ;GET ENTRY FROM FUNCTION CODE TABLE
6465 024054 042737 175777 001140 BIC    #1CIAE,SGDDAT
6466 024062 013737 001342 001142 MOV    RMER1I,$BDDAT  ;BAD DATA FOR TYPEOUT
6467 024070 042737 175777 001142 BIC    #1CIAE,$BDDAT
6468 024076 023737 001140 001142 CMP    SGDDAT,$BDDAT  ;IS IAE STATUS CORRECT?
6469 024104 001402              BEQ    80$            ;YES!!
6470 024106 104217              ERROR                ;REPORT INCORRECT IAE STATUS
6471 024110 000440              BR     110$
6472 024112 016237 067254 001140 80$: MOV    FNCDTB(R2),SGDDAT
6473 024120 032737 040000 001340 BIT    #ERR,RMSI      ;WAS AN ERROR DETECTED??
6474 024126 001403              BEQ    90$            ;NO!!
6475 024130 052737 100000 001140 BIS    #ATA,SGDDAT    ;YES - ATA SHOULD BE ON
6476 024136 042737 077777 001140 90$: BIC    #1CATA,SGDDAT
6477 024144 013737 001340 001142 MOV    RMSI,$BDDAT   ;GET DRIVE'S ATTENTION
6478 024152 042737 077777 001142 BIC    #1CATA,$BDDAT
6479 024160 023737 001140 001142 CMP    SGDDAT,$BDDAT ;IS ATA STATUS OK??
6480 024166 001402              BEQ    100$           ;YES!!
6481 024170 104255              ERROR                ;INCORRECT ATA STATUS
6482 024172 000407              BR     110$
6483 024174 062702 000002 100$: ADD    #2,R2          ;GO TO NEXT FUNCTION CODE
6484 024200 022702 000076      CMP    #1LF76,R2     ;DONE??
6485 024204 103402              BLO    110$           ;YES!!
6486 024206 000137 023500      JMP    10$            ;TEST NEXT FUNCTION
6487 024212                    110$:
6488 ;*****
6489 ;*TEST 36 WRITE LOCK ERROR TEST
6490 ;*****
6491 024212                    †ST36:
6492 024212 000004              SCOPE                ;SCOPE CALL
6493 024214 000240              NOP                    ;START OF TEST
6494 024216 012706 001100      MOV    #STACK,SP     ;INITIALIZE STACK POINTER
6495 024222 013700 001276      MOV    $BASE,R0      ;R0=UNIBUS ADDRESS
6496 024226 013701 001446      MOV    TSTQUE,R1     ;(R1) = DEVICE BEING TESTED
6497 024232 012737 000036 001226 MOV    #36,$TESTN    ;SET TEST NUMBER IN APT MAIL BOX
6498
6499 024240 004737 043216      JSR    PC,TSTPRP     ;PREPARE DEVICE FOR TEST
6500 024244 040000              .WORD 040000 ;TASK DESCRIPTOR
6501 024246 000404              BR     5$            ;GO TO 5$ IF NO ERROR
6502 024250 000240              NOP                    ;RETURN HERE IF ERROR
6503 024252 104000              ERROR                ;ERROR # DEFINED BY TSTPRP SUBROUTINE
6504 024254 000137 024776      JMP    110$           ;GO TO 110$ IF ERROR WAS FOUND
6505 024260 004737 044132      5$: JSR    PC,GETSTS    ;SETUP FOR STATUS
6506 024264 012702 000000      MOV    #NOP,R2

```

6507	024270			
6508	024270	004737	053360	
6509	024274	000404		
6510	024276	000240		
6511	024300	104000		
6512	024302	000137	024776	
6513	024306			
6514				
6515				
6516				
6517	024306	112737	000024	001533
6518	024314	112737	000200	001534
6519	024322	012737	000001	001422
6520	024330	004737	044466	
6521	024334	000404		
6522	024336	000240		
6523	024340	104000		
6524	024342	000137	024776	
6525	024346			
6526	024346	112737	000024	001533
6527	024354	112737	000200	001534
6528	024362	012737	001411	001422
6529	024370	004737	044466	
6530	024374	000404		
6531	024376	000240		
6532	024400	104000		
6533	024402	000137	024776	
6534	024406			
6535				
6536				
6537	024406	112737	000000	001533
6538	024414	112737	000200	001534
6539	024422	012737	000023	001376
6540	024430	004737	044466	
6541	024434	000404		
6542	024436	000240		
6543	024440	104000		
6544	024442	000137	024776	
6545	024446			
6546	024446	012737	000001	001376
6547	024454	050237	001376	
6548	024460	012737	106126	001402
6549	024466	012737	177777	001400
6550	024474	005037	001404	
6551	024500	005037	001432	
6552	024504	012737	010000	001430
6553	024512	012703	001533	
6554	024516	112723	000004	
6555	024522	112723	000002	
6556	024526	112723	000032	
6557	024532	112723	000006	
6558	024536	112723	000034	
6559	024542	112723	000000	
6560	024546	112713	000200	
6561	024552	004737	044466	
6562	024556	000404		

```

10$: JSR PC,CNTCLR
BR 20$ ;GO TO 20$ IF NO ERROR
NOP ;RETURN HERE IF ERROR
ERROR ;ERROR NUMBER DEFINED BY SUB
JMP 110$ ;GO TO 110$ IF ERROR WAS FOUND

20$: ;SET DIAGNOSTIC MODE AND DIAGNOSTIC UNIT READY, DIAGNOSTIC ON
;CYLINDER, AND DIAGNOSTIC WRITE LOCK
MOV B #RMMR1,PUTINX ;SETUP PUT INDEX TABLE
MOV #200,PUTINX+1 ;WRITE TERMINATOR BYTE
MOV #DMD,RMMR10 ;RMMR1=DMD
JSR PC,PUT ;GO WRITE RMMR1 VIA SUB
BR 30$ ;GO TO 30$ IF NO ERROR
NOP ;RETURN HERE IF ERROR
ERROR ;ERROR NUMBER DEFINED BY PUT SUB
JMP 110$ ;GO TO 110$ IF ERROR WAS FOUND

30$: MOV B #RMMR1,PUTINX ;SETUP PUT INDEX TABLE
MOV B #200,PUTINX+1 ;WRITE TERMINATOR BYTE
MOV #DMD!MUR!MOC!MWP,RMMR10 ;RMMR1=DMD!MUR!MOC!MWP
JSR PC,PUT ;GO WRITE RMMR1 VIA SUB
BR 35$ ;GO TO 35$ IF NO ERROR
NOP ;RETURN HERE IF ERROR
ERROR ;ERROR NUMBER DEFINED BY PUT SUB
JMP 110$ ;GO TO 110$ IF ERROR WAS FOUND

35$: ;SET VOLUME VALID BEFORE ISSUING FUNCTION CODE BEING TESTED
MOV B #RMCS1,PUTINX ;SETUP PUT INDEX TABLE
MOV B #200,PUTINX+1 ;WRITE TERMINATOR
MOV #PAKACK!GO,RMCS10 ;RMCS1 OUTPUT BUFFER = PAKACK!GO
JSR PC,PUT ;CALL PUT SUBROUTINE
BR 40$ ;GO TO 40$ IF NO ERROR
NOP ;RETURN HERE TO REPORT AN ERROR
ERROR ;ERROR NUMBER DEFINED BY PUT SUB
JMP 110$ ;GO TO 110$ IF ERROR WAS FOUND

40$: MOV #GO,RMCS10
BIS R2,RMCS10 ;WRITE FUNCTION CODE IN BUFFER
MOV #BUFONE,RMBA0 ;DUMMY BUS ADDRESS
MOV #<PC1+1>,RMWCO ;DUMMY WORD COUNT
CLR RMDAO ;CLEAR DISK ADDRESS
CLR RMDCO ;CLEAR CYLINDER ADDRESS
MOV #FMT16,RMOFO ;16 BHT FORMAT
MOV #PUTINX,R3 ;WRITE REGISTER INDEX TABLE
MOV B #RMBR,(R3)+
MOV B #RMWC,(R3)+
MOV B #RMOF,(R3)+
MOV B #RMDA,(R3)+
MOV B #RMDC,(R3)+
MOV B #RMCS1,(R3)+
MOV B #200,(R3)
JSR PC,PUT ;GO WRITE REGISTERS VIA PUT SUB
BR 50$ ;GO TO 50$ IF NO ERROR

```

```

6563 024560 000240      NOP      ;RETURN HERE IF ERROR
6564 024562 104000      ERROR    ;ERROR DEFINED BY PUT SUB
6565 024564 000137 024776  JMP      110$ ;GO TO 110$ IF ERROR WAS FOUND
6566 024570 004737 045026 50$: JSR     PC,TIMOUT ;WAIT FOR GO TO RESET
6567 024574 004737 044216  JSR     PC,GET    ;GO READ REGISTERS VIA GET SUB
6568 024600 000404      BR       60$    ;GO TO 60$ IF NO ERROR
6569 024602 000240      NOP      ;RETURN HERE IF ERROR
6570 024604 104000      ERROR    ;ERROR DEFINED BY GET SUB
6571 024606 000137 024776  JMP      110$    ;GO TO 110$ IF ERROR WAS FOUND
6572 024612      60$:      JSR     PC,PRIERR ;GO CHECK FOR PRIMARY ERRORS
6573 024612 004737 045212  BR       70$    ;GO TO 70$ IF NO ERROR
6574 024616 000405      NOP      ;RETURN HERE IF ERROR
6575 024620 000240      ERROR    ;ERROR # DEFINED BY PRIERR SUBROUTINE
6576 024622 104000      JSR     PC,(SP)+ ;GO BACK FOR MORE ERROR CHECKS
6577 024624 004736 024776  JMP      110$    ;GO TO 110$ IF ERROR WAS FOUND
6578 024626 000137 024776  MOV     FNCDTB(R2),SGDDAT ;GET ENTRY FROM FUNCTION CODE TABLE
6579 024632 016237 067254 001140 70$: BIC     #1CWLE,SGDDAT
6580 024640 042737 173777 001140  BIC     #1CWLE,$BDDAT ;BAD DATA FOR TIMEOUT
6581 024646 013737 001342 001142  MOV     RMER1I,$BDDAT
6582 024654 042737 173777 001142  BIC     #1CWLE,$BDDAT
6583 024662 023737 001140 001142  CMP     $GDDAT,$BDDAT ;IS WLE STATUS CORRECT?
6584 024670 001402      BEQ     80$    ;YES!!
6585 024672 104220      ERROR    ;REPORT INCORRECT WLE STATUS
6586 024674 000440      BR       110$
6587 024676 016237 067254 001140 80$: MOV     FNCDTB(R2),SGDDAT
6588 024704 032737 040000 001340  BIT     #ERR,RMDSI ;WAS AN ERROR DETECTED??
6589 024712 001403      BEQ     90$    ;NO!!
6590 024714 052737 100000 001140  BIS     #ATA,SGDDAT ;YES - ATA SHOULD BE ON
6591 024722 042737 077777 001140 90$: BIC     #1CATA,SGDDAT
6592 024730 013737 001340 001142  MOV     RMDSI,$BDDAT ;GET DRIVE'S ATTENTION
6593 024736 042737 077777 001142  BIC     #1CATA,$BDDAT
6594 024744 023737 001140 001142  CMP     $GDDAT,$BDDAT ;IS ATA STATUS OK??
6595 024752 001402      BEQ     100$   ;YES!!
6596 024754 104255      ERROR    ;INCORRECT ATA STATUS
6597 024756 000407      BR       110$
6598 024760 062702 000002 100$: ADD     #2,R2 ;GO TO NEXT FUNCTION CODE
6599 024764 022702 000076      CMP     #1LF76,R2 ;DONE??
6600 024770 103402      BLO    110$   ;YES!!
6601 024772 000137 024270      JMP     10$    ;TEST NEXT FUNCTION
6602 024776
6603 *****
6604 ;*TEST 37 OPI TEST
6605 *****
6606 †TST37:
6607 024776 000004      SCOPE    ;SCOPE CALL
6608 025000 000240      NOP      ;START OF TEST
6609 025002 012706 001100  MOV     #STACK,SP ;INITIALIZE STACK POINTER
6610 025006 013700 001276  MOV     $BASE,R0 ;R0=UNIBUS ADDRESS
6611 025012 013701 001446  MOV     TSTQUE,R1 ;(R1) = DEVICE BEING TESTED
6612 025016 012737 000037 001226  MOV     #37,$TESTN ;SET TEST NUMBER IN APT MAIL BOX
6613
6614 025024 004737 043216  JSR     PC,TSTPRP ;PREPARE DEVICE FOR TEST
6615 025030 040000      .WORD   040000 ;TASK DESCRIPTOR
6616 025032 000404      BR       5$    ;GO TO 5$ IF NO ERROR
6617 025034 000240      NOP      ;RETURN HERE IF ERROR
6618 025036 104000      ERROR    ;ERROR # DEFINED BY TSTPRP SUBROUTINE

```

```

6619 025040 000137 025622      JMP      110$      ;GO TO 110$ IF ERROR WAS FOUND
6620 025044 004737 044132      5$: JSR      PC,GETSTS ;SETUP FOR STATUS
6621 025050 012702 000000      MOV      #NOP,R2
6622 025054      10$: JSR      PC,CNTCLR
6623 025054 004737 053360      BR      20$      ;GO TO 20$ IF NO ERROR
6624 025060 000404      NOP      ;RETURN HERE IF ERROR
6625 025062 000240      ERROR   ;ERROR NUMBER DEFINED BY SUB
6626 025064 104000      JMP      110$     ;GO TO 110$ IF ERROR WAS FOUND
6627 025066 000137 025622      20$:
6628 025072
6629
6630      ;SET DIAGNOSTIC MODE AND DIAGNOSTIC UNIT READY, DIAGNOSTIC ON
6631      ;CYLINDER
6632 025072 112737 000024 001533      MOV      #RMMR1,PUTINX ;SETUP PUT INDEX TABLE
6633 025100 112737 000200 001534      MOV      #200,PUTINX+1 ;WRITE TERMINATOR BYTE
6634 025106 012737 000001 001422      MOV      #DMD,RMMR10 ;RMMR1=DMD
6635 025114 004737 044466      JSR      PC,PUT ;GO WRITE RMMR1 VIA SUB
6636 025120 000404      BR      30$      ;GO TO 30$ IF NO ERROR
6637 025122 000240      NOP      ;RETURN HERE IF ERROR
6638 025124 104000      ERROR   ;ERROR NUMBER DEFINED BY PUT SUB
6639 025126 000137 025622      JMP      110$     ;GO TO 110$ IF ERROR WAS FOUND
6640 025132
6641 025132 112737 000024 001533      30$: MOV      #RMMR1,PUTINX ;SETUP PUT INDEX TABLE
6642 025140 112737 000200 001534      MOV      #200,PUTINX+1 ;WRITE TERMINATOR BYTE
6643 025146 012737 001401 001422      MOV      #DMD!MUR!MOC,RMMR10 ;RMMR1=DMD!MUR!MOC
6644 025154 004737 044466      JSR      PC,PUT ;GO WRITE RMMR1 VIA SUB
6645 025160 000404      BR      35$      ;GO TO 35$ IF NO ERROR
6646 025162 000240      NOP      ;RETURN HERE IF ERROR
6647 025164 104000      ERROR   ;ERROR NUMBER DEFINED BY PUT SUB
6648 025166 000137 025622      JMP      110$     ;GO TO 110$ IF ERROR WAS FOUND
6649 025172
6650
6651      ;SET VOLUME VALID BEFORE ISSUING FUNCTION CODE BEING TESTED
6652 025172 112737 000000 001533      MOV      #RMCS1,PUTINX ;SETUP PUT INDEX TABLE
6653 025200 112737 000200 001534      MOV      #200,PUTINX+1 ;WRITE TERMINATOR
6654 025206 012737 000023 001376      MOV      #PAKACK!GO,RMCS10 ;RMCS1 OUTPUT BUFFER = PAKACK!GO
6655 025214 004737 044466      JSR      PC,PUT ;CALL PUT SUBROUTINE
6656 025220 000404      BR      36$      ;GO TO 36$ IF NO ERROR
6657 025222 000240      NOP      ;RETURN HERE TO REPORT AN ERROR
6658 025224 104000      ERROR   ;ERROR NUMBER DEFINED BY PUT SUB
6659 025226 000137 025622      JMP      110$     ;GO TO 110$ IF ERROR WAS FOUND
6660 025232
6661 025232 112737 000024 001533      36$: MOV      #RMMR1,PUTINX ;SETUP PUT INDEX TABLE
6662 025240 112737 000200 001534      MOV      #200,PUTINX+1 ;WRITE TERMINATOR BYTE
6663 025246 012737 000401 001422      MOV      #DMD!MOC,RMMR10 ;RMMR1=DMD!MOC
6664 025254 004737 044466      JSR      PC,PUT ;GO WRITE RMMR1 VIA SUB
6665 025260 000404      BR      40$      ;GO TO 40$ IF NO ERROR
6666 025262 000240      NOP      ;RETURN HERE IF ERROR
6667 025264 104000      ERROR   ;ERROR NUMBER DEFINED BY PUT SUB
6668 025266 000137 025622      JMP      110$     ;GO TO 110$ IF ERROR WAS FOUND
6669 025272
6670 025272 012737 000001 001376      40$: MOV      #GO,RMCS10
6671 025300 050237 001376      BIS      R2,RMCS10 ;WRITE FUNCTION CODE IN BUFFER
6672 025304 012737 106126 001402      MOV      #BUFONE,RMBA0 ;DUMMY BUS ADDRESS
6673 025312 012737 177777 001400      MOV      #<↑C1+1>,RMWCO ;DUMMY WORD COUNT
6674 025320 005037 001404      CLR      RMDA0 ;CLEAR DISK ADDRESS

```

```

6675 025324 005037 001432 CLR RMDCO ;CLEAR CYLINDER ADDRESS
6676 025330 012737 010000 001430 MOV #FMT16,RMOF0 ;16 BHT FORMAT
6677 025336 012703 001533 MOV #PUTINX,R3 ;WRITE REGISTER INDEX TABLE
6678 025342 112723 000004 MOVB #RMBR,(R3)+
6679 025346 112723 000002 MOVB #RMWC,(R3)+
6680 025352 112723 000032 MOVB #RMOF,(R3)+
6681 025356 112723 000006 MOVB #RMDA,(R3)+
6682 025362 112723 000034 MOVB #RMDC,(R3)+
6683 025366 112723 000000 MOVB #RMCS1,(R3)+
6684 025372 112713 000200 MOVB #200,(R3)
6685 025376 004737 044466 JSR PC,PUT ;GO WRITE REGISTERS VIA PUT SUB
6686 025402 000404 BR 50$ ;GO TO 50$ IF NO ERROR
6687 025404 000240 NOP ;RETURN HERE IF ERROR
6688 025406 104000 ERROR ;ERROR DEFINED BY PUT SUB
6689 025410 000137 025622 JMP 110$ ;GO TO 110$ IF ERROR WAS FOUND
6690 025414 004737 045026 50$: JSR PC,TIMOUT ;WAIT FOR GO TO RESET
6691 025420 004737 044216 JSR PC,GET ;GO READ REGISTERS VIA GET SUB
6692 025424 000404 BR 60$ ;GO TO 60$ IF NO ERROR
6693 025426 000240 NOP ;RETURN HERE IF ERROR
6694 025430 104000 ERROR ;ERROR DEFINED BY GET SUB
6695 025432 000137 025622 JMP 110$ ;GO TO 110$ IF ERROR WAS FOUND
6696 025436 60$:
6697 025436 004737 045212 JSR PC,PRIERR ;GO CHECK FOR PRIMARY ERRORS
6698 025442 000405 BR 70$ ;GO TO 70$ IF NO ERROR
6699 025444 000240 NOP ;RETURN HERE IF ERROR
6700 025446 104000 ERROR ;ERROR # DEFINED BY PRIERR SUBROUTINE
6701 025450 004736 JSR PC,(SP)+ ;GO BACK FOR MORE ERROR CHECKS
6702 025452 000137 025622 JMP 110$ ;GO TO 110$ IF ERROR WAS FOUND
6703 025456 016237 067254 001140 70$: MOV FNCDTB(R2),SGDDAT ;GET ENTRY FROM FUNCTION CODE TABLE
6704 025464 042737 157777 001140 BIC #↑COPI,SGDDAT
6705 025472 013737 001342 001142 MOV RMERRI,$BDDAT ;BAD DATA FOR TYPEOUT
6706 025500 042737 157777 001142 BIC #↑COPI,$BDDAT
6707 025506 023737 001140 001142 CMP SGDDAT,$BDDAT ;IS OPI STATUS CORRECT?
6708 025514 001402 BEQ 80$ ;YES!!
6709 025516 104221 ERROR 221 ;REPORT INCORRECT OPI STATUS
6710 025520 000440 BR 110$
6711 025522 016237 067254 001140 80$: MOV FNCDTB(R2),SGDDAT
6712 025530 032737 040000 001340 BIT #ERR,RMDSI ;WAS AN ERROR DETECTED??
6713 025536 001403 BEQ 90$ ;NO!!
6714 025540 052737 100000 001140 BIS #ATA,SGDDAT ;YES - ATA SHOULD BE ON
6715 025546 042737 077777 001140 90$: BIC #↑CATA,SGDDAT
6716 025554 013737 001340 001142 MOV RMDSI,$BDDAT ;GET DRIVE'S ATTENTION
6717 025562 042737 077777 001142 BIC #↑CATA,$BDDAT
6718 025570 023737 001140 001142 CMP SGDDAT,$BDDAT ;IS ATA STATUS OK??
6719 025576 001402 BEQ 100$ ;YES!!
6720 025600 104255 ERROR 255 ;INCORRECT ATA STATUS
6721 025602 000407 BR 110$
6722 025604 062702 000002 100$: ADD #2,R2 ;GO TO NEXT FUNCTION CODE
6723 025610 022702 000076 CMP #↑F76,R2 ;DONE??
6724 025614 103402 BLO 110$ ;YES!!
6725 025616 000137 025054 JMP 10$ ;TEST NEXT FUNCTION
6726 025622 110$:
6727 *****
6728 ;*TEST 40 ERROR ABORT TESTS
6729 *****
6730 †ST40:

```

```

6731 025622 000004          SCOPE          ;SCOPE CALL
6732 025624 000240          NOP           ;START OF TEST
6733 025626 012706 001100  MOV          #STACK,SP  ;INITIALIZE STACK POINTER
6734 025632 013700 001276  MOV          $BASE,R0  ;RO=UNIBUS ADDRESS
6735 025636 013701 001446  MOV          TSTQUE,R1 ;(R1) = DEVICE BEING TESTED
6736 025642 012737 000040 001226  MOV          #40,$TESTN ;;SET TEST NUMBER IN APT MAIL BOX
6737
6738 025650 004737 043216  JSR          PC,TSTPRP ;PREPARE DEVICE FOR TEST
6739 025654 054130          .WORD        054130 ;TASK DESCRIPTOR
6740 025656 000404          BR           10$      ;GO TO 10$ IF NO ERROR
6741 025660 000240          NOP           ;RETURN HERE IF ERROR
6742 025662 104000          ERROR       ;ERROR # DEFINED BY TSTPRP SUBROUTINE
6743 025664 000137 026160  JMP          80$      ;GO TO 80$ IF ERROR WAS FOUND
6744 025670
10$:
6745 025670 004737 044132  JSR          PC,GETSTS ;GO TO GETSTS SUBROUTINE
6746 025674 012702 000000  MOV          #NOP,R2  ;R2 = FUNCTION CODE
6747 025700
20$:
6748 025700 004737 053360  JSR          PC,CNTCLR ;GO ISSUE CONTROLLER CLEAR
6749 025704 000404          BR           30$      ;GO TO 30$ IF NO ERROR
6750 025706 000240          NOP           ;RETURN HERE IF ERROR
6751 025710 104000          ERROR       ;ERROR # DEFINED BY CNTCLR SUBROUTINE
6752 025712 000137 026160  JMP          80$      ;GO TO 80$ IF ERROR WAS FOUND
6753 025716
30$:
6754 025716 112737 000014 001533  MOVB        #RMER1,PUTINX ;SETUP PUT INDEX TABLE
6755 025724 112737 000200 001534  MOVB        #200,PUTINX+1 ;WRITE TERMINATOR BYTE
6756 025732 012737 040000 001412  MOV          #UN$ ,RMER10 ;RMER1 OUTPUT BUFFER = #UN$
6757 025740 004737 044466  JSR          PC,PUT    ;WRITE RMER1 VIA PUT SUB
6758 025744 000404          BR           40$      ;GO TO 40$ IF NO ERROR
6759 025746 000240          NOP           ;RETURN HERE TO REPORT ERROR
6760 025750 104000          ERROR       ;ERROR NUMBER DEFINED BY PUT SUB
6761 025752 000137 026160  JMP          80$      ;GO TO 80$ IF ERROR WAS FOUND
6762 025756
40$:
6763 025756 012737 000001 001376  MOV          #GO, RMCS10
6764 025764 050237 001376          BIS          R2, RMCS10 ;WRITE FUNCTION CODE IN BUFFER
6765 025770 012737 106126 001402  MOV          #BUFONE, RMBAO ;DUMMY BUS ADDRESS
6766 025776 012737 177777 001400  MOV          #<↑C1+1>, RMCWO ;DUMMY WORD COUNT
6767 026004 012737 000000 001404  MOV          #0, RMDAO   ;CLEAR DISK ADDRESS
6768 026012 012737 000000 001432  MOV          #0, RMDCO   ;CLEAR CYLINDER ADDRESS
6769 026020 012737 010000 001430  MOV          #FMT16, RMOFO ;16 BIT FORMAT
6770 026026 012703 001533          MOV          #PUTINX, R3 ;WRITE REGISTER INDEX TABLE
6771 026032 112723 000004          MOVB        #RMB, (R3)+
6772 026036 112723 000002          MOVB        #RMC, (R3)+
6773 026042 112723 000032          MOVB        #RMOF, (R3)+
6774 026046 112723 000006          MOVB        #RMDA, (R3)+
6775 026052 112723 000034          MOVB        #RMDC, (R3)+
6776 026056 112723 000000          MOVB        #RMCS1, (R3)+
6777 026062 112713 000200          MOVB        #200, (R3)
6778 026066 004737 044466  JSR          PC,PUT    ;GO WRITE REGISTERS WITH PUT SUBROUTINE
6779 026072 000404          BR           45$      ;GO TO 45$ IF NO ERROR
6780 026074 000240          NOP           ;RETURN HERE IF ERROR
6781 026076 104000          ERROR       ;ERROR # DEFINED BY PUT SUBROUTINE
6782 026100 000137 026160  JMP          80$      ;GO TO 80$ IF ERROR WAS FOUND
6783 026104
45$:
6784 026104 004737 045026  JSR          PC,TIMOUT ;GO TO TIMEOUT SUBROUTINE
6785 026110 004737 044216  JSR          PC,GET    ;GO READ REGISTERS WITH GET SUBROUTINE
6786 026114 000404          BR           50$      ;GO TO 50$ IF NO ERROR

```

```

6787 026116 000240      NOP      ;RETURN HERE IF ERROR
6788 026120 104000      ERROR    ;ERROR # DEFINED BY GET SUBROUTINE
6789 026122 000137 026160  JMP      80$      ;GO TO 80$ IF ERROR WAS FOUND
6790 026126          50$:
6791 026126 004737 045212  JSR      PC,PRIERR ;GO CHECK FOR PRIMARY ERRORS
6792 026132 000405      BR       60$      ;GO TO 60$ IF NO ERROR
6793 026134 000240      NOP      ;RETURN HERE IF ERROR
6794 026136 104000      ERROR    ;ERROR # DEFINED BY PRIERR SUBROUTINE
6795 026140 004736      JSR      PC,2(SP)+ ;GO BACK FOR MORE ERROR CHECKS
6796 026142 000137 026160  JMP      80$      ;GO TO 80$ IF ERROR WAS FOUND
6797 026146          60$:
6798 026146          70$:
6799 026146 062702 000002  ADD      #2,R2     ;ADVANCE FUNCTION CODE
6800 026152 022702 000076  CMP      #ILF76,R2 ;DONE ALL COMMANDS
6801 026156 103250      BHIS     20$      ;NO !!
6802 026160
6803
6804
6805
6806 026160          *****
6807 026160 000004          ;*TEST 41 RMR TEST
6808 026162 000240          *****
6809 026164 012706 001100  MOV      #STACK,SP ;SCOPE CALL
6810 026170 013700 001276  MOV      $BASE,R0  ;START OF TEST
6811 026174 013701 001446  MOV      TSTQUE,R1 ;INITIALIZE STACK POINTER
6812 026200 012737 000041 001226  MOV      #41,$TESTN ;RO=UNIBUS ADDRESS
6813                                     ;(R1) = DEVICE BEING TESTED
6814 026206 004737 043216  JSR      PC,TSTPRP ;SET TEST NUMBER IN APT MAIL BOX
6815 026212 040000      .WORD   040000 ;TASK DESCRIPTOR
6816 026214 000404      BR       10$      ;GO TO 10$ IF NO ERROR
6817 026216 000240      NOP      ;RETURN HERE IF ERROR
6818 026220 104000      ERROR    ;ERROR # DEFINED BY TSTPRP SUBROUTINE
6819 026222 000137 026620  JMP      100$     ;GO TO 100$ IF ERROR WAS FOUND
6820 026226          10$:
6821 026226 004737 044132  JSR      PC,GETSTS ;GO TO GETSTS SUBROUTINE
6822 026232          20$:
6823 026232 112737 000024 001533  MOVB    #RMMR1,PUTINX ;SETUP PUT INDEX TABLE
6824 026240 112737 000200 001534  MOVB    #200,PUTINX+1 ;WRITE TERMINATOR BYTE
6825 026246 012737 000001 001422  MOV     #DMD,RMMR10 ;RMMR1=DMD
6826 026254 004737 044466      JSR      PC,PUT    ;GO WRITE RMMR1 VIA SUB
6827 026260 000404      BR       30$      ;GO TO 30$ IF NO ERROR
6828 026262 000240      NOP      ;RETURN HERE IF ERROR
6829 026264 104000      ERROR    ;ERROR NUMBER DEFINED BY PUT SUB
6830 026266 000137 026620  JMP      100$     ;GO TO 100$ IF ERROR WAS FOUND
6831 026272          30$:
6832 026272 112737 000024 001533  MOVB    #RMMR1,PUTINX ;SETUP PUT INDEX TABLE
6833 026300 112737 000200 001534  MOVB    #200,PUTINX+1 ;WRITE TERMINATOR BYTE
6834 026306 012737 001401 001422  MOV     #DMD!MUR!MOC,RMMR10 ;RMMR1=DMD!MUR!MOC
6835 026314 004737 044466      JSR      PC,PUT    ;GO WRITE RMMR1 VIA SUB
6836 026320 000404      BR       40$      ;GO TO 40$ IF NO ERROR
6837 026322 000240      NOP      ;RETURN HERE IF ERROR
6838 026324 104000      ERROR    ;ERROR NUMBER DEFINED BY PUT SUB
6839 026326 000137 026620  JMP      100$     ;GO TO 100$ IF ERROR WAS FOUND
6840 026332          40$:
6841 026332 112737 000000 001533  MOVB    #RMCS1,PUTINX ;SETUP PUT INDEX TABLE
6842 026340 112737 000200 001534  MOVB    #200,PUTINX+1 ;WRITE TERMINATOR

```

M11

CZRMCB0 RMO3/2 FCTNL TST 1  
CZRMCB.P11 23-NOV-77 12:14

MACY11 30(1046) 23-NOV-77 12:25 PAGE 142  
T41 RMR TEST

SEQ 0142

```

6843 026346 012737 000023 001376 MOV #PAKACK!GO, RMCS10 ; RMCS1 OUTPUT BUFFER = PAKACK!GO
6844 026354 004737 044466 JSR PC PUT ; CALL PUT SUBROUTINE
6845 026360 000404 BR 50$ ; GO TO 50$ IF NO ERROR
6846 026362 000240 NOP ; RETURN HERE TO REPORT AN ERROR
6847 026364 104000 ERROR ; ERROR NUMBER DEFINED BY PUT SUB
6848 026366 000137 026620 JMP 100$ ; GO TO 100$ IF ERROR WAS FOUND
6849 026372 50$:
6850 026372 004737 044216 JSR PC GET ; GO READ REGISTERS WITH GET SUBROUTINE
6851 026376 000404 BR 60$ ; GO TO 60$ IF NO ERROR
6852 026400 000240 NOP ; RETURN HERE IF ERROR
6853 026402 104000 ERROR ; ERROR # DEFINED BY GET SUBROUTINE
6854 026404 000137 026620 JMP 100$ ; GO TO 100$ IF ERROR WAS FOUND
6855 026410 60$:
6856 026410 000240 NOP
6857 026412 112737 000024 001533 MOVB #RMMR1, PUTINX ; SETUP PUT INDEX TABLE
6858 026420 112737 000200 001534 MOVB #200, PUTINX+1 ; WRITE TERMINATOR BYTE
6859 026426 012737 041401 001422 MOV #DMD!MUR!MOC!DBEN, RMMR10 ; RMMR1=DMD!MUR!MOC!DBEN
6860 026434 004737 044466 JSR PC PUT ; GO WRITE RMMR1 VIA SUB
6861 026440 000404 BR 70$ ; GO TO 70$ IF NO ERROR
6862 026442 000240 NOP ; RETURN HERE IF ERROR
6863 026444 104000 ERROR ; ERROR NUMBER DEFINED BY PUT SUB
6864 026446 000137 026620 JMP 100$ ; GO TO 100$ IF ERROR WAS FOUND
6865 026452 70$:
6866 026452 112737 000000 001533 MOVB #RMCS1, PUTINX ; SETUP PUT INDEX TABLE
6867 026460 112737 000200 001534 MOVB #200, PUTINX+1 ; WRITE TERMINATOR
6868 026466 012737 000001 001376 MOV #NOP!GO, RMCS10 ; RMCS1 OUTPUT BUFFER = NOP!GO
6869 026474 004737 044466 JSR PC PUT ; CALL PUT SUBROUTINE
6870 026500 000404 BR 80$ ; GO TO 80$ IF NO ERROR
6871 026502 000240 NOP ; RETURN HERE TO REPORT AN ERROR
6872 026504 104000 ERROR ; ERROR NUMBER DEFINED BY PUT SUB
6873 026506 000137 026620 JMP 100$ ; GO TO 100$ IF ERROR WAS FOUND
6874 026512 80$:
6875 026512 112737 000000 001533 MOVB #RMCS1, PUTINX ; SETUP PUT INDEX TABLE
6876 026520 112737 000200 001534 MOVB #200, PUTINX+1 ; WRITE TERMINATOR
6877 026526 012737 000015 001376 MOV #OFFSET!GO, RMCS10 ; RMCS1 OUTPUT BUFFER = OFFSET!GO
6878 026534 004737 044466 JSR PC PUT ; CALL PUT SUBROUTINE
6879 026540 000404 BR 85$ ; GO TO 85$ IF NO ERROR
6880 026542 000240 NOP ; RETURN HERE TO REPORT AN ERROR
6881 026544 104000 ERROR ; ERROR NUMBER DEFINED BY PUT SUB
6882 026546 000137 026620 JMP 100$ ; GO TO 100$ IF ERROR WAS FOUND
6883 026552 85$:
6884 026552 004737 044216 JSR PC GET ; GO READ REGISTERS WITH GET SUBROUTINE
6885 026556 000404 BR 90$ ; GO TO 90$ IF NO ERROR
6886 026560 000240 NOP ; RETURN HERE IF ERROR
6887 026562 104000 ERROR ; ERROR # DEFINED BY GET SUBROUTINE
6888 026564 000137 026620 JMP 100$ ; GO TO 100$ IF ERROR WAS FOUND
6889 026570 90$:
6890 026570 000240 NOP
6891 026572 032737 000004 001342 BIT #RMR, RMR11 ; IS RMR SET ??
6892 026600 001007 BNE 100$ ; YES !!
6893 026602 012737 000004 001140 MOV #RMR, $GDDAT ; EXPECTED STATUS
6894 026610 013737 001342 001142 MOV RMR11, $BDDAT ; RECEIVED STATUS
6895 026616 104222 ERROR 222 ; RMR DID NOT SET
6896 026620 100$:
6897 ;*****
6898 ;*TEST 42 PARITY ERROR TEST

```



```

6899
6900 026620
6901 026620 000004
6902 026622 000240
6903 026624 012706 001100
6904 026630 013700 001276
6905 026634 013701 001446
6906 026640 012737 000042 001226
6907
6908 026646 004737 043216
6909 026652 040000
6910 026654 000404
6911 026656 000240
6912 026660 104000
6913 026662 000137 027044
6914 026666
6915 026666 012702 000001
6916 026672
6917 026672 004737 053360
6918 026676 000404
6919 026700 000240
6920 026702 104000
6921 026704 000137 027044
6922 026710
6923 026710 111103
6924 026712 042703 177770
6925 026716 052703 000020
6926 026722 010337 001406
6927 026726 010237 001404
6928 026732 012703 001533
6929 026736 112723 000010
6930 026742 112723 000006
6931 026746 112723 000200
6932
6933 026752 004737 044466
6934 026756 000404
6935 026760 000240
6936 026762 104000
6937 026764 000137 027044
6938 026770
6939 026770 004737 044216
6940 026774 000404
6941 026776 000240
6942 027000 104000
6943 027002 000137 027044
6944 027006
6945 027006 032737 000010 001342
6946 027014 001011
6947 027016 012737 000010 001140
6948 027024 013737 001342 001142
6949 027032 010237 001174
6950 027036 104223
6951 027040
6952 027040 006302
6953 027042 001313
6954 027044

*****
TST42:
SCOPE ; SCOPE CALL
NOP ; START OF TEST
MOV #STACK, SP ; INITIALIZE STACK POINTER
MOV $BASE, R0 ; R0=UNIBUS ADDRESS
MOV TSTQUE, R1 ; (R1) = DEVICE BEING TESTED
MOV #42, $TESTN ; ; SET TEST NUMBER IN APT MAIL BOX

JSR PC, TSTPRP ; PREPARE DEVICE FOR TEST
; .WORD 040000 ; TASK DESCRIPTOR
BR 10$ ; GO TO 10$ IF NO ERROR
NOP ; RETURN HERE IF ERROR
ERROR ; ERROR # DEFINED BY TSTPRP SUBROUTINE
JMP 70$ ; GO TO 70$ IF ERROR WAS FOUND

10$: MOV #1, R2 ; R2 = DATA PATTERN

20$: JSR PC, CNTCLR ; GO ISSUE CONTROLLER CLEAR
BR 30$ ; GO TO 30$ IF NO ERROR
NOP ; RETURN HERE IF ERROR
ERROR ; ERROR # DEFINED BY CNTCLR SUBROUTINE
JMP 70$ ; GO TO 70$ IF ERROR WAS FOUND

30$: MOVB (R1), R3 ; SETUP RMCS2
BIC #CNTMSK, R3
BIS #PAT, R3
MOV R3, RMCS20 ; OUTPUT VALUE TO RMCS2
MOV R2, RMDA0 ; VALUE TO RMDA
MOV #PUTINX, R3 ; WRITE REGISTER OUTPUT INDEX
MOVB #RMCS2, (R3)+
MOVB #RMDA, (R3)+
MOVB #200, (R3)+

JSR PC, PUT ; GO WRITE REGISTERS WITH PUT SUBROUTINE
BR 40$ ; GO TO 40$ IF NO ERROR
NOP ; RETURN HERE IF ERROR
ERROR ; ERROR # DEFINED BY PUT SUBROUTINE
JMP 70$ ; GO TO 70$ IF ERROR WAS FOUND

40$: JSR PC, GET ; GO READ REGISTERS WITH GET SUBROUTINE
BR 50$ ; GO TO 50$ IF NO ERROR
NOP ; RETURN HERE IF ERROR
ERROR ; ERROR # DEFINED BY GET SUBROUTINE
JMP 70$ ; GO TO 70$ IF ERROR WAS FOUND

50$: BIT #PAR, RMER1I ; IS PARITY ERROR SET ??
BNE 60$ ; YES !!
MOV #PAR, $GDDAT ; EXPECTED STATUS
MOV RMER1I, $BDDAT ; RECEIVED STATUS
MOV R2, $TMPD ; DATA PATTERN
ERROR 223 ; PAR DID NOT SET

60$: ASL R2 ; ADVANCE DATA PATTERN
BNE 70$ ; BRANCH IF NOT DONE

70$:

```

6955  
6956  
6957  
6958 027044  
6959 027044 000004  
6960 027046 000240  
6961 027050 012706 001100  
6962 027054 013700 001276  
6963 027060 013701 001446  
6964 027064 012737 000043 001226  
6965  
6966 027072 004737 043216  
6967 027076 040000  
6968 027100 000404  
6969 027102 000240  
6970 027104 104000  
6971 027106 000137 027372  
6972 027112 005005 10\$:  
6973 027114 004737 044132  
6974 027120 013746 000004  
6975 027124 013746 000006  
6976 027130 012737 027370 000004  
6977 027136 012737 000300 000006  
6978 027144 005002  
6979 027146 20\$:  
6980 027146 004737 053360  
6981 027152 000404  
6982 027154 000240  
6983 027156 104000  
6984 027160 000137 027304  
6985 027164 010003 30\$:  
6986 027166 060203  
6987 027170 005013  
6988 027172 004737 051706  
6989 027176 000404  
6990 027200 000240  
6991 027202 104000  
6992 027204 000137 027372  
6993 027210 35\$:  
6994 027210 004737 044216  
6995 027214 000404  
6996 027216 000240  
6997 027220 104000  
6998 027222 000137 027304  
6999 027226 40\$:  
7000 027226 004737 045212  
7001 027232 000405  
7002 027234 000240  
7003 027236 104000  
7004 027240 004736  
7005 027242 000137 027304  
7006 027246 010537 001140  
7007 027252 013737 001342 001142  
7008 027260 042737 177775 001142  
7009 027266 023737 001140 001142  
7010 027274 001403

```
*****  
: *TEST 43 ILLEGAL REGISTER TEST  
: *****  
↑T43:  
SCOPE ; SCOPE CALL  
NOP ; START OF TEST  
MOV #STACK, SP ; INITIALIZE STACK POINTER  
MOV $BASE, R0 ; R0=UNIBUS ADDRESS  
MOV TSTQUE, R1 ; (R1) = DEVICE BEING TESTED  
MOV #43, $TESTN ; ; SET TEST NUMBER IN APT MAIL BOX  
  
JSR PC, TSTPRP ; PREPARE DEVICE FOR TEST  
.WORD 040000 ; TASK DESCRIPTOR  
BR 10$ ; GO TO 10$ IF NO ERROR  
NOP ; RETURN HERE IF ERROR  
ERROR ; ERROR # DEFINED BY TSTPRP SUBROUTINE  
JMP 120$ ; GO TO 120$ IF ERROR WAS FOUND  
10$: CLR R5 ; R5 = EXPECTED STATUS  
JSR PC, GETSTS ; SETUP FOR STATUS  
MOV ERRVEC, -(SP) ; ; PUSH ERRVEC ON STACK  
MOV ERRVEC+2, -(SP) ; ; PUSH ERRVEC+2 ON STACK  
MOV #110$, ERRVEC ; SETUP FOR BUS TIMEOUT  
MOV #PR6, ERRVEC+2  
CLR R2 ; R2=REGISTER INDEX  
  
20$: JSR PC, CNTCLR  
BR 30$ ; GO TO 30$ IF NO ERROR  
NOP ; RETURN HERE IF ERROR  
ERROR ; ERROR NUMBER DEFINED BY SUB  
JMP 70$ ; GO TO 70$ IF ERROR WAS FOUND  
30$: MOV R0, R3 ; R3=REGISTER ADDRESS  
ADD R2, R3  
CLR (R3) ; CLEAR THE REGISTER  
JSR PC, DEVSEL ; GO SELECT DEVICE  
BR 35$ ; GO TO 35$ IF NO ERROR  
NOP ; RETURN HERE IF ERROR  
ERROR ; ERROR # DEFINED BY DEVSEL SUBROUTINE  
JMP 120$ ; GO TO 120$ IF ERROR WAS FOUND  
  
35$: JSR PC, GET  
BR 40$ ; GO TO 40$ IF NO ERROR  
NOP ; RETURN HERE IF ERROR  
ERROR ; ERROR DEFINED BY GET SUB  
JMP 70$ ; GO TO 70$ IF ERROR WAS FOUND  
  
40$: JSR PC, PRIERR ; GO CHECK FOR PRIMARY ERRORS  
BR 50$ ; GO TO 50$ IF NO ERROR  
NOP ; RETURN HERE IF ERROR  
ERROR ; ERROR # DEFINED BY PRIERR SUBROUTINE  
JSR PC, @ (SP)+ ; GO BACK FOR MORE ERROR CHECKS  
JMP 70$ ; GO TO 70$ IF ERROR WAS FOUND  
50$: MOV R5, $GDDAT ; GET DRIVE'S ILR STATUS  
MOV #↑CILR, $BDDAT  
BIC #↑CILR, $BDDAT  
CMP $GDDAT, $BDDAT ; IS ILR STATUS OK??  
BEQ 70$ ; YES!!
```

C12

7011 027276 010237 001174  
7012 027302 104256  
7013  
7014  
7015  
7016  
7017  
7018  
7019  
7020  
7021  
7022  
7023  
7024  
7025  
7026  
7027  
7028  
7029  
7030  
7031  
7032 027304 062702 000002  
7033 027310 022702 000050  
7034 027314 101314  
7035 027316 103420  
7036 027320 012705 000002  
7037 027324 012760 001400 000000  
7038 027332 012702 000054  
7039 027336 016003 000050  
7040 027342 042703 177774  
7041 027346 022703 000003  
7042 027352 001402  
7043 027354 012702 000050  
7044 027360 022702 000074  
7045 027364 101402  
7046 027366 000667  
7047  
7048 027370 022626  
7049 027372  
7050 027372 012637 000006  
7051 027376 012637 000004  
7052  
7053  
7054  
7055  
7056 027402  
7057 027402 000004  
7058 027404 000240  
7059 027406 012737 000001 001206  
7060 027414 012737 027430 001122  
7061 027422 012737 027430 001124  
7062 027430  
7063 027430 012706 001100  
7064 027434 013700 001276  
7065 027440 013701 001446  
7066 027444 012737 000044 001226

```
MOV R2,STMPD ;SAVE R2 FOR ERROR DATA
ERROR 256
:70$: ADD #2,R2
CMP #RMBAE,R2 ;IS NEXT REGISTER RMBAE??
BNE 80$ ;NO!!
MOV #A16!A17,RMCS1(R0) ;SET A16 & A17
MOV RMBAE(R0),R3 ;IS THIS AN RH70??
BIC #C<BIT0!BIT1>,R3 ;CLEAR ALL BUT ADDRESS BITS
CMP #BIT0!BIT1,R3 ;ARE ADDRESS BITS ON ??
BEQ 100$ ;YES
MOV #ILR,R5 ;NO - EXPECT ILR=1
BR 100$
:80$: CMP #RMCS3+2,R2 ;SHOULD ILR BE SET??
BNE 90$ ;NO!!
MOV #ILR,R5 ;YES!!
BR 100$
:90$: CMP #76,R2 ;DONE??
BLO 120$ ;YES!!
BR 20$
:100$: THE FOLLOWING CODING FOR HANDLE RH70
:RH 70 REGISTER NUMBERS IS EITHER 22 OR 32
:70$: ADD #2,R2 ;INCREMENT THE REGISTER ADDRESS
CMP #50,R2 ;TIME TO CHECK THE EXTEND ADDRESS REG ?
BHI 20$ ;BRANCH IF NOT
BLO 80$ ;BRANCH IF ALREADY SET UP
MOV #ILR,R5 ;EXCEPT ILR HAPPEND
MOV #A16!A17,RMCS1(R0) ;SET EXTEND ADDRESS BIT
MOV #54,R2 ;SET ADDRESS TO 54, IF 22 REGISTERS
MOV 50(R0),R3 ;IS THIS 22 REG RH70 ?
BIC #177774,R3 ;LEFT ONLY BIT 0 AND BIT 1
CMP #BIT0!BIT1,R3 ;BIT 0 AND BIT 1 SET AT THE SAME TIME ?
BEQ 80$ ;BRANCH IF SO
MOV #50,R2 ;OTHERWISE, SET ADDRESS TO 50
:80$: CMP #74,R2 ;ALL REGISTERS CHECKED ?
BLOS 120$ ;BRANCH IF SO
BR 20$ ;NEXT REGISTER
:110$: CMP (SP)+,(SP)+
:120$: MOV (SP)+,ERRVEC+2 ;POP STACK INTO ERRVEC+2
MOV (SP)+,ERRVEC ;POP STACK INTO ERRVEC
:*****
:TEST 44 SEEK LAST CYLINDER
:*****
:ST44: SCOPE ;SCOPE CALL
NOP ;START OF TEST
MOV #1,STIMES ;LOAD ITERATION COUNT
MOV #1$,SLPADR
MOV #1$,SLPERR
:1$: MOV #STACK,SP ;INITIALIZE STACK POINTER
MOV $BASE,R0 ;R0=UNIBUS ADDRESS
MOV TSTQUE,R1 ;(R1) = DEVICE BEING TESTED
MOV #44,$TESTN ;SET TEST NUMBER IN APT MAIL BOX
```

7067	027452			10\$:			
7068	027452	004737	043216		JSR	PC,TSTPRP	;PREPARE DEVICE FOR TEST
7069	027456	054130			.WORD	054130	;TASK DESCRIPTOR
7070	027460	000404			BR	80\$	;GO TO 80\$ IF NO ERROR
7071	027462	000240			NOP		;RETURN HERE IF ERROR
7072	027464	104000			ERROR		;ERROR # DEFINED BY TSTPRP SUBROUTINE
7073	027466	000137	027704		JMP	140\$	;GO TO 140\$ IF ERROR WAS FOUND
7074	027472			80\$:			
7075	027472	012737	000000		MOV	#0,RMDAO	;TRACK = SECTOR = 0
7076	027500	012737	001466	001404	MOV	#822,RMDC0	;CYLINDER = 822
7077	027506	012737	000005	001432	MOV	#SEEK!GO,RMCS10	;LOAD SEEK COMMAND IN BUFFER
7078	027514	012702	001533	001376	MOV	#PUTINX,R2	;R2 POINTS TO REGISTER TABLE
7079	027520	112722	000034		MOVB	#RMDC,(R2)+	;WRITE REGISTER INDEX TABLE
7080	027524	112722	000006		MOVB	#RMDA,(R2)+	
7081	027530	112722	000000		MOVB	#RMCS1,(R2)+	
7082	027534	112722	000200		MOVB	#200,(R2)+	;WRITE TERMINATOR
7083	027540	004737	044466		JSR	PC,PUT	;GO WRITE REGISTERS VIA PUT SUB
7084	027544	000404			BR	90\$	;GO TO 90\$ IF NO ERROR
7085	027546	000240			NOP		;RETURN HERE IF ERROR
7086	027550	104000			ERROR		;ERROR DEFINED BY PUT SUB
7087	027552	000137	027704		JMP	140\$	;GO TO 140\$ IF ERROR WAS FOUND
7088	027556	004737	044132	90\$:	JSR	PC,GETSTS	;SETUP FOR STATUS FETCH
7089	027562	004737	045026		JSR	PC,TIMOUT	;WAIT FOR SEEK TO COMPLETE
7090	027566	004737	044216		JSR	PC,GET	;GO READ REGISTERS VIA GET SUB
7091	027572	000404			BR	100\$	;GO TO 100\$ IF NO ERROR
7092	027574	000240			NOP		;RETURN HERE IF ERROR
7093	027576	104000			ERROR		;ERROR DEFINED BY GET SUB
7094	027600	000137	027704		JMP	140\$	;GO TO 140\$ IF ERROR WAS FOUND
7095	027604			100\$:			
7096	027604	004737	045212		JSR	PC,PRIERR	;GO CHECK FOR PRIMARY ERRORS
7097	027610	000405			BR	110\$	;GO TO 110\$ IF NO ERROR
7098	027612	000240			NOP		;RETURN HERE IF ERROR
7099	027614	104000			ERROR		;ERROR # DEFINED BY PRIERR SUBROUTINE
7100	027616	004736			JSR	PC,@(SP)+	;GO BACK FOR MORE ERROR CHECKS
7101	027620	000137	027704		JMP	140\$	;GO TO 140\$ IF ERROR WAS FOUND
7102	027624			110\$:			
7103	027624	004737	052120		JSR	PC,SEKSTS	;GO VERIFY RESULTS OF SEEK OPERATION
7104	027630	000405			BR	120\$	;GO TO 120\$ IF NO ERROR
7105	027632	000240			NOP		;RETURN HERE IF ERROR
7106	027634	104000			ERROR		;ERROR # DEFINED BY SEKSTS SUBROUTINE
7107	027636	004736			JSR	PC,@(SP)+	;GO BACK FOR MORE ERROR CHECKS
7108	027640	000137	027704		JMP	140\$	;GO TO 140\$ IF ERROR WAS FOUND
7109	027644			120\$:			
7110	027644	004737	061566		JSR	PC,CMPEARRSTS	;CHECK ANY ERRORS NOT MASKED
7111	027650	115760			.WORD	NDTMSK	;MASK FOR RMER1
7112	027652	000010			.WORD	DPE	;MASK FOR RMER2
7113	027654	000405			BR	130\$	;GO TO 130\$ IF NO ERROR
7114	027656	000240			NOP		;RETURN HERE IF ERROR
7115	027660	104000			ERROR		;ERROR # DEFINED BY CMPEARRSTS SUBROUTINE
7116	027662	004736			JSR	PC,@(SP)+	;GO BACK FOR MORE ERROR CHECKS
7117	027664	000137	027704		JMP	140\$	;GO TO 140\$ IF ERROR WAS FOUND
7118	027670			130\$:			
7119	027670	004737	046044		JSR	PC,SECERR	;GO CHECK FOR SECONDARY ERRORS
7120	027674	000403			BR	140\$	;GO TO 140\$ IF NO ERROR
7121	027676	000240			NOP		;RETURN HERE IF ERROR
7122	027700	104000			ERROR		;ERROR # DEFINED BY SECERR SUBROUTINE

```

7123 027702 004736      JSR    PC,(SP)+      ;GO BACK FOR MORE ERROR CHECKS
7124 027704
7125
7126
7127
7128
7129 027704
7130 027704 000004      SCOPE      ;SCOPE CALL
7131 027706 000240      NOP        ;START OF TEST
7132 027710 012737 000001 001206  MOV     #1,STIMES ;LOAD ITERATION COUNT
7133 027716 012737 027732 001122  MOV     #1$,SLPADR
7134 027724 012737 027732 001124  MOV     #1$,SLPERR
7135 027732
7136 027732 012706 001100      1$:      MOV     #STACK,SP ;INITIALIZE STACK POINTER
7137 027736 013700 001276  MOV     $BASE,R0   ;R0=UNIBUS ADDRESS
7138 027742 013701 001446  MOV     TSTQUE,R1 ;(R1) = DEVICE BEING TESTED
7139 027746 012737 000045 001226  MOV     #45,$TESTN ;SET TEST NUMBER IN APT MAIL BOX
7140 027754
7141 027754 004737 043216      10$:     JSR    PC,TSTPRP   ;PREPARE DEVICE FOR TEST
7142 027760 054130      .WORD   054130 ;TASK DESCRIPTOR
7143 027762 000404      BR      80$       ;GO TO 80$ IF NO ERROR
7144 027764 000240      NOP
7145 027766 104000      ERROR  #         ;RETURN HERE IF ERROR
7146 027770 000137 030206      JMP    140$      ;ERROR # DEFINED BY TSTPRP SUBROUTINE
7147 027774
7148 027774 012737 000000 001404      80$:     MOV     #0,RMDAO  ;TRACK = SECTOR = 0
7149 030002 012737 000000 001432      MOV     #0,RMDCO  ;CYLINDER = 0
7150 030010 012737 000005 001376      MOV     #SEEK!GO, RMCS10 ;LOAD SEEK COMMAND IN BUFFER
7151 030016 012702 001533      MOV     #PUTINX,R2 ;R2 POINTS TO REGISTER TABLE
7152 030022 112722 000034      MOV     #RMDC,(R2)+ ;WRITE REGISTER INDEX TABLE
7153 030026 112722 000006      MOV     #RMDA,(R2)+
7154 030032 112722 000000      MOV     #RMCS1,(R2)+
7155 030036 112722 000200      MOV     #200,(R2)+ ;WRITE TERMINATOR
7156 030042 004737 044466      JSR    PC,PUT     ;GO WRITE REGISTERS VIA PUT SUB
7157 030046 000404      BR      90$       ;GO TO 90$ IF NO ERROR
7158 030050 000240      NOP
7159 030052 104000      ERROR  #         ;RETURN HERE IF ERROR
7160 030054 000137 030206      JMP    140$      ;ERROR DEFINED BY PUT SUB
7161 030060 004737 044132      90$:     JSR    PC,GETSTS  ;GO TO 140$ IF ERROR WAS FOUND
7162 030064 004737 045026      JSR    PC,TIMOUT ;SETUP FOR STATUS FETCH
7163 030070 004737 044216      JSR    PC,GET     ;WAIT FOR SEEK TO COMPLETE
7164 030074 000404      BR      100$     ;GO READ REGISTERS VIA GET SUB
7165 030076 000240      NOP
7166 030100 104000      ERROR  #         ;RETURN HERE IF ERROR
7167 030102 000137 030206      JMP    140$      ;ERROR DEFINED BY GET SUB
7168 030106
7169 030106 004737 045212      100$:    JSR    PC,PRIERR  ;GO CHECK FOR PRIMARY ERRORS
7170 030112 000405      BR      110$     ;GO TO 110$ IF NO ERROR
7171 030114 000240      NOP
7172 030116 104000      ERROR  #         ;RETURN HERE IF ERROR
7173 030120 004736      JSR    PC,(SP)+  ;ERROR # DEFINED BY PRIERR SUBROUTINE
7174 030122 000137 030206      JMP    140$      ;GO BACK FOR MORE ERROR CHECKS
7175 030126
7176 030126 004737 052120      110$:    JSR    PC,SEKSTS ;GO VERIFY RESULTS OF SEEK OPERATION
7177 030132 000405      BR      120$     ;GO TO 120$ IF NO ERROR
7178 030134 000240      NOP
;RETURN HERE IF ERROR

```

```

7179 030136 104000          ERROR          ;ERROR # DEFINED BY SEKSTS SUBROUTINE
7180 030140 004736          JSR          PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
7181 030142 000137 030206   JMP          140$      ;GO TO 140$ IF ERROR WAS FOUND
7182 030146                120$:
7183 030146 004737 061566   JSR          PC,CMPERRSTS ;CHECK ANY ERRORS NOT MASKED
7184 030152 115760          .WORD       ND↑MSK      ;MASK FOR RMER1
7185 030154 000010          .WORD       DPE        ;MASK FOR RMER2
7186 030156 000405          BR          130$      ;GO TO 130$ IF NO ERROR
7187 030160 000240          NOP          ;RETURN HERE IF ERROR
7188 030162 104000          ERROR          ;ERROR # DEFINED BY CMPERRSTS SUBROUTINE
7189 030164 004736          JSR          PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
7190 030166 000137 030206   JMP          140$      ;GO TO 140$ IF ERROR WAS FOUND
7191 030172                130$:
7192 030172 004737 046044   JSR          PC,SECERR   ;GO CHECK FOR SECONDARY ERRORS
7193 030176 000403          BR          140$      ;GO TO 140$ IF NO ERROR
7194 030200 000240          NOP          ;RETURN HERE IF ERROR
7195 030202 104000          ERROR          ;ERROR # DEFINED BY SECERR SUBROUTINE
7196 030204 004736          JSR          PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
7197 030206                140$:
7198                      ;*****
7199                      ;*TEST 46          SEEK PRIME CYLINDERS
7200                      ;*****
7201                      ;*TST46:
7202 030206 000004          SCOPE          ;SCOPE CALL
7203 030210 000240          NOP          ;START OF TEST
7204 030212 012737 000001 001206   MOV          #1,$TIMES ;LOAD ITERATION COUNT
7205 030220 012737 030234 001122   MOV          #1$,$LPADR
7206 030226 012737 030234 001124   MOV          #1$,$LPERR
7207 030234                1$:
7208 030234 012706 001100   MOV          #STACK,SP ;INITIALIZE STACK POINTER
7209 030240 013700 001276   MOV          $BASE,R0  ;R0=UNIBUS ADDRESS
7210 030244 013701 001446   MOV          TSTQUE,R1 ;(R1) = DEVICE BEING TESTED
7211 030250 012737 000046 001226   MOV          #46,$TESTN ;SET TEST NUMBER IN APT MAIL BOX
7212 030256 012737 000001 001432   MOV          #1,$RMDCO ;FIRST CYLINDER WILL BE 1
7213 030264                10$:
7214 030264 004737 043216   JSR          PC,TSTPRP  ;PREPARE DEVICE FOR TEST
7215 030270 054130          .WORD       054130 ;TASK DESCRIPTOR
7216 030272 000404          BR          80$      ;GO TO 80$ IF NO ERROR
7217 030274 000240          NOP          ;RETURN HERE IF ERROR
7218 030276 104000          ERROR          ;ERROR # DEFINED BY TSTPRP SUBROUTINE
7219 030300 000137 030534   JMP          150$      ;GO TO 150$ IF ERROR WAS FOUND
7220 030304 012737 000000 001404 80$:
7221 030312 012737 000005 001376   MOV          #0,$RMDAO ;TRACK = SECTOR = 0
7222 030320 012702 001533   MOV          #SEEK!GO,RMCS10 ;LOAD SEEK COMMAND IN BUFFER
7223 030324 112722 000034   MOV          #RMDC,(R2)+ ;R2 POINTS TO REGISTER TABLE
7224 030330 112722 000006   MOV          #RMDA,(R2)+ ;WRITE REGISTER INDEX TABLE
7225 030334 112722 000000   MOV          #RMCS1,(R2)+
7226 030340 112722 000200   MOV          #200,(R2)+
7227 030344 004737 044466   MOV          PC,PUT     ;WRITE TERMINATOR
7228 030350 000404          JSR          PC,PUT    ;GO WRITE REGISTERS VIA PUT SUB
7229 030352 000240          BR          90$      ;GO TO 90$ IF NO ERROR
7230 030354 104000          NOP          ;RETURN HERE IF ERROR
7231 030356 000137 030510   ERROR          ;ERROR DEFINED BY PUT SUB
7232 030362 004737 044132   JMP          140$      ;GO TO 140$ IF ERROR WAS FOUND
7233 030366 004737 045026   JSR          PC,GETSTS  ;SETUP FOR STATUS FETCH
7234                      JSR          PC,TIMOUT ;WAIT FOR SEEK TO COMPLETE

```

```

7235 030372 004737 044216 JSR PC,GET ;GO READ REGISTERS VIA GET SUB
7236 030376 000404 BR 100$ ;GO TO 100$ IF NO ERROR
7237 030400 000240 NOP ;RETURN HERE IF ERROR
7238 030402 104000 ERROR ;ERROR DEFINED BY GET SUB
7239 030404 000137 030510 JMP 140$ ;GO TO 140$ IF ERROR WAS FOUND
100$:
7241 030410 004737 045212 JSR PC,PRIERR ;GO CHECK FOR PRIMARY ERRORS
7242 030414 000405 BR 110$ ;GO TO 110$ IF NO ERROR
7243 030416 000240 NOP ;RETURN HERE IF ERROR
7244 030420 104000 ERROR ;ERROR # DEFINED BY PRIERR SUBROUTINE
7245 030422 004736 JSR PC,(SP)+ ;GO BACK FOR MORE ERROR CHECKS
7246 030424 000137 030510 JMP 140$ ;GO TO 140$ IF ERROR WAS FOUND
110$:
7248 030430 004737 052120 JSR PC,SEKSTS ;GO VERIFY RESULTS OF SEEK OPERATION
7249 030434 000405 BR 120$ ;GO TO 120$ IF NO ERROR
7250 030436 000240 NOP ;RETURN HERE IF ERROR
7251 030440 104000 ERROR ;ERROR # DEFINED BY SEKSTS SUBROUTINE
7252 030442 004736 JSR PC,(SP)+ ;GO BACK FOR MORE ERROR CHECKS
7253 030444 000137 030510 JMP 140$ ;GO TO 140$ IF ERROR WAS FOUND
120$:
7255 030450 004737 061566 JSR PC,CMPERRSTS ;CHECK ANY ERRORS NOT MASKED
7256 030454 115760 .WORD NDTMSK ;MASK FOR RMER1
7257 030456 000010 .WORD DPE ;MASK FOR RMER2
7258 030460 000405 BR 130$ ;GO TO 130$ IF NO ERROR
7259 030462 000240 NOP ;RETURN HERE IF ERROR
7260 030464 104000 ERROR ;ERROR # DEFINED BY CMPERRSTS SUBROUTINE
7261 030466 004736 JSR PC,(SP)+ ;GO BACK FOR MORE ERROR CHECKS
7262 030470 000137 030510 JMP 140$ ;GO TO 140$ IF ERROR WAS FOUND
130$:
7264 030474 004737 046044 JSR PC,SECERR ;GO CHECK FOR SECONDARY ERRORS
7265 030500 000403 BR 140$ ;GO TO 140$ IF NO ERROR
7266 030502 000240 NOP ;RETURN HERE IF ERROR
7267 030504 104000 ERROR ;ERROR # DEFINED BY SECERR SUBROUTINE
7268 030506 004736 JSR PC,(SP)+ ;GO BACK FOR MORE ERROR CHECKS
7269 030510 013746 001432 MOV RMDCO,-(SP) ;SHIFT TO NEXT PRIME CYLINDER
7270 030514 006316 ASL (SP)
7271 030516 011637 001432 MOV (SP),RMDCO
7272 030522 022726 001000 CMP #512,(SP)+ ;IS THE TEST DONE??
7273 030526 103402 BLO 150$ ;YES!!
7274 030530 000137 030264 JMP 10$ ;GO DO NEXT CYLINDER
150$:
7275 030534
7276
7277
7278 ;*****
7279 ;*TEST 47 SEEK ZERO DIFFERENCE
7280 ;*****
7281
7282 †ST47:
7283 030534 000004 SCOPE ;SCOPE CALL
7284 030536 000240 NOP ;START OF TEST
7285 030540 012737 000001 001206 MOV #1,STIMES ;LOAD ITERATION COUNT
7286 030546 012737 030562 001122 MOV #1$,SLPADR
7287 030554 012737 030562 001124 MOV #1$,SLPERR
1$:
7288 030562
7289 030562 012706 001100 MOV #STACK,SP ;INITIALIZE STACK POINTER
7290 030566 013700 001276 MOV $BASE,RO ;RO=UNIBUS ADDRESS

```

```

7291 030572 013701 001446      MOV    TSTQUE,R1      ;(R1) = DEVICE BEING TESTED
7292 030576 012737 000047      MOV    #47,STESTN    ;;SET TEST NUMBER IN APT MAIL BOX
001226
7293 030604 004737 043216      10$:  JSR    PC,TSTPRP    ;PREPARE DEVICE FOR TEST
7294 030604 054130 000000      .WORD 054130 ;TASK DESCRIPTOR
7295 030610 000404 000000      BR     80$          ;GO TO 80$ IF NO ERROR
7296 030612 000240 000000      NOP
7297 030614 000240 000000      ERROR ;RETURN HERE IF ERROR
7298 030616 104000 000000      ERROR ;ERROR # DEFINED BY TSTPRP SUBROUTINE
7299 030620 000137 031056      JMP    170$        ;GO TO 170$ IF ERROR WAS FOUND
7300 030624 012703 000001      80$:  MOV    #1,R3        ;R3 = NUMBER OF SEEKS
7301 030624 012737 000000      MOV    #0,RMDCO     ;CYLINDER = 0
7302 030630 012737 000000      MOV    #0,RMDAO     ;TRACK = SECTOR = 0
001432
7303 030636 012737 000000      MOV    #SEEK!GO,RMCS10 ;FUNCTION CODE FOR SEEK
001404
7304 030644 012737 000005      MOV    #PUTINX,R2   ;R2 POINTS TO REGISTER INDEX
001376
7305 030652 012702 001533      MOV    #RMDA,(R2)+ ;WRITE REGISTER INDEX TABLE
7306 030656 112722 000006      MOV    #RMDC,(R2)+
7307 030662 112722 000034      MOV    #RMCS1,(R2)+
7308 030666 112722 000000      MOV    #200,(R2)+ ;TERMINATE TABLE
7309 030672 112722 000200
7310 030676 004737 044466      90$:  JSR    PC,PUT      ;GO WRITE REGISTERS VIA PUT SUB
7311 030676 000404 000000      BR     100$       ;GO TO 100$ IF NO ERROR
7312 030702 000240 000000      NOP
7313 030704 000240 000000      ERROR ;RETURN HERE IF ERROR
7314 030706 104000 000000      ERROR ;ERROR DEFINED BY PUT SUB
7315 030710 000137 031056      JMP    170$       ;GO TO 170$ IF ERROR WAS FOUND
7316 030714 004737 044132      100$: JSR    PC,GETSTS   ;SETUP FOR READING STATUS
7317 030720 004737 045026      JSR    PC,TIMOUT   ;WAIT FOR COMPLETION
7318 030724 004737 044216      JSR    PC,GET      ;GO READ REGISTERS VIA GET SUB
7319 030730 000404 000000      BR     120$       ;GO TO 120$ IF NO ERROR
7320 030732 000240 000000      NOP
7321 030734 104000 000000      ERROR ;RETURN HERE IF ERROR
7322 030736 000137 031056      ERROR ;ERROR DEFINED BY GET SUB
7323 030742 000137 031056      JMP    170$       ;GO TO 170$ IF ERROR WAS FOUND
7324 030742 004737 045212      120$: JSR    PC,PRIERR   ;GO CHECK FOR PRIMARY ERRORS
7325 030746 000405 000000      BR     130$       ;GO TO 130$ IF NO ERROR
7326 030750 000240 000000      NOP
7327 030752 104000 000000      ERROR ;RETURN HERE IF ERROR
7328 030754 004736 000000      ERROR ;ERROR # DEFINED BY PRIERR SUBROUTINE
7329 030756 000137 031056      JSR    PC,@(SP)+   ;GO BACK FOR MORE ERROR CHECKS
7330 030762 000137 031056      JMP    170$       ;GO TO 170$ IF ERROR WAS FOUND
7331 030762 004737 052120      130$: JSR    PC,SEKSTS   ;GO VERIFY RESULTS OF SEEK OPERATION
7332 030766 000405 000000      BR     140$       ;GO TO 140$ IF NO ERROR
7333 030770 000240 000000      NOP
7334 030772 104000 000000      ERROR ;RETURN HERE IF ERROR
7335 030774 004736 000000      ERROR ;ERROR # DEFINED BY SEKSTS SUBROUTINE
7336 030776 000137 031056      JSR    PC,@(SP)+   ;GO BACK FOR MORE ERROR CHECKS
7337 031002 000137 031056      JMP    170$       ;GO TO 170$ IF ERROR WAS FOUND
7338 031002 004737 061566      140$: JSR    PC,CMPERRSTS ;CHECK ANY ERRORS NOT MASKED
7339 031006 115760 000000      .WORD ND1MSK     ;MASK FOR RMER1
7340 031010 000010 000000      .WORD DPE        ;MASK FOR RMER2
7341 031012 000405 000000      BR     150$       ;GO TO 150$ IF NO ERROR
7342 031014 000240 000000      NOP
7343 031016 104000 000000      ERROR ;RETURN HERE IF ERROR
7344 031020 004736 000000      ERROR ;ERROR # DEFINED BY CMPERRSTS SUBROUTINE
7345 031022 000137 031056      JSR    PC,@(SP)+   ;GO BACK FOR MORE ERROR CHECKS
7346 031026 000137 031056      JMP    170$       ;GO TO 170$ IF ERROR WAS FOUND
150$:

```



```

7347 031026 004737 046044 JSR PC,SECERR ;GO CHECK FOR SECONDARY ERRORS
7348 031032 000405 BR 160$ ;GO TO 160$ IF NO ERROR
7349 031034 000240 NOP ;RETURN HERE IF ERROR
7350 031036 104000 ERROR ;ERROR # DEFINED BY SECERR SUBROUTINE
7351 031040 004736 JSR PC,(SP)+ ;GO BACK FOR MORE ERROR CHECKS
7352 031042 000137 031056 JMP 170$ ;GO TO 170$ IF ERROR WAS FOUND
7353 031046 160$: DEC R3 ;DONE ALL SEEKS??
7354 031046 005303 BMI 170$ ;YES!!
7355 031050 100402 JMP 90$ ;NO - GO DO NEXT SEEK
7356 031052 000137 030676
7357 031056
7358 ;*****
7359 ;*TEST 50 SEEK MAXIMUM DIFFERENCE FORWARD
7360 ;*****
7361 ;*TST50:
7362 031056
7363 031056 000004 SCOPE ;SCOPE CALL
7364 031060 000240 NOP ;START OF TEST
7365 031062 012737 000002 001206 MOV #2,$TIMES ;LOAD ITERATION COUNT
7366 031070 012737 031104 001122 MOV #1,$SLPADR
7367 031076 012737 031104 001124 MOV #1,$SLPERR
7368 031104
7369 031104 012706 001100 MOV #STACK,SP ;INITIALIZE STACK POINTER
7370 031110 013700 001276 MOV $BASE,R0 ;R0=UNIBUS ADDRESS
7371 031114 013701 001446 MOV TSTQUE,R1 ;(R1) = DEVICE BEING TESTED
7372 031120 012737 000050 001226 MOV #50,$TESTN ;SET TEST NUMBER IN APT MAIL BOX
7373 031126
7374 031126 004737 043216 JSR PC,TSTPRP ;PREPARE DEVICE FOR TEST
7375 031132 054130 .WORD 054130 ;TASK DESCRIPTOR
7376 031134 000404 BR 80$ ;GO TO 80$ IF NO ERROR
7377 031136 000240 NOP ;RETURN HERE IF ERROR
7378 031140 104000 ERROR ;ERROR # DEFINED BY TSTPRP SUBROUTINE
7379 031142 000137 031404 JMP 160$ ;GO TO 160$ IF ERROR WAS FOUND
7380 031146
7381 031146 012737 000000 001432 MOV #0,RMDC0 ;SEEK TO CYLINDER 0
7382 031154 012737 000000 001404 MOV #0,RMDA0 ;TRACK = SECTOR = 0
7383 031162 012737 000005 001376 MOV #SEEK!GO, RMCS10 ;FUNCTION CODE FOR SEEK
7384 031170 012702 001533 MOV #PUTINX,R2 ;R2 POINTS TO REGISTER TABLE
7385 031174 112722 000006 MOVB #RMDA,(R2)+ ;WRITE REGISTER INDEX TABLE
7386 031200 112722 000034 MOVB #RMDC,(R2)+
7387 031204 112722 000000 MOVB #RMCS1,(R2)+
7388 031210 112722 000200 MOVB #200,(R2)+ ;TERMINATE THE TABLE
7389 031214
7390 031214 004737 044466 JSR PC,PUT ;GO WRITE REGISTERS VIA PUT SUB
7391 031220 000404 BR 100$ ;GO TO 100$ IF NO ERROR
7392 031222 000240 NOP ;RETURN HERE IF ERROR
7393 031224 104000 ERROR ;ERROR DEFINED BY PUT SUB
7394 031226 000137 031404 JMP 160$ ;GO TO 160$ IF ERROR WAS FOUND
7395 031232
7396 031232 004737 044132 JSR PC,GETSTS ;SETUP FOR STATUS FETCH
7397 031236 004737 045026 JSR PC,TIMOUT ;WAIT FOR SEEK TO COMPLETE
7398 031242 004737 044216 JSR PC,GET ;GO READ REGISTERS VIA GET SUB
7399 031246 000404 BR 110$ ;GO TO 110$ IF NO ERROR
7400 031250 000240 NOP ;RETURN HERE IF ERROR
7401 031252 104000 ERROR ;ERROR DEFINED BY GET SUB
7402 031254 000137 031404 JMP 160$ ;GO TO 160$ IF ERROR WAS FOUND

```

```

7403 031260          110$:
7404 031260 004737 045212 JSR PC,PRIERR ;GO CHECK FOR PRIMARY ERRORS
7405 031264 000405          BR 120$ ;GO TO 120$ IF NO ERROR
7406 031266 000240          NOP ;RETURN HERE IF ERROR
7407 031270 104000          ERROR ;ERROR # DEFINED BY PRIERR SUBROUTINE
7408 031272 004736          JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
7409 031274 000137 031404 JMP 160$ ;GO TO 160$ IF ERROR WAS FOUND
7410 031300          120$:
7411 031300 004737 052120 JSR PC,SEKSTS ;GO VERIFY RESULTS OF SEEK OPERATION
7412 031304 000405          BR 130$ ;GO TO 130$ IF NO ERROR
7413 031306 000240          NOP ;RETURN HERE IF ERROR
7414 031310 104000          ERROR ;ERROR # DEFINED BY SEKSTS SUBROUTINE
7415 031312 004736          JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
7416 031314 000137 031404 JMP 160$ ;GO TO 160$ IF ERROR WAS FOUND
7417 031320          130$:
7418 031320 004737 061566 JSR PC,CMPEERRSTS ;CHECK ANY ERRORS NOT MASKED
7419 031324 115760          .WORD ND1MSK ;MASK FOR RMER1
7420 031326 000010          .WORD DPE ;MASK FOR RMER2
7421 031330 000405          BR 140$ ;GO TO 140$ IF NO ERROR
7422 031332 000240          NOP ;RETURN HERE IF ERROR
7423 031334 104000          ERROR ;ERROR # DEFINED BY CMPEERRSTS SUBROUTINE
7424 031336 004736          JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
7425 031340 000137 031404 JMP 160$ ;GO TO 160$ IF ERROR WAS FOUND
7426 031344          140$:
7427 031344 004737 046044 JSR PC,SECERR ;GO CHECK FOR SECONDARY ERRORS
7428 031350 000405          BR 150$ ;GO TO 150$ IF NO ERROR
7429 031352 000240          NOP ;RETURN HERE IF ERROR
7430 031354 104000          ERROR ;ERROR # DEFINED BY SECERR SUBROUTINE
7431 031356 004736          JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
7432 031360 000137 031404 JMP 160$ ;GO TO 160$ IF ERROR WAS FOUND
7433 031364          150$:
7434 031364 005737 001432 TST RMDCO ;IS TEST DONE??
7435 031370 001005          BNE 160$ ;YES!!
7436 031372 012737 001466 001432 MOV #822.,RMDCO ;NO - SEEK TO LAST CYLINDER
7437 031400 000137 031214 JMP 90$
7438 031404          160$:
7439          ;*****
7440          ;*TEST 51 SEEK ADJACENT FORWARD
7441          ;*****
7442          ;*****
7443 031404          ;TST51:
7444 031404 000004          SCOPE ;SCOPE CALL
7445 031406 000240          NOP ;START OF TEST
7446 031410 012737 000001 001206 MOV #1,$TIMES ;LOAD ITERATION COUNT
7447 031416 012737 031432 001122 MOV #1,$SLPADR
7448 031424 012737 031432 001124 MOV #1,$SLPERR
7449 031432          1$:
7450 031432 012706 001100          MOV #STACK,SP ;INITIALIZE STACK POINTER
7451 031436 013700 001276          MOV $BASE,R0 ;R0=UNIBUS ADDRESS
7452 031442 013701 001446          MOV TSTQUE,R1 ;(R1) = DEVICE BEING TESTED
7453 031446 012737 000051 001226 MOV #51,$TESTN ;SET TEST NUMBER IN APT MAIL BOX
7454 031454          10$:
7455 031454 004737 043216 JSR PC,TSTPRP ;PREPARE DEVICE FOR TEST
7456 031460 054130          .WORD 80$ ;TASK DESCRIPTOR
7457 031462 000404          BR 80$ ;GO TO 80$ IF NO ERROR
7458 031464 000240          NOP ;RETURN HERE IF ERROR

```

```

7459 031466 104000          ERROR
7460 031470 000137 031732    JMP      160$          ;ERROR # DEFINED BY TSTPRP SUBROUTINE
7461 031474          80$:          ;GO TO 160$ IF ERROR WAS FOUND
7462 031474 012737 000000    001432    MOV      #0,RMDCO      ;CYLINDER = 0
7463 031502 012737 000000    001404    MOV      #0,RMDAO      ;TRACK = SECTOR = 0
7464 031510 012737 000005    001376    MOV      #SEEK!GO,RMCS10 ;FUNCTION CODE FOR SEEK
7465 031516 012702 001533    MOV      #PUTINX,R2     ;R2 POINTS TO REGISTER INDEX
7466 031522 112722 000034    MOV      #RMDC,(R2)+    ;WRITE REGISTER INDEX TABLE
7467 031526 112722 000006    MOV      #RMDA,(R2)+
7468 031532 112722 000000    MOV      #RMCS1,(R2)+
7469 031536 112722 000200    MOV      #200,(R2)+    ;TERMINATE REGISTER TABLE
7470 031542          90$:
7471 031542 004737 044466    JSR      PC,PUT        ;GO WRITE REGISTERS VIA PUT SUB
7472 031546 000404          BR      100$          ;GO TO 100$ IF NO ERROR
7473 031550 000240          NOP
7474 031552 104000          ERROR
7475 031554 000137 031732    JMP      160$          ;GO TO 160$ IF ERROR WAS FOUND
7476 031560 004737 044132    100$:    JSR      PC,GETSTS     ;SETUP FOR STATUS FETCH
7477 031564 004737 045026    JSR      PC,TIMOUT     ;WAIT FOR COMPLETION
7478 031570 004737 044216    JSR      PC,GET        ;GO READ REGISTERS VIA GET SUB
7479 031574 000404          BR      110$          ;GO TO 110$ IF NO ERROR
7480 031576 000240          NOP
7481 031600 104000          ERROR
7482 031602 000137 031732    JMP      160$          ;GO TO 160$ IF ERROR WAS FOUND
7483 031606          110$:
7484 031606 004737 045212    JSR      PC,PRIERR     ;GO CHECK FOR PRIMARY ERRORS
7485 031612 000405          BR      120$          ;GO TO 120$ IF NO ERROR
7486 031614 000240          NOP
7487 031616 104000          ERROR
7488 031620 004736          JSR      PC,@(SP)+     ;GO BACK FOR MORE ERROR CHECKS
7489 031622 000137 031732    JMP      160$          ;GO TO 160$ IF ERROR WAS FOUND
7490 031626          120$:
7491 031626 004737 052120    JSR      PC,SEKSTS     ;GO VERIFY RESULTS OF SEEK OPERATION
7492 031632 000405          BR      130$          ;GO TO 130$ IF NO ERROR
7493 031634 000240          NOP
7494 031636 104000          ERROR
7495 031640 004736          JSR      PC,@(SP)+     ;GO BACK FOR MORE ERROR CHECKS
7496 031642 000137 031732    JMP      160$          ;GO TO 160$ IF ERROR WAS FOUND
7497 031646          130$:
7498 031646 004737 061566    JSR      PC,CMPERRSTS  ;CHECK ANY ERRORS NOT MASKED
7499 031652 115760          .WORD   ND1MSK        ;MASK FOR RMER1
7500 031654 000010          .WORD   DPE           ;MASK FOR RMER2
7501 031656 000405          BR      140$          ;GO TO 140$ IF NO ERROR
7502 031660 000240          NOP
7503 031662 104000          ERROR
7504 031664 004736          JSR      PC,@(SP)+     ;GO BACK FOR MORE ERROR CHECKS
7505 031666 000137 031732    JMP      160$          ;GO TO 160$ IF ERROR WAS FOUND
7506 031672          140$:
7507 031672 004737 046044    JSR      PC,SECERR     ;GO CHECK FOR SECONDARY ERRORS
7508 031676 000405          BR      150$          ;GO TO 150$ IF NO ERROR
7509 031700 000240          NOP
7510 031702 104000          ERROR
7511 031704 004736          JSR      PC,@(SP)+     ;GO BACK FOR MORE ERROR CHECKS
7512 031706 000137 031732    JMP      160$          ;GO TO 160$ IF ERROR WAS FOUND
7513 031712          150$:
7514 031712 005737 001432    TST      RMDCO         ;FIRST TIME THROUGH??

```

```

7515 031716 001005          BNE      160$          ;NO!!
7516 031720 012737 000001 001432  MOV     #1,RMDCO      ;YES - SEEK TO LAST CYLINDER
7517 031726 000137 031542  JMP     90$
7518 031732
7519
7520
7521
7522
7523 031732          ;*****
7524 031732 000004          ;*TEST 52      SEEK ADJACENT REVERSE
7525 031734 000240          ;*****
7526 031736 012737 000001 001206  SCOPE          ;SCOPE CALL
7527 031744 012737 031760 001122  NOP          ;START OF TEST
7528 031752 012737 031760 001124  MOV     #1,$SLPADR    ;LOAD ITERATION COUNT
7529 031760          MOV     #1,$SLPERR
7530 031760 012706 001100 1$:      MOV     #STACK,SP    ;INITIALIZE STACK POINTER
7531 031764 013700 001276  MOV     $BASE,R0     ;R0=UNIBUS ADDRESS
7532 031770 013701 001446  MOV     TSTQUE,R1    ;(R1) = DEVICE BEING TESTED
7533 031774 012737 000052 001226  MOV     #52,$TESTN   ;SET TEST NUMBER IN APT MAIL BOX
7534 032002
7535 032002 004737 043216 10$:     JSR     PC,TSTPRP    ;PREPARE DEVICE FOR TEST
7536 032006 054130          .WORD   054130 ;TASK DESCRIPTOR
7537 032010 000404          BR      80$         ;GO TO 80$ IF NO ERROR
7538 032012 000240          NOP
7539 032014 104000          ERROR   ;RETURN HERE IF ERROR
7540 032016 000137 032260  JMP     160$        ;ERROR # DEFINED BY TSTPRP SUBROUTINE
7541 032022          ;GO TO 160$ IF ERROR WAS FOUND
7542 032022 012737 001466 001432 80$:     MOV     #822,RMDCO   ;START AT LAST CYLINDER
7543 032030 012737 000000 001404  MOV     #0,RMDAO     ;TRACK = SECTOR = 0
7544 032036 012737 000005 001376  MOV     #SEEK!GO,RMCS10 ;FUNCTION CODE FOR SEEK
7545 032044 012702 001533  MOV     #PUTINX,R2   ;R2 POINTS TO REGISTER INDEX
7546 032050 112722 000006  MOV     #RMDA,(R2)+  ;WRITE REGISTER INDEX TABLE
7547 032054 112722 000034  MOV     #RMDC,(R2)+
7548 032060 112722 000000  MOV     #RMCS1,(R2)+
7549 032064 112722 000200  MOV     #200,(R2)+  ;TERMINATE TABLE
7550 032070
7551 032070 004737 044466 90$:     JSR     PC,PUT       ;GO WRITE REGISTERS VIA PUT SUB
7552 032074 000404          BR      100$        ;GO TO 100$ IF NO ERROR
7553 032076 000240          NOP
7554 032100 104000          ERROR   ;RETURN HERE IF ERROR
7555 032102 000137 032260  JMP     160$        ;ERROR DEFINED BY PUT SUB
7556 032106 004737 044132 100$:   JSR     PC,GETSTS    ;GO TO 160$ IF ERROR WAS FOUND
7557 032112 004737 045026  JSR     PC,TIMOUT    ;SETUP FOR STATUS FETCH
7558 032116 004737 044216  JSR     PC,GET       ;WAIT FOR SEEK TO COMPLETE
7559 032122 000404          BR      110$        ;GO READ REGISTERS VIA GET SUB
7560 032124 000240          NOP
7561 032126 104000          ERROR   ;RETURN HERE IF ERROR
7562 032130 000137 032260  JMP     160$        ;ERROR DEFINED BY GET SUB
7563 032134
7564 032134 004737 045212 110$:   JSR     PC,PRIERR    ;GO CHECK FOR PRIMARY ERRORS
7565 032140 000405          BR      120$        ;GO TO 120$ IF NO ERROR
7566 032142 000240          NOP
7567 032144 104000          ERROR   ;RETURN HERE IF ERROR
7568 032146 004736  JSR     PC,(SP)+     ;ERROR # DEFINED BY PRIERR SUBROUTINE
7569 032150 000137 032260  JMP     160$        ;GO BACK FOR MORE ERROR CHECKS
7570 032154          ;GO TO 160$ IF ERROR WAS FOUND

```

```

7571 032154 004737 052120 JSR PC_SEKSTS ;GO VERIFY RESULTS OF SEEK OPERATION
7572 032160 000405 BR 130$ ;GO TO 130$ IF NO ERROR
7573 032162 000240 NOP ;RETURN HERE IF ERROR
7574 032164 104000 ERROR ;ERROR # DEFINED BY SEKSTS SUBROUTINE
7575 032166 004736 JSR PC_2(SP)+ ;GO BACK FOR MORE ERROR CHECKS
7576 032170 000137 032260 JMP 160$ ;GO TO 160$ IF ERROR WAS FOUND
7577 032174 130$: JSR PC_CMPERRSTS ;CHECK ANY ERRORS NOT MASKED
7578 032174 004737 061566 .WORD NDTMSK ;MASK FOR RMR1
7579 032200 115760 .WORD DPE ;MASK FOR RMR2
7580 032202 000010 BR 140$ ;GO TO 140$ IF NO ERROR
7581 032204 000405 NOP ;RETURN HERE IF ERROR
7582 032206 000240 ERROR ;ERROR # DEFINED BY CMPERRSTS SUBROUTINE
7583 032210 104000 JSR PC_2(SP)+ ;GO BACK FOR MORE ERROR CHECKS
7584 032212 004736 JMP 160$ ;GO TO 160$ IF ERROR WAS FOUND
7585 032214 000137 032260 140$: JSR PC_SECERR ;GO CHECK FOR SECONDARY ERRORS
7586 032220 004737 046044 BR 150$ ;GO TO 150$ IF NO ERROR
7587 032222 000405 NOP ;RETURN HERE IF ERROR
7588 032224 000240 ERROR ;ERROR # DEFINED BY SECERR SUBROUTINE
7589 032226 000240 JSR PC_2(SP)+ ;GO BACK FOR MORE ERROR CHECKS
7590 032230 104000 JMP 160$ ;GO TO 160$ IF ERROR WAS FOUND
7591 032232 004736 150$: CMP #822.,RMDCO ;IS THIS THE FIRST SEEK??
7592 032234 000137 032260 BNE 160$ ;NO!!
7593 032240 000137 032260 DEC RMDCO ;YES - SEEK TO ADJACENT CYLINDER
7594 032240 022737 001466 001432 JMP 90$ ;GO SEEK
7595 032246 001004
7596 032250 005337 001432
7597 032254 000137 032070
7598 032260
7599
7600 *****
7601 *TEST 53 SEEK INVALID SECTOR
7602 *****
7603 †ST53: SCOPE ;SCOPE CALL
7604 NOP ;START OF TEST
7605 032260 000004 MOV #STACK,SP ;INITIALIZE STACK POINTER
7606 032264 012706 001100 MOV $BASE,R0 ;R0=UNIBUS ADDRESS
7607 032270 013700 001276 MOV TSTQUE,R1 ;(R1) = DEVICE BEING TESTED
7608 032274 013701 001446 MOV #53,$TESTN ;;SET TEST NUMBER IN APT MAIL BOX
7609 032300 012737 000053 001226
7610 032306 10$: JSR PC_TSTPRP ;PREPARE DEVICE FOR TEST
7611 032306 004737 043216 .WORD 054130 ;TASK DESCRIPTOR
7612 032312 054130 BR 80$ ;GO TO 80$ IF NO ERROR
7613 032314 000404 NOP ;RETURN HERE IF ERROR
7614 032316 000240 ERROR ;ERROR # DEFINED BY TSTPRP SUBROUTINE
7615 032320 104000 JMP 180$ ;GO TO 180$ IF ERROR WAS FOUND
7616 032322 000137 032646 80$: MOV #SEEK!GO,RMCS10 ;SEEK COMMAND
7617 032326 012737 000005 001376 MOV #0,RMFOF ;RESET FORMAT 16 BIT
7618 032334 012737 000000 001430 MOV #0,RMDCO ;CYLINDER=0
7619 032342 012737 000000 001432 MOV #30,RMDAO ;SECTOR=30,TRACK=0
7620 032350 012737 000036 001404 MOV #PUTINX,R2 ;R2 POINTS TO REGISTER TABLE
7621 032356 012702 001533 MOVB #RMDF,(R2)+ ;WRITE REGISTER INDEX TABLE
7622 032362 112722 000032 MOVB #RMDA,(R2)+
7623 032366 112722 000006 MOVB #RMDC,(R2)+
7624 032372 112722 000034 MOVB #RMCS1,(R2)+
7625 032376 112722 000000 MOVB #200,(R2)+
7626 032402 112722 000200 ;TERMINATE TABLE

```

7627	032406	004737	044132		JSR	PC,GETSTS	;SETUP INPUT REGISTER INDEX
7628	032412			90\$:			
7629	032412	004737	053360		JSR	PC,CNTCLR	
7630	032416	000404			BR	95\$	;GO TO 95\$ IF NO ERROR
7631	032420	000240			NOP		;RETURN HERE IF ERROR
7632	032422	104000			ERROR		;ERROR NUMBER DEFINED BY SUB
7633	032424	000137	032646		JMP	180\$	;GO TO 180\$ IF ERROR WAS FOUND
7634	032430			95\$:			
7635	032430	004737	044216		JSR	PC,GET	;GO READ REGISTERS VIA GET SUB
7636	032434	000404			BR	100\$	;GO TO 100\$ IF NO ERROR
7637	032436	000240			NOP		;RETURN HERE IF ERROR
7638	032440	104000			ERROR		;ERROR DEFINED BY GET SUB
7639	032442	000137	032646		JMP	180\$	;GO TO 180\$ IF ERROR WAS FOUND
7640	032446			100\$:			
7641	032446	004737	053476		JSR	PC,CLSTS	;GO VERIFY CONTROLLER CLEAR OPERATION
7642	032452	000405			BR	110\$	;GO TO 110\$ IF NO ERROR
7643	032454	000240			NOP		;RETURN HERE IF ERROR
7644	032456	104000			ERROR		;ERROR # DEFINED BY CLSTS SUBROUTINE
7645	032460	004736			JSR	PC,@(SP)+	;GO BACK FOR MORE ERROR CHECKS
7646	032462	000137	032646		JMP	180\$	;GO TO 180\$ IF ERROR WAS FOUND
7647	032466			110\$:			
7648	032466	004737	044466		JSR	PC,PUT	;GO WRITE REGISTERS VIA PUT SUB
7649	032472	000404			BR	120\$	;GO TO 120\$ IF NO ERROR
7650	032474	000240			NOP		;RETURN HERE IF ERROR
7651	032476	104000			ERROR		;ERROR DEFINED BY PUT SUB
7652	032500	000137	032626		JMP	170\$	;GO TO 170\$ IF ERROR WAS FOUND
7653	032504	004737	045026	120\$:	JSR	PC,TIMOUT	;WAIT FOR GO TO RESET
7654	032510	004737	044216		JSR	PC,GET	;GO READ REGISTERS WITH GET SUBROUTINE
7655	032514	000404			BR	125\$	;GO TO 125\$ IF NO ERROR
7656	032516	000240			NOP		;RETURN HERE IF ERROR
7657	032520	104000			ERROR		;ERROR # DEFINED BY GET SUBROUTINE
7658	032522	000137	032646		JMP	180\$	;GO TO 180\$ IF ERROR WAS FOUND
7659	032526			125\$:			
7660	032526	004737	045212		JSR	PC,PRIERR	;GO CHECK FOR PRIMARY ERRORS
7661	032532	000405			BR	130\$	;GO TO 130\$ IF NO ERROR
7662	032534	000240			NOP		;RETURN HERE IF ERROR
7663	032536	104000			ERROR		;ERROR # DEFINED BY PRIERR SUBROUTINE
7664	032540	004736			JSR	PC,@(SP)+	;GO BACK FOR MORE ERROR CHECKS
7665	032542	000137	032646		JMP	180\$	;GO TO 180\$ IF ERROR WAS FOUND
7666	032546			130\$:			
7667	032546	004737	052120		JSR	PC,SEKSTS	;GO VERIFY RESULTS OF SEEK OPERATION
7668	032552	000405			BR	140\$	;GO TO 140\$ IF NO ERROR
7669	032554	000240			NOP		;RETURN HERE IF ERROR
7670	032556	104000			ERROR		;ERROR # DEFINED BY SEKSTS SUBROUTINE
7671	032560	004736			JSR	PC,@(SP)+	;GO BACK FOR MORE ERROR CHECKS
7672	032562	000137	032646		JMP	180\$	;GO TO 180\$ IF ERROR WAS FOUND
7673	032566			140\$:			
7674	032566			150\$:			
7675	032566	004737	061566		JSR	PC,CMPERRSTS	;CHECK ANY ERRORS NOT MASKED
7676	032572	117760			.WORD	IAE!NDTMSK	;MASK FOR RMER1
7677	032574	000010			.WORD	DPE	;MASK FOR RMER2
7678	032576	000405			BR	160\$	;GO TO 160\$ IF NO ERROR
7679	032600	000240			NOP		;RETURN HERE IF ERROR
7680	032602	104000			ERROR		;ERROR # DEFINED BY CMPERRSTS SUBROUTINE
7681	032604	004736			JSR	PC,@(SP)+	;GO BACK FOR MORE ERROR CHECKS
7682	032606	000137	032626		JMP	170\$	;GO TO 170\$ IF ERROR WAS FOUND

```

7683 032612
7684 032612 004737 046044
7685 032616 000403
7686 032620 000240
7687 032622 104000
7688 032624 004736
7689 032626 005237 001404
7690 032632 022737 000037 001404
7691 032640 103402
7692 032642 000137 032412
7693 032646
7694
7695
7696
7697
7698 032646
7699 032646 000004
7700 032650 000240
7701 032652 012706 001100
7702 032656 013700 001276
7703 032662 013701 001446
7704 032666 012737 000054 001226
7705
7706 032674 004737 043216
7707 032700 054130
7708 032702 000404
7709 032704 000240
7710 032706 104000
7711 032710 000137 033262
7712 032714 012737 000005 001376
7713 032722 012737 000000 001432
7714 032730 012737 002400 001404
7715 032736 012737 000000 001430
7716 032744 012702 001533
7717 032750 112722 000032
7718 032754 112722 000034
7719 032760 112722 000006
7720 032764 112722 000000
7721 032770 112722 000200
7722 032774 004737 044132
7723 033000
7724 033000 004737 053360
7725 033004 000404
7726 033006 000240
7727 033010 104000
7728 033012 000137 033262
7729 033016
7730 033016 004737 044216
7731 033022 000404
7732 033024 000240
7733 033026 104000
7734 033030 000137 033262
7735 033034
7736 033034 004737 053476
7737 033040 000405
7738 033042 000240

```

```

160$: JSR PC, SECERR ;GO CHECK FOR SECONDARY ERRORS
      BR 170$ ;GO TO 170$ IF NO ERROR
      NOP ;RETURN HERE IF ERROR
      ERROR ;ERROR # DEFINED BY SECERR SUBROUTINE
170$: JSR PC, 2(SP)+ ;GO BACK FOR MORE ERROR CHECKS
      INC RMDAO ;INCREMENT SECTOR ADDRESS
      CMP #31, RMDAO ;DONE??
      BLO 180$ ;YES!!
      JMP 90$ ;NO - TEST NEXT SECTOR
180$:

```

```

*****
*TEST 54 SEEK INVALID TRACK
*****
TST54:
      SCOPE ;SCOPE CALL
      NOP ;START OF TEST
      MOV #STACK, SP ;INITIALIZE STACK POINTER
      MOV $BASE, R0 ;R0=UNIBUS ADDRESS
      MOV TSTQUE, R1 ;(R1) = DEVICE BEING TESTED
      MOV #54, $TESTN ;SET TEST NUMBER IN APT MAIL BOX
      JSR PC, TSTPRP ;PREPARE DEVICE FOR TEST
      .WORD 054130 ;TASK DESCRIPTOR
      BR 80$ ;GO TO 80$ IF NO ERROR
      NOP ;RETURN HERE IF ERROR
      ERROR ;ERROR # DEFINED BY TSTPRP SUBROUTINE
      JMP 200$ ;GO TO 200$ IF ERROR WAS FOUND
80$: MOV #SEEK!GO, RMCS10 ;SEEK COMMAND
      MOV #0, RMDCO ;DESIRED CYLINDER=0
      MOV #002400, RMDAO ;SECTOR=0, TRACK=5
      MOV #0, RMOF0 ;18 BIT FORMAT
      MOV #PUTINX, R2 ;R2 POINTS TO REGISTER TABLE
      MOVB #RMOF, (R2)+ ;WRITE REGISTER INDEX
      MOVB #RMDC, (R2)+ ;TABLE FOR OUTPUT
      MOVB #RMDA, (R2)+
      MOVB #RMCS1, (R2)+
      MOVB #200, (R2)+ ;TERMINATE TABLE
      JSR PC, GETSTS ;SETUP INPUT TABLE FOR STATUS
90$: JSR PC, CNTCLR
      BR 95$ ;GO TO 95$ IF NO ERROR
      NOP ;RETURN HERE IF ERROR
      ERROR ;ERROR NUMBER DEFINED BY SUB
      JMP 200$ ;GO TO 200$ IF ERROR WAS FOUND
95$: JSR PC, GET
      BR 100$ ;GO TO 100$ IF NO ERROR
      NOP ;RETURN HERE IF ERROR
      ERROR ;ERROR DEFINED BY GET SUB
      JMP 200$ ;GO TO 200$ IF ERROR WAS FOUND
100$: JSR PC, CLRSTS ;GO VERIFY CONTROLLER CLEAR OPERATION
      BR 110$ ;GO TO 110$ IF NO ERROR
      NOP ;RETURN HERE IF ERROR

```

C13

```

7735 033044 104000          ERROR
7740 033046 004736          JSR      PC,2(SP)+
7741 033050 000137 033262    JMP      200$          ;ERROR # DEFINED BY CLSTS SUBROUTINE
7742 033054          110$:          ;GO BACK FOR MORE ERROR CHECKS
7743 033054 004737 044466          JSR      PC,PUT          ;GO TO 200$ IF ERROR WAS FOUND
7744 033050 000404          BR      120$          ;GO WRITE REGISTERS VIA PUT SUB
7745 033062 000240          NOP          ;RETURN HERE IF NO ERROR
7746 033064 104000          ERROR          ;RETURN HERE IF ERROR
7747 033066 000137 033262    JMP      200$          ;ERROR # DEFINED BY PUT SUB
7748 033072 004737 045026    120$:          JSR      PC,TIMOUT      ;GO TO 200$ IF ERROR WAS FOUND
7749 033076 004737 044216    JSR      PC,GET          ;WAIT FOR GO TO RESET
7750 033102 000404          BR      130$          ;GO READ REGISTERS VIA GET SUB
7751 033104 000240          NOP          ;GO TO 130$ IF NO ERROR
7752 033106 104000          ERROR          ;RETURN HERE IF ERROR
7753 033110 000137 033262    JMP      200$          ;ERROR # DEFINED BY GET SUB
7754 033114          130$:          ;GO TO 200$ IF ERROR WAS FOUND
7755 033114 004737 045212    JSR      PC,PRIERR      ;GO CHECK FOR PRIMARY ERRORS
7756 033120 000405          BR      140$          ;GO TO 140$ IF NO ERROR
7757 033122 000240          NOP          ;RETURN HERE IF ERROR
7758 033124 104000          ERROR          ;ERROR # DEFINED BY PRIERR SUBROUTINE
7759 033126 004736          JSR      PC,2(SP)+
7760 033130 000137 033262    JMP      200$          ;GO BACK FOR MORE ERROR CHECKS
7761 033134          140$:          ;GO TO 200$ IF ERROR WAS FOUND
7762 033134 004737 052120    JSR      PC,SEKSTS      ;GO VERIFY RESULTS OF SEEK OPERATION
7763 033140 000405          BR      150$          ;GO TO 150$ IF NO ERROR
7764 033142 000240          NOP          ;RETURN HERE IF ERROR
7765 033144 104000          ERROR          ;ERROR # DEFINED BY SEKSTS SUBROUTINE
7766 033146 004736          JSR      PC,2(SP)+
7767 033150 000137 033214    JMP      180$          ;GO BACK FOR MORE ERROR CHECKS
7768 033154          150$:          ;GO TO 180$ IF ERROR WAS FOUND
7769 033154          160$:
7770 033154 004737 061566    JSR      PC,CMPERRSTS   ;CHECK ANY ERRORS NOT MASKED
7771 033160 117760          .WORD    IAE!NDTMSK    ;MASK FOR RMR1
7772 033162 000010          .WORD    DPE          ;MASK FOR RMR2
7773 033164 000405          BR      170$          ;GO TO 170$ IF NO ERROR
7774 033166 000240          NOP          ;RETURN HERE IF ERROR
7775 033170 104000          ERROR          ;ERROR # DEFINED BY CMPERRSTS SUBROUTINE
7776 033172 004736          JSR      PC,2(SP)+
7777 033174 000137 033214    JMP      180$          ;GO BACK FOR MORE ERROR CHECKS
7778 033200          170$:          ;GO TO 180$ IF ERROR WAS FOUND
7779 033200 004737 046044    JSR      PC,SECERR      ;GO CHECK FOR SECONDARY ERRORS
7780 033204 000403          BR      180$          ;GO TO 180$ IF NO ERROR
7781 033206 000240          NOP          ;RETURN HERE IF ERROR
7782 033210 104000          ERROR          ;ERROR # DEFINED BY SECERR SUBROUTINE
7783 033212 004736          JSR      PC,2(SP)+
7784 033214 062737 000400 001404 180$:          ADD      #400,RMDAO     ;GO BACK FOR MORE ERROR CHECKS
7785 033222 022737 003400 001404          CMP      #003400,RMDAO ;INCREMENT TRACK ADDRESS
7786 033230 103012          BHS     195$          ;DONE??
7787 033232 032737 010000 001430 190$:          BIT      #FMT16,RMOFO  ;NO-DO NEXT TRACK
7788 033240 001010          BNE     200$          ;WAS TEST DONE FOR 16 BIT??
7789 033242 012737 010000 001430          MOV      #FMT16,RMOFO  ;YES!!
7790 033250 012737 002400 001404          MOV      #002400,RMDAO ;SET FORMAT 16
7791 033256 000137 033000          195$:          JMP      90$          ;TRACK = 5
7792 033262          200$:          ;DO TEST FOR 16 BIT FORMAT
7793
7794

```

::\*\*\*\*\*



```
7795 ;*TEST 55 SEEK INVALID CYLINDER  
7796 ;*****  
7797 TST55: SCOPE ;SCOPE CALL  
7798 033262 000004 NOP ;START OF TEST  
7799 033264 000240 MOV #STACK,SP ;INITIALIZE STACK POINTER  
7800 033266 012706 001100 MOV $BASE,R0 ;R0=UNIBUS ADDRESS  
7801 033272 013700 001276 MOV TSTQUE,R1 ;(R1) = DEVICE BEING TESTED  
7802 033276 013701 001446 MOV #55,$TESTN ;SET TEST NUMBER IN APT MAIL BOX  
7803 033302 012737 000055 001226 JSR PC,TSTPRP ;PREPARE DEVICE FOR TEST  
7804 .WORD 054130 ;TASK DESCRIPTOR  
7805 033310 004737 043216 BR 80$ ;GO TO 80$ IF NO ERROR  
7806 033314 054130 ;TASK DESCRIPTOR  
7807 033316 000404 NOP ;RETURN HERE IF ERROR  
7808 033320 000240 ERROR ;ERROR # DEFINED BY TSTPRP SUBROUTINE  
7809 033322 104000 JMP 200$ ;GO TO 200$ IF ERROR WAS FOUND  
7810 033324 000137 033674 80$: MOV #SEEK!GO,RMCS10 ;SEEK FUNCTION CODE  
7811 033330 012737 000005 001376 MOV #0,RMDAO ;SECTOR = TRACK = 0  
7812 033336 012737 000000 001404 MOV #823,RMDCO ;CYLINDER = 823  
7813 033344 012737 001467 001432 MOV #0,RMOFO ;18 BIT FORMAT  
7814 033352 012737 000000 001430 MOV #PUTINX,R2 ;R2 POINTS TO INDEX TABLE  
7815 033360 012702 001533 MOVB #RMDA,(R2)+ ;WRITE REGISTER TABLE  
7816 033364 112722 000006 MOVB #RMDC,(R2)+  
7817 033370 112722 000034 MOVB #RMOF,(R2)+  
7818 033374 112722 000032 MOVB #RMCS1,(R2)+  
7819 033400 112722 000000 MOVB #200,(R2)+ ;TERMINATE TABLE  
7820 033404 112722 000200 JSR PC,GETSTS ;SETUP FOR STATUS  
7821 033410 004737 044132 90$: JSR PC,CNTCLR  
7822 033414 004737 053360 BR 95$ ;GO TO 95$ IF NO ERROR  
7823 033414 004737 053360 NOP ;RETURN HERE IF ERROR  
7824 033420 000404 ERROR ;ERROR NUMBER DEFINED BY SUB  
7825 033422 000240 JMP 180$ ;GO TO 180$ IF ERROR WAS FOUND  
7826 033424 104000 95$: JSR PC,GET  
7827 033426 000137 033630 BR 100$ ;GO TO 100$ IF NO ERROR  
7828 033432 004737 044216 NOP ;RETURN HERE IF ERROR  
7829 033432 004737 044216 ERROR ;ERROR DEFINED BY GET SUB  
7830 033436 000404 JMP 180$ ;GO TO 180$ IF ERROR WAS FOUND  
7831 033440 000240 100$: JSR PC,CLRSTS ;GO VERIFY CONTROLLER CLEAR OPERATION  
7832 033442 104000 BR 110$ ;GO TO 110$ IF NO ERROR  
7833 033444 000137 033630 NOP ;RETURN HERE IF ERROR  
7834 033450 004737 053476 ERROR ;ERROR # DEFINED BY CLRSTS SUBROUTINE  
7835 033450 004737 053476 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS  
7836 033454 000405 BR 120$ ;GO TO 120$ IF NO ERROR  
7837 033456 000240 NOP ;RETURN HERE IF ERROR  
7838 033460 104000 ERROR ;ERROR DEFINED BY PUT SUB  
7839 033462 004736 JSR PC,PUT ;GO WRITE REGISTERS VIA PUT SUB  
7840 033464 000137 033630 BR 130$ ;GO TO 130$ IF NO ERROR  
7841 033470 004737 044466 BR 120$ ;GO TO 120$ IF NO ERROR  
7842 033470 004737 044466 NOP ;RETURN HERE IF ERROR  
7843 033474 000404 ERROR ;ERROR DEFINED BY PUT SUB  
7844 033476 000240 JMP 180$ ;GO TO 180$ IF ERROR WAS FOUND  
7845 033500 104000 120$: JSR PC,TIMOUT ;WAIT FOR GO TO RESET  
7846 033502 000137 033630 JSR PC,GET ;GO READ REGISTERS VIA GET SUB  
7847 033506 004737 045026 BR 130$ ;GO TO 130$ IF NO ERROR  
7848 033512 004737 044216 BR 130$ ;GO TO 130$ IF NO ERROR  
7849 033516 000404 JSR PC,GET ;GO READ REGISTERS VIA GET SUB  
7850 033520 000240 NOP ;RETURN HERE IF ERROR
```

```

7851 033522 104000          ERROR          ;ERROR DEFINED BY GET SUB
7852 033524 000137 033630 130$: JMP 180$ ;GO TO 180$ IF ERROR WAS FOUND
7853 033530          ;GO CHECK FOR PRIMARY ERRORS
7854 033530 004737 045212 JSR PC,PRIERR ;GO TO 140$ IF NO ERROR
7855 033534 000405 BR 140$ ;RETURN HERE IF ERROR
7856 033536 000240 NOP ;ERROR # DEFINED BY PRIERR SUBROUTINE
7857 033540 104000 ERROR ;GO BACK FOR MORE ERROR CHECKS
7858 033542 004736 JSR PC,(SP)+ ;GO TO 180$ IF ERROR WAS FOUND
7859 033544 000137 033630 JMP 180$
7860 033550          ;GO VERIFY RESULTS OF SEEK OPERATION
7861 033550 004737 052120 JSR PC,SEKSTS ;GO TO 150$ IF NO ERROR
7862 033554 000405 BR 150$ ;RETURN HERE IF ERROR
7863 033556 000240 NOP ;ERROR # DEFINED BY SEKSTS SUBROUTINE
7864 033560 104000 ERROR ;GO BACK FOR MORE ERROR CHECKS
7865 033562 004736 JSR PC,(SP)+ ;GO TO 180$ IF ERROR WAS FOUND
7866 033564 000137 033630 JMP 180$
7867 033570          ;CHECK ANY ERRORS NOT MASKED
7868 033570          ;MASK FOR RMER1
7869 033570 004737 061566 JSR PC,CMPERRSTS ;MASK FOR RMER2
7870 033574 117760 .WORD IAE!NDTMSK ;GO TO 170$ IF NO ERROR
7871 033576 000010 .WORD DPE ;RETURN HERE IF ERROR
7872 033600 000405 BR 170$ ;ERROR # DEFINED BY CMPERRSTS SUBROUTINE
7873 033602 000240 NOP ;GO BACK FOR MORE ERROR CHECKS
7874 033604 104000 ERROR ;GO TO 180$ IF ERROR WAS FOUND
7875 033606 004736 JSR PC,(SP)+
7876 033610 000137 033630 JMP 180$
7877 033614          ;GO CHECK FOR SECONDARY ERRORS
7878 033614 004737 046044 JSR PC,SECERR ;GO TO 180$ IF NO ERROR
7879 033620 000403 BR 180$ ;RETURN HERE IF ERROR
7880 033622 000240 NOP ;ERROR # DEFINED BY SECERR SUBROUTINE
7881 033624 104000 ERROR ;GO BACK FOR MORE ERROR CHECKS
7882 033626 004736 JSR PC,(SP)+ ;INCREMENT CYLINDER ADDRESS
7883 033630 005237 001432 180$: INC RMDCO ;DONE??
7884 033634 022737 002000 001432 CMP #1024.,RMDCO ;NO-DO NEXT CYLINDER
7885 033642 101012 BHI 195$ ;16 BIT FORMAT TESTED??
7886 033644 032737 010000 001430 190$: BIT #FMT16,RMOFO ;YESS!!
7887 033652 001010 BNE 200$ ;SETUP FOR 16 BIT TEST
7888 033654 012737 010000 001430 MOV #FMT16,RMOFO
7889 033662 012737 001467 001432 MOV #223.,RMDCO
7890 033670 000137 033414 195$: JMP 90$
7891 033674 200$:

```

```

*****
;TEST 56 IVC SEEK TEST
*****

```

```

TST56:
7896 033674          ;SCOPE CALL
7897 033674 000004 NOP ;START OF TEST
7898 033676 000240 MOV #STACK,SP ;INITIALIZE STACK POINTER
7899 033700 012706 001100 MOV $BASE,R0 ;R0=UNIBUS ADDRESS
7900 033704 013700 001276 MOV TSTQUE,R1 ;(R1) = DEVICE BEING TESTED
7901 033710 013701 001446 MOV #56,$TESTN ;;SET TEST NUMBER IN APT MAIL BOX
7902 033714 012737 000056 001226
7903
7904 033722 004737 053360 JSR PC,CNTCLR
7905 033726 000404 BR 10$ ;GO TO 10$ IF NO ERROR
7906 033730 000240 NOP ;RETURN HERE IF ERROR

```

```

7907 033732 104000          ERROR          ;ERROR NUMBER DEFINED BY SUB
7908 033734 000137 034234  JMP          90$          ;GO TO 90$ IF ERROR WAS FOUND
7909 033740          10$:
7910 033740 112737 000024 001533  MOVB        #RMMR1,PUTINX ;SETUP PUT INDEX TABLE
7911 033746 112737 000200 001534  MOVB        #200,PUTINX+1 ;WRITE TERMINATOR BYTE
7912 033754 012737 000001 001422  MOV         #DMD,RMMR10   ;RMMR1=DMD
7913 033762 004737 044466          JSR         PC,PUT        ;GO WRITE RMMR1 VIA SUB
7914 033766 000404          BR          20$          ;GO TO 20$ IF NO ERROR
7915 033770 000240          NOP          ;RETURN HERE IF ERROR
7916 033772 104000          ERROR          ;ERROR NUMBER DEFINED BY PUT SUB
7917 033774 000137 034234  JMP          90$          ;GO TO 90$ IF ERROR WAS FOUND
7918 034000          20$:
7919 034000 012737 000005 001376  MOV         #SEEK!GO,RMCS10
7920 034006 012737 000000 001422  MOV         #0,RMMR10
7921 034014 012737 000000 001404  MOV         #0,RMDAO       ;SECTOR=TRACK=0
7922 034022 012737 000000 001432  MOV         #0,RMDCO       ;CYLINDER=0
7923 034030 012702 001533          MOV         #PUTINX,R2    ;WRITE REGISTER INDEX
7924 034034 112722 000024          MOVB       #RMMR1,(R2)+  ;TABLE
7925 034040 112722 000006          MOVB       #RMDA,(R2)+
7926 034044 112722 000034          MOVB       #RMDC,(R2)+
7927 034050 112722 000000          MOVB       #RMCS1,(R2)+
7928 034054 112722 000200          MOVB       #200,(R2)+
7929 034060 004737 044132          JSR         PC,GETSTS    ;SETUP FOR STATUS
7930 034064 004737 044466          JSR         PC,PUT        ;GO WRITE REGISTERS VIA PUT SUB
7931 034070 000404          BR          30$          ;GO TO 30$ IF NO ERROR
7932 034072 000240          NOP          ;RETURN HERE IF ERROR
7933 034074 104000          ERROR          ;ERROR DEFINED BY PUT SUB
7934 034076 000137 034234  JMP          90$          ;GO TO 90$ IF ERROR WAS FOUND
7935 034102          30$:
7936 034102 004737 044216          JSR         PC,GET        ;GO READ REGISTERS VIA GET SUB
7937 034106 000404          BR          40$          ;GO TO 40$ IF NO ERROR
7938 034110 000240          NOP          ;RETURN HERE IF ERROR
7939 034112 104000          ERROR          ;ERROR DEFINED BY GET SUB
7940 034114 000137 034234  JMP          90$          ;GO TO 90$ IF ERROR WAS FOUND
7941 034120          40$:
7942 034120 004737 045212          JSR         PC,PRIERR    ;GO CHECK FOR PRIMARY ERRORS
7943 034124 000405          BR          50$          ;GO TO 50$ IF NO ERROR
7944 034126 000240          NOP          ;RETURN HERE IF ERROR
7945 034130 104000          ERROR          ;ERROR # DEFINED BY PRIERR SUBROUTINE
7946 034132 004736          JSR         PC,@(SP)+    ;GO BACK FOR MORE ERROR CHECKS
7947 034134 000137 034234  JMP          90$          ;GO TO 90$ IF ERROR WAS FOUND
7948 034140 032737 010000 001370 50$:
7949 034146 001012          BIT         #IVC,RMER2I  ;DID INVALID COMMAND SET??
7950 034150 012737 010000 001140          BNE        60$          ;YES!!
7951 034156 013737 001370 001142          MOV         #IVC,$GDDAT  ;GOOD DATA FOR TYPEOUT
7952 034164 042737 167777 001142          MOV         #RMER2I,$BDDAT ;BAD DATA FOR TYPEOUT
7953 034172 104064          BIC        #↑CIVC,$BDDAT
7954 034174          ERROR          64          ;IVC NOT DETECTED
7955 034174          60$:
7956 034174 004737 061566          JSR         PC,CMPEERRSTS ;CHECK ANY ERRORS NOT MASKED
7957 034200 115760          .WORD      NOTMSK       ;MASK FOR RMER1
7958 034202 010010          .WORD      IVC!DPE     ;MASK FOR RMER2
7959 034204 000405          BR          80$          ;GO TO 80$ IF NO ERROR
7960 034206 000240          NOP          ;RETURN HERE IF ERROR
7961 034210 104000          ERROR          ;ERROR # DEFINED BY CMPEERRSTS SUBROUTINE
7962 034212 004736          JSR         PC,@(SP)+    ;GO BACK FOR MORE ERROR CHECKS

```

```

7963 034214 000137 034234
7964 034220
7965 034220 004737 046044
7966 034224 000403
7967 034226 000240
7968 034230 104000
7969 034232 004736
7970 034234
7971
7972
7973
7974
7975 034234
7976 034234 000004
7977 034236 000240
7978 034240 012706 001100
7979 034244 013700 001276
7980 034250 013701 001446
7981 034254 012737 000057 001226
7982
7983 034262 004737 043216
7984 034266 054130
7985 034270 000404
7986 034272 000240
7987 034274 104000
7988 034276 000137 034576
7989 034302 012737 040000 001412
7990 034310 012737 000000 001404

```

```

80$: JMP 90$ ;GO TO 90$ IF ERROR WAS FOUND
JSR PC,SECERR ;GO CHECK FOR SECONDARY ERRORS
BR 90$ ;GO TO 90$ IF NO ERROR
NOP ;RETURN HERE IF ERROR
ERROR ;ERROR # DEFINED BY SECERR SUBROUTINE
JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS

90$:

;*****
;*TEST 57 ABORT SEEK TEST
;*****
†ST57:
SCOPE ;SCOPE CALL
NOP ;START OF TEST
MOV #STACK,SP ;INITIALIZE STACK POINTER
MOV $BASE,R0 ;R0=UNIBUS ADDRESS
MOV TSTQUE,R1 ;(R1) = DEVICE BEING TESTED
MOV #57,$TESTN ;;SET TEST NUMBER IN APT MAIL BOX

JSR PC,TSTPRP ;PREPARE DEVICE FOR TEST
WORD 054130 ;TASK DESCRIPTOR
BR 80$ ;GO TO 80$ IF NO ERROR
NOP ;RETURN HERE IF ERROR
ERROR ;ERROR # DEFINED BY TSTPRP SUBROUTINE
JMP 160$ ;GO TO 160$ IF ERROR WAS FOUND
MOV #UNS,RMER10 ;SET UNSAFE ERROR
MOV #0,RMDAO ;SECTOR = TRACK = 0

```

```

7991 034316 012737 000000 001432 MOV #0,RMDC0 ;CYLINDER = 0
7992 034324 012737 000005 001376 MOV #SEEK!GO,RMCS10 ;SEEK COMMAND
7993 034332 012702 001533 MOV #PUTINX,R2 ;SETUP REGISTER INDEX TABLE
7994 034336 112722 000006 MOV #RMDA,(R2)+ ;AND OUTPUT BUFFER
7995 034342 112722 000034 MOV #RMDC,(R2)+
7996 034346 112722 000014 MOV #RMER1,(R2)+
7997 034352 112722 000000 MOV #RMCS1,(R2)+
7998 034356 112722 000200 MOV #200,(R2)+
7999 034362 004737 044132 JSR PC,GETSTS ;SETUP FOR STATUS FETCH
8000 034366 004737 044466 JSR PC,PUT ;GO WRITE REGISTERS VIA PUT SUB
8001 034372 000404 BR 90$ ;GO TO 90$ IF NO ERROR
8002 034374 000240 NOP ;RETURN HERE IF ERROR
8003 034376 104000 ERROR ;ERROR DEFINED BY PUT SUB
8004 034400 000137 034576 JMP 160$ ;GO TO 160$ IF ERROR WAS FOUND
8005 034404 90$:
8006 034404 004737 044216 JSR PC,GET ;GO READ REGISTERS VIA GET SUB
8007 034410 000404 BR 100$ ;GO TO 100$ IF NO ERROR
8008 034412 000240 NOP ;RETURN HERE IF ERROR
8009 034414 104000 ERROR ;ERROR DEFINED BY GET SUB
8010 034416 000137 034576 JMP 160$ ;GO TO 160$ IF ERROR WAS FOUND
8011 034422 032737 020000 001340 100$: BIT #PIP,RMDSI ;DID DRIVE START SEEK??
8012 034430 001411 BEQ 110$ ;NO!!
8013 034432 013737 001340 001142 MOV RMDSI,$BDDAT ;BAD DATA FOR TYPEOUT
8014 034440 042737 157777 001142 BIC #!CPIP,$BDDAT
8015 034446 005037 001140 CLR $GDDAT ;GOOD DATA FOR TYPEOUT
8016 034452 104065 ERROR 65 ;DRIVE SHOULD NOT SEEK
8017 034454 004737 045026 110$: JSR PC,TIMOUT ;WAIT FOR GO TO RESET
8018 034460 004737 044216 JSR PC,GET ;GO READ REGISTERS VIA GET SUB
8019 034464 000404 BR 120$ ;GO TO 120$ IF NO ERROR
8020 034466 000240 NOP ;RETURN HERE IF ERROR
8021 034470 104000 ERROR ;ERROR DEFINED BY GET SUB
8022 034472 000137 034576 JMP 160$ ;GO TO 160$ IF ERROR WAS FOUND
8023 034476 120$:
8024 034476 004737 045212 JSR PC,PRIERR ;GO CHECK FOR PRIMARY ERRORS
8025 034502 000405 BR 130$ ;GO TO 130$ IF NO ERROR
8026 034504 000240 NOP ;RETURN HERE IF ERROR
8027 034506 104000 ERROR ;ERROR # DEFINED BY PRIERR SUBROUTINE
8028 034510 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
8029 034512 000137 034576 JMP 160$ ;GO TO 160$ IF ERROR WAS FOUND
8030 034516 130$:
8031 034516 004737 061062 JSR PC,STCDRVSTS ;GO CHECK FOR CHANGES IN DRIVE STATUS
8032 034522 000405 BR 140$ ;GO TO 140$ IF NO ERROR
8033 034524 000240 NOP ;RETURN HERE IF ERROR
8034 034526 104000 ERROR ;ERROR # DEFINED BY STCDRVSTS SUBROUTINE
8035 034530 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
8036 034532 000137 034576 JMP 160$ ;GO TO 160$ IF ERROR WAS FOUND
8037 034536 140$:
8038 034536 004737 061566 JSR PC,CMPERRSTS ;CHECK ANY ERRORS NOT MASKED
8039 034542 155760 .WORD ND!MSK!UNS ;MASK FOR RMER1
8040 034544 000010 .WORD DPE ;MASK FOR RMER2
8041 034546 000405 BR 150$ ;GO TO 150$ IF NO ERROR
8042 034550 000240 NOP ;RETURN HERE IF ERROR
8043 034552 104000 ERROR ;ERROR # DEFINED BY CMPERRSTS SUBROUTINE
8044 034554 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
8045 034556 000137 034576 JMP 160$ ;GO TO 160$ IF ERROR WAS FOUND
8046 034562 150$:

```

```

8047 034562 004737 046044 JSR PC,SECERR ;GO CHECK FOR SECONDARY ERRORS
8048 034566 000403 BR 160$ ;GO TO 160$ IF NO ERROR
8049 034570 000240 NOP ;RETURN HERE IF ERROR
8050 034572 104000 ERROR ;ERROR # DEFINED BY SECERR SUBROUTINE
8051 034574 004736 JSR PC,2(SP)+ ;GO BACK FOR MORE ERROR CHECKS
8052 034576 160$:
8053
8054
8055 ;*****
8056 ;*TEST 60 SEEK AT OFFSET
8057 ;*****
8058 034576 000004 TST60:
8059 034600 000240 SCOPE ;SCOPE CALL
8060 034602 012737 000001 001206 NOP ;START OF TEST
8061 034610 012737 034624 001122 MOV #1,$TIMES ;LOAD ITERATION COUNT
8062 034616 012737 034624 001124 MOV #1$,SLPADR
8063 034624 1$: MOV #1$,SLPERR
8064 034624 012706 001100 MOV #STACK,SP ;INITIALIZE STACK POINTER
8065 034630 013700 001276 MOV $BASE,R0 ;R0=UNIBUS ADDRESS
8066 034634 013701 001446 MOV TSTQUE,R1 ;(R1) = DEVICE BEING TESTED
8067 034640 012737 000060 001226 MOV #60,$TESTN ;;SET TEST NUMBER IN APT MAIL BOX
8068 034646 10$:
8069 034646 004737 043216 JSR PC,TSTPRP ;PREPARE DEVICE FOR TEST
8070 034652 054130 .WORD 054130 ;TASK DESCRIPTOR
8071 034654 000404 BR 20$ ;GO TO 20$ IF NO ERROR
8072 034656 000240 NOP ;RETURN HERE IF ERROR
8073 034660 104000 ERROR ;ERROR # DEFINED BY TSTPRP SUBROUTINE
8074 034662 000137 035144 JMP 140$ ;GO TO 140$ IF ERROR WAS FOUND
8075 034666 20$:
8076 034666 012737 000000 001404 MOV #0,RMDAO ;TRACK = SECTOR = 0
8077 034674 012737 000000 001432 MOV #0,RMDCO ;CYLINDER = 0
8078 034702 012737 000015 001376 MOV #OFFSET!GO,RMCS10 ;LOAD OFFSET COMMAND IN BUFFER
8079 034710 012702 001533 MOV #PUTINX,R2 ;R2 POINTS TO REGISTER TABLE
8080 034714 112722 000034 MOVB #RMDC,(R2)+ ;WRITE REGISTER INDEX TABLE
8081 034720 112722 000006 MOVB #RMDA,(R2)+
8082 034724 112722 000000 MOVB #RMCS1,(R2)+
8083 034730 112722 000200 MOVB #200,(R2)+ ;WRITE TERMINATOR
8084 034734 004737 044466 JSR PC,PUT ;GO WRITE REGISTERS VIA PUT SUB
8085 034740 000404 BR 30$ ;GO TO 30$ IF NO ERROR
8086 034742 000240 NOP ;RETURN HERE IF ERROR
8087 034744 104000 ERROR ;ERROR DEFINED BY PUT SUB
8088 034746 000137 035144 JMP 140$ ;GO TO 140$ IF ERROR WAS FOUND
8089 034752 004737 044132 30$: JSR PC,GETSTS ;SETUP FOR STATUS FETCH
8090 034756 004737 045026 JSR PC,TIMOUT ;WAIT FOR OFFSET TO COMPLETE
8091 034762 40$:
8092 034762 012737 000005 001376 MOV #SEEK!GO,RMCS10 ;LOAD SEEK COMMAND
8093 034770 112737 000000 001533 MOVB #RMCS1,PUTINX ;LOAD REGISTER INDEX TABLE
8094 034776 112737 000200 001534 MOVB #200,PUTINX+1
8095 035004 004737 044466 JSR PC,PUT ;GO WRITE REGISTERS VIA PUT SUB
8096 035010 000404 BR 50$ ;GO TO 50$ IF NO ERROR
8097 035012 000240 NOP ;RETURN HERE IF ERROR
8098 035014 104000 ERROR ;ERROR DEFINED BY PUT SUB
8099 035016 000137 035144 JMP 140$ ;GO TO 140$ IF ERROR WAS FOUND
8100 035022 50$:
8101 035022 004737 045026 JSR PC,TIMOUT ;GO TO TIMOUT SUBROUTINE
8102 035026 60$:

```

```

8103 035026 004737 044216 JSR PC.GET ;GO READ REGISTERS VIA GET SUB
8104 035032 000404 BR 100$ ;GO TO 100$ IF NO ERROR
8105 035034 000240 NOP ;RETURN HERE IF ERROR
8106 035036 104000 ERROR ;ERROR DEFINED BY GET SUB
8107 035040 000137 035144 JMP 140$ ;GO TO 140$ IF ERROR WAS FOUND
8108 035044 100$:
8109 035044 004737 045212 JSR PC.PRIERR ;GO CHECK FOR PRIMARY ERRORS
8110 035050 000405 BR 110$ ;GO TO 110$ IF NO ERROR
8111 035052 000240 NOP ;RETURN HERE IF ERROR
8112 035054 104000 ERROR ;ERROR # DEFINED BY PRIERR SUBROUTINE
8113 035056 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
8114 035060 000137 035144 JMP 140$ ;GO TO 140$ IF ERROR WAS FOUND
8115 035064 110$:
8116 035064 004737 052120 JSR PC.SEKSTS ;GO VERIFY RESULTS OF SEEK OPERATION
8117 035070 000405 BR 120$ ;GO TO 120$ IF NO ERROR
8118 035072 000240 NOP ;RETURN HERE IF ERROR
8119 035074 104000 ERROR ;ERROR # DEFINED BY SEKSTS SUBROUTINE
8120 035076 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
8121 035100 000137 035144 JMP 140$ ;GO TO 140$ IF ERROR WAS FOUND
8122 035104 120$:
8123 035104 004737 061566 JSR PC.CMPERRSTS ;CHECK ANY ERRORS NOT MASKED
8124 035110 115760 .WORD NDTMSK ;MASK FOR AMER1
8125 035112 000010 .WORD DPE ;MASK FOR AMER2
8126 035114 000405 BR 130$ ;GO TO 130$ IF NO ERROR
8127 035116 000240 NOP ;RETURN HERE IF ERROR
8128 035120 104000 ERROR ;ERROR # DEFINED BY CMPERRSTS SUBROUTINE
8129 035122 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
8130 035124 000137 035144 JMP 140$ ;GO TO 140$ IF ERROR WAS FOUND
8131 035130 130$:
8132 035130 004737 046044 JSR PC.SECERR ;GO CHECK FOR SECONDARY ERRORS
8133 035134 000403 BR 140$ ;GO TO 140$ IF NO ERROR
8134 035136 000240 NOP ;RETURN HERE IF ERROR
8135 035140 104000 ERROR ;ERROR # DEFINED BY SECERR SUBROUTINE
8136 035142 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
8137 035144 140$:
8138 *****
8139 ;*TEST 61 LOOK AHEAD TEST
8140 *****
8141 †ST61:
8142 035144 000004 SCOPE ;SCOPE CALL
8143 035146 000240 NOP ;START OF TEST
8144 035150 012706 001100 MOV #STACK,SP ;INITIALIZE STACK POINTER
8145 035154 013700 001276 MOV $BASE,R0 ;R0=UNIBUS ADDRESS
8146 035160 013701 001446 MOV TSTQUE,R1 ;(R1) = DEVICE BEING TESTED
8147 035164 012737 000061 001226 MOV #61,$TESTN ;SET TEST NUMBER IN APT MAIL BOX
8148
8149 035172 004737 053360 JSR PC.CNTCLR
8150 035176 000404 BR 10$ ;GO TO 10$ IF NO ERROR
8151 035200 000240 NOP ;RETURN HERE IF ERROR
8152 035202 104000 ERROR ;ERROR NUMBER DEFINED BY SUB
8153 035204 000137 035616 JMP 160$ ;GO TO 160$ IF ERROR WAS FOUND
8154 035210 10$:
8155 035210 013746 000004 MOV ERRVEC,-(SP) ;;PUSH ERRVEC ON STACK
8156 035214 013746 000006 MOV ERRVEC+2,-(SP) ;;PUSH ERRVEC+2 ON STACK
8157 035220 012737 035604 000004 MOV #145$,ERRVEC ;SETUP FOR BUS TIMEOUT
8158 035226 012737 000300 000006 MOV #PR6,ERRVEC+2

```

8159	035234	012703	000041		MOV	#33, R3	;R3=SAMPLE COUNT
8160	035240	012737	010000	001430	MOV	#FMT16, RMOFO	;SETUP 16 BIT MODE
8161	035246	012737	000000	001404	MOV	#0, RMDAO	;SEARCH SECTOR 0
8162	035254	012737	000000	001432	MOV	#0, RMDCO	;CYLINDER 0
8163	035262	012737	000031	001376	MOV	#SEARCH!GO, RMCS10	;RECALIBRATE COMMAND
8164	035270	012702	001533		MOV	#PUTINX, R2	
8165	035274	112722	000006		MOVB	#RMDA, (R2)+	
8166	035300	112722	000034		MOVB	#RMDC, (R2)+	
8167	035304	112722	000032		MOVB	#RMOF, (R2)+	
8168	035310	112722	000000		MOVB	#RMCS1, (R2)+	
8169	035314	112722	000200		MOVB	#200, (R2)+	
8170	035320	004737	044132		JSR	PC, GETSTS	
8171	035324						
8172	035324	004737	044466	20\$:	JSR	PC, PUT	;GO WRITE REGISTERS VIA PUT SUB
8173	035330	000404			BR	30\$	;GO TO 30\$ IF NO ERROR
8174	035332	000240			NOP		;RETURN HERE IF ERROR
8175	035334	104000			ERROR		;ERROR DEFINED BY PUT SUB
8176	035336	000137	035606		JMP	150\$	;GO TO 150\$ IF ERROR WAS FOUND
8177	035342	004737	045026	30\$:	JSR	PC, TIMEOUT	;WAIT FOR COMPLETION
8178	035346	004737	044216		JSR	PC, GET	;GO READ REGISTERS VIA GET SUB
8179	035352	000404			BR	40\$	;GO TO 40\$ IF NO ERROR
8180	035354	000240			NOP		;RETURN HERE IF ERROR
8181	035356	104000			ERROR		;ERROR DEFINED BY GET SUB
8182	035360	000137	035606		JMP	150\$	;GO TO 150\$ IF ERROR WAS FOUND
8183	035364			40\$:			
8184	035364	004737	045212		JSR	PC, PRIERR	;GO CHECK FOR PRIMARY ERRORS
8185	035370	000405			BR	50\$	;GO TO 50\$ IF NO ERROR
8186	035372	000240			NOP		;RETURN HERE IF ERROR
8187	035374	104000			ERROR		;ERROR # DEFINED BY PRIERR SUBROUTINE
8188	035376	004736			JSR	PC, a(SP)+	;GO BACK FOR MORE ERROR CHECKS
8189	035400	000137	035606		JMP	150\$	;GO TO 150\$ IF ERROR WAS FOUND
8190	035404			50\$:			
8191	035404	012704	106126	60\$:	MOV	#BUFFER, R4	;R4=STORAGE ADDRESS
8192	035410	012705	177777		MOV	#-1, R5	;R5=GROSS TIMER
8193	035414	016014	000020	70\$:	MOV	RMLA(R0), (R4)	;STORE RMLA SAMPLE
8194	035420	016002	000020		MOV	RMLA(R0), R2	;GET ANOTHER LOOK
8195	035424	020214			CMP	R2, (R4)	;ARE SAMPLES SAME??
8196	035426	001403			BEQ	80\$	;YES!!
8197	035430	005305			DEC	R5	;TIMEOUT??
8198	035432	001370			BNE	70\$	;NO - TRY AGAIN
8199	035434	000411			BR	100\$	;PROGRAM TIMEOUT
8200	035436	062704	000002	80\$:	ADD	#2, R4	;ADVANCE STORAGE ADDRESS
8201	035442	005303			DEC	R3	;ALL SAMPLES TAKEN??
8202	035444	001410			BEQ	110\$	;YES!!
8203	035446	026002	000020	90\$:	CMP	RMLA(R0), R2	;WAIT FOR CHANGE
8204	035452	001360			BNE	70\$	;YES!!
8205	035454	005305			DEC	R5	;TIMEOUT??
8206	035456	001373			BNE	90\$	;NO
8207	035460	104352		100\$:	ERROR	352	;PROGRAM TIMEOUT
8208	035462	000137	035616		JMP	160\$	
8209	035466	012703	000040	110\$:	MOV	#32, R3	;R3 = NUMBER OF COMPARES
8210	035472	012702	003700		MOV	#3700, R2	;R2 = MAXIMUM SAMPLE
8211	035476	012704	106126		MOV	#BUFFER, R4	;R4 = BUFFER ADDRESS
8212	035502	032737	010000	001430	BIT	#FMT16, RMOFO	;WAS SAMPLE FOR 16 BIT MODE??
8213	035510	001004			BNE	120\$	;YES
8214	035512	012703	000036		MOV	#30, R3	;CHANGE COMPARE COUNT AND



```

8215 035516 012702 003500      MOV      #3500,R2      ;MAXIMUM SAMPLE
8216 035522 012405      MOV      (R4)+,R5     ;GET A SAMPLE AND INCREMENT
8217 035524 062705 000100      ADD      #100,R5     ;FOR EXPECTED VALUE OF NEXT
8218 035530 020205      CMP      R2,R5       ;SHOULD NEXT BE 0??
8219 035532 103001      BHIS    130$        ;NO!!
8220 035534 005005      CLR      R5         ;YES - CHANGE EXPECTED
8221 035536 020514      CMP      R5,(R4)    ;IS NEXT SAMPLE CORRECT??
8222 035540 001406      BEQ     140$        ;YES!!
8223 035542 010537 001140      MOV      R5,$GDDAT  ;EXPECTED VALUE
8224 035546 011437 001142      MOV      (R4),$BDDAT;RECEIVED VALUE
8225 035552 104353      ERROR   353        ;FAILURE IN LOOK AHEAD TEST
8226 035554 000414      BR      150$
8227 035556 005303      DEC     R3         ;ALL SAMPLES CHECKED??
8228 035560 001360      BNE     120$        ;NO!!
8229 035562 032737 010000 001430      BIT     #FMT16,RMOFO;DONE TEST??
8230 035570 001406      BEQ     150$        ;YES!!
8231 035572 005037 001430      CLR     RMOFO      ;SETUP FOR 18 BIT MODE
8232 035576 012703 000037      MOV     #31.,R3
8233 035602 000650      BR      20$        ;DO AGAIN FOR 18 BIT MODE
8234 035604 022626      CMP     (SP)+,(SP)+;RESTORE STACK
8235 035606      150$:
8236 035606 012637 000006      MOV     (SP)+,ERRVEC+2;POP STACK INTO ERRVEC+2
8237 035612 012637 000004      MOV     (SP)+,ERRVEC ;POP STACK INTO ERRVEC
8238 035616
8239
8240      160$:
8241      ;*****
8242      ;*TEST 62 SEARCH ON CYLINDER
8243      ;*****
8244      †T62:
8245      SCOPE      ;SCOPE CALL
8246      NOP        ;START OF TEST
8247      MOV      #STACK,SP ;INITIALIZE STACK POINTER
8248      MOV      $BASE,R0  ;R0=UNIBUS ADDRESS
8249      MOV      TSTQUE,R1 ;(R1) = DEVICE BEING TESTED
8250      MOV      #62,$TSTN ;SET TEST NUMBER IN APT MAIL BOX
8251      JSR     PC,TSTPRP ;PREPARE DEVICE FOR TEST
8252      .WORD   054130 ;TASK DESCRIPTOR
8253      BR      80$      ;GO TO 80$ IF NO ERROR
8254      NOP        ;RETURN HERE IF ERROR
8255      ERROR   #  ;ERROR # DEFINED BY TSTPRP SUBROUTINE
8256      JMP     190$    ;GO TO 190$ IF ERROR WAS FOUND
8257      MOV     #29.,R3 ;R3=MAXIMUM SECTOR ADDRESS
8258      MOV     #0,RMDAO ;TRACK=SECTOR=0
8259      MOV     #0,RMDCO ;CYLINDER=0
8260      MOV     #0,RMOFO ;18 BIT FORMAT
8261      MOV     #SEEK!GO,RMCS10 ;SEEK COMMAND
8262      MOV     #PUTINX,R2 ;SETUP REGISTER INDEX TABLE
8263      MOV     #RMDA,(R2)+ ;FOR SEEK TO CYLINDER 0
8264      MOV     #RMDC,(R2)+
8265      MOV     #RMOF,(R2)+
8266      MOV     #RMCS1,(R2)+
8267      MOV     #200,(R2)+
8268      JSR     PC,GETSTS ;SETUP FOR STATUS FETCH
8269      JSR     PC,PUT     ;GO WRITE REGISTERS VIA PUT SUB
8270      BR      90$      ;GO TO 90$ IF NO ERROR
      NOP        ;RETURN HERE IF ERROR
      ERROR   #  ;ERROR DEFINED BY PUT SUB

```

```

8271 035766 000137 036274
8272 035772 004737 045026
8273 035776 004737 044216
8274 036002 000404
8275 036004 000240
8276 036006 104000
8277 036010 000137 036274
8278 036014
8279 036014 004737 045212
8280 036020 000405
8281 036022 000240
8282 036024 104000
8283 036026 004736
8284 036030 000137 036274
8285 036034
8286 036034 004737 052120
8287 036040 000405
8288 036042 000240
8289 036044 104000
8290 036046 004736
8291 036050 000137 036274
8292 036054 012737 000031 001376 120$:
8293 036062 004737 044466
8294 036066 000404
8295 036070 000240
8296 036072 104000
8297 036074 000137 036274
8298 036100
8299 036100 004737 045026
8300 036104 004737 044216
8301 036110 000404
8302 036112 000240
8303 036114 104000
8304 036116 000137 036274
8305 036122
8306 036122 004737 045212
8307 036126 000405
8308 036130 000240
8309 036132 104000
8310 036134 004736
8311 036136 000137 036274
8312 036142
8313 036142 004737 057516
8314 036146 000405
8315 036150 000240
8316 036152 104000
8317 036154 004736
8318 036156 000137 036274
8319 036162
8320 036162 004737 061566
8321 036166 115760
8322 036170 000010
8323 036172 000405
8324 036174 000240
8325 036176 104000
8326 036200 004736

90$: JMP 190$ ;GO TO 190$ IF ERROR WAS FOUND
      JSR PC,TIMOUT
      JSR PC,GET ;GO READ REGISTERS VIA GET SUB
      BR 100$ ;GO TO 100$ IF NO ERROR
      NOP ;RETURN HERE IF ERROR
      ERROR ;ERROR DEFINED BY GET SUB
      JMP 190$ ;GO TO 190$ IF ERROR WAS FOUND

100$: JSR PC,PRIERR ;GO CHECK FOR PRIMARY ERRORS
      BR 110$ ;GO TO 110$ IF NO ERROR
      NOP ;RETURN HERE IF ERROR
      ERROR ;ERROR # DEFINED BY PRIERR SUBROUTINE
      JSR PC,(SP)+ ;GO BACK FOR MORE ERROR CHECKS
      JMP 190$ ;GO TO 190$ IF ERROR WAS FOUND

110$: JSR PC,SEKSTS ;GO VERIFY RESULTS OF SEEK OPERATION
      BR 120$ ;GO TO 120$ IF NO ERROR
      NOP ;RETURN HERE IF ERROR
      ERROR ;ERROR # DEFINED BY SEKSTS SUBROUTINE
      JSR PC,(SP)+ ;GO BACK FOR MORE ERROR CHECKS
      JMP 190$ ;GO TO 190$ IF ERROR WAS FOUND

120$: MOV #SEARCH!GO, RMCS10 ;STORE SEARCH COMMAND
      JSR PC,PUT ;GO WRITE REGISTERS VIA PUT SUB
      BR 130$ ;GO TO 130$ IF NO ERROR
      NOP ;RETURN HERE IF ERROR
      ERROR ;ERROR DEFINED BY PUT SUB
      JMP 190$ ;GO TO 190$ IF ERROR WAS FOUND

130$: JSR PC,TIMOUT ;WAIT FOR SEARCH TO COMPLETE
      JSR PC,GET ;GO READ REGISTERS VIA GET SUB
      BR 140$ ;GO TO 140$ IF NO ERROR
      NOP ;RETURN HERE IF ERROR
      ERROR ;ERROR DEFINED BY GET SUB
      JMP 190$ ;GO TO 190$ IF ERROR WAS FOUND

140$: JSR PC,PRIERR ;GO CHECK FOR PRIMARY ERRORS
      BR 150$ ;GO TO 150$ IF NO ERROR
      NOP ;RETURN HERE IF ERROR
      ERROR ;ERROR # DEFINED BY PRIERR SUBROUTINE
      JSR PC,(SP)+ ;GO BACK FOR MORE ERROR CHECKS
      JMP 190$ ;GO TO 190$ IF ERROR WAS FOUND

150$: JSR PC,SCHSTS ;GO VERIFY SEARCH OPERATION
      BR 160$ ;GO TO 160$ IF NO ERROR
      NOP ;RETURN HERE IF ERROR
      ERROR ;ERROR # DEFINED BY SCHSTS SUBROUTINE
      JSR PC,(SP)+ ;GO BACK FOR MORE ERROR CHECKS
      JMP 190$ ;GO TO 190$ IF ERROR WAS FOUND

160$: JSR PC,CMPERRSTS ;CHECK ANY ERRORS NOT MASKED
      .WORD NOTMSK ;MASK FOR RMER1
      .WORD DPE ;MASK FOR RMER2
      BR 170$ ;GO TO 170$ IF NO ERROR
      NOP ;RETURN HERE IF ERROR
      ERROR ;ERROR # DEFINED BY CMPERRSTS SUBROUTINE
      JSR PC,(SP)+ ;GO BACK FOR MORE ERROR CHECKS

```

```

8327 036202 000137 036274          JMP      190$          ;GO TO 190$ IF ERROR WAS FOUND
8328 036206          170$:          JSR      PC,SECERR    ;GO CHECK FOR SECONDARY ERRORS
8329 036206 004737 046044          BR       180$          ;GO TO 180$ IF NO ERROR
8330 036212 000405          NOP          ;RETURN HERE IF ERROR
8331 036214 000240          ERROR      ;ERROR # DEFINED BY SECERR SUBROUTINE
8332 036216 104000          JSR      PC,(SP)+    ;GO BACK FOR MORE ERROR CHECKS
8333 036220 004736          JMP      190$          ;GO TO 190$ IF ERROR WAS FOUND
8334 036222 000137 036274          INC      RMDAO       ;INCREMENT SECTOR ADDRESS
8335 036226 005237 001404          CMP      R3,RMDAO    ;DONE ALL SECTORS??
8336 036232 020337 001404          BHIS    120$        ;NO!!
8337 036236 103306          BIT      #FMT16,RMOFO ;IS 16 BIT FORMAT DONE??
8338 036240 032737 010000 001430      BNE      190$        ;YES!!
8339 036246 001012          MOV      #FMT16,RMOFO ;SET 16 BIT FORMAT
8340 036250 012737 010000 001430      MOV      #31,R3      ;R3=MAXIMUM SECTOR ADDRESS
8341 036256 012703 000037          MOV      #0,RMDAO    ;START AT SECTOR 0
8342 036262 012737 000000 001404      JMP      85$         ;GO TEST 16 BIT MODE
8343 036270 000137 035712          190$:
8344 036274
8345
8346
8347
8348
8349
8350

```

```

;*****
;TEST 63 SEARCH OFF CYLINDER
;*****
↑T63:

```

```

8351 036274          SCOPE          ;SCOPE CALL
8352 036274 000004          NOP          ;START OF TEST
8353 036276 000240          MOV      #STACK,SP  ;INITIALIZE STACK POINTER
8354 036300 012706 001100      MOV      $BASE,R0    ;R0=UNIBUS ADDRESS
8355 036304 013700 001276      MOV      TSTQUE,R1   ;(R1) = DEVICE BEING TESTED
8356 036310 013701 001446      MOV      #63,$TSTN  ;SET TEST NUMBER IN APT MAIL BOX
8357 036314 012737 000063 001226      JSR      PC,TSTPRP  ;PREPARE DEVICE FOR TEST
8358 036322 004737 043216      .WORD    054130 ;TASK DESCRIPTOR
8359 036326 054130          BR       80$         ;GO TO 80$ IF NO ERROR
8360 036330 000404          NOP          ;RETURN HERE IF ERROR
8361 036332 000240          ERROR      ;ERROR # DEFINED BY TSTPRP SUBROUTINE
8362 036334 104000          JMP      230$        ;GO TO 230$ IF ERROR WAS FOUND
8363 036336 000137 037002          80$:          MOV      #0,RMDAO
8364 036342 012737 000000 001404      MOV      #0,RMOFO    ;START WITH 16 BIT MODE
8365 036350 012737 000000 001430      MOV      #29,R4      ;R4=MAXIMUM SECTOR ADDRESS
8366 036356 012704 000035      MOV      #411,R3    ;R3=SEARCH CYLINDER
8367 036362 012703 000633      MOV      #412,R5    ;R5=SEEK CYLINDER
8368 036366 012705 000634          MOV      #SEEK!GO,RMCS10 ;LOAD SEEK COMMAND
8369 036372 012737 000005 001376 90$:      MOV      R5,RMDCO    ;LOAD CYLINDER ADDRESS
8370 036400 010537 001432          MOV      #PUTINX,R2  ;R2 POINTS TO REGISTER TABLE
8371 036404 012702 001533          MOV      #RMOF,(R2)+ ;SETUP REGISTER INDEX TABLE
8372 036410 112722 000032          MOV      #RMDC,(R2)+ ;FOR SEEK COMMAND
8373 036414 112722 000034          MOV      #RMDA,(R2)+
8374 036420 112722 000006          MOV      #RMCS1,(R2)+
8375 036424 112722 000000          MOV      #200,(R2)+ ;TERMINATE TABLE
8376 036430 112722 000200          JSR      PC,GETSTS  ;SETUP FOR STATUS
8377 036434 004737 044132          JSR      PC,PUT     ;GO WRITE REGISTERS VIA PUT SUB
8378 036440 004737 044466          BR       100$        ;GO TO 100$ IF NO ERROR
8379 036444 000404          NOP          ;RETURN HERE IF ERROR
8380 036446 000240          ERROR      ;ERROR DEFINED BY PUT SUB
8381 036450 104000          JMP      230$        ;GO TO 230$ IF ERROR WAS FOUND
8382 036452 000137 037002

```

8383	036456	004737	045026	100\$:	JSR	PC,TIMOUT		;WAIT FOR SEEK TO COMPLETE
8384	036462	004737	044216		JSR	PC,GET		;GO READ REGISTERS VIA GET SUB
8385	036466	000404			BR	110\$	;GO TO 110\$ IF NO ERROR	
8386	036470	000240			NOP			;RETURN HERE IF ERROR
8387	036472	104000			ERROR			;ERROR DEFINED BY GET SUB
8388	036474	000137	037002		JMP	230\$	;GO TO 230\$ IF ERROR WAS FOUND	
8389	036500			110\$:				
8390	036500	004737	045212		JSR	PC,PRIERR		;GO CHECK FOR PRIMARY ERRORS
8391	036504	000405			BR	120\$	;GO TO 120\$ IF NO ERROR	
8392	036506	000240			NOP			;RETURN HERE IF ERROR
8393	036510	104000			ERROR			;ERROR # DEFINED BY PRIERR SUBROUTINE
8394	036512	004736			JSR	PC,(SP)+		;GO BACK FOR MORE ERROR CHECKS
8395	036514	000137	037002		JMP	230\$	;GO TO 230\$ IF ERROR WAS FOUND	
8396	036520			120\$:				
8397	036520	004737	052120		JSR	PC,SEKSTS		;GO VERIFY RESULTS OF SEEK OPERATION
8398	036524	000405			BR	130\$	;GO TO 130\$ IF NO ERROR	
8399	036526	000240			NOP			;RETURN HERE IF ERROR
8400	036530	104000			ERROR			;ERROR # DEFINED BY SEKSTS SUBROUTINE
8401	036532	004736			JSR	PC,(SP)+		;GO BACK FOR MORE ERROR CHECKS
8402	036534	000137	037002		JMP	230\$	;GO TO 230\$ IF ERROR WAS FOUND	
8403	036540	010337	001432	130\$:	MOV	R3,RMDC0		;LOAD CYLINDER ADDRESS
8404	036544	012737	000031	001376	MOV	#SEARCH!GO,RMCS10		;LOAD SEARCH COMMAND
8405	036552	004737	044466		JSR	PC,PUT		;GO WRITE REGISTERS VIA PUT SUB
8406	036556	000404			BR	140\$	;GO TO 140\$ IF NO ERROR	
8407	036560	000240			NOP			;RETURN HERE IF ERROR
8408	036562	104000			ERROR			;ERROR DEFINED BY PUT SUB
8409	036564	000137	037002		JMP	230\$	;GO TO 230\$ IF ERROR WAS FOUND	
8410	036570	004737	045026	140\$:	JSR	PC,TIMOUT		;WAIT FOR SEARCH TO COMPLETE
8411	036574	004737	044216		JSR	PC,GET		;GO READ REGISTERS VIA GET SUB
8412	036600	000404			BR	150\$	;GO TO 150\$ IF NO ERROR	
8413	036602	000240			NOP			;RETURN HERE IF ERROR
8414	036604	104000			ERROR			;ERROR DEFINED BY GET SUB
8415	036606	000137	037002		JMP	230\$	;GO TO 230\$ IF ERROR WAS FOUND	
8416	036612			150\$:				
8417	036612	004737	045212		JSR	PC,PRIERR		;GO CHECK FOR PRIMARY ERRORS
8418	036616	000405			BR	160\$	;GO TO 160\$ IF NO ERROR	
8419	036620	000240			NOP			;RETURN HERE IF ERROR
8420	036622	104000			ERROR			;ERROR # DEFINED BY PRIERR SUBROUTINE
8421	036624	004736			JSR	PC,(SP)+		;GO BACK FOR MORE ERROR CHECKS
8422	036626	000137	037002		JMP	230\$	;GO TO 230\$ IF ERROR WAS FOUND	
8423	036632			160\$:				
8424	036632	004737	057516		JSR	PC,SCHSTS		;GO VERIFY SEARCH OPERATION
8425	036636	000405			BR	170\$	;GO TO 170\$ IF NO ERROR	
8426	036640	000240			NOP			;RETURN HERE IF ERROR
8427	036642	104000			ERROR			;ERROR # DEFINED BY SCHSTS SUBROUTINE
8428	036644	004736			JSR	PC,(SP)+		;GO BACK FOR MORE ERROR CHECKS
8429	036646	000137	037002		JMP	230\$	;GO TO 230\$ IF ERROR WAS FOUND	
8430	036652			170\$:				
8431	036652	004737	061566		JSR	PC,CMPEERRSTS		;CHECK ANY ERRORS NOT MASKED
8432	036656	115760			.WORD	NDTMSK		;MASK FOR RMER1
8433	036660	000010			.WORD	DPE		;MASK FOR RMER2
8434	036662	000405			BR	180\$	;GO TO 180\$ IF NO ERROR	
8435	036664	000240			NOP			;RETURN HERE IF ERROR
8436	036666	104000			ERROR			;ERROR # DEFINED BY CMPEERRSTS SUBROUTINE
8437	036670	004736			JSR	PC,(SP)+		;GO BACK FOR MORE ERROR CHECKS
8438	036672	000137	037002		JMP	230\$	;GO TO 230\$ IF ERROR WAS FOUND	

```

8439 036676 180$: JSR PC,SECERR ;GO CHECK FOR SECONDARY ERRORS
8440 036676 004737 046044 BR 190$ ;GO TO 190$ IF NO ERROR
8441 036702 000405 NOP ;RETURN HERE IF ERROR
8442 036704 000240 ERROR ;ERROR # DEFINED BY SECERR SUBROUTINE
8443 036706 104000 JSR PC,(SP)+ ;GO BACK FOR MORE ERROR CHECKS
8444 036710 004736 JMP 190$ ;GO TO 190$ IF ERROR WAS FOUND
8445 036712 000137 036716 190$: DEC R3 ;DECREMENT SEARCH CYLINDER
8446 036716 005303 INC R5 ;INCREMENT SEEK CYLINDER
8447 036720 005205 INC RMDAO ;INCREMENT SECTOR ADDRESS
8448 036722 005237 001404 CMP R4,RMDAO ;DONE ALL SECTORS??
8449 036726 020437 001404 BLO 210$ ;YES!!
8450 036732 103401 BR 90$ ;DO NEXT SECTOR
8451 036734 000616 210$: BIT #FMT16,RMOFO ;DONE BOTH FORMATS??
8452 036736 032737 010000 001430 BNE 230$ ;YES!!
8453 036744 001016 MOV #31.,R4 ;R4=MAXIMUM SECTOR ADDRESS
8454 036746 012704 000037 MOV #412.,R3 ;R3=SEARCH CYLINDER
8455 036752 012703 000634 MOV #411.,R5 ;R5=SEEK CYLINDER
8456 036756 012705 000633 MOV #FMT16,RMOFO ;SET 16 BIT FORMAT
8457 036762 012737 010000 001430 MOV #0,RMDAO ;START AT SECTOR 0
8458 036770 012737 000000 001404 JMP 90$ ;START 16 BIT TEST
8459 036776 000137 036372
8460 037002
8461
8462
8463
8464 037002
8465 037002 000004
8466 037004 000240
8467 037006 012706 001100
8468 037012 013700 001276
8469 037016 013701 001446
8470 037022 012737 000064 001226
8471
8472 037030 004737 043216 JSR PC,TSTPRP ;PREPARE DEVICE FOR TEST
8473 037034 054130 .WORD 054130 ;TASK DESCRIPTOR
8474 037036 000404 BR 80$ ;GO TO 80$ IF NO ERROR
8475 037040 000240 NOP ;RETURN HERE IF ERROR
8476 037042 104000 ERROR ;ERROR # DEFINED BY TSTPRP SUBROUTINE
8477 037044 000137 037362 JMP 190$ ;GO TO 190$ IF ERROR WAS FOUND
8478 037050 012737 000000 001430 80$: MOV #0,RMOFO ;SET 18 BIT FORMAT
8479 037056 012737 000036 001404 MOV #30.,RMDAO ;START WITH SECTOR 30
8480 037064 012737 000000 001432 MOV #0,RMDCO ;CYLINDER=0
8481 037072 012737 000031 001376 MOV #SEARCH!GO,RMCS10 ;SEARCH COMMAND
8482 037100 012702 001533 MOV #PUTINX,R2 ;WRITE REGISTER TABLE FOR
8483 037104 112722 000034 MOV #RMDC,(R2)+ ;COMMAND
8484 037110 112722 000032 MOV #RMOF,(R2)+
8485 037114 112722 000006 MOV #RMDA,(R2)+
8486 037120 112722 000000 MOV #RMCS1,(R2)+
8487 037124 112722 000200 MOV #200,(R2)+ ;TERMINATE TABLE
8488 037130 004737 044132 JSR PC,GETSTS ;SETUP STATUS FETCH
8489 037134
8490 037134 004737 044466 90$: JSR PC,PUT ;GO WRITE REGISTERS VIA PUT SUB
8491 037140 000404 BR 100$ ;GO TO 100$ IF NO ERROR
8492 037142 000240 NOP ;RETURN HERE IF ERROR
8493 037144 104000 ERROR ;ERROR DEFINED BY PUT SUB
8494 037146 000137 037330 JMP 170$ ;GO TO 170$ IF ERROR WAS FOUND

```

```

230$:
*****
;TEST 64 SEARCH INVALID SECTOR
*****
TST64:

```

```

8495 037152 004737 045026      100$: JSR   PC,TIMOUT      ;WAIT FOR GO TO RESET
8496 037156 004737 044216      JSR   PC,GET          ;GO READ REGISTERS VIA GET SUB
8497 037162 000404              BR    120$           ;GO TO 120$ IF NO ERROR
8498 037164 000240              NOP                    ;RETURN HERE IF ERROR
8499 037166 104000              ERROR                 ;ERROR DEFINED BY GET SUB
8500 037170 000137 037330      JMP   170$           ;GO TO 170$ IF ERROR WAS FOUND
8501 037174              120$:
8502 037174 004737 045212      JSR   PC,PRIERR      ;GO CHECK FOR PRIMARY ERRORS
8503 037200 000405              BR    130$           ;GO TO 130$ IF NO ERROR
8504 037202 000240              NOP                    ;RETURN HERE IF ERROR
8505 037204 104000              ERROR                 ;ERROR # DEFINED BY PRIERR SUBROUTINE
8506 037206 004736              JSR   PC,@(SP)+      ;GO BACK FOR MORE ERROR CHECKS
8507 037210 000137 037330      JMP   170$           ;GO TO 170$ IF ERROR WAS FOUND
8508 037214 032737 002000 001342 130$: BIT   #IAE,RMER1I    ;DID "IAE" SET??
8509 037222 001012              BNE   140$           ;YES!!
8510 037224 012737 002000 001140      MOV   #IAE,$GDDAT    ;EXPECTED STATUS FOR TYPEOUT
8511 037232 013737 001342 001142      MOV   RMER1I,$BDDAT  ;RECEIVED STATUS FOR TYPEOUT
8512 037240 042737 175777 001142      BIC   #ICIAE,$BDDAT
8513 037246 104257              ERROR                 ;IVC NOT DETECTED
8514 037250              140$:
8515 037250 004737 061062      JSR   PC,STCDRVSTS   ;GO CHECK FOR CHANGES IN DRIVE STATUS
8516 037254 000405              BR    150$           ;GO TO 150$ IF NO ERROR
8517 037256 000240              NOP                    ;RETURN HERE IF ERROR
8518 037260 104000              ERROR                 ;ERROR # DEFINED BY STCDRVSTS SUBROUTINE
8519 037262 004736              JSR   PC,@(SP)+      ;GO BACK FOR MORE ERROR CHECKS
8520 037264 000137 037330      JMP   170$           ;GO TO 170$ IF ERROR WAS FOUND
8521 037270              150$:
8522 037270 004737 061566      JSR   PC,CMPEERRSTS  ;CHECK ANY ERRORS NOT MASKED
8523 037274 117760              .WORD ND!MSK!IAE    ;MASK FOR RMER1
8524 037276 000010              .WORD DPE            ;MASK FOR RMER2
8525 037300 000405              BR    160$           ;GO TO 160$ IF NO ERROR
8526 037302 000240              NOP                    ;RETURN HERE IF ERROR
8527 037304 104000              ERROR                 ;ERROR # DEFINED BY CMPEERRSTS SUBROUTINE
8528 037306 004736              JSR   PC,@(SP)+      ;GO BACK FOR MORE ERROR CHECKS
8529 037310 000137 037330      JMP   170$           ;GO TO 170$ IF ERROR WAS FOUND
8530 037314              160$:
8531 037314 004737 046044      JSR   PC,SECERR      ;GO CHECK FOR SECONDARY ERRORS
8532 037320 000403              BR    170$           ;GO TO 170$ IF NO ERROR
8533 037322 000240              NOP                    ;RETURN HERE IF ERROR
8534 037324 104000              ERROR                 ;ERROR # DEFINED BY SECERR SUBROUTINE
8535 037326 004736              JSR   PC,@(SP)+      ;GO BACK FOR MORE ERROR CHECKS
8536 037330 005237 001404 001404 170$: INC   RMDAO          ;INCREMENT SECTOR ADDRESS
8537 037334 022737 000037 001404      CMP   #31,RMDAO      ;DONE??
8538 037342 103407              BLO   190$           ;YES!!
8539 037344 004737 053360      JSR   PC,CNTCLR      ;GO TO 180$ IF NO ERROR
8540 037350 000402              BR    180$           ;RETURN HERE IF ERROR
8541 037352 000240              NOP                    ;ERROR NUMBER DEFINED BY SUB
8542 037354 104000              ERROR                 ;TEST NEXT SECTOR
8543 037356 000137 037134      JMP   90$
8544 037362      180$:
8545
8546
8547
8548
8549
8550

```

```

8551
8552
8553
8554
8555
8556
8557
8558
8559
8560 037362
8561 037362 000004
8562 037364 000240
8563 037366 012706 001100
8564 037372 013700 001276
8565 037376 013701 001446
8566 037402 012737 000065 001226
8567 037410 004737 043216
8568 037414 054130
8569 037416 000404
8570 037420 000240
8571 037422 104000
8572 037424 000137 037750
8573
8574 037430 012737 000000 001430 80$:
8575 037436 012737 002400 001404
8576 037444 012737 000000 001432
8577 037452 012737 000031 001376
8578 037460 012702 001533
8579 037464 112722 000006
8580 037470 112722 000034
8581 037474 112722 000032
8582 037500 112722 000000
8583 037504 112722 000200
8584 037510 004737 044132
8585 037514
8586 037514 004737 044466
8587 037520 000404
8588 037522 000240
8589 037524 104000
8590 037526 000137 037670
8591 037532 004737 045026
8592 037536 004737 044216
8593 037542 000404
8594 037544 000240
8595 037546 104000
8596 037550 000137 037670
8597 037554
8598 037554 004737 045212
8599 037560 000405
8600 037562 000240
8601 037564 104000
8602 037566 004736
8603 037570 000137 037670
8604 037574 032737 002000 001342 120$:
8605 037602 001012
8606 037604 012737 002000 001140

```

```

*****
*TEST 65 SEARCH INVALID TRACK
*****
†ST65:
SCOPE ;SCOPE CALL
NOP ;START OF TEST
MOV #STACK,SP ;INITIALIZE STACK POINTER
MOV $BASE,R0 ;R0=UNIBUS ADDRESS
MOV TSTQUE,R1 ;(R1) = DEVICE BEING TESTED
MOV #65,STESTN ;SET TEST NUMBER IN APT MAIL BOX
JSR PC,†STPRP ;PREPARE DEVICE FOR TEST
WORD 054130 ;TASK DESCRIPTOR
BR 80$ ;GO TO 80$ IF NO ERROR
NOP ;RETURN HERE IF ERROR
ERROR # ;ERROR # DEFINED BY TSTPRP SUBROUTINE
JMP 180$ ;GO TO 180$ IF ERROR WAS FOUND

80$: MOV #0,RMOFO ;SET 18 BIT FORMAT
MOV #002400,RMDAO ;START WITH TRACK 5, SECTOR 0
MOV #0,RMDC0 ;CYLINDER=0
MOV #SEARCH!GO,RMCS10 ;SEARCH COMMAND
MOV #PUTINX,R2 ;WRITE REGISTER INDEX TABLE
MOVB #RMDA,(R2)+
MOVB #RMDC,(R2)+
MOVB #RMOF,(R2)+
MOVB #RMCS1,(R2)+
MOVB #200,(R2)+ ;TERMINATE TABLE
JSR PC,GETSTS

90$: JSR PC,PUT ;GO WRITE REGISTERS VIA PUT SUB
BR 100$ ;GO TO 100$ IF NO ERROR
NOP ;RETURN HERE IF ERROR
ERROR ;ERROR DEFINED BY PUT SUB
JMP 160$ ;GO TO 160$ IF ERROR WAS FOUND

100$: JSR PC,TIMOUT ;WAIT FOR GO TO RESET
JSR PC,GET ;GO READ REGISTERS VIA GET SUB
BR 110$ ;GO TO 110$ IF NO ERROR
NOP ;RETURN HERE IF ERROR
ERROR ;ERROR DEFINED BY GET SUB
JMP 160$ ;GO TO 160$ IF ERROR WAS FOUND

110$: JSR PC,PRIERR ;GO CHECK FOR PRIMARY ERRORS
BR 120$ ;GO TO 120$ IF NO ERROR
NOP ;RETURN HERE IF ERROR
ERROR # ;ERROR # DEFINED BY PRIERR SUBROUTINE
JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
JMP 160$ ;GO TO 160$ IF ERROR WAS FOUND

120$: BIT #IAE,RMER1I ;DID "IAE" SET??
BNE 130$ ;YES!!
MOV #IAE,$GDDAT ;EXPECTED STATUS FOR TYPEOUT

```

```

8607 037612 013737 001342 001142      MOV      RMER1I,$BDDAT      ;RECEIVED STATUS FOR TYPEOUT
8608 037620 042737 175777 001142      BIC      #1CIAE,$BDDAT
8609 037626 104257                      ERROR    257                ;IAE NOT SET DURING SEARCH
8610 037630                      130$:
8611 037630                      140$:
8612 037630 004737 061566      JSR      PC,CMPERRSTS      ;CHECK ANY ERRORS NOT MASKED
8613 037634 117760                      .WORD   NDTMSK!IAE          ;MASK FOR RMER1
8614 037636 000010                      .WORD   DPE                ;MASK FOR RMER2
8615 037640 000405                      BR       150$              ;GO TO 150$ IF NO ERROR
8616 037642 000240                      NOP
8617 037644 104000                      ERROR    ;RETURN HERE IF ERROR
8618 037646 004736                      JSR      PC,@(SP)+         ;ERROR # DEFINED BY CMPERRSTS SUBROUTINE
8619 037650 000137 037670      JMP      160$              ;GO BACK FOR MORE ERROR CHECKS
8620 037654                      150$:                      ;GO TO 160$ IF ERROR WAS FOUND
8621 037654 004737 046044      JSR      PC,SECERR         ;GO CHECK FOR SECONDARY ERRORS
8622 037660 000403                      BR       160$              ;GO TO 160$ IF NO ERROR
8623 037662 000240                      NOP
8624 037664 104000                      ERROR    ;RETURN HERE IF ERROR
8625 037666 004736                      JSR      PC,@(SP)+         ;ERROR # DEFINED BY SECERR SUBROUTINE
8626 037670 062737 000400 001404 160$:      ADD      #400,RMDAO        ;GO BACK FOR MORE ERROR CHECKS
8627 037676 022737 004000 001404      CMP      #4000,RMDAO       ;INCREMENT TRACK ADDRESS
8628 037704 101012                      BHI     170$               ;DONE ALL TRACKS??
8629 037706 032737 010000 001430      BIT     #FMT16,RMOFO       ;NO!!
8630 037714 001015                      BNE     180$               ;DONE 16 BIT MODE??
8631 037716 012737 010000 001430      MOV     #FMT16,RMOFO       ;YES!!
8632 037724 012737 002400 001404      MOV     #002400,RMDAO      ;SET 16 BIT FORMAT
8633 037732                      170$:                      ;START WITH TRACK 5
8634 037732 004737 053360      JSR      PC,CNTCLR        ;TEST NEXT TRACK
8635 037736 000402                      BR       175$              ;GO TO 175$ IF NO ERROR
8636 037740 000240                      NOP
8637 037742 104000                      ERROR    ;RETURN HERE IF ERROR
8638 037744 000137 037514 175$:      JMP      90$               ;ERROR NUMBER DEFINED BY SUB
8639
8640 037750                      180$:
8641
8642
8643
8644
8645
8646
8647 037750
8648 037750 000004
8649 037752 000240
8650 037754 012706 001100
8651 037760 013700 001276
8652 037764 013701 001446
8653 037770 012737 000066 001226
8654
8655 037776 004737 043216
8656 040002 054130
8657 040004 000404
8658 040006 000240
8659 040010 104000
8660 040012 000137 040354
8661 040016 012737 000000 001430 80$:
8662 040024 012737 000000 001404      MOV     #0,RMOFO           ;SCOPE CALL
      MOV     #0,RMDAO         ;START OF TEST
      ;SCOPE CALL
      ;INITIALIZE STACK POINTER
      ;RO=UNIBUS ADDRESS
      ;(R1) = DEVICE BEING TESTED
      ;;SET TEST NUMBER IN APT MAIL BOX
      ;PREPARE DEVICE FOR TEST
      ;TASK DESCRIPTOR
      ;GO TO 80$ IF NO ERROR
      ;RETURN HERE IF ERROR
      ;ERROR # DEFINED BY TSTPRP SUBROUTINE
      ;GO TO 190$ IF ERROR WAS FOUND
      ;SET 18 BIT FORMAT
      ;TRACK=SECTOR=0

```

```

;*****
; *TEST 66 SEARCH INVALID CYLINDER
;*****
TST66:

```



8663	040032	012737	001467	001432	MOV	#823, RMDCO	; START AT CYLINDER 823
8664	040040	012737	000031	001376	MOV	#SEARCH!GO, RMCS10	; SEARCH COMMAND
8665	040046	012702	001533		MOV	#PUTINX, R2	; WRITE REGISTER INDEX TABLE
8666	040052	112722	000032		MOV	#RMOF, (R2)+	
8667	040056	112722	000034		MOV	#RMDC, (R2)+	
8668	040062	112722	000006		MOV	#RMDA, (R2)+	
8669	040066	112722	000000		MOV	#RMCS1, (R2)+	
8670	040072	112722	000200		MOV	#200, (R2)+	
8671	040076	004737	044132		JSR	PC, GETSTS	; SETUP STATUS FETCH
8672	040102			90\$:			
8673	040102	004737	044466		JSR	PC, PUT	; GO WRITE REGISTERS VIA PUT SUB
8674	040106	000404			BR	100\$	; GO TO 100\$ IF NO ERROR
8675	040110	000240			NOP		; RETURN HERE IF ERROR
8676	040112	104000			ERROR		; ERROR DEFINED BY PUT SUB
8677	040114	000137	040276		JMP	160\$	; GO TO 160\$ IF ERROR WAS FOUND
8678	040120	004737	045026	100\$:	JSR	PC, TIMEOUT	
8679	040124	004737	044216		JSR	PC, GET	; GO READ REGISTERS VIA GET SUB
8680	040130	000404			BR	110\$	; GO TO 110\$ IF NO ERROR
8681	040132	000240			NOP		; RETURN HERE IF ERROR
8682	040134	104000			ERROR		; ERROR DEFINED BY GET SUB
8683	040136	000137	040276		JMP	160\$	; GO TO 160\$ IF ERROR WAS FOUND
8684	040142			110\$:			
8685	040142	004737	045212		JSR	PC, PRIERR	; GO CHECK FOR PRIMARY ERRORS
8686	040146	000405			BR	120\$	; GO TO 120\$ IF NO ERROR
8687	040150	000240			NOP		; RETURN HERE IF ERROR
8688	040152	104000			ERROR		; ERROR # DEFINED BY PRIERR SUBROUTINE
8689	040154	004736			JSR	PC, @ (SP)+	; GO BACK FOR MORE ERROR CHECKS
8690	040156	000137	040276		JMP	160\$	; GO TO 160\$ IF ERROR WAS FOUND
8691	040162	032737	002000	001342	120\$:	BIT	#IAE, RMER11
8692	040170	001012			BNE	130\$	; IS "IAE" SET??
8693	040172	012737	002000	001140	MOV	#IAE, \$GDDAT	; YES!!
8694	040200	013737	001342	001142	MOV	RMER11, \$BDDAT	; EXPECTED STATUS FOR TYPEOUT
8695	040206	042737	175777	001142	BIC	#CIAE, \$BDDAT	; RECEIVED STATUS FOR TYPEOUT
8696	040214	104257			ERROR	257	; IAE NOT SET DURING SEARCH
8697	040216			130\$:			
8698	040216	004737	061062		JSR	PC, STCDRVSTS	; GO CHECK FOR CHANGES IN DRIVE STATUS
8699	040222	000405			BR	140\$	; GO TO 140\$ IF NO ERROR
8700	040224	000240			NOP		; RETURN HERE IF ERROR
8701	040226	104000			ERROR		; ERROR # DEFINED BY STCDRVSTS SUBROUTINE
8702	040230	004736			JSR	PC, @ (SP)+	; GO BACK FOR MORE ERROR CHECKS
8703	040232	000137	040276		JMP	160\$	; GO TO 160\$ IF ERROR WAS FOUND
8704	040236			140\$:			
8705	040236	004737	061566		JSR	PC, CMPERRSTS	; CHECK ANY ERRORS NOT MASKED
8706	040242	117760			.WORD	IAE!NDTMSK	; MASK FOR RMER1
8707	040244	000010			.WORD	DPE	; MASK FOR RMER2
8708	040246	000405			BR	150\$	; GO TO 150\$ IF NO ERROR
8709	040250	000240			NOP		; RETURN HERE IF ERROR
8710	040252	104000			ERROR		; ERROR # DEFINED BY CMPERRSTS SUBROUTINE
8711	040254	004736			JSR	PC, @ (SP)+	; GO BACK FOR MORE ERROR CHECKS
8712	040256	000137	040276		JMP	160\$	; GO TO 160\$ IF ERROR WAS FOUND
8713	040262			150\$:			
8714	040262	004737	046044		JSR	PC, SECERR	; GO CHECK FOR SECONDARY ERRORS
8715	040266	000403			BR	160\$	; GO TO 160\$ IF NO ERROR
8716	040270	000240			NOP		; RETURN HERE IF ERROR
8717	040272	104000			ERROR		; ERROR # DEFINED BY SECERR SUBROUTINE
8718	040274	004736			JSR	PC, @ (SP)+	; GO BACK FOR MORE ERROR CHECKS

```

8719 040276 005237 001432 160$: INC RMDC0 ;INCREMENT CYLINDER ADDRESS
8720 040302 022737 002000 001432 CMP #1024.,RMDC0 ;DONE ALL CYLINDERS??
8721 040310 101012 BHI 170$ ;NO!!
8722 040312 032737 010000 001430 BIT #FMT16,RMOFO ;SET 16 BIT FORMAT
8723 040320 001015 BNE 190$ ;YES!!
8724 040322 012737 010000 001430 MOV #FMT16,RMOFO ;SET 16 BIT FORMAT
8725 040330 012737 001467 001432 MOV #823.,RMDC0 ;CYLINDER=823
8726 040336
8727 040336 004737 053360 170$: JSR PC,CNTCLR
8728 040342 000402 BR 180$ ;GO TO 180$ IF NO ERROR
8729 040344 000240 NOP ;RETURN HERE IF ERROR
8730 040346 104000 ERROR ;ERROR NUMBER DEFINED BY SUB
8731 040350 000137 040102 180$: JMP 90$
8732 040354 190$:
8733
8734
8735
8736
8737
8738
8739
8740

```

```

*****
; *TEST 67 IVC SEARCH TEST
*****
†ST67:

```

```

8741 040354 000004 SCOPE ;SCOPE CALL
8742 040354 000240 NOP ;START OF TEST
8743 040356 000240 MOV #STACK,SP ;INITIALIZE STACK POINTER
8744 040360 012706 001100 MOV $BASE,R0 ;R0=UNIBUS ADDRESS
8745 040364 013700 001276 MOV TSTQUE,R1 ;(R1) = DEVICE BEING TESTED
8746 040370 013701 001446 MOV #67,$TESTN ;SET TEST NUMBER IN APT MAIL BOX
8747 040374 012737 000067 001226
8748
8749 040402 004737 043216 JSR PC,TSTPRP ;PREPARE DEVICE FOR TEST
8750 040406 054130 .WORD 80$ ;TASK DESCRIPTOR
8751 040410 000404 BR 80$ ;GO TO 80$ IF NO ERROR
8752 040412 000240 NOP ;RETURN HERE IF ERROR
8753 040414 104000 ERROR ;ERROR # DEFINED BY TSTPRP SUBROUTINE
8754 040416 000137 040734 80$: JMP 160$ ;GO TO 160$ IF ERROR WAS FOUND
8755 040422
8756 040422 112737 000024 001533 MOV #RMMR1,PUTINX ;SETUP PUT INDEX TABLE
8757 040430 112737 000200 001534 MOV #200,PUTINX+1 ;WRITE TERMINATOR BYTE
8758 040436 012737 000001 001422 MOV #DMD,RMMR10 ;RMMR1=DMD
8759 040444 004737 044466 JSR PC,PUT ;GO WRITE RMMR1 VIA SUB
8760 040450 000404 BR 90$ ;GO TO 90$ IF NO ERROR
8761 040452 000240 NOP ;RETURN HERE IF ERROR
8762 040454 104000 ERROR ;ERROR NUMBER DEFINED BY PUT SUB
8763 040456 000137 040734 90$: JMP 160$ ;GO TO 160$ IF ERROR WAS FOUND
8764 040462 012737 000000 001422 MOV #0,RMMR10 ;RESET DIAGNOSTIC MODE
8765 040470 012737 000000 001432 MOV #0,RMDC0 ;CYLINDER 0
8766 040476 012737 000000 001404 MOV #0,RMDA0 ;TRACK=SECTOR=0
8767 040504 012737 000000 001430 MOV #0,RMOFO ;16 BIT FORMAT
8768 040512 012737 000031 001376 MOV #SEARCH!GO,RMCS10 ;SEARCH COMMAND
8769 040520 012702 001533 MOV #PUTINX,R2 ;LOAD INDEX TABLE
8770 040524 112722 000024 MOV #RMMR1,(R2)+
8771 040530 112722 000034 MOV #RMDC,(R2)+
8772 040534 112722 000006 MOV #RMDA,(R2)+
8773 040540 112722 000032 MOV #RMOF,(R2)+
8774 040544 112722 000000 MOV #RMCS1,(R2)+

```

```

8775 040550 112722 000200      MOVB    #200,(R2)+
8776 040554 004737 044132      JSR     PC,GETSTS
8777 040560 004737 044466      JSR     PC,PUT      ;GO WRITE REGISTERS VIA PUT SUB
8778 040564 000404                BR      100$      ;GO TO 100$ IF NO ERROR
8779 040566 000240                NOP
8780 040570 104000                ERROR   ;RETURN HERE IF ERROR
8781 040572 000137 040734      JMP     160$      ;GO TO 160$ IF ERROR WAS FOUND
8782 040576 004737 045026      JSR     PC,TIMOUT  ;WAIT FOR GO TO RESET
8783 040602 004737 044216      JSR     PC,GET     ;GO READ REGISTERS VIA GET SUB
8784 040606 000404                BR      110$      ;GO TO 110$ IF NO ERROR
8785 040610 000240                NOP
8786 040612 104000                ERROR   ;RETURN HERE IF ERROR
8787 040614 000137 040734      JMP     160$      ;GO TO 160$ IF ERROR WAS FOUND
8788 040620                110$:
8789 040620 004737 045212      JSR     PC,PRIERR  ;GO CHECK FOR PRIMARY ERRORS
8790 040624 000405                BR      120$      ;GO TO 120$ IF NO ERROR
8791 040626 000240                NOP
8792 040630 104000                ERROR   ;RETURN HERE IF ERROR
8793 040632 004736                JSR     PC,@(SP)+ ;ERROR # DEFINED BY PRIERR SUBROUTINE
8794 040634 000137 040734      JMP     160$      ;GO BACK FOR MORE ERROR CHECKS
8795 040640 032737 010000 001370 120$: BIT    #IVC,RMER2I ;DID IVC SET??
8796 040646 001012                BNE    130$      ;YES!!
8797 040650 012737 010000 001140  MOV    #IVC,$GDDAT ;EXPECTED STATUS
8798 040656 013737 001370 001142  MOV    RMER2I,$BDDAT ;RECEIVED STATUS
8799 040664 042737 167777 001142  BIC    #IVC,$BDDAT
8800 040672 104260                ERROR   ;IVC NOT SET DURING SEARCH
8801 040674                130$:
8802 040674                140$:
8803 040674 004737 061566      JSR     PC,CMPERRSTS ;CHECK ANY ERRORS NOT MASKED
8804 040700 115760                .WORD  NDIMSK     ;MASK FOR RMER1
8805 040702 010010                .WORD  IVC!DPE    ;MASK FOR RMER2
8806 040704 000405                BR      150$      ;GO TO 150$ IF NO ERROR
8807 040706 000240                NOP
8808 040710 104000                ERROR   ;RETURN HERE IF ERROR
8809 040712 004736                JSR     PC,@(SP)+ ;ERROR # DEFINED BY CMPERRSTS SUBROUTINE
8810 040714 000137 040734      JMP     160$      ;GO BACK FOR MORE ERROR CHECKS
8811 040720                150$:
8812 040720 004737 046044      JSR     PC,SECERR  ;GO CHECK FOR SECONDARY ERRORS
8813 040724 000403                BR      160$      ;GO TO 160$ IF NO ERROR
8814 040726 000240                NOP
8815 040730 104000                ERROR   ;RETURN HERE IF ERROR
8816 040732 004736                JSR     PC,@(SP)+ ;ERROR # DEFINED BY SECERR SUBROUTINE
8817 040734                160$:
8818                ;*****
8819                ;*TEST 70      ABORT SEARCH TEST
8820                ;*****
8821 040734                †ST70:
8822 040734 000004                SCOPE   ;SCOPE CALL
8823 040736 000240                NOP     ;START OF TEST
8824 040740 012706 001100      MOV     #STACK,SP ;INITIALIZE STACK POINTER
8825 040744 013700 001276      MOV     $BASE,R0  ;R0=UNIBUS ADDRESS
8826 040750 013701 001446      MOV     TSTQUE,R1 ;(R1) = DEVICE BEING TESTED
8827 040754 012737 000070 001226  MOV     #70,$TESTN ;SET TEST NUMBER IN APT MAIL BOX
8828
8829 040762 004737 043216      JSR     PC,TSTPRP  ;PREPARE DEVICE FOR TEST
8830 040766 054130                .WORD  ;TASK DESCRIPTOR

```

```

8831 040770 000404 BR 80$ ;GO TO 80$ IF NO ERROR
8832 040772 000240 NOP ;RETURN HERE IF ERROR
8833 040774 104000 ERROR ;ERROR # DEFINED BY TSTPRP SUBROUTINE
8834 040776 000137 041300 JMP 160$ ;GO TO 160$ IF ERROR WAS FOUND
8835 041002 012737 040000 001412 80$: MOV #UNS,RMER10 ;SET UNSAFE ERROR
8836 041010 012737 000031 001376 MOV #SEARCH!GO,RMCS10 ;SEARCH COMMAND
8837 041016 012737 000000 001432 MOV #0,RMDC0 ;CYLINDER 0
8838 041024 012737 000000 001404 MOV #0,RMDAO ;SECTOR=TRACK=0
8839 041032 012702 001533 MOV #PUTINX,R2 ;WRITE REGISTER INDEX TABLE
8840 041036 112722 000034 MOVB #RMDC,(R2)+
8841 041042 112722 000006 MOVB #RMDA,(R2)+
8842 041046 112722 000014 MOVB #RMER1,(R2)+
8843 041052 112722 000000 MOVB #RMCS1,(R2)+
8844 041056 112722 000200 MOVB #200,(R2)+ ;TERMINATE TABLE
8845 041062 004737 044132 JSR PC,GETSTS ;SETUP FOR STATUS
8846 041066 004737 044466 JSR PC,PUT ;GO WRITE REGISTERS VIA PUT SUB
8847 041072 000404 BR 90$ ;GO TO 90$ IF NO ERROR
8848 041074 000240 NOP ;RETURN HERE IF ERROR
8849 041076 104000 ERROR ;ERROR DEFINED BY PUT SUB
8850 041100 000137 041300 JMP 160$ ;GO TO 160$ IF ERROR WAS FOUND
8851 041104 90$:
8852 041104 004737 044216 JSR PC,GET ;GO READ REGISTERS VIA GET SUB
8853 041110 000404 BR 100$ ;GO TO 100$ IF NO ERROR
8854 041112 000240 NOP ;RETURN HERE IF ERROR
8855 041114 104000 ERROR ;ERROR DEFINED BY GET SUB
8856 041116 000137 041300 JMP 160$ ;GO TO 160$ IF ERROR WAS FOUND
8857 041122 032737 020000 001340 100$: BIT #PIP,RMDSI ;IS PIP SET??
8858 041130 001412 BEQ 110$ ;NO!!
8859 041132 012737 000000 001140 MOV #0,$GDDAT ;EXPECTED STATUS
8860 041140 013737 001340 001142 MOV RMDSI,$BDDAT ;RECEIVED STATUS
8861 041146 042737 157777 001142 BIC #!CPIP,$BDDAT
8862 041154 104261 ERROR 261 ;DRIVE DID NOT ABORT SEARCH
8863 041156 004737 045026 110$: JSR PC,TIMOUT ;WAIT FOR GO TO RESET
8864 041162 004737 044216 JSR PC,GET ;GO READ REGISTERS VIA GET SUB
8865 041166 000404 BR 120$ ;GO TO 120$ IF NO ERROR
8866 041170 000240 NOP ;RETURN HERE IF ERROR
8867 041172 104000 ERROR ;ERROR DEFINED BY GET SUB
8868 041174 000137 041300 JMP 160$ ;GO TO 160$ IF ERROR WAS FOUND
8869 041200 120$:
8870 041200 004737 045212 JSR PC,PRIERR ;GO CHECK FOR PRIMARY ERRORS
8871 041204 000405 BR 130$ ;GO TO 130$ IF NO ERROR
8872 041206 000240 NOP ;RETURN HERE IF ERROR
8873 041210 104000 ERROR ;ERROR # DEFINED BY PRIERR SUBROUTINE
8874 041212 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
8875 041214 000137 041300 JMP 160$ ;GO TO 160$ IF ERROR WAS FOUND
8876 041220 130$:
8877 041220 004737 061062 JSR PC,STCDRVSTS ;GO CHECK FOR CHANGES IN DRIVE STATUS
8878 041224 000405 BR 140$ ;GO TO 140$ IF NO ERROR
8879 041226 000240 NOP ;RETURN HERE IF ERROR
8880 041230 104000 ERROR ;ERROR # DEFINED BY STCDRVSTS SUBROUTINE
8881 041232 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
8882 041234 000137 041300 JMP 160$ ;GO TO 160$ IF ERROR WAS FOUND
8883 041240 140$:
8884 041240 004737 061566 JSR PC,CMPESTS ;CHECK ANY ERRORS NOT MASKED
8885 041244 155760 .WORD ND!MSK!UNS ;MASK FOR RMER1
8886 041246 000010 .WORD DPE ;MASK FOR RMER2

```

```

8887 041250 000405 BR 150$ ;GO TO 150$ IF NO ERROR
8888 041252 000240 NOP ;RETURN HERE IF ERROR
8889 041254 104000 ERROR ;ERROR # DEFINED BY CMPERRSTS SUBROUTINE
8890 041256 004736 JSR PC,2(SP)+ ;GO BACK FOR MORE ERROR CHECKS
8891 041260 000137 041300 JMP 160$ ;GO TO 160$ IF ERROR WAS FOUND
8892 041264 150$: JSR PC,SECERR ;GO CHECK FOR SECONDARY ERRORS
8893 041264 004737 046044 BR 160$ ;GO TO 160$ IF NO ERROR
8894 041270 000403 NOP ;RETURN HERE IF ERROR
8895 041272 000240 ERROR ;ERROR # DEFINED BY SECERR SUBROUTINE
8896 041274 104000 JSR PC,2(SP)+ ;GO BACK FOR MORE ERROR CHECKS
8897 041276 004736
8898 041300
8899
8900
8901
8902
8903 041300
8904 041300 000004
8905 041302 000240
8906 041304 012706 001100
8907 041310 013700 001276
8908 041314 013701 0C1446
8909 041320 012737 000071 001226
8910 041326 004737 043216
8911 041332 054130
8912 041334 000404
8913 041336 000240
8914 041340 104000
8915 041342 000137 041642
8916 041346 012737 000000 001404 80$:
8917 041354 012737 000000 001432
8918 041362 012737 010000 001430
8919 041370 012737 000015 001376
8920 041376 012702 001533
8921 041402 112722 000006
8922 041406 112722 000034
8923 041412 112722 000032
8924 041416 112722 000000
8925 041422 112722 000200
8926 041426 004737 044466
8927 041432 000404
8928 041434 000240
8929 041436 104000
8930 041440 000137 041642
8931 041444 004737 044132 90$:
8932 041450 004737 045026
8933 041454 112737 000000 001533 120$:
8934 041462 112737 000200 001534
8935 041470 012737 000031 001376
8936 041476 004737 044466
8937 041502 000404
8938 041504 000240
8939 041506 104000
8940 041510 000137 041642
8941 041514
8942 041514 004737 045026 130$:

```

```

*****
;TEST 71 SEARCH AT OFFSET
*****
TST71:

```

```

SCOPE ;SCOPE CALL
NOP ;START OF TEST
MOV #STACK,SP ;INITIALIZE STACK POINTER
MOV $BASE,R0 ;R0=UNIBUS ADDRESS
MOV TSTQUE,R1 ;(R1) = DEVICE BEING TESTED
MOV #71,STESTN ;SET TEST NUMBER IN APT MAIL BOX
JSR PC,TSTPRP ;PREPARE DEVICE FOR TEST
WORD 054130 ;TASK DESCRIPTOR
BR 80$ ;GO TO 80$ IF NO ERROR
NOP ;RETURN HERE IF ERROR
ERROR ;ERROR # DEFINED BY TSTPRP SUBROUTINE
JMP 190$ ;GO TO 190$ IF ERROR WAS FOUND
MOV #0,RMDAO ;TRACK=SECTOR=0
MOV #0,RMDCO ;CYLINDER=0
MOV #FMT16,RMOFO ;16 BIT FORMAT
MOV #OFFSET!GO,RMCS10 ;OFFSET COMMAND
MOV #PUTINX,R2 ;SETUP REGISTER INDEX TABLE
MOVB #RMDA,(R2)+ ;FOR SEEK TO CYLINDER 0
MOVB #RMDC,(R2)+
MOVB #RMOF,(R2)+
MOVB #RMCS1,(R2)+
MOVB #200,(R2)+
JSR PC,PUT ;GO WRITE REGISTERS VIA PUT SUB
BR 90$ ;GO TO 90$ IF NO ERROR
NOP ;RETURN HERE IF ERROR
ERROR ;ERROR DEFINED BY PUT SUB
JMP 190$ ;GO TO 190$ IF ERROR WAS FOUND
JSR PC,GETSTS ;SETUP FOR STATUS FETCH
JSR PC,TIMOUT
MOVB #RMCS1,PUTINX ;LOAD REGISTER INDEX TABLE
MOVB #200,PUTINX+1
MOV #SEARCH!GO,RMCS10 ;STORE SEARCH COMMAND
JSR PC,PUT ;GO WRITE REGISTERS VIA PUT SUB
BR 130$ ;GO TO 130$ IF NO ERROR
NOP ;RETURN HERE IF ERROR
ERROR ;ERROR DEFINED BY PUT SUB
JMP 190$ ;GO TO 190$ IF ERROR WAS FOUND
JSR PC,TIMOUT ;WAIT FOR SEARCH TO COMPLETE

```

```

8943 041520 004737 044216 JSR PC_GET ;GO READ REGISTERS VIA GET SUB
8944 041524 000404 BR 140$ ;GO TO 140$ IF NO ERROR
8945 041526 000240 NOP ;RETURN HERE IF ERROR
8946 041530 104000 ERROR ;ERROR DEFINED BY GET SUB
8947 041532 000137 041642 JMP 190$ ;GO TO 190$ IF ERROR WAS FOUND
8948 041536 140$:
8949 041536 004737 045212 JSR PC_PRIERR ;GO CHECK FOR PRIMARY ERRORS
8950 041542 000405 BR 150$ ;GO TO 150$ IF NO ERROR
8951 041544 000240 NOP ;RETURN HERE IF ERROR
8952 041546 104000 ERROR ;ERROR # DEFINED BY PRIERR SUBROUTINE
8953 041550 004736 JSR PC_2(SP)+ ;GO BACK FOR MORE ERROR CHECKS
8954 041552 000137 041642 JMP 190$ ;GO TO 190$ IF ERROR WAS FOUND
8955 041556 150$:
8956 041556 004737 057516 JSR PC_SCHSTS ;GO VERIFY SEARCH OPERATION
8957 041562 000405 BR 160$ ;GO TO 160$ IF NO ERROR
8958 041564 000240 NOP ;RETURN HERE IF ERROR
8959 041566 104000 ERROR ;ERROR # DEFINED BY SCHSTS SUBROUTINE
8960 041570 004736 JSR PC_2(SP)+ ;GO BACK FOR MORE ERROR CHECKS
8961 041572 000137 041642 JMP 190$ ;GO TO 190$ IF ERROR WAS FOUND
8962 041576 160$:
8963 041576 004737 061566 JSR PC_CMPERRSTS ;CHECK ANY ERRORS NOT MASKED
8964 041602 115760 .WORD ND1MSK ;MASK FOR RMER1
8965 041604 000010 .WORD DPE ;MASK FOR RMER2
8966 041606 000405 BR 170$ ;GO TO 170$ IF NO ERROR
8967 041610 000240 NOP ;RETURN HERE IF ERROR
8968 041612 104000 ERROR ;ERROR # DEFINED BY CMPERRSTS SUBROUTINE
8969 041614 004736 JSR PC_2(SP)+ ;GO BACK FOR MORE ERROR CHECKS
8970 041616 000137 041642 JMP 190$ ;GO TO 190$ IF ERROR WAS FOUND
8971 041622 170$:
8972 041622 004737 046044 JSR PC_SECERR ;GO CHECK FOR SECONDARY ERRORS
8973 041626 000405 BR 180$ ;GO TO 180$ IF NO ERROR
8974 041630 000240 NOP ;RETURN HERE IF ERROR
8975 041632 104000 ERROR ;ERROR # DEFINED BY SECERR SUBROUTINE
8976 041634 004736 JSR PC_2(SP)+ ;GO BACK FOR MORE ERROR CHECKS
8977 041636 000137 041642 JMP 190$ ;GO TO 190$ IF ERROR WAS FOUND
8978 041642 180$:
8979 041642 190$:
8980
8981 041642 000137 042150 JMP $E0SP ;SKIP OVER HEAD ALIGNMENT SEEK
8982
8983 ;PUT NEWTEST HERE
8984 ;*****
8985 ;*TEST 72 HEAD ALIGNMENT SEEK
8986 ;*****
8987 †ST72:
8988 041646 000004 SCOPE ;SCOPE CALL
8989 041650 000240 NOP ;START OF TEST
8990 041652 012737 000001 001206 MOV #1,$TIMES ;LOAD ITERATION COUNT
8991 041660 012737 041674 001122 MOV #1,$SLPADR
8992 041666 012737 041674 001124 MOV #1,$SLPERR
8993 041674 1$:
8994 041674 012706 001100 MOV #STACK,$SP ;INITIALIZE STACK POINTER
8995 041700 013700 001276 MOV $BASE,$RO ;RO=UNIBUS ADDRESS
8996 041704 013701 001446 MOV TSTQUE,$R1 ;(R1) = DEVICE BEING TESTED
8997 041710 012737 000072 001226 MOV #72,$TESTN ;SET TEST NUMBER IN APT MAIL BOX
8998

```



9055	042116	000010		.WORD	DPE		;MASK FOR RMER2
9056	042120	000405		BR	130\$		;GO TO 130\$ IF NO ERROR
9057	042122	000240		NOP			;RETURN HERE IF ERROR
9058	042124	104000		ERROR			;ERROR # DEFINED BY CMPERRSTS SUBROUTINE
9059	042126	004736		JSR	PC,2(SP)+		;GO BACK FOR MORE ERROR CHECKS
9060	042130	000137	042150	JMP	140\$		;GO TO 140\$ IF ERROR WAS FOUND
9061	042134						
9062	042134	004737	046044			130\$:	
9063	042140	000403		JSR	PC,SECERR		;GO CHECK FOR SECONDARY ERRORS
9064	042142	000240		BR	140\$		;GO TO 140\$ IF NO ERROR
9065	042144	104000		NOP			;RETURN HERE IF ERROR
9066	042146	004736		ERROR			;ERROR # DEFINED BY SECERR SUBROUTINE
9067	042150			JSR	PC,2(SP)+		;GO BACK FOR MORE ERROR CHECKS
						140\$:	



9068 042150  
 9069 042150 000240  
 9070 042152 013700 001446  
 9071 042156 062700 000002  
 9072 042162 010037 001446  
 9073 042166 005710  
 9074 042170 001402  
 9075 042172 000137 007106  
 9076 042176 012737 001450 001446  
 9077  
 9078  
 9079  
 9080  
 9081  
 9082  
 9083  
 9084  
 9085  
 9086 042204  
 9087 042204 000240  
 9088 042206 005037 001116  
 9089 042212 005037 001206  
 9090 042216 005237 001230  
 9091 042222 042737 100000 001230  
 9092 042230 005327  
 9093 042232 000001  
 9094 042234 003063  
 9095 042236 012737  
 9096 042240 000001  
 9097 042242 042232  
 9098 042244 104401 042252  
 9099 042250 000407  
 9100  
 9101 042270  
 9102 042270 013746 001230  
 9103  
 9104 042274 104405  
 9105 042276 104401 042304  
 9106 042302 000421  
 9107  
 9108 042346  
 9109 042346 013746 001126  
 9110  
 9111 042352 104405  
 9112 042354 104401 001217  
 9113 042360 005037 001126  
 9114 042364 013700 000042  
 9115 042370 001405  
 9116 042372 000005  
 9117 042374 004710  
 9118 042376 000240  
 9119 042400 000240  
 9120 042402 000240  
 9121 042404  
 9122 042404 000137  
 9123 042406 007106

```

SEOSP:
  NOP
  MOV TSTQUE,RO
  ADD #2,RO
  MOV RO,TSTQUE
  TST (RO)
  BEQ 1$
  JMP READY
  MOV #TSTQUE+2,TSTQUE
  1$:
  .SBTTL END OF PASS ROUTINE

*****
;INCREMENT THE PASS NUMBER ($PASS)
;*TYPE "END PASS #XXXXX TOTAL NUMBER OF ERRORS SINCE LAST REPORT YYYYY"
;*WHERE XXXXX AND YYYYY ARE DECIMAL NUMBERS
;*IF THERES A MONITOR GO TO IT
;*IF THERE ISN'T JUMP TO READY

SEOP:
  NOP
  CLR $STNM           ;;ZERO THE TEST NUMBER
  CLR $TIMES          ;;ZERO THE NUMBER OF ITERATIONS
  INC $PASS           ;;INCREMENT THE PASS NUMBER
  BIC #100000,$PASS  ;;DON'T ALLOW A NEG. NUMBER
  DEC (PC)+           ;;LOOP?
SEOPCT: .WORD 1
  BGT $DOAGN          ;;YES
  MOV (PC)+,2(PC)+   ;;RESTORE COUNTER
SENDCT: .WORD 1
  $EOPCT
  TYPE 65$           ;;TYPE ASCIZ STRING
  BR 64$             ;;GET OVER THE ASCIZ
;;65$: .ASCIZ <12><15>/END PASS #/
64$: MOV $PASS,-(SP) ;;SAVE $PASS FOR TYPEOUT
      ;;TYPE PASS NUMBER
      GO TYPE--DECIMAL ASCII WITH SIGN
      TYPE 67$       ;;TYPE ASCIZ STRING
      BR 66$         ;;GET OVER THE ASCIZ
;;67$: .ASCIZ / TOTAL ERRORS SINCE LAST REPORT /
66$: MOV $ERTTL,-(SP) ;;SAVE $ERTTL FOR TYPEOUT
      ;;TOTAL NUMBER OF ERRORS
      GO TYPE--DECIMAL ASCII WITH SIGN
      TYPE $CRLF     ;;TYPE CARRIAGE RETURN, LINE FEED
      CLR $ERTTL    ;;CLEAR ERROR TOTAL
      MOV #42,RO    ;;GET MONITOR ADDRESS
      BEQ $DOAGN    ;;BRANCH IF NO MONITOR
      RESET        ;;CLEAR THE WORLD
SENDAD: JSR PC,(RO) ;;GO TO MONITOR
        NOP        ;;SAVE ROOM
        NOP        ;;FOR
        NOP        ;;ACT11
$DOAGN: JMP 2(PC)+   ;;RETURN
$RTNAD: .WORD READY

```

CZRMCB0 RMO3/2 FCTNL TS 1  
CZRMCB.P11 23-NOV-77 12:14

MACY11 30(1046) 23-NOV-77 12:25 PAGE 184  
END OF PASS ROUTINE

SEQ 0184

9124 042410 377 377  
9125 042414

000 \$ENULL: .BYTE -1,-1,0  
.EVEN

::NULL CHARACTER STRING

```

9126
9127
9128
9129
9130
9131
9132
9133
9134
9135
9136
9137
9138
9139
9140
9141 042414
9142 042414 104414
9143 042416 032777 020000 136530
9144 042424 001402
9145 042426 000137 043144
9146
9147 042432 104401 001217
9148 042436 104401 043160
9149 042442 013746 001234
9150
9151 042446 104403
9152 042450 003
9153 042451 000
9154 042452 005037 043150
9155 042456 013737 001226 043150
9156 042464 104401 043166
9157 042470 013746 043150
9158
9159 042474 104403
9160 042476 003
9161 042477 000
9162 042500 005037 043152
9163 042504 113737 001130 043152
9164 042512 001406
9165 042514 104401 043176
9166 042520 013746 043152
9167
9168 042524 104403
9169 042526 003
9170 042527 000
9171 042530 104401 043205
9172 042534 013746 001132
9173
9174 042540 104403
9175 042542 006
9176 042543 001
9177
9178 042544 005737 043152
9179 042550 001575
9180 042552 104401 001217
9181 042556 105037 043156

```

```

.SBTTL SUBROUTINES
:*****
.SBTTL ERROR TYPEOUT ROUTINE
:
:*THE ERROR TYPEOUT ROUTINE ASSEMBLES AND PRINTS INFORMATION
:*REGARDING THE DETECTION OF AN ERROR AS FOLLOWS:
:*
:* .UNIT NUMBER, TEST NUMBER, ERROR NUMBER AND PROGRAM COUNTER ARE
:*PRINTED ON THE FIRST LINE;
:* .ERROR MESSAGE IS ASSEMBLED, FORMATTED AND PRINTED ON
:*ONE OR MORE SUCCEEDING LINES;
:* .PAIRED LINES OF ERROR HEADERS AND ERROR DATA
:*ARE PRINTED AFTER THE ERROR MESSAGE.
ERRTYP:
SAVREG
BIT #SW13,DSWR ;INHIBIT TYPEOUTS??
BEQ 1$ ;NO!!
JMP 21$ ;YES!!
1$:
TYPE UNIT NUMBER, TEST NUMBER, ERROR NUMBER, AND PROGRAM COUNTER
TYPE ,SCLF
TYPE ,ERTY00 ;TYPE "UNT#"
MOV $UNIT,-(SP) ;SAVE $UNIT FOR TYPEOUT
;TYPE UNIT NUMBER
;GO TYPE--OCTAL ASCII
;TYPE 3 DIGIT(S)
;SUPPRESS LEADING ZEROS
;LOAD TEST NUMBER FOR
TYPOS
.BYTE 3
.BYTE 0
CLR TSTNMB
MOV $TSTN,TSTNMB ;TYPE "TST#"
TYPE ,ERTY01 ;SAVE TSTNMB FOR TYPEOUT
MOV $TSTNMB,-(SP) ;TYPE TEST NUMBER
;GO TYPE--OCTAL ASCII
;TYPE 3 DIGIT(S)
;SUPPRESS LEADING ZEROS
;LOAD ERROR NUMBER FOR
TYPOS
.BYTE 3
.BYTE 0
CLR ERRNMB
MOVB $ITEMB,ERRNMB ;TYPEOUT
BEQ 2$ ;SKIP IF NO ERROR CALLED
TYPE ,ERTY02 ;TYPE "ERR#"
MOV $ERRNMB,-(SP) ;SAVE ERRNMB FOR TYPEOUT
;TYPE ERROR NUMBER
;GO TYPE--OCTAL ASCII
;TYPE 3 DIGIT(S)
;SUPPRESS LEADING ZEROS
;TYPE "PC="
2$:
TYPE ,ERTY03 ;SAVE $ERRPC FOR TYPEOUT
MOV $ERRPC,-(SP) ;TYPE PROGRAM COUNTER
;GO TYPE--OCTAL ASCII
;TYPE 6 DIGIT(S)
;TYPE LEADING ZEROS
3$:
GENERATE POINTER TO ERROR TABLE UNLESS ERROR NUMBER IS 0
TST ERRNMB ;WAS AN ERROR CALLED?
BEQ 21$ ;NO!!
TYPE ,SCLF ;YES-TYPE CRLF
CLRB BOTFLG ;CLEAR BOT FLAG

```

```

9182 042562 105037 043157      CLRB   CHRCNT      ; CLEAR CHARACTER COUNTER
9183 042566 013700 043152      MOV    ERRNMB,R0  ; R0 POINTS TO FIRST OF
9184 042572 006300                ASL    R0          ; FOUR ENTRIES IN ERROR
9185 042574 006300                ASL    R0          ; TABLE
9186 042576 006300                ASL    R0
9187 042600 062700 001552      ADD    #ERRTB-B.,R0
9188 042604 011001                MOV    (R0),R1   ; R1 POINTS TO ERROR MESSAGE
9189                                ; TABLE
9190 042606 001507                BEQ    13$        ; BRANCH IF NO ERROR MESSAGE
9191                                ; TYPE THE ERROR MESSAGE
9192 042610 012102 4$:      MOV    (R1)+,R2  ; R2=ADDRESS OF MESSAGE STRING
9193 042612 001505                BEQ    12$        ; BRANCH IF END OF MESSAGE
9194 042614 010237 042762      MOV    R2,11$    ; LOAD ADDRESS OF STRING
9195 042620 005037 043154      CLR    BOTADR    ; CLEAR BOT ADDRESS
9196 042624 112203 5$:      MOV    (R2)+,R3  ; END OF STRING??
9197 042626 001454                BEQ    10$        ; YES!!
9198 042630 122703 000015      CMPB  #CR,R3     ; CARRIAGE RETURN??
9199 042634 001003                BNE    6$        ; NO!!
9200 042636 105037 043157      CLRB   CHRCNT    ; YES-CLEAR CHAR COUNT
9201 042642 000770                BR     5$        ; GET NEXT CHARACTER
9202 042644 122703 000012 6$:      CMPB  #LF,R3     ; LINE FEED??
9203 042650 001765                BEQ    5$        ; YES-GET NEXT CHARACTER
9204 042652 122703 000011      CMPB  #HT,R3     ; HORIZONTAL TAB??
9205 042656 001007                BNE    8$        ; NO!!
9206 042660 105237 043157 7$:      INCB  CHRCNT    ; ADJUST CHARACTER COUNT
9207 042664 132737 000007 043157  BITB  #7,CHRCNT
9208 042672 001372                BNE    7$
9209 042674 000407                BR     9$
9210 042676 105237 043157 8$:      INCB  CHRCNT    ; INCREMENT CHARACTER COUNT
9211 042702 122703 000040      CMPB  #' ,R3     ; SPACE??
9212 042706 001002                BNE    9$        ; NO!!
9213 042710 010237 043154      MOV    R2,BOTADR ; SAVE ADDRESS OF SPACE
9214 042714 122737 000100 043157 9$:      CMPB  #64.,CHRCNT
9215 042722 103340                BHS    5$        ; END OF LINE??
9216 042724 013704 043154      MOV    BOTADR,R4 ; NO!!
9217 042730 001007                BNE    90$       ; GET ADDRESS OF LAST SPACE
9218 042732 104401 001217      TYPE  $CRLF      ; BRANCH IF SPACE DETECTED
9219 042736 105037 043157      CLRB   CHRCNT    ; TYPE CRLF
9220 042742 013702 042762      MOV    11$,R2   ; CLEAR CHARACTER COUNT
9221 042746 000726                BR     5$        ; SET UP R2 FOR TESTING
9222 042750 105044 90$:      CLRB  -(R4)     ; REPLACE SPACE
9223 042752 112737 177777 043156  MOV    #-1,BOTFLG ; SET BOT FLAG
9224 042760 104401 10$:      TYPE  $CRLF      ; TYPE ERROR MESSAGE STRING
9225 042762 000000 11$:      .WORD ; STRING ADDRESS GOES HERE
9226 042764 105737 043156      TSTB  BOTFLG    ; WAS STRING TRUNCATED??
9227 042770 001707                BEQ    4$        ; NO!!
9228 042772 104401 001217      TYPE  $CRLF      ; YES-TYPE CRLF
9229 042776 105037 043156      CLRB  BOTFLG    ; CLEAR BOT FLAG
9230 043002 105037 043157      CLRB  CHRCNT    ; CLEAR CHARACTER COUNT
9231 043006 013702 043154      MOV    BOTADR,R2 ; SETUP R2 FOR TESTING
9232 043012 010237 042762      MOV    R2,11$   ; SETUP 11$ FOR TYPING
9233 043016 112747 000040      MOV    #' ,-(R2) ; RESTORE SPACE
9234 043022 105722                TSTB  (R2)+     ; RESTORE R2
9235 043024 000677                BR     5$        ; TYPE REST OF STRING
9236 043026
9237
12$:
;TYPE ERROR HEADER AND ERROR DATA

```



9290  
9291  
9292  
9293  
9294  
9295  
9296  
9297  
9298  
9299  
9300  
9301  
9302  
9303  
9304  
9305  
9306  
9307  
9308  
9309  
9310  
9311  
9312  
9313  
9314  
9315  
9316  
9317  
9318  
9319  
9320  
9321  
9322  
9323  
9324  
9325  
9326  
9327  
9328  
9329  
9330  
9331  
9332  
9333  
9334  
9335  
9336  
9337  
9338  
9339  
9340  
9341  
9342  
9343  
9344  
9345

.SBTTL TEST PREPARATION MODULE

: THIS MODULE PREPARES THE RMO3 SUBSYSTEM FOR THE EXECUTION OF A TEST,  
: REPORTING AN ERROR TO THE USER IF AN ERROR IS DETECTED. THE USER  
: SPECIFIES TASKS TO BE PERFORMED, WHICH THE MODULE EXECUTES  
: USING SUBROUTINES.

:CALL:

JSR PC,TSTPRP  
.WORD  
BR ??  
NOP  
ERROR

TASK/VERIFY DESCRIPTOR  
RETURN HERE IF NO ERROR  
RETURN HERE IF ERROR  
ERROR DEFINED BY MODULE

:TASK/VERIFY DESCRIPTOR

BIT 15 = 1 SELECT DEVICE AND VERIFY DEVICE IS AVAILABLE  
BIT 14 = 1 CLEAR CONTROLLER AND SELECT DEVICE  
(RESERVED FOR DRIVE CLEAR)  
BIT 13 = 1 PACK ACKNOWLEDGE IF VOLUME NOT VALID  
BIT 12 = 1 RECALIBRATE IF POSITIONING IN PROGRESS  
BIT 11 = 1  
BIT 10  
BIT 9  
BIT 8  
BIT 7  
BIT 6 = 1 VERIFY CONTROLLER CLEAR OPERATION  
(RESERVED FOR DRIVE CLEAR)  
BIT 5 = 1 VERIFY PACK ACKNOWLEDGE  
BIT 4 = 1 VERIFY RECALIBRATION  
BIT 3 = 1  
BIT 2  
BIT 1  
BIT 0

TSTPRP:

:STORE TASK DESCRIPTOR AND CLEAR USER'S ERROR CALL  
MOV 2(SP),500\$ ;STORE DESCRIPTOR  
ADD #6,(SP) ;MOVE SP TO USERS ERROR CALL  
CLRB 2(SP) ;CLEAR ERROR CALL  
SUB #4,(SP) ;MOVE SP TO NO ERROR RETURN

:\*\*\*\*\*  
:SELECT DEVICE AND VERIFY DEVICE AVAILABLE IF BIT 15 SET IN TASK

BIT #BIT15,500\$ ;SELECT DEVICE??  
BEQ 30\$ ;NO!!  
JSR PC,DEVSEL ;GO SELECT DEVICE  
BR 30\$ ;NO ERROR - CONTINUE  
BR 20\$  
10\$: .WORD ;ERROR NUMBER FROM DEVSEL  
20\$: ADD #4,(SP) ;TRANSFER ERROR TO USER  
MOV 10\$,2(SP)  
JMP 400\$

30\$:

:\*\*\*\*\*  
:CLEAR CONTROLLER IF BIT 14 IS SET IN TASK

BIT #BIT14,500\$ ;CLEAR CONTROLLER??  
BEQ 120\$ ;NO!!

043216  
043216 017637 000000 044130  
043224 062716 000006  
043230 105076 000000  
043234 162716 000004  
043240 032737 100000 044130  
043246 001414  
043250 004737 051706  
043254 000411  
043256 000401  
043260 000000  
043262 062716 000004  
043266 113776 043260 000000  
043274 000137 044116  
043300 032737 040000 044130  
043306 001453

```

9346 043310 004737 053360          JSR    PC,CNTCLR      ;GO CLEAR CONTROLLER
9347 043314 000411                   BR     60$           ;CONTINUE - NO ERROR
9348 043316 000401                   BR     50$           ;
9349 043320 000000                   40$: .WORD          ;ERROR NUMBER FROM CNTCLR
9350 043322 062716 000004          50$: ADD     #4,(SP)  ;TRANSFER ERROR TO USER
9351 043326 113776 043320 000000    MOVB   40$,2(SP)
9352 043334 000137 044116          JMP     400$
9353 043340
9354
9355 ;*****
9356 043340 032737 000100 044130    ;VERIFY CONTROLLER CLEAR IF BIT6 SET IN TASK
9357 043346 001433                   BIT    #BIT6,500$   ;VERIFY??
9358 043350 004737 044132                   BEQ   120$          ;NO!!
9359 043354 004737 044216          JSR    PC,GETSTS    ;SETUP INDEX TABLE
9360 043360 000411                   JSR    PC,GET      ;GO GET STATUS
9361 043362 000401                   BR     90$         ;NO ERROR GETTING STATUS
9362 043364 000000                   BR     80$         ;
9363 043366 062716 000004          70$: .WORD          ;ERROR FROM GETTING STATUS
9364 043372 113776 043364 000000    80$: ADD     #4,(SP) ;TRANSFER ERROR TO USER
9365 043400 000137 044116          MOVB   70$,2(SP)
9366 043404 004737 053476          90$: JSR    PC,CLRSTS ;GO VERIFY STATUS CLEAR
9367 043410 000412                   BR     120$       ;NO ERROR IN CLEAR
9368 043412 000401                   BR     110$       ;
9369 043414 000000                   100$: .WORD        ;ERROR IN STATUS CLEAR
9370 043416 005726                   TST   (SP)+        ;STRIP RETURN ADDRESS TO
9371 043420 062716 000004          110$: ADD     #4,(SP) ;SUBROUTINE AND TRANSFER
9372 043424 113776 043414 000000    MOVB   100$,2(SP) ;ERROR TO USER
9373 043432 000137 044116          JMP     400$
9374 043436
9375
9376 ;*****
9377 ;EXECUTE PACK ACKNOWLEDGE IF BIT12 SET IN TASK AND VOLUME IS
9378 ;NOT VALID
9379 043436 032737 010000 044130    BIT    #BIT12,500$ ;PACK ACKNOWLEDGE??
9380 043444 001511                   BEQ   240$         ;NO!!
9381 043446 112737 000012 001504    MOVB   #RMDS,GETINX ;GET RMDS
9382 043454 112737 000200 001505    MOVB   #200,GETINX+1
9383 043462 004737 044216          JSR    PC,GET      ;
9384 043466 000411                   BR     150$       ;NO ERROR GETTING RMDS
9385 043470 000401                   BR     140$       ;
9386 043472 000000                   130$: .WORD        ;
9387 043474 062716 000004          140$: ADD     #4,(SP) ;TRANSFER ERROR TO USER
9388 043500 113776 043472 000000    MOVB   130$,2(SP)
9389 043506 000137 044116          JMP     400$
9390 043512 032737 000100 001340    150$: BIT    #VV,RMDSI ;IS VOLUME VALID??
9391 043520 001063                   BNE   240$         ;YES!!
9392 043522 005037 001472                   CLR   MEDENB      ;CLEAR MEDIA ENABLE
9393 043526 012737 000023 001376    MOV    #PAKACK!GO,RMCSI0 ;LOAD PACK ACK COMMAND
9394 043534 112737 000000 001533    MOVB   #RMCSI,PUTINX ;SETUP REGISTER INDEX TABLE
9395 043542 112737 000200 001534    MOVB   #200,PUTINX+1
9396 043550 004737 044466          JSR    PC,PUT      ;GO WRITE COMMAND
9397 043554 000410                   BR     180$       ;NO ERROR LOADING REGISTER
9398 043556 000401                   BR     170$       ;
9399 043560 000000                   160$: .WORD        ;ERROR FROM PUT SUB
9400 043562 062716 000004          170$: ADD     #4,(SP) ;TRANSFER ERROR TO USER
9401 043566 113776 043560 000000    MOVB   160$,2(SP)

```

```

9402 043574 000550          BR      400$
9403 043576          180$:
9404
9405          ;*****
9406          ;VERIFY PACK ACKNOWLEDGE IF #BIT4 SET IN TASK
9407 043576 032737 000020 044130  BIT      #BIT4,500$      ;VERIFY PACK ACKNOWLEDGE??
9408 043604 001431          BEQ      240$          ;NO!!
9409 043606 004737 044132          JSR      PC,GETSTS      ;SETUP FOR STATUS
9410 043612 004737 044216          JSR      PC,GET          ;GO GET STATUS
9411 043616 000410          BR      210$          ;NO ERROR GETTING STATUS
9412 043620 000401          BR      200$
9413 043622 000000          190$: .WORD          ;ERROR FROM GET SUB
9414 043624 062716 000004 200$: ADD      #4,(SP)      ;TRANSFER ERROR TO USER
9415 043630 113776 043622 000000  MOVB     190$,2(SP)
9416 043636 000527          BR      400$
9417 043640 004737 054356 210$: JSR      PC,ACKSTS      ;GO CHECK ACKNOWLEDGE
9418 043644 000411          BR      240$          ;NO ERROR
9419 043646 000401          BR      230$
9420 043650 000000          220$: .WORD          ;PACK ACKNOWLEDGE ERROR
9421 043652 005726 230$: TST      (SP)+      ;STRIP RETURN TO SUB AND
9422 043654 062716 000004  ADD      #4,(SP)      ;TRANSFER ERROR TO USER
9423 043660 113776 043650 000000  MOVB     220$,2(SP)
9424 043666 000513          BR      400$
9425 043670          240$:
9426
9427          ;*****
9428          ;RECALIBRATE DRIVE IF BIT 11 SET IN TASK AND PIP IS ACTIVE
9429 043670 032737 004000 044130  BIT      #BIT11,500$    ;RECALIBRATE??
9430 043676 001513          BEQ      410$          ;NO!!
9431 043700 112737 000012 001504  MOVB     #RMDS,GETINX    ;LOAD REGISTER INDEX TABLE
9432 043706 112737 000200 001505  MOVB     #200,GETINX+1
9433 043714 004737 044216          JSR      PC,GET          ;GO GET RMDS
9434 043720 000410          BR      270$          ;NO ERROR GETTING RMDS
9435 043722 000401          BR      260$
9436 043724 000000          250$: .WORD          ;ERROR FROM GET SUB
9437 043726 062716 000004 260$: ADD      #4,(SP)      ;TRANSFER ERROR TO USER
9438 043732 113776 043724 000000  MOVB     250$,2(SP)
9439 043740 000466          BR      400$
9440 043742 032737 020000 001340 270$: BIT      #PIP,RMDSI      ;IS PIP ACTIVE??
9441 043750 001466          BEQ      410$          ;NO!!
9442 043752 012737 000007 001376  MOV      #RECAL!GO,RMCS10 ;LOAD RECALIBRATE COMMAND
9443 043760 112737 000000 001533  MOVB     #RMCS1,PUTINX    ;AND REGISTER INDEX
9444 043766 112737 000200 001534  MOVB     #200,PUTINX+1
9445 043774 004737 044466          JSR      PC,PUT          ;GO ISSUE RECALIBRATE
9446 044000 000410          BR      300$          ;NO ERROR
9447 044002 000401          BR      290$
9448 044004 000000          280$: .WORD          ;ERROR IN REGISTER TRANSFER
9449 044006 062716 000004 290$: ADD      #4,(SP)      ;TRANSFER ERROR TO USER
9450 044012 113776 044004 000000  MOVB     280$,2(SP)
9451 044020 000436          BR      400$
9452 044022 004737 044132 300$: JSR      PC,GETSTS      ;SETUP FOR STATUS
9453 044026 004737 045026          JSR      PC,TIMOUT      ;WAIT FOR COMPLETION
9454
9455          ;*****
9456          ;VERIFY RECALIBRATE IF BIT 3 SET IN TASK
9457 044032 032737 000010 044130  BIT      #BIT3,500$      ;VERIFY RECALIBRATE??

```



9458	044040	001432				BEG	410\$		:NO!!
9459	044042	004737	044216			JSR	PC,GET		:GO GET STATUS
9460	044046	000410				BR	330\$		:NO ERROR GETTING STATUS
9461	044050	000401				BR	320\$		
9462	044052	000000			310\$:	.WORD			:ERROR FROM GET
9463	044054	062716	000004		320\$:	ADD	#4,(SP)		:TRANSFER ERROR TO USER
9464	044060	113776	044052	000000		MOVB	310\$,2(SP)		
9465	044066	000413				BR	400\$		
9466	044070	004737	055152		330\$:	JSR	PC,RCLSTS		:GO CHECK RECALIBRATE
9467	044074	000414				BR	410\$		:NO ERROR DURING RECALIBRATE
9468	044076	000401				BR	350\$		
9469	044100	000000			340\$:	.WORD			:ERROR DURING RECALIBRATE
9470	044102	005726			350\$:	TST	(SP)+		:STRIP RETURN TO SUB AND
9471	044104	062716	000004			ADD	#4,(SP)		:TRANSFER ERROR TO USER
9472	044110	113776	044100	000000		MOVB	340\$,2(SP)		
9473	044116	162716	000002		400\$:	SUB	#2,(SP)		:MOVE SP BACK BEFORE ERROR
9474	044122	000240				NOP			
9475	044124	000240				NOP			
9476	044126	000207			410\$:	RTS	PC		:RETURN TO USER
9477									
9478	044130	000000			500\$:	.WORD			:TASK/VERIFY DESCRIPTOR

9479  
 9480  
 9481  
 9482  
 9483  
 9484  
 9485  
 9486  
 9487  
 9488 044132  
 9489 044132 010046  
 9490 044134 010146  
 9491 044136 010246  
 9492 044140 012700 001504  
 9493 044144 012701 001376  
 9494 044150 012702 000046  
 9495 044154 110220  
 9496 044156 005041  
 9497 044160 162702 000002  
 9498 044164 100405  
 9499 044166 022702 000022  
 9500 044172 001370  
 9501 044174 005041  
 9502 044176 000770  
 9503 044200 112720 000200  
 9504 044204 012602  
 9505 044206 012601  
 9506 044210 012600  
 9507 044212 000240  
 9508 044214 000207  
 9509

```

.SBTTL GET STATUS SUBROUTINE
; THIS SUBROUTINE SETS UP THE "GET INDEX TABLE" AND THE "GET
; BUFFER" FOR READING ALL SUBSYSTEM REGISTERS VIA THE GET SUBROUTINE
; AND THEN RETURNS TO THE USER.
; CALL: JSR PC,GE1STS RETURN HERE
; ???
GETSTS:
MOV RO,-(SP) ;: PUSH RO ON STACK
MOV R1,-(SP) ;: PUSH R1 ON STACK
MOV R2,-(SP) ;: PUSH R2 ON STACK
MOV #GETINX,RO ;: RO= ADDRESS OF INDEX TABLE
MOV #RMEC2I+2,R1 ;: R1 = ADDRESS OF GET BUFFER
MOV #RMEC2,R2 ;: R2 = REGISTER INDE
2$: MOV B R2,(RO)+ ;: WRITE REGISTER INDEX IN TABLE
CLR -(R1) ;: CLEAR CORRESPONDING LOCATION
3$: SUB #2,R2 ;: DECREMENT TO NEXT INDEX
BMI 4$ ;: BRANCH OUT IF DONE
CMP #RMDB,R2 ;: DONT WRITE RMDB INDEX
BNE 2$
CLR -(R1)
BR 3$
4$: MOV B #200,(RO)+ ;: WRITE TERMINATOR
MOV (SP)+,R2 ;: POP STACK INTO R2
MOV (SP)+,R1 ;: POP STACK INTO R1
MOV (SP)+,RO ;: POP STACK INTO RO
NOP
RTS PC

```

```

9510 .SBTTL GET SUBROUTINE
9511
9512 ;THIS SUBROUTINE READS THE REGISTERS WHICH ARE LISTED IN THE
9513 ;"GET INDEX TABLE" AND STORES THEIR VALUES IN THE CORRESPONDING
9514 ;LOCATION IN THE "GET REGISTER BUFFER". FOR EXAMPLE, AN
9515 ;ENTRY OF 04 IN THE TABLE WILL CAUSE THE SUBROUTINE TO
9516 ;READ "RMB4" AND STORE ITS CONTENTS AT THE LOCATION IN
9517 ;THE BUFFER ASSIGNED TO THAT REGISTER. THE NUMBER OF
9518 ;REGISTERS TO BE READ IS VARIABLE FROM 1 TO 22; THE INDEX
9519 ;TABLE MUST BE TERMINATED WITH A CONTROL BYTE (200)
9520 ;WHICH SHOULD FOLLOW THE LAST ENTRY.
9521
9522 SUBROUTINE CALL:
9523 (1) "GET INDEX TABLE" HAS BEEN LOADED WITH REGISTER INDEX
9524 VALUES AND TERMINATED WITH A CONTROL BYTE
9525 (2) "GET INPUT BUFFER" IS AVAILABLE FOR USE. (NOTE THAT
9526 UNUSED LOCATIONS, I.E., ENTRIES IN BUFFER CORRESPONDING
9527 TO REGISTERS NOT READ, ARE NOT CHANGED.)
9528 (3) JSR PC GET
9529 BR ??? RETURN HERE IF NO ERROR FOUND
9530 NOP RETURN HERE IF ANY ERROR FOUND
9531 ERROR SUB DEFINES ERROR NUMBER
9532 ???
9533
9534 GET: NOP
9535 ADD #4,(SP) ;CLEAR ERROR NUMBER IN USER'S
9536 CLRB @ (SP) ;ERROR CALL
9537 SUB #4,(SP)
9538 MOV RO,-(SP) ;;PUSH RO ON STACK
9539 MOV R1,-(SP) ;;PUSH R1 ON STACK
9540 MOV R2,-(SP) ;;PUSH R2 ON STACK
9541 MOV R3,-(SP) ;;PUSH R3 ON STACK
9542 MOV R4,-(SP) ;;PUSH R4 ON STACK
9543 MOV ERVEC,-(SP) ;;PUSH ERVEC ON STACK
9544 MOV ERVEC+2,-(SP) ;;PUSH ERVEC+2 ON STACK
9545 MOV $BASE,RO
9546 MOV #GETBUF,R2
9547 MOV #GETINX,R4
9548 MOV #55,ERRVEC ;SETUP FOR TIMEOUT
9549 MOV #PR6,ERRVEC+2
9550 MOV RMCS2(RO),$TMP0 ;GET "NED" STATUS
9551 MOV RMCS1(RO),$TMP1 ;GET "DVA" STATUS
9552 BIT #DVA,$TMP1 ;DEVICE AVAILABLE??
9553 BNE 3$ ;YES!!
9554 ADD #4,16(SP) ;WRITE ERROR NUMBER IN USER'S
9555 MOVB #112,@16(SP) ;ERROR CALL
9556 BR 7$
9557 TSTB (R4) ;DONE??
9558 BMI 9$ ;YES!!
9559 MOVB (R4),R1 ;R1 = REGISTER ADDRESS
9560 BIC #+CIDXMSK,R1 ;CLEAR ANY SIGN EXTENSION
9561 ADD RO,R1
9562 MOVB (R4)+,R3 ;R3 = STORAGE ADDRESS FOR REGISTER
9563 BIC #+CIDXMSK,R3 ;CLEAR ANY SIGN EXTENSION
9564 ADD R2,R3
9565 MOV (R1),(R3) ;READ REGISTER
  
```

```
9566 044376 000764 BR 3$
9567
9568 044400 022626 5$: CMP (SP)+,(SP)+ ;RESTORE STACK
9569 044402 062766 000004 000016 ADD #4,16(SP) ;WRITE ERROR NUMBER IN
9570 044410 112776 000007 000016 MOVB #7,16(SP) ;USER'S ERROR CALL
9571 044416 162766 000002 000016 7$: SUB #2,16(SP)
9572 044424 105714 8$: TSTB (R4) ;DONE CLEARING??
9573 044426 100405 BMI 9$ ;YES!!
9574 044430 005003 CLR R3 ;CLEAR REMAINING STORAGE
9575 044432 112403 MOVB (R4)+,R3 ;LOCATIONS
9576 044434 060203 ADD R2,R3
9577 044436 005013 CLR (R3)
9578 044440 000771 BR 8$
9579 044442 9$:
9580 044442 012637 000006 MOV (SP)+,ERRVEC+2 ;POP STACK INTO ERRVEC+2
9581 044446 012637 000004 MOV (SP)+,ERRVEC ;POP STACK INTO ERRVEC
9582 044452 012604 MOVB (SP)+,R4 ;POP STACK INTO R4
9583 044454 012603 MOV (SP)+,R3 ;POP STACK INTO R3
9584 044456 012602 MOV (SP)+,R2 ;POP STACK INTO R2
9585 044460 012601 MOV (SP)+,R1 ;POP STACK INTO R1
9586 044462 012600 MOV (SP)+,R0 ;POP STACK INTO R0
9587 044464 000207 RTS PC ;RETURN
9588
```

9589  
9590  
9591  
9592  
9593  
9594  
9595  
9596  
9597  
9598  
9599  
9600  
9601  
9602  
9603  
9604  
9605  
9606  
9607  
9608  
9609  
9610  
9611  
9612  
9613  
9614  
9615  
9616  
9617  
9618  
9619  
9620  
9621  
9622  
9623  
9624  
9625  
9626  
9627  
9628  
9629  
9630  
9631  
9632  
9633  
9634  
9635  
9636  
9637  
9638  
9639  
9640  
9641  
9642  
9643  
9644

044466 000240  
044470 010046  
044472 010146  
044474 010246  
044476 010346  
044500 010446  
044502 013746 000004  
044506 013746 000006  
044512 013700 001276  
044516 012702 001376  
044522 012704 001533  
044526 012737 044634 000004  
044534 012737 000300 000006  
044542 016037 000010 001174  
044550 016037 000000 001176  
044556 032737 004000 001176  
044564 001007  
044566 062766 000004 000016  
044574 112776 000112 000016  
044602 000423  
044604 105714  
044606 100424  
044610 111401  
044612 042701 177700  
044616 060001  
044620 112403  
044622 042703 177700  
044626 060203  
044630 011311  
044632 000764  
044634 022626  
044636 062766 000004 000016  
044644 112776 000007 000016  
044652 162766 000002 000016

.SBTTL PUT SUBROUTINE

: THIS SUBROUTINE WRITES THE REGISTERS WHICH ARE LISTED IN THE  
: "PUT INDEX TABLE" WITH THE CONTENTS OF THE CORRESPONDING  
: LOCATION IN THE "PUT REGISTER BUFFER". THE NUMBER OF  
: REGISTERS WRITTEN IS VARIABLE; THE INDEX TABLE MUST  
: BE TERMINATED WITH A CONTROL BYTE (200) WHICH SHOULD  
: FOLLOW THE LAST ENTRY.

: SUBROUTINE CALL:

- : (1) "PUT INDEX TABLE" HAS BEEN LOADED WITH INDEX VALUES  
: OF REGISTERS TO BE WRITTEN.
- : (2) "PUT REGISTER BUFFER" CONTAINS CONTENTS OF EACH  
: REGISTER TO BE WRITTEN.
- : (3) JSR PC,PUT  
: BR ??? RETURN HERE IF NO ERROR FOUND  
: NOP RETURN HERE IF ANY ERROR FOUND  
: ERROR SUB DEFINES ERROR NUMBER  
: ???

```

PUT:  NOP
      MOV    RO,-(SP)      ;; PUSH RO ON STACK
      MOV    R1,-(SP)      ;; PUSH R1 ON STACK
      MOV    R2,-(SP)      ;; PUSH R2 ON STACK
      MOV    R3,-(SP)      ;; PUSH R3 ON STACK
      MOV    R4,-(SP)      ;; PUSH R4 ON STACK
      MOV    ERRVEC,-(SP)  ;; PUSH ERRVEC ON STACK
      MOV    ERRVEC+2,-(SP) ;; PUSH ERRVEC+2 ON STACK
      MOV    $BASE,RO
      MOV    #PUTBUF,R2
      MOV    #PUTINX,R4
      MOV    #SS,ERRVEC    ;SETUP FOR TIMEOUT
      MOV    #PR6,ERRVEC+2
1$:   MOV    RMCS2(RO),$TMP0 ;GET "NED" STATUS
      MOV    RMCS1(RO),$TMP1 ;GET "DVA" STATUS
      BIT    #DVA,$TMP1     ;DEVICE AVAILABLE??
      BNE   3$             ;YES!!
      ADD   #4,16(SP)      ;WRITE ERROR NUMBER IN
      MOVB  #112,216(SP)   ;USER'S ERROR CALL
      BR   7$
3$:   TSTB  (R4)           ;DONE??
      BMI  9$             ;YES!!
      MOVB (R4),R1        ;R1 = REGISTER ADDRESS
      BIC  #1CIDXMSK,R1   ;CLEAR ANY SIGN EXTENSION
      ADD  RO,R1
      MOVB (R4)+,R3       ;R3 = STORAGE ADDRESS
      BIC  #1CIDXMSK,R3   ;CLEAR ANY SIGN EXTENSION
      ADD  R2,R3
      MOV  (R3),(R1)      ;WRITE REGISTER
      BR   3$
5$:   CMP   (SP)+,(SP)+   ;ADJUST STACK
      ADD  #4,16(SP)      ;WRITE ERROR NUMBER IN
      MOVB #7,216(SP)    ;USER'S ERROR CALL
7$:   SUB   #2,16(SP)

```

9645			
9646	044660		
9647	044660	012637	000006
9648	044664	012637	000004
9649	044670	012604	
9650	044672	012603	
9651	044674	012602	
9652	044676	012601	
9653	044700	012600	
9654	044702	000207	
9655			

95:

```
MOV (SP)+,ERRVEC+2  
MOV (SP)+,ERRVEC  
MOV (SP)+,R4  
MOV (SP)+,R3  
MOV (SP)+,R2  
MOV (SP)+,R1  
MOV (SP)+,R0  
PC  
RTS  
:  
: POP STACK INTO ERRVEC+2  
: POP STACK INTO ERRVEC  
: POP STACK INTO R4  
: POP STACK INTO R3  
: POP STACK INTO R2  
: POP STACK INTO R1  
: POP STACK INTO R0  
: RETURN
```

```

9656 .SBTTL SIZE CLOCK SUBROUTINE
9657
9658 044704          SIZCLK:
9659 044704 013746 000004      MOV     ERRVEC -(SP)      ;; PUSH ERRVEC ON STACK
9660 044710 013746 000006      MOV     ERRVEC+2 -(SP)   ;; PUSH ERRVEC+2 ON STACK
9661 044714 012737 044752 000004      MOV     #1$,ERRVEC     ;; SET UP FOR BUS TIMEOUT
9662 044722 012737 000300 000006      MOV     #PR6,ERRVEC+2
9663 044730 012737 177546 001500      MOV     #177546,CLKADR ;; LOAD ADDRESSES FOR KW11-L
9664 044736 012737 000100 001502      MOV     #100,CLKVCT
9665 044744 005777 134530      TST     @CLKADR        ;; TEST FOR KW11-L PRESENT
9666 044750 000421              BR      3$             ;; YES - KW11-L IS PRESENT
9667 044752 022626              CMP     (SP)+,(SP)+    ;; RESTORE SP
9668 044754 012737 045004 000004 1$:      MOV     #2$,ERRVEC     ;; SET UP FOR BUS TIMEOUT
9669 044762 012737 172540 001500      MOV     #172540,CLKADR ;; LOAD ADDRESSES FOR KW11-P CLOCK
9670 044770 012737 000104 001502      MOV     #104,CLKVCT
9671 044776 005777 134476      TST     @CLKADR        ;; TEST FOR KW11-P PRESENT
9672 045002 000404              BR      3$             ;; YES - KW11-P IS PRESENT
9673 045004 022626              CMP     (SP)+,(SP)+    ;; RESTORE SP
9674 045006 062766 000002 000004 2$:      ADD     #2,4(SP)       ;; MOVE RETURN TO ERROR
9675 045014              3$:
9676 045014 012637 000006      MOV     (SP)+,ERRVEC+2 ;; POP STACK INTO ERRVEC+2
9677 045020 012637 000004      MOV     (SP)+,ERRVEC   ;; POP STACK INTO ERRVEC
9678 045024 000207              RTS     PC             ;; RETURN TO USER

```

```

9679      .SBTTL  TIMEOUT SUBROUTINE
9680
9681      ; THIS SUBROUTINE WAITS FOR GO TO RESET OR FOR A TIMEOUT GREATER THAN
9682      ; 500 MS, WHICH EVER OCCURS FIRST, AND THEN RETURNS.
9683
9684      ; CALL:  JSR      PC, TIMEOUT
9685      ;          ???
9686      ;          RETURN HERE
9687
9688      TIMEOUT:
9689      MOV      R0, -(SP)      ; PUSH R0 ON STACK
9690      MOV      R1, -(SP)      ; PUSH R1 ON STACK
9691      MOV      R2, -(SP)      ; PUSH R2 ON STACK
9692      MOV      ERRVEC, -(SP)  ; PUSH ERRVEC ON STACK
9693      MOV      ERRVEC+2, -(SP) ; PUSH ERRVEC+2 ON STACK
9694      MOV      #4$, ERRVEC    ; SETUP FOR BUS TIMEOUT - 04 TRAP
9695      MOV      #PR6, ERRVEC+2
9696      MOV      $BASE, R0      ; R0=RMO3 ADDRESS
9697      MOV      CLKADR, R1     ; R1=CLOCK ADDRESS
9698      MOV      #31, R2       ; R2=NUMBER OF CLOCK CYCLES
9699      CMP      R1, #172540    ; KW11-P CLOCK??
9700      BNE      2$            ; NO!!
9701      MOV      #1, 2(R1)     ; SET COUNTER
9702      MOV      #BIT2!BIT0, (R1) ; START COUNTER
9703
9704      1$:
9705      MOV      RMCS1(R0), -(SP) ; GET STATUS
9706      BIC      #+C<RDY!GO>, (SP)
9707      CMP      #RDY, (SP)+    ; RDY=1, GO=0??
9708      BEQ      5$            ; YES!!
9709      BIT      #BIT7, (R1)    ; TIMER DONE??
9710      BEQ      3$            ; NO!!
9711      DEC      R2            ; DEC NUMBER OF CYCLES
9712      BNE      1$            ; CONTINUE IF NOT DONE
9713      BR      5$
9714
9715      3$:
9716      CMP      (SP)+, (SP)+    ; ADJUST STACK
9717      ADD      #4, 12(SP)     ; MOVE SP TO USER'S CALL
9718      MOVB    #7, 212(SP)    ; WRITE ERROR NUMBER
9719      SUB      #2, 12(SP)
9720
9721      4$:
9722      MOV      (SP)+, ERRVEC+2 ; POP STACK INTO ERRVEC+2
9723      MOV      (SP)+, ERRVEC  ; POP STACK INTO ERRVEC
9724      MOV      (SP)+, R2      ; POP STACK INTO R2
9725      MOV      (SP)+, R1      ; POP STACK INTO R1
9726      MOV      (SP)+, R0      ; POP STACK INTO R0
9727      RTS      PC            ; RETURN TO USER

```



```

9725
9726
9727
9728
9729
9730
9731
9732
9733
9734
9735
9736
9737
9738
9739
9740
9741
9742
9743
9744
9745
9746
9747
9748
9749
9750
9751
9752
9753
9754
9755
9756
9757
9758
9759
9760
9761
9762
9763 045212
9764
9765
9766 045212 062716 000004
9767 045216 105076 000000
9768 045222 162716 000004
9769
9770
9771
9772 045226 013737 001336 001142
9773 045234 042737 177770 001142
9774 045242 013737 001234 001140
9775 045250 042737 177770 001140
9776 045256 123737 001140 001142
9777
9778 045264 001415
9779 045266 062716 000004
9780 045272 112776 000001 000000

```

```

.SBTTL PRIMARY ERROR CHECK SUBROUTINE
:THE PURPOSE OF THIS SUBROUTINE IS TO VERIFY THAT STAUS IS VALID AND
:THAT FURTHER ERROR AND STATUS CHECKING SHOULD BE PERFORMED. THE
:FOLLOWING CHECKS ARE MADE:
:
: .CURRENT UNIT IS SELECTED, I.E., THE UNIT SELECT BITS OF RMCS2
:(BITS 0-2) EQUAL THE UNIT BEING TESTED;
:
: .SELECTED UNIT IS AVAILABLE, I.E., DVA (BIT 11 OF RMCS1) IS SET
:AND NED (BIT 12 OF RMCS2) IS RESET;
:
: .LAST COMMAND WAS COMPLETED, I.E., THE MASSBUS CONTROLLER IS
:READY (BIT 7 OF RMCS1) AND THE GO BIT IS RESET (BIT 0 OF RMCS1) OR THE
:DRIVE READY BIT (BIT 7 OF RMDS) IS SET.
: .NO PARITY ERROR OCCURRED WHEN READING REMOTE REGISTERS,
:I.E., MCPE = 0.
: .NO PARITY ERROR OCCURRED WHEN WRITING REMOTE REGISTERS,
:I.E., PAR = 0, OR, PAR = DPE = 1
:
:THE SUBROUTINE ASSUMES THAT:
:
: .STATUS HAS BEEN STORED IN THE REGISTER INPUT BUFFER,
:IN PARTICULAR, RMCS1, RMCS2 AND RMDS HAVE BEEN STORED IN THEIR
:CORRESPONDING LOCATIONS OF THE "GET" BUFFER.
:
: .($UNIT) CONTAINS THE DRIVE NUMBER
:
:THE SUBROUTINE IS CALLED AS FOLLOWS:
:(1) JSR PC,PRIERR
: BR ??? RETURN HERE IF NO ERROR
: NOP RETURN HERE TO REPORT AN ERROR
: ERROR ERROR NUMBER DEFINED BY SUB
: JSR PC,@(SP)+ GO BACK TO SUB FOR MORE ERROR CHECKS
: ??? RETURN HERE IF NO MORE ERRORS
:
PRIERR:
: CLEAR USER'S ERROR CALL
: ADD #4,(SP) ; MOVE (SP) TO ERROR CALL
: CLRB @(SP) ; CLEAR ERROR NUMBER
: SUB #4,(SP) ; MOVE (SP) TO NO ERROR RETURN
:
: REPORT AN ERROR IF THE WRONG UNIT IS SELECTED
: MOV RMCS2I,$BDDAT ; CORRECT UNIT SELECTED??
: BIC #1CUNTMSK,$BDDAT
: MOV $UNIT,$GDDAT ; GOOD DATA FOR TYPEOUT
: BIC #1CUNTMSK,$GDDAT
: CMPB $GDDAT,$BDDAT ; COMPARE EXPECTED AND RECEIVED
: ; DRIVE NUMBERS
: BEQ 1$ ; YES!!
: ADD #4,(SP)
: MOVB #1,@(SP) ; ERROR 1

```

```

9781 045300 162716 000002          SUB      #2,(SP)          ;MOVE SP TO RETURN FOR ERROR
9782 045304 004736                JSR      PC,@(SP)+      ;REPORT WRONG UNIT SELECTED
9783 045306 162716 000010          SUB      #10,(SP)       ;RESTORE (SP)
9784 045312 000240                NOP
9785 045314 000137 046034          JMP      10$           ;SKIP OTHER CHECKS
9786 045320
9787
9788                                ;REPORT AN ERROR IF THE DEVICE IS NOT AVAILABLE OR IF
9789                                ;THE DEVICE IS NONEXISTANT
9790 045320 032737 004000 001326      BIT      #DVA, RMCS1I   ;DEVICE AVAILABLE??
9791 045326 001045                BNE      5$            ;YES!!
9792 045330 013737 001326 001140      MOV      RMCS1I,$GDDAT ;EXPECTED STATUS
9793 045336 052737 004000 001140      BIS      #DVA,$GDDAT
9794 045344 013737 001326 001142      MOV      RMCS1I,$BDDAT ;RECEIVED STATUS
9795 045352 062716 000004          ADD      #4,(SP)
9796 045356 112776 000002 000000      MOV      #2,@(SP)      ;ERROR #2
9797 045364 032737 010000 001336      BIT      #NED, RMCS2I   ;WAS NED SET??
9798 045372 001414                BEQ      2$            ;NO!!
9799 045374 013737 001336 001140      MOV      RMCS2I,$GDDAT ;EXPECTED STATUS
9800 045402 013737 001336 001142      MOV      RMCS2I,$BDDAT ;RECEIVED STATUS
9801 045410 042737 010000 001140      BIC      #NED,$GDDAT
9802 045416 112776 000003 000000      MOV      #3,@(SP)      ;YES - CHANGE ERROR NUMBER
9803 045424 162716 000002          SUB      #2,(SP)       ;MOVE SP TO RETURN FOR ERROR
9804 045430 004736                JSR      PC,@(SP)+      ;REPORT DEVICE NOT AVAILABLE
9805 045432 162716 000010          SUB      #10,(SP)       ;RESTORE (SP)
9806 045436 000240                NOP
9807 045440 000575                BR       10$           ;SKIP OTHER CHECKS
9808 045442
9809
9810                                ;REPORT AN ERROR IF MASSBUS CONTROLLER IS NOT READY
9811 045442 032737 000200 001326      BIT      #RDY, RMCS1I   ;CONTROLLER READY??
9812 045450 001030                BNE      7$            ;YES!!
9813 045452 013737 001326 001140      MOV      RMCS1I,$GDDAT ;EXPECTED STATUS
9814 045460 052737 000200 001140      BIS      #RDY,$GDDAT
9815 045466 042737 160001 001140      BIC      #SC!TRÉ!MCPE!GO,$GDDAT
9816 045474 013737 001326 001142      MOV      RMCS1I,$BDDAT ;RECEIVED STATUS
9817 045502 062716 000004          ADD      #4,(SP)
9818 045506 112776 000004 000000      MOV      #4,@(SP)      ;ERROR #4
9819 045514 162716 000002          SUB      #2,(SP)       ;MOVE SP TO RETURN FOR ERROR
9820 045520 004736                JSR      PC,@(SP)+      ;REPORT CONTROLLER NOT READY
9821 045522 162716 000010          SUB      #10,(SP)       ;RESTORE (SP)
9822 045526 000240                NOP
9823 045530 000541                BR       10$           ;SKIP OTHER CHECKS
9824 045532
9825
9826                                ;REPORT AN ERROR IF GO IS NOT ZERO AND DRY IS NOT ONE
9827 045532 032737 000001 001326      BIT      #GO, RMCS1I    ;GO RESET??
9828 045540 001431                BEQ      8$            ;YES!!
9829 045542 032737 000200 001340      BIT      #DRY, RMDSI    ;DRIVE READY??
9830 045550 001025                BNE      8$            ;YES!!
9831 045552 013737 001326 001140      MOV      RMCS1I,$GDDAT ;EXPECTED STATUS
9832 045560 042737 160001 001140      BIC      #SC!TRÉ!MCPE!GO,$GDDAT
9833 045566 013737 001326 001142      MOV      RMCS1I,$BDDAT ;RECEIVED STATUS
9834 045574 062716 000004          ADD      #4,(SP)
9835 045600 112776 000005 000000      MOV      #5,@(SP)      ;ERROR #5
9836 045606 162716 000002          SUB      #2,(SP)       ;MOVE SP TO RETURN FOR ERROR

```

```

9837 045612 004736          JSR    PC, @ (SP)+      ;REPORT DRIVE NOT READY
9838 045614 162716 000010  SUB    #10, (SP)       ;RESTORE (SP)
9839 045620 000240          NOP
9840 045622 000504          BR     10$
9841 045624
9842
9843
9844          ;REPORT AN ERROR IF THE RH CONTROLLER DETECTED BAD
          ;PARITY ON THE MASSBUS CONTROL BUS
9845 045624 032737 020000 001326 BIT    #MCPE, RMCS1I    ;PARITY ERROR ??
9846 045632 001425          BEQ    9$              ;NO!!
9847 045634 013737 001326 001140 MOV    RMCS1I, $GDDAT   ;EXPECTED STATUS
9848 045642 042737 160001 001140 BIC    #SC:TRÉ:MCPE:GO, $GDDAT
9849 045650 013737 001326 001142 MOV    RMCS1I, $BDDAT   ;RECEIVED STATUS
9850 045656 062716 000004          ADD    #4, (SP)        ;MOVE STACK TO USER'S ERROR
9851 045662 112776 000013 000000 MOVB   #13, @ (SP)     ;ERROR #47
9852 045670 162716 000002          SUB    #2, (SP)        ;MOVE SP TO RETURN FOR ERROR
9853 045674 004736          JSR    PC, @ (SP)+      ;REPORT ERROR VIA USER
9854 045676 162716 000010  SUB    #10, (SP)       ;RESTORE STACK
9855 045702 000240          NOP
9856 045704 000453          BR     10$
9857 045706
9858
9859          ;REPORT AN ERROR IF THE RMO3 DETECTED A CONTROL BUS PARITY ERROR
9860 045706 032737 000010 001342 BIT    #PAR, RMER1I     ;WAS THERE A PARITY ERROR??
9861 045714 001451          BEQ    11$             ;NO!!
9862 045716 032737 000010 001370 BIT    #DPE, RMER2I     ;WAS IT THE CONTROL BUS??
9863 045724 001045          BNE    11$             ;NOT SURE!!
9864 045726 032737 000010 001412 BIT    #PAR, RMER10     ;DID TEST SET PAR ??
9865 045734 001413          BEQ    93$            ;NO!!
9866 045736 010046          MOV    RO, -(SP)       ;PUSH RO ON STACK
9867 045740 012700 001533          MOV    #PUTINX, RO     ;RO POINTS TO INDEX TABLE
9868 045744 122710 000014 91$:  CMPB   #RMER1, (RO)    ;SEARCH TABLE FOR RMER1
9869 045750 001002          BNE    92$            ;
9870 045752 012600          MOV    (SP)+, RO       ;POP STACK INTO RO
9871 045754 000431          BR     11$             ;PAR WAS SET BY TEST
9872 045756 105720 92$:  TSTB   (RO)+           ;END OF TABLE??
9873 045760 100371          BPL    91$             ;NO!!
9874 045762 012600          MOV    (SP)+, RO       ;POP STACK INTO RO
9875 045764 013737 001342 001140 93$:  MOV    RMER1I, $GDDAT   ;EXPECTED STATUS
9876 045772 042737 000010 001140 BIC    #PAR, $GDDAT
9877 046000 013737 001342 001142 MOV    RMER1I, $BDDAT   ;RECEIVED STATUS
9878 046006 062716 000004          ADD    #4, (SP)        ;MOVE SP TO USER'S ERROR CALL
9879 046012 112776 000050 000000 MOVB   #50, @ (SP)     ;WRITE THE ERROR NUMBER
9880 046020 162716 000002          SUB    #2, (SP)        ;MOVE SP TO RETURN FOR ERROR
9881 046024 004736          JSR    PC, @ (SP)+      ;REPORT THE ERROR
9882 046026 162716 000010  SUB    #10, (SP)       ;MOVE SP TO NO ERROR RETURN
9883 046032 000240          NOP
9884 046034 062716 000010 10$:  ADD    #10, (SP)       ;RETURN TO ERROR
9885 046040 000240          NOP                    ;RETURN TO NO ERROR
9886 046042 000207          RTS
9887

```

9888  
9889  
9890  
9891  
9892  
9893  
9894  
9895  
9896  
9897  
9898  
9899  
9900  
9901  
9902  
9903  
9904  
9905  
9906  
9907  
9908  
9909  
9910  
9911  
9912  
9913  
9914  
9915  
9916  
9917  
9918  
9919  
9920  
9921  
9922  
9923  
9924  
9925  
9926  
9927  
9928  
9929  
9930  
9931  
9932  
9933  
9934  
9935  
9936  
9937  
9938  
9939  
9940  
9941  
9942  
9943

046044

046044	013737	001376	051704
046052	042737	177701	051704
046060	062716	000004	
046064	105076	000000	
046070	162716	000004	
046074	032737	000200	001340
046102	001024		
046104	013737	001340	001142
046112	042737	177577	001142
046120	012737	000200	001140
046126	062716	000004	
046132	112776	000010	000000
046140	162716	000002	
046144	004736		
046146	162716	000010	
046152	000240		
046154	032737	000001	001326
046162	001423		
046164	013737	001326	001142
046172	042737	177776	001142
046200	005037	001140	
046204	062716	000004	

```

.SBTTL SECONDARY ERROR CHECK SUBROUTINE
:
:THE ERROR CHECK SUBROUTINE PROVIDES DETECTION OF SECONDARY ERRORS
:SUCH AS UNEXPECTED ERRORS AND UNEXPECTED REGISTER
:CONTENTS. THESE ERRORS ARE DEEMED
:SECONDARY IN THAT THEY ARE NOT NECESSARILY ASSOCIATED WITH THE OPERATION
:BEING PERFORMED. WHEN THE SUBROUTINE IDENTIFIES SUCH AN ERROR, IT MOVES
:THE ERROR NUMBER TO THE ERROR CALL IN THE TEST ROUTINE AND THEN RETURNS
:TO THE TEST ROUTINE WHICH MAKES THE ERROR CALL. AFTER THE TEST ROUTINE
:MAKES THE ERROR CALL, IT RETURNS TO THE SUBROUTINE WHICH THEN LOOKS FOR
:OTHER ERRORS. WHEN ALL ERRORS HAVE BEEN REPORTED, THE SUBROUTINE
:RETURNS TO THE ADDRESS FOLLOWING THE SUBROUTINE CALL.
:
:CALL: JSR PC,SECERR
:      BR   ???          RETURN HERE IF NO ERROR
:      NOP          RETURN HERE TO REPORT AN ERROR
:      ERROR      ERROR NUMBER DEFINED BY SUB
:      JSR PC,@(SP)+   GO BACK TO SUB FOR MORE ERROR CHECKS
:      ???          RETURN HERE IF NO MORE ERRORS
:
:NOTE: THE SUBROUTINE ASSUMES THAT REGISTERS HAVE BEEN STORED AT THE
:INPUT REGISTER BUFFER.
SECERR:
:*****
:STORE FUNCTION CODE AND CLEAR USER'S ERROR NUMBER
MOV   RMCS10,S15$      ;STORE FUNCTION CODE
BIC   #1C<F0!F1!F2!F3!F4>,S15$
ADD   #4,(SP)          ;MOVE (SP) TO ERROR CALL
CLRB  @2(SP)           ;CLEAR ERROR NUMBER
SUB   #4,(SP)          ;MOVE (SP) TO NO ERROR RETURN
:*****
:CHECK SECONDARY ERRORS COMMON TO ALL COMMANDS
:REPORT ERROR IF DRIVE IS NOT READY, I.E. IF DRY = 0
BIT   #DRY,RMDSI      ;DRIVE READY??
BNE   S$              ;YES!!
MOV   RMDSI,$BDDAT    ;BAD DATA FOR TYPEOUT
BIC   #1CDRY,$BDDAT
MOV   #DRY,$GDDAT     ;GOOD DATA FOR TYPEOUT
ADD   #4,(SP)
MOVVB #10,@(SP)       ;ERROR NUMBER
SUB   #2,(SP)         ;MOVE SP TO RETURN FOR ERROR
JSR   PC,@(SP)+       ;REPORT NOT READY
SUB   #10,(SP)        ;RESTORE (SP) TO ERROR N
NOP
:REPORT ERROR IF GO BIT IS NOT RESET
S$: BIT   #GO,RMCS11   ;GO BIT RESET??
BEQ   10$             ;YES!!
MOV   RMCS11,$BDDAT  ;BAD DATA FOR TYPEOUT
BIC   #1CGO,$BDDAT
CLR   $GDDAT         ;GOOD DATA FOR TYPEOUT
ADD   #4,(SP)

```

```

9944 046210 112776 000011 000000      MOVB    #11,2(SP)      ;ERROR NUMBER
9945 046216 162716 000002          SUB     #2,(SP)       ;MOVE SP TO RETURN FOR ERROR
9946 046222 004736          JSR    PC,2(SP)+     ;REPORT DEVICE NOT AVAILABLE
9947 046224 162716 000010          SUB     #10,(SP)     ;RESTORE (SP)
9948 046230 000240          NOP
9949
9950      ;REPORT ERROR IF FUNCTION CODE READ FROM DEVICE IS NOT CORRECT
9951 046232 013737 001326 001142 10$:  MOV    RMCS1I,$BDDAT ;IS FUNCTION CODE CORRECT??
9952 046240 042737 177701 001142      BIC    #1C76,$BDDAT
9953 046246 013737 051704 001140      MOV    5155,$GDDAT  ;EXPECTED FUNCTION CODE
9954 046254 023737 001142 001140      CMP    $BDDAT,$GDDAT
9955 046262 001413          BEQ    15$          ;YES!!
9956 046264 062716 000004          ADD    #4,(SP)
9957 046270 112776 000012 000000      MOVB   #12,2(SP)     ;ERROR NUMBER
9958 046276 162716 000002          SUB    #2,(SP)       ;MOVE SP TO RETURN FOR ERROR
9959 046302 004736          JSR    PC,2(SP)+     ;REPORT WRONG FUNCTION CODE
9960 046304 162716 000010          SUB    #10,(SP)     ;RESTORE (SP)
9961 046310 000240          NOP
9962 046312
9963      15$:
9964      ;REPORT AN ERROR IF COMPOSITE ERROR IS SET AND NO OTHER
9965      ;ERRORS ARE SET, OR IF COMPOSITE ERROR IS NOT SET AND
9966      ;OTHER ERRORS ARE SET
9966 046312 005037 001140      CLR    $GDDAT        ;EXPECT "ERR"=0
9967 046316 005737 001342      TST    RMER1I        ;IS RMER1 =0??
9968 046322 001003          BNE    20$          ;NO!!
9969 046324 005737 001370      TST    RMER2I        ;IS RMERZ=0??
9970 046330 001403          BEQ    25$          ;YES!!
9971 046332 052737 040000 001140 20$:  BIS    #ERR,$GDDAT   ;"ERR" SHOULD BE SET
9972 046340 013737 001340 001142 25$:  MOV    RMDSI,$BDDAT
9973 046346 042737 137777 001142      BIC    #1CERR,$BDDAT
9974 046354 023737 001140 001142      CMP    $GDDAT,$BDDAT ;IS "ERR" OK??
9975 046362 001412          BEQ    30$          ;YES!!
9976 046364 062716 000004          ADD    #4,(SP)     ;MOVE SP TO USER'S ERROR
9977 046370 112776 000047 000000      MOVB   #4,2(SP)     ;WRITE ERROR NUMBER
9978 046376 162716 000002          SUB    #2,(SP)       ;MOVE SP TO ERROR RETURN
9979 046402 004736          JSR    PC,2(SP)+     ;REPORT INVALID COMP ERROR
9980 046404 162716 000010          SUB    #10,(SP)
9981
9982      ;REPORT AN ERROR IF "TRE" IS SET AND NONE OF THE BITS WHICH SET
9983      ;TRE IS SET, OR IF TRE IS NOT SET AND ONE OR MORE BITS WHICH
9984      ;SET TRE IS SET
9985 046410 005037 001140 30$:  CLR    $GDDAT        ;EXPECT "TRE" =0
9986 046414 013746 001336      MOV    RMCS2I,-(SP) ;WAS DLT, WCE, UPE, NED, NEM
9987 046420 042726 000377      BIC    #377,(SP)+   ;PGE, MXF OR MDPE SET
9988 046424 001010          BNE    35$          ;YES!!
9989 046426 032737 040000 001340      BIT    #ERR,RMDSI   ;WAS EXCEPTION RECEIVED??
9990 046434 001407          BEQ    40$          ;NO!!
9991 046436 022737 000030 051704      CMP    #SEARCH,5155 ;WAS DATA TRANSFERRED??
9992 046444 103003          BHIS  40$          ;NO!!
9993 046446 052737 040000 001140 35$:  BIS    #TRE,$GDDAT  ;"TRE" SHOULD BE SET
9994 046454 013737 001326 001142 40$:  MOV    RMCS1I,$BDDAT ;BAD DATA FOR TYPEOUT
9995 046462 042737 137777 001142      BIC    #1CTRE,$BDDAT
9996 046470 023737 001140 001142      CMP    $GDDAT,$BDDAT ;IS "TRE" OK??
9997 046476 001413          BEQ    45$          ;YES!!
9998 046500 062716 000004          ADD    #4,(SP)     ;MOVE SP TO USER'S ERROR CALL
9999 046504 112776 000014 000000      MOVB   #14,2(SP)   ;WRITE ERROR NUMBER

```

10000 046512 162716 000002  
 10001 046516 004736  
 10002 046520 162716 000010  
 10003 046524 000240  
 10004 046526  
 10005  
 10006  
 10007  
 10008  
 10009  
 10010  
 10011  
 10012  
 10013  
 10014  
 10015 046526 010046  
 10016 046530 013700 051704  
 10017 046534 016037 067254 051676  
 10018 046542 012600  
 10019  
 10020  
 10021  
 10022 046544 013737 051676 001140  
 10023 046552 032737 040000 001340  
 10024 046560 001403  
 10025 046562 052737 100000 001140  
 10026 046570 042737 077777 001140  
 10027 046576 013737 001340 001142  
 10028 046604 042737 077777 001142  
 10029 046612 023737 001140 001142  
 10030 046620 001413  
 10031 046622 062716 000004  
 10032 046626 112776 000006 000000  
 10033 046634 162716 000002  
 10034 046640 004736  
 10035 046642 162716 000010  
 10036 046646 000240  
 10037 046650  
 10038  
 10039  
 10040  
 10041 046650 013737 051676 001140  
 10042 046656 042737 177776 001140  
 10043 046664 013737 001342 001142  
 10044 046672 042737 177776 001142  
 10045 046700 023737 001140 001142  
 10046 046706 001412  
 10047 046710 062716 000004  
 10048 046714 112776 000254 000000  
 10049 046722 162716 000002  
 10050 046726 004736  
 10051 046730 162716 000010  
 10052 046734 005037 001140  
 10053  
 10054  
 10055 046740 013746 051676

```

SUB #2,(SP) ;MOVE SP TO RETURN FOR ERROR
JSR PC,@(SP)+ ;REPORT THE ERROR
SUB #10,(SP) ;RESTORE (SP)
NOP

45$:
;*****
; USING THE FUNCTION CODE TABLE, CHECK FOR THE FOLLOWING ERRORS:
; .STATUS BITS NOT SET THAT SHOULD BE SET, E.G., ATA AND ILF
; .STATUS BITS SET THAT SHOULD NOT BE SET, E.G., WCE AND ECH
; NOTE THAT SOME ERROR BITS ARE CONDITIONAL ON THE COMMAND AND OTHER
; STATUS CONDITIONS, E.G., WRITE LOCK ERROR SHOULD ONLY BE SET IF
; WRITE LOCK IS ON AND THE COMMAND IS A WRITE.

;GET AND STORE THE ENTRY FROM THE FUNCTION CODE TABLE
MOV RO,-(SP) ;PUSH RO ON STACK
MOV $15$,RO ;RO = FUNCTION CODE
MOV FNCDTB(RO),500$ ;STORE ENTRY
MOV (SP)+,RO ;POP STACK INTO RO

;REPORT AN ERROR IF AN UNEXPECTED ATTENTION OCCURRED OR IF
;ATA IS NOT SET AND SHOULD BE SET.
MOV 500$,SGDDAT ;GET EXPECTED ATA STATUS
BIT #ERR,RMSDI ;IS COMPOSITE ERROR SET ??
BEQ 50$ ;NO !!
BIS #ATA,SGDDAT ;EXPECT AN ATTENTION
BIC #+CATA,SGDDAT ;STRIP DONT CARES
MOV RMSDI,$BDDAT ;GET RECEIVED ATA
BIC #+CATA,$BDDAT ;STRIP DONT CARES
CMP SGDDAT,$BDDAT ;IS ATA OK ??
BEQ 55$ ;YES !!
ADD #4,(SP) ;MOVE SP TO USERS ERROR CALL
MOVB #6,@(SP) ;LOAD ERROR # IN CALL
SUB #2,(SP) ;MOVE SP TO ERROR RETURN
JSR PC,@(SP)+ ;REPORT ERROR
SUB #10,(SP) ;RESTORE SP
NOP

55$:
;REPORT ERROR IF ILF IS INCORRECT, I.E., IF ILF DOES NOT COMPARE
;WITH FUNCTION CODE TABLE
MOV 500$,SGDDAT ;GET EXPECTED ILF
BIC #+CILF,SGDDAT ;CLEAR ALL OTHER BITS
MOV RMERRI,$BDDAT ;GET RECEIVED ILF
BIC #+CILF,$BDDAT ;CLEAR ALL OTHER BITS
CMP SGDDAT,$BDDAT ;IS ILF OK ??
BEQ 60$ ;YES !!
ADD #4,(SP) ;MOVE SP TO USERS ERROR CALL
MOVB #254,@(SP) ;WRITE ERROR NUMBER IN CALL
SUB #2,(SP) ;MOVE SP TO ERROR RETURN
JSR PC,@(SP)+ ;REPORT ERROR AND RETURN
SUB #10,(SP) ;MOVE SP TO NO ERROR
NOP

60$:
CLR SGDDAT ;CLEAR EXPECTED STATUS

;REPORT AN ERROR IF WCE IS SET AND SHOULD NOT BE SET
MOV 500$,-(SP) ;GET WCE STATUS ENABLE

```

10056	046744	052716	137777			BIS	#1CWCE,(SP)	;SET ALL OTHER BITS
10057	046750	013737	001336	001142		MOV	RMCS2I,\$BDDAT	;RECEIVED STATUS
10058	046756	042637	001142			BIC	(SP)+,\$BDDAT	;CLEAR WCE IF ENABLED
10059	046762	001412				BEQ	90\$	;BRANCH IF WCE OK
10060	046764	062716	000004			ADD	#4,(SP)	;MOVE SP TO USER'S ERROR CALL
10061	046770	112776	000026	000000		MOVB	#26,@(SP)	;WRITE ERROR NUMBER
10062	046776	162716	000002			SUB	#2,(SP)	;MOVE SP TO ERROR RETURN
10063	047002	004736				JSR	PC,@(SP)+	;REPORT ERROR
10064	047004	162716	000010			SUB	#10,(SP)	;RESTORE ERROR
10065	047010							
10066								
10067								
10068	047010	013746	051676					
10069	047014	052716	157777					
10070	047020	013737	001342	001142				
10071	047026	042637	001142					
10072	047032	001412						
10073	047034	062716	000004					
10074	047040	112776	000164	000000				
10075	047046	162716	000002					
10076	047052	004736						
10077	047054	162716	000010					
10078	047060							
10079								
10080								
10081								
10082	047060	013746	051676					
10083	047064	032737	000100	001340				
10084	047072	001402						
10085	047074	042716	010000					
10086	047100	052716	167777					
10087	047104	013737	001370	001142				
10088	047112	042637	001142					
10089	047116	001412						
10090	047120	062716	000004					
10091	047124	112776	000165	000000				
10092	047132	162716	000002					
10093	047136	004736						
10094	047140	162716	000010					
10095	047144							
10096								
10097								
10098								
10099								
10100								
10101								
10102								
10103								
10104								
10105								
10106								
10107	047144	012746	177777					
10108	047150	032737	004000	051676				
10109	047156	001404						
10110	047160	032737	004000	001340				
10111	047166	001002						

```

90$:
;REPORT ERROR IF OPI STATUS IS SET AND SHOULD NOT BE SET
MOV 500$,-(SP) ;GET OPI STATUS ENABLE
BIS #1COP1,(SP) ;SET ALL OTHER BITS
MOV RMER1I,$BDDAT ;GET RECEIVED STATUS
BIC (SP)+,$BDDAT ;CLEAR OPI IF ENABLED
BEQ 100$ ;BRANCH IF OPI OK
ADD #4,(SP) ;MOVE SP TO USER'S ERROR CALL
MOVB #164,@(SP) ;WRITE ERROR NUMBER IN CALL
SUB #2,(SP) ;MOVE SP TO ERROR RETURN
JSR PC,@(SP)+ ;REPORT ERROR
SUB #10,(SP) ;RESTORE SP

100$:
;REPORT ERROR IF IVC IS SET AND IS NOT ENABLED OR IF IVC IS
;SET AND VV IS NOT RESET
MOV 500$,-(SP) ;GET IVC STATUS ENABLE
BIT #VV,RMDSI ;IS VV SET
BEQ 105$ ;NO !!
BIC #IVC,(SP) ;YES - IVC SHOULD BE 0
BIS #1CIVC,(SP) ;SET ALL OTHER BITS
MOV RMER2I,$BDDAT ;GET RECEIVED STATUS
BIC (SP)+,$BDDAT ;CLEAR IVC IF ENABLED
BEQ 110$ ;BRANCH IF IVC OK
ADD #4,(SP) ;MOVE SP TO USERS ERROR CALL
MOVB #165,@(SP) ;WRITE ERROR NUMBER IN CALL
SUB #2,(SP) ;MOVE SP TO ERROR RETURN
JSR PC,@(SP)+ ;REPORT ERROR
SUB #10,(SP) ;RESTORE SP TO NO ERROR

110$:
;BIT 11 (WLE) OF THE FUNCTION CODE TABLE IS THE ENABLING BIT FOR
;ALL WRITE ERRORS, I.E.,
; RMER1 - WLE, WCF
; RMER2 - DPE
; RMCS2 - UPE.
;EACH OF THESE ERRORS IS CHECKED TO SEE IF AN ERROR IS SET WHEN THE
;WRITE ERROR ENABLE BIT IS RESET.
;REPORT AN ERROR IF WLE IS SET AND WRITE ERRORS ARE NOT ENABLED, OR IF
;THE DRIVE IS NOT WRITE PROTECTED
MOV #-1,-(SP) ;ASSUME WRITE ERRORS ENABLED
BIT #WLE,500$ ;ARE WRITE ERRORS ENABLED ??
BEQ 115$ ;NO !!
BIT #WRL,RMDSI ;IS THE DRIVE WRITE PROTECTED ??
BNE 120$ ;YES !!
    
```

10112	047170	042716	004000		115\$:	BIC	#WLE (SP)	:RESET WLE ENABLE
10113	047174	013737	001342	001142	120\$:	MOV	RMER1I,\$BDDAT	:GET RECEIVED STATUS
10114	047202	042637	001142			BIC	(SP)+,\$BDDAT	:CLEAR WLE IF ENABLED
10115	047206	001412				BEQ	125\$	:BRANCH IF WLE OK
10116	047210	062716	000004			ADD	#4,(SP)	:MOVE SP TO USERS ERROR CALL
10117	047214	112776	000023	000000		MOVB	#23,@(SP)	:WRITE ERROR NUMBER IN CALL
10118	047222	162716	000002			SUB	#2,(SP)	:MOVE SP TO ERROR RETURN
10119	047226	004736				JSR	PC,@(SP)+	:REPORT ERROR AND RETURN
10120	047230	162716	000010			SUB	#10,(SP)	:RESTORE SP TO NO ERROR
10121	047234				125\$:			
10122								
10123								
10124	047234	012746	177777					:REPORT ERROR IF WCF IS SET AND WRITE ERRORS ARE NOT ENABLED
10125	047240	032737	004000	051676		MOV	#-1,-(SP)	:ASSUME WRITE ERRORS ENABLED
10126	047246	001002				BIT	#WLE,500\$	:ARE WRITE ERRORS ENABLED ??
10127	047250	042716	000040			BNE	130\$	:YES !!
10128	047254	013737	001342	001142	130\$:	BIC	#WCF (SP)	:DISABLE WCF ERROR
10129	047262	042637	001142			MOV	RMER1I,\$BDDAT	:GET RECEIVED STATUS
10130	047266	001412				BIC	(SP)+,\$BDDAT	:RESET WCF IF ENABLED
10131	047270	062716	000004			BEQ	135\$	:BRANCH IF WCF OK
10132	047274	112776	000025	000000		ADD	#4,(SP)	:MOVE SP TO USERS ERROR CALL
10133	047302	162716	000002			MOVB	#25,@(SP)	:WRITE ERROR NUMBER IN CALL
10134	047306	004736				SUB	#2,(SP)	:MOVE SP TO ERROR RETURN
10135	047310	162716	000010			JSR	PC,@(SP)+	:REPORT ERROR
10136	047314				135\$:	SUB	#10,(SP)	:RESTORE SP TO NO ERROR
10137								
10138								
10139	047314	012746	177777					:REPORT ERROR IF DPE IS SET AND WRITE ERRORS ARE NOT ENABLED
10140	047320	032737	004000	051676		MOV	#-1,-(SP)	:ASSUME WRITE ERRORS ARE ENABLED
10141	047326	001002				BIT	#WLE,500\$	:ARE WRITE ERRORS ENABLED ??
10142	047330	042716	000010			BNE	140\$	:YES !!
10143	047334	013737	001370	001142	140\$:	BIC	#DPE (SP)	:RESET DPE ENABLE
10144	047342	042637	001142			MOV	RMER2I,\$BDDAT	:GET RECEIVED STATUS
10145	047346	001412				BIC	(SP)+,\$BDDAT	:RESET DPE IF ENABLED
10146	047350	062716	000004			BEQ	145\$	:BRANCH IF DPE OK
10147	047354	112776	000040	000000		ADD	#4,(SP)	:MOVE SP TO USERS ERROR CALL
10148	047362	162716	000002			MOVB	#40,@(SP)	:WRITE ERROR NUMBER IN CALL
10149	047366	004736				SUB	#2,(SP)	:MOVE SP TO ERROR RETURN
10150	047370	162716	000010			JSR	PC,@(SP)+	:REPORT ERROR
10151	047374				145\$:	SUB	#10,(SP)	:RESTORE SP TO NO ERROR
10152								
10153								
10154	047374	012746	177777					:REPORT AN ERROR IF UPE IS SET AND WRITE ERRORS ARE NOT ENABLED
10155	047400	032737	004000	051676		MOV	#-1,-(SP)	:ASSUME WRITE ERRORS ARE ENABLED
10156	047406	001002				BIT	#WLE,500\$	:ARE WRITE ERRORS ENABLED ??
10157	047410	042716	020000			BNE	150\$	:YES !!
10158	047414	013737	001336	001142	150\$:	BIC	#UPE (SP)	:DISABLE UPE ERROR
10159	047422	042637	001142			MOV	RMCS2I,\$BDDAT	:GET RECEIVED STATUS
10160	047426	001412				BIC	(SP)+,\$BDDAT	:RESET UPE IF ENABLED
10161	047430	062716	000004			BEQ	155\$	:BRANCH IF UPE OK
10162	047434	112776	000024	000000		ADD	#4,(SP)	:MOVE SP TO USERS ERROR CALL
10163	047442	162716	000002			MOVB	#24,@(SP)	:WRITE ERROR NUMBER IN CALL
10164	047446	004736				SUB	#2,(SP)	:MOVE SP TO ERROR RETURN
10165	047450	162716	000010			JSR	PC,@(SP)+	:REPORT ERROR AND RETURN
10166	047454				155\$:	SUB	#10,(SP)	:MOVE SP TO NO ERROR
10167								



10168  
10169 047454 013746 051676  
10170 047460 052716 175777  
10171 047464 013737 001342 001142  
10172 047472 042637 001142  
10173 047476 001412  
10174 047500 062716 000004  
10175 047504 112776 000166 000000  
10176 047512 162716 000002  
10177 047516 004736  
10178 047520 162716 000010  
10179 047524

```

;REPORT AN ERROR IF IAE IS SET AND IS NOT ENABLED
MOV 500$, -(SP) ;GET IAE ENABLE
BIS #1,IAE,(SP) ;SET ALL OTHER BITS
MOV RMER1I,$BDDAT ;GET RECEIVED STATUS
BIC (SP)+,$BDDAT ;CLEAR IAE IF ENABLED
BEQ 160$ ;BRANCH IF IAE IS OK
ADD #4,(SP) ;MOVE SP TO USERS ERROR CALL
MOVB #166,2(SP) ;WRITE ERROR NUMBER
SUB #2,(SP) ;MOVE SP TO ERROR RETURN
JSR PC,2(SP)+ ;REPORT ERROR AND RETURN
SUB #10,(SP) ;MOVE SP TO NO ERROR

```

160\$:

```

;BIT 09 (AOE) OF THE FUNCTION CODE TABLE IS THE ENABLING BIT FOR
;ALL READ/WRITE ERRORS, I.E.,
RMCS1 - TRE
RMCS2 - DLT,NEM,MXF
RMDS - LBT
RMER1 - AOE

```

```

NOTE: LBT IS NOT CHECKED BECAUSE IT ONLY RESETS WHEN THE DESIRED
CYLINDER REGISTER IS WRITTEN

```

```

NOTE: AOE CANNOT BE SET IF LBT IS NOT ALSO SET

```

```

NOTE: TRE IS CHECKED AS A FUNCTION OF OTHER ERROR CONDITONS ABOVE

```

10196  
10197 047524 012746 177777  
10198 047530 032737 001000 051676  
10199 047536 001002  
10200 047540 042716 100000  
10201 047544 013737 001336 001142  
10202 047552 042637 001142  
10203 047556 001412  
10204 047560 062716 000004  
10205 047564 112776 000032 000000  
10206 047572 162716 000002  
10207 047576 004736  
10208 047600 162716 000010  
10209 047604

```

;REPORT AN ERROR IF DLT IS SET AND READ/WRITE ERRORS ARE NOT ENABLED
MOV #-1,-(SP) ;ASSUME ERRORS ARE ENABLED
BIT #AOE,500$ ;ARE ERRORS ENABLED ??
BNE 165$ ;YES !!
BIC #DLT,(SP) ;RESET DLT ENABLE
MOV RMCS2I,$BDDAT ;GET RECEIVED STATUS
BIC (SP)+,$BDDAT ;CLEAR DLT IF ENABLED
BEQ 170$ ;BRANCH IF DLT IS OK
ADD #4,(SP) ;MOVE SP TO USERS ERROR CALL
MOVB #32,2(SP) ;WRITE ERROR NUMBER IN CALL
SUB #2,(SP) ;MOVE SP TO ERROR RETURN
JSR PC,2(SP)+ ;REPORT ERROR AND RETURN
SUB #10,(SP) ;MOVE SP TO NO ERROR

```

170\$:

```

;REPORT ERROR IF NEM IS SET AND READ/WRITE ERRORS ARE NOT ENABLED

```

10211  
10212 047604 012746 177777  
10213 047610 032737 001000 051676  
10214 047616 001002  
10215 047620 042716 004000  
10216 047624 013737 001336 001142  
10217 047632 042637 001142  
10218 047636 001412  
10219 047640 062716 000004  
10220 047644 112776 000167 000000  
10221 047652 162716 000002  
10222 047656 004736  
10223 047660 162716 000010

```

MOV #-1,-(SP) ;ASSUME ERRORS ARE ENABLED
BIT #AOE,500$ ;ARE ERRORS ENABLED ??
BNE 175$ ;YES !!
BIC #NEM,(SP) ;DISABLE NEM
MOV RMCS2I,$BDDAT ;GET RECEIVED STATUS
BIC (SP)+,$BDDAT ;CLEAR NEM IF ENABLED
BEQ 180$ ;BRANCH IF NEM IS OK
ADD #4,(SP) ;MOVE SP TO USERS ERROR CALL
MOVB #167,2(SP) ;WRITE ERROR NUMBER IN CALL
SUB #2,(SP) ;MOVE SP TO ERROR RETURN
JSR PC,2(SP)+ ;REPORT ERROR AND RETURN
SUB #10,(SP) ;MOVE SP TO NO ERROR

```

```

10224 047664 180$:
10225
10226 ;REPORT ERROR IF MXF IS SET AND READ/WRITE ERRORS ARE NOT ENABLED
10227 047664 012746 177777 MOV #1-(SP) ;ASSUME ERRORS ARE ENABLED
10228 047670 032737 001000 051676 BIT #AOE,500$ ;ARE DATA ERRORS ENABLED ??
10229 047676 001002 BNE 185$ ;YES !!
10230 047700 042716 001000 BIC #MXF,(SP) ;DISABLE MXF ERROR
10231 047704 013737 001336 001142 185$: MOV RMCS2I,$BDDAT ;GET RECEIVED STATUS
10232 047712 042637 001142 BIC (SP)+,$BDDAT ;CLEAR MXF IF ENABLED
10233 047716 001412 BEQ 190$ ;BRANCH IF MXF IS OK
10234 047720 062716 000004 ADD #4,(SP) ;MOVE SP TO USERS ERROR CALL
10235 047724 112776 000033 000000 MOVB #33,2(SP) ;WRITE ERROR NUMBER IN CALL
10236 047732 162716 000002 SUB #2,(SP) ;MOVE SP TO ERROR RETURN
10237 047736 004736 JSR PC,2(SP)+ ;REPORT ERROR AND RETURN
10238 047740 162716 000010 SUB #10,(SP) ;MOVE SP TO NO ERROR
10239 047744
10240
10241 ;REPORT ERROR IF AOE IS SET AND DATA ERRORS ARE NOT ENABLED
10242 047744 012746 177777 MOV #1-(SP) ;ASSUME DATA ERRORS ARE ENABLED
10243 047750 032737 001000 051676 BIT #AOE,500$ ;ARE DATA ERRORS EABLED ??
10244 047756 001404 BEQ 191$ ;NO !!
10245 047760 032737 002000 001340 BIT #LBT,RMDSI ;IS LBT ALSO SET ??
10246 047766 001002 BNE 195$ ;YES !!
10247 047770 042716 001000 191$: BIC #AOE,(SP) ;DISABLE AOE
10248 047774 013737 001342 001142 195$: MOV RMER1I,$BDDAT ;GET RECEIVED STATUS
10249 050002 042637 001142 BIC (SP)+,$BDDAT ;CLEAR AOE IF ENABLED
10250 050006 001412 BEQ 200$ ;BRANCH IF AOE IS OK
10251 050010 062716 000004 ADD #4,(SP) ;MOVE SP TO USERS ERROR CALL
10252 050014 112776 000020 000000 MOVB #20,2(SP) ;WRITE ERROR NUMBER
10253 050022 162716 000002 SUB #2,(SP) ;MOVE SP TO ERROR RETURN
10254 050026 004736 JSR PC,2(SP)+ ;REPORT ERROR AND RETURN
10255 050030 162716 000010 SUB #10,(SP) ;MOVE SP TO NO ERROR
10256 050034
10257
10258 ;BIT 07 (HCE) OF THE FUNCTION CODE TABLE IS THE ENABLING BIT FOR
10259 ;HEADER ERRORS, I.E.,
10260 ; RMER1 - HCRC,HCE,FER
10261 ; RMER2 - BSE
10262
10263 ;RESET THE ENABLING BIT (HCE) IF HEADER COMPARE INHIBIT IS SET
10264 050034 032737 002000 001360 BIT #HCI,RMOFI ;IS HCI SET ??
10265 050042 001403 BEQ 201$ ;NO !!
10266 050044 042737 000200 051676 BIC #HCE,500$ ;YES - DISABLE ALL HEADER ERRORS
10267 050052
10268
10269 ;REPORT AN ERROR IF HCRC IS SET AND HEADER ERRORS ARE NOT ENABLED
10270 050052 012746 177777 MOV #1-(SP) ;ASSUME ERRORS ENABLED
10271 050056 032737 000200 051676 BIT #HCE,500$ ;ARE HEADER ERRORS ENABLED ??
10272 050064 001002 BNE 205$ ;YES !!
10273 050066 042716 000400 BIC #HCRC,(SP) ;DISABLE HCRC
10274 050072 013737 001342 001142 205$: MOV RMER1I,$BDDAT ;GET RECEIVED STATUS
10275 050100 042637 001142 BIC (SP)+,$BDDAT ;RESET HCRC IF ENABLED
10276 050104 001412 BEQ 210$ ;BRANCH IF HCRC IS OK
10277 050106 062716 000004 ADD #4,(SP) ;MOVE SP TO USERS ERROR CALL
10278 050112 112776 000035 000000 MOVB #35,2(SP) ;WRITE ERROR NUMBER IN CALL
10279 050120 162716 000002 SUB #2,(SP) ;MOVE SP TO ERROR RETURN

```

SECONDARY ERROR CHECK SUBROUTINE

```

10280 050124 004736          JSR    PC,2(SP)+      ;REPORT ERROR AND RETURN
10281 050126 162716 000010    SUB    #10,(SP)        ;MOVE SP TO NO ERROR
10282 050132          210$:
10283
10284          ;REPORT ERROR IF HCE IS SET AND HEADER ERRORS ARE NOT ENABLED
10285 050132 012746 177777    MOV    #-1,-(SP)      ;ASSUME ERRORS ENABLED
10286 050136 032737 000200 051676 BIT    #HCE,500$      ;ARE ERRORS ENABLED ??
10287 050144 001002          BNE    215$          ;YES !!
10288 050146 042716 000200    BIC    #HCE,(SP)      ;DISABLE HCE
10289 050152 013737 001342 001142 215$: MOV    RMER11,$BDDAT  ;GET RECEIVED STATUS
10290 050160 042637 001142    BIC    (SP)+,$BDDAT  ;CLEAR HCE IF ENABLED
10291 050164 001412          BEQ    220$          ;BRANCH IF HCE IS OK
10292 050166 062716 000004    ADD    #4,(SP)       ;MOVE SP TO USERS ERROR CALL
10293 050172 112776 000036 000000 MOVB   #36,2(SP)      ;WRITE ERROR NUMBER IN CALL
10294 050200 162716 000002    SUB    #2,(SP)       ;MOVE SP TO ERROR RETURN
10295 050204 004736          JSR    PC,2(SP)+      ;REPORT ERROR AND RETURN
10296 050206 162716 000010    SUB    #10,(SP)      ;MOVE SP TO NO ERROR
10297 050212          220$:
10298
10299          ;REPORT ERROR IF FER IS SET AND HEADER ERRORS ARE NOT ENABLED
10300 050212 012746 177777    MOV    #-1,-(SP)      ;ASSUME FER IS ENABLED
10301 050216 032737 000200 051676 BIT    #HCE,500$      ;ARE HEADER ERRORS ENABLED ??
10302 050224 001002          BNE    225$          ;YES !!
10303 050226 042716 000020    BIC    #FER,(SP)     ;DISABLE FER
10304 050232 013737 001342 001142 225$: MOV    RMER11,$BDDAT  ;GET RECEIVED STATUS
10305 050240 042637 001142    BIC    (SP)+,$BDDAT  ;RESET FER IF ENABLED
10306 050244 001412          BEQ    230$          ;BRANCH IF FER OK
10307 050246 062716 000004    ADD    #4,(SP)       ;MOVE SP TO USERS ERROR CALL
10308 050252 112776 000037 000000 MOVB   #37,2(SP)      ;WRITE ERROR NUMBER IN CALL
10309 050260 162716 000002    SUB    #2,(SP)       ;MOVE SP TO ERROR RETURN
10310 050264 004736          JSR    PC,2(SP)+      ;REPORT ERROR AND RETURN
10311 050266 162716 000010    SUB    #10,(SP)      ;MOVE SP TO NO ERROR
10312 050272          230$:
10313
10314          ;REPORT ERROR IF BSE IS SET AND HEADER ERRORS ARE NOT ENABLED
10315 050272 012746 177777    MOV    #-1,-(SP)      ;ASSUME ERRORS ENABLED
10316 050276 032737 000200 051676 BIT    #HCE,500$      ;ARE THEY ENABLED ??
10317 050304 001002          BNE    235$          ;YES !!
10318 050306 042716 100000    BIC    #BSE,(SP)     ;DISABLE BSE
10319 050312 013737 001370 001142 235$: MOV    RMER21,$BDDAT  ;GET RECEIVED STATUS
10320 050320 042637 001142    BIC    (SP)+,$BDDAT  ;CLEAR BSE IF ENABLED
10321 050324 001412          BEQ    240$          ;BRANCH IF BSE OK
10322 050326 062716 000004    ADD    #4,(SP)       ;MOVE SP TO USERS ERROR CALL
10323 050332 112776 000354 000000 MOVB   #354,2(SP)     ;WRITE ERROR NUMBER
10324 050340 162716 000002    SUB    #2,(SP)       ;MOVE SP TO ERROR RETURN
10325 050344 004736          JSR    PC,2(SP)+      ;REPORT ERROR AND RETURN
10326 050346 162716 000010    SUB    #10,(SP)      ;MOVE SP TO NO ERROR
10327 050352          240$:
10328
10329          ;BIT 06 OF THE FUNCTION CODE TABLE IS THE ENABLING BIT FOR DATA
10330          ;FIELD ERRORS, I.E.
10331          ; RMCS2 - MDPE
10332          ; RMER1 - DCK,ECH
10333          ;NOTE:
10334          ; ECH CANNOT SET UNLESS IT IS ENABLED AND ECI IS RESET AND
10335          ; DCK IS SET.

```

```

10336
10337 ;REPORT ERROR IF MDPE IS SET AND IS NOT ENABLED
10338 050352 012746 177777 MOV #1, -(SP) ;ASSUME ENABLED
10339 050356 032737 000100 CS1676 BIT #ECH, 500$ ;ARE DATA FIELD ERRORS ENABLED ??
10340 050364 001002 BNE 245$ ;YES !!
10341 050366 042716 000400 BIC #MDPE, (SP) ;DISABLE MDPE
10342 050372 013737 001336 001142 245$: MOV RMCS21, $BDDAT ;GET RECEIVED STATUS
10343 050400 042637 001142 BIC (SP)+, $BDDAT ;CLEAR MDPE IF ENABLED
10344 050404 001412 BEQ 250$ ;BRANCH IF MDPE OK
10345 050406 062716 000004 ADD #4, (SP) ;MOVE SP TO USERS ERROR CALL
10346 050412 112776 000027 000000 MOV# #27, 2(SP) ;WRITE ERROR NUMBER IN CALL
10347 050420 162716 000002 SUB #2, (SP) ;MOVE SP TO ERROR RETURN
10348 050424 004736 JSR PC, 2(SP)+ ;REPORT ERROR AND RETURN
10349 050426 162716 000010 SUB #10, (SP) ;MOVE SP TO NO ERROR
10350 050432 250$:
10351
10352 ;REPORT ERROR IF DCK IS SET AND DATA FIELD ERRORS ARE NOT ENABLED
10353 050432 012746 177777 MOV #1, -(SP) ;ASSUME ENABLED
10354 050436 032737 000100 051676 BIT #ECH, 500$ ;ARE THEY ENABLED ??
10355 050444 001002 BNE 255$ ;YES !!
10356 050446 042716 100000 BIC #DCK, (SP) ;DISABLE DCK
10357 050452 013737 001342 001142 255$: MOV RMER11, $BDDAT ;GET RECEIVED STATUS
10358 050460 042637 001142 BIC (SP)+, $BDDAT ;CLEAR DCK IF ENABLED
10359 050464 001412 BEQ 260$ ;BRANCH IF DCK IS OK
10360 050466 062716 000004 ADD #4, (SP) ;MOVE SP TO USERS ERROR CALL
10361 050472 112776 000030 000000 MOV# #30, 2(SP) ;WRITE ERROR NUMBER IN CALL
10362 050500 162716 000002 SUB #2, (SP) ;MOVE SP TO ERROR RETURN
10363 050504 004736 JSR PC, 2(SP)+ ;REPORT ERROR AND RETURN
10364 050506 162716 000010 SUB #10, (SP) ;MOVE SP TO NO ERROR
10365 050512 260$:
10366
10367 ;REPORT ERROR IF ECH IS SET AND
10368 ;DATA FIELD ERRORS ARE NOT ENABLED, OR
10369 ;ECI IS SET, OR
10370 ;DCK IS NOT SET.
10371 050512 012746 177777 MOV #1, -(SP) ;ASSUME ENABLED
10372 050516 032737 000100 051676 BIT #ECH, 500$ ;ARE ERRORS ENABLED ??
10373 050524 001410 BEQ 265$ ;NO !!
10374 050526 032737 004000 001360 BIT #ECI, RMOFI ;IS ECI SET ??
10375 050534 001004 BNE 265$ ;YES !!
10376 050536 032737 100000 001342 BIT #DCK, RMER11 ;IS DCK ALSO SET ??
10377 050544 001002 BNE 270$ ;YES !!
10378 050546 042716 000100 265$: BIC #ECH, (SP) ;DISABLE ECH
10379 050552 013737 001342 001142 270$: MOV RMER11, $BDDAT ;GET RECEIVED STATUS
10380 050560 042637 001142 BIC (SP)+, $BDDAT ;CLEAR ECH IF ENABLED
10381 050564 001412 BEQ 275$ ;BRANCH IF ECH IS OK
10382 050566 062716 000004 ADD #4, (SP) ;MOVE SP TO USERS ERROR CALL
10383 050572 112776 000031 000000 MOV# #31, 2(SP) ;WRITE ERROR NUMBER IN CALL
10384 050600 162716 000002 SUB #2, (SP) ;MOVE SP TO ERROR RETURN
10385 050604 004736 JSR PC, 2(SP)+ ;REPORT ERROR AND RETURN
10386 050606 162716 000010 SUB #10, (SP) ;MOVE SP TO NO ERROR
10387 050612 275$:
10388
10389 ;*****
10390 ;PERFORM THE REMAINING ERROR CHECKS ONLY FOR DATA TRANSFER COMMANDS
10391

```

EO1

CZRMCO RMO3/2 FCTNL TST 1  
CZRCB.P11 23-NOV-77 12:14

MACY11 30(1046) 23-NOV-77 12:25 PAGE 211  
SECONDARY ERROR CHECK SUBROUTINE

SEQ 0211

10392	050612	022737	000030	051704	CMP	#SEARCH,515\$	;WAS DATA TRANSFERRED??
10393	050620	103402			BLO	280\$	;YES!!
10394	050622	000137	051650		JMP	355\$	
10395							

```

10396 ;THE FOLLOWING STATUS CHECKS ARE FOR DATA TRANSFER COMMANDS ONLY
10397 ;REPORT ERROR IF RMWC NOT ZERO AND TRE IS ZERO
10398 050626 013737 001330 001142 280$: MOV RMWCI,$BDDAT ;WORD COUNT ZERO??
10399 050634 001421 001330 001142 BEQ 285$ ;YES
10400 050636 032737 040000 001326 BIT #TRE,RMCSI1 ;TRANSFER ERROR DETECTED??
10401 050644 001015 001330 001142 BNE 285$ ;YES!!
10402 050646 062716 000004 000000 ADD #4,(SP)
10403 050652 112776 000015 000000 MOVB #15,2(SP) ;ERROR NUMBER
10404 050660 005037 001140 000000 CLR $GDDAT ;GOOD DADA FOR TYPEOUT
10405 050664 162716 000002 000000 SUB #2,(SP) ;MOVE SP TO RETURN FOR ERROR
10406 050670 004736 000002 000000 JSR PC,2(SP)+ ;REPORT WORD COUNT NOT ZERO
10407 050672 162716 000010 000000 SUB #10,(SP) ;RESTORE (SP)
10408 050676 000240 000000 NOP
10409 ;REPORT ERROR IF RMBAI IS NOT CORRECT
10410 050700 013737 001330 001140 285$: MOV RMWCI,$GDDAT ;NUMBER OF WORDS TRANSFERRED
10411 050706 163737 001400 001140 SUB RMWCO,$GDDAT
10412 050714 006337 001140 001140 ASL $GDDAT
10413 050720 063737 001402 001140 ADD RMBAO,$GDDAT ;EXPECTED BUS ADDRESS
10414 050726 032737 000010 001336 BIT #BAI,RMCSI2 ;WAS BAI SET ??
10415 050734 001403 001402 001140 BEQ 290$ ;NO !!
10416 050736 013737 001402 001140 MOV RMBAO,$GDDAT ;ADDRESS SHOULD NOT HAVE CHANGED
10417 050744 023737 001140 001332 290$: CMP $GDDAT,RMBAI ;BUS ADDRESS OK??
10418 050752 001416 001140 001332 BEQ 295$ ;YES!!
10419 050754 013737 001332 001142 MOV RMBAI,$BDDAT ;BAD DATA FOR TYPEOUT
10420 050762 062716 000004 000000 ADD #4,(SP)
10421 050766 112776 000016 000000 MOVB #16,2(SP) ;ERROR NUMBER
10422 050774 162716 000002 000000 SUB #2,(SP) ;MOVE SP TO RETURN FOR ERROR
10423 051000 004736 000002 000000 JSR PC,2(SP)+ ;REPORT UNEXPECTED ADDRESS
10424 051002 162716 000010 000000 SUB #10,(SP) ;RESTORE (SP)
10425 051006 000240 000000 NOP
10426 ;COMPUTE NUMBER OF SECTORS TRANSFERRED
10427 051010 005046 001330 001140 295$: CLR -(SP) ;NUMBER OF SECTORS TRANSFERRED
10428 051012 013746 001330 001140 MOV RMWCI,-(SP) ;NUMBER OF WORDS TRANSFERRED
10429 051016 163716 001400 001140 SUB RMWCO,(SP)
10430 051022 012746 000400 001376 MOV #256,-(SP) ;NUMBER OF WORDS PER SECTOR
10431 051026 032737 000002 001376 BIT #BIT1,RMCSI0 ;HEADER & DATA COMMAND ??
10432 051034 001402 000402 001376 BEQ 300$ ;NO !!
10433 051036 012716 000402 001376 MOV #258,(SP) ;YES - CHANGE WORDS PER SECTOR
10434 051042 005266 000004 001376 300$: INC 4(SP) ;INCREMENT SECTOR COUNT
10435 051046 161666 000002 001376 SUB (SP),2(SP) ;SUBTRACT ONE SECTOR'S WORTH
10436 051052 003373 000002 001376 BGT 300$ ;CONTINUE IF NOT DONE
10437 051054 022626 000002 001376 CMP (SP)+,(SP)+ ;STRIP 2 FROM STACK
10438 ;COMPUTE EXPECTED SECTOR, TRACK AND CYLINDER ADDRESS FROM NUMBER OF SECTORS
10439 051056 013737 001404 051702 MOV RMDAO,510$ ;STORE ORIGINAL SECTOR
10440 051064 013737 001404 051700 MOV RMDAO,505$ ;STORE ORIGINAL TRACK
10441 051072 013737 001432 051676 MOV RMDCO,500$ ;STORE ORIGINAL CYLINDER
10442 051100 042737 177740 051702 BIC #C37,510$
10443 051106 000337 051700 SWAB 505$
10444 051112 042737 177770 051700 BIC #C7,505$
10445 051120 062637 051702 ADD (SP)+,510$
10446
10447 051124 023727 051702 000040 305$: CMP 510$,#32. ;SECTOR OVEFLOWED??
10448 051132 103420 051702 000040 BLO 315$ ;NO!!
10449 051134 023727 051702 000240 CMP 510$,#<5*32.> ;CYLINDERS WORTH??
10450 051142 103406 051702 000240 BLO 310$ ;NO!!
10451 051144 005237 051676 INC 500$ ;YES INCREMENT CYLINDER

```

```

10452 051150 162737 000240 051702      SUB      #(<5*32.),510$ ;ADJUST SECTOR
10453 051156 000762                BR      305$ ;TRY AGAIN
10454 051160 005237 051700      310$: INC      505$ ;INCREMENT TRACK
10455 051164 162737 000040 051702      SUB      #32.,510$ ;ADJUST SECTOR
10456 051172 000754                BR      305$ ;TRY AGAIN
10457
10458 051174 023727 051700 000005 315$: CMP      505$,#5 ;TRACK OVERFLOWED??
10459 051202 103406                BLO     320$ ;NO!!
10460 051204 005237 051676      INC      500$ ;INCREMENT CYLINDER
10461 051210 162737 000005 051700      SUB      #5,505$ ;ADJUST TRACK
10462 051216 000766                BR      315$ ;TRY AGAIN
10463 ;REPORT ERROR IF "LBT" IS NOT CORRECT
10464 051220 005037 001140      320$: CLR      $GDDAT ;SET GOOD DATA FOR LBT=0
10465 051224 022737 001467 051676      CMP      #823.,500$ ;SHOULD LBT BE SET??
10466 051232 101007                BHI     325$ ;NO!!
10467 051234 032737 002000 001342      BIT      #IAE,RMER11 ;WAS IAE SET ??
10468 051242 0C1003                BNE     325$ ;YES - LBT SHOULD NOT BE SET
10469 051244 012737 002000 001140      MOV      #LBT,$GDDAT ;SET GOOD DATA FOR LBT=1
10470 051252 013737 001340 001142 325$: MOV      RMDS1,$BDDAT ;BAD DATA FOR TYPEOUT
10471 051260 042737 175777 001142      BIC      #↑CLBT,$BDDAT
10472 051266 023737 001140 001142      CMP      $GDDAT,$BDDAT ;IS LBT CORRECT??
10473 051274 001413                BEQ     330$ ;YES!!
10474 051276 062716 000004      ADD      #4,(SP)
10475 051302 112776 000017 000000      MOVB    #17,2(SP) ;ERROR NUMBER
10476 051310 162716 000002      SUB      #2,(SP) ;MOVE SP TO RETURN FOR ERROR
10477 051314 004736      JSR     PC,2(SP)+ ;REPORT LBT IS WRONG
10478 051316 162716 000010      SUB      #10,(SP) ;RESTORE (SP)
10479 051322 000240      NOP
10480 ;REPORT ERROR IF "AOE" IS INCORRECT
10481 051324 005037 001140      330$: CLR      $GDDAT ;SET FOR AOE=0
10482 051330 032737 002000 001342      BIT      #IAE,RMER11 ;WAS "IAE" DETECTED??
10483 051336 001031                BNE     340$ ;YES-"AOE" SHOULD BE ZERO
10484 051340 022737 001467 051676      CMP      #823.,500$ ;SHOULD AOE BE SET??
10485 051346 101025                BHI     340$ ;NO!!
10486 051350 005737 051700      TST     505$ ;MAYBE
10487 051354 001012                BNE     335$ ;YES
10488 051356 005737 051702      TST     510$
10489 051362 001007                BNE     335$ ;YES !!
10490 051364 032737 000010 051704      BIT      #F2,515$ ;WAS THIS READ OR WRITE CHECK ??
10491 051372 001413                BEQ     340$ ;NO !!
10492 051374 005737 001330      TST     RMWCI ;WAS ALL DATA TRANSFERRED ??
10493 051400 001410                BEQ     340$ ;YES !!
10494 051402 012737 001000 001140 335$: MOV      #AOE,$GDDAT ;SET FOR AOE=1
10495 051410 005037 051700      CLR      505$ ;CLEAR EXPECTED TRACK
10496 051414 012737 000001 051702      MOV      #1,510$ ;EXPECT SECTOR=1
10497 051422 013737 001342 001142 340$: MOV      RMER11,$BDDAT ;BAD DATA FOR TYPEOUT
10498 051430 042737 176777 001142      BIC      #↑CAOE,$BDDAT
10499 051436 023737 001140 001142      CMP      $GDDAT,$BDDAT ;IS AOE CORRECT??
10500 051444 001413                BEQ     345$ ;YES!!
10501 051446 062716 000004      ADD      #4,(SP)
10502 051452 112776 000020 000000      MOVB    #20,2(SP) ;ERROR NUMBER
10503 051460 162716 000002      SUB      #2,(SP) ;MOVE SP TO RETURN FOR ERROR
10504 051464 004736      JSR     PC,2(SP)+ ;REPORT AOE IS WRONG
10505 051466 162716 000010      SUB      #10,(SP) ;RESTORE (SP)
10506 051472 000240      NOP
10507 ;REPORT ERROR IF RMDA IS NOT CORRECT

```

# H01

CZRMCO RM03/2 FCTNL TST 1  
CZRMCO.P11 23-NOV-77 12:14

MACY11 30(1046) 23-NOV-77 12:25 PAGE 214  
SECONDARY ERROR CHECK SUBROUTINE

SEQ 0214

10508	051474	032737	002000	001342	345\$:	BIT	#IAE, RMERII	; WAS THERE AN IAE ERROR ??
10509	051502	001062				BNE	355\$	; YES - DONT CHECK RMDA, RMDC
10510	051504	013737	051700	001140		MOV	505\$, \$GDDAT	; SETUP EXPECTED DISK ADDRESS
10511	051512	000337	001140			SWAB	\$GDDAT	
10512	051516	113737	051702	001140		MOVB	510\$, \$GDDAT	
10513	051524	013737	001334	001142		MOV	RMDAT, \$BDDAT	; SETUP RECEIVED DISK ADDRESS
10514	051532	023737	001140	001142		CMP	\$GDDAT, \$BDDAT	; COMPARE EXPECTED & RECEIVED
10515	051540	001413				BEQ	350\$	; BRANCH IF EQUAL
10516	051542	062716	000004			ADD	#4, (SP)	
10517	051546	112776	000021	000000		MOVB	#21, 2(SP)	; ERROR NUMBER
10518	051554	162716	000002			SUB	#2, (SP)	; MOVE SP TO RETURN FOR ERROR
10519	051560	004736				JSR	PC, 2(SP)+	; REPORT BAD DISK ADDRESS
10520	051562	162716	000010			SUB	#10, (SP)	; RESTORE (SP)
10521	051566	000240				NOP		
10522								
10523	051570	013737	051676	001140				
10524	051576	042737	176000	001140				
10525	051604	013737	001362	001142				
10526	051612	023737	001140	001142				
10527	051620	001413						
10528	051622	062716	000004					
10529	051626	112776	000022	000000				
10530	051634	162716	000002					
10531	051640	004736						
10532	051642	162716	000010					
10533	051646	000240						

350\$:

REPORT ERROR IF RMDC IS INCORRECT

MOV	500\$, \$GDDAT	; SETUP EXPECTED CYLINDER
BIC	#C1777, \$GDDAT	
MOV	RMDCI, \$BDDAT	; SETUP RECEIVED CYLINDER
CMP	\$GDDAT, \$BDDAT	; COMPARE CYLINDERS
BEQ	355\$	; BRANCH IF EQUAL
ADD	#4, (SP)	
MOVB	#22, 2(SP)	; ERROR NUMBER
SUB	#2, (SP)	; MOVE SP TO RETURN FOR ERROR
JSR	PC, 2(SP)+	; REPORT BAD CYLINDER
SUB	#10, (SP)	; RESTORE (SP)
NOP		



CZRMCB0 RM03/2 FCTNL TST 1  
CZRMCB.P11 23-NOV-77 12:14

MACY11 30(1046) 23-NOV-77 12:25 PAGE 215  
SECONDARY ERROR CHECK SUBROUTINE

SEQ 0215

10534	051650	062716	000004
10535	051654	105776	000000
10536	051660	001403	
10537	051662	062716	000004
10538	051666	000402	
10539	051670	162716	000004
10540	051674	000207	
10541			
10542	051676	000000	
10543	051700	000000	
10544	051702	000000	
10545	051704	000000	
10546			
10547			

355\$:	ADD	#4 (SP)	; MOVE (SP) TO ERROR CALL
	TSTB	3(SP)	; WAS ERROR FOUND??
	SEQ	360\$	
	ADD	#4 (SP)	; MOVE (SP) TO ERROR RETURN
	BR	365\$	
360\$:	SUB	#4 (SP)	; MOVE (SP) TO NO ERROR RETURN
365\$:	RTS	PC	
500\$:	.WORD	0	; CYLINDER
505\$:	.WORD	0	; TRACK
510\$:	.WORD	0	; SECTOR
515\$:	.WORD	0	; FUNCTION CODE

```

10548
10549
10550
10551
10552
10553
10554
10555
10556
10557
10558
10559 051706
10560
10561
10562 051706 062716 000004
10563 051712 105076 000000
10564 051716 162716 000004
10565
10566 051722 013746 000004
10567 051726 013746 000006
10568 051732 010046
10569 051734 010146
10570 051736 012737 052056 000004
10571 051744 012737 000300 000006
10572 051752 013700 001276
10573 051756 013701 001446
10574
10575
10576 051762 111160 000010
10577 051766 016037 000000 001176
10578 051774 016037 000010 001174
10579 052002 032737 010000 001174
10580 052010 001407
10581 052012 062766 000004 000010
10582 052020 112776 000111 000010
10583 052026 000422
10584 052030 032737 004000 001176 10$:
10585 052036 001021
10586 052040 062766 000004 000010
10587 052046 112776 000112 000010
10588 052054 000407
10589
10590 052056
10591
10592
10593 052056' 022626
10594 052060 062766 000004 000010
10595 052066 112776 000113 000010
10596 052074 162766 000002 000010 30$:
10597
10598 052102
10599
10600
10601
10602 052102 012601
10603 052104 012600

```

```

.SBTTL DEVICE SELECT SUBROUTINE
; THIS SUBROUTINE SELECTS THE DEVICE, GETTING THE DEVICE NUMBER FROM THE
; TEST QUEUE.
;CALL:
;(1) JSR PC,DEVSEL
;(2) BR ?? RETURN IF NO ERROR
;(3) NOP RETURN IF ERROR
;(4) ERROR ERROR DEFINED BY SUBROUTINE
DEVSEL:
;CLEAR USER'S ERROR CALL
ADD #4,(SP) ;MOVE SP TO USER'S ERROR
CLRB @2(SP) ;CLEAR LOW ORDER BYTE OF CALL
SUB #4,(SP) ;MOVE SP BACK
;SAVE USER'S INFORMATION AND SETUP REGISTERS
MOV ERRVEC,-(SP) ;;PUSH ERRVEC ON STACK
MOV ERRVEC+2,-(SP) ;;PUSH ERRVEC+2 ON STACK
MOV RO,-(SP) ;;PUSH RO ON STACK
MOV R1,-(SP) ;;PUSH R1 ON STACK
MOV #20$,ERRVEC ;SETUP FOR BUS TIMEOUT
MOV #PR6,ERRVEC+2
MOV $BASE,RO ;RO = UNIBUS ADDRESS
MOV TSTQU$,R1 ;R1 POINTS TO DEVICE NUMBER
;SELECT DEVICE AND VERIFY THAT DEVICE IS AVAILABLE
MOVB (R1),RMCS2(RO) ;WRITE UNIT SELECT BITS
MOV RMCS1(RO),STMP1 ;GET "DVA" STATUS
MOV RMCS2(RO),STMP0 ;GET "NED" STATUS
BIT #NED,STMP0 ;IS DEVICE NONEXISTENT??
BEQ 10$ ;NO!!
ADD #4,10(SP) ;MOVE SP TO USERS ERROR CALL
MOVB #111,@10(SP) ;WRITE ERROR NUMBER
BR 30$
BIT #DVA,STMP1 ;IS DEVICE AVAILABLE??
BNE 35$ ;YES!!
ADD #4,10(SP)
MOVB #112,@10(SP)
BR 30$
20$:
;HANDLE BUS TIMEOUT
CMP (SP)+,(SP)+ ;ADJUST SP
ADD #4,10(SP)
MOVB #113,@10(SP)
SUB #2,10(SP) ;MOVE SP TO RETURN IF ERROR
30$:
35$:
;RESTORE USERS DATA AND RETURN TO ADDRESS ON STACK
MOV (SP)+,R1 ;;POP STACK INTO R1
MOV (SP)+,RO ;;POP STACK INTO RO

```

K01

CZRMCB0 RMO3/2 FCTNL TST 1  
CZRMCB.P11 23-NOV-77 12:14

MACY11 30(1046) 23-NOV-77 12:25 PAGE 217  
DEVICE SELECT SUBROUTINE

SEQ 0217

10604 052106 012637 000006  
10605 052112 012637 000004  
10606 052116 000207

MOV (SP)+,ERRVEC+2  
MOV (SP)+,ERRVEC  
RTS PC  
;;POP STACK INTO ERRVEC+2  
;;POP STACK INTO ERRVEC  
;EXIT

```

10607
10608
10609
10610
10611
10612
10613
10614
10615
10616
10617
10618
10619
10620
10621
10622
10623
10624
10625 052120
10626
10627
10628 052120 000240
10629 052122 062716 000004
10630 052126 105076 000000
10631 052132 162716 000004
10632 052136 005037 053356
10633
10634
10635
10636 052142 032737 000010 001342
10637 052150 001424
10638 052152 032737 000010 001370
10639 052160 001020
10640
10641
10642 052162 005037 001140
10643 052166 013737 001342 001142
10644 052174 062716 000004
10645 052200 112776 000050 000000
10646 052206 162716 000002
10647 052212 004736
10648 052214 162716 000010
10649 052220 000437
10650
10651
10652
10653
10654 052222 012737 002000 001140
10655 052230 052737 040000 053356
10656 052236 023727 001432 001466
10657 052244 101025
10658 052246 042737 040000 053356
10659 052254 123727 001404 000037
10660 052262 101016
10661 052264 123727 001404 000035
10662 052272 101404
    
```

```

.SBTTL SEEK STATUS CHECK SUBROUTINE
; THIS SUBROUTINE VERIFIES THE RESULTS OF SEEK TESTS USING STATUS
; STORED IN THE GET BUFFER AND TEST PARAMETERS STORED IN THE PUT BUFFER.

; THE SUBROUTINE RETURNS TO THE CALLING ROUTINE IF AN ERROR IS DETECTED
; AFTER HAVING LOADED THE APPROPRIATE ERROR NUMBER IN THE "ERROR" TRAP
; OF THE CALLING ROUTINE. SEEK STATUS IS CHECKED AS FOLLOWS:

CALL:
(1) JSR PC,SEKSTS
BR ??? RETURN HERE IF NO ERROR
NOP RETURN HERE TO REPORT AN ERROR
ERROR ERROR NUMBER DEFINED BY SUB
JSR PC,@(SP)+ GO BACK TO SUB FOR MORE ERROR CHECKS
??? RETURN HERE IF NO MORE ERRORS

SEKSTS:
; CLEAR USER'S ERROR CALL
NOP
ADD #4,(SP) ; MOVE (SP) TO ERROR CALL
CLRB @(SP) ; CLEAR ERROR NUMBER
SUB #4,(SP) ; MOVE (SP) TO NO ERROR RETURN
CLR 300$ ; CLEAR ERROR FLAGS

; TEST FOR MASSBUS CONTROL BUS PARITY ERROR WHEN WRITING
; LOCAL REGISTERS, I.E. "PAR" = 1 AND "DPE" = 0
BIT #PAR,RMER1I ; WAS PARITY ERROR DETECTED??
BEQ 1$ ; NO!!
BIT #DPE,RMER2I ; WAS IT DUE TO CONTROL BUS??
BNE 1$ ; NOT SURE!!

; REPORT REGISTER PARITY ERROR VIA USER'S ERROR CALL
CLR $GDDAT ; EXPECTED STATUS
MOV RMER1I,$BDDAT ; RECEIVED STATUS
ADD #4,(SP) ; MOVE STACK TO USER'S ERROR
MOVB #50,@(SP) ; ERROR #50
SUB #2,(SP) ; MOVE SP TO RETURN FOR ERROR
JSR PC,@(SP)+
SUB #10,(SP) ; RESTORE STACK
BR 3$ ; IAE SHOULD BE ZERO

; DETERMINE THE VALUE OF "IAE" STATUS BASED ON TRACK, SECTOR AND
; CYLINDER ADDRESS USED DURING SEEK OPERATION
1$: MOV #IAE,$GDDAT ; SET UP FOR IAE = 1
BIS #SKI,300$ ; SET SKI ERROR FLAG
CMP RMDCO,#822. ; CYLINDER > 822??
BHI 3$ ; YES!!
BIC #SKI,300$ ; CLEAR SKI ERROR FLAG
CMPB RMDAO,#31. ; SECTOR > 31??
BHI 3$ ; YES!!
CMPB RMDAO,#29. ; SECTOR > 29 ??
BLOS 2$ ; NO!!
    
```

```

10663 052274 032737 010000 001430          BIT      #FMT16,RMOFO      ;30 SECTOR FORMAT??
10664 052302 001406          BEQ      3$              ;YES!!
10665 052304 123727 001405 000004 2$:      CMPB     RMDAO+1,#4.     ;TRACK >4??
10666 052312 101002          BHI      3$              ;YES!!
10667 052314 005037 001140          CLR      $GDDAT         ;"IAE" SHOULD BE 0
10668
10669          ;COMPARE EXPECTED AND RECEIVED "IAE" STATUS
10670 052320 013737 001342 001142 3$:      MOV      RMER1I,$BDDAT   ;IS IAE OK??
10671 052326 042737 175777 001142          BIC      #1CSKI,$BDDAT
10672 052334 023737 001140 001142          CMP      $GDDAT,$BDDAT
10673 052342 001004          BNE     35$             ;IAE IN ERROR
10674 052344 042737 040000 053356          BIC      #SKI,300$      ;CLEAR SKI FLAG
10675 052352 000413          BR      5$              ;GO CHECK NEXT ERROR
10676 052354
10677          35$:
;REPORT INCORRECT "IAE" STATUS VIA USER'S ERROR CALL
10678 052354 062716 000004          ADD      #4,(SP)
10679 052360 112776 000051 000000          MOVB     #51,2(SP)      ;ERROR 51
10680 052366 162716 000002          SUB      #2,(SP)        ;MOVE SP TO RETURN FOR ERROR
10681 052372 004736          JSR     PC,2(SP)+      ;REPORT INCORRECT IAE
10682 052374 162716 000010          SUB      #10,(SP)      ;RESTORE (SP)
10683 052400 000240          NOP
10684 052402
10685
10686          5$:
;REPORT ANY IVC ERROR AS
10687          ; IVC ERROR WITH VOLUME VALID ZERO
10688          ; ERRONEOUS IVC ERROR, VOLUME VALID IS SET
10689 052402 032737 010000 001370          BIT      #IVC,RMER2I    ;IVC ERROR??
10690 052410 001427          BEQ     52$             ;NO!!
10691 052412 005037 001140          CLR      $GDDAT        ;EXPECTED STATUS
10692 052416 013737 001370 001142          MOV      RMER2I,$BDDAT ;RECEIVED STATUS
10693 052424 062716 000004          ADD      #4,(SP)        ;MOVE SP TO USER'S ERROR
10694 052430 112776 000060 000000          MOVB     #60,2(SP)      ;ERROR 60 IF VV = 0
10695 052436 032737 000100 001340          BIT      #VV,RMDSI
10696 052444 001403          BEQ     51$             ;ERROR 61 IF VV = 1
10697 052446 112776 000061 000000          MOVB     #61,2(SP)      ;ERROR 61 IF VV = 1
10698 052454 162716 000002 51$:      SUB      #2,(SP)        ;MOVE SP TO RETURN FOR ERROR
10699 052460 004736          JSR     PC,2(SP)+      ;REPORT ERROR VIA USER
10700 052462 162716 000010          SUB      #10,(SP)      ;RESTORE SP
10701 052466 000240          NOP
10702
10703 052470 013737 001370 001142 52$:      MOV      RMER2I,$BDDAT   ;RECEIVED STATUS
10704 052476 042737 137777 001142          BIC      #1CSKI,$BDDAT ;CLEAR DONT CARES
10705 052504 013737 053356 001140          MOV      300$,$GDDAT    ;GET EXPECTED SKI STATUS
10706 052512 042737 137777 001140          BIC      #1CSKI,$GDDAT ;CLEAR DONT CARES
10707 052520 001417          BEQ     53$             ;BRANCH IF 0 EXPECTED
10708
10709          ;REPORT ERROR IF SKI IS NOT SET (IAE WAS NOT DETECTED)
10710 052522 032737 040000 001142          BIT      #SKI,$BDDAT    ;WAS SKI DETECTED ??
10711 052530 001032          BNE     54$             ;YES !!
10712 052532 062716 000004          ADD      #4,(SP)        ;MOVE SP TO USERS ERROR CALL
10713 052536 112776 000267 000000          MOVB     #267,2(SP)     ;WRITE ERROR NUMBER
10714 052544 162716 000002          SUB      #2,(SP)        ;MOVE SP TO ERROR RETURN
10715 052550 004736          JSR     PC,2(SP)+      ;REPORT ERROR AND RETURN
10716 052552 162716 000010          SUB      #10,(SP)      ;MOVE SP TO NO ERROR
10717 052556 000443          BR      6$              ;GO TO NEXT ERROR CHECK
10718 052560          53$:

```

```

10719
10720 ;REPORT ERROR IF SKI IS SET
10721 052560 032737 040000 001142 BIT #SKI,$BDDAT ;IS SKI SET ??
10722 052566 001413 BEQ 54$ ;NO - SKI IS OK
10723 052570 062716 000004 ADD #4,(SP) ;MOVE (SP) TO ERROR
10724 052574 112776 000054 000000 MOVB #54,2(SP) ;LOAD ERROR NUMBER
10725 052602 162716 000002 SUB #2,(SP) ;MOVE SP TO RETURN FOR ERROR
10726 052606 004736 JSR PC,2(SP)+ ;REPORT SEEK ERROR
10727 052610 162716 000010 SUB #10,(SP) ;RESTORE (SP)
10728 052614 000240 NOP
10729
10730 ;REPORT ANY DEVICE CHECK
10731 052616 032737 000200 001370 54$: BIT #DVC,RMER2I ;WAS THERE DVC DURING SEEK??
10732 052624 001420 BEQ 6$ ;NO!!
10733 052626 005037 001140 CLR $GDDAT ;EXPECTED STATUS
10734 052632 013737 001370 001142 MOV RMER2I,$BDDAT ;RECEIVED STATUS
10735 052640 062716 000004 ADD #4,(SP)
10736 052644 112776 000055 000000 MOVB #55,2(SP) ;ERROR #55
10737 052652 162716 000002 SUB #2,(SP) ;MOVE SP TO RETURN FOR ERROR
10738 052656 004736 JSR PC,2(SP)+ ;REPORT ERROR VIA USER
10739 052660 162716 000010 SUB #10,(SP) ;RESTORE SP
10740 052664 000240 NOP
10741
10742 ;REPORT ANY "OPI" ERROR AS OPI WITH MOL =0, OR OPI
10743 ;BECAUSE ON CYLINDER LATCH DIDN'T RESET
10744 052666 032737 020000 001342 6$: BIT #OPI,RMER1I ;"OPI" ERROR??
10745 052674 001427 BEQ 8$ ;NO!!
10746 052676 005037 001140 CLR $GDDAT ;EXPECTED STATUS
10747 052702 013737 001342 001142 MOV RMER1I,$BDDAT ;RECEIVED STATUS
10748 052710 062716 000004 ADD #4,(SP) ;MOVE (SP) TO ERROR
10749 052714 112776 000052 000000 MOVB #52,2(SP) ;LOAD ERROR NUMBER
10750 052722 032737 010000 001340 BIT #MOL,RMDSI ;WAS MEDIUM ON LINE??
10751 052730 001403 BEQ 7$ ;NO!!
10752 052732 112776 000053 000000 MOVB #53,2(SP) ;YES - CHANGE ERROR NUMBER
10753 052740 162716 000002 7$: SUB #2,(SP) ;MOVE SP TO RETURN FOR ERROR
10754 052744 004736 JSR PC,2(SP)+ ;REPORT "OPI" ERROR
10755 052746 162716 000010 SUB #10,(SP) ;RESTORE (SP)
10756 052752 000240 NOP
10757
10758 ;SEE IF "PIP" IS 0, AND "ATA","MOL"AND"VV" =1
10759 052754 013746 001340 8$: MOV RMDSI, -(SP)
10760 052760 042716 047677 BIC #1<ATA!PIP!MOL!VV>,(SP)
10761 052764 022726 110100 CMP #ATA!MOL!VV,(SP)+
10762 052770 001002 BNE 9$ ;ERROR IN RMDS
10763 052772 000137 053326 JMP 14$ ;RMDS IS OK
10764
10765 ;REPORT ERROR IF MOL = 0 AND OPI = 0
10766 052776 032737 010000 001340 9$: BIT #MOL,RMDSI ;IS MOL RESET??
10767 053004 001030 BNE 10$ ;NO - MOL IS SET
10768 053006 032737 020000 001342 BIT #OPI,RMER1I ;WAS OPI SET
10769 053014 001024 BNE 10$ ;YES - DONT REPORT ERROR
10770 053016 013737 001340 001140 MOV RMDSI,$GDDAT ;EXPECTED STATUS
10771 053024 052737 010000 001140 BIS #MOL,$GDDAT
10772 053032 013737 001340 001142 MOV RMDSI,$BDDAT ;RECEIVED STATUS
10773 053040 062716 000004 ADD #4,(SP)
10774 053044 112776 000062 000000 MOVB #62,2(SP)

```

```

10775 053052 162716 000002          SUB      #2,(SP)          ;MOVE SP TO RETURN FOR ERROR
10776 053056 004736                JSR      PC,@(SP)+      ;REPORT ERROR VIA USER
10777 053060 162716 000010          SUB      #10,(SP)
10778 053064 000240                NOP
10779
10780          ;REPORT AN ERROR IF "PIP" IS STIL SET AND SKI NOT SET
10781 053066 032737 020000 001340 105:  BIT      #PIP,RMSI      ;IS "PIP" STILL SET??
10782 053074 001430                BEQ      11$           ;NO!!
10783 053076 032737 040000 001370  BIT      #SKI,RMER2I    ;WAS "SKI"SET??
10784 053104 001024                BNE      11$           ;YES-DONT REPORT PIP
10785 053106 013737 001340 001140  MOV      RMSI,$GDDAT    ;EXPECTED STATUS
10786 053114 042737 020000 001142  BIC      #PIP,$DDAT
10787 053122 013737 001340 001142  MOV      RMSI,$BDDAT    ;RECEIVED STATUS
10788 053130 062716 000004                ADD      #4,(SP)       ;MOVE (SP) TO ERROR
10789 053134 112776 000056 000000  MOVB     #56,@(SP)      ;LOAD ERROR NUMBER
10790 053142 162716 000002          SUB      #2,(SP)       ;MOVE SP TO RETURN FOR ERROR
10791 053146 004736                JSR      PC,@(SP)+      ;REPORT "PIP" SET AFTER SEEK
10792 053150 162716 000010          SUB      #10,(SP)      ;RESTORE (SP)
10793 053154 000240                NOP
10794
10795          ;REPORT AN ERROR IF "ATA" IS NOT SET
10796 053156 032737 100000 001340 115:  BIT      #ATA,RMSI      ;WAS "ATA" SET ??
10797 053164 001024                BNE      13$           ;YES!!
10798 053166 013737 001340 001140  MOV      RMSI,$GDDAT    ;EXPECTED STATUS
10799 053174 052737 110600 001140  BIS      #ATA#MOL#DPR#DRY,$GDDAT
10800 053202 013737 001340 001142  MOV      RMSI,$BDDAT    ;RECEIVED STATUS
10801 053210 062716 000004                ADD      #4,(SP)       ;MOVE (SP) TO ERROR
10802 053214 112776 000057 000000  MOVB     #57,@(SP)      ;LOAD ERROR NUMBER
10803 053222 162716 000002          SUB      #2,(SP)       ;MOVE SP TO RETURN FOR ERROR
10804 053226 004736                JSR      PC,@(SP)+      ;REPORT ATTENTION NOT SET DURING
10805                                ;SEEK TEST
10806 053230 162716 000010          SUB      #10,(SP)      ;RESTORE (SP)
10807 053234 000240                NOP
10808
10809          ;REPORT ERROR IF VOLUME VALID IS RESET AND IVC IS ZERO
10810 053236 032737 000100 001340 135:  BIT      #VV,RMSI      ;IS VV = 0 ??
10811 053244 001030                BNE      14$           ;NO!!
10812 053246 032737 010000 001370  BIT      #IVC,RMER2I    ;IS IVC ALSO 0 ??
10813 053254 001024                BNE      14$           ;NO - IVC IS SET
10814 053256 013737 001340 001140  MOV      RMSI,$GDDAT    ;EXPECTED STATUS
10815 053264 052737 000100 001140  BIS      #VV,$GDDAT
10816 053272 013737 001340 001142  MOV      RMSI,$BDDAT    ;RECEIVED STATUS
10817 053300 062716 000004                ADD      #4,(SP)
10818 053304 112776 000064 000000  MOVB     #64,@(SP)      ;ERROR #64
10819 053312 162716 000002          SUB      #2,(SP)       ;MOVE SP TO RETURN FOR ERROR
10820 053316 004736                JSR      PC,@(SP)+
10821 053320 162716 000010          SUB      #10,(SP)
10822 053324 000240                NOP
10823
10824          14$:
10825          ;MODIFY THE RETURN ADDRESS IF AN ERROR WAS DETECTED
10826 053326 000240                NOP
10827 053330 062716 000004                ADD      #4,(SP)       ;MOVE (SP) TO ERROR CALL
10828 053334 105776 000000  TSTB     @(SP)          ;WAS ERROR CALLED??
10829 053340 001403                BEQ      15$           ;NO!!
10830 053342 062716 000004                ADD      #4,(SP)       ;MOVE TO ERROR RETURN

```

CZRMCB0 RM03/2 FCTNL TST 1  
CZRMCB.P11 23-NOV-77 12:14

MACY11 30(1046) 23-NOV-77 12:25 PAGE 222  
SEEK STATUS CHECK SUBROUTINE

SEQ 0222

10831 053346 000402  
10832  
10833 053350 162716 000004  
10834 053354 000207  
10835  
10836 053356 000000  
10837

BR 16\$

15\$: SUB #4, (SP)  
16\$: RTS PC

;MOVE (SP) TO NO ERROR RETURN  
;RETURN

300\$: .WORD 0

;ERROR FLAGS



```

10838
10839
10840
10841
10842
10843
10844
10845
10846
10847
10848
10849 053360
10850 053360 010046
10851 053362 010146
10852 053364 013746 000004
10853 053370 013746 000006
10854 053374 012737 053434 000004
10855 053402 012737 000300 000006
10856 053410 013700 001276
10857 053414 012760 000040 000010
10858 053422 013701 001446
10859 053426 111160 000010
10860 053432 000412
10861 053434 022626
10862 053436 062766 000004 000010
10863 053444 112776 000007 000010
10864 053452 162766 000002 000010
10865 053460
10866 053460 012637 000006
10867 053464 012637 000004
10868 053470 012601
10869 053472 012600
10870 053474 000207
10871

```

```

.SBTTL CONTROLLER CLEAR SUBROUTINE
; THIS SUBROUTINE CLEARS THE MASSBUS CONTROLLER, MASSBUS ADAPTERS,
; AND DRIVES, THEN SELECTS THE DRIVE.
CALL: JSR PC,CNTCLR          RETURN HERE IF NO ERROR FOUND
      BR   ???              RETURN HERE IF ANY ERROR FOUND
      NOP                               SUB DEFINES ERROR NUMBER
      ERROR
      ???
CNTCLR: MOV RO,-(SP)          ;; PUSH RO ON STACK
        MOV R1,-(SP)        ;; PUSH R1 ON STACK
        MOV ERRVEC,-(SP)    ;; PUSH ERRVEC ON STACK
        MOV ERRVEC+2,-(SP)  ;; PUSH ERRVEC+2 ON STACK
        MOV #10$,ERRVEC     ; SETUP FOR BUS TIMEOUT
        MOV #PR6,ERRVEC+2
        MOV $BASE,RO        ; RO=UNIBUS ADDRESS
        MOV #CLR,AMCS2(RO)  ; CLEAR MASSBUS
        MOV TSTQUE,R1
        MOVB (R1),AMCS2(RO) ; SELECT DEVICE
        BR 20$
10$:   CMP (SP)+,(SP)+      ; ADJUST STACK
        ADD #4,10(SP)      ; MOVE SP TO USER'S ERROR CALL
        MOVB #7,10(SP)    ; WRITE THE ERROR NUMBER
        SUB #2,10(SP)
20$:   MOV (SP)+,ERRVEC+2  ;; POP STACK INTO ERRVEC+2
        MOV (SP)+,ERRVEC  ;; POP STACK INTO ERRVEC
        MOV (SP)+,R1      ;; POP STACK INTO R1
        MOV (SP)+,RO      ;; POP STACK INTO RO
        RTS
        PC

```

```

10872
10873
10874
10875
10876
10877
10878
10879
10880
10881
10882
10883
10884
10885
10886
10887
10888
10889
10890
10891
10892
10893 053476
10894
10895
10896 053476 062716 000004
10897 053502 105076 000000
10898 053506 162716 000004
10899
10900 053512 013737 001326 001142
10901 053520 042737 100000 001142
10902 053526 012737 004200 001140
10903 053534 023737 001140 001142
10904 053542 001413
10905 053544 062716 000004
10906 053550 112776 000126 000000
10907 053556 162716 000002
10908 053562 004736
10909 053564 162716 000010
10910 053570 000240
10911
10912 053572 005037 001140 001142
10913 053576 013737 001332 001142
10914 053604 001413
10915 053606 062716 000004
10916 053612 112776 000127 000000
10917 053620 162716 000002
10918 053624 004736
10919 053626 162716 000010
10920 053632 000240
10921
10922 053634 013737 001336 001142
10923 053642 010146
10924 053644 005046
10925 053646 013701 001446
10926 053652 111116
10927 053654 052716 000100

```

```

.SBTTL CONTROLLER CLEAR STATUS CHECK SUBROUTINE

; THIS SUBROUTINE VERIFIES THAT THE RMO3 SUBSYSTEM IS INITIALIZED BASED ON
; STATUS STORED IN THE GET BUFFER. THIS SUBROUTINE SHOULD ONLY BE
; USED FOLLOWING A CONTROLLER CLEAR OPERATION, I.E., WRITING A 1 IN BIT
; 5 OF RMCS2, BECAUSE THE ERROR MESSAGES ARE BASED ON THAT CONDITION.

; STATUS PERTINENT TO THE DEVICE IS NOT CHECKED. IN PARTICULAR, THE
; FOLLOWING STATUS BITS ARE NOT CHECKED:
;
; ATA,ERR,PIP,MOL,WRL,LBT,PGM,VV,OM,UNS,SKI,DVC

; CALL:
; (1) JSR PC,CLRSTS          RETURN HERE IF NO ERROR
;      BR   ???              RETURN HERE TO REPORT AN ERROR
;      NOP                                ERROR NUMBER DEFINED BY SUB
;      ERROR                               GO BACK TO SUB FOR MORE ERROR CHECKS
;      JSR PC,@(SP)+          RETURN HERE IF NO MORE ERRORS
;      ???

CLRSTS:

; CLEAR USER'S ERROR CALL
; MOVE SP TO ERROR
; CLEAR ERROR NUMBER
; MOVE SP BACK TO NO ERROR
; REPORT ERROR IF RMCS1 NOT INITIALIZED
; VERIFY RMCS1
; IGNORE SPECIAL CONDITION
; EXPECT DVA & RDY
; COMPARE EXPECTED, RECEIVED
; BRANCH IF EQUAL
; MOVE SP TO USER'S ERROR CALL
; WRITE ERROR NUMBER IN CALL
; MOVE SP TO RETURN FOR ERROR
; REPORT ERROR VIA USER
; MOVE SP BACK TO NO ERROR
; REPORT ERROR IF RMBA NOT RESET
; VERIFY RMBA IS ZERO
; BRANCH IF ZERO
; MOVE SP TO USER'S ERROR CALL
; WRITE ERROR NUMBER IN CALL
; MOVE SP TO RETURN FOR ERROR
; REPORT ERROR VIA USER
; MOVE SP BACK TO NO ERROR
; REPORT ERROR IF RMCS2 NOT INITIALIZED
; VERIFY RMCS2
; PUSH R1 ON STACK
; EXPECT IR & UNIT NUMBER
; R1 = ADDRESS OF TEST QUE

```

10928	053660	012637	001140		MOV	(SP)+,\$GDDAT	
10929	053664	012601			MOV	(SP)+,R1	::POP STACK INTO R1
10930	053666	023737	001140	001142	CMP	\$GDDAT,\$BDDAT	::COMPARE EXPECTED & RECEIVED
10931	053674	001413			BEQ	9\$	::BRANCH IF EQUAL
10932	053676	062716	000004		ADD	#4,(SP)	::MOVE SP TO USER'S ERROR CALL
10933	053702	112776	000130	000000	MOVB	#130,@(SP)	::WRITE ERROR NUMBER IN CALL
10934	053710	162716	000002		SUB	#2,(SP)	::MOVE SP TO RETURN FOR ERROR
10935	053714	004736			JSR	PC,@(SP)+	::REPORT ERROR VIA USER
10936	053716	162716	000010		SUB	#10,(SP)	::MOVE SP BACK TO NO ERROR
10937	053722	000240			NOP		
10938					;REPORT ERROR IF RMER1 NOT RESET-IGNORE UNS		
10939	053724	005037	001140		9\$: CLR	\$GDDAT	::VERIFY RMER1
10940	053730	013737	001342	001142	MOV	RMER1I,\$BDDAT	
10941	053736	042737	040000	001142	BIC	#UNS,\$BDDAT	::IGNORE UNSAFE
10942	053744	001413			BEQ	13\$	::BRANCH IF ZERO
10943	053746	062716	000004		ADD	#4,(SP)	::MOVE SP TO USER'S ERROR CALL
10944	053752	112776	000131	000000	MOVB	#131,@(SP)	::WRITE ERROR NUMBER IN CALL
10945	053760	162716	000002		SUB	#2,(SP)	::MOVE SP TO RETURN FOR ERROR
10946	053764	004736			JSR	PC,@(SP)+	::REPORT ERROR VIA USER
10947	053766	162716	000010		SUB	#10,(SP)	::MOVE SP BACK TO NO ERROR
10948	053772	000240			NOP		
10949					;REPORT ERROR IF RMMR1 NOT INITIALIZED-IGNORE WC,LS,LST		
10950	053774	013737	001352	001142	13\$: MOV	RMMR1I,\$BDDAT	::VERIFY RMMR1
10951	054002	042737	000046	001142	BIC	#WC!LS!LST,\$BDDAT	::IGNORE WORD CLOCK, SCT, TRK
10952	054010	012737	000010	001140	MOV	#MWD,\$GDDAT	::EXPECT WRITE DATA BIT
10953	054016	023737	001140	001142	CMP	\$GDDAT,\$BDDAT	::COMPARE EXPECTED AND RECEIVED
10954	054024	001413			BEQ	17\$	::BRANCH IF 0
10955	054026	062716	000004		ADD	#4,(SP)	::MOVE SP TO USER'S ERROR CALL
10956	054032	112776	000133	000000	MOVB	#133,@(SP)	::WRITE ERROR NUMBER IN CALL
10957	054040	162716	000002		SUB	#2,(SP)	::MOVE SP TO RETURN FOR ERROR
10958	054044	004736			JSR	PC,@(SP)+	::REPORT ERROR VIA USER
10959	054046	162716	000010		SUB	#10,(SP)	::MOVE SP BACK TO NO ERROR
10960	054052	000240			NOP		
10961					;REPORT AN ERROR IF RMEC2 IS NOT RESET		
10962	054054	005037	001140		17\$: CLR	\$GDDAT	::EXPECT ZEROS
10963	054060	013737	001374	001142	MOV	RMEC2I,\$BDDAT	::VERIFY RMEC2=0
10964	054066	001413			BEQ	19\$	
10965	054070	062716	000004		ADD	#4,(SP)	::MOVE SP TO USER'S ERROR CALL
10966	054074	112776	000135	000000	MOVB	#135,@(SP)	::WRITE ERROR NUMBER IN CALL
10967	054102	162716	000002		SUB	#2,(SP)	::MOVE SP TO RETURN FOR ERROR
10968	054106	004736			JSR	PC,@(SP)+	::REPORT ERROR VIA USER
10969	054110	162716	000010		SUB	#10,(SP)	::MOVE SP BACK TO NO ERROR
10970	054114	000240			NOP		
10971					;REPORT ERROR IF RMMR2 NOT INITIALIZED-IGNORE RQA,RQB		
10972	054116	013737	001366	001142	19\$: MOV	RMMR2I,\$BDDAT	::VERIFY RMMR2
10973	054124	042737	140000	001142	BIC	#RQA!RQB,\$BDDAT	
10974	054132	012737	011777	001140	MOV	#TST!1777,\$GDDAT	::EXPECT TEST BIT ON
10975	054140	023737	001140	001142	CMP	\$GDDAT,\$BDDAT	
10976	054146	001413			BEQ	21\$	
10977	054150	062716	000004		ADD	#4,(SP)	::MOVE SP TO USER'S ERROR CALL
10978	054154	112776	000136	000000	MOVB	#136,@(SP)	::WRITE ERROR NUMBER IN CALL
10979	054162	162716	000002		SUB	#2,(SP)	::MOVE SP TO RETURN FOR ERROR
10980	054166	004736			JSR	PC,@(SP)+	::REPORT ERROR VIA USER
10981	054170	162716	000010		SUB	#10,(SP)	::MOVE SP BACK TO NO ERROR
10982	054174	000240			NOP		
10983					;REPORT ERROR IF RMER2 NOT RESET-IGNORE SKI,DVC		

```

10984 054176 005037 001140          21$: CLR      $GDDAT      ;EXPECT ALL ZEROS
10985 054202 013737 001370 001142  MOV      RMER2I,$BDDAT ;VERIFY RMER2
10986 054210 042737 040200 001142  BIC      #SKI!DVC,$BDDAT ;IGNORE DEVICE ERRORS
10987 054216 001413                BEQ      215$          ;BRANCH IF OTHER BITS 0
10988 054220 062716 000004                ADD      #4,(SP)       ;MOVE SP TO USER'S ERROR CALL
10989 054224 112776 000174 000000  MOVB     #174,2(SP)    ;WRITE ERROR NUMBER IN CALL
10990 054232 162716 000002                SUB      #2,(SP)      ;MOVE SP TO RETURN FOR ERROR
10991 054236 004736                JSR      PC,2(SP)+    ;REPORT ERROR VIA USER
10992 054240 162716 000010                SUB      #10,(SP)     ;MOVE SP BACK TO NO ERROR
10993 054244 000240                NOP
10994                ;REPORT ERROR IF RMD5 NOT INITIALIZED
10995 054246 013737 001340 001142  215$: MOV      RMD5I,$BDDAT ;TEST DRIVE STATUS REGISTER
10996 054254 042737 177177 001142  BIC      #1C<DRY!DPR>,$BDDAT
10997 054262 012737 000600 001140  MOV      #DPR!DRY,$GDDAT ;EXPECTED DRIVE STATUS
10998 054270 023737 001140 001142  CMP      $GDDAT,$BDDAT ;COMPARE EXPECTED & RECEIVED
10999 054276 001413                BEQ      22$          ;BRANCH IF EQUAL
11000 054300 062716 000004                ADD      #4,(SP)       ;MOVE SP TO USER'S ERROR CALL
11001 054304 112776 000134 000000  MOVB     #134,2(SP)    ;WRITE ERROR NUMBER
11002 054312 162716 000002                SUB      #2,(SP)      ;MOVE SP TO RETURN FOR ERROR
11003 054316 004736                JSR      PC,2(SP)+    ;REPORT ERROR TO USER
11004 054320 162716 000010                SUB      #10,(SP)     ;MOVE SP BACK TO NO ERROR
11005 054324 000240                NOP
11006 054326 062716 000004          22$: ADD      #4,(SP)       ;MOVE SP TO ERROR CALL
11007 054332 105776 000000                TSTB     2(SP)         ;WAS AN ERROE DETECTED??
11008 054336 001403                BEQ      23$          ;NO!!
11009 054340 062716 000004                ADD      #4,(SP)       ;YES - MOVE TO ERROR RETURN
11010 054344 000402                BR       24$
11011 054346 162716 000004          23$: SUB      #4,(SP)       ;MOVE SP TO NO ERROR RETURN
11012 054352 000240          24$: NOP
11013 054354 000207                RTS      PC

```

```

11014
11015
11016
11017
11018
11019
11020
11021
11022
11023
11024
11025
11026
11027
11028 054356
11029
11030
11031 054356 062716 000004
11032 054362 105076 000000
11033 054366 162716 000004
11034
11035
11036 054372 032737 000100 001340
11037 054400 001024
11038 054402 013737 001340 001140
11039 054410 052737 000100 001140
11040 054416 013737 001340 001142
11041 054424 062716 000004
11042 054430 112776 000155 000000
11043 054436 162716 000002
11044 054442 004736
11045 054444 162716 000010
11046 054450 000240
11047 054452
11048
11049
11050 054452 032737 010000 001340
11051 054460 001024
11052 054462 013737 001340 001140
11053 054470 052737 010000 001140
11054 054476 013737 001340 001142
11055 054504 062716 000004
11056 054510 112776 000041 000000
11057 054516 162716 000002
11058 054522 004736
11059 054524 162716 000010
11060 054530 000240
11061 054532
11062
11063
11064 054532 032737 060007 001342
11065 054540 001570
11066
11067
11068 054542 032737 040000 001342
11069 054550 001424

```

```

.SBTTL PACK ACKNOWLEDGE STATUS CHECK

; THIS SUBROUTINE CHECKS THE RESULTS OF A PACK ACKNOWLEDGE
; COMMAND USING THE STATUS STORED IN THE GET BUFFER. ERRORS ARE
; REPORTED TO THE USER VIA THE USER'S ERROR CALL.

; CALL:
; (1) JSR PC,ACKSTS
; BR ???
; NOP
; ERROR
; JSR PC,2(SP)+
; ???

RETURN HERE IF NO ERROR
RETURN HERE TO REPORT AN ERROR
ERROR NUMBER DEFINED BY SUB
GO BACK TO SUB FOR MORE ERROR CHECKS
RETURN HERE IF NO MORE ERRORS

ACKSTS:

; CLEAR USER'S ERROR CALL
ADD #4,(SP) ; MOVE SP TO ERROR CALL
CLRB 2(SP) ; CLEAR LOW ORDER BYTE
SUB #4,(SP) ; MOVE SP BACK

; REPORT AN ERROR IF "VV" IS 0
BIT #VV,RMDSI ; IS VOLUME VALID SET??
BNE 1$ ; YES!!
MOV RMDSI,$GDDAT ; EXPECTED STATUS
BIS #VV,$GDDAT
MOV RMDSI,$BDDAT ; RECEIVED STATUS
ADD #4,(SP) ; MOVE SP TO ERROR CALL
MOVB #155,2(SP) ; WRITE NUMBER IN ERROR CALL
SUB #2,(SP) ; MOVE SP TO RETURN FOR ERROR
JSR PC,2(SP)+ ; REPORT THE ERROR
SUB #10,(SP) ; MOVE SP BACK TO BRANCH
NOP

1$:
; REPORT AN ERROR IF "MOL" IS 0
BIT #MOL,RMDSI ; IS MOL SET??
BNE 2$ ; YES!!
MOV RMDSI,$GDDAT ; EXPECTED STATUS
BIS #MOL,$GDDAT
MOV RMDSI,$BDDAT ; RECEIVED STATUS
ADD #4,(SP) ; MOVE SP TO ERROR CALL
MOVB #41,2(SP) ; WRITE NUMBER OF ERROR IN CALL
SUB #2,(SP) ; MOVE SP TO RETURN FOR ERROR
JSR PC,2(SP)+ ; REPORT TH ERROR
SUB #10,(SP) ; MOVE SP TO BRANCH
NOP

2$:
; SEE IF "UNS","OPI" "RMR" "ILR" OR "ILF" IS SET
BIT #UNS!OPI!RMR!ILR!ILF,RMER1I
BEQ 7$

; REPORT AN ERROR IF "UNS" IS SET
BIT #UNS,RMER1I ; WAS UNS SET??
BEQ 3$ ; NO!!

```

11070	054552	013737	001342	001142	MOV	RMER11,\$BDDAT	;RECEIVED STATUS
11071	054560	013737	001342	001140	MOV	RMER11,\$GDDAT	;EXPECTED STATUS
11072	054566	042737	040000	001140	BIC	#UNS,\$GDDAT	
11073	054574	062716	000004		ADD	#4,(SP)	;MOVE SP TO ERROR CALL
11074	054600	112776	000042	000000	MOVSB	#42,@(SP)	;WRITE NUMBER OF ERROR IN CALL
11075	054606	162716	000002		SUB	#2,(SP)	;MOVE SP TO RETURN FOR ERROR
11076	054612	004736			JSR	PC,@(SP)+	;REPORT THE ERROR VIA USER
11077	054614	162716	000010		SUB	#10,(SP)	;MOVE SP TO NO ERROR RETURN
11078	054620	000240			NOP		
11079	054622						
11080							
11081							
11082	054622	032737	020000	001342	;REPORT ANY OPI ERROR		
11083	054630	001424			BIT	#OPI,RMER11	;WAS OPI SET ??
11084	054632	013737	001342	001142	BEQ	4\$	;NO!!
11085	054640	013737	001342	001140	MOV	RMER11,\$BDDAT	;RECEIVED STATUS
11086	054646	042737	020000	001140	MOV	RMER11,\$GDDAT	;EXPECTED STATUS
11087	054654	062716	000004		BIC	#OPI,\$GDDAT	
11088	054660	112776	000043	000000	ADD	#4,(SP)	;MOVE SP TO ERROR CALL
11089	054666	162716	000002		MOVSB	#43,@(SP)	;WRITE NUMBER OF ERROR IN CALL
11090	054672	004736			SUB	#2,(SP)	;MOVE SP TO RETURN FOR ERROR
11091	054674	162716	000010		JSR	PC,@(SP)+	;REPORT THE ERROR VIA USER
11092	054700	000240			SUB	#10,(SP)	;MOVE SP TO NO ERROR RETURN
11093	054702				NOP		
11094							
11095							
11096	054702	032737	000004	001342	;REPORT ANY RMR ERROR		
11097	054710	001424			BIT	#RMR,RMER11	;WAS RMR SET??
11098	054712	013737	001342	001142	BEQ	5\$	;NO!!
11099	054720	013737	001342	001140	MOV	RMER11,\$BDDAT	;RECEIVED STATUS
11100	054726	042737	000004	001140	MOV	RMER11,\$GDDAT	;EXPECTED STATUS
11101	054734	062716	000004		BIC	#RMR,\$GDDAT	
11102	054740	112776	000044	000000	ADD	#4,(SP)	;MOVE SP TO ERROR CALL
11103	054746	162716	000002		MOVSB	#44,@(SP)	;WRITE NUMBER OF ERROR IN CALL
11104	054752	004736			SUB	#2,(SP)	;MOVE SP TO RETURN FOR ERROR
11105	054754	162716	000010		JSR	PC,@(SP)+	;REPORT THE ERROR VIA USER
11106	054760	000240			SUB	#10,(SP)	;MOVE SP TO NO ERROR RETURN
11107	054762				NOP		
11108							
11109							
11110	054762	032737	000002	001342	;REPORT ANY ILR ERROR		
11111	054770	001424			BIT	#ILR,RMER11	;WAS ILR SET??
11112	054772	013737	001342	001142	BEQ	6\$	;NO!!
11113	055000	013737	001342	001140	MOV	RMER11,\$BDDAT	;RECEIVED STATUS
11114	055006	042737	000002	001140	MOV	RMER11,\$GDDAT	;EXPECTED STATUS
11115	055014	062716	000004		BIC	#ILR,\$GDDAT	
11116	055020	112776	000045	000000	ADD	#4,(SP)	;MOVE SP TO ERROR CALL
11117	055026	162716	000002		MOVSB	#45,@(SP)	;WRITE NUMBER OF ERROR IN CALL
11118	055032	004736			SUB	#2,(SP)	;MOVE SP TO RETURN FOR ERROR
11119	055034	162716	000010		JSR	PC,@(SP)+	;REPORT THE ERROR VIA USER
11120	055040	000240			SUB	#10,(SP)	;MOVE SP TO NO ERROR RETURN
11121	055042				NOP		
11122							
11123							
11124	055042	032737	000001	001342	;REPORT ANY ILF ERROR		
11125	055050	001424			BIT	#ILF,RMER11	;WAS ILF SET??
					BEQ	7\$	;NO!!

11126	055052	013737	001342	001142	MOV	RMER11,\$BDDAT	;RECEIVED STATUS
11127	055060	013737	001342	001140	MOV	RMER11,\$GDDAT	;EXPECTED STATUS
11128	055066	042737	000001	001140	BIC	#1LF,\$GDDAT	
11129	055074	062716	000004		ADD	#4,(SP)	;MOVE SP TO ERROR CALL
11130	055100	112776	000046	000000	MOVB	#46,@(SP)	;WRITE NUMBER OF ERROR IN CALL
11131	055106	162716	000002		SUB	#2,(SP)	;MOVE SP TO RETURN FOR ERROR
11132	055112	004736			JSR	PC,@(SP)+	;REPORT THE ERROR VIA USER
11133	055114	162716	000010		SUB	#10,(SP)	;MOVE SP TO NO ERROR RETURN
11134	055120	000240			NOP		
11135	055122						
11136							
11137							
11138	055122	062716	000004		ADD	#4,(SP)	;MOVE SP TO ERROR CALL
11139	055126	105776	000000		TSTB	@(SP)	;WAS ERROR FOUND??
11140	055132	001403			BEQ	8\$	;NO!!
11141	055134	062716	000004		ADD	#4,(SP)	;YES - MOVE TO ERROR RETURN
11142	055140	000402			BR	9\$	
11143	055142	162716	000004		SUB	#4,(SP)	;MOVE SP TO NO ERROR RETURN
11144	055146	000240			NOP		
11145	055150	000207			RTS	PC	
11146							

7\$:

;AUGMENT RETURN ADDRESS IF ERROR WAS FOUND

8\$:  
9\$:

```

11147
11148
11149
11150
11151
11152
11153
11154
11155
11156
11157
11158
11159
11160
11161 055152
11162
11163
11164 055152 062716 000004
11165 055156 105076 000000
11166 055162 162716 000004
11167
11168
11169
11170 055166 032737 022011 001342
11171 055174 001553
11172
11173
11174
11175 055176 032737 000010 001342
11176 055204 001430
11177 055206 032737 000010 001370
11178 055214 001024
11179 055216 013737 001342 001140
11180 055224 042737 000010 001140
11181 055232 013737 001342 001142
11182 055240 062716 000004
11183 055244 112776 000050 000000
11184 055252 162716 000002
11185 055256 004736
11186 055260 162716 000010
11187 055264 000240
11188 055266
11189
11190
11191 055266 032737 000001 001342
11192 055274 001424
11193 055276 013737 001342 001140
11194 055304 042737 000001 001140
11195 055312 013737 001342 001142
11196 055320 062716 000004
11197 055324 112776 000071 000000
11198 055332 162716 000002
11199 055336 004736
11200 055340 162716 000010
11201 055344 000240
11202 055346

```

```

.SBTTL RECALIBRATE STATUS CHECK SUBROUTINE
;THIS SUBROUTINE CHECKS THE RESULTS OF A RECALIBRATE OPERATION
;USING THE STATUS STORED IN THE GET BUFFER.
;CALL:
(1) JSR PC,RCLSTS ;CALL SUBROUTINE
BR ??? ;RETURN HERE IF NO ERROR
NOP ;RETURN HERE TO REPORT AN ERROR
ERROR ;ERROR NUMBER DEFINED BY SUB
JSR PC,@(SF)+ ;GO BACK TO SUB FOR MORE ERROR CHECKS
??? ;RETURN HERE IF NO MORE ERRORS

RCLSTS:
;CLEAR USER'S ERROR NUMBER
ADD #4,(SP)
CLRB @(SP) ;CLEAR USER'S ERROR CALL
SUB #4,(SP) ;MOVE SP BACK TO BRANCH

;SEE IF "PAR" OR "ILF" OR "OPI" OR "IAE" IS SET
BIT #OPI!PAR!ILF!IAE,RMER1I
BEQ 4$ ;NONE ARE SET - GO TO NEXT CHECK

;REPORT ANY MASSBUS CONTROL BUS PARITY ERROR, I.E.,
;"PAR" = 1 AND "DPE" = 0
BIT #PAR,RMER1I ;WAS "PAR" SET??
BEQ 1$ ;NO!!
BIT #DPE,RMER2I ;WAS "DPE" SET??
BNE 1$ ;YES - NOT A REGISTER ERROR
MOV RMER1I,$GDDAT ;EXPECTED STATUS
BIC #PAR,$GDDAT
MOV RMER1I,$BDDAT ;RECEIVED STATUS
ADD #4,(SP) ;MOVE SP TO USER'S ERROR CALL
MOVSB #50,@(SP) ;WRITE ERROR NUMBER IN CALL
SUB #2,(SP) ;MOVE SP TO RETURN FOR ERROR
JSR PC,@(SP)+ ;GO REPORT ERROR
SUB #10,(SP) ;MOVE SP BACK TO BRANCH
NOP

1$:
;REPORT ANY "ILF" ERROR
BIT #ILF,RMER1I ;WAS "ILF" SET??
BEQ 2$ ;NO!!
MOV RMER1I,$GDDAT ;EXPECTED STATUS
BIC #ILF,$GDDAT
MOV RMER1I,$BDDAT ;RECEIVED STATUS
ADD #4,(SP) ;MOVE SP TO USER'S ERROR CALL
MOVSB #71,@(SP) ;WRITE ERROR NUMBER IN CALL
SUB #2,(SP) ;MOVE SP TO RETURN FOR ERROR
JSR PC,@(SP)+ ;REPORT ERROR VIA USER
SUB #10,(SP) ;MOVE SP BACK TO BRANCH
NOP

2$:

```



```

11203
11204 ;REPORT ANY "OPI" ERROR AS
11205 . OPI DUE TO "MOL" = 0
11206 . OPI BECAUSE ON CYLINDER LATCH DIDN'T RESET
11207 055346 032737 020000 001342 BIT #OPI,RMER1I ;WAS OPI SET??
11208 055354 001433 BEQ 3IS ;NO!!
11209 055356 013737 001342 001140 MOV RMER1I,$GDDAT ;EXPECTED STATUS
11210 055364 042737 020000 001140 BIC #OPI,$GDDAT
11211 055372 013737 001342 001142 MOV RMER1I,$BDDAT ;RECEIVED STATUS
11212 055400 062716 000004 ADD #4,(SP) ;MOVE SP TO USER'S ERROR CALL
11213 055404 112776 000072 000000 MOVB #72,(SP) ;WRITE ERROR NUMBER IN USER'S CALL
11214 055412 032737 010000 001340 BIT #MOL,RMDSI ;WAS "MOL" = 0??
11215 055420 001403 BEQ 3S ;YES!!
11216 055422 112776 000073 000000 MOVB #73,(SP) ;NO - CHANGE ERROR NUMBER
11217 055430 162716 000002 3S: SUB #2,(SP) ;MOVE SP TO RETURN FOR ERROR
11218 055434 004736 JSR PC,(SP)+ ;REPORT ERROR VIA USER
11219 055436 162716 000010 SUB #10,(SP) ;MOVE SP BACK TO BRANCH
11220 055442 000240 NOP
11221 055444 3IS:
11222
11223 ;REPORT AN ERROR IF "IAE" IS SET
11224 055444 032737 002000 001342 BIT #IAE,RMER1I ;IS "IAE" SET??
11225 055452 001424 BEQ 4S ;NO!!
11226 055454 013737 001342 001140 MOV RMER1I,$GDDAT ;EXPECTED STATUS
11227 055462 042737 002000 001140 BIC #IAE,$GDDAT
11228 055470 013737 001342 001142 MOV RMER1I,$BDDAT ;RECEIVED STATUS
11229 055476 062716 000004 ADD #4,(SP) ;MOVE SP TO ERROR CALL
11230 055502 112776 000070 000000 MOVB #70,(SP) ;WRITE ERROR NUMBER IN USER'S CALL
11231 055510 162716 000002 SUB #2,(SP) ;MOVE SP TO RETURN FOR ERROR
11232 055514 004736 JSR PC,(SP)+ ;REPORT ERROR
11233 055516 162716 000010 SUB #10,(SP) ;MOVE SP BACK TO NO ERROR RETURN
11234 055522 000240 NOP
11235 055524 4S:
11236
11237 ;SEE IF "SKI" OR "IVC" OR "DVC" IS SET
11238 055524 032737 050200 001370 BIT #SKI!IVC!DVC,RMER2I
11239 055532 001517 BEQ 8S ;NONE OF THE BITS ARE SET
11240
11241
11242 ;REPORT ANY "IVC" ERROR AS
11243 . IVC WITH VV = 0
11244 . ERRONEOUS IVC ERROR
11245 055534 032737 010000 001370 BIT #IVC,RMER2I ;WAS IVC SET??
11246 055542 001433 BEQ 6S ;NO!!
11247 055544 013737 001370 001140 MOV RMER2I,$GDDAT ;EXPECTED STATUS
11248 055552 042737 010000 001140 BIC #IVC,$GDDAT
11249 055560 013737 001370 001142 MOV RMER2I,$BDDAT ;RECEIVED STATUS
11250 055566 062716 000004 ADD #4,(SP) ;MOVE SP TO USER'S ERROR CALL
11251 055572 112776 000074 000000 MOVB #74,(SP) ;WRITE ERROR NUMBER IN CALL
11252 055600 032737 000100 001340 BIT #VV,RMDSI ;WAS VV = 0??
11253 055606 001403 BEQ 5S ;YES!!
11254 055610 112776 000075 000000 MOVB #75,(SP) ;NO - CHANGE ERROR NUMBER
11255 055616 162716 000002 5S: SUB #2,(SP) ;MOVE SP TO RETURN FOR ERROR
11256 055622 004736 JSR PC,(SP)+ ;REPORT ERROR VIA USER
11257 055624 162716 000010 SUB #10,(SP) ;MOVE SP BACK TO BRANCH
11258 055630 000240 NOP

```

```

11259 055632
11260
11261
11262 055632 032737 040000 001370
11263 055640 001424
11264 055642 013737 001370 001140
11265 055650 042737 040000 001140
11266 055656 013737 001370 001142
11267 055664 062716 000004
11268 055670 112776 000076 000000
11269 055676 162716 000002
11270 055702 004736
11271 055704 162716 000010
11272 055710 000240
11273 055712
11274
11275
11276 055712 032737 000200 001370
11277 055720 001424
11278 055722 013737 001370 001140
11279 055730 042737 000200 001140
11280 055736 013737 001370 001142
11281 055744 062716 000004
11282 055750 112776 000077 000000
11283 055756 162716 000002
11284 055762 004736
11285 055764 162716 000010
11286 055770 000240
11287 055772
11288
11289
11290 055772 013746 001340
11291 055776 042716 047676
11292 056002 022726 110100
11293 056006 001002
11294 056010 000137 056424
11295 056014
11296
11297
11298
11299 056014 032737 010000 001340
11300 056022 001030
11301 056024 032737 020000 001342
11302 056032 001024
11303 056034 013737 001340 001140
11304 056042 052737 010000 001140
11305 056050 013737 001340 001142
11306 056056 062716 000004
11307 056062 112776 000100 000000
11308 056070 162716 000002
11309 056074 004736
11310 056076 162716 000010
11311 056102 000240
11312 056104
11313
11314

6$:
;REPORT ANY "SKI" ERROR
BIT #SKI,RMER2I ;WAS SKI SET??
BEQ 9$ ;NO!!
MOV RMER2I,$GDDAT ;EXPECTED STATUS
BIC #SKI,$GDDAT
MOV RMER2I,$BDDAT ;RECEIVED STATUS
ADD #4,(SP) ;MOVE SP TO USER'S ERROR CALL
MOVB #76,(SP) ;WRITE ERROR NUMBER
SUB #2,(SP) ;MOVE SP TO RETURN FOR ERROR
JSR PC,(SP)+ ;REPORT ERROR VIA USER
SUB #10,(SP) ;MOVE SP TO BRANCH

7$:
;REPORT ANY "DVC" ERROR
BIT #DVC,RMER2I ;WAS "DVC" SET??
BEQ 8$ ;NO!!
MOV RMER2I,$GDDAT ;EXPECTED STATUS
BIC #DVC,$GDDAT
MOV RMER2I,$BDDAT ;RECEIVED STATUS
ADD #4,(SP) ;MOVE SP TO USER'S ERROR CALL
MOVB #77,(SP) ;WRITE ERROR NUMBER
SUB #2,(SP) ;MOVE SP TO RETURN FOR ERROR
JSR PC,(SP)+ ;REPORT ERROR VIA USER
SUB #10,(SP) ;MOVE SP TO USER'S BRANCH

8$:
;SEE IF "PIP" AND "OM" ARE 0, AND "ATA" "MOL" AND "VV" ARE 1
MOV RMDSI,(SP) ;PUT RMDI ON STACK
BIC #C<PIP!MOL!VV!OM!ATA>,(SP)
CMP #ATA!MOL!VV,(SP)+
BNE 85$
JMP 13$

85$:
;REPORT AN ERROR IF MOL = 0 AND OPI = 0, I.E., MEDIUM WENT OFF
;LINE AFTER RECALIBRATE WAS INITIATED
BIT #MOL,RMDSI ;DID MOL DROP??
BNE 9$ ;NO!!
BIT #OPI,RMER1I ;WAS OPI ERROR REPORTED??
BNE 9$ ;YES - DON'T REPORT MOL=0
MOV RMDSI,$GDDAT ;EXPECTED STATUS
BIS #MOL,$GDDAT
MOV RMDSI,$BDDAT ;RECEIVED STATUS
ADD #4,(SP) ;MOVE SP TO USER'S ERROR CALL
MOVB #100,(SP) ;WRITE ERROR NUMBER
SUB #2,(SP) ;MOVE SP TO RETURN FOR ERROR
JSR PC,(SP)+ ;REPORT ERROR VIA USER
SUB #10,(SP) ;MOVE SP BACK TO USER'S BRANCH

9$:
;REPORT AN ERROR IF "VV" = 0 AND "IVC" = 0

```

11315	056104	032737	000100	001340	BIT	#VV,RMDSI	; DID "VV" DROP??
11316	056112	001030			BNE	10\$	; NO!!
11317	056114	032737	010000	001370	BIT	#IVC,RMER2I	; WAS THERE A IVC ERROR??
11318	056122	001024			BNE	10\$	; YES - DONT REPORT VV=0
11319	056124	013737	001340	001140	MOV	RMDSI,\$GDDAT	; EXPECTED STATUS
11320	056132	013737	001340	001142	MOV	RMDSI,\$BDDAT	; RECEIVED STATUS
11321	056140	052737	000100	001140	BIS	#VV,\$GDDAT	
11322	056146	062716	000004		ADD	#4,(SP)	; MOVE SP TO USER'S ERROR CALL
11323	056152	112776	000101	000000	MOVB	#101,a(SP)	; WRITE ERROR NUMBER IN CALL
11324	056160	162716	000002		SUB	#2,(SP)	; MOVE SP TO RETURN FOR ERROR
11325	056164	004736			JSR	PC,a(SP)+	
11326	056166	162716	000010		SUB	#10,(SP)	; MOVE SP BACK TO USER'S BRANCH
11327	056172	000240			NOP		
11328	056174						
11329							
11330							
11331	056174	032737	100000	001340	10\$:		
11332	056202	001024					
11333	056204	013737	001340	001140			
11334	056212	052737	100000	001140			
11335	056220	013737	001340	001142			
11336	056226	062716	000004				
11337	056232	112776	000102	000000			
11338	056240	162716	000002				
11339	056244	004736					
11340	056246	162716	000010				
11341	056252	000240					
11342							
11343	056254						
11344							
11345							
11346							
11347	056254	032737	000001	001340			
11348	056262	001424					
11349	056264	013737	001340	001140			
11350	056272	042737	000001	001140			
11351	056300	013737	001340	001142			
11352	056306	062716	000004				
11353	056312	112776	000103	000000			
11354	056320	162716	000002				
11355	056324	004736					
11356	056326	162716	000010				
11357	056332	000240					
11358	056334						
11359							
11360							
11361							
11362	056334	032737	020000	001340			
11363	056342	001430					
11364	056344	032737	040000	001370			
11365	056352	001024					
11366	056354	013737	001340	001140			
11367	056362	042737	020000	001140			
11368	056370	013737	001340	001142			
11369	056376	062716	000004				
11370	056402	112776	000104	000000			

```

11371 056410 162716 0000U2          SUB      #2,(SP)          ;MOVE SP TO RETURN FOR ERROR
11372 056414 004736                JSR      PC,@(SP)+
11373 056416 162716 000010          SUB      #10,(SP)         ;MOVE SP BACK TO USER'S BRANCH
11374 056422 000240                NOP
11375 056424
11376
11377
11378 056424 032737 040006 001342          ;SEE IF "ILR" OR "RMR" OR "UNS" IS SET
11379 056432 001514                BIT      #ILR!RMR!UNS,RMER11
11380
11381
11382 056434 032737 000002 001342          ;REPORT AN ERROR IF "ILR" IS SET
11383 056442 001424                BIT      #ILR,RMER11      ;WAS ILR SET DURING RECALIBRATE??
11384 056444 013737 001342 001140          BEQ      14$              ;NO!!
11385 056452 042737 000002 001140          MOV      RMER11,$GDDAT    ;EXPECTED STATUS
11386 056460 013737 001342 001142          BIC      #ILR,$GDDAT
11387 056466 062716 000004                MOV      RMER11,$BDDAT    ;RECEIVED STATUS
11388 056472 112776 000105 000000          ADD      #4,(SP)         ;MOVE SP TO USER'S ERROR CALL
11389 056500 162716 000002                MOVB    #105,@(SP)       ;WRITE ERROR NUMBER IN CALL
11390 056504 004736                SUB      #2,(SP)         ;MOVE SP TO RETURN FOR ERROR
11391 056506 162716 000010          JSR      PC,@(SP)+
11392 056512 000240                SUB      #10,(SP)        ;MOVE SP TO USER'S BRANCH
11393 056514
11394
11395
11396 056514 032737 000004 001342          ;REPORT AN ERROR IF "RMR" IS SET
11397 056522 001424                BIT      #RMR,RMER11      ;WAS RMR SET??
11398 056524 013737 001342 001140          BEQ      15$              ;NO!!
11399 056532 042737 000004 001140          MOV      RMER11,$GDDAT    ;EXPECTED STATUS
11400 056540 013737 001342 001142          BIC      #RMR,$GDDAT
11401 056546 062716 000004                MOV      RMER11,$BDDAT    ;RECEIVED STATUS
11402 056552 112776 000106 000000          ADD      #4,(SP)         ;MOVE SP TO USER'S ERROR CALL
11403 056560 162716 000002                MOVB    #106,@(SP)       ;WRITE ERROR NUMBER IN USER'S CALL
11404 056564 004736                SUB      #2,(SP)         ;MOVE SP TO RETURN FOR ERROR
11405 056566 162716 000010          JSR      PC,@(SP)+
11406 056572 000240                SUB      #10,(SP)        ;REPORT ERROR VIA USER
11407 056574
11408
11409
11410 056574 032737 040000 001342          ;REPORT AN ERROR IF "UNS" IS SET AND "DVC" IS 0
11411 056602 001430                BIT      #UNS,RMER11      ;WAS UNSAFE ON??
11412 056604 032737 000200 001370          BEQ      16$              ;NO!!
11413 056612 001024                BIT      #DVC,RMER21      ;WAS THERE A DEVICE CHECK??
11414 056614 013737 001342 001140          BNE      16$              ;YES - DON'T REPORT UNSAFE
11415 056622 042737 040000 001140          MOV      RMER11,$GDDAT    ;EXPECTED STATUS
11416 056630 013737 001342 001142          BIC      #UNS,$GDDAT
11417 056636 062716 000004                MOV      RMER11,$BDDAT    ;RECEIVED STATUS
11418 056642 112776 000107 000000          ADD      #4,(SP)         ;MOVE SP TO USER'S ERROR CALL
11419 056650 162716 000002                MOVB    #107,@(SP)       ;WRITE ERROR NUMBER
11420 056654 004736                SUB      #2,(SP)         ;MOVE SP TO RETURN FOR ERROR
11421 056656 162716 000010          JSR      PC,@(SP)+
11422 056662 000240                SUB      #10,(SP)        ;REPORT ERROR VIA USER
11423 056664
11424
11425
11426 056664 062716 000004                ;AUGMENT THE RETURN ADDRESS IF ANY ERROR WAS DETECTED
11426 056664 062716 000004                ADD      #4,(SP)         ;MOVE SP TO USER'S ERROR CALL

```

CZRMCB0 RM03/2 FCTNL TST 1  
CZRMCB.P11 23-NOV-77 12:14

MACY11 30(1046) 23-NOV-77 12:25 PAGE 235  
RECALIBRATE STATUS CHECK SUBROUTINE

SEQ 0235

11427	056670	105776	000000
11428	056674	001403	
11429	056676	062716	000004
11430	056702	000402	
11431	056704	162716	000004
11432	056710	000240	
11433	056712	000207	
11434			

	TSTB	2(SP)	; WAS AN ERROR REPORTED??
	BEQ	17\$	; NO!!
	ADD	#4 (SP)	; YES - AUGMENT SP RETURN
	BR	18\$	
17\$:	SUB	#4, (SP)	; NO ERROR - RETURN SP TO BRANCH
18\$:	NOP		
	RTS	PC	; STATUS CECK IS COMPLETE

```

11435
11436
11437
11438
11439
11440
11441
11442 056714
11443
11444
11445 056714 062716 000004
11446 056720 105076 000000
11447 056724 162716 000004
11448
11449 056730 013737 001326 001142
11450 056736 042737 173700 001142
11451 056744 012737 004010 001140
11452 056752 023737 001140 001142
11453 056760 001443
11454 056762 062716 000004
11455 056766 112776 000141 000000
11456 056774 162716 000002
11457 057000 004736
11458 057002 162716 000010
11459 057006 000240
11460
11461 057010 013737 001340 001142
11462 057016 042737 021101 001142
11463 057024 012737 010600 001140
11464 057032 023737 001140 001142
11465 057040 001413
11466 057042 062716 000004
11467 057046 112776 000142 000000
11468 057054 162716 000002
11469 057060 004736
11470 057062 162716 000010
11471 057066 000240
11472
11473 057070 005037 001140
11474 057074 013737 001342 001142
11475 057102 001413
11476 057104 062716 000004
11477 057110 112776 000143 000000
11478 057116 162716 000002
11479 057122 004736
11480 057124 162716 000010
11481 057130 000240
11482
11483 057132 013737 001344 001142
11484 057140 010146
11485 057142 010246
11486 057144 013701 001446
11487 057150 116102 000001
11488 057154 042702 177400
11489 057160 005102
11490 057162 040237 001142

```

```

.SBTTL DRIVE CLEAR STATUS CHECK SUBROUTINE
:
: BR ??? RETURN HERE IF NO ERROR
: NOP RETURN HERE TO REPORT AN ERROR
: ERROR ERROR NUMBER DEFINED BY SUB
: JSR PC,2(SP)+ GO BACK TO SUB FOR MORE ERROR CHECKS
: ??? RETURN HERE IF NO MORE ERRORS

DRVSTS:

;CLEAR USER'S ERROR CALL
ADD #4,(SP) ;MOVE SP TO ERROR CALL
CLRB 2(SP) ;CLEAR ERROR CALL
SUB #4,(SP) ;MOVE SP TO USER'S BRANCH

;REPORT ERROR IF RMCS1 NOT INITIALIZED
4$: MOV RMCSI,$BDDAT ;CHECK RMCS1
BIC #C<DVA!FNCMSK>,$BDDAT ;CLEAR DONT CARES
MOV #DVA!DRVCLR,$GDDAT ;EXPECT DVA
CMP $GDDAT,$BDDAT ;COMPARE EXPECTED & RECEIVED
BEQ 6$ ;BRANCH IF EQUAL
ADD #4,(SP) ;MOVE SP TO ERROR CALL
MOVB #141,2(SP) ;WRITE NUMBER OF ERROR IN CALL
SUB #2,(SP) ;MOVE SP TO RETURN FOR ERROR
JSR PC,2(SP)+ ;REPORT THE ERROR VIA USER
SUB #10,(SP) ;MOVE SP TO NO ERROR RETURN
NOP

;REPORT ERROR IF RMDS NOT INITIALIZED
5$: MOV RMDSI,$BDDAT ;CHECK RMDS
BIC #PGM!OM!VV!PIP,$BDDAT ;CLEAR DONT CARES
MOV #MOL!DPR!DRY,$GDDAT ;EXPECT DRY & DPR
CMP $GDDAT,$BDDAT ;COMPARE EXPECTED & RECEIVED
BEQ 6$ ;BRANCH IF EQUAL
ADD #4,(SP) ;MOVE SP TO ERROR CALL
MOVB #142,2(SP) ;WRITE NUMBER OF ERROR IN CALL
SUB #2,(SP) ;MOVE SP TO RETURN FOR ERROR
JSR PC,2(SP)+ ;REPORT THE ERROR VIA USER
SUB #10,(SP) ;MOVE SP TO NO ERROR RETURN
NOP

;REPORT ERROR IF RMER1 NOT INITIALIZED
6$: CLR $GDDAT ;EXPECT 0'S
MOV RMER1I,$BDDAT ;CHECK RMER1
BEQ 8$ ;BRANCH IF EQUAL
ADD #4,(SP) ;MOVE SP TO ERROR CALL
MOVB #143,2(SP) ;WRITE NUMBER OF ERROR IN CALL
SUB #2,(SP) ;MOVE SP TO RETURN FOR ERROR
JSR PC,2(SP)+ ;REPORT THE ERROR VIA USER
SUB #10,(SP) ;MOVE SP TO NO ERROR RETURN
NOP

;REPORT ERROR IF ATA NOT INITIALIZED
8$: MOV RMASI,$BDDAT ;CHECK ATTENTION BIT
MOV R1,-(SP) ;;PUSH R1 ON STACK
MOV R2,-(SP) ;;PUSH R2 ON STACK
MOV TSTQUE,R1
MOVB 1(R1),R2
BIC #CATNMSK,R2
COM R2
BIC R2,$BDDAT

```

E03

CZRMCB0 RM03/2 FCTNL TST 1  
CZRMCB.P11 23-NOV-77 12:14

MACY11 30(1046) 23-NOV-77 12:25 PAGE 237  
DRIVE CLEAR STATUS CHECK SUBROUTINE

SEQ 0237

11491	057166	012602			MOV	(SP)+,R2	::POP STACK INTO R2
11492	057170	012601			MOV	(SP)+,R1	::POP STACK INTO R1
11493	057172	005737	001142		TST	\$BDDAT	::IS ATTENTION CLEARED??
11494	057176	001413			BEQ	9\$	::BRANCH IF ATTENTION CLEARED
11495	057200	062716	000004		ADD	#4,(SP)	::MOVE SP TO ERROR CALL
11496	057204	112776	000144	000000	MOVB	#144,@(SP)	::WRITE NUMBER OF ERROR IN CALL
11497	057212	162716	000002		SUB	#2,(SP)	::MOVE SP TO RETURN FOR ERROR
11498	057216	004736			JSR	PC,@(SP)+	::REPORT THE ERROR VIA USER
11499	057220	162716	000010		SUB	#10,(SP)	::MOVE SP TO NO ERROR RETURN
11500	057224	000240			NOP		
11501							
11502	057226	013737	001352	001142	9\$:	REPORT ERROR IF RMMR1 NOT INITIALIZED	
11503	057234	042737	000046	001142	MOV	RMMR1I,\$BDDAT	::CHECK RMMR
11504	057242	012737	000010	001140	BIC	#WC!LS!LST,\$BDDAT	::CLEAR DONT CARES
11505	057250	023737	001140	001142	MOV	#MWD,\$GDDAT	::EXPECT WRITE DATA ON
11506	057256	001413			CMP	\$GDDAT,\$BDDAT	::COMPARE EXPECTED AND RECEIVED
11507	057260	062716	000004		BEQ	11\$	::BRANCH IF ZERO
11508	057264	112776	000145	000000	ADD	#4,(SP)	::MOVE SP TO ERROR CALL
11509	057272	162716	000002		MOVB	#145,@(SP)	::WRITE NUMBER OF ERROR IN CALL
11510	057276	004736			SUB	#2,(SP)	::MOVE SP TO RETURN FOR ERROR
11511	057300	162716	000010		JSR	PC,@(SP)+	::REPORT THE ERROR VIA USER
11512	057304	000240			SUB	#10,(SP)	::MOVE SP TO NO ERROR RETURN
11513					NOP		
11514	057306	013737	001366	001142	11\$:	REPORT ERROR IF RMMR2 NOT INITIALIZED	
11515	057314	042737	140000	001142	MOV	RMMR2I,\$BDDAT	::CHECK RMMR2
11516	057322	012737	011777	001140	BIC	#RQA!RQB,\$BDDAT	::CLEAR RQA, RQB
11517	057330	023737	001140	001142	MOV	#TST!1777,\$GDDAT	::EXPECT TEST BIT ON
11518	057336	001413			CMP	\$GDDAT,\$BDDAT	::COMPARE EXPECTED & RECEIVED
11519	057340	062716	000004		BEQ	15\$	::BRANCH IF EQUAL
11520	057344	112776	000146	000000	ADD	#4,(SP)	::MOVE SP TO ERROR CALL
11521	057352	162716	000002		MOVB	#146,@(SP)	::WRITE NUMBER OF ERROR IN CALL
11522	057356	004736			SUB	#2,(SP)	::MOVE SP TO RETURN FOR ERROR
11523	057360	162716	000010		JSR	PC,@(SP)+	::REPORT THE ERROR VIA USER
11524	057364	000240			SUB	#10,(SP)	::MOVE SP TO NO ERROR RETURN
11525	057366	005037	001140		NOP		
11526					15\$:	CLR \$GDDAT	::EXPECT ZEROS
11527	057372	013737	001374	001142	;REPORT	ERROR IF RMEC2 NOT RESET	
11528	057400	001413			MOV	RMEC2I,\$BDDAT	::CHECK RMEC2
11529	057402	062716	000004		BEQ	17\$	::BRANCH IF 0
11530	057406	112776	000150	000000	ADD	#4,(SP)	::MOVE SP TO ERROR CALL
11531	057414	162716	000002		MOVB	#150,@(SP)	::WRITE NUMBER OF ERROR IN CALL
11532	057420	004736			SUB	#2,(SP)	::MOVE SP TO RETURN FOR ERROR
11533	057422	162716	000010		JSR	PC,@(SP)+	::REPORT THE ERROR VIA USER
11534	057426	000240			SUB	#10,(SP)	::MOVE SP TO NO ERROR RETURN
11535					NOP		
11536	057430	013737	001370	001142	17\$:	REPORT ERROR IF RMER2 NOT RESET	
11537	057436	001413			MOV	RMER2I,\$BDDAT	::CHECK RMER2
11538	057440	062716	000004		BEQ	18\$	::BRANCH IF NO ERROR
11539	057444	112776	000147	000000	ADD	#4,(SP)	::MOVE SP TO ERROR CALL
11540	057452	162716	000002		MOVB	#147,@(SP)	::WRITE NUMBER OF ERROR IN CALL
11541	057456	004736			SUB	#2,(SP)	::MOVE SP TO RETURN FOR ERROR
11542	057460	162716	000010		JSR	PC,@(SP)+	::REPORT THE ERROR VIA USER
11543	057464	000240			SUB	#10,(SP)	::MOVE SP TO NO ERROR RETURN
11544	057466				NOP		
11545					18\$:		
11546	057466				19\$:		

F03

CZRMCB0 RM03/2 FCTNL TST 1  
CZRMCB.P11 23-NOV-77 12:14

MACY11 30(1046) 23-NOV-77 12:25 PAGE 238  
DRIVE CLEAR STATUS CHECK SUBROUTINE

SEQ 0238

11547			
11548			
11549	057466	062716	000004
11550	057472	105776	000000
11551	057476	001403	
11552	057500	062716	000004
11553	057504	000402	
11554	057506	162716	000004
11555	057512	000240	
11556	057514	000207	

```

;AUGMENT RETURN ADDRESS IF ANY ERROR WAS FOUND
      ADD      #4,(SP)      ;MOVE SP TO ERROR CALL
      TSTB    @2(SP)      ;WAS AN ERROR DETECTED??
      BEQ     21$          ;NO!!
      ADD     #4,(SP)      ;YES - MOVE SP TO ERROR RETURN
      BR      23$
21$:   SUB     #4,(SP) ;MOVE SP BACK TO NO ERROR RETURN
23$:   NOP
      RTS      PC          ;RETURN TO USER

```



```

11557
11558
11559
11560
11561
11562
11563
11564
11565
11566
11567
11568
11569
11570
11571
11572
11573
11574
11575
11576
11577
11578
11579
11580
11581
11582
11583
11584
11585
11586
11587
11588
11589
11590
11591
11592
11593
11594
11595
11596 057516
11597
11598
11599 057516 062716 000004
11600 057522 105076 000000
11601 057526 162716 000004
11602 057532 005037 061060
11603
11604
11605 057536 032737 000010 001342
11606 057544 001431
11607 057546 032737 000010 001370
11608 057554 001025
11609
11610
11611 057556 013737 001342 001140
11612 057564 042737 000010 001140
    
```

```

.SBTTL SEARCH STATUS CHECK SUBROUTINE

; THIS SUBROUTINE VERIFIES THE RESULTS OF SEARCH OPERATIONS USING
; STATUS STORED IN THE GET BUFFER AND TEST CONDITIONS STORED IN THE
; PUT BUFFER.

; THE SUBROUTINE RETURNS TO THE CALLING ROUTINE IF AN ERROR IS
; DETECTED AFTER HAVING LOADED THE APPROPRIATE ERROR NUMBER IN
; THE USER'S "ERROR" TRAP.

; THE FOLLOWING CONDITIONS ARE CHECKED:

; .ANY ERROR WHICH OCCURRED WHILE READING OR WRITING REMOTE
; REGISTERS IS REPORTED, I.E., "MCPE"=1 OR "PAR"=1

; "IAE" STATUS IS CHECKED IN ACCORDANCE WITH THE VALUE DETERMINED
; BY THE PROGRAM, WHICH IS BASED ON FORMAT AND ADDRESS.

; "OPI" IF SET, IS REPORTED AS 1) "OPI" DUE TO MOL=0, OR 2)
; "OPI" DUE TO ON CYLINDER LATCH.

; "IVC" IF SET, IS REPORTED AS 1) "IVC" ERROR WITH VOLUME
; VALID ZERO, OR 2) ERRONEOUS "IVC" ERROR WITH VOLUME VALID SET.

; "SKI" IS REPORTED IF SET

; "DVC" IS REPORTED IF SET

; AN ERROR IS REPORTED IF "MOL"=0, OR "PIP"=1, OR "ATA"=0,
; OR "VV"=0

CALL:
(1) JSR PC,SCHSTS
(2) BR ??
(3) NOP
(4) ERROR
(5) JSR PC,@(SP)+
(6) ??

RETURN HERE IF NO ERROR
RETURN HERE TO REPORT ERROR
SUBROUTINE WILL LOAD ERROR #
GO BACK FOR MORE CHECKS
RETURN AFTER ALL ERRORS REPORTED

SCHSTS:

; CLEAR USER'S ERROR CALL
ADD #4,(SP) ; MOVE SP TO USER'S ERROR CALL
CLRB @(SP) ; CLEAR ERROR NUMBER
SUB #4,(SP) ; MOVE SP BACK TO NO ERROR BR
CLR 200$ ; CLEAR STATUS FLAGS

; TEST FOR MASSBUS CONTROL BUS PARITY ERROR WHEN WRITING REMOTE
; REGISTERS, I.E. "PAR"=1 AND "DPE"=0.
BIT #PAR,RMER1I ; WAS PARITY ERROR DETECTED??
BEQ 10$ ; NO!!
BIT #DPE,RMER2I ; WAS IT CONTROL BUS ERROR??
BNE 10$ ; PROBABLY NOT!!

; REPORT CONTROL BUS PARITY ERROR VIA USER'S ERROR CALL
MOV RMER1I,$GDDAT ; EXPECTED STATUS
BIC #PAR,$GDDAT
    
```

```

11613 057572 013737 001342 001142      MOV      RMER11,$BDDAT      ;RECEIVED STATUS
11614 057600 062716 000004                ADD      #4,(SP)            ;MOVE SP TO USER'S ERROR CALL
11615 057604 112776 000050 000000      MOV     #50,2(SP)          ;WRITE ERROR NUMBER IN CALL
11616 057612 162716 000002                SUB      #2,(SP)            ;MOVE SP TO RETURN IF ERROR
11617 057616 004736                JSR     PC,2(SP)+          ;REPORT ERROR
11618 057620 162716 000010      SUB     #10,(SP)           ;RESTORE SP TO NO ERROR
11619 057624 000240                NOP
11620 057626 000430                BR      15$                ;SKIP FURTHER ERROR CHECKS
11621 057630
11622
11623
11624
11625 057630 032737 020000 001326      BIT     #MCPE,RMCS11      ;TEST FOR MASSBUS CONTROL BUS PARITY ERROR WHEN READING REMOTE
11626 057636 001426                BEQ     20$                ;REGISTERS I.E. "MCPE"=1 ;WAS PARITY ERROR DETECTED??
11627
11628
11629 057640 013737 001326 001140      MOV     RMCS11,$GDDAT     ;REPORT CONTROL BUS PARITY ERROR VIA USER'S ERROR CALL. ;EXPECTED STATUS
11630 057646 042737 020000 001140      BIC     #MCPE,$GDDAT
11631 057654 013737 001326 001142      MOV     RMCS11,$BDDAT     ;RECEIVED STATUS
11632 057662 062716 000004                ADD     #4,(SP)            ;MOVE SP TO USER'S ERROR CALL
11633 057666 112776 000013 000000      MOV     #13,2(SP)         ;WRITE ERROR NUMBER
11634 057674 162716 000002                SUB     #2,(SP)            ;MOVE SP TO RETURN IF ERROR
11635 057700 004736                JSR     PC,2(SP)+          ;REPORT ERROR AND RETURN
11636 057702 162716 000010      SUB     #10,(SP)           ;RESTORE SP TO NO ERROR
11637 057706 000240                NOP
11638 057710 000137 061032      15$:   JMP     150$            ;OMIT STATUS CHECKING
11639
11640 057714
11641
11642
11643
11644
11645 057714 012737 002000 001140      MOV     #IAE,$GDDAT       ;DETERMINE THE VALUE OF "IAE" STATUS BASED ON TRACK, SECTOR AND CYLINDER
11646 057722 052737 040000 061060      BIS     #SKI,200$         ;ADDRESS USED DURING SEARCH. ALSO SET "SKI" FLAG IF CYLINDER ADDRESS
11647 057730 023727 001432 001466      CMP     RMD0,#822.        ;IS TOO LARGE
11648 057736 101025                BHI     30$                ;SETUP FOR IAE=1
11649 057740 042737 040000 061060      BIC     #SKI,200$         ;SETUP FOR SKI=1
11650 057746 123727 001404 000037      CMPB   RMDA0,#31.        ;CYLINDER > 822??
11651 057754 101016                BHI     30$                ;YES - CYLINDER IS INVALID
11652 057756 123727 001404 000035      CMPB   RMDA0,#29.        ;"SKI" SHOULD BE ZERO
11653 057764 101404                BLOS   25$                ;SECTOR > 31??
11654 057766 032737 010000 001360      BIT     #FMT16,RMOFI     ;YES - SECTOR IS INVALID
11655 057774 001406                BEQ     30$                ;SECTOR > 29??
11656 057776 123727 000007 000004      25$:   CMPB   RMDA+1,#4        ;NO!!
11657 060004 101002                BHI     30$                ;18 BIT FORMAT??
11658 060006 005037 001140                CLR     $GDDAT            ;YES - SECTOR IS INVALID
11659 060012
11660
11661
11662 060012 013737 001342 001142      MOV     RMER11,$BDDAT     ;COMPARE EXPECTED AND RECIVED "IAE" STATUS ;GET RECEIVED IAE
11663 060020 042737 175777 001142      BIC     #ICIAE,$BDDAT
11664 060026 023737 001140 001142      CMP     $GDDAT,$BDDAT     ;IS IAE CORRECT??
11665 060034 001004                BNE     40$                ;NO!!
11666 060036 042737 040000 061060      BIC     #SKI,200$         ;SKI SHOULD BE ZERO
11667 060044 000413
11668 060046
40$:

```

```

11669                                     ;REPORT INCORRECT IAE STATUS VIA USER'S ERROR CALL
11670                                     ADD      #4,(SP)                ;MOVE SP TO USER'S ERROR CALL
11671 060046 062716 000004 000000      MOVVB   #257,2(SP)          ;WRITE ERROR NUMBER IN CALL
11672 060052 112776 000257 000000      SUB     #2,(SP)            ;MOVE SP TO RETURN IF ERROR
11673 060060 162716 000002                                     ;REPORT ERROR AND RETURN
11674 060064 004736                                     ;RETURN SP TO NO ERROR
11675 060066 162716 000010      JSR    PC,2(SP)+
11676 060072 000240      SUB     #10,(SP)
11677 060074      NOP
11678
11679                                     50$:
11680 060074 032737 050200 001370      ;SEE IF "SKI" OR "DVC" OR "IVC" IS SET
11681 060102 001531      BIT     #SKI!DVC!IVC,RMER2I ;ARE ANY BITS SET??
11682                                     BEQ    90$                ;NO!!
11683
11684 060104 013737 001370 001142      ;REPORT ERROR IF "SKI" IS SET AND "SKI" FLAG IS NOT SET
11685 060112 042737 137777 001142      MOV     RMER2I,$BDDAT      ;RECEIVED "SKI" STATUS
11686 060120 013737 061060 001140      BIC    #1CSKI,$BDDAT
11687 060126 042737 137777 001140      MOV     200$,$GDDAT       ;EXPECTED "SKI" STATUS
11688 060134 023737 001140 001142      BIC    #1CSKI,$GDDAT
11689 060142 001422      CMP     $GDDAT,$BDDAT     ;IS "SKI" OK??
11690 060144 062716 000004      BEQ    60$                ;YES-CHANGE ERROR NUMBER
11691 060150 112776 000263 000000      ADD     #4,(SP)           ;MOVE SP TO USER'S ERROR CALL
11692 060156 032737 040000 001140      MOVVB  #263,2(SP)         ;WRITE ERROR NUMBER
11693 060164 001403      BIT     #SKI,$GDDAT       ;SHOUL "SKI" BE SET??
11694 060166 112776 000267 000000      BEQ    55$                ;NO!!
11695 060174 162716 000002      MOVVB  #267,2(SP)         ;YES-CHANGE ERROR NUMBER
11696 060200 004736                                     ;MOVE SP TO RETURN IF ERROR
11697 060202 162716 000010      JSR    PC,2(SP)+
11698 060206 000240      SUB     #10,(SP)         ;REPORT ERROR AND RETURN
11699 060210      NOP                        ;RESTORE SP TO NO ERROR
11700
11701                                     60$:
11702                                     ;REPORT "IVC" ERROR AS
11703                                     .IVC DUE TO LOSS OF VOLUME VALID
11704 060210 032737 010000 001370      .ERRONEOUS IVC WITH VOLUME VALID SET
11705 060216 001433      BIT     #IVC,RMER2I       ;IS IVC SET??
11706 060220 013737 001370 001140      BEQ    80$                ;NO!!
11707 060226 042737 010000 001140      MOV     RMER2I,$GDDAT     ;EXPECTED STATUS
11708 060234 013737 001370 001142      BIC    #IVC,$GDDAT
11709 060242 062716 000004      MOV     RMER2I,$BDDAT     ;RECEIVED STATUS
11710 060246 112776 000264 000000      ADD     #4,(SP)           ;MOVE SP TO USER'S ERROR CALL
11711 060254 032737 000100 001340      MOVVB  #264,2(SP)         ;WRITE ERROR NUMBER IN CALL
11712 060262 001403      BIT     #VV,RMDSI        ;WAS VOLUME VALID??
11713 060264 112776 000265 000000      BEQ    70$                ;NO!!
11714 060272 162716 000002      MOVVB  #265,2(SP)         ;YES - CHANGE ERROR NUMBER
11715 060276 004736                                     ;MOVE SP TO RETURN IF ERROR
11716 060300 162716 000010      JSR    PC,2(SP)+
11717 060304 000240      SUB     #10,(SP)         ;REPORT ERROR AND RETURN
11718 060306      NOP                        ;RESTORE SP TO NO ERROR
11719
11720                                     70$:
11721 060306 032737 000200 001370      ;REPORT ANY DEVICE FAULT, I.E., "DVC"=1
11722 060314 001424      BIT     #DVC,RMER2I      ;WAS THERE A DEVICE FAULT??
11723 060316 013737 001370 001140      BEQ    90$                ;NO!!
11724 060324 042737 000200 001140      MOV     RMER2I,$GDDAT     ;EXPECTED STATUS
11724 060324 042737 000200 001140      BIC    #DVC,$GDDAT

```

```

11725 060332 013737 001370 001142     MOV      RMER2I,$BDDAT ;RECEIVED STATUS
11726 060340 062716 000004             ADD      #4,(SP)       ;MOVE SP TO USER'S ERROR CALL
11727 060344 112776 000266 000000     MOVVB   #266,@(SP)    ;WRITE ERROR NUMBER IN CALL
11728 060352 162716 000002             SUB      #2,(SP)      ;MOVE SP TO RETURN IF ERROR
11729 060356 004736             JSR     PC,@(SP)+     ;REPORT ERROR AND RETURN
11730 060360 162716 000010     SUB      #10,(SP)    ;RESTORE SP TO NO ERROR
11731 060364 000240             NOP
11732 060366
11733
11734
11735 ;REPORT ANY "OPI" ERROR AS
11736 ;
11737 060366 032737 020000 001342     BIT      #OPI,RMER1I ;WAS OPI SET??
11738 060374 001433             BEQ     110$         ;NO!!
11739 060376 013737 001342 001140     MOV      RMER1I,$GDDAT ;EXPECTED STATUS
11740 060404 042737 020000 001140     BIC     #OPI,$GDDAT
11741 060412 013737 001342 001142     MOV      RMER1I,$BDDAT ;RECEIVED STATUS
11742 060420 062716 000004             ADD      #4,(SP)       ;MOVE SP TO USER'S ERROR CALL
11743 060424 112776 000270 000000     MOVVB   #270,@(SP)    ;SETUP ERROR FOR MOL=0
11744 060432 032737 010000 001340     BIT      #MOL,RMDSI   ;WAS MOL 0??
11745 060440 001403             BEQ     105$         ;YES!!
11746 060442 112776 000271 000000     MOVVB   #271,@(SP)    ;MOL WAS 1 - CHANGE ERROR
11747 060450 162716 000002 105$:     SUB      #2,(SP)      ;MOVE SP TO RETURN IF ERROR
11748 060454 004736             JSR     PC,@(SP)+     ;REPORT ERROR AND RETURN
11749 060456 162716 000010     SUB      #10,(SP)    ;RESTORE SP TO NO ERROR
11750 060462 000240             NOP
11751 060464
11752
11753 ;SEE IF "ATA"="MOL"="VV"=1 AND "PIP"=0
11754 060464 013746 001340             MOV      RMDSI,-(SP)  ;GET DRIVE STATUS
11755 060470 042716 047677             BIC     #1<ATA!PIP!MOL!VV>,(SP)
11756 060474 022726 110100             CMP     #ATA!MOL!VV,(SP)+ ;IS DRIVE STATUS CORRECT??
11757 060500 001554             BEQ     150$         ;YES!!
11758
11759 ;REPORT AN ERROR IF MOL=0 AND OPI ERROR WAS NOT REPORTED, I.E., OPI=0
11760 060502 032737 010000 001340     BIT      #MOL,RMDSI   ;WAS MEDIUM OFF LINE??
11761 060510 001030             BNE     120$         ;NO!!
11762 060512 013737 001340 001140     MOV      RMDSI,$GDDAT ;EXPECTED STATUS
11763 060520 052737 010000 001140     BIS     #MOL,$GDDAT
11764 060526 013737 001340 001142     MOV      RMDSI,$BDDAT ;RECEIVED STATUS
11765 060534 032737 020000 001342     BIT      #OPI,RMER1I ;WAS OPI REPORTED BEFORE??
11766 060542 001013             BNE     120$         ;YES - DON'T REPORT MOL=0
11767 060544 062716 000004             ADD      #4,(SP)       ;MOVE SP TO USER'S ERROR CALL
11768 060550 112776 000272 000000     MOVVB   #272,@(SP)    ;WRITE ERROR NUMBER IN CALL
11769 060556 162716 000002             SUB      #2,(SP)      ;MOVE SP TO RETURN IF ERROR
11770 060562 004736             JSR     PC,@(SP)+     ;REPORT ERROR AND RETURN
11771 060564 162716 000010     SUB      #10,(SP)    ;RESTORE SP TO NO ERROR
11772 060570 000240             NOP
11773 060572
11774
11775 ;REPORT AN ERROR IF PIP IS STIL SET AND SKI IS RESET
11776 060572 032737 020000 001340     BIT      #PIP,RMDSI   ;IS POSITIONING IN PROGRESS??
11777 060600 001430             BEQ     130$         ;NO!!
11778 060602 032737 040000 001370     BIT      #SKI,RMER2I ;WAS "SKI" DETECTED??
11779 060610 001024             BNE     130$         ;YES-DONT REPORT PIP
11780 060612 013737 001340 001140     MOV      RMDSI,$GDDAT ;EXPECTED STATUS

```

```

11781 060620 042737 020000 001140      BIC      #PIP,$GDDAT
11782 060626 013737 001340 001142      MOV      RMDSI,$BDDAT      ;RECEIVED STATUS
11783 060634 062716 000004      ADD      #4,(SP)           ;MOVE SP TO USER'S ERROR CALL
11784 060640 112776 000273 000000      MOVVB   #273,@(SP)        ;WRITE ERROR NUMBER IN CALL
11785 060646 162716 000002      SUB      #2,(SP)           ;MOVE SP TO RETURN IF ERROR
11786 060652 004736      JSR      PC,@(SP)+         ;REPORT ERROR AND RETURN
11787 060654 162716 000010      SUB      #10,(SP)         ;RESTORE SP TO NO ERROR
11788 060660 000240
11789 060662
11790
11791
11792 060662 032737 000100 001340      ;REPORT AN ERROR IF VOLUME IS NOT VALID AND IVC=0
11793 060670 001030      BIT      #VV,RMDSI         ;IS VOLUME VALID??
11794 060672 032737 010000 001370      BNE      140$              ;YES!!
11795 060700 001024      BIT      #IVC,RMER2I       ;WAS IVC DETECTED??
11796 060702 013737 001340 001140      BNE      140$              ;YES - DON'T REPORT VV=0
11797 060710 052737 000100 001140      MOV      RMDSI,$GDDAT      ;EXPECTED STATUS
11798 060716 013737 001340 001142      BIS      #VV,$GDDAT        ;RECEIVED STATUS
11799 060724 062716 000004      MOV      RMDSI,$BDDAT      ;MOVE SP TO USERS ERROR CALL
11800 060730 112776 000350 000000      ADD      #4,(SP)           ;WRITE ERROR NUMBER IN CALL
11801 060736 162716 000002      MOVVB   #350,@(SP)        ;MOVE SP TO RETURN IF ERROR
11802 060742 004736      JSR      PC,@(SP)+         ;REPORT ERROR AND RETURN
11803 060744 162716 000010      SUB      #10,(SP)         ;RESTORE SP TO NO ERROR
11804 060750 000240
11805 060752
11806
11807
11808 060752 032737 100000 001340      ;REPORT AN ERROR IF ATTENTION IS NOT SET
11809 060760 001024      BIT      #ATA,RMDSI         ;IS ATA ON??
11810 060762 013737 001340 001140      BNE      150$              ;YES!!
11811 060770 052737 100000 001140      MOV      RMDSI,$GDDAT      ;EXPECTED STATUS
11812 060776 013737 001340 001142      BIS      #ATA,$GDDAT        ;RECEIVED STATUS
11813 061004 062716 000004      MOV      RMDSI,$BDDAT      ;MOVE SP TO USER'S ERROR CALL
11814 061010 112776 000351 000000      ADD      #4,(SP)           ;WRITE ERROR NUMBER IN CALL
11815 061016 162716 000002      MOVVB   #351,@(SP)        ;MOVE SP TO RETURN IF ERROR
11816 061022 004736      JSR      PC,@(SP)+         ;REPORT ERROR AND RETURN
11817 061024 162716 000010      SUB      #10,(SP)         ;RESTORE SP TO NO ERROR
11818 061030 000240
11819 061032
11820
11821
11822 061032 062716 000004      ;AUGMENT THE RETURN ADDRESS IF AN ERROR WAS DETECTED
11823 061036 105776 000000      ADD      #4,(SP)           ;MOVE SP TO USER'S ERROR CALL
11824 061042 001403      TSTB    @(SP)              ;WAS ERROR FOUND??
11825 061044 062716 000004      BEQ      160$              ;NO!!
11826 061050 000402      ADD      #4,(SP)           ;YES - CHANGE RETURN
11827 061052 162716 000004      BR       170$
11828 061056 000207      160$:  SUB      #4,(SP)      ;NO ERROR FOUND
11829
11830 061060 000000      170$:  RTS      PC          ;RETURN TO USER
200$:  .WORD      ;STORAGE FOR FLAGS

```

```

11831
11832
11833
11834
11835
11836
11837
11838
11839
11840
11841
11842
11843
11844
11845
11846
11847
11848
11849
11850
11851
11852
11853
11854
11855
11856
11857 061062
11858
11859
11860 061062 062716 000004
11861 061066 105076 000000
11862 061072 162716 000004
11863
11864 061076 013746 001340
11865 061102 042716 147677
11866 061106 022726 010100
11867 061112 001524
11868
11869
11870 061114 032737 010000 001340
11871 061122 001030
11872 061124 032737 020000 001342
11873 061132 001024
11874 061134 013737 001340 001140
11875 061142 052737 010000 001140
11876 061150 013737 001340 001142
11877 061156 062716 000004
11878 061162 112776 000207 000000
11879 061170 162716 000002
11880 061174 004736
11881 061176 162716 000010
    
```

```

.SBTTL STATIC DRIVE STATUS CHECK SUBROUTINE
; THIS SUBROUTINE LOOKS FOR UNEXPECTED CHANGES IN DRIVE
; STATUS, SUCH AS THE DRIVE LOSING VOLUME VALID. THE SUBROUTINE
; CAN BE USED BY HOUSEKEEPING AND OTHER COMMANDS DURING WHICH THERE
; SHOULD NOT BE ANY DRIVE ERRORS OR CHANGES IN STATE.
; THE FOLLOWING CONDITIONS ARE TESTED AND REPORTED AS ERRORS
; IF TRUE:
; .MOL = 0, INDICATES DRIVE WENT OFFLINE, NOTE
; THAT MOL IS ASSUMED TO HAVE BEEN SET
; .VV = 0, INDICATES THE DRIVE LOST VOLUME VALID
; .PIP = 1, INDICATES THAT THE DRIVE IS OFF CYLINDER
; .SKI = 1, INDICATES THE DRIVE HAS AN UNEXPECTED SKI ERROR
; .DVC = 1, INDICATES AN UNEXPECTED DEVICE FAULT
; THE SUBROUTINE IS CALLED AFTER STORING STATUS IN THE GET BUFFER.
; (1) JSR PC,STCDRVSTS
; BR ??? RETURN HERE IF NO ERROR
; NOP RETURN HERE TO REPORT AN ERROR
; ERROR ERROR NUMBER DEFINED BY SUB
; JSR PC,2(SP)+ GO BACK TO SUB FOR MORE ERROR CHECKS
; ??? RETURN HERE IF NO MORE ERRORS
STCDRVSTS:
; CLEAR USER'S ERROR CALL
ADD #4,(SP) ; MOVE SP TO USER'S ERROR CALL
CLRB 2(SP) ; CLEAR ERROR NUMBER
SUB #4,(SP) ; MOVE SP BACK TO NO ERROR RETURN
; SEE IF "MOL" = "VV" = 1 AND "PIP" = 0
MOV RMDSI,-(SP) ; PUT DRIVE STATUS ON STACK
BIC #1C<PIP!MOL!VV>,(SP)
CMP #MOL!VV,(SP)+ ; ARE MOL,VV AND PIP O.K.??
BEQ 30$ ; YES!!
; REPORT AN ERROR IF MOL = 0 AND "OPI" = 0
BIT #MOL,RMDSI ; IS MOL ON ??
BNE 10$ ; YES!!
BIT #OPI,RMER1I ; WAS "OPI" SET??
BNE 10$ ; YES-DONT REPORT "MOL" = 0
MOV RMDSI,$GDDAT ; EXPECTED STATUS
BIS #MOL,$GDDAT
MOV RMDSI,$BDDAT ; RECEIVED STATUS
ADD #4,(SP) ; MOVE SP TO USER'S ERROR CALL
MOVB #207,2(SP) ; WRITE ERROR NUMBER IN CALL
SUB #2,(SP) ; MOVE SP TO RETURN FOR ERROR
JSR PC,2(SP)+ ; REPORT ERROR VIA USER
SUB #10,(SP) ; MOVE SP BACK TO NO ERROR RETURN
    
```

```

11882 061202 000240
11883 061204
11884
11885
11886 061204 032737 000100 001340
11887 061212 001030
11888 061214 032737 010000 001370
11889 061222 001024
11890 061224 013737 001340 001140
11891 061232 052737 000100 001340
11892 061240 013737 001340 001142
11893 061246 062716 000004
11894 061252 112776 000210 000000
11895 061260 162716 000002
11896 061264 004736
11897 061266 162716 000010
11898 061272 000240
11899 061274
11900
11901
11902 061274 032737 020000 001340
11903 061302 001430
11904 061304 032737 040000 001370
11905 061312 001024
11906 061314 013737 001340 001140
11907 061322 042737 020000 001140
11908 061330 013737 001340 001142
11909 061336 062716 000004
11910 061342 112776 000211 000000
11911 061350 162716 000002
11912 061354 004736
11913 061356 162716 000010
11914 061362 000240
11915 061364
11916
11917
11918 061364 013746 001370
11919 061370 042726 137577
11920 061374 001460
11921 061376
11922
11923
11924 061376 032737 000200 001370
11925 061404 001424
11926 061406 013737 001370 001140
11927 061414 042737 000200 001140
11928 061422 013737 001370 001142
11929 061430 062716 000004
11930 061434 112776 000212 000000
11931 061442 162716 000002
11932 061446 004736
11933 061450 162716 000010
11934 061454 000240
11935 061456
11936
11937

;REPORT AN ERROR IF VOLUME VALID IS NOW ZERO AND "IVC" = 0
10$:
BIT #VV,RMDSI ;IS "VV" = 0??
BNE 20$ ;NO!!
BIT #IVC,RMER2I ;WAS "IVC" SET??
BNE 20$ ;YES-DONT REPORT "VV" = 0
MOV RMDSI,$GDDAT ;EXPECTED STATUS
BIS #VV,RMDSI
MOV RMDSI,$BDDAT ;RECEIVED STATUS
ADD #4,(SP) ;MOVE SP TO USER'S ERROR CALL
MOV #210,(SP) ;WRITE ERROR NUMBER IN CALL
SUB #2,(SP) ;MOVE SP TO RETURN FOR ERROR
JSR PC,(SP)+ ;REPORT ERROR VIA USER
SUB #10,(SP) ;MOVE SP BACK TO NO ERROR
NOP

20$:
;REPORT AN ERROR IF DRIVE IS OFF CYLINDER AND "SKI" = 0
BIT #PIP,RMDSI ;IS DRIVE OFF CYLINDER??
BEQ 30$ ;NO!!
BIT #SKI,RMER2I ;WAS "SKI" SET??
BNE 30$ ;YES-DONT REPORT "PIP" = 1
MOV RMDSI,$GDDAT ;EXPECTED STATUS
BIC #PIP,$GDDAT
MOV RMDSI,$BDDAT ;RECEIVED STATUS
ADD #4,(SP) ;MOVE SP TO USER'S ERROR CALL
MOV #211,(SP) ;WRITE ERROR NUMBER IN USER'S CALL
SUB #2,(SP) ;MOVE SP TO RETURN FOR ERROR
JSR PC,(SP)+ ;REPORT ERROR VIA USER
SUB #10,(SP) ;MOVE SP TO NO ERROR RETURN
NOP

30$:
;SEE IF "SKI" = "DVC" = 0
MOV RMER2I,-(SP) ;PUT ERROR REG 2 ON STACK
BIC #C<SKI!DVC>,(SP)+
BEQ 60$ ;BRANCH IF NO ERROR

40$:
;REPORT AN ERROR IF THERE IS A DEVICE FAULT
BIT #DVC,RMER2I ;ANY DEVICE FAULT??
BEQ 50$ ;NO!!
MOV RMER2I,$GDDAT ;EXPECTED STATUS
BIC #DVC,$GDDAT
MOV RMER2I,$BDDAT ;RECEIVED STATUS
ADD #4,(SP) ;MOVE SP TO USER'S CALL
MOV #212,(SP) ;WRITE NUMBER OF ERROR IN CALL
SUB #2,(SP) ;MOVE SP TO RETURN FOR ERROR
JSR PC,(SP)+ ;REPORT ERROR VIA USER
SUB #10,(SP) ;MOVE SP BACK TO NO ERROR
NOP

50$:
;REPORT AN ERROR IF "SKI" = 1

```

11938	061456	032737	040000	001370	BIT	#SKI,RMER2I	; IS THERE A SEEK INCOMPLETE ERROR
11939	061464	001424			BEG	60\$	; NO!!
11940	061466	013737	001370	001140	MOV	RMER2I,\$GDDAT	; EXPECTED STATUS
11941	061474	042737	040000	001140	BIC	#SKI,\$GDDAT	
11942	061502	013737	001370	001142	MOV	RMER2I,\$BDDAT	; RECEIVED STATUS
11943	061510	062716	000004		ADD	#4,(SP)	; MOVE SP TO USER'S ERROR CALL
11944	061514	112776	000213	000000	MOVB	#213,a(SP)	; WRITE ERROR NUMBER IN USER'S ERROR CALL
11945	061522	162716	000002		SUB	#2,(SP)	; MOVE SP TO RETURN FOR ERROR
11946	061526	004736			JSR	PC,a(SP)+	; REPORT ERROR VIA USER
11947	061530	162716	000010		SUB	#10,(SP)	; MOVE SP BACK TO NO ERROR
11948	061534	000240			NOP		
11949	061536						
11950							
11951							
11952	061536	062716	000004				
11953	061542	105776	000000		ADD	#4,(SP)	; AUGMENT THE RETURN ADDRESS IF ANY ERROR WAS DETECTED
11954	061546	001403			TSTB	a(SP)	; MOVE SP TO USER'S ERROR CALL
11955	061550	062716	000004		BEG	70\$	; WAS AN ERROR DETECTED??
11956	061554	000402			ADD	#4,(SP)	; NO!!
11957	061556	162716	000004		BR	80\$	; YES - MOVE SP TO USER'S ERROR RETURN
11958	061562	000240			SUB	#4,(SP)	; NO - MOVE SP TO NO ERROR RETURN
11959	061564	000207			NOP		
					RTS	PC	; RETURN TO USER



```

11960
11961
11962
11963
11964
11965
11966
11967
11968
11969
11970
11971
11972
11973
11974
11975
11976
11977
11978
11979
11980 061566
11981
11982
11983 061566 013737 001342 001176
11984 061574 047637 000000 001176
11985 061602 062716 000002
11986 061606 013737 001370 001200
11987 061614 047637 000000 001200
11988
11989
11990
11991 061622 062716 000006
11992 061626 105076 000000
11993 061632 162716 000004
11994
11995
11996 061636 005737 001176
11997 061642 001420
11998 061644 013737 001176 001142
11999 061652 005037 001140
12000 061656 062716 000004
12001 061662 112776 000066 000000
12002 061670 162716 000002
12003 061674 004736
12004 061676 162716 000010
12005 061702 000240
12006 061704
12007
12008
12009
12010 061704 005737 001200
12011 061710 001420
12012
12013 061712 013737 001200 001142
12014 061720 005037 001140
12015 061724 062716 000004

```

```

.SBTTL COMPOSITE ERROR CHECK SUBROUTINE

; THIS SUBROUTINE CHECKS THE STORED CONTENTS OF RMER1 AND
; RMER2 AFTER MASKING EACH REGISTER WORD WITH THE USER'S STATUS
; MASKS AND REPORTS AN ERROR IF ANY BITS ARE LEFT ON AFTER
; THE MASKS ARE APPLIED.

; CALL:
; (1) JSR PC, CMPERRSTS      MASK FOR ERROR REGISTER 1
;      .WORD                MASK FOR ERROR REGISTER 2
;      .WORD                RETURN HERE IF NO ERROR
;      BR                    RETURN HERE TO REPORT AN ERROR
;      NOP                  ERROR NUMBER DEFINED BY SUB
;      ERROR                GO BACK TO SUB FOR MORE ERROR CHECKS
;      JSR PC, a(SP)+       RETURN HERE IF NO MORE ERRORS
;      ???

; NOTE: BITS TO BE MASKED SHOULD BE ONE; BITS TO BE TESTED SHOULD
; BE ZERO

CMPERRSTS:
; MASK AND STORE THE CONTENTS OF RMER1 AND RMER2
MOV RMER1, $TMP1      ; STORE RMER1 AT TEMP STORAGE
BIC a(SP), $TMP1     ; MASK RMER1
ADD #2, (SP)         ; MOVE SP TO NEXT MASK
MOV RMER2, $TMP2     ; STORE RMER2 AT TEMP STORAGE
BIC a(SP), $TMP2     ; MASK RMER2

; CLEAR USER'S ERROR CALL
ADD #6, (SP)         ; MOVE SP TO USER'S ERROR CALL
CLRB a(SP)          ; CLEAR ERROR NUMBER
SUB #4, (SP)         ; LEAVE SP AT NO ERROR RETURN

; SEE IF THERE WERE ANY ERRORS IN RMER1, I.E. $TMP1
TST $TMP1           ; ANY ERRORS TO REPORT??
BEQ SS              ; NO !!
MOV $TMP1, $BDDAT   ; RECEIVED STATUS FOR TYPEOUT
CLR $GDDAT          ; EXPECTED STATUS FOR TYPEOUT
ADD #4, (SP)        ; MOVE SP TO USER'S ERROR CALL
MOVB #66, a(SP)    ; CORRECTABLE DATA CHECK ERROR #
SUB #2, (SP)        ; MOVE SP TO RETURN FOR ERROR
JSR PC, a(SP)+     ; REPORT ERROR VIA USER
SUB #10, (SP)      ; MOVE SP BACK TO BRANCH
NOP

SS:

; SEE IF THERE ARE ANY ERRORS TO REPORT IN RMER2 ($TMP2)
TST $TMP2           ; ANY ERRORS IN RMER2?
BEQ 10$            ; NO !!
MOV $TMP2, $BDDAT   ; RECEIVED STATUS FOR TYPEOUT
CLR $GDDAT          ; EXPECTED STATUS FOR TYPEOUT
ADD #4, (SP)        ; MOVE SP TO USER'S ERROR CALL

```

12016	061730	112776	000067	000000	MOVW	#67, 2(SP)	;WRITE ERROR NUMBER IN USER'S CALL
12017	061736	162716	000002		SUB	#2, (SP)	;MOVE SP TO RETURN FOR ERROR
12018	061742	004736			JSR	PC, 2(SP)+	;REPORT ERROR VIA USER
12019	061744	162716	000010		SUB	#10, (SP)	;MOVE SP TO NO ERROR RETURN
12020	061750	000240			NOP		
12021	061752						
12022							
12023							
12024	061752	062716	000004				
12025	061756	105776	000000		ADD	#4, (SP)	;MOVE SP TO USER'S ERROR CALL
12026	061762	001403			TSTB	2(SP)	;WAS THERE AN ERROR CALLED??
12027	061764	062716	000004		BEQ	20\$	;NO!!
12028	061770	000402			ADD	#4, (SP)	;YES - MOVE SP TO ERROR RETURN
12029	061772	162716	000004		BR	30\$	
12030	061776	000207		20\$:	SUB	#4, (SP)	;MOVE SP TO NO ERROR RETURN
12031				30\$:	RTS	PC	;RETURN TO USER
12032							

```

12033 .SBTTL STOP AND SHUTDOWN SUBROUTINES
12034
12035 062000 STOP:
12036
12037 ;DROP PRIORITY TO ALLOW CONSOLE INTERRUPT
12038 062000 012746 000140 MOV #PR3,-(SF) ;;PUT NEW PS ON STACK
12039 062004 012746 062012 MOV #64$,-(SP) ;;PUT NEW PC ON STACK
12040 062010 000002 RTI ;;POP NEW PC AND PS
12041 062012
12042 062012 000240 64$:
12043 NOP
12044 062014 012746 000300 ;RAISE PRIORITY TO INHIBIT INTERRUPT
12045 062020 012746 062026 MOV #PR6,-(SP) ;;PUT NEW PS ON STACK
12046 062024 000002 MOV #65$,-(SP) ;;PUT NEW PC ON STACK
12047 062026 RTI ;;POP NEW PC AND PS
12048
12049 062026 000207 10$: RTS PC ;CONTINUE
12050
12051
12052 062030 SHUT:
12053 062030 104401 062052 TYPE ,100$ ;TYPE THE HALT MESSAGE
12054 062034 005737 000042 TST 42 ;RUNNING STANDALONE ??
12055 062040 001402 BEQ 10$ ;YES !!
12056 062042 000137 042204 JMP $EOP ;NO - GO TO END OF PASS
12057 062046
12058 062046 000137 005322 10$: JMP START ;GO TO START
12059 062052 042524 052123 053440 100$: .ASCIZ @TEST WAS HALTED<CR><LF><LF>
12060 062060 051501 044040 046101
12061 062066 042524 006504 005012
12062 062074 000
12063 062076 .EVEN

```

```

12064
12065
12066
12067
12068
12069
12070
12071
12072
12073
12074
12075
12076
12077
12078
12079
12080
12081 062076
12082 062076 010046
12083 062100 010146
12084 062102 010246
12085 062104 010346
12086 062106 010446
12087 062110 010546
12088 062112 016646 000022
12089 062116 016646 000022
12090 062122 016646 000022
12091 062126 016646 000022
12092 062132 000002
12093
12094
12095
12096
12097 062134
12098 062134 012666 000022
12099 062140 012666 000022
12100 062144 012666 000022
12101 062150 012666 000022
12102 062154 012605
12103 062156 012604
12104 062160 012603
12105 062162 012602
12106 062164 012601
12107 062166 012600
12108 062170 000002
12109
12110
12111
12112
12113
12114
12115
12116
12117
12118 062172 010146
12119 062174 016601 000006

```

```

.SBTTL SAVE AND RESTORE RO-R5 ROUTINES
:*****
:SAVE RO-R5
:CALL:
: SAVREG
:UPON RETURN FROM $$SAVREG THE STACK WILL LOOK LIKE:
:
:TOP---(+16)
: +2---(+18)
: +4---R5
: +6---R4
: +8---R3
: +10---R2
: +12---R1
: +14---R0
:
$SAVREG:
MOV RO,-(SP) ;; PUSH RO ON STACK
MOV R1,-(SP) ;; PUSH R1 ON STACK
MOV R2,-(SP) ;; PUSH R2 ON STACK
MOV R3,-(SP) ;; PUSH R3 ON STACK
MOV R4,-(SP) ;; PUSH R4 ON STACK
MOV R5,-(SP) ;; PUSH R5 ON STACK
MOV 22(SP),-(SP) ;; SAVE PS OF MAIN FLOW
MOV 22(SP),-(SP) ;; SAVE PC OF MAIN FLOW
MOV 22(SP),-(SP) ;; SAVE PS OF CALL
MOV 22(SP),-(SP) ;; SAVE PC OF CALL
RTI

:RESTORE RO-R5
:CALL:
: RESREG
$RESREG:
MOV (SP)+,22(SP) ;; RESTORE PC OF CALL
MOV (SP)+,22(SP) ;; RESTORE PS OF CALL
MOV (SP)+,22(SP) ;; RESTORE PC OF MAIN FLOW
MOV (SP)+,22(SP) ;; RESTORE PS OF MAIN FLOW
MOV (SP)+,R5 ;; POP STACK INTO R5
MOV (SP)+,R4 ;; POP STACK INTO R4
MOV (SP)+,R3 ;; POP STACK INTO R3
MOV (SP)+,R2 ;; POP STACK INTO R2
MOV (SP)+,R1 ;; POP STACK INTO R1
MOV (SP)+,R0 ;; POP STACK INTO R0
RTI

.SBTTL BINARY TO ASCII AND TYPE ROUTINE
:*****
:THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 16-BIT
: BINARY-ASCII NUMBER AND TYPE IT.
:CALL:
: MOV NUMBER,-(SP) ;; NUMBER TO BE TYPED
: TYPBN ;; TYPE IT
$TYPBN: MOV R1,-(SP) ;; SAVE R1 ON THE STACK
MOV 6(SP),R1 ;; GET THE INPUT NUMBER

```

```

12120 062200 000261          SEC                ;; SET "C" SO CAN KEEP TRACK OF THE NUMBER OF BITS
12121 062202 112737 000060 062244 1$:  MOVB          #'0,$BIN  ;; SET CHARACTER TO AN ASCII "0".
12122 062210 006101          ROL            R1        ;; GET THIS BIT
12123 062212 001406          BEQ            2$        ;; DONE?
12124 062214 105537 062244  ADCB          $BIN        ;; NO--SET THE CHARACTER EQUAL TO THIS BIT
12125 062220 104401 062244  TYPE          , $BIN      ;; GO TYPE THIS BIT
12126 062224 000241          CLC            ;; CLEAR "C" SO CAN KEEP TRACK OF BITS
12127 062226 000765          BR            1$        ;; GO DO THE NEXT BIT
12128 062230 012601          MOV            (SP)+,R1  ;; POP THE STACK INTO R1
12129 062232 016666 000002 000004 2$:  MOV            2(SP),4(SP) ;; ADJUST THE STACK
12130 062240 012616          MOV            (SP)+,(SP)
12131 062242 000002          RTI            ;; RETURN TO USER
12132 062244          000          000  $BIN: .BYTE 0,0  ;; STORAGE FOR ASCII CHAR. AND TERMINATOR
12133          .SBTTL CONVERT BINARY TO DECIMAL AND TYPE ROUTINE
12134
12135          ;; *****
12136          ;; *THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 5-DIGIT
12137          ;; *SIGNED DECIMAL (ASCII) NUMBER AND TYPE IT. DEPENDING ON WHETHER THE
12138          ;; *NUMBER IS POSITIVE OR NEGATIVE A SPACE OR A MINUS SIGN WILL BE TYPED
12139          ;; *BEFORE THE FIRST DIGIT OF THE NUMBER. LEADING ZEROS WILL ALWAYS BE
12140          ;; *REPLACED WITH SPACES.
12141          ;; *CALL:
12142          ;; *      MOV      NUM,-(SP)  ;; PUT THE BINARY NUMBER ON THE STACK
12143          ;; *      TYPDS  ;; GO TO THE ROUTINE
12144
12145          $TYPDS:
12146 062246 010046          MOV            R0,-(SP)  ;; PUSH R0 ON STACK
12147 062250 010146          MOV            R1,-(SP)  ;; PUSH R1 ON STACK
12148 062252 010246          MOV            R2,-(SP)  ;; PUSH R2 ON STACK
12149 062254 010346          MOV            R3,-(SP)  ;; PUSH R3 ON STACK
12150 062256 010546          MOV            R5,-(SP)  ;; PUSH R5 ON STACK
12151 062260 012746 020200  MOV            #20200,-(SP) ;; SET BLANK SWITCH AND SIGN
12152 062264 016605 000020  MOV            20(SP),R5  ;; GET THE INPUT NUMBER
12153 062270 100004          BPL            1$        ;; BR IF INPUT IS POS.
12154 062272 005405          NEG            R5        ;; MAKE THE BINARY NUMBER POS.
12155 062274 112766 000055 000001 1$:  MOVB          #'-,1(SP)  ;; MAKE THE ASCII NUMBER NEG.
12156 062302 005000          CLR            R0        ;; ZERO THE CONSTANTS INDEX
12157 062304 012703 062462  MOV            $DBLK,R3  ;; SETUP THE OUTPUT POINTER
12158 062310 112723 000040  MOVB          #' ,(R3)+  ;; SET THE FIRST CHARACTER TO A BLANK
12159 062314 005002          CLR            R2        ;; CLEAR THE BCD NUMBER
12160 062316 016001 062452  MOV            $DTBL(R0),R1 ;; GET THE CONSTANT
12161 062322 160105          SUB            R1,R5     ;; FORM THIS BCD DIGIT
12162 062324 002402          BLT            4$        ;; BR IF DONE
12163 062326 005202          INC            R2        ;; INCREASE THE BCD DIGIT BY 1
12164 062330 000774          BR            3$
12165 062332 060105          ADD            R1,R5     ;; ADD BACK THE CONSTANT
12166 062334 005702          TST            R2        ;; CHECK IF BCD DIGIT=0
12167 062336 001002          BNE            5$        ;; FALL THROUGH IF 0
12168 062340 105716          TSTB          (SP)      ;; STILL DOING LEADING 0'S?
12169 062342 100407          BMI            7$        ;; BR IF YES
12170 062344 106316          ASLB          (SP)      ;; MSD?
12171 062346 103003          BCC            6$        ;; BR IF NO
12172 062350 116663 000001 177777 6$:  MOVB          1(SP),-1(R3) ;; YES--SET THE SIGN
12173 062356 052702 000060  BIS            #'0,R2    ;; MAKE THE BCD DIGIT ASCII
12174 062362 052702 000040  BIS            #' ,R2    ;; MAKE IT A SPACE IF NOT ALREADY A DIGIT
12175 062366 110223          MOVB          R2,(R3)+  ;; PUT THIS CHARACTER IN THE OUTPUT BUFFER

```

```

12176 062370 005720          TST      (R0)+          ;; JUST INCREMENTING
12177 062372 020027 000010  CMP      R0,#10        ;; CHECK THE TABLE INDEX
12178 062376 002746          BLT      2$           ;; GO DO THE NEXT DIGIT
12179 062400 003002          BGT      8$           ;; GO TO EXIT
12180 062402 010502          MOV      R5,R2        ;; GET THE LSD
12181 062404 000764          BR       6$           ;; GO CHANGE TO ASCII
12182 062406 105726          8$: TSTB     (SP)+          ;; WAS THE LSD THE FIRST NON-ZERO?
12183 062410 100003          BPL      9$           ;; BR IF NO
12184 062412 116663 177777 177776  MOVB     -1(SP),-2(R3) ;; YES--SET THE SIGN FOR TYPING
12185 062420 105013          9$: CLRB     (R3)        ;; SET THE TERMINATOR
12186 062422 012605          MOV      (SP)+,R5     ;; POP STACK INTO R5
12187 062424 012603          MOV      (SP)+,R3     ;; POP STACK INTO R3
12188 062426 012602          MOV      (SP)+,R2     ;; POP STACK INTO R2
12189 062430 012601          MOV      (SP)+,R1     ;; POP STACK INTO R1
12190 062432 012600          MOV      (SP)+,R0     ;; POP STACK INTO R0
12191 062434 104401 062462  TYPE      $DBLK        ;; NOW TYPE THE NUMBER
12192 062440 016666 000002 000004  MOV      2(SP),4(SP)   ;; ADJUST THE STACK
12193 062446 012616          MOV      (SP)+,(SP)   ;;
12194 062450 000002          RTI                    ;; RETURN TO USER
12195 062452 023420          $DTBL: 10000.
12196 062454 001750          1000.
12197 062456 000144          100.
12198 062460 000012          10.
12199 062462 000004          $DBLK: .BLKW 4
          .SBTTL BINARY TO OCTAL (ASCII) AND TYPE
12200
12201
12202
12203
12204
12205
12206
12207
12208
12209
12210
12211
12212
12213
12214
12215
12216
12217
12218
12219
12220
12221
12222
12223
12224
12225 062472 017646 000000          *
12226 062476 116637 000001 062715  * *****
12227 062504 112637 062717          * THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 6-DIGIT
12228 062510 062716 000002          * OCTAL (ASCII) NUMBER AND TYPE IT.
12229 062514 000406          * $TYPOS---ENTER HERE TO SETUP SUPPRESS ZEROS AND NUMBER OF DIGITS TO TYPE
12230 062516 112737 000001 062715  *
12231 062524 112737 000006 062717  *
          *CALL:
          *   MOV      NUM,-(SP)          ;; NUMBER TO BE TYPED
          *   TYPOS          ;; CALL FOR TYPEOUT
          *   .BYTE  N          ;; N=1 TO 6 FOR NUMBER OF DIGITS TO TYPE
          *   .BYTE  M          ;; M=1 OR 0
          *                                     ;; 1=TYPE LEADING ZEROS
          *                                     ;; 0=SUPPRESS LEADING ZEROS
          *
          * $TYPON---ENTER HERE TO TYPE OUT WITH THE SAME PARAMETERS AS THE LAST
          * $TYPOS OR $TYPOC
          *CALL:
          *   MOV      NUM,-(SP)          ;; NUMBER TO BE TYPED
          *   TYPON          ;; CALL FOR TYPEOUT
          *
          * $TYPOC---ENTER HERE FOR TYPEOUT OF A 16 BIT NUMBER
          *CALL:
          *   MOV      NUM,-(SP)          ;; NUMBER TO BE TYPED
          *   TYPOC          ;; CALL FOR TYPEOUT
          *
          * $TYPOS: MOV      2(SP),-(SP)      ;; PICKUP THE MODE
          *           MOVB     1(SP),$OFILL   ;; LOAD ZERO FILL SWITCH
          *           MOVB     (SP)+,$OMODE+1 ;; NUMBER OF DIGITS TO TYPE
          *           ADD      #2,(SP)      ;; ADJUST RETURN ADDRESS
          *           BR       $TYPON
          * $TYPOC: MOVB     #1,$OFILL      ;; SET THE ZERO FILL SWITCH
          *           MOVB     #6,$OMODE+1  ;; SET FOR SIX(6) DIGITS

```

```

12232 062532 112737 000005 062714 $TYPON: MOVB #5,$OCNT      ;; SET THE ITERATION COUNT
12233 062540 010346          MOV R3,-(SP)      ;; SAVE R3
12234 062542 010446          MOV R4,-(SP)      ;; SAVE R4
12235 062544 010546          MOV R5,-(SP)      ;; SAVE R5
12236 062546 113704 062717  MOVB $OMODE+1,R4  ;; GET THE NUMBER OF DIGITS TO TYPE
12237 062552 005404          NEG R4
12238 062554 062704 000006  ADD #6,R4        ;; SUBTRACT IT FOR MAX. ALLOWED
12239 062560 110437 062716  MOVB R4,$OMODE  ;; SAVE IT FOR USE
12240 062564 113704 062715  MOVB $OFILL,R4  ;; GET THE ZERO FILL SWITCH
12241 062570 016605 000012  MOV 12(SP),R5  ;; PICKUP THE INPUT NUMBER
12242 062574 005003          CLR R3          ;; CLEAR THE OUTPUT WORD
12243 062576 006105          1$: ROL R5    ;; ROTATE MSB INTO "C"
12244 062600 000404          BR 3$         ;; GO DO MSB
12245 062602 006105          2$: ROL R5    ;; FORM THIS DIGIT
12246 062604 006105          ROL R5
12247 062606 006105          ROL R5
12248 062610 010503          MOV R5,R3
12249 062612 006103          3$: ROL R3    ;; GET LSB OF THIS DIGIT
12250 062614 105337 062716  DECB $OMODE    ;; TYPE THIS DIGIT?
12251 062620 100016          BPL 7$        ;; BR IF NO
12252 062622 042703 177770  BIC #177770,R3 ;; GET RID OF JUNK
12253 062626 001002          BNE 4$        ;; TEST FOR 0
12254 062630 005704          TST R4        ;; SUPPRESS THIS 0?
12255 062632 001403          BEQ 5$        ;; BR IF YES
12256 062634 005204          4$: INC R4    ;; DON'T SUPPRESS ANYMORE 0'S
12257 062636 052703 000060  BIS #'0,R3    ;; MAKE THIS DIGIT ASCII
12258 062642 052703 000040  5$: BIS #'R3  ;; MAKE ASCII IF NOT ALREADY
12259 062646 110337 062712  MOVB R3,$S    ;; SAVE FOR TYPING
12260 062652 104401 062712  TYPE #8$     ;; GO TYPE THIS DIGIT
12261 062656 105337 062714  7$: DECB $OCNT ;; COUNT BY 1
12262 062662 003347          BGT 2$        ;; BR IF MORE TO DO
12263 062664 002402          BLT 6$        ;; BR IF DONE
12264 062666 005204          INC R4        ;; INSURE LAST DIGIT ISN'T A BLANK
12265 062670 000744          BR 2$        ;; GO DO THE LAST DIGIT
12266 062672 012605          6$: MOV (SP)+,R5  ;; RESTORE R5
12267 062674 012604          MOV (SP)+,R4  ;; RESTORE R4
12268 062676 012603          MOV (SP)+,R3  ;; RESTORE R3
12269 062700 016666 000002 000004  MOV 2(SP),4(SP) ;; SET THE STACK FOR RETURNING
12270 062706 012616          MOV (SP)+,(SP)
12271 062710 000002          RTI
12272 062712 000          8$: .BYTE 0   ;; RETURN
12273 062713 000          .BYTE 0   ;; STORAGE FOR ASCII DIGIT
12274 062714 000          $OCNT: .BYTE 0 ;; TERMINATOR FOR TYPE ROUTINE
12275 062715 000          $OFILL: .BYTE 0 ;; OCTAL DIGIT COUNTER
12276 062716 000000          $OMODE: .WORD 0 ;; ZERO FILL SWITCH
12277          .SBTTL TYPE ROUTINE ;; NUMBER OF DIGITS TO TYPE
12278
12279          ;; *****
12280          ;; *ROUTINE TO TYPE ASCII MESSAGE. MESSAGE MUST TERMINATE WITH A 0 BYTE.
12281          ;; *THE ROUTINE WILL INSERT A NUMBER OF NULL CHARACTERS AFTER A LINE FEED.
12282          ;; *NOTE1: $NULL CONTAINS THE CHARACTER TO BE USED AS THE FILLER CHARACTER.
12283          ;; *NOTE2: $FILLS CONTAINS THE NUMBER OF FILLER CHARACTERS REQUIRED.
12284          ;; *NOTE3: $FILLC CONTAINS THE CHARACTER TO FILL AFTER.
12285          ;; *
12286          ;; *CALL:
12287          ;; *1) USING A TRAP INSTRUCTION

```

```

;*
;*OR
;*
;*
;*
;TYPE ROUTINE
;MESADR IS FIRST ADDRESS OF AN ASCIZ STRING
;TYPE ,MESADR
;TYPE MESADR
;TYPE: TSTB $STPFLG ;: IS THERE A TERMINAL?
;BPL 1$ ;: BR IF YES
;HALT ;: HALT HERE IF NO TERMINAL
;BR 3$ ;: LEAVE
;MOV RO,-(SP) ;: SAVE RO
;MOV 22(SP),RO ;: GET ADDRESS OF ASCIZ STRING
;CMPB #APTENV,$ENV ;: RUNNING IN APT MODE
;BNE 62$ ;: NO GO CHECK FOR APT CONSOLE
;BITB #APTSPool,$ENVM ;: SPOOL MESSAGE TO APT
;BEQ 62$ ;: NO GO CHECK FOR CONSOLE
;MOV RO,61$ ;: SETUP MESSAGE ADDRESS FOR APT
;JSR PC,$ATY3 ;: SPOOL MESSAGE TO APT
; .WORD 0 ;: MESSAGE ADDRESS
;BITB #APTC SUP,$ENVM ;: APT CONSOLE SUPPRESSED
;BNE 60$ ;: YES, SKIP TYPE OUT
;MOVB (RO)+,-(SP) ;: PUSH CHARACTER TO BE TYPED ONTO STACK
;BNE 4$ ;: BR IF IT ISN'T THE TERMINATOR
;TST (SP)+ ;: IF TERMINATOR POP IT OFF THE STACK
;MOV (SP)+,RO ;: RESTORE RO
;ADD #2,(SP) ;: ADJUST RETURN PC
;RTI ;: RETURN
;CMPB #HT,(SP) ;: BRANCH IF <HT>
;BEQ 8$ ;: BRANCH IF NOT <CRLF>
;CMPB #CRLF,(SP) ;: BRANCH IF NOT <CRLF>
;BNE 5$ ;: POP <CR><LF> EQUIV
;TST (SP)+ ;: TYPE A CR AND LF
;TYPE $CRLF ;: CLEAR CHARACTER COUNT
;CLR B $CHARCNT ;: GET NEXT CHARACTER
;BR 2$ ;: GO TYPE THIS CHARACTER
;JSR PC,$TYPEC ;: GO TYPE THIS CHARACTER
;CMPB $FILLC,(SP)+ ;: IS IT TIME FOR FILLER CHARS.?
;BNE 2$ ;: IF NO GO GET NEXT CHAR.
;MOV $NULL,-(SP) ;: GET # OF FILLER CHARS. NEEDED
; ;: AND THE NULL CHAR.
; ;: DOES A NULL NEED TO BE TYPED?
; ;: BR IF NO--GO POP THE NULL OFF OF STACK
; ;: GO TYPE A NULL
; ;: DO NOT COUNT AS A COUNT
; ;: LOOP
;HORIZONTAL TAB PROCESSOR
; ;: REPLACE TAB WITH SPACE
; ;: TYPE A SPACE
; ;: BRANCH IF NOT AT
; ;: TAB STOP
; ;: POP SPACE OFF STACK
; ;: GET NEXT CHARACTER
; ;: WAIT UNTIL PRINTER IS READY
8$: MOVB #' (SP) ;: REPLACE TAB WITH SPACE
9$: JSR PC,$TYPEC ;: TYPE A SPACE
;BITB #7,$CHARCNT ;: BRANCH IF NOT AT
;BNE 9$ ;: TAB STOP
;TST (SP)+ ;: POP SPACE OFF STACK
;BR 2$ ;: GET NEXT CHARACTER
;TYPEC: TSTB $STPS ;: WAIT UNTIL PRINTER IS READY

```



```

12344 063136 100375          BPL      $STPEC
12345 063140 116677 000002 116020  MOVB    2(SP),@STPB      ;; LOAD CHAR TO BE TYPED INTO DATA REG.
12346 063146 122766 000015 000002  CMPB    #CR,2(SP)      ;; IS CHARACTER A CARRIAGE RETURN?
12347 063154 001003          BNE     1$             ;; BRANCH IF NO
12348 063156 105037 063176  CLRB    $CHARCNT      ;; YES--CLEAR CHARACTER COUNT
12349 063162 000406          BR      $TYPEX        ;; EXIT
12350 063164 122766 000012 000002 1$:  CMPB    #LF,2(SP)      ;; IS CHARACTER A LINE FEED?
12351 063172 001402          BEQ     $TYPEX        ;; BRANCH IF YES
12352 063174 105227          INCB   (PC)+         ;; COUNT THE CHARACTER
12353 063176 000000          $CHARCNT: .WORD    0 ;; CHARACTER COUNT STORAGE
12354 063200 000207          $TYPEX: RTS         PC
12355
12356          .SBTTL  SCOPE HANDLER ROUTINE
12357
12358          ;; *****
12359          ;; THIS ROUTINE CONTROLS THE LOOPING OF SUBTESTS. IT WILL INCREMENT
12360          ;; AND LOAD THE TEST NUMBER($STNM) INTO THE DISPLAY REG.(DISPLAY<7:0>)
12361          ;; AND LOAD THE ERROR FLAG ($ERFLG) INTO DISPLAY<15:08>
12362          ;; THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
12363          ;; *SW14=1      LOOP ON TEST
12364          ;; *SW11=1      INHIBIT ITERATIONS
12365          ;; *SW09=1      LOOP ON ERROR
12366          ;; *SW08=1      LOOP ON TEST IN SWR<7:0>
12367          ;; *CALL
12368          ;; *          SCOPE          ;; SCOPE=IOT
12369
12370          $SCOPE:
12371 063202 104410          CKSWR          ;; TEST FOR CHANGE IN SOFT-SWR
12372 063204 004737 062000 115736 1$:  JSR     PC_STOP      ;; LOOP ON PRESENT TEST?
12373 063210 032777 040000          BIT     #BIT14,@SWR  ;; YES IF SW14=1
12374 063216 001131          BNE     $OVER       ;; TESTER*****
12375          ;; *****START OF CODE FOR THE XOR TESTER*****
12376 063220 000416          $XTSTR: BR     6$    ;; IF RUNNING ON THE "XOR" TESTER CHANGE
12377          ;; THIS INSTRUCTION TO A "NOP" (NOP=240)
12378 063222 013746 000004          MOV     @#ERRVEC,-(SP) ;; SAVE THE CONTENTS OF THE ERROR VECTOR
12379 063226 012737 063246 000004          MOV     #5,@#ERRVEC  ;; SET FOR TIMEOUT
12380 063234 005737 177060          TST    @#177060     ;; TIME OUT ON XOR?
12381 063240 012637 000004          MOV     (SP)+,@#ERRVEC ;; RESTORE THE ERROR VECTOR
12382 063244 000500          BR      $$VLAD      ;; GO TO THE NEXT TEST
12383 063246 022626          $$:  CMP     (SP)+,(SP)+ ;; CLEAR THE STACK AFTER A TIME OUT
12384 063250 012637 000004          MOV     (SP)+,@#ERRVEC ;; RESTORE THE ERROR VECTOR
12385 063254 000440          BR      7$         ;; LOOP ON THE PRESENT TEST
12386 063256          6$:; *****END OF CODE FOR THE XOR TESTER*****
12387 063256 032777 000400 115670          BIT     #BIT08,@SWR  ;; LOOP ON SPEC. TEST?
12388 063264 001421          BEQ     2$         ;; BR IF NO
12389 063266 005046          CLR     -(SP)      ;; CLEAR A TEMP. LOCATION
12390 063270 117716 115660          MOVB   @SWR,(SP)   ;; PICKUP THE DESIRED TEST NUMBER
12391 063274 001414          BEQ     8$         ;; BRANCH IF BAD TEST NUMBER IN SWR
12392 063276 022716 000072          CMP     #72,(SP)   ;; CHECK THE NUMBER IN THE SWR
12393 063302 002411          BLT    8$         ;; BRANCH IF TEST NUMBER IS OUT OF RANGE
12394 063304 011637 001116          MOV     (SP),$STNM ;; UPDATE THE TEST NUMBER
12395 063310 005316          DEC    (SP)       ;; BACKUP BY ONE
12396 063312 006316          ASL    (SP)       ;; SCALE THE TEST NUMBER AS AN INDEX
12397 063314 062716 063520          ADD    #$$SWOBTBL,(SP) ;; FORM THE ADDRESS OF TEST POINTER
12398 063320 013637 001122          MOV    @($SP)+,$LPADR ;; SET LOOP ADDRESS TO DESIRED TEST
12399 063324 000466          BR     $OVER      ;; GO LOOP ON THE TEST

```

12400	063326	005726		8\$:	TST	(SP)+	;; CLEAN THE BAD TEST NUMBER OFF OF THE STACK
12401	063330	105737	001117	2\$:	TSTB	SERFLG	;; HAS AN ERROR OCCURRED?
12402	063334	001421			BEQ	3\$	;; BR IF NO
12403	063336	123737	001131 001117		CMPB	SERMAX, SERFLG	;; MAX. ERRORS FOR THIS TEST OCCURRED?
12404	063344	101015			BHI	3\$	;; BR IF NO
12405	063346	032777	001000 115600		BIT	#BIT09, ASWR	;; LOOP ON ERROR?
12406	063354	001404			BEQ	4\$	;; BR IF NO
12407	063356	013737	001124 001122	7\$:	MOV	\$LPERR, \$LPADR	;; SET LOOP ADDRESS TO LAST SCOPE
12408	063364	000446			BR	\$OVER	
12409	063366	105037	001117	4\$:	CLRB	SERFLG	;; ZERO THE ERROR FLAG
12410	063372	005037	001206		CLR	\$TIMES	;; CLEAR THE NUMBER OF ITERATIONS TO MAKE
12411	063376	000415			BR	1\$	;; ESCAPE TO THE NEXT TEST
12412	063400	032777	004000 115546	3\$:	BIT	#BIT11, ASWR	;; INHIBIT ITERATIONS?
12413	063406	001011			BNE	1\$	;; BR IF YES
12414	063410	005737	001230		TST	\$PASS	;; IF FIRST PASS OF PROGRAM
12415	063414	001406			BEQ	1\$	;; INHIBIT ITERATIONS
12416	063416	005237	001120		INC	\$ICNT	;; INCREMENT ITERATION COUNT
12417	063422	023737	001206 001120		CMP	\$TIMES, \$ICNT	;; CHECK THE NUMBER OF ITERATIONS MADE
12418	063430	002024			BGE	\$OVER	;; BR IF MORE ITERATION REQUIRED
12419	063432	012737	000001 001120	1\$:	MOV	#1, \$ICNT	;; REINITIALIZE THE ITERATION COUNTER
12420	063440	013737	063516 001206		MOV	\$MXCNT, \$TIMES	;; SET NUMBER OF ITERATIONS TO DO
12421	063446	105237	001116	\$SVLAD:	INCB	\$STNM	;; COUNT TEST NUMBERS
12422	063452	113737	001116 001226		MOVB	\$STNM, \$TESTN	;; SET TEST NUMBER IN APT MAILBOX
12423	063460	011637	001122		MOV	(SP), \$LPADR	;; SAVE SCOPE LOOP ADDRESS
12424	063464	011637	001124		MOV	(SP), \$LPERR	;; SAVE ERROR LOOP ADDRESS
12425	063470	005037	001210		CLR	\$ESCAPE	;; CLEAR THE ESCAPE FROM ERROR ADDRESS
12426	063474	112737	000001 001131		MOVB	#1, SERMAX	;; ONLY ALLOW ONE(1) ERROR ON NEXT TEST
12427	063502	013777	001116 115446	\$OVER:	MOV	\$STNM, \$DISPLAY	;; DISPLAY TEST NUMBER
12428	063510	013716	001122		MOV	\$LPADR, (SP)	;; FUDGE RETURN ADDRESS
12429	063514	000002			RTI		;; FIXES PS
12430	063516	000012			\$MXCNT:	10.	;; MAX. NUMBER OF ITERATIONS
12431	063520				\$SWOBTBL:		
12432	063520	007142			.WORD	TST1+2	;; STARTING ADDRESS OF TEST 1
12433	063522	007340			.WORD	TST2+2	;; STARTING ADDRESS OF TEST 2
12434	063524	007524			.WORD	TST3+2	;; STARTING ADDRESS OF TEST 3
12435	063526	007706			.WORD	TST4+2	;; STARTING ADDRESS OF TEST 4
12436	063530	010572			.WORD	TST5+2	;; STARTING ADDRESS OF TEST 5
12437	063532	011130			.WORD	TST6+2	;; STARTING ADDRESS OF TEST 6
12438	063534	011334			.WORD	TST7+2	;; STARTING ADDRESS OF TEST 7
12439	063536	011660			.WORD	TST10+2	;; STARTING ADDRESS OF TEST 10
12440	063540	012040			.WORD	TST11+2	;; STARTING ADDRESS OF TEST 11
12441	063542	013112			.WORD	TST12+2	;; STARTING ADDRESS OF TEST 12
12442	063544	013412			.WORD	TST13+2	;; STARTING ADDRESS OF TEST 13
12443	063546	013644			.WORD	TST14+2	;; STARTING ADDRESS OF TEST 14
12444	063550	014166			.WORD	TST15+2	;; STARTING ADDRESS OF TEST 15
12445	063552	014512			.WORD	TST16+2	;; STARTING ADDRESS OF TEST 16
12446	063554	014770			.WORD	TST17+2	;; STARTING ADDRESS OF TEST 17
12447	063556	015262			.WORD	TST20+2	;; STARTING ADDRESS OF TEST 20
12448	063560	015532			.WORD	TST21+2	;; STARTING ADDRESS OF TEST 21
12449	063562	015762			.WORD	TST22+2	;; STARTING ADDRESS OF TEST 22
12450	063564	016306			.WORD	TST23+2	;; STARTING ADDRESS OF TEST 23
12451	063566	016726			.WORD	TST24+2	;; STARTING ADDRESS OF TEST 24
12452	063570	017272			.WORD	TST25+2	;; STARTING ADDRESS OF TEST 25
12453	063572	017664			.WORD	TST26+2	;; STARTING ADDRESS OF TEST 26
12454	063574	020340			.WORD	TST27+2	;; STARTING ADDRESS OF TEST 27
12455	063576	020672			.WORD	TST30+2	;; STARTING ADDRESS OF TEST 30



```

12512 063736 005237 001126      1S:   INC      SERTTL      ;; COUNT THE NUMBER OF ERRORS
12513 063742 011637 001132      MOV      (SP),SERRPC  ;; GET ADDRESS OF ERROR INSTRUCTION
12514 063746 162737 000002 001132  SUB      #2,SERRPC
12515 063754 117737 115152 001130  MOV      #SERRPC,$ITEMB ;; STRIP AND SAVE THE ERROR ITEM CODE
12516 063762 032777 020000 115164  BIT      #BIT13,$SWR    ;; SKIP TIMEOUT IF SET
12517 063770 001004          BNE      #0$           ;; SKIP TIMEOUTS
12518 063772 004737 042414  JSR      PC,ERRTP      ;; GO TO USER ERROR ROUTINE
12519 063776 104401 001217          TYPE      ,SCLF
12520 064002          20S:
12521 064002 122737 000001 001242  CMP      #APTENV,$ENV  ;; RUNNING IN APT MODE
12522 064010 001007          BNE      #2$           ;; NO SKIP APT ERROR REPORT
12523 064012 113737 001130 064024  MOV      $ITEMB,21$    ;; SET ITEM NUMBER AS ERROR NUMBER
12524 064020 004737 065746          JSR      PC,$ATY4      ;; REPORT FATAL ERROR TO APT
12525 064024          21S:
12526 064025          .BYTE    0
12527 064026          .BYTE    0
12528 064030 000777          BR       #22$          ;; APT ERROR LOOP
12529 064034 005777 115120 2S:      TST      #SWR          ;; HALT ON ERROR
12530 064036 100002          BPL      #3$           ;; SKIP IF CONTINUE
12531 064040 104410          HALT     #0$           ;; HALT ON ERROR!
12532 064042 032777 001000 115104 3S:      CKSWR
12533 064050 001402          BIT      #BIT09,$SWR  ;; TEST FOR CHANGE IN SOFT-SWR
12534 064052 013716 001124          BEQ      #4$           ;; LOOP ON ERROR SWITCH SET?
12535 064054 005737 001210 4S:      MOV      $LPERB,(SP)  ;; BR IF NO
12536 064062 001402          TST      $ESCAPE      ;; FUDGE RETURN FOR LOOPING
12537 064064 013716 001210 5S:      BEQ      #5$           ;; CHECK FOR AN ESCAPE ADDRESS
12538 064070          MOV      $ESCAPE,(SP) ;; BR IF NONE
12539 064070 022737 042374 000042 6S:      CMP      #SENDAD,#42  ;; FUDGE RETURN ADDRESS FOR ESCAPE
12540 064076 001001          BNE      #6$           ;; ACT-11 AUTO-ACCEPT?
12541 064100 000000          HALT     #0$           ;; BRANCH IF NO
12542 064102          6S:
12543 064102 000002          RTI          ;; RETURN
12544          .SBTTL  TTY INPUT ROUTINE
12545          ;; *****
12546          ENABL  LSB
12547          $TKCNT: .WORD 0      ;; NUMBER OF ITEMS IN QUEUE
12548 064104 000000          $TKQIN: .WORD 0      ;; INPUT POINTER
12549 064106 000000          $TKQOUT: .WORD 0     ;; OUTPUT POINTER
12550 064110 000000          $TKQSRV: .BLKB 1     ;; TTY KEYBOARD QUEUE
12551 064112 000001          $TKQEND=.
12552          .EVEN
12553
12554          ;; *TK INITIALIZE ROUTINE
12555          ;; *THIS ROUTINE WILL INITIALIZE THE TTY KEYBOARD INPUT QUEUE
12556          ;; *SETUP THE INTERRUPT VECTOR AND TURN ON THE KEYBOARD INTERRUPT
12557
12558          ;; *CALL:
12559          ;; *      JSR      PC,$TKINT
12560          ;; *      RETURN
12561
12562          $TKINT: CLR      $TKCNT      ;; CLEAR COUNT OF ITEMS IN QUEUE
12563 064114 005037 064104          MOV      #TKQSRV,$TKQIN ;; MOVE THE STARTING ADDRESS OF THE
12564 064120 012737 064112 064106  MOV      $TKQIN,$TKQOUT ;; QUEUE INTO THE INPUT & OUTPUT POINTERS.
12565 064126 013737 064106 064110  MOV      #TKSRV,$TKVEC  ;; INITIALIZE THE KEYBOARD VECTOR
12566 064134 012737 064164 000060  MOV      #200,$TKVEC+2 ;; "BR" LEVEL 4
12567 064142 012737 000200 000062

```

```

12568 064150 005777 115006          TST      @STKB          ;; CLEAR DONE FLAG
12569 064154 012777 000100 114776  MOV      @100,@STKS    ;; ENABLE TTY KEYBOARD INTERRUPT
12570 064162 000207                RTS      PC             ;; RETURN TO CALLER
12571
12572          ;; *TK SERVICE ROUTINE
12573          ;; *THIS ROUTINE WILL SERVICE THE TTY KEYBOARD INTERRUPT
12574          ;; *BY READING THE CHARACTER FROM THE INPUT BUFFER AND PUTTING
12575          ;; *IT IN THE QUEUE.
12576          ;; *IF THE CHARACTER IS A "CONTROL-C" (^C) STKINT IS CALLED AND
12577          ;; *UPON RETURN EXIT IS MADE TO THE "CONTROL-C" RESTART ADDRESS (SHUT)
12578
12579 064164 117746 114772  $TKSRV: MOVB   @STKB,-(SP)  ;; PICKUP THE CHARACTER
12580 064170 042716 177600      BIC      @1C177,(SP)    ;; STRIP THE JUNK
12581 064174 021627 000003      CMP      (SP),#3       ;; IS IT A CONTROL C?
12582 064200 001007                BNE      1$            ;; BRANCH IF NO
12583 064202 104401 065300      TYPE    @SCNTLC       ;; TYPE A CONTROL-C (^C)
12584 064206 004737 064114      JSR     PC,STKINT     ;; INIT THE KEYBOARD
12585 064212 005726                TST      (SP)+         ;; CLEAN UP STACK
12586 064214 000137 062030      JMP     SHUT          ;; CONTROL C RESTART
12587 064220 021627 000007 1$:    CMP      (SP),#7       ;; IS IT A CONTROL G?
12588 064224 001004                BNE      2$            ;; BRANCH IF NO
12589 064226 022737 000176 001154    CMP      @SWREG,SWR    ;; IS SOFT-SWR SELECTED?
12590 064234 001500                BEQ     6$            ;; GO TO SWR CHANGE
12591
12592 064236                2$:    CMP      #1,STKCNT    ;; IS THE QUEUE FULL?
12593 064236 022737 000001 064104    BNE      3$            ;; BRANCH IF NO
12594 064244 001004                TYPE    @SBELL        ;; RING THE TTY BELL
12595 064246 104401 001212      TST     (SP)+         ;; CLEAN CHARACTER OFF OF STACK
12596 064252 005726                BR      5$            ;; EXIT
12597 064254 000451                3$:    CMP      (SP),#23    ;; IS IT A CONTROL-S?
12598 064256 021627 000023    BNE      32$          ;; BRANCH IF NO
12599 064262 001021                CLR     @STKS         ;; DISABLE TTY KEYBOARD INTERRUPTS
12600 064264 005077 114670      TST     (SP)+         ;; CLEAN CHAR OFF STACK
12601 064270 005726                TSTB   @STKS         ;; WAIT FOR A CHAR
12602 064272 105777 114662 31$:   BPL     31$          ;; LOOP UNTIL ITS THERE
12603 064276 100375                MOVB   @STKB,-(SP)    ;; GET THE CHARACTER
12604 064300 117746 114656      BIC     @1C177,(SP)  ;; MAKE IT 7-BIT ASCII
12605 064304 042716 177600      CMP     (SP)+,#21    ;; IS IT A CONTROL-Q?
12606 064310 022627 000021    BNE     31$          ;; BRANCH IF NO
12607 064314 001366                MOV     @100,@STKS    ;; REENABLE TTY KEYBOARD INTERRUPTS
12608 064316 012777 000100 114634    RTI                    ;; RETURN
12609 064324 000002                32$:  INC     STKCNT        ;; COUNT THIS CHARACTER
12610 064326 005237 064104      CMP     (SP),#140    ;; IS IT UPPER CASE?
12611 064332 021627 000140      BLT     4$            ;; BRANCH IF YES
12612 064336 002405                CMP     (SP),#175    ;; IS IT A SPECIAL CHAR?
12613 064340 021627 000175      BGT     4$            ;; BRANCH IF YES
12614 064344 003002                BIC     #40,(SP)     ;; MAKE IT UPPER CASE
12615 064346 042716 000040      MOVB   (SP)+,@STKQIN ;; AND PUT IT IN QUEUE
12616 064352 112677 177530 4$:    INC     STKQIN        ;; UPDATE THE POINTER
12617 064356 005237 064106      CMP     STKQIN,@STKQEND ;; GO OFF THE END?
12618 064362 023727 064106 064113    BNE     5$            ;; BRANCH IF NO
12619 064370 001003                MOV     @STKQSRST,STKQIN ;; RESET THE POINTER
12620 064372 012737 064112 064106 5$:    RTI                    ;; RETURN
12621 064400 000002
12622
12623          ;; *****

```

```

12624
12625
12626
12627
12628 064402 022737 000176 001154
12629 064410 001124
12630 064412 105777 114542
12631 064416 100121
12632 064420 117746 114536
12633 064424 042716 177600
12634 064430 021627 000007
12635 064434 001300
12636
12637
12638
12639
12640
12641
12642 064436 123727 001150 000001
12643 064444 001674
12644 064446 005726
12645 064450 004737 064114
12646 064454 005077 114500
12647 064460 112737 000001 001151
12648
12649 064466 104401 065312
12650 064472 104401 065317
12651 064476 013746 000176
12652 064502 104402
12653 064504 104401 065330
12654 064510 005046
12655 064512 005046
12656 064514 105777 114440
12657 064520 100375
12658
12659 064522 117746 114434
12660 064526 042716 177600
12661
12662 064532 021627 000003
12663 064536 001015
12664 064540 104401 065300
12665 064544 062706 000006
12666 064550 123727 001151 000001
12667 064556 001003
12668 064560 012777 000100 114372
12669 064566 000137 062030
12670
12671
12672 064572 021627 000025
12673 064576 001005
12674 064600 104401 065305
12675 064604 062706 000006
12676 064610 000737
12677
12678
12679 064612 021627 000015

; *SOFTWARE SWITCH REGISTER CHANGE ROUTINE.
; *ROUTINE IS ENTERED FROM THE TRAP HANDLER, AND WILL
; *SERVICE THE TEST FOR CHANGE IN SOFTWARE SWITCH REGISTER TRAP
; *CALL WHEN OPERATING IN TTY INTERRUPT MODE.
$CKSWR: CMP #SWREG,SWR ; IS THE SOFT-SWR SELECTED
        BNE 15$ ; EXIT IF NOT
        TST @STKS ; IS A CHAR WAITING?
        BPL 15$ ; IF NOT, EXIT
        MOV @STKB,-(SP) ; YES
        BIC #1C177,(SP) ; MAKE IT 7-BIT ASCII
        CMP (SP),#7 ; IS IT A CONTROL-G?
        BNE 2$ ; IF NOT, PUT IT IN THE TTY QUEUE
; AND EXIT

; *****
; *CONTROL IS PASSED TO THIS POINT FROM EITHER THE TTY INTERRUPT SERVICE
; *ROUTINE OR FROM THE SOFTWARE SWITCH REGISTER TRAP CALL, AS A RESULT OF A
; *CONTROL-G BEING TYPED, AND THE SOFTWARE SWITCH REGISTER BEING SELECTED.
6$: CMPB $AUTOB,#1 ; ARE WE RUNNING IN AUTO-MODE?
    BEQ 2$ ; BRANCH IF YES
    TST (SP)+ ; CLEAR CONTROL-G OFF STACK
    JSR PC,STKINT ; FLUSH THE TTY INPUT QUEUE
    CLR @STKS ; DISABLE TTY KEYBOARD INTERRUPTS
    MOV #1,$INTAG ; SET INTERRUPT MODE INDICATOR

SGTSWR: TYPE ,SCNTLG ; ECHO THE CONTROL-G (↑G)
        TYPE ,SMSWR ; TYPE CURRENT CONTENTS
        MOV SWREG,-(SP) ; SAVE SWREG FOR TYPEOUT
        TYPOC ; GO TYPE--OCTAL ASCII(ALL DIGITS)
        TYPE ,SMNEW ; PROMPT FOR NEW SWR
19$: CLR -(SP) ; CLEAR COUNTER
    CLR -(SP) ; THE NEW SWR
7$: TSTB @STKS ; CHAR THERE?
    BPL 7$ ; IF NOT TRY AGAIN

        MOV @STKB,-(SP) ; PICK UP CHAR
        BIC #1C177,(SP) ; MAKE IT 7-BIT ASCII

        CMP (SP),#3 ; IS IT A CONTROL-C?
        BNE 9$ ; BRANCH IF NOT
        TYPE ,SCNTLC ; YES, ECHO CONTROL-C (↑C)
        ADD #6,SP ; CLEAN UP STACK
        CMPB $INTAG,#1 ; REENABLE TTY KEYBOARD INTERRUPTS?
        BNE 8$ ; BRANCH IF NO
        MOV #100,@STKS ; ALLOW TTY KEYBOARD INTERRUPTS
        JMP SHUT ; CONTROL-C RESTART

9$: CMP (SP),#25 ; IS IT A CONTROL-U?
    BNE 10$ ; BRANCH IF NOT
    TYPE ,SCNTLU ; YES, ECHO CONTROL-U (↑U)
    ADD #6,SP ; IGNORE PREVIOUS INPUT
    BR 19$ ; LET'S TRY IT AGAIN

10$: CMP (SP),#15 ; IS IT A <CR>?

```

```

12680 064616 001022          BNE      16$          ;; BRANCH IF NO
12681 064620 005766 000004    TST      4(SP)       ;; YES, IS IT THE FIRST CHAR?
12682 064624 001403          BEQ      11$          ;; BRANCH IF YES
12683 064626 016677 000002 114320  MOV      2(SP),@SWR  ;; SAVE NEW SWR
12684 064634 062706 000006 11$:    ADD      @6,SP       ;; CLEAR UP STACK
12685 064640 104401 001217 14$:    TYPE   $CRLF       ;; ECHO <CR> AND <LF>
12686 064644 123727 001151 000001  CMPB    $INTAG,#1   ;; RE-ENABLE TTY KBD INTERRUPTS?
12687 064652 001003          BNE      15$          ;; BRANCH IF NOT
12688 064654 012777 000100 114276  MOV      @100,@STKS ;; RE-ENABLE TTY KBD INTERRUPTS
12689 064662 000002          RTI                      ;; RETURN
12690 064664 004737 063132 15$:    JSR     PC,$TYPEC   ;; ECHO CHAR
12691 064670 021627 000060 16$:    CMP     (SP),#60    ;; CHAR < 0?
12692 064674 002420          BLT     18$          ;; BRANCH IF YES
12693 064676 021627 000067          CMP     (SP),#67    ;; CHAR > ??
12694 064702 003015          BGT     18$          ;; BRANCH IF YES
12695 064704 042726 000060          BIC     @60,(SP)+   ;; STRIP-OFF ASCII
12696 064710 005766 000002          TST     2(SP)       ;; IS THIS THE FIRST CHAR
12697 064714 001403          BEQ     17$          ;; BRANCH IF YES
12698 064716 006316          ASL     (SP)        ;; NO, SHIFT PRESENT
12699 064720 006316          ASL     (SP)        ;; CHAR OVER TO MAKE
12700 064722 006316          ASL     (SP)        ;; ROOM FOR NEW ONE.
12701 064724 005266 000002 17$:    INC     2(SP)       ;; KEEP COUNT OF CHAR
12702 064730 056616 177776          BIS     -2(SP),(SP) ;; SET IN NEW CHAR
12703 064734 000667          BR      7$          ;; GET THE NEXT ONE
12704 064736 104401 001216 18$:    TYPE   $QUES      ;; TYPE ?<CR><LF>
12705 064742 000720          BR      20$        ;; SIMULATE CONTROL-U
12706          .DSABL  LSB
12707
12708
12709          ;; *****
12710          ;; THIS ROUTINE WILL INPUT A SINGLE CHARACTER FROM THE TTY
12711          ;; *CALL:
12712          ;; * RDCHR          ;; GET A CHARACTER FROM THE QUEUE
12713          ;; * RETURN HERE   ;; CHARACTER IS ON THE STACK
12714          ;; *              ;; WITH PARITY BIT STRIPPED OFF
12715          ;;
12716          ;;
12717 064744 011646          $RDCHR: MOV     (SP),-(SP) ;; PUSH DOWN THE PC AND
12718 064746 016666 000004 000002  MOV     4(SP),2(SP) ;; THE PS
12719 064754 005066 000004          CLR     4(SP)       ;; GET READY FOR A CHARACTER
12720 064760 005046          CLR     -(SP)       ;; PUT NEW PS ON STACK
12721 064762 012746 064770          MOV     @64$,-(SP) ;; PUT NEW PC ON STACK
12722 064766 000002          RTI                      ;; POP NEW PC AND PS
12723 064770          64$:
12724 064770 005737 064104 1$:    TST     $STKCNT     ;; WAIT ON A CHARACTER
12725 064774 001775          BEQ     1$          ;;
12726 064776 005337 064104          DEC     $STKCNT     ;; DECREMENT THE COUNTER
12727 065002 117766 177102 000004  MOVB    @STKGOUT,4(SP) ;; GET ONE CHARACTER
12728 065010 005237 064110          INC     $STKGOUT    ;; UPDATE THE POINTER
12729 065014 023727 064110 064113  CMP     $STKGOUT,$STKGEND ;; DID IT GO OFF OF THE END?
12730 065022 001003          BNE     2$          ;; BRANCH IF NO
12731 065024 012737 064112 064110  MOV     @STKQSRST,$STKGOUT ;; RESET THE POINTER
12732 065032 000002          RTI                      ;; RETURN
12733          2$:
12734          ;; *****
12735          ;; THIS ROUTINE WILL INPUT A STRING FROM THE TTY
          ;; *CALL:

```

```

12736 ;*      RDLIN      ;: INPUT A STRING FROM THE TTY
12737 ;*      RETURN HERE ;: ADDRESS OF FIRST CHARACTER WILL BE ON THE STACK
12738 ;*                ;: TERMINATOR WILL BE A BYTE OF ALL 0'S
12739
12740 065034 010346 $RDLIN: MOV      R3, -(SP)      ;: SAVE R3
12741 065036 005046      CLR      -(SP)      ;: CLEAR THE RUBOUT KEY
12742 065040 012703 065270 1$:  MOV      #STTYIN, R3      ;: GET ADDRESS
12743 065044 022703 065300 2$:  CMP      #STTYIN+8., R3      ;: BUFFER FULL?
12744 065050 101456      BLOS     4$      ;: BR IF YES
12745 065052 104411      RDCHR     ;: GO READ ONE CHARACTER FROM THE TTY
12746 065054 112613      MOV      (SP)+, (R3)      ;: GET CHARACTER
12747 065056 122713 000177 10$: CMPB     #177, (R3)      ;: IS IT A RUBOUT
12748 065062 001022      BNE      5$      ;: BR IF NO
12749 065064 005716      TST      (SP)      ;: IS THIS THE FIRST RUBOUT?
12750 065066 001007      BNE      6$      ;: BR IF NO
12751 065070 112737 000134 065266 MOV      #' \, 9$      ;: TYPE A BACK SLASH
12752 065076 104401 065266      TYPE     9$      ;:
12753 065102 012716 177777      MOV      #-1, (SP)      ;: SET THE RUBOUT KEY
12754 065106 005303 6$:  DEC      R3      ;: BACKUP BY ONE
12755 065110 020327 065270      CMP      R3, #STTYIN      ;: STACK EMPTY?
12756 065114 103434      BLO      4$      ;: BR IF YES
12757 065116 111337 065266 MOV      (R3), 9$      ;: SETUP TO TYPEOUT THE DELETED CHAR.
12758 065122 104401 065266      TYPE     9$      ;: GO TYPE
12759 065126 000746      BR       2$      ;: GO READ ANOTHER CHAR.
12760 065130 005716 5$:  TST      (SP)      ;: RUBOUT KEY SET?
12761 065132 001406      BEQ      7$      ;: BR IF NO
12762 065134 112737 000134 065266 MOV      #' \, 9$      ;: TYPE A BACK SLASH
12763 065142 104401 065266      TYPE     9$      ;:
12764 065146 005016 7$:  CLR      (SP)      ;: CLEAR THE RUBOUT KEY
12765 065150 122713 000025 CMPB     #25, (R3)      ;: IS CHARACTER A CTRL U?
12766 065154 001003      BNE      8$      ;: BR IF NO
12767 065156 104401 065305      TYPE     $CNTLU      ;: TYPE A CONTROL "U"
12768 065162 000726      BR       1$      ;: GO START OVER
12769 065164 122713 000022 8$:  CMPB     #22, (R3)      ;: IS CHARACTER A "r"?
12770 065170 001011      BNE      3$      ;: BRANCH IF NO
12771 065172 105013      CLRB     (R3)      ;: CLEAR THE CHARACTER
12772 065174 104401 001217      TYPE     $CRLF      ;: TYPE A "CR" & "LF"
12773 065200 104401 065270      TYPE     $TTYIN      ;: TYPE THE INPUT STRING
12774 065204 000717      BR       2$      ;: GO PICKUP ANOTHER CHARACTER
12775 065206 104401 001216 4$:  TYPE     $QUES      ;: TYPE A '?'
12776 065212 000712      BR       1$      ;: CLEAR THE BUFFER AND LOOP
12777 065214 111337 065266 3$:  MOV      (R3), 9$      ;: ECHO THE CHARACTER
12778 065220 104401 065266      TYPE     9$      ;:
12779 065224 122723 000015 CMPB     #15, (R3)+      ;: CHECK FOR RETURN
12780 065230 001305      BNE      2$      ;: LOOP IF NOT RETURN
12781 065232 105063 177777 CLRB     -1(R3)      ;: CLEAR RETURN (THE 15)
12782 065236 104401 001220      TYPE     $LF      ;: TYPE A LINE FEED
12783 065242 005726      TST      (SP)+      ;: CLEAR RUBOUT KEY FROM THE STACK
12784 065244 012603      MOV      (SP)+, R3      ;: RESTORE R3
12785 065246 011646      MOV      (SP), -(SP)      ;: ADJUST THE STACK AND PUT ADDRESS OF THE
12786 065250 016666 000004 000002 MOV      4(SF), 2(SF)      ;: FIRST ASCII CHARACTER ON IT
12787 065256 012766 065270 000004 MOV      #STTYIN, 4(SF)
12788 065264 000002      RTI      ;: RETURN
12789 065266 000      9$:  .BYTE 0      ;: STORAGE FOR ASCII CHAR. TO TYPE
12790 065267 000      .BYTE 0      ;: TERMINATOR
12791 065270 000010 $TTYIN: .BLKB 8.      ;: RESERVE 8 BYTES FOR TTY INPUT

```



```

12792 065300 041536 005015 000 $CNTLC: .ASCIZ /↑C/<15><12> ;;CONTROL "C"
12793 065305 136 006525 000012 $CNTLU: .ASCIZ /↑U/<15><12> ;;CONTROL "U"
12794 065312 043536 005015 000 $CNTLG: .ASCIZ /↑G/<15><12> ;;CONTROL "G"
12795 065317 015 051412 051127 $MSWR: .ASCIZ <15><12>/SWR = /
12796 065324 036440 000040
12797 065330 020040 042516 020127 $MNEW: .ASCIZ / NEW = /
12798 065336 020075 000
12799 065342
12800 .EVEN
.SBTTL READ AN OCTAL NUMBER FROM THE TTY
12801
12802 ;*****
12803 ;*THIS ROUTINE WILL READ AN OCTAL (ASCII) NUMBER FROM THE TTY AND
12804 ;*CHANGE IT TO BINARY.
12805 ;*CALL:
12806 ;* RDOCT ;; READ AN OCTAL NUMBER
12807 ;* RETURN HERE ;; LOW ORDER BITS ARE ON TOP OF THE STACK
12808 ;* ;; HIGH ORDER BITS ARE IN $HIOCT
12809
12810 065342 011646 000004 000002 $RDOCT: MOV (SP),-(SP) ;; PROVIDE SPACE FOR THE
12811 065344 016666 MOV 4(SP),2(SP) ;; INPUT NUMBER
12812 065352 010046 MOV RO,-(SP) ;; PUSH RO ON STACK
12813 065354 010146 MOV R1,-(SP) ;; PUSH R1 ON STACK
12814 065356 010246 MOV R2,-(SP) ;; PUSH R2 ON STACK
12815 065360 104412 1$: RDLIN ;; READ AN ASCII LINE
12816 065362 012600 MOV (SP)+,RO ;; GET ADDRESS OF 1ST CHARACTER
12817 065364 005001 CLR R1 ;; CLEAR DATA WORD
12818 065366 005002 CLR R2
12819 065370 112046 2$: MOV (RO)+,-(SP) ;; PICKUP THIS CHARACTER
12820 065372 001412 BEQ 3$ ;; IF ZERO GET OUT
12821 065374 006301 ASL R1 ;; *2
12822 065376 006102 ROL R2
12823 065400 006301 ASL R1 ;; *4
12824 065402 006102 ROL R2
12825 065404 006301 ASL R1 ;; *8
12826 065406 006102 ROL R2
12827 065410 177770 BIC #1C7,(SP) ;; STRIP THE ASCII JUNK
12828 065414 062601 ADD (SP)+,R1 ;; ADD IN THIS DIGIT
12829 065416 000764 BR 2$ ;; LOOP
12830 065420 005726 3$: TST (SP)+ ;; CLEAN TERMINATOR FROM STACK
12831 065422 010166 000012 MOV R1,12(SP) ;; SAVE THE RESULT
12832 065426 010237 065442 MOV R2,$HIOCT
12833 065432 012602 MOV (SP)+,R2 ;; POP STACK INTO R2
12834 065434 012601 MOV (SP)+,R1 ;; POP STACK INTO R1
12835 065436 012600 MOV (SP)+,RO ;; POP STACK INTO RO
12836 065440 000002 RTI ;; RETURN
12837 065442 000000 $HIOCT: .WORD 0 ;; HIGH ORDER BITS GO HERE
12838 .SBTTL TRAP DECODER
12839
12840 ;*****
12841 ;*THIS ROUTINE WILL PICKUP THE LOWER BYTE OF THE "TRAP" INSTRUCTION
12842 ;*AND USE IT TO INDEX THROUGH THE TRAP TABLE FOR THE STARTING ADDRESS
12843 ;*OF THE DESIRED ROUTINE. THEN USING THE ADDRESS OBTAINED IT WILL
12844 ;*GO TO THAT ROUTINE.
12845
12846 065444 016646 000002 $TRAP: MOV 2(SP),-(SP) ;; ASSUME THE STATUS OF
12847 065450 042716 000020 BIC #20,(SP) ;; THE CALLER--DO NOT ALLOW

```

12848 065454 012746 065462  
 12849 065460 000002  
 12850 065462 010046  
 12851 065464 016600 000002  
 12852 065470 005740  
 12853 065472 111000  
 12854 065474 006300  
 12855 065476 016000 065516  
 12856 065502 000200

```

MOV #1$, -(SP) ;; T-BIT TRAPS
RTI ;; SET THE NEW STATUS
1$: MOV RO, -(SP) ;; SAVE RO
MOV 2(SP), RO ;; GET TRAP ADDRESS
TST -(RO) ;; BACKUP BY 2
MOVB (RO), RO ;; GET RIGHT BYTE OF TRAP
ASL RO ;; POSITION FOR INDEXING
MOV $TRPAD(RO), RO ;; INDEX TO TABLE
RTS RO ;; GO TO ROUTINE
  
```

;; THIS IS USE TO HANDLE THE "GETPRI" MACRO

12861 065504 011646  
 12862 065506 016666 000004 000002  
 12863 065514 000002

```

$TRAP2: MOV (SP), -(SP) ;; MOVE THE PC DOWN
MOV 4(SP), 2(SP) ;; MOVE THE PSW DOWN
RTI ;; RESTORE THE PSW
  
```

.SBTTL TRAP TABLE

;\*THIS TABLE CONTAINS THE STARTING ADDRESSES OF THE ROUTINES CALLED  
;\*BY THE "TRAP" INSTRUCTION.

12870  
 12871  
 12872 065516 065504  
 12873 065520 062720  
 12874 065522 062516  
 12875 065524 062472  
 12876 065526 062532  
 12877 065530 062246  
 12878 065532 062172  
 12879  
 12880 065534 064472  
 12881  
 12882 065536 064402  
 12883 065540 064744  
 12884 065542 065034  
 12885 065544 065342  
 12886 065546 062076  
 12887 065550 062134

```

ROUTINE
-----
$TRPAD: .WORD $TRAP2
$TYPE ;; CALL=TYPE TRAP+1(104401) TTY TYPEOUT ROUTINE
$TYPOC ;; CALL=TYPOC TRAP+2(104402) TYPE OCTAL NUMBER (WITH LEADING ZEROS)
$TYPOS ;; CALL=TYPOS TRAP+3(104403) TYPE OCTAL NUMBER (NO LEADING ZEROS)
$TYPON ;; CALL=TYPON TRAP+4(104404) TYPE OCTAL NUMBER (AS PER LAST CALL)
$TYPDS ;; CALL=TYPDS TRAP+5(104405) TYPE DECIMAL NUMBER (WITH SIGN)
$TYPBN ;; CALL=TYPBN TRAP+6(104406) TYPE BINARY (ASCII) NUMBER

$GTSWR ;; CALL=GTSWR TRAP+7(104407) GET SOFT-SWR SETTING

$CKSWR ;; CALL=CKSWR TRAP+10(104410) TEST FOR CHANGE IN SOFT-SWR
$RDCHR ;; CALL=RDCHR TRAP+11(104411) TTY TYPEIN CHARACTER ROUTINE
$RDLIN ;; CALL=RDLIN TRAP+12(104412) TTY TYPEIN STRING ROUTINE
$RDOCT ;; CALL=RDOCT TRAP+13(104413) READ AN OCTAL NUMBER FROM TTY
$SAVREG ;; CALL=SAVREG TRAP+14(104414) SAVE RO-R5 ROUTINE
$RESREG ;; CALL=RESREG TRAP+15(104415) RESTORE RO-R5 ROUTINE
  
```

.SBTTL POWER DOWN AND UP ROUTINES

\*\*\*\*\*

12890  
 12891  
 12892 065552 012737 065712 000024  
 12893 065560 012737 000340 000026  
 12894 065566 010046  
 12895 065570 010146  
 12896 065572 010246  
 12897 065574 010346  
 12898 065576 010446  
 12899 065600 010546  
 12900 065602 017746 113346  
 12901 065606 010637 065716  
 12902 065612 012737 065624 000024  
 12903 065620 000000

```

POWER DOWN ROUTINE
$PWRDN: MOV # $ILLUP, @PWRVEC ;; SET FOR FAST UP
MOV #340, @PWRVEC+2 ;; PRIO:7
MOV RO, -(SP) ;; PUSH RO ON STACK
MOV R1, -(SP) ;; PUSH R1 ON STACK
MOV R2, -(SP) ;; PUSH R2 ON STACK
MOV R3, -(SP) ;; PUSH R3 ON STACK
MOV R4, -(SP) ;; PUSH R4 ON STACK
MOV R5, -(SP) ;; PUSH R5 ON STACK
MOV @SWR, -(SP) ;; PUSH @SWR ON STACK
MOV SP, $SAVR6 ;; SAVE SP
MOV # $PWRUP, @PWRVEC ;; SET UP VECTOR
HALT
  
```

```

12904 065622 000776 BR -2 ;;HANG UP
12905
12906
12907
12908 065624 012737 065712 000024 $PWRUP: MOV #SILLUP, @PWRVEC ;; SET FOR FAST DOWN
12909 065632 013706 065716 $SAVR6, SP ;; GET SP
12910 065636 005037 065716 CLR $SAVR6 ;; WAIT LOOP FOR THE TTY
12911 065642 005237 065716 1$: INC $SAVR6 ;; WAIT FOR THE INC
12912 065646 001375 BNE 1$ ;; OF WORD
12913 065650 012677 113300 MOV (SP)+, @SWR ;; POP STACK INTO @SWR
12914 065654 012605 MOV (SP)+, R5 ;; POP STACK INTO R5
12915 065656 012604 MOV (SP)+, R4 ;; POP STACK INTO R4
12916 065660 012603 MOV (SP)+, R3 ;; POP STACK INTO R3
12917 065662 012602 MOV (SP)+, R2 ;; POP STACK INTO R2
12918 065664 012601 MOV (SP)+, R1 ;; POP STACK INTO R1
12919 065666 012600 MOV (SP)+, R0 ;; POP STACK INTO R0
12920 065670 012737 065552 000024 MOV #SPWRDN, @PWRVEC ;; SET UP THE POWER DOWN VECTOR
12921 065676 012737 000340 000026 MOV #340, @PWRVEC+2 ;; PRIO:7
12922 065704 104401 TYPE ;; REPORT THE POWER FAILURE
12923 065706 065720 $PWRMG: .WORD $POWER ;; POWER FAIL MESSAGE POINTER
12924 065710 000002 RTI
12925 065712 000000 $SILLUP: HALT ;; THE POWER UP SEQUENCE WAS STARTED
12926 065714 000776 BR -2 ;; BEFORE THE POWER DOWN WAS COMPLETE
12927 065716 000000 $SAVR6: 0 ;; PUT THE SP HERE
12928 065720 005015 047520 042527 $POWER: .ASCIZ <15><12>"POWER"
12929 065726 000122
12930
12931 .EVEN
12932 .SBTTL APT COMMUNICATIONS ROUTINE
12933
12934 065730 112737 000001 066174 $ATY1: MOVB #1, $FFLG ;; TO REPORT FATAL ERROR
12935 065736 112737 000001 066172 $ATY3: MOVB #1, $MFLG ;; TO TYPE A MESSAGE
12936 065744 000403 BR $ATYC
12937 065746 112737 000001 066174 $ATY4: MOVB #1, $FFLG ;; TO ONLY REPORT FATAL ERROR
12938 065754 $ATYC:
12939 065754 010046 MOV R0, -(SP) ;; PUSH R0 ON STACK
12940 065756 010146 MOV R1, -(SP) ;; PUSH R1 ON STACK
12941 065760 105737 066172 TSTB $MFLG ;; SHOULD TYPE A MESSAGE?
12942 065764 001450 BEQ 5$ ;; IF NOT: BR
12943 065766 122737 000001 001242 CMPB #APTENV, $ENV ;; OPERATING UNDER APT?
12944 065774 001031 BNE 3$ ;; IF NOT: BR
12945 065776 132737 000100 001243 BITB #APTPOOL, $ENVM ;; SHOULD SPOOL MESSAGES?
12946 066004 001425 BEQ 3$ ;; IF NOT: BR
12947 066006 017600 000004 MOV @4(SP), R0 ;; GET MESSAGE ADDR.
12948 066012 062766 000002 000004 ADD #2, 4(SP) ;; BUMP RETURN ADDR.
12949 066020 005737 001222 1$: TST $MSGTYPE ;; SEE IF DONE W/ LAST XMISSION?
12950 066024 001375 BNE 1$ ;; IF NOT: WAIT
12951 066026 010037 001236 MOV R0, $MSGAD ;; PUT ADDR IN MAILBOX
12952 066032 105720 2$: TSTB (R0)+ ;; FIND END OF MESSAGE
12953 066034 001376 BNE 2$
12954 066036 163700 001236 SUB $MSGAD, R0 ;; SUB START OF MESSAGE
12955 066042 006200 ASR R0 ;; GET MESSAGE LNTH IN WORDS
12956 066044 010037 001240 MOV R0, $MSGGLT ;; PUT LENGTH IN MAILBOX
12957 066050 012737 000004 001222 MOV #4, $MSGTYPE ;; TELL APT TO TAKE MSG.
12958 066056 000413 BR 5$
12959 066060 017637 000004 066104 3$: MOV @4(SP), 4$ ;; PUT MSG ADDR IN JSR LINKAGE

```

```

12960 066066 062766 000002 000004      ADD      #2,4(SP)          ;;BUMP RETURN ADDRESS
12961 066074 013746 177776      MOV      177776,-(SP)     ;;PUSH 177776 ON STACK
12962 066100 004737 062720      JSR      PC,$TYPE        ;;CALL TYPE MACRO
12963 066104 000000      .WORD   0
12964 066106      4$:
12965 066106 105737 066174      5$:
10$:      TSTB     $FFLG          ;; SHOULD REPORT FATAL ERROR?
      BEQ     12$          ;; IF NOT: BR
12966 066112 001416      TST     $ENV           ;; RUNNING UNDER APT?
12967 066114 005737 001242      TST     12$           ;; IF NOT: BR
12968 066120 001413      BEQ     11$           ;; FINISHED LAST MESSAGE?
12969 066122 005737 001222      TST     $MSGTYPE       ;; IF NOT: WAIT
12970 066126 001375      BNE     11$           ;; GET ERROR #
12971 066130 017637 000004 001224      MOV     24(SP),$FATAL    ;;BUMP RETURN ADDR.
12972 066136 062766 000002 000004      ADD     #2,4(SP)
12973 066144 005237 001222      INC     $MSGTYPE       ;; TELL APT TO TAKE ERROR
12974 066150 105037 066174      12$:  CLRB    $FFLG     ;; CLEAR FATAL FLAG
12975 066154 105037 066173      CLRB   $LFLG          ;; CLEAR LOG FLAG
12976 066160 105037 066172      CLRB   $MFLG         ;; CLEAR MESSAGE FLAG
12977 066164 012601      MOV     (SP)+,R1       ;; POP STACK INTO R1
12978 066166 012600      MOV     (SP)+,R0       ;; POP STACK INTO R0
12979 066170 000207      RTS     PC             ;; RETURN
12980 066172      000      0              ;; MESSG. FLAG
12981 066173      000      0              ;; LOG FLAG
12982 066174      000      0              ;; FATAL FLAG
12983      066176      .EVEN
12984      000200      APTSIZE=200
12985      000001      APTENV=001
12986      000100      APTSPool=100
12987      000040      APTCSUP=040
12988
12989      .NLIST BEX
    
```

.SBTTL CONSOLE MESSAGES

066176				SCTMSG:	
066176	005015	040503	047116	.ASCII	<CR><LF>CANNOT RECOVER THE BAD SECTOR FILES FROM LAST <CR><LF>
066260	051124	041501	020113	.ASCIZ	TRACK FOR THIS DEVICE
066306	051			CLSPRN:	.ASCII @)
066307	075	000		EQUALS:	.ASCIZ @=
066311	015	025012	000	PROMPT:	.ASCIZ <CR><LF>@*@
066315	077	000		QSTMRK:	.ASCIZ @?@
066317				HELPOST:	
066317	015	052012	050131	.ASCIZ	<CR><LF>@TYPE HELP TEXT (Y OR N)??@
066353				UBUSOST:	
066353	015	041412	040510	.ASCIZ	<CR><LF>@CHANGE RM03 UNIBUS ADDRESS OR VECTOR ADDRESS (Y OR N)<CR> ??@
066452	005015	051525	020105	CNSLO0:	.ASCIZ <CR><LF>@USE SAME DEVICES (Y OR N) ??@
066511	015	051012	030115	CNSLO1:	.ASCIZ <CR><LF>@RM03 BUS ADDRESS (@
066536	005015	047105	051124	CNSLO2:	.ASCII <CR><LF>@ENTRY NOT IN I/O PAGE@
066565	015	040412	042104	.ASCIZ	<CR><LF>@ADDRESS MUST BE >160000@
066617	015	051012	030115	CNSLO3:	.ASCIZ <CR><LF>@RM03 VECTOR ADDRESS (@
066647	015	042412	052116	CNSLO4:	.ASCII <CR><LF>@ENTRY OUT OF RANGE@
066673	015	040412	042104	.ASCIZ	<CR><LF>@ADDRESS MUST BE <1000@
066723	015	051012	030115	CNSLO5:	.ASCIZ <CR><LF>@RM03 INTERRUPT PRIORITY (@
066757	015	042412	052116	CNSLO6:	.ASCIZ <CR><LF>@ENTRY OUT OF RANGE@
067004				CNSLO7:	
067004	005015	054524	042520	.ASCII	<CR><LF>@TYPE (A) TO TEST ALL DEVICES, OR TYPE DEVICE@
067062	047040	046525	042502	.ASCII	@ NUMBER(S)@
067074	005015	042524	046522	.ASCIZ	<CR><LF>@TERMINATE INPUT WITH CARRIAGE RETURN@
067143	015	041412	040510	XDPMG:	.ASCII <CR><LF>/CHANGE XXDP PACK, CLEAR LOC 40/
067202	005015	042522	052123	.ASCIZ	<CR><LF>/RESTART THE PROGRAM/
067230	005015	047516	020124	NOTEX:	.ASCIZ <CR><LF>/NOT EXIST DRIVE /

.EVEN

.SBTTL FUNCTION CODE TABLE

; THE FUNCTION CODE TABLE IS USED TO DEFINE STATUS CONDITIONS FOR  
; EACH FUNCTION CODE. BIT USAGE IS AS FOLLOWS:

; ATA - BIT 15 IS SET IN THE ENTRY FOR A GIVEN FUNCTION CODE  
; IF ATA SHOULD BE SET WHEN THE FUNCTION CODE IS EXECUTED, OTHERWISE,  
; BIT 15 IS ZERO, INDICATING THAT ATA SHOULD NOT NORMALLY BE SET.  
; NOTE THAT ATA MAY BE SET WHEN A COMMAND IS EXECUTED EVEN THOUGH  
; IT IS NOT EXPECTED AS A RESULT OF THE COMMAND.

; WCE - BIT 14 IS SET IN THE ENTRY FOR A GIVEN FUNCTION CODE  
; IF WRITE CHECK ERRORS ARE ENABLED AS A FUNCTION OF THE COMMAND.

; OPI - BIT 13 IS SET IN THE ENTRY FOR A GIVEN FUNCTION CODE  
; IF OPI ERRORS ARE ENABLED DURING THE EXECUTION OF THAT COMMAND.

; IVC - BIT 12 IS SET IN THE ENTRY FOR A GIVEN FUNCTION CODE  
; IF IVC ERRORS ARE ENABLED DURING THE EXECUTION OF THAT COMMAND.

; WLE - BIT 11 IS SET IN THE ENTRY FOR A GIVEN FUNCTION CODE  
; IF WRITE ERRORS ARE ENABLED DURING THE EXECUTION OF THAT COMMAND.  
; THE WRITE ERRORS WHICH ARE ENABLED ARE "WLE", "WCF", "DPE", "UPE".

; IAE - BIT 10 IS SET IN THE ENTRY FOR A GIVEN FUNCTION CODE  
; IF INVALID ADDRESS ERROR IS ENABLED FOR THAT COMMAND.

; AOE - BIT 09 IS SET IN THE ENTRY FOR A GIVEN FUNCTION CODE  
; IF READ AND WRITE ERRORS ARE ENABLED DURING THE EXECUTION OF THE  
; COMMAND. THE ERRORS ENABLED BY THIS BIT ARE "TRE", "DLT", "NEM",  
; "MXF", "LBT", AND "AOE".

; BIT 08 IS NOT USED.

; HCE - BIT 07 IS SET IN THE ENTRY FOR A GIVEN FUNCTION CODE  
; IF HEADER ERRORS ARE ENABLED DURING THE EXECUTION OF THAT COMMAND.  
; HEADER ERRORS INCLUDE "HCRC", "HCE", "FER", AND "BSE".

; ECH - BIT 06 IS SET IN THE ENTRY FOR A GIVEN FUNCTION CODE  
; IF DATA FIELD ERRORS ARE ENABLED DURING THE EXECUTION OF THAT  
; COMMAND. THESE ERRORS INCLUDE "MDPE", "DCK", AND "ECH".

; BIT 05 IS NOT USED.

; BIT 04 IS NOT USED.

; BIT 03 IS NOT USED.

; BIT 02 IS NOT USED.

; BIT 01 IS NOT USED.

; ILF - BIT 00 IS SET IF THE FUNCTION CODE IS ILLEGAL.

067254

FNCDTB:

;FUNCTION CODE TABLE

067254	020000	.WORD	OPI	:NOP
067256	130001	.WORD	OPI:ATA:ILF:IVC	:ILLEGAL FUNCTION (2)
067260	132000	.WORD	ATA:OPI:IVC:IAE	:SEEK
067262	130000	.WORD	ATA:OPI:IVC	:RECALIBRATE
067264	020000	.WORD	OPI	:DRIVE CLEAR
067266	030000	.WORD	OPI:IVC	:RELEASE
067270	130000	.WORD	OPI:ATA:IVC	:OFFSET
067272	130000	.WORD	OPI:ATA:IVC	:RETURN TO CENTERLINE
067274	020000	.WORD	OPI	:READ IN PRESET
067276	020000	.WORD	OPI	:PACK ACKNOWLEDGE
067300	130001	.WORD	OPI:ATA:ILF:IVC	:ILLEGAL FUNCTION (24)
067302	130001	.WORD	OPI:ATA:ILF:IVC	:ILLEGAL FUNCTION (26)
067304	132000	.WORD	ATA:OPI:IVC:IAE	:SEARCH
067306	130001	.WORD	OPI:ATA:ILF:IVC	:ILLEGAL FUNCTION (32)
067310	130001	.WORD	OPI:ATA:ILF:IVC	:ILLEGAL FUNCTION (34)
067312	130001	.WORD	OPI:ATA:ILF:IVC	:ILLEGAL FUNCTION (36)
067314	130001	.WORD	OPI:ATA:ILF:IVC	:ILLEGAL FUNCTION (40)
067316	130001	.WORD	OPI:ATA:ILF:IVC	:ILLEGAL FUNCTION (42)
067320	130001	.WORD	OPI:ATA:ILF:IVC	:ILLEGAL FUNCTION (44)
067322	130001	.WORD	OPI:ATA:ILF:IVC	:ILLEGAL FUNCTION (46)
067324	073300	.WORD	WCE:OPI:IVC:IAE:AOE:HCE:ECH	:WRITE CHECK DATA
067326	073300	.WORD	WCE:OPI:IVC:IAE:AOE:HCE:ECH	:WRITE CHECK HEADER AND DATA
067330	130001	.WORD	OPI:ATA:ILF:IVC	:ILLEGAL FUNCTION (54)
067332	130001	.WORD	OPI:ATA:ILF:IVC	:ILLEGAL FUNCTION (56)
067334	037200	.WORD	OPI:IVC:WLE:IAE:AOE:HCE	:WRITE DATA
067336	037000	.WORD	OPI:IVC:WLE:IAE:AOE	:WRITE HEADER AND DATA
067340	130001	.WORD	OPI:ATA:ILF:IVC	:ILLEGAL FUNCTION (64)
067342	130001	.WORD	OPI:ATA:ILF:IVC	:ILLEGAL FUNCTION (66)
067344	033300	.WORD	OPI:IVC:IAE:AOE:HCE:ECH	:READ DATA
067346	033300	.WORD	OPI:IVC:IAE:AOE:HCE:ECH	:READ HEADER AND DATA
067350	130001	.WORD	OPI:ATA:ILF:IVC	:ILLEGAL FUNCTION (74)
067352	130001	.WORD	OPI:ATA:ILF:IVC	:ILLEGAL FUNCTION (76)

.SBTTL ATTENTION (ATA) TABLE

067354	001
067355	002
067356	004
067357	010
067360	020
067361	040
067362	100
067363	200

ATNTBL:	.BYTE	1.
	.BYTE	2.
	.BYTE	4.
	.BYTE	8.
	.BYTE	16.
	.BYTE	32.
	.BYTE	64.
	.BYTE	128.



.SBTTL DATA PATTERN TABLE

067364  
067364  
067364 000000  
067366 000001  
067370 000003  
067372 000007  
067374 000017  
067376 000037  
067400 000077  
067402 000177  
067404 000377  
067406 000777  
067410 001777  
067412 003777  
067414 007777  
067416 017777  
067420 037777  
067422 077777  
067424 177777  
067426 177777  
067430 077777  
067432 037777  
067434 017777  
067436 007777  
067440 003777  
067442 001777  
067444 000777  
067446 000377  
067450 000177  
067452 000077  
067454 000037  
067456 000017  
067460 000007  
067462 000003  
067464 000001  
067466 000000  
067470 000000  
067472 000001  
067474 000002  
067476 000004  
067500 000010  
067502 000020  
067504 000040  
067506 000100  
067510 000200  
067512 000400  
067514 001000  
067516 002000  
067520 004000  
067522 010000  
067524 020000  
067526 040000  
067530 100000  
067532 100000

RGDTPT:  
MIXED:

.WORD 0.  
.WORD 1.  
.WORD 3.  
.WORD 7.  
.WORD 15.  
.WORD 31.  
.WORD 63.  
.WORD 127.  
.WORD 255.  
.WORD 511.  
.WORD 1023.  
.WORD 2047.  
.WORD 4095.  
.WORD 8191.  
.WORD 16383.  
.WORD 32767.  
.WORD 65535.  
.WORD 65535.  
.WORD 32767.  
.WORD 16383.  
.WORD 8191.  
.WORD 4095.  
.WORD 2047.  
.WORD 1023.  
.WORD 511.  
.WORD 255.  
.WORD 127.  
.WORD 63.  
.WORD 31.  
.WORD 15.  
.WORD 7.  
.WORD 3.  
.WORD 1.  
.WORD 0.  
.WORD 0.  
.WORD 1.  
.WORD 2.  
.WORD 4.  
.WORD 8.  
.WORD 16.  
.WORD 32.  
.WORD 64.  
.WORD 128.  
.WORD 256.  
.WORD 512.  
.WORD 1024.  
.WORD 2048.  
.WORD 4096.  
.WORD 8192.  
.WORD 16384.  
.WORD 32768.  
.WORD 32768.

ONES:

ZEROS:

067534	040000	.WORD	16384.
067536	020000	.WORD	8192.
067540	010000	.WORD	4096.
067542	004000	.WORD	2048.
067544	002000	.WORD	1024.
067546	001000	.WORD	512.
067550	000400	.WORD	256.
067552	000200	.WORD	128.
067554	000100	.WORD	64.
067556	000040	.WORD	32.
067560	000020	.WORD	16.
067562	000010	.WORD	8.
067564	000004	.WORD	4.
067566	000002	.WORD	2.
067570	000001	.WORD	1.
067572	000000	.WORD	0.
067574	177777	.WORD	65535.
067576	177776	.WORD	65534.
067600	177774	.WORD	65532.
067602	177770	.WORD	65528.
067604	177760	.WORD	65520.
067606	177740	.WORD	65504.
067610	177700	.WORD	65472.
067612	177600	.WORD	65408.
067614	177400	.WORD	65280.
067616	177000	.WORD	65024.
067620	176000	.WORD	64512.
067622	174000	.WORD	63488.
067624	170000	.WORD	61440.
067626	160000	.WORD	57344.
067630	140000	.WORD	49152.
067632	100000	.WORD	32768.
067634	000000	.WORD	0.
067636	000000	.WORD	0.
067640	100000	.WORD	32768.
067642	140000	.WORD	49152.
067644	160000	.WORD	57344.
067646	170000	.WORD	61440.
067650	174000	.WORD	63488.
067652	176000	.WORD	64512.
067654	177000	.WORD	65024.
067656	177400	.WORD	65280.
067660	177600	.WORD	65408.
067662	177700	.WORD	65472.
067664	177740	.WORD	65504.
067666	177760	.WORD	65520.
067670	177770	.WORD	65528.
067672	177774	.WORD	65532.
067674	177776	.WORD	65534.
067676	177777	.WORD	65535.
067700	125252	.WORD	43690.
067702	152525	.WORD	43690./2
067704	125252	.WORD	43690.
067706	177777	.WORD	65535.
067710	177776	.WORD	65534.
067712	177775	.WORD	65533.

EARLY:

067714	177773	.WORD	65531.
067716	177767	.WORD	65527.
067720	177757	.WORD	65519.
067722	177737	.WORD	65503.
067724	177677	.WORD	65471.
067726	177577	.WORD	65407.
067730	177377	.WORD	65279.
067732	176777	.WORD	65023.
067734	175777	.WORD	64511.
067736	173777	.WORD	63487.
067740	167777	.WORD	61439.
067742	157777	.WORD	57343.
067744	137777	.WORD	49151.
067746	077777	.WORD	32767.
067750	077777	.WORD	32767.
067752	137777	.WORD	49151.
067754	157777	.WORD	57343.
067756	167777	.WORD	61439.
067760	173777	.WORD	63487.
067762	175777	.WORD	64511.
067764	176777	.WORD	65023.
067766	177377	.WORD	65279.
067770	177577	.WORD	65407.
067772	177677	.WORD	65471.
067774	177737	.WORD	65503.
067776	177757	.WORD	65519.
070000	177767	.WORD	65527.
070002	177773	.WORD	65531.
070004	177775	.WORD	65533.
070006	177776	.WORD	65534.
070010	177777	.WORD	65535.
070012			

ENRGDT:

.SBTTL ERROR MESSAGE TABLE

070012	074406	000000	000000	EMT1:	.WORD	EMS1,0
070016	074455	074472	000000	EMT2:	.WORD	EMS2,EMS3,0
070024	074455	074535	000000	EMT3:	.WORD	EMS2,EMS4,0
070032	074600	074630	000000	EMT4:	.WORD	EMS5,EMS6,0
070040	074600	074742	000000	EMT5:	.WORD	EMS5,EMS10,0
070046	101435	076623	000000	EMT6:	.WORD	EMS167,EMS64,0
070054	077371	101462	000000	EMT7:	.WORD	EMS110,EMS170,0
070062	074675	000000		EMT10:	.WORD	EMS7,0
070066	074742	000000		EMT11:	.WORD	EMS10,0
070072	075004	075015	000000	EMT12:	.WORD	EMS11,EMS12,0
070100	075056	075067	075100	EMT13:	.WORD	EMS13,EMS14,EMS15,EMS16,0
070112	075152	076623	000000	EMT14:	.WORD	EMS17,EMS64,0
070120	075004	075235	000000	EMT15:	.WORD	EMS11,EMS21,0
070126	075004	075260	075407	EMT16:	.WORD	EMS11,EMS22,EMS27,0
070136	075004	075274	075420	EMT17:	.WORD	EMS11,EMS23,EMS30,0
070146	075004	075322	075420	EMT20:	.WORD	EMS11,EMS24,EMS30,0
070156	075004	075351	075407	EMT21:	.WORD	EMS11,EMS25,EMS27,0
070166	075004	075366	075407	EMT22:	.WORD	EMS11,EMS26,EMS27,0
070176	075004	075430	075420	EMT23:	.WORD	EMS11,EMS27,EMS30,0
070206	075004	075457	075420	EMT24:	.WORD	EMS11,EMS28,EMS30,0
070216	075004	075506	075420	EMT25:	.WORD	EMS11,EMS29,EMS30,0
070226	075004	075534	075420	EMT26:	.WORD	EMS11,EMS30,EMS30,0
070236	075004	075605	075420	EMT27:	.WORD	EMS11,EMS31,EMS30,0
070246	075004	075634	075420	EMT30:	.WORD	EMS11,EMS32,EMS30,0
070256	075004	075663	075420	EMT31:	.WORD	EMS11,EMS33,EMS30,0
070266	075004	075711	075420	EMT32:	.WORD	EMS11,EMS34,EMS30,0
070276	075004	075740	075420	EMT33:	.WORD	EMS11,EMS35,EMS30,0
070306	075004	075766	075420	EMT34:	.WORD	EMS11,EMS36,EMS30,0
070316	075004	076015	075420	EMT35:	.WORD	EMS11,EMS37,EMS30,0
070326	075004	076044	075420	EMT36:	.WORD	EMS11,EMS38,EMS30,0
070336	075004	076117	075420	EMT37:	.WORD	EMS11,EMS39,EMS30,0
070346	076707	075212	000000	EMT40:	.WORD	EMS66,EMS20,0
070354	077075	100603	077103	EMT41:	.WORD	EMS75,EMS141,EMS76,0
070364	100674	100704	077031	EMT42:	.WORD	EMS144,EMS144,EMS76,0
070376	076211	076327	077103	EMT43:	.WORD	EMS47,EMS53,EMS76,0
070406	077134	076327	077103	EMT44:	.WORD	EMS77,EMS53,EMS76,0
070416	077162	076327	077103	EMT45:	.WORD	EMS100,EMS53,EMS76,0
070426	077210	076327	077103	EMT46:	.WORD	EMS101,EMS53,EMS76,0
070436	076641	076623	000000	EMT47:	.WORD	EMS65,EMS64,0
070444	075056	075100	076575	EMT50:	.WORD	EMS13,EMS15,EMS63,0
070454	075004	076162	075420	EMT51:	.WORD	EMS11,EMS46,EMS30,EMS67,0
070466	076211	076327	076757	EMT52:	.WORD	EMS47,EMS53,EMS67,EMS115,EMS140,EMS141,0
070504	076211	076327	076757	EMT53:	.WORD	EMS47,EMS53,EMS67,EMS115,EMS141,EMS164,0
070522	076240	076327	076757	EMT54:	.WORD	EMS50,EMS53,EMS67,0
070532	100631	100646	076327	EMT55:	.WORD	EMS142,EMS143,EMS53,EMS67,0
070544	076267	077031	076757	EMT56:	.WORD	EMS51,EMS72,EMS67,EMS115,EMS50,EMS70,0
070562	101435	077041	076757	EMT57:	.WORD	EMS167,EMS73,EMS67,0
070572	076412	076757	077571	EMT60:	.WORD	EMS56,EMS67,EMS115,EMS150,EMS152,EMS70,0
070610	077016	076412	076757	EMT61:	.WORD	EMS71,EMS56,EMS67,EMS115,EMS150,EMS152,EMS72,0
070630	100562	076757	077571	EMT62:	.WORD	EMS140,EMS67,EMS115,EMS47,EMS70,0
070644	000000			EMT63:	.WORD	
070646	100767	101032	077004	EMT64:	.WORD	EMS150,EMS152,EMS70,EMS115,EMS56,EMS73,EMS67,0
070666	076315	102062	102243	EMT65:	.WORD	EMS52,EMS205,EMS214,EMS206,EMS115,EMS51,EMS72,0
070706	101374	077265	077031	EMT66:	.WORD	EMS165,EMS103,EMS72,EMS124,0

070720	101374	077265	077031	EMT67:	.WORD	EMS165, EMS103, EMS72, EMS171, 0
070732	076162	075212	101267	EMT70:	.WORD	EMS46, EMS20, EMS163, 0
070742	077016	077210	101267	EMT71:	.WORD	EMS71, EMS101, EMS163, 0
070752	076211	077031	101267	EMT72:	.WORD	EMS47, EMS72, EMS163, EMS115, EMS140, EMS141, 0
070770	076211	077031	101267	EMT73:	.WORD	EMS47, EMS72, EMS163, EMS115, EMS141, EMS72, 0
071006	076412	076327	101267	EMT74:	.WORD	EMS56, EMS53, EMS163, 0
071016	077016	076412	101267	EMT75:	.WORD	EMS71, EMS56, EMS163, EMS115, EMS150, EMS152, EMS72, 0
071036	076240	076327	101267	EMT76:	.WORD	EMS50, EMS53, EMS163, 0
071046	100631	100646	076327	EMT77:	.WORD	EMS142, EMS143, EMS53, EMS163, 0
071060	077075	100603	101267	EMT100:	.WORD	EMS75, EMS141, EMS163, EMS115, EMS47, EMS70, 0
071076	077075	100767	101267	EMT101:	.WORD	EMS75, EMS150, EMS163, EMS115, EMS56, EMS73, 0
071114	101435	077041	101267	EMT102:	.WORD	EMS167, EMS73, EMS163, 0
071124	100752	101006	077056	EMT103:	.WORD	EMS147, EMS151, EMS74, EMS163, 0
071136	076267	077056	101267	EMT104:	.WORD	EMS51, EMS74, EMS163, EMS115, EMS50, EMS70, 0
071154	101374	077162	101267	EMT105:	.WORD	EMS165, EMS100, EMS163, 0
071164	101374	077134	101267	EMT106:	.WORD	EMS165, EMS77, EMS163, 0
071174	100674	100704	076327	EMT107:	.WORD	EMS144, EMS145, EMS53, EMS163, EMS115, EMS143, EMS70, 0
071214	077371	077431	077576	EMT110:	.WORD	EMS110, EMS112, EMS116, EMS111, 0
071226	077515	074535	000000	EMT111:	.WORD	EMS113, EMS4, 0
071234	077515	074472	000000	EMT112:	.WORD	EMS113, EMS3, 0
071242	077371	077571	077576	EMT113:	.WORD	EMS110, EMS115, EMS116, EMS117, EMS114, 0
071256	077515	077650	000000	EMT114:	.WORD	EMS113, EMS120, 0
071264	077665	100325	100351	EMT115:	.WORD	EMS121, EMS132, EMS133, 0
071274	077730	100325	100351	EMT116:	.WORD	EMS122, EMS132, EMS133, 0
071304	077765	100325	100351	EMT117:	.WORD	EMS123, EMS132, EMS133, 0
071314	100030	100325	100351	EMT120:	.WORD	EMS124, EMS132, EMS133, 0
071324	100062	100325	100351	EMT121:	.WORD	EMS125, EMS132, EMS133, 0
071334	100125	100325	100351	EMT122:	.WORD	EMS126, EMS132, EMS133, 0
071344	100525	100325	100351	EMT123:	.WORD	EMS127, EMS132, EMS133, 0
071354	100227	100325	100351	EMT124:	.WORD	EMS130, EMS132, EMS133, 0
071364	100265	100325	100351	EMT125:	.WORD	EMS131, EMS132, EMS133, 0
071374	077665	100325	100374	EMT126:	.WORD	EMS121, EMS132, EMS134, EMS123, 0
071406	077730	100325	100374	EMT127:	.WORD	EMS122, EMS132, EMS134, EMS123, 0
071420	077765	100325	100374	EMT130:	.WORD	EMS123, EMS132, EMS134, EMS123, 0
071432	100030	100325	100374	EMT131:	.WORD	EMS124, EMS132, EMS134, EMS123, 0
071444	100062	100325	100374	EMT132:	.WORD	EMS125, EMS132, EMS134, EMS123, 0
071456	100125	100325	100374	EMT133:	.WORD	EMS126, EMS132, EMS134, EMS123, 0
071470	100525	100325	100374	EMT134:	.WORD	EMS127, EMS132, EMS134, EMS123, 0
071502	100227	100325	100374	EMT135:	.WORD	EMS130, EMS132, EMS134, EMS123, 0
071514	100265	100325	100374	EMT136:	.WORD	EMS131, EMS132, EMS134, EMS123, 0
071526	077665	100325	100436	EMT137:	.WORD	EMS121, EMS132, EMS135, 0
071536	077765	100325	100436	EMT140:	.WORD	EMS123, EMS132, EMS135, 0
071546	077665	100325	100500	EMT141:	.WORD	EMS121, EMS132, EMS136, 0
071556	100525	100325	100500	EMT142:	.WORD	EMS127, EMS132, EMS136, 0
071566	100030	100325	100500	EMT143:	.WORD	EMS124, EMS132, EMS136, 0
071576	100062	100325	100500	EMT144:	.WORD	EMS125, EMS132, EMS136, 0
071606	100125	100325	100500	EMT145:	.WORD	EMS126, EMS132, EMS136, 0
071616	100265	100325	100500	EMT146:	.WORD	EMS131, EMS132, EMS136, 0
071626	101234	100325	100500	EMT147:	.WORD	EMS162, EMS132, EMS136, 0
071636	100227	100325	100500	EMT150:	.WORD	EMS130, EMS132, EMS136, 0
071646	100562	077571	100603	EMT151:	.WORD	EMS140, EMS115, EMS141, EMS70, 0
071660	100631	077571	100646	EMT152:	.WORD	EMS142, EMS115, EMS143, EMS72, 0
071672	100674	100704	100733	EMT153:	.WORD	EMS144, EMS145, EMS146, EMS115, EMS143, EMS72, 0
071710	100674	100704	075212	EMT154:	.WORD	EMS144, EMS145, EMS20, EMS115, EMS143, EMS70, 0
071726	100767	101032	101100	EMT155:	.WORD	EMS150, EMS152, EMS154, EMS153, 0
071740	100752	101006	101100	EMT156:	.WORD	EMS147, EMS151, EMS154, EMS155, 0

071752	100752	101006	101134	EMT157:	.WORD	EMS147,EMS151,EMS156,EMS157,0
071764	101204	101134	101167	EMT160:	.WORD	EMS161,EMS156,EMS160,0
071774	075351	075407	101134	EMT161:	.WORD	EMS25,EMS27,EMS156,EMS160,0
072006	075366	075407	101134	EMT162:	.WORD	EMS26,EMS27,EMS156,EMS160,0
072020	076211	101267	100562	EMT163:	.WORD	EMS47,EMS163,EMS140,0
072030	076211	075212	000000	EMT164:	.WORD	EMS47,EMS20,0
072036	076412	075212	000000	EMT165:	.WORD	EMS56,EMS20,0
072044	076162	075212	000000	EMT166:	.WORD	EMS46,EMS20,0
072052	102563	075212	000000	EMT167:	.WORD	EMS224,EMS20,0
072060	101435	101100	101410	EMT170:	.WORD	EMS167,EMS154,EMS166,0
072070	101435	101100	101152	EMT171:	.WORD	EMS167,EMS154,EMS157,0
072100	101435	101100	101114	EMT172:	.WORD	EMS167,EMS154,EMS155,0
072110	101511	100325	100351	EMT173:	.WORD	EMS171,EMS132,EMS133,0
072120	101511	100325	100374	EMT174:	.WORD	EMS171,EMS132,EMS134,EMS123,0
072132	077515	101664	000000	EMT175:	.WORD	EMS113,EMS177,0
072140	101706	101723	000000	EMT176:	.WORD	EMS200,EMS201,0
072146	102021	100603	075420	EMT177:	.WORD	EMS203,EMS141,EMS30,EMS202,0
072160	102021	076267	075420	EMT200:	.WORD	EMS203,EMS51,EMS30,EMS202,0
072172	102021	102034	075420	EMT201:	.WORD	EMS203,EMS204,EMS30,EMS202,0
072204	102021	076240	075420	EMT202:	.WORD	EMS203,EMS50,EMS30,EMS202,0
072216	102021	100646	075420	EMT203:	.WORD	EMS203,EMS143,EMS30,EMS202,0
072230	100767	077056	101771	EMT204:	.WORD	EMS150,EMS74,EMS202,EMS115,EMS152,EMS72,0
072246	076240	077265	077031	EMT205:	.WORD	EMS50,EMS103,EMS72,0
072256	077274	077041	101771	EMT206:	.WORD	EMS104,EMS73,EMS202,0
072266	077075	100603	077571	EMT207:	.WORD	EMS75,EMS141,EMS115,EMS140,0
072300	077075	100767	000000	EMT210:	.WORD	EMS75,EMS150,0
072306	076267	077031	077571	EMT211:	.WORD	EMS51,EMS72,EMS115,EMS50,EMS70,0
072322	100631	076327	077571	EMT212:	.WORD	EMS142,EMS53,EMS115,EMS143,EMS72,0
072336	076240	077265	076327	EMT213:	.WORD	EMS50,EMS103,EMS53,0
072346	076315	102062	101410	EMT214:	.WORD	EMS52,EMS205,EMS166,EMS206,EMS115,EMS51,EMS72,0
072366	076315	077626	076412	EMT215:	.WORD	EMS52,EMS117,EMS56,EMS163,0
072400	076412	075420	076623	EMT216:	.WORD	EMS56,EMS30,EMS64,0
072410	076162	075420	076623	EMT217:	.WORD	EMS46,EMS30,EMS64,0
072420	075430	075420	076623	EMT220:	.WORD	EMS31,EMS30,EMS64,0
072430	076211	075420	076623	EMT221:	.WORD	EMS47,EMS30,EMS64,0
072440	076315	077626	077134	EMT222:	.WORD	EMS52,EMS117,EMS77,0
072450	076315	077626	076575	EMT223:	.WORD	EMS52,EMS117,EMS63,0
072460	000000			EMT224:	.WORD	
072462	000000			EMT225:	.WORD	
072464	000000			EMT226:	.WORD	
072466	000000			EMT227:	.WORD	
072470	000000			EMT230:	.WORD	
072472	000000			EMT231:	.WORD	
072474	000000			EMT232:	.WORD	
072476	000000			EMT233:	.WORD	
072500	000000			EMT234:	.WORD	
072502	000000			EMT235:	.WORD	
072504	000000			EMT236:	.WORD	
072506	000000			EMT237:	.WORD	
072510	000000			EMT240:	.WORD	
072512	000000			EMT241:	.WORD	
072514	000000			EMT242:	.WORD	
072516	000000			EMT243:	.WORD	
072520	000000			EMT244:	.WORD	
072522	000000			EMT245:	.WORD	
072524	101435	100325	102121	EMT246:	.WORD	EMS167,EMS132,EMS207,0

072534	101435	100325	102146	EMT247:	.WORD	EMS167, EMS132, EMS210, EMS125, 0
072546	101435	102157	102146	EMT250:	.WORD	EMS167, EMS211, EMS210, EMS207, EMS206, 0
072562	102175	102220	000000	EMT251:	.WORD	EMS212, EMS213, 0
072570	101374	102175	000000	EMT252:	.WORD	EMS165, EMS212, 0
072576	100752	101006	101134	EMT253:	.WORD	EMS147, EMS151, EMS156, EMS210, EMS26, EMS27, 0
072614	102021	077210	075420	EMT254:	.WORD	EMS203, EMS101, EMS30, 0
072624	102021	101435	075420	EMT255:	.WORD	EMS203, EMS167, EMS30, 0
072634	102021	077162	075420	EMT256:	.WORD	EMS203, EMS100, EMS30, 0
072644	075004	076162	075420	EMT257:	.WORD	EMS11, EMS46, EMS30, EMS102, 0
072656	076315	077626	076412	EMT260:	.WORD	EMS52, EMS117, EMS56, EMS102, 0
072670	076315	102062	102365	EMT261:	.WORD	EMS52, EMS205, EMS220, EMS206, EMS115, EMS51, EMS72, 0
072710	077274	077041	101771	EMT262:	.WORD	EMS104, EMS73, EMS202, 0
072720	076240	076327	077236	EMT263:	.WORD	EMS50, EMS53, EMS102, 0
072730	076412	076327	077236	EMT264:	.WORD	EMS56, EMS53, EMS102, EMS115, EMS150, EMS152, EMS70, 0
072750	077016	076412	077236	EMT265:	.WORD	EMS71, EMS56, EMS102, EMS115, EMS150, EMS152, EMS72, 0
072770	100631	100646	076327	EMT266:	.WORD	EMS142, EMS143, EMS53, EMS102, 0
073002	076240	100733	077571	EMT267:	.WORD	EMS50, EMS146, EMS115, EMS52, EMS117, EMS46, 0
073020	076211	076327	077236	EMT270:	.WORD	EMS47, EMS53, EMS102, EMS115, EMS140, 0
073034	076211	076327	077236	EMT271:	.WORD	EMS47, EMS53, EMS102, EMS115, EMS141, EMS72, 0
073052	077075	100603	077236	EMT272:	.WORD	EMS75, EMS141, EMS102, EMS115, EMS47, EMS73, 0
073070	076267	077056	077236	EMT273:	.WORD	EMS51, EMS74, EMS102, EMS115, EMS50, EMS70, 0
073106	076575	076327	076467	EMT274:	.WORD	EMS63, EMS53, EMS57, EMS115, EMS41, EMS146, 0
073124	077576	076327	075740	EMT275:	.WORD	EMS116, EMS53, EMS41, EMS57, 0
073136	076211	076327	076467	EMT276:	.WORD	EMS47, EMS53, EMS57, EMS115, EMS140, 0
073152	076211	076327	076467	EMT277:	.WORD	EMS47, EMS53, EMS57, EMS115, EMS141, EMS72, 0
073170	076412	076327	076467	EMT300:	.WORD	EMS56, EMS53, EMS57, EMS115, EMS150, EMS152, EMS70, 0
073210	077016	076412	076327	EMT301:	.WORD	EMS71, EMS56, EMS53, EMS57, EMS115, EMS150, EMS152, EMS72, 0
073232	101374	077162	077265	EMT302:	.WORD	EMS165, EMS100, EMS103, EMS57, 0
073244	101374	077210	077265	EMT303:	.WORD	EMS165, EMS101, EMS103, EMS57, 0
073256	101374	077134	077265	EMT304:	.WORD	EMS165, EMS77, EMS103, EMS57, 0
073270	076162	075420	076623	EMT305:	.WORD	EMS46, EMS30, EMS64, EMS57, 0
073302	076240	076327	076467	EMT306:	.WORD	EMS50, EMS53, EMS57, 0
073312	076240	100733	077571	EMT307:	.WORD	EMS50, EMS146, EMS115, EMS52, EMS117, EMS46, EMS57, 0
073332	100631	100646	076327	EMT310:	.WORD	EMS142, EMS143, EMS53, EMS57, 0
073344	077274	077265	076327	EMT311:	.WORD	EMS104, EMS103, EMS53, EMS57, 0
073356	077323	077265	076327	EMT312:	.WORD	EMS105, EMS103, EMS53, EMS57, 0
073370	100674	100704	077265	EMT313:	.WORD	EMS144, EMS145, EMS103, EMS57, EMS115, EMS143, EMS70, 0
073410	075766	077265	076327	EMT314:	.WORD	EMS42, EMS103, EMS53, EMS57, 0
073422	075430	077265	076327	EMT315:	.WORD	EMS31, EMS103, EMS53, EMS57, 0
073434	077016	075430	077265	EMT316:	.WORD	EMS71, EMS31, EMS103, EMS57, 0
073446	076015	077265	076467	EMT317:	.WORD	EMS43, EMS103, EMS57, 0
073456	076117	077265	076467	EMT320:	.WORD	EMS45, EMS103, EMS57, 0
073466	076044	077265	076467	EMT321:	.WORD	EMS44, EMS103, EMS57, 0
073476	077352	075212	000000	EMT322:	.WORD	EMS106, EMS20, 0
073504	075634	077265	076467	EMT323:	.WORD	EMS36, EMS103, EMS57, 0
073514	101564	075634	077265	EMT324:	.WORD	EMS173, EMS36, EMS103, EMS57, 0
073526	101544	075634	077265	EMT325:	.WORD	EMS172, EMS36, EMS103, EMS57, 0
073540	075056	101601	075100	EMT326:	.WORD	EMS13, EMS174, EMS15, EMS35, EMS53, EMS175, 0
073556	100752	101006	077056	EMT327:	.WORD	EMS147, EMS151, EMS74, EMS175, 0
073570	076707	076327	101607	EMT330:	.WORD	EMS66, EMS53, EMS175, 0
073600	075506	077265	076327	EMT331:	.WORD	EMS33, EMS103, EMS53, EMS175, 0
073612	075711	077265	076327	EMT332:	.WORD	EMS40, EMS103, EMS53, EMS57, 0
073624	076267	077056	076467	EMT333:	.WORD	EMS51, EMS74, EMS57, EMS115, EMS50, EMS70, 0
073642	077075	100603	076467	EMT334:	.WORD	EMS75, EMS141, EMS57, EMS115, EMS47, EMS73, 0
073660	077075	100767	101032	EMT335:	.WORD	EMS75, EMS150, EMS152, EMS57, EMS115, EMS56, EMS73, 0
073700	076515	076530	076557	EMT336:	.WORD	EMS60, EMS61, EMS62, 0

073710	077576	077626	075534	EMT337: .WORD	EMS116, EMS117, EMS34, 0
073720	075534	076327	076341	EMT340: .WORD	EMS34, EMS53, EMS54, EMS111, 0
073732	076363	075534	000000	EMT341: .WORD	EMS55, EMS34, 0
073740	076315	077626	076412	EMT342: .WORD	EMS52, EMS117, EMS56, EMS57, 0
073752	076315	077626	076117	EMT343: .WORD	EMS52, EMS117, EMS45, EMS57, 0
073764	076315	077626	076044	EMT344: .WORD	EMS52, EMS117, EMS44, EMS57, 0
073776	076315	077626	102405	EMT345: .WORD	EMS52, EMS117, EMS221, 0
074006	077352	075212	077571	EMT346: .WORD	EMS106, EMS20, EMS115, EMS223, EMS72, 0
074022	076315	102062	102455	EMT347: .WORD	EMS52, EMS205, EMS222, EMS206, 0
074034	077075	100767	077236	EMT350: .WORD	EMS75, EMS150, EMS102, EMS115, EMS56, EMS73, 0
074052	101435	077041	077236	EMT351: .WORD	EMS167, EMS73, EMS102, 0
074062	102261	000000		EMT352: .WORD	EMS215, 0
074066	102332	102021	102302	EMT353: .WORD	EMS217, EMS203, EMS216, 0
074076	102405	075212	000000	EMT354: .WORD	EMS221, EMS20, 0



074104	102635	103441	103516	EHT1:	.WORD	EH1,STSH1,STSH2,STSH4,0
074116	103441	103516	103643	EHT2:	.WORD	STSH1,STSH2,STSH4,0
074126	102654	000000		EHT110:	.WORD	EH110,0
074132	102663	000000		EHT111:	.WORD	EH111,0
074136	102702	000000		EHT114:	.WORD	EH114,0
074142	102731	103441	103516	EHT223:	.WORD	EH223,STSH1,STSH2,STSH4,0
074154	102757	103441	103516	EHT256:	.WORD	EH256,STSH1,STSH2,STSH4,0
074166	103034	103441	103516	EHT336:	.WORD	EH336,STSH1,STSH2,STSH4,0
074200	103073	103441	103516	EHT337:	.WORD	EH337,STSH1,STSH2,STSH4,0
074212	103232	103441	103516	EHT344:	.WORD	EH344,STSH1,STSH2,STSH4,0
074224	103372	000000		EHT353:	.WORD	EH353,0

074230	103702	103776	104014	EDT1:	.WORD	ED1,STSD1,STSD2,STSD4
074240	103776	104014	104046	EDT2:	.WORD	STSD1,STSD2,STSD4
074246	103710			EDT110:	.WORD	ED110
074250	103714			EDT111:	.WORD	ED111
074252	103722			EDT114:	.WORD	ED114
074254	103732	103776	104014	EDT223:	.WORD	ED223,STSD1,STSD2,STSD4
074264	103742	103776	104014	EDT336:	.WORD	ED336,STSD1,STSD2,STSD4
074274	103754	103776	104014	EDT337:	.WORD	ED337,STSD1,STSD2,STSD4
074304	103754	103776	104014	EDT344:	.WORD	ED337,STSD1,STSD2,STSD4,0
074316	103766			EDT353:	.WORD	ED353

074320	104061	104077	104077	EFT1:	.WORD	EF111, STSF, STSF, STSF
074330	104077	104077	104077	EFT2:	.WORD	STSF, STSF, STSF
074336	104060			EFT110:	.WORD	EF110
074340	104061			EFT111:	.WORD	EF111
074342	104063			EFT114:	.WORD	EF114
074344	104063	104077	104077	EFT223:	.WORD	EF114, STSF, STSF, STSF
074354	104066	104077	104077	EFT336:	.WORD	EF336, STSF, STSF, STSF
074364	104066	104077	104077	EFT337:	.WORD	EF336, STSF, STSF, STSF
074374	104066	104077	104077	EFT344:	.WORD	EF336, STSF, STSF, STSF
074404	104063			EFT353:	.WORD	EF114

.SBTTL ERROR MESSAGE STRINGS

074406	051127	047117	020107	EMS1:	.ASCIZ	WRONG UNIT SELECTED (RMCS2, BITS 0-2) a
074455	104	053105	041511	EMS2:	.ASCIZ	DEVICE WENT a
074472	047125	053101	044501	EMS3:	.ASCIZ	UNAVAILABLE "DVA" (RMCS1, BIT 11) a
074535	116	047117	054105	EMS4:	.ASCIZ	NONEXISTENT "NED" (RMCS2, BIT 12) a
074600	047503	046515	047101	EMS5:	.ASCIZ	COMMAND NOT COMPLETED a
074630	047503	052116	047522	EMS6:	.ASCIZ	CONTROLLER NOT READY (RMCS1, BIT 7) a
074675	104	044522	042526	EMS7:	.ASCIZ	DRIVE NOT READY "DRY" (RMDS, BIT 7) a
074742	047507	047040	052117	EMS10:	.ASCIZ	GO NOT RESET "GO" (RMCS1, BIT 0) a
075004	047111	040526	044514	EMS11:	.ASCIZ	INVALID a
075015	106	047125	052103	EMS12:	.ASCIZ	FUNCTION CODE (RMCS1, BITS 1-5) a
075056	040515	051523	052502	EMS13:	.ASCIZ	MASSBUS a
075067	103	047117	051124	EMS14:	.ASCIZ	CONTROL a
075100	052502	020123	040520	EMS15:	.ASCIZ	BUS PARITY ERROR a
075122	046442	050103	021105	EMS16:	.ASCIZ	"MCPE" (RMCS1, BIT 13) a
075152	051124	047101	043123	EMS17:	.ASCIZ	TRANSFER ERROR (RMCS1, BIT 14) a
075212	044123	052517	042114	EMS20:	.ASCIZ	SHOULD NOT BE SET a
075235	127	051117	020104	EMS21:	.ASCIZ	WORD COUNT (RMWC) a
075260	052502	020123	051050	EMS22:	.ASCIZ	BUS (RMB) a
075274	046042	052102	020042	EMS23:	.ASCIZ	"LBT" (RMDS, BIT 10) a
075322	040442	042517	020042	EMS24:	.ASCIZ	"AOE" (RMER1, BIT 09) a
075351	104	051511	020113	EMS25:	.ASCIZ	DISK (RMDA) a
075366	054503	044514	042116	EMS26:	.ASCIZ	CYLINDER (RMDC) a
075407	101	042104	042522	EMS27:	.ASCIZ	ADDRESS a
075420	052123	052101	051525	EMS30:	.ASCIZ	STATUS a
075430	053442	042514	020042	EMS31:	.ASCIZ	"WLF" (RMER1, BIT 11) a
075457	042	050125	021105	EMS32:	.ASCIZ	"UPE" (RMCS2, BIT 13) a
075506	053442	043103	020042	EMS33:	.ASCIZ	"WCF" (RMER1, BIT 5) a
075534	051127	052111	020105	EMS34:	.ASCIZ	WRITE CHECK ERROR-"WCE" (RMCS2, BIT 14) a
075605	042	042115	042520	EMS35:	.ASCIZ	"MDFE" (RMCS2, BIT 8) a
075634	042042	045503	020042	EMS36:	.ASCIZ	"DCK" (RMER1, BIT 15) a
075663	042	041505	021110	EMS37:	.ASCIZ	"ECH" (RMER1, BIT 6) a
075711	042	046104	021124	EMS40:	.ASCIZ	"DLT" (RMCS2, BIT 15) a
075740	046442	043130	020042	EMS41:	.ASCIZ	"MXF" (RMCS2, BIT 9) a
075766	042042	042524	020042	EMS42:	.ASCIZ	"DTE" (RMER1, BIT 12) a
076015	042	041510	041522	EMS43:	.ASCIZ	"HCRC" (RMER1, BIT 8) a
076044	042510	042101	051105	EMS44:	.ASCIZ	HEADER COMPARE ERROR "HCE" (RMER1, BIT 7) a
076117	106	051117	040515	EMS45:	.ASCIZ	FORMAT ERROR "FER" (RMER1, BIT 4) a
076162	044442	042501	020042	EMS46:	.ASCIZ	"IAE" (RMER1, BIT 10) a
076211	042	050117	021111	EMS47:	.ASCIZ	"OPT" (RMER1, BIT 13) a
076240	051442	044513	020042	EMS50:	.ASCIZ	"SKI" (RMER2, BIT 14) a
076267	042	044520	021120	EMS51:	.ASCIZ	"PIP" (RMDS, BIT 13) a
076315	124	042510	051040	EMS52:	.ASCIZ	THE RM03 a
076327	104	052105	041505	EMS53:	.ASCIZ	DETECTED a
076341	101	020124	047101	EMS54:	.ASCIZ	AT AN UNEXPECTED a
076363	111	041516	051117	EMS55:	.ASCIZ	INCORRECT DATA DURING a
076412	047111	040526	044514	EMS56:	.ASCIZ	INVALID COMMAND ERROR "IVC" (RMER2, BIT 12) a
076467	104	051125	047111	EMS57:	.ASCIZ	DURING DATA TRANSFER a
076515	104	052101	020101	EMS60:	.ASCIZ	DATA READ a
076530	047504	051505	047040	EMS61:	.ASCIZ	DOES NOT COMPARE WITH a
076557	104	052101	020101	EMS62:	.ASCIZ	DATA WRITTEN a
076575	042	040520	021122	EMS63:	.ASCIZ	"PAR" (RMER1, BIT 3) a
076623	111	020123	047111	EMS64:	.ASCIZ	IS INCORRECT a
076641	103	046517	047520	EMS65:	.ASCIZ	COMPOSITE ERROR "ERR" (RMDS, BIT 14) a
076707	104	052101	020101	EMS66:	.ASCIZ	DATA PARITY ERROR "DPE" (RMER2, BIT 3) a

076757	104	051125	047111	MS67:	.ASCIZ	ADURING SEEK COMMAND a
077004	051511	051040	051509	MS70:	.ASCIZ	DIS RESET a
077016	051105	047522	047516	MS71:	.ASCIZ	ERRONEOUS a
077031	111	020123	047516	MS72:	.ASCIZ	IS SET a
077041	104	042111	047516	MS73:	.ASCIZ	DID NOT SET a
077056	044504	020104	047516	MS74:	.ASCIZ	DID NOT RESET a
077075	114	051517	020124	MS75:	.ASCIZ	LOST a
077103	104	051125	047516	MS76:	.ASCIZ	DURING PACK ACK COMMAND a
077134	051042	051125	020124	MS77:	.ASCIZ	"RM" (RMR1, BIT 2) a
077162	044444	051114	020124	MS100:	.ASCIZ	"IL" (RMR1, BIT 1) a
077210	044444	043114	020124	MS101:	.ASCIZ	"IL" (RMR1, BIT 0) a
077236	052504	044522	047516	MS102:	.ASCIZ	DURING SEARCH COMMAND a
077265	10	051125	020124	MS103:	.ASCIZ	ERROR a
077274	046042	051506	020124	MS104:	.ASCIZ	"LBC" (RMR2, BIT 10) a
077323	042510	051514	020124	MS105:	.ASCIZ	"LSC" (RMR2, BIT 11) a
077352	042510	042101	020124	MS106:	.ASCIZ	HEADER ERRORS a
077371	102	051525	020124	MS110:	.ASCIZ	BUS TIMEOUT (04 TRAP) a
077420	042101	051104	020124	MS111:	.ASCIZ	ADDRESS a
077431	127	042510	020124	MS112:	.ASCIZ	WHEN READING/WRITING RH REGISTERS a
077473	101	020124	020124	MS113:	.ASCIZ	AT THE FOLLOWING a
077515	124	042510	020124	MS114:	.ASCIZ	THE SELECTED DEVICE IS a
077545	116	047117	020124	MS115:	.ASCIZ	NONEXISTENT DEVICE a
077571	040	006455	000010	MS116:	.ASCIZ	-a<CR><LF>
077576	044124	020105	040510	MS117:	.ASCIZ	THE MASSBUS CONTROLLER a
077626	040506	046111	042510	MS118:	.ASCIZ	FAILED TO DETECT a
077650	047516	020124	047101	MS120:	.ASCIZ	NOT AN RMO3 a
077665	103	047117	020124	MS121:	.ASCIZ	CONTROL STATUS REGISTER 1, RMCS1, a
077730	052502	020123	020124	MS122:	.ASCIZ	BUS ADDRESS REGISTER, RMAA, a
077765	103	047117	020124	MS123:	.ASCIZ	CONTROL STATUS REGISTER 2, RMCS2, a
100030	051105	047522	020124	MS124:	.ASCIZ	ERROR REGISTER 1, RMR1, a
100062	052101	042524	020124	MS125:	.ASCIZ	ATTENTION SUMMARY REGISTER, RMAA, a
100125	115	044501	020124	MS126:	.ASCIZ	MAINTENANCE REGISTER #1, RMMR #1, a
100170	041505	020103	020124	MS127:	.ASCIZ	ECC POSITION REGISTER, RMEC1, a
100227	105	041503	050040	MS128:	.ASCIZ	ECC PATTERN REGISTER, RMEC2, a
100265	115	044501	020124	MS129:	.ASCIZ	MAINTENANCE REGISTER 2, RMMR2, a
100325	115	052117	020124	MS130:	.ASCIZ	NOT INITIALIZED BY a
100351	125	044516	020124	MS131:	.ASCIZ	BUS INITIALIZE a
100374	047503	052116	047522	MS132:	.ASCIZ	CONTROLLER CLEAR, I.E. BIT 5 OF a
100436	044122	030461	047522	MS133:	.ASCIZ	RAII ERROR CLEAR (RMCS1, BIT 14) a
100500	051104	053111	020124	MS134:	.ASCIZ	DRIVE CLEAR COMMAND a
100525	104	044522	047522	MS135:	.ASCIZ	DRIVE STATUS REGISTER, RMD5 a
100562	042515	044504	020124	MS136:	.ASCIZ	MEDIUM OFF LINE a
100603	042515	047515	020124	MS137:	.ASCIZ	"MOL" (RMD5, BIT 12) a
100631	104	044522	020124	MS138:	.ASCIZ	DRIVE FAULT a
100646	042042	041525	020124	MS139:	.ASCIZ	"DVC" (RMR2, BIT 7) a
100674	047125	040523	047522	MS140:	.ASCIZ	UNSAFE a
100704	052442	051516	020124	MS141:	.ASCIZ	"UNS" (RMR1, BIT 14) a
100733	123	047510	020124	MS142:	.ASCIZ	SHOULD BE SET a
100752	043117	051506	020124	MS143:	.ASCIZ	OFFSET MODE a
100767	040	047526	020124	MS150:	.ASCIZ	a VOLUME VALID a
101006	047442	021115	024040	MS151:	.ASCIZ	"OM" (RMD5, BIT 0) a
101032	053042	021126	024040	MS152:	.ASCIZ	"VV" (RMD5, BIT 6) a
101056	040520	045503	040440	MS153:	.ASCIZ	PACK ACK COMMAND a
101100	047516	020124	042522	MS154:	.ASCIZ	NOT SET BY a
101114	043117	051506	052105	MS155:	.ASCIZ	OFFSET COMMAND a
101134	047516	020124	042522	MS156:	.ASCIZ	NOT RESET BY a

101152	052122	020103	047503	EMS157:	.ASCIZ	DRTC COMMAND
101167	122	050111	041440	EMS160:	.ASCIZ	DRIP COMMAND
101204	043117	051506	052105	EMS161:	.ASCIZ	DOFFSET REGISTER (RMOF)
101234	051105	047522	020122	EMS162:	.ASCIZ	ERROR REGISTER #2, RMER2,
101267	104	051125	047111	EMS163:	.ASCIZ	DURING RECALIBRATE
101313	111	020123	047111	EMS164:	.ASCIZ	DIS INTERMITTENT OR DRIVE DIDNT DROP ON
101362	054503	044514	042116		.ASCIZ	DCYLINDER
101374	047125	054105	042520	EMS165:	.ASCIZ	DUNEXPECTED
101410	042522	040503	044514	EMS166:	.ASCIZ	DRECALIBRATE COMMAND
101435	042	052101	021101	EMS167:	.ASCIZ	D"ATA" (RMD5, BIT15)
101462	044127	047105	051040	EMS170:	.ASCIZ	DWHEN READING REGISTER
101511	105	051122	051117	EMS171:	.ASCIZ	ERROR REGISTER #2, RMER2,
101544	047516	051116	041505	EMS172:	.ASCIZ	DNONRECOVERABLE
101564	042522	047503	042522	EMS173:	.ASCIZ	DRECOVERABLE
101601	104	052101	020101	EMS174:	.ASCIZ	DATA
101607	104	051125	047111	EMS175:	.ASCIZ	DURING WRITE COMMAND
101635	042	050117	021105	EMS176:	.ASCIZ	D"OPE" (RMER2, BIT 13)
101664	047111	053440	044522	EMS177:	.ASCIZ	DIN WRITE PROTECT
101706	040503	020116	047516	EMS200:	.ASCIZ	DSCAN NOT SET
101723	104	040511	047107	EMS201:	.ASCIZ	D"DIAGNOSTIC MODE "DMD" (RMMR1, BIT 0)
101771	104	051125	047111	EMS202:	.ASCIZ	DURING DIAGNOSTIC MODE
102021	111	041516	051117	EMS203:	.ASCIZ	DINCORRECT
102034	053442	046122	020042	EMS204:	.ASCIZ	D"HAL" (RMD5, BIT 11)
102062	054105	041505	052125	EMS205:	.ASCIZ	D"EXECUTED"
102074	044527	044124	041440	EMS206:	.ASCIZ	DWITH COMP ERROR SET
102121	042	047507	020042	EMS207:	.ASCIZ	D"GO" (RMCS1, BIT 0)
102146	051127	052111	047111	EMS210:	.ASCIZ	DWRITING
102157	127	051501	051040	EMS211:	.ASCIZ	D"AS RESET BY
102175	120	047522	051107	EMS212:	.ASCIZ	DPROGRAM INTERRUPT
102220	040527	020123	047516	EMS213:	.ASCIZ	D"AS NOT GENERATED
102243	123	042505	020113	EMS214:	.ASCIZ	DSEEK COMMAND
102261	120	047522	051107	EMS215:	.ASCIZ	DPROGRAM TIMEOUT
102302	052504	044522	043516	EMS216:	.ASCIZ	DURING LOOK AHEAD TEST
102332	047514	045517	040440	EMS217:	.ASCIZ	DLOOK AHEAD REGISTER, RMLA,
102365	123	040505	041522	EMS220:	.ASCIZ	DSEARCH COMMAND
102405	102	042101	051440	EMS221:	.ASCIZ	D"BAD SECTOR ERROR "BSE" (RMER2, BIT 15)
102455	101	042040	052101	EMS222:	.ASCIZ	D"DATA TRANSFER COMMAND
102506	042510	042101	051105	EMS223:	.ASCIZ	D"HEADER COMPARE INHIBIT "HCI" (RMOF, BIT 10)
102563	116	047117	054105	EMS224:	.ASCIZ	DNONEXISTENT MEMORY "NEM" (RMCS2, BIT 11)

102635	105	050130	052103	EH1:	.ASCIZ	RECEVD					
102654	052502	040523	051104	EH110:	.ASCIZ	RECEVD					
102663	040	046522	051503	EH111:	.ASCIZ	RECEVD					
102702	042522	042503	042126	EH114:	.ASCIZ	RECEVD	SNGPRT	DULPRT			
102731	105	050130	052103	EH223:	.ASCIZ	RECEVD	RECEVD	DATA			
102757	105	050130	052103	EH256:	.ASCIZ	RECEVD	RECEVD	RGSTR	<CR><LF>		
103006	052123	052101	051525		.ASCIZ	STATUS	STATUS	INDEX			
103034	042107	042101	051522	EH336:	.ASCIZ	RECEVD	RECEVD	RECEVD			
103073	122	041515	031123	EH337:	.ASCII	STATUS	STATUS	FAILING	DATA	<CR><LF>	
103133	137	057537	057537		.ASCII	*****	*****	*****	*****	<CR><LF>	
103173	105	050130	052103		.ASCIZ	RECEVD	RECEVD	BIT	ADRESS		
103232	046522	051105	020061	EH344:	.ASCII	STATUS	STATUS	HEADER	FAILING	<CR><LF>	
103273	137	057537	057537		.ASCII	*****	*****	WORD	BIT	<CR><LF>	
103332	054105	041520	042124		.ASCIZ	RECEVD	RECEVD	NUMBER	POSITION		
103372	054105	041520	042124	EH353:	.ASCII	RECEVD	RECEVD	RECEVD	<CR><LF>		
103412	051040	046115	020101		.ASCIZ	RMLA	RMLA	RMOF			
103441	040	046522	051503	STSH1:	.ASCII	RMCS1	RMCS2	RMDS	RMER1	RMER2	
103506	020040	051040	040515		.ASCIZ	RMSA					
103516	051040	053515	020103	STSH2:	.ASCII	RMWC	RMBA	RMDA	RMOF	RMDC	
103563	040	020040	051040		.ASCIZ	RMEC1	RMEC2				
103605	040	046522	040504	STSH3:	.ASCIZ	RMDA	RMDC	RMOF	RMLA		
103643	040	046522	051115	STSH4:	.ASCIZ	RMMR1	RMMR2	RMDT	RMSN		

	103702			.EVEN		
103702	001140	001142	000000	ED1:	.WORD	SGDDAT,SBDDAT,0
103710	001276	000000		ED110:	.WORD	SBASE,0
103714	001174	001176	000000	ED111:	.WORD	STMPO,STMP1,0
103722	001354	001176	001200	ED114:	.WORD	RMDTI,STMP1,STMP2,0
103732	001140	001142	001174	ED223:	.WORD	SGDDAT,SBDDAT,STMPO,0
103742	001134	001140	001136	ED336:	.WORD	SGDADR,SGDDAT,SBADR,SBDDAT,0
103754	001140	001142	001174	ED337:	.WORD	SGDDAT,SBDDAT,STMPO,STMP1,0
103766	001140	001142	001430	ED353:	.WORD	SGDDAT,SBDDAT,RMOFO,0
103776	001326	001336	001340	STSD1:	.WORD	RMCS1I, RMCS2I, RMDSI, RMER1I, RMER2I, RMASI, 0
104014	001330	001332	001334	STSD2:	.WORD	RMWCI, RMBAI, RMDAI, RMOFI, RMDCI, RMECI
104030	001374	000000			.WORD	RMEC2I, 0
104034	001334	001362	001360	STSD3:	.WORD	RMDAI, RMDCI, RMOFI, RMLAI, 0
104046	001352	001366	001354	STSD4:	.WORD	RMMR1I, RMMR2I, RMDTI, RMSNI, 0



104060	000			EF110:	.BYTE	0
104061	000	000		EF111:	.BYTE	0,0
104063	000	000	000	EF114:	.BYTE	0,0,0
104066	000	000	000	EF336:	.BYTE	0,0,0,0
104072	000	000	000	EF337:	.BYTE	0,0,0,0,0
104077	000	000	000	STSF:	.BYTE	0,0,0,0,0,0,0

CZRMCB0 RMD3/2 FCTNL TST 1  
CZRMCB.P11 23-NOV-77 12:14

MACY11 30(1046) 23-NOV-77 12:25 PAGE 288  
ERROR MESSAGE STRINGS

007

SEQ 0288

104106 000402  
105112 177777  
105114 177777  
105116 000402  
106122 177777  
106124 177777

.EVEN  
MFGFIL: .BLKW 258.  
          .WORD -1  
          .WORD -1  
USRFIL:        .BLKW 258.  
          .WORD -1  
          .WORD -1  
  
.EVEN

106126  
106126 000402  
107132 000402

BUFFER:  
BUFONE: .BLKW 258.  
BUFTWO: .BLKW 258.

106126 106126  
106126 005015  
106130 046011 051511 020124  
106150 057411 057537 057537  
106170 030524 041411 047117  
106223 124 004462 042504  
106255 124 004463 051104  
106301 124 004464 047125  
106334 032524 041411 047117  
106366 033124 042411 051122  
106413 124 004467 051104  
106441 124 030061 050011  
106503 124 030461 042011  
106535 124 031061 050011  
106570 030524 004463 042522  
106616 030524 004464 041101  
106652 030524 004465 053111  
106704 030524 004466 040511  
106736 030524 004467 042522  
106771 124 030062 042011  
107017 124 030462 047011  
107035 124 031062 047411  
107056 031124 004463 047507  
107077 124 032062 053411  
107123 124 032462 042411  
107147 124 033062 050011  
107203 124 033462 044411  
107237 124 030063 051011  
107276 031524 004461 042522  
107327 124 031063 051011  
107363 124 031463 044411  
107416 031524 004464 047111  
107450 031524 004465 047111  
107510 031524 004466 051127  
107543 124 033463 047411  
107561 124 030064 042411  
107610 032124 004461 046522  
107626 032124 004462 040520  
107655 124 031464 044411  
107710 032124 004464 042523  
107740 032124 004465 042523  
107771 124 033064 051411  
110023 124 033464 051411  
110055 124 030065 051411  
110122 032524 004461 042523  
110155 124 031065 051411  
110210 032524 004463 042523  
110241 124 032065 051411  
110271 124 032465 051411  
110324 032524 004466 053111

HELP: = BUFFER  
.ASCII <CR><LF>  
@  
@T1  
@T2  
@T3  
@T4  
@T5  
@T6  
@T7  
@T10  
@T11  
@T12  
@T13  
@T14  
@T15  
@T16  
@T17  
@T20  
@T21  
@T22  
@T23  
@T24  
@T25  
@T26  
@T27  
@T30  
@T31  
@T32  
@T33  
@T34  
@T35  
@T36  
@T37  
@T40  
@T41  
@T42  
@T43  
@T44  
@T45  
@T46  
@T47  
@T50  
@T51  
@T52  
@T53  
@T54  
@T55  
@T56

LIST OF TESTS@<CR><LF>  
\*\*\*\*\*@<CR><LF>  
CONTROLLER ACCESS TEST@<CR><LF>  
DEVICE AVAILABLE TEST@<CR><LF>  
DRIVE TYPE TEST@<CR><LF>  
UNIBUS INITIALIZE TEST@<CR><LF>  
CONTROLLER CLEAR TEST@<CR><LF>  
ERROR CLEAR TEST@<CR><LF>  
DRIVE STATUS TEST@<CR><LF>  
PRIMARY/SECONDARY ERROR TEST@<CR><LF>  
DIAGNOSTIC MODE TEST@<CR><LF>  
PACK ACKNOWLEDGE TEST@<CR><LF>  
RECALIBRATE TEST@<CR><LF>  
ABORT RECALIBRATE TEST@<CR><LF>  
IVC RECALIBRATE TEST@<CR><LF>  
IAE RECALIBRATE TEST@<CR><LF>  
RECALIBRATE AT OFFSET@<CR><LF>  
DRIVE CLEAR TEST@<CR><LF>  
NOP TEST@<CR><LF>  
OFFSET TEST@<CR><LF>  
GO/ATA TEST@<CR><LF>  
WRITE ATA TEST@<CR><LF>  
ERROR/ATA TEST@<CR><LF>  
PROGRAM INTERRUPT TEST@<CR><LF>  
INHIBIT INTERRUPT TEST@<CR><LF>  
RETURN TO CENTERLINE TEST@<CR><LF>  
READ IN PRESET TEST@<CR><LF>  
RMDC CLEAR OFFSET TEST@<CR><LF>  
ILLEGAL FUNCTION TEST@<CR><LF>  
INVALID COMMAND TEST@<CR><LF>  
INVALID ADDRESS ERROR TEST@<CR><LF>  
WRITE LOCK ERROR TEST@<CR><LF>  
OPI TEST@<CR><LF>  
ERROR ABORT TESTS@<CR><LF>  
RMR TEST@<CR><LF>  
PARITY ERROR TEST@<CR><LF>  
ILLEGAL REGISTER TEST@<CR><LF>  
SEEK LAST CYLINDERS@<CR><LF>  
SEEK FIRST CYLINDERS@<CR><LF>  
SEEK PRIME CYLINDERS@<CR><LF>  
SEEK ZERO DIFFERENCE@<CR><LF>  
SEEK MAXIMUM DIFFERENCE FORWARD@<CR><LF>  
SEEK ADJACENT FORWARD@<CR><LF>  
SEEK ADJACENT REVERSE@<CR><LF>  
SEEK INVALID SECTORS@<CR><LF>  
SEEK INVALID TRACKS@<CR><LF>  
SEEK INVALID CYLINDERS@<CR><LF>  
IVC SEEK TEST@<CR><LF>

```

110347      124 033465 040411 .ASCII @T57 ABORT SEEK TEST@<CR><LF>
110374      033124 004460 042523 .ASCII @T60 SEEK AT OFFSET@<CR><LF>
110420      033124 004461 047514 .ASCII @T61 LOOK AHEAD TEST@<CR><LF>
110445      124 031066 051411 .ASCII @T62 SEARCH ON CYLINDER@<CR><LF>
110475      124 031466 051411 .ASCII @T63 SEARCH OFF CYLINDER@<CR><LF>
110526      033124 004464 042523 .ASCII @T64 SEARCH INVALID SECTOR@<CR><LF>
110561      124 032466 051411 .ASCII @T65 SEARCH INVALID TRACK@<CR><LF>
110613      124 033066 051411 .ASCII @T66 SEARCH INVALID CYLINDER@<CR><LF>
110650      033124 004467 053111 .ASCII @T67 IVC SEARCH TEST@<CR><LF>
110675      124 030067 040411 .ASCII @T70 ABORT SEARCH TEST@<CR><LF>
110724      033524 004461 042523 .ASCII @T71 SEARCH AT OFFSET@<CR><LF>
110752      033524 004462 042510 .ASCII @T72 HEAD ALIGNMENT SEEK @<CR><LF>
111004      005015 .ASCII <CR><LF>
111006      047411 042520 040522 .ASCII @ OPERATIONAL SWITCH SETTINGS@<CR><LF>
111044      057411 057537 057537 .ASCII @ *****@<CR><LF>
111102      005015 .ASCII <CR><LF>
111104      053523 052111 044103 .ASCII @SWITCH USE@<CR><LF>
111122      026455 026455 026455 .ASCII @-----@<CR><LF>
111160      020040 032461 004411 .ASCII @ 15 HALT ON ERROR@<CR><LF>
111205      040 030440 004464 .ASCII @ 14 LOOP ON TEST@<CR><LF>
111231      040 030440 004463 .ASCII @ 13 INHIBIT ERROR TYPEOUTS@<CR><LF>
111267      040 030440 004462 .ASCII @ 12 @<CR><LF>
111277      040 030440 004461 .ASCII @ 11 INHIBIT ITERATIONS@<CR><LF>
111331      040 030440 004460 .ASCII @ 10 BELL ON ERROR@<CR><LF>
111356      020040 034440 004411 .ASCII @ 9 LOOP ON ERROR@<CR><LF>
111403      040 020040 004470 .ASCII @ 8 LOOP ON TEST IN SWR<7:0>@<CR><LF>
111443      040 020040 004467 .ASCII @ 7 TN128@<CR><LF>
111460      020040 033040 004411 .ASCII @ 6 TN64@<CR><LF>
111474      020040 032440 004411 .ASCII @ 5 TN32@<CR><LF>
111510      020040 032040 004411 .ASCII @ 4 TN16@<CR><LF>
111524      020040 031440 004411 .ASCII @ 3 TN8@<CR><LF>
111537      040 020040 004462 .ASCII @ 2 TN4@<CR><LF>
111552      020040 030440 004411 .ASCII @ 1 TN2@<CR><LF>
111565      040 020040 004460 .ASCII @ 0 TN1@<CR><LF>
111600      005015 .ASCII <CR><LF>
111602      005015 000 .ASCII <CR><LF>
111602      000001 .END

```







BITS = 000040	1616#																				
BIT6 = 000100	1615#	9356																			
BIT7 = 000200	1614#	4000	9707																		
BIT8 = 000400	1613#																				
BIT9 = 001000	1612#																				
BOTADR 043154	9195#	9213*	9216	9231	9276#																
BOTFLG 043156	9181#	9223*	9226	9229*	9277#																
BPTVEC= 000014	1628#																				
BSE = 100000	1837#	10318																			
BUFFER 106126	8191	8211	12989#																		
BUFONE 106126	6209	6318	6433	6548	6672	6765	12989#														
BUFTWO 107132	12989#																				
CC = 004000	1821#																				
CH = 002000	1822#																				
CHRCNT 043157	9182#	9200*	9206*	9207	9210*	9214	9219*	9230*	9278#												
CKSWR = 104410	12371	12505	12531	12882#																	
CLEAN = ***** U	12989																				
CLKADR 001500	2177#	9663*	9665	9669*	9671	9696															
CLKVCT 001502	2178#	9664*	9670*																		
CLR = 000040	1912#	4007	10857																		
CLRSTS 053476	4531	7641	7736	7835	9366	10893#															
CLSPRN 066306	4078	4094	4115	12989#																	
CMNSTA 006754	4030	4165#																			
CMPERR 061566	5370	5446	5508	5545	5637	5821	5970	6057	7110	7183	7255	7338	7418								
	7498	7578	7675	7770	7869	7956	8038	8123	8320	8431	8522	8612	8705								
	8803	8884	8963	9053	11980#																
CNSL00 066452	4040	12989#																			
CNSL01 066511	4075	12989#																			
CNSL02 066536	4084	12989#																			
CNSL03 066617	4089	12989#																			
CNSL04 066647	4100	12989#																			
CNSL05 066723	4110	12989#																			
CNSL06 066757	4121	12989#																			
CNSL07 067004	4134	12989#																			
CNTCLR 053360	4264	4308	4352	4481	4519	4558	4605	4671	4718	4865	6169	6284	6393								
	6508	6623	6748	6917	6980	7629	7724	7823	7904	8149	8539	8634	8727								
	9346	10849#																			
CONT = 000100	1785#																				
CR = 000015	1536#	4148	9198	12059	12346	12356	12989														
CRLF = 000200	1537#	3984	12317	12356																	
CYLSK= 001777	1812#																				
DBCK = 100000	1758#																				
DBEN = 040000	1759#	4372	4501	6859																	
DBL = 002000	1929#																				
DCK = 100000	1719#	1736	10356	10376																	
DDISP = 177570	1543#	2029	3948																		
DEBL = 020000	1760#																				
DEVSEL 051706	6988	9333	10559#																		
DISPLA 001156	2029#	3948*	3956*	12427*	12508*																
DISPRE 000174	1956#	3956																			
DLT = 100000	1901#	10200																			
DMD = 000001	1772#	1791#	4372	4501	4726	4738	4740	4777	4789	4791	4873	5085	6180								
	6189	6295	6304	6404	6413	6519	6528	6634	6643	6663	6825	6834	6859								
	7912	8758																			
DPE = 000010	1844#	5372	5448	5547	5823	5972	6059	7112	7185	7257	7340	7420	7500								
	7580	7677	7772	7871	7958	8040	8125	8322	8433	8524	8614	8707	8805								



K07

CZRMCB0 RMO3/2 FCTNL TST 1  
CZRMCB.P11 23-NOV-77 12:14

MACY11 30(1046) 23-NOV-77 12:25 PAGE 296  
CROSS REFERENCE TABLE -- USER SYMBOLS

SEQ 0295

DPEHI = 040000	8886	8965	9055	9862	10142	10638	11177	11607						
DPELO = 020000	1925#													
DPR = 000400	1926#													
DRQ = 004000	1712#	4461	4462	4648	10799	10996	10997	11463						
DRVCLR= 000010	1798#													
DRVSTS 056714	1656#	4834	5286	11451										
DRY = 000200	5316	11442#												
DSWR = 177570	1713#	4461	4462	4648	9829	9925	9928	9929	10799	10996	10997	11463		
DTE = 010000	1542#	2028	3947											
DTO = 010000	1722#	1736												
DULPRT= 024024	1761#													
DVA = 004000	1801#	4323	4327	4330										
DVC = 000200	1641#	4013	4283	4401	9552	9625	9790	9793	10584	10902	11450	11451		
EARLY = 067700	1843#	4457	4626	4632	4768	4771	4819	4822	4823	10731	10986	11238	11276	
EBL = 020000	11279	11412	11680	11721	11724	11919	11924	11927						
ECH = 000100	12989#													
ECI = 004000	1778#													
ECRC = 001000	1728#	1736	10339	10354	10372	10378	12989							
EDT1 = 074230	1806#	6020	6042	10374										
	2212	2219	2226	2233	2240	2247	2261	2268	2275	2282	2289	2296	2303	
	2310	2317	2324	2331	2338	2345	2352	2359	2366	2373	2380	2387	2394	
	2401	2408	2415	2422	2429	2436	2443	2450	2457	2464	2471	2478	2485	
	2492	2499	2507	2514	2521	2528	2535	2543	2551	2559	2573	2580	2587	
	2594	2601	2608	2615	2623	2630	2637	2644	2651	2658	2665	2672	2679	
	2686	2693	2700	2707	2714	2721	2728	2735	2742	2749	2756	2763	2770	
	2812	2819	2826	2833	2840	2847	2854	2861	2868	2875	2882	2889	2896	
	2903	2910	2917	2924	2931	2938	2945	2952	2959	2966	2973	2980	2987	
	2994	3001	3008	3015	3022	3029	3036	3043	3050	3057	3064	3071	3078	
	3100	3107	3114	3121	3128	3135	3142	3149	3156	3163	3170	3177	3184	
	3205	3212	3219	3226	3233	3240	3247	3254	3261	3268	3275	3282	3289	
	3450	3457	3464	3471	3478	3485	3492	3499	3506	3513	3520	3527	3534	
	3546	3553	3560	3567	3574	3581	3588	3595	3602	3609	3616	3623	3630	
	3641	3648	3655	3662	3669	3676	3683	3690	3697	3704	3711	3718	3725	
	3732	3739	3746	3753	3760	3767	3774	3781	3788	3795	3802	3809	3816	
	3872	12989#												
EDT110 074246	2714	12989#												
EDT111 074250	2721	12989#												
EDT114 074252	2742	12989#												
EDT2 074240	3191	3198	3394	3401	12989#									
EDT223 074254	3240	3429	12989#											
EDT336 074264	3016	3774	3788	3795	12989#									
EDT337 074274	3781	12989#												
EDT344 074304	3816	12989#												
EDT353 074316	3865	12989#												
ED1 103702	12989#													
ED110 103710	12989#													
ED111 103714	12989#													
ED114 103722	12989#													
ED223 103732	12989#													
ED336 103742	12989#													
ED337 103754	12989#													
ED353 103766	12989#													
EECC = 000020	1787#													
EFT1 074320	2213	2220	2227	2234	2241	2248	2262	2269	2276	2283	2290	2297	2304	
	2311	2318	2325	2332	2339	2346	2353	2360	2367	2374	2381	2388	2395	

		2402	2409	2416	2423	2430	2437	2444	2451	2458	2465	2472	2479	2486
		2493	2500	2508	2515	2522	2529	2536	2544	2552	2560	2574	2581	2588
		2595	2602	2609	2616	2624	2631	2638	2645	2652	2659	2666	2673	2680
		2687	2694	2701	2708	2715	2722	2729	2736	2743	2750	2757	2764	2771
		2778	2785	2792	2799	2806	2813	2820	2827	2834	2841	2848	2855	2862
		2869	2876	2883	2890	2897	2904	2911	2918	2925	2932	2939	2946	2953
		2960	2967	2974	2981	2988	2995	3002	3009	3016	3023	3030	3037	3044
		3051	3058	3065	3072	3079	3086	3093	3100	3107	3114	3121	3128	3135
		3142	3149	3156	3163	3170	3177	3184	3191	3198	3205	3212	3219	3226
		3233	3240	3247	3254	3261	3268	3275	3282	3289	3296	3303	3310	3317
		3324	3331	3338	3345	3352	3359	3366	3373	3380	3387	3394	3401	3408
		3415	3422	3429	3436	3443	3450	3457	3464	3471	3478	3485	3492	3499
		3506	3513	3520	3527	3534	3541	3548	3555	3562	3569	3576	3583	3590
		3597	3604	3611	3618	3625	3632	3639	3646	3653	3660	3667	3674	3681
		3688	3695	3702	3709	3716	3723	3730	3737	3744	3751	3758	3765	3772
		3779	3786	3793	3800	3807	3814	3821	3828	3835	3842	3849	3856	3863
		3870	3877	3884	3891	3898	3905	3912	3919	3926	3933	3940	3947	3954
		3961	3968	3975	3982	3989	3996	4003	4010	4017	4024	4031	4038	4045
		4052	4059	4066	4073	4080	4087	4094	4101	4108	4115	4122	4129	4136
		4143	4150	4157	4164	4171	4178	4185	4192	4199	4206	4213	4220	4227
		4234	4241	4248	4255	4262	4269	4276	4283	4290	4297	4304	4311	4318
		4325	4332	4339	4346	4353	4360	4367	4374	4381	4388	4395	4402	4409
		4416	4423	4430	4437	4444	4451	4458	4465	4472	4479	4486	4493	4500
		4507	4514	4521	4528	4535	4542	4549	4556	4563	4570	4577	4584	4591
		4598	4605	4612	4619	4626	4633	4640	4647	4654	4661	4668	4675	4682
		4689	4696	4703	4710	4717	4724	4731	4738	4745	4752	4759	4766	4773
		4780	4787	4794	4801	4808	4815	4822	4829	4836	4843	4850	4857	4864
		4871	4878	4885	4892	4899	4906	4913	4920	4927	4934	4941	4948	4955
		4962	4969	4976	4983	4990	4997	5004	5011	5018	5025	5032	5039	5046
		5053	5060	5067	5074	5081	5088	5095	5102	5109	5116	5123	5130	5137
		5144	5151	5158	5165	5172	5179	5186	5193	5200	5207	5214	5221	5228
		5235	5242	5249	5256	5263	5270	5277	5284	5291	5298	5305	5312	5319
		5326	5333	5340	5347	5354	5361	5368	5375	5382	5389	5396	5403	5410
		5417	5424	5431	5438	5445	5452	5459	5466	5473	5480	5487	5494	5501
		5508	5515	5522	5529	5536	5543	5550	5557	5564	5571	5578	5585	5592
		5599	5606	5613	5620	5627	5634	5641	5648	5655	5662	5669	5676	5683
		5690	5697	5704	5711	5718	5725	5732	5739	5746	5753	5760	5767	5774
		5781	5788	5795	5802	5809	5816	5823	5830	5837	5844	5851	5858	5865
		5872	5879	5886	5893	5900	5907	5914	5921	5928	5935	5942	5949	5956
		5963	5970	5977	5984	5991	5998	6005	6012	6019	6026	6033	6040	6047
		6054	6061	6068	6075	6082	6089	6096	6103	6110	6117	6124	6131	6138
		6145	6152	6159	6166	6173	6180	6187	6194	6201	6208	6215	6222	6229
		6236	6243	6250	6257	6264	6271	6278	6285	6292	6299	6306	6313	6320
		6327	6334	6341	6348	6355	6362	6369	6376	6383	6390	6397	6404	6411
		6418	6425	6432	6439	6446	6453	6460	6467	6474	6481	6488	6495	6502
		6509	6516	6523	6530	6537	6544	6551	6558	6565	6572	6579	6586	6593
		6600	6607	6614	6621	6628	6635	6642	6649	6656	6663	6670	6677	6684
		6691	6698	6705	6712	6719	6726	6733	6740	6747	6754	6761	6768	6775
		6782	6789	6796	6803	6810	6817	6824	6831	6838	6845	6852	6859	6866
		6873	6880	6887	6894	6901	6908	6915	6922	6929	6936	6943	6950	6957
		6964	6971	6978	6985	6992	6999	7006	7013	7020	7027	7034	7041	7048
		7055	7062	7069	7076	7083	7090	7097	7104	7111	7118	7125	7132	7139
		7146	7153	7160	7167	7174	7181	7188	7195	7202	7209	7216	7223	7230
		7237	7244	7251	7258	7265	7272	7279	7286	7293	7300	7307	7314	7321
		7328	7335	7342	7349	7356	7363	7370	7377	7384	7391	7398	7405	7412
		7419	7426	7433	7440	7447	7454	7461	7468	7475	7482	7489	7496	7503
		7510	7517	7524	7531	7538	7545	7552	7559	7566	7573	7580	7587	7594
		7601	7608	7615	7622	7629	7636	7643	7650	7657	7664	7671	7678	7685
		7692	7699	7706	7713	7720	7727	7734	7741	7748	7755	7762	7769	7776
		7783	7790	7797	7804	7811	7818	7825	7832	7839	7846	7853	7860	7867
		7874	7881	7888	7895	7902	7909	7916	7923	7930	7937	7944	7951	7958
		7965	7972	7979	7986	7993	8000	8007	8014	8021	8028	8035	8042	8049
		8056	8063	8070	8077	8084	8091	8098	8105	8112	8119	8126	8133	8140
		8147	8154	8161	8168	8175	8182	8189	8196	8203	8210	8217	8224	8231
		8238	8245	8252	8259	8266	8273	8280	8287	8294	8301	8308	8315	8322
		8329	8336	8343	8350	8357	8364	8371	8378	8385	8392	8399	8406	8413
		8420	8427	8434	8441	8448	8455	8462	8469	8476	8483	8490	8497	8504
		8511	8518	8525	8532	8539	8546	8553	8560	8567	8574	8581	8588	8595
		8602	8609	8616	8623	8630	8637	8644	8651	8658	8665	8672	8679	8686
		8693	8700	8707	8714	8721	8728	8735	8742	8749	8756	8763	8770	8777
		8784	8791	8798	8805	8812	8819	8826	8833	8840	8847	8854	8861	8868
		8875	8882	8889	8896	8903	8910	8917	8924	8931	8938	8945	8952	8959
		8966	8973	8980	8987	8994	9001	9008	9015	9022	9029	9036	9043	9050
		9057	9064	9071	9078	9085	9092	9099	9106	9113	9120	9127	9134	9141
		9148	9155	9162	9169	9176	9183	9190	9197	9204	9211	9218	9225	9232
		9239	9246	9253	9260	9267	9274	9281	9288	9295	9302	9309	9316	9323
		9330	9337	9344	9351	9358	9365	9372	9379	9386	9393	9400	9407	9414
		9421	9428	9435	9442	9449	9456	9463	9470	9477	9484	9491	9498	9505
		9512	9519	9526	9533	9540	9547	9554	9561	9568	9575	9582	9589	9596
		9603	9610	9617	9624	9631	9638	9645	9652	9659	9666	9673	9680	9687
		9694	9701	9708	9715	9722	9729	9736	9743	9750	9757	9764	9771	9778
		9785	9792	9799	9806	9813	9820	9827	9834	9841	9848	9855	9862	9869
		9876	9883	9890	9897	9904	9911	9918	9925	9932	9939	9946	9953	9960
		9967	9974	9981	9988	9995	10002	10009	10016	10023	10030	10037	10044	10051
		10058	10065	10072	10079	10086	10093	10100	10107	10114	10121	10128	10135	10142
		10149	10156	10163	10170	10177	10184	10191	10198	10205	10212	10219	10226	10233
		10240	10247	10254	10261	10268	10275	10282	10289	10296	10303	10310	10317	10324
		10331	10338	10345	10352	10359	10366	10373	10380	10387	10394	10401	10408	10415
		10422	10429	10436	10443	10450	10457	10464	10471	10478	10485	10492	10499	10506
		10513	10520	10527	10534	10541	10548	10555	10562	10569	10576	10583	10590	10597
		10604	10611	10618	10625	10632	10639	10646	10653	10660	10667	10674	10681	10688
		10695	10702	10709	10716	10723	10730	10737	10744	10751	10758	10765	10772	10779
		10786	10793	10800	10807									

EH111	102663	12989#
EH114	102702	12989#
EH223	102731	12989#
EH256	102757	12989#
EH336	103034	12989#
EH337	103073	12989#
EH344	103232	12989#
EH353	103372	12989#
EMS1	074406	12989#
EMS10	074742	12989#
EMS100	077162	12989#
EMS101	077210	12989#
EMS102	077236	12989#
EMS103	077265	12989#
EMS104	077274	12989#
EMS105	077323	12989#
EMS106	077352	12989#
EMS11	075004	12989#
EMS110	077371	12989#
EMS111	077420	12989#
EMS112	077431	12989#
EMS113	077515	12989#
EMS114	077545	12989#
EMS115	077571	12989#
EMS116	077576	12989#
EMS117	077626	12989#
EMS12	075015	12989#
EMS120	077650	12989#
EMS121	077665	12989#
EMS122	077730	12989#
EMS123	077765	12989#
EMS124	100030	12989#
EMS125	100062	12989#
EMS126	100125	12989#
EMS127	100170	12989#
EMS13	075056	12989#
EMS130	100227	12989#
EMS131	100265	12989#
EMS132	100325	12989#
EMS133	100351	12989#
EMS134	100374	12989#
EMS135	100436	12989#
EMS136	100500	12989#
EMS137	100525	12989#
EMS14	075067	12989#
EMS140	100562	12989#
EMS141	100603	12989#
EMS142	100631	12989#
EMS143	100646	12989#
EMS144	100674	12989#
EMS145	100704	12989#
EMS146	100733	12989#
EMS147	100752	12989#
EMS15	075100	12989#
EMS150	100767	12989#
EMS151	101006	12989#

EMS152	101032	12989#
EMS153	101056	12989#
EMS154	101100	12989#
EMS155	101114	12989#
EMS156	101134	12989#
EMS157	101152	12989#
EMS16	075122	12989#
EMS160	101167	12989#
EMS161	101204	12989#
EMS162	101234	12989#
EMS163	101267	12989#
EMS164	101313	12989#
EMS165	101374	12989#
EMS166	101410	12989#
EMS167	101435	12989#
EMS17	075152	12989#
EMS170	101462	12989#
EMS171	101511	12989#
EMS172	101544	12989#
EMS173	101564	12989#
EMS174	101601	12989#
EMS175	101607	12989#
EMS176	101635	12989#
EMS177	101664	12989#
EMS2	074455	12989#
EMS20	075212	12989#
EMS200	101706	12989#
EMS201	101723	12989#
EMS202	101771	12989#
EMS203	102021	12989#
EMS204	102034	12989#
EMS205	102062	12989#
EMS206	102074	12989#
EMS207	102121	12989#
EMS21	075235	12989#
EMS210	102146	12989#
EMS211	102157	12989#
EMS212	102175	12989#
EMS213	102220	12989#
EMS214	102243	12989#
EMS215	102261	12989#
EMS216	102302	12989#
EMS217	102332	12989#
EMS22	075260	12989#
EMS220	102365	12989#
EMS221	102405	12989#
EMS222	102455	12989#
EMS223	102506	12989#
EMS224	102563	12989#
EMS23	075274	12989#
EMS24	075322	12989#
EMS25	075351	12989#
EMS26	075366	12989#
EMS27	075407	12989#
EMS3	074472	12989#
EMS30	075420	12989#

EMS31	075430	12989#		
EMS32	075457	12989#		
EMS33	075506	12989#		
EMS34	075534	12989#		
EMS35	075605	12989#		
EMS36	075634	12989#		
EMS37	075663	12989#		
EMS4	074535	12989#		
EMS40	075711	12989#		
EMS41	075740	12989#		
EMS42	075766	12989#		
EMS43	076015	12989#		
EMS44	076044	12989#		
EMS45	076117	12989#		
EMS46	076162	12989#		
EMS47	076211	12989#		
EMS5	074600	12989#		
EMS50	076240	12989#		
EMS51	076267	12989#		
EMS52	076315	12989#		
EMS53	076327	12989#		
EMS54	076341	12989#		
EMS55	076363	12989#		
EMS56	076412	12989#		
EMS57	076467	12989#		
EMS6	074630	12989#		
EMS60	076515	12989#		
EMS61	076530	12989#		
EMS62	076557	12989#		
EMS63	076575	12989#		
EMS64	076623	12989#		
EMS65	076641	12989#		
EMS66	076707	12989#		
EMS67	076757	12989#		
EMS7	074675	12989#		
EMS70	077004	12989#		
EMS71	077016	12989#		
EMS72	077031	12989#		
EMS73	077041	12989#		
EMS74	077056	12989#		
EMS75	077075	12989#		
EMS76	077103	12989#		
EMS77	077134	12989#		
EMTVEC=	000030	1631#	3931*	3932*
EMT1	070012	2210	12989#	
EMT10	070062	2259	12989#	
EMT100	071060	2656	12989#	
EMT101	071076	2663	12989#	
EMT102	071114	2670	12989#	
EMT103	071124	2677	12989#	
EMT104	071136	2684	12989#	
EMT105	071154	2691	12989#	
EMT106	071164	2698	12989#	
EMT107	071174	2705	12989#	
EMT11	070066	2266	12989#	
EMT110	071214	2712	12989#	

EMT111	071226	2719	12989#
EMT112	071234	2726	12989#
EMT113	071242	2733	12989#
EMT114	071256	2740	12989#
EMT115	071264	2747	12989#
EMT116	071274	2754	12989#
EMT117	071304	2761	12989#
EMT12	070072	2273	12989#
EMT120	071314	2768	12989#
EMT121	071324	2775	12989#
EMT122	071334	2782	12989#
EMT123	071344	2789	12989#
EMT124	071354	2796	12989#
EMT125	071364	2803	12989#
EMT126	071374	2810	12989#
EMT127	071406	2817	12989#
EMT13	070100	2280	12989#
EMT130	071420	2824	12989#
EMT131	071432	2831	12989#
EMT132	071444	2838	12989#
EMT133	071456	2845	12989#
EMT134	071470	2852	12989#
EMT135	071502	2859	12989#
EMT136	071514	2866	12989#
EMT137	071526	2873	12989#
EMT14	070112	2287	12989#
EMT140	071536	2880	12989#
EMT141	071546	2887	12989#
EMT142	071556	2894	12989#
EMT143	071566	2901	12989#
EMT144	071576	2908	12989#
EMT145	071606	2915	12989#
EMT146	071616	2922	12989#
EMT147	071626	2929	12989#
EMT15	070120	2294	12989#
EMT150	071636	2936	12989#
EMT151	071646	2943	12989#
EMT152	071660	2950	12989#
EMT153	071672	2957	12989#
EMT154	071710	2964	12989#
EMT155	071726	2971	12989#
EMT156	071740	2978	12989#
EMT157	071752	2985	12989#
EMT16	070126	2301	12989#
EMT160	071764	2992	12989#
EMT161	071774	2999	12989#
EMT162	072006	3006	12989#
EMT163	072020	12989#	
EMT164	072030	3021	12989#
EMT165	072036	3028	12989#
EMT166	072044	3035	12989#
EMT167	072052	3042	12989#
EMT17	070136	2308	12989#
EMT170	072060	12989#	
EMT171	072070	3056	12989#
EMT172	072100	3063	12989#

EMT173	072110	3070	12989#
EMT174	072120	3077	12989#
EMT175	072132	3084	12989#
EMT176	072140	3091	12989#
EMT177	072146	3098	12989#
EMT2	070016	2217	12989#
EMT20	070146	2315	12989#
EMT200	072160	3105	12989#
EMT201	072172	3112	12989#
EMT202	072204	3119	12989#
EMT203	072216	3126	12989#
EMT204	072230	3133	12989#
EMT205	072246	3140	12989#
EMT206	072256	3147	12989#
EMT207	072266	3154	12989#
EMT21	070156	2322	12989#
EMT210	072300	3161	12989#
EMT211	072306	3168	12989#
EMT212	072322	3175	12989#
EMT213	072336	3182	12989#
EMT214	072346	3189	12989#
EMT215	072366	3196	12989#
EMT216	072400	3203	12989#
EMT217	072410	3210	12989#
EMT22	070166	2329	12989#
EMT220	072420	3217	12989#
EMT221	072430	3224	12989#
EMT222	072440	3231	12989#
EMT223	072450	3238	12989#
EMT224	072460	12989#	
EMT225	072462	12989#	
EMT226	072464	12989#	
EMT227	072466	12989#	
EMT23	070176	2336	12989#
EMT230	072470	12989#	
EMT231	072472	12989#	
EMT232	072474	12989#	
EMT233	072476	12989#	
EMT234	072500	12989#	
EMT235	072502	12989#	
EMT236	072504	12989#	
EMT237	072506	12989#	
EMT24	070206	2343	12989#
EMT240	072510	12989#	
EMT241	072512	12989#	
EMT242	072514	12989#	
EMT243	072516	12989#	
EMT244	072520	12989#	
EMT245	072522	12989#	
EMT246	072524	3371	12989#
EMT247	072534	3378	12989#
EMT25	070216	2350	12989#
EMT250	072546	3385	12989#
EMT251	072562	3392	12989#
EMT252	072570	3399	12989#
EMT253	072576	3406	12989#

EMT254	072614	3413	12989#
EMT255	072624	3420	12989#
EMT256	072634	3427	12989#
EMT257	072644	3434	12989#
EMT26	070226	2357	12989#
EMT260	072656	3441	12989#
EMT261	072670	3448	12989#
EMT262	072710	3455	12989#
EMT263	072720	3462	12989#
EMT264	072730	3469	12989#
EMT265	072750	3476	12989#
EMT266	072770	3483	12989#
EMT267	073002	3491	12989#
EMT27	070236	2364	12989#
EMT270	073020	3498	12989#
EMT271	073034	3506	12989#
EMT272	073052	3513	12989#
EMT273	073070	3520	12989#
EMT274	073106	3528	12989#
EMT275	073124	3536	12989#
EMT276	073136	3544	12989#
EMT277	073152	3553	12989#
EMT3	070024	2224	12989#
EMT30	070246	2371	12989#
EMT300	073170	3561	12989#
EMT301	073210	3569	12989#
EMT302	073232	3576	12989#
EMT303	073244	3583	12989#
EMT304	073256	3590	12989#
EMT305	073270	3597	12989#
EMT306	073302	3604	12989#
EMT307	073312	3611	12989#
EMT31	070256	2378	12989#
EMT310	073332	3618	12989#
EMT311	073344	3625	12989#
EMT312	073356	3632	12989#
EMT313	073370	3639	12989#
EMT314	073410	3646	12989#
EMT315	073422	3653	12989#
EMT316	073434	3660	12989#
EMT317	073446	3667	12989#
EMT32	070266	2385	12989#
EMT320	073456	3674	12989#
EMT321	073466	3681	12989#
EMT322	073476	3688	12989#
EMT323	073504	3695	12989#
EMT324	073514	3702	12989#
EMT325	073526	3709	12989#
EMT326	073540	3716	12989#
EMT327	073556	3723	12989#
EMT33	070276	2392	12989#
EMT330	073570	3730	12989#
EMT331	073600	3737	12989#
EMT332	073612	3744	12989#
EMT333	073624	3751	12989#
EMT334	073642	3758	12989#



EMT335	073660	3765	12989#
EMT336	073700	3014	3772 12989#
EMT337	073710	3779	12989#
EMT34	070306	2399	12989#
EMT340	073720	3786	12989#
EMT341	073732	3793	12989#
EMT342	073740	3800	12989#
EMT343	073752	3807	12989#
EMT344	073764	3814	12989#
EMT345	073776	3821	12989#
EMT346	074006	3828	12989#
EMT347	074022	3835	12989#
EMT35	070316	2406	12989#
EMT350	074034	3842	12989#
EMT351	074052	3849	12989#
EMT352	074062	3856	12989#
EMT353	074066	3863	12989#
EMT354	074076	3870	12989#
EMT36	070326	2413	12989#
EMT37	070336	2420	12989#
EMT4	070032	2231	12989#
EMT40	070346	2427	12989#
EMT41	070354	2434	12989#
EMT42	070364	2441	12989#
EMT43	070376	2448	12989#
EMT44	070406	2455	12989#
EMT45	070416	2462	12989#
EMT46	070426	2469	12989#
EMT47	070436	2476	12989#
EMT5	070040	2238	12989#
EMT50	070444	2483	12989#
EMT51	070454	2490	12989#
EMT52	070466	2497	12989#
EMT53	070504	2505	12989#
EMT54	070522	2512	12989#
EMT55	070532	2519	12989#
EMT56	070544	2526	12989#
EMT57	070562	2533	12989#
EMT6	070046	2245	12989#
EMT60	070572	2541	12989#
EMT61	070610	2549	12989#
EMT62	070630	2557	12989#
EMT63	070644	12989#	
EMT64	070646	2571	12989#
EMT65	070666	2578	12989#
EMT66	070706	2585	12989#
EMT67	070720	2592	12989#
EMT7	070054	2252	12989#
EMT70	070732	2599	12989#
EMT71	070742	2606	12989#
EMT72	070752	2613	12989#
EMT73	070770	2621	12989#
EMT74	071006	2628	12989#
EMT75	071016	2635	12989#
EMT76	071036	2642	12989#
EMT77	071046	2649	12989#

ENRGDT 070012  
EQUALS 066307  
ERR = 040000  
ERRNMB 043152  
ERRTYP 042414  
ERRVEC= 000004

12989#													
12989#													
1706#	4620	6249	6358	6473	6588	6712	9971	9973	9989	10023			
9162#	9163#	9166	9178	9183	9275#								
9141#	12518												
1624#	3945	3946#	3957#	4224	4225	4226#	4227#	4238#	4239#	4243#	4244#	4270	
4271	4272#	4273#	4277#	4278#	4289#	4290#	6974	6975	6976#	6977#	7050#	7051#	
8155	8156	8157#	8158#	8236#	8237#	9543	9544	9548#	9549#	9580#	9581#	9616	
9617	9621#	9622#	9647#	9648#	9659	9660	9661#	9662#	9668#	9676#	9677#	9691	
9692	9693#	9694#	9718#	9719#	10566	10567	10570#	10571#	10604#	10605#	10852	10853	
10854#	10855#	10866#	10867#	12378	12379#	12381#	12384#						

ERTY00 043160  
ERTY01 043166  
ERTY02 043176  
ERTY03 043205  
ERTY04 043213  
ESRC = 004000  
FER = 000020  
FIND = 000001

9148	9280#												
9156	9281#												
9165	9283#												
9171	9285#												
9267	9287#												
1780#													
1730#	1736	10303											
4531#	4532	4539#	4540	4693#	4694	4700#	4701	4905#	4906	4912#	4913	4920#	
4921	4942#	4944#	4965#	4966	4972#	4973	4979#	4980	5001#	5003#	5041#	5042	
5048#	5049	5055#	5056	5076#	5078#	5117#	5118	5127#	5128	5148#	5150#	5176#	
5177	5183#	5184	5190#	5191	5212#	5214#	5237#	5239#	5241#	5242	5247#	5248	
5254#	5255	5261#	5262	5278#	5280#	5309#	5310	5316#	5317	5323#	5324	5341#	
5343#	5363#	5364	5370#	5373#	5379#	5380	5386#	5387	5404#	5406#	5427#	5428	
5446#	5449#	5455#	5456	5462#	5463	5480#	5482#	5508#	5511#	5532#	5533	5545#	
5548#	5554#	5555	5561#	5562	5579#	5581#	5624#	5625	5637#	5640#	5657#	5659#	
5715#	5716	5722#	5723	5740#	5742#	5795#	5796	5814#	5815	5821#	5824#	5830#	
5831	5837#	5838	5855#	5857#	5928#	5930#	5951#	5952	5970#	5973#	5979#	5980	
5986#	5987	6005#	6007#	6035#	6036	6057#	6060#	6066#	6067	6073#	6074	6091#	
6093#	6113#	6114	6160#	6162#	6234#	6235	6275#	6277#	6343#	6344	6384#	6386#	
6458#	6459	6499#	6501#	6573#	6574	6614#	6616#	6697#	6698	6738#	6740#	6745#	
6748#	6749	6778#	6779	6784#	6785#	6786	6791#	6792	6814#	6816#	6821#	6850#	
6851	6884#	6885	6908#	6910#	6917#	6918	6933#	6934	6939#	6940	6966#	6968#	
6988#	6989	7000#	7001	7068#	7070#	7096#	7097	7103#	7104	7110#	7113#	7119#	
7120	7141#	7143#	7169#	7170	7176#	7177	7183#	7186#	7192#	7193	7215#	7217#	
7241#	7242	7248#	7249	7255#	7258#	7264#	7265	7294#	7296#	7324#	7325	7331#	
7332	7338#	7341#	7347#	7348	7374#	7376#	7404#	7405	7411#	7412	7418#	7421#	
7427#	7428	7455#	7457#	7484#	7485	7491#	7492	7498#	7501#	7507#	7508	7535#	
7537#	7564#	7565	7571#	7572	7578#	7581#	7587#	7588	7611#	7613#	7641#	7642	
7654#	7655	7660#	7661	7667#	7668	7675#	7678#	7684#	7685	7706#	7706#	7736#	
7737	7755#	7756	7762#	7763	7770#	7773#	7779#	7780	7805#	7807#	7835#	7836	
7854#	7855	7861#	7862	7869#	7872#	7878#	7879	7942#	7943	7956#	7959#	7965#	
7966	7983#	7985#	8024#	8025	8031#	8032	8038#	8041#	8047#	8048	8069#	8071#	
8101#	8109#	8110	8116#	8117	8123#	8126#	8132#	8133	8184#	8185	8249#	8251#	
8279#	8280	8286#	8287	8306#	8307	8313#	8314	8320#	8323#	8329#	8330	8358#	
8360#	8390#	8391	8397#	8398	8417#	8418	8424#	8425	8431#	8434#	8440#	8441	
8472#	8474#	8502#	8503	8515#	8516	8522#	8525#	8531#	8532	8567#	8569#	8598#	
8599	8612#	8615#	8621#	8622	8655#	8657#	8685#	8686	8698#	8699	8705#	8708#	
8714#	8715	8749#	8751#	8789#	8790	8803#	8806#	8812#	8813	8829#	8831#	8870#	
8871	8877#	8878	8884#	8887#	8893#	8894	8910#	8912#	8949#	8950	8956#	8957	
8963#	8966#	8972#	8973	9011#	9013#	9039#	9040	9046#	9047	9053#	9056#	9062#	
9063													
1805#	6020	6042	6213	6322	6437	6552	6676	6769	7787	7789	7886	7888	
8160	8212	8229	8338	8340	8452	8457	8629	8631	8722	8724	8918	10663	
11654													
6240	6248	6349	6357	6464	6472	6579	6587	6703	6711	10017	12989#		

FMT16 = 010000  
FNCDTB 067254

ENCMSK= 000077  
FO = 000002  
F1 = 000004  
F2 = 000010  
F3 = 000020  
F4 = 000040  
GET 044216

1648# 11450  
1646# 9916  
1645# 9916  
1644# 9916 10490  
1643# 9916  
1642# 9916  
4317 4393 4525 4575 4612 4687 4733 4784 4841 4899 4959 5026 5035  
5111 5170 5241 5303 5357 5421 5496 5526 5595 5618 5673 5703 5789  
5808 5910 5945 6029 6107 6136 6228 6337 6452 6567 6691 6785 6850  
6884 6939 6994 7090 7163 7235 7318 7398 7478 7558 7635 7654 7730  
7749 7829 7848 7936 8006 8018 8103 8178 8273 8300 8384 8411 8496  
8592 8679 8783 8852 8864 8943 9033 9359 9383 9410 9433 9459 9534#

GETBUF 001326  
GETINX 001504  
GETSTS 044132

2112# 9546  
2183# 4314\* 4315\* 4572\* 4573\* 4574\* 9381\* 9382\* 9431\* 9432\* 9492 9547  
4392 4524 4611 4685 4732 4897 4957 5025 5109 5168 5237 5301 5356  
5419 5495 5594 5672 5781 5879 5943 6027 6106 6166 6281 6390 6505  
6620 6745 6821 6973 7088 7161 7233 7316 7396 7476 7556 7627 7722  
7821 7929 7999 8089 8170 8266 8377 8488 8584 8671 8776 8845 8931  
9031 9358 9409 9452 9488#  
1955 3983 9100 9107 12873 12874 12875 12876 12877 12878 12880 12882 12883

GNS = \*\*\*\*\* U

GO = 000001

12884 12885 12886 12887  
1647# 4679 4834 4891 4951 5019 5103 5157 5221 5230 5286 5350 5413  
5489 5519 5588 5666 5696 5775 5882 5937 6021 6100 6200 6207 6316  
6424 6431 6539 6546 6654 6670 6763 6843 6868 6877 7077 7150 7222  
7304 7383 7464 7544 7617 7712 7811 7919 7992 8078 8092 8163 8259  
8292 8369 8404 8481 8577 8664 8768 8836 8919 8935 9020 9393 9442  
9704 9815 9827 9832 9848 9938 9941

GTSWR = 104407  
HCE = 000200  
HCI = 002000  
HCRC = 000400  
HELP 106126  
HELPGS 066317  
HT = 000011  
IAE = 002000

3978 4199 12880#  
1727# 1736 10266 10271 10286 10288 10301 10316 12989  
1807# 6020 6042 10264  
1726# 1736 10273  
4060 12989#  
4054 12989#  
1534# 9204 12315 12356  
1724# 6465 6467 7676 7771 7870 8508 8510 8512 8523 8604 8606 8608  
8613 8691 8693 8695 8706 10170 10467 10482 10508 10654 10671 11170 11224  
11227 11645 11663 12989  
1883# 9560 9563 9633 9636  
1897# 1930# 5775 5882  
1734# 6241 6243 10042 10044 11064 11124 11128 11170 11191 11194 12989

IDXMSK= 000077  
IE = 000100  
ILF = 000001  
ILF02 = 000002  
ILF24 = 000024  
ILF26 = 000026  
ILF30 = 000030  
ILF32 = 000032  
ILF34 = 000034  
ILF36 = 000036  
ILF40 = 000040  
ILF42 = 000042  
ILF44 = 000044  
ILF46 = 000046  
ILF54 = 000054  
ILF56 = 000056  
ILF64 = 000064  
ILF66 = 000066  
ILF74 = 000074

1653#  
1663#  
1664#  
1666#  
1667#  
1668#  
1669#  
1670#  
1671#  
1672#  
1673#  
1676#  
1677#  
1680#  
1681#  
1684#

ILF76 = 000076	1685#	6260	6369	6484	6599	6723	6800													
ILR = 000002	1733#	7008	7036	11064	11110	11114	11378	11382	11385											
ILRG50 = 000050	1869#																			
ILRG52 = 000052	1870#																			
ILRG54 = 000054	1871#																			
ILRG56 = 000056	1872#																			
ILRG60 = 000060	1873#																			
ILRG62 = 000062	1874#																			
ILRG64 = 000064	1875#																			
ILRG66 = 000066	1876#																			
ILRG70 = 000070	1877#																			
ILRG72 = 000072	1878#																			
ILRG74 = 000074	1879#																			
ILRG76 = 000076	1880#																			
IOTVEC = 000020	1629#	3929*	3930*																	
IPCK0 = 000001	1934#																			
IPCK1 = 000002	1933#																			
IPCK2 = 000004	1932#																			
IPCK3 = 000010	1931#																			
IR = 000100	1911#	4414	10927																	
IVC = 010000	1840#	5123	6350	6352	7948	7950	7952	7958	8795	8797	8799	8805	10085							
	10086	10689	10812	11238	11245	11248	11317	11680	11704	11707	11794	11888	12989							
LBC = 002000	1842#	4846	4849	4850																
LBT = 002000	1710#	4620	10245	10469	10471															
LF = 000012	1535#	9202	12059	12350	12356	12989														
LS = 000004	1789#	4437	10951	11503																
LSC = 004000	1841#	5289																		
LST = 000002	1790#	4437	10951	11503																
MCLK = 004000	1762#																			
MCPE = 020000	1891#	4582	9815	9832	9845	9848	11625	11630												
MDF = 000100	1767#	4777																		
MDPE = 000400	1908#	4587	10341																	
MEDENB = 001472	2171#	4210*	9392*																	
MFGFIL = 104106	12989#																			
MI = 000004	1770#																			
MIXED = 067364	12989#																			
MOC = 000400	1765#	4777	6189	6304	6413	6528	6643	6663	6834	6859										
MOH = 020000	1797#																			
MOL = 010000	1708#	4617	4621	4648	4744	4747	4795	4798	4799	10750	10760	10761	10766							
	10771	10799	11050	11053	11214	11291	11292	11299	11304	11463	11744	11755	11756							
	11760	11763	11865	11866	11870	11875														
MRD = 002000	1763#																			
MS = 000040	1768#																			
MSC = 000002	1771#																			
MSE = 100000	1848#																			
MSER = 000200	1766#	4777																		
MUR = 001000	1764#	4777	6189	6304	6413	6528	6643	6834	6859											
MWD = 000010	1788#	4438	10952	11504																
MWP = 000010	1769#	4777	6528																	
MXF = 001000	1907#	4587	10230																	
NDTMSK = 115760	1736#	5371	5447	5546	5822	5971	6058	7111	7184	7256	7339	7419	7499							
	7579	7676	7771	7870	7957	8039	8124	8321	8432	8523	8613	8706	8804							
	8885	8964	9054																	
NED = 010000	1904#	4010	4279	4587	9797	9801	10579													
NEM = 004000	1905#	10215																		
NOP = 000000	1652#	4538	5350	5519	5696	5894	6167	6282	6391	6506	6621	6746	6868							

NOTEX	067230	4018	12989#											
NSA	= 100000	1795#												
OCC	= 100000	1776#												
OFD	= 000200	1808#	6020	6042										
OFFSET	= 000014	1658#	5221	5413	5489	5588	5666	5775	5882	6100	6877	8078	8919	
OM	= 000001	1715#	4648	5433	5436	5437	5957	5961	6119	6122	6123	6141	6144	11291
		11347	11350	11462										
ONES	067424	12989#												
OPE	= 020000	1839#												
OPI	= 020000	1721#	6704	6706	10069	10744	10768	11064	11082	11086	11170	11207	11210	11301
		11737	11740	11765	11872	12989								
OR	= 000200	1910#												
PACACK	= 000022	1662#												
PAKACK	= 000022	1661#	1662	4679	4891	6200	6424	6539	6654	6843	9393			
PAR	= 000010	1731#	6945	6947	9860	9864	9876	10636	11170	11175	11180	11605	11612	
PAT	= 000020	1913#	6925											
PDA	= 000400	1783#												
PGE	= 002000	1906#	4587											
PGM	= 001000	1711#	4648	11462										
PHA	= 000200	1784#												
PIP	= 020000	1707#	4620	4750	4753	4754	4801	4804	5031	8011	8014	8857	8861	9440
		10760	10781	10786	11291	11362	11367	11462	11755	11776	11781	11865	11902	11907
PIRQ	= 177772	1541#												
PIRQVE	= 000240	1635#												
PLFS	= 002000	1781#												
PRIERR	045212	4693	4905	4965	5041	5117	5176	5247	5309	5363	5427	5532	5624	5795
		5814	5951	6035	6113	6234	6343	6458	6573	6697	6791	7000	7096	7169
		7241	7324	7404	7484	7564	7660	7755	7854	7942	8024	8109	8184	8279
		8306	8390	8417	8502	8598	8685	8789	8870	8949	9039	9763#		
PROMPT	066311	4135	4144	12989#										
PRO	= 000000	1558#												
PR1	= 000040	1559#												
PR2	= 000100	1560#												
PR3	= 000140	1561#	12038											
PR4	= 000200	1562#												
PR5	= 000240	1563#												
PR6	= 000300	1564#	3916	4205	4227	4273	5752	5761	5866	5869	6977	8158	9549	9622
		9662	9694	10571	10855	12044								
PR7	= 000340	1565#	5759	5875										
PS	= 177776	1538#	1539											
PSEL	= 002000	1893#												
PSW	= 177776	1539#												
PUT	044466	4362	4384	4491	4512	4567	4680	4727	4778	4835	4874	4883	4892	4952
		5011	5020	5086	5095	5104	5163	5222	5231	5296	5351	5414	5490	5520
		5589	5612	5667	5688	5697	5768	5776	5883	5895	5938	6022	6101	6130
		6181	6190	6201	6222	6296	6305	6331	6405	6414	6425	6446	6520	6529
		6540	6561	6635	6644	6655	6664	6685	6757	6778	6826	6835	6844	6860
		6869	6878	6933	7083	7156	7228	7311	7390	7471	7551	7648	7743	7842
		7913	7930	8000	8084	8095	8172	8267	8293	8378	8405	8490	8586	8673
		8759	8777	8846	8926	8936	9026	9396	9445	9610#				
PUTBUF	001376	2139#	9619											
PUTINX	001533	2188#	4359*	4360*	4376	4488*	4489*	4504	4564*	4565*	4677*	4678*	4724*	4725*
		4775#	4776*	4832*	4833*	4871*	4872*	4880*	4881*	4889*	4890*	4949*	4950*	5008*
		5009#	5017*	5018*	5083*	5084*	5092*	5093*	5101*	5102*	5158	5219*	5220*	5228*
		5229#	5290	5348*	5349*	5411*	5412*	5487*	5488*	5517*	5518*	5586*	5587*	5610*
		5611#	5664*	5665*	5685*	5686*	5694*	5695*	5766*	5767*	5773*	5774*	5880*	5881*



RMDA = 000006

1854#	5160	5291	6013	6218	6327	6442	6557	6681	6774	6930	7080	7153
7225	7306	7385	7467	7546	7623	7719	7816	7925	7994	8081	8165	8261
8374	8485	8579	8668	8772	8841	8921	9023	11656				
2118#	6046	6048	10513	12989								
2145#	5156*	5285*	6018*	6211*	6320*	6435*	6550*	6674*	6767*	6927*	7075*	7148*
7221*	7303*	7382*	7463*	7543*	7620*	7689*	7690	7714*	7784*	7785	7790*	7812*
7921*	7990*	8076*	8161*	8256*	8335*	8336	8342*	8364*	8448*	8449	8458*	8479*
8536*	8537	8575*	8626*	8627	8632*	8662*	8766*	8838*	8916*	9018*	10439	10440
10659	10661	10665	11650	11652								
1941#	4236*	4237	4359	4488	9499							
2124#												
2151#	4358*	4487*										
1863#	5159	6014	6128	6219	6328	6443	6558	6682	6775	7079	7152	7224
7307	7386	7466	7547	7624	7718	7817	7926	7995	8080	8166	8262	8373
8483	8580	8667	8771	8840	8922	9022						
2129#	6051	6053	10525	12989								
2156#	5155*	6019*	6127*	6212*	6321*	6436*	6551*	6675*	6768*	7076*	7149*	7213*
7269	7271*	7302*	7381*	7434	7436*	7462*	7514	7516*	7542*	7594	7596*	7619*
7713*	7813*	7883*	7884	7889*	7922*	7991*	8077*	8162*	8257*	8370*	8403*	8480*
8576*	8663*	8719*	8720	8725*	8765*	8837*	8917*	9019*	10441	10656	11647	
1855#	9381	9431										
2120#	4460	4617	4619	4622	4645	4647	4649	4744	4746	4750	4752	4756
4758	4795	4797	4801	4803	4807	4809	4825	4827	5031	5433	5435	5439
5441	5501	5504	5538	5540	5600	5602	5630	5632	5678	5680	5708	5711
5957	5960	5963	5965	6119	6121	6141	6143	6249	6253	6358	6362	6473
6477	6588	6592	6712	6716	8011	8013	8857	8860	9390	9440	9829	9925
9927	9972	9989	10023	10027	10083	10110	10245	10470	10695	10750	10759	10766
10770	10772	10781	10785	10787	10796	10798	10800	10810	10814	10816	10995	11036
11038	11040	11050	11052	11054	11214	11252	11290	11299	11303	11305	11315	11319
11320	11331	11333	11335	11347	11349	11351	11362	11366	11368	11461	11711	11744
11754	11760	11762	11764	11776	11780	11782	11792	11796	11798	11808	11810	11812
11864	11870	11874	11876	11886	11890	11891*	11892	11902	11906	11908	12989	

RMDB = 000022

RMDBI = 001350

RMDBO = 001420

RMDC = 000034

RMDCI = 001362

RMDCO = 001432

RMDS = 000012

RMDSI = 001340

RMDSO = 001410

RMDT = 000026

RMDTI = 001354

RMDTO = 001424

RMEC1 = 000044

RMEC1I = 001372

RMEC1O = 001442

RMEC2 = 000046

RMEC2I = 001374

RMEC2O = 001444

RMER1 = 000014

RMER1I = 001342

RMER1O = 001412

RMER2 = 000042

RMER2I = 001370

2147#												
1860#	4314											
2126#	4316*	4321	4323	4325	4327	12989						
2153#												
1867#												
2133#	12989											
2160#												
1868#	9494											
2134#	4444	9493	10963	11527	12989							
2161#												
1856#	4378	4506	5008	5293	5685	6754	7996	8842	9868			
2121#	4421	4634	4636	4640	4642	6242	6466	6581	6705	6891	6894	6945
6948	7007	8508	8511	8604	8607	8691	8694	9860	9875	9877	9967	10043
10070	10113	10128	10171	10248	10274	10289	10304	10357	10376	10379	10467	10482
10497	10508	10636	10643	10670	10744	10747	10768	10940	11064	11068	11070	11071
11082	11084	11085	11096	11098	11099	11110	11112	11113	11124	11126	11127	11170
11175	11179	11181	11191	11193	11195	11207	11209	11211	11224	11226	11228	11301
11378	11382	11384	11386	11396	11398	11400	11410	11414	11416	11474	11605	11611
11613	11662	11737	11739	11741	11765	11872	11983	12989				
2148#	4370*	4499*	5010*	5287*	5687*	6756*	7989*	8835*	9864			
1866#	4379	4507	5292									
2132#	4456	4626	4628	4632	4653	4655	4762	4764	4768	4770	4813	4815
4819	4821	4846	4848	5123	6351	7948	7951	8795	8798	9862	9969	10087
10143	10319	10638	10689	10692	10703	10731	10734	10783	10812	10985	11177	11238

M08

CZRMCB0 RMO3/2 FCTNL TST 1  
CZRMCB.P11 23-NOV-77 12:14

MACY11 30(1046) 23-NOV-77 12:25 PAGE 311  
CROSS REFERENCE TABLE -- USER SYMBOLS

SEQ 0310

	11245	11247	11249	11262	11264	11266	11276	11278	11280	11317	11364	11412	11536
	11607	11680	11684	11704	11706	11708	11721	11723	11725	11778	11794	11888	11904
	11918	11924	11926	11928	11938	11940	11942	11986	12989				
RMER20 = 001440	2159#	4371*	4500*	5288*	5289*								
RMLA = 000020	1858#	8193	8194	8203									
RMLAI = 001346	2123#	12989											
RMLAO = 001416	2150#												
RMMR1 = 000024	1859#	4380	4508	4724	4775	4871	4880	5083	5092	6178	6187	6293	6302
	6402	6411	6517	6526	6632	6641	6661	6823	6832	6857	7910	7924	8756
	8770												
RMMR1I = 001352	2125#	4436	4738	4741	4789	4792	10950	11502	12989				
RMMR1O = 001422	2152#	4372*	4501*	4726*	4777*	4873*	4882*	5085*	5094*	6180*	6189*	6295*	6304*
	6404*	6413*	6519*	6528*	6634*	6643*	6663*	6825*	6834*	6859*	7912*	7920*	8758*
	8764*												
RMMR2 = 000040	1865#												
RMMR2I = 001366	2131#	4448	10972	11514	12989								
RMMR2O = 001436	2158#												
RMOF = 000032	1862#	6015	6217	6326	6441	6556	6680	6773	7622	7717	7818	8167	8263
	8372	8484	8581	8666	8773	8923							
RMOFI = 001360	2128#	6041	10264	10374	11654	12989							
RMOFO = 001430	2155#	6020*	6213*	6322*	6437*	6552*	6676*	6769*	7618*	7715*	7787	7789*	7814*
	7886	7888*	8160*	8212	8229	8231*	8258*	8338	8340*	8365*	8452	8457*	8478*
	8574*	8629	8631*	8661*	8722	8724*	8767*	8918*	10663	12989			
	1732#	6891	6893	11064	11096	11100	11378	11396	11399				
	1861#												
RMR = 000004	2127#	12989											
RMSN = 000030	2154#												
RMSNI = 001356	1938#	4230*	4231	6216	6325	6440	6555	6679	6772				
RMSNO = 001426	2116#	10398	10410	10428	10492	12989							
RMWC = 000002	2143#	6210*	6319*	6434*	6549*	6673*	6766*	10411	10429				
RMWCI = 001330	1817#	4449	10973	11515									
RMWCO = 001400	1818#	4449	10973	11515									
RQA = 100000	1659#	5937											
RQB = 040000	1701#												
RTC = 000016	9142	12886*											
SADMSK = 000037	1696#												
SAVREG = 104414	1692#												
SA1 = 000001	1695#												
SA16 = 000020	1694#												
SA2 = 000002	1693#												
SA4 = 000004	1889#	4400	9815	9832	9848	10901							
SAB = 000010	8313	8424	8956	11596*									
SC = 100000	12989#												
SCHSTS = 057516	1752#												
SCTMSG = 066176	1750#												
SCTMSK = 003700	1749#												
SCO = 000100	1748#												
SC1 = 000200	1747#												
SC2 = 000400	1746#												
SC3 = 001000	1665#	8163	8292	8404	8481	8577	8664	8768	8836	8935	9991	10392	
SC4 = 002000	4539	4700	4920	4979	5055	5127	5190	5261	5323	5386	5462	5561	5722
SEARCH = 000030	5837	5986	6073	7119	7192	7264	7347	7427	7507	7587	7684	7779	7878
SECERR = 046044	7965	8047	8132	8329	8440	8531	8621	8714	8812	8893	8972	9062	9911*
	1654#	7077	7150	7222	7304	7383	7464	7544	7617	7712	7811	7919	7992
SEEK = 000004	8092	8259	8369	9020									
SEKSTS = 052120	7103	7176	7248	7331	7411	7491	7571	7667	7762	7861	8116	8286	8397













		10469*	10472	10481*	10494*	10499	10510*	10511*	10512*	10514	10523*	10524*	10526	10642*
		10654*	10667*	10672	10691*	10705*	10706*	10733*	10746*	10770*	10771*	10785*	10798*	10799*
		10814*	10815*	10902*	10903	10912*	10928*	10930	10939*	10952*	10953	10962*	10974*	10975
		10984*	10997*	10998	11038*	11039*	11052*	11053*	11071*	11072*	11085*	11086*	11099*	11100*
		11113*	11114*	11127*	11128*	11179*	11180*	11193*	11194*	11209*	11210*	11226*	11227*	11247*
		11248*	11264*	11265*	11278*	11279*	11303*	11304*	11319*	11321*	11333*	11334*	11349*	11350*
		11366*	11367*	11384*	11385*	11398*	11399*	11414*	11415*	11451*	11452	11463*	11464	11473*
		11504*	11505	11516*	11517	11525*	11611*	11612*	11629*	11630*	11645*	11658*	11664	11686*
		11687*	11688	11692	11706*	11707*	1.723*	11724*	11739*	11740*	11762*	11763*	11780*	11781*
		11796*	11797*	11810*	11811*	11874*	11875*	11890*	11906*	11907*	11926*	11927*	11940*	11941*
		11999*	12014*	12989										
\$GET42	042364	9114#												
\$GTSMR	064472	12650#	12880											
\$HD =	000001	1505	1506											
\$HIBTS	001100	1994#												
\$HIOCT	065442	12832*	12837#											
\$ICNT	001120	2012#	12416*	12417	12419*	12430								
\$ILLUP	065712	12892	12908	12925#										
\$INTAG	001151	2026#	12647*	12666	12686	12799								
\$ITEMB	001130	2016#	9163	12515*	12523	12544								
\$LF	001220	2048#	12356	12544	12782	12792								
\$LFLG	066173	12975*	12981#											
\$LPADR	001122	2013#	3941*	4216*	4343*	4935*	4993*	5069*	5141*	5204*	7060*	7133*	7206*	7286*
		7366*	7447*	7527*	8061*	8991*	12398*	12407*	12423*	12428	12430			
\$LPERR	001124	2014#	3942*	4217*	4344*	4936*	4994*	5070*	5142*	5205*	7061*	7134*	7207*	7287*
		7367*	7448*	7528*	8062*	8992*	12407	12424*	12430	12534				
\$MADR1	001254	2081#												
\$MADR2	001260	2085#												
\$MADR3	001264	2088#												
\$MADR4	001270	2091#												
\$MAIL	001222	1995	1999	2054#	3959	3974	4195	4222	4262	4306	4349	4479	4556	4603
		4669	4716	4863	4941	4999	5075	5147	5210	5277	5340	5403	5478	5577
		5655	5738	5853	5927	6003	6089	6158	6273	6382	6497	6612	6736	6812
		6906	6964	7066	7139	7212	7292	7372	7453	7533	7608	7704	7803	7902
		7981	8067	8147	8248	8357	8470	8566	8653	8747	8827	8909	8997	12300
		12422	12521											
\$MAMS1	001252	2075#												
\$MAMS2	001256	2083#												
\$MAMS3	001262	2086#												
\$MAMS4	001266	2089#												
\$MBADR	001102	1995#												
\$MFLG	066172	12935*	12941	12976*	12980#									
\$MNEW	065330	12653	12797#											
\$MSGAD	001236	2061#	12951*	12954										
\$MSGLG	001240	2062#	12956*											
\$MSGTY	001222	2055#	12949	12957*	12969	12973*								
\$MSWR	065317	12650	12795#											
\$MTYP1	001253	2076#												
\$MTYP2	001257	2084#												
\$MTYP3	001263	2087#												
\$MTYP4	001267	2090#												
\$MXCNT	063516	12420	12430#											
\$NULL	001170	2034#	12327	12356										
\$NWTST=	000001	4211#	4213	4252#	4254	4296#	4298	4335#	4337	4469#	4471	4546#	4548	4593#
		4595	4660#	4707#	4853#	4855	4927#	4929	4986#	5062#	5134#	5197#	5267#	5269
		5330#	5332	5393#	5395	5469#	5568#	5646#	5729#	5844#	5918#	5920	5993#	5995







CZRMCOB0 RM03/2 FCTNL TST 1  
CZRMCOB.P11 23-NOV-77 12:14

MACY11 30(1046) 23-NOV-77 12:25 PAGE 320  
CROSS REFERENCE TABLE -- USER SYMBOLS

SEQ 0319

12356	12430	12431	12544	12547	12551#	12552	12553#	12791#	12792	12799#	12904	12926
12983#	12989#											
12935	12938											
1983#	1988											

.SASTA= \*\*\*\*\* U  
.SX = 001100