

Micro Fiche Scan

Name of device(s) tested:

RD31/51/52/53/54,RQDX3,RX33

Test description:

RQDX3 FORMATTER

MAINDEC Number or Package Identifier (after SEP 1977):

CZRQCC0

Fiche Document Part Number:

AH-U110C-MC

Fiche preparation date unknown, using copyright year:

1986

Image resolution:

1-bit black&white, compressed for minimal file size

COPYRIGHT (C) 1985-86 by d|i|g|i|t|a|l

1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36

.REM \*C

IDENTIFICATION

PRODUCT CODE: AC U109C MC  
PRODUCT NAME: CZRQCC0 RQDX3 FORMATTER  
PRODUCT DATE: JUNE 6, 1986  
MAINTAINER: DIAGNOSTIC ENGINEERING  
AUTHOR: Richard Dietz

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS DOCUMENT.

NO RESPONSIBILITY IS ASSUMED FOR THE USE OR RELIABILITY OF SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL OR ITS AFFILIATED COMPANIES.

COPYRIGHT (C) 1986 BY DIGITAL EQUIPMENT CORPORATION

THE FOLLOWING ARE TRADEMARKS OF DIGITAL EQUIPMENT CORPORATION:

DIGITAL  
DEC

PDP  
DECUS

UNIBUS  
DECTAPE

MASSBUS

38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55  
56  
57  
58  
59

TABLE OF CONTENTS

1.	ABSTRACT	What is it?
2.		How to run it?
2.1		Hardware Requirements
2.2		Software Requirements
2.3		Questions asked and their answers
2.3.1		Hardware Questions from diagnostic software
2.3.2		Manual Questions from controller firmware
2.3.3		UIT tables
2.4		Program messages and format completion
2.5		Execution time
3.		Errors
4.		Program design and flow
5.		Modification of UIT for additional drives
6.		GLOSSARY
7.		BIBLIOGRAPHY
8.		REVISION HISTORY

61  
62  
63  
64  
65  
66  
67  
68  
69  
70  
71  
72  
73  
74  
75  
76  
77  
78  
79  
80  
81  
82  
83  
84  
85  
86  
87  
88  
89  
90  
91  
92  
93  
94  
95  
96  
97  
98  
99  
100  
101  
102  
103  
104  
105  
106  
107  
108  
109  
110  
111  
112  
113  
114  
115  
116  
117

## 1.0 ABSTRACT

This formatter was written to format Winchester drives attached to the RQDX3 disk controller. All new drives being attached to the RQDX3 controller must be formatted so that the drive can be brought online for use by a MSCP server or in simpler terms to be used by an operating system. This disk formatter is similar to the RQDX1/2 disk formatter in that the same standard DUP dialog is used and similar standard formatter questions are passed by the controller to the host user. The formatter is different from the RQDX1/2 disk formatter because a table of disk formatting parameters is passed to the controller. The RQDX1/2 disk controller already has these tables in its firmware.

The format program actually has 2 controller run programs in it. If the controller is an RQDX3, the program will down line load a program into the controller which will identify the drive according to its cylinder size. Since each of the DEC drives have a different cylinder size it will know which drive it is and therefore which parameter or UIT table to pass to the controller. The second program is already contained in the microcode. This program called "FORMAT" does the actual formatting of the drive. The host program just passes information back and forth to the controller local program.

The UIT, Unit Information Table is picked by the down line loaded auto sizer program (AUTOSZ). After the drive is known the format program will be run on the controller. This format program (FORMAT) is very similar to the RQDX1/2 format program. The only difference as stated before is that the UIT will be down line loaded into the drive if the down line load question is asked. Every time the drive is brought on line the UIT table which was placed on the drive by this formatter program will be transferred into the controller with all the drive parameters. As long as the UIT still exists on the drive it does not have to be passed in by the host user. Only if the user requests to "Down line load" information to the controller will the UIT table be passed to the drive. Note the RX33 floppy drive does not use the UIT tables. The RX33 drive parameters are stored in the firmware so a table wasn't necessary.

The UIT table contains information about the drive such as size, number of tracks per surface, etc. This information is already known for certain DEC acquired Winchester drives. These tables are usually different for the different drives manufactured. CAUTION do not use non DEC drives you are liable to destroy Format and Data stored on them.

All though not a goal of the diagnostic this program can be used to run standard DUP dialog local programs such as "DIRECT". These local programs are stored in the firmware.

## 2.0 HOW TO RUN IT?

### 2.1 HARDWARE REQUIREMENTS

118  
119  
120  
121  
122  
123  
124  
125  
126  
127  
128  
129  
130  
131  
132  
133  
134  
135  
136  
137  
138  
139  
140  
141  
142  
143  
144  
145  
146  
147  
148  
149  
150  
151  
152  
153  
154  
155  
156  
157  
158  
159  
160  
161  
162  
163  
164  
165  
166  
167  
168  
169  
170  
171  
172  
173  
174

An RQDX3 disk controller and one or more Winchester or RX33 drives configured into a Q bus PDP 11 system.

## 2.2 SOFTWARE REQUIREMENTS

This diagnostic was written using DRS the Diagnostic Supervisor. The diagnostic is expected to be run under XXDP diagnostic operating system. It is also possible to run the formatter under APT.

## 2.3 QUESTIONS ASKED AND THEIR ANSWERS

### 2.3.1 HARDWARE QUESTIONS FROM DIAGNOSTIC SOFTWARE

The diagnostic is a standard DRS program with the standard DRS commands. Below I have a script of the questions asked and the answers to the initial DRS questions. The Default value for the IP address is 172150. This is standard configuration address for the first MSCP controller on a system. Any other MSCP controllers on the system will have to be in the floating address space of the IO page. The default vector address is 154 any other value between 0 774 could be used but is not suggested. If you want the default answers then just hit the "return" key on the keyboard. The Formatter will run an auto sizer to determine the proper drive characteristic table to give to the controller. This auto sizer will figure out how many cylinders on the drive and through a small look up table we decide which table to down line load to the RQDX3 controller. The user will have to enter a drive number and a serial number. After this a warning message will appear asking if the user wants to proceed. The default is no so the user must type "Y" in order to format his drives.

#### Typical Diagnostic Script:

```
boot up XXDP
.RUN ZRQC??
ZRQCCO.BIN

DRSXM-A0
ZRQC-C-0
RQDX3 Disk Park\Format Utility
Unit is RD51,RD52,RD53,RD54,RX33,RD31           Please type yes to "Change HW?"
Restart Address is 141656
DR>START

Change HW ? Y
# Units ? 1

IP Address 172150 ? <rtn>
Vector Address 154 ? <rtn>
Just Park heads N ? <rtn>
Logical Drive (0-255) 0 ? <rtn>
Drive Serial Number(1 32000) 12345 ? <rtn>

***** WARNING all the data on this drive will be DESTROYED *****

Proceed to format the drive N ? <Y><rtn>
```

175  
176  
177  
178  
179  
180  
181  
182  
183  
184  
185  
186  
187  
188  
189  
190  
191  
192  
193  
194  
195  
196  
197  
198  
199  
200  
201  
202  
203  
204  
205  
206  
207  
208  
209  
210  
211  
212  
213  
214  
215  
216  
217  
218  
219  
220  
221  
222  
223  
224  
225  
226  
227  
228  
229  
230  
231

### 2.3.2 UIT TABLES

The UIT tables are stored in this program. There are 10 large data tables formed in this diagnostic that contain the drive parameters for certain DEC drives. There are only 6 RQDX3 Winchester drive manufactures. So only 6 of the tables contain any information. The others are there for future drives. The AUTOSZ program ran previous to the FORMAT program will determine what type of drive is to be formatted and which table to pass to the disk controller. Once in the disk controller the table will be written to the disk drive. This table should never be erased unless the drive is broken or format is run again.

NOTE this is only for the RQDX3 disk controller and NOT for the RQDX1/2.

Unit Information Tables listed:

Enter UIT:

UIT Drive Name

0:	RD51
1:	RD52 part # 30 21721 02 (1 light on front panel)
2:	RD52 part # 30 23227 02 (2 lights on front panel)
3:	RD53
4:	RD31
5:	RD54
6:	
7:	
10:	

### 2.4 PROGRAM MESSAGES AND FORMAT COMPLETION

When the format finally starts a "Format Begun" message will appear and in the end a "Format Complete" message will appear. There may be 60+ minutes between the messages. If the extended messages are allowed 3 "Verification Pass XXXXXX Begun" messages may appear. These messages tell when the controller checks the blocks for bad spots in the disk surface. These passes take several minutes each and touch all the cylinders on the drive. At the end of the format if extended messages are on a table will be printed out reporting the results of the format. Usually there are several bad spots on a disk. This is very common and is NOT a mistake. These bad blocks are revectorred to new areas on the disk. If the manufactures bad block information is used which is usually the case. There will only be 1 verification pass. After the drive formats the autosizer program will be run again. This will park the heads on the inner most cylinder. Some manufactures have a parking area where the heads are placed before the drive is physically moved or shipped to the customer. If you plan on moving your system you should backup your system and run the formatter to put the heads on the parking area. This will help prevent damage to the heads and formatted data surfaces.

Completion Report:

xxx Revectorred LBNS  
xxx Primary revectorred LBNS

232  
233  
234  
235  
236  
237  
238  
239  
240  
241  
242  
243  
244  
245  
246  
247  
248  
249  
250  
251  
252  
253  
254  
255  
256  
257  
258  
259  
260  
261  
262  
263  
264  
265  
266  
267  
268  
269  
270  
271  
272  
273  
274  
275  
276  
277  
278  
279  
280  
281  
282  
283  
284  
285  
286  
287  
288

xxx Secondary/tertiary revectoring LBNs  
xxx Bad Blocks in the RCT area due to data errors  
xxx Bad Blocks in the DBN area due to data errors  
xxx Bad Blocks in the XBN area due to data errors  
xxx Blocks retired on check pass  
FCT was not used  
Format Completed

RQDX Drive xxxx finished  
PLEASE wait .... Parking drive heads

pass aborted for this unit  
ZRQC EOP 1  
0 Cumulative errors

Note that every time the disk formats successfully the program drops the UNIT. This is purposely done so one doesn't reformat it twice.

RX33 diskette formatting is a little varied in that several extra questions will be asked. These questions were installed mainly to protect the person trying to format a diskette on the same drive as their boot media. If the drive doing the formatting is not the boot drive then please ignore the warnings.

WARNING Remove boot diskette if in drive.  
Insert a diskette to be formatted & press <RETURN>.

Format Complete  
FCT was not used  
Format completed

Do you want to format another diskette?

If boot drive, reinsert boot diskette & press <RETURN>.

RQDX Drive xxxx finished  
pass aborted for this unit  
ZRQC EOP 1  
0 Cumulative errors

## 2.5 EXECUTION TIME

The execution time for this diagnostic varies greatly according to the size of the drive being formatted. If an error in the drive configuration or state such as a write protect switch being on, an error will occur right after all the questions have been answered. If there are no errors the formatter will take between 5 minutes to 60 minutes depending on the drive being formatted. A RD51 takes between 10 minutes to format depending on the way questions are answered. A RD52 take between 10 & 25 minutes to format and a RD53 a very long time to format. The program checks continuously to make sure the controller is still working. If no progress is indicated by the progress indicator a timeout error will occur. If the disk controller goes off line for some unapparent reason the formatter will know. Either way if one checks the light on the

289  
290  
291  
292  
293  
294  
295  
296  
297  
298  
299  
300  
301  
302  
303  
304  
305  
306  
307  
308  
309  
310  
311  
312  
313  
314  
315  
316  
317  
318  
319  
320  
321  
322  
323  
324  
325  
326  
327  
328  
329  
330  
331  
332  
333  
334  
335  
336  
337  
338  
339  
340  
341  
342  
343  
344  
345

Winchester to see if it is lite or check the READY light of the drive for a flickering light, this will tell the user that the formatter is working. When the formatter completes a "Format complete" message will appear on the terminal.

### 3. ERRORS

There are many types of errors possible while formatting a drive. First the system has to be configured right. The drives have to be jumpered right along with the disk controller. If you get an error read the entire error message carefully. See if there is something simple wrong such as loss and misconfigured drives before calling FS. This is usually the case very seldom do the drive or controller break. So check the cables, check the jumpers, try several times and if you still can't format then call Field Service.

error #	Comment	Problem
0,SF0	;unkown response	Not a DUP standard local program or Data Error in local program execution.
1,HRD0	;Fatal DUP type returned	Error with Format program check detailed error message more then likely this will be a drive error or drive configuration error. If the detailed message has a GET STATUS error. This means that the drive you asked to format had the wrong status. Example offline,write protected, RX50 instead of an RDxx, power plug us loose, jumpers are wrong.
2,DF3	;Can't do remote programs"	Wrong controller or bad microcode controller error.
3,SFT0	;"already active will do an ABORT cmd"	Wrong controller or bad microcode controller error. The controller was expected to be in an idle state but was found in an active state. Try again and if still there check for ECOs and new Microcode.
4,DF2	;wrong step bit set after interrupt	Controller initialazation error. Controller is broken or at wrong address and something is in its place.
5,DF1	;controller timeout during hard init	Controller error, controller is slow or it can't interrupt the Q bus. Controller is dead.
6,SFT1	;wrong model #,wrong controller	This is not really an error. You are using the wrong formatter program to for the wrong disk controller. It still might work but no guarantees.
7,DF4	;NXM trap at controller IP address	Wrong configuration address of the controller check for wrong jumper settings.
8,SF100	;Unexpected interrupt	



346  
347  
348  
349  
350  
351  
352  
353  
354  
355  
356  
357  
358  
359  
360  
361  
362  
363  
364  
365  
366  
367  
368  
369  
370  
371  
372  
373  
374  
375  
376  
377  
378  
379  
380  
381  
382  
383  
384  
385  
386  
387  
388  
389  
390  
391  
392  
393  
394  
395  
396  
397  
398  
399  
400  
401  
402

Something in system interrupting or late interrupt. This could be the system clock or an interrupt from an IO port. If the interrupt is at address 4,10 probable a software error Try again.

- 9,DF12 ;Fatal SA error  
Controller crashed check detailed error message either dead controller or configuration error.
- 10,DF11 ;Bad response packet  
Inappropriate command or soft controller error check detail message for more info.
- 11,DF13 ;no progress shown after cmd timeout  
The controller didn't indicate progress which means that it is working very slow or is stuck. Leave the program running for a couple minutes. If this message repeats then the drive is likely broken. If you just get 1 message it is possible the controller took too long to revector a block. This is probable a drive error or a drive with many revector blocks.
- 12,DF14 ;no interrupt after get dust status command controller dead  
The controller got lost. The program running in the controller got out of synch with the host program. This could mean several things. Check for a loose controller board loose cables. Try running again after rebooting the system. If you still get the error check the controller.

#### 4. PROGRAM DESIGN AND FLOW

The program is kind of simple. There is only 1 command ring and 1 response ring. For every command sent there is expected 1 response. If the command sent times out a "Get DUST Status" command is sent to check on the controllers progress. This usually happens when the actual format is being done. The rest of the commands pass information back and forth from the user to the controller and back with out ever timing out. This program is written according to UQSSP and DUP specs. This specs can be acquired from NEWTON::ARCH\$FILES:. At the start of the program the INIT sequence brings the controller into the higher protocol state of running DUP commands. Once initialized the controller executed a GET DUST STATUS command to make sure the controller is in an Idle state.

If idle which it should be the program asks for a program name to run. The EXECUTE LOCAL PROGRAM command is executed which should start the program into the DUP dialog loop. This dialog is described in the DUP spec. Here several SEND DATA and RECEIVE DATA commands are executed to ask questions and supply information on the success and completion of the local FORMAT program running in the RQDX3.

A pass will occur when the formatter has completed formatting all the logical units.

#### 5.0 GLOSSARY

403  
404  
405  
406  
407  
408  
409  
410  
411  
412  
413  
414  
415  
416  
417  
418  
419  
420  
421  
422  
423  
424  
425  
426  
427  
428  
429  
430  
431  
432  
433  
434  
435  
436  
437  
438  
439  
440  
441  
442  
443  
444  
445  
446  
447  
448  
449  
450  
451  
452

ZRQCc0 follows the module name format described in the  
XXDP Programmer's Guide.

RQ Identifies the hardware and thus the module.

C Distiguishes between two or more different  
d'agnostics for the same generic device. The  
sequence A, B, C, ETC. must be used for  
each additional diagnostic.

c Specifies the module revision.

0 Specifies the number of patches.

#### 7.0 BIBLIOGRAPHY

UQSSP (NEWTON::ARCH\$FILES:)

MSCP (NEWTON::ARCH\$FILES:)

DUP (NEWTON::ARCH\$FILES:)

DRS programmers manual (JON::disk\$user1:[diaglib.drs])

XXDP programmer guide (JON::disk\$user1:[diaglib.xxdp])

#### 8.0 REVISION HISTORY

Revision B contains an autosizing routine which will  
size the drive instead of having the user pick the drive table.  
This will keep people out of the systems and lower the changes  
of loose cables etc. Also added a AUTO mode which allows no manual  
interventions. Set up the default p-table to format drive 0 3.  
Since floppies are always the last drive in the system this is  
gauranteed to format all the drive in the system and error when 't  
gets to the floppy.

Revision C contains several changes. First RX33,RD31,RD54 support was  
added. The RX33 boot device questions where added. The autosizer was  
fixed to also size for floppies. The Autosizer errors are now reported  
to the host along with what drives are located on what units and there  
drive size or floppy type. The default question in manual mode was  
changed so that if an FCT (factory control table) is not present  
"Bad Block Information" it will not continue on. This was changed for  
all drives except the RD51 which doesn't have a FCT table. Also there  
was a small change to the autosizer which affects version C1 hardware  
etched RQDX3 boards specially the ones without the LUN ECO. The autosizer  
now run in the beg'ning and the end. A head parking feature was added  
so that RD31 and RD32 heads would be parked in the inner most cylinder  
upon completion of the program. The autosizer utility was updated to  
displays a little more information.

)\*

K1

```
454
455      .MCALL SVC
456 000000 SVC
457 000000 .ENABLE ABS,AMA
458      000052 .-52
459 000052 010000      .word      bit12      ;extended monitor in XXDP
460      002000      .=2000
461 002000 BGNMOD MOD1
462 002000 POINTER BGNDU,BGNCLN,BGNPROT,BGNSETUP
463 002000 HEADER ZRQC,C,0,600,0
464 002122 DISPATCH 1
465 002126 DESCRIPT <RQDX3 Format\Park Disk Utility>
466 002166 DEVTYPE <RD51,RD52,RD53,RD31,RD54,RX33 *** Answer "Y" to "Change HW (L) ?" ***>
467
```

469 002274  
470 002276 172150  
471 002300 000154  
472 002302 000000  
473 002304 030071  
474 002306 100000  
475 002310  
476

BGNHW DFPTBL  
.WORD 172150  
.WORD 154  
.WORD 000000  
.WORD 012345  
.word 100000  
ENDHW

;IP address  
;Vector address  
;unit zero as default drive  
;serial number  
;auto sizer-"yes", warning="no" or don't continue

478 002310

```

                                EQUALS
                                ; BIT DIFINITIONS
                                ;
                                BIT15== 100000
                                BIT14== 40000
                                BIT13== 20000
                                BIT12== 10000
                                BIT11== 4000
                                BIT10== 2000
                                BIT09== 1000
                                BIT08== 400
                                BIT07== 200
                                BIT06== 100
                                BIT05== 40
                                BIT04== 20
                                BIT03== 10
                                BIT02== 4
                                BIT01== 2
                                BIT00== 1
                                ;
                                BIT9== BIT09
                                BIT8== BIT08
                                BIT7== BIT07
                                BIT6== BIT06
                                BIT5== BIT05
                                BIT4== BIT04
                                BIT3== BIT03
                                BIT2== BIT02
                                BIT1== BIT01
                                BIT0== BIT00
                                ;
                                ; EVENT FLAG DEFINITIONS
                                ; EF32:EF17 RESERVED FOR SUPERVISOR TO PROGRAM COMMUNICATION
                                ;
                                ; BIT POSITION IN SECOND STATUS WORD
                                ; (100000) START COMMAND WAS ISSUED
                                ; (040000) RESTART COMMAND WAS ISSUED
                                ; (020000) CONTINUE COMMAND WAS ISSUED
                                ; (010000) A NEW PASS HAS BEEN STARTED
                                ; (004000) A POWER-FAIL/POWER UP OCCURRED
                                ;
                                EF.START== 32.
                                EF.RESTART== 31.
                                EF.CONTINUE== 30.
                                EF.NEW== 29.
                                EF.PWR== 28.
                                ;
                                ; PRIORITY LEVEL DEFINITIONS
                                ;
                                PRI07== 340
                                PRI06== 300
                                PRI05== 240
                                PRI04== 200
                                PRI03== 140
                                PRI02== 100
                                PRI01== 40
                                PRI00== 0
                                ;
                                ; OPERATOR FLAG BITS
                                ;
                                EVL== 4
                                ;
                                000004
```

```

000010      LOT==      10
000020      ADR==      20
000040      IDU==      40
000100      ISR==     100
000200      UAM==     200
000400      BOE==     400
001000      PNT--    1000
002000      PRI--    2000
004000      IXE==    4000
010000      IBE==   10000
020000      IER==   20000
040000      LOE==   40000
100000      HOE==  100000
479          .sbttl Literals
480
481          ;+
482          ; Mask values to mask out specified flags
483          ; -
484          000010      UITothr = 10          ;UIT other
485                                     ;if UIT doesn't exist
486
487          ;+
488          ; M'sc.
489          ; -
490          000004      MaxDrv = 4          ;Maximum Number of drives
491          000002      DUP.id = bit1      ;DUP connection ID
492          000007      Mrqdx1 = 7.        ;model number for RQDX1
493          000023      Mrqdx3 = 19.       ;model number for RQDX3
494          000001      stdaln = bit0      ;stand alone modifier
495          000367      retry = 367        ;Number of retries UDC
496
497          ;+
498          ; Opcodes for DUP commands
499          ; -
500          000001      op.gds = 1
501          000006      op.abrt = 6
502          000004      op.sen = 4
503          000005      op.rec = 5
504          000003      op.elp = 3
505          000002      op.esp = 2
506          000200      op.end = 200
507
508          ;+
509          ; Message type masks
510          ; -
511          000001      Question = 1
512          000002      DefQuest = 2
513          000003      inform = 3
514          000004      terminat = 4
515          000005      ftlerr = 5
516          000006      specl = 6
517
518          177760      type = 177760
519          170000      msgnbr = 170000
520
521          ;+
522          ; Auto sizer literals
523
524          ; Interrupt Service Routines and Priority Levels

```

terals

```

523
524      100002      ;$udc -      100002      ; Pointer to UDC interrupt handler
525      100006      ;$clk =      100006      ; Pointer to Clock interrupt handler
526      100016      ;$sec -      100016      ; Pointer to Sector Done Interrupt hand. r
527      000000      ps0 -      0          ; Allow Any Interrupts
528      000340      ps7 -      340         ; Inhibit Interrupts
529
530      ; CSRs
531
532      140002      rw$pll -      140002
533      140004      w$fpl -      140004
534      140006      r$fps =      140006
535      140010      r$dat =      140010
536      140012      r$cmd -      140012
537      140020      w$dat -      140020
538      140022      w$cmd -      140022
539
540      ; RECEIVE DATA ASCII reply message types:
541
542      000020      .a.typ =      20          ; ASCII Message Type Multiplier
543      000020      .a.que -      1*.a.typ   ; Question
544      000040      .a.def =      2*.a.typ   ; Default question
545      000060      .a.inf =      3*.a.typ   ; Information
546      000100      .a.ter =      4*.a.typ   ; Termination
547      000120      .a.fat =      5*.a.typ   ; Fatal error
548
549      ; RECEIVE DATA binary message types.
550
551      000140      .b.spl =      6*.a.typ   ; Special
552
553      ; Status Codes returned by SIZER (Success is zero)
554
555      000001      erudon =      1          ; UDC Never Done
556      000002      eruint =      2          ; UDC Never Interrupted
557      000003      ersek0 =      3          ; Couldn't Restore to Cyl 0
558
559      ; UDC Commands
560
561      000000      op.res =      0          ; Reset 9224
562      000001      op.dd =      1          ; Deselect Drive
563      000003      op.rd =      3          ; Restore Drive
564      000005      op.sil =      5          ; Step In One Cylinder
565      000007      op.sol =      7          ; Step Out One Cylinder
566      000044      op.srd =      44         ; Select Winchester Drive
567      000054      op.srx =      54         ; Select Floppy Drive
568      000100      op.srp =      100        ; Set Register Pointer
569      000300      rd.mode =      300       ; RD Mode
570
571

```

Macro Definitions

573  
574  
575  
576  
577  
578  
579  
580  
581  
582  
583  
584  
585  
586  
587  
588  
589  
590  
591  
592  
593  
594  
595  
596  
597  
598  
599  
600  
601  
602  
603  
604  
605  
606  
607  
608  
609  
610  
611  
612  
613  
614  
615  
616  
617  
618  
619

000000  
000001

```
.sbttl Macro Definitions

;+
; Execute a GET DUST STATUS command and then check the response.
;

A=0
B=1
.MACRO GETDUST ;Execute a GET DUST STATUS command
B=B+1 ;increment the CRN number
gdstmp \B ;call variable B as 'f' t where a number (\)
.ENDM

.MACRO GDSTMP B
.list
GDS'B: bit #bit15,cmdrng+2 ;test ownership of ring make sure we own it
; if we don't own it wait until we do
bne GDS'B ;load length of packet to be send
mov #14.,cmdlen ;load msg type and credit
movb #0,cmdlen+2 ;load DUP connection ID
movb #dup.id,cmdlen+3 ;load new CRN
inc cmdpak
clr cmdpak+2
clr cmdpak+4
clr cmdpak+6
mov #op.gds,cmdpak+10 ;load up opcode
clr cmdpak+12 ;no modifiers

mov #RFD'B,@vector ;New vector place
mov #rsppak,rsprng ;load response packet area into ring
mov #cmdpak,cmdrng ;load command packet area into ring
mov #140000,RSPRNG+2 ;Port ownership bit.
mov #bit15,CMDRNG+2
jsr pc,POLLWT ;Go to poll and wait routine.

;*****

RFD'B: ;Intr to here.
add #6,sp ;fix stack for interrupt (4), pollwt subrtn (2)
mov #intsrv,@vector ;Change vector
jsr pc,RSPCHK ;Go to routine that will check on
;the response recvd from the mut.
;it will check the cmd ref
;num, the endcode and status.

.list
.ENDM
```



Macro Definitions

621  
622  
623  
624  
625  
626  
627  
628  
629  
630  
631  
632  
633  
634  
635  
636  
637  
638  
639  
640  
641  
642  
643  
644  
645  
646  
647  
648  
649  
650  
651  
652  
653  
654  
655  
656  
657  
658  
659  
660  
661  
662  
663  
664

```

;+
; Execute an ABORT command and then checks the response.
;-

.MACRO ABRT                                     ;Execute an ABORT command
B-B+1                                           ;increment the CRN number
abrttmp \B                                       ;call variable B as if it where a number (...)
.ENDM

.MACRO ABRTTMP B
.l'st
ABRT'B: bit #bit15,cmdrng+2                     ;test ownership of ring make sure we own it
          bne ABRT'B                             ;if we don't own it wait until we do
          mov #14.,cmdlen                         ;load length of packet to be send
          movb #0,cmdlen+2                        ;load msg type and credit
          movb #dup.id,cmdlen+3                   ;load DUP connect'on ID
          inc cmdpak                               ;load new CRN
          clr cmdpak+2
          clr cmdpak+4
          clr cmdpak+6
          mov #op.abrt,cmdpak+10                  ;load up opcode
          clr cmdpak+12                           ;no modifiers

          mov #RFD'B,@vector                       ;New vector place
          mov #rsppak,rsprng                       ;load response packet area into ring
          mov #cmdpak,cmdrng                       ;load command packet area into ring
          mov #140000,RSPRNG+2                     ;Port ownership bit.
          mov #bit15,CMDRNG+2
          jsr pc,POLLWT                             ;Go to poll and wait routine.

;*****

          RFD'B:
          add #6,sp                                 ;_ntr to here.
          mov #intsrv,@vector                       ;fix stack for interrupt (4), pollwt subrtn (2)
          jsr pc,RSPCHK                             ;Change vector
                                                  ;Go to routine that will check on
                                                  ;the response recvd from the mut.
                                                  ;it will check the cmd ref
                                                  ;num, the endcode and status.

          .nl'st
.ENDM

```

## Macro Definitions

```

666
667
668      ;+
669      ;      Execute a Send data cmd in dup and then check the response for the proper info
670      ;
671
672
673      .MACRO SENDDAT SPLACE,SBYTCN      ;Execute a Send Data command
674      B-B+1                          ;increment the CRN number
675      sendtmp \B,SPlace,Sbytcn      ;call variable A,B as if it where a number (\)
676      .ENDM
677
678      .MACRO SENDTMP B,Splace,Sbytcnt
679      .list
680      SDT'B: bit #bit15,cmdrng+2      ;test ownership of ring make sure we own it
681             bne SDT'B                ;if we don't own it wait until we do
682             mov #34,cmdlen           ;load lenght of packet to be send
683             movb #0,cmdlen+2         ;load msg type and credit
684             movb #dup.id,cmdlen+3    ;load DUP connection ID
685             inc cmdpak               ;load new CRN
686             clr cmdpak+2
687             clr cmdpak+4
688             clr cmdpak+6
689             mov #op.sen,cmdpak+10    ;load up opcode
690             clr cmdpak+12            ;no modifiers
691             mov Sbytcnt,cmdpak+14
692             clr cmdpak+16
693             mov Splace,cmdpak+20     ;load address of buffer desribtor
694             clr cmdpak+22
695             clr cmdpak+24
696             clr cmdpak+26
697             clr cmdpak+30
698             clr cmdpak+32
699
700             mov #RFD'B,@vector      ;New vector place
701             mov #rsppak,rsprng      ;load response packet area into ring
702             mov #cmdpak,cmdrng      ;load command packet area into ring
703             mov #140000,RSPRNG+2    ;Port ownership bit.
704             mov #bit15,CMDRNG+2
705             jsr pc,POLLWT           ;Go to poll and wait routine.
706
707      ;*****
708
709      RFD'B:
710             add #6,sp                ;Intr to here.
711             mov #intsrv,@vector     ;fix stack for interrupt (4), pollwt subrtn (2)
712             jsr pc,RSPCHK           ;Change vector
713                                     ;Go to routine that will check on
714                                     ;the response recvd from the mut.
715                                     ;it will check the cmd ref
716                                     ;num, the endcode and status.
717      .nlist
      .ENDM

```

## Macro Definitions

```

719
720
721      ;*
722      ;      Execute a Receive Data command and the check the response.
723      ;
724
725      .MACRO RECVDAT Rplace,Rbytcnt      ;Execute a Send Data command
726      B-B+1                              ;increment the CRN number
727      recvtmp \B,Rplace,Rbytcnt        ;call variable A,B as if it where a number (\)
728      .ENDM
729
730      .MACRO RECVTMP B,RPlace,Rbytcnt
731      .list
732      RCD'B: bit      #b't15,cmdrng+2      ;test ownership of ring make sure we own it
733      bne      RCD'B      ;if we don't own it wait until we do
734      mov      #34,cmdlen      ;load length of packet to be send
735      movb     #0,cmdlen+2      ;load msg type and credit
736      movb     #dup.id,cmdlen+3      ;load DUP connection ID
737      inc      cmdpak          ;load new CRN
738      clr      cmdpak+2
739      clr      cmdpak+4
740      clr      cmdpak+6
741      mov      #op.rec,cmdpak+10      ;load up opcode
742      clr      cmdpak+12      ;no modifiers
743      mov      Rbytcnt,cmdpak+14
744      clr      cmdpak+16
745      mov      Rplace,cmdpak+20      ;load address of buffer descriptor
746      clr      cmdpak+22
747      clr      cmdpak+24
748      clr      cmdpak+26
749      clr      cmdpak+30
750      clr      cmdpak+32
751
752      mov      #RFD'B,@vector      ;New vector place
753      mov      #rspak,rspng      ;load response packet area into ring
754      mov      #cmdpak,cmdrng      ;load command packet area into ring
755      mov      #140000,RSPRNG+2      ;Port ownership bit.
756      mov      #bit15,CMDRNG+2
757      jsr      pc,POLLWT          ;Go to poll and wait routine.
758
759      ;*****
760
761      RFD'B:      ;Intr to here.
762      add      #6,sp      ;fix stack for interrupt (4), pollwt subrtn (2)
763      mov      #intsrv,@vector      ;Change vector
764      jsr      pc,RSPCHK          ;Go to routine that will check on
765      ;the response recvd from the mut.
766      ;it will check the cmd ref
767      ;num, the endcode and status.
768
769      .nlist
770      .ENDM

```

G2

Macro Definitions

772  
773  
774  
775  
776  
777  
778  
779  
780  
781  
782  
783  
784  
785  
786  
787  
788  
789  
790  
791  
792  
793  
794  
795  
796  
797  
798  
799  
800  
801  
802  
803  
804  
805  
806  
807  
808  
809  
810  
811  
812  
813  
814  
815  
816  
817  
818  
819  
820  
821

```

;+
; Execute a Execute Local Program command and the check the response.
;
.MACRO EXLCPRG Enamadr          ;Execute a Send Data command
B-B+1                          ;increment the CRN number
elptmp \B,Enamadr              ;call variable A,B as 'f it where a number (\)
.ENDM

.MACRO ELPTMP B,Enamadr
.list
ELP'B: bit #bit15,cmdrng+2      ;test ownership of ring make sure we own it
      bne ELP'B                ;if we don't own it wait unt'l we do
      mov #22,cmdlen           ;load lenght of packet to be send
      movb #0,cmdlen+2         ;load msg type and credit
      movb #dup.id,cmdlen+3    ;load DUP connection ID
      inc cmdpak               ;load new CRN
      clr cmdpak+2
      clr cmdpak+4
      clr cmdpak+6
      mov #op.elp,cmdpak+10    ;load up opcode
      mov #stdaln,cmdpak+12    ;stand alone modifier
      mov #6,r0                ;6 letters transfer
      mov #cmdpak+14,r1        ;starting address to place program name
      mov #Enamadr,r2          ;start of Program Name
rfdj'B: movb (r2)+,(r1)+       ;add 2 to bycnt then store
      sob r0,rfdj'B

      mov #RFD'B,@vector      ;New vector place
      mov #rsppak,rsprng      ;load response packet area into ring
      mov #cmdpak,cmdrng      ;load command packet area into ring
      mov #140000,RSPRNG+2    ;Port ownership bit.
      mov #bit15,CMDRNG+2
      jsr pc,POLLWT           ;Go to poll and wait routine.

;*****
RFD'B: ;Intr to here.
      add #6,sp               ;fix stack for interrupt (4), pollwt subrtn (2)
      mov #intsrv,@vector    ;Change vector
      jsr pc,RSPCHK          ;Go to routine that will check on
                              ;the response recvd from the mut.
                              ;it will check the cmd ref
                              ;num, the endcode and status.
.list
.ENDM

```

Macro Definitions

823  
824  
825  
826  
827  
828  
829  
830  
831  
832  
833  
834  
835  
836  
837  
838  
839  
840  
841  
842  
843  
844  
845  
846  
847  
848  
849  
850  
851  
852  
853  
854  
855  
856  
857  
858  
859  
860  
861  
862  
863  
864  
865  
866  
867  
868  
869  
870  
871  
872  
873  
874  
875

```

;+
; Execute a Eexecute Supplied Program command and the check the response.
;
;
.MACRO EXCSUPPRG ;Execute a Supplied program command
B-B+1 ;increment the CRN number
esptmp \B ;call variable A,B as if it where a number (\)
.ENDM

.MACRO ESPTMP B
.list
ESP'B: bit #b't15,cmdrng+2 ;test ownership of ring make sure we own it
; if we don't own it wait until we do
bne ESP'B ;load lenght of packet to be send
mov #50,cmdlen ;load msg type and credit value
movb #0,cmdlen+2 ;load DUP connection ID
movb #dup.'d,cmdlen+3
clr CMDpak+2
clr CMDpak+4
clr CMDpak+6
mov #op.esp,CMDpak+10 ;load up opcode
mov #0,CMDpak+12 ;no stand alone modifier
mov #<autoend autosz>,cmdpak+14 ;load length of prg into buffer
clr cmdpak+16
mov #autosz,cmdpak+20 ;starting address of downline load prg
clr CMDpak+22
clr CMDpak+24
clr CMDpak+26
clr CMDpak+30
clr CMDpak+32
clr CMDpak+34 ;overlay buffer descriptor
clr CMDpak+36
clr CMDpak+40
clr CMDpak+42
clr CMDpak+44
clr CMDpak+46
mov #RFD'B,@vector ;New vector place
mov #rsppak,rsprng ;load response packet area into ring
mov #cmdpak,cmdrng ;load command packet area into ring
mov #140000,RSPRNG+2 ;Port ownership bit.
mov #bit15,CMDRNG+2
jsr pc,POLLWT ;Go to poll and wa't routine.
;*****
RFD'B: ;Intr to here.
add #6,sp ;fix stack for interrupt (4), pollwt subrtn (2)
mov #intsrv,@vector ;Channe vector
jsr pc,RSPCHK ;Go to routine that will check on
;the response recvd from the mut.
;it will check the cmd ref
;num, the endcode and status.
.list
.ENDM

```

## Word &amp; Buffer definitions

```

877      .sbtbl Word & Buffer defintions
878
879 002310 000000 LOGUNIT: .WORD      ;logunit number
880 002312 000000 LOCAL:   .WORD      ;
881 002314 000000 PLOC:    .WORD      ;p table address
882 002316 000000 ptbl:   .WORD      ;p table address
883 002320 000000 UITadr: .word
884 002322 000000 BOOT:   .word      ;bootable media
885
886      ;*
887      ; These next locations may be altered to supply the correct IP & SA address
888      ; If only 1 jumper is to be placed on the MUT the locations should be filled
889      ; with addresses 177770 and 177772 respectively.
890      ;
891
892 002324 000000 IPreg:  .WORD      0      ;Address of the SA and IP registers
893 002326 000000 Vector: .word      0
894 002330 000000 Unit:   .word      0      ;unit number
895 002332 000123      .word      123
896 002334 177777 sernbr: .word      177777 ;serial number
897 002336 000000 UNTflgs: .word      0      ;flags, bit15 =auto mode
898      ;bit13 =unknown model number,bit12 =park heads only
899 002340 000000 mdlnbr: .word      0      ;model number of the controller as returned in step 4
900 002342 000000 mcdnbr: .word      0      ;micorcode number of the controller as returned in step 4
901 002344 000000 UIN:    .word      0      ;th's is a pointer to the correct UIT table
902
903 002346 RSP1:   .BLKW      2      ;Response packet length
904 002352 RSPPAK: .BLKW      30.    ;Response packet
905 002446 CMDLEN: .BLKW      2      ;Command packet length
906 002452 CMDPAK: .BLKW      20.    ;Command packet
907
908 002522 000000 CINTR:  .WORD      0      ;Command interrupt indicator
909 002524 000000 RINTR:  .WORD      0      ;Response interrupt indicator
910 002526 002352 RSPRNG: .word      rsppak   ;Message ring
911 002530 140000      .word      140000
912 002532 002452 CMDRNG:  .word      cmdpak   ;Command ring
913 002534 100000      .word      100000
914 002536 177777      .WORD      1
915
916 002540 000000 LSTCRN: .word      0      ;storage for unreturned command CRN
917 002542 000000 LSTCMD: .word      0      ;storage for unreturned command opcode
918 002544 000000 LSTVCT: .word      0      ;storage for unreturned command interrupt vector address
919 002546 000000 LOPRGI: .word      0      ;Low word of the progress indicator
920 002550 000000 HIPRGI: .word      0      ;High word of progress indicator
921
922      .nlist bin      ;data area
923 002552 DATARE: .asciz /*A1234567890123456789012345678901234567890123456789012345678901234567890/
924      .even
925 002676 PRGnam: .ascii /FORMAT/ ;address of local format program name
926 002704      .byte      0      ;null for asciz
927 002705 XBN:    .ASCIZ /0123456789/
928 002720 DBN:    .ASCIZ /0123456789/
929 002733 LBN:    .ASCIZ /0123456789/
930 002746 RBN:    .ASCIZ /0123456789/
931      .even
932      .list b'n

```

Word & Buffer definitions

934  
935  
936  
937  
938  
939  
940  
941 002776 002776  
942 002776 177777  
943 003000 003000  
944  
945  
946  
947  
948  
949  
950 003000  
951  
952 003000 000071  
953 003002 000000  
954 003004 000127  
955 003006 000000  
956 003010 052360  
957 003012 000000  
958 003014 000220  
959 003016 000000  
960 003020 000022  
961 003022 000004  
962 003024 000462  
963 003026 000156  
964 003030 000462  
965 003032 000000  
966 003034 000001  
967 003036 000044  
968 003040 000004  
969 003042 040063  
970 003044 022544  
971 003046 000002  
972 003050 000002  
973 003052 000001  
974 003054 000020  
975 003056 000020  
976 003060 000005  
977 003062 000020  
978 003064 000015  
979 003066 000001  
980 003070 000001  
981 003072 000001  
982 003074 000002  
983 003076 000151  
984 003100 000463  
985 003102 000463  
986 000104  
987 003104  
988  
989  
990

.sbt1 DISK UNIT INFORMATION TABLES

;\*  
; The following tables are made up of disk drive parameters which will be  
; feed to the FORMAT controller local program which will then use the  
; information to format the drives.

.-2776  
.word 1 ;back door for custom table build  
.-3000

Unit Information table RD51 Seagate

UITO:

```

.word 57. ;/*Top of Unit Information table (UIT)
.word 0 ;/XBN size (lo wrd) XBN size = 3*(1+sectors_per track)/
.word 87. ;/XBN size (hi wrd)/
.word 0 ;/DBN size (lo wrd)/
.word 21744. ;/DBN size (hi wrd)/
.word 0 ;/LBN size (lo wrd)/
.word 144. ;/LBN size (hi wrd)/
.word 0 ;/RBN size (lo wrd)/
.word 18. ;/RBN size (hi wrd)/
.word 4. ;/Sectors per track/
.word 306. ;/Surfaces per unit/
.word 110. ;/Cylinders per unit/
.word 306. ;/Write precomp cylinder/
.word 0 ;/Reduce write current cylinder /
.word 1 ;/Seek Rate/
.word 36. ;/Use CRC or ECC/
.word 4. ;/RCT Size/
.word 4. ;/Number of RCT copies/
.word +B0100000000110011 ;+H4033;/Media (lo wrd)/
.word +B0010010101100100 ;+H2564;/Media (hi wrd)/
.word 2 ;/Sector Interleave (n-to 1)/
.word 2 ;/Surface to Surface Skew/
.word 1 ;/Cylinder to Cylinder Skew/
.word 16. ;/Gap size 0/
.word 16. ;/Gap size 1/
.word 5. ;/Gap size 2/
.word 16. ;/Gap size 3/
.word 13. ;/Sync size/
.word 1 ;/MSCP cylinders per Unit/
.word 1 ;/MSCP Groups per Cylinder/
.word 1 ;/MSCP Tracks per Group/
.word 2 ;/Max allowed bad spots per surface/
.word 105. ;/Bad spot tolerance (bytes)/
.word 307. ;/auto recal cylinder
.word 307. ;/auto recal cylinder

```

UITsiz = .-UITO  
.=3000+ UITsiz

;\*  
;

DISK UNIT INFORMATION TABLES

```

991      ;      Unit Information table   RD52 Quantum drive
992      ;
993
994
995 003104      UIT1:
996                                     ;/*Top of Unit Information table (UIT)
997 003104 000066      .word 54.      ;/XBN size (lo wrd) XBN size = 3*(1+sectors_per_track)/
998 003106 000000      .word 0      ;/XBN size (hi wrd)/
999 003110 000122      .word 82.      ;/DBN size (lo wrd)/
1000 003112 000000      .word 0      ;/DBN size (hi wrd)/
1001 003114 166140      .word 60512.      ;/LBN size (lo wrd)/
1002 003116 000000      .word 0      ;/LBN size (hi wrd)/
1003 003120 000250      .word 168.      ;/RBN size (lo wrd)/
1004 003122 000000      .word 0      ;/RBN size (hi wrd)/
1005 003124 000021      .word 17.      ;/Sectors per track/
1006 003126 000010      .word 8.      ;/Surfaces per unit/
1007 003130 001000      .word 512.      ;/Cylinders per unit/
1008 003132 000400      .word 256.      ;/Write precomp cylinder/
1009 003134 001000      .word 512.      ;/Reduce write current cylinder /
1010 003136 000000      .word 0      ;/Seek Rate/
1011 003140 000001      .word 1      ;/Use CRC or ECC/
1012 003142 000004      .word 4      ;/RCT Size/
1013 003144 000010      .word 8.      ;/Number of RCT copies/
1014 003146 040064      .word †B0100000000110100 †H4034;/Media (lo wrd)/
1015 003150 022544      .word †B0010010101100100 †H2564;/Media (hi wrd)/
1016 003152 000001      .word 1      ;/Sector Interleave (n-to 1)/
1017 003154 000002      .word 2      ;/Surface to Surface Skew/
1018 003156 000015      .word 13.      ;/Cylinder to Cylinder Skew/
1019 003160 000020      .word 16.      ;/Gap size 0/
1020 003162 000020      .word 16.      ;/Gap size 1/
1021 003164 000005      .word 5.      ;/Gap size 2/
1022 003166 000050      .word 40.      ;/Gap size 3/
1023 003170 000015      .word 13.      ;/Sync size/
1024 003172 000001      .word 1      ;/MSCP cylinders per Unit/
1025 003174 000001      .word 1      ;/MSCP Groups per Cylinder/
1026 003176 000001      .word 1      ;/MSCP Tracks per Group/
1027 003200 000012      .word 10.      ;/Max allowed bad spots per surface/
1028 003202 000151      .word 105.      ;/Bad spot tolerance (bytes)/
1029 003204 001000      .word 512.      ;/auto recal cylinder
1030 003206 001000      .word 512.      ;/auto recal cylinder
1031
1032      003210      .=3000+UITsiz+UITsiz
1033
1034
1035      ;+
1036      ;      Unit Information table   RD52 Atasi
1037      ;-
1038
1039
1040 003210      UIT2:
1041                                     ;/*Top of Unit Information table (UIT)
1042 003210 000066      .word 54.      ;/XBN size (lo wrd) XBN size = 3*(1+sectors_per_track)/
1043 003212 000000      .word 0      ;/XBN size (hi wrd)/
1044 003214 000101      .word 65.      ;/DBN size (lo wrd)/
1045 003216 000000      .word 0      ;/DBN size (hi wrd)/
1046 003220 166140      .word 60512.      ;/LBN size (lo wrd)/
1047 003222 000000      .word 0      ;/LBN size (hi wrd)/

```



## DISK UNIT INFORMATION TABLES

```

1048 003224 000250 .word 168. ;/RBN size (lo wrd)/
1049 003226 000000 .word 0 ;/RBN size (hi wrd)/
1050 003230 000021 .word 17. ;/Sectors per track/
1051 003232 000007 .word 7. ;/Surfaces per unit/
1052 003234 001205 .word 645. ;/Cylinders per unit/
1053 003236 000500 .word 320. ;/Write precomp cylinder/
1054 003240 001205 .word 645. ;/Reduce write current cylinder /
1055 003242 000000 .word 0 ;/Seek Rate/
1056 003244 000001 .word 1 ;/Use CRC or ECC/
1057 003246 000004 .word 4 ;/RCT Size/
1058 003250 000010 .word 8. ;/Number of RCT copies/
1059 003252 040064 .word †B0100000000110100 ;†H4034;/Media (lo wrd)/
1060 003254 022544 .word †B0010010101100100 ;†H2564;/Media (hi wrd)/
1061 003256 000001 .word 1 ;/Sector Interleave (n to-1)/
1062 003260 000002 .word 2 ;/Surface to Surface Skew/
1063 003262 000007 .word 7. ;/Cylinder to Cylinder Skew/
1064 003264 000020 .word 16. ;/Gap size 0/
1065 003266 000020 .word 16. ;/Gap size 1/
1066 003270 000005 .word 5. ;/Gap size 2/
1067 003272 000050 .word 40. ;/Gap size 3/
1068 003274 000015 .word 13. ;/Sync size/
1069 003276 000001 .word 1 ;/MSCP cylinders per Unit/
1070 003300 000001 .word 1 ;/MSCP Groups per Cylinder/
1071 003302 000001 .word 1 ;/MSCP Tracks per Group/
1072 003304 000024 .word 20. ;/Max allowed bad spots per surface/
1073 003306 000151 .word 105. ;/Bad spot tolerance (bytes)/
1074 003310 001206 .word 646. ;/auto recal cyl'nder
1075 003312 001206 .word 646. ;/auto recal cylinder
1076
1077 003314 .-3000*UITsiz+UITsiz+UITsiz
1078
1079 ;+
1080 ; Unit Information table RD53 Micropol's
1081 ;-
1082
1083
1084 003314 UIT3:
1085 ;/*Top of Unit Information table (UIT)
1086 003314 000066 .word 54. ;/XBN size (lo wrd) XBN size = 3*(1+sectors_per track)/
1087 003316 000000 .word 0 ;/XBN size (hi wrd)/
1088 003320 000122 .word 82. ;/DBN size (lo wrd)/
1089 003322 000000 .word 0 ;/DBN size (hi wrd)/
1090 003324 016730 .word 7640. ;/LBN size (lo wrd)/
1091 003326 000002 .word 2. ;/LBN size (hi wrd)/
1092 003330 000430 .word 280. ;/RBN size (lo wrd)/
1093 003332 000000 .word 0 ;/RBN size (hi wrd)/
1094 003334 000021 .word 17. ;/Sectors per track/
1095 003336 000010 .word 8. ;/Surfaces per unit/
1096 003340 002000 .word 1024. ;/Cylinders per unit/
1097 003342 002000 .word 1024. ;/Write precomp cylinder/
1098 003344 002000 .word 1024. ;/Reduce write current cylinder /
1099 003346 000000 .word 0 ;/Seek Rate/
1100 003350 000001 .word 1 ;/Use CRC or ECC/
1101 003352 000005 .word 5 ;/RCT Size/
1102 003354 000010 .word 8. ;/Number of RCT copies/
1103 003356 040065 .word †B0100000000110101 ;†H4035;/Media (lo wrd)/
1104 003360 022544 .word †B0010010101100100 ;†H2564;/Media (hi wrd)/

```

## DISK UNIT INFORMATION TABLES

```

1105 003362 000001 .word 1 ;/Sector Interleave (n-to-1)/
1106 003364 000002 .word 2 ;/Surface to Surface Skew/
1107 003366 000010 .word 8. ;/Cylinder to Cylinder Skew/
1108 003370 000020 .word 16. ;/Gap size 0/
1109 003372 000020 .word 16. ;/Gap size 1/
1110 003374 000005 .word 5. ;/Gap size 2/
1111 003376 000050 .word 40. ;/Gap size 3/
1112 003400 000015 .word 13. ;/Sync size/
1113 003402 000001 .word 1 ;/MSCP cylinders per Unit/
1114 003404 000001 .word 1 ;/MSCP Groups per Cylinder/
1115 003406 000001 .word 1 ;/MSCP Tracks per Group/
1116 003410 000040 .word 32. ;/Max allowed bad spots per surface/
1117 003412 000156 .word 110. ;/Bad spot tolerance (bytes)/
1118 003414 002000 .word 1024. ;/auto recal cylinder
1119 003416 002000 .word 1024. ;/auto recal cylinder
1120
1121 003420 .-3000+UITsiz+UITsiz+UITsiz+UITsiz
1122
1123
1124 ;+
1125 ; Unit Information table RD31 Seagate
1126 ;
1127
1128
1129 003420 UIT4:
1130 ;/*Top of Unit Information table (UIT)
1131 003420 000066 .word 54. ;/XBN size (lo wrd) XBN size = 3*(1+sectors_per_track)/
1132 003422 000000 .word 0 ;/XBN size (hi wrd)/
1133 003424 000016 .word 14. ;/DBN size (lo wrd)/
1134 003426 000000 .word 0 ;/DBN size (hi wrd)/
1135 003430 121160 .word 41584. ;/LBN size (lo wrd)/
1136 003432 000000 .word 0 ;/LBN size (hi wrd)/
1137 003434 000144 .word 100. ;/RBN size (lo wrd)/
1138 003436 000000 .word 0 ;/RBN size (hi wrd)/
1139 003440 000021 .word 17. ;/Sectors per track/
1140 003442 000004 .word 4. ;/Surfaces per unit/
1141 003444 001147 .word 615. ;/Cylinders per unit/
1142 003446 000400 .word 256. ;/Write precomp cylinder/
1143 003450 001147 .word 615. ;/Reduce write current cylinder /
1144 003452 000000 .word 0 ;/Seek Rate/
1145 003454 000001 .word 1 ;/Use CRC or ECC/
1146 003456 000003 .word 3 ;/RCT Size/
1147 003460 000010 .word 8. ;/Number of RCT copies/
1148 003462 040037 .word †B0100000000011111 †H401F;/Media (lo wrd)/
1149 003464 022544 .word †B0010010101100100 †H2564;/Media (hi wrd)/
1150 003466 000001 .word 1 ;/Sector Interleave (n-to 1)/
1151 003470 000002 .word 2 ;/Surface to Surface Skew/
1152 003472 000004 .word 4. ;/Cylinder to Cylinder Skew/
1153 003474 000020 .word 16. ;/Gap size 0/
1154 003476 000020 .word 16. ;/Gap size 1/
1155 003500 000005 .word 5. ;/Gap size 2/
1156 003502 000050 .word 40. ;/Gap size 3/
1157 003504 000015 .word 13. ;/Sync size/
1158 003506 000001 .word 1 ;/MSCP cylinders per Unit/
1159 003510 000001 .word 1 ;/MSCP Groups per Cylinder/
1160 003512 000001 .word 1 ;/MSCP Tracks per Group/
1161 003514 000010 .word 8. ;/Max allowed bad spots per surface/

```

DISK UNIT INFORMATION TABLES

```

1162 003516 000151 .word 105. ;/Bad spot tolerance (bytes)/
1163 003520 001147 .word 615. ;/auto recal cylinder
1164 003522 001150 .word 616. ;/auto recal cylinder
1165
1166 003524 . =3000*UITsiz+UITsiz+UITsiz+UITsiz+UITsiz
1167
1168
1169 ;+
1170 ; Unit Information table RD54 Maxtor Drive
1171 ;
1172
1173
1174 003524 UIT5:
1175 ;/*Top of Unit Information table (UIT)
1176 003524 000066 .word 54. ;/XBN size (lo wrd) XBN size = 3*(1+sectors_per_track)/
1177 003526 000000 .word 0 ;/XBN size (hi wrd)/
1178 003530 000711 .word 201. ;/DBN size (lo wrd)/
1179 003532 000000 .word 0 ;/DBN size (hi wrd)/
1180 003534 137730 .word 137730 ;/LBN size (lo wrd)/
1181 003536 000004 .word 4 ;/LBN size (hi wrd)/
1182 003540 001141 .word 609. ;/RBN size (lo wrd)/
1183 003542 000000 .word 0 ;/RBN size (hi wrd)/
1184 003544 000021 .word 17. ;/Sectors per track/
1185 003546 000017 .word 15. ;/Surfaces per unit/
1186 003550 002311 .word 1225. ;/Cylinders per unit/
1187 003552 002311 .word 1225. ;/Write precomp cylinder/
1188 003554 002311 .word 1225. ;/Reduce write current cylinder /
1189 003556 000000 .word 0 ;/Seek Rate/
1190 003560 000001 .word 1 ;/Use CRC or ECC/
1191 003562 000007 .word 7 ;/RCT Size/
1192 003564 000010 .word 8. ;/Number of RCT copies/
1193 003566 040066 .word +B0100000000110110 ;+H4036;/Media (lo wrd)/
1194 003570 022544 .word +B0010010101100100 ;+H2564;/Media (hi wrd)/
1195 003572 000001 .word 1 ;/Sector Interleave (n-to 1)/
1196 003574 000002 .word 2 ;/Surface to Surface Skew/
1197 003576 000010 .word 8. ;/Cylinder to Cylinder Skew/
1198 003600 000020 .word 16. ;/Gap size 0/
1199 003602 000020 .word 16. ;/Gap size 1/
1200 003604 000005 .word 5. ;/Gap size 2/
1201 003606 000050 .word 40. ;/Gap size 3/
1202 003610 000015 .word 13. ;/Sync size/
1203 003612 000001 .word 1 ;/MSCP cylinders per Unit/
1204 003614 000001 .word 1 ;/MSCP Groups per Cylinder/
1205 003616 000001 .word 1 ;/MSCP Tracks per Group/
1206 003620 000040 .word 32. ;/Max allowed bad spots per surface/
1207 003622 000151 .word 105. ;/Bad spot tolerance (bytes)/
1208 003624 002311 .word 1225. ;/auto recal cylinder
1209 003626 002312 .word 1226. ;/auto recal cylinder possible on this vendor's
1210 ;/drive mmm
1211
1212 003630 . =3000*UITsiz+UITsiz+UITsiz+UITsiz+UITsiz+UITsiz
1213
1214
1215 ;+
1216 ; Unit Information table
1217 ;-
1218

```

DISK UNIT INFORMATION TABLES

```

1219
1220 003630          UIT6:
1221
1222 003630 000066      .word 54.      ;/*Top of Unit Information table (UIT)
1223 003632 000000      .word 0        ;/XBN size (lo wrd) XBN size = 3*(1+sectors per track)
1224 003634 000057      .word 47.      ;/XBN size (hi wrd)/
1225 003636 000000      .word 0        ;/DBN size (lo wrd)/
1226 003640 016677      .word 016677   ;/DBN size (hi wrd)/
1227 003642 000002      .word 2        ;/LBN size (lo wrd)/
1228 003644 000524      .word 340.     ;/LBN size (hi wrd)/
1229 003646 000000      .word 0        ;/RBN size (lo wrd)/
1230 003650 000021      .word 17.      ;/RBN size (hi wrd)/
1231 003652 000010      .word 8.       ;/Sectors per track/
1232 003654 002000      .word 1024.    ;/Surfaces per unit/
1233 003656 002000      .word 1024.    ;/Cylinders per unit/
1234 003660 002000      .word 1024.    ;/Write precomp cylinder/
1235 003662 000000      .word 0        ;/Reduce write current cylinder /
1236 003664 000001      .word 1        ;/Seek Rate/
1237 003666 000005      .word 5        ;/Use CRC or ECC/
1238 003670 000003      .word 3        ;/RCT Size/
1239 003672 040065      .word +B0100000000110101 ;+H4035;/Media (lo wrd)/
1240 003674 022544      .word +B0010010101100100 ;+H2564;/Media (hi wrd)/
1241 003676 000001      .word 1        ;/Sector Interleave (n-to-1)/
1242 003700 000002      .word 2        ;/Surface to Surface Skew/
1243 003702 000010      .word 8.       ;/Cylinder to Cylinder Skew/
1244 003704 000020      .word 16.      ;/Gap size 0/
1245 003706 000020      .word 16.      ;/Gap size 1/
1246 003710 000005      .word 5.       ;/Gap size 2/
1247 003712 000050      .word 40.      ;/Gap size 3/
1248 003714 000015      .word 13.      ;/Sync size/
1249 003716 000001      .word 1        ;/MSCP cylinders per Unit/
1250 003720 000001      .word 1        ;/MSCP Groups per Cylinder/
1251 003722 000001      .word 1        ;/MSCP Tracks per Group/
1252 003724 000040      .word 32.      ;/Max allowed bad spots per surface/
1253 003726 000156      .word 110.     ;/Bad spot tolerance (bytes)/
1254 003730 002000      .word 1024.    ;/auto recal cylinder
1255 003732 002000      .word 1024.    ;/auto recal cylinder
1256
1257          003734      .=3000*UITsiz+UITsiz+UITsiz+UITsiz+UITsiz+UITsiz+UITsiz
1258
1259
1260          ;+
1261          ;      Unit Information table
1262          ;-
1263
1264
1265 003734          UIT7:
1266
1267 003734 000066      .word 54.      ;/*Top of Unit Information table (UIT)
1268 003736 000000      .word 0        ;/XBN size (lo wrd) XBN size = 3*(1+sectors_per_track)/
1269 003740 000057      .word 47.      ;/XBN size (hi wrd)/
1270 003742 000000      .word 0        ;/DBN size (lo wrd)/
1271 003744 016677      .word 016677   ;/DBN size (hi wrd)/
1272 003746 000002      .word 2        ;/LBN size (lo wrd)/
1273 003750 000524      .word 340.     ;/LBN size (hi wrd)/
1274 003752 000000      .word 0        ;/RBN size (lo wrd)/
1275 003754 000021      .word 17.      ;/RBN size (hi wrd)/
                    ;/Sectors per track/

```

DISK UNIT INFORMATION TABLES

1276	003756	000010	.word	8.	;/Surfaces per unit/
1277	003760	002000	.word	1024.	;/Cylinders per unit/
1278	003762	002000	.word	1024.	;/Write precomp cylinder/
1279	003764	002000	.word	1024.	;/Reduce write current cylinder /
1280	003766	000000	.word	0	;/Seek Rate/
1281	003770	000001	.word	1	;/Use CRC or ECC/
1282	003772	000005	.word	5	;/RCT Size/
1283	003774	000003	.word	3	;/Number of RCT copies/
1284	003776	040065	.word	†B0100000000110101	;/Media (lo wrd)/
1285	004000	022544	.word	†B0010010101100100	;/Media (hi wrd)/
1286	004002	000001	.word	1	;/Sector Interleave (n-to-1)/
1287	004004	000002	.word	2	;/Surface to Surface Skew/
1288	004006	000010	.word	8.	;/Cylinder to Cylinder Skew/
1289	004010	000020	.word	16.	;/Gap size 0/
1290	004012	000020	.word	16.	;/Gap size 1/
1291	004014	000005	.word	5.	;/Gap size 2/
1292	004016	000050	.word	40.	;/Gap size 3/
1293	004022	000015	.word	13.	;/Sync size/
1294	004022	000001	.word	1	;/MSCP cylinders per Unit/
1295	004024	000001	.word	1	;/MSCP Groups per Cylinder/
1296	004026	000001	.word	1	;/MSCP Tracks per Group/
1297	004030	000040	.word	32.	;/Max allowed bad spots per surface/
1298	004032	000156	.word	110.	;/Bad spot tolerance (bytes)/
1299	004034	002000	.word	1024.	;/auto recal cylinder
1300	004036	002000	.word	1024.	;/auto recal cylinder

1301  
1302           004040       .-3000+UITsiz+UITsiz+UITsiz+UITsiz+UITsiz+UITsiz+UITsiz+UITsiz

1303  
1304  
1305  
1306       ;+       DEFAULT Unit Information table  
1307       ;:  
1308       ;

1309  
1310       004040       UITdf:  
1311                               ; /\*Top of Unit Information table (UIT)  
1312       004040       000066       .word   54.       ;/XBN size (lo wrd) XBN size - 3\*(1+sectors per\_track)/  
1313       004042       000000       .word   0       ;/XBN size (hi wrd)/  
1314       004044       000311       .word   201.       ;/DBN size (lo wrd)/  
1315       004046       000000       .word   0       ;/DBN size (hi wrd)/  
1316       004050       137710       .word   137710       ;/LBN size (lo wrd)/  
1317       004052       000004       .word   4       ;/LBN size (hi wrd)/  
1318       004054       001161       .word   625.       ;/RBN size (lo wrd)/  
1319       004056       000000       .word   0       ;/RBN size (hi wrd)/  
1320       004060       000021       .word   17.       ;/Sectors per track/  
1321       004062       000017       .word   15.       ;/Surfaces per unit/  
1322       004064       002311       .word   1225.       ;/Cylinders per unit/  
1323       004066       002311       .word   1225.       ;/Write precomp cylinder/  
1324       004070       002311       .word   1225.       ;/Reduce write current cylinder /  
1325       004072       000000       .word   0       ;/Seek Rate/  
1326       004074       000001       .word   1       ;/Use CRC or ECC/  
1327       004076       000007       .word   7       ;/RCT Size/  
1328       004100       000010       .word   8.       ;/Number of RCT copies/  
1329       004102       040066       .word   †B0100000000110110   ;/Media (lo wrd)/  
1330       004104       022544       .word   †B0010010101100100   ;/Media (hi wrd)/  
1331       004106       000001       .word   1       ;/Sector Interleave (n-to-1)/  
1332       004110       000002       .word   2       ;/Surface to Surface Skew/

## DISK UNIT INFORMATION TABLES

1333	004112	000015	.word	13.	;/Cylinder to Cylinder Skew/
1334	004114	000020	.word	16.	;/Gap size 0/
1335	004116	000020	.word	16.	;/Gap size 1/
1336	004120	000005	.word	5.	;/Gap size 2/
1337	004122	000050	.word	40.	;/Gap size 3/
1338	004124	000015	.word	13.	;/Sync size/
1339	004126	000001	.word	1	;/MSCP cylinders per Unit/
1340	004130	000001	.word	1	;/MSCP Groups per Cylinder/
1341	004132	000001	.word	1	;/MSCP Tracks per Group/
1342	004134	000012	.word	10.	;/Max allowed bad spots per surface/
1343	004136	000151	.word	105.	;/Bad spot tolerance (bytes)/
1344	004140	002000	.word	1024.	;/auto recal cylinder
1345	004142	002000	.word	1024.	;/auto recal cylinder
1346					

## DISK PARAMETER QUESTIONS

```

1348                                     .sbttl DISK PARAMETER QUESTIONS
1349     .nlist bin
1350
1351     ;*
1352     ; P table Questions
1353     ;*
1354
1355 004144 IP.adr: .ASCIZ /IP Address/
1356 004157 vec.adr: .ASCIZ /Vector Address/
1357 004176 prk.hds: .ASCIZ /Just park the heads/
1358 004222 drv.nbr: .ASCIZ /Logical Drive (0 255)/
1359 004250 ser.nbr: .ASCIZ /Drive Serial Number(1 32000)/
1360 004305 auto.md: .ASCIZ /Auto Format Mode/
1361 004326 warning: .ASCIZ /***** WARNING all the data on this drive will be DESTROYED *****/
1362 004425 .byte 0
1363
1364 004426 do.cont: .ASCIZ /Proceed to format the drive/
1365
1366 004462 DrvTxa: .asciz /*N*/AUIT# Drive Name/*N/
1367 004511 DrvTxb: .asciz /*A_-----*N/
1368 004605 DrvTx0: .asciz /*A_ 0 RD51 *N/
1369 004701 DrvTx1: .asciz /*A_ 1 RD52 part # 30 21721 02 (1 light on front panel) *N/
1370 004775 DrvTx2: .asciz /*A_ 2 RD52 part # 30-23227-02 (2 lights on front panel) *N/
1371 005071 DrvTx3: .asciz /*A_ 3 RD53 *N/
1372 005165 DrvTx4: .asciz /*A_ 4 RD31 *N/
1373 005261 DrvTx5: .asciz /*A_ 5 RD54 *N/
1374 005355 DrvTx6: .asciz /*A_ 6 *N/
1375 005450 DrvTx7: .asciz /*A_ 7 *N/
1376 005543 DrvTxc: .asciz /*A_ 10 *N/
1377 005637 ASMSGr: .ASCIZ /*A_ Unrecognized Drive *N/
1378
1379 005733 ASMSG1: .ASCII /*N*/AAUTOSIZER FOUND:/
1380 005757 .ASCIZ /*N*/Aunt Cyls UIT# Drive Name/*N/
1381 006021 ASMSG7: .ASCIZ /*A_ *D1*A Nonexistent/*N/
1382 006066 ASMSG8: .ASCIZ /*A_ *D1*A RX50 Floppy (UNFORMATABLE)*N/
1383 006152 ASMSG9: .ASCIZ /*A_ *D1*A RX33 Floppy (FORMATABLE)*N/
1384 006234 ASMSG2: .ASCIZ /*A_ *D1*A *D4*A /
1385 006257 ASMSG3: .ASCIZ /*N*/AAUTOSIZER RETURNED FAILURE STATUS CODE *D1*A:/
1386 006341 ASMSG4: .ASCIZ /*N*/A CONTROLLER CHIP NEVER WENT DONE/
1387 006411 ASMSG5: .ASCIZ /*N*/A CONTROLLER CHIP NEVER INTERRUPTED/
1388 006463 ASMSG6: .ASCIZ /*N*/A SEEK FAILED/
1389 006507 ASMSGT: .ASCIZ /*N/
1390 006512 parkdrv: .ASCIZ /*N*/PLEASE wa'it .... parking d'sk heads./
1391
1392 006563 Unt.nbr: .ASCIZ /Enter Unit Identifier Table (UIT)/
1393 006625 ask.prg: .ASCIZ /What local program do you want to run/
1394 006673 ask.xbn: .ASCIZ /Enter XBN size in decimal (upto 10 digits)/
1395 006746 ask.dbn: .ASCIZ /Enter DBN size in decimal (upto 10 digits)/
1396 007021 ask.lbn: .ASCIZ /Enter LBN size in decimal (upto 10 digits)/
1397 007074 ask.rbn: .ASCIZ /Enter RBN size in decimal (upto 10 digits)/
1398
1399
1400 007147 bot.dev: .ASCII <15><12>/WARNING - If FLOPPY remove boot diskette if in drive to be formatted and/
1401 007261 .ASCII <15><12>/ insert a diskette to be formatted./
1402 007351 .ASCII <15><12>/ If WINCHESTER check if wrt protect switch (off) & ready switch (on)./
1403 007471 .ASCIZ <15><12>/WARNING - All data on drive will be DESTROYED, do you want to continue?/
1404 007603 bot.rep: .ASCIZ /If boot drive, reinsert boot diskette & ress <RETURN>./

```

DISK PARAMETER QUESTIONS

```

1405 007673 bot.con: .ASCIZ <15><12>/Do you want to format another diskette?/
1406
1407 ; Top of Unit Information table (UIT)
1408
1409 007745 TBQ0: .ASCIZ /XBN size (lo wrd) XBN size 3*(1+sectors per_track)/
1410 010032 TBQ1: .ASCIZ /XBN size (hi wrd)/
1411 010054 TBQ2: .ASCIZ /DBN size (lo wrd)/
1412 010076 TBQ3: .ASCIZ /DBN size (hi wrd)/
1413 010120 TBQ4: .ASCIZ /LBN size (lo wrd)/
1414 010142 TBQ5: .ASCIZ /LBN size (hi wrd)/
1415 010164 TBQ6: .ASCIZ /RBN size (lo wrd)/
1416 010206 TBQ7: .ASCIZ /RBN size (hi wrd)/
1417 010230 TBQ8: .ASCIZ /Sectors per track/
1418 010252 TBQ9: .ASCIZ /Surfaces per unit/
1419 010274 TBQ10: .ASCIZ /Cylinders per unit/
1420 010317 TBQ11: .ASCIZ /Write precomp cylinder/
1421 010346 TBQ12: .ASCIZ /Reduce write current cylinder /
1422 010405 TBQ13: .ASCIZ /Seek Rate/
1423 010417 TBQ14: .ASCIZ /Use CRC or ECC/
1424 010436 TBQ15: .ASCIZ /RCT Size/
1425 010447 TBQ16: .ASCIZ /Number of RCT copies/
1426 010474 TBQ17: .ASCIZ /Media (lo wrd)/
1427 010513 TBQ18: .ASCIZ /Media (hi wrd)/
1428 010532 TBQ19: .ASCIZ /Sector Interleave (n-to 1)/
1429 010565 TBQ20: .ASCIZ /Surface to Surface Skew/
1430 010615 TBQ21: .ASCIZ /Cylinder to Cylinder Skew/
1431 010647 TBQ22: .ASCIZ /Gap size 0/
1432 010662 TBQ23: .ASCIZ /Gap size 1/
1433 010675 TBQ24: .ASCIZ /Gap size 2/
1434 010710 TBQ25: .ASCIZ /Gap size 3/
1435 010723 TBQ26: .ASCIZ /Sync size/
1436 010735 TBQ28: .ASCIZ /MSCP cylinders per Unit/
1437 010765 TBQ29: .ASCIZ /MSCP Groups per Cylinder/
1438 011016 TBQ30: .ASCIZ /MSCP Tracks per Group/
1439 011044 TBQ31: .ASCIZ /Max allowed bad spots per surface/
1440 011106 TBQ32: .ASCIZ /Bad spot tolerance (bytes)/
1441
1442 011141 DF1: .ASCIZ /Controller Initialization Timeout/
1443 011203 DF2: .ASCIZ /Controller never advanced to next step/
1444 011252 DF3: .ASCIZ /Controller can not execute local programs or non STD DUP dialog program/
1445 011362 DF4: .ASCIZ /NXM Trap at controllers IP address/
1446 ;DF10: .ASCIZ /No Interrupt occurred after SA polled/
1447 011425 DF11: .ASCIZ /Bad Response Packet returned/
1448 011462 DF12: .ASCIZ /Fatal SA error ctrl offline/
1449 011516 DF13: .ASCIZ /No progress shown after a cmd had timed out/
1450 011572 DF14: .ASCIZ /GET DUST CMD time_out after another CMD time_out/
1451 011653 DF15: .ASCIZ /*N*AFatal error was reported when running local program/
1452 011743 DF16: .ASCIZ /*N*AA Special was reported when running local program don't know how to handle it/
1453 012065 SFO: .ASCIZ /DUP protocol Error, unexpected message/
1454 012134 SF1: .ASCIZ /*N*ASYSTEM is NOT in manual mode/
1455 012175 SF100: .ASCIZ /Unexpected or delayed Controller Interrupt/
1456 012250 HRDO: .ASCIZ /Fatal Format error/
1457 012273 SFT0: .ASCIZ /Controller in an unexpected ACTIVE state/
1458 012344 SFT1: .ASCIZ /Wrong Model Number on controller/
1459 012405 PBO: .ASCIZ /*N*AModel # listed *06/
1460 012434 PB1: .ASCIZ /*N*AEExpected SA step bit *06*A,Received in SA *06/
1461 012516 PB3: .ASCIZ /*N*AAasking for Format Parameter table/

```



## DISK PARAMETER QUESTIONS

```

1462 012564 PB4: .ASCIZ /*N*AReceived valid Format Parameter table/
1463 012636 PB5: .ASCIZ /*N*AO n UNIT #06#A, #06 Bad Blks were found during Format/
1464 012727 PB6: .ASCIZ /*N*AO n UNIT #06#A, #06 Bad Blks were found during Verify pass #06/
1465 013031 PB7: .ASCIZ /*N*ADUP Message Type: #06/
1466 013063 PB8: .ASCIZ /*N*ADUP message number: #06/
1467 013117 PB9: .ASCIZ /*N*AMSCP Controller model #: #03/
1468 013161 PB10: .ASCIZ /*N*AMicrocode version #: #03/
1469 013223 PB11: .ASCIZ /*N*AController is IDLE when it should be ACTIVE running format program/
1470 013332 PB13: .ASCIZ /*N/
1471 013335 PF2: .ASCIZ /*N*NAFinished local program without procedure error/
1472 013422 PBF0: .ASCIZ /*N*AFFormat Parameter table entry at byte #06#N#A is out of range/
1473 013522 PBF1: .ASCIZ /*N*AFFormat Parameter table entry at byte #06#N#A is incompatible with entry at byte #06/
1474 013651 PBF2: .ASCIZ /*N*AUUNIT #06#A does not exist on controller/
1475 013725 PBF3: .ASCIZ /*N*AUUNIT #06#A does exist but doesn't respond on controller/
1476 014021 PBF4: .ASCIZ /*N*AUUNIT #06#A is write protected /
1477 014064 PBF5: .ASCIZ /*N*AWWrite Fault detected on UNIT #06/
1478 014131 PBF6: .ASCIZ /*N*AAAttempt to step hd #03#A at cyl #03#A failed on UNIT #06/
1479 014226 PBF7: .ASCIZ /*N*AAAttempt to format hd #03#A at cyl #03#A failed on UNIT #06/
1480 014325 PBF8: .ASCIZ /*N*ATo many Bad Blocks total Bad Blocks #06/
1481 014415 PBF9: .ASCIZ /*N*ADisk Controller model : #03/
1482 014455 PBF10: .ASCIZ /*N*AMicrocode version : #03/
1483 014515 PB11crn: .ASCIZ /*N*AEExpected CRN #06#A,Received CRN #06/
1484 014565 PB11op: .ASCIZ /*N*ACMDpkt Opcode #06#A,RSPpkt Opcode #06/
1485 014637 PB11sts: .ASCIZ /*N*AResponse pkt status #06/
1486 014673 PB11end: .ASCIZ /*N*ANo end bit(200) in response packet endcode/
1487 014752 PB11GDS: .ASCIZ /*N*AGet Dust Status cmd/
1488 015002 PB11ESP: .ASCIZ /*N*AEExecute Supplied Prg cmd/
1489 015037 PB11ELP: .ASCIZ /*N*AEExecute Local Prg cmd/
1490 015071 PB11SD: .ASCIZ /*N*ASend Data cmd/
1491 015113 PB11RD: .ASCIZ /*N*AReceive Data cmd/
1492 015140 PB11AP: .ASCIZ /*N*AAAbort Prg cmd/
1493 015162 pb11s0: .ASCIZ /*N*AsTs: successful/
1494 015207 pb11s1: .ASCIZ /*N*AsTs: Invalid Command/
1495 015241 pb11s2: .ASCIZ /*N*AsTs: No Region Available/
1496 015277 pb11s3: .ASCIZ /*N*AsTs: No Region Suitable/
1497 015334 pb11s4: .ASCIZ /*N*AsTs: Program Not Known/
1498 015370 pb11s5: .ASCIZ /*N*AsTs: Load Failure/
1499 015417 pb11s6: .ASCIZ /*N*AsTs: Standalone/
1500 015444 pb11s9: .ASCIZ /*N*AsTs: Host Buffer Access error/
1501 015507 pb11w0: .ASCIZ /*N*AUknown command OP CODE received in timeout loop/
1502 015573 pb11w1: .ASCIZ /*N*AUknown command CRN received in command timeout loop/
1503 015664 pb1201: .ASCIZ /*N*ASA er: Envelope\packet Read (parity or timeout)/
1504 015750 pb1202: .ASCIZ /*N*ASA er: Envelope\packet Write (parity or timeout)/
1505 016035 pb1203: .ASCIZ /*N*ASA er: Controller ROM and RAM parity/
1506 016106 pb1204: .ASCIZ /*N*ASA er: Controller RAM parity/
1507 016147 pb1205: .ASCIZ /*N*ASA er: Controller ROM parity/
1508 016210 pb1206: .ASCIZ /*N*ASA er: Queue Read (parity or timeout)/
1509 016262 pb1207: .ASCIZ /*N*ASA er: Queue Write (parity or timeout)/
1510 016335 pb1208: .ASCIZ /*N*ASA er: Interrupt Master/
1511 016371 pb1209: .ASCIZ /*N*ASA er: Host Access Timeout (higher level protocol dependent)/
1512 016472 pb1210: .ASCIZ /*N*ASA er: Credit Limit Exceeded /
1513 016534 pb1211: .ASCIZ /*N*ASA er: Bus Master Error/
1514 016570 pb1212: .ASCIZ /*N*ASA er: Diagnostic Controller Fatal error/
1515 016645 pb1213: .ASCIZ /*N*ASA er: Instruction Loop Timeout/
1516 016711 pb1214: .ASCIZ /*N*ASA er: Invalid Connection Identifier/
1517 016762 pb1215: .ASCIZ /*N*ASA er: Interrupt Write Error/
1518 017023 pb1216: .ASCIZ /*N*ASA er: MAINTENANCE READ\WRITE Invalid Region Identifier/

```

DISK PARAMETER QUESTIONS

```
1519 017117 pb1217: .ASCIZ /*N*ASA er: MAINTENANCE WRITE Load to non loadable controller/
1520 017214 pb1218: .ASCIZ /*N*ASA er: Controller RA:1 error (non parity)/
1521 017271 pb1219: .ASCIZ /*N*ASA er: INIT sequence error/
1522 017330 pb1220: .ASCIZ /*N*ASA er: High level protocol incompatibility error/
1523 017415 pb1221: .ASCIZ /*N*ASA er: Purge\poll hardware failure/
1524 017464 pb1222: .ASCIZ /*N*ASA er: Mapping Register read error (parity or timeout)/
1525 017557 pb1223: .ASCIZ /*N*ASA er: Attempt to set port data transfer mapping when option not present/
1526 017674 PB12: .ASCIZ /*N*ASA Value (oct) *06/
1527
1528 017723 PBsf0: .ASCIZ /*N*ADUP type *06*A message number *06/
1529 017771 DRPunt: .ASCIZ /*N*ARQDX DRIVE *06*A finished./
1530 020032 TYPASC: .ASCIZ /*N*PLEASE TYPE ANSWER to controller question or just <return>/
1531
1532 ;mmm
1533 ;
```

FORMAT Messages

```

1535          .sbt1l  FORMAT Messages
1536
1537          ; quer'es
1538
1539 020131  qfuit:  ;.byte  2...b.spl          ; Unit Info Table? (spl #2)
1540 020131          .asciz  '*N*Entering UIT*02*A: on drive number *D3*N'
1541 020206  qfdat:  ;.byte  0...a.que          ; Date? (que #0)
1542 020206          .asciz  'Enter date <MM DD-YYYY>:'
1543 020237  dfunt:  ;.byte  1...a.def          ; Unit? (def #1)
1544 020237          .asciz  'Enter unit number to format <0>:'
1545 020300  dfbad:  ;.byte  4...a.def          ; Use Bad? (def #4)
1546 020300          .asciz  'Use existing bad block information <N>:'
1547 020350  dfdwn:  ;.byte  5...a.def          ; Downline? (def #5)
1548 020350          .asciz  'Use down line load <Y>:'
1549 020400  dfcon:  ;.byte  6...a.def          ; Continue? (def #6)
1550 020400          .asciz  'Continue if bad block information is inaccessible <N>:'
1551 020467  qfser:  ;.byte  7...a.que          ; Ser'al #? (que #7)
1552 020467          .asciz  'Enter non zero serial number <8 10 d'gits>:'
1553 020543  ASK.ANSWER:
1554 020543          .asciz  'ans>'
1555
1556          ; Informational Messages
1557
1558 020550  sfbegt:  ;.byte  0...a.inf          ; Begin (inf #0)
1559 020550          .asciz  '*N*Format Begun'
1560 020571  sfdont:  ;.byte  1...a.inf          ; Complete (inf #1)
1561 020571          .asciz  '*N*Format complete'
1562 020615  sfrevt:  ;.byte  2...a.inf          ; # of Revector'd LBNS (inf #2)
1563 020615          .asciz  '* Revector'd LBNS'
1564 020637  sfr1t:  ;.byte  3...a.inf          ; # of primary ... (inf #3)
1565 020637          .asciz  '* Primary revector'd LBNS'
1566 020671  sfr2t:  ;.byte  4...a.inf          ; # of secondary ... (inf #4)
1567 020671          .asciz  '* Secondary/tertiary revector'd LBNS'
1568 020736  sfrcbt:  ;.byte  5...a.inf          ; # of Bad RCT blocks ... (inf #5)
1569 020736          .asciz  '* Bad blocks in the RCT area due to data errors'
1570 021016  sfdbbt:  ;.byte  7...a.inf          ; # of Bad DBNs ... (inf #7)
1571 021016          .asciz  '* Bad blocks in the DBN area due to data errors'
1572 021076  sfxbbt:  ;.byte  9...a.inf          ; # of Bad XBNs ... (inf #9)
1573 021076          .asciz  '* Bad blocks in the XBN area due to data errors'
1574 021156  sftryt:  ;.byte  11...a.inf         ; # of Retries (inf #11)
1575 021156          .asciz  '* Blocks retried on the check pass'
1576 021221  sfrbbt:  ;.byte  14...a.inf         ; # of Bad RBNS ... (inf #14)
1577 021221          .asciz  '* Bad RBNS'
1578 021234  sfcylt:  ;.byte  15...a.'nf         ; Formatting Cyl (inf #15)
1579 021234          .asciz  'Formatting Cyl *'
    
```

## FORMAT Messages

```

1581
1582      ; Successful Termination Messages
1583
1584      ;.byte      12...a.te      ; Reformat Worked (ter #12)
1585 021255 sffcut: .asciz  '%N%AFCT used successfully'
1586      ;.byte      13...a.ter     ; Reconstruct Worked (ter #13)
1587 021307 sffcnt: .ascii  '%N%AFCT wa. not used'
1588 021333      .asciz  '%N%AFFormat completed'
1589      ; Error messages
1590
1591 021360 efstat: ;.byte  1...a.fat      ; Status Error (fat #1)
1592 021360      .asciz  '%N%AGET STATUS failure'
1593
1594 021407 efsndt: ;.byte  2...a.fat      ; Send Error (fat #2)
1595 021407      .asciz  '%N%AQ PORT send error'
1596
1597 021435 efcmdt: ;.byte  3...a.fat      ; Command Error (fat #3)
1598 021435      .asciz  '%N%AUnsuccessful command'
1599
1600 021466 efrcvr: ;.byte  4...a.fat      ; Receive Error (fat #4)
1601 021466      .asciz  '%N%AQ PORT receive error'
1602
1603 021517 efbust: ;.byte  5...a.fat      ; Bus Error (fat #5)
1604 021517      .asciz  '%N%AQ-Bus I/O error'
1605
1606 021543 efinit: ;.byte  6...a.fat      ; Format Init Error (fat #6)
1607 021543      .asciz  '%N%AFormatter initialization error'
1608
1609 021606 efnut:  ;.byte  7...a.fat      ; Unit nonexistent error (fat #7)
1610 021606      .asciz  '%N%ANonexistent unit number'
1611
1612 021642 efdxft: ;.byte  8...a.fat      ; DBN/XBN Format error (fat #8)
1613 021642      .asciz  '%N%ADB N/XBN format error (drive FORMAT command failed)'
1614
1615 021731 effcct: ;.byte  9...a.fat      ; FCT copies error (fat #9)
1616 021731      .asciz  '%N%AFCT does not have enough good copies of each block'
1617
1618 022020 efsekt: ;.byte 10...a.fat      ; Seek error (fat #10)
1619 022020      .asciz  '%N%ASEEK error'
1620
1621 022037 efrctt: ;.byte 11...a.fat      ; RCT copies error (fat #11)
1622 022037      .asc'z  '%N%ARCT does not have enough good copies of each block'
1623
1624 022126 eflbft: ;.byte 12...a.fat      ; LBN format error (fat #12)
1625 022126      .asciz  '%N%ALBN format error (drive FORMAT command failed)'
1626
1627 022211 effcwt: ;.byte 13...a.fat      ; FCT write error (fat #13)
1628 022211      .asciz  '%N%AFCT write error (check write protect switch)'
1629
1630 022272 efrctr: ;.byte 14...a.fat      ; RCT read error (fat #14)
1631 022272      .asciz  '%N%ARCT read error'
1632
1633 022315 efrctw: ;.byte 15...a.fat      ; RCT write error (fat #15)
1634 022315      .asciz  '%N%ARCT write error'
1635
1636 022341 efrctf: ;.byte 16...a.fat      ; RCT full error (fat #16)
1637 022341      .asc'z  '%N%ARCT full'

```

FORMAT Messages

```

1638
1639 022356 effcnt: ;.byte 17...a.fat ; FCT read error (fat #17)
1640 022356 .asciz 'N%AFCT read error'
1641
1642 022401 effcnt: ;.byte 18...a.fat ; FCT nonexistent error (fat #18)
1643 022401 .asciz 'N%AFCT nonexistent'
1644
1645 022425 effcdt: ;.byte 19...a.fat ; FCT downline load error (fat #19)
1646 022425 .asciz 'N%AFCT Down line load error'
1647
1648 022462 eftmot: ;.byte 20...a.fat ; Drive t'meout error (fat #20)
1649 022462 .asciz 'N%ADrive in't timeout'
1650
1651 022511 efillt: ;.byte 21...a.fat ; Illegal response error (fat #21)
1652 022511 .asciz 'N%AIllegal response to start up quest'on'
1653
1654 022563 efwart: ;.byte 22...a.fat ; Head error (fat #22)
1655 022563 .asciz 'N%AWARNING possible head addressing problem run diagnostics
1656
1657 022664 efinpt: ;.byte 23...a.fat ; Input error (fat #23)
1658 022664 .asciz 'N%AINPUT Error '
1659
1660 022705 efmedt: ;.byte 24...a.fat ; Media error (fat #24)
1661 022705 .asciz 'N%AMedia degraded'
1662
1663 022730 efunrg: ;.byte 1...a.fat ; Status Error (fat #1)
1664 022730 .asciz 'N%AUncogonized drive'
1665
1666 .list bin
1667 .even

```



## Global subroutines

```

1726 023022 106427 000340      mtps   #340      ;don't want interrupts while setting up for cmd
1727 023026 004737 031606      jsr    pc,BIT15T ;test SA make sure not a fatal error
1728 023032 013700 002462      mov    cmdpak+10,r0 ;get opcode
1729 023036 022700 000001      cmp    #op.gds,r0 ;if the command issued was a GETDUST STATUS and time
out big trouble
1730 023042 001006      bne    GDS0      ;if not go do a GET DUST to find out what the situat
ion is
1731 023044      ERRDF  12,df14   ;type no interrupt after get dust status command cont
roller dead
1732 023054 000137 037420      jmp    dropunt   ;drop unit and go on
1733      ;GETDUST      ;save timed out command information
1734
1735
1736 023060 017737 157242 002544  GDS0:  mov    @vector,LSTVCT ;store the vector address of timeout command
1737 023066 013737 002452 002540      mov    cmdpak,LSTCRN ;store the CRN of the timed out command
1738 023074 013737 002462 002542      mov    cmdpak+10,LSTCMD ;store the opcode of timed out command
1739
1740 023102 032737 100000 002534      bit    #b't15,cmdrng+2 ;test ownership of ring make sure we own it
1741 023110 001363      bne    GDS0      ;if we don't own it wait until we do
1742 023112 012737 000016 002446      mov    #14.,cmdlen ;load lenght of packet to be send
1743 023120 112737 000000 002450      movb  #0,cmdlen+2 ;load msg type and credit
1744 023126 112737 000002 002451      movb  #dup.id,cmdlen+3 ;load DUP connection ID
1745 023134 005237 002452      inc    cmdpak     ;load new CRN
1746 023140 005037 002454      clr    cmdpak+2
1747 023144 005037 002456      clr    cmdpak+4
1748 023150 005037 002460      clr    cmdpak+6
1749 023154 012737 000001 002462      mov    #op.gds,cmdpak+10 ;load up opcode
1750 023162 005037 002464      clr    cmdpak+12 ;no modifiers
1751
1752 023166 012777 023226 157132      mov    #RFDO,@vector ;NEW VECTOR PLACE
1753 023174 012737 002352 002526      mov    #rsppak,rsprng ;load response packet area into ring
1754 023202 012737 002452 002532      mov    #cmdpak,cmdrng ;load command packet area into ring
1755 023210 012737 140000 002530      mov    #140000,RSPRNG+2 ;PORT OWNERSHIP BIT.
1756 023216 012737 100000 002534      mov    #bit15,CMDRNG+2
1757 023224 000655      br     POLLWT    ;GO and wait for interrupt
1758
1759
1760
1761      ;+
1762      ; There is only 3 ways out code.
1763      ; If GETDUST resposne and TIMED_OUT cmd response was handled
1764      ; if LSTCRN = 0 and RSPPAK+10 = OP.GDS+OP.END then
1765      ; back to DUP dialog mode.
1766      ;or
1767      ; (TIMED_OUT cmd still hasn't returned but GETDUST has returned)
1768      ; if LSTCRN = # and RSPPAK+10 = OP.GDS+OP.END then
1769      ; check if idle or active. if idle then error
1770      ; check for progress in progress indicator if no progress then error
1771      ; load LSTVCT into @vector,LSTCRN into cmdpak, LSTCMD into cmdpak+10
1772      ; set response ring ownership to Port Owned
1773      ; jmp to pollwt.
1774      ;or
1775      ; (TIMED_OUT cmd response recieved before GETDUST response returned)
1776      ; if LSTCRN = # and RSPPAK+10 not= OP.GDS+OP.END then
1777      ; clear LSTCRN and
1778      ; jmp to pollwt.
1779      ;+
1780 023226      RFDO:      ;INTR TO HERE if GETDUST or TIMED_OUT cmd
1781 023226 106427 000340      mtps   #340      ;No interrupts please
1782 023232 062706 000004      add    #4,sp     ;fix stack 4 for intrpt

```

## Global subroutines

```

1783 023236 013701 002452      mov      cmdpak,r1      ;check command packet CRN
1784 023242 013700 002352      mov      rsppak,r0     ;check response packet CRN
1785 023246 020001              cmp      r0,r1         ;Are they the SAME must be GETDUST cmd
1786 023250 001103              bne      3$           ;if not it must be the TIMED_OUT cmd
1787
1788 023252 023727 002362 000201  cmp      rsppak+10,#op.gds+op.end ;it should be a GETDUST lets make sure
1789 023260 001412              beq      1$           ;
1790 023262              printf   #pb11w0      ;unexpected cmd response in time out loop
1791 023302 000137 037404              jmp      unkwn        ;error handler
1792
1793 023306 004737 030654              jsr      pc,RSPCHK    ;check the response
1794 023312 005737 002540              tst      LSTCRN       ;see if timed out command was already rec'ed (lstrc
rn = 0)
1795 023316 001004              bne      2$           ;
1796 023320 062706 000002              add      #2,sp        ;adjust stack for Timed Out cmd's initial call to P0
LLWT
1797 023324 000137 034100              jmp      DUPDLG       ;if Timed out cmd was already received then goto DUP
dialog mode
1798
1799 023330              2$:              ;if Timed out command was not received already (LSTC
RN not= 0)
1800 023330 132737 000010 002371      bitb     #bit3,rsppek+17 ;if server idle then error
1801 023336 001010              bne      1002$       ;if not check for progress
1802 023340              printf   #pb11        ;controller idle when it should be active
1803
1804 023360 013700 002372              1002$:  mov      rsppek+20,r0   ;check for progress in progress indicator
1805 023364 013701 002374              mov      rsppek+22,r1
1806 023370 020037 002546              cmp      r0,lopgrj    ;see if low word of progress indicator is the same a
s older value
1807 023374 001007              bne      1001$       ;if it is then continue
1808 023376 020137 002550              cmp      r1,hiprgj    ;see if high vaule is the same
1809 023402 001004              bne      1001$       ;
1810 023404              ERRDF   11,DF13      ;no progress shown after cmd timeout
1811
1812 023414 010037 002546              1001$:  mov      r0,lopgrj    ;update progress indicator
1813 023420 010137 002550              mov      r1,hiprgj
1814 023424 013737 002540 002452      mov      LSTCRN,cmdpak ;move TIMED_OUT cmd CRN into cmd
1815 023432 013737 002542 002462      mov      LSTCMD,cmdpak+10 ;move TIMED_OUT cmd Opcode into cmd
1816 023440 013777 002544 156660      mov      LSTVCT,@vector ;load TIMED_OUT cmd interrupt handler address into v
ector
1817 023446 012737 140000 002530      mov      #140000,RSPRNG+2 ;Port owned
1818 023454 000137 022760              jmp      pollw        ;wait for TIMED OUT cmd response
1819
1820
1821
1822 023460 020037 002540              3$:      cmp      r0,LSTCRN    ;check the crn with the last CRN from the timeout co
mmand
1823 023464 001412              beq      4$           ;
1824 023466              printf   #pb11w1      ;Unexpected cmd response in time out loop
1825 023506 000137 037404              jmp      unkwn        ;error handler
1826
1827              ;Timed out command recieved but Get Dust Status is s
till in Queue
1828 023512 013737 002540 002452 4$:      mov      LSTCRN,cmdpak ;load timed out command values for RSPCHK routine
1829 023520 013737 002542 002462      mov      LSTCMD,cmdpak+10 ;load timed out command values for RSPCHK routine
1830 023526 005037 002540              clr      LSTCRN       ;if it is the timeout command clear LAST CRN registe
r
1831 023532 004737 030654              jsr      pc,RSPCHK    ;go check the command
1832 023536 012737 140000 002530      mov      #140000,RSPRNG+2 ;PORT OWNERSHIP BIT.
1833 023544 000137 022760              jmp      POLLW        ;go wait for GETDUST interupt

```







Global subroutines

```

1949 024210          ERRDF  4,DF2          ; DEVICE FATAL wrong step bit set after interrupt
:350 024220          Printf #pb1,r3,(r4) ; Expected SA step bit xxxxx, received in SA yyyyyy
1951 024244 000137 037420 jmp      dropunt ;drop unit and go on
1952
1953 024250          GOBIT:
1954 024250 012714 000001      mov      #1,(r4)          ;Controller is NOW INITIALIZED
1955 024254 012700 177777      mov      # 1,r0
1956 024260 000240          1$:      nop
1957 024262 077002          sob      r0,1$          ;waste just a little time so program can terminate
1958 024264          GDScmd:
1959 024264          GETDUST
024264 032737 100000 002534 GDS2:  bit      #bit15,cmdrng+2 ;Do a Get Dust Status command start things off
024272 001374          bne      GDS2           ;test ownership of ring make sure we own it
024274 012737 000016 002446      mov      #14.,cmdlen    ;if we don't own it wait until we do
024302 112737 000000 002450      movb    #0,cmdlen+2     ;load lenght of packet to be send
024310 112737 000002 002451      movb    #dup.id,cmdlen+3 ;load msg type and credit
024316 005237 002452          inc      cmdpak         ;load DUP connection ID
024322 005037 002454          clr      cmdpak+2       ;load new CRN
024326 005037 002456          clr      cmdpak+4
024332 005037 002460          clr      cmdpak+6
024336 012737 000001 002462      mov      #op.gds,cmdpak+10 ;load up opcode
024344 005037 002464          clr      cmdpak+12     ;no modifiers

024350 012777 024412 155750      mov      #RFD2,@vector   ;New vector place
024356 012737 002352 002526      mov      #rsppak,rsprng ;load response packet area into ring
024364 012737 002452 002532      mov      #cmdpak,cmdrng ;load command packet area into ring
024372 012737 140000 002530      mov      #140000,RSPRNG+2 ;Port ownership bit.
024400 012737 100000 002534      mov      #bit15,CMDRNG+2
024406 004737 022760          jsr      pc,POLLWT      ;Go to poll and wait routine.

;*****

024412          RFD2:
024412 062706 000006          add      #6,sp           ;Intr to here.
024416 012777 032650 155702      mov      #intsrv,@vector ;fix stack for interrupt (4), pollwt subrtn (2)
024424 004737 030654          jsr      pc,RSPCHK      ;Change vector
                                ;Go to routine that will check on
                                ;the response recvd from the mut.
                                ;it will check the cmd ref
                                ;num, the endcode and status.
1960 024430 132737 000010 002371      bitb    #bit3,rsppak+17 ;is this server active already
1961 024436 001467          beg     dnint           ;branch to Execute Local Program
1962 024440          ERRSOFT 3,SFT0       ;Soft Error "already active" will do an ABORT cmd
1963 024450          ABRT
024450 032737 100000 002534 ABRT3: bit      #bit15,cmdrng+2 ;Doing an ABRT do get into 'dle state
024456 001374          bne      ABRT3         ;test ownership of ring make sure we own it
024460 012737 000016 002446      mov      #14.,cmdlen    ;if we don't own it wait until we do
024466 112737 000000 002450      movb    #0,cmdlen+2     ;load lenght of packet to be send
024474 112737 000002 002451      movb    #dup.id,cmdlen+3 ;load msg type and credit
024502 005237 002452          inc      cmdpak         ;load DUP connection ID
024506 005037 002454          clr      cmdpak+2       ;load new CRN
024512 005037 002456          clr      cmdpak+4
024516 005037 002460          clr      cmdpak+6
024522 012737 000006 002462      mov      #op.abrt,cmdpak+10 ;load up opcode
024530 005037 002464          clr      cmdpak+12     ;no modifiers

024534 012777 024576 155564      mov      #RFD3,@vector   ;New vector place
024542 012737 002352 002526      mov      #rsppak,rsprng ;load response packet area into ring

```

Global subroutines

024550	012737	002452	002532	mov	#cmdpak,cmdrng	;load command packet area into ring
024556	012737	140000	002530	mov	#140000,RSPRNG+2	;Port ownership bit.
024564	012737	100000	002534	mov	#bit15,CMDRNG+2	
024572	004737	022760		jsr	pc,POLLWT	;Go to poll and wait routine.

\*\*\*\*\*

024576				RFD3:		;Intr to here.
024576	062706	000006		add	#6,sp	;fix stack for interrupt (4), pollwt subrtn (2)
024602	012777	032650	155516	mov	#intsrvc,@vector	;Change vector
024610	004737	030654		jsr	pc,RSPCHK	;Go to routine that will check on ;the response recvd from the mut. ;it will check the cmd ref ;num, the endcode and status.

1964	024614	000623		br	GDScmd	;branch back to make sure not busy
1965	024616			DNINT:		
1966	024616	000207		rts	pc	
1967						

Global subroutines

1969  
1970  
1971  
1972  
1973  
1974  
1975  
1976  
1977  
1978  
1979  
1980  
1981  
1982

024620			
024620	032737	100000	002534
024626	001374		
024630	012737	000050	002446
024636	112737	000000	002450
024644	112737	000002	002451
024652	005037	002454	
024656	005037	002456	
024662	005037	002460	
024666	012737	000002	002462
024674	012737	000000	002464
024702	012737	001204	002466
024710	005037	002470	
024714	012737	025270	002472
024722	005037	002474	
024726	005037	002476	
024732	005037	002500	
024736	005037	002502	
024742	005037	002504	
024746	005037	002506	
024752	005037	002510	
024756	005037	002512	
024762	005037	002514	
024766	005037	002516	
024772	005037	002520	
024776	012777	025040	155322
025004	012737	002352	002526
025012	012737	002452	002532
025020	012737	140000	002530
025026	012737	100000	002534
025034	004737	022760	

```

*****
;
;           AUTOSizer
;   This routine runs the Execute Supplied program called AUTOSZ
;   This program is downline loaded into the controller to determine
;   which drive is out in the controller. First you must tell which drive
;   you want to format. After listing the drive number the program will load
;   the program and figure which DEC drive it is and which UIT to load into
;   the disk controller for the format program.
;
*****

```

```

AUTOSizer:
  excSUPprg           ;downline load the program autosz
ESP4:  bit            #bit15,cmdrng+2      ;test ownership of ring make sure we own it
      bne            ESP4                ;if we don't own it wait until we do
      mov            #50,cmdlen          ;load length of packet to be send
      movb           #0,cmdlen+2        ;load msg type and credit value
      movb           #dup.id,cmdlen+3   ;load DUP connection ID
      clr            CMDpak+2
      clr            CMDpak+4
      clr            CMDpak+6
      mov            #op.esp,CMDpak+10   ;load up opcode
      mov            #0,CMDpak+12       ;no stand alone modifier
      mov            #<autoend-autosz>,cmdpak+14 ;load length of prg into buffer
      clr            cmdpak+16
      mov            #autosz,cmdpak+20   ;starting address of downline load prg
      clr            CMDpak+22
      clr            CMDpak+24
      clr            CMDpak+26
      clr            CMDpak+30
      clr            CMDpak+32
      clr            CMDpak+34         ;overlay buffer descriptor
      clr            CMDpak+36
      clr            CMDpak+40
      clr            CMDpak+42
      clr            CMDpak+44
      clr            CMDpak+46
      mov            #RFD4,@vector      ;New vector place
      mov            #rsppek,rsprng     ;load response packet area into ring
      mov            #cmdpak,cmdrng    ;load command packet area into ring
      mov            #140000,RSPRNG+2 ;Port ownership bit.
      mov            #bit15,CMDRNG+2
      jsr            pc,POLLWT         ;Go to poll and wait routine.

```

```

*****
RFD4:
  add            #6,sp
  mov            #intsrv,@vector
  jsr            pc,RSPCHK
;Intr to here.
;fix stack for interrupt (4), pollwt subrtn (2)
;Change vector
;Go to routine that will check on
;the response recvd from the mut.
;get results of auto size

```

1983	025056		
	025056	032737	100000
	025064	001374	
	025066	012737	000034
	025074	112737	000000
	025102	112737	000002
	025110	005237	002452

```

Recvdata  #msg,#msglen
RCD5:  bit            #bit15,cmdrng+2      ;test ownership of ring make sure we own it
      bne            RCD5                ;if we don't own it wait until we do
      mov            #34,cmdlen          ;load length of packet to be send
      movb           #0,cmdlen+2        ;load msg type and credit
      movb           #dup.id,cmdlen+3   ;load DUP connection ID
      inc            cmdpak             ;load new CRN

```

## Global subroutines

```

025114 005037 002454      clr      cmdpak+2
025120 005037 002456      clr      cmdpak+4
025124 005037 002460      clr      cmdpak+6
025130 012737 000005 002462      mov      #op.rec,cmdpak+10      ;load up opcode
025136 005037 002464      clr      cmdpak+12      ;no modifiers
025142 012737 000014 002466      mov      #msglen,cmdpak+14
025150 005037 002470      clr      cmdpak+16
025154 012737 026460 002472      mov      #msg,cmdpak+20      ;load address of buffer descriptor
025162 005037 002474      clr      cmdpak+22
025166 005037 002476      clr      cmdpak+24
025172 005037 002500      clr      cmdpak+26
025176 005037 002502      clr      cmdpak+30
025202 005037 002504      clr      cmdpak+32

025206 012777 025250 155112      mov      #RFD5,@vector      ;New vector place
025214 012737 002352 002526      mov      #rsppak,rsprng      ;load response packet area into ring
025222 012737 002452 002532      mov      #cmdpak,cmdrng      ;load command packet area into ring
025230 012737 140000 002530      mov      #140000,RSPRNG+2      ;Port ownership bit.
025236 012737 100000 002534      mov      #b't15.CMDRNG+2
025244 004737 022760      jsr      pc,PULLWT      ;Go to poll and wait routine.

;*****

025250      RFD5:      ;Intr to here.
025250 062706 000006      add      #6,sp      ;fix stack for interrupt (4), pollwt subrtn (2)
025254 012777 032650 155044      mov      #intsrv,@vector      ;Change vector
025262 004737 030654      jsr      pc,RSPCHK      ;Go to routine that will check on
                                ;the response recvd from the mut.
                                ;it will check the cmd ref
                                ;num, the endcode and status.
                                ;return

1984 025266 000207      rts      pc

```

Global subroutines

1986  
1987  
1988  
1989  
1990  
1991  
1992  
1993  
1994  
1995  
1996  
1997  
1998  
1999  
2000  
2001  
2002  
2003  
2004  
2005  
2006  
2007  
2008  
2009  
2010  
2011  
2012  
2013  
2014  
2015  
2016  
2017  
2018  
2019  
2020  
2021  
2022  
2023  
2024  
2025  
2026  
2027  
2028  
2029  
2030  
2031  
2032  
2033  
2034  
2035  
2036  
2037  
2038  
2039  
2040  
2041  
2042

025270  
001204  
000000  
000000  
000000  
101 125 124

.sbt1 AUTOSZ

\*\*\*\*\*  
; AUTOSZ  
; This is the actual down line loaded code which is placed in  
; the RAM inside the RQDX3 controller. This code figures out the  
; cylinder size of the drive. From the cylinder size we can determine  
; which drive it is. If the drive is a winchester we will step the drive  
; into the inner most cylinder. The inner most cylinder for most drives  
; is the parking cylinder.

;\* AUTOSZ Determine Drive Type and Size

; Input: None.

; Output: A Special Type Message:

+-----+  
} Special Msg #10 (decimal) } +00  
+-----+  
} Status } +02  
+-----+  
} Innermost Cylinder for Unit 0 } +04  
+-----+  
} Innermost Cylinder for Unit 1 } +06  
+-----+  
} Innermost Cylinder for Unit 2 } +10  
+-----+  
} Innermost Cylinder for Unit 3 } +12  
+-----+

where, status = 0 for success,  
1 for UDC never went done,  
2 for UDC never interrupted,  
3 for Seek Failed

cylinder = 3 for RX33 Floppy  
2 for RX50 Floppy  
0 to 2048 for Winnie,  
-1 for Non existent unit

; Note: The Unit Numbers will correspond to the numbers that the Host  
; would use (i.e., not necessarily the DRVSEL numbers). Thus,  
; Winnies will always precede Floppies and "null devices".

\*\*\*\*\*

AUTOSZ:  
.dsable AMA ;Byte count low TEST HEADER  
.word <AUTOend-AUTOSZ> ;byte count high  
.word 0 ;overlay low  
.word 0 ;overlay high  
.word 0 ;6 character asciz name  
.ascii /AUTOSZ/

## AUTOSZ

```

025303      117      123      132
2043
2044 025306 000001      .even
2045 025310      000      .word 1 ;version number
2046 025311      177      .byte 0 ;flags
2047 025312 000240      .byte 177 ;timeout
2048
2049 025314      000240      nop ;start down line loaded test
2050
2051
2052      ; Executable Code Starts Here
2053
2054 025316 106427 000340      mtps #ps7 ; Set up our own interrupts handlers
2055 025322 005037 140004      clr @#w$fp1 ; clear the leds
2056 025326 013746 100002      mov @#i$udc, (sp) ; Save the MSCP handlers - UDC
2057 025332 013746 100006      mov @#i$clk, (sp) ; ... Clock
2058 025336 013746 100016      mov @#i$sec, (sp) ; ... Sector
2059
2060      ; Taken from RQDX3.MAC m$'n'it code:
2061
2062 025342 112737 000000 140022      movb #op.res,@#w$cmd ; reset the smc9224 chip
2063 025350 112737 000111 140022      movb #op.srp+11,@#w$cmd ; enable interrupts
2064 025356 112737 000040 140020      movb #40,@#w$dat ;
2065 025364 005067 001064      clr s$$bug ; assume the bug 's not present
2066 025370 032737 020000 140006      b't #20000,@#r$fps ; 's the ECO wire there?
2067 025376 001415      beq sizset ; definitely not
2068 025400 112737 000001 140022      movb #op.dd,@#w$cmd ; deselect all drives
2069 025406 012700 001000      mov #1000,r0 ; wait for a bit
2070
2071      sizwt:
2072 025412 005300      dec r0 ; ...
2073 025414 001376      bne sizwt ; ...
2074
2074 025416 032737 020000 140006      b't #20000,@#r$fps ; is the ECO wire there?
2075 025424 001002      bne s'zset ; nope
2076 025426 005267 001022      inc s$$bug ; say it is
2077
2078      sizset:
2079 025432 010700      mov pc,r0 ; Set up handlers
2080 025434 062700 000670      add #<s$$udc-.>,r0 ; ...
2081 025440 010037 100002      mov r0,@#i$udc ; Use our own udc handler
2082 025444 010700      mov pc,r0 ; ...
2083 025446 062700 000716      add #<s$$rti .>,r0 ;
2084 025452 010037 100006      mov r0,@#i$clk ; Make clock interrupt rti
2085 025456 010037 100016      mov r0,@#i$sec ; Make sector interrupt rti
2086 025462 106427 000000      mtps #ps0 ; Make it good
2087
2088      ; Go Size the Drives
2089
2090 025466 010146      mov r1, (sp) ; Save Registers
2091 025470 010246      mov r2,-(sp) ; Save Registers
2092 025472 010346      mov r3, (sp) ;
2093 025474 010702      mov pc,r2 ; Point to Unit Descriptor Table
2094 025476 062702 000766      add #<msgdat+2> .,r2 ; ...
2095 025502 010200      mov r2,r0 ;
2096 025504 012703 000004      mov #4.,r3 ; Initialize all Unit Descriptors
2097 025510      siznon:
2098 025510 012720 177777      mov #-1.,(r0)+ ; ... to "Non-Existant Unit"

```



## AUTOSZ

```

2099 025514 077303          sob      r3,siznon          ; ...
2100                                     ;
2101 025516 012703 000002    mov      #2.,r3           ; Set Drive Count to logical unit 0
2102                                     ;
2103 025522                sizlop::          ; ** Loop Until We Get All of Them **
2104                                     ; **Check if it is a Winnie**
2105 025522 012737 000010 140002    mov      #bit3,@#rw$pll   ; Set up Pllctl Csr
2106 025530 012737 000104 140022    mov      #op.srp+4,@#w$cmd ; Set up UDC registers
2107 025536 005037 140020          clr      @#w$dat          ; ... Head 0
2108 025542 005037 140020          clr      @#w$dat          ; ... Cylinder 0
2109 025546 012737 000110 140022    mov      #op.srp+8.,@#w$cmd ; ...
2110 025554 012737 000300 140020    mov      #rd.mode,@#w$dat  ; ... Set mode for winnie
2111 025562 010300                mov      r3,r0           ; Select the Drive
2112 025564 062700 000044          add      #op.srd,r0       ; ... op.sd.rd=44
2113 025570 004767 000572          jsr      pc,doudc        ; Do UDC command
2114 025574 005700                tst      r0              ; Okay?
2115 025576 001402                beq      sizfps          ; Nope, something 's screwed up
2116 025600 000167 000416          jmp      sizend
2117 025604                sizfps:
2118 025604 032737 140000 140006    bit      #bit14+bit15,@#r$fps ; Winnie?
2119 025612 001121                bne      s'zwin          ; Yes, go set cylinder count
2120                                     ;
2121 025614                sizflp:
2122 025614 012737 000011 140002    mov      #bit0+bit3,@#rw$pll ; ** Check if it is a Floppy **
2123 025622 112737 000107 140022    movb     #op.srp+7,@#w$cmd  ; Set Pllctl CSR
2124 025630 112737 000367 140020    movb     #retry,@#w$dat     ; Set up UDC registers
2125 025636 010300                mov      r3,r0           ; ... retry = 367
2126 025640 062700 000054          add      #op.srx,r0       ; Select the Drive
2127 025644 004767 000516          jsr      pc,doudc        ; ... op.sd.rx=54
2128 025650 005700                tst      r0              ; Do UDC command
2129 025652 001123                bne      sizend          ; Okay?
2130 025654 005004                clr      r4              ; Nope, something is screwed up
2131                                     ; Step counter
2132 025656                steprx:
2133 025656 020427 000240          cmp      r4,#160.         ; ** Step In & Out Until Track 0 Found **
2134 025662 002034                bge      sizrx           ; How many times have we step?
2135 025664 112737 000111 140022    movb     #op.srp+9.,@#w$cmd ; Enough?
2136 025672 132737 000020 140010    bitb     #bit4,@#r$dat    ; Set up UDC registers
2137 025700 001025                bne      sizrx           ; At track 0?
2138 025702 020427 000120          cmp      r4,#80.         ; Yes, then go check Floppy type
2139 025706 002412                blt      stepout         ; Is step counter >= 80 ?
2140 025710 020427 000202          cmp      r4,#130.        ;
2141 025714 003007                bgt      stepout         ; Is step counter <= 130 ?
2142 025716 012700 000005          mov      #op.sil,r0      ; Step in one track
2143 025722 004767 000440          jsr      pc,doudc        ; Do UDC command
2144 025726 005700                tst      r0              ; Okay?
2145 025730 001134                bne      sizend          ; Nope, something is screwed up
2146 025732 000406                br       stepmore
2147 025734                stepout:
2148 025734 012700 000007          mov      #op.soi,r0      ; Step out one track
2149 025740 004767 000422          jsr      pc,doudc        ; Do UDC command
2150 025744 005700                tst      r0              ; Okay?
2151 025746 001125                bne      sizend          ; Nope, something is screwed up
2152 025750                stepmore:
2153 025750 005204                inc      r4              ; Increment step counter
2154 025752 000741                br       steprx         ; ** Bottom of find track 0 loop **
2155

```

AUTOSZ

```

2156 025754          sizrx:          ; ** Check Floppy type RX50/RX33 **
2157 025754 112737 000111 140022      movb   #op.srp+9.,@#w$cmd      ; Set up UDC registers
2158 025762 132737 000020 140010      bitb   #bit4,@#r$dat          ; At track 0?
2159 025770 001506          beq     sizdrv                 ;
2160 025772 112737 000104 140022      movb   #op.srp+4,@#w$cmd      ; Set up UDC registers
2161 026000 112737 000001 140020      movb   #1,@#w$dat            ; .. Head =1
2162 026006 010300          mov     r3,r0                 ; Select the Drive
2163 026010 062700 000054          add    #op.srx,r0            ; ... op.sd.rx=54
2164 026014 004767 000346          jsr    pc,doudc              ; Do UDC command
2165 026020 005700          tst    r0                     ; Okay?
2166 026022 001077          bne    sizend                ; Nope, something is screwed up
2167 026024 112737 000111 140022      movb   #op.srp+9.,@#w$cmd      ; Set up UDC registers
2168 026032 132737 000020 140010      bitb   #bit4,@#r$dat          ; At track 0?
2169 026040 001003          bne    sizrx3                ; No, it's an RX50
2170 026042 012712 000002          mov    #2,(r2)                ; Mark it as an RX50
2171 026046 000455          br     sizrd                  ;
2172 026050          sizrx3:
2173 026050 012712 000003          mov    #3,(r2)                ; Yes, mark it as an RX33
2174 026054 000452          br     sizrd                  ; Go do next drive
2175 026056          sizwin:
2176 026056 005012          clr    (r2)                   ; It's a Winnie Set Count to 0
2177
2178 026060 012700 000007          mov    #op.sol,r0            ; Step out one track
2179 026064 004767 000276          jsr    pc,doudc              ; Do UDC command
2180 026070 005700          tst    r0                     ; Okay?
2181 026072 001053          bne    sizend                ; Nope, something is screwed up
2182
2183 026074 012700 000003          mov    #ersek0,r0            ; Assume that seek to 0 failed
2184 026100 112737 000111 140022      movb   #op.srp+9.,@#w$cmd      ; At Cylinder 0?
2185 026106 132737 000020 140010      bitb   #bit4,@#r$dat          ; ...
2186 026114 001442          beq    sizend                ; Nope, something's wrong
2187
2188 026116          sizin:
2189 026116 005212          inc    (r2)                   ; ** Step In Unt'l Track 0 Found **
2190 026120 012700 000005          mov    #op.sil,r0            ; Up Cylinder Count
2191 026124 004767 000236          jsr    pc,doudc              ; Step In One Cylinder
2192 026130 005700          tst    r0                     ; Do UDC Command
2193 026132 001033          bne    sizend                ; Okay?
2194
2195 026134 112737 000111 140022      movb   #op.srp+9.,@#w$cmd      ; At Cylinder 0?
2196 026142 132737 000020 140010      bitb   #bit4,@#r$dat          ; If so, skip to bump up
2197 026150 001003          bne    parkit                ; ... descriptors
2198
2199 026152 021227 004000          cmp    (r2),#2048.            ; SMC Cylinder Limit Reached?
2200 026156 002757          blt    sizin                  ; ** Bottom of Step In Loop **
2201
2202 026160          parkit:
2203 026160 011201          mov    (r2),r1                ; step in, to inner most cylinder
2204 026162 005301          dec    r1                     ; get total number of cylinders
2205 026164 012700 000005          mov    #op.sil,r0            ; we want one less then recalibrate cylinder
2206 026170 004767 000172          jsr    pc,doudc              ; Step In One Cylinder
2207 026174 005700          tst    r0                     ; Do UDC Command
2208 026176 001011          bne    sizend                ; Okay?
2209 026200 077107          sob    r1,1$                 ; Nope, something is screwed up
2210          sizrd:
2211
2212 026202 062702 000002          add    #untdsz,r2            ; ** This was a Winnie **
                                     ; Bump Pointer to Next Unit Descriptor

```

## AUTOSZ

```

2213
2214 026206          sizdrv:          ; ** Check Next Drive **
2215 026206 005203   inc      r3          ; Up Drive Count
2216 026210 020327 000005   cmp      r3,#5       ; All 4 Drives Checked?
2217 026214 003002   bgt      sizend      ; ...
2218 026216 000167 177300   jmp      sizlop      ; ** Bottom of Loop **
2219
2220 026222          sizend:          ; ** Send Status and Table **
2221 026222 010067 000234   mov      r0,msgdat   ; Save status
2222 026226 012700 000001   mov      #op.dd,r0   ; Deselect Drive
2223 026232 004767 000130   jsr      pc,doudc    ; ...
2224 026236 012603   mov      (sp)+,r3    ; Pop
2225 026240 012602   mov      (sp)+,r2    ; ...
2226 026242 012601   mov      (sp)+,r1    ; ...
2227 026244 106427 000340   mtps    #ps7        ; Put the MSCP Handlers Back
2228 026250 012637 100016   mov      (sp)+,@#i$sec ; ...
2229 026254 012637 100006   mov      (sp)+,@#i$clk ; ...
2230 026260 012637 100002   mov      (sp)+,@#i$udc ; ...
2231 026264 106427 000000   mtps    #ps0        ; ...
2232
2233 026270          sizexi::          ; ** Okay, talk to the Host **
2234
2235          ;PutData,msg,msglen  Send Response to Host
2236
2237 026270 010700   mov      pc,r0       ;figure the relative address
2238 026272 062700 000166   add      #msg-.,r0   ;... of the buffer
2239 026276 012746 000014   mov      #msglen,(sp) ;load lenght in bytes of the buffer
2240 026302 010046   mov      r0,-(sp)    ;load relative address of the buffer
2241 026304 013746 000146   mov      @#146,(sp)  ;load location of routine in microcode
2242 026310 004736   jsr      pc,@(sp)+   ;call Put Data routine in Ucode
2243 026312 022626   cmp      (sp)+,(sp)+ ;fix stack
2244
2245          ; Terminate Supplied Program
2246
2247 026314 013700 000142   mov      @#142,r0    ;load location of routine in microcode
2248 026320 004710   jsr      pc,(r0)     ;call Terminate routine in Ucode
2249 026322 000207   rts      pc          ; ...

```

## AUTOSZ

```

2251
2252 ;+
2253 ; UDC Interrupt Handler
2254 ; Taken from RQDX3.MAC m$udc code:
2255 ;-
2256
2257 026324 s$$udc:: ; UDC Handler
2258 026324 005767 000124          ; 's the ECO wire there?
2259 026330 001404          ; nope
2260 026332 032737 020000 140006 bit #20000,@#r$fps ; 's the 9224 interrupt line set?
2261 026340 001011          ; if not, must be a bogus interrupt
2262
2263 026342 s$$udi: ; ...
2264 026342 113746 140012          ; get interrupt status
2265 026346 142716 000035          ; clear bits of no interest
2266 026352 122726 000240          ; val'd status?
2267 026356 001002          ; no, it's a bogus interrupt
2268 026360 005267 000072          ; set the flag
2269
2270 ;+
2271 ; Return from Interrupt
2272 ;
2273
2274 026364 s$$rti:: ;;; ...
2275 026364 000002          ;;; just quit
2276
2277 ;+
2278 ; DOUDC - Do a UDC Command
2279 ;
2280 ; This routine sends a commands and waits an interrupt or
2281 ; until timer expires.
2282 ;
2283 ; Input:      r0      - command
2284 ; Output:     r0      - 0 for success, non zero for failure
2285 ;-
2286
2287          msec = 30.*132.          ; Max Step Rate + some *
2288                                     ; loop for 7.5 MHz T11 clock
2289
2290 026366 doudc:: ; ** Do a UDC command **
2291 026366 010146          ; save r1
2292 026370 005067 000062          ; Clear udc flag (interrupt pending)
2293 026374 010037 1+0022          ; Send the command
2294 026400 012700 004000          ; Set the rom timer (max cylinders)
2295
2296 026404 mswait: ; ** Wait **
2297 026404 012701 007570          ; set one millisecond counter
2298 026410 ms'n: ; ** Top of Inner Loop **
2299 026410 005767 000042          ; 3.60 udc interrupted
2300 026414 001005          ; 1.60 out if udc interrupted
2301 026416 077104          ; 2.40 Total: 7.60 @7.5MHz=>
2302                                     ; 8.5457 @6.67MHz
2303 026420          ; ** Bottom of Outer Loop **
2304 026422 012700 000002          ; Never Interrupted
2305 026426 000410          ; ...
2306
2307 026430 msend: ; ** Interrupt Happened **

```

N4

AUTOSZ

```
2308 026430 012700 000001      mov    #erudon,r0      ; Assume Never Done
2309 026434 013701 140012      mov    @#r$cmd,r1     ; Get the return status
2310 026440 032701 000040      bit    #bit5,r1      ; All done yet?
2311 026444 001401              beq    douret         ; If so, pop out of this
2312                          ;
2313 026446 005000              clr    r0            ; Assume everything's ok
2314                          ;
2315                          douret: ; ** Return **
2316 026450 012601      mov    (sp)+,r1
2317 026452 000207      rts    pc            ; Back to caller
```

SIZER supplied Program Data

```
2319 .sbttl SIZER Supplied Program Data
2320
2321 ; .psect cldata
2322
2323 ; Special Stuff
2324
2325 026454 s$$bug: .blkw 1 ; ECO Wire
2326 026456 s$$flag: .blkw 1 ; UDC flag
2327
2328 ; Packet Area
2329
2330 026460 012 140 msg:: .byte 10...b.spl ; Final Message
2331 026462 msgdat: .blkw 5. ; Status and Unit Descriptor Table
2332 000014 msglen = : msg ; Message Length (Byte Count)
2333 000002 untdsz = 2. ; Unit Descriptor Length
2334
2335 .enable AMA
2336 026474 AUTOend:
```

SIZER Supplied Program Data

```

2338
2339 ;*****
2340 ;           AUTOdisplay
2341 ;           This routine will display the results of the autosizers
2342 ;           findings. It will say weather the autosizer errored or not and
2343 ;           what drives it found.
2344 ;
2345 ;*****
2346
2347 026474      123727 026461 000140  AUTOdis:      cmpb    msg+1, #.b.spl      ;check 'f Special Message
2348 026474      001401      beq     1$                ;'f not then no 'nfo to print
2349 026502      000207      rts     pc                ;so just return
2350 026504
2351
2352 026506      123727 026460 000012  1$:      cmpb    msg, #10.         ;
2353 026514      001401      beq     2$                ;check message number
2354 026516      000207      rts     pc                ;return if msg number doesn t match
2355 026520
2356 026520      005737 026462      tst     msg+2             ;test complet'on status of Autosizer
2357 026524      001457      beq     24$              ;if zero no error report the findings
2358
2359
2360 ; Autos'zer Failure Code
2361 026526      023727 026462 000001  printb  #ASMSG3, msg+2     ; Print Autosizer Failure Code
2362 026552      001010      cmp     msg+2, #1         ; Is it a UDC never done error ?
2363 026560      001010      bne    11$              ; No, check for next code
2364 026562      023727 026462 000002  11$:    printb  #ASMSG4           ; Yes, Tell error type
2365 026602      001010      cmp     msg+2, #2         ; Is 't a UDC never interrupted error ?
2366 026610      001010      bne    12$              ; No, check for next code
2367 026612      023727 026462 000003  12$:    printb  #ASMSG5           ; Yes, Tell error type
2368 026632      001010      cmp     msg+2, #3         ; Is it a seek error ?
2369 026640      001010      bne    13$              ; No, go reinitialize ctrl
2370 026642      000207      printb  #ASMSG6           ; Yes, Tell error type
2371 026662
2372 026662      000207      rts     pc                ;return
2373
2374 ; Autosizer Findings
2375 026664      012701 026464 000000  24$:    printb  #ASMSG1           ; print Autosizer findings
2376 026704      005002      mov     #msg+4, r1        ; first cylinder entry
2377 026710      022711 177777 26$:    clr     r2                ; Start with unit number zero
2378 026712      001013      cmp     #-1., (r1)        ; Is unit Non-existent ?
2379 026716      001013      bne    61$              ; No, check for RX50
2380 026720      000137 027522 61$:    printb  #ASMSG7, R2      ; Yes, tell 't is non-existent
2381 026742      022711 000002  jmp     20$              ; ...
2382 026746      001013      cmp     #2., (r1)        ; Is unit an RX50 ?
2383 026752      001013      bne    62$              ; No, check for RX33
2384 026754      000137 027522 62$:    printb  #ASMSG8, R2      ; Yes, tell it is an RX50
2385 026776      022711 000003  jmp     20$              ; ...
2386 027002      001013      cmp     #3., (r1)        ; Is unit an RX33 ?
2387 027006      000137 027522 63$:    bne    63$              ; No, then it is a Winchester
2388 027010      000137 027522  printb  #ASMSG9, R2      ; Yes, tell 't is RX33
2389 027032      000137 027522  jmp     20$              ;
2390 027036      000137 027522 63$:    ; It is a WINCHESTER
2391 027036      000137 027522  printb  #ASMSG2, r2, (r1) ; Tell it is a Winchester with so many cylinder
2392 027036
2393
2394 027062      71$:

```

SIZER Supplied Program Data

t	2395	027062	023711	003102	cmp	UIT0+UITsiz-2,(r1)	;if cylinder # equals UIT table # this is the correc	
	t UIT table							
	2396	027066	001403		beq	710\$		
t	2397	027070	023711	003100	cmp	UIT0+UITsiz 4,(r1)	;if cylinder # equals UIT table # this is the correc	
	t JIT table							
	2398	027074	001012		bne	72\$		
	2399	027076		710\$:	printb	#DrvTx0	:1 rd51	
	2400	027116	000137	027522	jmp	20\$		
	2401							
t	2402	027122	023711	003206	72\$:	cmp	UIT1+UITsiz-2,(r1)	;if cylinder # equals UIT table # this is the correc
	t UIT table							
	2403	027126	001403		beq	720\$		
t	2404	027130	023711	003204	cmp	UIT1+UITsiz-4,(r1)	;if cylinder # equals UIT table # this is the correc	
	t UIT table							
	2405	027134	001011		bne	73\$		
	2406	027136		720\$:	printb	#DrvTx1	:1 rd52	
	2407	027156	000561		br	20\$		
	2408							
t	2409	027160	023711	003312	73\$:	cmp	UIT2+UITsiz-2,(r1)	;if cylinder # equals UIT table # this is the correc
	t UIT table							
	2410	027164	001403		beq	730\$		
t	2411	027166	023711	003310	cmp	UIT2+UITsiz 4,(r1)	;if cylinder # equals UIT table # this is the correc	
	t UIT table							
	2412	027172	001011		bne	74\$		
	2413	027174		730\$:	printb	#DrvTx2	:1 rd52	
	2414	027214	000542		br	20\$		
	2415							
t	2416	027216	023711	003416	74\$:	cmp	UIT3+UITsiz 2,(r1)	;if cylinder # equals UIT table # this is the correc
	t UIT table							
	2417	027222	001403		beq	740\$		
t	2418	027224	023711	003414	cmp	UIT3+UITsiz 4,(r1)	;if cylinder # equals UIT table # this is the correc	
	t UIT table							
	2419	027230	001011		bne	75\$		
	2420	027232		740\$:	printb	#DrvTx3	:1 rd53	
	2421	027252	000523		br	20\$		
	2422							
t	2423	027254	023711	003522	75\$:	cmp	UIT4+UITsiz-2,(r1)	;if cylinder # equals UIT table # this is the correc
	t UIT table							
	2424	027260	001403		beq	750\$		
t	2425	027262	023711	003520	cmp	UIT4+UITsiz 4,(r1)	;if cylinder # equals UIT table # this is the correc	
	t UIT table							
	2426	027266	001011		bne	76\$		
	2427	027270		750\$:	printb	#DrvTx4	:1 rd54	
	2428	027310	000504		br	20\$		
	2429							
t	2430	027312	023711	003626	76\$:	cmp	UIT5+UITsiz-2,(r1)	;if cylinder # equals UIT table # this is the correc
	t UIT table							
	2431	027316	001403		beq	760\$		
t	2432	027320	023711	003624	cmp	UIT5+UITsiz-4,(r1)	;if cylinder # equals UIT table # this is the correc	
	t UIT table							
	2433	027324	001011		bne	77\$		
	2434	027326		760\$:	printb	#DrvTx5	:1 rd31	
	2435	027346	000465		br	20\$		
	2436							
t	2437	027350	023711	003732	77\$:	cmp	UIT6+UITsiz 2,(r1)	;if cylinder # equals UIT table # this is the correc
	t UIT table							
	2438	027354	001403		beq	770\$		
t	2439	027356	023711	003730	cmp	UIT6+UITsiz-4,(r1)	;if cylinder # equals UIT table # this is the correc	
	t UIT table							
	2440	027362	001011		bne	78\$		
	2441	027364		770\$:	printb	#DrvTx6	:1 rd	
	2442	027404	000446		br	20\$		
	2443							
t	2444	027406	023711	004036	78\$:	cmp	UIT7+UITsiz-2,(r1)	;if cylinder # equals UIT table # this is the correc
	t UIT table							
	2445	027412	001403		beq	780\$		



```

2447 027420 001011
2448 027422
2449 027442 000427
2450
2451 027444 023711 004142 79$: cmp UITdf+UITsiz-2,(r1) ;if cylinder # equals UIT table # this is the correc
t UIT table
MAIN MACRO V05.03 Tuesday 10 Jun-86 13:21 Page 25-2 SEQ 0056
SIZER Supplied Program Data
2452 027450 001403 beq 79$
2453 027452 023711 004140 cmp UITdf+UITsiz-4,(r1) ;if cylinder # equals UIT table # this is the correc
t UIT table
2454 027456 001011
2455 027460 790$: printb #DrvTxc ;1 custom rd
2456 027500 000410 br 20$
2457
2458 027502 80$: printb #ASMSGr ;"Unrecognized Drive"
2459
2460 027522 005721 20$: tst (r1)+ ; Point to next unit descriptor
2461 027524 005202 inc r2 ; Set for next unit
2462 027526 020227 000004 cmp r2,#MaxDrv ; Last unit?
2463 027532 001402 beq 27$ ; Yes, exit routine
2464 027534 000137 026712 jmp 26$ ; No, do next unit
2465 027540 000207 27$: rts pc ;
2466
2467 ;*****
2468 ;
2469 ; This routine builds the UIT table or get the UIT table
2470 ; depending who the questions are answered to the manual questions.
2471 ; If the unit is a listed or recognizable drive we will use a prebuilt
2472 ; UIT table. If not we will have to ask all the questions to build
2473 ; a table.
2474 ;
2475 ;*****
2476 027542 BLDUIT:
2477 027542 032737 100000 002336 bit #bit15,untflgs
2478 027550 001402 beq manbld
2479 027552 000137 030060 jmp autobld
2480
2481 027556 manbld: printf #DrvTxa ;print out UIT tables and their related drives
2482 027576 printf #DrvTxb ;UIN Drive
2483 027616 printf #DrvTx0 ;0 rd51
2484 027636 printf #DrvTx1 ;1 rd52
2485 027656 printf #DrvTx2 ;2 etc
2486 027676 printf #DrvTx3 ;3 etc
2487 027716 printf #DrvTx4 ;4
2488 027736 printf #DrvTx5
2489 027756 printf #DrvTx6
2490 027776 printf #DrvTx7
2491 030016 printf #DrvTxc
2492
2493 030036 GMANID unt.nbr,UIN,0,17,0,10,no ;GET Unit identifier number (0 7)
2494 ;PLACE IN bits 0-3.
2495 ;no defaults person must know what Unit Identificati
on number.
2496 030056 000515 br uitloc ;get correct table address into UITadrs
2497
2498 030060 autobld:
2499 030060 013700 002330 mov unit,r0 ;get unit number
2500 030064 006300 asl r0 ;get the byte offset of tbl
2501 030066 012737 000000 002344 1$: mov #0,uin ;pick UIT number 0
2502 030074 023760 003102 026464 cmp UIT0+UITsiz 2,msg+4(r0) ;if cylinder # equals UIT table # this is the correc
t UIT table
2503 030102 001503 beq 2$
2504 030104 012737 000001 002344 mov #1,uin ;pick UIT number 1
2505 030112 023760 003206 026464 cmp UIT1+UITsiz-2,msg+4(r0) ;if cylinder # equals UIT table # this is the correc
t UIT table
2506 030120 001474 beq 2$
2507 030122 012737 000002 002344 mov #2,uin ;pick UIT number 2
2508 030130 023760 003312 026464 cmp UIT2+UITsiz-2,msg+4(r0) ;if cylinder # equals UIT table # this is the correc
t UIT table

```

SIZER Supplied Program Data

```

2509 030136 001465          beq      2$
2510 030140 012737 000003 002344  mov     #3,uin          ;pick UIT number 3
2511 030146 023760 003416 026464  cmp     UIT3+UITsiz 2,msg+4(r0) ;if cylinder # equals UIT table # this is the correc
t UIT table
2512 030154 001456          beq      2$
2513 030156 012737 000004 002344  mov     #4,uin          ;pick UIT number 4
2514 030164 023760 003522 026464  cmp     UIT4+UITsiz-2,msg+4(r0) ;if cylinder # equals UIT table # this is the correc
t UIT table
2515 030172 001447          beq      2$
2516 030174 023760 003520 026464  cmp     UIT4+UITsiz-4,msg+4(r0) ;if cylinder # equals UIT table # this is the correc
t UIT table
2517 030202 001443          beq      2$          ;automatic recal feature of this drive
2518 030204 012737 000005 002344  mov     #5,uin          ;pick UIT number 5
2519 030212 023760 003626 026464  cmp     UIT5+UITsiz 2,msg+4(r0) ;if cylinder # equals UIT table # this is the correc
t UIT table
2520 030220 001434          beq      2$
2521 030222 023760 003624 026464  cmp     UIT5+UITsiz 4,msg+4(r0) ;if cylinder # equals UIT table # this is the correc
t UIT table
2522 030230 001430          beq      2$          ;automatic recal feature of this drive
2523 030232 012737 000006 002344  mov     #6,uin          ;pick UIT number 6
2524 030240 023760 003732 026464  cmp     UIT6+UITsiz 2,msg+4(r0) ;if cylinder # equals UIT table # this is the correc
t UIT table
2525 030246 001421          beq      2$
2526 030250 012737 000007 002344  mov     #7,uin          ;pick UIT number 7
2527 030256 023760 004036 026464  cmp     UIT7+UITsiz 2,msg+4(r0) ;if cylinder # equals UIT table # this is the correc
t UIT table
2528 030264 001412          beq      2$
2529 030266          printb #efunrg          ;"No UIT table suitable for this drive"
2530 030306 000137 037420          jmp     dropunt          ;drop unit and end pass
2531 030312          2$:
2532 030312          uitloc:
2533 030312 012703 003000          mov     #UIT0,r3          ;r3 contains base address of UIT tables
2534 030316 013702 002344          mov     UIN,r2          ;get the correct UIT table address into UITadr regis
ter
2535 030322 001403          beq      11$          ;if UIN=0 then set table to UIT0
2536 030324 062703 000104 10$:          add     #UITsiz,r3          ;else multiply UIT size by the UIN number and add to
base address
2537 030330 077203          sob     r2,10$
2538 030332 010337 002320 11$:          mov     r3,UITadr          ;store the proper address of the UIT table
2539 030336 000137 030344          jmp     cont          ;all done
2540
2541 030342          tblbld:
2542 030342 000240          nop          ;We must build a UNIT INFORMATION TABLE
;try IRQCBI for custom built tables available thru S
DC.
2543 030344 000207          cont: rts     pc          ;go back
2544          ;*****
2545          ;
2546          ; Octal number to ASCII Decimal number
2547          ; r1 = address of ascii decimal data
2548          ; r0 = octal data word
2549          ;*****
2550 030346          OCTASC:
2551 030346 010246          mov     r2,-(sp)
2552 030350 010346          mov     r3,(sp)
2553 030352 005002          clr     r2          ;clear the decimal table pointer
2554 030354 005003 1$:          clr     r3          ;clear decimal digit
2555 030356 005203 2$:          inc     r3          ;increment decimal digit
2556 030360 166200 030420          sub     dectbl(r2),r0          ;subtract a power of ten from accumulator
2557 030364 002374          bge     2$          ;if not negative subtract another
2558 030366 066200 030420          add     dectbl(r2),r0          ;adjust accumulator so positive
2559 030372 005303          dec     r3          ;adjust decimal digit
2560 030374 062703 000060          add     #60,r3          ;convert decimal to ascii
2561 030400 110321          movb   r3,(r1)+          ;mov ascii digit text into buffer
2562 030402 005722          tst     (r2)+          ;increment table pointer
2563 030404 005762 030420          tst     dectbl(r2)          ;check if thats all
2564 030410 001361          bne     1$

```

SIZER Supplied Program Data

2566 030414 012602  
 2567 030416 000207  
 2568 030420  
 2569 030420 023420  
 2570 030422 001750  
 2571 030424 000144  
 2572 030426 000012  
 2573 030430 000001  
 2574 030432 000000  
 2575  
 2576  
 2577  
 2578  
 2579  
 2580  
 2581 030434  
 2582 030434 010546  
 2583 030436 010446  
 2584 030440 010346  
 2585 030442 010246  
 2586 030444 005004  
 2587 030446 005003  
 2588 030450 005002  
 2589 030452 112104  
 2590 030454 001423  
 2591  
 2592  
 2593  
 2594  
 2595  
 2596 030456 162704 000060  
 2597 030462 010346  
 2598 030464 010246  
 2599  
 2600 030466 012705 000003  
 2601 030472 006302  
 2602 030474 006103  
 2603 030476 077503  
 2604  
 2605 030500 006316  
 2606 030502 006166 000002  
 2607  
 2608 030506 000241  
 2609 030510 062602  
 2610 030512 005503  
 2611 030514 062603  
 2612  
 2613 030516 060402  
 2614 030520 005503  
 2615 030522 000753  
 2616  
 2617 030524 010220  
 2618 030526 010310  
 2619  
 2620 030530 012602  
 2621 030532 012603  
 2622 030534 012604

```

mov      (sp)+,r2
rts      pc
dectbl:  .word 10000.
         .word 1000.
         .word 100.
         .word 10.
         .word 1.
         .word 0
;*****
;
;   ASCII DECIMAL numbers to Octal numbers
;   r1 - address of ascii decimal data
;   r0 = address to store octal data low word, high word
;*****
ASCDEC:
mov      r5, (sp)
mov      r4, (sp)
mov      r3, (sp)
mov      r2, -(sp)
clr      r4
clr      r3
clr      r2
3$:      movb  (r1)+,r4
         beq  1$
         cmp  r4,#60
         blt  asklbn
         cmp  r4,#71
         bgt  asklbn
         ;if digit equals null than all done
         ;check for a real number value
         ;wasn't a real number
         ;wasn't a real number
sub      #60,r4
mov      r3, (sp)
mov      r2, (sp)
         ;save accum
         ;accum * 8
4$:      mov  #3,r5
         asl  r2
         rol  r3
         sob  r5,4$
         ;accum*2
         asl  (sp)
         rol  2(sp)
         ; accum*8 + accum*2
         clc
         add  (sp)+,r2
         adc  r3
         add  (sp)+,r3
         ;add present digit to accum*10
         add  r4,r2
         adc  r3
         br   3$
1$:      mov  r2,(r0)+
         mov  r3,(r0)
         ;load lo number
         ;load hi number
         mov  (sp)+,r2
         mov  (sp)+,r3
         mov  (sp)+,r4
         ;restore stack to its orginal
  
```

SIZER Supplied Program Data

```

2623 030536 012605          mov      (sp)+,r5
2624 030540 000207          rts      pc
2625
2626 ;*****
2627 ;
2628 ; This routine types out the ASCII information passed
2629 ; by the disk controller. This ASCII information is
2630 ; contained in the buffer called DATARE and is offset
2631 ; by 1 word. To fake the DRS macro routine a "A" is
2632 ; placed in front of the text.
2633 ;*****
2634
2635 030542          typDUPbuf:
2636 030542 012701 002552          mov      #datare,r1      ;get data area address of ascii info
2637 030546 063701 002366          add      rsppak+14,r1    ;add the number of byte transfered
2638 030552 105021          1$:      clrb     (r1)+         ;put null characters into data buffer after end of ASCII inf
;
2639 030554 020127 002676          cmp      r1,#prgnam     ;
2640 030560 001374          bne     1$              ;we do this to fake out the DRS macro
2641
2642 030562 112737 000045 002552          movb    #45,datare      ;put the "*" delimiter for the DRS macro
2643 030570 112737 000101 002553          movb    #101,datare+1  ;put the "A" for ascii info for the DRS macro
2644 030576          printx #PB13         ;New Line <cr><lf>
2645 030616          printx #datare        ;print the message returned from the controller
2646
2647 030636          clrDUPbuf:
2648 030636 012701 002552          mov      #datare,r1     ;clear out entire data area
2649 030642 105021          2$:      clrb     (r1)+         ;
2650 030644 020127 002676          cmp     r1,#prgnam     ;
2651 030650 001374          bne     2$              ;
2652 030652 000207          rts      pc
2653 ;*****
2654 ;
2655 ; THIS ROUTINE IS TO CHECK ON THE RESPONSE PACKET
2656 ; GOODNESS. THE COMMAND REFERENCE NUMBER, THE END CODE
2657 ; AND THE STATUS ARE TESTED.
2658 ;*****
2659
2660 030654          RSPCHK:
2661
2662 030654 013701 002452          mov      cmdpak,r1
2663 030660 013700 002352          mov      rsppak,r0
2664 030664 020001          cmp      r0,r1          ;compare CRN numbers
2665 030666 001014          bne     1$
2666 030670 013701 002462          mov      cmdpak+10,r1
2667 030674 062701 000200          add      #200,r1
2668 030700 013700 002362          mov      rsppak+10,r0
2669 030704 020001          cmp      r0,r1          ;compare Opcodes
2670 030706 001004          bne     1$
2671 030710 013701 002364          mov      rsppak+12,r1  ;check the status
2672 030714 001001          bne     1$
2673 030716 000207          rts      pc            ;if all checks then return
2674
2675 ;if all doesn't check then a bad packet
2676 030720          1$:      ERRDF 10,df11    ;Bad response packet
2677 030730          PRNTPkt:
2678 030730          Printb #PB11crn,cmdpak,rsppak ;Expected CRN XXXX ,Received CRN YYYY
2679 030760 013701 002362          mov      rsppak+10,r1 ;check response opcode reply

```

## SIZER Supplied Program Data

```

2680 030764 032701 000200      bit      #200,r1      ;see if a end command response was send
2681 030770 001010      bne      2$          ;No end bit in response packet encode
2682 030772      printx  #PB1lend     ;
2683 031012 022701 000201      2$:      cmp      #201,r1     ;check if Get Dust Status command
2684 031016 001010      bne      3$          ;
2685 031020      printx  #PB11GDS    ;
2686 031040 022701 000202      3$:      cmp      #202,r1     ;check if Execute Supplied Program
2687 031044 001010      bne      4$          ;
2688 031046      printx  #PB11ESP    ;
2689 031066 022701 000203      4$:      cmp      #203,r1     ;check if Execute Local Program
2690 031072 001010      bne      5$          ;
2691 031074      printx  #PB11ELP    ;
2692 031114 022701 000204      5$:      cmp      #204,r1     ;check if Send Data
2693 031120 001010      bne      6$          ;
2694 031122      printx  #PB11SD     ;
2695 031142 022701 000205      6$:      cmp      #205,r1     ;check if Receive Data
2696 031146 001022      bne      7$          ;
2697 031150      printx  #PB11RD     ;
2698 031170      Printb #PBSF0,r3,r5 ;"type xxx, message number xxxxx is unknow to this program"
2699 031214 022701 000206      7$:      cmp      #206,r1     ;check if Abort Program
2700 031220 001010      bne      8$          ;
2701 031222      printx  #PB11AP    ;
2702 031242      Printb #PB11op,cmdpak+10,rsppak+10 ;CMDpkt opcode XXXX,RSPpkt opcode YYYYY
2703      ;
2704      ;
2705 031272 013701 002364      mov      rsppak+12,r1 ;find out what kind of status we have
2706 031276 022701 000000      cmp      #0.,r1     ;
2707 031302 001010      bne      10$         ;
2708 031304      printx  #pb11s0     ;status:  successful
2709 031324 022701 000001      10$:     cmp      #1.,r1     ;
2710 031330 001010      bne      11$         ;
2711 031332      printx  #pb11s1     ;status:  Invalid Command
2712 031352 022701 000002      11$:     cmp      #2.,r1     ;
2713 031356 001010      bne      12$         ;
2714 031360      printx  #pb11s2     ;status:  No Region Available
2715 031400 022701 000003      12$:     cmp      #3.,r1     ;
2716 031404 001010      bne      13$         ;
2717 031406      printx  #pb11s3     ;status:  No Region Suitable
2718 031426 022701 000004      13$:     cmp      #4.,r1     ;
2719 031432 001010      bne      14$         ;
2720 031434      printx  #pb11s4     ;status:  Program Not Known
2721 031454 022701 000005      14$:     cmp      #5.,r1     ;
2722 031460 001010      bne      15$         ;
2723 031462      printx  #pb11s5     ;status:  Load Failure
2724 031502 022701 000006      15$:     cmp      #6.,r1     ;
2725 031506 001010      bne      16$         ;
2726 031510      printx  #pb11s6     ;status:  Standalone
2727 031530 022701 000011      16$:     cmp      #9.,r1     ;
2728 031534 001010      bne      19$         ;
2729 031536      printx  #pb11s9     ;status:  Host Buffer Access error
2730 031556      19$:     ;
2731 031556      Printb #PB11sts,rsppak+12 ;Response packet status XXXX
2732 031602 000137 037420      jmp      dropunt    ;drop unit and go on
2733      ;
2734      ;
2735      ;*****
2736      ;

```

SIZER Supplied Program Data

```

2737
2738
2739 031606
2740 031606 032714 100000
2741 031612 001001
2742 031614 000207
2743 031616
2744 031626 011401
2745 031630 022701 001000
2746 031634 001010
2747 031636
2748 031656 022701 100001
2749 031662 001010
2750 031664
2751 031704 022701 100002
2752 031710 001010
2753 031712
2754 031732 022701 100003
2755 031736 001010
2756 031740
2757 031760 022701 100004
2758 031764 001010
2759 031766
2760 032006 022701 100005
2761 032012 001010
2762 032014
2763 032034 022701 100006
2764 032040 001010
2765 032042
2766 032062 022701 100007
2767 032066 001010
2768 032070
2769 032110 022701 100010
2770 032114 001010
2771 032116
2772 032136 022701 100011
2773 032142 001010
2774 032144
2775 032164 022701 100012
2776 032170 001010
2777 032172
2778 032212 022701 100013
2779 032216 001010
2780 032220
2781 032240 022701 100014
2782 032244 001010
2783 032246
2784 032266 022701 100015
2785 032272 001010
2786 032274
2787 032314 022701 100016
2788 032320 001010
2789 032322
2790 032342 022701 100017
2791 032346 001010
2792 032350
2793 032370 022701 100020

```

```

;
;*****
BIT15T:
bit #bit15,(r4)
bne 100$
rts pc
100$: ERRDF 9,df12 ;Fatal SA error
mov (r4),r1
cmp #1000,r1
bne 1$
printx #pb1201 ;
1$: cmp #100001,r1
bne 2$
printx #pb1202 ;
2$: cmp #100002,r1
bne 3$
printx #pb1203 ;
3$: cmp #100003,r1
bne 4$
printx #pb1204 ;
4$: cmp #100004,r1
bne 5$
printx #pb1205 ;
5$: cmp #100005,r1
bne 6$
printx #pb1206 ;
6$: cmp #100006,r1
bne 7$
printx #pb1207 ;
7$: cmp #100007,r1
bne 8$
printx #pb1208 ;
8$: cmp #100010,r1
bne 9$
printx #pb1209 ;
9$: cmp #100011,r1
bne 10$
printx #pb1210 ;
10$: cmp #100012,r1
bne 11$
printx #pb1211 ;
11$: cmp #100013,r1
bne 12$
printx #pb1212 ;
12$: cmp #100014,r1
bne 13$
printx #pb1213 ;
13$: cmp #100015,r1
bne 14$
printx #pb1214 ;
14$: cmp #100016,r1
bne 15$
printx #pb1215 ;
15$: cmp #100017,r1
bne 16$
printx #pb1216 ;
16$: cmp #100020,r1

```

SIZER Supplied Program Data

```

2794 032374 001010      bne      17$
2795 032376              printx   #pb1217      ;
2796 032416 022701 100021 17$:      cmp      #100021,r1
2797 032422 001010      bne      18$
2798 032424              printx   #pb1218      ;
2799 032444 022701 100022 18$:      cmp      #100022,r1
2800 032450 001010      bne      19$
2801 032452              printx   #pb1219      ;
2802 032472 022701 100023 19$:      cmp      #100023,r1
2803 032476 001010      bne      20$
2804 032500              printx   #pb1220      ;
2805 032520 022701 100024 20$:      cmp      #100024,r1
2806 032524 001010      bne      21$
2807 032526              printx   #pb1221      ;
2808 032546 022701 100025 21$:      cmp      #100025,r1
2809 032552 001010      bne      22$
2810 032554              printx   #pb1222      ;
2811 032574 022701 100026 22$:      cmp      #100026,r1
2812 032600 001010      bne      23$
2813 032602              printx   #pb1223      ;
2814 032622 23$:
2815 032622              printb   #pb12,r1      ;SA value: xxxxx
2816 032644 000137 037420 jmp      dropunt      ;drop unit and go on
2817
2818 ;*****+*****
2819 ;      Unexpected Interrupt Server
2820 ;
2821 ;*****+*****
2822 032650      intsrv:
2823
2824 032650      ERRSF  8,sf100 ;Fatal SA error
2825 032660      docln   ;do clean up and ou+
2826 032662 000137 037420 jmp      dropunt      ;drop test unit and org. pass
2827
2828

```

SIZER Supplied Program Data

```

2830 032666          BGNPROT
2831 032666 177777  .WORD -1
2832 032670 177777  .WORD 1
2833 032672 177777  .WORD 1
2834 032674          ENDPROT
2835
2836 032674          BGNINIT          ;Sequential example
2837 032674          READEF          #EF.CONTINUE ;Continue command?
2838 032702          BCOMPLETE       conton      ;Yes, get no P table but still initialize
2839 032704          READEF          #EF.NEW      ;New pass
2840 032712          BNCOMPLETE      next       ;if not new then go to next unit number
2841 032714          SETUP:
2842 032714 012737 177777 002310      mov      #-1,LOGUNIT      ;Initialize logical unit nbr
2843 032722          NEXT:
2844 032722 005237 002310      .nc      LOGUNIT          ;Point to next logical unit
2845 032726 023737 002310 002012      cmp      LOGUNIT,L$UNIT   ;Have we passed maximum?
2846 032734 001002          bne      1$          ;No
2847 032736 000137 033114          jmp      ABORT           ;Yes, abort the pass
2848 032742          1$:
2849 032742          GPHARD LOGUNIT,PLOC      ;Get the P table
2850 032754          BNCOMPLETE NEXT      ;if not available get next unit
2851
2852 032756 013700 002314      mov      ploc,r0
2853 032762 010037 002316      mov      r0,ptbl        ;store the Ptable address for unit
2854 032766 012037 002324      mov      (r0)+,ipreg    ;store IPreg address into register
2855 032772 012037 002326      mov      (r0)+,vector   ;store vector
2856 032776 012037 002330      mov      (r0)+,unit     ;store logical drive number
2857 033002 012037 002334      mov      (r0)+,sernbr   ;store the serial number
2858 033006 012037 002336      mov      (r0)+,untflgs
2859
2860 033012 005037 002540      conton: clr      LSTCRN      ;basic initialization stuff
2861 033016 005037 002544      clr      LSTVCT
2862 033022 005037 002546      clr      LOPRGI
2863 033026 005037 002550      clr      HIPRGI
2864
2865 033032 013746 000004      1$:  mov      @#4,(sp)        ;test to see if controller is there
2866 033036 012737 033052 000004      mov      #2,@#4
2867 033044 005077 147254      clr      @IPreg
2868 033050 000410          br      $3
2869
2870 033052          $2:  ERRDF  7,DF4          ;NXM trap at controller IP address
2871 033062          dodu  LOGUNIT      ;drop unit
2872 033070 000714          br      next          ;get new unit
2873
2874 033072 012637 000004      $3:  mov      (sp)+,@#4      ;move value back into location 4
2875
2876 033076 012700 000076      mov      #76,r0        ;clean out all packets and interrupt flags
2877 033102 012701 002346      mov      #rsp1,r1      ;and the command area
2878 033106 005021          $4:  clr      (r1)+
2879 033110 077002          sob     r0,$4
2880
2881 033112 000401          br      end
2882
2883 033114          ABORT:
2884 033114          DOCLN          ;Do clean up and abort the pass
2885 033116          END:
2886 033116          ENDINIT        ;Finished

```



M5

SIZER Supplied Program Data

```
2887
2888
2889 033120      BGNAUTO
2890 033120      DODU LOGUNIT
2891 033126      ENDAUTO
2892
2893 033130      BGNCLN
2894 033130      005077 147170      clr      @IPreg      ;get controller into know state
2895 033134      Break
2896 033136      ENDCLN      ;waste some time
2897
2898 033140      BGNDU
2899 033140      printf #DRPunt,unit
2900 033164      ENDDU
2901
```

## SIZER Supplied Program Data

```

2903 033166          BGNTST 1
2904 033166 004737 023550          jsr    pc,hrd'nt          ;init the controller
2905 033172 032737 010000 002336  bit    #bit12,untflgs    ;check if just want to park the heads
2906 033200 001402          beq    3$
2907 033202 000137 037420          jmp    dropunt           ;jump to end of test where heads are automatically p
arked
2908 033206 122737 000023 002340 3$:   cmpb   #Mrqdx3,mdlnbr    ;check if RQDX3 controller
2909 033214 001403          beq    2$
2910 033216 042737 100000 002336  bic    #bit15,untflgs    ;if other than RQDX3 than impossible to run auto siz
er or in auto mo
2911 033224 032737 100000 002336 2$:   bit    #bit15,untflgs    ;test if auto mode is enabled
2912 033232 001404          beq    1$
2913 033234 004737 024620          jsr    pc,AUTOsizer      ;if it is then run AUTO SIZER on the controller
2914 033240 004737 026474          jsr    pc,AUTOd's        ;display information from autosizer routine
2915
2916 033244          1$:
2917 033244 005077 147054          clr    @IPreg            ;...
2918 033250          printb #ASMSGT         ;can any spurious interrupts
2919 033270          ELPcmd:
2920 033270 000401          br     4$
2921 033272 000415          br     3$
2922 033274 005037 002322          4$:   clr    boot
2923 033300          GMANIL bot.dev,BOOT, 1,YES ; set this to a NOP for APT compatability
2924
2925 033314 005737 002322          tst    BOOT
2926 033320 001002          bne    3$
2927 033322 000137 037420          jmp    dropunt           ; skip manual question
2928 033326          3$:
2929
2930 033326 004737 023550          jsr    pc,hrd'nt         ; WARNING - remove boot diskette frst
2931 033332          printb #pb9,mdlnbr    ; Insert new diskette
2932 033356          printb #pb10,mcnbr    ; DO you want to continue
2933
2934 033402 032737 100000 002336  bit    #bit15,untflgs    ;
2935 033410 001011          bne    1$
2936 033412          GMANID ASK.prg,PRGnam,A,-1,6.,6.,yes ; Reinit ctrl in case of unknown state
2937 033432 000411          br     2$
2938 033434          1$:
2939 033434 012737 047506 002676          mov    #"FO,PRGnam
2940 033442 012737 046522 002700          mov    #"RM,PRGnam+2
2941 033450 012737 052101 002702          mov    #"AT,PRGnam+4
2942 033456          2$:
2943 033456          EXLCPRG PRGnam
2944
2945 033456 032737 100000 002534  ELP6: bit    #bit15,cmdrng+2 ;test ownership of ring make sure we own it
2946 033464 001374          bne    ELP6             ;if we don't own it wait until we do
2947 033466 012737 000022 002446          mov    #22,cmdlen
2948 033474 112737 000000 002450          movb   #0,cmdlen+2
2949 033502 112737 000002 002451          movb   #dup.id,cmdlen+3 ;load lenght of packet to be send
2950 033510 005237 002452          inc    cmdpak
2951 033514 005037 002454          clr    cmdpak+2
2952 033520 005037 002456          clr    cmdpak+4
2953 033524 005037 002460          clr    cmdpak+6
2954 033530 012737 000003 002462          mov    #op.elp,cmdpak+10 ;load up opcode
2955 033536 012737 000001 002464          mov    #stdaln,cmdpak+12 ;stand alone modifier
2956 033544 012700 000006          mov    #6,r0
2957 033550 012701 002466          mov    #cmdpak+14,r1
2958 033554 012702 002676          mov    #PRGnam,r2
2959 033560 112221          rfdj6: movb   (r2)+,(r1)+ ;6 letters transfer
2960 033562 077002          sob    r0,rfdj6         ;starting address to place program name
2961
2962
2963
2964
2965
2966
2967
2968
2969
2970
2971
2972
2973
2974
2975
2976
2977
2978
2979
2980
2981
2982
2983
2984
2985
2986
2987
2988
2989
2990
2991
2992
2993
2994
2995
2996
2997
2998
2999

```

SIZER Supplied Program Data

033564	012777	033626	146534	mov	#RFD6,@vector	;New vector place
033572	012737	002352	002526	mov	#rsppak,rsprng	;load response packet area into ring
033600	012737	002452	002532	mov	#cmdpak,cmdrng	;load command packet area into ring
033606	012737	140000	002530	mov	#140000,RSPRNG+2	;Port ownership bit.
033614	012737	100000	002534	mov	#bit15,CMDRNG+2	
033622	004737	022760		jsr	pc,POLLWT	;Go to poll and wait routine.

\*\*\*\*\*

033626				RFD6:		;Intr to here.
033626	062706	000006		add	#6,sp	;fix stack for interrupt (4), pollwt subrtn (2)
033632	012777	032650	146466	mov	#intsrv,@vector	;Change vector
033640	004737	030654		jsr	pc,RSPCHK	;Go to routine that will check on ;the response recvd from the mut. ;it will check the cmd ref ;num, the endcode and status.

2944							
2945	033644	122737	000011	002371	cmpb	#bit3+bit0,rsppak+17	;is this program a standalone,DUP d'alog type
2946	033652	001406			beq	1\$	;
2947	033654				ERRDF	2,DF3	;"Device Fatal can't do remote programs
2948	033664	000137	037420		jmp	dropunt	;drop unit and go on

2949	033670				1\$:			
2950	033670				RCDcmd:			
2951	033670				RECVDAT	#datare,#80.		
	033670	032737	100000	002534	RCD7:	bit	#bit15,cmdrng+2	;test ownership of ring make sure we own it
	033676	001374			bne	RCD7	;if we don't own it wait until we do	
	033700	012737	000034	002446	mov	#34,cmdlen	;load length of packet to be send	
	033706	112737	000000	002450	movb	#0,cmdlen+2	;load msg type and credit	
	033714	112737	000002	002451	movb	#dup.id,cmdlen+3	;load DUP connection ID	
	033722	005237	002452		inc	cmdpak	;load new CRN	
	033726	005037	002454		clr	cmdpak+2		
	033732	005037	002456		clr	cmdpak+4		
	033736	005037	002460		clr	cmdpak+6		
	033742	012737	000005	002462	mov	#op.rec,cmdpak+10	;load up opcode	
	033750	005037	002464		clr	cmdpak+12	;no modifiers	
	033754	012737	000120	002466	mov	#80.,cmdpak+14		
	033762	005037	002470		clr	cmdpak+16		
	033766	012737	002552	002472	mov	#datare,cmdpak+20	;load address of buffer descriptor	
	033774	005037	002474		clr	cmdpak+22		
	034000	005037	002476		clr	cmdpak+24		
	034004	005037	002500		clr	cmdpak+26		
	034010	005037	002502		clr	cmdpak+30		
	034014	005037	002504		clr	cmdpak+32		

034020	012777	034062	146300	mov	#RFD7,@vector	;New vector place
034026	012737	002352	002526	mov	#rsppak,rsprng	;load response packet area into ring
034034	012737	002452	002532	mov	#cmdpak,cmdrng	;load command packet area into ring
034042	012737	140000	002530	mov	#140000,RSPRNG+2	;Port ownership bit.
034050	012737	100000	002534	mov	#bit15,CMDRNG+2	
034056	004737	022760		jsr	pc,POLLWT	;Go to poll and wait routine.

\*\*\*\*\*

034062				RFD7:		;Intr to here.
034062	062706	000006		add	#6,sp	;fix stack for interrupt (4), pollwt subrtn (2)
034066	012777	032650	146232	mov	#intsrv,@vector	;Change vector

## SIZER Supplied Program Data

	034074	004737	030654	jsr	pc.RSPCHK	;Go to routine that will check on ;the response recvd from the mut. ;it will check the cmd ref ;num, the endcode and status.
2952				;;		
2953				;;	get	
2954				;;	r3 = type	
2955				;;	r4 - SA adrs	
2956				;;	r5 - sub number	
2957				;;		
2958	034100	113703	002553	DUPDLG:	movb datare+1,r3	;get dup type info
2959	034104	006203			asr r3	
2960	034106	006203			asr r3	
2961	034110	006203			asr r3	
2962	034112	006203			asr r3	
2963	034114	042703	177760		bic #type,r3	;mask off all but DUP type
2964	034120	013705	002552		mov datare,r5	;get dup message number info
2965	034124	042705	170000		bic #msgnbr,r5	;clear out top 4 bits
2966						
2967						
2968				;;		
2969				;;	Check for the type.	
2970				;;	if QUESTION type, it will be answered by sending	
2971				;;	an answer through a Send command which will be followed	
2972				;;	by a Receive command to await further instructions.	
2973				;;		
2974				;;	If a DEFAULT QUESTION type is given an answer will	
2975				;;	either be given or a blank send command returned.	
2976				;;	Either way we will do a Send command followed by a	
2977				;;	Receive command.	
2978				;;		
2979				;;	if INFORMATIONAL type, check message number and type	
2980				;;	information according to message number given.	
2981				;;		
2982				;;	if FATAL ERROR type, check message number and print	
2983				;;	error message accordingly. No other commands will	
2984				;;	be given following this type of command.	
2985				;;		
2986				;;	If TERMINATION type check the message number and print the	
2987				;;	correct message. Usually this implies a succesful	
2988				;;	end to the formatter. After this command we exit the program	
2989				;;		
2990				;;	If SPECIAL type we are asking for the FCT table to be passed	
2991				;;	to the RQDX3 controller. We will send the table with a Send	
2992				;;	command and then to a Receive command to proceed.	
2993				;;		
2994	034130	022703	000001	qstn:	cmp #Question,r3	;test for "quest'on" subtype
2995	034134	001117			bne dfqstn	;if not branch
2996	034136	032737	020000 002336		bit #bit13,untflgs	;see if we are working on a known controller
2997	034144	001077			bne qnbra	;if not type out ascii
2998	034146	122737	000106 002676		cmpb #'F,prgram	;if running the format program then print info
2999	034154	001073			bne qnbra	;else just go for an answer
3000						
ult	3001	034156	004737 030636	qnbr0:	jsr pc.clrDUPbuf	;clear out data buffer so DRS macros don't show defa
	3002	034162	022705 000000		cmp #0,r5	;check for message number
	3003	034166	001036		bne qnbr7	;check for next message number
	3004	034170	032737 100000 002336		bit #bit15,untflgs	

D0

## SIZER Supplied Program Data

```

3005 034176 001011
3006 034200          GMANID  bne      1$
3007 034220 000417          br      2$
3008 034222 012737 033060 002552 1$:  mov     #"06,datare      ;The date 's not used anyway so any date will do
3009 034230 012737 030455 002554          mov     #" 1,datare+2    ;I'll be celebrating this day
3010 034236 012737 026467 002556          mov     #"7-,datare+4
3011 034244 012737 034461 002560          mov     #"19,datare+6
3012 034252 012737 033070 002562          mov     #"86,datare+10
3013 034260 000137 035016          2$:  jmp     SDTcmd          ;branch to Send Data command
3014
3015 034264 022705 000007          qnbr7:  cmp     #7,r5          ;check for message number
3016 034270 001025          bne     qnbr8          ;check for next message number
3017 034272 032737 100000 002336          bit     #bit15,untflgs
3018 034300 001011          bne     1$
3019 034302          GMANID  qfser,DATARE,A,177777,8.,10.,NO      ;SERIAL NUMBER 9 d'g'its ?
3020 034322 000406          br      2$
3021 034324 013700 002334          1$:  mov     sernbr,r0
3022 034330 012701 002552          mov     #datare,r1      ;place to stick asc'
3023 034334 004737 030346          jsr     pc,OCTASC       ;convert octal to decimal asc'
3024 034340 000137 035016          2$:  jmp     SDTcmd
3025
3026 034344 004737 030542          qnbr8:  jsr     pc,typDUPbuf    ;type out ASCII sent by disk controller
3027 034350          GMANID  ASK.ANSWER,DATARE,A,177777,0.,10.,YES ;give 't an answer
3028 034370 000137 035016          jmp     SDTcmd          ;branch to Send Data command
3029
3030
3031 034374 022703 000002          dfqstn: cmp     #DefQuest,r3    ;test for "Default Question" subtype
3032 034400 001402          beq     1$
3033 034402 000137 035232          jmp     infrm          ;if not branch
3034 034406 032737 020000 002336 1$:  bic     #bit13,untflgs  ;see if we are working on a known controller
3035 034414 001402          beq     2$
3036 034416 000137 034772          jmp     dqnbr8          ;if not type out asc'i
3037 034422 122737 000106 002676 2$:  cnpb   #'F,prgnam      ;if running the format program then print 'nfo
3038 034430 001160          bne     dqnbr8          ;else just go for an answer
3039
3040 034432 004737 030636          dqnbr1: jsr     pc,clrDUPbuf    ;clear out data buffer so DRS macros don't show defa
ult
3041 034436 022705 000001          cmp     #1,r5          ;check for message number
3042 034442 001043          bne     dqnbr4          ;check for next message number
3043
3044 034444 032737 100000 002336          bit     #bit15,untflgs ;put in message number
3045 034452 001011          bne     3$
3046 034454          GMANID  dfunt,DATARE,A,177777,0,3,YES      ;Ask for UNIT NUMBER 0-255 ?
3047 034474 000406          br      4$
3048 034476 013700 002330          3$:  mov     unit,r0        ;get unit number if 'n auto mode from Hardware P tab
le
3049 034502 012701 002552          mov     #datare,r1      ;store decimal ascii conversion 'n data area
3050 034506 004737 030346          jsr     pc,OCTASC       ;convert octal to asc'i decimal 'n data area
3051
3052 034512 012701 002552          4$:  mov     #datare,r1      ;address of ascii decimal data
3053 034516 012700 002330          mov     #unit,r0        ;address to store octal conversion
3054 034522 004737 030434          jsr     pc,ASCDEC       ;convert ascii decimal to octal
3055 034526 022737 000003 002330 2$:  cmp     #3,unit        ;make sure unit number is less than 4 or between 0-3
3056 034534 002004          bge     1$
3057 034536 162737 000004 002330          sub     #4,unit        ;subtract 4 until unit 's less than four
3058 034544 000770          br      2$
3059 034546          1$:
3060
3061 034546 000137 035016          jmp     SDTcmd          ;branch to Send Data command

```

SIZER Supplied Program Data

```

3062
3063 034552 022705 000004      dqnbr4: cmp      #4,r5      ;check for message number
3064 034556 001021             bne      dqnbr5      ;check for next message number
3065 034560 012737 000116 002552^  mov      #'N,datare   ;set the default for NO
3066 034566 032737 100000 002336  bit      #bit15,unflgs
3067 034574 001010             bne      1$
3068 034576             GMANID  dfbad,DATAARE,A,177777,0,1,YES ;Use existing bad block information (Y or N)?
3069 034616 000137 035016      1$:      jmp      SDTcmd      ;branch to Send Data command
3070
3071 034622 022705 000005      dqnbr5: cmp      #5,r5      ;check for message number
3072 034626 001021             bne      dqnbr6      ;check for next message number
3073 034630 012737 000131 002552  mov      #'Y,datare   ;Set the default for YES
3074 034636 032737 100000 002336  bit      #b't15,unflgs
3075 034644 001010             bne      1$
3076 034646             GMANID  dfdown,DATAARE,A,177777,0,1,YES ;Use Down Line Load (Y or N)?
3077 034666 000137 035016      1$:      jmp      SDTcmd      ;branch to Send Data command
3078
3079 034672 022705 000006      dqnbr6: cmp      #6,r5      ;check for message number
3080 034676 001035             bne      dqnbr6      ;check for next message number
3081 034700 012737 000116 002552  mov      #'N,datare   ;set the default for NO
3082 034706 032737 100000 002336  bit      #bit15,unflgs ;'s this auto mode
3083 034714 001414             beq      1$          ;NO, ask question
3084                                     ;Yes see if RD51
3085 034716 013701 002330             mov      unit,r1     ; first cylinder entry
3086 034722 006301             asl      r1          ;
3087 034724 062701 026464             add      #msg+4,r1   ; point to current un't entry
3088 034730 023711 003102             cmp      UIT0+UITsiz 2,(r1) ; Is it an RD51?
3089 034734 001014             bne      2$          ; NO, all done
3090                                     ; YES, make quest'on answer yes because
3091                                     ; NO FCT tables on RD51
3092 034736 012737 000131 002552  mov      #'Y,datare   ; set the default for NO
3093 034744 000410             br       2$          ; and skip question
3094 034746
3095 034746             1$:      GMANID  dfcon,DATAARE,A,177777,0,1,YES ;Continue if bad block information is inaccessible (
Y or N)?
3096 034766 000137 035016      2$:      jmp      SDTcmd
3097
3098                                     ;if unknown use default and continue
3099                                     ;who knows maybe it will be useful some day
3100 034772
3101 034772 004737 030542      dqnbr6: jsr      pc,typDUPbuf ;type out ASCII sent by d'sk controller
3102
3103 034776             GMANID  ASK.ANSWER,DATAARE,A,177777,0.,10.,YES ;g'ive it an answer
3104
3105 035016             SDTcmd:
3106 035016             SENDDAT #datare,#10. ;sent the answer
035016 032737 100000 002534 SDT10: bit      #bit15,cmdrng+2 ;test ownership of ring make sure we own it
035024 001374             bne      SDT10      ;if we don't own it wait until we do
035026 012737 000034 002446  mov      #34,cmdlen  ;load lenght of packet to be send
035034 112737 000000 002450  movb     #0,cmdlen+2 ;load msg type and credit
035042 112737 000002 002451  movb     #dup.id,cmdlen+3 ;load DUP connect'on ID
035050 005237 002452             inc      cmdpak     ;load new CRN
035054 005037 002454             clr     cmdpak+2
035060 005037 002456             clr     cmdpak+4
035064 005037 002460             clr     cmdpak+6
035070 012737 000004 002462  mov      #op.sen,cmdpak+10 ;load up opcode
035076 005037 002464             clr     cmdpak+12   ;no modifiers
035102 012737 000012 002466  mov      #10.,cmdpak+14

```

SIZER Supplied Program Data

```

035110 005037 002470          clr      cmdpak+16
035114 012737 002552 002472  mov      #datare,cmdpak+20      ;load address of buffer descriptor
035122 005037 002474          clr      cmdpak+22
035126 005037 002476          clr      cmdpak+24
035132 005037 002500          clr      cmdpak+26
035136 005037 002502          clr      cmdpak+30
035142 005037 002504          clr      cmdpak+32

035146 012777 035210 145152  mov      #RFD10,@vector        ;New vector place
035154 012737 002352 002526  mov      #rsppak,rsprng        ;load response packet area into ring
035162 012737 002452 002532  mov      #cmdpak,cmdrng        ;load command packet area into ring
035170 012737 140000 002530  mov      #140000,RSPRNG+2      ;Port ownership bit.
035176 012737 100000 002534  mov      #bit15,CMDRNG+2
035204 004737 022760          jsr      pc,POLLWT            ;Go to poll and wait routine.

;*****

035210          RFD10:
035210 062706 000006          add      #6,sp                ;Intr to here.
035214 012777 032650 145104  mov      #intsrv,@vector      ;fix stack for interrupt (4), pollwt subrtn (2)
035222 004737 030654          jsr      pc,RSPCHK           ;Change vector
                                ;Go to routine that will check on
                                ;the response recvd from the mut.
                                ;it will check the cmd ref
                                ;num, the endcode and status.
                                ;do another receive cmd

3107 035226 000137 033670          jmp      RCDcmd

3108
3109
3110
3111 035232 022703 000003  infrm:  cmp      #Inform,r3        ;test for "Informational" subtype
3112 035236 001046          bne     term                 ;if not branch
3113 035240 032737 020000 002336  bit     #bit13,unflgs        ;see if we are working on a known controller
3114 035246 001036          bne     inbra                ;if not type out ascii
3115 035250 122737 000106 002676  cmpb   #'F,prngam           ;if running the format program then print info
3116 035256 001032          bne     inbra
3117
3118 035260 022705 000000  inbr0:  cmp      #0,r5            ;check for message number
3119 035264 001012          bne     inbr1                ;check for next message number
3120 035266 004737 030636          jsr      pc,clrDUPbuf        ;clear out DUP buffer so there is no echo on last AS

CII
3121 035272          printf  #sfbegt              ;format begun
3122 035312 022705 000001  inbr1:  cmp      #1,r5            ;check for message number
3123 035316 001012          bne     inbra                ;check for next message number
3124 035320 004737 030636          jsr      pc,clrDUPbuf        ;clear out DUP buffer so there is no echo on last AS

CII
3125 035324          printf  #sfdont              ;format complete
3126
3127 035344 004737 030542  inbra:  jsr      pc,typDUPbuf   ;type out ASCII sent by disk controller
3128 035350 000137 033670          jmp      RCDcmd            ;do another receive command
3129
3130
3131
3132 035354 022703 000004  term:   cmp      #terminat,r3  ;test for termination type
3133 035360 001116          bne     ftler                 ;if not branch
3134 035362 032737 020000 002336  bit     #bit13,unflgs        ;see if we are working on a known controller
3135 035370 001076          bne     tnbra                ;if not type out ascii
3136 035372 122737 000106 002676  cmpb   #'F,prngam           ;if running the format program then branch to error

routine
3137 035400 001072          bne     tnbra
3138
3139 035402 022705 000014  tnbr12: cmp      #12.,r5        ;test for sub number #1

```

SIZER Supplied Program Data

```
3140 035406 001012          bne      tnbr13          ;branch if not sub number #1
3141 035410          printf  #sffcut          ;
3142 035430 000137 037420    jmp      dropunt        ;drop test unit and end pass
3143
3144 035434 022705 000015    tnbr13: cmp      #13.,r5    ;test for msg number
3145 035440 001052          bne      tnbra          ;branch if not right number
3146 035442          printf  #sffcnt          ;
3147 035462 032737 100000 002336 bit      #bit15,untflgs ;are we in auto mode
3148 035470 001434          beq      2$            ; NO , then we are all done
3149          ; YES, is this an RX33
3150 035472 013701 002330    mov      unit,r1        ; first cylinder entry
3151 035476 006301          asl      r1            ;
3152 035500 062701 026464    add      #msg+4,r1      ; point to current unit entry
3153 035504 022711 000003    cmp      #3,(r1)        ; Is it an RX33?
3154 035510 001024          bne      2$            ; NO, all done
3155          ; YES, ask if it wants to continue or not
3156
3157 035512 005077 144606    GMANIL  clr      @IPreg    ; reinit the controller stop spurious interrupts
3158 035516          bot.con,BOOT, 1,YES ; Do you want to format another?
3159
3160 035532 005737 002322    tst      BOOT          ; Yes, execute local program
3161 035536 001007          bne      1$            ; No, tell him to insert bootable media
3162
3163 035540 000402          GMANIL  bot.rep,BOOT, 1,YES ; Please insert boot media and hit return
3164 035554          br      2$            ;
3165 035556 000137 033270    1$:    jmp      ELPcmd        ;
3166 035562 000137 037420    2$:    jmp      dropunt        ;
3167
3168 035566 004737 030542    tnbra:  jsr      pc,typDUPbuf ;type out ASCII sent by disk controller
3169 035572          printf  #PF2          ;print finished local program without procedure error
3170
3170 035612 000137 037426    jmp      etst          ;end DUP diaglog but stay in test loop
3171
3172
3173 035616 022703 000005    ftler:  cmp      #Ftlerr,r3 ;test for "Fatal Error" subtype
3174 035622 001402          beq      1$            ;
3175 035624 000137 037100    1$:    jmp      spcl          ;if not branch
3176 035630 032737 020000 002336 bit      #bit13,untflgs ;see if we are working on a known controller
3177 035636 001004          bne      3$            ;if not type out ascii
3178 035640 122737 000106 002676    cmpb    #'F,prgram      ;if running the format program then branch to error
3179
3179 035646 001414          beq      2$            ;
3180 035650 004737 030542    3$:    jsr      pc,typDUPbuf ;type out ASCII sent by disk controller
3181 035654          printf  #DF15          ;Fatal error reported when running local program
3182 035674 000137 037420    jmp      dropunt        ;drop unit and end pass
3183
3184 035700          2$:    ERRHRD  1,HRDO        ;Hard device error
3185
3186 035710 022705 000001    fnbr1:  cmp      #1,r5    ;test for sub number #1
3187 035714 001012          bne      fnbr2        ;branch if not sub number #1
3188
3188 035716          gstsfc: printb  #efstat        ;"GET STATUS failure"
3189 035716          jmp      dropunt        ;drop unit and end pass
3190 035736 000137 037420
3191
3192 035742 022705 000002    fnbr2:  cmp      #2.,r5    ;test for msg number
3193 035746 001012          bne      fnbr3        ;branch if not right number
3194 035750          printf  #efsndt        ;
3195 035770 000137 037420    jmp      dropunt        ;drop unit and end pass
3196
```



## SIZER Supplied Program Data

3197	035774	022705	000003	fnbr3:	cmp	#3.,r5	;test for msg number
3198	036000	001012			bne	fnbr4	;branch if not right number
3199	036002				printf	#efcmdt	;
3200	036022	000137	037420		jmp	dropunt	;drop unit and end pass
3201				fnbr4:	cmp	#4.,r5	;test for msg number
3202	036026	022705	000004		bne	fnbr5	;branch if not right number
3203	036032	001012			printf	#efrcvt	;
3204	036034				jmp	dropunt	;drop unit and end pass
3205	036054	000137	037420				
3206				fnbr5:	cmp	#5.,r5	;test for msg number
3207	036060	022705	000005		bne	fnbr6	;branch if not right number
3208	036064	001012			printf	#efbust	;
3209	036066				jmp	dropunt	;drop unit and end pass
3210	036106	000137	037420				
3211				fnbr6:	cmp	#6.,r5	;test for msg number
3212	036112	022705	000006		bne	fnbr7	;branch if not right number
3213	036116	001012			printf	#efinit	;
3214	036120				jmp	dropunt	;drop unit and end pass
3215	036140	000137	037420				
3216				fnbr7:	cmp	#7.,r5	;test for msg number
3217	036144	022705	000007		bne	fnbr8	;branch if not right number
3218	036150	001012			printf	#efnut	;
3219	036152				jmp	dropunt	;drop unit and end pass
3220	036172	000137	037420				
3221				fnbr8:	cmp	#8.,r5	;test for msg number
3222	036176	022705	000010		bne	fnbr9	;branch if not right number
3223	036202	001012			printf	#efdxft	;
3224	036204				jmp	dropunt	;drop unit and end pass
3225	036224	000137	037420				
3226				fnbr9:	cmp	#9.,r5	;test for msg number
3227	036230	022705	000011		bne	fnbr10	;branch if not right number
3228	036234	001012			printf	#effcct	;
3229	036236				jmp	dropunt	;drop unit and end pass
3230	036256	000137	037420				
3231				fnbr10:	cmp	#10.,r5	;test for msg number
3232	036262	022705	000012		bne	fnbr11	;branch if not right number
3233	036266	001012			printf	#efsekt	;
3234	036270				jmp	dropunt	;drop unit and end pass
3235	036310	000137	037420				
3236				fnbr11:	cmp	#11.,r5	;test for msg number
3237	036314	022705	000013		bne	fnbr12	;branch if not right number
3238	036320	001012			printf	#efrcct	;
3239	036322				jmp	dropunt	;drop unit and end pass
3240	036342	000137	037420				
3241				fnbr12:	cmp	#12.,r5	;test for msg number
3242	036346	022705	000014		bne	fnbr13	;branch if not right number
3243	036352	001012			printf	#eflbft	;
3244	036354				jmp	dropunt	;drop unit and end pass
3245	036374	000137	037420				
3246				fnbr13:	cmp	#13.,r5	;test for msg number
3247	036400	022705	000015		bne	fnbr14	;branch if not right number
3248	036404	001012			printf	#effcwt	;
3249	036406				jmp	dropunt	;drop unit and end pass
3250	036426	000137	037420				
3251				fnbr14:	cmp	#14.,r5	;test for msg number
3252	036432	022705	000016		bne	fnbr15	;branch if not right number
3253	036436	001012					

## SIZER Suppl'ed Program Data

```

3254 036440          printf #efrcrt          ;
3255 036460 000137 037420      no          dropunt          ;drop unit and end pass
3256
3257 036464 022705 000017      fnbr15: cmp          #15.,r5          ;test for msg number
3258 036470 001012          bne          fnbr16          ;branch if not right number
3259 036472          printf #efrcwt          ;
3260 036512 000137 037420      jmp          dropunt          ;drop unit and end pass
3261
3262 036516 022705 000020      fnbr16: cmp          #16.,r5          ;test for msg number
3263 036522 001012          bne          fnbr17          ;branch if not right number
3264 036524          printf #efrcft          ;
3265 036544 000137 037420      jmp          dropunt          ;drop unit and end pass
3266
3267 036550 022705 000021      fnbr17: cmp          #17.,r5          ;test for msg number
3268 036554 001012          bne          fnbr18          ;branch if not right number
3269 036556          printf #effcrt          ;
3270 036576 000137 037420      jmp          dropunt          ;drop unit and end pass
3271
3272 036602 022705 000022      fnbr18: cmp          #18.,r5          ;test for msg number
3273 036606 001012          bne          fnbr19          ;branch if not right number
3274 036610          printf #effcft          ;
3275 036630 000137 037420      jmp          dropunt          ;drop unit and end pass
3276
3277 036634 022705 000023      fnbr19: cmp          #19.,r5          ;test for msg number
3278 036640 001012          bne          fnbr20          ;branch if not right number
3279 036642          printf #effcdt          ;
3280 036662 000137 037420      jmp          dropunt          ;drop unit and end pass
3281
3282 036666 022705 000024      fnbr20: cmp          #20.,r5          ;test for msg number
3283 036672 001012          bne          fnbr21          ;branch if not right number
3284 036674          printf #eftmot          ;
3285 036714 000137 037420      jmp          dropunt          ;drop unit and end pass
3286
3287 036720 022705 000025      fnbr21: cmp          #21.,r5          ;test for msg number
3288 036724 001012          bne          fnbr22          ;branch if not right number
3289 036726          printf #efillt          ;
3290 036746 000137 037420      jmp          dropunt          ;drop unit and end pass
3291
3292 036752 022705 000026      fnbr22: cmp          #22.,r5          ;test for msg number
3293 036756 001012          bne          fnbr23          ;branch if not right number
3294 036760          printf #efwart          ;
3295 037000 000137 037420      jmp          dropunt          ;drop unit and end pass
3296
3297 037004 022705 000027      fnbr23: cmp          #23.,r5          ;test for msg number
3298 037010 000412          br          fnbr24          ;branch if not right number
3299 037012          printf #efinpt          ;
3300 037032 000137 037420      jmp          dropunt          ;drop unit and end pass
3301
3302
3303 037036 022705 000030      fnbr24: cmp          #24.,r5          ;test for msg number
3304 037042 001012          bne          1$          ;
3305 037044          printf #efmedt          ;
3306 037064 000137 037420      jmp          dropunt          ;drop unit and end pass
3307
3308 037070 004737 030542      1$:      jsr          pc,typDUPbuf          ;type out ASCII sent by disk controller
3309 037074 000137 037420      jmp          dropunt          ;drop unit and end pass
3310

```

SIZER Supplied Program Data

```

3311
3312
3313
3314 037100 022703 000006      spcl:  cmp    #specl,r3      ;test for special type
3315 037104 001137              bne    unkwn      ;branch if not known
3316 037106 032737 020000 002336  bit    #bit13,untflgs ;see if we are working on a known controller
3317 037114 001004              bne    2$         ;if not type out ascii
3318 037116 122737 000106 002676  cmpb   #'F,prgnam   ;if running the format program then print info
3319 037124 001414              beq    1$         ;type out ASCII sent by disk controller
3320 037126 004737 030542      2$:   jsr    pc,typDUPbuf ;special command issued by local program did not kno
3321 037132              prntf  #DF16
w how to handle
3322 037152 000137 037404              jmp    unkwn      ;report error
3323
3324 037156 022705 000002      1$:   cmp    #2,r5      ;test for message number 1
3325 037162 001110              bne    unkwn      ;branch if not known
3326 037164 004737 027542              jsr    pc,blduit  ;go get or build UIT table
3327 037170              SENDDAT UITadr,#UITsiz ;sent Unit Information table
037170 032737 100000 002534  SDT11: bit    #bit15,cmdrng+2 ;test ownership of ring make sure we own it
037176 001374              bne    SDT11      ;if we don't own it wait until we do
037200 012737 000034 002446  mov    #34,cmdlen  ;load length of packet to be send
037206 112737 000000 002450  movb   #0,cmdlen+2 ;load msg type and credit
037214 112737 000002 002451  movb   #dup.id,cmdlen+3 ;load DUP connection ID
037222 005237 002452              inc    cmdpak     ;load new CRN
037226 005037 002454              clr    cmdpak+2
037232 005037 002456              clr    cmdpak+4
037236 005037 002460              clr    cmdpak+6
037242 012737 000004 002462  mov    #op.sen,cmdpak+10 ;load up opcode
037250 005037 002464              clr    cmdpak+12  ;no modifiers
037254 012737 000104 002466  mov    #UITs'z,cmdpak+14
037262 005037 002470              clr    cmdpak+16
037266 013737 002320 002472  mov    UITadr,cmdpak+20 ;load address of buffer descriptor
037274 005037 002474              clr    cmdpak+22
037300 005037 002476              clr    cmdpak+24
037304 005037 002500              clr    cmdpak+26
037310 005037 002502              clr    cmdpak+30
037314 005037 002504              clr    cmdpak+32
037320 012777 037362 143000  mov    #RFD11,@vector ;New vector place
037326 012737 002352 002526  mov    #rsppak,rsprng ;load response packet area into ring
037334 012737 002452 002532  mov    #cmdpak,cmdrng ;load command packet area into ring
037342 012737 140000 002530  mov    #140000,RSPRNG+2 ;Port ownership bit.
037350 012737 100000 002534  mov    #bit15 CMDRNG+2
037356 004737 022760              jsr    pc,POLL T   ;Go to poll and wait routine.

;*****
037362              RFD11:
037362 062706 000006              add    #6,sp      ;Intr to here.
037366 012777 032650 142732  mov    #intsrv,@vector ;fix stack for interrupt (4), pollut subrtn (2)
037374 004737 030654              jsr    pc,RSPCHK  ;Change vector
;Go to routine that will check on
;the response recvd from the mut.
;it will check the cmd ref
;num, the endcode and status.
;do another receive cmd
3328 037400 000137 033670              jmp    RCDcmd
3329
3330
3331 037404              unkwn: ERRSF 0,SFO ; system error unkown response

```



## SIZER Supplied Program Data

```

3347 037472          BGNHRD
3348
3349 037474          GPRMA ip.adr,0,0,160000,177776,YES ;Get IP reg addr (170000-177776)
3350                                     ;place in word 2 of the table
3351                                     ;default value is from default
3352                                     ;table.
3353
3354 037504          GPRMA vec.adr,2,0,0,776,YES ;Get the vector addr (octal 0-776)
3355                                     ;place in word
3356                                     ;default value is from default
3357                                     ;table.
3358
3359 037514          GPRML prk.hds,10,bit12,YES ;ask if they want to just park the heads
3360
3361 037522          XFERT label0 ;If last gprml input is true (y) transfer
3362
3363 037524          GPRML auto.md,10,bit15,YES ;ask if they want to go in to auto mode
3364                                     ;This will format the drive using the autosizer
3365
3366 037532          XFERF label0 ;If last gprml input is false (n) transfer
3367                                     ;control to label.
3368
3369 037534          GPRMD drv.nbr,4,D,-1,0,255.,YES ;Get the logical drive (DECIMAL 0-255)
3370                                     ;place in word
3371                                     ;default value is from default
3372                                     ;table.
3373
3374
3375 037546          GPRMD ser.nbr,6,D, 1,1,012345.,YES ;Get the drive serial number
3376                                     ;place in word
3377                                     ;default value is from default
3378                                     ;table.
3379
3380
3381 037560          label0:
3382
3383 037560          exit hrd
3384 037562          ENDHRD
3385
3386
3387 037562          LASTAD
3388 037566          L$LAST::
3389 037566          ENDMOD
3389          000001          .END

```

## Symbol table

A	=	000000	
ABORT		033114	
ABRT3		024450	
ADR	=	000020	G
ASCDEC		030434	
ASK.AN		020543	
A.K.DB		006746	
ASK.LB		007021	
ASK.PR		006625	
ASK.RB		007074	
ASK.XB		006673	
ASMSGR		005637	
ASMSGT		006507	
ASMSG1		005733	
ASMSG2		006234	
ASMSG3		006257	
ASMSG4		006341	
ASMSG5		006411	
ASMSG6		006463	
ASMSG7		006021	
ASMSG8		006066	
ASMSG9		006152	
ASSEMB	=	000010	
AUTO		025314	G
AUTOBL		030060	
AUTODI		026474	
AUTOEN		026474	
AUTOSI		024620	
AUTOSZ		025270	
AUTO.M		004305	
B	=	000011	
BIT0	=	000001	G
BIT00	=	000001	G
BIT01	=	000002	G
BIT02	=	000004	G
BIT03	=	000010	G
BIT04	=	000020	G
BIT05	=	000040	G
BIT06	=	000100	G
BIT07	=	000200	G
BIT08	=	000400	G
BIT09	=	001000	G
BIT1	=	000002	G
BIT10	=	002000	G
BIT11	=	004000	G
BIT12	=	010000	G
BIT13	=	020000	G
BIT14	=	040000	G
BIT15	=	100000	G
BIT15T		031606	
BIT2	=	000004	G
BIT3	=	000010	G
BIT4	=	000020	G
BIT5	=	000040	G
BIT6	=	000100	G
BIT7	=	000200	G
BIT8	=	000400	G
BIT9	=	001000	G
BLDUIT		027542	
BOE	=	000400	G
BOOT		002322	
BOT.CO		007673	
BOT.DE		007147	
BOT.RE		007603	
CINTR		002522	
CLRDUP		030636	
CMDLEN		002446	
CMOPAK		002452	
CMORNG		002532	
CONT		030344	
CONTON		033012	
C\$AU	=	000052	
C\$AUTO	=	000061	
C\$BRK	=	000022	
C\$BSEG	=	000004	
C\$BSUB	=	000002	
C\$CLCK	=	000062	
C\$CLEA	=	000012	
C\$CLOS	=	000035	
C\$CLP1	=	000006	
C\$CPBF	=	000074	
C\$CPME	=	000075	
C\$CVEC	=	000036	
C\$DCLN	=	000044	
C\$DODU	=	000051	
C\$DRPT	=	000024	
C\$DU	=	000053	
C\$EDIT	=	000003	
C\$ERDF	=	000055	
C\$ERHR	=	000056	
C\$ERRO	=	000060	
C\$ERSF	=	000054	
C\$ERSO	=	000057	
C\$ESCA	=	000010	
C\$ESEG	=	000005	
C\$ESUB	=	000003	
C\$ETST	=	000001	
C\$EXIT	=	000032	
C\$FREQ	=	000101	
C\$FRME	=	000100	
C\$GETB	=	000026	
C\$GETW	=	000027	
C\$GMAN	=	000043	
C\$GPHR	=	000042	
C\$GPRI	=	000040	
C\$INIT	=	000011	
C\$INLP	=	000020	
C\$MANI	=	000050	
C\$MAP	=	000102	
C\$MEM	=	000031	
C\$MMU	=	000103	
C\$MSG	=	000023	
C\$OPNR	=	000034	
C\$OPNW	=	000104	
C\$PNTR	=	000014	
C\$PNTF	=	000017	
C\$PNTS	=	000016	
C\$PNTX	=	000015	
C\$PUTB	=	000072	
C\$PUTW	=	000073	
C\$QIO	=	000377	
C\$RDBU	=	000007	
C\$REFG	=	000047	
C\$REL	=	000077	
C\$RESE	=	000033	
C\$REVI	=	000003	
C\$RFLA	=	000021	
C\$RPT	=	000025	
C\$SEFG	=	000046	
C\$SPRI	=	000041	
C\$SVEC	=	000037	
C\$TOME	=	000076	
DATARE		002552	
DBN		002720	
DECTBL		030420	
DEFQUE	=	000002	
DFBAD		020300	
DFCON		020400	
DFDWN		020350	
DFPTBL		002276	G
DFQSTN		034374	
DFUNT		020237	
DF1		011141	
DF11		011425	
DF12		011462	
DF13		011516	
DF14		011572	
DF15		011653	
DF16		011743	
DF2		011203	
DF3		011252	
DF4		011362	
DIAGMC	=	000000	
DNINT		024616	
DOUDC		026366	G
DOURET		026450	
DO.CON		004426	
DQNBR		034772	
DQNBR1		034432	
DQNCR4		034552	
DQNBR5		034622	
DQNBR6		034672	
DROPUN		037420	
DRPUNT		017771	
DRVTXA		004462	
DRVTXB		004511	
DRVTXC		005543	
DRVTX0		004605	
DRVTX1		004701	
DRVTX2		004775	
DRVTX3		005071	
DRVTX4		005165	
DRVTX5		005261	
DRVTX6		005355	
DRVTX7		005450	
DRV.NB		004222	
DUPDLG		034100	
DUP.ID	=	000002	
EFCBLST		021517	
EFCMDT		021435	
EFDXFT		021642	
EFFCCT		021731	
EFFCDT		022425	
EFFCNT		022401	
EFFCRT		022356	
EFFCW		022211	
EFILLT		022511	
EFINLT		021543	
EFINPT		022664	
EFLBFT		022126	
EFMEDT		022705	
EFNUT		021606	
EFRCC		022037	
EFRCCFT		022341	
EFRCCRT		022272	
EFRCVT		021466	
EFRCW		022315	
EFSEKT		022020	
EFSNDT		021407	
EFTSTAT		021360	
EFTMOT		022462	
EFUNRG		022730	
EFWART		022563	
EF.CON	=	000036	G
EF.NEW	=	000035	G
EF.PWR	=	000034	G
EF.RES	=	000037	G
EF.STA	=	000040	G
ELPCMD		033270	
ELP6		033456	
END		033116	
ERSEKO	=	000003	
ERUDON	=	000001	
ERUINT	=	000002	
ESP4		024620	
ETST		037420	
EVL	=	000004	G
E\$END	=	002100	
E\$LOAD	=	000035	
FNBR1		035710	
FNBR10		036262	
FNBR11		036314	
FNBR12		036346	
FNBR13		036400	
FNBR14		036432	
FNBR15		036464	
FNBR16		036516	
FNBR17		036550	
FNBR18		036602	
FNBR19		036634	
FNBR2		035742	
FNBR20		036666	
FNBR21		036720	
FNBR22		036752	
FNBR23		037004	
FNBR24		037036	
FNBR3		035774	
FNBR4		036026	
FNBR5		036060	
FNBR6		036112	
FNBR7		036144	
FNBR8		036176	
FNBR9		036230	
FTLER		035616	
FTLERR	=	000005	
F\$AU	=	000015	
F\$AUTO	=	000020	
F\$BGN	=	000040	
F\$CLEA	=	000007	
F\$DU	=	000016	
F\$END	=	000041	
F\$HARD	=	000004	
F\$HW	=	000013	
F\$INIT	=	000006	
F\$JMP	=	000050	
F\$MOD	=	000000	
F\$MSG	=	000011	
F\$PROT	=	000021	
F\$PWR	=	000017	
F\$RPT	=	000012	
F\$SEG	=	000003	
F\$SOFT	=	000005	
F\$SRV	=	000010	
F\$SUB	=	000002	
F\$SW	=	000014	
F\$TEST	=	000001	
GDS CMD		024264	
GDS0		023060	
GDS2		024264	
GOBIT		024250	
GSTSF		035716	
G\$CNT0	=	000200	
G\$DELM	=	000372	
G\$DISP	=	000003	
G\$EXCP	=	000400	
G\$HILI	=	000002	
G\$LOLI	=	000001	
G\$NO	=	000000	
G\$OFFS	=	000400	
G\$OFSI	=	000376	
G\$PRMA	=	000001	
G\$PRMD	=	000002	
G\$PRML	=	000000	
G\$RADA	=	000140	
G\$RADB	=	000000	

## Symbol table

G\$RADD=	000040	L\$CCP	002106	G	MRQDX1=	000007	PB11EN	014673	PRI01 =	000040	G
G\$RADL=	000120	L\$CLEA	033130	G	MRQDX3=	000023	PB11ES	015002	PRI02 =	000100	G
G\$RADO=	000020	L\$CO	002032	G	MSECA =	007570	PB11GD	014752	PRI03 =	000140	G
G\$XFER=	000004	L\$DEPO	002011	G	MSEND	026430	PB11OP	014565	PRI04 =	000200	G
G\$YES =	000010	L\$DESC	002126	G	MSG	026450	PB11RD	015113	PRI05 =	000240	G
HIPRGI	002550	L\$DESP	002076	G	MSGDAT	026462	PB11SD	015071	PRI06 =	000300	G
HOE =	100000	L\$DEVP	002060	G	MSGLEN=	000014	PB11ST	014637	PRI07 =	000340	G
HRDINT	023550	L\$DISP	002124	G	MSGNBR=	170000	PB11SO	015162	PRK.HD	004176	
HRDO	012250	L\$DLY	002116	G	MSIN	026410	PB11S1	015207	FRNTPK	030730	
IBE =	010000	L\$DTP	002040	G	MSWAIT	026404	PB11S2	015241	PS0 =	000000	
IDU =	000040	L\$DTYP	002034	G	NEXT	032722	PB11S3	015277	PS7 =	000340	
IER =	020000	L\$DU	033140	G	OCTASC	030346	PB11S4	015334	PTBL	002316	
INBRA	035344	L\$DUT	002072	G	OP.ABR-	000006	PB11S5	015370	QFDAT	020206	
INBRO	035260	L\$DVTY	002166	G	OP.DD -	000001	PB11S6	015417	QFSER	020467	
INBR1	035312	L\$EF	002052	G	OP.ELP=	000003	PB11S9	015444	QFUIT	020131	
INFORM=	000003	L\$ENVI	002044	G	OP.END=	000200	PB11W0	015507	QNBRA	034344	
INFRM	035232	L\$ETP	002102	G	OP.ESP=	000002	PB11W1	015573	QNBRO	034156	
INTSRV	032650	L\$EXP1	002046	G	OP.GDS=	000001	PB12	017674	QNBRO	034264	
IPREG	002324	L\$EXP4	002064	G	OP.RD =	000003	PB1201	015664	QSTN	034130	
IP ADR	004144	L\$EXP5	002066	G	OP.REC=	000005	PB1202	015750	QUESTI=	000001	
ISR =	000100	L\$HARD	037474	G	OP.RES=	000000	PB1203	016035	RBN	002746	
IXE =	004000	L\$HIME	002120	G	OP.SEN=	000004	PB1204	016106	RCDCMD	033670	
I\$AU =	000041	L\$HPCP	002016	G	OP.SI1=	000005	PB1205	016147	RCD5	025056	
I\$AUTO=	000041	L\$HPTP	002022	G	OP.S01=	000007	PB1206	016210	RCD7	033670	
I\$CLK =	100006	L\$HW	002276	G	OP.SRD=	000044	PB1207	016262	RD.MOD=	000300	
I\$CLN =	000041	L\$ICP	002104	G	OP.SRP=	000100	PB1208	016335	RETRY =	000367	
I\$DU =	000041	L\$INIT	032674	G	OP.SRX=	000054	PB1209	016371	RFDJ6	033560	
I\$HRD =	000041	L\$LADP	002026	G	O\$APTS=	000000	PB1210	016472	RFD0	023226	
I\$INIT=	000041	L\$LAST	037566	G	O\$AU =	000000	PB1211	016534	RFD10	035210	
I\$MOD =	000041	L\$LOAD	002100	G	O\$BGNR=	000000	PB1212	016570	RFD11	037362	
I\$MSG =	000041	L\$LUN	002074	G	O\$BGNS=	000000	PB1213	016645	RFD2	024412	
I\$PROT=	000040	L\$MREV	002050	G	O\$DU =	000001	PB1214	016711	RFD3	024576	
I\$PTAB=	000041	L\$NAME	002000	G	O\$ERRT=	000000	PB1215	016762	RFD4	025040	
I\$PWR =	000041	L\$PRIO	002042	G	O\$GNSW=	000000	PB1216	017023	RFD5	025250	
I\$RPT =	000041	L\$PROT	032666	G	O\$POIN=	000001	PB1217	017117	RFD6	033626	
I\$SEC =	100016	L\$PRT	002112	G	O\$SETU=	000001	PB1218	017214	RFD7	034062	
I\$SEG =	000041	L\$REPP	002062	G	PARKDR	006512	PB1219	017271	RINTR	002524	
J\$SETU=	000041	L\$REV	002010	G	PARKIT	026160	PB1220	017330	RSPCHK	030654	
J\$SRV =	000041	L\$SPC	002056	G	PBF0	013422	PB1221	017415	RSPPAK	002352	
I.SUB =	000041	L\$SPCP	002020	G	PBF1	013522	PB1222	017464	RSPRNG	002526	
I\$TST =	000041	L\$SPTP	002024	G	PBF10	014455	PB1223	017557	RSP1	002346	
I\$UDC =	100002	L\$STA	002030	G	PBF2	013651	PB13	013332	RW\$PLL=	140002	
J\$JMP =	000167	L\$TEST	002114	G	PBF3	013725	PB3	012516	R\$CMD =	140012	
LABEL0	037560	L\$TIML	002014	G	PBF4	014021	PB4	012564	R\$DAT =	140010	
LBN	002733	L\$UNIT	002012	G	PBF5	014064	PB5	012636	R\$FPS =	140006	
LOCAL	002312	L10000	002310		PBF6	014131	PB6	012727	SDTCMD	035016	
LOE =	040000	L10002	033116		PBF7	014226	PB7	013031	SDT10	035016	
LOGUNI	002310	L10003	033126		PBF8	014325	PB8	013063	SDT11	037170	
LOPRGI	002546	L10004	033136		PBF9	014415	PB9	013117	SERNBR	002334	
LOT =	000010	L10005	033164		PBSF0	017723	PF2	013335	SER.NB	004250	
LSTCMD	002542	L10006	037470		PB0	012405	PLQC	002314	SETUP	032714	
LSTCRN	002540	L10007	037562		PB1	012434	PNT =	001000	SFBEGT	020550	
LSTVCT	002544	MANBLD	027556		PB10	013161	POLLW	022760	SFCYLT	021234	
L\$ACP	002110	MAXDRV=	000004		PB11	013223	POLLWT	022760	SFDBBT	021016	
L\$APT	002036	MCDNBR	002342		PB11AP	015140	PRGNAM	002676	SFDONT	020571	
L\$AUT	002070	MDLNBR	002340		PB11CR	014515	PRI =	002000	SFFCNT	021307	
L\$AUTO	033120	MOD1	002000	G	PB11EL	015037	PRI00 =	000000	SFFCUT	021255	

Symbol table

SFRBBT	021221	STPRX	025656	TBQ28	010735	T\$NEST-	177777	UIT2	003210
SFRCBT	020736	SVCGBL	= 000000	TBQ29	010765	T\$NS0 =	000000	UIT3	003314
SFRFVT	020615	SVCINS	= 177777	TBQ3	010076	T\$NS1 =	000004	UIT4	003420
SFR1T	020637	SVCSUB	= 177777	TBQ30	011016	T\$PTHV=	***** GX	UIT5	003524
SFR2T	020671	SVCTAG	= 177777	TBQ31	011044	T\$PTNU=	000000	UIT6	003630
SFR3T	021156	SVCTST	= 177777	TBQ32	011106	T\$SAVL =	177777	UIT7	003734
SF10	012273	S\$LSYM	= 010000	TBQ4	010120	T\$SEGL =	177777	UNIT	002330
SFT1	012344	S\$#BUG	026454	TBQ5	010142	T\$SIZE=	***** GX	UNKWN	037404
SFXBBT	021076	S\$#FLA	026456	TBQ6	010164	T\$SUBN=	000000	UNTD SZ	= 000002
SFO	012065	S\$#RTI	026364 G	TBQ7	010206	T\$TAGL =	177777	UNTFLG	002336
SF1	012134	S\$#UDC	026324 G	TBQ8	010230	T\$TAGN =	010010	UNT.NB	006563
SF100	012175	S\$#UDI	026342	TBQ9	010252	T\$TEMP=	000000	VECTOR	002326
SIZDRV	026206	TBLBLD	030342	TERM	035354	T\$TEST=	000001	VEC.AD	004157
SIZEND	026222	TBQ0	007745	TERMIN=	000004	T\$TSTM=	177777	WARNIN	004326
SIZEXI	026270 G	TBQ1	010032	TIMOUT	024150	T\$TSTS=	000001	WRNGST	024210
SIZFLP	025614	TBQ10	010274	TNBR	035566	T\$#AUT=	010003	W\$CMD =	140022
SIZFPS	025604	TBQ11	010317	TNBR12	035402	T\$#CLE=	010004	W\$DAT =	140020
SIZIN	026116	TBQ12	010346	TNBR13	035434	T\$#DU =	010005	W\$FPL =	140004
SIZLOP	025522 G	TBQ13	010405	TYPASC	020032	T\$#HAR=	010007	XBN	002705
SIZNON	025510	TBQ14	010417	TYPDUP	030542	T\$#HW =	010000	X\$ALWA=	000000
SIZRD	026202	TBQ15	010436	TYPE =	177760	T\$#INI=	010002	X\$FALS=	000040
SIZRX	025754	TBQ16	010447	T\$ARGC=	000001	T\$#PRO=	010001	X\$OFFS=	000400
SIZRX3	026050	TBQ17	010474	T\$CODE=	001004	T\$#TES=	010006	X\$TRUE=	000020
SIZSET	025432	TBQ18	010513	T\$ERRN=	000000	T1	033166 G	\$2	033052
SIZWIN	026056	TBQ19	010532	T\$EXCP=	000000	UAM	- 000200 G	\$3	033072
SIZWT	025412	TBQ2	010054	T\$FLAG=	000041	UIN	002344	\$4	033106
SPCL	037100	TBQ20	010565	T\$FREE=	***** GX	UITADR	002320	.A.DEF=	000040
SPECL	= 000006	TBQ21	010615	T\$GMAN=	000000	UITDF	004040	.A.FAT=	000120
SP2INT	023672	TBQ22	010647	T\$HILI=	030071	UITLOC	030312	.A.INF=	000060
SP3INT	023762	TBQ23	010662	T\$LAST=	000001	UITOTH=	000010	.A.QUE=	000020
SP4INT	024042	TBQ24	010675	T\$LOLI=	000001	UITSIZ=	000104	.A.TER=	000100
STDALN	= 000001	TBQ25	010710	T\$LSYM=	010000	UITO	003000	.A.TYP=	000020
STEPMD	025750	TBQ26	010723	T\$LTNO=	000001	UIT1	003104	.B.SPL=	000140
STEPOU	025734								

. ABS. 037566 000 (RW,I,GBL,ABS,OVR)  
 000000 001 (RW,I,LCL,REL,CON)  
 Errors detected: 0

\*\*\* Assembler statistics

Work file reads: 332  
 Work file writes: 338  
 Size of work file: 39752 Words ( 156 Pages)  
 Size of core pool: 19684 Words ( 75 Pages)  
 Operating system: RSX 11M/PLUS (Under VAX/VMS)

Elapsed time: 00:04:22.27  
 ZRQCCO.ZRQCCO.LST/-SP=SVC35R/ML,ZRQCCO.MAC