

TK50 DATA RELIAB TST CZTKBA0

TEST NO.	TEST NAME	TEST TYPE	TEST RESULT	TEST DATE	TEST TIME	TEST OPERATOR	TEST LOCATION	TEST EQUIPMENT	TEST COMMENTS
1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67
68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100

100 01 100
05 05 05
00 00 00

.REM @

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43

IDENTIFICATION

PRODUCT CODE:	AC - T773A - MC
PRODUCT NAME:	CZTKBAO TK50 DATA RELIABILITY
PRODUCT DATE:	17 - APRIL - 1985
MAINTAINER:	TAPE OPTICAL DIAGNOSTIC ENGINEERING
AUTHOR:	BRIAN T. LEBLANC

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS DOCUMENT.

NO RESPONSIBILITY IS ASSUMED FOR THE USE OR RELIABILITY OF SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL OR ITS AFFILIATED COMPANIES.

COPYRIGHT (C) 1985 BY DIGITAL EQUIPMENT CORPORATION

THE FOLLOWING ARE TRADEMARKS OF DIGITAL EQUIPMENT CORPORATION:

DIGITAL	PDP	UNIBUS	MASSBUS
DEC	DECUS	DECTAPE	

TABLE OF CONTENTS

45		
46		
47		
48		
49		
50		
51		
52		
53		
54		
55		
56		
57		
58		
59		
60		
61		
62		
63		
64		
65		
66		
67		
68		
69		
70		
71		
72		
73		
74		
75		
76		
77		
78		
79		
80		
81		
82		
83		
84		
85		
86		
87		
88		
89		
90		
91		
	1	GENERAL INFORMATION
	1.1	PROGRAM ABSTRACT
	1.2	RUNTIME ENVIRONMENT REQUIREMENTS
	1.3	RELATED DOCUMENTS AND STANDARDS
	1.4	PASS/FAIL CRITERIA
	1.5	DATA COMPARE FUNCTION
	1.6	RESTRICTIONS
	2	OPERATING INSTRUCTIONS
	2.1	USER DIALOGUE
	2.2	HARDWARE QUESTIONS
	2.2.1	DEFINITION OF HARDWARE QUESTIONS
	2.3	SOFTWARE QUESTIONS
	2.3.1	DEFINITION OF SOFTWARE QUESTIONS
	2.4	CONVERSATION MODE TEST QUESTIONS
	2.5	ALLOWABLE COMMANDS
	2.6	SUPERVISOR RUNTIME FLAGS
	3	ERROR INFORMATION
	3.1	ERROR REPORTING
	3.2	COMMANDS
	3.3	TYPE OF ERROR
	3.4	STATUS ERRORS
	3.5	ERROR LOG PACKETS
	3.6	PROGRAM DETECTED ERROR CONDITIONS
	3.7	DRIVE ERRORS
	3.8	HARD ERROR REPORTS
	3.9	SOFT ERROR REPORTS
	4	PERFORMANCE AND PROGRESS REPORTS
	4.1	STATISTICS MATRIX
	4.2	READ ERROR DEFINITION
	4.3	WRITE ERROR DEFINITION
	4.4	MISCELLANEOUS
	5	TEST DESCRIPTIONS
	5.1	TEST 1 BASIC FUNCTION TEST
	5.2	TEST 2 QUICK VERIFY WRITE/READ TEST
	5.3	TEST 3 COMPLEX WRITE/READ TEST
	5.4	TEST 4 WRITE INTERCHANGE TAPE
	5.5	TEST 5 READ UNKNOWN TAPE
	5.6	TEST 6 START/STOP WRITE/READ TEST
	5.7	TEST 7 CONVERSATION MODE TEST

93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117
118
119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142
143
144
145
146
147
148
149

1 GENERAL INFORMATION

1.1 Program Abstract

The TK50 PDP11 Q-bus Data Reliability program will exercise the TK50 and establish the performance quality of each unit through the accumulation of statistics. Predetermined sequences of operations will permit read and write compatibility (Media Interchange testing) and data reliability testing. This program will be designed to run in a PDP11 Q-bus XXDP+ environment.

The Data Reliability program will detect functional faults, but will not provide diagnostic isolation to the field replaceable unit.

The PDP11 Q-bus TK50 Data Reliability program is intended for the following users:

1. Quality and user audit functions,
2. F A & T at our various facilities,
3. Field service personnel,
4. DEC customers who choose to provide their own maintenance.

Program uses include but are not limited to the following:

1. Determination of a unit's specific performance (error rate)
2. Fault detection,
3. Repair verification,
4. Installation verification,
5. Preventive maintenance software tool.

This program will exercise up to 4 TK50's in a round-robin manner. It will require 28KW of memory. One default pass will be when a tape cartridge (600') has been started at the beginning of tape (BOT) marker and has passed all available tape to the end of tape (EOT) marker over the tape head, twice. One End Of Pass (EOP) will require approximately 1 hour and 10 minutes for each unit under test.

1.2 Runtime Environment Requirements

Run time environment requirements include:

1. XXDP+ Diagnostic Supervisor
2. PDP11 family Q-bus CPU,
3. 28KW of memory,

150
151
152
153
154
155
156
157
158
159
160
161
162
163
164
165
166
167
168
169
170
171
172
173
174
175
176
177
178
179
180
181
182
183
184
185
186
187
188
189
190
191
192
193
194
195
196
197
198
199
200
201
202
203
204
205
206

4. an XXDP Load Device,
5. Console Terminal,
6. 1 to 4 TK50 drives with controllers,
7. 1 scratch tape cartridge / TK50

1.3 Related Documents And Standards

The TK50 Data Reliability program will run under the XXDP+ operating system, and will be Supervisor compatible. The program, with the supervisor will run on all PDP11 Q-bus processors.

This program will conform to the following documents:

1. EL-ENDIA-11 "PDP11 Diagnostic Design Guide",
2. PDP Diagnostic Quality Assurance Checklist,
3. Software Development Policies And Procedures Manual,
4. DEC Std 100,
5. UNIBUS/Q-bus Storage Systems Port Spec Version 2.1
6. Magnetic Tape Mass Storage Control Protocol Spec Version 1.6
7. Mass Storage Control Protocol Spec Version 1.2

1.4 Pass/Fail Criteria

A unit under test will not pass the data reliability mode of testing if any of the following error conditions have occurred during the test cycle:

1. Any irrecoverable write errors detected as documented in the TK50 product specification,
2. Any irrecoverable read errors detected as documented in the TK50 product specification,
3. Irrecoverable hardware errors have occurred,
4. CRC recoverable read errors which exceed TBD errors in 10 to the 11th bits read
5. ECC recoverable read errors which exceed TBD errors in 10 to the 11th bits read

207
208
209
210
211
212
213
214
215
216
217
218
219
220
221
222
223
224
225
226
227
228
229
230
231
232
233
234
235
236
237

If less than the required data has been transferred, the confidence that the unit has met the error rate is diminished. That is to say if the program is run in a quick verify mode, the unit may be accepted as error free but only with a low degree of confidence.

1.5 Data Compare Function

The time required to perform 100% software data comparisons is entirely prohibitive for streaming tape drives. This problem is further exacerbated by the asynchronous nature of command execution under TMSCP and program size limitations which dictate the allocation of a single read data buffer.

To minimize the impact of all this, tests 2 and 3 (the only tests which will perform software data compares) will do software data compares on every 4th record. To avoid the problem of performing data compares on a dynamic read buffer, 3 records will be read from tape using the Access command.

1.6 Restrictions

This program is not intended for use as an isolation tool to detect a fault to the single Field Replaceable Unit (FRU). As such, it will not contain scope loops for that purpose. The parameter selection process, discussed later in this document, is meant to be used only for functional fault detection and unit isolation.

239
240
241
242
243
244
245
246
247
248
249
250
251
252
253
254
255
256
257
258
259
260
261
262
263
264
265
266
267
268
269
270
271
272
273
274
275
276
277
278
279
280
281
282
283
284
285
286
287
288
289
290
291
292
293
294
295

2 OPERATING INSTRUCTIONS

2.1 User Dialogue

The following user dialogue will be provided by the diagnostic to allow the operator to establish certain operational parameters of the program.

2.2 Hardware Questions

This set of questions must be answered by operator when the program is first started.

CHANGE HARDWARE (L) ? no default

NUMBER OF UNITS (D) ?

UNIT x
TKIP ADDRESS (O) 774500 ?
T/MSCP UNIT NUMBER (O) 0 ?

x = Number of unit the p-table is
being built for.

Unit specific prompting will continue for a maximum of 4 times, depending on the users response to the "NUMBER OF UNITS" question.

2.2.1 Definition Of Hardware Questions -

CHANGE HARDWARE - If you want to change the hardware p-table to be used in the testing this question must be answered yes. This question must be answered with a yes on the initial start of the program.

NUMBER OF UNITS - Number of units to test in decimal.

TKIP ADDRESS - The base address for this unit.

T/MSCP UNIT NUMBER - The unit number of the controller board as specified by MSCP.

2.3 Software Questions

Answering of the software questions is always optional. Default values for a specific question can be obtained simply by typing a <CR>.

CHANGE SW (L) ? no default

ENABLE TIME OF DAY CLOCK (L) N ?
INPUT HOUR IN 24 HOUR FORMAT (OMIT LEADING ZERO) (D) 0 ?
INPUT MINUTES (OMIT LEADING ZERO) (D) 0 ?
CHANGE CONTROLLER PARAMETERS (L) N ?
ENABLE CONTROLLER ERROR CORRECTION (L) Y ?
ENABLE CONTROLLER ERROR RECOVERY (L) Y ?
ENABLE PAD BLOCKING (L) Y ?
CHANGE PRINTING PARAMETERS (L) N ?
ENABLE SOFT ERROR REPORT PRINTING (L) N ?

296 ENABLE READ SOFT ERRORS ONLY (L) Y ?
 297 CLEAR MEDIA TABLE ON EVERY PASS (L) N ?
 298 ENABLE PRINTING OF MEDIA DEFECTS TABLE (L) N ?
 299 ENABLE PROGRAM VARIABLES DUMP ON ERROR (L) N ?
 300 ENABLE CLEAR STATS ON FATAL ERROR (L) N ?
 301 CHANGE TEST PARAMETERS (L) N ?
 302 DATA PATTERN (D) 0 ?
 303 RUN TEST 3 ONLY (L) Y ?
 304 ENABLE DATA COMPARES IN TEST 5 (L) Y ?
 305 ENABLE PRINT READ BUFFER IN TEST 5 (L) N ?
 306 CHANGE COMMAND SEQUENCE (L) N ?
 307
 308
 309

2.3.1 Definition Of Software Questions -

ENABLE TIME OF DAY CLOCK (L) N ?

The default is to not enable the clock. This question allows the operator to start a program clock to track time on a 24 hour basis during the running of the program. The clock will remain fairly accurate as long as the program is running. Any time you stop the program the clock will stop running. It is therefore necessary to reset the time whenever the program is started.

INPUT HOUR IN 24 HOUR FORMAT (OMIT LEADING ZEROS) (D) 0 ?

Input the hour in a decimal number leaving off any leading zeros.

INPUT MINUTES (OMIT LEADING ZEROS) (L) 0 ?

Input the minutes in a decimal number leaving off any leading zeros.

CHANGE CONTROLLER PARAMETERS (L) N ?

The default answer (no) prohibits the asking of the controller parameter questions. To change the controller parameters type a Y.

ENABLE CONTROLLER ERROR CORRECTION (L) Y ?

If answered "yes" (default) the program will enable the controller's error correction algorithms for read errors.

ENABLE CONTROLLER ERROR RECOVERY (L) Y ?

If answered "yes" (default) the program will enable the controller's error recovery algorithms for write and read errors.

ENABLE PAD BLOCKING (L) Y ?

310
 311
 312
 313
 314
 315
 316
 317
 318
 319
 320
 321
 322
 323
 324
 325
 326
 327
 328
 329
 330
 331
 332
 333
 334
 335
 336
 337
 338
 339
 340
 341
 342
 343
 344
 345
 346
 347
 348
 349
 350
 351
 352

353
354
355
356
357
358
359
360
361
362
363
364
365
366
367
368
369
370
371
372
373
374
375
376
377
378
379
380
381
382
383
384
385
386
387
388
389
390
391
392
393
394
395
396
397
398
399
400
401
402
403
404
405
406
407
408
409

If answered "yes" (default) the program will enable the controller's pad blocking algorithms to assist in streaming

CHANGE PRINTING PARAMETERS (L) N ?

The default answer (no) prohibits the asking of the printing parameter questions. To change the printing parameters type a Y.

ENABLE SOFT ERROR REPORTS (L) N ?

The default answer (no) inhibits the printing, but not the tallying of soft errors as reported by the subsystem. Answering the question "yes" will result in detailed error reports on the terminal for each recoverable data error.

ENABLE READ SOFT ERRORS ONLY (L) N ?

This question will only be asked when the above question is answered no. This question allows the operator to enable print outs on read soft errors only. The default answer is to inhibit all soft error printouts.

CLEAR MEDIA TABLE ON EVERY PASS (L) N ?

The default answer (no) allows the tallying of media defects over multiple passes. By answering the question yes, the operator can then print the table on every pass and see how the defects are affected by passing over the heads.

ENABLE PRINTING OF MEDIA DEFECTS TABLE (L) N ?

The default answer (no) inhibits the printing, but not the tallying of media defects as reported in the soft error reports by the subsystem. If the default answer is used the table may still be printed by giving the PRINT command at the supervisor prompt (DS>) after the termination of the program. Answering the question "yes" will cause the printing of the table after every pass and after a control C (C) is issued.

ENABLE CLEAR STATS ON FATAL ERROR (L) N ?

The default answer (no) allows the accumulation of statistics from pass to pass. An answer of "yes" results in the clearing of a devices statistical matrix following any error that results in the unit's being dropped from the test sequence for the rest of the current pass. This action is intended for use primarily by Springfield volume manufacturing.

ENABLE PROGRAM VARIABLES DUMP ON FATAL ERROR (L) N ?

410
411 This question is intended as a program and subsystem debug tool.
412 Answering the question "yes" will cause the program to print out the
413 contents of approximately 1K words of critical memory locations. This
414 is a time consuming process and this question should be defaulted
415 under ordinary circumstances.
416
417
418
419 CHANGE TEST PARAMETERS (L) N ?
420
421 The default answer (no) prohibits the asking of the test parameter
422 questions. To change the test parameters type a Y.
423
424 DATA PATTERN (0) 0 ?
425
426 This question allows the user to select a data pattern from the table
427 of patterns provided by the program. (See the Data Pattern section
428 below.) The default answer, "0", causes the program to cycle through
429 all the data patterns. Answering the question with a number from 1-5
430 will causes the program to use that pattern only. A number higher
431 than 5 will cause the question to be repeated.
432
433
434 RUN TEST 3 ONLY (L) Y ?
435
436 Answering this question "Y" (default) will automatically cause the
437 program to run test 3 only; i.e., it will no longer be necessary to
438 use the /TES:3 switch to the start command. Please note that this
439 question will effectively override the /TES: switch if the user
440 wishes to run a test other than 3. That is, if the user wants to run
441 test 4 he must specify the /TES:4 switch AND answer this question "N".
442
443
444 ENABLE DATA COMPARES IN TEST 5 (L) N ?
445
446 The default answer (no) disallows the data compare function during
447 test 5. This would have to be the case when running with a truly
448 unknown tape. The option (yes) is given to the operator so that when
449 a tape is written in a known manner using this program the operator
450 can then run test 5 using data compares.
451
452
453 ENABLE PRINT READ BUFFER IN TEST 5 (L) N ?
454
455 Answering this question "yes" will cause a printout of all data read
456 from tape in test 5. The data will be presented on a record basis.
457 This is a time consuming process, and this question should be
458 defaulted except in special cases.
459
460 CHANGE COMMAND SEQUENCE (L) N ?
461
462 Answering this question "Y" will cause the program to prompt the user
463 for a sequence of commands to be used in Test 7. (See Test 7 below.)
464 If defaulted, this is the last software question asked.
465
466

467
468
469
470
471
472
473
474
475
476
477
478
479
480
481
482
483
484
485
486
487
488
489
490
491
492
493
494
495
496
497
498
499
500
501
502
503
504
505
506
507
508
509
510
511
512
513
514
515
516
517
518
519
520
521
522
523

2.4 Conversation Mode Test Questions

Answering of these question is optional. These questions will not be asked unless the operator has answered the CHANGE COMMAND SEQUENCE question with a yes. A total of seven commands may be entered by the operator.

Test 7 is intended to give the user the ability to create a specific sequence of commands. Note that Test 7 will not support the entire TMSCP command repertoire, it is limited primarily to the tape motion commands. To run Test 7, the user must issue a STA/TES:7 and must answer "Run Test 3 Only" with a N(0). The user must also answer "Change Command Sequence" with a Y (yes). Understand that the program does not check for legality of command sequences issued by the user, the onus is on the user to perform this check.

The following questions will be asked by the program to prompt the user for his input.

CMD/1 (0) 160 ?

The user enters the octal value for the desired command from the list shown below. Please note that the command values are those defined by the diagnostic, not by TMSCP. The default value for the first command is a rewind.

DATA PATTERN (0) 1 ?

The user should enter the octal value of the desired data pattern from the table of patterns shown above. If the command does not use a data pattern, any number entered here is ignored.

PATTERN #	DESCRIPTION
-----	-----
0	ROTATE THROUGH ALL DATA PATTERNS
1	ALL 1'S
2	ALL 0'S
3	WORST-CASE MFM PEAK SHIFT (110)
4	ALTERNATE 1'S AND 0'S
5	RANDOM DATA
6	MW PEAK SHIFT (1110)
7	COMBINATION OF PATTERN 3 AND 5
200	NO DATA PATTERN USED

ITEM COUNT (BYTE, RECORD, OBJECT) (D) 0 ?

The purpose of this field varies with the type of command. For example, for write and read commands, the user may specify the record size, in decimal bytes. If the command is a reposition command, the user may specify the number of records, objects or file marks. There are also two special commands provided which use this value in unique

524
525
526
527
528
529
530
531
532
533
534
535
536
537
538
539
540
541
542
543
544
545
546
547
548
549
550
551
552
553
554
555
556
557
558
559
560
561
562
563
564
565
566
567
568
569
570
571
572
573
574
575
576
577
578
579
580

ways. For a branch command, the user would specify the command number to which (s)he wishes to branch. For the delay command, the value entered here is the relative delay length, with larger numbers producing longer delays. User experimentation may be required to produce desired delay.

ITERATION COUNT (D) 1 ?

This field allows the user to specify how many times the command should be issued before the program issues the next command. The value is entered in decimal.

Additional Commands

This same sequence of four questions will be repeated up to 6 more times, allowing the operator to create a command table with seven unique commands. The only noticeable difference in question format is that each time the command question is asked, its relative position in the Test 7 command table is identified.

2.5 Allowable Commands

The following commands are supported by Test 7. Please remember that the octal values are defined by the program and have no numerical correlation to TMSCP command opcodes. Also note that the diagnostic does not check for legality of the value entered or for valid command sequences. Operator error in either of these cases could result in bizarre program behavior.

Octal	Command	Description
10	RD	Read forward
20	WR	Write
30	CMP	Compare host data
40	ACC	Access
50	SPC	Space records
51	SCR	Space records reverse
60	SKP	Skip tape marks
61	SKR	Skip tape marks reverse
70	SPO	Space objects
71	SPR	Space objects reverse
100	WTM	Write tape mark
160	REW	Rewind
300	BR	Branch - item count specifies destination
310	DLY	Delay - item count specifies relative delay
377	END	End of sequence - necessary if sequence has less than 7 commands

2.6 Supervisor Run Time Flags

This program will support all of the PDP11 Diagnostic Supervisor flags except for those mentioned here.

LOE - Loop on Error - This flag will not be supported by this program.

581
582
583
584
585
586
587

Data reliability programs do not lend themselves to implementation of error loops.

IDR - Inhibit Drop Units - This flag will not be supported by this program due to the devices sequential operation. If an error of fatal extent happens on the device there is no way to continue running in any meaningful way.

589
590
591
592
593
594
595
596
597
598
599
600
601
602
603
604
605
606
607
608
609
610
611
612
613
614
615
616
617
618
619
620
621
622
623
624
625
626
627
628
629
630
631
632
633
634
635
636
637
638
639
640
641
642
643
644
645

3 ERROR INFORMATION

3.1 Error Reporting

TKDR provides a variety of information in its error printouts, most of which is self-explanatory. The following information is intended to clarify certain messages and abbreviations used.

3.2 Commands

All error printouts will contain a field indicating the command on which the error was detected. Refer to the TMSCP specification for detailed descriptions of these commands. Also, please note that commands currently used by TKDR are indicated by an asterisk.

RD*	read
WRT*	write
CMP	compare host data
ACC*	access
SPC*	space records (position)
SKP*	skip tape marks (position)
SPO*	space objects (position)
WTM*	write tape mark
ERS	erase
ERG	erase gap
AVL*	available
ONL*	online
SUC	set unit characteristics
REW*	rewind (position)
ABO	abort
GCS*	get command status
GUS*	get unit status
SCC*	set controller characteristics

The following two "commands" are used by TKDR for special purposes and are not actually sent as commands to the subsystem:

NUL	null - used by program to while waiting for last responses to real commands
INT	initialize - used by program to invoke the UQ-Port init sequence

3.3 Type Of Error

Each error message includes one line of text intended to describe the type of error detected. There are three distinct sources of information used by the program to generate the text message: the status field of an end packet; an error log packet; and program detected error conditions.

3.4 Status Errors

646 These messages are derived from the status field of an end packet
 647 and correspond directly to the status codes as defined in the TMSCP
 648 specification.
 649

650 Invalid command issued
 651 Command aborted
 652 Unit offline
 653 Unit available error
 654 Unit write protected
 655 Data compare error
 656 Data error
 657 Host buffer access error
 658 Controller error
 659 Drive error
 660 Formatter error
 661 BOT encountered
 662 Tape mark encountered
 663 Data record truncated
 664 Position lost
 665 Serious exception
 666 Logical EOT encountered
 667
 668
 669

670 3.5 Error Log Packets

671 Certain messages will be generated as a result of receiving the
 672 "diagnostic mode" error log packet.
 673

674 Retriable Data
 675 Hard CRC
 676 Data Underrun
 677 Data Overrun
 678 ECC Corrected
 679 CRC Error on ECC Block
 680
 681
 682
 683

684 3.6 Program Detected Error Conditions

685 In addition to reporting errors detected by the subsystem, TKDR
 686 may generate additional error reports based on problems it detects.
 687 These error conditions are presented and defined here.
 688

689 Invalid status received - the contents of the status field of an end
 690 packet is not a valid status as defined by
 691 TMSCP
 692
 693 Port-detected error - examination of the SA register indicated an
 694 error condition exists within the controller
 695
 696 Program command timeout - the program received no end packet from the
 697 subsystem within the predefined command time-
 698 out.
 699
 700 Response out of sequence - the program received an end packet for a
 701
 702

703 sequential command other than the oldest out-
 704 standing command.
 705
 706
 707 Port initialization failed - the port failed to make an expected step
 708 transition during the UQ-Port init sequence.
 709
 710 Software data compare - the program's data compare routine detected a
 711 miscomparison of read data to expected data.
 712
 713 Record length short - the data record read from tape was shorter than
 714 the record length expected.
 715

3.7 Drive Errors

716
 717
 718 On occurrence of a Drive Error, status code of 13(8), the error
 719 log packet will now contain a status code which is the drive error
 720 byte as returned by the drive. This value will be placed in the DRV
 721 CODE field of the error log packet.
 722

723 To understand the precise nature of the error condition it will
 724 be necessary to correlate the value presented in the printout against
 725 the table below.
 726

727	Octal	Hex	Description
728	1	01	Write lock violation
729	2	02	Drive fault
730	4	04	Communication exception (timeout, etc.)
731	6	06	Wrong track error (following a turnaround)
732	10	08	No cable or drive powered off
733	20	10	Synchronization failure - write/read
734	23	13	
735	44	22	
736	45	23	
737	47	27	
738	201	81	Failure to load to BOT
739	202	82	Failure to unload tape into cartridge
740	203	83	General motor or tach failure
741	204	84	Motor A failure
742	205	85	Motor B failure
743	206	86	Drive lost control of tape or bad tach
744	207	87	Excessive drag in tape transport
745	210	88	Failure to stop tape or remain stopped
746	211	89	Cartridge insert error
747	212	8A	Cartridge extract error
748	213	8B	CU attempted to move tape with drive in error
749	214	8C	Deceleration timeout error
750	215	8D	Second attempt to balance reels in init failed
751	220	90	8155 RAM memory failure in self-test
752	221	91	8155 timer failure
753	222	92	Read amplit (Hd 1) too low in calibrate
754	223	93	Read amplit (Hd 2) too low in calibrate
755	225	95	EOT sensed in R/W/S
756	226	96	BOT sensed in R/W/S
757	227	97	Drive block address overflow
758			
759			

760	230	98	Drive block address underflow
761	231	99	Servo error - excessive speed variations
762	231	9A	Failure in tracking - currently not used
763	233	9B	Command error - not recognized
764	234	9C	Illegal command - incompatible with drive state
765	235	9D	Write lock error
766	236	9E	Write gate at wrong time
767	237	9F	No write gate for calibration track write
768	240	A0	Error sensing cal track 1 - bad head?
769	241	A1	Error sensing cal track 2 - bad head?
770	242	A2	Detection of edges of cal trk 1 out of spec
771	243	A3	Detection of edges of cal trk 2 out of spec
772	244	A4	Offset of cal trk 2 from 1 is too great
773	245	A5	Search for bottom edge of tape failed
774	246	A6	Bottom tape edge tolerance error
775	247	A7	Drive is overheating
776			
777	250	A8	No current in LED of BOT sensor (cable?)
778	251	A9	Hall switch sense lines Motor A questionable
779	252	AA	Tachometer failure

3.8 Hard Error Reports

Hard error reports, if not user disabled, will be generated anytime an error recovery process does not successfully complete.

Hard Error reports will typically be of the following format:

```
CZTKB HRD ERR 00014 ON UNIT 00 TST 003 SUB 000 PC: 020460
HARD DATA ERROR
COMMAND: RD      T/MSCP UNIT: 000(0)
PASS: 1(D)      DATA PAT: 01(0)
RECORD BYTE COUNT: 457(D)
OBJECT CNT : 000000026352(0)
```

RESPONSE PACKET

HIGH WORD	LOW WORD
000000(0)	026532(0)
000000(0)	000000(0)
000050(0)	010240(0)
000000(0)	000733(0)
000000(0)	000000(0)
000000(0)	000000(0)
000000(0)	000000(0)
000000(0)	001413(0)
000000(0)	000733(0)

NOTE

Some error reports will not include a Response Packet field. For example a Command Timeout Error, by definition, results only when no response to a command has been received prior to expiration of the programs watch dog timer.

760
761
762
763
764
765
766
767
768
769
770
771
772
773
774
775
776
777
778
779
780
781
782
783
784
785
786
787
788
789
790
791
792
793
794
795
796
797
798
799
800
801
802
803
804
805
806
807
808
809
810
811
812
813
814
815
816

817
818
819
820
821
822
823
824
825
826
827
828
829
830
831
832
833
834
835
836
837
838
839

3.9 Soft Error Reports

Soft error reports, if not user disabled, will be generated anytime an error recovery process is successful. The soft error report will include the number of retries necessary in order to successfully complete the current operation. Soft Error reports will typically be of the following format:

CZTKB SFT RD ERR 00014 ON UNIT 00 TST 003 SUB 000 PC: 020460
ECC RECOVERED DATA ERROR
COMMAND: RD T/MSCP UNIT: 000(0)
PASS: 1(D) DATA PAT: 01(0)
OBJECT CNT : 000000026352(0)
TAP OBJ CNT: 000000026352(0)
TRK NUM: 6(D) LEVEL: 0(D) RETRIES: 1(D)
LOG BLK NUM: 0(D) PHYS BLK NUM: 9932(D)
DRV CODE: 000(0) DRV FLGS: 041(0)
DRV STATE: 000000(0) INTERN STATUS: 002(0)
TAP CNT 0: 227(0) TAP CNT 1: 015(0)
TAP CNT 2: 035(0) RD/WR STATE: 000000(0)
OPER FLGS: 000000(0)

841
842
843
844
845
846
847
848
849
850
851
852
853
854
855
856
857
858
859
860
861
862
863
864
865
866
867
868
869
870
871
872
873
874
875
876
877
878
879
880
881
882
883
884
885
886
887
888
889
890
891
892
893
894
895
896
897

4 PERFORMANCE AND PROGRESS REPORTS

4.1 Statistics Matrix

	READ		WRITE			
	CH 1	CH 2	CH 1	CH 2		
SOFT DATA ERRORS						
RETRY RECOVERED	X	X	X	X		
ECC CORRECTED	X	X	N.A.			
HARD DATA ERRORS	X	X	X	X		
CRC ON ECC BLOCK	X	X	N.A.			
DATA COMPARE ERRORS		X	N.A.			
DATA UNDERRUN		N.A.	X			
DATA OVERRUN		X	N.A.			
MISPOSITIONS		X	X			
OTHERS		X				
TIMES DROPPED		X				
BYTES WRITTEN	X,XXX,XXX,XXX					
BYTES READ	X,XXX,XXX,XXX					
	TRK	PHY BLK	HWR	HRD	SWR	SRD
	0	26	0	0	1	0
	0	2474	0	0	1	0
	1	126	0	0	1	0
	1	10374	0	0	1	0

4.2 Read Error Definition

1. SOFT DATA ERRORS

- 0 Retry Corrected - ECC disabled or repositioning was required because >1 block in ECC group was bad.
- 0 ECC Corrected - CRC error occurred on data block but ECC has corrected it

2. Hard Data Errors - Maximum retries exhausted and data not recovered.

3. CRC Error on ECC Block - Data was read successfully, but CRC error occurred

4. Data Compare - No hardware detected errors, but the data compare failed. on an associated ECC block.

5. Data Overrun - The controller did not have sufficient buffer space for read data.

898
899
900
901
902
903
904
905
906
907
908
909
910
911
912
913
914
915
916
917
918
919
920
921
922
923
924
925

4.3 Write Error Definition

1. Retry Recovered - Operational write algorithm was enabled and controller successfully recovered from a write error. (In this case, media-induced write errors will appear in this category.)
2. Hard Data Errors - Write retries exhausted and block not successfully written.
3. Underrun - Controller ran out of write data blocks prior to a record boundary.

4.4 Miscellaneous

1. Mispositions - Times the drive lost position on tape.
2. Others - This is a tally of all errors not specifically called out in the error matrix.
3. Times Dropped - Times the drive has been dropped by the program.

927
928
929
930
931
932
933
934
935
936
937
938
939
940
941
942
943
944
945
946
947
948
949
950
951
952
953
954
955
956
957
958
959
960
961
962
963
964
965
966
967
968
969
970
971
972
973
974
975
976
977
978
979
980
981
982
983

5 TEST DESCRIPTIONS

5.1 Test 1 Basic Function Test

This test will execute a subset of the available commands on the unit under test. It serves as a quick verify test to ascertain that the unit can move tape and write/read predictably, without error. The subset of legal commands will be issued in a coherent manner.

The testing sequence, performed once will be as follows:

1. Execute online
2. Rewind to ensure that tape is at BOT,
3. Write two tapemarks, just after BOT,
4. Backspace two tapemarks,
5. Space forward to LEOT,
6. Rewind,
7. Write, using increasing byte counts, rotating through all data patterns, using decreasing file lengths. Files to be separated by tape marks.
8. Write LEOT after previous sequence,
9. Rewind,
10. Read records of the first file,
11. Space records over the second and third files,
12. Space objects over the fourth file,
13. Read records of the fifth file,
14. Skip reverse over four tape marks,
15. Skip forward one tape mark,
16. Read the second file set,
17. Space objects over the third record set,
18. Read the fourth record set,
19. Space objects to LEOT,
20. Space objects reverse to Just after BOT,
21. Skip four tape marks,
22. Space records over the fourth record set,

- 984 23. Skip a tape mark,
985
986 24. Read the sixth record set,
987
988 25. Skip two tape marks,
989
990 26. Space objects reverse to the end of the second file set,
991
992 27. Skip a tape mark,
993
994 28. Read the third file set,
995
996 29. Rewind tape,
997
998
999

5.2 Test 2 Quick Verify Read/Write Test

This test rewinds the tape, then executes the following sequence:

1. Write record set,
2. Write LEOT,
3. Rewind,
4. Reposition to just written record set,
5. Read the current record set,
6. Skip to LEOT.

for 5 iterations or until fatal error is encountered. This test permits retries, fixed record length (4096 bytes decimal), fixed number of records/set (250), and predetermined data patterns. This test will execute in a round-robin manner.

5.3 Test 3 Complex Read/Write Test

This test rewinds the tape, and executes the following sequence:

1. Write N records,
2. Write a tape mark,
3. Repeat 1 and 2 until EOT is reached,
4. Write 2 tape marks (LEOT),
5. Rewind,
6. Read N records,
7. Space 1 record (should see unexpected tape mark)

1000
1001
1002
1003
1004
1005
1006
1007
1008
1009
1010
1011
1012
1013
1014
1015
1016
1017
1018
1019
1020
1021
1022
1023
1024
1025
1026
1027
1028
1029
1030
1031
1032
1033
1034
1035
1036
1037
1038
1039
1040

1041
1042
1043
1044
1045
1046
1047
1048
1049
1050
1051
1052
1053
1054
1055
1056
1057
1058
1059
1060
1061
1062
1063
1064
1065
1066
1067
1068
1069
1070
1071
1072
1073
1074
1075
1076
1077
1078
1079
1080
1081
1082
1083
1084
1085
1086
1087
1088
1089
1090
1091
1092
1093
1094
1095
1096
1097

8. Repeat 6 and 7 until LEOT.

Number of records (N), and record size will be randomly selected. This sequence will permit hardware retries, if enabled by the operator. This test will run until EOT, LEOT or fatal error is detected. All data patterns including random data will be used in this test.

5.4 Test 4 Write Interchange Tape

This test will rewind the tape, then write until EOT or a fatal error is encountered. This test will keep track of the number of records and files written. If a fatal error is encountered, a message will report it, the tape on the unit will be rewound, and the unit prevented from executing further write operations.

5.5 Test 5 Read Unknown Tape

This test will rewind a tape, then read until EOT, LEOT or fatal error is encountered. This test will keep track of the number of records and files read. If a fatal error is encountered, a message will report it, the tape on the unit will be rewound, and the unit prevented from executing further read operations.

NOTE

Tests 4 and 5 can be used to perform a media interchange test for multiple drives. The program will not attempt to make any determination as to whether the unit that wrote the tape or the unit reading the tape is at fault for any errors.

5.6 Test 6 Start/Stop Write/Read Test

This test rewinds the tape, then executes the following sequence:

1. Write record set, stopping between each record,
2. Write a tape mark,
3. Repeat steps one and two until two tracks have been written,
4. Write LEOT,
5. Rewind,
6. Read the record set stopping between each record,
7. Skip a tape mark,
8. Repeat steps six and seven until LEOT is detected,

1098
1099
1100
1101
1102
1103
1104
1105
1106
1107
1108
1109
1110
1111
1112
1113
1114
1115
1116
1117

9. Rewind.

Until fatal error is encountered. This test permits retries, fixed record length (8096 bytes decimal), fixed number of records/set (250), and predetermined data patterns. This test will execute in a round-robin manner.

5.7 Test 7 Conversation Test

Conversation mode will run with or without error reports. The user can select, from a list of commands, a sequence which can be used to emulate a known failure mode. Between commands, the user can specify unique delays, ranging from 10 to 250 ms. The user can follow each tape command with integer values, the first indicating the byte/record/file count and the second indicating the # of repetitions necessary for that command.

@


```

1123
1134 .TITLE PROGRAM HEADER AND TABLES
1135 .SBTTL PROGRAM HEADER
1161
1163 000000 .ENABL ABS,AMA
1164 002000 = 2000
1166
1167 002000 BGNMOD
1168
1169 ;**
1170 ; THE PROGRAM HEADER IS THE INTERFACE BETWEEN
1171 ; THE DIAGNOSTIC PROGRAM AND THE SUPERVISOR.
1172 ;--
1173
1174 002000 POINTER BGNSW,BGNSFT,BGNRPT,ERRTBL,BGNDU,BGNSETUP
1175
1183
1184
1185 002000 HEADER CZTKB,A,0,15000,1,0
002000 L$NAME:: ;DIAGNOSTIC NAME
002000 103 .ASCII /C/
002001 132 .ASCII /Z/
002002 124 .ASCII /T/
002003 113 .ASCII /K/
002004 102 .ASCII /B/
002005 000 .BYTE 0
002006 000 .BYTE 0
002007 000 .BYTE 0
002010 L$REV:: ;REVISION LEVEL
002010 101 .ASCII /A/
002011 L$DEPO:: ;0
002011 060 .ASCII /0/
002012 L$UNIT:: ;NUMBER OF UNITS
002012 000001 .WORD T$PTHV
002014 L$TIML:: ;LONGEST TEST TIME
002014 015000 .WORD 15000
002016 L$HPCP:: ;PTR. TO H.W. QUES.
002016 046236 .WORD L$HARD
002020 L$SPCP:: ;PTR. TO S.W. QUES.
002020 046324 .WORD L$SOFT
002022 L$HPTP:: ;PTR. TO DEF. H.W. PTABLE
002022 002204 .WORD L$HW
002024 L$SPTP:: ;PTR. TO S.W. PTABLE
002024 002212 .WORD L$SW
002026 L$LADP:: ;DIAG. END ADDRESS
002026 115736 .WORD L$LAST
002030 L$STA:: ;RESERVED FOR APT STATS
002030 000000 .WORD 0
002032 L$CO:: .WORD 0
002032 000000 .WORD 0
002034 L$DTYP:: ;DIAGNOSTIC TYPE
002034 000001 .WORD 1
002036 L$APT:: ;APT EXPANSION
002036 000000 .WORD 0
002040 L$DTP:: ;PTR. TO DISPATCH TABLE
002040 002124 .WORD L$DISPATCH
002042 L$PRIO:: ;DIAGNOSTIC RUN PRIORITY

```

002042	000000		.WORD	0	
002044		L\$ENVI::			;FLAGS DESCRIBE HOW IT WAS SETUP
002044	000000		.WORD	0	
002046		L\$EXP1::			;EXPANSION WORD
002046	000000		.WORD	0	
002050		L\$MREV::			;SVC REV AND EDIT #
002050	004		.BYTE	C\$REVISION	
002051	000		.BYTE	C\$EDIT	
002052		L\$EF::			;DIAG. EVENT FLAGS
002052	000000		.WORD	0	
002054	000000		.WORD	0	
002056		L\$SPC::			
002056	000000		.WORD	0	
002060		L\$DEVP::			; POINTER TO DEVICE TYPE LIST
002060	002174		.WORD	L\$DVTYP	
002062		L\$REPP::			;PTR. TO REPORT CODE
002062	034210		.WORD	L\$RPT	
002064		L\$EXP4::			
002064	000000		.WORD	0	
002066		L\$EXP5::			
002066	000000		.WORD	0	
002070		L\$AUT::			;PTR. TO ADD UNIT CODE
002070	000000		.WORD	0	
002072		L\$DUT::			;PTR. TO DROP UNIT CODE
002072	040700		.WORD	L\$DU	
002074		L\$LUN::			;LUN FOR EXERCISERS TO FILL
002074	000000		.WORD	0	
002076		L\$DESP::			;PTR. TO DIAG. DESCRIPTION
002076	002142		.WORD	L\$DESC	
002100		L\$LOAD::			;GENERATE SPECIAL AUTOLOAD EMT
002100	104035		EMT	E\$LOAD	
002102		L\$ETP::			;PTR. TO ERR_TBL
002102	013262		.WORD	L\$ERR_TBL	
002104		L\$ICP::			;PTR. TO INIT CODE
002104	037004		.WORD	L\$INIT	
002106		L\$CCP::			;PTR. TO CLEAN-UP CODE
002106	040372		.WORD	L\$CLEAN	
002110		L\$ACP::			;PTR. TO AUTO CODE
002110	040370		.WORD	L\$AUTO	
002112		L\$PRT::			;PTR. TO PROTECT TABLE
002112	021036		.WORD	L\$PROT	
002114		L\$TEST::			;TEST NUMBER
002114	000000		.WORD	0	
002116		L\$DLY::			;DELAY COUNT
002116	000000		.WORD	0	
002120		L\$HIME::			;PTR. TO HIGH MEM
002120	000000		.WORD	0	

```

1187          .SBTTL DISPATCH TABLE
1188
1189          ;**
1190          ; THE DISPATCH TABLE CONTAINS THE STARTING ADDRESS OF EACH TEST.
1191          ; IT IS USED BY THE SUPERVISOR TO DISPATCH TO EACH TEST.
1192          ;--
1193
1194          002122          DISPATCH 7
          002122          000007          .WORD 7
          002124          L$DISPATCH::
          002124          040714          .WORD T1
          002126          043116          .WORD T2
          002130          043612          .WORD T3
          002132          044270          .WORD T4
          002134          044650          .WORD T5
          002136          045170          .WORD T6
          002140          045646          .WORD T7
1195
1196
1197          002142          DESCRIPT          <CZTKBAO DATA RELIABILITY>
          002142          103          132          124          L$DESC::
          002142          .ASCIZ /CZTKBAO DATA RELIABILITY/
          .EVEN
1198
1199          ;
1200          ; NAMES OF DEVICES SUPPORTED BY PROGRAM
1201          ;
1202
1203          002174          DEVTYP          <TK50>
          002174          124          113          065          L$DVTYP::
          002174          .ASCIZ %TK50%
          .EVEN
1204

```

1206
 1207
 1208
 1209
 1210
 1211
 1212
 1213
 1214 002202
 002202 000002
 002204
 002204
 1215
 1216 002204 174500
 1217 002206 000000
 1218
 1219 002210
 002210

.SBTTL DEFAULT HARDWARE P-TABLE

```

; **
; THE DEFAULT HARDWARE P-TABLE CONTAINS DEFAULT VALUES OF
; THE TEST-DEVICE PARAMETERS. THE STRUCTURE OF THIS TABLE
; IS IDENTICAL TO THE STRUCTURE OF THE HARDWARE P-TABLES.
; --

```

```

          BGNHW  DFPTBL
          .WORD  L10000-L$HW/2
L$HW::
DFPTBL::
          174500          ;TKIP ADDRESS
          0               ;T/MSCP UNIT NUMBER
          ENDPHW
L10000:

```

```

1221          .SBTTL  SOFTWARE P-TABLE
1222
1223          ;**
1224          ; THE SOFTWARE P-TABLE CONTAINS THE VALUES OF THE PROGRAM
1225          ; PARAMETERS THAT CAN BE CHANGED BY THE OPERATOR.
1226          ;--
1227
1228 002210          BGNSW  SFPTBL
          002210      000041  .WORD  L10001-L$SW/2
          002212          L$SW::
          002212          SFPTBL::
1229
1230 002212      000      CLOCK::          .BYTE  0          ;ENABLE TIME OF DAY CLOCK
1231 002213      000      HOURS::          .BYTE  0          ;HOURS FOR TIME OF DAY CLOCK
1232 002214      000      MINUTE::          .BYTE  0          ;MINUTES FOR TIME OF DAY CLOCK
1233 002215      000      SECOND::          .BYTE  0          ;SECONDS FOR TIME OF DAY CLOCK
1234 002216      000      SUBSEC::          .BYTE  0          ;SUBSECONDS FOR TIME OF DAY CLOCK
1235
1236 002217      000      CONTPA::          .BYTE  0          ;CHANGE CONTROLLER PARARMETERS
1237 002220      001      SERREC::          .BYTE  1          ;ENABLE ERROR CORRECTION FLAG
1238 002221      001      SERCOR::          .BYTE  1          ;ENABLE ERROR RECOVERY FLAG
1239 002222      001      PADING::          .BYTE  1          ;ENABLE PAD BLOCKING
1240
1241 002223      000      PRNTPA::          .BYTE  0          ;CHANGE PRINT PARAMETERS
1242 002224      000      SOERRP::          .BYTE  0          ;ENABLE SOFT ERROR REPORT FLAG
1243 002225      001      RDSOER::          .BYTE  1          ;ENABLE READ SOFT ERRORS ONLY
1244 002226      000      CLRMED::          .BYTE  0          ;ENABLE CLEAR MEDIA TABLE EVERY PASS
1245 002227      000      MEDTBL::          .BYTE  0          ;ENABLE PRINT MEDIA TABLE CONTENTS
1246 002230      000      NOCLR::          .BYTE  0          ;ENABLE CLEAR STATS ON FATAL ERROR
1247 002231      000      DMPFLG::          .BYTE  0          ;ENABLE PROGRAM TABLE DUMP ON ERROR
1248
1249 002232          T7TBL::          ;COMMAND TABLE TOP -6
1250
1251 002232      000      TESTPA::          .BYTE  0          ;CHANGE TEST PARAMETERS
1252 002233      000      PATERN::          .BYTE  0          ;CHANGE DATA PATTERN
1253 002234      001      T3ONLY::          .BYTE  1          ;RUN TEST 3 ONLY
1254 002235      001      T5CMP::          .BYTE  1          ;ENABLE DATA COMPARES IN TEST 5
1255 002236      000      DMPBUF::          .BYTE  0          ;ENABLE READ BUFFER DUMP IN TEST 5
1256 002237      000      CHGFLG::          .BYTE  0          ;CHANGE CMD SEQ TABLE FLAG
1257
1258 002240      160      T7CMD1:          .BYTE  REW          ;REWIND
1259 002241      000          .BYTE  NULPAT
1260 002242      000000          .WORD  0
1261 002244      000001          .WORD  1
1262
1263 002246      020      T7CMD2:          .BYTE  WR          ;WRITE RECORDS
1264 002247      200          .BYTE  ALLPAT
1265 002250      004000          .WORD  2048.
1266 002252      000310          .WORD  200.
1267
1268 002254      100      T7CMD3:          .BYTE  WTM          ;WRITE TAPE MARK
1269 002255      000          .BYTE  NULPAT
1270 002256      000000          .WORD  0
1271 002260      000002          .WORD  2
1272
1273 002262      160      T7CMD4:          .BYTE  REW          ;REWIND
1274 002263      000          .BYTE  NULPAT

```

1275	002264	000000		.WORD	0	
1276	002266	000001		.WORD	1	
1277						
1278	002270	010	T7CMD5:	.BYTE	RD	;READ RECORDS
1279	002271	200		.BYTE	ALLPAT	
1280	002272	004000		.WORD	2048.	
1281	002274	000310		.WORD	200.	
1282						
1283	002276	060	T7CMD6:	.BYTE	SKP	;SKIP TAPE MARK
1284	002277	000		.BYTE	NULPAT	
1285	002300	000001		.WORD	1	
1286	002302	000002		.WORD	2	
1287						
1288	002304	160	T7CMD7:	.BYTE	REW	;REWIND
1289	002305	000		.BYTE	NULPAT	
1290	002306	000000		.WORD	0	
1291	002310	000001		.WORD	1	
1292						
1293	002312	177777	T7END:	.WORD	-1	
1294				.EVEN		
1295						
1296	002314		ENDSW			
	002314		L10001:			
1297						
1298	002314		ENDMOD			

1301
1312
1313
1388
1389 002314
1390
1391
1392
1393
1394
1395
1396
1397
1398
1399
1400
1401
1402 002314

.TITLE GLOBAL AREAS
.SBTTL GLOBAL EQUATES SECTION

BGNMOD

;/**/
; 1.0 SUPERVISOR DEFINED LITERALS
;/**/

; **
; THE GLOBAL EQUATES SECTION CONTAINS PROGRAM EQUATES THAT
; ARE USED IN MORE THAN ONE TEST.
; --

EQUALS

; BIT DIFINITIONS

100000	BIT15==	100000
040000	BIT14==	40000
020000	BIT13==	20000
010000	BIT12==	10000
C04000	BIT11==	4000
002000	BIT10==	2000
001000	BIT09==	1000
000400	BIT08==	400
000200	BIT07==	200
000100	BIT06==	100
000040	BIT05==	40
000020	BIT04==	20
000010	BIT03==	10
000004	BIT02==	4
000002	BIT01==	2
000001	BIT00==	1

001000	BIT9==	BIT09
000400	BIT8==	BIT08
000200	BIT7==	BIT07
000100	BIT6==	BIT06
000040	BIT5==	BIT05
000020	BIT4==	BIT04
000010	BIT3==	BIT03
000004	BIT2==	BIT02
000002	BIT1==	BIT01
000001	BIT0==	BIT00

; EVENT FLAG DEFINITIONS
; EF32:EF17 RESERVED FOR SUPERVISOR TO PROGRAM COMMUNICATION

000040	EF.START==	32.	; BIT POSITION IN SECOND STATUS WORD
000037	EF.RESTART==	31.	; (100000) START COMMAND WAS ISSUED
000036	EF.CONTINUE==	30.	; (040000) RESTART COMMAND WAS ISSUED
000035	EF.NEW==	29.	; (020000) CONTINUE COMMAND WAS ISSUED
			; (010000) A NEW PASS HAS BEEN STARTED

```

000034      EF.PWR==      28.      ; (004000) A POWER-FAIL/POWER-UP OCCURRED
;
; PRIORITY LEVEL DEFINITIONS
;
000340      PRI07== 340
000300      PRI06== 300
000240      PRI05== 240
000200      PRI04== 200
000140      PRI03== 140
000100      PRI02== 100
000040      PRI01== 40
000000      PRI00== 0
;
; OPERATOR FLAG BITS
;
000004      EVL==      4
000010      LOT==     10
000020      ADR==     20
000040      IDU==     40
000100      ISR==    100
000200      UAM==    200
000400      BOE==    400
001000      PNT==   1000
002000      PRI==   2000
004000      IXE==   4000
010000      IBE==  10000
020000      IER==  20000
040000      LOE==  40000
100000      HOE== 100000

```

1403


```

1405
1406
1407 ;/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*\
1408 ; 2.0 TMSCP COMMAND LITERALS
1409 ;/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*\
1410
1411 ; 2.1 COMMAND PACKET OPCODES
1412 000001 OP.ABO == 01 ;ABORT COMMAND
1413 000020 OP.ACC == 20 ;ACCESS COMMAND
1414 000010 OP.AVL == 10 ;AVAILABLE COMMAND
1415 000040 OP.CMP == 40 ;COMPARE HOST DATA COMMAND
1416 000013 OP.DAP == 13 ;DETERMINE ACCESS PATH COMMAND
1417 000022 OP.ERS == 22 ;ERASE COMMAND
1418 000026 OP.ERG == 26 ;ERASE GAP COMMAND
1419 000002 OP.GCS == 02 ;GET COMMAND STATUS COMMAND
1420 000003 OP.GUS == 03 ;GET UNIT STATUS COMMAND
1421 000011 OP.ONL == 11 ;ONLINE COMMAND
1422 000041 OP.RD == 41 ;READ COMMAND
1423 000045 OP.REP == 45 ;REPOSITION COMMAND
1424 000004 OP.SCC == 04 ;SET CONTROLLER CHARACTERISTICS COMMAND
1425 000012 OP.SUC == 12 ;SET UNIT CHARACTERISTICS COMMAND
1426 000042 OP.WR == 42 ;WRITE COMMAND
1427 000044 OP.WTM == 44 ;WRITE TAPE MARK COMMAND
1428 000200 OP.END == 200 ;END MESSAGE FLAG
1429 000100 OP.AVA == 100 ;AVAILABLE ATTENTION MESSAGE
1430 000102 OP.ACP == 102 ;ACCESS PATH ATTENTION MESSAGE
1431
1432 ; 2.2 COMMAND MODIFIERS
1433 040000 MD.CMP == 040000 ;COMPARE
1434 020000 MD.CSE == 020000 ;CLEAR SERIOUS EXCEPTION
1435 001000 MD.SEC == 001000 ;SUPPRESS ERROR CORRECTION
1436 000400 MD.SER == 000400 ;SUPPRESS ERROR RECOVERY
1437 000200 MD.DLE == 000200 ;DETECT LEOT
1438 000100 MD.IMM == 000100 ;IMMEDIATE
1439 000040 MD.EXC == 000040 ;EXCLUSIVE ACCESS
1440 000020 MD.UNL == 000020 ;UNLOAD
1441 000010 MD.REV == 000010 ;REVERSE
1442 000004 MD.OBC == 000004 ;OBJECT COUNT
1443 000004 MD.SWP == 000004 ;SET WRITE PROTECT
1444 000002 MD.RWD == 000002 ;REWIND
1445 000002 MD.ALL == 000002 ;ALL CLASS DRIVERS
1446 000001 MD.SPD == 000001 ;SPEED
1447 000001 MD.NXU == 000001 ;NEXT UNIT
1448
1449 ; 2.3 GENERIC COMMAND PACKET OFFSETS
1450 000000 P.CRF == 0 ;COMMAND REFERENCE NUMBER
1451 000004 P.UNIT == 4 ;UNIT NUMBER
1452 000010 P.OPCD == 10 ;OPCODE
1453 000012 P.MOD == 12 ;MODIFIERS
1454 000014 P.BCNT == 14 ;BYTE COUNT
1455 000020 P.BUFF == 20 ;BUFFER DESCRIPTOR
1456
1457 ; 2.4 ABORT AND GET COMMAND STATUS OFFSETS PACKET OFFSETS
1458 000014 P.OTRF == 14 ;OUTSTANDING COMMAND REFERENCE NUMBER
1459
1460 ; 2.5 ONLINE AND SET UNIT CHARACTERISTICS PACKET OFFSETS
1461 000014 P.UNFL == 14 ;UNIT FLAGS

```

```

1462      000034      P.DVPM ==      34      ;DEVICE DEPENDENT PARAMETERS
1463      000040      P.FORM ==      40      ;FORMAT
1464      000042      P.SPED ==      42      ;SPEED
1465
1466      ; 2.6 REPOSITION COMMAND PACKET OFFSETS
1467      000014      P.REDD ==      14      ;RECORD/OBJECT COUNT
1468      000020      P.TMGC ==      20      ;TAPE MARK COUNT
1469
1470      ; 2.7 SET CONTROLLER CHARACTERISTICS PACKET OFFSETS
1471      000014      P.VRSN ==      14      ;MSCP VERSION
1472      000016      P.CNTF ==      16      ;CONTROLLER FLAGS
1473      000020      P.HTMO ==      20      ;HOST TIMEOUT
1474      000024      P.TIME ==      24      ;QUAD-WORD TIME AND DATE
1475      000034      P.CTPM ==      34      ;CONTROLLER DEPENDENT PARAMETERS
1476

```

```

1478 ;/*\*/\*/\*/\*/\*/\*/\*/\*/\*/\*/\*/\*/\*/\*/\*/\*/\*/\*/\*/\
1479 ; 3.0 TMSCP END PACKET LITERALS
1480 ;/*\*/\*/\*/\*/\*/\*/\*/\*/\*/\*/\*/\*/\*/\*/\*/\*/\*/\*/\*/\
1481
1482 ; 3.1 END PACKET FLAGS
1483 EF.LOG == 000040 ;ERROR LOG GENERATED
1484 EF.SEX == 000020 ;SERIOUS EXCEPTION
1485 EF.EOT == 000010 ;EOT ENCOUNTERED
1486
1487 ; 3.2 CONTROLLER FLAGS
1488 CF.ATN == 000200 ;ENABLE ATTENTION INTERUPTS
1489 CF.MSC == 000100 ;ENABLE MISCELLANEOUS ERROR LOG MESSAGES
1490 CF.OTH == 000040 ;ENABLE OTHER HOSTS ERROR LOG MESSAGES
1491 CF.THS == 000020 ;ENABLE THIS HOSTS ERROR LOG MESSAGES
1492
1493 ; 3.3 UNIT FLAGS
1494 UF.WPH == 020000 ;WRITE PROTECT (HARDWARE)
1495 UF.VSU == 020000 ;VARIABLE SPEED UNIT
1496 UF.WPS == 010000 ;SOFTWARE WRITE PROTECT
1497 UF.RMV == 000200 ;REMOVABLE MEDIA
1498 UF.VSS == 000040 ;VARIABLE SPEED MODE SUPPRESSION
1499 UF.CMW == 000002 ;COMPARE WRITES
1500 UF.CMR == 000001 ;COMPARE READS
1501
1502 ; 3.4 GENERIC END MESSAGE OFFSETS
1503 P.CRF == 0 ;COMMAND REFERENCE NUMBER
1504 P.UNIT == 4 ;UNIT NUMBER
1505 P.OPCD == 10 ;ENDCODE
1506 P.FLGS == 11 ;END MESSAGE FLAGS
1507 P.STS == 12 ;STATUS
1508 P.BCNT == 14 ;BYTE COUNT
1509
1510 ; 3.5 ACCESS,COMPARE HOST DATA,READ,REPOSITION,WRITE,-
1511 ; AND WRITE TAPE MARK END MESSAGE OFFSETS
1512 P.POS == 34 ;POSITION (OBJECT COUNT)
1513 P.TRBC == 40 ;TAPE RECORD BYTE COUNT
1514
1515 ; 3.6 GET COMMAND STATUS END PACKET OFFSETS
1516 P.OTRF == 14 ;OUTSTANDING COMMAND REFERENCE NUMBER
1517 P.CMST == 20 ;COMMAND STATUS
1518
1519 ; 3.7 GET UNIT STATUS END MESSAGE OFFSETS
1520 P.MLUN == 14 ;MULTI-UNIT CODE
1521 P.UNFL == 16 ;UNIT FLAGS
1522 P.UNTI == 24 ;UNIT IDENTIFIER
1523 P.MEDI == 34 ;MEDIA IDENTIFIER
1524 P.FORM == 40 ;TAPE FORMAT
1525 P.SPED == 42 ;SPEED
1526 P.FMEM == 44 ;FORMAT MENU
1527 P.CSVR == 50 ;CONTROLLER SOFTWARE VERSION
1528 P.CHVR == 51 ;CONTROLLER HARDWARE VERSION
1529 P.USVR == 52 ;UNIT SOFTWARE VERSION
1530 P.UHVR == 53 ;UNIT HARDWARE VERSION
1531
1532 ; 3.8 OP.ONL, OP.AVL AND OP.SUC MESSAGE OFFSETS
1533 P.MXWR == 44 ;MAXIMUM WRITE RECORD SIZE
1534 P.NREC == 50 ;NOISE RECORD

```

```

1535
1536
1537          000014
1538          000020
1539
1540          ; 3.9 REPOSITION MESSAGE OFFSETS
1541          P.RCSK == 14 ;RECORDS SKIPPED
1542          P.TMSK == 20 ;TAPE MARKS SKIPPED
1543
1544          ; 3.10 SET CONTROLLER CHARACTERISTICS MESSAGE OFFSETS
1545          P.VRSN == 14 ;MSCP VERSION
1546          P.CNTF == 16 ;CONTROLLER FLAGS
1547          P.HTMO == 20 ;HOST TIMEOUT
1548          P.TIME == 24 ;QUAD-WORD TIME AND DATE

```

```

1546 ;/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*\
1547 ; 4.0 ERROR LOG LITERALS
1548 ;/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*\
1549
1550 ; 4.1 ERROR LOG MESSAGE FORMAT CODES
1551 000000 FM.CNT == 000000 ;CONTROLLER ERRORS
1552 000001 FM.BAD == 000001 ;HOST MEMORY ACCESS ERRORS WITH BUS ADDRESS
1553 000005 FM.TPE == 000005 ;TAPE TRANSFER ERRORS
1554
1555 ; 4.2 ERROR LOG MESSAGE FLAGS
1556 000200 LF.SUC == 000200 ;OPERATION SUCCESSFUL
1557 000100 LF.CON == 000100 ;OPERATION CONTINUING
1558 000001 LF.SNR == 000001 ;SEQUENCE NUMBER REQUEST
1559
1560 ; 4.3 TAPE FORMAT FLAG VALUES
1561 000001 TF.800 == 000001 ;NRZI 800 BPI
1562 000002 TF.PE == 000002 ;PHASE ENCODED 1600 BPI
1563 000004 TF.GCR == 000004 ;GROUP CODED RECORDING 6250 BPI
1564 000010 TF.BLK == 000010 ;6667 BPI
1565
1566 ; 4.4 ERROR LOG MESSAGE OFFSETS
1567 000000 L.CRF == 0 ;COMMAND REFERENCE NUMBER
1568 000004 L.UNIT == 4 ;UNIT NUMBER
1569 000006 L.SEQN == 6 ;SEQUENCE NUMBER
1570 000010 L.FMT == 10 ;FORMAT
1571 000011 L.FLGS == 11 ;ERROR LOG MESSAGE FLAGS
1572 000012 L.EVNT == 12 ;EVENT CODES
1573 000014 L.CNTI == 14 ;CONTROLLER ID
1574 000024 L.CSVR == 24 ;CONTROLLER SOFTWARE VERSION
1575 000025 L.CHVR == 25 ;CONTROLLER HARDWARE VERSION
1576 000026 L.MLUN == 26 ;MULTI UNIT CODE
1577 000030 L.UNTI == 30 ;UNIT ID
1578 000030 L.BADR == 30 ;BUS ADDRESS
1579 000040 L.USVR == 40 ;UNIT SOFTWARE VERSION
1580 000041 L.UHVR == 41 ;UNIT HARDWARE VERSION
1581 000042 L.LVL == 42 ;RETRY LEVEL
1582 000042 L.FMTD == 42 ;FORMAT DEPENDENT
1583 000043 L.RTRY == 43 ;RETRY COUNT FOR THE CURRENT LEVEL
1584 000044 L.GPCT == 44 ;GAP COUNT
1585 000044 L.VSER == 44 ;VOLUME SERIAL NUMBER
1586 000044 L.PSTN == 44 ;TAPE OBJECT COUNT
1587 000050 L.STI == 50 ;STI INFORMATION
1588 000050 L.FHVR == 50 ;FORMATTER HARDWARE VERSION
1589 000051 L.FSVR == 51 ;FORMATTER SOFTWARE VERSION
1590 000052 L.STS == 52 ;CONTROLLER INTERNAL STATUS
1591 000053 L.DRVC == 53 ;DRIVE ERROR CODE
1592 000054 L.DFLG == 54 ;DRIVE STATE FLAGS
1593 000055 L.TRK == 55 ;LOGICAL TRACK NUMBER
1594 000056 L.PBLK == 56 ;PHYSICAL BLOCK NUMBER
1595 000060 L.LBLK == 60 ;LOGICAL BLOCK NUMBER
1596 000061 L.CNT0 == 61 ;TAPE COUNT 0
1597 000062 L.CNT1 == 62 ;TAPE COUNT 1
1598 000063 L.CNT2 == 63 ;TAPE COUNT 2
1599 000064 L.DRVS == 64 ;DRIVE STATE
1600 000066 L.RWST == 66 ;READ/WRITE STATE
1601 000070 L.OPFL == 70 ;OPERATION FLAGS
1602
    
```

Line	Value	Symbol	Status	Code	Description
1603		: 4.5			STATUS AND EVENT CODES
1604	000037	ST.MSK	==	37	;STATUS/EVENT CODE MASK
1605	000040	ST.SUB	==	40	;SUB-CODE MULTIPLIER
1606	000000	ST.SUC	==	0	;SUCCESS
1607	000001	ST.CMD	==	1	;INVALID COMMAND
1608	000002	ST.ABO	==	2	;COMMAND ABORTED
1609	000003	ST.OFL	==	3	;UNIT-OFFLINE
1610	000004	ST.AVL	==	4	;UNIT-AVAILABLE
1611	000005	ST.MFE	==	5	;MEDIA FORMAT ERROR
1612	000006	ST.WPR	==	6	;WRITE PROTECTED
1613	000007	ST.CMP	==	7	;COMPARE ERROR
1614	000010	ST.DAT	==	10	;DATA ERROR
1615	000011	ST.HST	==	11	;HOST BUFFER ACCESS ERROR
1616	000012	ST.CNT	==	12	;CONTROLLER ERROR
1617	000013	ST.DRV	==	13	;DRIVE ERROR
1618	000014	ST.FNT	==	14	;FORMATTER ERROR
1619	000015	ST.BOT	==	15	;BOT ENCOUNTERED
1620	000016	ST.TM	==	16	;TAPE MARK ENCOUNTERED
1621	000020	ST.RDT	==	20	;RECORD DATA TRUNCATED
1622	000021	ST.POL	==	21	;POSITION LOST
1623	000022	ST.SEX	==	22	;SERIOUS EXCEPTION
1624	000023	ST.LED	==	23	;LEOT DETECTED
1625	000037	ST.DIA	==	37	;INTERNAL DIAGNOSTIC MESSAGE
1626	000400	ST.ONL	==	400	;UNIT ALREADY ONLINE
1627					
1628	000010	EV.LGP	==	10	;LONG GAP ENCOUNTERED
1629	000050	EV.DST	==	50	;DATA SYNC TIMEOUT
1630	000052	EV.CTO	==	52	;COMM CHANNEL TIMEOUT
1631	000053	EV.SRT	==	53	;DRIVE COMMAND TIMEOUT
1632	000113	EV.SRI	==	113	;CONTROLLER DETECTED TRANSMISSION ERROR
1633	000150	EV.COR	==	150	;CORRECTABLE ERROR
1634	000152	EV.IDS	==	152	;INTERNAL INCONSISTENCY ERROR
1635	000153	EV.SER	==	153	;SOFT ERROR
1636	000213	EV.HER	==	213	;HARD ERROR
1637	000350	EV.URE	==	350	;UNRECORVERABLE DATA ERROR

```

1639 ;/ ** / ** / ** / ** / ** / ** / ** / ** / ** / ** / ** / ** / ** / ** / ** / ** / ** / ** / ** / ** / ** / ** /
1640 ; 5.0 PROGRAM DEFINED LITERALS
1641 ;/ ** / ** / ** / ** / ** / ** / ** / ** / ** / ** / ** / ** / ** / ** / ** / ** / ** / ** / ** / ** / ** /
1642
1643 ; 5.1 TKSA BIT DEFINITIONS
1644 100000 ERR == 100000 ;ERROR
1645 004000 S1 == 004000 ;STEP 1
1646 000001 GO == 000001 ;GO
1647 111400 TKINIT == 111400 ;TK50 STEP 1 RESPONSE
1648
1649 ; 5.2 DRIVE IN USE TABLE BIT DEFINITIONS
1650 000001 AVB == 000001 ;DRIVE AVAILABLE
1651 000002 NRDY == 000002 ;DRIVE NOT READY
1652 000004 EOT == 000004 ;DRIVE AT EOT
1653 000010 DROP == 000010 ;DRIVE DROPPED
1654 000020 FAIL == 000020 ;DRIVE FAILED
1655
1656 ; 5.3 I/O STATUS MESSAGES
1657 000000 IONORM == 0 ;SUCCESSFUL COMMAND TRANSMISSION
1658 100000 NURESP == BIT15 ;NEW RESPONSE RECEIVED
1659 040000 ERRLOG == BIT14 ;ERROR LOG PACKET RECEIVED
1660 020000 IOICRD == BIT13 ;INSUFFICIENT CREDIT TO POST COMMAND
1661 000001 CMDLST == 1. ;GCS RESPONSE NEVER CAME BACK
1662 000002 IOHUNG == 2. ;CONTROLLER HUNG
1663 000003 IOPDRE == 3. ;PORT DETECTED ERROR
1664 000004 IOTIME == 4. ;CONTROLLER TIME OUT
1665 000005 MISSEQ == 5. ;COMMAND RETURNED IN WRONG SEQUENCE
1666 000006 INTERR == 6. ;ERROR DURING INITIALIZATION
1667 000007 ILLCMD == 7. ;ILLEGAL COMMAND
1668
1669 ; 5.4 RESPONSE CONDITION CODES
1670 000001 SUCCES == 000001 ;RESPONSE HANDLED SUCCESSFULLY
1671 000002 SEREXC == 000002 ;SERIOUS EXCEPTION CONDITION
1672 000004 ABORT == 000004 ;SYSTEM FATAL ERROR ABORT PROGRAM
1673
1674 ; 5.5 U/Q PORT LITERALS
1675 100000 OWN == BIT15 ;DESCRIPTOR OWNERSHIP BIT
1676 040000 FLAG == BIT14 ;DESCRIPTOR INTERRUPT FLAG BIT
1677 000200 IMM == BIT07 ;IMMEDIATE COMMAND FLAG
1678
1679 ; 5.6 PROGRAM LITERALS
1680 177546 KWCSR == 177546 ;LINE CLOCK REGISTER ADDRESS
1681 001233 RS1 == 1233 ;RANDOM GENERATOR SEED
1682 007622 RS2 == 7622 ;RANDOM GENERATOR SEED
1683 000000 RS3 == 0 ;RANDOM GENERATOR SEED
1684 000000 NULPAT == 0 ;NO DATA PATTERN NEEDED
1685 000000 RNDBYT == 0 ;RANDOM BYTE COUNT
1686 020000 MAXBUF == 8192. ;MAXIMUM BUFFER SIZE
1687 000024 MINBUF == 20. ;MINIMUM BUFFER SIZE
1688 000000 RNDITR == 0 ;RANDOM ITERATION COUNT
1689 003720 MAXITR == 2000. ;MAXIMUM ITERATION SET
1690 000144 MINITR == 100. ;MINIMUM ITERATION SET
1691 000001 PAT1 == 1 ;ALL 1'S DATA PATTERN
1692 000002 PAT2 == 2 ;ALL 0'S DATA PATTERN
1693 000003 PAT3 == 3 ;WORST CASE MFM DATA PATTERN
1694 000004 PAT4 == 4 ;ALTERNATING 1'S AND 0'S
1695 000005 PAT5 == 5 ;RANDOM DATA PATTERN

```

```

1696      000006      PAT6      ==      6      ;1110 REPEATING PATTERN
1697      000007      PAT7      ==      7      ;COMBINATION PATTERN 3 AND 5
1698      000010      ENDPAT   ==      8      ;RANDOM PATTERN VALUE
1699      000200      ALLPAT   ==     200      ;CYCLE THROUGH ALL PATTERNS
1700      000002      UNTSTP   ==      2      ;STEP THROUGH UNITS
1701      000000      HSTIMO   ==      0      ;HOST TIMEOUT VALUE
1702      000000      MSCPVR   ==      0      ;MSCP VERSION NUMBER
1703      177776      LOBYTE   ==     -2      ;LOW BYTE OFFSET FOR COMPARE DATA
1704      177777      HIBYTE   ==     -1      ;HIGH BYTE OFFSET FOR COMPARE DATA
1705      004716      T2END    ==    2510.     ;RECORDS TO FILL 2 TRACKS
1706      000004      N        ==      4      ;VALUE USED IN SUBITR
1707      000001      ONE      ==      1      ;BYTE OFFSET
1708
1709      ; 5.7  ERROR MASKING LITERALS
1710      000001      LEDB     ==    000001     ;DETECT LOGICAL END OF TAPE
1711      000002      RDTB     ==    000002     ;RECORD DATA TRUNCATED
1712      000004      SEXB     ==    000004     ;SERIOUS EXCEPTION
1713      000010      TMB      ==    000010     ;ENCOUNTERED TAPE MARK
1714      000020      WPRB     ==    000020     ;DRIVE WRITE PROTECTED
1715      000040      AVLB     ==    000040     ;UNIT AVAILABLE
1716      000100      ONLB     ==    000100     ;UNIT ONLINE
1717
1718      ; 5.8  ERROR TYPE LITERALS
1719      000000      SYSFAT   ==      0      ;SYSTEM FATAL ERROR
1720      000001      DEVFAT   ==      1      ;DEVICE FATAL ERROR
1721      000002      HARD     ==      2      ;HARD DEVICE ERROR
1722      000003      SOFT     ==      3      ;SOFT DEVICE ERROR
1723      000004      STATUS   ==      4      ;STATUS MESSAGE
1724
1725      ; 5.9  BIT VALUES FOR LUN FLAG
1726      000001      INTDON   ==    000001     ;INITIALIZATION HAS BEEN DONE ON THIS UNIT
1727      000002      SEREXC   ==    000002     ;A SERIOUS EXCEPTION CONDITION EXISTS
1728      000004      NOTALY   ==    000004     ;DON'T TALLY BYTES FOR THIS COMMAND
1729      000010      EOTPR    ==    000010     ;EOT PRINTED FOR THIS UNIT
1730      000020      ODDFLG   ==    000020     ;ODD BYTE COUNT FLAG
1731      000040      MTBLOV   ==    000040     ;MEDIA STATS OVERFLOW FLAG
1732      000100      ECCFLG   ==    000100     ;DON'T DECREMENT ECC COUNT FLAG
1733
1734      ;PROGRAM CONTROL FLAG BIT VALUES
1735      000001      T7BRFL   ==    000001     ;BRANCH FLAG FOR TEST 7
1736      000002      NCLKFL   ==    000002     ;NO CLOCK PRESENT FLAG
1737      000004      TCNTFL   ==    000004     ;COUNT RECORDS AND TAPE MARKS FLAG
1738      000010      DRERFL   ==    000010     ;DRIVE ERROR FLAG
1739      000020      GCSCFL   ==    000020     ;GET COMMAND STATUS COMMAND FLAG
1740      000040      GCSRFL   ==    000040     ;GET COMMAND STATUS RESPONSE FLAG
1741      000100      NOMDTB   ==    000100     ;DON'T PRINT MEDIA DEFECTS FLAG
1742      000200      CMDONE   ==    000200     ;ALL COMMANDS ISSUED FLAG
1743      000400      DROPIT   ==    000400     ;DRIVE BEING DROPPED
    
```


1795					
1796		: 6.7	LUN TABLE OFFSETS		
1797	000000	TKIP	==	0	;IP REGISTER ADDRESS
1798	000002	TKSA	==	2	;SA REGISTER ADDRESS
1799	000004	TKUNIT	==	4	;TMSCP DEVICE UNIT NUMBER
1800	000006	CMDSEQ	==	6	;COMMAND REFERENCE NUMBER
1801	000010	SLTUSE	==	10	;BIT MAP OF RESPONSES RECEIVED
1802	000012	CMDSSV	==	12	;COMMAND DESCRIPTOR
1803	000014	CNUSAV	==	14	;NEW COMMAND BUFFER POINTER
1804	000016	COLSAV	==	16	;OLD COMMAND BUFFER POINTER
1805	000020	RNUSAV	==	20	;NEW RESPONSE BUFFER POINTER
1806	000022	ROLSAV	==	22	;OLD RESPONSE BUFFER POINTER
1807	000024	PATSAV	==	24	;DATA PATTERN
1808	000026	LUNFLG	==	26	;INITIALIZATION FLAG
1809	000030	LEOTFL	==	30	;UNIT LOGICAL END OF TAPE FLAG
1810	000032	UNDROP	==	32	;UNIT DROP COUNT
1811	000034	OBJFDL	==	34	;OBJECT COUNT LOW ORDER
1812	000036	OBJFDH	==	36	;OBJECT COUNT HIGH ORDER
1813	000040	S1READ	==	40	;SOFT READ ERROR CHANNEL 1
1814	000042	S2READ	==	42	;SOFT READ ERROR CHANNEL 2
1815	000044	S1WRIT	==	44	;SOFT WRITE ERROR CHANNEL 1
1816	000046	S2WRIT	==	46	;SOFT WRITE ERROR CHANNEL 2
1817	000050	EC1COR	==	50	;ECC CORRECTABLE CHANNEL 1
1818	000052	EC2COR	==	52	;ECC CORRECTABLE CHANNEL 2
1819	000054	H1READ	==	54	;HARD READ ERROR CHANNEL 1
1820	000056	H2READ	==	56	;HARD READ ERROR CHANNEL 2
1821	000060	H1WRIT	==	60	;HARD WRITE ERROR CHANNEL 1
1822	000062	H2WRIT	==	62	;HARD WRITE ERROR CHANNEL 2
1823	000064	RTYEC1	==	64	;CRC ERROR ON ECC BLOCK CHANNEL 1
1824	000066	RTYEC2	==	66	;CRC ERROR ON ECC BLOCK CHANNEL 2
1825	000070	DTCPER	==	70	;DATA COMPARE ERROR
1826	000072	UNDRUN	==	72	;DATA UNDERRUN
1827	000074	OVRRUN	==	74	;DATA OVERRUN
1828	000076	RMSPQS	==	76	;READ MISPOSITION ERROR
1829	000100	WMSPQS	==	100	;WRITE MISPOSITION ERROR
1830	000102	OTHER	==	102	;OTHER ERRORS
1831	000104	DROPPD	==	104	;TIMES UNIT WAS DROPPED
1832	000106	NOERR	==	106	;NO ERROR
1833	000110	RDBYT1	==	110	;HUNDREDS BYTES READ
1834	000112	RDBYT2	==	112	;THOUSANDS BYTES READ
1835	000114	RDBYT3	==	114	;MILLIONS BYTES READ
1836	000116	RDBYT4	==	116	;BILLIONS BYTES READ
1837	000120	WRBYT1	==	120	;HUNDREDS BYTES WRITTEN
1838	000122	WRBYT2	==	122	;THOUSANDS BYTES WRITTEN
1839	000124	WRBYT3	==	124	;MILLIONS BYTES WRITTEN
1840	000126	WRBYT4	==	126	;BILLIONS BYTES WRITTEN
1841	000130	TBLTOP	==	130	;TOP OF MEDIA STATS TABLE
1842	000132	TBLBTM	==	132	;BOTTOM OF MEDIA STATS TABLE
1843	000134	LSTENT	==	134	;FIRST FREE SLOT IN MEDIA STATS TABLE
1844	000136	SED1	==	136	;PRIME RANDOM GENERATOR SEED
1845	000140	SED2	==	140	;PRIME RANDOM GENERATOR SEED
1846	000142	SED3	==	142	;PRIME RANDOM GENERATOR SEED
1847	000144	SEED1	==	144	;RANDOM GENERATOR SEED
1848	000146	SEED2	==	146	;RANDOM GENERATOR SEED
1849	000150	SEED3	==	150	;RANDOM GENERATOR SEED
1850	000152	OLDBLK	==	152	;SAVE OF LAST BLOCK IN ERROR
1851	000154	OLDTRK	==	154	;SAVE OF LAST TRACK IN ERROR

1853	000156	URSPBF ==	156	;START OF THIS UNITS RESPONSE BUFFER
1854	000160	URBEND ==	160	;END OF THIS UNITS RESPONSE BUFFER
1855	000162	URDSRG ==	162	;START OF THIS UNITS RESPONSE DESCRIPTOR RING
1856	000164	URDEND ==	164	;END OF THIS UNITS RESPONSE DESCRIPTOR RING
1857	000166	UCDSRG ==	166	;START OF THIS UNITS COMMAND DESCRIPTOR RING
1858	000170	UCDEND ==	170	;END OF THIS UNITS COMMAND DESCRIPTOR RING
1859	000172	LUNSTP ==	172	;OFFSET TO NEXT LUN BLOCK

```

1861 ;/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*\
1862 ; 7.0 PROGRAM PRIMITIVES
1863 ;/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/**\
1864
1865 ; 7.1 COMMAND PRIMITIVE LITERALS
1866 000000 NUL == 000 ;NULL
1867 000010 RD == 010 ;READ
1868 000011 RDR == 011 ;READ REVERSE
1869 000020 WR == 020 ;WRITE
1870 000030 CMP == 030 ;COMPARE HOST DATA
1871 000031 CMR == 031 ;COMPARE HOST DATA REVERSE
1872 000040 ACC == 040 ;ACCESS
1873 000041 ACR == 041 ;ACCESS REVERSE
1874 000050 SPC == 050 ;SPACE RECORDS
1875 000051 SCR == 051 ;SPACE RECORDS REVERSE
1876 000052 SCD == 052 ;SPACE TO LEOT
1877 000060 SKP == 060 ;SKIP TAPE MARKS
1878 000061 SKR == 061 ;SKIP TAPE MARKS REVERSE
1879 000062 SKD == 062 ;SKIP TO LEOT
1880 000070 SPO == 070 ;SPACE OBJECTS
1881 000071 SPR == 071 ;SPACE OBJECTS REVERSE
1882 000100 WTM == 100 ;WRITE TAPE MARKS
1883 000110 ERS == 110 ;ERASE
1884 000113 ERI == 113 ;ERASE IMMEDIATE
1885 000120 ERG == 120 ;ERASE GAPS
1886 000130 AVL == 130 ;AVAILABLE
1887 000134 AVU == 134 ;AVAILABLE UNLOAD
1888 000140 ONL == 140 ;ONLINE
1889 000150 SUC == 150 ;SET UNIT CHARACTERISTICS
1890 000155 SUW == 155 ;SET UNIT CHARA. W/WRITE PROTECT
1891 000160 REW == 160 ;REWIND
1892 000163 RWI == 163 ;REWIND IMMEDIATE
1893 000170 INT == 170 ;INITIALIZATION
1894 000200 ABO == 200 ;ABORT
1895 000210 GCS == 210 ;GET COMMAND STATUS
1896 000220 GUS == 220 ;GET UNIT STATUS
1897 000230 SCC == 230 ;SET CONTROLLER CHARACTERISTICS
1898
1899 ; 7.2 COMMAND PRIMITIVE MODIFIER LITERALS
1900 000001 REVBIT == 1 ;REVERSE MODIFIER
1901 000002 EOTBIT == 2 ;DETECT LEOT MODIFIER
1902 000003 IMMBIT == 3 ;IMMEDIATE MODIFIER
1903 000004 UNLBIT == 4 ;UNLOAD MOIFIER
1904 000005 WPRBIT == 5 ;WRITE PROTECT MODIFIER
1905

```


1964					
1965	003414	000000	RESP::	.WORD 0	;DRIVER RESPONSE COUNT
1966	003416	000000	BYTES::	.WORD 0	;BYTE COUNT
1967	003420	000000	ITERS::	.WORD 0	;ITERATION COUNT
1968	003422	000000	BUFADR::	.WORD 0	;COMMAND BUFFER ADDRESS
1969	003424	000000	SUBCNT::	.WORD 0	;SUB-ITERATION COUNT FOR DATA COMPARES
1970					
1971	003426	000000	RANWRD::	.WORD 0	;USED BY RANGEN
1972	003430	000000	RAN1::	.WORD 0	;SEED WORK LOCATION
1973	003432	000000	RAN2::	.WORD 0	;SEED WORK LOCATION
1974	003434	000000	RAN3::	.WORD 0	;SEED WORK LOCATION
1975					
1976	003436	000000	SAVDIF::	.WORD 0	;COMMAND AND RESPONSE COUNT DIFFERENCE
1977	003440	000000	TSTMSK::	.WORD 0	;TEST LOAD WITH ACCEPTABLE ERROR CODES
1978	003442	000000	WRKMSK::	.WORD 0	;USED BY ERROR DECODE
1979					
1980	003444	000000	CMPERR::	.WORD 0	;NUMBER OF BYTES IN ERROR
1981	003446		BYTADD::	.BLKW 10.	;SAVE TABLE FOR BYTE IN ERROR ADDRESS
1982		003472	TBLEND ==		;END OF BYTE ADDRESS TABLE
1983	003472		DATBL::	.BLKW 10.	;SAVE TABLE FOR BYTE IN ERROR DATA
1984	003516	000000	PCFLAG::	.WORD 0	;PROGRAM CONTROL FLAGS
1985					
1986	003520	000000	OBJECT::	.WORD 0	;OBJECT COUNTER FOR TEST 2
1987	003522	000000	PASCNT::	.WORD 0	;PASS COUNTER
1988	003524	000000	UDROP::	.WORD 0	;NUMBER OF DROPPED UNITS
1989	003526	000000	UEOT::	.WORD 0	;COUNT OF UNITS AT EOT
1990					
1991	003530	000000	R8::	.WORD 0	;USED FOR TEMP STORAGE
1992	003532	000000	R9::	.WORD 0	;USED FOR TEMP STORAGE
1993	003534	000000	R10::	.WORD 0	;USED FOR TEMP STORAGE
1994	003536	000000	R11::	.WORD 0	;USED FOR TEMP STORAGE
1995	003540	000000	R12::	.WORD 0	;USED FOR TEMP STORAGE
1996					
1997	003542	000000	SECRNS::	.WORD 0	;SERIOUS EXCEPTION CMD REF #
1998	003544	000000	TBLOFF::	.WORD 0	;MEDIA ERROR TABLE OFFSET
1999	003546	000000	RECCNT::	.WORD 0	;NUMBER OF RECORDS
2000	003550	000000	TMCNT::	.WORD 0	;NUMBER OF TAPE MARKS
2001	003552	000000	LOHEX::	.WORD 0	;LOW ORDER HEX DIGIT
2002					
2003	003554	000000	HIHEX::	.WORD 0	;HIGH ORDER HEX DIGIT
2004	003556	000000	EVENT::	.WORD 0	;EVENT CODE STORAGE
2005	003560	000000	R3SAVE::	.WORD 0	;SAVE LOCATION FOR R3
2006	003562	000000	R4SAVE::	.WORD 0	;SAVE LOCATION FOR R4
2007	003564	000	DAYS::	.BYTE 0	;NUMBER OF DAYS IN RUN
2008			.EVEN		

```

2010 ;/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*\
2011 ; 9.0 TMSCP CLASS AND PORT DRIVER DATA STRUCTURES
2012 ;/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*\
2013
2014 ; 9.1 CLASS DRIVER BUFFERS
2015 003566 CMDBF1:: .BLKW 2. ;DRIVE COMMAND BUFFER 1
2016 003572 DCMDBF:: .BLKW 18. ;DRIVER COMMAND BUFFER
2017 003636 CMDBF2:: .BLKW 20. ;DRIVE COMMAND BUFFER 2
2018 003706 CMDBF3:: .BLKW 20. ;DRIVE COMMAND BUFFER 3
2019 003756 CMDBF4:: .BLKW 20. ;DRIVE COMMAND BUFFER 4
2020
2021 004026 RSPBF0:: .BLKW 2. ;TOP 4 LOCATIONS OF RESPONSE BUFFER UNIT 0
2022 004032 DCBEND:: ;END OF COMMAND BUFFER
2023 004032 DRSPB0:: .BLKW 270. ;DRIVER RESPONSE BUFFER UNIT 0
2024
2025 005066 RSPBF1:: .BLKW 2. ;TOP 4 LOCATIONS OF RESPONSE BUFFER UNIT 1
2026 005072 DRBEN0:: ;END OF RESPONSE BUFFER UNIT 0
2027 005072 DRSPB1:: .BLKW 270. ;DRIVER RESPONSE BUFFER UNIT 1
2028
2029 006126 RSPBF2:: .BLKW 2. ;TOP 4 LOCATIONS OF RESPONSE BUFFER UNIT 2
2030 006132 DRBEN1:: ;END OF RESPONSE BUFFER UNIT 1
2031 006132 DRSPB2:: .BLKW 270. ;DRIVER RESPONSE BUFFER UNIT 2
2032
2033 007166 RSPBF3:: .BLKW 2. ;TOP 4 LOCATIONS OF RESPONSE BUFFER UNIT 3
2034 007172 DRBEN2:: ;END OF RESPONSE BUFFER UNIT 2
2035 007172 DRSPB3:: .BLKW 270. ;DRIVER RESPONSE BUFFER UNIT 3
2036

```

```

2038      ; 9.2 U/Q PORT DESCRIPTOR RINGS
2039 010226 DSRNG0::      .BLKW  2.      ;DESCRIPTOR RING UNIT 0
2040 010232 DRBEN3::      ;END OF RESPONSE BUFFER UNIT 3
2041 010232 RDSRG0::      .BLKW 16.      ;RESPONSE DESCRIPTOR RING UNIT 0
2042 010272 RDRENO::      ;END OF RESPONCE DESCRIPTOR RING UNIT 0
2043 010272 CDSRG0::      .BLKW  8.      ;COMMAND DESCRIPTOR RING UNIT 0
2044 010312 CDRENO::      ;END OF COMMAND DESCRIPTOR RING UNIT 0
2045
2046 010312 DSRNG1::      .BLKW  2.      ;DESCRIPTOR RING UNIT 1
2047 010316 RDSRG1::      .BLKW 16.      ;RESPONSE DESCRIPTOR RING UNIT 1
2048 010356 RDREN1::      ;END OF RESPONCE DESCRIPTOR RING UNIT 1
2049 010356 CDSRG1::      .BLKW  8.      ;COMMAND DESCRIPTOR RING UNIT 1
2050 010376 CDREN1::      ;END OF COMMAND DESCRIPTOR RING UNIT 1
2051
2052 010376 DSRNG2::      .BLKW  2.      ;DESCRIPTOR RING UNIT 2
2053 010402 RDSRG2::      .BLKW 16.      ;RESPONSE DESCRIPTOR RING UNIT 2
2054 010442 RDREN2::      ;END OF RESPONCE DESCRIPTOR RING UNIT 2
2055 010442 CDSRG2::      .BLKW  8.      ;COMMAND DESCRIPTOR RING UNIT 2
2056 010462 CDREN2::      ;END OF COMMAND DESCRIPTOR RING UNIT 2
2057
2058 010462 DSRNG3::      .BLKW  2.      ;DESCRIPTOR RING UNIT 3
2059 010466 RDSRG3::      .BLKW 16.      ;RESPONSE DESCRIPTOR RING UNIT 3
2060 010526 RDREN3::      ;END OF RESPONCE DESCRIPTOR RING UNIT 3
2061 010526 CDSRG3::      .BLKW  8.      ;COMMAND DESCRIPTOR RING UNIT 3
2062 010546 CDREN3::      ;END OF COMMAND DESCRIPTOR RING UNIT 3
2063
2064      ; 9.3 CLASS AND PORT DRIVER VARIABLES
2065 010546 000000 IOSTAT::      .WORD  0      ;I/O STATUS
2066 010550 177777 CMSTSV::      .WORD -1      ;COMMAND STATUS FROM GCS MODE
2067 010552 000000 GCSREF::      .WORD  0      ;GCS COMMAND REFERENCE NUMBER
2068 010554 000000 CNTHI::      .WORD  0      ;VALUE OF THE HIGH TIMEOUT
2069 010556 000000 TIMER::      .WORD  0      ;TIMER VALUE
2070 010560 000000 LOOPS::      .WORD  0      ;
2071 010562 000120 CNTFLG::      .WORD  CF.THS!CF.MSC ;CONTROLLER FLAGS(ENABLE THIS HOSTS
;AND MISCELLANEOUS ERROR LOG MESSAGES)
2072
2073 010564 000000 PCKSIZ::      .WORD  0      ;PACKET SIZE IN BYTES
2074 010566 000000 SAERR::      .WORD  0      ;SA REGISTER SAVE ON ERROR
2075 010570 000    MINLIM::      .BYTE  0      ;MINIMUM REQUIRED CREDIT LIMIT
2076 010571 004    CRDLIM::      .BYTE  4      ;DRIVER CREDIT LIMIT
2077      .EVEN
2078

```


2080					
2081					
2082	010572	001			
2083	010573	102			
2084	010574	000001			
2085	010576	012213			
2086	010600	013272			
2087					
2088	010602	001			
2089	010603	102			
2090	010604	000002			
2091	010606	012246			
2092	010610	013272			
2093					
2094	010612	001			
2095	010613	102			
2096	010614	000003			
2097	010616	012266			
2098	010620	013272			
2099					
2100	010622	001			
2101	010623	102			
2102	010624	000004			
2103	010626	012312			
2104	010630	013272			
2105					
2106	010632	001			
2107	010633	102			
2108	010634	000005			
2109	010636	012347			
2110	010640	013272			
2111					
2112	010642	001			
2113	010643	102			
2114	010644	000006			
2115	010646	012400			
2116	010650	013272			
2117					
2118					
2119					
2120	010652	001			
2121	010653	102			
2122	010654	000007			
2123	010656	011502			
2124	010660	013272			
2125					
2126	010662	001			
2127	010663	102			
2128	010664	000010			
2129	010666	011525			
2130	010670	013272			
2131					
2132	010672	001			
2133	010673	102			
2134	010674	000011			
2135	010676	011541			
2136	010700	013272			

; I/O STATUS ERROR INFORMATION TABLE

IOERTB:: .BYTE DEVFAT ; GET COMMAND STATUS FAILED

.BYTE OTHER
.WORD 1
.WORD CMLSER
.WORD DEVERR

; CONTROLLER HUNG

.BYTE DEVFAT
.BYTE OTHER
.WORD 2
.WORD HUNGER
.WORD DEVERR

; PORT DETECTED ERROR

.BYTE DEVFAT
.BYTE OTHER
.WORD 3
.WORD PORTER
.WORD DEVERR

; PROGRAM DETECTED COMMAND TIMEOUT

.BYTE DEVFAT
.BYTE OTHER
.WORD 4
.WORD TIMERR
.WORD DEVERR

; COMMAND SEQUENCE ERROR

.BYTE DEVFAT
.BYTE OTHER
.WORD 5
.WORD SEQER
.WORD DEVERR

; ERROR DETECTED DURING INIT

.BYTE DEVFAT
.BYTE OTHER
.WORD 6
.WORD INITER
.WORD DEVERR

; PROGRAM DETECTED ERROR INFORMATION TABLE

CMDT:: .BYTE DEVFAT ;INVALID COMMAND ISSUED

.BYTE OTHER
.WORD 7.
.WORD CMDER
.WORD DEVERR

;COMMAND ABORTED

ABOT:: .BYTE DEVFAT
.BYTE OTHER
.WORD 8.
.WORD ABOER
.WORD DEVERR

;UNIT OFFLINE

OFLT:: .BYTE DEVFAT
.BYTE OTHER
.WORD 9.
.WORD OFLER
.WORD DEVERR

2137					
2138	010702	001	AVLT::	.BYTE DEVFAT	;UNIT AVAILABLE ERROR
2139	010703	102		.BYTE OTHER	
2140	010704	000012		.WORD 10.	
2141	010706	011556		.WORD AVLER	
2142	010710	013272		.WORD DEVERR	
2143					
2144	010712	001	IVST1::	.BYTE DEVFAT	;INVALID STATUS RETURNED
2145	010713	102		.BYTE OTHER	
2146	010714	000013		.WORD 11.	
2147	010716	012135		.WORD IVSER	
2148	010720	013272		.WORD DEVERR	
2149					
2150	010722	001	WPRT::	.BYTE DEVFAT	;UNIT WRITE PROTECTED
2151	010723	102		.BYTE OTHER	
2152	010724	000014		.WORD 12.	
2153	010726	011603		.WORD WPRER	
2154	010730	013272		.WORD DEVERR	
2155					
2156	010732	002	CMPT::	.BYTE HARD	;DATA COMPARE ERROR
2157	010733	070		.BYTE DTCPER	
2158	010734	000015		.WORD 13.	
2159	010736	012464		.WORD CMPER	
2160	010740	013272		.WORD DEVERR	
2161					
2162	010742	002	DATT::	.BYTE HARD	;DATA ERROR
2163	010743	106		.BYTE NOERR	
2164	010744	000016		.WORD 14.	
2165	010746	011630		.WORD DATER	
2166	010750	013272		.WORD DEVERR	
2167					
2168	010752	001	HSTT::	.BYTE DEVFAT	;HOST DETECTED TIMEOUT
2169	010753	102		.BYTE OTHER	
2170	010754	000017		.WORD 15.	
2171	010756	012165		.WORD HSTER	
2172	010760	013272		.WORD DEVERR	
2173					
2174	010762	001	CNTT::	.BYTE DEVFAT	;CONTROLLER ERROR
2175	010763	102		.BYTE OTHER	
2176	010764	000020		.WORD 16.	
2177	010766	011674		.WORD CNTER	
2178	010770	013272		.WORD DEVERR	
2179					
2180	010772	001	DRVT::	.BYTE DEVFAT	;DRIVE ERROR
2181	010773	102		.BYTE OTHER	
2182	010774	000021		.WORD 17.	
2183	010776	011715		.WORD DRVER	
2184	011000	013272		.WORD DEVERR	
2185					
2186	011002	001	FMTT::	.BYTE DEVFAT	;FORMATTER ERROR
2187	011003	102		.BYTE OTHER	
2188	011004	000022		.WORD 18.	
2189	011006	011731		.WORD FMTER	
2190	011010	013272		.WORD DEVERR	
2191					
2192	011012	001	BOTT::	.BYTE DEVFAT	;UNEXPECTED BOT ENCOUNTERED
2193	011013	102		.BYTE OTHER	

2194	011014	000023		.WORD	19.	
2195	011016	011751		.WORD	BOTER	
2196	011020	013272		.WORD	DEVERR	
2197						
2198	011022	001	TMT::	.BYTE	DEVFAT	;UNEXPECTED TAPE MARK ENCOUNTERED
2199	011023	102		.BYTE	OTHER	
2200	011024	000024		.WORD	20.	
2201	011026	011771		.WORD	TMER	
2202	011030	013272		.WORD	DEVERR	
2203						
2204	011032	001	IVST2::	.BYTE	DEVFAT	;INVALID STATS RECEIVED
2205	011033	102		.BYTE	OTHER	
2206	011034	000025		.WORD	21.	
2207	011036	012135		.WORD	IVSER	
2208	011040	013272		.WORD	DEVERR	
2209						
2210	011042	001	RDTT::	.BYTE	DEVFAT	;DATA RECORD TRUNCATED
2211	011043	102		.BYTE	OTHER	
2212	011044	000026		.WORD	22.	
2213	011046	012017		.WORD	RDTER	
2214	011050	013272		.WORD	DEVERR	
2215						
2216	011052	001	POLT::	.BYTE	DEVFAT	;TAPE POSITION LOST
2217	011053	076		.BYTE	RMSP0S	
2218	011054	000027		.WORD	23.	
2219	011056	012045		.WORD	POLER	
2220	011060	013272		.WORD	DEVERR	
2221						
2222	011062	001	SEXT::	.BYTE	DEVFAT	;SERIOUS EXCEPTION
2223	011063	102		.BYTE	OTHER	
2224	011064	000030		.WORD	24.	
2225	011066	012063		.WORD	SEXER	
2226	011070	013272		.WORD	DEVERR	
2227						
2228	011072	001	LEDT::	.BYTE	DEVFAT	;LEOT ENCOUNTERED
2229	011073	102		.BYTE	OTHER	
2230	011074	000031		.WORD	25.	
2231	011076	012105		.WORD	LEDER	
2232	011100	013272		.WORD	DEVERR	
2233						
2234	011102	001	IVST3::	.BYTE	DEVFAT	;INVALID STATUS RETURNED
2235	011103	102		.BYTE	OTHER	
2236	011104	000032		.WORD	26.	
2237	011106	012135		.WORD	IVSER	
2238	011110	013272		.WORD	DEVERR	
2239						
2240	011112	002	DCMPT::	.BYTE	HARD	;DATA COMPARE ERROR
2241	011113	070		.BYTE	DTCPER	
2242	011114	000033		.WORD	27.	
2243	011116	012507		.WORD	DCMPER	
2244	011120	013272		.WORD	DEVERR	
2245						
2246	011122	002	RLST::	.BYTE	HARD	;RECORD LENGTH SHORT ERROR
2247	011123	102		.BYTE	OTHER	
2248	011124	000034		.WORD	28.	
2249	011126	012421		.WORD	RLSER	
2250	011130	013272		.WORD	DEVERR	

2251					
2252					
2253					
2254	011132				
2255	011132	002			
2256	011133	106			
2257	011134	000035			
2258	011136	013172			
2259	011140	014502			
2260					
2261	011142				
2262	011142	002			
2263	011143	106			
2264	011144	000036			
2265	011146	013233			
2266	011150	014502			
2267					
2268	011152				
2269	011152	002			
2270	011153	070			
2271	011154	000037			
2272	011156	013030			
2273	011160	014502			
2274					
2275	011162				
2276	011162	002			
2277	011163	106			
2278	011164	000040			
2279	011166	013125			
2280	011170	014502			
2281					
2282	011172				
2283	011172	002			
2284	011173	106			
2285	011174	000041			
2286	011176	013145			
2287	011200	014502			
2288					
2289	011202				
2290	011202	002			
2291	011203	106			
2292	011204	000042			
2293	011206	013057			
2294	011210	014502			
2295					
2296	011212				
2297	011212	002			
2298	011213	054			
2299	011214	000043			
2300	011216	013103			
2301	011220	014502			
2302					
2303	011222				
2304	011222	002			
2305	011223	060			
2306	011224	000043			
2307	011226	013103			

;ERROR LOG ERROR TABLES

CNTLER:

.BYTE HARD
 .BYTE NOERR
 .WORD 29.
 .WORD CNTLEL
 .WORD ERLGER

;CONTROLLER (LAST FAIL) ERROR LOG

BADERL:

.BYTE HARD
 .BYTE NOERR
 .WORD 30.
 .WORD BADEL
 .WORD ERLGER

;HOST MEMORY ACCSESS ERROR

CMPEL:

.BYTE HARD
 .BYTE DTCPER
 .WORD 31.
 .WORD CMPEL
 .WORD ERLGER

;COMPARE ERROR

DRVERL:

.BYTE HARD
 .BYTE NOERR
 .WORD 32.
 .WORD DRVEL
 .WORD ERLGER

;DRIVE ERROR LOG

CNTERL:

.BYTE HARD
 .BYTE NOERR
 .WORD 33.
 .WORD CNTEL
 .WORD ERLGER

;CONTROLLER ERROR

LGPERL:

.BYTE HARD
 .BYTE NOERR
 .WORD 34.
 .WORD LGPEL
 .WORD ERLGER

;LONG GAP ENCOUNTERED

RDSTEL:

.BYTE HARD
 .BYTE H1READ
 .WORD 35.
 .WORD DSTEL
 .WORD ERLGER

;READ DATA SYNC NOT FOUND

WDSTEL:

.BYTE HARD
 .BYTE H1WRIT
 .WORD 35.
 .WORD DSTEL

;WRITE DATA SYNC NOT FOUND

2308	011230	014502	.WORD	ERLGER	
2309					
2310	011232				
2311	011232	003	CORERL :	.BYTE	SOFT ;CORRECTABLE WRITE DATA ERROR
2312	011233	044		.BYTE	S1WRIT
2313	011234	000044		.WORD	36.
2314	011236	012627		.WORD	COREL
2315	011240	014502		.WORD	ERLGER
2316					
2317	011242				
2318	011242	002	UWEERL :	.BYTE	HARD ;UNRECOVERABLE WRITE DATA ERROR
2319	011243	060		.BYTE	H1WRIT
2320	011244	000045		.WORD	37.
2321	011246	012760		.WORD	UWEEL
2322	011250	014502		.WORD	ERLGER
2323					
2324	011252				
2325	011252	003	RTYERL :	.BYTE	SOFT ;SOFT READ ERROR
2326	011253	040		.BYTE	S1READ
2327	011254	000052		.WORD	42.
2328	011256	012574		.WORD	RTYEL
2329	011260	014502		.WORD	ERLGER
2330					
2331	011262				
2332	011262	002	UREERL :	.BYTE	HARD ;UNRECOVERABLE READ DATA ERROR
2333	011263	054		.BYTE	H1READ
2334	011264	000046		.WORD	38.
2335	011266	012740		.WORD	UREEL
2336	011270	014502		.WORD	ERLGER
2337					
2338	011272				
2339	011272	003	ECBERL :	.BYTE	SOFT ;CRC ERROR ON AN ECC BLOCK
2340	011273	064		.BYTE	RTYEC1
2341	011274	000047		.WORD	39.
2342	011276	013001		.WORD	ECBEL
2343	011300	014502		.WORD	ERLGER
2344					
2345	011302				
2346	011302	003	ECTERL :	.BYTE	SOFT ;ECC CORRECTION ON A TAPE MARK
2347	011303	050		.BYTE	EC1COR
2348	011304	000050		.WORD	40.
2349	011306	012707		.WORD	ECTEL
2350	011310	014502		.WORD	ERLGER
2351					
2352	011312				
2353	011312	003	ECDERL :	.BYTE	SOFT ;ECC CORRECTION ON A DATA BLOCK
2354	011313	050		.BYTE	EC1COR
2355	011314	000051		.WORD	41.
2356	011316	012663		.WORD	ECDEL
2357	011320	014502		.WORD	ERLGER
2358					

```

2360          .SBTTL GLOBAL TEXT SECTION
2361
2362          ; COMMAND PRIMITIVE ASCII
2363
2364 011322          CMDASC::
2365 011322          116      125      114      .ASCIZ ?NUL?          ;NULL
2366 011326          122      104      040      .ASCIZ ?RD ?          ;READ
2367 011332          127      122      124      .ASCIZ ?WRT?          ;WRITE
2368 011336          103      115      120      .ASCIZ ?CMP?          ;COMPARE HOST DATA
2369 011342          101      103      103      .ASCIZ ?ACC?          ;ACCESS
2370 011346          123      120      103      SPCASC: .ASCIZ ?SPC?          ;SPACE RECORDS
2371 011352          123      113      120      .ASCIZ ?SKP?          ;SKIP TAPE MARKS
2372 011356          123      120      117      .ASCIZ ?SPO?          ;SPACE OBJECTS
2373 011362          127      124      115      .ASCIZ ?WTM?          ;WRITE TAPE MARK
2374 011366          105      122      123      .ASCIZ ?ERS?          ;ERASE
2375 011372          105      122      107      .ASCIZ ?ERG?          ;ERASE GAP
2376 011376          101      126      114      .ASCIZ ?AVL?          ;AVAILABLE
2377 011402          117      116      114      .ASCIZ ?ONL?          ;ONLINE
2378 011406          123      125      103      .ASCIZ ?SUC?          ;SET UNIT CHARACTERISTICS
2379 011412          122      105      127      .ASCIZ ?REW?          ;REWIND
2380 011416          111      116      124      .ASCIZ ?INT?          ;INITIALIZE
2381 011422          101      102      117      .ASCIZ ?ABO?          ;ABORT
2382 011426          107      103      123      .ASCIZ ?GCS?          ;GET COMMAND STATUS
2383 011432          107      125      123      .ASCIZ ?GUS?          ;GET UNIT STATUS
2384 011436          123      103      103      .ASCIZ ?SCC?          ;SET CONTROLLER CHARACTERISTICS
2385
2386
2387          ;ASCII FOR HEXADECIMAL PRINTOUTS
2388 011442          HEXTBL::
2389 011442          060      000      .ASCIZ ?0?          ;
2390 011444          061      000      .ASCIZ ?1?          ;
2391 011446          062      000      .ASCIZ ?2?          ;
2392 011450          063      000      .ASCIZ ?3?          ;
2393 011452          064      000      .ASCIZ ?4?          ;
2394 011454          065      000      .ASCIZ ?5?          ;
2395 011456          066      000      .ASCIZ ?6?          ;
2396 011460          067      000      .ASCIZ ?7?          ;
2397 011462          070      000      .ASCIZ ?8?          ;
2398 011464          071      000      .ASCIZ ?9?          ;
2399 011466          101      000      .ASCIZ ?A?          ;
2400 011470          102      000      .ASCIZ ?B?          ;
2401 011472          103      000      .ASCIZ ?C?          ;
2402 011474          104      000      .ASCIZ ?D?          ;
2403 011476          105      000      .ASCIZ ?E?          ;
2404 011500          106      000      .ASCIZ ?F?          ;
2405          .EVEN

```

```

2407
2408      ; FORMAT STATEMENTS USED IN PRINT CALLS
2409      ;
2410
2411 011502      111      116      126  CMDER: .ASCIZ /INVALID CMD ISSUED/
2412 011525      103      115      104  ABOER: .ASCIZ /CMD ABORTED/
2413 011541      125      116      111  OFLER: .ASCIZ /UNIT OFFLINE/
2414 011556      125      116      111  AVLER: .ASCIZ /UNIT AVAILABLE ERROR/
2415 011603      125      116      111  WPRER: .ASCIZ /UNIT WRITE PROTECTED/
2416 011630      104      101      124  DATER: .ASCIZ /DATA ERROR/
2417 011643      110      117      123  BADER: .ASCIZ /HOST BUFFER ACCESS ERROR/
2418 011674      103      117      116  CNTER: .ASCIZ /CONTROLLER ERROR/
2419 011715      104      122      111  DRVER: .ASCIZ /DRIVE ERROR/
2420 011731      106      117      122  FMTER: .ASCIZ /FORMATTER ERROR/
2421 011751      102      117      124  BOTER: .ASCIZ /BOT ENCOUNTERED/
2422 011771      124      101      120  TMER: .ASCIZ /TAPE MARK ENCOUNTERED/
2423 012017      104      101      124  RDTER: .ASCIZ /DATA RECORD TRUNCATED/
2424 012045      120      117      123  POLER: .ASCIZ /POSITION LOST/
2425 012063      123      105      122  SEXER: .ASCIZ /SERIOUS EXCEPTION/
2426 012105      114      117      107  LEDER: .ASCIZ /LOGICAL EOT ENCOUNTERED/
2427 012135      111      116      126  IVSER: .ASCIZ /INVALID STATUS RECEIVED/
2428 012165      110      117      123  HSTER: .ASCIZ /HOST DETECTED TIMEOUT/
2429 012213      116      117      040  CMLSER: .ASCIZ /NO RESPONSE TO GCS COMMAND/
2430 012246      103      117      116  HUNGER: .ASCIZ /CONTROLLER HUNG/
2431 012266      120      117      122  PORTER: .ASCIZ /PORT-DETECTED ERROR/
2432 012312      120      122      117  TIMERR: .ASCIZ /PROGRAM DETECTED CMD TIMEOUT/
2433 012347      122      105      123  SEQER: .ASCIZ /RESPONSE OUT OF SEQUENCE/
2434 012400      120      117      122  INITER: .ASCIZ /PORT INIT FAILED/
2435 012421      122      105      103  RLSER: .ASCIZ /RECORD LENGTH SHORT/
2436 012445      123      124      101  STATER: .ASCIZ /STATUS MESSAGE/
2437 012464      104      101      124  CMPER: .ASCIZ /DATA COMPARE ERROR/
2438 012507      123      057      127  DCMPE: .ASCIZ ?S/W DETECTED DATA COMPARE?
2439 012541      104      101      124  UDRNER: .ASCIZ /DATA UNDERRUN/
2440 012557      104      101      124  OVERUN: .ASCIZ /DATA OVERRUN/
2441 012574      122      105      124  RTYEL: .ASCIZ /RETRY RECOVERED READ ERROR/
2442 012627      122      105      124  COREL: .ASCIZ /RETRY RECOVERED WRITE ERROR/
2443 012663      105      103      103  ECDEL: .ASCIZ /ECC DATA CORRECTION/
2444 012707      105      103      103  ECTEL: .ASCIZ /ECC TAPE MARK CORRECTION/
2445 012740      110      101      122  UREEL: .ASCIZ /HARD READ ERROR/
2446 012760      110      101      122  UWEEL: .ASCIZ /HARD WRITE ERROR/
2447 013001      103      122      103  ECBEL: .ASCIZ /CRC ERROR ON ECC BLOCK/
2448 013030      104      101      124  CMPEL: .ASCIZ /DATA COMPARE ERROR LOG/
2449 013057      114      117      116  LGPEL: .ASCIZ /LONG GAP ENCOUNTERD/
2450 013103      104      101      124  DSTEL: .ASCIZ /DATA SYNC TIMEOUT/
2451 013125      104      122      111  DRVEL: .ASCIZ /DRIVE ERROR LOG/
2452 013145      103      117      116  CNTEL: .ASCIZ /CONTROLLER ERROR LOG/
2453 013172      103      117      116  CNTLEL: .ASCIZ /CONTROLLER (LAST FAIL) ERROR LOG/
2454 013233      110      117      123  BADEL: .ASCIZ /HOST MEMORY ERROR LOG/
2455
2456      .EVEN
2463
2464
    
```

2473
 2474
 2475
 2476
 2477
 2478
 2479
 2480

.SBTTL GLOBAL ERROR REPORT SECTION

```

; **
; THE GLOBAL ERROR REPORT SECTION CONTAINS THE PRINTB AND PRINTX CALLS
; THAT ARE USED IN MORE THAN ONE TEST. IT ALSO INCLUDES THE ASCII MESSAGES
; THAT ARE USED BY THE PRINTB AND PRINTX CALLS..
; --
    
```

2481 013262
 013262
 013262 000000
 013264 000000
 013266 000000
 013270 000000

```

ERRTBL ;GENERIC ERROR TABLE
L$ERRTBL::
ERRTYP:: .WORD 0
ERRNBR:: .WORD 0
ERRMSG:: .WORD 0
ERRBLK:: .WORD 0
    
```

2482
 2483

013272
 013272

BGNMSG DEVERR
 DEVERR::

2484 013272
 013272 010146
 013274 010546
 2485 013276 013703 003560
 2486 013302 013704 003562
 2487 013306 116205 000000
 2488 013312 042705 177407
 2489 013316 006205
 2490 013320 062705 011322
 2491 013324 016237 000000 003530
 2492 013332 042737 177770 003530
 2493 013340 001014
 2494 013342

```

PUSH <R1,R5> ;SAVE R1 AND R5
MOV R1,-(SP) ;;PUSH R1 ON STACK
MOV R5,-(SP) ;;PUSH R5 ON STACK
MOV R3SAVE,R3 ;RESTORE R3
MOV R4SAVE,R4 ;RESTORE R4
MOVB CMD(R2),R5 ;GET THE COMMAND PRIMITIVE
BIC #177407,R5 ;CLEAR MODIFIERS
ASR R5 ;THE PRIMITIVE
ADD #CMDASC,R5 ;PUT ADDRESS IN R5
MOV CMD(R2),R8 ;GET THE PRIMITIVE AGAIN
BIC #177770,R8 ;SAVE THE LAST 3 BITS
BNE 1$ ;BRANCH IF NOT ZERO
PRINTB #ERR00,R5,TKUNIT(R4)
MOV TKUNIT(R4),-(SP)
MOV R5,-(SP)
MOV #ERR00,-(SP)
MOV #3,-(SP)
MOV SP,R0
TRAP C$PNTB
ADD #10,SP
BR 6$
    
```

2495 013370 000513
 2496 013372 022737 000001 003530 1\$:
 2497 013400 001014
 2498 013402

```

PRINTB #ERR01,R5,TKUNIT(R4)
MOV TKUNIT(R4),-(SP)
MOV R5,-(SP)
MOV #ERR01,-(SP)
MOV #3,-(SP)
MOV SP,R0
TRAP C$PNTB
ADD #10,SP
BR 6$ ;GO PRINT THE REST OF THE MESSAGE
CMP #REVBIT,R8 ;IS IT A REVERSE ?
BNE 2$ ;BRANCH IF NOT
PRINTB #ERR01,R5,TKUNIT(R4)
MOV TKUNIT(R4),-(SP)
MOV R5,-(SP)
MOV #ERR01,-(SP)
MOV #3,-(SP)
MOV SP,R0
TRAP C$PNTB
ADD #10,SP
BR 6$
    
```

2499 013430 000473
 2500 013432 032737 000002 003530 2\$:
 2501 013440 001414
 2502 013442

```

PRINTB #ERR02,R5,TKUNIT(R4)
MOV TKUNIT(R4),-(SP)
MOV R5,-(SP)
MOV #ERR02,-(SP)
MOV #3,-(SP)
MOV SP,R0
BR 6$ ;GO PRINT THE REST OF THE MESSAGE
BIT #EOTBIT,R8 ;IS IT A DETECT LEOT ?
BEQ 3$ ;BRANCH IF NOT
PRINTB #ERR02,R5,TKUNIT(R4)
MOV TKUNIT(R4),-(SP)
MOV R5,-(SP)
MOV #ERR02,-(SP)
MOV #3,-(SP)
MOV SP,R0
    
```

013442 016446 000004
 013446 010546
 013450 012746 016116
 013454 012746 000003
 013460 010600

013462	104414			TRAP	C\$PNTB	
013464	062706	000010		ADD	#10,SP	
2503 013470	000453			BR	6\$	
2504 013472	022737	000003	003530 3\$:	CMP	#IMMBIT,R8	;GO PRINT THE REST OF THE MESSAGE
2505 013500	001014			BNE	4\$;IS IT A IMMEDIATE ?
2506 013502				PRINTB	#ERR03,R5,TKUNIT(R4)	;BRANCH IF NOT
013502	016446	000004		MOV	TKUNIT(R4),-(SP)	
013506	010546			MOV	R5, -(SP)	
013510	012746	016175		MOV	#ERR03, -(SP)	
013514	012746	000003		MOV	#3, -(SP)	
013520	010600			MOV	SP,RO	
013522	104414			TRAP	C\$PNTB	
013524	062706	000010		ADD	#10,SP	
2507 013530	000433			BR	6\$;GO PRINT THE REST OF THE MESSAGE
2508 013532	022737	000004	003530 4\$:	CMP	#UNLBIT,R8	;IS IT A UNLOAD ?
2509 013540	001014			BNE	5\$;BRANCH IF NOT
2510 013542				PRINTB	#ERR04,R5,TKUNIT(R4)	
013542	016446	000004		MOV	TKUNIT(R4),-(SP)	
013546	010546			MOV	R5, -(SP)	
013550	012746	016253		MOV	#ERR04, -(SP)	
013554	012746	000003		MOV	#3, -(SP)	
013560	010600			MOV	SP,RO	
013562	104414			TRAP	C\$PNTB	
013564	062706	000010		ADD	#10,SP	
2511 013570	000413			BR	6\$;GO PRINT THE REST OF THE MESSAGE
2512 013572			5\$:	PRINTB	#ERR05,R5,TKUNIT(R4)	
013572	016446	000004		MOV	TKUNIT(R4),-(SP)	
013576	010546			MOV	R5, -(SP)	
013600	012746	016332		MOV	#ERR05, -(SP)	
013604	012746	000003		MOV	#3, -(SP)	
013610	010600			MOV	SP,RO	
013612	104414			TRAP	C\$PNTB	
013614	062706	000010		ADD	#10,SP	
2513 013620			6\$:	PRINTB	#ERR06,PASCNT,PATSAV(R4)	
013620	016446	000024		MOV	PATSAV(R4),-(SP)	
013624	013746	003522		MOV	PASCNT, -(SP)	
013630	012746	016411		MOV	#ERR06, -(SP)	
013634	012746	000003		MOV	#3, -(SP)	
013640	010600			MOV	SP,RO	
013642	104414			TRAP	C\$PNTB	
013644	062706	000010		ADD	#10,SP	
2514 013650	022705	011346		CMP	#SPCASC,R5	;IS IT A DATA TRANSFER ERROR ?
2515 013654	101412			BLOS	7\$;NO, DON'T PRINT THE BYTE COUNT
2516 013656				PRINTB	#ERR07,BYTES	;PRINT THE BYTE COUNT
013656	013746	003416		MOV	BYTES, -(SP)	
013662	012746	016461		MOV	#ERR07, -(SP)	
013666	012746	000002		MOV	#2, -(SP)	
013672	010600			MOV	SP,RO	
013674	104414			TRAP	C\$PNTB	
013676	062706	000006		ADD	#6,SP	
2517 013702			7\$:	PRINTB	#ERR08,OBOFFH(R2),OBOFFL(R2)	
013702	016246	000004		MOV	OBOFFL(R2),-(SP)	
013706	016246	000006		MOV	OBOFFH(R2),-(SP)	
013712	012746	016521		MOV	#ERR08, -(SP)	
013716	012746	000003		MOV	#3, -(SP)	
013722	010600			MOV	SP,RO	
013724	104414			TRAP	C\$PNTB	

2518	013726	062706	000010			ADD	#10,SP	
2519	013732	032737	000010	003516		BIT	#DRERFL,PCFLAG	; WAS IT A DRIVE ERROR ?
2520	013740	001417				BEQ	8\$; NO, GO PRINT TIME
2521	013742	042737	000010	003516		BIC	#DRERFL,PCFLAG	; CLEAR THE DRIVE ERROR FLAG
	013750					PRINTB	#ERR09,HIHEX,LOHEX	; PRINT THE DRIVE ERROR CODE
	013754	013746	003552			MOV	LOHEX,-(SP)	
	013760	012746	003554			MOV	HIHEX,-(SP)	
	013764	012746	016556			MOV	#ERR09,-(SP)	
	013770	012746	000003			MOV	#3,-(SP)	
	013772	010600				MOV	SP,R0	
	013774	104414				TRAP	C\$PNTB	
2522	014000	062706	000010			ADD	#10,SP	
2523	014006	122737	000006	010546	8\$:	CMPB	#INTERR,IOSTAT	; IS IT A PORT INIT FAILURE ?
2524	014010	001001				BNE	9\$; KEEP GOING IF IT ISN'T
2525	014012	000404				BR	10\$; GO PRINT SA CONTENTS
2526	014020	122737	000003	010546	9\$:	CMPB	#IOPDRE,IOSTAT	; IS IT A PORT DETECTED FAILURE ?
2527	014022	001014				BNE	11\$; KEEP GOING IF IT ISN'T
	014022				10\$:	PRINTB	#ERR10,SAERR	; PRINT THE SA CONTENTS IF IT IS
	014026	013746	010566			MOV	SAERR,-(SP)	
	014032	012746	016617			MOV	#ERR10,-(SP)	
	014036	012746	000002			MOV	#2,-(SP)	
	014040	010600				MOV	SP,R0	
	014042	104414				TRAP	C\$PNTB	
2528	014046	062706	000006			ADD	#6,SP	
2529	014052	005037	010566			CLR	SAERR	; CLEAR THE ERROR OUT OF THE LOCATION
2530	014056	105737	010546		11\$:	TSTB	IOSTAT	; WAS IT AN I/O ERROR ?
2531	014060	001150				BNE	DEVEXT	; GET OUT IF IT WAS
2532	014064	005737	003444			TST	CMPEER	; WAS IT A COMPARE ERROR ?
2533	014066	001051				BNE	CMPPRI	; GO PRINT THE ERROR DATA
	014066					PRINTX	#ERR11	
	014072	012746	016651			MOV	#ERR11,-(SP)	
	014076	012746	000001			MOV	#1,-(SP)	
	014100	010600				MOV	SP,R0	
	014102	104415				TRAP	C\$PNTX	
2534	014106	062706	000004			ADD	#4,SP	
	014106					PRINTX	#ERR12	
	014112	012746	016675			MOV	#ERR12,-(SP)	
	014116	012746	000001			MOV	#1,-(SP)	
	014120	010600				MOV	SP,R0	
	014122	104415				TRAP	C\$PNTX	
2535	014126	062706	000004			ADD	#4,SP	
2536	014130	010305				MOV	R3,R5	; GET POINTER TO RESPONSE PACKET
2537	014132	010301				MOV	R3,R1	; AND A SECOND COPY
2538	014136	062701	000002			ADD	#2,R1	; R1 POINT TO SECOND WORD OF PACKET
2539	014142	005763	177774		PRIPCK:	TST	MSGLEN(R3)	; CHECK THE MESSAGE LENGTH
2540	014144	100422				BMI	CMPPRI	; GET OUT IF IT WENT NEGATIVE
	014144					PRINTX	#ERR13,(R1),(R5)	
	014146	011546				MOV	(R5),-(SP)	
	014150	011146				MOV	(R1),-(SP)	
	014154	012746	016733			MOV	#ERR13,-(SP)	
	014160	012746	000003			MOV	#3,-(SP)	
	014162	010600				MOV	SP,R0	
	014164	104415				TRAP	C\$PNTX	
2541	014170	062706	000010			ADD	#10,SP	
2542	014174	062701	000004			ADD	#4,R1	; GET THE NEXT WORD
2543	014200	062705	000004			ADD	#4,R5	; AND AGAIN
	162763	000004	177774			SUB	#4,MSGLEN(R3)	; ADJUST MESSAGE LENGTH DOWN 2 WORDS

```

2544 014206 001353
2545 014210 005737 003444
2546 014214 001471
2547 014216
2548 014220 012701 003446
2549 014224 012702 003472
2550 014230 013705 003444
2551 014234
    014234 012746 016764
    014240 012746 000001
    014244 010600
    014246 104415
    014250 062706 000004
2552 014254
    014254 012746 017012
    014260 012746 000001
    014264 010600
    014266 104415
    014270 062706 000004
2553 014274
    014274 005046
    014276 151216
    014300 005046
    014302 156216 000001
    014306 011146
    014310 012746 017062
    014314 012746 000004
    014320 010600
    014322 104415
    014324 062706 000012
2554 014330 005337 003444
2555 014334 001405
2556 014336 005721
2557 014340 005722
2558 014342 022701 003472
2559 014346 001352
2560 014350
    014350 010546
    014352 012746 017107
    014356 012746 000002
    014362 010600
    014364 104415
    014366 062706 000006
2561 014372 005037 003444
2562 014376
2563 014400
    014400 012746 020527
    014404 012746 000001
    014410 010600
    014412 104417
    014414 062706 000004
2564 014420 105737 002212
2565 014424 001421
2566 014426
    014426 005046
    014430 153716 002215
    014434 005046

CMPPRI: BNE PRIPCK ;KEEP PRINTING TILL ALL DONE
        TST CMPERR ;WAS THIS A COMPARE ERROR ?
        BEQ DEVEXT ;GET OUT IF IT WASN'T
        PUSH <R2> ;SAVE R2
        MOV #BYTADD,R1 ;POINT R1 TO THE BYTE ADDRESS TABLE
        MOV #DATBL,R2 ;POINT R2 TO THE WRITE DATA TABLE
        MOV CMPERR,R5 ;LET R5 = THE NUMBER OF BYTES IN ERROR
        PRINTX #ERR14
        MOV #ERR14,-(SP)
        MOV #1,-(SP)
        MOV SP,R0
        TRAP C$PNTX
        ADD #4,SP
        PRINTX #ERR15
        MOV #ERR15,-(SP)
        MOV #1,-(SP)
        MOV SP,R0
        TRAP C$PNTX
        ADD #4,SP
1$: PRINTX #ERR16,(R1),<B,ONE(R2)>,<B,(R2)>
        CLR -(SP)
        BISB (R2),(SP)
        CLR -(SP)
        BISB ONE(R2),(SP)
        MOV (R1),-(SP)
        MOV #ERR16,-(SP)
        MOV #4,-(SP)
        MOV SP,R0
        TRAP C$PNTX
        ADD #12,SP
        DEC CMPERR ;SUBTRACT 1 FROM NUMBER OF ERRORS
        BEQ CPRIEX ;GO PRINT TOTAL NUMBER IN ERROR
        TST (R1)+ ;POINT R1 TO THE NEXT ADDRESS
        TST (R2)+ ;POINT R2 TO THE NEXT DATA
        CMP #TBLEND,R1 ;HAVE WE PRINTED THE WHOLE TABLE ?
        BNE 1$ ;NO CONTINUE
CPRIEX: PRINTX #ERR17,R5
        MOV R5,-(SP)
        MOV #ERR17,-(SP)
        MOV #2,-(SP)
        MOV SP,R0
        TRAP C$PNTX
        ADD #6,SP
        CLR CMPERR ;CLEAR THE ERROR COUNTER
        POP <R2>
DEVEXT: PRINTF #LINE
        MOV #LINE,-(SP)
        MOV #1,-(SP)
        MOV SP,R0
        TRAP C$PNTF
        ADD #4,SP
        TSTB CLOCK ;IS THE CLOCK ENABLED
        BEQ 1$ ;NO, THEN CAN'T PRINT TIME
        PRINTF #TIME,<B,HOURS>,<B,MINUTE>,<B,SECOND>
        CLR -(SP)
        BISB SECOND,(SP)
        CLR -(SP)

```

	014436	153716	002214		BISB	MINUTE,(SP)
	014442	005046			CLR	-(SP)
	014444	153716	002213		BISB	HOURS,(SP)
	014450	012746	020044		MOV	#TIME,-(SP)
	014454	012746	000004		MOV	#4,-(SP)
	014460	010600			MOV	SP,R0
	014462	104417			TRAP	C\$PNTF
	014464	062706	000012		ADD	#12,SP
2567	014470			1\$:	POP	<R5,R1>
2568	014474				EXIT	MSG
	014474	000167			.WORD	J\$.JMP
	014476	000000			.WORD	L10002-2-
2569	014500				ENDMSG	
	014500			L10002:		
	014500	104423			TRAP	C\$MSG

2571	014502					BGNMSG	ERLGER	
	014502					ERLGER::		
2572	014502					PUSH	<R1,R5>	;SAVE R1 AND R5
	014502	010146				MOV	R1,-(SP)	::PUSH R1 ON STACK
	014504	010546				MOV	R5,-(SP)	::PUSH R5 ON STACK
2573	014506	013703	003560			MOV	R3SAVE,R3	;RESTORE R3
2574	014512	013704	003562			MOV	R4SAVE,R4	;RESTORE R4
2575	014516	113705	003536			MOVB	R11,R5	;GET THE COMMAND PRIMITIVE
2576	014522	042705	177407			BIC	#177407,R5	;CLEAR MODIFIERS
2577	014526	006205				ASR	R5	;THE PRIMITIVE
2578	014530	062705	011322			ADD	#CMDASC,R5	;PUT ADDRESS IN R5
2579	014534	013737	003536	003530		MOV	R11,R8	;GET THE PRIMITIVE AGAIN
2580	014542	042737	177770	003530		BIC	#177770,R8	;SAVE THE LAST 3 BITS
2581	014550	001014				BNE	5\$;BRANCH IF NOT ZERO
2582	014552					PRINTB	#ERR00,R5,TKUNIT(R4)	
	014552	016446	000004			MOV	TKUNIT(R4),-(SP)	
	014556	010546				MOV	R5,-(SP)	
	014560	012746	015770			MOV	#ERR00,-(SP)	
	014564	012746	000003			MOV	#3,-(SP)	
	014570	010600				MOV	SP,R0	
	014572	104414				TRAP	C\$PNTB	
	014574	062706	000010			ADD	#10,SP	
2583	014600	000512				BR	30\$;GO PRINT THE REST OF THE MESSAGE
2584	014602	022737	000001	003530	5\$:	CMP	#REVBIT,R8	;IS IT A REVERSE ?
2585	014610	001013				BNE	10\$;BRANCH IF NOT
2586	014612					PRINTB	#ERR01,R5,TKUNIT(R4)	
	014612	016446	000004			MOV	TKUNIT(R4),-(SP)	
	014616	010546				MOV	R5,-(SP)	
	014620	012746	016040			MOV	#ERR01,-(SP)	
	014624	012746	000003			MOV	#3,-(SP)	
	014630	010600				MOV	SP,R0	
	014632	104414				TRAP	C\$PNTB	
	014634	062706	000010			ADD	#10,SP	
2587	014640	032737	000002	003530	10\$:	BIT	#EOTBIT,R8	;IS IT A DETECT LEOT ?
2588	014646	001414				BEQ	15\$;BRANCH IF NOT
2589	014650					PRINTB	#ERR02,R5,TKUNIT(R4)	
	014650	016446	000004			MOV	TKUNIT(R4),-(SP)	
	014654	010546				MOV	R5,-(SP)	
	014656	012746	016116			MOV	#ERR02,-(SP)	
	014662	012746	000003			MOV	#3,-(SP)	
	014666	010600				MOV	SP,R0	
	014670	104414				TRAP	C\$PNTB	
	014672	062706	000010			ADD	#10,SP	
2590	014676	000453				BR	30\$;GO PRINT THE REST OF THE MESSAGE
2591	014700	022737	000003	003530	15\$:	CMP	#IMMBIT,R8	;IS IT A IMMEDIATE ?
2592	014706	001014				BNE	20\$;BRANCH IF NOT
2593	014710					PRINTB	#ERR03,R5,TKUNIT(R4)	
	014710	016446	000004			MOV	TKUNIT(R4),-(SP)	
	014714	010546				MOV	R5,-(SP)	
	014716	012746	016175			MOV	#ERR03,-(SP)	
	014722	012746	000003			MOV	#3,-(SP)	
	014726	010600				MOV	SP,R0	
	014730	104414				TRAP	C\$PNTB	
	014732	062706	000010			ADD	#10,SP	
2594	014736	000433				BR	30\$;GO PRINT THE REST OF THE MESSAGE
2595	014740	022737	000004	003530	20\$:	CMP	#UNLBIT,R8	;IS IT A UNLOAD ?
2596	014746	001014				BNE	25\$;BRANCH IF NOT

2597	014750			PRINTB	#ERR04,R5,TKUNIT(R4)		
	014750	016446	000004	MOV	TKUNIT(R4),-(SP)		
	014754	010546		MOV	R5,-(SP)		
	014756	012746	016253	MOV	#ERR04,-(SP)		
	014762	012746	000003	MOV	#3,-(SP)		
	014766	010600		MOV	SP,R0		
	014770	104414		TRAP	C\$PNTB		
	014772	062706	000010	ADD	#10,SP		
2598	014776	000413		BR	30\$;GO PRINT THE REST OF THE MESSAGE	
2599	015000			25\$: PRINTB	#ERR05,R5,TKUNIT(R4)		
	015000	016446	000004	MOV	TKUNIT(R4),-(SP)		
	015004	010546		MOV	R5,-(SP)		
	015006	012746	016332	MOV	#ERR05,-(SP)		
	015012	012746	000003	MOV	#3,-(SP)		
	015016	010600		MOV	SP,R0		
	015020	104414		TRAP	C\$PNTB		
	015022	062706	000010	ADD	#10,SP		
2600	015026			30\$: PRINTB	#ERR06,PASCNT,PATSAV(R4)		
	015026	016446	000024	MOV	PATSAV(R4),-(SP)		
	015032	013746	003522	MOV	PASCNT,-(SP)		
	015036	012746	016411	MOV	#ERR06,-(SP)		
	015042	012746	000003	MOV	#3,-(SP)		
	015046	010600		MOV	SP,R0		
	015050	104414		TRAP	C\$PNTB		
	015052	062706	000010	ADD	#10,SP		
2601	015056	122763	000005	000010	CMPB	#FM.TPE,L.FMT(R3)	;IS IT A TAPE TRANSFER ERROR LOG ?
2602	015064	001402		BEQ	35\$;YES, GO PRINT IT	
2603	015066	000137	015476	JMP	PKPRNT	;NO, PRINT THE ERROR LOG PACKET	
2604	015072			35\$: PRINTB	#ERR07,BYTES	;PRINT THE BYTE COUNT	
	015072	013746	003416	MOV	BYTES,-(SP)		
	015076	012746	016461	MOV	#ERR07,-(SP)		
	015102	012746	000002	MOV	#2,-(SP)		
	015106	010600		MOV	SP,R0		
	015110	104414		TRAP	C\$PNTB		
	015112	062706	000006	ADD	#6,SP		
2605	015116			PRINTB	#ERR08,OBOFFH(R2),OBOFFL(R2)		
	015116	016246	000004	MOV	OBOFFL(R2),-(SP)		
	015122	016246	000006	MOV	OBOFFH(R2),-(SP)		
	015126	012746	016521	MOV	#ERR08,-(SP)		
	015132	012746	000003	MOV	#3,-(SP)		
	015136	010600		MOV	SP,R0		
	015140	104414		TRAP	C\$PNTB		
	015142	062706	000010	ADD	#10,SP		
2606	015146			PRINTX	#ERL00,L.PSTN+2(R3),L.PSTN(R3)		
	015146	016346	000044	MOV	L.PSTN(R3),-(SP)		
	015152	016346	000046	MOV	L.PSTN+2(R3),-(SP)		
	015156	012746	017146	MOV	#ERL00,-(SP)		
	015162	012746	000003	MOV	#3,-(SP)		
	015166	010600		MOV	SP,R0		
	015170	104415		TRAP	C\$PNTX		
	015172	062706	000010	ADD	#10,SP		
2607	015176			PRINTX	#ERL01,<B,L.TRK(R3)>,<B,L.LVL(R3)>,<B,L.RTRY(R3)>		
	015176	005046		CLR	-(SP)		
	015200	156316	000043	BISB	L.RTRY(R3),(SP)		
	015204	005046		CLR	-(SP)		
	015206	156316	000042	BISB	L.LVL(R3),(SP)		
	015212	005046		CLR	-(SP)		

	015214	156316	000055	BISB	L. TRK(R3), (SP)
	015220	012746	017203	MOV	#ERL01, -(SP)
	015224	012746	000004	MOV	#4, -(SP)
	015230	010600		MOV	SP, R0
	015232	104415		TRAP	C\$PNTX
	015234	062706	000012	ADD	#12, SP
2608	015240			PRINTX	#ERL02, <B, L.LBLK(R3)>, L.PBLK(R3)
	015240	016346	000056	MOV	L.PBLK(R3), -(SP)
	015244	005046		CLR	-(SP)
	015246	156316	000060	BISB	L.LBLK(R3), (SP)
	015252	012746	017301	MOV	#ERL02, -(SP)
	015256	012746	000003	MOV	#3, -(SP)
	015262	010600		MOV	SP, R0
	015264	104415		TRAP	C\$PNTX
	015266	062706	000010	ADD	#10, SP
2609	015272			PRINTX	#ERL03, <B, L.DRVC(R3)>, <B, L.DFLG(R3)>
	015272	005046		CLR	-(SP)
	015274	156316	000054	BISB	L.DFLG(R3), (SP)
	015300	005046		CLR	-(SP)
	015302	156316	000053	BISB	L.DRVC(R3), (SP)
	015306	012746	017365	MOV	#ERL03, -(SP)
	015312	012746	000003	MOV	#3, -(SP)
	015316	010600		MOV	SP, R0
	015320	104415		TRAP	C\$PNTX
	015322	062706	000010	ADD	#10, SP
2610	015326			PRINTX	#ERL04, L.DRVS(R3), <B, L.STS(R3)>
	015326	005046		CLR	-(SP)
	015330	156316	000052	BISB	L.STS(R3), (SP)
	015334	016346	000064	MOV	L.DRVS(R3), -(SP)
	015340	012746	017454	MOV	#ERL04, -(SP)
	015344	012746	000003	MOV	#3, -(SP)
	015350	010600		MOV	SP, R0
	015352	104415		TRAP	C\$PNTX
	015354	062706	000010	ADD	#10, SP
2611	015360			PRINTX	#ERL05, <B, L.CNT0(R3)>, <B, L.CNT1(R3)>
	015360	005046		CLR	-(SP)
	015362	156316	000062	BISB	L.CNT1(R3), (SP)
	015366	005046		CLR	-(SP)
	015370	156316	000061	BISB	L.CNT0(R3), (SP)
	015374	012746	017540	MOV	#ERL05, -(SP)
	015400	012746	000003	MOV	#3, -(SP)
	015404	010600		MOV	SP, R0
	015406	104415		TRAP	C\$PNTX
	015410	062706	000010	ADD	#10, SP
2612	015414			PRINTX	#ERL06, <B, L.CNT2(R3)>, L.RWST(R3)
	015414	016346	000066	MOV	L.RWST(R3), -(SP)
	015420	005046		CLR	-(SP)
	015422	156316	000063	BISB	L.CNT2(R3), (SP)
	015426	012746	017627	MOV	#ERL06, -(SP)
	015432	012746	000003	MOV	#3, -(SP)
	015436	010600		MOV	SP, R0
	015440	104415		TRAP	C\$PNTX
	015442	062706	000010	ADD	#10, SP
2613	015446			PRINTX	#ERL07, L.OPFL(R3)
	015446	016346	000070	MOV	L.OPFL(R3), -(SP)
	015452	012746	017713	MOV	#ERL07, -(SP)
	015456	012746	000002	MOV	#2, -(SP)

015462	010600		MOV	SP,R0		
015464	104415		TRAP	C\$PNTX		
015466	062706	000006	ADD	#6,SP		
2614 015472	000137	015670	JMP	MSGEXT	;GET OUT	
2615 015476			PKPRNT: PRINTB	#ERR08,OBOFFH(R2),OBOFFL(R2)		
015476	016246	000004	MOV	OBOFFL(R2),-(SP)		
015502	016246	000006	MOV	OBOFFH(R2),-(SP)		
015506	012746	016521	MOV	#ERR08,-(SP)		
015512	012746	000003	MOV	#3,-(SP)		
015516	010600		MOV	SP,R0		
015520	104414		TRAP	C\$PNTB		
015522	062706	000010	ADD	#10,SP		
2616 015526			PRINTX	#ERL08		
015526	012746	017743	MOV	#ERL08,-(SP)		
015532	012746	000001	MOV	#1,-(SP)		
015536	010600		MOV	SP,R0		
015540	104415		TRAP	C\$PNTX		
015542	062706	000004	ADD	#4,SP		
2617 015546			PRINTX	#ERR11		
015546	012746	016651	MOV	#ERR11,-(SP)		
015552	012746	000001	MOV	#1,-(SP)		
015556	010600		MOV	SP,R0		
015560	104415		TRAP	C\$PNTX		
015562	062706	000004	ADD	#4,SP		
2618 015566			PRINTX	#ERR12		
015566	012746	016675	MOV	#ERR12,-(SP)		
015572	012746	000001	MOV	#1,-(SP)		
015576	010600		MOV	SP,R0		
015600	104415		TRAP	C\$PNTX		
015602	062706	000004	ADD	#4,SP		
2619 015606	010305		MOV	R3,R5	;GET POINTER TO RESPONSE PACKET	
2620 015610	010301		MOV	R3,R1	;AND A SECOND COPY	
2621 015612	062701	000002	ADD	#2,R1	;R1 POINT TO SECOND WORD OF PACKET	
2622 015616	005763	177774	1\$: TST	MSGLEN(R3)	;ARE WE STILL POSITIVE ?	
2623 015622	100422		BMI	MSGEXT	;NO, GET OUT	
2624 015624			PRINTX	#ERR13,(R1),(R5)		
015624	011546		MOV	(R5),-(SP)		
015626	011146		MOV	(R1),-(SP)		
015630	012746	016733	MOV	#ERR13,-(SP)		
015634	012746	000003	MOV	#3,-(SP)		
015640	010600		MOV	SP,R0		
015642	104415		TRAP	C\$PNTX		
015644	062706	000010	ADD	#10,SP		
2625 015650	062701	000004	ADD	#4,R1	;GET THE NEXT WORD	
2626 015654	062705	000004	ADD	#4,R5	;AND AGAIN	
2627 015660	162763	000004	2627 015660	SUB	#4,MSGLEN(R3)	;ADJUST MESSAGE LENGTH DOWN 2 WORDS
2628 015666	001353		BNE	1\$;KEEP PRINTING TILL ALL DONE	
2629 015670			MSGEXT: PRINTF	#LINE		
015670	012746	020527	MOV	#LINE,-(SP)		
015674	012746	000001	MOV	#1,-(SP)		
015700	010600		MOV	SP,R0		
015702	104417		TRAP	C\$PNTF		
015704	062706	000004	ADD	#4,SP		
2630 015710	105737	002212	TSTB	CLOCK	;IS THE CLOCK ENABLED	
2631 015714	001421		BEQ	1\$;NO, THEN CAN'T PRINT TIME	
2632 015716			PRINTF	#TIME,<B,HOURS>,<B,MINUTE>,<B,SECOND>		
015716	005046		CLR	-(SP)		

015720	153716	002215
015724	005046	
015726	153716	002214
015732	005046	
015734	153716	002213
015740	012746	020044
015744	012746	000004
015750	010600	
015752	104417	
015754	062706	000012
2633 015760		
2634 015764		
015764	000167	
015766	003044	

```

BISB   SECOND, (SP)
CLR    -(SP)
BISB   MINUTE, (SP)
CLR    -(SP)
BISB   HOURS, (SP)
MOV    #TIME, -(SP)
MOV    #4, -(SP)
MOV    SP, R0
TRAP   C$PNTF
ADD    #12, SP
POP    <R5, R1>
EXIT   MSG
.WORD  J$JMP
.WORD  L10003-2-.

```

2635							
2636	015770	045	101	103	ERR00::	.ASCIZ	?#ACOMMAND: #T#S3#AT/MSCP UNIT: #03#A(0)?
2637	016040	045	101	103	ERR01::	.ASCIZ	?#ACOMMAND: #T#A-REV#S3#AT/MSCP UNIT: #03#A(0)?
2638	016116	045	101	103	ERR02::	.ASCIZ	?#ACOMMAND: #T#A-LEOT#S3#AT/MSCP UNIT: #03#A(0)?
2639	016175	045	101	103	ERR03::	.ASCIZ	?#ACOMMAND: #T#A-IMM#S3#AT/MSCP UNIT: #03#A(0)?
2640	016253	045	101	103	ERR04::	.ASCIZ	?#ACOMMAND: #T#A-UNLD#S3#AT/MSCP UNIT: #03#A(0)?
2641	016332	045	101	103	ERR05::	.ASCIZ	?#ACOMMAND: #T#A-WRPR#S3#AT/MSCP UNIT: #03#A(0)?
2642	016411	045	116	045	ERR06::	.ASCIZ	?#N#APASS: #D3#A(D) DATA PAT: #02#A(0)?
2643	016461	045	116	045	ERR07::	.ASCIZ	?#N#ARECORD BYTE COUNT: #D6#A(D)?
2644	016521	045	116	045	ERR08::	.ASCIZ	?#N#AOBJECT CNT : #06#06#A(0)?
2645	016556	045	116	045	ERR09::	.ASCIZ	?#N#ADRIVE ERROR CODE : #T#T#A(H)?
2646	016617	045	116	045	ERR10::	.ASCIZ	?#N#ASA CONTENTS: #06#A(0)?
2647	016651	045	116	045	ERR11::	.ASCIZ	?#N#ARESPONSE PACKET?
2648	016675	045	116	045	ERR12::	.ASCIZ	?#N#S5#AHIGH WORD#S6#ALOW WORD?
2649	016733	045	116	045	ERR13::	.ASCIZ	?#N#S5#06#A(0)#S6#06#A(0)?
2650	016764	045	116	045	ERR14::	.ASCIZ	?#N#S2#ABYTE#S10#ADATA?
2651	017012	045	116	045	ERR15::	.ASCIZ	?#N#S2#AADDR#S3#AEXPECTED#S3#ARECEIVED#N?
2652	017062	045	123	061	ERR16::	.ASCIZ	?#S1#06#S5#03#S8#03#N?
2653	017107	045	101	124	ERR17::	.ASCIZ	?#ATOTAL BYTES IN ERROR : #D4#N?
2654	017146	045	116	045	ERL00::	.ASCIZ	?#N#ATAP OBJ CNT: #06#06#A(0)?
2655	017203	045	116	045	ERL01::	.ASCIZ	?#N#ATRK NUM: #D2#A(D) LEVEL: #D2#A(D) RETRIES: #D2#A(D)?
2656	017301	045	116	045	ERL02::	.ASCIZ	?#N#ALOG BLK NUM: #D3#A(D) PHYS BLK NUM: #D6#A(D)?
2657	017365	045	116	045	ERL03::	.ASCIZ	?#N#ADRV CODE: #03#A(0) DRV FLGS: #03#A(0)?
2658	017454	045	116	045	ERL04::	.ASCIZ	?#N#ADRV STATE: #06#A(0) INTERN STATUS: #03#A(0)?
2659	017540	045	116	045	ERL05::	.ASCIZ	?#N#ATAP CNT 0: #03#A(0) TAP CNT 1: #03#A(0)?
2660	017627	045	116	045	ERL06::	.ASCIZ	?#N#ATAP CNT 2: #03#A(0) RD/WR STATE: #06#A(0)?
2661	017713	045	116	045	ERL07::	.ASCIZ	?#N#AOPER FLGS: #06#A(0)?
2662	017743	045	116	045	ERL08::	.ASCIZ	?#N#AERROR LOG PACKET?
2663	017770	045	116	045	NCLK::	.ASCIZ	?#N#A*/*/*/*/* CLOCK NOT PRESENT */*/*/*/*#N?
2664	020044	045	116	045	TIME::	.ASCIZ	?#N#A*/*/*/*/* TIME #Z2#A:#Z2#A:#Z2#A */*/*/*/*#N?
2665	020125	045	116	045	DAY::	.ASCIZ	?#N#A*/*/*/*/* START OF DAY #02#A */*/*/*/*#N?
2666	020202	045	101	102	COUNTS::	.ASCIZ	?#ABYTE COUNT: #D#A(D) FILE SIZE: #D#A(D)#N?
2667	020256	045	116	045	UNTEOT::	.ASCIZ	?#N#AUNIT: #01#A IS AT EOT#N?
2668	020312	045	116	045	UNTLOT::	.ASCIZ	?#N#AUNIT: #01#A IS AT LEOT#N?
2669	020347	045	116	045	DUMP::	.ASCIZ	?#N#AR1:#06#A R2:#06#A R3:#06#A R4:#06#A R5:#06#N?
2670	020430	045	116	045	DUMP1::	.ASCIZ	?#N#N#ABYTES X-FERRED: #D5#A(D)#N?
2671	020471	045	117	066	DUMP2::	.ASCIZ	?#06#S3#06#S3#06#S3#06#S3#06#N?
2672	020527	045	116	000	LINE::	.ASCIZ	?#N?
2673	020532	045	116	045	CONTRV::	.ASCII	/#N#AUNIT: #D1/
2674	020547	045	116	045		.ASCII	/#N#ACONTROLLER SOFTWARE VERSION : #D3/
2675	020614	045	116	045		.ASCII	/#N#ACONTROLLER HARDWARE VERSION : #D3/
2676	020662	045	116	045	UNITRV::	.ASCII	/#N#ADRIVE SOFTWARE VERSION : #D3/
2677	020727	045	116	045		.ASCII	/#N#ADRIVE HARDWARE VERSION : #D3#N#N/

```
2678 021001      045    116    045  BYPASS::      .ASCIZ /#N#A TEST #Z3#A BYPASSED#N/  
2679                .EVEN  
2680 021034                ENDMSG  
      021034                L10003:  
      021034 104423        TRAP    C#MSG
```

2682
2683
2684 021036
021036
2685 021036 000000
2686 021040 177777
2687 021042 177777
2688 021044
2689

;PROTECTION TABLE

BGNPROT
L\$PROT::
.WORD 0
.WORD -1
.WORD -1
ENDPROT

```

2691          .SBTTL  CLOCK HANDLER
2692
2693 021044    BGNSRV  NOCLK
      021044    NOCLK::
2694
2695 021044    105037  002212          CLRB   CLOCK          ;CLEAR THE CLOCK ENABLED BIT
2696 021050    052737  000002  003516  BIS    #NCLKFL,PCFLAG ;SET UP NO CLOCK PRESENT FLAG
2697 021056    012746  017770          PRINTF #NCLK          ;PRINT MESSAGE
      021056    012746  000001          MOV    #NCLK,-(SP)
      021062    012746  000001          MOV    #1,-(SP)
      021066    010600          MOV    SP,R0
      021070    104417          TRAP  C$PNTF
      021072    062706  000004          ADD   #4,SP
2698
2699 021076    ENDSRV
      021076    L10005:
      021076    000002          RTI
2700
2701 021100    BGNSRV  KWHDL
      021100    KWHDL::
2702
2703 021100    105237  002216          INCB  SUBSEC          ;INCREMENT THE SUB-SECOND COUNTER
2704 021104    122737  000074  002216  CMPB  #60.,SUBSEC     ;IS IT A SECOND YET ?
2705 021112    001051          BNE   HDLEXT         ;NO, GET OUT
2706 021114    105037  002216          CLRB  SUBSEC          ;CLEAR THE SUBSEC COUNTER
2707 021120    105237  002215          INCB  SECOND         ;INCREMENT THE SECONDS COUNTER
2708 021124    005237  010556          INC   TIMER          ;INCREMENT THE COMMAND TIMER
2709 021130    122737  000074  002215  CMPB  #60.,SECOND     ;IS IT A MINUTE YET ?
2710 021136    001037          BNE   HDLEXT         ;NO, GET OUT
2711 021140    105037  002215          CLRB  SECOND         ;CLEAR THE SECOND COUNTER
2712 021144    105237  002214          INCB  MINUTE         ;INCREMENT THE MINUTE COUNTER
2713 021150    122737  000074  002214  CMPB  #60.,MINUTE     ;IS IT AN HOUR YET ?
2714 021156    001027          BNE   HDLEXT         ;NO, GET OUT
2715 021160    105037  002214          CLRB  MINUTE         ;CLEAR THE MINUTE COUNTER
2716 021164    105237  002213          INCB  HOURS          ;INCREMENT THE HOUR COUNTER
2717 021170    122737  000030  002213  CMPB  #24.,HOURS      ;IS IT A DAY YET ?
2718 021176    001017          BNE   HDLEXT         ;NO, GET OUT
2719 021200    105037  002213          CLRB  HOURS          ;CLEAR THE HOURS COUNTER
2720 021204    105237  003564          INCB  DAYS           ;INCREMENT THE DAY COUNT
2721 021210    PRINTF  #DAY,<B,DAYS> ;PRINT END OF DAY STATMENT
      021210    005046          CLR   -(SP)
      021212    153716  003564          BISB  DAYS,(SP)
      021216    012746  020125          MOV   #DAY,-(SP)
      021222    012746  000002          MOV   #2,-(SP)
      021226    010600          MOV   SP,R0
      021230    104417          TRAP  C$PNTF
      021232    062706  000006          ADD   #6,SP
2722 021236    HDLEXT:
2723 021236    ENDSRV
      021236    L10006:
      021236    000002          RTI

```

```

2725 .SBTTL SCHEDULER
2726 ;*****
2727 ;
2728 ; SCHEDULER
2729 ;
2730 ;Called by      : Test N
2731 ;Calls to      : CMMDSQ
2732 ;Outputs       : EOT Flag, Dropped Flag
2733 ;Register Inputs: R5 (Pointer to command active in table - not used here)
2734 ;Registers Used: R4 (Pointer to LUN Block for use by called subs)
2735 ;
2736
2737 021240 SCHED::
2738 021240 005001 CLR R1 ;SET R1 TO FIST UNIT
2739 021242 005037 002074 CLR L$LUN ;SET L$LUN TO FIRST UNIT
2740 021246 012704 002314 MOV #LUN0,R4 ;SET R4 TO THE FIRST LUN BLOCK
2741 021252 022737 000003 002114 CMP #3,L$TEST ;ARE WE IN TEST 3 ?
2742 021260 001014 BNE 1$ ;YES, PRINT LINEFEED
2743 021262 122765 000020 000000 CMPB #WR,CMD(R5) ;IS IT A WRITE COMMAND ?
2744 021270 001010 BNE 1$ ;NO, GET OUT
2745 021272 PRINTF #LINE ;PRINT A LINE FEED
      021272 012746 020527 MOV #LINE,-(SP)
      021276 012746 000001 MOV #1,-(SP)
      021302 010600 MOV SP,R0
      021304 104417 TRAP C$PNTF
      021306 062706 000004 ADD #4,SP
2746 021312 032761 000001 003350 1$: BIT #AVB,DRINUS(R1) ;SEE IF DRIVE IS PRESENT AND AVAILABLE
2747 021320 001416 BEQ 2$ ;GET THE NEXT DRIVE IF IT ISN'T
2748 021322 032761 000004 003350 BIT #EOT,DRINUS(R1) ;CHECK IF THE DRIVE IS AT EOT
2749 021330 001012 BNE 2$ ;GET NEXT DRIVE IF IT IS
2750
2751 021332 012764 000377 000010 MOV #377,SLTUSE(R4) ;SET ALL RESPONSE SLOTS TO THE PORT
2752 021340 004737 026230 JSR PC,PRTCLR ;GO DO IT
2753 021344 112737 000004 010571 MOVB #4,CRDLIM ;CREDITS START AT 4 FOR NEW LUN
2754 021352 004737 021406 JSR PC,CMMDSQ ;GO DO THE TEST ON THIS DRIVE
2755
2756 021356 022701 000006 2$: CMP #6.,R1 ;HAVE WE DONE THEM ALL ?
2757 021362 001410 BEQ 3$ ;GET OUT
2758 021364 062701 000002 ADD #UNTSTP,R1 ;GET NEXT UNIT
2759 021370 062704 000172 ADD #LUNSTP,R4 ;SET UP THE NEXT LUN BLOCK
2760 021374 005237 002074 INC L$LUN ;GET NEXT UNIT
2761 021400 BREAK
      021400 104422 TRAP C$BRK
2762 021402 000743 BR 1$ ;GO DO THE NEXT ONE
2763 021404 000207 3$: RTS PC ;RETURN

```

```

2765 .SBTTL COMMAND SEQUENCER
2766 ;*****
2767 ;
2768 ;COMMAND SEQUENCER
2769 ;
2770 ;Called by : SCHED
2771 ;Calls to : CMDBLD, QCMD, CLSDRV, RSPHDR, UNJAM
2772 ;Register Inputs: R5 - POINTER TO COMMAND ACTIVE IN TABLE
2773 ; R4 - POINTER TO LUN BLOCK
2774 ;
2775 ;
2776 021406 CMMDSQ::
2777 021406 PUSH <R1,R5> ;SAVE R1 AND R5
021406 010146 MOV R1,-(SP) ;;PUSH R1 ON STACK
021410 010546 MOV R5,-(SP) ;;PUSH R5 ON STACK
2778 021412 004737 022002 JSR PC,CMDBLD ;GO BUILD THE COMMAND
2779 021416 042737 000200 003516 BIC #CMDONE,PCFLAG ;GET SET TO START ISSUING COMMANDS
2780 021424 013737 003420 003400 MOV ITERS,CMDCNT ;GET THE COMMAND COUNT
2781 021432 013737 003420 003402 MOV ITERS,RSPCNT ;GET THE RESPONSE COUNT
2782 021440 012737 177777 010550 MOV #-1,CMSTSV ;RESET THE GCS PROGRESS COUNT
2783
2784 021446 032737 000040 003516 5$: BIT #GCSRFL,PCFLAG ;STILL LOOKING FOR A GCS RESPONSE ?
2785 021454 001023 BNE 15$ ;DON'T QUEUE UP THE NEXT COMMAND
2786 021456 005737 003400 TST CMDCNT ;DO WE STILL HAVE COMMANDS TO ISSUE ?
2787 021462 001004 BNE 10$ ;YES, KEEP GOING.
2788 021464 052737 000200 003516 BIS #CMDONE,PCFLAG ;SET THE ALL COMMANDS ISSUED FLAG
2789 021472 000414 BR 15$
2790
2791 021474 004737 023050 10$: JSR PC,QCMD ;GO QUEUE UP THE NEXT COMMAND
2792 021500 032737 000002 003516 BIT #NCLKFL,PCFLAG ;IS A CLOCK PRESENT ?
2793 021506 001003 BNE 13$ ;NO CLOCK, START REGULAR TIMER
2794 021510 005037 010556 CLR TIMER ;SET TIMER TO 0
2795 021514 000403 BR 15$ ;GO ISSUE COMMAND
2796 021516 012737 010000 010556 13$: MOV #10000,TIMER ;SET UP THE TIMER
2797
2798 021524 15$: BREAK
021524 104422 TRAP C$BRK
2799 021526 004737 023444 JSR PC,CLSDRV ;CALL THE CLASS DRIVER
2800 021532 032737 000002 003516 BIT #NCLKFL,PCFLAG ;IS A CLOCK PRESENT ?
2801 021540 001007 BNE 18$ ;NO CLOCK, START REGULAR TIMER
2802 021542 022737 000171 010556 CMP #121.,TIMER ;HAVE WE TIMED OUT ?
2803 021550 101012 BHI 20$ ;NO, KEEP GOING
2804 021552 005037 010556 CLR TIMER ;SET TIMER TO 0
2805 021556 000414 BR 25$ ;YES,SET UP FOR TIME OUT
2806
2807 021560 005337 010556 18$: DEC TIMER ;DECREMENT THE TIMER
2808 021564 001004 BNE 20$ ;BRANCH IF NOT 0
2809 021566 012737 010000 010556 MOV #10000,TIMER ;RESET THE TIMER
2810 021574 000405 BR 25$ ;SET TIME OUT ERROR
2811
2812 021576 022737 020000 010546 20$: CMP #IOICRD,IOSTAT ;INSUFFICIENT CREDITS ?
2813 021604 001747 BEQ 15$ ;YES, TRY AGAIN
2814 021606 000425 BR 35$ ;YES, CHECK IT OUT
2815
2816 021610 032737 000040 003516 25$: BIT #GCSRFL,PCFLAG ;WAITING FOR A GCS RESPONSE ?
2817 021616 001412 BEQ 30$ ;NO, SET UP TO DO A GCS
2818 021620 042737 000040 003516 BIC #GCSRFL,PCFLAG ;CLEAR THE GCS RESPONSE FLAG
    
```

```

2819 021626 012737 000004 010546      MOV      #IOTIME,IOSTAT      ;SET UP TIME OUT ERROR
2820 021634 004737 033734      JSR      PC,CORDMP          ;DO A VARIABLES DUMP
2821 021640 000240      NOP
2822 021642 000407      BR       35$                ;GO REPORT ERROR AND DROP UNIT
2823
2824 021644 052737 000020 003516 30$:  BIS      #GCSCFL,PCFLAG      ;SET THE GCS COMMAND FLAG
2825 021652 052737 000040 003516      BIS      #GCSRFL,PCFLAG      ;SET THE GCS RESPONSE FLAG
2826 021660 000721      BR       15$                ;GO ISSUE THE GCS COMMAND
2827
2828 021662 022737 060000 010546 35$:  CMP      #ERRLOG!IOICRD,IOSTAT ;DID WE GET ERROR LOG PACKET ONLY?
2829 021670 001406      BEQ      40$                ;YES - SO BRANCH AROUND NEXT INSTRUCTION
2830 021672 032737 000240 003516      BIT      #CMDONE!GCSRFL,PCFLAG ;HAVE ALL COMMANDS BEEN ISSUED ?
2831 021700 001002      BNE      40$                ;YES, DON'T LET CMDCNT GO NEGATIVE
2832 021702 005337 003400      DEC      CMDCNT              ;DECREMENT THE COMMAND COUNT
2833 021706 022737 000000 010546 40$:  CMP      #IONORM,IOSTAT      ;WAS IT A NORMAL COMPLETION ?
2834 021714 001414      BEQ      45$                ;YES , GET OUT
2835 021716 004737 027426      JSR      PC,RSPHDL           ;NO, LETS SEE WHAT IT WAS
2836
2837 021722 032737 020000 010546      BIT      #IOICRD,IOSTAT      ;WERE WE IN RSPHDL FOR ERROR LOG ONLY?
2838 021730 001275      BNE      15$                ;YES - GO TRY TO POST SAME COMMAND.
2839 021732 022737 000002 003406      CMP      #SEREXC,RESPON      ;WAS IT A SERIOUS EXCEPTION ?
2840 021740 001002      BNE      45$                ;NO, CONTINUE
2841 021742 004737 033242      JSR      PC,UNJAM           ;YES, GO UNJAM THE QUEUES
2842
2843 021746 032761 000001 003350 45$:  BIT      #AVB,DRINUS(R1)      ;HAS THE DRIVE BEEN DROPPED ?
2844 021754 001407      BEQ      50$                ;YES, EXIT
2845 021756 005737 003402      TST      RSPCNT              ;HAVE WE GOTTEN ALL THE RESPONSE BACK ?
2846 021762 001231      BNE      5$                 ;NO, GO BACK TO THE TOP
2847 021764 032737 000040 003516      BIT      #GCSRFL,PCFLAG      ;STILL LOOKING FOR A GCS RESPONSE ?
2848 021772 001225      BNE      5$                 ;YES, DON'T GET OUT YET
2849
2850 021774      50$:  POP      <R5,R1>            ;RESTORE REGISTERS R1 AND R5
      021774 012605      MOV      (SP)+,R5           ;;POP STACK INTO R5
      021776 012601      MOV      (SP)+,R1           ;;POP STACK INTO R1
2851 022000 000207      RTS      PC                 ;RETURN

```

```

2853 .SBTTL COMMAND BUILDER
2854 ;*****
2855 ;
2856 ;COMMAND BUILDER
2857 ;
2858 ;Called by : CMMDSQ
2859 ;Calls to : BYTCNT, SELDAT, SELREC
2860 ;Register Inputs: R5 - pointer to test's command table
2861 ; R4 - pointer to LUN BLOCK
2862 ;Register Output: R3 - new pointer for command ring (set to start of ring)
2863 ; R2 - old pointer for command ring (set to start of ring)
2864 ;Registers Used : R3 Pointer to dummy packet before setting to command ring
2865 ;
2866 ;
2867 022002 CMDBLD::
2868 022002 012737 000004 003424 MOV #N,SUBCNT ;INITIALIZE THE SUB-ITERATION COUNTER
2869 022010 012703 003344 MOV #DUMPKT,R3 ;PUT THE DUMMY PACKET ADDRESS IN R3
2870 022014 116563 000000 000000 MOVB CMD(R5),CMD(R3) ;MOVE THE COMMAND PRIMITIVE TO THE PACKET
2871 ;
2872 022022 004737 022124 JSR PC,BYTCNT ;GO GET THE BYTE COUNT
2873 022026 013763 003416 000002 MOV BYTES,ITMOFF(R3) ;PUT THE BYTE COUNT IN THE DUMMY PACKET
2874 022034 004737 022212 JSR PC,SELDAT ;GO GET THE DATA
2875 022040 004737 022644 JSR PC,SELREC ;GO GET THE RECORD COUNT
2876 ;
2877 022044 022737 000003 002114 CMP #3,L$TEST ;ARE WE IN TEST 3 ?
2878 022052 001020 BNE 5$ ;YES, PRINT COUNTS
2879 022054 122765 000020 000000 CMPB #WR,CMD(R5) ;IS IT A WRITE COMMAND ?
2880 022062 001014 BNE 5$ ;NO, GET OUT
2881 022064 PRINTF #COUNTS,BYTES,ITERS ;YES, PRINT BYTE AND ITERATION COUNTS
2882 022064 013746 003420 MOV ITERS,-(SP)
2883 022070 013746 003416 MOV BYTES,-(SP)
2884 022074 012746 020202 MOV #COUNTS,-(SP)
2885 022100 012746 000003 MOV #3,-(SP)
2886 022104 010600 MOV SP,R0
2887 022106 104417 TRAP C$PNTF
2888 022110 062706 000010 ADD #10,SP
2889 ;
2890 5$: MOV #PCMDBF,R3 ;PUT THE PROGRAM COMMAND RING ADDRESS IN
2891 MOV R3,R2 ;R3 AND R2
2892 RTS PC ;RETURN

```



```

2889      .SBTTL  BYTE COUNT
2890      ;*****
2891      ;
2892      ; BYTE COUNT
2893      ;
2894      ;Called by      : CMDBLD
2895      ;Calls to      : RANGEN
2896      ;Outputs       : BYTES (contains byte or item count to be used for this iteration set)
2897      ;Register Inputs: R5 - pointer to test command table
2898      ;               R4 - pointer to LUN BLOCK
2899      ;Register Output: None
2900      ;Registers Used : None
2901      ;
2902      ;
2903      022124      BYTCNT::
2904      022124      005037      003416      CLR      BYTES      ;CLEAR BYTES
2905      022130      005765      000002      TST      ITMCNT(R5) ;CHECK ITMCNT FOR 0
2906      022134      001404      BEQ      1$          ;CONTINUE IF IT IS 0
2907      022136      016537      000002      003416  MOV      ITMCNT(R5),BYTES ;PUT ITMCNT INTO BYTES
2908      022144      000421      BR       3$          ;EXIT
2909      ;
2910      022146      122765      000020      000000  1$:      CMPB     #WR,CMD(R5) ;IS IT A READ OR WRITE
2911      022154      103415      BLO     3$          ;GET OUT IF IT ISN'T
2912      ;
2913      022156      004737      022716      2$:      JSR      PC,RANGEN ;GO TO THE RANDOM GENERATOR
2914      022162      023727      003426      020000  CMP      RANWRD,#MAXBUF ;IS THE RESULT WITHIN THE LIMITS ?
2915      022170      101372      BHI     2$          ;BRANCH IF TOO HIGH
2916      022172      023727      003426      000024  CMP      RANWRD,#MINBUF ;IS IT TOO SMALL ?
2917      022200      103766      BLO     2$          ;BRANCH IF TOO SMALL
2918      022202      013737      003426      003416  MOV      RANWRD,BYTES ;PUT RANWRD INTO BYTES
2919      022210      000207      3$:      RTS      PC      ;RETURN

```

```

2921 .SBTTL SELECT DATA PATTERN
2922 ;*****
2923 ;
2924 ; SELECT DATA PATTERN
2925 ;
2926 ;Called by      : CMDBLD
2927 ;Calls to      : RANGEN
2928 ;Inputs       : Data Pattern in test command table
2929 ;              : PATSAV in LUN BLOCK if rotating pattern in use
2930 ;Outputs      : Write Buffer filled with appropriate data pattern
2931 ;              : PATSAV in LUN BLOCK updated to next pattern
2932 ;Register Inputs: R5 - pointer to test command table
2933 ;              : R4 - pointer to LUN BLOCK
2934 ;Registers Used : R3 - pointer to WRTBUF
2935 ;              : R2 - pointer to data pattern
2936 ;
2937 ;
2938 SELDAT::
2939     PUSH    <R1,R5>                ;SAVE R1 AND R5
2940     TSTB   DATPAT(R5)              ;TEST DATPAT FOR A TEST PATTERN
2941     BEQ    20$                     ;BRANCH IF WE DON'T NEED ONE
2942     TSTB   PATERN                  ;PATTERN SPECIFIED IN SOFTWARE P-TABLE ?
2943     BEQ    1$                      ;NO, KEEP GOING
2944     MOVB   PATERN,PATSAV(R4)      ;PUT THE PATTERN IN THE SAVE LOCATION
2945     BR     10$
2946
2947     1$:   TSTB   DATPAT(R5)          ;DO WE WANT ROTATING DATA PATTERNS ?
2948     BMI   5$                       ;IF NEGATIVE GO TO 5$
2949     MOVB   DATPAT(R5),PATSAV(R4)   ;LET PATSAV EQUAL DATPAT
2950     BR     10$                     ;BRANCH
2951
2952     5$:   INC    PATSAV(R4)          ;ADD 1 TO PATSAV
2953     CMP    PATSAV(R4),#ENDPAT      ;ARE WE AT THE END OF THE PATTERN TABLE ?
2954     BNE   10$                       ;NO, KEEP GOING
2955     MOV    #1.,PATSAV(R4)         ;AT THE END, LET PATSAV EQUAL 1
2956
2957     10$:  MOV    BYTES,R5           ;PUT THE BYTE COUNT IN R5
2958     BIT    #BIT0,R5                ;IS THE BYTE COUNT ODD ?
2959     BEQ   15$                       ;BRANCH IF NOT
2960     INC    R5                       ;MAKE BYTE COUNT EVEN FOR PATGEN
2961
2962     15$:  MOV    #WRTBUF,R3         ;POINT R3 TO THE WRITE BUFFER
2963     MOVB   PATSAV(R4),R1           ;SAVE PATSAV IN R1
2964     DEC    R1                       ;ADJUST FOR TABLE STEP
2965     ASL    R1                       ;MAKE IT MOD 2 OFFSET
2966
2967     20$:  JSR    PC,@PATTBL(R1)     ;GO FILL THE BUFFER
2968     POP    <R5,R1>                 ;RESTORE R5 AND R1
2969     RTS    PC                       ;RETURN
2970
2971 PATTBL::
2972     .WORD  PATGN1                   ;ALL 1'S
2973     .WORD  PATGN2                   ;ALL 0'S
2974     .WORD  PATGN3                   ;WORST CASE MFM
2975     .WORD  PATGN4                   ;ALTERNATE 1'S AND 0'S
2976     .WORD  PATGN5                   ;RANDOM DATA
2977

```

```

2978 022356 022504          .WORD  PATGN6          ;1110 REPEATING PATTERN
2979 022360 022520          .WORD  PATGN7          ;COMBINATION PAT 3 AND 5
2980
2981 022362                PATGN1:
2982 022362 012723 177777    MOV    #-1,(R3)+      ;PUT ALL 1'S INTO THE BUFFER
2983 022366 162705 000002    SUB    #2,R5          ;SUBTRACT TWO FROM R5
2984 022372 001373          BNE    PATGN1         ;KEEP GOING IF WE AREN'T AT 0
2985 022374 000207          RTS    PC             ;RETURN
2986
2987 022376                PATGN2:
2988 022376 005023          CLR    (R3)+          ;PUT ALL 0'S INTO THE BUFFER
2989 022400 162705 000002    SUB    #2,R5          ;SUBTRACT TWO FROM R5
2990 022404 001374          BNE    PATGN2         ;KEEP GOING IF WE AREN'T AT 0
2991 022406 000207          RTS    PC             ;RETURN
2992
2993 022410                PATGN3:
2994 022410 012723 133333    MOV    #133333,(R3)+ ;PUT THE NUMBER INTO THE BUFFER
2995 022414 162705 000002    SUB    #2,R5          ;SUBTRACT TWO FROM R5
2996 022420 001412          BEQ    1$            ;KEEP GOING IF WE AREN'T AT 0
2997 022422 012723 155555    MOV    #155555,(R3)+ ;PUT THE NUMBER INTO THE BUFFER
2998 022426 162705 000002    SUB    #2,R5          ;SUBTRACT TWO FROM R5
2999 022432 001405          BEQ    1$            ;KEEP GOING IF WE AREN'T AT 0
3000 022434 012723 066666    MOV    #066666,(R3)+ ;PUT THE NUMBER INTO THE BUFFER
3001 022440 162705 000002    SUB    #2,R5          ;SUBTRACT TWO FROM R5
3002 022444 001361          BNE    PATGN3         ;KEEP GOING IF WE AREN'T AT 0
3003 022446 000207          1$:  RTS    PC             ;RETURN
3004
3005 022450                PATGN4:
3006 022450 012723 125252    MOV    #125252,(R3)+ ;PUT ALTERNATING 1 AND 0 INTO THE BUFFER
3007 022454 162705 000002    SUB    #2,R5          ;SUBTRACT TWO FROM R5
3008 022460 001373          BNE    PATGN4         ;KEEP GOING IF WE AREN'T AT 0
3009 022462 000207          RTS    PC             ;RETURN
3010
3011 022464                PATGN5:
3012 022464 004737 022716    JSR    PC,RANGEN      ;GO GENERATE RANDOM PATTERN
3013 022470 013723 003426    MOV    RANWRD,(R3)+  ;PUT THE NUMBER INTO THE BUFFER
3014 022474 162705 000002    SUB    #2,R5          ;SUBTRACT TWO FROM R5
3015 022500 001371          BNE    PATGN5         ;KEEP GOING IF WE AREN'T AT 0
3016 022502 000207          RTS    PC             ;RETURN
3017
3018 022504                PATGN6:
3019 022504 012723 167356    MOV    #167356,(R3)+ ;PUT 1110 REPEATING IN BUFFER
3020 022510 162705 000002    SUB    #2,R5          ;SUBTRACT TWO FROM R5
3021 022514 001373          BNE    PATGN6         ;KEEP GOING IF WE AREN'T AT 0
3022 022516 000207          RTS    PC             ;RETURN
3023
3024 022520                PATGN7:
3025 022520          PUSH    <R2>
3026 022522 012702 001000    1$:  MOV    #512.,R2
3027 022526 012723 133333    3$:  MOV    #133333,(R3)+ ;PUT THE NUMBER INTO THE BUFFER
3028 022532 162705 000002    SUB    #2,R5          ;SUBTRACT TWO FROM R5
3029 022536 001440          BEQ    10$           ;KEEP GOING IF WE AREN'T AT 0
3030 022540 162702 000002    SUB    #2,R2          ;HAVE WE DONE A FULL BLOCK YET
3031 022544 001420          BEQ    5$            ;YES DO NEXT BLOCK IN PATTERN 5
3032 022546 012723 155555    MOV    #155555,(R3)+ ;PUT THE NUMBER INTO THE BUFFER
3033 022552 162705 000002    SUB    #2,R5          ;SUBTRACT TWO FROM R5
3034 022556 001430          BEQ    10$           ;KEEP GOING IF WE AREN'T AT 0
    
```



```

3055      .SBTTL  SELECT RECORD
3056      ;*****
3057      ;
3058      ; SELECT RECORD
3059      ;
3060      ;Called by      : CMDBLD
3061      ;Calls to      : RANGEN
3062      ;Outputs       : ITERS (number of iterations for this set)
3063      ;Register Inputs: R5 - pointer to test command table
3064      ;               : R4 - pointer to LUN BLOCK
3065      ;
3066      ;
3067 022644 SELREC::
3068 022644 005765 000004      TST      ITRCNT(R5)      ;TEST THE ITERATION COUNT
3069 022650 001016      BNE      10$          ;IF IT ISN'T 0 THEN BRANCH
3070 022652 004737 022716      JSR      PC,RANGEN      ;GO TO THE RANDOM GENERATOR
3071 022656 023727 003426 003720  CMP      RANWRD,#MAXITR  ;IS THE ITERATION COUNT TO HIGH ?
3072 022664 101372      BHI      5$          ;GO TRY AGAIN
3073 022666 023727 003426 000144  CMP      RANWRD,#MINITR  ;IS THE ITERATION SET TOO SMALL ?
3074 022674 103766      BLO      5$          ;GO TRY AGAIN
3075 022676 013737 003426 003420  MOV      RANWRD,ITERS    ;SAVE THE RANDOM NUMBER
3076 022704 000403      BR       15$          ;EXIT
3077 022706 016537 000004 003420 10$:  MOV      ITRCNT(R5),ITERS ;SAVE THE ITERATION COUNT
3078 022714 000207      15$:  RTS      PC          ;RETURN

```

```

3080 .SBTTL RANDOM NUMBER GENERATOR
3081 ;*****
3082 ;
3083 ;RANDOM NUMBER GENERATOR
3084 ;
3085 ;Called by      : BYTCNT, SELDAT, SELREC
3086 ;Inputs        : RAN1, RAN2, RAN3
3087 ;Outputs       : RANWRD
3088 ;Registers Used : R5
3089 ;
3090
3091 022716 RANGEN::
3092 022716      PUSH      <R5>                ;SAVE R5
3093 022720 016437 000144 003430      MOV      SEED1(R4),RAN1          ;PUT SEED1 INTO RAN1
3094 022726 016437 000146 003432      MOV      SEED2(R4),RAN2          ;PUT SEED2 INTO RAN2
3095 022734 016437 000150 003434      MOV      SEED3(R4),RAN3          ;PUT SEED3 INTO RAN3
3096 022742 013705 003430      MOV      RAN1,R5                ;MOVE THE FIRST SEED INTO R5
3097 022746 000241      CLC                          ;CLEAR THE CARRY FLAG
3098 022750 005337 003434      DEC      RAN3                    ;DECREMENT THE THIRD SEED
3099 022754 006105      ROL      R5
3100 022756 006105      ROL      R5
3101 022760 063705 003432      ADD      RAN2,R5                ;ADD THE SECOND SEED TO R5
3102 022764 010537 003430      MOV      R5,RAN1                ;PUT IT ALL IN THE FIRST SEED
3103 022770 063705 003434      ADD      RAN3,R5                ;PUT THE THIRD SEED INTO R5
3104 022774 006105      ROL      R5
3105 022776 006105      ROL      R5
3106 023000 063705 003432      ADD      RAN2,R5                ;ADD THE SECOND SEED TO R5
3107 023004 006105      ROL      R5
3108 023006 006105      ROL      R5
3109 023010 010537 003432      MOV      R5,RAN2                ;PUT IT IN THE SECOND SEED
3110 023014 013737 003430 003426      MOV      RAN1,RANWRD            ;PUT THE FIRST SEED INTO RANWORD
3111 023022 013764 003430 000144      MOV      RAN1,SEED1(R4)         ;PUT RAN1 INTO SEED1
3112 023030 013764 003432 000146      MOV      RAN2,SEED2(R4)         ;PUT RAN2 INTO SEED2
3113 023036 013764 003434 000150      MOV      RAN3,SEED3(R4)         ;PUT RAN3 INTO SEED3
3114 023044      POP      <R5>                ;RESTORE R5
3115 023046 000207      RTS      PC                    ;EXIT

```

```

3117      .SBTTL  QUEUE COMMANDS
3118      ;*****
3119      ;
3120      ; QUEUE COMMANDS
3121      ;
3122      ;Called by      : CMMDSQ
3123      ;Calls to      : SUBITR
3124      ;Register Inputs: R3 - pointer to next slot in ring
3125      ;                R4 - pointer to LUN BLOCK
3126      ;Register Output: R3 - updated to point to next available slot
3127      ;Registers Used : R5 - Points to dummy packet
3128      ;
3129
3130      QCMD::
3131      023050 022703 003344      CMP      #PCBEND,R3      ;IS R3 POINTING AT THE END OF THE RING ?
3132      023054 001002              BNE      1$              ;NO, THEN KEEP GOING
3133      023056 012703 003264      MOV      #PCMDBF,R3     ;YES, SET IT TO THE RING BEGINNING
3134      023062 012705 003344      1$:     MOV      #DUMPKT,R5  ;POINT R5 TO THE DUMMY PACKET
3135      023066 116563 000000 000000  MOVB     CMD(R5),CMD(R3) ;PUT THE COMMAND PRIMITIVE INTO THE RING
3136      023074 016563 000002 000002  MOV      ITMOFF(R5),ITMOFF(R3) ;PUT THE ITEM OFFSET INTO THE RING
3137
3138      023102 004737 023276              JSR      PC,OBCTHD      ;GO GET THE OBJECT COUNT
3139      023106 016463 000034 000004  MOV      OBJFDL(R4),OBOFFL(R3) ;PUT THE LOW FIELD INTO THE RING
3140      023114 016463 000036 000006  MOV      OBJFDH(R4),OBOFFH(R3) ;PUT THE HIGH FIELD INTO THE RING
3141
3142      023122 004737 023142              JSR      PC,SUBITR      ;GO TO SUB-ITERS
3143      023126 013763 003422 000012  MOV      BUFADR,BUFOFF(R3) ;PUT THE BUFFER ADDRESS INTO THE RING
3144      023134 062703 000014              ADD      #PCBSTP,R3     ;MOVE R3 TO THE NEXT SLOT IN THE RING
3145      023140 000207              RTS      PC              ;RETURN

```

```

3147      .SBTTL SUB-ITERATION
3148      ;*****
3149      ;
3150      ; SUB-ITERATION
3151      ;
3152      ;Called by      : QCMD
3153      ;Outputs       : BUFADR
3154      ;Register Inputs: R3 - pointer to command slot
3155      ;               : R4 - pointer to LUN BLOCK
3156      ;
3157      ;
3158      SUBITR::
3159      023142 105763 000000      TSTB   CMD(R3)      ;ARE WE ISSUING NULL COMMANDS ?
3160      023146 001452          BEQ     10$          ;BRANCH IF THE NULL COMMAND
3161      023150 122763 000020 000000  CMPB   #WR,CMD(R3)  ;IS IT GREATER THAN A WRITE
3162      023156 103446          BLO     10$          ;YES, BRANCH
3163
3164      023160 005337 003424      1$:   DEC   SUBCNT      ;SUBTRACT 1 FROM SUBCNT
3165      023164 001025          BNE     5$          ;BRANCH IF NOT 0
3166      023166 016337 000004 070550  MOV   OBOFFL(R3),WRTBUF-2 ;PUT LOW ORDER OBJECT COUNT IN WRTBUF
3167      023174 012737 000004 003424  MOV   #N,SUBCNT        ;REINIT SUBCNT
3168      023202 012737 050552 003422  4$:   MOV   #RDBUF,BUFADR  ;PUT THE READ BUFFER ADDRESS IN BUFADR
3169      023210 122763 000020 000000  CMPB   #WR,CMD(R3)  ;IS IT A WRITE COMMAND
3170      023216 001026          BNE     10$         ;GET OUT IF IT'S NOT
3171      023220 022737 000003 002114  CMP   #3,L$TEST      ;ARE WE IN TEST 3 ?
3172      023226 001017          BNE     7$          ;NO, SET WRITE BUFFER IN BUFADR
3173      023230 012737 070550 003422  MOV   #WRTBUF-2,BUFADR ;SET MODIFIED WRITE BUFFER IN BUFADR
3174      023236 000416          BR      10$         ;EXIT
3175
3176      023240 122763 000020 000000  5$:   CMPB   #WR,CMD(R3)  ;SEE IF ITS A WRITE
3177      023246 001407          BEQ     7$          ;YES, BRANCH
3178      023250 022737 000006 002114  CMP   #6,L$TEST      ;ARE WE IN TEST 6 ?
3179      023256 001751          BEQ     4$          ;YES, PUT READ BUFFER IN BUFADR
3180      023260 112763 000040 000000  MOVB  #ACC,CMD(R3)   ;SET UP A COMPARE HOST DATA COMMAND
3181      023266 012737 070552 003422  7$:   MOV   #WRTBUF,BUFADR ;SET WRTBUF ADDRESS IN BUFADR
3182      023274 000207          10$:  RTS    PC          ;RETURN

```



```

3184 .SBTTL OBJET COUNT HANDLER
3185 ;*****
3186 ;
3187 ; OBJECT COUNT HANDLER
3188 ;
3189 ;Called by      : QCMD
3190 ;Inputs        : Current Object Count in LUN BLOCK
3191 ;Outputs       : Updated Object Count in LUN BLOCK
3192 ;Register Inputs: R3 - pointer to command slot
3193 ;              : R4 - pointer to LUN BLOCK
3194 ;
3195 ;
3196 023276 OBCTHD::
3197 023276          PUSH      <R1>                ;SAVE R1
3198 023300 116301 000000          MOVB     CMD(R3),R1          ;PUT THE COMMAND PRIMITIVE INTO R1
3199 023304 042701 000007          BIC     #7,R1            ;STRIP OFF THE MODIFIERS
3200 023310 005701                TST     R1                ;IS IT THE NULL COMMAND ?
3201 023312 001452                BEQ     6$                ;EXIT IF IT IS
3202 023314 022701 000160          CMP     #REW,R1          ;IS IT A REWIND ?
3203 023320 001005                BNE     1$                ;BRANCH IF NOT
3204 023322 005064 000034          CLR     OBJFDL(R4)      ;CLEAR THE OBJECT
3205 023326 005064 000036          CLR     OBJFDH(R4)      ;COUNT FIELD AND
3206 023332 000442                BR      6$                ;EXIT
3207
3208 023334 022701 000050          1$:    CMP     #SPC,R1          ;IS IT A NON-DATA TRANSFER COMMAND ?
3209 023340 101007                BHI     2$                ;BRANCH IF IT IS
3210 023342 022701 000100          CMP     #WTM,R1          ;IS IT A WRITE TAPE MARK ?
3211 023346 001404                BEQ     2$                ;BRANCH IF IT IS
3212 023350 016337 000002 003530  MOV     ITMOFF(R3),R8    ;PUT THE ITEM COUNT IN TEMP REGISTER
3213 023356 000403                BR      3$                ;CONTINUE
3214
3215 023360 012737 000001 003530  2$:    MOV     #1,R8            ;PUT A 1 IN THE TEMP REGISTER
3216 023366 032763 000002 000000  3$:    BIT     #EOTBIT,CMD(R3)  ;IS IT AN LEOT COMMAND ?
3217 023374 001021                BNE     6$                ;GET OUT IF IT IS
3218 023376 032763 000001 000000  BIT     #REVBIT,CMD(R3)  ;IS THE COMMAND REVERSE ?
3219 023404 001007                BNE     4$                ;BRANCH IF REVERSE
3220 023406 063764 003530 000034  ADD     R8,OBJFDL(R4)    ;ADD TEMP TO THE OBJECT COUNT
3221 023414 103011                BCC     6$                ;BRANCH IF NO CARRY
3222 023416 005264 000036          INC     OBJFDH(R4)      ;OTHERWISE ADD 1 TO THE HIGH OBJECT COUNT
3223 023422 000406                BR      6$                ;EXIT
3224
3225 023424 163764 003530 000034  4$:    SUB     R8,OBJFDL(R4)    ;IF REVERSE, SUBTRACT TEMP FROM THE
3226 023432 103002                BCC     6$                ;OBJECT COUNT AND BRANCH IF NO CARRY
3227 023434 005364 000036          DEC     OBJFDH(R4)      ;OTHERWISE SUBTRACT 1 FROM OBJECT COUNT HIGH
3228 023440                6$:    POP     <R1>            ;RESTORE R1
3229 023442 000207                RTS     PC                ;EXIT

```

```

3231 .SBTTL CLASS DRIVER TRANSMIT
3232 ;*****
3233 ;
3234 ;Class Driver Transmit
3235 ;
3236 ;Called By      : CMMDSQ
3237 ;Calls To       : CDRECV, STFPCK, PRTRV
3238 ;Inputs         : CRDLIM - Command slots open in the drive.
3239                : COLSAV - Old driver command pointer.
3240 ;Outputs        : IOSTAT - Transfer status.
3241                : CMDSEQ - Number appended to each command packet.
3242                : GCSREF - Get Command Status reference number.
3243 ;Register Inputs: R2 - Old pointer to program command ring.
3244                : R3 - New pointer to program command ring.
3245                : R4 - Lun block pointer.
3246 ;Register Outputs: R5 - Old pointer to driver command ring.
3247 ;
3248 ;
3249 023444 CLSDRV::
3250 023444          PUSH      <R3,R5>          ;SAVE R3, R5
3251 023450 016405 000016          MOV      COLSAV(R4),R5          ;POINT R5 TO THE OLD DRIVER COMMAND
3252 023454 032737 000040 003516          BIT      #GCSRFL,PCFLAG        ;IS THIS A GCS COMMAND ?
3253 023462 001010                BNE      10$                    ;YES, GO SETUP
3254 023464 022703 003264          CMP      #PCMDBF,R3           ;IS R3 AT THE BEGINNING OF THE PROGRAM RING ?
3255 023470 001403                BEQ      5$                      ;YES, BRANCH
3256 023472 162703 000014          SUB      #PCBSTP,R3           ;NO, MOVE R3 ONE SLOT BACK
3257 023476 000402                BR       10$                    ;CONTINUE
3258 ;
3259 023500 062703 000044          5$:    ADD      #PCB3SP,R3          ;YES, ADVANCE R3 TWO SLOTS
3260 023504 005037 010546          10$:   CLR      IOSTAT             ;CLEAR THE I/O STATUS WORD
3261 023510 122763 000170 000000          CMPB    #INT,CMD(R3)          ;IS THIS A INITIALIZATION COMMAND ?
3262 023516 001003                BNE      15$                    ;CONTINUE IF IT ISN'T
3263 ;
3264 023520 004737 026306          JSR      PC,PRINT              ;CALL THE PORT INIT ROUTINE
3265 023524 000464                BR       55$                    ;EXIT
3266 023526 005764 000010          15$:   TST      SLTUSE(R4)        ;DID WE HANDLE ANY RESPONSES LAST TIME ?
3267 023532 001402                BEQ      20$                    ;BRANCH IF NOT
3268 023534 004737 026230          JSR      PC,PRTCLR             ;GO CLEAR THE OLD RESPONSES
3269 ;
3270 023540 004737 023710          20$:   JSR      PC,CDRECV           ;GO CHECK FOR ANY NEW RESPONSES
3271 023544 105737 010546          TSTB    IOSTAT                 ;IS THE I/O STATUS O.K. ?
3272 023550 001052                BNE      55$                    ;EXIT IF IT ISN'T
3273 ;
3274 023552 032737 000020 003516          25$:   BIT      #GCSCFL,PCFLAG        ;IS THIS A GCS COMMAND ?
3275 023560 001010                BNE      30$                    ;YES, GO SETUP MINLIM
3276 023562 032737 000200 003516          BIT      #CMDONE,PCFLAG        ;IS THIS A NULL COMMAND ?
3277 023570 001042                BNE      55$                    ;EXIT IF IT IS
3278 023572 032763 000200 000000          BIT      #IMM,CMD(R3)          ;IS THIS AN IMMEDIATE COMMAND ?
3279 023600 001404                BEQ      35$                    ;NO, BRANCH
3280 023602 112737 000001 010570          30$:   MOVB    #1,MINLIM           ;YES, SET MINIMUM LIMIT TO 1
3281 023610 000403                BR       40$                    ;BRANCH
3282 ;
3283 023612 112737 000002 010570          35$:   MOVB    #2,MINLIM           ;NO, SET MINIMUM LIMIT TO 2
3284 023620 123737 010571 010570          40$:   CMPB    CRDLIM,MINLIM        ;DO WE HAVE ENOUGH CREDITS ?
3285 023626 103004                BHIS    45$                    ;YES, KEEP GOING
3286 023630 052737 020000 010546          BIS     #IOICRD,IOSTAT         ;SET INSUFFICIENT CREDIT IN I/O STATUS
3287 023636 000417                BR       55$                    ;GET OUT

```

3288									
3289	023640	005264	000006		45\$:	INC	CMDSEQ(R4)		;ADD 1 TO THE COMMAND SEQUENCE NUMBER
3290	023644	032737	000020	003516		BIT	#GCSCFL,PCFLAG		;IS IT A GCS COMMAND ?
3291	023652	001403				BEQ	50\$;NO, BRANCH
3292	023654	016437	000006	010552		MOV	CMDSEQ(R4),GCSREF		;SAVE THE COMMAND REFERENCE NUMBER
3293									
3294	023662	105337	010571		50\$:	DECB	CRDLIM		;SUBTRACT 1 FROM THE CREDIT LIMIT
3295	023666	004737	024164			JSR	PC,STFPCK		;GO FILL THE TMSCP PACKET
3296	023672	004737	025730			JSR	PC,PRTDRV		;GO SEND THE COMMAND
3297									
3298	023676	010564	000016		55\$:	MOV	R5,COLSAV(R4)		;SAVE R5 IN COMMAND OLD POINTER SAVE
3299	023702					POP	<R5,R3>		;RESTORE R3, AND R5
3300	023706	000207				RTS	PC		;RETURN

```

3302 .SBTTL CLASS DRIVER RECEIVE
3303 ;*****
3304 ;
3305 ;Class Driver Receive
3306 ;
3307 ;Called By      : CLSDVR
3308 ;Calls To      : PDRECV, PRTCLR
3309 ;Inputs        : RESP - The number of RESPONSEs found.
3310 ;              : GCSREF - Get Command Status reference number.
3311 ;              : RNUSAV - New response buffer save
3312 ;              : CMSTSV - Command progress count.
3313 ;              : ELBSAV - Error log buffer pointer.
3314 ;Register Inputs: R2 - Old pointer to program command ring.
3315 ;              : R3 - New pointer to program command ring.
3316 ;              : R4 - Lun block pointer.
3317 ;              : R5 - Old pointer to driver command ring.
3318 ;Registers Used : R1 - Old pointer to driver RESPONSE ring.
3319 ;
3320 ;
3321 023710 CDRECV::
3322 023710          PUSH      <R1,R2>          ;SAVE R1,R2
3323 023714 016401 000020          MOV      RNUSAV(R4),R1          ;LET R1 = NEW RESPONSE BUFFER SAVE
3324 023720 004737 026106          JSR      PC,PDRECV            ;CALL PORT DRIVER RECEIVE
3325 023724 005737 003414          TST      RESP                ;DID WE GET A RESPONSE ?
3326 023730 001506                    BEQ      35$                  ;NO, GET OUT OF HERE
3327 023732 013737 003414 003412          MOV      RESP,HNDLRP         ;SAVE A COPY FOR RSPHDL
3328
3329 023740 022761 000022 000012 5$:          CMP      #ST.SEX,P.STS(R1)    ;IS IT A SERIOUS EXCEPTION ?
3330 023746 001425                    BEQ      10$                  ;YES, CONTINUE
3331 023750 005761 000000          TST      P.CRF(R1)           ;IS IT AN UNSOLICITED ERROR LOG ?
3332 023754 001422                    BEQ      10$                  ;YES, GO HANDLE ERROR LOG
3333 023756 026165 000000 000000          CMP      P.CRF(R1),P.CRF(R5) ;IS THIS THE COMMAND THAT IS EXPECTED ?
3334 023764 001416                    BEQ      10$                  ;YES, CONTINUE
3335 023766 023761 010552 000000          CMP      GCSREF,P.CRF(R1)    ;IS IT THE GCS END PACKET
3336 023774 001003                    BNE      7$                   ;NO, GO DO RESPONSE OUT OF SEQUENCE
3337 023776 004737 026530          JSR      PC,GCSHDL           ;GO TO THE GCS HANDLING ROUTINE
3338 024002 000461                    BR       35$                  ;GET OUT
3339
3340 024004 112737 000005 010546 7$:          MOV      #MISSEQ,IOSTAT      ;SET MISSING SEQUENCE IN I/O STATUS
3341 024012 004737 033734          JSR      PC,CORDMP
3342 024016 000240                    NOP
3343 024020 000452                    BR       35$                  ;EXIT
3344
3345 024022 032761 000200 000010 10$:         BIT      #OP.END,P.OPCD(R1)   ;YES, IS IT AN END PACKET ?
3346 024030 001427                    BEQ      20$                  ;NO, GO HANDLE ERROR LOG
3347 024032 052737 100000 010546          BIS      #NURESP,IOSTAT     ;SET A NEW RESPONSE IN THE I/O STATUS
3348 024040 105237 010571          INCB    CRDLIM              ;ADD 1 TO THE CREDIT LIMIT
3349 024044 062705 000050          ADD     #DCBSTP,R5          ;ADJUST THE OLD COMMAND POINTER
3350 024050 022705 004032          CMP     #DCBEND,R5         ;IS IT AT THE END OF THE RING ?
3351 024054 001002                    BNE     15$                  ;NO, BRANCH
3352 024056 012705 003572          MOV     #DCMDBF,R5         ;YES, SET IT TO THE TOP OF THE RING
3353
3354 024062 016162 000012 000010 15$:         MOV     P.STS(R1),XFERST(R2) ;PUT REPSONCE STATUS IN THE HOST PACKET
3355 024070 062702 000014          ADD     #PCBSTP,R2         ;ADJUST R2 TO POINT AT THE NEXT SLOT
3356 024074 022702 003344          CMP     #PCBEND,R2        ;IS IT AT THE END OF THE RING ?
3357 024100 001006                    BNE     25$                  ;NO, BRANCH
3358 024102 012702 003264          MOV     #PCMDBF,R2        ;YES, SET IT BACK TO TOP OF THE RING

```

3359	024106	000403				BR	25\$;BRANCH TO THE END
3360									
3361	024110	052737	040000	010546	20\$:	BIS	#ERRLOG,IOSTAT		;SET ERROR LOG IN I/O STATUS
3362	024116	005337	003414		25\$:	DEC	RESP		;SUBTRACT 1 FROM THE RESPONSE COUNT
3363	024122	062701	000104			ADD	#DRBSTP,R1		;ADJUST R1
3364	024126	026401	000160			CMP	URBEND(R4),R1		;IS IT AT THE END OF THE RING ?
3365	024132	001002				BNE	30\$;NO, KEEP GOING
3366	024134	016401	000156			MOV	URSPBF(R4),R1		;YES, SET IT TO BEGINNING OF THE RING
3367									
3368	024140	005737	003414		30\$:	TST	RESP		;HAVE WE DONE ALL THE RESPONSES ?
3369	024144	001275				BNE	5\$;NO, DO IT AGAIN
3370									
3371	024146	005037	003414		35\$:	CLR	RESP		;CLEAR NOW IN CASE WE MADE ERROR EXIT
3372	024152	010164	000020			MOV	R1,RNUSAV(R4)		;SAVE THE NEW RESPONSE BUFFER POINTER
3373	024156					POP	<R2,R1>		;RESTORE R2,R1
3374	024162	000207				RTS	PC		;RETURN

```

3376 .SBTTL COMMAND STUFFER
3377 ;*****
3378 ;
3379 ; Stuff TMSCP Command Packet
3380 ;
3381 ;Called By      : CLSDRV
3382 ;Inputs        : CNUSAV - Points to next slot in the driver command ring.
3383 ;              : CMDSEQ - Number appended to each command packet.
3384 ;              : GCSREF - Get Command Status reference number.
3385 ;              : SEREXP - Flag set non-zero on occurrence of a serious exception.
3386 ;Outputs       : PCKSIZ - Length in bytes of the command packet.
3387 ;Register Inputs: R3 - New pointer to program command ring.
3388 ;              : R4 - Lun block pointer.
3389 ;              : R5 - Old pointer to driver command ring.
3390 ;Registers Used: R1 - New pointer to driver command ring.
3391
3392 024164 STFPCK::
3393 024164      PUSH      <R1,R2>          ;SAVE R1 AND R2
3394 024170      005037 010564      CLR      PCKSIZ          ;CLEAR PACKET SIZE
3395 024174      016401 000014      MOV      CNUSAV(R4),R1   ;LET R1 EQUAL THE NEW COMMAND POINTER
3396 024200      016461 000006 000000  MOV      CMDSEQ(R4),P.CRF(R1) ;PUT COMMAND SEQUENCE NUMBER INTO PACKET
3397 024206      005061 000002      CLR      P.CRF+2(R1)    ;CLEAR THE UPPER WORD
3398 024212      016461 000004 000004  MOV      TKUNIT(R4),P.UNIT(R1) ;PUT THE UNIT NUMBER INTO THE PACKET
3399 024220      005061 000006      CLR      P.UNIT+2(R1)   ;CLEAR THE UPPER WORD
3400 024224      005061 000012      CLR      P.MOD(R1)     ;CLEAR MODIFIERS FIELD
3401 024230      032737 000020 003516  BIT      #GCSCFL,PCFLAG ;ARE WE IN GCS COMMAND MODE ?
3402 024236      001402              BEQ      5$            ;NO, CONTINUE
3403 024240      000137 025400      JMP      GCMDST        ;YES, GO DO A GET COMMAND STATUS
3404
3405 024244      016361 000002 000014 5$:  MOV      ITMOFF(R3),P.BCNT(R1) ;PUT THE BYTE COUNT INTO THE PACKET
3406 024252      005061 000016      CLR      P.BCNT+2(R1)   ;CLEAR THE UPPER WORD
3407 024256      016337 000000 003530  MOV      CMD(R3),R8     ;PUT THE PRIMITIVE IN R8
3408 024264      042737 177770 003530  BIC      #177770,R8    ;GET JUST THE MODIFIERS
3409 024272      022737 000001 003530  CMP      #REVBIT,R8   ;IS THE COMMAND A REVERSE ?
3410 024300      001003              BNE      10$          ;NO, BRANCH
3411 024302      052761 000010 000012  BIS      #MD.REV,P.MOD(R1) ;YES, SET REVERSE IN THE MODIFIER FIELD
3412
3413 024310      032764 000002 000026 10$: BIT      #SEREXC,LUNFLG(R4) ;IS IT A SERIOUS EXCEPTION CONDITION ?
3414 024316      001406              BEQ      15$          ;NO, BRANCH
3415 024320      052761 020000 000012  BIS      #MD.CSE,P.MOD(R1) ;YES, SET CLEAR SERIOUS EXCEPTION
3416 024326      042764 000002 000026  BIC      #SEREXC,LUNFLG(R4) ;CLEAR SERIOUS EXCEPTION FLAG
3417
3418 024334      116302 000000      15$: MOVVB   CMD(R3),R2      ;PUT THE COMMAND PRIMITIVE INTO R1
3419 024340      006202              ASR      R2
3420 024342      006202              ASR      R2
3421 024344      042702 177701      BIC      #1C76,R2     ;ADJUST FOR THE CASE STATEMENT
3422 024350      022702 000046      CMP      #46,R2      ;ARE WE IN THE RANGE ?
3423 024354      103002              BHS      20$          ;YES, KEEP GOING
3424 024356      000137 025604      JMP      ILCMD        ;NO, HANDLE AN ILLEGAL COMMAND
3425 024362      000172 024366      20$: JMP      @CMDTBL(R2)  ;SELECT
3426
3427 024366      024436      CMDTBL: .WORD  NULL
3428 024370      024442      .WORD  READ
3429 024372      024462      .WORD  WRITE
3430 024374      024502      .WORD  CHODAT
3431 024376      024522      .WORD  ACCESS
3432 024400      024542      .WORD  SPCRETC

```

```

3433 024402 024610 .WORD SKPTMK
3434 024404 024664 .WORD SPCOBJ
3435 024406 024722 .WORD WTAPMK
3436 024410 024750 .WORD ERASE
3437 024412 025006 .WORD ERASGP
3438 024414 025026 .WORD AVALAB
3439 024416 025064 .WORD ONLINE
3440 024420 025162 .WORD SUNCHR
3441 024422 025254 .WORD REWIND
3442 024424 025342 .WORD INIT
3443 024426 025346 .WORD ABOR
3444 024430 025400 .WORD GCMDST
3445 024432 025440 .WORD GUNSTA
3446 024434 025466 .WORD SCNTCH
3447
3448 024436 000137 025700 NULL: JMP COMEXI ;EXIT
3449
3450 024442 012761 000041 000010 READ: MOV #OP.RD,P.OPCD(R1) ;PUT THE READ OPCODE INTO THE PACKET
3451 024450 012737 000034 010564 MOV #34,PCKSIZ ;PUT THE PACKET SIZE INTO THE PACKET
3452 024456 000137 025616 JMP BUFDSC ;GOTO THE BUFFER DESCRIPTOR ROUTINE
3453
3454 024462 012761 000042 000010 WRITE: MOV #OP.WR,P.OPCD(R1) ;PUT THE WRITE OPCODE INTO THE PACKET
3455 024470 012737 000034 010564 MOV #34,PCKSIZ ;PUT THE PACKET SIZE INTO THE PACKET
3456 024476 000137 025616 JMP BUFDSC ;GOTO THE BUFFER DESCRIPTOR ROUTINE
3457
3458 024502 012761 000040 000010 CHODAT: MOV #OP.CMP,P.OPCD(R1) ;PUT COMPARE HOST DATA OPCODE IN PACKET
3459 024510 012737 000034 010564 MOV #34,PCKSIZ ;PUT THE PACKET SIZE INTO THE PACKET
3460 024516 000137 025616 JMP BUFDSC ;GOTO THE BUFFER DESCRIPTOR ROUTINE
3461
3462 024522 012761 000020 000010 ACCESS: MOV #OP.ACC,P.OPCD(R1) ;PUT THE ACCESS OPCODE INTO THE PACKET
3463 024530 012737 000020 010564 MOV #20,PCKSIZ ;PUT THE PACKET SIZE INTO THE PACKET
3464 024536 000137 025650 JMP SUPRES ;GOTO THE SUPPRESS ROUTINE
3465
3466 024542 012761 000045 000010 SPCREC: MOV #OP.REP,P.OPCD(R1) ;PUT REPOSITION OPCODE INTO THE PACKET
3467 024550 005061 000020 CLR P.TMGC(R1) ;CLEAR THE TAPE MARK COUNT
3468 024554 005061 000022 CLR P.TMGC+2(R1) ;CLEAR THE UPPER WORD
3469 024560 032737 000002 003530 BIT #EOTBIT,R8 ;IS THE DETECT LEOT BIT SET ?
3470 024566 001403 BEQ 70$ ;NO,CONTINUE
3471 024570 052761 000200 000012 BIS #MD.DLE,P.MOD(R1) ;YES, SET DETECT LEOT IN THE MODIFIER
3472 024576 012737 000024 010564 70$: MOV #24,PCKSIZ ;PUT THE PACKET SIZE INTO THE PACKET
3473 024604 000137 025650 JMP SUPRES ;GOTO THE SUPPRESS ROUTINE
3474
3475 024610 012761 000045 000010 SKPTMK: MOV #OP.REP,P.OPCD(R1) ;PUT THE REPOSITION OPCODE IN PACKET
3476 024616 016161 000014 000020 MOV P.BCNT(R1),P.TMGC(R1) ;PUT THE TAPE MARK COUNT IN PACKET
3477 024624 005061 000022 CLR P.TMGC+2(R1) ;CLEAR THE TAPE MARK FIELD
3478 024630 005061 000014 CLR P.BCNT(R1) ;CLEAR THE UPPER WORD
3479 024634 032737 000002 003530 BIT #EOTBIT,R8 ;IS THE DETECT LEOT BIT SET ?
3480 024642 001403 BEQ 100$ ;NO,CONTINUE
3481 024644 052761 000200 000012 BIS #MD.DLE,P.MOD(R1) ;YES, SET DETECT LEOT IN THE MODIFIER
3482 024652 012737 000024 010564 100$: MOV #24,PCKSIZ ;PUT THE PACKET SIZE INTO THE PACKET
3483 024660 000137 025650 JMP SUPRES ;GOTO THE SUPPRESS ROUTINE
3484
3485 024664 012761 000045 000010 SPCOBJ: MOV #OP.REP,P.OPCD(R1) ;PUT THE REPOSITION OPCODE IN PACKET
3486 024672 052761 000004 000012 BIS #MD.OBC,P.MOD(R1) ;SET THE OBJECT BIT IN THE MODIFIER
3487 024700 005061 000020 CLR P.TMGC(R1) ;CLEAR THE TAPE MARK FIELD
3488 024704 005061 000022 CLR P.TMGC+2(R1) ;CLEAR THE UPPER WORD
3489 024710 012737 000024 010564 MOV #24,PCKSIZ ;PUT THE PACKET SIZE INTO THE PACKET

```

```

3490 024716 000137 025650          JMP      SUPRES          ;GOTO THE SUPPRESS ROUTINE
3491
3492 024722 012761 000044 000010 WTAPMK: MOV      #OP.WTM,P.OPCD(R1)    ;PUT WRITE TAPE MARK OPCODE IN PACKET
3493 024730 052761 020000 000012      BIS      #MD.CSE,P.MOD(R1)    ;YES, SET CLEAR SERIOUS EXCEPTION
3494 024736 012737 000014 010564      MOV      #14,PCKSIZ          ;PUT THE PACKET SIZE INTO THE PACKET
3495 024744 000137 025700          JMP      COMEXI          ;GOTO THE EXIT
3496
3497 024750 012761 000022 000010 ERASE: MOV      #OP.ERS,P.OPCD(R1)    ;PUT THE ERASE OPCODE INTO THE PACKET
3498 024756 022737 000003 003530      CMP      #IMMBIT,R8        ;IS THE IMMEDIATE BIT SET ?
3499 024764 001403          BEQ      20$              ;NO,CONTINUE
3500 024766 052761 000100 000012      BIS      #MD.IMM,P.MOD(R1)    ;YES, SET IMMEDIATE IN THE MODIFIER
3501 024774 012737 000014 010564 20$:  MOV      #14,PCKSIZ          ;PUT THE PACKET SIZE INTO THE PACKET
3502 025002 000137 025700          JMP      COMEXI          ;GOTO THE EXIT
3503
3504 025006 012761 000026 000010 ERASGP: MOV      #OP.ERG,P.OPCD(R1)    ;PUT ERASE GAP OPCODE INTO THE PACKET
3505 025014 012737 000014 010564      MOV      #14,PCKSIZ          ;PUT THE PACKET SIZE INTO THE PACKET
3506 025022 000137 025700          JMP      COMEXI          ;GOTO THE EXIT
3507
3508 025026 012761 000010 000010 AVALAB: MOV      #OP.AVL,P.OPCD(R1)    ;PUT AVAILABLE OPCODE INTO THE PACKET
3509 025034 022737 000004 003530      CMP      #UNLBIT,R8        ;IS THE UNLOAD BIT SET ?
3510 025042 001403          BEQ      10$              ;NO,CONTINUE
3511 025044 052761 000020 000012      BIS      #MD.UNL,P.MOD(R1)    ;YES, SET UNLOAD IN THE MODIFIER FIELD
3512 025052 012737 000014 010564 10$:  MOV      #14,PCKSIZ          ;PUT THE PACKET SIZE INTO THE PACKET
3513 025060 000137 025700          JMP      COMEXI          ;GOTO THE EXIT
3514
3515 025064 012761 000011 000010 ONLINE: MOV      #OP.ONL,P.OPCD(R1)    ;PUT THE ONLINE OPCODE INTO THE PACKET
3516 025072 005061 000014          CLR      P.UNFL-2(R1)      ;CLEAR THE UNIT FLAG FIELD
3517 025076 005061 000016          CLR      P.UNFL(R1)
3518 025102 005061 000020          CLR      P.UNFL+2(R1)
3519 025106 005061 000022          CLR      P.UNFL+4(R1)
3520 025112 005061 000024          CLR      P.UNFL+6(R1)
3521 025116 005061 000026          CLR      P.UNFL+10(R1)
3522 025122 005061 000030          CLR      P.UNFL+12(R1)
3523 025126 005061 000032          CLR      P.UNFL+14(R1)
3524 025132 005061 000034          CLR      P.DVPM(R1)
3525 025136 012761 000010 000040      MOV      #TF.BLK,P.FORM(R1)  ;CLEAR THE DEVICE PARAMETER FIELD
3526 025144 005061 000042          CLR      P.SPED(R1)        ;PUT THE TAPE FORMAT INTO THE PACKET
3527 025150 012737 000044 010564      MOV      #44,PCKSIZ        ;CLEAR THE SPEED FIELD
3528 025156 000137 025700          JMP      COMEXI          ;PUT THE PACKET SIZE INTO THE PACKET
3529
3530 025162 012761 000012 000010 SUNCHR: MOV      #OP.SUC,P.OPCD(R1)    ;GOTO THE EXIT
3531 025170 005061 000014          CLR      P.UNFL-2(R1)      ;SET UNIT CHARA. OPCODE INTO THE PACKET
3532 025174 005061 000016          CLR      P.UNFL(R1)        ;CLEAR THE UNIT FLAG FIELD
3533 025200 005061 000020          CLR      P.UNFL+2(R1)
3534 025204 005061 000022          CLR      P.UNFL+4(R1)
3535 025210 005061 000024          CLR      P.UNFL+6(R1)
3536 025214 005061 000026          CLR      P.UNFL+10(R1)
3537 025220 005061 000030          CLR      P.UNFL+12(R1)
3538 025224 005061 000032          CLR      P.UNFL+14(R1)
3539 025230 005061 000034          CLR      P.DVPM(R1)
3540 025234 012761 000010 000040      MOV      #TF.BLK,P.FORM(R1)  ;CLEAR THE DEVICE PARAMETERS FIELD
3541 025242 005061 000042          CLR      P.SPED(R1)        ;PUT THE TAPE FORMAT INTO THE PACKET
3542 025246 012737 000044 010564      MOV      #44,PCKSIZ        ;CLEAR THE SPEED FIELD
3543
3544 025254 012761 000045 000010 REWIND: MOV      #OP.REP,P.OPCD(R1)    ;PUT THE REPOSITION OPCODE INTO PACKET
3545 025262 052761 020002 000012      BIS      #MD.CSE!MD.RWD,P.MOD(R1) ;SET THE REWIND MODIFIER
3546 025270 022737 000003 003530      CMP      #IMMBIT,R8        ;IS THE IMMEDIATE BIT SET

```



```

3547 025276 001003          BNE      60$          ;NO,CONTINUE
3548 025300 052761 000100 000012          BIS      #MD.IMM,P.MOD(R1) ;YES, SET THE IMMEDIATE MODIFIER
3549 025306 005061 000020          60$:   CLR      P.TMGC(R1)      ;CLEAR THE TAPE MARK
3550 025312 005061 000022          CLR      P.TMGC+2(R1)    ;COUNT FIELD
3551 025316 012737 000024 010564          MOV      #24,PCKSIZ     ;PUT THE PACKET SIZE INTO THE PACKET
3552 025324 005064 000006          CLR      CMDSEQ(R4)     ;RESET THE COMMAND SEQUENCE NUMBER
3553 025330 042764 000010 000026          BIC      #EOTPR,LUNFLG(R4) ;CLEAT THE EOT PRINT FLAG
3554 025336 000137 025700          JMP      COMEXI         ;GOTO THE EXIT
3555
3556 025342 000137 025722          INIT:   JMP      EXIT          ;EXIT
3557
3558 025346 012761 000001 000010          ABOR:   MOV      #OP.ABO,P.OPCD(R1) ;PUT THE ABORT OPCODE INTO THE PACKET
3559 025354 016561 000000 000014          MOV      P.CRF(R5),P.OTRF(R1) ;PUT THE OLD CRN INTO THE PACKET
3560 025362 005061 000016          CLR      P.OTRF+2(R1)   ;CLEAR THE UPPER WORD
3561 025366 012737 000020 010564          MOV      #20,PCKSIZ     ;PUT THE PACKET SIZE INTO THE PACKET
3562 025374 000137 025700          JMP      COMEXI         ;GOTO THE EXIT
3563
3564 025400 012761 000002 000010          GCMDST: MOV      #OP.GCS,P.OPCD(R1) ;PUT GCS OPCODE INTO THE PACKET
3565 025406 016561 000000 000014          MOV      P.CRF(R5),P.OTRF(R1) ;PUT THE OLD CRN INTO THE PACKET
3566 025414 005061 000016          CLR      P.OTRF+2(R1)   ;CLEAR THE UPPER WORD
3567 025420 012737 000020 010564          MOV      #20,PCKSIZ     ;PUT THE PACKET SIZE INTO THE PACKET
3568 025426 042737 000020 003516          BIC      #GCSCFL,PCFLAG ;CLEAR GCS COMMAND MODE ?
3569 025434 000137 025700          JMP      COMEXI         ;GOTO THE EXIT
3570
3571 025440 012761 000003 000010          GUNSTA: MOV      #OP.GUS,P.OPCD(R1) ;PUT THE GUS OPCODE INTO THE PACKET
3572 025446 042761 020000 000012          BIC      #MD.CSE,P.MOD(R1) ;CLEAR CLEAR SERIOUS EXCEPTION MODIFIER
3573 025454 012737 000014 010564          MOV      #14,PCKSIZ     ;PUT THE PACKET SIZE INTO THE PACKET
3574 025462 000137 025700          JMP      COMEXI         ;GOTO THE EXIT
3575
3576 025466 012761 000004 000010          SCNTCH: MOV      #OP.SCC,P.OPCD(R1) ;PUT THE SCC OPCODE INTO THE PACKET
3577 025474 005061 000004          CLR      P.UNIT(R1)     ;CLEAR THE UNIT NUMBER
3578 025500 012761 000000 000014          MOV      #MSCPVR,P.VRSN(R1) ;PUT THE MSCP VERSION INTO THE PACKET
3579 025506 013761 010562 000016          MOV      CNTFLG,P.CNTF(R1) ;PUT CONTROLLER FLAGS INTO THE PACKET
3580 025514 012761 000000 000020          MOV      #HSTIMO,P.HTMO(R1) ;PUT THE HOST TIMEOUT INTO THE PACKET
3581 025522 005061 000022          CLR      P.HTMO+2(R1)   ;CLEAR THE TIME FIELD
3582 025526 005061 000024          CLR      P.TIME(R1)     ;
3583 025532 005061 000026          CLR      P.TIME+2(R1)   ;
3584 025536 005061 000030          CLR      P.TIME+4(R1)   ;
3585 025542 005061 000032          CLR      P.TIME+6(R1)   ;
3586 025546 005061 000034          CLR      P.CTPM(R1)     ;CLEAR THE FIRDT WORD
3587 025552 005061 000036          CLR      P.CTPM+2(R1)   ;CLEAR THE SECOND WORD
3588 025556 105737 002222          TSTB    PADDING         ;ARE WE ALLOWING WRITE PADDING ?
3589 025562 001003          BNE      5$           ;YES, DON'T SET THE BIT
3590 025564 052761 000001 000034          BIS      #BIT0,P.CTPM(R1) ;SET CNTRL PARAM TO DISABLE PADDING
3591 025572 012737 000040 010564          5$:   MOV      #40,PCKSIZ     ;PUT THE PACKET SIZE INTO THE PACKET
3592 025600 000137 025700          JMP      COMEXI         ;GOTO THE EXIT
3593
3594 025604 052737 000007 010546          ILCMD:  BIS      #ILLCMD,IOSTAT ;SET ILLCMD IN THE I/O STATUS
3595 025612 000137 025722          JMP      EXIT          ;GOTO THE ERROR EXIT
3596
3597 025616 016361 000012 000020          BUFDC:  MOV      BUFOFF(R3),P.BUFF(R1) ;PUT THE BUFFER ADDRESS INTO THE PACKET
3598 025624 005061 000022          CLR      P.BUFF+2(R1)   ;CLEAR THE REST OF THE BUFFER FIELD
3599 025630 005061 000024          CLR      P.BUFF+4(R1)   ;
3600 025634 005061 000026          CLR      P.BUFF+6(R1)   ;
3601 025640 005061 000030          CLR      P.BUFF+10(R1)  ;
3602 025644 005061 000032          CLR      P.BUFF+12(R1)  ;
3603

```

3604	025650	105737	002220		SUPRES:	TSTB	SERREC		
3605	025654	001003				BNE	105\$;IS SUPPRESS ERROR CORRECTION ENABLED ?
3606	025656	052761	001000	000012		BIS	#MD.SEC,P.MOD(R1)		;NO
3607	025664	105737	002221		105\$:	TSTB	SERCOR		;YES, SET SEC MODIFIER
3608	025670	001003				BNE	COMEXI		;IS SUPPRESS ERROR RECOVERY ENABLED ?
3609	025672	052761	000400	000012		BIS	#MD.SER,P.MOD(R1)		;NO
3610									;YES, SET THE SER MODIFIER
3611	025700	062701	000050		COMEXI:	ADD	#DCBSTP,R1		;SET THE POINTER TO THE NEXT SLOT
3612	025704	022701	004032			CMP	#DCBEND,R1		;ARE WE AT THE END OF THE RING ?
3613	025710	001002				BNE	110\$;NO, EXIT
3614	025712	012701	003572			MOV	#DCMDBF,R1		;YES, SET THE POINTER TO START OF RING
3615	025716	010164	000014		110\$:	MOV	R1,CNUSAV(R4)		;SAVE THE POINTER
3616									
3617	025722				EXIT:	POP	<R2,R1>		;RESTORE R1
3618	025726	000207				RTS	PC		;RETURN

```

3620 .SBTTL PORT DRIVER TRANSMIT
3621 ;*****
3622 ;
3623 ;Port Driver Transmit
3624 ;
3625 ;Called By      : CLSDVR
3626 ;Inputs        : CMDSSV - Command descriptor ring pointer.
3627 ;              : DCDSAV - Driver command ring pointer.
3628 ;              : CRDLIM - Number of open slots in the driver command ring.
3629 ;              : PCKSIZ - Length in bytes of the command packet.
3630 ;Register Inputs: R4 - Lun block pointer.
3631 ;Registers Used : R2 - Pointer to driver command ring.
3632 ;              : R1 - Pointer to driver command descriptor ring.
3633 ;
3634 ;
3635 025730 PRTDRV::
3636 025730      PUSH      <R3,R2,R1>          ;SAVE R3, R2 AND R1
3637 025736 016402 000014      MOV      CNUSAV(R4),R2          ;POINT R2 AT NEW COMMAND BUFFER SLOT
3638 025742 016401 000012      MOV      CMDSSV(R4),R1        ;LET R1 POINT TO THE COMMAND DESCRIPTOR
3639 025746 022702 003572      CMP      #DCMDBF,R2         ;IS R2 AT TOP OF DRIVER COMMAND Ring
3640 025752 001403              BEQ      1$                  ;YES, BRANCH
3641 025754 162702 000050      SUB      #DCBSTP,R2         ;NO, SUBTRACT DCBSTP FROM R2
3642 025760 000402              BR       5$                  ;
3643 ;
3644 025762 062702 000170      1$:      ADD      #DCB3SP,R2          ;YES, ADD DCB3SP TO R2
3645 025766 113762 010571 177776 5$:      MOVB     CRDLIM,CRD(R2)        ;PUT THE CREDIT LIMIT INTO THE PACKET
3646 025774 112762 000001 177777      MOVB     #1,CONID(R2)        ;PUT THE CONNECTION TYPE INTO THE PACKET
3647 026002 013762 010564 177774      MOV      PCKSIZ,MSGLEN(R2)   ;PUT THE PACKET SIZE INTO THE PACKET
3648 026010 010211              MOV      R2,(R1)             ;PUT THE PACKET ADDRESS INTO THE DESCRIPTOR
3649 026012 052761 100000 000002      BIS      #OWN,HIADDR(R1)     ;SET THE OWNERSHIP BIT OF THE DESCRIPTOR
3650 026020 042761 040000 000002      BIC      #FLAG,HIADDR(R1)   ;CLEAR TO DESCRIPTOR FLAG BIT
3651 026026 005774 000000              TST      @TKIP(R4)           ;READ THE IP REGISTER
3652 026032 017437 000002 010566      MOV      @TKSA(R4),SAERR     ;SAVE THE SA FOR THE ERROR PRINTOUT
3653 026040 005737 010566              TST      SAERR               ;READ THE SA REGISTER
3654 026044 100003              BPL      10$                 ;BRANCH IF NO ERRORS
3655 026046 052737 000003 010546      BIS      #IOPDRE,IOSTAT     ;SET PORT DETECTED ERROR IN I/O STATUS
3656 ;
3657 026054 062701 000004      10$:     ADD      #DSPSTP,R1        ;ADVANCE THE DESCRIPTOR POINTER
3658 026060 026401 000170      CMP      UCDEND(R4),R1      ;ARE WE AT END OF THE DESCRIPTOR RING
3659 026064 001002              BNE      15$                 ;NO, BRANCH
3660 026066 016401 000166      MOV      UCDSRG(R4),R1      ;YES, SET POINTER TO START OF THE RING
3661 ;
3662 026072 010164 000012      15$:     MOV      R1,CMDSSV(R4)       ;SAVE THE POINTER
3663 026076              POP      <R1,R2,R3>         ;RESTORE R1, R2 AND R3
3664 026104 000207              RTS      PC                  ;RETURN

```

```

3666 .SBTTL PORT DRIVER RECEIVE
3667 ;*****
3668 ;
3669 ;Port Driver Receive
3670 ;
3671 ;Called By : CDRECV
3672 ;Inputs : URDSRG - RESPONSE descriptor ring.
3673 ; UCDSRG - Command descriptor ring.
3674 ;Outputs : RESP - Number of new RESPONSEs.
3675 ;Registers Used : R1 - RESPONSE descriptor ring pointer.
3676 ;
3677 ;
3678 026106 PDRECV::
3679 026106 PUSH <R1> ;SAVE R1
3680 026110 016401 000162 MOV URDSRG(R4),R1 ;SET R1 TO THE RESPONSE DESCRIPTOR
3681 026114 017437 000002 010566 MOV @TKSA(R4),SAERR ;SAVE THE SA FOR THE ERROR PRINTOUT
3682 026122 005737 010566 TST SAERR ;READ THE SA REGISTER
3683 026126 100003 BPL 1$ ;BRANCH IF NO ERRORS
3684 026130 052737 000003 010546 BIS #IOPDRE,IOSTAT ;SET PORT DETECTED ERROR IN I/O STATUS
3685 ;
3686 026136 006364 000010 1$: ASL SLTUSE(R4) ;SHIFT BITMAP
3687 026142 032737 000040 003516 BIT #GCSRFL,PCFLAG ;ARE WE IN GCS MODE ?
3688 026150 001403 BEQ 2$ ;NO, DO ALL RESPONSES
3689 026152 005737 003414 TST RESP ;HAVE WE GOTTEN A RESPONSE ?
3690 026156 001012 BNE 5$ ;YES, GCS MODE ALLOW ONLY 1 RESPONSE
3691 ;
3692 026160 032761 100000 000002 2$: BIT #OWN,HIADDR(R1) ;IS THE SLOT SET TO US ?
3693 026166 001006 BNE 5$ ;NO , BRANCH
3694 026170 005237 003414 INC RESP ;ADD 1 TO THE RESPONSE COUNT
3695 026174 052764 000001 000010 BIS .BIT0,SLTUSE(R4) ;SET SLOT-IN-USE
3696 026202 000403 BR 10$
3697 ;
3698 026204 042764 000001 000010 5$: BIC #BIT0,SLTUSE(R4) ;ELSE CLEAR THIS SLOT-IN-USE
3699 026212 062701 000004 10$: ADD #DSPSTP,R1 ;SET THE POINTER TO THE NEXT SLOT
3700 026216 026401 000164 CMP URDEND(R4),R1 ;ARE WE AT THE END OF THE RING ?
3701 026222 001345 BNE 1$ ;NO, KEEP GOING TILL WE GET THEM ALL
3702 026224 POP <R1> ;RESTORE R1
3703 026226 000207 RTS PC ;RETURN
    
```

```

3705 .SBTTL PORT DRIVER CLEAR
3706 ;*****
3707 ;
3708 ;Port Driver Clear
3709 ;
3710 ;Called By : CDRECV
3711 ;Register Inputs: R4 - Lun block pointer.
3712 ;Registers Used : R1 - Current location in the RESPONSE descriptor ring.
3713 ;
3714 ;
3715 026230 PRTCLR::
3716 J26230 PUSH <R1,R2> ;SAVE R1 AND R2
3717 026234 016401 000164 MOV URDEND(R4),R1 ;R1 = END OF RESPONSE DESCRIPTOR RING
3718 026240 016402 000162 MOV URDSRG(R4),R2 ;R2 = RESPONSE DESCRIPTOR RING
3719 026244 162702 000004 SUB #4,R2 ;BACK UP POINTER BY A LONGWORD
3720 ;
3721 026250 162701 000004 1$: SUB #4,R1 ;BACK UP POINTER BY A LONGWORD
3722 026254 020201 CMP R2,R1 ;BACKED UP PAST START OF RING?
3723 026256 001410 BEQ 20$ ;YES - SO GET OUT
3724 026260 000241 CLC ;CLEAR THE CARRY
3725 026262 006064 000010 ROR SLTUSE(R4) ;MOVE BIT0 TO CARY BIT
3726 026266 103003 BCC 5$ ;BRANCH IF SLOT NOT USED
3727 026270 012761 100000 000002 MOV #OWN,HIADDR(R1) ;GIVE SLOT BACK TO PORT
3728 ;
3729 026276 000764 5$: BR 1$ ;LOOK FOR MORE
3730 026300 20$: POP <R2,R1> ;RESTORE R2 AND R1
3731 026304 000207 RTS PC ;RETURN
3732

```

```

3734 .SBTTL PORT DRIVER INITIALIZATION
3735 ;*****
3736 ;
3737 ;Port Driver Initialization
3738 ;
3739 ;Called By      : CLSDRV
3740 ;Register Inputs: R4 - Lun block pointer.
3741 ;Registers Used : R1 - Current init step in process
3742 ;                R2 - Used by the watchdog timer
3743 ;                R3 - Initialization data table pointer
3744 ;
3745 ;
3746 026306          PRTINT::
3747 026306          PUSH    <R1,R2,R3,R5>          ;SAVE R1, R2, R3 AND R5
3748 026316 010174 000000          MOV     R1,@TKIP(R4)          ;INITIALIZE THE DRIVE
3749 026322 016437 000162 026522  MOV     URDSRG(R4),INTTBL+2  ;PUT RESP DESCRIPTOR ADDRESS IN TABLE
3750 026330 012703 026520          MOV     #INTTBL,R3          ;PUT THE TABLE ADDRESS INTO R3
3751 026334 012701 004000          MOV     #S1,R1             ;SET UP TO BEGIN AT STEP 1
3752
3753 026340 012737 000050 010554 LOOP: MOV     #40.,CNTHI          ;SET UP THE TIME OUT COUNTER
3754 026346 005002          CLR     R2                 ;CLEAR R2
3755
3756 026350          ILOOP:
3757 026350          BREAK
3758 026350 104422          TRAP   C$BRK
3759 026352 005202          INC     R2                 ;INCREMENT HI TIME OUT VALUE ?
3760 026354 001003          BNE    2$                 ;IF NOT, BRANCH
3761 026356 005337 010554          DEC     CNTHI              ;ELSE, INCREMENT HI TIMEOUT
3762 026362 001444          BEQ    TKERR               ;GET OUT, WE'VE TIMED OUT
3763
3764 026364 037401 000002          2$:   BIT     @TKSA(R4),R1    ;TEST FOR STEP BIT FROM DRIVE
3765 026370 001767          BEQ    ILOOP              ;LOOP UNTIL SOMETHING SETS
3766 026372 017437 000002 010566  MOV     @TKSA(R4),SAERR    ;SAVE THE SA FOR THE ERROR PRINTOUT
3767 026400 005737 010566          TST    SAERR               ;CHECK FOR ERROR
3768 026404 100433          BMI    TKERR               ;GET OUT ON ERROR
3769 026406 012374 000002          3$:   MOV     (R3)+,@TKSA(R4)  ;WRITE WORD FROM TABLE TO CONTROLLER
3770 026412 006301          ASL    R1                   ;SHIFT TO NEXT STEP
3771 026414 100351          BPL    LOOP                ;IF NOT AT LAST STEP LOOP
3772
3773 026416 016402 000162          MOV     URDSRG(R4),R2      ;PUT THE RESPONSE DESCRIPTOR ADD IN R2
3774 026422 016403 000156          MOV     URSPBF(R4),R3     ;PUT THE RESPONSE BUFFER ADDRESS IN R3
3775 026426 010322          5$:   MOV     R3,(R2)+          ;PUT THE BUFF ADD IN THE DESCRIPTOR
3776 026430 005022          CLR     (R2)+              ;CLEAR THE NEXT WORD
3777 026432 062703 000104          ADD     #DRBSTP,R3        ;STEP TO THE NEXT BUFFER SLOT
3778 026436 026403 000160          CMP     URBEND(R4),R3     ;ARE WE AT THE END OF THE BUFFER ?
3779 026442 001371          BNE    5$                  ;NO, KEEP GOING
3780
3781 026444 016402 000166          MOV     UCDSRG(R4),R2     ;PUT THE CMD DESCRIPTOR ADDRESS IN R2
3782 026450 012703 003572          MOV     #DCMDF,R3        ;PUT THE CMD BUFFER ADDRESS IN R3
3783 026454 010322          10$:  MOV     R3,(R2)+          ;PUT THE BUFF ADD IN THE DESCRIPTOR
3784 026456 005022          CLR     (R2)+              ;CLEAR THE NEXT WORD
3785 026460 062703 000050          ADD     #DCBSTP,R3        ;STEP TO THE NEXT BUFFER SLOT
3786 026464 022703 004032          CMP     #DCBEND,R3       ;ARE WE AT THE END OF THE BUFFER ?
3787 026470 001371          BNE    10$                 ;NO, KEEP GOING
3788 026472 000403          BR     IDONE               ;ALL DONE
3789

```

```

3790 026474 012737 000006 010546 TKERR: MOV #INTERR,I0STAT ;SET UP FOR A FATAL ERROR
3791
3792 026502 005337 003402 IDONE: DEC RSPCNT
3793 026506 POP <R5,R3,R2,R1> ;RESTORE THE REGISTERS
026506 012605 MOV (SP)+,R5 ;;POP STACK INTO R5
026510 012603 MOV (SP)+,R3 ;;POP STACK INTO R3
026512 012602 MOV (SP)+,R2 ;;POP STACK INTO R2
026514 012601 MOV (SP)+,R1 ;;POP STACK INTO R1
3794 026516 000207 RTS PC ;RETURN
3795
3796 ;INIT DATA TABLE
3797
3798 026520 111400 INTTBL: .WORD TKINIT
3799 026522 000000 .WORD 0
3800 026524 000000 .WORD 0
3801 026526 000001 .WORD GO

```

```

3803 .SBTTL GCS RESPONSE HANDLER
3804 ;*****
3805 ;
3806 ;GCS RESPONSE HANDLER
3807 ;
3808 ;Called By :
3809 ;Calls To :
3810 ;Register Inputs :
3811 ;
3812 ;Register Inputs :
3813 ;
3814 ;
3815 026530 GCSHDL::
3816 026530 023761 010550 000020 CMP CMSTSV,P.CMST(R1) ;ANY PROGRESS ?
3817 026536 101017 BHI 5$ ;YES, CLKEAN UP THE MESS
3818 026540 042737 000040 003516 BIC #GCSRFL,PCFLAG ;CLEAR THE GCS MODE FLAG
3819 026546 005037 003414 CLR RESP ;TAKE OFF THE RESPONSE
3820 026552 005037 003412 CLR HNDLRP ;TAKE OFF THE RESPONSE
3821 026556 112737 000002 010546 MOVB #IOHUNG,IOSTAT ;SET HUNG CONTROLLER BIT
3822 026564 004737 033734 JSR PC,CORDMP
3823 026570 000240 NOP
3824 026572 000137 027314 JMP GCSEXT ;GET OUT
3825
3826 026576 5$: PUSH <R1,R2> ;
    026576 010146 MOV R1,-(SP) ;;PUSH R1 ON STACK
    026600 010246 MOV R2,-(SP) ;;PUSH R2 ON STACK
3827 026602 016401 000016 MOV COLSAV(R4),R1 ;PUT THE OLD POINTER IN R1
3828 026606 162701 000004 SUB #4,R1 ;ADJUST TO INCLUDE DESCRIPTOR WORDS
3829 026612 016402 000014 MOV CNUSAV(R4),R2 ;PUT THE NEW POINTER IN R2
3830 026616 162702 000004 SUB #4,R2 ;ADJUST TO INCLUDE DESCRIPTOR WORDS
3831 026622 022701 003566 CMP #CMDBF1,R1 ;OLD POINTER AT BF1 ?
3832 026626 001407 BEQ OLD1 ;YES, GO HANDLE IT
3833 026630 022701 003636 CMP #CMDBF2,R1 ;OLD POINTER AT BF2 ?
3834 026634 001434 BEQ OLD2 ;YES, GO HANDLE IT
3835 026636 022701 003706 CMP #CMDBF3,R1 ;OLD POINTER AT BF3 ?
3836 026642 001461 BEQ OLD3 ;YES, GO HANDLE IT
3837 026644 000510 BR OLD4 ;NO, GO HANDLE BF4
3838
3839 026646 022702 003706 OLD1: CMP #CMDBF3,R2 ;NEW POINTER AT BF3 ?
3840 026652 001004 BNE 5$ ;NO, TRY AGAIN
3841 026654 004737 027316 JSR PC,EXC1A2 ;GO MOVE COMMAND 1 TO 2
3842 026660 000137 027142 JMP ADJUST ;GO ADJUST THE OLD POINTER
3843 026664 022702 003756 5$: CMP #CMDBF4,R2 ;NEW POINTER AT BF4 ?
3844 026670 001006 BNE 10$ ;NO, TRY AGAIN
3845 026672 004737 027340 JSR PC,EXC2A3 ;GO MOVE COMMAND 2 TO 3
3846 026676 004737 027316 JSR PC,EXC1A2 ;GO MOVE COMMAND 1 TO 2
3847 026702 000137 027142 JMP ADJUST ;GO ADJUST THE OLD POINTER
3848 026706 004737 027362 10$: JSR PC,EXC3A4 ;GO MOVE COMMAND 3 TO 4
3849 026712 004737 027340 JSR PC,EXC2A3 ;GO MOVE COMMAND 2 TO 3
3850 026716 004737 027316 JSR PC,EXC1A2 ;GO MOVE COMMAND 1 TO 2
3851 026722 000137 027142 JMP ADJUST ;GO ADJUST THE OLD POINTER
3852
3853 026726 022702 003756 OLD2: CMP #CMDBF4,R2 ;NEW POINTER AT BF4 ?
3854 026732 001004 BNE 5$ ;NO, TRY AGAIN
3855 026734 004737 027340 JSR PC,EXC2A3 ;GO MOVE COMMAND 2 TO 3
3856 026740 000137 027142 JMP ADJUST ;GO ADJUST THE OLD POINTER
3857 026744 022702 003566 5$: CMP #CMDBF1,R2 ;NEW POINTER AT BF1 ?
    
```



```

3858 026750 001006          BNE      10$          ;NO, TRY AGAIN
3859 026752 004737 027362   JSR     PC,EXC3A4     ;GO MOVE COMMAND 3 TO 4
3860 026756 004737 027340   JSR     PC,EXC2A3     ;GO MOVE COMMAND 2 TO 3
3861 026762 000137 027142   JMP     ADJUST        ;GO ADJUST THE OLD POINTER
3862 026766 004737 027404   10$:   JSR     PC,EXC4A1     ;GO MOVE COMMAND 4 TO 1
3863 026772 004737 027362   JSR     PC,EXC3A4     ;GO MOVE COMMAND 3 TO 4
3864 026776 004737 027340   JSR     PC,EXC2A3     ;GO MOVE COMMAND 2 TO 3
3865 027002 000137 027142   JMP     ADJUST        ;GO ADJUST THE OLD POINTER
3866
3867 027006 022702 003566   OLD3:  CMP     #CMDBF1,R2 ;NEW POINTER AT BF1 ?
3868 027012 001004          BNE     5$            ;NO, TRY AGAIN
3869 027014 004737 027362   JSR     PC,EXC3A4     ;GO MOVE COMMAND 3 TO 4
3870 027020 000137 027142   JMP     ADJUST        ;GO ADJUST THE OLD POINTER
3871 027024 022702 003636   5$:    CMP     #CMDBF2,R2 ;NEW POINTER AT BF2 ?
3872 027030 001006          BNE     10$          ;NO, TRY AGAIN
3873 027032 004737 027404   JSR     PC,EXC4A1     ;GO MOVE COMMAND 4 TO 1
3874 027036 004737 027362   JSR     PC,EXC3A4     ;GO MOVE COMMAND 3 TO 4
3875 027042 000137 027142   JMP     ADJUST        ;GO ADJUST THE OLD POINTER
3876 027046 004737 027316   10$:   JSR     PC,EXC1A2     ;GO MOVE COMMAND 1 TO 2
3877 027052 004737 027404   JSR     PC,EXC4A1     ;GO MOVE COMMAND 4 TO 1
3878 027056 004737 027362   JSR     PC,EXC3A4     ;GO MOVE COMMAND 3 TO 4
3879 027062 000137 027142   JMP     ADJUST        ;GO ADJUST THE OLD POINTER
3880
3881 027066 022702 003636   OLD4:  CMP     #CMDBF2,R2 ;NEW POINTER AT BF2 ?
3882 027072 001004          BNE     5$            ;NO, TRY AGAIN
3883 027074 004737 027404   JSR     PC,EXC4A1     ;GO MOVE COMMAND 4 TO 1
3884 027100 000137 027142   JMP     ADJUST        ;GO ADJUST THE OLD POINTER
3885 027104 022702 003706   5$:    CMP     #CMDBF3,R2 ;NEW POINTER AT BF3 ?
3886 027110 001006          BNE     10$          ;NO, TRY AGAIN
3887 027112 004737 027316   JSR     PC,EXC1A2     ;GO MOVE COMMAND 1 TO 2
3888 027116 004737 027404   JSR     PC,EXC4A1     ;GO MOVE COMMAND 4 TO 1
3889 027122 000137 027142   JMP     ADJUST        ;GO ADJUST THE OLD POINTER
3890 027126 004737 027340   10$:   JSR     PC,EXC2A3     ;GO MOVE COMMAND 2 TO 3
3891 027132 004737 027316   JSR     PC,EXC1A2     ;GO MOVE COMMAND 1 TO 2
3892 027136 004737 027404   JSR     PC,EXC4A1     ;GO MOVE COMMAND 4 TO 1
3893
3894 027142          ADJUST: POP     <R2,R1> ;
      027142 012602      MOV     (SP)+,R2      ;;POP STACK INTO R2
      027144 012601      MOV     (SP)+,R1      ;;POP STACK INTO R1
3895 027146 042737 000040 003516   BIC     #GCSRFL,PCFLAG ;CLEAR THE GCS MODE FLAG
3896 027154 016137 000020 010550   MOV     P,CMST(R1),CMSTSV ;PUT THE CMD STATUS INTO THE SAVE LOC
3897 027162 005037 003414          CLR     RESP          ;TAKE OFF THE RESPONSE
3898 027166 005037 003412          CLR     HNDLRP        ;TAKE OFF THE RESPONSE
3899 027172 005364 000006          DEC     CMDSEQ(R4)     ;ADJUST THE CMDSEQ NUMBER BACK 1
3900 027176 042737 100000 010546   BIC     #NURESP,IOSTAT ;CLEAR THE NEW RESPONSE FLAG IN IOSTAT
3901 027204 105237 010571          INCB    CRDLIM        ;ADD 1 TO THE CREDIT LIMIT
3902
3903 027210 062764 000050 000016          ADD     #DCBSTP,COLSAV(R4) ;ADJUST THE OLD COMMAND POINTER
3904 027216 022764 004032 000016          CMP     #DCBEND,COLSAV(R4) ;IS IT AT THE END OF THE RING ?
3905 027224 001003          BNE     5$            ;NO, BRANCH
3906 027226 012764 003572 000016          MOV     #DCMDBF,COLSAV(R4) ;YES, SET IT TO THE TOP OF THE RING
3907
3908 027234 062705 000050          5$:    ADD     #DCBSTP,R5     ;ADJUST THE OLD COMMAND POINTER
3909 027240 022705 004032          CMP     #DCBEND,R5     ;IS IT AT THE END OF THE RING ?
3910 027244 001002          BNE     10$          ;NO, BRANCH
3911 027246 012705 003572          MOV     #DCMDBF,R5     ;YES, SET IT TO THE TOP OF THE RING
3912

```

```

3913 027252 062764 000104 000022 10$: ADD #DRBSTP,ROLSAV(R4) ;ADJUST THE OLD RESPONSE POINTER
3914 027260 026464 000160 000022 CMP URBEND(R4),ROLSAV(R4) ;IS IT AT THE END OF THE BUFFER ?
3915 027266 001003 BNE 15$ ;NO, KEEP GOING
3916 027270 016464 000156 000022 MOV URSPBF(R4),ROLSAV(R4) ;YES, SET IT TO BEGINNING OF THE BUFFER
3917
3918 027276 062701 000104 15$: ADD #DRBSTP,R1 ;ADJUST R1
3919 027302 026401 000160 CMP URBEND(R4),R1 ;IS IT AT THE END OF THE BUFFER ?
3920 027306 001002 BNE GCSEXT ;NO, GET OUT
3921 027310 016401 000156 MOV URSPBF(R4),R1 ;YES, SET IT TO BEGINNING OF THE BUFFER
3922
3923 027314 GCSEXT:
3924 027314 000207 RTS PC ;RETURN
3925
3926
3927 027316 012701 003566 EXC1A2: MOV #CMDBF1,R1 ;SET R1 TO BF1
3928 027322 012702 003636 MOV #CMDBF2,R2 ;SET R2 TO BF2
3929 027326 012122 5$: MOV (R1)+,(R2)+ ;MOV BF1 CONTENTS TO BF2
3930 027330 022701 003636 CMP #CMDBF2,R1 ;HAVE WE MOVED THEM ALL
3931 027334 001374 BNE 5$ ;NO, KEEP MOVING IT
3932 027336 000207 RTS PC ;YES, GET OUT
3933
3934 027340 012701 003636 EXC2A3: MOV #CMDBF2,R1 ;SET R1 TO BF2
3935 027344 012702 003706 MOV #CMDBF3,R2 ;SET R2 TO BF3
3936 027350 012122 5$: MOV (R1)+,(R2)+ ;MOV BF2 CONTENTS TO BF3
3937 027352 022701 003706 CMP #CMDBF3,R1 ;HAVE WE MOVED THEM ALL
3938 027356 001374 BNE 5$ ;NO, KEEP MOVING IT
3939 027360 000207 RTS PC ;YES, GET OUT
3940
3941 027362 012701 003706 EXC3A4: MOV #CMDBF3,R1 ;SET R1 TO BF3
3942 027366 012702 003756 MOV #CMDBF4,R2 ;SET R2 TO BF4
3943 027372 012122 5$: MOV (R1)+,(R2)+ ;MOV BF3 CONTENTS TO BF4
3944 027374 022701 003756 CMP #CMDBF4,R1 ;HAVE WE MOVED THEM ALL
3945 027400 001374 BNE 5$ ;NO, KEEP MOVING IT
3946 027402 000207 RTS PC ;YES, GET OUT
3947
3948 027404 012701 003756 EXC4A1: MOV #CMDBF4,R1 ;SET R1 TO BF4
3949 027410 012702 003566 MOV #CMDBF1,R2 ;SET R2 TO BF1
3950 027414 012122 5$: MOV (R1)+,(R2)+ ;MOV BF4 CONTENTS TO BF1
3951 027416 022702 003636 CMP #CMDBF2,R2 ;HAVE WE MOVED THEM ALL
3952 027422 001374 BNE 5$ ;NO, KEEP MOVING IT
3953 027424 000207 RTS PC ;YES, GET OUT

```

```

3955 .SBTTL RESPONSE HANDLER
3956 ;*****
3957 ;
3958 ;RESPONSE HANDLER
3959 ;
3960 ;Called By : CMDSEQ
3961 ;Calls To : ERRDEI, ERRDEL, ERRDEC, CMPDAT, DQCMD
3962 ;Register Inputs : R1 - UNIT NUMBER
3963 ; : R4 - LUN BLOCK POINTER
3964 ;Register Inputs : R3 - POINTER TO CURRENT RESPONSE PACKET
3965 ;
3966
3967 027426 RSPHDL::
3968 027426 PUSH <R3>
027426 010346 MOV R3,-(SP) ;:PUSH R3 ON STACK
3969 027430 005037 003406 CLR RESPON ;0 HERE TELLS CMDSEQ ALL'S OKAY
3970 027434 105737 010546 TSTB IOSTAT ;DID WE HAVE I/O TYPE FAILURE?
3971 027440 001403 BEQ 5$ ;BRANCH AROUND IF NOT
3972 027442 004737 030774 JSR PC,ERRDEI ;ELSE DECODE AND PRINT IT
3973 027446 000501 BR 60$ ;GET OUT NOW
3974
3975 027450 016403 000022 5$: MOV ROLSAV(R4),R3 ;GET OLD RESPONSE BUFFER POINTER
3976 027454 005737 003412 TST HNDLRP ;DID WE HAVE ANY RESPONSES ?
3977 027460 001474 BEQ 60$ ;NO, GET OUT OF HERE
3978 027462 032763 000200 000010 10$: BIT #OP.END,P.OPCD(R3) ;IS IT AN END PACKET?
3979 027470 001003 BNE 15$ ;YES, BRANCH
3980 027472 004737 031236 JSR PC,ERRDEL ;GO HANDLE ERROR LOG PACKET
3981 027476 000453 BR 50$ ;SEE IF THERE'S MORE RESPONSES
3982
3983 027500 005763 000012 15$: TST P.STS(R3) ;WAS STATUS "NORMAL"?
3984 027504 001413 BEQ 25$ ;YES - BRANCH
3985 027506 022763 000022 000012 CMP #ST.SEX,P.STS(R3) ;IS IT SERIOUS EXCEPTION STATUS?
3986 027514 001004 BNE 20$ ;NO - GO HANDLE THE ERROR
3987 027516 052764 000004 000026 BIS #NOTALY,LUNFLG(R4) ;SET THE NO-TALLY FLAG
3988 027524 000436 BR 45$ ;YES, GO DE-QUE THE COMMANDS
3989 027526 004737 030304 20$: JSR PC,ERRDEC ;GO HANDLE ERROR STATUS
3990 027532 000403 BR 30$
3991 027534 000241 25$: CLC ;CLEAR THE CARRY BIT
3992 027536 006164 000030 ROL LEOTFL(R4) ;ROTATE THE CARRY INTO THE LEOT FLAG
3993
3994 027542 032761 000001 003350 30$: BIT #AVB,DRINUS(R1) ;HAVE WE DROPPED THE UNIT?
3995 027550 001440 BEQ 60$ ;YES - GET OUT
3996 027552 022763 000241 000010 CMP #OP.END!OP.RD,P.OPCD(R3) ;DID WE READ THIS TIME?
3997 027560 001020 BNE 45$ ;NO - SKIP DATA COMPARE
3998 027562 022737 000005 002114 CMP #5,L$TEST ;ARE WE IN TEST 5?
3999 027570 001003 BNE 35$ ;YES - SKIP DATA COMPARE
4000 027572 105737 002235 TSTB TSCMP ;DO DATA COMPARES IN TEST 5 ?
4001 027576 001403 BEQ 40$ ;NO, SKIP DATA COMPARE
4002 027600 004737 032552 35$: JSR PC,CMPDAT ;DO COMPARE DATA
4003 027604 000406 BR 45$
4004 027606 132737 000001 002236 40$: BITB #BIT0,DMPBUF ;SHOULD WE DUMP RDBUF?
4005 027614 001402 BEQ 45$ ;NO - BRANCH
4006 027616 004737 034066 JSR PC,BUFDMP
4007
4008 027622 004737 027662 45$: JSR PC,DQCMD ;DEQUEUE THE COMMAND
4009 027626 062703 000104 50$: ADD #DRBSTP,R3 ;ADJUST POINTER TO NEXT PACKET
4010 027632 026403 000160 CMP URBEND(R4),R3 ;END OF RESPONSE BUFFER?

```

```

4011 027636 001002          BNE    55$          ;NO - BRANCH AROUND
4012 027640 016403 000156  MOV    URSPBF(R4),R3  ;PUT POINTER AT BEGINNING OF BUFFER
4013
4014 027644 005337 003412  55$:  DEC    HNDLRP      ;DECREMENT RESPONSE COUNTER
4015 027650 001304          BNE    10$          ;GO HANDLE ANOTHER ONE
4016
4017 027652 010364 000022  60$:  MOV    R3,ROLSAV(R4) ;SAVE OLD RESPONSE BUFFER POINTER
4018 027656          POP    <R3>
         027656 012603  MOV    (SP)+,R3      ;;POP STACK INTO R3
4019 027660 000207          RTS    PC

```

```

4021 .SBTTL DE-QUEUE COMMAND
4022 ;*****
4023 ;
4024 ; DE-QUEUE COMMAND
4025 ;
4026 ;Called By      : RSPHDL
4027 ;Calls To       : LGSTAT
4028 ;Register Inputs : R2 - OLD POINTER TO PROGRAM COMMAND RING
4029 ;Register Outputs: R2 - UPDATED
4030 ;
4031
4032 027662 DQCMD::
4033 027662 004737 027720 JSR PC, LGSTAT ;CALL LOG STATS
4034 027666 062702 000014 ADD #PCBSTP, R2 ;ADJUST THE OLD COMMAND POINTER
4035 027672 022702 003344 CMP #PCBEND, R2 ;ARE WE AT THE END OF THE BUFFER ?
4036 027676 001002 BNE 5$ ;NO, KEEP GOING
4037 027700 012702 003264 MOV #PCMDBF, R2 ;YES, SET IT BACK TO THE TOP
4038
4039 027704 005337 003402 5$: DEC RSPCNT ;DECREMENT THE RESPONSE COUNTER
4040 027710 012737 177777 010550 MOV #-1, CMSTSV ;RESET THE GCS PROGRESS COUNT
4041 027716 000207 RTS PC ;RETURN
4042

```

```

4044      .SBTTL LOG STATISTICS
4045      ;*****
4046      ;
4047      ; LOG STATISTICS
4048      ;
4049      ;Called By      : DQCMD
4050      ;Register Inputs : R2 - OLD PROGRAM COMMAND POINTER
4051      ;                : R4 - LUN BLOCK POINTER
4052      ;
4053      ;
4054      LGSTAT::
4055      027720 032764 000004 000026      BIT      #NOTALY,LUNFLG(R4)      ;IS THIS NOT TO BE TALLIED ?
4056      027726 001162                    BNE      10$                    ;YES, GET OUT
4057      027730 122762 000040 000000      CMPB     #ACC,CMD(R2)          ;SEE IF COMMAND A READ OR WRITE
4058      027736 103556                    BLO      10$                    ;NO, EXIT SUBROUTINE
4059      027740 105762 000000      TSTB     CMD(R2)                ;IS IT A NULL ?
4060      027744 001553                    BEQ      10$                    ;YES, EXIT SUBROUTINE
4061      027746 122762 000020 000000      CMPB     #WR,CMD(R2)           ;IS IT A WRITE ?
4062      027754 001056                    BNE      5$                      ;NO, HANDLE READ
4063      027756 066264 000002 000120      ADD      ITMOFF(R2),WRBYT1(R4) ;YES, ADD THE BYTES WRITTEN TO TOTAL
4064      027764 026427 000120 001747 1$:  CMP      WRBYT1(R4),#999.        ;IS IT HIGER THAN 999. ?
4065      027772 003406                    BLE      2$                      ;BRANCH IF IT'S NOT
4066      027774 162764 001750 000120      SUB      #1000.,WRBYT1(R4)     ;SUBTRACT 1000. FROM THE LOWER ORDER WORD
4067      030002 005264 000122      INC      WRBYT2(R4)            ;INCREMENT THE SECOND WORD
4068      030006 000766                    BR       1$                      ;
4069      030010 026427 000122 001747 2$:  CMP      WRBYT2(R4),#999.        ;IS IT HIGER THAN 999. ?
4070      030016 003406                    BLE      3$                      ;BRANCH IF IT'S NOT
4071      030020 162764 001750 000122      SUB      #1000.,WRBYT2(R4)     ;SUBTRACT 1000. FROM THE LOWER ORDER WORD
4072      030026 005264 000124      INC      WRBYT3(R4)            ;INCREMENT THE SECOND WORD
4073      030032 000766                    BR       2$                      ;
4074      030034 026427 000124 001747 3$:  CMP      WRBYT3(R4),#999.        ;IS IT HIGER THAN 999. ?
4075      030042 003406                    BLE      4$                      ;BRANCH IF IT'S NOT
4076      030044 162764 001750 000124      SUB      #1000.,WRBYT3(R4)     ;SUBTRACT 1000. FROM THE LOWER ORDER WORD
4077      030052 005264 000126      INC      WRBYT4(R4)            ;INCREMENT THE SECOND WORD
4078      030056 000766                    BR       3$                      ;
4079      030060 026427 000126 001747 4$:  CMP      WRBYT4(R4),#999.        ;IS IT HIGER THAN 999. ?
4080      030066 003502                    BLE      10$                     ;BRANCH IF IT'S NOT
4081      030070 005064 000120      CLR      WRBYT1(R4)            ;
4082      030074 005064 000122      CLR      WRBYT2(R4)            ;
4083      030100 005064 000124      CLR      WRBYT3(R4)            ;
4084      030104 005064 000126      CLR      WRBYT4(R4)            ;
4085      030110 000471                    BR       10$                     ;EXIT
4086      ;
4087      030112 022763 000016 000012 5$:  CMP      #ST.TM,P.STS(R3)       ;WAS THIS A TAPE MARK DURING READ
4088      030120 001465                    BEQ      10$                    ;YES, GET OUT
4089      030122 022763 000010 000012      CMP      #10,P.STS(R3)         ;WAS THIS A DATA ERROR DURING READ
4090      030130 001461                    BEQ      10$                    ;YES, GET OUT
4091      030132 022763 000350 000012      CMP      #350,P.STS(R3)       ;WAS THIS A DATA ERROR DURING READ
4092      030140 001455                    BEQ      10$                    ;YES, GET OUT
4093      030142 066364 000040 000110      ADD      P.TRBC(R3),RDBYT1(R4) ;YES, ADD THE BYTES WRITTEN TO TOTAL
4094      030150 026427 000110 001747 6$:  CMP      RDBYT1(R4),#999.        ;IS IT HIGER THAN 999. ?
4095      030156 003406                    BLE      7$                      ;BRANCH IF IT'S NOT
4096      030160 162764 001750 000110      SUB      #1000.,RDBYT1(R4)     ;SUBTRACT 1000. FROM THE LOWER ORDER WORD
4097      030166 005264 000112      INC      RDBYT2(R4)            ;INCREMENT THE SECOND WORD
4098      030172 000766                    BR       6$                      ;
4099      030174 026427 000112 001747 7$:  CMP      RDBYT2(R4),#999.        ;IS IT HIGER THAN 999. ?
4100      030202 003406                    BLE      8$                      ;BRANCH IF IT'S NOT

```

4101	030204	162764	001750	000112		SUB	#1000.,RDBYT2(R4)		;SUBTRACT 1000. FROM THE LOWER ORDER WORD
4102	030212	005264	000114			INC	RDBYT3(R4)		;INCREMENT THE SECOND WORD
4103	030216	000766				BR	7\$		
4104	030220	026427	000114	001747	8\$:	CMP	RDBYT3(R4),#999.		;IS IT HIGER THAN 999. ?
4105	030226	003406				BLE	9\$;BRANCH IF IT'S NOT
4106	030230	162764	001750	000114		SUB	#1000.,RDBYT3(R4)		;SUBTRACT 1000. FROM THE LOWER ORDER WORD
4107	030236	005264	000116			INC	RDBYT4(R4)		;INCREMENT THE SECOND WORD
4108	030242	000766				BR	8\$		
4109	030244	026427	000116	001747	9\$:	CMP	RDBYT4(R4),#999.		;IS IT HIGER THAN 999. ?
4110	030252	003410				BLE	10\$;BRANCH IF IT'S NOT
4111	030254	005064	000110			CLR	RDBYT1(R4)		;
4112	030260	005064	000112			CLR	RDBYT2(R4)		;
4113	030264	005064	000114			CLR	RDBYT3(R4)		;
4114	030270	005064	000116			CLR	RDBYT4(R4)		;
4115	030274	042764	000004	000026	10\$:	BIC	#NOTALY,LUNFLG(R4)		;CLEAR THE NO-TALLY FLAG BEFORE EXITING
4116	030302	000207				RTS	PC		;RETURN

```

4118 .SBTTL ERROR DECODE
4119 ;*****
4120 ;
4121 ; ERROR DECODE
4122 ;
4123 ;Called By      : RSPHDL
4124 ;Calls To      : ERRTLY, PRIERR
4125 ;Register Inputs : R2 - OLD PROGRAM COMMAND BUFFER POINTER
4126 ;
4127 ;
4128 030304 ERRDEC::
4129 030304          PUSH    <R5>                ;SAVE R5
4130 030304 010546  MOV     R5,-(SP)          ;;PUSH R5 ON STACK
4131 030306 016205 000010  MOV     XFERST(R2),R5      ;PUT THE COMMAND STATUS IN R5
4132 030312 022705 000400  CMP     #ST.ONL,R5        ;IS IT A UNIT ONLINE ERROR ?
4133 030316 001005          BNE     997$              ;BRANCH IF IT ISN'T
4134 030320 012737 000100 003442  MOV     #ONLB,WRKMSK      ;SET THE ERROR BIT IN THE MASK
4135 030326 000137 030762          JMP     MSKTST           ;GO TEST IF IT'S O.K.
4136 030332 042705 177740          BIC     #177740,R5       ;CLEAR THE UNWANTED BITS
4137 030336 022762 002000 000010  CMP     #2000,XFERST(R2) ;IS EOT SET IN TRANSFER STATUS ?
4138 030344 001037          BNE     1$              ;BRANCH IF IT ISN'T
4139 030346 052761 000004 003350  BIS     #EOT,DRINUS(R1)  ;SET THE DRIVE TO EOT
4140 030354 005237 003526          INC     UEOT            ;INC THE EOT FLAG
4141 030360 163737 003400 003402  SUB     CMDCNT,RSPCNT    ;SET RESPONSE COUNT TO NUMBER OUT
4142 030366 005037 003400          CLR     CMDCNT         ;ISSUE NO MORE COMMANDS
4143 030372 032764 000010 000026  BIT     #EOTPR,LUNFLG(R4) ;HAS EOT BEEN PRINTED FOR THIS DRIVE ?
4144 030400 001017          BNE     999$           ;DON'T PRINT IT AGAIN
4145 030402          PUSH    <R1>                ;SAVE R1
4146 030404 010146  MOV     R1,-(SP)          ;;PUSH R1 ON STACK
4147 030406 006001          ROR     R1              ;DIVIDE R1 BY 2
4148 030406          PRINTF  #UNTEOT,R1     ;PRINT UNIT AT EOT MESSAGE
4149 030410 010146  MOV     R1,-(SP)
4150 030414 012746 020256  MOV     #UNTEOT,-(SP)
4151 030420 012746 000002  MOV     #2,-(SP)
4152 030422 010600  MOV     SP,R0
4153 030424 104417  TRAP   C$PNTF
4154 030424 062706 000006  ADD     #6,SP
4155 030430          POP     <R1>            ;RESTORE R1
4156 030432 052764 000010 000026  BIS     #EOTPR,LUNFLG(R4) ;EOT BEEN PRINTED FOR THIS DRIVE
4157 030440 000137 031232          JMP     EDCEXT         ;GET OUT
4158 030444 012737 010652 003530 1$:  MOV     #CMDT,R8        ;PUT THE ERROR TABLE ADDRESS IN R8
4159 030452 022705 000013          CMP     #13,R5        ;IS IT A DRIVE ERROR ?
4160 030456 001005          BNE     4$            ;NO, CONTINUE
4161 030460 052737 000010 003516  BIS     #DRERFL,PCFLAG  ;SET THE DRIVE ERROR FLAG
4162 030466 004737 033370          JSR     PC,OCTHEX     ;GO DECODE THE STATUS
4163 030472 022705 000023          CMP     #23,R5        ;IS IT A VALID STATUS ?
4164 030476 103003          BHS     5$            ;IT'S VALID, BRANCH
4165 030500 012705 000024          MOV     #24,R5        ;MAKE SURE ITS NOT MORE THAN 24
4166 030504 000543          BR     ERREXT         ;TAKE THE ERROR EXIT
4167 030506 012737 000002 003406 5$:  MOV     #SEREXC,RESPON  ;SET SERIOUS EXCEPTION
4168 030514 016337 000000 003542  MOV     P.CRF(R3),SECRNS ;SAVE THE CURRENT COMMAND REF #
4169 030522 022705 000006          CMP     #ST.WPR,R5    ;IS IT A WRITE PROTECT ERROR ?
4170 030526 001004          BNE     10$           ;BRANCH IF IT ISN'T
4171 030530 012737 000020 003442  MOV     #WPRB,WRKMSK   ;SET THE ERROR BIT IN THE MASK
4172 030536 000511          BR     MSKTST         ;GO TEST IF IT'S O.K.

```



```

4167
4168 030540 022705 000016      10$:  CMP      #ST.TM,R5      ;IS IT A TAPE MARK ERROR ?
4169 030544 001061              BNE      15$      ;BRANCH IF IT ISN'T
4170 030546 052764 000002 000026  BIS      #SEREXC,LUNFLG(R4) ;SET SERIOUS EXCEPTION
4171 030554 000261              SEC              ;
4172 030556 006164 000030      ROL      LEOTFL(R4)      ;
4173 030562 042764 177774 000030  BIC      #177774,LEOTFL(R4) ;
4174 030570 022764 000003 000030  CMP      #3,LEOTFL(R4)      ;
4175 030576 001032              BNE      13$      ;
4176 030600 052761 000004 003350  BIS      #EOT,DRINUS(R1)    ;
4177 030606 005237 003526      INC      UEOT      ;INC THE EOT FLAG
4178 030612              PUSH     <R1>      ;SAVE R1
4179 030614 006001              ROR      R1        ;DIVIDE R1 BY 2
4180 030616      PRINTF #UNTLOT,R1      ;PRINT UNIT AT EOT MESSAGE
      030616 010146      MOV      R1,-(SP)
      030620 012746 020312      MOV      #UNTLOT,-(SP)
      030624 012746 000002      MOV      #2,-(SP)
      030630 010600      MOV      SP,RO
      030632 104417      TRAP    C$PNTF
      030634 062706 000006      ADD      #6,SP
4181 030640      POP      <R1>      ;RESTORE R1
4182 030642 163737 003400 003402  SUB      CMDCNT,RSPCNT    ;SET RESPONSE COUNT TO NUMBER OUT
4183 030650 005037 003400      CLR      CMDCNT      ;ISSUE NO MORE COMMANDS
4184 030654 005037 003406      CLR      RESPON     ;MAKE SURE WE
4185 030660 000137 031232      JMP      EDCEXT      ;GET OUT
4186
4187 030664 132763 000010 000011 13$:  BITB    #EF.EOT,P.FLGS(R3) ;IS THE TAPE MARK AT EOT ?
4188 030672 001402              BEQ      14$      ;NO, KEEP ON GOING
4189 030674 000137 031232      JMP      EDCEXT    ;YES, GET OUT
4190 030700 012737 000010 003442 14$:  MOV      #TMB,WRKMSK    ;SET THE ERROR BIT IN THE MASK
4191 030706 000425              BR       MSKTST    ;GO TEST IF IT'S O.K.
4192
4193 030710 022705 000020      15$:  CMP      #ST.RDT,R5      ;IS IT A RECORD DATA TRUNCATED ERROR ?
4194 030714 001007              BNE      20$      ;BRANCH IF IT ISN'T
4195 030716 000241              CLC              ;CLEAR THE CARRY BIT
4196 030720 006164 000030      ROL      LEOTFL(R4)    ;ROTATE THE CARRY INTO THE LEOT FLAG
4197 030724 012737 000002 003442  MOV      #RDTB,WRKMSK    ;SET THE ERROR BIT IN THE MASK
4198 030732 000413              BR       MSKTST    ;GO TEST IF IT'S O.K.
4199
4200 030734 022705 000023      20$:  CMP      #ST.LED,R5      ;IS IT A LOGICAL END OF TAPE ERROR ?
4201 030740 001002              BNE      25$      ;BRANCH IF IT ISN'T
4202 030742 000137 031232      JMP      EDCEXT    ;GET OUT IF LEOT DETECTED
4203
4204 030746 022705 000004      25$:  CMP      #ST.AVL,R5      ;IS IT A UNIT AVAILABLE ERROR ?
4205 030752 001020              BNE      ERREXT     ;BRANCH IF IT ISN'T
4206 030754 012737 000040 003442  MOV      #AVLB,WRKMSK    ;SET THE ERROR BIT IN THE MASK
4207
4208 030762 033737 003442 003440  MSKTST: BIT      WRKMSK,TSTMSK ;IS IT AN ACCEPTABLE ERROR ?
4209 030770 001120              BNE      EDCEXT     ;GET OUT IF IT IS
4210 030772 000410              BR       ERREXT     ;OTHERWISE PRINT THE ERROR
4211
4212 030774      ERRDEI::
4213 030774      PUSH     <R5>      ;SAVE R5
4214 030776 113705 010546      MOVB    IOSTAT,R5      ;PUT THE I/O ERROR CODE INTO R5
4215 031002 012737 010572 003530  MOV      #IOERTB,R8     ;SET THE ERROR TABLE ADDRESS IN R8
4216 031010 042705 177770      BIC     #177770,R5     ;CLEAR OFF ALL UNWANTED BITS
4217

```

```

4218 031014 005305          ERREXT: DEC      R5          ;SUBTRACT 1 FROM R5
4219 031016 006305          ASL      R5          ;MULTIPLY R5 BY 10(8)
4220 031020 006305          ASL      R5          ;
4221 031022 006305          ASL      R5          ;
4222 031024 063705 003530  ADD      R8,R5      ;ADD THE TABLE ADDRESS TO R5
4223 031030          PUSH     <R3>
4224 031032 012703 013262  MOV      #L$ERRTBL,R3 ;SET R3 TO THE GENERIC ERROR TABLE
4225 031036 012523          MOV      (R5)+,(R3)+ ;MOVE ERROR TABLE CONTENTS
4226 031040 012523          MOV      (R5)+,(R3)+ ;MOVE ERROR TABLE CONTENTS
4227 031042 012523          MOV      (R5)+,(R3)+ ;MOVE ERROR TABLE CONTENTS
4228 031044 011513          MOV      (R5),(R3)   ;MOVE ERROR TABLE CONTENTS
4229 031046          POP      <R3>
4230
4231 031050 022762 000010 000010  CMP      #EV.LGP,XFERST(R2) ;IS IS A LONG GAP ENCOUNTERED ?
4232 031056 001031          BNE     ERTLY        ;NO, KEEP GOING
4233 031060 112737 000001 013262  MOVB    #DEVFAT,ERRTYP ;YES, DROP THE UNIT
4234 031066 004737 033734          JSR    PC,CORDMP     ;;;;GO DO IT
4235 031072 000240          NOP
4236 031074 122762 000020 000000  CMPB    #WR,CMD(R2)   ;IS IT A WRITE ?
4237 031102 001004          BNE     1$          ;NO TRY AGAIN
4238 031104 112737 000060 013263  MOVB    #H1WRIT,ERRTYP+1 ;AND TALLY THE HARD WRITE ERROR
4239 031112 000413          BR     ERTLY        ;GO TALLY THE ERROR
4240 031114 122762 000100 000000 1$:  CMPB    #WTM,CMD(R2) ;IS IT A WRITE TAPE MARK ?
4241 031122 001004          BNE     5$          ;NO, MUST BE A READ
4242 031124 112737 000060 013263  MOVB    #H1WRIT,ERRTYP+1 ;AND TALLY THE HARD WRITE ERROR
4243 031132 000403          BR     ERTLY        ;TALLY THE ERROR
4244 031134 112737 000054 013263 5$:  MOVB    #H1READ,ERRTYP+1 ;TALLY THE HARD READ ERROR
4245 031142 004737 032036  ERTLY: JSR    PC,ERTLY    ;TALLY THE ERROR
4246 031146 105037 013263          CLRB   ERRTYP+1    ;CLEAR UPPER BYTE
4247 031152 105737 002224          TSTB   SOERRP      ;ARE SOFT ERRORS ENABLED ?
4248 031156 001004          BNE     6$          ;YES, GO PRINT THE ERROR
4249 031160 122737 000003 013262  CMPB    #SOFT,L$ERRTBL ;IS IT A SOFT ERROR ?
4250 031166 001402          BEQ    8$          ;YES, DON'T PRINT IT
4251 031170 004737 032536          JSR    PC,PRIERR    ;GO PRINT THE ERROR
4252
4253 031174 132737 000001 002231 8$:  BITB    #BITO,DMPFLG ;SHOULD WE DUMP PROGRAM TABLES?
4254 031202 001403          BEQ    10$         ;NO - BRANCH
4255 031204 004737 033734          JSR    PC,CORDMP     ;GO DO IT
4256 031210 000240          NOP
4257 031212 022737 000001 013262 10$: CMP      #DEVFAT,ERRTYP ;IS IT A FATAL ERROR ?
4258 031220 001004          BNE     EDCEXT      ;NO EXIT
4259 031222 010100          MOV     R1,R0       ;MOVE UNIT # * 2 TO R0
4260 031224 006000          ROR    R0           ;DIVIDE BY 2
4261 031226 004737 040442          JSR    PC,DROPUN    ;DROP DRIVE FROM TESTING
4262 031232          EDCEXT: POP      <R5> ;RESTORE REGISTERS
4263 031234 000207          RTS     PC          ;RETURN
4264

```

```

4266 .SBTTL ERROR LOG DECODE
4267 ;*****
4268 ;
4269 ; ERROR LOG DECODE
4270 ;
4271 ;Called By      :
4272 ;Calls To       :
4273 ;Inputs         :
4274 ;Outputs        :
4275 ;Register Inputs:
4276 ;Register Outputs:
4277
4278 031236 ERRDEL::
4279 031236      PUSH    <R3,R5>
4280 031242 116237 000000 003536      MOVB   CMD(R2),R11      ;GET THE COMMAND PRIMITIVE FOR LATER USE
4281 031250 042737 177407 003536      BIC    #177407,R11     ;GET JUST THE ROOT PRIMITIVE
4282 031256      PUSH    <R1>      ;SAVE R1
4283 031260 122763 000005 000010      CMPB   #FM.TPE,L.FMT(R3) ;TAPE TRANSFER ERROR LOG?
4284 031266 001420      BEQ    5$              ;YES, DECODE IT
4285 031270 122763 000000 000010      CMPB   #FM.CNT,L.FMT(R3) ;CONTROLLER ERROR LOG?
4286 031276 001004      BNE    1$              ;NO, SEE WHAT IT IS
4287 031300 012705 011132      MOV    #CNTLER,R5      ;PRINT PACKET
4288 031304 000137 031724      JMP    PRTEXT          ;GET OUT
4289 031310 122763 000001 000010 1$:  CMPB   #FM.BAD,L.FMT(R3) ;HOST MEMORY ACCESS ERROR LOG?
4290 031316 001004      BNE    5$              ;NO, GET OUT
4291 031320 012705 011142      MOV    #BADERL,R5      ;SET UP TO PRINT HOST MEM ACC ERL
4292 031324 000137 031724      JMP    PRTEXT          ;GO PRINT IT
4293 031330 016337 000012 003556 5$:  MOV    L.EVNT(R3),EVENT ;GET A COPY OF THE EVENT CODE
4294 031336 042737 177740 003556      BIC    #177740,EVENT   ;GET RID OF THE SUBCODES
4295 031344 022737 000007 003556      CMP    #ST.CMP,EVENT   ;IS IT A COMPARE ERROR ?
4296 031352 001004      BNE    10$             ;NO, KEEP GOING
4297 031354 012705 011152      MOV    #CMPERL,R5      ;SET UP TO PRINT ERROR
4298 031360 000137 031724      JMP    PRTEXT          ;GO PRINT THE ERROR
4299 031364 022737 000013 003556 10$:  CMP    #ST.DRV,EVENT   ;IS IT A DRIVE ERROR ?
4300 031372 001004      BNE    15$             ;NO, KEEP GOING
4301 031374 012705 011162      MOV    #DRVERL,R5      ;SET UP TO PRINT ERROR
4302 031400 000137 031724      JMP    PRTEXT          ;GO PRINT THE ERROR
4303 031404 022737 000012 003556 15$:  CMP    #ST.CNT,EVENT   ;IS IT A CONTROLLER ERROR ?
4304 031412 001004      BNE    DATAEL        ;NO, MUST BE A DATA ERROR
4305 031414 012705 011172      MOV    #CNTERL,R5      ;SET UP TO PRINT ERROR
4306 031420 000137 031724      JMP    PRTEXT          ;GO PRINT THE ERROR
4307 031424 022763 000010 000012 DATAEL:  CMP    #EV.LGP,L.EVNT(R3) ;IS IT A LONG GAP ENCOUNTERED ?
4308 031432 001004      BNE    1$              ;NO, KEEP TRYING
4309 031434 012705 011202      MOV    #LGPERL,R5      ;SET UP TO PRINT LGE ERROR
4310 031440 000137 031724      JMP    PRTEXT          ;GO PRINT IT
4311 031444 012701 003360      1$:  MOV    #UNITBL,R1      ;PUT THE TEMP TABLE ADDRESS IN R1
4312 031450 116361 000055 000000      MOVB   L.TRK(R3),TRK(R1) ;PUT THE TRACK NUMBER IN TEMP
4313 031456 016361 000056 000002      MOV    L.PBLK(R3),PHB(R1) ;PHYSICAL BLOCK NUMBER TO TEMP
4314 031464 022737 000020 003536      CMP    #WR,R11         ;WAS IT A WRITE COMMAND ?
4315 031472 001404      BEQ    WRERL          ;GO HANDLE WRITE ERROR
4316 031474 022737 000100 003536      CMP    #WTM,R11        ;IS IT A WRITE TAPE MARK COMMAND ?
4317 031502 001026      BNE    RDERL          ;GO HANDLE READ ERROR LOG
4318 031504 022763 000150 000012 WRERL:  CMP    #EV.COR,L.EVNT(R3) ;IS IT A SOFT ERROR ?
4319 031512 001005      BNE    1$              ;NO, INCREMENT HARD ERROR
4320 031514 105261 000004      INCB   SWR(R1)         ;YES, INCREMENT SOFT WRITE ERROR
4321 031520 012705 011232      MOV    #CORERL,R5      ;SET UP TO PRINT ERROR
4322 031524 000413      BR     10$            ;KEEP GOING
    
```

4323	031526	105261	000006		1\$:	INCB	HWR(R1)		;INCREMENT HARD WRITE ERROR
4324	031532	022763	000050	000012		CMP	#EV.DST,L.EVNT(R3)		;IS IT A DATA SYNC TIMEOUT ?
4325	031540	001003				BNE	5\$;NO, KEEP TRYING
4326	031542	012705	011222			MOV	#WDSTEL,R5		;SET UP TO PRINT DST ERROR
4327	031546	000402				BR	10\$;GO PRINT IT
4328	031550	012705	011242		5\$:	MOV	#UWEERL,R5		;SET UP TO PRINT ERROR
4329	031554	000137	031720		10\$:	JMP	SRTBL		;GO SORT THE ERROR AND PRINT
4330	031560	022763	000350	000012	RDERL:	CMP	#EV.URE,L.EVNT(R3)		;IS IT A HARD READ ERROR ?
4331	031566	001006				BNE	1\$;NO, HANDLE SOFT READ
4332	031570	105261	000007			INCB	HRD(R1)		;INC THE HARD READ ERROR
4333	031574	012705	011262			MOV	#UREERL,R5		;SET UP TO PRINT ERROR
4334	031600	000137	031720			JMP	SRTBL		;GO SORT AND PRINT IT
4335	031604	022763	000050	000012	1\$:	CMP	#EV.DST,L.EVNT(R3)		;IS IT A DATA SYNC TIMEOUT ?
4336	031612	001006				BNE	5\$;NO, KEEP TRYING
4337	031614	105261	000007			INCB	HRD(R1)		;INC THE HARD READ ERROR
4338	031620	012705	011212			MOV	#RDSTEL,R5		;SET UP TO PRINT DST ERROR
4339	031624	000137	031720			JMP	SRTBL		;GO SORT AND PRINT IT
4340	031630	105261	000005		5\$:	INCB	SRD(R1)		;INC THE SOFT READ ERROR
4341	031634	105763	000042			TSTB	L.LVL(R3)		;WAS IT RECOVERED BY ECC ?
4342	031640	001025				BNE	20\$;NO, KEEP TRYING
4343	031642	122763	000036	000052		CMPB	#ECCBC,L.STS(R3)		;WAS THE ERROR ON AN ECC BLOCK ?
4344	031650	001003				BNE	10\$;NO TRY AGAIN
4345	031652	012705	011272			MOV	#ECBERL,R5		;SET UP TO PRINT ERROR
4346	031656	000420				BR	SRTBL		;GO SORT AND PRINT ERROR
4347	031660	122763	000030	000052	10\$:	CMPB	#ECCTC,L.STS(R3)		;WAS ERROR ON A TAPE MARK ?
4348	031666	001003				BNE	15\$;TRY AGAIN
4349	031670	012705	011302			MOV	#ECTERL,R5		;SET UP TO PRINT ERROR
4350	031674	000411				BR	SRTBL		;GO SORT AND PRINT ERROR
4351	031676	122763	000026	000052	15\$:	CMPB	#ECCDC,L.STS(R3)		;WAS ERROR ON DATA BLOCK ?
4352	031704	001003				BNE	20\$;NO, TRY AGAIN
4353	031706	012705	011312			MOV	#ECDERL,R5		;SET UP TO PRINT ERROR
4354	031712	000402				BR	SRTBL		;GO SORT AND PRINT ERROR
4355	031714	012705	011252		20\$:	MOV	#RTYERL,R5		;SET UP RETRY RECOVERED
4356	031720	004737	032162		SRTBL:	JSR	PC,TBLSRT		;GO TALLY ERROR IN MEDIA TABLE
4357	031724	116237	000000	003536	PRTEXT:	MOVB	CMD(R2),R11		;GET THE COMMAND PRIMITIVE FOR LATER USE
4358	031732	012701	013262			MOV	#L\$ERRTBL,R1		;R1 = SUPERVISORS ERROR TABLE
4359	031736	012521				MOV	(R5)+,(R1)+		;COPY PROGRAM'S ERROR TABLE
4360	031740	012521				MOV	(R5)+,(R1)+		; TO SUPERVISOR'S
4361	031742	012521				MOV	(R5)+,(R1)+		; ERROR
4362	031744	011511				MOV	(R5),(R1)		; TABLE
4363	031746					POP	<R1>		;RESTORE R1
4364	031750	004737	032120			JSR	PC,ETLLY		;TALLY ERROR FIRST
4365	031754	105037	013263			CLRB	ERRTYP+1		;DISCARD INFO USED BY ERRTLLY
4366	031760	105737	002224			TSTB	SOERRP		;ARE SOFT ERRORS ENABLED ?
4367	031764	001017				BNE	1\$;YES, GO PRINT THE ERROR
4368	031766	122737	000003	013262		CMPB	#SOFT,L\$ERRTBL		;IS IT A SOFT ERROR ?
4369	031774	001013				BNE	1\$;NO, PRINT IT
4370	031776	022737	000020	003536		CMP	#WR,R11		;IS IT A WRITE ?
4371	032004	001411				BEQ	EDLEXT		;DON'T PRINT IT
4372	032006	022737	000100	003536		CMP	#WTM,R11		;IS IT A WRITE TAPE MARK ?
4373	032014	001405				BEQ	EDLEXT		;DON'T PRINT IT
4374	032016	105737	002225			TSTB	RDSOER		;ARE WE PRINTING SOFT READ ERRORS ?
4375	032022	001402				BEQ	EDLEXT		;NO, DON'T PRINT IT
4376	032024	004737	032536		1\$:	JSR	PC,PRIERR		;GO PRINT IT
4377	032030				EDLEXT:	POP	<R5,R3>		
4378	032034	000207				RTS	PC		

```

4380 .SBTTL ERROR TALLY
4381 ;*****
4382 ;
4383 ; ERROR TALLY
4384 ;
4385 ;Called By : ERRDEC, ERRDEI, ERRDEL
4386 ;
4387
4388 ERRPLY::
4389 032036 PUSH <R1> ;SAVE R1
4390 032040 122737 000106 013263 CMPB #NOERR,ERRTYP+1 ;IS IT A STATUS ERROR ?
4391 032046 001422 BEQ 15$ ;YES, GET OUT
4392 032050 113701 013263 MOVB ERRTYP+1,R1 ;PUT THE ERROR TYPE IN R1
4393 032054 122737 000076 013263 CMPB #RMSPOS,ERRTYP+1 ;IS IT A MISPOSITION ERROR
4394 032062 001012 BNE 10$ ;NO KEEP GOING
4395 032064 122762 000020 000000 CMPB #WR,CMD(P2) ;IS IT A WRITE ?
4396 032072 001404 BEQ 5$ ;NO TRY AGAIN
4397 032074 122762 000100 000000 CMPB #WTM,CMD(R2) ;IS IT A WRITE TAPE MARK ?
4398 032102 001002 BNE 10$ ;NO, MUST BE A READ
4399 032104 112701 000100 5$: MOVB #WMSPO3,R1 ;SET IT TO A WRITE MISPOSITON
4400 032110 060401 10$: ADD R4,R1 ;ADD THE OFFSET TO THE LUN POINTER
4401 032112 005211 INC (R1) ;INC THE ERROR COUNT
4402 032114 15$: POP <R1> ;RESTORE R1 AND R4
4403 032116 000207 RTS PC ;EXIT
4404

```

```

4406 .SBTTL ERROR LOG TALLY
4407 ;*****
4408 ;
4409 ; ERROR LOG TALLY
4410 ;
4411 ;Called By      :
4412 ;Calls To      :
4413 ;Inputs        :
4414 ;Outputs       :
4415 ;Register Inputs :
4416 ;Register Outputs:
4417

```

```

4418 032120      ETTY::      PUSH      <R1>          ;SAVE R1
4419 032120      CMPB      #NOERR,ERRTYP+1 ;IS IT A STATUS ERROR ?
4420 032122 122737 000106 013263      BEQ      ELTEXT      ;YES, GET OUT
4421 032130 001412          MOVB      ERRTYP+1,R1 ;LET R1 = THE ERROR TYPE
4422 032132 113701 013263          ADD      R4,R1      ;ADD THE LUN BLOCK POINTER TO R1
4423 032136 060401          BITB      #BIT0,L.TRK(R3) ;IS IT AN ODD TRACK NUMBER ?
4424 032140 132763 000001 000055      BEQ      1$          ;YES, GO TALLY THE ERROR
4425 032146 001402          ADD      #2,R1      ;NO, TALLY THE EVEN TRACK
4426 032150 062701 000002          INC      (R1)      ;INC THE ERROR COUNT
4427 032154 005211          ELTEXT: POP      <R1> ;RESTORE R1
4428 032156          RTS      PC          ;RETURN
4429 032160 000207

```

```

4431      .SBTTL  TABLE SORTER
4432      ;*****
4433      ;
4434      ; TABLE SORTER
4435      ;
4436      ;Called By      : ERRDEL
4437      ;Register Inputs :
4438      ;Register Outputs:
4439
4440 032162      TBLSORT::PUSH      <R1,R2,R3,R5>      ;SAVE R1,R2,R3,R5 ON STACK
4441 032172      012701      003360      MOV      #UNTTBL,R1      ;INITIALIZE R1,R2,R3,R5
4442 032176      016402      000130      MOV      TBLTOP(R4),R2      ;FOR LOCAL USAGE
4443 032202      016403      000134      MOV      LSTENT(R4),R3
4444 032206      010205      MOV      R2,R5
4445 032210      020203      CMP      R2,R3      ;FIRST ENTRY?
4446 032212      001524      BEQ      30$      ;YES, PUT IT IN THE TABLE
4447
4448 032214      126162      000000      000000      1$:      CMPB     TRK(R1),TRK(R2)      ;GET TO THE RIGHT TRACK
4449 032222      101405      BLOS    5$
4450 032224      062702      000010      ADD     #8.,R2
4451 032230      020203      CMP     R2,R3      ;NEXT UNUSED SLOT ?
4452 032232      001514      BEQ     30$      ;YES, PUT IT IN THE TABLE
4453 032234      000767      BR      1$
4454
4455 032236      126162      000000      000000      5$:      CMPB     TRK(R1),TRK(R2)      ;MAKE SURE ITS THE SAME TRACK
4456 032244      001024      BNE     15$
4457 032246      026162      000002      000002      CMP     PHB(R1),PHB(R2)      ;IF OUR OBJ CNT HIGHER
4458 032254      101405      BLOS    10$
4459 032256      062702      000010      ADD     #8.,R2      ;GO TO NEXT TABLE LOCATION
4460 032262      020203      CMP     R2,R3      ;NEXT UNUSED SLOT ?
4461 032264      001477      BEQ     30$      ;YES, PUT IT IN THE TABLE
4462 032266      000763      BR      5$
4463
4464 032270      026162      000002      000002      10$:     CMP     PHB(R1),PHB(R2)      ;IF THE ENTRY ALREADY EXIST
4465 032276      001007      BNE     15$
4466 032300      066162      000004      000004      ADD     SWR(R1),SWR(R2)      ;THEN ADD THE ERROR COUNT
4467 032306      066162      000006      000006      ADD     HWR(R1),HWR(R2)
4468 032314      000477      BR      EXTSRT
4469
4470 032316      026464      000134      000132      15$:     CMP     LSTENT(R4),TBLBTM(R4) ;IF THE TABLES FULL, GET OUT
4471 032324      001022      BNE     20$
4472 032326      032764      000040      000026      17$:     BIT     #MTBLOV,LUNFLG(R4)
4473 032334      001067      BNE     EXTSRT
4474 032336      052764      000040      000026      BIS     #MTBLOV,LUNFLG(R4)
4475 032344      PRINTF   #TBLFUL,L$LUN
      032344      013746      002074      MOV     L$LUN,-(SP)
      032350      012746      036716      MOV     #TBLFUL,-(SP)
      032354      012746      000002      MOV     #2,-(SP)
      032360      010600      MOV     SP,R0
      032362      104417      TRAP   C$PNTF
4476 032364      062706      000006      ADD     #6,SP
4477 032370      000451      BR      EXTSRT
4478 032372      016405      000134      20$:     MOV     LSTENT(R4),R5      ;MOVE THE TABLE CONTENTS
4479 032376      010503      MOV     R5,R3      ;DOWN TO PUT IN THE ENTRY
4480 032400      162703      000010      SUB     #8.,R3
4481

```

```

4482 032404 116365 000000 000000 25$:  MOVB  TRK(R3),TRK(R5)
4483 032412 016365 000002 000002      MOV   PHB(R3),PHB(R5)
4484 032420 116365 000004 000004      MOVB  SWR(R3),SWR(R5)
4485 032426 116365 000005 000005      MOVB  SRD(R3),SRD(R5)
4486 032434 116365 000006 000006      MOVB  HWR(R3),HWR(R5)
4487 032442 116365 000007 000007      MOVB  HRD(R3),HRD(R5)
4488 032450 162703 000010                SUB   #8.,R3
4489 032454 162705 000010                SUB   #8.,R5
4490 032460 020502                CMP   R5,R2                ;KEEP GOING TILL THE RIGHT SLOT
4491 032462 101350                BHI   25$                  ;IS OPEN
4492
4493 032464 026464 000134 000132 30$:  CMP   LSTENT(R4),TBLBTM(R4) ;IF THE TABLES FULL, GET OUT
4494 032472 001715                BEQ   17$
4495 032474 020301                CMP   R3,R1
4496 032476 103403                BLO   35$
4497 032500 010103                MOV   R1,R3
4498 032502 010205                MOV   R2,R5
4499 032504 000737                BR    25$
4500 032506 062764 000010 000134 35$:  ADD   #8.,LSTENT(R4)        ;ADJUST THE LAST ENTRY POINTER
4501 032514 005061 000004                EXTSRT: CLR  SWR(R1)         ;CLEAR SOFT ERROR COUNTERS
4502 032520 005061 000006                CLR  HWR(R1)         ;CLEAR HARD ERROR COUNTERS
4503 032524                POP   <R5,R3,R2,R1>      ;RESTORE REGISTERS
4504 032534 000207                RTS   PC

```


4506
 4507
 4508
 4509
 4510
 4511
 4512
 4513
 4514
 4515
 4516 032536
 4517 032536 010337 003560
 4518 032542 010437 003562
 4519 032546
 032546 104460
 4520 032550 000207
 4521

```

.SBTTL PRINT ERROR
;*****
;
; PRINT ERROR
;
;Called By      : ERRDEC, ERRDEI, ERRDEL
;Calls To      : ERROR
;Register Inputs :
;Register Outputs:

PRIERR::
      MOV      R3,R3SAVE      ;SAVE R3
      MOV      R4,R4SAVE      ;SAVE R4
      ERROR
      TRAP     C$ERROR        ;ERROR MACRO
      RTS      PC             ;RETURN
  
```

```

4523      .SBTTL COMPARE DATA
4524      ;*****
4525      ;
4526      ; COMPARE DATA
4527      ;
4528      ;Called By      :
4529      ;Calls To      :
4530      ;Inputs        :
4531      ;Outputs       :
4532      ;Register Inputs :
4533      ;Register Outputs:
4534      ;
4535
4536 032552 CMPDAT::
4537 032552      PUSH      <R1,R2,R3,R5>          ;SAVE R1,R2,R3,R5
          032552 010146      MOV      R1,-(SP)          ;;PUSH R1 ON STACK
          032554 010246      MOV      R2,-(SP)          ;;PUSH R2 ON STACK
          032556 010346      MOV      R3,-(SP)          ;;PUSH R3 ON STACK
          032560 010546      MOV      R5,-(SP)          ;;PUSH R5 ON STACK
4538 032562 026363 000040 000014      CMP      P.TRBC(R3),P.BCNT(R3) ;AS MANY BYTES READ AS WRITTEN ?
4539 032570 001426      BEQ      5$          ;BRANCH IF YES
4540 032572 012705 011122      MOV      #RLST,R5          ;PUT THE RLS TABLE ADDRESS IN R5
4541 032576 012702 013262      MOV      #L$ERRTBL,R2     ;PUT THE ERROR TABLE ADDRESS IN R2
4542 032602 012522      MOV      (R5)+,(R2)+     ;MOV THE RLS TABLE TO THE ERROR TABLE
4543 032604 012522      MOV      (R5)+,(R2)+
4544 032606 012522      MOV      (R5)+,(R2)+
4545 032610 011512      MOV      (R5),(R2)
4546 032612      POP      <R5,R3,R2,R1>      ;RESTORE REGISTERS
          032612 012605      MOV      (SP)+,R5          ;;POP STACK INTO R5
          032614 012603      MOV      (SP)+,R3          ;;POP STACK INTO R3
          032616 012602      MOV      (SP)+,R2          ;;POP STACK INTO R2
          032620 012601      MOV      (SP)+,R1          ;;POP STACK INTO R1
4547 032622 004737 032036      JSR      PC,ERRTLY        ;GO TALLY THE ERROR
4548 032626 105037 013263      CLR      ERRTYP+1        ;CLEAR THE LUN POINTER
4549 032632 004737 032536      JSR      PC,PRIERR        ;GO PRINT THE ERROR
4550 032636      PUSH      <R1,R2,R3,R5>      ;SAVE R1,R2,R3,R5
          032636 010146      MOV      R1,-(SP)          ;;PUSH R1 ON STACK
          032640 010246      MOV      R2,-(SP)          ;;PUSH R2 ON STACK
          032642 010346      MOV      R3,-(SP)          ;;PUSH R3 ON STACK
          032644 010546      MOV      R5,-(SP)          ;;PUSH R5 ON STACK
4551 032646 005037 003444 5$:      CLR      CMPERR          ;CLEAR LOCATION CMPERR
4552 032652 042764 000020 000026      BIC      #ODDFLG,LUNFLG(R4) ;CLEAR THE ODD BYTE COUNT FLAG
4553 032660 016337 000014 003530      MOV      P.BCNT(R3),R8    ;PUT THE TAPE RECORD BYTE COUNT IN R8
4554 032666 005037 003532      CLR      R9              ;CLEAR THE BYTE ADDRESS COUNTER
4555 032672 032737 000001 003530      BIT      #BIT0,R8        ;IS THE BYTE COUNT ODD
4556 032700 001406      BEQ      10$            ;BRANCH IF NOT
4557 032702 042737 000001 003530      BIC      #BIT0,R8        ;MAKE THE COUNT EVEN
4558 032710 052764 000020 000026      BIS      #ODDFLG,LUNFLG(R4) ;SET THE ODD BYTE FLAG
4559 032716 012701 003446 10$:      MOV      #BYTADD,R1      ;LET R1 POINT TO THE ADDRESS TABLE
4560 032722 022737 000003 002114      CMP      #3,L$TEST      ;ARE WE IN TEST 3 ?
4561 032730 001003      BNE      11$            ;NO, SO JUST SET RDBUF IN BUFADR
4562 032732 012702 070550      MOV      #WRTBUF-2,R2    ;LET R2 POINT TO THE WRITE BUFFER
4563 032736 000402      BR      12$
4564 032740 012702 070552 11$:      MOV      #WRTBUF,R2      ;LET R2 POINT TO THE WRITE BUFFER
4565 032744 012703 050552 12$:      MOV      #RDBUF,R3      ;LET R3 POINT TO THE READ BUFFER
4566 032750 012705 003472      MOV      #DATBL,R5      ;LET R5 POINT TO THE ERROR DATA TABLE
4567 032754 022322 14$:      CMP      (R3)+,(R2)+     ;COMPARE THE FIRST WORD OF DATA

```

4568	032756	001447				BEQ	25\$;BRANCH IF THEY ARE EQUAL
4569	032760	126362	177776	177776		CMPB	LOBYTE(R3),LOBYTE(R2)		;COMPARE THE LOW BYTE
4570	032766	001415				BEQ	15\$;BRANCH IF EQUAL
4571	032770	005237	003444			INC	CMPERR		;ADD 1 TO THE ERROR COUNT
4572	032774	022701	003472			CMP	#TBLEND,R1		;IS THERE ROOM TO SAVE THIS DATA ?
4573	033000	001410				BEQ	15\$;BRANCH IF NOT
4574	033002	116315	177776			MOVB	LOBYTE(R3),(R5)		;LOW READ BYTE IN SAVE BYTE
4575	033006	116265	177776	000001		MOVB	LOBYTE(R2),ONE(R5)		;LOW WRITE BYTE IN SAVE BYTE
4576	033014	013721	003532			MOV	R9,(R1)+		;SAVE THE ADDRESS FOR PRINTING
4577	033020	005725				TST	(R5)+		;POINT R5 TO NEXT TABLE LOCATION
4578	033022	005237	003532		15\$:	INC	R9		;ADD 1 TO THE BYTE COUNT
4579	033026	126362	177777	177777		CMPB	HIBYTE(R3),HIBYTE(R2)		;COMPARE THE HIGH BYTE
4580	033034	001415				BEQ	20\$;BRANCH IF THEY ARE THE SAME
4581	033036	005237	003444			INC	CMPERR		;ADD 1 TO THE ERROR COUNT
4582	033042	022701	003472			CMP	#TBLEND,R1		;ROOM TO SAVE THIS DATA ?
4583	033046	001410				BEQ	20\$;BRANCH IF NOT
4584	033050	116315	177777			MOVB	HIBYTE(R3),(R5)		;HI READ BYTE TO LOW SAVE BYTE
4585	033054	116265	177777	000001		MOVB	HIBYTE(R2),ONE(R5)		;HIGH WRITE BYTE TO HIGH SAVE BYTE
4586	033062	013721	003532			MOV	R9,(R1)+		;SAVE THE ADDRESS TO PRINT
4587	033066	005725				TST	(R5)+		;POINT R5 TO THE NEXT TABLE LOCATION
4588	033070	005237	003532		20\$:	INC	R9		;ADD 1 TO THE BYTE COUNTER
4589	033074	000403				BR	30\$;BRANCH
4590	033076	062737	000002	003532	25\$:	ADD	#2,R9		;ADD 2 TO THE BYTE COUNT
4591	033104	023737	003532	003530	30\$:	CMP	R9,R8		;HAVE WE COMPARED THEM ALL ?
4592	033112	001320				BNE	14\$;NO, GO DO SOME MORE
4593	033114	032764	000020	000026		BIT	#ODDFLG,LUNFLG(R4)		;WAS IT AN ODD BYTE COUNT ?
4594	033122	001414				BEQ	35\$;BRANCH IF NOT
4595	033124	121312				CMPB	(R3),(R2)		;COMPARE THE LOW BYTES
4596	033126	001412				BEQ	35\$;BRANCH IF THEY MATCH
4597	033130	005237	003444			INC	CMPERR		;ADD 1 TO THE ERROR COUNT
4598	033134	022701	003472			CMP	#TBLEND,R1		;IS THERE ROOM FOR THIS DATA ?
4599	033140	001405				BEQ	35\$;BRANCH IF NOT
4600	033142	111315				MOVB	(R3),(R5)		;LOW READ BYTE IN THE LOW SAVE BYTE
4601	033144	111265	000001			MOVB	(R2),ONE(R5)		;LOW WRITE BYTE TO HIGH SAVE BYTE
4602	033150	013721	003532			MOV	R9,(R1)+		;SAVE THE ADDRESS TO PRINT
4603	033154	005737	003444		35\$:	TST	CMPERR		;DID WE HAVE ANY ERRORS ?
4604	033160	001423				BEQ	40\$;BRANCH TO EXIT IF NOT
4605	033162	012705	011112			MOV	#DCMPT,R5		;POINT R5 TO THE DATA COMPARE ERROR TABLE
4606	033166	012702	013262			MOV	#L\$ERRTBL,R2		;POINT R2 TO THE ERROR TABLE
4607	033172	012522				MOV	(R5)+,(R2)+		;MOVE THE DATA COMPARE COMPARE TABLE
4608	033174	012522				MOV	(R5)+,(R2)+		;TO THE ERROR TABLE
4609	033176	012522				MOV	(R5)+,(R2)+		
4610	033200	011512				MOV	(R5),(R2)		
4611	033202					POP	<R5,R3,R2,R1>		;RESTORE THE REGISTERS
	033202	012605				MOV	(SP)+,R5	::POP	STACK INTO R5
	033204	012603				MOV	(SP)+,R3	::POP	STACK INTO R3
	033206	012602				MOV	(SP)+,R2	::POP	STACK INTO R2
	033210	012601				MOV	(SP)+,R1	::POP	STACK INTO R1
4612	033212	004737	032036			JSR	PC,ERRTLY		;GO TALLY THE ERROR
4613	033216	105037	013263			CLRB	ERRTYP+1		;CLEAR THE UPPER BYTE OF ERROR TYPE
4614	033222	004737	032536			JSR	PC,PRIERR		;GO PRINT THE ERROR
4615	033226	000404				BR	45\$;EXIT
4616	033230				40\$:	POP	<R5,R3,R2,R1>		;RESTORE THE REGISTERS
	033230	012605				MOV	(SP)+,R5	::POP	STACK INTO R5
	033232	012603				MOV	(SP)+,R3	::POP	STACK INTO R3
	033234	012602				MOV	(SP)+,R2	::POP	STACK INTO R2
	033236	012601				MOV	(SP)+,R1	::POP	STACK INTO R1

GLOBAL AREAS
COMPARE DATA

MACRO Y05.02 Thursday 18-Apr-85 13:37 Page 59-2

L9

SEQ 115

4617 033240 000207

454: RTS PC

;RETURN

```

4619      .SBTTL UNJAM
4620      ;*****
4621      ;
4622      ; UNJAM
4623      ;
4624      ;Called By      :
4625      ;Calls To      :
4626      ;Inputs        :
4627      ;Outputs       :
4628      ;Register Inputs :
4629      ;Register Outputs:
4630      ;
4631
4632      UNJAM::
4633      033242 005737 003344      TST      DUMPKT      ;ARE WE ISSUEING NULL COMMANDS
4634      033246 001444      BEQ      15$      ;YES , THEN EXIT
4635      033250 023764 003542 000006  CMP      SECURNS,CMDSEQ(R4) ;IS IT THE ONLY COMMAND OUT ?
4636      033256 001440      BEQ      15$      ;YES , THEN EXIT
4637      033260 016437 000006 003436  MOV      CMDSEQ(R4),SAVDIF ;SET UP TO UNJAM THE QUEUES
4638      033266 163737 003542 003436  SUB      SECURNS,SAVDIF ;SUBTRACT CURRENT FROM THE HIGHEST
4639      033274 063737 003436 003400  ADD      SAVDIF,CMDCNT ;ADJUST THE COMMAND COUNT
4640      033302 063737 003436 003402  ADD      SAVDIF,RSPCNT ;ADJUST THE RESPONSE COUNT
4641      033310 042737 000200 003516  BIC      #CMDONE,PCFLAG ;CLEAR THE ALL COMMANDS ISSUED FLAG
4642      033316 163764 003436 000034  SUB      SAVDIF,OBJFDL(R4) ;ADJUST THE OBJECT COUNT
4643      033324 103002      BCC      5$      ;GET OUT IF NO CARRY
4644      033326 005364 000036      DEC      OBJFDH(R4) ;OTHERWISE, ADJUST THE HIGH WORD
4645      033332 022737 000004 003424 5$:  CMP      #N,SUBCNT
4646      033340 001002      BNE      10$
4647      033342 005037 003424      CLR      SUBCNT
4648      033346 005237 003424 10$:  INC      SUBCNT
4649      033352 005337 003436      DEC      SAVDIF
4650      033356 001365      BNE      5$
4651      033360 052764 000002 000026 15$:  BIS      #SEREXC,LUNFLG(R4) ;SET THE SERIOUS EXCEPTION FLAG
4652      033366 000207      RTS      PC      ;RETURN
4653      033370      ENDMOD
4654

```

```

4656 .SBTTL OCTAL -> HEX CONVERTER
4657 ;*****
4658 ;
4659 ; OCTAL -> HEX CONVERTER
4660 ;
4661
4662 033370 OCTHEX::
4663 033370 116337 000013 003552 MOV B P.STS+1(R3),LOHEX ;GET THE UPPER STATUS BYTE
4664 033376 013737 003552 003554 MOV LOHEX,HIHEX ;GET A SECOND COPY
4665 033404 042737 177760 003552 BIC #177760,LOHEX ;CLEAR THE UNWANTED BITS
4666 033412 042737 177417 003554 BIC #177417,HIHEX ;CLEAR THE UNWANTED BITS
4667 033420 006037 003554 ROR HIHEX ;SHIFT THE
4668 033424 006037 003554 ROR HIHEX ; UPPER NIBBLE
4669 033430 006037 003554 ROR HIHEX ; OVER 3 PLACES
4670 033434 006137 003552 ROL LOHEX ;SHIFT THE LOWER NIBBLE OVER 1
4671 033440 062737 011442 003552 ADD #HEXTBL,LOHEX ;ADD ASCII TABLE BASE ADDRESS
4672 033446 062737 011442 003554 ADD #HEXTBL,HIHEX ;ADD ASCII TABLE BASE ADDRESS
4673 033454 000207 RTS PC ;RETURN

```

```

4675          .SBTTL CLEAR EOT
4676          ;*****
4677          ;
4678          ; CLEAR EOT
4679          ;
4680
4681 033456    CLREOT::
4682 033456    PUSH    <R1,R2,R4>          ;SAVE R1, R2, AND R4
          033456 010146    MOV     R1,-(SP)          ;;PUSH R1 ON STACK
          033460 010246    MOV     R2,-(SP)          ;;PUSH R2 ON STACK
          033462 010446    MOV     R4,-(SP)          ;;PUSH R4 ON STACK
4683 033464 005002    CLR     R2          ;CLEAR OUT R2
4684 033466 012701 177776    MOV     #-2.,R1          ;SET R1 TO THE FIRST UNIT
4685 033472 012704 002314    MOV     #LUN0,R4          ;LET R4 EQUAL THE FIRDT LUN
4686 033476 062701 000002    5$:   ADD     #2.,R1          ;ADD 2 TO THE UNIT POINTER
4687 033502 062702 000001    ADD     #1.,R2          ;ADD 1 TO R2
4688 033506 112764 177777 000154    MOVB   #-1,OLDTRK(R4)    ;INITIALIZE OLD TRACK
4689 033514 012764 177777 000152    MOV     #-1,OLDBLK(R4)  ;INITIALIZE OLD BLOCK
4690 033522 062704 000172    ADD     #LUNSTP,R4      ;SET R4 TO THE NEXT LUN
4691 033526 042761 000004 003350    BIC     #EOT,DRINUS(R1) ;CLEAR THE EOT BIT IN DRINUS
4692 033534 005037 003526    CLR     UEOT          ;CLEAR THE EOT FLAG
4693 033540 023702 002012    10$:  CMP     L$UNIT,R2      ;HAVE WE DONE THEM ALL
4694 033544 001354    BNE     5$            ;NO, KEEP GOING TILL ALL DONE
4695 033546    POP     <R4,R2,R1>    ;RESTORE R4, R2, AND R1
          033546 012604    MOV     (SP)+,R4        ;;POP STACK INTO R4
          033550 012602    MOV     (SP)+,R2        ;;POP STACK INTO R2
          033552 012601    MOV     (SP)+,R1        ;;POP STACK INTO R1
4696 033554 000207    RTS     PC              ;RETURN

```

```

4698      .SBTTL SEED SETUP AND SAVE
4699      ;*****
4700      ;
4701      ; SEED SETUP
4702      ;
4703
4704 033556 SDSTUP::
4705 033556      PUSH      <R1,R4>
          033556 010146      MOV      R1,-(SP)      ;;PUSH R1 ON STACK
          033560 010446      MOV      R4,-(SP)      ;;PUSH R4 ON STACK
4706 033562 013701 002012      MOV      L$UNIT,R1
4707 033566 012704 002314      MOV      #LUNO,R4
4708 033572 016464 000136 000144 5$: MOV      SED1(R4),SEED1(R4)
4709 033600 016464 000140 000146      MOV      SED2(R4),SEED2(R4)
4710 033606 016464 000142 000150      MOV      SED3(R4),SEED3(R4)
4711 033614 062704 000172      ADD      #LUNSTP,R4
4712 033620 005301      DEC      R1
4713 033622 001363      BNE     5$
4714 033624      POP      <R4,R1>
          033624 012604      MOV      (SP)+,R4      ;;POP STACK INTO R4
          033626 012601      MOV      (SP)+,R1      ;;POP STACK INTO R1
4715 033630 000207      RTS      PC
4716
4717      ;*****
4718      ;
4719      ; SEED SAVE
4720      ;
4721
4722 033632 SDSAVE::
4723 033632      PUSH      <R1,R4>
          033632 010146      MOV      R1,-(SP)      ;;PUSH R1 ON STACK
          033634 010446      MOV      R4,-(SP)      ;;PUSH R4 ON STACK
4724 033636 013701 002012      MOV      L$UNIT,R1
4725 033642 012704 002314      MOV      #LUNO,R4
4726 033646 016464 000144 000136 5$: MOV      SEED1(R4),SED1(R4)
4727 033654 016464 000146 000140      MOV      SEED2(R4),SED2(R4)
4728 033662 016464 000150 000142      MOV      SEED3(R4),SED3(R4)
4729 033670 062704 000172      ADD      #LUNSTP,R4
4730 033674 005301      DEC      R1
4731 033676 001363      BNE     5$
4732 033700      POP      <R4,R1>
          033700 012604      MOV      (SP)+,R4      ;;POP STACK INTO R4
          033702 012601      MOV      (SP)+,R1      ;;POP STACK INTO R1
4733 033704 000207      RTS      PC
4734

```



```

4736
4737
4738
4739
4740
4741
4742
4743
4744 033706
4745 033706 012704 002314
4746 033712 005064 000024
4747 033716 022704 003072
4748 033722 001403
4749 033724 062704 000172
4750 033730 000770
4751 033732 000207
4752
4753
4754

```

```

.SBTTL PATTERN CLEAR
;*****
;
; PATTERN CLEAR
;
;THIS ROUTINE DOES NOT SAVE R4 AND THEREFORE SHOULD NOT BE CALLED FROM ANY
;PLACE OTHER THAN A TEST.

PATCLR:
1$:  MOV    #LUN0,R4
      CLR   PATSAV(R4)
      CMP   #LUN3,R4
      BEQ   2$
      ADD   #LUNSTP,R4
      BR    1$
2$:  RTS   PC

```

```

4756          .SBTTL CORE DUMP
4757          ;*****
4758          ;
4759          ; CORE DUMP
4760          ;
4761          ; THIS ROUTINE IS DESIGNED TO DUMP ALL CRITICAL MEMORY LOCATIONS ON
4762          ; OCCURRENCE OF ERRORS, WHEN ENEABLED BY THE OPERATOR VIA THE SOFTWARE
4763          ; QUESTIONS. IT IS INTENDED PRIMARILY AS AN AID TO DEBUGGING THE
4764          ; PROGRAM, BUT MAY PROVE USEFUL IN ANALYZING CERTAIN DEVICE ERRORS
4765          ; AS WELL.
4766
4767 033734     CORDMP:
4768 033734     PUSH    <R1,R2>
          033734 010146     MOV     R1,-(SP)          ;; PUSH R1 ON STACK
          033736 010246     MOV     R2,-(SP)          ;; PUSH R2 ON STACK
4769 033740     PRINTF  #DUMP,R1,R2,R3,R4,R5
          033740 010546     MOV     R5,-(SP)
          033742 010446     MOV     R4,-(SP)
          033744 010346     MOV     R3,-(SP)
          033746 010246     MOV     R2,-(SP)
          033750 010146     MOV     R1,-(SP)
          033752 012746 020347     MOV     #DUMP,-(SP)
          033756 012746 000006     MOV     #6,-(SP)
          033762 010600     MOV     SP,R0
          033764 104417     TRAP   C$PNTF
          033766 062706 000016     ADD     #16,SP
4770 033772 012701 002314     MOV     #LUN0,R1          ;PUT STARING ADDRESS IN R1
4771 033776 012702 002314     MOV     #LUN0,R2          ;AND ANOTHER COPY IN R2
4772 034002     1$: PRINTF  #DUMP2,R1,(R2),2(R2),4(R2),6(R2)
          034002 016246 000006     MOV     6(R2),-(SP)
          034006 016246 000004     MOV     4(R2),-(SP)
          034012 016246 000002     MOV     2(R2),-(SP)
          034016 011246     MOV     (R2),-(SP)
          034020 010146     MOV     R1,-(SP)
          034022 012746 020471     MOV     #DUMP2,-(SP)
          034026 012746 000006     MOV     #6,-(SP)
          034032 010600     MOV     SP,R0
          034034 104417     TRAP   C$PNTF
          034036 062706 000016     ADD     #16,SP
4773
4774 034042 062701 000010     ADD     #10,R1          ;UPDATE R1
4775 034046 062702 000010     ADD     #10,R2          ;UPDATE R2
4776 034052 022701 010572     CMP     #IOERTB,R1      ;ARE WE AT THE END OF DUMP AREA
4777 034056 101351     BHI    1$              ;KEEP GOING IF NOT
4778 034060     POP     <R2,R1>
4779 034064 000207     RTS    PC
4780

```

```

4782
4783
4784
4785
4786
4787
4788
4789
4790 034066
4791 034066
4792 034072 016301 000014
4793 034076 012702 050552
4794 034102
      034102 010146
      034104 012746 020430
      034110 012746 000002
      034114 010600
      034116 104417
      034120 062706 000006
4795
4796 034124
      034124 016246 000010
      034130 016246 000006
      034134 016246 000004
      034140 016246 000002
      034144 011246
      034146 012746 020471
      034152 012746 000006
      034156 010600
      034160 104417
      034162 062706 000016
4797 034166 062702 000012
4798 034172 162701 000012
4799 034176 001401
4800 034200 100351
4801
4802 034202
4803 034206 000207
4804

```

```

.SBTTL BUFFER DUMP
;*****
;
; BUFFER DUMP
;
; THIS ROUTINE WILL PRINT THE READ BUFFER FOR EVERY RECORD READ IN
; TEST 5.

BUFDMP:
  PUSH    <R1,R2>
  MOV     P.BCNT(R3),R1          ;GET NUMBER OF BYTES X-FERRED
  MOV     #RDBUF,R2             ;GET BUFFER ADDRESS
  PRINTF  #DUMP1,R1             ;PRINT NUMBER OF BYTES
  MOV     R1,-(SP)
  MOV     #DUMP1,-(SP)
  MOV     #2,-(SP)
  MOV     SP,R0
  TRAP   C$PNTF
  ADD     #6,SP

1$:      PRINTF #DUMP2,(R2),2(R2),4(R2),6(R2),10(R2)
  MOV     10(R2),-(SP)
  MOV     6(R2),-(SP)
  MOV     4(R2),-(SP)
  MOV     2(R2),-(SP)
  MOV     (R2),-(SP)
  MOV     #DUMP2,-(SP)
  MOV     #6,-(SP)
  MOV     SP,R0
  TRAP   C$PNTF
  ADD     #16,SP
  ADD     #12,R2
  SUB     #12,R1
  BEQ     5$
  BPL     1$
          ;ADJUST BUFFER POINTER
          ;ADJUST BYTE COUNT
          ;IF ZERO GET OUT
          ;KEEP GOING IF POSITIVE

5$:      POP     <R2,R1>
  RTS     PC

```

```

4816          .TITLE MISCELLANEOUS SECTIONS
4817          .SBTTL  REPORT CODING SECTION
4845
4846 034210          BGNMOD
4847
4848          ;++
4849          ; THE REPORT CODING SECTION CONTAINS THE
4850          ; "PRINTS" CALLS THAT GENERATE STATISTICAL REPORTS.
4851          ;--
4852
4853 034210          BGNRPT
4854 034210          L$RPT::
4860 034210          PUSH    <R1,R4,R5>
4861 034210 010146          MOV    R1,-(SP)          ;;PUSH R1 ON STACK
4862 034212 010446          MOV    R4,-(SP)          ;;PUSH R4 ON STACK
4863 034214 010546          MOV    R5,-(SP)          ;;PUSH R5 ON STACK
4864 034216 032737 000400 003516          BIT    #DROPT,PCFLAG          ;ARE WE DROPPING A UNIT
4865 034224 001015          BNE    5$          ;YES, ONLY PRINT STATS FOR THIS UNIT
4866 034226 005001          CLR    R1          ;SET R1 TO FIRST UNIT
4867 034230 005037 002074          CLR    L$LUN          ;START WITH UNIT 0
4868 034234 012704 002314          MOV    #LUNO,R4          ;START WITH LUN BLOCK FOP UNIT 0
4869 034240 013705 002012          MOV    L$UNIT,R5          ;INIT UNIT COUNTER
4870 034244 032761 000010 003350 1$:          BIT    #DROP,DRINUS(R1)          ;HAS THE DRIVE BEEN DROPPED ?
4871 034252 001402          BEQ    5$          ;NO, PRINT ITS STATS
4872 034254 000137 035346          JMP    15$          ;OTHERWISE GET THE NEXT DRIVE
4873
4874 034260          5$:          PRINTS #STAT0
4875 034260 012746 035464          MOV    #STAT0,-(SP)
4876 034264 012746 000001          MOV    #1,-(SP)
4877 034270 010600          MOV    SP,R0
4878 034272 104416          TRAP  C$PNTS
4879 034274 062706 000004          ADD    #4,SP
4880
4881 034300          PRINTS #STAT1,L$LUN
4882 034300 013746 002074          MOV    L$LUN,-(SP)
4883 034304 012746 035467          MOV    #STAT1,-(SP)
4884 034310 012746 000002          MOV    #2,-(SP)
4885 034314 010600          MOV    SP,R0
4886 034316 104416          TRAP  C$PNTS
4887 034320 062706 000006          ADD    #6,SP
4888
4889 034324          PRINTS #STAT2
4890 034324 012746 035533          MOV    #STAT2,-(SP)
4891 034330 012746 000001          MOV    #1,-(SP)
4892 034334 010600          MOV    SP,R0
4893 034336 104416          TRAP  C$PNTS
4894 034340 062706 000004          ADD    #4,SP
4895
4896 034344          PRINTS #STAT3
4897 034344 012746 035600          MOV    #STAT3,-(SP)
4898 034350 012746 000001          MOV    #1,-(SP)
4899 034354 010600          MOV    SP,R0
4900 034356 104416          TRAP  C$PNTS
4901 034360 062706 000004          ADD    #4,SP
4902
4903 034364          PRINTS #STAT4

```

	034364	012746	035660	MOV	#STAT4,-(SP)
	034370	012746	000001	MOV	#1,-(SP)
	034374	010600		MOV	SP,R0
	034376	104416		TRAP	C\$PNTS
	034400	062706	000004	ADD	#4,SP
4880					
4881	034404			PRINTS	#STAT5,S1READ(R4),S2READ(R4),S1WRIT(R4),S2WRIT(R4)
	034404	016446	000046	MOV	S2WRIT(R4),-(SP)
	034410	016446	000044	MOV	S1WRIT(R4),-(SP)
	034414	016446	000042	MOV	S2READ(R4),-(SP)
	034420	016446	000040	MOV	S1READ(R4),-(SP)
	034424	012746	035705	MOV	#STAT5,-(SP)
	034430	012746	000005	MOV	#5,-(SP)
	034434	010600		MOV	SP,R0
	034436	104416		TRAP	C\$PNTS
	034440	062706	000014	ADD	#14,SP
4882					
4883	034444			PRINTS	#STAT6,EC1COR(R4),EC2COR(R4)
	034444	016446	000052	MOV	EC2COR(R4),-(SP)
	034450	016446	000050	MOV	EC1COR(R4),-(SP)
	034454	012746	035752	MOV	#STAT6,-(SP)
	034460	012746	000003	MOV	#3,-(SP)
	034464	010600		MOV	SP,R0
	034466	104416		TRAP	C\$PNTS
	034470	062706	000010	ADD	#10,SP
4884					
4885	034474			PRINTS	#STAT7,H1READ(R4),H2READ(R4),H1WRIT(R4),H2WRIT(R4)
	034474	016446	000062	MOV	H2WRIT(R4),-(SP)
	034500	016446	000060	MOV	H1WRIT(R4),-(SP)
	034504	016446	000056	MOV	H2READ(R4),-(SP)
	034510	016446	000054	MOV	H1READ(R4),-(SP)
	034514	012746	036024	MOV	#STAT7,-(SP)
	034520	012746	000005	MOV	#5,-(SP)
	034524	010600		MOV	SP,R0
	034526	104416		TRAP	C\$PNTS
	034530	062706	000014	ADD	#14,SP
4886					
4887	034534			PRINTS	#STAT8,RTYEC1(R4),RTYEC2(R4)
	034534	016446	000066	MOV	RTYEC2(R4),-(SP)
	034540	016446	000064	MOV	RTYEC1(R4),-(SP)
	034544	012746	036071	MOV	#STAT8,-(SP)
	034550	012746	000003	MOV	#3,-(SP)
	034554	010600		MOV	SP,R0
	034556	104416		TRAP	C\$PNTS
	034560	062706	000010	ADD	#10,SP
4888					
4889	034564			PRINTS	#STAT9,DTCPER(R4)
	034564	016446	000070	MOV	DTCPER(R4),-(SP)
	034570	012746	036143	MOV	#STAT9,-(SP)
	034574	012746	000002	MOV	#2,-(SP)
	034600	010600		MOV	SP,R0
	034602	104416		TRAP	C\$PNTS
	034604	062706	000006	ADD	#6,SP
4890					
4891	034610			PRINTS	#STAT10,UNDRUN(R4)
	034610	016446	000072	MOV	UNDRUN(R4),-(SP)
	034614	012746	036222	MOV	#STAT10,-(SP)

	034620	012746	000002	MOV	#2,-(SP)
	034624	010600		MOV	SP,R0
	034626	104416		TRAP	C\$PNTS
	034630	062706	000006	ADD	#6,SP
4892					
4893	034634			PRINTS	#STAT11,OVRUN(R4)
	034634	016446	000074	MOV	OVRUN(R4),-(SP)
	034640	012746	036272	MOV	#STAT11, -(SP)
	034644	012746	000002	MOV	#2,-(SP)
	034650	010600		MOV	SP,R0
	034652	104416		TRAP	C\$PNTS
	034654	062706	000006	ADD	#6,SP
4894					
4895	034660			PRINTS	#STAT12,RMSPOS(R4),WMSPOS(R4)
	034660	016446	000100	MOV	WMSPOS(R4),-(SP)
	034664	016446	000076	MOV	RMSPOS(R4),-(SP)
	034670	012746	036344	MOV	#STAT12, -(SP)
	034674	012746	000003	MOV	#3,-(SP)
	034700	010600		MOV	SP,R0
	034702	104416		TRAP	C\$PNTS
	034704	062706	000010	ADD	#10,SP
4896					
4897	034710			PRINTS	#STAT13,OTHER(R4)
	034710	016446	000102	MOV	OTHER(R4),-(SP)
	034714	012746	036405	MOV	#STAT13, -(SP)
	034720	012746	000002	MOV	#2,-(SP)
	034724	010600		MOV	SP,R0
	034726	104416		TRAP	C\$PNTS
	034730	062706	000006	ADD	#6,SP
4898					
4899	034734			PRINTS	#STAT14,DROPPD(R4)
	034734	016446	000104	MOV	DROPPD(R4),-(SP)
	034740	012746	036430	MOV	#STAT14, -(SP)
	034744	012746	000002	MOV	#2,-(SP)
	034750	010600		MOV	SP,R0
	034752	104416		TRAP	C\$PNTS
	034754	062706	000006	ADD	#6,SP
4900					
4901	034760			PRINTS	#STAT15,WRBYT4(R4),WRBYT3(R4),WRBYT2(R4),WRBYT1(R4)
	034760	016446	000120	MOV	WRBYT1(R4),-(SP)
	034764	016446	000122	MOV	WRBYT2(R4),-(SP)
	034770	016446	000124	MOV	WRBYT3(R4),-(SP)
	034774	016446	000126	MOV	WRBYT4(R4),-(SP)
	035000	012746	036453	MOV	#STAT15, -(SP)
	035004	012746	000005	MOV	#5,-(SP)
	035010	010600		MOV	SP,R0
	035012	104416		TRAP	C\$PNTS
	035014	062706	000014	ADD	#14,SP
4902					
4903	035020			PRINTS	#STAT16,RDBYT4(R4),RDBYT3(R4),RDBYT2(R4),RDBYT1(R4)
	035020	016446	000110	MOV	RDBYT1(R4),-(SP)
	035024	016446	000112	MOV	RDBYT2(R4),-(SP)
	035030	016446	000114	MOV	RDBYT3(R4),-(SP)
	035034	016446	000116	MOV	RDBYT4(R4),-(SP)
	035040	012746	036525	MOV	#STAT16, -(SP)
	035044	012746	000005	MOV	#5,-(SP)
	035050	010600		MOV	SP,R0

4904	035052	104416			TRAP	C\$PNTS		
	035054	062706	000014		ADD	#14,SP		
4905	035060				PRINTS	#STAT0		
	035060	012746	035464		MOV	#STAT0,-(SP)		
	035064	012746	000001		MOV	#1,-(SP)		
	035070	010600			MOV	SP,R0		
	035072	104416			TRAP	C\$PNTS		
	035074	062706	000004		ADD	#4,SP		
4906								
4907	035100	032737	000100	003516	BIT	#NOMDTB,PCFLAG		;IS THE TABLE TO BE PRINTED
4908	035106	001117			BNE	15\$;NO, GET OUT
4909	035110				PUSH	<R1,R2,R3>		
4910	035116	016401	000130		MOV	TBLTOP(R4),R1		;POINT R1 TO THE TOP OF THE TABLE
4911	035122	016402	000134		MOV	LSTENT(R4),R2		;POINT R2 TO THE LAST ENTRY IN TABLE
4912								
4913	035126				PRINTS	#STAT17,L\$LUN		
	035126	013746	002074		MOV	L\$LUN,-(SP)		
	035132	012746	036577		MOV	#STAT17,-(SP)		
	035136	012746	000002		MOV	#2,-(SP)		
	035142	010600			MOV	SP,R0		
	035144	104416			TRAP	C\$PNTS		
	035146	062706	000006		ADD	#6,SP		
4914								
4915	035152	016103	000000		MOV	TRK(R1),R3		;MOV THE TRACK # TO TEMP STORAGE
4916	035156	020102		10\$:	CMP	R1,R2		;HAVE WE PRINTED ALL ENTRIES ?
4917	035160	001451			BEQ	12\$;YES, GET OUT
4918	035162	026103	000000		CMP	TRK(R1),R3		;ARE WE STILL ON THE SAME TRACK ?
4919	035166	001412			BEQ	11\$;YES, KEEP GOING
4920	035170	016103	000000		MOV	TRK(R1),R3		;MOV THE TRACK # TO TEMP STORAGE
4921								
4922	035174				PRINTS	#STAT0		
	035174	012746	035464		MOV	#STAT0,-(SP)		
	035200	012746	000001		MOV	#1,-(SP)		
	035204	010600			MOV	SP,R0		
	035206	104416			TRAP	C\$PNTS		
	035210	062706	000004		ADD	#4,SP		
4923								
4924	035214			11\$:	PRINTS	#STAT18,<B,TRK(R1)>,PHB(R1),<B,HWR(R1)>,<B,HRD(R1)>,<B,SWR(R1)>,<B,SRD(R1)>		
	035214	005046			CLR	-(SP)		
	035216	156116	000005		BISB	SRD(R1),(SP)		
	035222	005046			CLR	-(SP)		
	035224	156116	000004		BISB	SWR(R1),(SP)		
	035230	005046			CLR	-(SP)		
	035232	156116	000007		BISB	HRD(R1),(SP)		
	035236	005046			CLR	-(SP)		
	035240	156116	000006		BISB	HWR(R1),(SP)		
	035244	016146	000002		MOV	PHB(R1),-(SP)		
	035250	005046			CLR	-(SP)		
	035252	156116	000000		BISB	TRK(R1),(SP)		
	035256	012746	036647		MOV	#STAT18,-(SP)		
	035262	012746	000007		MOV	#7,-(SP)		
	035266	010600			MOV	SP,R0		
	035270	104416			TRAP	C\$PNTS		
	035272	062706	000020		ADD	#20,SP		
4925								
4926	035276	062701	000010		ADD	#8.,R1		;STEP R1 TO THE NEXT TABLE LOCATION

```

4927 035302 000725          BR      10$          ;NO, KEEP PRINTING
4928 035304          POP      <R3,R2,R1>
4929 035312 032764 000040 000026 12$:  BIT      #MTBLOV,LUNFLG(R4)  ;IS THE TABLE FULL ?
4930 035320 001412          BEQ      15$          ;NO, GET NEXT DRIVE
4931 035322          PRINTF   #TBLFUL,L$LUN      ;PRINT TABLE FULL MESSAGE
      035322 013746 002074          MOV      L$LUN,-(SP)
      035326 012746 036716          MOV      #TBLFUL,-(SP)
      035332 012746 000002          MOV      #2,-(SP)
      035336 010600          MOV      SP,R0
      035340 104417          TRAP    C$PNTF
      035342 062706 000006          ADD      #6,SP

4932
4933 035346 032737 000400 003516 15$:  BIT      #DROPT,PCFLAG      ;ARE WE DROPPING A UNIT
4934 035354 001036          BNE      25$          ;YES, ONLY PRINT STATS FOR THIS UNIT
4935 035356 062704 000172          ADD      #LUNSTP,R4        ;R4 POINTS TO NEXT LUN BLOCK
4936 035362 062701 000002          ADD      #2,R1            ;POINT R1 TO THE NEXT UNIT
4937 035366 005237 002074          INC      L$LUN            ;POINTS TO NEXT UNIT NUMBER
4938 035372 005305          DEC      R5              ;ANY UNITS LEFT TO REPORT?
4939 035374 001402          BEQ      20$          ;BRANCH IF NOT
4940 035376 000137 034244          JMP      1$            ;ELSE, DO IT AGAIN
4941 035402 105737 002212          TSTB    CLOCK            ;IS THE CLOCK ENABLED
4942 035406 001421          BEQ      25$          ;NO, THEN CAN'T PRINT TIME
4943 035410          PRINTF   #TIME,<B,HOURS>,<B,MINUTE>,<B,SECOND>,
      035410 005046          CLR      -(SP)
      035412 153716 002215          BISB    SECOND,(SP)
      035416 005046          CLR      -(SP)
      035420 153716 002214          BISB    MINUTE,(SP)
      035424 005046          CLR      -(SP)
      035426 153716 002213          BISB    HOURS,(SP)
      035432 012746 020044          MOV      #TIME,-(SP)
      035436 012746 000004          MOV      #4,-(SP)
      035442 010600          MOV      SP,R0
      035444 104417          TRAP    C$PNTF
      035446 062706 000012          ADD      #12,SP
4944 035452          POP      <R5,R4,R1>      ;RESTORE REGS
4945 035460          EXIT    RPT
      035460 000167          .WORD   J$JMP
      035462 001316          .WORD   L10007-2-.

4946
4958

```


;FORMAT STATEMENTS FOR PRINT CALLS

```

4960
4961
4962 035464      045      116      000  STAT0: .ASCIZ  ?N?
4963 035467      045      116      045  STAT1: .ASCIZ  ?N%ASTATISTICAL REPORT FOR UNIT %D1?
4964 035533      045      116      045  STAT2: .ASCIZ  ?N%S8%S8%S8%S8%S2%AREAD%S4%S8%AWRITE?
4965 035600      045      116      045  STAT3: .ASCIZ  ?N%S8%S8%S8%S6%ACH 1%S4%ACH 2%S4%ACH 1%S4%ACH 2?
4966 035660      045      116      045  STAT4: .ASCIZ  ?N%ASOFT DATA ERRORS?
4967 035705      045      116      045  STAT5: .ASCIZ  ?N%A  RETRY RECOVERED%S8%D8%D8%D8%D8?
4968 035752      045      116      045  STAT6: .ASCIZ  ?N%A  ECC CORRECTED  %S8%D8%D8%S8%A  N.A.?
4969 036024      045      116      045  STAT7: .ASCIZ  ?N%AHARD DATA ERRORS %S8%D8%D8%D8%D8?
4970 036071      045      116      045  STAT8: .ASCIZ  ?N%ACRC ON ECC BLOCKS%S8%D8%D8%S8%A  N.A.?
4971 036143      045      116      045  STAT9: .ASCIZ  ?N%ADATA COMPARE ERRORS  %S8%D8%S8%A  N.A.?
4972 036222      045      116      045  STAT10: .ASCIZ ?N%ADATA UNDERRUNS%S7%S7%S7%AN.A.%S6%D8?
4973 036272      045      116      045  STAT11: .ASCIZ ?N%ADATA OVERRUNS%S8%S8%D8%S8%A  N.A.?
4974 036344      045      116      045  STAT12: .ASCIZ ?N%AMISPOSITIONS %S8%S8%D8%S8%D8?
4975 036405      045      116      045  STAT13: .ASCIZ ?N%AOTHERS %S8%D8?
4976 036430      045      116      045  STAT14: .ASCIZ ?N%ADROPS %S8%D8?
4977 036453      045      116      045  STAT15: .ASCIZ ?N%ABYTES WRITTEN %D3%A,%Z3%A,%Z3%A,%Z3?
4978 036525      045      116      045  STAT16: .ASCIZ ?N%ABYTES READ %D3%A,%Z3%A,%Z3%A,%Z3?
4979 036577      045      116      045  STAT17: .ASCIZ ?N%A TRK PHY BLK HWR HRD SWR SRD%N?
4980 036647      045      116      045  STAT18: .ASCIZ ?N%S2%D2%S3%D5%S3%D3%S2%D3%S2%D3?
4981 036716      045      116      045  TBLFUL: .ASCIZ ?N%AUNIT %D1%A MEDIA DATA TABLE HAS OVERFLOWED%N%N?
4982
4983
4984
4985 037002
      037002
      037002 104425

```

L10007: ENDRPT
TRAP C\$RPT

```

4987          .SBTTL INITIALIZE SECTION
4988
4989
4990          ;**
4991          ; THE INITIALIZE SECTION CONTAINS THE CODING THAT IS PERFORMED
4992          ; AT THE BEGINNING OF EACH PASS.
4993          ;--
4994 037004          BGNINIT
4995 037004          L$INIT::
4996 037004          STINIT::
4997 037004          READEF #EF.START
037004 012700 000040      MOV #EF.START,R0
037010 104447          TRAP C$REFG
4998 037012          BCOMPLETE START
037012 103414          BCS START
4999
5000 037014          READEF #EF.RESTART
037014 012700 000037      MOV #EF.RESTART,R0
037020 104447          TRAP C$REFG
5001 037022          BCOMPLETE START
037022 103410          BCS START
5002
5003 037024          READEF #EF.NEW
037024 012700 000035      MOV #EF.NEW,R0
037030 104447          TRAP C$REFG
5004 037032          BCOMPLETE NUPASS
037032 103463          BCS NUPASS
5005
5006 037034          READEF #EF.CONTINUE
037034 012700 000036      MOV #EF.CONTINUE,R0
037040 104447          TRAP C$REFG
5007 037042          BCOMPLETE NUPASS
037042 103457          BCS NUPASS
5008
5009 037044 112737 000001 003564 START: MOVB #1,DAYS          ;SET TO FIRST DAY
5010 037052 005037 003522          CLR PASCNT          ;CLEAR THE PASS COUNTER
5011 037056 005037 003444          CLR CMPERR          ;CLEAR THE COMPARE ERROR COUNTER
5012
5013 037062 012701 002314          MOV #LUN0,R1          ;SET R1 TO THE FIRST LUN
5014 037066 010102          5$: MOV R1,R2          ;LET R2 = R1
5015 037070 062702 000156          ADD #URSPBF,R2          ;LET R2 = THE END OF THE CLEAR AREA
5016 037074 005021          10$: CLR (R1)+          ;CLEAR THE LUN LOCATION
5017 037076 020201          CMP R2,R1          ;ARE WE AT THE END OF THE CLEAR AREA
5018 037100 001375          BNE 10$          ;NO, KEEP CLEARING
5019 037102 062701 000014          ADD #14,R1          ;SET R1 TO THE NEXT LUN BLOCK
5020 037106 022701 003264          CMP #PCMDBF,R1          ;HAVE WE DONE THEM ALL
5021 037112 001365          BNE 5$          ;GO CLEAR THE NEXT LUN BLOCK
5022
5023 037114 005021          15$: CLR (R1)+          ;CLEAR THE LOCATION AND GET THE NEXT
5024 037116 022701 003400          CMP #CMDCNT,R1          ;HAVE WE CLEARED THEM ALL ?
5025 037122 001374          BNE 15$          ;NO, KEEP GOING
5026
5027 037124 012701 110552          20$: MOV #MEDIAS,R1          ;PUT THE STATS TABLE ADDRESS INTO R1
5028 037130 005021          CLR (R1)+          ;CLEAR THE LOCATION AND GET THE NEXT
5029 037132 022701 115612          CMP #PATCH,R1          ;HAVE WE CLEARED THEM ALL ?
5030 037136 001374          BNE 20$          ;NO, KEEP GOING

```

INITIALIZE SECTION

```

5031
5032 037140 012704 002314      MOV      #LUN0,R4      ;SET R4 TO THE FIRST LUN
5033 037144 013702 002012      MOV      L$UNIT,R2    ;SET UP R2
5034 037150 012764 001233 000136 25$:  MOV      #RS1,SED1(R4) ;SET UP THE SEED IN THE LUN BLOCK
5035 037156 012764 007622 000140      MOV      #RS2,SED2(R4) ;SET UP THE SEED IN THE LUN BLOCK
5036 037164 012764 000000 000142      MOV      #RS3,SED3(R4) ;SET UP THE SEED IN THE LUN BLOCK
5037
5038 037172 062704 000172      30$:    ADD      #LUNSTP,R4    ;SET UP THE NEXT LUN BLOCK
5039 037176 005302      DEC      R2            ;DECREMENT R2
5040 037200 001363      BNE     25$           ;DID YOU DO THEM ALL
5041
5042 037202      NUPASS: BRESET
      037202 104433      TRAP    C$RESET
5043 037204 005737 003522      TST     PASCNT        ;IS THIS THE FIRST PASS ?
5044 037210 001403      BEQ     1$            ;YES GO CLEAR THE MEDIA TABLE
5045 037212 105737 002226      TSTB   CLRMED        ;ARE WE CLEARING THE MEDIA TABLE ?
5046 037216 001457      BEQ     25$          ;NO GET OUT
5047
5048 037220      1$:
5049 037220 013702 002012      MOV     L$UNIT,R2    ;SET UP R2
5050 037224 022702 000001      CMP     #1,R2        ;IS THERE 1 UNIT ?
5051 037230 001004      BNE     3$            ;NO, CHECK AGAIN
5052 037232 012737 005040 003544      MOV     #U1OFF,TBLOFF ;SET OFFSET FOR 1 UNIT IN TBLOFF
5053 037240 000421      BR     15$           ;GO GET STARTED
5054
5055 037242 022702 000002      3$:    CMP     #2,R2        ;IS THERE 2 UNITS ?
5056 037246 001004      BNE     5$            ;NO, CHECK AGAIN
5057 037250 012737 002420 003544      MOV     #U2OFF,TBLOFF ;SET OFFSET FOR 2 UNITS IN TBLOFF
5058 037256 000412      BR     15$           ;GO GET STARTED
5059
5060 037260 022702 000003      5$:    CMP     #3,R2        ;IS THERE 3 UNITS ?
5061 037264 001004      BNE     10$           ;NO, CHECK AGAIN
5062 037266 012737 001540 003544      MOV     #U3OFF,TBLOFF ;SET OFFSET FOR 3 UNITS IN TBLOFF
5063 037274 000403      BR     15$           ;GO GET STARTED
5064
5065 037276 012737 001210 003544 10$:    MOV     #U4OFF,TBLOFF ;SET OFFSET FOR 4 UNITS IN TBLOFF
5066
5067 037304 012704 002314      15$:    MOV     #LUN0,R4      ;SET R4 TO THE FIRST LUN
5068 037310 012737 110552 003530      MOV     #MEDIAS,R8    ;PUT THE STAT TABLE ADDRESS IN R8
5069
5070 037316 013764 003530 000130 20$:    MOV     R8,TBLTOP(R4) ;PUT THE TOP TABLE ADDR IN LUN BLOCK
5071 037324 013764 003530 000134      MOV     R8,LSTENT(R4) ;PUT THE TABLE ENTRY ADDR IN LUN BLOCK
5072 037332 063737 003544 003530      ADD     TBLOFF,R8     ;ADD THE LENGTH FOR EACH UNIT
5073 037340 013764 003530 000132      MOV     R8,TBLBTM(R4) ;PUT THE TABLE BOTTOM POINTER IN LUNBLK
5074 037346 062704 000172      ADD     #LUNSTP,R4    ;SET UP THE NEXT LUN BLOCK
5075 037352 005302      DEC     R2            ;DECREMENT R2
5076 037354 001360      BNE     20$          ;DID YOU DO THEM ALL
5077
5078 037356 005037 003516      25$:    CLR     PCFLAG        ;CLEAR THE PROGRAM CONTROL FLAG.
5079 037362 005037 003526      CLR     UEOT          ;CLEAR THE EOT FLAG
5080 037366 013737 002012 003524      MOV     L$UNIT,UDROP  ;SET UP THE DROP UNIT FLAG
5081 037374 005237 003522      INC     PASCNT        ;ADD 1 TO PASS COUNTER
5082 037400 105737 002227      TSTB   MEDTBL        ;IS THE MEDIA TABLE TO BE PRINTED
5083 037404 001003      BNE     30$           ;YES, DON'T DO ANYTHING
5084 037406 052737 000100 003516      BIS     #NOMDTB,PCFLAG ;NO, SET THE PROGRAM CONTROL FLAG BIT
5085
5086 037414 012702 003566      30$:    MOV     #CMDBF1,R2    ;PUT COMMAND BUFFER ADDRESS IN R2

```

```

INITIALIZE SECTION
5087 037420 005022          35$: CLR (R2)+ ;CLEAR THE BUFFERS
5088 037422 022702 010226 CMP #DSRNG0,R2 ;ARE WE AT THE END OF THE BUFFER ?
5089 037426 001374          BNE 35$ ;KEPP GOING TILL WE ARE
5090
5091 037430 012704 002314 MOV #LUN0,R4 ;SET R4 TO THE FIRST LUN
5092 037434 013702 002012 MOV L$UNIT,R2 ;SET UP R2
5093 037440 005001          CLR R1 ;CLEAR R1
5094 037442 005003          CLR R3 ;CLEAR R3
5095
5096 037444 032761 000020 003350 40$: BIT #FAIL,DRINUS(R1) ;HAS THIS DRIVE FAILED ?
5097 037452 001054          BNE 60$ ;YES, GET NEXT UNIT
5098
5099 037454 032761 000010 003350 45$: BIT #DROP,DRINUS(R1) ;DID THIS DRIVE DROP LAST TIME
5100 037462 001002          BNE 50$ ;YES, KEEP GOING
5101 037464 005064 000032          CLR UNDROP(R4) ;OTHERWISE CLEAR THE DROP COUNTER
5102 037470 012761 000001 003350 50$: MOV #AVB,DRINUS(R1) ;SET UP ALL DRIVES TO AVAILABLE
5103
5104 037476 012764 003572 000014 55$: MOV #DCMDBF,CNUSAV(R4) ;SET UP NEW COMMAND BUFFER SAVE
5105 037504 012764 003572 000016 MOV #DCMDBF,COLSAV(R4) ;SET UP OLD COMMAND BUFFER SAVE
5106 037512 016464 000166 000012 MOV UCDSRG(R4),CMDSSV(R4) ;SET UP COMMAND DESCRIPTOR SAVE
5107 037520 016464 000156 000020 MOV URSPBF(R4),RNUSAV(R4) ;SET UP NEW RESPONSE BUFFER SAVE
5108 037526 016464 000156 000022 MOV URSPBF(R4),ROLSAV(R4) ;SET UP OLD RESPONSE BUFFER SAVE
5109
5110 037534 005064 000006          CLR CMDSEQ(R4) ;CLEAR THE COMMAND REFERENCE NUMBER
5111 037540 005064 000034          CLR OBJFDL(R4) ;CLEAR THE LOW OBJECT FIELD
5112 037544 005064 000036          CLR OBJFDH(R4) ;CLEAR THE HIGH OBJECT FIELD
5113 037550 005064 000010          CLR SLTUSE(R4) ;CLEAR THE SLOT IN USE FLAG
5114 037554 010300          MOV R3,R0 ;
5115
5116 037556          GPWARD R0,R0
5117 037556 104442          TRAP C$GPHRD
5118 037560          BNCOMPLETE 60$
5119 037560 103011          BCC 60$
5120
5121 037562 011064 000000          MOV (R0),TKIP(R4) ;
5122 037566 012064 000002          MOV (R0)+,TKSA(R4) ;
5123 037572 062764 000002 000002 ADD #2,TKSA(R4) ;
5124 037600 011064 000004          MOV (R0),TKUNIT(R4) ;
5125
5126 037604 062701 000002          60$: ADD #2,R1 ;SET R1 TO THE NEXT UNIT
5127 037610 062703 000001          ADD #1.,R3 ;GET NEXT UNIT
5128 037614 062704 000172          ADD #LUNSTP,R4 ;SET UP THE NEXT LUN BLOCK
5129 037620 005302          DEC R2 ;DECREMENT R2
5130 037622 001310          BNE 40$ ;DID YOU DO THEM ALL
5131
5132 037624 042737 000002 003516 BIC #NCLKFL,PCFLAG ;GET READY TO TEST FOR CLOCK PRESENT
5133 037632          SETVEC #4,#NOCLK,#PRI00 ;SET VECTOR 4 IN CASE NO CLOCK
5134 037632 012746 000000          MOV #PRI00,-(SP)
5135 037636 012746 021044          MOV #NOCLK,-(SP)
5136 037642 012746 000004          MOV #4,-(SP)
5137 037646 012746 000003          MOV #3,-(SP)
5138 037652 104437          TRAP C$SVEC
5139 037654 062706 000010          ADD #10,SP
5140 037660 005737 177546          TST KWCSR ;IS THE CLOCK THERE ?
5141 037664 000240          NOP
5142 037666 000240          NOP
5143
5144

```

```

INITIALIZE SECTION
5136 037670          CLRVEC #4          ;RETURN VECTOR TO TRAP CATCHER
      037670 012700 000004  MOV #4,R0
      037674 104436  TRAP C$CVEC
5137 037676 032737 000002 003516  BIT #NCLKFL,PCFLAG ;WAS A CLOCK PRESENT ?
5138 037704 001016  BNE ISTART ;NO CLOCK, START REGULAR INIT
5139 037706          SETVEC #100,#KWHDL,#PRI00 ;SET UP THE CLOCK VECTOR
      037706 012746 000000  MOV #PRI00,-(SP)
      037712 012746 021100  MOV #KWHDL,-(SP)
      037716 012746 000100  MOV #100,-(SP)
      037722 012746 000003  MOV #3,-(SP)
      037726 104437  TRAP C$SVEC
      037730 062706 000010  ADD #10,SP
5140 037734 012737 000100 177546  MOV #100,KWCSR ;ENABLE THE CLOCK INTERRUPTS
5141
5142 037742 005001          ISTART: CLR R1 ;SET R1 TO FIST UNIT
5143 037744 005037 002074  CLR L$LUN ;SET L$LUN TO FIRST UNIT
5144 037750 012704 002314  MOV #LUN0,R4 ;SET R4 TO THE FIRST LUN BLOCK
5145
5146 037754 032761 000001 003350 1$: BIT #AVB,DRINUS(R1) ;SEE IF DRIVE IS PRESENT AND AVAILABLE
5147 037762 001547  BEQ 20$ ;GET THE NEXT DRIVE IF IT ISN'T
5148 037764 032761 000004 003350  BIT #EOT,DRINUS(R1) ;CHECK IF THE DRIVE IS AT EOT
5149 037772 001143  BNE 20$ ;GET NEXT DRIVE IF IT IS
5150
5151 037774 012764 000377 000010  MOV #377,SLTUSE(R4) ;SET ALL RESPONSE SLOTS TO THE PORT
5152 040002 004737 026230  JSR PC,PRTCLR ;GO DO IT
5153 040006 112737 000004 010571  MOVB #4,CRDLIM ;CREDITS START AT 4 FOR NEW LUN
5154
5155 040014 012705 040336  MOV #INITIT,R5 ;PUT INIT TEST TABLE ADDRESS IN R5
5156 040020 004737 021406  JSR PC,CMMDSQ ;GO DO INIT ON THIS DRIVE
5157 040024 032761 000001 003350  BIT #AVB,DRINUS(R1) ;SEE IF DRIVE IS PRESENT AND AVAILABLE
5158 040032 001523  BEQ 20$ ;GET THE NEXT DRIVE IF IT ISN'T
5159
5160 040034 012764 000377 000010  MOV #377,SLTUSE(R4) ;SET ALL RESPONSE SLOTS TO THE PORT
5161 040042 004737 026230  JSR PC,PRTCLR ;GO DO IT
5162 040046 112737 000004 010571  MOVB #4,CRDLIM ;CREDITS START AT 4 FOR NEW LUN
5163 040054 062705 000006  ADD #TSTSTP,R5 ;POINT R5 TO THE SCC COMMAND
5164 040060 004737 021406  JSR PC,CMMDSQ ;GO DO SCC ON THIS DRIVE
5165 040064 032761 000001 003350  BIT #AVB,DRINUS(R1) ;SEE IF DRIVE IS PRESENT AND AVAILABLE
5166 040072 001503  BEQ 20$ ;GET THE NEXT DRIVE IF IT ISN'T
5167
5168 040074 012764 000377 000010 5$: MOV #377,SLTUSE(R4) ;SET ALL RESPONSE SLOTS TO THE PORT
5169 040102 004737 026230  JSR PC,PRTCLR ;GO DO IT
5170 040106 112737 000004 010571  MOVB #4,CRDLIM ;CREDITS START AT 4 FOR NEW LUN
5171 040114 062705 000006  ADD #TSTSTP,R5 ;POINT R5 TO THE ONL COMMAND
5172 040120 004737 021406  JSR PC,CMMDSQ ;GO DO ONLINE ON THIS DRIVE
5173
5174 040124 012764 000377 000010 10$: MOV #377,SLTUSE(R4) ;SET ALL RESPONSE SLOTS TO THE PORT
5175 040132 004737 026230  JSR PC,PRTCLR ;GO DO IT
5176 040136 112737 000004 010571  MOVB #4,CRDLIM ;CREDITS START AT 4 FOR NEW LUN
5177 040144 062705 000006  ADD #TSTSTP,R5 ;POINT R5 TO THE GUS COMMAND
5178 040150 012737 000040 003440  MOV #AVLB,TSTMSK ;ALLOW UNIT AVAILABLE ERRORS
5179 040156 004737 021406  JSR PC,CMMDSQ ;GO DO GUS ON THIS DRIVE
5180 040162 005037 003440  CLR TSTMSK ;ALLOW NO ERRORS
5181 040166 032761 000001 003350  BIT #AVB,DRINUS(R1) ;SEE IF DRIVE IS PRESENT AND AVAILABLE
5182 040174 001442  BEQ 20$ ;GET THE NEXT DRIVE IF IT ISN'T
5183
5184 040176 016403 000022          15$: MOV ROLSAV(R4),R3 ;LET R3 = OLD RESPONSE BUFFER POINTER

```

```

5185 040202 162703 000104      SUB      #DRBSTP,R3          ;ADJUST R3 BACK TO THE LAST RESPONCE
5186 040206      PRINTF  #CONTRV,L$LUN,<B,P.CSVR(R3)>,<B,P.CHVR(R3)>
      040206 005046      CLR      -(SP)
      040210 156316 000051      BISB    P.CHVR(R3),(SP)
      040214 005046      CLR      -(SP)
      040216 156316 000050      BISB    P.CSVR(R3),(SP)
      040222 013746 002074      MOV     L$LUN,-(SP)
      040226 012746 020532      MOV     #CONTRV,-(SP)
      040232 012746 000004      MOV     #4,-(SP)
      040236 010600      MOV     SP,R0
      040240 104417      TRAP    C$PNTF
      040242 062706 000012      ADD     #12,SP
5187 040246      PRINTF  #UNITRV,<B,P.USVR(R3)>,<B,P.UHVR(R3)>
      040246 005046      CLR      -(SP)
      040250 156316 000053      BISB    P.UHVR(R3),(SP)
      040254 005046      CLR      -(SP)
      040256 156316 000052      BISB    P.USVR(R3),(SP)
      040262 012746 020662      MOV     #UNITRV,-(SP)
      040266 012746 000003      MOV     #3,-(SP)
      040272 010600      MOV     SP,R0
      040274 104417      TRAP    C$PNTF
      040276 062706 000010      ADD     #10,SP
5188
5189 040302 022701 000006      20$:   CMP     #6.,R1          ;HAVE WE DONE THEM ALL ?
5190 040306 001411      BEQ     EXTINT          ;GET OUT
5191 040310 062701 000002      ADD     #UNTSTP,R1      ;GET NEXT UNIT
5192 040314 062704 000172      ADD     #LUNSTP,R4      ;SET UP THE NEXT LUN BLOCK
5193 040320 005237 002074      INC     L$LUN          ;GET NEXT UNIT
5194 040324      BREAK
      040324 104422      TRAP    C$BRK
5195 040326 000137 037754      JMP     1$             ;GO DO THE NEXT ONE
5196
5197 040332      EXTINT: EXIT  INIT
      040332 104432      TRAP    C$EXIT
      040334 000032      .WORD  L10010-.
5198
5199      ;INIT TEST TABLE
5200 040336      INITIT:: .BYTE  INT      ;INITIALIZATION TABLE
      040337 000      .BYTE  NULPAT
      040340 000000      .WORD  0
      040342 000001      .WORD  1
      040344 230      .BYTE  SCC      ;SET CONTROLLER CHARACTERISTICS TABLE
      040345 000      .BYTE  NULPAT
      040346 000000      .WORD  0
      040350 000001      .WORD  1
      040352 140      .BYTE  ONL      ;ONLINE TABLE
      040353 000      .BYTE  NULPAT
      040354 000000      .WORD  0
      040356 000001      .WORD  1
      040360 220      .BYTE  GUS      ;GET UNIT STATUS TABLE
      040361 000      .BYTE  NULPAT
      040362 000000      .WORD  0
      040364 000001      .WORD  1
5216      .EVEN
5217
5218 040366      ENDINIT
      040366      L10010:

```

040366 104411

TRAP C\$INIT

5220 040370
040370
5221 040370
040370
040370 104461

BGNAUTO
L\$AUTO::
ENDAUTO
L10011: TRAP C\$AUTO


```

5223
5224
5225
5226
5227
5228 040372
      040372
5229
5236 040372 032737 000002 003516
5237 040400 001005
5238 040402 005037 177546
5239 040406
      040406 012700 000100
      040412 104436
5240 040414
      040414 104424
5241 040416 032737 000400 003516
5242 040424 001003
5243 040426 042737 000100 003516
5244 040434
      040434 104432
      040436 000002
5245
5257
5258
5259
5260 040440
      040440
      040440 104412

      .SBTTL CLEANUP CODING SECTION
      ; THE CLEANUP CODING SECTION CONTAINS THE CODING THAT IS PERFORMED
      ; AFTER THE HARDWARE TESTS HAVE BEEN PERFORMED.
      ;--

      BGNCLN
L$CLEAN::

      BIT #NCLKFL,PCFLAG ;WAS A CLOCK PRESENT ?
      BNE 5$ ;NO CLOCK, DO REPORT
      CLR KWCSR
      CLRVEC #100
      MOV #100,R0
      TRAP C$CVEC
5$:
      DORPT
      TRAP C$DRPT
      BIT #DROPT,PCFLAG
      BNE EXTCLN
      BIC #NOMDTB,PCFLAG
EXTCLN:
      EXIT CLN
      TRAP C$EXIT
      .WORD L10012-.

      .EVEN
      ENDCLN
L10012:
      TRAP C$CLEAN

```

```

5262          .SBTTL  DROP UNIT SECTION
5263
5264          ;++
5265          ; THE DROP-UNIT SECTION CONTAINS THE CODING THAT CAUSES A DEVICE
5266          ; TO NO LONGER BE TESTED.
5267          ;--
5268
5269 040442     DROPUN::
5270 040442     PUSH    <R1>                ;SAVE R1
                    MOV    R1,-(SP)        ;;PUSH R1 ON STACK
                    MOV    R0,R1          ;POINT R1 TO THE DRINUS TABLE
                    ROL    R1              ;MULTIPLY BY 2
5271 040444     010146     INC    DROPPD(R4)    ;INC DROPPED FLAG FOR THIS UNIT
5272 040446     006101     BIS    #DROPI,PCFLAG ;SET THE UNIT DROP FLAG
5273 040450     005264     000104     PUSH    <R0>                ;SAVE R0
5274 040454     052737     000400     003516   MOV    R0,-(SP)        ;;PUSH R0 ON STACK
5275 040462     010046     DORPT   C$DRPT          ;GO PRINT UNIT STATS
5276 040464     104424     TRAP   C$DRPT
5277 040466     012600     POP    <R0>                ;RESTORE R0
                    MOV    (SP)+,R0      ;;POP STACK INTO R0
5278 040470     042737     000400     003516   BIC    #DROPI,PCFLAG    ;CLEAR THE DROP FLAG
5279 040476     105737     002230     TSTB  NOCLR             ;DO WE WANT TO CLEAR STATS ON ERROR ?
5280 040502     001415     BEQ    3$                ;NO, DON'T CLEAR THE STATS
5281 040504     010246     PUSH    <R2,R3>
                    MOV    R2,-(SP)      ;;PUSH R2 ON STACK
                    MOV    R3,-(SP)      ;;PUSH R3 ON STACK
5282 040510     012702     000040     MOV    #S1READ,R2      ;STARTING ADDRESS OF STATS IN R2
5283 040514     012703     000130     MOV    #TBLTOP,R3      ;END ADDRESS OF STATS IN R3
5284 040520     060402     ADD    R4,R2            ;ADD THE LUN BLOCK ADDRESS TO R2
5285 040522     060403     ADD    R4,R3            ;ADD THE LUN BLOCK ADDRESS TO R3
5286 040524     005022     2$:   CLR    (R2)+            ;CLEAR THE LOCATION
5287 040526     020203     CMP    R2,R3            ;ARE WE AT THE END OF THE STATS
5288 040530     001375     BNE    2$                ;NO, KEEP CLEARING
5289 040532     012603     POP    <R3,R2>
                    MOV    (SP)+,R3      ;;POP STACK INTO R3
                    MOV    (SP)+,R2      ;;POP STACK INTO R2
5290 040536     042761     000001     003350   3$:   BIC    #AVB,DRINUS(R1) ;CLEAR THE AVB BIT IN DRIVE IN USE TABLE
5291 040544     032761     000004     003350   BIT    #EOT,DRINUS(R1) ;IS THE DRIVE AT EOT ?
5292 040552     001404     BEQ    5$                ;BRANCH IF NOT
5293 040554     042761     000004     003350   BIC    #EOT,DRINUS(R1) ;CLEAR THE EOT BIT IN DRIVE IN USE TABLE
5294 040562     000402     BR     10$               ;GET OUT
5295 040564     005337     003524     5$:   DEC    UDROP            ;SUBTRACT 1 TO DROPPED FLAG
5296 040570     052761     000010     003350   10$:  BIS    #DROP,DRINUS(R1) ;SET DRIVE IN USE TABLE TO DROPPED
5297 040576     005264     000032     INC    UNDROP(R4)      ;ADD 1 TO THE UNIT DROP COUNT
5298 040602     022764     000012     000032   CMP    #10.,UNDROP(R4) ;DO WE HAVE 10. ERRORS ?
5299 040610     001004     BNE    15$               ;NO, GET OUT
5300 040612     052761     000020     003350   BIS    #FAIL,DRINUS(R1) ;SET THE DRIVE TO FAIL
5301 040620     104451     DODU   R0
                    TRAP   C$DODU
5302 040622     005037     003406     15$:  CLR    RESPON          ;CLEAR THE RESPONSE STATUS
5303 040626     012601     POP    <R1>                ;RESTORE R1
                    MOV    (SP)+,R1      ;;POP STACK INTO R1
5304 040630     012727     000024     DELAY 20.              ;DELAY FOR AWHILE
                    MOV    #20.,(PC)+
                    .WORD  0
                    MOV    L$DLY,(PC)+
                    .WORD  0

```

040644	005367	177772		DEC	-6(PC)	
040650	001375			BNE	.-4	
040652	005367	177756		DEC	-22(PC)	
040656	001367			BNE	.-20	
5305	040660	010174	000000	MOV	R1,@TKIP(R4)	;FLUSH THE DRIVE
5306	040664	012764	000377 000010	MOV	#377,SLTUSE(R4)	;SET ALL RESPONCE SLOTS TO PORT
5307	040672	004737	026230	JSR	PC,PRTCLR	;GO CLEAR THE PORT
5308	040676	000207		RTS	PC	;RETURN
5309						
5310						
5311	040700			BGNDU		
	040700			L\$DU::		
5312	040700			EXIT	DU	
	040700	000167		.WORD	J\$JMP	
	040702	000000		.WORD	L10013-2-	
5313						
5325						
5326				.EVEN		
5327						
5328	040704			ENDDU		
	040704			L10013:		
	040704	104453		TRAP	C\$DU	

ADD UNIT SECTION

```

5330          .SBTTL  ADD UNIT SECTION
5331
5332          ;**
5333          ; THE ADD-UNIT SECTION CONTAINS ANY CODE THE PROGRAMMER WISHES
5334          ; TO BE EXECUTED IN CONJUNCTION WITH THE ADDING OF A UNIT BACK
5335          ; TO THE TEST CYCLE.
5336          ;--
5337
5338 040706          BGNAU
5339 040706          L$AU::
5345
5346 040706          EXIT      AU
5346 040706 000167    .WORD    J$JMP
5346 040710 000000    .WORD    L10014-2-.
5347
5359
5360          .EVEN
5361
5362 040712          ENDAU
5362 040712          L10014:
5362 040712 104452    TRAP     C$AU
5363
5364 040714          ENDMOD
5365

```

5368
 5369
 5380
 5381
 5417
 5418
 5419
 5420
 5421
 5422
 5423
 5424
 5425
 5426
 5433
 5439

.TITLE HARDWARE TESTS
 .SBTTL TEST 1: Basic Function Test
 BGNMOD

```

; **
; This test will execute a subset of the legal commands on the unit
; under test. It serves as a quick verify test to ascertain that the
; unit can move tape and write/read predictably, without error. The
; subset of legal commands will be issued in a coherent manner.
; --
  
```

5440 040714
 040714
 5441 040714 105737 002234
 5442 040720 001414
 5443 040722
 040722 013746 002114
 040726 012746 021001
 040732 012746 000002
 040736 010600
 040740 104417
 040742 062706 000006
 5444 040746 000137 042624
 5445
 5446 040752 005737 003524
 5447 040756 001014
 5448 040760
 040760 013746 002114
 040764 012746 021001
 040770 012746 000002
 040774 010600
 040776 104417
 041000 062706 000006
 5449 041004 000137 042624
 5450
 5451 041010 105737 002212
 5452 041014 001421
 5453 041016
 041016 005046
 041020 153716 002215
 041024 005046
 041026 153716 002214
 041032 005046
 041034 153716 002213
 041040 012746 020044
 041044 012746 000004
 041050 010600
 041052 104417
 041054 062706 000012
 5454
 5455 041060 004737 033456
 5456 041064 012737 000100 003440

```

T1::      BGNTST
          TSTB   T3ONLY           ;CHECK THE TEST 3 ONLY FLAG
          BEQ    START1          ;BRANCH IF IT IS CLEAR
          PRINTF #BYPASS,L$TEST  ;PRINT THE TEST BYPASSED MESSAGE
          MOV    L$TEST,-(SP)
          MOV    #BYPASS,-(SP)
          MOV    #2,-(SP)
          MOV    SP,R0
          TRAP  C$PNTF
          ADD    #6,SP
          JMP    T1EXIT          ;JUMP IF IT IS NOT CLEAR

START1:   TST    UDROP           ;HAVE ALL UNITS BEEN DROPPED ?
          BNE    5$              ;NO, CONTINUE
          PRINTF #BYPASS,L$TEST  ;PRINT THE TEST BYPASSED MESSAGE
          MOV    L$TEST,-(SP)
          MOV    #BYPASS,-(SP)
          MOV    #2,-(SP)
          MOV    SP,R0
          TRAP  C$PNTF
          ADD    #6,SP
          JMP    T1EXIT          ;GET OUT IF NONE LEFT TO TEST

5$:       TSTB   CLOCK           ;IS THE CLOCK ENABLED
          BEQ    GO1             ;NO, THEN CAN'T PRINT TIME
          PRINTF #TIME,<B,HOURS>,<B,MINUTE>,<B,SECOND>,
          CLR    -(SP)
          BISB  SECOND,(SP)
          CLR    -(SP)
          BISB  MINUTE,(SP)
          CLR    -(SP)
          BISB  HOURS,(SP)
          MOV   #TIME,-(SP)
          MOV   #4,-(SP)
          MOV   SP,R0
          TRAP  C$PNTF
          ADD   #12,SP

GO1:     JSR    PC,CLREOT        ;MAKE SURE EOT STATUS IS CLEAR
          MOV   #ONLB,TSTMSK    ;ALLOW ALREADY ONLINE STATUS
  
```

```

5457
5458 041072 012705 042630      MOV      #T1ONL,R5      ;SET UP TO DO AN ONLINE
5459 041076 004737 021240      JSR      PC,SCHED      ;GO ISSUE THE COMMAND
5460 041102 005737 003524      TST      UDROP          ;HAVE ALL UNITS BEEN DROPPED ?
5461 041106 001002                BNE      5$             ;NO, CONTINUE
5462 041110 000137 042624      JMP      T1EXIT        ;GET OUT IF NONE LEFT TO TEST
5463
5464 041114 005037 003440      5$:     CLR      TSTMSK    ;ALLOW NO ERRORS
5465 041120 012705 042636      MOV      #T1REW,R5    ;SET UP TO DO A REWIND
5466 041124 004737 021240      JSR      PC,SCHED      ;GO ISSUE THE COMMAND
5467 041130 005737 003524      TST      UDROP          ;HAVE ALL UNITS BEEN DROPPED ?
5468 041134 001002                BNE      10$           ;NO, CONTINUE
5469 041136 000137 042624      JMP      T1EXIT        ;GET OUT IF NONE LEFT TO TEST
5470
5471 041142 012705 042644      10$:    MOV      #T1LEOT,R5   ;SET UP TO DO 2 TAPE MARK COMMANDS
5472 041146 004737 021240      JSR      PC,SCHED      ;GO ISSUE THE COMMAND
5473 041152 005737 003524      TST      UDROP          ;HAVE ALL UNITS BEEN DROPPED ?
5474 041156 001002                BNE      15$           ;NO, CONTINUE
5475 041160 000137 042624      JMP      T1EXIT        ;GET OUT IF NONE LEFT TO TEST
5476
5477 041164 012705 042666      15$:    MOV      #T1SKR,R5   ;SET UP TO SKIP REVERSE 2 TAPE MARKS
5478 041170 004737 021240      JSR      PC,SCHED      ;GO ISSUE THE COMMAND
5479 041174 005737 003524      TST      UDROP          ;HAVE ALL UNITS BEEN DROPPED ?
5480 041200 001002                BNE      20$           ;NO, CONTINUE
5481 041202 000137 042624      JMP      T1EXIT        ;GET OUT IF NONE LEFT TO TEST
5482
5483 041206 052737 000001 003440 20$:    BIS      #LEDB,TSTMSK  ;SET UP TO ALLOW LEOT DETECTED
5484 041214 012705 042776      MOV      #T1SKD,R5    ;SET UP TO DO A SPACE TO LEOT
5485 041220 004737 021240      JSR      PC,SCHED      ;GO ISSUE THE COMMAND
5486 041224 042737 000001 003440  BIC      #LEDB,TSTMSK  ;DISALLOW LEOT DETECTED
5487 041232 005737 003524      TST      UDROP          ;HAVE ALL UNITS BEEN DROPPED ?
5488 041236 001002                BNE      25$           ;NO, CONTINUE
5489 041240 000137 042624      JMP      T1EXIT        ;GET OUT IF NONE LEFT TO TEST
5490
5491 041244 012705 042636      25$:    MOV      #T1REW,R5    ;SET UP TO DO A REWIND
5492 041250 004737 021240      JSR      PC,SCHED      ;GO ISSUE THE COMMAND
5493 041254 005737 003524      TST      UDROP          ;HAVE ALL UNITS BEEN DROPPED ?
5494 041260 001002                BNE      30$           ;NO, CONTINUE
5495 041262 000137 042624      JMP      T1EXIT        ;GET OUT IF NONE LEFT TO TEST
5496
5497 041266 012705 043004      30$:    MOV      #T1WR1,R5    ;WRITE 99, 512 BYTE RECORDS
5498 041272 004737 033556      JSR      PC,SDSTUP     ;RESET THE RANDOM SEEDS
5499 041276 004737 021240      JSR      PC,SCHED      ;GO ISSUE THE COMMAND
5500 041302 005737 003524      TST      UDROP          ;HAVE ALL UNITS BEEN DROPPED ?
5501 041306 001002                BNE      35$           ;NO, CONTINUE
5502 041310 000137 042624      JMP      T1EXIT        ;GET OUT IF NONE LEFT TO TEST
5503
5504 041314 012705 042652      35$:    MOV      #T1WTM,R5    ;SET UP TO WRITE A TAPE MARK
5505 041320 004737 021240      JSR      PC,SCHED      ;GO ISSUE THE COMMAND
5506 041324 005737 003524      TST      UDROP          ;HAVE ALL UNITS BEEN DROPPED ?
5507 041330 001002                BNE      40$           ;NO, CONTINUE
5508 041332 000137 042624      JMP      T1EXIT        ;GET OUT IF NONE LEFT TO TEST
5509
5510 041336 012705 043012      40$:    MOV      #T1WR2,R5    ;WRITE 84, 525 BYTE RECORDS
5511 041342 004737 033556      JSR      PC,SDSTUP     ;RESET THE RANDOM SEEDS
5512 041346 004737 021240      JSR      PC,SCHED      ;GO ISSUE THE COMMAND
5513 041352 005737 003524      TST      UDROP          ;HAVE ALL UNITS BEEN DROPPED ?

```

5514	041356	001002		BNE	45\$;NO, CONTINUE
5515	041360	000137	042624	JMP	T1EXIT		;GET OUT IF NONE LEFT TO TEST
5516							
5517	041364	012705	042652	45\$:	MOV	#T1WTM,R5	;SET UP TO WRITE A TAPE MARK
5518	041370	004737	021240		JSR	PC,SCHED	;GO ISSUE THE COMMAND
5519	041374	005737	003524		TST	UDROP	;HAVE ALL UNITS BEEN DROPPED ?
5520	041400	001002			BNE	50\$;NO, CONTINUE
5521	041402	000137	042624		JMP	T1EXIT	;GET OUT IF NONE LEFT TO TEST
5522							
5523	041406	012705	043020	50\$:	MOV	#T1WR3,R5	;WRITE 69, 1038 BYTE RECORDS
5524	041412	004737	033556		JSR	PC,SDSTUP	;RESET THE RANDOM SEEDS
5525	041416	004737	021240		JSR	PC,SCHED	;GO ISSUE THE COMMAND
5526	041422	005737	003524		TST	UDROP	;HAVE ALL UNITS BEEN DROPPED ?
5527	041426	001002			BNE	55\$;NO, CONTINUE
5528	041430	000137	042624		JMP	T1EXIT	;GET OUT IF NONE LEFT TO TEST
5529							
5530	041434	012705	042652	55\$:	MOV	#T1WTM,R5	;SET UP TO WRITE A TAPE MARK
5531	041440	004737	021240		JSR	PC,SCHED	;GO ISSUE THE COMMAND
5532	041444	005737	003524		TST	UDROP	;HAVE ALL UNITS BEEN DROPPED ?
5533	041450	001002			BNE	60\$;NO, CONTINUE
5534	041452	000137	042624		JMP	T1EXIT	;GET OUT IF NONE LEFT TO TEST
5535							
5536	041456	012705	043026	60\$:	MOV	#T1WR4,R5	;WRITE 54, 1551 BYTE RECORDS
5537	041462	004737	033556		JSR	PC,SDSTUP	;RESET THE RANDOM SEEDS
5538	041466	004737	021240		JSR	PC,SCHED	;GO ISSUE THE COMMAND
5539	041472	005737	003524		TST	UDROP	;HAVE ALL UNITS BEEN DROPPED ?
5540	041476	001002			BNE	65\$;NO, CONTINUE
5541	041500	000137	042624		JMP	T1EXIT	;GET OUT IF NONE LEFT TO TEST
5542							
5543	041504	012705	042652	65\$:	MOV	#T1WTM,R5	;SET UP TO WRITE A TAPE MARK
5544	041510	004737	021240		JSR	PC,SCHED	;GO ISSUE THE COMMAND
5545	041514	005737	003524		TST	UDROP	;HAVE ALL UNITS BEEN DROPPED ?
5546	041520	001002			BNE	70\$;NO, CONTINUE
5547	041522	000137	042624		JMP	T1EXIT	;GET OUT IF NONE LEFT TO TEST
5548							
5549	041526	012705	043034	70\$:	MOV	#T1WR5,R5	;WRITE 39, 2064 BYTE RECORDS
5550	041532	004737	033556		JSR	PC,SDSTUP	;RESET THE RANDOM SEEDS
5551	041536	004737	021240		JSR	PC,SCHED	;GO ISSUE THE COMMAND
5552	041542	005737	003524		TST	UDROP	;HAVE ALL UNITS BEEN DROPPED ?
5553	041546	001002			BNE	75\$;NO, CONTINUE
5554	041550	000137	042624		JMP	T1EXIT	;GET OUT IF NONE LEFT TO TEST
5555							
5556	041554	012705	042652	75\$:	MOV	#T1WTM,R5	;SET UP TO WRITE A TAPE MARK
5557	041560	004737	021240		JSR	PC,SCHED	;GO ISSUE THE COMMAND
5558	041564	005737	003524		TST	UDROP	;HAVE ALL UNITS BEEN DROPPED ?
5559	041570	001002			BNE	80\$;NO, CONTINUE
5560	041572	000137	042624		JMP	T1EXIT	;GET OUT IF NONE LEFT TO TEST
5561							
5562	041576	012705	043042	80\$:	MOV	#T1WR6,R5	;WRITE 24, 2577 BYTE RECORDS
5563	041602	004737	033556		JSR	PC,SDSTUP	;RESET THE RANDOM SEEDS
5564	041606	004737	021240		JSR	PC,SCHED	;GO ISSUE THE COMMAND
5565	041612	005737	003524		TST	UDROP	;HAVE ALL UNITS BEEN DROPPED ?
5566	041616	001002			BNE	85\$;NO, CONTINUE
5567	041620	000137	042624		JMP	T1EXIT	;GET OUT IF NONE LEFT TO TEST
5568							
5569	041624	012705	042644	85\$:	MOV	#T1LEOT,R5	;SET UP TO WRITE LOGICAL END OF TAPE
5570	041630	004737	021240		JSR	PC,SCHED	;GO ISSUE THE COMMAND

5571	041634	005737	003524	TST	UDROP	;HAVE ALL UNITS BEEN DROPPED ?
5572	041640	001002		BNE	90\$;NO, CONTINUE
5573	041642	000137	042624	JMP	T1EXIT	;GET OUT IF NONE LEFT TO TEST
5574						
5575	041646	012705	042636	90\$: MOV	#T1REW,R5	;SET UP TO REWIND
5576	041652	004737	021240	JSR	PC,SCHED	;GO ISSUE THE COMMAND
5577	041656	005737	003524	TST	UDROP	;HAVE ALL UNITS BEEN DROPPED ?
5578	041662	001002		BNE	95\$;NO, CONTINUE
5579	041664	000137	042624	JMP	T1EXIT	;GET OUT IF NONE LEFT TO TEST
5580						
5581	041670	012705	043050	95\$: MOV	#T1RD1,R5	;SET UP TO READ 100 RECORDS
5582	041674	004737	033556	JSR	PC,SDSTUP	;RESET THE RANDOM SEEDS
5583	041700	004737	021240	JSR	PC,SCHED	;GO ISSUE THE COMMAND
5584	041704	005737	003524	TST	UDROP	;HAVE ALL UNITS BEEN DROPPED ?
5585	041710	001002		BNE	100\$;NO, CONTINUE
5586	041712	000137	042624	JMP	T1EXIT	;GET OUT IF NONE LEFT TO TEST
5587						
5588	041716	012705	042660	100\$: MOV	#T1SKP,R5	;SET UP TO SKIP A TAPE MARK
5589	041722	004737	021240	JSR	PC,SCHED	;GO ISSUE THE COMMAND
5590	041726	005737	003524	TST	UDROP	;HAVE ALL UNITS BEEN DROPPED ?
5591	041732	001002		BNE	105\$;NO, CONTINUE
5592	041734	000137	042624	JMP	T1EXIT	;GET OUT IF NONE LEFT TO TEST
5593						
5594	041740	012705	042674	105\$: MOV	#T1SPC1,R5	;SET UP TO SPACE 84 RECORDS
5595	041744	004737	021240	JSR	PC,SCHED	;GO ISSUE THE COMMAND
5596	041750	005737	003524	TST	UDROP	;HAVE ALL UNITS BEEN DROPPED ?
5597	041754	001002		BNE	110\$;NO, CONTINUE
5598	041756	000137	042624	JMP	T1EXIT	;GET OUT IF NONE LEFT TO TEST
5599						
5600	041762	012705	042660	110\$: MOV	#T1SKP,R5	;SET UP TO SKIP A TAPE MARK
5601	041766	004737	021240	JSR	PC,SCHED	;GO ISSUE THE COMMAND
5602	041772	005737	003524	TST	UDROP	;HAVE ALL UNITS BEEN DROPPED ?
5603	041776	001002		BNE	115\$;NO, CONTINUE
5604	042000	000137	042624	JMP	T1EXIT	;GET OUT IF NONE LEFT TO TEST
5605						
5606	042004	012705	042702	115\$: MOV	#T1SPC2,R5	;SET UP TO SPACE 69 RECORDS
5607	042010	004737	021240	JSR	PC,SCHED	;GO ISSUE THE COMMAND
5608	042014	005737	003524	TST	UDROP	;HAVE ALL UNITS BEEN DROPPED ?
5609	042020	001002		BNE	120\$;NO, CONTINUE
5610	042022	000137	042624	JMP	T1EXIT	;GET OUT IF NONE LEFT TO TEST
5611						
5612	042026	012705	042716	120\$: MOV	#T1SP01,R5	;SET UP TO SPACE 56 OBJECTS
5613	042032	004737	021240	JSR	PC,SCHED	;GO ISSUE THE COMMAND
5614	042036	005737	003524	TST	UDROP	;HAVE ALL UNITS BEEN DROPPED ?
5615	042042	001002		BNE	125\$;NO, CONTINUE
5616	042044	000137	042624	JMP	T1EXIT	;GET OUT IF NONE LEFT TO TEST
5617						
5618	042050	012705	043100	125\$: MOV	#T1RD5,R5	;SET UP TO READ 39 RECORDS
5619	042054	004737	033556	JSR	PC,SDSTUP	;RESET THE RANDOM SEEDS
5620	042060	004737	021240	JSR	PC,SCHED	;GO ISSUE THE COMMAND
5621	042064	005737	003524	TST	UDROP	;HAVE ALL UNITS BEEN DROPPED ?
5622	042070	001002		BNE	130\$;NO, CONTINUE
5623	042072	000137	042624	JMP	T1EXIT	;GET OUT IF NONE LEFT TO TEST
5624						
5625	042076	012705	042724	130\$: MOV	#T1SKR1,R5	;SET UP TO SKIP REVERSE 4 TAPE MARKS
5626	042102	004737	021240	JSR	PC,SCHED	;GO ISSUE THE COMMAND
5627	042106	005737	003524	TST	UDROP	;HAVE ALL UNITS BEEN DROPPED ?

5628	042112	001002		BNE	135\$;NO, CONTINUE
5629	042114	000137	042624	JMP	T1EXIT		;GET OUT IF NONE LEFT TO TEST
5630							
5631	042120	012705	042660	135\$:	MOV	#T1SKP,R5	;SET UP TO SKIP TAPE MARK FORWARD
5632	042124	004737	021240		JSR	PC,SCHED	;GO ISSUE THE COMMAND
5633	042130	005737	003524		TST	UDROP	;HAVE ALL UNITS BEEN DROPPED ?
5634	042134	001002		BNE	140\$;NO, CONTINUE
5635	042136	000137	042624	JMP	T1EXIT		;GET OUT IF NONE LEFT TO TEST
5636							
5637	042142	012705	043056	140\$:	MOV	#T1RD2,R5	;SET UP TO READ 84 RECORDS
5638	042146	004737	033556		JSR	PC,SDSTUP	;RESET THE RANDOM SEEDS
5639	042152	004737	021240		JSR	PC,SCHED	;GO ISSUE THE COMMAND
5640	042156	005737	003524		TST	UDROP	;HAVE ALL UNITS BEEN DROPPED ?
5641	042162	001002		BNE	145\$;NO, CONTINUE
5642	042164	000137	042624	JMP	T1EXIT		;GET OUT IF NONE LEFT TO TEST
5643							
5644	042170	012705	042732	145\$:	MOV	#T1SP02,R5	;SET UP TO SPACE 71 OBJECTS
5645	042174	004737	021240		JSR	PC,SCHED	;GO ISSUE THE COMMAND
5646	042200	005737	003524		TST	UDROP	;HAVE ALL UNITS BEEN DROPPED ?
5647	042204	001002		BNE	150\$;NO, CONTINUE
5648	042206	000137	042624	JMP	T1EXIT		;GET OUT IF NONE LEFT TO TEST
5649							
5650	042212	012705	043072	150\$:	MOV	#T1RD4,R5	;SET UP TO READ 54 RECORDS
5651	042216	004737	033556		JSR	PC,SDSTUP	;RESET THE RANDOM SEEDS
5652	042222	004737	021240		JSR	PC,SCHED	;GO ISSUE THE COMMAND
5653	042226	005737	003524		TST	UDROP	;HAVE ALL UNITS BEEN DROPPED ?
5654	042232	001002		BNE	155\$;NO, CONTINUE
5655	042234	000137	042624	JMP	T1EXIT		;GET OUT IF NONE LEFT TO TEST
5656							
5657	042240	012705	042740	155\$:	MOV	#T1SP03,R5	;SET UP TO SPACE 66 OBJECTS
5658	042244	004737	021240		JSR	PC,SCHED	;GO ISSUE THE COMMAND
5659	042250	005737	003524		TST	UDROP	;HAVE ALL UNITS BEEN DROPPED ?
5660	042254	001002		BNE	160\$;NO, CONTINUE
5661	042256	000137	042624	JMP	T1EXIT		;GET OUT IF NONE LEFT TO TEST
5662							
5663	042262	012705	042746	160\$:	MOV	#T1SPR1,R5	;SET UP TO SPACE REVERSE 375 OBJECTS
5664	042266	004737	021240		JSR	PC,SCHED	;GO ISSUE THE COMMAND
5665	042272	005737	003524		TST	UDROP	;HAVE ALL UNITS BEEN DROPPED ?
5666	042276	001002		BNE	165\$;NO, CONTINUE
5667	042300	000137	042624	JMP	T1EXIT		;GET OUT IF NONE LEFT TO TEST
5668							
5669	042304	012705	042754	165\$:	MOV	#T1SKP1,R5	;SET UP TO SKIP FORWARD 4 TAPE MARKS
5670	042310	004737	021240		JSR	PC,SCHED	;GO ISSUE THE COMMAND
5671	042314	005737	003524		TST	UDROP	;HAVE ALL UNITS BEEN DROPPED ?
5672	042320	001002		BNE	170\$;NO, CONTINUE
5673	042322	000137	042624	JMP	T1EXIT		;GET OUT IF NONE LEFT TO TEST
5674							
5675	042326	012705	042710	170\$:	MOV	#T1SPC3,R5	;SET UP TO SPACE 39 RECORDS
5676	042332	004737	021240		JSR	PC,SCHED	;GO ISSUE THE COMMAND
5677	042336	005737	003524		TST	UDROP	;HAVE ALL UNITS BEEN DROPPED ?
5678	042342	001002		BNE	175\$;NO, CONTINUE
5679	042344	000137	042624	JMP	T1EXIT		;GET OUT IF NONE LEFT TO TEST
5680							
5681	042350	012705	042660	175\$:	MOV	#T1SKP,R5	;SET UP TO SKIP A TAPE MARK
5682	042354	004737	021240		JSR	PC,SCHED	;GO ISSUE THE COMMAND
5683	042360	005737	003524		TST	UDROP	;HAVE ALL UNITS BEEN DROPPED ?
5684	042364	001002		BNE	180\$;NO, CONTINUE

```

5685 042366 000137 042624      JMP      T1EXIT      ;GET OUT IF NONE LEFT TO TEST
5686
5687 042372 012705 043106      180$:   MOV      #T1RD6,R5      ;SET UP TO READ 824 RECORDS
5688 042376 004737 033556      JSR      PC,SDSTUP    ;RESET THE RANDOM SEEDS
5689 042402 004737 021240      JSR      PC,SCHED    ;GO ISSUE THE COMMAND
5690 042406 005737 003524      TST      UDROP      ;HAVE ALL UNITS BEEN DROPPED ?
5691 042412 001002      BNE      185$      ;NO, CONTINUE
5692 042414 000137 042624      JMP      T1EXIT      ;GET OUT IF NONE LEFT TO TEST
5693
5694 042420 012705 042762      185$:   MOV      #T1SKP2,R5    ;SET UP TO SKIP 2 TAPE MARKS
5695 042424 004737 021240      JSR      PC,SCHED    ;GO ISSUE THE COMMAND
5696 042430 005737 003524      TST      UDROP      ;HAVE ALL UNITS BEEN DROPPED ?
5697 042434 001002      BNE      190$      ;NO, CONTINUE
5698 042436 000137 042624      JMP      T1EXIT      ;GET OUT IF NONE LEFT TO TEST
5699
5700 042442 012705 042770      190$:   MOV      #T1SPR2,R5   ;SET UP TO SPACE REVERSE 192 OBJECTS
5701 042446 004737 021240      JSR      PC,SCHED    ;GO ISSUE THE COMMAND
5702 042452 005737 003524      TST      UDROP      ;HAVE ALL UNITS BEEN DROPPED ?
5703 042456 001002      BNE      195$      ;NO, CONTINUE
5704 042460 000137 042624      JMP      T1EXIT      ;GET OUT IF NONE LEFT TO TEST
5705
5706 042464 012705 042660      195$:   MOV      #T1SKP,R5    ;SET UP TO SKIP A TAPE MARK
5707 042470 004737 021240      JSR      PC,SCHED    ;GO ISSUE THE COMMAND
5708 042474 005737 003524      TST      UDROP      ;HAVE ALL UNITS BEEN DROPPED ?
5709 042500 001002      BNE      200$      ;NO, CONTINUE
5710 042502 000137 042624      JMP      T1EXIT      ;GET OUT IF NONE LEFT TO TEST
5711
5712 042506 012705 043064      200$:   MOV      #T1RD3,R5   ;SET UP TO READ 69 RECORDS
5713 042512 004737 033556      JSR      PC,SDSTUP    ;RESET THE RANDOM SEEDS
5714 042516 004737 021240      JSR      PC,SCHED    ;GO ISSUE THE COMMAND
5715 042522 005737 003524      TST      UDROP      ;HAVE ALL UNITS BEEN DROPPED ?
5716 042526 001002      BNE      205$      ;NO, CONTINUE
5717 042530 000137 042624      JMP      T1EXIT      ;GET OUT IF NONE LEFT TO TEST
5718
5719 042534 012705 042636      205$:   MOV      #T1REW,R5   ;SET UP TO REWIND
5720 042540 004737 021240      JSR      PC,SCHED    ;GO ISSUE THE COMMAND
5721 042544 005737 003524      TST      UDROP      ;HAVE ALL UNITS BEEN DROPPED ?
5722 042550 001002      BNE      210$      ;NO, CONTINUE
5723 042552 000137 042624      JMP      T1EXIT      ;GET OUT IF NONE LEFT TO TEST
5724
5725 042556 052737 000001 003440 210$:   BIS      #LEDB,TSTMSK ;SET UP TO ALLOW LEOT DETECTED
5726 042564 012705 042776      MOV      #T1SKD,R5   ;SET UP TO SKIP TO LEOT
5727 042570 004737 021240      JSR      PC,SCHED    ;GO ISSUE THE COMMAND
5728 042574 042737 000001 003440  BIC      #LEDB,TSTMSK ;DISALLOW LEOT DETECTED
5729 042602 005737 003524      TST      UDROP      ;HAVE ALL UNITS BEEN DROPPED ?
5730 042606 001002      BNE      215$      ;NO, CONTINUE
5731 042610 000137 042624      JMP      T1EXIT      ;GET OUT IF NONE LEFT TO TEST
5732
5733 042614 012705 042636      215$:   MOV      #T1REW,R5   ;SET UP TO REWIND
5734 042620 004737 021240      JSR      PC,SCHED    ;GO ISSUE THE COMMAND
5735
5736 042624      T1EXIT:  EXIT      TST
          042624 104432      TRAP      C$EXIT
          042626 000266      .WORD     L10015-.

```

5738					
5739	042630	140	T1ONL:	.BYTE ONL	; ONLINE COMMAND
5740	042631	000		.BYTE NULPAT	; NO DATA NEEDED
5741	042632	000000		.WORD 0	; NO ITEM COUNT
5742	042634	000001		.WORD 1	; DO IT ONE TIME
5743					
5744	042636	160	T1REW:	.BYTE REW	; REWIND COMMAND
5745	042637	000		.BYTE NULPAT	; NO DATA NEEDED
5746	042640	000000		.WORD 0	; NO ITEM COUNT
5747	042642	000001		.WORD 1	; DO IT ONE TIME
5748					
5749	042644	100	T1LEOT:	.BYTE WTM	; WRITE TAPE MARK
5750	042645	000		.BYTE NULPAT	; NO DATA NEEDED
5751	042646	000000		.WORD 0	; NO ITEM COUNT
5752	042650	000002		.WORD 2	; DO IT TWICE
5753					
5754	042652	100	T1WTM:	.BYTE WTM	; WRITE TAPE MARK
5755	042653	000		.BYTE NULPAT	; NO DATA NEEDED
5756	042654	000000		.WORD 0	; NO ITEM COUNT
5757	042656	000001		.WORD 1	; DO IT ONE TIME
5758					
5759	042660	060	T1SKP:	.BYTE SKP	; SKIP TAPE MARK
5760	042661	000		.BYTE NULPAT	; NO DATA NEEDED
5761	042662	000001		.WORD 1	; SKIP 1 TAPE MARK
5762	042664	000001		.WORD 1	; DO IT ONE TIME
5763					
5764	042666	061	T1SKR:	.BYTE SKR	; SKIP TAPE MARK REVERSE
5765	042667	000		.BYTE NULPAT	; NO DATA NEEDED
5766	042670	000002		.WORD 2	; SKIP REVERSE 2 TAPE MARKS
5767	042672	000001		.WORD 1	; DO IT ONCE
5768					
5769	042674	050	T1SPC1:	.BYTE SPC	; SPACE RECORDS
5770	042675	000		.BYTE NULPAT	; NO DATA NEEDED
5771	042676	000124		.WORD 84.	; SPACE 84 RECORDS
5772	042700	000001		.WORD 1	; DO IT ONE TIME
5773					
5774	042702	050	T1SPC2:	.BYTE SPC	; SPACE RECORDS
5775	042703	000		.BYTE NULPAT	; NO DATA NEEDED
5776	042704	000105		.WORD 69.	; SPACE 69 RECORDS
5777	042706	000001		.WORD 1	; DO IT ONE TIME
5778					
5779	042710	050	T1SPC3:	.BYTE SPC	; SPACE RECORDS
5780	042711	000		.BYTE NULPAT	; NO DATA NEEDED
5781	042712	000047		.WORD 39.	; SPACE 39 RECORDS
5782	042714	000001		.WORD 1	; DO IT ONE TIME
5783					
5784	042716	070	T1SP01:	.BYTE SPO	; SPACE OBJECTS
5785	042717	000		.BYTE NULPAT	; NO DATA NEEDED
5786	042720	000070		.WORD 56.	; SPACE 56 OBJECTS
5787	042722	000001		.WORD 1	; DO IT ONE TIME
5788					
5789	042724	061	T1SKR1:	.BYTE SKR	; SKIP TAPE MARK REVERSE
5790	042725	000		.BYTE NULPAT	; NO DATA NEEDED
5791	042726	000004		.WORD 4	; 4 TAPE MARKS
5792	042730	000001		.WORD 1	; DO IT ONCE
5793					
5794	042732	070	T1SP02:	.BYTE SPO	; SPACE OBJECTS

5795	042733	000	.BYTE	NULPAT	;NO DATA NEEDED
5796	042734	000107	.WORD	71.	;SPACE 71 OBJECTS
5797	042736	000001	.WORD	1	;DO IT ONE TIME
5798					
5799	042740	070	T1SP03: .BYTE	SPO	;SPACE OBJECTS
5800	042741	000	.BYTE	NULPAT	;NO DATA NEEDED
5801	042742	000102	.WORD	66.	;SPACE 66 OBJECTS
5802	042744	000001	.WORD	1	;DO IT ONE TIME
5803					
5804	042746	071	T1SPR1: .BYTE	SPR	;SPACE OBJECTS REVERSE
5805	042747	000	.BYTE	NULPAT	;NO DATA NEEDED
5806	042750	000567	.WORD	375.	;SPACE 375 OBJECTS
5807	042752	000001	.WORD	1	;DO IT ONE TIME
5808					
5809	042754	060	T1SKP1: .BYTE	SKP	;SKIP TAPE MARKS
5810	042755	000	.BYTE	NULPAT	;NO DATA NEEDED
5811	042756	000004	.WORD	4.	;SKIP 4 TAPE MARKS
5812	042760	000001	.WORD	1	;DO IT ONE TIME
5813					
5814	042762	060	T1SKP2: .BYTE	SKP	;SKIP TAPE MARKS
5815	042763	000	.BYTE	NULPAT	;NO DATA NEEDED
5816	042764	000002	.WORD	2.	;SKIP 2 TAPE MARKS
5817	042766	000001	.WORD	1	;DO IT ONE TIME
5818					
5819	042770	071	T1SPR2: .BYTE	SPR	;SPACE OBJECTS REVERSE
5820	042771	000	.BYTE	NULPAT	;NO DATA NEEDED
5821	042772	000300	.WORD	192.	;SPACE 192 OBJECTS
5822	042774	000001	.WORD	1	;DO IT ONE TIME
5823					
5824	042776	062	T1SKD: .BYTE	SKD	;SKIP TO LEOT
5825	042777	000	.BYTE	NULPAT	;NO DATA NEEDED
5826	043000	000004	.WORD	4	;NO ITEM COUNT
5827	043002	000001	.WORD	1	;DO IT ONE TIME
5828					
5829	043004	020	T1WR1: .BYTE	WR	;WRITE RECORD
5830	043005	001	.BYTE	PAT1	;DATA PATTERN 1 (ALL 1'S)
5831	043006	000026	.WORD	22.	;BYTE COUNT OF 512.
5832	043010	000143	.WORD	99.	;DO IT 99 TIMES
5833					
5834	043012	020	T1WR2: .BYTE	WR	;WRITE RECORD
5835	043013	002	.BYTE	PAT2	;DATA PATTERN 2 (ALL 0'S)
5836	043014	001015	.WORD	525.	;BYTE COUNT OF 525
5837	043016	000124	.WORD	84.	;DO IT 84 TIMES
5838					
5839	043020	020	T1WR3: .BYTE	WR	;WRITE RECORD
5840	043021	003	.BYTE	PAT3	;DATA PATTERN 3 (WORST MFM)
5841	043022	002016	.WORD	1038.	;BYTE COUNT OF 1038
5842	043024	000105	.WORD	69.	;DO IT 69 TIMES
5843					
5844	043026	020	T1WR4: .BYTE	WR	;WRITE RECORD
5845	043027	004	.BYTE	PAT4	;DATA PATTERN 4 (ALTERNATE 1'S AND 0'S)
5846	043030	003017	.WORD	1551.	;BYTE COUNT OF 1551
5847	043032	000066	.WORD	54.	;DO IT 54 TIMES
5848					
5849	043034	020	T1WR5: .BYTE	WR	;WRITE RECORD
5850	043035	003	.BYTE	PAT3	;DATA PATTERN 3 (WORST MFM)
5851	043036	004020	.WORD	2064.	;BYTE COUNT OF 2064

```

5852 043040 000047          .WORD  39.          ;DO IT 39 TIMES
5853
5854 043042      020      T1WR6: .BYTE  WR          ;WRITE RECORD
5855 043043      001          .BYTE  PAT1         ;DATA PATERN 1 (ALL 1'S)
5856 043044 005021          .WORD  2577.        ;BYTE COUNT OF 2577
5857 043046 000030          .WORD  24.          ;DO IT 24 TIMES
5858
5859 043050      010      T1RD1: .BYTE  RD          ;READ RECORD
5860 043051      001          .BYTE  PAT1         ;DATA PATERN 1 (ALL 1'S)
5861 043052 000026          .WORD  22.          ;BYTE COUNT OF 512.
5862 043054 000143          .WORD  99.          ;DO IT 99 TIMES
5863
5864 043056      010      T1RD2: .BYTE  RD          ;READ RECORD
5865 043057      002          .BYTE  PAT2         ;DATA PATERN 2 (ALL 0'S)
5866 043060 001015          .WORD  525.         ;BYTE COUNT OF 525
5867 043062 000124          .WORD  84.          ;DO IT 84 TIMES
5868
5869 043064      010      T1RD3: .BYTE  RD          ;READ RECORD
5870 043065      003          .BYTE  PAT3         ;DATA PATERN 3 (WORST MFM)
5871 043066 002016          .WORD  1038.        ;BYTE COUNT OF 1038
5872 043070 000105          .WORD  69.          ;DO IT 69 TIMES
5873
5874 043072      010      T1RD4: .BYTE  RD          ;READ RECORD
5875 043073      004          .BYTE  PAT4         ;DATA PATERN 4 (ALTERNATE 1'S AND 0'S)
5876 043074 003017          .WORD  1551.        ;BYTE COUNT OF 1551
5877 043076 000066          .WORD  54.          ;DO IT 54 TIMES
5878
5879 043100      010      T1RD5: .BYTE  RD          ;READ RECORD
5880 043101      003          .BYTE  PAT3         ;DATA PATERN 3 (WORST MFM)
5881 043102 004020          .WORD  2064.        ;BYTE COUNT OF 2064
5882 043104 000047          .WORD  39.          ;DO IT 39 TIMES
5883
5884 043106      010      T1RD6: .BYTE  RD          ;READ RECORD
5885 043107      001          .BYTE  PAT1         ;DATA PATERN 1 (ALL 1'S)
5886 043110 005021          .WORD  2577.        ;BYTE COUNT OF 2577
5887 043112 000030          .WORD  24.          ;DO IT 24 TIMES
5888
5889          .EVEN
5890
5891 043114          ENDTST
      043114          L10015:
      043114 104401          TRAP  C$ETST

```

```

5898          .SBTTL TEST 2: Quick Verify Write/Read Test
5899
5900          ;++
5901          ;This test rewinds the tape, then executes the following sequence:
5902          ;
5903          ;   1. Write record set,
5904          ;   2. Reposition over just written record set,
5905          ;   3. Then read the current record set,
5906          ;
5907          ;for 5 iterations or until fatal error is encountered. This test
5908          ;permits retries, fixed record length (2048 bytes), fixed number of
5909          ;records/set (400), and predetermined data patterns. This test will
5910          ;execute in a round-robin manner.
5911          ;--
5912          043116          BGNTST
5913          043116          T2::
5914          043116 105737 002234          TSTB      T3ONLY          ;CHECK THE TEST 3 ONLY FLAG
5915          043122 001414          BEQ        START2          ;BRANCH IF IT IS CLEAR
5916          043124 013746 002114          PRINTF     #BYPASS,L$TEST      ;PRINT THE TEST BYPASSED MESSAGE
5917          043130 012746 021001          MOV        L$TEST,-(SP)
5918          043134 012746 000002          MOV        #BYPASS,-(SP)
5919          043140 010600          MOV        #2,-(SP)
5920          043142 104417          MOV        SP,R0
5921          043144 062706 000006          TRAP      C$PNTF
5922          043150 000137 043534          ADD        #6,SP
5923          043154 005737 003524          JMP        T2EXIT          ;GET OUT
5924          043160 001014          START2: TST      UDROP          ;HAVE ALL UNITS BEEN DROPPED ?
5925          043162 013746 002114          BNE        5$              ;GO START THE TEST
5926          043166 012746 021001          PRINTF     #BYPASS,L$TEST      ;PRINT THE TEST BYPASSED MESSAGE
5927          043172 012746 000002          MOV        L$TEST,-(SP)
5928          043176 010600          MOV        #BYPASS,-(SP)
5929          043200 104417          MOV        #2,-(SP)
5930          043202 062706 000006          MOV        SP,R0
5931          043206 000137 043534          TRAP      C$PNTF
5932          043212 105737 002212          ADD        #6,SP
5933          043216 001421          JMP        T2EXIT          ;GET OUT IF NONE LEFT TO TEST
5934          043220 005046          5$:      TSTB      CLOCK          ;IS THE CLOCK ENABLED
5935          043222 153716 002215          BEQ        G02              ;NO, THEN CAN'T PRINT TIME
5936          043226 005046          PRINTF     #TIME,<B,HOURS>,<B,MINUTE>,<B,SECOND>,
5937          043230 153716 002214          CLR        -(SP)
5938          043234 005046          BISB      SECOND,(SP)
5939          043236 153716 002213          CLR        -(SP)
5940          043242 012746 020044          BISB      MINUTE,(SP)
5941          043246 012746 000004          CLR        -(SP)
5942          043252 010600          BISB      HOURS,(SP)
5943          043254 104417          MOV        #TIME,-(SP)
5944          043256 062706 000012          MOV        #4,-(SP)
5945          043262 004737 033456          MOV        SP,R0
5946          043266 005037 003520          TRAP      C$PNTF
5947          043272 005037 003440          ADD        #12,SP
5948          043262 004737 033456          G02:     JSR      PC,CLREOT      ;MAKE SURE EOT STATUS IS CLEAR
5949          043266 005037 003520          CLR        OBJECT          ;CLEAR THE OBJECT COUNTER
5950          043272 005037 003440          CLR        TSTMSK          ;ALLOW NO ERRORS

```

```

5931 043276 012705 043544      MOV      #T2REW,R5      ;SET UP TO DO A REWIND
5932 043302 004737 021240      JSR      PC,SCHED      ;GO ISSUE A REWIND TO ALL DRIVES
5933 043306 005737 003524      TST      UDROP          ;HAVE ALL UNITS BEEN DROPPED ?
5934 043312 001510      BEQ      T2EXIT        ;GET OUT IF NONE LEFT TO TEST
5935
5936
5937 043314 004737 033556      5$:     JSR      PC,SDSTUP   ;RESET THE RANDOM SEEDS
5938 043320 012705 043552      MOV      #T2WRT,R5     ;SET UP TO DO A WRITE ITERATION
5939 043324 004737 021240      JSR      PC,SCHED      ;GO ISSUE WRITES TO ALL DRIVES
5940 043330 005737 003524      TST      UDROP          ;HAVE ALL UNITS BEEN DROPPED ?
5941 043334 001477      BEQ      T2EXIT        ;GET OUT IF NONE LEFT TO TEST
5942
5943 043336 012705 043560      MOV      #T2LEOT,R5    ;SET UP TO DO A WRITE LEOT
5944 043342 004737 021240      JSR      PC,SCHED      ;GO ISSUE WRITES TO ALL DRIVES
5945 043346 005737 003524      TST      UDROP          ;HAVE ALL UNITS BEEN DROPPED ?
5946 043352 001470      BEQ      T2EXIT        ;GET OUT IF NONE LEFT TO TEST
5947
5948 043354 012705 043544      MOV      #T2REW,R5     ;SET UP TO DO A REWIND
5949 043360 004737 021240      JSR      PC,SCHED      ;GO ISSUE A REWIND TO ALL DRIVES
5950 043364 005737 003524      TST      UDROP          ;HAVE ALL UNITS BEEN DROPPED ?
5951 043370 001461      BEQ      T2EXIT        ;GET OUT IF NONE LEFT TO TEST
5952
5953 043372 005737 003520      TST      OBJECT        ;IS THIS THE FIRST TIME THROUGH ?
5954 043376 001412      BEQ      10$           ;YES, DON'T DO THE SPACE FORWARD
5955 043400 012705 043602      MOV      #T2SPO,R5     ;SET UP TO SPACE OBJECTS
5956 043404 013765 003520 000002  MOV      OBJECTS,ITMCNT(R5) ;SET UP # OF OBJECTS TO SPACE FORWARD
5957 043412 004737 021240      JSR      PC,SCHED      ;GO ISSUE A REWIND TO ALL DRIVES
5958 043416 005737 003524      TST      UDROP          ;HAVE ALL UNITS BEEN DROPPED ?
5959 043422 001444      BEQ      T2EXIT        ;GET OUT IF NONE LEFT TO TEST
5960
5961 043424 004737 033556      10$:    JSR      PC,SDSTUP   ;RESET THE RANDOM SEEDS
5962 043430 012705 043566      MOV      #T2RD,R5      ;SET UP TO DO A READITERATION
5963 043434 004737 021240      JSR      PC,SCHED      ;GO ISSUE READS TO ALL DRIVES
5964 043440 005737 003524      TST      UDROP          ;HAVE ALL UNITS BEEN DROPPED ?
5965 043444 001433      BEQ      T2EXIT        ;GET OUT IF NONE LEFT TO TEST
5966 043446 066537 000004 003520  ADD      ITRCNT(R5),OBJECTS ;ADD THE # OF RECORDS TO OBJECTS
5967
5968 043454 052737 000001 003440  BIS      #LEDB,TSTMSK   ;SET UP TO ALLOW LEOT DETECTED
5969 043462 012705 043574      MOV      #T2SKD,R5     ;SET UP TO DO A SKIP TO LEOT
5970 043466 004737 021240      JSR      PC,SCHED      ;GO ISSUE READS TO ALL DRIVES
5971 043472 042737 000001 003440  BIC      #LEDB,TSTMSK   ;DISALLOW LEOT DETECTED
5972 043500 005737 003524      TST      UDROP          ;HAVE ALL UNITS BEEN DROPPED ?
5973 043504 001413      BEQ      T2EXIT        ;GET OUT IF NONE LEFT TO TEST
5974 043506 066537 000004 003520  ADD      ITRCNT(R5),OBJECTS ;ADD THE # OF RECORDS TO OBJECTS
5975
5976 043514 022737 004716 003520  CMP      #T2END,OBJECTS ;HAVE WE DONE 2 TRACKS ?
5977 043522 001274      BNE      5$           ;NO, KEEP GOING
5978 043524 012705 043544      MOV      #T2REW,R5     ;SET UP TO DO A REWIND
5979 043530 004737 021240      JSR      PC,SCHED      ;GO ISSUE A REWIND TO ALL DRIVES
5980 043534 004737 033632      T2EXIT: JSR      PC,SDSAVE   ;RESET THE RANDOM SEEDS
5981 043540      EXIT      TST
      043540 104432      TRAP     C$EXIT
      043542 000046      .WORD   L10016-.
5982
5983
5984 043544      160      T2REW:  .BYTE   REW
5985 043545      000      .BYTE   NULPAT      ;REWIND
    
```

5986	043546	000000		.WORD	0	
5987	043550	000001		.WORD	1	
5988						
5989	043552	020	T2WRT:	.BYTE	WR	;WRITE RECORDS
5990	043553	003		.BYTE	PAT3	
5991	043554	010000		.WORD	4096.	
5992	043556	000372		.WORD	250.	
5993						
5994	043560	100	T2LEOT:	.BYTE	WTM	;WRITE TAPE MARK
5995	043561	000		.BYTE	NULPAT	;NO DATA NEEDED
5996	043562	000000		.WORD	0	;NO ITEM COUNT
5997	043564	000002		.WORD	2	;DO IT TWICE
5998						
5999	043566	010	T2RD:	.BYTE	RD	;READ RECORDS
6000	043567	003		.BYTE	PAT3	
6001	043570	010000		.WORD	4096.	
6002	043572	000372		.WORD	250.	
6003						
6004	043574	062	T2SKD:	.BYTE	SKD	;SKIP TAPE MARK TO LEOT
6005	043575	000		.BYTE	NULPAT	;NO DATA NEEDED
6006	043576	000062		.WORD	50.	;SKIP 50 TAPE MARKS
6007	043600	000001		.WORD	1	;DO IT ONE TIME
6008						
6009	043602	070	T2SP0:	.BYTE	SPO	;SPACE OBJECTS
6010	043603	000		.BYTE	NULPAT	
6011	043604	000001		.WORD	1	
6012	043606	000001		.WORD	1	
6013						
6014				.EVEN		
6015	043610			ENDTST		
	043610		L10016:			
	043610	104401		TRAP	C\$ETST	
6016						




```

6018 .SBTTL TEST 3: Complex Write/Read Test
6019
6020 ;**
6021 ;This test rewinds the tape, and executes the following sequence:
6022 ;
6023 ; 1. Write 1000 records,
6024 ; 2. Write a file mark,
6025 ; 3. Repeat 1 and 2 until EOT is reached,
6026 ; 4. Write 2 file marks (LEOT),
6027 ; 5. Rewind,
6028 ; 6. Read 1000 records,
6029 ; 7. Read 1 record (should see unexpected tape mark)
6030 ; 8. Repeat 6 and 7 until LEOT.
6031 ;
6032 ;# of records (N), and record size will be randomly selected. This
6033 ;sequence will permit hardware retries, if not user disabled. This
6034 ;test will run until EOT, LEOT or fatal error is detected. All data
6035 ;patterns including random data will be used in this test.
6036 ;--
6037 043612 BGNTST
        043612
6038 T3::
6039 043612 005737 003524 START3: TST UDROP ;HAVE ALL UNITS BEEN DROPPED ?
6040 043616 001014 BNE 5$ ;GO START THE TEST
6041 043620 PRINTF #BYPASS,L$TEST ;PRINT THE TEST BYPASSED MESSAGE
        043620 013746 002114 MOV L$TEST,-(SP)
        043624 012746 021001 MOV #BYPASS,-(SP)
        043630 012746 000002 MOV #2,-(SP)
        043634 010600 MOV SP,R0
        043636 104417 TRAP C$PNTF
        043640 062706 000006 ADD #6,SP
6042 043644 000137 044220 JMP T3EXIT ;GET OUT IF NONE LEFT TO TEST
6043
6044 043650 105737 002212 5$: TSTB CLOCK ;IS THE CLOCK ENABLED
6045 043654 001421 BEQ G03 ;NO, THEN CAN'T PRINT TIME
6046 043656 PRINTF #TIME,<B,HOURS>,<B,MINUTE>,<B,SECOND>,
        043656 005046 CLR -(SP)
        043660 153716 002215 BISB SECOND,(SP)
        043664 005046 CLR -(SP)
        043666 153716 002214 BISB MINUTE,(SP)
        043672 005046 CLR -(SP)
        043674 153716 002213 BISB HOURS,(SP)
        043700 012746 020044 MOV #TIME,-(SP)
        043704 012746 000004 MOV #4,-(SP)
        043710 010600 MOV SP,R0
        043712 104417 TRAP C$PNTF
        043714 062706 000012 ADD #12,SP
6047
6048 043720 004737 033706 G03: JSR PC,PATCLR ;MAKE SURE WE START WITH PATTERN 1
6049 043724 004737 033556 JSR PC,SDSTUP ;RESET THE RANDOM SEEDS
6050 043730 004737 033456 JSR PC,CLREOT ;CLEAR ALL EOT INDICATIONS
6051
6052 043734 005037 003440 CLR TSTMSK ;ALLOW NO ERRORS
6053 043740 005737 003524 TST UDROP ;HAVE ALL UNITS BEEN DROPPED ?
6054 043744 001525 BEQ T3EXIT ;GET OUT IF NONE LEFT TO TEST
6055
6056 043746 012705 044230 MOV #T3REW,R5 ;SET UP TO DO REWIND
    
```

6057	043752	004737	021240			JSR	PC,SCHED		;GO ISSUE TO ALL DRIVES
6058	043756	005737	003524			TST	UDROP		;HAVE ALL UNITS BEEN DROPPED ?
6059	043762	001516				BEQ	T3EXIT		;GET OUT IF NONE LEFT TO TEST
6060									
6061	043764	012705	044236	5\$:		MOV	#T3WRT,R5		;SET UP A WRITE ITERATION
6062	043770	004737	021240			JSR	PC,SCHED		;GO DO IT ON ALL DRIVES
6063	043774	005737	003524			TST	UDROP		;HAVE ALL UNITS BEEN DROPPED ?
6064	044000	001507				BEQ	T3EXIT		;GET OUT IF NONE LEFT TO TEST
6065	044002	023737	003526	003524		CMP	UEOT,UDROP		;ARE ALL UNITS AT EOT ?
6066	044010	001413				BEQ	10\$;YES, WRITE ONE MORE REC AND LEOT
6067									
6068	044012	012705	044244			MOV	#T3WTM,R5		;SET UP TO WRITE A TAPE MARK
6069	044016	004737	021240			JSR	PC,SCHED		;GO DO IT ON ALL DRIVES
6070	044022	005737	003524			TST	UDROP		;HAVE ALL UNITS BEEN DROPPED ?
6071	044026	001474				BEQ	T3EXIT		;GET OUT IF NONE LEFT TO TEST
6072	044030	023737	003526	003524		CMP	UEOT,UDROP		;ARE ALL UNITS AT EOT ?
6073	044036	001352				BNE	5\$;NO, KEEP WRITING
6074									
6075	044040	012737	000004	010560	10\$:	MOV	#4,LOOPS		;SET UP TO DO 4 TAPE MARKS
6076	044046	004737	033456		15\$:	JSR	PC,CLREOT		;CLEAR THE EOT INDICATORS
6077	044052	012705	044244			MOV	#T3WTM,R5		;SET UP TO WRITE A TAPE MARK
6078	044056	004737	021240			JSR	PC,SCHED		;GO DO IT ON ALL DRIVES
6079	044062	005737	003524			TST	UDROP		;HAVE ALL UNITS BEEN DROPPED ?
6080	044066	001454				BEQ	T3EXIT		;GET OUT IF NONE LEFT TO TEST
6081	044070	005337	010560			DEC	LOOPS		;SUBTRACT 1 FROM THE TAPE MARK COUNT
6082	044074	001364				BNE	15\$;KEEP GOING TIL THEY'RE ALL WRITTEN
6083									
6084	044076	004737	033456			JSR	PC,CLREOT		;CLEAR THE EOT INDICATORS
6085	044102	012705	044230			MOV	#T3REW,R5		;SET UP TO REWIND ALL DRIVES
6086	044106	004737	021240			JSR	PC,SCHED		;GO DO IT
6087	044112	005737	003524			TST	UDROP		;HAVE ALL UNITS BEEN DROPPED ?
6088	044116	001440				BEQ	T3EXIT		;GET OUT IF NONE LEFT TO TEST
6089	044120	004737	033706			JSR	PC,PATCLR		;START AT PATTERN 1
6090	044124	004737	033556			JSR	PC,SDSTUP		;RESET THE RANDOM SEEDS
6091									
6092	044130	012705	044252	20\$:		MOV	#T3RD,R5		;SET UP TO READ AN ITERATION SET
6093	044134	004737	021240			JSR	PC,SCHED		;GO ISSUE TO ALL DRIVES
6094	044140	005737	003524			TST	UDROP		;HAVE ALL UNITS BEEN DROPPED ?
6095	044144	001425				BEQ	T3EXIT		;GET OUT IF NONE LEFT TO TEST
6096	044146	023737	003526	003524		CMP	UEOT,UDROP		;ALL UNITS AT EOT ?
6097	044154	001413				BEQ	EX3REW		;YES, GO REWIND ALL DRIVES
6098									
6099	044156	012705	044260			MOV	#T3SPO,R5		;SPACE 1 OBJECT (TAPE MARK)
6100	044162	004737	021240			JSR	PC,SCHED		;GO DO IT AN ALL DRIVES
6101	044166	005737	003524			TST	UDROP		;HAVE ALL UNITS BEEN DROPPED ?
6102	044172	001412				BEQ	T3EXIT		;GET OUT IF NONE LEFT TO TEST
6103	044174	023737	003526	003524		CMP	UEOT,UDROP		;ALL UNITS AT EOT ?
6104	044202	001352				BNE	20\$;NO, KEEP READING
6105									
6106	044204	004737	033456	EX3REW:		JSR	PC,CLREOT		;CLEAR THE EOT INDICATORS
6107	044210	012705	044230			MOV	#T3REW,R5		;SET UP TO REWIND ALL DRIVES
6108	044214	004737	021240			JSR	PC,SCHED		;GO DO IT
6109									
6110	044220	004737	033632	T3EXIT:		JSR	PC,SDSAVE		;RESET THE RANDOM SEEDS
6111	044224					EXIT	TST		
	044224	104432				TRAP	C\$EXIT		
	044226	000040				.WORD	L10017-		

6112

6114	044230	160	T3REW:	.BYTE	REW		:REWIND
6115	044231	000		.BYTE	NULPAT		
6116	044232	000000		.WORD	0		
6117	044234	000001		.WORD	1		
6118							
6119	044236	020	T3WRT:	.BYTE	WR		:WRITE RECORDS
6120	044237	200		.BYTE	ALLPAT		
6121	044240	000000		.WORD	RNDBYT		
6122	044242	000000		.WORD	RNDITR		
6123							
6124	044244	100	T3WTM:	.BYTE	WTM		:WRITE TAPE MARK
6125	044245	000		.BYTE	NULPAT		
6126	044246	000000		.WORD	0		
6127	044250	000001		.WORD	1		
6128							
6129	044252	010	T3RD:	.BYTE	RD		:READ RECORDS
6130	044253	200		.BYTE	ALLPAT		
6131	044254	000000		.WORD	RNDBYT		
6132	044256	000000		.WORD	RNDITR		
6133							
6134	044260	070	T3SPO:	.BYTE	SPO		:SPACE OBJECT (TAPE MARK)
6135	044261	000		.BYTE	NULPAT		
6136	044262	000001		.WORD	1		
6137	044264	000001		.WORD	1		
6138							
6139				.EVEN			
6140	044266		ENDTST				
	044266		L10017:				
	044266	104401	TRAP		C\$ETST		

```

6142          .SBTTL TEST 4: Write Interchange Tape
6143
6144          ;**
6145          ;This test will rewind the tape, then write until EOT or a fatal error is
6146          ;encountered This test will keep track of the number of records and tape
6147          ;marks written. If a fatal error is encountered, a message will report
6148          ;it, and the unit prevented from executing further write operations.
6149          ;--
6150 044270      BGNTST
6151 044270      T4::
6152 044270      TSTB      T3ONLY          ;CHECK THE TEST 3 ONLY FLAG
6153 044270      BEQ       START4          ;BRANCH IF IT IS CLEAR
6154 044270      PRINTF   #BYPASS,L$TEST  ;PRINT THE TEST BYPASSED MESSAGE
6155 044270      MOV       L$TEST,-(SP)
6156 044270      MOV       #BYPASS,-(SP)
6157 044270      MOV       #2,-(SP)
6158 044270      MOV       SP,RO
6159 044270      TRAP     C$PNTF
6160 044270      ADD       #6,SP
6161 044270      JMP      T4EXIT          ;GET OUT
6162 044270
6163 044270      START4: TST      UDROP          ;HAVE ALL UNITS BEEN DROPPED ?
6164 044270      BNE      5$              ;GO START THE TEST
6165 044270      PRINTF   #BYPASS,L$TEST  ;PRINT THE TEST BYPASSED MESSAGE
6166 044270      MOV       L$TEST,-(SP)
6167 044270      MOV       #BYPASS,-(SP)
6168 044270      MOV       #2,-(SP)
6169 044270      MOV       SP,RO
6170 044270      TRAP     C$PNTF
6171 044270      ADD       #6,SP
6172 044270      JMP      T4EXIT          ;GET OUT IF NONE LEFT TO TEST
6173 044270
6174 044270      5$:      TSTB      CLOCK          ;IS THE CLOCK ENABLED
6175 044270      BEQ       G04            ;NO, THEN CAN'T PRINT TIME
6176 044270      PRINTF   #TIME,<B,HOURS>,<B,MINUTE>,<B,SECOND>,
6177 044270      CLR       -(SP)
6178 044270      BISB     SECOND,(SP)
6179 044270      CLR       -(SP)
6180 044270      BISB     MINUTE,(SP)
6181 044270      CLR       -(SP)
6182 044270      BISB     HOURS,(SP)
6183 044270      MOV       #TIME,-(SP)
6184 044270      MOV       #4,-(SP)
6185 044270      MOV       SP,RO
6186 044270      TRAP     C$PNTF
6187 044270      ADD       #12,SP
6188 044270
6189 044270      G04:     JSR      PC,PATCLR
6190 044270      JSR      PC,SDSTUP
6191 044270      JSR      PC,CLREOT
6192 044270      CLR      TSTMSK
6193 044270
6194 044270      MOV      #T4REW,R5
6195 044270      JSR      PC,SCHED
6196 044270      TST      UDROP
6197 044270      BEQ      T4EXIT          ;GET OUT IF NONE LEFT TO TEST

```



```

6221          .SBTTL TEST 5: Read Unknown Tape
6222
6223          ;**
6224          ;This test will rewind a tape, then read until EOT, LEOT or fatal error
6225          ;is encountered. This test will keep track of the number of records
6226          ;and files read. If a fatal error is encountered, a message will
6227          ;report it, the tape on the unit will be rewound, and the unit
6228          ;prevented from executing further read operations.
6229          ;--
6230 044650      BGNTST
6231 044650      T5::
6232 044650 105737 002234      TSTB      T3ONLY          ;CHECK THE TEST 3 ONLY FLAG
6233 044654 001414          BEQ        START5          ;BRANCH IF IT IS CLEAR
6234 044656          PRINTF     #BYPASS,L$TEST      ;PRINT THE TEST BYPASSED MESSAGE
6235 044656 013746 002114      MOV        L$TEST,-(SP)
6236 044662 012746 021001      MOV        #BYPASS,-(SP)
6237 044666 012746 000002      MOV        #2,-(SP)
6238 044672 010600          MOV        SP,R0
6239 044674 104417          TRAP      C$PNTF
6240 044676 062706 000006      ADD        #6,SP
6241 044702 000137 045146      JMP        T5EXIT          ;GET OUT
6242
6243          START5: TST        UDROP          ;HAVE ALL UNITS BEEN DROPPED ?
6244          BNE        5$          ;GO START THE TEST
6245          PRINTF     #BYPASS,L$TEST      ;PRINT THE TEST BYPASSED MESSAGE
6246          MOV        L$TEST,-(SP)
6247          MOV        #BYPASS,-(SP)
6248          MOV        #2,-(SP)
6249          MOV        SP,R0
6250          TRAP      C$PNTF
6251          ADD        #6,SP
6252          JMP        T5EXIT          ;GET OUT IF NONE LEFT TO TEST
6253
6254          5$:  TSTB      CLOCK          ;IS THE CLOCK ENABLED
6255          BEQ        G05          ;NO, THEN CAN'T PRINT TIME
6256          PRINTF     #TIME,<B,HOURS>,<B,MINUTE>,<B,SECOND>,
6257          CLR        -(SP)
6258          BISB      SECOND,(SP)
6259          CLR        -(SP)
6260          BISB      MINUTE,(SP)
6261          CLR        -(SP)
6262          BISB      HOURS,(SP)
6263          MOV        #TIME,-(SP)
6264          MOV        #4,-(SP)
6265          MOV        SP,R0
6266          TRAP      C$PNTF
6267          ADD        #12,SP
6268
6269          G05:  JSR        PC,PATCLR      ;MAKE SURE WE START WITH PATTERN 1
6270          JSR        PC,SDSTUP      ;SET UP THE RANDOM SEEDS
6271          JSR        PC,CLREOT      ;CLEAR THE EOT FLAG
6272
6273          BITB      #BIT0,DMPBUF      ;ARE WE DUMPING ALL RECORDS?
6274          BEQ        1$          ;NO - BRANCH
6275          MOV        #1,T5RD+4      ;CHANGE ITER COUNT TO 1
6276
6277          1$:  CLR        TSTMSK          ;NO ALLOWABLE ERRORS

```

```

6254 045052 012705 045152          MOV    #T5REW,R5          ;POINT R5 TO THE REWIND TABLE
6255 045056 004737 021240          JSR    PC,SCHED          ;GO START THE TEST
6256 045062 005737 003524          TST    UDROP              ;HAVE ALL UNITS BEEN DROPPED ?
6257 045066 001427                    BEQ    T5EXIT             ;GET OUT IF NONE LEFT TO TEST
6258
6259 045070 012737 000012 003440      MOV    #TMB!RDTB,TSTMSK  ;TAPE MARKS AND TRUNC. RECORDS OK
6260 045076 012705 045160          5$:   MOV    #T5RD,R5          ;POINT R5 TO THE TEST TABLE
6261 045102 004737 021240          JSR    PC,SCHED          ;GO START THE TEST
6262 045106 005737 003524          TST    UDROP              ;HAVE ALL UNITS BEEN DROPPED ?
6263 045112 001415                    BEQ    T5EXIT             ;GET OUT IF NONE LEFT TO TEST
6264 045114 023737 003526 003524      CMP    UEOT,UDROP        ;ARE THEY ALL AT EOT ?
6265 045122 001365                    BNE    5$                 ;BRANCH IF THEY ARE NOT
6266
6267 045124 004737 033456          10$:  JSR    PC,CLREOT          ;
6268 045130 012705 045152          MOV    #T5REW,R5          ;POINT R5 TO THE REWIND TABLE
6269 045134 004737 021240          JSR    PC,SCHED          ;GO REWIND ALL UNITS
6270 045140 012737 001751 045164      MOV    #1001.,T5RD+4     ;RESTORE ITER COUNT
6271 045146          T5EXIT: EXIT            TST
        045146 104432          TRAP   C$EXIT
        045150 000016          .WORD  L10021-.
6272
6273 045152          160          T5REW: .BYTE  REW          ;REWIND
6274 045153          000          .BYTE  NULPAT
6275 045154          000000      .WORD  0
6276 045156          000001      .WORD  1
6277
6278 045160          010          T5RD:  .BYTE  RD          ;READ RECORDS
6279 045161          200          .BYTE  ALLPAT
6280 045162          010000      .WORD  4096.
6281 045164          001751      .WORD  1001.
6282
6283          .EVEN
6284 045166          ENDTST
        045166          L10021:
        045166 104401          TRAP   C$ETST

```



```

6286          .SBTTL TEST 6: Start/Stop Write/Read Test
6287
6288
6289          ;**
6290          ;This test rewinds the tape, and executes the following sequence:
6291          ;
6292          ;   1. Write 1300 records one at a time,
6293          ;   2. Write 2 file marks (LEOT),
6294          ;   3. Rewind,
6295          ;   4. Read 1300 records one at a time,
6296          ;   5. Skip to LEOT.
6297          ;   6. Rewind,
6298          ;
6299          ;This sequence will permit hardware retries, if not user disabled.
6300          ;This test will run until exhaustion of the command count or fatal error
6301          ;is detected. All data patterns including random data will be used
6302          ;in this test.
6303          ;--
6303          BGNTST
6304          T6::
6305          TSTB      T3ONLY          ;CHECK THE TEST 3 ONLY FLAG
6306          BEQ      START6          ;BRANCH IF IT IS CLEAR
6307          PRINTF   #BYPASS,L$TEST  ;PRINT THE TEST BYPASSED MESSAGE
6308          MOV      L$TEST,-(SP)
6309          MOV      #BYPASS,-(SP)
6310          MOV      #2,-(SP)
6311          MOV      SP,R0
6312          TRAP    C$PNTF
6313          ADD      #6,SP
6314          JMP      T6EXIT          ;GET OUT
6315
6316          START6: TST      UDROP          ;HAVE ALL UNITS BEEN DROPPED ?
6317          BNE      5$              ;GO START THE TEST
6318          PRINTF   #BYPASS,L$TEST  ;PRINT THE TEST BYPASSED MESSAGE
6319          MOV      L$TEST,-(SP)
6320          MOV      #BYPASS,-(SP)
6321          MOV      #2,-(SP)
6322          MOV      SP,R0
6323          TRAP    C$PNTF
6324          ADD      #6,SP
6325          JMP      T6EXIT          ;GET OUT IF NONE LEFT TO TEST
6326
6327          5$:   TSTB      CLOCK          ;IS THE CLOCK ENABLED
6328          BEQ      G06              ;NO, THEN CAN'T PRINT TIME
6329          PRINTF   #TIME,<B,HOURS>,<B,MINUTE>,<B,SECOND>,
6330          CLR      -(SP)
6331          BISB     SECOND,(SP)
6332          CLR      -(SP)
6333          BISB     MINUTE,(SP)
6334          CLR      -(SP)
6335          BISB     HOURS,(SP)
6336          MOV      #TIME,-(SP)
6337          MOV      #4,-(SP)
6338          MOV      SP,R0
6339          TRAP    C$PNTF
6340          ADD      #12,SP
6341
6342          G06:   JSR      PC,PATCLR    ;MAKE SURE WE START WITH PATTERN 1

```

6319	045340	004737	033556		JSR	PC,SDSTUP	;RESET THE RANDOM SEEDS
6320	045344	004737	033456		JSR	PC,CLREOT	;CLEAR ALL EOT INDICATIONS
6321							
6322	045350	005037	003440		CLR	TSTMSK	;ALLOW NO ERRORS
6323	045354	005737	003524		TST	UDROP	;HAVE ALL UNITS BEEN DROPPED ?
6324	045360	001506			BEQ	T6EXIT	;GET OUT IF NONE LEFT TO TEST
6325							
6326	045362	012705	045606		MOV	#T6REW,R5	;SET UP TO DO REWIND
6327	045366	004737	021240		JSR	PC,SCHED	;GO ISSUE TO ALL DRIVES
6328	045372	005737	003524		TST	UDROP	;HAVE ALL UNITS BEEN DROPPED ?
6329	045376	001477			BEQ	T6EXIT	;GET OUT IF NONE LEFT TO TEST
6330	045400	012737	002424	003404	MOV	#1300.,COUNT	;STEP UP THE WRITE ITERATION COUNT
6331							
6332	045406	012705	045614	5\$:	MOV	#T6WRT,R5	;SET UP A WRITE ITERATION
6333	045412	004737	021240		JSR	PC,SCHED	;GO DO IT ON ALL DRIVES
6334	045416	005737	003524		TST	UDROP	;HAVE ALL UNITS BEEN DROPPED ?
6335	045422	001465			BEQ	T6EXIT	;GET OUT IF NONE LEFT TO TEST
6336	045424	005337	003404		DEC	COUNT	;SUBTRACT 1 FROM THE ITERATION COUNT
6337	045430	001366			BNE	5\$;MORE COMMANDS TO DO, KEEP GOING
6338							
6339	045432	012705	045622		MOV	#T6WTM,R5	;SET UP TO WRITE A TAPE MARK
6340	045436	004737	021240		JSR	PC,SCHED	;GO DO IT ON ALL DRIVES
6341	045442	005737	003524		TST	UDROP	;HAVE ALL UNITS BEEN DROPPED ?
6342	045446	001453			BEQ	T6EXIT	;GET OUT IF NONE LEFT TO TEST
6343							
6344	045450	012705	045606		MOV	#T6REW,R5	;SET UP TO REWIND ALL DRIVES
6345	045454	004737	021240		JSR	PC,SCHED	;GO DO IT
6346	045460	005737	003524		TST	UDROP	;HAVE ALL UNITS BEEN DROPPED ?
6347	045464	001444			BEQ	T6EXIT	;GET OUT IF NONE LEFT TO TEST
6348							
6349	045466	004737	033706		JSR	PC,PATCLR	;START AT PATTERN 1
6350	045472	004737	033556		JSR	PC,SDSTUP	;RESET THE RANDOM SEEDS
6351	045476	012737	002424	003404	MOV	#1300.,COUNT	;STEP UP THE WRITE ITERATION COUNT
6352							
6353	045504	012705	045630	10\$:	MOV	#T6RD,R5	;SET UP TO READ AN ITERATION SET
6354	045510	004737	021240		JSR	PC,SCHED	;GO DO IT ON ALL DRIVES
6355	045514	005737	003524		TST	UDROP	;HAVE ALL UNITS BEEN DROPPED ?
6356	045520	001426			BEQ	T6EXIT	;GET OUT IF NONE LEFT TO TEST
6357	045522	005337	003404		DEC	COUNT	;SUBTRACT 1 FROM THE ITERATION COUNT
6358	045526	001366			BNE	10\$;MORE COMMANDS TO DO, KEEP GOING
6359							
6360	045530	052737	000001	003440	BIS	#LEDB,TSTMSK	;SET UP TO ALLOW LEOT DETECTED
6361	045536	012705	045636		MOV	#T6SKD,R5	;SKIP TO LEOT
6362	045542	004737	021240		JSR	PC,SCHED	;GO DO IT AN ALL DRIVES
6363	045546	042737	000001	003440	BIC	#LEDB,TSTMSK	;DISALLOW LEOT DETECTED
6364	045554	005737	003524		TST	UDROP	;HAVE ALL UNITS BEEN DROPPED ?
6365	045560	001406			BEQ	T6EXIT	;GET OUT IF NONE LEFT TO TEST
6366							
6367	045562	004737	033456		JSR	PC,CLREOT	;CLEAR THE EOT INDICATORS
6368	045566	012705	045606		MOV	#T6REW,R5	;SET UP TO REWIND ALL DRIVES
6369	045572	004737	021240		JSR	PC,SCHED	;GO DO IT
6370							
6371	045576	004737	033632	T6EXIT:	JSR	PC,SDSAVE	;RESET THE RANDOM SEEDS
6372	045602				EXIT	TST	
	045602	104432			TRAP	C\$EXIT	
	045604	000040			.WORD	L10022-	
6373							

6375	045606	160	T6REW:	.BYTE	REW		
6376	045607	000		.BYTE	NULPAT		;REWIND
6377	045610	000000		.WORD	0		
6378	045612	000001		.WORD	1.		
6379							
6380	045614	020	T6WRT:	.BYTE	WR		;WRITE RECORDS
6381	045615	200		.BYTE	ALLPAT		
6382	045616	020000		.WORD	8192.		
6383	045620	000001		.WORD	1.		
6384							
6385	045622	100	T6WTM:	.BYTE	WTM		;WRITE TAPE MARK
6386	045623	000		.BYTE	NULPAT		
6387	045624	000000		.WORD	0		
6388	045626	000002		.WORD	2.		
6389							
6390	045630	010	T6RD:	.BYTE	RD		;READ RECORDS
6391	045631	200		.BYTE	ALLPAT		
6392	045632	020000		.WORD	8192.		
6393	045634	000001		.WORD	1.		
6394							
6395	045636	062	T6SKD:	.BYTE	SKD		;SKIP TO LEOT
6396	045637	000		.BYTE	NULPAT		
6397	045640	000001		.WORD	1		
6398	045642	000001		.WORD	1		
6399							
6400				.EVEN			
6401	045644			ENDTST			
	045644		L10022:				
	045644	104401		TRAP	C\$ETST		

```

6403          .SBTTL TEST 7: Conversation Test
6404
6405          ;**
6406          ;Conversation mode will run with or without error reports.  The user
6407          ;can select, from a list of commands, a sequence which can be used to
6408          ;emulate a known failure mode.  Between commands, the user can specify
6409          ;unique delays, ranging from 10 to 250 ms.  The user can follow each
6410          ;tape command with integer values, the first indicating the
6411          ;byte/record/file count and the second indicating the # of repetitions
6412          ;necessary for that command.
6413          ;--
6414 045646      BGNTST
6415 045646      T7::
6416 045646      105737 002234      TSTB      T3ONLY          ;CHECK THE TEST 3 ONLY FLAG
6417 045652      001414          BEQ        START7          ;BRANCH IF IT IS CLEAR
6418 045654      013746 002114      PRINTF     #BYPASS,L$TEST      ;PRINT THE TEST BYPASSED MESSAGE
6419 045660      012746 021001      MOV        L$TEST,-(SP)
6420 045664      012746 000002      MOV        #BYPASS,-(SP)
6421 045670      010600          MOV        #2,-(SP)
6422 045672      104417          MOV        SP,R0
6423 045674      062706 000006      TRAP      C$PNTF
6424 045700      000137 046222      ADD        #6,SP
6425          JMP        T7EXIT          ;GET OUT
6426 045704      005737 003524      START7: TST      UDROP          ;HAVE ALL UNITS BEEN DROPPED ?
6427 045710      001014          BNE       5$                  ;GO START THE TEST
6428 045712      013746 002114      PRINTF     #BYPASS,L$TEST      ;PRINT THE TEST BYPASSED MESSAGE
6429 045716      012746 021001      MOV        L$TEST,-(SP)
6430 045722      012746 000002      MOV        #BYPASS,-(SP)
6431 045726      010600          MOV        #2,-(SP)
6432 045730      104417          MOV        SP,R0
6433 045732      062706 000006      TRAP      C$PNTF
6434 045736      000137 046222      ADD        #6,SP
6435          JMP        T7EXIT          ;GET OUT IF NONE LEFT TO TEST
6436 045742      105737 002212      5$:      TSTB     CLOCK          ;IS THE CLOCK ENABLED
6437 045746      001421          BEQ       G07                 ;NO, THEN CAN'T PRINT TIME
6438 045750      005046          PRINTF    #TIME,<B,HOURS>,<B,MINUTE>,<B,SECOND>,
6439 045752      153716 002215      CLR        -(SP)
6440 045756      005046          BISB     SECOND,(SP)
6441 045760      153716 002214      CLR        -(SP)
6442 045764      005046          BISB     MINUTE,(SP)
6443 045766      153716 002213      CLR        -(SP)
6444 045772      012746 020044      BISB     HOURS,(SP)
6445 045776      012746 000004      MOV        #TIME,-(SP)
6446 046002      010600          MOV        #4,-(SP)
6447 046004      104417          MOV        SP,R0
6448 046006      062706 000012      TRAP      C$PNTF
6449          ADD        #12,SP
6450 046012      005037 003410      G07:     CLR      BRCNT          ; CLEAR THE BRANCH COUNTER
6451 046016      012705 002232      MOV      #T7TBL,R5          ;POINT R5 TO TEST 7 TABLE
6452 046022      005037 003440      CLR      TSTMSK            ;NO ALLOWABLE ERRORS
6453 046026      052737 000001 003440      BIS      #LEDB,TSTMSK       ;SET UP TO ALLOW LEOT DETECTED
6454 046034      004737 033556      10$:     JSR      PC,SDSTUP      ;SET UP THE RANDOM SEEDS
6455 046040      004737 033706      JSR      PC,PATCLR          ;USE THE SAME PATTERN

```



```

6484
6486
6497
6498
6526
6527 046234
6528
6529
6530
6531
6532
6533
6534
6535
6536
6537
6538 046234
        046234 000032
        046236
6539
6540 046236
        046236 000031
        046240 046262
        046242 160002
        046244 177564
6541 046246
        046246 001032
        046250 046277
        046252 000777
        046254 000000
        046256 000251
6542
6543 046260
        046260 021004
6544
6545
6546 046262 124 113 111 TKIPAD: .ASCIZ ?TKIP ADDRESS?
6547 046277 124 057 115 TKUNT: .ASCIZ ?T/MSCP UNIT NUMBER?
6548 .EVEN
6549 046322
        046322
        ENDHRD
        .EVEN
        L10024:

```

```

.TITLE PARAMETER CODING
.SBTTL  HARDWARE PARAMETER CODING SECTION
      BGNMOD

```

```

; **
; THE HARDWARE PARAMETER CODING SECTION CONTAINS MACROS
; THAT ARE USED BY THE SUPERVISOR TO BUILD P-TABLES.  THE
; MACROS ARE NOT EXECUTED AS MACHINE INSTRUCTIONS BUT ARE
; INTERPRETED BY THE SUPERVISOR AS DATA STRUCTURES.  THE
; MACROS ALLOW THE SUPERVISOR TO ESTABLISH COMMUNICATIONS
; WITH THE OPERATOR.
; --

```

```

      BGNHRD
      .WORD L10024-L$HARD/2
L$HARD::
      GPRMA  TKIPAD,0,0,160002,177564,YES
      .WORD  T$CODE
      .WORD  TKIPAD
      .WORD  T$LLOLIM
      .WORD  T$HILIM
      GPRMD  TKUNT,2,0,777,0,251,YES
      .WORD  T$CODE
      .WORD  TKUNT
      .WORD  777
      .WORD  T$LLOLIM
      .WORD  T$HILIM

```

```

EXIT HRD
.WORD  T$CODE

```

6551
6552
6553
6554
6555
6556
6557
6558
6559
6560
6561
6562 046322
046322 001107
046324
6563
6564 046324
046324 000130
046326 047210
046330 000001
6565 046332
046332 013044
6566 046334
046334 000052
046336 047241
046340 177400
046342 000000
046344 000030
6567 046346
046346 001052
046350 047323
046352 000377
046354 000000
046356 000074
6568
6569 046360
046360 002130
046362 047370
046364 000400
6570 046366
046366 012044
6571 046370
046370 003130
046372 047425
046374 000001
6572 046376
046376 003130
046400 047471
046402 000400
6573 046404
046404 004130
046406 047533
046410 000001
6574
6575 046412
046412 004130
046414 047562
046416 000400

.SBTTL SOFTWARE PARAMETER CODING SECTION

```

; **
; THE SOFTWARE PARAMETER CODING SECTION CONTAINS MACROS
; THAT ARE USED BY THE SUPERVISOR TO BUILD P-TABLES. THE
; MACROS ARE NOT EXECUTED AS MACHINE INSTRUCTIONS BUT ARE
; INTERPRETED BY THE SUPERVISOR AS DATA STRUCTURES. THE
; MACROS ALLOW THE SUPERVISOR TO ESTABLISH COMMUNICATIONS
; WITH THE OPERATOR.
; --

```

```

BGNSFT
.WORD L10025-L$SOFT/2
L$SOFT::
GPRML ECLK,0,1,YES
.WORD T$CODE
.WORD ECLK
.WORD 1
XFERF 5$
.WORD T$CODE
GPRMD HOUR,0,D,177400,0,24.,YES
.WORD T$CODE
.WORD HOUR
.WORD 177400
.WORD T$LOLIM
.WORD T$HILIM
GPRMD MINT,2,D,000377,0,60.,YES
.WORD T$CODE
.WORD MINT
.WORD 000377
.WORD T$LOLIM
.WORD T$HILIM
5$: GPRML CTPA,4,400,YES
.WORD T$CODE
.WORD CTPA
.WORD 400
XFERF 10$
.WORD T$CODE
GPRML SERR,6,1,YES
.WORD T$CODE
.WORD SERR
.WORD 1
GPRML SERC,6,400,YES
.WORD T$CODE
.WORD SERC
.WORD 400
GPRML PADD,10,1,YES
.WORD T$CODE
.WORD PADD
.WORD 1
10$: GPRML PRPA,10,400,YES
.WORD T$CODE
.WORD PRPA
.WORD 400

```

6576	046420		XFERF	15\$
	046420	024044	.WORD	T\$CODE
6577	046422		GPRML	SOER,12,1,YES
	046422	005130	.WORD	T\$CODE
	046424	047615	.WORD	SOER
	046426	000001	.WORD	1
6578	046430		XFERT	11\$
	046430	004024	.WORD	T\$CODE
6579	046432		GPRML	SRER,12,400,YES
	046432	005130	.WORD	T\$CODE
	046434	047660	.WORD	SRER
	046436	000400	.WORD	400
6580	046440		11\$: GPRML	CLMD,14,1,YES
	046440	006130	.WORD	T\$CODE
	046442	047717	.WORD	CLMD
	046444	000001	.WORD	1
6581	046446		GPRML	MDTB,14,400,YES
	046446	006130	.WORD	T\$CODE
	046450	047766	.WORD	MDTB
	046452	000400	.WORD	400
6582	046454		GPRML	NOCL,16,1,YES
	046454	007130	.WORD	T\$CODE
	046456	050026	.WORD	NOCL
	046460	000001	.WORD	1
6583	046462		GPRML	PDMP,16,400,YES
	046462	007130	.WORD	T\$CODE
	046464	050071	.WORD	PDMP
	046466	000400	.WORD	400
6584				
6585	046470		15\$: GPRML	TSPA,20,1,YES
	046470	010130	.WORD	T\$CODE
	046472	050134	.WORD	TSPA
	046474	000001	.WORD	1
6586	046476		XFERF	20\$
	046476	023044	.WORD	T\$CODE
6587	046500		GPRMD	PATE,20,0,177400,0,7,YES
	046500	010032	.WORD	T\$CODE
	046502	050163	.WORD	PATE
	046504	177400	.WORD	177400
	046506	000000	.WORD	T\$LOLIM
	046510	000007	.WORD	T\$HILIM
6588	046512		GPRML	T3ON,22,1,YES
	046512	011130	.WORD	T\$CODE
	046514	050201	.WORD	T3ON
	046516	000001	.WORD	1
6589	046520		GPRML	TSCP,22,400,YES
	046520	011130	.WORD	T\$CODE
	046522	050222	.WORD	TSCP
	046524	000400	.WORD	400
6590	046526		GPRML	BDMP,24,1,YES
	046526	012130	.WORD	T\$CODE
	046530	050262	.WORD	BDMP
	046532	000001	.WORD	1
6591	046534		GPRML	CHGF,24,400,YES
	046534	012130	.WORD	T\$CODE
	046536	050326	.WORD	CHGF
	046540	000400	.WORD	400

6592	046542		XFERT	25\$
	046542	002024	.WORD	T\$CODE
6593	046544		20\$: XFER	SFTEX1
	046544	076004	.WORD	T\$CODE
6594				
6595	046546		25\$: GPRMD	CMD1,26,0,000377,0,377,YES
	046546	013032	.WORD	T\$CODE
	046550	050470	.WORD	CMD1
	046552	000377	.WORD	000377
	046554	000000	.WORD	T\$LLOLIM
	046556	000377	.WORD	T\$HILIM
6596	046560		GPRMD	DPAT,26,0,177400,0,7,YES
	046560	013032	.WORD	T\$CODE
	046562	050362	.WORD	DPAT
	046564	177400	.WORD	177400
	046566	000000	.WORD	T\$LLOLIM
	046570	000007	.WORD	T\$HILIM
6597	046572		GPRMD	ICNT,30,D,177777,0,MAXBUF,YES
	046572	014052	.WORD	T\$CODE
	046574	050401	.WORD	ICNT
	046576	177777	.WORD	177777
	046600	000000	.WORD	T\$LLOLIM
	046602	020000	.WORD	T\$HILIM
6598	046604		GPRMD	ITER,32,D,177777,0,65000,YES
	046604	015052	.WORD	T\$CODE
	046606	050443	.WORD	ITER
	046610	177777	.WORD	177777
	046612	000000	.WORD	T\$LLOLIM
	046614	065000	.WORD	T\$HILIM
6599				
6600	046616		GPRMD	CMD2,34,0,000377,0,377,YES
	046616	016032	.WORD	T\$CODE
	046620	050476	.WORD	CMD2
	046622	000377	.WORD	000377
	046624	000000	.WORD	T\$LLOLIM
	046626	000377	.WORD	T\$HILIM
6601	046630		GPRMD	DPAT,34,0,177400,0,7,YES
	046630	016032	.WORD	T\$CODE
	046632	050362	.WORD	DPAT
	046634	177400	.WORD	177400
	046636	000000	.WORD	T\$LLOLIM
	046640	000007	.WORD	T\$HILIM
6602	046642		GPRMD	ICNT,36,D,177777,0,MAXBUF,YES
	046642	017052	.WORD	T\$CODE
	046644	050401	.WORD	ICNT
	046646	177777	.WORD	177777
	046650	000000	.WORD	T\$LLOLIM
	046652	020000	.WORD	T\$HILIM
6603	046654		GPRMD	ITER,40,D,177777,0,65000,YES
	046654	020052	.WORD	T\$CODE
	046656	050443	.WORD	ITER
	046660	177777	.WORD	177777
	046662	000000	.WORD	T\$LLOLIM
	046664	065000	.WORD	T\$HILIM
6604				
6605	046666		GPRMD	CMD3,42,0,000377,0,377,YES
	046666	021032	.WORD	T\$CODE

	046670	050504	.WORD	CMD3
	046672	000377	.WORD	000377
	046674	000000	.WORD	T\$LOLIM
	046676	000377	.WORD	T\$HILIM
6606	046700		GPRMD	DPAT,42,0,177400,0,7,YES
	046700	021032	.WORD	T\$CODE
	046702	050362	.WORD	DPAT
	046704	177400	.WORD	177400
	046706	000000	.WORD	T\$LOLIM
	046710	000007	.WORD	T\$HILIM
6607	046712		GPRMD	ICNT,44,D,177777,0,MAXBUF,YES
	046712	022052	.WORD	T\$CODE
	046714	050401	.WORD	ICNT
	046716	177777	.WORD	177777
	046720	000000	.WORD	T\$LOLIM
	046722	020000	.WORD	T\$HILIM
6608	046724		GPRMD	ITER,46,D,177777,0,65000,YES
	046724	023052	.WORD	T\$CODE
	046726	050443	.WORD	ITER
	046730	177777	.WORD	177777
	046732	000000	.WORD	T\$LOLIM
	046734	065000	.WORD	T\$HILIM
6609	046736		XFER	CONT1
	046736	002004	.WORD	T\$CODE
6610				
6611	046740		SFTEX1: XFER	SFTEX2
	046740	076004	.WORD	T\$CODE
6612				
6613	046742		CONT1: GPRMD	CMD4,50,0,000377,0,377,YES
	046742	024032	.WORD	T\$CODE
	046744	050512	.WORD	CMD4
	046746	000377	.WORD	000377
	046750	000000	.WORD	T\$LOLIM
	046752	000377	.WORD	T\$HILIM
6614	046754		GPRMD	DPAT,50,0,177400,0,7,YES
	046754	024032	.WORD	T\$CODE
	046756	050362	.WORD	DPAT
	046760	177400	.WORD	177400
	046762	000000	.WORD	T\$LOLIM
	046764	000007	.WORD	T\$HILIM
6615	046766		GPRMD	ICNT,52,D,177777,0,MAXBUF,YES
	046766	025052	.WORD	T\$CODE
	046770	050401	.WORD	ICNT
	046772	177777	.WORD	177777
	046774	000000	.WORD	T\$LOLIM
	046776	020000	.WORD	T\$HILIM
6616	047000		GPRMD	ITER,54,D,177777,0,65000,YES
	047000	026052	.WORD	T\$CODE
	047002	050443	.WORD	ITER
	047004	177777	.WORD	177777
	047006	000000	.WORD	T\$LOLIM
	047010	065000	.WORD	T\$HILIM
6617				
6618	047012		GPRMD	CMD5,56,0,000377,0,377,YES
	047012	027032	.WORD	T\$CODE
	047014	050520	.WORD	CMD5
	047016	000377	.WORD	000377

	047020	000000		.WORD	T\$LOLIM
	047022	000377		.WORD	T\$HILIM
6619	047024			GPRMD	DPAT,56,0,177400,0,7,YES
	047024	027032		.WORD	T\$CODE
	047026	050362		.WORD	DPAT
	047030	177400		.WORD	177400
	047032	000000		.WORD	T\$LOLIM
	047034	000007		.WORD	T\$HILIM
6620	047036			GPRMD	ICNT,60,D,177777,0,MAXBUF,YES
	047036	030052		.WORD	T\$CODE
	047040	050401		.WORD	ICNT
	047042	177777		.WORD	177777
	047044	000000		.WORD	T\$LOLIM
	047046	020000		.WORD	T\$HILIM
6621	047050			GPRMD	ITER,62,D,177777,0,65000,YES
	047050	031052		.WORD	T\$CODE
	047052	050443		.WORD	ITER
	047054	177777		.WORD	177777
	047056	000000		.WORD	T\$LOLIM
	047060	065000		.WORD	T\$HILIM
6622					
6623	047062			GPRMD	CMD6,64,0,000377,0,377,YES
	047062	032032		.WORD	T\$CODE
	047064	050526		.WORD	CMD6
	047066	000377		.WORD	000377
	047070	000000		.WORD	T\$LOLIM
	047072	000377		.WORD	T\$HILIM
6624	047074			GPRMD	DPAT,64,0,177400,0,7,YES
	047074	032032		.WORD	T\$CODE
	047076	050362		.WORD	DPAT
	047100	177400		.WORD	177400
	047102	000000		.WORD	T\$LOLIM
	047104	000007		.WORD	T\$HILIM
6625	047106			GPRMD	ICNT,66,D,177777,0,MAXBUF,YES
	047106	033052		.WORD	T\$CODE
	047110	050401		.WORD	ICNT
	047112	177777		.WORD	177777
	047114	000000		.WORD	T\$LOLIM
	047116	020000		.WORD	T\$HILIM
6626	047120			GPRMD	ITER,70,D,177777,0,65000,YES
	047120	034052		.WORD	T\$CODE
	047122	050443		.WORD	ITER
	047124	177777		.WORD	177777
	047126	000000		.WORD	T\$LOLIM
	047130	065000		.WORD	T\$HILIM
6627	047132			XFER	CONT2
	047132	002004		.WORD	T\$CODE
6628					
6629	047134		SFTEX2:	XFER	SFTEX3
	047134	025004		.WORD	T\$CODE
6630					
6631	047136		CONT2:	GPRMD	CMD7,72,0,000377,0,377,YES
	047136	035032		.WORD	T\$CODE
	047140	050534		.WORD	CMD7
	047142	000377		.WORD	000377
	047144	000000		.WORD	T\$LOLIM
	047146	000377		.WORD	T\$HILIM

6632	047150				GPRMD	DPAT,72,0,177400,0,7,YES
	047150	035032			.WORD	T\$CODE
	047152	050362			.WORD	DPAT
	047154	177400			.WORD	177400
	047156	000000			.WORD	T\$LOLIM
	047160	000007			.WORD	T\$HILIM
6633	047162				GPRMD	ICNT,74,D,177777,0,MAXBUF,YES
	047162	036052			.WORD	T\$CODE
	047164	050401			.WORD	ICNT
	047166	177777			.WORD	177777
	047170	000000			.WORD	T\$LOLIM
	047172	020000			.WORD	T\$HILIM
6634	047174				GPRMD	ITER,76,D,177777,0,65000,YES
	047174	037052			.WORD	T\$CODE
	047176	050443			.WORD	ITER
	047200	177777			.WORD	177777
	047202	000000			.WORD	T\$LOLIM
	047204	065000			.WORD	T\$HILIM
6635						
6636	047206				SFTEX3: XFER	SFTEX4
	047206	070004			.WORD	T\$CODE
6637						
6638	047210	105	116	101	ECLK: .ASCIZ	/ENABLE TIME OF DAY CLOCK/
6639	047241	040	111	116	HOUR: .ASCIZ	/ INPUT HOUR IN 24 HOUR FORMAT (OMIT LEADING ZERO)/
6640	047323	040	111	116	MINT: .ASCIZ	/ INPUT MINUTES (OMIT LEADING ZERO)/
6641					.EVEN	
6642						
6643	047366				SFTEX4: XFER	SFTEX5
	047366	075004			.WORD	T\$CODE
6644						
6645	047370	103	110	101	CTPA: .ASCIZ	/CHANGE CONTROLLER PARAMETERS/
6646	047425	040	105	116	SERR: .ASCIZ	/ ENABLE CONTROLLER ERROR CORRECTION/
6647	047471	040	105	116	SERC: .ASCIZ	/ ENABLE CONTROLLER ERROR RECOVERY/
6648	047533	040	105	116	PADD: .ASCIZ	/ ENABLE PAD BLOCKING/
6649					.EVEN	
6650						
6651	047560				SFTEX5: XFER	SFTEX6
	047560	102004			.WORD	T\$CODE
6652						
6653	047562	103	110	101	PRPA: .ASCIZ	/CHANGE PRINTING PARAMETERS/
6654	047615	040	105	116	SOER: .ASCIZ	/ ENABLE SOFT ERROR REPORT PRINTING/
6655	047660	040	040	105	SRER: .ASCIZ	/ ENABLE READ SOFT ERRORS ONLY/
6656	047717	040	105	116	CLMD: .ASCIZ	/ ENABLE CLEAR MEDIA TABLE EVERY PASS/
6657					.EVEN	
6658						
6659	047764				SFTEX6: XFER	SFTEX7
	047764	063004			.WORD	T\$CODE
6660						
6661	047766	040	105	116	MDTB: .ASCIZ	/ ENABLE PRINTING OF MEDIA TABLE/
6662	050026	040	105	116	NOCL: .ASCIZ	/ ENABLE CLEAR STATS ON FATAL ERROR/
6663	050071	040	105	116	PDMP: .ASCIZ	/ ENABLE VARIABLES DUMP ON ERROR/
6664					.EVEN	
6665						
6666	050132				SFTEX7: XFER	SFTEX8
	050132	113004			.WORD	T\$CODE
6667						
6668	050134	103	110	101	TSPA: .ASCIZ	/CHANGE TEST PARAMETERS/

```

6669 050163      040      104      101 PATE:  .ASCIZ / DATA PATTERN/
6670 050201      040      122      125 T3ON:  .ASCIZ / RUN TEST 3 ONLY/
6671 050222      040      105      116 T5CP:  .ASCIZ / ENABLE DATA COMPARES IN TEST 5/
6672 050262      040      105      116 BDMP:  .ASCIZ / ENABLE PRINT READ BUFFER IN TEST 5/
6673 050326      040      103      110 CHGF:  .ASCIZ / CHANGE COMMAND SEQUENCE/
6674
6675
6676 050360      043004      SFTEX8: XFER      SFTEX9
        050360      .WORD      T$CODE
6677
6678 050362      040      040      104 DPAT:  .ASCIZ / DATA PATTERN/
6679 050401      040      040      111 ICNT:  .ASCIZ / ITEM COUNT (BYTE,RECORD,OBJECT)/
6680 050443      040      040      111 ITER:  .ASCIZ / ITERATION COUNT/
6681
6682
6683 050466      026004      SFTEX9: XFER      SFTEXT
        050466      .WORD      T$CODE
6684
6685 050470      103      115      104 CMD1:  .ASCIZ "CMD/1"
6686 050476      103      115      104 CMD2:  .ASCIZ "CMD/2"
6687 050504      103      115      104 CMD3:  .ASCIZ "CMD/3"
6688 050512      103      115      104 CMD4:  .ASCIZ "CMD/4"
6689 050520      103      115      104 CMD5:  .ASCIZ "CMD/5"
6690 050526      103      115      104 CMD6:  .ASCIZ "CMD/6"
6691 050534      103      115      104 CMD7:  .ASCIZ "CMD/7"
6692
6693
6694 050542      SFTEXT:
6695 050542      ENDSFT
        .EVEN
        050542      L10025:
6696
6703
6704 050542      ENDMOD
6705
6706 050542      .BLKW      4
6707 050552      RDBUF::    .BLKW      10000 ;READ BUFFER
6708 070552      WRTBUF::   .BLKW      10000 ;WRITE BUFFER
6709
6710 110552      MEDIAS::   .BLKW      1296. ;MEDIA STATISTICS TABLE
6711
6712 115612      PATCH::    .BLKW      50 ;PATCH SPACE
6713
6714
6715 115732      LASTAD
        .EVEN
        115732 115746 .WORD T$FREE
        115734 000004 .WORD T$SIZE
        115736 L$LAST::
6716
6717 115736      BGNSETUP      1 ;NUMBER OF P-TABLES
6718 115736      BGNPTAB
        115736 000000 .WORD      0
        115740 000002 .WORD      L10030-./2-1
        115742 L10026:
6719 115742      174500 .WORD      174500 ;IP ADDRESS
6720 115744      000000 .WORD      0 ;UNIT NUMBER
    
```

6721	115746		ENDPTAB
	115746	L10030:	
6722	115746		ENDSETUP
6723		.END	
	000001		

PARAMETER CODING
Symbol table

ABO = 000200 G	BYPASS 021001 G	CMR = 000031 G	C\$GETW= 000027	DRBSTP= 000104 G
ABOER 011525	BYTADD 003446 G	CMSTSV 010550 G	C\$GMAN= 000043	DRERFL= 000010 G
ABOR 025346	BYTCNT 022124 G	CNTEL 013145	C\$GPHR= 000042	DRINUS 003350 G
ABORT = 000004 G	BYTES 003416 G	CNTER 011674	C\$GPRI= 000040	DROP = 000010 G
ABOT 010662 G	CDRECV 023710 G	CNTERL 011172	C\$INIT= 000011	DROPIT= 000400 G
ACC = 000040 G	CDRENO 010312 G	CNTFLG 010562 G	C\$INLP= 000020	DROPPD= 000104 G
ACCESS 024522	CDREN1 010376 G	CNTHI 010554 G	C\$MANI= 000050	DROPUN 040442 G
ACR = 000041 G	CDREN2 010462 G	CNTLEL 013172	C\$MAP = 000102	DRSPB0 004032 G
ADJUST 027142	CDREN3 010546 G	CNTLER 011132	C\$MEM = 000031	DRSPB1 005072 G
ADR = 000020 G	CDSRGO 010272 G	CNTT 010762 G	C\$MMU = 000103	DRSPB2 006132 G
ALLPAT= 000200 G	CDSRG1 010356 G	CNUSAV= 000014 G	C\$MSG = 000023	DRSPB3 007172 G
ASSEMB= 000010	CDSRG2 010442 G	COLSAV= 000016 G	C\$OPNR= 000034	DRVEL 013125
AVALAB 025026	CDSRG3 010526 G	COMEXI 025700	C\$OPNW= 000104	DRVER 011715
AVB = 000001 G	CF.ATN= 000200 G	CONID = 177777 G	C\$PNTB= 000014	DRVERL 011162
AVL = 000130 G	CF.MSC= 000100 G	CONTPA 002217 G	C\$PNTF= 000017	DRVT 010772 G
AVLB = 000040 G	CF.OTH= 000040 G	CONTRV 020532 G	C\$PNTS= 000016	DSPSTP= 000004 G
AVLER 011556	CF.THS= 000020 G	CONT1 046742	C\$PNTX= 000015	DSRNG0 010226 G
AVLT 010702 G	CHGF 050326	CONT2 047136	C\$PUTB= 000072	DSRNG1 010312 G
AVU = 000134 G	CHGFLG 002237 G	CORDMP 033734	C\$PUTW= 000073	DSRNG2 010376 G
BADEL 013233	CHODAT 024502	COREL 012627	C\$QIO = 000377	DSRNG3 010462 G
BADER 011643	CLMD 047717	CORERL 011232	C\$RDBU= 000007	DSTEL 013103
BADERL 011142	CLOCK 002212 G	COUNT 003404 G	C\$REFG= 000047	DTCPER= 000070 G
BDMP 050262	CLREOT 033456 G	COUNTS 020202 G	C\$REL = 000077	DUMP 020347 G
BIT0 = 000001 G	CLRMED 002226 G	CPRIEX 014350	C\$RESE= 000033	DUMPKT 003344 G
BIT00 = 000001 G	CLSDRV 023444 G	CRD = 177776 G	C\$REVI= 000004	DUMP1 020430 G
BIT01 = 000002 G	CMD = 000000 G	CRDLIM 010571 G	C\$RFLA= 000021	DUMP2 020471 G
BIT02 = 000004 G	CMDASC 011322 G	CTPA 047370	C\$RPT = 000025	ECBEL 013001
BIT03 = 000010 G	CMDBF1 003566 G	C\$AU = 000052	C\$SEFG= 000046	ECBERL 011272
BIT04 = 000020 G	CMDBF2 003636 G	C\$AUTO= 000061	C\$SPRI= 000041	ECCBC = 000036 G
BIT05 = 000040 G	CMDBF3 003706 G	C\$BRK = 000022	C\$SVEC= 000037	ECCDC = 000026 G
BIT06 = 000100 G	CMDBF4 003756 G	C\$BSEG= 000004	C\$TOME= 000076	ECCFLG= 000100 G
BIT07 = 000200 G	CMDBLD 022002 G	C\$BSUB= 000002	DATAEL 031424	ECCTC = 000030 G
BIT08 = 000400 G	CMDCNT 003400 G	C\$CLCK= 000062	DATBL 003472 G	ECDEL 012663
BIT09 = 001000 G	CMDER 011502	C\$CLEA= 000012	DATER 011630	ECDERL 011312
BIT1 = 000002 G	CMDLST= 000001 G	C\$CLOS= 000035	DATPAT= 000001 G	ECLK 047210
BIT10 = 002000 G	CMDONE= 000200 G	C\$CLP1= 000006	DATT 010742 G	ECTEL 012707
BIT11 = 004000 G	CMDSEQ= 000006 G	C\$CPBF= 000074	DAY 020125 G	ECTERL 011302
BIT12 = 010000 G	CMDSSV= 000012 G	C\$CPME= 000075	DAYS 003564 G	EC1COR= 000050 G
BIT13 = 020000 G	CMDT 010652 G	C\$CVEC= 000036	DCBEND 004032 G	EC2COR= 000052 G
BIT14 = 040000 G	CMDTBL 024366	C\$DCLN= 000044	DCBSTP= 000050 G	EDEXT 031232
BIT15 = 100000 G	CMD1 050470	C\$DODU= 000051	DCB3SP= 000170 G	EDLEXT 032030
BIT2 = 000004 G	CMD2 050476	C\$DRPT= 000024	DCMDFB 003572 G	EF.CON= 000036 G
BIT3 = 000010 G	CMD3 050504	C\$DU = 000053	DCMPER 012507	EF.EOT= 000010 G
BIT4 = 000020 G	CMD4 050512	C\$EDIT= 000000	DCMPT 011112 G	EF.LOG= 000040 G
BIT5 = 000040 G	CMD5 050520	C\$ERDF= 000055	DEVERR 013272 G	EF.NEW= 000035 G
BIT6 = 000100 G	CMD6 050526	C\$ERHR= 000056	DEVEXT 014400	EF.PWR= 000034 G
BIT7 = 000200 G	CMD7 050534	C\$ERRO= 000060	DEVFAT= 000001 G	EF.RES= 000037 G
BIT8 = 000400 G	CMLSER 012213	C\$ERSF= 000054	DFPTBL 002204 G	EF.SEX= 000020 G
BIT9 = 001000 G	CMDSQ 021406 G	C\$ERSO= 000057	DIAGMC= 000000	EF.STA= 000040 G
BOE = 000400 G	CMP = 000030 G	C\$ESCA= 000010	DMPBUF 002236 G	ELTEXT 032156
BOTER 011751	CMPDAT 032552 G	C\$ESEG= 000005	DMPFLG 002231 G	ENDPAT= 000010 G
BOTT 011012 G	CMPEL 013030	C\$ESUB= 000003	DPAT 050362	EOT = 000004 G
BRCNT 003410 G	CMPER 012464	C\$ETST= 000001	DQCMD 027662 G	EOTBIT= 000002 G
BUFADR 003422 G	CMPERL 011152	C\$EXIT= 000032	DRBENO 005072 G	EOTPR = 000010 G
BUFDMP 034066	CMPEL 013030	C\$FREQ= 000101	DRBEN1 006132 G	ERASE 024750
BUFDSC 025616	CMPPRR 003444 G	C\$FRME= 000100	DRBEN2 007172 G	ERASGP 025006
BUFOFF= 000012 G	CMPT 010732 G	C\$GETB= 000026	DRBEN3 010232 G	ERG = 000120 G

ERI = 000113 G	EXC3A4 027362	G\$EXCP= 000400	IONORM= 000000 G	LUN0 002314 G
ERLGER 014502 G	EXC4A1 027404	G\$HILI= 000002	IOPDRE= 000003 G	LUN1 002506 G
ERL00 017146 G	EXIT 025722	G\$LOLI= 000001	IOSTAT 010546 G	LUN2 002700 G
ERL01 017203 G	EXTCLN 040434	G\$NO = 000000	IOTIME= 000004 G	LUN3 003072 G
ERL02 017301 G	EXTINT 040332	G\$OFFS= 000400	ISR = 000100 G	L\$ACP 002110 G
ERL03 017365 G	EXTSRT 032514	G\$OFFSI= 000376	ISTART 037742	L\$APT 002036 G
ERL04 017454 G	EX3REW 044204	G\$PRMA= 000001	ITER 050443	L\$AU 040706 G
ERL05 017540 G	E\$END = 002100	G\$PRMD= 000002	ITERS 003420 G	L\$AUT 002070 G
ERL06 017627 G	E\$LOAD= 000035	G\$PRML= 000000	ITMCNT= 000002 G	L\$AUTO 040370 G
ERL07 017713 G	FAIL = 000020 G	G\$RADA= 000140	ITMOFF= 000002 G	L\$CCP 002106 G
ERL08 017743 G	FLAG = 040000 G	G\$RADB= 000000	ITRCNT= 000004 G	L\$CLEA 040372 G
ERR = 100000 G	FMTER 011731	G\$RADD= 000040	IVSER 012135	L\$CO 002032 G
ERRBLK 013270 G	FMTT 011002 G	G\$RADL= 000120	IVST1 010712 G	L\$DEPO 002011 G
ERRDEC 030304 G	FM.BAD= 000001 G	G\$RADO= 000020	IVST2 011032 G	L\$DESC 002142 G
ERRDEI 030774 G	FM.CNT= 000000 G	G\$XFER= 000004	IVST3 011102 G	L\$DESP 002076 G
ERRDEL 031236 G	FM.TPE= 000005 G	G\$YES = 000010	IXE = 004000 G	L\$DEVP 002060 G
ERREXT 031014	F\$AU = 000015	HARD = 000002 G	I\$AU = 000041	L\$DISP 002124 G
ERRLOG= 040000 G	F\$AUTO= 000020	HDLEXT 021236	I\$AUTO= 000041	L\$DLY 002116 G
ERRMSG 013266 G	F\$BGN = 000040	HELP = 000000	I\$CLN = 000041	L\$DTP 002040 G
ERRNBR 013264 G	F\$CLEA= 000007	HEXTBL 011442 G	I\$DU = 000041	L\$DTYP 002034 G
ERRTLY 032036 G	F\$DU = 000016	HIADDR= 000002 G	I\$HRD = 000041	L\$DU 040700 G
ERRTYP 013262 G	F\$END = 000041	HIBYTE= 177777 G	I\$INIT= 000041	L\$DUT 002072 G
ERR00 015770 G	F\$HARD= 000004	HIMEX 003554 G	I\$MOD = 000041	L\$DVTY 002174 G
ERR01 016040 G	F\$HW = 000013	HNDLRP 003412 G	I\$MSG = 000041	L\$EF 002052 G
ERR02 016116 G	F\$INIT= 000006	HOE = 100000 G	I\$PROT= 000040	L\$ENVI 002044 G
ERR03 016175 G	F\$JMP = 000050	HOUR 047241	I\$PTAB= 000041	L\$ERRT 013262 G
ERR04 016253 G	F\$MOD = 000000	HOURS 002213 G	I\$PWR = 000041	L\$ETP 002102 G
ERR05 016332 G	F\$MSG = 000011	HRD = 000007 G	I\$RPT = 000041	L\$EXP1 002046 G
ERR06 016411 G	F\$PROT= 000021	HSTER 012165	I\$SEG = 000041	L\$EXP4 002064 G
ERR07 016461 G	F\$PWR = 000017	HSTIMO= 000000 G	I\$SETU= 000041	L\$EXP5 002066 G
ERR08 016521 G	F\$RPT = 000012	HSTT 010752 G	I\$SFT = 000041	L\$HARD 046236 G
ERR09 016556 G	F\$SEG = 000003	HUNGER 012246	I\$SRV = 000041	L\$HIME 002120 G
ERR10 016617 G	F\$SOFT= 000005	HWR = 000006 G	I\$SUB = 000041	L\$HPCP 002016 G
ERR11 016651 G	F\$SRV = 000010	H1READ= 000054 G	I\$TST = 000041	L\$HPTP 002022 G
ERR12 016675 G	F\$SUB = 000002	H1WRIT= 000060 G	J\$JMP = 000167	L\$HW 002204 G
ERR13 016733 G	F\$SW = 000014	H2READ= 000056 G	KWCSR = 177546 G	L\$ICP 002104 G
ERR14 016764 G	F\$TEST= 000001	H2WRIT= 000062 G	KWHDL 021100 G	L\$INIT 037004 G
ERR15 017012 G	GCMDST 025400	IBE = 010000 G	LEDB = 000001 G	L\$LADP 002026 G
ERR16 017062 G	GCS = 000210 G	ICNT 050401	LEDER 012105	L\$LAST 115736 G
ERR17 017107 G	GCSCFL= 000020 G	IDONE 026502	LEDT 011072 G	L\$LOAD 002100 G
ERS = 000110 G	GCSEXT 027314	IDU = 000040 G	LEOTFL= 000030 G	L\$LUN 002074 G
ERTLY 031142	GCSHDL 026530 G	IER = 020000 G	LF.CON= 000100 G	L\$MREV 002050 G
ETLLY 032120 G	GCSREF 010552 G	ILCMD 025604	LF.SNR= 000001 G	L\$NAME 002000 G
EVENT 003556 G	GCSRFL= 000040 G	ILLCMD= 000007 G	LF.SUC= 000200 G	L\$PRIO 002042 G
EVL = 000004 G	GO = 000001 G	ILOOP 026350	LGPEL 013057	L\$PROT 021036 G
EV.COR= 000150 G	GO1 041060	IMM = 000200 G	LGPERL 011202	L\$PRT 002112 G
EV.CTO= 000052 G	GO2 043262	IMMBIT= 000003 G	LGSTAT 027720 G	L\$REPP 002062 G
EV.DST= 000050 G	GO3 043720	INIT 025342	LINE 020527 G	L\$REV 002010 G
EV.HER= 000213 G	GO4 044434	INITER 012400	LOBYTE= 177776 G	L\$RPT 034210 G
EV.IDS= 000152 G	GO5 045014	INITIT 040336 G	LOE = 040000 G	L\$SOFT 046324 G
EV.LGP= 000010 G	GO6 045334	INT = 000170 G	LOHEX 003552 G	L\$SPC 002056 G
EV.SER= 000153 G	GO7 046012	INTDON= 000001 G	LOOP 026340	L\$SPCP 002020 G
EV.SRI= 000113 G	GUNSTA 025440	INTERR= 000006 G	LOOPS 010560 G	L\$SPTP 002024 G
EV.SRT= 000053 G	GUS = 000220 G	INTTBL 026520	LOT = 000010 G	L\$STA 002030 G
EV.URE= 000350 G	G\$CNTO= 000200	IOERTB 010572 G	LSTENT= 000134 G	L\$SW 002212 G
EXC1A2 027316	G\$DELM= 000372	IOHUNG= 000002 G	LUNFLG= 000026 G	L\$TEST 002114 G
EXC2A3 027340	G\$DISP= 000003	IOICRD= 020000 G	LUNSTP= 000172 G	L\$TIML 002014 G

PARAMETER CODING
Symbol table

MACRO Y05.02 Thursday 18-Apr-85 13:37 Page 85-11

SEQ 177

RNDITR= 000000 G	SFTEX4 047366	ST.CMD= 000001 G	TKINIT= 111400 G	T\$\$SRV= 010006
RNUSAV= 000020 G	SFTEX5 047560	ST.CMP= 000007 G	TKIP = 000000 G	T\$\$SW = 010001
ROLSAV= 000022 G	SFTEX6 047764	ST.CNT= 000012 G	TKIPAD 046262	T\$\$TES= 010023
RSPBF0 004026 G	SFTEX7 050132	ST.DAT= 000010 G	TKSA = 000002 G	T1 040714 G
RSPBF1 005066 G	SFTEX8 050360	ST.DIA= 000037 G	TKUNIT= 000004 G	T1EXIT 042624
RSPBF2 006126 G	SFTEX9 050466	ST.DRV= 000013 G	TKUNT 046277	T1LEOT 042644
RSPBF3 007166 G	SKD = 000062 G	ST.FNT= 000014 G	TMB = 000010 G	T1ONL 042630
RSPCNT 003402 G	SKP = 000060 G	ST.HST= 000011 G	TMCNT 003550 G	T1RD1 043050
RSPHDL 027426 G	SKPTMK 024610	ST.LED= 000023 G	TMER 011771	T1RD2 043056
RS1 = 001233 G	SKR = 000061 G	ST.MFE= 000005 G	TMT 011022 G	T1RD3 043064
RS2 = 007622 G	SLTUSE= 000010 G	ST.MSK= 000037 G	TRK = 000000 G	T1RD4 043072
RS3 = 000000 G	SOER 047615	ST.ONL= 000400 G	TSPA 050134	T1RD5 043100
RTYEC1= 000064 G	SOERRP 002224 G	ST.POL= 000021 G	TSTMSK 003440 G	T1RD6 043106
RTYEC2= 000066 G	SOFT = 000003 G	ST.RDT= 000020 G	TSTSTP= 000006 G	T1REW 042636
RTYEL 012574	SPC = 000050 G	ST.SEX= 000022 G	T\$ARGC= 000004	T1SKD 042776
RTYERL 011252	SPCASC 011346	ST.SUB= 000040 G	T\$CODE= 026004	T1SKP 042660
RWI = 000163 G	SPCOBJ 024664	ST.SUC= 000000 G	T\$ERRN= 000000	T1SKP1 042754
R10 003534 G	SPCREC 024542	ST.TM = 000016 G	T\$EXCP= 000000	T1SKP2 042762
R11 003536 G	SPO = 000070 G	ST.WPR= 000006 G	T\$FLAG= 000041	T1SKR 042666
R12 003540 G	SPR = 000071 G	SUBCNT 003424 G	T\$FREE= 115746	T1SKR1 042724
R3SAVE 003560 G	SRD = 000005 G	SUBITR 023142 G	T\$GMAN= 000000	T1SPC1 042674
R4SAVE 003562 G	SRER 047660	SUBSEC 002216 G	T\$HILI= 065000	T1SPC2 042702
R8 003530 G	SRTBL 031720	SUC = 000150 G	T\$LAST= 000001	T1SPC3 042710
R9 003532 G	START 037044	SUCCESS= 000001 G	T\$LLOI= 000000	T1SP01 042716
SAERR 010566 G	START1 040752	SUNCHR 025162	T\$LSYM= 010000	T1SP02 042732
SAVDIF 003436 G	START2 043154	SUPRES 025650	T\$LTNO= 000007	T1SP03 042740
SCC = 000230 G	START3 043612	SUW = 000155 G	T\$NEST= 177777	T1SPR1 042746
SCD = 000052 G	START4 044326	SVCGBL= 000000	T\$NSO = 000000	T1SPR2 042770
SCHED 021240 G	START5 044706	SVCINS= 000000	T\$NS1 = 000005	T1WR1 043004
SCNTCH 025466	START6 045226	SVCSUB= 000000	T\$PCNT= 000000	T1WR2 043012
SCR = 000051 G	START7 045704	SVCTAG= 000000	T\$PTAB= 010027	T1WR3 043020
SDSAVE 033632 G	STATER 012445	SVCTST= 000000	T\$PTHV= 000001	T1WR4 043026
SDSTUP 033556 G	STATUS= 000004 G	SWR = 000004 G	T\$PTNU= 000001	T1WR5 043034
SECOND 002215 G	STAT0 035464	SYSFAT= 000000 G	T\$SAVL= 177777	T1WR6 043042
SECRNS 003542 G	STAT1 035467	S\$LSYM= 010000	T\$SEGL= 177777	T1WTM 042652
SED1 = 000136 G	STAT10 036222	S1 = 004000 G	T\$SIZE= 000004	T2 043116 G
SED2 = 000140 G	STAT11 036272	S1READ= 000040 G	T\$SUBN= 000000	T2END = 004716 G
SED3 = 000142 G	STAT12 036344	S1WRIT= 000044 G	T\$TAGL= 177777	T2EXIT 043534
SEED1 = 000144 G	STAT13 036405	S2READ= 000042 G	T\$TAGN= 010031	T2LEOT 043560
SEED2 = 000146 G	STAT14 036430	S2WRIT= 000046 G	T\$TEMP= 000000	T2RD 043566
SEED3 = 000150 G	STAT15 036453	TBLBTM= 000132 G	T\$TEST= 000007	T2REW 043544
SELDAT 022212 G	STAT16 036525	TBLEND= 003472 G	T\$TSTM= 177777	T2SKD 043574
SELREC 022644 G	STAT17 036577	TBLFUL 036716 G	T\$TSTS= 000001	T2SPO 043602
SEGER 012347 G	STAT18 036647	TBLFF 003544 G	T\$\$AU = 010014	T2WRT 043552
SERC 047471	STAT2 035533	TBLORT 032162 G	T\$\$AUT= 010011	T3 043612 G
SERCOR 002221 G	STAT3 035600	TBLTOP= 000130 G	T\$\$CLE= 010012	T3EXIT 044220
SEREXC= 000002 G	STAT4 035660	TCNTFL= 000004 G	T\$\$DAT= 010030	T3ON 050201
SERR 047425	STAT5 035705	TESTPA 002232 G	T\$\$DU = 010013	T3ONLY 002234 G
SERREC 002220 G	STAT6 035752	TF.BLK= 000010 G	T\$\$HAR= 010024	T3RD 044252
SEXB = 000004 G	STAT7 036024	TF.GCR= 000004 G	T\$\$HW = 010000	T3REW 044230
SEXER 012063	STAT8 036071	TF.PE = 000002 G	T\$\$INI= 010010	T3SPO 044260
SEXT 011062 G	STAT9 036143	TF.800= 000001 G	T\$\$MSG= 010003	T3WRT 044236
SFPTBL 002212 G	STFPCK 024164 G	TIME 020044 G	T\$\$PC = 000001	T3WTM 044244
SFTEXT 050542	STINIT 037004 G	TIMERR 012312	T\$\$PRO= 010004	T4 044270 G
SFTEX1 046740	ST.ABO= 000002 G	TKERR 026474	T\$\$PTA= 010027	T4EXIT 044620
SFTEX2 047134	ST.AVL= 000004 G		T\$\$RPT= 010007	T4REW 044624
SFTEX3 047206	ST.BOT= 000015 G		T\$\$SOF= 010025	T4WRT 044632

PARAMETER CODING
Symbol table

MACRO Y05.02 Thursday 18-Apr-85 13:37 Page 85-12

SEQ 178

T4WTM 044640	T7CMD2 002246	UF.RMV= 000200 G	URDSRG= 000162 G	WR = 000020 G
T5 044650 G	T7CMD3 002254	UF.VSS= 000040 G	UREEL 012740	WRBYT1= 000120 G
T5CMP 002235 G	T7CMD4 002262	UF.VSU= 020000 G	UREERL 011262	WRBYT2= 000122 G
T5CP 050222	T7CMD5 002270	UF.WPH= 020000 G	URSPBF= 000156 G	WRBYT3= 000124 G
T5EXIT 045146	T7CMD6 002276	UF.WPS= 010000 G	UWHEEL 012760	WRBYT4= 000126 G
T5RD 045160	T7CMD7 002304	UNDROP= 000032 G	UWEERL 011242	WRERL 031504
T5REW 045152	T7END 002312	UNDRUN= 000072 G	U10FF = 005040 G	WRITE 024462
T6 045170 G	T7EXIT 046222	UNITRV 020662 G	U20FF = 002420 G	WRKMSK 003442 G
T6EXIT 045576	T7TBL 002232 G	UNJAM 033242 G	U30FF = 001540 G	WRTBUF 070552 G
T6RD 045630	UAM = 000200 G	UNLBIT= 000004 G	U40FF = 001210 G	WTAPMK 024722
T6REW 045606	UCDEND= 000170 G	UNTEOT 020256 G	WDSTEL 011222	WTM = 000100 G
T6SKD 045636	UCDSRG= 000166 G	UNTLOT 020312 G	WMSPOS= 000100 G	XFERST= 000010 G
T6WRT 045614	UDRNER 012541	UNTSTP= 000002 G	WPRB = 000020 G	X\$ALWA= 000000
T6WTM 045622	UDROP 003524 G	UNTTBL 003360 G	WPRBIT= 000005 G	X\$FALS= 000040
T7 045646 G	UEOT 003526 G	URBEND= 000160 G	WPRER 011603	X\$OFFS= 000400
T7BRFL= 000001 G	UF.CMR= 000001 G	URDEND= 000164 G	WPRT 010722 G	X\$TRUE= 000020
T7CMD1 002240	UF.CMW= 000002 G			

. ABS. 115746 000 (RW,I,GBL,ABS,OVR)
000000 001 (RW,I,LCL,REL,CON)

Errors detected: 0

*** Assembler statistics

Work file reads: 331
Work file writes: 328
Size of work file: 35448 Words (139 Pages)
Size of core pool: 19714 Words (75 Pages)
Operating system: RSX-11M/PLUS (Under VAX/VMS)

Elapsed time: 00:10:26.01
CZTKBA.BIN,CZTKBA.LST/-SP=SVC40R.MLB/ML,CZTKBA