


DZV-11

(4) LINE ASYNCHRONOUS MUX
MD-11-DVDZB-A
TESTS, PART 2 OF 2

EP-DVDZB-A-DL-A
COPYRIGHT 1977
FICHE 1 OF 1

OCT 1977
digital
MADE IN USA



120

B01

EOF10VDZBRSBQ411

00010000

770920

IDENTIFICATION

2HDR10VDZBASE0

00010000

770920
SEQ 0001

PRODUCT CODE: MAINDEC-11-DVDZB-A-D
PRODUCT NAME: DZV11 4 LINE ASYNC MUX TESTS PART 2 OF 2
DATE RELEASED: APRIL 1977
MAINTAINER: DIAGNOSTIC ENGINEERING

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS DOCUMENT.

THE SOFTWARE DESCRIBED IN THIS DOCUMENT IS FURNISHED UNDER A LICENSE AND MAY ONLY BE USED OR COPIED IN ACCORDANCE WITH THE TERMS OF SUCH LICENSE.

DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL.

COPYRIGHT (C) 1977 DIGITAL EQUIPMENT CORPORATION

1. ABSTRACT

The function of the DZV11 diagnostics is to verify the option operates according to specifications. The diagnostics also verify that the DZV11 operates in its environment such as the system in which it is installed.

Parameters may be supplied to the program by either 'AUTO SIZING' or input from the user on the console by having SW00=1 at start time. Auto sizing will be done only the first time the program is started and SW07=0 and SW00=0 and SW03=0. The AUTOSIZER is designed to detect DZV11 device addresses and vectors only. All remaining parameters will default to certain values (see Sec.8.5). Console input may be controlled at any start time through the use of SW00, SW03, SW04, and SW06 (see Sec. 4.1.1 for a detailed description of these switches).

Currently there are three standalone diagnostics (DVDZA, DVDZB, and DVDZC) one system module for DEC X/11 (DZBA), and an overlay for ITEP (DVDZD).

DVDZA together with DVDZB will test all logical functions of the DZV11 interface module.

DVDZC is designed as a non-chainable standalone diagnostic providing the operator with direct control over the testing of all DZV11 EIA cables.

2. REQUIREMENTS

2.1 EQUIPMENT

An LSI11 CPU with minimum 4K of memory.
ASR 33 (or equivalent for console)
DZV11 INTERFACE MODULE
H329 Staggered turnaround connector.
H325 Cable turnaround connector.

NOTE: A staggered turnaround connector is needed in order to test the PARITY logic.

2.2 STORAGE

Program will use all 4K of memory except where ABL and BOOTSTRAP LOADER reside. Location 1500 thru 1740 are especially to be noted and to be untouched by operator after parameters have been input from console (SMOD=1); or after the 'AUTO SIZING' has been done. These locations may be changed if the user understands their meaning and different parameters are required.

3. LOADING PROCEEDURE

3.1 METHOD

All programs are in absolute format and are loaded using the ABSOLUTE LOADER. NOTE: if the diagnostics are on a media such as DISK, MAGTAPE, DECTAPE, or CASSETTE; follow instructions for the monitor which has been provided on that specific media.

ABSOLUTE LOADER starting address #500

MEMORY * SIZE

4k	17
8k	37
12k	57
16k	77
20k	117
24k	137
28k	157

- 3.1.1 Starting the processor at the Absolute Loader starting address will load the diagnostic into memory.

4. STARTING PROCEDURE

- A. Set SMR to zero for 'AUTO SIZING' or set SW00=1 for user parameter input from console terminal. NOTE: loc. 000176 is used as a software Switch Register in all of the DZV11 diagnostics. (see Sec. 4.1)
On the first startup of the diagnostic if SW07=1 and SW00=0 the program will assume that the status table has been already built from a previous DZV11 diagnostic run. NOTE: any DZV11 diagnostic will overlay the status table when loaded to preserve its contents and thus will not alter a previously built table.
- B. Start the diagnostic at Loc. 200(8). The program will type Maindec and program names (if this was the first start up of the program) and also the following: (on the first program run or if parameters were changed)

```
'MAP OF DZV11 STATUS'
1500 160100
1502 000300
1504 000017
1506 017470
1510 000000
```

The above is only an example! This would indicate the status table starting at add. 1500 in the program. THE STATUS TABLE MUST BE VERIFIED BY THE USER IF AUTO SIZING IS DONE. For information of status table see section 8.4 for help.

The program will type "Running" and proceed to run the diagnostic.

4.1 CONTROL SWITCH SETTINGS

NOTE: This program utilizes a Software Switch Register which may be modified by changing Loc. 176 or by typing Control "G" (fG) on the console terminal while the program is running.

```
SW 15 Set: Halt on error
SW 14 Set: Loop on current test
SW 13 Set: Inhibit error print out
SW 12 Set: Inhibit **ALL** type out/bell on error.
SW 11 Set: Inhibit iterations. (quick pass)
SW 10 Set: Escape to next test
SW 09 Set: Loop with current data
SW 08 Set: Catch error and loop on it
SW 07 Set: NO AUTO SIZE. If 1st start of program after loading and
if SW00=0 then the program will assume that the status map
has been built from a previous DZV11 diagnostic run.

SW 06 Set: Reselect DZV11's desired active
SW 05 Set: Reserved
SW 04 Set: Select delay parameter (see SEC. 4.1.1)
SW 03 Set: Extra parameter input (see SEC. 4.1.1)
SW 02 Set: Lock on selected test
SW 01 Set: Restart program at selected test
SW 00 Set: Get users parameters from console
```

4.1.1 SWITCH REGISTER CONTROL OF PARAMETER INPUT FROM CONSOLE

- SW 00 GET USERS PARAMETERS FROM CONSOLE. Setting this switch at start up time allows the user to input at the Console terminal the following parameters: base device address, base vector address, mode of operation (EXTERNAL, INTERNAL, OR STAGGERED), and the number of DZV11's that are running. Using this switch alone will default the following parameters: all 4 lines are set to be tested on each DZV11, the default baud rate is set at 19.2 Kbaud and the character length for the majority of testing is set at eight bits per character with two stop bits.
- SW 03 EXTRA PARAMETER INPUT. Setting this switch at start up time provides the user with the ability to set the lines active for testing and to set the default baud rate used for the majority of the diagnostic tests. The Delay Parameter is automatically adjusted to the baud rate given by the user.
- SW 04 SELECT DELAY PARAMETER. The DELAY parameter this switch controls determines the length of time the program stalls waiting for a character to be completely transmitted or received. This delay count is automatically set to provide enough delay time for the default baud rate specified when running the program on an LS111 with MOS memory. When running this program on a processor with a faster memory speed this delay count should be adjusted proportionately higher than the following defaulted values:
- | | | |
|------|-----------|------------|
| 2450 | ;time for | 50 baud |
| 1560 | ;time for | 75 baud |
| 1120 | ;time for | 110 baud |
| 0750 | ;time for | 134 baud |
| 0660 | ;time for | 150 baud |
| 0330 | ;time for | 300 baud |
| 0150 | ;time for | 600 baud |
| 0060 | ;time for | 1200 baud |
| 0040 | ;time for | 1800 baud |
| 0030 | ;time for | 2000 baud |
| 0020 | ;time for | 2400 baud |
| 0010 | ;time for | 3600 baud |
| 0001 | ;time for | 4800 baud |
| 0001 | ;time for | 7200 baud |
| 0001 | ;time for | 9600 baud |
| 0001 | ;time for | 19.2 kbaud |

4.1.2 SWITCH REGISTER RESTRICTIONS

- SW 06 RESELECT DZV11'S DESIRED ACTIVE. A message is typed out on the console terminal asking the operator to type a bit map of the DZV's desired active. Using this switch allows location DZVACTV to be altered (see Sec. 8.3 for a description of this location).
EXAMPLE:
If the devices corresponding to the DZV11's numbered zero, two, and four in the DZV11 Status Map (Loc. 1500 through 1740) are to be tested, type in: 25
This will set bits zero, two, and four in location DZVACTV. All remaining devices in the status map will then not be tested.
- SW 01 RESTART PROGRAM AT SELECTED TEST it is strongly suggested that at least one pass has been made before trying to select a test that is not in the order of sequence the reason being is that the program has to clear areas and set up parameters.
Note: if running multiple DZV11's; the DZV11 you desire to be under test must be selected by the use of SW06 before locking on the test. In other words; each time the program is started; the first DZV11 will be selected to be under test unless SW06 is used to select only one.
- SW 09 LOOP ON CURRENT DATA: this switch will only work if call 'SCOPI' is in that test. The reason being that most tests deal with blocks of different data to be sent or received all at once thus in block data, one pattern can't be singled out.
This switch is designed to provide an aid for a trained troubleshooter to sample various signals on the module and is not meant to be used as a general user control switch.
- SW 04 SELECT DELAY PARAMETER: THIS SWITCH SHOULD BE USED WITH CARE AS TOO SHORT A DELAY WILL CAUSE VALID TESTS TO FAIL.
(see Sec. 4.1.1)

4.1.3 SWITCH REGISTER PRIORITIES

ERROR SWITCHES

1. SW 12 Delete print out/bell on error.
2. SW 13 Delete error printout.
3. SW 15 Halt on the error.
4. SW 08 Go to beginning of the test(on error).
5. SW 10 Goto next test(on error).

SCOPE SWITCHES

1. SW 09 (if enabled by 'SCOPI'). If an '*' is printed in front of the test no. on an error report (ex. *TEST NO. 10) SW09 is incorporated in that test and therefore SW09 is *usually* the best switch for the scope loop (SW14=0, SW10=0, SW09=1, SW08=0) if the program user is technically trained to electronically isolate signal problems on the DZV11 module. If SW09 is not enabled; and there is a *HARD* error (constant); SW08 is best.
2. For intermittent errors either start the program with SW01 and SW02 set which will allow the user to lock on a selected test, or else set SW14 as an error is being typed out on the terminal. SW14 will continue to loop on that test regardless of whether an error occurs.
3. SW 14 Loop on current test.

4.2 STARTING ADDRESS

SA 200 - The starting address for any DZV11 diagnostic is Loc. 200

NOTE: If address 000042 is non-zero the program assumes it is under ACT11 or XXDP control and will act accordingly. After *ALL* available DZV11s are tested the program will return to 'XXDP' or 'ACT-11'.

5. OPERATING PROCEEDURE

When the program is initially started, messages as described in section four will be printed and the diagnostic will begin running.

5.1 NORMAL START OF DIAGNOSTIC

On the first start of the diagnostic at address 200, if SW00=1 then the following questions are asked and must be answered:

"1ST CSR ADDRESS (160000:163770): "
You must type in the first DZV11 CSR in the system you wish testing to begin at. RANGE: 160000:163770

"1ST VECTOR ADDRESS (300:770): "
You must type in the vector of the first DZV11 in the system under test. RANGE 300:770

"Maintenance Mode
[EXTERNAL <H325> (E)]
[INTERNAL <DZCSR03=1>(I)]
[STAGGERED <H329> (S)] :
Type "E" or "I" or "S" depending on which mode you wish to run in. If running "EXTERNAL"; all selected lines must be terminated by an H325 test connector.

"# OF DZV11'S <IN OCTAL> (1:20): "
Type total number of DZV11's to be tested in the system. RANGE is 1 thru 20 in octal.

***** IF SW03=1 THEN THE FOLLOWING WILL BE PRINTED *****

"LINES ACTIVE BY BIT <IN OCTAL> (001:017):"
Each bit represents a line and any combination of lines may be selected (HOWEVER IN STAGGERED MODE TWO ADJACENT LINES MUST BE SELECTED (0-1, 2-3).

"DEFAULT BAUD RATE <IN OCTAL> (00:17): "
This gives the user a chance to change the default baud rate used in APP. 90% of the test. Baud rate choices are:
"00"(50 baud), "01"(75 baud), "02"(110 baud), "03"(134 baud),
"04"(150 baud), "05"(300 baud), "06"(600 baud), "07"(1200 baud),
"10"(1800 baud), "11"(2000 baud), "12"(2400 baud), "13"(3600 baud),
"14"(4800 baud), "15"(7200 baud), "16"(9600 baud), "17"(19.2 kbaud)
Low default baud rates are not suggested since they lengthen the time to complete a program pass dramatically.

It is important to note that all DZV11's in the system must be CONTIGIOUS for both ADDRESS and VECTORS. Also all the EXTRA PARAMETERS other than CSR and VECTORS are given to the EXISTING DZV11's in the system.

If the mode of operation is different for each DZV11 THIS MUST BE PATCHED INTO THE CORRECT STATUS MAP ENTRY which is printed at start time. An alternative is to put SW00=1 at start time; answer questions about DZV11 under test and INDICATE ONE DZV11 in the system. IF THE STATUS MAP IS TO BE "PATCHED" IT MUST BE DONE AFTER THE QUESTIONS ARE ANSWERED OR AFTER THE AUTO SIZE.

5.2 PROGRAM AND/OR OPERATOR ACTION

The variety of program Control Switches provided in this Diagnostic Package is designed to provide the user with a wide range of trouble-shooting techniques. Before the user attempts to run this diagnostic he should become familiar with the use of these Control Switches and their restrictions. (See Sec. 4.1, 4.1.1, 4.1.2, 4.1.3)

When the program detects an error the TEST NUMBER and PC will be typed out and possibly an error message (depending on the particular error). If it is necessary to know more information concerning the error report then look in the program listing for that TEST NUMBER and then note the PC of the error report. The reason for the error report will become clearer when reading the comments in the program listing.

6. ERRORS

As described previously there will always be a TEST NUMBER and PC typed out at the time of an error (providing SW 13=0 and SW 12=0). In most cases additional information will be supplied to the error message which is to give the operator an indication of the error.

6.1 ERROR RECOVERY

If for some reason the DZV11 should 'HANG THE BUS' (gain control of bus so that console manual functions are inhibited) an init or power down/up is necessary for operator to regain control of cpu. If this should happen; look in location 'STSTNM' (address 1246) for the number of the test that was running at the time of the catastrophic error. In this way the operator will have an idea as to what the DZV11 was doing at the time of the error.

7. RESTRICTIONS

7.1 STARTING RESTRICTIONS

See section 4.1.2
The status table should be verified regardless of how the program was started. Also it is important to use this listing along with the information printed on the TTY to completely isolate problems.

7.2 OPERATING RESTRICTIONS

Parameter must be input from user OR APT if "AUTO SIZING" is not used.

8. MISCELLANEOUS

8.1 EXECUTION TIME

All DZV11 device diagnostics will give an 'END PASS' message (providing no errors and SW12=0) within 2 min. This is assuming SW11=1 (INHIBIT ITERATIONS) is set to give the fastest possible execution.

8.2 PASS COMPLETE

NOTE: #EVERY# time the program is started; the tests will run as if SW11 (delete iterations) was up (=1). This is to 'VERIFY NO *HARD* ERRORS' as soon as possible. Therefore the first pass -EACH TIME PROGRAM IS STARTED- will be a 'QUICK PASS' until all DZV11's in system are tested. When the diagnostic has completed a pass the following is an example of the print out to be expected.

END PASS DVDZB-A CSR: 160100 VEC: 300 PASSES: 000001 ERRORS: 000000

NOTE: The numbers for CSR and VEC are not necessarily the values for the device. They are only for this example.

B.3 KEY LOCATIONS

SLPADR (1252) Contains the address where program will return when iteration count is reached or if loop on test is asserted.

NEXT (1362) Contains the address of the next test to be performed.

STSTNM (1246) Contains the number of the test now being performed.

RUN (1412) The bit in 'RUN' always points one past the DZV11 currently being tested. EXAMPLE: (RUN) 1412/0000000001000000 Means that DZV11 no.5 is the DZV11 now running.

STATUS MAP (1500)-(1740) These locations contain the information needed to test up to 16 (decimal) DZV11s sequentially. they contain the CSR, VECTOR and STATUS concerning the configuration of each DZV11.

DZVACTV(1406) Each bit set in this location indicates that the associated DZV11 will be tested in turn. EXAMPLE: (DZVACTV) 1406/0000000000011111 means that DZV11 no. 00,01,02,03,04 will be tested. EXAMPLE: (DZVACTV) 1406/0000000000010001 Means that DZ11 no. 00,04 will be tested.

SBASE (1174) Contains the receiver CSR of the current DZV11 under test.

B.4 MORE ON THAT 'STATUS TABLE' (1500-1740)

'MAP OF DZV11 STATUS'	
1500	160100
1502	000300
1504	000017
1506	017470
1510	000000

The above information will be repeated for each of up to 16 DZV11's in the system (these will follow under this table). EXPLANATION:

1500	160100	This is the system control register for the 1st DZV11 in the system.
1502	000300	This is vector 'A' for the first DZV11 in the system.
1504	000017	This is the binary representation of what lines are to be tested.
1506	017470	This is the parameter location used in most of the tests. It indicates parameters of: RX ON, SPEED SELECT 17 (19.2K BAUD) EIGHT BITS PER CHAR, AND TWO STOP BITS. The user may alter the stop bits and the speed, but the remaining parameters should be left alone. This location is used to load the DZV11 Line Parameter Register for each line. The meaning of the bits set in this location is the same as the function of the related bits in the device Line Parameter Register.
1510	000000	This location will contain either all zeros indicating that internal loop was selected as mode of operation or it will contain 100000 indicating that "staggered mode" was selected or it will contain 000200 indicating that "external" was the mode selected.

The above is repeated for each DZV11 in the system. The table is filled by AUTO SIZING or by the manual parameter input program as described previously. Also if desired by user; the locations may be altered by hand to suit the specific configuration.

B.5 * METHOD OF AUTO SIZING *******B.5.1 FINDING THE CONTROL STATUS REGISTER.**

The program will start at address 160000 and start 'REFERENCING' the address in the pointer. If a NON-EX MEMORY TRAP occurs, the pointer (holding 160000) is updated by 10 and the above is repeated until address 163770 is reached. If a 'BUS REPLY' response was issued by the DZV11 (or any other device) (no nzm trap), "MASTER SCAN ENABLE" is attempted to be set and the TCR bits for all four lines are set. "TRDY" is then tested to be set and "MASTER SCAN ENABLE" is tested to be still set. The diagnostic will then check that at least one TCR bit is still set. If all of the above worked, this device is assumed to be a DZV11. If any of the above failed, updating of the pointer is done and the sequence is repeated.

NOTE: If the program does not find your DZV11, something is wrong and AUTO SIZING should not be done.

B.5.2 FINDING THE VECTOR

The vector area (address 300-776) is filled with the instruction IOT and '+2' (next address). Bit14 and Bit5 (TX INTERRUPT ENABLE AND MSTSCAN ENABLE) are set into the DZVCSR. All TCR bits are set, a delay occurs, and if no interrupt occurs (because of a bad DZV11) the program assumes vector address 300 and the problem should be fixed in the diagnostic. Once the problem is fixed, the program should be setup again to set the correct vector. If an interrupt occurred, the address to which the DZV11 interrupted to is picked up and reported as the vector. NOTE: if the vector reported is not the vector set up by you, there is a problem and AUTO SIZING should not be done.

B.5.3 PARAMETER ASSUMPTIONS.

Since too much hardware would need to be turned on to SIZE the rest of the parameters; the program must assume the remaining variations. The result if not to your specific configuration may be altered by hand. In this way 95% of the parameter setup was done by the program and 5% by you.

THEREFORE:

- 1) ALL FOUR LINES ARE ASSUMED TO BE TESTED.
- 2) DEFAULT BAUD RATE IS SET TO 17 (19.2 KBAUD).
- 3) MODE OF OPERATION IS "INTERNAL MODE".

For all parameter adjustments please refer to section B.4 for greater detail.

9.0 RUNNING THE DZV11 DIAGNOSTIC UNDER APT

9.1.1 THE APT INTERFACE

The DZV diagnostics have been designed to be compatible with the APT (Automated Product Test) system. The DZV logic test diagnostics (DVDZA, and DVDZB) can be run as standalone diagnostics or in either of the APT modes. DVDZC, however is designed as a standalone diagnostic only and requires direct operator participation.

9.1.2 SETTING UP THE DIAGNOSTIC USING APT

The diagnostic uses several variables in the region subtitled "APT Mailbox-Etable". These variables are:

SSWREG -(1142)	used as the software switch register while running under APT.
SVECT1 -(1170)	used to specify the first vector address
SBASE -(1174)	used to indicate bottom address of DZV11 under test
SDEVM -(1176)	a bit map representing which DZV11's will be tested
SCDW1 -(1200)	used to indicate which lines to run on all DZV11's
SCDW2 -(1202)	used to indicate the default test mode. Set to 0 for internal testing, 200 for external loop back (H325 installed), or set to 100000 for staggered loop back testing (H329 installed).
SDDWD -(1204)	each of the SDDWD words describes the parameters (LPR) for a particular DZV11, going up to 16 DZV11's

9.1.3 RUNNING UNDER APT

All of the variables mentioned in section 9.1.2 should be set up prior to running the diagnostic under APT.

NOTE

Be sure SBASE points to the first DZV11 before running

Based on these values, the diagnostic will set up the status table. The user is then free to monitor under APT as normal.

DVDZBA SEQ

C02

DECDOC VER 00.04 27-JUL-77 13:19 PAGE 01

SEQ 0015

DOCUMENT

DVDZBA SEQ

COPYRIGHT 1977
DIGITAL EQUIPMENT CORPORATION
MAYNARD, MASS. 01754

2 COPYRIGHT (C) 1977
 DIGITAL EQUIPMENT CORP.
 MAYNARD, MASS. 01754

 THIS PROGRAM WAS ASSEMBLED USING THE PDP-11 MAINDEC SYSMAC
 PACKAGE (MAINDEC-11-DZGAC-C3), JAN 19, 1977.

46 INITIAL ADDRESS OF THE STACK POINTER *** 1120 ***

51 MISCELLANEOUS DEFINITIONS

63 GENERAL PURPOSE REGISTER DEFINITIONS

75 PRIORITY LEVEL DEFINITIONS

85 "SWITCH REGISTER" SWITCH DEFINITIONS

113 DATA BIT DEFINITIONS (BIT00 TO BIT15)

141 BASIC "CPU" TRAP VECTOR ADDRESSES

358 BITS 15-11=CPU TYPE
 11/04=01, 11/05=02, 11/20=03, 11/40=04, 11/45=05
 11/70=06, PDQ=07, Q=10
 BIT 10=REAL TIME CLOCK
 BIT 9=FLOATING POINT PROCESSOR
 BIT 8=MEMORY MANAGEMENT

366 MEM.TYPE BYTE -- (HIGH BYTE)
 900 NSEC CORE=001
 300 NSEC BIPOLAR=002
 500 NSEC MOS=003

371 MEM.LAST ADDR.=3 BYTES, THIS WORD AND LOW OF "TYPE" ABO

410 THIS TABLE CONTAINS VARIOUS COMMON STORAGE LOCATIONS
 USED IN THE PROGRAM.

462 THIS TABLE CONTAINS THE INFORMATION FOR EACH ERROR THAT CAN OCCUR.
 THE INFORMATION IS OBTAINED BY USING THE INDEX NUMBER FOUND IN
 LOCATION SITEMB. THIS NUMBER INDICATES WHICH ITEM IN THE TABLE IS PERTINENT.
 NOTE1: IF SITEMB IS 0 THE ONLY PERTINENT DATA IS (\$ERRPC).
 NOTE2: EACH ITEM IN THE TABLE CONTAINS 4 POINTERS EXPLAINED AS FOLLOWS:

468 EM ;;POINTS TO THE ERROR MESSAGE
 DH ;;POINTS TO THE DATA HEADER
 DT ;;POINTS TO THE DATA
 DF ;;POINTS TO THE DATA FORMAT

1010 INCREMENT THE PASS NUMBER (\$PASS)
IF THERES A MONITOR GO TO IT
IF THERE ISN'T JUMP TO CYCLE

1072 THIS ROUTINE CONTROLS THE LOOPING OF SUBTESTS. IT WILL INCREMENT
AND LOAD THE TEST NUMBER(\$STNM) INTO THE DISPLAY REG.(DISPLAY<7:0>)
AND LOAD THE ERROR FLAG (\$ERFLG) INTO DISPLAY<15:08>
THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
SW14=1 LOOP ON TEST
SW11=1 INHIBIT ITERATIONS
CALL
 SCOPE ;;SCOPE=IOT

1147 ROUTINE TO TYPE ASCIZ MESSAGE. MESSAGE MUST TERMINATE WITH A 0 BYTE.
THE ROUTINE WILL INSERT A NUMBER OF NULL CHARACTERS AFTER A LINE FEED.
NOTE1: \$NULL CONTAINS THE CHARACTER TO BE USED AS THE FILLER CHARACTER.
NOTE2: \$FILLS CONTAINS THE NUMBER OF FILLER CHARACTERS REQUIRED.
NOTE3: \$FILLC CONTAINS THE CHARACTER TO FILL AFTER.

CALL:
1) USING A TRAP INSTRUCTION
 TYPE ,MESADR ;;MESADR IS FIRST ADDRESS OF AN ASCIZ STRING
OR
 TYPE
 MESADR

1931 ROUTINE USED TO SET UP THE DIAGNOSTIC VIA APT.
IF BIT7 IN THE ENVIRONMENT MODE (\$ENVM) BYTE IS SET,
THE PROGRAM WILL LOAD ITS PARAMETERS FROM THE ETABLÉ.

1963 ROUTINE USED TO "AUTO SIZE" THE DZV11
CSR AND VECTOR.
NOTE: THE CSR MAY BE ANY WHERE IN THE FLOATING
 ADDRESS RANGE (160000:163770)
 AND THE VECTOR MAY BE ANY WHERE IN THE
 FLOATING VECTOR RANGE (300:770)

2071 ***** TEST 1 *****
THIS TEST VERIFIES OVERRUN AND SILO ALARM
ONE LINE AT A TIME - BASED UPON VALID LINES
AS EACH OF THE FIRST 16 CHARS ARE SENT; SILO ALARM IS
TESTED TO BE CLEARED. ON THE 16TH CHAR THE PROGRAM THEN
EXPECTS SILO ALARM TO SET. THEN THE ENTIRE
SILO IS FILLED AND AN OVERRUN IS EXPECTED ON THE 65TH
CHAR PULLED OUT OF THE SILO.
ERROR PRINTOUTS WILL REPORT TRANSMITTING LINE NO.
USING SWITCH NINE FOR THIS TEST SENDS 20. CHARACTERS
ON DZV LINE PREVIOUSLY SELECTED CONTINUOUSLY WHILE SW09=1.
USED TO SCOPE SILO ALARM PULSES, ETC.

- 2192 ***** TEST 2 *****
THIS TEST THAT "SILO ENABLE" WILL INHIBIT
RECEIVER INTERRUPTS AND THAT ON THE
16TH CHAR THAT "SILO ALARM" WILL CAUSE AN
INTERRUPT WITH "RIE" SET.
THIS WILL DO ALL SELECTED LINES ONE AT A TIME.
ERROR PRINTOUTS WILL REPORT TRANSMITTING LINE NO.
- 2264 ***** TEST 3 *****
THIS TEST RUNS ALL LINES FULL BORE
BASED UPON QUALIFIED LINES
..THIS IS AN INTERRUPT TEST ON THE RECEIVER AND
TRANSMITTER
- 2397 ***** TEST 4 *****
DZV11 RELATIVE TIMING TEST.
EACH SELECTED LINE WILL IN TURN RUN 16. CHARS
AT ALL BAUD RATES AND THEN THE HIGHEST BAUD
WITH ALL CHAR LENGTHS. EACH NEW PARAMETER SHOULD
DECREASE IN TIME FROM THE PREVIOUS PARAMETERS SELECTED.
THE TIME IS CHECKED AGAINST THE LAST PARAMETER USED
AND A LOWER TIME IS EXPECTED ON THE CURRENT PARAMETER.
PARAMETERS ARE:
EIGHT BITS/PER/CHAR - TWO STOP BITS AT
50, 75, 110, 134.5, 150, 300, 600, 1200, 1800, 2000
2400, 3600, 4800, 7200, 9600 BAUD.
19.2 K BAUD - TWO STOP BITS AT
SEVEN, SIX, FIVE BITS/PER/CHAR.
AFTER EACH LINE HAS FINISHED ALL THE ABOVE PARAMETERS
THE NEXT SELECTED LINE IS THEN TESTED.
WHEN RUNNING UNDER THE APT MANUFACTURING SYSTEM
THIS TEST IS ONLY RUN THE FIRST PASS
- 2491 ***** TEST 5 *****
THE MAIN FUNCTION OF THIS TEST IS TO VERIFY
THAT "PE" (PARITY ERROR) CAN BE FLAGGED BY
THE UARTS. THIS TEST WILL NOT BE DONE UNLESS
YOU ARE IN "STAGGERED" MODE.
40(8) CHARS ARE USED FOR THIS TEST.
ALL SELECTED LINES WILL BE ENABLED AT THE SAME TIME.
THIS TEST FIRST CHECKS EVEN PARITY FOR ODD LINES AND
ODD PARITY FOR EVEN LINES, THEN IT CHECKS THE REVERSE.

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56

000001

001120

000011
000012
000015
000200
177776

```

.TITLE MD-11-DVDZB-A
; *COPYRIGHT (C) 1977
; *DIGITAL EQUIPMENT CORP.
; *MAYNARD, MASS. 01754
; *
; *
; *THIS PROGRAM WAS ASSEMBLED USING THE PDP-11 MAINDEC SYSMAC
; *PACKAGE (MAINDEC-11-DZQAC-C3), JAN 19, 1977.
; *
$TN=1
; STARTING PROCEDURE
; LOAD PROGRAM
; LOAD ADDRESS 000200
; PRESS START
; PROGRAM WILL TYPE
; "MAINDEC-11-DVDZBA/<200>/FOUR LINE ASYNC MUX TESTS, PART 2 OF 2"
; PROGRAM WILL TYPE "RUNNING" TO INDICATE THAT TESTING HAS STARTED
; AT THE END OF A PASS, PROGRAM WILL TYPE PASS COMPLETE MESSAGE
; AND THEN RESUME TESTING

.REM !
; SWITCH REGISTER OPTIONS
; -----

SW15=100000 ;=1, HALT ON ERROR
SW14=40000 ;=1, LOOP ON CURRENT TEST
SW13=20000 ;=1, INHIBIT ERROR TIMEOUT
SW12=10000 ;=1, DELETE TIMEOUT/BELL ON ERROR.
SW11=4000 ;=1, INHIBIT ITERATIONS
SW10=2000 ;=1, ESCAPE TO NEXT TEST ON ERROR
SW09=1000 ;=1, LOOP WITH CURRENT DATA
SW08=400 ;=1, LOOP ON ERROR
SW07=200 ;=1, DO "AUTO SIZING" ON INITIAL START UP.
SW06=100 ;=1, DESELECT SPECIFIC DEVICES
; NOTE: THIS MUST NOT EXCEED ORIGINAL COUNT

SW05=40 ;=1, SELECT DELAY PARAMETER
SW04=20 ;=1, SELECT SPECIFIC PARAMETERS
SW03=10 ;=1, LOCK ON TEST SELECT
SW02=4 ;=1, RESTART PROGRAM AT SELECTED TEST
SW01=2 ;=1, SELECT DEVICE ADDRESS, VECTOR, ETC.
SW00=1

; SBTTL BASIC DEFINITIONS

; *INITIAL ADDRESS OF THE STACK POINTER *** 1120 ***
STACK= 1120
.EQUIV EMT,ERROR ; ;BASIC DEFINITION OF ERROR CALL
.EQUIV IOT,SCOPE ; ;BASIC DEFINITION OF SCOPE CALL

; *MISCELLANEOUS DEFINITIONS
HT= 11 ; ;CODE FOR HORIZONTAL TAB
LF= 12 ; ;CODE FOR LINE FEED
CR= 15 ; ;CODE FOR CARRIAGE RETURN
CRLF= 200 ; ;CODE FOR CARRIAGE RETURN-LINE FEED
PS= 177776 ; ;PROCESSOR STATUS WORD

```

```

57      .EQUIV PS,PSW
58      177774 STKLMT= 177774      ;;STACK LIMIT REGISTER
59      177772 PIRQ= 177772      ;;PROGRAM INTERRUPT REQUEST REGISTER
60      177570 DSWR= 177570      ;;HARDWARE SWITCH REGISTER
61      177570 DDISP= 177570     ;;HARDWARE DISPLAY REGISTER
62
63      .;*GENERAL PURPOSE REGISTER DEFINITIONS
64      000000 R0= %0      ;;GENERAL REGISTER
65      000001 R1= %1      ;;GENERAL REGISTER
66      000002 R2= %2      ;;GENERAL REGISTER
67      000003 R3= %3      ;;GENERAL REGISTER
68      000004 R4= %4      ;;GENERAL REGISTER
69      000005 R5= %5      ;;GENERAL REGISTER
70      000006 R6= %6      ;;GENERAL REGISTER
71      000007 R7= %7      ;;GENERAL REGISTER
72      000006 SP= %6      ;;STACK POINTER
73      000007 PC= %7      ;;PROGRAM COUNTER
74
75      .;*PRIORITY LEVEL DEFINITIONS
76      000000 PR0= 0      ;;PRIORITY LEVEL 0
77      000040 PR1= 40     ;;PRIORITY LEVEL 1
78      000100 PR2= 100    ;;PRIORITY LEVEL 2
79      000140 PR3= 140    ;;PRIORITY LEVEL 3
80      000200 PR4= 200    ;;PRIORITY LEVEL 4
81      000240 PR5= 240    ;;PRIORITY LEVEL 5
82      000300 PR6= 300    ;;PRIORITY LEVEL 6
83      000340 PR7= 340    ;;PRIORITY LEVEL 7
84
85      .;*SWITCH REGISTER SWITCH DEFINITIONS
86      100000 SW15= 100000
87      040000 SW14= 40000
88      020000 SW13= 20000
89      010000 SW12= 10000
90      004000 SW11= 4000
91      002000 SW10= 2000
92      001000 SW09= 1000
93      000400 SW08= 400
94      000200 SW07= 200
95      000100 SW06= 100
96      000040 SW05= 40
97      000020 SW04= 20
98      000010 SW03= 10
99      000004 SW02= 4
100     000002 SW01= 2
101     000001 SW00= 1
102     .EQUIV SW09,SW9
103     .EQUIV SW08,SW8
104     .EQUIV SW07,SW7
105     .EQUIV SW06,SW6
106     .EQUIV SW05,SW5
107     .EQUIV SW04,SW4
108     .EQUIV SW03,SW3
109     .EQUIV SW02,SW2
110     .EQUIV SW01,SW1
111     .EQUIV SW00,SW0
112

```

```

113      .:DATA BIT DEFINITIONS (BIT00 TO BIT15)
114      100000      BIT15= 100000
115      040000      BIT14= 40000
116      020000      BIT13= 20000
117      010000      BIT12= 10000
118      004000      BIT11= 4000
119      002000      BIT10= 2000
120      001000      BIT09= 1000
121      000400      BIT08= 400
122      000200      BIT07= 200
123      000100      BIT06= 100
124      000040      BIT05= 40
125      000020      BIT04= 20
126      000010      BIT03= 10
127      000004      BIT02= 4
128      000002      BIT01= 2
129      000001      BIT00= 1
130      .EQUIV      BIT09,BIT9
131      .EQUIV      BIT08,BIT8
132      .EQUIV      BIT07,BIT7
133      .EQUIV      BIT06,BIT6
134      .EQUIV      BIT05,BIT5
135      .EQUIV      BIT04,BIT4
136      .EQUIV      BIT03,BIT3
137      .EQUIV      BIT02,BIT2
138      .EQUIV      BIT01,BIT1
139      .EQUIV      BIT00,BIT0
140
141      .:BASIC "CPU" TRAP VECTOR ADDRESSES
142      000004      ERRVEC= 4      ;; TIME OUT AND OTHER ERRORS
143      000010      RESVEC= 10     ;; RESERVED AND ILLEGAL INSTRUCTIONS
144      000014      TBITVEC=14     ;; "T" BIT
145      000014      TRTVEC= 14     ;; TRACE TRAP
146      000014      BPTVEC= 14     ;; BREAKPOINT TRAP (BPT)
147      000020      IOTVEC= 20     ;; INPUT/OUTPUT TRAP (IOT) **SCOPE**
148      000024      PWRVEC= 24     ;; POWER FAIL
149      000030      EMTVEC= 30     ;; EMULATOR TRAP (EMT) **ERROR**
150      000034      TRAPVEC=34     ;; "TRAP" TRAP
151      000060      TKVEC= 60      ;; TTY KEYBOARD VECTOR
152      000064      TPVEC= 64     ;; TTY PRINTER VECTOR
153      000240      PIRQVEC=240    ;; PROGRAM INTERRUPT REQUEST VECTOR
154
155
156      .:INSTRUCTION DEFINITIONS
157      -----
158
159      005746      PUSH1SP=5746    ; DECREMENT PROCESSOR STACK 1 WORD
160      005726      POP1SP=5726    ; INCREMENT PROCESSOR STACK 1 WORD
161      010046      PUSHRO=10046    ; SAVE R0 ON STACK
162      012600      POPRO=12600     ; RESTORE R0 FROM STACK
163      024646      PUSH2SP=24646  ; DECREMENT STACK TWICE
164      022626      POP2SP=22626   ; INCREMENT STACK TWICE
165      000200      MASK=BIT7      ; SET INTERRUPT MASK (INHIBIT FURTHER INTERRUPTS)
166      000000      CLEAR=0        ; ALLOW INTERRUPTS (CLEAR PROCESSOR STATUS)
167
168
    
```

```

169                                     ;DZV11 CONTROL AND STATUS REGISTER DEFINITIONS
170                                     ;(DZVCSR)      BIT DEFINITIONS
171                                     ;-----
172
173      000010      MAINT = BIT3      ; MAINTENANCE MODE ENABLE
174      000020      DCLR=BIT4      ; DEVICE CLEAR
175      000040      MSENAB=BIT5     ; MASTER SCAN ENABLE
176      000100      RIE=BIT6       ; RECEIVER INTERRUPT ENABLE
177      000200      RDONE=BIT7     ; RECEIVER DONE
178      010000      SILOEN= BIT12   ; SILO ALARM ENABLE
179      020000      SILOAL = BIT13  ; SILO ALARM
180      040000      TIE=BIT14      ; TRANSMITTER INTERRUPT ENABLE
181      100000      TRDY=BIT15     ; TRANSMITTER READY
182
183                                     ;DZVCSR WORD DEFINITIONS
184                                     ;-----
185      000000      TLO=0           ; TRANSMIT LINE 0
186      000400      TL1=BIT8       ; TRANSMIT LINE 1
187      001000      TL2=BIT9       ; TRANSMIT LINE 2
188      001400      TL3=BIT9!BIT8  ; TRANSMIT LINE 3
189
190                                     ;DZVRBUF BIT DEFINITIONS
191                                     ;-----
192
193      010000      PARER=BIT12     ; PARITY ERROR
194      020000      FRMERR=BIT13    ; FRAME ERROR
195      040000      OVRRUN=BIT14    ; OVERRUN ERROR
196      100000      DVALID=BIT15   ; DATA VALID
197
198                                     ;DZVRBUF WORD DEFINITIONS
199                                     ;-----
200
201      000000      RLO=0           ; RECEIVER LINE 0
202      000400      RL1=BIT8       ; RECEIVER LINE 1
203      001000      RL2=BIT9       ; RECEIVER LINE 2
204      001400      RL3=BIT9!BIT8 ; RECEIVER LINE 3
205
206                                     ;DZVLPR WORD DEFINITIONS
207                                     ;-----
208
209      000000      LPO=0           ; LINE PARAMETER 0
210      000001      LP1=BIT0       ; LINE PARAMETER 1
211      000002      LP2=BIT1       ; LINE PARAMETER 2
212      000003      LP3=BIT1!BIT0 ; LINE PARAMETER 3
213
214      000000      FIVE=0         ; FIVE BITS/CHAR, 1 STOP BIT
215      000010      SIX=BIT3       ; SIX BITS/CHAR, 1 STOP BIT
216      000020      SEVEN=BIT4     ; SEVEN BITS/CHAR, 1 STOP BIT
217      000030      EIGHT=BIT4!BIT3 ; EIGHT BITS/CHAR, 1 STOP BIT
218      000040      FIVES=BITS     ; FIVE BITS/CHAR, 2 STOP BITS
219      000050      SIXS=BITS!BIT3 ; SIX BITS/CHAR, 2 STOP BITS
220      000060      SEVENS=BITS!BIT4 ; SEVEN BITS/CHAR, 2 STOP BITS
221      000070      EIGHTS=BITS!BIT4!BIT3 ; EIGHT BITS/CHAR, 2 STOP BITS
222
223
224      000100      PARITY=BIT6     ; PARITY ENABLED
    
```

225	000200	ODDPAR=BIT7	: ODD PARITY ENABLED
226	000000	ONESTOP=0	: ONE STOP BIT ENABLED
227	000040	TWOSTOP=BITS	: TWO STOP BITS ENABLED
228	000000	EVEPAR=0	: EVEN PARITY ENABLED
229	010000	RCVON=BIT12	: ENABLE RECEIVER (RECEIVER ON)
230			
231	000000	S50=0	: SPEED 50 BAUD
232	000400	S75=BIT8	: SPEED 75 BAUD
233	001000	S110=BIT9	: SPEED 110 BAUD
234	001400	S134=BIT9:BIT8	: SPEED 134.5 BAUD
235	002000	S150=BIT10	: SPEED 150 BAUD
236	002400	S300=BIT10:BIT8	: SPEED 300 BAUD
237	003000	S600=BIT10:BIT9	: SPEED 600 BAUD
238	003400	S1200=BIT10:BIT9:BIT8	: SPEED 1200 BAUD
239	004000	S1800=BIT11	: SPEED 1800 BAUD
240	004400	S2000=BIT11:BIT8	: SPEED 2000 BAUD
241	005000	S2400=BIT11:BIT9	: SPEED 2400 BAUD
242	005400	S3600=BIT11:BIT9:BIT8	: SPEED 3600 BAUD
243	006000	S4800=BIT11:BIT10	: SPEED 4800 BAUD
244	006400	S7200=BIT11:BIT10:BIT8	: SPEED 7200 BAUD
245	007000	S9600=BIT11:BIT10:BIT9	: SPEED 9600 BAUD
246	007400	S19200=BIT11:BIT10:BIT9:BIT8	: SPEED 19200 BAUD
247			
248			
249			
250	000001	TCR0=BIT0	: ENABLE TRANSMISSION ON LINE 0
251	000002	TCR1=BIT1	: ENABLE TRANSMISSION ON LINE 1
252	000004	TCR2=BIT2	: ENABLE TRANSMISSION ON LINE 2
253	000010	TCR3=BIT3	: ENABLE TRANSMISSION ON LINE 3
254	000400	DTR0=BIT8	: DATA TERMINAL READY FOR LINE 0
255	001000	DTR1=BIT9	: DATA TERMINAL READY FOR LINE 1
256	002000	DTR2=BIT10	: DATA TERMINAL READY FOR LINE 2
257	004000	DTR3=BIT11	: DATA TERMINAL READY FOR LINE 3
258			
259			
260			
261	000001	RING0=BIT0	: RING INDICATED ON LINE 0
262	000002	RING1=BIT1	: RING INDICATED ON LINE 1
263	000004	RING2=BIT2	: RING INDICATED ON LINE 2
264	000010	RING3=BIT3	: RING INDICATED ON LINE 3
265	000400	C00=BIT8	: CARRIER PRESENT ON LINE 0
266	001000	C01=BIT9	: CARRIER PRESENT ON LINE 1
267	002000	C02=BIT10	: CARRIER PRESENT ON LINE 2
268	004000	C03=BIT11	: CARRIER PRESENT ON LINE 3
269			
270			
271			
272			
273	000400	BRK0=BIT8	: BREAK FOR LINE 0
274	001000	BRK1=BIT9	: BREAK FOR LINE 1
275	002000	BRK2=BIT10	: BREAK FOR LINE 2
276	004000	BRK3=BIT11	: BREAK FOR LINE 3

277
278
279
280
281
282
283
284
285
286
287
288
289
290
291
292
293
294

TABLE OF LOOP AROUND FUNCTIONS (H325)

I	↑
V	↑
REC	TRANS
DATA	DATA

I	↑
V	↑
CO	RTS

I	↑
V	↑
RING	DTR

```

295
296
297
298
299
300
301
302
303
304          000000
305
306
307
308          000020
309 000020 004300
310 000022 000200
311 000024 007236
312 000026 000340
313 000030 006344
314 000032 000340
315 000034 006136
316 000036 000340
317
318
319
320
321          000040
322          000046
323 000046 004234
324          000052
325 000052 000000
326          000040
327
328          000174
329 000174 000000
330 000176 000000
331          000200
332 000200 000137 002116
333
334
335          001000
336 001000 005200 040515 047111
(2)

```

```

:*****
:-----
: TRAPCATCHER FOR ILLEGAL INTERRUPTS
: THE STANDARD "TRAP CATCHER" IS PLACED
: BETWEEN ADDRESS 0 TO ADDRESS 776.
: IT LOOKS LIKE "PC+2 HALT".
:-----
:*****
.=0
: STANDARD INTERRUPT VECTORS
:-----
.=20
:SCOPE                                ;SCOPE LOOP HANDLER
MASK                                  ;HANDLE AT PRIORITY 7
$PWDRN                                ;POWER FAIL HANDLER
340                                    ;SERVICE AT PRIORITY LEVEL 7
$ERROR                                ;ERROR HANDLER
340                                    ;SERVICE AT PRIORITY LEVEL 7
:TRPSRV                                ;GENERAL HANDLER DISPATCH SERVICE
340                                    ;SERVICE AT PRIORITY LEVEL 7
.SBTTL ACT11 HOOKS
:*****
:HOOKS REQUIRED BY ACT11
$SVPC=.                                ;SAVE PC
.=46                                    ;;1)SET LOC.46 TO ADDRESS OF SENDAD IN .SEOP
$SENDAD                                ;;2)SET LOC.52 TO ZERO
.=52                                    ;; RESTORE PC
:WORD 0
:=$SVPC
.=174
DISPREG:0                               ;SOFTWARE DISPLAY REGISTER FOR SWITCHLESS 11S
SWREG: 0                                ;SOFTWARE SWITCH REGISTER FOR SWITCHLESS 11S
.=200
JMP .START                               ;GO TO START OF PROGRAM
.=1000
MTITLE: .ASCIZ <200><12>/MAINDEC-11-DVDZBA/<200>/FOUR LINE ASYNC MUX TESTS, PART 2 OF 2

```

```

337      001120      .=1120
338      ;:*****
339      .SBTTL  APT MAILBOX-ETABLE
340      ;:*****
341      .EVEN
342
343      001120      SMAIL:          ;: APT MAILBOX
344      001120      000000      SMSGTY: .WORD  AMSGTY ;: MESSAGE TYPE CODE
345      001122      000000      SFATAL: .WORD  AFATAL ;: FATAL ERROR NUMBER
346      001124      000000      $TESTN: .WORD  ATESTN ;: TEST NUMBER
347      001126      000000      SPASS: .WORD  APASS ;: PASS COUNT
348      001130      000000      SDEVCT: .WORD  ADEVCT ;: DEVICE COUNT
349      001132      000000      SUNIT: .WORD  ALUNIT ;: I/O UNIT NUMBER
350      001134      000000      SMSGAD: .WORD  AMSGAD ;: MESSAGE ADDRESS
351      001136      000000      SMSGLG: .WORD  AMSGLG ;: MESSAGE LENGTH
352      001140      SETABLE: ;: APT ENVIRONMENT TABLE
353      001140      000      SENV: .BYTE  AENV ;: ENVIRONMENT BYTE
354      001141      000      SENVM: .BYTE  AENVM ;: ENVIRONMENT MODE BITS
355      001142      000000      SSWREG: .WORD  ASWREG ;: APT SWITCH REGISTER
356      001144      000000      SUSWR: .WORD  AUSWR ;: USER SWITCHES
357      001146      000000      $CPUOP: .WORD  ACPUOP ;: CPU TYPE, OPTIONS
358      ;:
359      ;: BITS 15-11=CPU TYPE
360      ;: 11/04=01, 11/05=02, 11/20=03, 11/40=04, 11/45=05
361      ;: 11/70=06, P00=07, Q=10
362      ;:
363      ;: BIT 10=REAL TIME CLOCK
364      001150      000      $MAMS1: .BYTE  AMAMS1 ;: HIGH ADDRESS, M.S. BYTE
365      001151      000      $MTYP1: .BYTE  AMTYP1 ;: MEM. TYPE, BLK#1
366      ;: MEM. TYPE BYTE -- (HIGH BYTE)
367      ;: 900 NSEC CORE=001
368      ;: 300 NSEC BIPOLAR=002
369      ;: 500 NSEC MOS=003
370      001152      000000      $MADR1: .WORD  AMADR1 ;: HIGH ADDRESS, BLK#1
371      ;: MEM. LAST ADDR.=3 BYTES, THIS WORD AND LOW OF "TYPE" ABOVE
372      001154      000      $MAMS2: .BYTE  AMAMS2 ;: HIGH ADDRESS, M.S. BYTE
373      001155      000      $MTYP2: .BYTE  AMTYP2 ;: MEM. TYPE, BLK#2
374      001156      000000      $MADR2: .WORD  AMADR2 ;: MEM. LAST ADDRESS, BLK#2
375      001160      000      $MAMS3: .BYTE  AMAMS3 ;: HIGH ADDRESS, M.S. BYTE
376      001161      000      $MTYP3: .BYTE  AMTYP3 ;: MEM. TYPE, BLK#3
377      001162      000000      $MADR3: .WORD  AMADR3 ;: MEM. LAST ADDRESS, BLK#3
378      001164      000      $MAMS4: .BYTE  AMAMS4 ;: HIGH ADDRESS, M.S. BYTE
379      001165      000      $MTYP4: .BYTE  AMTYP4 ;: MEM. TYPE, BLK#4
380      001166      000000      $MADR4: .WORD  AMADR4 ;: MEM. LAST ADDRESS, BLK#4
381      001170      000300      $VECT1: .WORD  AVECT1 ;: INTERRUPT VECTOR#1, BUS PRIORITY#1
382      001172      000000      $VECT2: .WORD  AVECT2 ;: INTERRUPT VECTOR#2, BUS PRIORITY#2
383      001174      160010      $BASE: .WORD  ABASE ;: BASE ADDRESS OF EQUIPMENT UNDER TEST
384      001176      000001      $DEVN: .WORD  ADEVN ;: DEVICE MAP
385      001200      000017      $CDW1: .WORD  ACDW1 ;: CONTROLLER DESCRIPTION WORD#1
386      001202      000000      $CDW2: .WORD  ACDW2 ;: CONTROLLER DESCRIPTION WORD#2
387      001204      017470      $DDW0: .WORD  ADDW0 ;: DEVICE DESCRIPTOR WORD#0
388      001206      017470      $DDW1: .WORD  ADDW1 ;: DEVICE DESCRIPTOR WORD#1
389      001210      017470      $DDW2: .WORD  ADDW2 ;: DEVICE DESCRIPTOR WORD#2
390      001212      017470      $DDW3: .WORD  ADDW3 ;: DEVICE DESCRIPTOR WORD#3
391      001214      017470      $DDW4: .WORD  ADDW4 ;: DEVICE DESCRIPTOR WORD#4
392      001216      017470      $DDW5: .WORD  ADDW5 ;: DEVICE DESCRIPTOR WORD#5

```


407
408
409
410
411
412
413 001244
414 001244 000000
415 001246 000
416 001247 000
417 001250 000000
418 001252 000000
419 001254 000000
420 001256 000000
421 001260 000
422 001261 001
423 001262 000000
424 001264 000000
425 001266 000000
426 001270 000000
427 001272 000000
428 001274 000000
429 001276 000000
430 001300 000
431 001301 000
432 001302 000000
433 001304 177570
434 001306 177570
435 001310 177560
436 001312 177562
437 001314 177564
438 001316 177566
439 001320 000
440 001321 002
441 001322 012
442 001323 000
443 001324 000000
444
445 001326 000000
446 001330 000000
447 001332 000000
448 001334 000000
449 001336 000000
450 001340 000000
451 001342 000000
452 001344 000000
453 001346 000000
454 001350 000000
455 001352 000000
456 001354 000000
457 001356 077
458 001357 015
459 001360 000012

.SBTTL COMMON TAGS

;;*****
;;THIS TABLE CONTAINS VARIOUS COMMON STORAGE LOCATIONS
;;USED IN THE PROGRAM.

SCMTAG: ;;
STSTNM: .WORD 0
SERFLG: .BYTE 0
SICNT: .WORD 0
SLPADR: .WORD 0
SLPERR: .WORD 0
SERTTL: .WORD 0
SITEMB: .BYTE 0
SERMAX: .BYTE 1
SERRPC: .WORD 0
SGADR: .WORD 0
SBDADR: .WORD 0
SGDAT: .WORD 0
SBDDAT: .WORD 0
SAUTOB: .BYTE 0
SINTAG: .BYTE 0
SWR: .WORD DSWR
DISPLAY: .WORD DDISP
STKS: 177560
STKB: 177562
STPS: 177564
STPB: 177566
SNLL: .BYTE 0
SFILLS: .BYTE 2
SFILLC: .BYTE 12
STPFLG: .BYTE 0
SREGAD: .WORD 0
SREG0: .WORD 0
SREG1: .WORD 0
SREG2: .WORD 0
SREG3: .WORD 0
SREG4: .WORD 0
SREG5: .WORD 0
STMP0: .WORD 0
STMP1: .WORD 0
STMP2: .WORD 0
STMP3: .WORD 0
STMP4: .WORD 0
STIMES: 0
SQUES: .ASCII /?/
SCRLF: .ASCII <15>
SLF: .ASCII <12>

;;START OF COMMON TAGS
;;CONTAINS THE TEST NUMBER
;;CONTAINS ERROR FLAG
;;CONTAINS SUBTEST ITERATION COUNT
;;CONTAINS SCOPE LOOP ADDRESS
;;CONTAINS SCOPE RETURN FOR ERRORS
;;CONTAINS TOTAL ERRORS DETECTED
;;CONTAINS ITEM CONTROL BYTE
;;CONTAINS MAX. ERRORS PER TEST
;;CONTAINS PC OF LAST ERROR INSTRUCTION
;;CONTAINS ADDRESS OF 'GOOD' DATA
;;CONTAINS ADDRESS OF 'BAD' DATA
;;CONTAINS 'GOOD' DATA
;;CONTAINS 'BAD' DATA
;;RESERVED--NOT TO BE USED
;;AUTOMATIC MODE INDICATOR
;;INTERRUPT MODE INDICATOR
;;ADDRESS OF SWITCH REGISTER
;;ADDRESS OF DISPLAY REGISTER
;;TTY KBD STATUS
;;TTY KBD BUFFER
;;TTY PRINTER STATUS REG. ADDRESS
;;TTY PRINTER BUFFER REG. ADDRESS
;;CONTAINS NULL CHARACTER FOR FILLS
;;CONTAINS # OF FILLER CHARACTERS REQUIRED
;;INSERT FILL CHARS. AFTER A "LINE FEED"
;;"TERMINAL AVAILABLE" FLAG (BIT<07>=0=YES)
;;CONTAINS THE ADDRESS FROM
;;WHICH (SREG0) WAS OBTAINED
;;CONTAINS ((SREGAD)+0)
;;CONTAINS ((SREGAD)+2)
;;CONTAINS ((SREGAD)+4)
;;CONTAINS ((SREGAD)+6)
;;CONTAINS ((SREGAD)+10)
;;CONTAINS ((SREGAD)+12)
;;USER DEFINED
;;USER DEFINED
;;USER DEFINED
;;USER DEFINED
;;USER DEFINED
;;MAX. NUMBER OF ITERATIONS
;;QUESTION MARK
;;CARRIAGE RETURN
;;LINE FEED

460
461
462
463
464
465
466
467
468
469
470
471
472
473
474
475
476
477
478
479
480
481
482
483
484
485
486
487
488
489
490
491
492
493
494
495
496
497
498
499
500

001362

001362 000000
001364 000000

001366 000017
001370 017470
001372 000000
001374 000000
001376 000000
001400 000000
001402 000000
001404 000000
001406 000001
001410 000001
001412 000001
001414 000001
001415 001
001416 000001
001420 001420
001500

.SBTTL ERROR POINTER TABLE

;;THIS TABLE CONTAINS THE INFORMATION FOR EACH ERROR THAT CAN OCCUR.
;;THE INFORMATION IS OBTAINED BY USING THE INDEX NUMBER FOUND IN
;;LOCATION SITEMB. THIS NUMBER INDICATES WHICH ITEM IN THE TABLE IS PERTINENT.
;;NOTE1: IF SITEMB IS 0 THE ONLY PERTINENT DATA IS (SERRPC).
;;NOTE2: EACH ITEM IN THE TABLE CONTAINS 4 POINTERS EXPLAINED AS FOLLOWS:

;; EM ;;POINTS TO THE ERROR MESSAGE
;; DH ;;POINTS TO THE DATA HEADER
;; DT ;;POINTS TO THE DATA
;; DF ;;POINTS TO THE DATA FORMAT

SERRTB:

;;PROGRAM CONTROL PARAMETERS
;-----

NEXT: 0 ;ADDRESS OF NEXT TEST TO BE EXECUTED
LOCK: 0 ;ADDRESS FOR LOCK ON CURRENT TEST,TIGHT LOOP

;;PROGRAM VARIABLES
;-----

LINE: 17 ;DEFAULT ALL FOUR LINES RUNNING
PAR: 17470 ;PARAMETERS: 8 BITS/CHAR,2 STOP BITS,19200 BAUD,NO PARIT
MODE: 0 ;DEFAULT MAINTENANCE MODE
SAVLIN: 0 ;LINE NUMBER
XMTLIN: 0 ;TRANSMISSION LINE NUMBER
XMTCNT: 0 ;COUNT OF WORDS IN A TRANSMISSION PATTERN
REGIST: 0 ;DEVICE ADDRESS STORAGE LOCATION
SAVPC: 0 ;PROGRAM COUNTER STORAGE
DZVACTV: .BLKW 1 ;*DZV11'S SELECTED ACTIVE.
SAVACTV: .BLKW 1 ;*A BIT MAP OF DZV11'S IN THE SYSTEM
RUN: 1 ;*POINTER ONE PAST RUNNING DEVICE.
DZVNUM: .BLKB 1 ;*OCTAL NUMBER OF DZV11'S IN THE SYSTEM.
SAVNUM: .BYTE 1 ;*WORKABLE NUMBER.
SAVNO: .BLKB 1 ;*OCTAL NUMBER OF DZV11'S BEING TESTED
.EVEN
ACTIVE: DZV.MAP ;TABLE POINTER.

501					
502					
503					
504					:PROGRAM CONTROL FLAGS
505	001422	000			
506	001423	000			
507	001424	000			
508	001425	000			
509					
510					
511	001426	000000			
512	001430	000000			
513	001432	000000			
514	001434	000000			
515	001436	000000			
516	001440	000000			
517	001442	000000			
518	001444	000000			
519	001446				
520					
521					
522					
523					
524					
525		001446			
526		000024			
527	000024	000200			
528		000044			
529	000044	001446			
530		001446			
531					
532					
533					
534					
535	001446				
536	001446	000000			
537	001450	001120			
538	001452	000132			
539	001454	000137			
540	001456	000000			
541	001460	000052			
542					
543					
544					
545		001500			
546	001500				
547					
548	001500	000001			
549	001502	000001			
550	001504	000001			
551	001506	000001			
552	001510	000001			
553					
554	001512	000001			
555	001514	000001			
556	001516	000001			

:PROGRAM CONTROL FLAGS
:-----

INIFLG: .BYTE 0 ;PROGRAM INITIALIZATION FLAG
HDRFLG: .BYTE 0 ;PROGRAM INITIALIZATION FLAG FOR HEADER MAP
MNTFLG: .BYTE 0 ;MAINTENANCE BIT SET FLAG
DONFLG: .BYTE 0 ;TRANSMISSION COMPLETION FLAG

:DATA VARIABLES

TDO: .WORD 0
TD1: .WORD 0
TD2: .WORD 0
TD3: .WORD 0
TRO: .WORD 0
TR1: .WORD 0
TR2: .WORD 0
TR3: .WORD 0

STOP:
.SBTTL APT PARAMETER BLOCK

;SET LOCATIONS 24 AND 44 AS REQUIRED FOR APT

.SX= . ;SAVE CURRENT LOCATION
.=24 ;SET POWER FAIL TO POINT TO START OF PROGRAM
200 ;FOR APT START UP
.=44 ;POINT TO APT INDIRECT ADDRESS PNTR.
\$APTHDR ;POINT TO APT HEADER BLOCK
.=.SX ;RESET LOCATION COUNTER

;SETUP APT PARAMETER BLOCK AS DEFINED IN THE APT-PDP11 DIAGNOSTIC
;INTERFACE SPEC.

\$APTHD: ;
\$HIBTS: .WORD 0 ;TWO HIGH BITS OF 18 BIT MAILBOX ADDR.
\$MADDR: .WORD \$MAIL ;ADDRESS OF APT MAILBOX (BITS 0-15)
\$STMT: .WORD 90. ;RUN TIM OF LONGEST TEST
\$PASTM: .WORD 95. ;RUN TIME IN SECS. OF 1ST PASS ON 1 UNIT (QUICK VERIFY)
\$UNITM: .WORD 0. ;ADDITIONAL RUN TIME (SECS) OF A PASS FOR EACH ADDITIONAL UNIT
;WORD \$ETEND-\$MAIL/2 ;LENGTH MAILBOX-ETABLE(WORDS)
;DZV11 STATUS TABLE AND ADDRESS ASSIGNMENTS

.=1500
DZV.MAP:

DZCRO: .BLKW 1 ;CONTROL STATUS REGISTER FOR DZV11 NUMBER 0
DZVCO: .BLKW 1 ;RECEIVER AND BASE VECTOR FOR DZV11 NUMBER 0
LINE0: .BLKW 1 ;ALL LINES SELECTED
PAR0: .BLKW 1 ;PARAMETERS
MANT0: .BLKW 1 ;MAINTENANCE MODE FOR THIS DEVICE
DZCR1: .BLKW 1 ;CONTROL STATUS REGISTER FOR DZV11 NUMBER 1
DZVC1: .BLKW 1 ;RECEIVER AND BASE VECTOR FOR DZV11 NUMBER 1
LINE1: .BLKW 1 ;ALL LINES SELECTED

557	001520	000001	PAR1:	.BLKW	1	:PARAMETERS
558	001522	000001	MANT1:	.BLKW	1	:MAINTENANCE MODE FOR THIS DEVICE
559						
560	001524	000001	DZCR2:	.BLKW	1	:CONTROL STATUS REGISTER FOR DZV11 NUMBER 2
561	001526	000001	DZVC2:	.BLKW	1	:RECEIVER AND BASE VECTOR FOR DZV11 NUMBER 2
562	001530	000001	LINE2:	.BLKW	1	:ALL LINES SELECTED
563	001532	000001	PAR2:	.BLKW	1	:PARAMETERS
564	001534	000001	MANT2:	.BLKW	1	:MAINTENANCE MODE FOR THIS DEVICE
565						
566	001536	000001	DZCR3:	.BLKW	1	:CONTROL STATUS REGISTER FOR DZV11 NUMBER 3
567	001540	000001	DZVC3:	.BLKW	1	:RECEIVER AND BASE VECTOR FOR DZV11 NUMBER 3
568	001542	000001	LINE3:	.BLKW	1	:ALL LINES SELECTED
569	001544	000001	PAR3:	.BLKW	1	:PARAMETERS
570	001546	000001	MANT3:	.BLKW	1	:MAINTENANCE MODE FOR THIS DEVICE
571						
572	001550	000001	DZCR4:	.BLKW	1	:CONTROL STATUS REGISTER FOR DZV11 NUMBER 4
573	001552	000001	DZVC4:	.BLKW	1	:RECEIVER AND BASE VECTOR FOR DZV11 NUMBER 4
574	001554	000001	LINE4:	.BLKW	1	:ALL LINES SELECTED
575	001556	000001	PAR4:	.BLKW	1	:PARAMETERS
576	001560	000001	MANT4:	.BLKW	1	:MAINTENANCE MODE FOR THIS DEVICE
577						
578	001562	000001	DZCR5:	.BLKW	1	:CONTROL STATUS REGISTER FOR DZV11 NUMBER 5
579	001564	000001	DZVC5:	.BLKW	1	:RECEIVER AND BASE VECTOR FOR DZV11 NUMBER 5
580	001566	000001	LINE5:	.BLKW	1	:ALL LINES SELECTED
581	001570	000001	PAR5:	.BLKW	1	:PARAMETERS
582	001572	000001	MANT5:	.BLKW	1	:MAINTENANCE MODE FOR THIS DEVICE
583						
584	001574	000001	DZCR6:	.BLKW	1	:CONTROL STATUS REGISTER FOR DZV11 NUMBER 6
585	001576	000001	DZVC6:	.BLKW	1	:RECEIVER AND BASE VECTOR FOR DZV11 NUMBER 6
586	001600	000001	LINE6:	.BLKW	1	:ALL LINES SELECTED
587	001602	000001	PAR6:	.BLKW	1	:PARAMETERS
588	001604	000001	MANT6:	.BLKW	1	:MAINTENANCE MODE FOR THIS DEVICE
589						
590	001606	000001	DZCR7:	.BLKW	1	:CONTROL STATUS REGISTER FOR DZV11 NUMBER 7
591	001610	000001	DZVC7:	.BLKW	1	:RECEIVER AND BASE VECTOR FOR DZV11 NUMBER 7
592	001612	000001	LINE7:	.BLKW	1	:ALL LINES SELECTED
593	001614	000001	PAR7:	.BLKW	1	:PARAMETERS
594	001616	000001	MANT7:	.BLKW	1	:MAINTENANCE MODE FOR THIS DEVICE
595						
596	001620	000001	DZCR10:	.BLKW	1	:CONTROL STATUS REGISTER FOR DZV11 NUMBER 10
597	001622	000001	DZVC10:	.BLKW	1	:RECEIVER AND BASE VECTOR FOR DZV11 NUMBER 10
598	001624	000001	LINE10:	.BLKW	1	:ALL LINES SELECTED
599	001626	000001	PAR10:	.BLKW	1	:PARAMETERS
600	001630	000001	MANT10:	.BLKW	1	:MAINTENANCE MODE FOR THIS DEVICE
601						
602	001632	000001	DZCR11:	.BLKW	1	:CONTROL STATUS REGISTER FOR DZV11 NUMBER 11
603	001634	000001	DZVC11:	.BLKW	1	:RECEIVER AND BASE VECTOR FOR DZV11 NUMBER 11
604	001636	000001	LINE11:	.BLKW	1	:ALL LINES SELECTED
605	001640	000001	PAR11:	.BLKW	1	:PARAMETERS
606	001642	000001	MANT11:	.BLKW	1	:MAINTENANCE MODE FOR THIS DEVICE
607						
608	001644	000001	DZCR12:	.BLKW	1	:CONTROL STATUS REGISTER FOR DZV11 NUMBER 12
609	001646	000001	DZVC12:	.BLKW	1	:RECEIVER AND BASE VECTOR FOR DZV11 NUMBER 12
610	001650	000001	LINE12:	.BLKW	1	:ALL LINES SELECTED
611	001652	000001	PAR12:	.BLKW	1	:PARAMETERS
612	001654	000001	MANT12:	.BLKW	1	:MAINTENANCE MODE FOR THIS DEVICE

G03

MD-11-DVDZB-A MACY11 30(1046) 28-JUL-77 07:37 PAGE 14
DVDZBA.P11 28-JUL-77 07:37 APT PARAMETER BLOCK

SEQ 0032

613					
614	001656	000001	DZCR13: .BLKW	1	:CONTROL STATUS REGISTER FOR DZV11 NUMBER 13
615	001660	000001	DZVC13: .BLKW	1	:RECEIVER AND BASE VECTOR FOR DZV11 NUMBER 13
616	001662	000001	LINE13: .BLKW	1	:ALL LINES SELECTED
617	001664	000001	PAR13: .BLKW	1	:PARAMETERS
618	001666	000001	MANT13: .BLKW	1	:MAINTENANCE MODE FOR THIS DEVICE
619					
620	001670	000001	DZCR14: .BLKW	1	:CONTROL STATUS REGISTER FOR DZV11 NUMBER 14
621	001672	000001	DZVC14: .BLKW	1	:RECEIVER AND BASE VECTOR FOR DZV11 NUMBER 14
622	001674	000001	LINE14: .BLKW	1	:ALL LINES SELECTED
623	001676	000001	PAR14: .BLKW	1	:PARAMETERS
624	001700	000001	MANT14: .BLKW	1	:MAINTENANCE MODE FOR THIS DEVICE
625					
626	001702	000001	DZCR15: .BLKW	1	:CONTROL STATUS REGISTER FOR DZV11 NUMBER 15
627	001704	000001	DZVC15: .BLKW	1	:RECEIVER AND BASE VECTOR FOR DZV11 NUMBER 15
628	001706	000001	LINE15: .BLKW	1	:ALL LINES SELECTED
629	001710	000001	PAR15: .BLKW	1	:PARAMETERS
630	001712	000001	MANT15: .BLKW	1	:MAINTENANCE MODE FOR THIS DEVICE
631					
632	001714	000001	DZCR16: .BLKW	1	:CONTROL STATUS REGISTER FOR DZV11 NUMBER 16
633	001716	000001	DZVC16: .BLKW	1	:RECEIVER AND BASE VECTOR FOR DZV11 NUMBER 16
634	001720	000001	LINE16: .BLKW	1	:ALL LINES SELECTED
635	001722	000001	PAR16: .BLKW	1	:PARAMETERS
636	001724	000001	MANT16: .BLKW	1	:MAINTENANCE MODE FOR THIS DEVICE
637					
638	001726	000001	DZCR17: .BLKW	1	:CONTROL STATUS REGISTER FOR DZV11 NUMBER 17
639	001730	000001	DZVC17: .BLKW	1	:RECEIVER AND BASE VECTOR FOR DZV11 NUMBER 17
640	001732	000001	LINE17: .BLKW	1	:ALL LINES SELECTED
641	001734	000001	PAR17: .BLKW	1	:PARAMETERS
642	001736	000001	MANT17: .BLKW	1	:MAINTENANCE MODE FOR THIS DEVICE
643					
644	001740	177777	DZV.END:	177777	

H03

MD-11-DVDZB-A MACY11 30(1046) 28-JUL-77 07:37 PAGE 15
 DVDZBA.P11 28-JUL-77 07:37 APT PARAMETER BLOCK

SEQ 0033

```

645                                     ;DEFINITIONS FOR TRAP SUBROUTINE CALLS
646                                     ;POINTERS TO SUBROUTINES CAN BE FOUND
647                                     ;IN THE TABLE IMMEDIATELY FOLLOWING THE DEFINITIONS
648
649                                     ;:*****
650                                     ;-----
651 001742 .TRPTAB:
652 104400 ADVANCE=TRAP+0 ;CALL TO ADVANCE TO NEXT TEST( OR SCOPE THIS ONE)
653 001742 006232 .ADVANCE
654 104401 SCOP1=TRAP+1 ;CALL TO LOOP ON CURRENT DATA HANDLER
655 001744 004544 .SCOP1
656 104402 TYPE=TRAP+2 ;CALL TO TELETYPE OUTPUT ROUTINE
657 001746 004570 .TYPE
658 104403 INSTR=TRAP+3 ;CALL TO ASCII STRING INPUT ROUTINE
659 001750 005336 .INSTR
660 104404 INSTER=TRAP+4 ;CALL TO INPUT ERROR HANDLER
661 001752 005442 .INSTER
662 104405 PARAM=TRAP+5 ;CALL TO NUMERICAL DATA INPUT ROUTINE
663 001754 005462 .PARAM
664 104406 SETFLG=TRAP+6 ;CALL TO SET FLAG ROUTINE
665 001756 010074 .SETFLG
666 104407 SAVOS=TRAP+7 ;CALL TO REGISTER SAVE ROUTINE
667 001760 005662 .SAVOS
668 104410 RESOS=TRAP+10 ;CALL TO REGISTER RESTORE ROUTINE
669 001762 005722 .RESOS
670 104411 CONVRT=TRAP+11 ;CALL TO DATA OUTPUT ROUTINE
671 001764 005754 .CONVRT
672 104412 CNVRT=TRAP+12 ;CALL TO DATA OUTPUT ROUTINE WITHOUT CR/LF.
673 001766 005760 .CNVRT
674 104413 DEVICE.CLR=TRAP+13 ;CALL TO ISSUE A DEVICE CLEAR
675 001770 006160 .DEVICE.CLR
676 104414 DELAY=TRAP+14 ;CALL TO DELAY FOR FAST CPU'S
677 001772 006212 .DELAY
678 104415 PARMD=TRAP+15 ;CONVERT DECIMAL STRING TO OCTAL
679 001774 011142 .PARMD
680 104416 PANCH=TRAP+16 ;SET FLAG ECHO OR CABLE
681 001776 010214 .PANCH
682 104417 DCLASM=TRAP+17 ;CLEAR DEVICE, SET MAINT. BIT IF I MODE
683 002000 006200 .DCLASM
684 104420 SHIFT=TRAP+20 ;CALL TO ROTATE LINE POINTER
685 002002 006244 .SHIFT
686 104421 LPRSET=TRAP+21 ;CALL TO SET UP LPR DEVICE REGISTER
687 002004 006262 .LPRSET
688 104422 BUFSET=TRAP+22 ;CALL TO ZERO BUFFER AREA
689 002006 006322 .BUFSET
690
691                                     ;:*****
692                                     ;-----
  
```

```

693                                     ;DZV11 VECTOR AND REGISTER INDIRECT POINTERS
694                                     ;WORKING AREA
695
696 002010 160040 DZVCSR: 160040 ;R/W
697 002012 160041 HDZVCSR: 160041 ;R/W
698 002014 160042 DZVRBUF: 160042 ;READ ONLY
699 002016 160043 HDZVRBUF: 160043 ;READ ONLY
700 002020 160042 DZVLPR: 160042 ;WRITE ONLY
701 002022 160043 HDZVLPR: 160043 ;WRITE ONLY
702 002024 160044 DZVTCR: 160044 ;R/W
703 002026 160045 HDZVTCR: 160045 ;R/W
704 002030 160046 DZVMSR: 160046 ;READ ONLY
705 002032 160047 HDZVMSR: 160047 ;READ ONLY
706 002034 160046 DZVTDR: 160046 ;WRITE ONLY
707 002036 160047 HDZVTDR: 160047 ;WRITE ONLY
708
709                                     ;DEFAULT DZV VECTORS
710
711 002040 000300 DZVRIV: 300 ;REC INTR VECTOR
712 002042 000302 DZVRIS: 302 ;REC INTR STATUS
713 002044 000304 DZVTIV: 304 ;XMIT INTR VECTOR
714 002046 000306 DZVTIS: 306 ;XMIT INTR STATUS
715
716
    
```

717
718
719
720
721
722
723
724
725
726
727
728
729
730
731
732
733
734
735
736
737
738
739
740

002050
002050 000000
002052 000000
002054 000000
002056 000000
002060 000000
002062 000000
002064 000000
002066 000000
002070 000000
002072 000000
002074 000000
002076 000000
002100 000000
002102 000000
002104 000000
002106 000000
002110 000000
002112 000000
002114 000000

; TIME TABLE FOR RELATIVE TIMING TESTS

TMTBL:
T50: 0
T75: 0
T110: 0
T134: 0
T150: 0
T300: 0
T600: 0
T1200: 0
T1800: 0
T2000: 0
T2400: 0
T3600: 0
T4800: 0
T7200: 0
T9600: 0
TEIGHT: 0
TSEVEN: 0
TSIX: 0
TFIVE: 0

K03

MD-11-DVDZB-A MACY11 30(1046) 28-JUL-77 07:37 PAGE 18
 DVDZBA.P11 28-JUL-77 07:37 PROGRAM INITIALIZATION AND START UP.

SEQ 0036

```

741
742
743
744
745
746
747
748
749
750
751
752
753
754
755
756
757
758
759
760
761
762
763
764
765
766
767
768
769
770
771
772
773
774
775
776
777
778
779
780
781
782
783
784
785
786
787
788
789
790
791
792
793
794
795
796

```

```

;PROGRAM INITIALIZATION
;LOCK OUT INTERRUPTS
;SET UP PROCESSOR STACK
;SET UP POWER FAIL VECTOR
;CLEAR PROGRAM CONTROL FLAGS AND COUNTS
;TYPE TITLE MESSAGE

.START:
RESET
MOV #STACK,SP
MTPS #MASK
MOV #SPWRDN,2#24
CLR #PASS
CLRB #ERRFLG
MOV #DZV.MAP,ACTIVE
MOV #1,RUN
CLR #ERRCTL
CLR #ERRPC
CLR #STSTM
MOV #.START,SLPADR

;CLEAR THE WORLD. START NEW ENVIRONMENT
;SET UP STACK
;LOCK OUT INTERRUPTS
;SET UP POWER FAIL VECTOR
;CLEAR PASS COUNT
;CLEAR ERROR FLAG
;GET MAP POINTER.
;POINT POINTER TO FIRST DEVICE.
;CLEAR ERROR COUNT
;CLEAR LAST ERROR POINTER
;SET UP FOR TEST 1
;SET UP FOR POWER FAIL BEFORE
;TESTING STARTS

;SET UP FOR SMALL 11 SWITCH REGISTER COMPATIBILITY
MOV #SWREG,SWR
MOV #DISPREG,DISPLAY
TSTB #INIFLG
BNE #10$
CMP #2#42,#SENDAD
BEQ #1$
TYPE #,MTITLE
1$: DECB #INIFLG
10$: TSTB #ENVH
BPL #15$
JSR #PC,SETAPT
JMP #105$
15$: BIT #SW00,2SWR
BNE #20$
JMP #55$
20$: MOV #DZV.MAP,RO
CLRB #HDRFLG
25$: CLR #(RO)+
CMP #RO,#DZV.END
BNE #25$
DECB #INIFLG

;POINT TO SOFTWARE SWR
;POINT TO SOFTWARE DISPLAY REGISTER
;HAVE WE ALREADY BEEN HERE TODAY?
;IF SO, SKIP PRINTING THE TITLE
;IF RUNNING UNDER ACT
;DON'T PRINT TITLE
;PRINT THE DIAGNOSTIC'S TITLE
;SET THE ONCE ONLY FLAG
;DETERMINE WHETHER APT SIZING SHOULD BE DONE
;IF NOT, GO CHECK FOR AUTO-SIZING
;OTHERWISE, GO DO APT SIZING FROM ETABLE
;GO PRINT DZV STATUS TABLE
;RESELECT ?
;IF YES, GO SET UP THE INFORMATION
;IF NO, SKIP THE INTERROGATION
;POINT TO THE BEGINNING OF THE MAP TABLE
;MAKE SURE A MAP GETS PRINTED
;CLEAR A TABLE LOCATION
;HAVE THE TABLE BOUNDARIES BEEN EXCEEDED?
;IF NOT, CLEAR THE NEXT LOCATION IN THE TABLE
;INSURE NO AUTO SIZING IF QUESTIONS ANSWERED!

;THE FOLLOWING ARE PARAMETERS USED TO FILL IN THE MAP
;TABLE AND SET UP THE DIAGNOSTIC.

;GET THE BASE ADDRESS OF THE DZV11'S

INSTR
91$
PARAM
160000
163770
DZCRO
;CALL THE STRING INPUT ROUTINE
;POINTER TO MESSAGE TO BE PRINTED
;CALL THE OCTAL TO ASCII CONVERT ROUTINE
;LOWEST LEGITIMATE VALUE OF EXPECTED RESPONSE
;HIGHEST LEGITIMATE VALUE OF EXPECTED RESPONSE
;POINTER TO MAP LOCATION TO BE FILLED

```

L03

MD-11-DVDZB-A MACY11 30(1046) 28-JUL-77 07:37 PAGE 19
 DVDZBA.P11 28-JUL-77 07:37 PROGRAM INITIALIZATION AND START UP.

SEQ 0037

797	002340	007			.BYTE	7		;MASK OF INVALID BITS FOR THIS PARAMETER
798	002341	001			.BYTE	1		;NUMBER OF PARAMETERS TO STORE
799	002342	013737	001500	001174	MOV	DZCRO,SBASE		;COPY BASE ADDRESS TO ETABLE
800								
801								;GET THE BASE VECTOR ADDRESS
802								
803	002350	104403			INSTR			;CALL THE STRING INPUT ROUTINE
804	002352	003062			92\$;POINTER TO MESSAGE TO BE PRINTED
805	002354	104405			PARAM			;CALL THE OCTAL TO ASCII CONVERT ROUTINE
806	002356	000300			300			;LOWEST LEGITIMATE VALUE OF EXPECTED RESPONSE
807	002360	000776			776			;HIGHEST LEGITIMATE VALUE OF EXPECTED RESPONSE
808	002362	001502			DZVCO			;POINTER TO MAP LOCATION TO BE FILLED
809	002364	003			.BYTE	3		;MASK OF INVALID BITS FOR THIS PARAMETER
810	002365	001			.BYTE	1		;NUMBER OF PARAMETERS TO STORE
811	002366	013737	001502	001170	MOV	DZVCO,SVECT1		;COPY VECTOR TO ETABLE
812								;GET THE MODE OF OPERATION (E,I,S)
813								
814	002374	104403			INSTR			;CALL THE STRING INPUT ROUTINE
815	002376	003311			96\$;POINTER TO THE MESSAGE TO BE PRINTED
816	002400	104406			SETFLG			;CALL THE MAINTENANCE FLAG SETUP ROUTINE
817	002402	001510			MANTO			;THIS IS THE FLAG BEING SETUP
818								
819								;GET THE NUMBER OF DZV11'S RUNNING
820								
821	002404	104403			INSTR			;CALL THE STRING INPUT ROUTINE
822	002406	003246			95\$;POINTER TO MESSAGE TO BE PRINTED
823	002410	104405			PARAM			;CALL THE OCTAL TO ASCII CONVERT ROUTINE
824	002412	000001			1			;LOWEST LEGITIMATE VALUE OF EXPECTED RESPONSE
825	002414	000020			16.			;HIGHEST LEGITIMATE VALUE OF EXPECTED RESPONSE
826	002416	001344			\$TMP1			;POINTER TO MAP LOCATION TO BE FILLED
827	002420	000			.BYTE	0		;MASK OF INVALID BITS FOR THIS PARAMETER
828	002421	001			.BYTE	1		;NUMBER OF PARAMETERS TO STORE
829								
830	002422	012737	000017	001504	MOV	#17,LINED		;SET UP DEFAULT LINES
831	002430	012737	017470	001506	MOV	#17470,PARO		;SET UP DEFAULT LPR PARAMETER
832								;RECEIVER ON; 19.2 KBAUD; 2STOP BITS; 8 BIT/CHAR
833	002436	032777	000010	176640	BIT	#SW03,2SWR		;DO YOU WANT PARAMETERS?
834	002444	001402			BEQ	30\$;IF NO, SKIP THE PARAMETER CALL
835	002446	004737	002626		JSR	PC,65\$;GET PARAMETERS
836	002452	012737	000001	001410	30\$:	MOV	#1,SAVACTV	;INITIALIZE ACTIVE DEVICE SELECTION PARAMETER
837	002460	113737	001344	001414	MOV	\$TMP1,DZVNUM		;COPY THE NUMBER OF DEVICES
838	002466	005337	001344		35\$:	DEC	\$TMP1	;STMP1 CONTAINS THE COUNT OF UNINITIALIZED
839	002472	001404			BEQ	40\$;SELECTED DEVICES
840	002474	000261			SEC			;SET A BIT FLAG TO INDICATE AN ACTIVE DEVICE
841	002476	006137	001410		ROL	SAVACTV		;POINT TO THE NEXT DEVICE
842	002502	000771			BR	35\$;GO DO THIS PROCEDURE AGAIN
843	002504	013737	001410	001346	40\$:	MOV	SAVACTV,\$TMP2	;# OF TIMES
844	002512	012700	001500		MOV	#DZCRO,R0		;SET A POINTER TO THE SPECIFIED INFORMATION
845	002516	012701	001512		MOV	#DZCR1,R1		;POINT R1 TO THE REST OF THE MAP TABLE
846	002522	012702	001204		MOV	#SDDWO,R2		;POINT TO ETABLE'S DEVICE DESCRIPTOR WORDS
847	002526	000241			CLC			;INITIALIZE THE "C" BIT FOR A ROTATION
848	002530	006037	001346		ROR	\$TMP2		;SKIP MAPPING SETUP FOR DEVICE 0- IT'S DONE
849	002534	006237	001346		45\$:	ASR	\$TMP2	;ISOLATE A SELECTION FLAG IN THE "C" BIT
850	002540	103404			BCS	50\$;IS THIS DEVICE SELECTED? IF YES, GO LOAD TABLE
851	002542	012711	177777		MOV	#-1,(R1)		;TERMINATE THE LIST
852	002546	000137	003514		JMP	100\$;GO TO THE NEXT BLOCK

M03

MD-11-DVDZB-A MACY11 30(1046) 28-JUL-77 07:37 PAGE 20
 DVDZBA.P11 28-JUL-77 07:37

PROGRAM INITIALIZATION AND START UP.

SEQ 0038

```

853 002552 012011          50$:  MOV      (R0)+,(R1)      ;ADDRESS
854 002554 062721 000010    ADD      #10,(R1)+      ;POINT TO THE NEXT DZV11 ADDRESS VALUE
855 002560 012011          MOV      (R0)+,(R1)      ;VECTOR
856 002562 062721 000010    ADD      #10,(R1)+      ;POINT TO THE NEXT VECTOR VALUE
857 002566 012021          MOV      (R0)+,(R1)+     ;LINES
858 002570 012021          MOV      (R0)+,(R1)+     ;PARAMETERS
859 002572 012021          MOV      (R0)+,(R1)+     ;MAINTENANCE MODE
860 002574 000757          BR       45$
861 002576 032777 000010 176500 55$: BIT      #5M03,#SMR      ;ASK PARAMETERS ?
862 002604 001002          BNE     60$             ;IF NO, GO DO AUTO SIZING
863 002606 000137 003514    JMP     100$           ;GO SET UP FOR AUTO SIZING
864 002612 004737 002626    60$:  JSR     PC,65$       ;GO ASK PARAMETERS
865 002616 105337 001422    DEC    INIFLG         ;INSURE NO AUTO SIZE IF QUESTIONS ANSWERED
866 002622 000137 003540    JMP     105$         ;GO TO THE NEXT BLOCK
867
868 ;GET THE ACTIVE LINES PARAMETER
869
870 002626          65$:
871 002626 104403          INSTR     ;CALL THE STRING INPUT ROUTINE
872 002630 003123          93$      ;POINTER TO MESSAGE TO BE PRINTED
873 002632 104405          PARAM    ;CALL THE OCTAL TO ASCII CONVERT ROUTINE
874 002634 000001          1       ;LOWEST LEGITIMATE VALUE OF EXPECTED RESPONSE
875 002636 000017          17      ;HIGHEST LEGITIMATE VALUE OF EXPECTED RESPONSE
876 002640 001504          LINEO    ;POINTER TO MAP LOCATION TO BE FILLED
877 002642          360    ;MASK OF INVALID BITS FOR THIS PARAMETER
878 002643          001    ;NUMBER OF PARAMETERS TO STORE
879 002644 105037 001423    CLRB    HDRFLG       ;MAKE SURE THE CHANGES ARE PRINTED
880
881 ;THIS SEGMENT CHECKS TO MAKE SURE THE LINE PARAMETER JUST ENTERED
882 ;IS LEGITIMATE IN STAGGERED MODE OPERATION IF THAT MODE WAS SELECTED
883
884 002650 005737 001510          TST     MANTO         ;IS STAGGERED THE MODE OF OPERATION?
885 002654 100021          BPL     85$          ;IF NOT, SKIP THIS SEGMENT
886 002656 013703 001504          MOV     LINEO,R3     ;GET A SCRATCH COPY OF THE ACTIVE LINES
887 002662 006003          70$:  ROR     R3         ;GET A LINE SELECTION BIT(EVEN NUMBER LINE)
888 002664 103410          BCS     80$          ;IF IT IS SELECTED, CHECK TO SEE IF THE NEXT IS TOO
889 002666 001414          BEQ     85$          ;IF ALL HAVE BEEN CHECKED, CONTINUE PROCESSING
890 002670 006203          ASR     R3           ;IF IT IS 0,CHECK TO SEE IF THE NEXT IS TOO
891 002672 103373          BCC     70$         ;IF THIS ONE'S 0 TOO, GO CHECK THE NEXT PAIR
892 002674 104402 001356          TYPE    'SQUES      ;THIS IS AN INCORRECT PARAMETER
893 002700 104402 010020          TYPE    MBADLN      ;LET THE USER KNOW ABOUT IT
894 002704 000750          BR     65$          ;GO GET THE CORRECT PARAMETER
895 002706 001772          80$:  BEQ     75$          ;IF ANOTHER FLAG ISN'T SET, THERE'S AN ERROR
896 002710 006203          ASR     R3           ;GET THE NEXT FLAG
897 002712 103370          BCC     75$          ;IF IT ISN'T SET, THERE'S AN ERROR
898 002714 000241          CLC     ;INITIALIZE THE "C" BIT FOR TESTING OF THE NEXT PAIR
899 002716 000761          BR     70$         ;GO TEST THE NEXT PAIR OF FLAGS
900
901 ;GET THE LINE PARAMETER REGISTER ARGUMENT
902
903 002720          85$:
904 002720 104403          INSTR     ;CALL THE STRING INPUT ROUTINE
905 002722 003176          94$      ;POINTER TO MESSAGE TO BE PRINTED
906 002724 104405          PARAM    ;CALL THE OCTAL TO ASCII CONVERT ROUTINE
907 002726 000000          0       ;LOWEST LEGITIMATE VALUE OF EXPECTED RESPONSE
908 002730 000017          17      ;HIGHEST LEGITIMATE VALUE OF EXPECTED RESPONSE

```

909	002732	001506				PAR0		: POINTER TO MAP LOCATION TO BE FILLED
910	002734	000				.BYTE	0	: MASK OF INVALID BITS FOR THIS PARAMETER
911	002736	001				.BYTE	1	: NUMBER OF PARAMETERS TO STORE
912	002736	012702	001504			MOV	#LINE0,R2	: POINT TO THE LINE SELECTION PARAMETER
913	002742	012703	001506			MOV	#PAR0,R3	: POINT TO THE CHOSEN PARAMETERS
914	002746	011304				MOV	(R3),R4	: USE BAUD RATE AS AN INDEX IN DELAY TABLE
915	002750	006304				ASL	R4	: ALIGN INDEX ON WORD BOUNDARY
916	002752	016437	017166	006230		MOV	DLYTBL(R4),DLYCNT	: SET THE DELAY COUNT FOR THIS BAUD RATE
917	002760	000313				SWAB	(R3)	: PLACE IN HIGH BYTE
918	002762	052713	010070			BIS	#10070,(R3)	: PLACE EXTRA PARAMETERS INTO LOC
919	002766	011262	000012		90\$:	MOV	(R2),12(R2)	: LOAD THE LINES
920	002772	011363	000012			MOV	(R3),12(R3)	: LOAD THE PARAMETERS
921	002776	062702	000012			ADD	#12,R2	: POINT TO THE NEXT SET
922	003002	062703	000012			ADD	#12,R3	: ... OF BOTH PARAMETERS
923	003006	020327	001734			CMP	R3,#PAR17	: HAVE THE TABLE BOUNDARIES BEEN EXCEEDED?
924	003012	001365				BNE	90\$: IF NOT, GO LOAD SOME MORE PARAMETERS
925	003014	000207				RTS	PC	: RETURN TO CALLING BLOCK
926	003016	030600	052123	041440	91\$:	.ASCIZ	<200>/1ST CSR ADDRESS (16000:163770): /	
(1)	003062	030600	052123	053040	92\$:	.ASCIZ	<200>/1ST VECTOR ADDRESS (300:770): /	
(1)	003123	200	044514	042516	93\$:	.ASCIZ	<200>/LINES ACTIVE BY BIT <IN OCTAL>(001:17): /	
(1)	003176	042200	043105	052501	94\$:	.ASCIZ	<200>/DEFAULT BAUD RATE <IN OCTAL>(00:17): /	
(1)	003246	021600	047440	020106	95\$:	.ASCIZ	<200>/# OF DZV11'S <IN OCTAL> (1:20): /	
(1)	003311	200	040515	047111	96\$:	.ASCII	<200>/MAINTENANCE MODE/	
(1)	003332	020200	042533	052130		.ASCII	<200>/ [EXTERNAL <H325> (E)]/	
(1)	003366	020200	044533	052116		.ASCII	<200>/ [INTERNAL <DZVCSR03=1>(I)]/	
(1)	003423	200	055440	052123		.ASCIZ	<200>/ [STAGGERED <H329> (S)]: /	
(1)	003462	042600	052116	051105	97\$:	.ASCIZ	<200>/ENTER DELAY PARAMETER: /	
(1)	003514	003514			100\$:	.EVEN		
927	003514	122737	000377	001422		CMPB	#377,INIFLG	: ONLY DO AUTO SIZE ON 1ST START
928	003522	001006				BNE	105\$	
929	003524	032777	000200	175552		BIT	#BIT7,#SWR	: BIT7=1??
930	003532	001002				BNE	105\$: BR IF NO AUTO SIZE
931	003534	004737	011464			JSR	PC,AUTO.SIZE	: GO DO THE AUTO SIZE
932	003540	105737	001423		105\$:	TSTB	HDRFLG	: HAS THE TABLE BEEN TYPED YET?
933	003544	001021				BNE	120\$: IF SO, DON'T TYPE IT AGAIN
934	003546	105337	001423			DECB	HDRFLG	: INDICATE THAT THE TABLE WILL BE TYPED
935	003552	104402	007772			TYPE	XHEAD	: TYPE MAP HEADER
936	003556	012700	001500			MOV	#DZV.MAP,R0	: SET POINTER
937	003562	010037	001344		110\$:	MOV	R0,STMP1	: POINT TO THE MAP LOCATION
938	003566	012037	001346			MOV	(R0)+,STMP2	: SET DATA
939	003572	022737	177777	001346		CMP	#-1,STMP2	: END OF LIST?
940	003600	001403				BEQ	120\$: BR IF YES
941	003602	104411			115\$:	CONVRT		: CALL THE OCTAL TO ASCII CONVERSION ROUTINE
942	003604	010062				XSTATQ		: CONVERT THE DATA AT THIS ADDRESS
943	003606	000765				BR	110\$: GO PRINT THE NEXT PARAMETER
944	003610	013737	001410	001406	120\$:	MOV	SAVACTV,DZVACTV	: COPY BIT MAP OF ACTIVE DEVICES
945	003616	113737	001414	001416		MOVB	DZVNUM,SAVNO	: COPY NO. OF DEVICES IN THE SYSTEM
946	003624	032777	000100	175452		BIT	#SM06,#SWR	: DESELECT SPECIFIC DEVICES??
947	003632	001431				BEQ	135\$: BR IF NO.
948	003634				121\$:			
949	003634	104403				INSTR		: CALL THE STRING INPUT ROUTINE
950	003636	007710				MNEW		: POINTER TO MESSAGE TO BE PRINTED
951	003640	104405				PARAM		: CALL THE OCTAL TO ASCII CONVERT ROUTINE
952	003642	000001				1		: LOWEST LEGITIMATE VALUE OF EXPECTED RESPONSE
953	003644	177777				177777		: HIGHEST LEGITIMATE VALUE OF EXPECTED RESPONSE

```

954 003646 001406          DZVACTV          ; POINTER TO MAP LOCATION TO BE FILLED
955 003650          .BYTE 0          ; MASK OF INVALID BITS FOR THIS PARAMETER
956 003651          .BYTE 1          ; NUMBER OF PARAMETERS TO STORE
957 003652 023737 001406 001410  CMP DZVACTV, SAVACTV ; IS VALUE VALID?
958 003660 101403          BLOS 122$          ; IF YES BRANCH
959 003662 104402 007562          TYPE MERR3        ; IF NOT TYPE ERROR
960 003666 000762          BR 121$          ; THEN REASK QUESTION
961 003670 105037 001416          CLR SAVNO          ; INITIALIZE NO. OF ACTIVE DEVICES
962 003674 013737 001406 001344  MOV DZVACTV, STMP1 ; COPY BIT MAP OF ACTIVE DEVICES
963 003702 006237 001344          ASR STMP1          ; ROTATE OUT AN ACTIVE BIT
964 003706 103002          BCC 127$          ; IF NOT ACTIVE SKIP RECORDING IT
965 003710 105237 001416          INCB SAVNO         ; INCREMENT NO. OF ACTIVE DEVICES
966 003714 001372          BNE 126$          ; IF NOT DONE GO CONTINUE
967 003716 032777 000020 175360 135$: BIT #SM04, 2SMR    ; CHECK TO SEE IF DELAY COUNT CHANGES
968 003724 001407          BEQ 140$          ; IF NOT, GO CLEAR VECTOR AREA
969 003726 1044J3          INSTR 97$         ; CALL THE STRING INPUT ROUTINE
970 003730 003462          PARAM 1          ; POINTER TO MESSAGE TO BE PRINTED
971 003732 104405          177777          ; CALL THE OCTAL TO ASCII CONVERT ROUTINE
972 003734 000001          177777          ; LOWEST LEGITIMATE VALUE OF EXPECTED RESPONSE
973 003736 177777          DLYCNT           ; HIGHEST LEGITIMATE VALUE OF EXPECTED RESPONSE
974 003740 006230          .BYTE 0          ; POINTER TO MAP LOCATION TO BE FILLED
975 003742          .BYTE 1          ; MASK OF INVALID BITS FOR THIS PARAMETER
976 003743          .BYTE 1          ; NUMBER OF PARAMETERS TO STORE
977 003744 012700 000300          140$: MOV #300, R0      ; PREPARE TO CLEAR THE FLOATING
978 003750 012701 000302          MOV #302, R1      ; VECTOR AREA. 300-776
979 003754 010120          145$: MOV R1 (R0)+ ; START PUTTING "PC+2 - HALT"
980 003756 005021          CLR (R1)+         ; IN VECTOR AREA.
981 003760 022021          CMP (R0)+, (R1)+ ; POP POINTERS
982 003762 022700 001000          CMP #1000, R0    ; ALL DONE??
983 003766 001372          BNE 145$         ; BR IF NO.
984
985          ; TEST START AND RESTART
986          ; -----
987
988 003770 012706 001120          .BEGIN: MOV #STACK, SP ; SET UP STACK
989 003774 106427 000200          MTPS #MASK       ; LOCK OUT INTERRUPTS
990 004000 005737 000042          TST 2#42         ; IS PROGRAM UNDER MONITOR CONTROL
991 004004 001015          BNE 2$          ; BR IF YES
992 004006 032777 000004 175270  BIT #BIT2, 2SMR  ; CHECK FOR LOCK ON TEST
993 004014 001406          BEQ 1$          ; BR IF NO LOCK DESIRED.
994 004016 104402 007606          TYPE MLOCK      ; TYPE LOCK SELECTED.
995 004022 012737 000240 004312  MOV #NOP, TTST   ; ADJUST SCOPE ROUTINE.
996 004030 000403          BR 2$          ; CONTINUE ALONG.
997 004032 013737 004540 004312 1$: MOV BRW, TTST   ; PREPARE NORMAL SCOPE ROUTINE
998 004040 012737 010436 001252 2$: MOV #CYCLE, $LPADR ; START AT "CYCLE" FIND WHICH DEVICE TO TEST
999 004046 113737 001416 001415  MOV#B SAVNO, SAVNUM ; COPY NO. OF ACTIVE DEVICES
1000 004054 104402 007477          TYPE MR         ; TYPE "RUNNING"
1001 004060 000177 175166          JMP 2$LPADR     ; START TESTING
    
```

1002
1003
1004
1005
1006
1007
1008
1009
1010
1011
1012
1013
1014
1015
1016
1017
1018
1019
1020
1021
1022
1023
1024
1025
1026
1027
1028
1029
1030
1031
1032
1033
1034
1035
1036
1037
1038
1039
1040
1041
1042
1043
1044
1045
1046
1047
1048
1049
1050
1051
1052
1053
1054
1055
1056
1057

004064
004064 000004
004066 005037 001262
004072 105037 001247
004076 104402 007453
004102 104402 007635
004106 104412 004250
004112 104402 007643
004116 104412 004256
004122 005237 001126
004126 104402 007651
004132 104412 004264
004136 005337 001126
004142 104402 007662
004146 104412 004272
004152 005237 001130
004156 105337 001415
004162 001030
004164 113737 001416 001415
004172 005037 001354
004176 005237 001126
004202 042737 100000 001126
004210 005327
004212 000001
004214 003013
004216 012737
004220 000001
004222 004212
004224 013700 000042
004230 001405
004232 000005
004234 004710
004236 000240
004240 000240
004242 000240
004244
004244 000137
004246 010436
004250 000001
004252 006 002
004254 002010
004256 000001
004260 003 002

```

:END OF PASS
:TYPE NAME OF TEST
:UPDATE PASS COUNT
:CHECK FOR EXIT TO ACT-11
:RESTART TEST
.SBTTL END OF PASS ROUTINE

:*****
:INCREMENT THE PASS NUMBER (SPASS)
:IF THERES A MONITOR GO TO IT
:IF THERE ISN'T JUMP TO CYCLE

SEOP:
SCOPE
CLR SERRPC ;CLEAR LAST ERROR PC
CLRB SERFLG ;CLEAR ERROR FLAG
TYPE ,MEPASS ;TYPE END PASS
TYPE ,MCSRX ;TYPE CSR
CNVRT ,XCSR ;SHOW IT
TYPE ,MVECX ;TYPE VECTOR
CNVRT ,XVEC ;SHOW IT
INC $PASS ;RAISE PASS COUNT
TYPE ,MPASSX ;TYPE PASSES
CNVRT ,XPASS ;SHOW IT
DEC $PASS ;RESTORE PASS COUNT
TYPE ,MERRX ;TYPE ERRORS
CNVRT ,XERR ;SHOW IT
INC $DEVCT ;INC DEVCNT FOR APT
DECB SAVNUM ;ARE ALL DEVICES TESTED?
BNE SDOAGN ;BR IF NO.
MOVB SAVNO, SAVNUM ;RESTORE THE COUNT
CLR $TIMES ;ZERO THE NUMBER OF ITERATIONS
INC $PASS ;INCREMENT THE PASS NUMBER
BIC #100000, $PASS ;DON'T ALLOW A NEG. NUMBER
DEC (PC)+ ;LOOP?

SEOPCT: .WORD 1 ;YES
BGT SDOAGN ;RESTORE COUNTER
MOV (PC)+, 2(PC)+

SENDCT: .WORD 1

SGET42: MOV 2#42, R0 ;GET MONITOR ADDRESS
BEQ SDOAGN ;BRANCH IF NO MONITOR
RESET ;CLEAR THE WORLD
SENDAD: JSR PC, (R0) ;GO TO MONITOR
NOP ;SAVE ROOM
NOP ;FOR
NOP ;ACT11

SDOAGN: JMP 2(PC)+ ;RETURN
SRTNAD: .WORD CYCLE

XCSR: 1
.BYTE 6,2
DZVCSR

XVEC: 1
.BYTE 3,2
```

1058	004262	002040		
1059	004264	000001		
1060	004266	006	002	
1061	004270	001126		
1062	004272	000001		
1063	004274	006	002	
1064	004276	001256		
1065				
1066				
1067				
1068				
1069				
1070				
1071				
1072				
1073				
1074				
1075				
1076				
1077				
1078				
1079				
1080				
1081	004300			
1082	004300	005037	001262	
1083	004304	022716	012172	
1084	004310	001413		
1085	004312	000406		
1086	004314	105777	174770	
1087	004320	100067		
1088	004322	017766	174764	177776
1089	004330	032777	040000	174746
1090	004336	001060		
1091				
1092	004340	000416		
1093				
1094	004342	013746	000004	
1095	004346	012737	004366	000004
1096	004354	005737	177060	
1097	004360	012637	000004	
1098	004364	000436		
1099	004366	022626		
1100	004370	012637	000004	
1101	004374	000441		
1102	004376			
1103	004376	105737	001247	
1104	004402	001404		
1105	004404	105037	001247	
1106	004410	005037	001354	
1107	004414	032777	004000	174662
1108	004422	001011		
1109	004424	005737	001126	
1110	004430	001406		
1111	004432	005237	001250	
1112	004436	023737	001354	001250
1113	004444	002015		

```

DZVRIV
XPASS: 1
       .BYTE 6,2
       $PASS
XERR:  1
       .BYTE 6,2
       $ERTTL

;SCOPE LOOP AND ITERATION HANDLER
-----
.SBTTL SCOPE HANDLER ROUTINE

;*****
;THIS ROUTINE CONTROLS THE LOOPING OF SUBTESTS. IT WILL INCREMENT
;AND LOAD THE TEST NUMBER($STNM) INTO THE DISPLAY REG.(DISPLAY<7:0>)
;AND LOAD THE ERROR FLAG ($ERFLG) INTO DISPLAY<15:08>
;THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
;SW14=1      LOOP ON TEST
;SW11=1      INHIBIT ITERATIONS
;CALL
;          SCOPE          ;;SCOPE=IOT

$SCOPE:
.SCOPE: CLR      $ERRPC          ;CLEAR LAST ERROR PC.
        CMP      $TST1+2,(SP)  ;IS THIS THE SCOPE AT THE BEGINNING OF TST1?
        BEQ      $XTSTR        ;IF SO, DON'T LOOP ON IT
TTST:   BR       $S            ;GOTO $S (IF LOCK SW02=1; THIS LOC =240)
        TSTB    $STKS          ;KEYBOARD DONE?
        BPL     $OVER          ;BR IF NO. (LOCK: HIT KEY TO GOTO NEXT TEST)
        MOV     $STKB,-2(SP)   ;CLEAR DONE BIT
1$:     BIT     $BIT14,$SWR    ;LOOP ON PRESENT TEST?
        BNE     $OVER          ;YES IF SW14=1
;*****START OF CODE FOR THE XOR TESTER*****
$XTSTR: BR      $S            ;IF RUNNING ON THE "XOR" TESTER CHANGE
;THIS INSTRUCTION TO A "NOP" (NOP=240)
        MOV     $ERRVEC,-(SP)  ;SAVE THE CONTENTS OF THE ERROR VECTOR
        MOV     $SS,$ERRVEC   ;SET FOR TIMEOUT
        TST     $177060       ;TIME OUT ON XOR?
        MOV     (SP)+,$ERRVEC ;RESTORE THE ERROR VECTOR
        BR     $SVLAD        ;GO TO THE NEXT TEST
5$:     CMP     (SP)+,(SP)+   ;CLEAR THE STACK AFTER A TIME OUT
        MOV     (SP)+,$ERRVEC ;RESTORE THE ERROR VECTOR
        BR     $OVER          ;LOOP ON THE PRESENT TEST
6$; *****END OF CODE FOR THE XOR TESTER*****
2$:     TSTB    $ERFLG        ;HAS AN ERROR OCCURRED?
        BEQ     $S            ;BR IF NO
4$:     CLRB   $ERFLG        ;ZERO THE ERROR FLAG
        CLR     $TIMES        ;CLEAR THE NUMBER OF ITERATIONS TO MAKE
3$:     BIT     $BIT11,$SWR   ;INHIBIT ITERATIONS?
        BNE     $S            ;BR IF YES
        TST     $PASS        ;IF FIRST PASS OF PROGRAM
        BEQ     $S            ;INHIBIT ITERATIONS
        INC     $ICNT        ;INCREMENT ITERATION COUNT
        CMP     $TIMES,$ICNT  ;CHECK THE NUMBER OF ITERATIONS MADE
        BGE     $OVER        ;;BR IF MORE ITERATION REQUIRED

```

```

1114 004446 012737 000001 001250 1S:  MOV      #1,SICNT      ;;REINITIALIZE THE ITERATION COUNTER
1115 004454 013737 004542 001354      MOV      SMXCNT,STIMES  ;;SET NUMBER OF ITERATIONS TO DO
1116 004462 105237 001246      SSVLAD: INCB     STSTNM      ;;COUNT TEST NUMBERS
1117 004466 113737 001246 001124      MOVVB    STSTNM,STESTN  ;;SET TEST NUMBER IN APT MAILBOX
1118 004474 011637 001252      MOV      (SP),SLPADR    ;;SAVE SCOPE LOOP ADDRESS
1119 004500 013777 001246 174600 SOVER:  MOV      STSTNM,SDISPLAY  ;;DISPLAY TEST NUMBER
1120 004506 013716 001252      MOV      SLPADR,(SP)    ;;FUDGE RETURN ADDRESS
1121 004512 004737 006772      JSR      PC,SERV.G      ;;FIND OUT IF TG WAS TYPED
1122 004516 105037 001424      CLRB    MNTFLG         ;;CLEAR THE MAINTENANCE BIT SETTER AFTER EACH TEST
1123 004522 005737 001372      TST     MODE           ;;HAS THE MODE BEEN CHANGED?
1124 004526 001003      BNE     #5             ;;IF NOT INTERNAL, GO DO A TEST
1125 004530 112737 000010 001424      MOVVB   #MAINT,MNTFLG  ;;IF INTERNAL MODE NOW, SET THE MAINTENANCE BIT
1126 004536 000002      4S:    RTI             ;;GO DO THE TEST
1127 004540 000406      BRW:    406
1128 004542 000005      SMXCNT: 5              ;;MAX. NUMBER OF ITERATIONS
1129
1130      ;;CHECK FOR FREEZE ON CURRENT DATA
1131      -----
1132
1133 004544 032777 001000 174532 .SCOP1: BIT      #SW09,DSWR      ;;IS SW09=1(SET)?
1134 004552 001405      BEQ     1S             ;;BR IF NOT SET.
1135 004554 005737 001364      TST     LOCK          ;;IS THERE A TIGHT LOOP SPECIFIED?
1136 004560 001402      BEQ     1S             ;;IF NO, RETURN
1137 004562 013716 001364      MOV     LOCK,(SP)     ;;IF YES, GOTO THE ADDRESS IN LOCK.
1138 004566 000002      1S:    RTI             ;;GO BACK.
1139
1140 004570 032777 010000 174506 .TYPE:  BIT      #SW12,DSWR      ;;INHIBIT ALL PRINTOUT??
1141 004576 001403      BEQ     $TYPE         ;;IF NOT, GO TYPE
1142 004600 062716 000002      ADD     #2,(SP)       ;;SKIP OVER MESSAGE POINTER
1143 004604 000002      RTI                    ;;RETURN TO WHERE PROCEDURE WAS INVOKED
1144
1145      .SBTTL  TYPE ROUTINE
1146
1147      ;;*****
1148      ;;ROUTINE TO TYPE ASCIZ MESSAGE. MESSAGE MUST TERMINATE WITH A 0 BYTE.
1149      ;;THE ROUTINE WILL INSERT A NUMBER OF NULL CHARACTERS AFTER A LINE FEED.
1150      ;;NOTE1:      $NULL CONTAINS THE CHARACTER TO BE USED AS THE FILLER CHARACTER.
1151      ;;NOTE2:      $FILLS CONTAINS THE NUMBER OF FILLER CHARACTERS REQUIRED.
1152      ;;NOTE3:      $FILLC CONTAINS THE CHARACTER TO FILL AFTER.
1153      ;;
1154      ;;CALL:
1155      ;;#1) USING A TRAP INSTRUCTION
1156      ;;      TYPE      ,MESADR      ;;MESADR IS FIRST ADDRESS OF AN ASCIZ STRING
1157      ;;#OR
1158      ;;      TYPE
1159      ;;      MESADR
1160      ;;
1161 004606 105737 001323      $TYPE:  TSTB    $TPFLG      ;;IS THERE A TERMINAL?
1162 004612 100002      BPL     1S             ;;BR IF YES
1163 004614 000000      HALT                    ;;HALT HERE IF NO TERMINAL
1164 004616 000430      BR      3S             ;;LEAVE
1165 004620 010046      1S:    MOV      RO,-(SP)    ;;SAVE RO
1166 004622 017600 000002      MOV     #2(SP),RO      ;;GET ADDRESS OF ASCIZ STRING
1167 004626 122737 000001 001140      CMPB   #APTENV,SENV    ;;RUNNING IN APT MODE
1168 004634 001011      BNE     62S           ;;NO,GO CHECK FOR APT CONSOLE
1169 004636 132737 000100 001141      BITB   #APTPOOL,SENVM  ;;SPOOL MESSAGE TO APT

```

```

1170 004644 001405      BEQ      62$      ;; NO GO CHECK FOR CONSOLE
1171 004646 010037 004656  MOV      RD,61$  ;; SETUP MESSAGE ADDRESS FOR APT
1172 004652 004737 005076  JSR      PC,SATY3  ;; SPOOL MESSAGE TO APT
1173 004656 000000      .WORD    0        ;; MESSAGE ADDRESS
1174 004660 132737 000040 001141 61$:     .WORD    0        ;;
1175 004666 001003      BITB    #APTCSUP,SENVH  ;; APT CONSOLE SUPPRESSED
1176 004670 112046      BNE     60$      ;; YES, SKIP TYPE OUT
1177 004672 001005      MOVB   (RD)+,-(SP)  ;; PUSH CHARACTER TO BE TYPED ONTO STACK
1178 004674 005726      BNE     4$       ;; BR IF IT ISN'T THE TERMINATOR
1179 004676 012600      TST    (SP)+      ;; IF TERMINATOR POP IT OFF THE STACK
1180 004700 062716 000002 60$:     MOV      (SP)+,RO  ;; RESTORE RO
1181 004704 000002      ADD     #2,(SP)    ;; ADJUST RETURN PC
1182 004706 122716 000011 4$:     RTI              ;; RETURN
1183 004712 001430      CMPB   #HT,(SP)   ;; BRANCH IF <HT>
1184 004714 122716 000200 8$:     BEQ      8$       ;; BRANCH IF NOT <CRLF>
1185 004720 001006      CMPB   #CRLF,(SP)  ;;
1186 004722 005726      BNE     5$       ;; POP <CR><LF> EQUIV
1187 004724 104402      TST    (SP)+      ;; TYPE A CR AND LF
1188 004726 001357      TYPE   $CRLF     ;;
1189 004730 105037 005064  CLRB   $CHARCNT  ;; CLEAR CHARACTER COUNT
1190 004734 000755      BR     2$       ;; GET NEXT CHARACTER
1191 004736 004737 005020 5$:     JSR      PC,$TYPEC  ;; GO TYPE THIS CHARACTER
1192 004742 123726 001322 6$:     CMPB   $FILLC,(SP)+  ;; IS IT TIME FOR FILLER CHARS.?
1193 004746 001350      BNE     2$       ;; IF NO GO GET NEXT CHAR.
1194 004750 013746 001320  MOV     $NULL,-(SP)  ;; GET # OF FILLER CHARS. NEEDED
1195                                ;; AND THE NULL CHAR.
1196 004754 105366 000001 7$:     DECB   1(SP)     ;; DOES A NULL NEED TO BE TYPED?
1197 004760 002770      BLT    6$       ;; BR IF NO--GO POP THE NULL OFF OF STACK
1198 004762 004737 005020  JSR      PC,$TYPEC  ;; GO TYPE A NULL
1199 004766 105337 005064  DECB   $CHARCNT  ;; DO NOT COUNT AS A COUNT
1200 004772 000770      BR     7$       ;; LOOP
1201
1202 ;HORIZONTAL TAB PROCESSOR
1203
1204 004774 112716 000040 8$:     MOVB   #' ,(SP)   ;; REPLACE TAB WITH SPACE
1205 005000 004737 005020 9$:     JSR      PC,$TYPEC  ;; TYPE A SPACE
1206 005004 132737 000007 005064  BITB   #7,$CHARCNT  ;; BRANCH IF NOT AT
1207 005012 001372      BNE     9$       ;; TAB STOP
1208 005014 005726      TST    (SP)+      ;; POP SPACE OFF STACK
1209 005016 000724      BR     2$       ;; GET NEXT CHARACTER
1210 005020 105777 174270  $TYPEC: TSTB   $STPS     ;; WAIT UNTIL PRINTER IS READY
1211 005024 100375      BPL    $TYPEC    ;;
1212 005026 116677 000002 174262  MOVB   2(SP),2$TPB  ;; LOAD CHAR TO BE TYPED INTO DATA REG.
1213 005034 122766 000015 000002  CMPB   #CR,2(SP)   ;; IS CHARACTER A CARRIAGE RETURN?
1214 005042 001003      BNE     1$       ;; BRANCH IF NO
1215 005044 105037 005064  CLRB   $CHARCNT  ;; YES--CLEAR CHARACTER COUNT
1216 005050 000406      BR     $TYPEX    ;; EXIT
1217 005052 122766 000012 000002 1$:     CMPB   #LF,2(SP)  ;; IS CHARACTER A LINE FEED?
1218 005060 001402      BEQ    $TYPEX    ;; BRANCH IF YES
1219 005062 105227      INCB  (PC)+      ;; COUNT THE CHARACTER
1220 005064 000000  $CHARCNT: .WORD  0  ;; CHARACTER COUNT STORAGE
1221 005066 000207  $TYPEX:  RTS     PC
1222
1223 .SBTTL  APT COMMUNICATIONS ROUTINE
1224
1225 ;;*****

```

```

1226 005070 112737 000001 005334 SATY1: MOVB #1,SFFLG ;; TO REPORT FATAL ERROR
1227 005076 112737 000001 005332 SATY3: MOVB #1,SMFLG ;; TO TYPE A MESSAGE
1228 005104 000403 BR SATYC
1229 005106 112737 000001 005334 SATY4: MOVB #1,SFFLG ;; TO ONLY REPORT FATAL ERROR
1230 005114 SATYC:
1231 005114 010046 MOV RO,-(SP) ;; PUSH RO ON STACK
1232 005116 010146 MOV R1,-(SP) ;; PUSH R1 ON STACK
1233 005120 105737 005332 TSTB SMFLG ;; SHOULD TYPE A MESSAGE?
1234 005124 001450 BEQ 55 ;; IF NOT: BR
1235 005126 122737 000001 001140 CMPB #APTENV,SENV ;; OPERATING UNDER APT?
1236 005134 001031 BNE 35 ;; IF NOT: BR
1237 005136 132737 000100 001141 BITB #APTPOOL,SENV ;; SHOULD SPOOL MESSAGES?
1238 005144 001425 BEQ 35 ;; IF NOT: BR
1239 005146 017600 000004 MOV #4(SP),RO ;; GET MESSAGE ADDR.
1240 005152 062766 000002 000004 ADD #2,4(SP) ;; BUMP RETURN ADDR.
1241 005160 005737 001120 1S: TST SMSGTYPE ;; SEE IF DONE W/ LAST XMISSION?
1242 005164 001375 BNE 1S ;; IF NOT: WAIT
1243 005166 010037 001134 MOV RO,SMSGAD ;; PUT ADDR IN MAILBOX
1244 005172 105720 2S: TSTB (RO)+ ;; FIND END OF MESSAGE
1245 005174 001376 BNE 2S
1246 005176 163700 001134 SUB SMSGAD,RO ;; SUB START OF MESSAGE
1247 005202 006200 ASR RO ;; GET MESSAGE LNTH IN WORDS
1248 005204 010037 001136 MOV RO,SMSGLT ;; PUT LENGTH IN MAILBOX
1249 005210 012737 000004 001120 MOV #4,SMSGTYPE ;; TELL APT TO TAKE MSG.
1250 005216 000413 BR 55
1251 005220 017637 000004 005244 3S: MOV #4(SP),4S ;; PUT MSG ADDR IN JSR LINKAGE
1252 005226 062766 000002 000004 ADD #2,4(SP) ;; BUMP RETURN ADDRESS
1253 005234 013746 177776 MOV 177776,-(SP) ;; PUSH 177776 ON STACK
1254 005240 004737 004606 JSR PC,STYPE ;; CALL TYPE MACRO
1255 005244 000000 4S: .WORD 0
1256 005246 5S:
1257 005246 105737 005334 10S: TSTB SFFLG ;; SHOULD REPORT FATAL ERROR?
1258 005252 001416 BEQ 12S ;; IF NOT: BR
1259 005254 005737 001140 TST SENV ;; RUNNING UNDER APT?
1260 005260 001413 BEQ 12S ;; IF NOT: BR
1261 005262 005737 001120 11S: TST SMSGTYPE ;; FINISHED LAST MESSAGE?
1262 005266 001375 BNE 11S ;; IF NOT: WAIT
1263 005270 017637 000004 001122 MOV #4(SP),SFATAL ;; GET ERROR #
1264 005276 062766 000002 000004 ADD #2,4(SP) ;; BUMP RETURN ADDR.
1265 005304 005237 001120 INC SMSGTYPE ;; TELL APT TO TAKE ERROR
1266 005310 105037 005334 12S: CLRB SFFLG ;; CLEAR FATAL FLAG
1267 005314 105037 005333 CLRB SLFLG ;; CLEAR LOG FLAG
1268 005320 105037 005332 CLRB SMFLG ;; CLEAR MESSAGE FLAG
1269 005324 012601 MOV (SP)+,R1 ;; POP STACK INTO R1
1270 005326 012600 MOV (SP)+,RO ;; POP STACK INTO RO
1271 005330 000207 RTS PC ;; RETURN
1272 005332 000 SMFLG: .BYTE 0 ;; MESSG. FLAG
1273 005333 000 SLFLG: .BYTE 0 ;; LOG FLAG
1274 005334 000 SFFLG: .BYTE 0 ;; FATAL FLAG
1275 005336 .EVEN
1276 000200 APTSIZE=200
1277 000001 APTENV=001
1278 000100 APTPOOL=100
1279 000040 APTCSUP=040
1281 ;STRING INPUT ROUTINE

```

```

1282 ;-----
1283 ;
1284 005336 010346 .INSTR: MOV R3,-(SP) ;SAVE R3 ON STACK
1285 005340 010446 MOV R4,-(SP) ;SAVE R4 ON STACK
1286 005342 017637 000004 005360 MOV 24(SP),.MSG ;GET THE ADDRESS OF THE MESSAGE TO BE PRINTED
1287 005350 062766 000002 000004 ADD #2,4(SP) ;POINT TO INSTRUCTION AFTER ADDRESS POINTER
1288 005356 104402 .INST1: TYPE ;PRINT THE MESSAGE
1289 005360 000000 .MSG: 0 ;MESSAGE IS POINTED TO FROM HERE
1290 005362 012704 010270 MOV #INBUF,R4 ;POINT R4 TO THE INPUT BUFFER
1291 005367 012703 000007 MOV #7,R3 ;SET THE MAXIMUM NUMBER OF CHARACTERS ALLOWED
1292 005372 105777 173712 1$: TSTB 2$TKS ;HAS A CHARACTER BEEN RECEIVED?
1293 005376 100375 BPL 1$ ;IF NO, KEEP WAITING FOR IT
1294 005400 117714 173706 MOVB 2$TKB,(R4) ;IF YES, SAVE IT IN THE INPUT BUFFER
1295 005404 142714 000200 BICB #200,(R4) ;KEEP ONLY THE 7-BIT ASCII INFORMATION
1296 005410 122427 000015 CMPB (R4)+,#15 ;IS THIS CHARACTER A LINE FEED?
1297 005414 001417 BEQ INSTR2 ;IF SO, TERMINATE THE INPUT SEQUENCE
1298 005416 105777 173672 2$: TSTB 2$TPS ;IF NOT, CHECK TO SEE IF THE CHARACTER CAN PRINT
1299 005422 100375 BPL 2$ ;IF WE CAN'T, WAIT UNTIL WE CAN
1300 005424 017777 173662 173664 MOV 2$TKB,2$TPB ;ECHO THE CHARACTER BACK
1301 005432 005303 DEC R3 ;REDUCE THE NUMBER OF CHARACTERS RECEIVED
1302 005434 001356 BNE 1$ ;IF WE DON'T HAVE 7, GO GET SOME MORE
1303 005436 012604 MOV (SP)+,R4 ;IF WE HAVE 7, RESTORE R4
1304 005440 012603 MOV (SP)+,R3 ;RESTORE R3
1305 005442 010346 .INSTE: MOV R3,-(SP) ;SAVE R3 ON THE STACK
1306 005444 010446 MOV R4,-(SP) ;SAVE R4 ON THE STACK
1307 005446 104402 001356 TYPE ,SQUES ;PRINT A QUESTION MARK... WHAT'S GOING ON?
1308 005452 000741 BR .INST1 ;GO PRINT THE MESSAGE AGAIN
1309 005454 012604 INSTR2: MOV (SP)+,R4 ;RESTORE R4
1310 005456 012603 MOV (SP)+,R3 ;RESTORE R3
1311 005460 000002 RTI ;RETURN TO THE MAIN PROCEDURE
1312 ;
1313 ;CONVERT ASCII STRING TO OCTAL
1314 ;-----
1315 ;
1316 005462 010546 .PARAM: MOV R5,-(SP) ;SAVE R5 ON THE STACK
1317 005464 010446 MOV R4,-(SP) ;SAVE R4 ON THE STACK
1318 005466 016605 000004 MOV 4(SP),R5 ;GET THE SETUP INFORMATION POINTER
1319 005472 012537 005652 MOV (R5)+,LOLIM ;SET THE LOW LIMIT FOR THE INPUT
1320 005476 012537 005654 MOV (R5)+,HILIM ;SET THE HIGH LIMIT FOR THE INPUT
1321 005502 012537 005656 MOV (R5)+,DEVAOR ;SAVE THE ADDRESS WHERE THE RESULT WILL BE STORED
1322 005506 112537 005660 MOVB (R5)+,LOBITS ;GET THE MASK OF THE INCORRECT BITS
1323 005512 112537 005661 MOVB (R5)+,ADRCNT ;GET THE COUNT OF ITEMS TO BE STORED
1324 005516 010566 000004 MOV R5,4(SP) ;POINT TO WHERE MAIN LINE PROGRAM WILL RESUME
1325 005522 005005 PARAM1: CLR R5 ;INITIALIZE THE ASCII TO OCTAL RESULT WORD
1326 005524 012704 010270 MOV #INBUF,R4 ;POINT TO THE INPUT BUFFER
1327 005530 122714 000015 CMPB #15,(R4) ;IS THIS CHARACTER A CARRIAGE RETURN?
1328 005534 001420 BEQ PARERR ;IF SO, PRINT THE MESSAGE AGAIN
1329 005536 121427 000060 1$: CMPB (R4),#60 ;IS THIS CHARACTER BELOW THE NUMERIC RANGE?
1330 005542 002415 BLT PARERR ;IF SO, GO PRINT THE MESSAGE AGAIN
1331 005544 121427 000067 CMPB (R4),#67 ;IS THIS CHARACTER ABOVE THE NUMERIC RANGE?
1332 005550 003012 BGT PARERR ;IF SO, GO PRINT THE MESSAGE AGAIN
1333 005552 142714 000060 BICB #60,(R4) ;ISOLATE THE NUMBER THE CHARACTER REPRESENTS
1334 005556 152405 BISB (R4)+,R5 ;CONCATENATE THESE BITS TO THE ALREADY EXISTING STRING
1335 005560 122714 000015 CMPB #15,(R4) ;IS THE NEXT CHARACTER A CARRIAGE RETURN?
1336 005564 001406 BEQ LIMITS ;IF SO, GO SEE IF NUMBER IS WITHIN LIMITS
1337 005566 006305 ASL R5 ;CLEAR BIT POSITION 0, MOVE EXISTING STRING TO LEFT
    
```

```

1338 005570 006305          ASL      R5          ;CLEAR POSITION 1, MOVE STRING TO LEFT AGAIN
1339 005572 006305          ASL      R5          ;MOVE THE STRING ONE MORE TIME TO MAKE ROOM FOR
1340                                ;NEXT THREE BITS
1341 005574 000760          BR        1$          ;GO GET THE NEXT CHARACTER
1342 005576 104404          PARERR: INSTER       ;THERE WAS AN ERROR... GO PRINT MESSAGE AGAIN
1343 005600 000750          BR        PARAM1     ;TRY GETTING THE PARAMETERS AGAIN
1344
1345                                ;TEST TO SEE IF NUMBER IS WITHIN LIMITS
1346                                -----
1347
1348 005602 020537 005654          LIMITS: CMP      R5,HILIM ;DOES RESULT EXCEED ITS MAXIMUM CORRECT VALUE?
1349 005606 101373          BHI      PARERR      ;IF YES, GO PRINT THE MESSAGE AGAIN
1350 005610 020537 005652          CMP      R5,LOLIM    ;IS THE RESULT LOWER THAN ALLOWED?
1351 005614 103770          BLO      PARERR      ;IF YES, GO PRINT THE MESSAGE AGAIN
1352 005616 133705 005660          BITB    LOBITS,R5   ;ARE ANY INCORRECT BITS SET IN THE RESULT?
1353 005622 001365          BNE      PARERR      ;IF SO, GO PRINT THE MESSAGE AGAIN
1354
1355                                ;STORE NUMBER AT SPECIFIED ADDRESS
1356
1357 005624 013704 005656          1$:      MOV      DEVADR,R4 ;POINT TO THE LOCATION WHERE THE RESULT WILL BE STORED
1358 005630 010524          MOV      R5,(R4)+    ;STORE THE RESULT
1359 005632 062705 000002          ADD      #2,R5       ;CALCULATE THE NEXT DATUM
1360 005636 105337 005661          DECB    ADCNT        ;REDUCE COUNT OF STORED RESULTS. IS IT EXCEEDED?
1361 005642 001372          BNE      1$          ;IF NOT, GO STORE THE NEXT DATUM
1362 005644 012604          MOV      (SP)+,R4    ;RESTORE R4
1363 005646 012605          MOV      (SP)+,R5    ;RESTORE R5
1364 005650 000002          RTI                    ;RETURN TO THE MAIN PROGRAM
1365
1366 005652 000000          LOLIM:  0              ;LOWEST ACCEPTABLE VALUE
1367 005654 000000          HILIM:  0              ;HIGHEST ACCEPTABLE
1368 005656 000000          DEVADR: 0              ;LOCATION WHERE RESULT WILL BE STORED
1369 005660          000              ;INCORRECT BITS MASK
1370 005661          000              ;COUNT OF ITEMS TO BE STORED
1371
1372                                ;SAVE PC OF TEST THAT FAILED AND R0-R5
1373                                -----
1374
1375 005662 016637 000004 001404 .SAV05: MOV      4(SP),SAVPC ;SAVE R7 (PC)
1376
1377                                ;SAVE R0-R5
1378
1379 005670 010537 001340          SV05:  MOV      R5,$REG5 ;SAVE R5
1380 005674 010437 001336          MOV      R4,$REG4    ;SAVE R4
1381 005700 010337 001334          MOV      R3,$REG3    ;SAVE R3
1382 005704 010237 001332          MOV      R2,$REG2    ;SAVE R2
1383 005710 010137 001330          MOV      R1,$REG1    ;SAVE R1
1384 005714 010037 001326          MOV      R0,$REG0    ;SAVE R0
1385 005720 000002          RTI                    ;LEAVE.
1386
1387                                ;RESTORE R0-R5
1388
1389 005722 013700 001326          .RES05: MOV      $REG0,R0 ;RESTORE R0
1390 005726 013701 001330          MOV      $REG1,R1    ;RESTORE R1
1391 005732 013702 001332          MOV      $REG2,R2    ;RESTORE R2
1392 005736 013703 001334          MOV      $REG3,R3    ;RESTORE R3
1393 005742 013704 001336          MOV      $REG4,R4    ;RESTORE R4

```

```

1394 005746 013705 001340      MOV      SREGS,R5      ;RESTORE R5
1395 005752 000002      RTI                    ;LEAVE
1396
1397      ;-----
1398      ;CONVERT OCTAL NUMBER TO ASCII AND OUTPUT TO TELEPRINTER
1399      ;-----
1400 005754 104402 001357      .CONVR: TYPE          SCRLF          ;PRINT A CARRIAGE RETURN
1401 005760 010046      .CNVRT: MOV           R0,-(SP)      ;SAVE R0
1402 005762 010146      MOV           R1,-(SP)      ;SAVE R1
1403 005764 010346      MOV           R3,-(SP)      ;SAVE R3
1404 005766 010446      MOV           R4,-(SP)      ;SAVE R4
1405 005770 010546      MOV           R5,-(SP)      ;SAVE R5
1406 005772 017601 000012      MOV           @12(SP),R1     ;PLACE THE ADDRESS OF THE ARGUMENTS IN R1
1407 005776 062766 000002 000012      ADD           #2,12(SP)     ;POINT TO WHERE MAIN PROGRAM WILL RESUME
1408 006004 012137 006130      MOV           (R1)+,WRDCNT  ;GET NUMBER OF WORDS TO BE PRINTED
1409 006010 112105      1S:  MOVVB        (R1)+,R5     ;GET THE NUMBER OF CHARACTERS TO BE PRINTED
1410 006012 112100      MOVVB        (R1)+,R0     ;GET THE NUMBER OF SPACES TO PRINT
1411 006014 013104      MOV           @2(R1)+,R4    ;COPY THE WORD TO BE CONVERTED
1412 006016 110537 006132      MOVVB        R5,CHRCNT    ;COPY THE CHARACTER COUNT
1413 006022 010403      3S:  MOV           R4,R3     ;COPY THE ARGUMENT WORD AGAIN
1414 006024 042703 177770      BIC           #1C(7),R3    ;ISOLATE THREE BITS TO BE TREATED AS A CHARACTER
1415 006030 062703 000060      ADD           #060,R3     ;MAKE AN ASCII CHARACTER OUT OF THEM
1416 006034 110346      MOVVB        R3,-(SP)     ;SAVE THAT CHARACTER
1417 006036 006004      ROR           R4          ;MOVE THE NEXT THREE BITS INTO PLACE
1418 006040 006204      ASR           R4          ;MOVE THEM AGAIN
1419 006042 006204      ASR           R4          ;AND FINALLY A THIRD TIME
1420 006044 005305      DEC           R5          ;REDUCE CHARACTER COUNT. ARE ALL CHARACTERS
1421      ;BUILT?
1422 006046 001365      BNE           3S         ;IF NO, GO BUILD THE NEXT ONE.
1423 006050 012703 010374      MOV           #MDATA,R3    ;NOW POINT TO WHERE NUMBER WILL BE PRINTED FROM
1424 006054 112623      4S:  MOVVB        (SP)+,(R3)+  ;STORE THE CHARACTER, STARTING WITH THE MOST
1425 006056 105337 006132      DECB         CHRCNT       ;REDUCE COUNT. ARE ALL CHARACTERS TRANSFERRED?
1426 006062 001374      BNE           4S         ;IF NO, GO TRANSFER ANOTHER
1427 006064 105700      TSTB        R0           ;ARE ANY SPACES TO BE PRINTED?
1428 006066 001404      BEQ           6S         ;IF NO, DON'T SET UP ANY
1429 006070 112723 000040      5S:  MOVVB        #040,(R3)+  ;ADD A SPACE TO THE OUTPUT BUFFER
1430 006074 105300      DECB         R0           ;REDUCE THE COUNT. SHOULD WE PRINT MORE?
1431 006076 001374      BNE           5S         ;IF YES, GO ADD ANOTHER SPACE
1432 006100 105013      6S:  CLRB         (R3)       ;TERMINATE THE OUTPUT BUFFER WITH A ZERO
1433 006102 104402 010374      TYPE        ,MDATA      ;PRINT THE STRING WE JUST BUILT
1434 006106 005337 006130      DEC         WRDCNT       ;REDUCE THE WORD COUNT. ARE ANY MORE WORDS LEFT?
1435 006112 001336      BNE           1S         ;IF YES, GO CONVERT THEM
1436 006114 012605      MOV         (SP)+,R5     ;RESTORE R5
1437 006116 012604      MOV         (SP)+,R4     ;RESTORE R4
1438 006120 012603      MOV         (SP)+,R3     ;RESTORE R3
1439 006122 012601      MOV         (SP)+,R1     ;RESTORE R1
1440 006124 012600      MOV         (SP)+,R0     ;RESTORE R0
1441 006126 000002      RTI                    ;RETURN TO THE MAIN PROGRAM
1442 006130 000000      WRDCNT: 0
1443 006132 000      CHRCNT: .BYTE
1444 006133 000      SPACNT: .BYTE 0
1445
1446 006134 000000      BINWRD: 0
1447
1448
1449      ;TRAP DISPATCH SERVICE
    
```



```

1503                                     ;LINE PARAMETER REGISTER SETUP ROUTINE
1504
1505 006262 010146 .LPRSET:MOV R1,-(SP) ;SAVE CONTENTS OF R1
1506 006264 010246 MOV R2,-(SP) ;SAVE CONTENTS OF R2
1507 006266 013701 001370 MOV PAR,R1 ;MOVE DEFAULT PARAM. INTO R1
1508 006272 012702 000001 MOV #1,R2 ;INIT. FOR LINE 1
1509 006276 010177 173516 1$: MOV R1,20ZVLPR ;LOAD PARAM. REGISTER
1510 006302 005201 INC R1 ;SET R1 FOR NEXT LINE
1511 006304 106302 ASLB R2 ;SET R2 FOR NEXT LINE
1512 006306 032702 000020 BIT #BIT4,R2 ;ALL LINES DONE?
1513 006312 001771 BEQ 1$ ;IF NO LOAD NEXT LINE
1514 006314 012602 MOV (SP)+,R2 ;RELOAD R2
1515 006316 012601 MOV (SP)+,R1 ;RELOAD R1
1516 006320 000002 RTI ;RETURN
1517
1518                                     ;ROUTINE TO ZERO DATA BUFFER
1519
1520 006322 010046 .BUFSET:MOV R0,-(SP) ;SAVE CONTENTS OF R0
1521 006324 012700 001426 MOV #TDO,R0 ;SET R0 TO TOP OF BUFFER
1522 006330 005020 1$: CLR (R0)+ ;CLEAR BUFFER LOCATION
1523 006332 022700 001446 CMP #STOP,R0 ;IS BUFFER ALL CLEARED
1524 006336 001374 BNE 1$ ;IF NOT CLEAR NEXT LOCATION
1525 006340 012600 MOV (SP)+,R0 ;RELOAD R0
1526 006342 000002 RTI ;RETURN
1527
1528                                     ;ERROR HANDLER
1529 -----
1530
1531 006344 004737 006772 172726 SERROR: JSR PC,SERV.G ;FIND OUT IF <IG> WAS HIT
1532 006350 032777 010000 BIT #SW12,2SWR ;BELL ON ERROR?
1533 006356 001406 BEQ XBX ;BR IF NO BELL
1534 006360 105777 172730 TSTB 2STPS ;TTY READY.
1535 006364 100003 BPL XBX ;DON'T WAIT IF TTY NOT READY.
1536 006366 112777 000207 172722 MOVB #207,2STPB ;PUSH A BELL AT THE TTY.
1537 006374 032777 020000 172702 XBX: BIT #SW13,2SWR ;DELETE ERROR PRINT OUT?
1538 006402 001113 BNE HALTS ;BR IF NO PRINT OUT WANTED.
1539 006404 021637 001262 CMP (SP),SERRPC ;WAS THIS ERROR FOUND LAST TIME?
1540 006410 001404 BEQ 1$ ;BR IF YES
1541 006412 011637 001262 MOV (SP),SERRPC ;RECORD BEING HERE
1542 006416 105037 001247 CLRB SERFLG ;PREPARE HEADER
1543 006422 104407 1$: SAVD5 ;SAVE ALL PROC REGISTERS
1544 006424 011605 MOV (SP),R5 ;GET THE PC OF ERROR
1545 006426 162705 000002 SUB #2,R5 ;GET ADDRESS OF TRAP CALL
1546 006432 011504 MOV (R5),R4 ;GET ERROR INSTRUCTION
1547 006434 110437 001260 MOVB R4,$ITEMB ;COPY TEST NUMBER FOR APT HANDLING
1548 006440 006304 ASL R4 ;MULT BY TWO
1549 006442 061504 ADD (R5),R4 ;DOUBLE IT
1550 006444 006304 ASL R4 ;MULT AGAIN
1551 006446 042704 177001 BIC #177001,R4 ;CLEAR JUNK
1552 006452 062704 015316 ADD #.ERRTAB,R4 ;GET POINTER
1553 006456 012437 006602 MOV (R4)+,ERRMSG ;GET ERROR MESSAGE
1554 006462 012437 006614 MOV (R4)+,DATAHD ;GET DATA HEADRER
1555 006466 011437 006626 MOV (R4),DATABP ;GET DATA TABLE
1556 006472 105737 001247 TSTB SERFLG ;TYPE HEADER
1557 006476 001403 BEQ TYPMSG ;BR IF YES
1558 006500 005737 006626 TST DATABP ;DOES DATA TABLE EXIST?
    
```

```

1559 006504 001044
1560 006506 104402 001357 TYPMSG: BNE TYPDAT ;BR IF YES.
1561 006512 104402 001357 TYPE ,SCRLF ;TYPE A CARRIAGE RETURN
1562 006516 005737 001364 TST ,SCRLF ;AND TYPE ANOTHER
1563 006522 001402 BEQ LOCK
1564 006524 104402 007705 TYPE IS
1565 006530 104402 007673 1S: TYPE ,MASTEK
1566 006534 104412 006764 CNVRT ,MTSTN ;SHOW IT
1567 006540 104402 007765 TYPE ,XTSTN ;TYPE PC.
1568 006544 104412 006756 CNVRT ,MERRPC ;SHOW IT
1569 006550 104402 007635 TYPE ,ERTAB0
1570 006554 104412 004250 CNVRT ,MCSRX
1571 006560 104402 001357 TYPE ,XCSR
1572 006564 112737 177777 001247 MOVB ,SCRLF ;GIVE A CR/LF
1573 006572 005737 006602 TST #-1, SERFLG ;NO MORE HEADER UNLESS NO DATA TABLE.
1574 006576 001402 BEQ ERRMSG ;IS THERE AN ERROR MESSAGE?
1575 006600 104402 TYPE WTBS.FM ;BR IF NO.
1576 006602 000000 ERRMSG: 0 ;TYPE
1577 006604 000000 WTBS.FM: ; ERROR MESSAGE
1578 006604 005737 006614 TST DATAHD ;DATA HEADER?
1579 006610 001402 BEQ TYPDAT ;BR IF NO
1580 006612 104402 TYPE ;TYPE
1581 006614 000000 DATAHD: 0 ; DATA HEADER
1582 006616 005737 006626 TYPDAT: TST DATABP ;DATA TABLE?
1583 006622 001402 BEQ RESREG ;BR IF NO.
1584 006624 104411 CNVRT ;SHOW
1585 006626 000000 DATABP: 0 ; DATA TABLE
1586 006630 104410 RESREG: RESOS ;RESTORE PROC REGISTERS
1587 006632 122737 000001 001140 HALTS: CMPB #APTENV, SENV ;IS APT RUNNING?
1588 006640 001007 BNE 15S ;SKIP APT CALL IF NOT
1589 006642 113737 001260 006654 MOVB $ITEMB, 5S ;COPY ERROR NUMBER
1590 006650 004737 005106 JSR PC, SATY4 ;CALL APT SERVICE
1591 006654 000000 5S: .WORD 0 ;ERROR NUMBER STUCK HERE
1592 006656 000777 10S: BR 10S ;LOCK UP HERE
1593 006660 022737 004234 000042 15S: CMP #SENDAD, @#42 ;CHECK TO SEE IF IN ACT-11 MODE
1594 006666 001403 BEQ 20S ;IF SO, HANDLE ACCORDINGLY
1595 006670 005777 172410 TST @SWR ;HALT ON ERROR?
1596 006674 100004 BPL EXITER ;BR IF NO HALT ON ERROR
1597 006676 016677 000002 172402 20S: MOV 2(SP), @DISPLAY ;SHOW ERROR PC IN DATA DISPLAY
1598 006704 000000 HALT ;HALT
1599 006706 005237 001256 EXITER: INC SERTTL ;UPDATE ERROR COUNT
1600 006712 004737 006772 JSR PC, SERV.G ;FIND OUT IF IG WAS TYPED
1601 006716 032777 000400 172360 BIT #SW08, @SWR ;GOTO TOP OF TEST?
1602 006724 001007 BNE 1S ;BR IF YES
1603 006726 032777 002000 172350 BIT #SW10, @SWR ;GOTO NEXT TEST?
1604 006734 001407 BEQ 2S ;BR IF NO
1605 006736 013737 001362 001252 1S: MOV NEXT, $LPADR ;SET FOR NEXT TEST
1606 006744 012706 001120 MOV #STACK, SP ;RESET SP
1607 006750 000177 172276 JMP @SLPADR ;GOTO SPECIFIED TEST
1608 006754 000002 2S: RTI ;RETURN
1609 006756 000001 ERTAB0: 1
1610 006760 006 002 .BYTE 6,2
1611 006762 001404 SAVPC
1612 006764 000001 XTSTN: 1
1613 006766 002 002 .BYTE 2,2
1614 006770 001246 $TSTNM

```

```

1615 006772 017746 172314      SERV.G: MOV      2$TKB,-(SP)      ; OTHERWISE, GET THE LAST CHARACTER TYPED
1616 006776 042716 000200      BIC      8BIT7,(SP)           ; STRIP PARITY(EIGHTH) BIT
1617 007002 122726 000007      CMPB     87,(SP)+             ; IS IT 1G?
1618 007006 001076                   BNE      6$                  ; IF NOT, IGNORE INPUT
1619 007010 032777 004000 172272      BIT      84000,2$TKS         ; RX BUSY?
1620 007016 001365                   BNE      SERV.G             ; BR IF YES
1621 007020 017737 172260 007226      MOV      2$SWR,90$          ; SAVE (SWR).
1622 007026 104402 007206      1$:     TYPE     '89$         ; TYPE HEADER FOR OLD SWITCH REGISTER
1623 007032 104412 007220      CNVRT    '88$               ; TYPE THE NUMBER ITSELF
1624 007036 104402 007230      TYPE     '91$               ; AFTER HAVING CONVERTED IT TO ASCII
1625 007042 105037 007234      CLRB     92$                ; CLEAR SWR CHANGE FLAG
1626 007046 005077 172232      CLR      2$SWR              ; CLEAR THE SOFTWARE SWITCH REGISTER
1627 007052 105777 172232      3$:     TSTB     2$TKS         ; WAIT FOR DONE.
1628 007056 100375                   BPL      3$                  ; CONTINUE WAITING FOR IT
1629 007060 017746 172226      MOV      2$TKB,-(SP)         ; PUT THE CHARACTER ON THE STACK
1630 007064 042716 000200      BIC      8BIT7,(SP)           ; STRIP PARITY BIT
1631 007070 122726 000015      CMPB     15,(SP)+            ; IS IT THE CARRIAGE RETURN CHAR?
1632 007074 001433                   BEQ      4$                  ; IF SO, GO PRINT CRLF
1633 007076 105777 172212      2$:     TSTB     2$TPS         ; IS THE OUTPUT BUFFER AVAILABLE
1634 007102 100375                   BPL      2$                  ; IF NOT, WAIT FOR IT TO BE READY
1635 007104 105237 007234      INCB     92$                ; INDICATE THAT THE SWR WAS CHANGED
1636 007110 014677 172202      MOV      -(SP),2$TPB         ; PLACE THE CHARACTER THERE(ECHO BACK)
1637 007114 000241                   LCL      ; GET READY TO ROTATE
1638 007116 006177 172162      ROL      2$SWR               ; MOVE THE EXISTING BITS OVER
1639 007122 006177 172156      ROL      2$SWR               ; TO MAKE ROOM FOR THE INCOMING
1640 007126 006177 172152      ROL      2$SWR               ; THREE BITS FROM THIS CHARACTER
1641 007132 103735                   BCS      1$                  ; ERROR
1642 007134 022627 000060      CMP      (SP)+,#60           ; IS IT LOWER THAN 0?
1643 007140 002732                   BLT      1$                  ; IF SO, GO ASK AGAIN
1644 007142 026627 177776 000067      CMP      -2(SP),#67         ; IS IT HIGHER THAN 7?
1645 007150 003326                   BGT      1$                  ; IF SO, GO ASK AGAIN
1646 007152 042746 177770      BIC      81C<7>,-(SP)        ; ISOLATE INFORMATION BITS
1647 007156 052677 172122      BIS      (SP)+,2$SWR         ; ADD THEM TO THE SWITCH REGISTER
1648 007162 000733                   BR       3$                  ; GO CHECK FOR THE NEXT CHARACTER
1649 007164 105737 007234      4$:     TSTB     92$           ; HAS THE SWR BEEN CHANGED?
1650 007170 001003                   BNE      5$                  ; IF YES GO TYPE CRLF
1651 007172 013777 007226 172104      MOV      90$,2$SWR          ; IF NOT RESTORE SWR
1652 007200 104402 001357      5$:     TYPE     $CRLF         ; TYPE A CARRIAGE RETURN AND LINE FEED
1653 007204 000207      6$:     RTS      PC           ; RETURN TO CALLING PROCEDURE
1654
1655 007206 020200 051450 051127 89$:     .ASCIZ  <200>? (SWR)=/?
1656 007214 036451 000057
1657
1658 007220 000001      .EVEN
1659 007222 006 000      88$:     1
1660 007224 007226      .BYTE 6,0
1661 007226 000000      90$:     .WORD 0
1662 007230 036457 000057      91$:     .ASCIZ  ?/=/?
1663 007234 000 000      92$:     .BYTE 0
1664
1665      .EVEN
1666      .SBTTL  POWER DOWN AND UP ROUTINES
1667
1668      ; *****
1669 007236 012737 007402 000024      ; POWER DOWN ROUTINE
1670 007244 012737 000340 000026      $PWRDN: MOV      8$ILLUP,2$PWRVEC ; SET FOR FAST UP
1670 007244 012737 000340 000026      MOV      8340,2$PWRVEC+2 ; ;PRIO:7

```

```

1671 007252 010046      MOV      R0,-(SP)      ;;PUSH R0 ON STACK
1672 007254 010146      MOV      R1,-(SP)      ;;PUSH R1 ON STACK
1673 007256 010246      MOV      R2,-(SP)      ;;PUSH R2 ON STACK
1674 007260 010346      MOV      R3,-(SP)      ;;PUSH R3 ON STACK
1675 007262 010446      MOV      R4,-(SP)      ;;PUSH R4 ON STACK
1676 007264 010546      MOV      R5,-(SP)      ;;PUSH R5 ON STACK
1677 007266 017746      MOV      2SMR,-(SP)    ;;PUSH 2SMR ON STACK
1678 007272 010637 007406      MOV      SP,$$AVR6    ;;SAVE SP
1679 007276 012737 007310 000024      MOV      2$PWRUP,2$PWRVEC ;;SET UP VECTOR
1680 007304 000000      HALT
1681 007306 000776      BR      -2            ;;HANG UP
1682
1683      ;;*****
1684      ;;POWER UP ROUTINE
1685 007310 012737 007402 000024      $PWRUP: MOV      2$ILLUP,2$PWRVEC ;;SET FOR FAST DOWN
1686 007316 013706 007406      MOV      $$AVR6,SP    ;;GET SP
1687 007322 005037 007406      CLR      $$AVR6      ;;WAIT LOOP FOR THE TTY
1688 007326 005237 007406      1$:    INC      $$AVR6    ;;WAIT FOR THE INC
1689 007332 001375      BNE     1$          ;;OF WORD
1690 007334 012677 171744      MOV      (SP)+,2SMR   ;;POP STACK INTO 2SMR
1691 007340 012605      MOV      (SP)+,R5    ;;POP STACK INTO R5
1692 007342 012604      MOV      (SP)+,R4    ;;POP STACK INTO R4
1693 007344 012603      MOV      (SP)+,R3    ;;POP STACK INTO R3
1694 007346 012602      MOV      (SP)+,R2    ;;POP STACK INTO R2
1695 007350 012601      MOV      (SP)+,R1    ;;POP STACK INTO R1
1696 007352 012600      MOV      (SP)+,R0    ;;POP STACK INTO R0
1697 007354 012737 007236 000024      MOV      2$PWRDN,2$PWRVEC ;;SET UP THE POWER DOWN VECTOR
1698 007362 012737 000340 000026      MOV      2$340,2$PWRVEC+2 ;;PRIO:7
1699 007370 104402      TYPE
1700 007372 007410      SPWRMG: .WORD  MPFAIL    ;;REPORT THE POWER FAILURE
1701 007374 012716      MOV      (PC)+,(SP)  ;;POWER FAIL MESSAGE POINTER
1702 007376 010776      SPWRAD: .WORD  RESTART  ;;RESTART AT RESTART
1703 007400 000002      RTI
1704 007402 000000      $ILLUP: HALT        ;;RESTART ADDRESS
1705 007404 000776      BR      -2            ;;THE POWER UP SEQUENCE WAS STARTED
1706 007406 000000      $SAVR6: 0            ;;BEFORE THE POWER DOWN WAS COMPLETE
1707 007410 050200 051127 043040      MPFAIL: .ASCIZ <200>/PWR FAILED. RESTART AT LAST TEST /
(2) 007453 200 047105 020104      MEPASS: .ASCIZ <200>/END PASS DVDZB-A /
(2) 007477 200 052522 047116      MR:     .ASCIZ <200>/RUNNING /
(2) 007513 200 051120 043517      MERR2: .ASCIZ <200>/PROGRAM INDICATES NO DEVICES PRESENT./
(2) 007562 044600 051516 043125      MERR3: .ASCIZ <200>/INSUFFICIENT DATA!/
(2) 007606 046200 041517 020113      MLOCK: .ASCIZ <200>/LOCK ON SELECTED TEST/
(2) 007635 103 051123 020072      MCSRX: .ASCIZ /CSR: /
(2) 007643 126 041505 020072      MVECX: .ASCIZ /VEC: /
(2) 007651 120 051501 042523      MPASSX: .ASCIZ /PASSES: /
(2) 007662 051105 047522 051522      MERRX: .ASCIZ /ERRORS: /
(2) 007673 124 051505 020124      MTSTN: .ASCIZ /TEST NO: /
(2) 007705 052 000040      MASTEK: .ASCIZ /* /
(2) 007710 052200 050131 020105      MNEW:  .ASCIZ <200>/TYPE A BIT MAP OF DZV11'S DESIRED ACTIVE: /
(2) 007765 120 035103 000040      MERRPC: .ASCIZ /PC: /
(2) 007772 046600 050101 047440      XHEAD: .ASCIZ <200>/MAP OF DZV11 STATUS/<200>
(2) 010020 044600 046114 043505      MBADLN: .ASCIZ <200>/ILLEGAL ENTRY IN STAGGERED MODE/<200>
(2)
(2) 010062 000002      .EVEN
(2) 010064 006 003      XSTATQ: 2
1708 010064 006 003      .BYTE 6,3
1709 010066 001344      STMP1

```

```

1710 010070 006 002 .BYTE 6,2
1711 010072 001346 .STMP2
1712 .EVEN
1713 ; THIS ROUTINE ESTABLISHES WHICH MAINTENANCE MODE THE DEVICE IS IN
1714 ;-----
1715 ;E=EXTERNAL LOOP BACK
1716 ;I=INTERNAL LOOP BACK
1717 ;S=STAGGERED LOOP BACK
1718 010074 017605 000000 .SETFLG: MOV 2(SP),R5 ; PICK UP ADDRESS OF TAG
1719 010100 042737 000040 010270 BIC #40,INBUF ; STRIP LOWER CASE
1720 010106 122737 000105 010270 CMPB #'E,INBUF ; IS IT EXTERNAL LOOP BACK ?
1721 010114 001005 BNE 4$ ; NO
1722 010116 013715 010206 MOV 1$,(R5) ; YES STORE INFO
1723 010122 105037 001424 CLRB MNTFLG ; SET MAINT BIT =0
1724 010126 000422 BR 7$ ; GET OUT
1725 010130 122737 000111 010270 4$: CMPB #'I,INBUF ; IS IT INTERNAL LOOP BACK ?
1726 010136 001006 BNE 5$ ; NO
1727 010140 013715 010210 MOV 2$,(R5) ; YES STORE INFO
1728 010144 112737 000010 001424 MOVB #MAINT,MNTFLG ; SET UP THE MAINTENANCE FLAG LOADER
1729 010152 000410 BR 7$ ; GET OUT
1730 010154 122737 000123 010270 5$: CMPB #'S,INBUF ; IS IT STAGGERED LOOP BACK ?
1731 010162 001007 BNE 6$ ; WHAT ?
1732 010164 013715 010212 MOV 3$,(R5) ; YES STORE INFO
1733 010170 105037 001424 CLRB MNTFLG ; ZERO BITS
1734 010174 062716 000002 7$: ADD #2,(SP) ; POP AROUND
1735 010200 000002 RTI
1736 010202 104404 6$: INSTER ; RETRY
1737 010204 000733 BR .SETFLG ; DITTO
1738 010206 000200 1$: .WORD 200 ; EXTERNAL = E
1739 010210 000000 2$: .WORD 0 ; INTERNAL = I
1740 010212 100000 3$: .WORD 100000 ; STAGGERED = S
1741

```

```

1742                                     ;COMPARE THE FIRST CHARACTER IN THE TELETYPE INPUT
1743                                     ;BUFFER TO THE CHARACTERS "E" AND "C"
1744                                     ;IF THE CHARACTER IS "E" CLEAR THE FLAG
1745                                     ;IF THE CHARACTER IS "C" SET THE FLAG
1746
1747 010214 017605 000000 .PAWCH:MOV      2(SP),R5
1748 010220 142737 000040 010270 BICB    #40,INBUF      ;SET FOR LOWER CASE INPUT
1749 010226 122737 000105 010270 CMPB    #'E,INBUF      ;IS IT "E" ?
1750 010234 001002 BNE     1$
1751 010236 105015 CLRB    (R5)           ;000
1752 010240 000406 BR      2$
1753 010242 122737 000103 010270 1$:  CMPB    #'C,INBUF      ;IS IT "C" ?
1754 010250 001005 BNE     3$
1755 010252 112715 177777 MOVB    #-1,(R5)       ;3177
1756 010256 062716 000002 2$:  ADD     #2,(SP)
1757 010262 000002 RTI
1758 010264 104404 3$:  INSTER
1759 010266 000752 BR      .PAWCH      ;RETRY
1760
1761                                     ;BUFFERS FOR INPUT-OUTPUT
1762
1763 010270 000000 INBUF:  0
1764 .+.40
1765 010332 000000 TEMP:   0
1766 .+.40
1767 010374 000000 MDATA:  0
1768 .+.40
1769
    
```

E05

MD-11-DVDZB-A MACY11 30(1046) 28-JUL-77 07:37 PAGE 38
 DVDZBA.P11 28-JUL-77 07:37 POWER DOWN AND UP ROUTINES

SEQ 0056

```

1770
1771
1772
1773
1774
1775
1776
1777
1778
1779 010436 005737 001406          CYCLE: TST      DZVACTV      ;ARE ANY DZV11'S TO BE TESTED?
1780 010442 001004                      BNE      1$          ;BR IF OK.
1781 010444 104402 007513          TYPE     ,MERR2     ;NO DZV11'S SELECTED!!
1782 010450 000000                      HALT                                ;STOP THE SHOW.
1783 010452 000776                      BR       -2         ;DISQUALIFY CONT. SW.
1784 010454 013737 004542 001354 1$: MOV     $MXCNT,$STMS ;RESTORE THE NUMBER OF ITERATIONS TO MAKE
1785 010462 033737 001412 001406 BIT     RUN,DZVACTV ;IS THIS ONE "ACTIVE"
1786 010470 001017                      BNE     2$          ;BR IF GOOD ONE FOUND.
1787 010472 006137 001412          ROL     RUN        ;UPDATE POINTER
1788 010476 005537 001412          ADC     RUN        ;CATCH CARRY FROM RUN
1789 010502 062737 000012 001420 ADD     $I2,ACTIVE  ;UPDATE ADDRESS POINTER.
1790 010510 022737 001740 001420 CMP     $DZV.END,ACTIVE ;HAVE WE PASSED THE END OF THE MAP?
1791 010516 001356                      BNE     1$          ;IF NO, KEEP GOING; NOT ALL TESTED FOR.
1792 010520 012737 001500 001420 MOV     $DZV.MAP,ACTIVE ;RESET ADDRESS POINTER.
1793 010526 000752                      BR      1$          ;KEEP LOOKING FOR ACTIVE DZV11
1794 010530 006137 001412          ROL     RUN        ;UPDATE POINTER.
1795 010534 005537 001412          ADC     RUN        ;CATCH CARRY.
1796 010540 013700 001420          MOV     ACTIVE,RO  ;GET ADDRESS POINTER.
1797 010544 062737 000012 001420 ADD     $I2,ACTIVE  ;UPDATE.
1798 010552 022737 001740 001420 CMP     $DZV.END,ACTIVE
1799
1800 010560 001003                      BNE     3$          ;ALL DONE?
1801 010562 012737 001500 001420 MOV     $DZV.MAP,ACTIVE ;BR IF NO.
1802 010570 012037 001174          MOV     (RO)+,$BASE ;RESTORE POINTER.
1803 010574 012037 002040          MOV     (RO)+,$DZVRIV ;LOAD SYSTEM CTRL. REG
1804 010600 012037 001366          MOV     (RO)+,LINE  ;LOAD VECTOR
1805 010604 012037 001370          MOV     (RO)+,$PAR  ;SET UP DZV LINES ACTIVE
1806 010610 012037 001372          MOV     (RO)+,MODE  ;SET UP PARAMETERIZATION
1807 010614 105037 001424          CLR     MNTFLG ;RESET MAINT. FLAG IF
1808 010620 005737 001372          TST     MODE       ;RUNNING TESTS
1809 010624 001003                      BNE     9$          ;IN
1810 010626 112737 000010 001424 MOV     $MAINT,MNTFLG ;INTERNAL MAINT. MODE
1811 010634 004737 011002          JSR     PC,DZVLEV  ;SET UP
1812 010640 005737 000042          TST     $42        ;ARE WE UNDER MONITOR CONTROL?
1813 010644 001051                      BNE     7$          ;IF YES, SKIP THIS SETUP
1814 010646 032777 000002 170430 BIT     $SW01,$SWR  ;IF SW01=1, GET STARTING TEST #
1815 010654 001445                      BEQ     7$          ;BR IF NO TEST IS TO BE INPUTTED
1816 010656 104402 001357          TYPE     ,SCRLF
1817 010662 104403
1818 010664 007673
1819 010666 104405
1820 010670 000001
1821 010672 001000
1822 010674 001246
1823 010676 000
1824 010677 001
1825 010700 012700 012170          MOV     $TST1,RO
;CALL THE STRING INPUT ROUTINE
;POINTER TO MESSAGE TO BE PRINTED
;CALL THE OCTAL TO ASCII CONVERT ROUTINE
;LOWEST LEGITIMATE VALUE OF EXPECTED RESPONSE
;HIGHEST LEGITIMATE VALUE OF EXPECTED RESPONSE
;POINTER TO MAP LOCATION TO BE FILLED
;MASK OF INVALID BITS FOR THIS PARAMETER
;NUMBER OF PARAMETERS TO STORE

```

```

1826 010704 022710 000004      55:   CMP      #4,(R0)
1827 010710 001020              BNE      65
1828 010712 022760 012737 000002   CMP      #12737,2(R0)
1829 010720 001014              BNE      65
1830 010722 023760 001246 000004   CMP      $STNM,4(R0)
1831 010730 001010              BNE      65
1832 010732 010037 001252   MOV      R0,$LPADR
1833 010736 062737 000002 001252   ADD      #2,$LPADR
1834 010744 104402 001357   TYPE    $CALF
1835 010750 000412              BR       65
1836 010752 005720      65:   TST      (R0)+
1837 010754 020027 014322   CMP      R0,$TLAST+10
1838 010760 001351              BNE      55
1839 010762 104402 001356   TYPE    $QUES
1840 010766 000733              BR       45
1841 010770 012737 012170 001252 75:   MOV      $TST1,$LPADR ;PREPARE TEST ADDRESS
1842 010776              85:
1843 010776 000177 170250   RESTART:JMP $LPADR ;GO START TESTING.***WARNING!***
1844                                     ;THIS JUMP IS USED BY POWER UP ROUTINE!!!!
1845
1846                                     ;THIS UTILITY SETS UP CSR'S,SETS UP VECTORS.
1847 011002 013700 002040   DZVLEV: MOV      DZVRIV,R0 ;PLACE THE BASE VECTOR ADDRESS IN R0
1848 011006 062700 000002   ADD      #2,R0 ;CALCULATE THE RECEIVER INTERRUPT STATUS ADDR.
1849 011012 010037 002042   MOV      R0,DZVRIS ;STORE IT HERE
1850 011016 062700 000002   ADD      #2,R0 ;CALCULATE THE TRANSMITTER INTERRUPT VECTOR
1851 011022 010037 002044   MOV      R0,DZVTIV ;STORE IT HERE
1852 011026 062700 000002   ADD      #2,R0 ;CALCULATE THE TRANSMITTER VECTOR STATUS ADDRESS
1853 011032 010037 002046   MOV      R0,DZVTIS ;STORE IT HERE
1854
1855                                     ;THIS SEGMENT SETS UP POINTERS FOR THE GIVEN DZV11. $BASE IS THE BASE ADDRESS
1856                                     ;OF THE DEVICE
1857 011036 013700 001174   MOV      $BASE,R0 ;COPY THE ADDRESS BEING LOADED
1858 011042 010037 002010   MOV      R0,DZVCSR ;XXX0
1859 011046 005200   INC      R0
1860 011050 010037 002012   MOV      R0,HDZVCSR ;XXX1
1861 011054 005200   INC      R0
1862 011056 010037 002014   MOV      R0,DZVRBUF ;XXX2
1863 011062 010037 002020   MOV      R0,DZVLPR ;XXX2
1864 011066 005200   INC      R0
1865 011070 010037 002016   MOV      R0,HDZVRBUF ;XXX3
1866 011074 010037 002022   MOV      R0,HDZVLPR ;XXX3
1867 011100 005200   INC      R0
1868 011102 010037 002024   MOV      R0,DZVTCR ;XXX4
1869 011106 005200   INC      R0
1870 011110 010037 002026   MOV      R0,HDZVTCR ;XXX5
1871 011114 005200   INC      R0
1872 011116 010037 002030   MOV      R0,DZVMSR ;XXX6
1873 011122 010037 002034   MOV      R0,DZVTDR ;XXX6
1874 011126 005200   INC      R0
1875 011130 010037 002032   MOV      R0,HDZVMSR ;XXX7
1876 011134 010037 002036   MOV      R0,HDZVTDR ;XXX7
1877 011140 000207   RTS      PC
    
```



```

1931                                     ;#ROUTINE USED TO SET UP THE DIAGNOSTIC VIA APT.
1932                                     ;#IF BIT7 IN THE ENVIRONMENT MODE (SEVM) BYTE IS SET
1933                                     ;#THE PROGRAM WILL LOAD ITS PARAMETERS FROM THE ETABLE.
1934
1935 011336 012700 001500 SETAPT: MOV #DZV.MAP,R0 ;POINT TO THE DEVICE MAP TABLE
1936 011342 013701 001174 MOV #BASE,R1 ;BUILD DEVICE ADDRESSES IN R1
1937 011346 013702 001170 MOV #VECT1,R2 ;BUILD DEVICE VECTORS IN R2
1938 011352 042702 177007 BIC #C<770>,R2 ;STRIP AWAY OTHER INFORMATION
1939 011356 012704 001204 MOV #SDO0,R4 ;POINT TO THE BEGINNING OF DEVICE PARAMETERS
1940 011362 013705 001176 MOV #DEVH,R5 ;GET THE MAP OF ACTIVE DEVICES
1941 011366 105037 001414 CLRB DZVNUM ;INITIALIZE THE NO. OF ACTIVE DEVICES
1942 011372 005037 001410 CLR SAVACTV ;CLEAR THE ACTIVE BIT MAP
1943 011376 006005 1S: ROR R5 ;GET A DEVICE SELECTION BIT
1944 011400 103407 BCS 3S ;IF IT IS SELECTED, GO SET UP A MAP
1945 011402 001422 BEQ 5S ;IF NO MORE ARE SELECTED, GET OUT OF SETUP
1946 011404 005724 TST (R4)+ ;POINT TO NEXT DEVICE DESCRIPTOR
1947 011406 062701 000010 2S: ADD #10,R1 ;SET UP THE NEXT ADDRESS
1948 011412 062702 000010 ADD #10,R2 ;SET UP THE NEXT VECTOR GROUP
1949 011416 000767 BR 1S ;GO SEE IF MORE DEVICES REMAIN
1950 011420 006137 001410 3S: ROL SAVACTV ;SET BIT IN ACTIVE DEVICE MAP
1951 011424 105237 001414 INCB DZVNUM ;INCREMENT NO. OF ACTIVE DEVICES
1952 011430 010120 MOV R1,(R0)+ ;LOAD DEVICE ADDRESS
1953 011432 010220 MOV R2,(R0)+ ;LOAD THE VECTOR ADDRESS
1954 011434 013720 001200 MOV #CDW1,(R0)+ ;GET THE NUMBER OF LINES IN OPERATION
1955 011440 012420 MOV (R4)+,(R0)+ ;LOAD DEVICE PARAMETERS
1956 011442 013720 001202 MOV #CDW2,(R0)+ ;LOAD DEFAULT TESTING MODE
1957 011446 000757 BR 2S ;GO BUILD THE NEXT ADDRESS
1958 011450 012710 177777 5S: MOV #-1,(R0) ;TERMINATE THE DEVICE MAP
1959 011454 012737 001142 001304 MOV #SSWREG,SWR ;SET TO SOFTWARE APT SWITCH REGISTER
1960 011462 000207 RTS PC ;RETURN TO PRINT STATUS TABLE

```

```

1961
1962                                     ;#ROUTINE USED TO "AUTO SIZE" THE DZV11
1963                                     ;#CSR AND VECTOR.
1964                                     ;#NOTE: THE CSR MAY BE ANY WHERE IN THE FLOATING
1965                                     ;# ADDRESS RANGE (160000:163770)
1966                                     ;# AND THE VECTOR MAY BE ANY WHERE IN THE
1967                                     ;# FLOATING VECTOR RANGE (300:770)
1968                                     ;#
1969                                     ;#
1970
1971 AUTO.SIZE:
1972 011464 000005 RESET ;INSURE A BUS INIT.
1973 011466 105337 001422 DECB INIFLG ;SHOW THAT I WAS HERE
1974 011472 012702 001500 CSRMAP: MOV #DZV.MAP,R2 ;LOAD MAP POINTER.
1975 011476 012703 001204 MOV #SDO0,R3 ;POINT TO ETABLE DEVICE DESCRIPTOR WORDS
1976 011502 005022 1S: CLR (R2)+ ;ZERO ENTIRE MAP
1977 011504 022702 001740 CMP #DZV.END,R2 ;ALL DONE?
1978 011510 001374 BNE 1S ;BR IF NO
1979 011512 105037 001414 CLRB DZVNUM ;SET OCTAL NUMBER OF DZV11'S TO 0
1980 011516 012702 001500 MOV #DZV.MAP,R2
1981 011522 012701 160000 MOV #160000,R1 ;SET FOR FIRST ADDRESS TO BE TESTED
1982 011526 012737 011772 000004 MOV #65,2#4 ;SET FOR NON-EXISTENT DEVICE TIME OUT
1983 011534 052711 000040 2S: BIS #BIT5,(R1) ;TRY TO SET MASTER SCAN ENABLE
1984 011540 052761 000017 000004 BIS #17,4(R1) ;TRY TO TRANSMIT ON ANY LINE
1985 011546 005000 CLR R0 ;USE R0 AS A COUNTER
1986 011550 005711 7S: TST (R1) ;HAS TRANSMITTER READY COME UP?

```

1987	011552	100403			BMI	8S			: IF SO, GO GET A FINAL CHECK
1988	011554	005300			DEC	R0			: REDUCE COUNT. TIME UP?
1989	011556	001374			BNE	7S			: IF NOT, KEEP WAITING
1990	011560	000437			BR	3S			: ASSUME IT'S NOT A DZV11
1991	011562	032761	000017	000004	8S:	BIT	#17,4(R1)		: ARE ANY TCR BITS STILL SET? THEY SHOULD BE
1992	011570	001433			BEQ	3S			: IF IT'S NOT, ASSUME IT'S NOT A DZV11
1993	011572	032711	000040		BIT	#BITS,(R1)			: IS MASTER SCAN ENABLE STILL SET?
1994	011576	001430			BEQ	3S			: IF NOT, ASSUME IT'S NOT A DZV11
1995	011600	052711	000020		BIS	#20,(R1)			: SET DEVICE CLEAR
1996	011604	000240			NOP				
1997	011606	032711	000040		BIT	#40,(R1)			: DID SCANNER CLEAR
1998	011612	001022			BNE	3S			: IF NOT ASSUME IT IS NOT DZV
1999	011614	005061	000004		CLR	4(R1)			: GET RID OF TCR BITS
2000									: AT THIS POINT IT IS ASSUMED THAT R1 HOLDS A DZV11 CSR ADDRESS.
2001	011620	010122			MOV	R1,(R2)+			: STORE CSR IN CORE TABLE.
2002	011622	005722			TST	(R2)+			: POP OVER VECTOR STORE AREA
2003	011624	012722	000017		MOV	#17,(R2)+			: SET THE DEFAULT LINE SELECTION PARAMETER
2004	011630	012712	017470		MOV	#17470,(R2)			: SET THE DEFAULT PARAMETERS
2005	011634	012223			MOV	(R2)+,(R3)+			: COPY PARAMETERS INTO ETABLE DESCRIPTOR
2006	011636	005022			CLR	(R2)+			: SET THE DEFAULT MODE OF OPERATION
2007	011640	012712	177777		MOV	#-1,(R2)			: TERMINATE LIST
2008	011644	105237	001414		INCB	DZVNUM			: UPDATE DEVICE COUNTER
2009	011650	122737	000020	001414	CMPB	#20,DZVNUM			: ARE MAX. NO. OF DEV FOUND?
2010	011656	001405			BEQ	100S			: YES DON'T LOOK FOR ANY MORE.
2011	011660	052701	000010		3S:	ADD	#10,R1		: UPDATE CSR POINTER ADDRESS
2012	011664	022701	164000		CMP	#164000,R1			
2013	011670	001321			BNE	2S			: BR IF MORE ADDRESS TO CHECK.
2014	011672				100S:				
2015	011672	105737	001414		TSTB	DZVNUM			: WERE ANY DZV11'S FOUND AT ALL?
2016	011676	001430			BEQ	5S			: ERROR AUTO SIZER FOUND NO DZV11'S IN THIS SYS.
2017	011700	113701	001414		MOVB	DZVNUM,R1			
2018	011704	012737	000001	001410	MOV	#1,SAVACTV			: CREATE A BIT MAP OF
2019	011712	005301			4S:	DEC	R1		: THE DEVICES IN THE SYSTEM
2020	011714	001404			BEQ	98S			
2021	011716	000261			SEC				
2022	011720	006137	001410		ROL	SAVACTV			
2023	011724	000772			BR	4S			
2024	011726	013737	001500	001174	98S:	MOV	DZCRO,SBASE		: POINT TO THE ADDRESS OF FIRST DEVICE
2025	011734	013737	001510	001202	MOV	MANTO,SCDW2			: INDICATE TO ETABLE WHAT MODE IS BEING USED
2026	011742	012737	000006	000004	99S:	MOV	#6,#4		: RESTORE TRAP VECTOR
2027	011750	013737	001410	001176	MOV	SAVACTV,SDEVM			: SAVE ACTIVE REGISTER
2028	011756	000410			BR	VECMAP			: GO FIND THE VECTOR NOW.
2029	011760	104402	007513		5S:	TYPE	MERR2		: NOTIFY OPR THAT NO DZV11'S FOUND.
2030	011764	005000			CLR	R0			: MAKE DATA DISPLAY ZERO
2031	011766	000000			HALT				: STOP THE SHOW
2032	011770	000776			BR	.-2			: DISABLE CONT. SW.
2033	011772	012716	011660		6S:	MOV	#3S,(SP)		: ENTERED BY NON-EXISTENT TIME-OUT
2034	011776	000002			RTI				: RETURN TO MAINSTREAM
2035									
2036	012000	012737	000200	000022	VECMAP:	MOV	#MASK,#22		: SET IOT TRAP PRIORITY
2037	012006	012737	012122	000020	MOV	#4S,#20			: SET IOT TRAP VECTOR
2038	012014	012702	001500		MOV	#DZV.MAP,R2			: SET SOFTWARE POINTER
2039	012020	012700	000300		MOV	#300,R0			: FLOATING VECTORS START HERE.
2040	012024	012701	000302		MOV	#302,R1			: PC OF IOT INSTR.
2041	012030	010120			1S:	MOV	R1,(R0)+		: START FILLING VECTOR AREA
2042	012032	012721	000004		MOV	#4,(R1)+			: WITH .+2; IOT

2070
2071
2072
2073
2074
2075
2076
2077
2078
2079
2080
2081
2082
2083
2084
2085
2086
2087
2088
2089
2090
2091
2092
2093
2094
2095
2096
2097
2098
2099
2100
2101
2102
2103
2104
2105
2106
2107
2108
2109
2110
2111
2112
2113
2114
2115
2116
2117
2118
2119
2120
2121
2122
2123
2124
2125

012170 000004
012172 012737 000001 001246
012200 012737 012632 001362
012206 012737 012546 001364
012214 104417
012216 104421
012220 005037 001374
012224 104422
012226 012702 000001
012232 052777 010040 167550
012240 030237 001366
012244 001533
012246 013700 001374
012252 006300
012254 010277 167544
012260 105777 167524
012264 100001
012266 104020
012270 005003
012272 005004
012274 005777 167510
012300 100404
012302 104414
012304 005204
012306 001372
012310 104003
012312 116077 001426 167514
012320 005260 001426
012324 020327 000017
012330 103006
012332 032777 020000 167450
012340 001413
012342 104013
012344 000411
012346 005004
012350 032777 020000 167432
012356 001004
012360 104414
012362 005204
012364 001371

```
***** TEST 1 *****  
:THIS TEST VERIFIES OVERRUN AND SILO ALARM  
:ONE LINE AT A TIME - BASED UPON VALID LINES  
:AS EACH OF THE FIRST 16 CHARS ARE SENT; SILO ALARM IS  
:TESTED TO BE CLEARED. ON THE 16TH CHAR THE PROGRAM THEN  
:EXPECTS SILO ALARM TO SET. THEN THE ENTIRE  
:SILO IS FILLED AND AN OVERRUN IS EXPECTED ON THE 65TH  
:CHAR PULLED OUT OF THE SILO.  
:ERROR PRINTOUTS WILL REPORT TRANSMITTING LINE NO.  
:USING SWITCH NINE FOR THIS TEST SENDS 20. CHARACTERS  
:ON DZV LINE PREVIOUSLY SELECTED CONTINUOUSLY WHILE SW09=1.  
:USED TO SCOPE SILO ALARM PULSES, ETC.  
::* TEST 1  
:*****  
TST1: SCOPE  
MOV #1,STSTM ;LOAD THE NUMBER OF THIS TEST  
MOV #TST2,NEXT ;POINT TO THE START OF THE NEXT TEST  
MOV #18S,LOCK ;SET FOR LOOP  
DCLASH ;SET DCLR IN CSR AND SET MNTFLG  
LPRSET ;LOAD LINE PARAMETERS  
CLR SAVLIN ;INIT LINE INDICATOR  
BUFSET ;ZERO DATA BUFFER  
MOV #1,R2 ;LINE POINTER  
BIS #SENAB!SILOEN, @DZVCSR ;START SCANNER & SET SILO ENABLE  
3S: BIT R2,LINE ;VALID LINE?  
BEQ 21S ;IF NOT GO TO NEXT LINE  
MOV SAVLIN,R0 ;MAKE OFFSET  
ASL R0 ;MAKE POWER OF TWO  
MOV R2,@DZVTCR ;SET TCR BIT  
4S: TSTB @DZVCSR ;REC DONE = 1 ?  
BPL .+4  
ERROR 20 ;REC DONE SHOULD NOT = 1  
CLR R3 ;SET CHARACTER COUNT  
5S: CLR R4  
6S: TST @DZVCSR ;IS TRDY SET?  
BMI 7S ;IF YES, LOAD CHAR.  
DELAY ;WAIT FOR TRDY TO SET  
INC R4 ;INC DELAY COUNTER  
BNE 6S  
ERROR 3 ;*TRDY FAILED TO SET  
7S: MOVB TDO(R0),@DZVTDR ;LOAD A CHARACTER  
INC TDO(R0) ;SET UP NEXT CHARACTER  
CMP R3,#15. ;16 CHARACTERS ?  
BHS 8S  
BIT #SILOAL,@DZVCSR ;SILO ALARM = 0 ?  
BEQ 10S ;YES  
ERROR 13 ;*SILO ALARM SHOULD NOT = 1  
;UNTIL 16. DATA CHARACTERS  
BR 10S  
8S: CLR R4  
9S: BIT #SILOAL,@DZVCSR  
BNE 10S  
DELAY  
INC R4  
BNE 9S
```

L05

MD-11-DVDZB-A MACY11 30(1046) 28-JUL-77 07:37
 DVDZBA.P11 28-JUL-77 07:37

28-JUL-77 07:37 PAGE 45
 DZV11 DEVICE DIAGNOSTICS.

COPYRIGHT 1977 DIGITAL EQUIP. CORP.

SEQ 0063

```

2126 012366 104014          ERROR 14          ;#SILO ALARM FAILED TO SET!
2127                                ;SILO ALARM SHOULD =1 AFTER 16.
2128                                ;DATA CHARACTERS
2129 012370 005203          10$: INC R3          ;INC CHAR COUNT
2130 012372 022703 000102  CMP #66.,R3      ;FINISHED SENDING CHARACTERS ?
2131 012376 001335          BNE 5$          ;NO
2132 012400 005004          CLR R4
2133 012402 104414          DELAY
2134 012404 105204          INCB R4
2135 012406 001375          BNE -4
2136                                ;NOW LETS READ THE SILO
2137 012410 013705 001374  MOV SAVLIN,R5    ;MAKE EXPECTED LINE #
2138 012414 005737 001372  TST MODE        ;IS THIS TEST IN STAGGERED MODE?
2139 012420 100006          BPL 13$        ;IF NOT, SKIP STAGGERED SETUP
2140
2141                                ;WE MUST NOW INVERT THE LAST BIT OF THE LINE NUMBER
2142
2143 012422 006205          ASR R5          ;GET THE LAST BIT INTO THE CARRY BIT
2144 012424 103402          BCS 11$        ;IF IT IS SET, GO CLEAR IT
2145 012426 000261          SEC          ;IF IT IS CLEAR SET IT HERE
2146 012430 000401          BR 12$        ;SKIP THE CLEARING
2147 012432 000241          11$: CLC          ;CLEAR THE CARRY BIT (INVERSION OF LINE PARITY)
2148 012434 006105          12$: ROL R5     ;GET THE NEW BIT BACK INTO R5
2149 012436 000305          13$: SWAB R5     ;PUT IN UPPER BYTE
2150 012440 052705 100000  BIS #DVALID,R5 ;ADD DATA VALID
2151 012444 017704 167344  14$: MOV @DZVRBUF,R4 ;ACTUAL
2152 012450 020405          CMP R4,R5     ;ACTUAL VS. EXPECTED
2153 012452 001401          BEQ 15$      ;YES
2154 012454 104006          ERROR 6        ;#DATA/CONTENTS DID NOT COMPARE
2155 012456 032777 020000 167324 15$: BIT #SILOAL,@DZVCSR ;SILO ALARM= 0 ?
2156 012464 001401          BEQ 16$      ;YES
2157 012466 104016          ERROR 16       ;READING DZVRBUF DID NOT CLEAR SILO ALARM
2158 012470 005205          16$: INC R5
2159 012472 120527 000077  CMPB R5,#63.    ;UP CHARACTER
2160 012476 101762          BLOS 14$     ;LAST SILO CHAR ?....64TH CHAR
2161 012500 005205          INC R5
2162 012502 052705 040000  BIS #OVERRUN,R5 ;ADD OVERRUN TO EXPECTED
2163 012506 120527 000101  CMPB R5,#65.    ;LAST CHARACTER ?
2164 012512 001754          BEQ 14$
2165 012514 017704 167274  MOV @DZVRBUF,R4 ;FOR GOOD MEASURE
2166 012520 005704          TST R4       ;DATA VALID SHOULD = 0
2167 012522 100001          BPL 17$      ;YES
2168 012524 104017          ERROR 17       ;DATA VALID SHOULD = 0
2169 012526 040277 167272  17$: BIC R2,@DZVTCR ;CLR TCR BIT
2170 012532 104401          SCOP1
2171 012534 005237 001374  21$: INC SAVLIN ;INC EXPECTED LINE
2172 012540 104420          SHIFT
2173 012542 000137 012240  JMP 3$        ;NEXT LINE
2174
2175                                ;TIGHT SCOPE LOOP FOR THIS TEST. SENDS 20. CHARACTERS
2176                                ;ON DZV LINE PREVIOUSLY SELECTED CONTINUOUSLY WHILE SW09=1.
2177                                ;USED TO SCOPE SILO ALARM PULSES, ETC.
2178
2179 012546 052777 010040 167234 18$: BIS #MSENAB!SILOEN,@DZVCSR ;SETUP DEVICE
2180 012554 012777 012622 167262  MOV #20,@DZVTIV ;SETUP TRANSMITTER VECTOR
2181 012562 012701 000024  MOV #20.,R1    ;TEMPORARY COUNT OF CHARACTER BURST
  
```

M05

MD-11-DVDZB-A MACY11 30(1046) 28-JUL-77 07:37 PAGE 46
 DVDZBA.P11 28-JUL-77 07:37

DZV11 DEVICE DIAGNOSTICS.

COPYRIGHT 1977 DIGITAL EQUIP. CORP.

SEQ 0064

```

2182 012566 050277 167232      BIS      R2, 0ZVTCR      ;ENABLE LINE
2183 012572 052777 040000 167210  BIS      #TIE, 0ZVCSR   ;ENABLE INTERRUPTS
2184 012600 106427 000000      MTPS     #0           ;LOWER PRIORITY
2185 012604 000001      WAIT     ;ALLOW INTERRUPTS
2186 012606 077102      SOB      R1, 19$     ;REDUCE COUNT. ALL CHARACTERS SENT?
2187 012610 042777 050040 167172  BIC      #SILOEN!#SENAB!TIE, 0ZVCSR ;RESET SILO COUNTER, CLEAR STROBE
2188 012616 104401      SCOP1    ;LOOP AGAIN?
2189 012620 000742      BR       17$        ;IF NOT, RETURN TO WHERE YOU LEFT OFF
2190 012622 112777 000252 167204 20$:  MOVB    #252, 0ZVTDOR ;SEND A CHARACTER
2191 012630 000002      RTI     ;ALLOW MORE CHARACTERS TO COME
2192                                     ;***** TEST 2 *****
2193                                     ;*THIS TEST THAT "SILO ENABLE" WILL INHIBIT
2194                                     ;*RECEIVER INTERRUPTS AND THAT ON THE
2195                                     ;*16TH CHAR THAT "SILO ALARM" WILL CAUSE AN
2196                                     ;*INTERRUPT WITH "RIE" SET.
2197                                     ;*THIS WILL DO ALL SELECTED LINES ONE AT A TIME.
2198                                     ;*ERROR PRINTOUTS WILL REPORT TRANSMITTING LINE NO.
2199
2200                                     ;::* TEST 2
2201                                     ;*****
2201 012632 000004      TST2:   SCOPE
2202 012634 012737 000002 001246  MOV      #2, $TSTNM   ;LOAD THE NUMBER OF THIS TEST
2203 012642 012737 013132 001362  MOV      #TST3, NEXT  ;POINT TO THE START OF THE NEXT TEST
2204 012650 012737 012674 001364  MOV      #3$, LOCK   ;SET FOR LOOP
2205 012656 104417      DCLASM   ;SET DCLR IN CSR AND SET MNTFLG
2206 012660 104421      LPRSET   ;LOAD LINE PARAMETERS
2207 012662 005037 001374  CLR      SAVLIN      ;INIT LINE INDICATOR
2208 012666 104422      BUFSET   ;ZERO DATA BUFFER
2209 012670 012702 000001      MOV      #1, R2     ;LINE POINTER
2210 012674 012777 013104 167136 3$:  MOV      #1$, 0ZVRIV  ;SET FOR UNEXPECTED INTER.
2211 012702 012777 000200 167132  MOV      #MASK, 0ZVRI ;SET PRIO.
2212 012710 052777 010140 167072  BIS      ##SENAB!SILOEN!RIE, 0ZVCSR ;START SCANNER & SET SILO ENABLE
2213                                     ;VALID LINE?
2214 012716 030237 001366      BIT      R2, LINE   ;VALID LINE?
2215 012722 001477      BEQ     18$        ;IF NOT GO TO NEXT LINE
2216 012724 005777 167064      TST     0ZVVRBUF    ;EMPTY THE SILO
2217 012730 100775      BMI     .-4        ;BR IF DATA VALID IS SET!
2218 012732 106427 000000      MTPS     #0         ;SET PROCESSOR PRIORITY TO 0
2219 012736 013700 001374      MOV     SAVLIN, R0  ;MAKE OFFSET
2220 012742 006300      ASL     R0         ;MAKE POWER OF TWO
2221 012744 010277 167054      MOV     R2, 0ZVTCR ;SET TCR BIT
2222 012750 005004      CLR     R4
2223 012752 005777 167032 5$:  TST     0ZVCSR
2224 012756 100404      BMI     7$
2225 012760 104414      DELAY
2226 012762 005204      INC     R4
2227 012764 001372      BNE     6$
2228 012766 104003      ERROR   3
2229 012770 116077 001426 167036 7$:  MOVB    TDO(R0), 0ZVTDOR ;*TRDY FAILED TO SET
2230 012776 005260 001426      INC     TDO(R0)     ;LOAD A CHARACTER
2231 013002 022760 000017 001426  CMP     #15., TDO(R0) ;SET UP NEXT CHARACTER
2232 013010 001406      BEQ     8$         ;15 CHARS YET?
2233 013012 032777 020000 166770  BIT     #SILOAL, 0ZVCSR ;SILO ALARM = 0 ?
2234 013020 001401      BEQ     +4        ;YES
2235 013022 104013      ERROR   13       ;*SILO ALARM SHOULD NOT = 1
2236                                     ;UNTIL 16. DATA CHARACTERS
2237 013024 000752      BR      6$

```

N05

MD-11-DVDZB-A MACY11 30(1046) 28-JUL-77 07:37 PAGE 47

DVDZBA.P11 28-JUL-77 07:37

DZV11 DEVICE DIAGNOSTICS.

COPYRIGHT 1977 DIGITAL EQUIP. CORP.

SEQ 0065

```

2238 013026 012777 013112 167004 8S:  MOV  #12S, @DZVRIV  ;SET NEW VECTOR
2239 013034 005777 166750          TST  @DZVCSR      ;READY FOR 16TH CHAR
2240 013040 100375          BPL  -4
2241 013042 016077 001426 166764  MOV  TDO(R0), @DZVTDR ;LOAD THE 16TH CHAR.
2242 013050 005004          CLR  R4
2243 013052 032777 020000 166730 9S:  BIT  #SILOAL, @DZVCSR
2244 013060 001005          BNE  10S
2245 013062 104414          DELAY
2246 013064 005204          INC  R4
2247 013066 001371          BNE  9S
2248 013070 104014          ERROR 14
2249 013072 000410          BR   17S          ;#SILO ALARM FAILED TO SET!
2250                                ;SILO ALARM SHOULD =1 AFTER 16.
2251 013074 000240          10S: NOP
2252 013076 000240          NOP
2253 013100 104027          ERROR 27
2254 013102 000404          BR   17S          ;SILO ALARM NOT INTERRUPTING.
2255 013104 022626          11S: POP2SP        ;CONTINUE TEST.
2256 013106 104012          ERROR 12
2257 013110 000401          BR   17S          ;FAKE RTI
2258 013112 022626          12S: POP2SP        ;RX SHOULD NOT INTERRUPT
2259 013114 040277 166704 17S:  BIC  R2, @DZVTDR  ;CONTINUE
2260 013120 104401          SCOP1 ;GOOD INTERRUPT TO HERE.
2261 013122 005237 001374 18S:  INC  SAVLIN      ;CLR TCR BIT
2262 013126 104420          SHIFT ;LOOP?
2263 013130 000661          BR   3S          ;INC EXPECTED LINE
                                ;NEXT LINE
                                ;YES

```

2264
2265
2266
2267
2268
2269
2270
2271
2272
2273
2274
2275
2276
2277
2278
2279
2280
2281
2282
2283
2284
2285
2286
2287
2288
2289
2290
2291
2292
2293
2294
2295
2296
2297
2298
2299
2300
2301
2302
2303
2304
2305
2306
2307
2308
2309
2310
2311
2312
2313
2314
2315
2316
2317
2318
2319

013132 000004
013134 012737 000003 001246
013142 012737 013674 001362
013150 104417
013152 013737 001366 013672
013160 013737 001366 013412
013166 104421
013170 104422
013172 012777 013414 166640
013200 012777 000200 166634
013206 012777 013300 166630
013214 012777 000200 166624
013222 052777 040140 166560
013230 113777 001366 166566
013236 106427 000000

013242 005037 013276
013246 104414
013250 105737 013672
013254 001002
013256 000137 013620
013262 005237 013276
013266 001367
013270 104007
013272 104011
013274 104400
013276 000000

013300 117703 166506
013304 042703 177774
013310 010304
013312 010337 001374
013316 005777 166466
013322 100401
013324 104003
013326 012702 000001
013332 105303
013334 100402
013336 006302
013340 000774
013342 030237 001366
013346 001001
013350 104015
013352 030237 013412
013356 001003
013360 040277 166440
013364 000411

```
***** TEST 3 *****
*THIS TEST RUNS ALL LINES FULL BORE
*BASED UPON QUALIFIED LINES
*..THIS IS AN INTERRUPT TEST ON THE RECEIVER AND
*TRANSMITTER
::# TEST 3
*****
TST3: SCOPE
MOV #3,STSTNM ;LOAD THE NUMBER OF THIS TEST
MOV #TST4,NEXT ;POINT TO THE START OF THE NEXT TEST
DCLASM ;SET DCLR IN CSR AND SET MNTFLG
MOV LINE,RXTCR ;SET IMAGE OF TCR BITS
MOV LINE,TXTCR ;SET IMAGE OF TCR BITS
LPRSET ;LOAD LINE PARAMETERS
BUFSET ;ZERO DATA BUFFER
MOV #RXSVC,ADZVRIV ;SET UP REC INTR VECTOR
MOV #MASK,ADZVRIS ;STATUS
MOV #TXSVC,ADZVTIV ;SET UP TRANS INTR VECTOR
MOV #MASK,ADZVTIS ;STATUS
BIS #SENAB!RIE!TIE,ADZVCSR ;SET MASTER SCAN ENABLE
MOVB LINE,ADZVTCR ;SET TCR BITS
MTPS #CLEAR ;ALLOW INTERRUPTS

SNAP: CLR 4$ ;CLEAR DELAY COUNTER
2$: DELAY ;WAIT FOR RECEIVERS TO FINISH
TSTB RXTCR ;WAIT FOR ALL RECIEVERS TO FINISH
BNE 3$
JMP OUT
3$: INC 4$ ;INCREMENT DELAY COUNTER
BNE 2$ ;DELAY FINISHED?
ERROR 7 ;*TRANSMITTER FAILED TO INTERRUPT
ERROR 11 ;*RECEIVER FAILED TO INTERRUPT
ADVANCE ;LEAVE THIS TEST
4$: 0

:TRANS INTR SVC ROUTINE
TXSVC: MOVB #ADZVCSR,R3 ;FIND LINE NO.
BIC #C(3),R3 ;ISOLATE LINE NO.
MOV R3,R4 ;SAVE LINE NO.
MOV R3,SAVLIN ;SAVE LINE NO.
TST ADZVCSR ;TRANS READY SET ?
BMI +4
ERROR 3 ;*TRANSMITTER FAILED
MOV #1,R2 ;SET UP POSITION POINTER
3$: DECB R3 ;IS IT THIS LINE ?
BMI 4$ ;YES
ASL R2 ;UP THE LINE #
BR 3$ ;GO 'ROUND AGAIN
4$: BIT R2,LINE ;VALID LINE?
BNE +4 ;YES
ERROR 15 ;NO INVALID LINE!!!!
BIT R2,TXTCR ;DATA FINISHED?
BNE 6$ ;IF NOT SEND CHAR.
BIC R2,ADZVTCR ;CLEAR TCR BIT
BR 5$ ;RETURN
```

```

2320 013366 006304 6S: ASL R4 ;MAKE POWER OF 2
2321 013370 116477 001426 166436 MOVB TDO(R4),DZVTD ;LOAD CHARACTER
2322 013376 105264 001426 INCB TDO(R4) ;SET UP NEXT CHARACTER
2323 013402 001002 BNE 5$ ;LAST CHARACTER ?
2324 013404 040237 013412 BIC R2,TXTCR ;INDICAT LINE FINISHED
2325 013410 000002 5S: RTI
2326
2327 013412 000000 TXTCR: 0
2328
2329 ;REC INTR SVC ROUTINE
2330 013414 105777 166370 RXSVC: TSTB DZVCSR ;REC DONE ?
2331 013420 100401 BMI .+4 ;YES
2332 013422 104004 ERROR 4 ;FALSE INTERRUPT
2333 013424 032777 020000 166356 BIT #SILOAL,DZVCSR ;SILO ALARM?
2334 013432 001401 BEQ .+4 ;NO
2335 013434 104013 ERROR 13 ;SILO ALARM SHOULD NOT =1
2336 013436 017704 166352 MOV DZVRBUF,R4 ;SAVE IT
2337 013442 010403 MOV R4,R3
2338 013444 000303 SWAB R3
2339 013446 042703 177774 BIC #1C<3>,R3 ;STRIP JUNK
2340 013452 010337 001374 MOV R3,SAVLIN ;SAVE LINE NUMBER
2341 013456 005704 TST R4 ;DATA VALID?
2342 013460 100401 BMI 4$ ;IF YES SKIP ERROR PRINTOUT
2343 013462 104023 ERROR 23 ;YOU LOSE ...DATA VALID WAS'NT SET
2344 013464 032704 040000 4S: BIT #OVRUN,R4 ;TEST FOR OVERRUN
2345 013470 001401 BEQ 1$ ;IF NO OVERRUN SKIP ERROR
2346 013472 104024 ERROR 24 ;DATA OVERRUN
2347 013474 032704 020000 1S: BIT #FMERR,R4 ;DATA FRAMING ERROR
2348 013500 001401 BEQ 2$ ;IF NO FRAMING ERROR CONTINUE
2349 013502 104025 ERROR 25 ;FRAMING ERROR
2350 013504 032704 010000 2S: BIT #PARER,R4 ;TEST FOR PARITY ERROR
2351 013510 001401 BEQ 3$ ;BRANCH IF NO ERROR
2352 013512 104026 ERROR 26 ;TYPE OUT PARITY ERROR
2353 013514 012702 000001 3S: MOV #1,R2 ;SET UP POSITION POINTER
2354 013520 105303 5S: DECB R3
2355 013522 100402 BMI 6$
2356 013524 006302 ASL R2 ;RE POSITION POINTER
2357 013526 000774 BR 5$ ;GO 'ROUND AGAIN
2358 013530 030237 001366 6S: BIT R2,LINE ;LINE VALID ?
2359 013534 001001 BNE .+4 ;YES
2360 013536 104015 ERROR 15 ;INVALID LINE #
2361 013540 013703 001374 MOV SAVLIN,R3 ;GET THE LINE NUMBER AGAIN
2362 013544 006303 ASL R3 ;USE R3 AS A POINTER IN THE DATA TABLE
2363 013546 126304 001436 CMPB TRO(R3),R4 ;DOES THE DATA CHARACTER COMPARE ?
2364 013552 001410 BEQ 7$ ;YES
2365 013554 013705 001374 MOV SAVLIN,R5 ;MOVE LINE NO INTO EXPECTED
2366 013560 000305 SWAB R5 ;ADJUST TO HIGH BYTE
2367 013562 052705 100000 BIS #DVALID,R5 ;SET DVALID IN EXPECTED
2368 013566 056305 001436 BIS TRO(R3),R5 ;SET DATA IN EXPECTED
2369 013572 104005 ERROR 5 ;*NO, DATA DOES NOT COMPARE
2370 013574 005263 001436 7S: INC TRO(R3) ;SET UP FOR NEXT CHARACTER
2371 013600 105763 001436 TSTB TRO(R3) ;ALL CHARS DONE?
2372 013604 001002 BNE .+6
2373 013606 040237 013672 BIC R2,RXTCR ;ZERO LINE DONE INDICATOR.
2374 013612 012716 013242 MOV #SNAP,(SP) ;RESET THE BACKGROUND TIMING LOOP
2375 013616 000002 RTI

```

2376
2377
2378
2379 013620 106427 000200
2380 013624 104413
2381 013626 005003
2382 013630 005037 001374
2383 013634 012702 000001
2384 013640 030237 001366
2385 013644 001405
2386 013646 022763 000400 001436
2387 013654 001401
2388 013656 104030
2389
2390 013660 005237 001374
2391 013664 005723
2392 013666 104420
2393 013670 000763
2394 013672 000000
2395
2396
2397
2398
2399
400
401
402
403
404
405
406
407
408
409
410
411
412
413
414
415
416
417 013674 000004
418 013676 012737 000004 001246
419 013704 012737 014312 001362
420 013712 012737 014032 001364
421 013720 132737 000001 001140
422 013726 001405
423 013730 005737 001126
424 013734 001402
425 013736 000177 165420
426 013742 012737 000002 001354 10S:
427 013750 005037 015314
428 013754 005037 001374
429 013760 005037 001376
430 013764 012702 000001
431 013770 012703 010070

```

;FINISH UP ROUTINE
OUT:  MTPS  #MASK          ;STOP ALL INTERRUPTS
      DEVICE.CLR        ;CLEAR ALL INTERRUPTS AWAY
      CLR  R3
      CLR  SAVLIN
      MOV  #1,R2
1S:   BIT  R2,LINE        ;VALID LINE ?
      BEQ  2S            ;NO
      CMP  #400,TR0(R3)  ;RECEIVED A BINARY COUNT PATTERN ?
      BEQ  .+4           ;YES
      ERROR 30          ;THE LINE FAILED TO RECEIVE A FULL
                          ;BINARY COUNT PATTERN
2S:   INC  SAVLIN        ;SET UP FOR NEXT LINE
      TST  (R3)+         ;ADD 2
      SHIFT
      BR   1S           ;SET UP NEXT LINE POINTER
RXTCR: 0                ;FINISHED ?
                          ;RX IMAGE OF TCR BITS

```

```

***** TEST 4 *****
#DZV11 RELATIVE TIMING TEST.
#EACH SELECTED LINE WILL IN TURN RUN 16. CHARS
#AT ALL BAUD RATES AND THEN THE HIGHEST BAUD
#WITH ALL CHAR LENGTHS. EACH NEW PARAMETER SHOULD
#DECREASE IN TIME FROM THE PREVIOUS PARAMETERS SELECTED.
#THE TIME IS CHECKED AGAINST THE LAST PARAMETER USED
# AND A LOWER TIME IS EXPECTED ON THE CURRENT PARAMETER.
#PARAMETERS ARE:
# EIGHT BITS/PER/CHAR - TWO STOP BITS AT
# 50, 75, 110, 134.5, 150, 300, 600, 1200, 1800, 2000
# 2400, 3600, 4800, 7200, 9600 BAUD.
# 19.2 K BAUD - TWO STOP BITS AT
# SEVEN, SIX, FIVE BITS/PER/CHAR.
#AFTER EACH LINE HAS FINISHED ALL THE ABOVE PARAMETERS
#THE NEXT SELECTED LINE IS THEN TESTED.
#WHEN RUNNING UNDER THE APT MANUFACTURING SYSTEM
#THIS TEST IS ONLY RUN THE FIRST PASS

```

```

::# TEST 4
*****
TST4: SCOPE
      MOV  #4,STSTNM      ;LOAD THE NUMBER OF THIS TEST
      MOV  #TSTS,NEXT    ;POINT TO THE START OF THE NEXT TEST
      MOV  #3S,LOCK      ;USE THIS ADDRESS IF A TIGHT SCOPE LOOP IS SELECTED
      BITB #1,$ENV       ;RUNNING UNDER APT?
      BEQ  10S           ;IF NOT CONTINUE WITH TEST
      TST  $PASS         ;IF YES IS THIS FIRST PASS
      BEQ  10S           ;IF NOT 1ST PASS SKIP TEST
      JMP  @NEXT
10S:  MOV  #2,$TIMES     ;SET UP FOR 2 ITERATIONS
      CLR  OFFSET        ;RESET THIS VARIABLE
      CLR  SAVLIN        ;RESET LINE NUMBER INDICATOR
      CLR  XMTLIN        ;USE THIS WORD TO TELL WHAT LINE TRANSMITTED
      MOV  #1,R2         ;USE R2 AS A BIT POINTER
      MOV  @RCVON!550!EIGHT!TWOSTOP,R3 ;BUILD TEMPORARY PARAMETERS

```

2432	013774	030237	001366		1S:	BIT	R2,LINE		: IS THIS LINE ACTIVE?
2433	014000	001014				BNE	3S		: IF SO, GO GET STARTED
2434	014002	012703	010070		2S:	MOV	#RCVON!SSO!EIGHT		:TWO STOP, R3 :LOAD PARAMETERS TEMPORARILY
2435	014006	005237	001376			INC	XMTLIN		:POINT TO THE NEXT LINE TO TRANSMIT
2436	014012	042703	000007			BIC	#7,R3		:MAKE SURE TEMPORARY PARAMETERS POINT TO 0
2437	014016	053703	001376			BIS	XMTLIN,R3		:ADD DESIRED LINE NUMBER
2438	014022	005037	015314			CLR	OFFSET		
2439	014026	104420				SHIFT			:POINT TO THE NEXT LINE
2440	014030	000761				BR	1S		:PROCESS THE NEXT LINE
2441	014032				3S:				
2442	014032	104417				DCLASH			:CLEAR DEVICE AND SET MAINT BIT IF I MODE
2443	014034	042703	010000			BIC	#RCVON,R3		:ZERO PARAMTERS FOR TX LINE
2444	014040	010377	165754			MOV	R3,#DZVLPR		:LOAD PARAMTERS FOR TX
2445	014044	005737	001372			TST	MODE		:STAGGERED?
2446	014050	100007				BPL	100S		:BR IF NO
2447	014052	000241				CLC			:SET UP LINE
2448	014054	006003				ROR	R3		
2449	014056	103002				BCC	98S		:BR IF LINE WAS EVEN
2450	014060	000241				CLC			:PREPARE TO MAKE LINE EVEN
2451	014062	000401				BR	99S		:CONTINUE
2452	014064	000261			98S:	SEC			:PREPARE TO MAKE LINE ODD
2453	014066	006103			99S:	ROL	R3		:SET ALTERED LINE
2454	014070	052703	010000		100S:	BIS	#RCVON,R3		:SET RX ON
2455	014074	010377	165720			MOV	R3,#DZVLPR		:LOAD RX PARAMETERS
2456	014100	010337	001374			MOV	R3,#SAVLIN		:SET FOR RECEIV. LINE
2457	014104	042737	177774	001374		BIC	#1<3>,SAVLIN		:ISOLATE LINE NO.
2458	014112	042703	000003			BIC	#3,R3		:CLEAR OLD LINE #
2459	014116	053703	001376			BIS	XMTLIN,R3		:SET LINE UP AGAIN
2460	014122	010337	001402			MOV	R3,REGIST		:SAVE PARAMETERS FOR PRINTOUT
2461	014126	104422				BUFSET			:ZERO DATA BUFFER
2462	014130	005037	001342			CLR	\$TMP0		:USE \$TMP0 TO COUNT TOTAL NUMBER OF TRANSMISSIONS
2463	014134	005037	001344			CLR	\$TMP1		:INITIALIZE THE TIMER
2464	014140	005037	001350			CLR	\$TMP3		:INITIALIZE THESE BITS ALSO
2465	014144	012737	000020	001400		MOV	#20,XMTCNT		:SET HOW MANY CHARACTERS TO TRANSMIT
2466	014152	012777	014742	165664		MOV	#XMTSRV,#DZVTIV		
2467	014160	012777	015112	165652		MOV	#RXISR1,#DZVRIV		
2468	014166	012777	000200	165646		MOV	#MASK,#DZVRIS		
2469	014174	012777	000200	165644		MOV	#MASK,#DZVTIS		
2470	014202	110277	165616			MOVB	R2,#DZVTCR		:START THE VALID LINE
2471	014206	052777	040140	165574		BIS	#TIE!RIE!MSENAB,#DZVCSR		
2472	014214	106427	000000			MTPS	#0		:LOWER THE PRIORITY TO ALLOW INTERRUPTS
2473	014220	032777	000100	165562	4S:	BIT	#RIE,#DZVCSR		:IS ROUTINE DONE?
2474	014226	001407				BEQ	5S		:WHEN ALL IS DONE RX IE IS CLEARED IN ISR.
2475	014230	005237	001344			INC	\$TMP1		:INCREMENT TIMER
2476	014234	001371				BNE	4S		:WHEN IT OVERFLOWS
2477	014236	005237	001350			INC	\$TMP3		:CATCH CARRY
2478	014242	001366				BNE	4S		:CONTINUE TEST
2479	014244	104011				ERROR	11		:INTERRUPTS NOT FINISHED
2480	014246	004737	006772		5S:	JSR	PC,SERV.G		:<1G>?
2481	014252	104401				SCOPI			:LOOP?
2482	014254	062737	000002	015314		ADD	#2,OFFSET		
2483	014262	022703	017400			CMP	#17400,R3		
2484	014266	003006				BGT	6S		
2485	014270	032703	000030			BIT	#BIT4+BIT3,R3		:IS CHARACTER SIZE DONE?
2486	014274	001642				BEQ	2S		
2487	014276	162703	000010			SUB	#BIT3,R3		

```

188 014302 000653
189 014304 062703 000400
190 014310 000650
191
192
193
194
195
196
197
198
199
200
201
202
203
204
205
206
207
208
209
210
211
212
213
214
215
216
217
218
219
220
221
222
223
224
225
226
227
228
229
230
231
232
233
234
235
236
237
238
239
240
241
242
243

```

```

65: BR 35
ADD #400,R3
BR 35
***** TEST 5 *****
*THE MAIN FUNCTION OF THIS TEST IS TO VERIFY
*THAT "PE" (PARITY ERROR) CAN BE FLAGGED BY
*THE UARTS. THIS TEST WILL NOT BE DONE UNLESS
*YOU ARE IN "STAGGERED" MODE.
*40(8) CHARS ARE USED FOR THIS TEST.
*ALL SELECTED LINES WILL BE ENABLED AT THE SAME TIME.
*THIS TEST FIRST CHECKS EVEN PARITY FOR ODD LINES AND
*ODD PARITY FOR EVEN LINES, THEN IT CHECKS THE REVERSE.
::# TEST 5
*****
TST5: SCOPE
MOV #5,STSTNM ;LOAD THE NUMBER OF THIS TEST
MOV #SEOP,NEXT ;POINT TO THE END-OF-PASS HANDLER
TST MODE ;IS THIS STAGGERED MODE?
BPL 175 ;IF NOT, DON'T DO THIS TEST
CLRB DONFLG ;SET UP FOR FIRST TEST PASS
145: DEVICE.CLR ;SET DCLR IN CSR
MOV PAR,R1 ;USE R1 TO BUILD PARAMETERS TO BE LOADED
BIC #000PAR,R1 ;MAKE SURE ODD PARITY ISN'T SET
BIS #PARITY,R1 ;MAKE SURE PARITY IS TURNED ON
MOV #1,R2 ;USE R2 AS A LINE POINTER
15: BIT R2,LINE ;IS THIS A VALID LINE?
BEQ 35 ;IF NOT, SKIP TO THE NEXT LINE
TSTB DONFLG ;FIRST PASS THROUGH TEST?
BNE 155 ;IF NO BRANCH
BIT #BIT0,R1 ;IS THIS LINE AN ODD LINE?
BNE 25 ;IF IT'S ODD, USE EVEN PARITY
BR 165 ;IF EVEN SET FOR ODD PARITY
155: BIT #BIT0,R1 ;IF THE LINE IS EVEN SET FOR EVEN PAR.
BEQ 25 ;GO LOAD PARAMETER
165: BIS #000PAR,R1 ;IF IT'S ODD, USE ODD PARITY
25: MOV R1,JDZVLP ;LOAD THE LINE PARAMETER REGISTER
BIC #000PAR,R1 ;SET UP THE NEXT PARITY TO EVEN
35: INC R1 ;POINT TO THE NEXT LINE
ASL R2 ;
BIT #BIT4,R2 ;ALL LINES DONE?
BEQ 15 ;IF NOT, GO CHECK THE NEXT LINE
CLR SAVLIN ;CLEAR THE LINE NUMBER INDICATOR
CLR STMPD ;USE STMPD TO COUNT TOTAL NUMBER OF TRANSMISSIONS
CLR R3 ;USE R3 TO COUNT TOTAL NUMBER OF RECEPTIONS
MOV #40,XMTCNT ;TRANSMIT A BINARY COUNT PATTERN(00-40)
BLFSET ;ZERO BUFFER AREA
MOV #XMTSRV,JDZVTIV ;SET UP THE TRANSMITTER INTERRUPT VECTOR
MOV #95,JDZVRIV ;SET UP THE RECEIVER INTERRUPT VECTOR
MOV #MASK,JDZVRIS ;SET THE INTERRUPT VECTOR STATUS
MOV #MASK,JDZVTIS ;SET TRANSMITTER INTERRUPT PRIORITY
BIS #RIE!TIE!MSENAB,JDZVCSR ;ENABLE THE DEVICE
MOV# LINE,JDZVTCR ;ENABLE ALL SELECTED LINES
MTPS #0 ;ALLOW INTERRUPTS
45: CLR 75
CLR 85
55: BIT #RIE,JDZVCSR ;WHEN RX DONE; RIE WILL =0

```

2584	014554	001407				BEQ	6\$;BR IF ALL DONE
2585	014556	005237	014614			INC	7\$		
2586	014558	001371				BNE	5\$		
2587	014564	105237	014616			INCB	8\$		
2588	014570	100366				BPL	5\$		
2589	014572	104011				ERROR	11		;;RX FAILED TO FINISH (INTERRUPT)
2590	014574	106427	000200		6\$:	MTPS	8\$MASK		;;SHUT OFF INTERRUPTS
2591	014600	105737	001425			TSTB	DONFLG		;;IS THIS SECOND TEST PASS
2592	014604	001005				BNE	17\$;;IF SO GET OUT
2593	014606	105237	001425			INCB	DONFLG		;;INDICATE FIRST TEST PASS DONE
2594	014612	000653				BR	14\$;;START OVER
2595	014614	000000			7\$:	0			
2596	014616	000000			8\$:	0			
2597	014620	104400			17\$:	ADVANCE			
;RECEIVER SERVICE ROUTINE									
2598	014622	017704	165166		9\$:	MOV	2DZVRBUF,R4		;GET THE CHARACTER
2599	014626	010401				MOV	R4,R1		;COPY THE RECEIVED INFORMATION
2600	014630	000301				SWAB	R1		;GET THE LINE NUMBER IN THE LOWER BYTE
2601	014632	042701	177774			BIC	#1C<3>,R1		;ISOLATE THE LINE NUMBER
2602	014636	010137	001374			MOV	R1,SAVLIN		;SET LINE INDIC. TO RECEIVING LINE
2603	014642	005704				TST	R4		;IS DATA VALID SET?
2604	014644	100401				BMI	10\$;IF YES DON'T PRINT ERROR
2605	014646	104023				ERROR	23		;DATA VALID NOT SET
2606	014650	010105			10\$:	MOV	R1,R5		;BUILD LINE NO. FOR
2607	014652	000305				SWAB	R5		;EXPECTED DATA IN RECEIVER BUFFER
2608	014654	006301				ASL	R1		;ADJUST R1 FOR OFFSET
2609	014656	156105	001436			BISB	TRD(R1),R5		;LOAD CHARACTER IN EXPECTED
2610	014662	052705	110000			BIS	#DVALID!PARER,R5		;BUILD WHAT WAS EXPECTED
2611	014666	020405				CMP	R4,R5		;DOES RECEIVED=EXPECTED
2612	014670	001401				BEQ	12\$;IF YES DON'T PRINT ERROR
2613	014672	104006				ERROR	6		;ERROR- DID NOT GET CORRECT INFORMATION
2614	014674	005261	001436		12\$:	INC	TRD(R1)		;SET UP THE NEXT CHARACTER
2615	014700	005203				INC	R3		;ADD TO THE TOTAL RECEIVED COUNT
2616	014702	032777	040000	165100		BIT	#TIE,2DZVCSR		;ARE TRANSMISSIONS DONE?
2617	014710	001011				BNE	13\$;IF NO, GO RECEIVE SOME MORE
2618	014712	023703	001342			CMP	\$TMP0,R3		;ARE ALL CHARACTERS RECEIVED?
2619	014716	001006				BNE	13\$;IF NO, GO RECEIVE SOME MORE
2620	014720	042777	000100	165062		BIC	#RIE,2DZVCSR		;DISABLE RECEIVER INTERRUPTS
2621	014726	012716	014574			MOV	#6\$, (SP)		;CRUNCH THE STACK
2622	014732	000002				RTI			;RETURN AND FINISH
2623	014734	012716	014536		13\$:	MOV	#4\$, (SP)		;CRUNCH THE STACK
2624	014740	000002				RTI			;GO BACK TO RECEIVER WAIT LOOP

2600
2601
2602
2603
2604
2605
2606
2607
2608
2609
2610
2611
2612
2613
2614
2615
2616
2617
2618
2619
2620
2621
2622
2623
2624
2625
2626
2627
2628
2629

 ; TRANSMITTER INTERRUPT SERVICE

```

XMTSRV:  MOVB    @DZVCSR,R1      ;GET THE LINE NUMBER.
          BIC     #C(3),R1      ;CLEAR JUNK
          MOV     SAVLIN,R5      ;SAVE REC. LINE NO.
          MOV     R1,SAVLIN      ;LOAD TRANS LINE NO FOR ERROR PRINTOUT
          ASL    R1              ;ADJUST R1 FOR OFFSET
          CMP    XMTCNT,TDO(R1)  ;HAVE ALL CHAR. BEEN SENT
          BLE    6S              ;IF YES GO CLEAR TCR
          TST    @DZVCSR         ;TRDY SET?
          BMI    2S              ;IF YES GO LOAD CHAR.
          ERROR   3              ;*TRANSMITTER NOT READY- FALSE INTERRUPT
          MOVB   TDO(R1),@DZVTDR ;LOAD THE CURRENT CHARACTER FOR THIS LINE
          INC    TDO(R1)         ;SET UP NEXT CHARACTER FOR THIS LINE
          INC    $TMPD           ;UP THE NUMBER OF TRANSMISSIONS
          BR     7S              ;GO RETURN
          6S:   MOV     #1,R0      ;SET UP A DESELECTION POINTER
          ASR    R1              ;GET LINE NO. AGAIN
          12S:  DEC     R1         ;REDUCE THE COUNT. WAS THIS THE LINE?
          BMI    3S              ;IF SO, GO DISABLE THE ENABLE BIT FOR IT
          ASL    R0              ;MOVE THE POINTER TO THE NEXT LINE
          BR     12S             ;GO CHECK THE NEXT LINE
          3S:   BICB   R0,@DZVTCR ;DISABLE THE LINE POINTED TO BY R0
          BNE    7S              ;IF MORE LINES ARE ACTIVE, GO CONTINUE TRANSMIT
          BIC    #TIE,@DZVCSR    ;IF NOT, DISABLE TRANSMITTER INTERRUPTS
          7S:   MOV     R5,SAVLIN  ;RESTORE RECEIV. LINE
          RTI                    ;RETURN TO THE TIMING LOOP
    
```

 ; RELATIVE TIME BUILDING ROUTINE

```

BUILD:  MOV     #2,$TMP2         ;ROTATE 2 BITS BACK INTO $TMP1
1S:     ROR    $TMP3            ;GET THE BITS FROM $TMP3, THE HIGH BYTE
          ROR    $TMP1           ;OF THE RELATIVE TIME COUNTER. PUT THEM BACK
          DEC    $TMP2           ;INTO $TMP1 USING THE CARRY BIT WITH
          ROTATE INSTRUCTIONS
          BNE    1S              ;REDUCE COUNT. ALL BITS BACK? IF NOT, GET MORE
          RTS     PC             ;RETURN TO CALLING TEST
    
```


JOB

MD-11-DVDZB-A MACY11 30(1046) 28-JUL-77 07:37 PAGE 56
 DVDZBA.P11 28-JUL-77 07:37

DZV11 DEVICE DIAGNOSTICS. COPYRIGHT 1977 DIGITAL EQUIP. CORP.

SEQ 0074

Address	Data 1	Data 2	Code	Label
2673				
2674	015316	000000	0	;ERROR 0
2675	015320	000000	0	
2676	015322	000000	0	
2677				
2678	015324	015544	EM1	;ERROR
2679	015326	016670	DH1	
2680	015330	017070	DT1	
2681				
2682	015332	015617	EM2	;ERROR 2
2683	015334	016714	DH2	
2684	015336	017102	DT2	
2685				
2686	015340	015645	EM3	;ERROR 3
2687	015342	016747	DH3	
2688	015344	017120	DT3	
2689				
2690	015346	015704	EM4	;ERROR 4
2691	015350	016747	DH3	
2692	015352	017120	DT3	
2693				
2694	015354	015733	EM5	;ERROR 5
2695	015356	016761	DH4	
2696	015360	017126	DT4	
2697				
2698	015362	015762	EM6	;ERROR 6
2699	015364	016761	DH4	
2700	015366	017126	DT4	
2701				
2702	015370	000000	0	
2703	015372	000000	0	
2704	015374	000000	0	
2705				
2706	015376	000000	0	
2707	015400	000000	0	
2708	015402	000000	0	
2709				
2710	015404	016021	EM11	;ERROR 11
2711	015406	016747	DH3	
2712	015410	017120	DT3	
2713				
2714	015412	000000	0	
2715	015414	000000	0	
2716	015416	000000	0	
2717				
2718	015420	016057	EM13	;ERROR 13
2719	015422	016747	DH3	
2720	015424	017120	DT3	
2721				
2722	015426	016110	EM14	;ERROR 14
2723	015430	016747	DH3	
2724	015432	017120	DT3	
2725				
2726	015434	016142	EM15	;ERROR 15
2727	015436	000000	0	
2728	015440	000000	0	

K06

MD-11-DVDZB-A MACY11 30(1046) 28-JUL-77 07:37 PAGE 57
DVDZBA.P11 28-JUL-77 07:37

DZV11 DEVICE DIAGNOSTICS. COPYRIGHT 1977 DIGITAL EQUIP. CORP.

SEQ 0075

2729				
2730	015442	016204	EM16	
2731	015444	016747	DH3	
2732	015446	017120	DT3	
2733				
2734	015450	016256	EM17	;ERROR 17
2735	015452	016747	DH3	
2736	015454	017120	DT3	
2737				
2738	015456	016314	EM20	
2739	015460	016747	DH3	
2740	015462	017120	DT3	
2741				
2742	015464	016355	EM21	;ERROR 21
2743	015466	017010	DH5	
2744	015470	017144	DT5	
2745				
2746	015472	000000	0	
2747	015474	000000	0	
2748	015476	000000	0	
2749				
2750	015500	016405	EM23	;ERROR 23
2751	015502	016747	DH3	
2752	015504	017120	DT3	
2753				
2754	015506	016435	EM24	
2755	015510	016747	DH3	
2756	015512	017120	DT3	
2757				
2758	015514	016463	EM25	
2759	015516	016747	DH3	
2760	015520	017120	DT3	
2761				
2762	015522	016513	EM26	
2763	015524	016747	DH3	
2764	015526	017120	DT3	
2765				
2766	015530	016542	EM27	
2767	015532	016747	DH3	
2768	015534	017120	DT3	
2769				
2770	015536	016610	EM30	
2771	015540	016747	DH3	
2772	015542	017120	DT3	

2773
 2774

015544 047200 020117 052502
 015617 200 042522 044507
 015645 200 051124 047101
 015704 051200 041505 044505
 015733 200 040504 040524
 015762 042200 053132 030461
 016021 200 042522 042503
 016057 200 044523 047514
 016110 051600 046111 020117
 016142 040600 052103 047511
 016204 051200 040505 044504
 016256 042200 052101 020101
 016314 051200 041505 044505
 016355 200 042522 040514
 016405 200 040504 040524
 016435 200 040504 040524
 016463 200 051106 046501
 016513 200 040520 044522
 016542 051600 046111 020117
 016610 046200 047111 020105

 016670 052200 040522 020120
 016714 042600 050130 041505
 016747 200 044514 042516
 016761 200 054105 042520
 017010 052200 020130 044514

;ERROR MESSAGES
 EM1: .ASCIZ <200>/NO BUS REPLY RESPONSE FROM DZV11 REGISTER/
 EM2: .ASCIZ <200>/REGISTER R/W FAILURE/
 EM3: .ASCIZ <200>/TRANSMIT READY (TRDY) NOT SET/
 EM4: .ASCIZ <200>/RECEIVER DONE NOT SET/
 EM5: .ASCIZ <200>/DATA COMPARISON ERROR/
 EM6: .ASCIZ <200>/DZV11 #RECEIVER BUFFER# ERROR/
 EM11: .ASCIZ <200>/RECEIVER FAILED TO INTERRUPT/
 EM13: .ASCIZ <200>/SILO ALARM SET TOO SOON/
 EM14: .ASCIZ <200>/SILO ALARM FAILED TO SET/
 EM15: .ASCIZ <200>/ACTION DETECTED ON INVALID LINE./
 EM16: .ASCIZ <200>/READING DZV11BUF DID NOT CLEAR SILO ALARM/
 EM17: .ASCIZ <200>/DATA VALID SHOULD NOT BE SET/
 EM20: .ASCIZ <200>/RECEIVER DONE SHOULD NOT BE SET/
 EM21: .ASCIZ <200>/RELATIVE TIMING ERROR./
 EM23: .ASCIZ <200>/DATA VALID IS NOT SET!/
 EM24: .ASCIZ <200>/DATA OVERRUN IS SET!/
 EM25: .ASCIZ <200>/FRAMING ERROR OCCURRED/
 EM26: .ASCIZ <200>/PARITY ERROR OCCURRED/
 EM27: .ASCIZ <200>/SILO ALARM FAILED TO CAUSE INTERRUPT/
 EM30: .ASCIZ <200>/LINE DID NOT RECEIVE FULL BINARY COUNT PATTERN/

 DH1: .ASCIZ <200>/TRAP PC DZV11 REG/
 DH2: .ASCIZ <200>/EXPECTED FOUND REGISTER/
 DH3: .ASCIZ <200>/LINE NO./
 DH4: .ASCIZ <200>/EXPECTED FOUND LINE/
 DH5: .ASCIZ <200>/TX LINE PREVIOUS TIME ACTUAL TIME PARAMETER/

017070

.EVEN

;DATA TABLES FOR ERROR MESSAGES

2775
 2776
 2777
 2778
 2779
 2780
 2781
 2782
 2783
 2784
 2785
 2786
 2787
 2788
 2789
 2790
 2791
 2792
 2793
 2794
 2795
 2796
 2797
 2798
 2799
 2800

017070 000002
 017072 006 003
 017074 001330
 017076 006 001
 017100 001326

 017102 000003
 017104 006 004
 017106 001340
 017110 006 001
 017112 001336
 017114 006 001
 017116 001326

 017120 000001
 017122 003 001
 017124 001374

 017126 000003
 017130 006 004
 017132 001340
 017134 006 001
 017136 001336
 017140 003 001
 017142 001374

DT1: 2
 .BYTE 6,3
 \$REG1
 .BYTE 6,1
 \$REG0

 DT2: 3
 .BYTE 6,4
 \$REG5
 .BYTE 6,1
 \$REG4
 .BYTE 6,1
 \$REG0

 DT3: 1
 .BYTE 3,1
 SAVLIN

 DT4: 3
 .BYTE 6,4
 \$REG5
 .BYTE 6,1
 \$REG4
 .BYTE 3,1
 SAVLIN

```

2801 017144 000004
2802 017146 003 005
2803 017150 001374
2804 017152 006 011
2805 017154 001340
2806 017156 006 007
2807 017160 001344
2808 017162 006 001
2809 017164 001402

```

```

DTS: 4
      .BYTE 3,5
      SAVLIN
      .BYTE 6,9.
      $REG5
      .BYTE 6,7
      $TMP1
      .BYTE 6,1
      REGIST

```

TABLE OF DELAY TIMES FOR INDIVIDUAL BAUD RATES

```

2810
2811
2812
2813 017166 002450
2814 017170 001560
2815 017172 001120
2816 017174 000750
2817 017176 000660
2818 017200 000330
2819 017202 000150
2820 017204 000060
2821 017206 000040
2822 017210 000030
2823 017212 000020
2824 017214 000010
2825 017216 000001
2826 017220 000001
2827 017222 000001
2828 017224 000001
2829
2830
2831
2832
2833 017226 000001
2834

```

```

DLYTBL: 2450
         1560
         1120
         750
         660
         330
         150
         60
         40
         30
         20
         10
         1
         1
         1
         1

```

```

: TIME FOR 50 BAUD
: TIME FOR 75 BAUD
: TIME FOR 110 BAUD
: TIME FOR 134 BAUD
: TIME FOR 150 BAUD
: TIME FOR 300 BAUD
: TIME FOR 600 BAUD
: TIME FOR 1200 BAUD
: TIME FOR 1800 BAUD
: TIME FOR 2000 BAUD
: TIME FOR 2400 BAUD
: TIME FOR 3600 BAUD
: TIME FOR 4800 BAUD
: TIME FOR 7200 BAUD
: TIME FOR 9600 BAUD
: TIME OF DELAY FOR 19200 BAUD

```

DELAYS WERE COMPUTED TO ALLOW MAXIMUM TIME AT EACH BAUD RATE
FOR ALL TESTS TO FUNCTION CORRECTLY ON A LSI11.

```

CORMAX:
.END

```

ABASE = 160010	18	342	383						
ACM1 = 000017	18	342	385						
ACM2 = 000000	342	386							
ACPUOP = 000000	342	357							
ACTIVE = 001420	500#	756#	1789#	1790	1792*	1796	1797*	1798	1801*
ADD0 = 017470	18	342	387						
ADD1 = 017470	18	342	388						
ADD10 = 017470	18	342	397						
ADD11 = 017470	18	342	398						
ADD12 = 017470	18	342	399						
ADD13 = 017470	18	342	400						
ADD14 = 017470	18	342	401						
ADD15 = 017470	18	342	402						
ADD2 = 017470	18	342	389						
ADD3 = 017470	18	342	390						
ADD4 = 017470	18	342	391						
ADD5 = 017470	18	342	392						
ADD6 = 017470	18	342	393						
ADD7 = 017470	18	342	394						
ADD8 = 017470	18	342	395						
ADD9 = 017470	18	342	396						
ADEVCT = 000000	342	348							
ADEVN = 000001	18	342	384						
ADRNT = 005661	1323#	1360#	1370#						
ADVANC = 104400	652#	1500	2297	2557					
RENV = 000000	342	353							
RENVN = 000000	342	354							
AFATAL = 000000	342	345							
AMADR1 = 000000	342	370							
AMADR2 = 000000	342	374							
AMADR3 = 000000	342	377							
AMADR4 = 000000	342	380							
AMANS1 = 000000	342	364							
AMANS2 = 000000	342	372							
AMANS3 = 000000	342	375							
AMANS4 = 000000	342	378							
AMSGAD = 000000	342	350							
AMSGLC = 000000	342	351							
AMSGTY = 000000	342	344							
AMTYP1 = 000000	342	365							
AMTYP2 = 000000	342	373							
AMTYP3 = 000000	342	376							
AMTYP4 = 000000	342	379							
APASS = 000000	342	347							
APRIOR = 000000	342								
APTC SU = 000040	1174	1279#							
APTE NV = 000001	1167	1235	1277#	1587					
APTSIZ = 000200	1276#								
APTSPO = 000100	1169	1237	1278#						
ASWREG = 000000	342	355							
ATESTN = 000000	342	346							
AUNIT = 000000	342	349							
AUSMR = 000000	342	356							
AUTO.S = 011464	931	1971#							
AVECT1 = 000300	18	342	381						
AVECT2 = 000000	342	382							

SPASTM	001454	539#																			
SPWRAD	007376	1702#																			
SPWRDN	007236	311	753	1669#	1697																
SPWRMG	007372	1700#																			
SPWRUP	007310	1679	1685#																		
SOLES	001356	457#	892	1223	1307	1839															
SREG0	001324	443#																			
SREG0	001326	445#	1384#	1389	2779	2787															
SREG1	001330	446#	1383#	1390	2777																
SREG2	001332	447#	1382#	1391																	
SREG3	001334	448#	1381#	1392																	
SREG4	001336	449#	1380#	1393	2785	2797															
SREG5	001340	450#	1379#	1394	2783	2795	2805														
SRTM0	004246	1051#																			
SSAVR6	007406	1678#	1686	1687#	1688#	1706#															
SSCOPE	004300	1081#																			
SSETUP	000000	1033	1082																		
SSVLAD	004462	1098	1116#																		
SSVPC	000040	321#	326																		
SSMR	164000	1#	10	456	457	1011	1033	1044	1050	1052	1075	1076	1077	1078							
		1089	1101	1103	1104	1105	1106	1107	1119	1128	1703	2086	2202	2272							
		2418	2503																		
SSWREG	001142	355#	1959																		
SSWRNK	000000	1078																			
STESTN	001124	346#	1117#																		
STIMES	001354	456#	1033#	1106#	1112	1115#	1128	1784#	2426#												
STKB	001312	436#	1088	1294	1300	1615	1629														
STKS	001310	435#	1086	1292	1619	1627															
STMP0	001342	451#	2462#	2530#	2582	2605#	2658														
STMP1	001344	452#	826	837	838#	937#	962#	963#	1709	2463#	2475#	2624#	2662	2666							
		2807																			
STMP2	001346	453#	843#	848#	849#	938#	939	1711	2622#	2625#											
STMP3	001350	454#	2464#	2477#	2623#																
STMP4	001352	455#																			
STN	000006	10#	2084	2086#	2200	2202#	2270	2272#	2416	2418#	2501	2503#									
STPB	001316	438#	1212#	1223	1300#	1536#	1636#														
STPFLG	001323	442#	1161	1223																	
STPS	001314	437#	1210	1223	1298	1534	1633														
STSTM	001452	538#																			
STSTNM	001246	415#	760#	1074	1116#	1117	1119	1129	1614	1822	1830	2086#	2202#	2272#							
		2418#	2503#																		
STYPE	004606	1141	1161#	1254																	
STYPEC	005020	1191	1198	1205	1210#	1211															
STYPEX	005066	1216	1218	1221#																	
SUNIT	001132	349#																			
SUNITM	001456	540#																			
SUSMR	001144	356#																			
SVECT1	001170	381#	811#	1937	2066#																
SVECT2	001172	382#																			
SXTSTR	004340	1084	1092#																		
SY	000023	645#	652	654#	656#	658#	660#	662#	664#	666#	668#	670#	672#	674#							
		676#	678#	680#	682#	684#	686#	688#	690#												
SSGET4	000000	1044#																			
S4OCAT	***** U	1089																			
.	017226	304#	305	308#	321	322#	324#	326#	328#	331#	335#	337#	460	493#							
		494#	496#	498#	499#	525	526#	528#	530#	545#	548#	549#	550#	551#							

SSCHTH	3378	451	452	453	454	455
SSESCA	1548					
SSHEWT	1548	2084	2200	2270	2416	2501
SSSKIP	1548					
.EQUAT	18	44				
.HEADE	18					
.SETUP	18					
.SACT1	18	317				
.SAPT8	18	3398				
.SAPTH	18	520				
.SAPTY	18	1223				
.SCATC	18					
.SCHTA	3378					
.SEOP	18	1007				
.SERRO	18					
.SPOWE	18	1665				
.SSCOP	18	1069				
.STRAP	18					
.STYPE	18	1144				

. ABS. 017226 000

ERRORS DETECTED: 0

DVDZBA, DVDZBA.SEQ=DVDZBA.P11
 RUN-TIME: 19 11 1 SECONDS
 RUN-TIME RATIO: 119/32=3.6
 CORE USED: 34K (67 PAGES)

C08