

# CD11

CARD READER DIAGNOSTIC  
MD-11-DZCDA-C

EP-DZCDA-C-DL-A  
COPYRIGHT © 1976  
FICHE 1 OF 1

NOV 1976  
**digital**  
MADE IN USA

This microfiche card contains a grid of 60 frames of diagnostic data, arranged in 10 rows and 6 columns. Each frame displays a different set of test results, including binary strings, numerical values, and graphical representations of data patterns. The data is organized into columns, with some frames showing multiple columns of information. The frames are separated by thin white lines, and the overall layout is consistent across the entire grid.



1.0 ABSTRACT

THIS PROGRAM IS TO BE USED AS A CARD READER DIAGNOSTIC FOR THE PDP-11 WITH THE CD11 CARD READER INTERFACE TO THE DOCUMENTATION M1000 OR M1200 PUNCHED CARD READER. IT TESTS ALL LOGIC FUNCTIONS OF THE CARD READER, AND INCLUDES AN EXERCISER FOR ALPHANUMERIC AND BINARY TEST DECKS. SEPARATE STARTING ADDRESSES ALLOW THE ERROR SENSING FUNCTIONS OF THE DOCUMENTATION M 1000 AND M1200 READER TO BE CHECKED. ANOTHER STARTING ADDRESS TESTS SPECIAL DECKS WHICH HAVE ALL COLUMNS AND CARDS PUNCHED IDENTICALLY, TO AID IN DIAGNOSING SPECIAL PROBLEMS.

2.0 REQUIREMENTS

2.1 EQUIPMENT

PDP-11/ STANDARD COMPUTERS  
CD11 CARD READER

2.2 TEST DECKS

MAINDEC-89-D2A1-C ALPHANUMERIC TEST DECK  
MAINDEC-89-D2A2-C BINARY TEST DECK  
SPARE CARDS FOR THE ERROR FUNCTION TEST

2.3 STORAGE

THE ROUTINE USES MEMORY 0 TO 16100.

3.0 LOADING PROCEDURE

PROCEDURE FOR NORMAL ABSOLUTE TAPES SHOULD BE FOLLOWED.

4.0 STARTING PROCEDURE

4.1 CONTROL SWITCH SETTINGS

BASIC SWITCH REGISTER SETTINGS ARE:

- SW15=1 OR UP---HALT ON ERROR
- SW14=1 OR UP---SCOPE LOOP
- SW13=1 OR UP---INHIBIT PRINT OUT
- SW12=1 OR UP---INHIBIT TRACE TRAPPING

3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55  
56  
57  
58  
59  
60  
61  
62  
63  
64  
65  
66  
67  
68  
69  
70  
71  
72  
73  
74  
75  
76  
77  
78  
79  
80  
81  
82  
83  
84  
85  
86  
87  
88  
89  
90

001

MAINDEC-11-DZCDA-C-D  
DZCDAC.P11

CD11 CARD READER DIAGNOSTICS

MACY11 27(732) 15-OCT-76 16:01 PAGE 4

91  
92

SW11=1 OR UP---INHIBIT SUB-PROGRAM ITERATION  
SW07=1 OR UP---LOOP THRU THE INSTRUCTION TEST PORTION

93  
94  
95  
96  
97  
98  
99  
100  
101  
102  
103  
104  
105  
106  
107  
108  
109  
110  
111  
112  
113  
114  
115  
116  
117  
118  
119  
120  
121  
122  
123  
124  
125  
126  
127  
128  
129  
130  
131  
132  
133  
134  
135  
136  
137  
138  
139  
140  
141  
142  
143  
144  
145  
146  
147  
148

(NOTE THAT THE PROCESSOR MAY HANG  
LEGITIMATELY WHEN THE INPUT HOPPER GOES EMPTY  
IF SW7 IS SET)

SW06=1 OR UP---RETURN TO THE BEGINNING OF THE INSTRUCTION  
TEST WHEN CONTINUING FROM ONE DECK TO ANOTHER  
SW05=1 OR UP---HALT BETWEEN TEST DECKS  
(SEE 5.2.1 FOR EXPLANATION OF SW5=0)  
SW04=1 OR UP---RUN THE BINARY TEST DECK  
SW03=1 OR UP---RUN IN IMAGE MODE ONLY  
SW02=1 OR UP---RUN IN PACKING MODE ONLY

4.2 STARTING ADDRESSES

200 = INSTRUCTION AND DATA TEST  
210 = ERROR FUNCTION TEST (M1000)  
220 = SINGLE SUBTEST LOOP  
240 = READ SINGLE DATA PATTERN TEST  
250 = ERROR FUNCTION TEST (M1200)

4.3 PROGRAM AND/OR OPERATOR ACTION

4.3.1 INSTRUCTION AND DATA RELIABILITY TEST (SA 200)

LOAD PROGRAM INTO MEMORY.  
LOAD ONE TEST DECK IN THE CARD READER INPUT HOPPER.  
PRESS RESET ON THE CARD READER.  
SET SWITCH REGISTER TO STARTING ADDRESS.  
LOAD ADDRESS.  
SET SWITCHES (SEE 4.1)-ALL DOWN FOR WORST CASE, ALPHA TEST  
DECK.  
PRESS START.  
WHEN THE INPUT HOPPER IS EMPTY THE PROGRAM WILL HANG WAITING  
FOR AN INTERRUPT FROM THE CARD READER. LOAD ONE OR  
MORE TEST DECKS INTO THE INPUT HOPPER. PRESSING  
"RESET" ON THE CARD READER SHOULD CAUSE PROGRAM  
EXECUTION TO RESUME.  
THIS ENTIRE SEQUENCE IS NECESSARY TO RUN THE FULL TEST ON  
THE CARD READER.

4.3.2 ERROR FUNCTION TEST (SA 210 OR SA 250)

STARTING ADDRESS 210 FOR M1000 READER AND 250 FOR M1200  
READER.  
LOAD A FEW SPARE CARDS INTO THE INPUT HOPPER (DO NOT LOAD A  
TEST DECK-THIS IS DESTRUCTIVE!)  
PRESS "RESET" ON THE CARD READER.  
LOAD THE STARTING ADDRESS, THEN SET THE DESIRED SWITCH

**F01**

MAINDEC-11-DZCDA-C-D  
DZCDAC.P11

CD11 CARD READER DIAGNOSTICS

MACY11 27(732) 15-OCT-76 16:01 PAGE 6

149  
150

OPTIONS.  
PRESS START.

151  
152  
153  
154  
155  
156  
157  
158  
159  
160  
161  
162  
163  
164  
165  
166  
167  
168  
169  
170  
171  
172  
173  
174  
175  
176  
177  
178  
179  
180  
181  
182  
183  
184  
185  
186  
187  
188  
189  
190  
191  
192  
193  
194  
195  
196  
197  
198  
199  
200  
201  
202  
203  
204

FOLLOW THE INSTRUCTIONS AS THEY ARE PRINTED OUT.

#### 4.3.3 SINGLE SUBTEST LOOP (SA 220)

LOAD CARDS (SPARE CARDS OR A TEST DECK) INTO THE INPUT HOPPER.

PRESS "RESET" ON THE CARD READER.

LOAD THE STARTING ADDRESS.

PRESS START.

AT THE 1ST HALT: LOAD THE STARTING ADDRESS OF THE DESIRED TEST (ADDRESS OF THE SCOPE INSTRUCTION AT THE BEGINNING OF THE TEST.)

PRESS CONTINUE.

AT THE 2ND HALT SET THE SWITCH REGISTER OPTIONS (BIT 11 MUST=0).

PRESS CONTINUE.

#### 4.3.4 SINGLE DATA PATTERN TEST (SA 240)

A SPECIAL DECK (1 OR MORE CARDS) MUST BE PUNCHED TO RUN THIS TEST. ANY DATA PATTERN MAY BE USED, BUT IT MUST BE IDENTICAL IN ALL 80 COLUMNS OF ALL THE CARDS (I.E. ONLY ONE PIECE OF DATA).

LOAD THIS PREPARED DECK INTO THE INPUT HOPPER.

PRESS CARD READER "RESET".

LOAD SA 240.

PRESS START.

AT THE INITIAL HALT SET THE CARD IMAGE OF THE DATA PATTERN USED IN SW11-SW00.

PRESS CONTINUE.

ON THE SECOND HALT LOAD THE DESIRED SWITCH SETTINGS.

PRESS CONTINUE.

WHEN THE CARD READER RUNS OUT OF CARDS IT WILL RING THE BELL.

RELOADING THE DECK AND PRESSING "RESET" ON THE CARD READER WILL CONTINUE THE TEST.

### 5.0 OPERATING PROCEDURE

#### 5.1 OPERATIONAL SWITCH SETTINGS

##### 5.1.1 AT SA 200 (INSTRUCTION AND DATA RELIABILITY TEST)

SEE 4.1

205  
206  
207  
208  
209  
210  
211  
212  
213  
214  
215  
216  
217  
218  
219  
220  
221  
222  
223  
224  
225  
226  
227  
228  
229  
230  
231  
232  
233  
234  
235  
236  
237  
238  
239  
240  
241  
242  
243  
244  
245  
246  
247  
248  
249  
250  
251  
252  
253  
254  
255  
256  
257  
258  
259  
260

5.1.2 AT SA 210 OR SA 250 (ERROR FUNCTION TEST FOR CD11)

SW14=1 TO LOOP THRU THE CURRENT SUBTEST  
SW15=1 TO HALT ON ERROR

5.1.3 AT SA 220 (SINGLE SUBTEST LOOP)

1ST HALT - LOAD STARTING ADDRESS OF DESIRED TEST  
2ND HALT - SET SR OPTIONS (BIT 11 MUST=0)  
SEE 4.1 FOR SR OPTIONS

5.1.4 AT SA 240 (SINGLE DATA PATTERN TEST)

1ST HALT-LOAD THE CARD-IMAGE OF THE DATA PATTERN IN  
SW11-SW00.  
2ND HALT-SET SR OPTIONS.

SW15=1 TO HALT ON ERROR  
SW03=1 TO TEST IMAGE MODE ONLY  
SW02=1 TO TEST PACKING MODE ONLY

5.2 SUBROUTINE ABSTRACTS

5.2.1 BEGIN (SA 200)

THE INSTRUCTION TESTS ARE RUN FIRST, FOLLOWED BY THE DATA RELIABILITY TESTS ON THE REMAINING CARDS IN THE FIRST TEST DECK. AT THE END OF THE DECK THE BELL WILL RING, AND IF SW5=1 THE PROGRAM HALTS. IF SW5=0, PROGRAM ACTION DEPENDS ON THE NUMBER OF TEST DECKS LOADED. IF THERE ARE STILL CARDS IN THE INPUT HOPPER, THE PROGRAM WILL RUN THE DATA RELIABILITY TEST ON THE ENTIRE DECK. IF THE INPUT HOPPER IS EMPTY AT THE END OF A DECK, THE PROGRAM WILL RUN A SET OF TESTS OF OFF-LINE OPERATIONS. AT THE END OF THESE TESTS, IT WAITS FOR THE CARD READER TO BE PUT BACK ON-LINE. FURTHER CHECKS ARE MADE OF THE OFF-LINE TO ON-LINE OPERATIONS, AND THEN THE DATA RELIABILITY TEST IS RUN ON THE ENTIRE DECK. IF SW5=1, HITTING CONTINUE WILL RESUME PROGRAM OPERATION AFTER THE HALT. IF ALL OTHER SWITCHES WERE DOWN, FOR EXAMPLE, THE DATA RELIABILITY TEST WOULD THEN BE RUN ON THE NEXT DECK. THE OTHER SWITCHES AFFECT PROGRAM FLOW AS NOTED IN 4.1.

5.2.2 SCOPE

THIS SUBROUTINE CALL IS PLACED BETWEEN EACH SUBTEST IN THE



261  
262

INSTRUCTION SECTION. IT RECORDS THE STARTING ADDRESS OF  
EACH SUB-TEST AS IT IS BEING ENTERED. IF A SCOPE LOOP IS

263  
264  
265  
266  
267  
268  
269  
270  
271  
272  
273  
274  
275  
276  
277  
278  
279  
280  
281  
282  
283  
284  
285  
286  
287  
288  
289  
290  
291  
292  
293  
294  
295  
296  
297  
298  
299  
300  
301  
302  
303  
304  
305  
306  
307  
308  
309  
310  
311  
312  
313  
314  
315  
316  
317

REQUESTED, IT WILL JUMP TO THE START OF THE SUBTEST THAT THE SCOPE LOOP IS REQUESTED FOR. IF SCOPE LOOP IS NOT REQUESTED, THERE WILL BE 1 ITERATION ON THAT SUBTEST BEFORE THE NEXT SUBTEST IS ENTERED. SWITCH 11 ON A 1 INHIBITS ITERATION OF SUBTESTS.

5.2.3 HLT

THIS SUBROUTINE PRINTS OUT THE LOCATION COUNTER AT THE TIME OF FAILURE. THE CONTENTS OF THE PROCESSOR STATUS REGISTER, AND THE CONTENTS OF THE CARD READER STATUS REGISTER. NOTE THAT THE LOCATION COUNTER WILL BE THE ADDRESS OF THE HLT PLUS TWO.

5.2.4 TTRAP

THIS ROUTINE ALLOWS THE TRACE BIT TO BE SET AFTER THE FIRST LOOP OF THE PROGRAM. THE TRACE BIT WILL BE SET ON ALTERNATE LOOPS OF THE INSTRUCTION AND DATA TEST UNLESS SW12 IS SET. THE FIRST INSTRUCTION EXECUTED UPON TRAPPING IS AN "RTI" WHICH RETURNS TO THE INTERRUPTED SEQUENCE. THIS CONTINUES UNTIL THE END OF THE PROGRAM LOOP IS REACHED.

5.2.5 TRAPCATCHER

THIS IS A SERIES OF INSTRUCTIONS STARTING AT LOCATION 0 DESIGNED TO DETECT AND ISOLATE UNEXPECTED TRAPS AND INTERRUPTS TO THE TRAP AND INTERRUPT VECTOR AREA OF MEMORY.

EACH VECTOR ENTRANCE ADDRESS IS LOADED WITH THE ADDRESS OF THE NEXT LOCATION. THE NEXT LOCATION IS LOADED WITH A HALT (00000). THUS AN ILLEGAL TRAP OR INTERRUPT WILL CAUSE A HALT AT THE TRAP LOCATION PLUS TWO.

IF A HALT OCCURS IN THE TRAP OR INTERRUPT AREA, EXAMINE REGISTER SIX. IT WILL CONTAIN THE CURRENT STACK ADDRESS. THE CONTENTS OF THE CURRENT STACK ADDRESS IS THE VALUE OF THE LOCATION COUNTER WHEN THE TRAP OR INTERRUPT OCCURRED.

5.2.6 ERCD11 (ERROR FUNCTION TEST)

THE FIRST SUBTEST OF THE ERROR FUNCTION TEST (TESTA) CHECKS THE DATA LATE ERROR. THE REST OF THE SUBTESTS CHECK THE OPERATION OF THE VARIOUS ERROR SENSING FEATURES OF THE DOCUMENTATION M1000 AND M1200 CARD READER. CARD READER OFF-LINE, INPUT HOPPER EMPTY, OUTPUT STACKER FULL, PICK ERROR, STACK ERROR, AND READ ERROR ARE CHECKED.

318  
319  
320  
321  
322  
323  
324  
325  
326  
327  
328  
329  
330  
331  
332  
333  
334  
335  
336  
337  
338  
339  
340  
341  
342  
343  
344  
345  
346  
347  
348  
349  
350  
351  
352  
353  
354  
355  
356  
357  
358  
359  
360  
361  
362  
363  
364  
365  
366  
367  
368  
369  
370  
371  
372  
373

## 5.2.7 TESTX (SINGLE TEST LOOP)

THIS ROUTINE ALLOWS A SINGLE SUBTEST TO BE RUN CONTINUOUSLY FOR SCOPE LOOP PURPOSES. WHILE A SCOPE LOOP SWITCH OPTIONS EXISTS, IT REQUIRES THAT YOU ARE WITHIN THE TEST IN WHICH YOU WISH TO LOOP. IN SOME CASES (SUCH AS WITH INTERMITTENT FAILURES) THAT'S NOT EASY TO DO. THIS SUBROUTINE ALLOWS YOU TO LOAD THE ADDRESS OF ANY TEST FROM TEST1 THRU TEST22 AND TESTA THRU TESTH AT THE HALT AND THEN GO DIRECTLY TO THAT TEST.

## 5.2.8 CKSAME (SINGLE DATA PATTERN TEST)

THIS TEST IS DESIGNED TO AID IN THE DIAGNOSIS OF DIFFICULT DATA ERROR PROBLEMS AND FACILITATE SOME CARD READER ADJUSTMENTS. IT CONTINUOUSLY READS CARDS WHICH HAVE ALL COLUMNS PUNCHED IDENTICALLY (AND ALL CARDS MUST BE IDENTICAL), CHECKING THE DATA AGAINST A PATTERN SET UP ON THE SWITCHES INITIALLY. ANY ERRORS ARE PRINTED OUT, ALONG WITH A COUNT OF THE TOTAL NUMBER OF CARDS READ AND THE TOTAL NUMBER OF DATA ERRORS WHICH HAVE OCCURRED SINCE THE TEST WAS STARTED.

## 5.3 PROGRAM AND/OR OPERATOR ACTION

## 5.3.1

LOADING AND STARTING AT 200 WITH ALL SWITCHES DOWN IS WORST CASE TESTING. A SINGLE ALPHANUMERIC DECK SHOULD BE RUN. THIS EXECUTES AN INSTRUCTION TEST FOLLOWED BY A DATA RELIABILITY TEST. AT THE END OF THE DECK CHECKS ARE MADE OF THE FLAG SETTINGS WHICH SHOULD BE AFFECTED, AND THE PROGRAM WAITS FOR AN INTERRUPT FROM THE READER COMING BACK ON-LINE. AT THE END OF THE FIRST DECK THE OPERATOR SHOULD LOAD ONE OR MORE DECKS IN THE INPUT HOPPER AND PRESS "RESET" ON THE CARD READER. IF THE CARD READER IS WORKING PROPERLY, THE ENTIRE DECK WILL BE RUN THRU THE DATA RELIABILITY PORTION OF THE TEST. IF, AFTER READING 80 CARDS, THE INPUT HOPPER IS NOT EMPTY, THE PROGRAM WILL CONTINUE TO THE NEXT DECK. SWITCH OPTIONS MAY BE USED TO ALTER THIS FLOW AS NOTED IN SECTION 4.1.

## 5.3.2

TO GO DIRECTLY TO A SINGLE SUBTEST AND RUN IT CONTINUOUSLY, USE SA 220. AT THE FIRST HALT, SET THE SWITCH REGISTER TO THE STARTING ADDRESS OF THE DESIRED SUBTEST (I.E. THE ADDRESS OF THE SCOPE INSTRUCTION AT THE START OF THE TEST), AND CONTINUE. AT THE SECOND HALT, SET THE DESIRED SWITCH REGISTER OPTIONS AND CONTINUE (SW11 MUST BE = 0). THE PROGRAM WILL CONTINUOUSLY LOOP THRU THE DESIRED SUBTEST

**L01**

MAINDEC-11-DZCDA-C-D  
DZCDAC.P11

CD11 CARD READER DIAGNOSTICS

MACY11 27(732) 15-OCT-76 16:01 PAGE 12

374

UNTIL SW11 IS SET OR THE PROCESSOR IS HALTED.

375  
376  
377  
378  
379  
380  
381  
382  
383  
384  
385  
386  
387  
388  
389  
390  
391  
392  
393  
394  
395  
396  
397  
398  
399  
400  
401  
402  
403  
404  
405  
406  
407  
408  
409  
410  
411  
412  
413  
414  
415  
416  
417  
418  
419  
420  
421  
422  
423  
424  
425  
426  
427  
428

6.0 ERRORS

6.1 ERROR PRINTOUT

6.1.1 STANDARD PRINTOUT

PRINTOUTS ARE IN A THREE-WORD FORMAT. THE FIRST IS THE PC+2 OF THE DETECTED ERROR. THE SECOND IS THE CONTENTS OF THE PROCESSOR STATUS REGISTER WHEN THE ERROR WAS DETECTED. THE THIRD IS THE CARD READER STATUS REGISTER.

6.1.2 DATA ERROR PRINTOUT

THE HEADING IS PRINTED OUT ONCE PER TEST DECK. THE COLUMNS HAVE THE FOLLOWING SIGNIFICANCE:

- DECK =EITHER ALPHANUMERIC OR BINARY, DEPENDING ON SWITCH 4
- CARD =THE CARD NUMBER WHERE THE FAILURE OCCURRED (IN OCTAL)
- COLUMN =THE COLUMN NUMBER WHERE THE FAILURE OCCURED (IN OCTAL)
- PATTERN =THE CORRECT CARD DATA THAT SHOULD HAVE BEEN READ READ =WHAT WAS ACTUALLY READ INTO CORE

DATA ERRORS NOT TRACED TO CARD READER HARDWARE INCLUDE:

- A. SW04 NOT SET TO TYPE OF DECK USED
- B. CARD MISSING
- C. CARD DECK OUT OF PROPER SEQUENCE
- D. DAMAGED CARD

6.1.3 SINGLE DATA PATTERN PRINTOUT

THE SINGLE DATA PATTERN TEST PRINTS OUT A HEADING ONCE. THE COLUMNS HAVE THE FOLLOWING SIGNIFICANCE:

- COLUMN =THE COLUMN NUMBER WHERE THE FAILURE OCCURRED.
- READ =DATA THAT WAS ACTUALLY READ INTO CORE
- CARDS =THE TOTAL NUMBER OF CARDS (IN OCTAL) THAT HAVE BEEN RUN SINCE THE TEST WAS STARTED.
- ERRORS =THE TOTAL NUMBER OF ERRORS DETECTED (IN OCTAL) SINCE THE TEST WAS STARTED.

429  
430  
431  
432  
433  
434  
435  
436  
437  
438  
439  
440  
441  
442  
443  
444  
445  
446  
447  
448  
449  
450  
451  
452  
453  
454  
455  
456  
457  
458  
459  
460  
461  
462  
463  
464  
465  
466  
467  
468  
469  
470  
471  
472  
473  
474  
475  
476  
477  
478  
479  
480  
481  
482  
483

## 6.2 ERROR RECOVERY

IN GENERAL, TEST FAILURES WILL PRINTOUT AN ERROR MESSAGE AND CONTINUE. IF THE "HALT ON ERROR" SWITCH IS SET, HITTING CONTINUE WILL RECOVER. IF THE PROGRAM HANGS UP IN A LOOP, THE ERROR IS LIKELY TO BE A SIGNAL WHICH WAS NEVER RECEIVED. IF A HALT OCCURS IN THE TRAP AND VECTOR AREA THE PROGRAM MUST BE RESTARTED. IF THE PROGRAM HALTS IN THE MAIN FLOW, CONSULT THE LISTING IF NO MESSAGE IS TYPED OUT.

## 7.0 RESTRICTIONS

## 7.1 STARTING PROCEDURE

NONE

## 7.2 OPERATIONAL RESTRICTIONS

## 7.2.1 COMBINED INSTRUCTION AND DATA RELIABILITY TEST (SA200)

IF A STANDARD TEST DECK IS NOT BEING USED, SW7 MUST BE SET TO INHIBIT RUNNING THE DATA RELIABILITY PORTION OF THE TEST. THE PROCESSOR MAY HANG WHEN THE INPUT HOPPER GOES EMPTY, AND THIS IS NOT TO BE REGARDED AS A FAILURE.

WHEN USING THE STANDARD TEST DECKS, THEY MUST BE IN PROPER SEQUENCE AND IN GOOD CONDITION. IT IS A GOOD IDEA TO NUMBER THE CARDS IN EACH DECK AS SOON AS THE DECK IS RECEIVED.

## 7.2.2 ERROR FUNCTION TEST (SA 210 OR SA 250)

THE ERROR FUNCTION TEST REQUIRES SPARE CARDS, AS IT BENDS SEVERAL. ALSO, TO RUN THE DARK-LIGHT CHECK, A CARD MUST BE SPECIALLY PREPARED. THE TEST WILL TYPE OUT A REQUEST FOR THAT CARD WHEN IT IS NEEDED. TO MAKE IT, TEAR ONE CORNER OFF ONE CARD.

## 7.2.3 SINGLE DATA PATTERN TEST (SA 240)

A SPECIAL DECK (ONE OR MORE CARDS) MUST BE PREPARED. ALL COLUMNS OF ALL CARDS ARE PUNCHED IDENTICALLY, USING A DATA PATTERN WHICH WILL TEST THE PROBLEM BEING DIAGNOSED.



%

.TITLE MAINDEC-11-DZCDA-C-D CD11 CARD READER DIAGNOSTICS  
 :DIAGNOSTIC FOR THE CD11 CARD READER  
 :COPYRIGHT 1973 BY DIGITAL EQUIPMENT CORP., MAYNARD, MASS. 01754  
 :PROGRAMMER: KEN CHAPMAN  
 : SUB MALLICK (CHANGED FROM REV A TO REV B )

## :STARTING ADDRESSES ARE:

200=INSTRUCTION AND DATA TEST FOR THE CD11  
 210=ERROR FUNCTION TEST OF CD11 (M-1000)  
 220=SINGLE TEST LOOP  
 240=READ SINGLE DATA PATTERN TEST  
 250=ERROR FUNCTION TEST FOR CD11 (M-1200)

## :SWITCH REGISTER SETTINGS FOR THE INSTRUCTION AND DATA TEST ARE:

SW02=1 RUN IN DATA IMAGE MODE ONLY  
 SW03=1 RUN IN DATA PACKING MODE ONLY (IGNORED IF SW02=1)  
 SW04=1 FOR THE BINARY TEST DECK  
 SW05=1 TO HALT AT THE END OF A STANDARD 80 CARD  
 TEST DECK. (HITTING CONTINUE WILL START TESTING  
 OF THE NEXT DECK IN ACCORDANCE WITH CURRENT  
 SWR SETTINGS).  
 =0 TO CONTINUE FROM ONE DECK TO THE NEXT.  
 AFTER THE LAST DECK IN THE HOPPER IS  
 RUN, THE PROGRAM WAITS FOR THE CARD READER  
 TO COME BACK ON-LINE, AND RUNS THRU  
 A SERIES OF CHECKS OF OFF-LINE AND  
 COMING ON-LINE OPERATIONS OF THE READER.  
 WHEN THE READER IS BACK ON-LINE AND THE  
 CHECKS ARE COMPLETE, THE DATA TEST IS RESUMED.  
 SW06=1 TO RUN THE COMBINED INSTRUCTION AND DATA TEST  
 WHEN CONTINUING FROM ONE DECK TO THE NEXT  
 =0 TO RUN ONLY THE DATA TEST ON EVERY DECK AFTER THE FIRST  
 SW07=1 TO RUN ONLY THE INSTRUCTION TEST CONTINUALLY.  
 SETTING SW06 AND SW07 AT THE END OF A DECK WILL  
 CAUSE THE INSTRUCTION TEST TO BE RUN CONTINUOUSLY FROM THEN ON  
 (NOTE THAT IF SW7 IS SET, THE PROGRAM MAY HANG WHEN THE  
 CARD READER RUNS OUT OF CARDS)  
 SW11=1 TO INHIBIT SUBPROGRAM ITERATION  
 (NOTE THAT IF PROGRAM FLOW IS ALLOWED TO ENTER THE  
 DATA SUBTEST WHEN SW11 IS SET, DATA ERRORS WILL  
 OCCUR SINCE THE CARD COUNT WILL BE INCORRECT.)  
 SW12=1 TO INHIBIT TRACE TRAPPING  
 SW13=1 TO INHIBIT PRINTOUT  
 SW14=1 FOR SCOPE LOOP  
 SW15=1 TO HALT ON ERROR

## :OPERATING PROCEDURE FOR THE INSTRUCTION AND DATA TEST:

1. LOAD TEST DECK IN CARD READER AND PRESS "START" ON THE CARD READER. IF THE DECK BEING USED IS NOT A STANDARD TEST DECK, ONLY THE INSTRUCTION PORTION OF THE TEST CAN BE RUN. (SW7 MUST BE SET TO ONE TO INDICATE THIS).
2. LOAD SA 200, THEN SET THE SWITCH REGISTER SWITCHES TO THE DESIRED COMBINATION

531  
532  
533  
534  
535  
536  
537  
538  
539  
540  
541  
542  
543  
544  
545  
546  
547  
548  
549  
550  
551  
552  
553  
554  
555  
556  
557  
558  
559  
560  
561  
562  
563  
564  
565  
566  
567  
568  
569  
570  
571  
572  
573  
574  
575  
576  
577  
578  
579  
580  
581  
582  
583  
584  
585  
586



587  
588  
589  
590  
591  
592  
593  
594  
595  
596  
597  
598  
599  
600  
601  
602  
603  
604  
605  
606  
607  
608  
609  
610  
611  
612  
613  
614  
615  
616  
617  
618  
619  
620  
621  
622  
623  
624  
625  
626  
627  
628  
629  
630  
631

3. PRESS "START" ON THE CONSOLE
4. NOTE THAT RUNNING THE COMPLETE INSTRUCTION TEST REQUIRES THAT THE INPUT HOPPER MUST RUN OUT OF CARDS AT THE END OF A TEST DECK AT LEAST ONCE. WHEN THIS OCCURS, THE PROCESSOR SHOULD CONTINUE TO RUN. LOADING A DECK INTO THE INPUT HOPPER AND PRESSING "START" ON THE CARD READER SHOULD CAUSE THE BELL TO RING AND THE CARD READER TO RESUME READING CARDS. IF THIS DOES NOT OCCUR, IT IS A FAULT AND SHOULD BE FIXED.

: SPECIAL SWITCH REGISTER SETTINGS FOR THE ERROR FUNCTION TEST:  
 : SW14=1 TO LOOP THRU THE CURRENT SUBTEST  
 : SW15=1 TO HALT ON ERROR

: OPERATING PROCEDURE FOR THE ERROR FUNCTION TEST:  
 : 1. LOAD A FEW SPARE CARDS INTO THE INPUT HOPPER.  
 : 2. PRESS "START" ON THE CARD READER.  
 : 3. LOAD THE SA, THEN SET THE DESIRED SWITCH OPTIONS.  
 : 4. PRESS "START" ON THE CONSOLE.  
 : 5. FOLLOW THE INSTRUCTIONS AS THEY ARE PRINTED OUT.

: SINGLE TEST LOOP (SA 220) HALTS TWICE!  
 : 1ST HALT - LOAD STARTING ADDRESS OF DESIRED TEST (TEST1 TO TEST 24)  
 : 2ND HALT - SET SWR OPTIONS (BIT 11 MUST = 0)  
 : THIS TEST USES TRACE TRAPPING WHERE APPLICABLE IF SW12 IS NOT SET

: DESCRIPTION OF SINGLE DATA PATTERN TEST  
 : THIS TEST IS DESIGNED TO AID IN THE LOCATION OF DIFFICULT DATA ERROR PROBLEMS AND PERHAPS HELP IN SOME CARD READER ADJUSTMENTS. IT CONTINUOUSLY READS CARDS WHICH HAVE ALL COLUMNS PUNCHED OR MARKED IDENTICALLY, CHECKING THE DATA AGAINST A PATTERN SET UP ON THE SWITCHES INITIALLY. ANY ERRORS ARE PRINTED OUT, ALONG WITH A COUNT OF THE TOTAL NUMBER OF CARDS READ AND THE TOTAL NUMBER OF DATA ERRORS WHICH HAVE OCCURRED SINCE THE TEST WAS STARTED.

: OPERATING PROCEDURE FOR SINGLE DATA PATTERN TEST:  
 : 1. LOAD TEST DECK OF IDENTICAL CARDS IN THE INPUT HOPPER, AND PUT THE CARD READER ON-LINE.  
 : 2. LOAD SA 240, THEN PRESS "START" ON THE CONSOLE.  
 : 3. AT THE INITIAL HALT SET THE CORRECT CARD-IMAGE DATA PATTERN IN SW11-SW00, THEN PRESS CONTINUE.  
 : 4. WHEN THE READER RUNS OUT OF CARDS IT WILL RING THE BELL. RELOADING THE DECK AND PRESSING "START" ON THE CARD READER WILL CONTINUE THE TEST.

632  
633  
634  
635  
636  
637  
638  
639  
640  
641  
642  
643  
644  
645  
646  
647  
648  
649  
650  
651  
652  
653  
654  
655  
656  
657  
658  
659  
660  
661  
662  
663  
664  
665  
666  
667  
668  
669  
670  
671  
672  
673  
674  
675  
676  
677  
678  
679  
680  
681  
682  
683  
684  
685  
686  
687

177570  
177776  
000240  
104000  
104400  
000004  
000000  
000000  
000001  
000002  
000003  
000004  
000005  
000005  
000006  
000007  
  
000000  
  
000014  
000016  
000020  
000022  
000024  
000026  
000030  
000032  
000034  
000036

:STATUS AND CONTROL REGISTER (CDST) BIT DESIGNATION  
:BIT 0 READ  
:BIT 1 DATA PACKING  
:BIT 2 BUSY  
:BIT 3 READER TRANSITION TO ON LINE  
:BIT 4 ADDRESS BIT 16  
:BIT 5 ADDRESS BIT 17  
:BIT 6 INTERRUPT ENABLE  
:BIT 7 CONTROLLER READY  
:BIT 8 POWER CLEAR  
:BIT 9 NON-EXISTENT MEMORY  
:BIT 10 DATA LATE  
:BIT 11 DATA ERROR  
:BIT 12 OFF LINE  
:BIT 13 END OF FILE (M1200 ONLY)  
:BIT 14 CARD READER ERROR  
:BIT 15 ERROR

SWR= 177570  
PS= 177776  
NOP= 240  
HLT= EMT  
SCOPE= TRAP  
TYPE= IOT  
DUMMY= 0  
RO= %0  
R1= %1  
ADINT= %2  
CDS= %3  
CDC= %4  
CDA= %5  
TTY= %5  
SP= %6  
PC= %7

:SCRATCH  
:SCRATCH  
:CONTAINS ADDRESS OF INTERRUPT VECTOR  
:CONTAINS ADDRESS OF CARD READER STATUS REGISTER  
:CONTAINS ADDRESS OF CARD READER COLUMN COUNT  
:CONTAINS ADDRESS OF CARD READER BUS ADDRESS REG.

:STACK POINTER  
:PROGRAM COUNTER

.ABS  
.=0 ;TRAP CATCHER IS LOADED INTO LOCATIONS 0 THRU 377

:LOAD TRAP VECTORS FOR HLT AND SCOPE ROUTINES

.=14 TRTRAP  
340  
  
.=20 \$TYPE  
340  
  
.=24 POWR  
340  
  
.=30 PRINT  
340  
  
.=34 SCOPEC  
340

```

688 ;LOAD STARTING ADDRESS AREA
689 . =200
690 000200 012706 000500 MOV #STACK, SP
691 000204 000167 000570 JMP BEGIN ;NORMAL STARTING ADDRESS FOR CD11 READER
692 . =210
693 000210 012706 000500 MOV #STACK, SP
694 000214 000167 006322 JMP ERCD11 ;STARTING ADDRESS FOR CD11 (M1000) ERROR FUNCTION TEST
695 . =220
696 000220 012706 000500 MOV #STACK, SP
697 000224 000167 011016 JMP TESTX ;STARTING ADDRESS FOR LOOP WHICH CONTINUALLY RUNS
698 ;ANY SINGLE SUBTEST
699 . =240
700 000240 012706 000500 MOV #STACK, SP
701 000244 000167 011106 JMP CKSAME ;STARTING ADDRESS OF TEST TO READ A SINGLE DATA
702 ;PATTERN CONTINUOUSLY
703
704
705 . =250
706 000250 012706 000500 MOV #STACK, SP
707 000254 000167 006252 JMP ER1200 ;STARTING ADDRESS FOR M-1200 ERROR FUNCTION TEST
708
709
710
711 ;LOAD POINTERS AND GENERAL STORAGE
712 . =500
713 000500 000000 STACK: 0 ;STACK POINTER INITIALIZED TO POINT HERE
714 000502 177160 CDST: 177160 ;ADDRESS OF CARD READER STATUS REGISTER
715 000504 177162 CDCC: 177162 ;ADDRESS OF CARD READER COLUMN COUNT
716 000506 177164 CDBA: 177164 ;ADDRESS OF CARD READER BUS ADDRESS
717 000510 177564 TPS: 177564 ;ADDRESS OF TELETYPE STATUS REGISTER
718 000512 177566 TPB: 177566 ;ADDRESS OF TELETYPE DATA BUFFER
719 000514 000002 TRTRAP: RTI ;RETURN FROM TRACE LOOP
720 000516 000230 INTVC: 230 ;ADDRESS OF CARD READER INTERRUPT VECTOR
721 000520 000232 232
722 000522 000000 COUNT: 0 ;USED FOR TIMING, ETC.
723 000524 000000 INTFLG: 0 ;CONTAINS LEVEL THAT INTERRUPT IS FOUND AT
724 000526 000000 TRFLG: 0 ;TOGGLED TO SWITCH BETWEEN TRACE TRAPPING AND NORMAL FLO
725 000530 000000 PROC: 0 ;STORES PROCESSOR STATUS WHEN TRACE TRAP MUST BE CLEARED
726 ;IN A SUBTEST
727 000532 000000 ERFLG: 0 ;SET TO ZERO TO OUTPUT DATA ERROR HEADING
728 000534 000000 CKRF: 0 ;FLAG FOR CHECKERBOARD DECK
729 000536 000000 COUNTG: 0 ;USED AS COUNTER IN TESTG
730 000540 000000 CD1000: 0 ;M-1200 OR M-1000 CARD READER DETECTOR
731
732 ;INITIALIZE CSR AND DBR POINTERS
733 000542 012767 000001 011660 SETUP: MOV #1, ITMAX ;SET ITERATION MAXIMUM TO 1 ITERATION
734 000550 016703 177726 MOV CDST, CDS ;SET UP STATUS REGISTER POINTER
735 000554 016704 177724 MOV CDCC, CDC ;SET UP COLUMN COUNT REGISTER POINTER
736 000560 016705 177722 MOV CDBA, CDA ;SET UP BUS ADDRESS REGISTER POINTER
737 000564 016702 177726 MOV INTVC, ADINT ;LOAD ADDRESS OF INTERRUPT VECTOR
738 000570 016712 177724 MOV INTVC+2, (ADINT) ;SET UP CD11 TRAP VECTOR
739 000574 005077 177720 CLR @INTVC+2 ; TO HALT
740 000600 005067 177720 CLR INTFLG ;INITIALIZE INTERRUPT FLAG
741 000604 005067 177716 CLR TRFLG ;INITIALIZE TRACE FLAG
742 000610 012767 000340 177160 MOV #340, PS ;SETUP PROCESSOR STATUS
743 000616 000207 RTS %7 ;RETURN

```

```

744
745      001000      . = 1000
746
747
748
749
750 001000 012767 001000 011426 BEGIN: MOV #BEGIN, RETURN ;SAVE RETURN FOR POWER FAIL
751 001006 004767 177530 JSR %7, SETUP ;INITIALIZE POINTERS AND FLAGS
752 001012 000416 BR TEST ;GO TO INSTRUCTION TESTS
753 001014 005767 177506 RESTRT: TST TRFLG ;CHECK FOR TRACE TRAPPING
754 001020 001004 BNE TRAPX ;IF SET, TRACE TRAP
755 001022 012767 000340 176746 NOTRP: MOV #340, PS ;IF ZERO, CLEAR TRACE BIT
756 001030 000407 BR TEST ;GO TO INSTRUCTION TESTS
757 001032 032767 010000 176530 TRAPX: BIT #10000, SWR ;CHECK SW12
758 001040 001370 BNE NOTRP ;BRANCH IF SET TO CLEAR TRACE BIT
759 001042 012767 000360 176726 MOV #360, PS ;SET TRACE BIT
760
761 ;TEST FOR CORRECT INITIALIZATION OF ALL CARD READER REGISTERS
762 001050 012767 001060 011356 TEST: MOV #TEST1A, RETURN ;SETUP SCOPE LOOP RETURN ADDRESS
763 001056 104400 TEST1: SCOPE ;SO ALL TESTS START WITH SCOPE
764 001060 004767 011114 TEST1A: JSR %7, CKOFFL ;CHECK FOR OFF-LINE SET
765 001064 000005 RESET ;SEND OUT INIT
766 001066 022713 000200 CMP #200, %CDS ;CHECK FOR STATUS REGISTER BIT 7 SET
767 001072 001401 BEQ .+4 ;BRANCH IF OK
768 001074 104000 HLT ;STATUS REGISTER NOT CORRECTLY INITIALIZED
769
770 001076 005714 TST %CDC ;CHECK FOR COLUMN COUNT CLEARED
771 001100 001401 BEQ .+4 ;BR IF OK
772 001102 104000 HLT ;COLUMN COUNT NOT CLEARED BY INIT
773
774 001104 005715 TST %CDA ;CHECK FOR BUS ADDRESS CLEARED
775 001106 001401 BEQ .+4 ;BR IF OK
776 001110 104000 HLT ;BUS ADDRESS NOT CLEARED BY INIT
777
778 001112 104400 TEST2: SCOPE
779 ;TEST THAT ONLY THE PROPER BITS OF THE STATUS REGISTER ARE READ/WRITE
780 ;ONLY BITS 1, 4, 5, AND 6 OF THE STATUS REGISTER SHOULD BE
781 ;ABLE TO BE SET TO ONE AND READ BACK AS ONE
782 001114 052713 177376 BIS #177376, %CDS ;SET ALL BITS BUT 0 AND 8
783 001120 022713 000362 CMP #362, %CDS ;ONLY BITS 1, 4, 5, 6, AND 7 SHOULD BE SET
784 001124 001402 BEQ .+6 ;BRANCH IF OK
785 001126 104000 HLT ;STATUS REGISTER DIDN'T CONTAIN 362
786 001130 000413 BR TEST3 ;BRANCH AFTER FAILURE
787
788 ;CLEARING STATUS REGISTER SHOULD CLEAR BITS 1, 4, 5, AND 6
789 001132 005013 CLR %CDS ;CLEAR BITS 1, 4, 5, AND 6
790 001134 022713 000200 CMP #200, %CDS ;CHECK FOR ALL BITS CLEAR BUT 7
791 001140 001401 BEQ .+4 ;BRANCH IF OK
792 001142 104000 HLT ;STATUS REGISTER DIDN'T CONTAIN 200
793
794 ;SETTING ALL BITS SHOULD DO A POWER CLEAR
795 001144 012713 177777 MOV #177777, %CDS ;SET ALL BITS OF THE STATUS REGISTER
796 001150 022713 000200 CMP #200, %CDS ;CHECK FOR ALL BITS CLEAR BUT 7
797 001154 001401 BEQ .+4 ;BRANCH IF OK
798 001156 104000 HLT ;STATUS REGISTER DIDN'T CONTAIN 200
799

```

```

800 001160 104400          TEST3: SCOPE
801                                ;TEST THE COLUMN COUNT REGISTER FOR READ/WRITE-ABILITY
802 001162 012714 177777    MOV      #177777, @CDC      ;LOAD ALL BITS
803 001166 022714 177777    CMP      #177777, @CDC      ;TEST TO SEE IF IT CAN BE READ
804 001172 001401          BEQ      .+4                ;BRANCH IF OK
805 001174 104000          HLT                                ;CDCC FAILED TO READ/WRITE
806
807 001176 022713 000200    CMP      #200,  @CDS       ;CHECK STATUS REG
808 001202 001401          BEQ      .+4                ;BRANCH IF OK
809 001204 104000          HLT                                ;STATUS REG CHANGED
810
811 001206 052713 000400    BIS      #400,  @CDS       ;DO A POWER CLEAR
812 001212 005714          TST      @CDC              ;CHECK FOR COLUMN COUNT CLEARED
813 001214 001401          BEQ      .+4                ;BRANCH IF OK
814 001216 104000          HLT                                ;COLUMN COUNT NOT CLEARED BY POWER CLEAR
815
816 001220 022713 000200    CMP      #200,  @CDS       ;CHECK STATUS REG
817 001224 001401          BEQ      .+4                ;BRANCH IF OK
818 001226 104000          HLT                                ;STATUS REG CHANGED
819
820 001230 104400          TEST4: SCOPE
821                                ;TEST THE BUS ADDRESS REGISTER FOR READ/WRITE-ABILITY
822 001232 012715 177777    MOV      #177777, @CDA     ;LOAD ALL BITS
823 001236 022715 177777    CMP      #177777, @CDA     ;TEST TO SEE IF IT CAN BE READ
824 001242 001401          BEQ      .+4                ;BRANCH IF OK
825 001244 104000          HLT                                ;CDBA FAILED TO READ/WRITE
826
827 001246 022713 000200    CMP      #200,  @CDS       ;CHECK STATUS REG
828 001252 001401          BEQ      .+4                ;BRANCH IF OK
829 001254 104000          HLT                                ;STATUS REG CHANGED
830
831 001256 052713 000400    BIS      #400,  @CDS       ;DO A POWER CLEAR
832 001262 005715          TST      @CDA              ;CHECK FOR BUS ADDRESS CLEARED
833 001264 001401          BEQ      .+4                ;BRANCH IF OK
834 001266 104000          HLT                                ;BUS ADDRESS NOT CLEARED BY POWER CLEAR
835
836 001270 022713 000200    CMP      #200,  @CDS       ;CHECK STATUS REG
837 001274 001401          BEQ      .+4                ;BRANCH IF OK
838 001276 104000          HLT                                ;STATUS REG CHANGED
839
840 001300 104400          TEST5: SCOPE
841                                ;START SHOULD CAUSE CONTROLLER READY WITHIN ABOUT 1 SECOND
842                                ;BIT 0 SHOULD ALWAYS READ AS BEING EQUAL TO ZERO
843 001302 004767 010672    JSR      %7,  CKOFFL       ;CHECK FOR OFF-LINE SET
844 001306 012714 177777    MOV      #-1,  @CDC        ;SET UP COLUMN COUNT TO READ 1 COLUMN
845 001312 012715 016000    MOV      #BUFBEQ, @CDA     ;SET UP BUS ADDRESS
846 001316 016767 176454 177204  MOV      PS,  PROC         ;STORE CURRENT PROCESSOR STATUS
847 001324 005067 176446    CLR      PS                ;CLEAR TRACE BIT
848 001330 005067 177166    CLR      COUNT            ;INITIALIZE COUNTER
849 001334 005213          INC      @CDS              ;START READING A CARD
850 001336 105713          TSTB    @CDS              ;CHECK FOR CONTROLLER READY CLEARED
851 001340 100001          BPL     .+4                ;BRANCH IF OK
852 001342 104000          HLT                                ;CONTROLLER READY DIDN'T CLEAR
853
854 001344 032713 000001    LOPS5: BIT      #1,  @CDS   ;CHECK BIT 0
855 001350 001402          BEQ     .+6                ;BRANCH IF NOT SET

```

```

856 001352 104000          HLT          ;BIT 0 READ AS A ONE
857 001354 000421          BR          TEST6      ;BRANCH AFTER FAILURE
858 001356 005267 177140  INC          COUNT     ;WAIT ABOUT
859 001362 001370          BNE        LOOP5
860 001364 016767 177140 176404 MOV        PROC, PS    ;RESTORE PROCESSOR STATUS
861 001372 105713          TSTB       ACDS
862 001374 100401          BMI        .+4        ;CHECK CONTROLLER READY
863 001376 104000          HLT          ;CONTINUE IF SET
864 001400 005713          TST        ACDS        ;CONTROLLER READY DIDN'T SET WITHIN 1 SEC
865 001402 100002          BPL        .+6
866 001404 104000          HLT          ;ERROR BIT SET
867 001406 000404          BR          TEST6
868 001410 032713 177577  BIT          #177577, ACDS ;CHECK FOR ANY OTHER BITS
869 001414 001401          BEQ        .+4        ;BRANCH IF OK
870 001416 104000          HLT          ;EXTRA BIT(S) SET
871
872 001420 104400          TEST6: SCOPE
873          ; (BIT 2) SHOULD NOT BE SET BY READING A CARD
874          ; IT SHOULD REMAIN NOT SET
875          ; THIS SHOULD HAPPEN WITHIN ABOUT 1 SECOND
876 001422 004767 010552  JSR        %7, CKOFFL  ;CHECK FOR OFF-LINE SET
877 001426 005013          CLR        ACDS        ;INITIALIZE STATUS REGISTER
878 001430 012714 177754  MOV        #-20, ACDC  ;SET UP COLUMN COUNT TO READ 20 COLUMNS
879 001434 012715 016000  MOV        #BUFBEG, ACDA ;SET UP BUS ADDRESS
880 001440 005213          INC        ACDS        ;READ A CARD
881 001442 032713 000004  BIT        #4, ACDS    ;CHECK BUSY
882 001446 001401          BEQ        .+4
883 001450 104000          HLT          ;BUSY SET
884 001452 005067 177044  CLR        COUNT      ;SET UP WAIT COUNTER
885 001456 016767 176314 177044 MOV        PS, PROC    ;SAVE PROCESSOR STATUS
886 001464 005067 176306  CLR        PS
887 001470 105713          TSTB       ACDS        ;CLR THE T BIT
888 001472 100405          BMI        LOOP6A     ;CHECK READY
889 001474 005367 177022  DEC        COUNT      ;BRANCH IF READY
890 001500 001373          BNE        LOOP6A     ;WAIT ABOUT 1 SEC.
891 001502 104000          HLT          ;READING A CARD DIDN'T SET READY
892 001504 000411          BR          TEST7
893 001506 016767 177016 176262 LOOP6B: MOV        PROC, PS    ;RESTORE THE STATUS
894 001514 105713          TSTB       ACDS        ;CHECK CONTROLLER READY
895 001516 100401          BMI        DONE6      ;BRANCH IF SET
896 001520 104000          HLT          ;RESTORING STATUS RESET READY
897
898 001522 005713          DONE6: TST        ACDS ;CHECK ERROR BIT 15
899 001524 100001          BPL        .+4        ;BRANCH IF OK
900 001526 104000          HLT          ;ERROR BIT 15 WAS SET
901
902 001530 104400          TEST7: SCOPE
903          ;CONTROLLER READY SHOULD CAUSE AN INTERRUPT
904 001532 004767 010376  JSR        %7, INIT    ;INITIALIZE
905 001536 012712 001622  MOV        #TINT7, ADINT ;LOAD RETURN POINTER
906 001542 052767 000340 176226 BIS        #340, PS    ;SET PROCESSOR TO LEVEL 7
907 001550 016762 176222 000002 MOV        PS, 2(ADINT) ;LOAD RETURN PROCESSOR STATUS
908 001556 042767 000340 176212 BIC        #340, PS    ;SET PROCESSOR PRIORITY TO 0
909 001564 012714 177741  MOV        #-31, ACDC  ;SET UP COLUMN COUNT TO READ 31 COLUMNS
910 001570 012715 016000  MOV        #BUFBEG, ACDA ;SET UP BUS ADDRESS
911 001574 012713 000101  MOV        #101, ACDS  ;SET INTERRUPT ENABLE AND READ

```

```

912 001600 105713          TSTB  ACDS          ;WAIT FOR CONTROLLER READY
913 001602 100376          BPL   -2
914 001604 016267 000002 176164  MOV  2(ADINT),PS    ;RESTORE PROCESSOR TO HIGHEST PRIORITY
915 001612 042713 000100          BIC  #100, ACDS     ;CLEAR INTERRUPT ENABLE
916 001616 104000          HLT
917 001620 000410          BR   CONT7         ;NO INTERRUPT OCCURRED
918 001622 105713          TINT7: TSTB ACDS     ;CHECK CONTROLLER READY
919 001624 100401          BMI  .+4           ;BRANCH IF SET
920 001626 104000          HLT
921 001630 022626          CMP  (SP)+, (SP)+  ;CONTROLLER READY NOT SET
922 001632 005713          TST  ACDS          ;RESTORE STACK POINTER
923 001634 100001          BPL  .+4           ;MAKE SURE NO ERROR OCCURRED
924 001636 104000          HLT
925 001640 005013          CLR  ACDS          ;BIT 15 WAS SET
926 001642 012712 000232  CONT7: MOV  #232,ADINT ;DISABLE INTERRUPTS
927 001646 005037 000232          CLR  #232         ;CHANGE INTERRUPT RETURN ADDRESS
928                                     ;TO CAUSE A HALT IF AN INTERRUPT OCCURS
929 001652 104400          TEST10: SCOPE
930                                     ;CONTROLLER READY SHOULDN'T CAUSE AN INTERRUPT IF THE PROCESSOR IS
931                                     ;AT LEVEL 7 PRIORITY
932 001654 004767 010254          JSR  %7, INIT      ;INITIALIZE
933 001660 012712 001722          MOV  #TINT10,ADINT ;SETUP RETURN
934 001664 052767 000340 176104  BIS  #340, PS      ;SETUP RETURN ADDRESS
935 001672 016762 176100 000002  MOV  PS, 2(ADINT)  ;SET PROCESSOR TO LEVEL 7 PRIORITY
936 001700 012714 177703          MOV  #-61, ACDC    ;LOAD RETURN PROCESSOR STATUS
937 001704 012715 016000          MOV  #BUFBEG,ACDA  ;SET UP COLUMN COUNT TO READ 61 COLUMNS
938 001710 012713 000101          MOV  #101, ACDS    ;SET UP BUS ADDRESS
939 001714 105713          TSTB ACDS          ;SET INTERRUPT ENABLE AND READ
940 001716 100376          BPL  -2           ;WAIT FOR CONTROLLER READY
941 001720 000402          BR   .+6         ;CONTINUE IF NO INTERRUPT OCCURRED
942 001722 104000          TINT10: HLT        ;AN INTERRUPT OCCURRED
943 001724 022626          CMP  (SP)+, (SP)+ ;RESTORE STACK POINTER
944 001726 005013          CLR  ACDS          ;CLEAR INTERRUPT ENABLE
945 001730 012712 000232  MOV  #232,ADINT    ;CHANGE INTERRUPT RETURN ADDRESS
946 001734 005037 000232          CLR  #232         ;TO CAUSE A HALT IF AN INTERRUPT OCCURS
947
948                                     ;FIND THE LEVEL AT WHICH AN INTERRUPT OCCURS
949                                     ;PRINT OUT A MESSAGE STATING THIS LEVEL IF IT IS OTHER THAN THE STANDARD
950                                     ;:(LEVEL 6) MAKE CERTAIN THAT IT ALWAYS OCCURS AT THIS LEVEL
951                                     ;THE MESSAGE STATING THE LEVEL IS PRINTED ONLY ONCE, AND THE PROGRAM MUST
952                                     ;BE STARTED OVER AT LOCATION 200 FOR IT TO BE PRINTED AGAIN
953
954                                     ;TEST FOR AN INTERRUPT ON LEVEL 7
955 TEST11: SCOPE
956 001740 104400          JSR  %7, INIT      ;INITIALIZE
957 001742 004767 010166          MOV  #TINT11,ADINT ;SETUP RETURN ADDRESS
958 001746 012712 002064          BIS  #340, PS      ;SETUP RETURN ADDRESS
959 001752 052767 000340 176016  MOV  PS, 2(ADINT)  ;SET PROCESSOR PRIORITY TO 7
960 001760 016762 176012 000002  MOV  #340, PS      ;SETUP RETURN PROCESSOR STATUS
961 001766 042767 000340 176002  BIC  #340, PS      ;SET PROCESSOR PRIORITY TO 0
962 001774 052767 000300 175774  BIS  #300, PS      ;SET PROCESSOR TO LEVEL 6 PRIORITY
963 002002 012714 177660          MOV  #-80, ACDC    ;SETUP COLUMN COUNT TO READ 80 COLUMNS
964 002006 012715 016000          MOV  #BUFBEG,ACDA  ;SET UP BUS ADDRESS
965 002012 012713 000101          MOV  #101, ACDS    ;SETUP BUS ADDRESS
966 002016 105713          TSTB ACDS          ;SET INTERRUPT ENABLE AND READ
967 002020 100376          BPL  -2           ;WAIT FOR CONTROLLER READY
967 002022 016267 000002 175746  MOV  2(ADINT),PS    ;RESTORE PROCESSOR TO HIGHEST PRIORITY

```





1024	002322	005767	176176		TST	INTFLG		:CHECK FOR PREVIOUS FLAG
1025	002326	100413			BMI	SET6	:BRANCH	IF FLAG SET
1026	002330	012767	100006	176166	MOV	#100006,INTFLG		:SET FLAG AND LEVEL
1027	002336	000004	014056		TYPE,	MSG4		:PRINT MESSAGE "THE INTERRUPT LEVEL WAS"
1028	002342	012767	000006	010204	MOV	#6,PRINT1		:TYPE #6 IN OCTAL
1029	002350	004767	010244		JSR	%7,PRINTS		:AND SUPRESS LEADING ZERO'S
1030	002354	000405			BR	TEST13		
1031	002356	026727	176142	100006	SET6: CMP	INTFLG, #100006		:CHECK PREVIOUS LEVEL
1032	002364	100001			BPL	TEST13		
1033	002366	104000			HLT			:INTERRUPT PREVIOUSLY OCCURRED ONLY AT A LOWER LEVEL
1034					:TEST FOR AN INTERRUPT ON LEVEL 5			
1035	002370	104400			TEST13: SCOPE			
1036	002372	004767	007536		JSR	%7, INIT		:INITIALIZE
1037	002376	012712	002514		MOV	#TINT13,ADINT		:SETUP RETURN ADDRESS
1038	002402	052767	000340	175366	BIS	#340, PS		:SET PROCESSOR PRIORITY TO 7
1039	002410	016762	175362	000002	MOV	PS, 2(ADINT)		:SETUP RETURN PROCESSOR STATUS
1040	002416	042767	000340	175352	BIC	#340, PS		:SET PROCESSOR PRIORITY TO 0
1041	002424	052767	000200	175344	BIS	#200, PS		:SET PROCESSOR TO LEVEL 4 PRIORITY
1042	002432	012714	177660		MOV	#-80,ACDC		:SET UP COLUMN COUNT TO READ 80 COLUMNS
1043	002436	012715	016000		MOV	#BUFBEQ,ACDA		:SET UP BUS ADDRESS
1044	002442	012713	000101		MOV	#101,ACDS		:SET INTERRUPT ENABLE AND READ
1045	002446	105713			TSTB	ACDS		:WAIT FOR CONTROLLER READY
1046	002450	100376			BPL	-2		
1047	002452	016267	000002	175316	MOV	2(ADINT),PS		:RESTORE PROCESSOR TO HIGHEST PRIORITY
1048	002460	005013			CLR	ACDS		:DISABLE INTERRUPTS
1049	002462	012712	000232		MOV	#232,ADINT		:CHANGE INTERRUPT RETURN ADDRESS
1050	002466	005037	000232		CLR	#232		:TO CAUSE A HALT IF AN INTERRUPT OCCURS
1051	002472	005767	176026		TST	INTFLG		:TEST FOR A PREVIOUS INTERUPT
1052	002476	001442			BEQ	TEST14		:BRANCH IF NONE
1053	002500	026727	176020	100005	CMP	INTFLG, #100005		:CHECK PREVIOUS LEVEL
1054	002506	100436			BMI	TEST14		:BRANCH IF LOWER
1055	002510	104000			HLT			:INTERUPT PREVIOUSLY OCCURRED AT LEVEL 5 OR HIGHER
1056	002512	000434			BR	TEST14		
1057	002514	105713			TINT13: TSTB	ACDS		:MAKE SURE CONTROLLER READY IS SET
1058	002516	100401			BMI	.+4		:BRANCH IF SET
1059	002520	104000			HLT			:CONTROLLER READY WASN'T SET
1060	002522	005013			CLR	ACDS		:DISABLE FURTHER INTERRUPTS
1061	002524	012712	000232		MOV	#232,ADINT		:CHANGE INTERRUPT RETURN ADDRESS
1062	002530	005037	000232		CLR	#232		:TO CAUSE A HALT IF AN INTERRUPT OCCURS
1063	002534	022626			CMP	(SP)+ (SP)+		:RESTORE STACK POINTER
1064	002536	005767	175762		TST	INTFLG		:CHECK FOR PREVIOUS FLAG
1065	002542	100413			BMI	SET5	:BRANCH	IF FLAG SET
1066	002544	012767	100005	175752	MOV	#100005,INTFLG		:SET FLAG AND LEVEL
1067	002552	000004	014056		TYPE,	MSG4		:PRINT MESSAGE "THE INTERRUPT LEVEL WAS"
1068	002556	012767	000005	007770	MOV	#5,PRINT1		:TYPE #5 IN OCTAL
1069	002564	004767	010030		JSR	%7,PRINTS		:AND SUPRESS LEADING ZERO'S
1070	002570	000405			BR	TEST14		
1071	002572	026727	175726	100005	SET5: CMP	INTFLG, #100005		:CHECK PREVIOUS LEVEL
1072	002600	100001			BPL	TEST14		
1073	002602	104000			HLT			:INTERRUPT PREVIOUSLY OCCURRED ONLY AT A LOWER LEVEL
1074					:TEST FOR AN INTERRUPT ON LEVEL 4			
1075	002604	104400			TEST14: SCOPE			
1076	002606	004767	007322		JSR	%7, INIT		:INITIALIZE
1077	002612	012712	002730		MOV	#TINT14,ADINT		:SETUP RETURN ADDRESS
1078	002616	052767	000340	175152	BIS	#340, PS		:SET PROCESSOR PRIORITY TO 7
1079	002624	016762	175146	000002	MOV	PS, 2(ADINT)		:SETUP RETURN PROCESSOR STATUS

# M02

MAINDEC-11-DZCDA-C-D  
DZCDAC.P11

CD11 CARD READER DIAGNOSTICS  
LOGIC FUNCTION TESTS

MACY11 27(732) 15-OCT-76 16:01 PAGE 26

1080	002632	042767	000340	175136	BIC	#340,	PS	;SET PROCESSOR PRIORITY TO 0
1081	002640	052767	000140	175130	BIS	#140,	PS	;SET PROCESSOR TO LEVEL 3 PRIORITY
1082	002646	012714	177660		MOV	#-80,	QDCD	;SET UP COLUMN COUNT TO READ 80 COLUMNS
1083	002652	012715	016000		MOV	#BUFBEG,	QCD A	;SET UP BUS ADDRESS
1084	002656	012713	000101		MOV	#101,	QCD S	;SET INTERRUPT ENABLE AND READ
1085	002662	105713			TSTB	QCD S		;WAIT FOR CONTROLLER READY
1086	002664	100376			BPL	.-2		
1087	002666	016267	000002	175102	MOV	2(ADINT),	PS	;RESTORE PROCESSOR TO HIGHEST PRIORITY
1088	002674	005013			CLR	QCD S		;DISABLE INTERRUPTS
1089	002676	012712	000232		MOV	#232,	QADINT	;CHANGE INTERRUPT RETURN ADDRESS
1090	002702	005037	000232		CLR	Q#232		;TO CAUSE A HALT IF AN INTERRUPT OCCURS
1091	002706	005767	175612		TST	INTFLG		;TEST FOR A PREVIOUS INTERUPT
1092	002712	001433			BEQ	TEST15		;BRANCH IF NONE
1093	002714	026727	175604	100004	CMP	INTFLG,	#100004	;CHECK PREVIOUS LEVEL
1094	002722	100427			BMI	TEST15		;BRANCH IF LOWER
1095	002724	104000			HLT			;INTERUPT PREVIOUSLY OCCURRED AT LEVEL 4 OR HIGHER
1096	002726	000425			BR	TEST15		
1097	002730	105713			TINT14: TSTB	QCD S		;MAKE SURE CONTROLLER READY IS SET
1098	002732	100401			BMI	+.4		;BRANCH IF SET
1099	002734	104000			HLT			;CONTROLLER READY WASN'T SET
1100	002736	005013			CLR	QCD S		;DISABLE FURTHER INTERRUPTS
1101	002740	012712	000232		MOV	#232,	QADINT	;CHANGE INTERRUPT RETURN ADDRESS
1102	002744	005037	000232		CLR	Q#232		;TO CAUSE A HALT IF AN INTERRUPT OCCURS
1103	002750	022626			CMP	(SP)+	(SP)+	;RESTORE STACK POINTER
1104	002752	005767	175546		TST	INTFLG		;CHECK FOR PREVIOUS FLAG
1105	002756	100404			BMI	SET4		;BRANCH IF FLAG SET
1106	002760	012767	100004	175536	MOV	#100004,	INTFLG	;SET FLAG AND LEVEL
1107	002766	000405			BR	TEST15		
1108	002770	026727	175530	100004	SET4: CMP	INTFLG,	#100004	;CHECK PREVIOUS LEVEL
1109	002776	100001			BPL	TEST15		
1110	003000	104000			HLT			;INTERUPT PREVIOUSLY OCCURRED ONLY AT A LOWER LEVEL
1111					;TEST FOR AN INTERRUPT ON LEVEL 3			
1112	003002	104400			TEST15: SCOPE			
1113	003004	004767	007124		JSR	%7,	INIT	;INITIALIZE
1114	003010	012712	003126		MOV	#TINT15,	QADINT	;SETUP RETURN ADDRESS
1115	003014	052767	000340	174754	BIS	#340,	PS	;SET PROCESSOR PRIORITY TO 7
1116	003022	016762	174750	000002	MOV	PS,	2(ADINT)	;SETUP RETURN PROCESSOR STATUS
1117	003030	042767	000340	174740	BIC	#340,	PS	;SET PROCESSOR PRIORITY TO 0
1118	003036	052767	000100	174732	BIS	#100,	PS	;SET PROCESSOR TO LEVEL 2 PRIORITY
1119	003044	012714	177660		MOV	#-80,	QDCD	;SET UP COLUMN COUNT TO READ 80 COLUMNS
1120	003050	012715	016000		MOV	#BUFBEG,	QCD A	;SET UP BUS ADDRESS
1121	003054	012713	000101		MOV	#101,	QCD S	;SET INTERRUPT ENABLE AND READ
1122	003060	105713			TSTB	QCD S		;WAIT FOR CONTROLLER READY
1123	003062	100376			BPL	.-2		
1124	003064	016267	000002	174704	MOV	2(ADINT),	PS	;RESTORE PROCESSOR TO HIGHEST PRIORITY
1125	003072	005013			CLR	QCD S		;DISABLE INTERRUPTS
1126	003074	012712	000232		MOV	#232,	QADINT	;CHANGE INTERRUPT RETURN ADDRESS
1127	003100	005037	000232		CLR	Q#232		;TO CAUSE A HALT IF AN INTERRUPT OCCURS
1128	003104	005767	175414		TST	INTFLG		;TEST FOR A PREVIOUS INTERUPT
1129	003110	001442			BEQ	TEST16		;BRANCH IF NONE
1130	003112	026727	175406	100003	CMP	INTFLG,	#100003	;CHECK PREVIOUS LEVEL
1131	003120	100436			BMI	TEST16		;BRANCH IF LOWER
1132	003122	104000			HLT			;INTERUPT PREVIOUSLY OCCURRED AT LEVEL 3 OR HIGHER
1133	003124	000434			BR	TEST16		
1134	003126	105713			TINT15: TSTB	QCD S		;MAKE SURE CONTROLLER READY IS SET
1135	003130	100401			BMI	+.4		;BRANCH IF SET

```

1136 003132 104000 HLT ;CONTROLLER READY WASN'T SET
1137 003134 005013 CLR ;DISABLE FURTHER INTERRUPTS
1138 003136 012712 000232 MOV #232, @ADINT ;CHANGE INTERRUPT RETURN ADDRESS
1139 003142 005037 000232 CLR @#232 ;TO CAUSE A HALT IF AN INTERRUPT OCCURS
1140 003146 022626 CMP (SP)+, (SP)+ ;RESTORE STACK POINTER
1141 003150 005767 175350 TST INTFLG ;CHECK FOR PREVIOUS FLAG
1142 003154 100413 BMI SET3 ;BRANCH IF FLAG SET
1143 003156 012767 100003 175340 MOV #100003, INTFLG ;SET FLAG AND LEVEL
1144 003164 000004 014056 TYPE, MSG4 ;PRINT MESSAGE "THE INTERRUPT LEVEL WAS"
1145 003170 012767 000003 007356 MOV #3, PRINT1 ;TYPE #3 IN OCTAL
1146 003176 004767 007416 JSR %7, PRINTS ;AND SUPPRESS LEADING ZERO'S
1147 003202 000405 BR TEST16
1148 003204 026727 175314 100003 SET3: CMP INTFLG, #100003 ;CHECK PREVIOUS LEVEL
1149 003212 100001 BPL TEST16
1150 003214 104000 HLT ;INTERRUPT PREVIOUSLY OCCURRED ONLY AT A LOWER LEVEL
1151 ;TEST FOR AN INTERRUPT ON LEVEL 2
1152 003216 104400 TEST16: SCOPE
1153 003220 004767 006710 JSR %7, INIT ;INITIALIZE
1154 003224 012712 003342 MOV #TINT16, @ADINT ;SETUP RETURN ADDRESS
1155 003230 052767 000340 174540 BIS #340, PS ;SET PROCESSOR PRIORITY TO 7
1156 003236 016762 174534 000002 MOV PS, 2(ADINT) ;SETUP RETURN PROCESSOR STATUS
1157 003244 042767 000340 174524 BIC #340, PS ;SET PROCESSOR PRIORITY TO 0
1158 003252 052767 000040 174516 BIS #040, PS ;SET PROCESSOR TO LEVEL 1 PRIORITY
1159 003260 012714 177660 MOV #-80, @CDC ;SET UP COLUMN COUNT TO READ 80 COLUMNS
1160 003264 012715 016000 MOV #BUFBEG, @CDA ;SET UP BUS ADDRESS
1161 003270 012713 000101 MOV #101, @CDS ;SET INTERRUPT ENABLE AND READ
1162 003274 105713 TSTB @CDS ;WAIT FOR CONTROLLER READY
1163 003276 100376 BPL -2
1164 003300 016267 000002 174470 MOV 2(ADINT), PS ;RESTORE PROCESSOR TO HIGHEST PRIORITY
1165 003306 005013 CLR @CDS ;DISABLE INTERRUPTS
1166 003310 012712 000232 MOV #232, @ADINT ;CHANGE INTERRUPT RETURN ADDRESS
1167 003314 005037 000232 CLR @#232 ;TO CAUSE A HALT IF AN INTERRUPT OCCURS
1168 003320 005767 175200 TST INTFLG ;TEST FOR A PREVIOUS INTERUPT
1169 003324 001442 BEQ TEST17 ;BRANCH IF NONE
1170 003326 026727 175172 100002 CMP INTFLG, #100002 ;CHECK PREVIOUS LEVEL
1171 003334 100436 BMI TEST17 ;BRANCH IF LOWER
1172 003336 104000 HLT ;INTERRUPT PREVIOUSLY OCCURRED AT LEVEL 2 OR HIGHER
1173 003340 000434 BR TEST17
1174 003342 105713 TINT16: TSTB @CDS ;MAKE SURE CONTROLLER READY IS SET
1175 003344 100401 BMI .+4 ;BRANCH IF SET
1176 003346 104000 HLT ;CONTROLLER READY WASN'T SET
1177 003350 005013 CLR @CDS ;DISABLE FURTHER INTERRUPTS
1178 003352 012712 000232 MOV #232, @ADINT ;CHANGE INTERRUPT RETURN ADDRESS
1179 003356 005037 000232 CLR @#232 ;TO CAUSE A HALT IF AN INTERRUPT OCCURS
1180 003362 022626 CMP (SP)+, (SP)+ ;RESTORE STACK POINTER
1181 003364 005767 175134 TST INTFLG ;CHECK FOR PREVIOUS FLAG
1182 003370 100413 BMI SET2 ;BRANCH IF FLAG SET
1183 003372 012767 100002 175124 MOV #100002, INTFLG ;SET FLAG AND LEVEL
1184 003400 000004 014056 TYPE, MSG4 ;PRINT MESSAGE "THE INTERRUPT LEVEL WAS"
1185 003404 012767 000002 007142 MOV #2, PRINT1 ;TYPE #2 IN OCTAL
1186 003412 004767 007202 JSR %7, PRINTS ;AND SUPPRESS LEADING ZERO'S
1187 003416 000405 BR TEST17
1188 003420 026727 175100 100002 SET2: CMP INTFLG, #100002 ;CHECK PREVIOUS LEVEL
1189 003426 100001 BPL TEST17
1190 003430 104000 HLT ;INTERRUPT PREVIOUSLY OCCURRED ONLY AT A LOWER LEVEL
1191 ;TEST FOR AN INTERRUPT ON LEVEL 1

```

```

1192 003432 104400          TEST17: SCOPE
1193 003434 004767 006474   JSR    %7, INIT      ;INITIALIZE
1194 003440 012712 003540   MOV    #TINT17,ADINT ;SETUP RETURN ADDRESS
1195 003444 052767 000340 174324   BIS    #340, PS      ;SET PROCESSOR PRIORITY TO 7
1196 003452 016762 174320 000002   MOV    PS, 2(ADINT) ;SETUP RETURN PROCESSOR STATUS
1197 003460 042767 000340 174310   BIC    #340, PS      ;SET PROCESSOR PRIORITY TO 0
1198 003466 052767 000000 174302   BIS    #000, PS      ;SET PROCESSOR TO LEVEL 0 PRIORITY
1199 003474 012714 177660   MOV    #-80, @CDC    ;SET UP COLUMN COUNT TO READ 80 COLUMNS
1200 003500 012715 016000   MOV    #BUFBEG,@CDA  ;SET UP BUS ADDRESS
1201 003504 012713 000101   MOV    #101, @CDS    ;SET INTERRUPT ENABLE AND READ
1202 003510 105713   TSTB  @CDS           ;WAIT FOR CONTROLLER READY
1203 003512 100376   BPL    -2
1204 003514 016267 000002 174254   MOV    2(ADINT),PS   ;RESTORE PROCESSOR TO HIGHEST PRIORITY
1205 003522 005013   CLR    @CDS          ;DISABLE INTERRUPTS
1206 003524 012712 000232   MOV    #232, @ADINT  ;CHANGE INTERRUPT RETURN ADDRESS
1207 003530 005037 000232   CLR    @#232        ;TO CAUSE A HALT IF AN INTERRUPT OCCURS
1208 003534 104000   HLT
1209 003536 000434   BR     TEST20
1210 003540 105713   TINT17: TSTB @CDS    ;MAKE SURE CONTROLLER READY IS SET
1211 003542 100401   BMI    .+4          ;BRANCH IF SET
1212 003544 104000   HLT                ;CONTROLLER READY WASN'T SET
1213 003546 005013   CLR    @CDS        ;DISABLE FURTHER INTERRUPTS
1214 003550 012712 000232   MOV    #232, @ADINT ;CHANGE INTERRUPT RETURN ADDRESS
1215 003554 005037 000232   CLR    @#232      ;TO CAUSE A HALT IF AN INTERRUPT OCCURS
1216 003560 022626   CMP    (SP)+, (SP)+ ;RESTORE STACK POINTER
1217 003562 005767 174736   TST   INTFLG      ;CHECK FOR PREVIOUS FLAG
1218 003566 100413   BMI    SET1        ;BRANCH IF FLAG SET
1219 003570 012767 100001 174726   MOV    #100001,INTFLG ;SET FLAG AND LEVEL
1220 003576 000004 014056   TYPE, MSG4        ;PRINT MESSAGE "THE INTERRUPT LEVEL WAS"
1221 003602 012767 000001 006744   MOV    #1,PRINT1  ;TYPE #1 IN OCTAL
1222 003610 004767 007004   JSR    %7,PRINTS  ;AND SUPPRESS LEADING ZERO'S
1223 003614 000405   BR     TEST20
1224 003616 026727 174702 100001 SET1: CMP INTFLG, #100001 ;CHECK PREVIOUS LEVEL
1225 003624 100001   BPL    TEST20
1226 003626 104000   HLT                ;INTERRUPT PREVIOUSLY OCCURRED ONLY AT A LOWER LEVEL
1227
1228 003630 104400          TEST20: SCOPE
1229 ;TEST FOR NO INTERRUPT OCCURING WITH INTERRUPT ENABLE SET AND REST CLEARED
1230 003632 004767 006276   JSR    %7, INIT    ;INITIALIZE CSR TO ZERO
1231 003636 012712 003722   MOV    #TINT20,ADINT ;SETUP RETURN ADDRESS
1232 003642 052767 000340, 174126   BIS    #340, PS     ;SET PROCESSOR TO LEVEL 7
1233 003650 016762 174122 000002   MOV    PS, 2(ADINT) ;STORE PROCESSOR STATUS
1234 003656 005067 174114   CLR    PS          ;SET PROCESSOR TO LEVEL 0
1235 003662 012714 177777   MOV    #-1, @CDC   ;SET UP COLUMN COUNT TO READ 1 COLUMN
1236 003666 012715 016000   MOV    #BUFBEG,@CDA ;SET UP BUS ADDRESS
1237 003672 012713 000100   MOV    #100, @CDS  ;ENABLE INTERRUPTS
1238 003676 005067 174620   CLR    COUNT      ;INITIALIZE COUNTER
1239 003702 005267 174614   INC   COUNT       ;WAIT AWHILE
1240 003706 001375   BNE    .-4
1241 003710 016267 000002 174060   MOV    2(ADINT),PS  ;RESTORE PROCESSOR TO LEVEL 7
1242 003716 005013   CLR    @CDS        ;DISABLE FURTHER INTERRUPTS
1243 003720 000403   BR     CONT20
1244 003722 104000   TINT20: HLT        ;AN INTERRUPT OCCURRED
1245 003724 022626   CMP    (SP)+, (SP)+ ;RESTORE STACK
1246 003726 005013   CLR    @CDS        ;DISABLE FURTHER INTERRUPTS
1247 003730 005037 000232   CONT20: CLR @#232  ;CHANGE INTERRUPT RETURN ADDRESS TO

```

```

1248 003734 012712 000232      MOV      #232,  @ADINT ;CAUSE A HALT IF AN INTERRUPT OCCURS
1249
1250 003740 104400      TEST21: SCOPE
1251      ;CHECK FOR SIMULTANEOUS INTERRUPTS ON MORE THAN ONE LEVEL
1252 003742 004767 006166      JSR      %7,  INIT      ;INITIALIZE CSR TO ZERO
1253 003746 012712 004012      MOV      #TINT21, @ADINT ;SETUP RETURN ADDRESS
1254 003752 052767 000340 174016      BIS      #340,  PS      ;SET PROCESSOR TO LEVEL 7
1255 003760 016762 174012 000002      MOV      PS,    2(ADINT) ;STORE PROCESSOR STATUS
1256 003766 042767 000340 174002      BIC      #340,  PS      ;SET PROCESSOR TO LEVEL 0
1257 003774 012714 177777      MOV      #-1,  @CDC     ;SET UP COLUMN COUNT TO READ 1 COLUMN
1258 004000 012715 016000      MOV      #BUFBEQ, @CDA   ;SET UP BUS ADDRESS
1259 004004 012713 000101      MOV      #101,  @CDS    ;SET INTERRUPT ENABLE AND READ
1260 004010 000777      BR                          ;WAIT FOR INTERRUPT
1261 004012 022626      TINT21: CMP      (SP)+, (SP)+ ;RESTORE STACK POINTER
1262 004014 012712 004036      MOV      #TINA21, @ADINT ;CHANGE RETRUN ADDRESS
1263 004020 005067 173752      CLR      PS              ;SET PROCESSOR TO LEVEL 0
1264 004024 000240      NOP                          ;WAIT
1265 004026 016267 000002 173742      MOV      2(ADINT), PS    ;RESTORE PROCESSOR TO LEVEL 7
1266 004034 000402      BR                          ;
1267 004036 022626      TINA21: CMP      (SP)+, (SP)+ ;RESTORE STACK
1268 004040 104000      HLT                          ;THE INTERRUPT OCCURRED AT 2 LEVELS
1269 004042 005013      CONT21: CLR      @CDS     ;DISABLE INTERRUPTS
1270 004044 005037 000232      CLR      @#232          ;CHANGE INTERRUPT RETURN ADDRESS TO
1271 004050 012712 000232      MOV      #232,  @ADINT  ;CAUSE A HALT IF AN INTERRUPT OCCURS
1272
1273 004054 104400      TEST22: SCOPE
1274      ;CHECK THAT NON-EXISTANT MEMORY IS DETECTED PROPERLY
1275 004056 004767 006052      JSR      %7,  INIT      ;INITIALIZE CSR TO ZERO
1276 004062 012712 004126      MOV      #TINT22, @ADINT ;SETUP RETURN ADDRESS
1277 004066 052767 000340 173702      BIS      #340,  PS      ;SET PROCESSOR TO LEVEL 7
1278 004074 016762 173676 000002      MOV      PS,    2(ADINT) ;STORE PROCESSOR STATUS
1279 004102 042767 000340 173666      BIC      #340,  PS      ;SET PROCESSOR TO LEVEL 0
1280 004110 012714 177773      MOV      #-5,  @CDC     ;SET UP COLUMN COUNT TO READ 1 COLUMN
1281 004114 012715 160000      MOV      #160000, @CDA  ;SET UP BUS ADDRESS TO NON-EXISTANT MEMORY
1282 004120 012713 000161      MOV      #161,  @CDS    ;SET INTERRUPT ENABLE AND READ, X MEM BITS SET
1283 004124 000777      BR                          ;WAIT FOR INTERRUPT
1284 004126 022626      TINT22: CMP      (SP)+, (SP)+ ;RESTORE STACK
1285 004130 005037 000232      CLR      @#232          ;CHANGE INTERRUPT RETURN ADDRESS TO
1286 004134 012712 000232      MOV      #232,  @ADINT  ;CAUSE A HALT IF AN INTERRUPT OCCURS
1287 004140 105713      TSTB     @CDS           ;CHECK FOR CONTROLLER READY
1288 004142 100401      BMI      .+4             ;BRANCH IF SET OK
1289 004144 104000      HLT                          ;CONTROLLER READY DIDN'T SET
1290
1291 004146 005713      TST      @CDS           ;CHECK FOR ERROR (BIT 15)
1292 004150 100401      BMI      .+4             ;BRANCH IF SET OK
1293 004152 104000      HLT                          ;ERROR BIT 15 NOT SET
1294
1295 004154 032713 001000      BIT      #1000, @CDS    ;CHECK FOR NON-EXISTANT MEMORY (BIT 9)
1296 004160 001001      BNE      .+4             ;BRANCH IF SET OK
1297 004162 104000      HLT                          ;BIT 9 NOT SET
1298
1299 004164 032713 000040      BIT      #40,  @CDS     ;CHECK FOR EXTENDED MEMORY BIT 17 SET
1300 004170 001001      BNE      .+4             ;BRANCH IF SET OK
1301 004172 104000      HLT                          ;EX-MEM BIT 17 GOT CLEARED
1302
1303 004174 032713 000020      BIT      #20,  @CDS     ;CHECK FOR EX-MEM (BIT 4)

```

```

1304 004200 001001      BNE      .+4      ;BRANCH IF SET OK
1305 004202 104000      HLT      ;EX-MEM (BIT 4) GOT CLEARED
1306
1307 004204 032713 076417 BIT      #076417,DCDS ;CHECK FOR ANY OTHER BITS
1308 004210 001401      BEQ      .+4      ;BRANCH IF OK
1309 004212 104000      HLT      ;EXTRA ERROR BITS SET
1310
1311 004214 022715 160002 CMP      #160002,DCDA ;CHECK ADDRESS BUFFER
1312 004220 001401      BEQ      .+4      ;BRANCH IF OK
1313 004222 104000      HLT      ;BUS ADDRESS REG CHANGED
1314
1315 004224 022714 177774 CMP      #-4, DCDC  ;CHECK COLUMN COUNT REG
1316 004230 001401      BEQ      .+4      ;BRANCH IF OK
1317 004232 104000      HLT      ;COLUMN COUNT REG CHANGED
1318
1319 ;CHECK SW7 AND RETURN TO TEST1 IF SET, AFTER RINGING BELL
1320 ;OTHERWISE GO INTO THE DATA TEST
1321 004234 104400      ENDCK:  SCOPE
1322 004236 032767 000200 173324 BIT      #200,SWR
1323 004244 001406      BEQ      DATST
1324 004246 004767 005710 JSR      %7,BELL
1325 004252 005167 174250 COM      TRFLG      ;TOGGLE TRACE FLAG
1326 004256 000167 174532 JMP      RESTRT
1327
1328
1329
1330
1331
1332
1333
1334
1335 ;*****
1336 ;DATA RELIABILITY TEST FOR CD11
1337 ;*****
1338
1339 ;CHECK SWR FOR TYPE OF DECK BEING TESTED, AND INITIALIZE POINTERS
1340 DATST: CLR      CLCNT      ;MAKE SURE COLUMN COUNT IS ZERO
1341 CLR      CDCNT      ;SETUP CARD COUNT TO ENTER DATA TABLE AT BEGINNING
1342 CLR      ERFLG      ;FLAG SET PREVENTS PRINTING OUT ERROR HEADING
1343 004276 032767 000020 173264 BIT      #20, SWR      ;CHECK BIT 4 OF SWR FOR TYPE OF DECK
1344 004304 001412      BEQ      ALP1      ;BRANCH IF NOT SET TO LOAD ALPHANUMERIC POINTERS
1345 004306 012767 013324 002202 MOV      #BINCD, TSTART ;BIT 2 SET, LOAD BINARY TABLE POINTERS
1346 004314 012767 013564 002176 MOV      #BINEND+2, TEND
1347 004322 012767 015127 001632 MOV      #MSG15, DECK
1348 004330 000411      BR      CONTD      ;BRANCH AROUND ALPHANUMERIC POINTERS
1349 004332 012767 012744 002156 ALP1: MOV      #ALPCD, TSTART ;LOAD ALPHANUMERIC TABLE POINTERS
1350 004340 012767 013204 002152 MOV      #ALPEND+2, TEND
1351 004346 012767 015116 001606 MOV      #MSG14, DECK
1352 004354 005767 174146 CONTD: TST      TRFLG      ;CHECK TRACE TRAP FLAG
1353 004360 001004      BNE      TRP1      ;BRANCH IF FLAG WAS SET
1354 004362 012767 000340 173406 NOTRP1: MOV      #340, PS      ;CLEAR TRACE BIT
1355 004370 000407      BR      DCNT1
1356 004372 032767 010000 173170 TRP1: BIT      #10000, SWR ;CHECK SW12 TO INHIBIT TRACE TRAPPING
1357 004400 001370      BNE      NOTRP1   ;BRANCH IF SET
1358 004402 012767 000360 173366 MOV      #360, PS      ;SET TRACE BIT
1359 004410 004767 005520 DCNT1: JSR      %7, INIT ;INITIALIZE CARD READER STATUS REGISTER

```

# E03

MAINDEC-11-DZCDA-C-D  
DZCDA.P11

CD11 CARD READER DIAGNOSTICS  
DATA RELIABILITY TEST

MACY11 27(732) 15-OCT-76 16:01 PAGE 31

```

1360 ;SET UP INTERRUPT SERVICING, AND START READING
1361 004414 012712 004546 MOV #SRVC, ADINT ;SETUP RETURN POINTER
1362 004420 042767 000340 173350 BIC #340, PS ;SET PROCESSOR TO LEVEL 0
1363 004426 016762 173344 000002 MOV PS, 2(ADINT) ;STORE CURRENT STATUS
1364 004434 016701 002056 MOV TSTART, R1 ;SET UP TABLE POINTER
1365 004440 012700 016000 MOV #BUFBEG, RO ;SET UP BUFFER POINTER
1366 004444 012767 177660 002032 MOV #-120, SIZE ;SET UP "SIZE"
1367 004452 012767 177660 002026 MOV #-120, OFFSET
1368 004460 016714 002020 MOV SIZE, ADCDC ;SET UP COLUMN COUNT
1369 004464 010015 MOV RO, ADCDA ;SET UP ADDRESS REG
1370 004466 012713 000100 MOV #100, ADCDS ;ENABLE INTERRUPTS
1371 004472 032767 000010 173070 BIT #10, SWR ;CHECK FOR PACK MODE ONLY
1372 004500 001406 BEQ CDREAD ;BRANCH IF NOT SET
1373 004502 032737 000004 177570 BIT #4, ASWR ;CHECK FOR IMAGE MODE ONLY
1374 004510 001002 BNE CDREAD ;BRANCH IF SET
1375 004512 004767 001372 JSR %7, PAKSET ;SET UP FOR PACKING MODE
1376 004516 005213 CDREAD: INC ADCDS ;READ
1377 004520 032713 004000 BKGND: BIT #4000, ADCDS ;CHECK FOR DATA ERROR
1378 004524 001775 BEQ BKGND
1379 004526 011467 001776 MOV ADCDC, DERCNT ;SAVE THE COLUMN COUNT
1380 004532 032713 004000 BKGND1: BIT #4000, ADCDS ;CHECK FOR DATA ERROR
1381 004536 001375 BNE BKGND1 ;BRANCH IF SET
1382 004540 005067 001764 CLR DERCNT ;CLR COLUMN COUNT SAVER
1383 004544 000765 BR BKGND

1384
1385 ;INTERRUPT SERVICE ROUTINE WHICH RUNS DATA RELIABILITY TEST
1386 004546 105713 SRVC: TSTB ADCDS ;CHECK CONTROLLER READY
1387 004550 100401 BMI .+4 ;BRANCH IF SET
1388 004552 104000 HLT ;CONTROLLER READY NOT SET
1389 004554 032713 000002 BIT #2, ADCDS ;CHECK FOR DATA PACK MODE
1390 004560 001402 BEQ ISR ;BRANCH IF IMAGE MODE
1391 004562 000167 000470 JMP PSR ;JUMP TO PACK MODE ROUTINE
1392
1393 004566 032713 177477 ISR: BIT #177477, ADCDS ;CHECK ALL BITS EXCEPT 6 AND 7
1394 004572 001157 BNE ISRER ;BRANCH TO ERROR ROUTINE
1395 004574 005714 TST ADCDC ;CHECK COLUMN COUNT
1396 004576 001401 BEQ .+4 ;BRANCH IF OK
1397 004600 104000 HLT ;COLUMN COUNT REGISTER NOT 0
1398
1399 004602 010067 001702 MOV RO, BUFEND
1400 004606 166767 001672 001674 SUB SIZE, BUFEND
1401 004614 166767 001664 001666 SUB SIZE, BUFEND
1402 004622 026715 001662 CMP BUFEND, ADCDA
1403 004626 001401 BEQ .+4
1404 004630 104000 HLT

1405
1406 004632 016767 001646 173662 ISRNC: MOV SIZE, COUNT ;SET UP COLUMN COUNTER
1407 004640 022021 ISRLP: CMP (RO)+, (R1)+ ;TEST THE DATA
1408 004642 001035 BNE ISRDE ;BRANCH IF DATA ERROR
1409 004644 020167 001650 ISRRT: CMP R1, TEND ;CHECK FOR END OF TABLE
1410 004650 100402 BMI .+6 ;BRANCH IF NOT
1411 004652 016701 001640 MOV TSTART, R1 ;MOVE POINTER TO TOP OF TABLE
1412 004656 005267 173640 INC COUNT ;CHECK FOR END OF BUFFER
1413 004662 001412 BEQ ISRBE ;BRANCH IF BUFFER END
1414 004664 005267 001634 INC CLCNT ;KEEP TRACK OF COLUMNS
1415 004670 026727 001630 000120 CMP CLCNT, #120 ;CHECK FOR END OF CARD

```

```

1416 004676 001360          BNE  ISRLP      ;BRANCH IF NOT END OF CARD
1417 004700 004767 001402  JSR  %7      NXCRD  ;INC TO NEXT CARD
1418 004704 005721          TST  (R1)+    ;UPDATE TABLE POINTER FOR NEXT CARD
1419 004706 000754          BR   ISRLP
1420
1421 004710 004767 001372  ISRBE: JSR  %7      NXCRD  ;GO TO NEXT CARD
1422 004714 005721  ISRNX: TST  (R1)+
1423 004716 032767 000004 172644 BIT  #4      SWR    ;CHECK FOR IMAGE MODE ONLY
1424 004724 001002          BNE  ISRNX1   ;BRANCH IF SET
1425 004726 004767 001156  JSR  %7      PAKSET ;SET UP FOR PACKING MODE
1426 004732 000167 001066  ISRNX1: JMP  SRTRN  ;CALCULATE "SIZE" AND RETURN
1427
1428 ;DATA ERROR WAS DETECTED, OUTPUT ERROR PRINTOUT
1429 004736 005767 001560  ISRDE: TST  CDCNT  ;CHECK FOR FIRST CARD
1430 004742 001045          BNE  ISRD2   ;BRANCH IF NOT
1431 004744 005740  ISRD1: TST  -(R0) ;SUB 2 FROM POINTER
1432 004746 005267 001550  INC  CDCNT
1433 004752 022021          CMP  (R0)+, (R1)+ ;TEST THE DATA
1434 004754 001031          BNE  1$      ;BRANCH IF NOT THE SAME
1435 004756 062701 000042  ADD  #42, R1   ;ADD THE MAGIC NUMBER
1436 004762 020167 001532  CMP  R1, TEND ;CHECK FOR RAP AROUND
1437 004766 003402          BLE  2$      ;BRANCH IF NOT
1438 004770 162701 000240  SUB  #240, R1  ;RAP AROUND
1439 004774 026011 000042  2$:  CMP  42(R0), (R1) ;CHECK FOR DOUBLE MATCH
1440 005000 001010          BNE  3$      ;BRANCH IF NOT
1441 005002 162701 000042  SUB  #42, R1   ;SUBTRACT THE MAGIC NUMBER
1442 005006 020167 001504  CMP  R1, TSTART ;CHECK FOR RAP AROUND
1443 005012 003314          BGT  ISRRT   ;BRANCH IF NOT
1444 005014 062701 000240  ADD  #240, R1  ;RAP AROUND
1445 005020 000711          BR   ISRRT   ;GO CHECK REST OF DATA
1446
1447 005022 162701 000042  3$:  SUB  #42, R1   ;SUBTRACT MAGIC NUMBER
1448 005026 020167 001464  CMP  R1, TSTART ;CHECK FOR RAP AROUND
1449 005032 003002          BGT  1$      ;BRANCH IF NOT
1450 005034 062701 000240  ADD  #240, R1  ;RAP AROUND
1451 005040 020167 001454  1$:  CMP  R1, TEND
1452 005044 001337          BNE  ISRD1
1453 005046 016701 001444  MOV  TSTART, R1
1454 005052 005067 001444  CLR  CDCNT
1455 005056 032767 020000 172504 ISRD2: BIT  #20000, SWR ;RESET CARD COUNTER
1456 005064 001015          BNE  ISRD4   ;CK SW13 FOR INHIBIT PRINTOUT
1457 005066 004767 001050  JSR  %7      TYHEAD ;BRANCH IF SET
1458 005072 014167 005456  MOV  -(R1), PRINT1 ;TYPE HEADING, DECK, CDCNT, CLCNT
1459 005076 004767 005506  JSR  %7, PRINTR ;TYPE -(R1) IN OCTAL
1460 005102 000004 013711  TYPE, SPACE ;TYPE LEADING ZERO'S
1461 005106 014067 005442  MOV  -(R0), PRINT1 ;TYPE -(R0) IN OCTAL
1462 005112 004767 005472  JSR  %7, PRINTR ;TYPE LEADING ZERO'S
1463 005116 022021          CMP  (R0)+, (R1)+ ;RESET POINTERS
1464 005120 005767 172444  ISRDE4: TST  SWR   ;CHECK FOR HALT ON ERROR
1465 005124 100001          BPL  .+4     ;BRANCH IF HALT ON ERROR NOT SET
1466 005126 000000          HALT
1467 005130 000645          BR   ISRRT
1468
1469 ;INTERUPT DUE TO SOME KIND OF ERROR
1470 ;THESE ERRORS ARE DESASTEROUS, THEREFORE THE DATA TEST IS RESTARTED
1471 005132 100402  ISRER: BMI  ISRE1  ;BRANCH ON ERROR BIT 15

```





1528	005344	001412			BEO	PSRBE			; BRANCH IF BUFFER END
1529	005346	005267	001152		INC	CLCNT			; KEEP TRACK OF COLUMNS
1530	005352	026727	001146	000120	CMP	CLCNT,	#120		; CHECK FOR END OF CARD
1531	005360	001360			BNE	PSRLP			; BRANCH IF NOT END OF CARD
1532	005362	004767	000720		JSR	%7	NXCRD		; GO TO NEXT CARD
1533	005366	105721			TSTB	(R1)+			; UPDATE TABLE POINTER FOR NEXT CARD
1534	005370	000754			BR	PSRLP			
1535									
1536	005372	004767	000710		PSRBE:	JSR	%7	NXCRD	; GO TO NEXT CARD
1537	005376	105721			PSRNX:	TSTB	(R1)+		
1538	005400	032767	000010	172162		BIT	#10,	SWR	
1539	005406	001014			BNE	PSRNX1			
1540	005410	162767	000240	001100	SUB	#160.,	TSTART		; MOVE TABLE POINTER TO IMAGE TABLE
1541	005416	162767	000120	001074	SUB	#80.,	TEND		
1542	005424	162701	000240		SUB	#160.,	R1		; UPDATE TABLE POINTER
1543	005430	066701	001066		ADD	CDCNT,	R1		; COMPENSATE FOR BYTES
1544	005434	042713	000002		BIC	#2,	QCDS		; CLR PACKING MODE BIT
1545	005440	000167	000360		PSRNX1:	JMP	SRETRN		; CALCULATE "SIZE" AND READ MORE CARDS
1546									
1547									
1548	005444	005767	001052						; DATA ERROR WAS DETECTED, OUTPUT ERROR PRINTOUT
1549	005450	001045			PSRDE:	TST	CDCNT		
1550	005452	105740				BNE	PSRD2		
1551	005454	005267	001042		PSRD1:	TSTB	-(R0)		; SUB 1 FROM POINTER
1552	005460	122021				INC	CDCNT		
1553	005462	001031				CMPB	(R0)+,	(R1)+	; TEST THE DATA
1554	005464	062701	000021			BNE	1\$		; BRANCH IF NOT THE SAME
1555	005470	020167	001024			ADD	#21,	R1	; ADD THE MAGIC NUMBER
1556	005474	003402				CMP	R1,	TEND	; CHECK FOR RAP AROUND
1557	005476	162701	000120			BLE	2\$		; BRANCH IF NOT
1558	005502	126011	000021			SUB	#120,	R1	; RAP AROUND
1559	005506	001010			2\$:	CMPB	21(R0),	(R1)	; CHECK FOR DOUBLE MATCH
1560	005510	162701	000021			BNE	3\$		; BRANCH IF NOT
1561	005514	020167	000776			SUB	#21,	R1	; SUBTRACT THE MAGIC NUMBER
1562	005520	003302				CMP	R1,	TSTART	; CHECK FOR RAP AROUND
1563	005522	062701	000120			BGT	PSRRT		; BRANCH IF NOT
1564	005526	000677				ADD	#120,	R1	; RAP AROUND
1565						BR	PSRRT		; GO CHECK REST OF DATA
1566	005530	162701	000021		3\$:	SUB	#21,	R1	; SUBTRACT MAGIC NUMBER
1567	005534	020167	000756			CMP	R1,	TSTART	; CHECK FOR RAP AROUND
1568	005540	003002				BGT	1\$		; BRANCH IF NOT
1569	005542	062701	000120			ADD	#120,	R1	; RAP AROUND
1570	005546	020167	000746		1\$:	CMP	R1,	TEND	
1571	005552	001337				BNE	PSRD1		
1572	005554	016701	000736			MOV	TSTART,	R1	
1573	005560	005067	000736			CLR	CDCNT		; RESET CARD COUNTER
1574	005564	032767	020000	171776	PSRD2:	BIT	#20000,	SWR	; CK SW13 FOR INHIBIT PRINTOUT
1575	005572	001017				BNE	PSRDE3		; BRANCH IF SET
1576	005574	004767	000342			JSR	%7	TYHEAD	; TYPE HEADING, DECK, CDCNT, CLCNT
1577	005600	000004	013711			TYPE,	SPACE		
1578	005604	114167	004745			MOVB	-(R1),	PRINT1+1	; MOVE BYTE INTO PRINT BUFFER
1579	005610	004767	004754			JSR	%7	PRINTB	; AND PRINT IT
1580	005614	000004	013706			TYPE,	SPACE-3		
1581	005620	114067	004731			MOVB	-(R0),	PRINT1+1	; MOVE BYTE INTO PRINT BUFFER
1582	005624	004767	004740			JSR	%7	PRINTB	; AND PRINT IT
1583	005630	122021				CMPB	(R0)+,	(R1)+	; RESET POINTERS

```

1584 005632 005767 171732 PSRDE3: TST SWR ;CHECK FOR HALT ON ERROR
1585 005636 100001 BPL .+4 ;BRANCH IF HALT ON ERROR NOT SET
1586 005640 000000 HALT ;HALT ON ERROR SET
1587 005642 000631 BR PSRRT
1588
1589 ;INTERUPT DUE TO SOME KIND OF ERROR
1590 005644 100402 PSRER: BMI PSRE1 ;BRANCH ON ERROR BIT 15
1591 005646 104000 HLT ;ERROR BIT 15 NOT SET
1592 005650 000463 BR PSRST
1593
1594 005652 032713 004000 PSRE1: BIT #4000, ACDS
1595 005656 001414 BEQ PSRE2 ;BRANCH IF NOT
1596 005660 032713 000002 BIT #2, ACDS
1597 005664 001001 BNE .+4
1598 005666 104000 HLT
1599 005670 032767 000020 171672 BIT #20, SWR
1600 005676 001001 BNE .+4 ;BRANCH IF BINARY DECK
1601 005700 104000 HLT
1602 005702 012767 177660 172612 MOV #-120, COUNT ;ONLY READ ONE CARD
1603 005710 032713 010000 PSRE2: BIT #10000, ACDS ;CHECK FOR OFF-LINE
1604 005714 001415 BEQ PSRE3
1605 005716 032713 040000 BIT #40000, ACDS ;CHECK FOR CARD READER ERROR
1606 005722 001002 BNE .+6 ;BRANCH IF SET
1607 005724 104000 HLT ;OFF-LINE BUT NOT CARD READER ERROR
1608 005726 000414 BR PSRE4
1609
1610 005730 004767 000312 JSR %7, LASTCD ;CHECK FOR LAST CARD
1611 005734 002402 BLT 15 ;BRANCH IF NOT
1612 005736 000167 177352 JMP PSRNC ;BRANCH IF BOTH CARD
1613 005742 104000 15: HLT ;CARD READER ERROR BUT NOT BOTH CARD
1614 005744 000167 000526 JMP DATRST ;RESTART THE ENTIRE TEST
1615
1616 005750 032713 040000 PSRE3: BIT #40000, ACDS ;CHECK FOR CARD READER ERROR
1617 005754 001401 BEQ .+4 ;BRANCH IF NOT
1618 005756 104000 HLT ;CARD READER ERROR BUT NOT OFF LINE
1619
1620 005760 032713 020000 PSRE4: BIT #20000, ACDS
1621 005764 001401 BEQ .+4
1622 005766 104000 HLT ;END OF FILE ERROR (M1200 ONLY)
1623
1624 005770 032713 002000 BIT #2000, ACDS
1625 005774 001401 BEQ .+4
1626 005776 104000 HLT ;DATA LATE ERROR
1627
1628 006000 032713 001000 BIT #1000, ACDS
1629 006004 001401 BEQ .+4
1630 006006 104000 HLT ;NON-EXISTANT MEMORY ERROR
1631 006010 032713 077000 BIT #077000, ACDS ;CHECK ALL ERROR BITS
1632 006014 001001 BNE .+4 ;BRANCH IF AT LEAST ONE
1633 006016 104000 HLT ;NONE OF THE ERROR BITS SET
1634 006020 000167 177276 PSRST: JMP PSRLP ;GO CHECK THE DATA
1635
1636 ;RETURN PORTION OF INTERUPT SERVICE ROUTINE
1637 ;CALCULATES A NEW "SIZE" (NUMBER OF COLUMNS TO BE READ)
1638 ;SETS UP THE CARD READER BUFFERS, AND ISSUES THE READ COMMAND
1639 ;THEN DOES AN RTI TO THE BACKGROUND ROUTINE

```

1640	006024	066767	000456	000452	SRETRN:	ADD	OFFSET,	SIZE		
1641	006032	100404				BMI	SRETR1			
1642	006034	012767	177660	000444		MOV	#-120,	OFFSET		
1643	006042	000770				BR	SRETRN			
1644	006044	032767	001000	000432	SRETR1:	BIT	#001000,	SIZE		
1645	006052	001004				BNE	SRETR4			
1646	006054	012767	000120	000424	SRETR3:	MOV	#120,	OFFSET		
1647	006062	000760				BR	SRETRN			
1648	006064	004767	000156		SRETR4:	JSR	%7,	LASTCD	:CHECK FOR MORE THAN 80 CARDS	
1649	006070	003371				BGT	SRETR3		:BRANCH IF GREATER	
1650	006072	016714	000406			MOV	SIZE,	QCDC	:SET UP COLUMN COUNT	
1651	006076	012700	016000			MOV	#BUFBEQ,	RO	:RESET TABLE POINTER	
1652	006102	010015				MOV	RO,	QCDA	:SET UP ADDRESS REG	
1653	006104	005213				INC	QCDS		:READ	
1654	006106	000002				RTI				
1655										
1656										
1657										
1658	006110	062767	000240	000400						
1659	006116	062767	000120	000374	PAKSET:	ADD	#160.,	TSTART	:MOVE TABLE POINTER TO PACKED TABLE	
1660	006124	062701	000240			ADD	#80.,	TEND		
1661	006130	166701	000366			ADD	#160.,	R1	:UPDATE TABLE POINTER	
1662	006134	052713	000002			SUB	CDCNT,	R1	:COMPENSATE FOR BYTES	
1663	006140	000207				BIS	#2,	QCDS	:SET PACKING MODE BIT	
1664						RTS	%7			
1665										
1666	006142	005767	172364							
1667	006146	001004								
1668	006150	005267	172356							
1669	006154	000004	015047							
1670	006160	000004								
1671	006162	000000								
1672	006164	000004	013711							
1673	006170	005267	000326							
1674	006174	016767	000322	004352						
1675	006202	004767	004402							
1676	006206	005367	000310							
1677	006212	000004	013711							
1678	006216	005267	000302							
1679	006222	016767	000276	004324						
1680	006230	004767	004354							
1681	006234	005367	000264							
1682	006240	000004	013711							
1683	006244	000207								
1684										
1685										
1686	006246	016767	000232	000236						
1687	006254	016767	000242	000232						
1688	006262	005267	000226							
1689	006266	062767	000120	000216						
1690	006274	100772								
1691	006276	026727	000212	000120						
1692	006304	000207								
1693										
1694										
1695	006306	005067	000212							

```

;SUBROUTINE TO SET PACKING MODE AND MOVE THE POINTERS FOR THE DATA.
PAKSET: ADD #160., TSTART ;MOVE TABLE POINTER TO PACKED TABLE
        ADD #80., TEND
        ADD #160., R1 ;UPDATE TABLE POINTER
        SUB CDCNT, R1 ;COMPENSATE FOR BYTES
        BIS #2, QCDS ;SET PACKING MODE BIT
        RTS %7
    
```

```

;SUBROUTINE TO TYPE HEADING, TYPE OF DECK, CARD COUNT, AND COLUMN COUNT
TYHEAD: TST ERFLG ;CHECK FOR FIRST ERROR
        BNE NOHEAD ;BRANCH IF NOT
        INC ERFLG ;SET FLAG
        TYPE, MSG13 ;TYPE HEADING FOR DATA ERRORS
        NOHEAD: TYPE ;OUTPUT TYPE OF DECK
        DECK: DUMMY ;POINTER TO DECK TITLE
        TYPE, SPACE
        INC CDCNT ;ADJUST CADR COUNT
        MOV CDCNT, PRINT1 ;TYPE CDCNT IN OCTAL
        JSR %7, PRINTR ;TYPE LEADING ZERO'S
        DEC CDCNT ;READJUST CADR COUNT
        TYPE, SPACE
        INC CLCNT ;ADJUST COLUMN COUNT
        MOV CLCNT, PRINT1 ;TYPE CLCNT IN OCTAL
        JSR %7, PRINTR ;TYPE LEADING ZERO'S
        DEC CLCNT ;READJUST COLUMN COUNT
        TYPE, SPACE
        RTS %7
    
```

```

;SUBROUTINE TO CHECK FOR LAST CARD
LASTCD: MOV SIZE, TEMP1
        MOV CDCNT, TEMP2
        LSTCD1: INC TEMP2
        ADD #120, TEMP1
        BMI LSTCD1
        CMP TEMP2, #80.
        RTS %7
    
```

```

;SUBROUTINE TO KEEP TRACK OF CARDS
NXCRD: CLR CLCNT ;RESET COLUMN COUNT
    
```

# K03

MAINDEC-11-DZCDA-C-D  
DZCDAC.P11

CD11 CARD READER DIAGNOSTICS  
DATA RELIABILITY TEST

MACY11 27(732) 15-OCT-76 16:01 PAGE 37

1696	006312	005267	000204		INC	CDCNT			;KEEP TRACK OF CARDS
1697	006316	026727	000200	000120	CMP	CDCNT	#120		;CHECK FOR BOTH CARD
1698	006324	002001			BGE	ALLDON			
1699	006326	000207			RTS	%7			;RETURN
1700									
1701	006330	005726			ALLDON: TST	(6)+			;CORRECT STACK POINTER TO REPLACE RTS
1702	006332	022626			CMP	(6)+	(6)+		;CORRECT STACK POINTER TO REPLACE RTI
1703	006334	004767	003622		JSR	%7, BELL			;RING BELL
1704	006340	013700	000042		MOV	#42	%0		;LOAD CONTENTS OF SOFT VECTOR 42
1705	006344	001405			BEQ	HOOK1			;BRANCH IF NO HOOK
1706	006346	000005			RESET				;CLEAR ALL I/O
1707	006350	004710			JSR	%7,	(R0)		;RETURN TO MONITOR
1708	006352	000240			NOP				
1709	006354	000240			NOP				
1710	006356	000240			NOP				
1711	006360	032767	000040	171202	HOOK1: BIT	#40, SWR			;CHECK SWR FOR HALT AT END OF DECK
1712	006366	001402			BEQ	ONLINE			;CONTINUE IF NOT SET
1713	006370	000000			HALT				;END OF DECK, SW5 SET
1714	006372	000427			BR	DECKCK			
1715									
1716	006374	032713	010000		ONLINE: BIT	#10000, ACDS			;CHECK FOR OFF-LINE
1717	006400	001424			BEQ	DECKCK			;BRANCH IF NOT
1718	006402	005713			TST	ACDS			;CHECK FOR ERROR (BIT 15)
1719	006404	100401			BMI	+.4			;BRANCH IF SET OK
1720	006406	104000			HLT				;ERROR BIT 15 NOT SET
1721									
1722	006410	032713	040000		BIT	#40000, ACDS			;CHECK FOR CARD READER ERROR
1723	006414	001001			BNE	+.4			;BRANCH IF SET OK
1724	006416	104000			HLT				;OFF-LINE NOT DUE TO CARD READER ERROR
1725									
1726	006420	032713	023471		BIT	#023471, ACDS			;CHECK FOR EXTRA BITS SET
1727	006424	001401			BEQ	+.4			;BRANCH IF OK
1728	006426	104000			HLT				;EXTRA ERROR BITS SET
1729									
1730	006430	012712	006440		MOV	#ONINT, ADINT			;SET UP INTERRUPT VECTOR
1731	006434	000001			WAIT				;WAIT FOR AN INTERRUPT
1732	006436	000776			BR	.-2			;WAIT ON TRACE TRAPS
1733									
1734	006440	032713	000010		ONINT: BIT	#10, ACDS			;CHECK FOR TRANSITION TO ON LINE
1735	006444	001001			BNE	+.4			;BRANCH IF SET OK
1736	006446	104000			HLT				;INTERUPT BY OTHER THAN BIT 3 SETTING
1737									
1738	006450	022626			CMP	(SP)+, (SP)+			;RESTORE THE STACK
1739					;WHEN CONTINUING FROM ONE DECK TO ANOTHER, CHECK SW6 FOR TYPE				
1740					;OF TESTING TO BE PERFORMED				
1741	006452	005167	172050		DECKCK: COM	TRFLG			;TOGGLE TRACE FLAG
1742	006456	032767	000100	171104	BIT	#100, SWR			;CHECK SW6
1743	006464	001402			BEQ	+.6			;BRANCH IF NOT SET
1744	006466	000167	172322		JMP	RETRST			;RERUN COMBINED INSTRUCTION AND DATA TEST
1745	006472	000167	175564		JMP	DATST			
1746									
1747	006476	022626			DATRST: CMP	(SP)+, (SP)+			;RESTORE THE STACK
1748	006500	000167	175556		JMP	DATST			;RESTART DATA TEST
1749									
1750	006504	177660			SIZE:	-120			
1751	006506	177660			OFFSET:	-120			

1752	006510	000000
1753	006512	000000
1754	006514	000000
1755	006516	000000
1756	006520	000000
1757	006522	000000
1758	006524	000000
1759	006526	000000
1760	006530	000000

BUFEND:	0
TEMP1:	00
TEMP2:	00
TSTART:	00
TEND:	00
CDCNT:	00
CLCNT:	00
PTOFF:	00
DERCNT:	0

: STARTING ADDRESS OF DATA TABLE  
: END ADDRESS OF DATA TABLE  
: NUMBER OF CARD BEING READ  
: NUMBER OF COLUMN BEING CHECKED  
: OFFSET TO POINTER FOR DATA PRINTOUT  
: DATA ERROR COLUMN COUNT

```

1761
1762
1763 006532 005067 172002
1764 006536 000167 000006
1765 006542 012767 177777 171770
1766 006550 004767 171766
1767 006554 012767 006570 003652
1768 006562 005067 003642
1769
1770
1771
1772
1773 006566 104400
1774 006570 004767 003340
1775 006574 000004 013717
1776 006600 000004 015417
1777 006604 000004 015462
1778 006610 000004 015545
1779 006614 000004 015606
1780 006620 000004 015655
1781 006624 000004 013714
1782 006630 012714 177701
1783 006634 012715 016000
1784 006640 000000
1785 006642 005213
1786 006644 105713
1787 006646 001001
1788 006650 104000
1789
1790 006652 005713
1791 006654 001001
1792 006656 104000
1793
1794 006660 032713 002000
1795 006664 001001
1796 006666 104000
1797
1798 006670 032713 075577
1799 006674 001401
1800 006676 104000
1801
1802
1803
1804
1805 006700 104400
1806 006702 004767 003226
1807 006706 000004 014023
1808 006712 000004 013756
1809 006716 000004 013714
1810 006722 000000
1811 006724 032713 010000
1812 006730 001001
1813 006732 104000
1814
1815 006734 005713
1816 006736 100401

;SETUP FOR ERROR FUNCTION TEST
ER1200: CLR CD1000 ;CARD READER IS M-1200
        JMP ER12CD
ERCD11: MOV #177777, CD1000 ;CARD READER IS M1000
ER12CD: JSR %7, SETUP ;INITIALIZE REGISTERS
        MOV #TESTA+2, RETURN ;SETUP SCOPE LOOP RETURN ADDRESS
        CLR ITMAX ;RUN EACH ERROR TEST ONCE ONLY

;HALT SHOULD CAUSE DATA LATE ERROR (BIT 10)
;SHOULD SET ERROR (BIT 15)
TESTA: SCOPE
        JSR %7, INIT ;INITIALIZE STATUS REGISTER
        TYPE, CRLF
        TYPE, MSG22 ;"WHEN PRINTING STOPS PUT HALT AND
        TYPE, MSG23 ;SINGLE BUS CYCLE DOWN, AND HIT 'CONTINUE' ON THE
        TYPE, MSG24 ;CONSOLE UNTIL ONE CARD IS READ
        TYPE, MSG25 ;THEN PUT UP THE TWO SWITCHES AND HIT
        TYPE, MSG26 ;'CONTINUE' ON THE CONSOLE
        MOV #-77, @CDC ;MOVE MESSAGE UP ON TTY
        MOV #BUFBEQ, @CDA ;SET UP COLUMN COUNT
        HALT ;SET UP BUS ADDRESS
        INC @CDS ;START READING
        TSTB @CDS ;CHECK FOR CONTROLLER READY
        BNE .+4 ;BRANCH IF SET OK
        HLT ;CONTROLLER READY FAILED TO SET

        TST @CDS ;CHECK FOR ERROR ( BIT 15)
        BNE .+4 ;BRANCH IF SET OK
        HLT ;ERROR BIT 15 NOT SET

        BIT #2000, @CDS ;CHECK FOR DATA LATE ERROR (BIT 10)
        BNE .+4 ;BRANCH IF SET OK
        HLT ;DATA LATE BIT 10 NOT SET

        BIT #075577, @CDS ;CHECK FOR ANY OTHER BITS
        BEQ .+4 ;BRANCH IF OK
        HLT ;EXTRA BITS SET IN STATUS WORD

;THE CARD READER GOING OFF-LINE SHOULD SET ERROR (BIT 15)
;AND OFF-LINE (BIT 12)
;GOING BACK ON LINE SHOULD SET "TRANSITION TO ON-LINE" (BIT 3)
TESTB: SCOPE
        JSR %7, INIT ;INITIALIZE STATUS REGISTER
        TYPE, MSG3 ;"PRESS CARD READER 'STOP'"
        TYPE, MSG2 ;"THEN HIT 'CONTINUE' ON THE CONSOLE"
        TYPE, CRLF-3 ;MOVE MESSAGE UP ON TTY
        HALT
        BIT #10000, @CDS ;CHECK BIT 12
        BNE .+4 ;BRANCH IF SET
        HLT ;OFF-LINE (BIT 12) WASN'T SET

        TST @CDS ;CHECK BIT 15
        BMI .+4 ;BRANCH IF SET
    
```

```

1817 006740 104000 HLT ;ERROR (BIT 15) WASN'T SET
1818
1819 006742 031327 067577 BIT ;CHECK FOR EXTRA BITS
1820 006746 001401 BEQ .+4 ;BRANCH IF OK
1821 006750 104000 HLT ;STATUS WORD ERROR
1822
1823 006752 000004 013722 TYPE, MSG1 ;"PRESS CARD READER 'RESET'";
1824 006756 000004 013756 TYPE, MSG2 ;"THEN HIT 'CONTINUE' ON THE CONSOLE"
1825 006762 000004 013714 TYPE, CRLF-3 ;MOVE MESSAGE UP ON TTY
1826 006766 000000 HALT
1827
1828 006770 032713 000010 BIT #10, ;CHECK FOR TRANSITION TO ON-LINE(BIT 3)
1829 006774 001001 BNE .+4 ;BRANCH IF SET OK
1830 006776 104000 HLT ;TRANSITION TO ON-LINE FAILED TO SET
1831
1832 007000 032713 010000 BIT #10000, ;CHECK FOR OFF-LINE
1833 007004 001401 BEQ .+4 ;BRANCH IF OK
1834 007006 104000 HLT ;OFF-LINE STILL SET
1835
1836 007010 005713 TST ;CHECK ERROR (BIT 15)
1837 007012 100401 BMI .+4 ;BRANCH IF STILL SET
1838 007014 104000 HLT ;ERROR BIT 15 CLEARED
1839
1840 007016 032713 077567 BIT #077567, ;CHECK FOR EXTRA BITS
1841 007022 001401 BEQ .+4 ;BRANCH IF OK
1842 007024 104000 HLT ;EXTRA STATUS BITS SET
1843
1844 ; TRYING TO READ WHEN CARD READER IS OFF-LINE SHOULD CAUSE AN INTERRUPT
1845 ; CHECK THAT AN INTERRUPT OCCURS WHEN THE CARD READER COMES ON LINE
1846 007026 104400 TESTC: SCOPE
1847 007030 004767 003100 JSR %7, INIT ; INITIALIZE STATUS REGISTER
1848 007034 012712 007106 MOV #TINTC, ; LOAD RETURN POINTER
1849 007040 052767 000340 170730 MOV #340, ; SET PROCESSOR TO LEVEL 7
1850 007046 016762 170724 000002 MOV PS, 2(ADINT) ; LOAD RETURN PROCESSOR STATUS
1851 007054 042767 000340 170714 BIC #340, ; SET PROSSOR PRIORITY TO 0
1852 007062 012713 000100 MOV #100, ; SET INTERRUPT ENABLE
1853 007066 000004 014023 TYPE, MSG3 ; "PRESS CARD READER 'STOP'"
1854 007072 000004 013714 TYPE, CRLF-3 ; MOVE MESSAGE UP ON TTY
1855 007076 032713 010000 TLOPC: BIT #10000, ; WAIT FOR OFF-LINE TO SET
1856 007102 001775 BEQ TLOPC
1857 007104 000402 BR CONTC ; SKIP INTERUPT HANDLER
1858
1859 007106 104000 TINTC: HLT ; 'STOP' SHOULDN'T CAUSE AN INTERUPT
1860 007110 000002 RTI ; RETURN FROM THE INTERUPT
1861
1862 007112 105713 CONTC: TSTB ; CHECK CONTROLLER READY BIT 7
1863 007114 100401 BMI .+4 ; BRANCH IF OK
1864 007116 104000 HLT ; CU READY DIDN'T SET YET
1865
1866 007120 005713 TST ; CHECK ERROR BIT
1867 007122 100401 BMI .+4 ; BRANCH IF SET
1868 007124 104000 HLT ; ERROR (BIT 15) NOT SET
1869
1870 007126 032713 067477 BIT #067477, ; CHECK FOR EXTRA BITS
1871 007132 001401 BEQ .+4 ; BRANCH IF OK
1872 007134 104000 HLT ; STATUS WORD ERROR

```



```

1873
1874 007136 012712 007170      MOV      #TINTCA,ADINT  ;LOAD RETURN POINTER
1875 007142 052767 000340 170626  BIS      #340, PS      ;SET PROCESSOR TO LEVEL 7
1876 007150 016762 170622 000002  MOV      PS, 2(ADINT) ;LOAD RETURN PROCESSOR STATUS
1877 007156 042767 000340 170612  BIC      #340, PS      ;SET PROSSOR PRIORITY TO 0
1878 007164 005213      INC      @CDS          ;TRY TO READ A CARD
1879 007166 000777      BR       .             ;WAIT FOR THE INTERUPT
1880
1881 007170 022626      TINTCA: CMP     (SP)+, (SP)+ ;RESTORE THE STACK
1882 007172 105713      TSTB    @CDS          ;CHECK CONTROLLER READY BIT 7
1883 007174 100401      BMI     .+4           ;BRANCH IF OK
1884 007176 104000      HLT     .             ;CU READY DIDN'T SET YET
1885
1886 007200 032713 010000      BIT     #10000, @CDS  ;CHECK FOR OFF-LINE BIT 12
1887 007204 001001      BNE     .+4           ;BRANCH IF OK
1888 007206 104000      HLT     .             ;OFF-LINE BIT 12 NOT SET
1889
1890 007210 005713      TST     @CDS          ;CHECK ERROR BIT
1891 007212 100401      BMI     .+4           ;BRANCH IF SET
1892 007214 104000      HLT     .             ;ERROR (BIT 15) NOT SET
1893
1894 007216 032713 067477      BIT     #067477,@CDS ;CHECK FOR EXTRA BITS
1895 007222 001401      BEQ     .+4           ;BRANCH IF OK
1896 007224 104000      HLT     .             ;STATUS WORD ERROR
1897
1898 007226 012712 007266      MOV      #TINTCB,ADINT ;LOAD RETURN POINTER
1899 007232 052767 000340 170536  BIS      #340, PS      ;SET PROCESSOR TO LEVEL 7
1900 007240 016762 170532 000002  MOV      PS, 2(ADINT) ;LOAD RETURN PROCESSOR STATUS
1901 007246 042767 000340 170522  BIC      #340, PS      ;SET PROSSOR PRIORITY TO 0
1902 007254 000004 013722      TYPE,   MSG1          ;"PRESS CARD READER 'RESET'"
1903 007260 000004 013714      TYPE,   CRLF-3        ;MOVE MESSAGE UP ON TTY
1904 007264 000777      BR       .             ;WAIT FOR THE INTERUPT
1905
1906 007266 022626      TINTCB: CMP     (SP)+, (SP)+ ;RESTORE THE STACK
1907 007270 032713 000010      BIT     #10, @CDS     ;CHECK FOR TRANSITION TO ON-LINE(BIT 3)
1908 007274 001001      BNE     .+4           ;BRANCH IF SET OK
1909 007276 104000      HLT     .             ;TRANSITION TO ON-LINE FAILED TO SET
1910
1911 007300 032713 010000      BIT     #10000, @CDS  ;CHECK FOR OFF-LINE
1912 007304 001401      BEQ     .+4           ;BRANCH IF OK
1913 007306 104000      HLT     .             ;OFF-LINE STILL SET
1914
1915 007310 005713      TST     @CDS          ;CHECK ERROR (BIT 15)
1916 007312 100401      BMI     .+4           ;BRANCH IF STILL SET
1917 007314 104000      HLT     .             ;ERROR BIT 15 CLEARED
1918
1919 007316 032713 077467      BIT     #077467,@CDS ;CHECK FOR EXTRA BITS
1920 007322 001401      BEQ     .+4           ;BRANCH IF OK
1921 007324 104000      HLT     .             ;EXTRA STATUS BITS SET
1922
1923      ;INPUT HOPPER EMPTY SHOULD SET SPECIAL CONDITION
1924      ;CHECK THAT INTERRUPTS OCCUR WHEN THE CARD READER COMES ON LINE
1925 007326 104400      TESTD: SCOPE
1926 007330 004767 002600      JSR     %7,INIT       ;INITIALIZE STATUS REGISTER
1927 007334 000004 014111      TYPE,   MSG5          ;"REMOVE ALL CARDS FROM THE INPUT HOPPER"
1928 007340 000004 013756      TYPE,   MSG2          ;"THEN HIT 'CONTINUE' ON THE CONSOLE"

```

1929	007344	000004	013714		TYPE,	CRLF-3		;MOVE MESSAGE UP ON TTY
1930	007350	000000			HALT			
1931	007352	032713	010000		BIT	#10000, QCD		;CHECK BIT12
1932	007356	001001			BNE	.+4		;BRANCH IF SET
1933	007360	104000			HLT			;OFF-LINE (BIT 12) WASN'T SET
1934								
1935	007362	005713			TST	QCD		;CHECK ERROR BIT
1936	007364	100401			BMI	.+4		;BRANCH IF SET
1937	007366	104000			HLT			;ERROR (BIT 15) NOT SET
1938								
1939	007370	032713	040000		BIT	#40000, QCD		;CHECK FOR CARD READER ERROR
1940	007374	001001			BNE	.+4		;BRANCH IF SET
1941	007376	104000			HLT			;CARD READER ERROR BIT 14 NOT SET
1942								
1943	007400	032713	027573		BIT	#027573, QCD		;CHECK FOR EXTRA BITS
1944	007404	001401			BEQ	.+4		;BRANCH IF OK
1945	007406	104000			HLT			;STATUS WORD ERROR
1946								
1947	007410	012712	007460		MOV	#TINTD, QADINT		;LOAD RETURN POINTER
1948	007414	052767	000340	170354	BIS	#340, PS		;SET PROCESSOR TO LEVEL 7
1949	007422	016762	170350	000002	MOV	PS, 2(ADINT)		;LOAD RETURN PROCESSOR STATUS
1950	007430	042767	000340	170340	BIC	#340, PS		;SET PROSSOR PRIORITY TO 0
1951	007436	012713	000100		MOV	#100, QCD		;SET INTERRUPT ENABLE
1952	007442	000004	014162		TYPE,	MSG6		; "RESTORE CARDS TO THE INPUT HOPPER"
1953	007446	000004	013722		TYPE,	MSG1		; "PRESS CARD READER 'RESET'"
1954	007452	000004	013714		TYPE,	CRLF-3		;MOVE MESSAGE UP ON TTY
1955	007456	000777			BR	.		;WAIT FOR THE INTERUPT
1956								
1957	007460	022626			TINTD:	CMP (SP)+, (SP)+		;RESTORE THE STACK
1958	007462	012712	007524		MOV	#TINTDA, QADINT		;LOAD RETURN POINTER
1959	007466	052767	000340	170302	BIS	#340, PS		;SET PROCESSOR TO LEVEL 7
1960	007474	016762	170276	000002	MOV	PS, 2(ADINT)		;LOAD RETURN PROCESSOR STATUS
1961	007502	042767	000340	170266	BIC	#340, PS		;SET PROSSOR PRIORITY TO 0
1962	007510	012714	177701		MOV	#-77, QCD		;SET UP COLUMN COUNT
1963	007514	012715	016000		MOV	#BUFBEG, QCD		;SET UP BUS ADDRESS
1964	007520	005213			INC	QCD		;START READING
1965	007522	000777			BR	.		;WAIT FOR AN INTERUPT
1966								
1967	007524	022626			TINTDA:	CMP (SP)+, (SP)+		;RESTORE THE STACK
1968	007526	022713	000300		CMP	#000300, QCD		;CHECH THE CARD READER STATUS
1969	007532	001401			BEQ	.+4		;BRANCH IF OK
1970	007534	104000			HLT			;CARD READER STATUS ERROR
1971								
1972					:OUTPUT	STACKER FULL SHOULD SET BITS 15, 14, 12, 7		
1973	007536	104400			TESTE:	SCOPE		
1974	007540	004767	002370		JSR	%7, INIT		;INITIALIZE STATUS REGISTER
1975	007544	000004	014226		TYPE,	MSG7		; "PULL OUTPUT STACKER PRESSURE ARM
1976								; ALL THE WAY DOWN"
1977	007550	000004	013756		TYPE,	MSG2		; "THEN HIT 'CONTINUE' ON THE CONSOLE"
1978	007554	000004	013714		TYPE,	CRLF-3		;MOVE MESSAGE UP ON TTY
1979	007560	000000			HALT			
1980	007562	032713	010000		BIT	#10000, QCD		;CHECK OFF-LINE BIT12
1981	007566	001001			BNE	.+4		;BRANCH IF SET
1982	007570	104000			HLT			;OFF-LINE (BIT 12) WASN'T SET
1983								
1984	007572	005713			TST	QCD		;CHECK ERROR BIT 15

1985	007574	100401			BMI	.+4		:BRANCH IF SET
1986	007576	104000			HLT			:ERROR BIT 15 NOT SET
1987								
1988	007600	032713	040000		BIT	#40000, ACDS		:CHECK FOR CARD READER ERROR
1989	007604	001001			BNE	.+4		:BRANCH IF SET
1990	007606	104000			HLT			:CARD READER ERROR BIT 14 NOT SET
1991								
1992	007610	032713	027577		BIT	#027577, ACDS		:CHECK FOR EXTRA BITS
1993	007614	001401			BEQ	.+4		:BRANCH IF OK
1994	007616	104000			HLT			:STATUS WORD ERROR
1995								
1996	007620	012712	007664		MOV	#TINTE, ADINT		:LOAD RETURN POINTER
1997	007624	052767	000340	170144	BIS	#340, PS		:SET PROCESSOR TO LEVEL 7
1998	007632	016762	170140	000002	MOV	PS, 2(ADINT)		:LOAD RETURN PROCESSOR STATUS
1999	007640	042767	000340	170130	BIC	#340, PS		:SET PROSSOR PRIORITY TO 0
2000	007646	012713	000100		MOV	#100, ACDS		:SET INTERRUPT ENABLE
2001	007652	000004	013722		TYPE,	MSG1		: "PRESS CARD READER 'RESET'"
2002	007656	000004	013714		TYPE,	CRLF-3		:MOVE MESSAGE UP ON TTY
2003	007662	000777			BR	.		:WAIT FOR THE INTERUPT
2004								
2005	007664	022626			TINTE: CMP	(SP)+ (SP)+		:RESTORE THE STACK
2006	007666	012712	007730		MOV	#TINTEA, ADINT		:LOAD RETURN POINTER
2007	007672	052767	000340	170076	BIS	#340, PS		:SET PROCESSOR TO LEVEL 7
2008	007700	016762	170072	000002	MOV	PS, 2(ADINT)		:LOAD RETURN PROCESSOR STATUS
2009	007706	042767	000340	170062	BIC	#340, PS		:SET PROSSOR PRIORITY TO 0
2010	007714	012714	177701		MOV	#-77, ACDC		:SET UP COLUMN COUNT
2011	007720	012715	016000		MOV	#BUFBEG, ACDA		:SET UP BUS ADDRESS
2012	007724	005213			INC	ACDS		:START READING
2013	007726	000777			BR	.		:WAIT FOR AN INTERUPT
2014								
2015	007730	022626			TINTEA: CMP	(SP)+ (SP)+		:RESTORE THE STACK
2016	007732	022713	000300		CMP	#000300, ACDS		:CHECK THE CARD READER STATUS
2017	007736	001401			BEQ	.+4		:BRANCH IF OK
2018	007740	104000			HLT			:CARD READER STATUS ERROR
2019								
2020								
2021								
2022								
2023	007742	104400			TESTF: SCOPE			
2024	007744	004767	002164		JSR	%7, INIT		
2025	007750	000004	014111		TYPE,	MSG5		: "REMOVE ALL CARDS FROM THE INPUT HOPPER"
2026	007754	000004	013756		TYPE,	MSG2		: "THEN HIT 'CONTINUE' ON THE CONSOLE"
2027	007760	000004	014330		TYPE,	MSG8		: "HOLD DOWN THE SWITCH UNDER THE CAP
2028								: OF THE INPUT HOPPER"
2029	007764	000004	013722		TYPE,	MSG1		: "PRESS CARD READER 'RESET'"
2030	007770	000004	013714		TYPE,	CRLF-3		:MOVE MESSAGE UP ON TTY
2031	007774	000000			HALT			
2032	007776	032713	010000		BIT	#10000, ACDS		:CHECK FOR OFF-LINE
2033	010002	001001			BNE	.+4		:BRANCH IF SET
2034	010004	104000			HLT			:OFF LINE NOT SET AFTER "CONTINUE"
2035								
2036	010006	032713	000010		BIT	#10, ACDS		:CHECK FOR "TRANSITION TO ON LINE"
2037	010012	001775			BEQ	.-4		:WAIT FOR IT
2038	010014	022713	140210		CMP	#140210, ACDS		:CHECK FOR CORRECT STATUS BITS
2039	010020	001401			BEQ	.+4		:BRANCH IF OK
2040	010022	104000			HLT			:STATUS NOT EQUAL TO 140210

:A PICK CHECK ERROR SHOULD SET BIT 15, BIT 14, AND BIT 12  
 :THIS ERROR OCCURS WHEN THE FEED MECHANISM FAILS TO DELIVER A CARD TO  
 :THE READ STATION WITHIN 400 MS.

# E04

MAINDEC-11-DZCDA-C-D  
DZCDAC.P11

CD11 CARD READER DIAGNOSTICS  
ERROR FUNCTION TESTS

MACY11 27(732) 15-OCT-76 16:01 PAGE 44

```

2041
2042 010024 012714 177701      MOV      #-77,  @CDC      ;SET UP COLUMN COUNT
2043 010030 012715 016000      MOV      #BUFBEG,@CDA    ;SET UP BUS ADDRESS
2044 010034 005213              INC      @CDS            ;READ
2045 010036 105713              TSTB    @CDS            ;CHECK CONTROLLER READY
2046 010040 100376              BPL     .-2             ;WAIT FOR CONTROLLER READY
2047 010042 032713 010000      BIT     #10000,@CDS     ;CHECK BIT12
2048 010046 001001              BNE     .+4             ;BRANCH IF SET
2049 010050 104000              HLT                                     ;OFF-LINE (BIT 12) WASN'T SET
2050
2051 010052 005713              TST     @CDS            ;CHECK SPECIAL CONDITION BIT
2052 010054 100401              BMI     .+4             ;BRANCH IF SET
2053 010056 104000              HLT                                     ;SPECIAL CONDITION NOT SET
2054
2055 010060 032713 040000      BIT     #40000, @CDS    ;CHECK FOR CARD READER ERROR
2056 010064 001001              BNE     .+4             ;BRANCH IF SET
2057 010066 104000              HLT                                     ;CARD READER ERROR BIT 14 NOT SET
2058
2059 010070 031327 027577      BIT     @CDS,#027577   ;CHECK FOR EXTRA BITS
2060 010074 001401              BEQ     .+4             ;BRANCH IF OK
2061 010076 104000              HLT                                     ;STATUS WORD ERROR
2062
2063 010100 012712 010150      MOV     #TINTF, @ADINT  ;LOAD RETURN POINTER
2064 010104 052767 000340 167664  BIS     #340, PS        ;SET PROCESSOR TO LEVEL 7
2065 010112 016762 167660 000002  MOV     PS, 2(@ADINT)   ;LOAD RETURN PROCESSOR STATUS
2066 010120 042767 000340 167650  BIC     #340, PS        ;SET PROSSOR PRIORITY TO 0
2067 010126 012713 000100      MOV     #100, @CDS     ;SET INTERRUPT ENABLE
2068 010132 000004 014162      TYPE,  MSG6            ;"RESTORE CARDS TO THE INPUT HOPPER"
2069 010136 000004 013722      TYPE,  MSG1            ;"PRESS CARD READER 'RESET'"
2070 010142 000004 013714      TYPE,  CRLF-3          ;MOVE MESSAGE UP ON TTY
2071 010146 000777              BR      .               ;WAIT FOR THE INTERUPT
2072
2073 010150 022626              TINTF:  CMP     (SP)+, (SP)+ ;RESTORE THE STACK
2074 010152 012712 010214      MOV     #TINTFA,@ADINT ;LOAD RETURN POINTER
2075 010156 052767 000340 167612  BIS     #340, PS        ;SET PROCESSOR TO LEVEL 7
2076 010164 016762 167606 000002  MOV     PS, 2(@ADINT)   ;LOAD RETURN PROCESSOR STATUS
2077 010172 042767 000340 167576  BIC     #340, PS        ;SET PROSSOR PRIORITY TO 0
2078 010200 012714 177701      MOV     #-77, @CDC     ;SET UP COLUMN COUNT
2079 010204 012715 016000      MOV     #BUFBEG,@CDA   ;SET UP BUS ADDRESS
2080 010210 005213              INC     @CDS            ;START READING
2081 010212 000777              BR      .               ;WAIT FOR AN INTERUPT
2082
2083 010214 022626              TINTFA: CMP     (SP)+, (SP)+ ;RESTORE THE STACK
2084 010216 022713 000300      CMP     #000300,@CDS   ;CHECH THE CARD READER STATUS
2085 010222 001401              BEQ     .+4             ;BRANCH IF OK
2086 010224 104000              HLT                                     ;CARD READER STATUS ERROR
2087
2088 ;A STACK CHECK ERROR SHOULD SET BIT 15, BIT 14, AND BIT 12
2089 ;THIS ERROR OCCURS WHEN THE FEED MECHANISM FAILS TO DELIVER A CARD TO
2090 ;THE READ STATION
2091 010226 104400      TESTG: SCOPE
2092 010230 004767 001700      JSR     %7,INIT
2093 010234 000004 014023      TYPE,  MSG3            ;"PRESS CARD READER 'STOP'"
2094 010240 000004 014421      TYPE,  MSG9            ;"SLIDE A CARD FROM THE OUTPUT HOPPER ABOUT
2095 ;HALF AN INCH BACK INTO THE READ HEAD
2096 ;BLOCKING THE PHOTO CELL

```



```

2153                                     ;END OF FILE BUTTON AND HOPPER CHECK TEST
2154                                     ;ON M-1000 BIT 13 IS ALWAYS CLEARED
2155                                     ;ON M-1200 IF END OF FILE BUTTON IS PRESSED WITH INPUT
2156                                     ;HOPPER LOADED THEN WHEN INPUT HOPPER BECOMES EMPTY
2157                                     ;HOPPER CHECK INDICATOR LIGHT COMES ON AND BITS
2158                                     ;13 14 AND 15 ARE SET
2159
2160
2161 010502 005767 170032                TST   CD1000                ; IS READER M-1000?
2162 010506 001402                                BEQ   TESTI                ; BRANCH IF READER IS M-1200
2163 010510 000167 000322                JMP   TESTH                ; OUT OF THIS TEST IF M-1000
2164
2165 010514 104400                TESTI: SCOPE
2166 010516 004767 001412                JSR   %7, INIT
2167 010522 000004 015320                TYPE, MSG20
2168 010526 000004 013722                TYPE, MSG1                ; "PUT ANY TWO CARDS IN INPUT HOPPER"
2169 010532 000004 013756                TYPE, MSG2                ; "PRESS CARD READER 'RESET'"
2170 010536 000004 013714                TYPE, CRLF-3              ; "THEN HIT 'CONTINUE' ON THE CONSOLE"
2171 010542 000000                                HALT                       ; MOVE MESSAGE UP ON TTY
2172
2173 010544 032713 000010                BIT   #10, %CDS           ; CHECK FOR TRANSITION TO ON LINE
2174 010550 001775                                BEQ   .-4
2175 010552 000004 015364                TYPE, MSG21
2176 010556 000004 013756                TYPE, MSG2                ; WAIT FOR IT
2177 010562 000004 013714                TYPE, CRLF-3              ; "PRESS END OF FILE BUTTON"
2178 010566 004767 001342                JSR   %7, INIT            ; "THEN HIT 'CONTINUE' ON THE CONSOLE"
2179 010572 000000                                HALT                       ; MOVE MESSAGE UP ON TTY
2180
2181
2182 010574 032713 020000                BIT   #20000, %CDS        ; CHECK BIT 13
2183 010600 001401                                BEQ   .+4                  ; BRANCH IF NOT SET
2184 010602 104000                                HLT                         ; EOF SET FROM BEGINING
2185
2186
2187 010604 032713 040000                BIT   #40000, %CDS        ; CHECK BIT 14
2188 010610 001401                                BEQ   .+4                  ; BRANCH IF NOT SET
2189 010612 104000                                HLT                         ; READER CHECK ERROR SET FROM BEGINNING
2190
2191
2192 010614 032713 000004                BIT   #4, %CDS           ; CHECK BIT 2
2193 010620 001401                                BEQ   .+4                  ; BRANCH IF NOT SET
2194 010622 104000                                HLT                         ; HOPPER CHECK SET FROM BEGINING
2195
2196 010624 005713                TST   %CDS                ; CHECK ERROR BIT
2197 010626 100001                                BPL   .+4                  ; BRANCH IF NOT SET
2198 010630 104000                                HLT                         ; ERROR SET FROM BEGINING
2199
2200
2201
2202
2203 010632 012712 010700                MOV   #TINTI, %ADINT      ; LOAD RETURN POINTER
2204 010636 052767 000340 167132 SECN: BIS   #340, PS              ; SET PROCESSOR TO LEVEL 7
2205 010644 016762 167126 000002      MOV   PS, 2(%ADINT)       ; LOAD RETURN PROCESSOR STATUS
2206 010652 042767 000340 167116      BIC   #340, PS            ; SET PROCESSOR PRIORITY TO 0
2207 010660 012713 000100                MOV   #100, %CDS         ; SET INTERRUPT ENABLE
2208 010664 012714 177701                MOV   #-77, %CDC         ; SET UP COLUMN COUNT

```

```

2209 010670 012715 016000      MOV    #BUFBEQ,@CDA    ;SET UP BUS ADDRESS
2210 010674 005213              INC    @CDS           ;START READER
2211 010676 000777              BR     .              ;WAIT FOR AN INTERRUPT
2212
2213
2214 010700 022626      TINTI: CMP    (SP)+, (SP)+ ;RESTORE THE STACK
2215
2216 010702 032713 020000      BIT    #20000, @CDS   ;CHECK BIT 13
2217 010706 001401              BEQ    .+4            ;BRANCH IF NOT SET
2218 010710 104000              HLT                    ;EOF SET AT END OF ONE CARD
2219
2220 010712 032713 040000      BIT    #40000, @CDS   ;CHECK BIT 14
2221 010716 001401              BEQ    .+4            ;BRANCH IF NOT SET
2222 010720 104000              HLT                    ;READER CHECK ERROR SET AT END OF ONE CARD
2223
2224 010722 005713              TST    @CDS           ;CHECK ERROR BIT
2225 010724 100001              BPL    .+4            ;BRANCH IF NOT SET
2226 010726 104000              HLT                    ;ERROR SET AT END OF ONE CARD
2227
2228 010730 012712 010736      MOV    #TINTIA,@ADINT ;LOAD RETURN POINTER
2229 010734 000740              BR     SECN           ;READ SECOND CARD
2230 010736 022626      TINTIA: CMP    (SP)+, (SP)+ ;RESTORE THE STACK
2231
2232 010740 032713 020000      BIT    #20000, @CDS   ;CHECK BIT 13
2233 010744 001001              BNE    .+4            ;BRANCH IF SET
2234 010746 104000              HLT                    ;EOF NOT SET AT END OF FILE
2235
2236 010750 032713 040000      BIT    #40000, @CDS   ;CHECK BIT 14
2237 010754 001001              BNE    .+4            ;BRANCH IF SET
2238 010756 104000              HLT                    ;READER CHECK NOT SET AT END OF FILE
2239
2240 010760 032713 000004      BIT    #4, @CDS       ;CHECK BIT 2
2241 010764 001001              BNE    .+4            ;BRANCH IF SET
2242 010766 104000              HLT                    ;HOPPER CHECK NOT SET WHEN HOPPER EMPTY
2243
2244
2245 010770 005713              TST    @CDS           ;CHECK ERROR BIT
2246 010772 100401              BMI    .+4            ;BRANCH IF SET
2247 010774 104000              HLT                    ;ERROR BIT NOT SET AT END OF FILE
2248
2249 010776 000004 014162      TYPE, MSG6           ;"RESTORE CARDS TO THE INPUT HOPPER"
2250 011002 000004 013722      TYPE, MSG1           ;"PRESS CARD READER 'RESET'"
2251 011006 000004 013756      TYPE, MSG2           ;"THEN HIT CONTINUE ON THE CONSOLE"
2252 011012 000004 013714      TYPE, CRLF-3        ;MOVE MESSAGE UP ON TTY
2253 011016 000000      HALT
2254
2255 011020 032713 000010      BIT    #10, @CDS      ;CHECK TRANSITION TO ON LINE
2256 011024 001775              BEQ    .-4            ;WAIT FOR IT
2257
2258
2259 011026 032713 020000      BIT    #20000, @CDS   ;CHECK BIT 13
2260 011032 001401              BEQ    .+4            ;BRANCH IF NOT SET
2261 011034 104000              HLT                    ;EOF DIDN'T CLEAR BY TRANSITION TO ON LINE
2262
2263
2264

```

;;A READ CHECK ERROR SHOULD SET BIT 15, BIT 14, AND BIT 12

```

2265 ;THIS ERROR OCCURS WHEN THE READ ELECTRONICS IN THE CARD
2266 ;READER DISAGREES WITH THE NORMAL UNPUNCHED AREA OF THE CARD
2267 011036 104400 TESTH: SCOPE
2268 011040 004767 001070 JSR %7,INIT
2269 011044 000004 014676 TYPE, MSG12 ;"PLACE SPECIAL DARK LIGHT CHECK CARD ONLY
2270 ;AT THE FRONT OF THE INPUT STACK"
2271 011050 000004 013722 TYPE, MSG1 ;"PRESS CARD READER 'RESET'"
2272 011054 000004 013714 TYPE, CRLF-3 ;MOVE MESSAGE UP ON TTY
2273 011060 032713 010000 TLOPH: BIT #10000, @CDS ;CHECK FOR OF LINE
2274 011064 001775 BEQ TLOPH ;WAIT FOR OFF-LINE
2275 011066 032713 000010 TLOPHA: BIT #10, @CDS ;CHECK FOR "TRANSITION TO ON LINE"
2276 011072 001775 BEQ TLOPHA ;WAIT FOR IT
2277 011074 022713 140210 CMP #140210, @CDS ;CHECK FOR CORRECT STATUS BITS
2278 011100 001401 BEQ .+4 ;BRANCH IF OK
2279 011102 104000 HLT ;STATUS NOT EQUAL TO 140210
2280
2281 011104 012714 177701 MOV #-77, @CDC ;SET UP COLUMN COUNT
2282 011110 012715 016000 MOV #BUFBEQ, @CDA ;SET UP BUS ADDRESS
2283 011114 005213 INC @CDS ;READ
2284 011116 105713 TLOPHB: TSTB @CDS ;CHECK CONTROLLER READY
2285 011120 100376 BPL TLOPHR ;WAIT FOR CONTROLLER READY
2286 011122 032713 010000 BIT #10000, @CDS ;CHECK BIT12
2287 011126 001001 BNE .+4 ;BRANCH IF SET
2288 011130 104000 HLT ;OFF-LINE (BIT 12) WASN'T SET
2289
2290 011132 005713 TST @CDS ;CHECK SPECIAL CONDITION BIT
2291 011134 100401 BMI .+4 ;BRANCH IF SET
2292 011136 104000 HLT ;SPECIAL CONDITION NOT SET
2293
2294 011140 032713 040000 BIT #40000, @CDS ;CHECK FOR CARD READER ERROR
2295 011144 001001 BNE .+4 ;BRANCH IF SET
2296 011146 104000 HLT ;CARD READER ERROR BIT 14 NOT SET
2297
2298 011150 032713 027577 BIT #027577, @CDS ;CHECK FOR EXTRA BITS
2299 011154 001401 BEQ .+4 ;BRANCH IF OK
2300 011156 104000 HLT ;STATUS WORD ERROR
2301
2302 011160 012712 011232 MOV #TINTH, @ADINT ;LOAD RETURN POINTER
2303 011164 052767 000340 166604 BIS #340, PS ;SET PROCESSOR TO LEVEL 7
2304 011172 016762 166600 000002 MOV PS, 2(ADINT) ;LOAD RETURN PROCESSOR STATUS
2305 011200 042767 000340 166570 BIC #340, PS ;SET PROSSOR PRIORITY TO 0
2306 011206 012713 000100 MOV #100, @CDS ;SET INTERRUPT ENABLE
2307 011212 000004 014162 TYPE, MSG6 ;"RESTORE CARDS TO THE INPUT HOPPER"
2308 011216 000004 013722 TYPE, MSG1 ;"PRESS CARD READER 'RESET'"
2309 011222 000004 013714 TYPE, CRLF-3 ;MOVE MESSAGE UP ON TTY
2310 011226 000777 BR . ;WAIT FOR AN INTERRUPT
2311 011230 000000 HALT
2312 011232 022626 TINTH: CMP (SP)+, (SP)+ ;RESTORE THE STACK
2313 011234 104400 SCOPE
2314 011236 004767 000720 JSR %7, BELL ;RING THE BELL
2315 011242 000167 175302 JMP ER12CD ;LOOP BACK TO THE BEGINNING
2316
2317
2318
2319
2320

```

```

;*****
;ROUTINE TO LOOP THRU A SINGLE INSTRUCTION TEST OR ERROR FUNCTION TEST

```



```

2321
2322
2323 011246 004767 167270
2324 011252 000000
2325 011254 016767 166310 000072
2326 011262 062767 000002 000064
2327 011270 000000
2328 011272 032767 010000 166270
2329 011300 001404
2330 011302 042767 000020 166466
2331 011310 000403
2332 011312 052767 000020 166456
2333 011320 005067 001106
2334 011324 012767 004000 001076
2335 011332 012767 011344 001074
2336 011340 000177 000010
2337 011344 005067 001062
2338 011350 000177 000000
2339 011354 000000
2340
2341
2342
2343
2344
2345
2346
2347
2348
2349
2350
2351
2352
2353
2354
2355
2356
2357
2358 011356 012767 011356 001050
2359 011364 004767 167152
2360 011370 000000
2361 011372 016767 166172 000526
2362 011400 042767 170000 000520
2363 011406 016767 000514 000514
2364 011414 005067 000512
2365 011420 006067 000504
2366 011424 106167 000501
2367 011430 106067 000474
2368 011434 106167 000471
2369 011440 106167 000465
2370 011444 106167 000461
2371 011450 106167 000455
2372 011454 012701 000007
2373 011460 006067 000444
2374 011464 103004
2375 011466 005267 000440
2376 011472 150167 000433

```

```

;NOTE THAT SW11 MUST BE DOWN AFTER 2ND HALT
*****
TESTX: JSR %7, SETUP ; SETUP POINTERS AND FLAGS
        HALT ; WAIT FOR STARTING ADDRESS
        MOV SWR, RETRNX ; STORE STARTING ADDRESS
        ADD #2, RETRNX ; CHANGE TO FIRST ADDRESS AFTER SCOPE INSTRUCTION
        HALT ; SET SWR OPTIONS (BIT 11 MUST = 0)
        BIT #10000, SWR ; CHECK SW12
        BEQ .+12 ; BRANCH IF NOT SET
        BIC #20, PS ; CLEAR TRACE BIT
        BR .+10 ; SKIP NEXT INSTRUCTION
        BIS #20, PS ; SET TRACE BIT
        CLR ITCNT ; CLEAR ITERATION COUNTER
        MOV #4000, ITMAX
        MOV #XLOOP, RETURN ; LOAD RETURN ADDRESS
        JMP @RETRNX ; JUMP TO TEST
XLOOP: CLR ITCNT ; KEEP ITERATION COUNTER AT ZERO
        JMP @RETRNX ; JUMP TO TEST
RETRNX: 0

```

```

*****
:ROUTINE TO CHECK CARDS WHICH HAVE ALL COLUMNS IDENTICALLY PUNCHED.
:THIS ROUTINE ALLOWS SPECIFIC TYPES OF DATA FAILURES TO BE STUDIED
:EASILY. THE ROUTINE HALTS ONCE AT THE START. SET THE CORRECT CARD
:IMAGE PATTERN IN SW11-SW00, THEN HIT CONTINUE (AFTER THE DECK IS
:LOADED AND CARD READER IS ON-LINE). THE PATTERN IS STORED, AND THEN
:EACH COLUMN OF EACH CARD IS READ TWICE AND COMPARED WITH IT. IF A
:DISCREPANCY OCCURS, THE ERROR IS PRINTED OUT ALONG WITH THE TOTAL
:NUMBER OF CARDS READ AND THE TOTAL NUMBER OF DATA ERRORS DISCOVERED
:UP TO THAT POINT (ALL PRINTOUTS ARE IN OCTAL). WHEN THE INPUT HOPPER
:IS EMPTY, THE ROUTINE RINGS THE BELL AND WAITS FOR MORE CARDS TO BE
:LOADED AND THE CARD READER TO BE PUT BACK ON-LINE.
:SW15=1 CAUSES A HALT AFTER AN ERROR, AND SW13=1 INHIBITS ERROR PRINTOUTS.
*****

```

```

CKSAME: MOV #CKSAME, RETURN ; INITIALIZE POINTERS
        JSR %7, SETUP ; WAIT FOR CARD IMAGE PATTERN
        HALT ; STORE PATTERN
        MOV SWR, CARDIM ; CLEAR UPPER BITS OF PATTERN
        BIC #170000, CARDIM
        MOV CARDIM, CDPK0
        CLR DERFLG
        ROR CDPK0
        ROLB CDPK1
        RORB CDPK0
        ROLB CDPK1
        ROLB CDPK1
        ROLB CDPK1
        ROLB CDPK1
        ROLB CDPK1
        MOV #7, R1
CKLOP1: ROR CDPK0
        BCC CKOVR
        INC DERFLG
        BISB R1, CDPK1

```

2377	011476	005301		CKOVR:	DEC	R1	
2378	011500	001367			BNE	CKLOP1	
2379	011502	000000			HALT		;WAIT FOR SWITCH SETTINGS
2380	011504	004767	000424	CKSTRT:	JSR	%7,INIT	
2381	011510	005067	000410		CLR	TOTCRD	;INITIALIZE CARD COUNT
2382	011514	005067	000402		CLR	TOTERR	;INITIALIZE ERROR COUNT
2383	011520	005067	167006		CLR	ERFLG	;CLEAR FLAG FOR PRINTING ERROR HEADING
2384	011524	105067	000403	CKLOOP:	CLRB	DERFLG+1	
2385	011530	032767	000010		BIT	#10, SWR	;CHECK FOR PACK MODE ONLY
2386	011536	001410			BEQ	CKREAD	;BRANCH IF NOT SET
2387	011540	032737	000004		BIT	#4, @#SWR	;CHECK FOR IMAGE MODE ONLY
2388	011546	001004			BNE	CKREAD	;BRANCH IF SET
2389	011550	052713	000002		BIS	#2, @CDS	;SET PACKING MODE
2390	011554	105167	000353		COMB	DERFLG+1	
2391	011560	005067	174740	CKREAD:	CLR	CLCNT	;INITIALIZE COLUMN COUNT
2392	011564	012700	016000		MOV	#BUFBEG,RO	;SET UP BUFFER POINTER
2393	011570	012714	177660		MOV	#-120, @CDC	;SET UP COLUMN COUNTER
2394	011574	010015			MOV	RO, @CDA	;SET UP BUS ADDRESS
2395	011576	005213			INC	@CDS	;START READING CARD
2396	011600	005267	000320		INC	TOTCRD	;INCREMENT CARD COUNT
2397	011604	105713		CKLP1:	TSTB	@CDS	;CHECK CONTROLLER READY
2398	011606	100376			BPL	CKLP1	;LOOP IF NOT SET
2399	011610	005713			TST	@CDS	;CHECK FOR ERROR
2400	011612	100427			BMI	CKERR	;BRANCH IF ERROR SET
2401	011614	005767	000312		TST	DERFLG	
2402	011620	100012			BPL	CKLOP2	
2403	011622	122067	000303	CKLOP3:	CMPB	(RO)+,CDPK1	;CHECK DATA
2404	011626	001046			BNE	CKFAIL	
2405	011630	005267	174670		INC	CLCNT	
2406	011634	026727	174664		CMP	CLCNT, #120	
2407	011642	001367			BNE	CKLOP3	
2408	011644	000727			BR	CKLOOP	
2409	011646	022067	000254	CKLOP2:	CMP	(RO)+, CARDIM	;CHECK THE DATA
2410	011652	001034			BNE	CKFAIL	;BRANCH IF DATA ERROR
2411	011654	005267	174644		INC	CLCNT	;COUNT THE COLUMNS
2412	011660	026727	174640		CMP	CLCNT, #120	;CHECK FOR LAST COLUMN
2413	011666	001367			BNE	CKLOP2	
2414	011670	000715			BR	CKLOOP	
2415							
2416	011672	032713	010000	CKERR:	BIT	#10000, @CDS	;CHECK FOR OFFLINE
2417	011676	001406			BEQ	CKERR1	;BRANCH IF NOT
2418	011700	004767	000256		JSR	%7, BELL	;RING THE BELL
2419	011704	032713	000010	CKERR3:	BIT	#10, @CDS	;CHECK TRANSITION TO ON-LINE
2420	011710	001775			BEQ	CKERR3	;BRANCH IF OFF-LINE
2421	011712	000674			BR	CKSTRT	;START OVER
2422							
2423	011714	032713	004000	CKERR1:	BIT	#4000, @CDS	;CHECK FOR DATA ERROR
2424	011720	001407			BEQ	CKERR2	
2425	011722	005767	000204		TST	DERFLG	
2426	011726	100004			BPL	CKERR2	
2427	011730	122767	000001		CMPB	#1, DERFLG	
2428	011736	003331			BGT	CKLOP3	;BRANCH IF LEGIT
2429	011740	104000		CKERR2:	HLT		;REAL, LIVE ERROR.
2430	011742	000670			BR	CKLOOP	
2431							
2432	011744	005267	000152	CKFAIL:	INC	TOTERR	;COUNT ERRORS

2433	011750	032767	020000	165612		BIT	#20000,SWR		;CHECK FOR INHIBITING PRINTOUT
2434	011756	001054				BNE	CKHLT		;BRANCH AROUND PRINTOUT IF SET
2435	011760	005767	166546			TST	ERFLG		;TEST FLAG TO PRINT HEADING
2436	011764	001004				BNE	CKNOHD		;BRANCH IF ALREADY DONE
2437	011766	005267	166540			INC	ERFLG		;PRINT HEADING ONCE ONLY
2438	011772	000004	015264			TYPE,	MSG19		;OUTPUT HEADING
2439	011776	000004	013717			CKNOHD:	CRLF		;OUTPUT CARRIAGE RETURN, LINEFEED
2440	012002	016767	174516	000544		MOV	CLCNT,PRINT1		;TYPE CLCNT IN OCTAL
2441	012010	004767	000574			JSR	%7,PRINTR		;TYPE LEADING ZERO'S
2442	012014	000004	013711			TYPE,	SPACE		
2443	012020	005767	000106			TST	DERFLG		
2444	012024	100006				BPL	CKNOPK		
2445	012026	114067	000523			MOVB	-(R0), PRINT1+1		;MOVE BYTE INTO PRINT BUFFER
2446	012032	004767	000532			JSR	%7, PRINTB		;AND PRINT IT
2447	012036	105720				TSTB	(R0)+		
2448	012040	000405				BR	CKOVR1		
2449	012042					CKNOPK:			
2450	012042	014067	000506			MOV	-(R0),PRINT1		;TYPE -(R0) IN OCTAL
2451	012046	004767	000536			JSR	%7,PRINTR		;TYPE LEADING ZERO'S
2452	012052	005720				TST	(R0)+		
2453	012054	000004	013711			CKOVR1:	SPACE		
2454	012060	016767	000040	000466		MOV	TOTCRD,PRINT1		;TYPE TOTCRD IN OCTAL
2455	012066	004767	000516			JSR	%7,PRINTR		;TYPE LEADING ZERO'S
2456	012072	000004	013711			TYPE,	SPACE		
2457	012076	016767	000020	000450		MOV	TOTERR,PRINT1		;TYPE TOTERR IN OCTAL
2458	012104	004767	000500			JSR	%7,PRINTR		;TYPE LEADING ZERO'S
2459	012110	005767	165454			CKHLT:	SWR		;CHECK SW15 TO HALT ON ERROR
2460	012114	100203				BPL	CKLOOP		;BRANCH IF NOT SET
2461	012116	000000				HALT			;HALT ON ERROR
2462	012120	000601				BR	CKLOOP		;CONTINUE
2463									
2464	012122	000000				TOTERR:	0		
2465	012124	000000				TOTCRD:	0		
2466	012126	000000				CARDIM:	0		
2467	012130	000				CDPK0:	.BYTE 0		
2468	012131	000				CDPK1:	.BYTE 0		
2469	012132	000000				DERFLG:	0		

```

2470
2471      ;ISSUE MESSAGE IF CARD READER IS OFF-LINE
2472      ;WAIT FOR BUSY TO CLEAR IN CASE CARD READER IS STILL READING A CARD
2473      ;INITIALIZE STATUS REGISTER AND USE ERROR HALT IF IT DOESN'T CLEAR PROPERLY
2474      ;NOTE THAT PROGRAM WILL HANG HERE IF BUSY REMAINS SET
2475 012134 004767 000040      INIT: JSR      %7, CKOFFL      ;SEE IF OFF-LINE BIT IS SET
2476 012140 105713              TSTB     @CDS      ;WAIT FOR CONTROLLER READY, IN CASE
2477 012142 100376              BPL     .-2       ;A CARD IS STILL BEING READ
2478 012144 012713 000400      MOV     #400, @CDS ;INITIALIZE THE CARD READER
2479 012150 022713 000200      CMP     #200, @CDS ;MAKE SURE INITIALIZATION OK
2480 012154 001401              BEQ     .+4       ;BRANCH IF ALL BITS ZERO
2481 012156 104000              HLT                    ;NOT ALL BITS OF STATUS REGISTER ARE ZERO
2482 012160 000207              RTS     %7       ;RETURN
2483
2484      ;BELL ON PASS COMPLETE
2485 012162 105777 166322      BELL: TSTB     @TPS      ;WAIT FOR TTY READY
2486 012166 100375              BPL     .-4
2487 012170 012777 000207 166314  MOV     #207,@TPB    ;RING BELL
2488 012176 000207              RTS     %7       ;RETURN
2489
2490      ;SUBROUTINE TO CHECK FOR BIT 12 (OFF-LINE) BEING SET IN CARD
2491      ;READER CSR, AND PRINT OUT A MESSAGE IF IT IS
2492 012200 032713 010000      CKOFFL: BIT    #10000,@CDS ;CHECK BIT 12
2493 012204 001001              BNE     .+4       ;BRANCH IF SET
2494 012206 000207              RTS     %7       ;RETURN IF NOT SET
2495 012210 000004 015243      TYPE,  MSG18      ;"BIT 12 WAS SET"
2496 012214 000004 015161      TYPE,  MSG17      ;"REMEDY THE ERROR CONDITION"
2497 012220 000000              HALT                    ;WAIT FOR CONTINUE
2498 012222 000766              BR     CKOFFL     ;CHECK AGAIN
2499
2500      ;ENTERED WITH SYSTEM TRAP CALL (HLT)
2501      ;PRINT OUT THE ERROR PC AND STATUS REGISTER
2502 012224 036727 165340 020000 PRINT: BIT    SWR, #20000 ;TEST FOR INHIBIT PRINT OUT
2503 012232 001401              BEQ     .+4       ;BRANCH TO PRINT
2504 012234 000433              BR     B.CK      ;INHIBIT, CHECK FOR HALT
2505 012236 012667 000102      MOV     (6)+, SAVPC ;PC OF FAILING ROUTINE
2506 012242 012667 000100      MOV     (6)+, SAVPS ;PS OR ERROR CONDITION
2507 012246 024646              CMP     -(6), -(6) ;RESTORE STACK
2508 012250 000004 013717      TYPE,  CRLF      ;OUTPUT CARRIAGE RETURN, LINEFEED
2509 012254 016767 000064 000272  MOV     SAVPC,PRINT1 ;TYPE SAVPC IN OCTAL
2510 012262 004767 000322      JSR     %7,PRINTR  ;TYPE LEADING ZERO'S
2511 012266 000004 013710      TYPE,  SPACE-1
2512 012272 016767 000050 000254  MOV     SAVPS,PRINT1 ;TYPE SAVPS IN OCTAL
2513 012300 004767 000304      JSR     %7,PRINTR  ;TYPE LEADING ZERO'S
2514 012304 000004 013710      TYPE,  SPACE-1
2515 012310 011367 000240      MOV     @CDS,PRINT1 ;TYPE @CDS IN OCTAL
2516 012314 004767 000270      JSR     %7,PRINTR  ;TYPE LEADING ZERO'S
2517 012320 000004 013717      TYPE,  CRLF
2518 012324 005767 165240      B.CK: TST     SWR    ;CHECK SWR FOR HALT SWITCH
2519 012330 100001              BPL     .+4       ;BRANCH IF NOT SET
2520 012332 000000              HALT                    ;HALT ON ERROR UP
2521 012334 000002              RTI                    ;RETURN TO MAIN LINE
2522 012336 000000      SAVR2: C
2523 012340 000000      SAVR3: 0
2524 012342 000000      SAVR4: 0
2525 012344 000000      SAVPC: 0

```

```

2526 012346 000000
2527
2528
2529 012350 032767 040000 165212
2530 012356 001012
2531 012360 032767 004000 165202
2532 012366 001013
2533 012370 026767 000036 000032
2534 012376 100007
2535 012400 005267 000026
2536 012404 022606
2537 012406 012667 165364
2538 012412 000177 000016
2539 012416 005067 000010
2540 012422 011667 000006
2541 012426 000002
2542 012430 000001
2543 012432 000000
2544 012434 001060
2545
2546
2547
2548
2549
2550
2551
2552
2553
2554
2555 012436 177564
2556 012440 177566
2557 012442 000
2558 012443 002
2559 012444 000
2560 012445 000
2561
2562 012446 105767 177772
2563 012452 001402
2564 012454 000000
2565 012456 000407
2566 012460 010046
2567 012462 017600 000002
2568 012466 112046
2569 012470 001005
2570 012472 005726
2571 012474 012600
2572 012476 062716 000002
2573 012502 000002
2574 012504 004767 000026
2575 012510 122726 000012
2576 012514 001364
2577 012516 016746 177720
2578
2579 012522 105366 000001
2580 012526 002770
2581 012530 004767 000002
    
```

```

SAVPS: 0
;SCOPE AND/OR ITERATION LOOP FOR EACH TEST 2 TIMES
SCOPEC: BIT #4000, SWR ;TEST SWR FOR SCOPE
          BNE D.1 ;YES, SCOPE
          BIT #4000, SWR ;NO- TEST FOR ITERATION
          BNE D.2 ;INHIBIT ITERATION
          CMP ITCNT, ITMAX ;CHECK FOR ITERATIONS COMPLETE
          BPL D.2 ;EXIT-DONE
          INC ITCNT ;INCREMENT COUNT
D.1: CMP (6)+, %6 ;REPOSITION STACK POINTER
      MOV (6)+, PS ;RESTORE PROCESSOR STATUS
      JMP @RETURN ;RETURN TO RERUN TEST
D.2: CLR ITCNT ;CLEAR COUNTER
      MOV @%6, RETURN ;SAVE SCOPE RETURN POINTER
      RTI ;RETURN INLINE-NEXT TEST
ITMAX: 1 ;MAX NUMBER OF ITERATIONS
ITCNT: 0 ;COUNT LOCATION FOR ITERATION LOOP
RETURN: TEST1+2 ;ADDRESS OF LAST TEST
    
```

```

;ROUTINE TO TYPE ASCII MESSAGE, MESSAGE MUST TERMINATE WITH A 0 BYTE.
;THE ROUTINE WILL INSERT A NUMBER OF NULL CHARACTERS AFTER A LINE FEED.
;NOTE1: $NULL CONTAINS THE CHARACTER TO BE USED AS THE FILLER CHARACTER.
;NOTE2: $FILLS CONTAINS THE NUMBER OF FILLER CHARACTERS REQUIRED.
    
```

```

$TPS: 177564 ;TTY PRINTER STATUS REG. ADDRESS
$TPB: 177566 ;TTY PRINTER BUFFER REG. ADDRESS
$NULL: .BYTE 0 ;CONTAINS NULL CHARACTER FOR FILLS
$FILLS: .BYTE 2 ;CONTAINS # OF FILLER CHARACTERS REQUIPED
$TPFLG: .BYTE 0 ;"TERMINAL AVAILABLE" FLAG (0=YES)
        .BYTE 0 ;RESERVED
$TYPE: TSTB $TPFLG ;IS THERE A TERMINAL?
        BEQ 6$ ;BR IF YES
        HALT ;HALT HERE IF NO TERMINAL
        BR 7$ ;LEAVE
6$: MOV RO, -(SP) ;SAVE RO
    MOV @2(SP), RO ;GET ADDRESS OF ASCIZ STRING
1$: MOVB (RO)+, -(SP) ;PUSH CHARACTER TO BE TYPED ONTO STACK
    BNE 2$ ;BR IF IT ISN'T THE TERMINATOR
    TST (SP)+ ;IF TERMINATOR POP IT OFF THE STACK
    MOV (SP)+, RO ;RESTORE RO
    ADD #2, (SP) ;ADJUST RETURN PC
    RTI ;RETURN
2$: JSR PC, 5$ ;GO TYPE THIS CHARACTER
3$: CMPB #12, (SP)+ ;CHECK IF THE CHAR, TYPED WAS A LINE FEED
    BNE 1$ ;GO GET NEXT CHAR, IF NOT LINE FEED
    MOV $NULL, -(SP) ;GET # OF FILLER CHARS, NEEDED
    AND THE NULL CHAR.
4$: DECB 1(SP) ;DOES A NULL NEED TO BE TYPED?
    BLT 3$ ;BR IF NO--GO POP THE NULL OFF OF STACK
    JSR PC, 5$ ;GO TYPE A NULL
    
```

```

2582 012534 000772          BR      4$      ;LOOP
2583 012536 105777 177674  SS:    TSTB   3$TPS   ;WAIT UNTIL PRINTER IS READY
2584 012542 100375          BPL    5$
2585 012544 116677 000002 177666  MOVB   2(SP),3$TPB ;LOAD CHAR TO BE TYPED INTO DATA REG.
2586 012552 000207          RTS    PC
2587
2588
2589
2590
2591
2592
2593
2594
2595
2596
2597
2598
2599
2600
2601 012554 000000          ;
2602 012556 000000 000000 000000 PRINT1: 0
2603 012564 000000          PRINT2: .WORD 0,0,0,0
2604 012566 000          PRINT3: .BYTE 0,0
2605 012570 012767 176401 177770 PRINTB: MOV    #176401,PRINT3 ;.BYTE -1,3
2606 012576 010546          MOV    %5,-(6) ;SAVE R5
2607 012600 012705 012556          MOV    #PRINT2,%5 ;SET POINTER TO 1ST ASCII CHAR.
2608 012604 105015          CLRB   (5) ;CLR 1ST BYTE
2609 012606 000422          BR     PRINTT ;PRINT 2 BITS
2610 012610 112767 000001 177750 PRINTR: MOVB   #1,PRINT3 ;SET ZERO FILL SWITCH
2611 012616 000402          BR     .+6
2612 012620 005067 177742          PRINTS: CLR   PRINT3 ;SUPPRESS LEADING ZERO'S
2613 012624 112767 177772 177735 MOVB   #-6,PRINT3+1 ;SET COUNT
2614 012632 010546          MOV    %5,-(6) ;SAVE R5
2615 012634 012705 012556          MOV    #PRINT2,%5 ;SET POINTER TO FIRST ASCII CHAR.
2616 012640 105015          CLRB   (5) ;CLEAR FIRST BYTE
2617 012642 000407          BR     PRINTF ;ROTATE FIRST BIT
2618 012644 105015          PRINTL: CLRB  (5) ;CLEAR BYTE OF CHARACTER
2619 012646 006167 177702          ROL   PRINT1 ;ROTATE BIT INTO C
2620 012652 106115          ROLB  (5) ;PACK IT
2621 012654 006167 177674          PRINTT: ROL   PRINT1 ;ROTATE BIT INTO C
2622 012660 106115          ROLB  (5) ;PACK IT
2623 012662 006167 177666          PRINTF: ROL   PRINT1 ;ROTATE BIT INTO C
2624 012666 106115          ROLB  (5) ;PACK IT
2625 012670 105715          TSTB  (5)
2626 012672 001402          BEQ   .+6
2627 012674 105267 177666          INCB  PRINT3
2628 012700 105767 177662          TSTB  PRINT3 ;CHECK FILL SWITCH
2629 012704 001402          BEQ   .+6
2630 012706 152725 000060          BISB  #'0,(5)+ ;MAKE INTO ASCII CHAR
2631 012712 105267 177651          INCB  PRINT3+1
2632 012716 001352          BNE   PRINTL ;REPEAT
2633 012720 022705 012556          CMP   #PRINT2,%5
2634 012724 001002          BNE   .+6
2635 012726 112725 000060          MOVB  #'0,(5)+
2636 012732 105015          CLRB  (5)
2637 012734 000004 012556          TYPE, PRINT2 ;TYPE IT
2638 012740 012605          MOV   (6)+,%5 ;RESTORE R5
2639 012742 000207          RTS   %7

```

; OCTAL DUMP OF A WORD

2637  
2638  
2639  
2640  
2641  
2642  
2643  
2644 012744 004000  
2645 012746 004400  
2646 012750 004200  
2647 012752 004100  
2648 012754 004040  
2649 012756 004020  
2650 012760 004010  
2651 012762 004004  
2652 012764 004002  
2653 012766 004001  
2654 012770 004202  
2655 012772 004102  
2656 012774 004042  
2657 012776 004022  
2658 013000 004012  
2659 013002 004006  
2660 013004 002000  
2661 013006 002400  
2662 013010 002200  
2663 013012 002100  
2664 013014 002040  
2665 013016 002020  
2666 013020 002010  
2667 013022 002004  
2668 013024 002002  
2669 013026 002001  
2670 013030 002202  
2671 013032 002102  
2672 013034 002042  
2673 013036 002022  
2674 013040 002012  
2675 013042 002006  
2676 013044 001000  
2677 013046 001400  
2678 013050 001200  
2679 013052 001100  
2680 013054 001040  
2681 013056 001020  
2682 013060 001010  
2683 013062 001004  
2684 013064 001002  
2685 013066 001001  
2686 013070 001202  
2687 013072 001102  
2688 013074 001042  
2689 013076 001022  
2690 013100 001012  
2691 013102 001006  
2692 013104 000000  
2693 013106 000400

;DATA TABLES FOR DATA RELIABILITY TESTS

;ALPHANUMERIC DECK DATA TABLE  
;CARD IMAGE FORM

ALPCD: 4000  
4400  
4200  
4100  
4040  
4020  
4010  
4004  
4002  
4001  
4202  
4102  
4042  
4022  
4012  
4006  
2000  
2400  
2200  
2100  
2040  
2020  
2010  
2004  
2002  
2001  
2202  
2102  
2042  
2022  
2012  
2006  
1000  
1400  
1200  
1100  
1040  
1020  
1010  
1004  
1002  
1001  
1202  
1102  
1042  
1022  
1012  
1006  
0000  
0400

COLUMN	ASCII	PUNCH
1	0	0
2	1	1
3	2	2
4	3	3
5	4	4
6	5	5
7	6	6
8	7	7
9	8	8
10	9	9
11	A	0
12	B	1
13	C	2
14	D	3
15	E	4
16	F	5
17	G	6
18	H	7
19	I	8
20	J	9
21	K	0
22	L	1
23	M	2
24	N	3
25	O	4
26	P	5
27	Q	6
28	R	7
29	S	8
30	T	9
31	U	0
32	V	1
33	W	2
34	X	3
35	Y	4
36	Z	5
37	/	6
38	~	7
39		8
40		9
41		0
42		1
43		2
44		3
45		4
46		5
47		6
48		7
49		8
50		9
51		0
52		1
53		2
54		3
55		4
56		5
57		6
58		7
59		8
60		9
61		0
62		1
63		2
64		3
65		4
66		5
67		6
68		7
69		8
70		9
71		0
72		1
73		2
74		3
75		4
76		5
77		6
78		7
79		8
80		9
81		0
82		1
83		2
84		3
85		4
86		5
87		6
88		7
89		8
90		9
91		0
92		1
93		2
94		3
95		4
96		5
97		6
98		7
99		8
100		9
101		0
102		1
103		2
104		3
105		4
106		5
107		6
108		7
109		8
110		9
111		0
112		1
113		2
114		3
115		4
116		5
117		6
118		7
119		8
120		9
121		0
122		1
123		2
124		3
125		4
126		5
127		6
128		7
129		8
130		9
131		0
132		1
133		2
134		3
135		4
136		5
137		6
138		7
139		8
140		9
141		0
142		1
143		2
144		3
145		4
146		5
147		6
148		7
149		8
150		9
151		0
152		1
153		2
154		3
155		4
156		5
157		6
158		7
159		8
160		9
161		0
162		1
163		2
164		3
165		4
166		5
167		6
168		7
169		8
170		9
171		0
172		1
173		2
174		3
175		4
176		5
177		6
178		7
179		8
180		9
181		0
182		1
183		2
184		3
185		4
186		5
187		6
188		7
189		8
190		9
191		0
192		1
193		2
194		3
195		4
196		5
197		6
198		7
199		8
200		9
201		0
202		1
203		2
204		3
205		4
206		5
207		6
208		7
209		8
210		9
211		0
212		1
213		2
214		3
215		4
216		5
217		6
218		7
219		8
220		9
221		0
222		1
223		2
224		3
225		4
226		5
227		6
228		7
229		8
230		9
231		0
232		1
233		2
234		3
235		4
236		5
237		6
238		7
239		8
240		9
241		0
242		1
243		2
244		3
245		4
246		5
247		6
248		7
249		8
250		9
251		0
252		1
253		2
254		3
255		4
256		5
257		6
258		7
259		8
260		9
261		0
262		1
263		2
264		3
265		4
266		5
267		6
268		7
269		8
270		9
271		0
272		1
273		2
274		3
275		4
276		5
277		6
278		7
279		8
280		9
281		0
282		1
283		2
284		3
285		4
286		5
287		6
288		7
289		8
290		9
291		0
292		1
293		2
294		3
295		4
296		5
297		6
298		7
299		8
300		9
301		0
302		1
303		2
304		3
305		4
306		5
307		6
308		7
309		8
310		9
311		0
312		1
313		2
314		3
315		4
316		5
317		6
318		7
319		8
320		9
321		0
322		1
323		2
324		3
325		4
326		5
327		6
328		7
329		8
330		9
331		0
332		1
333		2
334		3
335		4
336		5
337		6
338		7
339		8
340		9
341		0
342		1
343		2
344		3
345		4
346		5
347		6
348		7
349		8
350		9
351		0
352		1
353		2
354		3
355		4
356		5
357		6
358		7
359		8
360		9
361		0
362		1
363		2
364		3
365		4
366		5
367		6
368		7
369		8
370		9
371		0
372		1
373		2
374		3
375		4
376		5
377		6
378		7
379		8
380		9
381		0
382		1
383		2
384		3
385		4
386		5
387		6
388		7
389		8
390		9
391		0
392		1
393		2
394		3
395		4
396		5
397		6
398		7
399		8
400		9





2749	013232	106
2750	013233	107
2751	013234	110
2752	013235	120
2753	013236	112
2754	013237	113
2755	013240	114
2756	013241	115
2757	013242	116
2758	013243	117
2759	013244	040
2760	013245	041
2761	013246	042
2762	013247	043
2763	013250	044
2764	013251	045
2765	013252	046
2766	013253	047
2767	013254	050
2768	013255	060
2769	013256	052
2770	013257	053
2771	013260	054
2772	013261	055
2773	013262	056
2774	013263	057
2775	013264	000
2776	013265	001
2777	013266	002
2778	013267	003
2779	013270	004
2780	013271	005
2781	013272	006
2782	013273	007
2783	013274	010
2784	013275	020
2785	013276	012
2786	013277	013
2787	013300	014
2788	013301	015
2789	013302	016
2790	013303	017
2791	013304	200
2792	013305	201
2793	013306	202
2794	013307	203
2795	013310	204
2796	013311	205
2797	013312	206
2798	013313	207
2799	013314	210
2800	013315	220
2801	013316	212
2802	013317	213
2803	013320	214
2804	013321	215

.BYTE	106
.BYTE	107
.BYTE	110
.BYTE	120
.BYTE	112
.BYTE	113
.BYTE	114
.BYTE	115
.BYTE	116
.BYTE	117
.BYTE	40
.BYTE	41
.BYTE	42
.BYTE	43
.BYTE	44
.BYTE	45
.BYTE	46
.BYTE	47
.BYTE	50
.BYTE	60
.BYTE	52
.BYTE	53
.BYTE	54
.BYTE	55
.BYTE	56
.BYTE	57
.BYTE	0
.BYTE	1
.BYTE	2
.BYTE	3
.BYTE	4
.BYTE	5
.BYTE	6
.BYTE	7
.BYTE	10
.BYTE	20
.BYTE	12
.BYTE	13
.BYTE	14
.BYTE	15
.BYTE	16
.BYTE	17
.BYTE	200
.BYTE	201
.BYTE	202
.BYTE	203
.BYTE	204
.BYTE	205
.BYTE	206
.BYTE	207
.BYTE	210
.BYTE	220
.BYTE	212
.BYTE	213
.BYTE	214
.BYTE	215

.....	0
.....	1
.....	2
.....	3
.....	4
.....	5
.....	6
.....	7
.....	8
.....	9
.....	10
.....	11
.....	12
.....	13
.....	14
.....	15
.....	16
.....	17
.....	18
.....	19
.....	20
.....	21
.....	22
.....	23
.....	24
.....	25
.....	26
.....	27
.....	28
.....	29
.....	30
.....	31
.....	32
.....	33
.....	34
.....	35
.....	36
.....	37
.....	38
.....	39
.....	40
.....	41
.....	42
.....	43
.....	44
.....	45
.....	46
.....	47
.....	48
.....	49
.....	50
.....	51
.....	52
.....	53
.....	54
.....	55
.....	56
.....	57
.....	58
.....	59
.....	60
.....	61
.....	62
.....	63
.....	64
.....	65
.....	66
.....	67
.....	68
.....	69
.....	70
.....	71
.....	72
.....	73
.....	74
.....	75
.....	76
.....	77
.....	78

.....	0
.....	1
.....	2
.....	3
.....	4
.....	5
.....	6
.....	7
.....	8
.....	9
.....	10
.....	11
.....	12
.....	13
.....	14
.....	15
.....	16
.....	17
.....	18
.....	19
.....	20
.....	21
.....	22
.....	23
.....	24
.....	25
.....	26
.....	27
.....	28
.....	29
.....	30
.....	31
.....	32
.....	33
.....	34
.....	35
.....	36
.....	37
.....	38
.....	39
.....	40
.....	41
.....	42
.....	43
.....	44
.....	45
.....	46
.....	47
.....	48
.....	49
.....	50
.....	51
.....	52
.....	53
.....	54
.....	55
.....	56
.....	57
.....	58
.....	59
.....	60
.....	61
.....	62
.....	63
.....	64
.....	65
.....	66
.....	67
.....	68
.....	69
.....	70
.....	71
.....	72
.....	73
.....	74
.....	75
.....	76
.....	77
.....	78

NUMTUN

NUMTUN

NUMTUN

NUMTUN

SPACE

BLANK



2861	013472	005353
2862	013474	005454
2863	013476	005656
2864	013500	005757
2865	013502	006060
2866	013504	006161
2867	013506	006262
2868	013510	006363
2869	013512	006464
2870	013514	006565
2871	013516	006767
2872	013520	007070
2873	013522	007171
2874	013524	007272
2875	013526	007373
2876	013530	007474
2877	013532	007575
2878	013534	007676
2879	013536	000101
2880	013540	000202
2881	013542	000303
2882	013544	000404
2883	013546	000505
2884	013550	000606
2885	013552	000707
2886	013554	003210
2887	013556	000123
2888	013560	007654
2889	013562	004567

5353  
5454  
5656  
5757  
6060  
6161  
6262  
6363  
6464  
6565  
6767  
7070  
7171  
7272  
7373  
7474  
7575  
7676  
0101  
0202  
0303  
0404  
0505  
0606  
0707  
3210  
0123  
7654  
4567

:52  
:53  
:54  
:55  
:56  
:57  
:58  
:59  
:60  
:61  
:62  
:63  
:64  
:65  
:66  
:67  
:68  
:69  
:70  
:71  
:72  
:73  
:74  
:75  
:76  
:77  
:78  
:79  
:80

BINEND: 4567

: BINARY DECK DATA TABLE  
: THE VALUE IS THE ENCODED VALUE, WHICH ORS THE OCTAL REPRESENTATION OF  
: ROWS ONE THRU SEVEN

2894		
2895	013564	000
2896	013565	020
2897	013566	010
2898	013567	007
2899	013570	006
2900	013571	005
2901	013572	004
2902	013573	003
2903	013574	002
2904	013575	001
2905	013576	040
2906	013577	100
2907	013600	200
2908	013601	067
2909	013602	117
2910	013603	177
2911	013604	207
2912	013605	267
2913	013606	317
2914	013607	377
2915	013610	046
2916	013611	056

BINCDP: .BYTE 0  
.BYTE 20  
.BYTE 10  
.BYTE 7  
.BYTE 6  
.BYTE 5  
.BYTE 4  
.BYTE 3  
.BYTE 2  
.BYTE 1  
.BYTE 40  
.BYTE 100  
.BYTE 200  
.BYTE 67  
.BYTE 117  
.BYTE 177  
.BYTE 207  
.BYTE 267  
.BYTE 317  
.BYTE 377  
.BYTE 46  
.BYTE 56

COLUMN	ASCII	PUNCH
:1	SPACE	BLANK
:2		
:3		
:4		
:5		
:6		
:7		
:8		
:9		
:10		
:11		
:12		
:13		
:14		
:15		
:16		
:17		
:18		
:19		
:20		
:21		
:22		

2917	013612	077
2918	013613	047
2919	013614	067
2920	013615	057
2921	013616	077
2922	013617	105
2923	013620	127
2924	013621	137
2925	013622	107
2926	013623	127
2927	013624	117
2928	013625	137
2929	013626	147
2930	013627	167
2931	013630	157
2932	013631	147
2933	013632	167
2934	013633	157
2935	013634	177
2936	013635	204
2937	013636	227
2938	013637	216
2939	013640	237
2940	013641	227
2941	013642	217
2942	013643	237
2943	013644	246
2944	013645	267
2945	013646	256
2946	013647	277
2947	013650	247
2948	013651	257
2949	013652	277
2950	013653	205
2951	013654	227
2952	013655	217
2953	013656	237
2954	013657	207
2955	013660	227
2956	013661	237
2957	013662	247
2958	013663	267
2959	013664	257
2960	013665	277
2961	013666	247
2962	013667	267
2963	013670	257
2964	013671	023
2965	013672	012
2966	013673	033
2967	013674	007
2968	013675	027
2969	013676	017
2970	013677	037
2971	013700	146
2972	013701	037

.BYTE	77
.BYTE	47
.BYTE	67
.BYTE	57
.BYTE	77
.BYTE	105
.BYTE	127
.BYTE	137
.BYTE	107
.BYTE	127
.BYTE	117
.BYTE	137
.BYTE	147
.BYTE	167
.BYTE	157
.BYTE	147
.BYTE	167
.BYTE	157
.BYTE	177
.BYTE	204
.BYTE	227
.BYTE	216
.BYTE	237
.BYTE	227
.BYTE	217
.BYTE	237
.BYTE	246
.BYTE	267
.BYTE	256
.BYTE	277
.BYTE	247
.BYTE	257
.BYTE	277
.BYTE	205
.BYTE	227
.BYTE	217
.BYTE	237
.BYTE	207
.BYTE	227
.BYTE	237
.BYTE	247
.BYTE	267
.BYTE	257
.BYTE	277
.BYTE	247
.BYTE	267
.BYTE	257
.BYTE	277
.BYTE	247
.BYTE	267
.BYTE	257
.BYTE	23
.BYTE	12
.BYTE	33
.BYTE	7
.BYTE	27
.BYTE	17
.BYTE	37
.BYTE	146
.BYTE	37

23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67
68
69
70
71
72
73
74
75
76
77
78

2973	013702	347							
2974	013703	237				BINENP:	.BYTE	347	:79
2975							.BYTE	237	:80
2976	013704	020040	020040	040			.ASCII	/	/
2977	013711	040	000040			SPACE:	.ASCIZ	/	/
2978	013714	005012	012				.ASCII	<12><12><12>	
2979	013717	015	000012			CRLF:	.ASCIZ	<15><12>	
2980									
2981	013722	005015	051120	051505		MSG1:	.ASCIZ	<15><12>/PRESS CARD READER 'RESET' /	
2982	013730	020123	040503	042122					
2983	013736	051040	040505	042504					
2984	013744	020122	051047	051505					
2985	013752	052105	000047						
2986	013756	005015	044124	047105		MSG2:	.ASCIZ	<15><12>/THEN HIT 'CONTINUE' ON THE CONSOLE /	
2987	013764	044040	052111	023440					
2988	013772	047503	052116	047111					
2989	014000	042525	020047	047117					
2990	014006	052040	042510	041440					
2991	014014	047117	047523	042514					
2992	014022	000							
2993	014023	015	050012	042522		MSG3:	.ASCIZ	<15><12>/PRESS CARD READER 'STOP' /	
2994	014030	051523	041440	051101					
2995	014036	020104	042522	042101					
2996	014044	051105	023440	052123					
2997	014052	050117	000047						
2998	014056	005015	044124	020105		MSG4:	.ASCIZ	<15><12>/THE INTERRUPT LEVEL WAS /	
2999	014064	047111	042524	051122					
3000	014072	050125	020124	042514					
3001	014100	042526	020114	040527					
3002	014106	020123	000						
3003	014111	015	051012	046505		MSG5:	.ASCIZ	<15><12>/REMOVE ALL CARDS FROM THE INPUT HOPPER /	
3004	014116	053117	020105	046101					
3005	014124	020114	040503	042122					
3006	014132	020123	051106	046517					
3007	014140	052040	042510	044440					
3008	014146	050116	052125	044040					
3009	014154	050117	042520	000122					
3010	014162	005015	042522	052123		MSG6:	.ASCIZ	<15><12>/RESTORE CARDS TO THE INPUT HOPPER /	
3011	014170	051117	020105	040503					
3012	014176	042122	020123	047524					
3013	014204	052040	042510	044440					
3014	014212	050116	052125	044040					
3015	014220	050117	042520	000122					
3016	014226	005015	052520	046114		MSG7:	.ASCII	<15><12>/PULL OUTPUT STACKER PRESSURE ARM DOWN /	
3017	014234	047440	052125	052520					
3018	014242	020124	052123	041501					
3019	014250	042513	020122	051120					
3020	014256	051505	052523	042522					
3021	014264	040440	046522	042040					
3022	014272	053517	020116						
3023	014276	047125	044524	020114			.ASCIZ	/UNTIL HOPPER CHECK LIGHTS /	
3024	014304	047510	050120	051105					
3025	014312	041440	042510	045503					
3026	014320	046040	043511	052110					
3027	014326	000123							
3028	014330	005015	047510	042114		MSG8:	.ASCII	<15><12>/HOLD DOWN THE SWITCH UNDER THE CAP OF THE INPUT /	

3029	014336	042040	053517	020116
3030	014344	044124	020105	053523
3031	014352	052111	044103	052440
3032	014360	042116	051105	052040
3033	014366	042510	041440	050101
3034	014374	047440	020106	044124
3035	014402	020105	047111	052520
3036	014410	020124		
3037	014412	047510	050120	051105
3038	014420	000		
3039	014421	015	051412	044514
3040	014426	042504	040440	041440
3041	014434	051101	020104	051106
3042	014442	046517	052040	042510
3043	014450	047440	052125	052520
3044	014456	020124	047510	050120
3045	014464	051105	040440	047502
3046	014472	052125	044040	046101
3047	014500	020106	047101	044440
3048	014506	041516	020110	
3049	014512	005015	020040	040502
3050	014520	045503	044440	052116
3051	014526	020117	044124	020105
3052	014534	042522	042101	044040
3053	014542	040505	026104	041040
3054	014550	047514	045503	047111
3055	014556	020107	044124	020105
3056	014564	044120	052117	020117
3057	014572	042503	046114	000
3058	014577	015	051012	046505
3059	014604	053117	020105	040512
3060	014612	046515	042105	041440
3061	014620	051101	000104	
3062	014624	005015	047510	042114
3063	014632	052040	042510	047440
3064	014640	052125	052520	020124
3065	014646	052123	041501	042513
3066	014654	020122	040507	042524
3067	014662	047440	042520	027116
3068	014670	052040	042510	000116
3069	014676	005015	046120	041501
3070	014704	020105	050123	041505
3071	014712	040511	020114	040504
3072	014720	045522	046055	043511
3073	014726	052110	041440	042510
3074	014734	045503	041440	051101
3075	014742	020104	047117	054514
3076	014750	024040	042523	020105
3077	014756	027067	027062	020062
3078	014764	043117	040	
3079	014767	124	042510	053440
3080	014774	044522	042524	052455
3081	015002	024520		
3082	015004	005015	052101	052040
3083	015012	042510	041040	052117
3084	015020	047524	020115	043117

.ASCIZ /HOPPER/

MSG9: .ASCII <15><12>/SLIDE A CARD FROM THE OUTPUT HOPPER ABOUT HALF AN INCH /

.ASCIZ <15><12>/ BACK INTO THE READ HEAD, BLOCKING THE PHOTO CELL/

MSG10: .ASCIZ <15><12>/REMOVE JAMMED CARD/

MSG11: .ASCIZ <15><12>/HOLD THE OUTPUT STACKER GATE OPEN. THEN/

MSG12: .ASCII <15><12>/PLACE SPECIAL DARK-LIGHT CHECK CARD ONLY (SEE 7.2.2 OF /

.ASCII /THE WRITE-UP)/

.ASCIZ <15><12> /AT THE BOTTOM OF THE INPUT STACK/

3085	015026	052040	042510	044440	
3086	015034	050116	052125	051440	
3087	015042	040524	045503	000	
3088	015047	015	042012	041505	MSG13: .ASCIZ <15><12>/DECK CARD COLUMN PATTERN READ/
3089	015054	020113	020040	041440	
3090	015062	051101	020104	020040	
3091	015070	041440	046117	046525	
3092	015076	020116	050040	052101	
3093	015104	042524	047122	051040	
3094	015112	040505	000104		
3095	015116	005015	046101	044120	MSG14: .ASCIZ <15><12>/ALPHA /
3096	015124	020101	000		
3097	015127	015	041012	047111	MSG15: .ASCIZ <15><12>/BINARY/
3098	015134	051101	000131		
3099	015140	005015	044502	020124	MSG16: .ASCIZ <15><12>/BIT 15 WAS SET/
3100	015146	032461	053440	051501	
3101	015154	051440	052105	000	
3102	015161	015	051012	046505	MSG17: .ASCIZ <15><12>/REMEDY THE ERROR CONDITION AND PRESS 'CONTINUE' /
3103	015166	042105	020131	044124	
3104	015174	020105	051105	047522	
3105	015202	020122	047503	042116	
3106	015210	052111	047511	020116	
3107	015216	047101	020104	051120	
3108	015224	051505	020123	041447	
3109	015232	047117	044524	052516	
3110	015240	023505	000		
3111	015243	015	041012	052111	MSG18: .ASCIZ <15><12>/BIT 12 WAS SET/
3112	015250	030440	020062	040527	
3113	015256	020123	042523	000124	
3114	015264	005015	047503	052514	MSG19: .ASCIZ <15><12>/COLUMN READ CARDS ERRORS/
3115	015272	047115	051040	040505	
3116	015300	020104	041440	051101	
3117	015306	051504	042440	051122	
3118	015314	051117	000123		
3119	015320	005015	052520	020124	MSG20: .ASCIZ <15><12>/PUT ANY TWO CARDS IN INPUT HOPPER/
3120	015326	047101	020131	053524	
3121	015334	020117	040503	042122	
3122	015342	020123	047111	044440	
3123	015350	050116	052125	044040	
3124	015356	050117	042520	000122	
3125	015364	005015	051120	051505	MSG21: .ASCIZ <15><12>/PRESS END OF FILE BUTTON/
3126	015372	020123	047105	020104	
3127	015400	043117	043040	046111	
3128	015406	020105	052502	052124	
3129	015414	047117	000		
3130	015417	015	053412	042510	MSG22: .ASCIZ <15><12>/WHEN PRINTING STOPS PUT HALT AND/
3131	015424	020116	051120	047111	
3132	015432	044524	043516	051440	
3133	015440	047524	051520	050040	
3134	015446	052125	044040	046101	
3135	015454	020124	047101	000104	
3136	015462	005015	044523	043516	MSG23: .ASCIZ <15><12>/SINGLE BUS CYCLE DOWN, AND HIT 'CONTINUE' ON THE/
3137	015470	042514	041040	051525	
3138	015476	041440	041531	042514	
3139	015504	042040	053517	026116	
3140	015512	040440	042116	044040	

3141	015520	052111	023440	047503
3142	015526	052113	047111	042525
3143	015534	020047	047117	052040
3144	015542	042510	000	
3145	015545	015	041412	047117
3146	015552	047523	042514	052440
3147	015560	052116	046111	047440
3148	015566	042516	041440	051101
3149	015574	020104	051511	051040
3150	015602	040505	000104	
3151	015606	005015	044124	047105
3152	015614	050040	052125	052440
3153	015622	020120	044124	020105
3154	015630	053524	020117	053523
3155	015636	052111	044103	051505
3156	015644	040440	042116	044040
3157	015652	052111	000	
3158	015655	015	023412	047503
3159	015662	052116	047111	042525
3160	015670	020047	047117	052040
3161	015676	042510	041440	047117
3162	015704	047523	042514	000
3163		015712		

MSG24: .ASCIZ <15><12>/CONSOLE UNTIL ONE CARD IS READ/

MSG25: .ASCIZ <15><12>/THEN PUT UP THE TWO SWITCHES AND HIT/

MSG26: .ASCIZ <15><12>/'CONTINUE' ON THE CONSOLE/

.EVEN



```

3164
3165 015712 012767 015742 162104 POWR: MOV #RESTOR,24
3166 015720 010046 MOV %0,-(6)
3167 015722 010146 MOV %1,-(6)
3168 015724 010246 MOV %2,-(6)
3169 015726 010346 MOV %3,-(6)
3170 015730 010446 MOV %4,-(6)
3171 015732 010546 MOV %5,-(6)
3172 015734 010667 000036 MOV %6,SAVE
3173 015740 000000 HALT
3174
3175
3176 015742 012767 015712 162054 RESTOR: MOV #POWR,24
3177 015750 016706 000022 MOV SAVE,%6
3178 015754 012605 MOV (6)+,%5
3179 015756 012604 MOV (6)+,%4
3180 015760 012603 MOV (6)+,%3
3181 015762 012602 MOV (6)+,%2
3182 015764 012601 MOV (6)+,%1
3183 015766 012600 MOV (6)+,%0
3184 015770 016716 174440 MOV RETURN,(6) ;START TEST OVER
3185 015774 000002 RTI
3186
3187 015776 000000 SAV6: 0
3188
3189 016000 000000 BUFBEQ: 0
3190 000001 .END

```

N05

MAINDEC-11-DZCDA-C-D  
DZCDA.P11

CD11 CARD READER DIAGNOSTICS  
CROSS REFERENCE TABLE -- USER SYMBOLS

MACY11 27(732) 15-OCT-76 16:01 PAGE 67

ADINT =%000002

ALLDON 006330  
ALPCD 012744  
ALPCDP 013204  
ALPEND 013202  
ALFENP 013323  
ALPI 004332  
BEGIN 001000  
BELL 012162  
BINCD 013324  
BINCDP 013564  
BINEND 013562  
BINENP 013703  
BKGND 004520  
BKGND1 004532  
BUFBEQ 016000  
  
BUFEND 006510  
B.CK 012324  
CARDIM 012126  
CDA =%000005  
  
CDBA 000506  
CDC =%000004  
  
CDCC 000504  
CDCNT 006522  
  
CDPK0 012130  
CDPK1 012131  
CDREAD 004516  
CCS =%000003

660*	737*	738*	905*	907*	914	926*	933*	935*	945*	957*	959*	967
969*	981*	997*	999*	1007	1009*	1021*	1037*	1039*	1047	1049*	1061*	1077*
1079*	1087	1089*	1101*	1114*	1116*	1124	1126*	1138*	1154*	1156*	1164	1166*
1178*	1194*	1196*	1204	1206*	1214*	1231*	1233*	1241	1248*	1253*	1255*	1262*
1265	1271*	1276*	1278*	1286*	1361*	1363*	1730*	1848*	1850*	1874*	1876*	1898*
1900*	1947*	1949*	1958*	1960*	1996*	1998*	2006*	2008*	2053*	2065*	2074*	2076*
2128*	2130*	2139*	2141*	2203*	2205*	2228*	2302*	2304*				
1698	1701*											
1348	2643*											
2727*												
1349	2722*											
2806*												
1343	1348*											
691	750*											
1324	1703	2314	2418	2485*								
1344	2810*											
2895*												
1345	2889*											
2974*												
1377*	1378	1383										
1380*	1381											
845	879	910	937	963	1003	1043	1083	1120	1160	1200	1236	1258
1365	1651	1783	1963	2011	2043	2079	2108	2144	2209	2282	2392	3189*
1399*	1400*	1401*	1402	1516*	1517*	1518	1752*					
2504	2518*											
2361*	2362*	2363	2409	2466*								
663*	736*	774	822*	823	832	845*	879*	910*	937*	963*	1003*	1043*
1083*	1120*	1160*	1200*	1236*	1258*	1281*	1311	1369*	1402	1518	1652*	1783*
1963*	2011*	2043*	2079*	2108*	2144*	2209*	2282*	2394*				
716*	736											
662*	735*	770	802*	803	812	844*	878*	909*	936*	962*	1002*	1042*
1082*	1119*	1159*	1199*	1235*	1257*	1280*	1315	1368*	1379	1395	1513	1650*
1782*	1962*	2010*	2042*	2078*	2107*	2143*	2208*	2281*	2393*			
715*	735											
1340*	1429	1432*	1454*	1543	1548	1551*	1573*	1661	1673*	1674	1676*	1687
1696*	1697	1757*										
2363*	2365*	2367*	2373*	2467*								
2366*	2368*	2369*	2370*	2371*	2376*	2403	2468*					
1372	1374	1376*										
661*	734*	766	782*	783	789*	790	795*	796	807	811*	816	827
831*	836	849*	850	854	861	864	868	877*	880*	881	887	894
898	911*	912	915*	918	922	925*	938*	939	944*	964*	965	968*
977	980*	1004*	1005	1008*	1017	1020*	1044*	1045	1048*	1057	1060*	1084*
1085	1088*	1097	1100*	1121*	1122	1125*	1134	1137*	1161*	1162	1165*	1174
1177*	1201*	1202	1205*	1210	1213*	1237*	1242*	1246*	1259*	1269*	1282*	1287
1291	1295	1299	1303	1307	1370*	1376*	1377	1380	1386	1389	1393	1475
1477	1487	1491	1495	1499	1503	1506	1511	1544*	1594	1596	1603	1605
1616	1620	1624	1628	1631	1653*	1662*	1716	1718	1722	1726	1734	1785*
1786	1790	1794	1798	1811	1815	1819	1828	1832	1836	1840	1852*	1855
1862	1866	1870	1878*	1882	1886	1890	1894	1907	1911	1915	1919	1931
1935	1939	1943	1951*	1964*	1968	1980	1984	1988	1992	2000*	2012*	2016
2032	2036	2038	2044*	2045	2047	2051	2055	2059	2067*	2080*	2084	2099
2101	2103	2109*	2110	2112	2116	2120	2124	2132*	2145*	2149	2173	2182
2187	2192	2196	2207*	2210*	2216	2220	2224	2232	2236	2240	2245	2255
2259	2273	2275	2277	2283*	2284	2286	2290	2294	2298	2306*	2389*	2395*
2397	2399	2416	2419	2423	2476	2478*	2479	2492	2515			









TESTH	011036	2163	2267#				
TESTI	010514	2162	2165#				
TESTX	011246	697	2323#				
TEST1	001056	763#	2544				
TEST1A	001060	762	764#				
TEST10	001652	929#					
TEST11	001740	955#					
TEST12	002154	972	974	976	990	992	995#
TEST13	002370	1012	1014	1016	1030	1032	1035#
TEST14	002604	1052	1054	1056	1070	1072	1075#
TEST15	003002	1092	1094	1096	1107	1109	1112#
TEST16	003216	1129	1131	1133	1147	1149	1152#
TEST17	003432	1169	1171	1173	1187	1189	1192#
TEST2	001112	778#					
TEST20	003630	1209	1223	1225	1228#		
TEST21	003740	1250#					
TEST22	004054	1273#					
TEST3	001160	786	800#				
TEST4	001230	820#					
TEST5	001300	840#					
TEST6	001420	857	867	872#			
TEST7	001530	892	902#				
TINA21	004036	1262	1267#				
TINTC	007106	1848	1859#				
TINTCA	007170	1874	1881#				
TINTCB	007266	1898	1906#				
TINTD	007460	1947	1957#				
TINTDA	007524	1958	1967#				
TINTE	007664	1996	2005#				
TINTEA	007730	2006	2015#				
TINTF	010150	2063	2073#				
TINTFA	010214	2074	2083#				
TINTG	010424	2128	2138#				
TINTGA	010470	2139	2148#				
TINTH	011232	2302	2312#				
TINTI	010700	2203	2214#				
TINTIA	010736	2228	2230#				
TINT10	001722	933	942#				
TINT11	002064	957	977#				
TINT12	002300	997	1017#				
TINT13	002514	1037	1057#				
TINT14	002730	1077	1097#				
TINT15	003126	1114	1134#				
TINT16	003342	1154	1174#				
TINT17	003540	1194	1210#				
TINT20	003722	1231	1244#				
TINT21	004012	1253	1261#				
TINT22	004126	1276	1284#				
TINT7	001622	905	918#				
TLOPC	007076	1855#	1856				
TLOPG	010254	2099#	2100				
TLOPGA	010262	2101#	2102				
TLOPGB	010312	2110#	2111				
TLOPH	011060	2273#	2274				
TLOPHA	011066	2275#	2276				
TLOPHB	011116	2284#	2285				







.SSAVE	18
.SSB2D	18
.SSB20	18
.SSCOP	18
.SSIZE	18
.SSUPR	18
.STRAP	18
.STYPB	18
.STYPD	18
.STYPE	18
.STYPO	18
.S4OCA	18
.1170	18

ADD	1435	1444	1450	1543	1554	1563	1569	1640	1658	1659	1660	1689	2326	2572	
BCC	2374														
BEQ	767	771	775	784	791	797	804	808	813	817	824	828	833	837	855
	869	882	972	1012	1052	1092	1129	1169	1308	1312	1316	1323	1343	1372	1378
	1390	1396	1403	1413	1476	1488	1492	1496	1500	1504	1514	1519	1528	1595	1604
	1617	1621	1625	1629	1705	1712	1717	1727	1743	1799	1820	1833	1841	1856	1871
	1895	1912	1920	1944	1969	1993	2017	2037	2039	2060	2085	2100	2102	2104	2125
	2150	2162	2174	2183	2188	2193	2217	2221	2256	2260	2274	2276	2278	2299	2329
	2386	2417	2420	2424	2480	2503	2563	2623	2626						
BGE	1483	1698													
BGT	1443	1449	1562	1568	1649	2428									
BIC	908	915	960	1000	1040	1080	1117	1157	1197	1256	1279	1362	1544	1851	1877
	1901	1950	1961	1999	2009	2066	2077	2131	2142	2206	2305	2330	2362		
BIS	782	811	831	906	934	958	961	998	1001	1038	1041	1078	1081	1115	1118
	1155	1158	1195	1198	1232	1254	1277	1662	1849	1875	1899	1948	1959	1997	2007
	2064	2075	2129	2140	2204	2303	2332	2389							
BISB	2376	2627													
BIT	757	854	868	881	1295	1299	1303	1307	1322	1342	1355	1371	1373	1377	1380
	1389	1393	1423	1455	1475	1477	1487	1491	1495	1499	1503	1506	1511	1538	1574
	1594	1596	1599	1603	1605	1616	1620	1624	1628	1631	1644	1711	1716	1722	1726
	1734	1742	1794	1798	1811	1819	1828	1832	1840	1855	1870	1886	1894	1907	1911
	1919	1931	1939	1943	1980	1988	1992	2032	2036	2047	2055	2059	2099	2101	2112
	2120	2124	2173	2182	2187	2192	2216	2220	2232	2236	2240	2255	2259	2273	2275
	2286	2294	2298	2328	2385	2387	2416	2419	2423	2433	2492	2502	2529	2531	
BLE	1437	1556													
BLT	1611	2580													
BMI	862	888	895	919	974	978	985	1014	1018	1025	1054	1058	1065	1094	1098
	1105	1131	1135	1142	1171	1175	1182	1211	1218	1288	1292	1387	1410	1471	1525
	1590	1641	1690	1719	1816	1937	1863	1867	1883	1891	1916	1936	1985	2052	2117
	2246	2291	2400												
BNE	754	758	859	890	1240	1296	1300	1304	1352	1356	1374	1381	1394	1408	1416
	1424	1430	1434	1440	1452	1456	1478	1507	1512	1523	1531	1539	1549	1553	1559
	1571	1575	1597	1600	1606	1632	1645	1667	1723	1735	1787	1791	1795	1812	1829
	1887	1908	1932	1940	1981	1989	2033	2048	2056	2113	2121	2233	2237	2241	2287
	2295	2378	2388	2404	2407	2410	2413	2434	2436	2493	2530	2532	2569	2576	2629
	2631														
BPL	851	865	899	913	923	940	966	992	1006	1032	1046	1072	1086	1109	1123
	1149	1163	1189	1203	1225	1465	1585	2046	2111	2197	2225	2285	2398	2402	2426
	2444	2460	2477	2486	2519	2534	2584								
BR	752	756	786	857	867	892	917	941	976	990	1016	1030	1056	1070	1096
	1107	1133	1147	1173	1187	1209	1223	1243	1260	1266	1283	1347	1354	1383	1419
	1445	1467	1473	1480	1485	1534	1564	1587	1592	1608	1643	1647	1714	1732	1857
	1879	1904	1955	1965	2003	2013	2071	2081	2136	2146	2211	2229	2310	2331	2408
	2414	2421	2430	2448	2462	2498	2504	2565	2582	2605	2608	2614			
CLR	739	740	741	789	847	848	877	884	886	925	927	944	946	968	970
	980	982	1008	1010	1020	1022	1048	1050	1060	1062	1088	1090	1100	1102	1125
	1127	1137	1139	1165	1167	1177	1179	1205	1207	1213	1215	1234	1238	1242	1246
	1247	1263	1269	1270	1285	1339	1340	1341	1382	1454	1573	1695	1763	1768	2333
	2337	2364	2381	2382	2383	2391	2539	2609							
CLRB	2384	2604	2613	2615	2633										
CMP	766	783	790	796	803	807	816	823	827	836	921	943	973	983	991
	1013	1023	1031	1053	1063	1071	1093	1103	1108	1130	1140	1148	1170	1180	1188
	1215	1224	1245	1261	1267	1284	1311	1315	1402	1407	1409	1415	1433	1436	1439
	1442	1448	1451	1463	1518	1524	1530	1555	1561	1567	1570	1691	1697	1702	1738
	1747	1881	1906	1957	1967	1968	2005	2015	2016	2038	2073	2083	2084	2103	2138
	2148	2149	2214	2230	2277	2312	2406	2409	2412	2479	2507	2533	2536	2630	

CMPB	1522	1552	1558	1583	2403	2427	2575								
COM	1325	1741													
COMB	2390														
DEC	889	1676	1681	2377											
DECB	2579														
EMT	654														
HALT	670	1466	1586	1713	1784	1810	1826	1930	1979	2031	2171	2179	2253	2311	2324
	2327	2360	2379	2461	2497	2520	2564	3173							
INC	849	858	880	1239	1376	1412	1414	1432	1527	1529	1551	1653	1668	1673	1678
	1688	1696	1785	1878	1964	2012	2044	2080	2109	2145	2210	2283	2375	2395	2396
	2405	2411	2432	2437	2535										
INCB	2624	2628													
IOT	656														
JMP	691	694	697	701	707	1326	1391	1426	1509	1545	1612	1614	1634	1744	1745
	1748	1764	2163	2315	2336	2338	2538								
JSR	751	764	843	876	904	932	956	989	996	1029	1036	1069	1076	1113	1146
	1153	1186	1193	1222	1230	1252	1275	1324	1358	1375	1417	1421	1425	1457	1459
	1462	1482	1532	1536	1576	1579	1582	1610	1648	1675	1680	1703	1707	1766	1774
	1806	1847	1926	1974	2024	2092	2166	2178	2268	2314	2323	2359	2380	2418	2441
	2446	2451	2455	2458	2475	2510	2513	2516	2574	2581					
MOV	690	693	696	700	706	733	734	735	736	737	738	742	750	755	759
	762	795	802	822	844	845	846	860	878	879	885	893	905	907	909
	910	911	914	926	933	935	936	937	938	945	957	959	962	963	964
	967	969	981	986	988	997	999	1002	1003	1004	1007	1009	1021	1026	1028
	1037	1039	1042	1043	1044	1047	1049	1061	1066	1068	1077	1079	1082	1083	1084
	1087	1089	1101	1106	1114	1116	1119	1120	1121	1124	1126	1138	1143	1145	1154
	1156	1159	1160	1161	1164	1166	1178	1183	1185	1194	1196	1199	1200	1201	1204
	1206	1214	1219	1221	1231	1233	1235	1236	1237	1241	1248	1253	1255	1257	1258
	1259	1262	1265	1271	1276	1278	1280	1281	1282	1286	1344	1345	1346	1348	1349
	1350	1353	1357	1361	1363	1364	1365	1366	1367	1368	1369	1370	1379	1399	1406
	1411	1453	1458	1461	1516	1521	1526	1572	1602	1642	1646	1650	1651	1652	1674
	1679	1686	1687	1704	1730	1765	1767	1782	1783	1848	1850	1852	1874	1876	1898
	1900	1947	1949	1951	1958	1960	1962	1963	1996	1998	2000	2006	2008	2010	2011
	2042	2043	2063	2065	2067	2074	2076	2078	2079	2107	2108	2128	2130	2132	2139
	2141	2143	2144	2203	2205	2207	2208	2209	2228	2281	2282	2302	2304	2306	2325
	2334	2335	2358	2361	2363	2372	2392	2393	2394	2440	2450	2454	2457	2478	2487
	2505	2506	2509	2512	2515	2537	2540	2566	2567	2571	2577	2601	2602	2603	2611
	2612	2635	3165	3166	3167	3168	3169	3170	3171	3172	3176	3177	3178	3179	3180
	3181	3182	3183	3184											
MOVB	1578	1581	2445	2568	2585	2607	2610	2632							
NOP	1264	1708	1709	1710											
RESET	765	1706													
ROL	2616	2618	2620												
ROLB	2366	2368	2359	2370	2371	2617	2619	2621							
ROR	2365	2373													
RORB	2367														
RTI	719	1654	1860	2521	2541	2573	3185								
RTS	743	1663	1683	1692	1699	2482	2488	2494	2586	2636					
SUB	1400	1401	1438	1441	1447	1517	1540	1541	1542	1557	1560	1566	1661		
TRAP	655														
TST	753	770	774	812	832	864	898	922	971	984	1011	1024	1051	1064	1091
	1104	1123	1141	1168	1181	1217	1291	1351	1395	1418	1422	1429	1431	1464	1513
	1548	1584	1666	1701	1718	1790	1815	1836	1866	1890	1915	1935	1984	2051	2116
	2161	2196	2224	2245	2290	2399	2401	2425	2435	2443	2452	2459	2518	2570	
TSTB	850	861	887	894	912	918	939	965	977	1005	1017	1045	1057	1085	1097
	1122	1134	1162	1174	1202	1210	1287	1386	1533	1537	1550	1786	1862	1882	2045

	2110	2284	2397	2447	2476	2485	2562	2583	2622	2625					
WAIT	1731														
.ABS	668														
.ASCII	2976	2978	3016	3028	3039	3069	3079								
.ASCIZ	2977	2979	2981	2986	2993	2998	3003	3010	3023	3037	3049	3058	3062	3082	3088
	3095	3097	3099	3102	3111	3114	3119	3125	3130	3136	3145	3151	3158		
.BYTE	2467	2468	2557	2558	2559	2560	2599	2727	2728	2729	2730	2731	2732	2733	2734
	2735	2736	2737	2738	2739	2740	2741	2742	2743	2744	2745	2746	2747	2748	2749
	2750	2751	2752	2753	2754	2755	2756	2757	2758	2759	2760	2761	2762	2763	2764
	2765	2766	2767	2768	2769	2770	2771	2772	2773	2774	2775	2776	2777	2778	2779
	2780	2781	2782	2783	2784	2785	2786	2787	2788	2789	2790	2791	2792	2793	2794
	2795	2796	2797	2798	2799	2800	2801	2802	2803	2804	2805	2806	2895	2896	2897
	2898	2899	2900	2901	2902	2903	2904	2905	2906	2907	2908	2909	2910	2911	2912
	2913	2914	2915	2916	2917	2918	2919	2920	2921	2922	2923	2924	2925	2926	2927
	2928	2929	2930	2931	2932	2933	2934	2935	2936	2937	2938	2939	2940	2941	2942
	2943	2944	2945	2946	2947	2948	2949	2950	2951	2952	2953	2954	2955	2956	2957
	2958	2959	2960	2961	2962	2963	2964	2965	2966	2967	2968	2969	2970	2971	2972
	2973	2974													
.ENABL	1														
.END	3190														
.ENDC	976	990	1016	1030	1056	1070	1096	1107	1133	1147	1173	1187	1208	1209	1223
.EVEN	3163														
.IFEQ	976	1016	1056	1096	1133	1173	1208								
.IFNE	971	987	1011	1027	1051	1067	1091	1107	1128	1144	1168	1184	1208	1220	
.LIST	1	532	632	670	731	744	1333	1761	2317	2342	2470	2637	3164		
.MACR	687	688	954												
.MACRO	1														
.NLIST	1	532	632	670	731	744	1333	1761	2317	2342	2470	2637	3164		
.REM	1														
.REPT	670														
.SBTTL	532	632	731	744	1333	1761	2317	2342	2470	2637	3164				
.TITLE	533														
.WORD	2597														

ERRORS DETECTED: 0  
 DEFAULT GLOBALS GENERATED: 0

\* ,DZCDAC.SEG/SOL/CRF/PAGNUM/NL:TOC=SYSMAC.CO,DZCDAC.P11  
 RUN-TIME: 29 40 4 SECONDS  
 RUN-TIME RATIO: 126/74=1.6  
 CORE USED: 33K (65 PAGES)

