

DR11-L/M

EXERCISER
MD-11-DZDRH-A

EP-DZDRH-A-DL-A
COPYRIGHT © 1976
FICHE 1 OF 1

NOV 1976
digital
MADE IN USA

The image displays a grid of 150 small data tables or charts, arranged in 10 columns and 15 rows. Each cell in the grid contains a small, dense table of numbers and text, likely representing test results or performance metrics. The data is organized into a structured format, with columns and rows of varying lengths and content. The overall appearance is that of a technical document or a data log, possibly related to the 'EXERCISER' mentioned in the header. The text is small and difficult to read, but the layout is consistent across the grid.

IDENTIFICATION

Product Code: MAINDEC-11-DZDRH-A-D
Product Name: DR11-L, DR11-M Exerciser
Date Created: Sept. 1, 1975
Maintainer: Diagnostic Engineering
Author: Edward C. Badger

Copyright (C) 1975, Digital Equipment Corporation

This software is furnished under a license for use only on a single computer system and may be copied only with the inclusion of the above copyright notice. This software, or any other copies thereof, may not be provided or otherwise made available to any other person except for use on such system and to one who agrees to these license terms. Title to and ownership of the software shall at all times remain in Digital.

The information in this document is subject to change without notice and should not be construed as a commitment by Digital Equipment Corporation.

Digital Equipment Corporation assumes no responsibility for the use or reliability of its software on equipment which is not supplied by Digital.

TABLE OF CONTENTS

| | |
|------|---------------------|
| 1.0 | ABSTRACT |
| 2.0 | REQUIREMENTS |
| 3.0 | LOADING PROCEDURE |
| 4.0 | STARTING PROCEDURE |
| 5.0 | OPERATING PROCEDURE |
| 6.0 | ERRORS |
| 7.0 | RESTRICTIONS |
| 8.0 | MISCELLANEOUS |
| 9.0 | PROGRAM DESCRIPTION |
| 10.0 | FLOW CHARTS |
| 11.0 | LISTING |

1.0 ABSTRACT

This program allows the user to checkout or debug the DR11-L or DR11-M module (UNIBUS 2 word input interface or UNIBUS 2 word output interface). To run the logic test, the user must have a maintenance loop-back cable. Logic tests are limited and cannot check the input or output data paths. To check input or output data paths, some means of generating or detecting data changes is needed.

2.0 REQUIREMENTS

2.1 Equipment

1. PDP-11/Family computer with 4K of core or more and I/O terminal.
2. DR11L or DR11M (To be tested).
3. For logic test, maintenance loop-back cable. The maintenance loop-back cable is made up of a Berg Connector with 2 wires. One wire connects pin "V" with pin "VV". The other wire connects pin "X" with pin "TT".
4. For auto-slave, a master PDP-11 with DR11-M and this program.
5. For auto-master, a slave CPU (PDP-8 or PDP-11) with input module (DR11-L).
6. For auto-master/slave, a DR11L cabled to a DR11M.
7. For all other tests, some means of generating or detecting data changes.

2.2 Storage

This program occupies core locations 000000-017474.

3.0 LOADING PROCEDURE

3.1 Method

Procedure for normal binary tapes should be followed:

1. Absolute Loader must be in memory.
2. Place binary tape in reader.
3. Load address #7500 (*Determined by location of loader).
4. Press "START" (Program will load).

4.0 STARTING PROCEDURE

4.1 Control Switch Settings

Starting at SA200 or 210 set all switches as desired. See Section 5.1.

4.2 Starting Addresses

1. Load and start at location 200 for initial questions about SPC modules.
2. Load and start at location 210 to avoid questions if you wish to run the program with the same parameters as set by a start at 200.

NOTE

After loading program into core you
must initially start at location 200.

4.3 Program AND/OR Operator Action

1. Load program into core.
2. Set switch register to starting address.
3. Load address.
4. Set switches to desired settings - See Section 5.1.
5. Press start.
6. The program will type first question.

4.4 Program Questions

4.4.1 TERMINAL CHANGE REQUIRED (Y OR N)?

Respond by typing a Y or (no carriage return required) to represent YES or NO. If the program is started on the CPU's console TTY and you wish to change to a different TTY, type "Y", otherwise type "N".

4.4.2 KEYBOARD CSR ADDR. OF NEW TERMINAL?

Question asked only if YES was the response to 4.4.1. Respond by typing the keyboard CSR address of the new terminal.

4.4.3 ITS VECTOR ADDR.?

Question asked only if YES was the response to 4.4.1. Respond by typing the vector address of the new terminal's keyboard.

4.4.4 PRINTER CSR ADDR. OF NEW TERMINAL?

Question asked only if YES was the response to 4.4.1. Respond by typing the printer CSR address of the new terminal.

4.4.5 CSR ADDR. OF INPUT MODULE?

Respond by typing the CSR address of the word on the input module you wish to exercise. If you do not wish to exercise an input module, type only a carriage return.

4.4.6 CSR ADDR. OF OUTPUT MODULE?

Respond by typing the CSR address of the word on the output module you wish to exercise. If you do not wish to exercise an output module, type only a carriage return.

4.4.7 MODE?

Respond to this question by typing a character from "A" to "M" followed by carriage return. At any time (except logic tests) you may return to this question by typing "fC" (control and the letter "C" typed together).

| <u>MODE</u> | <u>MODULE AFFECTED</u> | <u>FUNCTION</u> |
|-------------|------------------------|--|
| A | output | Continuous output. Load data to the output module without checking for any flag. |
| B | output | Flag output. Check for output modules's "Ready" flag (bit7) and loads DBR with data. |
| C | output | Interrupt output. Program sets output module's interrupt enable. On interrupt it loads output modules DBR with data. |
| D | output | Delayed output. The program clears output modules CSR bit0; loads DBR with data; and then sets CSR bit0. |
| E | output | Start Auto Mode Master. This program may be used to generate data a a master to send to a slave CPU running slave mode. A table of data is outputted in modes A-D automatically. Mode "K" of program MD-11-DZDRH (for PDP-11's) or MD-08-DHDRH (for PDP-8's) must have been selected. Output word must be cabled to input word of DR11-M or DR8-ED. "Start Mode" is typed at the beginning of this mode. The program stalls waiting to link up with the input module its connected to. After link-up, "Immediate Send Mode" is typed. In this mode data from the table is sent directly out as soon as the input module |

is ready to receive it. If the input module detects an error in the data it receives, it can request a re-transmit of the previous data by setting the stat out bit thus setting the input module's stat in bit. If this occurs "Resending data xxxxx" will be typed. After this mode, "Burst Send Mode" is typed. In this mode the output module is allowed to interrupt for table data. "END PASS" is typed after completion.

Warning: Before starting the input or output module into "Start Mode", both CPU's should be running and waiting at "4.4.2 Mode?". At no time should the program be allowed to enter "Start Mode" and the other CPU initialized.

This mode was not designed to diagnose this module. Only data errors are checked. If any of the control signals fail the program could "hang" waiting for the signal. Maximum time between timeouts should not exceed 3 minutes - if it does, halt the CPU and determine the PC the program is at. Go to the listing for more information. Prints mentioned in the listing can be coordinated against the flow chart.

- F output Output Module Logic Test.
The program performs a brief logic check of the outputs module's CSR and interrupt capacities. A Maintenance loop-back must be installed in the word under test.
- G input Continuous input.
The program continuously reads the input module's DBR.
- H input Flag input.
The program waits for the "Ready" flag (CSR bit7) and then does a DBR read when bit7=1.
- I input Interrupt input.
The program sets interrupt enable and waits until the input module interrupts to read the module's DBR.
- J input Delayed input.
The program clears CSR bit0; reads the DBR; and then sets CSR bit0, thus delaying Data accept from returning.
- K input Start Auto Slave
The program may be used to receive data as a slave to receive data incoming from master CPU running in Master Mode (see Mode E), as data is received it is compared against a table of data. Modes G-J are automatically executed. If data received does not compare to the table, an error is reported.
- Mode "E" of MD-11-DZDRH must be selected in Master CPU. Input word must be cabled to the output word of a DR11-L.
- "Start Mode" is typed at the beginning of this mode. The program stalls waiting to link up with the output module its connected to. After link-up, "Immediate Send Mode" is typed. Each time data is ready, the data is read and compared against table data. "Burst Send Mode" is next. Here the input module is allowed to interrupt each time it receives data. "End Pass" is typed at completion.
- Warning: Before starting the input or output module into "Start Mode" both CPU's should be

running and waiting at "4.4.2 Mode?". At no time should the program be allowed to enter "Start Mode" and the other CPU be initialized.

This mode was not designed to diagnose this module. Only data errors are checked. If any of the control signals fail the program could "hang" waiting for the signal. Maximum time between timeouts should not exceed 3 minutes - if it does, halt the CPU and determine the PC the program is at. Go to the listing for more information. Points mentioned in the listing can be coordinated against the flow chart.

L input

Input Module Logic Test.
The program performs a brief logic check of the input modules CSR and interrupt capacities. A Maintenance loop back connector must be installed in the word under test.

M input-output

Start Auto Master-Slave.
Performs Modes E and K on an input and output mode located in the same CPU. The input word on the DR11-M must be cabled to the output word on the DR11-L.

4.4.8 SOURCE OF DATA?

This question is typed when an output Mode A-D is selected. What the program wants to know is where do you want to get the data that you want to output. Respond by typing a character from A-D followed by a carriage return.

- A Data from the Switch Register
- B Data from the TTY.
In this case, any future octal digits typed on the Keyboard will be assembled as data and each time a carriage return is typed the new data typed will be sent out.
- C Program generated pattern.
The program will automatically generate the data to be outputed in one of 4 ways specified by the operator by question 4.4.10.
- D Data is outputed from a table in core.
Data to be outputed can be found by finding the address of TABLE and looking in the listing.

4.4.9 STARTING PATTERN? (If Source of Data "C" Selected)

Respond by typing the octal representation of the data you wish to start outputting. This data will be modified according to the pattern modifier you select in 4.4.10.

4.4.10 PATTERN MODIFIER? (If source of Data "C" Selected)

Respond by typing a character from "A" to "D" to represent how you want the data that is being outputted to be modified.

| <u>MODIFIER</u> | <u>FUNCTION</u> |
|-----------------|-----------------------|
| A | INCREMENT DATA |
| B | DECREMENT DATA |
| C | FLOAT ZERO-COMPLEMENT |
| D | COMPLEMENT |

4.4.11 METHOD OF REPORTING DATA?

Respond by typing a character from "A" to "C" to represent the way you wish the data being received by the input module to be reported.

| <u>MEANS</u> | <u>METHOD</u> |
|--------------|--|
| A | in data lights |
| B | on TTY-reported each time a change in input data is detected. |
| C | Error check. An input module is cabled to an output module/data beginning sent to the output module is compared to the data received by the input module-if data is different an error is reported. After each 100 transfers are made, "END PASS" is reported. |
| D | Error Check. An input module is cabled to an |

output module in another CPU. This method only works when the "Source of Data" for the output module is that of the table "D".

On the output module side, you would select "Mode" "B" or "C"; "Source of Data" "D".

On the input module side, you would select "Mode" "H" or "I".

ERRORS detected as in modes "E" and "K".

5.0 OPERATING PROCEDURE LOGIC TEST

5.1 Definition - Switch Register

The program must, at various points in execution, determine what the operator desires to do at these points (such as "halt on error"). Standard procedure was to get this information from the hardware switch register. With the addition of CPU's to this family of computers that have no switch register, a hardware switch register can no longer be assumed. This program uses a software switch register; that is, a location in memory "SWREQ" as the source of "switch register" data.

5.1.1 Loading the Software Switch Register

The software switch register can be altered in two ways:

5.1.2 From the Hardware Switch Register

This way over-rides the other ways. Data loaded into the hardware switch register will be transferred to the software switch register directly each time "switch register" data is needed.

5.1.3 From the User's Terminal

A "FS" (control and letter "S" keys typed simultaneously) will cause the current software switch register to be typed out and allow the user to type in the new value of the switch register.

If a hardware switch register exists, and the user desires to use the software switch register, the user should leave the hardware switch register clear (all switches down).

NOTE 1

When using a pure software switch register "halt on error" is re-defined to "hold on error". If the CPU were allowed to halt, then core data could not be examined and the switch register data could not be altered. "Hold on error" sets in a loop testing software SWR bit 15, allowing TTY interrupts.

NOTE 2

Some means of examining CPU memory must be incorporated into the keyboard handler must be made so that the operator on a switch register - less CPU can examine core locations while in a "hold on error". The program uses a "fE xxxxx" where xxxxx is the location to be examined.

5.1.4 Switch Register Function

SW15=1 or up Halt on error.
SW14=1 or up Loop on test.
SW13=1 or up Inhibit printout of error.
SW11=1 or up Inhibit subtest iterations.

5.2 Scope Loops

If an error occurs and the user wishes to scope the error, he (or she) should set SW15=1 to halt on error, then when the program halts on error, SW15=0, set SW14=1 to (loop on current test), SW13=1 (to inhibit error printout) and press continue on the CPU's CONSOLE.

5.3 Program AND/OR Operator Action

The first pass through the program will be made with iterations inhibited. Successive passes will enable iterations if SW11=0. "END PASS" is printed at the end of a pass. The vector and priority of each input or output under test will be typed when program is initially run or if the vector or priority is changed during a pass.

6.0 ERRORS

6.1 Error Typeout

Print out varies with the error detected. The error PC typed out is the actual location of the error call. Error typeouts are preceded with THE ADDRESS of the error, if information is desired, reference the listing in respect to the PC (ADDRESS) typed out.

6.2 Non-Standard Errors

"TRAPPED TO LOCATION:XXXXXX FROM LOCATION:YYYYYY"

indicates:

1. An INPUT or OUTPUT module interrupted to a wrong vector.
2. Time-out or illegal instruction hardware trap. This is a fatal error that can not be continued past.

7.0 RESTRICTIONS

7.1 Starting Restriction

If the Vector address of any input or output is either 200 or 210-the program must be restricted at address 001000.

8.0 MISCELLANEOUS

8.1 Execution Time Logic Test

0,5 MIN. Iterations inhibited-no errors.
1,0 MIN. WITH ITERATIONS (FOR EACH CONNECTION)-NO ERRORS.

Execution times are approximate, as the various PDP-11 CPU's have varied instruction execution times.

MAINDEC-11-DZDRH-A MACY11 27(732) 21-SEP-76 09:52 PAGE 2
DZDRH.P11

1
2
3
4
5

064000

SSWR= 064000
.TITLE MAINDEC-11-DZDRH-A
;*COPYRIGHT (C) 1975
;*DIGITAL EQUIPMENT CORP.

000000
000001
000002
000003
000004
000005
000006
000007
000008
000009
000010
000011
000012
000013
000014
000015
000016
000017
000018
000019
000020
000021
000022
000023
000024
000025
000026
000027
000028
000029
000030
000031
000032
000033
000034
000035
000036
000037
000038
000039
000040
000041
000042
000043
000044
000045
000046
000047
000048
000049
000050
000051
000052
000053
000054
000055
000056
000057
000058
000059
000060
000061
000062
000063
000064
000065
000066
000067
000068
000069
000070
000071
000072
000073
000074
000075
000076
000077
000078
000079
000080
000081
000082
000083
000084
000085
000086
000087
000088
000089
000090
000091
000092
000093
000094
000095
000096
000097
000098
000099
000100

```

: *MAYNARD, MASS. 01754 002
: *
: *PROGRAM BY EDWARD C. BADGER
: *
: *THIS PROGRAM WAS ASSEMBLED USING THE PDF-11 MAINDEC SYSMAC
: *PACKAGE (MAINDEC-11-DZQAC-C2), SEPT 14, 1976.
: *
$TN=1

.SBTTL TRAP CATCHER

.=0
: *ALL UNUSED LOCATIONS 0 FROM 4 TO 776 CONTAIN .+4. IOTT (TRAP CALL)
: *SEQUENCE TO CATCH ILLEGAL TRAPS AND INTERRUPTS TO WRONG VECTORS AND
: *ROUTE THEM TO ROUTINE "IOTR" FOR TYPEOUT.
: *LOCATION 0 CONTAINS 0 TO CATCH IMPROPERLY LOADED VECTORS.

.=40
.WORD 42
.WORD 0
.=174
SWREG: 0
DISPRE: 0
.=200
JMP 2#START ;GO TO STARTING ADDRESS OF PROGRAM.
.=210
JMP 2#RSTART
.=1000
JMP 2#START

.SBTTL BASIC DEFINITIONS

: *INITIAL ADDRESS OF THE STACK POINTER *** 1100 ***
STACK= 1100
.EQUIV EMT,ERROR ;;BASIC DEFINITION OF ERROR CALL
.EQUIV IOT,SCOPE ;;BASIC DEFINITION OF SCOPE CALL

: *MISCELLANEOUS DEFINITIONS
HT= 11 ;;CODE FOR HORIZONTAL TAB
LF= 12 ;;CODE FOR LINE FEED
CR= 15 ;;CODE FOR CARRIAGE RETURN
CRLF= 200 ;;CODE FOR CARRIAGE RETURN-LINE FEED
PS= 177776 ;;PROCESSOR STATUS WORD
.EQUIV PS,PSW
STKLM= 177774 ;;STACK LIMIT REGISTER
PIRQ= 177772 ;;PROGRAM INTERRUPT REQUEST REGISTER
DSWR= 177570 ;;HARDWARE SWITCH REGISTER
DDISP= 177570 ;;HARDWARE DISPLAY REGISTER
```

57
58
59
60
61
62
63
64
65
66
67
68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112

000000
000001
000002
000003
000004
000005
000006
000007
000006
000007

000000
000040
000100
000140
000200
000240
000300
000340

100000
040000
020000
010000
004000
002000
001000
000400
000200
000100
000040
000020
000010
000004
000002
000001

100000
040000
020000
010000

```

:*GENERAL PURPOSE REGISTER DEFINITIONS
R0= %0          ;; GENERAL REGISTER
R1= %1          ;; GENERAL REGISTER
R2= %2          ;; GENERAL REGISTER
R3= %3          ;; GENERAL REGISTER
R4= %4          ;; GENERAL REGISTER
R5= %5          ;; GENERAL REGISTER
R6= %6          ;; GENERAL REGISTER
R7= %7          ;; GENERAL REGISTER
SP= %6         ;; STACK POINTER
PC= %7         ;; PROGRAM COUNTER

:*PRIORITY LEVEL DEFINITIONS
PR0= 0          ;; PRIORITY LEVEL 0
PR1= 40         ;; PRIORITY LEVEL 1
PR2= 100        ;; PRIORITY LEVEL 2
PR3= 140        ;; PRIORITY LEVEL 3
PR4= 200        ;; PRIORITY LEVEL 4
PR5= 240        ;; PRIORITY LEVEL 5
PR6= 300        ;; PRIORITY LEVEL 6
PR7= 340        ;; PRIORITY LEVEL 7

:*"SWITCH REGISTER" SWITCH DEFINITIONS
SW15= 100000
SW14= 40000
SW13= 20000
SW12= 10000
SW11= 4000
SW10= 2000
SW09= 1000
SW08= 400
SW07= 200
SW06= 100
SW05= 40
SW04= 20
SW03= 10
SW02= 4
SW01= 2
SW00= 1
.EQUIV SW09,SW9
.EQUIV SW08,SW8
.EQUIV SW07,SW7
.EQUIV SW06,SW6
.EQUIV SW05,SW5
.EQUIV SW04,SW4
.EQUIV SW03,SW3
.EQUIV SW02,SW2
.EQUIV SW01,SW1
.EQUIV SW00,SW0

:*DATA BIT DEFINITIONS (BIT00 TO BIT15)
BIT15= 100000
BIT14= 40000
BIT13= 20000
BIT12= 10000
```

113 004000
 114 002000
 115 001000
 116 000400
 117 000200
 118 000100
 119 000040
 120 000020
 121 000010
 122 000004
 123 000002
 124 000001
 125
 126
 127
 128
 129
 130
 131
 132
 133
 134
 135
 136
 137 000004
 138 000010
 139 000014
 140 000014
 141 000014
 142 000020
 143 000024
 144 000030
 145 000034
 146 000060
 147 000064
 148 000240
 149
 150 022626
 151
 152
 153
 154
 155

BIT11= 4000
 BIT10= 2000
 BIT09= 1000
 BIT08= 400
 BIT07= 200
 BIT06= 100
 BIT05= 40
 BIT04= 20
 BIT03= 10
 BIT02= 4
 BIT01= 2
 BIT00= 1
 .EQUIV BIT09,BIT9
 .EQUIV BIT08,BIT8
 .EQUIV BIT07,BIT7
 .EQUIV BIT06,BIT6
 .EQUIV BIT05,BIT5
 .EQUIV BIT04,BIT4
 .EQUIV BIT03,BIT3
 .EQUIV BIT02,BIT2
 .EQUIV BIT01,BIT1
 .EQUIV BIT00,BIT0

.*BASIC "CPU" TRAP VECTOR ADDRESSES
 ERRVEC= 4 : TIME OUT AND OTHER ERRORS
 RESVEC= 10 : RESERVED AND ILLEGAL INSTRUCTIONS
 TBITVEC= 14 : "T" BIT
 TRTVEC= 14 : TRACE TRAP
 BPTVEC= 14 : BREAKPOINT TRAP (BPT)
 IOTVEC= 20 : INPUT/OUTPUT TRAP (IOT) **SCOPE**
 PWRVEC= 24 : POWER FAIL
 EMTVEC= 30 : EMULATOR TRAP (EMT) **ERROR**
 TRAPVEC= 34 : "TRAP" TRAP
 TKVEC= 60 : TTY KEYBOARD VECTOR
 TPVEC= 64 : TTY PRINTER VECTOR
 PIRQVEC= 240 : PROGRAM INTERRUPT REQUEST VECTOR

POPS2= 22626

.SBTTL COMMON TAGS

*THIS TABLE CONTAINS VARIOUS COMMON STORAGE LOCATIONS
*USED IN THE PROGRAM.

| | | | | | | | | | | |
|-----|--------|--------|------------|--------|--------|--|--|--|--|--|
| 156 | | | | | | | | | | |
| 157 | | | | | | | | | | |
| 158 | | | | | | | | | | |
| 159 | | | | | | | | | | |
| 160 | | | | | | | | | | |
| 161 | | | | | | | | | | |
| 162 | | 001100 | | .=1100 | | | | | | |
| 163 | 001100 | | \$CMTAG: | | | | | :: START OF COMMON TAGS | | |
| 164 | 001100 | 000000 | \$PASS: | .WORD | 0 | | | :: CONTAINS PASS COUNT | | |
| 165 | 001102 | 000 | \$TSTNM: | .BYTE | 0 | | | :: CONTAINS THE TEST NUMBER | | |
| 166 | 001103 | 000 | \$ERFLG: | .BYTE | 0 | | | :: CONTAINS ERROR FLAG | | |
| 167 | 001104 | 000000 | \$ICNT: | .WORD | 0 | | | :: CONTAINS SUBTEST ITERATION COUNT | | |
| 168 | 001106 | 000000 | \$LPADR: | .WORD | 0 | | | :: CONTAINS SCOPE LOOP ADDRESS | | |
| 169 | 001110 | 000000 | \$LPERR: | .WORD | 0 | | | :: CONTAINS SCOPE RETURN FOR ERRORS | | |
| 170 | 001112 | 000000 | \$ERTTL: | .WORD | 0 | | | :: CONTAINS TOTAL ERRORS DETECTED | | |
| 171 | 001114 | 000 | \$ITEMB: | .BYTE | 0 | | | :: CONTAINS ITEM CONTROL BYTE | | |
| 172 | 001115 | 001 | \$ERMAX: | .BYTE | 1 | | | :: CONTAINS MAX. ERRORS PER TEST | | |
| 173 | 001116 | 000000 | \$ERRPC: | .WORD | 0 | | | :: CONTAINS PC OF LAST ERROR INSTRUCTION | | |
| 174 | 001120 | 000000 | \$GDADR: | .WORD | 0 | | | :: CONTAINS ADDRESS OF 'GOOD' DATA | | |
| 175 | 001122 | 000000 | \$BDADR: | .WORD | 0 | | | :: CONTAINS ADDRESS OF 'BAD' DATA | | |
| 176 | 001124 | 000000 | \$GDDAT: | .WORD | 0 | | | :: CONTAINS 'GOOD' DATA | | |
| 177 | 001126 | 000000 | \$BDDAT: | .WORD | 0 | | | :: CONTAINS 'BAD' DATA | | |
| 178 | 001130 | 000000 | | .WORD | 0 | | | :: RESERVED--NOT TO BE USED | | |
| 179 | 001132 | 000000 | | .WORD | 0 | | | | | |
| 180 | 001134 | 000 | \$AUTOB: | .BYTE | 0 | | | :: AUTOMATIC MODE INDICATOR | | |
| 181 | 001135 | 000 | \$INTAG: | .BYTE | 0 | | | :: INTERRUPT MODE INDICATOR | | |
| 182 | 001136 | 000000 | | .WORD | 0 | | | | | |
| 183 | 001140 | 177570 | \$SWR: | .WORD | DSWR | | | :: ADDRESS OF SWITCH REGISTER | | |
| 184 | 001142 | 177570 | \$DISPLAY: | .WORD | DDISP | | | :: ADDRESS OF DISPLAY REGISTER | | |
| 185 | 001144 | 177560 | \$TKS: | | 177560 | | | :: TTY KBD STATUS | | |
| 186 | 001146 | 177562 | \$TKB: | | 177562 | | | :: TTY KBD BUFFER | | |
| 187 | 001150 | 177564 | \$TPS: | | 177564 | | | :: TTY PRINTER STATUS REG. ADDRESS | | |
| 188 | 001152 | 177566 | \$TPB: | | 177566 | | | :: TTY PRINTER BUFFER REG. ADDRESS | | |
| 189 | 001154 | 000 | \$NULL: | .BYTE | 0 | | | :: CONTAINS NULL CHARACTER FOR FILLS | | |
| 190 | 001155 | 002 | \$FILLS: | .BYTE | 2 | | | :: CONTAINS # OF FILLER CHARACTERS REQUIRED | | |
| 191 | 001156 | 012 | \$FILLC: | .BYTE | 12 | | | :: INSERT FILL CHARS. AFTER A "LINE FEED" | | |
| 192 | 001157 | 000 | \$TPFLG: | .BYTE | 0 | | | :: "TERMINAL AVAILABLE" FLAG (BIT<07>=0=YES) | | |
| 193 | 001160 | 000000 | \$REGAD: | .WORD | 0 | | | :: CONTAINS THE ADDRESS FROM | | |
| 194 | | | | | | | | :: WHICH (\$REGD) WAS OBTAINED | | |
| 195 | 001162 | 000000 | \$REGO: | .WORD | 0 | | | :: CONTAINS ((\$REGAD)+0) | | |
| 196 | 001164 | 000000 | \$TMPD: | .WORD | 0 | | | :: USER DEFINED | | |
| 197 | 001166 | 000000 | \$TIMES: | | 0 | | | :: MAX. NUMBER OF ITERATIONS | | |
| 198 | 001170 | 077 | \$QUES: | .ASCII | /?/ | | | :: QUESTION MARK | | |
| 199 | 001171 | 015 | \$CRLF: | .ASCII | <15> | | | :: CARRIAGE RETURN | | |
| 200 | 001172 | 000012 | \$LF: | .ASCIZ | <12> | | | :: LINE FEED | | |
| 201 | | | ***** | | | | | | | |
| 202 | | | | | | | | | | |
| 203 | 001174 | 000000 | XCSRA: | .WORD | 0 | | | :: ADDRESS OF OUTPUT MODULE'S CSR. | | |
| 204 | | | | | | | | | | |
| 205 | 001176 | 000000 | XDBRA: | .WORD | 0 | | | :: ADDRESS OF OUTPUT MODULE'S DBR. | | |
| 206 | | | | | | | | | | |
| 207 | 001200 | 000000 | XVT: | .WORD | 0 | | | :: VECTOR ADDR. OF OUTPUT MODULE. | | |
| 208 | 001202 | 000000 | XVT2: | .WORD | 0 | | | :: VECTOR ADDR.+2 FOR INTR. PSW. | | |
| 209 | | | | | | | | | | |
| 210 | 001204 | 000000 | RCSRA: | .WORD | 0 | | | :: ADDRESS OF INPUT MODULE'S CSR. | | |
| 211 | 001206 | 000000 | RDBRA: | .WORD | 0 | | | :: ADDRESS OF INPUT MODULES DBR. | | |

| | | | | | |
|-----|--------|--------|----------|-------|------|
| 212 | | | | | |
| 213 | 001210 | 000000 | RVT: | .WORD | 0 |
| 214 | 001212 | 000000 | RVT2: | .WORD | 0 |
| 215 | | | | | |
| 216 | 001214 | 000060 | TKV: | .WORD | 60 |
| 217 | 001216 | 000062 | TKV2: | .WORD | 62 |
| 218 | | | | | |
| 219 | 001220 | 000000 | MODE: | .WORD | 0 |
| 220 | 001222 | 000000 | MODE1: | .WORD | 0 |
| 221 | 001224 | 000000 | PATFR0: | .WORD | 0 |
| 222 | | | | | |
| 223 | 001226 | 000000 | PATM: | .WORD | 0 |
| 224 | 001230 | 000000 | PATRN: | .WORD | 0 |
| 225 | 001232 | 000000 | TEXTP: | .WORD | 0 |
| 226 | 001234 | 000000 | TABLEP: | .WORD | 0 |
| 227 | 001236 | 000000 | TTYPAT: | .WORD | 0 |
| 228 | 001240 | 000000 | PATOUT: | .WORD | 0 |
| 229 | 001242 | 000000 | PATTIN: | .WORD | 0 |
| 230 | 001244 | 000000 | PATOLD: | .WORD | 0 |
| 231 | | | | | |
| 232 | 001246 | 000000 | PTRM: | .WORD | 0 |
| 233 | 001250 | 000000 | PTRS: | .WORD | 0 |
| 234 | 001252 | 000000 | SMSST: | .WORD | 0 |
| 235 | 001254 | 000000 | SSLST: | .WORD | 0 |
| 236 | | | | | |
| 237 | 001256 | 000000 | XNO: | .WORD | 0 |
| 238 | 001260 | 000000 | SXNO: | .WORD | 0 |
| 239 | | | | | |
| 240 | 001262 | 000000 | STABLP: | .WORD | 0 |
| 241 | 001264 | 000000 | XVTP: | .WORD | 0 |
| 242 | 001266 | 000000 | RVTP: | .WORD | 0 |
| 243 | | | | | |
| 244 | 001270 | 000000 | CHAR: | .WORD | 0 |
| 245 | 001272 | 000001 | ST200: | .WORD | 1 |
| 246 | 001274 | 000000 | \$TEMPO: | .WORD | 0 |
| 247 | 001276 | 000000 | SAVPC: | .WORD | 0 |
| 248 | 001300 | 177570 | BSWR: | .WORD | BSWR |
| 249 | 001302 | 000000 | SWREQ: | .WORD | 0 |
| 250 | 001304 | 000000 | ERTYCN: | .WORD | 0 |
| 251 | | | | | |

;VECTOR ADDR. OF INPUT MODULE.
 ;VECTOR ADDR.+2 OF INPUT MODULE
 ;I/O TERMINAL VECTOR ADDR.
 ;I/O TERMINAL VECTOR ADDR.+2.
 ;MODE OF OPERATION OF PROGRAM
 ;MODE OF OPERATION OF INPUT ROUTINES.
 ;INDICATES SOURCE OF DATA
 ;VALUES 'A' TO 'D'
 ;INDICATES PATTERN MODIFIER
 ;ACTUAL PATTERN TO BE OUTPUTTED.
 ;POINTS TO TABLE OF PATTERNS FOR MASTER.
 ;POINTS TO TABLE OF PATTERNS
 ;PATTERN INPUTTED ON TTY.
 ;METHOD OF REPORTING DATA.
 ;DATA READ FROM INPUT MODULE.
 ;OLD PATTERN IF OUTPUTTING ON TTY.
 ;USED BY MASTER-SLAVE AUTO TO SAVE MASTER'S PC.
 ;USED BY MASTER-SLAVE AUTO TO SAVE SLAVE'S PC.
 ;USED BY MASTER-SLAVE AUTO TO SAVE MASTER'S STATUS.
 ;USED BY MASTER-SLAVE AUTO TO SAVE SLAVE'S STATUS.
 ;MASTER'S ITERATION COUNT
 ;SLAVE'S ITERATION COUNT.
 ;POINTS TO SLAVE'S BSM STORAGE AREA.
 ;PRIORITY OF OUTPUT.
 ;PRIORITY OF INPUT.
 ;CHARACTER INPUTTED FROM TTY.
 ;INDICATES STARTED AT 200 IF 0.
 ;TEMP STORAGE.
 ;SAVES PC IN ERROR ROUTINE.
 ;ADDR. OF REAL HARDWARE SWITCH REGISTER.
 ;SOFTWARE SWITCH REGISTER.
 ;#OF ERRORS TYPED OUT.

252
253
254
255
256
257
258
259
260
261
262
263
264
265
266
267
268
269
270
271
272
273
274
275
276
277
278
279
280
281
282
283
284
285
286
287
288
289
290
291
292
293
294
295
296
297
298
299
300
301
302
303
304
305
306
307

.SBTTL ERROR POINTER TABLE

;*THIS TABLE CONTAINS THE INFORMATION FOR EACH ERROR THAT CAN OCCUR.
;*THE INFORMATION IS OBTAINED BY USING THE INDEX NUMBER FOUND IN
;*LOCATION \$ITEMB. THIS NUMBER INDICATES WHICH ITEM IN THE TABLE IS PERTINENT.
;*NOTE1: IF \$ITEMB IS 0 THE ONLY PERTINENT DATA IS (\$ERRPC).
;*NOTE2: EACH ITEM IN THE TABLE CONTAINS 4 POINTERS EXPLAINED AS FOLLOWS:

;* EM ;;POINTS TO THE ERROR MESSAGE
;* DH ;;POINTS TO THE DATA HEADER
;* DT ;;POINTS TO THE DATA
;* DF ;;POINTS TO THE DATA FORMAT

\$ERRTB:

.SBTTL PROGRAM START-UP

```
START:
.SBTTL INITIALIZE THE COMMON TAGS
;;CLEAR THE COMMON TAGS ($CMTAG) AREA
MOV $CMTAG,R6 ;;FIRST LOCATION TO BE CLEARED
CLR (R6)+ ;;CLEAR MEMORY LOCATION
CMP $SWR,R6 ;;DONE?
BNE -6 ;;LOOP BACK IF NO
MOV $STACK,SP ;;SETUP THE STACK POINTER
;;INITIALIZE A FEW VECTORS
MOV $SCOPE,$IOTVEC ;;IOT VECTOR FOR SCOPE ROUTINE
MOV $340,$IOTVEC+2 ;;LEVEL 7
MOV $ERROR,$EMTVEC ;;EMT VECTOR FOR ERROR ROUTINE
MOV $340,$EMTVEC+2 ;;LEVEL 7
MOV $TRAP,$TRAPVEC ;;TRAP VECTOR FOR TRAP CALLS
MOV $340,$TRAPVEC+2 ;;LEVEL 7
MOV $PWRDN,$PWRVEC ;;POWER FAILURE VECTOR
MOV $340,$PWRVEC+2 ;;LEVEL 7
CLR $TIMES ;;INITIALIZE NUMBER OF ITERATIONS
MOV $,$SLPADR ;;INITIALIZE THE LOOP ADDRESS FOR SCOPE
;;SIZE FOR A HARDWARE SWITCH REGISTER. IF NOT FOUND OR IT IS
;;EQUAL TO A "-1" SETUP FOR A SOFTWARE SWITCH REGISTER.
MOV $ERRVEC,-(SP) ;;SAVE ERROR VECTOR
MOV $64,$ERRVEC ;;SET UP ERROR VECTOR
MOV $DSWR,$SWR ;;SETUP FOR A HARDWARE SWICH REGISTER
MOV $DDISP,$DISPLAY ;;AND A HARDWARE DISPLAY REGISTER
CMP #-1,$SWR ;;TRY TO REFERENCE HARDWARE SWR
BNE 66$ ;;BRANCH IF NO TIMEOUT TRAP OCCURRED
;;AND THE HARDWARE SWR IS NOT = -1
BR 65$ ;;BRANCH IF NO TIMEOUT
64$: MOV $65$,(SP) ;;SET UP FOR TRAP RETURN
RTI
65$: MOV $SWREG,$SWR ;;POINT TO SOFTWARE SWR
MOV $DISPREG,$DISPLAY
66$: MOV (SP)+,$ERRVEC ;;RESTORE ERROR VECTOR
```

;* PROGRAM TEST TO DETERMINE WHAT CLASS OF COMPUTER WE ARE RUNNING IN.

```

308 001506 012737 001534 000010 ST1:  MOV    #ST2, @#10      ; TO DO THIS WE WILL DO AN INSTRUCTION THAT
309                                     ; ONLY AN 11/40 OR GREATER MACHINE WILL RECOGNIZE.
310                                     ; WE'LL SET THE ILLEGAL INSTR. TRAP VECTOR IF
311                                     ; THE CPU WE'RE RUNNING ON CAN'T PREFORM AN
312                                     ; "XOR" INSTR. IT WILL TRAP.
313 001514 074101                XOR    R1,R1          ; THIS "XOR" WILL CAUSE 11/20 OR
314                                     ; LOWER CLASS PDP11 CPU TO TRAP TO "ST2".
315
316 001516 012737 000006 006260    MOV    #6,INSRT1     ; WE DIDN'T TRAP! MUST BE ON 11/40 OR BETTER.
317                                     ; IN THAT CASE WE MUST REPLACE "RTI" INSTR. WITH
318                                     ; "RTT" INSTRUCTION WHERE WE RETURN FROM A TRACE TRAP CAL
319 001524 012737 000006 006310    MOV    #6,INSRT2     ; THERE ARE TWO LOCATIONS.
320
321 001532 000402                BR     ST3           ; GOTO "ST3"
322
323 001534 062706 000004          ST2:  ADD    #4,R6      ; TRAPPED HERE IF ON 11/20 OR LESSER CPU.
324                                     ; FIX THE STACK POINTER.
325
326 001540 012737 000012 000010 ST3:  MOV    #12, @#10     ; RESTORE LOCATION 10 FOR FUTURE TRAPS.
327
328                                     ; *END PROGRAM TEST FOR CLASS OF COMPUTER.
329
330 001546 012737 001302 001140    MOV    #SWREQ,SWR    ; POINT TO SOFTWARE SWR.
331
332 001554 005037 001174          CLR    XCSRA         ; CLEAR ADDR. OF OUTPUT CSR.
333 001560 005037 001204          CLR    RCSRA         ; CLEAR ADDR. OF INPUT CSR.
334 001564 013777 001202 177406    MOV    XVT2, @XVT    ; RESTORE VECTOR IN CASE OF ILLEGAL
335 001572 012777 104416 177402    MOV    #IOTT, @XVT2  ; INTERRUPT
336 001600 013777 001212 177402    MOV    RVT2, @RVT    ; RESTORE VECTOR IN CASE OF
337 001606 012777 104416 177376    MOV    #IOTT, @RVT2  ; ILLEGAL INTERRUPT.
338 001614 005037 001200          CLR    XVT           ; CLEAR VECTOR ADDR.
339 001620 005037 001202          CLR    XVT2         ; CLEAR VECTOR ADDR.
340 001624 005037 001210          CLR    RVT          ; CLEAR VECTOR ADDR.
341 001630 005037 001212          CLR    RVT2         ; CLEAR VECTOR ADDR.
342 001634 012777 000340 177354    MOV    #340, @TKV2   ; SET KEYBOARD STATUS VECTOR.
343 001642 042777 000100 177274    BIC    #BIT6, @STKS  ; CLEAR INTERRUPT ENABLE.
344 001650 104401 001656          TYPE   ,65$         ; TYPE ASCIZ STRING
345 001654 000410                BR     64$          ; GET OVER THE ASCIZ
346                                     ;:65$: .ASCIZ <15><12>#MD-11-DZDRH-A#
347 001676                64$:
348
349 001676                15$:
350 001676 104401 001704          TYPE   ,67$         ;:TYPE ASCIZ STRING
351 001702 000427                BR     66$          ;:GET OVER THE ASCIZ
352                                     ;:67$: .ASCIZ <15><12><12>#4.4.1 TERMINAL CHANGE REQUIRED (Y OR N)? #
353 001762                66$:
354 001762 104406                25$: RDCHR          ;:GET OPER RESPONCE.
355 001764 012600                MOV    (SP)+,R0     ;:CHAR. ON STACK.
356 001766 120027 000116          CMPB  R0,#'N        ;:IS ANSWER NO?
357 001772 001007                BNE   35$           ;:IF NOT CONTINUE.
358 001774 104401 002002          TYPE   ,69$         ;:TYPE ASCIZ STRING
359 002000 000402                BR     68$          ;:GET OVER THE ASCIZ
360                                     ;:69$: .ASCIZ #NO#
361 002006                68$:
362 002006 000137 002646          JMP    INPASK       ;:ASK FOR INPUT MODULE ADDRS.
363

```

```

364 002012 120027 000131 3$: CMPB RO,#'Y ;IS ANSWER "YES"?
365 002016 001327 BNE 1$ ;IF NOT REASK QUESTIKN
366
367 002020 104401 002026 TYPE ,71$ ;;TYPE ASCIZ STRING
368 002024 000402 BR ,70$ ;;GET OVER THE ASCIZ
369
370 002032 ;;71$: .ASCIZ #YES#
371 70$:
372 002032 4$:
373 002032 104401 002040 TYPE ,73$ ;;TYPE ASCIZ STRING
374 002036 000427 BR ,72$ ;;GET OVER THE ASCIZ
375
376 002116 ;;73$: .ASCIZ <15><12>#4.4.2 KEYBOARD CSR ADDR. OF NEW TERMINAL? #
377 002116 005077 177022 72$: CLR ,STKS
378 002122 104410 RDOCT
379 002124 012600 MOV (SP)+,RO
380 002126 004737 013264 JSR PC,CKADR ;CHECK THAT ADDRESS IS LEGAL.
381 002132 103737 BCS 4$ ;CARRY BIT SET ON RETURN MEANS NO.
382 002134 010001 MOV RO,R1 ;SET ADDR. OF NEW KEYBOARD CSR.
383 002136 5$:
384 002136 104401 002144 TYPE ,75$ ;;TYPE ASCIZ STRING
385 002142 000416 BR ,74$ ;;GET OVER THE ASCIZ
386
387 002200 ;;75$: .ASCIZ <15><12>#4.4.3 ITS VECTOR ADDR.? #
388 74$:
389 002200 104410 RDOCT ;GET VECTOR ADDR.
390 002202 012600 MOV (SP)+,RO ;ADDR ON STACK.
391 002204 032700 000001 BIT #BIT0,RO ;ADD # ENTERED?
392 002210 001422 BEQ 6$ ;NO-CONTINUE
393 002212 104401 002220 TYPE ,77$ ;;TYPE ASCIZ STRING
394 002216 000416 BR ,76$ ;;GET OVER THE ASCIZ
395
396 002254 ;;77$: .ASCIZ <15><12>#ODD NUMBER NOT EXPECTED!#
397 002254 000730 76$: BR 5$
398 002256 032700 176000 6$: BIT #176000,RO ;NUMBER TOO LARGE?
399 002262 001416 BEQ 7$ ;NO-CONTINUE
400 002264 104401 002272 TYPE ,79$ ;;TYPE ASCIZ STRING
401 002270 000412 BR ,78$ ;;GET OVER THE ASCIZ
402
403 002316 ;;79$: .ASCIZ <15><12>#NUMBER TOO LARGE!#
404 002316 000707 78$: BR 5$ ;REASK QUESTION
405
406 002320 020027 000040 7$: CMP RO,#40 ;NUMBER TOO SMALL?
407 002324 103016 BHIS 8$ ;NO-CONTINUE
408 002326 104401 002334 TYPE ,81$ ;;TYPE ASCIZ STRING
409 002332 000412 BR ,80$ ;;GET OVER THE ASCIZ
410
411 002360 ;;81$: .ASCIZ <15><12>#NUMBER TOO SMALL!#
412 002360 000666 80$: BR 5$ ;REASK QUESTION
413
414 002362 013777 001216 176624 8$: MOV TKV2,@TKV ;RESTORE PREVIOUS TTY VECTOR.
415 002370 012777 104416 176620 MOV #IOTT,@TKV2
416 002376 010037 001214 MOV RO,TKV ;SAVE NEW TTY VECTOR.
417 002402 062700 000002 ADD #2,RO
418 002406 010037 001216 MOV RO,TKV2
419 002412 012777 000340 176576 MOV #340,@TKV2 ;PRIORITY 7 ON INTERRUPT

```



```

420
421 002420
422 002420 104401 002426
423 002424 000426
424
425 002502
426 002502 104410
427 002504 012600
428 002506 004737 013264
429 002512 103742
430
431 002514 104401 002522
432 002520 000416
433
434 002556
435 002556 010137 001144
436 002562 062701 000002
437 002566 010137 001146
438
439
440 002572 010037 001150
441 002576 062700 000002
442 002602 010037 001152
443
444 002606 104401 002614
445 002612 000415
446
447 002646
448
449 002646 005077 176272
450 002652 104401 002660
451 002656 000422
452
453 002724
454 002724 104410
455 002726 012600
456 002730 004737 013264
457 002734 103744
458 002736 010037 001204
459 002742 062700 000002
460 002746 010037 001206
461
462 002752
463 002752 104401 002760
464 002756 000423
465
466 003026
467 003026 104410
468 003030 012600
469 003032 004737 013264
470 003036 103745
471 003040 010037 001174
472 003044 062700 000002
473 003050 010037 001176
474 003054 005037 001272
475

10$:
TYPE 83$
BR 82$
::83$: .ASCIZ <15><12>#4.4.4 PRINTER CSR ADDR. OF NEW TERMINAL? #
82$:
RDOCT
MOV (SP)+,RO
JSR PC,CKADR
BCS 10$
::85$: .ASCIZ <15><12>#SWITCHING TO NEW TERMINAL#
84$:
MOV R1,$TKS
ADD #2,R1
MOV R1,$TKB

MOV RO,$STPS ;STORE ADDR. OF PRINTER.
ADD #2,RO
MOV RO,$TPB

TYPE 87$
BR 86$
::87$: .ASCIZ <15><12>#NEW TERMINAL ACTIVE.#<15><12><12>
86$:

INPASK: CLR 0$TKS
TYPE 65$
BR 64$
::65$: .ASCIZ <15><12>#4.4.5 CSR ADDR. OF INPUT MODULE? #
64$:
RDOCT
MOV (SP)+,RO
JSR PC,CKADR
BCS INPASK
MOV RO,RCSRA
ADD #2,RO
MOV RO,RDBRA

OUTASK: TYPE 65$
BR 64$
::65$: .ASCIZ <15><12>#4.4.6 CSR ADDR. OF OUTPUT MODULE? #
64$:
RDOCT
MOV (SP)+,RO
JSR PC,CKADR
BCS OUTASK
MOV RO,XCSRA
ADD #2,RO
MOV RO,XDBRA
CLR ST200
.SBTTL PROGRAM RESTART
;TYPE ASCIZ STRING
;GET OVER THE ASCIZ
;GET ADDR.
;ADDR. ON STACK
;CHECK THAT ADDR. IS OK
;IF NOT REASK.
;TYPE ASCIZ STRING
;GET OVER THE ASCIZ
;MOV R1,$TKS
;ADD #2,R1
;MOV R1,$TKB
;STORE ADDR. OF PRINTER.
;TYPE ASCIZ STRING
;GET OVER THE ASCIZ
;NEW TERMINAL ACTIVE.#<15><12><12>
;TYPE ASCIZ STRING
;GET OVER THE ASCIZ
;4.4.5 CSR ADDR. OF INPUT MODULE? #
;GET ADDR.
;ADDR. ON STACK
;SEE IS ADDR. LEGAL.
;IF NOT-REASK.
;STORE ADDR. OF CSR.
;MAKE ADDR. OF DBR
;STORE DBR ADDR.
;TYPE ASCIZ STRING
;GET OVER THE ASCIZ
;4.4.6 CSR ADDR. OF OUTPUT MODULE? #
;GET ADDR.
;ADDR ON STACK.
;SEE IF ADDR. LEGAL
;IF NOT-REASK.
;STORE ADDR. OF CSR
;FORM DBR ADDR.
;STORE DBR ADDR.
;INDICATE HAD STARTED AT LOC 200.

```

476

;*THIS SECTION ENTERED FROM START AT 210 OR ↑C

```

482
483 003060 012706 001100 RSTART: MOV #STACK,SP
484 003064 005037 001100 CLR $PASS
485 003070 005037 001112 CLR $ERTTL ;CLEAR ERROR COUNT.
486 003074 005037 001304 CLR ERTYCN ;CLEAR # OF ERRORS TYPED OUT.
487 003100 012777 013434 176106 MOV #KEYSRV,ATKV
488 003106 000005 RESET
489 003110 012737 003130 000004 MOV #1$,A#4 ;SET FOR TRAP IF NO SWR.
490 003116 005037 000006 CLR A#6
491 003122 005737 177570 TST A#177570 ;ADDRESS THE SWR IF TRAPS THEN NONE.
492 003126 000407 BR 2$ ;NO TRAP - CONTINUE.
493
494 003130 022626 1$: POPSP2 ;WE TRAPPED-MUST BE NO HARDWARE SWR.
495 003132 012737 001302 001300 MOV #SWREQ,BSWR ;SET SOFTWARE SWR AS ADDRESS OF SWR
496 003140 012737 001162 001142 MOV #SREGO,DISPLAY ;MAKE SURE TO TAKE CARE OF DISPLAY.
497
498 003146 012737 000006 000004 2$: MOV #6,A#4 ;RESET THE TRAP VECTOR.
499 003154 012737 104416 000006 MOV #IOTT,A#6 ;TRAP ROUTINE IN CASE OF ILL TRAP.
500 003162 005737 001272 TST ST200 ;WAS THIS PROG. ORIGINALLY STARTED AT 200?
501 003166 001436 BEQ RST2 ;LOC "ST200" ZEROED BY START ROUTINE.
502
503 003170 104401 003176 TYPE ,65$ ;:TYPE ASCIZ STRING
504 003174 000430 BR ,64$ ;:GET OVER THE ASCIZ
505 ;:65$: .ASCIZ <15><12>#PROGRAM MUST BE STARTED AT LOC 200 INITAILLY#
506 ;:64$:
507 003256 000000 HALT
508 003260 000137 000200 JMP A#200
509
510
511 003264 RST2:
512 003264 104401 003272 TYPE ,65$ ;:TYPE ASCIZ STRING
513 003270 000407 BR ,64$ ;:GET OVER THE ASCIZ
514 ;:65$: .ASCIZ <15><12>#4.4.7 MODE?#
515 ;:64$:
516 003310 CLR $ICNT
517 003314 005037 001104 CLR PATOUT
518 003320 012777 013434 175666 MOV #KEYSRV,ATKV
519 003326 042777 000100 175610 BIC #BIT6,ATKVS ;DISABLE TTY INTERRUPTS
520 003334 104407 RDLIN ;GET OPER TEXT.
521 003336 052777 000100 175600 BIS #BIT6,ATKVS
522 003344 012600 MOV (SP)+,RO ;ADDR. OF TEXT ON STACK.
523 003346 111037 001220 MOV#B (RO),MODE
524 003352 121027 000113 1$: CMP#B (RO),#'K ;SLAVE AUTO MODE SELECTED "K"?
525 003356 001002 BNE 2$
526 003360 000137 005770 JMP STARTS ;YES-GOTO START SLAVE.
527
528 003364 121027 000105 2$: CMP#B (RO),#'E ;MASTER AUTO MODE SELECTED "E"?
529 003370 001002 BNE 3$
530 003372 000137 006064 JMP STARTM ;YES-GOTO START MASTER.
531

```

```

532 003376 121027 000114      3$:  CMPB  (RO),#'L      ;INPUT MODULE LOGIC TEST "L"?
533 003402 001002                BNE  4$
534 003404 000137 010052      JMP  IMLT      ;YES-GOTO INPUT MOD. LOGIC TEST.
535
536 003410 121027 000106      4$:  CMPB  (RO),#'F      ;OUTPUT MODULE LOGIC TEST?
537 003414 001002                BNE  5$
538 003416 000137 011052      JMP  OMLT      ;YES-DO OUTPUT MODULE LOGIC TEST
539
540 003422 121027 000115      5$:  CMPB  (RO),#'M      ;MASTER-SLAVE AUTO MODE?
541 003426 001002                BNE  QE
542 003430 000137 006162      JMP  STRTMS    ;YES-DO MASTER-SLAVE AUTO.
543
544 003434 121027 000107      QE:  CMPB  (RO),#'G      ;MODE > G?
545 003440 002410                BLT  1$        ;NO-MUST BE OUTPUT MODE.
546 003442 121027 000112      CMPB  (RO),#'J      ;MODE < = J?
547 003446 003005                BGT  1$        ;NO-GOT TO BE OUTPUT MODE.
548 003450 012737 014270 001234  MOV  #TABLE, TABLEP
549 003456 000137 004662      JMP  INPM      ;GOTO INPUT MODE.
550
551 003462 121027 000101      1$:  CMPB  (RO),#'A      ;MODE < A?
552 003466 002403                BLT  2$        ;YES-UNKNOWN MODE.
553 003470 121027 000104      CMPB  (RO),#'D      ;MODE > D?
554 003474 003401                BLE  OUTM      ;NO-OUTPUT MODE
555
556
557 003476                2$:
558 003476 000672                BR   RST2      ;REASK QUESTION
559 003500 005737 001174      OUTM: TST  XCSRA    ;OUTPUT MODULE ENTERED?
560 003504 001527                BEQ  5$
561 003506 104401 003514      TYPE  65$      ;;TYPE ASCIZ STRING
562 003512 000414                BR   64$      ;;GET OVER THE ASCIZ
563
564 003544                ;;65$: .ASCIZ <15><12>#4.4.8 SOURCE OF DATA?#
565
566 003544 104407                RDLIN
567 003546 012600                MOV  (SP)+,RO  ;GET ADDR. RESPONSE
568 003550 121027 000101      CMPB  (RO),#'A      ;ADDR. OF RESPONSE ON STACK.
569 003554 002751                BLT  OUTM      ;GREATER THAN SOURCE "A"?
570 003556 121027 000104      CMPB  (RO),#'D      ;YES-REASK QUESTION
571 003562 003346                BGT  OUTM      ;LESS THAN SOURCE "D"?
572
573 003564 111037 001224 000103  1$:  MOVB  (RO),PATFRO  ;STORE SOURCE OF DATA.
574 003570 123727 001224      CMPB  PATFRO,#'C    ;SOURCE FROM PROGRAM GENERATION?
575 003576 001057                BNE  4$        ;NO-CONTINUE
576
577 003600                2$:
578 003600 104401 003606      TYPE  67$      ;;TYPE ASCIZ STRING
579 003604 000416                BR   66$      ;;GET OVER THE ASCIZ
580
581 003642                ;;67$: .ASCIZ <15><12>#4.4.9 STARTING PATTERN? #
582 003642 104410                RDOCT
583 003644 012637 001230      MOV  (SP)+,PATRN  ;GET FROM OPER.
584
585 003650                3$:
586 003650 104401 003656      TYPE  69$
587 003654 000416                BR   68$      ;;TYPE ASCIZ STRING
                    ;;GET OVER THE ASCIZ

```

```

588      ::695: .ASCIZ <15><12>#4.4.10 PATTERN MODIFIER? #
589      695:
589 003712      RDLIN      ;GET OPER RESPONSE
590 003712 104407      MOV      (SP)+,RO      ;ADDR. OF RESPONSE ON STACK
591 003714 012600      MOV      (RO),PATM      ;STORE MODIFIER.
592 003716 111037 001226  CMP      (RO),#'A      ;GREATER THAN 'A'?
593 003722 121027 000101  BLT      3$            ;IF SO-CONTINUE
594 003726 002750      CMP      (RO),#'D      ;LESS THAN, EQUAL TO 'D'?
595 003730 121027 000104  BGT      3$            ;IF NOT REASK.
596 003734 003345
597
598 003736 012737 014270 001232 4$:  MOV      #TABLE,TEXTP    ;POINT TO BEGINNING OF TABLE.
599 003744 005037 001236      CLR      TTYPAT        ;CLEAR TTY CHANGE PATTERN.
600 003750 012777 000000 175216  MOV      #0,DXCSRA
601 003756 005737 001174      TST      XCSRA         ;IS AN ADDRESS PRESENT?
602 003762 001026      BNE      OUTMVK        ;YES-CONTINUE.
603
604 003764      5$:
605 003764 104401 003772      TYPE      71$          ;:TYPE ASCIZ STRING
606 003770 000421      BR       70$           ;:GET OVER THE ASCIZ
607      ::71$: .ASCIZ <15><12>#NO OUTPUT MODULE ADDR. ENTERED!#
608      70$:
609 004034 000137 002752      JMP      OUTASK        ;ASK FOR ADDR.
610
611      .SBTTL OUTPUT MODULE ROUTINES
612

```

```

;#ROUTINE TO OUTPUT TO AN OUTPUT MODULE
;#USES ROUTINES "MODPAT" TO GET A PATTERN
;#AND "SNPAT" TO DO ACTUAL SENDING.

```

```

618
619 004040 000410      OUTMVK: BR      MODPAT    ;MODIFY OUTPUT PATTERN.
620 004042 000137 004322  OUTWR:  JMP      SNPAT     ;SEND DATA
621
622 004046 023727 001240 000103  OUTWR2: CMP      PATOUT,#103 ;DID WE COME FROM INPUT MOD ROUTINE?
623 004054 001371      BNE      OUTMVK        ;NO-LOOP
624 004056 000137 005100      JMP      INPMVK        ;YES-RETURN.
625

```

```

;#MODPAT ROUTINE USED TO MODIFY OUTPUT PATTERN
;#
;# PATFRO=      FUNCTION
;# -----      -----
;#
;# 101          PATTERN FROM SWITCH REGISTER
;# 102          PATTERN FROM TTY.
;# 103          PROGRAM GENERATED PATTERN.
;# 104          PATTERN FROM TABLE
;#

```

```

637
638 004062 123727 001224 000101  MODPAT: CMP      PATFRO,#'A ;PATTERN FROM SWR?
639 004070 001434      BEQ      PSWR         ;YES-GO READ IT.
640
641 004072 123727 001224 000103  1$:  CMP      PATFRO,#'C ;PATTERN FROM PROGRAM GEN?
642 004100 001002      BNE      2$           ;NO-CONTINUE.
643 004102 000137 004202      JMP      PPM          ;YES-GENERATE

```

```

644
645 004106 123727 001224 000102 2$: CMPB PATFR0,#'B ;PATTERN FROM TTY?
646 004114 001002 BNE 3$ ;NO-CONTINUE.
647 004116 000137 004042 JMP OUTWR ;YES-DONE AUTOMATICALLY.
648 ;PATTERN FROM THE TABLE
649 004122 017737 175104 001230 3$: MOV JTEXTP,PATRN ;LOAD NEW PATTERN
650 004130 062737 000002 001232 ADD #2,TEXTP ;UPDATE TABLE POINTER.
651 004136 023727 001232 014642 4$: CMP TEXTP,#TEXTE ;DONE WHOLE TABLE?
652 004144 001402 BEQ 6$ ;YES-
653 004146 000137 004042 5$: JMP OUTWR ;NO-SEND PATTERN
654
655 004152 012737 014270 001232 6$: MOV #TEXT,TEXTP ;POINT TO BEGINNING OF TABLE.
656 004160 000772 BR 5$
657
658 004162 017777 175112 174750 PSWR: MOV JBSWR,JSWR ;READ SWITCH REGISTER
659 004170 017737 174744 001230 MOV JSWR,PATRN
660 004176 000137 004042 JMP OUTWR
661

```

;*PPM PROGRAM GENERATED PATTERN ROUTINE.*

```

;*
;* PATTM= FUNCTION
;* -----
;* 101 INCREMENT
;* 102 DECREMENT
;* 103 ;FLOAT 0 - COMPLEMENT
;* 104 ;COMPLEMENT
;*

```

```

673
674 004202 123727 001226 000101 PPM: CMPB PATTM,#'A ;INCREMENT PATTERN?
675 004210 001433 BEQ INCP ;YES-GO DO IT
676
677 004212 123727 001226 000102 1$: CMPB PATTM,#'B ;DECREMENT PATTERN?
678 004220 001432 BEQ DECP ;YES-GO DO IT
679
680 004222 123727 001226 000103 2$: CMPB PATTM,#'C ;FLOAT 0-COMPLEMENT?
681 004230 001031 BNE COMP ;NO-MUST BE STRAIGHT COMPLEMENT.
682
683 004232 005737 001230 3$: TST PATRN ;PATTERN=0
684 004236 001003 BNE 4$ ;NO-CONTINUE.
685 004240 005237 001230 INC PATRN ;YES-SET TO A ONE.
686 004244 000413 BR PPMEXT ;EXIT
687
688 004246 105737 001231 4$: TSTB PATRN+1 ;HIGH BYTE=0 (INDICATE COMPLEMENT)?
689 004252 001403 BEQ 6$ ;
690
691 004254 105737 001230 5$: TSTB PATRN ;LOW BYTE=0 (INDICATES COMPLEMENT)?
692 004260 001015 BNE COMP ;NO-THEN COMPLEMENT
693
694 004262 000241 6$: CLC ;FLOAT COMP.
695 004264 006137 001230 ROL PATRN
696 004270 005137 001230 COM PATRN
697
698 004274 000137 004042 PPMEXT: JMP OUTWR
699

```

```

700 004300 005237 001230      INCP:  INC      PATTRN      ; INCREMENT.
701 004304 000773              BR          PPMEXT
702
703 004306 005337 001230      DECP:  DEC      PATTRN      ; DECREMENT
704 004312 000770              BR          PPMEXT
705
706 004314 005137 001230      COMP:  COM      PATTRN      ; COMPLEMENT
707 004320 000765              BR          PPMEXT
708
  
```

;*ROUTINE TO SEND PATTERN TO OUTPUT MODULE

```

;*
;*      MODE      METHOD
;*      A          CONTINUOUS OUTPUT
;*      B          FLAG OUTPUT
;*      C          INTERRUPT OUTPUT.
;*      D          ; DELAYED OUTPUT.
;*
  
```

```

719 004322 005037 177776      SNDPAT: CLR      PS
720 004326 052777 000001 174640      BIS      #BIT00, @XCSRA
721 004334 123727 001220 000101      CMPB     MODE, #'A      ; CONTINUOUS OUTPUT.
722 004342 001002              BNE      1$
723 004344 000137 004404      JMP      AMODE          ; YES-GO OUTPUT
724
725 004350 123727 001220 000102 1$:      CMPB     MODE, #'B      ; FLAG OUTPUT?
726 004356 001002              BNE      2$
727 004360 000137 004416      JMP      BMODE          ; YES-GO OUTPUT.
728
729 004364 123727 001220 000103 2$:      CMPB     MODE, #'C      ; INTERRUPT OUTPUT?
730 004372 001002              BNE      3$
731 004374 000137 004444      JMP      CMODE          ; YES-GO OUTPUT.
732                          ; DELAYED MODE.
733 004400 000137 004554      3$:      JMP      DMODE          ; GO-OUTPUT
734
735                          ; *ROUTINE TO DO A STRAIGHT OUTPUT.
736
737 004404 013777 001230 174564  AMODE:  MOV      PATTRN, @XDBRA ; LOAD OUTPUT.
738 004412 000137 004046      JMP      OUTWR2
739
740                          ; *FLAG MODE OUTPUT.
741
742 004416 004737 004614      BMODE:  JSR      PC, TSTFLG
743 004422 032777 000200 174544      BIT      #BIT7, @XCSRA ; DONE SET?
744 004430 001772              BEQ      BMODE          ; NO-WAIT.
745 004432 013777 001230 174536      MOV      PATTRN, @XDBRA ; LOAD OUTPUT.
746 004440 000137 004046      JMP      OUTWR2
747
748                          ; *INTERRUPT MODE OUTPUT
749
750 004444 104412      CMODE:  GETXC
751 004446 012777 004512 174524      MOV      #2$, @XVT      ; SET VECTOR FOR INTERRUPT
752 004454 012777 000340 174520      MOV      #340, @XVT2    ; PRIORITY 7 ON INTERRUPT
753 004462 052777 000100 174504      BIS      #BIT6, @XCSRA ; ALLOW INTERRUPT.
754 004470 000240      1$:      NOP
755 004472 012737 000340 177776      MOV      #340, PS      ; LOCK OUT INTRs.
  
```

```

756 004500 004737 004614      JSR    PC,TSTFLG      ;CHECK REXMIT REQ.
757
758 004504 005037 177776      CLR    PS             ;NOW ALLOW INTRS. AGAIN.
759 004510 000767              BR     1$
760
761                          ;*WILL INTERRUPT TO HERE
762
763 004512 022626              2$:    POPSP2
764
765 004514 013777 001230 174454    MOV    PATTRN,@XDBRA  ;RESET STACK.
766 004522 042777 000100 174444    BIC    #BIT6,@XCSRA  ;OUTPUT PATTERN.
767 004530 013777 001202 174444    MOV    XVT2,@XVT2    ;DISABLE ENABLE.
768 004536 012777 104416 174436    MOV    #IOTT,@XVT2
769 004544 005037 177776      CLR    PS             ;ALLOW INTERRUPTS.
770 004550 000137 004046      JMP    OUTWR2
771
772                          ;*DELAYED OUTPUT MODE.
773
774 004554 052777 000001 174412    DMODE: BIS    #BIT0,@XCSRA ;DISABLE DRE.
775 004562 004737 004614      1$:    JSR    PC,TSTFLG
776 004566 105777 174402      TSTB  @XCSRA
777 004572 100373              BPL    1$
778 004574 042777 000001 174372    BIC    #BIT00,@XCSRA
779 004602 013777 001230 174366    MOV    PATTRN,@XDBRA ;LOAD OUTPUT.
780 004610 000137 004046      JMP    OUTWR2
781
782 004614                          TSTFLG:
783 004614 005777 174354      TST    @XCSRA        ;IS RECEIVER REQUESTING REXMIT
784 004620 100017              BPL    1$            ;OF DATA??
785 004622 162737 000002 001232    SUB    #2,TEXTP
786 004630 004737 007470      JSR    PC,RXMIT      ;YES-DO THE PROTOCAL.
787 004634 023727 001224 000104    CMP    PATFR0,#'D    ;PATTERN FROM TABLE?
788 004642 001006              BNE    1$
789 004644 017737 174362 001230    MOV    @TEXTP,PATTRN ;YES RESET PATTRN.
790 004652 062737 000002 001232    ADD    #2,TEXTP
791 004660                          1$:
792 004660 000207              RTS    PC            ;EXIT BACK TO WHENCE YOU CAME.
793
794

```

;*INPUT MODULE ROUTINE MODES G-J

```

798
799 004662 005737 001204      INPM: TST    RCSRA    ;ANY ADDR ENTERED?
800 004666 001026              BNE    1$
801
802 004670 104401 004676      TYPE   ,65$          ;;TYPE ASCIZ STRING
803 004674 000421              BR     ,64$          ;;GET OVER THE ASCIZ
804                          ;;65$: .ASCIZ <15><12>#NO INPUT MODULE ADDR. ENTERED!#
805 004740                          64$:
806 004740 000137 002646      JMP    INPASK
807
808                          1$:
809 004744 104401 004752      TYPE   ,67$          ;;TYPE ASCIZ STRING
810 004750 000423              BR     ,66$          ;;GET OVER THE ASCIZ
811                          ;;67$: .ASCIZ <15><12>#4.4.11 METHOD OF REPORTING DATA ? #

```

```

812 005020          66$:
813
814 005020 104407          RDLIN          ;GET RESPONSE
815 005022 012600          MOV          (SP)+,RO      ;ADDR OF RESPONSE ON STACK
816 005024 011037 001240  MOV          (RO),PATOUT  ;SAVE
817 005030 121027 000101  CMPB         (RO),#'A      ;> OR= TO 'A?'
818 005034 002743          BLT          1$
819 005036 121027 000104  CMPB         (RO),#'D      ;< OR= TO 'D?'
820 005042 003340          BGT          1$
821 005044 005777 174136  TST          @RDBRA
822 005050 013737 001220 001222  MOV          MODE,MODEI
823 005056 162737 000006 001220  SUB          #6,MODE
824
825
826 005064 023727 001240 000103  CMP          PATOUT, #'C   ;CONNECTED TO OUTPUT?
827 005072 001002          BNE          INPMWK      ;NO-CONTINUE
828 005074 000137 003500          JMP          OUTM        ;YES-MORE QUESTIONS
829
830          .SBTTL  INPUT MODULE ROUTINES
831
832
  
```

```

; *THIS ROUTINE INPMWK TAKES CARE OF MODES G-J
; *OF READING DATA.
  
```

```

837
838 005100 000402          INPMWK: BR          REDMOD      ;GO READ DATA FROM MODULE.
839
840 005102 000137 005300  INPRD: JMP          REPPAT      ;REPORT DATA.
841
  
```

```

; *REDMOD THIS ROUTINE DETERMINES HOW WE ARE
; *GOING TO READ THE INPUT MODULE
; *
; *      MODE          METHOD
; *      ----          -
; *      G              CONTINUOUS
; *      H              FLAG
; *      I              INTERRUPT
; *      J              DELAYED
; *
  
```

```

854
855 005106 123727 001222 000107  REDMOD: CMPB         MODEI, #'G      ;CONTINUOUS READ 'G?'
856 005114 001411          BEQ          GMODE
857
858 005116 123727 001222 000110  1$:  CMPB         MODEI, #'H      ;FLAG MODE READ 'H?'
859 005124 001412          BEQ          HMODE
860
861 005126 123727 001222 000111  2$:  CMPB         MODEI, #'I      ;INTERRUPT MODE READ 'I?'
862 005134 001416          BEQ          IMODE
863
864 005136 000444          3$:  BR          JMODE      ;DELAYED MODE.
865
866          ; *ROUTINE TO CONTINUOUS READ
867
  
```



```

868 005140 017737 174042 001242 GMODE: MOV   @RDBRA,PATTIN ;READ INPUT MODULE.
869 005146 000137 005102          JMP   INPRD
870
871                                     ;*ROUTINE TO READ WHEN FLAG IS SET.
872                                     ;*>>WARNING<< IF DISPLAYING RESULTS IN DATA LIGHTS, A RESET
873                                     ;*(SYSTEM INITIALIZE) IS USED AND COULD CLEAR THE FLAG.
874
875 005152 105777 174026          HMODE: TSTB@RCSRA          ;FLAG SET?
876 005156 100375          BPL   HMODE          ;NO-WAIT FOR IT
877 005160 017737 174022 001242 MOV   @RDBRA,PATTIN ;YES-READ
878 005166 000137 005102          JMP   INPRD
879
880                                     ;*IMODE ROUTINE TO READ THE INPUT MODULE ON INTERRUPT.
881                                     ;*>>WARNING<< IF DISPLAYING RESULTS IN DATA LIGHTS, A RESET
882                                     ;*(SYSTEM INITIALIZE IS USED AND COULD CLEAR MODULES "READY" FLAG (CSR
883                                     ;*BIT 7) AND NO INTERRUPT WOULD OCCUR.
884
885 005172 104411          IMODE: GETRC          ;GET INTERRUPT VECTOR.
886 005174 012777 005226 174006 MOV   #2$,@RVT      ;SET UP INTERRUPT VECTOR.
887 005202 012777 000340 174002 MOV   #340,@RVT2   ;PRIORITY INTERRUPT VECTOR
888 005210 052777 000100 173766 BIS   #BIT6,@RCSRA ;SET INTERRUPT ENABLE
889 005216 005037 177776          CLR   PS
890 005222 000001          1$: WAIT          ;WAIT HERE FOR INTERRUPT MODULE
891 005224 000776          BR   1$           ;SHOUD INTERRUPT WHEN IT RECEIVES DATA
892
893 005226 022626          2$: POPSP2
894 005230 032777 000100 173746 BIT   #BIT6,@RCSRA ;DISABLE ENABLE
895 005236 017737 173744 001242 MOV   @RDBRA,PATTIN ;READ MODULE.
896 005244 000137 005102          JMP   INPRD
897
898                                     ;*ROUTINE TO READ DELAYED MODE.
899
900 005250 042777 000001 173726 JMODE: BIC   #BIT0,@RCSRA ;CLEAR DRE
901 005256 017737 173724 001242 MOV   @RDBRA,PATTIN ;READ MODULE.
902 005264 000240          NOP
903 005266 052777 000001 173710 BIS   #BIT0,@RCSRA ;SET DRE
904 005274 000137 005102          JMP   INPRD
905

```

```

;*ROUTINE USED BY INPMWK TO DISPLAY DATA READ
;*FROM INPUT MODULE. XFERS CONTROL TO RIGHT ROUTINE.
;*
;*      PATOUT=      METHOD
;*      -----
;*      101          DATA LIGHTS
;*      102          TTY OUTPUT ON CHANGE
;*      103          ERROR CHECK OUTPUT > INPUT
;*      104          ERROR CHECK OUTPUT(OTHER CPU)>INPUT (THIS CPU)
;*

```

```

918
919 005300 123727 001240 000101 REPPAT: CMPB  PATOUT,#'A ;DISPLAY IN LIGHTS 'A?
920 005306 001002          BNE  1$
921 005310 000137 005604          JMP   DISLGH ;YES-GO DISPLAY
922
923 005314 123727 001240 000102 1$:  CMPB  PATOUT,#'B ;REPORT ON TTY 'B?

```

```

924 005322 001002          BNE 11$
925 005324 000137 005624  JMP DISTTY ;YES-GO REPORT
926
927 005330 123727 001240 000104 11$: CMPB PATOUT,#'D
928 005336 001002          BNE 2$
929 005340 000137 005700  JMP CIO ;OUTPUT > INPUT
930
931 005344 005237 001104          2$: INC $ICNT
932 005350 104414          SWCAL
933 005352 023727 001104 030000  CMP $ICNT,#30000
934 005360 001003          BNE 3$
935 005362 005037 001104  CLR $ICNT
936 005366 104413          EOPCAL
937 005370 023737 001230 001242 3$: CMP PATRN,PATTIN ;DATA OUTPUTTED=DATA READ
938 005376 001002          BNE 5$ ;NO-REPORT ERROR
939 005400 000137 005536          4$: JMP 7$ ;YES-EXIT
940 005404 005237 001112          5$: INC $ERTTL
941 005410 104414          SWCAL
942 005412 032777 020000 173520  BIT #BIT13,$SWR ;INHIBIT ERROR TYPEOUT?
943 005420 001040          BNE 6$
944
945 005422 104401 005430          TYPE ,65$ ;:TYPE ASCIZ STRING
946 005426 000413          BR 64$ ;:GET OVER THE ASCIZ
947 ;:65$: .ASCIZ <15><12>#GOOD DATA BAD DATA#
948 005456          64$:
949 005456 104401 005464          TYPE ,67$ ;:TYPE ASCIZ STRING
950 005462 000403          BR 66$ ;:GET OVER THE ASCIZ
951 ;:67$: .ASCIZ <15><12># #
952 005472          66$:
953 005472 013746 001230          MOV PATRN,-(SP) ;:SAVE PATRN FOR TYPEOUT
954 005476 104402          TYPOC ;:GO TYPE--OCTAL ASCII(ALL DIGITS)
955 005500 104401 005506          TYPE ,69$ ;:TYPE ASCIZ STRING
956 005504 000403          BR 68$ ;:GET OVER THE ASCIZ
957 ;:69$: .ASCIZ # #
958 005514          68$:
959 005514 013746 001242          MOV PATTIN,-(SP) ;:SAVE PATTIN FOR TYPEOUT
960 005520 104402          TYPOC ;:GO TYPE--OCTAL ASCII(ALL DIGITS)
961
962 005522 104414          6$: SWCAL
963 005524 032777 100000 173406  BIT #BIT15,$SWR ;:HALT ON ERROR?
964 005532 001401          BEQ 7$ ;:NO CONTINUE
965 005534 104415          HALTCL ;:HALTED ON DATA ERROR
966 ;:DATA SENT TO OUTPUT MODULE
967 ;:DOES NOT MATCH DATA READ
968 ;:IN INPUT MODULE
969 ;:DATA OUTPUTTED IN PATRN
970 ;:DATA READ IN PATTIN
971 005536 104414          7$: SWCAL
972 005540 032777 040000 173372  BIT #BIT14,$SWR ;:LOOP ON CURRENT PATTERN (IF FROM TABLE)
973 005546 001002          BNE 9$ ;:YES-7$
974 005550 000137 004040          8$: JMP OUTMVK
975
976 005554 022737 014270 001234  9$: CMP #TABLE, TABLEP ;:BEGINNING OF TABLE?
977 005562 001004          BNE 10$ ;:NO-GO 9$
978 005564 012737 014266 001234  MOV #TABLE-2, TABLEP ;:YES POINT TO END OF TABLE.
979 005572 000766          BR 8$ ;:EXIT
  
```

```

980 005574 162737 000002 001234 10$: SUB #2, TABLEP ;POINT TO ERROR DATA
981 005602 000762 BR 8$ ;EXIT
982
983 ;*DISLGH ROUTINE TO DISPLAY DATA
984
985 005604 013700 001242 DISLGH: MOV PATTIN, R0 ;DISPLAY USING DATA LIGHTS
986 005610 104417 RESETC ;DISPLAY
987 005612 052777 000100 173324 BIS #BIT6, J$TKS ;REENABLE TTY INTERRUPTS.
988 005620 000137 005100 JMP INPMWK ;EXIT
989
990 ;*ROUTINE TO TYPE INPUT DATA CHANGE ON TTY.
991
992 005624 023737 001244 001242 DISTTY: CMP PATOLD, PATTIN ;HAS INPUT DATA CHANGED?
993 005632 001415 BEQ 1$ ;NO-GO EXIT
994 005634 104414 SWCAL
995 005636 032777 020000 173274 BIT #BIT13, J$WR ;INHIBIT TYPEOUT?
996 005644 001010 BNE 1$
997 005646 104401 005654 TYPE 65$ ;;TYPE ASCIZ STRING
998 005652 000402 BR 64$ ;;GET OVER THE ASCIZ
999
1000 005660 ;;65$: .ASCIZ <15><12>
1001 005660 013746 001242 MOV PATTIN, -(SP) ;;SAVE PATTIN FOR TYPEOUT
1002 005664 104402 TYPOC ;;GO TYPE--OCTAL ASCII(ALL DIGITS)
1003
1004 005666 013737 001242 001244 1$: MOV PATTIN, PATOLD ;OLD PATTERN=NEW PATTERN
1005 005674 000137 005100 JMP INPMWK
1006
1007

```

```

;*
;*ROUTINE USED BY REPPAT TO COMPARE DATA IN TO
;*TABLE DATA.
;*REPORT DATA MEATHOD ""D""
;*

```

```

1015
1016
1017 005700 023777 001242 173326 C10: CMP PATTIN, JTABLEP ;DATA RECEIVED=TABLE DATA?
1018 005706 001403 BEQ 1$ ;YES-GOTO END.
1019
1020 005710 004737 006450 JSR PC, SLERR ;NO-REPORT ERROR.
1021 005714 000403 BR 2$
1022 005716 062737 000002 001234 1$: ADD #2, TABLEP ;UPDATE TAPBLE POINT FOR NEXT DATA.
1023 005724 023727 001234 014642 2$: CMP TABLEP, #TABLEE ;DONE WHOLE TABLE?
1024 005732 001014 BNE 3$
1025 005734 012737 014270 001234 MOV #TABLE, TABLEP ;YES-RESET TABLE POINTER.
1026 005742 005237 001104 INC $ICNT ;UPDATE ITERATION COUNT.
1027 005746 023727 001104 001000 CMP $ICNT, #1000 ;DONE TABLE 1000 TIMES?
1028 005754 001003 BNE 3$ ;NO-EXIT.
1029
1030 005756 104413 EOPCAL ;YES REPOR END 0' PASS.
1031 005760 005037 001104 CLR $ICNT
1032
1033 005764 000137 005100 3$: JMP INPMWK ;EXIT.
1034
1035 .SBTTL SLAVE-MASTER AUTO SEND MODES

```

1036
 1037

;*STARTS ROUTINE TO START SLAVE AUTO MODE.

```

1041
1042 005770 005737 001204     STARTS: TST     RCSRA           ;ANY INPUT ADDR. ENTERED?
1043 005774 001402                BEQ     1$                    ;NO-REPORT ERROR
1044 005776 000137 006312     JMP     SMST                   ;YES-START SLAVE
1045
1046 006002 005037 177776     1$:    CLR     PS              ;NO CLEAR TRAP BIT IN CASE OF ENTRY FROM STRTMS
1047 006006 104401 006014     TYPE   65$                    ;TYPE ASCIZ STRING
1048 006012 000420                BR      64$                    ;GET OVER THE ASCIZ
1049                                     ;:65$: .ASCIZ <15><12>#NO INPUT MODULE ADDR ENTERED!#
1050                                     64$:
1051 006054 012706 001100     MOV     #STACK,SP             ;RESET STACK
1052 006060 000137 002646     JMP     INPASK                 ;GO GET ADDR.
1053
  
```

;*STARTM ROUTINE USED TO START MASTER AUTO MODE

```

1057
1058 006064 005737 001174     STARTM: TST     XCSRA          ;ANY OUTPUT MODULE ADDR. ENTERED?
1059 006070 001402                BEQ     1$                    ;NO REPORT ERROR
1060 006072 000137 007304     JMP     MST                    ;YES-START TEST.
1061
1062 006076 005037 177776     1$:    CLR     PS              ;CLEAR T BIT TRAPS IF RUNNING
1063                                     ;MASTER-SLAVE AUTO
1064 006102 104401 006110     TYPE   65$                    ;TYPE ASCIZ STRING
1065 006106 000421                BR      64$                    ;GET OVER THE ASCIZ
1066                                     ;:65$: .ASCIZ <15><12>#NO OUTPUT MODULE ADDR. ENTERED#
1067                                     64$:
1068 006152 012706 001100     MOV     #STACK,SP             ;RESET STACK POINTER
1069 006156 000137 002752     JMP     OUTASK                 ;GET ADDR.
1070
  
```

;*STRTMS USED TO START MASTER (STARTM) AND SLAVE
 ;*(STARTS) ROUTINE IF BOTH INPUT AND OUTPUT RESIDE ON SAME CPU.

```

1075
1076 006162 012737 006064 001246  STRTMS: MOV     #STARTM,PTRM    ;POINT TO BEGINNING OF MASTER ROUTINE
1077 006170 012737 005770 001250  MOV     #STARTS,PTRS         ;POINT TO BEGINNING OF SLAVE ROUTINE.
1078
1079 006176 012746 000020                MOV     #20,-(SP)            ;SET T BIT ON STACK
1080 006202 013746 001246                MOV     PTRM,-(SP)          ;GO TO MASTER ROUTINE FIRST
1081 006206 012737 006232 000014  MOV     #MTTRAP,2#14        ;SET FOR T BIT TRAP.
1082 006214 012737 000340 000016  MOV     #340,2#16          ;PRIORITY 7 ON TRAP
1083 006222 012737 000020 001254  MOV     #20,SSLST          ;T BIT IN SLAVE STATUS
1084 006230 000002                RTI                          ;EXECUTE FIRST INSTRUCTION OF
1085                                     ;MASTER ROUTINE
1086
1087                                     ;*MTTRAP ENTER HERE ON TRAPS FROM MASTER ROUTINE
1088
1089 006232                MTTRAP:
1090                                     ;YES MUST BE 11/40 OR 11/45 DO RTT
1091
  
```

```

1092 006232 012737 006262 000014 1$: MOV #STTRP, @#14 ;SET TO TRAP TO SLAVE HANDLER
1093 006240 012637 001246 MOV (SP)+, PTRM ;SAVE MASTER PC.
1094 006244 012637 001252 MOV (SP)+, SMSST ;SAVE MASTER STATUS
1095 006250 013746 001254 MOV SSLST, -(SP) ;USE SLAVE STATUS
1096 006254 013746 001250 MOV PTRS, -(SP) ;USE SLAVE PC.
1097 006260 000002 INSRT1: RTI ;WILL BE REPLACE TO RTT(000006) IF 11/40 OR GREATER.
1098
1099 ;* STTRP ENTER HERE ON T BIT TRAPS FROM MASTER ROUTINE
1100
1101 006262 STTRP:
1102
1103 006262 012737 006232 000014 1$: MOV #MTTRP, @#14 ;SET TO TRAP TO MASTER HANDLER.
1104 006270 012637 001250 MOV (SP)+, PTRS ;SAVE SLAVE'S PC
1105 006274 012637 001254 MOV (SP)+, SSLST ;SAVE SLAVE'S STATUS
1106 006300 013746 001252 MOV SMSST, -(SP) ;USE MASTER'S STATUS
1107 006304 013746 001246 MOV PTRM, -(SP) ;USE MASTER'S PC.
1108 006310 000002 INSRT2: RTI ;WILL VE REPLACED TO RTT(000006) IF 11/40 OR GREATER.
1109
1110 .SBTTL SLAVE AUTO RECIEVE MODE
1111
1112

```

;*ACTUAL SLAVE FLOWS

```

1116
1117 006312 104401 015226 SMST: TYPE ,MSM ;TYPE "START MODE"
1118
1119 ;*INITIATED INTER-CPU-DIALOGUE
1120 006316 005777 172662 SP1: TST @RCSRA ;STAT BIT SET?
1121 006322 100375 BPL SP1 ;NO WAIT FOR IT. NOTE: STAT BIT SETS
1122 ;WHEN MASTER SETS ITS CONTR BIT (BIT 8)
1123
1124 006324 052777 000400 172652 SP2: BIS #BIT8, @RCSRA ;SET CONTR. BIT (SETS MASTER'S STAT BIT)
1125
1126 006332 005777 172646 SP3: TST @RCSRA ;STAT BIT CLEAR?
1127 006336 100775 BMI SP3 ;NO WAIT FOR IT. NOTE: STAT BIT
1128 ;CLEARS WHEN CLEARS IT CONTR BIT
1129
1130 006340 005777 172642 SP3A: TST @RDBRA ;DUMB READ.
1131 006344 042777 000400 172632 BIC #BIT8, @RCSRA ;CLEAR CONTR BIT
1132
1133 .SBTTL SLAVE IMMED. SEND MODE
1134
1135 ;*IMMEDIATE SEND MODE
1136
1137
1138 006352 012737 001000 001260 SISM: MOV #1000, SXNO ;SET ITERATION COUNT
1139
1140 006360 104401 015243 SP13: TYPE ,MIM ;TYPE "IMMED. SEND MODE"
1141
1142 006364 012737 014270 001234 SP14: MOV #TABLE, TABLEP ;POINT TO BEGINNING OF TEXT.
1143
1144 006372 022737 014642 001234 SP15: CMP #TABLEE, TABLEP ;DONE ALL TEXT?
1145 006400 001521 BEQ SP22 ;YES POINT 22
1146
1147 006402 105777 172576 SP18: TSTB @RCSRA ;DATA AVAILABLE?

```

```

1148 006406 100375          BPL      SP18          ;NO-WAIT FOR IT
1149
1150 006410 017737 172572 001242 SP16:  MOV      @RDBRA,PATTIN ;YES-READ DATA
1151 006416 023777 001242 172610      CMP      PATTIN,@TABLEP ;DATA READ=TABLE?
1152 006424 001005          BNE      SP19          ;NO-REPORT ERROR
1153 006426 062737 000002 001234      ADD      #2, TABLEP    ;YES-UPDATE TABLE POINTER
1154 006434 000137 006372          JMP      SP15          ;LOOP
1155
1156 006440 004737 006450          SP19:  JSR      PC,SLERR  ;REPORT ERROR HANDLER.
1157 006444 000137 006372          JMP      SP15
1158
1159 006450 104414          SLERR:  SWCAL
1160 006452 032777 020000 172460      BIT      #BIT13,@SWR   ;INHIBIT ERROR TYPEOUT?
1161 006460 001042          BNE      1$          ;YES-SKIP IT
1162
1163 006462 104401 006470          TYPE    ,65$        ;;TYPE ASCIZ STRING
1164 006466 000414          BR      64$        ;;GET OVER THE ASCIZ
1165          ;;65$: .ASCIZ <15><12>#ERROR DATA GOOD DATA#
1166 006520          64$:
1167 006520 104401 006526          TYPE    ,67$        ;;TYPE ASCIZ STRING
1168 006524 000403          BR      66$        ;;GET OVER THE ASCIZ
1169          ;;67$: .ASCIZ <15><12># #
1170 006534          66$:
1171 006534 013746 001242          MOV      PATTIN,-(SP) ;;SAVE PATTIN FOR TYPEOUT
1172 006540 104402          TYPOC   ;           ;;GO TYPE--OCTAL ASCII(ALL DIGITS)
1173 006542 104401 006550          TYPE    ,69$        ;;TYPE ASCIZ STRING
1174 006546 000404          BR      68$        ;;GET OVER THE ASCIZ
1175          ;;69$: .ASCIZ # #
1176 006560          68$:
1177 006560 017746 172450          MOV      @TABLEP,-(SP) ;;SAVE @TABLEP FOR TYPEOUT
1178 006564 104402          TYPOC   ;           ;;GO TYPE--OCTAL ASCII(ALL DIGITS)
1179
1180 006566 005237 001112          1$:     INC      $ERTTL
1181 006572 104414          SWCAL
1182 006574 032777 004000 172336      BIT      #BIT11,@SWR   ;CONTINUE PAST ERROR?
1183 006602 001404          BEQ     SP17        ;NO-POINT 17
1184 006604 062737 000002 001234      ADD      #2, TABLEP    ;YES-UPDATE POINTER
1185 006612 000207          RTS     PC
1186
1187 006614 052777 000400 172362 SP17:  BIS      #BIT8,@RCSRA  ;SET CONTR BIT-REQUEST REXMIT OF DATA
1188
1189 006622 005777 172356          SP20:  TST      @RCSRA     ;STAT BIT SET? SET WHEN MASTER
1190 006626 100375          BPL     SP20        ;NO-WAIT FOR IT
1191
1192 006630 005777 172352          SP21:  TST      @RDBRA ;DUMB READ.
1193 006634 042777 000400 172342      BIC     #BIT8,@RCSRA  ;YES-CLEAR CONTROL BIT
1194 006642 000207          RTS     PC
1195
1196 006644 005337 001260          SP22:  DEC      SXNO      ;XNO=XNO-1 DECREMENT ITERATION COUNT
1197
1198 006650 001245          BNE     SP14        ;OTHERWISE ITERATE
1199 006652 104414          SWCAL
1200 006654 032777 040000 172256      BIT      #BIT14,@SWR
1201 006662 001233          BNE     SISM
1202
1203          1$:

```

```

1204          .SBTTL  SLAVE BURST SEND MODE
1205
1206
1207          ;*BURST SEND MODE
1208
1209 006664 104401 015267          SBSM:  TYPE      ,MBM          ;TYPE "BURST SEND MODE"
1210
1211 006670 012737 001000 001260 SP24:  MOV      #1000, SXNO          ;SET ITERATION COUNT
1212
1213 006676 005737 001260          SP25:  TST      SXNO          ;DONE 5 TIMES?
1214 006702 001010          BNE     SP26          ;NO-CONTINUE POINT 26.
1215 006704 104414          SWCAL
1216
1217 006706 032777 040000 172224          BIT     #BIT14, @SWR
1218 006714 001363          BNE     SBSM
1219          SF32:
1220 006716 104413          EOPCAL
1221 006720 000137 006312          JMP     SMST
1222
1223 006724 005777 172254          SP26:  TST     @RCSRA          ;STAT BIT SET?
1224 006730 100375          BPL     SP26          ;NO-WAIT FOR IT
1225
1226 006732 052777 000400 172244 SP27:  BIS     #BIT8, @RCSRA          ;YES-SET CONTROL BIT
1227
1228 006740 005777 172240          SP28:  TST     @RCSRA          ;STAT BIT CLEAR?
1229 006744 100775          BMI     SP28          ;NO-WAIT TILL CLEAR
1230
1231 006746 042777 000400 172230 SP29:  BIC     #BIT8, @RCSRA          ;CLEAR CONTROL BIT
1232 006754 012737 014644 001262          MOV     #STABL, STABLP          ;POINT TO BEGINNING OF TABLE
1233 006762 012737 014270 001234          MOV     #TABLE, TABLEP
1234 006770 104411          GETRC
1235 006772 012777 007260 172210          MOV     #BISR, @RVT          ;GFET VECTOR ADDR.
1236 007000 012777 000340 172204          MOV     #340, @RVT2          ;SET FOR INTERRUPT
1237 007006 052777 000100 172170          BIS     #BIT6, @RCSRA          ;PRIORITY 7 ON INTR.
1238          ;SET INTR. ENABLE
1239 007014 042737 000340 177776          BIC     #340, PS
1240 007022 000240          SP30:  NOP
1241          ;RECEIVE INTERRUPTS FOR EACH DATA XFER
1242 007024 023727 001234 014644 SP31:  CMP     TABLEP, #TABLEE+2          ;RECEIVED WHOLE TEXT?
1243 007032 001373          BNE     SP30          ;NO-WAIT FOR THEM
1244 007034 042777 000100 172142          BIC     #BIT6, @RCSRA          ;DON'T ALLOW INPUT TO INTERRUPT.
1245
1246 007042 012737 014644 001262 SP33:  MOV     #STABL, STABLP          ;POINT TO BEGINNING OF STORAGE TABLE
1247 007050 012737 014270 001234          MOV     #TABLE, TABLEP          ;POINT TO TEXT TABLE
1248
1249 007056 027777 172200 172150 SP34:  CMP     @STABLP, @TABLEP          ;DATA RECEIVED=TEXT?
1250 007064 001016          BNE     SP37          ;NO REPORT ERROR
1251
1252 007066 062737 000002 001262 SP35:  ADD     #2, STABLP          ;UPDATE TABLE POINTERS
1253 007074 062737 000002 001234          ADD     #2, TABLEP
1254
1255 007102 022737 014642 001234 SP36:  CMP     #TABLEE, TABLEP          ;COMPARED WHOLE TEXT?
1256 007110 001362          BNE     SP34          ;NO-DO NEXT COMPARE
1257
1258 007112 005337 001260          SP36A: DEC     SXNO          ;YES UP ITERATIN COUNT
1259 007116 000137 006676          JMP     SP25          ;LOOP
    
```

```

1260
1261 007122 104414
1262 007124 032777 020000 172006 SP37: SWCAL
1263 007132 001042 BIT #BIT13,@SWR ;INHIBIT ERROR TYPEOUT?
1264 ;:65$: .ASCIZ <15><12>#ERROR DATA GOOD DATA# ;YES-THEN SKIP
1265 007134 104401 007142 TYPE ,65$ ;;TYPE ASCIZ STRING
1266 007140 000414 BR 64$ ;;GET OVER THE ASCIZ
1267 ;:65$: .ASCIZ <15><12>#ERROR DATA GOOD DATA#
1268 007172 ;:64$:
1269 007172 104401 007200 TYPE ,67$ ;;TYPE ASCIZ STRING
1270 007176 000403 BR 66$ ;;GET OVER THE ASCIZ
1271 ;:67$: .ASCIZ <15><12>#
1272 007206 ;:66$:
1273 007206 017746 172022 MOV @TABLEP,-(SP) ;;SAVE @TABLEP FOR TYPEOUT
1274 007212 104402 TYPOC ;;GO TYPE--OCTAL ASCII(ALL DIGITS)
1275 007214 104401 007222 TYPE ,69$ ;;TYPE ASCIZ STRING
1276 007220 000404 BR 68$ ;;GET OVER THE ASCIZ
1277 ;:69$: .ASCIZ # #
1278 007232 ;:68$:
1279 007232 017746 172024 MOV @STABLP,-(SP) ;;SAVE @STABLP FOR TYPEOUT
1280 007236 104402 TYPOC ;;GO TYPE--OCTAL ASCII(ALL DIGITS)
1281
1282 007240 005237 001112 1$: INC $ERTTL
1283 007244 104414 SWCAL
1284 007246 032777 004000 171664 BIT #BIT11,@SWR ;CONTINUE?
1285 007254 001316 BNE SP36A ;YES
1286 007256 000703 BR SP35 ;NO-LOOP
1287
1288 ;*INTERRUPT HANDLER FOR SBSM
1289
1290 007260 017777 171722 171774 BISR: MOV @RDBRA,@STABLP ;READ AND STORE DATA
1291 007266 062737 000002 001262 ADD #2,STABLP ;UPDATE STORE POINTER
1292 007274 062737 000002 001234 ADD #2, TABLEP
1293 007302 000002 RTI ;EXIT THIS INTERRUPT
1294 .SBTTL MASTER AUTO SEND MODES-- START MODE
1295

```

;*INITIAL INTER-CPU DIALOGUE


```

1299
1300 007304 104401 015226          MST:  TYPE      ,MSM          ;TYPE "START MODE"
1301
1302 007310 052777 000400 171656 P1:   BIS        #BIT8,  @XCSRA  ;SET CONTROL BIT.
1303                                     ;(SETS SLAVE'S STAT BIT).
1304
1305 007316 005777 171652          P2:   TST        @XCSRA  ;NO MASTER'S STAT BIT SET?
1306 007322 100375          BPL        P2          ;SET WHEN SLAVE SETS IT'S
1307                                     ;CONTR. BIT.
1308                                     ;WAIT TILL SET.
1309
1310 007324 042777 000400 171642 P3:   BIC        #BIT8,  @XCSRA  ;CLEAR CONTROL BIT.
1311                                     ;(CLEARS SLAVE'S STAT BIT).
1312 007332 005777 171636          TST        @XCSRA
1313 007336 100772          BMI        P3
1314
1315                                     .SBTTL MASTER IMMEDIATE SEND MODE
1316

; *ISM IMMEDIATE MODE SEND

1322
1323 007340 052777 000001 171626 ISM:  BIS        #BIT0,  @XCSRA  ;SET BIT 0.
1324 007346 012737 001000 001256          MOV        #1000, XNO    ;SET XMITT LOOP TO 5
1325
1326 007354 104401 015243          P13:  TYPE      ,MIM          ;TYPE "IMMED. SEND MODE"
1327
1328 007360 012737 014270 001232 P14:  MOV        #TEXT,  TEXTP   ;POINT TO BEGINNING OF TEXT.
1329
1330 007366 023727 001232 014642 P15:  CMP        TEXTP,  #TEXTE  ;TRANSMITTED WHOLE TEXT?
1331 007374 001016          BNE        P16          ;NO-CONTINUE.
1332
1333 007376 162737 000001 001256 P22:  SUB        #1,      XNO     ;XNO=XNO-1
1334
1335 007404 001365          P23:  BNE        P14          ;IF NOT DONE 5 TIMES REPEAT.
1336 007406 104414
1337 007410 032777 040000 171522          SWCAL
1338 007416 001350          BIT        #BIT14, @SWR
1339 007420          BNE        ISM
1340
1341 007420 000137 007574          JMP        BSM          ;IF 5 THEN BUST MODE.
1342
1343
1344 007424 005777 171544          P17:  TST        @XCSRA    ;STAT BIT SET? SET BY SLAVE WHEN
1345                                     ;SLAVE WANTS LAST DATA
1346                                     ;RETRANSMITTED.
1347                                     ;IF SO GO DO IT.
1348
1349 007430 100413          BMI        P19
1350
1351 007432 032777 000200 171534 P16:  BIT        #BIT7, @XCSRA  ;DATA REQUEST SET?
1352 007440 001771          BEQ        P17          ;IF NOT WAIT FOR IT.
1353
1354 007442 017777 171564 171526 P18:  MOV        @TEXTP, @XDBRA  ;LOAD DATA.
1355
1356 007450 062737 000002 001232          ADD        #2,      TEXTP   ;UPDATE TEXT POINTER.

```

```

1355 007456 000743          BR      P15          ;LOOP BACK
1356
1357 007460 004737 007470    P19:    JSR      PC,RXMIT
1358 007464 000137 007366          JMP      P15
1359 007470 162737 000004 001232  RXMIT:  SUB      #4,      TEXTP  ;POINT TO DATA TO BE RE-SENT.
1360 007476 104414          SWCAL
1361 007500 032777 020000 171432  BIT      #BIT13, @SWR   ;INHIBIT ERROR MESSAGE?
1362 007506 001020          BNE     P20           ;IF SO-SKIP TYPEOUT
1363
1364 007510 104401 007516          TYPE     ,55$         ;:TYPE ASCIZ STRING
1365 007514 000412          BR      ,64$         ;:GET OVER THE ASCIZ
1366
1367 007542          ;:65$: .ASCIZ <15><12>#RESENDING DATA: #
1368 007542 017746 171464          MOV     @TEXTP,-(SP)  ;:SAVE @TEXTP FOR TYPEOUT
1369 007546 104402          TYPOC   ;:GO TYPE--OCTAL ASCII(ALL DIGITS)
1370
1371 007550 052777 000400 171416  P20:    BIS      #BIT8, @XCSRA ;SET CONTR. BIT TO ACKNOWLEDGE
1372          ;:SLAVE'S CONTR. BIT. (SETS SLAVE'S
1373          ;:STAT BIT.
1374
1375 007556 005777 171412          P21:    TST          @XCSRA ;:STAT BIT CLEAR? CLEAR WHEN
1376          ;:SLAVE SEES MASTERS CONTR SET.
1377 007562 100775          BMI     P21         ;:NO THEN WAIT.
1378
1379 007564 042777 000400 171402  BIC     #BIT8, @XCSRA ;YES - CLEAR CONTROL (CLEARS
1380          ;:SLAVE'S STAT BIT).
1381
1382 007572 000207          RTS     PC
1383
1384          .SBTTL MASTER BURST MODE SEND
1385
1386

```

;*BURST MODE SENT

```

1392
1393 007574 104401 015267          BSM:    TYPE     ,MBM      ;TYPE "BURST SEND MODE"
1394
1395 007600 012737 001000 001256  P24:    MOV      #1000, XNO    ;SET XMITT NO. TO 5
1396
1397 007606 023727 001256 000000  P25:    CMP      XNO,      #0    ;DONE 1000 TIMES?
1398 007614 001024          BNE     P26         ;NO - CONTINUE.
1399
1400 007616 104414          SWCAL
1401 007620 032777 040000 171312  BIT      #BIT14, @SWR
1402 007626 001362          BNE     BSM
1403
1404 007630 104413          P32:    EOPCAL
1405 007632 023727 001220 000115  CMP     MODE, #'M
1406 007640 001007          BNE     2$
1407 007642 005337 001100          DEC     $PASS
1408 007646 005037 007664          CLR     3$
1409 007652 005237 007664          1$:    INC     3$
1410 007656 001375          BNE     1$

```

```

1411 007660          2$:
1412
1413 007660 000137 007304          JMP      MST
1414
1415 007664 000000          3$:      .WORD  0
1416
1417
1418 007666 052777 000400 171300 P26:    BIS      #BIT8, @XCSRA ;SET CONTR. BIT. (SET SLAVE
1419                                ;SEES MASTER'S CONTR AND SETS ITS
1420                                ;CONTR BIT.
1421 007674 005777 171274          P27:    TST      @XCSRA ;STAT IN BIT SET YET?
1422
1423 007700 100375          BPL      P27          ;IF NOT SET - WAIT FOR IT.
1424
1425
1426 007702 042777 000400 171264 P28:    BIC      #BIT8, @XCSRA ;CLEAR CONTROL BIT (CLEARS
1427                                ;SLAVE'S STAT BIT.
1428 007710 104412          GETXC          ;GET INTERRUPT VECTOR.
1429
1430 007712 012777 010016 171260          MOV      #ISR, @XVT ;SET UP INTERRUPT VECTOR.
1431 007720 012777 000340 171254          MOV      #340, @XVT2 ;PRIORITY 7 ON INTERRUPT.
1432
1433 007726 042777 000001 171240          BIC      #BIT0, @XCSRA ;CLEAR ACCEPT.
1434 007734 012737 014270 001232          MOV      #TEXT, TEXTP ;POINT TO BEGINNING OF TEXT.
1435
1436 007742 017777 171264 171226 P29:    MOV      @TEXTP, @XDBRA ;FORCE 1ST XFERR.
1437 007750 062737 000002 001232          ADD      #2, TEXTP ;POINT TO NEXT WORD ON INTR.
1438 007756 052777 000101 171210          BIS      #BIT6!BIT0, @XCSRA ;SET INTR ENABLE, DATA EXCEPT.
1439 007764 042737 000340 177776          BIC      #340, PS
1440 007772 000240          P30:    NOP ;DATA REQUEST INTERRUPTS
1441                                ;OCCUR HERE.
1442 007774 023727 001232 014644 P31:    CMP      TEXTP, #TEXTE+2 ;TRANSFERRED WHOLE TEXT YET?
1443 010002 001373          BNE          P30 ;NO GO BACK AND WAIT.
1444
1445 010004 162737 000001 001256          SUB      #1, XNO ;YES, XNO=XNO -1
1446 010012 000137 007606          JMP      P25 ;GO BACK TO MAIN LINE
1447
  
```

```

; *INTERRUPT SERVICE ROUTINE FOR BSM)
; *LOADS NEW DATA CHECKS FOR END OF TEXT.
; *IF END IS REACHED, CLEARS INTR. ENABLE.
  
```

```

1455
1456 010016 017777 171210 171152 ISR:    MOV      @TEXTP, @XDBRA ;LOAD NEW DATA.
1457 010024 023727 001232 014642          CMP      TEXTP, #TEXTE ;XFERRERD WHOLE TEXT?
1458 010032 001003          BNE      1$ ;NO - EXIT
1459 010034 042777 000100 171132          BIC      #BIT6, @XCSRA ;YES - CLEAR INTR. ENABLE.
1460
1461 010042 062737 000002 001232 1$:    ADD      #2, TEXTP ;RETURN FROM INTR.
1462 010050 000002          RTI
1463
1464          .SBTTL INPUT MODULE'S CSR/DBR TESTS.
  
```

;*INPUT MODULE'S CSR, DBR TEST
;*ENTER WITH: RCSRT=ADDR. OF CSR UNDER TEST
;* RDBRT=ADDR. OF DBR UNDER TEST

```

1471
1472 010052 013737 001204 001120 IMLT:  MOV    RCSRA,  $GDADR  ;SET CSR ADDR FOR ERROR TYFOUT
1473
1474                                     ;:*****
1475                                     ;*TEST 1          *TEST CSR ADDRESS ABILITY
1476                                     ;:*****
1477 010060 000240          †ST1:  NOP
1478 010062 012737 010070 001106      MOV    #3$, $LPADR  ;;SET SCOPE LOOP ADDRESS
1479
1480 010070 013746 000004          3$:   MOV    @#4,  -(SP)  ;SAVE CONTENTS OF LOCATION 4 ON STACK.
1481 010074 012737 010110 000004      MOV    #1$,  @#4    ;SET LOC. IN CASE OF "TRAP" IF CSR DOES NOT RESPOND
1482 010102 005777 171076          TST   @RCSRA      ;ADDRESS CSR
1483 010106 000402          BR    2$         ;NO-TRAP IF HERE - NEXT TEST.
1484
1485 010110          1$:           ;TRAP HERE IS CSR DOES NOT RESPOND BY RETURNING SLAVE-SYNC.
1486 010110 022626          POPSP2          ;RESET STACK POINTER (R6).
1487 010112 104000          ERROR         ;NO RESPONSE FROM CSR UNDER TEST.
1488
1489 010114 012637 000004          2$:   MOV    (SP)+, @#4  ;RESTORE CONTENTS OF LOCATION 4 FROM STACK.
1490
1491                                     ;:*****
1492                                     ;*TEST 2          *TEST DBR ADDRESS ABILITY
1493                                     ;:*****
1494 010120 000004          †ST2:  SCOPE
1495
1496 010122 013746 000004          MOV    @#4,  -(SP)  ;SAVE CONTENTS OF LOCATION 4 ON STACK.
1497 010126 012737 010142 000004      MOV    #1$,  @#4    ;SET LOC. 4 IN CASE OF TRAP IF DBR DOES NOT RESPOND
1498 010134 005777 171046          TST   @RDBRA      ;ADDRESS DBR
1499 010140 000402          BR    2$         ;NO TRAP IF HERE - NEXT TEST.
1500
1501 010142          1$:           ;TRAP HERE IF DBR DOES NOT RESPOND BY RETURNING SLAVE-SYNC.
1502
1503 010142 022626          POPSP2          ;RESET STACK POINTER (R6).
1504 010144 104000          ERROR         ;NO RESPONSE FROM DBR UNDER TEST.
1505
1506 010146 012637 000004          2$:   MOV    (SP)+, @#4  ;RESTORE CONTENTS OF LOC. 4 FROM STACK.
1507
1508                                     ;:*****
1509                                     ;*TEST 3          *TEST THAT CSR BIT 0 IS SET ON INIT
1510                                     ;:*****
1511 010152 000004          †ST3:  SCOPE
1512 010154 012737 000002 001166      MOV    #2, $TIMES  ;;DO 2 ITERATIONS
1513
1514 010162 005737 001100          TST   $PASS      ;ONLY DO THIS TEST ON PASS 1.
1515 010166 001014          BNE   1$
1516 010170 104417          RESETC
1517 010172 017737 171006 001126      MOV    @RCSRA, $BDDAT ;READ CSR.
1518 010200 042737 177776 001126      BIC   #177776, $BDDAT ;ONLY WANT BIT 0 .
1519 010206 022737 000001 001126      CMP   #1,  $BDDAT   ;IS IT SET?
1520 010214 001401          BEQ   1$         ;YES - NEXT TEST.
1521
1522 010216 104000          ERROR         ;CSR BIT 0 NOT SET ON INIT.

```

```

1523                                     ;CSR DATA IN $BDDAT.
1524 010220 1$:
1525
1526 ::*****
1527 *TEST 4 *TEST THAT CSR BITS 6,7,AND 8 ARE CLEAR ON INIT.
1528 ::*****
1529 010220 000004 TST4: SCOPE
1530 010222 012737 000002 001166 MOV #2,$TIMES ;;DO 2 ITERATIONS
1531 010230 005737 001100 TST $PASS ;ONLY DO THIS TEST ON FIRST PASS.
1532 010234 001006 BNE 1$
1533 010236 104417 RESETC
1534 010240 032777 000700 170736 BIT #BIT6!BIT7!BIT8,$RCSRA ;SEE IF BITS 6,7,8,AND 15 ARE CLEAR.
1535 010246 001401 BEQ 1$
1536
1537                                     ;CSR BIT(S) 6,7,8, OR 15 NOT CLEAR ON
1538 010250 104000 ERROR ;SYSTEM INITIALIZE.
1539
1540 010252 1$:
1541
1542 ::*****
1543 *TEST 5 *TEST THAT CSR BITS 0,6, AND 8 CAN BE CLEARED
1544 ::*****
1545 010252 000004 TST5: SCOPE
1546 010254 012737 000005 001166 MOV #5,$TIMES ;;DO 5 ITERATIONS
1547
1548 010262 005737 001100 TST $PASS
1549 010266 001022 BNE 1$
1550 010270 104417 RESETC ;SET BITS 0 AND 1.
1551 010272 012737 000340 177776 MOV #340, PS
1552 010300 052777 000500 170676 BIS #BIT6!BIT8,$RCSRA ;SET BITS 6 AND 8
1553 010306 042777 000501 170670 BIC #BIT0!BIT6!BIT8,$RCSRA
1554 010314 017737 170664 001126 MOV $RCSRA,$BDDAT ;READ CSR.
1555 010322 032737 000501 001126 BIT #BIT0!BIT6!BIT8,$BDDAT ;SEE IF ANY ARE SET.
1556 010330 001401 BEQ 1$ ;NO - CONTINUE.
1557
1558 010332 104000 ERROR ;CSR BIT(S) 0 AND/OR 1 AND/OR 6 AND/OR 8
1559 ;COULD NOT BE BIT CLEAR. CSR RESULTS
1560 ;IN $BDDAT.
1561
1562 010334 052777 000100 170602 1$: BIS #BIT6,$STKS ;RE-ENABLE TTY INTERRUPTS.
1563 010342 005077 170636 CLR $RCSRA
1564 010346 005037 177776 CLR PS
1565
1566 ::*****
1567 *TEST 6 *TEST THAT CSR BITS 6, AND 8 CAN BE BIT SET
1568 ::*****
1569 010352 000004 TST6: SCOPE
1570
1571 010354 012737 000340 177776 MOV #340, PS
1572 010362 042777 000500 170614 BIC #BIT6!BIT8,$RCSRA ;MAKE SURE THEY ARE CLEAR
1573 010370 052777 000500 170606 BIS #BIT6!BIT8,$RCSRA ;THEN SET THEM.
1574
1575 010376 017737 170602 001126 MOV $RCSRA,$BDDAT ;READ CSR.
1576 010404 042737 177277 001126 BIC #177277,$BDDAT ;STRIP AWAY OTHER BITS.
1577
1578 010412 023727 001126 000500 CMP $BDDAT,#BIT6!BIT8 ;DID THEY ARE SET?

```

```

1579 010420 001401          BEQ      1$
1580
1581 010422 104000          ERROR          ;CSR BIT(S) 0 AND/OR 6 AND/OR 8
1582                                     ;DID NOT BIT SET. CSR RESULTS IN
1583                                     ;$BDDAT.
1584
1585 010424          1$:
1586 010424 005077 170554      CLR      @RCSRA
1587 010430 005037 177776      CLR      PS
1588
1589
1590                                     ;:*****
1591                                     ;:*TEST 7          *TEST THAT BIT 7 WILL SET WHEN BIT 8 IS SET
1592                                     ;:*****
1593 010434 000004      †ST7:  SCOPE
1594
1595 010436 042777 000400 170540      BIC      #BIT8,@RCSRA      ;MAKE SURE BIT 8 IS CLEAR.
1596 010444 005777 170536          TST      @RDBRA          ;THEN MAKE SURE BIT 7 IS CLEAR.
1597 010450 052777 000400 170526      BIS      #BIT8,@RCSRA      ;NOW SET CSR BIT 8 SHOULD SET BIT 7
1598                                     ;VIA THE MAINTANCE LOOP BACK CABLE.
1599 010456 105777 170522          TSTB     @RCSRA          ;DID BIT 7 SET?
1600 010462 100401          BMI      1$              ;YES-NEXT TEST.
1601
1602 010464 104000          ERROR          ;SETTING CSR BIT 8 FAILED TO SET CST BIT 7 VIA CABLE.
1603
1604 010466          1$:
1605
1606                                     ;:*****
1607                                     ;:*TEST 10         *TEST LOW BYTE OPERATION OF INPUT CSR.
1608                                     ;:*****
1609 010466 000004      †ST10: SCOPE
1610
1611 010470 005077 170510          CLR      @RCSRA          ;MAKE SURE CSR DAE, STAT OUT CLEAR.
1612 010474 112777 000401 170502      MOVB    #BIT8!BIT0,@RCSRA ;SET DAE-SHOULD NOT SET STAT OUT
1613 010502 032777 000400 170474      BIT     #BIT08,@RCSRA    ;DID STAT OUT SET?
1614 010510 001401          BEQ      1$              ;NO-CONTINUE.
1615
1616 010512 104000          ERROR          ;CO=1;C1=1;BUS ADDR. 00=0; BUT WROTE
1617                                     ;INTO HIGH BYTE OF MODULE CSR WORD.
1618
1619 010514 032777 000001 170462 1$:  BIT     #BIT00,@RCSRA    ;MAKE SURE WE DID SET BIT 0.
1620 010522 001001          BNE     2$              ;YES-NEXT TEST.
1621
1622 010524 104000          ERROR          ;FAILED TO SET BIT 00 IN CSR ON A
1623                                     ;MOVE BYTE INST. LOW BYTE OPERATION.
1624 010526          2$:
1625                                     ;:*****
1626                                     ;:*TEST 11         *TEST HIGH BYTE OPERATION OF CSR
1627                                     ;:*****
1628 010526 000004      †ST11: SCOPE
1629
1630 010530 005077 170450          CLR      @RCSRA          ;MAKE SURE DAE AND STAT OUT =0.
1631 010534 013737 001204 001274      MOV     RCSRA,$STEMPO    ;SET BUS ADDR. BIT 00 OF ADDRESS.
1632 010542 005237 001274          INC     $STEMPO
1633 010546 112777 000401 170520      MOVB    #BIT8!BIT0,@$STEMPO ;SEND WHOLE WORD TO CSR ONLY STAT
1634                                     ;OUT SHOULD SET (HIGH BYTE OPERATION)

```

```

1635 010554 032777 000001 170422 BIT #BIT00, @RCSRA ;DID BIT 00 SET?
1636 010562 001401 BEQ 1$ ;NO-CONTINUE.
1637
1638 010564 104000 ERROR ;CO=1:CI=1:AOO=1 BUT WROTE INTO
1639 ;LOW BYTE OF MODULE CSR WORD.
1640
1641 010566 032777 000400 170410 1$: BIT #BIT08, @RCSRA ;MAKE SURE STAT OUT HAD SET.
1642 010574 001001 BNE 2$ ;IF SO-NEXT TEST.
1643
1644 010576 104000 ERROR ;FAILED TO SET BIT 08 IN CSR ON A
1645 ;MOVE BYTE INSTR. HIGH BYTE OPERATION.
1646 010600 2$:
1647
1648
1649
1650
1651
1652
1653
1654
1655
1656
1657
1658

```

```

;*****
;*TEST 12 NPUT MODULE INTERRUPT TEST

```

```

;***>>> WARNING <<<***
; A MAINTANCE LOOP BACK CONNECTOR IS NEEDED FOR THIS
;TEST(S) OR THE TESTS WILL FAIL.
;***>>> END OF WARNING <<<***

```

```

1659 010600 000004 TST12: SCOPE
1660 010602 012737 000001 001166 MOV #1,$TIMES ;;DO 1 ITERATION
1661
1662 010610 104411 GETRC ;GET INTR. VECTOR + PRIORITY.
1663 010612 042777 000400 170364 BIC #BIT8,@RCSRA
1664 010620 005777 170362 TST @RDBRA ;RESET ALL CONDITIONS IN INPUT + OUTPUT CSR'S.
1665 010624 013700 001210 MOV RVT, R0 ;GET VECTOR ADDR. OF RECEIVER.
1666 010630 012737 000340 177776 MOV #340, PS ;LOCK OUT INTERRUPTS.
1667
1668 010636 012710 010676 MOV #1$, (0) ;SET UP INTERRUPT VECTOR.
1669 010642 016037 000002 001274 MOV 2(R0), $TEMPO ;SAVE CONTENTS OF VECTOR X2.
1670 010650 012710 000340 000002 MOV #340, 2(R0) ;SET PRIORITY ON INTERRUPT.
1671
1672 010656 052777 000500 170320 BIS #BIT6!BIT8,@RCSRA ;SET INTERRUPT ENABLE, AND CONTROL BIT.
1673 010664 005037 177776 CLR PS ;ALLOW INTERRUPTS.
1674
1675 010670 000240 NOP ;SHOULD INTERRUPT FROM HERE.
1676
1677 010672 104000 ERROR ;NO - INTERRUPT FROM INPUT MODULE.
1678
1679 010674 000406 BR 2$
1680
1681 ;MODULE SHOULD INTERRUPT TO HERE.
1682
1683 010676 022626 1$: POPSP2 ;RESET STACK PRINTER (R6)
1684 010700 042777 000500 170276 BIC #BIT6!BIT8,@RCSRA ;CLEAR INTERRUPT ENABLE.
1685 010706 005037 177776 CLR PS ;ALLOW INTERRUPTS.
1686 010712 005777 170270 2$: TST @RDBRA ;RESET ALL CSR BITS.
1687
1688
1689
1690

```

```

;*****
;*TEST 13 *THAT THE INPUT MODULE WON'T INTERRUPT IF CPU IS AT SAME PRIORITY

```

1691
1692
1693
1694
1695
1696
1697
1698
1699
1700
1701
1702
1703
1704
1705
1706
1707
1708
1709
1710
1711
1712
1713
1714
1715
1716
1717
1718
1719
1720
1721
1722
1723
1724
1725
1726
1727
1728
1729
1730
1731
1732
1733
1734
1735
1736

010716 000004
010720 012737 000001 001166
010726 005777 170254
010732 104411
010734 013700 001210
010740 012737 000340 177776
010746 012710 011012
010752 012760 000340 000002
010760 052777 000500 170216
010766 013737 001266 177776
010774 000240
010776 042777 000500 170200
011004 005037 177776
011010 000407
011012 022626
011014 042777 000500 170162
011022 005037 177776
011026 104000
011030 010001
011032 005721
011034 010110
011036 013760 001164 000002
011044 104413
011046 000137 010052

```

:
:***>>> WARNING <<<***
: A MAINTANCE LOOP BACK CONNECTOR IS NEEDED FOR THIS
: TEST(S) OR THE TESTS WILL FAIL.
:***>>> END OF WARNING <<<***
:
:*****
:ST13: SCOPE
:MOV #1,$TIMES ;;DO 1 ITERATION
:
:TST @RDBRA ;RESET ALL CSR BITS
:GETRC ;GET INTR. VECTOR + PRIORITY
:MOV RVT, RO ;GET VECTOR ADDR. OF INPUT MOD.
:MOV #340, PS ;LOCK OUT ALL INTRS.
:MOV #1$, (0) ;SET UP INTR. VECTOR FOR INTR.
:MOV #340, 2(0) ;SET PRIORITY ON INTR.
:
:BIS #BIT6!BIT8,@RCSRA ;SET INTERRUPT ENABLE.
:MOV RVTP, PS ;SET PROCESSOR PRIORITY TO THAT OF
: ;INPUT MODULE.
:NOP ;WILL INTERRUPT FROM HERE IF ANY.
:
:BIC #BIT6!BIT8,@RCSRA ;NO INTR. CLEAR INTR. ENABLE.
:CLR PS ;ALLOW INTERRUPTS
:BR 2$
:
: ;MODULE WILL INTERRUPT TO HERE IF ANY.
:
:1$: POPSP2 ;RESET STACK POINTER (R6).
:BIC #BIT6!BIT8,@RCSRA ;CLEAR INTERRUPT ENABLE.
:CLR PS ;ALLOW INTERRUPTS.
:
:ERROR ;REPORT ERROR - INPUT MODULE.
: ;INTERRUPTED WHEN CPU WAS SET AT
: ;SAME PRIORITY AS IT WAS.
:
:2$: MOV R0,R1
:TST (1)+
:MOV R1,(R0)
:MOV $TMPD, 2(R0) ;RESTORE VECTOR +2.
:
:
:EOPCAL
:
:3$: JMP IMLT
:
: .SBTTL OMLT OUTPUT MODULE CSR/DBR TEST.

```

```

: *OUTPUT MODULES CSR, DBR TEST.
: *ENTER WITH: XCSRA=ADDR. OF CSR UNDER TEST
: * XDBRA=ADDR. OF DBR UNDER TEST

```

1744
1745 011052 013737 001174 001120 OMLT: MOV XCSRA,\$GDADR ;SET CSR ADDR. FOR ERROR TYP0UT
1746


```

1747
1748
1749
1750 011060 000240
1751 011062 012737 011070 001106
1752
1753 011070 013746 000004
1754 011074 012737 011110 000004
1755 011102 005777 170066
1756 011106 000402
1757
1758 011110
1759 011110 022626
1760 011112 104000
1761
1762 011114 012637 000004
1763
1764
1765
1766
1767 011120 000004
1768
1769 011122 013746 000004
1770 011126 012737 011142 000004
1771 011134 005777 170036
1772 011140 000402
1773
1774 011142
1775
1776 011142 022626
1777 011144 104000
1778
1779 011146 012637 000004
1780
1781
1782
1783
1784 011152 000004
1785 011154 012737 000002 001166
1786 011162 005737 001100
1787 011166 001011
1788
1789 011170 042777 000001 167776
1790
1791 011176 104417
1792
1793 011200 032777 000001 167766
1794 011206 001001
1795
1796 011210 104000
1797
1798
1799 011212
1800
1801
1802

```

```

*****
;*TEST 14 *TEST CSR ADDRESSABILITY
*****
TST14: NOP
MOV #3$, $LPADR ;;SET SCOPE LOOP ADDRESS
3$: MOV @#4, -(SP) ;SAVE CONTENTS OF LOC. 4 ON STACK
MOV #1$, @#4 ;SET LOC. 4 IN CASE OF TRAP IF CSR DOESN'T RESPOND.
TST @XCSRA ;ADDRESS CSR.
BR 2$ ;NO TRAP IF HERE - NEXT TEST.
1$: ;TRAP HERE IF CSR DOES NOT RESPOND BY RETURNING SLAVE-SYNC.
POPSP2 ;RESET STACK POINTER (R6).
ERROR ;NO RESPONSE FROM CSR UNDER TEST.
2$: MOV (SP)+, @#4 ;RESTORE CONTENTS OF LOC 4 FROM STACK.
*****
;*TEST 15 *TEST DBR ADDRESSABILITY
*****
TST15: SCOPE
MOV @#4, -(SP) ;SAVE CONTENTS OF LOCATION 4 ON STACK
MOV #1$, @#4 ;SET LOC. 4 IN CASE OF TRAP IF DBR DOESN'T RESPOND.
TST @XDBRA ;ADDRESS DBR.
BR 2$ ;NO TRAP IF HERE - NEXT TEST.
1$: ;TRAP HERE IF DBR DOESN'T RESPOND BY RETURNING SLAVE-SYNC.
POPSP2 ;RESET STACK POINTER (R6).
ERROR ;NO RESPONSE FROM DBR UNDER TEST.
2$: MOV (SP)+, @#4 ;RESTOER CONTENTS OF LOCATION 4 FROM STACK.
*****
;*TEST 16 *TEST THAT XMITTER CSR BIT 0 IS SET ON INIT
*****
TST16: SCOPE
MOV #2, $TIMES ;;DO 2 ITERATIONS
TST $PASS ;ONLY DO THIS TEST ON FIRST PASS.
BNE 1$
BIC #BIT0, @XCSRA ;MAKE SURE CSR BIT 0 IS CLEAR.
RESETC ;ISSUE SYSTEM INITIALIZE, THIS
;SHOULD CAUSE BIT 0 TO SET.
BIT #BIT0, @XCSRA ;IS CSR BIT 0 SET?
BNE 1$ ;YES - NEXT TEST.
ERROR ;OUTPUT MODULES CSR BIT 0 FAILED TO
;SET ON INIT.
1$:
*****
;*TEST 17 *TEST THAT OUTPUT MOD. CSR BITS 1,6 AND 8 ARE CLEAR ON INIT.

```

K04

MAINDEC-11-DZDRH-A
DZDRH.P11 T17

MACY11 27(732) 21-SEP-76 09:52 PAGE 35
*TEST THAT OUTPUT MOD. CSR BITS 1,6 AND 8 ARE CLEAR ON INIT.

```

1803
1804 011212 000004
1805 011214 012737 000002 001166
1806 011222 005737 001100
1807 011226 001017
1808
1809 011230 012737 000340 177776
1810 011236 052777 000500 167730
1811
1812 011244 104417
1813
1814 011246 032777 000502 167720
1815 011254 001404
1816 011256 017737 167712 001126
1817
1818 011264 104000
1819
1820
1821 011266
1822 011266 005077 167702
1823 011272 005037 177776
1824
1825
1826
1827
1828 011276 000004
1829 011300 012737 000001 001166
1830
1831 011306 005737 001100
1832 011312 001006
1833 011314 104417
1834
1835 011316 017737 167654 001126
1836 011324 001401
1837
1838 011326 104000
1839
1840
1841 011330
1842
1843
1844
1845
1846 011330 000004
1847 011332 012737 000005 001166
1848
1849 011340 005737 001100
1850 011344 001022
1851 011346 104417
1852 011350 012737 000340 177776
1853 011356 052777 000500 167610
1854 011364 042777 000503 167602
1855 011372 017737 167576 001126
1856 011400 032737 000503 001126
1857 011406 001401
1858

*****
†ST17: SCOPE
MOV #2,$TIMES ;;DO 2 ITERATIONS
TST $PASS ;;ONLY DO THIS TEST FIRST PASS.
BNE 1$
MOV #340,PS
BIS #BIT6!BIT8,DXCSRA ;PRESET CSR BITS 6 AND 8.
RESETC ;SYSTEM INITIALIZE, SHOULD CLEAR
;BITS 1,6, AND 8
BIT #BIT1!BIT6!BIT8,DXCSRA ;ARE CSR BITS 1,6, AND 8 CLEAR?
BEQ 1$ ;YES - CONTINUE.
MOV DXCSRA,$BDDAT ;NO - STORE CSR FOR OPERATOR EXAMINATION.
ERROR ;OUTPUT MODULES CSR BIT 1 AND/OR BIT 6-
;AND/OR BIT 8 FAILED TO CLEAR ON INIT.
1$:
CLR DXCSRA
CLR PS
*****
†TEST 20 *TEST THAT DBR IS ZERO ON INIT
*****
†ST20: SCOPE
MOV #1,$TIMES ;;DO 1 ITERATION
TST $PASS ;ONLY DO THIS TEST FIRST PASS.
BNE 1$
RESETC ;ISSUE SYSTEM INITIALIZE.
MOV DXDBRA,$BDDAT ;READ DBR.
BEQ 1$ ;IF ZERO - NEXT TEST
ERROR ;DBR NOT ZERO AFTER INITIALIZE
;DBR ADDR. IN XDBRA.
1$:
*****
†TEST 21 *TEST THAT CSR BITS 0,1,6, AND 8 CAN BE BIT CLEARED
*****
†ST21: SCOPE
MOV #5,$TIMES ;;DO 5 ITERATIONS
TST $PASS ;ONLY DO THIS TEST FIRST PASS.
BNE 1$
RESETC ;SET BITS 0 AND 1.
MOV #340,PS
BIS #BIT6!BIT8,DXCSRA ;SET BITS 6 AND 8
BIC #BIT0!BIT1!BIT6!BIT8,DXCSRA ;NOW CLEAR THE BITS.
MOV DXCSRA,$BDDAT ;READ CSR.
BIT #BIT0!BIT1!BIT6!BIT8,$BDDAT ;SEE IF ANY ARE SET.
BEQ 1$ ;NO - CONTINUE.

```

MAINDEC-11-DZDRH-A
DZDRH.P11 T21

MACY11 27(732) 21-SEP-76 09:52 PAGE 36
*TEST THAT CSR BITS 0,1,6, AND 8 CAN BE BIT CLEARED

```

1859 011410 104000          ERROR          ;CSR BIT(S) 0 AND/OR 1 AND/OR 6 AND/OR 8
1860                                     ;COULD NOT BE BIT CLEAR. CSR RESULTS
1861                                     ;IN $BDDAT.
1862 011412 052777 000100 167524 1$:  BIS      #BIT6,$STKS ;RE-ENABLE TTY INTERRUPTS.
1863 011420 005077 167550          CLR      @XCSRA
1864 011424 005037 177776          CLR      PS
1865
1866                                     ;*****
1867                                     ;*TEST 22      *TEST THAT CSR BITS 0,6, AND 8 CAN BE BIT SET
1868                                     ;*****
1869 011430 000004          †ST22: SCOPE
1870
1871 011432 012737 000340 177776          MOV      #340,PS
1872 011440 042777 000501 167526          BIC      #BIT0!BIT6!BIT8,@XCSRA ;MAKE SURE THEY ARE CLEAR
1873 011446 052777 000501 167520          BIS      #BIT0!BIT6!BIT8,@XCSRA ;THEN SET THEM.
1874
1875 011454 017737 167514 001126          MOV      @XCSRA,$BDDAT ;READ CSR.
1876 011462 042737 177274 001126          BIC      #177274,$BDDAT ;STRIP AWAY OTHER BITS.
1877
1878 011470 023727 001126 000501          CMP      $BDDAT,#BIT0!BIT6!BIT8 ;DID THEY ARE SET?
1879 011476 001401          BEQ      1$
1880
1881 011500 104000          ERROR          ;CSR BIT(S) 0 AND/OR 6 AND/OR 8
1882                                     ;DID NOT BIT SET. CSR RESULTS IN
1883                                     ;$BDDAT
1884
1885 011502          1$:
1886 011502 005077 167466          CLR      @XCSRA
1887 011506 005037 177776          CLR      PS
1888
1889                                     ;*****
1890                                     ;*TEST 23      *TEST THAT CSR BIT 7 WILL SET WHEN BIT 8 IS SET
1891                                     ;*****
1892
1893                                     ;***>>> WARNING <<<***
1894                                     ; A MAINTANCE LOOP BACK CONNECTOR IS NEEDED FOR THIS
1895                                     ; TEST(S) OR THE TESTS WILL FAIL.
1896                                     ;***>>> END OF WARNING <<<***
1897
1898                                     ;*****
1899 011512 000004          †ST23: SCOPE
1900
1901 011514 005077 167454          CLR      @XCSRA ;CLEAR CSR BITS.
1902 011520 052777 000400 167446          BIS      #BIT8,@XCSRA ;SET CSR BIT8. SHOULD SET CSR BIT 7
1903 011526 105777 167442          TSTB    @XCSRA ;DID BIT7 SET?
1904 011532 001001          BNE      1$ ;YES - NEXT TEST.
1905
1906 011534 104000          ERROR          ;CSR BIT 7 DID NOT SET WHEN
1907                                     ;CSR BIT 8 WAS SET.
1908
1909
1910                                     ;***>>> WARNING <<<***
1911                                     ; A MAINTANCE LOOP BACK CONNECTOR IS NEEDED FOR THIS
1912                                     ; TEST(S) OR THE TESTS WILL FAIL.
1913                                     ;***>>> END OF WARNING <<<***
1914

```

```

1915
1916 011536 1$:
1917
1919 ::*****
1919 ;*TEST 24 *TEST LOW BYTE OPERATION OF OUTPUT MODS. CSR
1920 ::*****
1921 011536 000004 †ST24: SCOPE
1922
1923 011540 005077 167430 CLR @XCSRA ;MAKE SURE BIT 00 AND BIT 08 ARE CLEAR.
1924 011544 112777 000401 167422 MOVB #BIT8!BIT0,@XCSRA ;SEND ALL ONES TO CSR-ONLY LOW BYTE
1925 ;SHOULD GET THROUGH.
1926 011552 032777 000400 167414 BIT #BIT08,@XCSRA ;DID BIT 08 GET SET?(ITS IN HIGH BYTE).
1927 011560 001401 BEQ 1$ ;NO-CONTINUE.
1928
1929 011562 104000 ERROR ;C0=1;C1=1;BUS ADD=0 BUT WE WROTE INTO
1930 ;HIGH BYTE OF MODULES CSR WORD.
1931
1932 011564 032777 000001 167402 1$: BIT #BIT00, @XCSRA ;MAKE SURE WE SET BIT 00.
1933 011572 001001 BNE 2$ ;IF SO-NEXT TEST.
1934
1935 011574 104000 ERROR ;FAILED TO SET BIT 00 IN CSR ON A
1936 ;LOW BYTE MOV OPERATION.
1937
1938 011576 2$:
1939
1940 ::*****
1941 ;*TEST 25 *TEST HIGH BYTE OPERATION OF OUTPUT CSR.
1942 ::*****
1943 011576 000004 †ST25: SCOPE
1944
1945 011600 005077 167370 CLR @XCSRA ;MAKE SURE CSR BITS 00 AND 08 ARE CLEAR.
1946 011604 013737 001174 001274 MOV XCSRA,$STEMPO ;NOW FORM HIGH BYTE ADDRESS SET BUS-
1947 011612 005237 001274 INC $STEMPO ;ADDRESS BIT 00.
1948 011616 112777 000401 167450 MOVB #BIT8!BIT0,@STEMPO ;WRITE WHOLE WORD OUT MODULE SHOULD DECODE-
1949 ;ONLY WANTING TO WRITE INTO HIGH BYTE.
1950 011624 032777 000001 167342 BIT #BIT00, @XCSRA ;DID WE SET A BIT IN THE LOW WORD?
1951 011632 001401 BEQ 1$ ;NO-CONTINUE.
1952
1953 011634 104000 ERROR ;C0=1;C1=1;ADD=1 BUT WORTE INTO LOW
1954 ;BYTE OF MODULES CSR WORD.
1955
1956 011636 032777 000400 167330 1$: BIT #BIT08, @XCSRA ;MAKE SURE WE HAD SET BIT 08 IN HIGH BYTE.
1957 011644 001001 BNE 2$
1958
1959 011646 104000 ERROR ;FAILED TO SET BIT 08 IN CSR ON A
1960 ;MOV BYTE HIGH BYTE OPERATION.
1961
1962 011650 2$:
1963
1964 ::*****
1965 ;*TEST 26 *TEST THE LOW BYTE OPERATION OF THE OUTPUT MODS. DBR.
1966 ::*****
1967 011650 000004 †ST26: SCOPE
1968
1969 011652 005077 167320 CLR @XDBRA ;MAKE SURE DBR IS CLEAR.
1970 011656 112777 177777 167312 MOVB #-1,@XDBRA ;SEND ALL ONES TO DBR--BUT SENCE THIS IS

```

```

1971                                     ;A BYTE INSTR. ONLY THE LOW BYTE SHOLD BE WRITTEN.
1972 011664 032777 000400 167304      BIT   #BIT08, @XDBRA ;DID HIGH BYTE GET WRITTEN INTO?
1973 011672 001401                      BEQ   1$           ;NO-CONTINUE.
1974
1975 011674 104000                      ERROR                    ;HIGH BYTE OF DBR GOT WRITTEN INTO
1976
1977                                     ;ON A MOV TO LOW BYTE OPERATION.
1978 011676 032777 000001 167272 1$:   BIT   #BIT00, @XDBRA ;DID LOW BYTE GET WRITTEN?
1979 011704 001001                      BNE   2$           ;YES-NEXT TEST.
1980
1981 011706 104000                      ERROR                    ;LOW BYTE OF DBR FAILED TO GET WRITTEN
1982                                     ;INTO ON A LOW BYTE DATA0B INSTR.
1983 011710                               2$:
1984
1985                                     ;*****
1986                                     ;*TEST 27      *TEST THE HIGH BYTE OPERATION OF THE OUTPUT MODS. DBR.
1987                                     ;*****
1988 011710 000004      TST27: SCOPE
1989
1990 011712 005077 167260                CLR   @XDBRA          ;MAKE SURE DBR IS CLEAR.
1991 011716 013737 001176 001274        MOV   XDBRA, $STEMPO ;NOW FORM HIGH BYTE ADDRESS OF DBR.
1992 011724 005237 001274                INC   $STEMPO        ;BY SETTING BUS ADDR. BIT 00.
1993 011730 112777 177777 167336        MOVB  #-1, @STEMPO   ;WEN WHOLE WORD TO DBR ONLY HIGH BYTE
1994                                     ;OF DBR SHOULD BE WRITTEN INTO.
1995 011736 032777 000001 167232        BIT   #BIT00, @XDBRA ;DID LOW BYTE BE WRITTEN INTO?
1996
1997 011744 001401                      BEQ   1$           ;NO-CONTINUE.
1998
1999 011746 104000                      ERROR                    ;ERROR-WROTE INTO LOW BYTE OF DBR
2000                                     ;ON A MOV HIGH BYTE OPERATION.
2001                                     ;CO=1;C1=1;AO0=1.
2002
2003 011750 032777 000400 167220 1$:   BIT   #BIT08, @XDBRA ;MAKE SURE HIGH BYTE GOT WRITTEN INTO.
2004 011756 001001                      BNE   2$           ;YES-NEXT TEST.
2005
2006 011760 104000                      ERROR                    ;FAILED TO WRITE INTO HIGH BYTE
2007                                     ;OF DBR IN A MOV HIGH BYTE WRITE OPERATION.
2008
2009 011762                               2$:
2010                                     ;*****
2011                                     ;*TEST 30      *OUTPUT MODULE INTERRUPT TEST
2012                                     ;*****
2013
2014                                     ;***>>> WARNING <<<<***
2015                                     ; A MAINTANCE LOOP BACK CONNECTOR IS NEEDED FOR THIS
2016                                     ;TEST(S) OR THE TESTS WILL FAIL.
2017                                     ;***>>> END OF WARNING <<<<***
2018
2019                                     ;*****
2020 011762 000004      TST30: SCOPE
2021 011764 012737 000001 001166        MOV   #1, $TIMES     ;;DO 1 ITERATION
2022
2023 011772 104412                      GETXC                    ;GET INTR. VECTOR + PRIORITY.
2024 011774 042777 000400 167172        BIC   #BIT8, @XCSRA  ;RESET ALL CONDITIONS IN OUTPUT CSR.
2025 012002 005777 167170                TST   @XDBRA
2026 012006 013700 001200                MOV   XVT, RO        ;GET VECTOR ADDR. OF RECEIVER.

```

```

2027 012012 012737 000340 177776      MOV      #340, PS      ;LOCK OUT INTERRUPTS.
2028
2029 012020 012710 012060              MOV      #15, (0)     ;SET UP INTERRUPT VECTOR.
2030 012024 016037 000002 001164      MOV      2(R0), $TMP0 ;SAVE CONTENTS OF VECTOR X2.
2031 012032 012760 000340 000002      MOV      #340, 2(R0) ;SET PRIORITY ON INTERRUPT.
2032
2033 012040 052777 000500 167126      BIS      #BIT6!BIT8, $XCSRA ;SET INTERRUPT ENABLE, AND CONTROL BIT.
2034 012046 005037 177776              CLR      PS           ;ALLOW INTERRUPTS.
2035
2036 012052 000240              NOP                    ;SHOULD INTERRUPT FROM HERE.
2037
2038 012054 104000              ERROR                  ;NO - INTERRUPT FROM OUTPUT MODULE.
2039
2040 012056 000406              BR       2$
2041
2042              ;MODULE SHOULD INTERRUPT TO HERE.
2043
2044 012060 022626              1$: POPSP2              ;RESET STACK PRINTER (R6).
2045 012062 042777 000500 167104      BIC      #BIT6!BIT8, $XCSRA ;CLEAR INTERRUPT ENABLE.
2046 012070 005037 177776              CLR      PS           ;ALLOW INTERRUPTS.
2047
2048 012074              2$:
2049
2050              ;*****
2051              ;*TEST 31      *THAT THE OUTPUT MODULE WON'T INTERRUPT IF CPU IS AT SAME PRIORITY
2052
2053              ;
2054              ;***>>> WARNING <<<***
2055              ; A MAINTANCE LOOP BACK CONNECTOR IS NEEDED FOR THIS
2056              ; TEST(S) OR THE TESTS WILL FAIL.
2057              ;***>>> END OF WARNING <<<***
2058              ;
2059              ;*****
2060 012074 000004      $T31: SCOPE
2061 012076 012737 000001 001166      MOV      #1, $TIMES   ;;DO 1 ITERATION
2062
2063 012104 005777 167066      TST      $XDBRA       ;RESET ALL CSR BITS.
2064 012110 104412              GETXC                ;GET INTR. VECTOR + PRIORITY
2065 012112 013700 001200              MOV      XVT, R0     ;GET VECTOR ADDR. OF OUTPUT MOD.
2066 012116 012737 000340 177776      MOV      #340, PS    ;LOCK OUT ALL INTRs.
2067 012124 012710 012170              MOV      #15, (0)   ;SET UP INTR. VECTOR FOR INTR.
2068 012130 012760 000340 000002      MOV      #340, 2(0) ;SET PRIORITY ON INTR.
2069
2070 012136 052777 000500 167030      BIS      #BIT6!BIT8, $XCSRA ;SET INTERRUPT ENABLE.
2071 012144 013737 001264 177776      MOV      XVTP, PS    ;SET PROCESSOR PRIORITY TO THT OF
2072              ; INPUT MODULE.
2073 012152 000240              NOP                    ;WILL INTERRUPT FROM HERE IF ANY.
2074
2075 012154 042777 000500 167012      BIC      #BIT6!BIT8, $XCSRA ;NO INTR. CLEAR INTR. ENABLE.
2076 012162 005037 177776              CLR      PS           ;ALLOW INTERRUPTS.
2077 012166 000407              BR       2$
2078
2079              ;MODULE WILL INTERRUPT TO HERE IF ANY.
2080
2081 012170 022626              1$: POPSP2              ;RESET STACK POINTER (R6).
2082 012172 042777 000500 166774      BIC      #BIT6!BIT8, $XCSRA ;CLEAR INTERRUPT ENABLE.
  
```

MAINDEC-11-DZDRH-A
DZDRH.P11 T31

MACY11 27(732) 21-SEP-76 09:52 PAGE 40
*THAT THE OUTPUT MODULE WON'T INTERRUPT IF CPU IS AT SAME PRIORITY

```

2083 012200 005037 177776          CLR    PS          ;ALLOW INTERRUPTS.
2084
2085 012204 104000          ERROR          ;REPORT ERROR - OUTPUT MODULE.
2086
2087
2088 012206 010001          2S:  MOV    R0,R1
2089 012210 005721          TST    (R1)+
2090 012212 010110          MOV    R1,(R0)
2091 012214 013760 001164 000002    MOV    STMP0, 2(R0) ;RESTORE VECTOR +2.
2092 012222 104417          RESETC        ;CLEAR WORLD.
2093
2094 012224 104413          EOPCAL
2095 012226 000137 011052          JMP    OMLT
2096

```

```

;*XCVP AND RCVP - ROUTINES USE TO READ AND STORE
;*INPUT AND OUTPUT MODULES VECTOR + PRIORITIES.
;*CALL= JSR PC,XCVP FOR OUTPUT MODULE'S CSR.
;*
;*          REQUIRED: XCSRA
;*          XVT
;*          XVTP
;* CALL= JSR PC,RCVP FOR INPUT MODULES CSR.
;*          REQUIRED: RCSRA
;*          RVT
;*          RVTP

```

```

2109
2110 012232 017737 166736 001124 XCVP: MOV    @XCSRA,$GDDAT ;READ XMITTER CSR FOR PRIORITY
2111 012240 042737 177717 001124 BIC    #177717,$GDDAT ;PRIORITY IN BITS 4+5
2112 012246 013701 001124 MOV    $GDDAT,R1 ;PSW IN R1
2113 012252 006237 001124 ASR    $GDDAT ;STATES STATE4 PRIORITY
2114 012256 006237 001124 ASR    $GDDAT ; 0 0 4
2115 012262 006237 001124 ASR    $GDDAT ; 0 1 5
2116 012266 006237 001124 ASR    $GDDAT ; 1 0 6
2117 012272 006301 ASL    R1 ; 1 1 7
2118 012274 052701 000200 BIS    #BIT7,R1 ;RD TO KEEP COUNT.
2119 012300 017737 166670 001126 MOV    @XCSRA,$BDDAT ;READ XMITTER'S CSR FOR VECTOR.
2120 012306 042737 100777 001126 BIC    #100777,$BDDAT ;VECTOR BITS 9-14 IN CSR.
2121 012314 000337 001126 SWAB  $BDDAT ;CSR BITS 9-14 REPRESENT ADDR BITS 03-08.
2122 012320 006337 001126 ASL    $BDDAT
2123 012324 006337 001126 ASL    $BDDAT
2124 012330 017700 166640 MOV    @XCSRA,R0 ;READ CSR AGAIN TO FIND OUT
2125 012334 042700 177773 BIC    #177773,R0 ;THE STATE OF BIT 2.
2126 012340 060037 001126 ADD    R0,$BDDAT ;BIT 2 IS PART OF VECTOR ADDR.
2127 012344 013737 001174 001120 MOV    XCSRA,$GDADR;SET ADDR FOR TYPEOUT
2128 012352 020137 001264 CMP    R1,XVTP ;PRIORITY THE SAME?
2129 012356 001415 BEQ    3S ;YES -3S
2130 012360 010137 001264 2S: MOV    R1,XVTP ;NO - STORE NEW PRIORITY
2131 012364 013737 001126 001200 MOV    $BDDAT,XVT ;STORE VECTOR ADDR.
2132 012372 013737 001200 001202 MOV    XVT,XVT2
2133 012400 062737 000002 001202 ADD    #2,XVT2
2134 012406 000137 012636 JMP    XRCVPT ;GO TYPEOUT CHANGE.
2135 012412 023737 001126 001200 3S: CMP    $BDDAT,XVT ;IS THE VECTOR THE SAME?
2136 012420 001357 BNE    2S ;NO - GO TYPE IT OUT.
2137 012422 023727 001200 000100 CMP    XVT,#100
2138 012430 002753 BLT    2S

```

```

2139 012432 000002          RTI
2140
2141 012434 017737 166544 001124 RCVP: MOV   JRC5RA,$GDDAT ;READ RECEIVER CSR FOR PRIORITY
2142 012442 042737 177717 001124 BIC   #177717,$GDDAT ;PRIORITY IN BITS 4+5
2143 012450 013701 001124 MOV   $GDDAT,R1
2144 012454 006237 001124 ASK   $GDDAT ;STATES STATE4 PRIORITY
2145 012460 006237 001124 ASR   $GDDAT ; 0 0 4
2146 012464 006237 001124 ASR   $GDDAT ; 0 1 6
2147 012470 006237 001124 ASR   $GDDAT ; 1 0 6
2148 012474 006301 001124 ASL   R1 ; 1 1 7
2149 012476 052701 000200 BIS   #BIT7,R1 ;RD TO KEEP COUNT.
2150 012502 017737 166476 001126 MOV   JRC5RA,$BDDAT ;READ RECEIVER CSR FOR VECTOR.
2151 012510 042737 100777 001126 BIC   #100777,$BDDAT ;VECTOR BITS 9-14 IN CSR.
2152 012516 000337 001126 SWAB  $BDDAT ;CSR BITS 9-14 REPRESENT ADD BITS 03-08
2153 012522 006337 001126 ASL   $BDDAT
2154 012526 006337 001126 ASL   $BDDAT
2155 012532 017700 166446 MOV   JRC5RA,R0 ;READ CSR AGAIN TO FIND OUT
2156 012536 042700 177773 BIC   #177773,R0 ;THE STATE OF BIT 2.
2157 012542 060037 001126 ADD   R0,$BDDAT ;BIT 2 IS PART OF VECTOR ADDR.
2158 012546 013737 001204 001120 MOV   RCSR,$GDADR ;SET ADDR. FOR TYPEOUT.
2159
2160 012554 020137 001266 CMP   R1,RVTP ;PRIORITY THE SAME?
2161 012560 001415 BEQ   3$ ;YES -3$
2162 012562 010137 001266 2$: MOV   R1,RVTP ;NO-STORE NEW PRIORITY.
2163 012566 013737 001126 001210 MOV   $BDDAT,RVT ;STORE VECTOR ADDR.
2164 012574 013737 001210 001212 MOV   RVT,RVT2
2165 012602 062737 000002 001212 ADD   #2,RVT2
2166 012610 000137 012636 JMP   XRCVPT ;GO TYPEOUT CHANGE.
2167 012614 023737 001126 001210 3$: CMP   $BDDAT,RVT ;DID VECTOR ADDR. CHANGE?
2168 012622 001357 BNE   2$ ;YES-TYPE IT OUT.
2169 012624 023727 001210 000100 CMP   RVT,#100
2170 012632 002753 BLT   2$
2171 012634 000002 RTI
2172
2173 ;ROUTINE TO TYPEOUT A VECTOR OR PRIORITY CHANGE
2174
2175 012636 XRCVPT:
2176 012636 104401 012644 TYPE   ,65$ ;:TYPE ASCIZ STRING
2177 012642 000407 BR     64$ ;:GET OVER THE ASCIZ
2178 ;:65$: .ASCIZ <15><12>#CSR ADDR: #
2179 64$:
2180
2181 012662 013746 001120 MOV   $GDADR,-(SP) ;:SAVE $GDADR FOR TYPEOUT
2182 ;:TYPES CSR ADDRESS OF DEVICE
2183 012666 104402 TYPOC ;:GO TYPE--OCTAL ASCII(ALL DIGITS)
2184 012670 104401 012676 TYPE   ,67$ ;:TYPE ASCIZ STRING
2185 012674 000410 BR     66$ ;:GET OVER THE ASCIZ
2186 ;:67$: .ASCIZ # VECTOR ADDR.: #
2187 66$:
2188 012716 013746 001126 MOV   $BDDAT,-(SP) ;:SAVE $BDDAT FOR TYPEOUT
2189 ;:TYPES VECTOR ADDRESS OF DEVICE
2190 012722 104402 TYPOC ;:GO TYPE--OCTAL ASCII(ALL DIGITS)
2191 012724 104401 012732 TYPE   ,69$ ;:TYPE ASCIZ STRING
2192 012730 000406 BR     68$ ;:GET OVER THE ASCIZ
2193 ;:69$: .ASCIZ # PRIORITY: #
2194 68$:

```



```

2195
2196
2197
2198 012746 052737 000004 001124 BIS #BIT2,$GDDAT
2199 012754 013746 0C1124 MOV $GDDAT,-(SP)
2200
2201 012760 104402 TYPOC
2202 012762 104401 001171 TYPE,$SCRLF
2203 012766 023727 001126 000100 CMP $BDDAT,#100
2204 012774 002070 BGE 2$
2205 012776 104401 013004 TYPE 71$
2206 013002 000430 BR 70$
2207
2208 013064
2209 013064
2210 013064 104401 013072 TYPE 73$
2211 013070 000426 BR 72$
2212
2213 013146
2214 013146 000000
2215 013150 162716 000002 SUB #2,(SP)
2216 013154 000442 BR 3$
2217 013156 023737 001210 001200 2$ CMP RVT,XVT
2218 013164 001036 BNE 3$
2219
2220 013166 104401 013174 TYPE 75$
2221 013172 000432 BR 74$
2222
2223 013260
2224 013260 000701
2225
2226 013262 000002 3$ RTI
2227
2228

```

```

;*CKADR ROUTINE TO CHECK VALIDITY OF
;*AN ADDRESS.
;*CALL = JSR PC,CKADR
;*REQUIRED: ADDRESS IN R0
;*CARRY BIT CLEAR ON RETURN IF LEGAL
;*CARRY BIT SET ON RETURN IF ILLEGAL

```

```

2237
2238 013264 032700 000001 CKADR: BIT #BIT0,R0
2239 013270 001422 BEQ 3$
2240 013272 104401 013300 TYPE 65$
2241 013276 000416 BR 64$
2242
2243 013334
2244 013334 000435
2245
2246 013336 005700 3$ TST R0
2247 013340 001001 BNE 4$
2248
2249 013342 000207 RTS PC
2250

```

```

2251 013344          4$:
2252
2253 013344 005700          TST      RO          ;NUMBER LARGE ENOUGH?
2254 013346 100013          BPL      2$          ;NO-REPORT ERROR
2255 013350 032700 040000  BIT      #BIT14,RO
2256 013354 001410          BEQ      2$
2257 013356 032700 020000  BIT      #BIT13,RO
2258 013362 001405          BEQ      2$
2259 013364 020027 177670  CMP      RO,#177670 ;ADDRESS TOO LARGE?
2260 013370 003002          BGT      2$
2261 013372 000241          CLC
2262 013374 000207          RTS      PC
2263
2264
2265 013376          2$:
2266 013376 104401 013404          TYPE    ,67$          ;;TYPE ASCIZ STRING
2267 013402 000412          BR      66$          ;;GET OVER THE ASCIZ
2268          ;;67$: .ASCIZ <15><12>#ILLEGAL ADDRESS !#
2269 013430          66$:
2270
2271 013430 000261          CKADRE: SEC
2272 013432 000207          RTS      PC
2273

;*ROUTINE TO HANDLE KEYBOARD INTERRUPTS

2277
2278 013434 017737 165506 001270 KEYSRV: MOV      @STKB,CHAR ;READ CHAR.
2279 013442 042737 000200 001270          BIC      #BIT7,CHAR ;STRIP PARITY IF ANY
2280 013450 105777 165474          1$: TSTB    @STPS          ;SEE IF PRINTER BUSY
2281 013454 100375          BPL      1$
2282 013456 113777 001270 165466          MOVB    CHAR,@STPB ;ECHO
2283
2284 013464 123727 001270 000003          CMPB    CHAR,#3 ;IC TYPED?
2285 013472 001002          BNE      2$
2286 013474 000137 003060          JMP      RSTART ;YES-RESTART
2287 013500 123727 001270 000001 2$: CMPB    CHAR,#1 ;IA TYPED?
2288 013506 001002          BNE      3$
2289 013510 000137 001000          JMP      @#1000 ;YES-START
2290
2291 013514 123727 001270 000015 3$: CMPB    CHAR,#15 ;<CR> TYPED?
2292 013522 001010          BNE      5$
2293
2294 013524 104401 001171          TYPE    $CRLF
2295 013530 013737 001236 001230          MOV     TTYPAT,PATRN ;CHANGE PATTERN
2296 013536 005037 001236          CLR     TTYPAT
2297 013542 000002          4$: RTI
2298
2299 013544 123727 001270 000023 5$: CMPB    CHAR,#23 ;"IS" TYPED?
2300 013552 001463          BEQ     SWRSET ;IF YES TYPE SWR.
2301
2302 013554 123727 001270 000005          CMPB    CHAR,#5 ;"IE" TYPED?
2303 013562 001425          BEQ     LEXAM ;YES-TYPE OUT A LOCATION.
2304
2305
2306 013564 123727 001270 000060 6$: CMPB    CHAR,#'0 ;OCTAL DIGIT?

```

MAINDEC-11-DZDRH-A
DZDRH.P11 T31MACY11 27(732) 21-SEP-76 09:52 PAGE 44
*THAT THE OUTPUT MODULE WON'T INTERRUPT IF CPU IS AT SAME PRIORITY

```

2307 013572 002763          BLT      4$          ;NO-IGNORE
2308 013574 123727 001270 000067  CMPB    CHAR,#'7
2309 013602 003357          BGT     4$
2310 013604 006337 001236  ASL     TTYPAT
2311 013610 006337 001236  ASL     TTYPAT
2312 013614 006337 001236  ASL     TTYPAT
2313 013620 042737 177770 001270  BIC     #177770,CHAR
2314 013626 053737 001270 001236  BIS     CHAR,TTYPAT
2315 013634 000742          BR      4$
2316
2317
2318          ;ROUTINE TO TYPE OUT THE CONTENTS OF A LOCATION
2319          ;
2320 013636          LEXAM:
2321 013636 104401 013644  TYPE    ,65$          ;;TYPE ASCIZ STRING
2322 013642 000402          BR      64$          ;;GET OVER THE ASCIZ
2323          ;;65$: .ASCIZ #1E#
2324 013650 64$:
2325 013650 104410          RDOCT
2326 013652 012637 013720  MOV     (SP)+,1$
2327 013656 104401 013664  TYPE    ,67$          ;;TYPE ASCIZ STRING
2328 013662 000402          BR      66$          ;;GET OVER THE ASCIZ
2329          ;;67$: .ASCIZ <15><12>
2330 013670 66$:
2331 013670 013746 013720  MOV     1$,-(SP)      ;;SAVE 1$ FOR TYPEOUT
2332 013674 104402          TYPOC          ;;GO TYPE--OCTAL ASCII(ALL DIGITS)
2333 013676 104401 013704  TYPE    ,69$          ;;TYPE ASCIZ STRING
2334 013702 000402          BR      68$          ;;GET OVER THE ASCIZ
2335          ;;69$: .ASCIZ # / #
2336 013710 68$:
2337 013710 017746 000004  MOV     21$,-(SP)    ;;SAVE 21$ FOR TYPEOUT
2338 013714 104402          TYPOC          ;;GO TYPE--OCTAL ASCII(ALL DIGITS)
2339 013716 000002          RTI
2340
2341 013720 000000  1$:      .WORD      0          ;TEMP STORAGE FOR LEXAM.
2342
2343
2344          ;ROUTINE TO TYPE OUT THEN CHANGE THE SOFTWARE SWITCH REGISTER
2345          ;
2346 013722          SWRSET:
2347 013722 104401 013730  TYPE    ,65$          ;;TYPE ASCIZ STRING
2348 013726 000404          BR      64$          ;;GET OVER THE ASCIZ
2349          ;;65$: .ASCIZ <15><12>#SWR= #
2350 013740 64$:
2351 013740 104414          SWCAL
2352 013742 013746 001302  MOV     SWREQ,-(SP)  ;;SAVE SWREQ FOR TYPEOUT
2353 013746 104402          TYPOC          ;;GO TYPE--OCTAL ASCII(ALL DIGITS)
2354 013750 104401 013756  TYPE    ,67$          ;;TYPE ASCIZ STRING
2355 013754 000402          BR      66$          ;;GET OVER THE ASCIZ
2356          ;;67$: .ASCIZ #/ #
2357 013762 66$:
2358 013762 104410          RDOCT
2359 013764 012637 001302  MOV     (SP)+,SWREQ
2360 013770 000002          RTI
2361
2362

```

```

;*ROUTINE TO HANDLE TRAPS TO LOC 4, 10 AND.
;*INTERRUPTS TO WRONG VECTORS.
;*+.2, IOTT(TRAPS) WERE PUT IN LOCATIONS 4-1000

```

```

2369
2370 013772          IOTRD:
2371 013772 011637 014142          MOV      (R6), 2$      ;GET WHERE WE TRAPPED TO.
2372 013776 162737 000004 014142  SUB      #4, 2$      ;=WHERE R6 RETURN 10-4
2373 014004 104401 014012          TYPE     , 65$      ;:TYPE ASCIZ STRING
2374 014010 000412          BR       64$      ;:GET OVER THE ASCIZ
2375          ;:65$: .ASCIZ <15><12>#ILLEGAL TRAP TO: #
2376 014036          64$:
2377 014036 013746 014142          MOV      2$, -(SP)   ;:SAVE 2$ FOR TYPEOUT
2378 014042 104402          TYPOC   ;:GO TYPE--OCTAL ASCII(ALL DIGITS)
2379 014044 104401 014052          TYPE     , 67$      ;:TYPE ASCIZ STRING
2380 014050 000407          BR       66$      ;:GET OVER THE ASCIZ
2381          ;:67$: .ASCIZ # FROM LOC.: #
2382 014070          66$:
2383 014070 062706 000004          ADD      #4, R6      ;:POINT TO WHERE WE TRAPPED FROM.
2384 014074 011637 014144          MOV      (R6), 3$   ;:PICK UP LOC.
2385 014100 162737 000002 014144  SUB      #2, 3$      ;:FROM REAL ADDR.
2386 014106 013746 014144          MOV      3$, -(SP)  ;:SAVE 3$ FOR TYPEOUT
2387 014112 104402          TYPOC   ;:GO TYPE--OCTAL ASCII(ALL DIGITS)
2388
2389 014114 023727 014142 000004          CMP      2$, #4     ;:DID WE TRAP TO LOC 4?
2390 014122 001405          BEQ     1$         ;:IF SO - DON'T RETURN!
2391 014124 023727 014142 000010          CMP      2$, #10   ;:DID WE TRAP TO LOC. 10?
2392 014132 001401          BEQ     1$         ;:IF SO - DON'T RETURN!
2393 014134 000002          RTI          ;:TRY RETURNING.
2394
2395 014136 000000          1$: HALT        ;:WE STOPPED HERE BECAUSE WE TRAPPED
2396 014140 000776          BR       1$        ;:TO LOC 4 OR LOC 10. THIS IS A
2397          ;:FATAL CONDITION THAT WE CAN NOT
2398          ;:RECOVER FROM.
2399
2400 014142 000000          2$: .WORD 0      ;:USED BY IOTRP TO STORE WHERE WE TRAPPED TO.
2401 014144 000000          3$: .WORD 0      ;:USED BY IOTRP TO STORE WHERE WE TRAPPED FROM.
2402

```

```

;*
;*SWRCAL ROUTINE TO READ THE HARDWARE SWITCH REGISTER IF IT
;*EXISTS AND IF IT ITS NO-ZERO.
;*CALL = SWCAL
;*EXITS WITH SWR VALUE IN SWREQ IF HSWR IS USED.

```

```

2411
2412 014146 005777 165126          SWRCAL: TST      @BSWR
2413 014152 001403          BEQ     1$
2414 014154 017777 165120 164756  MOV      @BSWR, @SWR
2415 014162 000002          1$: RTI
2416
2417

```

```

;*
;*HALTER ROUTINE USED TO HALT ON ERROR IF NO SWR(HARDWARE)
;*IS BEING USED THEN "HOLDS ON ERROR".
;*CALL = HALTCL
;*

```

```

2425 014164 005777 165110 HALTER: TST 0BSWR
2426 014170 001402 BEQ 1S
2427
2428 014172 000000 HALT ;ERROR HALT.
2429
2430 014174 000425 BR 3S
2431
2432 014176 1S:
2433 014176 04401 014204 TYPE 65S ;:TYPE ASCIZ STRING
2434 014202 000412 BR 64S ;:GET OVER THE ASCIZ
2435 ;:65S: .ASCIZ <15><12>#HOLDING ON ERROR#
2436 64S:
2437 014230 005037 177776 CLR PS
2438 014234 052777 000100 164702 BIS #100,0$TKS
2439 014242 005777 164672 2S: TST 0BSWR
2440 014246 100775 BMI 2S
2441
2442 014250 000002 3S: RTI
2443
2444
2445
2446
2447

```

```

;*
;*RESETR- ROUTINE TO ISSUE SYSTEM INITIALIZE. AND WAIT FOR TYY
;*SETTLE DOWN FIRST.
;*CALL = RESETC
;*

```

```

2456
2457 014252 RESETR:
2458 014252 104401 014260 TYPE 65S ;:TYPE ASCIZ STRING
2459 014256 000402 BR 64S ;:GET OVER THE ASCIZ
2460 ;:65S: .ASCIZ <1><1><1>##
2461 64S:
2462 014264 000005 RESETR ;:SYSTEM INITIALIZE STATEMENT.
2463 014266 000002 RTI ;RETURN.
2464
2465

```

;*TEXT USED BY MASTER TO TRANSFER TO SLAVE.

```

2471
2472 014270 TABLE:
2473 014270 000000 TEXT: 000000
2474 014272 000001 000001 ;FLOATING ONES.

```

MAINDEC-11-DZDRH-A
DZDRH.P11 T31

MACY11 27(732) 21-SEP-76 09:52 PAGE 47
*THAT THE OUTPUT MODULE WON'T INTERRUPT IF CPU IS AT SAME PRIORITY

| | | | |
|------|--------|--------|--------|
| 2475 | 014274 | 000002 | 000002 |
| 2476 | 014276 | 000004 | 000004 |
| 2477 | 014300 | 000010 | 000010 |
| 2478 | 014302 | 000020 | 000020 |
| 2479 | 014304 | 000040 | 000040 |
| 2480 | 014306 | 000100 | 000100 |
| 2481 | 014310 | 000200 | 000200 |
| 2482 | 014312 | 000400 | 000400 |
| 2483 | 014314 | 001000 | 001000 |
| 2484 | 014316 | 002000 | 002000 |
| 2485 | 014320 | 004000 | 004000 |
| 2486 | 014322 | 010000 | 010000 |
| 2487 | 014324 | 020000 | 020000 |
| 2488 | | | |
| 2489 | 014326 | 040000 | 040000 |
| 2490 | 014330 | 100000 | 100000 |
| 2491 | 014332 | 000000 | 000000 |
| 2492 | 014334 | 177777 | 177777 |
| 2493 | 014336 | 177776 | 177776 |
| 2494 | 014340 | 177775 | 177775 |

;FLOATING ZEROS.

K05

MAINDEC-11-DZDRH-A
DZDRH.P11 T31

MACY11 27(732) 21-SEP-76 09:52 PAGE 48
*THAT THE OUTPUT MODULE WON'T INTERRUPT IF CPU IS AT SAME PRIORITY

| | | | |
|------|--------|--------|--------|
| 2495 | 014342 | 177773 | 177773 |
| 2496 | 014344 | 177767 | 177767 |
| 2497 | 014346 | 177757 | 177757 |
| 2498 | 014350 | 177737 | 177737 |
| 2499 | 014352 | 177677 | 177677 |
| 2500 | 014354 | 177577 | 177577 |
| 2501 | 014356 | 177377 | 177377 |
| 2502 | 014360 | 176777 | 176777 |
| 2503 | 014362 | 175777 | 175777 |
| 2504 | 014364 | 173777 | 173777 |
| 2505 | 014366 | 167777 | 167777 |
| 2506 | 014370 | 157777 | 157777 |
| 2507 | 014372 | 137777 | 137777 |
| 2508 | 014374 | 077777 | 077777 |
| 2509 | | | |
| 2510 | 014376 | 000000 | 000000 |
| 2511 | 014400 | 177777 | 177777 |
| 2512 | 014402 | 000000 | 000000 |
| 2513 | 014404 | 177777 | 177777 |
| 2514 | 014406 | 000000 | 000000 |
| 2515 | 014410 | 177777 | 177777 |
| 2516 | 014412 | 000000 | 000000 |
| 2517 | 014414 | 177777 | 177777 |
| 2518 | 014416 | 000000 | 000000 |
| 2519 | 014420 | 000000 | 000000 |
| 2520 | 014422 | 177777 | 177777 |
| 2521 | 014424 | 125252 | 125252 |
| 2522 | 014426 | 052525 | 052525 |
| 2523 | 014430 | 125252 | 125252 |
| 2524 | 014432 | 052525 | 052525 |
| 2525 | 014434 | 125252 | 125252 |
| 2526 | 014436 | 052525 | 052525 |
| 2527 | 014440 | 125252 | 125252 |
| 2528 | 014442 | 052525 | 052525 |
| 2529 | 014444 | 125252 | 125252 |
| 2530 | 014446 | 052525 | 052525 |
| 2531 | 014450 | 125252 | 125252 |
| 2532 | 014452 | 052525 | 052525 |
| 2533 | | | |
| 2534 | 014454 | 000377 | 000377 |
| 2535 | 014456 | 177400 | 177400 |
| 2536 | 014460 | 000377 | 000377 |
| 2537 | 014462 | 177400 | 177400 |
| 2538 | 014464 | 000377 | 000377 |
| 2539 | 014466 | 177400 | 177400 |
| 2540 | 014470 | 000377 | 000377 |
| 2541 | 014472 | 177400 | 177400 |
| 2542 | 014474 | 000377 | 000377 |
| 2543 | 014476 | 177400 | 177400 |
| 2544 | 014500 | 000377 | 000377 |
| 2545 | 014502 | 177400 | 177400 |
| 2546 | 014504 | 000377 | 000377 |
| 2547 | 014506 | 177400 | 177400 |
| 2548 | 014510 | 000377 | 000377 |
| 2549 | 014512 | 177777 | 177777 |
| 2550 | 014514 | 000377 | 000377 |

;ON/OFF

;ALTERNATES

;BYTE ALTERNATES

MAINDEC-11-DZDRH-A
DZDRH.P11 T31

MACY11 27(732) 21-SEP-76 09:52 PAGE 49
*THAT THE OUTPUT MODULE WON'T INTERRUPT IF CPU IS AT SAME PRIORITY

| | | | |
|------|--------|----------------------|----------------------------------|
| 2551 | 014516 | 000000 | 000000 |
| 2552 | 014520 | 000377 | 000377 |
| 2553 | 014522 | 177777 | 177777 |
| 2554 | 014524 | 177400 | 177400 |
| 2555 | 014526 | 000000 | 000000 |
| 2556 | 014530 | 177400 | 177400 |
| 2557 | | | |
| 2558 | 014532 | 000000 | 000000 |
| 2559 | 014534 | 177777 | 177777 |
| 2560 | 014536 | 177776 | 177776 |
| 2561 | 014540 | 000001 | 000001 |
| 2562 | 014542 | 177775 | 177775 |
| 2563 | 014544 | 000002 | 000002 |
| 2564 | 014546 | 177773 | 177773 |
| 2565 | 014550 | 000004 | 000004 |
| 2566 | 014552 | 177767 | 177767 |
| 2567 | 014554 | 000010 | 000010 |
| 2568 | 014556 | 177757 | 177757 |
| 2569 | 014560 | 000020 | 000020 |
| 2570 | 014562 | 177737 | 177737 |
| 2571 | 014564 | 000040 | 000040 |
| 2572 | 014566 | 177677 | 177677 |
| 2573 | 014570 | 000100 | 000100 |
| 2574 | 014572 | 177577 | 177577 |
| 2575 | 014574 | 000200 | 000200 |
| 2576 | 014576 | 177377 | 177377 |
| 2577 | 014600 | 000400 | 000400 |
| 2578 | 014602 | 176777 | 176777 |
| 2579 | 014604 | 001000 | 001000 |
| 2580 | 014606 | 175777 | 175777 |
| 2581 | | | |
| 2582 | 014610 | 002000 | 002000 |
| 2583 | 014612 | 173777 | 173777 |
| 2584 | 014614 | 004000 | 004000 |
| 2585 | 014616 | 167777 | 167777 |
| 2586 | 014620 | 010000 | 010000 |
| 2587 | 014622 | 157777 | 157777 |
| 2588 | 014624 | 020000 | 020000 |
| 2589 | 014626 | 137777 | 137777 |
| 2590 | 014630 | 040000 | 040000 |
| 2591 | 014632 | 077777 | 077777 |
| 2592 | 014634 | 100000 | 100000 |
| 2593 | 014636 | 077777 | 077777 |
| 2594 | 014640 | 000000 | 000000 |
| 2595 | 014642 | | |
| 2596 | 014642 | 000000 | 000000 |
| 2597 | | | |
| 2598 | 014644 | | |
| 2599 | 014644 | 000170 | |
| 2600 | 015224 | 000000 | |
| 2601 | | | |
| 2602 | | | |
| 2603 | | | : ASCII MESSAGES |
| 2604 | | | : |
| 2605 | | | |
| 2606 | 015226 | 005015 052123 051101 | MSM: .ASCIZ <15><12>/START MODE/ |

TABLEE:
TEXTE: 000000

STORE:
STABL: .BLKW 120.
STABLE: .WORD 0

| | | | | | | |
|------|--------|--------|--------|--------|------|-----------------------------------|
| 2607 | 015234 | 020124 | 047515 | 042504 | | |
| 2608 | 015242 | 000 | | | | |
| 2609 | 015243 | 015 | 044412 | 046515 | MIM: | .ASCIZ <15><12>/IMMED. SEND MODE/ |
| 2610 | 015250 | 042105 | 020056 | 051440 | | |
| 2611 | 015256 | 047105 | 020104 | 047515 | | |
| 2612 | 015264 | 042504 | 000 | | | |
| 2613 | 015267 | 015 | 041012 | 051125 | MBM: | .ASCIZ <15><12>/BURST SEND MODE/ |
| 2614 | 015274 | 052123 | 020040 | 042523 | | |
| 2615 | 015302 | 042116 | 020040 | 047515 | | |
| 2616 | 015310 | 042504 | 000 | | | |
| 2617 | | | | | | |
| 2618 | | 015314 | | | | .EVEN |
| 2619 | | | | | | |
| 2620 | | | | | | |

;*SYSMAC ROUTINES BEGIN HERE

2626
2627
2628
2629
2630
2631
2632
2633
2634
2635
2636
2637
2638
2639
2640
2641
2642
2643
2644
2645
2646
2647
2648
2649
2650
2651
2652
2653
2654
2655
2656
2657
2658
2659
2660
2661
2662

.SBTTL END OF PASS ROUTINE

```

*****
; *INCREMENT THE PASS NUMBER ($PASS)
; *INDICATE END-OF-PROGRAM AFTER 1 PASSES THRU THE PROGRAM
; *TYPE "END PASS #XXXXX" (WHERE XXXXX IS A DECIMAL NUMBER)
; *IF THERES A MONITOR GO TO IT
; *IF THERE ISN'T JUMP TO RET1

```

\$EOP:

```

SWCAL      :READ THE SWITCH REGISTER.
BIT        #BIT10, $SWR
BEQ        RETCON
INC        $PASS
BR         RET

```

RET1:

```

TYPE       65$      ;; TYPE ASCIZ STRING
BR         64$      ;; GET OVER THE ASCIZ

```

;;65\$: .ASCIZ # ERROR COUNT #

```

64$:      MOV      $ERTTL, -(SP)  ;; SAVE $ERTTL FOR TYPEOUT
          TYPDS   ;; GO TYPE--DECIMAL ASCII WITH SIGN
          TYPE    67$      ;; TYPE ASCIZ STRING
          BR      66$      ;; GET OVER THE ASCIZ

```

;;67\$: .ASCIZ # #

66\$:

RET: RTI

RETCON:

```

CLR        $STNM    ;; ZERO THE TEST NUMBER
CLR        $TIMES   ;; ZERO THE NUMBER OF ITERATIONS
INC        $PASS    ;; INCREMENT THE PASS NUMBER

```

```

2663 015420 042737 100000 001100      BIC      #100000,$PASS      ;;DON'T ALLOW A NEG. NUMBER
2664 015426 005327                      DEC      (PC)+              ;;LOOP?
2665 015430 000001      $EOPCT:  .WORD      1
2666 015432 003022                      BGT      $DOAGN          ;;YES
2667 015434 012737                      MOV      (PC)+,@(PC)+    ;;RESTORE COUNTER
2668 015436 000001      $ENDCT:  .WORD      1
2669 015440 015430      $EOPCT
2670 015442 104401 015507      TYPE      $ENDMG          ;;TYPE "END PASS #"
2671 015446 013746 001100      MOV      $PASS,-(SP)    ;;SAVE $PASS FOR TYPEOUT
2672 015452 104405                      TYPDS    ;;GO TYPE--DECIMAL ASCII WITH SIGN
2673 015454 104401 015504      TYPE      $ENULL        ;;TYPE A NULL CHARACTER
2674 015460 013700 000042      $GET42:  MOV      @#42,R0  ;;GET MONITOR ADDRESS
2675 015464 001405                      BEQ      $DOAGN        ;;BRANCH IF NO MONITOR
2676 015466 000005                      RESET    ;;CLEAR THE WORLD
2677 015470 004710      $ENDAD:  JSR      PC,(R0)  ;;GO TO MONITOR
2678 015472 000240                      NOP      ;;SAVE ROOM
2679 015474 000240                      NOP      ;;FOR
2680 015476 000240                      NOP      ;;ACT11
2681 015500      $DOAGN:
2682 015500 000137                      JMP      @(PC)+          ;;RETURN
2683 015502 015334      $RTNAD:  .WORD      RET1
2684 015504 377 377 000      $ENULL:  .BYTE      -1,-1,0  ;;NULL CHARACTER STRING
2685 015507 015 042412 042116      $ENDMG:  .ASCIZ    <15><12>/END PASS #/
2686 015514 050040 051501 020123
2687 015522 000043
2688
2689      .SBTTL  SCOPE HANDLER ROUTINE
2690
2691      ;;*****
2692      ;;THIS ROUTINE CONTROLS THE LOOPING OF SUBTESTS. IT WILL INCREMENT
2693      ;;AND LOAD THE TEST NUMBER($TSTNM) INTO THE DISPLAY REG.(DISPLAY<7:0>)
2694      ;;AND LOAD THE ERROR FLAG ($ERFLG) INTO DISPLAY<15:08>
2695      ;;THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
2696      ;;SW14=1      LOOP ON TEST
2697      ;;SW11=1      INHIBIT ITERATIONS
2698      ;;CALL
2699      ;;*      SCOPE      ;;SCOPE=IOT
2700
2701 015524      $SCOPE:
2702 015524 104414      SWCAL
2703
2704 015526 032777 040000 163404 1$:  BIT      #BIT14,@SWR      ;;LOOP ON PRESENT TEST?
2705 015534 001055                      BNE      $OVER          ;;YES IF SW14=1
2706      ;;*****START OF CODE FOR THE XOR TESTER*****
2707 015536 000416      $XTSTR:  BR      6$
2708      ;;IF RUNNING ON THE "XOR" TESTER CHANGE
2709      ;;THIS INSTRUCTION TO A "NOP" (NOP=240)
2710 015540 013746 000004      MOV      @#ERRVEC,-(SP)  ;;SAVE THE CONTENTS OF THE ERROR VECTOR
2711 015544 012737 015564 000004      MOV      #5,@#ERRVEC    ;;SET FOR TIMEOUT
2712 015552 005737 177060      TST      @#177060       ;;TIME OUT ON XOR?
2713 015556 012637 000004      MOV      (SP)+,@#ERRVEC  ;;RESTORE THE ERROR VECTOR
2714 015562 000436                      BR      $$VLAD          ;;GO TO THE NEXT TEST
2715 015564 022626 000004      5$:  CMP      (SP)+,(SP)+  ;;CLEAR THE STACK AFTER A TIME OUT
2716 015566 012637 000004      MOV      (SP)+,@#ERRVEC  ;;RESTORE THE ERROR VECTOR
2717 015572 000436                      BR      $OVER          ;;LOOP ON THE PRESENT TEST
2718 015574 105737 001103      6$:  ;;*****END OF CODE FOR THE XOR TESTER*****
2719      2$:  TSTB    $ERFLG      ;;HAS AN ERROR OCCURRED?

```

```

2719 015600 001404          BEQ      3$          ;; BR IF NO
2720 015602 105037 001103 4$:  CLRB    SERFLG      ;; ZERO THE ERROR FLAG
2721 015606 005037 001166          CLR     STIMES      ;; CLEAR THE NUMBER OF ITERATIONS TO MAKE
2722 015612 032777 004000 163320 3$:  BIT     #BIT11,2SWR  ;; INHIBIT ITERATIONS?
2723 015620 001011          BNE     1$          ;; BR IF YES
2724 015622 005737 001100          TST     $PASS      ;; IF FIRST PASS OF PROGRAM
2725 015626 001406          BEQ     1$          ;; INHIBIT ITERATIONS
2726 015630 005237 001104          INC     $ICNT      ;; INCREMENT ITERATION COUNT
2727 015634 023737 001166 001104  CMP     STIMES,$ICNT  ;; CHECK THE NUMBER OF ITERATIONS MADE
2728 015642 002012          BGE     $OVER      ;; BR IF MORE ITERATION REQUIRED
2729 015644 012737 000001 001104 1$:  MOV     #1,$ICNT    ;; REINITIALIZE THE ITERATION COUNTER
2730 015652 013737 015704 001166  MOV     $MXCNT,$TIMES  ;; SET NUMBER OF ITERATIONS TO DO
2731 015660 105237 001102  $SVLAD: INCB    $STNM     ;; COUNT TEST NUMBERS
2732 015664 011637 001106          MOV     (SP),$LPADR  ;; SAVE SCOPE LOOP ADDRESS
2733 015670 013777 001102 163244 $OVER: MOV     $STNM,2DISPLAY  ;; DISPLAY TEST NUMBER
2734 015676 013716 001106          MOV     $LPADR,(SP)  ;; FUDGE RETURN ADDRESS
2735 015702 000002          RTI                    ;; FIXES PS
2736 015704 003720          $MXCNT: 2000.          ;; MAX. NUMBER OF ITERATIONS
2737
2738
2739          .SBTTL  ERROR HANDLER ROUTINE
2740          ;; *****
2741          ;; THIS ROUTINE WILL INCREMENT THE ERROR FLAG AND ERROR COUNT.
2742          ;; IT WILL TYPE THE PC OF THE ERROR CALL IF SWR13=0
2743          ;; CALL = ERROR
2744
2745 015706 104414          $ERROR: SWCAL          ;; READ THE SWITCH REGISTER.
2746 015710 105237 001103          INCB    SERFLG      ;; SGET THE ERROR FLAG.
2747 015714 001774          BEQ     $ERROR      ;; INCREMENT ERROR COUNT.
2748 015716 005237 001112          INC     $ERTTL     ;; GET PC+2 OF ERROR CALL.
2749 015722 011637 001116          MOV     (SP),$ERRPC  ;; MAKE PC OF ERROR CALL.
2750 015726 162737 000002 001116  SUB     #2,$ERRPC
2751
2752 015734 032777 020000 163176  BIT     #BIT13,2SWR  ;; INHIBIT TYPEOUT OF THE ERROR?
2753 015742 001053          BNE     BSR15       ;; YES-THEN SKIP TYPEOUT.
2754
2755 015744 005237 001304          INC     ERTYCN      ;; INCREMENT THE #OF ERRORS TYPED OUT.
2756 015750 023727 001304 000013  CMP     ERTYCN,#11.  ;; HAVE WE TYPED OUT 10 ERRORS?
2757 015756 001030          BNE     1$
2758
2759 015760 104401 015766          TYPE    65$          ;; TYPE ASCIZ STRING
2760 015764 000421          BR     64$          ;; GET OVER THE ASCIZ
2761          ;; 65$: .ASCIZ <15><12>#HALTED ON TEN ERRORS TYPED OUT#
2762          64$:
2763
2764 016030          HALT
2765 016032 005037 001304          CLR     ERTYCN
2766 016036 000422          BR     BSR14
2767
2768
2769 016040          1$:
2770 016040 104401 016046          TYPE    67$          ;; TYPE ASCIZ STRING
2771 016044 000407          BR     66$          ;; GET OVER THE ASCIZ
2772          ;; 67$: .ASCIZ <15><12>#ERROR PC<15><12>
2773          66$:
2774 016064 013746 001116          MOV     $ERRPC,-(SP) ;; SAVE $ERRPC FOR TYPEOUT

```

```

2775 016070 104402          TYPOC          ;;GO TYPE--OCTAL ASCII(ALL DIGITS)
2776
2777 016072 104414          BSR15:  SWCAL          ;READ THE SWITCH REGISTER.
2778 016074 005777 163040  TST      2SWR          ;HALT ON ERROR?
2779 016100 100001          BPL      BSR14        ;NO-CONTINUE.
2780
2781 016102 104415          HALTCL
2782
2783 016104          BSR14:
2784
2785
2786 016104 000002          RTI
2787
2788
2789
2790
2791          ;;*****
2792          .SBTTL  TTY INPUT ROUTINE
2793
2794          ; NOTE: THIS ROUTINE IS NOT A SYSMAC ROUTINE. IT IS
2795          ; A CLOSE COPY OF THE ORIGINAL ".SREAD" EXCEPT FOR CONTROL
2796          ; CHARACTER DETECTION WHICH SENDS PROGRAM TO "KEYSRV"
2797          ; WHEN A CONTROL CHARACTER IS DETECTED.
2798
2799          ;*INPUT A SINGLE CHARACTER FOR THE TTY
2800          ;*CALL:
2801          ;*
2802          ;RDCHAR          ;INPUT A CHAR. FROM THE TTY.
2803          ;*RETURN HERE  ;CHAR. ON STACK.
2804 016106 011646 000004 000002  SRDCHR: MOV      (SP), -(SP)          ;KPUSH DOWN THE PS.
2805 016110 016666 163022          1$:  MOV      4(SP), 2(SP)          ;SAVE THE PC
2806 016116 105777 163022          1$:  TSTB   2$TKS          ;WAIT FOR A CHAR TO BE TYPED.
2807 016122 100375          BPL      1$
2808 016124 117766 163016 000004  MOVB   2$TKB, 4(SP)          ;READ THE TTY.
2809 016132 042766 177600 000004  BIC   2$177600, 4(SP)      ;GET RID OF PARITY ETC.
2810          RTI          ;GO BACK TO CALLER.
2811
2812          ;;*****
2813          ;*INPUT A STRING FROM THE TTY
2814          ;*CALL:
2815          ;*
2816          ;RDLIN          ;READ A STRING FROM THE TTY.
2817          ;RETURN HERE  ;ADDRESS OF FIRST CHAR ON STACK.
2818
2819 016142 010346          SRDLIN: MOV      R3, -(SP)          ;SAVE R3.
2820 016144 012703 016272 016302  1$:  MOV      2$TTYIN, R3          ;PUT ADDR. OF BUFFER IN R3.
2821 016150 022703 016302  2$:  CMP      2$TTYIN+8., R3          ;BUFFER FULL?
2822          BLOS   4$          ;IF YES ASK OPER WHATS GOING ON?
2823 016156 104406          RDCHR
2824 016160 112613          MOVB   (SP)+, (R3)          ;GOTO READ A CHAR. ROUTINE.
2825 016162 122713 000177          CMPB   2$177, (R3)          ;STORE THE CHAR.
2826 016166 001003          BNE   3$          ;WAS CHAR A RUBOUT??
2827 016170 104401 001170  4$:  TYPE   $QUES          ;YES TYPE A "?"
2828 016174 000763          BR     1$          ;RESTART INPUT.
2829 016176 111337 016270  3$:  MOVB   (R3), 8$          ;ECHO THE CHAR.
2830

```

```

2831 016202 104401 016270 5$: TYPE 8$
2832 016206 122713 000015 CMPB 15,(R3) ;CHECK FOR CARRAGE RETURN TYPED.
2833 016212 001412 BEQ 7$ ;IF NOT GETR NEX T CHAR.
2834 016214 122327 000040 CMPB (R3)+,#40
2835 016220 002353 BGE 2$
2836 016222 012603 MOV (SP)+,R3
2837 016224 011646 MOV (SP)-,(SP)
2838 016226 016666 000004 000002 MOV 4(SP),2(SP)
2839 016234 000137 013434 JMP KEYSRV
2840
2841 016240 105013 7$: CLRB (R3) ;INSERT ZERO TERMINATOR.
2842 016242 104401 001172 TYPE $LF ;TYPE A LINE FEED.
2843 016246 012603 MOV (SP)+,R3 ;RESTORE R3.
2844 016250 011646 MOV (SP)-,(SP) ;ADJUST THE STACK AND
2845 016252 016666 000004 000002 MOV 4(SP),2(SP) ;PUT THE FIRST ADDRESS OF THE
2846 016260 012766 016272 000004 MOV $TTYIN,4(SP) ;CHAR. ON STACK.
2847 016266 000002 RTI
2848 016270 000 000 8$: .BYTE 0,0 ;STORE FOR CHAR. ECHO.
2849 016272 000010 $TTYIN: .BLKB 8. ;RESERVE 8. BYTES FOR LINE ASCII STORAGE.
2850
2851 .SBTTL READ AN OCTAL NUMBER FROM THE TTY
2852
2853 ;*****
2854 ;*THIS ROUTINE WILL READ AN OCTAL (ASCII) NUMBER FROM THE TTY AND
2855 ;*CHANGE IT TO BINARY.
2856 ;*CALL:
2857 ;* RDOCT ;: READ AN OCTAL NUMBER
2858 ;* RETURN HERE ;: LOW ORDER BITS ARE ON TOP OF THE STACK
2859 ;* ;: HIGH ORDER BITS ARE IN $HIOCT
2860
2861 016302 011646 000004 000002 $RDOCT: MOV (SP)-,(SP) ;: PROVIDE SPACE FOR THE
2862 016304 016666 MOV 4(SP),2(SP) ;: INPUT NUMBER
2863 016312 010046 MOV R0,-(SP) ;: PUSH R0 ON STACK
2864 016314 010146 MOV R1,-(SP) ;: PUSH R1 ON STACK
2865 016316 010246 MOV R2,-(SP) ;: PUSH R2 ON STACK
2866 016320 104407 1$: RDLIN ;: READ AN ASCII LINE
2867 016322 012600 MOV (SP)+,R0 ;: GET ADDRESS OF 1ST CHARACTER
2868 016324 005001 CLR R1 ;: CLEAR DATA WORD
2869 016326 005002 CLR R2
2870 016330 112046 2$: MOVB (R0)+,-(SP) ;: PICKUP THIS CHARACTER
2871 016332 001412 BEQ 3$ ;: IF ZERO GET OUT
2872 016334 006301 ASL R1 ;: *2
2873 016336 006102 ROL R2 ;: *4
2874 016340 006301 ASL R1 ;: *8
2875 016342 006102 ROL R2
2876 016344 006301 ASL R1
2877 016346 006102 ROL R2
2878 016350 042716 177770 BIC #1C7,(SP) ;: STRIP THE ASCII JUNK
2879 016354 062601 ADD (SP)+,R1 ;: ADD IN THIS DIGIT
2880 016356 000764 BR 2$ ;: LOOP
2881 016360 005726 3$: TST (SP)+ ;: CLEAN TERMINATOR FROM STACK
2882 016362 010166 000012 MOV R1,12(SP) ;: SAVE THE RESULT
2883 016366 010237 016402 MOV R2,$HIOCT
2884 016372 012602 MOV (SP)+,R2 ;: POP STACK INTO R2
2885 016374 012601 MOV (SP)+,R1 ;: POP STACK INTO R1
2886 016376 012600 MOV (SP)+,R0 ;: POP STACK INTO R0

```

```

2887 016400 000002          RTI          ;;RETURN
2888 016402 000000          $HI OCT: .WORD 0      ;;HIGH ORDER BITS GO HERE
2889                               .SBTTL TYPE ROUTINE
2890
2891          ;*****
2892          ;ROUTINE TO TYPE ASCIZ MESSAGE. MESSAGE MUST TERMINATE WITH A 0 BYTE.
2893          ;THE ROUTINE WILL INSERT A NUMBER OF NULL CHARACTERS AFTER A LINE FEED.
2894          ;NOTE1:          $NULL CONTAINS THE CHARACTER TO BE USED AS THE FILLER CHARACTER.
2895          ;NOTE2:          $FILLS CONTAINS THE NUMBER OF FILLER CHARACTERS REQUIRED.
2896          ;NOTE3:          $FILLC CONTAINS THE CHARACTER TO FILL AFTER.
2897          ;
2898          ;CALL:
2899          ;1) USING A TRAP INSTRUCTION
2900          ;          TYPE      ,MESADR      ;;MESADR IS FIRST ADDRESS OF AN ASCIZ STRING
2901          ;OR
2902          ;          TYPE
2903          ;          MESADR
2904          ;
2905
2906 016404 105737 001157      $TYPE:  TSTB      $TPFLG      ;; IS THERE A TERMINAL?
2907 016410 100002          BPL          1$          ;; BR IF YES
2908 016412 000000          HALT          ;; HALT HERE IF NO TERMINAL
2909 016414 000407          BR          3$          ;; LEAVE
2910 016416 010046          1$:  MOV      RO, -(SP)      ;; SAVE RO
2911 016420 017600 000002      MOV      @2(SP), RO      ;; GET ADDRESS OF ASCIZ STRING
2912 016424 112046          2$:  MOVB    (RO)+, -(SP)    ;; PUSH CHARACTER TO BE TYPED ONTO STACK
2913 016426 001005          BNE      4$          ;; BR IF IT ISN'T THE TERMINATOR
2914 016430 005726          TST      (SP)+          ;; IF TERMINATOR POP IT OFF THE STACK
2915 016432 012600          60$: MOV      (SP)+, RO      ;; RESTORE RO
2916 016434 062716 000002      3$:  ADD      #2, (SP)      ;; ADJUST RETURN PC
2917 016440 000002          RTI          ;; RETURN
2918 016442 122716 000011      4$:  CMPB    #HT, (SP)      ;; BRANCH IF <HT>
2919 016446 001430          BEQ      8$          ;; BRANCH IF NOT <CRLF>
2920 016450 122716 000200      CMPB    #CRLF, (SP)
2921 016454 001006          BNE      5$          ;; POP <CR><LF> EQUIV
2922 016456 005726          TST      (SP)+          ;; TYPE A CR AND LF
2923 016460 104401          TYPE
2924 016462 001171          $CRLF
2925 016464 105037 016620      CLRB    $CHARCNT      ;; CLEAR CHARACTER COUNT
2926 016470 000755          BR      2$          ;; GET NEXT CHARACTER
2927 016472 004737 016554      5$:  JSR      PC, $TYPEPC    ;; GO TYPE THIS CHARACTER
2928 016476 123726 001156      6$:  CMPB    $FILLC, (SP)+    ;; IS IT TIME FOR FILLER CHARS.?
2929 016502 001350          BNE      2$          ;; IF NO GO GET NEXT CHAR.
2930 016504 013746 001154      MOV      $NULL, -(SP)    ;; GET # OF FILLER CHARS. NEEDED
2931                               ;; AND THE NULL CHAR.
2932 016510 105366 000001      7$:  DECB    1(SP)          ;; DOES A NULL NEED TO BE TYPED?
2933 016514 002770          BLT      6$          ;; BR IF NO--GO POP THE NULL OFF OF STACK
2934 016516 004737 016554      JSR      PC, $TYPEPC    ;; GO TYPE A NULL
2935 016522 105337 016620      DECB    $CHARCNT      ;; DO NOT COUNT AS A COUNT
2936 016526 000770          BR      7$          ;; LOOP
2937
2938          ;HORIZONTAL TAB PROCESSOR
2939
2940 016530 112716 000040      8$:  MOVB    #' , (SP)      ;; REPLACE TAB WITH SPACE
2941 016534 004737 016554      9$:  JSR      PC, $TYPEPC    ;; TYPE A SPACE
2942 016540 132737 000007 016620  BITB    #7, $CHARCNT    ;; BRANCH IF NOT AT

```

```

2943 016546 001372          BNE      9$          ;;TAB STOP
2944 016550 005726          TST      (SP)+      ;;POP SPACE OFF STACK
2945 016552 000724          BR       2$          ;;GET NEXT CHARACTER
2946 016554 105777 162370    $TYPEC: TSTB      2$TPS  ;;WAIT UNTIL PRINTER IS READY
2947 016560 100375          BPL      $TYPEC
2948 016562 116677 000002 162362    MOVVB   2(SP),2$TPB  ;;LOAD CHAR TO BE TYPED INTO DATA REG.
2949 016570 122766 000015 000002    CMPB   #CR,2(SP)    ;;IS CHARACTER A CARRIAGE RETURN?
2950 016576 001003          BNE      1$          ;;BRANCH IF NO
2951 016600 105037 016620    CLRB   $CHARCNT    ;;YES--CLEAR CHARACTER COUNT
2952 016604 000406          BR       $TYPEX     ;;EXIT
2953 016606 122766 000012 000002 1$:  CMPB   #LF,2(SP)    ;;IS CHARACTER A LINE FEED?
2954 016614 001402          BEQ     $TYPEX     ;;BRANCH IF YES
2955 016616 105227          INCB   (PC)+       ;;COUNT THE CHARACTER
2956 016620 000000    $CHARCNT: .WORD 0  ;;CHARACTER COUNT STORAGE
2957 016622 000207    $TYPEX: RTS      PC
2958
2959          .SBTTL  BINARY TO OCTAL (ASCII) AND TYPE
2960
2961          ;*****
2962          ;*THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 6-DIGIT
2963          ;*OCTAL (ASCII) NUMBER AND TYPE IT.
2964          ;*$TYPOS---ENTER HERE TO SETUP SUPPRESS ZEROS AND NUMBER OF DIGITS TO TYPE
2965          ;*CALL:
2966          ;*      MOV      NUM,-(SP)          ;;NUMBER TO BE TYPED
2967          ;*      TYPOS          ;;CALL FOR TYPEOUT
2968          ;*      .BYTE  N          ;;N=1 TO 6 FOR NUMBER OF DIGITS TO TYPE
2969          ;*      .BYTE  M          ;;M=1 OR 0
2970          ;*                                  ;;1=TYPE LEADING ZEROS
2971          ;*                                  ;;0=SUPPRESS LEADING ZEROS
2972          ;*
2973          ;*$STYPON---ENTER HERE TO TYPE OUT WITH THE SAME PARAMETERS AS THE LAST
2974          ;*$TYPOS OR $TYPOC
2975          ;*CALL:
2976          ;*      MOV      NUM,-(SP)          ;;NUMBER TO BE TYPED
2977          ;*      TYPON          ;;CALL FOR TYPEOUT
2978          ;*
2979          ;*$TYPOC---ENTER HERE FOR TYPEOUT OF A 16 BIT NUMBER
2980          ;*CALL:
2981          ;*      MOV      NUM,-(SP)          ;;NUMBER TO BE TYPED
2982          ;*      TYPOC          ;;CALL FOR TYPEOUT
2983
2984 016624 017646 000000          $TYPOS: MOV      2(SP),-(SP)  ;;PICKUP THE MODE
2985 016630 116637 000001 017047    MOVVB  1(SP),SOFILL  ;;LOAD ZERO FILL SWITCH
2986 016636 112637 017051          MOVVB  (SP)+,$SOMODE+1  ;;NUMBER OF DIGITS TO TYPE
2987 016642 062716 000002          ADD    #2,(SP)      ;;ADJUST RETURN ADDRESS
2988 016646 000406          BR     $TYPON
2989 016650 112737 000001 017047    $TYPOC: MOVVB  #1,SOFILL  ;;SET THE ZERO FILL SWITCH
2990 016656 112737 000006 017051    MOVVB  #6,$SOMODE+1  ;;SET FOR SIX(6) DIGITS
2991 016664 112737 000005 017046    $TYPON: MOVVB  #5,$SOCNT  ;;SET THE ITERATION COUNT
2992 016672 010346          MOV    R3,-(SP)    ;;SAVE R3
2993 016674 010446          MOV    R4,-(SP)    ;;SAVE R4
2994 016676 010546          MOV    R5,-(SP)    ;;SAVE R5
2995 016700 113704 017051          MOVVB  $SOMODE+1,R4  ;;GET THE NUMBER OF DIGITS TO TYPE
2996 016704 005404          NEG    R4
2997 016706 062704 000006          ADD    #6,R4
2998 016712 110437 017050          MOVVB  R4,$SOMODE  ;;SUBTRACT IT FOR MAX. ALLOWED
                ;;SAVE IT FOR USE

```

```

2999 016716 113704 017047      MOVB  $OFILL,R4      ;; GET THE ZERO FILL SWITCH
3000 016722 016605 000012      MOV   12(SP),R5     ;; PICKUP THE INPUT NUMBER
3001 016726 005003              CLR   R3            ;; CLEAR THE OUTPUT WORD
3002 016730 006105              1$:  ROL   R5            ;; ROTATE MSB INTO "C"
3003 016732 000404              BR    3$           ;; GO DO MSB
3004 016734 006105              2$:  ROL   R5            ;; FORM THIS DIGIT
3005 016736 006105              ROL   R5
3006 016740 006105              ROL   R5
3007 016742 010503              MOV   R5,R3
3008 016744 006103              3$:  ROL   R3            ;; GET LSB OF THIS DIGIT
3009 016746 105337 017050      DECB  $OMODE        ;; TYPE THIS DIGIT?
3010 016752 100016              BPL   7$           ;; BR IF NO
3011 016754 042703 177770      BIC   #177770,R3   ;; GET RID OF JUNK
3012 016760 001002              BNE   4$           ;; TEST FOR 0
3013 016762 005704              TST   R4           ;; SUPPRESS THIS 0?
3014 016764 001403              BEQ   5$           ;; BR IF YES
3015 016766 005204              4$:  INC   R4            ;; DON'T SUPPRESS ANYMORE 0'S
3016 016770 052703 000060      BIS   #'0,R3       ;; MAKE THIS DIGIT ASCII
3017 016774 052703 000040      5$:  BIS   #' ,R3       ;; MAKE ASCII IF NOT ALREADY
3018 017000 110337 017044      MOVB  R3,8$        ;; SAVE FOR TYPING
3019 017004 104401 017044      TYPE  8$          ;; GO TYPE THIS DIGIT
3020 017010 105337 017046      7$:  DECB  $OCNT        ;; COUNT BY 1
3021 017014 003347              BGT   2$           ;; BR IF MORE TO DO
3022 017016 002402              BLT   6$           ;; BR IF DONE
3023 017020 005204              INC   R4            ;; INSURE LAST DIGIT ISN'T A BLANK
3024 017022 000744              BR    2$           ;; GO DO THE LAST DIGIT
3025 017024 012605              6$:  MOV   (SP)+,R5    ;; RESTORE R5
3026 017026 012604              MOV   (SP)+,R4    ;; RESTORE R4
3027 017030 012603              MOV   (SP)+,R3    ;; RESTORE R3
3028 017032 016666 000002 000004  MOV   2(SP),4(SP)  ;; SET THE STACK FOR RETURNING
3029 017040 012616              MOV   (SP)+,(SP)
3030 017042 000002              RTI                    ;; RETURN
3031 017044 000              8$:  .BYTE 0          ;; STORAGE FOR ASCII DIGIT
3032 017045 000              .BYTE 0          ;; TERMINATOR FOR TYPE ROUTINE
3033 017046 000      $OCNT: .BYTE 0      ;; OCTAL DIGIT COUNTER
3034 017047 000      $OFILL: .BYTE 0   ;; ZERO FILL SWITCH
3035 017050 000000      $OMODE: .WORD 0    ;; NUMBER OF DIGITS TO TYPE
3036
3037      .SBTTL CONVERT BINARY TO DECIMAL AND TYPE ROUTINE
3038
3039      ;*****
3040      ;THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 5-DIGIT
3041      ;SIGNED DECIMAL (ASCII) NUMBER AND TYPE IT. DEPENDING ON WHETHER THE
3042      ;NUMBER IS POSITIVE OR NEGATIVE A SPACE OR A MINUS SIGN WILL BE TYPED
3043      ;BEFORE THE FIRST DIGIT OF THE NUMBER. LEADING ZEROS WILL ALWAYS BE
3044      ;REPLACED WITH SPACES.
3045      ;CALL:
3046      ;*      MOV   NUM,-(SP)      ;; PUT THE BINARY NUMBER ON THE STACK
3047      ;*      TYPDS                    ;; GO TO THE ROUTINE
3048
3049      $TYPDS:
3050      MOV   R0,-(SP)      ;; PUSH R0 ON STACK
3051      MOV   R1,-(SP)      ;; PUSH R1 ON STACK
3052      MOV   R2,-(SP)      ;; PUSH R2 ON STACK
3053      MOV   R3,-(SP)      ;; PUSH R3 ON STACK
3054      MOV   R5,-(SP)      ;; PUSH R5 ON STACK
3055      MOV   #20200,-(SP)   ;; SET BLANK SWITCH AND SIGN

```



```

3055 017070 016605 000020      MOV      20(SP),R5      ;; GET THE INPUT NUMBER
3056 017074 100004      BPL      1$           ;; BR IF INPUT IS POS.
3057 017076 005405      NEG      R5           ;; MAKE THE BINARY NUMBER POS.
3058 017100 112766 000055 000001  MOVVB   #'-,1(SP)     ;; MAKE THE ASCII NUMBER NEG.
3059 017106 005000      CLR      R0           ;; ZERO THE CONSTANTS INDEX
3060 017110 012703 017266 1$:      MOV      #$DBLK,R3    ;; SETUP THE OUTPUT POINTER
3061 017114 112723 000040      MOVVB   #' ,(R3)+    ;; SET THE FIRST CHARACTER TO A BLANK
3062 017120 005002      CLR      R2           ;; CLEAR THE BCD NUMBER
3063 017122 016001 017256 2$:      MOV      $DTBL(R0),R1 ;; GET THE CONSTANT
3064 017126 160105 3$:      SUB      R1,R5        ;; FORM THIS BCD DIGIT
3065 017130 002402      BLT     4$           ;; BR IF DONE
3066 017132 005202      INC     R2           ;; INCREASE THE BCD DIGIT BY 1
3067 017134 000774      BR      3$
3068 017136 060105 4$:      ADD     R1,R5        ;; ADD BACK THE CONSTANT
3069 017140 005702      TST     R2           ;; CHECK IF BCD DIGIT=0
3070 017142 001002      BNE     5$           ;; FALL THROUGH IF 0
3071 017144 105716      TSTB   (SP)          ;; STILL DOING LEADING 0'S?
3072 017146 100407      BMI     7$           ;; BR IF YES
3073 017150 106316 5$:      ASLB   (SP)          ;; MSD?
3074 017152 103003      BCC     6$           ;; BR IF NO
3075 017154 116663 000001 177777  MOVVB   1(SP),-1(R3)  ;; YES--SET THE SIGN
3076 017162 052702 000060 6$:      BIS     #'0,R2       ;; MAKE THE BCD DIGIT ASCII
3077 017166 052702 000040 7$:      BIS     #' ,R2       ;; MAKE IT A SPACE IF NOT ALREADY A DIGIT
3078 017172 110223      MOVVB   R2,(R3)+    ;; PUT THIS CHARACTER IN THE OUTPUT BUFFER
3079 017174 005720      TST    (R0)+        ;; JUST INCREMENTING
3080 017176 020027 000010      CMP     R0,#10      ;; CHECK THE TABLE INDEX
3081 017202 002746      BLT    2$           ;; GO DO THE NEXT DIGIT
3082 017204 003002      BGT     8$           ;; GO TO EXIT
3083 017206 010502      MOV     R5,R2       ;; GET THE LSD
3084 017210 000764      BR      6$           ;; GO CHANGE TO ASCII
3085 017212 105726 8$:      TSTB   (SP)+        ;; WAS THE LSD THE FIRST NON-ZERO?
3086 017214 100003      BPL     9$           ;; BR IF NO
3087 017216 116663 177777 177776  MOVVB   -1(SP),-2(R3) ;; YES--SET THE SIGN FOR TYPING
3088 017224 105013 9$:      CLRB   (R3)         ;; SET THE TERMINATOR
3089 017226 012605      MOV     (SP)+,R5    ;; POP STACK INTO R5
3090 017230 012603      MOV     (SP)+,R3    ;; POP STACK INTO R3
3091 017232 012602      MOV     (SP)+,R2    ;; POP STACK INTO R2
3092 017234 012601      MOV     (SP)+,R1    ;; POP STACK INTO R1
3093 017236 012600      MOV     (SP)+,R0    ;; POP STACK INTO R0
3094 017240 104401 017266      TYPE   $DBLK        ;; NOW TYPE THE NUMBER
3095 017244 016666 000002 000004  MOV     2(SP),4(SP)  ;; ADJUST THE STACK
3096 017252 012616      MOV     (SP)+,(SP)
3097 017254 000002      RTI
3098 017256 023420      SDTBL: 10000.
3099 017260 001750      1000.
3100 017262 000144      100.
3101 017264 000012      10.
3102 017266 000004      $DBLK: .BLKW 4
3103
3104      .SBTTL TRAP DECODER
3105
3106      ;*****
3107      ;*THIS ROUTINE WILL PICKUP THE LOWER BYTE OF THE "TRAP" INSTRUCTION
3108      ;*AND USE IT TO INDEX THROUGH THE TRAP TABLE FOR THE STARTING ADDRESS
3109      ;*OF THE DESIRED ROUTINE. THEN USING THE ADDRESS OBTAINED IT WILL
3110      ;*GO TO THAT ROUTINE.

```

```

3111
3112 017276 010046          $TRAP:  MOV    RO,-(SP)          ;;SAVE RO
3113 017300 016600 000002    MOV    2(SP),RO          ;;GET TRAP ADDRESS
3114 017304 005740          TST    -(RO)            ;;BACKUP BY 2
3115 017306 111000          MOV    (RO),RO          ;;GET RIGHT BYTE OF TRAP
3116 017310 006300          ASL    RO                ;;POSITION FOR INDEXING
3117 017312 016000 017332    MOV    $TRPAD(RO),RO    ;;INDEX TO TABLE
3118 017316 000200          RTS     RO                ;;GO TO ROUTINE
3119
3120
3121
3122      ;;THIS IS USE TO HANDLE THE "GETPF.I" MACRO
3123 017320 011646          $TRAP2: MOV   (SP),-(SP)      ;;MOVE THE PC DOWN
3124 017322 016666 000004 000002  MOV   4(SP),2(SP)        ;;MOVE THE PSW DOWN
3125 017330 000002          RTI                      ;;RESTORE THE PSW
3126
3127      .SBTTL  TRAP TABLE
3128
3129      ;*THIS TABLE CONTAINS THE STARTING ADDRESSES OF THE ROUTINES CALLED
3130      ;*BY THE "TRAP" INSTRUCTION.
3131
3132      ;      ROUTINE
3133      ;      -----
3134 017332 017320          $TRPAD: .WORD  $TRAP2          TRAP+1(104401)  TTY TYPEOUT ROUTINE
3135 017334 016404          $TYPE      ;;CALL=TYPE          TRAP+2(104402)  TYPE OCTAL NUMBER (WITH LEADING ZEROS)
3136 017336 016650          $TYPOC     ;;CALL=TYPOC         TRAP+3(104403)  TYPE OCTAL NUMBER (NO LEADING ZEROS)
3137 017340 016624          $TYPOS     ;;CALL=TYPOS         TRAP+4(104404)  TYPE OCTAL NUMBER (AS PER LAST CALL)
3138 017342 016664          $TYPON     ;;CALL=TYPON         TRAP+5(104405)  TYPE DECIMAL NUMBER (WITH SIGN)
3139 017344 017052          $TYPDS     ;;CALL=TYPDS
3140
3141
3142 017346 016106          $RDCHR     ;;CALL=RDCHR          TRAP+6(104406)  TTY TYPEIN CHARACTER ROUTINE
3143 017350 016142          $RDLIN     ;;CALL=RDLIN          TRAP+7(104407)  TTY TYPEIN STRING ROUTINE
3144 017352 016302          $RDOCT     ;;CALL=RDOCT          TRAP+10(104410) READ AN OCTAL NUMBER FROM TTY
3145
3146 017354 012434          RCVP       ;;CALL=GETRC          TRAP+11(104411)
3147 017356 012232          XCVP       ;;CALL=GETXC          TRAP+12(104412)
3148 017360 015314          $EOP       ;;CALL=EOPCAL         TRAP+13(104413)
3149 017362 014146          $SWCAL     ;;CALL=SWCAL          TRAP+14(104414)
3150 017364 014164          HALTER     ;;CALL=HALTCL         TRAP+15(104415)
3151 017366 013772          IOTRD     ;;CALL=IOTT           TRAP+16(104416)
3152 017370 014252          RESETR     ;;CALL=RESETC        TRAP+17(104417)
3153      .SBTTL  POWER DOWN AND UP ROUTINES
3154
3155      ;*****
3156      ;POWER DOWN ROUTINE
3157 017372 012737 017532 000024  $PWRDN: MOV    $SILLUP,2#$PWRVEC ;;SET FOR FAST UP
3158 017400 012737 000340 000026  MOV    #340,2#$PWRVEC+2 ;;PRIO:7
3159 017406 010046          MOV    RO,-(SP)          ;;PUSH RO ON STACK
3160 017410 010146          MOV    R1,-(SP)          ;;PUSH R1 ON STACK
3161 017412 010246          MOV    R2,-(SP)          ;;PUSH R2 ON STACK
3162 017414 010346          MOV    R3,-(SP)          ;;PUSH R3 ON STACK
3163 017416 010446          MOV    R4,-(SP)          ;;PUSH R4 ON STACK
3164 017420 010546          MOV    R5,-(SP)          ;;PUSH R5 ON STACK
3165 017422 017746 161512  MOV    2$SWR,-(SP)        ;;PUSH 2$SWR ON STACK
3166 017426 010637 017536  MOV    SP,$SAVR6         ;;SAVE SP

```

```

3167 017432 012737 017444 000024      MOV      #SPWRUP, @PWRVEC ;; SET UP VECTOR
3168 017440 000000                      HALT
3169 017442 000776                      BR       -2                ;; HANG UP
3170
3171                                     ::*****
3172                                     ::POWER UP ROUTINE
3173 017444 012737 017532 000024 $PWRUP: MOV      #SILLUP, @PWRVEC ;; SET FOR FAST DOWN
3174 017452 013706 017536          MOV      $SAVR6, SP      ;; GET SP
3175 017456 005037 017536          CLR      $SAVR6        ;; WAIT LOOP FOR THE TTY
3176 017462 005237 017536          1$: INC     $SAVR6      ;; WAIT FOR THE INC
3177 017466 001375                      BNE     1$             ;; OF WORD
3178 017470 012677 161444          MOV     (SP)+, @SWR    ;; POP STACK INTO @SWR
3179 017474 012605                      MOV     (SP)+, R5      ;; POP STACK INTO R5
3180 017476 012604                      MOV     (SP)+, R4      ;; POP STACK INTO R4
3181 017500 012603                      MOV     (SP)+, R3      ;; POP STACK INTO R3
3182 017502 012602                      MOV     (SP)+, R2      ;; POP STACK INTO R2
3183 017504 012601                      MOV     (SP)+, R1      ;; POP STACK INTO R1
3184 017506 012600                      MOV     (SP)+, R0      ;; POP STACK INTO R0
3185 017510 012737 017372 000024      MOV      #SPWRDN, @PWRVEC ;; SET UP THE POWER DOWN VECTOR
3186 017516 012737 000340 000026      MOV      #340, @PWRVEC+2 ;; PRIO:7
3187 017524 104401                      TYPE:   $POWER        ;; REPORT THE POWER FAILURE
3188 017526 017540                      SPWRMG: .WORD        ;; POWER FAIL MESSAGE POINTER
3189 017530 000002                      RTI
3190 017532 000000                      $SILLUP: HALT        ;; THE POWER UP SEQUENCE WAS STARTED
3191 017534 000776                      BR       -2            ;; BEFORE THE POWER DOWN WAS COMPLETE
3192 017536 000000                      $SAVR6: 0             ;; PUT THE SP HERE
3193 017540 005015 047520 042527 $POWER: .ASCIZ <15><12>"POWER"
3194 017546 000122
3195
3196                      .EVEN
                      .END
000001

```


| | | | | | | | | | | | | | | |
|--------|----------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|
| RDBRA | 001206 | 211# | 460* | 821 | 868 | 877 | 895 | 901 | 1130 | 1150 | 1192 | 1290 | 1498 | 1596 |
| | | 1664 | 1686 | 1701 | | | | | | | | | | |
| RDCHR | = 104406 | 354 | 2823 | 3142# | | | | | | | | | | |
| RDLIN | = 104407 | 520 | 566 | 590 | 814 | 2866 | 3143# | | | | | | | |
| RDOCT | = 104410 | 378 | 389 | 426 | 454 | 467 | 582 | 2325 | 2358 | 3144# | | | | |
| REDMOD | 005106 | 838 | 855# | | | | | | | | | | | |
| REPPAT | 005300 | 840 | 919# | | | | | | | | | | | |
| RESETC | = 104417 | 986 | 1516 | 1533 | 1550 | 1791 | 1812 | 1833 | 1851 | 2092 | 3152# | | | |
| RESETR | 014252 | 2457# | 3152 | | | | | | | | | | | |
| RESVEC | = 000010 | 138# | | | | | | | | | | | | |
| RET | 015402 | 2643 | 2656# | | | | | | | | | | | |
| RETCON | 015404 | 2641 | 2658# | | | | | | | | | | | |
| RET1 | 015334 | 2644# | 2683 | | | | | | | | | | | |
| RSTART | 003060 | 33 | 483# | 2286 | | | | | | | | | | |
| RST2 | 003264 | 501 | 511# | 558 | | | | | | | | | | |
| RVT | 001210 | 213# | 336* | 340* | 886* | 1235* | 1665 | 1703 | 2163* | 2164 | 2167 | 2169 | 2217 | |
| RVTP | 001266 | 242# | 1709 | 2160 | 2162* | | | | | | | | | |
| RVT2 | 001212 | 214# | 336 | 337* | 341* | 887* | 1236* | 2164* | 2165* | | | | | |
| RXMIT | 007470 | 786 | 1357 | 1359# | | | | | | | | | | |
| RO | =%000000 | 59# | 355* | 356 | 364 | 379* | 382 | 390* | 391 | 398 | 406 | 416 | 417* | 418 |
| | | 427* | 440 | 441* | 442 | 455* | 458 | 459* | 460 | 468* | 471 | 472* | 473 | 522* |
| | | 523 | 524 | 528 | 532 | 536 | 540 | 544 | 546 | 551 | 553 | 567* | 568 | 570 |
| | | 573 | 591* | 592 | 593 | 595 | 815* | 816 | 817 | 819 | 985* | 1665* | 1669 | 1670* |
| | | 1703* | 1726 | 1728* | 1729* | 2026* | 2030 | 2031* | 2065* | 2088 | 2090* | 2091* | 2124* | 2125* |
| | | 2126 | 2155* | 2156* | 2157 | 2238 | 2246 | 2253 | 2255 | 2257 | 2259 | 2674* | 2677 | 2863 |
| | | 2867* | 2870 | 2886* | 2910 | 2911* | 2912 | 2915* | 3049 | 3059* | 3063 | 3079 | 3080 | 3093* |
| | | 3112 | 3113* | 3114 | 3115* | 3116* | 3117* | 3118* | 3159 | 3184* | | | | |
| R1 | =%000001 | 60# | 313* | 382* | 435 | 436* | 437 | 1726* | 1728 | 2088* | 2089 | 2090 | 2112* | 2117* |
| | | 2118* | 2128 | 2130 | 2143* | 2148* | 2149* | 2160 | 2162 | 2864 | 2868* | 2872* | 2874* | 2876* |
| | | 2879* | 2882 | 2885* | 3050 | 3063* | 3064 | 3068 | 3092* | 3160 | 3183* | | | |
| R2 | =%000002 | 61# | 2865 | 2869* | 2873* | 2875* | 2877* | 2883 | 2884* | 3051 | 3062* | 3066* | 3069 | 3076* |
| | | 3077* | 3078 | 3083* | 3091* | 3161 | 3182* | | | | | | | |
| R3 | =%000003 | 62# | 2818 | 2819* | 2820 | 2824* | 2825 | 2829 | 2832 | 2834 | 2836* | 2841* | 2843* | 2992 |
| | | 3001* | 3007* | 3008* | 3011* | 3016* | 3017* | 3018 | 3027* | 3052 | 3060* | 3061* | 3075* | 3078* |
| | | 3087* | 3088* | 3090* | 3162 | 3181* | | | | | | | | |
| R4 | =%000004 | 63# | 2993 | 2995* | 2996* | 2997* | 2998 | 2999* | 3013 | 3015* | 3023* | 3026* | 3163 | 3180* |
| R5 | =%000005 | 64# | 2994 | 3000* | 3002* | 3004* | 3005* | 3006* | 3007 | 3025* | 3053 | 3055* | 3057* | 3064* |
| | | 3068* | 3083 | 3089* | 3164 | 3179* | | | | | | | | |
| R6 | =%000006 | 65# | 273* | 274* | 275 | 323* | 2371 | 2383* | 2384 | | | | | |
| R7 | =%000007 | 66# | | | | | | | | | | | | |
| SAVPC | 001276 | 247# | | | | | | | | | | | | |
| SBSM | 006664 | 1209# | 1218 | | | | | | | | | | | |
| SISM | 006352 | 1138# | 1201 | | | | | | | | | | | |
| SLERR | 006450 | 1020 | 1156 | 1159# | | | | | | | | | | |
| SMSST | 001252 | 234# | 1094* | 1106 | | | | | | | | | | |
| SMST | 006312 | 1044 | 1117# | 1221 | | | | | | | | | | |
| SNDPAT | 004322 | 620 | 719# | | | | | | | | | | | |
| SP | =%000006 | 67# | 277* | 291* | 299* | 303 | 355 | 379 | 390 | 427 | 455 | 468 | 483* | 522 |
| | | 567 | 583 | 591 | 815 | 953* | 959* | 1001* | 1051* | 1068* | 1079* | 1080* | 1093 | 1094 |
| | | 1095* | 1096* | 1104 | 1105 | 1106* | 1107* | 1171* | 1177* | 1273* | 1279* | 1368* | 1480* | 1489 |
| | | 1496* | 1506 | 1753* | 1762 | 1769* | 1779 | 2181* | 2188* | 2199* | 2215* | 2326 | 2331* | 2337* |
| | | 2352* | 2359 | 2377* | 2386* | 2649* | 2671* | 2709* | 2712 | 2714 | 2715 | 2732 | 2734* | 2749 |
| | | 2774* | 2803* | 2804* | 2807* | 2808* | 2818* | 2824 | 2836 | 2837* | 2838* | 2843 | 2844* | 2845* |
| | | 2846* | 2861* | 2862* | 2863* | 2864* | 2865* | 2867 | 2870* | 2878* | 2879 | 2881 | 2882* | 2884 |
| | | 2885 | 2886 | 2910* | 2911 | 2912* | 2914 | 2915 | 2916* | 2918 | 2920 | 2922 | 2928 | 2930* |
| | | 2932* | 2940* | 2944 | 2948 | 2949 | 2953 | 2984* | 2985 | 2986 | 2987* | 2992* | 2993* | 2994* |

| | | | | | | | | | | | | | | |
|-----------------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|--|
| SSUP = 177777 | 269# | | | | | | | | | | | | | |
| SSVLAD 015660 | 2713 | 2731# | | | | | | | | | | | | |
| SSWR = 064000 | 2# | 13 | 197 | 198 | 287 | 288 | 289 | 1478 | 1495 | 1512 | 1530 | 1546 | 1570 | |
| | 1594 | 1610 | 1629 | 1660 | 1699 | 1751 | 1768 | 1785 | 1805 | 1829 | 1847 | 1870 | 1900 | |
| | 1922 | 1944 | 1968 | 1989 | 2021 | 2061 | 2635 | 2661 | 2676 | 2682 | 2684 | 2695 | 2696 | |
| | 2697 | 2698 | 2704 | 2716 | 2718 | 2719 | 2720 | 2721 | 2722 | 2733 | 2736 | 3189 | | |
| SSWRMK= 000000 | 2698 | | | | | | | | | | | | | |
| STEMPO 001274 | 246# | 1631* | 1632* | 1633* | 1669* | 1946* | 1947* | 1948* | 1991* | 1992* | 1993* | | | |
| STIMES 001166 | 197# | 287* | 1512* | 1530* | 1546* | 1660* | 1699* | 1785* | 1805* | 1829* | 1847* | 2021* | 2061* | |
| | 2661* | 2721* | 2727 | 2730* | 2736 | | | | | | | | | |
| STKB 001146 | 186# | 437* | 2278 | 2807 | | | | | | | | | | |
| STKS 001144 | 185# | 343* | 377* | 435* | 449* | 519* | 521* | 987* | 1562* | 1862* | 2438* | 2805 | | |
| STMPO 001164 | 196# | 1729 | 2030* | 2091 | | | | | | | | | | |
| STN = 000032 | 13# | 1474 | 1478# | 1491 | 1495# | 1508 | 1512# | 1526 | 1530# | 1542 | 1546# | 1566 | 1570# | |
| | 1590 | 1594# | 1606 | 1610# | 1625 | 1629# | 1649 | 1660# | 1688 | 1699# | 1747 | 1751# | 1764 | |
| | 1768# | 1781 | 1785# | 1801 | 1805# | 1825 | 1829# | 1843 | 1847# | 1866 | 1870# | 1889 | 1900# | |
| | 1918 | 1922# | 1940 | 1944# | 1964 | 1968# | 1985 | 1989# | 2010 | 2021# | 2050 | 2061# | | |
| STPB 001152 | 188# | 442* | 2282* | 2948* | 2959 | | | | | | | | | |
| STPFLG 001157 | 192# | 2906 | 2959 | | | | | | | | | | | |
| STPS 001150 | 187# | 440* | 2280 | 2946 | 2959 | | | | | | | | | |
| STRAP 017276 | 283 | 3112# | | | | | | | | | | | | |
| STRAP2 017320 | 3123# | 3134 | | | | | | | | | | | | |
| STRP = 000020 | 3127# | 3136# | 3137# | 3138# | 3139# | 3140# | 3142 | 3143# | 3144# | 3145# | 3146 | 3147# | 3148# | |
| | 3149# | 3150# | 3151# | 3152# | 3153# | | | | | | | | | |
| STRPAD 017332 | 3117 | 3134# | | | | | | | | | | | | |
| STSTNM 001102 | 165# | 2660* | 2694 | 2731* | 2733 | 2737 | | | | | | | | |
| STTYIN 016272 | 2819 | 2820 | 2846 | 2849# | | | | | | | | | | |
| STYPBN= ***** U | 3140 | | | | | | | | | | | | | |
| STYPDS 017052 | 3048# | 3139 | | | | | | | | | | | | |
| STYPE 016404 | 2906# | 3127 | 3135 | | | | | | | | | | | |
| STYPEC 016554 | 2927 | 2934 | 2941 | 2946# | 2947 | | | | | | | | | |
| STYPEX 016622 | 2952 | 2954 | 2957# | | | | | | | | | | | |
| STYPOC 016650 | 2989# | 3136 | | | | | | | | | | | | |
| STYPON 016664 | 2988 | 2991# | 3138 | | | | | | | | | | | |
| STYPOS 016624 | 2984# | 3137 | | | | | | | | | | | | |
| STSTR 015536 | 2707# | | | | | | | | | | | | | |
| SSGET4= 000000 | 2676# | | | | | | | | | | | | | |
| SOFILL 017047 | 2985* | 2989* | 2999 | 3034# | | | | | | | | | | |
| S4OCAT= ***** U | 2704 | | | | | | | | | | | | | |
| . | 17# | 23# | 26# | 29# | 32# | 35# | 162# | 201 | 276 | 288 | 353# | 361# | 376# | |
| | 387# | 396# | 466# | 506# | 581# | 805# | 812# | 952# | 958# | 1000# | 1067# | 1170# | 1176# | |
| | 1272# | 1278# | 1367# | 2179# | 2223# | 2243# | 2324# | 2330# | 2357# | 2382# | 2436# | 2599# | 2618# | |
| | 2684 | 2688 | 2736 | 2737 | 2762# | 2773# | 2849# | 2959 | 3102# | 3169 | 3191 | | | |

| | | |
|--------|----|------|
| .EQUAT | 1# | 39 |
| .HEADE | 1# | 3 |
| .KT11 | 1# | |
| .SETTR | 1# | |
| .SETUP | 1# | 269 |
| .SWRHI | 1# | |
| .TRMTR | 1# | |
| .SACT1 | 1# | |
| .SAPT8 | 1# | |
| .SAPTH | 1# | |
| .SAPTY | 1# | |
| .SASTA | 1# | |
| .SCATC | 1# | |
| .SCMTA | 1# | 156 |
| .SDB2D | 1# | |
| .SDB20 | 1# | |
| .SDIV | 1# | |
| .SEOP | 1# | 2629 |
| .SERRO | 1# | |
| .SERRT | 1# | |
| .SMULT | 1# | |
| .SPOWE | 1# | 3153 |
| .SRAND | 1# | |
| .SRDE | 1# | |
| .SRDOC | 1# | 2851 |
| .SREAD | 1# | |
| .SR2AZ | 1# | |
| .SSAVE | 1# | |
| .SSB2D | 1# | |
| .SSB20 | 1# | |
| .SSCOP | 1# | 2689 |
| .SSIZE | 1# | |
| .SSUPR | 1# | |
| .STRAP | 1# | 3104 |
| .STYPB | 1# | |
| .STYPD | 1# | 3036 |
| .STYPE | 1# | 2889 |
| .STYPO | 1# | 2959 |
| .S4OCA | 1# | |
| .1170 | 1# | |

| | | | | | | | | | | | | | | | |
|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|
| ADD | 323 | 417 | 436 | 441 | 459 | 472 | 650 | 790 | 1022 | 1153 | 1184 | 1252 | 1253 | 1291 | 1292 |
| | 1354 | 1437 | 1461 | 2126 | 2133 | 2157 | 2165 | 2383 | 2379 | 2916 | 2987 | 2997 | 3068 | | |
| ASL | 2117 | 2122 | 2123 | 2148 | 2153 | 2154 | 2310 | 2311 | 2312 | 2872 | 2874 | 2876 | 3116 | | |
| ASLB | 3073 | | | | | | | | | | | | | | |
| ASR | 2113 | 2114 | 2115 | 2116 | 2144 | 2145 | 2146 | 2147 | | | | | | | |
| BCC | 3074 | | | | | | | | | | | | | | |
| BOS | 381 | 429 | 457 | 470 | | | | | | | | | | | |
| BEQ | 392 | 399 | 501 | 560 | 639 | 652 | 675 | 678 | 689 | 744 | 856 | 859 | 862 | 964 | 993 |
| | 1018 | 1043 | 1059 | 1145 | 1183 | 1350 | 1520 | 1535 | 1556 | 1579 | 1614 | 1636 | 1815 | 1836 | 1857 |
| | 1879 | 1927 | 1951 | 1973 | 1997 | 2129 | 2161 | 2239 | 2256 | 2258 | 2300 | 2303 | 2390 | 2392 | 2413 |
| | 2426 | 2641 | 2675 | 2719 | 2725 | 2747 | 2833 | 2871 | 2919 | 2954 | 3014 | | | | |
| BGE | 2204 | 2728 | 2835 | | | | | | | | | | | | |
| BGT | 547 | 571 | 596 | 820 | 2260 | 2309 | 2666 | 3021 | 3082 | | | | | | |
| BHIS | 407 | | | | | | | | | | | | | | |
| BIC | 343 | 519 | 766 | 778 | 900 | 1131 | 1193 | 1231 | 1239 | 1244 | 1310 | 1379 | 1426 | 1433 | 1439 |
| | 1459 | 1518 | 1553 | 1572 | 1576 | 1595 | 1663 | 1684 | 1713 | 1720 | 1789 | 1854 | 1872 | 1876 | 2024 |
| | 2045 | 2075 | 2082 | 2111 | 2120 | 2125 | 2142 | 2151 | 2156 | 2279 | 2313 | 2663 | 2808 | 2878 | 3011 |
| BIS | 521 | 720 | 753 | 774 | 888 | 903 | 987 | 1124 | 1187 | 1226 | 1237 | 1302 | 1323 | 1371 | 1418 |
| | 1438 | 1552 | 1562 | 1573 | 1597 | 1672 | 1708 | 1810 | 1853 | 1862 | 1873 | 1902 | 2033 | 2070 | 2118 |
| | 2149 | 2198 | 2314 | 2438 | 3016 | 3017 | 3076 | 3077 | | | | | | | |
| BIT | 391 | 399 | 743 | 894 | 942 | 963 | 972 | 995 | 1160 | 1182 | 1200 | 1217 | 1262 | 1284 | 1337 |
| | 1349 | 1361 | 1401 | 1534 | 1555 | 1613 | 1619 | 1635 | 1641 | 1793 | 1814 | 1856 | 1926 | 1932 | 1950 |
| | 1956 | 1972 | 1978 | 1995 | 2003 | 2238 | 2255 | 2257 | 2640 | 2704 | 2722 | 2752 | | | |
| BITB | 2942 | | | | | | | | | | | | | | |
| BLE | 554 | | | | | | | | | | | | | | |
| BLOS | 2821 | | | | | | | | | | | | | | |
| BLT | 545 | 552 | 569 | 594 | 818 | 2138 | 2170 | 2307 | 2933 | 3022 | 3065 | 3081 | | | |
| BMI | 1127 | 1229 | 1313 | 1347 | 1377 | 1600 | 2440 | 3072 | | | | | | | |
| BNE | 276 | 296 | 357 | 365 | 525 | 529 | 533 | 537 | 541 | 575 | 602 | 623 | 642 | 646 | 681 |
| | 684 | 692 | 722 | 726 | 730 | 788 | 800 | 827 | 920 | 924 | 928 | 934 | 938 | 943 | 973 |
| | 977 | 996 | 1024 | 1028 | 1152 | 1161 | 1198 | 1201 | 1214 | 1218 | 1243 | 1250 | 1256 | 1263 | 1285 |
| | 1331 | 1335 | 1338 | 1362 | 1398 | 1402 | 1406 | 1410 | 1443 | 1458 | 1515 | 1532 | 1549 | 1620 | 1642 |
| | 1787 | 1794 | 1807 | 1832 | 1850 | 1904 | 1933 | 1957 | 1979 | 2004 | 2136 | 2168 | 2218 | 2247 | 2285 |
| | 2288 | 2292 | 2705 | 2723 | 2753 | 2757 | 2826 | 2913 | 2921 | 2929 | 2943 | 2950 | 3012 | 3070 | 3177 |
| BPL | 777 | 784 | 876 | 1121 | 1148 | 1190 | 1224 | 1306 | 1423 | 2254 | 2281 | 2779 | 2806 | 2907 | 2947 |
| | 3010 | 3055 | 3086 | | | | | | | | | | | | |
| BR | 298 | 321 | 345 | 351 | 359 | 368 | 374 | 385 | 394 | 397 | 401 | 404 | 409 | 412 | 423 |
| | 432 | 445 | 451 | 464 | 492 | 504 | 513 | 558 | 562 | 579 | 587 | 606 | 619 | 656 | 686 |
| | 701 | 704 | 707 | 759 | 803 | 810 | 838 | 864 | 891 | 946 | 950 | 956 | 979 | 981 | 998 |
| | 1021 | 1048 | 1065 | 1164 | 1168 | 1174 | 1266 | 1270 | 1276 | 1286 | 1355 | 1365 | 1483 | 1499 | 1679 |
| | 1715 | 1756 | 1772 | 2040 | 2077 | 2177 | 2185 | 2192 | 2206 | 2211 | 2216 | 2221 | 2224 | 2241 | 2244 |
| | 2267 | 2315 | 2322 | 2328 | 2334 | 2348 | 2355 | 2374 | 2380 | 2396 | 2430 | 2434 | 2459 | 2643 | 2646 |
| | 2652 | 2707 | 2713 | 2716 | 2760 | 2766 | 2771 | 2828 | 2880 | 2909 | 2926 | 2936 | 2945 | 2952 | 2988 |
| | 3003 | 3024 | 3067 | 3084 | 3169 | 3191 | | | | | | | | | |
| CLC | 694 | 2261 | | | | | | | | | | | | | |
| CLR | 274 | 287 | 332 | 333 | 338 | 339 | 340 | 341 | 377 | 449 | 474 | 484 | 485 | 486 | 490 |
| | 516 | 517 | 599 | 719 | 758 | 769 | 889 | 935 | 1031 | 1046 | 1062 | 1408 | 1563 | 1564 | 1586 |
| | 1587 | 1611 | 1630 | 1673 | 1685 | 1714 | 1721 | 1822 | 1823 | 1863 | 1864 | 1896 | 1887 | 1901 | 1923 |
| | 1945 | 1969 | 1990 | 2034 | 2046 | 2076 | 2083 | 2296 | 2437 | 2660 | 2661 | 2721 | 2765 | 2868 | 2869 |
| | 3001 | 3059 | 3062 | 3175 | | | | | | | | | | | |
| CLRB | 2720 | 2841 | 2925 | 2951 | 3088 | | | | | | | | | | |
| CMP | 275 | 295 | 406 | 622 | 651 | 787 | 826 | 933 | 937 | 976 | 992 | 1017 | 1023 | 1027 | 1144 |
| | 1151 | 1242 | 1249 | 1255 | 1330 | 1397 | 1405 | 1442 | 1457 | 1519 | 1578 | 1878 | 2128 | 2135 | 2137 |
| | 2160 | 2167 | 2169 | 2203 | 2217 | 2259 | 2389 | 2391 | 2714 | 2727 | 2756 | 2820 | 3080 | | |
| CMPB | 356 | 364 | 524 | 528 | 532 | 536 | 540 | 544 | 546 | 551 | 553 | 568 | 570 | 574 | 593 |
| | 595 | 638 | 641 | 645 | 674 | 677 | 680 | 721 | 725 | 729 | 817 | 819 | 855 | 858 | 861 |

| | | | | | | | | | | | | | | | |
|-------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|
| | 919 | 923 | 927 | 2284 | 2287 | 2291 | 2299 | 2302 | 2306 | 2308 | 2825 | 2832 | 2834 | 2918 | 2920 |
| COM | 2928 | 2949 | 2953 | | | | | | | | | | | | |
| DEC | 696 | 706 | | | | | | | | | | | | | |
| DEC B | 703 | 1196 | 1258 | 1407 | 2664 | | | | | | | | | | |
| EMT | 2932 | 2935 | 3009 | 3020 | | | | | | | | | | | |
| HALT | 43 | | | | | | | | | | | | | | |
| INC | 507 | 2214 | 2395 | 2428 | 2764 | 2908 | 3168 | 3190 | | | | | | | |
| INC B | 685 | 700 | 931 | 940 | 1026 | 1180 | 1282 | 1409 | 1632 | 1947 | 1992 | 2642 | 2662 | 2726 | 2748 |
| IOT | 2755 | 3015 | 3023 | 3066 | 3176 | | | | | | | | | | |
| JMP | 2731 | 2746 | 2955 | | | | | | | | | | | | |
| | 30 | 33 | 36 | 362 | 508 | 526 | 530 | 534 | 538 | 542 | 549 | 609 | 620 | 624 | 643 |
| | 647 | 653 | 660 | 698 | 723 | 727 | 731 | 733 | 738 | 746 | 770 | 780 | 806 | 828 | 840 |
| | 869 | 878 | 896 | 904 | 921 | 925 | 929 | 939 | 974 | 988 | 1005 | 1033 | 1044 | 1052 | 1060 |
| | 1069 | 1154 | 1157 | 1221 | 1259 | 1341 | 1358 | 1413 | 1446 | 1733 | 2095 | 2134 | 2166 | 2286 | 2289 |
| JSR | 2682 | 2839 | | | | | | | | | | | | | |
| MOV | 380 | 428 | 456 | 469 | 742 | 756 | 775 | 786 | 1020 | 1156 | 1357 | 2677 | 2927 | 2934 | 2941 |
| | 273 | 277 | 279 | 280 | 281 | 282 | 283 | 284 | 285 | 286 | 288 | 291 | 292 | 293 | 294 |
| | 299 | 301 | 302 | 303 | 308 | 316 | 319 | 326 | 330 | 334 | 335 | 336 | 337 | 342 | 355 |
| | 379 | 382 | 390 | 414 | 415 | 416 | 418 | 419 | 427 | 435 | 437 | 440 | 442 | 455 | 458 |
| | 460 | 468 | 471 | 473 | 483 | 487 | 489 | 495 | 496 | 498 | 499 | 518 | 522 | 548 | 567 |
| | 583 | 591 | 598 | 600 | 649 | 655 | 658 | 659 | 737 | 745 | 751 | 752 | 755 | 765 | 767 |
| | 768 | 779 | 789 | 815 | 816 | 822 | 868 | 877 | 886 | 887 | 895 | 901 | 953 | 959 | 978 |
| | 985 | 1001 | 1004 | 1025 | 1051 | 1068 | 1076 | 1077 | 1079 | 1080 | 1081 | 1082 | 1083 | 1092 | 1093 |
| | 1094 | 1095 | 1096 | 1103 | 1104 | 1105 | 1106 | 1107 | 1138 | 1142 | 1150 | 1171 | 1177 | 1211 | 1232 |
| | 1233 | 1235 | 1236 | 1246 | 1247 | 1273 | 1279 | 1290 | 1324 | 1328 | 1352 | 1368 | 1395 | 1430 | 1431 |
| | 1434 | 1436 | 1456 | 1472 | 1478 | 1480 | 1481 | 1489 | 1496 | 1497 | 1506 | 1512 | 1517 | 1530 | 1546 |
| | 1551 | 1554 | 1571 | 1575 | 1631 | 1660 | 1665 | 1666 | 1668 | 1669 | 1670 | 1699 | 1703 | 1704 | 1705 |
| | 1706 | 1709 | 1726 | 1728 | 1729 | 1745 | 1751 | 1753 | 1754 | 1762 | 1769 | 1770 | 1779 | 1785 | 1805 |
| | 1809 | 1816 | 1829 | 1835 | 1847 | 1852 | 1855 | 1871 | 1875 | 1946 | 1991 | 2021 | 2026 | 2027 | 2029 |
| | 2030 | 2031 | 2061 | 2065 | 2066 | 2067 | 2068 | 2071 | 2088 | 2090 | 2091 | 2110 | 2112 | 2119 | 2124 |
| | 2127 | 2130 | 2131 | 2132 | 2141 | 2143 | 2150 | 2155 | 2158 | 2162 | 2163 | 2164 | 2181 | 2188 | 2199 |
| | 2278 | 2295 | 2326 | 2331 | 2337 | 2352 | 2359 | 2371 | 2377 | 2384 | 2386 | 2414 | 2649 | 2667 | 2671 |
| | 2674 | 2709 | 2710 | 2712 | 2715 | 2729 | 2730 | 2732 | 2733 | 2734 | 2749 | 2774 | 2803 | 2804 | 2818 |
| | 2819 | 2836 | 2837 | 2838 | 2843 | 2844 | 2845 | 2846 | 2861 | 2862 | 2863 | 2864 | 2865 | 2867 | 2882 |
| | 2883 | 2884 | 2885 | 2886 | 2910 | 2911 | 2915 | 2930 | 2984 | 2992 | 2993 | 2994 | 3000 | 3007 | 3025 |
| | 3026 | 3027 | 3028 | 3029 | 3049 | 3050 | 3051 | 3052 | 3053 | 3054 | 3055 | 3060 | 3063 | 3083 | 3089 |
| | 3090 | 3091 | 3092 | 3093 | 3095 | 3096 | 3112 | 3113 | 3117 | 3123 | 3124 | 3157 | 3158 | 3159 | 3160 |
| | 3161 | 3162 | 3163 | 3164 | 3165 | 3166 | 3167 | 3173 | 3174 | 3178 | 3179 | 3180 | 3181 | 3182 | 3183 |
| MOVB | 3184 | 3185 | 3186 | | | | | | | | | | | | |
| | 523 | 573 | 592 | 1612 | 1633 | 1924 | 1948 | 1970 | 1993 | 2282 | 2807 | 2824 | 2829 | 2870 | 2912 |
| | 2940 | 2948 | 2985 | 2986 | 2989 | 2990 | 2991 | 2995 | 2998 | 2999 | 3018 | 3058 | 3061 | 3075 | 3078 |
| | 3087 | 3115 | | | | | | | | | | | | | |
| NEG | 2996 | 3057 | | | | | | | | | | | | | |
| NOP | 754 | 902 | 1240 | 1440 | 1477 | 1675 | 1711 | 1750 | 2036 | 2073 | 2678 | 2679 | 2680 | | |
| RESET | 488 | 2462 | 2676 | | | | | | | | | | | | |
| ROL | 695 | 2873 | 2875 | 2877 | 3002 | 3004 | 3005 | 3006 | 3008 | | | | | | |
| RTI | 300 | 1084 | 1097 | 1108 | 1293 | 1462 | 2139 | 2171 | 2226 | 2297 | 2339 | 2360 | 2393 | 2415 | 2442 |
| | 2463 | 2656 | 2735 | 2786 | 2809 | 2847 | 2887 | 2917 | 3030 | 3097 | 3125 | 3189 | | | |
| RTS | 792 | 1185 | 1194 | 1382 | 2249 | 2262 | 2272 | 2957 | 3118 | | | | | | |
| SEC | 2271 | | | | | | | | | | | | | | |
| SUB | 785 | 823 | 980 | 1333 | 1359 | 1445 | 2215 | 2372 | 2385 | 2750 | 3064 | | | | |
| SWAB | 2121 | 2152 | | | | | | | | | | | | | |
| TRAP | 3127 | 3136 | 3137 | 3138 | 3139 | 3142 | 3143 | 3144 | 3146 | 3147 | 3148 | 3149 | 3150 | 3151 | 3152 |
| TST | 491 | 500 | 559 | 601 | 683 | 783 | 799 | 821 | 1042 | 1058 | 1120 | 1126 | 1130 | 1189 | 1192 |
| | 1213 | 1223 | 1228 | 1305 | 1312 | 1344 | 1375 | 1421 | 1482 | 1498 | 1514 | 1531 | 1548 | 1596 | 1664 |

| | | | | | | | | | | | | | | | |
|--------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|
| | 1686 | 1701 | 1727 | 1755 | 1771 | 1786 | 1806 | 1831 | 1849 | 2025 | 2063 | 2089 | 2246 | 2253 | 2412 |
| | 2425 | 2439 | 2711 | 2724 | 2778 | 2881 | 2914 | 2922 | 2944 | 3013 | 3069 | 3079 | 3114 | | |
| TSTB | 688 | 691 | 776 | 875 | 1147 | 1599 | 1903 | 2280 | 2718 | 2805 | 2906 | 2946 | 3071 | 3085 | |
| WAIT | 890 | | | | | | | | | | | | | | |
| XOR | 313 | | | | | | | | | | | | | | |
| .ASCII | 198 | 199 | | | | | | | | | | | | | |
| .ASCIZ | 200 | 347 | 353 | 361 | 370 | 376 | 387 | 396 | 403 | 411 | 425 | 434 | 447 | 453 | 466 |
| | 506 | 515 | 564 | 581 | 589 | 608 | 805 | 812 | 948 | 952 | 958 | 1000 | 1050 | 1067 | 1166 |
| | 1170 | 1176 | 1268 | 1272 | 1278 | 1367 | 2179 | 2187 | 2194 | 2208 | 2213 | 2223 | 2243 | 2269 | 2324 |
| | 2330 | 2336 | 2350 | 2357 | 2376 | 2382 | 2436 | 2461 | 2606 | 2609 | 2613 | 2648 | 2654 | 2685 | 2762 |
| | 2773 | 3193 | | | | | | | | | | | | | |
| .BLKB | 2849 | | | | | | | | | | | | | | |
| .BLKW | 2599 | 3102 | | | | | | | | | | | | | |
| .BYTE | 165 | 165 | 171 | 172 | 180 | 181 | 189 | 190 | 191 | 192 | 2684 | 2848 | 3031 | 3032 | 3033 |
| | 3034 | | | | | | | | | | | | | | |
| .ENABL | 1 | | | | | | | | | | | | | | |
| .END | 3196 | | | | | | | | | | | | | | |
| .ENDC | 8 | 43 | 135 | 149 | 159 | 163 | 165 | 193 | 196 | 197 | 198 | 202 | 252 | 269 | 277 |
| | 278 | 281 | 283 | 285 | 287 | 288 | 289 | 305 | 347 | 353 | 361 | 370 | 376 | 387 | 396 |
| | 403 | 411 | 425 | 434 | 447 | 453 | 466 | 478 | 481 | 506 | 515 | 564 | 581 | 589 | 608 |
| | 614 | 617 | 627 | 636 | 663 | 672 | 710 | 718 | 796 | 797 | 805 | 812 | 834 | 836 | 843 |
| | 853 | 907 | 917 | 948 | 952 | 958 | 1000 | 1009 | 1014 | 1039 | 1040 | 1050 | 1055 | 1056 | 1067 |
| | 1072 | 1074 | 1114 | 1115 | 1166 | 1170 | 1176 | 1268 | 1272 | 1278 | 1297 | 1298 | 1318 | 1321 | 1367 |
| | 1388 | 1391 | 1449 | 1454 | 1466 | 1470 | 1475 | 1476 | 1477 | 1478 | 1479 | 1492 | 1493 | 1494 | 1495 |
| | 1509 | 1510 | 1511 | 1512 | 1513 | 1527 | 1528 | 1529 | 1530 | 1531 | 1543 | 1544 | 1545 | 1546 | 1547 |
| | 1567 | 1568 | 1569 | 1570 | 1591 | 1592 | 1593 | 1594 | 1607 | 1608 | 1609 | 1610 | 1626 | 1627 | 1628 |
| | 1629 | 1650 | 1651 | 1658 | 1659 | 1660 | 1661 | 1689 | 1690 | 1697 | 1698 | 1699 | 1700 | 1738 | 1743 |
| | 1748 | 1749 | 1750 | 1751 | 1752 | 1765 | 1766 | 1767 | 1768 | 1782 | 1783 | 1784 | 1785 | 1786 | 1802 |
| | 1803 | 1804 | 1805 | 1806 | 1826 | 1827 | 1828 | 1829 | 1830 | 1844 | 1845 | 1846 | 1847 | 1848 | 1867 |
| | 1868 | 1869 | 1870 | 1890 | 1891 | 1898 | 1899 | 1900 | 1919 | 1920 | 1921 | 1922 | 1941 | 1942 | 1943 |
| | 1944 | 1965 | 1966 | 1967 | 1968 | 1986 | 1987 | 1988 | 1989 | 2011 | 2012 | 2019 | 2020 | 2021 | 2022 |
| | 2051 | 2052 | 2059 | 2060 | 2061 | 2062 | 2098 | 2108 | 2179 | 2187 | 2194 | 2208 | 2213 | 2223 | 2230 |
| | 2236 | 2243 | 2269 | 2275 | 2276 | 2324 | 2330 | 2336 | 2350 | 2357 | 2364 | 2368 | 2376 | 2382 | 2404 |
| | 2410 | 2419 | 2424 | 2436 | 2449 | 2455 | 2461 | 2467 | 2470 | 2622 | 2625 | 2632 | 2634 | 2635 | 2637 |
| | 2648 | 2654 | 2660 | 2666 | 2669 | 2670 | 2674 | 2676 | 2682 | 2684 | 2685 | 2688 | 2692 | 2695 | 2698 |
| | 2704 | 2706 | 2717 | 2718 | 2720 | 2722 | 2726 | 2731 | 2732 | 2733 | 2736 | 2737 | 2741 | 2762 | 2773 |
| | 2791 | 2812 | 2854 | 2856 | 2889 | 2892 | 2912 | 2962 | 3039 | 3107 | 3113 | 3116 | 3135 | 3136 | 3137 |
| | 3138 | 3139 | 3140 | 3141 | 3142 | 3143 | 3144 | 3145 | 3146 | 3147 | 3148 | 3149 | 3150 | 3151 | 3152 |
| | 3156 | 3165 | 3166 | 3172 | 3178 | 3179 | 3189 | 3196 | | | | | | | |
| .EQUIV | 43 | 44 | 52 | 97 | 98 | 99 | 100 | 101 | 102 | 103 | 104 | 105 | 106 | 125 | 126 |
| | 127 | 128 | 129 | 130 | 131 | 132 | 133 | 134 | | | | | | | |
| .EVEN | 347 | 353 | 361 | 370 | 376 | 387 | 396 | 403 | 411 | 425 | 434 | 447 | 453 | 466 | 506 |
| | 515 | 564 | 581 | 589 | 608 | 805 | 812 | 948 | 952 | 958 | 1000 | 1050 | 1067 | 1166 | 1170 |
| | 1176 | 1268 | 1272 | 1278 | 1367 | 2179 | 2187 | 2194 | 2208 | 2213 | 2223 | 2243 | 2269 | 2324 | 2330 |
| | 2336 | 2350 | 2357 | 2376 | 2382 | 2436 | 2461 | 2618 | 2648 | 2654 | 2762 | 2773 | 3195 | | |
| .IF | 4 | 41 | 107 | 135 | 158 | 162 | 164 | 193 | 196 | 197 | 198 | 201 | 202 | 269 | 272 |
| | 277 | 279 | 281 | 283 | 285 | 287 | 288 | 305 | 346 | 352 | 360 | 369 | 375 | 386 | 395 |
| | 402 | 410 | 424 | 433 | 446 | 452 | 465 | 478 | 481 | 505 | 514 | 563 | 580 | 588 | 607 |
| | 614 | 617 | 627 | 636 | 663 | 672 | 710 | 718 | 796 | 797 | 804 | 811 | 834 | 836 | 843 |
| | 853 | 907 | 917 | 947 | 951 | 957 | 999 | 1009 | 1014 | 1039 | 1040 | 1049 | 1055 | 1056 | 1066 |
| | 1072 | 1074 | 1114 | 1115 | 1165 | 1169 | 1175 | 1267 | 1271 | 1277 | 1297 | 1298 | 1318 | 1321 | 1366 |
| | 1388 | 1391 | 1449 | 1454 | 1466 | 1470 | 1474 | 1476 | 1478 | 1479 | 1491 | 1493 | 1495 | 1508 | 1510 |
| | 1512 | 1513 | 1526 | 1528 | 1530 | 1531 | 1542 | 1544 | 1546 | 1547 | 1566 | 1568 | 1570 | 1590 | 1592 |
| | 1594 | 1606 | 1608 | 1610 | 1625 | 1627 | 1629 | 1649 | 1651 | 1658 | 1660 | 1661 | 1688 | 1690 | 1697 |
| | 1699 | 1700 | 1738 | 1743 | 1747 | 1749 | 1751 | 1752 | 1764 | 1766 | 1768 | 1781 | 1783 | 1785 | 1786 |
| | 1801 | 1803 | 1805 | 1806 | 1825 | 1827 | 1829 | 1830 | 1843 | 1845 | 1847 | 1848 | 1866 | 1868 | 1870 |

| | | | | | | | | | | | | | | | |
|--------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|
| | 1889 | 1891 | 1898 | 1900 | 1918 | 1920 | 1922 | 1940 | 1942 | 1944 | 1964 | 1966 | 1968 | 1985 | 1987 |
| | 1989 | 2010 | 2012 | 2019 | 2021 | 2022 | 2050 | 2052 | 2059 | 2061 | 2062 | 2098 | 2108 | 2178 | 2186 |
| | 2193 | 2207 | 2212 | 2222 | 2230 | 2236 | 2242 | 2268 | 2275 | 2276 | 2323 | 2329 | 2335 | 2349 | 2356 |
| | 2364 | 2368 | 2375 | 2381 | 2404 | 2410 | 2419 | 2424 | 2435 | 2449 | 2455 | 2460 | 2467 | 2470 | 2622 |
| | 2625 | 2631 | 2632 | 2633 | 2634 | 2635 | 2636 | 2637 | 2639 | 2647 | 2653 | 2665 | 2668 | 2670 | 2674 |
| | 2675 | 2682 | 2684 | 2685 | 2691 | 2694 | 2698 | 2702 | 2704 | 2716 | 2718 | 2719 | 2720 | 2722 | 2724 |
| | 2732 | 2733 | 2735 | 2736 | 2737 | 2740 | 2761 | 2772 | 2790 | 2811 | 2853 | 2856 | 2868 | 2891 | 2912 |
| | 2961 | 3038 | 3106 | 3112 | 3116 | 3127 | 3136 | 3137 | 3138 | 3139 | 3140 | 3141 | 3142 | 3143 | 3144 |
| | 3145 | 3146 | 3147 | 3148 | 3149 | 3150 | 3151 | 3152 | 3155 | 3165 | 3166 | 3171 | 3178 | 3179 | 3187 |
| | 3189 | 3193 | | | | | | | | | | | | | |
| .IFF | 41 | 159 | 162 | 164 | 193 | 202 | 277 | 1474 | 1475 | 1476 | 1477 | 1478 | 1492 | 1493 | 1494 |
| | 1495 | 1509 | 1510 | 1511 | 1512 | 1527 | 1528 | 1529 | 1530 | 1543 | 1544 | 1545 | 1546 | 1567 | 1568 |
| | 1569 | 1570 | 1591 | 1592 | 1593 | 1594 | 1607 | 1608 | 1609 | 1610 | 1626 | 1627 | 1628 | 1629 | 1650 |
| | 1651 | 1659 | 1660 | 1661 | 1689 | 1690 | 1698 | 1699 | 1700 | 1747 | 1748 | 1749 | 1750 | 1751 | 1765 |
| | 1766 | 1767 | 1768 | 1782 | 1783 | 1784 | 1785 | 1802 | 1803 | 1804 | 1805 | 1826 | 1827 | 1828 | 1829 |
| | 1830 | 1844 | 1845 | 1846 | 1847 | 1867 | 1868 | 1869 | 1870 | 1890 | 1891 | 1899 | 1900 | 1919 | 1920 |
| | 1921 | 1922 | 1941 | 1942 | 1943 | 1944 | 1965 | 1966 | 1967 | 1968 | 1986 | 1987 | 1988 | 1989 | 2011 |
| | 2012 | 2020 | 2021 | 2022 | 2051 | 2052 | 2060 | 2061 | 2062 | 2632 | 2636 | 2639 | 2665 | 2668 | 2684 |
| | 2692 | 2716 | 2718 | 2720 | 2736 | 2737 | 2741 | 2791 | 2812 | 2854 | 2892 | 2962 | 3039 | 3107 | 3113 |
| | 3155 | 3172 | 3189 | | | | | | | | | | | | |
| .IFT | 347 | 353 | 361 | 370 | 376 | 387 | 396 | 403 | 411 | 425 | 434 | 447 | 453 | 466 | 506 |
| | 515 | 564 | 581 | 589 | 608 | 805 | 812 | 948 | 952 | 958 | 1000 | 1050 | 1067 | 1166 | 1170 |
| | 1176 | 1268 | 1272 | 1278 | 1367 | 2179 | 2187 | 2194 | 2208 | 2213 | 2223 | 2243 | 2269 | 2324 | 2330 |
| .IFTF | 2336 | 2350 | 2357 | 2376 | 2382 | 2436 | 2461 | 2648 | 2654 | 2722 | 2762 | 2773 | 2872 | 2888 | 2889 |
| | 347 | 353 | 361 | 370 | 376 | 387 | 396 | 403 | 411 | 425 | 434 | 447 | 453 | 466 | 506 |
| | 515 | 564 | 581 | 589 | 608 | 805 | 812 | 948 | 952 | 958 | 1000 | 1050 | 1067 | 1166 | 1170 |
| | 1176 | 1268 | 1272 | 1278 | 1367 | 2179 | 2187 | 2194 | 2208 | 2213 | 2223 | 2243 | 2269 | 2324 | 2330 |
| | 2336 | 2350 | 2357 | 2376 | 2382 | 2436 | 2461 | 2648 | 2654 | 2720 | 2762 | 2773 | 2868 | 2872 | 2888 |
| .IIF | 3 | 8 | 13 | 14 | 201 | 278 | 281 | 287 | 288 | 289 | 954 | 960 | 1002 | 1172 | 1178 |
| | 1274 | 1280 | 1369 | 2182 | 2189 | 2200 | 2332 | 2338 | 2353 | 2378 | 2387 | 2634 | 2650 | 2660 | 2661 |
| | 2672 | 2684 | 2688 | 2695 | 2696 | 2697 | 2698 | 2702 | 2721 | 2733 | 2736 | 2737 | 2775 | 2959 | 3135 |
| | 3136 | 3137 | 3138 | 3139 | 3142 | 3143 | 3144 | 3146 | 3147 | 3148 | 3149 | 3150 | 3151 | 3152 | |
| .IRP | 202 | 269 | 1474 | 1491 | 1508 | 1526 | 1542 | 1566 | 1590 | 1606 | 1625 | 1649 | 1688 | 1747 | 1764 |
| | 1781 | 1801 | 1825 | 1843 | 1866 | 1889 | 1918 | 1940 | 1964 | 1985 | 2010 | 2050 | 2639 | 2702 | 2863 |
| | 2884 | 3049 | 3089 | 3159 | 3165 | 3178 | 3179 | | | | | | | | |
| .LIST | 1 | 23 | 149 | 193 | 195 | 196 | 197 | 269 | 289 | 347 | 353 | 361 | 370 | 376 | 387 |
| | 396 | 403 | 411 | 425 | 434 | 447 | 453 | 466 | 477 | 482 | 506 | 515 | 564 | 581 | 589 |
| | 608 | 613 | 618 | 626 | 637 | 662 | 673 | 709 | 719 | 795 | 798 | 805 | 812 | 833 | 837 |
| | 842 | 854 | 906 | 918 | 948 | 952 | 958 | 1000 | 1008 | 1015 | 1038 | 1041 | 1050 | 1054 | 1057 |
| | 1067 | 1071 | 1075 | 1113 | 1116 | 1166 | 1170 | 1176 | 1268 | 1272 | 1278 | 1296 | 1299 | 1317 | 1322 |
| | 1367 | 1387 | 1392 | 1448 | 1455 | 1465 | 1471 | 1474 | 1478 | 1491 | 1495 | 1508 | 1512 | 1526 | 1530 |
| | 1542 | 1546 | 1566 | 1570 | 1590 | 1594 | 1606 | 1610 | 1625 | 1629 | 1649 | 1652 | 1660 | 1688 | 1691 |
| | 1699 | 1737 | 1744 | 1747 | 1751 | 1764 | 1768 | 1781 | 1785 | 1801 | 1805 | 1825 | 1829 | 1843 | 1847 |
| | 1866 | 1870 | 1889 | 1892 | 1900 | 1909 | 1918 | 1922 | 1940 | 1944 | 1964 | 1968 | 1985 | 1989 | 2010 |
| | 2013 | 2021 | 2050 | 2053 | 2061 | 2097 | 2109 | 2179 | 2187 | 2194 | 2208 | 2213 | 2223 | 2229 | 2237 |
| | 2243 | 2269 | 2274 | 2277 | 2324 | 2330 | 2336 | 2350 | 2357 | 2363 | 2369 | 2376 | 2382 | 2403 | 2411 |
| | 2418 | 2425 | 2436 | 2448 | 2456 | 2461 | 2466 | 2471 | 2621 | 2626 | 2648 | 2654 | 2660 | 2676 | 2698 |
| | 2762 | 2773 | 3127 | 3135 | 3136 | 3137 | 3138 | 3139 | 3140 | 3142 | 3143 | 3144 | 3145 | 3146 | 3147 |
| | 3148 | 3149 | 3150 | 3151 | 3152 | 3153 | | | | | | | | | |
| .MACRO | 1 | 152 | 154 | 156 | 2628 | 2689 | 3127 | | | | | | | | |
| .MCALL | 1 | 149 | 289 | | | | | | | | | | | | |
| .NLIST | 1 | 23 | 149 | 193 | 195 | 196 | 197 | 269 | 289 | 347 | 353 | 361 | 370 | 376 | 387 |
| | 396 | 403 | 411 | 425 | 434 | 447 | 453 | 466 | 477 | 482 | 506 | 515 | 564 | 581 | 589 |
| | 608 | 613 | 618 | 626 | 637 | 662 | 673 | 709 | 719 | 795 | 798 | 805 | 812 | 833 | 837 |
| | 842 | 854 | 906 | 918 | 948 | 952 | 958 | 1000 | 1008 | 1015 | 1038 | 1041 | 1050 | 1054 | 1057 |
| | 1067 | 1071 | 1075 | 1113 | 1116 | 1166 | 1170 | 1176 | 1268 | 1272 | 1278 | 1296 | 1299 | 1317 | 1322 |

| | | | | | | | | | | | | | | | |
|--------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|
| | 1367 | 1387 | 1392 | 1448 | 1455 | 1465 | 1471 | 1474 | 1478 | 1491 | 1495 | 1508 | 1512 | 1526 | 1530 |
| | 1542 | 1546 | 1566 | 1570 | 1590 | 1594 | 1606 | 1610 | 1625 | 1629 | 1649 | 1652 | 1660 | 1688 | 1691 |
| | 1699 | 1737 | 1744 | 1747 | 1751 | 1764 | 1768 | 1781 | 1785 | 1801 | 1805 | 1825 | 1829 | 1843 | 1847 |
| | 1866 | 1870 | 1889 | 1892 | 1900 | 1909 | 1918 | 1922 | 1940 | 1944 | 1964 | 1968 | 1985 | 1989 | 2010 |
| | 2013 | 2021 | 2050 | 2053 | 2061 | 2097 | 2109 | 2179 | 2187 | 2194 | 2208 | 2213 | 2223 | 2229 | 2237 |
| | 2243 | 2269 | 2274 | 2277 | 2324 | 2330 | 2336 | 2350 | 2357 | 2363 | 2369 | 2376 | 2382 | 2403 | 2411 |
| | 2418 | 2425 | 2436 | 2448 | 2456 | 2461 | 2466 | 2471 | 2621 | 2626 | 2648 | 2654 | 2660 | 2676 | 2698 |
| | 2762 | 2773 | 3127 | 3135 | 3136 | 3137 | 3138 | 3139 | 3140 | 3142 | 3143 | 3144 | 3145 | 3146 | 3147 |
| | 3148 | 3149 | 3150 | 3151 | 3152 | 3153 | | | | | | | | | |
| .PAGE | 156 | 252 | | | | | | | | | | | | | |
| .REPT | 23 | 195 | 196 | | | | | | | | | | | | |
| .SBTTL | 15 | 39 | 156 | 252 | 268 | 271 | 475 | 611 | 830 | 1035 | 1110 | 1134 | 1204 | 1294 | 1315 |
| | 1384 | 1464 | 1474 | 1491 | 1508 | 1526 | 1542 | 1566 | 1590 | 1606 | 1625 | 1649 | 1688 | 1735 | 1747 |
| | 1764 | 1781 | 1801 | 1825 | 1843 | 1866 | 1889 | 1918 | 1940 | 1964 | 1985 | 2010 | 2050 | 2629 | 2689 |
| | 2739 | 2791 | 2851 | 2889 | 2959 | 3036 | 3104 | 3127 | 3153 | | | | | | |
| .TITLE | 3 | | | | | | | | | | | | | | |
| .WORD | 23 | 24 | 25 | 164 | 167 | 168 | 169 | 170 | 173 | 174 | 175 | 176 | 177 | 178 | 179 |
| | 182 | 183 | 184 | 193 | 195 | 196 | 203 | 205 | 207 | 208 | 210 | 211 | 213 | 214 | 216 |
| | 217 | 219 | 220 | 221 | 223 | 224 | 225 | 226 | 227 | 228 | 229 | 230 | 232 | 233 | 234 |
| | 235 | 237 | 238 | 240 | 241 | 242 | 244 | 245 | 246 | 247 | 248 | 249 | 250 | 1415 | 2341 |
| | 2400 | 2401 | 2600 | 2665 | 2668 | 2683 | 2888 | 2956 | 3035 | 3134 | 3188 | | | | |

ERRORS DETECTED: 0
DEFAULT GLOBALS GENERATED: 0

* DZDRH.SEQ/SOL/CRF/PAGNUM+LIB:SYSMAC.SML,DSK:DZDRH
RUN-TIME: 66 49 6 SECONDS
RUN-TIME RATIO: 205/122=1.6
CORE USED: 34K (67 PAGES)

