

# PDP11

INTER TEST PROGRAM  
MD-11-DZITA-D

EP DZITA D DL B  
COPYRIGHT 1977  
FICHE 1 OF 1

MAR 1977  
**digital**  
MADE IN USA

The microfiche card contains a grid of frames. The leftmost column of frames contains text, likely program code or test instructions. The remaining frames in each row contain data, possibly test results or system status information. The text and data are too small to be legible in this image.

IDENTIFICATION

PRODUCT CODE: MAINDEC-11-DZITA-D-D  
PRODUCT NAME: INTERPROCESSOR TEST PROGRAM (ITEP)  
PROGRAM DATE: JANUARY 1977  
MAINTAINER: DIAGNOSTICS

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS DOCUMENT.

THE SOFTWARE DESCRIBED IN THIS DOCUMENT IS FURNISHED UNDER A LICENSE AND MAY ONLY BE USED OR COPIED IN ACCORDANCE WITH THE TERMS OF SUCH LICENSE.

DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL.

COPYRIGHT (C) 1973, 1977 BY DIGITAL EQUIPMENT CORPORATION

## 1.0 ABSTRACT.

THIS PROGRAM IS DESIGNED AS A MAINTENANCE AID FOR FIELD SERVICE PERSONEL. IT WILL VERIFY THE PROPER OPERATION OF A COMPLETE COMMUNICATION LINK FROM ONE PDP-11 SYSTEM TO ANOTHER OR TO A COMMUNICATION TEST CENTER.

## 2.0 REQUIREMENTS.

### 2.1 EQUIPMENT

A. PDP-11 SYSTEM WITH AT LEAST 4K OF CORE.

### 2.2 STORAGE.

4K OF CORE

### 2.3 LOADING PROCEDURE

THIS PROGRAM AND ALL OVERLAYS ARE ASSEMBLED IN ABSOLUTE FORMATS. THE ABS LOADER IS USED TO LOAD THE PROGRAM AND OVERLAYS.

LOAD THE ITEP PROGRAM AND THE APPROPRIATE OVERLAY FOR THE TYPE OF INTERFACE YOU WISH TO TEST.

## 4.0 OPERATING PROCEDURES.

IF RUNNING ITEP ON AN LSI-11 ENVIRONMENT :

1. IF THE LINE CLOCK IS TO BE USED IT SHOULD BE ENABLED PRIOR TO PROGRAM EXECUTION.
- A. TWO METHODS OF ENTERING PARAMETERS ARE PROVIDED
  1. LOAD ADDRESS 200 AND START TO ENTER PARAMS FROM CONSOLE TTY, PROCEED TO SECTION B.
  2. LOAD ADDRESS 200 AND SET SWITCH REGISTER BIT 15 BEFORE STARTING TO ENTER PARAMS FROM CONSOLE SWITCHES, PROCEED TO SECTION C.

\*THE PROGRAM MAY BE RESTARTED AT LOC 204 (ONCE PARAMETERS HAVE ALREADY BEEN SELECTED)
- B. CONSOLE DIALOGUE PARAMETER INPUT (CURRENT VALUES FOR PARAMETERS ARE FOUND IN OVERLAY)
 

DN11 AND DM11BB PARAMETERS ARE DISCUSSED IN SECT. 10.0 OF THIS LISTING.

  1. THE PROGRAM WILL TYPEOUT THE NAME OF THE VARIABLE OVERLAY.
    - A. IF YOU WISH TO SETUP JUST THE INDICATED OVERLAY, TYPE A CARAGE RETURN
    - B. IF YOU WISH TO SETUP A DN11, TYPE IN DN.
    - C. IF YOU WISH TO SETUP A DM11BB, TYPE IN DMB.

IF DN OR DMB WAS TYPED IN STEP 1 ABOVE THEN THE BUS ADDRESS, VECTOR, ETC. REFERED TO IN STEPS 2 THRU 7, PERTAIN TO THE DN11 OR DM11BB.
  2. THE PROGRAM WILL TYPE THE DEFAULT BUS ADDRESS OF THE INTERFACE UNDER TEST.
    - A. TYPE A CAR. RETURN TO USE DEFAULT BUS ADDRESS
    - B. TYPEIN ACTUAL BUS ADDRESS
  3. THE PROGRAM WILL TYPE OUT THE DEFAULT VECTOR ADDRESS
    - A. TYPE A CAR. RETURN TO USE DEFAULT ADDRESS

- B. TYPEIN ACTUAL VECTOR ADDRESS
4. THE PROGRAM WILL TYPE OUT THE DEFAULT INTERFACE PRIORITY  
 NOTE: 200=PRIO 4, 240=PRIO 5, 300=PRIO 6, ETC.  
 A. TYPE A CAR. RETURN TO USE DEFAULT VALUE  
 B. TYPEIN ACTUAL VALUE
  5. THE PROGRAM WILL TYPEOUT THE DEFAULT VALUE OF PARAM#1  
 IF REQUIRED BY THE OVERLAY. (SEE SECT. 10.0 IN OVERLAY LISTING FOR PARAMETER DESCRIPTION)  
 A. TYPE A CAR. RETURN TO USE DEFAULT VALUE  
 B. TYPEIN ACTUAL VALUE
  6. THE PROGRAM WILL TYPEOUT THE DEFAULT VALUE OF PARAM#2  
 IF REQUIRED BY THE OVERLAY.  
 A. TYPE A CAR. RETURN TO USE DEFAULT VALUE  
 B. ENTER ACTUAL VALUE
  7. THE PROGRAM WILL TYPEOUT THE DEFAULT VALUE OF PARAM#3  
 IF REQUIRED BY THE OVERLAY.  
 A. TYPE A CAR. RETURN TO USE DEFAULT VALUE  
 THE DN-11 WILL USE PARAM #3 AS THE # TO DIAL.  
 IF USING A MODEM WITHOUT AUTOMATIC HANDSHAKING,  
 THE NUMBER MUST TERMINATE WITH A  
 "END-OF-NUMBER" CHARACTER (:).  
 B. ENTER ACTUAL VALUE.
  8. THE PROGRAM WILL RETURN TO STEP B1 IF THIS SETUP  
 WAS FOR DN11 OR DM11BB.
  9. THE PROGRAM WILL REQUEST THAT SWITCH REGISTER BE SET.  
 A. SETUP SWITCH REGISTER AS SPECIFIED IN STEP D.  
 AND TYPE A CAR. RETURN.
- NOTE: IF ANY OF THE ABOVE ITEMS 2 THRU 7 WERE CHANGED BY ENTERING  
 NEW VALUES, THE NEW VALUE BECOMES THE DEFAULT VALUE FOR SUBSEQUENT  
 RESTARTS OF THE PROGRAM.

- C. MANUAL PARAMETER INPUT FROM SWITCH REGISTER
1. THE PROGRAM HALTS FOR ISR (INTERFACE SERVICE ROUTINE) SPECIFICATION  
 SWR14=1 SETUP DM-11BB ISR  
 SWR13=1 SETUP DN-11 ISR  
 SWR=000000=SETUP VARIABLE ISR (OVERLAY) (NOT DN-11 OR DM11BB)  
 SET APPROPRIATE SWITCHES AND HIT CONTINUE.
  2. THE FOLLOWING HALTS ARE REPEATED FOR EACH ISR SPECIFIED.  
 SETUP SEQUENCE IS: DN11, DM11-BB THEN VARIABLE ISR. (FOR EACH ENTRY SET SWITCHES AND THEN HIT CONT.)
    - A. HALT FOR BUS ADDRESS OF INTERFACE
    - B. HALT FOR VECTOR ADDRESS OF INTERFACE
    - C. HALT FOR PRIORITY OF INTERFACE (200=PRIO 4, 240=PRIO 5, 300=PRIO 6, ETC.)
    - D. HALT FOR INTERFACE PARAM #1 (SEE SECT. 10.0 IN OVERLAY LISTING FOR PARAMETER DESCRIPTION)
    - E. HALT FOR INTERFACE PARAM #2 (DN11 AND DMBB PARAMETERS ARE DISCUSSED IN SECT. 10.C OF THIS LISTING)
    - F. GO BACK TO STEP A IF THIS SETUP WAS FOR DN OR DMB.
  3. HALT FOR OPERATIONAL SWITCH SETTINGS. (SEE STEP D.)
    - A. PRESS CONTINUE TO START TESTING

THIS PROGRAM HAS BEEN MODIFIED TO RUN ON A PROCESSOR WITH OR WITHOUT A HARDWARE SWITCH REGISTER. WHEN FIRST EXECUTED THE PROGRAM TESTS THE EXISTENCE OF A HARDWARE SWITCH REGISTER. IF NOT FOUND A SOFTWARE SWITCH REGISTER LOCATION (SWREG=LOC. 176 ) IS DEFAULTED TO. IF THIS IS THE CASE, UPON EXECUTION THE CONTENTS OF THE SWREG ARE DUMPED IN OCTAL ON THE CONSOLE TTY AND ANY CHANGES ARE REQUESTED

(IF) SWR=XXXXXX NEW=

POSSIBLE RESPONSES ARE:

1. <CR> IF NO CHANGES ARE TO BE MADE
2. 6 DIGITS 0-7 TO REPRESENT IN OCTAL THE NEW SWITCH REGISTER VALUE ;LAST DIGIT FOLLOWED BY <CR>.
3. ↑U TO ALLOW REENTERING VALUE IF ERROR IS COMMITTED KEYING IN SWREG VALUE.

BUILT INTO THE PROGRAM IS THE ABILITY TO DYNAMICALLY CHANGE THE CONTENTS OF SWREG DURING PROGRAM EXECUTION. BY STRIKING ↑G (CNTRL G) ON CONSOLE TTY THE OPERATOR SETS A REQUEST FLAG TO CHANGE THE CONTENTS OF SWREG, WHICH IS PROCESSED IN KEY AREAS OF THE PROGRAM CODE (IE) ERROR ROUTINES, AFTER HALTS END OF PASS, AND OTHER APPLICABLE AREAS.

D. OPERATIONAL SWITCH SETTINGS.

SW15=1 HALT ON ERROR  
SW14=1 SINGLE PASS  
SW14 HAS NO EFFECT IF SW04=0  
SW13=1 INHIBIT ERROR TIMEOUTS  
SW12=1 INHIBIT ALL TIMEOUTS EXCEPT ERRORS  
IF SW12=0 AND SW04=1 END PASS IS TYPED  
AND TRANSMITTED/RECEIVED DATA IS TYPED.  
SW11=1 USE PREVIOUSLY SPECIFIED DATA  
SW10=1 DATA SELECT (WITH SW09)  
SW09=1 DATA SELECT (WITH SW10)  
00=1 GET DATA FROM OPERATOR  
01=1 TEST MESSAGE #1 (\$A QUICK BROWN FOX)  
10=1 TEST MESSAGE #2 (\$B NUMERIC5)  
11=1 TEST MESSAGE #3 (\$C COMTEST/QUICK BROWN FOX/NUMERIC5)  
SW08=1 TRANSMIT RECEIVED DATA (INTERNAL LOOPBACK MODE)  
SW07=1 DO NOT TEST RECEIVED DATA  
SW06=1 MONITOR TRANSMITTED DATA ON CONSOLE TTY.\*  
SW05=1 MONITOR RECEIVED DATA ON CONSOLE TTY.\*  
\* IN MANY CASES, NOT ALL DATA WILL APPEAR ON THE CONSOLE  
TTY. THIS IS ESPECIALLY TRUE WHEN THE COMM INTERFACE IS  
RUNNING AT A FASTER BAUD THAN THE CONSOLE, BUT EVEN AT EQUAL  
OR SLOWER BAUDS, ALL CHARACTERS MAY NOT APPEAR ON THE CONSOLE.  
  
SW04=1 RETURN TO MONITOR FOR END PASS  
WHEN SW04=0 PROGRAM LOOPS IN THE OVERLAY NEVER RETURNING TO THE MONITOR.  
SW03=1 INTERNAL LOOPBACK MODE  
SW02=1 EXTERNAL LOOPBACK MODE  
SW01=1 ONE-WAY-IN MODE  
SW00=1 ONE-WAY-OUT MODE

IF OPERATOR SPECIFIED DATA WAS INDICATED, THE PROGRAM WILL TYPE A  
REQUEST FOR THE DATA. DATA MAY BE ENTERED AS ASCII CHARACTERS OR OCTAL CODE.  
TYPE IN THE DATA TERMINATED WITH A CR. OCTAL CODE MAY BE ENTERED BY TYPING AN  
↑(UP ARROW) FOLLOWED BY THE OCTAL CODE (IN THE RANGE 000 TO 377)  
SEPERATED BY SPACES AND TERMINATED BY ↑(UP ARROW).  
I.E. ABCD↑ 000 123 377↑ EFG (CAR.RETURN)

A TYPICAL SWITCH SETTING FOR HALF-DUPLEX=003150 THIS SETTING USES  
INTERNAL LOOPBACK MODE, LOOPS IN OVERLAY, MONITORS TRANSMITTED AND RECEIVED  
DATA ON THE CONSOLE TTY, AND TESTS RECEIVED DATA USING TEST MESSAGE #3.

A TYPICAL SWITCH SETTING FOR FULL-DUPLEX=003144 THIS SETTING  
IS THE SAME AS ABOVE EXCEPT IT USES THE EXTERNAL LOOPBACK MODE.

ALL STANDARD MESSAGES( TEST MESSAGES 1-3) ARE PRECEDED BY 2 FILL CHARACTERS(177),  
AND ARE FOLLOWED BY A CR(015), LF(012), RECEIVE TERMINATING CHARACTER(001),  
4 FILLS(177), AND A TRANSMIT TERMINATING CHARACTER(000). DURING TRANSMISSION,  
WHEN A 000 CHARACTER IS SEEN THE TRANSMISSION IS STOPPED. DURING RECEPTION,  
WHEN A 001 CHARACTER IS RECEIVED, THE RECEIVER IS SHUT OFF.  
IF THE MESSAGE WAS INPUTED BY THE OPERATER, THE TERMINATING CHARACTERS ARE ADDED.

## TEST MODES

## INTERNAL LOOPBACK MODE

1. THE OVERLAY WAITS TO RECEIVE A MESSAGE (TERMINATED BY <001>)
2. VERIFIES THE DATA AGAINST THE DATA SELECTED BY SW09 AND SW10 (SW7=0)
3. TRANSMIT THE DATA SELECTED BY SW09 AND SW10 (SW8=0) OR  
TRANSMIT THE RECEIVED DATA (SW8=1)
4. RETURNS TO MONITOR FOR "END PASS" (SW4=1) OR  
GO TO STEP 1. (SW4=0)

## EXTERNAL LOOPBACK MODE

1. THE OVERLAY SETS REQUEST TO SEND
2. WAIT FOR CLEAR TO SEND
3. TRANSMITS THE SELECTED DATA
4. RESETS REQUEST TO SEND
5. WAIT FOR MESSAGE TO BE RECEIVED
6. VERIFIES THE DATA (SW07=0)
7. RETURNS TO MONITOR FOR "END PASS". (SW04=1) OR  
GO TO STEP 1 (SW04=0)

## ONE-WAY-IN MODE

1. THE OVERLAY WAITS FOR MESSAGE TO BE RECEIVED.
2. VERIFIES THE DATA (SW07=0)
3. RETURNS TO MONITOR FOR "END PASS" (SW04=1) OR  
GO TO STEP 1 (SW04=0)

## ONE-WAY-OUT MODE

1. THE OVERLAY SETS REQUEST TO SEND
2. WAITS FOR CLEAR TO SEND
3. TRANSMITS SELECTED DATA
4. RETURNS TO MONITOR FOR "END PASS". (SW04=1) OR  
GO TO STEP 1 (SW04=0)

- E. THE OVERLAY IS THEN ENTERED AND A CONNECTION ESTABLISHED EITHER MANUALLY OR AUTOMATICALLY.

IF ONE-WAY-IN OR INTERNAL LOOPBACK MODES ARE SELECTED.  
 THE OVERLAY WILL SET DATA TERMINAL READY AND WAIT FOR DATA.

IF ONE-WAY-OUT OR EXTERNAL LOOPBACK MODES WERE SELECTED.  
 THE OVERLAY WILL SET DATA TERMINAL READY AND REQUEST TO SEND.  
 THE OVERLAY WILL THEN WAIT FOR CLEAR TO SEND BEFORE ATTEMPTING TO  
 TRANSMIT DATA.

F. IF SW04=0 THE OVERLAY WILL CONTINUE TO TRANSMIT/RECEIVE DATA.

IF SW04=1 THE OVERLAY WILL RETURN TO THE MONITOR AND TYPE "END PASS".

IF BOTH SW04=1 AND SW14=1, THE PROGRAM WILL REQUEST NEW INTERFACE PARAMS AFTER ONE PASS OF THE SELECTED TEST MODE.

TEST EXECUTION MAY BE INTERRUPTED BY TYPING THE FOLLOWING CHARACTERS ON THE CONSOLE TTY.

LINE FEED = RESTART PROGRAM AT LOCATION 200.

QUESTION MARK = PRINTOUT FIRST 8 WORDS OF INPUT BUFFER. (ASCII)

THEN TYPE EITHER:

\*WXXXXXX TO PRINTOUT THE 8 WORDS AT LOC XXXXXX.

\*BXXXXXX TO PRINTOUT THE 16 BYTES AFTER LOC XXXXXX.

\*C TO CONTINUE

PROGRAM MUST BE RESTARTED AT 200 AFTER PRINTING.

CARRIAGE RETURN = RESTART AT REQUEST FOR NEW OPERATIONAL SWITCHES.

### 5.0 PROGRAM AND/OR OPERATOR ACTION

IF THE OPERATOR WISHES TO MANUALLY EXAMINE THE TRANSMIT OR RECEIVE BUFFERS, DO THE FOLLOWING: TO FIND THE STARTING ADDRESS OF THE RECEIVE BUFFER, LOAD ADDRESS 11020 AND EXAMINE. TO FIND THE STARTING ADDRESS OF THE TRANSMIT BUFFER, LOAD ADDRESS 11022 AND EXAMINE.

#### 5.1 NORMAL HALTS SEE SECTION 4.

### 6.0 ERRORS

#### 6.1 ERROR REPORTING

THE ONLY ERROR REPORT FROM THE CONTROL PROGRAM OCCURS IF THE INTERFACE SPECIFIED IS NOT LOADED.

THE ERROR REPORTS FROM THE VARIOUS INTERFACE SERVICE ROUTINES ARE AS DEFINED IN THEIR DOCUMENTS

### 7.0 RESTRICTIONS

THE OPERATION OF THIS PROGRAM REQUIRES COORDINATION BETWEEN THE OPERATOR AND THE OPERATOR OF ANOTHER PDP-11 SYSTEM UNLESS ONE OF THE SYSTEMS IS ALWAYS OPERATING IN A FIXED MODE. THE FOLLOWING TABLE LISTS THE VALID COMBINATIONS:



NOTE: ONLY ONE MODE MAY BE SELECTED AT A TIME.

CPU #1	CPU #2
ONE-WAY-OUT	ONE-WAY-IN
ONE-WAY-IN	ONE-WAY-OUT
EXTERNAL-LOOPBACK	INTERNAL-LOOPBACK
INTERNAL-LOOPBACK	EXTERNAL-LOOPBACK
EXTERNAL-LOOPBACK	EXTERNAL-LOOPBACK (FULL-DUPLEX)

WHEN THE COMMUNICATION LINK INVOLVES MODEMS THE FOLLOWING RESTRICTIONS APPLY:

IF RUNNING IN FULL DUPLEX MODE BOTH SYSTEMS MUST BE IN EXTERNAL LOOP BACK MODE.

BOTH SYSTEMS SHOULD BE RUNNING IDENTICAL ROUTINES.

EXAMPLE:  
SWITCHES 14,13,7,4 SHOULD BE THE SAME  
ON BOTH CPU S

## 9.0 MISCELLANEOUS

ITEP WAS CHECKED OUT USING THE FOLLOWING BELL TELEPHONE MODEMS.  
201A (HALF-DUPLEX SYNCHRONOUS 2000 BAUD)  
202C (HALF-DUPLEX ASYNCHRONOUS 1200 BAUD)  
103A (FULL-DUPLEX ASYNCHRONOUS 110 BAUD)

## 9.1 PROGRAM DESCRIPTION

THE INTERPROCESSOR TEST PROGRAM (ITP) PROVIDES THE LINKAGE BETWEEN THE OPERATOR AND THE VARIOUS INTERFACE SERVICE ROUTINES (OVERLAY) WHICH PERFORM THE ACTUAL DATA MOVEMENT AND VERIFICATION TO AND FROM THE COMMUNICATION LINK. IN ADDITION, ITP CONTAINS VARIOUS INTERRUPT AND SUB ROUTINES WHICH ARE USED BY THE OVERLAY'S.

## 9.1 TRAP CATCHER

THIS IS A SERIES OF JUMP AND HALT INSTRUCTIONS PLACED IN ALL UNUSED VECTORS TO CATCH UNEXPECTED INTERRUPTS.

## 9.2 SWITCH REGISTER INPUT ROUTINE (MANIN:)

THIS ROUTINE IS ENTERED ONLY WHEN SWITCH 15 IS SET WHEN PROGRAM IS STARTED AT LOCATION 200. IT ACCEPTS PARAMETERS FOR THE ISR'S FROM THE CONSOLE SWITCHES AT A SERIES OF HALTS. AS SPECIFIED IN OPERATING INSTRUCTIONS.

## 9.3 PARAMETER INPUT ROUTINE (GETIT:)

THIS ROUTINE SOLICITS PARAMETERS FROM THE OPERATOR ON THE CONSOLE DEVICE AND PLACES THEM IN THE SPECIFIED ISR'S PARAMETER TABLE.  
NOT USED OPTIONAL PARAMETER WORDS ARE INDICATED BY THE PRESENCE OF A NEGATIVE VALUE IN THE ISR'S TABLE. THIS SECTION OF CODE UTILIZES SUB/ROUTINE 'GETANY' WHICH PRINTS OUT THE WORD POINTED TO BY THE ADDRESS IN REGISTER 0.  
IT THEN INPUTS A WORD OR CARRIAGE RETURN FROM THE OPERATOR. IF ONLY A CARRIAGE RETURN IS TYPED, THE PARAMETER IS LEFT AS IT IS, OTHERWISE IT IS REPLACED BY THE OPERATORS TYPE IN AND THE POINTER IN REGISTER 0 IS INCREMENTED TO THE NEXT WORD.

## 9.4 TTY INTERRUPT (TTYINT:)

THE TTY INTERRUPT IS USED TO INTERRUPT THE EXECUTION OF A TEST IN ORDER TO RESTART (TYPE A LINE FEED) OR TO SPECIFY NEW OPERATIONAL SWITCHES (TYPE A CARRIAGE RETURN)

9.5 SET SWITCH OPTIONS (SWRSET:)

THE PROGRAM WILL HALT (MANUAL PARAMETER ENTRY) OR WAIT FOR A CARRIAGE RETURN (TTY CONTROL) AT THIS POINT TO PERMIT THE OPERATOR TO SETUP THE OPERATIONAL SWITCH SETTINGS. THE TEST MODE(SW00-SW03) AND TEST DATA(SW09-SW11) MAY BE CHANGED ONLY AT THIS POINT. ALL OTHER SWITCHES MAY BE CHANGED WHILE A TEST IS RUNNING. IF NEW VARIABLE DATA IS SPECIFIED, THIS ROUTINE WILL REQUEST THAT THE DATA BE ENTERED AND UTILIZES THE 'GETSTR' SUBROUTINE TO INPUT THE DATA FROM THE OPERATOR.

9.6 SETUP TIMER (SUTIME:)

THE PROGRAM LOOKS FOR AND UTILIZES EITHER THE LINE CLOCK OR REAL TIME CLOCK IF EITHER IS PRESENT ON THE SYSTEM. A BUS ERROR(NO RESPONSE) IS USED TO INDICATE THE ABSENCE OF A CLOCK. IF NEITHER EXISTS, THE PROGRAM WILL STILL RUN BUT IS SUBJECT TO WAITING IN UNENDING LOOPS.

9.7 THE INTERFACE SERVICE ROUTINES (ISR'S) ARE ENTERED AT THIS POINT.

9.8 END OF PASS (\$EOP:)

THIS SECTION OF CODE WILL PRINT "END OF PASS XXXXXX" AND THEN SENSE FOR SW14. IF SWITCH 14 IS RESET THE OVERLAY'S ARE REENTERED. IF SWITCH 14 IS SET THE PROGRAM CHECKS TO SEE IF IT WAS LOADED BY A MONITOR (LOCATION 42 NOT EQUAL 0) AND IF IT WAS, CONTROL IS RETURNED TO THE MONITOR. OTHERWISE THE PROGRAM REQUESTS NEW PARAMETERS.

9.10 HALT HANDLER (\$HLT:)

THIS ROUTINE IS USED TO SENSE THE OPERATIONAL SWITCHES AND PROVIDE ERROR CONTROL. IT WILL PRINTOUT THE ADDRESS OF THE ERROR HLT IF SWITCH 13 (DELETE ERROR TYPEOUTS) IS DOWN (NOT SET)

- 9.11 READ A CHARACTER ROUTINE (\$READC:)  
THIS ROUTINE GETS A CHARACTER FROM THE TTY AND PLACES IT ON THE STACK
- 9.12 READ A STRING ROUTINE (\$READS)  
THIS ROUTINE GETS A STRING OF CHARACTERS FROM THE TTY AND PLACES THEM IN A BUFFER SPECIFIED BY THE ADDRESS FOLLOWING THE SUB/ROUTINE CALL.  
THE ROUTINE WILL ALSO ACCEPT OCTALLY REPRESENTED CHARACTERS WHEN THEY ARE PRECEDED AND FOLLOWED BY LP ARROWS, AND SPERATED BY SPACES OR COMMAS.
- 9.13 OCTAL INPUT ROUTINE(\$ACCEPT:)  
THIS ROUTINE READS AN OCTALLY REPRESENTED WORD FROM THE TTY AND PLACES IT IN THE LOCATION INDICATED BY THE ADDRESS FOLLOWING THE SUB/ROUTINE CALL.
- 9.14 CLOCK INTERRUPT ROUTINE (TIMER:)  
THIS ROUTINE IS ENTERED ON INTERUPTS FROM EITHER THE LINE CLOCK OR REAL TIME CLOCK EVERY 16 MILLISECONDS IF EITHER IS PRESENT.  
IT WILL INCREMENT LOCATION 'TIME:' IN THE OVERLAY'S PARAMETER TABLE EVERY SECOND.
- 9.15 BINARY TO OCTAL RCUTINE (\$B2O16)  
THIS ROUTINE WILL PRINTOUT THE OCTAL REPRESENTATION OF A WORD ON THE STACK.
- 9.16 POWER DOWN ROUTINE (\$PWRDN:)  
THIS ROUTINE SAVES THE STATUS OF THE MACHINE WHEN POWER IS LOST.
- 9.17 POWER UP ROUTINE (\$PWRUP:)  
THIS ROUTINE RESTORES THE STATE OF THE MACHINE WHEN POWER IS RESTORED AND RESTARTS AT ADDRESS 200.
- 9.18 VARIABLE INTERFACE SERVICE ROUTINE (VISR:)  
THESE LOCATIONS ARE RESERVED FOR AND WILL BE OVERLAID BY THE VARIABLE ISR'S.  
THE FIRST 2 WORDS CONTAIN A 3 CHARACTER ISR NEMONIC FOLLOWED BY A ZERO CHARACTER.  
THE NEXT 3 WORDS CONTAIN THE BUS ADDRESS, VECTOR ADDRESS AND PRIORITY.  
THE NEXT 2 WORDS MAY CONTAIN OPTIONAL PARAMETERS. THEY WILL CONTAIN ALL ONES IF THEY ARE NOT REQUIRED  
THE NEXT WORD MAY CONTAIN THE ADDRESS OF AN INPUT BUFFER IF THE ISR REQUIRES AN ASCII PARAMETER. IT WILL CONTAIN

ALL ONES IF THE PARAMETER IS NOT REQUIRED.  
LOCATION 'CLOCK:' WILL BE INCREMENTED EVERY SECOND WHILE  
THE TEST IS BEING RUN IF THERE IS A LINE CLOCK OR REAL TIME CLOCK  
ON THE SYSTEM. IT MAY BE USED AS A ELAPSED TIMER BY THE ISR.

### 10.0 PARAMETERS FOR THE DM11BB AND THE DN11

#### 10.1 DM11BB PARAMETERS

PARAM#1 IS LOADED INTO THE CONTROL AND STATUS REGISTER OF THE DM11BB  
TO SELECT THE LINE NUMBER IN OCTAL (BITS 0-3). ALL OTHER BITS MUST BE 0'S.  
THIS IS THE ONLY PARAMETER USED BY THE DM11BB.

#### 10.2 DN11 PARAMETERS

ONLY PARAM#3 IS USED BY THE DN11, IT CONTAINS THE NUMBER THE DN WILL DIAL.

NO1

MAINDEC-11-DZITA-D INTERPROCESSOR TEST PROGRAM MACY11 27(1006) 01-DEC-76 11:01 PAGE 13  
DZITAS.F11 01-DEC-76 11:00

SEQ 0013

000000  
000001  
000002  
000003  
000004  
000005  
000006  
000007  
000000  
000006  
000007  
  
100000  
040000  
020000  
010000  
004000  
002000  
001000  
000400  
000200  
000100  
000040  
000020  
000010  
000004  
000002  
000001  
  
000000  
000040  
000100  
000140  
000200  
000240

:BASIC DEFINITIONS  
:\*\*\*\*\*  
:INITIAL ADDRESS OF THE STACK POINTER  
STACK= 1070

:\*\*\*\*\*  
:EQUIV EMT,HLT

:BASIC DEFINITION OF ERROR CALL

:REGISTER DEFINITION

R0= %0  
R1= %1  
R2= %2  
R3= %3  
R4= %4  
R5= %5  
R6= %6  
R7= %7  
MODE= %0  
R6=SP  
R7=PC

:GENERAL REGISTER  
:GENERAL REGISTER  
:GENERAL REGISTER  
:GENERAL REGISTER  
:GENERAL REGISTER  
:GENERAL REGISTER  
:GENERAL REGISTER  
:GENERAL REGISTER

:SWITCH DEFINITION

SW15= 100000  
SW14= 40000  
SW13= 20000  
SW12= 10000  
SW11= 4000  
SW10= 2000  
SW09= 1000  
SW08= 400  
SW07= 200  
SW06= 100  
SW05= 40  
SW04= 20  
SW03= 10  
SW02= 4  
SW01= 2  
SW00= 1

.EQUIV SW09,SW9  
.EQUIV SW08,SW8  
.EQUIV SW07,SW7  
.EQUIV SW06,SW6  
.EQUIV SW05,SW5  
.EQUIV SW04,SW4  
.EQUIV SW03,SW3  
.EQUIV SW02,SW2  
.EQUIV SW01,SW1  
.EQUIV SW00,SW0

PRTY0= 0  
PRTY1= 40  
PRTY2= 100  
PRTY3= 140  
PRTY4= 200  
PRTY5= 240

030300  
 000340  
 100000  
 040000  
 020000  
 010000  
 004000  
 002000  
 001000  
 000400  
 000200  
 000100  
 000040  
 000020  
 000010  
 000004  
 000002  
 000001  
 000004  
 000010  
 000014  
 000014  
 000014  
 000020  
 000024  
 000030  
 000034  
 000000  
 000024  
 000026  
 000030  
 000032  
 000034  
 000026

PRTY6= 300  
PRTY7= 340

: MISCELLANEOUS BIT ASSIGNMENT

BIT15= 100000  
 BIT14= 40000  
 BIT13= 20000  
 BIT12= 10000  
 BIT11= 4000  
 BIT10= 2000  
 BIT09= 1000  
 BIT08= 400  
 BIT07= 200  
 BIT06= 100  
 BIT05= 40  
 BIT04= 20  
 BIT03= 10  
 BIT02= 4  
 BIT01= 2  
 BIT00= 1  
 .EQUIV BIT09,BIT9  
 .EQUIV BIT08,BIT8  
 .EQUIV BIT07,BIT7  
 .EQUIV BIT06,BIT6  
 .EQUIV BIT05,BIT5  
 .EQUIV BIT04,BIT4  
 .EQUIV BIT03,BIT3  
 .EQUIV BIT02,BIT2  
 .EQUIV BIT01,BIT1  
 .EQUIV BIT00,BIT0

: VECTOR ADDRESSES

ERRVEC= 4  
 RESVEC= 10  
 TBITVEC= 14  
 TRTVEC= 14  
 BPTVEC= 14  
 IOTVEC= 20  
 PWRVEC= 24  
 EMTVEC= 30  
 TRAPVEC= 34  
 .EQUIV R4,CSR  
 .EQUIV R4,RCSR

:=0  
 :TRAP CATCHER IN UNUSED LOCATIONS FROM 0 - 776  
 :LOCATION 0 WILL CATCH IMPROPERLY LOADED VECTORS

:=24  
 \$PWRCN  
 340  
 \$HLT  
 34C  
 \$TRAP  
 34C



```

647          000100          . = 100
648 000100 006312          TIMER
649 000102 000340          340
650
651          000174          . = 174
652 000174 000000          DISPREG: 0
653 000176 000000          SWREG:  0
654
655          000200          . = 200
656
657 000200 000137 003254          JMP      @#BEGIN          : JUMP TO STARTING ADDRESS OF PROGRAM
658 000204 000137 004116          JMP      @#SWPANT        : RESTART AT 204. DO THE RESTART.

```

```

659                                     ;*****
660      001100                          .=1100
661
662                                     ;ROUTINE TO TYPE ASCII MESSAGE. MESSAGE MUST TERMINATE WITH A 0 BYTE.
663                                     ;THE ROUTINE WILL INSERT A NUMBER OF NULL CHARACTERS AFTER A LINE FEED.
664                                     ;NOTE1: NULL CONTAINS THE CHARACTER TO BE USED AS THE FILLER CHARACTER.
665                                     ;NOTE2: $FILLS CONTAINS THE NUMBER OF FILLER CHARACTERS REQUIRED.
666
667                                     ;CALL:
668                                     ;1) USING A TRAP INSTRUCTION
669                                     ;      TYPE      ,MESADR      ;MESADR IS FIRST ADDRESS OF AN ASCIZ STRING
670                                     ;OR
671                                     ;      TYPE
672                                     ;      MESADR
673
674      001100      010046      $TYPE:  MOV      RO, -(SP)      ;SAVE RO
675      001102      017600      MOV      @2(SP), RO      ;GET ADDRESS OF ASCIZ STRING
676      001106      062766      ADD      #2, 2(SP)      ;ADJUST RETURN PC
677      001114      112046      1$:      MOVVB   (RO)+, -(SP)      ;PUSH CHARACTER TO BE TYPED ONTO STACK
678      001116      001003      BNE      2$      ;BR IF IT ISN'T THE TERMINATOR
679      001120      005726      TST      (SP)+      ;IF TERMINATOR POP IT OFF THE STACK
680      001122      012600      MOV      (SP)+, RO      ;RESTORE RO
681      001124      000002      RTI      ;RETURN
682      001126      004737      2$:      JSR      PC, 5$      ;GO TYPE THIS CHARACTER
683      001132      122726      3$:      CMPB    #12, (SP)+      ;CHECK IF THE CHAR. TYPED WAS A LINE FEED
684      001136      001366      BNE      1$      ;GO GET NEXT CHAR. IF NOT LINE FEED
685      001140      013746      MOV      NULL, -(SP)      ;GET # OF FILLER CHARS. NEEDED
686                                     ;AND THE NULL CHAR.
687      001144      105366      4$:      DECB    1(SP)      ;DOES A NULL NEED TO BE TYPED?
688      001150      002770      BLT      3$      ;BR IF NO--GO POP THE NULL OFF OF STACK
689      001152      004737      JSR      PC, 5$      ;GO TYPE A NULL
690      001156      000772      BR      4$      ;LOOP
691      001160      105777      5$:      TSTB   @TPS      ;WAIT UNTIL PRINTER IS READY
692      001164      100375      BPL      5$
693      001166      116677      MOVVB   2(SP), @TPB      ;LOAD CHAR TO BE TYPED INTO DATA REG.
694      001174      000207      RTS      PC

```

```

696 :*****
697 :      DEBUG DUMP ROUTINE
698 :*****
699      =1200
700 001200 013746 011042 DMPHLT: MOV     FLAG, -(SP)
701 001204 042737 000070 011042 BIC     #70, FLAG      ;INIT FLAGS
702 001212 104400 001532 TYPE    ,ASTRK        ;TYPE *
703 001216 104402 GETCHR
704 001220 012637 001314 MOV     (SP)+, 6$
705 001224 104400 001314 TYPE    6$
706 001230 122737 000127 001542 CMPS   #127, $CHAR    ;W? FOR WORD
707 001236 001004 BNE     1$
708 001240 052737 00001C 011042 BIS     #BIT3, FLAG    ;SET FLAG BIT
709 001246 000430 BR      3$
710 001250 122737 000102 001542 1$: CMPB  #102, $CHAR    ;B? FOR BYTE
711 001256 001004 BNE     2$
712 001260 052737 000020 011042 BIS     #BIT4, FLAG
713 001266 000420 BR      3$
714 001270 122737 000103 001542 2$: CMPB  #103, $CHAR    ;C? FOR CONTINUE
715 001276 001014 BNE     3$
716 001300 012637 011042 MOV     (SP)+, FLAG
717 001304 052737 000040 011042 BIS     #BITS, FLAG
718 001312 000413 BR      DUMP
719 001314 000000 6$: 000000
720 001316 104400 001526 4$: TYPE    , GUES
721 001322 104400 001536 TYPE    , CRLF
722 001326 000724 BR      DMPHLT
723 001330 005037 001544 3$: CLR     WORK
724 001334 005726 TST    (SP)+
725 001336 104406 001544 ACCEPT  , WORK
726 001342 012700 001476 DUMP:  MOV    #DMPHLT, R0      ;INIT DUMP LIST
727 001346 062710 000020 ADD     #20, (R0)      ;BUMP ADDRESS
728 001352 032737 000040 011042 BIT     #BITS, FLAG
729 001360 001005 BNE     L1
730 001362 013737 001544 001476 MOV     WORK, DMPHLT
731 001370 001001 BNE     L1
732 001372 022020 CMP     (R0)+, (R0)+ ;SKIP 1ST TWO ENTRIES
733
734 001374 012001 L1:  MOV    (R0)+, R1      ;GET ADDR OF DATA FROM LIST
735 001376 001700 BEQ    DMPHLT        ;BR IF END OF LIST
736 001400 104400 001536 TYPE    , CRLF
737 001404 010146 MOV    R1, -(SP)     ;PUSH ADDR ON STACK
738 001406 004037 006350 JSR    R0, $B2016    ;PRINT OUT ADDRESS
739
740 001412 032737 000010 011042 BIT     #BIT3, FLAG
741 001420 001014 BNE     L3
742 001422 012702 000020 MOV     #20, R2      ;SET WORD COUNTER = 8
743 001426 005046 L2:  CLR     -(SP)
744 001430 112116 MOVB   (R1)+, (SP)
745 001432 104400 007152 TYPE    , MSG00
746 001436 004037 00633E JSR    R0, $B200T
747 001442 003 .BYTE 3
748 001443 001 .BYTE 1
749 001444 005302 DEC     R2          ;DECREMENT WORD COUNTER
750 001446 001367 BNE     L2        ;BR IF NOT = 0
751 001450 00075: BR      L1        ;GET NEXT ENTRY

```

752						
753	001452	012702	000010	L3:	MOV	#10,R2
754	001456	012146		1\$:	MOV	(R1)+,-(SP)
755	001460	104400	007152		TYPE	MSG00
756	001464	004037	006350		JSR	R0,\$B2016
757	001470	005302			DEC	R2 ;DECREMENT THE WORD COUNT
758	001472	001371			BNE	1\$
759	001474	000737			BR	L1 ;GET NEXT ENTRY
760	001476	000000		DMP1ST:	0	;RESERVED FOR SW. REG
761	001500	000000			0	;END OF TABLE FOR SW. REG
762	001502	000001		.RX:	.BLKW	1
763	001504	000001		.TX:	.BLKW	1
764	001506	000000			0	
765	001510	000000			0	
766	001512	000000			0	
767	001514	177560		TKS:	177560	;TTY KEYBOARD STATUS REG. ADDRESS
768	001516	177562		TKB:	177562	;TTY KEYBOARD DATA BUFFER REG. ADDRESS
769	001520	177564		TFS:	177564	;TTY PRINTER STATUS REG. ADDRESS
770	001522	177566		TPE:	177566	;TTY PRINTER BUFFER REG. ADDRESS
771	001524	000000		NULL:	.WORD	0 ;CONTAINS NULL CHARACTER FOR FILLS

772  
773  
774  
775  
776  
777  
778  
779  
780  
781  
782  
783  
784  
785  
786  
787  
788  
789  
790  
791  
792  
793  
794  
795  
796  
797  
798  
799  
800  
801  
802  
803  
804  
805  
806  
807  
808  
809  
810  
811  
812  
813  
814  
815  
816  
817  
818  
819  
820  
821  
822  
823  
824  
825  
826  
827  
828  
829  
830  
831  
832  
833  
834  
835  
836  
837  
838  
839  
840  
841  
842  
843  
844  
845  
846  
847  
848  
849  
850  
851  
852  
853  
854  
855  
856  
857  
858  
859  
860  
861  
862  
863  
864  
865  
866  
867  
868  
869  
870  
871  
872  
873  
874  
875  
876  
877  
878  
879  
880  
881  
882  
883  
884  
885  
886  
887  
888  
889  
890  
891  
892  
893  
894  
895  
896  
897  
898  
899  
900  
901  
902  
903  
904  
905  
906  
907  
908  
909  
910  
911  
912  
913  
914  
915  
916  
917  
918  
919  
920  
921  
922  
923  
924  
925  
926  
927  
928  
929  
930  
931  
932  
933  
934  
935  
936  
937  
938  
939  
940  
941  
942  
943  
944  
945  
946  
947  
948  
949  
950  
951  
952  
953  
954  
955  
956  
957  
958  
959  
960  
961  
962  
963  
964  
965  
966  
967  
968  
969  
970  
971  
972  
973  
974  
975  
976  
977  
978  
979  
980  
981  
982  
983  
984  
985  
986  
987  
988  
989  
990  
991  
992  
993  
994  
995  
996  
997  
998  
999  
1000

```

:*****
:           CONSTANTS AND WORKING STORAGE
:*****
    
```

```

QUES: .ASCIZ " ? "
ASTRK: .ASCIZ <15><12>"*"
CRLF: .ASCII <15>
LF: .ASCIZ <12>
      .EVEN
      $WORK=WORK
    
```

```

$CHAR: 0
WORK: 0
WORK1: 0
WORK2: 0
WORK3: 0
WORK4: 0
WORK5: 0
WORK6: 0
FLAGS: 0
    
```

:DATA PATTERN ADDRESS TABLE AND PATTERNS

```

DAT: .WORD VDB ;ADDRESS OF VARIABLE DATA BUFFER
      .WORD DP1 ;ADDRESS OF MESSAGE 1
      .WORD DP2 ;ADDRESS OF MESSAGE 2
      .WORD DP3 ;ADDRESS OF MESSAGE 3
      .WORD DP4 ;ADDRESS OF MESSAGE 4
      .WORD DP5 ;ADDRESS OF MESSAGE 5
      .WORD DP6 ;ADDRESS OF MESSAGE 6
      .WORD DP7 ;ADDRESS OF MESSAGE 7
    
```

:RECEIVER DATA BUFFER STARTS HERE..

```

IBUF: .BLKW 400
VDB: .BLKW 100 ;VARIABLE DATA BUFFER
    
```

```

DP1: .BYTE 177,177
      .ASCIZ 'SA THE QUICK BROWN FOX JUMPED OVER THE LAZY DOG.'<15><12><001><177><177><177><177><177><177>
      .EVEN
DP2: .BYTE 177,177
    
```

```

      .ASCIZ 'SB 0123456789'<15><12><001><177><177><177><177><177>
      .EVEN
DP3: .BYTE 177,177
    
```

```

      .ASCII 'SC COM-TEST MAYNARD THE QUICK BROWN FOX JUMPED OVER THE LAZY DOG'
      .ASCIZ ' 0123456789'<15><12><001><177><177><177><177><177>
      .EVEN
    
```

```

DP4=VDB ;SPARE
DP5=DP1 ;SPARE
DP6=DP2 ;SPARE
DP7=DP3 ;SPARE
    
```

```

014
015
016
017 003254
018 003254 012706 001070
019 003260 104414 000340
020 003264 104420
021 003266 005037 004774
022 003272 012737 003254 003462
023 003300 005037 001562
024 003304 000005
025
026
027
028 003306 022777 100000 005530
029 003314 001062
030
031
032
033
034 003316 012701 010164
035 003322 005000
036 003324 000000
037 003326 017737 005512 001562
038 003334 032777 020000 005502
039 003342 001402
040 003344 004737 003404
041
042 003350 012701 010406
043 003354 032737 040000 001562
044 003362 001402
045 003364 004737 003404
046
047 003370 012701 011004
048 003374 004737 003404
049
050 003400 000137 004200
051
052 003404 011100
053 003406 000000
054 003410 017721 005430
055 003414 011100
056 003416 000000
057 003420 017721 005420
058 003424 011100
059 003426 000000
060 003430 017721 005410
061 003434 011100
062 003436 100410
063 003440 000000
064 003442 017721 005376
065 003446 011100
066 003450 100403
067 003452 000000
068 003454 017721 005364
069 003460 000207

```

```

:*****
: START OF PROGRAM
:*****
BEGIN:
MOV #STACK,SP ;SETJP THE STACK POINTER
STPS,PRTY7
SUSWR
CLR $PASS ;CLEAR THE PASS COUNT
MOV #BEGIN,$LPADR ;INITILIZE THE LOOP ADDRESS FOR SCOPE
CLR FLAGS ;RESET FLAGS
RESET

:*****
: GET PARAMETERS FROM OPERATOR
:*****
CMP #100000,$SWR ;MANUAL INPUT??
BNE GETIT ;BR IF NO

:*****
: SWITCH REG INPUT ROUTINE
:*****
MANIN: MOV #DN+4,R1 ;PRESET POINTER FOR DN-11
CLR RO ;CLEAR DISPLAY
HALT ;HALT FOR ISR REQUEST
MOV $SWR, FLAGS ;SAVE ISR REQUEST INDICATORS
BIT #20000,$SWR ;IS DN11 SETUP REQUESTED?
BEQ .+6 ;BR IF NO
JSR PC,MANBA ;GO SETUP DN11

MOV #DMB+4,R1 ;PRESET DMB ISR ADDRESS
BIT #40000,FLAGS ;IS DMB SETUP REQUESTED?
BEQ .+6 ;BR IF NO
JSR PC,MANBA ;GO SETUP DM11-B

MOV #VISR+4,R1 ;PRESET VARIABLE ISR ADDRESS
JSR PC,MANBA ;GO SETUP VARIABLE ISR

JMP SWRSET ;GO GET OPERATIONAL SWITCHES

MANBA: MOV (R1), RO ;DISPLAY BUS ADDR
HALT ;HALT FOR BUS ADDR
MOV $SWR, (R1)+
MOV (R1), RO ;DISPLAY VECTOR ADDR
HALT ;HALT FOR VECTOR ADDR
MOV $SWR, (R1)+
MOV (R1), RO ;DISPLAY PRIORITY
HALT ;HALT FOR PRIORITY
MOV $SWR, (R1)+
MOV (R1), RO ;DISPLAY PARAM #1
BMI MANINX ;BR IF PARAM NOT REQUIRED
HALT ;HALT FOR PARAM #1
MOV $SWR, (R1)+
MOV (R1), RO ;DISPLAY PARAM #2
BMI MANINX ;BR IF PARAM NOT REQUIRED
HALT ;HALT FOR PARAM #2
MANINX: MOV $SWR, (R1)-
PC

```

```

870 003462 000000 $LPADR: 0
871
872 ;*****
873 ; ISR PARAM INPUT ROUTINE
874 ;*****
875 003464 012700 011000 GETIT: MOV #VISR, R0 ;PRESET ISR ADDR IN R0
876 003470 104400 007154 TYPE .MSG01 ;<15><12> INTERFACE TYPE
877 003474 104400 011000 TYPE ,VISR ;PRINTOUT ISR NAME
878 003500 104400 001526 TYPE ,QUES
879
880 003504 104404 001544 GETSTR ,WORK ;READIN OPERATOR'S RESPONSE
881 003510 23727 001544 000015 CMPB WORK ,#15 ;IS IT CAR. RET?
882 003516 001431 BEQ GETBA ;BR IF YES
883
884 003520 012700 010160 MOV #DN, R0 ;PRESET DN ISR ADDR
885 003524 023737 010160 001544 CMP DN, WORK ;IS IT DN?
886 003532 001004 BNE DMBTST ;BR IF NO
887 003534 052737 020000 001562 BIS #20000, FLAGS ;SET DN11 FLAG
888 003542 000417 BR GETBA ;GO GET DN11 PARAMS
889
890 003544 012700 010402 DMBTST: MOV #DMB, R0 ;PRESET DM11B ISR
891 003550 023737 010402 001544 CMP DMB, WORK ;IS IT DM?
892 003556 001004 BNE NOISR ;BR IF NO
893 003560 052737 040000 001562 BIS #40000, FLAGS ;SET DM11-B FLAG
894 003566 000405 BR GETBA ;GO GET DM11-B PARAMS
895
896
897 003570 NOISR:
898 003570 104400 007177 TYPE ,MSG02 ;<15><12> ISR NOT LOADED!
899
900 003574 000000 HALT ;HALT
901 003576 000137 003254 JMP BEGIN ;TRY AGAIN
902 003602 010004 GETBA: MOV R0, R4 ;SAVE POINTER
903 003604 022020 CMP (R0)+, (R0)+ ;INCREMENT ISR POINTER
904 003606 104400 007222 TYPE ,MSG03 ;<15><12> BUS ADDRESS=
905 003612 004737 JSR PC,GETANY ;GET THE BUS ADDR
906
907 003616 104400 007241 GETVA: TYPE ,MSG04 ;<15><12> VECTOR ADDRESS=
908 003622 004737 JSR PC,GETANY ;GET THE VECTOR ADDR.
909
910 003626 104400 007263 GETPRI: TYPE ,MSG05 ;<15><12> PRIORITY=
911 003632 004737 JSR PC,GETANY ;GET THE PRIORITY
912
913 003636 005710 GETPRM: TST (R0) ;PARAM #1 REQUIRED?
914 003640 100412 BMI GETP3 ;BR IF NO
915 003642 104400 007277 TYPE ,MSG06 ;<15><12> PARAMS #1=
916 003646 004737 JSR PC,GETANY ;GET PARAM
917
918 003652 005710 TST (R0) ;PARAM #2 REQUIRED?
919 003654 100404 BMI GETP3 ;BR IF NO
920 003656 104400 007314 TYPE ,MSG07 ;<15><12> PARAMS #2=
921 003662 004737 JSR PC,GETANY ;GET PARAM
922
923 003666 016437 000016 003704 GETP3: MOV 16(R4), ARIA ;IS ASCII PARAM REQUIRED
924 003674 100424 BMI GETEX ;BR IF NO
925 003676 104400 007331 TYPE ,MSG08 ;<15><12> ASCII PARAM=
926 003702 104400 TYPE ;PRINTOUT ASCII PARAM

```

```

926 003704 000000          ARIA: 0
927 003706 104400 001526      TYPE      .QUES
928
929 003712 104404          GETSTR          :GET ASCII INPJT AND
930 003714 001604          IBUF           :PUT IT HERE
931 003716 012702 001604      MOV      #IBUF, R2      :SETUP POINTER
932 003722 122712 000015      CMPB     #15, (R2)     :WAS NEW DATA EN(ERED)?
933 003726 001407          BEQ      GETEX        :BR IF NO
934
935 003730 013703 003704      MCV      ARIA, R3      :SETUP DEST. POINTER
936 003734 112223          MCVB     (R2)+, (R3)+  :MOV INPUT TO DEST.
937 003736 122712 000015      CMPB     #15, (R2)     :LAST DIGIT?
938 003742 001374          BNE     -5            :LOOP IF NO
939 003744 105013          CLRB     (R3)        :INSERT ALL ZERO CHAR
940
941
942 003746 020427 011000      GETEX:  CMP      R4, #VISR :WAS THIS THE VARIABLE ISR
943 003752 001461          BEQ     SWPNT        :BR IF YES
944 003754 000137 003464          JMP     GETIT        :GET ANOPHER
945
946          :TTY INTERRUPTS HERE WHEN MODULE IS RJNNING.
947
948 003760 017701 175532      TTYINT: MOV      @TKB,R1      :CLEAR TTY BUFFER
949 003764 042777 000100 175522      BIC     #100,@TKS     :RESET INT. ENABLE
950 003772 042701 177700          BIC     #177700,R1   :STRIP JUNK
951 003776 022701 000007          CMP     #7,R1
952 004002 001013          BNE     2$
953 004004 022737 000176 011044      CMP     #SWREG,SWR
954 004012 001003          BNE     1$
955 004014 052737 000001 011042      BIS     #BIT0,FLAG
956 004022 052777 000100 175454      1$:    BIS     #100,@TKS
957 004030 000002          RTI
958 004032 022701 000077      2$:    CMP     #'?', R1      :IS IT ?
959 004036 001014          BNE     NOQ          :BR IF NO
960 004040 012700 001476          MOV     #DMPNST,R0   :SETUP DUMP LIST
961 004044 012710 001634          MOV     #IBUF, (R0)  :TO PRINTOUT INPUT BUFFER
962 004050 017737 004744 001532      MOV     @IRDA,.RX    :IF SWITCH REG. =0 PRINT RX BUFFER.
963 004056 017737 004740 001534      MOV     @IXDA,.TX    : " " " " " " PRINT TX BUFFER.
964 004064 000137 001374          JMP     LI           :AND GO PRINT IT
965
966 004070 022701 000012      NOQ:   CMP     #12, R1   :IS IT LINE FEED?
967 004074 001002          BNE     RSTART      :BR IF NO
968 004076 000137 003254          JMP     BEGIN        :RESTART
969
970 004102 104400 010155      RSTART: TYPE     ,MFILL
971 004106 000005          RESET
972 004110 105227 000000          INCB     #0          :DELAY HERE FOR AWILE
973 004114 001375          BNE     -4
974 004116 022737 000176 011044      SWFRNT: CMP     #SWREG,SWR
975 004124 001007          BNE     XSWPNT
976 004126 052737 000002 011042      BIS     #BIT1,FLAG
977 004134 104400 007350          TYPE     ,MSG09
978 004140 104422          SETSWI
979 004142 000417          BR      REST
980 004144 104400 007350      XSWPNT: TYPE     ,MSG09      :#15,#12 SET SWITCHES
981 004150 105777 175340          *STB     @TKS      :WAIT FOR TTY INPUT

```



```

982 004154 100375          BPL      -4          ;LOOP
983 004156 017702 175334    MOV      @TKB,R2     ;RESET DONE FLAG
984 004162 017746 004656    MOV      @SWR, -(SP)
985 004166 004037 006350    JSR      R0,$B2016  ;PRINTOUT SWITCHES
986 004172 104400 001536    TYPE    .CALF
987 004176 000401          BR       .+4        ;SKIP OVER HALT
988
989 *****
990 SET SWITCH OPTIONS
991 *****
992 004200 000000          SWRSET: HALT        ;HALT FOR SWITCH SETUP
993                                     ;SW00=ONE WAY OUT
994                                     ;SW01=ONE WAY IN
995                                     ;SW02=EXTERNAL LOOPBACK
996                                     ;SW03=INTERNAL LOOPBACK
997                                     ;SW04=LOOP ON DATA
998                                     ;SW05=MONITOR INPUT
999                                     ;SW06=MONITOR OUTPUT
1000                                    ;SW07=NO DATA COMPARE
1001                                    ;SW08=EXTERNAL DATA
1002                                    ;SW09=DATA SELECT
1003                                    ;SW10=DATA SELECT
1004                                    ;SW11=DATA SELECT
1005                                    ;SW12=
1006                                    ;SW13=INHIBIT ERROR TYPECJTS
1007                                    ;SW14=LOOP ON TEST
1008                                    ;SW15=HALT ON ERROR
1009
1010 004202 012737 004210 003462 REST:  MOV    #RESTR,$LPADR ;SETUP LOOP
1011 004210 017701 004630 REST:  MOV    @SWR,R1
1012 004214 000301          SWAB    R1
1013 004216 032777 000017 004620    BIT     #17,@SWR    ;WAS SOME MODE SELECTED?
1014 004224 001003          BNE    .+10        ;BR IF YES
1015 004226 104400 007637          TYPE    MSG2'      ;<15><12>NO MODE SELECTED.
1016 004232 000723          BR     RSTART     ;GO GET SWITCH REGISTER.
1017 004234 042701 177761    BIC    #177761,R1  ;STRIP JUNK
1018 004240 016137 001564 011022    MOV    DAT(1),IXDA ;SETUP INIT DATA ADDR FROM TABLE
1019 004246 005701          TST    R1         ;VARIABLE DATA SPECIFIED?
1020 004250 001010          BNE    SUXCC      ;BR IF NO
1021 004252 032777 000400 004564    BIT     #400,@SWR  ;USE EXTERNAL DATA?
1022 004260 001004          BNE    SUXCC      ;BR IF YES
1023 *****
1024 GET VARIABLE DATA
1025 *****
1026 004262 104400 007372          TYPE    ,MSG10     ;<15><12> ENTER DATA \15\<12>
1027 004266 104404          GETSTR          ;GET DATA
1028 004270 002604          VDB           ;AND PUT IT HERE
1029 004272 012737 001604 011020 SUXCC: MOV    #IBUF,IRDA ;SETUP READ BUFFER ADDR
1030
1031 004300 032777 000400 004536    BIT     #400,@SWR  ;EXTERNAL DATA?
1032 004306 001403          BEG    SWRNXT     ;BR IF NO
1033 004310 012737 002604 011022    MOV    #VDB,IXDA  ;SETUP BUFFER ADDRESS
1034 004316          SWFNXT:
1035 004316 012737 003760 000060    MOV    #TTYINT,@#60 ;SETUP TTY VECTOR
1036 004324 012737 000340 000062    MOV    #340,@#62
1037 004332 012777 000100 175154    MOV    #100,@TKS  ;AND ENABLE INTERRUPTS

```

1038 004340 012702 001604  
1039 004344 005022  
1040 004346 022702 002004  
1041 004352 001374

CLRIB: MOV #IBUF, R2  
CLR (R2)+ ;CLEAR INPUT BUFFER  
CMP #IBUF+200,R2  
BNE CLRIB

```

1042 ;*****
1043 ;          SETUP TIMER          *
1044 ;*****
1045
1046 004354 012737 000060 006334 SUTIME: MOV      #60,      MSECS ;PRESET COUNTER
1047 004362 012737 006312 000100      MOV      #TIMER, 100 ;SETUP LINE CLOCK VECTOR
1048 004370 012737 000340 000102      MOV      #340,   102 ;AND PRIORITY
1049 004376 012737 004422 000004      MOV      #NOLC,  4 ;SETUP BUS ERROR VECTOR
1050 004404 012737 000340 000006      MOV      #340,   6 ;SET UP PRIORITY TO 7
1051 004412 052737 000100 177546      BIS      #100,   177546 ;ENABLE LINE CLOCK
1052 004420 000441
1053
1054 ;BUS ERROR RETURNS HERE IF NO LINE CLOCK
1055
1056 004422 012737 006312 000104 NOLC:  MOV      #TIMER, 104 ;SETUP RTC VECTOR
1057 004430 012737 000340 000106      MOV      #340,   106 ;AND PRIORITY
1058 004436 012737 004472 000004      MOV      #1$,    4 ;SETUP BUS ERROR VECTOR
1059 004444 012737 000340 000006      MOV      #340,   6 ;SET PRIORITY
1060 004452 012737 003100 172542      MOV      #1600., 172542 ;SET COUNTER BUFFER.
1061 004460 012737 000111 172540      MOV      #111,   172540 ;ENABLE REAL TIME TIME CLOCK
1062 004466 000240
1063 004470 000415
1064 004472 012737 004516 000100 1$:    MOV      #2$, 100 ;CONTINUE.
1065 004500 104414 000000      STPS,PRTYO ;TRY LSI CLOCK
1066 004504 005227 000000      3$:    INC      #0 ;LOWER PSW TO 0
1067 004510 001375
1068 004512 104400 007570
1069 004516 012737 006012 000100 2$:    TYPE,MSG19 ;NO CLOCK AVAILABLE
1070
1071 004524 000137 004530 NORTC: JMP      .+4 ;SPARE JUMP
1072 004530 012737 000006 000004      MOV      #6, 2#4 ;SET TRAP VECTOR
1073 004536 005037 000006      CLR      2#6 ;SET BUS ERROR VECTOR
1074 004542 012706 001070      MOV      #STACK, SP ;SETUP STACK
1075 004546 104414 000000      STPS,PRTYO
1076 004552 012737 006350 011030      MOV      #B2016,B2016 ;SETUP BIN TO OCT ADDR
1077
1078
1079 ;*****
1080 ;          DO TESTING NOW          *
1081 ;*****
1082 004560 032737 020000 001562      BIT      #20000, FLAGS ;WAS A DN11 SETUP
1083 004566 001402      BEQ      DMCHK ;BR IF NO
1084 004570 004737 010200      JSR      PC,DNGO ;GO TO DN11 ISR
1085
1086 004574 032737 040000 001562 DMCHK: BIT      #40000, FLAGS ;WAS A DM11-B SETUP?
1087 004602 001402      BEQ      VIGO ;BR IF NO
1088 004604 004737 010422      JSR      PC,DMGO ;GO TO DM11-B ISR
1089
1090 ;*****
1091 ;          GOTO THE MODULE AND RUN          *
1092 ;*****
1093
1094 004610 004777 004222      VIGO:  JSR      PC,2ISR+36 ;GO TO ISR

```

```

1095 :*****
1096 :      END OF PASS ROUTINE
1097 :*****
1098 004614 005237 004774 EOP:  INC  $PASS      ;INCREMENT PASS COUNTER
1099 004620 005746      TST  -(SP)      ;PUSH DOWN AND PROTECT STACK.
1100 004622 104416      KBDIN
1101 004624 032777 010000 004212 BIT  #SW12,DSWR  ;INHIBIT TYPEOUTS?
1102 004632 001034      BNE  2$        ;BR IF YES
1103 004634 104400 007411      TYPE  MSG11     ; 5<<12> END OF PASS
1104 004640 013746 004774      MOV  $PASS, -(SP)
1105 004644 004037 006350      JSR  RD,$B2016  ;PRINTOUT PASS COUNT
1106 004650 104400 001536      TYPE  CRLF
1107 004654 032700 000002      BIT  #OWI.MODE  ;SKIP TRANSMIT TYPEOUT IF OWI
1108 004660 001012      BNE  3$        ;BR IF YES
1109 004662 104400 010060      TYPE  MSG26     ;TRANSMITTED DATA=
1110 004666 013737 011022 004676 MOV  IXDA,4$    ;SET POINTER TO TXBUF
1111 004674 104400      TYPE          ;TYPE TXBUFFER
1112 004676 000000      4$:  0
1113 004700 032700 000001      BIT  #OWO.MODE  ;SKIP RECEIVE TYPEOUT IF OWO
1114 004704 001007      BNE  2$        ;BR IF YES
1115 004706 104400 010106      3$:  TYPE  MSG27     ;RECEIVED DATA=
1116 004712 013737 011020 004722 MOV  IRDA,5$    ;SET POINTER TO RXBUF
1117 004720 104400      TYPE          ;TYPE RXBUFFER
1118 004722 000000      5$:  0
1119 004724 032777 040000 004112 2$:  BIT  #BIT14,DSWR ;LOOP ON TEST?
1120 004732 001005      BNE  1$        ;BR IF NO...
1121 004734 016600 000002      MOV  2(SP),RO  ;GET RETURN ADDRESS
1122 004740 104414 000000      STPS,PRTYD
1123 004744 000110      JMP  (RO)       ;GO BACK TO MODULE.
1124 004746 012706 001070      1$:  MOV  #STACK,SP ;RESET THE STACK POINTER.
1125 004752 013700 000042      MOV  D#42, RO  ;GET MONITOR ADDRESS
1126 004756 001404      BEQ  $DCAGN    ;BR IF NONE
1127 004760 004710      JSR  PC,(RO)   ;GO TO MONITOR
1128 004762 000240      NOP
1129 004764 000240      NOP           ;SAVE ROOM FOR
1130 004766 000240      NOP           ;ACT-11
1131 004770 000137 000200 $DCAGN: JMP  D#20C    ;RESTART TEST
1132 004774 000000 $PASS:  0
1133
1134
1135 :*****
1136 :      SUBROUTINE TO INPUT OCTAL WORD FROM OPERATOR
1137 :*****
1138 004776 011046 GETANY: MOV  (RO), -(SP) ;PUT WORD ON STACK
1139 005000 004037 006350      JSR  RD,$B2016  ;AND TYPE IT
1140 005004 104400 001526      TYPE  QUES
1141 005010 011037 001544      MOV  (RO),WORK ;PRESET FOR DEFAULT (CR)
1142 005014 104406 001544      ANYMOR: ACCEPT WORK ;OCTAL READIN
1143 005020 013710 001544      MOV  WORK,(RO) ;MOVE IT TO ISR
1144 005024 005720      ANYEX: TST  (RO)+ ;BUMP POINTER
1145 005026 000240      NOP
1146 005030 000207      RTS  PC        ;SUB/ROUTINE EXIT
1147
1148
1149 :*****
1150 :      ERROR HLT HANDLER
1151 :*****

```

```

1151 005032          $HLT:
1152 005032 104414 000140          STPS,PRTY3          ;LOWER PSW PRIOTITY TO 3
1153 005036 005237 005730          $HLOT:  INC      $ERTIL          ;INCREMENT ERROR COUNTER
1154 005042 001775          BEQ      $HLOT          ;MAKE SURE ITS NOT ZERO
1155 005044 011637 005726          MOV      (SP)  , $HLTAD          ;SAVE ADDRESS OF HLT
1156 005050 162737 000002 005726  SUB      #2,    $HLTAD          ;AND BACK IT UP
1157 005056 010146          MOV      R1,    -(SP)          ;SAVE R1
1158
1159 005060 032777 020000 003756  BIT      #BIT13, @SWR          ;INHIBIT ERR TYPEOUTS?
1160 005066 001070          BNE      TRX              ;BR IF YES
1161
1162 005070 104400 001536          TYPE    ,CRLF
1163 005074 117701 000626          MOVVB   @ $HLTAD, R1          ;EXTRACT HLT CODE
1164 005100 006301          ASL     R1              ;AND ALIGN IT
1165 005102 016137 005270 005112  MOV     EMTAB(R1),..+10      ;GET HEADER ADDRESS
1166 005110 104400 005320          TYPE    ,EMO            ;AND PRINT HEADER
1167 005114 104400 007430          TYPE    ,MSG12           ; < AT LOC >
1168 005120 013746 005726          MOV     $HLTAD, -(SP)       ;GET HLT ADDRESS
1169 005124 004037 006350          JSR     R0, $B2016         ;AND PRINT IT
1170 005130 005701          TST     R1              ;HLT CODE = 0?
1171 005132 001446          BEQ     TRX              ;BR IF YES
1172
1173
1174 005134 022701 000016          CMP     #16, R1           ;IS IT HLT+7?
1175 005140 001023          BNE     1$              ;BR IF NO
1176 005142 005702          TST     R2              ;PRINTOUT BAD DATA?
1177 005144 001406          BEQ     2$              ;BR IF NO
1178 005146 104400 007767          TYPE    ,MSG23           ; < BAD DATA= ,
1179 005152 110246          MOVVB   R2, -(SP)        ;GET DATA
1180 005154 004037 006336          JSR     R0, $B20CT        ;AND PRINT IT
1181 005160 003          .BYTE   3
1182 005161 001          .BYTE   1
1183 005162 005703          2$:  TST     R3              ;PRINT OUT GOOD DATA?
1184 005164 001410          BEQ     3$              ;BR IF NO
1185 005166 104400 010003          TYPE    ,MSG24           ; < GOOD DATA= >
1186 005172 110346          MOVVB   R3, -(SP)        ;GET DATA
1187 005174 004037 006336          JSR     R0, $B20CT        ;AND PRINT IT
1188 005200 003          .BYTE   3
1189 005201 001          .BYTE   1
1190 005202 104400 001536          TYPE    ,CRLF
1191 005206 000420          3$:  BR     TRX
1192
1193
1194 005210 005702          1$:  TST     R2              ;PRINTOUT RCV CSR?
1195 005212 001405          BEQ     TR3             ;BR IF NO
1196 005214 104400 007441          TYPE    ,MSG13           ; < RCV CSR=>
1197 005220 010246          MOV     R2, -(SP)        ;GET DATA
1198 005222 004037 006350          JSR     R0, $B2016        ;AND PRINT IT
1199
1200 005226 005703          TR3: TST     R3              ;PRINTOUT XMIT CSR?
1201 005230 001407          BEQ     TRX             ;BR IF NO
1202 005232 104400 007453          TYPE    ,MSG14           ; < XMIT CSR=>
1203 005236 010346          MOV     R3, -(SP)        ;GET DATA
1204 005240 004037 006350          JSR     R0, $B2016        ;AND PRINT IT
1205 005244 104400 001536          TYPE    ,CRLF
1206

```

```

1207 005250 032777 100000 003566 TRX: BIT #BIT15, @SWR :HALT ON ERROR?
1208 005256 001401 BEQ HLTX ;BR IF NO
1209 005260 000000 HALT
1210
1211 005262 104416 HLTX: KBDIN
1212 005264 012601 MOV (SP)+, R1 :RESTORE R1
1213 005266 000002 RTI :AND RETURN TO PROGRAM
1214
1215 005270 005320 EMTAB: EMO
1216 005272 005333 EM1
1217 005274 005343 EM2
1218 005276 005363 EM3
1219 005300 005407 EM4
1220 005302 005422 EM5
1221 005304 005446 EM6
1222 005306 005542 EM7
1223 005310 005565 EM10
1224 005312 005642 EM11
1225 005314 005667 EM12
1226 005316 005711 EM13
1227

```

```

005320 051105 047522 020122 EMO: .ASCIZ "ERROR HALT"
005333 127 044501 044524 EM1: .ASCIZ "WAITING"
005343 127 044501 044524 EM2: .ASCIZ "WAITING TO XMIT"
005363 104 026516 030461 EM3: .ASCIZ "DN-11 NOT AVAILABLE"
005407 104 030516 026461 EM4: .ASCIZ "DN11-ERROR"
005422 047104 030461 041440 EM5: .ASCIZ "DN11 CALL ABANDONED"
005446 041522 020126 052502 EM6: .ASCIZ "RCV BUFFER FULL, END OF MESSAGE CHARACTER(CO1) WAS NOT FOUND"
005542 040504 040524 041440 EM7: .ASCIZ "DATA COMPARE ERROR"
005565 105 051122 051117 EM10: .ASCIZ "ERROR RCV CSR=CONTENTS OF SELECT 0 REGISTER"
005642 047125 054105 042520 EM11: .ASCIZ "UNEXPECTED INTERRUPT"
005667 116 046530 050040 EM12: .ASCIZ "NXM PRINCIPAL CAR"
005711 116 046530 040440 EM13: .ASCIZ "NXM ALT CAR"
005726 005726 .EVEN
1228 005726 000000 $HLTAD: 0
005730 000000 $ERTTL: 0

```

```

1229 :*****
1230 : READ A CHAR. ROUTINE
1231 :*****
1232 :
1233 : CALL= GETCHR ;INPUT A CHAR FROM TTY
1234 : RETURNS HERE WITH CHAR ON STACK
1235 005732 011646 $READC: MOV (SP),-(SP) ;PUSH THE PC
1236 005734 016666 MOV 4(SP),2(SP) ;SAVE THE PS
1237 005742 105777 TSTB @TKS ;IS RECEIVE DONE
1238 005746 100375 BPL -4 ;LOOP IF NO
1239 005750 017737 173542 001542 MOV @TKB,$CHAR ;SAVE THE CHAR.
1240 005756 042737 177600 001542 BIC #177600,$CHAR ;STRIP JUNK
1241 005764 013766 001542 000004 MOV $CHAR,4(SP) ;PUT CHAR ON STACK
1242 005772 000002 RTI ;EXIT
1243 :*****
1244 : READ A STRING ROUTINE
1245 :*****
1246 :
1247 : CALL= GETSTR ;INPUT A STRING OF CHARS FROM TTY
1248 : ADDR ;TO THIS ADDRESS
1249 : TERMINATE INPUT WITH LINE FEED
1250 005774 011602 $READS: MOV (SP), R2 ;SETUP ADDRESS OF INPUT BUFFER
1251 005776 012201 MOV (R2)+, R1 ;INCREMENT RETURN ADDRESS
1252 006000 010216 MOV R2,(SP) ;AND PUT BACK ON STACK
1253 :
1254 : GETIC: GETCHR ;GET A CHAR
1255 006004 104400 TYPE,$CHAR
1256 006010 122726 000136 CMPB #136,(SP)+ ;IS IT BINARY DELIMITER
1257 006014 001011 BNE GOTIC ;BR IF NO
1258 :
1259 : OCT: ACCEPT $WORK ;GET OCT. CHAR
1260 006022 113721 001544 MOVB $WORK,(R1)+ ;STORE OCT. CHAR.
1261 006026 122737 000136 001542 CMPB #136,$CHAR ;TERMINATOR=BIN. DELIMITER?
1262 006034 001370 BNE OCT ;BR IF NO
1263 006036 000761 BR GETIC
1264 :
1265 : GOTIC: MOVB $CHAR,(R1)+ ;STORE CHAR. IN BUFFER
1266 006044 022737 000015 001542 CMP #15,$CHAR ;IS IT END OF INPUT (CAR. RETURN)?
1267 006052 001353 BNE GETIC ;BR IF NO
1268 006054 112721 000012 MOVB #12,(R1)+
1269 006060 104400 001537 TYPE,LF ;TYPE A LINE FEED
1270 006064 112721 000001 MOVB #001,(R1)+ ;INSERT RX TERM.
1271 006070 112721 000177 MOVB #177,(R1)+ ;AND A FILL
1272 006074 112721 000177 MOVB #177,(R1)+ ;INSERT ANOTHER FILL
1273 006100 112721 000177 MOVB #177,(R1)+ ;INSERT 3RD FILL
1274 006104 112721 000177 MOVB #177,(R1)+ ;INSERT 4TH FILL
1275 006110 105011 CLRB (R1) ;PUT ZEROS AT END
1276 006112 000002 RTI

```

```

1278  :*****
1279  :ROUTINE TO ACCEPT AN OCTAL NUMBER FROM THE TTY
1280  :CALL:
1281  :
1282  :      ACCEPT  .ADDR      :PUT OCTAL NUMBER IN ADDR
1283  :
1284  $ACCEPT:
1285  MOV        R0,-(SP)      :SAVE R0
1286  MOV        R1,-(SP)      :SAVE R1
1287  MOV        R2,-(SP)      :SAVE R2
1288  MOV        R3,-(SP)      :SAVE R3
1289  MOV        10(SP),R0     :GET ADDRESS OF WHERE TO PUT NUMBER
1290  1$:  CLR        R1        :CLEAR PARTIAL NUMBER
1291  MOV        #6,R2        :MAX. # OF DIGITS ALLOWED
1292  2$:  GETCHR       :GET ONE CHARACTER
1293  MOVB      (SP)+,R3     :AND PUT IT IN R3
1294  MOVB      R3,6$       :
1295  TYPE      .6$        :ECHO THE CHARACTER
1296  CMP        #25,R3     :
1297  BEQ        8$         :
1298  CMF        #15,R3     :WAS THIS CHARACTER A "CR"?
1299  BEQ        5$         :BR IF YES
1300  CMP        #40,R3     :WAS "SPACE" HIT?
1301  BEQ        7$         :BR IF YES
1302  CMP        #136,R3    :WAS "!" HIT?
1303  BEQ        7$         :BR IF YES
1304  BIT        #110,R3    :INSURE THE CHARACTER IS
1305  BNE        4$         :A DIGIT BETWEEN 0 AND 7.
1306  :
1307  DEC        R2        :CHECK NUMBER OF CHARACTERS
1308  BLT        4$         :BR IF TO MANY
1309  ASL        R1        :POSITION PARTIAL NUMBER
1310  ASL        R1        :FOR THIS DIGIT
1311  BIC        #10<7>,R3 :GET RID OF THE ASCII JUNK
1312  BIC        R3,R1     :COMBINE THIS DIGIT WITH PARTIAL
1313  BR        2$         :GO GET ANOTHER DIGIT
1314  4$:  TYPE      .QUES   :TYPE "?"
1315  TYPE      .CRLF     :TYPE CARRAGE RETURN AND LINE FEED.
1316  BR        1$         :GO START OVER
1317  5$:  TYPE      .LF     :FOLLOW "CR" WITH A "LF"
1318  CMP        #6,R2     :WERE ANY DIGITS INPUT
1319  BNE        +6        :BR IF YES
1320  MOV        6(R0)+,R1  :USE OLD DATA
1321  RST        -(R0)     :BACKUP R0--
1322  7$:  MOV        R1,6(R0)+ :PASS THE NUMBER TO THE USER
1323  MOV        R0,10(SP)  ;SET FOR RETURN
1324  MOV        (SP)+,R3   :RESTORE R3
1325  MOV        (SP)+,R2   :RESTORE R2
1326  MOV        (SP)+,R1   :RESTORE R1
1327  MOV        (SP)+,R0   :RESTORE R0
1328  RTI
1329  8$:  TYPE      .OCTAL  :
1330  BR        1$         :
1331  9$:  .BYTE    0,0      :STORAGE FOR ASCII CHAR. AND TERMINATOR

```



1233  
1234  
1235  
1236  
1237  
1238  
1239  
1240  
1241  
1242  
1243  
1244  
1245  
1246  
1247  
1248  
1249  
1250  
1251  
1252  
1253  
1254  
1255  
1256  
1257  
1258  
1259  
1260  
1261  
1262  
1263  
1264  
1265  
1266  
1267  
1268  
1269  
1270  
1271  
1272  
1273  
1274  
1275  
1276  
1277  
1278  
1279  
1280  
1281  
1282  
1283  
1284  
1285  
1286  
1287  
1288  
1289  
1290

006312 005337 006334  
006316 001005  
006320 012737 000060 006334  
006326 005237 011032  
006332 000002  
006334 000000  
  
006336 112037 006543  
006342 112037 006541  
006346 000406  
006350 112737 000001 006541  
006356 112737 000006 006543  
006364 112737 000005 006540  
006372 010346  
006374 010446  
006376 010546  
006400 113704 006543  
006404 005404  
006406 062704 000006  
006412 110437 006542  
006416 113704 006541  
006422 016605 000010  
006426 005003  
006430 006105  
006432 000404  
006434 006105  
006436 006105  
006440 006105  
006442 010503  
006444 006103  
006446 105237 006542  
006448 100016

```
*****  
: CLOCK INTERRUPT ROUTINE  
*****  
TIMER: DEC MSECS :COUNT 60 CYCLES  
: BNE TIMEX :BR IF NOT 60  
MOV #60 MSECS :RESTORE COUNT  
INC TIME :INCREMENT SECONDS  
TIMEX: RTI :RETURN FROM INTERRUPT  
MSECS: 0  
*****  
: BINARY TO OCTAL (ASCII) AND TYPE  
: $B200T---ENTER HERE TO SETUP SUPPRESS ZEROS AND NUMBER OF DIGITS TO TYPE  
: CALL:  
: MOV NUM, -(SP) :NUMBER TO BE TYPED  
: JSR RO, $B200T :CALL FOR TYPEOUT  
: .BYTE N :N=1 TO 6 FOR NUMBER OF DIGITS TO TYPE  
: .BYTE M :M=1 OR 0  
: : :L=TYPE LEADING ZEROS  
: : :0=SUPPRESS LEADING ZEROS  
  
: $B201---ENTER HERE TO TYPE OUT WITH THE SAME PARAMETERS AS THE LAST $B200T OR $B2016  
: CALL:  
: MOV NUM, -(SP)  
: JSR RO, $B201  
  
: $B2016---ENTER HERE FOR TYPEOUT OF A 16 BIT NUMBER  
: CALL:  
: MOV NUM, -(SP)  
: JSR RO, $B2016  
  
$B200T: MOVB (R0)+, $OMODE+1 :PICKUP THE NUMBER OF DIGITS TO TYPE  
MOVB (R0)+, $OFILL :GET THE ZERO FILL SWITCH  
BR $B201  
$B2016: MOVB #1, $OFILL :SET THE ZERO FILL SWITCH  
MOVB #6, $OMODE+1 :SET FOR SIX(6) DIGITS  
$B201: MOVB #5, $OCNT :SET THE ITERATION COUNT  
MOV R3, -(SP) :SAVE R3  
MOV R4, -(SP) :SAVE R4  
MOV R5, -(SP) :SAVE R5  
MOVB $OMODE+1, R4 :GET THE NUMBER OF DIGITS TO TYPE  
NEG R4  
ADD #6, R4 :SUBTRACT IT FOR MAX. ALLOWED  
MOVB R4, $OMODE :SAVE IT FOR USE  
MOVB $OFILL, R4 :GET THE ZERO FILL SWITCH  
MOV 10(SP), R5 :PICKUP THE INPUT NUMBER  
CLR R3 :CLEAR THE OUTPUT WORD  
16: ROL R5 :ROTATE MSB INTO "0"  
BR $B201 :GO DO MSB  
28: ROL R5 :FORM THIS DIGIT  
R5  
R5  
R5  
R5, R3  
38: ROL R5 :GET LSB OF THIS DIGIT  
DECB $OMODE :TYPE THIS DIGIT  
BR $B201
```

```

1388 006454 042703 177770      BIC      #177770,R3      :GET RID OF JUNK
1389 006460 001002      BNE      4$            :TEST FOR 0
1390 006462 005704      TST      R4            :SUPPRESS THIS 0?
1391 006464 001403      BEQ      5$            :BR IF YES
1392 006466 005204      4$: INC      R4            :DON'T SUPPRESS ANYMORE 0'S
1393 006470 052703 000060      BIS      #'0,R3        :MAKE THIS DIGIT ASCII
1394 006474 052703 000040      5$: BIS      #' ,R3        :MAKE ASCII IF NOT ALREADY
1395 006500 110337 006536      MOVB     R3,6$         :SAVE FOR TYPING
1396 006504 104400 006536      TYPE    6$            :GO TYPE THIS DIGIT
1397 006510 105337 00654C      7$: DECB    $OCNT        :COUNT BY 1
1398 006514 003347      BGT      2$            :BR IF MORE TO DO
1399 006516 002402      BLT      6$            :BR IF DONE
1400 006520 005204      INC      R4            :INSURE LAST DIGIT ISN'T A BLANK
1401 006522 000744      BR       2$            :GO DO THE LAST DIGIT
1402 006524 012605      8$: MOV     (SP)+,R5      :RESTORE R5
1403 006526 012604      MOV     (SP)+,R4        :RESTORE R4
1404 006530 012603      MOV     (SP)+,R3        :RESTORE R3
1405 006532 012616      MOV     (SP)+,(SP)      :SET THE STACK FOR RETURNING
1406 006534 000200      RTS     R0              :RETURN
1407 006536      000      9$: .BYTE    00          :STORAGE FOR ASCII DIGIT
1408 006537      000      .BYTE    00          :TERMINATOR FOR TYPE ROUTINE
1409 006540      000      $OCNT: .BYTE    00          :OCTAL DIGIT COUNTER
1410 006541      000      $OFILL: .BYTE    0           :ZERO FILL SWITCH
1411 006542 000000      $CMODE: 0              :NUMBER OF DIGITS TO TYPE

```

```

*****
:TRAP HANDLER
$TRAP: MOV     R0,-(SP)      :SAVE R0
      MOV     2(SP),R0      :GET TRAP ADDRESS
      TST     -(R0)         :BACKUP BY 2
      MOVB   (R0),R0        :GET RIGHT BYTE OF TRAP
      MOV     $TRPAD(R0),R0 :INDEX TO TABLE
      RTS     R0            :GO TO ROUTINE

```

```

:TRAP TABLE
:ROUTINE
:-----
006564 001100      $TRPAD: $TYPE
      104400      TYPE=TRAP+0
006566 005732      $READC  GETCHR=TRAP+2
      104402      $READS  GETSTR=TRAP+4
006570 005774      $ACCEPT ACCEPT=TRAP+6
      104404      $RWAIT  RWAIT=TRAP+10
006572 006114      $XWAIT  XWAIT=TRAP+12
      104406      .STPS   STPS=TRAP+14
006574 006610      .KBDIN  KBDIN=TRAP+16
      104410
006576 006620
      104412
006600 007042
      104414
006602 006732
      104416
006604 007064

```

```

1444      104420
1445 006606 006750      .SETSWI      SUSWR=TRAP+20
1446      104422      SETSWI=TRAP+22
1447
1448 ;*****
1449 ;      SPECIAL PRINTOUT ROUTINES
1450 ;*****
1451
1452 006610 104400 007462 $RWAIT: TYPE      ,MSG15      ;<15><12> WAITING AT LOC <SP>
1453 006614 000137 006624      JMP      WAITPO
1454
1455 006620 104400 007505 $XWAIT: TYPE      ,MSG16      ;<15><12> WAITING FOR CLEAR TO SEND AT LOC <SP><SP>
1456
1457 006624 011646      WAITPO: MOV      (SP), -(SP) ;SETUP ADDRESS OF CALL FOR PRINTOUT
1458 006626 004037 006350      JSR      RO,$B2016 ;PRINTOUT ADDRESS
1459
1460 006632 104400 010021      TYPE      ,MSG25      ; <DMBB LINE STATUS REG= >
1461
1462 006636 016646 000004      MOV      4(SP), -(SP) ;MOV CSR TO BOTTOM OF STACK
1463 006642 016666 000004 000006      MOV      4(SP), 6(SP) ;MOVE PSW UP A WORD
1464 006650 016666 000002 003004      MOV      2(SP), 4(SP) ;MOVE PC UP A WORD
1465 006656 012616      MOV      (SP)+, (SP) ;MOVE CSR UP A WORD
1466 006660 004037 006350      JSR      RO,$B2016 ;GO PRINT CSR
1467
1468 006664 104400 007564      TYPE      ,MSG18      ;<.><15><12>
1469 ;GIVE IT LINE FEED
1470
1471 006670 000002      RTI      ;AND RETURN TO CALLER
1472
1473 ;*****
1474 ;POWER DOWN ROUTINE.
1475 ;SINCE INIT IS ISSUED IN A PWR DN/UP SEQUENCE.
1476 ;PROGRAM MUST BE RESTARTED AGAIN.
1477 ;
1478
1479 006672 012737 006704 000024 $PWRDN: MOV      #$PWRUP, @#24
1480 006700 000000      HALT
1481 006702 000776      BR      .-2
1482
1483 ;*****
1484 ;POWER UP ROUTINE.
1485 ;MESSAGE "POWER HAS FAILED..." WILL BE PRINTED OUT.
1486 ;PROGRAM WILL BE RESTARTED.
1487 ;
1488
1489 006704 012737 006672 000024 $PWRUP: MOV      #$PWRDN, @#24
1490 006712 012706 001070      MOV      #STACK, SP
1491 006716 104400 007616      TYPE      ,MSG20 ;<15><12> POWER FAILED..
1492 006722 104414 000000      STPS, PRTY0
1493 006726 000137 000200      JMP      @#200
1494
1495 006732 032737 000001 011042 .KBDIN: BIT      #BIT0, FLAG ;TEST IG FLAG
1496 006740 001437      BEQ      OUT ;NO, EXIT
1497 006742 042777 000100 172544      BIC      #100, @TKS ;CLEAR TTY IE

```

```

1500 006750 104400 010131 .SETSWI:TYPE SWEQ ;TYPE SWR=
1501 006754 017746 002064 MOV @SWR,-(SP) ;SET UP OCTAL TYPEOUT
1502 006760 004037 006350 JSR RD,$B2016 ;DO IT
1503 006764 104400 010141 TYPE NEQ ;TYPE NEW=
1504 006770 017737 002050 001544 MOV @SWR,WORK ;SET UP FOR CR DEFAULT
1505 006776 104406 001544 ACCEPT ,WORK ;GET VALUE
1506 007002 013777 001544 002034 MOV WORK,@SWR ;REPLACE IT
1507 007010 032737 000002 011042 BIT #BIT1,FLAG ;SEE HOW WE GOT HERE
1508 007016 001005 BNE 1$ ;WRONG WAY?
1509 007020 005777 172472 TST @TKB ;CLEAR BUFFER
1510 007024 052777 000100 172462 BIS #100,@TKS ;RESET TTY IE
1511 007032 042737 000003 011042 1$: BIC #BIT0+BIT1,FLAG ;CLEAR FLAG BITS
1512 007040 000002 OUT: RTI ;EXIT
1513
1514 007042 042766 000340 000502 .STPS: BIC #PTY7,2(SP) ;CLEAR OUT PRIORITY BITS
1515 007050 057666 000000 000002 BIS @2(SP),2(SP) ;SET NEW PRIORITY
1516 007056 062716 000002 ADD #2,(SP) ;SETUP EXIT
1517 007062 000002 RTI ;EXIT
1518
1519 007064 013746 000006 .SUSWR: MOV 6,-(SP) ;SAVE 6 ON STACK
1520 007070 013746 000004 MOV 4,-(SP) ;SAVE 4 ON STACK
1521 007074 012737 007122 000004 MOV #1$,4 ;SETUP TIMEOUT
1522 007102 012737 000340 000306 MOV #340,6 ;SET PRIORITY
1523 007110 022777 177777 001726 CMP #-1,@SWR ;TEST FOR 177570
1524 007116 001402 BEQ 2$ ;NOT ALL 1'S
1525 007120 000407 BR 3$ ;IT'S THERE - EXIT
1526 007122 022626 1$: CMP (SP)+,(SP)+ ;ADJUST STACK AFTER TRAP
1527 007124 012737 000176 011044 2$: MOV #SWREG,SWR ;REPLACE HARDWARE REGISTERS
1528 007132 012737 000174 011046 MOV #DISPREG,DISPLAY ;WITH SOFTWARE REGISTERS
1529 007140 012637 000004 3$: MOV (SP)+,4 ;RESTORE 4
1530 007144 012637 000006 MOV (SP)+,6 ;RESTORE 6
1531 007150 000002 RTI ;EXIT
    
```

1533  
1532  
1531  
1530  
1529  
1528  
1527  
1526  
1525  
1524  
1523  
1522  
1521  
1520  
1519  
1518  
1517  
1516  
1515  
1514  
1513  
1512  
1511  
1510  
1509  
1508  
1507  
1506  
1505  
1504  
1503  
1502  
1501  
1500

\*\*\*\*\*  
: AREA RESERVED FOR MOST ASCIZ MESSAGES.  
:\*\*\*\*\*

007152	000040			MSG00:	.ASCIZ	//
007154	005015	047111	042524	MSG01:	.ASCIZ	<15><12>/INTERFACE TYPE /
007177	015	044412	051123	MSG02:	.ASCIZ	<15><12>/ISR NOT LOADED!!/
007222	005015	052502	020123	MSG03:	.ASCIZ	<15><12>/BUS ADDRESS=/
007241	015	053012	041505	MSG04:	.ASCIZ	<15><12>/VECTOR ADDRESS=/
007263	015	050012	044522	MSG05:	.ASCIZ	<15><12>/PRIORITY=/
007277	015	050012	051101	MSG06:	.ASCIZ	<15><12>/PARAMS #1=/
007314	005015	040520	040522	MSG07:	.ASCIZ	<15><12>/PARAMS #2=/
007331	015	040412	041523	MSG08:	.ASCIZ	<15><12>/ASCII PARAM=/
007350	005015	042523	020124	MSG09:	.ASCIZ	<15><12>/SET SWITCHES.../
007372	005015	047105	042524	MSG10:	.ASCIZ	<15><12>/ENTER DATA/<15><12>
007411	015	042412	042116	MSG11:	.ASCIZ	<15><12>/END OF PASS /
007430	040440	020124	047514	MSG12:	.ASCIZ	/ AT LOC /
007441	040	041522	020126	MSG13:	.ASCIZ	/ RCV CSR=/
007453	040	041530	051123	MSG14:	.ASCIZ	/ XCSR=/
007462	005015	053440	044501	MSG15:	.ASCIZ	<15><12>/ WAITING AT LOC /
007505	015	053412	044501	MSG16:	.ASCIZ	<15><12>/WAITING FOR CLEAR TO SEND AT LOC
007551	040	020041	041440	MSG17:	.ASCIZ	/ ! CSR= /
007564	006456	000012		MSG18:	.ASCIZ	./.<15><12>
007570	005015	047516	041440	MSG19:	.ASCIZ	<15><12>/NO CLOCKS AVAILABLE/
007616	005015	047520	042527	MSG20:	.ASCIZ	<15><12>/POWER FAILED.../
007637	015	047012	020117	MSG21:	.ASCIZ	<15><12>/NO MODE SELECTED./
007663	015	044412	020106	MSG22:	.ASCII	<15><12>/IF CALLING, DIAL NUMBER/
007713	015	044412	020106		.ASCIZ	<15><12>/IF ANSWERING, PLACE MODEM IN AUTO-ANSWER/<15><12>
007767	073	041040	042101	MSG23:	.ASCIZ	/; BAD DATA=/
010003	040	020040	047507	MSG24:	.ASCIZ	/ GOOD DATA=/
010021	015	020012	046504	MSG25:	.ASCIZ	<15><12>/ DMBB LINE STATUS REGISTER= /
010060	005015	051124	047101	MSG26:	.ASCIZ	<15><12>/TRANSMITTED DATA=/'15'<12>
010106	005015	042522	042503	MSG27:	.ASCIZ	<15><12>/RECEIVED DATA=/'15'<12>
010131	015	051412	051127	SWEQ:	.ASCIZ	<15><12>/SWR= /
010141	040	042516	036527	NEQ:	.ASCIZ	/ NEW= /
010150	052536	005015	000	CTLL:	.ASCIZ	/!U/<15><12>
010155	177	000177		MFILL:	.ASCIZ	<177><177>

.EVEN

```

(1)
1541
1542
1543 010160 047104 000040
1544 010164 175200
1545 010166 000350
1546 010170 000200
1547 010172 177777
1548 010174 177777
1549 010176 010356
1550
1551
1552
1553
1554
1555
1556
1557
1558
1559
1560
1561
1562
1563
1564
1565
1566
1567
1568
1569
1570
1571
1572
1573
1574
1575
1576
1577
1578
1579
1580
1581
1582
1583
1584
1585
1586
1587
1588
1589
1590
1591
1592
1593
1594
1595
1596
1597
1598
1599
1600

```

```

:*****
: DN-11 INTERFACE SERVICE PARAMS
:*****
DN: .ASCIZ "DN "
DNBA: 175200 ;BUS ADDRESS
DNIV: 350 ;INTERRUPT VECTOR
DNPRI: 200 ;PRIORITY
DNPAR1: 177777 ;NOT USED
DNPAR2: 177777 ;NOT USED
DNPAR3: DIALNO ;ADDRESS OF DIAL *

```

```

PWI=100000 ;POWER INDICATOR
ACR=40000 ;ABANDON CALL AND RETRY
DLO=10000 ;DATA LINE OCCUPIED
DSS=40 ;DATA SET STATUS
PND=20 ;PRESENT NEXT DIGIT
DP=2 ;DIGIT PRESENT
CRQ=1 ;CALL REQUEST

```

```

1561 ;*****
1562 ; START OF DN-11 CODE
1563 ;*****
1564 010200 013704 010164 DNGO: MOV DNBA, R4 ;SETUP BUS ADDR
1565 010204 005014 CLR (R4) ;RESET DN-11
1566 010206 005037 011032 CLR TIME ;RESET TIMER
1567 010212 032737 000002 011032 BIT #2, TIME ;AND WAIT 2 SECS
1568 010220 001774 BEQ #-6
1569 010222 012703 010356 MOV #DIALNO, R3 ;SETUP DIAL # ADDRESS
1570 010226 012714 000001 MOV #CRQ, @CSR ;SET CALL REQUEST
1571 010232 032714 100000 BIT #PWI, @CSR ;IS DN AVAILABLE
1572 010236 001425 BEQ DNL1X ;BR IF YES
1573
1574 010240 011402 MOV @CSR, R2 ;SETUP CSR FOR PRINTOUT
1575 010242 005003 CLR R3
1576 010244 104003 HLT+3 ;PRINTOUT "DN NOT AVAILABLE"
1577 010246 000137 010200 JMP DNGO ;RESTART
1578
1579 010252 032714 000200 DNL1: BIT #DONE, @CSR ;IS DONE FLAG SET?
1580 010256 001775 BEQ DNL1 ;WAIT IF NO
1581 010260 042714 000200 BIC #DONE, @CSR ;RESET DONE
1582 010264 032714 140000 BIT #ACR+PWI, @CSR ;ANY ERRORS?
1583 010270 001003 BNE DNL1E ;BR IF YES
1584
1585
1586 010272 032714 000020 BIT #PNC, @CSR ;IS PRESENT NEXT DIGIT SET?
1587 010276 001005 BNE DNL1X ;BR IF YES
1588
1589 010300 011402 DNL1E: MOV @CSR, R2 ;SETUP CSR FOR PRINTOUT
1590 010302 005003 CLR R3
1591 010304 104004 HLT+4 ;PRINTOUT "DN ERROR"
1592 010306 000137 010200 JMP DNGO ;RESTART
1593
1594 010312 112364 DNL1X: MOVB (R3)+, 1(R4) ;LOAD NEXT DIGIT
1595 010316 052714 000002 BIS #DP, @CSR ;SET DIGIT PRESENT
1596 010322 105713 TSTB (R3) ;WAS THAT LAST CHAR?
1597 010324 001352 BNE DNL1 ;BR IF NO
1598
1599 010326 032714 000200 DNL2: BIT #DONE, @CSR ;WAIT FOR DONE FLAG
1600 010332 001775 BEQ DNL2
1601
1602 010334 032714 040000 BIT #ACR, @CSR ;WAS CALL ABANDONED?
1603 010340 001405 BEQ DNEK ;BR IF NO
1604
1605 010342 011402 MOV @CSR, R2 ;SETUP CSR FOR PRINTOUT
1606 010344 005003 CLR R3
1607 010346 104005 HLT+5 ;PRINTOUT "CALL ABANDONED"
1608 010350 000137 010200 JMP DNGO ;RESTART
1609
1610 010354 000207 DNEK: RTS PC ;RETURN TO ITEMP
1611
1612 010356 034470 032467 031460 DIALNO: .ASCIZ "8975030" ;NUMBER TO DIAL
1613 010364 000060
1614 010366 000000 000000 000000 0,0,0,0,0,0
1615 010374 000000 000000 000000

```

1616  
 1617  
 1618  
 1619  
 1620  
 1621 010402 046504 000102  
 1622 010406 170500  
 1623 010410 000310  
 1624 010412 000200  
 1625 010414 000000  
 1626 010416 177777  
 1627 010420 177777  
 1628  
 1629  
 1630  
 1631  
 1632  
 1633  
 1634  
 1635  
 1636  
 1637

```

:*****
:      DM11-B INTERFACE SERVICE PARAMS
:*****
DMB:      .ASCIZ  'DMB'      :ISR NAME
MBA:      170500             :BUS ADDRESS
IV:       310               :VECTOR ADDRESS
PRIO:     200               :PRIORITY
PARA1:    0                 :PARAM #1
PARA2:    177777           :PARAM #2
PARA3:    177777           :PARAM #3

```



```

1638 :*****
1639 : DM-11B INTERFACE SERVICE ROUTINE
1640 :*****
1641 010422 000240 DMBGO: NOP
1642 010424 013704 010406 MOV MBA R4 ;SETUP BUS ADDR INDEX
1643 010430 005037 011032 CLR TIME ;RESET TIMER
1644
1645
1646 010434 052714 006000 BIS #CS+CM, @CSR ;CLEAR DM-11 B
1647 010440 032714 000020 BIT #BUSY, @CSR ;WAIT TIL FREE
1648 010444 001375 BNE -4
1649 010446 013714 010414 MOV PARA1, @CSR ;SELECT LINE #
1650 010452 052764 000003 000002 BIS #DTR+LE, 2(R4) ;SET DATA TERM RDY & LINE ENABLE
1651 010460 032737 020000 0015E2 BIT #20000.FLAGS ;HAS DM11 MADE CONNECTION YET?
1652 010466 001002 BNE 1$ ;BR IF YES
1653 010470 104400 007663 TYPE .MSG22 ;TYPE "MAKE CONNECTION"
1654
1655 010474 032777 000005 000342 1$: BIT #OWO+XLB,@SWR ;IS MODE = OWO OR XLB
1656 010502 001444 BEQ REX1 ;BR IF NO
1657
1658
1659 010504 052764 000004 000002 STARTX: BIS #RQTS, 2(R4) ;SET REQUEST TO SEND
1660
1661 010512 032764 000040 000002 CTSW: BIT #CTS, LSTAT(R4) ;IS CLEAR TO SEND SET?
1662 010520 001016 BNE CTSOK ;BR IF YES
1663 010522 023727 011032 000036 CMP TIME, #36 ;30 SECS ELAPSED?
1664 010530 103770 BLO CTSW ;BR IF NO
1665 010532 016446 000002 MOV LSTAT(R4), -(SP) ;TYPE CONTENTS OF RCSR
1666 010536 032777 010000 000300 BIT #SW12,@SWR ;INHIBIT TYPEOUTS?
1667 010544 001001 BNE 1$ ;BR IF YES
1668 010546 104412 XWAIT ;PRINTOUT "WAITING FOR CTS"
1669 010550 005037 011032 1$: CLR TIME ;RESET TIMER
1670 010554 000756 BR CTSW ;WAIT SOME MORE
1671
1672 010556 CTSOK:
1673
1674 010556 012737 177777 011024 REX: MOV #-1, SETTLE ;SET UP DELAY FLAG
1675 010564 005037 010616 CLR TEMP1
1676 010570 012737 000014 010620 MOV #14, TEMP2
1677 010576 062737 000001 010616 ADD #1, TEMP1
1678 010604 001374 BNE -6
1679 010606 005337 010620 DEC TEMP2
1680 010612 001371 BNE -14
1681 010614 000207 REX1: RTS PC ;RETURN TO CONTROL PROGRAM
1682
1683 010616 000000 TEMP1: 0
1684 010620 000000 TEMP2: 0
1685 000001 OWO=1
1686 000002 OWI=2
1687 000004 TLB=4
1688 000004 XLB=4
1689 000010 ILB=10
1690
1691 : RCSR EQUATES
1692 .EQUIV R4, RCSR
1693 .EQUIV R4, CSR

```

```

1694
1695      100000      RI=100000      :RING INDICATOR
1696      000100      CF=100      :CARRIER FLAG
1697      000040      CTS=40      :CLEAR TO SEND
1698      010000      SRD=10000    :SEC. RECEIVE DATA
1699      004000      CS=4000     :CLEAR SCAN
1700      002000      CM=2000     :CLEAR MUX
1701      001000      MM=1000     :MAINT MODE
1702      000400      STEP=400    :STEP
1703      000200      DONE=200    :DONE
1704      000100      IE=100     :INTERRUPT ENABLE
1705      000040      SE=40      :SCAN ENABLE
1706      000020      BUSY=20     :BUST
1707      000017      LINE=17     ;LINE NUMBER
1708
1709      ;LINE STATUS REGGRSTER EQUATES
1710      000002      LSTAT=2
1711
1712      000004      RQTS=4      :REQUEST TO SEND
1713      000002      DTR=2      :DATA TERMINAL READY
1714      000001      LE=1       :LINE ENABLE
1715

```

1716 01100C  
1717  
1718  
1719  
1720  
1721  
1722  
1723  
1724  
1725 011000  
1726 011000 000002  
1727 011004 000001  
1728 011006 000001  
1729 011010 000001  
1730 011012 000001  
1731 011014 000001  
1732 011016 000001  
1733  
1734 011020 000001  
1735 011022 000001  
1736 011024 000001  
1737 011026 000001  
1738 011030 000001  
1739 011032 000001  
1740 011034 000001  
1741 011036 000001  
1742 011040  
1743 011040 000001  
1744 011041  
1745 011041 000001  
1746  
1747 011042 000001  
1748 011044 177570  
1749 011046 177570  
1750 011050 000001  
1751 011052 000001  
1752 011054 000001  
1753 011056 000001  
1754 011060 000001  
1755 011062 000001  
1756 011064 000001  
1757 011066 000001  
1758 011070 000001  
1759 011072 000001  
1760 011074 000001  
1761  
1762 011076 000001  
1763 011080 000001  
1764 011082 000001  
1765 000001

```

.=11000
:*****
: THE INTERFACE SERVICE ROUTINE IS LOADED HERE
:*****
: THE FOLLOWING 18 WORDS ARE USED AS
: THE LINKAGE BETWEEN THE ISR AND THE
: CONTROL PROGRAM.
:
VISR:
ISR: .BLKW 2 :.ASCIZ "DXX"
BA: .BLKW 1 :.175610 :BUS ADDRESS
VA: .BLKW 1 :.300 :VECTOR ADDRESS
PRIOR: .BLKW 1 :.340 :PRIORITY
PARAM1: .BLKW 1 :.-1 :PARAM #1
PARAM2: .BLKW 1 :.-1 :PARAM #2
PARAM3: .BLKW 1 :.-1 :PARAM #3

IRDA: .BLKW 1 :.WORD 0 :INITIAL READ DATA ADDRESS
IXDA: .BLKW 1 :.WORD 0 :INITIAL XMIT DATA ADDRESS
SETTLE: .BLKW 1 :.WORD 0 :LINE SETTLE DELAY FLAG
IRCC: .BLKW 1 :.WORD 0 :INITIAL RCV CHAR COUNT
B2016: .BLKW 1 :.WORD C :ADDR OF BIN TO OCT TYPE ROUTINE
TIME: .BLKW 1 :.WORD 0 :TIMER
MODEA: .BLKW 1 :.WORD C :ADDR OF ITEMP PARAMS
TX. TERM: .BLKW 1 :.WCRD START :ISR ENTRY ADDRESS
RX. TERM: .BLKB 1 :.BYTE 00C :TRANSMITER TERMINATING CHAR.
:RECEIVER TERMINATING CHAR.

FLAG: .BLKW 1
SWR: 177570
DISPLAY: 177570
START: .BLKW 1 :NOP
:BLKW 1 :NOP
:BLKW 1 :NOP
:BLKW 1 :NOP
CONT.: .BLKW 1 :NOP
:BLKW 1 :NOP
:BLKW 1 :NOP
FINI: .BLKW 1 :MVC #340,PS :LOCK OUT INTERRUPTS.
:BLKW 1 :MOV #ENTER,2(SP) :SET FOR RETURN IF SW14=C
:BLKW 1 :JSR PC.SAVEDS :GO SAVE YOUR REGISTERS.
:BLKW 1 :RTS PC :EXIT

ENTER: .BLKW 1 :JSR PC.RESTOS :GO AND RESTORE REGISTERS
:BLKW 1 :MVC #-1,DELAY :INDICATE DELAY FOR TX.
:BLKW 1 :JMP CONT. :CONTINUE IN PROGRAM
.END
```





# G04

MAINDEC-11-DZITA-D INTERPROCESSOR TEST PROGRAM MACY11 27(1006) 01-DEC-76 11:01 PAGE 46  
 DZITAD.P11 01-DEC-76 11:00 CROSS REFERENCE TABLE -- USER SYMBOLS

SEC 00+5

GETPRM	003642	914*						
GETP3	003666	913	918	922*				
GETSTR=	104404	880	929	1027	1432*			
GETVA	003616	906*						
GOTIC	006040	1257	1264*					
HFTX	005262	1208	1211*					
IBLUF	001604	803*	930	931	961	1029	1038	1040
IF =	000100	1704*						
IF =	000010	1689*						
IF =	000020	628*						
IF =	011026	1737*						
IF =	011020	962	1029*	1116	1734*			
IF =	011000	1094	1726*					
IF =	010410	1623*						
IF =	011022	963	1018*	1033*	1110	1735*		
IF =	104416	1100	1211	1442*				
IF =	000001	1650	1714*					
IF =	001537	780*	1269	1317				
IF =	000017	1707*						
IF =	000002	1661	1665	1710*				
IF =	001374	729	731	734*	751	759	964	
IF =	001426	743*	750					
IF =	001452	741	753*					
MANBA	003404	940	845	848	852*			
MANIN	003316	834*						
MANINX	003460	662	866	869*				
MBA	010406	1622*	1642					
MBILL	010155	970	1540*					
M =	001000	1701*						
MODEA	011034	1740*						
MSECS	006334	1046*	1335*	1337*	1341*			
MSC00	007152	745	755	1540*				
MSC01	007154	876	1540*					
MSC02	007177	897	1540*					
MSC03	007222	903	1540*					
MSC04	007241	906	1540*					
MSC05	007263	909	1540*					
MSC06	007277	914	1540*					
MSC07	007314	919	1540*					
MSC08	007331	924	1540*					
MSC09	007350	977	980	1540*				
MSC10	007372	1026	1540*					
MSC11	007411	1103	1540*					
MSC12	007430	1167	1540*					
MSC13	007443	1196	1540*					
MSC14	007452	1202	1540*					
MSC15	007455	1145	1540*					
MSC16	007500	1455	1540*					
MSC17	007505	1455	1540*					
MSC18	007505	1455	1540*					
MSC19	007505	1455	1540*					
MSC20	007505	1455	1540*					
MSC21	007505	1455	1540*					
MSC22	007505	1455	1540*					
MSC23	007505	1455	1540*					
MSC24	007505	1455	1540*					
MSC25	007505	1455	1540*					
MSC26	007505	1455	1540*					
MSC27	007505	1455	1540*					
MSC28	007505	1455	1540*					
MSC29	007505	1455	1540*					
MSC30	007505	1455	1540*					
MSC31	007505	1455	1540*					
MSC32	007505	1455	1540*					
MSC33	007505	1455	1540*					
MSC34	007505	1455	1540*					
MSC35	007505	1455	1540*					
MSC36	007505	1455	1540*					
MSC37	007505	1455	1540*					
MSC38	007505	1455	1540*					
MSC39	007505	1455	1540*					
MSC40	007505	1455	1540*					
MSC41	007505	1455	1540*					
MSC42	007505	1455	1540*					
MSC43	007505	1455	1540*					
MSC44	007505	1455	1540*					
MSC45	007505	1455	1540*					
MSC46	007505	1455	1540*					
MSC47	007505	1455	1540*					
MSC48	007505	1455	1540*					
MSC49	007505	1455	1540*					
MSC50	007505	1455	1540*					
MSC51	007505	1455	1540*					
MSC52	007505	1455	1540*					
MSC53	007505	1455	1540*					
MSC54	007505	1455	1540*					
MSC55	007505	1455	1540*					
MSC56	007505	1455	1540*					
MSC57	007505	1455	1540*					
MSC58	007505	1455	1540*					
MSC59	007505	1455	1540*					
MSC60	007505	1455	1540*					
MSC61	007505	1455	1540*					
MSC62	007505	1455	1540*					
MSC63	007505	1455	1540*					
MSC64	007505	1455	1540*					
MSC65	007505	1455	1540*					
MSC66	007505	1455	1540*					
MSC67	007505	1455	1540*					
MSC68	007505	1455	1540*					
MSC69	007505	1455	1540*					
MSC70	007505	1455	1540*					

00000000	1460	1540#				
00000001	1109	1540#				
00000002	1115	1540#				
00000003	1503	1540#				
00000004	892	896#				
00000005	1049	1056#				
00000006	959	966#				
00000007	1052	1063	1071#			
00000008	685	771#				
00000009	1259	1262				
00000010	1498	1512#				
00000011	1107	1686#				
00000012	1112	1655	1665#			
00000013	1730					
00000014	1731					
00000015	1732					
00000016	1625	1649				
00000017	1626					
00000018	1627					
00000019	1557	1586				
00000020	1624					
00000021	1729					
00000022	585	1065	1075	1122	1494	
00000023	586					
00000024	587					
00000025	588	1152				
00000026	589					
00000027	590					
00000028	591					
00000029	592	819	1514			
00000030	1553	1571	1582			
00000031	720	777#	878	927	1140	1314
00000032	979	1010#				
00000033	1010	1011#				
00000034	624					
00000035	1674					
00000036	1656	1681#				
00000037	1695					
00000038	1659	1712#				
00000039	967	970#	1016			
00000040	1436					
00000041	1744					
00000042	1705					
00000043	978	1446#				
00000044	1674	1736#				
00000045	1698					
00000046	525	619	1074	1124	1492	
00000047	1750					
00000048	1659					
00000049	1702					
00000050	819	1065	1075	1122	1152	1440# 1494
00000051	820	1444#				
00000052	1046					
00000053	1020	1022	1029#			
00000054	540	540#				







K04

MAINDEC-11-DZITA-D INTERPROCESSOR TEST PROGRAM MACY11 27(1006) 01-DEC-76 11:01 PAGE 51  
DZITAD.P11 01-DEC-76 11:00 CROSS REFERENCE TABLE -- MACRO NAMES

SEC 0049

BOX	624#	696	772	814	825	831	872	988	1023	1079	1095	1135	1148	1229	1243
	1332	1448	1540	1561	1616	1638	1717								
HE-10	10														
ALY	5410	1576	1591	1607											

. ABS. 011104 000

ERRORS DETECTED: 0  
DEFAULT GLOBALS GENERATED: 0

DSKZ:DZITAD,DZITAD/SOL/CRF/EN:AMA=DZITAD.P11  
RUN-TIME: 9.141 SECONDS  
RUN-TIME RATIO: 107/25=4.1  
CORE USED: 11K (21 PAGES)

