

# RP04/05/06

MULTI-DRIVE LOGIC EXER  
MD-11-DZRJD-A

EP-DZRJD-A-DL-A

NOV 1976

COPYRIGHT © 1976

FICHE 1 OF 1 MADE IN US

DZRJD  
500

Table 1	Table 2	Table 3	Table 4	Table 5	Table 6	Table 7	Table 8	Table 9	Table 10
Table 11	Table 12	Table 13	Table 14	Table 15	Table 16	Table 17	Table 18	Table 19	Table 20
Table 21	Table 22	Table 23	Table 24	Table 25	Table 26	Table 27	Table 28	Table 29	Table 30
Table 31	Table 32	Table 33	Table 34	Table 35	Table 36	Table 37	Table 38	Table 39	Table 40
Table 41	Table 42	Table 43	Table 44	Table 45	Table 46	Table 47	Table 48	Table 49	Table 50
Table 51	Table 52	Table 53	Table 54	Table 55	Table 56	Table 57	Table 58	Table 59	Table 60
Table 61	Table 62	Table 63	Table 64	Table 65	Table 66	Table 67	Table 68	Table 69	Table 70
Table 71	Table 72	Table 73	Table 74	Table 75	Table 76	Table 77	Table 78	Table 79	Table 80
Table 81	Table 82	Table 83	Table 84	Table 85	Table 86	Table 87	Table 88	Table 89	Table 90
Table 91	Table 92	Table 93	Table 94	Table 95	Table 96	Table 97	Table 98	Table 99	Table 100



.REM 2

IDENTIFICATION

PRODUCT CODE: MAINDEC-11-DZRJD-A-D  
PRODUCT NAME: RPO4/5/6 MULTI-DRIVE EXERCISER PROGRAM  
DATE CREATED: MAY 1976  
MAINTAINER: DIAGNOSTIC ENGINEERING  
AUTHOR: C. HESS

COPYRIGHT (C) 1976 DIGITAL EQUIPMENT CORP., MAYNARD, MASS.

THE INFORMATION IN THIS STATEMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION.

ACTUAL DISTRIBUTION OF THE SOFTWARE DESCRIBED IN THIS DOCUMENT WILL BE SUBJECT TO TERMS AND CONDITIONS TO BE ANNOUNCED ON SOME FUTURE DATE BY DIGITAL EQUIPMENT CORPORATION.

DEC ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT WHICH IS NOT SUPPLIED BY DEC.

THIS SOFTWARE IS FURNISHED TO PURCHASER UNDER A LICENSE TO USE ON A SINGLE COMPUTER SYSTEM AND CAN BE COPIED (WITH INCLUSION OF DEC'S COPYRIGHT NOTICE) ONLY FOR USE IN SUCH SYSTEM, EXCEPT AS MAY OTHERWISE BE PROVIDED IN WRITING BY DEC.

CONTENTS

1. ABSTRACT
2. REQUIREMENTS
  - 2.1 EQUIPMENT
  - 2.2 MEDIA
  - 2.3 PRELIMINARY PROGRAMS
3. OPERATING THE PROGRAM
  - 3.1 LOADING THE PROGRAM
  - 3.2 STARTING THE PROGRAM
  - 3.3 RESTARTING THE PROGRAM
  - 3.4 PROGRAM CONTROL
  - 3.5 PASS/TEST TERMINATION
    - 3.5.1 PASS TERMINATION
    - 3.5.2 TEST TERMINATION
  - 3.6 RUN TIME
    - 3.6.1 DATA TRANSFER MODE
    - 3.6.2 SEEK VERIFICATION MODE
  - 3.7 UNIBUS & VECTOR ADDRESSES
  - 3.8 DUAL PORT OPERATION
4. CONTROLLING THE PROGRAM
  - 4.1 DATE & OPERATOR IDENTIFICATION
  - 4.2 PARAMETERS
    - 4.2.1 PROGRAM CONTROL PARAMETERS
    - 4.2.2 PERIPHERAL DEVICE ADDRESSES
    - 4.2.3 PARAMETERS FOR THE FIRST OPERATION
  - 4.3 SWITCH REGISTER SETTINGS
  - 4.4 KEYBOARD COMMANDS
    - 4.4.1 'T' COMMAND
    - 4.4.2 'D' COMMAND
    - 4.4.3 'S' COMMAND
    - 4.4.4 'W' COMMAND
    - 4.4.5 'R' COMMAND
    - 4.4.6 GENERAL COMMAND INFORMATION
5. PERFORMANCE SUMMARY TYPEOUT
  - 5.1 PERFORMANCE SUMMARY TYPEOUT EXPLANATION
  - 5.2 HARD/SOFT ERROR DEFINITIONS
    - 5.2.1 HARD ERRORS
    - 5.2.2 SOFT ERRORS
6. DATA CHECKING & ERROR RECOVERY
  - 6.1 DATA BUFFER COMPARISON
  - 6.2 VERIFICATION OF DATA WRITTEN
  - 6.3 SECTOR REFORMATTING

6.4 BAD TRACK/SECTOR FLAGGING

7. ERROR MESSAGES

- 7.1 ERROR DESCRIPTION LINES
- 7.2 DETAIL ERROR LINES

8. PROGRAM DESCRIPTION

- 8.1 HOW THE PROGRAM OPERATES
- 8.2 DUAL PORT OPERATION
- 8.3 HOW VARIABLES ARE SELECTED FOR EACH OPERATION
- 8.4 DATA PATTERNS

9. PROGRAM LISTING

1. ABSTRACT  
-----

THE RPO4/5/6 MULTIDRIVE EXERCISER PROGRAM IS DESIGNED TO PERFORM AN INTERACTIVE TEST ON RPO4/5/6 DISK DRIVES CONNECTED TO A MASSBUS SUBSYSTEM. THE SUBSYSTEM MAY BE COMPOSED OF INTERMIXED RPO4, RPO5 OR RPO6 DISK DRIVES CONTROLLED BY EITHER AN RH11 OR AN RH70. IN ADDITION TO PERFORMING AN INTERACTIVE TEST OF THE DISK DRIVES ON THE SUBSYSTEM, THE PROGRAM IS INTENDED TO BE USED TO VERIFY THAT THE DRIVES UNDER TEST ARE PERFORMING TO THEIR DATA ERROR RATE AND SEEK ERROR RATE SPECIFICATIONS.

THE RPO4/5/6 MULTIDRIVE EXERCISER PROGRAM WILL EXERCISE DRIVES CONNECTED AS EITHER SINGLE OR DUAL PORT UNITS. DUAL PORT DRIVES ARE TESTED BY LOADING AND RUNNING THE PROGRAM FROM BOTH CONTROLLING SYSTEMS. THE PROGRAM WILL EXERCISE A MIXED SYSTEM OF DUAL PORT AND NON DUAL PORT DRIVES.

TO OBTAIN INTERACTIVE TESTING, OPERATIONS ON THE DRIVES ARE OVERLAPPED (OTHER DRIVES ARE PERFORMING SEEK/SEARCH OPERATIONS WHILE ONE DRIVE IS PERFORMING A DATA TRANSFER OR WRITE CHECK OPERATION). OPERATIONS AMONG THE DRIVES ARE OPTIMIZED SO THAT A HIGH SUBSYSTEM DATA TRANSFER RATE OR A HIGH POSITIONING OPERATION RATE IS MAINTAINED.

THE PERFORMANCE OF EACH DRIVE IS MONITORED BY THE PROGRAM. IF A DRIVE EXCEEDS A PRESET NUMBER OF ERRORS IN ANY OF SEVERAL CATEGORIES, THAT DRIVE IS AUTOMATICALLY DEASSIGNED. (THE OPERATOR MAY OVERRIDE THE AUTOMATIC DEASSIGNMENT FEATURE.) THE PROGRAM REPORTS PERFORMANCE STATISTICS FOR EACH DRIVE BEING EXERCISED ON REQUEST FROM THE OPERATOR OR AUTOMATICALLY AT AN INTERVAL DETERMINED BY THE OPERATOR.

ALL DATA TRANSFER COMMANDS ARE USED (I.E., WRITE DATA, WRITE HEADER & DATA, READ DATA, AND READ HEADER & DATA) AS WELL AS WRITE CHECK DATA AND WRITE CHECK HEADER & DATA COMMANDS. RECALIBRATE AND READ-IN PRESET COMMANDS ARE USED AT STARTUP AND DRIVE INITIALIZATION. RECALIBRATE, OFFSET, AND RETURN-TO-CENTERLINE COMMANDS ARE USED DURING ERROR PROCESSING.

THE DATA TRANSFER COMMANDS ARE SELECTED RANDOMLY EXCEPT FOR THE WRITE CHECK COMMANDS. THE WRITE CHECK COMMANDS ARE USED TO VERIFY A PREVIOUS WRITE OPERATION. THUS, WHEN A WRITE COMMAND IS SELECTED, THE DATA WRITTEN IS VERIFIED BY THE APPROPRIATE WRITE CHECK COMMAND.

PROGRAM OPERATOR COMMUNICATIONS ARE THROUGH THE KEYBOARD; DYNAMIC PROGRAM OPTIONS ARE SELECTED BY SWITCH REGISTER SETTINGS. ERRORS ARE REPORTED ON THE TELETYPE.

ALL COMMANDS, DATA PATTERNS, AND DATA BUFFER SIZES ARE SELECTED RANDOMLY BY THE PROGRAM. ADDITIONALLY THE ADDRESSES (EG, CYLINDER, TRACK, AND SECTOR) FOR EACH OPERATION ARE SELECTED RANDOMLY.

## 2. REQUIREMENTS

-----  
2.1 EQUIPMENTREQUIRED  
-----

PDP-11 PROCESSOR  
16K MEMORY (20K IF THE PROGRAM IS INCLUDED IN AN 'XXDP' CHAIN)  
TELETYPE  
PROGRAM LOADING DEVICE  
KW11-L OR KW11-P CLOCK  
RH11 OR RH70 WITH 1 RPO4, RPO5, OR RPO6 DISK DRIVE

OPTIONAL  
-----

ADDITIONAL MEMORY TO A MAXIMUM OF 28K  
1 TO 7 ADDITIONAL RPO4/5/6'S ON THE SAME RH11 OR RH70

## 2.2 MEDIA

THE RPO4/5/6 MULTIDRIVE EXERCISER PROGRAM REQUIRES FORMATTED DISK PACKS WHICH CONTAIN RANDOM OR PATTERNED DATA RECOGNIZED BY THE EXERCISER. DISK PACKS USED BY THE PROGRAM MAY BE GENERATED BY THE RPO4/5/6 FORMATTER PROGRAM (MAINDEC-11-DZRJB) OR BY THE 'W' COMMAND OF THE RPO4/5/6 MULTIDRIVE EXERCISER (SEE SECTION 4.4). THE PACKS MUST BE FORMATTED IN 22 SECTOR (16 BIT) MODE; THE ALTERNATE (20 SECTOR - 18 BIT) MODE IS NOT SUPPORTED.

## 2.3 PRELIMINARY PROGRAMS

RPO4/5/6 DISKLESS CONTROLLER TEST  
PART 1 (MAINDEC-11-DZRJG)  
PART 2 (MAINDEC-11-DZRJH)

RPO4/5/6 FUNCTIONAL CONTROLLER TEST  
PART 1 (MAINDEC-11-DZRJI)  
PART 2 (MAINDEC-11-DZRJJ)

RPO4/5/6 DUAL CONTROLLER LOGIC TEST (FOR DUAL PORT DRIVE TESTING)  
PART 1 (MAINDEC-11-DZRJE)  
PART 2 (MAINDEC-11-DZRJF)

3. OPERATING THE PROGRAM  
-----

3.1 THE PROGRAM MAY BE LOADED FROM PAPER TAPE USING THE ABSOLUTE LOADER OR IT MAY BE LOADED FROM THE APPROPRIATE 'XXDP' MEDIA USING THE ASSOCIATED LOADER. THE PROGRAM MAY BE INCLUDED IN AN 'XXDP' CHAIN. IF THE

PROGRAM IS BEING RUN ON A PROCESSOR WITH 16K. THE 'YXDP' LOADER WILL NOT BE PRESERVED. THE PROGRAM MUST BE RUN ON A SYSTEM WITH 20K OR MORE TO PRESERVE THE 'YXDP' LOADER. THE 'ABSOLUTE' LOADER WILL BE PRESERVED IN A 16K SYSTEM, HOWEVER.

- 3.2 THE PROGRAM STARTS AT LOCATION 200(8). PARAMETERS NOT INCLUDED IN THE TELETYPE DIAGLOGUE GROUP MUST BE CHANGED BEFORE THE PROGRAM IS STARTED.
- 3.3 START THE PROGRAM AT LOCATION 204(8) IF THE RH11 OR THE RH70 IS NOT AT ADDRESS 176700.
- 3.4 ONCE THE PROGRAM IS LOADED AND STARTED, OPERATIONS ARE INITIATED AND CONTROLLED BY KEYBOARD COMMANDS AND SWITCH REGISTER SWITCH SETTINGS.

IF THIS IS THE PROGRAM'S FIRST START, THE STATUS OF THE DRIVES ON THE SELECTED MASSBUS SUBSYSTEM WILL BE TYPED OUT. ON SUBSEQUENT STARTS, THIS TYPEOUT MAY BE INHIBITED BY SETTING SW<02>.

### 3.5 PASS/TEST TERMINATION

A PASS IS DETERMINED BY EITHER BITS READ OR SEEKS PERFORMED. THE NUMBER OF BITS OR SEEKS REQUIRED FOR A PASS IS DERIVED FROM EITHER THE SOFT ERROR RATE SPECIFICATION OR THE SEEK ERROR RATE SPECIFICATION. THE SPECIFICATIONS FOR RP04'S, RP05'S, AND RP06'S SPECIFY NO MORE THAN 1 SOFT ERROR (NON-PACK RELATED) IN  $1 \times 10^{19}$  BITS READ OR NO MORE THAN 1 SEEK ERROR IN  $1 \times 10^{16}$  SEEKS. THE NUMBER OF BITS OR SEEKS DETERMINING A PASS WERE SELECTED TO PROVIDE A 90% CONFIDENCE LEVEL THAT THE DRIVE IS PERFORMING TO THE APPLICABLE SPECIFICATION.

#### 3.5.1 PASS TERMINATION

END OF PASS MAY BE DETERMINED BY EITHER OF THE FOLLOWING CONDITIONS. THE END OF PASS CONDITION USED IS DETERMINED BY PARAMETER 'ENDET'.

- A. IF PARAMETER 'ENDET' IS 1, END OF PASS OCCURS WHEN THE DRIVE HAS READ  $1.875 \times 10^{18}$  WORDS ( $3 \times 10^{19}$  BITS).
- B. IF PARAMETER 'ENDET' IS 0, END OF PASS OCCURS WHEN THE DRIVE HAS PERFORMED  $3 \times 10^{16}$  SEEKS.

#### 3.5.2 TEST TERMINATION

THE TEST FOR A DRIVE IS TERMINATED (SW<04> = 0) WHEN:

- A. THE DRIVE HAS COMPLETED THE NUMBER OF PASSES SPECIFIED IN PARAMETER 'PASCNT'.
- B. THE TOTAL ERRORS ACCUMULATED EXCEED 100.
- C. A FATAL ERROR OCCURS: EM12 OR EM14.

### 3.6 RUN TIME

THE EXERCISER PROGRAM MAY BE RUN IN TWO MODES. THE MODE IS DETERMINED BY THE VALUE IN PARAMETER 'MAXDL'. IF 'MAXDL' IS ONE SECTOR, THE PROGRAM RUNS IN A SEEK HEAVY MODE; IF 'MAXDL' APPROACHES



ONE TRACK IN SIZE (5720 DECIMAL) THE PROGRAM RUNS IN A DATA TRANSFER HEAVY MODE. THE PROGRAM RUN TIME VARIES GREATLY DEPENDING ON THE OPERATION MODE SELECTED. THE MEMORY AVAILABLE OVER 16K, THE READ WRITE RATIO PARAMETER - 'RATIO', AND BY SWITCHES 0, 1, & 2.

3.5.1 DATA TRANSFER MODE

1 DRIVE - APPROXIMATELY 2.5 HRS (TO REACH 1.875 X 10<sup>18</sup> WORDS)  
 TO  
 8 DRIVES - APPROXIMATELY 11 HRS (FOR ALL DRIVES TO REACH 1.875 X 10<sup>18</sup> WORDS)

NOTE: IF SW<01> = 1 (NO SOFTWARE DATA COMPARSIONS), THE TUN TIMES ARE THE FOLLOWING VALUES, APPROXIMATELY:

1 DRIVE - 1.7 HRS (1.875 X 10<sup>18</sup> WORDS READ)  
 ADD 1/2 HOUR FOR EACH ADDITIONAL DRIVE TESTED.

IF THE PROGRAM IS RUN WITH BOTH SW<00> AND SW<01> SET, THE RUN TIMES SHOULD BE ABOUT 20% FASTER.

3.5.2 SEEK VERIFICATION MODE

PARAMETER 'MAXDL' = 1 SECTOR (256 WORDS)  
 PARAMETER 'MAXTRK' = 'MINTRK'  
 PARAMETER 'MAXSEC' = 'MINSEC'  
 SW<00> = 1 (READ ONLY MODE)

1 DRIVE - APPROXIMATELY 25 HRS (3 X 10<sup>16</sup> SEEKS)  
 TO  
 8 DRIVES - APPROXIMATELY 40 HRS (3 X 10<sup>16</sup> SEEKS FOR ALL DRIVES)

3.7 UNIBUS & VECTOR ADDRESSES

THE PROGRAM ASSUMES THE FOLLOWING UNIBUS AND VECTOR ADDRESSES. (REFER TO SECTION 4.2.2 FOR THE LOCATIONS AT WHICH TO CHANGE THESE ADDRESSES.)

UNIT	UNIBUS ADDRESS	VECTOR ADDRESS
RH11 OR RH70	176700	254
TTY PRINTER	177564	NOT USED
TTY KEYBOARD	177560	60
KW11-L	177546	100
KW11-P	172542	104

3.8 DUAL PORT OPERATION

A. LOAD THE RPO4/5/6 MULTIDRIVE EXERCISER PROGRAM INTO BOTH PROCESSORS.

- B. SWITCH THE 'CONTROLLER SELECT' SWITCH TO 'A/B' ON EACH DRIVE WHICH IS TO BE TESTED AS A DUAL PORT DRIVE; CYCLE THE DRIVES UP.
- C. START THE PROGRAM IN EACH PROCESSOR. RUN THE PROGRAM AS THOUGH EACH PROCESSOR WERE RUNNING INDEPENDENTLY OF THE OTHER.

#### 4. CONTROLLING THE PROGRAM

THE FOLLOWING KEYBOARD CONVENTIONS ARE USED BY THE KEYBOARD ENTRY ROUTINES IN THE PROGRAM:

- A. TO DELETE AN INCORRECT CHARACTER FROM AN ENTRY STRING, TYPE A 'RUBOUT' ('RO'). TYPING A 'RO' WILL DELETE SUCCESSIVE CHARACTERS FROM THE INPUT.
- B. TO DELETE AN ENTIRE LINE, TYPE A 'CONTROL U' ('IU').
- C. AN ENTRY MUST BE TERMINATED BY EITHER A 'CARRIAGE RETURN' OR A 'PERIOD'. THE 'PERIOD' TERMINATION IS RECOGNIZED BY THE PROGRAM AS A DEFAULT ENTRY REQUEST. WHEN A LINE IS TERMINATED BY A 'PERIOD' INSTEAD OF A 'CARRIAGE RETURN', THE PROGRAM WILL ACCEPT THE ENTERED VALUE AND WILL DEFAULT TO THE PRELOADED VALUES FOR ANY REMAINING ENTRIES.
- D. IF A 'CONTROL C' IS TYPED DURING KEYBOARD ENTRY, THE PROGRAM WILL RETURN TO THE BEGINNING OF THE GROUP BEING ENTERED.

##### 4.1 DATE & OPERATOR IDENTIFICATION

WHEN THE PROGRAM IS INITIALLY STARTED, IT WILL ASK FOR DATE AND OPERATOR I.D. ENTRIES. (THE REQUEST FOR THESE ENTRIES OCCURS ONLY WHEN THE PROGRAM IS FIRST STARTED AND WILL NOT APPEAR WHEN THE PROGRAM IS RESTARTED.) THESE ENTRIES ARE OPTIONAL AND MAY BE BYPASSED BY ENTERING A 'CARRIAGE RETURN' IN RESPONSE TO THE REQUEST. THE PROGRAM DOES NOT EDIT OR CHECK EITHER ENTRY. UP TO 8 CHARACTERS OF DATE INFORMATION AND UP TO 6 CHARACTERS OF OPERATOR IDENTIFICATION MAY BE ENTERED. BOTH THE DATE AND THE OPERATOR I.D. WILL BE TYPED WHEN THE 'SA' COMMAND IS PERFORMED (SEE SECTION 4.4.3).

##### 4.2 PARAMETERS

WHEN THE PROGRAM IS STARTED FROM LOCATION 200, THE OPERATOR WILL BE ASKED TO ENTER PARAMETERS. THE FOLLOWING MESSAGE WILL BE DISPLAYED:

ENTER PARAMETERS:

THE OPERATOR MUST ENTER A 'Y' TERMINATED BY A CARRIAGE RETURN (CR) IF PARAMETER ENTRIES ARE TO BE MADE. ANY OTHER CHARACTER IS ACCEPTED AS A 'NO' ENTRY. THE PROGRAM WILL IDENTIFY THE PARAMETER BY THE NAME

GIVEN BELOW, DISPLAY THE CURRENT VALUE OF THE PARAMETER AND WAIT FOR THE ENTRY. THE PROGRAM WILL TYPE 'INVALID ENTRY' IF THE ENTRY IS NOT CORRECT AND WAIT FOR A CORRECT ENTRY TO BE TYPED.

4.2.1 KEYBOARD ENTRY PARAMETERS

NAME	BASE	DEFAULT VALUE	VALUE RANGE	FUNCTION
MAXDL	10	(SEE NOTE)		CONTROLS THE MAXIMUM BUFFER SIZE USED FOR DATA TRANSFERS
PASCNT	10	1	1 - 999	NUMBER OF PASSES TO END OF TEST.
INTRVL	10	5	0 - 256	DETERMINES THE INTERVAL (IN MINUTES) BETWEEN AUTOMATIC PERFORMANCE SUMMARY TYPEOUTS
CMPLMT	10	3	0 - 'MAXDL'	ERRORS PRINTED OUT IF SW<07>=0
WCSEL	8	000000	0 OR 1	THE NUMBER OF DATA COMPARISON IF PARAMETER = 0, THE DATA TRANSFER WORD COUNT IS RANDOMLY SELECTED BETWEEN 4 (10) AND THE VALUE IN 'MAXDL'. IF PARAMETER = 1, THE DATA TRANSFER WORD COUNT WILL BE THE VALUE IN 'MAXDL'
ENDET	8	000001	0 OR 1	IF PARAMETER = 1, END OF PASS DETERMINED BY THE 'WORDS READ' COUNT. IF PARAMETER = 0, END OF PASS IS DETERMINED BY THE NUMBER OF SEEKS.
FORMAT	8	000001	0 OR 1	IF PARAMETER = 0; DO NOT PERFORM WRITE HEADER & DATA ORDERS; IF PARAMETER > 0, PERFORM WRITE HEADER & DATA ORDERS
RATIO	8	000003	0 - 7	CONTROLS THE APPROXIMATE RATIO OF READ TO WRITE ORDERS.
				VALUE R/W RATIO
				0 15/1
				1 7/1
				2 6/2
				3 5/3
				4 4/4
				5 3/5
				6 2/6
				7 1/7
AUTOCK	8	000001	0 OR 1	IF PARAMETER = 1, THE PROGRAM PERFORM WRITE CHECKS AFTER

NOTPRT 8 000001 0 OR 1

EACH WRITE COMMAND.  
IF PARAMETER = 0, THE PROGRAM  
WILL PERFORM WRITE CHECKS  
RANDOMLY.  
IF PARAMETER = 1, DO NOT PRINT  
ERROR MESSAGES FOR DATA ERRORS  
OCCURRING AT LOCATIONS DEFINED  
BY THE OPERATOR AS BAD PACK  
LOCATION.  
IF PARAMETER = 0, PRINT ERROR  
MESSAGES ASSOCIATED WITH BAD  
PACK LOCATIONS.

NOTE: THE PROGRAM WILL SELECT A MAXIMUM BUFFER SIZE WHICH  
IS DETERMINED BY THE MEMORY AVAILABLE. THE MAXIMUM BUFFER  
SIZE ASSIGNED BY THE PROGRAM IS 5980 (10) WORDS. THE  
OPERATOR MAY SPECIFY ANY OTHER MAXIMUM SIZE AS LONG AS THE  
VALUE SPECIFIED IS AT LEAST 4 WORDS BUT NO LARGER THAN  
THE INITIAL VALUE OF 'MAXDL' DETERMINED BY THE PROGRAM.

4.2.2 PERIPHERAL ADDRESSES AND OTHER LOCATIONS OF INTEREST

TO ALTER THESE LOCATIONS, THE OPERATOR MUST MAKE MANUAL ENTRIES  
BEFORE THE PROGRAM IS STARTED. THE KEYBOARD ENTRY ROUTINE DOES  
NOT PROVIDE ACCESS TO THESE LOCATIONS.

LOC	TAG	CONTENTS	FUNCTION
---	---	-----	-----
1144	\$TKS	177560	TTY KEYBOARD STATUS REGISTER
1146	\$TKB	177562	TTY KEYBOARD BUFFER REGISTER
1150	\$TPS	177564	TTY PRINTER STATUS REGISTER
1152	\$TPB	177566	TTY PRINTER BUFFER REGISTER
1174	\$LKCSR	172540	ADDRESS OF KW11-P STATUS REGISTER
1176	\$LKCSB	172542	ADDRESS OF KW11-P COUNTER BUFFER
1200	\$LPVEC	104	KW11-P VECTOR ADDRESS
1202	\$LKS	177546	ADDRESS OF KW11-L STATUS REGISTER
1204	\$LLVEC	100	KW11-L VECTOR ADDRESS
1212	HZ	74	74 (60 DECIMAL) IF SYSTEM IS 60 HZ; 62 (50 DECIMAL) IF SYSTEM IS 50 HZ.

THE RH11-RH70 ADDRESS AND VECTOR MAY BE CHANGED WHEN THE PROGRAM  
IS STARTED FROM LOCATION 204(8) OR IF THE PROGRAM DOES NOT RECEIVE  
A RESPONSE WHEN IT ACCESSES THE DEFAULT RH11-RH70 ADDRESS.

4.2.3 PARAMETERS FOR THE FIRST OPERATION

THE FOLLOWING PARAMETERS ARE USED FOR THE INITIAL OPERATION (IN  
ADDITION TO THE 'MINIMUM' ADDRESS VALUES).

INITIAL VALUE

LOC	TAG	VALUE	RANGE	FUNCTION
---	---	-----	-----	-----
1412	BEGPAT	10	1 - 15	THE CODE FOR THE STARTING PATTERN. (IF A WRITE ORDER OR A WRITE CHECK ORDER IS SPECIFIED IN 'BEGCOD')
1414	BEGCOD	5	0 - 5	THE INITIAL COMMAND FOR EACH DRIVE EXERCISED. 0 = WRITE CHECK DATA 1 = WRITE CHECK HEADER & DATA 2 = WRITE DATA 3 = WRITE HEADER & DATA 4 = READ DATA 5 = READ HEADER & DATA
1416	BEGSIZ	404	4 - MAXDL	THE BUFFER SIZE FOR THE FIRST DATA TRANSFER OPERATION.

## 4.3 SWITCH REGISTER SETTINGS

SW <15> = 1 HALT ON ERROR  
 SW <13> = 1 INHIBIT ERROR TYPEOUT  
 SW <10> = 1 RING THE TELETYPE BELL IF ERROR  
 SW <7> = 1 DISPLAY ALL DATA COMPARE ERRORS  
 SW <6> = 1 DO NOT ALTER THE CURRENT OPERATION PARAMETERS  
 SW <5> = 1 PARTIAL REGISTER DISPLAY IF ERROR; DO NOT DISPLAY ECC CORRECTION RESULTS  
 SW <4> = 1 INHIBIT MAXIMUM ERROR COUNT CHECK; DO NOT DEASSIGN DRIVES WHEN NORMAL END OF TEST REACHED.  
 SW <3> = 1 DISPLAY THE SECTOR IN ERROR (BEFORE RETRY ATTEMPTS) IF 'DCK', 'DTE', OR 'WCF' ERRORS OR AFTER THE 28TH RETRY IF 'UNCORRECTABLE' 'DCK' ERROR.  
 IF DATA COMPARE ERRORS & SW<7> SET, DISPLAY REST OF BUFFER  
 SW <2> = 1 INHIBIT SUBSYSTEM STATUS TYPEOUT DURING STARTUP.  
 INHIBIT PERFORMANCE SUMMARY TYPEOUTS.  
 SW <1> = 1 INHIBIT DATA COMPARSION AFTER READ ORDERS  
 SW <0> = 1 READ ONLY MODE

IF THE PROGRAM IS BEING RUN ON A SWITCHLESS PROCESSOR (I.E. AN 11/34) THE PROGRAM WILL DETERMINE THAT THE HARDWARE SWITCH REGISTER IS NOT PRESENT AND WILL USE A 'SOFTWARE' SWITCH REGISTER. THE 'SOFTWARE' SWITCH REGISTER IS LOCATED AT LOCATION 176 (8). THE SETTINGS OF THE 'SOFTWARE' SWITCHES ARE CONTROLLED THROUGH A KEYBOARD ROUTINE WHICH IS CALLED BY TYPING A 'CONTROL G'. THE PROGRAM WILL RECOGNIZE THE 'CONTROL G' AT ANY TIME EXCEPT WHEN THE PROGRAM IS IN KEYBOARD ENTRY MODE, OR IS AT A HIGHER PRIORITY PROCESSING AN PPO4/5/6 INTERRUPT. THE 'SOFTWARE' SWITCH VALUES ARE ENTERED AS AN OCTAL NUMBER IN RESPONSE TO THE PROMPT FROM THE SWITCH ENTRY ROUTINE:

'SWR = NNNNNN NEW ='

EACH TIME SWITCH SETTING ARE ENTERED, THE ENTIRE SWITCH REGISTER

IMAGE MUST BE ENTERED. LEADING ZEROS ARE NOT REQUIRED. 'RUBOUT' AND 'CONTROL U' FUNCTIONS MAY BE USED TO CORRECT TYPING ERRORS DURING SWITCH ENTRY.

ON PROCESSORS WITH HARDWARE SWITCH REGISTERS, THE 'SOFTWARE' SWITCH REGISTER MAY BE USED. IF THE PROGRAM FINDS ALL 16 SWITCHES IN THE 'UP' POSITION, ALL SWITCH REGISTER REFERENCES WILL BE TO THE 'SOFTWARE' REGISTER AND THE PROCEDURES DESCRIBED ABOVE MUST BE FOLLOWED.

4.4 KEYBOARD COMMANDS

THROUGH THE KEYBOARD COMMANDS, THE OPERATOR MAY ASSIGN DRIVES FOR TEST ('T' COMMAND), WRITE AND CHECK DATA PACKS ('W' COMMAND), PERFORM A SEQUENTIAL READ OF A PACK ('R' COMMAND), REQUEST A DRIVE PERFORMANCE SUMMARY ('S' COMMAND), OR DEASSIGN A DRIVE WHICH IS BEING TESTED, READING, OR WRITING ('D' COMMAND).

AFTER THE PROGRAM HAS BEEN INITIALIZED, THE FOLLOWING MESSAGE WILL BE TYPED:

'PROGRAM INITIALIZATION COMPLETE  
'TYPE A CONTROL C TO ENTER COMMANDS'

KEYBOARD ENTRIES WILL NOT BE RECOGNIZED UNTIL THE OPERATOR TYPES A 'CONTROL C'. WHEN THE PROGRAM SEES A 'CONTROL C' ENTRY, IT WILL SUSPEND THE SCHEDULING OF FURTHER DEVICE OPERATIONS AND WAIT UNTIL ALL OUTSTANDING ORDERS HAVE TERMINATED. THE PROGRAM WILL ENTER COMMAND ENTRY MODE AND TYPE THE FOLLOWING PROMPTING MESSAGE:

'HH:MM:SS  
'ENTER COMMANDS:'

THE PROGRAM WILL THEN ACCEPT ANY OF THE VALID COMMANDS. AT THE COMPLETION OF A COMMAND, THE PROGRAM WILL EXIT COMMAND MODE; THE OPERATOR MUST TYPE ANOTHER 'CONTROL C' TO RETURN THE PROGRAM TO COMMAND MODE. IF THE COMMAND ENTERED SPECIFIED AN 'A' DRIVE NUMBER, THE PROGRAM WILL REMAIN IN COMMAND MODE UNTIL ALL AVAILABLE DRIVES HAVE BEEN PROCESSED.

THE 'T', 'W', AND 'R' COMMANDS REQUIRE ADDRESS LIMITS, DRIVE I.D. AND BAD LOCATION ADDRESS ENTRIES FOR THE DRIVE BEING REFERENCED.

THE PROGRAM WILL FIRST ASK FOR ADDRESS LIMITS WITH THE FOLLOWING TYPEOUT:

'ENTER ADDRESS LIMITS FOR DRV #N / RP04' (OR RP05 OR RP06)

THE PROGRAM WILL REQUEST VALUES FOR THE FOLLOWING ADDRESS LIMIT PARAMETERS.

NAME	BASE	DEFAULT VALUE	VAL. RANGE	FUNCTION
------	------	---------------	------------	----------

MINCYL	10		(SEE NOTE)	THE MINIMUM CYLINDER ADDRESS
MAXCYL	10		(SEE NOTE)	THE MAXIMUM CYLINDER ADDRESS
MINTRK	10	0	0 - 18	THE MINIMUM TRACK ADDRESS
MAXTRK	10	18	0 - 18	THE MAXIMUM TRACK ADDRESS
MINSEC	10	0	0 - 21	THE MINIMUM SECTOR ADDRESS
MAXSEC	10	21	0 - 21	THE MAXIMUM SECTOR ADDRESS

- NOTE: 1. THE ADDRESS LIMITS ARE IN DECIMAL
2. THE MAXIMUM VALUES OF 'MINCYL' AND 'MAXCYL' WILL BE EITHER 410 (10) OR 814 (10) DEPENDING ON THE TYPE OF DRIVE.
3. THE MINIMUM CYLINDER, TRACK, OR SECTOR ADDRESS MAY BE SPECIFIED AS BEING LARGER THAN THE MAXIMUM ADDRESS. WHEN THESE VALUES ARE INVERTED, THE PROGRAM WILL SELECT ADDRESSES BETWEEN THE 'MIN' ADDRESS AND THE UPPER PHYSICAL LIMIT FOR THAT ADDRESS AND BETWEEN '0' AND THE VALUE IN 'MAX'.

EACH COMMAND, EXCEPT THE 'S' AND THE 'D' COMMANDS, WILL ASK FOR A DRIVE IDENTIFICATION ENTRY. THE DRIVE IDENTIFICATION ENTRY REQUEST IS MADE BY THE FOLLOWING MESSAGE:

'ENTER I.D. FOR DRV #N:'

THE OPERATOR MAY ENTER AN I.D. NUMBER FOR THE DRIVE OF UP TO 6 CHARACTERS IN LENGTH. THIS I.D. WILL BE DISPLAYED, ALONG WITH THE DATE AND OPERATOR I.D. ENTRIES (SEE SECTION 4.1), WHEN THE 'SA' COMMAND IS EXECUTED. THE OPERATOR MAY ENTER ANY CHARACTER STRING, TERMINATED BY A 'CARRIAGE RETURN', OR A 'PERIOD' ONLY (NULL ENTRY) IN RESPONSE TO THE I.D. REQUEST.

THE PROGRAM WILL THEN ASK FOR THE ADDRESSES OF KNOWN BAD SPOTS ON THE DISK PACK USED. UP TO 16 ADDRESSES MAY BE ENTERED:

'BAD TRK/SEC ADRS FOR DRV #N ?'

THE OPERATOR MAY DECLARE UP TO 16 BAD LOCATIONS ON THE PACK BEING USED. THE LOCATION MAY BE AN ENTIRE CYLINDER, A BAD TRACK, OR A SINGLE SECTOR. THE FORMATS USED ARE AS FOLLOWS:

FORMAT 1: C,T,S<CR>

- A. THE PROGRAM WILL INHIBIT DATA ERROR MESSAGES OR WILL IDENTIFY DATA ERRORS WHICH OCCUR AT THE SPECIFIED ADDRESS, DEPENDING ON THE VALUE OF PARAMETER 'NOTPRT'.
- B. LEADING ZEROS ARE NOT REQUIRED.

FORMAT 2: C,T<CR>

- A. WHEN THIS FORMAT IS USED, THE ENTIRE TRACK WILL BE CONSIDERED BAD; DATA ERRORS WILL BE HANDLED AS IN 'FORMAT 1', ABOVE.

B. LEADING ZEROS ARE NOT REQUIRED.

FORMAT 3: C<CR>

- A. WHEN THIS FORMAT IS USED, THE ENTIRE CYLINDER WILL BE CONSIDERED BAD; DATA ERRORS WILL BE HANDLED AS IN 'FORMAT 1' ABOVE.
- B. LEADING ZEROS ARE NOT REQUIRED.

NOTE: CYLINDER, TRACK, AND SECTOR ENTRIES ARE IN DECIMAL.

THE OPERATOR MAY TERMINATE THE BAD ADDRESS ENTRY BY ENTERING A 'PERIOD' IN RESPONSE TO THE ENTRY REQUEST OR BY TERMINATING AN ENTRY WITH A 'PERIOD' INSTEAD OF A 'CARRIAGE RETURN'.

#### 4.4.1 'T' COMMAND

USED TO ASSIGN A DRIVE(S) FOR TEST. THIS COMMAND IS REQUIRED TO PERFORM THE TEST OF THE DRIVE(S). THE OTHER COMMANDS ARE CONVIENCE COMMANDS OR SUPPORT COMMANDS.

FORMAT: TN<CR>

N = DRIVE NUMBER. MAY BE 0 TO 7 OR 'A'. ENTRY MUST BE TERMINIATED BY A CARRIAGE RETURN <CR>.

EXAMPLE: T0<CR> - ASSIGN DRIVE 0 FOR TEST  
TA<CR> - ASSIGN ALL AVAILABLE DRIVES FOR TEST

NOTE: DRIVE OPERATION BEGINS IMMEDIATELY AFTER COMMAND IS ENTERED.

#### 4.4.2 'D' COMMAND

USED TO DEASSIGN A DRIVE(S) BEING EXERCISED.

FORMAT: DN<CR>

N = DRIVE NUMBER. MAY BE 0 TO 7 OR 'A'. ENTRY MUST BE TERMINIATED BY A CARRIAGE RETURN <CR>.

EXAMPLE: D0<CR> - DEASSIGN DRIVE 0  
DA<CR> - DEASSIGN ALL DRIVES BEING TESTED.

- NOTES:
1. IF THE 'D' COMMAND REFERENCES A DRIVE NOT ASSIGNED THE PROGRAM WILL TYPEOUT 'DRIVE NOT ASSIGNED'
  2. THE DRIVES WILL BE DEASSIGNED AS THEIR OPERATIONS COMPLETE.
  3. IF 'DA' IS USED, ONLY DRIVES BEING



TESTED WILL BE DEASSIGNED - THE  
ERROR MESSAGE IN (1) ABOVE WILL NOT  
BE DISPLAYED.

#### 4.4.3 'S' COMMAND

USED TO REQUEST A PERFORMANCE SUMMARY TYPEOUT FOR THE REFERENCED  
DRIVE(S).

FORMAT: SN<CR>

N = DRIVE NUMBER. MAY BE 0 TO 7 OR 'A'. ENTRY MUST BE  
TERMINATED BY A CARRIAGE RETURN <CR>.

EXAMPLE: SO<CR> - TYPEOUT PERFORMANCE SUMMARY FOR DRIVE 0  
SA<CR> - TYPEOUT PERFORMANCE SUMMARY  
FOR ALL DRIVES BEING TESTED.

- NOTES:
1. IF 'SA' IS USED ONLY DRIVES BEING TESTED WILL  
BE DISPLAYED.
  2. IF PARAMETER 'INTRVL' IS NOT ZERO, THE PROGRAM  
WILL AUTOMATICALLY DISPLAY A PERFORMANCE SUMMARY  
FOR EACH DRIVE BEING TESTED AT A RATE DETERMINED BY  
'INTRVL'.
  3. IF THE 'SA' COMMAND IS USED, THE PROGRAM WILL TYPEOUT  
THE OPERATOR ENTERED DATE, OPERATOR I.D., AND THE DRIVE  
I.D. FOR EACH DRIVE BEING TESTED. THE DATE AND OPERATOR  
I.D. WILL NOT BE TYPED OUT IF NO DRIVES ARE BEING TESTED.

#### 4.4.4 'W' COMMAND

USED TO WRITE A DATA PACK WITH DATA ACCEPTABLE TO THE RPO4/5/6 MULTI-  
DRIVE EXERCISER PROGRAM.

FORMAT: WN<CR>

N = DRIVE NUMBER. MAY BE 0 TO 7 OR 'A'. ENTRY MUST BE  
TERMINATED BY A CARRIAGE RETURN <CR>.

EXAMPLE: WA<CR> - WRITE DATA PACKS ON ALL AVAILABLE DRIVES.  
WD<CR> - GENERATE A DATA PACK ON DRIVE 0.

- NOTES:
1. DATA PACKS GENERATED BY THE RPO4/5/6 FORMATTER PROGRAM  
(MD-11-DZRJB) OR BY THE RPO4/5/6 MECHANICAL & READ/WRITE  
PROGRAM (MD-11-DZRJA) TEST 20, ARE ACCEPTABLE. (PACKS  
WRITTEN BY TESTS 16, 17 OR 21 OF 'DZRJA' CANNOT BE USED  
AND MUST BE REWRITTEN.)
  2. THE 'W' COMMAND SHOULD NOT BE USED UNLESS 'MAXDL'  
PARAMETER IS APPROXIMATELY 1 TRACK IN SIZE - 5000 (10).  
IF THE BUFFER SIZE IS MUCH LESS THAN 1 TRACK, THE

TIME REQUIRED TO WRITE A DATA PACK IS TOO GREAT TO BE PRACTICAL.

3. THE 'W' COMMAND PERFORMS A SEQUENTIAL WRITE OF THE PACK USING A 'WRITE DATA' COMMAND. THE DATA PATTERN USED FOR EACH WRITE IS SELECTED RANDOMLY. HOWEVER, THE OPERATION OF THE COMMAND IS SEQUENTIAL, BEGINNING AT 'MINCYL', 'MINTRK' AND CONTINUING TO 'MAXCYL', 'MAXTRK'.
4. THE 'W' COMMAND DOES NOT WRITE HEADERS AND ASSUMES THAT THE FORMAT OF THE PACK IS GOOD.
5. THE 'W' COMMAND CANNOT BE STARTED IF SWITCH 0 (READ ONLY MODE) IS SET. IF SWITCH 0 SET DURING THE OPERATION OF THE 'W' COMMAND, THE DRIVE PERFORMING THE 'W' COMMAND WILL IGNORE THE SWITCH.
6. THE DATA WRITTEN IS VERIFIED BY A 'WRITE CHECK DATA' COMMAND.

#### 4.4.5 'R' COMMAND

USED TO PERFORM A SEQUENTIAL READ OF THE PACK.

FORMAT: RN<CR>

N = DRIVE NUMBER. MAY BE 0 TO 7 OR 'A'. ENTRY MUST BE TERMINATED BY A CARRIAGE RETURN <CR>.

EXAMPLE: RA<CR> - READ THE PACKS ON ALL OF THE ONLINE DRIVES.  
RD<CR> - READ THE PACK ON DRIVE 0.

- NOTES:
1. THE PROGRAM WILL PERFORM A NORMAL CHECK OF ALL DATA READ. HOWEVER, ALL OPERATIONS WILL BE SEQUENTIAL.
  2. THE PROGRAM WILL READ THE PACK STARTING AT THE ADDRESS SPECIFIED BY 'MINCYL', 'MINTRK' TO THE ADDRESS SPECIFIED BY 'MAXCYL', 'MAXTRK'. THE READ WILL BE SEQUENTIAL.

#### 4.4.6 GENERAL COMMAND INFORMATION

- A. WHEN A COMMAND IS ENTERED, THE PROGRAM WILL TYPE OUT THE TIME
- B. IF THE COMMAND ENTERED IS NOT VALID, THE PROGRAM WILL TYPE 'INVALID COMMAND'.
- C. DRIVES ASSIGNED (WITH THE 'T' COMMAND) OR DEASSIGNED (WITH THE 'D' COMMAND) MAY BE ENTERED IN ANY SEQUENCE.
- D. THE ERROR RESPONSES FROM THE PROGRAM ARE AS FOLLOWS

RESPONSE	COMMAND(S)
?UNIT N OFFLINE	T, W, R
?UNIT N NOT ASSIGNED	D, S
?UNIT N ALREADY ASSIGNED	T, W, R
?UNIT N NOT PRESENT	T, W, R
?UNIT N UNSAFE	T, W, R
?UNIT N NOT AN RP04/5/6	T, W, R

5. PERFORMANCE SUMMARY TYPEOUT

5.1 THE PROGRAM WILL DISPLAY A PERFORMANCE SUMMARY FOR THE DRIVES BEING EXERCISED. THIS SUMMARY WILL BE DISPLAYED AUTOMATICALLY IF THE PARAMETER 'INTRVL' IS NOT ZERO OR CAN BE DISPLAYED ON REQUEST BY THE OPERATOR THROUGH THE USE OF THE 'S' COMMAND. THE PERFORMANCE SUMMARY TYPEOUT CONTAINS THE FOLLOWING FIELDS:

'DRV'	THE DRIVE NUMBER
'PASS'	THE PRESENT PASS COUNT FOR THE DRIVE
'ORDERS'	THE NUMBER OF ORDERS PERFORMED BY THE DRIVE
'SEEKS'	THE NUMBER OF SEEK OPERATIONS THE DRIVE PERFORMED
'WRDS XFER'	THE TOTAL NUMBER OF WORDS WRITTEN AND READ BY THE DRIVE
'WRDS READ'	THE TOTAL NUMBER OF WORDS READ BY THE DRIVE
'SOFT'	THE NUMBER OF SOFT DATA ERRORS
'HARD'	THE NUMBER OF HARD DATA ERRORS
'SKI'	THE NUMBER OF 'SKI' OR 'OCYL' ERRORS
'MISP'	THE NUMBER OF POSITIONING ERRORS
'OTHER'	THE TOTAL ERRORS OF OTHER TYPES

NOTE: ERRORS EM1, EM2, EM3, EM4, EM5, & EM10 ARE NOT INCLUDED IN THE 'OTHER' ERROR TOTAL.

5.2 SOFT/HARD ERROR DEFINITIONS

5.2.1 HARD ERRORS

A. A 'DTE' (DRIVE TIMING ERROR) OR A 'DCK' (DATA CHECK ERROR) WHICH OCCURS DURING A READ DATA OR A READ HEADER & DATA OPERATION AND IS NOT CORRECTED OR BECOMES CORRECTABLE AFTER THE PROGRAM HAS PERFORMED THE COMPLETE RETRY SEQUENCE ON THE BAD SECTOR. THE RETRY SEQUENCE IS 16 RE-READS AT TRACK CENTER AND 2 ATTEMPTS AT EACH OF THE FOLLOWING OFFSETS:

RP04/5	RP06
+400 MICRO-INCHES	+200 MICRO-INCHES
-400 MICRO-INCHES	-200 MICRO-INCHES
+800 MICRO-INCHES	+400 MICRO-INCHES
-800 MICRO-INCHES	-400 MICRO-INCHES

+1200 MICRO-INCHES  
-1200 MICRO-INCHES+800 MICRO-INCHES  
-800 MICRO-INCHES

## 5.2.2 SOFT ERRORS

- A. ECC CORRECTABLE 'DCK' ERRORS.
- B. 'DCK' & 'ECH' ERRORS WHICH BECOME ECC CORRECTABLE DURING RETRY OR WHICH ARE READ CORRECTLY DURING RETRY.
- C. HEADER READ ERRORS - READ DATA, READ HEADER & DATA, OR WRITE DATA ORDERS.
- D. 'DTE' ERRORS WHICH ARE CORRECTED OR WHICH BECOME ECC CORRECTABLE 'DCK' ERROR DURING THE RETRY SEQUENCE.

6. DATA CHECKING & ERROR RECOVERY  
-----

## 6.1 DATA COMPARISON

DATA COMPARISON OCCURS AFTER EACH 'RDDAT' (READ DATA) OR 'RDHD' (READ HEADER AND DATA) OPERATION UNDER THE FOLLOWING CONDITIONS:

- A. THE ORDER TERMINATED WITH NO ERROR.
- B. THE OPERATION TERMINATED WITH 'DCK' SET AND THE ERROR IS ECC CORRECTABLE OR THE SECTOR IN ERROR IS READ CORRECTLY AFTER RETRY ATTEMPTS.

## 6.2 VERIFICATION OF DATA WRITTEN

AFTER EACH WRITE OPERATION, THE DATA WRITTEN IS CHECKED WITH THE APPROPRIATE WRITE CHECK COMMAND - IF PARAMETER 'AUTOCK' IS 1. (IF 'AUTOCK' IS 0, WRITE CHECKS WILL BE PERFORMED RANDOMLY.)

## 6.3 SECTOR REFORMATTING

THE PROGRAM WILL REFORMAT AN UNCORRECTABLE ERROR SECTOR IN THE FOLLOWING CASES (PARAMETER 'FORMAT' MUST BE SET AND SW<00> = 0). THIS PREVENTS THE SAME ERROR FROM BEING CONTINUOUSLY REPORTED.

- A. DATA CHECK ERRORS - EM21
- B. HEADER READ ERRORS - EM20, EM24, EM25, EM26, EM27
- C. DRIVE TIMING ERRORS - EM31
- D. OPERATION INCOMPLETE ERRORS - EM32
- E. WRITE CHECK ERRORS - EM22, EM23

## 6.4 BAD TRACK/SECTOR FLAGGING

SINCE THE RPO4 SUBSYSTEM DOES NOT HAVE AN AUTOMATIC BAD TRACK HANDLING CAPABILITY, THE MULTIDRIVE EXERCISER ALLOWS THE OPERATOR TO IDENTIFY UP TO 8 BAD TRACK/SECTOR LOCATIONS WHEN THE DRIVE IS ASSIGNED FOR TEST. (SEE SECTION 4.1 FOR ADDITIONAL INFORMATION.)

IF ONE OF THE FOLLOWING ERRORS OCCURS AT A LOCATION IDENTIFIED BY THE OPERATOR, THE PROGRAM WILL INHIBIT THE ERROR REPORT FOR THAT ERROR.

DATA CHECK ERRORS ('DCK')  
WRITE CHECK ERRORS ('WCE')  
OPERATION INCOMPLETE ERRORS ('OPI')  
DRIVE TIMING ERRORS ('DTE')  
HEADER READ ERRORS ('FER' & 'HCRC', 'HCE' & 'HCRC', 'HCRC')

OPTIONALLY, THE OPERATOR MAY REQUEST AN ERROR REPORT FOR FLAGGED AREAS. (PARAMETER 'NOTPRT' MUST BE SET TO 0 AT STARTUP.) THE PROGRAM WILL IDENTIFY ERROR MESSAGES ASSOCIATED WITH THE PACK; THESE ERRORS WILL NOT BE ADDED TO THE ERROR TOTALS MAINTAINED BY THE PROGRAM.

## 7. ERROR MESSAGES

DRIVE ERRORS ARE REPORTED ON THE TELETYPE OR (IF AVAILABLE) A LINE PRINTER. ALL ERROR CONDITIONS ARE REPORTED IN ERROR MESSAGES; THE PROGRAM CONTAINS NO CODED ERROR HALTS. IF THE PROGRAM HALTS (ASSUMING, OF COURSE, THAT SW<15> IS NOT SET), AN UNRECOVERABLE PROGRAM CONDITION HAS OCCURRED OR A CENTRAL PROCESSOR FAILURE HAS OCCURRED.

ERROR MESSAGES ARE MADE UP OF SEVERAL LINES. EACH TYPE OF ERROR HAS SEVERAL OPTIONAL LINES WHICH MAY APPEAR WITH IT. ALL OF THE POSSIBLE ERROR MESSAGE LINES WHICH MAY APPEAR ARE GIVEN IN THE SECTION DESCRIBING THE PARTICULAR ERROR HEADER.

### 7.1 ERROR DESCRIPTION LINES

MESSAGES EM1, EM2, EM3, EM4, EM5, EM10, EM11, & EM12 ARE ALWAYS DISPLAYED ON THE TTY. THE OTHER MESSAGES ARE DISPLAYED ON EITHER THE LINE PRINTER (IF AVAILABLE) OR THE TTY.

(THE MESSAGE TAGS ARE GIVEN FOR REFERENCE.)

MESSAGE  
TAG

TEXT

EM1	RH11 INTERRUPT OCCURRED (RPAS=0)
	THE RH11 INTERRUPTED AND THE ATTENTION SUMMARY REGISTER (RPAS) WAS CLEARED.
EM2	UNEXPECTED ATTENTION OCCURRED
	THE INDICATED DRIVE INTERRUPTED BUT THE DRIVE WAS NOT

- PERFORMING AN OPERATION.
- EM3 MASSBUS PARITY ERROR (MCPE=1)  
THE RH11 DETECTED A CONTROL BUS PARITY ERROR WHEN READING THE INDICATED REGISTER FROM THE INDICATED DRIVE.
- EM4 MASSBUS PARITY ERROR (PAR=1)  
THE INDICATED RPO4 DETECTED A CONTROL BUS PARITY ERROR WHEN THE RH11 LOADED THE SPECIFIED REGISTER.
- EM5 ADDRESS PLUG CHANGE BIT SET  
THE 'OPE' BIT WAS SET WHEN THE INDICATED DRIVE INTERRUPTED.
- EM6 RH11 DIDN'T RESPOND TO ADDRESSING  
WHEN THE PROGRAM ADDRESSED THE RH11, NO RESPONSE WAS RECEIVED FROM THE INDICATED ADDRESS.
- EM10 UNCORRECTABLE MASSBUS PARITY ERROR  
THE PROGRAM HAS TRIED 3 TIMES TO READ OR WRITE THE INDICATED REGISTER.
- EM11 FATAL MASSBUS PARITY ERROR  
A CONTROL BUS PARITY ERROR OCCURRED WHEN THE RH11 ATTEMPTED TO PROCESS A PREVIOUS, DIFFERENT PARITY ERROR.
- EM12 PERSISTENT DEVICE UNSAFE  
THE DRIVE BECAME UNSAFE; DRIVE CLEAR TO THE DRIVE DID NOT CLEAR THE UNSAFE CONDITION. THE PROGRAM WILL AUTOMATICALLY DEASSIGN THE DRIVE. THE DRIVE CANNOT BE EXERCISED UNTIL THE UNSAFE CONDITION HAS BEEN CLEARED.
- EM13 OPERATION NOT COMPLETED WITHIN TIME LIMIT  
THE DRIVE DID NOT COMPLETE THE OPERATION WITHIN 1 SECOND AFTER THE OPERATION WAS INITIATED.
- EM14 UNIT WENT OFFLINE  
THE DRIVE WENT OFFLINE DURING THE INDICATED OPERATION. (THE 'MOL' BIT BECAME ZERO.) THE PROGRAM WILL AUTOMATICALLY DEASSIGN THE DRIVE. THE OPERATOR MUST REASSIGN THE DRIVE WITH THE 'T' COMMAND TO RE-INITIATE TESTING.
- EM15 NO RESPONSE TO PORT REQUEST  
THE PROGRAM IS TESTING A DUAL PORT DRIVE WHICH HAS NOT SWITCHED

TO THE REQUESTING PORT WITHIN 10 SECONDS AFTER PORT REQUEST  
TO THE DRIVE FROM THE REPORTING PORT.

## EM20 HEADER CRC ERROR

A HEADER CRC ERROR WAS DETECTED AT THE INDICATED DISK ADDRESS.  
THE CONTENTS OF THE HEADER ARE DISPLAYED. THE OPERATION WILL  
BE RETRIED 3 TIMES.

## EM21 DATA CHECK ('DCK') ERROR

A DATA CHECK ERROR WAS DETECTED AT THE INDICATED SECTOR.  
THE FULL RETRY SEQUENCE (INCLUDING OFFSET) WILL BE INITIATED  
FOR THE SECTOR IN ERROR IF THE ECC HARD ERROR ('ECH') BIT  
IS SET.

## EM22 WRITE CHECK ERROR - DATA CHECK ('DCK') SET

A WRITE CHECK ERROR OCCURRED AND THE DATA CHECK ('DCK') BIT  
WAS SET. IF 'ECH' IS NOT SET, THE OPERATION WILL BE RETRIED  
UP TO 3 TIMES; IF THE 'ECH' BIT IS SET, THE OPERATION WILL  
BE RETRIED UP TO 16 TIMES.

## EM23 WRITE CHECK ERROR - DATA CHECK ('DCK') NOT SET

A WRITE CHECK ERROR OCCURRED AND 'DCK' WAS NOT SET. THE  
WORDS WHICH CAUSED THE ERROR ARE DISPLAYED IN THE ERROR  
MESSAGE. THE OPERATION WILL BE RETRIED 3 TIMES.

## EM24 HEADER READ ERROR - 'FMT' BIT DROPPED

A WRITE DATA, WRITE CHECK DATA, OR A READ DATA WAS BEING  
PERFORMED AND A 'FMT' ERROR OCCURRED. THE PROGRAM RE-READ THE  
HEADER OF THE ERROR SECTOR AND THE 'HCRC' BIT WAS SET. THE  
CONTENTS OF THE HEADER ARE DISPLAYED. THE OPERATION WILL  
BE RETRIED 3 TIMES.

## EM25 HEADER READ ERROR - HEADER COMPARE ('HCE') ERROR

SIMILAR TO EM24, EXCEPT THAT THE 'HCE' ERROR BIT WAS  
SET INITIALLY. THE OPERATION WILL BE RETRIED 3 TIMES.

## EM26 FORMAT ERROR ('FER')

FORMAT ERROR OCCURRED. WHEN THE HEADER WAS RE-READ, THE  
'HCRC' BIT WAS NOT SET. THE CONTENTS OF THE HEADER ARE  
DISPLAYED. THE OPERATION WILL BE RETRIED 3 TIMES.

## EM27 HEADER COMPARE ('HCE') ERROR

SIMILAR TO EM26 EXCEPT THAT THE 'HCE' BIT WAS SET INITIALLY.  
THE OPERATION WILL BE RETRIED 3 TIMES.

## EM30 MISCELLANEOUS DRIVE ERROR

THIS MESSAGE IS GIVEN FOR THE FOLLOWING ERROR BITS:  
'IXE', 'AOE', 'RMR', 'ILF', OR 'ILR'

- EM31 OPERATION INCOMPLETE ('OPI') ERROR  
AN OPERATION INCOMPLETE ERROR OCCURRED AT THE INDICATED SECTOR.
- EM32 DRIVE TIMING ('DTE') ERROR  
DRIVE TIMING ERROR OCCURRED ON THE INDICATED SECTOR. THE OPERATION WILL BE RETRIED 3 TIMES.
- EM33 PARITY ('PAR') ERROR AFTER OPERATION STARTED  
THE 'PAR' BIT WAS SET WHEN THE OPERATION WAS COMPLETED THE OPERATION WILL BE RETRIED 3 TIMES.
- EM34 WRITE CLOCK FAILURE ('WCF')  
A WRITE CLOCK FAILURE OCCURRED DURING THE OPERATION. THE OPERATION WILL BE RETRIED 3 TIMES.
- EM35 INVALID ADDRESS ('IAE') ERROR  
AN INVALID ADDRESS ERROR OCCURRED DURING THE OPERATION.
- EM36 WRITE LOCK ('WLE') ERROR  
A WRITE OPERATION WAS ATTEMPTED BUT THE DRIVE WAS WRITE LOCKED.
- EM40 RH11 OR UNIBUS TRANSFER ERROR  
'TRE' IS SET IN THE RH11 CONTROL REGISTER AND NO DRIVE ERROR HAS OCCURRED. THE OPERATION WILL BE RETRIED 3 TIMES IF THE ERROR WAS CAUSED BY 'DLT', 'LUPE', 'MXF', OR 'MDPE'.
- EM41 BUS ADDRESS OR WORD COUNT INCORRECT  
NO DRIVE ERROR OCCURRED BUT EITHER THE BUS ADDRESS INDICATES THAT AN INCORRECT NUMBER OF WORDS WERE TRANSFERED OR THE WORD COUNT REGISTER IS NOT ZERO.
- EM42 DATA COMPARE ERRORS - NO DRIVE ERROR DETECTED  
NO SUBSYSTEM ERROR WAS SIGNALLED; HOWEVER, THE DATA DOES NOT COMPARE.
- EM43 CAN'T MATCH DATA READ WITH A PATTERN  
THE DATA IN THE BUFFER DOES NOT MATCH ANY OF THE STANDARD



- PATTERNS.
- EM44 ERROR BIT(S) SET, BUT NO ERROR SIGNALLED BY THE RH11  
THE OPERATION COMPLETED NORMALLY; HOWEVER, THE PROGRAM FOUND EITHER ERROR BIT; IN THE RPO4 SET OR ERROR BITS IN THE RH11 SET.
- EM45 ECC LOGIC FAILURE  
THE CONTENTS OF EITHER THE ECC POSITION REGISTER (RPEC1) OR THE CONTENTS OF ECC PATTERN REGISTER (RPEC2) ARE NOT VALID. THE POSITION REGISTER IS EITHER '0' OR > 10041 (8) OR THE PATTERN REGISTER CONTAINS ZEROS.
- EM46 BUS ADDRESS OR WORD COUNT NOT CONSISTENT  
THE PROGRAM WAS PROCESSING AN ERROR AND FOUND THAT THE NUMBER OF WORDS TRANSFERED AS INDICATED BY THE BUS ADDRESS REGISTER DOES NOT AGREE WITH THE TRANSFER COUNT FROM THE WORD COUNT REGISTER.
- EM50 SEEK INCOMPLETE OR OFF CYLINDER ERROR  
THE DRIVE SIGNALLED EITHER 'SKI' OR 'OCYL' ERROR BITS.
- EM51 PROGRAM DETECTED POSITIONING ERROR  
A HEADER COMPARE ERROR OCCURRED ('HCE'); HOWEVER, WHEN THE PROGRAM EXAMINED THE HEADER OF THE SECTOR IN ERROR, IT FOUND THAT THE CYLINDER FIELD DID NOT AGREE WITH THE CONTENTS OF 'RPCC' OF THE DRIVE. THE DRIVE WILL BE RECALIBRATED.
- EM60 DEVICE UNSAFE  
THE INDICATED DRIVE UNSAFE ERROR OCCURRED; THE ERROR WAS CLEARED BY A 'DRIVE CLEAR' INSTRUCTION.

## 7.2 DETAIL ERROR LINES

THE LINE NUMBERS GIVEN BELOW ARE FOR REFERENCE ONLY.

LINE 1  
-----

TT:TT:TT (DESCRIPTION OF ERROR)

'TT:TT:TT' IS THE TIME SINCE THE PROGRAM WAS STARTED. TT:TT:TT IS GIVEN IN HOURS: MINUTES: SECONDS.

LINE 2  
-----

'PRESENT ORDER = XXXX PREVIOUS ORDER = YYYY'

MNEMONICS USED FOR THE ORDERS ARE DEFINED BELOW:

UNLOAD - UNLOAD (OCTAL 3)  
 SEEK - SEEK (OCTAL 5)  
 RECAL - RECALIBRATE (OCTAL 7)  
 DRVCLR - DRIVE CLEAR (OCTAL 11)  
 RELSE - RELEASE (OCTAL 13)  
 OFFSET - OFFSET (OCTAL 15)  
 RTC - RETURN TO CENTERLINE (OCTAL 17)  
 READIN - READIN PRESET (OCTAL 21)  
 PACK - PACK ACKNOWLEDGE (OCTAL 23)  
 SEARCH - SEARCH (OCTAL 31)  
 WCKD - WRITE CHECK DATA (OCTAL 51)  
 WCKHD - WRITE CHECK HEADER & DATA (OCTAL 53)  
 WRDAT - WRITE DATA (OCTAL 61)  
 WRTHD - WRITE CHECK HEADER & DATA (OCTAL 63)  
 RDDAT - READ DATA (OCTAL 71)  
 RDHD - READ HEADER & DATA (OCTAL 73)

(DISPLAY OF THE RP04/5/6 REGISTERS IN TWO GROUPS:  
 RPCS1, RPCS2, RPDS1, RPER1, RPER2, RPER3, RPEC1, & RPEC2 FORM THE FIRST  
 GROUP; ALL THE OTHER REGISTERS ARE IN THE SECOND GROUP.  
 IF SW<05> IS SET, ONLY THE REGISTERS IN THE FIRST GROUP WILL BE  
 DISPLAYED.)

THE ABOVE LINE WILL BE TYPED IF THE ERROR OCCURRED DURING  
 THE NON-DATA TRANSFER PART OF THE OPERATION.

'\* ERROR AT BAD TRACK/SECTOR'

THE ABOVE LINE WILL BE PRINTED IF A DATA ERROR OCCURS AT AN ADDRESS  
 ON THE PACK WHICH THE OPERATOR HAS IDENTIFIED AS BEING BAD. PARAMETER  
 'NOTPRT' MUST BE 0 FOR THE ERROR TO BE REPORTED.

A WORD CALLED 'STATUS' IS DISPLAYED WITH THE RP04/5/6 REGISTERS. THE  
 CONTENTS OF THIS WORD IDENTIFY HOW THE ERROR WAS PROCESSED BY THE  
 RP04/5/6 DRIVE HANDLER ROUTINE. THE BITS IN THIS WORD ARE ENCODED  
 AS FOLLOWS:

BIT #	MEANING IF BIT IS '1'
-----	-----
15	ERROR OCCURRED DONE (BIT07=0), BITS 14-9, 2, 1 SPECIFY TYPE DONE (BIT07=1), BITS 6-3 SPECIFY TYPE
14	DRIVE IS OFFLINE
12	PERSISTENT UNSAFE CONDITION EXISTS

11 UNCORRECTABLE PARITY ERROR OCCURRED  
10 FATAL PARITY ERROR OCCURRED. MASSBUS CLEAR  
WAS PERFORMED  
9 OPERATION NOT COMPLETED WITHIN 1 SECOND  
MASSBUS CLEAR PERFORMED. ALL OTHER  
OUTSTANDING OPERATIONS WERE RESTARTED.  
7 DONE - OPERATION COMPLETED  
6 DATA ERROR OCCURRED DURING THE TRANSFER  
5 ERROR OCCURRED WHILE SEARCHING FOR THE 'TRANSFER'  
SECTOR OR DURING RECALIBRATE OR OFFSET COMMANDS  
4 CORRECTABLE UNSAFE CONDITION OCCURRED  
3 DRIVE ERROR OCCURRED THAT CAUSED AN AUTOMATIC  
RECALIBRATE SEQUENCE  
2 PORT REQUEST TIMEOUT  
1 NON-EXISTENT DRIVE REQUESTED

LINE 3  
-----

ERROR AT CXXX TYY SZZ PREV ADDR = CUUU TVV SWW

THE ACTUAL ADDRESS OF THE ERROR SECTOR AND THE PREVIOUS  
DISK ADDRESS ARE GIVEN IN THIS LINE. CYLINDER, TRACK, &  
SECTOR ADDRESSES ARE IN DECIMAL.LINE 4  
-----

PRESENT ADDR = CXXX TYY SZZ PREV ADDR = CUUU TVV SWW

THIS LINE IDENTIFIES THE ADDRESS WHEN THE ERROR WAS DETECTED;  
THE PREVIOUS ADDRESS IS ALSO GIVEN. CYLINDER, TRACK, & SECTOR  
ADDRESSES ARE GIVEN IN DECIMAL.LINE 5  
-----

START CYL = XXX END CYL = YYY

THIS LINE IDENTIFIES THE STARTING CYLINDER OF A SEEK (IMPLIED)  
AND THE DESTINATION CYLINDER. CYLINDER ADDRESSES ARE IN  
DECIMAL.LINE 6  
-----

START CYL = XXX END CYL = YYY ACTUAL CYL = ZZZ

THIS LINE IDENTIFIES THE STARTING CYLINDER OF AN IMPLIED SEEK,  
THE DESTINATION CYLINDER, AND THE CYLINDER THE DISK ACTUALLY  
STOPPED AT. CYLINDER ADDRESSES ARE IN DECIMAL.

LINE 7  
-----

RPBA = XXXX RPWC = YYYY

THIS LINE GIVES THE CONTENTS OF THE RH11 BUFFER ADDRESS  
REGISTER AND THE RH11 WORD COUNT REGISTER. THIS LINE IS  
NOT PRINTED IF SW(05) IS NOT SET.

LINE 8  
-----

START CYL = XXX START TRK = YY START SECTOR = ZZ

THIS LINE IDENTIFIES THE STARTING DISK ADDRESS OF THE PRESENT  
OPERATION. CYLINDER, TRACK, AND SECTOR VALUES ARE DECIMAL.

LINE 9  
-----

RPDA = XXXX RPCA = YYYY

THIS LINE GIVES THE CONTENTS OF THE RPO4 TRACK AND SECTOR  
ADDRESS REGISTER AND THE CONTENTS OF THE DESIRED CYLINDER  
ADDRESS REGISTER. THIS LINE IS NOT PRINTED IF SW(05) IS NOT  
SET.

LINE 10  
-----

BUFFER ADDR = XXXX SIZE = YYYY ACTUAL NUMBR WRDS XFRD = ZZZZ

THIS LINE GIVES THE STARTING ADDRESS OF THE BUFFER USED FOR THE  
CURRENT DATA TRANSFER OPERATION, ITS SIZE, AND THE ACTUAL NUMBER  
OF WORD TRANSFERED. THE STARTING ADDRESS OF THE BUFFER IS IN  
OCTAL, THE SIZE AND WORD TRANSFERED VALUE ARE IN DECIMAL.

LINE 11  
-----

GOOD DATA = XXXX BAD DATA = YYYY SECT POS = ZZZ

THIS LINE GIVES THE GOOD DATA, THE ACTUAL DATA FROM THE DISK,  
AND THE LOCATION IN THE SECTOR OF THE ACTUAL DATA. THE SECTOR  
POSITION IS IN DECIMAL.

LINE 12

-----

HEADER CONTENTS OF ERROR SECTOR = XXXX XXXX XXXX XXXX

THIS LINE GIVES THE CONTENTS OF THE HEADER OF THE SECTOR WHICH  
GAVE THE ERROR.LINE 13  
-----

RPEC1 = XXXX RPEC2 = YYYY

THIS LINE WILL BE PRINTED AFTER A SUCCESSFUL RETRY OF A SECTOR  
WHICH BECAME ECC CORRECTABLE DURING RETRY.LINE 14  
-----

ECC CORRECTABLE WITHOUT OFFSET

THE SECTOR IN ERROR IS ECC CORRECTABLE; NO RETRY ATTEMPTS ARE  
NECESSARY.LINE 15  
-----

READ CORRECTLY AT OFFSET X MICRO-INCHES

THE SECTOR IN ERROR WAS READ WITHOUT ERROR AT THE INDICATED  
OFFSET VALUE.LINE 16  
-----

ECC CORRECTABLE AT OFFSET X MICRO-INCHES

THE SECTOR IN ERROR BECAME ECC CORRECTABLE AT THE INDICATED  
OFFSET.LINE 17  
-----

CORRECTED ON X RETRY

THE OPERATION WAS PERFORMED ERROR FREE ON THE INDICATED RETRY  
ATTEMPT.LINE 18  
-----

UNCORRECTABLE AFTER X RETRIES

THE OPERATION CANNOT BE PERFORMED CORRECTLY AFTER THE  
INDICATED NUMBER OF RETRY ATTEMPTS.

LINE 19  
-----

DIFFERENT ERROR DURING RETRY

WHILE THE PROGRAM WAS RETRYING THE ERROR, A DIFFERENT OCCURRED.  
IF THIS LINE IS PRINTED, THE RH11-RP04 REGISTERS WILL ALSO BE  
PRINTED (SEE LINE 2).

LINE 20  
-----

DATA COMPARISON ERRORS

A PRINTOUT OF THE DATA COMPARISON ERRORS FOLLOW THIS LINE.

LINE 21  
-----

TOTAL COMPARE ERRORS = XXXX

THIS LINE GIVES THE TOTAL DATA COMPARISON ERROR COUNT. THE  
VALUE GIVEN IS IN DECIMAL.

LINE 22  
-----

THE DATA COMPARED OK

THIS LINE INDICATES THE RESULTS OF THE DATA COMPARISON FOLLOWING  
ECC CORRECTION.

LINE 23  
-----

ECC CORRECTION RESULTS

THE PROGRAM PERFORMED ECC CORRECTION AND THE RESULTS ARE REPORTED.  
THE ADDRESS IN MEMORY OF THE WORD(S) IN ERROR ARE GIVEN, THE WORD(S)  
BEFORE CORRECTION AND THE WORD(S) AFTER CORRECTION ARE PRINTED.

LINE 24  
-----

ERROR BURST BEGINS AT WORD XXX IN DATA FIELD OF ERROR SECTOR

THIS IS AN INFORMATIONAL LINE WHICH WILL BE PRINTED FOR 'DCK' ERRORS  
WHICH ARE ECC CORRECTABLE OR WHICH BECOME ECC CORRECTABLE DURING  
RETRY. 'XXX' IS THE WORD OFFSET VALUE FROM 'RPEC1' AND IS IN  
DECIMAL.

LINE 25  
-----

ERROR WAS NOT IN THE DATA READ -  
ECC CORRECTION CAN'T BE PERFORMED

THE DATA ERROR WAS NOT IN DATA TRANSFERED TO MEMORY.

LINE 26  
-----

CONTENTS OF THE ERROR SECTOR (REPORTED ABOVE)

IF SW(03) IS SET, THE SECTOR WHICH GAVE THE 'DCK', 'DTE' OR,  
'WCF' ERROR OR 'HARD' DATA CHECK ERROR IS PRINTED. THE  
CONTENTS OF THE SECTOR FOLLOW THIS LINE.

LINE 27  
-----

ORDERS: WWW ERRORS: X WRDS XFR: YYYY WRDS READ: ZZZZ

THIS IS THE LAST LINE PRINTED FOR ALL NON-POSITIONING  
TYPE ERRORS.

'ORDERS' IS THE TOTAL NUMBER OF COMMANDS GIVEN TO THE DRIVE  
WHICH REPORTED THE ERROR.

'ERRORS' IS THE TOTAL ERROR COUNT FOR THE DRIVE AND INCLUDES  
EVERY ERROR DETECTED, REGARDLESS OF TYPE.

'WRDS XFR' IS THE TOTAL NUMBER OF WORDS WRITTEN AND READ BY  
THE DRIVE.

'WRDS READ' IS THE TOTAL NUMBER OF WORD READ BY THE DRIVE.

LINE 28  
-----

ORDERS: WWWW TOTAL SEEKS: XXX TOTAL POS ERR = YYY TOTAL SKI, OCYL ERR = Z

THIS IS THE LAST LINE PRINTED FOR ALL POSITIONING TYPE ERRORS.

'ORDERS' IS THE TOTAL NUMBER OF ORDERS GIVEN TO THE DRIVE WHICH  
REPORTED THE ERROR.

'TOTAL SEEKS' IS THE TOTAL NUMBER OF SEEK OPERATIONS PERFORMED  
BY THE DRIVE.

'TOTAL POS ERR' IS THE TOTAL NUMBER OF POSITIONING ERRORS WHICH  
THE PROGRAM DETECTED FOR THE DRIVE.

'TOTAL SKI, OCYL ERR' IS THE TOTAL NUMBER OF 'SKI' OR 'OCYL' ERRORS  
SIGNALLED BY THE DRIVE.

3/4

8. PROGRAM DESCRIPTION  
-----

## 8.1 PROGRAM OPERATION

WHEN THE PROGRAM IS STARTED, ALL TABLES AND PARAMETERS ARE CLEARED OR INITIALIZED. THE PARAMETERS WHICH ARE UNDER OPERATOR TTY ENTRY CONTROL ARE CHECKED FOR VALIDITY AND CONSISTENCY. RH11 INTERRUPT ENABLE ('IE') IS SET, TTY KEYBOARD INTERRUPT ENABLE IS SET, AND THE KW11-L OR KW11-P CLOCK IS STARTED. WHEN THESE ACTIONS HAVE BEEN COMPLETED, THE PROGRAM TYPES OUT 'PROGRAM INITIALIZE COMPLETE'. COMMAND ENTRIES WILL NOW BE ACCEPTED BY THE PROGRAM.

THE PROGRAM SCANS ITS INTERNAL ASSIGNMENT TABLES, LOOKING FOR:

- 1) DRIVES TO ASSIGN/DEASSIGN
- 2) PERFORMANCE SUMMARY TYPEOUT REQUESTS
- 3) DRIVES REQUIRING COMMAND INITIATION, BUFFER ASSIGNMENT, OR PARAMETER SELECTION.
- 4) DRIVES COMPLETING CURRENT OPERATIONS.

THE PROGRAM CONTINUES SCANNING ITS TABLES UNTIL AN ENTRY IS FOUND. IN THE CASE OF THE PROGRAM AT INITIAL START, THE FIRST ENTRY WILL BE MADE BY THE OPERATOR WHEN A DRIVE IS ASSIGNED ('T' COMMAND).

WHEN A DRIVE IS ASSIGNED, THE KEYBOARD ENTRY ROUTINE VERIFIES THAT THE DRIVE IS PRESENT, IS AN RPO4/5/6, AND IS ONLINE. THE ASSIGNMENT ROUTINE THEN ISSUES A 'READIN PRESET' INSTRUCTION, SETS 'FMT22', AND ISSUES A 'RECALIBRATE' INSTRUCTION.

PARAMETERS FOR THE OPERATION ARE SELECTED AND A BUFFER IS ASSIGNED. IF THE OPERATION IS A WRITE OR WRITE CHECK ORDER, THE ASSIGNED BUFFER WILL BE FILLED WITH THE SELECTED PATTERN. (WRITE CHECK ORDERS ARE ISSUED AFTER EACH WRITE ORDER. THE WRITE CHECK ORDER USES THE PARAMETERS SELECTED FOR THE PRECEDING WRITE ORDER.) CONTROL IS THEN PASSED TO THE COMMAND INITIATION ROUTINE.

THE COMMAND INITIATION ROUTINE FIRST LOOKS AT THE CYLINDER ADDRESS OF THE REQUESTED OPERATION. IF THE DRIVE MUST SEEK TO ANOTHER CYLINDER TO PERFORM THE OPERATION, THE PROGRAM ISSUES A SEARCH INSTRUCTION TO THE DRIVE WITH A 'TARGET' SECTOR WHICH IS 8 SECTORS EARLIER THAN THE 'TRANSFER' SECTOR. (THIS ALLOWS THE PROGRAM TO INITIATE OPERATIONS ON ANOTHER DRIVE WHILE THE PRESENT DRIVE, OR OTHER DRIVES, ARE SEARCHING FOR 'TARGET' SECTORS. ALL SEEKS ISSUED BY THE PROGRAM ARE IMPLIED SEEK SEARCH OPERATIONS.) WHEN A SEARCHING DRIVE FINDS THE 'TARGET' SECTOR AND INTERRUPTS, THE PROGRAM READS THE LOOK AHEAD REGISTER (RPLA) OF THE INTERRUPTING DRIVE AND COMPARES THE POSITION OF THE DISK WITH THAT OF THE DESIRED SECTOR.

IF OTHER DRIVES ARE WAITING ON CYLINDER, THEY ARE ALSO CHECKED. THE PROGRAM THEN ISSUES THE REQUESTED ORDER TO THE DRIVE NEAREST ITS TRANSFER SECTOR. THE DRIVES NOT SELECTED WILL HAVE ANOTHER SEARCH INITIATED. IF A DRIVE IS NOT SELECTED FOR TRANSFER AFTER THREE



REVOLUTIONS OF ITS DISK, IT IS GIVEN PRIORITY OVER DRIVES WHICH HAVE NOT BEEN ON CYLINDER AS LONG.

WHEN THE DATA TRANSFER OPERATION IS COMPLETE, THE DRIVE REGISTERS ARE STORED AND A DATA TRANSFER IS INITIATED FOR A WAITING DRIVE.

IF THE OPERATION HAS BEEN COMPLETED NORMALLY, THE SAVED DRIVE REGISTERS ARE CHECKED TO VERIFY THAT NO ERROR BITS ARE SET; THE RH11 BUS ADDRESS AND WORD COUNT ADDRESS REGISTERS ARE CHECKED TO VERIFY THAT THE CORRECT NUMBER OF WORDS HAVE BEEN TRANSFERRED AND THAT THE TWC REGISTERS ARE CONSISTENT WITH EACH OTHER; AND IF THE ORDER WAS A READ ORDER, THE DATA BUFFER IS COMPARED. WHEN THIS SEQUENCE IS COMPLETED, THE DRIVE IS RETURNED TO THE ASSIGNED, INACTIVE LIST. THE PROGRAM THEN INITIATES A DATA TRANSFER ON A WAITING DRIVE AND RESELECTS AND REINITIATES ANOTHER OPERATION ON THE RELEASED DRIVE.

ERRORS WHICH OCCUR ARE PROCESSED IN THE FOLLOWING ORDER. MULTIPLE ERRORS WILL BE REPORTED AS THE FIRST ERROR TYPE CHECKED.

A. ERRORS REPORTED FOR OPERATIONS WHICH HAVE NOT COMPLETED NORMALLY.

PERSISTENT UNSAFE CONDITION - EM12  
UNCORRECTABLE MASSBUS PARITY ERROR - EM10  
FATAL MASSBUS PARITY ERROR - EM11  
OPERATION NOT COMPLETED WITHIN TIME LIMIT - EM13  
UNIT WENT OFFLINE - EM14

B. ERRORS REPORTED FOR OPERATIONS WHICH COMPLETE NORMALLY.

CORRECTABLE UNSAFE - EM60  
DRIVE TIMING ERROR - EM32  
DATA CHECK ERROR - EM21  
WRITE CHECK WITH DCK SET - EM22  
HEADER CRC ERRORS - EM20  
FORMAT ERRORS - EM24, EM26  
HEADER COMPARE ERRORS - EM25, EM27  
PROGRAM DETECTED POSITIONING ERROR - EM51  
SEEK INCOMPLETE OR OFF CYLINDER ERROR - EM50  
WRITE CHECK WITHOUT 'DCK' SET - EM23  
RH11 OR UNIBUS TRANSFER ERROR - EM40  
'CPI' ERROR - EM31  
'PAR' ERROR - EM33  
'WCF' ERROR - EM34  
'IAE' ERROR - EM35  
'WLE' ERROR - EM36  
MISCELLANEOUS DRIVE ERROR - EM30

C. ERRORS NOT FLAGGED BY THE HARDWARE ERROR DETECTION LOGIC.

BUS ADDRESS OR WORD COUNT INCORRECT - EM41  
DATA COMPARE ERRORS - NO DRIVE ERROR DETECTED - EM42  
CAN'T MATCH DATA READ WITH A PATTERN - EM43  
ERROR BIT(S) SET, BUT NO ERROR SIGNALLED BY THE RH11 - EM44  
ECC LOGIC FAILURE - EM45

BUS ADDRESS OR WORD COUNT NOT CONSISTENT - EM46

## 8.2 DUAL PORT OPERATION

DUAL PORT OPERATION IS NEARLY IDENTICAL TO THE OPERATION DESCRIBED IN SECTION 8.1. THE DIFFERENCES ARE IN COMMAND SEQUENCE INITIATION AND ORDER TERMINATION.

WHEN THE DUAL PORT HANDLER ROUTINE IN THE MULTIDRIVE PROGRAM RECEIVES A REQUEST FOR A DRIVE, THE PROGRAM VERIFIES THAT THE DRIVE IS ONLINE. THE DRIVE IS SELECTED AND 0'S ARE WRITTEN INTO 'RPDS1': IF THE DRIVE IS IN NEUTRAL, THIS WILL SEIZE THE DRIVE. IF THE DRIVE IS SEIZED BY THE OTHER PORT, WRITING INTO 'RPDS1' WILL SET 'PORT REQUEST'. THE PROGRAM CHECKS 'DVA' IN 'RPCS1'. IF THE DRIVE IS AVAILABLE AS INDICATED BY THE 'DVA' BIT, THE COMMAND SEQUENCE WILL BE INITIATED IN THE NORMAL MANNER (SEE SECTION 8.1 ABOVE). IF 'DVA' WAS NOT SET, THE PROGRAM MAKES AN ENTRY FOR THE DRIVE IN AN INTERNAL 'PORT REQUEST PENDING' TABLE AND STARTS A 20 SECOND TIMER FOR THE DRIVE. IF THE DRIVE HAS NOT SWITCHED TO THE REQUESTING SYSTEM WITHIN THE 20 SECOND INTERVAL, THE PROGRAM REPORTS A 'NO RESPONSE TO PORT REQUEST' ERROR. NORMALLY THIS ERROR MESSAGE INDICATES A FAILURE IN THE DUAL PORT CONTROL LOGIC IN THE DRIVE BEING TESTED; HOWEVER, UNDER CERTAIN CONDITIONS (E.G. MASSBUS PARITY ERRORS BEING REPORTED ON THE OTHER SYSTEM ON A MOD33 TTY), THE OTHER PROCESSOR WAS UNABLE TO PROCESS THE DRIVE AFTER IT HAD REQUESTED THE DRIVE. THE OPERATOR MUST BE AWARE OF WHAT THE OTHER SYSTEM IS DOING AT ALL TIMES TO INTERPRET THE PORT RELATED ERROR MESSAGES PROPERLY.

AFTER A DRIVE HAS COMPLETED AN OPERATION, THE PROGRAM WILL STORE THE REGISTERS AND ISSUE A 'RELEASE' TO THE DRIVE. IF THE OPERATION TERMINATED WITH AN ERROR, THE DRIVE WILL NOT BE RELEASED UNTIL ERROR PROCESSING HAS BEEN COMPLETED.

SINGLE PORT DRIVES, DRIVES WHICH ARE IN NEUTRAL BUT NOT BEING EXERCISED BY THE OPPOSITE PORT ARE STILL TREATED AS DUAL PORT DRIVES IN THAT A RELEASE COMMAND IS ISSUED AT THE END OF NORMAL ORDER PROCESSING OR AT THE END OF ERROR PROCESSING. A RELEASE COMMAND ISSUED UNDER THESE CONDITIONS HAS NO FUNCTIONAL EFFECT ON THE OPERATION OF THE DRIVE.

## 8.3 SELECTION OF OPERATION VARIABLES

A. SECTOR ADDRESS SELECTION IS RANDOM BETWEEN THE VALUES IN 'MINSEC' AND 'MAXSEC'. TRACK ADDRESS SELECTION IS RANDOM BETWEEN THE VALUES IN 'MINTRK' AND 'MAXTRK'. CYLINDER ADDRESS SELECTION IS RANDOM BETWEEN 'MINCYL' AND 'MAXCYL'. IF A MINIMUM ADDRESS IS GREATER THAN THE CORRESPONDING MAXIMUM ADDRESS, THE PROGRAM WILL EXCLUDE ALL ADDRESSES BETWEEN 'MAX' AND 'MIN' FROM THE SELECTION. FOR EXAMPLE: IF 'MINTRK' IS 18 AND 'MAXTRK' IS 5, THEN TRACK ADDRESS SELECTION WILL EXCLUDE TRACKS 6 - 17 FROM THE SELECTION AND SELECT AN ADDRESS FROM AMONG ADDRESSES 18, 0, 1, 2, 3, 4, 5.

- B. THE BUFFER SIZE IS RANDOMLY SELECTED BETWEEN 4 (10) - AND THE VALUE IN 'MAXDL'. THE SIZE SELECTED IS WEIGHTED TO ENSURE THAT AT LEAST 4 WORDS ARE WRITTEN IN THE DATA AREA OF THE LAST SECTOR. THIS IS NECESSARY AS THE PROGRAM REQUIRES 4 LOCATIONS IN THE DATA PORTION OF THE SECTOR TO BE ABLE TO MATCH THE DATA TO A PATTERN FOR DATA COMPARISON PURPOSES.
- C. THE DATA WRITTEN IS RANDOMLY SELECTED AMONG THE 15 STANDARD PATTERNS. THE KEYWORDS IN THE HEADER (WHEN PERFORMING A WRITE HEADER & DATA ORDER) ARE ZERO FILLED. THE PROGRAM EXPECTS TO FIND THAT THE KEYWORDS ARE ZERO.
- D. THE ORDERS ARE SELECTED RANDOMLY. WRITE CHECK DATA AND WRITE CHECK HEADER & DATA ORDERS ARE PERFORMED ONLY IF THE PREVIOUS ORDER WAS THE APPROPRIATE DATA ORDER. IF THE 'FORMAT' PARAMETER IS ZERO, THE PROGRAM WILL NOT SELECT WRITE HEADER & DATA (AND WRITE CHECK HEADER & DATA) ORDERS. WHEN THE PROGRAM SELECTS A WRITE HEADER & DATA ORDER, THE BUFFER SIZE IS FORCED TO 260 (10); THE PROGRAM WILL NOT PERFORM A MULTI-SECTOR FORMAT WRITE OPERATION.
- E. THE FIRST ORDER PERFORMED AFTER A UNIT IS ASSIGNED WITH A 'T', 'W', OR 'R' COMMAND IS NOT RANDOMLY SELECTED. THE PARAMETERS FOR THE FIRST OPERATION ARE THE MINIMUM OR STARTING VALUES OF THE VARIABLES.

#### 8.4 DATA PATTERNS

THE PROGRAM SELECTS ONE OF THE FOLLOWING DATA PATTERNS TO WRITE WHEN A WRITE ORDER IS SELECTED. THE ENTIRE BUFFER IS FILLED WITH THE SELECTED PATTERN. WHEN DATA IS READ FROM THE DISK, THE PROGRAM COMPARES DATA ON A SECTOR BASIS: FROM THE FIRST 4 DATA WORDS OF EACH SECTOR, THE PROGRAM MATCHES THE DATA TO ONE OF THE FOLLOWING PATTERNS. TO MAINTAIN COMPATIBILITY WITH PACKS WRITTEN BY THE FORMAT PROGRAM (MAINDEC-11-DZRJB), THE PROGRAM WILL ACCEPT ALL ZERO'S AND ALL ONE'S PATTERNS; HOWEVER, ALL ZERO'S AND ALL ONE'S PATTERNS ARE NOT WRITTEN BY THE EXERCISER PROGRAM.

PATTERN '8' IS DEFINED AS THE 'WORST CASE' PATTERN.

PAT 1	PAT 2	PAT 3	PAT 4	PAT 5	PAT 6	PAT 7	PAT 8
000001	177776	000000	000000	052525	007417	026455	165555
000003	177774	000000	010421	052525	007417	026455	133333
000007	177770	000000	021042	052525	007417	026455	165555
000017	177760	177777	031463	125252	170360	151322	133333
000037	177740	177777	042104	125252	170360	151322	165555
000077	177700	177777	052525	125252	170360	151322	133333
000177	177600	000000	063146	052525	007417	026455	165555
000377	177400	000000	073567	052525	007417	026455	133333
000777	177000	177777	104210	125252	170360	151322	165555
001777	176000	177777	114631	125252	170360	151322	133333
003777	174000	000000	125252	052525	007417	026455	165555
007777	170000	177777	135673	125252	170360	151322	133333

017777	160000	000000	146314	052525	007417	026455	165555
037777	140000	177777	156735	125252	170360	151322	133333
077777	100000	000000	167356	052525	007417	026455	165555
177777	000000	177777	177777	125252	170360	151322	133333

PAT 9	PAT 10	PAT 11	PAT 12	PAT 13	PAT 14	PAT 15
000001	177776	172666	077777	153333	000000	177777
000002	177775	155555	137777	066667	177777	000000
000004	177773	172666	157777	153333	177777	000000
000010	177767	155555	167777	066667	177777	000000
000020	177757	172666	173777	153333	177777	000000
000040	177737	155555	175777	066667	177777	000000
000100	177677	172666	176777	153333	177777	000000
000200	177577	155555	177377	066667	177777	000000
000400	177377	172666	177577	153333	177777	000000
001000	176777	155555	177677	066667	177777	000000
002000	175777	172666	177737	153333	177777	000000
004000	173777	155555	177757	066667	177777	000000
010000	167777	172666	177767	153333	177777	000000
020000	157777	155555	177773	066667	177777	000000
040000	137777	172666	177775	153333	177777	000000
100000	077777	155555	177776	066667	177777	000000

9. PROGRAM LISTING

-----

*Handwritten marks*

K03

.MAIN. MACY11 27(655) 28-APR-76 17:08 PAGE 35  
DZRJDA.DOC


SEQ 0035

2  
.END

ERRORS DETECTED: 0

\*.DZRJDA/SOL=DZRJDA.DOC  
RUN-TIME: 6 11 0 SECONDS  
CORE USED: 3K

15	OPERATIONAL SWITCH SETTINGS
37	BASIC DEFINITIONS
150	RH11 REGISTERS
196	RPO4/5/6 REGISTERS
391	RPO4/5/6 DRIVER COMMANDS
416	TRAP CATCHER
425	STARTING ADDRESS(ES)
430	ACT11 HOOKS
440	COMMON TAGS
546	COMMON PARAMETERS
595	VALUES FOR FIRST OPERATION
618	TABLES, CONSTANTS, AND VARIABLE LOCATIONS
831	DATA PATTERNS
1126	ERROR POINTER TABLE
1187	SETUP AND INITIALIZATION ROUTINE
1198	INITIALIZE THE COMMON TAGS
1239	GET VALUE FOR SOFTWARE SWITCH REGISTER
1401	MAIN PROGRAM
3250	ERROR MESSAGE GENERATION ROUTINES
3692	GENERAL SUPPORT SUBROUTINES
5009	MACRO ROUTINES
5011	ERROR HANDLER ROUTINE
5053	ERROR MESSAGE TIMEOUT ROUTINE
5101	TYPE ROUTINE
5172	BINARY TO OCTAL (ASCII) AND TYPE
5250	CONVERT BINARY TO DECIMAL AND TYPE ROUTINE
5318	TTY INPUT ROUTINE
5427	RANDOM NUMBER GENERATOR ROUTINE
5464	SAVE AND RESTORE RD-R5 ROUTINES
5510	DOUBLE LENGTH BINARY TO DECIMAL ASCII CONVERT ROUTINE
5573	DOUBLE LENGTH BINARY TO OCTAL ASCII CONVERT ROUTINE
5613	TRAP DECODER
5636	TRAP TABLE
5664	SINGLE/DUAL PORT RH11/RPO4/5/6 DRIVER (REV 1.0)
7083	DATA, CONTROL, & STATUS BLOCKS
7247	ERROR MESSAGES
7806	TELETYPE MESSAGES
8122	ROUTINE TO SIZE MEMORY
8153	BUSADR - GET BUS ADDRESS AND VECTOR ADDRESS FOR RH11
8217	CK.NUM - CHECK NUMBER (OCTAL)



M03

MD-11-DZRID-A. RPO4 5/6 MULTI-DRIVE EXERCISER MACY11 27(655) 28-APR-76 17:04 PAGE 1  
RPO456.010

SEQ 0037

1

100987654321  
11  
12  
13  
14  
15  
16  
17  
18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55  
56  
57  
58  
59  
60  
61  
62  
63  
64  
65  
66  
67  
68  
69  
70  
71  
72  
73  
74  
75  
76  
77  
78  
79  
80  
81  
82  
83  
84  
85  
86  
87  
88  
89  
90  
91  
92  
93  
94  
95  
96  
97  
98  
99  
100

```

.TITLE MD-11-DZRJD-A, RP04/5/6 MULTI-DRIVE EXERCISER
;*COPYRIGHT (C) 1975
;*DIGITAL EQUIPMENT CORP.
;*MAYNARD, MASS. 01754
*
*PROGRAM 3Y C. HESS
*
*THIS PROGRAM WAS ASSEMBLED USING THE PDP-11 MAINDEC SYSMAC
*PACKAGE (MAINDEC-11-DZQAC-C1),MAR 24, 1976.
*
.SBTTL OPERATIONAL SWITCH SETTINGS
*
*      SWITCH          USE
*-----
*      15             HALT ON ERROR
*      13             INHIBIT ERROR TYPEOUTS
*      10             BELL ON ERROR
*      7              DISPLAY ALL DATA COMPARE ERRORS
*      6              DON'T CHANGE PARAMETERS (LOOP ON PRESENT VALUES)
*      5              A. PARTIAL REGISTER DISPLAY IF ERROR
*                   B. NO ECC CORRECTION RESULTS DISPLAYED IF ERROR
*      4              A. DO NOT CHECK FOR MAXIMUM ERROR COUNTS
*                   B. DO NOT DROP DRIVE WHEN NORMAL END OF TEST REACHED
*      3              A. DISPLAY ERROR SECTOR IF 'DCK', 'DTE', OR 'WCF' ERROR
*                   B. DISPLAY SECTOR IF 'DCK' ERR UNCORRECTABLE AFTER
*                   28TH RETRY
*                   C. IF DATA COMPARE ERROR & SW7 SET, DISPLAY
*                   REMAINDER OF BUFFER
*      2              A. DON'T TYPE SUBSYSTEM STATUS WHEN PROGRAM STARTED
*                   B. DON'T TYPE PERFORMANCE SUMMARY
*      1              INHIBIT DATA COMPARSION AFTER READ ORDERS
*      0              READ ONLY MODE
*
.SBTTL BASIC DEFINITIONS
*
*INITIAL ADDRESS OF THE STACK POINTER *** 1100 ***
001100 STACK= 1100
.EQUIV EMT,ERROR      ;;BASIC DEFINITION OF ERROR CALL
.EQUIV IOT,SCOPE      ;;BASIC DEFINITION OF SCOPE CALL

*
*MISCELLANEOUS DEFINITIONS
000011 HT= 11          ;;CODE FOR HORIZONTAL TAB
000012 LF= 12          ;;CODE FOR LINE FEED
000015 CR= 15          ;;CODE FOR CARRIAGE RETURN
000200 CRLF= 200       ;;CODE FOR CARRIAGE RETURN-LINE FEED
177776 PS= 177776     ;;PROCESSOR STATUS WORD
.EQUIV PS,PSW
177774 STKLMT= 177774 ;;STACK LIMIT REGISTER
177772 PIRQ= 177772   ;;PROGRAM INTERRUPT REQUEST REGISTER
177570 DSWR= 177570   ;;HARDWARE SWITCH REGISTER
177570 DDISP= 177570  ;;HARDWARE DISPLAY REGISTER

*
*GENERAL PURPOSE REGISTER DEFINITIONS

```

15



02R0.019

BASIC DEFINITIONS

00000000  
00000001  
00000002  
00000003  
00000004  
00000005  
00000006  
00000007  
  
00000000  
00000040  
00001000  
00001400  
00002000  
00002400  
00003000  
00003400  
  
10000000  
04000000  
02000000  
01000000  
00400000  
00200000  
00100000  
00040000  
00020000  
00010000  
00004000  
00002000  
00001000  
00000400  
00000200  
00000100  
  
10000000  
04000000  
02000000  
01000000

00000000  
00000001  
00000002  
00000003  
00000004  
00000005  
00000006  
00000007

R0 = 0  
R1 = 1  
R2 = 2  
R3 = 3  
R4 = 4  
R5 = 5  
R6 = 6  
R7 = 7  
.EQUIV R6, SP  
.EQUIV R7, PC

:: GENERAL REGISTER  
:: GENERAL REGISTER  
:: GENERAL REGISTER  
:: GENERAL REGISTER  
:: GENERAL REGISTER  
:: GENERAL REGISTER  
:: GENERAL REGISTER  
:: GENERAL REGISTER  
:: STACK POINTER  
:: PROGRAM COUNTER

\*PRIORITY LEVEL DEFINITIONS

PR0 = 0  
PR1 = 40  
PR2 = 100  
PR3 = 140  
PR4 = 200  
PR5 = 240  
PR6 = 300  
PR7 = 340

:: PRIORITY LEVEL 0  
:: PRIORITY LEVEL 1  
:: PRIORITY LEVEL 2  
:: PRIORITY LEVEL 3  
:: PRIORITY LEVEL 4  
:: PRIORITY LEVEL 5  
:: PRIORITY LEVEL 6  
:: PRIORITY LEVEL 7

\*"SWITCH REGISTER" SWITCH DEFINITIONS

SW15 = 100000  
SW14 = 40000  
SW13 = 20000  
SW12 = 10000  
SW11 = 4000  
SW10 = 2000  
SW09 = 1000  
SW08 = 400  
SW07 = 200  
SW06 = 100  
SW05 = 40  
SW04 = 20  
SW03 = 10  
SW02 = 4  
SW01 = 2  
SW00 = 1  
.EQUIV SW09, SW9  
.EQUIV SW08, SW8  
.EQUIV SW07, SW7  
.EQUIV SW06, SW6  
.EQUIV SW05, SW5  
.EQUIV SW04, SW4  
.EQUIV SW03, SW3  
.EQUIV SW02, SW2  
.EQUIV SW01, SW1  
.EQUIV SW00, SW0

\*DATA BIT DEFINITIONS (BIT00 TO BIT15)

BIT15 = 100000  
BIT14 = 40000  
BIT13 = 20000  
BIT12 = 10000

004000  
002000  
001000  
000400  
000200  
000100  
000040  
000020  
000010  
000004  
000002  
000001  
  
000004  
000010  
000014  
000014  
000014  
000020  
000024  
000030  
000034  
000060  
000064  
000240  
  
000100  
000200  
000400  
001000  
002000  
020000  
040000

BIT11= 4000  
BIT10= 2000  
BIT09= 1000  
BIT08= 400  
BIT07= 200  
BIT06= 100  
BIT05= 40  
BIT04= 20  
BIT03= 10  
BIT02= 4  
BIT01= 2  
BIT00= 1  
.EQUIV BIT09,BIT9  
.EQUIV BIT08,BIT8  
.EQUIV BIT07,BIT7  
.EQUIV BIT06,BIT6  
.EQUIV BIT05,BIT5  
.EQUIV BIT04,BIT4  
.EQUIV BIT03,BIT3  
.EQUIV BIT02,BIT2  
.EQUIV BIT01,BIT1  
.EQUIV BIT00,BIT0

.\*BASIC "CPJ" TRAP VECTOR ADDRESSES  
ERRVEC= 4 : TIME OUT AND OTHER ERRORS  
RESVEC= 10 : RESERVED AND ILLEGAL INSTRUCTIONS  
TBITVEC=14 : "T" BIT  
TRTVEC= 14 : TRACE TRAP  
BPTVEC= 14 : BREAKPOINT TRAP (BPT)  
IOTVEC= 20 : INPUT/OUTPUT TRAP (IOT) \*\*SCOPE\*\*  
PWRVEC= 24 : POWER FAIL  
EMTVEC= 30 : EMULATOR TRAP (EMT) \*\*ERROR\*\*  
TRAPVEC=34 : "TRAP" TRAP  
TKVEC= 60 : TTY KEYBOARD VECTOR  
TPVEC= 64 : TTY PRINTER VECTOR  
PIRQVEC=240 : PROGRAM INTERRUPT REQUEST VECTOR

;;\*\*\*\*\*

.SBTTL RHI1 REGISTERS

;;\*\*\*\*\*

:CONTROL AND STATUS REGISTER 1 (RPCS1)

IE= 100 : INTERRUPT ENABLE (BIT #6)  
RDY= 200 : READY (BIT #7)  
A16= 400 : HIGH ORDER BUS ADDRESS BIT (BIT #8)  
A17= 1000 : HIGH ORDER BUS ADDRESS BIT (BIT #9)  
PSEL= 2000 : PORT SELECT (BIT #10)  
MCPE= 20000 : MASSBUSS PARITY ERROR (BIT #13)  
TRE= 40000 : TRANSFER ERROR (BIT #14)  
:SC= 100000 : SPECIAL CONDITION (BIT #15)

D2510.019 RH11 REGISTERS

16  
17  
18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55  
56  
57  
58  
59  
60  
61  
62  
63  
64  
65  
66  
67  
68  
69  
70  
71  
72  
73  
74  
75  
76  
77  
78  
79  
80  
81  
82  
83  
84  
85  
86  
87  
88  
89  
90  
91  
92  
93  
94  
95  
96  
97  
98  
99  
100

:WORD COUNT REGISTER (RPWC)  
:(EACH BIT IS CALLED BY BIT NUMBER)

:BUS ADDRESS REGISTER (RPBA)  
:(EACH BIT IS CALLED BY BIT NUMBER)

:CONTROL AND STATUS REGISTER 2 (RPCS2)

000001  
000002  
000004  
000010  
000020  
000040  
000100  
000200  
000400  
001000  
002000  
004000  
010000  
020000  
040000  
100000

US1= 1  
US2= 2  
US4= 4  
BAI= 10  
PAT= 20  
CLR= 40  
IR= 100  
OR= 200  
MPE= 400  
MXF= 1000  
PGE= 2000  
NEM= 4000  
NED= 10000  
LPE= 20000  
WCE= 40000  
DLT= 100000

:UNIT SELECT (BIT #0)  
:UNIT SELECT (BIT #1)  
:UNIT SELECT (BIT #2)  
:BUS ADDRESS INCREMENT INHIBIT (BIT #3)  
:MASSBUS PARITY TEST (BIT #4)  
:CLEAR (BIT #5)  
:INPUT READY (BIT #6)  
:OUTPUT READY (BIT #7)  
:MASS BUS PARITY ERROR (BIT #8)  
:MISSED TRANSFER ERROR (BIT #9)  
:PROGRAM ERROR (BIT #10)  
:NON EXISTENT MEMORY (BIT #11)  
:NON EXISTENT DRIVE (BIT #12)  
:UNIBUS PARITY ERROR (BIT #13)  
:WRITE CHECK ERROR (BIT #14)  
:DATA LATE (BIT #15)

:DATA BUFFER REGISTER (RPDB)  
:(EACH BIT IS CALLED BY BIT NUMBER)

::\*\*\*\*\*

.SBTTL RPC4/5/6 REGISTERS

::\*\*\*\*\*

:CONTROL AND STATUS 1 REGISTER. (#00)

000001  
000002  
000004  
000010  
000020  
000040  
004000

GO= 1  
F1= 2  
F2= 4  
F3= 10  
F4= 20  
F5= 40  
DVA= 4000

:GO BIT (BIT #0)  
:FUNCTION CODE BIT #1  
:FUNCTION CODE BIT #2  
:FUNCTION CODE BIT #3  
:FUNCTION CODE BIT #4  
:FUNCTION CODE BIT #5  
:DEVICE AVAILABLE (BIT #11)

:DRIVE STATUS REGISTER (RPDS1) (#01)

000002  
000004  
000010  
000020  
000040  
000100

:DFS= 1  
OFF20= 2  
DIGB= 4  
GRV= 10  
CL64= 20  
DE1= 40  
VV= 100

DRIVE FORWARD 5"/SEC. (BIT #0)  
:DRIVE FORWARD 20"/SEC. (BIT #1)  
:DRIVE TO INNER GUARD BAND (BIT #2)  
:GO REVERSE (BIT #3)  
:DIFFERENCE LESS THAN 64 (BIT #4)  
:DIFFERENCE EQUALS 1 (BIT #5)  
:VOLUME VALID (BIT #6)

219  
220  
221  
222  
223  
224  
225  
226  
227  
228  
229  
230  
231  
232  
233  
234  
235  
236  
237  
238  
239  
240  
241  
242  
243  
244  
245  
246  
247  
248  
249  
250  
251  
252  
253  
254  
255  
256  
257  
258  
259  
260  
261  
262  
263  
264  
265  
266  
267  
268  
269  
270  
271

000200  
000400  
001000  
002000  
004000  
010000  
020000  
040000  
100000

DRY= 200  
DPR= 400  
PGM= 1000  
LST= 2000  
WRL= 4000  
MOL= 10000  
PIP= 20000  
ERR= 40000  
ATA= 100000

:DRIVE READY (BIT #7)  
:DRIVE PRESENT (BIT #8)  
:PROGRAMABLE (BIT #9)  
:LAST SECTOR TRANSFERRED (BIT #10)  
:WRITE LOCK (BIT #11)  
:MEDIUM ON-LINE (BIT #12)  
:POSITIONING OPERATION IN PROGRESS (BIT #13)  
:COMPOSITE ERROR (BIT #14)  
:ATTENTION ACTIVE (BIT #15)

;ERROR REGISTER #01 (RPER1) (#02)

000001  
000002  
000004  
000010  
000020  
000040  
000100  
000200  
000400  
001000  
002000  
004000  
010000  
020000  
040000  
100000

ILF= 1  
ILR= 2  
RMR= 4  
PAR= 10  
FER= 20  
WCF= 40  
ECH= 100  
HCE= 200  
HCRC= 400  
POE= 1000  
IAE= 2000  
WLE= 4000  
DTE= 10000  
CPI= 20000  
UNS= 40000  
DCK= 100000

:ILLEGAL FUNCTION (BIT #0)  
:ILLEGAL REGISTER (BIT #1)  
:REGISTER MODIFICATION REFUSED (BIT #2)  
:PARITY ERROR (BIT #3)  
:FORMAT ERROR (BIT #4)  
:WRITE CLOCK FAIL (BIT #5)  
:ECC HARD ERROR (BIT #6)  
:HEADER COMPARE ERROR (BIT #7)  
:HEADER CRC ERROR (BIT #9)  
:ADDRESS OVERFLOW ERROR (BIT #9)  
:INVALID ADDRESS ERROR (BIT #10)  
:WRITE LOCK ERROR (BIT #11)  
:DRIVE TIMING ERROR (BIT #12)  
:OPERATION INCOMPLETE (BIT #13)  
:DRIVE UNSAFE (BIT #14)  
:DATA CHECK ERROR (BIT 15)

;MAINTAINABILITY REGISTER (RPMR) (#03)

000001  
000002  
000004  
000010  
000020  
000040  
000200

DMD= 1  
MCLK= 2  
MINX= 4  
MSTCK= 10  
MRD= 20  
MWR= 40  
DTSY= 200

:DIAGINOSTIC MODE (BIT #0)  
:MAINTAINABILITY CLOCK (BIT #1)  
:MAINTAINABILITY INDEX (BIT #2)  
:MAINTAINABILITY SECTOR CLOCK (BIT #3)  
:MAINTAINABILITY READ (BIT #4)  
:MAINTAINABILITY WRITE (BIT #5)  
:MAINTAINABILITY SYNC DETECTED (BIT #7)

;ATTENTION SUMMARY PSEUDO-REGISTER (RPAS) (#04)

000001  
000002  
000004  
000010  
000020  
000040  
000100  
000200

AT0= 1  
AT1= 2  
AT2= 4  
AT3= 10  
AT4= 20  
AT5= 40  
AT6= 100  
AT7= 200

:DEVICE 0 (BIT #0)  
:DEVICE 1 (BIT #1)  
:DEVICE 2 (BIT #2)  
:DEVICE 3 (BIT #3)  
:DEVICE 4 (BIT #4)  
:DEVICE 5 (BIT #5)  
:DEVICE 6 (BIT #6)  
:DEVICE 7 (BIT #7)

;DESIRED SECTOR/TRACK ADDRESS REGISTER (RSDA) (#05)  
;(EACH BIT IS CALLED BY BIT NUMBER)

;DRIVE TYPE REGISTER (RPDT) (#06)

000001  
000002  
000004  
000010  
000020  
000040  
000100  
000200  
000400  
000800  
001000  
002000  
004000  
008000  
010000  
020000  
040000  
100000  
000001  
000002  
000004  
000010  
000020  
000040  
000100  
000200  
001000  
002000  
004000  
010000  
020000  
040000  
100000  
000001  
000002  
000004  
000010  
000020  
000040  
000100  
000200  
001000  
002000  
004000  
010000  
020000  
040000  
100000

000001  
000002  
000004  
000010  
000020  
000040  
000100  
000200  
000400  
000800  
001000  
002000  
004000  
008000  
010000  
020000  
040000  
100000

DT00= 1  
DT01= 2  
DT02= 4  
DT03= 10  
DT04= 20  
DT05= 40  
DT06= 100  
DT07= 200  
DT08= 400  
DRQ= 4000  
MOH= 20000  
TAP= 40000  
NBA= 100000

; DRIVE TYPE NUMBER BIT 1  
; DRIVE TYPE NUMBER BIT 2  
; DRIVE TYPE NUMBER BIT 3  
; DRIVE TYPE NUMBER BIT 4  
; DRIVE TYPE NUMBER BIT 5  
; DRIVE TYPE NUMBER BIT 6  
; DRIVE TYPE NUMBER BIT 7  
; DRIVE TYPE NUMBER BIT 8  
; DRIVE TYPE NUMBER BIT 9  
; DRIVE REQUEST REQUIRED (BIT #11)  
; MOVING HEAD (BIT #13)  
; TAPE DRIVE (BIT #14)  
; NOT BLOCK ADDRESSED (BIT #15)

;LOOK-AHEAD REGISTER (RPLA) (#07)

000001  
000002  
000004  
000010  
000020  
000040  
000100  
000200  
001000  
002000  
004000  
010000  
020000  
040000  
100000

EXT1= 1  
EXT2= 2  
EXT4= 4  
EXT10= 10  
EXT20= 20  
EXT40= 40  
SC1= 100  
SC2= 200  
SC4= 400  
SC10= 1000  
SC20= 2000  
TRK1= 4000  
TRK2= 10000  
TRK4= 20000  
TRK10= 40000  
TRK20= 100000

; EXTENSION 1 (BIT #0)  
; EXTENSION 2 (BIT #1)  
; EXTENSION 3 (BIT #2)  
; EXTENSION 4 (BIT #3)  
; EXTENSION 5 (BIT #4)  
; EXTENSION 6 (BIT #5)  
; SECTOR COUNT FIELD 0 (BIT #6)  
; SECTOR COUNT FIELD 1 (BIT #7)  
; SECTOR COUNT FIELD 2 (BIT #8)  
; SECTOR COUNT FIELD 3 (BIT #9)  
; SECTOR COUNT FIELD 4 (BIT #10)  
; TRACK FIELD 1 (BIT #11)  
; TRACK FIELD 2 (BIT #12)  
; TRACK FIELD 3 (BIT #13)  
; TRACK FIELD 4 (BIT #14)  
; TRACK FIELD 5 (BIT #15)

;RPO4 ERROR REGISTER #2 (RPER2) (#10)

000001  
000002  
000004  
000010  
000020  
000040  
000100  
000200  
000400  
001000  
002000  
004000  
010000  
020000  
100000

WCU= 1  
CSF= 2  
WSU= 4  
CSU= 10  
MSE= 20  
TDF= 40  
TUF= 100  
FEN= 200  
WRU= 400  
MHS= 1000  
NHS= 2000  
IXE= 4000  
VU30= 10000  
PLU= 20000  
ACU= 100000

; WRITE CURRENT UNSAFE (BIT #0)  
; CURRENT SINK FAILURE (BIT #1)  
; WRITE SELECT UNSAFE (BIT #2)  
; CURRENT SWITCH UNSAFE (BIT #3)  
; MOTOR SEQUENCE ERROR (BIT #4)  
; TRANSITIONS DETECTOR FAILURE (BIT #5)  
; TRANSITIONS UNSAFE (BIT #6)  
; FAILSAFE ENABLED (BIT #7)  
; WRITE READY UNSAFE (BIT #8)  
; MULTIPLE HEAD SELECT (BIT #9)  
; NO HEAD SELECTION (BIT #10)  
; INDEX ERROR (BIT #11)  
; 30VOLT UNSAFE (BIT #12)  
; PLO UNSAFE (BIT #13)  
; AC UNSAFE (BIT #15)

;RPO5/6 ERROR REGISTER #02 (RPER2) (#10)

326	000001	WCU=	1	;WRITE CURRENT UNSAFE (BIT #0)
327	000002	CSF=	2	;CURRENT SINK FAILURE (BIT #1)
328	000004	WSU=	4	;WRITE SELECT UNSAFE (BIT #2)
329	000010	CSU=	10	;CURRENT SWITCH UNSAFE (BIT #3)
330	000020	RAW=	20	;READ AND WRITE (BIT #4)
331	000040	TDF=	40	;TRANSITIONS DETECTOR FAILURE (BIT #5)
332	000100	TUF=	100	;TRANSITIONS UNSAFE (BIT #6)
333	000200	ABS=	200	;ABNORMAL STOP (BIT #7)
334	000400	WRU=	400	;WRITE READY UNSAFE (BIT #8)
335	001000	MHS=	1000	;MULTIPLE HEAD SELECT (BIT #9)
336	002000	NHS=	2000	;NO HEAD SELECTION (BIT #10)
337	004000	IXE=	4000	;INDEX ERROR (BIT #11)
338	020000	PLU=	20000	;PLO UNSAFE (BIT #12)
339				
340				;OFFSET REGISTER (RPOF) (#11)
341				
342	000001	OF25=	1	;OFFSET 25 MICRO INCHES (BIT #0)
343	000002	OF50=	2	;OFFSET 50 MICRO INCHES (BIT #1)
344	000004	OF100=	4	;OFFSET 100 MICRO INCHES (BIT #2)
345	000010	OF200=	10	;OFFSET 200 MICRO INCHES (BIT #3)
346	000020	OF400=	20	;OFFSET 400 MICRO INCHES (BIT #4)
347	000040	OF800=	40	;OFFSET 800 MICRO INCHES (BIT #5)
348	000200	OFREV=	200	;OFFSET NEGATIVE (REVERSE) (BIT #5)
349	002000	HCI=	2000	;HEADER COMPARE INHIBIT (BIT #10)
350	004000	ECI=	4000	;ERROR CORRECTION CODE INHIBIT (BIT #11)
351	010000	FMT22=	10000	;FORMAT BIT (BIT #12)
352				
353				;DESIRED CYLINDER ADDRESS (RPCA) (#12)
354				; (EACH BIT IS CALLED BY BIT NUMBER)
355				
356				;CURRENT CYLINDER ADDRESS (RPCC) (#13)
357				; (EACH BIT IS CALLED BY BIT NUMBER)
358				
359				;SERIAL NUMBER REGISTER (RPSN) (#14)
360				; (EACH IS CALLED BY BIT NUMBER)
361				
362				;RPO4 ERROR REGISTER #03 (RPER3) (#15)
363				
364	000001	PSU=	1	;PACK SPEED UNSAFE (BIT #0)
365	000002	VUF=	2	;VELOCITY UNSAFE (BIT #1)
366	000010	UWR=	10	;ANY UNSAFE EXCEPT READ/WRITE (BIT #3)
367	000040	ACL=	40	;AC LOW (BIT #5)
368	000100	DCL=	100	;DC LOW (BIT #6)
369	040000	SKI=	40000	;SEEK INCOMPLETE (BIT #14)
370	100000	OCYL=	100000	;OFF CYLINDER (BIT #15)
371				
372				;RPO5/6 ERROR REGISTER #03 (RPER3) (#15)
373				
374	000001	DCU=	1	;DC UNSAFE (BIT #0)
375	000002	WAO=	2	;WRITE AND OFFSET (BIT #1)
376	000040	ACL=	40	;AC LOW (BIT #5)
377	000100	DCL=	100	;DC LOW (BIT #6)
378	020000	OPE=	20000	;OPERATOR PLUG ERROR (BIT #13)
379	040000	SKI=	40000	;SEEK INCOMPLETE (BIT #14)

8

380  
381  
382  
383  
384  
385  
386  
387  
388  
389  
390  
391  
392  
393  
394  
395  
396  
397  
398  
399  
400  
401  
402  
403  
404  
405  
406  
407  
408  
409  
410  
411  
412  
413  
414  
415  
416  
417  
418  
419  
420  
421  
422  
423  
424  
425  
426  
427  
428  
429  
430  
431  
432  
433

100000

OCYL= 100000 ;OFF CYLINDER ERROR (BIT #15)

;ECC POSITION REGISTER (RPEC1) (#16)  
;(EACH BIT IS CALLED BY BIT NUMBER)

;ECC PATTERN REGISTER (RPEC2) (#17)  
;(EACH BIT IS CALLED BY BIT NUMBER)

;;\*\*\*\*\*

.SBTTL RPO4/5/6 DRIVER COMMANDS

;;\*\*\*\*\*

000101	RNOP	=	101	;NO OPERATION
000103	UNLOAD	=	103	;UNLOAD
000105	SEEK	=	105	;SEEK
000107	RECAL	=	107	;RECALIBRATE
000111	DRVCLR	=	111	;DRIVE CLEAR
000113	RELSE	=	113	;RELEASE
000115	OFFSET	=	115	;OFFSET
000117	RTC	=	117	;RETURN TO CENTER LINE
000121	READIN	=	121	;READ IN PRESET
000123	ACK	=	123	;PACK ACKNOWLEDGE
000131	SEARCH	=	131	;SEARCH
000141	GETREG	=	141	;GET REGISTERS
000143	SETFMT	=	143	;SET FORMAT (& ECI OR HCI)
000145	SELDRV	=	145	;SELECT DRIVE
000151	WCKD	=	151	;WRITE CHECK DATA
000153	WCKHD	=	153	;WRITE CHECK HEADER & DATA
000161	WRDAT	=	161	;WRITE DATA
000163	WRTHD	=	163	;WRITE HEADER & DATA
000171	RDDAT	=	171	;READ DATA
000173	RDHD	=	173	;READ HEADER & DATA

.SBTTL TRAP CATCHER

000000

. = 0  
;\*ALL UNUSED LOCATIONS FROM 4 - 776 CONTAIN A ".+2,HALT"  
;\*SEQUENCE TO CATCH ILLEGAL TRAPS AND INTERRUPTS  
;\*LOCATION 0 CONTAINS 0 TO CATCH IMPROPERLY LOADED VECTORS

000174	DISPREG:	.WORD	0	;; SOFTWARE DISPLAY REGISTER
000176	SWREG:	.WORD	0	;; SOFTWARE SWITCH REGISTER

.SBTTL STARTING ADDRESS(ES)

000200	000137	004076	JMP	@#START1	;; JUMP TO STARTING ADDRESS OF PROGRAM
000204	000137	004066	JMP	@#START	;; CHANGE THE RH11 UNIBUS ADDRESS ; AFTER INITIAL START

.SBTTL ACT11 HOOKS

;;\*\*\*\*\*

000210

;;HOOKS REQUIRED BY ACT11  
SSVPC=. ;SAVE PC

434		000046
435	000046	005310
436		000052
437	000052	040000
438		000210

```

.=46
$ENDAD
.=52
:WORD 40000
.=SVPC

```

```

;;1)SET LOC.46 TO ADDRESS OF $ENDAD IN .SEOP
;;2)SET LOC.52 TO 40000
;; RESTORE PC

```

20



439  
440  
441  
442  
443  
444  
445 001100  
446 001100 000000  
447 001100 000000  
448 001102 000  
449 001103 000  
450 001104 000000  
451 001106 000000  
452 001110 000000  
453 001112 000000  
454 001114 000  
455 001115 001  
456 001116 000000  
457 001120 000000  
458 001122 000000  
459 001124 000000  
460 001126 000000  
461 001130 000000  
462 001132 000000  
463 001134 000  
464 001135 000  
465 001136 000000  
466 001140 177570  
467 001142 177570  
468 001144 177560  
469 001146 177562  
470 001150 177564  
471 001152 177566  
472 001154 000  
473 001155 002  
474 001156 012  
475 001157 000  
476 001160 177607 000377  
477 001164 077  
478 001165 015  
479 001166 000012  
480  
481 000015  
482 000012  
483 001170 176700  
484 001172 000254  
485 001174 172540  
486 001176 172542  
487 001200 000104  
488 001202 177546  
489 001204 000100  
490 001206 177777  
491 001210 177777  
492 001212 000074

.SBTTL COMMON TAGS

::\*\*\*\*\*  
: \*THIS TABLE CONTAINS VARIOUS COMMON STORAGE LOCATIONS  
: \*USED IN THE PROGRAM.

.=1100  
\$CMTAG: .WORD 0 ;: START OF COMMON TAGS  
\$PASS: .WORD 0 ;: CONTAINS PASS COUNT  
\$STINM: .BYTE 0 ;: CONTAINS THE TEST NUMBER  
\$ERFLG: .BYTE 0 ;: CONTAINS ERROR FLAG  
\$ICNT: .WORD 0 ;: CONTAINS SUBTEST ITERATION COUNT  
\$LPADR: .WORD 0 ;: CONTAINS SCOPE LOOP ADDRESS  
\$LPERR: .WORD 0 ;: CONTAINS SCOPE RETURN FOR ERRORS  
\$ERTTL: .WORD 0 ;: CONTAINS TOTAL ERRORS DETECTED  
\$ITEMB: .BYTE 0 ;: CONTAINS ITEM CONTROL BYTE  
\$ERMAX: .BYTE 1 ;: CONTAINS MAX. ERRORS PER TEST  
\$ERRPC: .WORD 0 ;: CONTAINS PC OF LAST ERROR INSTRUCTION  
\$GDADR: .WORD 0 ;: CONTAINS ADDRESS OF 'GOOD' DATA  
\$BDADR: .WORD 0 ;: CONTAINS ADDRESS OF 'BAD' DATA  
\$GDADR: .WORD 0 ;: CONTAINS 'GOOD' DATA  
\$BDADR: .WORD 0 ;: CONTAINS 'BAD' DATA  
\$BDDAT: .WORD 0 ;: RESERVED--NOT TO BE USED  
\$AUTOB: .BYTE 0 ;: AUTOMATIC MODE INDICATOR  
\$INTAG: .BYTE 0 ;: INTERRUPT MODE INDICATOR  
\$SWR: .WORD DSWR ;: ADDRESS OF SWITCH REGISTER  
\$DISP: .WORD DDISP ;: ADDRESS OF DISPLAY REGISTER  
\$TKS: 177560 ;: TTY KBD STATUS  
\$TKB: 177562 ;: TTY KBD BUFFER  
\$TPS: 177564 ;: TTY PRINTER STATUS REG. ADDRESS  
\$TPB: 177566 ;: TTY PRINTER BUFFER REG. ADDRESS  
\$NULL: .BYTE 0 ;: CONTAINS NULL CHARACTER FOR FILLS  
\$FILLS: .BYTE 2 ;: CONTAINS # OF FILLER CHARACTERS REQUIRED  
\$FILLC: .BYTE 12 ;: INSERT FILL CHARS. AFTER A "LINE FEED"  
\$STPFLG: .BYTE 0 ;: "TERMINAL AVAILABLE" FLAG (BIT<07>=0=YES)  
\$BELL: .ASCIZ <207><377><377> ;: CODE FOR BELL  
\$QUES: .ASCII /?/ ;: QUESTION MARK  
\$CRLF: .ASCII <15> ;: CARRIAGE RETURN  
\$LF: .ASCIZ <12> ;: LINE FEED  
::\*\*\*\*\*  
CR = 15 ;: FIRST ADDRESS OF RH11/RP04/5/6 REGISTERS  
LF = 12 ;: RP04 VECTOR ADDRESS  
\$RPADR: .WORD 176700 ;: ADDR OF KW11-P STATUS REGISTER  
\$RPVEC: .WORD 254 ;: ADDR OF KW11-P COUNTER BUFFER  
\$LKCSR: .WORD 172540 ;: ADDR OF KW11-P VECTOR  
\$LKCSB: .WORD 172542 ;: ADDR OF KW11-L STATUS REGISTER  
\$LPVEC: .WORD 104 ;: ADDR OF KW11-L VECTOR  
\$LKS: .WORD 177546 ;: '0' IF KW11-P IS ON SYSTEM  
\$LLVEC: .WORD 100 ;: '0' IF A CLOCK IS AVAILABLE  
\$PCLOCK: .WORD -1 ;: 74 (8) IF 60 HZ SYSTEM; 52 (8) IF 50 HZ SYSTEM  
\$CLKFLG: .WORD -1  
\$HZ: .WORD 74

```

493 001214 000000          STATIN: .WORD 0          ; 'TYPE STATISTICS' INDICATOR
494 001216 000000          PACK:  .WORD 0          ; 'W' COMMAND INDICATOR
495 001220 000000 000000 000000 DATE:  .WORD 0,0,0,0.0 ; OPERATOR ENTERED DATE
496 001226 000000 000000          OPERID: .WORD 0,0,0,0 ; OPERATOR ID
497 001232 000000 000000          DRIVE:  .WORD 0          ; DRIVE # STORAGE: ERRORS 1-5 & 10
498 001240 000000          ATTN:   .WORD 0          ; ATTN REG STORAGE: ERRORS 1-5 & 10
499 001242 000000          UNIT:   .WORD 0          ; DRIVE # STORAGE FOR PRINTOUT
500 001244 000000          MASK:   .WORD 0          ; ERROR RETRY REGISTER MASK
501 001246 000000          RETRY:  .BYTE 0,0        ; ERROR RETRY LIMIT IN THE LOWER BYTE
502 001250 000000          FAIRNS: .WORD 3          ; RETRY COUNT IN THE UPPER BYTE
503 001252 000          LSTAD:  .WORD 0          ; MAXIMUM TIME IN QUEUE VALUE
504          000          CHGADR: .WORD 0          ; STORE LAST MEMORY ADDRESS HERE
505 001254 000000          CFLAG:  .WORD 0          ; CHANGE RH11 UNIBUS ADDRESS FLAG
506 001256 000000          BADSEC: .WORD 0          ; 'CONTROL C' FLAG
507 001260 000000          HOUR:  .WORD 0          ; BAD SECTOR/TRACK FLAG
508 001262 000000          MINUTE: .WORD 0          ; HOUR COUNT STORED HERE (MAXIMUM - 999.)
509 001264 000000          SECOND: .WORD 0          ; MINUTE'S COUNT STORED HERE
510 001266 000000          SIXTEE: .WORD 0          ; SECOND'S COUNT STORED HERE
511 001270 000000          ZROIND: .WORD -1        ; TIMER ROUTINE COUNTER (FOR ONE SECOND)
512 001272 000000          FRSTER: .BYTE 0          ; ZERO INDICATOR FOR THE DATA COMPARE ROUTINE
513 001274 000000          SAVER1: .WORD 0          ; DATA COMPARE ERROR FLAG
514 001276 177777          SAVER5: .WORD 0          ; IF > 0, PROCESSING 'DCKER' OR CAN'T MATCH PATTERN
515 001300 000          ERCTR:  .WORD 0          ; IF < 0, MISCOMPARSION FOUND
516          000          LIMIT:  .WORD 0          ; MISCOMPARSION OR CAN'T MATCH PATTERN FLAG
517          000          CMCNT:  .WORD 0          ; IF < 0, ERROR IN BUFFER
518 001301 000          CMCYL:  .WORD 0          ; SAVE R1 HERE
519          000          CMSEC:  .BYTE 0          ; SAVE R5 HERE
520 001302 000000          CMTRK:  .BYTE 0          ; NUMBER OF ERRORS
521 001304 000000          ECBIT:  .WORD 0          ; DISPLAY LIMIT
522 001306 000000          ECSEC:  .WORD 0          ; WORD COUNT
523 001308 000000          ECMSK0: .WORD 0          ; CYLINDER ADDRESS
524 001310 000000          ECMSK1: .WORD 0          ; SECTOR ADDRESS
525 001312 000000          ECWRD:  .WORD 0          ; TRACK ADDRESS
526 001314 000000          ECGD:   .WORD 0          ; ERROR BURST BIT OFFSET
527 001316 000          ECBAD0: .WORD 0          ; ERROR BURST WORD OFFSET (RELATIVE TO SECTOR)
528 001317 000          ECWRD1: .WORD 0          ; CORRECTION MASK FOR FIRST ERROR WORD
529 001320 000000          ECGD1:  .WORD 0          ; CORRECTION MASK FOR SECOND ERROR WORD
530 001322 000000          ECBAD1: .WORD 0          ; LOCATION OF FIRST ERROR WORD
531 001324 000000          SECLMT: .WORD 21.        ; GOOD DATA, FIRST WORD
532 001326 000000          TRKLMT: .WORD 18.        ; BAD DATA, FIRST WORD
533 001328 000000          CYLIMT: .WORD 410.       ; LOCATION OF SECOND ERROR WORD
534 001330 000000          SAVER1: .WORD 0          ; GOOD DATA, SECOND WORD
535 001332 000000          SAVER5: .WORD 0          ; BAD DATA, SECOND WORD
536 001334 000000          ERCTR:  .WORD 0          ; LOCATION OF SECOND ERROR WORD
537 001336 000000          LIMIT:  .WORD 0          ; GOOD DATA, SECOND WORD
538 001338 000000          CMCNT:  .WORD 0          ; BAD DATA, SECOND WORD
539 001340 000000          CMCYL:  .WORD 0          ; SECTOR ADDRESS LIMIT
540 001342 000000          CMSEC:  .BYTE 0          ; TRACK ADDRESS LIMIT
541 001344 000025          CMTRK:  .BYTE 0          ; CYLINDER ADDRESS LIMIT FOR RPO4/5'S
542 001346 000022          ECBIT:  .WORD 0          ; (CHANGED TO 814. FOR RPO6)
543 001348 000025          ECSEC:  .WORD 0          ;
544 001350 000632          ECMSK0: .WORD 0          ;
545          000000          ECMSK1: .WORD 0          ;
546          000000          ECWRD:  .WORD 0          ;

```

;\*\*\*\*\*

.SBTTL COMMON PARAMETERS

```

547      ::*****
548
549 001352 002740      ENDCON: .WORD 002740      ;1.875X10+8 WORDS (10) [3X10+9 BITS]
550 001354 005455      .WORD 005455      ;MSW
551 001356 143300      ENDSEK: .WORD 143300      ;3 X 10+6 SEEKS (LSW)
552 001360 000155      .WORD 55      ;MSW
553 001362 000001      PASCNT: .WORD 1      ;NUMBER OF PASSES TO END OF TEST
554 001364 000000      MAXDL: .WORD 0      ;MAXIMUM DATA TRANSFER SIZE IN WORDS
555      ;(FILLED BY PROGRAM AT STARTUP OR BY OPERATOR
556      ;DURING PARAMETER ENTRY DIALOG.)
557 001366 000144      MAXER: .WORD 100.      ;MAXIMUM ERRORS - 100(10)
558 001370 000005 000000 INTRVL: .WORD 5,0      ;FIRST WORD IS THE PERFORMANCE TYPEOUT INTERVAL
559      ;(IN MINUTES). SECOND WORD IS THE INTERVAL
560      ;COUNTER
561      ;COUNTER. UPPER BYTE IS VALUE.
562 001374 000004      CMPLMT: .WORD 4      ;NUMBER OF COMPARE ERRORS TYPED OUT
563 001376 000001      FORMAT: .WORD 1      ;IF NOT EQ 0, ALLOW WRITE HEADER & DATA ORDERS
564      ;IF EQ 0, DO NOT ALLOW WRITE HEADER & DATA ORDERS
565 001400 000000      WCSEL: .WORD 0      ;IF EQ TO 0, GENERATE A RANDOM WORD COUNT
566      ;FOR THE OPERATION.
567      ;IF NOT EQ TO 0, USE THE VALUE IN 'MAXDL' FOR
568      ;THE WORD COUNT
569 001402 000003      RATIO: .WORD 3      ;READ/WRITE RATIO [RANGE 0 - 7]
570      ;0 - 0/8 (READ/WRITE)
571      ;1 - 7/1
572      ;2 - 6/2
573      ;3 - 5/3
574      ;4 - 4/4
575      ;5 - 3/5
576      ;6 - 2/6
577      ;7 - 1/7
578 001404 000001      AUTOCK: .WORD 1      ;IF NOT EQ 0, DO AN APPROPRIATE WRITE
579      ;CHECK AFTER EACH WRITE ORDER.
580      ;IF EQ 0, SELECT WRITE CHECK ORDERS
581      ;RANDOMLY.
582 001406 000001      NOTPRT: .WORD 1      ;IF EQ 1, DO NOT PRINT DATA ERROR MESSAGES
583      ;ASSOCIATED WITH OPERATOR SPECIFIED
584      ;BAD PACK AREAS.
585      ;IF NOT EQ 0, PRINT ERROR MESSAGES RELATING TO
586      ;THESE AREAS.
587 001410 000001      ENDET: .WORD 1      ;IF NOT EQ 0, END OF PASS DETERMINED
588      ;BY THE 'WORDS READ' COUNT.
589      ;IF EQ 0, END OF PASS DETERMINED
590      ;BY THE SEEK COUNT.
591
592      ;*****
593
594      .SBTTL VALUES FOR FIRST OPERATION
595
596      ;*****
597
598 001412 000010      BEGPAT: .WORD 10      ;STARTING PATTERN CODE [RANGE 1 - 17 (OCTAL)]
599 001414 000005      BEGCOD: .WORD 5      ;STARTING COMMAND CODE [RANGE 0 - 5]
600      ;0 = WRITE CHECK DATA ('WCKD')

```

```

601                                     ;1 = WRITE CHECK HEADER & DATA ('WCHKHD')
602                                     ;2 = WRITE DATA ('WRDAT')
603                                     ;3 = WRITE HEADER & DATA ('WRTHD')
604                                     ;4 = READ DATA ('RDDAT')
605                                     ;5 = READ HEADER & DATA ('RDHD')
606 001416 000404 BEGSIZ: .WORD 404 ;STARTING RECORD SIZE [RANGE 4 - MAXMEM]
607                                     ;NOTE: THE SIZE MUST BE AT LEAST 4 IF
608                                     ;WRITE DATA OR READ DATA; THE SIZE MUST
609                                     ;BE AT LEAST 8 IF WRITE HEADER AND
610                                     ;DATA OR READ HEADER AND DATA.
611                                     ;IF THE SIZE IS GREATER THAN 1 SECTOR, THE
612                                     ;SIZE MUST ALLOW FOR OVERLAPPING 4 OR 8
613                                     ;WORDS INTO THE LAST SECTOR USED.
614
615 ;:*****
616
617 .SBTTL TABLES, CONSTANTS, AND VARIABLE LOCATIONS
618
619 ;:*****
620
621 001420 000000 000000 000000 ORDERQ: .WORD 0,0,0,0,0,0,0,0,0 ;LIST OF DRIVES PERFORMING COMMANDS
622 001426 000000 000000 000000
623 001434 000000 000000 000000
624
625 001442 000000 ASNLST: .WORD 0 ;A BIT SET IS AN ASSIGNED DRIVE
626
627 001444 000000 000000 000000 DUNIT: .WORD 0,0,0,0,0,0,0,0,0 ;ADDRESSES OF DRIVES TO BE DEASSIGNED
628 001452 000000 000000 000000
629 001460 000000 000000 000000
630
631 001466 000000 000000 000000 NEWUNT: .WORD 0,0,0,0,0,0,0,0,0 ;ADDRESSES OF NEWLY ASSIGNED DRIVES
632 001474 000000 000000 000000
633 001502 000000 000000 000000
634
635 001510 000000 000000 000000 AVAIL: .WORD 0,0,0,0,0,0,0,0,0 ;LIST OF DRIVES WAITING FOR BUFFERS/PARAMETERS
636 001516 000000 000000 000000
637 001524 000000 000000 000000
638
639 001532 000000 000000 000000 WAIT: .WORD 0,0,0,0,0,0,0,0,0 ;LIST OF DRIVES WAITING FOR BUFFERS
640 001540 000000 000000 000000
641 001546 000000 000000 000000
642
643 001554 000000 000000 000000 PARQ: .WORD 0,0,0,0,0,0,0,0,0 ;LIST OF DRIVES WAITING FOR NEXT PARAMETERS
644 001562 000000 000000 000000
645 001570 000000 000000 000000
646
647 001576 000000 BUFTBL: .WORD 0 ;BUFFER ALLOCATION TABLE ENTRY COUNT
648 001600 000000 .WORD 0,0
649 001604 000000 .WORD 0,0
650 001610 000000 .WORD 0,0
651 001614 000000 .WORD 0,0
652 001620 000000 .WORD 0,0
653 001624 000000 .WORD 0,0
654 001630 000000 .WORD 0,0

```

655	001634	000000	000000	.WORD	0,0	
656	001640	000000	000000	.WORD	0,0	
657	001644	000000	000000	.WORD	0,0	
658	001650	060000	000000	.WORD	0,0	
659	001654	000000	000000	.WORD	0,0	
660	001660	000000	000000	.WORD	0,0	
661	001664	000000	000000	.WORD	0,0	
662	001670	000000	000000	.WORD	0,0	
663	001674	000000	000000	.WORD	0,0	
664	001700	000000	000000	.WORD	0,0	
665	001704	000000	000000	.WORD	0,0	
666	001710	000000	000000	.WORD	0,0	
667	001714	000000	000000	.WORD	0,0	
668						
669	001720	041606		BLKADR: .WORD	DRIVE0	; ADDRESS OF THE BLOCK FOR DRIVE 0
670	001722	042112		.WORD	DRIVE1	; ADDRESS OF THE BLOCK FOR DRIVE 1
671	001724	042416		.WORD	DRIVE2	; ADDRESS OF THE BLOCK FOR DRIVE 2
672	001726	042722		.WORD	DRIVE3	; ADDRESS OF THE BLOCK FOR DRIVE 3
673	001730	043226		.WORD	DRIVE4	; ADDRESS OF THE BLOCK FOR DRIVE 4
674	001732	043532		.WORD	DRIVE5	; ADDRESS OF THE BLOCK FOR DRIVE 5
675	001734	044036		.WORD	DRIVE6	; ADDRESS OF THE BLOCK FOR DRIVE 6
676	001736	044342		.WORD	DRIVE7	; ADDRESS OF THE BLOCK FOR DRIVE 7
677						
678	001740	151		COMTBL: .BYTE	WCKD	; WRITE CHECK DATA
679	001741	153		.BYTE	WCKHD	; WRITE CHECK HEADER AND DATA
680	001742	161		.BYTE	WRDAT	; WRITE DATA
681	001743	163		.BYTE	WRTHD	; WRITE HEADER AND DATA
682	001744	171		.BYTE	RDDAT	; READ DATA
683	001745	173		.BYTE	RDHD	; READ HEADER AND DATA
684						
685	001746	002		OPTBL: .BYTE	2	; UNLOAD
686	001747	004		.BYTE	4	; SEEK
687	001750	006		.BYTE	6	; RECAL
688	001751	010		.BYTE	10	; DRIVE CLEAR
689	001752	012		.BYTE	12	; RELEASE
690	001753	014		.BYTE	14	; OFFSET
691	001754	016		.BYTE	16	; RETURN TO CENTERLINE
692	001755	020		.BYTE	20	; READIN PRESET
693	001756	022		.BYTE	22	; PACK ACKNOWLEDGE
694	001757	030		.BYTE	30	; SEARCH
695	001760	050		.BYTE	50	; WRITE CHECK DATA
696	001761	052		.BYTE	52	; WRITE CHECK HEADER AND DATA
697	001762	060		.BYTE	60	; WRITE DATA
698	001763	062		.BYTE	62	; WRITE HEADER AND DATA
699	001764	070		.BYTE	70	; READ DATA
700	001765	072		.BYTE	72	; READ HEADER AND DATA
701	001766	377		.BYTE	-1	; TERMINATOR
702						
703		001770		.EVEN		
704						
705	001770	047125	047514 042101	MNTBL: .ASCIZ	/UNLOAD /	
706	001776	000040				
707	002000	042523	045505 020040	.ASCIZ	/SEEK /	
708	002006	000040				

739	002010	042522	040503	020114	.ASCIZ	/RECAL	/
740	002010	000040					
741	002020	051104	041526	051114	.ASCIZ	/DRVCLR	/
742	002026	000040					
743	002030	042522	051514	020105	.ASCIZ	/RELSE	/
744	002036	000040					
745	002040	043117	051506	052105	.ASCIZ	/OFFSET	/
746	002046	000040					
747	002050	052122	020103	020040	.ASCIZ	/RTC	/
748	002056	000040					
749	002060	042522	042101	047111	.ASCIZ	/READIN	/
750	002066	000040					
751	002070	040520	045503	020040	.ASCIZ	/PACK	/
752	002076	000040					
753	002100	042523	051101	044103	.ASCIZ	/SEARCH	/
754	002106	000040					
755	002110	041527	042113	020040	.ASCIZ	/WCKD	/
756	002116	000040					
757	002120	041527	044113	020104	.ASCIZ	/WCKHD	/
758	002126	000040					
759	002130	051127	042124	052101	.ASCIZ	/WRTDAT	/
760	002136	000040					
761	002140	051127	044124	020104	.ASCIZ	/WRTHD	/
762	002146	000040					
763	002150	042122	040504	020124	.ASCIZ	/RCDAT	/
764	002156	000040					
765	002160	042122	042110	020040	.ASCIZ	/RDHD	/
766	002166	000040					
767	002170	047516	042516	020040	.ASCIZ	/NONE	/
768	002176	000040					

OFFCOD:	.BYTE	0	:OFFSET	CODE TABLE
	.BYTE	10	:+200 U	INCHES
	.BYTE	210	:-200 U	INCHES
	.BYTE	20	:+400 U	INCHES
	.BYTE	220	:-400 U	INCHES
	.BYTE	30	:+600 U	INCHES
	.BYTE	230,0	:-600 U	INCHES, TERMINATOR
	.BYTE	20	:+400 U	INCHES
	.BYTE	220	:-400 U	INCHES
	.BYTE	40	:+800 U	INCHES
	.BYTE	240	:-800 U	INCHES
	.BYTE	60	:+1200 U	INCHES
	.BYTE	250,0	:-1200 U	INCHES, TERMINATOR

.EVEN				
OFMT9L:	.WORD	OFMSG0	:1ST OFFSET	MESSAGE
	.WORD	OFMSG1	:2ND OFFSET	MESSAGE
	.WORD	OFMSG2	:3RD OFFSET	MESSAGE
	.WORD	OFMSG3	:4TH OFFSET	MESSAGE
	.WORD	OFMSG4	:5TH OFFSET	MESSAGE
	.WORD	OFMSG5	:6TH OFFSET	MESSAGE
	.WORD	OFMSG6	:7TH OFFSET	MESSAGE
	.WORD	OFMSG0	:1ST OFFSET	MESSAGE

740	002200	000		
741	002201	010		
742	002202	210		
743	002203	020		
744	002204	220		
745	002205	030		
746	002206	230	000	
747	002210	020		
748	002211	220		
749	002212	040		
750	002213	240		
751	002214	060		
752	002215	260	000	
753		002220		
754				
755	002220	002254		
756	002222	002307		
757	002224	002343		
758	002226	002377		
759	002230	002433		
760	002232	002467		
761	002234	002523		
762	002236	002254		

763	0023240	002377	.WORD	OFMSG3	:4TH OFFSET MESSAGE
764	0023242	002433	.WORD	OFMSG4	:5TH OFFSET MESSAGE
765	0023244	002557	.WORD	OFMSG7	:8TH OFFSET MESSAGE
766	0023246	002613	.WORD	OFMSG8	:9TH OFFSET MESSAGE
767	0023250	002647	.WORD	OFMSG9	:10TH OFFSET MESSAGE
768	0023252	002704	.WORD	OFMSGA	:11TH OFFSET MESSAGE
769	0023254	043101	042524	020122	OFMSG0: .ASCIZ /AFTER RETRY WITHOUT OFFSET/
770	0023252	042522	051124	020131	
771	0023270	044527	044124	052517	
772	0023276	020124	043117	051506	
773	0023304	052105	000		
774	0023307	101	020124	043117	OFMSG1: .ASCIZ /AT OFFSET +200 MICRO-INCHES/
775	0023314	051506	052105	025440	
776	0023322	030062	020060	044515	
777	0023330	051103	026517	047111	
778	0023336	044103	051505	000	
779	002343	101	020124	043117	OFMSG2: .ASCIZ /AT OFFSET -200 MICRO-INCHES/
780	0023350	051506	052105	026440	
781	0023356	030062	020060	044515	
782	0023364	051103	026517	047111	
783	0023372	044103	051505	000	
784	0023377	101	020124	043117	OFMSG3: .ASCIZ /AT OFFSET +400 MICRO-INCHES/
785	002404	051506	052105	025440	
786	002412	030064	020060	044515	
787	002420	051103	026517	047111	
788	002426	044103	051505	000	
789	002433	101	020124	043117	OFMSG4: .ASCIZ /AT OFFSET -400 MICRO-INCHES/
790	002440	051506	052105	026440	
791	002446	030064	020060	044515	
792	002454	051103	026517	047111	
793	002462	044103	051505	000	
794	002467	101	020124	043117	OFMSG5: .ASCIZ /AT OFFSET +600 MICRO-INCHES/
795	002474	051506	052105	025440	
796	002502	030066	020060	044515	
797	002510	051103	026517	047111	
798	002516	044103	051505	000	
799	002523	101	020124	043117	OFMSG6: .ASCIZ /AT OFFSET -600 MICRO-INCHES/
800	002530	051506	052105	026440	
801	002536	030066	020060	044515	
802	002544	051103	026517	047111	
803	002552	044103	051505	000	
804	002557	101	020124	043117	OFMSG7: .ASCIZ /AT OFFSET +800 MICRO-INCHES/
805	002564	051506	052105	025440	
806	002572	030070	020060	044515	
807	002600	051103	026517	047111	
808	002606	044103	051505	000	
809	002613	101	020124	043117	OFMSG8: .ASCIZ /AT OFFSET -800 MICRO-INCHES/
810	002620	051506	052105	026440	
811	002626	030070	020060	044515	
812	002634	051103	026517	047111	
813	002642	044103	051505	000	
814	002647	101	020124	043117	OFMSG9: .ASCIZ /AT OFFSET +1200 MICRO-INCHES/
815	002654	051506	052105	025440	

017	002662	031061	030060	046440
018	002670	041511	047522	044111
019	002676	041516	042510	000123
020	002704	052101	047440	043106
021	002712	042523	020124	030455
022	002720	030062	020060	044515
023	002726	051103	026517	047111
024	002734	044103	051505	000

OFMSGA: .ASCIZ /AT OFFSET -1200 MICRO-INCHES/

002742

.EVEN

::\*\*\*\*\*

.SBTTL DATA PATTERNS

::\*\*\*\*\*

034	002742	000000
035	002744	003046
036	002746	003106
037	002750	003146
038	002752	003206
039	002754	003246
040	002756	003306
041	002760	003346
042	002762	003406
043	002764	003446
044	002766	003506
045	002770	003546
046	002772	003606
047	002774	003646
048	002776	003706
049	003000	003746
050	003002	003006
051	003004	003710

```
STNDAT: .WORD 0 ;STANDARD DATA PATTERN POINTER TABLE
         .WORD DATA1
         .WORD DATA1+40
         .WORD DATA1+100
         .WORD DATA1+140
         .WORD DATA1+200
         .WORD DATA1+240
         .WORD DATA1+300
         .WORD DATA1+340
         .WORD DATA1+400
         .WORD DATA1+440
         .WORD DATA1+500
         .WORD DATA1+540
         .WORD DATA1+600
         .WORD DATA1+640
         .WORD DATA0 ;ZEROS
         .WORD DATA1+642 ;ONES
```

053	003006	000000
054	003010	000000
055	003012	000000
056	003014	000000
057	003016	000000
058	003020	000000
059	003022	000000
060	003024	000000
061	003026	000000
062	003030	000000
063	003032	000000
064	003034	000000
065	003036	000000
066	003040	000000
067	003042	000000
068	003044	000000

```
DATA0: .WORD 0 ;DUMMY DATA PATTERN
        .WORD 0
        .WORD 0
        .WORD 0
        .WORD 0
        .WORD 0
        .WORD 0
        .WORD 0
        .WORD 0
        .WORD 0
        .WORD 0
        .WORD 0
        .WORD 0
        .WORD 0
        .WORD 0
```

070 003046 000001

DATA1: .WORD 000001 ;STANDARD PATTERN 1



871	003050	000003	.WORD	000003
872	003052	000007	.WORD	000007
873	003054	000017	.WORD	000017
874	003056	000037	.WORD	000037
875	003060	000077	.WORD	000077
876	003062	000177	.WORD	000177
877	003064	000377	.WORD	000377
878	003066	000777	.WORD	000777
879	003070	001777	.WORD	001777
880	003072	003777	.WORD	003777
881	003074	007777	.WORD	007777
882	003076	017777	.WORD	017777
883	003100	037777	.WORD	037777
884	003102	077777	.WORD	077777
885	003104	177777	.WORD	177777
886				
887	003106	177776	.WORD	177776 ;STANDARD PATTERN 2
888	003110	177774	.WORD	177774
889	003112	177770	.WORD	177770
890	003114	177760	.WORD	177760
891	003116	177740	.WORD	177740
892	003120	177700	.WORD	177700
893	003122	177600	.WORD	177600
894	003124	177400	.WORD	177400
895	003126	177000	.WORD	177000
896	003130	176000	.WORD	176000
897	003132	174000	.WORD	174000
898	003134	170000	.WORD	170000
899	003136	160000	.WORD	160000
900	003140	140000	.WORD	140000
901	003142	100000	.WORD	100000
902	003144	000000	.WORD	000000
903				
904	003146	000000	.WORD	000000 ;STANDARD PATTERN 3
905	003150	000000	.WORD	000000
906	003152	000000	.WORD	000000
907	003154	177777	.WORD	177777
908	003156	177777	.WORD	177777
909	003160	177777	.WORD	177777
910	003162	000000	.WORD	000000
911	003164	000000	.WORD	000000
912	003166	177777	.WORD	177777
913	003170	177777	.WORD	177777
914	003172	000000	.WORD	000000
915	003174	177777	.WORD	177777
916	003176	000000	.WORD	000000
917	003200	177777	.WORD	177777
918	003202	000000	.WORD	000000
919	003204	177777	.WORD	177777
920				
921	003206	000000	.WORD	000000 ;STANDARD PATTERN 4
922	003210	010421	.WORD	010421
923	003212	021042	.WORD	021042
924	003214	031463	.WORD	031463

925	003216	042104	.WORD	042104
926	003220	052525	.WORD	052525
927	003222	063146	.WORD	063146
928	003224	073567	.WORD	073567
929	003226	104210	.WORD	104210
930	003230	114631	.WORD	114631
931	003232	125252	.WORD	125252
932	003234	135673	.WORD	135673
933	003236	146314	.WORD	146314
934	003240	156735	.WORD	156735
935	003242	167356	.WORD	167356
936	003244	177777	.WORD	177777
937				
938	003246	052525	.WORD	052525
939	003250	052525	.WORD	052525
940	003252	052525	.WORD	052525
941	003254	125252	.WORD	125252
942	003256	125252	.WORD	125252
943	003260	125252	.WORD	125252
944	003262	052525	.WORD	052525
945	003264	052525	.WORD	052525
946	003266	125252	.WORD	125252
947	003270	125252	.WORD	125252
948	003272	052525	.WORD	052525
949	003274	125252	.WORD	125252
950	003276	052525	.WORD	052525
951	003300	125252	.WORD	125252
952	003302	052525	.WORD	052525
953	003304	125252	.WORD	125252
954				
955	003306	007417	.WORD	007417
956	003310	007417	.WORD	007417
957	003312	007417	.WORD	007417
958	003314	170360	.WORD	170360
959	003316	170360	.WORD	170360
960	003320	170360	.WORD	170360
961	003322	007417	.WORD	007417
962	003324	007417	.WORD	007417
963	003326	170360	.WORD	170360
964	003330	170360	.WORD	170360
965	003332	007417	.WORD	007417
966	003334	170360	.WORD	170360
967	003336	007417	.WORD	007417
968	003340	170360	.WORD	170360
969	003342	007417	.WORD	007417
970	003344	170360	.WORD	170360
971				
972	003346	026455	.WORD	026455
973	003350	026455	.WORD	026455
974	003352	026455	.WORD	026455
975	003354	151322	.WORD	151322
976	003356	151322	.WORD	151322
977	003360	151322	.WORD	151322
978	003362	026455	.WORD	026455

;STANDARD PATTERN 5

;STANDARD PATTERN 6

;STANDARD PATTERN 7

979	003364	026455	.WORD	026455	
980	003366	151322	.WORD	151322	
981	003370	151322	.WORD	151322	
982	003372	026455	.WORD	026455	
983	003374	151322	.WORD	151322	
984	003376	026455	.WORD	026455	
985	003400	151322	.WORD	151322	
986	003402	026455	.WORD	026455	
987	003404	151322	.WORD	151322	
988					
989	003406	165555	.WORD	165555	; STANDARD PATTERN 9
990	003410	133333	.WORD	133333	
991	003412	165555	.WORD	165555	
992	003414	133333	.WORD	133333	
993	003416	165555	.WORD	165555	
994	003420	133333	.WORD	133333	
995	003422	165555	.WORD	165555	
996	003424	133333	.WORD	133333	
997	003426	165555	.WORD	165555	
998	003430	133333	.WORD	133333	
999	003432	165555	.WORD	165555	
1000	003434	133333	.WORD	133333	
1001	003436	165555	.WORD	165555	
1002	003440	133333	.WORD	133333	
1003	003442	165555	.WORD	165555	
1004	003444	133333	.WORD	133333	
1005					
1006	003446	000001	.WORD	000001	; STANDARD PATTERN 9
1007	003450	000002	.WORD	000002	
1008	003452	000004	.WORD	000004	
1009	003454	000010	.WORD	000010	
1010	003456	000020	.WORD	000020	
1011	003460	000040	.WORD	000040	
1012	003462	000100	.WORD	000100	
1013	003464	000200	.WORD	000200	
1014	003466	000400	.WORD	000400	
1015	003470	001000	.WORD	001000	
1016	003472	002000	.WORD	002000	
1017	003474	004000	.WORD	004000	
1018	003476	010000	.WORD	010000	
1019	003500	020000	.WORD	020000	
1020	003502	040000	.WORD	040000	
1021	003504	100000	.WORD	100000	
1022					
1023	003506	177776	.WORD	177776	; STANDARD PATTERN 10
1024	003510	177775	.WORD	177775	
1025	003512	177773	.WORD	177773	
1026	003514	177767	.WORD	177767	
1027	003516	177757	.WORD	177757	
1028	003520	177737	.WORD	177737	
1029	003522	177677	.WORD	177677	
1030	003524	177577	.WORD	177577	
1031	003526	177377	.WORD	177377	
1032	003530	176777	.WORD	176777	

Handwritten mark resembling a stylized 'S' or '3'.

Handwritten mark resembling a vertical line with a hook.

Handwritten mark resembling a vertical line with a hook.

Handwritten mark resembling a stylized 'S' or '3'.

Handwritten mark resembling a stylized 'S' or '3'.

1033	003532	175777	.WORD	175777	
1034	003534	173777	.WORD	173777	
1035	003536	167777	.WORD	167777	
1036	003540	157777	.WORD	157777	
1037	003542	137777	.WORD	137777	
1038	003544	077777	.WORD	077777	
1039					
1040	003546	172666	.WORD	172666	; STANDARD PATTERN 11
1041	003550	155555	.WORD	155555	
1042	003552	172666	.WORD	172666	
1043	003554	155555	.WORD	155555	
1044	003556	172666	.WORD	172666	
1045	003560	155555	.WORD	155555	
1046	003562	172666	.WORD	172666	
1047	003564	155555	.WORD	155555	
1048	003566	172666	.WORD	172666	
1049	003570	155555	.WORD	155555	
1050	003572	172666	.WORD	172666	
1051	003574	155555	.WORD	155555	
1052	003576	172666	.WORD	172666	
1053	003600	155555	.WORD	155555	
1054	003602	172666	.WORD	172666	
1055	003604	155555	.WORD	155555	
1056					
1057	003606	077777	.WORD	077777	; STANDARD PATTERN 12
1058	003610	137777	.WORD	137777	
1059	003612	157777	.WORD	157777	
1060	003614	167777	.WORD	167777	
1061	003616	173777	.WORD	173777	
1062	003620	175777	.WORD	175777	
1063	003622	176777	.WORD	176777	
1064	003624	177377	.WORD	177377	
1065	003626	177577	.WORD	177577	
1066	003630	177677	.WORD	177677	
1067	003632	177737	.WORD	177737	
1068	003634	177757	.WORD	177757	
1069	003636	177767	.WORD	177767	
1070	003640	177773	.WORD	177773	
1071	003642	177775	.WORD	177775	
1072	003644	177776	.WORD	177776	
1073					
1074	003646	153333	.WORD	153333	; STANDARD PATTERN 13
1075	003650	066667	.WORD	066667	
1076	003652	153333	.WORD	153333	
1077	003654	066667	.WORD	066667	
1078	003656	153333	.WORD	153333	
1079	003660	066667	.WORD	066667	
1080	003662	153333	.WORD	153333	
1081	003664	066667	.WORD	066667	
1082	003666	153333	.WORD	153333	
1083	003670	066667	.WORD	066667	
1084	003672	153333	.WORD	153333	
1085	003674	066667	.WORD	066667	
1086	003676	153333	.WORD	153333	

*eg 8/21*

1087	003700	066667	.WORD	066667	
1088	003702	153333	.WORD	153333	
1089	003704	066667	.WORD	066667	
1090					
1091	003706	000000	.WORD	000000	; STANDARD PATTERN 14
1092	003710	177777	.WORD	177777	
1093	003712	177777	.WORD	177777	
1094	003714	177777	.WORD	177777	
1095	003716	177777	.WORD	177777	
1096	003720	177777	.WORD	177777	
1097	003722	177777	.WORD	177777	
1098	003724	177777	.WORD	177777	
1099	003726	177777	.WORD	177777	
1100	003730	177777	.WORD	177777	
1101	003732	177777	.WORD	177777	
1102	003734	177777	.WORD	177777	
1103	003736	177777	.WORD	177777	
1104	003740	177777	.WORD	177777	
1105	003742	177777	.WORD	177777	
1106	003744	177777	.WORD	177777	
1107					
1108	003746	177777	.WORD	177777	; STANDARD PATTERN 15
1109	003750	000000	.WORD	000000	
1110	003752	000000	.WORD	000000	
1111	003754	000000	.WORD	000000	
1112	003756	000000	.WORD	000000	
1113	003760	000000	.WORD	000000	
1114	003762	000000	.WORD	000000	
1115	003764	000000	.WORD	000000	
1116	003766	000000	.WORD	000000	
1117	003770	000000	.WORD	000000	
1118	003772	000000	.WORD	000000	
1119	003774	000000	.WORD	000000	
1120	003776	000000	.WORD	000000	
1121	004000	000000	.WORD	000000	
1122	004002	000000	.WORD	000000	
1123	004004	000000	.WORD	000000	
1124					

*28 R 25*

DZRJD.019 ERROR POINTER TABLE

.SBTTL ERROR POINTER TABLE

;\*THIS TABLE CONTAINS THE INFORMATION FOR EACH ERROR THAT CAN OCCUR.
;\*THE INFORMATION IS OBTAINED BY USING THE INDEX NUMBER FOUND IN
;\*LOCATION \$ITEMB. THIS NUMBER INDICATES WHICH ITEM IN THE TABLE IS PERTINENT.
;\*NOTE1: IF \$ITEMB IS 0 THE ONLY PERTINENT DATA IS (\$ERRPC).
;\*NOTE2: EACH ITEM IN THE TABLE CONTAINS 4 POINTERS EXPLAINED AS FOLLOWS:

;\* EM ;;POINTS TO THE ERROR MESSAGE
;\* DH ;;POINTS TO THE DATA HEADER
;\* DT ;;POINTS TO THE DATA
;\* DF ;;POINTS TO THE DATA FORMAT

1125
1126
1127
1128
1129
1130
1131
1132
1133
1134
1135
1136
1137
1138
1139
1140
1141
1142
1143
1144
1145
1146
1147
1148
1149
1150
1151
1152
1153
1154
1155
1156
1157
1158
1159
1160
1161
1162
1163
1164
1165
1166
1167
1168
1169
1170
1171
1172
1173
1174
1175
1176
1177
1178

004006

\$ERRTB:
;ERROR 1

;ERROR 1

004006 044736
004010 047376
004012 050030
004014 000000

EM1
DH1
DT1
0

;RH11 INTERRUPT OCCURRED (RPAS = 0)

;ERROR 2

004016 045001
004020 047403
004022 050034
004024 000000

EM2
DH2
DT2
0

;UNEXPECTED ATTENTION OCCURRED

;ERROR 3

004026 045037
004030 047460
004032 050052
004034 000000

EM3
DH3
DT3
0

;MASSBUS PARITY ERROR (MCPE=1)

;ERROR 4

004036 045075
004040 047506
004042 050062
004044 000000

EM4
DH4
DT4
0

;MASSBUS PARITY ERROR (PAR=1)

;ERROR 5

004046 045132
004050 047403
004052 050034
004054 000000

EM5
DH2
DT2
0

;ADDRESS PLUG BIT CHANGED

;ERROR 6

```

1179 004056 045166          EM6          ;RH11 DIDN'T RESPOND TO ADDRESSING
1180 004060 047545          DH6
1181 004062 050074          DT6
1182 004064 000000          0
1183
1184 ;:*****
1185 .SBTTL  SETUP AND INITIALIZATION ROUTINE
1186
1187 ;      START ADDRESS = 200
1188 ;      ADDRESS TO CHANGE RH11 UNIBUS ADDRESS = 204
1189
1190 ;:*****
1191
1192
1193 004066 012737 177777 001260 START:  MOV    #-1,CHGADR      ;SET RH11 ADDRESS CHANGE FLAG
1194 004074 000402          BR      START2              ;START THE PROGRAM
1195 004076 005037 001260 START1: CLR    CHGADR        ;CLEAR THE RH11 ADDRESS CHANGE FLAG
1196 004102 000005          START2: RESET              ;CLEAR THE BUS
1197 .SBTTL  INITIALIZE THE COMMON TAGS
1198 ;:CLEAR THE COMMON TAGS ($CMTAG) AREA
1199 004104 012706 001100      MOV    $CMTAG,R6           ;;FIRST LOCATION TO BE CLEARED
1200 004110 005026          CLR    (R6)+              ;;CLEAR MEMORY LOCATION
1201 004112 022706 001140      CMP    $SWR,R6 ;;DONE?
1202 004116 001374          BNE    -6                 ;;LOOP BACK IF NO
1203 004120 012706 001100      MOV    $STACK,SP         ;;SETUP THE STACK POINTER
1204 ;:INITIALIZE A FEW VECTORS
1205 004124 012737 030460 000030      MOV    $ERROR,@$EMTVEC   ;;EMT VECTOR FOR ERROR ROUTINE
1206 004132 012737 000340 000032      MOV    #340,@$EMTVEC+2  ;;LEVEL 7
1207 004140 012737 033014 000034      MOV    $TRAP,@$TRAPVEC  ;;TRAP VECTOR FOR TRAP CALLS
1208 004146 012737 000340 000036      MOV    #340,@$TRAPVEC+2;LEVEL 7
1209 004154 012737 176543 032400      MOV    #176543,$HINUM    ;;PRIME THE RANDOM NUMBER GENERATOR
1210 004162 012737 123456 032402      MOV    #123456,$LONUM   ;;BOTH HIGH AND LOW WORDS
1211 ;:SIZE FOR A HARDWARE SWITCH REGISTER. IF NOT FOUND OR IT IS
1212 ;:EQUAL TO A "-1", SETUP FOR A SOFTWARE SWITCH REGISTER.
1213 004170 013746 000004          MOV    @$ERRVEC,-(SP)    ;;SAVE ERROR VECTOR
1214 004174 012737 004230 000004      MOV    #64,$@$ERRVEC    ;;SET UP ERROR VECTOR
1215 004202 012737 177570 001140      MOV    $DSWR,SWR        ;;SETUP FOR A HARDWARE SWICH REGISTER
1216 004210 012737 177570 001142      MOV    $DDISP,DISPLAY   ;;AND A HARDWARE DISPLAY REGISTER
1217 004216 022777 177777 174714      CMP    #-1,$SWR         ;;TRY TO REFERENCE HARDWARE SWR
1218 004224 001012          BNE    66$              ;;BRANCH IF NO TIMEOUT TRAP OCCURRED
1219 ;:AND THE HARDWARE SWR IS NOT = -1
1220 004226 000403          BR     65$              ;;BRANCH IF NO TIMEOUT
1221 004230 012716 004236          64$:  MOV    #65$,(SP)        ;;SET UP FOR TRAP RETURN
1222 004234 000002          RTI
1223 004236 012737 000176 001140      65$:  MOV    $SWREG,SWR       ;;POINT TO SOFTWARE SWR
1224 004244 012737 000174 001142      MOV    $DISPREG,DISPLAY
1225 004252 012637 000004          66$:  MOV    (SP)+,@$ERRVEC  ;;RESTORE ERROR VECTOR
1226
1227 004256 012737 000240 000032      MOV    #240,@$EMTVEC+2  ;CHANGE EMT PRIORITY TO 5
1228 004264 012737 000240 000036      MOV    #240,@$TRAPVEC+2;CHANGE TRAP PRIORITY TO 5
1229 004272 005227 177777          INC    #-1              ;FIRST START ?
1230 004276 001013          BNE    1$               ;BR IF NOT
1231 004300 104401 055254          TYPE  ,TITLE           ;NAME AND MANDEC NUMBER
1232 004304 005737 000042          TST   42               ;AUTO ACCEPT OR CHAIN MODE ?

```

```

1233 004310 001006          BNE      1$          ;BR IF EITHER
1234 004312 122737 000011 000041  CMPB    #11,41      ;LOADED FROM AN RPO4/5/6 ?
1235 004320 001002          BNE      1$          ;BR IF NOT
1236 004322 104401 055354          TYPE    LOADRV      ;INSTRUCT THE OPERATOR ON HOW TO TEST DRIVE 0
1237 004326 004737 030000          1$: JSR     PC,$TKINT  ;TURN ON THE KEYBOARD INTERRUPT
1238          .SBTTL GET VALUE FOR SOFTWARE SWITCH REGISTER
1239 004332 005737 000042          TST     2#42        ;ARE WE RUNNING UNDER XXDP/ACT?
1240 004336 001006          BNE      67$        ;BRANCH IF YES
1241 004340 023727 001140 000176  CMP     SWR,#SWREG  ;SOFTWARE SWITCH REG SELECTED?
1242 004346 001005          BNE      68$        ;BRANCH IF NO
1243 004350 104406          GTSWR                    ;GET SOFT-SWR SETTINGS
1244 004352 000403          BR      68$
1245 004354 112737 000001 001134 67$: MOVB   #1,$AUTOB   ;;SET AUTO-MODE INDICATOR
1246 004362          68$:
1247 004362 005227 177777          INC     #-1         ;FIRST START ?
1248 004366 001012          BNE      2$          ;BR IF NOT
1249 004370 004737 054662          JSR     PC,BUSADR   ;CHECK RH11 BUS ADDRESS
1250 004374 013737 001170 033250  MOV     $RPADR,RPADR ;RH11 ADDRESS
1251 004402 013737 001172 033252  MOV     $RPVEC,RPVEC ;RH11 VECTOR ADDRESS
1252 004410 004737 054404          JSR     PC,OPRDAT   ;GET THE DATE AND OPERATOR ID
1253 004414 005037 001214          2$: CLR     STATIN     ;CLEAR PERFORMANCE SUMMARY TYPEOUT FLAG
1254 004420 012705 001420          MOV     #ORDERQ,R5 ;START OF AREA TO CLEAR
1255 004424 005025          3$: CLR     (R5)+
1256 004426 022705 001720          CMP     #BLKADR,R5 ;LOOK FOR END OF CLEAR AREA
1257 004432 001374          BNE      3$          ;BR IF NOT FINISHED
1258 004434 012706 001100          MOV     #STACK,SP  ;SETUP THE STACK POINTER
1259 004440 005037 177776          CLR     PS         ;CLEAR THE PROCESSOR STATUS WORD
1260 004444 013737 001212 001274  MOV     HZ,SIXTEE   ;1/60 TH OR 1/50 TH SECOND COUNTER VALUE
1261 004452 005037 001266          CLR     HOUR       ;CLEAR THE HOUR'S COUNTER
1262 004456 005037 001270          CLR     MINUTE     ;CLEAR THE MINUTE'S COUNTER
1263 004462 005037 001272          CLR     SECOND     ;CLEAR THE SECOND'S COUNTER
1264 004466 005037 001372          CLR     INTRVL+2   ;CLEAR INTERVAL COUNTER
1265 004472 005037 001216          CLR     PACK       ;CLEAR THE 'R' OR 'W' COMMAND FLAG
1266 004476 005037 001262          CLR     CFLAG     ;CLEAR THE 'CONTROL C' FLAG
1267 004502 042737 170000 001366  BIC     #170000,MAXER ;MAKE SURE ERROR LIMITS ARE NOT TOO HIGH
1268
1269          ;ROUTINE TO DETERMINE BUFFER AREA SIZE
1270
1271 004510 005227 177777          SIZMEM: INC     #-1         ;SEE IF TIME TO SIZE MEMORY
1272 004514 001005          BNE      1$          ;BR IF NOT
1273 004516 004737 054564          JSR     PC,$SIZE    ;SEE HOW MUCH MEMORY ON SYSTEM
1274 004522 013737 054660 001256  MOV     $LSTAD,LSTAD ;SAVE THE LAST ADDRESS
1275 004530 012737 000001 001576  1$: MOV     #1,BUFTBL ;LOAD NUMBER OF BUFFERS
1276 004536 012737 054404 001600  MOV     #ENDPGM,BUFTBL+2 ;STARTING ADDRESS OF BUFFER
1277 004544 013737 001256 001602  MOV     LSTAD,BUFTBL+4 ;LAST ADDR TO BUFFER ALLOCATION TABLE
1278 004552 162737 054404 001602  SUB     #ENDPGM,BUFTBL+4 ;SUBTRACT PROGRAM SPACE
1279 004560 000241          CLC
1280 004562 006037 001602          ROR     BUFTBL+4   ;CONVERT TO WORD COUNT
1281 004566 162737 000144 001602  SUB     #100.,BUFTBL+4 ;SAVE ROOM FOR THE 'ABS' LOADER
1282 004574 023727 001256 100000  CMP     LSTAD,#100000 ;16K ON THE SYSTEM ?
1283 004602 103406          BLO     3$          ;BR IF YES
1284 004604 105737 000041          TSTB   41         ;SEE WHO LOADED THE PROGRAM
1285 004610 001403          BEQ     3$          ;BR IF LOADED BY PAPER TAPE
1286 004612 162737 002570 001602  SUB     #1400.,BUFTBL+4 ;SUBTRACT 'XXDP' LOADER SIZE

```



```

1287 004620 005737 001364      3$:   TST   MAXDL      ;VALUE IN 'MAXDL' ?
1288 004624 001012                BNE   4$          ;BR IF VALUE IS
1289 004626 012737 013534 001364   MOV   #5980,MAXDL ;ASSUME FULL TRACK + 1 SEC MAXIMUM
1290 004634 023737 001364 001602   CMP   MAXDL,BUFTBL+4 ;IS THAT TOO LARGE ?
1291 004642 103403                BLO   4$          ;BR IF NOT
1292 004644 013737 001602 001364   MOV   BUFTBL+4,MAXDL ;USE MAX AVAIL MEMORY AS MAX BUFFER SIZE
1293 004652 013737 001602 053374   4$:   MOV   BUFTBL+4,PARLST+2 ;VALUE FOR THE PARAMETER TABLE
1294
1295 ;SEE IF THE OPERATOR WANTS TO CHANGE ANY PARAMETERS
1296
1297 004660 005737 000042      LKPAR: TST   @#42      ;'XXDP' CHAIN MODE OR 'ACT11' OPERATION ?
1298 004664 001022                BNE   SETVEC      ;BR IF YES
1299 004666 104401 053470                TYPE  ,ASKPAR      ;ASK FOR PARAMETERS
1300 004672 104411                RDLIN ;READ THE ENTRY
1301 004674 012605                MOV   (SP)+,R5     ;ADDRESS OF ENTRY TO R5
1302 004676 122715 000131                CMPB  #'Y',(R5)    ;WAS ENTRY A 'Y' (YES)
1303 004702 001013                BNE   SETVEC      ;BR IF NOT 'Y'
1304
1305 004704 012703 053372      ENTPR: MOV   #PARLST,R3 ;PARAMETER TABLE ADDRESS
1306 004710 004737 026222                JSR   PC,PARENT   ;GET THE PARAMETER ENTRY
1307 004714 023727 001364 000004                CMP   MAXDL,#4    ;IS THE 'MAXDL' VALUE OK ?
1308 004722 103003                BHIS  SETVEC      ;BR IF IT IS
1309 004724 012737 000004 001364                MOV   #4,MAXDL    ;SET 'MAXDL' TO THE MINIMUM VALUE
1310
1311 ;DISPLAY DRIVE STATUS AND SET UP THE OTHER SYSTEM DEVICES THAT
1312 ; THE PROGRAM WILL USE
1313
1314 004732 004737 022342      SETVEC: JSR   PC,CKCLK ;START THE CLOCK
1315 004736 004737 033266                JSR   PC,RPINIT   ;INITIALIZE THE RPO4/5/6 DRIVER
1316 004742 012737 177777 033210                MOV   #-1,SAVEFG ;SET THE SAVE REGISTERS FLAG
1317 004750 062727 177777 000000                ADD   #-1,#0     ;CHECK FOR FIRST START
1318 004756 103004                BCC   11$        ;BR IF FIRST START
1319 004760 032777 000004 174152                BIT   #SW02,JSWR ;TYPEOUT THE DRIVE STATUS TABLE ?
1320 004766 001075                BNE   10$        ;BR IF NOT
1321 004770 012737 000340 177776   11$:  MOV   #PR7,PS     ;SET PRIORITY TO 7
1322 004776 005004                CLR   R4         ;DRIVE TABLE POINTER
1323 005000 104401 001165                TYPE  ,%CRLF     ;CR-LF
1324 005004 104401 052262                TYPE  ,SYSTAT    ;TYPE STATUS HEADING
1325
1326 005010 010446                1$:   MOV   R4,-(SP)   ;;SAVE R4 FOR TYPEOUT
1327 ; ;TYPE DRIVE NUMBER
1328 005012 104403                TYPOS ;GO TYPE--OCTAL ASCII
1329 005014 002                .BYTE 2          ;TYPE 2 DIGIT(S)
1330 005015 000                .BYTE 0          ;SUPPRESS LEADING ZEROS
1331 005016 104401 052071                TYPE  ,LIN4SP    ;SPACES
1332 005022 105764 033122                TSTB  DRVSTA(R4) ;CHECK DRIVE'S STATUS
1333 005026 100416                BMI   4$         ;BR IF UNSAFE
1334 005030 001020                BNE   5$         ;BR IF ONLINE
1335 005032 105764 033132                TSTB  DRVSTYP(R4);SEE IF OFFLINE OR NONEXISTENT
1336 005036 001404                BEQ   2$         ;BR IF NONEXISTENT
1337 005040 100006                BPL   3$         ;BR IF OFFLINE
1338 005042 104401 052175                TYPE  ,NOTRP     ;DRIVE NOT AN RPO4/5/6
1339 005046 000440                BR    9$         ;CHECK NEXT DRIVE
1340 005050 104401 052216                2$:   TYPE  ,NOTPRS  ;DRIVE NOT PRESENT

```

```

1341 005054 000435          BR      9$      ;CHECK NEXT DRIVE
1342 005056 104401 052104  3$:     TYPE    ,UNTOFF ;DRIVE OFFLINE
1343 005062 000405          BR      6$      ;PRINT DRIVE TYPE
1344 005064 104401 052252  4$:     TYPE    ,NOTSAF ;DRIVE UNSAFE
1345 005070 000402          BR      6$      ;PRINT DRIVE TYPE
1346 005072 104401 052115  5$:     TYPE    ,UNTON  ;DRIVE ONLINE
1347 005076 104401 052073  6$:     TYPE    ,LINSF  ;SPACES
1348 005102 012737 052302 005146  MOV     #RPO4B,8$ ;ADDRESS OF RPO4 MESSAGE
1349 005110 132764 000001 033132  BITB   #BIT00,DRV TYP(R4) ;RPO4 ?
1350 005116 001012          BNE     7$      ;BR IF YES
1351 005120 012737 052307 005146  MOV     #RPO5,8$ ;ADDRESS OF RPO5 MESSAGE
1352 005126 132764 000002 033132  BITB   #BIT01,DRV TYP(R4) ;RPO5 ?
1353 005134 001003          BNE     7$      ;BR IF YES
1354 005136 012737 052314 005146  MOV     #RPO6,8$ ;ADDRESS OF RPO6 MESSAGE
1355 005144 104401          7$:     TYPE    ;TYPE THE DRIVE TYPE MESSAGE
1356 005146 000000          8$:     .WORD   0      ;MESSAGE ADDRESS HERE
1357 005150 104401 001165  9$:     TYPE    ,SCRLF  ;CR-LF
1358 005154 005204          INC     R4      ;INCREMENT DRIVE NUMBER/TABLE POINTER
1359 005156 020427 000010          CMP     R4,#8.  ;FINISHED ?
1360 005162 001312          BNE     1$      ;BR IF NOT
1361 005164 104401 001165 10$:    TYPE    ,SCRLF  ;CR-LF
1362 005170 005037 177776          CLR     PS     ;SET PRIORITY BACK TO '0'
1363 005174 000137 005200          JMP     MONTR   ;CHECK FOR 'XXDP' OR 'ACT11' !ONITOR
1364
1365 ;SETUP IF 'XXDP' OR 'ACT11' OPERATION
1366
1367 005200 005737 000042  MONTR:  TST     42   ;'XXDP' CHAIN MODE OR 'ACT11' AUTO ACCEPT
1368 005204 001402          BEQ     1$      ;BR IF NEITHER
1369 005206 004737 024224          JSR     PC,ASGN2 ;ASSIGN DRIVES
1370 005212 005227 177777  1$:     INC     #-1 ;FIRST START ?
1371 005216 001011          BNE     2$      ;BR IF NOT
1372 005220 105737 000041          TSTB   2#41    ;LOADED FROM PAPER TAPE ?
1373 005224 001406          BEQ     2$      ;BR IF YES
1374 005226 023727 001256 100000  CMP     LSTAD,#100000 ;MORE THAN 16K ON THE SYSTEM ?
1375 005234 103002          BHS    2$      ;BR IF YES
1376 005236 104401 055553          TYPE    ,NOLOAD ;TELL THE OPERATOR THAT THE 'XXDP' LOADER
1377 ;WILL BE OVERWRITTEN
1378 005242 004737 030000  2$:     JSR     PC,$TKINT ;INITIALIZE THE KEYBOARD INTERRUPT HANDLER
1379 005246 104401 053257          TYPE    ,INTDON ;TYPE 'INITIALIZE COMPLETE'
1380 005252 000137 005452          JMP     MAIN1   ;START THE PROGRAM
1381
1382 ;'XXDP' OR 'ACT11' END OF TEST ROUTINE
1383
1384 005256 013700 000042  $GET42: MOV     42,RO  ;MONITOR ADDRESS
1385 005262 001002          BNE     1$      ;ER IF MONITOR
1386 005264 000137 005452          JMP     MAIN1   ;NONE, CONTINUE
1387 005270 022700 005310  1$:     CMP     #SENDAD,RO ;IS MONITOR 'ACT11' ?
1388 005274 001005          BNE     $ENDAD  ;BR IF NOT
1389 005276 022760 177777 000002  CMP     #-1,2(RO) ;LAST 'ACT11' PASS ?
1390 005304 001005          BNE     $DOAGN  ;NO, MAKE ANOTHER PASS
1391 005306 000005          RESET ;CLEAR EVERYTHING
1392 005310 004710  $ENDAD: JSR     PC,(RO) ;GO TO THE MONITOR
1393 005312 000240          NOP ;SAVE ROOM
1394 005314 000240          NOP ;FOR
    
```

```

1431 005316 000240 NUP :ACT11
1432 005320 000137 004066 SDOAGN: JMP START :START AGAIN
;:*****
.SBTTL MAIN PROGRAM
;:*****
1433 005324 012703 000010 MAIN: MOV #8.,R3 :DRIVE COUNTER
1434 005325 012705 001444 MOV #DUNIT,R5 :ADDRESS OF 'DROP DRIVE' TABLE
1435 005327 005715 15: TST (R5) :SEE IF ENTRY AT PRESENT POSITION
1436 005328 001011 BNE 35 :BR IF THERE IS ONE
1437 005330 062705 000002 25: ADD #2,R5 :INCREMENT TO NEXT TABLE POSITION
1438 005331 005303 DEC R3 :DECREMENT DRIVE COUNTER
1439 005332 001372 BNE 15 :BR IF MORE TO CHECK
1440 005333 005737 001442 TST #SNLST :ANY DRIVES ACTIVE ?
1441 005334 001036 BNE MAIN1 :BR IF YES
1442 005335 000137 005256 JMP $GET42 :CHECK FOR MONITOR RETURN
1443 005336 012701 001510 35: MOV #AVAIL,R1 :ADDRESS OF 'AVAILABLE DRIVES' TABLE
1444 005337 005711 45: TST (R1) :SEE IF AT END OF TABLE
1445 005338 001405 BEQ 55 :BR IF AT END: GO CHECK 'WAIT' TABLE
1446 005339 021115 CMP (R1),(R5) :IS DRIVE IN 'AVAIL' THE ONE TO BE DROPPED
1447 005340 001414 BEQ 75 :BR IF YES
1448 005341 062701 000002 ADD #2,R1 :INCREMENT 'AVAIL' TABLE ADDRESS
1449 005342 000771 BR 45 :CONTINUE LOOKING
1450 005343 012701 001532 55: MOV #WAIT,R1 :MOVE THE ADDRESS OF THE BUFFER WAIT TABLE
1451 005344 005711 65: TST (R1) :AT THE END OF THE 'WAIT' TABLE ?
1452 005345 001752 BEQ 25 :BR IF YES: SEE IF ANY MORE 'DROP' REQUESTS
1453 005346 021115 CMP (R1),(R5) :DRIVE IN THE 'WAIT' TABLE ?
1454 005347 001403 BEQ 75 :BR IF IT IS
1455 005348 062701 000002 ADD #2,R1 :INCREMENT 'WAIT' TABLE ADDRESS
1456 005349 000771 BR 65 :CONTINUE LOOK THROUGH THE 'WAIT' TABLE
1457 005350 011100 75: MOV (R1),R0 :PUT THE DRIVE'S BLOCK ADDRESS IN R0
1458 005351 104401 052566 TYPE DEASSG :TYPE 'DRIVE DEASSIGNED'
1459 005352 004737 022626 JSR PC,TYPEST :TYPE THE DRIVE'S PERFORMANCE SUMMARY
1460 005353 005015 CLR (R5) :CLEAR THE 'DROP DRIVE' TABLE ENTRY
1461 005354 005011 CLR (R1) :REMOVE THE DRIVE FROM THE 'AVAIL' OR 'WAIT' TABLE
1462 005355 004737 017460 JSR PC,COMPRES :COMPRESS THE RESPECTIVE TABLE
1463 005356 000733 BR 25 :SEE IF ANY MORE DRIVES
;LOOK FOR DRIVES TO BE ASSIGNED
1464 005452 012703 000010 MAIN1: MOV #8.,R3 :DRIVE COUNT
1465 005453 005002 CLR R2 :'AVAIL' INDEX
1466 005454 005004 CLR R4 :ASSIGN LIST INDEX
1467 005455 00FJ05 CLR R5 :NEW DRIVE INDEX
1468 005456 005765 001466 15: TST NEWUNT,R5 :NEW DRIVE IN THIS POSITION
1469 005457 001006 BNE 35 :BR IF THERE IS
1470 005458 062705 000002 25: ADD #2,R5 :INCREMENT R5
1471 005459 005204 INC R4 :INCREMENT ASSIGN INDEX
1472 005460 005303 DEC R3 :DECREMENT DRIVE COUNT
1473 005461 001370 BNE 15 :BR IF MORE DRIVES
1474 005462 005432 BR MAIN2 :START OPERATIONS FOR THE AVAILABLE DRIVES

```

```

1449 005506 104401 052076 35: TYPE UNTMSG ; 'DRIVE'
1450 005512 010446 MOV #4,-(SP) ; SAVE R4 FOR TYPEOUT
1451 ; TYPE DRIVE NUMBER
1452 005514 104403 TYPOS ; GO TYPE--OCTAL ASCII
1453 005516 002 .BYTE 2 ; TYPE 2 DIGIT(S)
1454 005517 000 .BYTE 0 ; SUPPRESS LEADING ZEROS
1455 005520 104401 052636 TYPE ASGND ; ASSIGNED
1456 005524 005762 001510 45: TST $AVAIL(R2) ; AT END OF AVAILABLE TABLE
1457 005530 001403 BEQ $5 ; BR IF YES
1458 005532 062702 000002 ADD #2,R2 ; INCREMENT AVAILABLE TABLE INDEX
1459 005536 000772 BR 45 ; CONTINUE LOOKING FOR END OF TABLE
1460 005540 016562 001466 001510 55: MOV NEWUNT(R5),AVAIL(R2) ; MOVE ADDR OF DRIVE INTO AVAIL_LST
1461 005546 005065 001466 CLR NEWUNT(R5) ; TAKE DRIVE OUT OF NEW DRIVE TABLE
1462 005552 156437 033236 001442 BISR ATABIT(R4),ASNLST ; SET DRIVE ASSIGNED INDICATOR
1463 005560 016200 001510 MOV AVAIL(R2),R0 ; PUT STARTING ADDRESS OF BLOCK IN R0
1464 005564 062702 000002 ADD #2,R2 ; INCREMENT AVAILABLE TABLE POINTER
1465 005570 000740 BR 25 ; LOOK FOR MORE DRIVES

;GET PARAMETERS, BUFFER SPACE, AND START ORDERS FOR DRIVES IN
; THE 'AVAILABLE' QUEUE

1470 005572 005737 001532 MAIN2: TST WAIT ; OUTSTANDING BUFFER REQUESTS
1471 005576 001113 BNE MAIN3 ; BR IF THERE ARE
1472 005600 005002 CLR R2 ; CLEAR DRIVE TABLE POINTER
1473 005602 005762 001510 15: TST AVAIL(R2) ; ANY DRIVES WAITING FOR PARAMETERS
1474 005606 001551 BEQ IDLE ; BRANCH IF NONE
1475 005610 016200 001510 MOV AVAIL(R2),R0 ; CONTROL BLOCK ADDR IN R0
1476 005614 005760 000104 TST $NEXT(R0) ; PARAMETERS BEEN SELECTED ?
1477 005620 001021 BNE 65 ; BR IF THEY HAVE
1478 005622 105760 000026 TSTB $PACK(R0) ; 'R' OR 'W' COMMAND FOR THE DRIVE ?
1479 005626 001403 BEQ 25 ; BR IF NOT
1480 005630 004737 017476 JSR PC,WRTPK ; GET DATA PACK PARAMETERS
1481 005634 000415 BR 75 ; GET THE BUFFER
1482 005636 012701 001554 25: MOV #PARQ,R1 ; ADDRESS OF THE PARAMETER QUEUE
1483 005642 020011 35: CMP R0,(R1) ; IS CURRENT DRIVE IN THE QUEUE ?
1484 005644 001403 BEQ 45 ; BR IF IT IS
1485 005646 005721 TST (R1)+ ; AT END OF THE QUEUE
1486 005650 001403 BEQ 55 ; BR IF AT END
1487 005652 000773 BR 35 ; CONTINUE LOOKING
1488 005654 004737 017460 45: JSR PC,COMPRES ; COMPRESS THE TABLE
1489 005660 004737 016376 55: JSR PC,SELPAR ; SELECT THE PARAMETERS
1490 005664 004737 017252 65: JSR PC,GETPAR ; LOAD NEW PARAMETERS
1491 005670 005046 75: CLR -(SP) ; MAKE ROOM ON THE STACK FOR THE BUFFER ADDR
1492 005672 004737 015622 JSR PC,GETBUF ; GET BUFFER
1493 005676 012660 000006 MOV (SP)+,$BUF(R0) ; MOVE BUFFER ADDR TO DPB
1494 005702 001424 BEQ 85 ; BR IF '0' ADDR (NO BUFFER)
1495 005704 004737 016172 JSR PC,FILBUF ; FILL THE BUFFER
1496 005710 005060 000072 CLR $FAIR(R0) ; CLEAR THE 'FAIRNESS' COUNT
1497 005714 004737 016320 JSR PC,GODRIV ; PUT CURRENT DPB IN DRIVER
1498 005720 012705 001420 MOV #ORDER0,R5 ; ADDRESS OF ORDER QUEUE IN R5
1499 005724 005725 TST (R5)+ ; END OF QUEUE ?
1500 005726 001376 BNE -2 ; BR IF NOT
1501 005730 010045 MOV R0,-(R5) ; PUT BLOCK ADDRESS INTO QUEUE
1502 005732 105760 000026 TSTB $PACK(R0) ; 'R' OR 'W' COMMAND FOR DRIVE ?

```

```

DZRJD.019 MAIN PROGRAM
1503 005736 001025 BNE 10$ :BR IF EITHER
1504 005740 012705 001554 MOV #PARQ,R5 :PUT BLOCK INTO THE PARAMETER QUEUE
1505 005744 005725 TST (R5)+ :FIND THE END OF THE QUEUE
1506 005746 001376 BNE -2 :BR IF NOT AT END OF QUEUE
1507 005750 010045 MOV R0,-(R5) :PUT BLOCK ADDRESS INTO THE QUEUE
1508 005752 000417 BR 10$ :CONTINUE LOOKING
1509 005754 026037 000072 001254 8$: CMP $FAIR(R0),FAIRNS :ENTRY BEEN IN THE QUEUE LONG ENOUGH ?
1510 005762 001405 BEQ 9$ :BR IF YES
1511 005764 005260 000072 INC $FAIR(R0) :INCREMENT THE ENTRY COUNT
1512 005770 062702 000002 ADD #2,R2 :INCREMENT THE POINTER
1513 005774 000702 BR 1$ :LOOK FOR SOME MORE DRIVES
1514 005776 012705 001532 9$: MOV #WAIT,R5 :'WAIT' QUEUE ADDRESS
1515 006002 005725 TST (R5)+ :LOOK FOR AN OPENING
1516 006004 001376 BNE -2 :BR IF NONE YET
1517 006006 016245 001510 MOV AVAIL(R2),-(R5) :MOVE DRIVE'S BLOCK ADDRESS TO QUEUE
1518 006012 012701 001510 10$: MOV #AVAIL,R1 :'AVAILABLE' TABLE ADDRESS
1519 006016 060201 ADD R2,R1 :FORM ADDRESS OF LAST ENTRY
1520 006020 004737 017460 JSR PC,CMPRES :COMPRESS THE TABLE
1521 006024 000656 BR 1$ :CONTINUE LOOKING

:GET BUFFER ASSIGNMENTS FOR DRIVES IN THE 'BUFFER WAIT' QUEUE
1522
1523
1524
1525 006026 013700 001532 MAIN3: MOV WAIT,R0 :MOVE THE 'WAIT' ENTRY TO R0
1526 006032 005046 CLR -(SP) :MAKE ROOM ON THE STACK FOR THE BUFFER ADDR
1527 006034 004737 015622 JSR PC,GETBUF :TRY TO GET A BUFFER
1528 006040 012660 000006 MOV (SP)+,$BUF(R0) :MOVE THE BUFFER ADDR TO THE DPB
1529 006044 001002 BNE 1$ :BR IF A BUFFER WAS ASSIGNED
1530 006046 000137 006132 JMP IDLE :NO BUFFER AVAILABLE YET
1531 006052 004737 016172 1$: JSR PC,FILBUF :FILL THE BUFFER
1532 006056 004737 016320 JSR PC,GODRIV :PUT THE ENTRY IN THE DRIVER
1533 006062 005060 000072 CLR $FAIR(R0) :CLEAR THE 'FAIRNESS' COUNT
1534 006066 012705 001420 MOV #ORDERQ,R5 :ADDRESS OF ORDER QUEUE IN R5
1535 006072 005725 TST (R5)+ :AT END OF THE QUEUE
1536 006074 001376 BNE -2 :BR IF NOT
1537 006076 010045 MOV R0,-(R5) :PUT BLOCK ADDRESS IN QUEUE
1538 006100 105760 000026 TSTB $PACK(R0) :'R' OR 'W' COMMAND FOR DRIVE ?
1539 006104 001005 BNE 2$ :BR IF YES, DON'T PUT BLOCK INTO 'PARQ'
1540 006106 012705 001554 MOV #PARQ,R5 :FIND THE END OF THE PARAMETER QUEUE
1541 006112 005725 TST (R5)+ :OPEN SLOT IN THE QUEUE ?
1542 006114 001376 BNE -2 :BR IF NOT
1543 006116 010045 MOV R0,-(R5) :PUT BLOCK ADDRESS INTO THE QUEUE
1544 006120 012701 001532 2$: MOV #WAIT,R1 :ADDRESS OF TABLE TO COMPRESS
1545 006124 004737 017460 JSR PC,CMPRES :COMPRESS THE WAIT TABLE
1546 006130 000620 BR MAIN2 :LOOK FOR MORE ENTRIES

:WAIT FOR AN ORDER TO FINISH
1547
1548
1549
1550 006132 012701 001420 IDLE: MOV #ORDERQ,R1 :ADDRESS OF THE ORDER QUEUE IN R1
1551 006136 012100 1$: MOV (R1)+,R0 :PUT BLOCK ADDRESS INTO R0
1552 006140 001433 BEQ IDLE1 :BR IF END OF QUEUE
1553 006142 005760 000016 TST $STATUS(R0) :SEE IF DRIVE FINISHED
1554 006146 001773 BNE 1$ :BR IF DRIVE NOT FINISHED
1555 006150 162701 000002 SUB #2,R1 :CORRECT THE QUEUE POINTER
1556 006154 010146 MOV R1,-(SP) :SAVE THE QUEUE ADDRESS

```

```

1557 006156 004737 015456 JSR PC,STATIS ;ACCUMULATE STATISTICS FOR DRIVE IN RC
1558 006162 000240 NOP ;DEBUGGING AID
1559 006164 004737 006470 JSR PC,PROCES ;PROCESS END OF ORDER
1560 006170 005037 001264 CLR BADSEC ;CLEAR THE BAD TRK/SEC ERROR INDICATOR
1561 006174 004737 026454 JSR PC,ABNRML ;SEE IF ANY DRIVES HAVE TOO MANY ERRORS
1562 006200 004737 026502 JSR PC,EOP ;SEE IF ANY DRIVE HAS XFERED 3X10^9 BITS
1563 006204 012601 MOV (SP)+,R1 ;RESTORE THE ORDER TABLE INDEX
1564 006206 012705 001510 MOV #AVAIL,R5 ;FIND THE END OF THE 'AVAILABLE' TABLE
1565 006212 005725 2$: TST (R5)+ ;END OF THE TABLE ?
1566 006214 001376 BNE 2$ ;BR IF NOT AT END OF LIST
1567 006216 011145 MOV (R1),-(R5) ;MOVE THE BLOCK ADDRESS INTO THE TABLE
1568 006220 004737 017460 JSR PC,CMPRES ;COMPRESS THE ORDER QUEUE
1569 006224 004737 015756 JSR PC,RELBUF ;RESTORE BUFFER
1570 006230 005737 001262 IDLE!: TST CFLAG ;'CONTROL C' FLAG ENTERED ?
1571 006234 001403 BEQ 1$ ;BR IF IT WAS
1572 006236 004737 023640 JSR PC,KSR ;SERVICE THE KEYBOARD
1573 006242 000733 BR IDLE ;SYSTEM WAS BUSY
1574 006244 032777 000004 172666 1$: BIT #SW02,JSWR ;TYPE PERFORMANCE SUMMARY
1575 006252 001007 BNE 2$ ;BR IF NOT
1576 006254 005737 001214 TST STATIN ;TIME TO TYPE THE PERFORMANCE SUMMARY ?
1577 006260 001404 BEQ 2$ ;BR IF NOT
1578 006262 005037 001214 CLR STATIN ;CLEAR THE INDICATOR
1579 006266 004737 022544 JSR PC,STATPR ;TYPE THE SUMMARY
1580 006272 005737 001554 2$: TST PARQ ;ENTRY IN THE PARAMETER QUEUE ?
1581 006276 001410 BEQ 3$ ;BR IF NOT
1582 006300 013700 001554 MOV PARQ,RO ;PUT THE BLOCK ADDRESS INTO RO
1583 006304 004737 016376 JSR PC,SELPAR ;GET THE PARAMETERS FOR NEXT OPERATION
1584 006310 012701 001554 MOV #PARQ,R1 ;SETUP TO COMPRESS THE TABLE
1585 006314 004737 017460 JSR PC,CMPRES ;COMPRESS THE PARAMETER QUEUE
1586 006320 000137 005324 3$: JMP MAIN ;CONTINUE THE LOOP
1587
1588 ;SETUP TO REFORMAT AN ERROR SECTOR
1589
1590 006324 032777 000001 172606 REFMT: BIT #SW0,JSWR ;READ ONLY SWITCH SET ?
1591 006332 001055 BNE REFMTX ;BR IF IT IS
1592 006334 032777 000200 172576 BIT #SW7,JSWR ;SWITCH 7 SET ?
1593 006342 001051 BNE REFMTX ;BR IF IT IS
1594 006344 005737 001376 TST FORMAT ;WRITE HEADER & DATA ORDERS ALLOWED ?
1595 006350 001446 BEQ REFMTX ;BR IF NOT
1596 006352 016060 000272 000100 MOV $RPOC(RO), $NOCYL(RO) ;USE PRESENT CYLINDER
1597 006350 004737 022244 JSR PC,READDR ;GET CORRECTED SECTOR-TRACK ADDRESSES
1598 006364 112660 000077 MOVB (SP)+, $NTRK(RO) ;TRACK ADDR TO DPB
1599 006370 112660 000076 MOVB (SP)+, $NSEC(RO) ;SECTOR ADDR TO DPB
1600 006374 012760 000404 000102 MOV #260, $NWRDL(RO) ;WORD COUNT FOR FORMAT
1601 006402 023727 001364 000404 CMP MAXDL, #260. ;CAN A FULL SECTOR BE WRITTEN ?
1602 006410 103003 BHIS 1$ ;BR IF IT CAN
1603 006412 013760 001364 000102 MOV MAXDL, $NWRDL(RO) ;PUT TRANSFER SIZE INTO THE DPB
1604 006420 112760 000003 000074 1$: MOVB #3, $NCODE(RO) ;COMMAND CODE
1605 006426 004737 017224 JSR PC,GETPAT ;GET A PATTERN
1606 006432 110560 000075 MOVB R5, $NPATC(RO) ;PATTERN CODE TO CONTROL BLOCK
1607 006436 012760 177777 000104 MOV #-1, $NEXT(RO) ;SET PARAMETERS SELECTED INDICATOR
1608 006444 012701 001554 MOV #PARQ, R1 ;SET UP TO SEE IF BLOCK IN THE PARAMETER QUEUE
1609 006450 005711 2$: TST (R1) ;SEE IF AT END OF TABLE
1610 006452 001405 BEQ REFMTX ;BR IF AT END

```

```

1611 006454 020021      CMP      RO,(R1)+      ;SEE IF BLOCK AT PRESENT POSITION
1612 006456 001374      BNE      2$           ;BR IF NOT
1613 006460 005041      CLR      -(R1)       ;CLEAR THE ENTRY
1614 006462 004737 017460    JSR      PC,CMPRES   ;COMPRESS THE TABLE
1615 006466 000207      REFMTX: RTS      PC      ;RETURN
1616
1617                ;PROCESS THE ORDER TERMINATION
1618
1619 006470 111037 001246    PROCES: MOVB      (RO),UNIT      ;DRIVE NUMBER FOR ANY ERROR MESSAGES
1620 006474 005760 000016    TST      STATUS(RO)      ;SEE IF DRIVER SIGNALLED AN ERROR
1621 006500 100427      BMI      ERPROC        ;BR IF ERROR
1622 006502 032760 100000 000234    BIT      #BIT15,$RPCS1(RO) ;SEE IF 'SC' SET
1623 006510 001410      SEQ      1$           ;BR IF NOT SET
1624 006512 032760 040000 000234    BIT      #BIT14,$RPCS1(RO) ;SEE IF 'TRE' SET
1625 006520 001017      BNE      ERPROC        ;BR IF SET
1626 006522 032760 040000 000246    BIT      #BIT14,$RPDS1(RO) ;SEE IF 'ERR' SET
1627 006530 001013      BNE      ERPROC        ;BR IF SET
1628 006532 004737 012720      1$: JSR      PC,CKERR    ;NO ERROR, CHECK ERROR BITS ANYWAY
1629 006536 004737 013020      JSR      PC,CKBUS     ;NO ERROR, CHECK BUS ADDR & WC
1630 006542 032777 000002 172370    BIT      #SW01,$SWR    ;DATA COMPARE ?
1631 006550 001002      BNE      2$           ;BR IF NOT
1632 006552 004737 013104      JSR      PC,CMPAR     ;NO ERROR, COMPARE DATA
1633 006556 000207      2$: RTS      PC      ;RETURN
1634
1635                ;ORDER TERMINATED WITH AN ERROR - PROCESS THE ERROR
1636
1637 006560 032760 000200 000016    ERPROC: BIT      #BIT07,$STATUS(RO) ;DONE BIT SET ?
1638 006566 001402      BEQ      ERPRC1      ;BR IF ORDER DIDN'T COMPLETE NORMALLY
1639 006570 000137 007214      JMP      DONE        ;PROCESS ERROR WITH 'DONE' BIT SET
1640
1641                ;PROCESS ORDER COMPLETION WITH 'ERROR' & 'DONE NOT' BITS
1642
1643 006574 032760 010000 000016    ERPRC1: BIT      #BIT12,$STATUS(RO) ;SEE IF DRIVE WAS UNSAFE
1644 006602 001025      BNE      PUNSAF      ;BR IF YES
1645 006604 032760 004000 000016    BIT      #BIT11,$STATUS(RO) ;PARITY ERROR OCCURRED
1646 006612 001055      BNE      UCPAR       ;BR IF IT DID
1647 006614 032760 002000 000016    BIT      #BIT10,$STATUS(RO) ;FATAL PARITY ERROR
1648 006622 001056      BNE      FALPAR      ;BR IF THERE IS ONE
1649 006624 032760 001000 000016    BIT      #BIT09,$STATUS(RO) ;TIMEOUT?
1650 006632 001076      BNE      SWTIM       ;BR IF YES
1651 006634 032760 040002 000016    BIT      #BIT14!BIT01,$STATUS(RO) ;DRIVE WENT OFFLINE
1652 006642 001111      BNE      OFLIN       ;BR IF IT DID
1653 006644 032760 000004 000016    BIT      #BIT2,$STATUS(RO) ;PORT REQUEST TIME OUT
1654 006652 001141      BNE      PRTIM       ;BR IF IT DID
1655 006654 000207      RTS      PC          ;ERROR. RETURN
1656
1657                ;DRIVE IS PERSISTENTLY UNSAFE
1658
1659 006656 104401 001165    PUNSAF: TYPE      ,SCLF      ;CR-LF
1660 006662 104401 045326    TYPE      ,EM12      ;'DRIVE UNSAFE' MESSAGE
1661 006666 104401 052611    TYPE      ,DRNUM     ;DRIVE NUMBER
1662 006672 013746 001246    MOV      UNIT,-(SP)  ;SAVE UNIT FOR TYPEOUT
1663                ;TYPE DRIVE NUMBER
1664 006676 104403      TYPOS                ;GO TYPE--OCTAL ASCII
    
```

```

1665 006700 002 .BYTE 2 ;TYPE 2 DIGIT(S)
1666 006701 000 .BYTE 0 ;SUPPRESS LEADING ZEROS
1667 006702 104401 001165 TYPE .SCLF ;CR-LF
1668 006706 004737 020130 JSR PC,LINE1 ;PRINT LINE 1 OF ERROR MESSAGE
1669 006712 104414 045326 DISPLY EM12 ;PERSISTENT DEVICE UNSAFE MESSAGE
1670 006716 004737 020174 JSR PC,LINE2 ;PRINT LINE 2 OF ERROR MESSAGE
1671 006722 004737 020602 JSR PC,LINE3 ;PRINT LINE 3 OF ERROR MESSAGE
1672 006726 004737 021256 JSR PC,LINE4 ;PRINT LINE 4 OF THE ERROR MESSAGE
1673 006732 004737 023354 JSR PC,INCTOT ;INCREMENT TOTAL ERROR COUNT
1674 006736 004737 021712 JSR PC,LINE7 ;PRINT LINE 7 OF ERROR MESSAGE
1675 006742 000137 026376 JMP DROP ;DROP THE DRIVE
1676
1677 ;UNCORRECTABLE MASSBUS PARITY ERROR OCCURRED
1678
1679 006746 104401 001165 UCPAR: TYPE .SCLF ;CR-LF
1680 006752 104401 045230 TYPE EM10 ;'UNCORRECTABLE PARITY ERROR' MESSAGE
1681 006756 000404 BR FALPR1 ;FINISH PROCESSING THE ERROR
1682
1683 ;'FATAL' MASSBUS PARITY ERROR OCCURRED
1684
1685 006760 104401 001165 FALPAR: TYPE .SCLF ;CR-LF
1686 006764 104401 045273 TYPE EM11 ;'FATAL PARITY ERROR' MESSAGE
1687 006770 104401 052611 FALPR1: TYPE DRNUM ;DRIVE NUMBER
1688 006774 013746 001246 MOV UNIT,-(SP) ;SAVE UNIT FOR TYPEOUT
1689 ;TYPE DRIVE NUMBER
1690 007000 104403 TYPOS ;GO TYPE--OCTAL ASCII
1691 007002 002 .BYTE 2 ;TYPE 2 DIGIT(S)
1692 007003 000 .BYTE 0 ;SUPPRESS LEADING ZEROS
1693 007004 104401 001165 TYPE .SCLF ;CR-LF
1694 007010 004737 023354 JSR PC,INCTOT ;INCREMENT TOTAL ERROR COUNT
1695 007014 032777 100000 172116 BIT #SW15,SWR ;HALT ON ERROR ?
1696 007022 001401 BEQ IS ;BR IF NOT
1697 007024 000900 HALT ;ERROR HALT
1698 007026 000207 IS: RTS PC
1699
1700 ;SOFTWARE TIMEOUT OCCURRED
1701
1702 007030 004737 020130 SWTIM: JSR PC,LINE1 ;PRINT LINE 1 OF ERROR MESSAGE
1703 007034 104414 045357 DISPLY EM13 ;PRINT THE TIME OUT MESSAGE
1704 007040 004737 020174 JSR PC,LINE2 ;PRINT LINE 2 OF ERROR MESSAGE
1705 007044 004737 020602 JSR PC,LINE3 ;PRINT LINE 3 OF ERROR MESSAGE
1706 007050 004737 021256 JSR PC,LINE4 ;PRINT LINE 4 OF ERROR MESSAGE
1707 007054 004737 023354 JSR PC,INCTOT ;INCREMENT TOTAL ERROR COUNT
1708 007060 004737 021712 JSR PC,LINE7 ;PRINT LINE 7 OF ERROR MESSAGE
1709 007064 000207 RTS PC ;RETURN
1710
1711 ;DRIVE WENT OFFLINE
1712
1713 007066 104401 001165 OFLIN: TYPE .SCLF ;CR-LF
1714 007072 104401 045431 TYPE EM14 ;'DRIVE WENT OFFLINE' MESSAGE
1715 007076 104401 052611 TYPE DRNUM ;DRIVE NUMBER
1716 007102 013746 001246 MOV UNIT,-(SP) ;SAVE UNIT FOR TYPEOUT
1717 ;TYPE DRIVE NUMBER
1718 007106 104403 TYPOS ;GO TYPE--OCTAL ASCII

```



```

1719 007110 002 .BYTE 2 ;:TYPE 2 DIGIT(S)
1720 007111 000 .BYTE 0 ;:SUPPRESS LEADING ZEROS
1721 007112 104401 001165 TYPE $CRLF ;:CR-LF
1722 007116 004737 020130 JSR PC,LINE1 ;:PRINT LINE 1 OF THE ERROR MESSAGE
1723 007122 104414 045431 DISPLY EM14 ;:PRINT OFFLINE MESSAGE
1724 007126 004737 020174 JSR PC,LINE2 ;:PRINT LINE 2 OF THE ERROR MESSAGE
1725 007132 004737 020602 JSR PC,LINE3 ;:PRINT LINE 3 OF THE ERROR MESSAGE
1726 007136 004737 021256 JSR PC,LINE4 ;:PRINT LINE 4 OF THE ERROR MESSAGE
1727 007142 004737 023354 JSR PC,INCTOT ;:INCREMENT TOTAL ERROR COUNT
1728 007146 004737 021712 JSR PC,LINE7 ;:PRINT LINE 7 OF THE ERROR MESSAGE
1729 007152 000137 026376 JMP DROP ;:DROP THE DRIVE
1730
1731 ;:PORT REQUEST TIMEOUT ERROR
1732
1733 007156 004737 020130 PRTIM: JSR PC,LINE1 ;:TYPE LINE 1 OF THE ERROR MESSAGE
1734 007162 104414 045454 DISPLY EM15 ;:PRINT PORT TIME OUT MESSAGE
1735 007166 004737 020174 JSR PC,LINE2 ;:TYPE LINE 2 OF THE ERROR MESSAGE
1736 007172 004737 020602 JSR PC,LINE3 ;:TYPE LINE 3 OF THE ERROR MESSAGE
1737 007176 004737 021256 JSR PC,LINE4 ;:TYPE LINE 4 OF THE ERROR MESSAGE
1738 007202 004737 023354 JSR PC,INCTOT ;:INCREMENT TOTAL ERROR COUNT
1739 007206 004737 021712 JSR PC,LINE7 ;:TYPE LINE 7 OF THE ERROR MESSAGE
1740 007212 000207 RTS ;:RETURN
1741
1742 ;:PROCESS ORDER COMPLETION WITH 'ERROR' & 'DONE' BITS SET
1743
1744 007214 032760 000030 000016 DONE: BIT #BIT04,STATUS(RO) ;:UNSAFE OCCURRED
1745 007222 001402 .+6 ;:BR IF NOT
1746 007224 000137 012416 JMP UNSAF ;:REPORT UNSAFE
1747 007230 032760 040000 000244 BIT #BIT14,$RPCS2(RO) ;:IS 'WCE' SET?
1748 007236 001006 BNE 1$ ;:BR IF SET
1749 007240 032760 040000 000246 BIT #BIT14,$RPDS1(RO) ;:CHECK 'ERR'
1750 007246 001002 BNE 1$ ;:BR IF SET
1751 007250 000137 012162 JMP TRFER ;:PROCESS 'TRE'
1752 007254 032760 000400 000250 1$: BIT #BIT08,$RPER1(RO) ;:'HCRC' SET?
1753 007262 001402 .+6 ;:BR IF NOT
1754 007264 000137 010640 JMP HCRCER ;:PROCESS 'HCRC'
1755 007270 032760 000020 000250 BIT #BIT04,$RPER1(RO) ;:'FMT' SET?
1756 007276 001402 .+6 ;:BR IF NOT SET
1757 007300 000137 011022 JMP CKFMT ;:CHECK FORMAT ERROR
1758 007304 032760 000200 000250 BIT #BIT07,$RPER1(RO) ;:'HCE' SET?
1759 007312 001402 .+6 ;:BR IF NOT SET
1760 007314 000137 011216 JMP CKHCE ;:CHECK 'HCE' ERROR
1761 007320 032760 020000 000250 BIT #BIT13,$RPER1(RO) ;:'OPI' SET?
1762 007326 001402 .+6 ;:BR IF NOT SET
1763 007330 000137 011516 JMP OPIER ;:REPORT 'OPI'
1764 007334 032760 000010 000250 BIT #BIT3,$RPER1(RO) ;:'PAR' SET?
1765 007342 001402 .+6 ;:BR IF NOT SET
1766 007344 000137 011650 JMP PARER ;:REPORT 'PAR'
1767 007350 032760 000040 000250 BIT #BIT5,$RPER1(RO) ;:'WCF' SET?
1768 007356 001402 .+6 ;:BR IF NOT SET
1769 007360 000137 012320 JMP WCFER ;:REPORT 'WCF'
1770 007364 032760 002000 000250 BIT #BIT10,$RPER1(RO) ;:'IAE' SET?
1771 007372 001402 .+6 ;:BR IF NOT SET
1772 007374 000137 011742 JMP IAEER ;:REPORT 'IAE'

```

```

1773 007400 032760 004000 000250 BIT #BIT11,$RPER1(RO) ;'WLE' SET?
1774 007406 001402 BEQ .+6 ;BR IF NOT SET
1775 007410 000137 011774 JMP WLEER ;REPORT 'WLE'
1776 007414 032760 001000 000250 BIT #BIT9,$RPER1(RO) ;'AOE' SET?
1777 007422 001405 BEQ 2$ ;BR IF NOT SET
1778 007424 032760 002000 000246 BIT #BIT10,$RPDS1(RO) ;'LST' SET?
1779 007432 001401 BEQ 2$ ;BR IF NOT SET
1780 007434 000207 RTS PC ;'AOE' & 'LST' SET, EXIT
1781 007436 032760 010000 000250 2$: BIT #BIT12,$RPER1(RO) ;SEE IF 'DTE' SET
1782 007444 001402 BEQ .+6 ;BR IF NOT
1783 007446 000137 011626 JMP DTEER ;REPORT 'DTE' ERROR
1784 007452 032760 040000 000244 BIT #BIT14,$RPCS2(RO) ;SEE IF 'WCK' SET
1785 007460 001402 BEQ .+6 ;BR IF NOT SET
1786 007462 000137 010312 JMP WCKER ;REPORT 'WCK'
1787 007466 005760 000250 TST $RPER1(RO) ;SEE IF 'DCK' SET
1788 007472 100002 BPL .+6 ;BR IF NOT
1789 007474 000137 007520 JMP DCKER ;PROCESS 'DCK'
1790 007500 032760 140000 000276 BIT #BIT15!BIT14,$RPER3(RO) ;'SKI' OR 'OCL' SET
1791 007506 001402 BEQ .+6 ;BR IF NOT SET
1792 007510 000137 012262 JMP SKIER ;REPORT ERROR
1793 007514 000137 010770 JMP DRIVER ;REPORT DRIVE ERROR
1794
1795 ;PROCESS DATA ('DCK') CHECK ERROR
1796
1797 007520 022760 010042 000300 DCKER: CMP #10042,$RPEC1(RO) ;VALID POSITION COUNT ?
1798 007526 101406 BLOS 1$ ;BR IF NOT VALID
1799 007530 005760 000300 TST $RPEC1(RO) ;POSITION COUNT 0 ?
1800 007534 001402 BEQ 1$ ;BR IF 0'S
1801 007536 005760 000302 TST $RPEC2(RO) ;VALUE IN PATTERN REGISTER ?
1802 007542 001026 BNE 4$ ;BR IF YES
1803 007544 004737 020130 1$: JSR PC,LINE1 ;TYPE FIRST LINE OF ERROR MESSAGE
1804 007550 104414 047061 DISPLY EM45 ;TYPE 'ECC LOGIC ERROR'
1805 007554 004737 020174 JSR PC,LINE2 ;TYPE LINE 2 OF ERROR MESSAGE
1806 007560 004737 023354 JSR PC,INCTOT ;INCREMENT TOTAL ERROR COUNT
1807 007564 012737 000003 001252 MOV #3,RETRY ;RETRY COUNT
1808 007572 004737 015330 JSR PC,$RETRY ;RETRY THE ORDER
1809 007576 000403 BR 2$ ;RETRY WAS NOT SUCCESSFUL
1810 007600 004737 021630 JSR PC,LINE6C ;TYPE LINE 6C OF ERROR MESSAGE
1811 007604 000402 BR 3$ ;FINISH THE ERROR REPORT
1812 007606 004737 021636 2$: JSR PC,LINE6D ;TYPE LINE 6D OF ERROR MESSAGE
1813 007612 004737 021712 3$: JSR PC,LINE7 ;TYPE LINE 7 OF ERROR MESSAGE
1814 007616 000402 BR 5$ ;EXIT
1815 007620 004737 017772 4$: JSR PC,SPOTCK ;SEE IF ERROR AT A BAD SPOT ON THE PACK
1816 007624 000207 5$: RTS PC ;IT IS, DON'T REPORT IT
1817 007626 126027 000024 000001 CMPB $CODE(RO),#1 ;IS ORDER A WRITE CHECK ?
1818 007634 101002 BHI 6$ ;BR IF NOT
1819 007636 000137 010312 JMP WCKER ;REPORT ERROR UNDER WRITE CHECK PROCESSING
1820 007642 004737 020130 6$: JSR PC,LINE1 ;PRINT LINE 1 OF ERROR MESSAGE
1821 007646 104414 045531 DISPLY EM21 ;DATA CHECK ERROR
1822 007652 004737 020174 DCKER1: JSR PC,LINE2 ;PRINT LINE 2 OF ERROR MESSAGE
1823 007656 004737 020602 JSR PC,LINE3 ;PRINT LINE 3 OF ERROR MESSAGE
1824 007662 004737 021256 JSR PC,LINE4 ;PRINT LINE 4 OF ERROR MESSAGE
1825 007666 004737 014772 JSR PC,PRTBAD ;SEE IF BAD SECTOR TO BE PRINTED
1826 007672 012737 110100 001250 MOV #BIT15!BIT12!BIT06,$MSK ;LOAD ERROR MASK

```

1827	007700	032760	010100	000250		BIT	#BIT12!BIT06,\$RPER1(RO)	:CHECK 'DTE' & 'ECH'
1828	007706	001003				BNE	1\$	:BR IF SET
1829	007710	004737	021602			JSR	PC,LINE6	:PRINT LINE 6 OF ERROR MESSAGE
1830	007714	000541				BR	8\$	:FINISH THE ERROR REPORT
1831	007716	012737	000020	001252	1\$:	MOV	#16.,RETRY	:RETRY COUNT
1832	007724	005001				CLR	R1	:R1 IS OFFSET CODE POINTER
1833	007726	032760	000002	000262		BIT	#BIT01,\$RPDT(RO)	:IS DRIVE AN RPO6 ?
1834	007734	001002				BNE	16\$	:BR IF IT IS
1835	007736	012701	000007			MOV	#7,R1	:INCREMENT PAST RPO6 OFFSET CODES
1836	007742	004737	015756		15\$:	JSR	PC,RELBUF	:RELEASE THE BUFFER
1837	007746	004737	022244			JSR	PC,READDR	:GET THE ADDRESS OF THE ERROR SECTOR
1838	007752	112660	000011			MOVB	(SP)+,\$TRK(RO)	:TRACK ADDRESS OF ERROR SECTOR
1839	007756	112660	000010			MOVB	(SP)+,\$SEC(RO)	:SECTOR ADDRESS OF ERROR SECTOR
1840	007762	016060	000272	000012		MOV	\$RPCC(RO),\$CYL(RO)	:PRESENT CYLINDER
1841	007770	026060	000022	000020		CMP	\$SSEC(RO),\$WRDL(RO)	:SEE IF TRANSFER LENGTH LESS THAN 1 SECTOR
1842	007776	103010				BHIS	15\$	:BR IF IT IS; USE PRESENT TRANSFER LENGTH
1843	010000	016060	000022	000020		MOV	\$SSEC(RO),\$WRDL(RO)	:CHANGE TRANSFER SIZE TO 1 SECTOR
1844	010006	016060	000020	000004		MOV	\$WRDL(RO),\$WRDM(RO)	:SETUP WORD COUNT FOR OPERATION
1845	010014	005460	000004			NEG	\$WRDM(RO)	:CHANGE COUNT TO 2'S COMP
1846	010020	005046			15\$:	CLR	-(SP)	:SPACE FOR NEW BUFFER ADDRESS
1847	010022	004737	015622			JSR	PC,GETBUF	:GET A BUFFER
1848	010026	012660	000006			MOV	(SP)+,\$BUF(RO)	:NEW BUFFER ADDRESS TO DPB
1849	010032	004737	016320		2\$:	JSR	PC,GOODRIV	:RETRY
1850	010036	005760	000016		3\$:	TST	\$STATUS(RO)	:TEST FOR DONE
1851	010042	001775				BEQ	3\$	:BR IF NOT DONE
1852	010044	100075				BPL	10\$	:BR IF NOT ERROR
1853	010046	032760	000200	000016		BIT	#BIT7,\$STATUS(RO)	:SEE IF ORDER TERMINATED NORMALLY
1854	010054	001006				BNE	14\$	:BR IF NOT
1855	010056	004737	023354			JSR	PC,INCTOT	:INCREMENT TOTAL ERROR COUNT
1856	010062	104414	051246			DISPLY	LINE8	:DIFFERENT ERROR DURING RETRY'
1857	010066	000137	006574			JMP	ERPRC1	:SEE WHICH ERROR
1858	010072	033760	001250	000250	14\$:	BIT	MASK,\$RPER1(RO)	:LOOK AT CURRENT ERROR
1859	010100	001430				BEQ	5\$	:BR IF DIFFERENT ERROR
1860	010102	032760	010100	000250		BIT	#BIT12!BIT6,\$RPER1(RO)	: 'ECH' OR 'DTE' STILL SET ?
1861	010110	001437				BEQ	7\$	:BR IF NEITHER SET
1862	010112	105237	001253			INCB	RETRY+1	:INCREMENT RETRY COUNT
1863	010116	123737	001252	001253		CMPB	RETRY,RETRY+1	:DONE ?
1864	010124	001342				BNE	2\$	:BR IF NOT
1865	010126	005201				INC	R1	:INCREMENT TABLE INDEX
1866	010130	116137	002200	044647		MOVB	OFFCOD(R1),GENDPB+\$FMT	:OFFSET CODE
1867	010136	001435				BEQ	9\$	:BR IF END OF OFFSET TABLE
1868	010140	062737	000002	001252		ADD	#2,RETRY	:NEW RETRY LIMIT
1869	010146	004737	015222			JSR	PC,OFFST	:OFFSET
1870	010152	005737	044664		4\$:	TST	GENDPB+\$STATUS	:SEE IF FINISHED WITH OFFSET
1871	010156	001775				BEQ	4\$	:BR IF NOT
1872	010160	100324				BPL	2\$	:BR IF NO ERROR PERFORMING OFFSET
1873	010162	004737	022160		5\$:	JSR	PC,LINE8	:PRINT LINE 8 OF ERROR MESSAGE
1874	010166	004737	023260		6\$:	JSR	PC,INCHRD	:INCREMENT 'HARD' ERROR COUNT
1875	010172	004737	023354			JSR	PC,INCTOT	:INCREMENT TOTAL ERROR COUNT
1876	010176	004737	021712			JSR	PC,LINE7	:PRINT LINE 7 OF ERROR MESSAGE
1377	010202	004737	014772			JSR	PC,PRTBAD	:PRINT THE BAD SECTOR
1878	010206	000436				BR	13\$	:CLEAN UP AND RETURN
1879	010210	004737	021622		7\$:	JSR	PC,LINE6B	:PRINT LINE 6B OF ERROR MESSAGE
1880	010214	004737	021540			JSR	PC,LINE5B	:PRINT LINE 5B OF THE ERROR MESSAGE

```

1881 010220 004737 023234      8$: JSR    PC,INCSOF      ;INCREMENT 'SOFT' ERROR COUNT
1882 010224 004737 014232      JSR    PC,ECC           ;CORRECT THE ERROR USING ECC AND CHECK IT
1883 010230 000407              BR     11$             ;COMPARE THE BUFFER
1884 010232 004737 021636      9$: JSR    PC,LINE6D     ;PRINT LINE 6D OF ERROR MESSAGE
1885 010236 000753              BR     6$             ;INCREMENT ERROR COUNT
1886 010240 004737 021614      10$: JSR   PC,LINE6A    ;PRINT LINE 6A OF ERROR MESSAGE
1887 010244 004737 023234      JSR    PC,INCSOF     ;INCREMENT 'SOFT' ERROR COUNT
1888 010250 012737 000001 001300 11$: MOV    #1,FRSTER     ;SET PROCESSING 'DCKER' INDICATOR
1889 010256 004737 013122      JSR    PC,CMPCARD    ;COMPARE THE BUFFER
1890 010262 105737 001301      TSTB   FRSTER+1     ;ERROR IN COMPARE ?
1891 010266 100406              BMI    13$           ;BRANCH IF ERROR
1892 010270 004737 023354      JSR    PC,INCTOT    ;INCREMENT TOTAL ERROR COUNT
1893 010274 104414 051460      DISPLY .LIN9G       ;'DATA COMPARE OK' MESSAGE
1894 010300 004737 021712      12$: JSR    PC,LINE7    ;PRINT LINE 7 OF ERROR MESSAGE
1895 010304 004737 005324      13$: JSR    PC,REFMT    ;REFORMAT THE ERROR SECTOR
1896 010310 000207              RTS     PC           ;RETURN
1897
1898 ;WRITE CHECK ERROR PROCESSING
1899
1900 010312 032760 100000 000250 WCKER: BIT    #BIT15,$RPER1(RO) ;SEE IF 'DCK' SET ALSO
1901 010320 001034              BNE    2$           ;BR IF IT IS
1902 010322 004737 020120      JSR    PC,LINE1     ;PRINT LINE 1 OF ERROR MESSAGE
1903 010326 104414 045635      DISPLY .EM23        ;PRINT WCK & DCK NOT
1904 010332 005037 001250      CLR    MASK         ;CLEAR ERROR MASK
1905 010336 004737 020174      JSR    PC,LINE2     ;PRINT LINE 2 OF ERROR MESSAGE
1906 010342 004737 020602      JSR    PC,LINE3     ;PRINT LINE 3 OF ERROR MESSAGE
1907 010346 004737 021256      JSR    PC,LINE4     ;PRINT LINE 4 OF ERROR MESSAGE
1908 010352 004737 021346      JSR    PC,LINE5     ;PRINT LINE 5 OF ERROR MESSAGE
1909 010356 004737 023354      JSR    PC,INCTOT    ;INCREMENT TOTAL ERROR COUNT
1910 010362 012737 000003 001252  MOV    #3,RETRY     ;RETRY LIMIT
1911 010370 004737 015330      JSR    PC,$RETRY    ;RETRY THE OPERATION
1912 010374 000403              BR     1$           ;RETRY UNSUCCESSFUL
1913 010376 004737 021630      JSR    PC,LINE6C    ;PRINT LINE 6C OF ERROR MESSAGE
1914 010402 000502              BR     8$           ;FINISH PROCESSING THE ERROR
1915 010404 004737 021636      1$: JSR    PC,LINE6D  ;PRINT LINE 6D OF ERROR MESSAGE
1916 010410 000506              BR     10$          ;FINISH PROCESSING THE ERROR
1917 010412 004737 017772      2$: JSR    PC,SPOTCK  ;SEE IF ERROR AT BAD SPOT ON THE PACK
1918 010416 000507              BR     11$          ;EXIT IF AT BAD SPOT ON PACK
1919 010420 004737 020130      JSR    PC,LINE1     ;PRINT LINE 1 OF ERROR MESSAGE
1920 010424 012737 045562 010452  MOV    #EM22,13$    ;ASSUME THAT EM22 WILL BE PRINTED
1921 010432 032760 040000 000244  BIT    #BIT14,$RPCS2(RO) ;DID 'WCK' ALSO SET ?
1922 010440 001003              BNE    12$          ;BR IF IT DID
1923 010442 012737 046463 010452  MOV    #EM37,13$    ;MESSAGE FOR 'DCK' AND 'WCK' NOT DURING
1924 ;WRITE CHECK
1925 010450 104414              12$: DISPLY ;TYPE THE ERROR MESSAGE
1926 010452 000000              13$: .WORD 0 ;MESSAGE ADDRESS GOES HERE
1927 010454 004737 020174      JSR    PC,LINE2     ;PRINT LINE 2 OF ERROR MESSAGE
1928 010460 004737 020602      JSR    PC,LINE3     ;PRINT LINE 3 OF ERROR MESSAGE
1929 010464 004737 021256      JSR    PC,LINE4     ;PRINT LINE 4 OF ERROR MESSAGE
1930 010470 004737 021346      JSR    PC,LINE5     ;PRINT LINE 5 OF ERROR MESSAGE
1931 010474 032760 000100 000250  BIT    #BIT06,$RPER1(RO) ;ECH SET ALSO ?
1932 010502 001442              BEQ    8$           ;FINISH PROCESSING THE ERROR
1933 010504 012737 000020 001252  3$: MOV    #16,RETRY  ;RETRY LIMIT - 16 (10)
1934 010512 004737 016320      4$: JSR    PC,$ODRIV ;RETRY THE ORDER
    
```

```

1935 010516 005760 000016      5$:   TST      $STATUS(RO)      ;ORDER FINISHED ?
1936 010522 001775              BEQ      5$                ;BR IF NOT
1937 010524 100405              BMI      6$                ;BR IF ERROR ON ORDER
1938 010526 105237 001253      INCB     RETRY+1           ;INCREMENT RETRY COUNT
1939 010532 004737 021630      JSR     PC,LINE6C         ;PRINT LINE 6C OF ERROR MESSAGE
1940 010536 000431              BR      9$                ;FINISH ERROR PROCESSING
1941 010540 105237 001253      6$:   INCB     RETRY+1           ;INCREMENT RETRY COUNT
1942 010544 123737 001252 001253  CMPB     RETRY,RETRY+1     ;DONE ?
1943 010552 001714              BEQ      1$                ;BR IF AT RETRY LIMIT
1944 010554 032760 100000 000250  BIT      #BIT15,$RPER1(RO) ;'DCK' SET
1945 010562 001407              BEQ      7$                ;BR IF NOT - DIFFERENT ERROR
1946 010564 032760 000100 000250  BIT      #BIT06,$RPER1(RO) ;'ECH' ALSO SET ?
1947 010572 001347              SNE     4$                ;BR IF IT IS, RETRY ORDER
1948 010574 004737 021630      JSR     PC,LINE6C         ;PRINT LINE 6C OF ERROR MESSAGE
1949 010600 000403              BR      8$                ;FINISH PROCESSING ERROR
1950 010602 004737 022160      7$:   JSR     PC,LINE8         ;PRINT LINE 8 - 'DIFFERENT ERROR'
1951 010606 000405              BR      9$                ;FINISH PROCESSING ERROR
1952 010610 004737 023354      8$:   JSR     PC,INCTOT        ;INCREMENT TOTAL ERROR COUNT
1953 010614 004737 021712      JSR     PC,LINE7         ;FINISH THE ERROR MESSAGE
1954 010620 000406              BR      11$               ;EXIT
1955 010622 004737 023354      9$:   JSR     PC,INCTOT        ;INCREMENT TOTAL ERROR COUNT
1956 010626 004737 021712      10$:  JSR     PC,LINE7         ;FINISH THE ERROR MESSAGE
1957 010632 004737 006324      JSR     PC,REFMT         ;REFORMAT THE SECTOR IN ERROR
1958 010636 000207              11$:  RTS      PC            ;RETURN
1959
1960 ;REPORT 'HCRC' ERROR
1961
1962 010640 004737 017772      HCRCER: JSR     PC,SPOTCK       ;SEE IF ERROR AT PACK BAD SPOT
1963 010644 000450              BR      3$                ;EXIT IF IT IS
1964 010646 004737 020130      JSR     PC,LINE1         ;PRINT LINE 1 OF ERROR MESSAGE
1965 010652 104414 045510      DISPLY  ,EM20            ;REPORT 'HCRC'
1966 010656 004737 020174      JSR     PC,LINE2         ;PRINT LINE 2 OF ERROR MESSAGE
1967 010662 004737 020602      JSR     PC,LINE3         ;PRINT LINE 3 OF ERROR MESSAGE
1968 010666 004737 021256      JSR     PC,LINE4         ;PRINT LINE 4 OF ERROR MESSAGE
1969 010672 032760 040000 000244  BIT      #BIT14,$RPCS2(RO) ;'WCE' ERROR ALSO ?
1970 010700 001402              BEQ      1$                ;BR IF NOT
1971 010702 004737 021346      JSR     PC,LINES         ;DISPLAY WORDS WHICH CAUSED 'WCE'
1972 010706 004737 023234      1$:   JSR     PC,INCSOF        ;INCREMENT 'SOFT' ERROR COUNT
1973 010712 004737 023354      JSR     PC,INCTOT        ;INCREMENT TOTAL ERROR COUNT
1974 010716 012737 000400 001250  MOV      #BIT8,MASK       ;SET ERROR MASK
1975 010724 012737 000003 001252  MOV      #3,RETRY         ;RETRY LIMIT
1976 010732 004737 015330      JSR     PC,$RETRY        ;RETRY ORDER
1977 010736 000405              BR      2$                ;RETRY NOT SUCCESSFUL
1978 010740 004737 021630      JSR     PC,LINE6C         ;PRINT LINE 6C OF ERROR MESSAGE
1979 010744 004737 021712      JSR     PC,LINE7         ;PRINT LINE 7 OF ERROR MESSAGE
1980 010750 000406              BR      3$                ;EXIT
1981 010752 004737 021636      2$:   JSR     PC,LINE6D        ;PRINT LINE 6D OF ERROR MESSAGE
1982 010756 004737 021712      JSR     PC,LINE7         ;PRINT LINE 7 OF ERROR MESSAGE
1983 010762 004737 006324      JSR     PC,REFMT         ;REFORMAT THE ERROR SECTOR
1984 010766 000207              3$:   RTS      PC            ;RETURN
1985
1986 ;REPORT DRIVE ERROR
1987
1988 010770 004737 020130      DRIVER: JSR     PC,LINE1       ;PRINT LINE 1 OF ERROR MESSAGE

```

Handwritten initials or mark.

```

1999 010774 104414 046125      DISPLY  EM30      ;REPORT DRIVE ERROR
1990 011000 004737 020174      JSR     PC,LINE2  ;PRINT LINE 2 OF ERROR MESSAGE
1991 011004 004737 020602      JSR     PC,LINE3  ;PRINT LINE 3 OF ERROR MESSAGE
1992 011010 004737 023354      JSR     PC,INCTOT ;INCREMENT TOTAL ERROR COUNT
1993 011014 004737 021712      JSR     PC,LINE7  ;PRINT LINE 7 OF ERROR MESSAGE
1994 011020 000207                RTS     PC        ;RETURN
1995
1996                ;PROCESS FORMAT ('FER') ERROR
1997
1998 011022 032760 000400 000250 CKFMT: BIT   #BIT8,$RPER1(RO) ;'HCRC' SET ON ORIGINAL ERROR ?
1999 011030 001402                BEQ    1$        ;BR IF NOT SET
2000 011032 000137 010640                JMP    HRCRER   ;REPORT HCRC ERROR
2001 011036 004737 022244                1$: JSR    PC,READDR ;GET CORRECTED TRACK & SECTOR ADDRSES
2002 011042 004737 015246                JSR    PC,READHD ;READ HEADER
2003 011046 032737 000400 044702 BIT   #BIT8,GENREG+RPER1 ;'HCRC' SET WHEN HEADER READ?
2004 011054 001002                BNE    2$        ;BR IF 'HCRC' SET
2005 011056 000137 012022                JMP    FMTER    ;NO. ERROR IS 'FMT' ONLY
2006 011062 004737 017772                2$: JSR    PC,SPOTCK ;SEE IF ERROR AT BAD SPOT ON THE PACK
2007 011066 000452                BR     5$        ;EXIT IF IT IS
2008 011070 004737 020130                JSR    PC,LINE1 ;PRINT LINE 1 OF ERROR MESSAGE
2009 011074 104414 045714                DISPLY  EM24      ;HEADER READ ERROR - FMT BIT DROPPED UP
2010 011100 004737 020174                JSR    PC,LINE2  ;PRINT LINE 2 OF ERROR MESSAGE
2011 011104 004737 020602                JSR    PC,LINE3  ;PRINT LINE 3 OF ERROR MESSAGE
2012 011110 004737 021256                JSR    PC,LINE4  ;PRINT LINE 4 OF ERROR MESSAGE
2013 011114 032760 040000 000244 BIT   #BIT14,$RPCS2(RO) ;'WCE' ERROR ALSO ?
2014 011122 001402                BEQ    3$        ;BR IF NOT
2015 011124 004737 021346                JSR    PC,LINES  ;DISPLAY WORDS WHICH CAUSED 'WCE'
2016 011130 004737 021446                3$: JSR    PC,LINESA ;DISPLAY HEADER
2017 011134 004737 023234                JSR    PC,INCSOF ;INCREMENT SOFT ERROR COUNT
2018 011140 004737 023354                JSR    PC,INCTOT ;INCREMENT TOTAL ERROR COUNT
2019 011144 012737 000020 001250 MOV   #BIT4,MASK  ;SET ERROR MASK
2020 011152 012737 000003 001252 MOV   #3,RETRY   ;RETRY LIMIT
2021 011160 004737 015330                JSR    PC,$RETRY ;RETRY THE ORDER
2022 011164 000405                BR     4$        ;RETRY NOT SUCCESSFUL
2023 011166 004737 021630                JSR    PC,LINE6C ;PRINT LINE 6C OF ERROR MESSAGE
2024 011172 004737 021712                JSR    PC,LINE7  ;PRINT LINE 7 OF ERROR MESSAGE
2025 011176 000406                BR     5$        ;EXIT
2026 011200 004737 021636                4$: JSR    PC,LINE6D ;PRINT LINE 6D OF ERROR MESSAGE
2027 011204 004737 021712                JSR    PC,LINE7  ;PRINT LINE 7 OF ERROR MESSAGE
2028 011210 004737 006324                JSR    PC,REFMT  ;REFORMAT THE ERROR SECTOR
2029 011214 000207                5$: RTS     PC        ;RETURN
2030
2031                ;PROCESS HEADER COMPARE ('HCE') ERROR
2032
2033 011216 032760 000400 000250 CKHCE: BIT   #BIT8,$RPER1(RO) ;HCRC SET ON ORIGINAL ERROR ?
2034 011224 001402                BEQ    1$        ;BR IF NOT SET
2035 011226 000137 010640                JMP    HRCRER   ;REPORT HEADER CRC ERROR
2036 011232 004737 022244                1$: JSR    PC,READDR ;GET CURRENT SECTOR & TRACK ADDR
2037 011236 004737 015246                JSR    PC,READHD ;READ HEADER OF CURRENT SECTOR
2038 011242 032737 000400 044702 BIT   #BIT8,GENREG+RPER1 ;'HCRC' SET ?
2039 011250 001016                BNE    3$        ;BR IF SET
2040 011252 042737 010000 054374 BIC   #BIT12,CYLDER ;CLEAR FORMAT BIT FROM HEADER
2041 011260 026037 000272 054374 CMP   $RPCC(RO),CYLDER ;CORRECT CYLINDER ?
2042 011266 001402                BEQ    2$        ;BR IF IT IS
    
```

```

2043 011270 000137 011442          JMP      POSER          ;REPORT POSITIONING ERROR
2044 011274 052737 010000 054374 2$:  BIS      #BIT12,CYLDER ;RESTORE THE FORMAT BIT
2045 011302 000137 012100          JMP      HCFER         ;REPORT 'HCE' ERROR
2046 011306 004737 017772          JSR      PC,SPOTCK     ;SEE IF ERROR AT BAD SPOT
2047 011312 000452          BR       6$           ;EXIT IF IT IS
2048 011314 004737 020130          JSR      PC,LINE1     ;PRINT LINE 1 OF ERROR MESSAGE
2049 011320 104414 045762          DISPLY  EM25         ;HEADER READ ERROR - 'HCE' SET
2050 011324 004737 020174          JSR      PC,LINE2     ;PRINT LINE 2 OF ERROR MESSAGE
2051 011330 004737 020602          JSR      PC,LINE3     ;PRINT LINE 3 OF ERROR MESSAGE
2052 011334 004737 021256          JSR      PC,LINE4     ;PRINT LINE 4 OF ERROR MESSAGE
2053 011340 032760 040000 000244  BIT      #BIT14,$RPCS2(RO) ;'WCE' ERROR ALSO ?
2054 011346 001402          BEQ     4$           ;BR IF NOT
2055 011350 004737 021346          JSR      PC,LINES     ;DISPLAY WORDS WHICH CAUSED 'WCE'
2056 011354 004737 021442          JSR      PC,LINE5A    ;PRINT LINE 5 OF ERROR MESSAGE
2057 011360 004737 023234          JSR      PC,INCSOF    ;INCREMENT SOFT ERROR COUNT
2058 011364 004737 023354          JSR      PC,INCTOT    ;INCREMENT TOTAL ERROR COUNT
2059 011370 012737 000200 001250  MOV      #BIT7,MASK    ;SET ERROR MASK
2060 011376 012737 000003 001252  MOV      #3,RETRY      ;RETRY LIMIT
2061 011404 004737 015330          JSR      PC,$RETRY    ;RETRY THE ORDER
2062 011410 000405          SR      5$           ;RETRY NOT SUCCESSFUL
2063 011412 004737 021630          JSR      PC,LINE6C    ;PRINT LINE 6C OF ERROR MESSAGE
2064 011416 004737 021712          JSR      PC,LINE7     ;PRINT LINE 7 OF ERROR MESSAGE
2065 011422 000406          BR       6$           ;EXIT
2066 011424 004737 021636          JSR      PC,LINE6D    ;PRINT LINE 6D OF ERROR MESSAGE
2067 011430 004737 021712          JSR      PC,LINE7     ;PRINT LINE 7 OF ERROR MESSAGE
2068 011434 004737 006324          JSR      PC,REFMT     ;REFORMAT THE ERROR SECTOR
2069 011440 000207          6$:     RTS      PC      ;RETURN
2070
2071          ;REPORT POSSIBLE POSITIONING ERROR
2072
2073 011442 004737 015170          POSER:  JSR      PC,RECALT ;RECALIBRATE
2074 011446 004737 020130          JSR      PC,LINE1     ;PRINT LINE 1 OF ERROR MESSAGE
2075 011452 104414 047310          DISPLY  EM51         ;PROGRAM DETECTED POSITIONING ERROR
2076 011456 004737 020174          JSR      PC,LINE2     ;PRINT LINE 2 OF ERROR MESSAGE
2077 011462 004737 020630          JSR      PC,LINE3C    ;PRINT LINE 3C OF ERROR MESSAGE
2078 011466 052737 010000 054374  BIS      #BIT12,CYLDER ;RESTORE THE FORMAT BIT
2079 011474 004737 021446          JSR      PC,LINE5A    ;PRINT LINE 5A OF THE ERROR MESSAGE
2080 011500 004737 023330          JSR      PC,INCMIS    ;INCREMENT MISPOSITIONING COUNT
2081 011504 004737 023354          JSR      PC,INCTOT    ;INCREMENT TOTAL ERROR COUNT
2082 011510 004737 022040          JSR      PC,LINE7A    ;PRINT LINE 7A OF ERROR MESSAGE
2083 011514 000207          RTS      PC          ;EXIT
2084
2085          ;REPORT 'OPI' ERROR
2086
2087 011516 004737 017772          OPIER:  JSR      PC,SPOTCK ;SEE IF ERROR AT BAD SPOT
2088 011522 000207          RTS      PC          ;RETURN IF IT IS
2089 011524 004737 020130          JSR      PC,LINE1     ;PRINT LINE 1 OF ERROR MESSAGE
2090 011530 104414 046157          DISPLY  EM31         ;'OPI' ERROR
2091 011534 004737 020174          JSR      PC,LINE2     ;PRINT LINE 2 OF ERROR MESSAGE
2092 011540 004737 020602          JSR      PC,LINE3     ;PRINT LINE 3 OF ERROR MESSAGE
2093 011544 004737 021256          JSR      PC,LINE4     ;PRINT LINE 4 OF ERROR MESSAGE
2094 011550 004737 023354          JSR      PC,INCTOT    ;INCREMENT TOTAL ERROR COUNT
2095 011554 012737 020000 001250  MOV      #BIT13,MASK   ;ERROR MASK
2096 011562 012737 000003 001252  OPIER1: MOV      #3,RETRY ;RETRY LIMIT
    
```

011570 004737 015330  
 011574 000405  
 011576 004737 021630  
 011602 004737 021712  
 011606 000207  
 011610 004737 021636  
 011614 004737 021712  
 011620 004737 006324  
 011624 000207  
  
 011626 004737 017772  
 011632 000207  
 011634 004737 020130  
 011640 104414 046222  
 011644 000137 007652  
  
 011650 004737 020130  
 011654 104414 046255  
 011660 004737 020174  
 011664 004737 020706  
 011670 004737 021256  
 011674 004737 023354  
 011700 012737 000010  
 011706 012737 000003  
 011714 004737 015330  
 011720 000405  
 011722 004737 021630  
 011726 004737 021712  
 011732 000207  
 011734 004737 021636  
 011740 000772  
  
 011742 004737 020130  
 011746 10441 046374  
 011752 00473 020174  
 011756 00473 020774  
 011762 004737 023354  
 011766 004737 021712  
 011772 000207  
  
 011774 004737 020130  
 012000 104414 046432  
 012004 004737 020174  
 012010 004737 023354  
 012014 004737 021712  
 012020 000207

001250  
001252

```

JSR PC,$RETRY      :RETRY THE ORDER
BR 1$              :RETRY UNSUCCESSFUL
JSR PC,LINE6C     :PRINT LINE 6C OF ERROR MESSAGE
JSR PC,LINE7      :PRINT LINE 7 OF ERROR MESSAGE
RTS PC             :EXIT
1$: JSR PC,LINE6D  :PRINT LINE 6D OF ERROR MESSAGE
    JSR PC,LINE7   :PRINT LINE 7 OF ERROR MESSAGE
    JSR PC,REFMT   :REFORMAT THE ERROR SECTOR
    RTS PC         :RETURN

:REPORT 'DTE' ERROR

DTEER: JSR PC,SPOTCK :SEE IF ERROR AT BAD SPOT
       RTS PC       :RETURN IF IT IS
       JSR PC,LINE1 :PRINT LINE 1 OF ERROR MESSAGE
       DISPLY EM32  :'DTE' ERROR
       JMP DCKER1  :FINISH PROCESSING THE 'DTE' ERROR

:REPORT 'PAR' ERROR

PARER: JSR PC,LINE1 :PRINT LINE 1 OF ERROR MESSAGE
       DISPLY EM33  :REPORT 'PAR'
       JSR PC,LINE2 :PRINT LINE 2 OF ERROR MESSAGE
       JSR PC,LINE3E :PRINT LINE 3E OF ERROR MESSAGE
       JSR PC,LINE4 :PRINT LINE 4 OF ERROR MESSAGE
       JSR PC,INCTOT :INCREMENT TOTAL ERROR COUNT
       MCV #BIT03,MASK :ERROR MASK
       MOV #3,RETRY  :RETRY LIMIT
       JSR PC,$RETRY :RETRY ORDER
       BR 2$        :RETRY UNSUCCESSFUL
       JSR PC,LINE6C :RETRY SUCCESSFUL
       RTS PC       :PRINT LINE 7 OF ERROR MESSAGE
2$: JSR PC,LINE6D  :PRINT LINE 6D OF ERROR MESSAGE
    BR 1$          :FINISH ERROR MESSAGE

:REPORT 'IAE' ERROR

IAEER: JSR PC,LINE1 :PRINT LINE 1 OF ERROR MESSAGE
       DISPLY EM35  :REPORT 'IAE'
       JSR PC,LINE2 :PRINT LINE 2 OF ERROR MESSAGE
       JSR PC,LINE3F :PRINT LINE 3F OF ERROR MESSAGE
       JSR PC,INCTOT :INCREMENT TOTAL ERROR COUNT
       JSR PC,LINE7  :PRINT LINE 7 OF ERROR MESSAGE
       RTS PC       :RETURN

:REPORT 'WLE' ERROR

WLEER: JSR PC,LINE1 :PRINT LINE 1 OF ERROR MESSAGE
       DISPLY EM36  :REPORT 'WLE'
       JSR PC,LINE2 :PRINT LINE 2 OF ERROR MESSAGE
       JSR PC,INCTOT :INCREMENT TOTAL ERROR COUNT
       JSR PC,LINE7  :PRINT LINE 7 OF ERROR MESSAGE
       RTS PC       :RETURN

```



012022  
012026  
012032  
012036  
012042  
012046  
012054  
012056  
012052  
012056  
012066  
012072  
012076  
012100  
012104  
012110  
012114  
012120  
012124  
012132  
012134  
012140  
012144  
012150  
012154  
012160  
012162  
012166  
012172  
012176  
012182  
012186  
012192  
012196  
012202  
012206  
012212  
012220  
012222  
012230  
012234  
012240  
012242  
012246  
012250  
012254  
012260

004737 020130  
104414 046043  
004737 020174  
004737 020602  
004737 021256  
032760 040000 000244  
001402  
004737 021346  
004737 021446  
004737 023354  
004737 021712  
000207  
  
004737 020130  
104414 046070  
004737 020174  
004737 020602  
004737 021256  
032760 040000 000244  
001402  
004737 021346  
004737 021446  
004737 023354  
004737 021712  
004737 006324  
000207  
  
004737 020130  
104414 046545  
004737 020174  
004737 020602  
004737 021256  
004737 023354  
032760 121400 000244  
001415 001252  
005037 001250  
004737 015330  
000403  
004737 021630  
000402  
004737 021636  
004737 021712  
000207

:REPORT FORMAT ERROR

```
FMTER: JSR PC,LINE1 ;PRINT LINE 1 OF ERROR MESSAGE
        DISPLY EM26 ;FORMAT ERROR
        JSR PC,LINE2 ;PRINT LINE 2 OF ERROR MESSAGE
        JSR PC,LINE3 ;PRINT LINE 3 OF ERROR MESSAGE
        JSR PC,LINE4 ;PRINT LINE 4 OF ERROR MESSAGE
        BIT #BIT14,$RPCS2(RO) ;'WCE' ERROR ALSO ?
        BEQ 1$ ;BR IF NOT
        JSR PC,LINES ;DISPLAY WORDS WHICH CAUSED 'WCE'
1$: JSR PC,LINESA ;PRINT LINE 5A OF ERROR MESSAGE
    JSR PC,INCTOT ;INCREMENT TOTAL ERROR COUNT
    JSR PC,LINE7 ;PRINT LINE 7 OF ERROR MESSAGE
    RTS PC
```

:REPORT HEADER COMPARE ERROR

```
HCEER: JSR PC,LINE1 ;PRINT LINE 1 OF ERROR MESSAGE
        DISPLY EM27 ;HEADER COMPARE ERROR
        JSR PC,LINE2 ;PRINT LINE 2 OF ERROR MESSAGE
        JSR PC,LINE3 ;PRINT LINE 3 OF ERROR MESSAGE
        JSR PC,LINE4 ;PRINT LINE 4 OF ERROR MESSAGE
        BIT #BIT14,$RPCS2(RO) ;'WCE' ERROR ALSO ?
        BEQ 1$ ;BR IF NOT
        JSR PC,LINES ;DISPLAY WORDS WHICH CAUSED 'WCE'
1$: JSR PC,LINESA ;PRINT LINE 5A OF ERROR MESSAGE
    JSR PC,INCTOT ;INCREMENT TOTAL ERROR COUNT
    JSR PC,LINE7 ;PRINT LINE 7 OF ERROR MESSAGE
    JSR PC,REFMT ;REFORMAT THE ERROR SECTOR
    RTS PC ;RETURN
```

:PROCESS CONTROL/INTERFACE TRANSFER ERROR

```
TRFER: JSR PC,LINE1 ;PRINT LINE 1 OF ERROR MESSAGE
        DISPLY EM40 ;RHI1 OR UNIBUS TRANSFER ERROR
        JSR PC,LINE2 ;PRINT LINE 2 OF ERROR MESSAGE
        JSR PC,LINE3 ;PRINT LINE 3 OF ERROR MESSAGE
        JSR PC,LINE4 ;PRINT LINE 4 OF ERROR MESSAGE
        JSR PC,INCTOT ;INCREMENT TOTAL ERROR COUNT
        BIT #BIT15:BIT13:BIT9:BIT8,$RPCS2(RO) ;'DLT','UPE','MXF','MOPE' SET ?
        BEQ 2$ ;BR IF NONE SET
        MOV #3,RETRY ;RETRY LIMIT
        CLR MASK ;CLEAR ERROR MASK
        JSR PC,$RETRY ;RETRY THE OPERATION
        BR 1$ ;RETURN HERE IF RETRY UNSUCCESSFUL
        JSR PC,LINE6C ;PRINT LINE 6C OF ERROR MESSAGE
        BR 2$ ;FINISH THE ERROR REPORT
1$: JSR PC,LINE6D ;PRINT LINE 6D OF ERROR MESSAGE
2$: JSR PC,LINE7 ;PRINT LINE 7 OF ERROR MESSAGE
    RTS PC
```

:PROCESS 'SKI' OR 'OCYL' ERRORS

DZRJD.019 MAIN PROGRAM

```

22205 012262 004737 020130
22206 012266 104414 047221
22207 012272 004737 020174
22208 012276 004737 020616
22209 012302 004737 023354
22210 012306 004737 023304
22211 012312 004737 022040
22212 012316 000207

```

```

SKIER: JSR PC,LINE1 ;PRINT LINE 1 OF ERROR MESSAGE
DISPLY EM50 ;'SKI' OR 'OCYL' ERROR
JSR PC,LINE2 ;PRINT LINE 2 OF ERROR MESSAGE
JSR PC,LINE3B ;PRINT LINE 3B OF ERROR MESSAGE
JSR PC,INCTOT ;INCREMENT TOTAL ERROR COUNT
JSR PC,INCSKI ;INCREMENT 'SKI' OR 'OCYL' ERROR COUNT
JSR PC,LINE7A ;PRINT LINE 7A OF ERROR MESSAGE
RTS PC

```

;REPORT WRITE CLOCK FAILURE ('WCF')

```

22215 012320 004737 020130
22216 012324 104414 046332
22217 012330 004737 020174
22218 012334 004737 020610
22219 012340 004737 021256
22220 012344 004737 023354
22221 012350 004737 014772
22222 012354 012737 000003
22223 012362 012737 000040
22224 012370 004737 015330
22225 012374 000405
22226 012376 004737 021630
22227 012402 004737 021712
22228 012406 000207
22229 012410 004737 021636
22230 012414 000772

```

```

WCFER: JSR PC,LINE1 ;PRINT LINE 1 OF ERROR MESSAGE
DISPLY EM34 ;REPORT WRITE CLOCK FAILURE
JSR PC,LINE2 ;PRINT LINE 2 OF ERROR MESSAGE
JSR PC,LINE3A ;PRINT LINE 3A OF ERROR MESSAGE
JSR PC,LINE4 ;PRINT LINE 4 OF ERROR MESSAGE
JSR PC,INCTOT ;INCREMENT TOTAL ERROR COUNT
JSR PC,PRIBAD ;SEE IF BAD SECTOR TO BE PRINTED
MOV #3,RETRY ;RETRY COUNT
MOV #BITS, MASK ;ERROR MASK
JSR PC,$RETRY ;RETRY THE ORDER
BR 2$ ;RETURN HERE IF RETRY UNSUCCESSFUL
JSR PC,LINE6C ;PRINT LINE 6C OF ERROR MESSAGE
1$: JSR PC,LINE7 ;PRINT LINE 7 OF ERROR MESSAGE
RTS PC
2$: JSR PC,LINE6D ;PRINT LINE 6D OF ERROR MESSAGE
BR 1$

```

001252  
001250

;PROCESS DRIVE UNSAFE ERROR

```

22233 012416 004737 020130
22234 012422 104414 047353
22235 012426 004737 020174
22236 012432 004737 020602
22237 012436 004737 023354
22238 012442 012737 000003
22239 012450 004737 015330
22240 012454 000403
22241 012456 004737 021630
22242 012462 000402
22243 012464 004737 021636
22244 012470 004737 021712
22245 012474 000207

```

```

UNSAF: JSR PC,LINE1 ;PRINT LINE 1 OF ERROR MESSAGE
DISPLY EM60 ;REPORT DRIVE UNSAFE
JSR PC,LINE2 ;PRINT LINE 2 OF ERROR MESSAGE
JSR PC,LINE3 ;PRINT LINE 3 OF ERROR MESSAGE
JSR PC,INCTOT ;INCREMENT TOTAL ERROR COUNT
MOV #3,RETRY ;RETRY COUNT
JSR PC,$RETRY ;RETRY THE ORDER
BR 1$ ;RETRY WAS UNSUCCESSFUL
JSR PC,LINE6C ;PRINT LINE 6C OF ERROR MESSAGE
BR 2$ ;CONTINUE WITH ERROR REPORT
1$: JSR PC,LINE6D ;PRINT LINE 6D OF ERROR MESSAGE
2$: JSR PC,LINE7 ;PRINT LINE 7 OF ERROR MESSAGE
RTS PC ;RETURN

```

001252

;REPORT AN 'UNKNOWN' DATA PATTERN

```

22248 012476 105737 001300
22249 012502 001013
22250 012504 004737 020130
22251 012510 104414 046730
22252 012514 004737 020174
22253 012520 004737 020610
22254 012524 004737 021256
22255 012530 000404

```

```

NOMTCH: TSTB FRSTER ;FIRST ERROR IN THE SECTOR ?
1$ BNE 1$ ;BR IF NOT OR IF PROCESSING 'DCKER'
JSR PC,LINE1 ;TYPE LINE 1 OF ERROR MESSAGE
DISPLY EM43 ;'CAN'T MATCH DATA WITH PATTERN'
JSR PC,LINE2 ;PRINT LINE 2 OF ERROR MESSAGE
JSR PC,LINE3A ;PRINT LINE 3A OF ERROR MESSAGE
JSR PC,LINE4 ;PRINT LINE 4 OF ERROR MESSAGE
BR 2$ ;CONTINUE PROCESSING ERROR

```

```

02259 012532 104414 046730 1S:  DISPLY  .EM43          ;'CAN'T MATCH DATA WITH PATTERN'
02260 012536 104414 001165  DISPLY  .$CRLF        ;CR-LF
02261 012542 104414 051410 2S:  DISPLY  .LIN9I      ;HEADER FOR DATA PRINTOUT
02262 012546 010146  MOV      R1,-(SP)    ;ADDRESS OF WORD 1
02263 012550 004737 022172  JSR      PC,LIN0CT  ;TYPE WORD 1
02264 012554 104414 052073  DISPLY  .LINSF      ;SPACES
02265 012560 012146  MOV      (R1)+,-(SP) ;ADDRESS OF WORD 1
02266 012562 004737 022172  JSR      PC,LIN0CT  ;TYPE WORD 1
02267 012566 104414 001165  DISPLY  .$CRLF        ;CR-LF
02268 012572 010146  MOV      R1,-(SP)    ;ADDRESS OF WORD 2
02269 012574 004737 022172  JSR      PC,LIN0CT  ;TYPE WORD 2
02270 012580 104414 052073  DISPLY  .LINSF      ;SPACES
02271 012604 012146  MOV      (R1)+,-(SP) ;ADDRESS OF WORD 2
02272 012606 004737 022172  JSR      PC,LIN0CT  ;TYPE WORD 2
02273 012612 104414 001165  DISPLY  .$CRLF        ;CR-LF
02274 012616 010146  MOV      R1,-(SP)    ;ADDRESS OF WORD 3
02275 012620 004737 022172  JSR      PC,LIN0CT  ;TYPE WORD 3
02276 012624 104414 052073  DISPLY  .LINSF      ;SPACES
02277 012630 012146  MOV      (R1)+,-(SP) ;ADDRESS OF WORD 3
02278 012632 004737 022172  JSR      PC,LIN0CT  ;TYPE WORD 3
02279 012636 104414 001165  DISPLY  .$CRLF        ;CR-LF
02280 012642 010146  MOV      R1,-(SP)    ;ADDRESS OF WORD 4
02281 012644 004737 022172  JSR      PC,LIN0CT  ;TYPE WORD 4
02282 012650 104414 052073  DISPLY  .LINSF      ;SPACES
02283 012654 012146  MOV      (R1)+,-(SP) ;ADDRESS OF WORD 4
02284 012656 004737 022172  JSR      PC,LIN0CT  ;TYPE WORD 4
02285 012662 104414 001165  DISPLY  .$CRLF        ;CR-LF
02286 012666 062701 000770  ADD     #(<252.*2.),R1 ;INCREMENT BUFFER POINTER
02287 012672 005002  CLR      R2          ;CLEAR 'WORDS TO COMPARE' COUNT IN R2
02288 012674 112737 000001 001300  MOVB    #1,FRSTER    ;SET 'NOT FIRST ERROR' INDICATOR
02289 012702 112737 177777 001301  MOVB    #-1,FRSTER+1 ;SET ERROR FOUND INDICATOR
02290 012710 013737 001374 001310  MCV     CMLMT,LIMIT  ;RESET THE COMPARE ERROR TYPEOLT LIMIT
02291 012716 000297  RTS      PC          ;RETURN
02292
02293 ;CHECK ERROR BITS IN THE RH11 & RPO4/5/6 REGISTERS
02294
02295 012720 032760 060000 000234 CKERR:  BIT     #60000,$RPCS1(R0) ;SEE IF 'TRE' OR 'MOPE' SET
02296 012726 001015  BNE     1S          ;BR IF EITHER SET
02297 012730 032760 177400 000244  BIT     #177400,$RPCS2(R0) ;SEE IF ERROR BITS IN CS2 SET
02298 012736 001011  BNE     1S          ;BR IF ANY SET
02299 012740 005760 000250  TST     $RPER1(R0)   ;ANY BITS SET IN ER1
02300 012744 001006  BNE     1S          ;BR IF ANY SET
02301 012746 005760 000274  TST     $RPER2(R0)   ;ANY BITS SET IN ER2
02302 012752 001003  BNE     1S          ;BR IF ANY SET
02303 012754 005760 000276  TST     $RPER3(R0)   ;ANY BITS SET IN ER3
02304 012760 001416  BEQ     2S          ;BR IF NONE SET
02305 012762 004737 020130 1S:  JSR      PC,LINE1   ;PRINT LINE 1 OF ERROR MESSAGE
02306 012766 104414 046775  DISPLY  .EM44          ;ERROR BITS SET, BUT 'SC' OR 'TRE' NOT SET
02307 012772 004737 020174  JSR      PC,LINE2   ;PRINT LINE 2 OF ERROR MESSAGE
02308 012776 004737 020602  JSR      PC,LINE3   ;PRINT LINE 3 OF ERROR MESSAGE
02309 013002 004737 021256  JSR      PC,LINE4   ;PRINT LINE 4 OF ERROR MESSAGE
02310 013006 004737 023354  JSR      PC,INCTOT  ;INCREMENT TOTAL ERROR COUNT
02311 013012 004737 021712  JSR      PC,LINE7   ;PRINT LINE 7 OF ERROR MESSAGE
02312 013016 000297 2S:  RTS      PC          ;RETURN

```

```

2313
2314 :CHECK BUS ADDRESS REGISTER & WORD COUNT REGISTER
2315
2316 013020 005760 000236 CKBUS: TST $SRPWC(RO) ;CHECK WORD COUNT
2317 013024 001010 BNE 1$ ;BR IF NOT ZERO
2318 013026 016046 000020 MOV $WRDL(RO),-(SP) ;WORD LENGTH
2319 013032 006316 ASL (SP) ;CHANGE INTO BYTE COUNT
2320 013034 066016 000006 ADD $BUF(RO),(SP) ;ADD THE STARTING LOCATION
2321 013040 022660 000240 CMP (SP)+,$RPBA(RO) ;BUFFER ADDRESS PROPER ?
2322 013044 001416 BEQ 2$ ;BR IF OK
2323 013046 004737 020130 1$: JSR PC,LINE1 ;PRINT LINE 1 OF ERROR MESSAGE
2324 013052 104414 046603 DISPLY EM41 ;BUS ADDRESS OR WORD COUNT INCORRECT
2325 013056 004737 020174 JSR PC,LINE2 ;PRINT LINE 2 OF ERROR MESSAGE
2326 013062 004737 020640 JSR PC,LINE3D ;PRINT LINE 3D OF ERROR MESSAGE
2327 013066 004737 021256 JSR PC,LINE4 ;PRINT LINE 4 OF ERROR MESSAGE
2328 013072 004737 023354 JSR PC,INCTOT ;INCREMENT TOTAL ERROR COUNT
2329 013076 004737 021712 JSR PC,LINE7 ;PRINT LINE 7 OF ERROR MESSAGE
2330 013102 000207 2$: RTS PC
2331
2332 :COMPARE THE BUFFER
2333
2334 013104 132760 000004 000024 CMPAR: BITB $BIT02,$CODE(RO) ;SEE IF READ ORDER
2335 013112 001001 BNE 1$ ;BR IF IT IS
2336 013114 000207 RTS PC ;RETURN
2337 013116 005037 001300 1$: CLR FRSTER ;CLEAR 'FIRST ERROR' INDICATOR
2338 013122 032777 000002 166010 CMPARD: BIT $SW01,$SWR ;IS SWITCH 1 SET?
2339 013130 001401 BEQ 1$ ;BR IF NOT
2340 013132 000207 RTS PC ;YES, DON'T COMPARE
2341 013134 005037 001306 1$: CLR ERCTR ;CLEAR THE ERROR COUNTER
2342 013140 016001 000006 MOV $BUF(RO),R1 ;BUFFER ADDRESS
2343 013144 016037 000020 001312 MOV $WRDL(RO),CMCNT ;WORD COUNT TO WORKING LOCATION
2344 013152 066037 000236 001312 ADD $RPWC(RO),CMCNT ;CALCULATE ACTUAL WORDS TRANSFERED
2345 013160 016037 000012 001314 MOV $CYL(RO),CMCYL ;CYLINDER ADDRESS WORKING LOCATION
2346 013166 052737 010000 001314 BIS $BIT12,CMCYL ;SET FORMAT BIT
2347 013174 016037 000010 001316 MOV $SSEC(RO),CMSEC ;SECTOR & TRACK ADDRESSES TO WORKING LOCNS
2348 013202 013737 001374 001310 MOV CMPLMT,LIMIT ;DISPLAY LIMIT
2349 013210 005237 001310 INC LIMIT ;CONVERT PARAMETER INTO LIMIT VALUE
2350 013214 012737 177777 001276 CMSTR: MOV #-1,ZROIND ;CLEAR THE 'ZERO'S' INDICATOR
2351 013222 005037 001302 CLR SAVER1 ;CLEAR THE R1 SAVE WORD
2352 013226 005037 001304 CLR SAVER5 ;CLEAR THE R5 SAVE WORD
2353 013232 023760 001312 000022 CMP CMCNT,$SSEC(RO) ;IS BUFFER SIZE GREATER THAN ONE SECTOR ?
2354 013240 101003 SHI 1$ ;BR IF IT IS
2355 013242 013702 001312 MOV CMCNT,R2 ;LESS THAN, USE REMAINING BUFFER
2356 013246 000402 BR 2$
2357 013250 016002 000022 1$: MOV $SSEC(RO),R2 ;COMPARE SECTOR
2358 013254 166037 000022 001312 2$: SUB $SSEC(RO),CMCNT ;DECREMENT WORD COUNT
2359 013262 126027 000024 000005 CMPB $CODE(RO),#5 ;READ HEADER & DATA?
2360 013270 001036 BNE CMDAT ;BR IF NOT
2361 013272 023721 001314 CMHED: CMP CMCYL,(R1)+ ;CHECK CYLINDER
2362 013276 001402 BEQ 1$ ;BR IF COMPARE OK
2363 013300 004737 013354 JSR PC,5$ ;REPORT ERROR
2364 013304 023721 001316 1$: CMP CMSEC,(R1)+ ;COMPARE SECTOR & TRACK
2365 013310 001402 BEQ 2$ ;BR IF EQ
2366 013312 004737 013354 JSR PC,5$ ;REPORT ERROR
    
```

2367	013316	005721		2\$:	TST	(R1)+		; 1ST KEY WORD ZERO?
2368	013320	001402			BEQ	3\$		; BR IF IT IS
2369	013322	004737	013354		JSR	PC, 5\$		; REPORT ERROR
2370	013326	005721		3\$:	TST	(R1)+		; CHECK 2ND KEY WORD
2371	013330	001402			BEQ	4\$		; BR IF ZERO
2372	013332	004737	013354		JSR	PC, 5\$		; REPORT THE ERROR
2373	013336	162702	000004	4\$:	SUB	#4, R2		; SUBTRACT HEADER LENGTH FROM SIZE
2374	013342	003530			BLE	CMPRX		; BR IF FINISHED
2375	013344	022702	000004		CMP	#4, R2		; SEE IF AT LEAST 4 MORE WORDS TO CHECK
2376	013350	101125			BHI	CMPRX		; BR IF NOT
2377	013352	000405			BR	CMDAT		; COMPARE THE DATA PORTION
2378	013354	005237	001306	5\$:	INC	ERCTR		; INCREMENT THE ERROR COUNT
2379	013360	004737	013632		JSR	PC, CMPRT		; REPORT THE COMPARISON ERROR
2380	013364	000207			RTS	PC		; CHECK THE REST OF THE HEADER
2381	013366	004737	014154	CMDAT:	JSR	PC, MATCH		; FIND THE PATTERN
2382	013372	000403			BR	2\$		; FOUND A PATTERN
2383	013374	004737	012476		JSR	PC, NOMTCH		; RETURN HERE IF NO MATCH WITH PATTERN MADE
2384	013400	000456			BR	8\$		; BYPASS COMPARE ROUTINE
2385	013402	011405		2\$:	MOV	(R4), R5		; ADDRESS OF PATTERN ADDRESS IN R4
2386	013404	012703	000020		MOV	#20, R3		; R3 IS PATTERN POS COUNTER
2387	013410	022125		3\$:	CMP	(R1)+, (R5)+		; COMPARE BUFFER WITH PATTERN
2388	013412	001016			BNE	5\$		; BR IF NOT EQUAL
2389	013414	005737	001306		TST	ERCTR		; ERRORS DETECTED ?
2390	013420	001406			BEQ	4\$		; BR IF NO ERRORS
2391	013422	032777	000010 165510		BIT	#SW3, 2SWR		; SWITCH 3 SET ?
2392	013430	001402			BEQ	4\$		; BR IF NOT SET
2393	013432	004737	013632		JSR	PC, CMPRT		; DISPLAY THE WORD
2394	013436	005302		4\$:	DEC	R2		; DECREMENT SIZE COUNT
2395	013440	001436			BEQ	8\$		; BR WHEN AT END
2396	013442	005303			DEC	R3		; DECREMENT PATT POS COUNT
2397	013444	001361			BNE	3\$		; BR IF NOT AT END OF PATT
2398	013446	000755			BR	2\$		; RESTART THE PATTERN
2399	013450	005761	177776	5\$:	TST	-2(R1)		; IS MISCOMPARED CHARACTER=0
2400	013454	001410			BEQ	6\$		; BR IF YES
2401	013456	012737	177777 001276		MOV	#-1, ZROIND		; SET NON-ZERO MISCOMPARED INDICATOR
2402	013464	005237	001306		INC	ERCTR		; INCREMENT THE ERROR COUNTER
2403	013470	004737	013632		JSR	PC, CMPRT		; REPORT ERROR
2404	013474	000760			BR	4\$		; CONTINUE COMPARE
2405	013476	105737	001300	6\$:	TSTB	FRSTER		; FIRST ERROR?
2406	013502	100407			BMI	7\$		; BR IF NOT
2407	013504	005037	001276		CLR	ZROIND		; SET THE ZERO INDICATOR
2408	013510	010137	001302		MOV	R1, SAVER1		; SAVE CURRENT R1
2409	013514	010537	001304		MOV	R5, SAVER5		; SAVE CURRENT R5
2410	013520	000746			BR	4\$		; CONTINUE COMPARE
2411	013522	005737	001276	7\$:	TST	ZROIND		; ANY MISCOMPARISONS NOT ZEROS ?
2412	013526	001743			BEQ	4\$		; BR IF NONE-ALL ERRORS=ZERO
2413	013530	004737	013632		JSR	PC, CMPRT		; REPORT ERROR
2414	013534	000740			BR	4\$		; CONTINUE COMPARING
2415	013536	005737	001312	8\$:	TST	CMCNT		; AT END OF BUFFER
2416	013542	003430			BLE	CMPRX		; BR IF AT END
2417	013544	126027	000024 000005		CMPB	\$CODE(R0), #5		; SEE IF READ HEADER & DATA
2418	013552	001220			BNE	CMSTR		; BR IF NOT
2419	013554	105237	001316		INCB	CMSEC		; INCREMENT SECTOR
2420	013560	123727	001316 000026		CMPB	CMSEC, #22.		; SECTOR GREATER THAN MAX ?

```

2421 013566 103512          BLO      CMSTR      ;BR IF NOT GREATER THAN MAX
2422 013570 105037 001316    CLRB     CMSEC     ;CLEAR SECTOR ADDRESS
2423 013574 105237 001317    INCB     CMTRK     ;INCREMENT TRACK
2424 013600 123727 00131  000023  CMPB     CMTRK,#19. ;TRACK GREATER THAN MAX ?
2425 013606 103502          BLO      CMSTR      ;BR IF NOT GREATER
2426 013610 105037 001317    CLRB     CMTRK     ;RESET TRACK ADDRESS
2427 013614 005237 001314    INC      CMCYL     ;INCREMENT CYLINDER ADDRESS
2428 013620 000137 013214    JMP      CMSTR      ;CONTINUE WITH COMPARE
2429 013624 004737 014106    JSR      PC,ENDCMP ;PRINT LAST LINE IF ERRORS
2430 013630 000207          RTS      PC
2431
2432          ;TYPE DATA COMPARE ERRORS
2433
2434 013632 005737 001302    CMPRT:  TST      SAVER1  ;PRINT SAVED VALUES ?
2435 013636 001010          BNE     2$        ;BR IF NOT
2436 013640 105737 001300    TSTB    FRSTER    ;FIRST ERROR?
2437 013644 100402          BMI     1$        ;BR IF NOT
2438 013646 004737 013726    JSR     PC,4$     ;PRINT INITIAL MESSAGE INFO
2439 013652 004737 014010    JSR     PC,8$     ;PRINT REMAINDER OF MESSAGE
2440 013656 000422          BR      3$        ;EXIT
2441
2442          2$:
2443          MOV     R1,-(SP) ;;PUSH R1 ON STACK
2444 013660 010146          MOV     R5,-(SP) ;;PUSH R5 ON STACK
2445 013662 010546          MOV     SAVER1,R1 ;DISPLAY SAVED R1
2446 013664 013701 001302    MOV     SAVER5,R5 ;DISPLAY SAVED R5
2447 013670 013705 001304    JSR     PC,4$     ;PRINT INITIAL MESSAGE INFO
2448 013674 004737 013726    JSR     PC,8$     ;PRINT SAVED VALUES
2449 013700 004737 014010    CLR     SAVER1    ;CLEAR SAVED REGISTER INDICATORS
2450 013704 005037 001302    CLR     SAVER5    ;CLEAR THE OTHER ONE
2451 013710 005037 001304    MOV     (SP)+,R5 ;;POP STACK INTO R5
2452 013714 012605          MOV     (SP)+,R1 ;;POP STACK INTO R1
2453 013716 012601          JSR     PC,8$     ;PRINT REMAINDER OF MESSAGE
2454 013720 004737 014010    RTS     PC        ;RETURN
2455 013724 000207          3$:
2456 013726 105737 001300    TSTB    FRSTER    ;FIRST ERROR ?
2457 013732 100425          BMI     7$        ;BR IF NOT
2458 013734 001013          BNE     5$        ;BR IF FIRST ERROR AND PROCESSING 'DCK' ERROR
2459 013736 004737 020130    JSR     PC,LINE1 ;PRINT LINE 1 OF ERROR MESSAGE
2460 013742 104414 046647    DISPLY  ,EM42     ;DATA COMPARE ERROR
2461 013746 004737 020174    JSR     PC,LINE2 ;PRINT LINE 2 OF ERROR MESSAGE
2462 013752 004737 020610    JSR     PC,LINE3A ;PRINT LINE 3A OF ERROR MESSAGE
2463 013756 004737 021256    JSR     PC,LINE4 ;PRINT LINE 4 OF ERROR MESSAGE
2464 013762 000404          BR      6$        ;GO TO TYPE HEADER
2465 013764 104414 051303    5$:
2466 013770 104414 001165    DISPLY  ,LIN9B    ;HEADER MESSAGE OF PROCESSING 'DCK' ERROR
2467 013774 104414 051332    6$:
2468 014000 012737 177777 001300    DISPLY  ,%CRLF    ;CR-LF
2469 014006 000207          MOV     #-1,FRSTER ;SET ERROR FLAG
2470 014010 000207          RTS     PC        ;RETURN
2471 014014 005737 001310    7$:
2472 014016 001403          TST     LIMIT     ;TYPEOUT LIMIT REACHED ?
2473 014022 001403          BEQ     9$        ;BR IF IT HAS
2474 014024 005337 001310    DEC     LIMIT     ;DECREMENT LIMIT COUNTER
2475 014026 001005          BNE     10$       ;BR IF NOT AT LIMIT
2476 014028 032777 000200 165106 9$:
2477 014032 001001          BIT     #SW07,%SWR ;PRINT ALL DATA COMPARE ERRORS ?
2478 014034 000207          BNE     10$       ;BR IF YES
2479          RTS     PC        ;RETURN

```

```

2475 014036 010146
2476 014040 162716 000002
2477 014044 004737 022172
2478 014050 104414 052073
2479 014054 016546 177776
2480 014060 004737 022172
2481 014064 104414 052073
2482 014070 016146 177776
2483 014074 004737 022172
2484 014100 104414 001165
2485 014104 000207
2486
2487
2488
2489 014106 105737 001301
2490 014112 001417
2491 014114 005737 001306
2492 014120 001410
2493 014122 104414 051430
2494 014126 013746 001306
2495 014132 004737 022224
2496 014136 104414 001165
2497 014142 004737 023354
2498 014146 004737 021712
2499 014152 000207
2500
2501
2502
2503
2504
2505
2506
2507
2508
2509 014154 010146
2510 014156 012704 000044
2511 014162 011601
2512 014164 162704 000002
2513 014170 016405 002742
2514 014174 001411
2515
2516 014176 012703 000034
2517 014202 022125
2518 014204 001366
2519 014206 005303
2520 014210 001374
2521 014212 062704 002742
2522 014216 000403
2523 014220 062766 000002 000002
2524 014226 012601
2525 014230 000207
2526
2527
2528
    
```

```

10$: MOV R1, -(SP) ; BUFFER ADDRESS
SUB #2, (SP) ; ADJUST ADDRESS
JSR PC, LINOCT ; TYPE IT
DISPLY .LINSF ; 2 SPACES
MOV -2(R5), -(SP) ; PUT GOOD DATA ON THE STACK
JSR PC, LINOCT ; TYPE IT
DISPLY .LINSF ; 2 SPACES
MOV -2(R1), -(SP) ; BAD DATA
JSR PC, LINOCT ; TYPE IT
DISPLY $CRLF ; CR-LF
RTS PC ; RETURN

; LAST LINE OF COMPARE ERROR REPORTING
ENDCMP: TSTB FRSTER+1 ; ANY COMPARE ERRORS FOUND ?
BEQ 2$ ; BR IF NOT
TST ERCTR ; SEE HOW MANY ERRORS
BEQ 1$ ; BR IF ONLY CAN'T MATCH PATTERN
DISPLY .LINSF ; 'NUMBER OF ERRORS='
MOV ERCTR, -(SP) ; NUMBER OF ERRORS
JSR PC, LINDEC ; TYPE IT
DISPLY $CRLF ; CR-LF
1$: JSR PC, INCTOT ; INCREMENT TOTAL ERROR COUNT
JSR PC, LINE7 ; PRINT LINE 7 OF ERROR MESSAGE
2$: RTS PC ; RETURN

; ROUTINE TO MATCH THE DATA WITH A PATTERN
; CALL:
; MOV #BUFFER, R1 ; BUFFER ADDRESS
; JSR PC, MATCH
; RETURN1 ; PATTERN ADDRESS IN R4
; RETURN2 ; COULDN'T MATCH PATTERN
MATCH: MOV R1, -(SP) ; SAVE R1 ON THE STACK
MOV #4, R4 ; PATTERN TABLE INDEX
1$: MOV (SP), R1 ; RELOAD R1
SUB #2, R4 ; DECREMENT INDEX
MOV STNDAT(R4), R5 ; ADDRESS OF PATTERN ADDRESS
BEQ 3$ ; BR IF ALL PATTERNS CHECKED AND NO MATCH
; FOUND
2$: MOV #4, R3 ; NUMBER OF LOCATIONS TO CHECK
CMP (R1)+, (R5)+ ; COMPARE THE BUFFER AGAINST THE PATTERN
BNE 1$ ; BR IF NOT EQUAL, TRY NEXT PATTERN
DEC R3 ; FINISHED CHECKING?
BNE 2$ ; BR IF NOT FINISHED
ADD #STNDAT, R4 ; MAKE PATTERN ADDRESS ABSOLUTE
BR 4$ ; EXIT
3$: ADD #2, 2(SP) ; INCREMENT RETURN ADDRESS
4$: MOV (SP)+, R1 ; RESTORE R1
RTS PC ; RETURN

; USE ECC TO CORRECT THE DATA ERROR
    
```

2529	014232	016037	000240	001322	ECC:	MOV	\$RPBA(RO),ECSEC	; ADDRESS OF LAST LOCN XFERED
2530	014240	016046	000236			MOV	\$RPWC(RO),-(SP)	; ACT WORDS XFERED (2'S COMP)
2531	014244	066016	000020			ADD	\$WRDL(RO),(SP)	; ADD WORDS REQUESTED
2532	014250	005046				CL	-(SP)	; CLEAR NEXT STACK LOCN
2533	014252	016046	000022			MC	\$SSEC(RO),-(SP)	; SECTOR SIZE
2534	014256	004737	027004			JS	PC, LINKDV	; DIVIDE WORDS XFERED BY SECTOR SIZE
2535	014262	005716				T	(SP)	; PARTIAL SECTOR XFERED ?
2536	014264	001413				E	1\$	; BR IF NOT
2537	014266	006316					(SP)	; CONVERT INTO NUMBER OF BYTES
2538	014270	161637	001322			SUB	(SP), ECSEC	; SUBTRACT SECTOR RESIDUE
2539	014274	126027	000024	000005		MPB	\$CODE(RO), #5	; WAS OP READ HEAD & DATA
2540	014302	001007				BNE	2\$	; BR IF NOT
2541	014304	062737	000010	001322		ADD	#8., ECSEC	; ADD HEADER SIZE (IN BYTES) BACK IN
2542	014312	000403				BR	2\$	; GO ADJUST THE STACK POINTER
2543	014314	162737	001000	001322	1\$:	SUB	#1000, ECSEC	; SUBTRACT SECTOR DATA FIELD SIZE (IN BYTES)
2544	014322	062706	000004		2\$:	ADD	#4, SP	; ADJUST THE STACK POINTER
2545	014326	016037	000300	001320		MOV	\$RPEC1(RO), ECBIT	; ECC POSITION COUNT
2546	014334	005337	001320			DEC	ECBIT	; ADJUST THE POSITION COUNT
2547	014340	013737	001320	001330		MOV	ECBIT, ECWRD	; LOAD THE WORD COUNT LOCATION
2548	014346	042737	177760	001320		BIC	#17, ECBIT	; SAVE THE BIT OFFSET COUNT
2549	014354	042737	000017	001330		BIC	#17, ECWRD	; CLEAR THE BIT OFFSET
2550	014362	006237	001330			ASR	ECWRD	; CHANGE TO BYTE COUNT
2551	014366	006237	001330			ASR	ECWRD	; CHANGE TO BYTE COUNT
2552	014372	006237	001330			ASR	ECWRD	; CHANGE TO BYTE COUNT
2553	014376	104414	051507			DISPLY	.LIN10A	; 'ERROR BURST BEGINS AT '
2554	014402	013746	001330			MOV	ECWRD, -(SP)	; PUT THE WORD COUNT ON THE STACK
2555	014406	006216				ASR	(SP)	; CONVERT TO WORD COUNT FOR MESSAGE
2556	014410	004737	027720			JSR	PC, \$SB2D	; CONVERT THE WORD COUNT
2557	014414	004737	027320			JSR	PC, \$SUPRS	; PRINT IT
2558	014420	104414	051543			DISPLY	.LIN10B	; ' IN DATA FIELD OF ERROR SECTOR'
2559	014424	063737	001322	001330		ADD	ECSEC, ECWRD	; FIND THE BEGINNING OF THE ERROR BURST
2560	014432	026037	000240	001330		CMP	\$RPBA(RO), ECWRD	; SEE IF BURST WAS IN DATA READ
2561	014440	101002				BHI	.+6	; BR IF IN DATA READ
2562	014442	000137	014760			JMP	ECC2	; NOT IN DATA READ - REPORT IT
2563	014446	016037	000302	001324		MOV	\$RPEC2(RO), ECMSK0	; GET THE ERROR MASK
2564	014454	005037	001326			CLR	ECMSK1	; CLEAR THE UPPER MASK WORD
2565	014460	005737	001320		3\$:	TST	ECBIT	; BIT OFFSET EQUAL ZERO
2566	014464	001407				BEQ	4\$	; BR IF IT IS
2567	014466	005337	001320			DEC	ECBIT	; DECREMENT THE BIT OFFSET COUNT
2568	014472	006337	001324			ASL	ECMSK0	; SHIFT THE ERROR MASK
2569	014476	006137	001326			ROL	ECMSK1	; SHIFT THE LOWER INTO THE UPPER
2570	014502	000766				BR	3\$	; CONTINUE THE SHIFT
2571	014504	017737	164620	001334	4\$:	MOV	ECWRD, ECBADD	; SAVE THE INCORRECT WORD
2572	014512	005037	001336			CLR	ECWRD1	; CLEAR SECOND INCORRECT WORD ADDRESS
2573	014516	013746	001324			MOV	ECMSK0, -(SP)	; PUT LOWER MASK ON STACK
2574	014522	047716	164602			BIC	ECWRD, (SP)	; CLEAR ERRONEOUS ONE BITS FROM MASK
2575	014526	043777	001324	164574		BIC	ECMSK0, ECWRD	; CLEAR ERRONEOUS ONE BITS FROM BAD WORD
2576	014534	052677	164570			BIS	(SP)+, ECWRD	; SET DROPPED BITS
2577	014540	005737	001326			TST	ECMSK1	; DOES BURST GO INTO NEXT WORD ?
2578	014544	001431				BEQ	ECC1	; BR IF BURST ONLY IN ONE WORD
2579	014546	013737	001330	001336		MOV	ECWRD, ECWRD1	; DUPLICATE ADDRESS
2580	014554	062737	000002	001336		ADD	#2, ECWRD1	; INCREMENT ERROR ADDRESS
2581	014562	026037	000240	001336		CMP	\$RPBA(RO), ECWRD1	; IS NEXT WORD IN THE BUFFER
2582	014570	101003				BHI	5\$	; BR IF IT IS





```

2583 014572 005037 001336 CLR ECWRD1 ;CLEAR 2ND WORD ADDRESS
2584 014576 000414 BR ECC1 ;PRINT WORD CORRECTED
2585 014600 017737 164532 001342 5$: MOV DECWRD1,ECBAD1 ;SAVE THE SECOND BAD WORD
2586 014606 013746 001326 MOV ECMSK1,-(SP) ;PUT THE UPPER MASK ON THE STACK
2587 014612 047716 164520 BIC DECWRD1,(SP) ;CLEAR ERRONEOUS ONE BITS FROM UPPER MASK
2588 014616 043777 001325 164512 BIC ECMSK1,DECWRD1 ;CLEAR ERRONEOUS ONE BITS FROM DATA WORD
2589 014624 052677 164506 BIS (SP)+,DECWRD1 ;SET DROPPED BITS
2590 014630 104414 051711 ECC1: DISPLY ,LIN10H ;HEADER
2591 014634 013746 001330 MOV ECWRD,-(SP) ;PUT ECWRD ON THE STACK
2592 014640 004737 022172 JSR PC,LIN0CT ;TYPE ECWRD
2593 014644 104414 052073 DISPLY ,LINSF ;SPACES
2594 014650 013746 001334 MOV ECBADD,-(SP) ;PUT ECBADD ON THE STACK
2595 014654 004737 022172 JSR PC,LIN0CT ;TYPE ECBADD
2596 014660 104414 052073 DISPLY ,LINSF ;SPACES
2597 014664 017746 164440 MOV DECWRD,-(SP) ;PUT DECWRD ON THE STACK
2598 014670 004737 022172 JSR PC,LIN0CT ;TYPE DECWRD
2599 014674 104414 052073 DISPLY ,LINSF ;SPACES
2600 014700 005737 001336 TST ECWRD1 ;PRINT THE NEXT WORD ?
2601 014704 001427 BEQ ECCX ;BR IF NOT
2602 014706 104414 001165 DISPLY ,$CRLF ;CR-LF
2603 014712 013746 001336 MOV ECWRD1,-(SP) ;PUT ECWRD1 ON THE STACK
2604 014716 004737 022172 JSR PC,LIN0CT ;TYPE ECWRD1
2605 014722 104414 052073 DISPLY ,LINSF ;SPACES
2606 014726 013746 001342 MOV ECBAD1,-(SP) ;PUT ECBAD1 ON THE STACK
2607 014732 004737 022172 JSR PC,LIN0CT ;TYPE ECBAD1
2608 014736 104414 052073 DISPLY ,LINSF ;SPACES
2609 014742 017746 164370 MOV DECWRD1,-(SP) ;PUT DECWRD1 ON THE STACK
2610 014746 004737 022172 JSR PC,LIN0CT ;TYPE DECWRD1
2611 014752 104414 052073 DISPLY ,LINSF ;SPACES
2612 014756 000402 BR ECCX ;EXIT
2613 014760 104414 051604 ECC2: DISPLY ,LIN10C ;ERROR BURST WAS NOT TRANSFERED TO MEMORY
2614 014764 104414 001165 ECCX: DISPLY ,$CRLF ;CR-LF
2615 014770 000207 RTS PC ;RETURN

;ROUTINE TO DISPLAY THE SECTOR WHICH GAVE THE HARD ERROR
2616
2617
2618
2619 014772 032777 000010 164140 PRTBAD: BIT $SW3,$SWR ;PRINT THE BAD SECTOR ?
2620 015000 001460 BEQ 6$ ;BR IF NOT
2621 015002 016001 000240 MOV $RPBA(R0),R1 ;PUT THE END ADDRESS INTO R1
2622 015006 016046 000020 MOV $WRDL(R0),-(SP) ;FIND THE BEGINNING OF THE SECTOR
2623 015012 066016 000236 ADD $RPWC(R0),(SP) ;SUBTRACT THE WORDS NOT TRANSFERED
2624 015016 005046 CLR -(SP) ;MAKE THE UPPER DIVIDEND 0
2625 015020 016046 000022 MOV $SSEC(R0),-(SP) ;DIVDE THE WORDS TRANSFERED BY THE SECTOR SIZE
2626 015024 004737 027004 JSR PC,LINKDV ;DIVIDE
2627 015030 005716 TST (SP) ;REMANDER = 0 ?
2628 015032 001403 BEQ 1$ ;BR IF IT IS - COMPLETE SECTOR TRANSFERED
2629 015034 006316 ASL (SP) ;CONVERT THE RESIDUAL SECTOR SIZE INTO BYTE COUNT
2630 015036 161601 SUB (SP),R1 ;SUBTRACT IT FROM THE END ADDRESS
2631 015040 000410 BR 2$ ;FINISH THE SIZING
2632 015042 162701 001000 1$: SUB #1000,R1 ;SUBTRACT FULL SECTOR SIZE FROM END ADDR
2633 015046 126027 000024 000005 CMPB $CODE(R0),#5 ;WAS OPERATION READ HEADER & DATA ?
2634 015054 001002 BNE 2$ ;BR IF NOT
2635 015056 162701 000010 SUB #10,R1 ;SUBTRACT HEADER SIZE FROM ADDR
2636 015062 062706 000004 2$: ADD #4,SP ;RESTORE THE STACK POINTER
    
```

```

2637 015066 104414 051776          DISPLY ,LIN11H          ;PRINT THE HEADER
2638 015072 012702 000007          3$: MOV #7,R2          ;R2 CONTAINS THE WORDS/LINE COUNT
2639 015076 010146                   MOV R1,-(SP)          ;PUT THE ADDRESS ON THE STACK
2640 015100 004737 022172          JSR PC,LIN0CT        ;TYPE THE ADDRESS
2641 015104 020160 000240          4$: CMP R1,$RPBA(RO) ;PRINTED ALL THE SECTOR ?
2642 015110 001412                   BEQ 5$               ;BR IF ALL PRINTED
2643 015112 104414 052073          DISPLY ,LINSF        ;SPACES
2644 015116 012146                   MOV (R1)+,-(SP)     ;PUT THE DATA ON THE STACK
2645 015120 004737 022172          JSR PC,LIN0CT        ;TYPE THE DATA
2646 015124 005302                   DEC R2              ;DECREMENT THE HORIZONTAL COUNT
2647 015126 001366                   BNE 4$              ;BR IF NOT AT THE END OF THE LINE
2648 015130 104414 001165          DISPLY $CRLF        ;CR-LF
2649 015134 000756                   BR 3$               ;RESTORE THE WORDS/LINE COUNT
2650 015136 104414 001165          5$: DISPLY $CRLF    ;PRINT WHAT REMAINS IN THE BUFFER
2651 015142 000207                   6$: RTS PC          ;RETURN

;ROUTINE TO DO AN RTC - DRIVE SELECTED IN RO
;CALL:
;      MOV #DPB,RO          ;DPB ADDRESS
;      JSR PC,RTNCTR
;      RETURN
2659 015144 111037 044646          RTNCTR: MOVB (RO),GENDPB ;MOVE THE DRIVE # TO THE GENERAL DPB
2660 015150 112737 000117          MOVB #RTC,GENDPB+$COMND ;COMMAND CODE
2661 015156 004037 034036          1$: JSR RO,RPO4        ;DRIVER ENTRANCE
2662 015162 044646                   GENDPB              ;DPB ADDRESS FOR ORDER
2663 015164 000774                   BR 1$               ;DRIVER DIDN'T ACCEPT ORDER
2664 015166 000207                   RTS PC              ;RETURN

;ROUTINE TO DO A RECALIBRATE - DRIVE SELECTED IN RO
;CALL:
;      MOV #DPB,RO          ;DPB ADDRESS
;      JSR PC,RECALT
;      RETURN
2672 015170 000000                   OR
2673 015170 000000                   ;
2674 015170 000000                   ;      MOV #DPB,RO          ;DPB ADDRESS
2675 015170 000000                   ;      MOVB #DRIVE,GENDPB ;DRIVE ADDRESS
2676 015170 000000                   ;      JSR PC,RECALTO
2677 015170 000000                   ;      RETURN
2679 015170 111037 044646          RECALT: MOVB (RO),GENDPB ;MOVE THE DRIVE # TO THE GENERAL DPB
2680 015174 112737 000107          RECALG: MOVB #RECAL,GENDPB+$COMND ;RECALIBRATE COMMAND
2681 015202 004037 034036          1$: JSR RO,RPO4        ;DRIVER ENTRANCE
2682 015206 044646                   GENDPB              ;DPB ADDRESS FOR ORDER
2683 015210 000774                   BR 1$               ;DRIVER DIDN'T ACCEPT THE ORDER
2684 015212 005737 044664          2$: TST GENDPB+$STATUS ;SEE IF FINISHED
2685 015216 001775                   BEQ 2$              ;BR IF NOT FINISHED
2686 015220 000207                   RTS PC              ;RETURN

;OFFSET THE DRIVE IN RO (OFFSET CODE PRELOADED INTO 'RPOF')
;CALL:
;      MOVB #OFFSET,GENDPB+$FMT ;OFFSET CCDE

```

```

2691      :      MOV      #DPB,RO      ;DPB ADDRESS
2692      :      JSR      PC,OFFST
2693      :      RETURN
2694
2695 015222 111037 044646      OFFST: MOVB      (RO),GENDPB      ;DRIVE # TO GENERAL DPB
2696 015226 112737 000115 044650 MOVB      #OFFSET,GENDPB+$COMND ;COMMAND
2697 015234 004037 034036 1$: JSR      RO,RPO4      ;DRIVER ENTRANCE
2698 015240 044646      GENDPB      ;DPB ADDRESS FOR ORDER
2699 015242 000774      BR      1$      ;DRIVER DIDN'T ACCEPT ORDER
2700 015244 000207      RTS      PC
2701
2702      ;UTILITY READ HEADER ROUTINE
2703      ;CALL:
2704      :      MOV      #DPB,RO      ;DPB ADDRESS
2705      :      MOV      #SECTOR,-(SP) ;SECTOR ADDRESS
2706      :      MOV      #TRACK,-(SP) ;TRACK ADDRESS
2707      :      JSR      PC,READDR
2708      :      RETURN
2709
2710 015246 116637 000002 044657 READHD: MOVB      2(SP),GENDPB+$TRK ;TRACK ADDRESS
2711 015254 116637 000004 044656 MOVB      4(SP),GENDPB+$SEC ;SECTOR ADDRESS
2712 015262 111037 044646      MOVB      (RO),GENDPB      ;DRIVE NUMBER
2713 015266 016037 000272 044660 MOV      $RPOC(RO),GENDPB+$CYL ;CYLINDER ADDRESS
2714 015274 112737 000173 044650 MOVB      #RDHD,GENDPB+$COMND ;COMMAND
2715 015302 004037 034036 1$: JSR      RO,RPO4      ;DRIVER ENTRANCE
2716 015306 044646      GENDPB      ;DPB ADDRESS FOR ORDER
2717 015310 000774      BR      1$      ;DRIVER DIDN'T ACCEPT COMMAND
2718 015312 005737 044664 2$: TST      GENDPB+$STATUS ;FINISHED?
2719 015316 001775      BEQ      2$      ;BR IF NOT
2720 015320 012666 000002      MOV      (SP)+,2(SP) ;ADJUST STACK FOR RETURN
2721 015324 005726      TST      (SP)+
2722 015326 000207      RTS      PC      ;RETURN
2723
2724      ;RETRY THE PRESENT OPERATION
2725      ;CALL:
2726      :      MOV      #COUNT,RETRY ;RETRY COUNT
2727      :      JSR      PC,$RETRY
2728      :      RETURN1 ;RETRY UNSUCCESSFUL
2729      :      RETURN2 ;SUCCESSFUL RETRY
2730      :      ;NOTE: IF A DIFFERENT ERROR OCCURS DURING
2731      :      ;RETRY, THE ROUTINE EXITS TO 'ERPRCI'
2732
2733 015330 004737 016320      $RETRY: JSR      PC,GODRIV ;RE-START ORDER
2734 015334 005760 000016 1$: TST      $STATUS(RO) ;ORDER FINISHED?
2735 015340 001775      BEQ      1$      ;BR IF NOT
2736 015342 100405      BMI      2$      ;BR IF ERROR
2737 015344 105237 001253      INCB     RETRY+1 ;INCREMENT RETRY COUNT
2738 015350 062716 000002      ADD      #2,(SP) ;INCREMENT RETURN
2739 015354 000425      BR      5$      ;GO TO EXIT
2740 015356 032760 000200 000016 2$: BIT      #BIT7,$STATUS(RO) ;DID ORDER TERMINATE NORMALLY ?
2741 015364 001430      BEQ      7$      ;BR IF NOT
2742 015366 005737 001250      TST      MASK ;IS ERROR MASK 0 ?
2743 015372 001004      BNE     3$      ;BR IF NOT
2744 015374 005760 000250      TST      $RPER1(RO) ;MAKE SURE THAT THE DRIVE ERROR REG IS CLEAR
    
```

```

2745 015400 001014 BNE 6$ ;BR IF NOT
2746 015402 000404 BR 4$ ;CONTINUE RETRY
2747 015404 033760 001250 000250 3$: BIT MASK,$RPER1(RO) ;SAME ERROR?
2748 015412 001407 BEQ 6$ ;BR IF NOT
2749 015414 105237 001253 4$: INCB RETRY+1 ;INCREMENT RETRY COUNT
2750 015420 123737 001252 001253 CMPB RETRY,RETRY+1 ;DONE ?
2751 015426 001340 BNE $RETRY ;BR IF NOT DONE
2752 015430 000207 5$: RTS PC ;RETURN
2753 015432 004737 022160 6$: JSR PC,LINE8 ;REPORT DIFFERENT ERROR
2754 015436 004737 021712 JSR PC,LINE7 ;PRINT LINE 7
2755 015442 005726 TST (SP)+ ;ADJUST STACK POINTER FOR DIRECT RETURN
2756 015444 000207 RTS PC ;RETURN
2757 015446 104414 051246 7$: DISPLY LIN8M ;'DIFFERENT ERROR DURING RETRY'
2758 015452 000137 006574 JMP ERPRC1 ;REPORT THE ERROR
2759
2760 ;ROUTINE TO UPDATE THE PERFORMANCE SUMMARY STATISTICS
2761 ;CALL:
2762 ; MOV #DPB,RO ;DPB ADDRESS
2763 ; JSR PC,STATIS
2764 ; RETURN
2765
2766 015456 032760 000300 000016 STATIS: BIT #BIT07!BIT06,$STATUS(RO) ;CHECK FOR DATA TERMINATION
2767 015464 001454 BEQ 3$ ;BR IF NOT DATA TERMINATION
2768 015466 016037 000240 015620 MOV $RPBA(RO),FACTOR ;STORE THE FINAL BUFFER ADDRESS
2769 015474 166037 000006 015620 SUB $BUF(RO),FACTOR ;SUBTRACT THE INITIAL ADDRESS
2770 015502 001434 BEQ 2$ ;BR IF NO DATA TRANSFER
2771 015504 006237 015620 ASR FACTOR ;CONVERT TO A WORD COUNT
2772 015510 063760 015620 000046 ADD FACTOR,$TRANS(RO) ;UPDATE WORD COUNT
2773 015516 005560 000050 ADC $TRANS+2(RO) ;ADD ANY CARRY
2774 015522 132760 000002 000024 BITB #BIT01,$CODE(RO) ;SEE IF ORDER READ OR WRITE
2775 015530 001021 BNE 2$ ;BRANCH IF ORDER WRITE
2776 015532 005737 001404 TST AUTOCK ;AUTO WRITE CHECKS BEING PERFORMED
2777 015536 001411 BEQ 1$ ;BR IF NOT
2778 015540 126027 000024 000001 CMPB $CODE(RO),#1 ;PRESENT OPERATION AN AUTOMATIC WRITE CHECK ?
2779 015546 101005 BHI 1$ ;BR IF NOT
2780 015550 066060 000020 000046 ADD $WRDL(RO),$TRANS(RO) ;ADD WORDS WRITTEN
2781 015556 005560 000050 ADC $TRANS+2(RO) ;ADD A CARRY
2782 015562 063760 015620 000052 1$: ADD FACTOR,$READ(RO) ;UPDATE THE READ WORD COUNT
2783 015570 005560 000054 ADC $READ+2(RO) ;ADD ANY CARRY
2784 015574 026060 000012 000270 2$: CMP $CYL(RO),$RPCA(RO) ;DID MID-TRANSFER SEEK OCCUR
2785 015602 001405 BEQ 3$ ;BR IF NOT
2786 015604 062760 000001 000042 ADD #1,$POSIT(RO) ;INCREMENT SEEK COUNT
2787 015612 005560 000044 ADC $POSIT+2(RO) ;ADD CARRY TO UPPER WORD
2788 015616 000207 3$: RTS PC
2789
2790 015620 000000 FACTOR: .WORD 0 ;USED FOR WORDS TRANSFERED
2791
2792 ;ROUTINE TO GET A BUFFER
2793 ;CALL:
2794 ; MOV #DPB,RO ;DPB ADDRESS
2795 ; CLR -(SP) ;CLEAR THE STACK
2796 ; JSR PC,GETBUF
2797 ; RETURN ;BUFFER ADDRESS WILL BE ON THE STACK
2798 ; ;STACK WILL BE ZERO IF NO BUFFER AVAILABLE
    
```

```

015622 010146 GETBUF: MOV R1,-(SP) :SAVE R1
015624 010246 MOV R2,-(SP) :SAVE R2
015626 010346 MOV R3,-(SP) :SAVE R3
015630 013702 001576 MOV BUFTBL,R2 :NUMBER OF SEPARATE BUFFERS
015634 001444 BEQ 65 :BR IF NONE AVAILABLE
015636 012701 001600 MOV #BUFTBL+2,R1 :FIRST ADDRESS OF ALLOCATION TABLE
015642 026061 000020 000002 15: CMP $WRDL(R0),2(R1) :SEE IF THERE IS A BLOCK LARGE ENOUGH
015650 101405 BLOS 35 :BRANCH IF IT IS
015652 005302 DEC R2 :DECREMENT TABLE COUNT
015654 001434 BEQ 65 :BR IF THROUGH TABLE
015656 062701 000004 ADD #4,R1 :INCREMENT TABLE POINTER
015662 000767 BR 15 :CONTINUE LOOKING
015664 011166 000010 35: MOV (R1),10(SP) :BUFFER ADDRESS TO STACK
015670 166061 000020 000002 SUB $WRDL(R0),2(R1) :ADJUST BUFFER SIZE
015676 001407 BEQ 45 :BR IF DIFFERENCE IS ZERO
015700 006360 000020 ASL $WRDL(R0) :CONVERT # WORDS TO BYTES
015704 066011 000020 ADD $WRDL(R0),(R1) :MAKE NEW STARTING ADDRESS
015710 006260 000020 ASR $WRDL(R0) :RETURN # BYTES TO WORDS
015714 000414 BR 65 :RETURN
015716 005337 001576 45: DEC BUFTBL :DECREMENT ENTRIES COUNT
015722 001411 BEQ 65 :BR IF ALLOCATION TABLE EMPTY
015724 005302 DEC R2 :DECREMENT TABLE COUNT
015726 001407 BEQ 65 :BR IF ITEM WERE LAST ENTRY
015730 010103 MOV R1,R3 :MOVE TABLE POINTER
015732 062703 000004 ADD #4,R3 :POINT TO NEXT ENTRY
015736 012321 55: MOV (R3)+,(R1)+ :MOVE ITEMS
015740 012321 MOV (R3)+,(R1)+
015742 005302 DEC R2 :DECREMENT TABLE COUNT
015744 001374 BNE 55 :CONTINUE IF NOT AT END OF TABLE
015746 012603 65: MOV (SP)+,R3 :RESTORE R3
015750 012602 MOV (SP)+,R2 :RESTORE R2
015752 012601 MOV (SP)+,R1 :RESTORE R1
015754 000207 RTS PC :RETURN

```

:ROUTINE TO PUT BUFFER BACK IN TABLE

```

:CALL:
: MOV #DPB,R0 :DPB ADDRESS
: JSR PC,RELBUF
: RETURN

```

```

015756 010146 RELBUF: MOV R1,-(SP) :SAVE R1
015760 012701 001600 MOV #BUFTBL+2,R1 :BEGINNING OF TABLE
015764 013702 001576 MOV BUFTBL,R2 :ENTRY COUNT
015770 001424 BEQ 25 :BR IF EMPTY TABLE
015772 016003 000020 MOV $WRDL(R0),R3 :TRIAL ADDRESS
015776 006303 ASL R3 :CHANGE TO BYTE COUNT
016000 066003 000006 ADD $BUF(R0),R3 :ADDRESS OF HIGHER ADJACENT BLOCK
016004 021103 15: CMP (R1),R3 :UPPER ADJACENT BLOCK
016006 001424 BEQ 45 :BR IF YES
016010 062701 000004 ADD #4,R1 :INCREMENT POINTER
016014 005302 DEC R2 :DECREMENT ENTRY COUNT
016016 001372 BNE 15 :CONTINUE SEARCHING

```

```

016011 000006
016020 000020 000002
016030 001576
016040 005220
016050 000444
016060 016021 000006 25:
016070 016021 000020
016080 005220 001576
016090 000443
016100 016011 000006 45:
016110 066061 000020 000002
016120 010246 55:
016130 013702 001576
016140 012705 001600
016150 016504 000002 65:
016160 006304
016170 061504
016180 020411
016190 001406
016200 062705 000004
016210 005302
016220 001366
016230 005726
016240 000415
016250 012602 85:
016260 066165 000002 000002
016270 005337 001576
016280 010106
016290 062705 000004
016300 012521 95:
016310 012521
016320 005302
016330 001374
016340 012601 105:
016350 000207

```

```

MOV $BUF(RO), (R1) ;PUT THE BUFFER BLOCK INTO THE TABLE
MOV $WORDL(RO), 2(R1) ;BLOCK SIZE
INC BUFTBL ;INCREMENT ENTRY COUNT
INC R2 ;INCREMENT R2 FOR USE LATER
BR 55 ;SEE IF A LOWER ADJACENT BLOCK IS IN THE TABLE
25: MOV $BUF(RO), (R1)+ ;BLOCK ADDRESS TO TABLE
MOV $WORDL(RO), (R1)+ ;SIZE TO TABLE
INC BUFTBL ;INCREMENT ENTRY COUNT
BR 105 ;EXIT
45: MOV $BUF(RO), (R1) ;RELEASED BUFFER IS LOWER ADJACENT
ADD $WORDL(RO), 2(R1) ;INCREMENTED SIZE
55: MOV R2, -(SP) ;SAVE R2
MOV BUFTBL, R2 ;ENTRY COUNT
MOV $BUFTBL+2, R5 ;BEGINNING OF TABLE
65: MOV 2(R5), R4 ;BLOCK SIZE (IN WORDS)
ASL R4 ;CHANGE TO BYTE COUNT
ADD (R5), R4 ;ADD BLOCK BEGINNING ADDRESS
CMP R4, (R1) ;R1 STILL POINTS TO INSERTED ENTRY
BEQ 85 ;LOWER ADJACENT IN TABLE
ADD #4, R5 ;INCREMENT POINTER
DEC R2 ;DECREMENT ENTRY COUNT
BNE 55 ;CONTINUE LOOKING
TST (SP)+ ;RESTORE STACK POINTER
BR 105 ;END
85: MOV (SP)+, R2 ;RESTORE R2
ADD 2(R1), 2(R5) ;INCREMENT LOWER BLOCK LENGTH
DEC BUFTBL ;DECREMENT ENTRY COUNT
MOV R1, R5 ;GET READY TO COMPRESS
ADD #4, R5 ;INCREMENT TO NEXT ENTRY
95: MOV (R5)+, (R1)+ ;COMPRESS TABLE
MOV (R5)+, (R1)+ ;MOVE SIZE FIELD DOWN
DEC R2 ;DECREMENT ENTRY COUNT
BNE 95 ;BR IF NOT FINISHED
105: MOV (SP)+, R1 ;RESTORE R1
RTS PC ;RETURN

```

```

;FILL THE ASSIGNED BUFFER (IF WRITE OR WRITE CHECK ORDER)
;CALL:
MOV #DPB, R0 ;DPB ADDRESS
MOV #BUFADR, $BUF(RO) ;LOAD BUFFER ADDRESS INTO THE DPB
MOVB #PATTERN, $PATTC(RO) ;PATTERN CODE
JSR PC, FILBUF
RETRN

```

```

016172 104412
016174 132760 000004 000024
016202 001044
016204 016001 000006 15:
016210 016002 000020
016214 132760 000001 000024
016222 001413
016224 016011 000012
016230 052721 C1C000

```

```

FILBUF: SAVREG ;SAVE THE REGISTERS
BITB #BIT02, $CODE(RO) ;SEE IF READ ORDER
BNE 45 ;BR IF READ
MOV $BUF(RO), R1 ;BUFFER ADDRESS
MOV $WORDL(RO), R2 ;POSITIVE WORD COUNT
BITB #BIT00, $CODE(RO) ;SEE IF WRITE HEADER TYPE ORDER
BEQ 25 ;BR IF NOT
MOV $CYL(RO), (R1) ;CYLINDER ADDRESS
BIS #BIT12, (R1)+ ;SET FMT22 BIT

```

```

2927 016234 016021 000010      MOV      $SEC(RO), (R1)+  ; MOVE SECTOR & TRACK
2928 016240 005021      CLR      (R1)+          ; CLEAR FIRST KEY WORD
2929 016242 005021      CLR      (R1)+          ; CLEAR THE SECOND
2930 016244 162702 000004      SUB      #4, R2         ; ADJUST THE WORD COUNT
2931 016250 003421      BLE     4$             ; BR IF END OF PATTERN
2932 016252 005004      CLR     R4             ; CLEAR R4
2933 016254 116004 000030      MOV     $PATT(RO), R4  ; RELATIVE PATTERN ADDRESS
2934 016260 016405 002742      MOV     STNDAT(R4), R5 ; PATTERN ADDRESS
2935 016264 012703 000020      MOV     #20, R3        ; PATTERN COUNT
2936 016270 012521      MOV     (R5)+, (R1)+   ; MOVE THE PATTERN INTO THE BUFFER
2937 016272 005302      DEC     R2            ; DECREMENT THE WORD COUNT
2938 016274 001407      BEQ     4$            ; BR IF DONE (WORD COUNT = 0)
2939 016276 005303      DEC     R3            ; DECREMENT THE PATTERN COUNT
2940 016300 001373      BNE     3$            ; BR IF MORE PATTERN
2941 016302 012703 000020      MOV     #20, R3        ; RESTORE PATTERN COUNT
2942 016306 016405 002742      MOV     STNDAT(R4), R5 ; RESTORE THE ADDRESS
2943 016312 000766      BR      3$            ; CONTINUE DISTRIBUTING THE PATTERN
2944 016314 104413      RESREG ; RESTORE THE REGISTERS
2945 016316 000207      RTS     PC            ; RETURN

; START THE ORDER FOR THE DPB IN RO
; CALL:
;
;      MOV     #DPB, RO      ; DPB ADDRESS
;      JSR     PC, GODRIV
;      RETURN
;
GODRIV: MOV     RO, -(SP)      ; SAVE RO
        MOV     RO, 2$      ; CURRENT DPB ADDRESS
1$:     JSR     RO, RPO4    ; CALL THE DRIVE HANDLER
2$:     .WORD 0             ; DRIVE BLOCK ADDRESS GOES HERE
        HALT              ; DRIVER REJECTED REQUEST
        MOV     (SP)+, RO   ; RESTORE RO
        ADD     #1, $OPERC(RO) ; INCREMENT THE OPERATION COUNT
2940 016346 005560 000040      ADC     $OPERC+2(RO)
2941 016352 026060 000034 000012      CMP     $PREVA+2(RO), $CYL(RO) ; DID ORDER REQUIRE A CYLINDER CHANGE
2942 016360 001405      BEQ     3$            ; BR IF NOT
2943 016362 062760 000001 000042      ADD     #1, $POSIT(RO)  ; INCREMENT SEEK COUNT
2944 016370 005560 000044      ADC     $POSIT+2(RO)    ; ADD ANY CARRY
3$:     RTS     PC

; GENERATE PARAMETERS FOR THE OPERATION
; CALL:
;
;      MOV     #DPB, RO      ; DPB ADDRESS
;      JSR     PC, SELPAR
;      RETURN
;
SELPAR: JSR     PC, $RAND    ; CYCLE THE RANDOM NUMBER GENERATOR
        B:T     #SWO, $SWR ; SEE IF SWO SET
2954 016410 001012      BNE     2$            ; BR IF SET - READ ONLY
2955 016412 012705 000010      MOV     #10, R5       ; READ/WRITE SELECTION DIVISOR
2956 016416 004737 026756      JSR     PC, GETREM    ; GET SELECTION VALUE
2957 016422 020537 001402      CMP     R5, RATIO     ; DETERMINE IF READ OR WRITE
2958 016426 103003      BHS    2$            ; BR IF READ
2959 016430 004737 017120      JSR     PC, RANWRT    ; SELECT A WRITE ORDER

```

```

2961 016434 000406
2962 016436 013705 032402
2963 016442 042705 177776
2964 016446 062705 000004
2965 016452 110560 000074
2966
2967
2968
2969
2970
2971 016456 016005 000116
2972 016462 026005 000120
2973 016466 001417
2974 016470 166005 000120
2975 016474 100002
2976 016476 062705 000026
2977 016502 005205
2978 016504 004737 026756
2979 016510 066005 000120
2980 016514 020527 000025
2981 016520 101402
2982 016522 162705 000026
2983 016526 110560 000076
2984
2985
2986 016532 016005 000112
2987 016536 026005 000114
2988 016542 001417
2989 016544 166005 000114
2990 016550 100002
2991 016552 062705 000023
2992 016556 005205
2993 016560 004737 026756
2994 016564 066005 000114
2995 016570 020527 000022
2996 016574 101402
2997 016576 162705 000023
2998 016602 110560 000077
2999
3000
3001 016606 012737 000633 001350
3002 016614 032760 000002 000262
3003 016622 001403
3004 016624 012737 001457 001350
3005 016632 016005 000106
3006 016636 026005 000110
3007 016642 001417
3008 016644 166005 000110
3009 016650 100002
3010 016652 063705 001350
3011 016656 005205
3012 016660 004737 026756
3013 016664 066005 000110
3014 016670 023705 001350

```

```

29: BR 3$ ;CONTINUE WITH THE SELECTION
MOV $LONUM,R5 ;SELECT READ OPERATION CODE
BIC #101,R5 ;MASK OUT ALL BUT BIT 0
ADD #4,R5 ;TABLE OFFSET FOR READ CODE
3$: MOVB R5,$NCODE(RO) ;ORDER SELECTION CODE TO CONTROL BLOCK

;GENERATE A RANDOM SECTOR ADDRESS BETWEEN VALUES 'MINSEC' & 'MAXSEC'

RANSEC: MOV MAXSEC(RO),R5 ;GET MAXIMUM SECTOR ADDRESS
CMP MINSEC(RO),R5 ;'MINSEC' AND 'MAXSEC' THE SAME ?
BEQ 2$ ;BR IF THEY ARE
SUB MINSEC(RO),R5 ;SUBTRACT MINIMUM SECTOR ADDRESS
BPL 1$ ;BR IF MAX LARGER THAN MIN
ADD #22.,R5 ;CORRECT THE NUMBER
1$: INC R5 ;INCREMENT DIFFERENCE TO USE AS DIVISOR
JSR PC,GETREM ;GET THE RANDOM AUGMENT
ADD MINSEC(RO),R5 ;NEW ADDRESS
CMP R5,#21. ;IS VALUE TOO LARGE ?
BLOS 2$ ;BR IF NOT
SUB #22.,R5 ;CORRECT VALUE
2$: MOVB R5,$NSEC(RO) ;STORE SECTOR ADDRESS IN DPB

;GENERATE A RANDOM TRACK ADDRESS BETWEEN VALUES 'MINTRK' & 'MAXTRK'

RANTRK: MOV MAXTRK(RO),R5 ;GET MAXIMUM TRACK ADDRESS
CMP MINTRK(RO),R5 ;'MINTRK' AND 'MAXTRK' THE SAME ?
BEQ 2$ ;BR IF THEY ARE
SUB MINTRK(RO),R5 ;SUBTRACT MINIMUM TRACK ADDRESS
BPL 1$ ;BR IF MAX LARGER THAN MIN
ADD #19.,R5 ;CORRECT THE NUMBER
1$: INC R5 ;INCREMENT DIFFERENCE TO USE AS DIVISOR
JSR PC,GETREM ;GET THE RANDOM AUGMENT
ADD MINTRK(RO),R5 ;NEW TRACK ADDRESS
CMP R5,#18. ;IS VALUE TOO LARGE ?
BLOS 2$ ;BR IF NOT
SUB #19.,R5 ;CORRECT VALUE
2$: MOVB R5,$NTRK(RO) ;STORE TRACK ADDRESS IN DPB

;GENERATE A RANDOM CYLINDER ADDRESS BETWEEN VALUES 'MINCYL' & 'MAXCYL'

RANCYL: MOV #411,CYLIMT ;ASSUME AN RPO4.5
BIT #BIT0!,$RPDT(RO) ;SEE IF RPO6
BEQ RANCYL ;BR IF NOT
MOV #915.,CYLIMT ;CHANGE CYLINDER LIMIT
MOV MAXCYL(RO),R5 ;GET MAXIMUM CYLINDER ADDRESS
CMP MINCYL(RO),R5 ;'MINCYL' AND 'MAXCYL' THE SAME ?
BEQ 2$ ;BR IF THEY ARE
SUB MINCYL(RO),R5 ;SUBTRACT MINIMUM CYLINDER ADDRESS
BPL 1$ ;BR IF MAX LARGER THAN MIN
ADD CYLIMT,R5 ;CORRECT THE NUMBER
1$: INC R5 ;INCREMENT DIFFERENCE TO USE AS DIVISOR
JSR PC,GETREM ;GET THE RANDOM AUGMENT
ADD MINCYL(RO),R5 ;NEW CYLINDER ADDRESS
CMP R5,CYLIMT ;IS VALUE TOO LARGE ?

```



```

3015 016674 101002          BHI      2$          ;BR IF NOT
3016 016676 163705 001350    SUB      CYLIMT,R5   ;CORRECT VALUE
3017 016702 010560 000100    MOV      R5,$N$CYL(RO) ;STORE CYLINDER ADDRESS IN DPB
3018 016706 122760 000003 000074 2$:  CMPB    #3,$N$CODE(RO) ;WRITE HEADER & DATA ?
3019 016714 001013          BNE      RANSIZ     ;BR IF NOT
3020 016716 012760 000404 000102  MOV      #260,$N$WRDL(RO) ;CHANGE WORD LENGTH .O 260 FOR WRTHC ORDER
3021 016724 023727 001364 000404  CMP      MAXDL,#260.   ;CAN A FULL SECTOR BE WRITTEN ?
3022 016732 103062          BHIS    RANPAT      ;BR IF IT CAN
3023 016734 013760 001364 000102  MOV      MAXDL,$N$WRDL(RO) ;CHANGE TRANSFER SIZE
3024 016742 000456          BR       RANPAT      ;CONTINUE WITH THE SELECTION
3025
3026 ;GENERATE A RANDOM BUFFER LENGTH BETWEEN 4 & THE VALUE IN 'MAXDL'
3027
3028 016744 013705 001364    RANSIZ: MOV      MAXDL,R5 ;GET BUFFER SIZE
3029 016750 005737 001400    TST     WCSEL       ;SELECT A RANDOM WORD COUNT ?
3030 016754 001010          BNE     1$         ;BR IF NOT
3031 016756 005205          INC     R5         ;INCREMENT THE MAXIMUM SIZE
3032 016760 004737 026756    JSR     PC,GETREM   ;DIVIDE BY MAX VALUE
3033 016764 005705          TST     R5         ;IS THE REMAINDER 0 ?
3034 016766 001003          BNE     1$         ;NOT 0, CONTINUE
3035 016770 004737 032302    JSR     PC,$RAND    ;CYCLE THE RANDOM NUMBER GENERATOR
3036 016774 000763          BR     RANSIZ     ;TRY AGAIN
3037 016776 010560 000102    1$:  MOV      R5,$N$WRDL(RO) ;WORD LENGTH TO CONTROL BLOCK
3038 017002 010546          MOV     R5,-(SP)   ;NEW WORD LENGTH ON STACK FOR CHECK
3039 017004 005046          CLR    -(SP)      ;MAKE UPPER DIVIDEND ZERO
3040 017006 012746 000400    MOV     #256,-(SP) ;SECTOR SIZE IS THE DIVISOR
3041 017012 132760 000001 000074  BITB    #1,$N$CODE(RO) ;SEE IF NEXT ORDER IS A HEADER ORDER
3042 017020 001402          BEQ    2$         ;BR IF NOT
3043 017022 062716 000004    ADD     #4,(SP)    ;ADD HEADER SIZE TO SECTOR SIZE
3044 017026 004737 027004    2$:  JSR     PC,LINKDV  ;DIVIDE BUFFER SIZE BY SECTOR SIZE
3045 017032 012616          MOV     (SP)+,(SP) ;MOV REMAINDER UP THE STACK
3046 017034 021627 000004    CMP     (SP),#4 ;SEE IF REMAINDER LESS THAN 4
3047 017040 103012          BHIS   4$         ;BR IF NOT
3048 017042 005737 001400    TST     WCSEL     ;SELECTING RANDOM TRANSFER SIZES ?
3049 017046 001403          BEQ    3$         ;BR IF YES
3050 017050 161660 000102    SUB     (SP),$N$WRDL(RO) ;ADJUST WORD LENGTH DOWNWARD
3051 017054 000404          BR     4$         ;CONTINUE
3052 017056 005726          3$:  TST     (SP)+     ;CORRECT THE STACK POINTER
3053 017060 004737 032302    JSR     PC,$RAND    ;CYCLE THE RANDOM NUMBER GENERATOR
3054 017064 000727          BR     RANSIZ     ;TRY AGAIN
3055 017066 005726          4$:  TST     (SP)+     ;CORRECT THE STACK POINTER
3056 017070 122760 000002 000074  CMPB    #2,$N$CODE(RO) ;SEE IF WRITE DATA
3057 017076 001004          BNE    RANXIT     ;BR IF NOT WRITE DATA
3058
3059 ;GET A RANDOM PATTERN NUMBER
3060
3061 017100 004737 017224    RANPAT: JSR     PC,GETPAT ;GET PATTERN CODE
3062 017104 110560 000075    MOVB    R5,$N$PATC(RO) ;MOVE PATTERN CODE TO CONTROL BLOCK
3063 017110 012760 177777 000104  RANXIT: MOV     #-1,$N$NEXT(RO) ;SET PARAMETERS SELECTED INDICATOR
3064 017116 000207          RTS     PC         ;RETURN
3065
3066 ;ROUTINE TO SELECT A WRITE (OR WRITE CHECK) OPERATION
3067
3068 017120 012705 000004    RANWRT: MOV     #4,R5 ;WRITE OPERATION SELECTION DIVISOR
    
```

```

3069 017124 004737 026756 JSR PC,GETREM ;GET SELECTION CODE
3070 017130 005737 001404 TST AUTOCK ;ARE WRITE CHECK ORDERS TO BE SELECTED
3071 ;RANDOMLY ?
3072 017134 001403 BEQ 1$ ;BR IF THEY ARE
3073 017136 152705 000002 BISB #2,R5 ;SET CODE TO EXCLUDE WRITE CHECK ORDERS
3074 017142 000420 BR 3$ ;COMPLETE SELECTION
3075 017144 020527 000001 1$: CMP R5,#1 ;WRITE CHECK SELECTED ?
3076 017150 101015 BHI 3$ ;BR IF NOT
3077 017152 132760 000002 000024 BITB #2,$CODE(RO) ;PREVIOUS WRITE OPERATION ?
3078 017160 001407 BEQ 2$ ;BR IF PREVIOUS WAS READ OR WRITE CHECK
3079 017162 116060 000024 000074 MOVB $CODE(RO),$NCODE(RO) ;MOVE CODE TO 'NEXT CODE'
3080 017170 142760 000002 000074 BICB #2,$NCODE(RO) ;CHANGE WRITE TO WRITE CHECK
3081 017176 000411 BR 5$ ;EXIT
3082 017200 052705 000002 2$: BIS #2,R5 ;CHANGE WRITE CHECK TO WRITE
3083 017204 005737 001376 3$: TST FORMAT ;WRITE HEADER ORDERS ALLOWED ?
3084 017210 001002 BNE 4$ ;BR IF THEY ARE
3085 017212 042705 000001 BIC #1,R5 ;ALTER POSSIBLE WRITE HEADER
3086 017216 110560 000074 4$: MOVB R5,$NCODE(RO) ;SETUP 'NEXT' CODE
3087 017222 000207 5$: RTS PC ;RETURN
3088
3089 ;ROUTINE TO SELECT A PATTERN
3090
3091 017224 012705 000020 GETPAT: MOV #20,R5 ;SELECT PATTERN
3092 017230 004737 026756 JSR PC,GETREM ;GET CODE
3093 017234 005705 TST R5 ;WAS PATTERN ZERO SELECTED ?
3094 017236 001003 BNE 1$ ;BR IF NOT ZERO
3095 017240 004737 032302 JSR PC,$RAND ;CYCLE THE RANDOM NUMBER GENERATOR
3096 017244 000767 BR GETPAT ;TRY AGAIN
3097 017246 006305 1$: ASL R5 ;MAKE CODE INTO TABLE INDEX
3098 017250 000207 RTS PC
3099
3100 ;ROUTINE TO GET THE PREVIOUSLY SELECTED PARAMETER VALUES
3101 ;CALL:
3102 ;
3103 ; MOV #DPB,RO ;DPB ADDRESS
3104 ; JSR PC,SELPAR ;SELECT THE PARAMETERS
3105 ; JSR PC,GETPAR
3106 ; RETURN
3107
3107 017252 010546 GETPAR: MOV R5, -(SP) ;SAVE R5
3108 017254 116060 000234 000027 MOVB $RPCS1(RO),$PREVA(RO) ;SAVE CURRENT PARAMETERS
3109 017262 032760 000006 000074 BIT #6,$NCODE(RO) ;SEE IF NEXT OPERATION IS READ OR WRITE
3110 017270 001007 BNE 1$ ;BR IF EITHER
3111 017272 016060 000012 000034 MOV $CYL(RO),$PREVA+2(RO) ;SAVE STARTING CYLINDER
3112 017300 016060 000010 000032 MOV $SEC(RO),$PREVA(RO) ;SAVE STARTING SECTOR AND TRACK
3113 017306 000411 BR 2$
3114 017310 004737 022244 1$: JSR PC,READR ;GET THE DECREMENTED SECTOR AND TRACK ADDRESSES
3115 017314 112660 000033 MOVB (SP)+,$PREVA+1(RO) ;TRACK ADDRESS
3116 017320 112660 000032 MOVB (SP)+,$PREVA(RO) ;SECTOR ADDRESS
3117 017324 016060 000272 000034 MOV $RPMC(RO),$PREVA+2(RO) ;CURRENT CYLINDER
3118 017332 032777 000100 161600 2$: BIT #SW06,$SWR ;SWITCH 6 SET ?
3119 017340 001043 BNE 3$ ;BR IF SET
3120 017342 116060 000074 000024 MOVB $NCODE(RO),$CODE(RO) ;LOGICAL CODE FOR OPERATION
3121 017350 116005 000074 MOVB $NCODE(RO),R5 ;LOAD R5 FOR USE AS TABLE INDEX
3122 017354 116560 001740 000002 MOVB COMTBL(R5),$COMND(RO) ;RPO4 COMMAND CODE

```

Handwritten notes and scribbles on the right margin, including a circled '2' and other illegible marks.

# H08

```

3123 017362 116060 000075 000030      MOVB  $NPATC(RO), $PATTC(RO) ; PATTERN CODE
3124 017370 016060 000076 000010      MOV   $NSEC(RO), $SEC(RO) ; TRACK AND SECTOR ADDRESSES
3125 017376 016060 000100 000012      MOV   $NICYL(RO), $CYL(RO) ; CYLINDER ADDRESS
3126 017404 016060 000102 000020      MOV   $NWRDL(RO), $WRDL(RO) ; BUFFER SIZE
3127 017412 016060 000102 000004      MOV   $NWRDL(RO), $WRDM(RO) ; WORD COUNT FOR THE RH11
3128 017420 015460 000004      NEG   $WRDM(RO) ; COMPLEMENT IT
3129 017424 012760 000400 000022      MOV   #256, $SSEC(RO) ; INITIAL VALUE OF SECTOR SIZE
3130 017432 032760 000001 000024      BIT   #1, $CODE(RO) ; HEADER OPERATION ?
3131 017440 001403      BEQ   3$, ; BR IF NOT
3132 017442 062760 000004 000022      ADD   #4, $SSEC(RO) ; ADD HEADER SIZE
3133 017450 005060 000104      CLR   $NEXT(RO) ; RESET 'PARAMETERS LOADED' INDICATOR
3134 017454 012605      MOV   (SP)+, R5 ; RESTORE R5
3135 017456 000207      RTS   PC ; RETURN

; ROUTINE TO COMPRESS A LIST
3137      ; CALL:
3138      ;
3139      ; MOV #ADDRS, R1 ; COMPRESS LIST STARTING AT THIS ADDRESS
3140      ; JSR PC, CMPRES
3141      ;
3142      ;
3143 017460 016111 000002      CMPRES: MOV 2(R1), (R1) ; COMPRESS THE TABLE IN R1
3144 017464 001403      BEQ 1$ ; BR WHEN ZERO FOUND
3145 017466 062701 000002      ADD #2, R1 ; INCREMENT R1
3146 017472 000772      BR CMPRES ; CONTINUE COMPRESSING TABLE
3147 017474 000207      1$: RTS PC ; RETURN

; ROUTINE TO SETUP PARAMETERS FOR A SEQUENTIAL READ OR WRITE OF THE DISK
3149      ; CALL:
3150      ;
3151      ; MOV #DPB, RO ; DPB ADDRESS
3152      ; MOV #-1, $PACK(RO) ; 'WRITE PACK' FLAG
3153      ; OR
3154      ; MOV #1, $PACK(RO) ; 'READ PACK' FLAG
3155      ; JSR PC, WRTPK
3156      ;
3157      ;
3158 017476 004737 032302      WRTPK JSR PC, $RAND ; CYCLE THE RANDOM NUMBER GENERATOR
3159 017502 005760 000040      TST $OPERC+2(RO) ; SEE IF FIRST OPERATION
3160 017506 001007      BNE WRTPK1 ; BR IF UPPER WORD OF COUNTER NOT ZERO
3161 017510 005760 000036      TST $OPERC(RO) ; LOWER WORD ZERO ?
3162 017514 001004      BNE WRTPK1 ; BR IF NOT 1ST OPERATION
3163 017516 105760 000026      TSTB $PACK(RO) ; SEE WHICH - 'R' OR 'W'
3164 017522 100503      BMI WRTPK3 ; BR IF 'W'
3165 017524 000470      BR WRTPK2 ; 'R' OPERATION
3166 017526 116060 000234 000027      WRTPK1: MOVB $RPCS1(RO), $PREV0(RO) ; SAVE CURRENT PARAMETERS
3167 017534 004737 022244      JSR PC, READR ; GET THE DECREMENTED SECTOR AND TRACK ADDRESSES
3168 017540 112660 000033      MOVB (SP)+, $PREVA+1(RO) ; TRACK ADDRESS
3169 017544 112660 000032      MOVB (SP)+, $PREVA(RO) ; SECTOR ADDRESS
3170 017550 016060 000272 000034      MOV $RPCC(RO), $PREVA+2(RO) ; CURRENT CYLINDER
3171 017556 016060 000242 000010      MOV $RPDA(RO), $SEC(RO) ; NEW SECTOR & TRACK ADDRESS
3172 017564 016060 000270 000012      MOV $RPCA(RO), $CYL(RO) ; NEW CYLINDER ADDRESS
3173 017572 026060 000012 000106      CMP $CYL(RO), MAXCYL(RO) ; SEE IF AT END
3174 017600 103427      BLO 2$ ; BR IF LESS THAN 'MAXCYL'
3175 017602 101004      BHI 1$ ; BR IF GREATER THAN 'MAXCYL'
3176 017604 126060 000011 000112      CMPB $TRK(RO), MAXTRK(RO) ; SEE IF AT MAX TRACK
    
```

```

3177 017612 101422          BLOS      2$          ;BR IF NOT GREATER
3178 017614 116060 000114 000011 1$:  MOVB    MINTRK(RO), $TRK(RO) ;RESET TRACK ADDRESS
3179 017622 116060 000120 000010  MOVB    MINSEC(RO), $SEC(RO) ;RESET SECTOR ADDRESS
3180 017630 016060 000110 000012  MOV     MINCYL(RO), $CYL(RO) ;RESET CYLINDER ADDRESS
3181 017636 004737 026556          JSR     PC, EOP2          ;DROP THE DRIVE (NORMAL TERMINATION)
3182 017642 032777 000020 161270  BIT     #SW04, $SWR      ;IS SWITCH 4 SET ?
3183 017650 001003          SNE     2$          ;BR IF SET
3184 017652 005726          TST    (SP)+          ;INCREMENT THE STACK POINTER
3185 017654 000137 005324          JMP     MAIN          ;RETURN DIRECTLY TO 'MAIN'
3186 017660 013760 001364 000020 2$:  MOV     MAXDL, $WRDL(RO) ;BUFFER SIZE IS MAXIMUM
3187 017666 013760 001364 000004  MOV     MAXDL, $WRDM(RO) ;WORD COUNT
3188 017674 005460 000004          NEG     $WRDM(RO)      ;CHANGE WORD COUNT TO 2'S COMPLEMENT
3189 017700 105760 000026          TSTB   $PACK(RO)      ;READ OR WRITE ?
3190 017704 100412          BMI    WRTPK3         ;BR IF WRITE
3191 017706 012760 000404 000022 WRTPK2: MOV    #260, $SSEC(RO) ;SECTOR SIZE FOR READ
3192 017714 112760 000005 000024  MOVB   #5, $CODE(RO) ;CODE FOR READ HEADER & DATA
3193 017722 112760 000173 000002  MOVB   #RDHD, $COMND(RO) ;DRIVE CODE FOR OPERATION
3194 017730 000415          BR     WRTPK4         ;SET UP FOR EXIT
3195 017732 012760 000400 000022 WRTPK3: MOV    #256, $SSEC(RO) ;SECTOR SIZE
3196 017740 112760 000002 000024  MOVB   #2, $CODE(RO) ;CODE FOR WRTDAT
3197 017746 112760 000161 000002  MOVB   #WRTDAT, $COMND(RO) ;OP CODE
3198 017754 004737 017224          JSR    PC, GETPAT     ;GET PATTERN CODE
3199 017760 110560 000030          MOVB   RS, $PATT(RO) ;PATTERN CODE
3200 017764 005060 000104 WRTPK4: CLR    $NEXT(RO) ;CLEAR 'PARAMETER SELECTED' INDICATOR
3201 017770 000207          RTS     PC           ;RETURN
3202
3203 ;ROUTINE TO DETERMINE OF ERROR IS AT A LOCATION ON THE PACK DEFINED
3204 ; IN THE BAD TRACK/SECTOR TABLE FOR THE DRIVE.
3205 ;CALL:
3206 ;
3207 ; JSR     PC, SPOTCK
3208 ; RETURN1 ;ERROR AT AN ADDRESS IN TABLE
3209 ; RETURN2 ;NO TABLE ENTRY FOR ERROR ADDRESS OR
3210 ; ;PARAMETER 'NOTPRT' IS 0
3211 SPOTCK:
3212 017772 010146          MOV     R1, -(SP) ;;PUSH R1 ON STACK
3213 017774 010246          MOV     R2, -(SP) ;;PUSH R2 ON STACK
3214 017776 012701 000124          MOV     #80SEC, R1 ;INCREMENT FOR BAD SECTOR TABLE
3215 020002 060001          ADD    RO, R1 ;ADD THE BLOCK'S STARTING ADDRESS
3216 020004 012702 000010          MOV     #8, R2 ;BAD SECTOR TABLE SIZE COUNT
3217 020010 021160 000272 1$:  CMP     (R1), $RPCC(RO) ;IS CYLINDER IN THE TABLE ?
3218 020014 00102?          SNE    4$          ;BR IF NOT
3219 020016 105761 000003          TSTB   3(R1) ;TRACK ENTRY ?
3220 020022 100426          BMI    5$          ;BR IF NOT
3221 020024 004737 022244          JSR    PC, READDR ;DECREMENT THE SECTOR/TRACK ADDRESS
3222 020030 122661 000003          CMPB   (SP)+, 3(R1) ;COMPARE THE TRACK ADDRESS
3223 020034 001011          BNE    3$          ;BR IF IT IS NOT EQUAL
3224 020036 105761 000002          TSTB   2(R1) ;IS A SECTOR ADDRESS IN THE TABLE ?
3225 020042 100002          BPL    2$          ;BR IF ONE IS
3226 020044 005726          TST    (SP)+ ;INCREMENT THE STACK POINTER
3227 020046 000414          BR     5$          ;DISPLAY THE MESSAGE
3228 020050 122661 000002 2$:  CMPB   (SP)+, 2(R1) ;COMPARE THE SECTOR ADDRESS
3229 020054 001002          BNE    4$          ;BR IF NOT EQUAL
3230 020056 000410          BP     5$          ;CHECK 'NOTPRT'
    
```

```

3231 020060 005726          3$:   TST      (SP)+      ; INCREMENT THE STACK POINTER
3232 020062 062701 000004  4$:   ADD      #4,R1      ; GO TO THE NEXT LOCATION IN THE TABLE
3233 020066 005711          TST      (R1)          ; PAST THE TABLE ENTRIES ?
3234 020070 100411          BMI      6$           ; BR IF PAST
3235 020072 005302          DEC      R2           ; DECREMENT THE MAXIMUM ENTRY COUNT
3236 020074 001345          BNE      1$           ; BR IF MORE TO CHECK
3237 020076 000406          BR       6$           ; END, EXIT
3238 020100 005737 001406  5$:   TST      NOTPRT      ; PRINT THE ERROR ANYWAY ?
3239 020104 001006          BNE      7$           ; BR IF NOT
3240 020106 012737 177777 001264  MOV     #-1,BADSEC     ; SET THE INDICATOR FOR THE IDENTIFICATION ! *ME
3241 020114 062766 000002 000004  6$:   ADD      #2,4(SP)    ; INCREMENT THE RETURN
3242 020122
3243 020122 012602          MOV     (SP)+,R2      ; POP STACK INTO R2
3244 020124 012601          MOV     (SP)+,R1      ; POP STACK INTO R1
3245 020126 000207          RTS      PC           ; RETURN

```

;\*\*\*\*\*

.SBTTL ERROR MESSAGE GENERATION ROUTINES

;\*\*\*\*\*

;PRINT LINE 1 OF ERROR MESSAGE:

; 'HH:MM:SS'

```

3256 020130 032777 002000 161002 LINE1: BIT      #SW10,JSWR    ; SWITCH 10 SET ?
3257 020136 001402          BEQ      1$           ; BR IF NOT
3258 020140 104401 001160          TYPE     $BELL        ; RING THE BELL
3259 020144 032777 020000 160766  1$:   BIT      #SW13,JSWR    ; INHIBIT TYPEOUT ?
3260 020152 001403          BEQ      2$           ; BR IF NOT
3261 020154 104414 001165          DISPLY   $CRLF        ; CR-LF
3262 020160 000404          BR       3$           ; EXIT
3263 020162 004737 023400  2$:   JSR      PC,$TIME     ; TYPE THE TIME
3264 020166 104414 052074          DISPLY   LINSPO       ; SPACES
3265 020172 000207          RTS      PC           ; RETURN & TYPE DESCRIPTION

```

;PRINT LINE 2 OF ERROR MESSAGE

; 'PRESENT ORDER = XXXX PREVIOUS ORDER = XXXX'

; '\* ERROR AT BAD TRACK/SECTOR'

; 'DRV RPCS1 RPCS2 RPDS1 RPER1 RPER2 RPER3 RPEC1 RPEC2'

; 'RPWC RPBA RPDA RPAS RPLA RPOB RPMR RPOD'

; 'RPSN RPOF RPCA RPCC STATUS'

; 'BUS ADDRESS OR WORD COUNT NOT CONSISTENT'

; 'RPBA = XXXXXX RPWC = XXXXXX'

; 'BUFFER ADR = XXXXXX SIZE = XXXX ACTUAL NMBR WRDS XFRD = XXX'

LINE2:

```

3277 020174
3278 020174 010346          MOV     R3,-(SP)      ; PUSH R3 ON STACK
3279 020176 010446          MOV     R4,-(SP)      ; PUSH R4 ON STACK
3280 020200 010546          MOV     R5,-(SP)      ; PUSH R5 ON STACK
3281 020202 104414 001165          DISPLY   $CRLF        ; CR-LF
3282 020206 005037 020334          CLR     4$           ; CLEAR MESSAGE ADDRESS STORAGE
3283 020212 005004          CLR     R4           ; WORKING REGISTER
3284 020214 012737 050160 020334  MOV     #LIN2C,4$     ; ADDRESS OF 'PRESENT ORDER = ' MSG

```

3285	020222	116004	000234		MOV B	\$RPCS1(RO),R4	;GET THE OPCODE	
3286	020226	042704	177701		BIC	#C76,R4	;SAVE ONLY SIGNIFICANT BITS	
3287	020232	004737	020270		JSR	PC,1\$	;TYPE THE FIRST MNEMONIC	
3288	020236	005737	020340		TST	5\$	;SEE IF MNEMONIC ENTRY FOUND	
3289	020242	001440			BEQ	LINE2A	;BR IF NOT	
3290	020244	012737	050201	020334	MOV	#LIN2P,4\$	;ADDRESS OF 'PREVIOUS ORDER = ' MSG	
3291	020252	116004	000027		MOV B	\$PREV0(RO),R4	;PREVIOUS OPERATION CODE	
3292	020256	042704	177701		BIC	#C76,R4	;SAVE ONLY SIGNIFICANT BITS	
3293	020262	004737	020270		JSR	PC,1\$	;TYPE THE PREVIOUS MNEMONIC	
3294	020266	000426			BR	LINE2A	;CONTINUE	
3295	020270	005005		1\$:	CLR	R5	;CLEAR THE TABLE INDEX	
3296	020272	126504	001746	2\$:	CMP B	OPTBL(R5),R4	;LOOK FOR THE OPCODE	
3297	020276	001405			BEQ	3\$	;BR WHEN OPCODE COUNT EQUALS OPCODE	
3298	020300	005765	001746		TST B	OPTBL(R5)	;LOOK FOR END OF TABLE	
3299	020304	100402			BMI	3\$	;BR IF END	
3300	020306	005205			INC	R5	;INCREMENT THE POINTER	
3301	020310	000770			BR	2\$	;CONTINUE - NOT END OF TABLE	
3302	020312	006305		3\$:	ASL	R5	;SHIFT INDEX	
3303	020314	006305			ASL	R5	;SHIFT THE INDEX	
3304	020316	006305			ASL	R5	;SHIFT THE INDEX	
3305	020320	012737	001770	020340	MOV	#MNTBL,5\$	;ADDRESS OF ASCII TEXT TABLE	
3306	020326	060537	020340		ADD	R5,5\$	;ADD THE INDEX	
3307	020332	104414			DISPLY		;TYPE IT	
3308	020334	000000		4\$:	.WORD	0	;ADDRESS OF 'PRESENT' OR 'PREVIOUS' MESSAGE	
3309	020336	104414			DISPLY		;TYPE THE OPERATION MNEMONIC	
3310	020340	000000		5\$:	.WORD	C	;ADDRESS OF MESSAGE	
3311	020342	000207			RTS	PC	;RETURN TO MAIN ROUTINE	
3312	020344	005737	001264	LINE2A:	TST	BADSEC	;PRINT THE BAD SECTOR LINE ?	
3313	020350	001404			BEQ	LINE2B	;BR IF NOT	
3314	020352	104414	001165		DISPLY	, \$CRLF	;CR-LF	
3315	020356	104414	050225		DISPLY	, LIN2S	;ERROR ADDRESS DEFINED AS BAD AREA	
3316	020362	104414	001165	LINE2B:	DISPLY	, \$CRLF	;CR-LF	
3317	020366	104414	047554		DISPLY	, DH14	;STANDARD RPO4/5/6 REGISTER HEADER	
3318	020372	104414	052074		DISPLY	, LINSPO	;TYPE A SPACE	
3319	020376	013746	001246		MOV	UNIT, -(SP)	;PUT THE DRIVE NUMBER ON THE STACK	
3320	020402	004737	022224		JSR	PC, LINDEC	;TYPE DRIVE NUMBER	
3321	020406	104414	052073		DISPLY	, LINSP	;SPACES	
3322	020412	012705	050100		MOV	#DT14,R5	;REGISTER INDEXES	
3323	020416	004737	020546		JSR	PC, 3\$	;PRINT THE REGISTERS	
3324	020422	032777	000040	160510	BIT	#SW05, 0SWR	;PRINT THE OPTIONAL REGISTERS ?	
3325	020430	001014			BNE	1\$	;BR IF NOT	
3326	020432	104414	047660		DISPLY	, DH15		
3327	020436	012705	050122		MOV	#DT15,R5	;SECOND DATA LINE	
3328	020442	004737	020546		JSR	PC, 3\$	;PRINT THEM	
3329	020446	104414	047757		DISPLY	, DH14		
3330	020452	012705	050144		MOV	#DT16,R5	;THIRD DATA LINE	
3331	020456	004737	020546		JSR	PC, 3\$	;PRINT THE REGISTERS	
3332	020462	032760	000100	000016	1\$:	BIT	#BIT6, \$STATUS(RO)	;DATA ERROR ?
3333	020470	001422			BEQ	2\$	;BR IF NO	
3334	020472	016046	000020		MOV	\$WRDL(RO), -(SP)	;TRANSFER SIZE	
3335	020476	066016	000236		ADD	\$RPMC(RO), (SP)	;ADD REMAINING WORD COUNT	
3336	020502	006316			ASL	(SP)	;CONVERT TO AN BYTE INCREMENT	
3337	020504	066016	000006		ADD	\$BUF(RO), (SP)	;BUFFER STARTING ADDRESS	
3338	020510	022660	000240		CMP	(SP)+, \$RPBA(RO)	;CORRECT BUFFER ADDRESS ?	

```

3339 020514 001410          BEQ      2$          ;BR IF YES
3340 020516 104414 047147  DISPLY  ,EM46      ;'BUS ADDRESS AND WORD COUNT ARE NOT CONSISTENT'
3341 020522 104414 001165  DISPLY  , $CRLF    ;CR-LF
3342 020526 004737 020640  JSR     PC,LIN3D   ;PRINT LINE 3D OF ERROR MESSAGE
3343 020532 004737 021256  JSR     PC,LIN4   ;PRINT LINE 4 OF ERROR MESSAGE
3344 020536          2$:
3345 020536 012605          MOV     (SP)+,R5   ;POP STACK INTO R5
3346 020540 012604          MOV     (SP)+,R4   ;POP STACK INTO R4
3347 020542 012603          MOV     (SP)+,R3   ;POP STACK INTO R3
3348 020544 000207          RTS     PC         ;RETURN TO ERROR PROCESSING ROUTINE
3349 020546 012546          3$: MOV     (R5)+,-(SP) ;PUT THE REGISTER INDEX ON THE STACK
3350 020550 060016          ADD     RD,(SP)    ;ADD DRIVE'S TABLE ADDRESS
3351 020552 017646 000000  MOV     2(SP),-(SP) ;VALUE
3352 020556 004737 022172  JSR     PC,LIN0CT ;TYPE IT
3353 020562 005726          TST     (SP)+     ;CORRECT THE STACK POINTER
3354 020564 104414 052073  DISPLY  ,LINSP    ;PRINT 2 SPACES
3355 020570 005715          TST     (R5)     ;AT END OF LINE ?
3356 020572 001365          BNE     3$       ;BR IF NOT
3357 020574 104414 001165  4$: DISPLY  , $CRLF ;CR-LF
3358 020600 000207          RTS     PC         ;RETURN
3359
3360          ;PRINT LINE 3 OF ERROR MESSAGE
3361          ;'ERROR AT CCC TT SS PREVIOUS ADR = CCC TT SS'
3362
3363 020602 104414 050261  LINE3: DISPLY  ,LINM3 ;LINE 3 ENTRANCE
3364 020606 000517          BR      LIN3.1    ;FINISH PRINTOUT
3365
3366          ;PRINT LINE 3A OF ERROR MESSAGE
3367          ;'START CYL = CCC END CYL = CCC'
3368
3369 020610 104414 050277  LINE3A: DISPLY ,LINN3 ;LINE 3A ENTRANCE
3370 020614 000514          BR      LIN3.1    ;FINISH ERROR LINE
3371
3372          ;PRINT LINE 3B OF ERROR MESSAGE
3373          ;'START CYL = CCC END CYL = CCC ACTUAL CYL = CCC'
3374
3375 020616 004737 021160  LINE3B: JSR     PC,LIN3.3 ;LINE 3B ENTRANCE
3376 020622 104414 001165  DISPLY  , $CRLF
3377 020626 000207          RTS     PC
3378
3379          ;PRINT LINE 3C OF ERROR MESSAGE
3380          ;'START CYL = CCC END CYL = CCC ACTUAL CYL = CCC TRK = TT'
3381
3382 020630 004737 021160  LINE3C: JSR     PC,LIN3.3 ;LINE 3C ENTRANCE
3383 020634 000137 021212  JMP     LIN3.4    ;FINISH MESSAGE
3384
3385          ;PRINT LINE 3D OF ERROR MESSAGE
3386          ;'RPBA = XXXXXX RPWC = XXXXXX'
3387
3388 020640 032777 000040 160272 LINE3D: BIT     #SW05,2SWR ;SWITCH 5 SET ?
3389 020646 001416          BEQ     1$        ;BR IF IT IS
3390 020650 104414 050450  DISPLY  ,LINB3    ;'RPBA = '
3391 020654 016046 000240  MOV     $RPBA(R0),-(SP) ;BUFFER ADDR REG CONTENTS
3392 020660 004737 022172  JSR     PC,LIN0CT ;CONVERT TO OCTAL AND TYPE IT
    
```

# M08

```

3393 020664 104414 050460
3394 020670 016046 000236
3395 020674 004737 022172
3396 020700 104414 001165
3397 020704 000207
3398
3399
3400
3401
3402 020706 104414 050344
3403 020712 016046 000012
3404 020716 004737 022224
3405 020722 104414 052073
3406 020726 104414 050472
3407 020732 005046
3408 020734 116016 000011
3409 020740 004737 022224
3410 020744 104414 052073
3411 020750 104414 050507
3412 020754 005046
3413 020756 116016 000010
3414 020762 004737 022224
3415 020766 104414 001165
3416 020772 000207
3417
3418
3419
3420
3421 020774 032777 000040 160136
3422 021002 001420
3423 021004 104414 050440
3424 021010 016046 000242
3425 021014 004737 022172
3426 021020 104414 052073
3427 021024 104414 050427
3428 021030 016046 000270
3429 021034 004737 022172
3430 021040 104414 001165
3431 021044 000207
3432
3433
3434
3435 021046 016046 000272
3436 021052 004737 022224
3437 021056 104414 050274
3438 021062 004737 022244
3439 021066 004737 022224
3440 021072 104414 050320
3441 021076 004737 022224
3442 021102 104414 050323
3443 021106 016046 000034
3444 021112 004737 022224
3445 021116 104414 050274
3446 021122 005046
  
```

```

DISPLY LINW3 ;' RPWC = '
MOV $RPWC(RO),-(SP) ;WORD COUNT REGISTER CONTENTS
JSR PC,LINOC ;CONVERT TO OCTAL AND TYPE IT
DISPLY $CRLF
1$: RTS PC

;PRINT LINE 3E OF ERROR MESSAGE
;'START CYL = CCC START TRK = TT START SEC = SS'
LINE3E: DISPLY LINS3 ;'START CYL = '
MOV $CYL(RO),-(SP) ;MOVE CYL TO STACK
JSR PC,LINDEC ;TYPE IT IN DECIMAL
DISPLY ,LINS ;SPACES
DISPLY ,LINST3 ;'START TRK = '
CLR -(SP) ;CLEAR STACK
MOVB $TRK(RO),(SP) ;TRACK TO STACK
JSR PC,LINDEC ;TYPE IT IN DECIMAL
DISPLY ,LINS ;SPACES
DISPLY ,LINS3 ;'START SEC = '
CLR -(SP) ;CLEAR STACK
MOVB $SEC(RO),(SP) ;SECTOR ADDR TO STACK
JSR PC,LINDEC ;TYPE IT IN DECIMAL
DISPLY $CRLF
RTS PC

;PRINT LINE 3F OF ERROR MESSAGE
;'RPDA = XXXXXX RPCA = XXXXXX'
LINE3F: BIT #SWS,SWR ;SWITCH 5 SET ?
BEQ 1$ ;BR IF NOT
DISPLY ,LINDA3 ;'RPDA = '
MOV $RPDA(RO),-(SP) ;PUT SECTOR/TRACK ADDRESS ON THE STACK
JSR PC,LINOC ;TYPE IT
DISPLY ,LINS ;SPACES
DISPLY ,LINDA3 ;'RPCA = '
MOV $RPCA(RO),-(SP) ;PUT DESIRED CYLINDER ADDRESS ON THE STACK
JSR PC,LINOC ;TYPE IT
DISPLY $CRLF
1$: RTS PC

;'CCC TT SS PREV ADR = CCC TT SS'
LIN3.1: MOV $RPCC(RO),-(SP) ;PUT CYLINDER ADDR ON STACK
JSR PC,LINDEC ;TYPE IT IN DECIMAL
DISPLY T ;PRINT ' T '
JSR PC,READDR ;DECREMENT TRACK AND SECTOR ADDRESSES
JSR PC,LINDEC ;TYPE TRACK IN DECIMAL
DISPLY S ;PRINT ' S '
JSR PC,LINDEC ;TYPE SECTOR ADDRESS
DISPLY ,LINS3 ;PRINT 'PREV ADDR'
MOV $PREVA+2(RO),-(SP) ;PREVIOUS CYLINDER
JSR PC,LINDEC ;TYPE IT IN DECIMAL
DISPLY T ;PRINT ' T '
CLR -(SP) ;MAKE ROOM ON THE STACK
  
```



```

3447 021124 116016 000033      MOVB   $PREVA+1(RO), (SP)  ;PREVIOUS TRACK ADDRESS
3448 021130 004737 022224      JSR    PC,LINDEC          ;TYPE IT IN DECIMAL
3449 021134 104414 050320      DISPLY .S                  ;PRINT 'S'
3450 021140 005046                CLR    -(SP)              ;MAKE ROOM ON THE STACK
3451 021142 116016 000032      MOVB   $PREVA(RO), (SP)  ;PREVIOUS SECTOR ADDRESS
3452 021146 004737 022224      JSR    PC,LINDEC          ;TYPE IT IN DECIMAL
3453 021152 104414 001165      DISPLY $CRLF
3454 021156 000207      RTS    PC
3455
3456                                ;'START CYL = CCC  END CYL = CCC'
3457
3458 021160 104414 050344      LIN3.3: DISPLY .LINS3      ;LINE '3B & 3C' ENTRANCE
3459 021164 016046 000034      MOV    $PREVA+2(RO), -(SP) ;PREVIOUS CYLINDER
3460 021170 004737 022224      JSR    PC,LINDEC          ;TYPE IT IN DECIMAL
3461 021174 104414 050361      DISPLY .LINS3            ;PRINT 'END CYL'
3462 021200 016046 000272      MOV    $RPCC(RO), -(SP)  ;PRESENT CYLINDER
3463 021204 004737 022224      JSR    PC,LINDEC          ;TYPE IT IN DECIMAL
3464 021210 000207      RTS    PC
3465
3466                                ;'ACTUAL CYL = CCC  TRK = TT'
3467
3468 021212 104414 050376      LIN3.4: DISPLY .LINA3     ;PRINT 'ACTUAL'
3469 021216 013746 054374      MOV    CYLDER, -(SP)     ;ACTUAL CYLINDER
3470 021222 042716 010000      BIC    #BIT12, (SP)     ;CLEAR THE FORMAT BIT
3471 021226 004737 022224      JSR    PC,LINDEC          ;TYPE IT IN DECIMAL
3472 021232 104414 050416      DISPLY .LINT3           ;PRINT TRACK
3473 021236 005046                CLR    -(SP)              ;CLEAR STACK WORD
3474 021240 116016 000243      MOVB   $RPDA+1(RO), (SP) ;PUT TRACK ON STACK
3475 021244 004737 022224      JSR    PC,LINDEC          ;TYPE IT IN DECIMAL
3476 021250 104414 001165      DISPLY $CRLF
3477 021254 000207      RTS    PC
3478
3479                                ;PRINT LINE 4 OF ERROR MESSAGE
3480                                ;'BUFFER ADR = XXXXXX  SIZE = XXXX  ACTUAL NMBR WRDS XFRD = XXX'
3481
3482 021256 032760 000100 000016 LINE4: BIT   #BIT06, $STATUS(RO) ;DATA ERROR ?
3483 021264 001427                BEQ    1$                 ;BR IF NOT
3484 021266 104414 050524      DISPLY .LINM4            ;'PRINT BUFFER'
3485 021272 016046 000006      MOV    $BUF(RO), -(SP)  ;BUFFER ADDR ON STACK
3486 021276 004737 022172      JSR    PC,LINOC†        ;CONVERT TO OCTAL & PRINT
3487 021302 104414 050543      DISPLY .LINS4           ;PRINT 'SIZE'
3488 021306 016046 000020      MOV    $WRDL(RO), -(SP) ;BUFFER SIZE
3489 021312 004737 022224      JSR    PC,LINDEC          ;TYPE IT IN DECIMAL
3490 021316 104414 050555      DISPLY .LINX4           ;'ACTUAL NMBR WRDS XFRD = '
3491 021322 016046 000240      MOV    $RPBA(RO), -(SP) ;VALUE IN BUFFER ADDR REGISTER
3492 021326 166016 000006      SUB    $BUF(RO), (SP)   ;SUBTRACT STARTING ADDRESS
3493 021332 006216                ASR    (SP)              ;CONVERT INTO A WORD COUNT
3494 021334 004737 022224      JSR    PC,LINDEC          ;TYPE IT IN DECIMAL
3495 021340 104414 001165      DISPLY $CRLF
3496 021344 000207      1$: RTS    PC            ;RETURN
3497
3498                                ;PRINT LINE 5 OF ERROR MESSAGE
3499                                ;'GOOD DATA = XXXXXX  BAD DATA = XXXXXX  SECT POS = XXX'
3500

```

000000 104414 050610  
000001 013746 054374  
000002 004737 022172  
000003 104414 052073  
000004 013746 054376  
000005 004737 022172  
000006 104414 052073  
000007 013746 054400  
000008 004737 022172  
000009 104414 052073  
000010 013746 054402  
000011 004737 022172  
000012 104414 052073  
000013 104414 001165  
000014 000207

```
000240 LINES: DISPLY .LIND5 :PRINT 'GOOD DATA'  
SUB #2 $RPA(RO) :BACK THE ADDRESS UP  
MOV $RPA(RO),-(SP) :'GOOD' DATA - AT THE BUFFER LOCATION  
JSR PC,LINOC :TYPE IT  
DISPLY .LINB5 :PRINT 'BAD DATA'  
MOV $RPA(RO),-(SP) :BAD DATA FROM BUFFER  
JSR PC,LINOC :TYPE IT  
MOV $RPA(RO),-(SP) :WORD LENGTH ON STACK  
ADD $RDL(RO),(SP) :MAKE INTO A POSITIVE NUMBER  
CLR -(SP) :UPPER DIVIDEND TO ZERO  
MOV $SSEC(RO),-(SP) :SECTOR SIZE ON THE STACK  
JSR PC,LINOCV :DIVIDE WORDS XFERED BY SECTOR SIZE  
MOV (SP)+(SP) :MOVE REMAINDER LP THE STACK  
DISPLY .LINS :PRINT 'SECT POS'  
JSR PC,LINDEC :TYPE THE POSITION  
DISPLY $CRLF  
RTS PC
```

:PRINT LINE 5A OF THE ERROR MESSAGE  
:'HEADER FROM ERROR SECTOR XXXXXX XXXXXX XXXXXX XXXXXX'

021446 104414 050661  
021452 013746 054374  
021458 004737 022172  
021464 104414 052073  
021470 013746 054376  
021476 004737 022172  
021482 104414 052073  
021488 013746 054400  
021494 004737 022172  
021500 104414 052073  
021506 013746 054402  
021512 004737 022172  
021518 104414 052073  
021524 013746 054402  
021530 004737 022172  
021536 104414 052073  
021542 104414 001165  
021548 000207

```
LINESA: DISPLY .LINS : 'HEADER CONTENTS OF ERROR SECTOR'  
MOV CYLDER, -(SP) : 'HEADER POSITION'  
JSR PC,LINOC :TYPE IT  
DISPLY .LINS :SPACES  
MOV CYLDER+2, -(SP) : 'HEADER POSITION +2'  
JSR PC,LINOC :TYPE IT  
DISPLY .LINS :SPACES  
MOV CYLDER+4, -(SP) : 'HEADER POSITION +4'  
JSR PC,LINOC :TYPE IT  
DISPLY .LINS :SPACES  
MOV CYLDER+6, -(SP) : 'HEADER POSITION +6'  
JSR PC,LINOC :TYPE IT  
DISPLY .LINS :SPACES  
DISPLY $CRLF  
RTS PC
```

:PRINT LINE 5B OF ERROR MESSAGE  
:'RPEC1 = XXXXXX RPEC2 = XXXXXX'

021543 104414 050715  
021544 016046 000300  
021550 004737 022172  
021554 104414 052073  
021560 104414 050726  
021564 016046 000302  
021570 004737 022172  
021574 104414 001165  
021600 000207

```
LINESB: DISPLY .LINE5 : 'RPEC1 = '  
MOV $RPEC1(RO),-(SP) :PUT REGISTER CONTENTS ON THE STACK  
JSR PC,LINOC :TYPE IT  
DISPLY .LINS :SPACES  
DISPLY .LINE5 : 'RPEC2 = '  
MOV $RPEC2(RO),-(SP) :PUT REGISTER CONTENTS ON THE STACK  
JSR PC,LINOC :TYPE IT  
DISPLY $CRLF  
RTS PC :RETURN
```

:PRINT LINE 6 OF ERROR MESSAGE  
:'SECTOR IS ECC CORRECTABLE'

021602 104414 050740

```
LINE6: DISPLY .LINB6 :ECC CORRECTABLE
```

```

3555 021606 104414 001165          DISPLY  $CRLF
3556 021612 000207          RTS      PC
3557                                     :PRINT LINE 6A OF THE ERROR MESSAGE
3558                                     : 'SECTOR READ CORRECTLY AT OFFSET N'
3559
3560 021614 104414 050773  LINE6A: DISPLY  ,LINC6          :PRINT 'READ CORRECTLY AT OFFSET N'
3561 021620 000411          BR      LINC.1          :TYPE THE REST OF THE LINE
3562                                     :PRINT LINE 6B OF THE ERROR MESSAGE
3563                                     : 'SECTOR IS ECC CORRECTABLE AT OFFSET N'
3564
3565 021622 104414 050740  LINE6B: DISPLY  ,LINB6          :PRINT 'SECTOR IS ECC CORRECTABLE '
3566 021626 000406          BR      LINB.1
3567                                     :PRINT LINE 6C OF THE ERROR MESSAGE
3568                                     : 'CORRECTED ON NTH RETRY'
3569
3570 021630 104414 051022  LINE6C: DISPLY  ,LING6          : 'CORRECTED ON NTH RETRY'
3571 021634 000414          BR      LING.2          :TYPE THE REST OF THE LINE
3572                                     :PRINT LINE 6D OF THE ERROR MESSAGE
3573                                     : 'UNCORRECTABLE AFTER N RETRIES'
3574
3575 021636 104414 051051  LINE6D: DISPLY  ,LINU06         : 'UNCORRECTABLE AFTER N RETRIES'
3576 021642 000411          BR      LIN6.2         :FINISH
3577                                     :TYPE THE OFFSET VALUE IN MICRO-INCHES
3578
3579 021644 006301          LINE6.1: ASL      R1          :DOUBLE THE OFFSET TABLE INDEX
3580 021646 016137 002220 021656  MOV      OFMTBL(R1),15    :ADDRESS OF OFFSET POSITION MESSAGE
3581 021654 104414          DISPLY
3582 021656 000000          IS:      .WORD 0          :OFFSET VALUE
3583 021660 104414 001165          DISPLY  $CRLF
3584 021664 000207          RTS      PC
3585                                     :RETRY COUNT TYPEOUT
3586
3587 021666 005046          LINE6.2: CLR      -(SP)         :CLEAR STACK
3588 021670 113716 001253  MOVB     RETRY+1,(SP)     :RETRY COUNT
3589 021674 004737 022224  JSR      PC,LINDEC       :TYPE IT IN DECIMAL
3590 021700 104414 051040  DISPLY  ,LINR6          : 'RETRY'
3591 021704 104414 001165  DISPLY  $CRLF
3592 021710 000207          RTS      PC
3593                                     :PRINT LINE 7 OF THE ERROR MESSAGE
3594                                     : 'ORDERS:XXXXX TOTAL ERRORS:XXX WRDS XFRD:XXXX>XX WRDS READ:XXXXXXX'
3595
3600 021712 104414 051124  LINE7:  DISPLY  ,LIN70          :PRINT ORDER COUNT
3601 021716 012746 000036  MOV      $OPERC,-(SP)    :TO STACK
3602 021722 060016          ADD      R0,(SP)        :ADD THE BASE ADDRESS
3603 021724 004737 032500  JSR      PC,$DB20       :CONVERT IT
3604 021730 004737 027320  JSR      PC,$SUPRS      :PRINT IT
3605 021734 104414 051203  DISPLY  ,LIN7T          :TOTAL ERRORS

```

ERROR MESSAGE GENERATION ROUTINES

```

0220019 0221740 016046 000056      MOV      $TOTAL(R0),-(SP)      ;TO STACK
0220020 0221744 004737 022224      JSR      PC,LINDEC           ;TYPE IT IN DECIMAL
0220021 0221750 104414 051215      DISPLY   .LIN7X              ;PRINT 'WRDS XFR'
0220022 0221754 012746 000046      MOV      $STRANS,-(SP)       ;ADDRESS OF LOW WORD ON STACK
0220023 0221760 060016          ADD      R0,(SP)
0220024 0221762 004737 032500      JSR      PC,$DB2D           ;CONVERT
0220025 0221766 004737 027320      JSR      PC,$SUPRS          ;PRINT
0220026 0221772 104414 051231      DISPLY   .LIN7R              ;'BITS READ'
0220027 0221776 012746 000052      MOV      $SREAD,-(SP)       ;LOW WORD ADDR ISS
0220028 0222004 060016          ADD      R0,(SP)
0220029 0222010 004737 032500      JSR      PC,$DB2D           ;CONVERT
0220030 0222014 004737 027320      JSR      PC,$SUPRS          ;PRINT
0220031 0222018 104414 001165      DISPLY   .$CRLF
0220032 0222022 104414 001165      DISPLY   .$CRLF
0220033 0222026 032777 100000      BIT      $SW15,$SWR         ;SEE IF 'HALT ON ERROR' - SWITCH 15
0220034 0222032 001401          BEQ      IS                  ;BR IF NOT
0220035 0222036 000050          HALT
0220036 000207          RTS      PC                  ;SWITCH 15 HALT

IS:
;PRINT LINE 7A OF ERROR MESSAGE
;'ORDERS:XXXXX TOTAL SEEKS=XXXXX TOTAL MISPOS ERR = XXX TOTAL SKI,OCYL ERR = XXX'
LINE7A: DISPLY .LIN7O          ;'ORDERS = '
MOV      $OPERC,-(SP)        ;ORDER COUNT INCREMENT
ADD      R0,(SP)             ;ADD BASE ADDRESS
JSR      PC,$DB2D           ;CONVERT THE COUNT
JSR      PC,$SUPRS          ;PRINT IT
DISPLY   .LIN7P              ;'TOTAL SEEKS = '
MOV      $SPOSIT,-(SP)      ;TOTAL SEEKS
ADD      R0,(SP)             ;DEVICE TABLE ADDRESS
JSR      PC,$DB2D           ;CONVERT THE SEEK COUNT
JSR      PC,$SUPRS          ;PRINT IT
DISPLY   .LIN7M              ;' TOTAL MISPOS ERR = '
MOV      $MISPO(R0),-(SP)   ;TOTAL ERRORS
JSR      PC,LINDEC          ;TYPE IT IN DECIMAL
DISPLY   .LIN7S              ;' TOTAL SKI,OCYL ERR = '
MOV      $SKI(R0),-(SP)     ;CONVERT & PRINT IT
JSR      PC,LINDEC          ;TYPE IT IN DECIMAL
DISPLY   .$CRLF
DISPLY   .$CRLF
BIT      $SW15,$SWR         ;SEE IF HALT ON ERROR - SWITCH 15 SET
BEQ      IS                  ;BR IF NOT
HALT
IS:      RTS      PC          ;SWITCH 15 HALT

;PRINT LINE 8 OF THE ERROR MESSAGE
;'DIFFERENT ERROR DURING RETRY'
LINE8:  DISPLY   .LIN8M
JSR      PC,LIN2           ;PRINT LINE 2 OF ERROR MESSAGE
RTS      PC

;OCTAL TYPEOUT ROUTINE
;CALL:

```

```

3663      :      MOV      NUM,-(SP)      ;PUT THE NUMBER ON THE STACK
3664      :      JSR      PC,LINOC7
3665      :      RETURN
3666
3667      022172  016646  000002      LINOC7: MOV      2(SP),-(SP)      ;PUT NUMBER IN PROPER LOCATION ON STACK
3668      022176  004737  027750      JSR      PC,$$820      ;CONVERT THE NUMBER TO OCTAL
3669      022202  012637  022216      MOV      (SP)+,1$      ;GET THE ADDRESS OF THE ASCII STRING
3670      022206  062737  000005  022216      ADD      #5.,1$      ;ADDRESS THE LAST 6 ASCII DIGITS
3671      022214  104414      DISPLY      ;TYPE IT
3672      022216  000000      1$:      .WORD      0      ;ADDRESS
3673      022220  012616      MOV      (SP)+,(SP)      ;CORRECT THE STACK
3674      022222  000207      RTS      PC      ;RETURN
3675
3676      ;ROUTINE TO CONVERT THE INPUT NUMBER TO DECIMAL AND TYPE IT WITH
3677      ;LEADING ZERO SUPPRESSION
3678      ;CALL:
3679      :      MOV      NUM,-(SP)      ;PUT THE NUMBER ON THE STACK
3680      :      JSR      PC,LINDEC
3681      :      RETURN
3682
3683      022224  016646  000002      LINDEC: MOV      2(SP),-(SP)      ;SET UP STACK FOR CONVERT
3684      022230  004737  027720      JSR      PC,$$820      ;CONVERT IT TO DECIMAL
3685      022234  004737  027320      JSR      PC,$$SUPRS      ;TYPE IT (WITH LEADING ZEROS SUPRESSED)
3686      022240  012616      MOV      (SP)+,(SP)      ;RESTORE STACK POINTER
3687      022242  000207      RTS      PC
3688
3689      ::*****
3690      .SBTTL  GENERAL SUPPORT SUBROUTINES
3691      ::*****
3692
3693      ;DECREMENT THE SECTOR-TRACK ADDRESS
3694      ;CALL:
3695      :      MOV      #DPB,RO      ;DPB ADDRESS
3696      :      JSR      PC,READDR
3697      :      RETURN
3698      :      (SP) CONTAINS THE TRACK ADDRESS
3699      :      2(SP) CONTAINS THE SECTOR ADDRESS
3700
3701
3702
3703      022244  162706  000004      READDR: SUB      #4,SP      ;DECREMENT THE STACK POINTER
3704      022250  016616  000004      MOV      4(SP),(SP)      ;MOVE THE RETURN ADDR DOWN THE STACK
3705      022254  005066  000004      CLR      4(SP)      ;CLEAR STACK FOR SECTOR
3706      022260  005066  000002      CLR      2(SP)      ;CLEAR STACK FOR TRACK
3707      022264  116066  000242  000004      MOVB     $RPDA(RO),4(SP)      ;INCREMENTED SECTOR ON STACK
3708      022272  005366  000004      DEC      4(SP)      ;DECREMENT THE SECTOR ADDRESS
3709      022276  100015      BPL      1$      ;BR IF SECTOR GREATER THAN 0
3710      022300  012766  000025  000004      MOV      #21.,4(SP)      ;JAM SECTOR ADDRESS TO 21(10)
3711      022306  116066  000243  000002      MOVB     $RPDA+1(RO),2(SP)      ;TRACK ADDRESS
3712      022314  005366  000002      DEC      2(SP)      ;DECREMENT TRACK ADDRESS
3713      022320  100007      BPL      2$      ;BR IF IT DIDN'T GO NEG
3714      022322  012766  000022  000002      MOV      #18.,2(SP)      ;RESET TRACK TO 18(10)
3715      022330  000403      BR      2$
3716      022332  116066  000243  000002  1$:      MOVB     $RPDA+1(RO),2(SP)      ;TRACK ADDRESS

```

```

3717 022340 000207      2$:   RTS      PC      ;RETURN
3718
3719      ;ROUTINE TO CHECK FOR KW11-L OR KW11-P CLOCKS
3720
3721 022342 012737 177777 001210 CKCLK:  MOV      #-1,CLKFLG ;CLEAR CLOCK AVAILABILITY FLAG
3722 022350 012737 177777 001206      MOV      #-1,PCLOCK ;CLEAR KW11-P CLOCK AVAILABILITY FLAG
3723 022356 012737 022436 000004      MOV      #CKCLK1,ERRVEC ;SET UP VECTOR FOR CLOCK CHECK
3724 022364 005037 000006      CLR      @#ERRVEC+2 ;NEW PSW
3725 022370 005777 156600      TST      @SLKCSR ;CHECK FOR KW11-P
3726 022374 005037 001210      CLR      CLKFLG ;SET CLOCK AVAILABILITY FLAG
3727 022400 005037 001206      CLR      PCLOCK ;SET KW11-P CLOCK FLAG
3728 022404 013701 001200      MOV      $LPVEC,R1 ;KW11-P VECTOR ADDRESS
3729 022410 012721 023476      MOV      #CLOCK,(R1)+ ;SET UP KW11-P VECTOR
3730 022414 012711 000300      MOV      #300,(R1) ;PSW - PRI 6
3731 022420 012777 174575 156550      MOV      #-1667,@SLKCSB ;LOAD COUNTER BUFFER WITH 16.67
3732 022426 012777 000131 156540      MOV      #131,@SLKCSR ;SET CLOCK - CNT UP, IOUS. CONT INT
3733 022434 000437
3734 022436 062706 000004      BR      CKCLK3
3735 022442 012737 022504 000004 CKCLK1: ADD      #4,SP ;RESTORE THE STACK POINTER
3736 022450 005777 156526      MOV      #CKCLK2,@#ERRVEC ;CHANGE ERROR VECTOR TO CHECK FOR KW11-L
3737 022454 005037 001210      TST      @SLKS ;LOOK FOR KW11-L
3738 022460 013701 001204      CLR      CLKFLG ;SET CLOCK FLAG
3739 022464 012721 023476      MOV      $LLVEC,R1 ;KW11-L VECTOR ADDRESS
3740 022470 012711 000300      MOV      #CLOCK,(R1)+ ;SET UP KW11-L VECTOR
3741 022474 012777 000100 156500      MOV      #300,(R1) ;PSW - PRI 6
3742 022502 000414      MOV      #100,@SLKS ;SET KW11-L INTERRUPT
3743 022504 062706 000004      BR      CKCLK3
3744 022510 104401 052651      CKCLK2: ADD      #4,SP ;RESTORE THE STACK POINTER
3745 022514 005737 000042      TYPE    ,NEOCLK ;'P OR L CLOCK MUST BE ON SYSTEM'
3746 022520 001402      TST     42 ;UNDER MONITOR CONTROL ?
3747 022522 000137 005256      BEQ     1$ ;BR IF NOT
3748 022526 000000      JMP     $GET42 ;ABORT PROGRAM
3749 022530 000137 004066      1$:     HALT ;HALT
3750 022534 012737 000006 000004 CKCLK3: JMP     START ;TRY AGAIN
3751 022542 000207      MOV     #6,@#ERRVEC ;RESTORE THE ERROR VECTOR
3752      RTS     PC
3753      ;ROUTINE TO DISPLAY STATISTICS FOR ALL DRIVE ASSIGNED
3754      ;CALL:
3755      ; JSR PC,STATPR
3756      ; RETURN
3757
3758 022544 010046      STATPR: MOV     R0,-(SP) ;SAVE R0
3759 022546 010446      MOV     R4,-(SP) ;SAVE R4
3760 022550 005737 001442      TST     ASNLST ;ANY DRIVES ASSIGNED ?
3761 022554 001421      BEQ     3$ ;BR IF NOT
3762 022556 004737 022654      JSR     PC,SHDTYP ;TYPE THE HEADING
3763 022562 005004      CLR     R4 ;CLEAR THE DRIVE INDEX
3764 022564 006304      1$:     ASL     R4 ;CHANGE TO INDEX WORDS
3765 022566 016400 001720      MOV     BLKADR(R4),R0 ;GET THE DRIVE'S BLOCK ADDRESS
3766 022572 006204      ASR     R4 ;RESTORE R4
3767 022574 136437 033236 001442      BITB   ATABIT(R4),ASNLST ;IS THIS DRIVE ASSIGNED ?
3768 022602 001402      BEQ     2$ ;BR IF NOT
3769 022604 004737 022676      JSR     PC,SDETAL ;TYPE THE PERFORMANCE SUMMARY
3770 022610 005204      2$:     INC     R4 ;INCREMENT THE INDEX
    
```

```

3771 022612 020427 000010      CMP      R4,#8.      ;FINISHED ?
3772 022616 001362              BNE      1$         ;BR IF NOT
3773 022620 012604      3$:      MOV      (SP)+,R4   ;RESTORE R4
3774 022622 012600      MOV      (SP)+,R0   ;RESTORE R0
3775 022624 000207      RTS       PC        ;RETURN
3776
3777      ;ROUTINE TO TYPE STATISTICS FOR AN INDIVIDUAL DRIVE
3778      ;CALL:
3779      ;
3780      ;      MOV      #DPB,R0      ;DPB ADDRESS
3781      ;      JSR      PC,TYPEST
3782      ;      RETURN
3783 022626 010046      TYPEST: MOV      R0,-(SP) ;SAVE R0
3784 022630 010446      MOV      R4,-(SP)   ;SAVE R4
3785 022632 004737 022654      JSR      PC,SHDTYP ;TYPE THE HEADING
3786 022636 005004      CLR      R4         ;CLEAR R4 FOR DRIVE NUMBER
3787 022640 111004      MOVB     (R0),R4    ;DRIVE NUMBER
3788 022642 004737 022676      JSR      PC,SDETAL ;TYPE THE STATISTICS
3789 022646 012604      MOV      (SP)+,R4   ;RESTORE R4
3790 022650 012600      MOV      (SP)+,R0   ;RESTORE R0
3791 022652 000207      RTS       PC        ;RETURN
3792
3793      ;TYPE THE HEADER FOR THE DRIVE PERFORMANCE SUMMARY TYPEOUT.
3794      ;CALL:
3795      ;      JSR      PC,SHDTYP
3796      ;      RETURN
3797
3798 022654 004737 023400      SHDTYP: JSR      PC,$TIME ;TYPE THE TIME OF DAY
3799 022660 004537 027360      JSR      R5,TYPRI4 ;TYPE AT PRIORITY 4
3800 022664 001165      $CRLF
3801 022666 004537 027360      JSR      R5,TYPRI4 ;TYPE THE HEADER
3802 022672 052321      STATHD
3803 022674 000207      RTS       PC        ;RETURN
3804
3805      ;TYPE THE PERFORMANCE SUMMARY DATE LINE
3806      ;CALL:
3807      ;      MOV      #DRIVE,R4   ;DRIVE NUMBER
3808      ;      MOV      #DPB,R0     ;DPB ADDRESS
3809      ;      RETURN
3810
3811 022676 010246      SDETAL: MOV      R2,-(SP) ;SAVE R2
3812 022700 010002      MOV      R0,R2     ;DPB ADDRESS
3813 022702 062702 000036      ADD     #%CPERC,R2 ;FIRST STATISTICAL FIELD
3814 022706 010446      MOV      R4,-(SP)  ;SAVE R4 FOR TYPEOUT
3815
3816 022710 104403      TYPOS
3817 022712      .BYTE 2          ;GO TYPE--OCTAL ASCII
3818 022713      .BYTE 0          ;TYPE 2 DIGIT(S)
3819 022714 104401 052073      TYPE     ,LINSPL   ;SUPPRESS LEADING ZEROS
3820 022720 016046 000070      MOV      $PASSC(R0),-(SP) ;SPACES
3821 022724 004737 027720      JSR      PC,$SB2D ;PUT THE PASS COUNT ON THE STACK
3822 022730 004537 027230      JSR      R5,REPLZ ;CONVERT IT
3823 022734 000003      .WORD 3          ;TYPE IT
3824 022736 104401 052073      TYPE     ,LINSPL   ;TYPE 3 DIGITS
                    ;SPACES
    
```

3825	022742	010246		MOV	R2, -(SP)	: PUT \$OPERC ON THE STACK
3826	022744	004737	032500	JSR	PC, \$DB2D	: CONVERT IT
3827	022750	004537	027230	JSR	R5, REPLZ	: TYPE \$OPERC
3828	022754	000006		.WORD	6	: TYPE 6 DIGITS
3829	022756	104401	052073	TYPE	, LINSF	: SPACES
3830	022762	062702	000004	ADD	#4, R2	: INCREMENT R2
3831	022766	010246		MOV	R2, -(SP)	: PUT \$POSIT ON THE STACK
3832	022770	004737	032500	JSR	PC, \$DB2D	: CONVERT IT
3833	022774	004537	027230	JSR	R5, REPLZ	: TYPE \$POSIT
3834	023000	000006		.WORD	6	: TYPE 6 DIGITS
3835	023002	104401	052073	TYPE	, LINSF	: SPACES
3836	023006	062702	000004	ADD	#4, R2	: INCREMENT R2
3837	023012	010246		MOV	R2, -(SP)	: PUT \$TRANS ON THE STACK
3838	023014	004737	032500	JSR	PC, \$DB2D	: CONVERT \$TRANS
3839	023020	004537	027230	JSR	R5, REPLZ	: TYPE IT
3840	023024	000012		.WORD	10	: TYPE 10 DIGITS
3841	023026	104401	052073	TYPE	, LINSF	: SPACES
3842	023032	062702	000004	ADD	#4, R2	: INCREMENT R2
3843	023036	010246		MOV	R2, -(SP)	: PUT \$READ ON THE STACK
3844	023040	004737	032500	JSR	PC, \$DB2D	: CONVERT \$READ
3845	023044	004537	027230	JSR	R5, REPLZ	: TYPE IT
3846	023050	000012		.WORD	10	: TYPE 10 DIGITS
3847	023052	104401	052074	TYPE	, LINSPO	: 1 SPACE
3848	023056	062702	000004	ADD	#4, R2	: INCREMENT R2
3849	023062	062702	000002	ADD	#2, R2	: INCREMENT R2 AGAIN
3850	023066	012246		MOV	(R2)+, -(SP)	: PUT \$SOFT ON THE STACK
3851	023070	004737	027720	JSR	PC, \$\$B2D	: CONVERT \$SOFT
3852	023074	004537	027230	JSR	R5, REPLZ	: TYPEOUT \$SOFT
3853	023100	000004		.WORD	4	: TYPE 4 DIGITS
3854	023102	104401	052074	TYPE	, LINSPO	: SPACES
3855	023106	012246		MOV	(R2)+, -(SP)	: PUT \$HARD ON THE STACK
3856	023110	004737	027720	JSR	PC, \$\$B2D	: CONVERT \$HARD
3857	023114	004537	027230	JSR	R5, REPLZ	: TYPEOUT \$HARD
3858	023120	000004		.WORD	4	: TYPE 4 DIGITS
3859	023122	104401	052074	TYPE	, LINSPO	: SPACES
3860	023126	012246		MOV	(R2)+, -(SP)	: PUT \$SKI ON THE STACK
3861	023130	004737	027720	JSR	PC, \$\$B2D	: CONVERT \$SKI
3862	023134	004537	027230	JSR	R5, REPLZ	: TYPEOUT \$SKI
3863	023140	000004		.WORD	4	: TYPE 4 DIGITS
3864	023142	104401	052074	TYPE	, LINSPO	: SPACES
3865	023146	012246		MOV	(R2)+, -(SP)	: PUT \$MISPO ON THE STACK
3866	023150	004737	027720	JSR	PC, \$\$B2D	: CONVERT \$MISPO
3867	023154	004537	027230	JSR	R5, REPLZ	: TYPEOUT \$MISPO
3868	023160	000004		.WORD	4	: TYPE 4 DIGITS
3869	023162	104401	052074	TYPE	, LINSPO	: SPACES
3870	023166	016046	000056	MOV	\$TOTAL(R0), -(SP)	: CALCULATE NUMBER OF OTHER ERRORS
3871	023172	166016	000060	SUB	\$SOFT(R0), (SP)	: SUBTRACT \$SOFT FROM \$TOTAL
3872	023176	166016	000062	SUB	\$HARD(R0), (SP)	: SUBTRACT \$HARD FROM \$TOTAL
3873	023202	166016	000064	SUB	\$SKI(R0), (SP)	: SUBTRACT \$SKI FROM \$TOTAL
3874	023206	166016	000066	SUB	\$MISPO(R0), (SP)	: SUBTRACT \$MISPO FROM \$TOTAL
3875	023212	004737	027720	JSR	PC, \$\$B2D	: CONVERT 'OTHER' COUNT
3876	023216	004537	027230	JSR	R5, REPLZ	: TYPE IT
3877	023222	000004		.WORD	4	: TYPE 4 DIGITS
3878	023224	104401	001165	TYPE	, \$CRLF	



```

3879 023230 012502      MOV      (SP)+,R2      ;RESTORE R2
3880 023232 000207      RTS        PC
3881
3882
3883
3884
3885      ;ROUTINE TO INCREMENT $SOFT
3886      ;NOTE: $SOFT WILL NOT BE INCREMENTED BEYOND 9999 (10)
3887
3888 023234 005737 001264      INCSOF: TST      BADSEC      ;SEE IF BAD TRK/SEC INDICATOR SET
3889 023240 001006          BNE        1$              ;BR IF IT'S SET, DON'T INCREMENT COUNT
3890 023242 026027 000060 023417      CMP        $SOFT(RO),#9999. ;IS $SOFT ALREADY AT MAXIMUM ?
3891 023250 103002          BHIS       1$              ;BR IF IT IS
3892 023252 005260 000060      INC        $SOFT(RO)      ;INCREMENT $SOFT
3893 023256 000207      1$:      RTS        PC      ;RETURN
3894
3895
3896      ;ROUTINE TO INCREMENT $SHARD
3897      ;NOTE: $SHARD WILL NOT BE INCREMENTED BEYOND 9999 (10)
3898
3899
3900 023260 005737 001264      INCHRD: TST      BADSEC      ;SEE IF BAD TRK/SEC INDICATOR SET
3901 023264 001006          BNE        1$              ;BR IF IT'S SET, DON'T INCREMENT COUNT
3902 023266 026027 000062 023417      CMP        $SHARD(RO),#9999. ;IS $SHARD ALREADY AT MAXIMUM ?
3903 023274 103002          BHIS       1$              ;BR IF IT IS
3904 023276 005260 000062      INC        $SHARD(RO)     ;INCREMENT $SHARD
3905 023302 000207      1$:      RTS        PC      ;RETURN
3906
3907
3908      ;ROUTINE TO INCREMENT $SKI
3909      ;NOTE: $SKI WILL NOT BE INCREMENTED BEYOND 9999 (10)
3910
3911
3912 023304 005737 001264      INCSKI: TST      BADSEC      ;SEE IF BAD TRK/SEC INDICATOR SET
3913 023310 001006          BNE        1$              ;BR IF IT'S SET, DON'T INCREMENT COUNT
3914 023312 026027 000064 023417      CMP        $SKI(RO),#9999.  ;IS $SKI ALREADY AT MAXIMUM ?
3915 023320 103002          BHIS       1$              ;BR IF IT IS
3916 023322 005260 000064      INC        $SKI(RO)       ;INCREMENT $SKI
3917 023326 000207      1$:      RTS        PC      ;RETURN
3918
3919
3920      ;ROUTINE TO INCREMENT $MISPO
3921      ;NOTE: $MISPO WILL NOT BE INCREMENTED BEYOND 9999 (10)
3922
3923
3924 023330 005737 001264      INCMIS: TST      BADSEC      ;SEE IF BAD TRK/SEC INDICATOR SET
3925 023334 001006          BNE        1$              ;BR IF IT'S SET, DON'T INCREMENT COUNT
3926 023336 026027 000066 023417      CMP        $MISPO(RO),#9999. ;IS $MISPO ALREADY AT MAXIMUM ?
3927 023344 103002          BHIS       1$              ;BR IF IT IS
3928 023346 005260 000066      INC        $MISPO(RO)     ;INCREMENT $MISPO
3929 023352 000207      1$:      RTS        PC      ;RETURN
3930
3931
3932      ;ROUTINE TO INCREMENT $TOTAL
    
```

```

3933
3934
3935
3936 023354 005737 001264
3937 023360 001036
3938 023362 026027 000056 023417
3939 023370 103002
3940 023372 005760 000056
3941 023376 000207
3942
3943
3944
3945
3946
3947
3948
3949
3950
3951
3952
3953
3954
3955
3956
3957
3958
3959
3960
3961
3962
3963
3964
3965
3966
3967
3968
3969
3970
3971
3972
3973
3974
3975
3976
3977
3978
3979
3980
3981
3982
3983
3984
3985
3986

```

```

;NOTE: $TOTAL WILL NOT BE INCREMENTED BEYOND 9999 (10)
INCTOT: TST BADSEC ;SEE IF BAD TRK/SEC INDICATOR SET
        BNE 1$ ;BR IF IT'S SET, DON'T INCREMENT COUNT
        CMP $TOTAL(R0),#9999 ;IS $TOTAL ALREADY AT MAXIMUM ?
        BHS 1$ ;BR IF IT IS
        INC $TOTAL(R0) ;INCREMENT $TOTAL
1$: RTS PC ;RETURN

```

:ROUTINE TO TYPE THE TIME

```

$TIME: TST CLKFLG ;CLOCK ON THE SYSTEM ?
        BNE 1$ ;BR IF NOT
        TYPE , $CRLF ;CR-LF
        MOV HOUR, -(SP) ;PUT 'HOURS' ON THE STACK
        JSR PC, $SB20 ;CONVERT TO DECIMAL
        JSR R5, REPLZ ;TYPE IT
        .WORD 2 ;TYPE 2 DIGITS
        TYPE , COLON ;'.'
        MOV MINUTE, -(SP) ;PUT 'MINUTES' ON THE STACK
        JSR PC, $SB20 ;CONVERT TO DECIMAL
        JSR R5, REPLZ ;TYPE IT
        .WORD 2 ;TYPE 2 DIGITS
        TYPE , COLON ;'.'
        MOV SECOND, -(SP) ;PUT SECONDS ON THE STACK
        JSR PC, $SB20 ;CONVERT TO DECIMAL
        JSR R5, REPLZ ;TYPE IT
        .WORD 2 ;TYPE 2 DIGITS
1$: RTS PC

```

:CLOCK HANDLER ROUTINE

```

CLOCK: DEC SIXTEE ;INCREMENT THE 1/60 SECOND COUNTER
        BNE 1$ ;BR IF A SECOND NOT COUNTED
        MOV HZ, SIXTEE ;RESTORE THE VALUE
        INC SECOND ;COUNT THE SECOND
        CMP #60., SECOND ;AT MAXIMUM ?
        BNE 1$ ;BR IF NOT
        CLR SECOND ;CLEAR THE SECOND'S COUNTER
        INC INTRVL+2 ;COUNT THE PERFORMANCE SUMMARY INTERVAL
        INC MINUTE ;COUNT THE MINUTE
        CMP #60., MINUTE ;AT MAXIMUM ?
        BNE 1$ ;BR IF NOT
        CLR MINUTE ;CLEAR THE MINUTE'S COUNTER
        INC HOUR ;COUNT THE HOURS
        CMP #999., HOUR ;AT MAXIMUM
        BHS 1$ ;BR IF NOT
        CLR HOUR ;CLEAR THE HOURS
        MOV #17., -(SP) ;17 MS ON THE STACK
        JSR PC, RPTMR ;DRIVER TIMER ROUTINE
        TST INTRVL ;DISPLAY THE PERFORMANCE SUMMARY ?
        BEQ 2$ ;BR IF NOT

```

```

3987 023614 023737 001370 001372      CMP      INTRVL,INTRVL+2 ;DISPLAY INTERVAL FINISHED ?
3988 023622 001005                      BNE      2$ ;BR IF NOT
3989 023624 012737 177777 001214      MOV      #-1,STATIN ;SET PERFORMANCE SUMMARY DISPLAY FLAG
3990 023632 005037 001372                      CLR      INTRVL+2 ;CLEAR THE PERFORMANCE INTERVAL COUNTER
3991 023636 000C02      2$:      RTI ;RTJRN
3992
3993      ;COMMAND DECODE ROUTINE
3994      ;CALL:
3995      ;      MOV      #-1,CFLAG ;'CFLAG' IS NORMALLY SET BY THE TTY SERVICE
3996      ;      ;ROUTINE IN INTERRUPT MODE
3997      ;      JSR      PC,KSR
3998      ;      RETURN1 ;SYSTEM BUSY RETURN
3999      ;      RETURN2 ;RETURN AFTER KEYBOARD SERVICED
4000
4001 023640 005737 001420      KSR:    TST      ORDERQ ;ANY OPERATIONS ACTIVE ?
4002 023644 001003                      BNE      1$ ;BR IF SOME ARE
4003 023646 005037 023672                      CLR      3$ ;CLEAR THE LOOP COUNTER
4004 023652 000410                      BR       KSR1 ;PROCESS THE KEYBOARD REQUEST
4005 023654 062737 000001 023672 1$:      ADD      #1,3$ ;COUNT THE TIMES THROUGH THE LOOP
4006 023662 001002                      BNE      2$ ;BR IF NOT ENOUGH
4007 023664 104401 053236                      TYPE     BUSY ;'SYSTEM BUSY...'
4008 023670 000207      2$:      RTS      PC ;PROCESS ANY COMPLETED DRIVES
4009 023672 000000      3$:      .WORD 0 ;LOOP COUNTER
4010 023674 104412      KSR1:   SAVREG ;SAVE THE REGISTERS
4011 023676 012737 000200 177776      MOV      #PR4,PS ;SET PRIORITY TO 4
4012 023704 005037 001262                      CLR      CFLAG ;CLEAR THE 'CONTROL C' FLAG
4013 023710 004737 023400                      JSR      PC,$TIME ;TYPE THE TIME
4014 023714 005777 155226                      TST      $STKB ;CLEAR ANY GARBAGE IN THE TTY BUFFER
4015 023720 104401 052751                      TYPE     ,ENTCOM ;'ENTER COMMANDS'
4016 023724 104411                      RDLIN   ;READ THE KEYBOARD
4017 023726 012605                      MOV      (SP)+,R5 ;GET ADDRESS OF INPUT STRING
4018 023730 005737 001262                      TST      CFLAG ;CHECK THE CONTROL C FLAG
4019 023734 001065                      BNE      7$ ;EXIT IF 'CONTROL C' ENTERED
4020 023736 005205                      INC      R5 ;POINT TO SECOND CHARACTER
4021 023740 122715 000101                      CMPB    #'A',(R5) ;EQ TO AN 'A'
4022 023744 001410                      BEQ     1$ ;BR IF IT IS
4023 023746 121527 000067                      CMPB    (R5),#'7' ;DRIVE NUMBER GREATER THAN AN ASCII 7 ?
4024 023752 101054                      BHI     6$ ;BR IF IT IS
4025 023754 121527 000060                      CMPB    (R5),#'0' ;DRIVE NUMBER LESS THAN AN ASCII 0 ?
4026 023760 103451                      BLO     6$ ;BR IF IT IS
4027 023762 142715 177770                      BICB    #1C7,(R5) ;LEAVE ONLY LOWER 3 BITS IF CHAR NOT 'A'
4028 023766 122765 000124 177777 1$:      CMPB    #'T',-1(R5) ;EQ TO 'T'
4029 023774 001003                      BNE     2$ ;BR IF NOT EQ
4030 023776 004737 024502                      JSR     PC,NEWASN ;ASSIGN DRIVE FOR TEST
4031 024002 000442                      BR      7$ ;EXIT
4032 024004 122765 000104 177777 2$:      CMPB    #'D',-1(R5) ;EQ TO 'D' ?
4033 024012 001003                      BNE     3$ ;BR IF NOT EQ
4034 024014 004737 024512                      JSR     PC,DEASGN ;DEASSIGN DRIVE
4035 024020 000433                      BR      7$ ;EXIT
4036 024022 122765 000123 177777 3$:      CMPB    #'S',-1(R5) ;EQ TO 'S'
4037 024030 001003                      BNE     4$ ;BR IF NOT EQ
4038 024032 004737 024620                      JSR     PC,SCMND ;TYPE STATISTICS
4039 024036 000424                      BR      7$ ;EXIT
4040 024040 122765 000127 177777 4$:      CMPB    #'W',-1(R5) ;EQ TO 'W'

```

```

4041 024046 001007          BNE      5$          ;BR IF NOT EQ
4042 024050 032777 000001 155062 BIT      #SWO,ASWR   ;IS SWITCH 0 SET ?
4043 024056 001012          BNE      6$          ;BR IF SET, CAN'T DO 'W' COMMAND
4044 024060 004737 025070 JSR      PC,DATAPK  ;WRITE A DATA PACK
4045 024064 000411          BR       7$          ;EXIT
4046 024066 122765 000122 177777 5$:  CMPB    #'R,-1(R5) ;EQ TO 'R' ?
4047 024074 001003          BNE      6$          ;BR IF NOT EQ
4048 024076 004737 025102 JSR      PC,REDAPK  ;READ A DATA PACK
4049 024102 000402          BR       7$          ;EXIT
4050 024104 104401 052727          6$:  TYPE  ,INVLD    ;TYPE 'INVALID COMMAND' MESSAGE
4051 024110 104413          7$:  RESREG ;RESTORE R0 - R5
4052 024112 062716 000002 ADD      #2,(SP)    ;INCREMENT THE RETURN ADDRESS
4053 024116 005777 155024 TST     AS$TKB     ;CLEAR THE TTY BUFFER
4054 024122 052777 000100 155014 BIS     #BIT06,AS$TKS ;SET TTY INTERRUPT ENABLE
4055 024130 005037 177776 CLR     PS         ;SET PRIORITY BACK TO ZERO
4056 024134 000207          RTS      PC        ;RETURN
4057
4058                                     :ROUTINE TO PROCESS THE ASSIGN REQUEST ('T', 'R', OR 'W' COMMANDS)
4059
4060 024136 122715 000101 ASSIGN: CMPB    #'A,(R5) ;ASSIGN ALL DRIVES?
4061 024142 001430          BEQ     ASGN2      ;BR IF ALL DRIVES
4062 024144 111504          ASGN1: MOVB   (R5),R4 ;PUT DRIVE # IN R4
4063 024146 012737 052147 026366 MOV     #UNTA$N,ASNMSG ;'DRIVE ASSIGNED' MESSAGE ADDRESS
4064 024154 012703 000001 MOV     #1,R3       ;RELOAD R3 FOR 1 UNIT
4065 024160 136437 033236 001442 BITB    ATABIT(R4),ASNLS ;DRIVE ALREADY ASSIGNED ?
4066 024166 001013          BNE     2$        ;BR IF IT IS
4067 024170 005704          TST     R4        ;TRYING TO ASSIGN DRIVE 0 ?
4068 024172 001007          BNE     1$        ;BR IF NOT
4069 024174 012737 052233 026366 MOV     #NOTAVL,ASNMSG ;'NOT AVAILABLE' MESSAGE ADDRESS
4070 024202 122737 000011 000041 CMPB    #11,41     ;SEE IF LOADED FROM AN RPO4/5/6
4071 024210 001402          BEQ     2$        ;BR IF RPO4/5/6 IS THE LOAD DEVICE
4072 024212 004737 024276          1$:  JSR     PC,ASGN3 ;SEE IF DRIVE ON THE SYSTEM
4073 024216 000137 026346          2$:  JMP     ASNERR  ;RETURN HERE IF DRIVE NOT AVAIL
4074 024222 000207          RTS      PC        ;EXIT
4075 024224 122737 000011 000041 ASGN2: CMPB    #11,41 ;LOADED FROM AN RPO4/5/6
4076 024232 001005          BNE     1$        ;BR IF NOT
4077 024234 012704 000001 MOV     #1,R4      ;START WITH DRIVE 1
4078 024240 012703 000007 MOV     #7.,R3     ;SETUP FOR ONLY 7 DRIVES
4079 024244 000403          BR       2$        ;CONTINUE
4080 024246 005004          1$:  CLR     R4        ;START WITH DRIVE 0
4081 024250 012703 000010 MOV     #8.,R3     ;DRIVE COUNT FOR 8 DRIVES
4082 024254 004737 024276          2$:  JSR     PC,ASGN3 ;ASSIGN ALL UNASSIGNED, AVAIL DRIVES
4083 024260 000137 024266          3$:  JMP     4$        ;DRIVE NOT ON SYSTEM
4084 024264 000207          RTS      PC        ;RETURN
4085 024266 012746 024260          4$:  MOV     #3$,-(SP) ;PUT RETURN ADDRESS ON THE STACK
4086 024272 000137 024414          JMP     ASGN4      ;LOOK FOR MORE DRIVES
4087 024276 136437 033236 001442 ASGN3: BITB    ATABIT(R4),ASNLS ;DRIVE ALREADY ASSIGNED ?
4088 024304 001043          BNE     ASGN4      ;BR IF IT IS
4089 024306 005737 033234          1$:  TST     DTUW     ;DATA TRANSFER UNDER WAY ?
4090 024312 100375          BPL     1$        ;BR IF IT IS
4091 024314 110437 044646          MOVB   R4,GENDPB  ;DRIVE NUMBER
4092 024320 004737 015174          JSR     PC,RECALO  ;RECALIBRATE DRIVE
4093 024324 105764 033122          TSTB   DRVSTA(R4) ;DRIVE AVAILABLE?
4094 024330 001444          BEQ     ASGN7      ;BR IF DRIVE OFFLINE OR NONEXISTENT

```

```

4095 024332 100437 BMI ASGN6 ;BR IF DRIVE UNSAFE
4096 024334 006304 ASL R4 ;MAKE R4 INTO WORD INDEX
4097 024336 016464 001720 001466 MOV BLKADR(R4),NEWUNT(R4) ;DPB ADDRESS
4099 024344 016400 001720 MOV BLKADR(R4),RO ;PUT BLOCK'S ADDR INTO RO
4099 024350 004737 025114 JSR PC,CLRDPB ;CLEAR BLOCK FOR DRIVE JUST ASSIGNED
4100 024354 004737 025310 JSR PC,DRVPRM ;GET THE DRIVE'S ADDRESS LIMITS
4101 024360 004737 025572 JSR PC,GETID ;GET DRIVE I.D.
4102 024364 004737 025702 JSR PC,GETADR ;GET BAD SECTOR ADDRESSES
4103 024370 012760 000001 000070 MOV #1,$PASSC(RO) ;PRESET PASS COUNT TO 1
4104 024376 005737 001216 TST PACK ;WRITE DATA PACK ?
4105 024402 001403 BEQ 2$ ;BR IF NOT
4106 024404 113760 001216 000026 MOVB PACK,$PACK(RO) ;SET READ/WRITE DATA PACK INDICATOR
4107 024412 006204 2$: ASR R4 ;RESTORE DRIVE ADDRESS
4108 024414 005303 ASGN4: DEC R3 ;DECREMENT DRIVE COUNT
4109 024416 001402 BEQ ASGN5 ;BR IF FINISHED
4110 024420 005204 INC R4 ;INCREMENT DRIVE NUMBER
4111 024422 000725 BR ASGN3 ;CONTINUE
4112 024424 062716 000004 ASGN5: ADD #4,(SP) ;INCREMENT RETURN
4113 024430 000207 RTS PC ;RETURN
4114 024432 012737 052252 026366 ASGN6: MOV #NOTSAF,ASNMSG ;'UNSAFE' MESSAGE ADDRESS
4115 024440 000207 RTS PC ;RETURN
4116 024442 105764 033132 ASGN7: TSTB DRVTP(R4) ;DRIVE PRESENT?
4117 024446 001405 BEQ 1$ ;BR IF NOT
4118 024450 100010 BPL 2$ ;BR IF DRIVE OFFLINE
4119 024452 012737 052175 026366 MOV #NOTRP,ASNMSG ;ADDRESS OF 'NOT RPO4/5/6' MSG
4120 024460 000407 BR 3$ ;EXIT
4121 024462 012737 052215 026366 1$: MOV #NOTPRS,ASNMSG ;ADDRESS OF 'NOT PRESENT' MSG
4122 024470 000403 BR 3$ ;EXIT
4123 024472 012737 052104 026366 2$: MOV #UNTOFF,ASNMSG ;ADDRESS OF 'DRIVE OFFLINE' MESSAGE
4124 024500 000207 3$: RTS PC ;ERROR RETURN
4125
4126 ;'T' COMMAND (ROUTINE TO ASSIGN A DRIVE)
4127
4128 024502 005037 001216 NEWASN: CLR PACK ;CLEAR 'W' COMMAND INDICATOR
4129 024506 000137 024136 JMP ASSIGN ;GO TO THE ASSIGN ROUTINE
4130
4131 ;'D' COMMAND (ROUTINE TO DEASSIGN A DRIVE)
4132
4133 024512 005004 DEASGN: CLR R4
4134 024514 122715 000101 CMPB #'A,(R5) ;DEASSIGN ALL DRIVES ?
4135 024520 001434 BEQ 5$ ;BR IF YES
4136 024522 012703 000001 MOV #BIT00,R3 ;SET R3 FOR ONE UNIT
4137 024526 111504 MOVB (R5),R4 ;GET DRIVE NUMBER
4138 024530 136437 033236 001442 1$: BITB ATABIT(R4),ASNLST ;DRIVE ASSIGNED ?
4139 024536 001414 BEQ 3$ ;BR IF NOT
4140 024540 146437 033236 001442 BICB ATABIT(R4),ASNLST ;DELETE THE DRIVE FROM THE ASSIGNED LIST
4141 024546 006304 ASL R4 ;MAKE ADDR INTO A WORD INDEX
4142 024550 016464 001720 001444 MOV BLKADR(R4),DUNIT(R4) ;PUT ADDRESS IN DEASSIGN LIST
4143 024556 006204 ASR R4
4144 024560 005303 2$: DEC R3 ;ANY MORE DRIVES ?
4145 024562 001412 BEQ 4$ ;BR IF NOT
4146 024564 005204 INC R4
4147 024566 000760 BR 1$
4148 024570 122715 000101 3$: CMPB #'A,(R5) ;DEASSIGN ALL DRIVES ?

```

```

4149 024574 001771          BEQ      2$          ;BR IF YES
4150 024576 012737 052125 026366  MOV      #UNTNOT,ASNMSG ;ADDR OF 'NOT ASSIGNED' MESSAGE
4151 024604 004737 026346          JSR      PC,ASNEAR  ;REPORT IT
4152 024610 000207          4$:     RTS      PC
4153 024612 012703 000010          5$:     MOV      #8.,R3          ;SET UNIT COUNT TO 8
4154 024616 000744          BR       1$
4155
4156          ;'S' COMMAND (ROUTINE TO TYPE DRIVE PERFORMANCE SUMMARY)
4157
4158 024620 005004          SCMND:  CLR      R4
4159 024622 122715 000101          CMPB    #'A,(R5)          ;ALL STATISTICS ?
4160 024626 001421          BEQ      2$          ;BR IF YES
4161 024630 111504          MOVB    (R5),R4          ;GET DRIVE NUMBER
4162 024632 136437 032236 001442  BITB    ATABIT(R4),ASNLST ;SEE IF DRIVE ASSIGNED
4163 024640 001406          BEQ      1$          ;BR IF NOT
4164 024642 006304          ASL     R4          ;MAKE DRIVE ADDR INTO WORD INDEX
4165 024644 015400 001720          MOV     BLKADR(R4),R0    ;ADDR OF BLOCK
4166 024650 004737 022626          JSR     PC,TYPEST       ;TYPE DRIVE STATISTICS
4167 024654 000504          BR      9$          ;EXIT
4168 024656 012737 052125 026366 1$:     MOV     #UNTNOT,ASNMSG  ;ADDR OF 'NOT ASSIGNED' MSG
4169 024664 004737 026346          JSR     PC,ASNEAR       ;TYPE ERROR MESSAGE
4170 024670 000476          BR      9$          ;EXIT
4171 024672 012703 000010          2$:     MOV     #8.,R3          ;DRIVE COUNT
4172 024676 136437 033236 001442 3$:     BITB    ATABIT(R4),ASNLST ;SEE IF DRIVE ASSIGNED
4173 024704 001004          BNE     4$          ;BR IF YES
4174 024706 005204          INC     R4          ;INCREMENT DRIVE ADDRESS
4175 024710 005303          DEC     R3          ;DECREMENT COUNTER
4176 024712 001371          BNE     3$          ;MORE TO CHECK
4177 024714 000464          BR      9$          ;NONE ASSIGNED, RETURN
4178 024716 004737 022544          4$:     JSR     PC,STATPR     ;TYPE ALL STATISTICS
4179 024722 105737 001220          TSTB   DATE          ;SEE IF 'DATE' ENTERED
4180 024726 001404          BEQ     11$         ;BR IF NOT
4181 024730 104401 053127          TYPE   .DATEIS       ;'DATE: '
4182 024734 104401 001220          TYPE   .DATE          ;THE OPERATOR ENTERED DATE
4183 024740 105737 001232          11$:   TSTB   OPERID       ;SEE IF OPERATOR I.D. ENTERED
4184 024744 001404          BEQ     12$         ;BR IF NOT
4185 024746 104401 053140          TYPE   .IDIS         ;'OPERATOR I.D.: '
4186 024752 104401 001232          TYPE   ,OPERID       ;THE OPERATOR I.D.
4187 024756 104401 053162          12$:   TYPE   ,HEDLIN      ;HEADER LINE
4188 024762 012737 042032 025036  MOV     #DRIVED+$DRVID,6$ ;DRIVE I.D. FIELD ADDRESS
4189 024770 005004          CLR     R4          ;DRIVE ADDRESS
4190 024772 012703 000010          MOV     #8.,R3          ;COUNTER
4191 024776 136437 033236 001442 5$:     BITB    ATABIT(R4),ASNLST ;SEE IF DRIVE ASSIGNED
4192 025004 001417          BEQ     7$          ;BR IF NOT ASSIGNED
4193 025006 010446          MOV     R4,-(SP)      ;SAVE R4 FOR TYPEOUT
4194
4195 025010 104403          TYPOS   ;TYPE DRIVE NUMBER
4196 025012 002          .BYTE  2          ;GO TYPE--OCTAL ASCII
4197 025013 000          .BYTE  0          ;TYPE 2 DIGIT(S)
4198 025014 104401 052071          TYPE   ,LIN4SP      ;SUPPRESS LEADING ZEROS
4199 025020 105777 000012          TSTB   06$          ;4 SPACES
4200 025024 001003          BNE     10$         ;SEE IF DRIVE I.D. ENTERED
4201 025026 104401 053205          TYPE   ,NONE        ;BR IF DRIVE I.D. PRESENT
4202 025032 000404          BR      7$          ;TYPE 'NONE'
                                ;CONTINUE
    
```

```

025034 104401      105:  TYPE      ;TYPE THE DRIVE I.D.
025036 000000      65:  WORD      0      ;ADDRESS OF DRIVE I.D. FIELD HERE
025040 104401      75:  TYPE      $CRLF   ;CR-LF
025044 005303      BEQ      R3        ;DECREMENT THE COUNTER
025046 001405      BEQ      R5        ;BR IF AT END
025050 062704      ADD      #RPEC2+2.6$ ;INCREMENT THE MESSAGE FIELD ADDRESS
025056 005204      INC      R4        ;INCREMENT DRIVE ADDRESS
025060 000746      BR       R5        ;CONTINUE
025062 104401      85:  TYPE      $CRLF   ;CR-LF
025066 000207      95:  RTS       PC

; 'W' COMMAND (ROUTINE TO WRITE A DATA PACK)

025070 012737 177777 001216 DATAPK: MOV      #1,PACK      ;SET THE 'W' COMMAND INDICATOR
025076 000137 024136      JMP      ASSIGN     ;ASSIGN REQUESTED DRIVE

; 'R' COMMAND (ROUTINE TO READ A DATA PACK)

025102 012737 003001 001216 REDAPK: MOV      #1,PACK      ;SET THE 'READ' INDICATOR
025110 000137 024136      JMP      ASSIGN     ;ASSIGN THE REQUESTED DRIVE

; ROUTINE TO CLEAR THE DPB FOR THE ASSIGNED DRIVE
; CALL:
;       MOV      #DPB FO      ;DPB ADDRESS
;       JSR     PC,CLDPB
;       RETURN

CLDPB:
MOV      R3, -(SP)      ;: PUSH R3 ON STACK
MOV      R4, -(SP)      ;: PUSH R4 ON STACK
MOV      R5, -(SP)      ;: PUSH R5 ON STACK
MOV      R7, R4        ;: GET THE DPB ADDRESS
ADD      #2, R4        ;: ADDRESS OF FIRST LOCK TO BE CLEARED
MOV      #5, R3        ;: NUMBER OF LOCKS TO BE CLEARED
15:     CLR      (R4)+    ;: CLEAR THE LOCATION
DEC      R3            ;: DECREMENT THE COUNTER
BNE     R3            ;: BR IF NOT FINISHED
ADD      #2, R4        ;: MOVE THE ADDRESS PAST THE 'REG' ADDR
MOV      #NEXT-$REG, R3 ;: NUMBER OF LOCKS TO BE CLEARED
25:     CLR      (R4)+    ;: CLEAR
SUB      #2, R3        ;: DECREMENT THE LOCK COUNTER
BNE     R3            ;: BR IF NOT FINISHED
ADD      #12, R4       ;: MOVE PAST ADDRESS LIMITS
MOV      #RPEC2-MINSEC, R3 ;: NUMBER OF LOCKS TO BE CLEARED
35:     CLR      (R4)+    ;: CLEAR A LOCATION
SUB      #2, R3        ;: DECREMENT THE COUNTER
BNE     R3            ;: BR IF NOT DONE
MOVB    BEGCOD, $CODE(R0) ;: INITIAL COMMAND CODE
MOV      BEGCOD, R1    ;: GET THE ACTUAL OP CODE
MOVB    COMBL(R1), $COMND(R0) ;: OPERATION CODE
MOVB    BEGPAT, $PATTC(R0) ;: PATTERN CODE
ASLB    $PATTC(R0)     ;: CONVERT CODE TO A TABLE INDEX
MOV      BEGSIZ, $WRDL(R0) ;: BEGINNING RECORD SIZE

```

```

42957 025242 013760 001416 000004
42958 025244 005460 000004
42959 025246 012760 000400 000022
42960 025248 132760 000001 000024
42961 025250 001403
42962 025252 062760 000004 000022
42963 025300
42964 025302 012605
42965 025304 012604
42966 025306 012603
42967 025308 000207
42968
42969
42970
42971
42972
42973
42974
42975
42976
42977
42978
42979
42980
42981
42982
42983
42984
42985
42986
42987
42988
42989
42990
42991
42992
42993
42994
42995
42996
42997
42998
42999
43000
43001
43002
43003
43004
43005
43006
43007
43008
43009
43010

```

```

MOV BEGSIZ, $WRDM(R0) ; VALUE FOR DATA TRANSFER
NEG $WRDM(R0) ; MAKE IT INTO 2'S COMPLEMENT
MOV #256, $SSEC(R0) ; INITIAL VALUE OF SECTOR SIZE
BITB #1, $CODE(R0) ; HEADER ORDER ?
BEQ 4$ ; BR IF NOT
ADD #4, $SSEC(R0) ; ADD HEADER SIZE TO SECTOR SIZE
4$:
MOV (SP)+, R5 ; POP STACK INTO R5
MOV (SP)+, R4 ; POP STACK INTO R4
MOV (SP)+, R3 ; POP STACK INTO R3
RTS PC ; RETURN

:ROUTINE TO GET ADDRESS LIMITS FROM THE OPERATOR
DRVPRM: MOV R3, -(SP) ; SAVE R3
MOV R4, -(SP) ; SAVE R4
TST 42 ; RUNNING UNDER MONITOR CONTROL
BNE 3$ ; BR IF YES
TYPE ,ENTLMT ; 'ENTER ADDRESSES'
ASR R4 ; CONVERT INDEX TO DRIVE NUMBER
MOV R4, -(SP) ; SAVE R4 FOR TYPEOUT
; TYPE DRIVE NUMBER
; GO TYPE--OCTAL ASCII
; TYPE 2 DIGIT(S)
; SUPPRESS LEADING ZEROS
; SLASH
; ADDRESS OF 'RPO4' MESSAGE
MOV #RPO4B, 2$ ; RPO4 ?
BITB #BIT00, DRVTP(R4) ; RPO4 ?
BNE 1$ ; BR IF YES
MOV #RPO5, 2$ ; ADDRESS OF 'RPO5' MESSAGE
BITB #BIT01, DRVTP(R4) ; RPO5 ?
BNE 1$ ; BR IF YES
MOV #RPO6, 2$ ; ADDRESS OF 'RPO6' MESSAGE
1$:
TYPE ; TYPE THE MESSAGE WHICH FOLLOWS
2$:
WORD 0 ; MESSAGE ADDRESS
; CR-LF
MOV #410, CYLIMT ; ASSUME AN RPO4/5
BITB #BIT02, DRVTP(R4) ; SEE IF RPO6
BEQ 4$ ; BR IF NOT
MOV #814, CYLIMT ; CHANGE LIMIT TO 814
ADD #-1, $FIRST(R0) ; SEE IF FIRST TIME STARTED
BCS 5$ ; BR IF NOT
MOV CYLIMT, MAXCYL(R0) ; LOAD MAXIMUM CYLINDER
CLR MINCYL(R0) ; CLEAR MINIMUM CYLINDER
MOV TRKLMT, MAXTRK(R0) ; LOAD MAXIMUM TRACK
CLR MINTRK(R0) ; CLEAR MINIMUM TRACK
MOV SECLMT, MAXSEC(R0) ; LOAD MAXIMUM SECTOR
CLR MINSEC(R0) ; CLEAR MINIMUM SECTOR
5$:
ASL R4 ; SETUP TO ADDRESS WORDS
MOV TABLE(R4), R3 ; PARAMETER TABLE ADDRESS
MOV CYLIMT, 2(R3) ; LOAD CYLINDER LIMIT FOR LAST CYLINDER
MOV CYLIMT, 10(R3) ; LOAD CYLINDER LIMIT FOR STARTING CYLINDER
TST 42 ; UNDER MONITOR CONTROL ?
BNE 6$ ; BR IF YES

```



```

4311 025536 004737 026222 JSR PC PARENT ;GET THE DRIVE'S PARAMETERS
4312 025542 116060 000120 000010 6$: MOVB MINSEC(RO), $SEC(RO) ;INITIAL SECTOR VALUE
4313 025550 115060 000114 000011 MOVB MINTRK(RO), $TRK(RO) ;INITIAL TRACK VALUE
4314 025556 016060 000110 000012 MOV MINCYL(RO), $CYL(RO) ;INITIAL CYLINDER VALUE
4315 025564 012604 MOV (SP)+,R4 ;RESTORE R4
4316 025566 012603 MOV (SP)+,R3 ;RESTORE R3
4317 025570 000207 RTS PC ;RETURN

```

:ROUTINE TO GET THE DRIVE I.D. FROM THE OPERATOR

```

4320 025572 010546 GETID: MOV R5, -(SP) ;SAVE R5
4321 025574 005737 000042 TST 42 ;UNDER MONITOR CONTROL ?
4322 025600 001036 BNE 2$ ;BR IF NOT
4323 025602 005037 001262 1$: CLR CFLAG ;CLEAR THE 'CONTROL C' FLAG
4324 025605 104401 052776 TYPE ,ENTDRV ;'ENTER DRV I.D.:'
4325 025612 005046 CLR -(SP) ;CLEAR THE STACK
4326 025614 111016 MOVB (RO), (SP) ;PUT THE DRIVE NUMBER ON THE STACK
4327 025616 104403 TYPOS ;TYPE 1 THE DRIVE NUMBER
4328 025620 002 .BYTE 2 ;TYPE 2 DIGITS
4329 025621 000 .BYTE 0 ;SUPPRESS LEADING ZEROS
4330 025622 104401 001165 TYPE ,$CR LF ;CR-LF
4331 025626 104411 RDLIN ;READ THE ENTRY
4332 025630 012605 MOV (SP)+,R5 ;GET THE ENTRY ADDRESS
4333 025632 005737 001262 TST CFLAG ;'CONTROL C' ENTERED ?
4334 025636 001361 BNE 1$ ;BR IF IT WAS
4335 025640 121527 000056 CMPB (R5), #'.' ;PERIOD ENTERED ?
4336 025644 001414 BEQ 2$ ;BR IF YES
4337 025646 112560 000224 MOVB (R5)+, $DRVID(RO) ;STORE THE I.D.
4338 025652 112560 000225 MOVB (R5)+, $DRVID+1(RO) ;STORE THE I.D.
4339 025656 112560 000226 MOVB (R5)+, $DRVID+2(RO) ;STORE THE I.D.
4340 025662 112560 000227 MOVB (R5)+, $DRVID+3(RO) ;STORE THE I.D.
4341 025666 112560 000230 MOVB (R5)+, $DRVID+4(RO) ;STORE THE I.D.
4342 025672 112560 000231 MOVB (R5)+, $DRVID+5(RO) ;STORE THE I.D.
4343 025676 012605 2$: MOV (SP)+,R5 ;RESTORE R5
4344 025700 000207 RTS PC ;RETURN

```

:ROUTINE TO GET THE ADDRESSES OF ANY BAD SECTORS (UP TO A MAX OF 16)

```

4349 025702 GETADR:
4350 025702 010146 MOV R1, -(SP) ;: FUS- R1 ON STACK
4351 025704 010246 MOV R2, -(SP) ;: PUSH R2 ON STACK
4352 025706 010346 MOV R3, -(SP) ;: PUSH R3 ON STACK
4353 025710 010446 MOV R4, -(SP) ;: PUSH R4 ON STACK
4354 025712 005737 000042 TST 42 ;UNDER MONITOR CONTROL ?
4355 025716 001012 BNE 14$ ;BR IF YES
4356 025720 005037 001262 14$: CLR CFLAG ;CLEAR 'CONTROL C' FLAG
4357 025724 104401 053064 TYPE ,ENTADR ;ENTER SECTOR ADDRESSES
4358 025730 005046 CLR -(SP) ;CLEAR THE STACK
4359 025732 111016 MOVB (RO), (SP) ;PUT THE DRIVE NUMBER ON THE STACK
4360 025734 104403 TYPOS ;TYPE THE DRIVE NUMBER
4361 025736 002 .BYTE 2 ;TYPE 2 DIGITS
4362 025737 000 .BYTE 0 ;SUPPRESS LEADING ZEROS
4363 025740 104401 001165 TYPE , $CR LF ;CR-LF
4364 025744 012703 000040 15$: MOV #32, R3 ;NUMBER OF LOCATIONS IN THE TABLE TO PRESET

```

4365	025750	012704	000124	MOV	#8DSEC,R4	;TABLE INCREMENT
4366	025754	060004		ADD	R0,R4	;BLOCK STARTING ADDRESS
4367	025756	012724	177777	1\$: MOV	#-1,(R4)+	;SET LOCATION TO 1'S
4368	025762	005303		DEC	R3	;DECREMENT TABLE SIZE COUNT
4369	025764	001374		BNE	1\$	;BR IF NOT FINISHED WITH TABLE
4370	025766	005737	000042	TST	42	;UNDER MONITOR CONTROL ?
4371	025772	001106		BNE	13\$	;BR IF YES
4372	025774	162704	000100	SUB	#64.,R4	;SET POINTER TO BEGINNING OF TABLE
4373	026000	012703	000020	MOV	#16.,R3	;NUMBER OF ADDRESSES IN TABLE
4374	026004	104411		2\$: RDLIN		;GET ADDRESS FROM OPERATOR
4375	026006	012601		MOV	(SP)+,R1	;TEXT POINTER
4376	026010	005737	001262	TST	CFLAG	; 'CONTROL C' ENTERED ?
4377	026014	001341		BNE	14\$	;BR IF IT WAS
4378	026016	013702	001350	MOV	CYLIMT,R2	;UPPER LIMIT OF INPUT
4379	026022	004537	027562	JSR	R5,CK.DIG	;CHECK THE DIGIT(S)
4380	026026	026170		12\$		;CARRIAGE RETURN ONLY ENTERED
4381	026030	026210		13\$		;PERIOD ONLY ENTERED
4382	026032	026170		12\$		;ILLEGAL INPUT
4383	026034	026045		4\$		;TERMINATED WITH A CARRIAGE RETURN
4384	026036	026052		5\$		;TERMINATED WITH A "."
4385	026040	026042		3\$		;TERMINATED WITH A ":"
4386	026042	010214		3\$: MOV	R2,(R4)	;CYLINDER ADDRESS
4387	026044	000461		BR	13\$	;EXIT, PERIOD ENTERED
4388	026046	010214		4\$: MOV	R2,(R4)	;CYLINDER ADDRESS
4389	026050	000442		3R	11\$	;FINISHED WITH THIS ADDRESS. 'CR' ENTERED
4390	026052	010214		5\$: MOV	R2,(R4)	;CYLINDER ADDRESS
4391	026054	013702	001346	MOV	TRKLMT,R2	;UPPER LIMIT OF INPUT
4392	026060	004537	027562	JSR	R5,CK.DIG	;CHECK THE DIGIT(S)
4393	026064	026170		12\$		;CARRIAGE RETURN ONLY ENTERED
4394	026066	026210		13\$		;PERIOD ONLY ENTERED
4395	026070	026170		12\$		;ILLEGAL INPUT
4396	026072	026106		7\$		;TERMINATED WITH A CARRIAGE RETURN
4397	026074	026114		8\$		;TERMINATED WITH A "."
4398	026076	026100		6\$		;TERMINATED WITH A ":"
4399	026100	110264	000003	6\$: MOVB	R2,3(R4)	;TRACK ADDRESS
4400	026104	000441		BR	13\$	;EXIT, ENTRY TERMINATED BY PERIOD
4401	026106	110264	000003	7\$: MOVB	R2,3(R4)	;TRACK ADDRESS
4402	026112	000421		BR	11\$	;FINISHED WITH THIS ADDRESS. 'CR' ENTERED
4403	026114	110264	000003	8\$: MOVB	R2,3(R4)	;TRACK ADDRESS
4404	026120	013702	001344	MOV	SECLMT,R2	;UPPER LIMIT OF INPUT
4405	026124	004537	027562	JSR	R5,CK.DIG	;CHECK THE DIGIT(S)
4406	026130	026170		12\$		;CARRIAGE RETURN ONLY ENTERED
4407	026132	026210		13\$		;PERIOD ONLY ENTERED
4408	026134	026170		12\$		;ILLEGAL INPUT
4409	026136	026152		10\$		;TERMINATED WITH A CARRIAGE RETURN
4410	026140	026170		12\$		;TERMINATED WITH A "."
4411	026142	026144		9\$		;TERMINATED WITH A ":"
4412	026144	110264	000002	9\$: MOVB	R2,2(R4)	;SECTOR ADDRESS
4413	026150	000417		BR	13\$	;EXIT, ENTRY TERMINATED BY PERIOD
4414	026152	110264	000002	10\$: MOVB	R2,2(R4)	;SECTOR ADDRESS
4415	026156	005303		11\$: DEC	R3	;MORE ENTRIES ?
4416	026160	001413		BEQ	13\$	;BR IF NOT
4417	026162	062704	000004	ADD	#4,R4	;INCREMENT THE TABLE POINTER
4418	026166	005706		BR	2\$	;CONTINUE

```

4419 026170 012714 177777 12$: MOV # -1, (R4) ; CLEAR PRESENT TABLE ENTRY
4420 026174 012764 177777 000002 MOV # -1, 2(R4) ; CLEAR PRESENT TABLE ENTRY
4421 026202 104401 053214 TYPE ,BADENT ; 'INVALID ENTRY'
4422 026206 000676 BR 2$ ; TRY AGAIN
4423 026210 13$:
4424 026210 012604 MOV (SP)+, R4 ; POP STACK INTO R4
4425 026212 012603 MOV (SP)+, R3 ; POP STACK INTO R3
4426 026214 012602 MOV (SP)+, R2 ; POP STACK INTO R2
4427 026216 012601 MOV (SP)+, R1 ; POP STACK INTO R1
4428 026220 000207 RTS PC ; RETURN
4429
4430 ; PARAMETER ENTRY ROUTINE
4431 ; CALL
4432 ;
4433 ; MOV #ADR, R3 ; PARAMETER TABLE ADDRESS
4434 ; JSR PC, PARENT ; GET THE PARAMETERS
4435 026222 010346 PARENT: MOV R3, -(SP) ; SAVE THE PARAMETER TABLE ADDRESS
4436 026224 005037 001262 CLR CFLAG ; CLEAR THE 'CONTROL C' FLAG
4437 026230 012337 026240 1$: MOV (R3)+, 3$ ; ADDRESS OF PARAMETER NAME
4438 026234 001442 BEQ 9$ ; BR IF AT END OF TABLE
4439 026236 104401 TYPE ; TYPE THE PARAMETER NAME
4440 026240 000000 3$: .WORD 0 ; ADDRESS OF PARAMETER NAME TEXT
4441 026242 012302 MOV (R3)+, R2 ; MAXIMUM PARAMETER VALUE
4442 026244 012305 MOV (R3)+, R5 ; ADDRESS OF PARAMETER
4443 026246 011546 MOV (R5), -(SP) ; CURRENT VALUE OF PARAMETER
4444 026250 104405 TYPDS ; TYPE THE CURRENT VALUE OF THE PARAMETER
4445 026252 104401 053514 TYPE ,SLASH /
4446 026256 104411 ROLIN ; READ THE KEYBOARD
4447 026260 012601 MOV (SP)+, R1 ; INPUT ASCII STRING ADDRESS
4448 026262 005737 001262 TST CFLAG ; 'CONTROL C' ENTERED ?
4449 026266 001021 BNE 8$ ; BR IF IT WAS
4450 026270 004537 027562 JSR R5, CK.DIG ; CHECK THE DIGIT(S)
4451 026274 026230 1$ ; CARRIAGE RETURN ONLY ENTERED
4452 026276 026342 9$ ; PERIOD ONLY ENTERED
4453 026300 026314 6$ ; ILLEGAL INPUT
4454 026302 026310 5$ ; TERMINATED WITH A CARRIAGE RETURN
4455 026304 026314 6$ ; TERMINATED WITH A "."
4456 026306 026326 7$ ; TERMINATED WITH A "'"
4457 026310 010215 5$: MOV R2, (R5) ; MOVE NEW VALUE TO PARAMETER LOCATION
4458 026312 000746 BR 1$ ; GET MORE PARAMETERS
4459 026314 104401 053214 6$: TYPE ,BADENT ; 'BAD ENTRY'
4460 026320 162703 000006 SUB #6, R3 ; DECREMENT THE TABLE POINTER
4461 026324 000741 BR 1$ ; TRY AGAIN
4462 026326 010215 7$: MOV R2, (R5) ; NEW VALUE
4463 026330 000404 BR 9$ ; EXIT
4464 026332 005037 001262 8$: CLR CFLAG ; CLEAR THE 'CONTROL C' FLAG
4465 026336 011603 MOV (SP), R3 ; RELOAD THE PARAMETER TABLE ADDRESS
4466 026340 000733 BR 1$ ; TRY AGAIN
4467 026342 005726 9$: TST (SP)+ ; CORRECT THE STACK POINTER
4468 026344 000207 RTS PC ; RETURN
4469
4470 ; TYPEOUT ASSIGN/DEASSIGN ERROR MESSAGE
4471 ; CALL
4472 ; MOV #MESADR, ASNMSG ; ERROR MESSAGE ADDRESS
    
```

```

4473      :      JSR      PC,ASNERR
4474      :      RETURN
4475
4476      026346 104401 052725      ASNERR: TYPE .QUES      ;QUESTION MARK
4477      026352 104401 052076      TYPE      .UNTMSG     ;TYPE 'DRIVE'
4478      026356 010446      MOV      R4,-(SP)     ;SAVE R4 FOR TYPEOUT
4479
4480      026360 104403      TYPOS
4481      026362      002      .BYTE      2      ;GO TYPE--OCTAL ASCII
4482      026363      000      .BYTE      0      ;TYPE 2 DIGIT(S)
4483      026364 104401      TYPE
4484      026366 000000      ASNMSG: .WORD      0      ;SUPPRESS LEADING ZEROS
4485      026370 104401 001165      TYPE      $CRLF     ;TYPE SPECIFIC MESSAGE
4486      026374 000207      RTS      PC      ;MESSAGE ADDRESS
4487
4488      ;DEASSIGN DRIVE IF A FATAL ERROR OCCURS
4489      ;CALL
4490
4491      :      JSR      PC,DROP
4492      :      RETURN
4493
4494      026376 005004      DROP:  CLR      R4      ;CLEAR R4 FOR DRIVE NUMBER
4495      026400 111004      MOV      (R0),R4     ;MOVE DRIVE NUMBER TO R4
4496      026402 146437 033236 001442      BICB    ATABIT(R4),ASNLS1 ;REMOVE DRIVE FROM ASSIGNED LIST
4497      026410 006304      ASL      R4      ;MAKE DRIVE NUMBER INTO A TABLE INDEX
4498      026412 010064 001444      MOV      R0,DUNIT(R4) ;PUT DRIVE IN DROP LIST
4499      026416 104401 001165      TYPE      $CRLF
4500      026422 104401 001165      TYPE      $CRLF
4501      026426 104401 052500      TYPE      ,DROPNQ     ;TYPE 'DROPPING DRIVE'
4502      026432 104401 052611      TYPE      ,DRNUM     ;'DRIVE #'
4503      026436 006204      ASR      R4      ;DRIVE NUMBER
4504      026440 010446      MOV      R4,-(SP)   ;SAVE R4 FOR TYPEOUT
4505
4506      026442 104403      TYPOS
4507      026444      002      .BYTE      2      ;TYPE 2 DIGIT(S)
4508      026445      000      .BYTE      0      ;SUPPRESS LEADING ZEROS
4509      026446 104401 001165      TYPE      $CRLF
4510      026452 000207      RTS      PC
4511
4512      ;ROUTINE TO DEASSIGN DRIVE IF ERRORS BECOMES EXCESSIVE
4513      026454 032777 000020 152456      ABNAML: BIT      #SW04,$SWR ;SEE IF SWITCH 4 SET
4514      026462 001006      BNE
4515      026464 023760 001366 000056      CMP      MAXER,$TOTAL(R0) ;CHECK TOTAL ERROR VALUE
4516      026472 103002      BHIS    1$      ;BR IF ERRORS DONOT EXCEED MAX
4517      026474 000137 026376      JMP      DROP      ;DEASSING THE DRIVE
4518      026500 000207      1$:    RTS      PC      ;RETURN
4519
4520      ;ROUTINE TO CHECK FOR END OF PASS AND END OF TEST
4521
4522      026502 005737 001410      EOP:   TST      ENDET   ;END OF PASS DETERMINED BY SEEKS OR WORDS ?
4523      026506 001412      BEQ
4524      026510 026037 000054 001354      CMP      $READ+2(R0),ENDCON+2 ;CHECK MSW OF WORDS READ COUNT
4525      026516 101017      BHI
4526      026520 103405      BLO     EOP1      ;BR IF MSW GREATER THAN LIMIT
                    ;BR IF MSW LESS THAN LIMIT
    
```

# H10

4527	026522	026037	000052	001352		CMP	\$READ(RO),ENDCON	;CHECK LSW AGAINST LIMIT
4528	026530	103012				BHIS	EOP2	;BR IF EQUAL OR GREATER
4529	026532	000510				BR	EOPX	;EXIT
4530	026534	026037	000044	001360	EOP1:	CMP	\$POSIT+2(RO),ENDSEK+2	;CHECK MSW OF SEEK COUNT
4531	026542	101005				BHI	EOP2	;BR IF MSW GREATER THAN LIMIT
4532	026544	103503				BLO	EOPX	;EXIT IF MSW LESS THAN LIMIT
4533	026546	026037	000042	001356		CMP	\$POSIT(RO),ENDSEK	;CHECK LSW OF SEEK COUNT
4534	026554	103477				BLO	EOPX	;EXIT IF LSW LESS THAN LIMIT
4535	026556	104401	001165		EOP2:	TYPE	,\$CRLF	;CR-LF
4536	026562	104401	052534			TYPE	,ENDPAS	;END OF PASS FOR THE DRIVE
4537	026566	016046	000070			MOV	\$PASSC(RO) -(SP)	;PUT PASS COUNT ON THE STACK
4538	026572	104405				TYPDS		;CONVERT PASS COUNT TO DECIMAL AND TYPE IT
4539	026574	111037	001246			MOV	(RO),UNIT	;STORE THE DRIVE NUMBER
4540	026600	032777	000020	152332		BIT	#SW04,ASWR	;SWITCH 4 SET ?
4541	026606	001017				BNE	1\$	;BR IF SET
4542	026610	026037	000070	001362		CMP	\$PASSC(RO),PASCNT	;SEE IF AT END OF TEST
4543	026616	103413				BLO	1\$	;BR IF NOT
4544	026620	104401	052550			TYPE	,ENDTST	;TYPE 'END OF TEST'
4545	026624	104401	052611			TYPE	,DRNUM	; 'DRIVE #'
4546	026630	013746	001246			MOV	UNIT,-(SP)	;SAVE UNIT FOR TYPEOUT
4547								;TYPE DRIVE NUMBER
4548	026634	104403				TYPOS		;GO TYPE--OCTAL ASCII
4549	026636	002				.BYTE	2	;TYPE 2 DIGIT(S)
4550	026637	000				.BYTE	0	;SUPPRESS LEADING ZEROS
4551	026640	104401	001165			TYPE	,\$CRLF	;CR-LF
4552	026644	000431				BR	3\$	;DEASSIGN THE DRIVE
4553	026646	104401	052611		1\$:	TYPE	,DRNUM	; 'DRIVE #'
4554	026652	013746	001246			MOV	UNIT,-(SP)	;SAVE UNIT FOR TYPEOUT
4555								;TYPE DRIVE NUMBER
4556	026656	104403				TYPOS		;GO TYPE--OCTAL ASCII
4557	026660	002				.BYTE	2	;TYPE 2 DIGIT(S)
4558	026661	000				.BYTE	0	;SUPPRESS LEADING ZEROS
4559	026662	104401	001165			TYPE	,\$CRLF	;CR-LF
4560	026666	004737	022626			JSR	PC,TYPEST	;TYPE THE DRIVE'S STATISTICS
4561	026672	010346				MOV	R3,-(SP)	;SAVE R3
4562	026674	010446				MOV	R4,-(SP)	;SAVE R4
4563	026676	010004				MOV	RO,R4	;DRIVE'S BLOCK ADDRESS
4564	026700	062704	000036			ADD	#\$OPERC,R4	;ADD THE STARTING ADDR OF SECTIONS TO CLEAR
4565	026704	012703	000010			MOV	#8.,R3	;NUMBER OF LOCNS TO BE CLEARED
4566								; (ERROR COUNTERS NOT CLEARED)
4567	026710	005024			2\$:	CLR	(R4)+	;CLEAR THE LOCN
4568	026712	005303				DEC	R3	;DECREMENT THE LOCATION COUNTER
4569	026714	001375				BNE	2\$	;BR IF MORE TO GO
4570	026716	012604				MOV	(SP)+,R4	;RESTORE R4
4571	026720	012603				MOV	(SP)+,R3	;RESTORE R3
4572	026722	005260	000070			INC	\$PASSC(RO)	;INCREMENT THE PASS COUNT
4573	026726	000412				BR	EOPX	;EXIT
4574	026730	104401	001165		3\$:	TYPE	,\$CRLF	
4575	026734	005004				CLR	R4	;CLEAR R4 FOR DRIVE NUMBER
4576	026736	111004				MOV	(RO),R4	;MOVE DRIVE NUMBER
4577	026740	146437	033236	001442		BICB	ATABIT(R4),ASNLST	;DELETE DRIVE FROM ASSIGNED LIST
4578	026746	006304				ASL	R4	;MAKE DRIVE NUMBER INTO TABLE INDEX
4579	026750	010064	001444			MOV	RO,DUNIT(R4)	;PUT BLOCK ADDRESS INTO DROP LIST
4580	026754	000207			EOPX:	RTS	PC	;RETURN

```

4581
4582      ;ROUTINE TO GET THE REMAINDER OF THE RANDOM NUMBER
4583      ;CALL
4584      ;
4585      ;
4586      ;
4587      ;
4588      ;
4589      ;
4590      ;
4591      ;
4592      ;
4593      ;
4594      ;
4595      ;
4596      ;
4597      ;
4598      ;
4599      ;
4600      ;
4601      ;
4602      ;
4603      ;
4604      ;
4605      ;
4606      ;
4607      ;
4608      ;
4609      ;
4610      ;
4611      ;
4612      ;
4613      ;
4614      ;
4615      ;
4616      ;
4617      ;
4618      ;
4619      ;
4620      ;
4621      ;
4622      ;
4623      ;
4624      ;
4625      ;
4626      ;
4627      ;
4628      ;
4629      ;
4630      ;
4631      ;
4632      ;
4633      ;
4634      ;

```

026756	013746	032402	GETREM:	MOV	\$LONUM, -(SP)	; STORE RANDOM NUMBER ON THE STACK FOR DIVIDE
026762	013746	032400		MOV	\$HINUM, -(SP)	; UPPER PART
026766	010546			MOV	R5, -(SP)	; PUT THE DIVISOR ONTO THE STACK
026770	004737	027004		JSR	PC, LINKDV	; DIVIDE THE RANDOM NUMBERS
026774	012605			MOV	(SP)+, R5	; PUT THE REMAINDER INTO R5
026776	005726			TST	(SP)+	; ADJUST THE STACK POINTER
027000	000240			NOP		; FOR DEBUGGING HALT
027002	000207			RTS	PC	

```

;LINK ROUTINE TO THE DIVISION UTILITY SUBROUTINE
; THIS ROUTINE ALLOWS THE 'SYSMAC' DIVIDE ROUTINE
; CALLING SEQUENCE TO BE USED
LINKDV: SAVREG      ; STORE R0 - R5
MOV      26(SP), R5 ; DIVISOR
CLR      R4         ; OTHER DIVISOR WORD
MOV      30(SP), R2 ; UPPER DIVIDEND WORD
MOV      32(SP), R3 ; LOWER DIVIDEND WORD
CLR      R0         ; CLEAR OTHER DIVIDEND REGISTERS
CLR      R1
CLR      R1
JSR      PC, M.DPID ; GO TO THE DIVIDE ROUTINE
MOV      R1, 30(SP) ; REMAINDER ON THE STACK
MOV      R3, 32(SP) ; QUOTIENT ON THE STACK
RESREG
MOV      (SP)+, (SP) ; RESTORE R0 - R5
RTS      PC         ; MOVE RETURN UP THE STACK

; DIVISION UTILITY SUBROUTINE
; R0-R1-R2-R3=DIVIDEND
; R4-R5=DIVISOR
; R0-R1=REMAINDER AFTER DIVISION
; R2-R3=QUOTIENT AFTER DIVISION
; ENTER WITH JSR PC, M.DPID
M.DPID: MOV      #40, -(SP) ; COUNTER FOR DIVISION CYCLES
MOV      R4, -(SP)        ; HIGH ORDER
MOV      R5, -(SP)        ; LOW ORDER DIVISOR TO THE STACK
NEG      2(SP)            ; JRM NEGATIVE
NEG      2SP              ; INVERSION OF THE DIVISOR
SBC      2(SP)
ADD      2SP, R1
ADC      R0                ; PERFORM THE INITIAL SUBTRACTION
ADD      2(SP), R0
BCS      M.DP50           ; IF CARRY THEN OVERFLOW HAS OCCURRED
CLR      -(SP)           ; THIS IS A LONGER LASTING CARRY BIT
M.DP40: ROL      R3
ROL      R2

```

```

4635 027114 006101      ROL    R1
4636 027116 006100      ROL    R0
4637 027120 005716      TST    QSP
4638 027122 001410      BEQ    M.DP41      ;TEST "CARRY" INDICATOR
4639 027124 005016      CLR    QSP          ;IF NO "CARRY" THEN ADD ELSE SUBTRACT
4640 027126 066601 000002  ADD    2(SP),R1    ;CLEAR UP FOR NEXT TIME
4641 027132 005500      ADC    R0          ;ADD -(DIVISOR)
4642 027134 005516      ADC    QSP          ;SET "CARRY"
4643 027136 066600 000004  ADD    4(SP),R0;<- I
4644 027142 000404      BR     M.DP42
4645 027144 060501      M.DP41: ADD    R5,R1
4646 027146 005500      ADC    R0          ;ADD +(DIVISOR)
4647 027150 005516      ADC    QSP          ;SET "CARRY"
4648 027152 060400      ADD    R4,R0      ;<-
4649 027154 005516      M.DP42: ADC    QSP
4650 027156 005716      TST    QSP          ;SET "CARRY"
4651 027160 001401      BEQ    .+4      ;TEST THE UPDATE INDICATOR
4652 027162 005203      INC    R3      ;IF ZERO FORGET IT
4653 027164 005366 000006  DEC    6(SP)      ;NO CARRY POSSIBLE HERE
4654 027170 003347      BGT    M.DP40      ;DECREMENT COUNTER
4655 027172 006003      ROR    R3          ;BRANCH IF MORE TO DO
4656 027174 103404      BCS    M.DP44
4657 027176 060501      ADD    R5,R1
4658 027200 005500      ADC    R0
4659 027202 060400      ADD    R4,R0
4660 027204 000241      CLC
4661 027206 006103      M.DP44: ROL    R3
4662 027210 062706 000010  ADD    #10,SP      ;ADJUST STACK BY 4 WORDS
4663 027214 000242      CLV
4664 027216 000207      RTS    PC
4665 027220 062706 000006  M.DP50: ADD    #6,SP
4666 027224 000262      SEV
4667 027226 000207      RTS    PC
4668
4669
4670      ;ROUTINE TO REPLACE LEADING ZEROS IN A NUMERIC STRING WITH SPACES
4671      ;CALL
4672      ;
4673      ;      MOV    #ADR, -(SP)      ;ADDRESS OF NUMBER (IN ASCII)
4674      ;      JSR    R5,REPLZ
4675      ;      .WORD  N      ;'N' IS NUMBER OF DIGITS TO BE TYPED
4676 027230 010046      REPLZ: MOV    R0, -(SP)      ;SAVE R0
4677 027232 012746 000012  MOV    #10, -(SP)      ;MAXIMUM NUMBER OF DIGITS TO BE TYPED
4678 027236 162516      SUB    (R5)+, (SP)      ;SUBTRACT DIGITS TO FORM INDEX
4679 027240 016600 000006  MOV    6(SP), R0      ;ADDRESS OF NUMBER TO R0
4680 027244 122710 000060  1$:  CMPB  #'0', (R0)      ;BYTE EQUAL TO ASCII '0' ?
4681 027250 001004      BNE    2$
4682 027252 112710 000040  MOVB  #40, (R0)      ;REPLACE THE ZERO WITH A SPACE
4683 027256 005200      INC    R0          ;INCREMENT THE BYTE ADDRESS
4684 027260 000771      BR     1$          ;GO BACK AND LOOK FOR MORE LEADING ZEROS
4685 027262 105710      2$:  TSTB  (R0)
4686 027264 001003      BNE    3$
4687 027266 005300      DEC    R0          ;SEE IF ZERO BYTE TERMINATOR
4688 027270 112710 000060  MOVB  #'0', (R0)      ;BR IF NOT
                        ;BACKUP STRING POINTER
                        ;PUT A ZERO BACK IN
    
```

```

4689 027274 016637 000006 027310 3$: MOV 6(SP),4$ ;PUT ADDRESS IN LOCATION FOR TYPEOUT
4690 027302 062637 027310 ADD (SP)+,4$ ;BEGINNING OF SIGNIFICANT DIGITS
4691 027306 104401 TYPE ;TYPE THE NUMBER
4692 027310 000000 4$: .WORD 0 ;ADDRESS OF NUMBER
4693 027312 012600 MOV (SP)+,RO ;RESTORE RO
4694 027314 012616 MOV (SP)+,(SP) ;MOVE RETURN ADDRESS
4695 027316 000205 RTS RS ;RETURN
4696
4697 ;TYPE NUMERICAL ASCIZ STRING SUPPRESS LEADING ZEROS
4698
4699 ;CALL
4700 ; MOV #NUMADR, -(SP) ;FIRST ADDRESS OF ASCIZ STRING
4701 ; JSR PC,$SUPRS
4702
4703 027320 010046 $$SUPRS: MOV RO, -(SP) ;SAVE RO
4704 027322 016500 000004 MOV 4(SP),RO ;PICKUP THE POINTER
4705 027326 105710 1$: TSTB (RO) ;TERMINATOR ?
4706 027330 001403 BEQ 2$ ;BR IF YES
4707 027332 122720 000060 CMPB #'0,(RO)+ ;IS THIS AN ASCII '0' ?
4708 027336 001773 BEQ 1$ ;BR IF YES
4709 027340 005300 2$: DEC RO ;BACKUP BY '1'
4710 027342 010037 027350 MOV RO,3$ ;SAVE FOR TYPING
4711 027346 104414 DISPLY ;GO PRINT
4712 027350 000000 3$: .WORD 0 ;ASCIZ POINTER GOES HERE
4713 027352 012600 MOV (SP)+,RO ;RESTORE RO
4714 027354 012616 MOV (SP)+,(SP) ;RESTORE THE STACK
4715 027356 000207 RTS PC ;RETURN
4716
4717 ;ROUTINE TO TYPE AT PRIORITY 4
4718
4719 027360 013746 177776 177776 TYPRI4: MOV @#PS, -(SP) ;SAVE THE PRESENT STATUS
4720 027364 012737 000200 MOV #200,@#PS ;CHANGE THE PRIORITY TO 4
4721 027372 012537 027402 MOV (RS)+,1$ ;MESSAGE ADDRESS
4722 027376 004737 030752 JSR PC,$TYPE ;TYPE THE MESSAGE
4723 027402 000000 1$: .WORD 0 ;MESSAGE ADDRESS GOES HERE
4724 027404 000205 RTS RS ;RETURN
4725
4726 ;ROUTINE TO TYPE ERRORS
4727 ;CALL
4728 ; DISPLY ;MUST DEFINED IN 'TRAP' TABLE
4729 ; MESADR ;ADDRESS OF MESSAGE
4730 ; RETURN
4731
4732 027406 032777 020000 151524 $DSPLY: BIT #BIT13,@SWR ;INHIBIT ERROR TYPEOUT ?
4733 027414 001004 BNE 1$ ;BR IF YES
4734 027416 005037 177776 CLR @#PS ;SET PRIORITY TO ZERO
4735 027422 000137 030752 JMP $TYPE ;TYPE THE MESSAGE
4736 027426 062716 000002 1$: ADD #2,(SP) ;INCREMENT THE RETURN
4737 027432 000002 RTI ;RETURN
4738
4739 ;THIS ROUTINE IS USED TO CHECK IF AN
4740 ;ASCII CHARACTER IS A DIGIT BETWEEN 0 AND 7.
4741 ;CALL
4742 ; MOV #ADR,R1 ;ADDRESS OF ASCII CHARACTER

```



```

4743      :      JSR      R5,CK.OCT      ;CHECK THE CHARACTER
4744      :      RETURN1    ;CHARACTER IS NOT BETWEEN 0-7
4745      :      RETURN2    ;CHARACTER IS IN R2 AS A
4746      :      :          ;OCTAL DIGIT
4747      :
4748 027434 121127 000060  CK.OCT:  CMPB      (R1),#'0      ;LESS THAN ZERO?
4749 027440 103407          SLO        1$          ;YES -- BRANCH
4750 027442 121127 000067          CMPB      (R1),#'7      ;GREATER THAN SEVEN?
4751 027446 101004          BHI        1$          ;YES -- BRANCH
4752 027450 111102          MOVB      (R1),R2      ;GET THE CHARACTER
4753 027452 042702 177770          BIC      #'07,R2      ;STRIP AWAY THE ASCII
4754 027456 005725          TST      (R5)+       ;ADJUST FOR RETURN
4755 027460 000205          1$:      RTS        R5          ;RETURN
4756
4757      :THIS ROUTINE IS USED TO CHECK AN ASCII CHARACTER
4758      :AND DETERMINE IF IT IS A DIGIT BETWEEN 0 AND 9.
4759      :CALL
4760      :      MOV      #ADR,R1      ;ADDRESS OF ASCII CHARACTER
4761      :      JSR      R5,CK.DEC      ;CHECK THE CHARACTER
4762      :      RETURN1    ;NOT BETWEEN 0 AND 9
4763      :      RETURN2    ;BETWEEN 0 AND 9
4764      :      :          ;R2 = DIGIT
4765      :
4766 027462 121127 000060  CK.DEC:  CMPB      (R1),#'0      ;LESS THAN ZERO?
4767 027466 103407          BLO        1$          ;YES -- BRANCH
4768 027470 121127 000071          CMPB      (R1),#'9      ;GREATER THAN NINE?
4769 027474 101004          BHI        1$          ;YES -- BRANCH
4770 027476 111102          MOVB      (R1),R2      ;GET THE CHARACTER
4771 027500 042702 000060          BIC      #'0,R2      ;STRIP AWAY THE ASCII
4772 027504 005725          TST      (R5)+       ;ADJUST FOR RETURN
4773 027506 000205          1$:      RTS        R5          ;RETURN
4774
4775      :THIS ROUTINE WILL CHECK AN ASCII CHARACTER TO
4776      :DETERMINE WHAT IT IS.
4777      :CALL
4778      :      MOV      #ADR,R1      ;ADDRESS OF ASCII CHARACTER
4779      :      JSR      R5,CK.CHR      ;CHECK CHARACTER
4780      :      RETURN    ADR1      ;UNKNOWN CHARACTER
4781      :      RETURN    ADR2      ;CARRIAGE RETURN * (R1)=ADR+1
4782      :      RETURN    ADR3      ;COMMA * (R1)=ADR+1
4783      :      RETURN    ADR4      ;PERIOD * (R1)=ADR+1
4784      :      RETURN    ADR5      ;DIGIT BETWEEN 0 AND 7.
4785      :      RETURN    ADR6      ;DIGIT BETWEEN 8 AND 9.
4786      :      :          ;R2 = DIGIT * (R1)=ADR+1
4787      :
4788 027510 105711          CK.CHR:  TSTB      (R1)      ;"CARRIAGE RETURN"?
4789 027512 001417          BEQ      3$          ;YES -- BRANCH
4790 027514 121127 000054          CMPB      (R1),#'.      ;"COMMA"?
4791 027520 001413          BEQ      2$          ;YES -- BRANCH
4792 027522 121127 000056          CMPB      (R1),#'.      ;"PERIOD"?
4793 027526 001407          BEQ      1$          ;YES -- BRANCH
4794 027530 004537 027462          JSR      R5,CK.DEC      ;"DIGIT"?
4795 027534 000410          BR       4$          ;NO -- BRANCH
4796 027536 004537 027434          JSR      R5,CK.OCT      ;OCTAL ?
    
```

# M10

```

4797 027542 005725      TST      (R5)+      ;DIGIT BETWEEN 8-9
4798 027544 005725      TST      (R5)+      ;DIGIT BETWEEN 0-7
4799 027546 005725      1$: TST      (R5)+      ;PERIOD
4800 027550 005725      2$: TST      (R5)+      ;COMMA
4801 027552 005725      3$: TST      (R5)+      ;CARRIAGE RETURN
4802 027554 005201      INC      R1          ;MOVE POINTER TO NEXT CHARACTER
4803 027556 011505      4$: MOV      (R5),R5    ;UNKNOWN CHARACTER
4804 027560 000205      RTS       R5        ;RETURN
4805
4806
4807      ; THIS ROUTINE CHECKS AN ASCII STRING FOR LEGAL
4808      ; CHARACTERS AND FORMS A DECIMAL VALUE BINARY NUMBER IN R2.
4809      CALL
4810      MOV      #ADR,R1      ; ADDRESS OF ASCIZ STRING
4811      MOV      #NUM,R2      ; MAX. MAGNITUDE OF INPUT NUMBER
4812      JSR      R5,CK.DIG    ; CHECK DIGITS
4813      RETURN   ADR1         ; "CR" ONLY ENTERED -- R2=0
4814      RETURN   ADR2         ; "PERIOD" ONLY ENTERED -- R2=0
4815      RETURN   ADR3         ; ILLEGAL CHARACTER OR INPUT TOO LARGE -- R2=?
4816      RETURN   ADR4         ; "CR" -- R2 = NUMBER
4817      RETURN   ADR5         ; "COMMA" -- R2 = NUMBER
4818      RETURN   ADR6         ; "PERIOD" -- R2 = NUMBER
4819 027562 010446      CK.DIG: MOV      R4,-(SP)    ; SAVE R4
4820 027564 010346      MOV      R3,-(SP)    ; SAVE R3
4821 027566 010246      MOV      R2,-(SP)    ; SAVE THE MAX. SIZE ON THE STACK
4822 027570 005002      CLR      R2          ; START WITH 0
4823 027572 005003      CLR      R3
4824 027574 005004      CLR      R4
4825 027576 004537      JSR      R5,CK.CHR    ; CHECK ONE CHARACTER
4826 027602 027676      6$:      ; ILLEGAL CHARACTER
4827 027604 027704      9$:      ; CARRIAGE RETURN
4828 027606 027676      6$:      ; " "
4829 027610 027700      7$:      ; " "
4830 027612 027616      1$:      ; DIGIT 0-7
4831 027614 027616      1$:      ; DIGIT 8-9
4832 027616 062705      1$: ADD      #4,R5      ; STEP RETURN POINTER PAST "CR" & "PERIOD" RETURNS
4833 027622 006303      2$: ASL      R3        ; INPUT NUMBER *2
4834 027624 010346      MOV      R3,-(SP)    ; SAVE *2
4835 027626 006303      ASL      R3          ; *4
4836 027630 006303      ASL      R3          ; *8
4837 027632 062603      ADD      (SP)+,R3    ; (*2)+(*8) = *10
4838 027634 060203      ADD      R2,R3      ; UPDATE THE INPUT NUMBER
4839 027636 004537      JSR      R5,CK.CHR    ; CHECK ONE CHARACTER
4840 027642 027702      8$:      ; ILLEGAL CHARACTER
4841 027644 027666      5$:      ; CARRIAGE RETURN
4842 027646 027664      4$:      ; " "
4843 027650 027656      3$:      ; " "
4844 027652 027622      2$:      ; DIGIT 0-7
4845 027654 027622      2$:      ; DIGIT 8-9
4846 027656 105711      3$: TSTB     (R1)      ; DOES A "CR" FOLLOW THE "PERIOD"
4847 027660 001010      BNE     8$          ; BR IF NOT
4848 027662 005724      TST      (R4)+      ; INCREMENT THE RETURN
4849 027664 005724      4$: TST      (R4)+      ; INCREMENT THE RETURN
4850 027666 005724      5$: TST      (R4)+      ; INCREMENT THE RETURN

```

```

4851 027670 020316      CMP      R3,(SP)      ;CHECK THE MAGNITUDE OF THE NUMBER
4852 027672 101004      BHI      9$          ;BR IF ENTERED NUMBER TOO LARGE
4853 027674 000402      BR       9$          ;BYPASS INCREMENT
4854 027676 005725      6$:     TST      (R5)+  ;INCREMENT RETURN PAST INVALID RETURN
4855 027700 005725      7$:     TST      (R5)+  ;INCREMENT RETURN
4856 027702 060405      8$:     ADD      R4,R5  ;SETUP RETURN POINTER
4857 027704 010302      9$:     MOV      R3,R2  ;ENTERED VALUE
4858 027706 005726      TST      (SP)+      ;CLEAN MAX. SIZE OFF OF STACK
4859 027710 012603      MOV      (SP)+,R3   ;RESTORE R3
4860 027712 012604      MOV      (SP)+,R4   ;RESTORE R4
4861 027714 011505      MOV      (R5),R5    ;GET RETURN ADDRESS
4862 027716 000205      RTS      R5         ;RETURN
4863
4864 ;THIS ROUTINE WILL CONVERT A 16-BIT UNSIGNED BINARY NUMBER TO AN
4865 ;UNSIGNED DECIMAL ASCIZ NUMBER.
4866 ;CALL
4867 ;
4868 ;
4869 ;
4870 ;
4871 ;NOTE: THE PROGRAM REQUIRES THIS FORM OF '$SB2D', NOT THE VERSION ON
4872 ;THE SYSMAC LIBRARY, REV C AND LATER
4873
4874 027720 016637 000002 027744 $SB2D: MOV      2(SP),1$      ;SAVE THE BINARY NUMBER
4875 027726 012746 027744      MOV      #1$,-(SP)   ;SET THE POINTER
4876 027732 004737 032500      JSR      PC,$DB2D    ;CALL THE DOUBLE LENGTH CONVERT
4877 027736 012666 000002      MOV      (SP)+,2(SP) ;PICKUP THE POINTER
4878 027742 000207      RTS      PC          ;RETURN
4879 027744 000000 000000      1$:     .WORD    0,0
4880
4881 ;THIS ROUTINE WILL CONVERT A 16-BIT UNSIGNED BINARY NUMBER TO AN
4882 ;UNSIGNED OCTAL ASCIZ NUMBER.
4883 ;CALL
4884 ;
4885 ;
4886 ;
4887 ;
4888 ;NOTE: THE PROGRAM REQUIRES THIS FORM OF '$SB2D', NOT THE VERSION ON
4889 ;THE SYSMAC LIBRARY, REV C AND LATER
4890
4891 027750 016637 000002 027774 $SB2D: MOV      2(SP),1$      ;SAVE THE BINARY NUMBER
4892 027756 012746 027774      MOV      #1$,-(SP)   ;SET THE POINTER
4893 027762 004737 032674      JSR      PC,$DB2D    ;CALL THE DOUBLE LENGTH CONVERT
4894 027766 012666 000002      MOV      (SP)+,2(SP) ;PICKUP THE POINTER
4895 027772 000207      RTS      PC          ;RETURN
4896 027774 000000 000000      1$:     .WORD    0,0
4897
4898 ;KEYBOARD INTERRUPT INITIALIZATION ROUTINE
4899 ;CALL
4900 ;
4901 ;
4902 ;
4903 030000 012737 030030 000060 $TKINT: MOV      #STKSRV,TKVEC ;SETUP VECTOR
4904 030006 012737 000240 000062      MOV      #PR5,TKVEC+2 ;PRIORITY TO 5
    
```

```

030014 J05777 151126 TST 2STKB :CLEAR THE BUFFER
030020 J12777 000100 15111E MOV 2BIT06,2STKS :SET INTERRUPT ENABLE
030026 000207 RTS PC :RETURN

:KEYBOARD INTERRUPT SERVICE ROUTINE
:CALL
: ENTER VIA INTERRUPT

STKSRV: RDCHR :READ THE KEYBOARD
MOV (SP)+,55 :GET THE CHARACTER
CMP 55,#3 :'CONTROL C' ?
BNE 15 :BR IF NOT
TYPE ,SCRLF :CR-LF
TYPE ,SCNTLC :'IC'
MOV 1-1,CFLAG :SET THE 'CONTROL C' FLAG
CLR 2STKS :CLEAR THE TTY INTERRUPT
BR 45 :
CMP SWR,#SWREG :SOFTWARE SWITCH REGISTER IN USE ?
BNE 35 :BR IF NOT
CMP 55,#7 :'CONTROL G' ?
BNE 35 :BR IF NOT
TYPE ,SCRLF :CR-LF
TYPE ,SCNTLG :'IG'
MOV PS-(SP) :PUT THE STATUS WORD ON THE STACK
MOVC 25-(SP) :RETURN ADDRESS
CLR 2STKS :CLEAR THE TTY INTERRUPT ENABLE
JMP 5GTSWR :GET THE SWITCH REGISTER ENTRY
MOV 2STKS :ENABLE TTY KEYBOARD INTERRUPT
BR 45 :EXIT
TYPE .55 :ECHO THE CHARACTER
RTI :RETURN

55: .WORD 0 :ENTERED CHARACTER

:THIS ROUTINE WILL INPUT A STRING FROM THE TTY
:CALL:
: RDIN :INPUT A STRING FROM THE TTY
: RETURN HERE :ADDRESS OF FIRST CHARACTER WILL BE ON THE STACK
: :TERMINATOR WILL BE A BYTE OF ALL 0'S

SRDLIN: MOV R3-(SP) :SAVE R3
CLR -(SP) :CLEAR THE RUBOUT KEY
15: MOV 2TTYIN,R3 :GET ADDRESS
25: CMP 2TTYIN+10..R3 :BUFFER FULL?
BLOS 45 :BR IF YES
RDCHR :GO READ ONE CHARACTER FROM THE TTY
MOV (SP)+,(R3) :GET CHARACTER
CMPB 2177,(R3) :IS IT A RUBOUT
BNE 55 :BR IF NO
TST (SP) :IS THIS THE FIRST RUBOUT?
BNE 65 :BR IF NO
MOV 2\,95 :TYPE A BACK SLASH
TYPE ,95 :
MOV 1-1,(SP) :SET THE RUBOUT KEY

```

```

4959 030234 J05303          55:  DEC      R3          ;BACKUP BY ONE
4960 030236 020327 030440  CMP      R3,#STTYIN ;STACK EMPTY?
4961 030242 03445  BLO     45          ;BR IF YES
4962 030244 111337 030436  MOVB   (R3),95      ;SETUP TO TYPEOUT THE DELETED CHAR.
4963 030250 104401 030436  TYPE   95          ;GO TYPE
4964 030254 000746  BR      25          ;GO READ ANOTHER CHAR.
4965 030256 005716          55:  TST   (SP)         ;RUBOUT KEY SET?
4966 030260 001406  BEQ    75          ;BR IF NO
4967 030262 112737 030134 030436  MOVB   #'\,95      ;TYPE A BACK SLASH
4968 030270 104401 030436  TYPE   95          ;
4969 030274 005016  CLR   (SP)         ;CLEAR THE RUBOUT KEY
4970 030276 122713 000025 75:  CMPB  #25,(R3)     ;IS CHARACTER A CTRL U?
4971 030302 001003  BNE   105         ;BR IF NO
4972 030304 104401 032246  TYPE   SCNTLU      ;TYPE A CONTROL "U"
4973 030310 000726  BR      15        ;GO START OVER
4974 030312 122713 000003 105:  CMPB  #3,(R3)     ;IS CHARACTER A CTRL C ?
4975 030316 001006  BNE   85          ;BR IF NOT
4976 030320 012737 177777 001252  MOV    #-1,CFLAG  ;SET CNTRL C FLAG
4977 030326 104401 030452  TYPE   SCNTLC      ;ECHO IT
4978 030332 000427  BR      115       ;EXIT
4979 030334 122713 000012 85:  CMPB  #12,(R3)    ;IS CHARACTER A "LF"?
4980 030340 001011  BNE   35          ;BRANCH IF NO
4981 030342 105013  CLRB  (R3)        ;CLEAR THE CHARACTER
4982 030344 104401 001165  TYPE   .SCRLF      ;TYPE A "CR" & "LF"
4983 030350 104401 020440  TYPE   STTYIN      ;TYPE THE INPUT STRING
4984 030354 000706  BR      25        ;GO PICKUP ANOTHER CHARACTER
4985 030356 104401 001164 45:  TYPE   .SQUES      ;TYPE A '?'
4986 030362 000701  BR      15        ;CLEAR THE BUFFER AND LOOP
4987 030364 111337 030436 35:  MOVB  (R3),95     ;ECHO THE CHARACTER
4988 030370 104401 030436  TYPE   95          ;
4989 030374 122723 000015  CMPB  #15,(R3)+   ;CHECK FOR RETURN
4990 030400 001274  BNE   25          ;LOOP IF NOT RETURN
4991 030402 105063 177777  CLRB  -1(R3)      ;CLEAR RETURN (THE 15)
4992 030406 104401 001166  TYPE   .SLF        ;TYPE A LINE FEED
4993 030412 005726 115:  TST   (SP)+       ;CLEAN RUBOUT KEY FROM THE STACK
4994 030414 012603  MOV    (SP)+,R3   ;RESTORE R3
4995 030416 011646  MOV    (SP)-,(SP) ;ADJUST THE STACK AND PUT ADDRESS OF THE
4996 030420 016666 000004 000002  MOV    4(SP),2(SP) ;FIRST ASCII CHARACTER ON IT
4997 030426 012766 030440 000004  MOV    #STTYIN,4(SP)
4998 030434 000002  RTI
4999 030436 000          95:  .BYTE  0          ;RETURN
5000 030437 000          .BYTE  0          ;STORAGE FOR ASCII CHAR. TO TYPE
5001 030440 000012 000          .BLKB  10         ;TERMINATOR
5002 030452 041536 005015 000  SCNTLC: .ASCIZ  ^C<<CR><LF> ;RESERVE 10 BYTES FOR TTY INPUT
5003
5004 030460 .EVEN ;CONTROL "C"
5005
5006
5007
5008
5009
5010
5011
5012

```

```

;*****
.SBTTL  MACRO ROUTINES
.SBTTL  ERROR HANDLER ROUTINE
;*****

```

ERRID.019

ERROR HANDLER ROUTINE

```

5001:
5002:
5003:
5004:
5005:
5006:
5007:
5008:
5009:
5010:
5011:
5012:
5013:
5014:
5015:
5016:
5017:
5018:
5019:
5020:
5021:
5022:
5023:
5024:
5025:
5026:
5027:
5028:
5029:
5030:
5031:
5032:
5033:
5034:
5035:
5036:
5037:
5038:
5039:
5040:
5041:
5042:
5043:
5044:
5045:
5046:
5047:
5048:
5049:
5050:
5051:
5052:
5053:
5054:
5055:
5056:
5057:
5058:
5059:
5060:
5061:
5062:
5063:
5064:
5065:
5066:

```

```

:*THIS ROUTINE WILL INCREMENT THE ERROR FLAG AND THE ERROR COUNT.
:*SAVE THE ERROR ITEM NUMBER AND THE ADDRESS OF THE ERROR CALL
:*AND GO TO $ERRTYP ON ERROR
:*THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
:*SW15=1      HALT ON ERROR
:*SW13=1      INHIBIT ERROR TYPEOUTS
:*SW10=1      BELL ON ERROR
:*CALL
:*          ERROR      N      ;;ERROR=EMT AND N=ERROR ITEM NUMBER

```

```

$ERROR:
          CKSWR          ;;TEST FOR CHANGE IN SOFT-SWR
          MOV            R3,ATTN      ;;SAVE THE ATTENTION REGISTER CONTENTS
          MOV            R1,DRIVE     ;;DRIVE NUMBER
          BIT            #SW13,$SWR   ;;INHIBIT PRINTOUTS ?
          BNE            .+6          ;;BR IF YES
          JSR            PC,$TIME     ;;TYPE THE TIME
          INCB           $ERFLG       ;;SET THE ERROR FLAG
          BEQ            7$           ;;DON'T LET THE FLAG GO TO ZERO
          MOV            $TSTNM,$DISP ;;DISPLAY TEST NUMBER AND ERROR FLAG
          BIT            #BIT10,$SWR  ;;BELL ON ERROR?
          BEQ            1$           ;;NO - SKIP
          TYPE           $BELL        ;;RING BELL
          INC            $ERTTL       ;;COUNT THE NUMBER OF ERRORS
          MOV            (SP),$ERRPC   ;;GET ADDRESS OF ERROR INSTRUCTION
          SUB            #2,$ERRPC
          MOVB           $ERRPC,$ITEMB ;;STRIP AND SAVE THE ERROR ITEM CODE
          BIT            #BIT13,$SWR  ;;SKIP TYPEOUT IF SET
          BNE            20$         ;;SKIP TYPEOUTS
          JSR            PC,$ERRTYP   ;;GO TO USER ERROR ROUTINE
          TYPE           , $CRLF

20$:
2$:      TST            $SWR          ;;HALT ON ERROR
          BPL            3$          ;;SKIP IF CONTINUE
          HALT           ;;HALT ON ERROR!
          CKSWR          ;;TEST FOR CHANGE IN SOFT-SWR

3$:      RTI                    ;;RETURN

```

.SBTTL ERROR MESSAGE TYPEOUT ROUTINE

```

;*****
;THIS ROUTINE USES THE "ITEM CONTROL BYTE" ($ITEMB) TO DETERMINE WHICH
;ERROR IS TO BE REPORTED. IT THEN OBTAINS, FROM THE "ERROR TABLE" ($ERRTB),
;AND REPORTS THE APPROPRIATE INFORMATION CONCERNING THE ERROR.

```

```

$ERRTYP:
          TYPE           $CRLF       ;; "CARRIAGE RETURN" & "LINE FEED"
          MOV            R0,-(SP)    ;;SAVE R0
          CLR            R0          ;;PICKUP THE ITEM INDEX
          BISB           2*$ITEMB,R0
          BNE            1$          ;;IF ITEM NUMBER IS ZERO, JUST
          MOV            $ERRPC,-(SP) ;;TYPE THE PC OF THE ERROR
          ;;SAVE $ERRPC FOR TYPEOUT

```

```

5067 030640 104402          TYP0C          ;; ERROR ADDRESS
5068 030642 000426          BR           6$          ;; GO TYPE--OCTAL ASCII(ALL DIGITS)
5069 030644 005300          1$: DEC        RO          ;; GET OUT
5070 030646 006300          ASL        RO          ;; ADJUST THE INDEX SO THAT IT WILL
5071 030650 006300          ASL        RO          ;; WORK FOR THE ERROR TABLE
5072 030652 006300          ASL        RO
5073 030654 062700 004006  ADD        $ERRTB,RO    ;; FORM TABLE POINTER
5074 030660 012037 030670  MOV        (RO)+,2$    ;; PICKUP "ERROR MESSAGE" POINTER
5075 030664 001404          BEQ        3$          ;; SKIP TYPEOUT IF NO POINTER
5076 030666 104401          TYPE          ;; TYPE THE "ERROR MESSAGE"
5077 030670 000000          2$: .WORD      0          ;; "ERROR MESSAGE" POINTER GOES HERE
5078 030672 104401 001165  TYPE        $CRLF      ;; "CARRIAGE RETURN" & "LINE FEED"
5079 030676 012037 030706  3$: MOV        (RO)+,4$    ;; PICKUP "DATA HEADER" POINTER
5080 030702 001404          BEQ        5$          ;; SKIP TYPEOUT IF 0
5081 030704 104401          TYPE          ;; TYPE THE "DATA HEADER"
5082 030706 000000          4$: .WORD      0          ;; "DATA HEADER" POINTER GOES HERE
5083 030710 104401 001165  TYPE        $CRLF      ;; "CARRIAGE RETURN" & "LINE FEED"
5084 030714 011000          5$: MOV        (RO),RO    ;; PICKUP "DATA TABLE" POINTER
5085 030716 001004          BNE        7$          ;; GO TYPE THE DATA
5086 030720 012600          6$: MOV        (SP)+,RO    ;; RESTORE RO
5087 030722 104401 001165  TYPE        $CRLF      ;; "CARRIAGE RETURN" & "LINE FEED"
5088 030726 000207          RTS         PC          ;; RETURN
5089 030730          7$:
5090 030730 013046          MOV        2(RO)+,-(SP) ;; SAVE 2(RO)+ FOR TYPEOUT
5091 030732 104402          TYP0C          ;; GO TYPE--OCTAL ASCII(ALL DIGITS)
5092 030734 005710          TST        (RO)        ;; IS THERE ANOTHER NUMBER?
5093 030736 001770          BEQ        6$          ;; BR IF NO
5094 030740 104401 030746  TYPE        8$          ;; TYPE TWO(2) SPACES
5095 030744 000771          BR         7$          ;; LOOP
5096 030746 020040 000          8$: .ASCIZ    / /          ;; TWO(2) SPACES
5097 030752          .EVEN

```

.SBTTL TYPE ROUTINE

```

100 *****
101 *ROUTINE TO TYPE ASCIZ MESSAGE. MESSAGE MUST TERMINATE WITH A 0 BYTE.
102 *THE ROUTINE WILL INSERT A NUMBER OF NULL CHARACTERS AFTER A LINE FEED.
103 *NOTE1: $NULL CONTAINS THE CHARACTER TO BE USED AS THE FILLER CHARACTER.
104 *NOTE2: $FILLS CONTAINS THE NUMBER OF FILLER CHARACTERS REQUIRED.
105 *NOTE3: $FILLC CONTAINS THE CHARACTER TO FILL AFTER.
106 *
107 *CALL:
108 *1) USING A TRAP INSTRUCTION
109 * TYPE ,MESADR ;;MESADR IS FIRST ADDRESS OF AN ASCIZ STRING
110 *OR
111 * TYPE
112 * MESADR
113 *
114 *
115 *
116 *
117 $TYPE: TSTB     STPLG    ;; IS THERE A TERMINAL?
118        BPL      1$      ;; BR IF YES
119        HALT     ;; HALT HERE IF NO TERMINAL
120        BR       3$      ;; LEAVE

```

```

5121 030764 010046      1$:  MOV      RO,-(SP)      ;;SAVE RO
5122 030766 017600 000002  MOV      @2(SP),RO      ;;GET ADDRESS OF ASCIZ STRING
5123 030772 112046      2$:  MOVB    (RO)+,-(SP)   ;;PUSH CHARACTER TO BE TYPED ONTO STACK
5124 030774 001005      BNE      4$             ;;BR IF IT ISN'T THE TERMINATOR
5125 030776 005726      TST      (SP)+         ;;IF TERMINATOR POP IT OFF THE STACK
5126 031000 012600      60$:  MOV      (SP)+,RO      ;;RESTORE RO
5127 031002 062716 000002  3$:  ADD      #2,(SP)      ;;ADJUST RETURN PC
5128 031006 000002      RTI                     ;;RETURN
5129 031010 122716 000011  4$:  CMPB    #HT,(SP)      ;;BRANCH IF <HT>
5130 031014 001430      BEQ      8$             ;;BRANCH IF NOT <CRLF>
5131 031016 122716 000200  CMPB    #CRLF,(SP)    ;;BRANCH IF NOT <CRLF>
5132 031022 001006      BNE      5$             ;;PCP <CR><LF> EQUIV
5133 031024 005726      TST      (SP)+         ;;TYPE A CR AND LF
5134 031026 104401      TYPE                     ;;TYPE A CR AND LF
5135 031030 001165      $CRLF                    ;;CLEAR CHARACTER COUNT
5136 031032 105037 031166  CLRB    $CHARCNT      ;;GET NEXT CHARACTER
5137 031036 000755      BR       2$             ;;GO TYPE THIS CHARACTER
5138 031040 004737 031122  5$:  JSR     PC,$TYPEPC    ;;GO TYPE THIS CHARACTER
5139 031044 123726 001156  6$:  CMPB    $FILLC,(SP)+  ;;IS IT TIME FOR FILLER CHARS.?
5140 031050 001350      BNE      2$             ;;IF NO GO GET NEXT CHAR.
5141 031052 013746 001154  MOV     $NULL,-(SP)    ;;GET # OF FILLER CHARS. NEEDED
5142                                     ;;AND THE NULL CHAR.
5143 031056 105366 000001  7$:  DECB    1(SP)         ;;DOES A NULL NEED TO BE TYPED?
5144 031062 002770      BLT     6$             ;;BR IF NO--GO POP THE NULL OFF OF STACK
5145 031064 004737 031122  JSR     PC,$TYPEPC    ;;GO TYPE A NULL
5146 031070 105337 031166  DECB    $CHARCNT      ;;DO NOT COUNT AS A COUNT
5147 031074 000770      BR      7$            ;;LOOP
5148
5149                                     ;HORIZONTAL TAB PROCESSOR
5150
5151 031076 112716 000040  8$:  MOVB    #' ,(SP)     ;;REPLACE TAB WITH SPACE
5152 031102 004737 031122  9$:  JSR     PC,$TYPEPC    ;;TYPE A SPACE
5153 031106 132737 000007 031166  BITB    #7,$CHARCNT   ;;BRANCH IF NOT AT
5154 031114 001372      BNE     9$             ;;TAB STOP
5155 031116 005726      TST     (SP)+         ;;POP SPACE OFF STACK
5156 031120 000724      BR      2$            ;;GET NEXT CHARACTER
5157 031122 105777 150022  $TYPEPC: TSTB   @2$TPS   ;;WAIT UNTIL PRINTER IS READY
5158 031126 100375      BPL     $TYPEPC
5159 031130 116677 000002 150014  MOVB    2(SP),@2$TPB  ;;LOAD CHAR TO BE TYPED INTO DATA REG.
5160 031136 122766 000015 000002  CMPB    #CR,2(SP)    ;;IS CHARACTER A CARRIAGE RETURN?
5161 031144 001003      BNE     1$            ;;BRANCH IF NO
5162 031146 105037 031166  CLRB    $CHARCNT      ;;YES--CLEAR CHARACTER COUNT
5163 031152 000406      BR      $TYPEPC      ;;EXIT
5164 031154 122766 000012 000002  1$:  CMPB    #LF,2(SP)    ;;IS CHARACTER A LINE FEED?
5165 031162 001402      BEQ     $TYPEPC      ;;BRANCH IF YES
5166 031164 105227      INCB   (PC)+         ;;COUNT THE CHARACTER
5167 031166 000000  $CHARCNT: .WORD 0    ;;CHARACTER COUNT STORAGE
5168 031170 000207  $TYPEPC: RTS      PC
5169
5170
5171                                     .SBTTL  BINARY TO OCTAL (ASCII) AND TYPE
5172
5173                                     ;*****
5174                                     ;*THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 6-DIGIT

```



5175  
5176  
5177  
5178  
5179  
5180  
5181  
5182  
5183  
5184  
5185  
5186  
5187  
5188  
5189  
5190  
5191  
5192  
5193  
5194  
5195  
5196  
5197  
5198  
5199  
5200  
5201  
5202  
5203  
5204  
5205  
5206  
5207  
5208  
5209  
5210  
5211  
5212  
5213  
5214  
5215  
5216  
5217  
5218  
5219  
5220  
5221  
5222  
5223  
5224  
5225  
5226  
5227  
5228

031172 017646 000000  
031176 116637 000001 031415  
031204 112637 031417  
031210 062716 000002  
031214 000406  
031216 112737 000001 031415  
031224 112737 000006 031417  
031232 112737 000005 031414  
031240 010346  
031242 010446  
031244 010546  
031246 113704 031417  
031252 005404  
031254 062704 000006  
031260 110437 031416  
031264 113704 031415  
031270 016605 000012  
031274 005003  
031276 006105 1\$:  
031300 000404 BR 3\$:  
031302 006105 RCL R5  
031304 006105 ROL R5  
031306 006105 ROL R5  
031310 010503 MOV R5,R3  
031312 006103 3\$: ROL R3  
031314 105337 031416 DECB \$OMODE  
031320 100016 BPL 7\$  
031322 042703 177770 BIC #177770,R3  
031326 001002 BNE 4\$:  
031330 005704 TST R4  
031332 001403 BEQ 5\$:  
031334 005204 4\$: INC R4  
031336 052703 000060 BIS #'0,R3

```
;;OCTAL (ASCII) NUMBER AND TYPE IT.
*$TYPOS-- ENTER HERE TO SETUP SUPPRESS ZEROS AND NUMBER OF DIGITS TO TYPE
*CALL:
*   MOV   NUM,-(SP)      ;;NUMBER TO BE TYPED
*   TYPOS                ;;CALL FOR TYPEOUT
*   .BYTE N              ;;N=1 TO 6 FOR NUMBER OF DIGITS TO TYPE
*   .BYTE M              ;;M=1 OR 0
*                               ;;1=TYPE LEADING ZEROS
*                               ;;0=SUPPRESS LEADING ZEROS
*$TYPON----ENTER HERE TO TYPE OUT WITH THE SAME PARAMETERS AS THE LAST
*$TYPOS OR $TYPOC
*CALL:
*   MOV   NUM,-(SP)      ;;NUMBER TO BE TYPED
*   TYPON                ;;CALL FOR TYPEOUT
*$TYPOC---ENTER HERE FOR TYPEOUT OF A 16 BIT NUMBER
*CALL:
*   MOV   NUM,-(SP)      ;;NUMBER TO BE TYPED
*   TYPOC                ;;CALL FOR TYPEOUT
*$TYPOS: MOV   2(SP),-(SP) ;;PICKUP THE MODE
MOVVB 1(SP), $OFILL ;;LOAD ZERO FILL SWITCH
MOVVB (SP)+, $OMODE+1 ;;NUMBER OF DIGITS TO TYPE
ADD #2,(SP) ;;ADJUST RETURN ADDRESS
BR $TYPON
*$TYPOC: MOVVB #1,$OFILL ;;SET THE ZERO FILL SWITCH
MOVVB #6,$OMODE+1 ;;SET FOR SIX(6) DIGITS
*$TYPON: MOVVB #5,$OCNT ;;SET THE ITERATION COUNT
MOV R3,-(SP) ;;SAVE R3
MOV R4,-(SP) ;;SAVE R4
MOV R5,-(SP) ;;SAVE R5
MOVVB $OMODE+1,R4 ;;GET THE NUMBER OF DIGITS TO TYPE
NEG R4
ADD #6,R4 ;;SUBTRACT IT FOR MAX. ALLOWED
MOVVB R4,$OMODE ;;SAVE IT FOR USE
MOVVB $OFILL,R4 ;;GET THE ZERO FILL SWITCH
MOV 12(SP),R5 ;;PICKUP THE INPUT NUMBER
CLR R3 ;;CLEAR THE OUTPUT WORD
RCL R5 ;;ROTATE MSB INTO "C"
BR 3$ ;;GO DO MSB
RCL R5 ;;FORM THIS DIGIT
ROL R5
MOV R5,R3
ROL R3 ;;GET LSB OF THIS DIGIT
DECB $OMODE ;;TYPE THIS DIGIT?
BPL 7$ ;;BR IF NO
BIC #177770,R3 ;;GET RID OF JUNK
BNE 4$ ;;TEST FOR 0
TST R4 ;;SUPPRESS THIS 0?
BEQ 5$ ;;BR IF YES
INC R4 ;;DON'T SUPPRESS ANYMORE 0'S
BIS #'0,R3 ;;MAKE THIS DIGIT ASCII
```

DZAJD.019

BINARY TO OCTAL (ASCII) AND TYPE

```

5229 031342 052703 000040 5$: BIS #',R3 ;;MAKE ASCII IF NOT ALREADY
5230 031346 110337 031412 MOVB R3,B$ ;;SAVE FOR TYPING
5231 031352 104401 031412 TYPE 8$ ;;GO TYPE THIS DIGIT
5232 031356 105337 031414 7$: DECB $OCNT ;;COUNT BY 1
5233 031362 003347 BGT 2$ ;;BR IF MORE TO DO
5234 031364 002402 BLT 6$ ;;BR IF DONE
5235 031366 005204 INC R4 ;;INSURE LAST DIGIT ISN'T A BLANK
5236 031370 000744 BR 2$ ;;GO DO THE LAST DIGIT
5237 031372 012605 5$: MOV (SP)+,R5 ;;RESTORE R5
5238 031374 012604 MOV (SP)+,R4 ;;RESTORE R4
5239 031376 012603 MOV (SP)+,R3 ;;RESTORE R3
5240 031400 016666 000002 000004 MOV 2(SP),4(SP) ;;SET THE STACK FOR RETURNING
5241 031406 012616 MOV (SP)+,(SP)
5242 031410 000002 RTI ;;RETURN
5243 031412 000 8$: .BYTE 0 ;;STORAGE FOR ASCII DIGIT
5244 031413 000 .BYTE 0 ;;TERMINATOR FOR TYPE ROUTINE
5245 031414 000 $OCNT: .BYTE 0 ;;OCTAL DIGIT COUNTER
5246 031415 000 $OFILL: .BYTE 0 ;;ZERO FILL SWITCH
5247 031416 000000 $OMODE: .WORD 0 ;;NUMBER OF DIGITS TO TYPE

```

.SBTTL CONVERT BINARY TO DECIMAL AND TYPE ROUTINE

```

5251 *****
5252 *THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 5-DIGIT
5253 *SIGNED DECIMAL (ASCII) NUMBER AND TYPE IT. DEPENDING ON WHETHER THE
5254 *NUMBER IS POSITIVE OR NEGATIVE A SPACE OR A MINUS SIGN WILL BE TYPED
5255 *BEFORE THE FIRST DIGIT OF THE NUMBER. LEADING ZEROS WILL ALWAYS BE
5256 *REPLACED WITH SPACES.
5257 *CALL:
5258 * MOV NUM,-(SP) ;;PUT THE BINARY NUMBER ON THE STACK
5259 * TYPDS ;;GO TO THE ROUTINE

```

```

5261 031420 $TYPDS: MOV R0,-(SP) ;;PUSH R0 ON STACK
5262 031420 010046 MOV R1,-(SP) ;;PUSH R1 ON STACK
5263 031422 010146 MOV R2,-(SP) ;;PUSH R2 ON STACK
5264 031424 010246 MOV R3,-(SP) ;;PUSH R3 ON STACK
5265 031426 010346 MOV R5,-(SP) ;;PUSH R5 ON STACK
5266 031430 010546 MOV #20200,-(SP) ;;SET BLANK SWITCH AND SIGN
5267 031432 012746 020200 MOV 20(SP),R5 ;;GET THE INPUT NUMBER
5268 031436 016605 000020 BPL 1$ ;;BR IF INPUT IS POS.
5269 031442 100004 1$: NEG R5 ;;MAKE THE BINARY NUMBER POS.
5270 031444 005405 000055 000001 MOVB #'-,1(SP) ;;MAKE THE ASCII NUMBER NEG.
5271 031446 112766 000055 000001 CLR R0 ;;ZERO THE CONSTANTS INDEX
5272 031454 005000 1$: MOV #0BLK,R3 ;;SETUP THE OUTPUT POINTER
5273 031456 012703 031634 MOVB #'',(R3)+ ;;SET THE FIRST CHARACTER TO A BLANK
5274 031462 112723 000040 2$: CLR R2 ;;CLEAR THE BCD NUMBER
5275 031466 005002 031624 3$: MOV $DTBL(R0),R1 ;;GET THE CONSTANT
5276 031470 016001 031624 3$: SUB R1,R5 ;;FORM THIS BCD DIGIT
5277 031474 160105 3$: BLT 4$ ;;BR IF DONE
5278 031476 002402 4$: INC R2 ;;INCREASE THE BCD DIGIT BY 1
5279 031500 005202 4$: BR 3$
5280 031502 000774 4$: ADD R1,R5 ;;ADD BACK THE CONSTANT
5281 031504 060105 4$: TST R2 ;;CHECK IF BCD DIGIT=0
5282 031506 005702

```

```

5283 031510 001002      BNE      5$          ;; FALL THROUGH IF 0
5284 031512 105716      TSTB     (SP)        ;; STILL DOING LEADING 0'S?
5285 031514 100407      BMI      7$          ;; BR IF YES
5286 031516 106316      5$: ASLB     (SP)        ;; MSD?
5287 031520 103003      BCC      6$          ;; BR IF NO
5288 031522 116663 000001 177777  MOVB     1(SP),-1(R3) ;; YES--SET THE SIGN
5289 031530 052702 000060 6$: BIS     #'0,R2     ;; MAKE THE BCD DIGIT ASCII
5290 031534 052702 000040 7$: BIS     #' ,R2     ;; MAKE IT A SPACE IF NOT ALREADY A DIGIT
5291 031540 110223      MOVB     R2,(R3)+    ;; PUT THIS CHARACTER IN THE OUTPUT BUFFER
5292 031542 005720      TST      (R0)+       ;; JUST INCREMENTING
5293 031544 020027 000010  CMP      R0,#10     ;; CHECK THE TABLE INDEX
5294 031550 002746      BLT      2$          ;; GO DO THE NEXT DIGIT
5295 031552 003002      SGT      8$          ;; GO TO EXIT
5296 031554 010502      MOV      R5,R2       ;; GET THE LSD
5297 031556 000764      BR       6$          ;; GO CHANGE TO ASCII
5298 031560 105726      8$: TSTB     (SP)+     ;; WAS THE LSD THE FIRST NON-ZERO?
5299 031562 100003      BPL      9$          ;; BR IF NO
5300 031564 116663 177777 177776  MOVB     -1(SP),-2(R3) ;; YES--SET THE SIGN FOR TYPING
5301 031572 105013      9$: CLRB     (R3)      ;; SET THE TERMINATOR
5302 031574 012605      MOV      (SP)+,R5    ;; POP STACK INTO R5
5303 031576 012603      MOV      (SP)+,R3    ;; POP STACK INTO R3
5304 031600 012602      MOV      (SP)+,R2    ;; POP STACK INTO R2
5305 031602 012601      MOV      (SP)+,R1    ;; POP STACK INTO R1
5306 031604 012600      MOV      (SP)+,R0    ;; POP STACK INTO R0
5307 031606 104401 031634  TYPE     $DBLK       ;; NOW TYPE THE NUMBER
5308 031612 016666 000002 000004  MOV      2(SP),4(SP) ;; ADJUST THE STACK
5309 031620 012616      MOV      (SP)+,(SP)
5310 031622 000002      RTI                          ;; RETURN TO USER
5311 031624 023420      $DTBL: 10000.
5312 031626 001750      1000.
5313 031630 000144      100.
5314 031632 000012      10.
5315 031634 000004      $DBLK: .BLKW 4
5316
5317      .SBTTL  TTY INPUT ROUTINE
5318
5319      ;;*****
5320      .ENABL  LSB
5321
5322      ;;*****
5323      ;;*SOFTWARE SWITCH REGISTER CHANGE ROUTINE.
5324      ;;*ROUTINE IS ENTERED FROM THE TRAP HANDLER, AND WILL
5325      ;;*SERVICE THE TEST FOR CHANGE IN SOFTWARE SWITCH REGISTER TRAP CALL
5326      ;;*WHEN OPERATING IN TTY FLAG MODE.
5327 031644 022737 000176 001140 $CKSWR: CMP     #SWREG,SWR  ;; IS THE SOFT-SWR SELECTED?
5328 031652 001074      BNE     15$         ;; BRANCH IF NO
5329 031654 105777 147264  TSTB     3$TKS      ;; CHAR THERE?
5330 031660 100071      BPL     15$         ;; IF NO, DON'T WAIT AROUND
5331 031662 117746 147260  MOVB     3$TKB,-(SP) ;; SAVE THE CHAR
5332 031666 042716 177600  BIC     #'C17,(SP)  ;; STRIP-OFF THE ASCII
5333 031672 022726 000007  CMP      #7,(SP)+   ;; IS IT A CONTROL G?
5334 031676 001062      BNE     15$         ;; NO, RETURN TO USER
5335 031700 123727 001134 000001  CMPB     $AUTOB,#1   ;; ARE WE RUNNING IN AUTO-MODE?
5336 031706 0C1456      BEQ     15$         ;; BRANCH IF YES

```

```

5337
5338 031710 104401 032253
5339 031714 104401 032260 $GTSWR: TYPE , $CNTLG ;; ECHO THE CONTROL-G (↑G)
5340 031720 013746 000176 MOV $MSWR ;; TYPE CURRENT CONTENTS
5341 031724 104402 TYPQC $WREG, -(SP) ;; SAVE SWREG FOR TYPEOUT
5342 031726 104401 032271 TYPE . $MNEW ;; GO TYPE--OCTAL ASCII(ALL DIGITS)
5343 031732 005046 19$: CLR -(SP) ;; PROMPT FOR NEW SWR
5344 031734 005046 CLR -(SP) ;; CLEAR COUNTER
5345 031736 105777 147202 7$: TSTB $TKS ;; THE NEW SWR
5346 031742 100375 BPL 7$ ;; CHAR THERE?
5347 ;; IF NOT TRY AGAIN
5348 031744 117746 147176 MOVB $TKB, -(SP) ;; PICK UP CHAR
5349 031750 042716 177600 BIC #↑C177, (SP) ;; MAKE IT 7-BIT ASCII
5350
5351
5352
5353 031754 021627 000025 9$: CMP (SP), #25 ;; IS IT A CONTROL-U?
5354 031760 001005 BNE 10$ ;; BRANCH IF NOT
5355 031762 104401 032246 TYPE , $CNTLU ;; YES, ECHO CONTROL-U (↑U)
5356 031766 062706 000006 20$: ADD #6, SP ;; IGNORE PREVIOUS INPUT
5357 031772 000757 BR 19$ ;; LET'S TRY IT AGAIN
5358
5359
5360 031774 021627 000015 10$: CMP (SP), #15 ;; IS IT A <CR>?
5361 032000 001022 BNE 16$ ;; BRANCH IF NO
5362 032002 005766 000004 TST 4(SP) ;; YES, IS IT THE FIRST CHAR?
5363 032006 001403 BEQ 11$ ;; BRANCH IF YES
5364 032010 016677 000002 147122 MOV 2(SP), $SWR ;; SAVE NEW SWR
5365 032016 062706 000006 11$: ADD #6, SP ;; CLEAR UP STACK
5366 032022 104401 001165 14$: TYPE $CRLF ;; ECHO <CR> AND <LF>
5367 032026 123727 001135 000001 CMPB $INTAG, #1 ;; RE-ENABLE TTY KBD INTERRUPTS?
5368 032034 001003 BNE 15$ ;; BRANCH IF NOT
5369 032036 012777 000100 147100 MOV #100, $TKS ;; RE-ENABLE TTY KBD INTERRUPTS
5370 032044 000002 15$: RTI ;; RETURN
5371 032046 004737 031122 16$: JSR PC, $TYPEC ;; ECHO CHAR
5372 032052 021627 000060 CMP (SP), #60 ;; CHAR < 0?
5373 032056 002420 BLT 18$ ;; BRANCH IF YES
5374 032060 021627 000067 CMP (SP), #67 ;; CHAR > 7?
5375 032064 003015 BGT 18$ ;; BRANCH IF YES
5376 032066 042726 000060 BIC #60, (SP)+ ;; STRIP-OFF ASCII
5377 032072 005766 000002 TST 2(SP) ;; IS THIS THE FIRST CHAR
5378 032076 001403 BEQ 17$ ;; BRANCH IF YES
5379 032100 006316 ASL (SP) ;; NO, SHIFT PRESENT
5380 032102 006316 ASL (SP) ;; CHAR OVER TO MAKE
5381 032104 006316 ASL (SP) ;; ROOM FOR NEW ONE.
5382 032106 005266 000002 17$: INC 2(SP) ;; KEEP COUNT OF CHAR
5383 032112 056616 177776 BIS -2(SP), (SP) ;; SET IN NEW CHAR
5384 032116 000707 BR 7$ ;; GET THE NEXT ONE
5385 032120 104401 001164 18$: TYPE $QUES ;; TYPE ?<CR><LF>
5386 032124 000720 BR 20$ ;; SIMULATE CONTROL-U
5387 .DSABL LSB
5388
5389
5390 ;*****

```

```

5391      ;*THIS ROUTINE WILL INPUT A SINGLE CHARACTER FROM THE TTY
5392      ;*CALL:
5393      ;*      RDCHR          ;; INPUT A SINGLE CHARACTER FROM THE TTY
5394      ;*      RETURN HERE   ;; CHARACTER IS ON THE STACK
5395      ;*                    ;; WITH PARITY BIT STRIPPED OFF
5396      ;
5397      ;
5398      032126 011646 $RDCHR: MOV      (SP), -(SP)      ;; PUSH DOWN THE PC
5399      032130 016666 000004 000002      MOV      4(SP), 2(SP)      ;; SAVE THE PS
5400      032136 105777 147002      1$: TSTB    2$TKS          ;; WAIT FOR
5401      032142 100375          BPL      1$            ;; A CHARACTER
5402      032144 117766 146776 000004      MOVB    2$TKB, 4(SP)      ;; READ THE TTY
5403      032152 042766 177600 000004      BIC     #1C<177>, 4(SP)  ;; GET RID OF JUNK IF ANY
5404      032160 026627 000004 000023      CMP     4(SP), #23      ;; IS IT A CONTROL-S?
5405      032166 001013          BNE     3$            ;; BRANCH IF NO
5406      032170 105777 146750      2$: TSTB    2$TKS          ;; WAIT FOR A CHARACTER
5407      032174 100375          BPL      2$            ;; LOOP UNTIL ITS THERE
5408      032176 117746 146744      MOVB    2$TKB, -(SP)     ;; GET CHARACTER
5409      032202 042716 177600          BIC     #1C177, (SP)    ;; MAKE IT 7-BIT ASCII
5410      032206 022627 000021      CMP     (SP)+, #21      ;; IS IT A CONTROL-Q?
5411      032212 001366          BNE     2$            ;; IF NOT DISCARD IT
5412      032214 000750          BR      1$            ;; YES, RESUME
5413      032216 026627 000004 000140      3$: CMP     4(SF), #140   ;; IS IT UPPER CASE?
5414      032224 002407          BLT     4$            ;; BRANCH IF YES
5415      032226 026627 000004 000175      CMP     4(SP), #175     ;; IS IT A SPECIAL CHAR?
5416      032234 003003          BGT     4$            ;; BRANCH IF YES
5417      032236 042766 000040 000004      BIC     #40, 4(SP)      ;; MAKE IT UPPER CASE
5418      032244 000002          RTI     ;              ;; GO BACK TO USER
5419      032246 052536 005015 000      $CNTLU: .ASCIZ /↑U/<15><12>  ;; CONTROL "U"
5420      032253 0136 006507 000012      $CNTLG: .ASCIZ /↑G/<15><12>  ;; CONTROL "G"
5421      032260 005015 053523 020122      $MSWR:  .ASCIZ <15><12>/SWR = /
5422      032266 020075 000
5423      032271 040 047040 053505      $MNEW:  .ASCIZ / NEW = /
5424      032276 036440 000040
5425
5426      .SBTTL  RANDOM NUMBER GENERATOR ROUTINE
5427
5428      ;******
5429      ;*THIS ROUTINE IS A DOUBLE PRECISION PSEUDO RANDOM NUMBER GENERATOR
5430      ;*WITH A RANGE OF 0 TO 2(+33)-1.
5431      ;*CALL:
5432      ;*      JSR      PC, $RAND      ;; CALL THE ROUTINE
5433      ;*      RETURN      ;; RETURN HERE THE RANDOM
5434      ;*                    ;; NUMBER WILL BE IN
5435      ;*                    ;; $HINUM, $LONUM
5436      ;*
5437      032302 $RAND: MOV      R0, -(SP)      ;; PUSH R0 ON STACK
5438      032302 010046      MOV      R1, -(SP)      ;; PUSH R1 ON STACK
5439      032304 010146      MOV      R2, -(SP)      ;; PUSH R2 ON STACK
5440      032306 010246      MOV      $LONUM, R0     ;; SET R0 WITH LOW
5441      032310 013700 032402      MOV      $HINUM, R1     ;; SET R1 WITH HIGH
5442      032314 013701 032400      MOV      #-7, R2        ;; SET SHIFT COUNT
5443      032320 012702 177771      1$: MOV      R0          ;; SHIFT R0 LEFT AND
5444      032324 006300

```

5445	032326	006101		ROL	R1	:: ROTATE CARRY INTO R1 AND
5446	032330	005202		INC	R2	:: CHECK FOR DONE
5447	032332	001374		BNE	1\$	:: CONTINUE SHIFT LOOP
5448	032334	063700	032402	ADD	\$LONUM,R0	:: ADD NUMBER TO MAKE X 129
5449	032340	005501		ADC	R1	:: PROPOGATE CARRY
5450	032342	063701	032400	ADD	\$HINUM,R1	:: ADD NUMBER TO MAKE X 129
5451	032346	062700	001057	ADD	#1057,R0	:: ADD LOW CONSTANT
5452	032352	005501		ADC	R1	:: PROPOGATE CARRY
5453	032354	062701	047401	ADD	#47401,R1	:: ADD HIGH CONSTANT
5454	032360	010037	032402	MOV	R0,\$LONUM	:: SAVE R0
5455	032364	010137	032400	MOV	R1,\$HINUM	:: SAVE R1
5456	032370	012602		MOV	(SP)+,R2	:: POP STACK INTO R2
5457	032372	012601		MOV	(SP)+,R1	:: POP STACK INTO R1
5458	032374	012600		MOV	(SP)+,R0	:: POP STACK INTO R0
5459	032376	000207		RTS	PC	:: RETURN
5460	032400	176543		\$HINUM: .WORD	176543	
5461	032402	123456		\$LONUM: .WORD	123456	

.SBTTL SAVE AND RESTORE R0-R5 ROUTINES

```

*****
*SAVE R0-R5
*CALL:
* SAVREG
*UPON RETURN FROM $$SAVREG THE STACK WILL LOOK LIKE:
*
*TOP---(+16)
* +2---(+18)
* +4---R5
* +6---R4
* +8---R3
*+10---R2
*+12---R1
*+14---R0

```

```

$$SAVREG:
MOV R0,-(SP) ;; PUSH R0 ON STACK
MOV R1,-(SP) ;; PUSH R1 ON STACK
MOV R2,-(SP) ;; PUSH R2 ON STACK
MOV R3,-(SP) ;; PUSH R3 ON STACK
MOV R4,-(SP) ;; PUSH R4 ON STACK
MOV R5,-(SP) ;; PUSH R5 ON STACK
MOV 22(SP),-(SP) ;; SAVE PS OF MAIN FLOW
MOV 22(SP),-(SP) ;; SAVE PC OF MAIN FLOW
MOV 22(SP),-(SP) ;; SAVE PS OF CALL
MOV 22(SP),-(SP) ;; SAVE PC OF CALL
RTI

```

```

*RESTORE R0-R5
*CALL:
* RESREG

```

```

$RESREG:
MOV (SP)+,22(SP) ;; RESTORE PC OF CALL
MOV (SP)+,22(SP) ;; RESTORE PS OF CALL

```

5480	032404					
5481	032404	010046				
5482	032406	010146				
5483	032410	010246				
5484	032412	010346				
5485	032414	010446				
5486	032416	010546				
5487	032420	016646	000022			
5488	032424	016646	000022			
5489	032430	016646	000022			
5490	032434	016646	000022			
5491	032440	000002				
5492						
5493						
5494						
5495						
5496	032442					
5497	032442	012666	000022			
5498	032446	012666	000022			

```

5499 032452 012666 000022      MOV      (SP)+,22(SP)      ;;RESTORE PC OF MAIN FLOW
5500 032456 012666 000022      MOV      (SP)+,22(SP)      ;;RESTORE PS OF MAIN FLOW
5501 032462 012605              MOV      (SP)+,R5          ;;POP STACK INTO R5
5502 032464 012604              MOV      (SP)+,R4          ;;POP STACK INTO R4
5503 032466 012603              MOV      (SP)+,R3          ;;POP STACK INTO R3
5504 032470 012602              MOV      (SP)+,R2          ;;POP STACK INTO R2
5505 032472 012601              MOV      (SP)+,R1          ;;POP STACK INTO R1
5506 032474 012600              MOV      (SP)+,R0          ;;POP STACK INTO R0
5507 032476 000002      RTI

```

.SBTTL DOUBLE LENGTH BINARY TO DECIMAL ASCII CONVERT ROUTINE

```

*****
*THIS ROUTINE WILL CONVERT A 32-BIT BINARY NUMBER TO AN UNSIGNED
*DECIMAL (ASCII) NUMBER. THE SIGN OF THE BINARY NUMBER MUST BE
*POSITIVE.

```

```

*CALL
*      MOV      #PNTR, -(SP)      ;; POINTER TO LOW WORD OF BINARY NUMBER
*      JSR      PC, @#$DB2D
*      RETURN                      ;; THE FIRST ADDRESS OF ASCII
*                                  ;; IS ON THE STACK

```

```

5522 032500 104412      $DB2C: SAVREG              ;; SAVE REGISTERS
5523 032502 016602 000002      MOV      2(SP), R2          ;; PICKUP THE DATA POINTER
5524 032506 012700 032660      MOV      #$DECVL, R0        ;; GET ADDRESS OF "$DECVL" STRING
5525 032512 010066 000002      MOV      R0, 2(SP)          ;; PUT ADDRESS OF ASCII STRING ON STACK
5526 032516 012201              MOV      (R2)+, R1          ;; PICKUP THE BINARY NUMBER
5527 032520 012202              MOV      (R2)+, R2
5528 032522 012737 000012 032576      MOV      #10, 4$           ;; SET UP TO DO 10 CONVERSIONS
5529 032530 012704 032610      MOV      #10, 4$           ;; ADDRESS OF TEN POWER
5530 032534 012705 032612      MOV      #10, 4$           ;; ADDRESS OF TEN POWER
5531 032540 005003      1$: CLR      R3              ;; CLEAR PARTIAL
5532 032542 161401      2$: SUB      (R4), R1          ;; SUBTRACT TEN POWER
5533 032544 005602              SBC      R2
5534 032546 161502              SUB      (R5), R2
5535 032550 002402              BLT     3$                  ;; BR IF TEN POWER TOO LARGE
5536 032552 005203              INC     R3                  ;; ADD 1 TO PARTIAL
5537 032554 000772              BR     2$                  ;; LOOP
5538 032556 062401      3$: ADD      (R4)+, R1          ;; RESTORE SUBTRACTED VALUE
5539 032560 005502              ADC     R2
5540 032562 062402              ADD     (R4)+, R2
5541 032564 022525              CMP     (R5)+, (R5)+        ;; MOVE TO NEXT TEN POWER
5542 032566 052703 000060      BIS     #'0, R3            ;; CHANGE PARTIAL TO ASCII
5543 032572 110320              MOV     R3, (R0)+          ;; SAVE IT
5544 032574 005327              DEC     (PC)+              ;; DONE?
5545 032576 000000      4$: .WORD 0
5546 032600 001357              BNE    1$                  ;; BR IF NO
5547 032602 105020              CLRB   (R0)+              ;; TERMINATOR
5548 032604 104413              RESREG                      ;; RESTORE REGISTERS
5549 032606 000207              RTS     PC                  ;; RETURN
5550 032610 145000      $TNPWR: 145000            ;; 1.0E09
5551 032612 035632              35632
5552 032614 160400              160400                    ;; 1.0E08

```

```

5553 032616 002765          2765
5554 032620 113200          113200          ;;1.0E07
5555 032622 000230          230
5556 032624 041100          041100          ;;1.0E06
5557 032626 000017          17
5558 032630 103240          103240          ;;1.0E05
5559 032632 000001          1
5560 032634 023420          23420          ;;1.0E04
5561 032636 000000          0
5562 032640 001750          1750          ;;1.0E03
5563 032642 000000          0
5564 032644 000144          144          ;;1.0E02
5565 032646 000000          0
5566 032650 000012          12          ;;1.0E01
5567 032652 000000          0
5568 032654 000001          1          ;;1.0E00
5569 032656 000000          0
5570 032660 000014          0

```

\$DECVL: .BLKB 12. ;;RESERVE STORAGE FOR ASCII STRING

.SBTTL DOUBLE LENGTH BINARY TO OCTAL ASCII CONVERT ROUTINE

```

;*****
;THIS ROUTINE WILL CONVERT A 32-BIT UNSIGNED BINARY NUMBER TO AN
;UNSIGNED OCTAL ASCII NUMBER.
;CALL

```

```

;*      MOV      #PNTR, -(SP)      ;; POINTER TO LOW WORD OF BINARY NUMBER
;*      JSR      PC, @#$DB20      ;; CALL THE ROUTINE
;*      RETURN                      ;; THE ADDRESS OF THE FIRST ASCII CHAR. IS ON THE STACK

```

```

5582
5583 032674 104412          $DB20: SAVREG          ;; SAVE ALL REGISTERS
5584 032676 016601 000002      MOV      2(SP), R1      ;; PICKUP THE POINTER TO LOW WORD
5585 032702 012705 033013      MOV      #$OCTVL+13., R5 ;; POINTER TO DATA TABLE
5586 032706 012704 000014      MOV      #12., R4      ;; DO ELEVEN CHARACTERS
5587 032712 012703 177770      MOV      #1C7, R3      ;; MASK
5588 032716 012100          MOV      (R1)+, R0      ;; LOWER WORD
5589 032720 012101          MOV      (R1)+, R1      ;; HIGH WORD
5590 032722 005002          CLR      R2            ;; TERMINATOR
5591 032724 110245          1$:      MOV      R2, -(R5)    ;; PUT CHARACTER IN DATA TABLE
5592 032726 010002          MOV      R0, R2        ;; GET THIS DIGIT
5593 032730 005304          DEC      R4            ;; COUNT THIS CHARACTER
5594 032732 003007          BGT      3$           ;; BR IF NOT THE LAST DIGIT
5595 032734 001405          BEQ      2$           ;; BR IF IT IS THE LAST DIGIT
5596 032736 005205          INC      R5            ;; ALL DIGITS DONE-ADJUST POINTER FOR FIRST
5597 032740 010566 000002      MOV      R5, 2(SP)    ;; ASCII CHAR. & PUT IT ON THE STACK
5598 032744 104413          RESREG          ;; RESTORE ALL REGISTERS
5599 032746 000207          RTS              ;; RETURN TO USER
5600 032750 006203          2$:      ASR      R3            ;; POSITION THE MASK FOR THE LAST DIGIT
5601 032752 006001          3$:      ROR      R1            ;; POSITION THE BINARY NUMBER FOR
5602 032754 006000          ROR      R0            ;; THE NEXT OCTAL DIGIT
5603 032756 006001          ROR      R1
5604 032760 006000          ROR      R0
5605 032762 006001          ROR      R1
5606 032764 006000          ROR      R0

```



0330766 040302  
0330770 062702 000060  
0330774 000753  
0330776 000016

BIC R3,R2 ;;MASK OUT ALL JUNK  
ADD 0,R2 ;;MAKE THIS CHAR. ASCII  
BR 15 ;;GO PUT IT IN THE DATA TABLE  
\$OCTVL: .BLKB 14. ;;RESERVE DATA TABLE

.SBTTL TRAP DECODER

\*\*\*\*\*  
\*THIS ROUTINE WILL PICKUP THE LOWER BYTE OF THE "TRAP" INSTRUCTION  
\*AND USE IT TO INDEX THROUGH THE TRAP TABLE FOR THE STARTING ADDRESS  
\*OF THE DESIRED ROUTINE. THEN USING THE ADDRESS OBTAINED IT WILL  
\*GO TO THAT ROUTINE.

033014 010046  
033016 016600 000002  
033022 005740  
033024 111000  
033026 006300  
033030 016000 033050  
033034 000200

\$TRAP: MOV RO, -(SP) ;;SAVE RO  
MOV 2(SP),RO ;;GET TRAP ADDRESS  
TST -(RO) ;;BACKUP BY 2  
MOVB (RO),RO ;;GET RIGHT BYTE OF TRAP  
ASL RO ;;POSITION FOR INDEXING  
MOV \$TRPAD(RO),RO ;;INDEX TO TABLE  
RTS RO ;;GO TO ROUTINE

;;THIS IS USE TO HANDLE THE "GETPRI" MACRO

033036 011646  
033040 016556 000004 000002  
033046 000002

\$TRAP2: MOV (SP), -(SP) ;;MOVE THE PC DOWN  
MOV 4(SP), 2(SP) ;;MOVE THE PSW DOWN  
RTI ;;RESTORE THE PSW

.SBTTL TRAP TABLE

\*THIS TABLE CONTAINS THE STARTING ADDRESSES OF THE ROUTINES CALLED  
\*BY THE "TRAP" INSTRUCTION.

033050 033036  
033052 030752  
033054 031216  
033056 031172  
033060 031232  
033062 031420  
  
033064 031714  
  
033066 031644  
033070 032126  
033072 030162  
033074 032404  
033076 032442  
033100 027406  
000032

ROUTINE  
-----  
\$TRPAD: .WORD \$TRAP2  
\$TYPE ;;CALL=TYPE TRAP+1(104401) TTY TYPEOUT ROUTINE  
\$TYPOC ;;CALL=TYPOC TRAP+2(104402) TYPE OCTAL NUMBER (WITH LEADING ZEROS)  
\$TYPOS ;;CALL=TYPOS TRAP+3(104403) TYPE OCTAL NUMBER (NO LEADING ZEROS)  
\$TYPON ;;CALL=TYPON TRAP+4(104404) TYPE OCTAL NUMBER (AS PER LAST CALL)  
\$TYPDS ;;CALL=TYPDS TRAP+5(104405) TYPE DECIMAL NUMBER (WITH SIGN)  
  
\$GTSWR ;;CALL=GTSWR TRAP+6(104406) GET SOFT-SWR SETTING  
  
\$CKSWR ;;CALL=CKSWR TRAP+7(104407) TEST FOR CHANGE IN SOFT-SWR  
\$RDCHR ;;CALL=RDCHR TRAP+10(104410) TTY TYPEIN CHARACTER ROUTINE  
\$ROLIN ;;CALL=ROLIN TRAP+11(104411) TTY TYPEIN STRING ROUTINE  
\$SAVREG ;;CALL=SAVREG TRAP+12(104412) SAVE RO-R5 ROUTINE  
\$RESREG ;;CALL=RESREG TRAP+13(104413) RESTORE RO-R5 ROUTINE  
\$DSPLY ;;CALL=DISPLY TRAP+14(104414) ROUTINE TO TYPE ERROR MESSAGES  
  
\$TERM=-\$TRPAD

\*\*\*\*\*

RP04 5/6 MULTI-DRIVE EXERCISER  
"RAP" TABLE

5661  
5662  
5663  
5664  
5665  
5666  
5667  
5668  
5669  
5670  
5671  
5672  
5673  
5674  
5675  
5676  
5677  
5678  
5679  
5680  
5681  
5682  
5683  
5684  
5685  
5686  
5687  
5688  
5689  
5690  
5691  
5692  
5693  
5694  
5695  
5696  
5697  
5698  
5699  
5700  
5701  
5702  
5703  
5704  
5705  
5706  
5707  
5708  
5709  
5710  
5711  
5712  
5713  
5714

.SBTTL SINGLE/DUAL PORT RH11/RP04/5/6 DRIVER (REV 1.0)

:COPYRIGHT (C) 1976  
:DIGITAL EQUIPMENT CORP.  
:MAYNARD, MA 01754  
:AUTHOR(S): JIM LACEY/CHUCK HESS

::\*\*\*\*\*

:STORAGE FOR RPDS1, RPER1, RPER2, AND RPER3 ON AN ERROR "2"

:RPER1 = RPDS1  
:RPER2 = RPER1  
:RPER3 = RPER2  
:RPER4 = RPER3

033102 000000 000000 000000 RPER1: .WORD 0,0,0,0  
033110 000000

:TABLE OF DRIVE ACTIVE INDICATORS (DRVACT=8 BYTES)

:DRVACT=0 IF DRIVE IS IDLE  
:DRVACT>0 IF DRIVE IS ACTIVE WITH A COMMAND  
:DRVACT<0 IF DRIVE IS ACTIVE WITH AN ERROR RECOVERY OPERATION

033112 000 :DRVACT: .BYTE 0 :DRIVE 0  
033113 000 : .BYTE 0 :DRIVE 1  
033114 000 : .BYTE 0 :DRIVE 2  
033115 000 : .BYTE 0 :DRIVE 3  
033116 000 : .BYTE 0 :DRIVE 4  
033117 000 : .BYTE 0 :DRIVE 5  
033120 000 : .BYTE 0 :DRIVE 6  
033121 000 : .BYTE 0 :DRIVE 7

:TABLE OF DRIVE STATUS INDICATORS (DRVSTA=8 BYTES)

:DRVSTA=0 IF DRIVE IS OFFLINE OR NONEXISTENT  
:DRVSTA>0 IF DRIVE IS ONLINE  
:DRVSTA<0 IF DRIVE IS UNSAFE

033122 000 DRVSTA: .BYTE 0 :DRIVE 0  
033123 000 : .BYTE 0 :DRIVE 1  
033124 000 : .BYTE 0 :DRIVE 2  
033125 000 : .BYTE 0 :DRIVE 3  
033126 000 : .BYTE 0 :DRIVE 4  
033127 000 : .BYTE 0 :DRIVE 5  
033130 000 : .BYTE 0 :DRIVE 6  
033131 000 : .BYTE 0 :DRIVE 7

:TABLE OF DRIVE TYPES (DRVTP=8 BYTES)

:DRVTP=0 IF DRIVE IS NONEXISTENT (DRVSTA=0, ALSO)  
:DRVTP=1 IF DRIVE IS RP04  
:DRVTP=2 IF DRIVE IS RP05  
:DRVTP=4 IF DRIVE IS RP06  
:DRVTP=-1 IF NOT RP04/5/6

5715  
5716  
5717  
5718  
5719  
5720  
5721  
5722  
5723  
5724  
5725  
5726  
5727  
5728  
5729  
5730  
5731  
5732  
5733  
5734  
5735  
5736  
5737  
5738  
5739  
5740  
5741  
5742  
5743  
5744  
5745  
5746  
5747  
5748  
5749  
5750  
5751  
5752  
5753  
5754  
5755  
5756  
5757  
5758  
5759  
5760  
5761  
5762  
5763  
5764  
5765  
5766  
5767  
5768

DRVTYP: .BYTE 0 ;DRIVE 0  
          .BYTE 0 ;DRIVE 1  
          .BYTE 0 ;DRIVE 2  
          .BYTE 0 ;DRIVE 3  
          .BYTE 0 ;DRIVE 4  
          .BYTE 0 ;DRIVE 5  
          .BYTE 0 ;DRIVE 6  
          .BYTE 0 ;DRIVE 7

;TABLE OF DUAL PORT INITIALIZATION INDICATORS  
;DPINT=C IF INITIALIZATION IS NOT ACTIVE ON THE DRIVE  
;DPINT<C IF INITIALIZATION IS IN PROGRESS

DPINT: .BYTE 0 ;DRIVE 0  
          .BYTE 0 ;DRIVE 1  
          .BYTE 0 ;DRIVE 2  
          .BYTE 0 ;DRIVE 3  
          .BYTE 0 ;DRIVE 4  
          .BYTE 0 ;DRIVE 5  
          .BYTE 0 ;DRIVE 6  
          .BYTE 0 ;DRIVE 7

;TABLE OF PENDING DUAL PORT REQUESTS  
;DPRQS=0 IF THAT A DUAL PORT REQUEST IS NOT PENDING FOR THAT DRIVE  
;DPRQS<0 IF THAT A DUAL PORT REQUEST IS PENDING FOR THAT DRIVE

DPRQS: .BYTE 0 ;DRIVE 0  
          .BYTE 0 ;DRIVE 1  
          .BYTE 0 ;DRIVE 2  
          .BYTE 0 ;DRIVE 3  
          .BYTE 0 ;DRIVE 4  
          .BYTE 0 ;DRIVE 5  
          .BYTE 0 ;DRIVE 6  
          .BYTE 0 ;DRIVE 7

;TRANSFER WAIT FLAG (TRNSWT=1 WORD)  
;THIS IS A ONE WORD QUEUE. IT WILL CONTAIN THE ADDRESS OF  
;"DPB" OF THE I/O OPERATION.

TRNSWT: .WORD 0

;SEARCH WAIT KEYS (SRCHWT=1 WORD)  
;THIS IS A ONE WORD QUEUE THAT WILL CONTAIN A KEY FOR EACH OF  
;THE DRIVES THAT ARE PERFORMING A SEARCH COMMAND FOR THE I/O  
;REQUEST THAT IS AT THE TOP OF THEIR REQUEST QUEUE.  
;EACH DRIVE IS ASSIGNED ONE BIT, STARTING AT BIT00 FOR DRIVE 0.

SRCHWT: .WORD 0

;RPO4/5/6 DRIVER ACTIVE FLAG (ACTDRV=1 BYTE)  
;ACTDRV=0 IF DRIVER IS INACTIVE  
;ACTDRV>0 IF DRIVER IS ACTIVE

```

5769 033166 000 ACTDRV: .BYTE 0
5770 ;SOFTWARE TIMER ROUTINE ACTIVE FLAG (ACTSTR=1 BYTE)
5771 ;ACTSTR=0 IF SOFTWARE TIMER ROUTINE IS INACTIVE
5772 ;ACTSTR>0 IF SOFTWARE TIMER ROUTINE IS ACTIVE
5773
5774 033157 000 ACTSTR: .BYTE 0
5775 ;UNLOAD FLAG (ULDFLG=8 BYTES)
5776 ;ULDFLG=0 IF NO UNLOAD COMMAND
5777 ;ULDFLG>0 IF UNLOAD COMMAND IN PROGRESS
5778 ;ULDFLG<0 IF UNLOAD COMMAND IN WAIT QUEUE
5779
5780 033170 000 ULDFLG: .BYTE 0 ;DRIVE 0
5781 033171 000 .BYTE 0 ;DRIVE 1
5782 033172 000 .BYTE 0 ;DRIVE 2
5783 033173 000 .BYTE 0 ;DRIVE 3
5784 033174 000 .BYTE 0 ;DRIVE 4
5785 033175 000 .BYTE 0 ;DRIVE 5
5786 033176 000 .BYTE 0 ;DRIVE 6
5787 033177 000 .BYTE 0 ;DRIVE 7
5788
5789 ;LOOK AHEAD COUNT (LACNT=8 BYTES)
5790 ;LACNT WILL INDICATE THE NUMBER OF LOOK AHEADS PERFORMED
5791
5792 033200 000 LACNT: .BYTE 0 ;DRIVE 0
5793 033201 000 .BYTE 0 ;DRIVE 1
5794 033202 000 .BYTE 0 ;DRIVE 2
5795 033203 000 .BYTE 0 ;DRIVE 3
5796 033204 000 .BYTE 0 ;DRIVE 4
5797 033205 000 .BYTE 0 ;DRIVE 5
5798 033206 000 .BYTE 0 ;DRIVE 6
5799 033207 000 .BYTE 0 ;DRIVE 7
5800
5801 ;SAVE REGISTERS FLAG (SAVEFG =1 WORD)
5802 ;SAVEFG <0 IF SAVE THE RH11/RPO4/5/6 REGISTERS WHEN THE
5803 ;OPERATION IS COMPLETED AS PER (DPB+14).
5804 ;SAVEFG=0 IF SAVE THE RH11/RPO4/5/6 REGISTERS, AS PER
5805 ;(DPB+14), AFTER AN ERROR.
5806
5807 033210 000000 SAVEFG: .WORD 0
5808
5809 ;SEEK FLAG (SEEKFG=1 WORD)
5810 ;SEEKFG=0 IF WHEN THE DISK ADDRESS ISN'T IN THE WINDOW
5811 ;FOR A DATA TRANSFER START A SEARCH COMMAND
5812 ;SEEKFG<0 IF DATA TRANSFER WILL DO IMPLIED SEEKS,
5813 ;DISREGARD THE WINDOW
5814
5815 033212 000000 SEEKFG: .WORD 0
5816
5817 ;TIMEOUT TABLE (TIMER=8 WORDS)
5818 ;THIS TABLE CONTAINS THE TIME ALLOWED FOR AN OPERATION
5819
5820 033214 177777 TIMER: .WORD -1 ;DRIVE 0
5821
5822

```

5823 033216 177777  
 5824 033220 177777  
 5825 033222 177777  
 5826 033224 177777  
 5827 033226 177777  
 5828 033230 177777  
 5829 033232 177777  
 5830  
 5831  
 5832  
 5833  
 5834  
 5835 033234 177777  
 5836  
 5837  
 5838  
 5839  
 5840  
 5841 033236 001  
 5842 033237 002  
 5843 033240 004  
 5844 033241 010  
 5845 033242 020  
 5846 033243 040  
 5847 033244 100  
 5848 033245 200  
 5849  
 5850  
 5851  
 5852  
 5853 033246 000003  
 5854  
 5855  
 5856  
 5857  
 5858 033250 176700  
 5859 033252 000254 000240  
 5860  
 5861  
 5862  
 5863 033256 000004  
 5864  
 5865  
 5866 033260 001000  
 5867  
 5868  
 5869 033262 000200  
 5870  
 5871  
 5872 033264 000005  
 5873  
 5874  
 5875  
 5876 000000

.WORD -1 :DRIVE 1  
 .WORD -1 :DRIVE 2  
 .WORD -1 :DRIVE 3  
 .WORD -1 :DRIVE 4  
 .WORD -1 :DRIVE 5  
 .WORD -1 :DRIVE 6  
 .WORD -1 :DRIVE 7

;DATA TRANSFER UNDERWAY INDICATOR (DTUW=1 WORD)  
 ;DTUW<0 IF NO DATA TRANSFER UNDERWAY  
 ;DTUW=+N (WHERE N=0 TO 7) IMPLIES DATA TRANSFER UNDERWAY ON DRIVE N

DTUW: .WORD -1

;ATTENTION BITS TABLE (ATABIT=8 BYTES)  
 ;THIS TABLE CONTAINS THE CORRESPONDING BIT TO EACH DRIVES  
 ;ATTENTION BIT

ATABIT: .BYTE 1 :DRIVE 0  
 .BYTE 2 :DRIVE 1  
 .BYTE 4 :DRIVE 2  
 .BYTE 10 :DRIVE 3  
 .BYTE 20 :DRIVE 4  
 .BYTE 40 :DRIVE 5  
 .BYTE 100 :DRIVE 6  
 .BYTE 200 :DRIVE 7

;RPO4/5/6 TO RH11 "MASSBUS CONTROL BUS PARITY ERRORS" (MCPE) ALLOWED BEFORE  
 ;CALLING IT FATAL (MCPEMX=1 WORD)

MCPEMX: .WORD 3

;STORAGE FOR RPADR (THE FIRST ADDRESS (776700) OF THE RH11/RPO4/5/6),  
 ;RPVEC (THE VECTOR ADDRESS (254)), AND RPVEC+2 (THE BR LEVEL (5)).

RPADR: .WORD 176700  
 RPVEC: .WORD 254,5\*32.

;MAXIMUM NUMBER OF LOOK AHEADS ALLOWED IS 4 (MXLACT=1 WORD)

MXLACT: .WORD 4  
 ;MAXIMUM DELTA DELAY IS 8 SECTORS (MXDLTA=1 WORD)

MXDLTA: .WORD 8.\*64.  
 ;MINIMUM DELTA DELAY IS 2 SECTORS (MNDLTA=1 WORD)

MNDLTA: .WORD 2\*64.  
 ;MAXIMUM SEARCH FOR I/O WINDOW IS 5 SECTORS (MXWNDW=1 WORD)

MXWNDW: .WORD 5

;DEFINITIONS OF THE RH11/RPO4/5/6 ADDRESS INDEXES

RPCS1=0 ;CONTROL AND STATUS REGISTER #1 (DRIVE REG. 00)

5977	000002	RPWC=2	:WORD COUNT REGISTER (NOT A DRIVE REG)
5978	000004	RPBA=4	:UNIBUS ADDRESS REGISTER (NOT A DRIVE REG)
5979	000006	RPDA=6	:DESIRED SECTOR/TRACK ADDRESS REGISTER (DRIVE REG. 05)
5980	000010	RPCS2=10	:CONTROL AND STATUS REGISTER #2 (NOT A DRIVE REG)
5981	000012	RPDS1=12	:DRIVE STATUS REGISTER (DRIVE REG 01)
5982	000014	RPER1=14	:ERROR REGISTER #1 (DRIVE REG. 02)
5983	000016	RPAS=16	:ATTENTION SUMMARY PSEUDO REGISTER (DRIVE REG. 04)
5984	000020	RPLA=20	:LOOK AHEAD REGISTER (DRIVE REG. 07)
5985	000022	RPDB=22	:DATA BUFFER REGISTER (NOT A DRIVE REG.)
5986	000024	RPMR=24	:MAINTAINABILITY REGISTER (DRIVE REG. 03)
5987	000026	RPDT=26	:DRIVE TYPE REGISTER (DRIVE REG. 06)
5988	000030	RPSN=30	:SERIAL NUMBER REGISTER (DRIVE REG. 10)
5989	000032	RPOF=32	:OFFSET REGISTER (DRIVE REG. 11)
5990	000034	RPCA=34	:DESIRED CYLINDER ADDRESS REGISTER (DRIVE REG. 12)
5991	000036	RPCC=36	:CURRENT CYLINDER ADDRESS REGISTER (DRIVE REG. 13)
5992	000040	RPER2=40	:ERROR REGISTER #2 (DRIVE REG. 14)
5993	000042	RPER3=42	:ERROR REGISTER #3 (DRIVE REG. 15)
5994	000044	RPEC1=44	:ECC POSITION REGISTER (DRIVE REG. 16)
5995	000046	RPEC2=46	:ECC PATTERN REGISTER (DRIVE REG. 17)

```

;RH11/RPO4/5/6 DRIVER INITIALIZATION CODE
;THIS ROUTINE WILL DETERMINE WHICH RPO4/5/6 DRIVES ARE
;AVAILABLE FOR TESTING AND SET THE DRVSTA INDICATOR
;TO THE PROPER STATE FOR EACH DRIVE.
;NOTE: THIS ROUTINE CALLS DRVINT

```

:CALL

```

JSR PC,RPINIT
RETURN

```

:NOTE: THE 'P' OR 'L' CLOCK MUST BE STARTED

5910	033266	104412	RPINIT: SAVREG	:SAVE R0 - R5
5911	033270	013746	MOV 2*PS, -(SP)	:SAVE THE PRESENT PROCESSOR STATUS
5912	033274	012737	MOV #(<5*32.>), 2*PS	:CHANGE THE PRIORITY TO 5
5913	033302	004737	JSR PC,CLRQUE	:CLEAR ALL REQUEST QUEUES
5914	033306	012701	MOV #RPER1,R1	:FIRST ADDRESS TO BE CLEARED
5915	033312	012702	MOV #SEEKFG,R2	:LAST ADDRESS TO BE CLEARED
5916	033316	005021	1\$: CLR (R1)+	:CLEAR
5917	033320	020102	CMP R1,R2	:ARE WE DONE?
5918	033322	101775	BLOS 1\$	:BRANCH IF NO
5919	033324	012702	MOV #DTUW,R2	:LAST ADDRESS
5920	033330	012721	2\$: MOV #-1,(R1)+	:INITIALIZE
5921	033334	020102	CMP R1,R2	:DONE?
5922	033336	101774	BLOS 2\$	:LOOP IF NO
5923	033340	005037	CLR DRVSTA	:SET ALL DRIVES TO OFFLINE
5924	033344	005037	CLR DRVSTA+2	
5925	033350	005037	CLR DRVSTA+4	
5926	033354	005037	CLR DRVSTA+6	
5927	033360	013703	MOV RPVEC,R3	:SETUP THE RH11 RPO4/5/6 VECTOR
5928	033364	012723	MOV #ISR,(R3)+	
5929	033370	013713	MOV RPVEC+2,(R3)	
5930	033374	013704	MOV RPADR,R4	:FIRST ADDRESS OF RH11 RPO4

```

5931 033400 012764 000040 000010      MOV      #BIT05,RPCS2(R4)      ;MASSBUS INIT
5932 033406 005001                    CLR      R1                    ;START WITH DRIVE 0
5933 033410 004037 033500      3$:     JSR      RD,DRVINT          ;INIT THE DRIVE
5934 033414 000401                    BR       4$                    ;'DVA' NOT SET OR PARITY ERROR
5935 033416 000402                    BR       5$                    ;NORMAL RETURN
5936 033420 105061 033122      4$:     CLRB   DRVSTA(R1)        ;SET DRIVE STATUS TO OFFLINE
5937 033424 005201 033122      5$:     INC      R1                ;GO TO NEXT DRIVE
5938 033426 042701 177770      BIC      #1C7,R1              ;MASK OUT UNUSED BITS
5939 033432 001366                    BNE     3$                    ;BR IF MORE DRIVES TO GO
5940 033434 012701 000007      MOV      #7,R1                ;START WITH DRIVE 7
5941 033440 005037 177776      CLR      @#PS                 ;CLEAR THE PROCESSOR STATUS
5942 033444 105761 033142      6$:     TSTB   DPINT(R1)        ;WAITING FOR DRIVE TO SWITCH PORTS ?
5943 033450 001405                    BEQ     8$                    ;BR NOT WAITING
5944 033452 004737 041004      JSR      PC,SET.IE           ;SET INTERRUPT
5945 033456 105761 033142      7$:     TSTB   DPINT(R1)        ;DRIVE SWITCHED PORTS ?
5946 033462 001375                    BNE     7$                    ;BR IF NOT
5947 033464 005301 033142      8$:     DEC      R1                ;GO TO THE NEXT DRIVE
5948 033466 100366                    BPL     6$                    ;CHECK NEXT DRIVE
5949 033470 012637 177776      MOV      (SP)+,@#PS          ;RESTORE THE PROCESSOR STATUS
5950 033474 104413                    RESREG  ;RESTORE R0 - R5
5951 033476 000207                    RTS      PC                    ;BYE-BYE
5952
5953      ;DRIVE INITIALIZATION ROUTINE
5954      ;THIS ROUTINE DETERMINES IF A DRIVE EXIST AND IF IT IS
5955      ;AN RPO4/5/6. IF IT IS, A "READ-IN PRESET" IS ISSUED AND FMT22
5956      ;IS SET TO A "1". THEN MOL, DPR, DRY, AND VV ARE CHECKED TO
5957      ;INSURE THEY ARE ALL ON A "1". AND DEPENDING ON THEIR STATE,
5958      ;DRVSTA IS SET TO THE PROPER CONDITION.
5959
5960      ;CALL
5961      :
5962      :
5963      :
5964      :
5965      :
5966      :
5967      :
5968      :
5969      :
5970      :
5971      :
5972      :
5973      :
5974      :
5975      :
5976      :
5977      :
5978      :
5979      :
5980      :
5981      :
5982      :
5983      :
5984      :
5967 033500 010546                    DRVINT: MOV      R5,-(SP)        ;SAVE R5
5968 033502 105061 033122      CLRB   DRVSTA(R1)            ;START DRIVE STATUS AS OFFLINE
5969 033506 105061 033132      CLRB   DRVSTYP(R1)           ;CLEAR THE DRIVE TYPE INDICATOR
5970 033512 105061 033170      CLRB   ULDFLG(R1)            ;CLEAR THE UNLOAD FLAG
5971 033516 010164 000010      MOV      R1,RPCS2(R4)        ;SELECT A DRIVE
5972 033522 112764 000111 000000      MOVB   #111,RPCS1(R4)        ;DO A DRIVE CLEAR COMMAND (& SEIZE DRIVE)
5973 033530 032764 010000 000010      BIT    #BIT12,RPCS2(R4)      ;NONEXISTENT DRIVE?
5974 033536 001403                    BEQ     1$                    ;NO---BRANCH
5975 033540 004737 041004      JSR      PC,SET.IE           ;GO SET "IE" WITHOUT A "TRE"
5976 033544 000520                    BR       6$                    ;LEAVE THIS ROUTINE
5977 033546 105061 033122      1$:     CLRB   DRVSTA(R1)        ;SET DRIVE STATUS TO OFFLINE
5978 033552 032764 004000 000000      BIT    #BIT11,RPCS1(R4)      ;SEE IF DRIVE AVAILABLE
5979 033560 001514                    BEQ     7$                    ;BR IF DRIVE NOT AVAILABLE
5980 033562 004037 040324      JSR      RD,RD.RP            ;READ THE DRIVE TYPE REG.
5981 033566 000026                    RPTD   ;
5982 033570 034032                    8$:     ;ERROR RETURN ADDRESS
5983 033572 012605                    MOV      (SP)+,R5            ;PUT DRIVE TYPE IN R5
5984 033574 112761 000001 033132      MOVB   #1,DRVSTYP(R1)        ;SET RPO4 INDICATOR
    
```

```

5985 033602 022705 020020      CMP      #20020,R5      ;IS IT A SINGLE PORT RPO4?
5986 033606 001431      BEQ      2$          ;BRANCH IF YES
5987 033610 022705 024020      CMP      #24020,R5      ;IS IT A DUAL PORT RPO4?
5988 033614 001426      BEQ      2$          ;BR IF YES
5989 033616 112761 000002 033132      MOVB     #2,DRVTP(R1)  ;SET RPO5 INDICATOR
5990 033624 022705 020021      CMP      #20021,R5      ;SINGLE PORT RPO5 ?
5991 033630 001420      BEQ      2$          ;BR IF YES
5992 033632 022705 024021      CMP      #24021,R5      ;DUAL PORT RPO5 ?
5993 033636 001415      BEQ      2$          ;BR IF YES
5994 033640 112761 000004 033132      MOVB     #4,DRVTP(R1)  ;SET RPO6 INDICATOR
5995 033646 022705 020022      CMP      #20022,R5      ;SINGLE PORT RPO6 ?
5996 033652 001407      BEQ      2$          ;BR IF YES
5997 033654 022705 024022      CMP      #24022,R5      ;DUAL PORT RPO6 ?
5998 033660 001404      BEQ      2$          ;BR IF YES
5999 033662 112761 177777 033132      MOVB     #-1,DRVTP(R1) ;SET INDICATOR TO 'OTHER'
6000 033670 000446      BR       6$          ;EXIT
6001 033672 012746 000121      2$:     MOV      #121,-(SP)  ;DO A "READ-IN PRESET"
6002 033676 034037 040500      JSR      RO,WRT.RP
6003 033702 000000      RPCS1
6004 033704 034032      BS
6005 033706 012746 010000      MOV      #BIT12,-(SP)  ;SET FMT22=1
6006 033712 004037 040500      JSR      RO,WRT.RP
6007 033716 000032      RPOF
6008 033720 034032      BS
6009 033722 004037 040324      JSR      RO,RO.RP      ;READ RPDS1
6010 033726 000012      RPDS1
6011 033730 034032      BS
6012 033732 012605      MOV      (SP)+,R5      ;AND SAVE IT IN R5
6013 033734 100015      BPL      4$          ;BRANCH IF ATA=0
6014 033736 116164 033236 000016      MOVB     ATABIT(R1),RPAS(R4) ;CLEAR ATTENTION BIT
6015 033744 004037 040324      JSR      RO,RO.RP      ;FIND OUT WHY ATA=1
6016 033750 000014      RPER1
6017 033752 034032      BS
6018 033754 006126      ROL      (SP)+        ;IS IT UNSAFE?
6019 033756 100004      BPL      4$          ;BR IF NOT
6020 033760 112761 177777 033122      MOVB     #-1,DRVSTA(R1) ;SET UNSAFE INDICATOR
6021 033766 000407      BR       6$          ;EXIT
6022 033770 005105      4$:     COM      R5          ;CHECK MOL, DPR, DRY, AND VV
6023 033772 042705 167077      BIC      #C<BIT12!BIT09!BIT07!BIT06>,R5
6024 033776 001003      BNE      6$          ;BRANCH IF MOL, DPR, DRY, OR VV IS CLEAR
6025 034000 112761 000001 033122      MOVB     #1,DRVSTA(R1) ;SET DRIVE STATUS TO ONLINE
6026 034006 005720      6$:     TST      (RO)+      ;STEP OVER THE ERROR RETURN
6027 034010 000410      BR       8$          ;EXIT
6028 034012 006301      7$:     ASL      R1          ;CHANGE INDEX TO ADDRESS WORDS
6029 034014 012761 003720 033214      MOV      #2000.,TIMER(R1) ;START 2 SEC TIMER
6030 034022 006201      ASR      R1          ;RESTORE R1
6031 034024 112761 177777 033142      MOVB     #-1,DPINT(R1) ;SET PORT INITIALIZE INIDICATOR
6032 034032 012605      8$:     MOV      (SP)+,R5      ;RESTORE R5
6033 034034 000200      RTS      RO          ;EXIT
6034
6035      ;REQUEST PRE-PROCESSOR-HANDLES SUBSYSTEM REQUEST
6036      ;
6037      ;CALL
6038      ;
    
```



```

6039      :      JSR      RO, @RPO4      ;CALL THE RPO4/5/6 DRIVER
6040      :      PNTADR     ;ADDRESS OF POINTER OF DRIVES PARAMETER BLOCK
6041      :      RETURN1    ;RETURN HERE IF QUEUE IS FULL
6042      :      RETURN2    ;RETURN HERE IF REQUEST IS IN QUEUE OR THERE
6043      :      ;          ;IS AN ERROR CONDITION
6044
6045 034036 013746 177776 RPO4: MOV      @#PS, -(SP)      ;SAVE THE CALLING STATUS
6046 034042 013737 033254 177776 MOV      RPVEC+2, @#PS    ;DON'T ALLOW ANY RPO4/5/6 INTERRUPTS
6047 034050 112737 000001 033166 MOVVB   #1, ACTDRV      ;SET "ACTIVE DRIVER" FLAG
6048 034056 104412 SAVREG   ;SAVE RO - R5
6049 034060 011002 MOV      (RO), R2      ;PICKUP THE DRIVE PARAMETER BLOCK POINTER
E050 034062 005062 000016 CLR      16(R2)      ;CLEAR THE STATUS/ERROR INDICATOR
6051 034066 111201 MOVVB   (R2), R1      ;PICKUP THE DRIVE NUMBER
6052 034070 013704 033250 MOV      RPADR, R4    ;UNIBUS ADDRESS OF RPCS1
6053 034074 105761 033122 TSTB   DRVSTA(R1)    ;CHECK DRIVES STATUS
6054 034100 003014 BGT     1$          ;BRANCH IF ONLINE
6055 034102 105761 033170 TSTB   ULDFLG(R1)    ;UNLOAD COMMAND IN QUEUE?
6056 034106 001036 BNE     3$          ;BRANCH IF YES
6057 034110 105761 033142 TSTB   DPINT(R1)     ;TRYING TO INIT THE DRIVE
6059 034114 001042 BNE     5$          ;BR IF YES
6059 034116 004037 033500 JSR     RO, DRVINT    ;GO INIT. THE DRIVE
6060 034122 000434 BR      4$          ;ERROR RETURN
6061 034124 105761 033122 TSTB   DRVSTA(R1)    ;IS DRIVE STATUS ONLINE?
6062 034130 003445 BLE     6$          ;BR IF NOT
6063 034132 105761 033152 1$: TSTB   DPRQS(R1)    ;OUTSTANDING PORT REQUEST FOR THE DRIVE ?
6064 034136 001031 BNE     5$          ;BR IF YES
6065 034140 010164 000010 MOV      R1, RPCS2(R4) ;SELECT THE DRIVE
6066 034144 004037 041446 JSR     RO, DRVQUE    ;PUT THIS REQUEST IN QUEUE
6067 034150 000460 BR      9$          ;QUEUE IS FULL
6068 034152 122762 000103 000002 CMPB   #103, 2(R2)    ;IS THIS REQ. FOR AN UNLOAD?
6069 034160 001003 BNE     2$          ;BR IF NO
6070 034162 112761 177777 033170 MOVVB   #-1, ULDFLG(R1) ;SET THE "UNLOAD IN QUEUE" FLAG
6071 034170 105761 033112 2$: TSTB   DRVACT(R1)    ;IS THIS DRIVE ACTIVE?
6072 034174 001043 BNE     8$          ;BR IF YES
6073 034176 004737 034330 JSR     PC, OPT      ;CALL THE OPTIMIZER
6074 034202 000440 BR      8$
6075 034204 012762 120000 000016 3$: MOV      #BIT15!BIT13, 16(R2) ;SET THE "UNLOAD IN QUEUE" ERROR FLAG
6076 034212 000434 BR      8$          ;EXIT
6077 034214 004737 035440 4$: JSR     PC, CI7      ;GO HANDLE THE PARITY ERROR
6078 034220 000431 BR      8$
6079 034222 004037 041446 5$: JSR     RO, DRVQUE    ;PUT REQUEST IN QUEUE
6080 034226 000431 BR      9$          ;QUEUE IS FULL
6081 034230 032714 060100 BIT     #BIT06, (R4)  ;IS 'IE' SET ALREADY ?
6082 034234 001023 BNE     8$          ;BR IF IT IS
6083 034236 004737 041004 JSR     PC, SET.IE   ;SET INTERRUPT
6084 034242 000420 BR      8$          ;RETURN, REQUEST IN QUEUE
6085 034244 105761 033122 6$: TSTB   DRVSTA(R1)    ;SEE IF DRIVE OFFLINE OR UNSAFE
6086 034250 002412 BLT     7$          ;BR IF UNSAFE
6087 034252 012762 140000 000016 MOV      #BIT15!BIT14, 16(R2) ;SET OFFLINE ERROR INDICATOR
6088 034260 105761 033132 TSTB   DRVTP(R1)    ;SEE IF OFFLINE OR NONEXISTENT
6089 034264 001007 BNE     8$          ;BR IF OFFLINE
6090 034266 012762 100002 000016 MOV      #BIT15!BIT01, 16(R2) ;REPORT DRIVE NONEXISTENT
6091 034274 000403 BR      8$          ;GO TO EXIT
6092 034276 012762 110000 000016 7$: MOV      #BIT15!BIT12, 16(R2) ;DRIVE IS UNSAFE
    
```

```

6093 034304 104413          5$: RESREG          ;RESTORE R0 - R5
6094 034306 005720          TST      (R0)+      ;SETUP FOR NORMAL RETURN
6095 034310 000401          BR       10$        ;FINISH UP, THEN EXIT
6096 034312 104413          9$: RESREG          ;RESTORE R0 - R5
6097 034314 005720          10$: TST      (R0)+  ;CORRECT THE RETURN ADDRESS
6098 034316 105037 033166      CLR      ACTDRV     ;CLEAR "ACTIVE DRIVER" FLAG
6099 034322 012637 177776      MOV      (SP)+, @#PS ;RETURN "PS" TO USER LEVEL
6100 034325 000200          RTS      R0         ;RETURN TO CALLER

        ;OPTIMIZER-CALLED FOR A PARTICULAR DRIVE
        ;CALL
        ;MOV      #DRVNUM, R1      ;DRIVE NUMBER TO R1
        ;JSR      PC, OPT         ;SETUP A COMMAND
OPT:    SAVREG          ;SAVE R0 - R5
        MOV      @#PS, -(SP)      ;SAVE PROC. STATUS
        BIC      ATABIT(R1), SRCHWT ;CLEAR "SEARCH WAIT" KEY
        JSR      PC, GETREQ       ;GET "DPB" POINTER OF REQUEST
        TST      R2              ;IS THERE A REQUEST IN QUEUE?
        BEQ      7$              ;NO--BRANCH TO EXIT
        BIT      #BIT12, RPDS1(R4) ;IS MOL STILL SET?
        BEQ      9$              ;BR IF NOT
        BIT      #BIT6, RPDS1(R4) ;IS VV SET?
        BNE      10$             ;BR IF IT IS
        JSR      R0, DRVINT       ;SEE IF DRIVE STILL ONLINE?
        BR       6$              ;PARITY OR 'DVA' NOT SET
        TST      DRVSTA(R1)      ;IS DRIVE ONLINE?
        SET      1$              ;YES--BRANCH
        JSR      PC, POPQUE       ;NO--REMOVE REQUEST FROM QUEUE
        MOV      #BIT15!BIT14, 16(R2) ;SET OFFLINE STATUS/ERROR INDICATOR
        TST      DRVSTA(R1)      ;IS DRIVE UNSAFE?
        BPL      8$              ;BR TO EXIT IF NOT
        MOV      #BIT15!BIT12, 16(R2) ;SET UNSAFE STATUS/ERROR INDICATOR
        BR       8$              ;BRANCH TO EXIT
        MOV      #111, -(SP)      ;LOAD COMMAND ONTO THE STACK
        JSR      R0, WRT.RP       ;LOAD THE REGISTER
        RPS      1              ;REGISTER INCREMENT
        6$              ;ERROR RETURN ADDRESS
        BIT      #BIT11, (R4)     ;DRIVE AVAILABLE?
        BEQ      5$              ;BR IF NOT
        CMP      #150, 2(R2)      ;IS THE REQUEST FOR I/O?
        BLT      2$              ;YES--BRANCH
        JSR      PC, CI4          ;CALL THE COMMAND INITIATOR
        BR       8$              ;BRANCH TO EXIT
        TST      DTUW            ;DATA TRANSFER UNDERWAY?
        BGE      4$              ;YES--GO START A SEARCH
        TST      SEEKFG          ;DO IMPLIED SEEKS?
        BMI      3$              ;YES---BRANCH
        JSR      R0, LA          ;NO--DO LOOK AHEAD
        BR       8$              ;RETURN HERE ON A PARITY ERROR
        BR       4$              ;GO START A SEARCH
        JSR      PC, CI1         ;START A DATA TRANSFER
        BR       8$

```

```

6147 034532 004737 034716      4$: JSR    PC,C13      ;START A SEARCH
6148 034536 000420                BR      8$          ;GO TO THE EXIT
6149 034540 112761 177777 033152 5$: MOVB   #-1,DPRQS(R1) ;SET PORT REQUEST INDICATOR
6150 034546 010103                MOV     R1,R3       ;SET UP TO ADDRESS WORDS
6151 034550 006303                ASL    R3           ;CONVERT TO WORD INDEX
6152 034552 012763 023420 033214 MOV     #10000.,TIMER(R3) ;START 10 SEC TIMER
6153 034560 000402                BR      7$          ;EXIT
6154 034562 004737 035440      6$: JSR    PC,C17      ;PROCESS THE PARITY ERROR
6155 034566 032714 000100      7$: BIT    #BIT06,(R4) ;SEE IF 'IE' ALREADY SET
6156 034572 001002                BNE    8$          ;BR IF SET
6157 034574 004737 041004      JSR    PC,SET.IE    ;SET "IE" WITHOUT A "TRE"
6158 034600 012637 177776      8$: MOV     (SP)+,@#PS ;RESTORE PROC. STATUS
6159 034604 104413                RESREG ;RESTORE RO - R5
6160 034606 000207                RTS     PC

6151                ;COMMAND INITIATOR
6152                ;
6163                ;CALL
6164                ;
6165                ;MOV     #DRVNUM,R1      ;DRIVE NUMBER
6166                ;MOV     #DPB,R2        ;ADDRESS OF DPB
6167                ;JSR     PC,C1?       ;C1?= C11,C13, OR C14
6168                ;WHERE:
6169                ;C11=DATA TRANSFER
6170                ;C12=SEARCH REQUESTED BY DATA XFER
6171                ;C14=NOT DATA TRANSFER
6172                ;
6173 034610 004737 041544      C11: JSR    PC,POPQUE   ;REMOVE REQUEST FROM "DRIVES WAIT" QUEUE
6174 034614 010237 033162      MOV     R2,TRNSWT  ;PUT REQ. IN TRANSFER WAIT QUEUE
6175 034620 010203                MOV     R2,R3       ;DPB ADDRESS TO R3
6176 034622 013704 033250      MOV     RPADR,R4   ;RPCS1 ADDRESS
6177 034626 010164 000010      MOV     R1,RPCS2(R4) ;SELECT DRIVE
6178 034632 062703 000004      ADD     #4,R3       ;DESIRED WORD COUNT
6179 034636 062704 000002      ADD     #2,R4       ;RPWC ADDRESS
6180 034642 012324                MOV     (R3)+,(R4)+ ;LOAD WORD COUNT
6181 034644 012324                MOV     (R3)+,(R4)+ ;LOAD BUFFER ADDRESS
6182 034646 012346                MOV     (R3)+,-(SP) ;LOAD SECTOR AND TRACK
6183 034650 004037 040500      JSR    RO,WRT.RP   ;CALL THE LOAD(WRITE) ROUTINE
6184 034654 000006                RPDA    ;INDEX OF REGISTER TO LOAD
6185 034656 035440                C17     ;ERROR RETURN ADDRESS
6186 034660 012346                MOV     (R3)+,-(SP) ;LOAD CYLINDER ADDRESS
6187 034662 004037 040500      JSR    RO,WRT.RP
6188 034666 000034                RPCA    ;
6189 034670 035440                C17     ;
6190 034672 016246 000002      MOV     2(R2),-(SP) ;LOAD "COMMAND+GO", "A173A16", AND "PSEL"
6191 034676 004037 040500      JSR    RO,WRT.RP
6192 034702 000000                RPCS1   ;
6193 034704 035440                C17     ;
6194 034706 010137 033234      MOV     R1,DTUW    ;SET "DATA TRANSFER UNDERWAY"
6195 034712 000137 035402      JMP     C15        ;
6196 034716 013704 033250      C13: MOV     RPADR,R4   ;RPCS1 ADDRESS
6197 034722 010164 000010      MOV     R1,RPCS2(R4) ;SELECT DRIVE
6198 034726 016246 000012      MOV     12(R2),-(SP) ;DESIRED CYLINDER ADDRESS
6199 034732 004037 040500      JSR    RO,WRT.RP
6200 034736 000034                RPCA    ;

```

M12

6201	034740	035440			CI7		
6202	034742	116203	000010		MOVB	10(R2),R3	;PICKUP SECTOR ADDRESS
6203	034746	163703	033264		SUB	MXWINDW,R3	;BACKUP BY MAX. SEARCH FOR I/O WINDOW
6204	034752	002002			BGE	1\$	
6205	034754	062703	000026		ADD	#22.,R3	
6206	034760	010346		1\$:	MOV	R3,-(SP)	;COMBINE THE ADJUSTED SECTOR WITH
6207	034762	116266	000011	000001	MOVB	11(R2),1(SP)	;THE DESIRED TRACK
6208	034770	004037	040500		JSR	RO,WRT.RP	;LOAD DESIRED TRACK & SECTOR
6209	034774	000006			RPDA		
6210	034776	035440			CI7		
6211	035000	012746	000131		MOV	#131,-(SP)	;START A SEARCH
6212	035004	004037	040500		JSR	RO,WRT.RP	
6213	035010	000000			RPCS1		
6214	035012	035440			CI7		
6215	035014	156137	033236	033164	BISB	ATABIT(R1),SRCHWT	;SET "SEARCH WAIT" KEY
6216	035022	000567			BR	CI5	
6217	035024	013704	033250	CI4:	MOV	RPADR,R4	;RPCS1 ADDRESS
6218	035030	010164	000010		MOV	R1,RPCS2(R4)	;SELECT DRIVE
6219	035034	116203	000002		MOVB	2(R2),R3	;PICKUP THE REQUESTED COMMAND
6220	035040	122703	000131		CMPB	#131,R3	;IS IT A SEARCH COMMAND?
6221	035044	001007			BNE	1\$	;BRANCH IF NO
6222	035046	016246	000010		MOV	10(R2),-(SP)	;LOAD DESIRED TRACK & SECTOR
6223	035052	004037	040500		JSR	RO,WRT.RP	
6224	035056	000006			RPDA		
6225	035060	035440			CI7		
6226	035062	000403			BR	2\$	;GO LOAD CYLINDER
6227	035064	122703	000105	1\$:	CMPB	#105,R3	;IS IT A SEEK COMMAND
6228	035070	001007			BNE	3\$	;BRANCH IF NO
6229	035072	016246	000012	2\$:	MOV	12(R2),-(SP)	;LOAD DESIRED CYLINDER
6230	035076	004037	040500		JSR	RO,WRT.RP	
6231	035102	000034			RPCA		
6232	035104	035440			CI7		
6233	035106	000546			BR	CI6	
6234	035110	122703	000115	3\$:	CMPB	#115,R3	;IS IT AN "OFFSET" COMMAND?
6235	035114	001013			BNE	4\$	;BR IF NO
6236	035116	004037	040324		JSR	RO,RO.RP	;MERGE THE OFFSET VALUE INTO RPOF
6237	035122	000032			RPOF		;BUT DON'T CHANGE THE UPPER
6238	035124	035440			CI7		
6239	035126	116216	000001		MOVB	1(R2),(SP)	;BYTE WHEN LOADING THE
6240	035132	004037	040500		JSR	RO,WRT.RP	;REGISTER (RPOF)
6241	035136	000032			RPOF		
6242	035140	035440			CI7		
6243	035142	000530			BR	CI6	;GO START THE COMMAND
6244	035144	122703	000107	4\$:	CMPB	#107,R3	;IS IT A "RECALIBRATE" COMMAND?
6245	035150	001525			BEQ	CI6	;BRANCH IF YES
6246	035152	122703	000117		CMPB	#117,R3	;IS IT A RETURN TO CENTER?
6247	035156	001522			BEQ	CI6	;BRANCH IF YES
6248	035160	122703	000103		CMPB	#103,R3	;IS IT AN "UNLOAD" COMMAND?
6249	035164	001016			BNE	5\$	;BRANCH IF NO
6250	035166	112761	000001	033112	MOVB	#1,DRVACT(R1)	;SET THE DRIVE ACTIVE INDICATOR
6251	035174	105061	033122		CLRB	DRVSTA(R1)	;PUT DRIVE STATUS TO OFFLINE
6252	035200	112761	000001	033170	MOVB	#1,ULDFLG(R1)	;SET "UNLOAD IN PROGRESS" FLAG
6253	035206	010346			MOV	R3,-(SP)	;START THE "UNLOAD" COMMAND
6254	035210	004037	040500		JSR	RO,WRT.RP	

6255	035214	000000			RPCS1			
6256	035216	035440			CI7			
6257	035220	000207			RTS	PC		; RETURN TO USER
6258	035222	122703	000143		5\$: CMPB	#143,R3		; IS IT A "SET FORMAT" COMMAND?
6259	035226	001014			BNE	6\$		; BRANCH IF NO
6260	035230	004037	040324		JSR	RO,RO.RP		; READ THE OFFSET REGISTER
6261	035234	000032			RPOF			
6262	035236	035440			CI7			
6263	035240	116266	000001	000001	MOVB	1(R2),1(SP)		; COMBINE "FMT22", "ECI", AND "HCI"
6264	035246	004037	040500		JSR	RO,WRT.RP		; LOAD "FMT22", "ECI", AND/OR "HCI".
6265	035252	000032			RPOF			
6266	035254	035440			CI7			
6267	035256	000436			BR	12\$		
6268	035260	122703	000141		6\$: CMPB	#141,R3		; IS IT A "GET REGISTER" COMMAND?
6269	035264	001023			BNE	10\$		; BRANCH IF NO
6270	035266	016203	000006		7\$: MOV	6(R2),R3		; POINTS TO 1ST ADDRESS OF WHERE
6271								; TO PUT THE REGISTER(S)
6272	035272	116237	000010	035310	MOVB	10(R2),9\$		; INIT. THE INDEX FOR THE FIRST REG.
6273	035300	116205	000011		MOVB	11(R2),R5		; INDEX OF LAST REG. TO MOVE
6274	035304	004037	040324		8\$: JSR	RO,RO.RP		; READ RPO4/5/6 REGISTER
6275	035310	000000			9\$: RPCS1			; INDEX OF REG. TO READ
6276	035312	035440			CI7			
6277	035314	012623			MOV	(SP)+,(R3)+		; GET THE CONTENTS OF RH11/RPO4/5/6 REG.
6278	035316	023705	035310		9\$: CMP	R5		; LAST REG. BEEN READ?
6279	035322	001414			BEQ	12\$		; GET OUT IF YES
6280	035324	062737	000002	035310	ADD	#2,9\$		; INCREASE THE INDEX BY 2
6281	035332	000764			BR	8\$		; LOOP--MORE TO READ
6282	035334	122703	000145		10\$: CMPB	#145,R3		; IS IT A "SELECT DRIVE" COMMAND?
6283	035340	001405			BEQ	12\$		; BRANCH IF YES
6284	035342	010346			11\$: MOV	R3,-(SP)		; LOAD THE COMMAND
6285	035344	004037	040500		JSR	RO,WRT.RP		
6286	035350	000000			RPCS1			
6287	035352	035440			CI7			
6288	035354	004737	041544		12\$: JSR	PC,POPQUE		; REMOVE REG. FROM QUEUE
6289	035360	052762	000200	000016	BIS	#BIT07,16(R2)		; SET THE "DONE" BIT
6290	035366	005737	033210		TST	SAVEFG		; SAVE THE RH11/RPO4/5/6 REGISTERS?
6291	035372	100002			BPL	13\$		; BRANCH IF NO
6292	035374	004737	040666		JSR	PC,SVRH11		; YES--GO SAVE THE REGISTERS
6293	035400	000207			13\$: RTS	PC		; RETURN TO USER
6294	035402	006301			CI5: ASL	R1		
6295	035404	012761	001750	033214	MOV	#1000.,TIMER(R1)		; SET A ONE SECOND TIMER
6296	035412	006201			ASR	R1		
6297	035414	112761	000001	033112	MOVB	#1,DRVACT(R1)		; SET THE DRIVE ACTIVE
6298	035422	000207			RTS	PC		; RETURN TO THE USER
6299	035424	010346			CI6: MOV	R3,-(SP)		; LOAD THE COMMAND
6300	035426	004037	040500		JSR	RO,WRT.RP		
6301	035432	000000			RPCS1			
6302	035434	035440			CI7			
6303	035436	000761			BR	CI5		
6304	035440	032764	010000	000010	CI7: BIT	#BIT12,RPCS2(R4)		; DRIVE NON-EXISTENT ?
6305	035446	001034			BNE	CI8		; BR IF YES
6306	035450	005702			1\$: TST	R2		; ANYTHING IN QUEUE ?
6307	035452	001405			BEQ	CI7B		; BR IF NOT
6308	035454	012762	104000	000016	MOV	#BIT15!BIT11,16(R2)		; SET "PARITY" ERROR INDICATOR

6309	035462	004737	040666			JSR	PC,SVRH11	:GO SAVE THE RH11/RPO4/5/6 REGISTERS
6310	035466	012746	033111			MOV	#11,-(SP)	:DO A "DRIVE CLEAR"
6311	035472	004037	040500			JSR	RO,WRT.RP	
6312	035476	000000				RPCS1		
6313	035500	035540				CIB		
6314	035502	004737	041426			JSR	PC,EMPTYQ	:EMPTY THE QUEUE
6315	035506	105061	033170			CLRB	ULDFLG(R1)	:CLEAR THE UNLOAD IN QUEUE FLAG
6316	035512	105061	033112			CLRB	DRVACT(R1)	:DRIVE IS IDLE
6317	035516	020137	033234			CMP	R1,DTUW	:IF THIS DRIVE HAD AN I/O REQUEST
6318	035522	001005				BNE	IS	:IN PROGRESS CLEAR ALL OF THE FLAGS
6319	035524	005037	033162			CLR	TRNSWT	
6320	035530	012737	177777	033234		MOV	#-1,DTUW	
6321	035536	000207				RTS	PC	
6322	035540	104412				CIB:	SAVREG	:SAVE R0 - R5
6323	035542	032764	010000	000010		BIT	#BIT12,RPCS2(R4)	:IS 'NED' SET ?
6324	035550	001002				BNE	IS	:BR IF YES
6325	035552	005001				CLR	R1	
6326	035554	005003				CLR	R3	
6327	035556	105761	033112			TSTB	DRVACT(R1)	:DRIVE ACTIVE?
6328	035562	001443				BEQ	5\$	:BRANCH IF NO
6329	035564	013702	033162			MOV	TRNSWT,R2	:GET THE "TRANSFER WAIT" QUEUE
6330	035570	020137	033234			CMP	R1,DTUW	:DID THIS DRIVE HAVE AN I/O IN PROGRESS?
6331	035574	001402				BEQ	2\$	:BRANCH IF YES
6332	035576	004737	041522			JSR	PC,GETREQ	:GET THE CPB POINTER
6333	035602	005702				TST	R2	:QUEUE ENTRY FOR DRIVE ?
6334	035604	001415				BEQ	4\$	:BR IF NOT
6335	035606	032764	010000	000010		BIT	#BIT12,RPCS2(R4)	: 'NED' SET ?
6336	035614	001404				BEQ	3\$	:BR IF NOT
6337	035616	012762	100002	000016		MOV	#BIT15:BIT01,16(R2)	:SET 'DRIVE NON-EXISTENT' INDICATOR
6338	035624	000405				BR	4\$	:CONTINUE
6339	035626	012762	102000	000016	3\$:	MOV	#BIT15:BIT10,16(R2)	:SET "NON-CLEARABLE PARITY" ERROR INDICATOR
6340	035634	004737	040666			JSR	PC,SVRH11	:SAVE RH11/RPO4/5/6 REGISTERS
6341	035640	012763	177777	033214	4\$:	MOV	#-1,TIMER(R3)	:STOP THE TIMER
6342	035646	105061	033112			CLRB	DRVACT(R1)	:SET "DRIVE ACTIVE" TO IDLE
6343	035652	020137	033234			CMP	R1,DTUW	:IS THIS DRIVE SETUP FOR A TRANSFER
6344	035656	001005				BNE	5\$	:BR IF NOT
6345	035660	012737	177777	033234		MOV	#-1,DTUW	:RESET THE INDICATOR
6346	035666	005037	033162			CLR	TRNSWT	:CLEAR THE TRANSFER QUEUE
6347	035672	105061	033170		5\$:	CLRB	ULDFLG(R1)	:CLEAR UNLOAD FLAG
6348	035676	032764	010000	000010		BIT	#BIT12,RPCS2(R4)	: 'NED' SET ?
6349	035704	001021				BNE	6\$	:BR IF YES
6350	035706	005201				INC	R1	:MOVE TO THE NEXT DRIVE
6351	035710	062703	000002			ADD	#2,R3	
6352	035714	042701	177770			BIC	#7,R1	
6353	035720	001316				BNE	IS	:BRANCH IF MORE DRIVES
6354	035722	012737	177777	033234		MOV	#-1,DTUW	:NO DATA TRANSFERS UNDERWAY
6355	035730	005037	033162			CLR	TRNSWT	:CLEAR THE 'TRANSFER WAIT' QUEUE
6356	035734	004737	041350			JSR	PC,CLRQUE	:CLEAR ALL OF THE REQUEST QUEUES
6357	035740	012764	000040	000010		MOV	#BIT05,RPCS2(R4)	:DO A MASSBUS INIT.
6358	035746	000406				BR	7\$	:CONTINUE
6359	035750	004737	041426		6\$:	JSR	PC,EMPTYQ	:CLEAR THE DRIVE'S QUEUE
6360	035754	105061	033122			CLRB	DRVSTA(R1)	:SET DRIVE TO OFFLINE
6361	035760	105061	033132			CLRB	DRVTYP(R1)	:CLEAR THE DRIVE TYPE INDICATOR
6362	035764	004737	041004		7\$:	JSR	PC,SET.IE	:SET "IE" WITHOUT "TRE"

```

6363 035770 104413 RESREG :RESTORE R0 - R5
6364 035772 000207 RTS PC :RETURN
6365
6366 :LOOK AHEAD ROUTINE
6367
6368 :CALL
6369 :
6370 :MOV #DRVNUM,R1 :DRIVE NUMBER
6371 :MOV #DPB,R2 :POINT TO DPB
6372 :JSR RC,LA :GO CHECK THE WINDOW
6373 :RETURN1 :ERROR RETURN
6374 :RETURN2 :START A SEARCH
6375 :RETURN3 :START A DATA TRANSFER
6376
6377 LA: MOV RPADR,R4 :GET RPCS1'S ADDRESS
6378 MOV R1,RPCS2(R4) :SELECT DRIVE
6379 JSR RO,RO.RP :READ CURRENT CYLINDER
6380 RPCC
6381 4$ :ERROR RETURN ADDRESS
6382 036014 022662 000012 CMP (SP)+,12(R2) :IS CURRENT CYLINDER=DESIRED
6383 :CYLINDER?
6384 036020 001037 BNE 3$ :EXIT IF NO
6385 036022 105261 033200 INCB LACNT(R1) :INCREMENT THE LOOK AHEAD COUNT
6386 036026 126137 033200 033256 CMPB LACNT(R1),MXLACT :EXCEED MAX?
6387 036034 003026 BGT 2$ :BRANCH IF YES
6388 036036 116203 000010 MOVB 10(R2),R3 :GET DESIRED SECTOR ADDRESS AND
6389 036042 000303 SWAB R3 :MULT. BY 64--ALIGN WITH
6390 036044 006203 ASR R3 :LOOK AHEAD REGISTER
6391 036050 012737 000340 177776 ASR R3
6392 036056 004037 040324 MOV #340,3#PS :PRIORITY LEVEL "7"
6393 036062 000020 JSR RO,RO.RP :READ LOOK AHEAD REGISTER
6394 036064 036124 RPLA
6395 036066 162603 4$
6396 036070 002002 SUB (SP)+,R3 :CALCULATE THE DELTA
6397 036072 062703 002600 BGE 1$
6398 035076 023703 033250 1$: ADD #(22.*64.),R3 :MAKE THE DELTA POSITIVE
6399 036102 002406 CMP MXDLTA,R3 :CHECK THE DELTA TO SEE
6400 036104 023703 033262 BLT 3$ :IF IT IS WITHIN THE
6401 036110 002003 CMP MNDLTA,R3 :WINDOW---IF YES, ZERO
6402 036112 105061 033200 2$: CLRB LACNT(R1) :THE LOOK AHEAD COUNT
6403 036116 005720 TST (R0)+ :AND TAKE THE I/O EXIT
6404 036120 005720 3$: TST (R0)+ :ADJUST THE RETURN ADDRESS
6405 036122 000402 BR 5$ :EXIT
6406 036124 004737 035440 4$: JSR PC,C17 :PROCESS THE ERROR
6407 036130 000200 5$: RTS RO :RETURN
6408
6409 :INTERRUPT SERVICE ROUTINE
6410
6411 036132 112737 000001 033166 ISP: MOVB #1,ACTDRV :SET "ACTIVE DRIVER" FLAG
6412 036140 104412 SAVREG :SAVE R0 - R5
6413 036142 013704 033250 MOV RPADR,R4 :ADDRESS OF RHSCS1
6414 036146 013701 033234 MOV DTUW,R1 :GET "DATA TRANSFER UNDERWAY" INDICATOR
6415 036152 002403 BLT 1$ :BRANCH IF NO DATA TRANSFER UNDERWAY
6416 036154 004737 036176 JSR PC,TD :CALL TRANSFER DONE
    
```

```

6417 036160 000402          BR      2$          ;EXIT
6418 036162 004737 036460 1$:      JSR      PC,SC    ;CALL SPECIAL CONDITIONS
6419 036166 104413          2$:      RESREG    ;RESTORE R0 - R5
6420 036170 105037 033166          CLR      ACTDRV   ;CLEAR "ACTIVE DRIVER" FLAG
6421 036174 000002          RTI              ;RETURN
6422
6423          ;TRANSFER DONE ROUTINE
6424
6425 036176 105061 033112 TD:      CLR      DRVACT(R1) ;SET DRIVE ACTIVE INDICATOR TO IDLE
6426 036202 012737 177777 033234      MOV      #-1,DTUW ;NO DATA TRANSFERS UNDERWAY
6427 036210 006301          ASL      R1
6428 036212 012761 177777 033214      MOV      #-1,TIMER(R1) ;CANCEL TIMEOUT
6429 036220 006201          ASR      R1
6430 036222 013702 033162          MOV      TRANSW,R2 ;GET "DPB" ADDRESS FROM THE
6431 036226 005037 033162          CLR      TRANSW   ;TRANSFER WAIT QUEUE--CLEAR QUEUE
6432 036232 052762 000200 000016      BIS      #BIT07,16(R2) ;SET DONE
6433 036240 010164 000010          MOV      R1,RPCS2(R4) ;SELECT THE DRIVE
6434 036244 004037 040324          JSR      R0,RD.RP  ;TRANSFER ERROR(TRE=1)?
6435 036250 000000          RPCS1
6436 036252 035440          CI7
6437 036254 006126          ROL      (SP)+
6438 036256 100421          BMI      3$      ;BR IF YES
6439 036260 005737 033210          TST      SAVEFG   ;SAVE THE RH11/RPO4/5/6 REGISTERS?
6440 036264 100002          BPL      1$      ;BRANCH IF NO
6441 036266 004737 040666          JSR      PC,SVRH11 ;YES--SAVE THE REGISTERS
6442 036272 004737 036352 1$:      JSR      PC,WC    ;SEE IF WRITE CHECK TO BE PUT IN QUEUE
6443 036276 004737 041522          JSR      PC,GETREQ ;GET DPB POINTER
6444 036302 005702          TST      R2      ;ENTRY FOR DRIVE ?
6445 036304 001403          BEQ      2$      ;BR IF NOT
6446 036306 004737 034330          JSR      PC,OPT   ;CALL OPTIMIZER
6447 036312 000462          BR       SC      ;CHECK OTHER DRIVES
6448 036314 012714 000113 2$:      MOV      #113,(R4) ;RELEASE THE DRIVE
6449 036320 000457          BR       SC      ;CHECK FOR OTHER DRIVES
6450 036322 052762 100100 000016 3$:      BIS      #BIT15!BIT06,16(R2) ;SET DATA ERROR FLAG
6451 036330 004737 041426          JSR      PC,EMPTYQ ;EMPTY THE "DRIVE'S WAIT" QUEUE
6452 036334 004737 040666          JSR      PC,SVRH11 ;SAVE THE RH11/RPO4/5/6 REGISTERS
6453 036340 012714 040111          MOV      #40111,(R4) ;ISSUE A "DRIVE CLEAR"
6454 036344 012714 000113          MOV      #113,(R4) ;ISSUE A RELEASE TO THE DRIVE
6455 036350 000443          BR       SC      ;CHECK FOR OTHER DRIVES
6456
6457          ;FORCED WRITE CHECK ROUTINE
6458
6459 036352 005737 001404 WC:      TST      AUTOCK   ;AUTOMATIC WRITE CHECKS ?
6460 036356 001437          BEQ      2$      ;BR IF NOT
6461 036360 122762 000002 000024      CMPB    #2,$CODE(R2) ;LAST OPERATION WRITE DATA ?
6462 036366 001404          BEQ      1$      ;BR IF IT WAS
6463 036370 122762 000003 000024      CMPB    #3,$CODE(R2) ;LAST OPERATION WRITE HEADER & DATA ?
6464 036376 001027          BNE      2$      ;BR IF NOT
6465 036400 004037 041446 1$:      JSR      R0,DRVQUE ;PUT THE OPERATION IN THE QUEUE
6466 036404 000424          BR       2$      ;QUEUE IS FULL
6467 036406 005062 000016          CLR      16(R2)   ;CLEAR "DONE" BIT IN DPB
6468 036412 116262 000234 000027      MOV      $RPCS1(R2),$PREV0(R2) ;SAVE WRITE OPERATION CODE
6469 036420 016262 000012 000034      MOV      $CYL(R2),$PREVA+2(R2) ;SAVE CYLINDER
6470 036426 016262 000010 000032      MOV      $SEC(R2),$PREVA(R2) ;SAVE SECTOR AND TRACK ADDRESSES
    
```



```

6471 036434 142762 000002 000024 BICB #2,$CODE(R2) ;CHANGE WRITE TO CHECK
6472 036442 142762 000020 000002 BICB #20,$COMND(R2) ;CHANGE DRIVER CODE TO WRITE CHECK
6473 036450 152762 000010 000002 BISB #10,$COMND(R2) ;FINISH CHANGING CODE TO WRITE CHECK
6474 036456 000207 2$: RTS PC ;EXIT
6475
6476 ;SPECIAL CONDITION ROUTINE
6477
6478 036460 116403 000016 5C: MOVB RPAS(R4),R3 ;READ "RPAS"
6479 036464 001012 BNE 2$ ;BRANCH IF ANY 'ATA' BITS SET
6480 036466 004037 040324 JSR RD,RD.RP ;READ CONTROL AND STATUS REGISTER
6481 036472 000000 RPCS1
6482 036474 035540 CIB
6483 036476 106126 ROLB (SP)+ ;IS "IE"=1?
6484 036500 100403 BMI 1$ ;YES, NO DRIVES TO CHECK
6485 036502 104001 ERROR 1 ;REPORT AN ILLEGAL INTERRUPT
6486 036504 004737 041004 JSR PC,SET.IE ;SET INTERRUPT ENABLE
6487 036510 000207 1$: RTS PC ;RETURN
6488 036512 005046 2$: CLR -(SP) ;PROCESS ALL DRIVES THAT HAVE
6489 036514 110316 MOVB R3,(SP) ;AN "ATA"=1
6490 036516 012703 000001 MOV #1,R3
6491 036522 005001 CLR R1
6492 036524 030316 5C3: BIT R3,(SP) ;ATA=1?
6493 036526 001005 BNE 5C5 ;YES--BRANCH
6494 036530 005001 5C4: INC R1 ;MOVE TO THE NEXT DRIVE
6495 036532 106303 ASLB R3
6496 036534 001373 BNE 5C3 ;BRANCH IF MORE TO CHECK?
6497 036536 005726 TST (SP)+ ;CLEAN OFF THE STACK
6498 036540 000207 RTS PC ;RETURN TO USER
6499 036542 105761 033142 5C5: TSTB DPINT(R1) ;INITIALIZING THE DRIVE ?
6500 036544 001402 BEQ 1$ ;BR IF NOT
6501 036550 000137 037436 JMP SC13 ;PROCESS THE DRIVE
6502 036554 105761 033152 1$: TSTB DPRQS(R1) ;PORT REQUEST OUTSTANDING ?
6503 036560 001402 BEQ 2$ ;BR IF NOT
6504 036562 000137 037436 JMP SC13 ;START THE OUTSTANDING COMMAND
6505 036564 105761 033122 2$: TSTB DRVSTA(R1) ;CHECK THE DRIVE STATUS
6506 036572 003025 BGT 5$ ;BRANCH IF ONLINE
6507 036574 105761 033170 TSTB ULDFLG(R1) ;UNLOAD IN PROGRESS?
6508 036600 002422 BLE 5$ ;BRANCH IF NOT
6509 036602 004737 041522 JSR PC,GETREG ;GET DPB POINTER
6510 036606 004737 040666 JSR PC,SVF,11 ;SAVE THE RH11/RPO4/5/6 REGISTERS
6511 036612 004737 037366 JSR PC,SC12 ;SAVE RPS1, RPER1, RPER2, AND RPER3
6512 ;ALSO DO A DRIVE INIT (DRVINT)
6513 036616 105761 033122 TSTB DRVSTA(R1) ;DID DRIVE COME ONLINE?
6514 036622 003416 BLE 6$ ;NO---BRANCH
6515 036624 032737 040000 033102 BIT #BIT14,RPERRS ;WAS THERE AN ERROR?
6516 036632 001002 BNE 3$ ;BR IF ERROR
6517 036634 000137 037276 JMP SC11 ;NO ERROR
6518 036640 013705 033104 3$: MOV RPERRS+2,R5 ;YES -- PICKUP RPER1 AND
6519 036644 000476 BR SC6A ;GO PROCESS THE ERROR
6520 036646 105761 033112 5$: TSTB DRVACT(R1) ;DRIVE ACTIVE WITH COMMAND OR ERROR RECOVERY ?
6521 036652 001027 BNE SC6 ;BR IF EITHER
6522 036654 004737 037366 JSR PC,SC12 ;SAVE RPS1, RPER1, RPER2, AND RPER3
6523 ;ALSO DO A DRVINT
6524 036660 105761 033142 6$: TSTB DPINT(R1) ;TRYING TO INIT THE DRIVE ?

```

6525	036664	001321			BNE	SC4		;BR IF YES, CHECK ON MORE DRIVES
6526	036666	105761	033122		TSTB	DRVSTA(R1)		;CHECK ON DRIVE'S STATUS
6527	036672	100412			BMI	7\$		;BR IF UNSAFE
6528	036674	032737	020000	033110	BIT	#BIT13,RPERRS+6		;ADDRESS PLUG CHANGED ?
6529	036702	001011			BNE	9\$		;BR IF YES
6530	036704	012746	000113		MOV	#113,-(SP)		;RELEASE COMMAND
6531	036710	004037	040500		JSR	RD,WRT.RP		;WRITE THE COMMAND INTO RPCS1
6532	036714	000000			RPCS1			;REGISTER INDEX
6533	036716	037246			SC8			;PARITY EXIT ADDRESS
6534	036720	011605		7\$:	MOV	(SP),R5		;PICKUP (RPAS) BEFORE THE ERROR CALL
6535	036722	104002			ERROR	2		;REPORT THE UNEXPECTED ATTENTION
6536	036724	000701			BR	SC4		;GO CHECK FOR MORE ATA'S
6537	036726			8\$:				
6538	036726	104005			ERROR	5		;REPORT THE ADDRESS PLUG CHANGE
6539	036730	000677			BR	SC4		;CHECK FOR MORE DRIVES
6540	036732	006301			ASL	R1		;SETUP TO ADDRESS WORDS
6541	036734	012761	177777	033214	MOV	#-1,TIMER(R1)		;STOP THE TIMER
6542	036742	006201			ASR	R1		;RESTORE THE DRIVE ADDRESS
6543	036744	004737	041522		JSR	PC,GETREQ		;GET THE DPB POINTER FROM THE QUEUE
6544	036750	010164	000010		MOV	R1,RPCS2(R4)		;SELECT DRIVE
6545	036754	004037	040324		JSR	RD,RD.RP		;READ THE RPO4'S STATUS REG.
6546	036760	000012			RPDS1			
6547	036762	037246			SC8			
6548	036764	011605			MOV	(SP),R5		;AND PUT IT IN R5
6549	036766	006126			ROL	(SP)+		;WAS THERE AN ERROR?
6550	036770	100407			BMI	1\$		;BR IF ERROR
6551	036772	105761	033112		TSTB	DRVACT(R1)		;CHECK DRIVE'S STATE
6552	036774	003137			BGT	SC11		;BR IF DRIVE ACTIVE WITH ORDER
6553	03700	052762	100210	000016	BIS	#BIT15!BIT07!BIT03,16(R2)		;INFORM USER OF ERROR RECOVER COMPLETION
6554	037006	000470			BR	SC7		
6555	037010	004037	040324		JSR	RD,RD.RP		;READ ERROR REGISTER #1
6556	037014	000014		1\$:	RPERR1			
6557	037016	037246			SC8			
6558	037020	012605			MOV	(SP)+,R5		;AND SAVE IT IN R5
6559	037022	004737	040666		JSR	PC,SVRH11		;SAVE RH11/RPO4/5/6 REGISTERS
6560	037026	012746	000111		MOV	#111,-(SP)		;ISSUE A DRIVE CLEAR
6561	037032	004037	040500		JSR	RD,WRT.RP		
6562	037036	000000			RPCS1			
6563	037040	037246			SC8			
6564	037042	006105		SC6A:	ROL	R5		;WAS "UNSAFE" CONDITION =1?
6565	037044	100406			BMI	1\$		;BRANCH IF YES
6566	037046	005702			TST	R2		;ANYTHING IN QUEUE ?
6567	037050	001447			BEQ	SC7		;BR IF NOT
6568	037052	052762	100240	000016	BIS	#BIT15!BIT07!BIT05,16(R2)		;INFORM USER OF ERROR
6569	037060	000443			BR	SC7		
6570	037062	004037	040324		JSR	RD,RD.RP		;READ DRIVE STATUS REG. #1
6571	037066	000012		1\$:	RPDS1			
6572	037070	037246			SC8			
6573	037072	011605			MOV	(SP),R5		;SAVE RPDS1 IN R5
6574	037074	006126			ROL	(SP)+		; "ERR"=1?
6575	037076	100011			BPL	2\$		;BR IF NO--UNSAFE CLEARED
6576	037100	112761	177777	033122	MOV	#-1,DRVSTA(R1)		;DRIVE IS UNSAFE
6577	037106	004737	040666		JSR	PC,SVRH11		;SAVE RH11/RPO4/5/6 REGISTERS
6578	037112	052762	110000	000016	BIS	#BIT15!BIT12,16(R2)		;INFORM USER OF UNSAFE ERROR

```

6579 037120 000423          BR          SC7
6580 037122 032705 010000      2$: BIT      #BIT12,R5          ;"MOL" = 1 ?
6581 037126 001015          BNE         3$          ;BR IF YES
6582 037130 112761 177777 033112      MOVB      #-1,DRVACT(R1) ;ACTIVE ERROR RECOVER
6583 037136 112761 000001 033122      MOVB      #1,DRVSTA(R1) ;ONLINE
6584 037144 006301          ASL         R1
6585 037146 012761 072460 033214      MOV       #30000.,TIMER(R1) ;START 30 SECOND TIMER
6586 037154 006201          ASR         R1
6587 037156 000137 036530      JMP        SC4
6588 037162 052762 100220 000016 3$: BIS      #BIT15!BIT07!BIT04,16(R2) ;INFORM USER OF ERROR
6589 037170 105061 033112      SC7: CLRB   DRVACT(R1)      ;DRIVE IS IDLE
6590 037174 004737 041426      JSR       PC,EMPTYQ      ;DUMP THE QUEUE
6591 037200 105761 033170      TSTB    ULDFLG(R1)      ;UNLOAD IN PROGRESS OR QUEUE?
6592 037204 003002          BGT        1$          ;BR IF NOT
6593 037206 105061 033170      CLRB    ULDFLG(R1)      ;CLEAR UNLOAD FLAG
6594 037212 116164 033236 000016 1$: MOVB   ATABIT(R1),RPAS(R4) ;CLEAR ATTENTION BIT
6595 037220 105761 033122      TSTB    DRVSTA(R1)      ;IS THE DRIVE UNSAFE ?
6596 037224 100406          BMI        2$          ;BR IF IT IS
6597 037226 012746 000113      MOV       #113,-(SP)     ;RELEASE COMMAND
6598 037232 004037 040500      JSR      RO,WRT.RP      ;WRITE THE COMMAND INTO RPCS1
6599 037236 000000          RPCS1
6600 037240 037246          SCB
6601 037242 000137 036530      2$: JMP     SC4          ;CHECK FOR MORE DRIVES
6602 037246 105761 033112      SC8: TSTB   DRVACT(R1)    ;IS DRIVE IDLE?
6603 037252 001405          BEQ       1$          ;YES--BRANCH
6604 037254 004737 041522      JSR      PC,GETREQ      ;GET DPB POINTER
6605 037260 004737 035440      JSR      PC,CI7        ;PROCESS THE PARITY ERROR
6606 037264 000402          BR        2$          ;CONTINUE
6607 037266 004737 035466      1$: JSR    PC,CI7B       ;PROCESS THE UNCORRECTABLE PARITY ERROR
6608 037272 000137 036530      2$: JMP     SC4          ;CHECK MORE DRIVES
6609 037276 105761 033170      SC11: TSTB  ULDFLG(R1)    ;"UNLOAD IN PROGRESS"?
6610 037302 003402          BLE       1$          ;BRANCH IF NO
6611 037304 105061 033170      CLRB    ULDFLG(R1)      ;CLEAR UNLOAD FLAG
6612 037310 105061 033112      1$: CLRB   DRVACT(R1)    ;SET DRIVE IDLE
6613 037314 136137 033236 033164      BITB    ATABIT(R1),SRCHWT ;DOING A SEARCH OPERATION FOR
6614                                     ;AN I/O COMMAND?
6615 037322 001012          BNE       2$          ;BRANCH IF YES
6616 037324 004737 041544      JSR      PC,POPQUE      ;REMOVE REQUEST FROM QUEUE
6617 037330 052762 000200 000016      BIS     #BIT07,16(R2)   ;SET "DONE" BIT
6618 037336 005737 033210      TST     SAVEFG          ;SAVE THE REGISTERS?
6619 037342 100002          BPL       2$          ;BRANCH IF NO
6620 037344 004737 040666      JSR      PC,SVRH11     ;YES--SAVE ALL OF THE RH11/RPO4/5/6 REG'S
6621 037350 116164 033236 000016 2$: MOVB   ATABIT(R1),RPAS(R4) ;CLEAR ATTENTION BIT
6622 037356 004737 034330      JSR      PC,OPT        ;START A REQUEST
6623 037362 000137 036530      JMP     SC4          ;CHECK FOR MORE DRIVES
6624 037366 010164 000010      SC12: MOV   R1,RPCS2(R4)  ;SELECT DRIVE
6625 037372 016437 000012 033102      MOV   RPD51(R4),RPERRS  ;SAVE THE FOUR REGISTERS THAT
6626 037400 016437 000014 033104      MOV   RPER1(R4),RPERRS+2 ;WILL TELL US SOMETHING
6627 037406 016437 000040 033106      MOV   RPER2(R4),RPERRS+4
6628 037414 016437 000042 033110      MOV   RPER3(R4),RPERRS+6
6629 037422 004037 033500      JSR      RO,DRVINT     ;INIT. THE STATE OF THE DRIVE
6630 037426 000401          BR        1$          ;TAKE ERROR EXIT
6631 037430 000207          RTS      PC           ;RETURN
6632 037432 005726      1$: TST   (SP)+        ;POP PC OFF OF THE STACK

```

```

6633 037434 000704          BR      SC8      ;PROCESS THE PARITY ERROR
6634 037436 006301          ASL     R1      ;SETUP TO ADDRESS WORDS
6635 037440 012761 177777 033214 SC13:  MOV     #-1,TIMER(R1) ;STOP THE TIMER
6636 037446 006201          ASR     R1      ;
6637 037450 010164 000010        MOV     R1,RPCS2(R4) ;SELECT THE DRIVE
6638 037454 116164 033236 000016        MOVVB  ATABIT(R1),RPAS(R4) ;CLEAR THE ATTENTION BIT
6639 037462 032714 004000        BIT     #BIT11,(R4) ;DRIVE AVAILABLE ?
6640 037466 001006          BNE     1$      ;BR IF AVAILABLE
6641 037470 006301          ASL     R1      ;
6642 037472 012761 023423 033214        MOV     #10000.,TIMER(R1) ;START 10 SEC TIMER AGAIN
6643 037500 006201          ASR     R1      ;
6644 037502 000433          BR      3$      ;EXIT
6645 037504 105761 033142          1$:  TSTB   DPINT(R1) ;INITIALIZING THE DRIVE ?
6646 037510 001424          BEQ     2$      ;BR IF NOT
6647 037512 105061 033142          CLRB   DPINT(R1) ;CLEAR THE INIT INDICATOR
6648 037516 004037 033500          JSR    RO,DRVINT ;GO INIT THE DRIVE
6649 037522 000240          NOP     ;DUMMY PARITY ERROR RETURN
6650 037524 105761 033122          TSTB   DRVSTA(R1) ;DRIVE ONLINE ?
6651 037530 003014          BGT     2$      ;BR IF YES -- START ORDER
6652 037532 005702          TST    R2      ;QUEUE ENTRY FOR THE DRIVE
6653 037534 001416          BEQ     3$      ;BR IF NOT
6654 037536 004737 041522          JSR    PC,GETREQ ;GET DPB ADDRESS
6655 037542 052762 140000 000016        BIS    #BIT15:BIT14,16(R2) ;INFORM USER THAT DRIVE OFFLINE
6656 037550 004737 040666          JSR    PC,SVRH11 ;SAVE THE REGISTERS
6657 037554 004737 041426          JSR    PC,EMPTYQ ;EMPTY THE REQUEST QUEUE
6658 037560 000404          BR      3$      ;
6659 037562 105061 033152          2$:  CLRB   DPRQS(R1) ;CLEAR THE PORT REQUEST INDICATOR
6660 037566 004737 034330          JSR    PC,OPT   ;START THE PENDING REQUEST
6661 037572 000137 036530          3$:  JMP     SC4      ;PROCESS OTHER DRIVES
6662
6663          ;RPO4/5/6 TIMER ROUTINE
6664          ;CALL
6665          ;
6666          ;      MOV     #TIME,-(SP) ;ELAPSED TIME IN MILLISECONDS ON THE STACK
6667          ;      JSR    PC,RPTMR ;CALL RPO4/5/6 TIME ROUTINE
6668 037576 005737 033166          RPTMR: TST     ACTDRV ;CHECK "ACTDRV & ACTSTR"
6669 037602 001030          BNE     4$      ;IF NON ZERO EXIT
6670 037604 112737 000001 033167        MOVVB  #1,ACTSTR ;SET "ACTSTR"
6671 037612 104412          SAVREG ;SAVE R0 - R5
6672 037614 005001          CLR     R1      ;START WITH DRIVE 0
6673 037616 005003          CLR     R3      ;
6674 037620 005763 033214          1$:  TST     TIMER(R3) ;IS THE TIMER RUNNING?
6675 037624 002407          BLT     2$      ;BRANCH IF NO
6676 037626 166663 000002 033214        SUB     2(SP),TIMER(R3) ;COUNT THE INTERVAL
6677 037634 003003          BGT     2$      ;BR IF NO SOFTWARE TIMEOUT
6678 037636 004737 037670          JSR    PC,STC   ;CALL SOFTWARE TIMEOUT ROUTINE
6679 037642 000405          BR      3$      ;GO TO THE EXIT
6680 037644 005201          2$:  INC     R1      ;MOVE TO NEXT DRIVE
6681 037646 005723          TST    (R3)+   ;
6682 037650 022701 000010        CMP     #8.,R1  ;OUT OF DRIVES?
6683 037654 003361          BGT     1$      ;BRANCH IF NO
6684 037656 104413          3$:  RESREG ;RESTORE R0 - R5
6685 037660 105037 033167        CLRB   ACTSTR  ;ZERO ACTIVE SOFTWARE TIMEOUT ROUTINE FLAG
6686 037664 012616          4$:  MOV     (SP)+,(SP) ;ADJUST THE STACK
    
```

```

6687 037666 000207          RTS      PC          ;RETURN
6688
6689          :SOFTWARE TIMEOUT ROUTINE
6690          :
6691          :NOTE: THIS ROUTINE MUST BE ENTERED AT PRIORITY 6
6692          :      OR GREATER
6693          :
6694          :CALL:  STO      PC          ;DRIVE NUMBER
6695          :      MOV      #DRVNUM,R1  ;DRIVE NUMBER
6696          :      JSR      PC,STO      ;CALL
6697          :
6698          :
6699          STO:  MOV      R1, -(SP)   ;SAVE R1
6700          MOV      R3, -(SP)   ;SAVE R3
6701          MOV      RPADR,R4     ;GET ADDRESS OF "RPCS1"
6702          MOV      R1,RPCS2(R4) ;SELECT THE DRIVE
6703          JSR      RD, RD.RP     ;READ "DRIVE STATUS REG"
6704          RPODS1
6705          STOS
6706          TSTB     (SP)+        ;IS "DRY"=1?
6707          BMI      ST02         ;BR IF YES
6708          ST01: TSTB     DPINT(R1) ;TRYING TO INTIALIZE THE DRIVE ?
6709          BNE      ST02         ;BR IF YES
6710          TSTB     DPRQS(R1)   ;OUTSTANDING PORT REQUEST FOR THE DRIVE ?
6711          BNE      ST02         ;BR IF YES
6712          MOV      TRANSW,R2    ;PICKUP TRANSFER WAIT QUEUE
6713          CMP      R1,DTUW      ;TRANSFER UNDERWAY ON THIS DRIVE?
6714          BEQ      1$          ;BRANCH IF YES
6715          JSR      PC,GETREQ    ;GET DPB ADDRESS
6716          BIS      #BIT15:BIT09,16(R2) ;SET THE ERROR FLAGS
6717          JSR      PC,SVRH11    ;SAVE RH11/RPO4/5/6 REGISTERS
6718          MOV      #BIT05,RPCS2(R4) ;"INIT" THE MASS BUS
6719          CLRB     DRVACT(R1)   ;DRIVE IS IDLE
6720          CLRB     ULDFLG(R1)  ;CLEAR THE UNLOAD FLAG
6721          CLR      R1           ;START WITH DRIVE 0
6722          CLR      R3
6723          JSR      RD,DRVINT    ;INIT. THIS DRIVE
6724          BR       ST05         ;PARITY ERROR RETURN
6725          TSTB     DRVACT(R1)  ;DRIVE IDLE BEFORE THE INIT."
6726          BEQ      4$          ;YES--BRANCH
6727          MOV      TRANSW,R2    ;GET TRANSFER WAIT QUEUE
6728          CMP      DTUW,R1     ;WAS THERE I/O ON THIS DRIVE?
6729          BEQ      3$          ;YES--BRANCH
6730          JSR      PC,GETREQ    ;GET THE DPB POINTER FROM QUEUE
6731          BIS      #BIT15:BIT08,16(R2) ;INFORM USER OF INIT.
6732          CLRB     DRVACT(R1)  ;SET DRIVE ACTIVE TO IDLE
6733          CLRB     ULDFLG(R1)  ;NO UNLOAD
6734          MOV      #-1,TIMER(R3) ;STOP THE TIMER
6735          TST      (R3)+        ;UPDATE THE INDEX
6736          INC      R1           ;INCREMENT THE DRIVE NUMBER
6737          CMP      #8.,R1      ;LAST DRIVE BEEN CHECKED?
6738          BGT      2$          ;NO--LOOP
6739          MOV      #-1,DTUW    ;NO DATA TRANSFERS UNDERWAY
6740          CLR      TRANSW      ;CLEAR TRANSFER WAIT QUEUE

```

```

6741 040110 004737 041350 JSR PC,CLRQUE ;CLEAR ALL REQUEST QUEUES
6742 040114 000500 BR ST09 ;EXIT
6743 040116 116405 000016 ST02: MOVB RPAS(R4),R5 ;READ ATTENTION REG
6744 040122 136105 033236 BITB ATABIT(R1),R5 ;IS ATTENTION FOR THIS DRIVE UP ?
6745 040126 001017 BNE ST03 ;YES--BRANCH
6746 040130 105761 033142 TSTB DPINT(R1) ;TRYING TO INITIALIZE THE DRIVE ?
6747 040134 001031 SNE ST06 ;BR IF YES - DRIVE NOT ONLINE
6748 040136 105761 033152 TSTB DPRQS(R1) ;OUTSTANDING PORT REQUEST FOR THE DRIVE ?
6749 040142 001045 BNE ST07 ;BR IF YES - NO RESPONSE TO REQUEST
6750 040144 020137 033234 CMP R1,DTUW ;DATA TRANSFER UNDERWAY FOR THIS DRIVE
6751 040150 001263 BNE ST01 ;BR IF NO
6752 040152 004037 040324 JSR RD,RD.RP ;YES--CHECK "RDY"
6753 040156 000000 RPCS1
6754 040160 040212 ST05
6755 040162 105726 TSTB (SP)+
6756 040164 100255 BFL ST01 ;BR IF "RDY"=0
6757 040166 105761 033142 ST03: TSTB DPINT(R1) ;INITIALIZING THE DRIVE ?
6758 040172 001003 BNE IS ;BR IF INIT PENDING
6759 040174 105761 033152 TSTB DPRQS(R1) ;PORT REQUEST PENDING ?
6760 040200 001446 BEQ ST09 ;BR IF NOT
6761 040202 012763 177777 033214 IS: MOV #-1,TIMER(R3) ;STOP THE TIMER
6762 040210 000442 BR ST09 ;EXIT
6763 040212 004737 035540 ST05: JSR PC,CIB ;GO HANDLE THE PARITY ERROR
6764 040216 000437 BR ST09
6765 040220 105061 033142 ST06: CLRB DPINT(R1) ;CLEAR THE INITIALIZE INDICATOR
6766 040224 105061 033122 CLRB DRVSTA(R1) ;SET UNIT OFFLINE
6767 040230 012763 177777 033214 MOV #-1,TIMER(R3) ;STOP THE TIMER
6768 040236 004737 041522 JSR PC,GETREQ ;GET THE DPB ADDRESS
6769 040242 005702 TST R2 ;REQUEST IN QUEUE ?
6770 040244 001424 BEQ ST09 ;BR IF NOT
6771 040246 052762 140000 000016 BIS #BIT15!BIT14,16(R2) ;INFORM THE USER DRIVE NOT AVAILABLE
6772 040254 000414 BR ST08 ;FINISH
6773 040256 012763 177777 033214 ST07: MOV #-1,TIMER(R3) ;STOP THE TIMER
6774 040264 105061 033152 CLRB DPRQS(R1) ;CLEAR PORT REQUEST INDICATOR
6775 040270 004737 041522 JSR PC,GETREQ ;GET DPB ADDRESS
6776 040274 005702 TST R2 ;QUEUE ENTRY FOR DRIVE ?
6777 040276 001407 BEQ ST09 ;BR IF NONE
6778 040300 012762 100004 000016 MOV #BIT15!BIT2,16(R2) ;INFORM USER OF PORT REQUEST ERROR
6779 040306 004737 041426 ST08: JSR PC,EMPTYQ ;CLEAR THE QUEUE FOR THE DRIVE
6780 040312 004737 040666 JSR PC,SVRH11 ;SAVE THE REGISTERS
6781 040316 012603 ST09: MOV (SP)+,R3 ;RESTORE R3
6782 040320 012601 MOV (SP)+,R1 ;RESTORE R1
6783 040322 000207 RTS PC ;RETURN
6784
6785 ;ROUTINE TO READ A RH11/RPO4/5/6 REGISTER
6786
6787 ;CALL
6788 JSR RD,RD.RP ;GO READ A REGISTER
6789 INDEX ;REG. INDEX FROM BASE
6790 ERRADR ;ERROR ADDRESS--PROCESS ERROR STARTING
6791 ;AT THIS ADDRESS
6792 RETURN ;CONTENTS OF REG. IS ON THE STACK
6793
6794 040324 013737 033246 040466 RD.RP: MOV MCPMX,RD.RP2 ;MAX. RETRYS ALLOWED
    
```

6795	040332	011646			MOV	(SP), -(SP)	;SAVE RD FOR RETURN
6796	040334	013737	033250	040350	MOV	RPADR, RD.ADR	;FORM THE DESIRED ADDRESS
6797	040342	062037	040350		ADD	(RD)+, RD.ADR	;USING THE BASE AND THE INDEX
6798	040346	013727			RD.RP1: MOV	2(PC)+, (PC)+	;READ THE DESIRED REGISTER OF THE RPO4
6799	040350	000000			RD.ADR: .WORD	0	;ADDRESS IS FORMED HERE
6800	040352	000000			RD.WRD: .WORD	0	;REG. CONTENTS PUT HERE
6801	040354	013766	040352	000002	MOV	RD.WRD, 2(SP)	;RETURN IT TO THE USER
6802	040362	013746	033250		MOV	RPADR, -(SP)	;PUT THE ADDRESS ON THE STACK
6803	040366	062716	000010		ADD	#RPCS2, (SP)	;FORM THE ADDRESS OF RPCS2
6804	040372	032736	010000		BIT	#BIT12, 2(SP)+	;CHECK THE 'NED' BIT
6805	040376	001035			BNE	RD.RP3	;BR IF DRIVE NON-EXISTENT
6806	040400	017746	172644		MOV	2RPADR, -(SP)	;READ RPCS1
6807	040404	032716	020000		BIT	#BIT13, (SP)	;DID MCPE SET?
6808	040410	001002			BNE	1\$	;BRANCH IF YES
6809	040412	022620			CMP	(SP)+, (RD)+	;ADJUST FOR RETURN
6810	040414	000430			BR	RD.RP4	;EXIT
6811	040416				1\$:		
6812	040416	104003			ERROR	3	;REPORT "MCPE" ERROR
6813	040420	005737	033234		TST	DTUW	;DATA TRANSFER UNDERWAY?
6814	040424	100405			BMI	2\$	;NO--BRANCH
6815	040426	032716	040000		BIT	#BIT14, (SP)	;NO--"TRE"=1?
6816	040432	001402			BEQ	2\$	;NO--BRANCH
6817	040434	005726			TST	(SP)+	;YES--CLEAN OFF THE STACK AND
6818	040436	000415			BR	RD.RP3	;TAKE THE FATAL ERROR EXIT
6819	040440	052716	040000		2\$:	BIS	#BIT14, (SP)
6820	040444	000316			SWAB	(SP)	;CLEAR "MCPE" BY SENDING A "1" TO "TRE"
6821	040446	013737	033250	040462	MOV	RPADR, 3\$	;POSITION BEFORE WRITING
6822	040454	005237	040462		INC	3\$	;FORM ADDRESS OF HIGH BYTE
6823	040460	112637			MOVW	(SP)+, 2(PC)+	;WRITE THE HIGH BYTE OF RPCS1
6824	040462	000000			3\$:	.WORD	;ADDRESS STORAGE
6825	040464	005327			DEC	(PC)+	;EXCEEDED MAX. RETRYS
6826	040466	000003			RD.RP2: .WORD	3	
6827	040470	002326			BGE	RD.RP1	;BRANCH IF NO
6828	040472	011000			RD.RP3: MOV	(RD), RD	;FATAL ERROR EXIT
6829	040474	012616			MOV	(SP)+, (SP)	
6830	040476	000200			RD.RP4: RTS	RD	
6831							
6832							
6833							
6834							
6835							
6836							
6837							
6838							
6839							
6840							
6841	040500	013737	033246	040650	WRT.RP: MOV	MCPEMX, WRT.R2	;MAX RETRYS ALLOWED
6842	040506	016637	000002	040566	MOV	2(SP), WRT.WD	;SAVE THE WORD TO WRITE
6843	040514	012616			MOV	(SP)+, (SP)	;ADJUST THE STACK
6844	040516	012037	040570		MOV	(RD)+, WRT.AD	;GET INDEX OF REGISTER TO BE WRITTEN
6845	040522	001015			BNE	1\$	;BRANCH IF NOT RPCS1
6846	040524	122737	000150	040566	CMPB	#150, WRT.WD	;IS THE COMMAND FOR DATA TRANSFERS?
6847	040532	002411			BLT	1\$	;YES--DON'T GET THE OLD A16 & A17, & PSEL
6848	040534	004037	040324		JSR	RD, RD.RP	;NO---COMBINE A16&A17, & PSEL WITH

;ROUTINE TO WRITE A REGISTER

;CALL

```

MOV DATA, -(SP)
JSR RD, WRT.RP
INDEX
ERRADR
RETURN
    
```

```

;DATA TO BE LOADED ON THE STACK
;CALL THE ROUTINE TO LOAD(WRITE) THE REG.
;INDEX OF THE REGISTER TO BE LOADED
;ADDRESS TO RETURN TO ON AN ERROR
;ERROR FREE RETURN
    
```

```

6849 040540 000000          RPCS1          ;THE COMMAND BEFORE SENDING IT TO
6850 040542 040656          WRT.R3          ;THE RH11/RPO4
6851 040544 000316          SWAB           (SP)
6852 040546 042716 177770          BIC            #1C7,(SP)
6853 040552 112637 040567          MOVB          (SP)+,WRT.WD+1
6854 040556 063737 033250 040570 1$: ADD          RPADR,WRT.AD ;FORM THE ADDRESS OF THE DISK REG.
6855 040564 012737          WRT.R1: MOV     (PC)+,3(PC)+ ;LOAD THE DESIRED REG.
6856 040566 000000          WRT.WD: .WORD 0 ;WORD TO WRITE GOES HERE
6857 040570 000000          WRT.AD: .WORD 0 ;ADDRESS IS FORMED HERE
6858 040572 013746 033250          MOV          RPADR,-(SP) ;PUT THE ADDRESS ON THE STACK
6859 040576 062716 000010          ADD          #RPCS2,(SP) ;FORM THE ADDRESS OF RPCS2
6860 040602 032736 010000          BIT          #BIT12,3(SP)+ ;CHECK THE 'NED' BIT
6861 040606 001023          SNE          WRT.R3 ;BR IF DRIVE NON-EXISTENT
6862 040610 004037 040324          JSR          RO,RO.RP ;CHECK FOR PARITY ERROR ON WRITE
6863 040614 000014          RPER1
6864 040616 040656          WRT.R3
6865 040620 032726 000010          BIT          #BIT03,(SP)+
6866 040624 001416          BEQ          WRT.R4 ;BRANCH IF "PAR=0"
6867 040626 016037 177776 040640          MOV          -2(RO),1$ ;PICKUP THE INDEX
6868 040634 004037 040324          JSR          RO,RO.RP ;READ THE REG.
6869 040640 000000          1$: .WORD 0 ;REG. INDEX
6870 040642 040656          WRT.R3 ;RETURN TO THIS ADDRESS ON ERROR
6871 040644 104004          ERROR 4 ;REPORT THE PARITY ON WRITE ERROR
6872 040646 005327          DEC          (PC)+ ;DECREMENT THE ERROR COUNT
6873 040650 000003          WRT.R2: .WORD 3 ;RETRY COUNTER
6874 040652 002344          BGE          WRT.R1 ;TRY AGAIN IF NOT FINISHED
6875 040654 005726          TST          (SP)+ ;CLEAN OFF THE STACK
6876 040656 011000          WRT.R3: MOV     (RO),RO ;TAKE THE "PARITY ON WRITE" ERROR EXIT
6877 040660 000401          BR          WRT.R5 ;EXIT
6878 040662 005720          WRT.44: TST    (RO)+ ;ADJUST FOR ERROR FREE EXIT
6879 040664 000200          WRT.R5: RTS    RO
6880
6881          ;ROUTINE TO SAVE THE RH11/RPO4/5/6 REGISTERS AS PER DPB+14
6882          ;CALL
6883          ;
6884          ; MOV     #DPBNUM,R2 ;DPB POINTER TO R2
6885          ; JSR     PC,SVRH11 ;SAVE THE DRIVES REG'S
6886
6887 040666 104412          SVRH11: SAVREG ;SAVE RO - R5
6888 040670 005702          TST          R2 ;QUEUE ENTRY FOR THE DRIVE ?
6889 040672 001430          BEQ          4$ ;BR IF NONE
6890 040674 013704 033250          MOV          RPADR,R4
6891 040700 111264 000010          MOVB        (R2),RPCS2(R4) ;SELECT DRIVE
6892 040704 016203 000014          MOV          14(R2),R3 ;GET THE ERROR TABLE POINTER
6893 040710 001433          BEQ          6$ ;EXIT IF NO ADDRESS
6894 040712 005037 040746          CLR          3$ ;COUNTER & POINTER
6895 040716 023727 040746 000022 1$: CMP          3$,#RPDB ;REACHED THE BUFFER REGISTER ?
6896 040724 001006          BNE          2$ ;BR IF NOT
6897 040726 032764 000200 000010          BIT          #BIT07,RPCS2(R4) ;'OR' SET ?
6898 040734 001002          BNE          2$ ;BR IF SET
6899 040736 005023          CLR          (R3)+ ;STORE RPDB AS ZEROES
6900 040740 000405          BR          4$ ;CONTINUE
6901 040742 004037 040324          2$: JSR          RO,RO.RP ;READ THE SELECTED REGISTER
6902 040746 000000          3$: .WORD 0 ;REGISTER INDEX
    
```



```

6903 040750 040774          5$:          ;ERROR RETURN ADDRESS
6904 040752 012623          MOV      (SP)+,(R3)+      ;STORE THE REGISTER CONTENTS
6905 040754 023727 040746 000046 4$:      CMP      3$,#RPEC2      ;REACHED THE END ?
6906 040762 001406          BEQ      6$              ;BR IF YES
6907 040764 062737 000002 040746          ADD      #2,3$          ;INCREMENT THE REGISTER INDEX
6908 040772 000751          BR       1$              ;CONTINUE READING THE REGISTERS
6909 040774 004737 035440          5$:      JSR      PC,C17      ;PROCESS THE UNCORRECTABLE PARITY ERROR
6910 041000 104413          6$:      RESREG          ;RESTORE R0 - R5
6911 041002 000207          RTS       PC              ;RETURN
6912
6913          ;ROUTINE TO SET THE INTERRUPT WITHOUT GETTING A "TRE"
6914          ;CALL
6915          ;
6916          ;       MOV      #DRVNUM,R1      ;DRIVE NUMBER TO R1
6917          ;       JSR      PC,SET.IE      ;SET "IE"
6918          ;
6919          SET.IE: MOV      R4,-(SP)      ;SAVE R4
6920 041006 013704 033250          MOV      RPADR,R4      ;PICKUP ADDRESS OF RPCS1
6921 041012 010164 000010          MOV      R1,RPCS2(R4)  ;SELECT DRIVE
6922 041016 011446          MOV      (R4),-(SP)    ;READ RPCS1
6923 041020 052716 040000          BIS      #BIT14,(SP)   ;SET THE "TRE" BIT OF THE WORD READ
6924 041024 009316          SWAB     (SP)          ;ADJUST FOR DATO
6925 041026 112714 000100          MOVB    #BIT06,(R4)    ;SET "IE"
6926 041032 032764 010000 000010          BIT     #BIT12,RPCS2(R4) ;IS "NED"=1?
6927 041040 001002          BNE     1$              ;YES--CLEAR "TRE"
6928 041042 005726          TST     (SP)+          ;CLEAN OFF THE STACK
6929 041044 000402          BR      2$              ;
6930 041046 112664 000001          1$:      MOVB    (SP)+,1(R4)  ;CLEAR "TRE"
6931 041052 012604          2$:      MOV      (SP)+,R4    ;RESTORE R4
6932 041054 000207          RTS       PC              ;RETURN TO CALLER
6933
6934          ;QUEUE COUNT
6935 041056          000          QCNT:   .BYTE   0          ;DRIVE 0
6936 041057          000          .BYTE   0          ;DRIVE 1
6937 041060          000          .BYTE   0          ;DRIVE 2
6938 041061          000          .BYTE   0          ;DRIVE 3
6939 041062          000          .BYTE   0          ;DRIVE 4
6940 041063          000          .BYTE   0          ;DRIVE 5
6941 041064          000          .BYTE   0          ;DRIVE 6
6942 041065          000          .BYTE   0          ;DRIVE 7
6943
6944          ;QUEUE INPUT POINTERS
6945
6946 041066 041150          QINPT: .WORD   QDRV0      ;DRIVE 0
6947 041070 041170          .WORD   QDRV1      ;DRIVE 1
6948 041072 041210          .WORD   QDRV2      ;DRIVE 2
6949 041074 041230          .WORD   QDRV3      ;DRIVE 3
6950 041076 041250          .WORD   QDRV4      ;DRIVE 4
6951 041100 041270          .WORD   QDRV5      ;DRIVE 5
6952 041102 041310          .WORD   QDRV6      ;DRIVE 6
6953 041104 041330          .WORD   QDRV7      ;DRIVE 7
6954
6955          ;QUEUE OUTPUT POINTERS
6956
    
```

```

6957 041106 041150          QOUTPT: .WORD  QDRV0          ;DRIVE 0
6958 041110 041170          .WORD  QDRV1          ;DRIVE 1
6959 041112 041210          .WORD  QDRV2          ;DRIVE 2
6960 041114 041230          .WORD  QDRV3          ;DRIVE 3
6961 041116 041250          .WORD  QDRV4          ;DRIVE 4
6962 041120 041270          .WORD  QDRV5          ;DRIVE 5
6963 041122 041310          .WORD  QDRV6          ;DRIVE 6
6964 041124 041330          .WORD  QDRV7          ;DRIVE 7
6965
6966 041126 041150          QSTART: .WORD  QDRV0          ;DRIVE 0 START ADDRESS
6967 041130 041170          QSTOP:  .WORD  QDRV1          ;DRIVE 0 STOP ADDRESS & DRIVE 1 START ADDRESS
6968 041132 041210          .WORD  QDRV2          ;STOP DRIVE 1--START DRIVE 2
6969 041134 041230          .WORD  QDRV3          ;STOP DRIVE 2--START DRIVE 3
6970 041136 041250          .WORD  QDRV4          ;STOP DRIVE 3--START DRIVE 4
6971 041140 041270          .WORD  QDRV5          ;STOP DRIVE 4--START DRIVE 5
6972 041142 041310          .WORD  QDRV6          ;STOP DRIVE 5--START DRIVE 6
6973 041144 041330          .WORD  QDRV7          ;STOP DRIVE 6--START DRIVE 7
6974 041146 041350          .WORD  QTERM          ;STOP DRIVE 7
6975
6976          ;DRIVE REQUEST QUEUES
6977
6978 041150 000010          QDRV0:  .BLKW  10
6979 041170 000010          QDRV1:  .BLKW  10
6980 041210 000010          QDRV2:  .BLKW  10
6981 041230 000010          QDRV3:  .BLKW  10
6982 041250 000010          QDRV4:  .BLKW  10
6983 041270 000010          QDRV5:  .BLKW  10
6984 041310 000010          QDRV6:  .BLKW  10
6985 041330 000010          QDRV7:  .BLKW  10
6986          QTERM=.
6987
6988          ;ROUTINE TO CLEAR ALL OF THE REQUEST QUEUES
6989
6990          ;CALL
6991          ;      JSR      PC,CLRQUE
6992
6993 041350 104412          CLRQUE: SAVREG          ;SAVE R0 - R5
6994 041352 012702 041056          MOV      #QCNT,R2          ;ZERO THE QUEUE COUNTS
6995 041356 005022          CLR      (R2)+          ;DRIVES 0 & 1
6996 041360 005022          CLR      (R2)+          ;DRIVES 2 & 3
6997 041362 005022          CLR      (R2)+          ;DRIVES 4 & 5
6998 041364 005022          CLR      (R2)+          ;DRIVES 6 & 7
6999 041366 012703 000010          MOV      #8,R3          ;MOVE THE STARTING
7000 041372 012701 041126          MOV      #QSTART,R1          ;ADDRESS OF THE QUEUE INTO
7001 041376 012122          1$: MOV      (R1)+,(R2)+          ;THE QUEUE INPUT POINTER
7002 041400 005303          DEC      R3
7003 041402 001375          BNE      1$
7004 041404 012703 000010          MOV      #8,R3          ;MOVE THE STARTING ADDRESS
7005 041410 012701 041126          MOV      #QSTART,R1          ;OF THE QUEUE INTO THE
7006 041414 012122          2$: MOV      (R1)+,(R2)+          ;QUEUE OUTPUT POINTER
7007 041416 005303          DEC      R3
7008 041420 001375          BNE      2$
7009 041422 104413          RESREG
7010 041424 000207          RTS      PC          ;RESTORE R0 - R5
    
```

```

7011 :EMPTY THE QUEUE SPECIFIED BY R1
7012 :CALL
7013 :   MOV   DRVNUM,R1      :DRIVE NUMBER TO R1
7014 :   JSR   PC,EMPTYQ
7015 :
7016 :
7017 :EMPTYQ: CLR   QCNT(R1)      ;CLEAR NUMBER OF ITEMS IN QUEUE
7018 :        ASL   R1
7019 :        MOV   QINPT(R1),QOUTPT(R1) ;SET OUTPUT QUEUE POINTER=INPUT POINTER
7020 :        ASR   R1
7021 :        RTS   PC
7022 :
7023 :ROUTINE TO PUT A REQUEST IN QUEUE
7024 :CALL
7025 :   MOV   #DRVNUM,R1      :DRIVE NUMBER
7026 :   MOV   #DPB,R2         :ADDRESS OF PARAMETER BLOCK
7027 :   JSR   RD,DRVQLE       :GO PUT REQUEST IN QUEUE
7028 :   RETURN1                :RETURN HERE IF QUEUE IS FULL
7029 :   RETURN2                :RETURN HERE IF REQUEST IS IN QUEUE
7030 :
7031 :
7032 :
7033 :041446 122761 000010 041056 DRVQLE: CMPB   #10,QCNT,R1)  :IS QUEUE FULL?
7034 :041454 001421 :BEQ   Z$                :BR IF YES-TAKE RETURN1
7035 :041456 105261 041056 :INCB  QCNT(R1)         :INCREMENT QUEUE COUNT
7036 :041462 006301 :ASL   R1
7037 :041464 010271 041066 :MOV   R2,QINPT(R1)     :PUT THIS REQUEST IN QUEUE
7038 :041470 062761 000002 041066 :ADD   #2,QINPT(R1)     :UPDATE THE QUEUE POINTER
7039 :041476 026161 041066 041130 :CMP   QINPT(R1),QSTOP(R1) ;TIME TO RESET THE POINTER
7040 :041504 001003 :BNE   IS                :BRANCH IF NO
7041 :041506 016161 041126 041066 :MOV   QSTART(R1),QINPT(R1) ;YES--RESET POINTER
7042 :041514 006201 :ASR   R1
7043 :041516 005720 :TST   (R0)+             :TAKE RETURN 2
7044 :041520 000200 :RTS   R0                :RETURN TO USER
7045 :
7046 :ROUTINE TO GET THE "DPB" ADDRESS OF NEXT REQUEST IN QUEUE
7047 :CALL
7048 :   MOV   #DRVNUM,R1      :DRIVE NUMBER TO R1
7049 :   JSR   PC,GETREQ
7050 :   RETURN                :R2="DPB" ADDRESS OF THE REQUEST
7051 :                          :R2=0 IF NO REQUEST IN QUEUE
7052 :
7053 :
7054 :041522 005002 :GETREQ: CLR   R2
7055 :041524 105761 041056 :TSTB  QCNT(R1)         :IS THERE ANY REQUEST IN QUEUE?
7056 :041530 001404 :BEQ   Z$                :NO---BRANCH
7057 :041532 006301 :ASL   R1
7058 :041534 017102 041106 :MOV   QOUTPT(R1),R2    :PICKUP "DPB" POINTER FOR THIS DRIVE
7059 :041540 006201 :ASR   R1
7060 :041542 000207 :RTS   PC                :RETURN TO USER
7061 :
7062 :ROUTINE TO "POP" THE REQUEST FROM QUEUE
7063 :CALL
7064 :

```

```

7065      :      MOV      #DRYNUM,R1      ;DRIVE NUMBER TO 5
7066      :      JSR      PC,POPQUE      ;CALL TO REMOVE REQUEST
7067      :      RETURN      ;R2=ADDRESS OF DPB REMOVED
7068
7069      0411544 105361 041056      POPQUE: DECB      QCNT(R1)      ;DECREMENT QUEUE COUNT
7070      0411550 006301      ASL      R1
7071      0411552 017102 041106      MOV      QOUTPT(R1),R2      ;GET THE "DPB" POINTER
7072      0411556 062761 000002 041106      ADD      #2,QOUTPT(R1)      ;UPDATE THE QUEUE POINTER
7073      0411564 026161 041106 041130      CMP      QOUTPT(R1),QSTOP(R1) ;TIME TO RESET THE POINTER?
7074      0411572 001003      BNE      IS
7075      0411574 016161 041126 041106      MOV      QSTART(R1),QOUTPT(R1) ;YES--RESET THE POINTER
7076      0411578 006201      IS:      ASR      R1
7077      0411584 003207      RTS      PC      ;RETURN TO USER

```

\*\*\*\*\*

.SBTTL DATA, CONTROL, & STATUS BLOCKS

\*\*\*\*\*

;BLOCK LOCATION EQUATE STATEMENTS

```

7088      000001      $FMT      =      1      ;FMT,HCI,ECI OR OFFSET CODE
7089      000002      $COMND      =      $FMT+1      ;OPERATION CODE
7090      000003      $PSEL      =      $FMT+2      ;PORT SELECT & BITS A16, A17
7091      000004      $WRDM      =      $FMT+3      ;WORD COUNT (2'S COMP)
7092      000006      $BUF      =      $FMT+5      ;BUFFER ADDR OR REGISTER TABLE POINTER
7093      000010      $SEC      =      $FMT+7      ;SECTOR ADDRESS OR 1ST REG ADDR
7094      000011      $TRK      =      $FMT+10      ;TRACK ADDRESS OF LAST REG ADDR
7095      000012      $CYL      =      $FMT+11      ;CYLINDER ADDR
7096      000014      $REG      =      $FMT+13      ;REGISTER STORAGE (IF ERROR)
7097      000016      $STATUS      =      $FMT+15      ;STATUS WORD (SET BY DRIVER)

```

;DRIVE'S HISTORY AND CURRENT INDICATOR STORAGE EQUATES

```

7100
7101      000020      $WRDL      =      $FMT+17      ;WORD COUNT (NOT 2'S COMP)
7102      000022      $$SEC      =      $WRDL+2      ;SECTOR SIZE FOR CURRENT OPERATION
7103      000024      $CODE      =      $WRDL+4      ;PRESENT COMMAND SELECTION CODE
7104      000026      $PACK      =      $WRDL+6      ;WRITE DATA PACK INDICATOR
7105      000027      $PREVO      =      $WRDL+7      ;PREVIOUS COMMAND SELECTION CODE
7106      000030      $PATTC      =      $WRDL+10      ;PATTERN CODE
7107      000032      $PREVA      =      $WRDL+12      ;PREVIOUS ADDRESS - TRACK, SECTOR, CYLINDER
7108      000036      $OPERC      =      $WRDL+16      ;OPERATION COUNT
7109      000042      $POSIT      =      $WRDL+22      ;SEEK COUNT
7110      000046      $TRANS      =      $WRDL+26      ;TOTAL BITS XFERED COUNT (R & W)
7111      000052      $READ      =      $WRDL+32      ;TOTAL BITS READ COUNT
7112      000056      $TOTAL      =      $WRDL+36      ;TOTAL ERRORS (ALL TYPES) COUNT
7113      000060      $$SOFT      =      $WRDL+40      ;'SOFT' ERROR COUNT
7114      000062      $HARD      =      $WRDL+42      ;'HARD' ERROR COUNT
7115      000064      $SKI      =      $WRDL+44      ;'SKI' OR 'OCYL' ERROR COUNT
7116      000066      $MISPO      =      $WRDL+46      ;PROG DETECTED MISPOSITIONING ERROR S COUNT
7117      000070      $PASSC      =      $WRDL+50      ;PASS COUNTER
7118      000072      $FAIR      =      $WRDL+52      ;OPERATION QUEUE 'FAIRNESS' COUNT

```

7119  
7120  
7121  
7122  
7123  
7124  
7125  
7126  
7127  
7128  
7129  
7130  
7131  
7132  
7133  
7134  
7135  
7136  
7137  
7138  
7139  
7140  
7141  
7142  
7143  
7144  
7145  
7146  
7147  
7148  
7149  
7150  
7151  
7152  
7153  
7154  
7155  
7156  
7157  
7158  
7159  
7160  
7161  
7162  
7163  
7164  
7165  
7166  
7167  
7168  
7169  
7170  
7171  
7172

000074  
000075  
000076  
000077  
000100  
000102  
000104  
  
000106  
000110  
000112  
000114  
000116  
000120  
000122  
  
000124  
  
000224  
  
000234  
000236  
000240  
000242  
000244  
000246  
000250  
000252  
000254  
000256  
000260  
000262  
000264  
000266  
000270  
000272  
000274  
000276  
000300  
000302

;INDEX EQUATES TO THE NEXT OPERATION PARAMETERS

\$NCODE = \$WRDL+54 ;NEXT OPERATION CODE  
\$NPATC = \$NCODE+1 ;NEXT PATTERN  
\$NSEC = \$NCODE+2 ;NEXT SECTOR  
\$NTRK = \$NCODE+3 ;NEXT TRACK  
\$NCYL = \$NCODE+4 ;NEXT CYLINDER  
\$NWRDL = \$NCODE+6 ;NEXT BUFFER SIZE  
\$NEXT = \$NCODE+10 ;PARAMETER SELECTION INDICATOR

;INDEX EQUATES FOR MAXIMUM/MINIMUM ADDRESSES

MAXCYL = \$NCODE+12 ;MAXIMUM CYLINDER ADDRESS  
MINCYL = MAXCYL+2 ;MINIMUM CYLINDER ADDRESS  
MAXTRK = MAXCYL+4 ;MAXIMUM TRACK ADDRESS  
MINTRK = MAXCYL+6 ;MINIMUM TRACK ADDRESS  
MAXSEC = MAXCYL+10 ;MAXIMUM SECTOR ADDRESS  
MINSEC = MAXCYL+12 ;MINIMUM SECTOR ADDRESS  
\$FIRST = MAXCYL+14 ;FIRST OPERATION INDICATOR

;BAD SECTOR/TRACK ADDRESS STORAGE AREA INDEX EQUATE

\$BDSEC = MAXCYL+16 ;BAD SECTOR STORAGE TABLE

;DRIVE ID AREA INDEX EQUATE

\$DRVID = \$BDSEC+100 ;DRIVE ID

;RH11/RP04/5/6 REGISTER EQUATES

\$RPCS1 = \$DRVID+10 ;RP04 REGISTER STORAGE  
\$RPWC = \$RPCS1+2  
\$RPBA = \$RPCS1+4  
\$RPDA = \$RPCS1+6  
\$RPCS2 = \$RPCS1+10  
\$RPCS1 = \$RPCS1+12  
\$RPER1 = \$RPCS1+14  
\$RPAS = \$RPCS1+16  
\$RPLA = \$RPCS1+20  
\$RPDB = \$RPCS1+22  
\$RPMR = \$RPCS1+24  
\$RPDT = \$RPCS1+26  
\$RPSN = \$RPCS1+30  
\$RPOF = \$RPCS1+32  
\$RPCA = \$RPCS1+34  
\$RPCC = \$RPCS1+36  
\$RPER2 = \$RPCS1+40  
\$RPER3 = \$RPCS1+42  
\$RPEC1 = \$RPCS1+44  
\$RPEC2 = \$RPCS1+46

;BLOCK FOR DRIVE 0

```

7173
7174 041606 000 000 DRIVED: .BYTE 0,0 ;DRIVE NUMBER
7175 041610 000005 .BLKW 5
7176 041622 042042 .WORD +$RPCS1-$REG
7177 041624 000266 .BLKB $RPEC2-$REG
7178
7179
7180 ;BLOCK FOR DRIVE 1
7181
7182 042112 001 000 DRIVE1: .BYTE 1,0 ;DRIVE NUMBER
7183 042114 000005 .BLKW 5
7184 042126 042346 .WORD +$RPCS1-$REG
7185 042130 000266 .BLKB $RPEC2-$REG
7186
7187
7188 ;BLOCK FOR DRIVE 2
7189
7190 042416 002 000 DRIVE2: .BYTE 2,0 ;DRIVE NUMBER
7191 042420 000005 .BLKW 5
7192 042432 042652 .WORD +$RPCS1-$REG
7193 042434 000266 .BLKB $RPEC2-$REG
7194
7195
7196 ;BLOCK FOR DRIVE 3
7197
7198 042722 003 000 DRIVE3: .BYTE 3,0 ;DRIVE NUMBER
7199 042724 000005 .BLKW 5
7200 042736 043156 .WORD +$RPCS1-$REG
7201 042740 000266 .BLKB $RPEC2-$REG
7202
7203
7204 ;BLOCK FOR DRIVE 4
7205
7206 043226 004 000 DRIVE4: .BYTE 4,0 ;DRIVE NUMBER
7207 043230 000005 .BLKW 5
7208 043242 043462 .WORD +$RPCS1-$REG
7209 043244 000266 .BLKB $RPEC2-$REG
7210
7211
7212 ;BLOCK FOR DRIVE 5
7213
7214 043532 005 000 DRIVES: .BYTE 5,0 ;DRIVE NUMBER
7215 043534 000005 .BLKW 5
7216 043546 043766 .WORD +$RPCS1-$REG
7217 043550 000266 .BLKB $RPEC2-$REG
7218
7219
7220 ;BLOCK FOR DRIVE 6
7221
7222 044036 006 000 DRIVE6: .BYTE 6,0 ;DRIVE NUMBER
7223 044040 000005 .BLKW 5
7224 044052 044272 .WORD +$RPCS1-$REG
7225 044054 000266 .BLKB $RPEC2-$REG
7226

```

```

7227
7228 ;BLOCK FOR DRIVE 7
7229
7230 044342 007 000 DRIVE7: .BYTE 7,0 ;DRIVE NUMBER
7231 044344 000005 .BLKW 5
7232 044356 044576 .WORD +$RPCS1-$REG
7233 044350 000266 .BLKB $RPEC2-$REG
7234
7235
7236 ;GENERAL PURPOSE DPB - USED BY 'READHD', 'RECALT', 'OFFSET', & 'RTNCTR'
7237
7238 044646 000000 000000 177774 GENDPB: .WORD 0,0,-4,CYLDER
7239 044654 054374
7240 044656 000000 000000 044666 .WORD 0,0,GENREG,0
7241 044664 000000
7242 044666 000024 GENREG: .BLKW 24 ;REGISTER STORAGE IF ERROR
7243
7244 ;*****
7245 .SBTTL ERROR MESSAGES
7246
7247 ;*****
7248
7249
7250 044736 044122 030461 044440 EM1: .ASCIZ /RH11 INTERRUPT OCCURRED (RPAS = 0)/
7251 044744 052116 051105 052522
7252 044752 052120 047440 041503
7253 044760 051125 042522 020104
7254 044766 051050 040520 020123
7255 044774 020075 024460 000
7256
7257 045001 125 042516 050130 EM2: .ASCIZ /UNEXPECTED ATTENTION OCCURRED/
7258 045006 041505 042524 020104
7259 045014 052101 042524 052116
7260 045022 047511 020116 041517
7261 045030 052503 051122 042105
7262 045036 000
7263
7264 045037 115 051501 041123 EM3: .ASCIZ /MASSBUS PARITY ERROR (MCPE=1)/
7265 045044 051525 050040 051101
7266 045052 052111 020131 051105
7267 045060 047522 020122 046450
7268 045066 050103 036505 024461
7269 045074 000
7270
7271 045075 115 051501 041123 EM4: .ASCIZ /MASSBUS PARITY ERROR (PAR=1)/
7272 045102 051525 050040 051101
7273 045110 052111 020131 051105
7274 045116 047522 020122 050050
7275 045124 051101 030475 000051
7276
7277 045132 042101 051104 051505 EM5: .ASCIZ /ADDRESS PLUG CHANGE BIT SET/
7278 045140 020123 046120 043525
7279 045146 041440 00510 043516
7280 045154 020105 044502 020124

```

7281	045162	042523	000124		
7282					
7283	045166	044122	030461	042040	EM6: .ASCIZ /RH11 DIDN'T RESPOND TO ADDRESSING/
7284	045174	042111	023516	020124	
7285	045202	042522	050123	047117	
7286	045210	020104	047524	040440	
7287	045216	042104	042522	051523	
7288	045224	047111	000107		
7289					
7290	045230	047125	047503	051122	EM10: .ASCIZ /UNCORRECTABLE MASSBUS PARITY ERROR/
7291	045236	041505	040524	046102	
7292	045244	020105	040515	051523	
7293	045252	052502	020123	040520	
7294	045260	044522	054524	042440	
7295	045266	051122	051117	000	
7296					
7297	045273	106	052101	046101	EM11: .ASCIZ /FATAL MASSBUS PARITY ERROR/
7298	045300	046440	051501	041123	
7299	045306	051525	050040	051101	
7300	045314	052111	020131	051105	
7301	045322	047522	000122		
7302					
7303	045326	042520	051522	051511	EM12: .ASCIZ /PERSISTENT DEVICE UNSAFE/
7304	045334	042524	052116	042040	
7305	045342	053105	041511	020105	
7306	045350	047125	040523	042506	
7307	045356	000			
7308					
7309	045357	117	042520	040522	EM13: .ASCIZ /OPERATION NOT COMPLETED WITHIN TIME LIMIT/
7310	045364	044524	047117	047040	
7311	045372	052117	041440	046517	
7312	045400	046120	052105	042105	
7313	045406	053440	052111	044510	
7314	045414	020116	044524	042515	
7315	045422	046040	046511	052111	
7316	045430	000			
7317					
7318	045431	104	044522	042526	EM14: .ASCIZ /DRIVE WENT OFFLINE/
7319	045436	053440	047105	020124	
7320	045444	043117	046106	047111	
7321	045452	000105			
7322					
7323	045454	047516	051040	051505	EM15: .ASCIZ /NO RESPONSE TO PORT REQUEST/
7324	045462	047520	051516	020105	
7325	045470	047524	050040	051117	
7326	045476	020124	042522	052521	
7327	045504	051505	000124		
7328					
7329	045510	042510	042101	051105	EM20: .ASCIZ /HEADER CRC ERROR/
7330	045516	041440	041522	042440	
7331	045524	051122	051117	000	
7332					
7333	045531	104	052101	020101	EM21: .ASCIZ /DATA CHECK ('DCK') ERROR/
7334	045536	044103	041505	020113	



Line	Code	Address	Address	Address	Message
7335	045544	023450	041504	023513	
7336	045552	020051	051105	047522	
7337	045560	000122			
7338					
7339	045562	051127	052111	020105	EM22: .ASCIZ /WRITE CHECK ERROR - DATA CHECK ('DCK') SET/
7340	045570	044103	041505	020113	
7341	045576	051105	047522	020122	
7342	045604	020055	040504	040524	
7343	045612	041440	042510	045503	
7344	045620	024040	042047	045503	
7345	045626	024447	051440	052105	
7346	045634	000			
7347					
7348	045635	127	044522	042524	EM23: .ASCIZ /WRITE CHECK ERROR - DATA CHECK ('DCK') NOT SET/
7349	045642	041440	042510	045503	
7350	045650	042440	051122	051117	
7351	045656	026440	042040	052101	
7352	045664	020101	044103	041505	
7353	045672	020113	023450	041504	
7354	045700	023513	020051	047516	
7355	045706	020124	042523	000124	
7356					
7357	045714	042510	042101	051105	EM24: .ASCIZ /HEADER READ ERROR - 'FMT' BIT DROPPED/
7358	045722	051040	040505	020104	
7359	045730	051105	047522	020122	
7360	045736	020055	043047	052115	
7361	045744	020047	044502	020124	
7362	045752	051104	050117	042520	
7363	045760	000104			
7364					
7365	045762	042510	042101	051105	EM25: .ASCIZ /HEADER READ ERROR - HEADER COMPARE ('HCE') ERROR/
7366	045770	051040	040505	020104	
7367	045776	051105	047522	020122	
7368	046004	020055	042510	042101	
7369	046012	051105	041440	046517	
7370	046020	040520	042522	024040	
7371	046026	044047	042503	024447	
7372	046034	042440	051122	051117	
7373	046042	000			
7374					
7375	046043	106	051117	040515	EM26: .ASCIZ /FORMAT ERROR ('FER')/
7376	046050	020124	051105	047522	
7377	046056	020122	023450	042506	
7378	046064	023522	000051		
7379					
7380	046070	042510	042101	051105	EM27: .ASCIZ /HEADER COMPARE ('HCE') ERROR/
7381	046076	041440	046517	040520	
7382	046104	042522	024040	044047	
7383	046112	042503	024447	042440	
7384	046120	051122	051117	000	
7395					
7396	046125	115	051511	042503	EM30: .ASCIZ /MISCELLANEOUS DRIVE ERROR/
7397	046132	046114	047101	047505	
7398	046140	051525	042040	044522	

7389	046146	042526	042440	051122		
7390	046154	051117	000			
7391						
7392	046157	117	042520	040522	EM31:	.ASCIZ /OPERATION INCOMPLETE ('OPI') ERROR/
7393	046164	044524	047117	044440		
7394	046172	041516	046517	046120		
7395	046200	052105	020105	023450		
7396	046206	050117	023511	020051		
7397	046214	051105	047522	000122		
7398						
7399	046222	051104	053111	020105	EM32:	.ASCIZ /DRIVE TIMING ('DTE') ERROR/
7400	046230	044524	044515	043516		
7401	046236	024040	042047	042524		
7402	046244	024447	042440	051122		
7403	046252	051117	000			
7404						
7405	046255	120	051101	052111	EM33:	.ASCIZ /PARITY ('PAR') ERROR AFTER OPERATION STARTED/
7406	046262	020131	023450	040520		
7407	046270	023522	020051	051105		
7408	046276	047522	020122	043101		
7409	046304	042524	020122	050117		
7410	046312	051105	052101	047511		
7411	046320	020116	052123	051101		
7412	046326	042524	000104			
7413						
7414	046332	051127	052111	020105	EM34:	.ASCIZ /WRITE CLOCK FAILURE ('WCF') ERROR/
7415	046340	046103	041517	020113		
7416	046346	040506	046111	051125		
7417	046354	020105	023450	041527		
7418	046362	023506	020051	051105		
7419	046370	047522	000122			
7420						
7421	046374	047111	040526	044514	EM35:	.ASCIZ /INVALID ADDRESS ('IAE') ERROR/
7422	046402	020104	042101	051104		
7423	046410	051505	020123	023450		
7424	046416	040511	023505	020051		
7425	046424	051105	047522	000122		
7426						
7427	046432	051127	052111	020105	EM36:	.ASCIZ /WRITE LOCK ('WLE') ERROR/
7428	046440	047514	045503	024040		
7429	046446	053447	042514	024447		
7430	046454	042440	051122	051117		
7431	046462	000				
7432						
7433	046463	104	052101	020101	EM37:	.ASCIZ /DATA CHECK ('DCK') SET DURING WRITE CHECK COMMAND/
7434	046470	044103	041505	020113		
7435	046476	023450	041504	023513		
7436	046504	020051	042523	020124		
7437	046512	052504	044522	043516		
7438	046520	053440	044522	042524		
7439	046526	041440	042510	045503		
7440	046534	041440	046517	040515		
7441	046542	042116	000			
7442						

7443	046545	122	030510	020061	EM40:	.ASCIZ /RH11 OR UNIBUS TRANSFER ERROR/
7444	046552	051117	052440	044516		
7445	046560	052502	020123	051124		
7446	046566	047101	043123	051105		
7447	046574	042440	051122	051117		
7448	046602	000				
7449						
7450	046603	102	051525	040440	EM41:	.ASCIZ /BUS ADDRESS OR WORD COUNT INCORRECT/
7451	046610	042104	042522	051523		
7452	046616	047440	020122	047527		
7453	046624	042122	041440	052517		
7454	046632	352116	044440	041516		
7455	046640	051117	042522	052103		
7456	046646	000				
7457						
7458	046647	104	052101	020101	EM42:	.ASCIZ /DATA COMPARE ERRORS - NO OTHER ERROR(S) DETECTED/
7459	046654	047503	050115	051101		
7460	046662	020105	051105	047522		
7461	046670	051522	026440	047040		
7462	046676	020117	052117	042510		
7463	046704	020122	051105	047522		
7464	046712	024122	024523	042040		
7465	046720	052105	041505	042524		
7466	046726	000104				
7467						
7468	046730	040503	023516	020124	EM43:	.ASCIZ /CAN'T MATCH DATA READ WITH A PATTERN/
7469	046736	040515	041524	020110		
7470	046744	040504	040524	051040		
7471	046752	040505	020104	044527		
7472	046760	044124	040440	050040		
7473	046766	052101	042524	047122		
7474	046774	000				
7475						
7476	046775	105	051122	051117	EM44:	.ASCIZ /ERROR BIT(S) SET, BUT NO ERROR SIGNALLED BY THE RH11/
7477	047002	041040	052111	051450		
7478	047010	020051	042523	026124		
7479	047016	041040	052125	047040		
7480	047024	020117	051105	047522		
7481	047032	020122	044523	047107		
7482	047040	046101	042105	041040		
7483	047046	020131	044124	020105		
7484	047054	044122	030461	000		
7485						
7486	047061	105	041503	046040	EM45:	.ASCIZ /ECC LOGIC FAILURE - POSITION REGISTER VALUE TOO LARGE/
7487	047066	043517	041511	043040		
7488	047074	044501	052514	042522		
7489	047102	026440	050040	051517		
7490	047110	052111	047511	020116		
7491	047116	042522	044507	052123		
7492	047124	051105	053040	046101		
7493	047132	042525	052040	047517		
7494	047140	046040	051101	042507		
7495	047146	000				
7496						

7497	047147	102	051525	040440	EM46:	.ASCIZ	/BUS ADDRESS AND WORD COUNT NOT CONSISTENT/
7498	047154	042104	042522	051523			
7499	047162	040440	042116	053440			
7500	047170	051117	020104	047503			
7501	047176	047125	020124	047516			
7502	047204	020124	047503	051516			
7503	047212	051511	042524	052116			
7504	047220	000					
7505							
7506	047221	123	042505	020113	EM50:	.ASCIZ	/SEEK INCOMPLETE ('SKI') OR OFF CYLINDER ('OCYL') ERROR/
7507	047226	047111	047503	050115			
7508	047234	042514	042524	024040			
7509	047242	051447	044513	024447			
7510	047250	047440	020122	043117			
7511	047256	020106	054503	044514			
7512	047264	042116	051105	024040			
7513	047272	047447	054503	023514			
7514	047300	020051	051105	047522			
7515	047306	000122					
7516							
7517	047310	051120	043517	040522	EM51:	.ASCIZ	/PROGRAM DETECTED POSITIONING ERROR/
7518	047316	020115	042504	042524			
7519	047324	052103	042105	050040			
7520	047332	051517	052111	047511			
7521	047340	044516	043516	042440			
7522	047346	051122	051117	000			
7523							
7524	047353	104	044522	042526	EM60:	.ASCIZ	/DRIVE UNSAFE ERROR/
7525	047360	052440	051516	043101			
7526	047366	020105	051105	047522			
7527	047374	000122					
7528							
7529	047376	050122	051501	000	DH1:	.ASCIZ	/RPAS/
7530							
7531	047403	104	044522	042526	DH2:	.ASCIZ	/DRIVE RPDS1 RPER1 RPER2 RPER3 RPAS/
7532	047410	020040	051040	042120			
7533	047416	030523	020040	051040			
7534	047424	042520	030522	020040			
7535	047432	051040	042520	031122			
7536	047440	020040	051040	042520			
7537	047446	031522	020040	051040			
7538	047454	040520	000123				
7539							
7540	047460	051104	053111	020105	DH3:	.ASCIZ	/DRIVE REG ADR DATA/
7541	047466	020040	042522	020107			
7542	047474	042101	020122	042040			
7543	047502	052101	000101				
7544							
7545	047506	051104	053111	020105	DH4:	.ASCIZ	/DRIVE REG ADR GOOD BAD/
7546	047514	020040	042522	020107			
7547	047522	042101	020122	020040			
7548	047530	043440	047517	020104			
7549	047536	020040	041040	042101			
7550	047544	000					

```

7551
7552 047545 044 050122 042101 DH6: .ASCIZ /$RPADR/
7553 047552 000122
7554
7555 047554 051104 020126 050122 DH14: .ASCII /DRV RPCS1 RPCS2 RPDS1 RPER1 /
7556 047562 051503 020061 020040
7557 047570 050122 051503 020062
7558 047576 020040 050122 051504
7559 047604 020061 020040 050122
7560 047612 051105 020061 020040
7561 047620 050122 051105 020062 .ASCIZ /RPER2 RPER3 RPEC1 RPEC2/<CR><LF>
7562 047626 020040 050122 051105
7563 047634 020063 020040 050122
7564 047642 041505 020061 020040
7565 047650 050122 041505 006462
7566 047656 000012
7567
7568 047660 050122 041527 020040 DH15: .ASCII /RPWC RPBA RPDA RPAS RPLA /
7569 047666 020040 050122 040502
7570 047674 020040 020040 050122
7571 047702 040504 020040 020040
7572 047710 050122 051501 020040
7573 047716 020040 050122 040514
7574 047724 020040 020040
7575 047730 050122 041104 020040 .ASCIZ /RPDB RPMR RPDT/<CR><LF>
7576 047736 020040 050122 051115
7577 047744 020040 020040 050122
7578 047752 052104 005015 000
7579
7580 047757 122 051520 020116 DH16: .ASCIZ /RPSN RPOF RPCA RPCC STATUS/<CR><LF>
7581 047764 020040 051040 047520
7582 047772 020106 020040 051040
7583 050000 041520 020101 020040
7584 050006 051040 041520 020103
7585 050014 020040 051440 040524
7586 050022 052524 006523 000012
7587
7588 .EVEN
7589
7590 050030 001244 000000 DT1: .WORD ATTN,0
7591
7592 050034 001242 033102 033104 DT2: .WORD DRIVE,RPERRS,RPERRS+2,RPERRS+4,RPERRS+6,ATTN,0
7593 050042 033106 033110 001244
7594 050050 000000
7595
7596 050052 001242 040350 040352 DT3: .WORD DRIVE,RD.ADR,RD.WRD,0
7597 050060 000000
7598
7599 050062 001242 040570 040566 DT4: .WORD DRIVE,WRT.AD,WRT.WD,RD.WRD,0
7600 050070 040352 000000
7601
7602 050074 001170 000000 DT6: .WORD $RPADR,0
7603
7604 050100 000234 000244 000246 DT14: .WORD $RPCS1,$RPCS2,$RPDS1,$RPER1,$RPER2,$RPER3,$RPEC1,$RPEC2,0

```

7605	050106	000250	000274	000276			
7606	050114	000300	000302	000000			
7607							
7608	050122	000236	000240	000242	DT15:	.WORD	\$RPWC, \$RPBA, \$RPDA, \$RPAS, \$RPLA, \$RPDB, \$RPMR, \$RPDT, 0
7609	050130	000252	000254	000256			
7610	050136	000260	000262	000000			
7611							
7612	050144	000264	000266	000270	DT16:	.WORD	\$RPSN, \$RPOF, \$RPCA, \$RPCC, \$STATUS, 0
7613	050152	000272	000016	000000			
7614							
7615	050160	051120	051505	047105	LIN2C:	.ASCIZ	/PRESENT ORDER = /
7616	050166	020124	051117	042504			
7617	050174	020122	020075	000			
7618	050201	040	050040	042522	LIN2P:	.ASCIZ	/ PREVIOUS ORDER = /
7619	050206	044526	052517	020123			
7620	050214	051117	042504	020122			
7621	050222	020075	000				
7622	050225	052	042440	051122	LIN2S:	.ASCIZ	@* ERROR AT BAD TRACK/SECTOR@
7623	050232	051117	040440	020124			
7624	050240	040502	020104	051124			
7625	050246	041501	027513	042523			
7626	050254	052103	051117	000			
7627	050261	105	051122	051117	LINM3:	.ASCIZ	/ERROR AT C/
7628	050266	040440	020124	000103			
7629	050274	052040	000		T:	.ASCIZ	/ T/
7630	050277	120	042522	042523	LINN3:	.ASCIZ	/PRESENT ADDR = C/
7631	050304	052116	040440	042104			
7632	050312	020122	020075	000103			
7633	050320	051440	000		S:	.ASCIZ	/ S/
7634	050323	040	020040	051120	LINP3:	.ASCIZ	/ PREV ADDR = C/
7635	050330	053105	040440	042104			
7636	050336	020122	020075	000103			
7637	050344	052123	051101	020124	LINS3:	.ASCIZ	/START CYL = /
7638	050352	054503	020114	020075			
7639	050360	000					
7640	050361	040	042440	042116	LINEN3:	.ASCIZ	/ END CYL = /
7641	050366	041440	046131	036440			
7642	050374	000040					
7643	050376	020040	041501	052524	LINA3:	.ASCIZ	/ ACTUAL CYL = /
7644	050404	046101	041440	046131			
7645	050412	036440	000040				
7646	050416	020040	051124	020113	LINT3:	.ASCIZ	/ TRK = /
7647	050424	020075	000				
7648	050427	040	050122	040503	LINCA3:	.ASCIZ	/ RPCA = /
7649	050434	036440	000040				
7650	050440	050122	040504	036440	LINDA3:	.ASCIZ	/RPDA = /
7651	050446	000040					
7652	050450	050122	040502	036440	LINB3:	.ASCIZ	/RPBA = /
7653	050456	000040					
7654	050460	020040	050122	041527	LINW3:	.ASCIZ	/ RPWC = /
7655	050466	036440	000040				
7656	050472	052123	051101	020124	LINST3:	.ASCIZ	/START TRK = /
7657	050500	051124	020113	020075			
7658	050506	000					

7659	050507	123	040524	052122	LINSS3:	.ASCIZ	/START SEC = /
7660	050514	051440	041505	036440			
7661	050522	000040					
7662	050524	052502	043106	051105	LINM4:	.ASCIZ	/BUFFER ADDR = /
7663	050532	040440	042104	020122			
7664	050540	020075	000				
7665	050543	040	051440	055111	LINS4:	.ASCIZ	/ SIZE = /
7666	050550	020105	020075	000			
7667	050555	040	040440	052103	LINX4:	.ASCIZ	/ ACTUAL NMBR WRDS XFRD = /
7668	050562	040525	020114	046516			
7669	050570	051102	053440	042122			
7670	050576	020123	043130	042122			
7671	050604	036440	000040				
7672	050610	047507	042117	042040	LIND5:	.ASCIZ	/GOOD DATA = /
7673	050616	052101	020101	020075			
7674	050624	000					
7675	050625	040	041040	042101	LINB5:	.ASCIZ	/ BAD DATA = /
7676	050632	042040	052101	020101			
7677	050640	020075	000				
7678	050643	040	051440	041505	LINP5:	.ASCIZ	/ SECT POS = /
7679	050650	020124	047520	020123			
7680	050656	020075	000				
7681	050661	110	040505	042504	LINS5:	.ASCIZ	/HEADER FROM ERROR SECTOR = /
7682	050666	020122	051106	046517			
7683	050674	042440	051122	051117			
7684	050702	051440	041505	047524			
7685	050710	020122	020075	000			
7686	050715	122	042520	030503	LINEP5:	.ASCIZ	/RPEC1 = /
7687	050722	036440	000040				
7688	050726	051040	042520	031103	LINEO5:	.ASCIZ	/ RPEC2 = /
7689	050734	036440	000040				
7690	050740	042523	052103	051117	LINB6:	.ASCIZ	/SECTOR IS ECC CORRECTABLE /
7691	050746	044440	020123	041505			
7692	050754	020103	047503	051122			
7693	050762	041505	040524	046102			
7694	050770	020105	000				
7695	050773	123	041505	047524	LINC6:	.ASCIZ	/SECTOR READ CORRECTLY /
7696	051000	020122	042522	042101			
7697	051006	041440	051117	042522			
7698	051014	052103	054514	000040			
7699	051022	047503	051122	041505	LING6:	.ASCIZ	/CORRECTED ON /
7700	051030	042524	020104	047117			
7701	051036	000040					
7702	051040	051040	052105	044522	LINR6:	.ASCIZ	/ RETRIES/
7703	051046	051505	000				
7704	051051	125	041516	051117	LINUO6:	.ASCIZ	/UNCORRECTABLE AFTER /
7705	051056	042522	052103	041101			
7706	051064	042514	040440	052106			
7707	051072	051105	000040				
7708	051076	020040	047524	040524	LIN7M:	.ASCIZ	/ TOTAL MISPOS ERR = /
7709	051104	020114	044515	050123			
7710	051112	051517	042440	051122			
7711	051120	036440	000040				
7712	051124	051117	042504	051522	LIN7O:	.ASCIZ	/ORDERS:/

R024 5 6 MULTI-DRIVE EXERCISER  
ERROR MESSAGES

7753	051117	046101	LIN7P:	.ASCIZ	/ TOTAL SEEKS = /
7754	051513	051513			
7755	046101	046101	LIN7S:	.ASCIZ	/ TOTAL SKI,OCYL ERR = /
7756	047454	047454			
7757	051105	051105			
7758	020122	020122	LIN7T:	.ASCIZ	/ ERRORS: /
7759	042440	051122			
7760	051122	051122	LIN7X:	.ASCIZ	/ WRDS XFR: /
7761	042122	042122			
7762	035122	035122			
7763	053440	042122	LIN7R:	.ASCIZ	WRDS READ: /
7764	042522	042522			
7765	043106	051105	LIN8M:	.ASCIZ	/ DIFFERENT ERROR DURING RETRY /
7766	022124	051105			
7767	020122	052504			
7768	043516	051040			
7769	052105	054522			
7770	052101	020101	LIN8B:	.ASCIZ	/ DATA COMPARISON ERRORS /
7771	050115	051101			
7772	047117	042440			
7773	051117	000123	LIN8H:	.ASCII	/ GOOD BAD / <CR> <LF>
7774	020040	020040			
7775	043440	047517			
7776	020040	041040			
7777	042101	005015			
7778	047514	020103		.ASCIZ	/ LOC DATA DATA / <CR> <LF>
7779	020040	042040			
7780	042040	052101			
7781	020101	042040			
7782	052101	006501	LIN9I:	.ASCIZ	/ LOC DATA / <CR> <LF>
7783	047514	020103			
7784	020040	042040			
7785	006501	000012			
7786	047524	040524	LIN9E:	.ASCIZ	/ TOTAL COMPARE ERRORS = /
7787	047503	050115			
7788	020105	051105			
7789	051522	036440			
7790	044124	020105	LIN9G:	.ASCIZ	/ THE DATA COMPARED OK / <CR> <LF>
7791	040524	041440			
7792	040520	042522			
7793	045517	005015			
7794	051122	051117	LIN10A:	.ASCIZ	/ ERROR BURST BEGINS AT WORD /
7795	041040	051125			
7796	041040	043505			
7797	020123	052101			
7798	051117	020104			
7799	051543	047111	LIN10B:	.ASCIZ	/ IN DATA FIELD OF ERROR SECTOR / <CR> <LF>
7800	052101	020101			
7801	046105	020104			
7802	042440	051122			
7803	051440	041505			



7767	051600	006522	000012		
7768	051604	051105	047522	020122	LIN10C: .ASCII /ERROR WAS NOT IN THE DATA READ - /<CR><LF>
7769	051612	040522	020123	047515	
7770	051620	020124	047111	052040	
7771	051626	042510	042040	052101	
7772	051624	020101	042522	042101	
7773	051642	026440	006440	012	
7774	051647	105	041503	041440	.ASCIZ /ECC CORRECTION CAN'T BE PERFORMED/
7775	051654	051117	042522	052103	
7776	051662	047511	020116	040503	
7777	051670	023516	020124	042502	
7778	051676	050040	051105	047506	
7779	051704	046522	042105	000	
7780	051711	105	041503	041440	LIN10H: .ASCII /ECC CORRECTION RESULTS/<CR><LF>
7781	051716	051117	042522	052103	
7782	051724	047511	020116	042522	
7783	051732	052523	052114	006523	
7784	051740	012			
7785	051741	101	042104	020122	.ASCIZ /ADDR BAD CORRECTED /<CR><LF>
7786	051746	020040	041040	042101	
7787	051754	020040	020040	041440	
7788	051762	051117	042522	052103	
7789	051770	042103	006440	000012	
7790	051776	047503	052116	047105	LIN11H: .ASCIZ /CONTENTS OF ERROR SECTOR (REPORTED ABOVE)/<CR><LF>
7791	052004	051524	047440	020106	
7792	052012	051105	047522	020122	
7793	052020	042523	052103	051117	
7794	052026	024040	042522	047520	
7795	052034	052122	042105	040440	
7796	052042	047502	042526	006451	
7797	052050	000012			
7798	052052	042101	051104	020040	.ASCIZ /ADDR DATA/<CR><LF>
7799	052060	020040	040504	040524	
7800	052066	005015	000		
7801	052071	040	040		LIN4SP: .ASCII / /
7802	052073	040			LIN5P: .ASCII / /
7803	052074	000040			LIN5PO: .ASCIZ / /
7804					
7805					.SBTTL TELETYPE MESSAGES
7806					
7807	052076	051104	053111	000105	UNTMSG: .ASCIZ /DRIVE/
7808	052104	047440	043106	044514	UNTOFF: .ASCIZ / OFFLINE/
7809	052112	042516	000		
7810	052115	040	047117	044514	UNTON: .ASCIZ / ONLINE/
7811	052122	042516	000		
7812	052125	040	047516	020124	UNTNOT: .ASCIZ / NOT BEING TESTED/
7813	052132	042502	047111	020107	
7814	052140	042524	052123	042105	
7815	052146	000			
7816	052147	040	046101	042522	UNTASN: .ASCIZ / ALREADY BEING TESTED/
7817	052154	042101	020131	042502	
7818	052162	047111	020107	042524	
7819	052170	052123	042105	000	
7820	052175	040	047516	020124	NOTRP: .ASCIZ / NOT AN RPO4.5/60

7821	052202	047101	051040	030120	
7822	052210	027464	027465	000066	
7823	052216	047040	052117	050040	NOTPRS: .ASCIZ / NOT PRESENT/
7824	052224	042522	042523	052116	
7825	052232	000			
7826	052233	040	047516	020124	NOTAVL: .ASCIZ / NOT AVAILABLE/
7827	052240	053101	044501	040514	
7828	052246	046102	000105		
7829	052252	052440	051516	043101	NOTSAF: .ASCIZ / UNSAFE/
7830	052260	000105			
7831	052262	047125	052111	051440	SYSTAT: .ASCIZ /UNIT STATUS:/(CR)(LF)(LF)
7832	052270	040524	052524	035123	
7833	052276	005015	000012		
7834	052302	050122	032060	000	RPO4B: .ASCIZ /RPO4/
7835	052307	122	030120	000065	RPO5: .ASCIZ /RPO5/
7836	052314	050122	033060	000	RPO6: .ASCIZ /RPO6/
7837	052321	104	044522	042526	STATHD: .ASCII /DRIVE PERFORMANCE SUMMARY/(CR)(LF)
7838	052326	050040	051105	047506	
7839	052334	046522	047101	042503	
7840	052342	051440	046525	040515	
7841	052350	054522	005015		
7842	052354	051104	020126	040520	.ASCII /DRV PASS ORDERS SEEKS WRDS XFER WRDS READ /
7843	052362	051523	047440	042122	
7844	052370	051105	020123	020040	
7845	052376	042523	045505	020123	
7846	052404	020040	051127	051504	
7847	052412	054040	042506	020122	
7848	052420	020040	051127	051504	
7849	052426	051040	040505	020104	
7850	052434	047523	052106	044040	.ASCIZ /SOFT HARD SKI MISP OTHER/(CR)(LF)
7851	052442	051101	020104	051440	
7852	052450	044513	046440	051511	
7853	052456	020120	052117	042510	
7854	052464	006522	000012		
7855	052470	047504	042516	005015	PDONE: .ASCIZ /DONE/(CR)(LF)(LF)
7856	052476	000012			
7857	052500	037407	040506	040524	DROPNG: .ASCIZ (C7)/?FATAL OR EXCESSIVE ERRORS/
7858	052506	020114	051117	042440	
7859	052514	041530	051505	044523	
7860	052522	042526	042440	051122	
7861	052530	051117	000123		
7862	052534	047105	020104	043117	ENDPAS: .ASCIZ /END OF PASS/
7863	052542	050040	051501	000123	
7864	052550	005015	047105	020104	ENDTST: .ASCIZ (CR)(LF)/END OF TEST/
7865	052556	043117	052040	051505	
7866	052564	000124			
7867	052566	005015	051104	053111	DEASSG: .ASCIZ (CR)(LF)/DRIVE DEASSIGNED/
7868	052574	020105	042504	051501	
7869	052602	044523	047107	042105	
7870	052610	000			
7871	052611	015	025012	025052	DRNUM: .ASCIZ (CR)(LF)/***** DRIVE #.
7872	052616	025052	025052	025052	
7873	052624	020052	051104	053111	
7874	052632	020105	000043		

7975	052636	051440	040524	052122	ASGND: .ASCIZ / STARTED/<CR><LF>
7976	052644	042105	005015	000	
7977	052651	015	037412	023440	NEDCLK: .ASCIZ <CR><LF>/? 'L' OR 'P' CLOCK REQUIRED ON SYSTEM/<CR><LF>
7978	052656	023514	047440	020122	
7979	052664	050047	020047	046103	
7980	052672	041517	020113	042522	
7981	052700	052521	051111	042105	
7982	052706	047440	020116	054523	
7983	052714	052123	046505	005015	
7984	052722	000			
7985	052723	056	000		PERIOD: .ASCIZ /:/
7986	052725	077	000		QUES: .ASCIZ /:/
7987	052727	111	053116	046101	INVLD: .ASCIZ /INVALID COMMAND/<CR><LF>
7988	052734	042111	041440	046517	
7989	052742	040515	042116	005015	
7990	052750	000			
7991	052751	015	042412	052116	ENTCOM: .ASCIZ <CR><LF>/ENTER COMMANDS: /<CR><LF>
7992	052756	051105	041440	046517	
7993	052764	040515	042116	035123	
7994	052772	006440	000012		
7995	052776	047105	042524	020122	ENTDRV: .ASCIZ /ENTER I.D. FOR DRV #/
7996	053004	027111	027104	043040	
7997	053012	051117	042040	053122	
7998	053020	021440	000		
7999	053023	015	042412	052116	ENTLMT: .ASCIZ <CR><LF>/ENTER ADDRESS LIMITS FOR DRV #/
7900	053030	051105	040440	042104	
7901	053036	042522	051523	046040	
7902	053044	046511	052111	020123	
7903	053052	047506	020122	051104	
7904	053060	020126	000043		
7905	053064	047105	042524	020122	ENTADR: .ASCIZ #ENTER BAD TRK/SEC ADRS FOR DRV #
7906	053072	040502	020104	051124	
7907	053100	027513	042523	020103	
7908	053106	042101	051522	043040	
7909	053114	051117	042040	053122	
7910	053122	021440	000		
7911	053125	072	000		COLON: .ASCIZ /:/
7912	053127	015	042012	052101	DATEIS: .ASCIZ <CR><LF>/DATE: /
7913	053134	035105	000040		
7914	053140	005015	050117	051105	IDIS: .ASCIZ <CR><LF>/OPERATOR I.D.: /
7915	053146	052101	051117	044440	
7916	053154	042056	035056	000040	
7917	053162	005015	042012	053122	HEDLIN: .ASCIZ <CR><LF><LF>/DRV DRV I.D./<CR><LF>
7918	053170	020040	051104	020126	
7919	053176	027111	027104	005015	
7920	053204	000			
7921	053205	116	047117	006505	NONE: .ASCIZ /NONE/<CR><LF>
7922	053212	000012			
7923	053214	020077	047111	040526	BADENT: .ASCIZ /? INVALID ENTRY/<CR><LF>
7924	053222	044514	020104	047105	
7925	053230	051124	006531	000012	
7926	053236	054523	052123	046505	BUSY: .ASCIZ /SYSTEM BUSY.../<CR><LF>
7927	053244	041040	051525	027131	
7928	053252	027056	005015	000	

```

7929 053257 015 050012 047522 INTDON: .ASCII <CR><LF>/PROGRAM INITIALIZATION COMPLETE/
7930 053264 051107 046501 044440
7931 053272 044516 044524 046101
7932 053300 055111 052101 047511
7933 053306 020116 047503 050115
7934 053314 042514 042524
7935 053320 005015 054524 042520 .ASCIZ <CR><LF>/TYPE A 'CONTROL C' TO ENTER COMMANDS/<CR><LF><LF>
7936 053326 040440 023440 047503
7937 053334 052116 047522 020114
7938 053342 023503 052040 020117
7939 053350 047105 042524 020122
7940 053356 047503 046515 047101
7941 053364 051504 005015 000012
7942
7943 .EVEN
7944
7945 ;PARAMETER ENTRY TABLE
7946
7947 053372 053520 000000 001364 PAR_ST: .WORD PAR1,0,MAXDL
7948 053400 053526 177777 001370 .WORD PAR2,-1,INTRVL
7949 053406 053656 177777 001362 .WORD PAR19,-1,PASCNT
7950 053414 053535 177777 001374 .WORD PAR3,-1,CMPLMT
7951 053422 053625 000001 001400 .WORD PAR11,1,WCSEL
7952 053430 053633 000007 001402 .WORD PAR14,7,RATIO
7953 053436 053650 000001 001410 .WORD PAR16,1,ENDET
7954 053444 053616 000001 001376 .WORD PAR10,1,FORMAT
7955 053452 053641 000001 001404 .WORD PAR15,1,AUTOCK
7956 053460 053665 000001 001406 .WORD PAR20,1,NOTPRT
7957 053466 000000 .WORD 0 ;TABLE TERMINATOR
7958
7959 053470 047105 042524 020122 ASKPAR: .ASCIZ /FITER PARAMETERS: /
7960 053476 040520 040522 042515
7961 053504 042524 051522 020072
7962 053512 000040
7963 053514 027440 000040 SLASH: .ASCIZ @ / @
7964
7965 053520 040515 042130 000114 PAR1: .ASCIZ /MAXDL/
7966 053526 047111 051124 046126 PAR2: .ASCIZ /INTRVL/
7967 053534 000
7968 053535 103 050115 046514 PAR3: .ASCIZ /CMPLMT/
7969 053542 000124
7970 053544 040515 041530 046131 PAR4: .ASCIZ /MAXCYL/
7971 053552 000
7972 053553 115 047111 054503 PAR5: .ASCIZ /MINCYL/
7973 053560 000114
7974 053562 040515 052130 045522 PAR6: .ASCIZ /MAXTRK/
7975 053570 000
7976 053571 115 047111 051124 PAR7: .ASCIZ /MINTRK/
7977 053576 000113
7978 053600 040515 051530 041505 PAR8: .ASCIZ /MAXSE.
7979 053606 000
7980 053607 115 047111 042523 PAR9: .ASCIZ /MINSEC/
7981 053614 000103
7982 053616 047506 046522 052101 PAR10: .ASCIZ /FORMAT/

```

```

7993 053624 000
7994 053625 127 051503 046105 PAR11: .ASCIZ /WCSEL/
7995 053632 000
7996 053633 122 052101 047511 PAR14: .ASCIZ /RATIO/
7997 053640 000
7998 053641 101 052125 041517 PAR15: .ASCIZ /AUTOCK/
7999 053646 000113
8000 053650 047105 042504 000124 PAR16: .ASCIZ /ENDET/
8001 053656 040520 041523 052116 PAR19: .ASCIZ /PASCNT/
8002 053664 000
8003 053665 116 052117 051120 PAR20: .ASCIZ /NOTPRT/
8004 053672 000124

```

.EVEN

;PARAMETER TABLE POINTERS FOR ADDRESS LIMITS

```

8000 053674 053714 TABLE: .WORD TABLE0 ;PARAMETER TABLE FOR DRIVE 0
8001 053676 053762 .WORD TABLE1 ;PARAMETER TABLE FOR DRIVE 1
8002 053700 054030 .WORD TABLE2 ;PARAMETER TABLE FOR DRIVE 2
8003 053702 054076 .WORD TABLE3 ;PARAMETER TABLE FOR DRIVE 3
8004 053704 054144 .WORD TABLE4 ;PARAMETER TABLE FOR DRIVE 4
8005 053706 054212 .WORD TABLE5 ;PARAMETER TABLE FOR DRIVE 5
8006 053710 054260 .WORD TABLE6 ;PARAMETER TABLE FOR DRIVE 6
8007 053712 054326 .WORD TABLE7 ;PARAMETER TABLE FOR DRIVE 7

```

;PARAMETER TABLE FOR ADDRESS LIMITS

```

8011 053714 053553 000000 041716 TABLE0: .WORD PAR5,0,MINCYL+DRIVE0
8012 053722 053544 000000 041714 .WORD PAR4,0,MAXCYL+DRIVE0
8013 053730 053571 000022 041722 .WORD PAR7,18.,MINTRK+DRIVE0
8014 053736 053562 000022 041720 .WORD PAR6,18.,MAXTRK+DRIVE0
8015 053744 053607 000025 041726 .WORD PAR9,21.,MINSEC+DRIVE0
8016 053752 053600 000025 041724 .WORD PAR8,21.,MAXSEC+DRIVE0,0
8017 053760 000000

```

```

8019 053762 053553 000000 042222 TABLE1: .WORD PAR5,0,MINCYL+DRIVE1
8020 053770 053544 000000 042220 .WORD PAR4,0,MAXCYL+DRIVE1
8021 053776 053571 000022 042226 .WORD PAR7,18.,MINTRK+DRIVE1
8022 054004 053562 000022 042224 .WORD PAR6,18.,MAXTRK+DRIVE1
8023 054012 053607 000025 042232 .WORD PAR9,21.,MINSEC+DRIVE1
8024 054020 053600 000025 042230 .WORD PAR8,21.,MAXSEC+DRIVE1,0
8025 054026 000000

```

```

8027 054030 053553 000000 042526 TABLE2: .WORD PAR5,0,MINCYL+DRIVE2
8028 054036 053544 000000 042524 .WORD PAR4,0,MAXCYL+DRIVE2
8029 054044 053571 000022 042532 .WORD PAR7,18.,MINTRK+DRIVE2
8030 054052 053562 000022 042530 .WORD PAR6,18.,MAXTRK+DRIVE2
8031 054060 053607 000025 042536 .WORD PAR9,21.,MINSEC+DRIVE2
8032 054066 053600 000025 042534 .WORD PAR8,21.,MAXSEC+DRIVE2,0
8033 054074 000000

```

```

8035 054076 053553 000000 043032 TABLE3: .WORD PAR5,0,MINCYL+DRIVE3
8036 054104 053544 000000 043030 .WORD PAR4,0,MAXCYL+DRIVE3

```

H15

```

8037 054112 053571 000022 043036 .WORD PAR7,18.,MINTRK+DRIVE3
8038 054120 053562 000022 043034 .WORD PAR6,18.,MAXTRK+DRIVE3
8039 054126 053507 000025 043042 .WORD PAR9,21.,MINSEC+DRIVE3
8040 054134 053600 000025 043040 .WORD PAR8,21.,MAXSEC+DRIVE3.0
8041 054142 000000
8042
8043 054144 053553 000000 043336 TABLE4: .WORD PAR5,0,MINCYL+DRIVE4
8044 054152 053544 000000 043334 .WORD PAR4,0,MAXCYL+DRIVE4
8045 054160 053571 000022 043342 .WORD PAR7,18.,MINTRK+DRIVE4
8046 054166 053562 000022 043340 .WORD PAR6,18.,MAXTRK+DRIVE4
8047 054174 053607 000025 043346 .WORD PAR9,21.,MINSEC+DRIVE4
8048 054202 053600 000025 043344 .WORD PAR8,21.,MAXSEC+DRIVE4.0
8049 054210 000000
8050
8051 054212 053553 000000 043642 TABLE5: .WORD PAR5,0,MINCYL+DRIVES
8052 054220 053544 000000 043640 .WORD PAR4,0,MAXCYL+DRIVES
8053 054226 053571 000022 043646 .WORD PAR7,18.,MINTRK+DRIVES
8054 054234 053562 000022 043644 .WORD PAR6,18.,MAXTRK+DRIVES
8055 054242 053607 000025 043652 .WORD PAR9,21.,MINSEC+DRIVES
8056 054250 053600 000025 043650 .WORD PAR8,21.,MAXSEC+DRIVES,0
8057 054256 000000
8058
8059 054260 053553 000000 044146 TABLE6: .WORD PAR5,0,MINCYL+DRIVE6
8060 054266 053544 000000 044144 .WORD PAR4,0,MAXCYL+DRIVE6
8061 054274 053571 000022 044152 .WORD PAR7,18.,MINTRK+DRIVE6
8062 054302 053562 000022 044150 .WORD PAR6,18.,MAXTRK+DRIVE6
8063 054310 053607 000025 044156 .WORD PAR9,21.,MINSEC+DRIVE6
8064 054316 053600 000025 044154 .WORD PAR8,21.,MAXSEC+DRIVE6,0
8065 054324 000000
8066
8067 054326 053553 000000 044452 TABLE7: .WORD PAR5,0,MINCYL+DRIVE7
8068 054334 053544 000000 044450 .WORD PAR4,0,MAXCYL+DRIVE7
8069 054342 053571 000022 044456 .WORD PAR7,18.,MINTRK+DRIVE7
8070 054350 053562 000022 044454 .WORD PAR6,18.,MAXTRK+DRIVE7
8071 054356 053607 000025 044462 .WORD PAR9,21.,MINSEC+DRIVE7
8072 054364 053600 000025 044460 .WORD PAR8,21.,MAXSEC+DRIVE7.0
8073 054372 000000
8074
8075
8076 054374 000000 000000 000000 CYLDER: .WORD 0,0,0,0 ;HEADER BUFFER FOR 'READHD' ROUTINE
8077 054402 000000
8078
8079 054404 ENDPGM = . ;LAST LOCATION OF PROG + 2
8080
8081 ;*****
8082
8083 ;ROUTINE TO GET THE DATE AND THE OPERATOR FROM THE OPERATOR
8084 ;CALL:
8085 ; JSR PC,OPRDAT
8086 ; RETURN
8087 ;
8088 ;NOTE: THIS ROUTINE IS ENTERED ONLY AT INITIAL START
8089
8090 054404 104401 054516 OPRDAT: TYPE ,ENTDAT ;'ENTER DATE'

```

```

8091 054410 104411 RDLIN ; READ THE ENTRY
8092 054412 012605 MOV (SP)+,R5 ; PUT THE ENTRY ADDRESS INTO R5
8093 054414 112537 001220 MOV (R5)+,DATE ; STORE THE DATE
8094 054420 112537 001221 MOV (R5)+,DATE+1 ; STORE THE DATE
8095 054424 112537 001222 MOV (R5)+,DATE+2 ; STORE THE DATE
8096 054430 112537 001223 MOV (R5)+,DATE+3 ; STORE THE DATE
8097 054434 112537 001224 MOV (R5)+,DATE+4 ; STORE THE DATE
8098 054440 112537 001225 MOV (R5)+,DATE+5 ; STORE THE DATE
8099 054444 112537 001226 MOV (R5)+,DATE+6 ; STORE THE DATE
8100 054450 112537 001227 MOV (R5)+,DATE+7 ; STORE THE DATE
8101 054454 104401 054535 TYPE ,ENTID ; 'ENTER OPERATOR I.D.'
8102 054450 104411 RDLIN ; READ THE ENTRY
8103 054462 012605 MOV (SP)+,R5 ; ENTRY ADDRESS
8104 054464 112537 001232 MOV (R5)+,OPERID ; STORE THE I.D.
8105 054470 112537 001233 MOV (R5)+,OPERID+1 ; STORE THE I.D.
8106 054474 112537 001234 MOV (R5)+,OPERID+2 ; STORE THE I.D.
8107 054500 112537 001235 MOV (R5)+,OPERID+3 ; STORE THE I.D.
8108 054504 112537 001236 MOV (R5)+,OPERID+4 ; STORE THE I.D.
8109 054510 112537 001237 MOV (R5)+,OPERID+5 ; STORE THE I.D.
8110 054514 000207 RTS PC ; RETURN
8111
8112 054516 005015 047105 042524 ENTDAT: .ASCIZ <CR><LF>/ENTER DATE: /
8113 054524 020122 040504 042524
8114 054532 020072 000
8115 054535 105 052116 051105 ENTDAT: .ASCIZ /ENTER OPERATOR I.D.: /
8116 054542 047440 042520 040522
8117 054550 047524 020122 027111
8118 054556 027104 020072 000
8119 054564
8120 .EVEN
8121 .SBTTL ROUTINE TO SIZE MEMORY
8122
8123 ;*****
8124 ;*CALL:
8125 ;* JSR PC,$SIZE
8126 ;* RETURN
8127 ;*$LSTAD WILL CONTAIN THE LAST AVAILABLE MEMORY LOCATION
8128
8129 $SIZE: MOV R0,-(SP) ; SAVE R0 ON THE STACK
8130 054566 010146 MOV R1,-(SP) ; SAVE R1 ON THE STACK
8131 054570 013745 000004 MOV @#ERRVEC,-(SP) ; SAVE PRESENT ERROR VECTOR PS & PC
8132 054574 013746 000006 MOV @#ERRVEC+2,-(SP)
8133 054600 010600 MOV SP,R0 ; SAVE THE STACK POINTER
8134 ;:SET THE ERRVEC PS TO THE PRESENT PS
8135 054602 104400 TRAP ;:PUSH OLD PSW AND PC ON STACK
8136 054604 012637 000006 MOV (SP)+,@#ERRVEC+2 ;:SAVE THE PSW IN @#ERRVEC+2
8137 054610 012737 054630 000004 MOV #2,@#ERRVEC ;:SET FOR TIMEOUT
8138 054616 012701 020000 MOV #20000,R1 ;:FIRST ADDRESS
8139 054622 005711 1$: TST (R1) ;:TEST THIS ADDRESS
8140 054624 005721 TST (R1)+ ;:STEP TO NEXT ADDRESS
8141 054626 000775 BR 1$ ;:TRY ANOTHER
8142 054630 162701 000002 2$: SUB #2,R1 ;:CROP BACK
8143 054634 010006 MOV R0,SP ;:RESTORE THE STACK
8144 054636 012637 000006 MOV (SP)+,@#ERRVEC+2 ;:RESTORE ERROR VECTOR

```

```

8145 054642 012637 000004      MOV      (SP)+, @#ERRVEC
8146 054646 010137 054660      MOV      R1, $LSTAD      ;; LAST ADDRESS
8147 054652 012601      MOV      (SP)+, R1      ;; RESTORE R1
8148 054654 012600      MOV      (SP)+, R0      ;; RESTORE R0
8149 054656 000207      RTS      PC
8150 054660 000000      $LSTAD: .WORD 0          ;; CONTAINS THE LAST ADDRESS
8151
8152      .SBTTL  BUSADR - GET BUS ADDRESS AND VECTOR ADDRESS FOR RH11
8153      :THIS ROUTINE IS USED TO INSURE THE BUS ADDRESS
8154      :OF THE RH11 IS SETUP FOR THE PROPER ADDRESS.
8155      :IT WILL ALSO READ THE ADDRESS FROM THE TTY IF
8156      :REQUIRED.
8157      :NOTE: THIS ROUTINE DESTROYS R0-R4
8158      :CALL
8159      :
8160      :
8161      :      JSR      PC, BUSADR
8162      :      RETURN
8163 054662 005737 001260      BUSADR: TST      CHGADR      ; INPUT FROM TTY REQUESTED?
8164 054666 001450      BEQ      7$              ; NO--BRANCH
8165 054670 005037 001260      CLR      CHGADR      ; YES--CLEAR THE REQUEST FLAG
8166 054674 012700 001179      1$:  MOV      #SRPADR, R0 ; FIRST ADDRESS
8167 054700 104401 055072      TYPE    MRPCS1        ; "RPCS1="
8168 054704 012046      MOV      (R0)+, -(SP)  ; PRESENT RPCS1 ADDRESS
8169 054706 104402      TYPOC   ; TYPE IT
8170 054710 104401 052073      TYPE    .LINSF        ; 2 SPACES
8171 054714 104411      RDLIN   ; GET THE ENTRY
8172 054716 012601      MOV      (SP)+, R1     ; ADDRESS OF ASCII TEXT
8173 054720 004537 055114      JSR      R5, CK.NUM    ; CHECK THE NUMBER
8174 054724 054744      3$     ; CARRIAGE RETURN ONLY ENTERED
8175 054726 055010      7$     ; PERIOD ONLY ENTERED
8176 054730 054674      1$     ; ILLEGAL INPUT
8177 054732 054740      2$     ; TERMINATED WITH A CARRIAGE RETURN
8178 054734 054674      1$     ; TERMINATED WITH A "."
8179 054736 055004      4$     ; TERMINATED WITH A ":"
8180 054740 010260 177776      2$:  MOV      R2, -2(R0)   ; SAVE NEW RPCS1
8181 054744 104401 055103      3$:  TYPE    MRHVEC      ; "RHVEC="
8182 054750 012046      MOV      (R0)+, -(SP) ; PRESENT RH11 VECTOR ADDRESS ON THE STACK
8183 054752 104402      TYPOC   ; TYPE IT
8184 054754 104401 052073      TYPE    .LINSF        ; 2 SPACES
8185 054760 104411      RDLIN   ; READ THE ENTRY
8186 054762 012601      MOV      (SP)+, R1     ; ASCII TEXT ADDRESS
8187 054764 004537 055114      JSR      R5, CK.NUM    ; CHECK THE NUMBER
8188 054770 055010      7$     ; CARRIAGE RETURN ONLY ENTERED
8189 054772 055010      7$     ; PERIOD ONLY ENTERED
8190 054774 054744      3$     ; ILLEGAL INPUT
8191 054776 055004      4$     ; TERMINATED WITH A CARRIAGE RETURN
8192 055000 054744      3$     ; TERMINATED WITH A "."
8193 055002 055004      4$     ; TERMINATED WITH A ":"
8194 055004 010260 177776      4$:  MOV      R2, -2(R0)   ; SAVE INPUT
8195 055010 013701 000004      7$:  MOV      ERRVEC, R1    ; SAVE THE ERROR VECTOR
8196 055014 012737 055050 000004      MOV      #8$, ERRVEC   ; SETUP FOR TRAP
8197 055022 005777 124142      TST      @SRPADR      ; CHECK FOR RH11
8198 055026 010137 000004      MOV      R1, ERRVEC    ; RESTORE ERROR VECTOR

```



```

8199 055032 012700 001170      MOV      #SRPADR,R0      ;FIRST ADDRESS OF NEW PARAMETERS
8200 055036 012701 033250      MOV      #RPADR,R1      ;FIRST ADDRESS OF WHERE TO PUT THEM
8201 055042 012021          MOV      (R0)+,(R1)+    ;BUS ADDRESS
8202 055044 012021          MOV      (R0)+,(R1)+    ;VECTOR ADDRESS
8203 055046 000207          RTS      PC              ;RETURN
8204 055050 010137 000004      8$: MOV      R1,ERRVEC    ;RESTORE ERROR VECTOR
8205 055054 022626          CMP      (SP)+,(SP)+    ;CLEAN OFF THE STACK
8206 055056 104006          ERROR   6              ;REPORT THE ERROR
8207 055060 005737 000042      TST     @#42            ;IS THERE A MONITOR?
8208 055064 001703          BEQ     1$              ;NO--GO ASK FOR ADDRESS
8209 055066 000137 005256      JMP     $GET42          ;GO TO END OF PROGRAM
8210
8211 055072 050122 051503 02J061 MRPCS1: .ASCIZ @RPCS1 = @
8212 055100 020075      000
8213 055103      122 053110 041505 MRHVEC: .ASCIZ @RHVEC = @
8214 055110 036440 000040
8215
8216          .SBTTL CK.NUM - CHECK NUMBER (OCTAL)
8217          ;THIS ROUTINE CHECKS AN ASCIZ STRING FOR LEGAL CHARACTERS
8218          ;AND FORMS AN OCTAL NUMBER IN R2
8219          ;CALL:
8220          ;
8221          ;
8222          ;
8223          ;
8224          ;
8225          ;
8226          ;
8227          ;
8228          ;
8229          ;
8230 055114 010446      CK.NUM: MOV      R4,-(SP)    ;SAVE R4
8231 055116 010346      MOV      R3,-(SP)    ;SAVE R3
8232 055120 010246      MOV      R2,-(SP)    ;SAVE R2
8233 055122 005004      CLR     R4            ;RETURN POINTER
8234 055124 005003      CLR     R3            ;START NUMBER AT ZERO
8235 055126 005002      CLR     R2            ;STORE RESULT
8236 055130 004537 027510      JSR     R5,CK.CHR    ;CHECK ONE CHARACTER
8237 055134 055232      6$              ;ILLEGAL CHARACTER
8238 055136 055236      8$              ;CARRIAGE RETURN
8239 055140 055232      6$              ;
8240 055142 055234      7$              ;
8241 055144 055150      1$              ;DIGIT 0-7
8242 055146 055232      6$              ;DIGIT 8-9
8243 055150 062705 000004      1$: ADD     #4,R5      ;INCREMENT RETURN PAST "CR" AND "PERIOD" ONLY RETURNS
8244 055154 006303      2$: ASL     R3          ;FOR THE OCTAL NUMBER IN R3
8245 055156 103425      BCS     6$          ;DON'T LET IT GET TO BIG
8246 055160 006303      ASL     R3
8247 055162 103423      BCS     6$
8248 055164 006303      ASL     R3
8249 055166 103421      BCS     6$
8250 055170 060203      ADD     R2,R3
8251 055172 004537 027510      JSR     R5,CK.CHR    ;CHECK ONE CHARACTER
8252 055176 055236      8$              ;ILLEGAL CHARACTER
    
```

8253	055200	055222			5\$				:CARRIAGE RETURN
8254	055202	055220			4\$				:..
8255	055204	055212			3\$				:..
8256	055206	055154			2\$				:DIGIT 0-7
8257	055210	055236			8\$				:DIGIT 8-9
8258	055212	105711			3\$:	TSTB	(R1)		:DOES A "CR" FOLLOW THE "PERIOD"
8259	055214	001010				BNE	8\$		:BR IF NOT
8260	055216	005724				TST	(R4)+		:INCREMENT THE RETURN
8261	055220	005724			4\$:	TST	(R4)+		:INCREMENT THE RETURN INDEX
8262	055222	005724			5\$:	TST	(R4)+		:INCREMENT THE RETURN INDEX
8263	055224	020316				CMP	R3,(SP)		:INPUT VALUE TOO LARGE ?
8264	055226	101003				BHI	8\$		:BR IF IT IS
8265	055230	000401				BR	7\$		:BR IF NOT
8266	055232	005725			6\$:	TST	(R5)+		:INCREMENT THE RETURN ADDRESS
8267	055234	005725			7\$:	TST	(R5)+		:INCREMENT THE RETURN ADDRESS
8268	055236	060405			8\$:	ADD	R4,R5		:SETUP FOR PROPER RETURN
8269	055240	010302				MOV	R3,R2		:LOAD ENTERED VALUE
8270	055242	005726				TST	(SP)+		:CLEAN OFF THE STACK
8271	055244	012603				MOV	(SP)+,R3		:RESTORE R3
8272	055246	012604				MOV	(SP)+,R4		:RESTORE R4
8273	055250	011505				MOV	(R5),R5		:GET RETURN ADDRESS
8274	055252	000205				RTS	R5		:RETURN
8275									
8276									
8277	055254	005015	040515	047111	TITLE:	.ASCII	<CR><LF>/MAINDEC-11-DZRJD-A/<CR><LF>		
8278	055262	042504	026503	030461					
8279	055270	042055	051132	042112					
8280	055276	040455	005015						
8281	055302	050122	032060	032457		.ASCIZ	@RPO4/5/6 MULTI-DRIVE EXERCISER PROGRAM@<CR><LF><LF>		
8282	055310	033057	046440	046125					
8283	055316	044524	042055	044522					
8284	055324	042526	042440	042530					
8285	055332	041522	051511	051105					
8286	055340	050040	047522	051107					
8287	055346	046501	005015	000012					
8288	055354	005015	047524	052040	LOADRV:	.ASCII	<CR><LF>/TO TEST DRIVE 0, REPLACE THE 'XXDP' PACK ON DRIVE 0/<CR><LF>		
8289	055362	051505	020124	051104					
8290	055370	053111	020105	026060					
8291	055376	051040	050105	040514					
8292	055404	042503	052040	042510					
8293	055412	023440	054130	050104					
8294	055420	020047	040520	045503					
8295	055426	047440	020116	051104					
8296	055434	053111	020105	006460					
8297	055442	012							
8298	055443	127	052111	020110		.ASCII	/WITH ANOTHER PACK, CLEAR MEMORY LOCATION 40,/<CR><LF>		
8299	055450	047101	052117	042510					
8300	055456	020122	040520	045503					
8301	055464	020054	046103	040505					
8302	055472	020122	042515	047515					
8303	055500	054522	046040	041517					
8304	055506	052101	047511	020116					
8305	055514	030064	006454	012					
8306	055521	101	042116	051040		.ASCIZ	/AND RESTART THE PROGRAM/<CR><LF>		

# M15

MD-11-DZRJD-A, RPO4/5/6 MULTI-DRIVE EXERCISER MACY11 27(655) 28-APR-76 17:04 PAGE 157  
DZRJD.019 CK.NUM - CHECK NUMBER (OCTAL)

SEQ 0193

8307	055526	051505	040524	052122
8308	055534	052040	042510	050040
8309	055542	047522	051107	046501
8310	055550	005015	000	
8311	055553	015	051412	051531
8312	055560	042524	020115	040510
8313	055566	020123	033061	020113
8314	055574	042515	047515	054522
8315	055602	020054	054047	042130
8316	055610	023520	046040	040517
8317	055616	042504	020122	044527
8318	055624	046114	041040	020105
8319	055632	053117	051105	051127
8320	055640	052111	042524	006516
8321	055646	000012		
8322				
8323	000001			

NOLOAD: .ASCIZ <CR><LF>/SYSTEM HAS 16K MEMORY, 'XXDP' LOADER WILL BE OVERWRITTEN/<CR><L

.END

ABNRML	026454	ABS	=	000200	ACK	=	000123	ACL	=	000040
ACTDRV	033166	ACTSTR		033167	ACU	=	100000	AOE	=	001000
ASGND	052636	ASGN1		024144	ASGN2		024224	ASGN3		024276
ASGN4	024414	ASGN5		024424	ASGN6		024432	ASGN7		024442
ASKPAR	053470	ASNERR		026346	ASNLST		001442	ASNMSG		026366
ASSIGN	024136	ATA	=	100000	ATABIT		033236	ATTN		001244
ATO	=	AT1	=	000002	AT2	=	000004	AT3	=	000010
AT4	=	AT5	=	000040	AT6	=	000100	AT7	=	000200
AUTOCK	001404	AVAIL		001510	A16	=	000400	A17	=	001000
BADENT	053214	BADSEC		001264	BAI	=	000010	BEGCOD		001414
BEGPAT	001412	BEGSIZ		001416	BIT0	=	000001	BIT00	=	000001
BIT01	=	BIT02	=	000004	BIT03	=	000010	BIT04	=	000020
BIT05	=	BIT06	=	000100	BIT07	=	000200	BIT08	=	000400
BIT09	=	BIT1	=	000002	BIT10	=	002000	BIT11	=	004000
BIT12	=	BIT13	=	020000	BIT14	=	040000	BIT15	=	100000
BIT2	=	BIT3	=	000010	BIT4	=	000020	BITS	=	000040
BIT6	=	BIT7	=	000200	BIT8	=	000400	BIT9	=	001000
BLKADR	001720	BPTVEC	=	000014	BUFTBL		001576	BUSADR		054662
BUSY	053236	CFLAG		001262	CHGADR		001260	CI1		034610
CI3	034716	CI4		035024	CI5		035402	CI6		035424
CI7	035440	CI7B		035466	CI8		035540	CKBUS		013020
CKCLK	022342	CKCLK1		022436	CKCLK2		022504	CKCLK3		022534
CKERR	012720	CKFMT		011022	CKHCE		011216	CKSWR	=	104407
CK.CHR	027510	CK.DEC		027462	CK.DIG		027562	CK.NUM		055114
CK.OCT	027434	CLKFLG		001210	CLOCK		023476	CLR	=	000040
CLRDPB	025114	CLRQUE		041350	CMCNT		001312	CMCYL		001314
CMDAT	013366	CMHED		013272	CMPAR		013104	CMPARD		013122
CMPLMT	001374	CMPRES		017460	CMPRT		013632	CMPRX		013624
CMSEC	001316	CMSTR		013214	CMTRK		001317	COLON		053125
COMTBL	001740	CR	=	000015	CRLF	=	000200	CSF	=	000002
CSU	=	CYLDER		054374	CYLIMT		001350	DATAPK		025070
DATA0	003006	DATA1		003046	DATE		001220	DATEIS		053127
DCK	=	DCKER		007520	DCKER1		007652	DCL	=	000100
DCU	=	DDISP	=	177570	DEASGN		024512	DEASSG		052566
DE1	=	OFF20	=	000002	DH1		047376	DH14		047554
DH15	047660	DH16		047757	DH2		047403	DH3		047460
DH4	047506	DH6		047545	DIGB	=	000004	DISPLA		001142
DISPLY	=	DISPRE		000174	DLT	=	100000	DL64	=	000020
DMD	=	DONE		007214	DPINT		033142	DPR	=	000400
DPRQS	033152	DRIVE		001242	DRIVE0		041606	DRIVE1		042112
DRIVE2	042416	DRIVE3		042722	DRIVE4		043226	DRIVE5		043532
DRIVE6	044036	DRIVE7		044342	DRNUM		052611	DROP		026376
DROPNG	052500	DRQ	=	004000	DRVACT		033112	DRVCLR	=	000111
DRVER	010770	DRVINT		033500	DRVPRM		025310	DRVQUE		041446
DRVSTA	033122	DRVYTP		033132	DRY	=	000200	DSWR	=	177570
DTE	=	DTEER		011626	DTSY	=	000200	DTUW		033234
DT00	=	DT01	=	000002	DT02	=	000004	DT03	=	000010
DT04	=	DT05	=	000040	DT06	=	000100	DT07	=	000200
DT08	=	DT1		050030	DT14		050100	DT15		050122
DT16	050144	DT2		050034	DT3		050052	DT4		050062
DT6	050074	DUNIT		001444	DVA	=	004000	ECBADO		001334
ECBAD1	001342	ECBIT		001320	ECC		014232	ECCX		014764
ECC1	014630	ECC2		014760	ECGD		001332	ECGD1		001340
ECH	=	ECI	=	004000	ECMSK0		001324	ECMSK1		001326



LIN90 051460  
LSTAD 001256  
LSTAD = 002000  
MAIN2 005572  
MAXCYL 000106  
MAXTRK 000112  
MHS 001000  
MINUTE 001270  
MOH 020000  
MRO 000020  
MSTCK 000010  
MXLACT 033256  
M.OP41 027144  
M.OP42 027154  
MBA 100000  
NEWASN 024502  
NOMTCH 012476  
NCTPRT 001406  
OFFC00 002200  
OFMSG0 002254  
OFMSG1 002307  
OFMSG2 002343  
OFMSG3 002377  
OFMSG4 002433  
OFMSG5 002467  
OFMSG6 002523  
OFMSG7 002557  
OFMTBL 002220  
OFREV 000200  
OF400 000020  
OF50 000002  
OF50 = 000000  
OPI 020000  
OPT 034330  
OPTBL 001746  
PAR 000010  
PAR0 001554  
PAR1 053520  
PAR15 053641  
PAR20 053665  
PAR6 053562  
PASCNT 001362  
POONE 052470  
PIP 020000  
POPDM 041544  
PR1 007156  
PR3 000140  
PR7 000340  
PRX 177776  
QDRV0 041150  
QDRV4 041250  
QINPT 041066  
QTERM 041350  
RANSEC 016456  
RANXIT 017110  
RODAT 000171  
RD.ADR 040350  
RD.RP2 040472  
READHO 015246  
RECALO 015174  
REIBUF 015756  
RESVEC 000010  
RPACR 033250  
RPCC 000036  
RPCB 000022

LIN91 051332  
LSTAD = 002000  
MAIN2 005572  
MAXCYL 000106  
MAXTRK 000112  
MHS 001000  
MINUTE 001270  
MOH 020000  
MRO 000020  
MSTCK 000010  
MXLACT 033256  
M.OP41 027144  
MBA 100000  
NEWASN 024502  
NOMTCH 012476  
NCTPRT 001406  
OFFC00 002200  
OFMSG0 002254  
OFMSG1 002307  
OFMSG2 002343  
OFMSG3 002377  
OFMSG4 002433  
OFMSG5 002467  
OFMSG6 002523  
OFMSG7 002557  
OFREV 000200  
OF400 000020  
OF50 000002  
OF50 = 000000  
OPI 020000  
OPT 034330  
OPTBL 001746  
PAR 000010  
PAR0 001554  
PAR1 053520  
PAR15 053641  
PAR20 053665  
PAR6 053562  
PASCNT 001362  
POONE 052470  
PIP 020000  
POPDM 041544  
PR1 007156  
PR3 000140  
PR7 000340  
PRX 177776  
QDRV0 041150  
QDRV4 041250  
QINPT 041066  
QTERM 041350  
RANSEC 016456  
RANXIT 017110  
RODAT 000171  
RD.ADR 040350  
RD.RP2 040472  
READHO 015246  
RECALO 015174  
REIBUF 015756  
RESVEC 000010  
RPACR 033250  
RPCC 000036  
RPCB 000022

LIN91 051410  
LSTAD 001256  
LSTAD = 002000  
MAIN3 006026  
MAXDL 001364  
MCLK 000002  
MINCYL 000110  
MINX 000004  
MOL 010000  
MRHVEC 055103  
MWR 000040  
MXWNOH 033264  
M.OP42 027154  
MED 010000  
NEWUNT 001466  
NONE 053205  
NOTRP 052175  
OFFSET 000115  
OFMSG0 002254  
OFMSG1 002307  
OFMSG2 002343  
OFMSG3 002377  
OFMSG4 002433  
OFMSG5 002467  
OFMSG6 002523  
OFMSG7 002557  
OF100 000004  
OF50 000002  
OPI 020000  
OPT 034330  
PACK 001216  
PARLST 053372  
PAR11 053625  
PAR19 053656  
PAR4 053544  
PAR8 053600  
PC =%000007  
PGE 002000  
PIRQVE 000240  
PROCES 006470  
PR1 000040  
PR5 000240  
PSEL 002000  
PWRVEC 000024  
QDRV2 041210  
QDRV6 041310  
QSTART 041126  
RANCYL 016632  
RANTRK 016532  
RAW 000020  
ROLIN 104411  
RD.RP1 040345  
RD.WRD 040352  
RECAL 000107  
REFMT 006324  
REPLZ 027230  
RMR 000004  
RPBA 000004  
RPCS2 000010  
RPDT 000026

LKPAR 004650  
MAIN 005324  
MASK 001250  
MAXER 001366  
MCPE 020000  
MINSEC 000120  
MNOLTA 033262  
MCNTR 005200  
MRPCS1 055072  
MXCLTA 033260  
M.OP10 027052  
M.OP44 027206  
MEDCLK 052651  
MHS 002000  
NOTAVL 052233  
NOTSAF 052252  
OFFST 015222  
OFMSG1 002307  
OFMSG2 002343  
OFMSG3 002467  
OFMSG4 002467  
OF200 000010  
OF800 000040  
OPTER 011516  
OPTBL 001746  
PAR 000010  
PAR0 001554  
PAR14 053633  
PAR2 053526  
PAR5 053553  
PAR9 053607  
PCLOCK 001206  
PGM 001000  
PLU 020000  
PRTBAD 014772  
PR2 000100  
PR6 000300  
PSU 000001  
QCNT 041056  
QDRV3 041230  
QDRV7 041330  
QSTOP 041130  
RANPAT 017100  
RANWRT 017120  
RDCHR 104410  
RDY 000200  
RD.RP2 040466  
READDR 022244  
RECALT 015170  
REFMTX 006466  
RESREG 104413  
RNOF 000101  
RPCA 000034  
RPCA 000006  
RPEC1 000044

RPER2 = 000046  
RPER3 = 000042  
RPFJ = 000032  
RPOC = 000002  
RPO6 = 052314  
R1 = 000001  
R5 = 000005  
SAVEFG = 033210  
SC = 036460  
SC11 = 037276  
SC2C = 002000  
SCE = 036732  
SDETAL = 022676  
SEEK = 000105  
SETFMT = 000143  
SIXTEE = 001274  
SLASH = 053514  
STACK = 001100  
STATHD = 052321  
STKLMT = 177774  
STO2 = 040116  
STO7 = 040256  
SWR = 001140  
SW00 = 000001  
SW04 = 000020  
SW08 = 000400  
SW11 = 004000  
SW15 = 100000  
SW5 = 000040  
SW9 = 001000  
TABLE0 = 053714  
TABLE4 = 054144  
TAP = 040000  
TIMER = 033214  
TRAPVE = 000034  
TRK1 = 004000  
TRK4 = 020000  
TYPDS = 104405  
TYPCN = 104404  
ULDFLG = 033170  
UNSAF = 012416  
UNTOFF = 052104  
US2 = 000002  
VU30 = 010000  
WC = 036352  
WCKD = 000151  
WCU = 000001  
WRTDAT = 000161  
WRTPK2 = 017706  
WRT.RP = 040500  
WRT.R4 = 040662  
WSU = 000004  
\$BDAT = 001126  
\$CHARC = 031166

RPERAS = 033102  
RPINIT = 033266  
RPSN = 000030  
RPO4 = 034036  
RTC = 000117  
R2 = 000002  
R6 = 000006  
SAVER1 = 001302  
SCMND = 024620  
SC12 = 037366  
SC3 = 036524  
SC6A = 037042  
SEARCH = 000131  
SEEKFG = 033212  
SETVEC = 004732  
SIZMEM = 004510  
SP = 000006  
START = 004066  
STATIN = 001214  
STNDAT = 002742  
STO3 = 040166  
STO8 = 040306  
SWREG = 000176  
SWC1 = 000002  
SWC5 = 000040  
SW09 = 001000  
SW12 = 010000  
SW2 = 000004  
SW6 = 000100  
SYSTAT = 052262  
TABLE1 = 053762  
TABLE5 = 054212  
TBITVE = 000014  
TITLE = 055254  
TRE = 040000  
TRK10 = 040000  
TRNSWT = 033162  
TYPE = 104401  
TYPCS = 104403  
UNIT = 001246  
UNTASN = 052147  
UNTON = 052115  
US4 = 000004  
VV = 000100  
WCE = 040000  
WCKER = 010312  
WLE = 004000  
WRTHD = 000163  
WRTPK3 = 017732  
WRT.R1 = 040564  
WRT.R5 = 040664  
ZROIND = 001276  
\$BDSEC = 000124  
\$CKSWR = 031644

RPER1 = 000014  
RPLA = 000020  
RPTMR = 037576  
RPO4B = 052302  
RTNCTR = 015144  
R3 = 000003  
R7 = 000007  
SAVER5 = 001304  
SC1 = 000100  
SC13 = 037436  
SC4 = 036530  
SC7 = 037170  
SECLMT = 001344  
SELDIV = 000145  
SET.IE = 041004  
SKI = 040000  
SPOTCK = 017772  
START1 = 004076  
STATIS = 015456  
STO = 037670  
STO5 = 040212  
STO9 = 040316  
SWTIM = 007030  
SW02 = 000004  
SW06 = 000100  
SW1 = 000002  
SW13 = 020000  
SW3 = 000010  
SW7 = 000200  
T = 050274  
TABLE2 = 054030  
TABLE6 = 054260  
TD = 036176  
TKVEC = 000060  
TRFER = 012162  
TRK2 = 010000  
TRTVEC = 000014  
TYPEST = 022626  
TYPRI4 = 027360  
UNLOAD = 000103  
UNMSG = 052076  
UPE = 020000  
UWR = 000010  
WAIT = 001532  
WCF = 000040  
WCKHD = 000153  
WLEER = 011774  
WRTPK = 017476  
WRTPK4 = 017764  
WRT.R2 = 040650  
WRT.WD = 040566  
\$AUTOB = 001134  
\$BELL = 001160  
\$CMTAG = 001100

RPER2 = 000040  
RPMR = 000024  
RPVEC = 033252  
RPO5 = 052307  
R0 = 000000  
R4 = 000004  
S = 050320  
SAVREG = 104412  
SC10 = 001000  
SC2 = 000200  
SC5 = 036542  
SC8 = 037246  
SECOND = 001272  
SELPAR = 016376  
SHDTYP = 022654  
SKIER = 012262  
SRCHWT = 033164  
START2 = 004102  
STATPR = 022544  
STO1 = 037720  
STO6 = 040220  
SVRH11 = 040666  
SW0 = 000001  
SW03 = 000010  
SW07 = 000200  
SW10 = 002000  
SW14 = 040000  
SW4 = 000020  
SW8 = 000400  
TABLE = 053674  
TABLE3 = 054076  
TABLE7 = 054326  
TDF = 000040  
TPVEC = 000064  
TRKLMT = 001346  
TRK20 = 100000  
TUF = 000100  
TYPOC = 104402  
LCPAR = 006746  
UNS = 040000  
UNTNOT = 052125  
US1 = 000001  
VJF = 000002  
WAQ = 000002  
WCFER = 012320  
WCESEL = 001400  
WRL = 004000  
WRTPK1 = 017526  
WRT.AD = 040570  
WRT.R3 = 040656  
WRJ = 000400  
\$BDADR = 001122  
\$BJF = 000006  
\$CM3 = 000000

\$CNTLC 030452	\$CNTLG 032253	\$CNTLU 032246	\$CODE = 000024
\$COMND= 000002	\$CRLF 001165	\$CYL = 000012	\$DBLK 031634
\$DB20 032500	\$DB20 032674	\$DECVL 032660	\$DOAGN 005320
\$DRVID= 000224	\$DSPLY 027406	\$DTBL 031624	\$ENDAD 005310
\$ERFLG 001103	\$ERMAX 001115	\$ERRCR 030460	\$ERRPC 001116
\$ERRTB 004006	\$ERRTY 030616	\$ERTTL 001112	\$FAIR = 000072
\$FILLC 001156	\$FILLS 001155	\$FIRST= 000122	\$FMT = 000001
\$GCADR 001120	\$GDDAT 001124	\$GET42 005256	\$GTSWR 031714
\$HARD = 000062	\$HD = 000000	\$HINUM 032400	\$ICNT 001104
\$INTAG 001135	\$ITEMB 001114	\$LF 001166	\$LKCSB 001176
\$LKCSR 001174	\$LKS 001202	\$LLVEC 001204	\$LONLM 032402
\$LPACR 001106	\$LPERR 001110	\$LPVEC 001200	\$LSTAD 054660
\$MISPO= 000066	\$MNEW 032271	\$MSWR 032260	\$NCODE= 000074
\$NCYL = 000100	\$NEXT = 000104	\$NPATC= 000075	\$NSEC = 000076
\$NTRK = 000077	\$NULL 001154	\$NRDL= 000102	\$OCNT 031414
\$OCTVL 032776	\$OMODE 031416	\$OPERC= 000036	\$PACK = 000026
\$PASS 001100	\$PASSC= 000070	\$PATTC= 000030	\$POSIT= 000042
\$PREVA= 000032	\$PREVO= 000027	\$PEL = 000033	\$QUES 001164
\$RAND 032302	\$RDCR 032126	\$POLIN 030162	\$RDSZ = 000001
\$READ = 000052	\$REG = 000014	\$RESRE 032442	\$RETRY 015330
\$RPADR 001170	\$RPAS = 000252	\$RPBA = 000240	\$RPCA = 000270
\$RPCC = 000272	\$RPCS1= 000234	\$RPCS2= 000244	\$RPDA = 000242
\$RPDB = 000256	\$RPDS1= 000246	\$RPDT = 000262	\$RPEC1= 000300
\$RPEC2= 000302	\$RPER1= 000250	\$RPER2= 000274	\$RPER3= 000276
\$RPLA = 000254	\$RPMR = 000260	\$RPOF = 000266	\$RPSN = 000264
\$RPVEC 001172	\$RPWC = 000236	\$SAVRE 032404	\$S820 027720
\$SB20 027750	\$SEC = 000010	\$SETUP= 000146	\$SIZE 054564
\$SKI = 000064	\$SOFT = 000060	\$SSEC = 000022	\$STUP = 177777
\$SJPRS 027320	\$SVPC = 000210	\$SWR = 122000	\$STATUS= 000016
\$TERM = 000032	\$TIME 023400	\$TKB 001146	\$TKINT 030300
\$TKS 001144	\$TKSRV 030030	\$TN = 000001	\$TNPWR 032610
\$TOTAL= 000056	\$TPB 001152	\$TPFLG 001157	\$TPS 001150
\$TRANS= 000046	\$TRAP 033014	\$TRAP2 033036	\$TRK = 000011
\$TRP = 000015	\$TRPAD 033050	\$TSTNM 001102	\$TTYIN 030440
\$TYPOS 031420	\$TYPE 030752	\$TYPEC 031122	\$TYPEX 031170
\$TYPOC 031216	\$TYPON 031232	\$TYPOS 031172	\$WRDL = 000020
\$WRDM = 000004	\$OFILL 031415	. = 055650	

ERRORS DETECTED: 0

\*DZRJDA, DZRJC/SOL/LI:ME/NL:MC:MD:CND=RPO456.010, DZRJD.019  
RUN-TIME: 105 89 1 SECONDS  
CORE USED: 39K



