

# RL11,RLV11,RL01

RL01 DRIVE TEST PART 1  
MD-11-DZRLC-A

EP-DZRLC-A-DL

COPYRIGHT © 1977

FICHE 1 OF 1

DEC 1977

**digital**

MADE IN USA

The main body of the document is a large grid of small, illegible data tables or charts, likely test results for the RL01 drive. The grid is organized into approximately 10 columns and 15 rows. Each cell in the grid contains a small table or chart with multiple columns and rows of data. The text is too small to be read, but the layout suggests a systematic recording of test parameters and results. The right side of the page is mostly blank, with a small, illegible table or chart in the bottom right corner.



IDENTIFICATION

PRODUCT CODE: MAINDEC-11-DZRLC-A-D  
PRODUCT NAME: RLO1 DRIVE TEST (PART 1)  
DATE CREATED: 28 OCTOBER 1977  
MAINTAINER: DIAGNOSTIC ENGINEERING  
AUTHOR: M. TEGROTENHUIS/D. DEKNIS

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS MANUAL.

THE SOFTWARE DESCRIBED IN THIS DOCUMENT IS FURNISHED TO THE PURCHASER UNDER A LICENSE FOR USE ON A SINGLE COMPUTER SYSTEM AND CAN BE COPIED (WITH INCLUSION OF DIGITAL'S COPYRIGHT NOTICE) ONLY FOR USE IN SUCH SYSTEM, EXCEPT AS MAY OTHERWISE BE PROVIDED IN WRITING BY DIGITAL.

DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL.

COPYRIGHT (C) 1977, DIGITAL EQUIPMENT CORPORATION



## 1.0 GENERAL INFORMATION

### 1.1 PROGRAM ABSTRACT

#### 1.1.1 STRUCTURE OF PROGRAM

THIS DIAGNOSTIC OCCUPIES 14.5K WORDS OF MEMORY AND IS COMPATIBLE WITH BOTH XXDP AND ACT. IT CAN BE RUN STANDALONE UNDER XXDP, AND CAN BE CHAINED UNDER XXDP, ACT AND APT IN ACT MODE (SEE "CREATE CORE IMAGE" COMMAND BELOW FOR DETAILS OF CHAINING PROCEDURE). IT IS A SINGLE PROGRAM FROM THE STANDPOINT OF THE DIAGNOSTIC USER, BUT WE HAVE INCORPORATED INTO IT A CONTROL MODULE WHICH WILL LATER BE RELEASED INDEPENDENTLY AS A DIAGNOSTIC SUPERVISOR.

WHEN THIS DIAGNOSTIC IS STARTED AT ADDRESS 200, CONTROL GOES FIRST TO THE SUPERVISOR PORTION, WHICH WILL ASK CERTAIN "HARD CORE" QUESTIONS ABOUT THE ENVIRONMENT. THEN IT WILL ENTER COMMAND MODE, INDICATED BY A PROMPT CHARACTER (DS A>). AT COMMAND MODE THE OPERATOR MAY ENTER ANY OF SEVERAL COMMANDS AS DESCRIBED BELOW.

THE SUPERVISOR CODING FOLLOWS IMMEDIATELY THE DIAGNOSTIC TEST CODING, BUT THE SUPERVISOR LISTING HAS BEEN SUPPRESSED FOR GENERAL DISTRIBUTION. A LIMITED DISTRIBUTION HAS BEEN MADE TO FIELD SERVICE OF THE SUPERVISOR ASSEMBLY LISTING, AND IT MAY BE CONSULTED IN EVENT OF A SOFTWARE PROBLEM.

#### 1.1.2 DIAGNOSTIC INFORMATION

THIS PROGRAM TESTS AND EXERCISES RLO1 DISK DRIVES RL11/RLV11 CONTROLLERS (4 DRIVES PER CONTROLLER). THE ENTIRE PROGRAM IS RUN ON THE FIRST DRIVE BEFORE STARTING ON THE SECOND. THE PROGRAM STARTS BY TESTING THE SIMPLEST FUNCTIONS FIRST USING THE LOGIC TESTED IN EARLIER TESTS TO TEST MORE COMPLEX FUNCTIONS.

THIS PROGRAM TESTS THE RLO1 INTERFACE AND BASIC DRIVE LOGIC. GET STATUS WITH RESET, GET STATUS, SEEK, AND READ HEADER ARE THE ONLY COMMANDS EXECUTED IN THE PROGRAM. ONLY SEEKS WITH 0 DIFFERENCE ARE USED SO NO HEAD MOVEMENT IS REQUIRED.

A SIGNIFICANT PORTION OF THE PROGRAM REQUIRES MANUAL INTERVENTION. THESE TESTS TEST THE COVER OPEN AND WRITE LOCK STATUS. THE DRIVE MUST BE LOADED AND UNLOADED TO TEST ALL THE CONDITIONS OF HEADS OUT, BRUSH HOME, AND DRIVE STATES. THE PROGRAM CAN BE RUN IN AUTOMATIC MODE IN WHICH CASE ALL TESTS REQUIRING MANUAL INTERVENTION ARE BYPASSED.

## 1.2 SYSTEM REQUIREMENTS

### 1.2.1 HARDWARE REQUIREMENTS

PDP-11/LSI-11 PROCESSOR WITH 16K OR MORE OF CORE  
CONSOLE DEVICE (LA30, LA36, VT50, ETC.)  
RL11/RLV11 CONTROLLER(S)  
1 - 8 RLO1 DRIVES



1 - 8 RLD1K CARTRIDGES WITH BAD SECTOR FILE  
KWIIP, KWIIL (OPTIONAL)  
LINEPRINTER(OPTIONAL)

## 1.2.2 SOFTWARE REQUIREMENTS

MAINDEC-11-DZRLC-A

## 1.3 RELATED DOCUMENTS AND STANDARDS

RLD1 USERS MANUAL (EK-RLD1-UG-PRE)  
XXDP USERS MANUAL  
DIAGNOSTIC SUPERVISOR PROGRAM LISTING

## 1.4 DIAGNOSTIC HIERARCHY PREREQUISITES

THE RLD1 SUBSYSTEM SHOULD HAVE SUCCESSFULLY RUN THE FOLLOWING PROGRAMS:

MD-11-DZRLA	RL11/RLV11 RLD1 CONTROLLER TEST (PART 1)
MD-11-DZRLB	RL11/RLV11 RLD1 CONTROLLER TEST (PART 2)
MD-11-DVRLA	RLV11 RLD1 DISKLESS TEST (RLV11 ONLY)

## 1.5 ASSUMPTIONS

THE HARDWARE OTHER THAN THE RLD1 SUBSYSTEM IS ASSUMED TO WORK PROPERLY. FALSE ERRORS MAY BE REPORTED IF THE PROCESSOR, ETC., DO NOT FUNCTION PROPERLY.

## 2.0 OPERATING INSTRUCTIONS

### 2.1 LOADING AND STARTING PROCEDURES

#### 2.1.1 LOADING PROCEDURES

FOLLOW STANDARD DEC PROCEDURES TO LOAD THE PROGRAM. (XXDP, ABSOLUTE LOADER, UPD1, UPD2)

#### 2.1.2 STARTING PROCEDURES

THE PROGRAM STARTS AT LOCATION 200. USE STANDARD DEC PROCEDURES TO START THE PROGRAM.

#### 2.1.3 STEPS FOR QUICK AND SIMPLE EXECUTION



THE DIAGNOSTIC CAN BE EXECUTED STANDALONE WITHOUT READING THE REMAINDER OF THIS DOCUMENT AS FOLLOWS:

SEG 0004

- A) LOAD THE DIAGNOSTIC
- B) START AT ADDRESS 200
- C) ANSWER THE HARDWARE QUESTIONS
- D) RECEIVE PROMPT (DS A)
- E) ENTER STA<CR>
- F) ANSWER HARDWARE AND SOFTWARE QUESTIONS
- G) GET END OF PASS MESSAGES OR ERROR MESSAGES
- H) TO END EXECUTION, ENTER CONTROL/C

## 2.2 SPECIAL ENVIRONMENTS

THE ENVIRONMENTS THIS PROGRAM WILL RUN IN ARE XXDP, XXDP CHAIN, ACT, SLIDE AND APT.

## 2.3 PROGRAM OPTIONS

### 2.3.1 START COMMAND

```
*****
STA(RT)/TESTS:<TEST-LIST>/PASS:<PASS-CNT>/FLAGS:<FLAG-LIST>/EOP:<INCR>
*****
```

#### 2.3.1.1 TESTS SWITCH (/TESTS:<TEST-LIST>)

<TEST-LIST> IS A SEQUENCE OF DECIMAL NUMBERS (1:2 ETC.) OR RANGES OF DECIMAL NUMBERS (1-5:8-10 ETC.) SEPARATED BY COLONS, SPECIFYING WHICH TESTS IT IS DESIRED BE EXECUTED. THE TEST NUMBERS RANGE FROM 1 TO THE LARGEST TEST NUMBER IN THE DIAGNOSTIC. THEY MAY BE SPECIFIED IN ANY ORDER. TESTS WILL BE EXECUTED IN NUMERICAL ORDER REGARDLESS OF ORDER OF SPECIFICATION. THE DEFAULT IS TO EXECUTE ALL TESTS. ON THIS AND ALL SWITCHES, THE ANGLE BRACKETS <> ARE PUNCTUATION USED IN THE DEFINITION ONLY, AND ARE NOT TO BE TYPED BY THE OPERATOR. SEE EXAMPLE AT END OF 2.3.1.

#### 2.3.1.2 PASS SWITCH (/PASS:<PASS-CNT>)

<PASS-CNT> IS A DECIMAL NUMBER INDICATING THE DESIRED NUMBER OF PASSES. A PASS IS DEFINED AS THE EXECUTION OF THE FULL DIAGNOSTIC (ALL SELECTED TESTS) AGAINST ALL UNITS SUBMITTED. THE DEFAULT IS NON-ENDING EXECUTION: IE, EXIT IS ACCOMPLISHED EITHER BY TYPING A CONTROL/C OR BY A HALT ON ERROR BEING ENCOUNTERED, IN WHICH CASE WE RETURN TO COMMAND MODE. SEE EXAMPLE AT END OF 2.3.1.

#### 2.3.1.3 FLAGS SWITCH (/FLAGS:<FLAG-LIST>)

<FLAG-LIST> IS A SEQUENCE OF ELEMENTS OF THE FORM <FLAG>, <FLAG=1>, OR <FLAG=0>, SEPARATED BY COLONS, WHERE <FLAG> HAS ONE OF THE FOLLOWING VALUES:

- HOE HALT ON ERROR, CAUSING COMMAND MODE TO BE ENTERED WHEN AN ERROR IS ENCOUNTERED
- LOE LOOP ON ERROR, CAUSING THE DIAGNOSTIC TO LOOP CONTINUOUSLY



IER	WITHIN THE SMALLEST DEFINED BLOCK OF CODING (SEGMENT, SUBTEST, OR TEST) CONTAINING THE ERROR
IBE	INHIBIT ERROR REPORTING
IXE	INHIBIT BASIC ERROR REPORTS
PRI	INHIBIT EXTENDED ERROR REPORTS
PNT	DIRECT ALL MESSAGES TO A LINE PRINTER
BOE	PRINT NUMBER OF TEST BEING EXECUTED
UAM	BELL ON ERROR
ISR	RUN IN UNATTENDED MODE, BYPASSING MANUAL INTERVENTION TESTS
IDR	INHIBIT STATISTICAL REPORTS
	INHIBIT DROPPING OF UNITS BY DIAGNOSTIC

THE FLAGS NAMED OR EQUATED TO 1 ARE SET, THOSE EQUATED TO 0 ARE CLEARED. A FLAG NOT SPECIFIED IS CLEARED. IF THE FLAGS SWITCH IS NOT GIVEN ALL FLAGS ARE CLEARED. SEE EXAMPLE AT END OF 2.3.1.

#### 2.3.1.4 END OF PASS SWITCH (/EOP:<INCR>)

<INCR> IS A DECIMAL NUMBER INDICATING HOW OFTEN (IN TERMS OF PASSES) IT IS DESIRED THAT THE END OF PASS MESSAGE BE PRINTED. THE DEFAULT IS AT THE END OF EVERY PASS. SEE EXAMPLE AT END OF 2.3.1.

#### 2.3.1.5 EFFECT OF COMMAND

THE EFFECT OF THE START COMMAND IS TO INITIATE THE HARDWARE PARAMETER DIALOGUE, THE SOFTWARE PARAMETER DIALOGUE, AND THEN THE DIAGNOSTIC TESTS THEMSELVES.

THE HARDWARE PARAMETER DIALOGUE COMMENCES WITH THE QUESTION "# UNITS?" TO WHICH THE OPERATOR REPLIES WITH A DECIMAL NUMBER N FROM 1 TO 64. THE TERM "UNIT" REFERS TO THE DEVICE TO WHICH THIS SERIES OF DIAGNOSTICS IS DEDICATED. FOLLOWING THIS ARE THE QUESTIONS WHEREBY THE P-TABLES THEMSELVES WILL BE BUILT. EACH P-TABLE IS A CORE-RESIDENT TABLE CONTAINING ALL THE HARDWARE INFORMATION FOR ONE UNIT. THE OPERATOR MUST SUPPLY N (NUMBER OF UNITS) VALUES FOR EACH QUESTION. HE MAY DO THIS BY GIVING ONE ANSWER TO EACH QUESTION (IN WHICH CASE THE SERIES OF QUESTIONS WILL BE POSED N TIMES) OR BY GIVING N VALUES, SEPARATED BY COMMAS, TO EACH QUESTION (SERIES WILL BE POSED ONCE). EACH QUESTION IS FOLLOWED BY THE RESPONSE RADIX (D FOR DECIMAL, B FOR BINARY, O FOR OCTAL, L FOR YES/NO) IN PARENTHESES AND THE DEFAULT VALUE AFTER THE PARENTHESES.

FOLLOWING THE HARDWARE QUESTIONS ARE THE SOFTWARE QUESTIONS TO BUILD THE SOFTWARE TABLES, WHICH DEFINE THE MODE (QUICK VERIFY ETC.) THAT THE DIAGNOSTIC WILL EXECUTE IN.

AT THE POINT WHERE THE QUESTION "# UNITS?" IS ANSWERED, CORE STORAGE IS ALLOCATED FOR THE P-TABLES, AND IF THERE IS NOT ENOUGH TO ACCOMMODATE THEM THE MESSAGE "TOO MANY UNITS" IS ISSUED. IN THIS CASE THE DIAGNOSTIC MUST BE EXECUTED MORE THAN ONCE TO TEST ALL UNITS.

#### EXAMPLE:

STA/TESTS:1:2-4:6:8-10/PASS:3/FLAGS:IER:HOE=1:UAM:LOE

THIS COMMAND WILL CAUSE THREE PASSES TO BE MADE, EACH PASS CONSISTING OF TESTS 1,2,3,4,6,8,9, AND 10 EXECUTED AGAINST ALL UNITS. THERE IS NO DIFFERENCE BETWEEN SAYING <FLAG> AND SAYING <FLAG=1>. THE NOTATION <FLAG=0> IS MEANINGFUL ONLY ON A COMMAND OTHER THAN



START TO CLEAR A FLAG THAT WAS PREVIOUSLY SET. NOTE THAT ON ALL COMMANDS ONLY THE FIRST THREE LETTERS ARE SCANNED.

### 2.3.2 RESTART COMMAND

```
*****
RES(TART)/TESTS:<TEST-LIST>/PASS:<PASS-CNT>/FLAGS:<FLAG-LIST>/UNITS:<UNIT-LIST>
*****
```

#### 2.3.2.1 TESTS, PASS, AND FLAGS SWITCHES

<TEST-LIST>, <PASS-CNT>, AND <FLAG-LIST> ARE AS IN THE START COMMAND.

#### 2.3.2.2 UNITS SWITCH (/UNITS:<UNIT-LIST>)

<UNIT-LIST> IS A SEQUENCE OF DECIMAL NUMBERS (1,2 ETC.) OR RANGES OF DECIMAL NUMBERS (1-5, 8-10 ETC.) SEPARATED BY COLONS, INDICATING WHICH UNITS IT IS DESIRED BE TESTED. THE NUMBERS MAY RANGE FROM 1 THRU N (N IS THE NUMBER OF UNITS SPECIFIED IN THE PREVIOUS START COMMAND). THE NUMBER INDICATES THE POSITION OF THE P-TABLE AS THE DATA WAS ENTERED DURING THE HARDWARE DIALOGUE. THE UNITS WHICH ARE SELECTED MUST NOT HAVE BEEN DROPPED BY THE DROP COMMAND. SEE THE DISCUSSION OF ADD AND DROP COMMANDS BELOW. DEFAULT IS TO TEST ALL UNITS WHICH HAVE NOT BEEN DROPPED BY A DROP COMMAND.

#### 2.3.2.3 EFFECT OF COMMAND

THE RESTART COMMAND DIFFERS FROM THE START COMMAND IN THAT THE P-TABLES FROM THE PREVIOUS START COMMAND (THERE MUST HAVE BEEN ONE) ARE USED, INSTEAD OF NEW ONES BEING BUILT. THE UNITS SWITCH GIVES THE ABILITY TO SELECT A SUBSET OF THESE. THE SOFTWARE DIALOGUE MAY OPTIONALLY BE RE-EXECUTED (OPERATOR WILL BE ASKED). THE COMMAND CAN BE USED AFTER COMMAND MODE HAS BEEN REENTERED IN ANY OF THE THREE NORMAL WAYS: A) THE REQUESTED NUMBER OF PASSES HAVE BEEN MADE B) AN ERROR WAS ENCOUNTERED WITH THE HALT ON ERROR FLAG SET C) A CONTROL/C WAS ENTERED BY THE OPERATOR.

### 2.3.3 CONTINUE COMMAND

```
*****
CON(TINUE)/PASS:<PASS-CNT>/FLAGS:<FLAG-LIST>
*****
```

#### 2.3.3.1 PASS SWITCH (/PASS:<PASS-CNT>)

<PASS-CNT> IS SAME AS IN START COMMAND, BUT THE DEFAULT IS THE UNSATISFIED PASS-CNT FROM THE PREVIOUS START OR RESTART. IF NONE REMAINS, THE DEFAULT IS NON-ENDING EXECUTION.

#### 2.3.3.2 FLAG SWITCH (/FLAGS:<FLAG-LIST>)

<FLAG-LIST> IS SAME AS IN START COMMAND, BUT UNSPECIFIED FLAGS RETAIN THEIR CURRENT VALUE.

#### 2.3.3.3 EFFECT OF COMMAND



# H01

SEQ 0007

CONTINUE MUST FOLLOW A START OR RESTART, AND COMMAND MODE MUST HAVE BEEN ENTERED DUE TO A HALT ON ERROR OR A CONTROL/C. THE EFFECT OF THE COMMAND IS TO GO TO THE BEGINNING OF THE TEST THAT WAS BEING EXECUTED WHEN THE HALT OR CONTROL/C TOOK PLACE. SOFTWARE DIALOGUE MAY OPTIONALLY BE REEXECUTED. HARDWARE PARAMETERS MAY NOT BE CHANGED.

## 2.3.4 PROCEED COMMAND

\*\*\*\*\*  
PRO(CEED)/FLAGS:<FLAG-LIST>  
\*\*\*\*\*

### 2.3.4.1 FLAGS SWITCH (/FLAGS:<FLAG-LIST>)

<FLAG-LIST> IS AS IN THE START COMMAND, BUT UNSPECIFIED FLAGS RETAIN THEIR CURRENT VALUE.

### 2.3.4.2 EFFECT OF COMMAND

PROCEED MUST FOLLOW A START, RESTART, OR CONTINUE. COMMAND MODE MUST HAVE BEEN ENTERED VIA A HALT ON ERROR. THE EFFECT OF THE COMMAND IS TO BEGIN EXECUTION AT THE LOCATION FOLLOWING THE ERROR CALL. NEITHER HARDWARE NOR SOFTWARE PARAMETERS MAY BE ALTERED.

## 2.3.5 CREATE CORE IMAGE COMMAND

\*\*\*\*\*  
CCI/TESTS:<TEST-LIST>/PASS:<PASS-CNT>/FLAGS:<FLAG-LIST>  
\*\*\*\*\*

### 2.3.5.1 TESTS, PASS, AND FLAGS SWITCHES

<TEST-LIST>, <PASS-CNT>, <FLAG-LIST>, AND ARE AS IN THE START COMMAND, EXCEPT THAT THE UAM (UNATTENDED MODE) FLAG DEFAULTS TO THE SET POSITION.

### 2.3.5.2 EFFECT OF COMMAND

THE PURPOSE OF THIS COMMAND IS TO CREATE A BIC FILE SUITABLE FOR CHAIN MODE EXECUTION. THE XXDP PROCEDURE IS AS FOLLOWS:

```
INVOKE THE XXDP UTILITY UPD1
LOAD XXN:FILE.BIN
START 200
<QUESTIONS AND ANSWERS>
RESTART UPD1 USING RESTART ADDRESS
HICORE ADDRESS (IF "PASSED 14.5K" MESSAGE CAME)
DUMP XXN:FILE.BIC
```

THE OPERATOR DIALOGUE (HARDWARE AND SOFTWARE) WILL BE EXECUTED AS IN THE START COMMAND, BUT AT THE END OF THE QUESTIONS THE HALT STATE WILL BE ENTERED, AT WHICH TIME THE OPERATOR SHOULD DUMP THE PROGRAM TO THE XXDP LIBRARY USING A BIC EXTENSION TO INDICATE THAT THIS FILE IS CHAINABLE. HE SHOULD USE THE XXDP UTILITY "UPD1" TO DO THIS. IF THE P-TABLES EXTEND BEYOND 14.5K, A MESSAGE WILL BE ISSUED GIVING THE NEW UPPER CORE LIMIT, TO WHICH THE OPERATOR



MUST ADJUST BEFORE DUMPING. HE MAY NOW DELETE THE NON-CHAINABLE BIN FILE IF DESIRED, SINCE THE BIC FILE HAS ALL THE CAPABILITIES OF IT.

WHEN THIS BIC FILE IS SUBSEQUENTLY EXECUTED IN CHAIN MODE, THE OPERATOR DIALOGUES WILL BE BYPASSED. HOWEVER, IF IT IS EXECUTED STANDALONE, THE DIALOGUE WILL BE REISSUED.

NOTE THAT IF THE MESSAGE "TOO MANY UNITS" IS ISSUED, TWO OR MORE CORE IMAGES MUST BE CREATED (WITH DIFFERENT NAMES) TO TEST ALL UNITS.

### 2.3.6 ADD COMMAND

```
*****
ADD/UNITS:<UNIT-LIST>
*****
```

#### 2.3.6.1 UNITS SWITCH (/UNITS:<UNIT-LIST>)

<UNIT-LIST> IS AS IN THE RESTART COMMAND.

#### 2.3.6.2 EFFECT OF COMMAND

THE UNITS SPECIFIED ARE ADDED TO THE TEST SEQUENCE. EACH UNIT MUST HAVE A P-TABLE IN MEMORY DUE TO AN EARLIER HARDWARE DIALOGUE. THIS COMMAND MUST BE FOLLOWED BY A RESTART OR CONTINUE. THE UNITS SWITCH MUST BE SPECIFIED. THE ADD COMMAND IS MEANINGFUL ONLY FOR UNITS THAT WERE PREVIOUSLY DROPPED.

### 2.3.7 DROP COMMAND

```
*****
DRO(P)/UNITS:<UNIT-LIST>
*****
```

#### 2.3.7.1 UNITS SWITCH (/UNITS:<UNIT-LIST>)

<UNIT-LIST> IS AS IN THE RESTART COMMAND.

#### 2.3.7.2 EFFECT OF COMMAND

THE UNITS SPECIFIED WILL BE DROPPED FROM TESTING. THE UNITS WILL BE RESELECTED ONLY BY THE EXECUTION OF AN ADD OR START COMMAND. THE UNITS SWITCH MUST BE ENTERED. THIS COMMAND MUST BE FOLLOWED BY A RESTART OR A CONTINUE COMMAND.

### 2.3.8 PRINT COMMAND

```
*****
PRINT)
*****
```

#### 2.3.8.1 EFFECT OF COMMAND

ALL STATISTICS TABLES ACCUMULATED BY THE DIAGNOSTIC ARE PRINTED. THE ISR (INHIBIT STATISTICAL REPORTING) FLAG IS CLEARED.



### 2.3.9 DISPLAY COMMAND

\*\*\*\*\*  
 DIS(PLAY)/UNITS:<UNIT-LIST>  
 \*\*\*\*\*

#### 2.3.9.1 UNITS SWITCH (/UNITS:<UNIT-LIST>)

<UNIT-LIST> IS AS IN THE RESTART COMMAND.

#### 2.3.9.2 EFFECT OF COMMAND

THE HARDWARE P-TABLES FOR ALL UNITS UNDER TEST ARE PRINTED OUT IN THE FORMAT IN WHICH THEY WERE ENTERED. ANY UNITS THAT WERE DROPPED BY THE OPERATOR "DROP" COMMAND ARE SO DESIGNATED.

### 2.3.10 FLAGS COMMAND

\*\*\*\*\*  
 FLA(GS)  
 \*\*\*\*\*

#### 2.3.10.1 EFFECT OF COMMAND

THE CURRENT SETTINGS OF ALL FLAGS ARE PRINTED.

### 2.3.11 ZFLAGS COMMAND

\*\*\*\*\*  
 ZFL(AGS)  
 \*\*\*\*\*

#### 2.3.11.1 EFFECT OF COMMAND

ALL FLAGS ARE CLEARED.

### 2.3.12 CONTROL CHARACTERS

A CONTROL C (↑C) ENTERED VIA THE CONSOLE DEVICE DURING THE EXECUTION OF A DIAGNOSTIC CAUSES A RETURN TO THE DIAGNOSTIC SUPERVISOR COMMAND MODE.

A CONTROL Z (↑Z) ENTERED WITHIN ONE OF THE THREE OPERATOR DIALOGUES (HARDWARE, HARDWARE, OR SOFTWARE QUESTIONS) CAUSES THE DEFAULT VALUES TO BE TAKEN FOR THE REMAINDER OF THAT DIALOGUE.

A CONTROL O (↑O) ENTERED DURING THE EXECUTION OF A DIAGNOSTIC CAUSES ALL CONSOLE DEVICE OUTPUT TO BE SUPPRESSED FOR THE REMAINDER OF THE DIAGNOSTIC OR UNTIL ANOTHER CONTROL O IS TYPED.

### 2.3.13 HARDWARE PARAMETERS



THE FOLLOWING QUESTIONS WILL BE ASKED ON A START COMMAND. THE VALUE LOCATED TO THE LEFT OF THE QUESTION MARK IS THE DEFAULT VALUE THAT WILL BE TAKEN ON A CARRIAGE RETURN RESPONSE.

RL11 (L) Y?

ANSWER YES(Y) IF YOU HAVE AN RL11 CONTROLLER, NO(N) IF YOU HAVE AN RLV11 CONTROLLER.

BUS ADDRESS (0) 174400?

ANSWER WITH THE BUS ADDRESS OF THE CONTROLLER.

VECTOR (0) 330?

ANSWER WITH THE INTERRUPT VECTOR OF THE CONTROLLER.

BR LEVEL (0) 5?

ANSWER WITH THE INTERRUPT PRIORITY OF THE CONTROLLER.

DRIVE (0) 0?

ANSWER WITH THE DRIVE(S) CONNECTED TO THE CONTROLLER.

#### 2.3.14 SOFTWARE PARAMETERS

AFTER HARDWARE PARAMETERS ARE SPECIFIED, THE USER IS ASKED IF SOFTWARE PARAMETERS ARE TO BE CHANGED.

CHANGE S.W. (Y OR N)? (NO DEFAULT)

IF "NO", SOFTWARE PARAMETER ENTRY IS SKIPPED, ALL DEFAULT VALUES ARE USED. IF "YES", THE PARAMETERS LISTED BELOW ARE REQUESTED. TYPING CONTROL Z IN RESPONSE TO ANY PARAMETER QUESTION ALLOWS THIS AND ALL REMAINING PARAMETERS TO DEFAULT.

EXECUTE DRIVE SELECT TESTS (N)?

IF "YES" TESTS 5 AND 6 ARE EXECUTED IN THE FIRST PASS OF THE PROGRAM. THESE TESTS REQUIRE MANUAL INTERVENTION TO CHANGE ADDRESS PLUGS AND REQUIRE A FULL COMPLEMENT OF ADDRESS PLUGS (0 - 3).

EXECUTE HEAD ALIGNMENT SUPPORT (N)?

IF "YES", TEST 11 IS EXECUTED IN THE FIRST PASS.

EXECUTE MANUAL INTERVENTION TESTS (N)?

IF "YES" TESTS 1, 2, 3, AND 4 ARE EXECUTED TO TEST BASIC INTERFACE OPERATIONS, HEAD LOADING, HEAD UNLOADING, AND ALL STATE CHANGES.

SPECIFY ERROR LIMIT (DECIMAL) (20)?

THIS PARAMETER SPECIFIES THE MAXIMUM NUMBER OF ERRORS ALLOWED. THIS LIMIT IS ON A PER DRIVE BASIS IN A SINGLE PASS. IF THE



ERROR LIMIT IS EXCEEDED, THE DRIVE IS DROPPED FROM FURTHER TESTING.

#### DROP DRIVE IF NO RESPONSE (N)?

IF THIS PARAMETER IS SPECIFIED AS YES, THE PROGRAM WILL CHECK EACH DRIVE BEFORE TESTING STARTS TO DETERMINE IF IT IS READY OR IF IT WILL RESPOND TO A GET STATUS. IF IT IS NOT READY AND WILL NOT RESPOND TO A GET STATUS, THE DRIVE IS DROPPED AND A MESSAGE IS PRINTED.

#### 2.3.15 EXTENDED DISCUSSION OF P-TABLE DIALOGUE

THE FULL CAPABILITY OF THE HARDWARE DIALOGUE IS REVEALED BY THE FOLLOWING DISCUSSION OF WHAT HAPPENS INTERNALLY.

AS SOON AS THE QUESTION "# UNITS?" IS ANSWERED (WITH THE NUMBER N, SAY) SPACE IN CORE IS ALLOCATED FOR N P-TABLES. ALL OF THE P-TABLES ARE OF THE SAME FORMAT, AND THERE IS A ONE-TO ONE CORRESPONDENCE BETWEEN THE HARDWARE PARAMETER QUESTIONS AND THE SLOTS IN THE P-TABLE FORMAT.

ON THE FIRST TRIP THRU THE QUESTIONS, ALL OF THE SLOTS IN ALL OF THE P-TABLES ARE FILLED. IF THE OPERATOR TYPES IN LESS THAN N EXPLICIT VALUES IN RESPONSE TO A PARTICULAR QUESTION, THESE VALUES ARE PLACED IN THE P-TABLES (ONE VALUE GOING INTO THE PROPER SLOT OF EACH P-TABLE BEGINNING WITH THE FIRST P-TABLE) UNTIL THE STRING OF VALUES IS EXHAUSTED. THE LAST VALUE IN THE STRING BECOMES THE NEW DEFAULT AND IS USED THEN AND THERE TO FILL THAT SLOT IN THE REMAINING P-TABLES.

ON SUBSEQUENT TRIPS THRU THE QUESTIONS, THE SAME PROCESS IS CARRIED OUT, EXCEPT THAT THE EARLIEST P-TABLE NOT TO HAVE RECEIVED AN EXPLICIT VALUE IN ANY OF ITS SLOTS NOW ASSUMES THE ROLE THAT TABLE NUMBER ONE PLAYED IN THE FIRST TRIP.

THE SERIES OF QUESTIONS IS REISSUED UNTIL AT LEAST ONE QUESTION HAS RECEIVED N EXPLICIT VALUES FROM THE OPERATOR.

IN GIVING A STRING OF VALUES, COMMAS WITHOUT INTERVENING VALUES MAY BE USED TO INDICATE A REPETITION OF THE LAST NAMED VALUE.

A STRING OF VALUES MAY BE GIVEN AS A RANGE (6-10 FOR EXAMPLE). IF THE VALUES REPRESENT PURE NUMERICAL DATA, THIS SAMPLE RANGE TRANSLATES TO THE STRING 6,7,8,9,10 (AN INCREMENT OF 1). IF THE VALUES ARE ADDRESSES, THE SAMPLE RANGE TRANSLATES TO THE STRING 6,8,10 (AN INCREMENT OF 2).

NOW LET US SEE HOW WE COULD USE THESE CAPABILITIES TO CONSTRUCT A SET OF P-TABLES. ASSUME THAT WE HAVE 64 UNITS, AND THAT THERE ARE THREE HARDWARE PARAMETERS FOR EACH (THREE SLOTS IN THE P-TABLE, THREE HARDWARE QUESTIONS IN THE DIALOGUE). LET THE DESIRED VALUE FOR THE FIRST PARAMETER BE THE NUMBER 75 FOR ALL 64 TABLES. LET THE DESIRED VALUE FOR THE SECOND PARAMETER BE EQUAL TO THE UNIT NUMBER (1,2,3,...,64) EXCEPT FOR UNIT 50, WHICH SHOULD RECEIVE THE VALUE 49. LET THE DESIRED VALUE FOR THE THIRD PARAMETER BE THE NUMBER 76 FOR THE FIRST 20 UNITS AND THE NUMBER 77 FOR THE LAST 44 UNITS.

THE FOLLOWING DIALOGUE WOULD ACCOMPLISH THIS GOAL:



# UNITS (D) ? 64

UNIT 1

<QUESTION 1> ? 75  
 <QUESTION 2> ? 1-20  
 <QUESTION 3> ? 76

UNIT 21

<QUESTION 1> ?  
 <QUESTION 2> ? 21-49,,51-64  
 <QUESTION 3> ? 77

THE FIRST TIME THE SERIES IS ASKED, SLOT ONE RECEIVES A 75 IN ALL 64 TABLES. SLOT TWO RECEIVES THE VALUES 1,2,3,...,20 IN TABLES 1 THRU 20 AND A CONSTANT 20 IN TABLES 21 THRU 64. SLOT THREE RECEIVES A CONSTANT 76 IN ALL 64 TABLES.

THE SECOND TIME THRU THE SERIES, TABLES 21 THRU THE END ARE GOING TO BE AFFECTED (NOTE THAT THIS PIECE OF INFORMATION IS PRINTED OUT FOR THE OPERATOR IN THE FORM "UNIT XX" AT THE BEGINNING OF EACH SERIES). QUESTION 1 IS RESPONDED TO BY A <CR>, SO SLOT ONE STAYS AT CONSTANT 75 IN TABLES 21 THRU 64, SINCE NO NEW EXPLICIT VALUES ARE TYPED IN. SLOT TWO GETS THE VALUES 21,22,23,...,49 IN TABLES 21 THRU 49, AND GETS A 49 IN SLOT 50, AND GETS THE VALUES 51,52,53,...,64 IN TABLES 51 THRU 64. SLOT THREE GETS THE VALUE 77 IN TABLES 21 THRU 64.

THE DIALOGUE IS TERMINATED WHEN THE SOFTWARE RECOGNIZES THAT 64 EXPLICIT VALUES HAVE BEEN GIVEN FOR AT LEAST ONE QUESTION (NAMELY QUESTION 2).

## 2.4 EXECUTION TIMES

FIRST PASS EXECUTION ON 1 DRIVE WITH MANUAL INTERVENTION WILL REQUIRE AT LEAST 3 MINUTES. THE ACTUAL AMOUNT OF TIME REQUIRED WILL DEPEND ON THE SPEED WITH WHICH THE REQUESTED OPERATIONS ARE PERFORMED BY THE USER.

FIRST PASS EXECUTION ON MORE THAN ONE DRIVE WITH DRIVE SELECT TESTS WILL REQUIRE AT LEAST (TBD). ACTUAL TIME WILL AGAIN DEPEND ON THE USER.

IF HEAD ALIGNMENT SUPPORT IS REQUESTED, THE PROGRAM RUN TIME IS CONTROLLED BY THE DURATION OF THE HEAD ALIGNMENT OPERATION.

IF MANUAL INTERVENTION, DRIVE SELECT, OR HEAD ALIGNMENT SUPPORT ARE NOT REQUESTED, (OR IN SECOND AND SUBSEQUENT PASSES REGARDLESS OF REQUESTED OPERATION) THE RUN TIME IS APPROXIMATELY 3 SECONDS.

## 3.0 ERROR INFORMATION

### 3.1 ERROR REPORTING

MOST ERROR REPORTS HAVE THE FOLLOWING FORMAT.



```

(1)  PROG NAME  ERR NUM  TEST NUM  SUBTEST NUM  ERR PC
(2)  ROUTINE TRACE SEQ (IN SEQ CALLED)
      (ADDRESS)
      (ADDRESS)

      (ADDRESS)
(3)  TEST DESCRIPTION
(4)  OPERATION:
(5)  RESULT:
(6)  ADDRESS OF UNIT UNDER TEST
(7)  RLCS  RLDA  RLBA  RLMP  CYL  HD
(8)  OP INIT
(9)  OP DONE
(10) DRIVE STATUS
(11) WORD NUM IS (XXXXXX) SB (YYYYYY)
(12) TOTAL COMPARE ERRS: (ZZZ) OF (128)

```

THE ONLY EXCEPTION TO THE ABOVE FORMAT IS PURE DATA COMPARE

ERRORS (NOT DETECTED BY READ ERROR). THEN THE FORMAT DOES NOT INCLUDE LINES 5 THROUGH 10.

LINE 1 IS THE ERROR HEADER AND IS PROVIDED BY THE SUPERVISOR. THE PROGRAM IS IDENTIFIED BY NAME WITH THE NUMBER OF TEST AND SUBTEST PRESENTLY BEING EXECUTED.

THE SUBTEST NUMBER IS UNIQUE IN THIS PROGRAM IN THAT IT DOES NOT REFER TO A PHYSICAL SUBTEST WITHIN A GIVEN TEST. RATHER IT REFLECTS THE NUMBER OF TIMES A SUBTEST HAS BEEN EXECUTED WITHIN A TEST. CONSEQUENTLY, ON A TEST THAT TESTS AN INCREMENTAL TYPE OF OPERATION (SUCH AS INCREMENTAL SEEKS, READ ALL HEADERS FROM BOTH SURFACES, ETC.) THE SUBTEST WILL BE DESCRIPTIVE OF WHERE IN THE TEST THE ERROR OCCURRED.

THE ERROR P.C. IS THE PHYSICAL MEMORY LOCATION WHERE THE ERROR REPORT WAS INITIATED. SINCE MANY FUNCTIONS ARE SUBROUTINED, AND ERRORS ARE REPORTED FROM SUBROUTINES, THE ERROR P.C. IS NOT SUFFICIENT TO IDENTIFY THE LOCATION OF THE ERROR CALL AND THE ROUTINE TRACE SEQUENCE IS PROVIDED.

LINE 2 IS THE ROUTINE TRACE SEQUENCE. IF THE ERROR CALL IS INITIATED FROM WITHIN THE TEST (AS OPPOSED TO WITHIN A ROUTINE), THIS PORTION OF THE REPORT IS OMITTED. IF THE CALL IS INITIATED FROM A ROUTINE (WHICH MAY BE CALLED BY ANOTHER ROUTINE, WHICH MAY BE CALLED BY ANOTHER ROUTINE, ETC. SEVERAL LEVELS DEEP) THE ROUTINE TRACE SEQUENCE PROVIDES A TRAIL TO THE ACTUAL LOCATION WITHIN THE TEST THAT CALLED THE FIRST ROUTINE. THE FIRST ENTRY LISTED IS THE LOCATION WHERE THE FIRST ROUTINE WAS CALLED.

LINE 3 IS THE TEST DESCRIPTION AND IS ROUGHLY IDENTICAL TO THE NAME OF THE TEST BEING PERFORMED.

LINE 4 IDENTIFIES THE ACTUAL HARDWARE FUNCTION THAT IS BEING PERFORMED. ADDITIONAL INFORMATION ON THIS LINE IS DESCRIPTIVE OF SPECIFIC USE OF THE FUNCTION. FOR EXAMPLE, THE OPERATION



LINE 4 WILL READ "READ HEADERS FOR 40 HEADERS" WHEN ALL HEADERS ARE BEING READ FROM A TRACK.

LINE 5 IDENTIFIES THE ERROR THAT HAS BEEN DETECTED. THE CONTENT OF LINE 5 IDENTIFIES WHAT WAS BEING TESTED (SUCH AS DRIVE READY, CONTROLLER ERROR, DRIVE STATE, ETC.), WHAT IT IS AND WHAT IT SHOULD BE. LINE 5 MAY BE REPEATED IF MORE THAN ONE TESTED ITEM IS FOUND IN ERROR.

IN ADDITION LINE 5 WILL REPORT ANY HARDWARE DETECTED ERRORS SUCH AS OPERATION INCOMPLETE, HEADER CRC, ETC. IN THIS CASE THE FIRST LINE PRINTED AS RESULT WILL BE DETERMINED BY THE THREE ERROR BITS OPI, HNF/DLT, AND HCRC/DCRC. THE LINE WILL BE DETERMINED AS IN THE FOLLOWING TRUTH TABLE:

HNF/DLT	DCRC/HCRC	OPI	MESSAGE
1	1	1	HDR NOT FND/HDR CRC/OPI ERROR
0	1	1	HDR CRC ERROR
1	0	1	HDR NOT FND ERROR
0	0	0	DATA CRC ERROR
1	0	0	DATA LATE ERROR

LINE 6 IDENTIFIES THE PHYSICAL ADDRESS OF THE UNIT UNDER TEST. THIS ADDRESS IS BY UNIBUS ADDRESS OF THE CONTROLLER AND DRIVE NUMBER.

LINE 7 NAMES THE CONTROLLER REGISTERS (AND CYLINDER AND HEAD WHERE THESE ARE APPLICABLE IN THE REPORT) TO BE REPORTED.

LINE 8 PROVIDES THE CONTENTS OF CONTROLLER REGISTERS WHEN THE OPERATION WAS INITIATED.

LINE 9 PROVIDES THE CONTENTS OF THE CONTROLLER REGISTERS WHEN THE ERROR BEING REPORTED WAS DETECTED. FREQUENTLY THE REGISTER CONTENTS OF OP INIT AND OP DONE WILL BE DIFFERENT. OP INIT MAY INDICATE A SEEK WAS BEING PERFORMED BUT OP DONE MAY INDICATE THE ERROR WAS DETECTED BY A READ HEADER. THE REASON IS THAT A SEEK WAS EXECUTED AND DID NOT PROPERLY POSITION HEADS AND WHEN THE READ HEADER WAS DONE THE HEADS WERE ON THE WRONG CYLINDER.

LINE 10 IS THE DRIVE STATUS. THIS LINE IS ONLY REPORTED IF THE RLMP REGISTER DOES NOT CONTAIN THE ACTUAL DRIVE STATUS.

LINE 11 AND LINE 12 ARE REPORTED IF THE ERROR WAS DETECTED AS A COMPARE OPERATION, EITHER DATA OR HEADERS. IN ADDITION, GOOD AND BAD DATA IS REPORTED FOR ALL READ ERRORS.

3.1.1 SPECIFIC OPERATION MESSAGES

THE OPERATION MESSAGE (LINE 4) IS GENERATED IN A DYNAMIC MANNER BASED ON THE SUBSYSTEM FUNCTION BEING EXECUTED AT THE TIME OF THE ERROR AND THE STATE OF THE FLAGS IN THE LOCATION TAGGED "OPFLAGS". THE POSSIBLE OPERATION MESSAGES ARE GIVEN BELOW.

SEEK -



FROM (CYL NUM) DIFF (CYL DIFF) SGN (0 OR 1) HD (0 OR 1) WHERE THE VALUES ARE GIVEN IN OCTAL. THIS MESSAGE IS THE RESULT OF A SEEK OPERATION THAT WAS VERIFIED BY A READ HEADER AND THE HEAD POSITION AFTER A SEEK IS IN ERROR. (THE ACTUAL HEAD POSITION IN THIS ERROR SITUATION IS GIVEN IN THE RESULT LINE, LINE 5.)

READ DATA -  
IS A READ DATA OPERATION WHERE SOME FORM OF ERROR WAS DETECTED

IN THE ACTUAL READ OPERATION. THIS ERROR COULD BE HARDWARE DETECTED SUCH AS DATA CRC, HEADER CRC, HEADER NOT FOUND, ETC. OR A SOFTWARE DETECTED ERROR SUCH AS DRIVE READY RESET AFTER A READ DATA COMPLETED.

READ DATA WITH DATA COMPARE -  
IS AN ERROR THAT WAS DETECTED AS BAD DATA IN THE BUFFER AFTER A READ DATA OPERATION. WHEN THIS OPERATION IS REPORTED IT INDICATES THE ACTUAL READ DATA OPERATION COMPLETED WITH NO DETECTED ERRORS BUT THE DATA WAS WRONG.

READ HEADER -  
READ HEADER FOR 40 HEADERS -  
READ HEADER FOR 40 HEADERS WITH HEADER COMPARE -  
HAVE THE SAME GENERAL MEANING AS THE READ DATA AND READ DATA WITH DATA COMPARE. MESSAGES HAVING THE OPERATION OF READ HEADER OR READ HEADER FOR 40 HEADERS ARE THE RESULT OF ERRORS DETECTED IN THE ACTUAL OPERATION WHILE THE READ HEADER FOR 40 HEADERS WITH HEADER COMPARE INDICATES NO ERROR IN THE ACTUAL OPERATION BUT THE HEADER DATA ITSELF WAS IN ERROR.

WRITE DATA -  
RESET -  
GET STATUS -  
GET STATUS WITH RESET -  
ARE ALL BASIC OPERATIONS. AS BEFORE, THE ERROR DETECTION CAN BE EITHER HARDWARE OR SOFTWARE. THE RESULT LINE (LINE 5) WILL DEFINE THE REASON FOR THE REPORT.

LD DRV -  
UNLD DRV -  
ARE OPERATION MESSAGES THAT WILL APPEAR IN THE REPORT WHEN THE DRIVE LOAD AND UNLOAD SEQUENCE IS BEING TESTED.

ANOTHER GROUP OF OPERATION QUALIFIERS WILL BE REPORTED FOR OPERATIONS THAT FAIL IN SPECIFIC TESTS. THESE TESTS ARE THE WRITE/READ TEST PART 2, OVERWRITE TEST, AND THE ADJACENT CYLINDER INTERFERENCE TEST.

OPERATION -----	QUALIFIER -----
READ DATA WITH DATA COMPARE	FOL 0 TO CC SEEK
READ DATA	FOL 255 TO CC SEEK
WRITE DATA	FOL WRITE (NO SEEK)
READ HEADER	ADJ. CYL WRITTEN AFTER FWD SK
	ADJ. CYL WRITTEN AFTER REV SK



THE ABOVE OPERATIONS CAN BE REPORTED WITH ANY OF THE

QUALIFIERS. THE QUALIFIERS IN THESE TESTS ARE AN ATTEMPT TO MAKE THE REPORT MORE MEANINGFUL BY PROVIDING INFORMATION ABOUT THE SEQUENCE OF OPERATIONS BEING DONE.

THE QUALIFIERS "FOL 0 TO CC SEEK" AND "FOL 255 TO CC SEEK" INDICATE THAT THE SEQUENCE OF OPERATIONS INCLUDED A SEEK OF A GIVEN DIRECTION TO THE CYLINDER WHERE THE TEST IS BEING PERFORMED.

THE "FOL WRITE (NO SEEK)" QUALIFIER MEANS THAT THE OPERATION WAS DONE AFTER A WRITE WITH NO HEAD MOVEMENT BETWEEN THE WRITE AND READ.

THE QUALIFIER "ADJ CYL WRITTEN AFTER FWD SK" AND "ADJ CYL WRITTEN AFTER REV SK" WILL BE REPORTED ONLY IN THE ADJACENT CYLINDER INTERFERENCE TEST. THESE QUALIFIERS ARE USED WHEN THE ERROR OCCURS ON THE CYLINDER UNDER TEST AND DEFINE THE DIRECTION THE HEADS WERE MOVED WHEN THE ADJACENT CYLINDER WAS WRITTEN.

THE QUALIFIERS "SK FWD, WRT-SK REV, OVERWRT" AND "SK REV, WRT-SK FWD, OVERWRT" WILL BE REPORTED ONLY IN THE OVERWRITE TEST. THESE QUALIFIERS DEFINE THE DIRECTION OF HEAD MOTION BEFORE THE INITIAL WRITE AND THE OVERWRITE.

THE QUALIFIER "ON BAD SEC FILES" WILL BE REPORTED WITH THE WRITE DATA COMMAND IF THE PROGRAM ABORTS THAT COMMAND BECAUSE THE WRITE WOULD BE ON THE BAD SECTOR FILES.

### 3.1.2 SPECIFIC RESULT MESSAGES

THE RESULT MESSAGE (LINE 5) IS GENERATED DYNAMICALLY BASED ON THE EXPECTED RESULT OF THE OPERATION BEING TESTED. SINCE OPERATIONS ARE MONITORED DURING EXECUTION THE RESULT MESSAGE MAY REPORT AN ERROR DETECTED DURING THE OPERATION AS WELL AS THE ERRORS SEEN AT THE END OF THE OPERATION. ONLY THE FIRST ERROR SEEN IS REPORTED IN ALL CASES.

THE GENERAL FORMAT FOR THE RESULT LINE IS

RESULT:(VAR 1) IS (VAR 2) SB (VAR 3) (OPTIONAL QUALIFIER)

WHERE VARIABLE 1 CAN BE ONE OF THE FOLLOWING:

CONT ERR	(CONTROLLER ERROR)
DRV ERR	(DRIVE ERROR)
NON-EXSTNT MEM	(NON-EXISTANT MEMORY)
HDR CRC	(HEADER CRC ERROR)
DATA CRC	
HDR NOT FND	(HEADER NOT FOUND)
DATA LATE	



HDR NOT FND/HDR CRC/OPI	(ALL 3 BITS SET)
DRV RDY	(DRIVE READY)
SELECTED HEAD	
VOL CHK	(VOLUME CHECK)
COVER OPEN	
BRUSH HME	(BRUCH HOME)
WRT LCK	(WRITE LOCK)
HDS OUT	(HEADER OUT)
DRV SEL ERR	(DRIVE SELECT ERROR)
DRV STATE	(DRIVE STATE)
SPIN TIMEOUT	(SPINDLE TIMEOUT SPD ERROR)
WRT GAT ERR	(WRITE GATE ERROR)
SEEK TIMEOUT	(SKTO ERROR)
CUR HEAD ERR	(CURRENT IN HEAD ERROR)
WRT DAT ERR	(WRITE DATA ERROR)
OP INCOMPLETE	(OPI ERROR)
HDR/DAT ERR	(HEADER CRC OR DATA CRC ERROR BIT 11 OF CS REGISTER)
HDR NOT FND/DAT LATE	(HEADER NOT FOUND OR DATA LATE ERROR BIT 12 OF CS REGISTER)
CYL	(CYLINDER WHEN REPORTING A SEEK ERROR)

VARIABLE 2 WILL BE A VALUE THAT DEFINES WHAT THE RESULT ACTUALLY IS. THIS CAN BE A 1 OR 0 TO INDICATE A SET OF RESULT CONDITIONS, A NUMBER 0 TO 7 TO INDICATE THE DRIVE STATE, OR A NUMBER 0 TO 377 (OCTAL) TO IDENTIFY A CYLINDER NUMBER.

VARIABLE 3 DEFINES THAT THE VALUE GIVEN IS VARIABLE 2 SHOULD BE.

THE OPTIONAL QUALIFIER IS PROVIDED WHEN IT IS USEFUL TO KNOW WHEN THE ERROR WAS DETECTED IN THE OPERATION BEING PERFORMED. THIS QUALIFIER IS USED TO REPORT RESULTS SUCH AS:

BRUSH HME	IS	1	SB	0	IN	STATE	2
HEADS OUT	IS	0	SB	1	IN	STATE	3
DRV RDY	IS	0	SB	1	IN	DATA	XFER
SELECTED HEAD	IS	1	SB	0	IN	CYCLE	UP
DRV RDY	IS	0	SB	1	IN	STATE	5
DRV RDY	IS	1	SB	0	IN	SEEK	W/O MOTION
DRV RDY	IS	0	SB	1	IN	10MS	
DRV RDY	IS	0	SB	1	IN	500MS	
DRV RDY	IS	0	SB	1	IN	5SECONDS	

THESE RESULTS, WHEN SEEN WITH THE OPERATION MESSAGE, WILL BE SELF EXPLANATORY.

OTHER RESULT MESSAGES THAT CAN BE PART OF AN ERROR REPORT ARE:

"INTERRUPT TO LATE"  
WHICH INDICATES THAT THE OPERATION BEING PERFORMED DID NOT

COMPLETE IN THE EXPECTED AMOUNT OF TIME. THIS RESULT CAN BE CAUSED BY THE DRIVE LOSING READY BEFORE STARTING A READ



F02

HEADER AND THEREFORE NOT COMPLETING THE READ HEADER IN IMS.

SEQ 0018

"FAIL TO RELOAD HDS AFTER ERR CLEAR"  
IS REPORTED WHEN AN ERROR CAUSES HEADS TO UNLOAD AND AFTER THE  
ERROR IS CLEARED THE HEADS DO NOT RELOAD.

"UNKN DRV STATE-NO RDY, NO ERR, HDS OUT"  
IS REPORTED WHEN THE PROGRAM CANNOT DETERMINE THE DRIVE STATE  
OR STATUS.



"WRITE ABORTED"  
IS REPORTED WHEN THE PROGRAM ABORTS A WRITE TO PROTECT THE BAD  
SECTOR FILES.

"COULD NOT RETRIEVE DRIVE STATUS"  
IS REPORTED IF THE GET STATUS COMMAND DOES NOT COMPLETE  
SUCCESSFULLY WHEN THE STATUS IS REQUIRED TO REPORT AN ERROR.

"OPI SET-NO DRIVE RESPONSE"  
IS REPORTED AS THE RESULT WHEN THE GET STATUS COMMAND IS TIMED  
OUT (OPI SETS) WHEN THAT COMMAND IS BEING USED IN THE EARLY  
TESTS TO CHECK THE DRIVE INTERFACE.

"NO INTERRUPT ON CMND COMPLETE"  
IS REPORTED WHEN THE COMMAND SUCCESSFULLY COMPLETES BUT THE  
CONTROLLER HAS NOT GENERATED AN INTERRUPT.

"ERR DID NOT CLEAR" IS REPORTED WHEN THE RESET COMMAND DOES  
NOT CLEAR THE CONTROLLER ERRORS. THIS IS A CONTROLER RELATED  
PROBLEM BUT IS REPORTED IF SEEN IN THE DRIVE TEST PROGRAMS.

"DRV ERR IS NOT CLEARED"  
IS REPORTED WHEN THE GET STATUS W/RESET COMMAND DOES NOT CLEAR  
ALL DRIVE ERRORS.

"UNEXPECTED ERR"  
IS REPORTED WHEN THE CONTROLLER SENSES AN ERROR BUT NO ERROR  
BITS ARE SET.

"BAD SEC FILE FMT ERR"  
IS REPORTED IF THE CONTENTS OF THE FILES DO NO CORRESPOND TO  
THE EXPECTED FORMAT. (REFER TO DEC STANDARD 144 FOR FORMAT  
SPECIFICS.)

### 3.1.3 OTHER MESSAGES

OTHER INFORMATION IS REPORTED UNDER VARIOUS CIRCUMSTANCES.  
THESE ARE:

"BAD SEC FILES NOT STRD. ALL SEC ASSUMED GOOD."  
THIS MESSAGE IS PRINTED WHEN A PARTICULAR TEST REQUIRES THE  
BAD SECTOR FILES BUT THEY HAVE NOT BEEN STORED. THIS  
SITUATION WILL OCCUR IF THIS TEST IS STARTED OUT OF THE NORMAL  
PROGRAM SEQUENCE OR IF THE BAD SECTOR FILES COULD NOT BE READ.

"ERROR LIMIT EXCEEDED-UNIT DROPPED"  
IS REPORTED (WITH THE UNIT NUMBER) WHEN MORE THAN THE  
SPECIFIED NUMBER OF ERRORS (DEFAULT 20) HAVE OCCURED IN ANY  
SINGLE PASS.

### 3.2 ERROR HALTS

ERROR HALTS ARE SUPPORTED PER DESCRIBED IN THE PREVIOUS SECTION  
WITH /FLAG:HOE. THERE ARE NO OTHER HALTS.



#### 4.0 PERFORMANCE AND PROGRESS REPORTS

---

##### 4.1 PERFORMANCE REPORTS

---

THIS PROGRAM WILL NOT GIVE ANY PERFORMANCE REPORTS.

##### 4.2 PROGRESS REPORTS

---

THIS PROGRAM WILL NOT GIVE ANY PROGRESS REPORTS.

#### 5.0 DEVICE INFORMATION TABLES

---

THE RL11/RLV11 CONTROLLER HAS THE FOLLOWING FOUR(4) REGISTERS FOR CONTROL OF THE SUBSYSTEM.

##### RLCS - CONTROL AND STATUS REGISTER (XXXXXD)

---

BIT 15 - COMPOSITE ERROR  
 BIT 14 - DRIVE ERROR  
 BIT 13 - NON EXISTANT MEMORY ERROR  
 BIT 12 - HEADER NOT FOUND (WITH BIT 10 SET)  
           - DATA LATE (WITH BIT 10 CLEAR)  
 BIT 11 - HEADER CRC (WITH BIT 10 SET)  
           - DATA CRC (WITH BIT 10 CLEAR)  
 BIT 10 - OPERATION INCOMPLETE  
 BIT 9/8 - DRIVE SELECT (0-3)  
 BIT 7 - CONTROLLER READY  
 BIT 6 - INTERRUPT ENABLE  
 BIT 5 - EXTENDED BUS ADDRESS (BIT 17)  
 BIT 4 - EXTENDED BUS ADDRESS (BIT 16)  
 BIT 3-1 - FUNCTION CODE  
           0 - NOP (PDP-11) MAINT (LSI-11)  
           1 - WRITE CHECK  
           2 - GET DRIVE STATUS  
           3 - SEEK  
           4 - READ HEADER  
           5 - WRITE DATA  
           6 - READ DATA  
           7 - READ WITHOUT HEADER COMPARE

BIT 0 - DRIVE READY

##### RLBA - BUS ADDRESS REGISTER (XXXXX2)

---

BITS 15-1 BUS ADDRESS OF DATA TRANSFER  
 BIT 0 SHOULD BE 0

##### RLDA - DISK ADDRESS REGISTER (XXXXX4)

---

FOR READ/WRITE FUNCTIONS



-----  
 BIT 15 - MUST BE ZERO(0)  
 BIT 14-7 - CYLINDER ADDRESS FOR TRANSFER  
 BIT 6 - SURFACE FOR TRANSFER  
 BIT 5-0 - SECTOR FOR TRANSFER (0-47)

FOR SEEK FUNCTION  
 -----

BIT 15 - MUST BE ZERO(0)  
 BIT 14-7 - DIFFERENCE TO NEW CYLINDER  
 BIT 6-5 - MUST BE ZERO(0)  
 BIT 4 - SURFACE  
 BIT 3 - MUST BE ZERO  
 BIT 2 - SEEK DIRECTION( 1 - IN / 0 - OUT )  
 BIT 1 - MUST BE ZERO  
 BIT 0 - MUST BE ONE(1)

FOR GET STATUS FUNCTION  
 -----

BIT 15-4 - IGNORED SHOULD BE ZERO  
 BIT 3 - DRIVE RESET  
 BIT 2 - MUST BE ZERO  
 BIT 1 - MUST BE ONE  
 BIT 0 - MUST BE ONE

RLMP - MULTIPURPOSE REGISTER  
 -----

FOR READ/WRITE FUNCTION  
 -----

BIT 15 - 0 - WORD COUNT(TWO'S COMPLIMENT)

FOR READ HEADER FUNCTION  
 -----

BIT 15-0 - DISK HEADER OF SECTOR (FIRST READ)  
 - ZERO WORD (SECOND READ)  
 - HEADER CRC (THIRD READ)

FOR GET STATUS FUNCTION  
 -----

HAS DRIVE STATUS

BIT 15 - WRITE DATA ERROR  
 BIT 14 - CURRENT HEAD ERROR(CHE)  
 BIT 13 - WRITE LOCK STATUS(WL)  
 BIT 12 - SEEK TIME OUT(SKTO)  
 BIT 11 - SPIN ERROR(SPE)  
 BIT 10 - WRITE GATE ERROR(WGE)  
 BIT 9 - VOLUME CHECK(VC)  
 BIT 8 - DRIVE SELECT ERROR(DSE)  
 BIT 7 - RESERVED(0)  
 BIT 6 - SURFACE  
 BIT 5 - COVER OPEN  
 BIT 4 - HEADS HOME



BIT 3 - BRUSHES HOME  
 BIT 2-0 - STATE BITS  
   0 - LOAD STATE  
   1 - SPIN UP  
   2 - BRUSH CYCLE  
   3 - LOAD HEADS  
   4 - SEEK - TRACK COUNTING  
   5 - SEEK - LINEAR MODE  
   6 - UNLOAD HEADS  
   7 - SPIN DOWN

## 6.0 TEST SUMMARIES

-----

### TEST 1 BASIC INTERFACE TEST (PART 1)

LOAD IN DRIVE NUMBER. DO GET STATUS WITH RESET. IF OPI SETS:  
 DRIVE INTERFACE IS DEAD  
 DRIVE COMMAND SHIFT REGISTER NOT LOADING/SHIFTING  
 MARKER DETECTION FAILED  
 DRIVE IS NOT SELECTING OR AC LOW IS SET  
 SYSTEM OR STATUS CLOCKS NOT OPERATIONAL  
 GET STATUS DETECTION FAILED.

IF INTERRUPT WITH NO OPI, CHECK STATUS RECEIVED. COVER OPEN  
 AND BRUSH HOME SHOULD BE SET. IF NOT:  
 BAD STATUS DATA LINE  
 BAD COVER SWITCH OR LOGIC  
 DRIVE COMMAND SHIFT REGISTER  
 BAD BRUSH HOME SWITCH OR LOGIC

CHECK WRITE LOCK STATUS BIT SET. IF NOT:  
 BAD SWITCH OR WRITE LOCK LOGIC

DRIVE COMMAND SHIFT REGISTER

CHECK STATE FOR 0. IF NOT:  
 BAD STATE ROM  
 DRIVE COMMAND SHIFT REGISTER

CHECK VOLUME CHECK RESET. IF NOT:  
 BAD RESET DETECTION  
 BAD VOLUME CHECK LOGIC  
 DRIVE COMMAND SHIFT REGISTER

CHECK DRIVE ERROR RESET. IF NOT:  
 BAD DRIVE ERROR INTERFACE  
 SOME OTHER ERROR STUCK ON. REPORT WHICH ERROR.

NOTE: THIS TEST IS EXECUTED ONLY IF PROGRAM OPERATION MODE 2  
 IS SELECTED, MANUAL INTERVENTION TESTING IS REQUESTED,



AND IS RUN IN FIRST PASS ONLY.

TEST 2 BASIC INTERFACE TEST (PART 2)

REQUEST OPERATOR TO CLOSE COVER AND RESET WRITE LOCK.

DO GET STATUS LOOP CHECKING IF COVER OPEN OR WRITE LOCK  
RESETS. WAIT 15 SECONDS FOR BOTH TO CHANGE. IF NO CHANGE,  
ASK OPERATOR TO TYPE CR IF PROCEDURE WAS FOLLOWED.

IF ONE CHANGED BUT NOT THE OTHER, REPORT WHICH FAILURE:

WRITE LOCK SWITCH OR LOGIC  
(OR) COVER OPEN SWITCH OR LOGIC  
DRIVE COMMAND SHIFT REGISTER

IF NEITHER CHANGED, REPORT BOTH FAILURES.

NOTE: THIS TEST IS EXECUTED ONLY IF PROGRAM OPERATION MODE 2  
IS SELECTED, MANUAL INTERVENTION TESTING IS REQUESTED,  
AND IS RUN IN FIRST PASS ONLY.

TEST 3 HEAD LOADING TEST

REQUEST OPERATOR TO PRESS LOAD SWITCH.

DO GET STATUS LOOP CHECKING FOR STATE TO GO TO 1. WAIT 30  
SECONDS FOR CHANGE. IF NO CHANGE, ASK OPERATOR TO CONFIRM  
ACTION BY TYPING CR.

IF LOAD WAS PRESSED:

BAD STATE ROM

BAD LOAD SWITCH OR LOGIC

CHECK THAT STATE 1 REMAINS FOR LESS THAN 30 SECONDS. IF NOT:

SPINDLE NOT TURNING OR TOO SLOW (AC SERVO)  
SECTOR PULSE DETECTION OR LOGIC BAD  
BAD CLOCK SHIFT REGISTER IN SPEED CONTROL  
BAD DISK ON SPEED LOGIC  
BAD STATE ROM

AND CHECK IF SPINUP TIMEOUT ERROR SET. IF NOT:

BAD STATE ROM  
BAD TIMEOUT DETECTION LOGIC

CHECK THAT STATE GOES TO 2. IF NOT:

BAD STATE ROM

CHECK THAT BRUSH HOME IS RESET 5 SECONDS OR LESS AFTER STATE  
IS 2. IF NOT:

BAD BRUSH HOME SWITCH OR LOGIC

BAD BRUSH MOTOR (AC SERVO)

WAIT 30 SECONDS FOR BRUSH HOME TO SET. IF NOT:

BAD AC SERVO  
BAD SWITCH OR LATCH

CHECK THAT STATE HAS CHANGED TO 3. IF NOT:

BAD STATE ROM

AFTER STATE IS 3, CHECK HEADS OUT IS SET. IF NOT:

BAD SWITCH  
BAD SEEK CONTROL ROM  
BAD VELOCITY ROM  
BAD DC SERVO

CHECK VOLUME CHECK IS SET. IF NOT:

BAD VOLUME CHECK LOGIC

CHECK IF DRIVE ERROR IS SET. IF NOT:

BAD DRIVE ERROR LOGIC OR INTERFACE

WAIT 300 MS FOR STATE TO CHANGE TO 4. IF IT DOESN'T CHANGE:

STATE ROM BAD  
SEEK ROM  
VEL ROM  
GUARD BAND DETECTION

WAIT 15 MS FOR STATE TO CHANGE TO 5.

8 MS AFTER STATE GOES TO 5, DRIVE READY SHOULD SET. IF NOT:

INTEGRATOR OR NULL DETECTION FAILURE  
READY ONE SHOT BAD  
ENABLE TIMEOUT H NOT SETTING OR COUNT LOGIC BAD

NOTE: THIS TEST IS EXECUTED ONLY IF PROGRAM OPERATION MODE 2  
IS SELECTED, MANUAL INTERVENTION TESTING IS REQUESTED,  
AND IS RUN IN FIRST PASS ONLY.

#### TEST 4 HEAD UNLOADING TEST

CHECK DRIVE IS READY. IF NOT REPORT AND ASK OPERATOR TO MAKE  
DRIVE READY.

REQUEST OPERATOR TO UNLOAD DRIVE.

LOOP ON GET STATUS WAITING FOR STATE TO CHANGE TO 6. IF NO  
CHANGE:

BAD STATE ROM  
BAD SWITCH



WAIT 300 MS FOR STATE TO CHANGE TO 7. IF NO CHANGE:

BAD STATE ROM

AFTER STATE IS 7, WAIT 30 SEC FOR STATE TO CHANGE TO STATE 0.  
IF NO CHANGE:

NO BRAKING  
BAD AC SERVO

REQUEST OPERATOR TO LOAD DRIVE. WAIT UNTIL DRIVE BECOMES  
READY.

NOTE: THIS TEST IS EXECUTED ONLY IF PROGRAM OPERATION MODE 2  
IS SELECTED, MANUAL INTERVENTION TESTING IS REQUESTED,  
AND IS RUN IN FIRST PASS ONLY.

#### TEST 5 DRIVE SELECT TEST

INSTRUCT THE OPERATOR TO REMOVE DRIVE ADDRESS PLUGS FROM ALL  
DRIVES EXCEPT THE DRIVE UNDER TEST. ASK THAT CARRIAGE RETURN

BE TYPED WHEN DONE.

DO GET STATUS TO ADDRESS OF DRIVE UNDER TEST. CHECK THAT NO  
ERRORS ARE REPORTED. DO GET STATUS TO ALL OTHER ADDRESSES AND  
CHECK THAT OPI SETS FOR ALL OTHER ADDRESSES.

DO GET STATUS TO ADDRESS OF NEXT SEQUENTIAL ADDRESS. CHECK  
THAT NO ERRORS ARE REPORTED. DO GET STATUS TO ALL OTHER  
ADDRESSES AND CHECK THAT OPI SETS.

REPEAT FOR ALL DRIVE ADDRESSES (0,1,2,3 - 0 IS SEQUENTIAL  
AFTER 3).

NOTE: THIS TEST IS EXECUTED ONLY IF PROGRAM OPERATION MODE 2  
IS SELECTED, DRIVE SELECT TESTING IS REQUESTED, AND IS  
RUN IN FIRST PASS ONLY.

#### TEST 6 DRIVE SELECT ERROR TEST

REQUEST OPERATOR INSERT IDENTICAL ADDRESS PLUGS IN TWO DRIVES  
(MUST BE IDENTICAL TO NUMBER SPECIFIED EARLIER). REQUEST  
OPERATOR TYPE CARRIAGE RETURN WHEN READY.

PROCEDURE WILL BE TO GET STATUS AND CHECK FOR DRIVE SELECT  
ERROR. THEN RESET THAT DRIVE AND VERIFY THAT DRIVE SELECT  
ERROR IS NOT REPORTED AGAIN. WAIT 1 SECOND, THEN CHANGE DRIVE  
SELECT TO A DIFFERENT NUMBER AND BACK AGAIN. DRIVE SELECT  
ERROR SHOULD SET AGAIN.

OPERATOR SHOULD SEE THE FAULT LIGHT ON ON BOTH DRIVES. IF  
INDICATOR IS NOT SEEN ON A DRIVE:

DRIVE SELECT ERROR DETECTION IS BAD IN THAT DRIVE.

NOTE: THIS TEST IS EXECUTED ONLY IF PROGRAM OPERATION MODE 2 IS SELECTED, DRIVE SELECT TESTING IS REQUESTED, AND IS RUN IN FIRST PASS ONLY.

#### 4.2 STANDARD TESTS

IF THE PROGRAM OPERATION MODE 1 IS SELECTED, THIS WILL BE THE FIRST TEST EXECUTED. THE DRIVE(S) TO BE TESTED MUST BE POWERED UP, HEADS LOADED, AND WRITE LOCK RESET.

#### TEST 7 INITIAL STATE TEST

DO GET STATUS, WAIT FOR INTERRUPT.

IF OPI OCCURS:

DRIVE INTERFACE IS DEAD

DRIVE COMMAND SHIFT REGISTER NOT LOADING/SHIFTING  
DRIVE IS NOT SELECTING OR AC LOW IS SET  
SYSTEM OR STATUS CLOCKS NOT OPERATIONAL  
GET STATUS DETECTION FAILED.

IF INTERRUPT OCCURS WITHOUT OPI, CHECK DRIVE READY. READY SET INDICATES HEADS ARE LOADED AND ARE TRACKING (POSITION WORKING).

IF MANUAL INTERVENTION TESTS WERE RUN, CHECK THAT HEAD 0 IS SELECTED. IF NOT:

DRIVE CYCLE UP DID NOT SELECT HEAD 0

IF DRIVE READY IS SET, CHECK STATUS MESSAGE RECEIVED. HEADS OUT AND BRUSH HOME MUST BE SET. IF NOT:

DRIVE COMMAND SHIFT REGISTER NOT LOADING/SHIFTING  
HEADS OUT OR BRUSH HOME SWITCH OR ASSOCIATED  
CIRCUITRY BAD  
STATUS DATA BAD

IF MANUAL INTERVENTION TESTS WERE RUN AND THIS IS THE FIRST PASS CHECK THAT VOLUME CHECK AND DRIVE ERROR ARE SET.

CHECK ALL ERROR BITS ARE 0.

CHECK STATE IS 5. IF NOT:

DRIVE COMMAND SHIFT REGISTER BAD

#### TEST 8 INITIAL RESET STATE TEST

DO GET STATUS HEAD SELECT = 0, WAIT FOR INTERRUPT.

DO GET STATUS WITH RESET, WAIT FOR INTERRUPT. BOTH DRIVE ERROR AND VOLUME CHECK SHOULD NOW BE RESET. IF NOT:

RESET DETECTION, RESET ERROR, OR VOLUME CHECK FLOP BAD



DRIVE COMMAND SHIFT REGISTER BAD

HEAD SELECTED BIT SHOULD STILL BE ZERO. IF NOT:

DRIVE COMMAND SHIFT REGISTER BAD  
HEAD SELECT SHIFT REGISTER NOT LOADING

TEST 9 DRIVE READY TEST

DO SEEK WITH 0 DIFFERENCE, SIGN 0, HEAD 0. WAIT FOR  
INTERRUPT. GET STATUS. CHECK STATE IS 5. IF NOT:

DIFFERENCE COUNTER PICKING UP BITS  
COUNTER CIRCUITRY IS NOT INDICATING 0 DIFFERENCE

CHECK DRIVE READY IS RESET. IF NOT:

ENABLE TIMEOUT OR READY LATCH/ONE SHOT BAD

WAIT APPROX 8 MS FOR READY TO SET. IF IT TAKES LONGER OR  
DOESN'T SET AT ALL:

HEADS MAY HAVE MOVED (INTEGRATOR OR NULL DETECTION)  
READY ONE SHOT FAILED

CHECK DRIVE ERROR DID NOT SET. IF IT SET, DO GET STATUS AND  
REPORT WHICH ERROR.

VERIFY HEAD SELECT IS ZERO.

TEST 10 SEEK SIGN SWITCH TEST

DO SEEK WITH DIFFERENCE 0, SIGN 1, HEAD 0. WAIT FOR  
INTERRUPT. GET STATUS AND CHECK STATE IS 5. IF NOT:

COUNT ROM  
DIFFERENCE COUNTER PICKING UP BITS  
COUNTER CIRCUITRY IS NOT INDICATING 0 DIFFERENCE

VERIFY DRIVE IS NOT READY

WAIT APPROX 8 MS FOR READY TO SET. IF IT TAKES LONGER OR  
DOESN'T SET AT ALL:

HEADS ARE MOVING (INTEGRATOR OR NULL DETECTION)  
READY ONE SHOT FAILED  
COUNT ROM

VERIFY DRIVE ERROR DID NOT SET

VERIFY HEAD SELECT IS ZERO.

DO SEEK WITH 0 DIFFERENCE, OPPOSITE SIGN, HEAD 0. REPEAT  
ABOVE TESTS.

TEST 11 HEAD ALIGNMENT SUPPORT ROUTINE

THIS TEST IS EXECUTED WHEN THE PROGRAM IS STARTED AT ADDRESS 204. HEAD ALIGNMENT SUPPORT IS REQUESTED, AND IN THE FIRST PASS ONLY. IT IS BYPASSED IF THE PROGRAM IS STARTED AT ANY OTHER ADDRESS AND IN THE SECOND AND SUBSEQUENT PASSES.

THIS TEST SELECTS THE DRIVE UNDER TEST AND LOOPS ON A GET

STATUS WITH RESET. THE WRITE LOCK BIT IS MONITORED AND WHEN WRITE LOCK IS RESET HEAD 0 IS SELECTED AND WHEN WRITE LOCK IS SET HEAD 1 IS SELECTED. THIS WILL PERMIT THE HEADS TO BE ALIGNED IN KEEPING WITH THE PRESENT HEAD ALIGNMENT PROCEDURE WITHOUT RETURNING TO THE CONSOLE.

TYPING A CARRIAGE RETURN ON THE CONSOLE WILL TERMINATE THIS TEST ON THE DRIVE UNDER TEST. BEFORE TERMINATING, THE TEST WILL CHECK THAT WRITE LOCK IS RESET. IF NOT, THE OPERATOR WILL BE REQUESTED TO RESET WRITE LOCK.

#### TEST 12 HEAD SWITCHING TEST

DO SEEK WITH 0 DIFFERENCE, SIGN 0, HEAD 1. WAIT FOR INTERRUPT. GET STATUS AND CHECK STATE IS 5. IF NOT:

DIFFERENCE COUNTER IS PICKING UP BITS  
ASSOCIATED CIRCUITRY IS BAD

VERIFY DRIVE READY RESET. IF NOT:

ENABLE TIMEOUT OR READY LATCH/ONE SHOT BAD

WAIT APPROX 8 MS FOR READY TO SET. IF IT TAKES LONGER OR DOESN'T SET AT ALL:

HEADS ARE MOVING (INTEGRATOR OR NULL DETECTION)  
READY ONE SHOT FAILED  
DRIVE CANNOT TRACK WITH THIS HEAD

VERIFY DRIVE ERROR DID NOT SET.

DO GET STATUS, CHECK HEAD SELECT IS CORRECT. IF NOT:

HEAD SELECT REGISTER BAD  
DRIVE COMMAND SHIFT REGISTER BAD

DO SEEK WITH 0 DIFFERENCE, SIGN 0, HEAD 0. REPEAT ABOVE TESTS.

#### TEST 13 READ HEADER TEST (PART 1)

DO SEEK WITH DIFFERENCE 0, HEAD 0, SIGN 0. WAIT FOR INTERRUPT AND WAIT FOR DRIVE READY.

DO READ HEADER, WAIT FOR INTERRUPT.

CHECK IF HEADER CRC ERROR SET. IF SET:

READ/WRITE BOARD BAD



READ DATA LINE BAD

SEQ 0029

CHECK IF BIT 6 OF WORD 1 IS SAME AS HEAD SELECT BIT IN STATUS.  
IF NOT:

HEADS ARE SWITCHED (CABLE)  
HEAD SELECT LOGIC

IF MANUAL INTERVENTION TESTS WERE RUN AND HEAD ALIGNMENT TESTS  
WERE NOT RUN, CHECK THAT HEADER WORD 0 INDICATES HEADS ARE  
POSITIONED OVER CYLINDER 0. STORE HEADER WORD 1.

REPEAT TESTS USING HEAD 1.

CHECK THAT CYLINDER PORTION OF STORED HEADER WORD 1 IS THE  
SAME AS HEADER WORD 1 OF THIS HEADER. IF NOT:

HEADS ARE MISALIGNED

TEST 14 READ HEADER TEST (PART 2)

DO SEEK WITH DIFFERENCE 0, SIGN 0, HEAD 0. WAIT FOR  
INTERRUPT. WAIT FOR READY.

DO 40 CONSECUTIVE READ HEADER, STORE 3 HEADER WORDS AFTER EACH  
READ.

CHECK ALL HEADERS FOR SEQUENCE AND CONTENT (WORD 2 ALL ZERO,  
BIT 15 WORD 1 AND 3 IS 0, HS BIT WORD 1 IS 0). IF NOT:

BAD READ/WRITE BOARD  
BAD PACK

DO SEEK WITH DIFFERENCE 0, SIGN 0, HEAD 1. REPEAT ABOVE TEST  
FOR HEAD 1.

7.0 PROGRAM LISTING  
-----

5195	*TEST 1	BASIC INTERFACE (PART 1)
5233	*TEST 2	BASIC INTERFACE (PART 2)
5262	*TEST 3	HEAD LOADING
5420	*TEST 4	HEAD UNLOADING
5501	*TEST 5	DRIVE SELECT
5550	*TEST 6	DRIVE SELECT TEST
5643	*TEST 7	INITIAL STATE
5707	*TEST 8	INITIAL RESET STATE
5730	*TEST 9	DRIVE READY
5788	*TEST 10	SEEK SIGN SWITCH
5860	*TEST 11	HEAD ALIGNMENT SUPPORT
5919	*TEST 12	HEAD SWITCHING
6037	*TEST 13	READ HEADER (PART 1)
	*TEST 14	READ HEADER (PART 2)



2806			.NLIST	CND,MD,ME
2807			.ENABL	ABS,AMA
2808			.=2000	
2809	002000		SVC	
2810			SVCTST=1	
2811	002000		SVCSUB=1	
2812		000001	SVCBGL=1	
2813		000001	SVCINS=0	
2814		000001	SVCTAG=0	
2815		000000	POINTER	BGNSW,BGNSFT,BGNDU
2816		000000		
2817	002000		BGNMOD	MDHEDR
2818			HEADER	DZRLC,A,0
2819	002000			.ASCII @0@
(S)	002000	104		.ASCII @Z@
(S)	002001	132		.ASCII @R@
(S)	002002	122		.ASCII @L@
(S)	002003	114		.ASCII @C@
(S)	002004	103		.BYTE 0
(S)	002005	000		.BYTE 0
(S)	002006	000		.BYTE 0
(S)	002007	000		.ASCII @A@
(F)	002010	101		.ASCII @0@
(F)	002011	060		.BYTE C\$REVISION
(F)	002012	001		.BYTE C\$EDIT
(W)	002013	006		.WORD 0
(F)	002014	000000		.WORD
(F)	002016	000000		.WORD
(F)	002020	000000		.WORD
(F)	002022	000000		.WORD
(F)	002024	000000		.WORD 0
(S)	002026	000000		.WORD 00
(F)	002030	000000		.WORD 00
(F)	002032	000000		.WORD 00
(F)	002034	000000		.WORD 00
(F)	002036	000000		.WORD 0
(F)	002040	014464		.WORD L\$DISPATCH
(F)	002042	014520		.WORD L\$INIT
(F)	002044	015466		.WORD L\$CLEAN
(F)	002046	031404		.WORD L\$HARD
(F)	002050	031530		.WORD L\$SOFT
(F)	002052	002104		.WORD L\$DVTYP
(F)	002054	000000		.WORD 0
(F)	002056	014432		.WORD L\$HW
(F)	002060	014446		.WORD L\$SW
(F)	002062	002102		.WORD L\$DR
(F)	002064	002102		.WORD L\$DRST
(F)	002066	000000		.WORD 0
(F)	002070	000000		.WORD 0
(F)	002072	015606		.WORD L\$DU
(F)	002074	000000		.WORD 0
(F)	002076	032004		.WORD L\$LAST
2800	002100		ENDMOD	DEVREG
(S)	002100			.WORD 0
(S)	002100	000000		.BLKW
(S)	002102	000001		







```

000010 HDALIGN =BIT03 ;EXECUTE HEAD ALIGNMENT TEST
000020 AUTOSZ =BIT04 ;AUTO SIZE FOR DRIVE-DROP IF NO RESPONSE
010000 HEADLM =BIT12 ;HEAD LIMIT SPECIFIED FLAG
020000 HICYL =BIT13 ;HI LIMIT SPECIFIED FLAG
040000 LOCYL =BIT14 ;LO LIMIT SPECIFIED
100000 MITEST =BIT15 ;EXECUTE MANUAL INTERVENTION TESTS

; SUBSYSTEM FUNCTIONS
000102 CKDATA =102 ;WRITE CHECK
000104 GTSTAT =104 ;GET STATUS
000106 SEEK =106 ;SEEK
000110 RDHEAD =110 ;READ HEADER
000112 WTDATA =112 ;WRITE DATA
000114 RDDATA =114 ;READ DATA
000116 RDNOHR =116 ;READ DATA, IGNORE HEADERS
000100 NOOP =100 ;NO OPERATION

; OPERATION FLAGS
007777 COMPOP =7777 ;COMPOSITE OPERATION FLAGS
000002 HDRCMP =BIT01 ;HEADER COMPARE OPERATION
000001 DATACMP =BIT00 ;DATA COMPARE OPERATION
000004 CYLUP =BIT02 ;CYCLE UP OPERATION
000010 ULOAD =BIT03 ;UNLOAD OPERATION
000020 INOUTS =BIT04 ;IN-OUT SEEK OPERATION
000040 OUTINS =BIT05 ;OUT-IN SEEK OPERATION
000100 FOLWRT =BIT06 ;FOLLOWING WRITE OPERATION
000200 REVSKS =BIT07 ;REV SEEK SEQ (ADJ INTERFERENCE)
000400 FWDSKS =BIT08 ;FWD SEEK SEQ (ADJ INTERFERENCE)
001000 REVSKO =BIT09 ;REV SEEK SEQ (OVERWRITE)
002000 FWDSKO =BIT10 ;FWD SEEK SEQ (OVERWRITE)
004000 BADADD =BIT11 ;BAD DISK ADDRESS
010000 SEEKOP =BIT12 ;SEEK OPERATION
020000 RORWOP =BIT13 ;READ OR WRITE OPERATION
040000 RELDWT =BIT14 ;RELOAD WAIT
100000 HDR40 =BIT15 ;40 HEADER OPERATION
003760 MQUALS =OUTINS!INOUTS!FOLWRT!REVSKS!FWDSKS!REVSKO!FWDSKO ;MESSAGE QUALIFIER BITS

; ERROR FLAGS FROM SUBROUTINES
000001 TOSLOW =BIT00 ;OPERATION TOOK TO LONG
000002 NOIRPT =BIT01 ;NO INTERRUPT FROM OPERATION
000004 CONHNG =BIT02 ;CONTROLLER HUNG
000010 NOCLR =BIT03 ;BAD CONTROLLER CLEAR

; CONTROL AND STATUS REGISTER
000000 RLCS =0 ;CONTROL AND STATUS REGISTER
000002 RLBA =2 ;BUS ADDRESS REGISTER
000004 RLDA =4 ;DISK ADDRESS REGISTER
000006 RLMP =6 ;MULTI-PURPOSE REGISTER

; REGISTER BIT DEFINITIONS - CONTROL STATUS REGISTER
000000 RLCSR =0 ;CONTROL AND STATUS REGISTER
100000 ANYERR =100000 ;ANY ERROR BIT
040000 DRVERR =40000 ;DRIVE ERROR BIT
020000 NXMERR =20000 ;NON-EXISTANT MEMORY ERROR
010000 DLTERR =10000 ;DATA LATE ERROR
010000 HNFERR =10000 ;HEADER NOT FOUND ERROR

```



2925	004000	DCKERR =4000	: DATA CHECK ERROR
2926	004000	HRCERR =4000	: HEADER CHECK ERROR
2927	002000	OPIERR =2000	: OPERATION INCOMPLETE ERROR
2928	001400	DSMSK =1400	: DRIVE SELECT MASK
2929	000200	CRDYMSK =200	: CONTROLLER READY MASK
2930	000100	INTEBL =100	: INTERRUPT ENABLE MASK
2931	000060	BAMSK =60	: BUS ADDRESS UPPER MASK
2932	000001	DRDYMSK =1	: DRIVE READY MASK
2933			
2934		: REGISTER BIT DEFINITIONS - DISK ADDRESS FOR DATA XFER	
2935	000077	SAMSK =77	: SECTOR ADDRESS MASK
2936	000100	HSMSK =100	: HEAD SELECT MASK
2937	077600	CAMSK =77600	: CYLINDER ADDRESS MASK
2938			
2939		: REGISTER BIT DEFINITIONS - DISK ADDRESS FOR SEEK	
2940	000001	MBSETO =1	: MUST BE SET, BIT 0
2941	000004	DIRBIT =4	: DIRECTION BIT
2942	000020	HDSEL =20	: HEAD SELECT BIT
2943	077600	DIRMSK =77600	: CYLINDER DIFFERENCE MASK
2944			
2945		: REGISTER BIT DEFINITIONS - DISK ADDRESS FOR GET STATUS	
2946	000003	GETSTAT =3	: GET STATUS SETUP
2947	000010	DRSET =10	: DRIVE RESET MASK
2948			
2949		: REGISTER BIT DEFINITIONS - MP FOR DATA XFER	
2950	017777	WCMSK =17777	: WORD COUNT MASK
2951	160000	WCRNG =160000	: WORD COUNT RANGE MASK
2952			
2953		: REGISTER BIT DEFINITIONS - MP FOR READ HEADER	
2954	077600	HDCYL =077600	: CYLINDER MASK
2955	000077	HDSEC =77	: SECTOR MASK
2956	000100	HDHSEL =100	: HEAD SELECT MASK
2957			
2958		: REGISTER BIT DEFINITIONS - MP FOR GET STATUS	
2959	000007	STAMSK =7	: STATE MASK
2960	000010	BHSTAT =10	: BRUSH HOME STATUS
2961	000020	HSTAT =20	: HEADS OUT STATUS
2962	000040	COSTAT =40	: COVER OPEN STATUS
2963	000100	HSSTAT =100	: HEAD SELECT STATUS
2964	000400	DSESTAT =400	: DRIVE SELECT ERROR STATUS
2965	001000	VCSTAT =1000	: VOLUME CHECK STATUS
2966	002000	WGSTAT =2000	: WRITE GATE ERROR STATUS
2967	004000	SPDSTAT =4000	: SPIN ERROR STATUS
2968	010000	STOSTAT =10000	: SEEK TIMEOUT ERROR STATUS
2969	020000	WLSTAT =20000	: WRITE LOCK STATUS
2970	040000	HCESTAT =40000	: HEAD CURRENT ERROR STATUS
2971	100000	WDESTAT =100000	: WRITE DATA ERROR STATUS
2972			
2973	002112	ENDMOD	
2974	002112	BGNMOD GLBDAT	
2975			
2976		: TABLE OF OPERATION MESSAGES	
2977	002112	OPMSG: .WORD 0	: FILLER
2978	002114	.WORD M.IRCHK	: MESSAGE FOR WRITE CHECK
2979	002116	.WORD MGTSTA	: GET STATUS
2980	002120	.WORD MSEEK	: SEEK

2981	002122	004555	.WORD	MREADH	:	READ HEADER
2982	002124	004606	.WORD	MWRITE	:	WRITE DATA
2983	002126	004542	.WORD	MREAD	:	READ DATA
2984	002130	004717	.WORD	MWRSET	:	WITH RESET
2985	002132	004636	.WORD	MDATCP	:	WITH DATA COMPARE
2986	002134	004661	.WORD	MHDRCP	:	WITH HEADER COMPARE
2987	002136	004774	.WORD	MCYLUP	:	LOAD HEADS
2988	002140	004763	.WORD	MULOAD	:	UNLOAD HEADS
2989	002142	005025	.WORD	MINOUT	:	IN-OUT SEQ
2990	002144	005004	.WORD	MOUTIN	:	OUT-IN SEQ
2991	002146	005050	.WORD	MFOLWRT	:	FOLLOWING WRITE
2992	002150	005074	.WORD	MREVSK	:	REV SEEK
2993	002152	005127	.WORD	MFWDSK	:	FWD SEEK
2994	002154	005216	.WORD	MRESKO	:	REV SEEK
2995	002156	005162	.WORD	MFWSKO	:	FWD SEEK
2996	002160	005252	.WORD	MBADAD	:	BAD DISK ADD FOR WRITE
2997	002162	004703	.WORD	M40HDR	:	40 HEADER OPERATION

2998						
2999						
3000	002164	010512	RESTBL:	TABLE OF RESULT NAME MESSAGE ADDRESSES		
3001	002166	010623	.WORD	MCERR	:	CONTROLLER ERROR
3002	002170	011150	.WORD	MDRERR	:	DRIVE ERROR
3003	002172	011122	.WORD	MNEERR	:	NON-EXISTANT MEMORY ERROR
3004	002174	011105	.WORD	MFLERR	:	HEADER NOT FOUND-DATA LATE
3005	002176	011066	.WORD	MHDERR	:	HEADER OR DATA ERROR
3006	002200	011175	.WORD	MOPERR	:	OPERATION INCOMPLETE
3007	002202	000000	.WORD	MNRST	:	NO DRIVE STATUS AVAILABLE
3008	002204	011051	.WORD	0		
3009	002206	011033	.WORD	MWDERR	:	WRITE DATA ERROR
3010	002210	000000	.WORD	MHCERR	:	HEAD CURRENT ERROR
3011	002212	011015	.WORD	0		
3012	002214	010762	.WORD	MSTERR	:	SEEK TIMEOUT ERROR
3013	002216	011000	.WORD	MSPERR	:	SPINDLE ERROR
3014	002220	000000	.WORD	MWGERR	:	WRITE GATE ERROR
3015	002222	010732	.WORD	0		
3016			.WORD	MDSERR	:	DRIVE SELECT ERROR

3017			PATTBL:	PATTERN TABLE		
3018	002224	004256	.WORD	PAT1		
3019	002226	004260	.WORD	PAT2		
3020	002230	004320	.WORD	PAT3		
3021	002232	004360	.WORD	PAT4		
3022	002234	004420	.WORD	PAT5		
3023	002236	004426	.WORD	PAT6		
3024	002240	004466	.WORD	PAT7		
3025	002242	004470	.WORD	PAT8		
3026	002244	004530	.WORD	PAT9		
3027	002246	004532	.WORD	PAT10		

3028						
3029						
3030			SUBSTK:	SUBROUTINE CALLING STACK		
3031	002250	000000	.WORD	0	:	STACK IS 12 WORDS LONG
3032	002252	000000	.WORD	0		
3033	002254	000000	.WORD	0		
3034	002256	000000	.WORD	0		
3035	002260	000000	.WORD	0		
3036	002262	000000	.WORD	0		



3037	002264	000000	.WORD	0
3038	002266	000000	.WORD	0
3039	002270	000000	.WORD	0
3040	002272	000000	.WORD	0
3041				
3042	002274	000002	T25TBL: .WORD	2
3043	002276	000006	.WORD	6
3044	002300	000011	.WORD	9
3045	002302	000014	.WORD	12
3046	002304	000021	.WORD	17
3047	002306	000026	.WORD	22
3048	002310	000033	.WORD	27
3049	002312	000042	.WORD	34
3050	002314	000051	.WORD	41
3051	002316	000200	.WORD	128
3052	002320	000377	.WORD	255
3053				
3054				
3055				
3056	002322	000010	T33TBL: .BLKW	10
3057				
3058	002342	002	CYLTBL: .BYTE	2
3059	002343	007	.BYTE	7
3060	002344	016	.BYTE	14
3061	002345	024	.BYTE	20
3062	002346	033	.BYTE	27
3063	002347	041	.BYTE	33
3064	002350	046	.BYTE	38
3065	002351	055	.BYTE	45
3066	002352	064	.BYTE	52
3067	002353	072	.BYTE	58
3068	002354	101	.BYTE	65
3069	002355	110	.BYTE	72
3070	002356	115	.BYTE	77
3071	002357	124	.BYTE	84
3072	002360	133	.BYTE	91
3073	002361	141	.BYTE	97
3074	002362	146	.BYTE	102
3075	002363	154	.BYTE	108
3076	002364	161	.BYTE	113
3077	002365	170	.BYTE	120
3078	002366	177	.BYTE	127
3079	002367	206	.BYTE	134
3080	002370	213	.BYTE	139
3081	002371	222	.BYTE	146
3082	002372	230	.BYTE	152
3083	002373	235	.BYTE	157
3084	002374	244	.BYTE	164
3085	002375	252	.BYTE	170
3086	002376	261	.BYTE	177
3087	002377	270	.BYTE	184
3088	002400	275	.BYTE	189
3089	002401	303	.BYTE	195
3090	002402	312	.BYTE	202
3091	002403	317	.BYTE	207
3092	002404	326	.BYTE	214

; TABLE OF DIFFERENCES TO BE USED  
; IN TEST 25

; TABLE TO BE USED IN TEST 33 AND 34 TO BUILD AND STORE THE  
CYLINDERS TO BE USED IN THE TEST.

; TABLE OF DEFAULT CYLINDERS

3093	002405	334	.BYTE	220.	
3094	002406	343	.BYTE	227.	
3095	002407	352	.BYTE	234.	
3096	002410	361	.BYTE	241.	
3097	002411	367	.BYTE	247.	
3098	002412	375	.BYTE	253.	
3099	002413	000	.BYTE	0	
3100					
3101	002414	000000	SSINDX: .WORD	0	;SUBROUTINE STACK INDEX POINTER
3102					
3103					
3104	002416	000000	OPFLAG: .WORD	0	;OPERATION FLAGS
3105	002420	000000	DONE: .WORD	0	;OPERATION COMPLETE FLAG
3106	002422	000000	HADONE: .WORD	0	;HEAD ALIGNMENT DONE FLAG
3107	002424	000000	ERHEAD: .WORD	0	;ADDRESS OF ERROR HEADER
3108	002426	000000	MORECE: .WORD	0	;MORE THAN 1 COMPARE ERROR
3109	002430	000000	ERRSWI: .WORD	0	;ERROR RETURN SWITCH
3110	002432	000000	BSFLAG: .WORD	0	;BAD SECTOR FLAGS
3111	002434	000000	WRTSWI: .WORD	0	;WRITE SWITCH
3112	002436	000000	TBLSTR: .WORD	0	;TABLE STORAGE
3113					
3114	002440	000000	RLBAS: .WORD	0	;RL11 BASE ADDRESS
3115	002442	000000	RLVEC: .WORD	0	;RL11 VECTOR ADDRESS
3116	002444	000000	RLDRV: .WORD	0	;DRIVE NUMBER UNDER TEST
3117					
3118	002446	000000	L.CS: .WORD	0	;CONTROLLER REGISTER STORAGE
3119	002450	000000	L.BA: .WORD	0	;BEFORE OPERATION
3120	002452	000000	L.DA: .WORD	0	
3121	002454	000000	L.MP: .WORD	0	
3122	002456	000000	T.CS: .WORD	0	;CONTROLLER REGISTER STORAGE
3123	002460	000000	T.BA: .WORD	0	; AFTER OPERATION
3124	002462	000000	T.DA: .WORD	0	
3125	002464		T.MP: .WORD	0	
3126	002464	000000	HDWRD1: .WORD	0	;HEADER WORD STORAGE
3127	002466	000000	HDWRD2: .WORD	0	
3128	002470	000000	HDWRD3: .WORD	0	
3129					
3130	002472	000000	T.STAT: .WORD	0	;DRIVE STATE STORAGE
3131					
3132	002474	000000	RESPARM: .WORD	0	;PARAM BLOCK-FOR REASON REPORT
3133	002476	000000	.WORD	0	
3134	002500	000000	.WORD	0	
3135	002502	000000	.WORD	0	
3136	002504	000000	.WORD	0	
3137					
3138	002506	000000	DRVCNT: .WORD	0	;DRIVE COUNT FOR DRIVES UNDER TEST
3139	002510	000000	DIFAUG: .WORD	0	;DIFFERENCE AUGMENT FOR SEEK
3140	002512	000000	OLDCYL: .WORD	0	;OLD CYLINDER
3141	002514	000000	NEWCYL: .WORD	0	;NEW CYLINDER
3142	002516	000000	CURCYL: .WORD	0	;CURRENT CYLINDER
3143	002520	000000	DESDIF: .WORD	0	;DESIRED DIFFERENCE
3144	002522	000000	DESSGN: .WORD	0	;DESIRED SIGN
3145	002524	000000	DESHD: .WORD	0	;DESIRED HEAD
3146	002526	000000	DESSEC: .WORD	0	;DESIRED SECTOR
3147	002530	000000	TEMPO: .WORD	0	;TEMPORARY STORAGE
3148	002532	000000	TEMP1: .WORD	0	;TEMPORARY STARGE



3149	002534	000000	TEMP2: .WORD	0	: TEMPORARY STORAGE
3150	002536	000000	TEMP3: .WORD	0	: TEMPORARY STORAGE
3151	002540	000000	TEMP4: .WORD	0	: TEMPORARY STORAGE
3152	002542	000000	TEMP5: .WORD	0	: TEMPORARY STORAGE
3153	002544	000000	TEMP6: .WORD	0	: TEMPORARY STORAGE
3154	002546	000000	TEMP7: .WORD	0	: TEMPORARY STORAGE
3155	002550	000000	TEMP8: .WORD	0	: TEMPORARY STORAGE
3156					
3157			: TIMER STORAGE		
3158	002552	000000	OFIN: .WORD	0	: ONE CYLINDER FORWARD INNER
3159	002554	000000	OFINU: .WORD	0	: UPPER
3160	002556	000000	OFMID: .WORD	0	: ONE CYLINDER FORWARD MIDDLE
3161	002560	000000	OFMIDU: .WORD	0	: UPPER
3162	002562	000000	OFOUT: .WORD	0	: ONE CYLINDER FORWARD OUTER
3163	002564	000000	OFOUTU: .WORD	0	: UPPER
3164	002566	000000	ORIN: .WORD	0	: ONE CYLINDER REVERSE INNER
3165	002570	000000	ORINU: .WORD	0	: UPPER
3166	002572	000000	ORMID: .WORD	0	: ONE CYLINDER REVERSE MIDDLE
3167	002574	000000	ORMIDU: .WORD	0	: UPPER
3168	002576	000000	OROUT: .WORD	0	: ONE CYLINDER REVERSE OUTER
3169	002600	000000	OROUTU: .WORD	0	: UPPER
3170	002602	000000	HFIN: .WORD	0	: 128 CYLINDER FORWARD INNER
3171	002604	000000	HFINU: .WORD	0	: UPPER
3172	002606	000000	HFOUT: .WORD	0	: 128 CYLINDER FORWARD OUTER
3173	002610	000000	HFOUTU: .WORD	0	: UPPER
3174	002612	000000	HRIN: .WORD	0	: 128 CYLINDER REVERSE INNER
3175	002614	000000	HRINU: .WORD	0	: UPPER
3176	002616	000000	HROUT: .WORD	0	: 128 CYLINDER REVERSE OUTER
3177	002620	000000	HROUTU: .WORD	0	: UPPER
3178	002622	000000	AFMID: .WORD	0	: 256 CYLINDER FORWARD
3179	002624	000000	AFMIDU: .WORD	0	: UPPER
3180	002626	000000	ARMID: .WORD	0	: 256 CYLINDER REVERSE
3181	002630	000000	ARMIDU: .WORD	0	: UPPER
3182					
3183	002632	000226	EXOCYL: .WORD	150.	: EXPECTED TIME ONE CYLINDER
3184	002634	001046	EXHCYL: .WORD	550.	: EXPECTED TIME 128 CYLINDER
3185	002636	001750	EXACYL: .WORD	1000.	: EXPECTED TIME 256 CYLINDER
3186	002640	000372	EXROT: .WORD	250.	: EXPECTED ROTATION TIME
3187	002642	000004	ERRVEC: .WORD	4	: ERROR VECTOR USED WHEN AUTO SIZING
3188					
3189			: MISCELLANEOUS COUNTERS		
3190	002644	000000	PASCNT: .WORD	0	: PASS COUNTER (LOCAL TO A TEST)
3191	002646	000000	COUNT: .WORD	0	: A COUNTER (LOCAL TO A TEST)
3192	002650	000000	ERRCNT: .WORD	0	: ERROR COUNTER FOR PROGRAM
3193	002652	000000	PASNUM: .WORD	0	: PASS NUMBER FOR PROGRAM
3194	002654	000000	PSETNM: .WORD	0	: COUNTER FOR PARAMETER SET NUMBER IN USE
3195	002656	000	LOCERR: .BYTE	0	: LOCAL ERROR COUNTER
3196	002657	000	NOERCT: .BYTE	0	: INHIBIT ERROR COUNTING FLAG
3197	002660	000000	TRPFLG: .WORD	0	: HARDWARE TRAP OCCURANCE
3198	002662	000000	PWRFLG: .WORD	0	: POWER FAILURE OCCURANCE
3199					
3200			: BAD SECTOR TABLES AND POINTERS		
3201	002664	000000	BSFVAL: .WORD	0	: BAD SECTORS FILES VALID FLAG
3202					
3203	002666	000076	SBSFIL: .BLKW	76	: SOFTWARE BAD SECTOR FILE
3204	003062	000076	FBSFIL: .BLKW	76	: FACTORY BAD SECTOR FILE



3205				
3206	003256	000200	IBUFF: .BLKW	200
3207	003656	000200	OBUFF: .BLKW	200
3208				
3209	004256	000000	PAT1: .WORD	0
3210	004260	177772	PAT2: .WORD	177772
3211	004262	177777	.WORD	177777
3212	004264	177777	.WORD	177777
3213	004266	052525	.WORD	052525
3214	004270	052525	.WORD	052525
3215	004272	052525	.WORD	052525
3216	004274	177777	.WORD	177777
3217	004276	177777	.WORD	177777
3218	004300	052525	.WORD	052525
3219	004302	052525	.WORD	052525
3220	004304	177777	.WORD	177777
3221	004306	052525	.WORD	052525
3222	004310	177252	.WORD	177252
3223	004312	177252	.WORD	177252
3224	004314	172765	.WORD	172765
3225	004316	172765	.WORD	172765
3226				
3227	004320	000003	PAT3: .WORD	000003
3228	004322	000000	.WORD	000000
3229	004324	000000	.WORD	000000
3230	004326	177777	.WORD	177777
3231	004330	177777	.WORD	177777
3232	004332	177777	.WORD	177777
3233	004334	000000	.WORD	000000
3234	004336	000000	.WORD	000000
3235	004340	177777	.WORD	177777
3236	004342	177777	.WORD	177777
3237	004344	000000	.WORD	000000
3238	004346	177777	.WORD	177777
3239	004350	000000	.WORD	000000
3240	004352	177777	.WORD	177777
3241	004354	000000	.WORD	000000
3242	004356	177777	.WORD	177777
3243				
3244	004360	025252	PAT4: .WORD	025252
3245	004362	052525	.WORD	052525
3246	004364	052525	.WORD	052525
3247	004366	125252	.WORD	125252
3248	004370	125252	.WORD	125252
3249	004372	125252	.WORD	125252
3250	004374	052525	.WORD	052525
3251	004376	052525	.WORD	052525
3252	004400	125252	.WORD	125252
3253	004402	125252	.WORD	125252
3254	004404	052525	.WORD	052525
3255	004406	125252	.WORD	125252
3256	004410	052525	.WORD	052525
3257	004412	125252	.WORD	125252
3258	004414	052525	.WORD	052525
3259	004416	125252	.WORD	125252
3260				

```

; INPUT BUFFER
; OUTPUT BUFFER
; PATTERN 1 (ALL ZEROS)

```



3261	004420	155555			PAT5:	.WORD	155555
3262	004422	133333				.WORD	133333
3263	004424	066666				.WORD	066666
3264							
3265	004426	121105			PAT6:	.WORD	121105
3266	004430	150442				.WORD	150442
3267	004432	064221				.WORD	064221
3268	004434	132110				.WORD	132110
3269	004436	055044				.WORD	055044
3270	004440	026442				.WORD	026442
3271	004442	013211				.WORD	013211
3272	004444	105504				.WORD	105504
3273	004446	042642				.WORD	042642
3274	004450	021321				.WORD	021321
3275	004452	110550				.WORD	110550
3276	004454	044264				.WORD	044264
3277	004456	022132				.WORD	022132
3278	004460	011055				.WORD	011055
3279	004462	104426				.WORD	104426
3280	004464	042213				.WORD	042213
3281							
3282	004466	177777			PAT7:	.WORD	177777
3283							
3284	004470	045513			PAT8:	.WORD	045513
3285	004472	122645				.WORD	122645
3286	004474	151322				.WORD	151322
3287	004476	064551				.WORD	064551
3288	004500	132264				.WORD	132264
3289	004502	055132				.WORD	055132
3290	004504	026455				.WORD	026455
3291	004506	113226				.WORD	113226
3292	004510	045513				.WORD	045513
3293	004512	122645				.WORD	122645
3294	004514	151322				.WORD	151322
3295	004516	064551				.WORD	064551
3296	004520	132264				.WORD	132264
3297	004522	055132				.WORD	055132
3298	004524	026455				.WORD	026455
3299	004526	113226				.WORD	113226
3300							
3301	004530	125252			PAT9:	.WORD	125252
3302							
3303	004532	155555			PAT10:	.WORD	155555
3304							
3305	004534				ENDMOD		
3306							
3310	004534				BGNMOD	GLBTXT	
3311	004534	042523	045505	000040	MSEEK:	.ASCIZ	/SEEK /
3312	004542	042522	042101	042040	MREAD:	.ASCIZ	/READ DATA /
3313	004555	122	040505	020104	MREADH:	.ASCIZ	/READ HEADER /
3314	004572	051127	052111	020105	MWRCHK:	.ASCIZ	/WRITE CHECK /
3315	004606	051127	052111	020105	MWRITE:	.ASCIZ	/WRITE DATA /
3316	004622	042507	020124	052123	MGTSTA:	.ASCIZ	/GET STATUS /
3317	004636	044527	044124	042040	MDATCP:	.ASCIZ	/WITH DATA COMPARE /
3318	004661	127	052111	020110	MHDRCP:	.ASCIZ	/WITH HDR COMPARE /
3319	004703	106	051117	032040	M40HDR:	.ASCIZ	/FOR 40 HDRS /

3320	004717	127	052111	020110	MWRSET:	.ASCIZ	/WITH RESET /
3321	004733	117	042520	040522	MOPER:	.ASCIZ	/OPERATION: /
3322	004747	122	051505	046125	MRSLT:	.ASCIZ	/RESULT: /
3323	004763	125	046116	020104	MULOAD:	.ASCIZ	/UNLD DRV/
3324	004774	042114	042040	053122	MCYLUP:	.ASCIZ	/LD DRV /
3325	005004	047506	020114	020060	MOUTIN:	.ASCIZ	/FOL 0 TO CC SEEK/
3326	005025	106	046117	031040	MINOUT:	.ASCIZ	/FOL 255 TO CC SEEK/
3327	005050	047506	020114	051127	MFOLWRT:	.ASCIZ	.ASCIZ /FOL WRITE (NO SEEK)/
3328	005074	042101	020112	054503	MREVSK:	.ASCIZ	/ADJ CYL WRTTN AFTER REV SK/
3329	005127	101	045104	041440	MFWSK:	.ASCIZ	/ADJ CYL WRTTN AFTER FWD SK/
3330	005162	045523	043040	042127	MFWSKO:	.ASCIZ	/SK FWD,WRT - SK REV,OVERWRT/
3331	005216	045523	051040	053105	MRESKO:	.ASCIZ	/SK REV,WRT - SK FWD,OVERWRT/
3332	005252	047117	041040	042101	MBADAD:	.ASCIZ	/ON BAD SEC FILES/
3333	005273	103	047101	052047	MBADSF:	.ASCIZ	/CAN'T GET BAD SEC FILES/
3334	005323	102	042101	051440	MFMTER:	.ASCIZ	/BAD SEC FILE FMT ERR/
3335	005350	047524	046440	047101	MTMBS:	.ASCIZ	/TO MANY BAD SEC FOR PROG CAPACITY/
3336	005412	052502	020123	042101	BASADD:	.ASCIZ	/BUS ADD=/
3337	005423	104	053122	000075	DRVNAM:	.ASCIZ	/DRV=/
3338	005430	051104	053111	020105	DRVNAV:	.ASCIZ	/DRIVE UNAVAILABLE FOR TEST/
3339	005463	104	053122	042040	NOFWR:	.ASCIZ	/DRV DID NOT REC'R FROM PWR FAIL/
3340	005523	122	041514	000123	CSNAM:	.ASCIZ	/RLCS/
3341	005530	046122	040502	000	BANAM:	.ASCIZ	/RLBA/
3342	005535	122	042114	000101	DANAM:	.ASCIZ	/RLDA/
3343	005542	046122	050115	000	MPNAM:	.ASCIZ	/RLMP/
3344	005547	117	020120	047111	LAB1:	.ASCIZ	/OP INIT = /
3345	005562	050117	042040	047117	LAB2:	.ASCIZ	/OP DONE = /
3346	005575	127	051117	020104	MWORD:	.ASCIZ	/WORD /
3347	005603	111	052116	050122	MTOSLOW:	.ASCIZ	.ASCIZ /INTRPT TO LATE/
3348	005622	050117	020111	042523	MDRRES:	.ASCIZ	/OPI SET-NO DRV RESPONSE/
3349	005652	047516	044440	052116	MNOINT:	.ASCIZ	/NO INTRPT ON CMND COMPLETE/
3350	005705	103	052116	051114	MCONHNG:	.ASCIZ	.ASCIZ /CNTLR HUNG (NO RDY)/
3351	005731	105	051122	042040	MNOCLR:	.ASCIZ	/ERR DID NOT CLR/
3352	005751	126	046117	041440	VCNSTR:	.ASCIZ	/VOL CHK NOT RSET/
3353	005772	047125	050130	052103	UNXERR:	.ASCIZ	/UNXPCTED ERR/
3354	006007	040	042524	052123	TSTLAB:	.ASCIZ	/TEST/
3356	006015	115	047101	044440	MISTST:	.ASCIZ	/MAN INTERVENT STAT/
3357	006040	052123	052101	020105	NSTACHG:	.ASCIZ	.ASCIZ /STATE CHG/
3358	006052	050123	042116	020114	SPDERR:	.ASCIZ	/SPNDL TIMEOUT FAILED TO SET/
3359	006106	040506	046111	043040	GSTER1:	.ASCIZ	/FAIL FORCING DRV SEL ERR/
3360	006137	111	044516	020124	INITST:	.ASCIZ	/INIT STATE/
3361	006152	051104	020126	042523	T05ERR:	.ASCIZ	/DRV SELECT/
3362	006165	104	053122	051040	T09ERR:	.ASCIZ	/DRV RDY/
3363	006175	123	042505	020113	T10ERR:	.ASCIZ	/SEEK SGN SWITCH/
3364	006215	110	020104	053523	T12ERR:	.ASCIZ	/HD SWITCH/
3365	006227	122	020104	042110	T13ERR:	.ASCIZ	/RD HDR (P1)/
3366	006243	122	020104	042110	T14ERR:	.ASCIZ	/RD HDR (P2)/
3367	006257	127	052122	046040	T16ERR:	.ASCIZ	/WRT LCK/
3369	006267				P2T01E:		
3370	006267	104	043111	020106	P2T02E:	.ASCIZ	/DIFF OF 1 SEEK/
3371	006306	052517	020124	051107	P2T03E:	.ASCIZ	/OUT GRD BAND DETECT/
3372	006332	047111	020103	042523	P2T04E:	.ASCIZ	/INC SEEK FWD HD 0/
3373	006354	047111	020103	042523	P2T05E:	.ASCIZ	/INC SEEK REV HD 0/
3374	006376	047111	020103	042523	P2T06E:	.ASCIZ	/INC SEEK FWD HD 1/
3375	006420	047111	020116	051107	P2T07E:	.ASCIZ	/INN GRD BAND DETECT/
3376	006444	047111	020103	042523	P2T08E:	.ASCIZ	/INC SEEK REV HD 1/
3377	006466	042523	045505	000	P2T09E:	.ASCIZ	/SEEK/



3378	006473	106	042127	047440	P2T10E:	.ASCIZ	/FWD OSC SEEK/
3379	006510	042522	020126	051517	P2T11E:	.ASCIZ	/REV OSC SEEK/
3380	006525	123	042505	020113	P2T12E:	.ASCIZ	/SEEK TIMING/
3381	006541	102	051501	041511	P2T13E:	.ASCIZ	/BASIC READ DATA/
3382	006561	127	052122	051057	P2T14E:	.ASCIZ	&WRT/READ DATA (P1)&
3383	006604	050123	047111	046104	P2T15E:	.ASCIZ	/SPINDLE ROTATION TIMING/
3384	006634	051127	027524	042522	P2T16E:	.ASCIZ	&WRT/READ DATA (P2)&
3385	006657	127	052122	046040	P2T17E:	.ASCIZ	/WRT LCK ERR AND DATA PROTECTION/
3386	006717	101	045104	041440	P2T18E:	.ASCIZ	/ADJ CYL INTERFERENCE/
3387	006744	053117	051105	051127	P2T19E:	.ASCIZ	/OVERWRITE/
3388	006756	042523	045505	052040	SKTMES:	.ASCIZ	/SEEK TIMES /
3389	006772	050123	047111	046104	SRTMES:	.ASCIZ	/SPINDLE ROTATION TIME /
3390	007021	050	052123	052101	VALDES:	.ASCIZ	/(STATED IN 100'S OF MICRO SEC)/
3391	007060	050101	051120	054117	MAPROX:	.ASCIZ	/APPROX /
3392	007070	047111	042516	000122	LABIN:	.ASCIZ	/INNER/
3393	007076	044515	042104	042514	LABMID:	.ASCIZ	/MIDDLE/
3394	007105	117	052125	051105	LABOUT:	.ASCIZ	/OUTER/
3395	007113	105	050130	041505	LABEXP:	.ASCIZ	/EXPECTED/
3396	007124	030060	020061	054503	LABOCF:	.ASCIZ	/001 CYL FWD/
3397	007140	030060	020061	054503	LABOCR:	.ASCIZ	/001 CYL REV/
3398	007154	031061	020070	054503	LABHCF:	.ASCIZ	/128 CYL FWD/
3399	007170	031061	020070	054503	LABHCR:	.ASCIZ	/128 CYL REV/
3400	007204	032462	020066	054503	LABACF:	.ASCIZ	/256 CYL FWD/
3401	007220	032462	020066	054503	LABACR:	.ASCIZ	/256 CYL REV/
3402	007234	042110	020123	040506	HDMOVF:	.ASCIZ	/HDS FAILED TO MOVE IN 10 TRIES/
3404	007273	103	046131	050040	CYLPER:	.ASCIZ	/CYL PORTION OF HDRS DIFFER WHEN READ FROM TRK 0 & 1/
3405	007357	110	040505	020104	HAMES1:	.ASCIZ	/HEAD ALIGN. RSET WRT LCK TO SEL HD 0, SET FOR HD 1/
3406	007442	054524	042520	021040	HAMES2:	.ASCIZ	/TYPE "CTL C" & "CONT" TO CONTINUE TESTING/
3407	007514	041101	053117	020105	OPR002:	.ASCIZ	/ABOVE CONDITIONS MET/
3408	007541	127	051501	046040	OPR003:	.ASCIZ	/WAS LOAD DEPRESSED/
3409	007564	044103	020113	051104	OPR1:	.ASCIZ	/CHK DRV IS UNLDED, COVER OPN, AND WRTE LCKED /
3410	007642	046103	042523	041440	OPR2:	.ASCIZ	/CLSE COVER & RST WRT LCK /
3411	007674	051120	051505	020123	OPR3:	.ASCIZ	/PRESS LOAD /
3412	007710	051120	051505	020123	OPR5:	.ASCIZ	/PRESS LOAD & WAIT FOR LOAD LIGHT /
3413	007752	051120	051505	020123	OPR6:	.ASCIZ	/PRESS LOAD & WAIT FOR RDY /
3414	010005	122	046505	053117	OPR7:	.ASCIZ	/REMOVE ADD PLGS EXCPT /
3415	010034	047111	051123	020124	OPR8:	.ASCIZ	/INSRT ADD PLG /
3416	010053	111	020116	046101	OPR9:	.ASCIZ	/IN ALL DRVS /
3417	010070	047111	052523	043106	OPR10:	.ASCIZ	/INSUFFICIENT DRVS FOR DRV SEL ERR TST/
3418	010136	050122	041514	020105	OPR11:	.ASCIZ	/RPLCE ADD PLGS AS BEFORE/
3420	010167	122	051505	052105	OPR12:	.ASCIZ	/RESET WRT LCK /
3421	010206	047117	000040		OPR1A:	.ASCIZ	/ON /
3422	010212	047117	042040	053122	OPR1B:	.ASCIZ	/ON DRV /
3423	010222	047125	042504	020122	UNDTST:	.ASCIZ	/UNDER TEST/
3424	010235	123	052105	053440	OPR004:	.ASCIZ	/SET WRT LCK /
3425	010252	044504	043106	000040	DIFWD:	.ASCIZ	/DIFF /
3426	010260	043523	020116	000	SGNWD:	.ASCIZ	/SGN /
3427	010265	110	020104	000	HDWD:	.ASCIZ	/HD /
3428	010271	123	041505	000040	SECWD:	.ASCIZ	/SEC /
3429	010276	054503	020114	000	CYLWD:	.ASCIZ	/CYL /
3430	010303	106	047522	020115	FRMWD:	.ASCIZ	/FROM /
3431	010311	040	054502	040520	BYPSNM:	.ASCIZ	/ BYPASSED /
3432	010324	047522	052125	047111	SEQMES:	.ASCIZ	/ROUTINE TRACE SEQ (IN SEQ CALLED):/
3433	010367	104	053122	051440	STAMES:	.ASCIZ	/DRV STAT/
3434	010400	040502	020104	042523	BSNSTR:	.ASCIZ	/BAD SEC FILES NOT STRD. ALL SEC ASSUMED GOOD./
3435	010456	047524	020124	047503	TCERR:	.ASCIZ	/TOT COMPARE ERRS: /





3496	011700	052045	052045	000	FMT1:	.ASCIZ	/%T%T/
3497	011705	045	022516	022524	FMT1.1:	.ASCIZ	/%N%T%T/
3498	011714	052045	000		FMT2:	.ASCIZ	/%T/
3499	011717	045	000116		FMT3:	.ASCIZ	/%N/
3500	011722	047045	052045	052045	FMT4:	.ASCIZ	/%N%T%T%N/
3501	011733	045	022516	022524	FMT5:	.ASCIZ	/%N%T%06%S1%T%01/
3502	011753	045	022516	030523	FMT6:	.ASCIZ	/%N%S11%T%54%T%54%T%54%T%52%T/
3503	012015	045	022516	022524	FMT7:	.ASCIZ	/%N%T%06%S2%06%S2%06%S2%06%S3%03%01%N/
3504	012065	045	022516	022524	FMT8:	.ASCIZ	/%N%T%06%S2%06%S2%06%S2%06/
3505	012117	045	022516	000124	FMT9:	.ASCIZ	/%N%T/
3506	012124	052045	047445	000061	FMT11:	.ASCIZ	/%T%01/
3507	012132	052045	047445	000063	FMT12:	.ASCIZ	/%T%03/
3508	012140	047045	051445	030461	FMT13:	.ASCIZ	/%N%S11%T%03%S1%T%03%S1%T%01%S1%T%01/
3509	012204	047045	052045	052045	FMT14:	.ASCIZ	/%N%T%T%D3%S1%T%06%S1%T%06/
3510	012236	047045	051445	030461	FMT15:	.ASCIZ	/%N%S11%T%D3%S1%T%06%S1%T%06/
3511	012272	047045	051445	022465	FMT16:	.ASCIZ	/%N%55%06/
3512	012303	045	030523	022460	FMT17:	.ASCIZ	/%S10%T%N%S11%06%N/
3513	012325	045	022516	030523	FMT18:	.ASCIZ	/%N%S13%T%55%T%54%T%55%T%N/
3514	012357	045	022524	031123	FMT19:	.ASCIZ	/%T%S2%D6%54%D6%54%D6%54%D6%N/
3515	012414	052045	051445	022462	FMT20:	.ASCIZ	/%T%S2%D6%54%D6%54%D6%54%D6%N/
3516	012444	052045	051445	031061	FMT21:	.ASCIZ	/%T%S12%D6%54%D6%N/
3517	012467	045	022516	030523	FMT22:	.ASCIZ	/%N%S11%T%03%S1%T%01%S1%T%02/
3518	012523	045	022524	022524	FMT23:	.ASCIZ	/%T%T%T%01%N/
3519	012537	045	022516	000124	FMT24:	.ASCIZ	/%N%T/
3520	012544	047045	042045	022462	FMT25:	.ASCIZ	/%N%D2%T/
3521	012554	047045	051445	022461	FMT26:	.ASCIZ	/%N%S1%T%D4%T%T%D3%N/
3522	012600	047045	052045	042045	FMT27:	.ASCIZ	/%N%T%D3%T%D3%N/
3523	012617	045	022516	022524	FMT28:	.ASCIZ	/%N%T%T%T/
3524	012630				ENDMOD		

3525	012630				BGNMOD	GLBERR	
3526					:	ERR1	R3 POINTS TO RESULT MESSAGE RESULT: (R3)
3527					:		
3528					:	ERR2	R3 POINTS TO RESULT NAME RESULT: (R3) IS 1 SB 0
3529					:		
3530					:	ERR3	R3 POINTS TO RESULT NAME RESULT: (R3) IS 0 SB 1
3531					:		
3532					:	ERR4	R3 POINTS TO RESULT NAME R4 POINTS TO RESULT CONDITIONS RESULT: (R3) IS 1 SB 0 (R4)
3533					:		
3534					:	ERR5	R3 POINTS TO RESULT NAME R4 POINTS TO RESULT CONDITIONS RESULT: (R3) IS 0 SB 1 (R4)
3535					:		
3536					:	ERR6	RESULT ROUTINE DETERMINES WHICH ERROR(S) ARE SET AND REPORTS ALL RESULT: "ERROR" IS 1 SB 0
3537					:		
3538					:	ERR7	DRIVE STATE ERROR REPORT R3 CONTAINS EXPECTED STATE T.STAT CONTAINS BAD STATE RESULT: DRIVE STATE IS (T.STAT) SB (R3)
3539					:		
3540					:		
3541					:		
3542					:		
3543					:		
3544					:		
3545					:		
3546					:		
3547					:		
3548					:		
3549					:		
3550					:		
3551					:		
3552					:		
3553					:		
3554					:		
3555					:		
3556					:		
3557					:		
3558					:		
3559					:		
3560					:		
3561					:		
3562					:		
3563					:		
3564					:		
3565					:		
3566					:		
3567					:		
3568					:		
3569					:		
3570					:		
3571					:		
3572					:		
3573					:		
3574					:		
3575					:		
3576					:		
3577					:		
3578					:		
3579					:		
3580					:		
3581					:		
3582					:		
3583					:		
3584					:		
3585					:		
3586					:		
3587					:		
3588					:		
3589					:		
3590					:		
3591					:		
3592					:		
3593					:		
3594					:		
3595					:		
3596					:		
3597					:		
3598					:		
3599					:		
3600					:		

```

3556 :
3557 :
3558 :
3559 :
3560 :
3561 :
3562 :
3563 :
3564 :
3565 :
3566 :
3567 :
3568 :
3569 :
3570 :
3571 :
3572 :
3573 :
3574 :
3575 :
3576 012630 105237 002657 BGNMSG ERR1
3577 012634 001002 TSTB NOERCT ;TEST IF ERROR COUNTING INHIBITED
3578 012636 005237 002650 BNE IS ;YES - SKIP
3579 012642 010146 INC ERRCNT ;ELSE BUMP ERROR COUNT
3580 012644 004737 021252 1S: MOV R1, -(SP) ;STORE R1
3581 012650 012721 000001 JSR PC, RPTOP ;REPORT OPERATION
3582 012654 010321 MOV #1, (R1)+ ;SET PARAM NUMBER
3583 012656 004737 022040 JSR PC, RPTRES ;INSERT MESSAGE ADDRESS POINTER
3584 012662 004737 022246 JSR PC, RPTREM ;REPORT RESULTS
3585 012666 012601 MOV (SP)+, R1 ;REPORT REMAINDER
3586 012670 004737 015656 JSR PC, CKERLM ;RESTORE R1
3587 012674 ;GO CHECK IF ERROR COUNT EXCEEDED
(3) 012674
(3) 012674 104023 ENDMSG
3588 L10000: EMT C$MSG
3589 012676 BGNMSG ERR2
3590 012676 005237 002650 INC ERRCNT ;BUMP ERROR COUNT
3591 012702 010146 MOV R1, -(SP) ;STORE R1
3592 012704 004737 021252 JSR PC, RPTOP ;REPORT OPERATION
3593 012710 012721 000003 MOV #3, (R1)+ ;SET PARAM NUMBER
3594 012714 010321 MOV R3, (R1)+ ;INSERT NAME ADD POINTER
3595 012716 012721 000001 MOV #1, (R1)+ ;SET IS VALUE
3596 012722 005021 CLR (R1)+ ;SET SB VALUE
3597 012724 004737 022040 JSR PC, RPTRES ;REPORT RESULTS
3598 012730 004737 022246 JSR PC, RPTREM ;REPORT REMAINDER
3599 012734 012601 MOV (SP)+, R1 ;RESTORE R1
3600 012736 004737 015656 JSR PC, CKERLM ;GO CHECK IF ERROR COUNT EXCEEDED
3601 012742
(3) 012742
(3) 012742 104023 ENDMSG
3602 L10001: EMT C$MSG
3603 012744 BGNMSG ERR3
3604 012744 005237 002650 INC ERRCNT ;BUMP ERROR COUNT
3605 012750 010146 MOV R1, -(SP) ;STORE R1
3606 012752 004737 021252 JSR PC, RPTOP ;REPORT OPERATION
3607 012756 012721 000003 MOV #3, (R1)+ ;SET PARAM NUMBER

```



3608	012762	010321		MOV	R3,(R1)+	::INSERT NAME ADD POINTER
3609	012764	005021		CLR	(R1)+	::SET IS VALUE
3610	012766	012721	000001	MOV	#1,(R1)+	::SET SB VALUE
3611	012772	004737	022040	JSR	PC,RPTRES	::REPORT RESULTS
3612	012776	004737	022246	JSR	PC,RPTREM	::REPORT REMAINDER
3613	013002	012601		MOV	(SP)+,R1	::RESTORE R1
3614	013004	004737	015656	JSR	PC,CKERLM	::GO CHECK IF ERROR COUNT EXCEEDED
3615	013010			ENDMSG		
(3)	013010			L10002:		
(3)	013010	104023		EMT	C\$MSG	
3616				BGNMSG	ERR4	
3617	013012			INC	ERRCNT	::BUMP ERROR COUNT
3618	013012	005237	002650	MOV	R1,-(SP)	::STORE R1
3619	013016	010146		JSR	PC,RPTOP	::REPORT OPERATION
3620	013020	004737	021252	MOV	#4,(R1)+	::SET PARAM NUMBER
3621	013024	012721	000004	MOV	R3,(R1)+	::INSERT NAME ADD POINTER
3622	013030	010321		MOV	#1,(R1)+	::SET IS VALUE
3623	013032	012721	000001	CLR	(R1)+	::SET SB VALUE
3624	013036	005021		MOV	R4,(R1)	::INSERT ADD OF CONDITION POINTER
3625	013040	010411		JSR	PC,RPTRES	::REPORT RESULTS
3626	013042	004737	022040	JSR	PC,RPTREM	::REPORT REMAINDER
3627	013046	004737	022246	MOV	(SP)+,R1	::RESTORE R1
3628	013052	012601		JSR	PC,CKERLM	::GO CHECK IF ERROR COUNT EXCEEDED
3629	013054	004737	015656			
3630	013060			ENDMSG		
(3)	013060			L10003:		
(3)	013060	104023		EMT	C\$MSG	
3631				BGNMSG	ERR5	
3632	013062			INC	ERRCNT	::BUMP ERROR COUNT
3633	013062	005237	002650	MOV	R1,-(SP)	::STORE R1
3634	013066	010146		JSR	PC,RPTOP	::REPORT OPERATION
3635	013070	004737	021252	MOV	#4,(R1)+	::SET PARAM NUMBER
3636	013074	012721	000004	MOV	R3,(R1)+	::INSERT NAME ADD POINTER
3637	013100	010321		CLR	(R1)+	::SET IS VALUE
3638	013102	005021		MOV	#1,(R1)+	::SET SB VALUE
3639	013104	012721	000001	MOV	R4,(R1)	::INSERT ADD OF CONDITION POINTER
3640	013110	010411		JSR	PC,RPTRES	::REPORT RESULTS
3641	013112	004737	022040	JSR	PC,RPTREM	::REPORT REMAINDER
3642	013116	004737	022246	MOV	(SP)+,R1	::RESTORE R1
3643	013122	012601		JSR	PC,CKERLM	::GO CHECK IF ERROR COUNT EXCEEDED
3644	013124	004737	015656			
3645	013130			ENDMSG		
(3)	013130			L10004:		
(3)	013130	104023		EMT	C\$MSG	
3646				BGNMSG	ERR6	
3647	013132			TSTB	NOERCT	::TEST IF ERROR COUNTING INHIBITED
3648	013132	105737	002657	BNE	17\$	::YES - SKIP
3649	013136	001002		INC	ERRCNT	::ELSE BUMP ERROR COUNT
3650	013140	005237	002650	MOV	R1,-(SP)	::STORE R1
3651	013144	010146		MOV	R3,-(SP)	::STORE R3
3652	013146	010346		MOV	R4,-(SP)	::STORE R4
3653	013150	010446		MOV	R5,-(SP)	::STORE R5
3654	013152	010546		JSR	PC,RPTOP	::REPORT OPERATION
3655	013154	004737	021252	MOV	#3,(R1)+	::SET PARAM NUMBER
3656	013160	012721	000003	MOV	#1,2(R1)	::INSERT IS VALUE
3657	013164	012761	000001 000002	MOV		

3658	013172	005037	002536		CLR	TEMP3	;CLEAR FOR STATUS STORAGE
3659	013176	013703	002456		MOV	T.CS,R3	;GET T.CS
3660	013202	042703	177761		BIC	#177761,R3	;AND CLEAR ALL BUT FUNCTION
3661	013206	022703	000004		CMP	#4,R3	;CHECK IF IT WAS GET STATUS
3662	013212	001432			BEQ	1\$	;YES - STATUS IS IN T.MP, SKIP
3663	013214	012762	000003	000004	MOV	#GETSTAT,RLDA(R2)	;ELSE DO GET STATUS
3664	013222	012703	000004		MOV	#4,R3	
3665	013226	053703	002444		BIS	RLDRV,R3	
3666	013232	010362	000000		MOV	R3,RLCS(R2)	
3667	013236				WAITUS	#10.	;WAIT FOR CONTROLLER READY
(3)	013236	012700	000012		MOV	#10.,R0	
(3)	013242	104027			EMT	CSWTU	
3668	013244	032762	000200	000000	BIT	#CRDYMSK,RLCS(R2)	;TEST IF READY
3669	013252	001003			BNE	10\$	;YES - SKIP
3670	013254	012703	001000	9\$:	MOV	#BIT9,R3	;ELSE SET NO DRIVE STATUS BIT
3671	013260	000413			BR	2\$	;IN MESSAGE WORD AND SKIP
3672	013262	016203	000006	10\$:	MOV	RLMP(R2),R3	;STORE STATUS FOR REPORT
3673	013266	010337	002536		MOV	R3,TEMP3	
3674	013272	113703	002537		MOVB	TEMP3+1,R3	;GET ERROR BITS IN PROPER POSITION
3675	013276	000402			BR	13\$	
3676	013300	113703	002465	1\$:	MOVB	T.MP+1,R3	;GET ERROR BITS FROM MP REG
3677	013304	042703	177442	13\$:	BIC	#177442,R3	;CLEAR UNUSED BITS
3678	013310	013704	002456	2\$:	MOV	T.CS,R4	;GET ERROR BITS FROM CS REG
3679	013314	042704	001777		BIC	#1777,R4	;CLEAR UNUSED BITS
3680	013320	050403			BIS	R4,R3	;MAKE ONE WORD OF POSSIBLE ERRORS
3681	013322	032703	002000		BIT	#OPIERR,R3	;TEST IF OPI SET
3682	013326	001442			BEQ	115\$	;NO - SKIP
3683	013330	032703	010000		BIT	#HNFERR,R3	;TEST IF HDR NOT FOUND ERROR
3684	013334	001026			BNE	107\$	;YES - SKIP
3685	013336	032703	004000		BIT	#HRCERR,R3	;TEST IF HDR CRC ERR
3686	013342	001020			BNE	105\$	;YES - SKIP
3687	013344	012704	011066		MOV	#MOPERR,R4	;SET OPI ALONE MESSAGE
3688	013350			100\$:	PRINTB	#FMT28,#MRSLT,R4,#MERRS	;REPORT ERROR
(10)	013350	012746	011424		MOV	#MERRS,-(SP)	
(9)	013354	010446			MOV	R4,-(SP)	
(8)	013356	012746	004747		MOV	#MRSLT,-(SP)	
(7)	013362	012746	012617		MOV	#FMT28,-(SP)	
(6)	013366	012746	000074		MOV	#4,-(SP)	
(3)	013372	010600			MOV	SP,R0	
(4)	013374	104014			EMT	CSPNTB	
(4)	013376	062706	000012		ADD	#12,SP	
3689	013402	000430			BR	120\$	;SKIP
3690	013404	012704	010524	105\$:	MOV	#MHCRC,R4	;HDR CRC MESSAGE
3691	013410	000757			BR	100\$	
3692	013412	032703	004000	107\$:	BIT	#HRCERR,R3	;TEST IF HCRC WITH HDR NOT FND
3693	013416	001003			BNE	109\$	;YES - SKIP
3694	013420	012704	010545		MOV	#MHNFR,R4	;MESSAGE HEADER NOT FOUND
3695	013424	000751			BR	100\$	
3696	013426	012704	010573	109\$:	MOV	#MHFCRC,R4	;HNF AND HCRC MESSAGE
3697	013432	000746			BR	100\$	;SKIP
3698	013434	032703	004000	115\$:	BIT	#DCKERR,R3	;TEST IF DATA CHECK SET, NOT OPI
3699	013440	001403			BEQ	118\$	;NO - SKIP
3700	013442	012704	010534		MOV	#MDCRC,R4	;SET MESSAGE DATA CHECK
3701	013446	000740			BR	100\$	;SKIP
3702	013450	032703	010000	118\$:	BIT	#DLTERR,R3	;TEST IF DATA LATE ERROR
3703	013454	001403			BEQ	120\$	;NO - SKIP



3704	013456	012704	010561		MOV	#MDLT,R4	:SET MESSAGE DATA LATE	
3705	013462	000732			BR	100\$	:SKIP	
3706	013464	012705	100000	120\$:	MOV	#BIT15,R5	:SET BIT POINTER FOR TEST	
3707	013470	005004			CLR	R4	:CLEAR R4 FOR TABLE COUNT	
3708	013472	030503		3\$:	BIT	R5,R3	:TEST IF BIT IS SET	
3709	013474	001005			BNE	6\$	:YES - SKIP TO REPORT	
3710	013476	005724		4\$:	TST	(R4)+	:ELSE BUMP TABLE POINTER	
3711	013500	000241			CLC		:CLEAR CARRY	
3712	013502	006005			ROR	R5	:SHIFT BIT POINTER TO NEXT BIT	
3713	013504	001372			BNE	3\$	:LOOP IF NOT 0	
3714	013506	000405			BR	7\$	:ELSE REPORT REMAINDER	
3715	013510	016411	002164	6\$:	MOV	RESTBL(R4),(R1)	:INSERT NAME ADDRESS	
3716	013514	004737	022040		JSR	PC,RPTRES	:REPORT RESULTS	
3717	013520	000766			BR	4\$	:GET NEXT BIT	
3718	013522	004737	022246	7\$:	JSR	PC,RPTREM	:REPORT REMAINDER	
3719	013526	005737	002536		TST	TEMP3	:TEST IF ANY NEW STATUS	
3720	013532	001414			BEQ	15\$	:NO - SKIP	
3721	013534				PRINTB	#FMT17,#STAMES,TEMP3		
(9)	013534	013746	002536		MOV	TEMP3,-(SP)		
(8)	013540	012746	010367		MOV	#STAMES,-(SP)		
(7)	013544	012746	012303		MOV	#FMT17,-(SP)		
(6)	013550	012746	000003		MOV	#3,-(SP)		
(3)	013554	010600			MOV	SP,R0		
(4)	013556	104014			EMT	C\$PNTB		
(4)	013560	062706	000010		ADD	#10,SP		
3722	013564	032737	004000	002456	15\$:	BIT	#DCKERR,T.CS	:TEST IF DATA CHECK ERROR
3723	013572	001453			BEQ	25\$	:NO - SKIP	
3724	013574	032737	002000	002456	BIT	#OPIERR,T.CS	:TEST IF OPI SET	
3725	013602	001047			BNE	25\$	:YES - SKIP	
3726	013604	005037	002426		CLR	MORECE	:CLEAR COMPARE ERROR COUNT	
3727	013610	012701	000200		MOV	#128,R1	:SET COMPARE LENGTH	
3728	013614	012703	000001		MOV	#1,R3	:SET WORD COUNT	
3729	013620	012705	003656		MOV	#OBUFF,R5	:SET GOOD WORD POINTER	
3730	013624	012704	003256		MOV	#IBUFF,R4	:SET TEST WORD POINTER	
3731	013630	021514		18\$:	CMP	(R5),(R4)	:CHECK WORD	
3732	013632	001427			BEQ	19\$	:GOOD - SKIP	
3733	013634	023727	002426	000012	CMP	MORECE,#10.	:TEST IF COMPARE LIMIT REACHED	
3734	013642	003021			BGT	20\$	:YES - SKIP	
3735	013644				PRINTB	#FMT15,#MWORD,R3,#RESE3,(R4),#RESE4,(R5)		
(13)	013644	011546			MOV	(R5)-{SP}		
(12)	013646	012746	011443		MOV	#RESE4,-(SP)		
(11)	013652	011446			MOV	(R4)-{SP}		
(10)	013654	012746	011437		MOV	#RESE3,-(SP)		
(9)	013660	010346			MOV	R3,-(SP)		
(8)	013662	012746	005575		MOV	#MWORD,-(SP)		
(7)	013666	012746	012236		MOV	#FMT15,-(SP)		
(6)	013672	012746	000007		MOV	#7,-(SP)		
(3)	013676	010600			MOV	SP,R0		
(4)	013700	104014			EMT	C\$PNTB		
(4)	013702	062706	000020		ADD	#20,SP		
3736	013706	005237	002426	20\$:	INC	MORECE	:BUMP ERROR COUNTER	
3737	013712	022524		19\$:	CMP	(R5)+,(R4)+	:BUMP POINTERS	
3738	013714	005203			INC	R3	:BUMP COUNTER	
3739	013716	005301			DEC	R1	:DEC LENGTH COUNT	
3740	013720	001343			BNE	18\$	:LOOP IF NOT DONE	
3741	013722	005737	002426	25\$:	TST	MORECE	:TEST IF ANY COMPARE ERRORS	

3742	013726	001421		BEG	27\$		:NO - SKIP
3743	013730	012701	000200	MOV	#128,R1		:SET COMPARE LENGTH
3744	013734			PRINTB	#FMT27,#TCERR,MORECE,#RESE6,R1		
(11)	013734	010146		MOV	R1,-(SP)		
(10)	013736	012746	011455	MOV	#RESE6,-(SP)		
(9)	013742	013746	002426	MOV	MORECE,-(SP)		
(8)	013746	012746	010456	MOV	#TCERR,-(SP)		
(7)	013752	012746	012600	MOV	#FMT27,-(SP)		
(6)	013756	012746	000005	MOV	#5,-(SP)		
(3)	013762	010600		MOV	SP,R0		
(4)	013764	104014		EMT	CSPNTB		
(4)	013766	062706	000014	ADD	#14,SP		
3745	013772	012605		27\$:	MOV (SP)+,R5		:RESTORE R5, 4, 3, 1
3746	013774	012604		MOV	(SP)+,R4		
3747	013776	012603		MOV	(SP)+,R3		
3748	014000	012601		MOV	(SP)+,R1		
3749	014002	004737	015656	JSR	PC,CKERLM		:GO CHECK IF ERROR COUNT EXCEEDED
3750	014006			ENDMSG			
(3)	014006			L10005:			
(3)	014006	104023		EMT	C\$MSG		
3751							
3752	014010			BGNMSG	ERR7		
3753	014010	005237	002650	INC	ERRCNT		:BUMP ERROR COUNT
3754	014014	010146		MOV	R1,-(SP)		:STORE R1
3755	014016	004737	021252	JSR	PC,RPTOP		:REPORT OPERATION
3756	014022	012721	000003	MOV	#3,(R1)+		:SET PARAM NUMBER
3757	014026	012721	010747	MOV	#MDRVST,(R1)+		:INSERT NAME ADD POINTER
3758	014032	013721	002472	MOV	T,STAT,(R1)+		:INSERT IS VALUE
3759	014036	010311		MOV	R3,(R1)+		:INSERT SB VALUE
3760	014040	004737	022040	JSR	PC,RPTRES		:REPORT RESULTS
3761	014044	004737	022246	JSR	PC,RPTREM		:REPORT REMAINDER
3762	014050	012601		MOV	(SP)+,R1		:RESTORE R1
3763	014052	004737	015656	JSR	PC,CKERLM		:GO CHECK IF ERROR COUNT EXCEEDED
3764	014056			ENDMSG			
(3)	014056			L10006:			
(3)	014056	104023		EMT	C\$MSG		
3765							
3766	014060			BGNMSG	ERR8		
3767	014060	005237	002650	INC	ERRCNT		:BUMP ERROR COUNT
3768	014064	010146		MOV	R1,-(SP)		:STORE R1
3769	014066	010346		MOV	R3,-(SP)		:STORE R3
3770	014070	004737	021252	JSR	PC,RPTOP		:REPORT OPERATION
3771	014074	012721	000003	MOV	#3,(R1)+		:SET PARAM NUMBER
3772	014100	012721	011170	MOV	#MCYLOC,(R1)+		:INSERT NAME ADD POINTER
3773	014104	013711	002464	MOV	HDWRD1,(R1)		:GET HEADER WORD
3774	014110	012703	000007	MOV	#7,R3		:SET SHIFT COUNT
3775	014114	000241		3\$:	CLC		
3776	014116	006011		ROR	(R1)		:ALIGN CHAR FOR PRINTING
3777	014120	005303		DEC	R3		:AS IS VALUE
3778	014122	001374		BNE	3\$		
3779	014124	005721		TST	(R1)+		:BUMP PARAM POINTER
3780	014126	013711	002514	MOV	NEWCYL,(R1)		:INSERT SB VALUE
3781	014132	004737	022040	JSR	PC,RPTRES		:REPORT RESULTS
3782	014136	004737	022246	JSR	PC,RPTREM		:REPORT REMAINDER
3783	014142	012603		MOV	(SP)+,R3		:RESTORE R3
3784	014144	012601		MOV	(SP)+,R1		:RESTORE R1



3785	014146	004737	015656		JSR	PC,CKERLM	;GO CHECK IF ERROR COUNT EXCEEDED
3786	014152			ENDMSG			
(3)	014152			L10007:			
(3)	014152	104023		EMT	C\$MSG		
3787							
3788	014154			BGNMSG	ERR9		
3789	014154	005237	002650	INC	ERRCNT		;BUMP ERROR COUNT
3790	014160	010146		MOV	R1,-(SP)		;STORE R1
3791	014162	004737	021252	JSR	PC,RPTOP		;REPORT OPERATION
3792	014166	012721	000003	MOV	#3,(R1)+		;SET PARAM NUMBER
3793	014172	010321		MOV	R3,(R1)+		;INSERT NAME ADD POINTER
3794	014174	010421		MOV	R4,(R1)+		;SET IS VALUE
3795	014176	010521		MOV	R5,(R1)+		;SET SB VALUE
3796	014200	004737	022040	JSR	PC,RPTRES		;REPORT RESULTS
3797	014204	004737	022246	JSR	PC,RPTREM		;REPORT REMAINDER
3798	014210	012601		MOV	(SP)+,R1		;RESTORE R1
3799	014212	004737	015656	JSR	PC,CKERLM		;GO CHECK IF ERROR COUNT EXCEEDED
3800	014216			ENDMSG			
(3)	014216			L10010:			
(3)	014216	104023		EMT	C\$MSG		
3801	014220			BGNMSG	ERR10		
3802	014220	010146		MOV	R1,-(SP)		;STORE R1
3803	014222	005737	002426	TST	MORECE		;TEST IF 2ND BAD LINE
3804	014226	001051		BNE	3\$		;YES - SKIP
3805	014230	005237	002650	INC	ERRCNT		;BUMP ERROR COUNT
3806	014234	004737	021252	JSR	PC,RPTOP		;REPORT OPERATION
3807	014240			PRINTB	#FMT5,#BASADD,RLBAS,#DRVNAM,<B,RLDRV+1>		;REPORT ID
(11)	014240	005046		CLR	-(SP)		
(11)	014242	153716	002445	BISB	RLDRV+1,(SP)		
(10)	014246	012746	005423	MOV	#DRVNAM,-(SP)		
(9)	014252	013746	002440	MOV	RLBAS,-(SP)		
(8)	014256	012746	005412	MOV	#BASADD,-(SP)		
(7)	014262	012746	011733	MOV	#FMT5,-(SP)		
(6)	014266	012746	000005	MOV	#5,-(SP)		
(3)	014272	010600		MOV	SP,R0		
(4)	014274	104014		EMT	C\$PNTB		
(4)	014276	062706	000014	ADD	#14,SP		
3808	014302			PRINTB	#FMT14,#MRSLT,#MWORD,R3,#RESE3,(R4),#RESE4,(R5)		
(14)	014302	011546		MOV	(R5)-,(SP)		
(13)	014304	012746	011443	MOV	#RESE4,-(SP)		
(12)	014310	011446		MOV	(R4)-,(SP)		
(11)	014312	012746	011437	MOV	#RESE3,-(SP)		
(10)	014316	010346		MOV	R3,-(SP)		
(9)	014320	012746	005575	MOV	#MWORD,-(SP)		
(8)	014324	012746	004747	MOV	#MRSLT,-(SP)		
(7)	014330	012746	012204	MOV	#FMT14,-(SP)		
(6)	014334	012746	000010	MOV	#10,-(SP)		
(3)	014340	010600		MOV	SP,R0		
(4)	014342	104014		EMT	C\$PNTB		
(4)	014344	062706	000022	ADD	#22,SP		
3809	014350	000421		BR	4\$		
3810	014352			3\$:	PRINTB	#FMT15,#MWORD,R3,#RESE3,(R4),#RESE4,(R5)	;REPORT DATA
(13)	014352	011546		MOV	(R5)-,(SP)		
(12)	014354	012746	011443	MOV	#RESE4,-(SP)		
(11)	014360	011446		MOV	(R4)-,(SP)		
(10)	014362	012746	011437	MOV	#RESE3,-(SP)		

```

(9) 014366 010346
(8) 014370 012746 005575
(7) 014374 012746 012236
(6) 014400 012746 000007
(3) 014404 010600
(4) 014406 104014
(4) 014410 062706 000020
3811 014414 005237 002426
3812 014420 012601
3813 014422 004737 015656
3814 014426
(3) 014426
(3) 014426 104023
3815 014430
3816
3817
3818 014430
3819 014430
(3) 014430 000005
3820 014432 174400
3821 014434 000330
3822 014436 000240
3823 014440 000000
3824 014442 000001
3825 014444
(3) 014444
3826 014444
3827
3828 014444
3829 014444
(3) 014444 000006
3830 014446 000000
3831
3832
3833
3834
3835
3836
3837
3838
3839 014450 000000
3840 014452 000377
3841 014454 000000
3842 014456 000024
3843 014460 000012
3844 014462
(3) 014462
3845 014462
3846
3847 014462
3849 014462
(4) 014462 000016
(6) 014464 022532
(6) 014466 023002
(6) 014470 023204
(6) 014472 024440

```

```

MOV R3, -(SP)
MOV #MWORD, -(SP)
MOV #FMT15, -(SP)
MOV #7, -(SP)
MOV SP, R0
EMT C$PNTB
ADD #20, SP
4$: INC MORECE ; INC COMPARE ERROR COUNT
MOV (SP)+, R1 ; RESTORE R1
JSR PC, CKERLM ; GO CHECK IF ERROR COUNT EXCEEDED

ENDMSG
L10011: EMT C$MSG
ENDMOD .EVEN
BGNMOD HPTCODE
BGNHW .WORD L10012-L$HW/2
        .WORD 174400 ; CSR BASE ADDRESS DEFAULT
        .WORD 330 ; VECTOR DEFAULT
        .WORD 240 ; PRIORITY DEFAULT
        .WORD 0 ; DRIVE NUMBER DEFAULT
        .WORD 1 ; RL11 CONTROLLER
ENDHW
L10012: ENDMOD
BGNMOD SPTCODE
BGNSW .WORD L10013-L$SW/2
MISWIW: .WORD 0 ; BIT 0 = USE ALL CYLINDERS
        ; BIT 1 = USE ALL SECTORS
        ; BIT 2 = EXECUTE DRIVE SELECT TEST
        ; BIT 3 = EXECUTE HEAD ALIGNMENT
        ; BIT 4 = DROP DRIVE IF NO RESPONSE
        ; BIT 12 = HEAD SELECT SUPPLIED FLAG
        ; BIT 13 = HILIMIT SPECIFIED FLAG
        ; BIT 14 = LO LIMIT SPECIFIED FLAG
        ; BIT 15 = DO MANUAL INTERVENTION

LOLIMW: .WORD 0
HILIMW: .WORD 255.
HEADW: .WORD 0
ERLIMW: .WORD 20. ; ERROR LIMIT
DCLIMW: .WORD 10. ; COMPARE ERROR LIMIT
ENDSW
L10013: ENDMOD
BGNMOD DSPCODE
DISPATCH .WORD 14
        .WORD 14
        .WORD T1
        .WORD T2
        .WORD T3
        .WORD T4

```



(6)	014474	025246			.WORD	T5	
(6)	014476	025652			.WORD	T6	
(6)	014500	026524			.WORD	T7	
(6)	014502	027036			.WORD	T8	
(6)	014504	027122			.WORD	T9	
(6)	014506	027422			.WORD	T10	
(6)	014510	027744			.WORD	T11	
(6)	014512	030376			.WORD	T12	
(6)	014514	030714			.WORD	T13	
(6)	014516	031126			.WORD	T14	
3854	014520				ENDMOD		
3855							
3856	014520				BGNMOD	INITCODE	
3857	014520				BGNINIT		
3858	014520				SETPRI	#340	
(3)	014520	012700	000340		MOV	#340,RO	
(3)	014524	104041			EMT	C\$SPRI	
3859	014526				MANUAL		;CHECK IF MANUAL INTERVENTION ALLOWED
(3)	014526	104051			EMT	C\$MANI	
3860	014530				B\$COMPLETE	1\$	;YES - SKIP
(2)	014530	103403			BCS	1\$	
3861	014532	042737	100014	014446	BIC	#MITEST!DRSELT!HDALIGN,MISWIW	;CLEAR ALL MANUAL INTERVENTION FLAGS
3862							
3863	014540	005037	002414		1\$: CLR	SSINDX	;CLEAR SUBROUTINE STACK INDEX
3864	014544				REDEF	#EF.PWR	;POWER FAILURE
(3)	014544	012700	000034		MOV	#EF.PWR,RO	
(3)	014550	104050			EMT	C\$REFG	
3865	014552				B\$COMPLETE	4\$	;NO, GO CHECK NEW PASS
(2)	014552	103004			BCC	4\$	
3866	014554	013737	002014	002662	MOV	LSUNIT,PWRFLG	;SET POWER FAIL FLAG
3867	014562	000513			BR	PWCON	;GO SERVICE POWER FAIL
3868	014564				4\$: REDEF	#EF.START	;CHECK IF START
(3)	014564	012700	000040		MOV	#EF.START,RO	
(3)	014570	104050			EMT	C\$REFG	
3869	014572				B\$COMPLETE	RESTART	;NO - SKIP
(2)	014572	103031			BCC	RESTART	
3870					:	ON START INITIALIZE TO START AT FIRST DRIVE, CLEAR INTERNAL	
3871					:	PASS COUNT, AND ERROR COUNT.	
3872	014574	013737	002014	002506	MOV	LSUNIT,DRVcnt	;SET UP UNIT COUNT
3873	014602	005037	002652		R\$TRT: CLR	PASNUM	;CLEAR PASS NUMBER
3874	014606	012737	177777	002654	MOV	#-1,PSETNM	;SET PARAM SELECT TO INITIAL VALUE
3875	014614	012737	177777	002422	MOV	#-1,HADONE	;PRESET HEAD ALIGN DONE FLAG
3876	014622	032737	020000	014446	BIT	#HICYL,MISWIW	;TEST IF HI LIMIT SET
3877	014630	001003			BNE	3\$	;YES - SKIP
3878	014632	012737	000377	014452	MOV	#377,HILIMW	;ELSE INIT HILIMIT
3879	014640	032737	040000	014446	3\$: BIT	#LOCYL,MISWIW	;TEST IF LO LIMIT SET
3880	014646	001002			BNE	5\$	;YES - SKIP
3881	014650	005037	014450		CLR	LOLIMW	;ELSE CLEAR LO LIMIT
3882	014654	000427			5\$: BR	SETDON	
3883	014656				RESTART:		
3884	014656				REDEF	#EF.RESTART	;CHECK IF RESTART
(3)	014656	012700	000037		MOV	#EF.RESTART,RO	
(3)	014662	104050			EMT	C\$REFG	
3885	014664				B\$COMPLETE	R\$TRT	;NO - SKIP
(2)	014664	103746			BCS	R\$TRT	
3886	014666				CONTINUE:		



```

3887 014666 012700 000036 READEF #EF.CONTINUE ;TEST IF CONTINUE
(3) 014666 104050 MOV #EF.CONTINUE,RO
(3) 014672 104050 EMT CSREFG
3888 014674 BCOMPLETE PWCON
(2) 014674 103446 BCS PWCON
3889 ; ON CONTINUE PICK UP UNIT LAST UNDER TEST
3890 014676 READEF #EF.NEW ;CHECK IF STARTING NEW PASS
(3) 014676 012700 000035 MOV #EF.NEW,RO
(3) 014702 104050 EMT CSREFG
3891 014704 BCOMPLETE PASNEW
(2) 014704 103403 BCS PASNEW
3892 014706 NXPAS:
3893 014706 005737 002506 TST DRVCNT ;TEST IF ALL UNITS CHECKED
3894 014712 001010 BNE SETDON ;NO - SKIP
3895 014714 005237 002652 PASNEW: INC PASNUM ;ELSE BUMP PASS COUNT
3896 014720 013737 002014 002506 MOV LSUNIT,DRVCNT ;GET ALL DRIVES
3897 014726 012737 177777 002654 MOV #-1,PSETNM ;SET PARAM SELECT TO INITIAL
3898 014734 005237 002654 SETDON: INC PSETNM ;NEXT SET OF PARAMETERS
3899 014740 005337 002506 DEC DRVCNT ;DOWN COUNT DRIVE TOTAL
3900 014744 013700 002654 MOV PSETNM,RO ;SET UP TO GET PARAMETERS
3901 014750 012702 002440 MOV #RLBAS,R2
3902 014754 GPHARD RO,R1
(3) 014754 104042 EMT CS$GPHRD
(3) 014756 010001 MOV RO,R1
3903 014760 BCOMPLETE 7$ ;SKIP IF GOOD PARAM
(2) 014760 103406 BCS 7$
3904 014762 005737 002662 TST PWRFLG ;RECENT POWER FAILURE
3905 014766 001747 BEQ NXPAS ;NO
3906 014770 005337 002662 DEC PWRFLG ;ACCOUNT FOR DRIVE
3907 014774 000744 BR NXPAS
3908 014776 012122 7$: MOV (R1)+,(R2)+ ;STORE PARAMETERS CSR
3909 015000 012122 MOV (R1)+,(R2)+ ; VECTOR
3910 015002 005721 TST (R1)+ ;BUMP PAST PRIORITY
3911 015004 012122 MOV (R1)+,(R2)+ ; DRIVE
3912 015006 005037 002650 CLR ERRCNT ;CLEAR OUT ERROR COUNT
3913 015012 PWCON: SETVEC RLVEC,#INTHLR,#340 ;SET UP VECTOR
(7) 015012 012746 000340 MOV #340,-(SP)
(6) 015016 012746 015620 MOV #INTHLR,-(SP)
(5) 015022 013746 002442 MOV RLVEC,-(SP)
(4) 015026 012746 000003 MOV #3,-(SP)
(3) 015032 104037 EMT CS$VEC
(2) 015034 062706 000010 ADD #10,SP
3914 015040 SETPRI #0 ;SET PRIORITY
(3) 015040 012700 000000 MOV #0,RO
(3) 015044 104041 EMT CS$PRI
3915 015046 013702 002440 MOV RLBAS,R2 ;SET RL BASE ADDRESS POINTER
3916
3917
3918
3919 ;
3920 ; CHECK IF DOING AUTO SIZE AND DROP DRIVE IF NOT READY AND
3921 015052 005737 002652 TST PASNUM ;TEST IF PASS 0
3922 015056 001135 BNE 22$ ;NO - SKIP
3923 015060 032737 000020 014446 BIT #AUTOSZ,MISWIW ;TEST IF DOING AUTO SIZE
3924 015066 001531 BEQ 22$ ;NO - SKIP
3925 ;CHECK IF UNIBUS ADDRESS IS THERE BEFORE WE CHECK DRIVE READY

```



3926	015070	005037	002660	CLR	TRPFLG	: TRAP OCCURANCE
3927	015074			SETVEC	ERRVEC, #TRPHAN, #340	: SET TRAP VECTOR
(7)	015074	012746	000340	MOV	#340, -(SP)	
(6)	015100	012746	015612	MOV	#TRPHAN, -(SP)	
(5)	015104	013746	002642	MOV	ERRVEC, -(SP)	
(4)	015110	012746	000003	MOV	#3, -(SP)	
(3)	015114	104037		EMT	C\$SVEC	
(2)	015116	062706	000010	ADD	#10, SP	
3928	015122	005762	000000	TST	RLCS(R2)	: ACCESS BUS
3929	015126	005737	002660	TST	TRPFLG	: TRAP OCCUR??
3930	015132	001032		BNE	SS	: YES, DON'T INVESTIGATE FURTHER
3931	015134	013705	002444	MOV	RLDRV, R5	: GET DRIVE NUMBER
3932	015140	052705	000200	BIS	#CRDYMSK, R5	: INSERT CONT READY
3933	015144	010562	000000	MOV	R5, RLCS(R2)	: LOAD IN-DRIVE NUMBER
3934	015150	032762	000001	BIT	#DRDYMSK, RLCS(R2)	: CHECK IF DRIVE IS READY
3935	015156	001072		BNE	20\$	: YES - GO DO TEST
3936	015160	012762	000003	MOV	#GETSTAT, RLDA(R2)	: ELSE INSERT GET STATUS
3937	015166	052705	000004	BIS	#4, R5	: LOAD R5 WITH GET STATUS FUNCTION
3938	015172	042705	000200	BIC	#CRDYMSK, R5	: CLEAR CONTROLLER READY
3939	015176	010562	000000	MOV	R5, RLCS(R2)	: LOAD CS REG
3940	015202			WAITMS	#4	: WAIT 4 MS
(3)	015202	012700	000004	MOV	#4, R0	
(3)	015206	104026		EMT	C\$WTM	
3941	015210	032762	002000	BIT	#OPIERR, RLCS(R2)	: TEST IF OPI SET
3942	015216	001452		BEQ	20\$	: NO - SKIP
3943	015220			SS:	CLAVEC	
(3)	015220	013700	002642	MOV	ERRVEC, R0	
(3)	015224	104036		EMT	C\$CVEC	
3944	015226			PRINTF	#FMT24, #DRVNAV	
(8)	015226	012746	005430	MOV	#DRVNAV, -(SP)	
(7)	015232	012746	012537	MOV	#FMT24, -(SP)	
(6)	015236	012746	000Q02	MOV	#2, -(SP)	
(3)	015242	010600		MOV	SP, R0	
(4)	015244	104017		EMT	C\$PNTF	
(4)	015246	062706	000006	ADD	#6, SP	
3945	015252			10\$:	PRINTF	#FMT5, #BASADD, RLBAS, #DRVNM, <B, RLDRV+1>
(11)	015252	005046		CLR	-(SP)	
(11)	015254	153716	002445	BISB	RLDRV+1, (SP)	
(10)	015260	012746	005423	MOV	#DRVNM, -(SP)	
(9)	015264	013746	002440	MOV	RLBAS, -(SP)	
(8)	015270	012746	005412	MOV	#BASADD, -(SP)	
(7)	015274	012746	011733	MOV	#FMT5, -(SP)	
(6)	015300	012746	000005	MOV	#5, -(SP)	
(3)	015304	010600		MOV	SP, R0	
(4)	015306	104017		EMT	C\$PNTF	
(4)	015310	062706	000014	ADD	#14, SP	
3946	015314			PRINTF	#FMT3	
(7)	015314	012746	011717	MOV	#FMT3, -(SP)	
(6)	015320	012746	000001	MOV	#1, -(SP)	
(3)	015324	010600		MOV	SP, R0	
(4)	015326	104017		EMT	C\$PNTF	
(4)	015330	062706	000004	ADD	#4, SP	
3947	015334			DODU	PSETNM	: DROP DRIVE
(3)	015334	013700	002654	MOV	PSETNM, R0	
(3)	015340	104053		EMT	C\$DODU	
3948	015342			DOCLN		

3949	(3)	015342	104044		20\$:	EMT	CSDCLN		
		015344				CLRVEC	ERRVEC		
	(3)	015344	013700	002642		MOV	ERRVEC,RO		
	(3)	015350	104036		22\$:	EMT	C\$CVEC		
3952		015352							
3953	(3)	015352	104051			MANUAL			; MANUAL INTERVENTION ALLOWED
	(3)	015352				EMT	C\$MANI		
3954	(2)	015354	103004			BNCOMPLETE		4\$	; NO
		015354				BCC	4\$		
3955		015356	005737	002652		TST	PASNUM		; YES, CHECK PASS NUMBER
3956		015362	001001			BNE	4\$		; NOT FIRST PASS, NEED DRIVE UP
3957		015364	000437			BR	8\$		; FIRST PASS, PROGRAM WILL INSTRUCT USER
3958									
3959									
3961									; CHECK IF POWER FAILURE WAIT IS NEEDED
3962									
3963		015366	005737	002662	4\$:	TST	PWRFLG		; NEEDED???
3964		015372	001434			BEG	8\$		; NO, SKIP
3965									
3966		015374	013705	002444		MOV	RLDRV,R5		; DRIVE SELECT
3967		015400	052705	000200		BIS	#CRDYMSK,R5		; SET CRDY
3968		015404	010562	000000		MOV	R5,RLCS(R2)		; SELECT DRIVE
3969		015410	012701	000074		MOV	#60,R1		; SIXTY SECOND TIMER
3970		015414	032762	000001	000000	9\$:	BIT	#DRDYMSK,RLCS(R2)	; DRIVE UP YET
3971		015422	001020			BNE	8\$		; YES START TEST
3972									
3973		015424				WAITMS	#10.		; WAIT A SECOND
	(3)	015424	012700	000012		MOV	#10.,RO		
	(3)	015430	104026			EMT	C\$WTM		
3974		015432	005301			DEC	R1		; SIXTY GONE BY
3975		015434	001367			BNE	9\$		; NO
3976		015436				PRINTF	#FMT24,#NOPWR		
	(8)	015436	012746	005463		MOV	#NOPWR,-(SP)		
	(7)	015442	012746	012537		MOV	#FMT24,-(SP)		
	(6)	015446	012746	000002		MOV	#2,-(SP)		
	(3)	015452	010600			MOV	SP,RO		
	(4)	015454	104017			EMT	C\$PNTF		
	(4)	015456	062706	000006		ADD	#6,SP		
3977		015462	000673			BR	10\$		
3978									
3979		015464			8\$:				
3980									
3981		015464				ENDINIT			
	(3)	015464				L10014:			
	(3)	015464	104011			EMT	C\$INIT		
3982		015466				ENDMOD			
3983									
3984		015466				BGNMOD	CLNCODE		
3985		015466				BGNCLN			
3986									
3987		015466				SETVEC	ERRVEC,#TRPHAN,#340		
	(7)	015466	012746	000340		MOV	#340,-(SP)		
	(6)	015472	012746	015612		MOV	#TRPHAN,-(SP)		
	(5)	015476	013746	002642		MOV	ERRVEC,-(SP)		
	(4)	015502	012746	000003		MOV	#3,-(SP)		



```

(3) 015506 104037          EMT      CSSVEC
(2) 015510 062706 000010  ADD      #10,SP
3988
3989 015514          SETPRI #7          ;SET PRORITY TO 7
(3) 015514 012700 000007  MOV      #7,RO
(3) 015520 104041          EMT      CSSPRI
3990 015522 032762 000200 000000 2$:  BIT      #CRDYMSK,RLCS(R2) ;TEST IF CONTROLLER READY
3991 015530 001407          BEQ      3$          ;NO LOOP UNTIL READY
3992 015532 053762 002444 000000  BIS      RLDRV,RLCS(R2) ;SET DRIVE NUMBER
3993 015540 032762 000001 000000  BIT      #DRDYMSK,RLCS(R2) ;TEST IF DRIVE BUSY
3994 015546 001003          BNE      5$          ;NO - SKIP
3995 015550          WAITMS #3          ;WAIT 300 MS
(3) 015550 012700 000003  MOV      #3,RO
(3) 015554 104026          EMT      CSWTM
3996 015556          CLRVEC  RLVEC          ;RELEASE VEC
(3) 015556 013700 002442  MOV      RLVEC,RO
(3) 015562 104036          EMT      CSCVEC
3997 015564 005737 002662  TST      PWRFLG ;PWR FAIL SET
3998 015570 001402          BEQ      7$          ;NO
3999 015572 005337 002662  DEC      PWRFLG
4000 015576          CLRVEC  ERRVEC
(3) 015576 013700 002642  MOV      ERRVEC,RO
(3) 015602 104036          EMT      CSCVEC
4001 015604          ENDCLN
(3) 015604          L10015:
(3) 015604 104012          EMT      CSCLEAN
4002
4003 015606          BGNDU
4004 015606 000240          NOP
4005 015610          ENDDU
(3) 015610          L10016:
(3) 015610 104055          EMT      CSDU
4006
4007 015612          ENDMOD
4008 015612          BGNMOD  GLBSUB
4009
4010 015612 005237 002660  TRPHAN: INC      TRPFLG
4011 015616 000002          RTI
4012
4013 015620          BGNSRV  INTHLR
4014 ;          INTERRUPT HANDLER. ABORTS WAIT TIMER AND STORES ALL RL11 REGS
4015 015620          ABORTWAIT
(3) 015620 104021          EMT      CSABRT
4016 015622 012237 002456  MOV      (R2)+,T.CS ;STORE RL REGISTERS
4017 015626 012237 002460  MOV      (R2)+,T.BA
4018 015632 012237 002462  MOV      (R2)+,T.DA
4019 015636 011237 002464  MOV      (R2),T.MP
4020 015642 012737 177777 002420  MOV      #-1,DONE ;SET DONE FLAG
4021 015650 013702 002440  MOV      RLBAS,R2 ;RESTORE R2
4022 015654          ENDSRV
(3) 015654          L10017:
(2) 015654 000002          RTI
4023
4024 ;          ERROR LIMIT CHECKING ROUTINE
4025 ;          DROPS DRIVE IF ERROR LIMIT EXCEEDED
4026 015656 023737 002650 014456 CKERLM: CMP      ERRCNT,ERLIMW ;TEST IF ERROR LIMIT EXCEEDED
    
```

4027	015664	002453			BLT	1\$		:NO - SKIP
4028	015666				INLOOP			:CHECK IF IN ERROR LOOP
(3)	015666	104020			EMT	C\$INLP		
4029	015670				BCOMplete	1\$		:YES - SKIP
(2)	015670	103451			BCS	1\$		
4030	015672				PRINTF	#FMT25,ERLIMW,#MEXERS		
(9)	015672	012746	011361		MOV	#MEXERS,-(SP)		
(8)	015676	013746	014456		MOV	ERLIMW,-(SP)		
(7)	015702	012746	012544		MOV	#FMT25,-(SP)		
(6)	015706	012746	000003		MOV	#3,-(SP)		
(3)	015712	010600			MOV	SP,RO		
(4)	015714	104017			EMT	C\$PNTF		
(4)	015716	062706	000010		ADD	#10,SP		
4031	015722				PRINTF	#FMT5,#BASADD,RLBAS,#DRVNAM,<B,RLDRV+1>		
(11)	015722	005046			CLR	-(SP)		
(11)	015724	153716	002445		BISB	RLDRV+1,(SP)		
(10)	015730	012746	005423		MOV	#DRVNAM,-(SP)		
(9)	015734	013746	002440		MOV	RLBAS,-(SP)		
(8)	015740	012746	005412		MOV	#BASADD,-(SP)		
(7)	015744	012746	011733		MOV	#FMT5,-(SP)		
(6)	015750	012746	000005		MOV	#5,-(SP)		
(3)	015754	010600			MOV	SP,RO		
(4)	015756	104017			EMT	C\$PNTF		
(4)	015760	062706	000014		ADD	#14,SP		
4032	015764				PRINTF	#FMT3		
(7)	015764	012746	011717		MOV	#FMT3,-(SP)		
(6)	015770	012746	000001		MOV	#1,-(SP)		
(3)	015774	010600			MOV	SP,RO		
(4)	015776	104017			EMT	C\$PNTF		
(4)	016000	062706	000004		ADD	#4,SP		
4033	016004				DODU	PSETNM		:DROP DRIVE
(3)	016004	013700	002654		MOV	PSETNM,RO		
(3)	016010	104053			EMT	CSDODU		
4034	016012				DOCLN			:GO TO CLEAN UP
(3)	016012	104044			EMT	CSDCLN		
4035	016014	000207			RTS	PC		
4036								
4037								
4038	016016	016237	000000	002456	:READRL:	READ AND STORE ALL RL11 REGISTERS		
4039	016024	016237	000002	002460	MOV	RLCSR(R2),T.CS		:GET CS REG
4040	016032	016237	000004	002462	MOV	RLBA(R2),T.BA		:GET BUS ADDRESS REG
4041	016040	016237	000006	002464	MOV	RLDA(R2),T.DA		:GET DISK ADDRESS
4042	016046	000207			MOV	RLMP(R2),T.MP		:GET MULTI-PURPOSE REG
4043					RTS	PC		:RETURN
4044								
4045	016050	011646			:WAITIN:	WAIT FOR CONTROLLER TIMEOUT TO FORCE INTERRUPT ROUTINE		
4046	016052	005066	000002		MOV	(SP),-(SP)		:MAKE ROOM FOR ERROR POINTER
4047	016056	032762	000200	000000	CLR	2(SP)		:CLEAR FOR POINTER
4048	016064	001420			BIT	#CRDYMSK,RLCSR(R2)		:TEST IF CONTROLLER READY
4049	016066	004737	016016		BEQ	4\$		:NO - SKIP TO WAIT
4050	016072	005737	002420		JSR	PC,READRL		:READ ALL RL REGS
4051	016076	001433			TST	DONE		:TEST IF INTERRUPT OCCURRED
4052	016100	012766	005603	000002	BEQ	5\$		:NO - GO SET NO INTERRUPT ERR FLAG
4053	016106	032737	002000	002456	1\$:	MOV	#MTOSLOW,2(SP)	:ELSE SET TO SLOW ERROR POINTER
4054	016114	001403			BIT	#OPIERR,T.CS		:TEST IF OPI SET
4055	016116	012766	005622	000002	BEQ	2\$		:NO - SKIP
					MOV	#MDRES,2(SP)		:SET MESSAGE FOR NO DRIVE RESPONSE



H05

```

4056 016124 000207          2$:   RTS          PC          ;RETURN
4057 016126          4$:   WAITMS      #3          ;WAIT 300 MS FOR TIMEOUT
(3) 016126 012700 000003      MOV          #3,RO
(3) 016132 104026          EMT          CSWTM
4058 016134 032762 000200 000000  BIT          #CRDYMSK,RLCS(R2) ;TEST IF READY NOW SET
4059 016142 001006          BNE          3$          ;YES - SKIP
4060 016144 004737 016016          JSR          PC,READRL ;READ RL REGS
4061 016150 012766 005705 000002  MOV          #MCONHNG,2(SP) ;SET MESSAGE FOR CONTROLLER HUNG
4062 016156 000762          BR           2$          ;SKIP
4063 016160 005737 002420          3$:   TST          DONE ;ELSE CHECK IF INTERRUPT OCCURRED
4064 016164 001345          BNE          1$          ;YES - SKIP TO SET TO SLOW
4065 016166 004737 016016          5$:   JSR          PC,READRL ;READ RL REGS
4066 016172 012766 005652 000002  MOV          #MNOINT,2(SP) ;ELSE SET NO INTERRUPT FLAG
4067 016200 000751          BR           2$          ;GO TO RETURN
4068
4069
4070 016202 005037 002416          ;TSTINT: OPERATION AND TEST INITIALIZE ROUTINE
4071 016206 105037 002657          CLR          OPFLAG ;CLEAR OPERATION FLAGS
4072 016212 005037 002426          CLR          NOERCT ;RESET INHIBIT ERROR COUNTING
4073 016216 000207          CLR          MORECE ;RESET MORE COMPARE ERRORS
4074
4075
4076 016220 013746 002540          ;GSTATR: GET STATUS AND GET STATUS WITH RESET ROUTINE
4077 016224 012737 000013 002540  MOV          TEMP4,-(SP) ;STORE TEMP4
4078 016232 000412          MOV          #GSTAT!DRSET,TEMP4 ;SET FOR RESET
4079 016234 013746 002540          BR           GSTATG
4080 016240 012737 000003 002540  GSTATC: MOV          TEMP4,-(SP) ;STORE TEMP4
4081 016246 000404          MOV          #GSTAT,TEMP4 ;SET FOR NO RESET
4082 016250 013746 002540          BR           GSTATG
4083 016254 005037 002540          GSTAT:  MOV          TEMP4,-(SP) ;STORE TEMP4
4084 016260 010346          CLR          TEMP4 ;SET FOR SAVE L. AND T. REGS
4085 016262 013703 002414          GSTATG: MOV          R3,-(SP) ;STORE R3
4086 016266 005723          MOV          SSINDX,R3 ;GET SUBROUTINE INDEX
4087 016270 016663 000004 002250  TST          (R3)+ ;BUMP IT FOR NEXT ENTRY
4088 016276 162763 000004 002250  MOV          4(SP),SUBSTK(R3) ;INSERT THIS CALL
4089 016304 010337 002414          SUB          #4,SUBSTK(R3) ;ADJUST IT TO CALLING LOCATION
4090 016310 010046          MOV          R3,SSINDX ;STORE IT BACK
4091 016312 010146          MOV          R0,-(SP) ;STORE R0
4092 016314 012737 000002 002430  MOV          R1,-(SP) ;STORE R1
4093 016322 032737 000010 002540  MOV          #2,ERRSWI ;SET FOR NO ERROR RETURN
4094 016330 001453          BIT          #DRSET,TEMP4 ;TEST IF DRIVE RESET
4095 016332 032762 040000 000000  BEQ          11$ ;NO - SKIP
4096 016340 001403          BIT          #DRVERR,RLCS(R2) ;TEST IF DRIVE ERROR SET
4097 016342          BEQ          49$ ;NO - SKIP
(3) 016342 012700 000003      WAITMS      #3          ;WAIT FOR 300 MS FOR DRIVE TO SETTLE
(3) 016346 104026          MOV          #3,RO
4098 016350 012701 000062          EMT          CSWTM
4099 016354 004737 016250          49$:  MOV          #50,R1 ;SET WAIT FOR 5 SEC
1100 016360 017014          50$:  JSR          PC,GSTAT ;GET DRIVE STATUS
1101 016362 032737 000001 002456  3$:   BIT          #DRDYMSK,T.CS ;TEST IF DRIVE READY
1102 016370 001051          BNE          5$          ;YES - GO DO CLEAR
1103 016372 032737 000020 002464  BIT          #HOSTAT,T.MP ;ELSE TEST IF HEADS OUT
1104 016400 001010          BNE          51$ ;YES - BYPASS RELOAD WAIT FLAG SETTING
1105 016402 032737 144000 002464  BIT          #SPDSTAT!HCESTAT!WDESTAT,T.MP ;TEST IF DRIVE HAS ERROR
1106
1107

```

4108	016410	001441			BEG	5\$	NO - SKIP
4109	016412	052737	040000	002416	BIS	#RELDWT,OPFLAG	ELSE SET WAIT FLAG
4110	016420	000435			BR	5\$	SKIP TO CLEAR
4111	016422	032737	040000	002456	51\$: BIT	#DRVERR,T.CS	TEST IF DRIVE ERROR NOW
4112	016430	001031			BNE	5\$	YES - SKIP TO CLEAR
4113	016432				WAITMS	#1	WAIT FOR DRIVE TO GET ERROR, RDY, OR HO
(3)	016432	012700	000001		MOV	#1,R0	
(3)	016436	104026			EMT	CSWTM	
4114	016440	005301			DEC	R1	DEC WAIT COUNTER
4115	016442	001344			BNE	50\$	IF NOT DONE, LOOP
4116	016444	012703	011235		MOV	#MUNDEF,R3	MESSAGE FOR UNDEFINED STATE
4117	016450				ERRHRD	10001,ERR1	
(3)	016450	104443			TRAP	T\$ERRCODE	
(5)	016452	023421			.WORD	10001	
(5)	016454	012630			.WORD	ERR1	
4118	016456	000554			BR	14\$	EXIT
4119	016460	005737	002540		TST	TEMP4	TEST IF SAVE REGISTERS
4120	016464	001013			BNE	5\$	NO SKIP
4121	016466	012701	000004		MOV	#4,R1	SET SAVE COUNT
4122	016472	012703	002456		MOV	#L,MP+2,R3	SET ADDRESS OF FIRST SAVE
4123	016476	014346			8\$: MOV	-(R3),-(SP)	PUT REG ON STACK
4124	016500	005301			DEC	R1	DEC COUNT
4125	016502	001375			BNE	8\$	LOOP UNTIL ALL SAVED
4126	016504	012737	000003	002452	MOV	#GETSTAT,L.DA	SET FOR GET STATUS
4127	016512	000403			BR	6\$	SKIP
4128	016514	013737	002540	002452	5\$: MOV	TEMP4,L.DA	INSERT PRESET FOR STATUS
4129	016522				6\$: CLR	DONE	CLEAR INTERRUPT FLAG
4130	016522	005037	002420		MOV	RLDRV,L.CS	SET UP TO GET STATUS
4131	016526	013737	002444	002446	BIC	#BIT10,L.CS	CLEAR FOR DRIVE 4 - 7 SPEC'D
4132	016534	042737	002000	002446	BIS	#GTSTAT,L.CS	
4133	016542	052737	000104	002446	MOV	L.DA,RLDA(R2)	LOAD RL REGS
4134	016550	013762	002452	000004	MOV	L.CS,RLCSR(R2)	LOAD CS REG
4135	016556	013762	002446	000000	WAITUS	#1	WAIT 100 US FOR INTERRUPT
(3)	016564	012700	000001		MOV	#1,R0	
(3)	016570	104027			EMT	CSWTM	
4137	016572	005737	002420		TST	DONE	CHECK IF INTERRUPT OCCURRED
4138	016576	001476			BEG	1\$	NO - SKIP
4139	016600	013737	002464	002472	4\$: MOV	T.MP,T.STAT	STORE MP REGISTER
4140	016606	042737	177770	002472	BIC	#1C<STATMSK>,T.STAT	CLEAR ALL BUT STATE
4141	016614	032737	000010	002452	BIT	#DRSET,L.DA	TEST IF RESET WAS SPECIFIED
4142	016622	001474			BEG	3\$	NO - SKIP TO EXIT
4143	016624	032737	040000	002416	BIT	#RELDWT,OPFLAG	TEST IF RELOAD WAIT FLAG SET
4144	016632	001424			BEG	12\$	NO - SKIP
4145	016634	012701	001130		MOV	#600,R1	SET WAIT COUNT FOR 60 SECONDS
4146	016640	032762	000001	000000	13\$: BIT	#DRDYMSK,RLCS(R2)	TEST IF DRIVE NOW READY
4147	016646	001016			BNE	12\$	YES - SKIP
4148	016650				WAITMS	#1	CALL WAIT
(3)	016650	012700	000001		MOV	#1,R0	
(3)	016654	104026			EMT	CSWTM	
4149	016656	005301			DEC	R1	DEC COUNT
4150	016660	001367			BNE	13\$	LOOP IF NOT 0
4151	016662	004737	016250		JSR	PC,GSTAT	GET DRIVE STATUS
4152	016666	017014			3\$		ERROR RETURN
4153	016670	012703	011302		MOV	#MRLFAL,R3	SET RESULT MESSAGE POINTER
4154	016674				ERRHRD	10003,ERR1	



(3)	016674	104443			TRAP	T\$ERCODE	
(5)	016676	023423			.WORD	10003	
(5)	016700	012630			.WORD	ERR1	
4155	016702	000442			BR	14\$	:GO TO EXIT
4156	016704			12\$:	WAITUS	#10.	:WAIT FOR IMS
(3)	016704	012700	000012		MOV	#10.,R0	
(3)	016710	104027			EMT	CSWTU	
4157	016712	004737	016250		JSR	PC,GSTAT	:GET DRIVE STATUS
4158	016716	017014			3\$		
4159	016720	032737	100000	002456	BIT	#ANYERR,T.CS	:TEST IF ANY ERROR
4160	016726	001432			BEQ	3\$	:NO - SKIP
4161	016730	032737	001000	002464	BIT	#VCSTAT,T.MP	:CHECK IF VOLUME CHECK RESET
4162	016736	001403			BEQ	7\$	:YES SKIP
4163	016740	012703	005751		MOV	#VCNRST,R3	:SET REASON POINTER
4164	016744	000416			BR	2\$	:EXIT
4165	016746	032737	040000	002456	7\$:	BIT	#DRVERR,T.CS
4166	016754	001404			BEQ	9\$	:CHECK IF DRIVE ERROR
4167	016756				ERRHRD	10004,ERR6	:NO - SKIP
(3)	016756	104443			TRAP	T\$ERCODE	
(5)	016760	023424			.WORD	10004	
(5)	016762	013132			.WORD	ERR6	
4168	016764	000411			BR	14\$	:EXIT
4169	016766	012703	005772		9\$:	MOV	#UNXERR,R3
4170	016772	000403			BR	2\$	:SET REASON POINTER
4171	016774	004737	016050		1\$:	JSR	PC,WAITIN
4172	017000	012603			MOV	(SP)+,R3	:EXIT
4173	017002				2\$:	ERRHRD	:WAIT FOR INTERRUPT
(3)	017002	104443			TRAP	10002,ERR1	:STORE REASON POINTER FOR RETURN
(5)	017004	023422			.WORD	T\$ERCODE	
(5)	017006	012630			.WORD	10002	
4174	017010	005037	002430		14\$:	CLR	ERRSWI
4175	017014	005737	002540		3\$:	TST	TEMP4
4176	017020	001007			BNE	22\$	:CLEAR FOR ERROR RETURN
4177	017022	012703	002446		MOV	#L.CS,R3	:TEST IF REGISTERS WERE SAVED
4178	017026	012701	000004		MOV	#4,R1	:NO - SKIP
4179	017032	012623			20\$:	MOV	:SET POINTER TO RESTORE
4180	017034	005301			DEC	R1	:SET REGISTER COUNT
4181	017036	001375			BNE	20\$	:RESTORE REG
4182	017040	162737	000002	002414	22\$:	SUB	:DEC COUNT
4183	017046	012601			MOV	(SP)+,R1	:LCJP UNTIL ALL ARE RESTORED
4184	017050	012600			MOV	(SP)+,R0	:REMOVE ENTRY FROM SUBROUT STACK
4185	017052	012603			MOV	(SP)+,R3	:RESTORE R1
4186	017054	012637	002540		MOV	(SP)+,TEMP4	:RESTORE R3
4187	017060	005737	002430		TST	ERRSWI	:RESTORE TEMP4
4188	017064	001403			BEQ	99\$	:TEST IF ERROR RETURN
4189	017066	063716	002430		ADD	ERRSWI,(SP)	:YES - SKIP
4190	017072	000207			RTS	PC	:ADD IN ERROR RETURN
4191	017074	017616	000000		99\$:	MOV	@(SP),(SP)
4192	017100	000207			RTS	PC	:SET ERROR RETURN ADDRESS
4193							
4194							
4293	017102	010346			SIMSEK:	MOV	R3, -(SP)
4294	017104	013703	002414		MOV	SSINDX,R3	:STORE REGISTERS
4295	017110	005723			TST	(R3)+	:GET SUBROUTINE INDEX
4296	017112	016663	000002	002250	MOV	2(SP),SUBSTK(R3)	:BUMP IT FOR NEXT ENTRY
4297	017120	162763	000004	002250	SUB	#4,SUBSTK(R3)	:INSERT THIS CALL
							:ADJUST IT TO CALLING LOCATION

```

4298 017126 010337 002414      MOV      R3,SSINDX      ;STORE IT BACK
4299 017132 010046      MOV      R0,-(SP)
4300 017134 010446      MOV      R4,-(SP)
4301 017136 012737 000002 002430      MOV      #2,ERRSWI      ;SET FOR NO ERROR RETURN
4302 017144 004737 017366      JSR      PC,RDYCHK      ;CHECK IF DRIVE READY
4303 017150 017330      #65$
4304 017152 012704 002446      MOV      #L.CS,R4      ;GET POINTER TO L REGS
4305 017156 012714 000106      MOV      #SEEK,(R4)     ;SET FOR SEEK
4306 017162 053714 002444      BIS      RLDRV,(R4)     ;INSERT DRIVE NUMBER
4307 017166 042724 002000      BIC      #BIT10,(R4)+   ;CLEAR FOR DRIVE 4 - 7 SPEC'D
4308 017172 005024      CLR      (R4)+         ;CLEAR BUS ADDRESS
4309 017174 013714 002520      MOV      DESDIF,(R4)   ;LOAD DIFFERENCE
4310 017200 012703 000007      MOV      #7,R3        ;SET COUNT FOR SHIFT TO ALIGN
4311 017204 006314      3$:      ASL      (R4)         ;ALIGN DIFFERENCE IN DA
4312 017206 005303      DEC      R3
4313 017210 001375      BNE      3$
4314 017212 005737 002522      TST      DESSGN        ;TEST IF SIGN SET
4315 017216 001402      BEQ      5$           ;NO - SKIP
4316 017220 052714 000004      RIS      #DIRBIT,(R4)  ;INSERT SIGN
4317 017224 005737 002524      5$:      TST      DESHD        ;TEST IF HEAD 0
4318 017230 001402      BEQ      7$           ;YES - SKIP
4319 017232 052714 000020      BIS      #HDSSEL,(R4)  ;INSERT HEAD BIT
4320 017236 052724 000001      7$:      BIS      #MBSSET0,(R4)+;INSERT MARKER BIT
4321 017242 005037 002420      CLR      DONE         ;CLEAR INTERRUPT FLAG
4322 017246 012701 000012      MOV      #10,R1        ;SET WAIT COUNT FOR 800US
4323 017252 014462 000004      MOV      -(R4),RLDA(R2);LOAD RL REGISTERS
4324 017256 014462 000002      MOV      -(R4),RLBA(R2)
4325 017262 014462 000000      MOV      -(R4),RLCS(R2)
4326 017266 005737 002420      10$:     TST      DONE         ;CHECK IF INTERRUPTED
4327 017272 001016      BNE      65$         ;YES - SKIP
4328 017274 005301      DEC      R1           ;DEC WAIT COUNT
4329 017276 001404      BEQ      13$         ;IF 0 - SKIP
4330 017300      WAITUS      #1
4331 (3) 017300 012700 000001      MOV      #1,R0
4332 (3) 017304 104027      EMT      CSWTU
4333 017306 000767      BR       10$         ;GO CHECK DONE
4334 017310 004737 016050      13$:     JSR      PC,WAITIN    ;GO WAIT FOR TIMEOUT
4335 017314 012603      MOV      (SP)+,R3     ;GET RESULT MESSAGE POINTER
4336 (3) 017316 104443      ERRHRD   10011,ERR1
4337 (5) 017320 023433      TRAP    T$ERCODE
4338 (5) 017322 012630      .WORD   10011
4339 017324 005037 002430      .WORD   ERR1
4340 017330      CLR      ERRSWI      ;CLEAR FOR ERROR ERROR RETURN
4341 017330 162737 000002 002414      14$:     SUB      #2,SSINDX    ;REMOVE ENTRY FROM SUBROUT STACK
4342 017336 012604      MOV      (SP)+,R4     ;RESTORE REGS
4343 017340 012600      MOV      (SP)+,R0
4344 017342 012603      MOV      (SP)+,R3
4345 017344 005737 002430      TST      ERRSWI      ;TEST IF ERROR RETURN
4346 017350 001403      BEQ      99$         ;YES - SKIP
4347 017352 063716 002430      ADD      ERRSWI,(SP)  ;ADD IN ERROR RETURN
4348 017356 000207      RTS      PC
4349 017360 017616 000000      99$:     MOV      2(SP),(SP)  ;SET ERROR RETURN ADDRESS
4350 017364 000207      RTS      PC
; DRIVE READY TEST ROUTINE. CHECKS DEIVE IS READY. IF NOT, WAIT

```



```

4425          SOOMS FOR READY TO SET.
4426 017366 010346          RDYCHK: MOV R3, -(SP)          ;STORE REGS
4427 017370 013703 002414  MOV SSINDX, R3          ;GET SUBROUTINE INDEX
4428 017374 005723          TST (R3)+              ;BUMP IT FOR NEXT ENTRY
4429 017376 016663 000002 002250  MOV 2(SP), SUBSTK(R3)  ;INSERT THIS CALL
4430 017404 162763 000004 002250  SUB #4, SUBSTK(R3)    ;ADJUST IT TO CALLING LOCATION
4431 017412 010337 002414  MOV R3, SSINDX        ;STORE IT BACK
4432 017416 010046          MOV R0, -(SP)
4433 017420 010146          MOV R1, -(SP)
4434 017422 010446          MOV R4, -(SP)
4435 017424 012737 000002 002430  MOV #2, ERRSWI        ;SET FOR NO ERROR RETURN
4436 017432 012701 011610  MOV #5000, R1         ;SET WAIT COUNT
4437 017436 004737 016250 15: JSR PC, GSTAT        ;GET DRIVE STATUS
4438 017442 017562          4$
4439 017444 032737 000001 002456  BIT #DRDYMSK, T.CS   ;TEST IF DRIVE READY
4440 017452 001045          BNE 5$              ;YES - EXIT
4441 017454          WAITUS #1
4442 (3) 017454 012700 000001  MOV #1, R0
4443 (3) 017460 104027          EMT CSWTU
4444 017462 005301          DEC R1              ;DEC WAIT COUNT
4445 017464 001364          BNE 1$              ;LOOP IF NOT 0
4446 017466 012703 010501  MOV #MDRDY, R3       ;SET RESULT MESSAGE POINTER
4447 017472 012704 011545  MOV #C500MS, R4     ;SET CONDITION MESSAGE POINTER
4448 (3) 017476 104443          ERRHRD 10010, ERRS
4449 (5) 017500 023432          TRAP T$ERRCODE
4450 (5) 017502 013062          .WORD 10010
4451 017504 012701 000062  MOV #50, R1         ;SET WAIT COUNT FOR 5 SECONDS
4452 017510 004737 016250 25: JSR PC, GSTAT        ;GET DRIVE STATUS
4453 017514 017562          4$
4454 017516 032737 000001 002456  BIT #DRDYMSK, T.CS   ;TEST IF DRIVE READY
4455 017524 001005          BNE 3$              ;YES - SKIP
4456 (3) 017526 012700 000001  WAITMS #1           ;WAIT FOR 100MS
4457 (3) 017532 104026          MOV #1, R0
4458 017534 005301          EMT CSWTM
4459 017536 001364          DEC R1              ;DEC WAIT COUNTER
4460 017540 032737 100000 002456 35: BNE 2$              ;LOOP UNTIL TIME DONE
4461 017546 001405          BIT #ANYERR, T.CS   ;TEST IF ANYERR SET
4462 (3) 017550 104443          BEQ 4$              ;NO - SKIP
4463 (5) 017552 023433          ERRHRD 10011, ERR6  ;REPORT ALL ERRORS
4464 (5) 017554 013132          TRAP T$ERRCODE
4465 017556 005337 002650  DEC ERRCNT          ;REDUCE ERROR COUNT FOR DUAL ERRORS
4466 017562 005037 002430 45: CLR ERRSWI          ;CLEAR FOR ERROR RETURN
4467 017566 162737 000002 002414 55: SUB #2, SSINDX      ;REMOVE ENTRY FROM SUBROUT STACK
4468 017574 012604          MOV (SP)+, R4       ;RESTORE REGS
4469 017576 012601          MOV (SP)+, R1
4470 017600 012600          MOV (SP)+, R0
4471 017602 012603          MOV (SP)+, R3
4472 017604 005737 002430  TST ERRSWI          ;TEST IF ERROR RETURN
4473 017610 001403          BEQ 99$            ;YES - SKIP
4474 017612 063716 002430  ADD ERRSWI, (SP)    ;ADD IN ERROR RETURN
4475 017616 000207          RTS PC
4476 017620 017616 000000 99$: MOV @ (SP), (SP)    ;SET ERROR RETURN ADDRESS
4477 017624 000207          RTS PC
    
```

# M05

OUTERR MACY11 30(1046) 04-NOV-77 13:14 PAGE 83-33  
 DZRLCA.PT1 04-NOV-77 13:13

SEG 0064

```

4471
4514
4515 017626 012737 000001 002540 XRDHDC: MOV #1,TEMP4 ;SET FLAG TO BYPASS REG STORAGE
4516 017634 000402 BR XRDHDG ;GO DO IT
4517 017636 005037 002540 XRDHD: CLR TEMP4 ;SET FLAG TO SAVE T. AMD L. REGS
4518 017642 010346 XRDHDG: MOV R3,-(SP) ;STORE REGISTERS
4519 017644 013703 002414 MOV SSINDX,R3 ;GET SUBROUTINE INDEX
4520 017650 005723 TST (R3)+ ;BUMP IT FOR NEXT ENTRY
4521 017652 016663 000002 002250 MOV 2(SP),SUBSTK(R3) ;INSERT THIS CALL
4522 017660 162763 000004 002250 SUB #4,SUBSTK(R3) ;ADJUST IT TO CALLING LOCATION
4523 017666 010337 002414 MOV R3,SSINDX ;STORE IT BACK
4524 017672 010046 MOV R0,-(SP)
4525 017674 010146 MOV R1,-(SP)
4526 017676 010446 MOV R4,-(SP)
4527 017700 012737 000002 002430 MOV #2,ERRSWI ;SET FOR NO ERROR RETURN
4528 017706 005737 002540 TST TEMP4 ;TEST IF REGISTERS TO BE SAVED
4529 017712 001007 BNE 2$ ;NO - SKIP
4530 017714 012703 002456 MOV #L.MP+2,R3 ;SET POINTER FOR REGS
4531 017720 012701 000004 MOV #4,R1 ;SET COUNT
4532 017724 014346 1$: MOV -(R3),-(SP) ;SAVE REGISTER
4533 017726 005301 DEC R1 ;DEC COUNT
4534 017730 001375 BNE 1$ ;LOOP UNTIL ALL ARE SAVED
4535 017732 004737 017366 2$: JSR PC,RDYCHK ;CHECK DRIVE READY
4536 017736 020172 #65$
4537 017740 005037 002420 CLR DONE ;CLEAR INTERRUPT FLAG
4538 017744 012701 002446 MOV #L.CS,R1 ;GET ADDRESS OF LOAD REGS
4539 017750 013711 002444 MOV RLDV,(R1) ;LOAD DRIVE NUMBER
4540 017754 042711 002000 BIC #BIT10,(R1) ;CLEAR FOR DRIVE 4 - 7 SPEC'D
4541 017760 052721 000110 BIS #RDHEAD,(R1)+ ;INSERT COMMAND
4542 017764 005021 CLR (R1)+ ;CLEAR BA
4543 017766 005021 CLR (R1)+ ;CLEAR DA
4544 017770 014162 000004 MOV -(R1),RLDA(R2) ;LOAD RL11 REGS
4545 017774 014162 000002 MOV -(R1),RLBA(R2)
4546 020000 014162 000000 MOV -(R1),RLCSR(R2)
4547 020004 3$: WAITUS #10. ;WAIT 1MS FOR INTERRUPT
(3) 020004 012700 000012 MOV #10.,R0
(3) 020010 104027 EMT CSWTU
4548 020012 005737 002420 TST DONE ;TEST IN INTERRUPT FLAG SET
4549 020016 001455 BEQ 14$ ;NO - SKIP
4550 020020 032737 000001 002456 5$: BIT #DRDYMSK,T.CS ;TEST IF DRIVE READY
4551 020026 001033 BNE 10$ ;YES - SKIP
4552 020030 012703 010501 MOV #MDRDY,R3 ;SET NO READY MESSAGE
4553 020034 012704 011564 MOV #CAFDT,R4 ;CONDITION OF AFTER DATA XFER
4554 020040 ERRHRD 10017,ERR5
(3) 020040 104443 TRAP TSERCODE
(5) 020042 023441 .WORD 10017
(5) 020044 013062 .WORD ERR5
4555 020046 012701 000062 MOV #50.,R1 ;SET WAIT COUNT FOR 5 SECONDS
4556 020052 004737 016250 4$: JSR PC,GSTAT ;GET STATUS
4557 020056 020166 60$
4558 020060 032737 000001 002456 BIT #DRDYMSK,T.CS ;TEST IF DRIVE HAS COME READY
4559 020066 001403 BEQ 11$ ;NO - SKIP
4560 020070 005037 002430 CLR ERRSWI ;CLEAR ERROR SWITCH
4561 020074 000410 BR 10$ ;SKIP
4562 020076 005301 11$: DEC R1 ;DEC WAIT COUNT
4563 020100 001364 BNE 4$ ;LOOP UNTIL TIME DONE
  
```



4564	020102	012704	011576		MOV	#CSSEC,R4	;SET CONDITION AFTER 5 SECONDS
4565	020106				ERRHRD	10014,ERR5	
(3)	020106	104443			TRAP	T\$ERCODE	
(5)	020110	023436			.WORD	10014	
(5)	020112	013062			.WORD	ERR5	
4566	020114	000424			BR	60\$	;EXIT
4567	020116	005737	002456	10\$:	TST	T,CS	;CHECK FOR ANY ERRORS
4568	020122	100004			BPL	12\$	;NO - SKIP
4569	020124				ERRHRD	10016,ERR6	;REPORT ALL ERRORS
(3)	020124	104443			TRAP	T\$ERCODE	
(5)	020126	023440			.WORD	10016	
(5)	020130	013132			.WORD	ERR6	
4570	020132	000415			BR	60\$	
4571	020134	012701	002466	12\$:	MOV	#HDWRD2,R1	;GET POINTER
4572	020140	016221	000006		MOV	RLMP(R2),(R1)+	;STORE LAST TWO HEADER WORDS
4573	020144	016221	000006		MOV	RLMP(R2),(R1)+	
4574	020150	000410			BR	65\$	;EXIT
4575	020152	004737	016050	14\$:	JSR	PC,WAITIN	;WAIT FOR INTERRUPT
4576	020156	012603			MOV	(SP)+,R3	;GET RESULTS
4577	020160				ERRHRD	10015,ERR1	;REPORT
(3)	020160	104443			TRAP	T\$ERCODE	
(5)	020162	023437			.WORD	10015	
(5)	020164	012630			.WORD	ERR1	
4578	020166	005037	002430	60\$:	CLR	ERRSWI	;CLEAR FOR ERROR ERROR RETURN
4579	020172	005737	002540	65\$:	TST	TEMP4	;TEST IF REGISTERS WERE SAVED
4580	020176	001007			BNE	22\$	;NO - SKIP
4581	020200	012703	002446		MOV	#L,CS,R3	;SET POINTER TO RESTORE REGS
4582	020204	012701	000004		MOV	#4,R1	;SET COUNT
4583	020210	012623		20\$:	MOV	(SP)+,(R3)+	;RESTORE REGISTER
4584	020212	005301			DEC	R1	;DEC COUNT
4585	020214	001375			BNE	20\$	;LOOP UNTIL ALL ARE RESTORED
4586	020216	162737	000002+ 002414	22\$:	SUB	#2,SSINDX	;REMOVE ENTRY FROM SUBROUT STACK
4587	020224	012604			MOV	(SP)+,R4	;RESTORE REGS
4588	020226	012601			MOV	(SP)+,R1	
4589	020230	012600			MOV	(SP)+,R0	
4590	020232	012603			MOV	(SP)+,R3	
4591	020234	005737	002430		TST	ERRSWI	;TEST IF ERROR RETURN
4592	020240	001403			BEQ	99\$	;YES - SKIP
4593	020242	063716	002430		ADD	ERRSWI,(SP)	;ADD IN ERROR RETURN
4594	020246	000207			RTS	PC	
4595	020250	017616	000000	99\$:	MOV	2(SP),(SP)	;SET ERROR RETURN ADDRESS
4596	020254	000207			RTS	PC	
4597							
4673							
4674	020256	013705	002464	POSHW1:	MOV	HDWRD1,R5	POSITION HEAD BIT FROM HEADER OR MULTIPURPOSE REGISTER TO LSB.
4675	020262	000402			BR	POSHD0	;START FOR POSITION HD BIT IN WD 1
4676	020264	013705	002464	POSHSB:	MOV	T,MP,R5	;START FOR POSITION HD BIT IN MP
4677	020270	010146		POSHD0:	MOV	R1-(SP)	;STORE R1
4678	020272	042705	177677		BIC	#1,CHSSTAT,R5	;CLEAR ALL BUT HEAD SEL BIT
4679	020276	012701	000006		MOV	#6,R1	;SET SHIFT COUNT
4680	020302	006205		1\$:	ASR	R5	;SHIFT FOR RIGHT JUSTIFY
4681	020304	005301			DEC	R1	
4682	020306	001375			BNE	1\$	
4683	020310	012601			MOV	(SP)+,R1	;RESTORE R1
4684	020312	000207			RTS	PC	;RETURN
4685							



```

4686      :      WAIT FOR READY ROUTINE. DURATION OF WAIT PASSED TO THE ROUTINE
4687      :      FROM THE CALLING ROUTINE IN R1.
4688      RDYWAIT:  MOV      R3,-(SP)      ;STORE R3
4689      020314  010346      MOV      SSINDX,R3      ;GET SUBROUTINE INDEX
4690      020316  013703  002414  TST      (R3)+      ;BUMP IT FOR NEXT ENTRY
4691      020322  005723      MOV      2(SP),SUBSTK(R3) ;INSERT THIS CALL
4692      020324  016663  000002  002250  SUB      #4,SUBSTK(R3) ;ADJUST IT TO CALLING LOCATION
4693      020326  162763  000004  002250  MOV      R3,SSINDX      ;STORE IT BACK
4694      020332  010337  002414  MOV      R0,-(SP)
4695      020334  010046      MOV      R1,-(SP)
4696      020336  010146      MOV      R4,-(SP)
4697      020338  010446      MOV      #2,ERRSWI      ;SET FOR NO ERROR RETURN
4698      020340  012737  000002  002430  JSR      PC,GSTAT      ;GET DRIVE STATUS
4699      020342  004737  016250  5$:      10$
4700      020344  020516      BIT      #DRDYMSK,T.CS ;CHECK IF READY
4701      020346  032737  000001  002456  BNE      9$           ;YES - SKIP
4702      020348  001052      DEC      R1           ;DEC WAIT COUNT
4703      020350  005301      BEQ      7$           ;SKIP IF 0
4704      020352  001404      WAITUS  #1
4705      (3) 020402  012700  000001      MOV      #1,R0
4706      (3) 020404  104027      EMT      CSWTU
4707      020406  000763      BR       5$
4708      020408  012703  010501  7$:      MOV      #MDRDY,R3      ;SET NAME MESSAGE PTR
4709      020410  012703  010501  ERRHRD  10020,ERR3 ;REPORT READY ERROR
4710      (3) 020412  104443      TRAP    T$ERCODE
4711      (5) 020414  023444      .WORD  10020
4712      (5) 020416  012744      .WORD  ERR3
4713      020418  012701  000062      MOV      #50,R1      ;SET WAIT COUNT FOR 5 SECONDS
4714      020420  004737  C16250  6$:      JSR      PC,GSTAT      ;GET DRIVE STATUS
4715      020422  020516      10$
4716      020424  032737  000001  002456  BIT      #DRDYMSK,T.CS ;TEST IF DRIVE READY
4717      020426  001013      BNE      8$           ;YES - SKIP
4718      020428  012700  000001      WAITMS  #1           ;WAIT 100 MS
4719      (3) 020430  104026      MOV      #1,R0
4720      (3) 020432  005301      EMT      CSWTM
4721      020434  001364      DEC      R1           ;DEC WAIT COUNT
4722      020436  012704  011576  BNE      6$           ;LOOP UNTIL TIME DONE
4723      020438  104443      MOV      #CSSEC,R4      ;SET CONDITION AFTER 5 SECS
4724      (3) 020440  023445      ERRHRD  10021,ERR5
4725      (5) 020442  013062      TRAP    T$ERCODE
4726      (5) 020444  000407      .WORD  10021
4727      020446  000407      .WORD  ERR5
4728      020448  032737  100000  002456  8$:      BR       11$
4729      020450  001405      BIT      #ANYERR,T.CS ;EXIT
4730      020452  020504      BEQ      10$          ;TEST IF ANY ERROR SET
4731      (3) 020454  104443      ERRHRD  10022,ERR6 ;NO - SKIP
4732      (5) 020456  023446      TRAP    T$ERCODE ;REPORT ALL ERRORS
4733      (5) 020458  013132      .WORD  10022
4734      020460  005337  002650  11$:      .WORD  ERR6
4735      020462  005037  002430  10$:      DEC      ERRCNT      ;DEC FOR DOUBLE ERROR REPORT
4736      020464  162737  000002  002414  9$:      CLR      ERRSWI      ;CLEAR FOR ERROR ERROR RETURN
4737      020466  012604      SUB      #2,SSINDX    ;REMOVE ENTRY FROM SUBROUT STACK
4738      020468  012601      MOV      (SP)+,R4     ;RESTORE REGISTERS
4739      020470  012600      MOV      (SP)+,R1
4740      020472  012600      MOV      (SP)+,R0
4741      020474  012603      MOV      (SP)+,R3     ;RESTORE R3
    
```



```

4729 020540 005737 002430      TST      ERRSWI      ;TEST IF ERROR RETURN
4730 020544 001403              BEQ      99$        ;YES - SKIP
4731 020546 063716 002430      ADD      ERRSWI,(SP) ;ADD IN ERROR RETURN
4732 020552 000207              RTS      PC
4733 020554 017616 000000      99$:    MOV      @ (SP), (SP) ;SET ERROR RETURN ADDRESS
4734 020560 000207              RTS      PC
4735
4736      ;
4737      ; GET POSITION ROUTINE. READS A HEADER FROM CURRENT CYLINDER
4738      ; (WHERE IT IS PRESENTLY POSITIONED) AND STORES CYLINDER
4739      ; NUMBER IN CURCYL.
4739 020562 010346      GETPOS:  MOV      R3, -(SP)      ;STORE REGISTERS
4740 020564 013703 002414      MOV      SSINDX,R3      ;GET SUBROUTINE INDEX
4741 020570 005723              TST      (R3)+          ;BUMP IT FOR NEXT ENTRY
4742 020572 016663 000002 002250      MOV      2(SP),SUBSTK(R3) ;INSERT THIS CALL
4743 020600 162763 000004 002250      SUB      #4,SUBSTK(R3)   ;ADJUST IT TO CALLING LOCATION
4744 020606 010337 002414      MOV      R3,SSINDX      ;STORE IT BACK
4745 020612 010046      MOV      R0,-(SP)
4746 020614 010546      MOV      R5,-(SP)
4747 020616 004737 017636      JSR      PC,XRDHD        ;DO READ HEADER
4748 020622 020652      #65$
4749 020624 013703 002464      MOV      HDWRD1,R3      ;GET HEADER WORD
4750 020630 042703 100177      BIC      #1CHDCYL,R3    ;CLEAR ALL BUT CYLINDER
4751 020634 012705 000007      MOV      #7,R5          ;SET SHIFT COUNT
4752 020640 006203      4$:    ASR      R3            ;SHIFT TO RIGHT JUSTIFY
4753 020642 005305      DEC      R5
4754 020644 001375      BNE      4$
4755 020646 010337 002516      MOV      R3,CURCYL      ;STORE AS CURRENT CYLINDER
4756 020652 162737 000002 002414 65$:    SUB      #2,SSINDX      ;REMOVE ENTRY FROM SUBROUT STACK
4757 020660 012605      MOV      (SP)+,R5
4758 020662 012600      MOV      (SP)+,R0
4759 020664 012603      MOV      (SP)+,R3
4760 020666 005737 002430      TST      ERRSWI        ;TEST IF ERROR RETURN
4761 020672 001403              BEQ      99$        ;YES - SKIP
4762 020674 063716 002430      ADD      ERRSWI,(SP)   ;ADD IN ERROR RETURN
4763 020700 000207              RTS      PC
4764 020702 017616 000000      99$:    MOV      @ (SP), (SP) ;SET ERROR RETURN ADDRESS
4765 020706 000207              RTS      PC
4766
4795      ;
4796      ; READ ALL HEADERS ROUTINE. 40 HEADERS ARE READ AND STORED
4797      ; IN Ibuff.
4797 020710 010346      RDALHD: MOV      R3, -(SP)      ;STORE REGISTERS
4798 020712 013703 002414      MOV      SSINDX,R3      ;GET SUBROUTINE INDEX
4799 020716 005723              TST      (R3)+          ;BUMP IT FOR NEXT ENTRY
4800 020720 016663 000002 002250      MOV      2(SP),SUBSTK(R3) ;INSERT THIS CALL
4801 020726 162763 000004 002250      SUB      #4,SUBSTK(R3)   ;ADJUST IT TO CALLING LOCATION
4802 020734 010337 002414      MOV      R3,SSINDX      ;STORE IT BACK
4803 020740 010046      MOV      R0,-(SP)
4804 020742 010146      MOV      R1,-(SP)
4805 020744 010446      MOV      R4,-(SP)
4806 020746 012737 000002 002430      MOV      #2,ERRSWI      ;SET FOR NO ERROR RETURN
4807 020754 012701 000050      MOV      #40,R1        ;SET HEADER COUNT
4808 020760 052737 100000 002416      BIS      #HDR40,OPFLAG   ;SET 40 HDR OP FLAG
4809 020766 012703 003256      MOV      #IBUFF,R3      ;SET POINTER TO STORE HDRS
4810 020772 013704 002440      MOV      RLBAS,R4       ;GET BASE ADDRESS
4811 020776 062704 000006      ADD      #RLMP,R4       ;MAKE IT POINT TO MP REG
4812 021002 012737 000010 002446      MOV      #10,L.CS      ;LOAD FOR READ HEADER, NO INTERRUPT
    
```



4813	021010	053737	002444	002446		BIS	RLDRV,L.CS	; INSERT DRIVE NUMBER
4814	021016	042737	002000	002446		BIC	#BIT10,L.CS	; CLEAR FOR DRIVE 4 - 7 SPEC'D
4815	021024	005037	002450			CLR	L.BA	; CLEAR BA
4816	021030	005037	002452			CLR	L.DA	; CLEAR DA
4817	021034	005737	002524			TST	DESHD	; TEST IF HEAD 0
4818	021040	001403				BEQ	3\$	; YES - SKIP
4819	021042	052737	000020	002452		BIS	#H0SEL,L.DA	; ELSE INSERT HEAD 0
4820	021050	013762	002452	000004	3\$:	MOV	L.DA,RLDA(R2)	; LOAD RLDA REG
4821	021056	013762	002450	000002		MOV	L.BA,RLBA(R2)	; LOAD RLBA
4822	021064	032762	000200	000000		BIT	#CRDYMSK,RLCS(R2)	; TEST IF CONTROLLER READY
4823	021072	001003				BNE	6\$	; YES - SKIP
4824	021074	004737	017366			JSR	PC,RDYCHK	; ELSE CHECK READY
4825	021100	021212				#65\$		
4826	021102	013762	002446	000000	6\$:	MOV	L.CS,RLCS(R2)	; LOAD RLCS REG
4827	021110	012700	077777			MOV	#77777,R0	; SET COUNT FOR WAIT
4828	021114	032762	000200	000000	7\$:	BIT	#CRDYMSK,RLCS(R2)	; CHECK THAT OPERATION COMPLETED
4829	021122	001015				BNE	8\$	; YES - SKIP
4830	021124	005300				DEC	R0	; DEC COUNT
4831	021126	001372				BNE	7\$	; SKIP IF NOT YET 0
4832	021130	004737	016016			JSR	PC,READRL	; ELSE GET ALL REGISTERS
4833	021134	004737	016050			JSR	PC,WAITIN	; ELSE WAIT FOR TIMEOUT
4834	021140	012603				MOV	(SP)+,R3	; GET RESULT MESSAGE POINTER
4835	021142					ERRHRD	10025,ERR1	
(3)	021142	104443				TRAP	T\$ERRCODE	
(5)	021144	023451				.WORD	10025	
(5)	021146	012630				.WORD	ERR1	
4836	021150	005037	002430			CLR	ERRSWI	; CLEAR FOR ERROR RETURN
4837	021154	000416				BR	65\$	
4838	021156	005737	002456		8\$:	TST	T.CS	; TEST FOR ANY ERRORS
4839	021162	100006				BPL	12\$	; NO - SKIP
4840	021164					ERRHRD	10026,ERR6	
(3)	021164	104443				TRAP	T\$ERRCODE	
(5)	021166	023452				.WORD	10026	
(5)	021170	013132				.WORD	ERR6	
4841	021172	005037	002430			CLR	ERRSWI	; CLEAR FOR ERROR RETURN
4842	021176	000405				BR	65\$	
4843	021200	011423			12\$:	MOV	(R4),(R3)+	; STORE HEADER WORDS
4844	021202	011423				MOV	(R4),(R3)+	
4845	021204	011423				MOV	(R4),(R3)+	
4846	021206	005301				DEC	R1	; DEC HEADER COUNT
4847	021210	001334				BNE	6\$	
4848	021212	162737	000002	002414	65\$:	SUB	#2,SSINDX	; REMOVE ENTRY FROM SUBROUT STACK
4849	021220	012604				MOV	(SP)+,R4	; RESTORE REGISTERS
4850	021222	012601				MOV	(SP)+,R1	
4851	021224	012600				MOV	(SP)+,R0	
4852	021226	012603				MOV	(SP)+,R3	
4853	021230	005737	002430			TST	ERRSWI	; TEST IF ERROR RETURN
4854	021234	001403				BEQ	99\$	; YES - SKIP
4855	021236	063716	002430			ADD	ERRSWI,(SP)	; ADD IN ERROR RETURN
4856	021242	000207				RTS	PC	
4857	021244	017616	000000		99\$:	MOV	@(SP),(SP)	; SET ERROR RETURN ADDRESS
4858	021250	000207				RTS	PC	

5088 ;  
 5089 ;  
 ; REPORT OPERATION ROUTINE. PRINTS SUBROUTINE TRACE SEQUENCE AND  
 ; OPERATION BEING PERFORMED PORTION OF ALL



```

5090          ERROR MESSAGES.
5091 021252 010446          RPTOP: MOV R4, -(SP)
5092 021254 005737 002414 TST SSINDX          ;TEST SUBROUTINE INDEX 0
5093 021260 001433          BEQ 1$          ;SKIP IF 0
5094 021262 012704 000002 MOV #2, R4          ;SET INDEXER TO FIRST ENTRY.
5095 021266          PRINTB #FMT9, #SEQMES ;PRINT "SUBROUTINE CALL SEQ"
(8) 021266 012746 010324 MOV #SEQMES, -(SP)
(7) 021272 012746 012117 MOV #FMT9, -(SP)
(6) 021276 012746 000002 MOV #2, -(SP)
(3) 021302 010600          MOV SP, R0
(4) 021304 104014          EMT C$PNTB
(4) 021306 062706 000006 ADD #6, SP
5096 021312          3$: PRINTB #FMT16, SUBSTK(R4) ;PRINT CALLING LOCATION
(8) 021312 016446 002250 MOV SUBSTK(R4), -(SP)
(7) 021316 012746 012272 MOV #FMT16, -(SP)
(6) 021322 012746 000002 MOV #2, -(SP)
(3) 021326 010600          MOV SP, R0
(4) 021330 104014          EMT C$PNTB
(4) 021332 062706 000006 ADD #6, SP
5097 021336 062704 000002 ADD #2, R4          ;BUMP INDEX
5098 021342 020437 002414 CMP R4, SSINDX      ;CHECK IF ALL PRINTED
5099 021346 003761          BLE 3$          ;LOOP IF NOT ALL PRINTED YET
5100 021350          1$: PRINTB #FMT4, ERHEAD, #TSTLAB ;PRINT ERROR HEADER
(9) 021350 012746 006007 MOV #TSTLAB, -(SP)
(8) 021354 013746 002424 MOV ERHEAD, -(SP)
(7) 021360 012746 011722 MOV #FMT4, -(SP)
(6) 021364 012746 000003 MOV #3, -(SP)
(3) 021370 010600          MOV SP, R0
(4) 021372 104014          EMT C$PNTB
(4) 021374 062706 000010 ADD #10, SP
5101 021400 042737 030000 002416 BIC #SEEKOP!RORWOP, OPFLAG ;CLEAR SK & RD OR WRT FLAG
5102 021406 013701 002446 MOV L, CS, R1          ;GET COMMAND EXECUTED
5103 021412 042701 177741 BIC #177741, R1      ;STRIP ALL BUT FUNCTION CODE
5104 021416 022701 000006 CMP #6, R1          ;TEST IF SEEK OPERATION
5105 021422 001003          BNE 2$          ;NO - SKIP
5106 021424 052737 010000 002416 BIS #SEEKOP, OPFLAG ;ELSE SET SEEK FLAG
5107 021432 022701 000012 2$: CMP #12, R1          ;TEST IF WRITE
5108 021436 001003          BNE 20$         ;NO - SKIP
5109 021440 052737 020000 002416 BIS #RORWOP, OPFLAG ;SET RD OR WRT FLAG
5110 021446 022701 000014 20$: CMP #14, R1          ;TEST IF READ
5111 021452 001003          BNE 22$         ;NO - SKIP
5112 021454 052737 020000 002416 BIS #RORWOP, OPFLAG ;SET RD OR WRT FLAG
5113 021462          22$: PRINTB #FMT1, #MOPER, OPMSGS(R1) ;PRINT OPERATION
(9) 021462 016146 002112 MOV OPMSGS(R1), -(SP)
(8) 021466 012746 004733 MOV #MOPER, -(SP)
(7) 021472 012746 011700 MOV #FMT1, -(SP)
(6) 021476 012746 000003 MOV #3, -(SP)
(3) 021502 010600          MOV SP, R0
(4) 021504 104014          EMT C$PNTB
(4) 021506 062706 000010 ADD #10, SP
5114 021512 020127 000004 CMP R1, #4          ;CHECK IF GET STATUS
5115 021516 001007          BNE 4$          ;NO - SKIP
5116 021520 032737 000010 002452 BIT #DRSET, L.DA    ;TEST IF RESET INCLUDED
5117 021526 001403          BEQ 4$          ;NO - SKIP
5118 021530 012701 000016 MOV #16, R1          ;SET TO PRINT WITH RESET
5119 021534 000436          BR 9$

```

5120	021536	032737	007777	002416	4\$:	BIT	#COMPOP,OPFLAG	:TEST IF ANY OTHER OPERATION
5121	021544	001424				BEQ	8\$	:NO - SKIP
5122	021546	013704	002416			MOV	OPFLAG,R4	:SET UP TO DETERMINE WHICH ONE
5123	021552	012701	000020			MOV	#20,R1	:PRESET THE POINTER
5124	021556	032704	000001		5\$:	BIT	#BIT00,R4	:CHECK THE BIT
5125	021562	001003				BNE	6\$	:IF SET - SKIP
5126	021564	005721				TST	(R1)+	:BUMP POINTER
5127	021566	006204				ASR	R4	
5128	021570	000772				BR	5\$	
5129	021572				6\$:	PRINTB	#FMT2,OPMSG\$(R1)	
(8)	021572	016146	002112			MOV	OPMSG\$(R1),-(SP)	
(7)	021576	012746	011714			MOV	#FMT2,-(SP)	
(6)	021502	012746	000002			MOV	#2,-(SP)	
(3)	021606	010600				MOV	SP,R0	
(4)	021610	104014				EMT	C\$PNTB	
(4)	021612	062706	000006			ADD	#6,SP	
5130	021616	032737	100000	002416	8\$:	BIT	#HDR40,OPFLAG	:TEST IF 40 HEADER OPERATION
5131	021624	001415				BEQ	10\$	:NO - SKIP
5132	021626	012701	000050			MOV	#50,R1	:ELSE PRINT IT
5133	021632				9\$:	PRINTB	#FMT2,OPMSG\$(R1)	
(8)	021632	016146	002112			MOV	OPMSG\$(R1),-(SP)	
(7)	021636	012746	011714			MOV	#FMT2,-(SP)	
(6)	021642	012746	000002			MOV	#2,-(SP)	
(3)	021646	010600				MOV	SP,R0	
(4)	021650	104014				EMT	C\$PNTB	
(4)	021652	062706	000006			ADD	#6,SP	
5134	021656	000434				BR	15\$	:SKIP
5135	021660	032737	010000	002416	10\$:	BIT	#SEEKOP,OPFLAG	:TEST IF SEEK
5136	021666	001430				BEQ	15\$	:NO - SKIP
5137	021670					PRINTB	#FMT13,#FRMWD,OLDCYL,#DIFWD,DESDIF,#SGNWD,DESSGN,#HDWD,DESHD	
(15)	021670	013746	002524			MOV	DESHD,-(SP)	
(14)	021674	012746	010265			MOV	#HDWD,-(SP)	
(13)	021700	013746	002522			MOV	DESSGN,-(SP)	
(12)	021704	012746	010260			MOV	#SGNWD,-(SP)	
(11)	021710	013746	002520			MOV	DESDIF,-(SP)	
(10)	021714	012746	010252			MOV	#DIFWD,-(SP)	
(9)	021720	013746	002512			MOV	OLDCYL,-(SP)	
(8)	021724	012746	010303			MOV	#FRMWD,-(SP)	
(7)	021730	012746	012140			MOV	#FMT13,-(SP)	
(6)	021734	012746	000011			MOV	#11,-(SP)	
(3)	021740	010600				MOV	SP,R0	
(4)	021742	104014				EMT	C\$PNTB	
(4)	021744	062706	000024			ADD	#24,SP	
5138	021750	032737	020000	002416	15\$:	BIT	#RORWOP,OPFLAG	:TEST IF READ OR WRITE SET
5139	021756	001424				BEQ	17\$	:NO - SKIP
5140	021760					PRINTB	#FMT22,#CYLWD,CURCYL,#HDWD,DESHD,#SECWD,DESSEC	
(13)	021760	013746	002526			MOV	DESSEC,-(SP)	
(12)	021764	012746	010271			MOV	#SECWD,-(SP)	
(11)	021770	013746	002524			MOV	DESHD,-(SP)	
(10)	021774	012746	010265			MOV	#HDWD,-(SP)	
(9)	022000	013746	002516			MOV	CURCYL,-(SP)	
(8)	022004	012746	010276			MOV	#CYLWD,-(SP)	
(7)	022010	012746	012467			MOV	#FMT22,-(SP)	
(6)	022014	012746	000007			MOV	#7,-(SP)	
(3)	022020	010600				MOV	SP,R0	
(4)	022022	104014				EMT	C\$PNTB	



```

(4) 022024 062706 000020          ADD      #20,SP
S141 022030 004737 022502          17$: JSR   PC,CLRPARM      ;CLEAR PARAM TABLE
S142 022034 012604                MOV   (SP)+,R4          ;RESTORE R4
S143 022036 000207                RTS   PC
S144
S145
S146
S147 022040 010146          : REPORT REASON ROUTINE
S148 022042 010346          : PRINTS REASON PORTION FOR ALL ERROR REPORTS.
S149 022044 010446          RPTRES: MOV  R1,-(SP)      ;STORE R1
S150 022046 012701 002474      MOV  R3,-(SP)      ;STORE R3
S151 022052 012103          MOV  R4,-(SP)      ;STORE R4
S152 022054                MOV  #RESPARM,R1    ;GET START OF PARAM
S153 022102 021127 011175      MOV  (R1)+,R3      ;GET NUMBER OF PARAM
S154 022106 001453          PRINTB #FMT1.1,#MRSLT,(R1) ;PRINT NAME
S155 022110 012704 012124      MOV  (R1),-(SP)
S156 022114 022127 011170      MOV  #MRSLT,-(SP)
S157 022120 001002          MOV  #FMT1.1,-(SP)
S158 022122 012704 012132      MOV  #3,-(SP)
S159 022126 005303          MOV  SP,RO
S160 022130 001442          EMT  C$PNTB
S161 022132                ADD  #10,SP
S162 022152 062706 000010      CMP  (R1),#MNRST    ;TEST IF MESSAGE IS NO DRV STATUS
S163 022202 162703 000002      BEQ  6$            ;YES - SKIP REST OF REPORT
S164 022206 001413          MOV  #FMT11,R4      ;PRISET FOR FORMAT 11
S165 022210                CMP  (R1)+,#MCYLOC  ;CHECK IF REPORTING CYLINDER LOC
S166 022212 012746 011450      BNE  3$            ;NO - SKIP
S167 022214 010446 000003      MOV  #FMT12,R4     ;ELSE CHANGE TO FORMAT 12
S168 022216 012746 000003      DEC  R3            ;DEC PARAM COUNT
S169 022218 010600          BEQ  6$            ;IF 0 - EXIT
S170 022220                PRINTB R4,#RESE3,(R1)+ ;REPORT IS VALUE
S171 022222 012146          MOV  (R1)+,-(SP)
S172 022224 012746 011437      MOV  #RESE3,-(SP)
S173 022226 010446          MOV  R4,-(SP)
S174 022228 012746 000003      MOV  #3,-(SP)
S175 022230 010600          MOV  SP,RO
S176 022232 104014          EMT  C$PNTB
S177 022234 062706 000010      ADD  #10,SP
S178 022236 012604          PRINTB R4,#RESE4,(R1)+ ;REPORT SB VALUE
S179 022238 012603          MOV  (R1)+,-(SP)
S180 022240 012603          MOV  #RESE4,-(SP)
S181 022242 010446          MOV  R4,-(SP)
S182 022244 012746 000003      MOV  #3,-(SP)
S183 022246 010600          MOV  SP,RO
S184 022248 104014          EMT  C$PNTB
S185 022250 062706 000010      ADD  #10,SP
S186 022252 012604          SUB  #2,R3         ;DEC PARAM COUNT
S187 022254 012603          BEQ  6$            ;IF 0 - EXIT
S188 022256 012603          PRINTB #FMT1,#RESE5,(R1)+ ;REPORT CONDITION
S189 022258 012146          MOV  (R1)+,-(SP)
S190 022260 012746 011450      MOV  #RESE5,-(SP)
S191 022262 012746 011700      MOV  #FMT1,-(SP)
S192 022264 012746 000003      MOV  #3,-(SP)
S193 022266 010600          MOV  SP,RO
S194 022268 104014          EMT  C$PNTB
S195 022270 062706 000010      ADD  #10,SP
S196 022272 012604          6$: MOV  (SP)+,R4      ;RESTORE REGS
S197 022274 012603          MOV  (SP)+,R3

```

```

S168 022242 012601      MOV      (SP)+,R1
S169 022244 000207      RTS      PC                ;RETURN
S170
S171
S172
S173 022246      :      REPORT PHYSICAL ADDRESS OF DEVICE UNDER TEST
S174 022246      RPTREM: PRINTB #FMT5,#BASADD,RLBAS,#DRVNAM,<B,RLDRV+1>
(11) 022246      CLR      -(SP)
(11) 022250      BISB   RLDRV+1,(SP)
(10) 022254      MOV     #DRVNAM,-(SP)
(9) 022260      MOV     RLBAS,-(SP)
(8) 022264      MOV     #BASADD,-(SP)
(7) 022270      MOV     #FMT5,-(SP)
(6) 022274      MOV     #5,-(SP)
(5) 022280      MOV     SP,RO
(4) 022302      EMT   C$PNTB
(4) 022304      ADD   #14,SP
S174 022310      :      REPORT RL11 REGISTERS
S175 022310      PRINTB #FMT6,#CSNAM,#DANAM,#BANAM,#MPNAM,#CYLWD,#HDWD
(13) 022310      MOV     #HDWD,-(SP)
(12) 022314      MOV     #CYLWD,-(SP)
(11) 022320      MOV     #MPNAM,-(SP)
(10) 022324      MOV     #BANAM,-(SP)
(9) 022330      MOV     #DANAM,-(SP)
(8) 022334      MOV     #CSNAM,-(SP)
(7) 022340      MOV     #FMT6,-(SP)
(6) 022344      MOV     #7,-(SP)
(5) 022350      MOV     SP,RO
(4) 022352      EMT   C$PNTB
(4) 022354      ADD   #20,SP
S176 022360      PRINTB #FMT8,#LAB1,L.CS,L.DA,L.BA,L.MP
(12) 022360      MOV     L.MP,-(SP)
(11) 022364      MOV     L.BA,-(SP)
(10) 022370      MOV     L.DA,-(SP)
(9) 022374      MOV     L.CS,-(SP)
(8) 022400      MOV     #LAB1,-(SP)
(7) 022404      MOV     #FMT8,-(SP)
(6) 022410      MOV     #6,-(SP)
(5) 022414      MOV     SP,RO
(4) 022416      EMT   C$PNTB
(4) 022420      ADD   #16,SP
S177 022424      PRINTB #FMT7,#LAB2,T.CS,T.DA,T.BA,T.MP,CURCYL,DESHD
(14) 022424      MOV     DESHD,-(SP)
(13) 022430      MOV     CURCYL,-(SP)
(12) 022434      MOV     T.MP,-(SP)
(11) 022440      MOV     T.BA,-(SP)
(10) 022444      MOV     T.DA,-(SP)
(9) 022450      MOV     T.CS,-(SP)
(8) 022454      MOV     #LAB2,-(SP)
(7) 022460      MOV     #FMT7,-(SP)
(6) 022464      MOV     #10,-(SP)
(5) 022470      MOV     SP,RO
(4) 022472      EMT   C$PNTB
(4) 022474      ADD   #22,SP
S178 022500      RTS      PC
S180
;      CLEAR PARAMETER BLOCK FOR REPORTING

```



5181	022502	010546		CLRPARM:	MOV	RS -(SP)	:STORE RS
5182	022504	012701	002474		#RESPARM,R1		:GET ADDRESS OF BLOCK
5183	022510	012705	000005		#5,RS		:SET COUNT
5184	022514	005021		2\$:	CLR	(R1)+	:CLEAR WORD
5185	022516	005305			DEC	RS	:DEC COUNT
5186	022520	001375			BNE	2\$	:LOOP UNTIL 0
5187	022522	012701	002474		MOV	#RESPARM,R1	:RESET POINTER
5188	022526	012605			MOV	(SP)+,RS	:RESTORE RS
5189	022530	000207			RTS	PC	
5190							
5191	022532			ENDMOD			

```

5194 022532          BGNMOD  HRDWTST          BASIC INTERFACE (PART 1)
5195          .SBTTL  *TEST 1
5196
5197 022532          BGNTST          ;TEST01          T1::
(3) 022532
5198 022532 005737 002652          TST          PASNUM          ;CHECK IF FIRST PASS
5199 022536 001120          BNE          65$          ;EXIT IF NO
5200 022540 005737 014446          TST          MISWIW          ;CHECK IF MANUAL INTERVENTION
5201 022544 100115          BPL          65$          ;NO - EXIT TEST
5202 022546 012737 006015 002424  MOV          #MISTST,ERHEAD ;LOAD ERR HEADER
5203 022554          2$:          PRINTF          #FMTOP1,#OPR1,#OPR1A,#BASADD,RLBAS,#DRVNAM,<B,RLDRV+1>
(13) 022554 005046          CLR          -(SP)
(13) 022556 153716 002445          BISB          RLDV+1,(SP)
(12) 022562 012746 005423          MOV          #DRVNAM,-(SP)
(11) 022566 013746 002440          MOV          RLBAS,-(SP)
(10) 022572 012746 005412          MOV          #BASADD,-(SP)
(9) 022576 012746 010206          MOV          #OPR1A,-(SP)
(8) 022602 012746 007564          MOV          #OPR1,-(SP)
(7) 022606 012746 011606          MOV          #FMTOP1,-(SP)
(6) 022612 012746 000007          MOV          #7,-(SP)
(3) 022616 010600          MOV          SP,RO
(4) 022620 104017          EMT          C$PNTF
(4) 022622 062706 000020          ADD          #20,SP
5204 022626 005037 003656          CLR          OBUFF          ;CLEAR FOR RESPONSE
5205 022632          GMANIL          #OPROO2,OBUFF,1,NO
(3) 022632 104043          EMT          C$GMAN
(3) 022634 000404          BR          10000$
(4) 022636 003656          .WORD          OBUFF
(5) 022640 000120          .WORD          T$CODE
(5) 022642 007514          .WORD          #OPROO2
(5) 022644 000001          .WORD          1
(3) 022646          10000$:
5206 022646 005737 003656          TST          OBUFF          ;TEST RESPONSE YES
5207 022652 001740          BEQ          2$          ;YES - SKIP
5208 022654 004737 016202          JSR          PC,TSTINT          ;INITIALIZE TEST
5209 022660 004737 016234          JSR          PC,GSTATC          ;GO GET STATUS (NO RESET)
5210 022664 023000          #65$
5211 022666 032737 000040 002464  BIT          #COSTAT,T.MP          ;CHECK IF COVER OPEN SET
5212 022674 001005          BNE          7$          ;YES - SKIP
5213 022676 012703 010662          MOV          #MCOSTA,R3          ;SET NAME POINTER
5214 022702          ERRHRD          101,ERR3
(3) 022702 104443          TRAP          T$ERRCODE
(5) 022704 000145          .WORD          101
(5) 022706 012744          .WORD          ERR3
5215 022710 032737 000010 002464  7$:          BIT          #BHSTAT,T.MP          ;TEST IF BRUSHES HOME
5216 022716 001005          BNE          9$          ;YES - SKIP
5217 022720 012703 010675          MOV          #MBHSTA,R3          ;SET POINTER FOR BRUSH HOME ERROR
5218 022724          ERRHRD          102,ERR3
(3) 022724 104443          TRAP          T$ERRCODE
(5) 022726 000146          .WORD          102
(5) 022730 012744          .WORD          ERR3
5219 022732 032737 020000 002464  9$:          BIT          #WLSTAT,T.MP          ;TEST IF WRITE LOCK SET
5220 022740 001005          BNE          11$          ;YES - SKIP
5221 022742 012703 010710          MOV          #MWLSTA,R3          ;SET NAME POINTER
5222 022746          ERRHRD          103,ERR3
(3) 022746 104443          TRAP          T$ERRCODE
  
```



(5)	022750	000147			.WORD	103		
(5)	022752	012744			.WORD	ERR3		
5223	022754	005737	002472	11\$:	TST	T. STAT		;TEST IF STATE ZERO
5224	022760	001404			BEQ	15\$		;YES - SKIP
5225	022762	005003			CLR	R3		;SET STATE EXPECTED
5226	022764				ERRHRD	104. ERR7		
(3)	022764	104443			TRAP	T\$ERCODE		
(5)	022766	000150			.WORD	104		
(5)	022770	014010			.WORD	ERR7		
5227	022772	004737	016220	15\$:	JSR	PC,G\$TATR		;DO DRIVE RESET
5228	022776	023000			65\$			
5229	023000			65\$:				
5230	023000			ENDTST				
(3)	023000			L10020:				
(3)	023000	104001			EMT	C\$ETST		
5231								

```

5233 .SBTTL *TEST 2 BASIC INTERFACE (PART 2)
5234
5235 BGNTST ;TEST 2
5236 (3) 023002 005737 002652 TST PASNUM ;TEST IF PASS 0
5237 023006 001075 BNE 65$ ;NO - SKIP
5238 023010 005737 014446 TST MISWIW ;TEST IF MANUAL INTERVENTION
5239 023014 100072 BPL 65$ ;NO - SKIP
5240 023016 012737 006015 002424 MOV #MISTST,ERHEAD ;SET ERROR HEADER
5241 023024 2$: PRINTF #FMTOP1,#OPR2,#OPR1A,#BASADD,RLBAS,#DRVNAM,<B,RLDRV+1> ;REQUEST CLOSE
(13) 023024 005046 CLR -(SP)
(13) 023026 153716 002445 BISB RLDRV+1,(SP)
(12) 023032 012746 005423 MOV #DRVNAM,-(SP)
(11) 023036 013746 002440 MOV RLBAS,-(SP)
(10) 023042 012746 005412 MOV #BASADD,-(SP)
(9) 023046 012746 010206 MOV #OPR1A,-(SP)
(8) 023052 012746 007642 MOV #OPR2,-(SP)
(7) 023056 012746 011606 MOV #FMTOP1,-(SP)
(6) 023062 012746 000007 MOV #7,-(SP)
(3) 023066 010600 MOV SP,RO
(4) 023070 104017 EMT C$PNTF
(4) 023072 062706 000020 ADD #20,SP
5242 ;COVER AND RESET WRITE LOCK
5243 023076 005037 003656 CLR OBUFF ;CLEAR FOR RESPONSE
5244 023102 GMANIL #OPR002,OBUFF,1,NO
(3) 023102 104043 EMT CSGMAN
(3) 023104 000404 BR 10000$
(4) 023106 003656 .WORD OBUFF
(5) 023110 000120 .WORD T$CODE
(5) 023112 007514 .WORD #OPR002
(5) 023114 000001 .WORD 1
(3) 023116 10000$:
5245 023116 005737 003656 TST OBUFF ;TEST IF RESPONSE YES
5246 023122 001740 BEQ 2$ ;NO - SKIP
5247 023124 004737 016202 1$: JSR PC,TSTINT ;INITIALIZE TEST
5248 023130 004737 016220 JSR PC,G$STATR ;GET STATUS WITH RESET
5249 023134 023202 #65$
5250 023136 032737 000040 002464 BIT #COSTAT,T.MP ;TEST IF COVER OPEN RESET
5251 023144 001405 BEQ 9$ ;YES - SKIP
5252 023146 012703 010662 MOV #MCOSTA,R3 ;SET NAME MESSAGE POINTER
5253 023152 ERRHRD 201,ERR2
(3) 023152 104443 TRAP T$ERCODE
(5) 023154 000311 .WORD 201
(5) 023156 012676 .WORD ERR2
5254 023160 032737 020000 002464 9$: BIT #WLSTAT,T.MP ;TEST IF WRITE LOCK RESET
5255 023166 001405 BEQ 65$ ;YES - SKIP
5256 023170 012703 010710 MOV #MWLSTA,R3 ;SET NAME MESSAGE POINTER
5257 023174 ERRHRD 202,ERR2
(3) 023174 104443 TRAP T$ERCODE
(5) 023176 000312 .WORD 202
(5) 023200 012676 .WORD ERR2
5258 023202 65$:
5259 023202 ENDTST
(3) 023202 L10021:
(3) 023202 104001 EMT C$SETST
5260

```



M06

OUTERR MACY11 30(1046) 04-NOV-77 13:14 PAGE 84-3  
 DZRLCA.P11 05-OCT-77 10:52 \*TEST 3

HEAD LOADING

SEQ 0077

```

5262          .SBTTL *TEST 3          HEAD LOADING
5263          BGNTST                  ;TEST03
(3) 023204          005737 002652          TST      PASNUM          ;TEST IF PASS 0
5264 023204          001003          BNE      4$              ;NO SKIP
5265 023210          005737 014446          TST      MISWIW         ;TEST IF MANUAL INTERVENTION
5266 023212          100402          BMI      5$              ;YES - SKIP
5267 023216          104032          4$:     EXIT      TST
(3) 023220          001214          EMT      C$EXIT
(3) 023222          004737 016202          .WORD   L10022-
5269 023224          004737 016220          JSR      PC,TSTINT     ;INITIALIZE TEST
5270 023230          024436          JSR      PC,GSTATR     ;GET STATUS
5271 023234          005737 002472          #T365$  T$STAT          ;TEST IF STATE ZERO
5272 023236          001440          BEQ      2$              ;YES - SKIP
5273 023242          005046          1$:     PRINTF   #FMTOP1,#OPR5,#OPR1A,#BASADD,RLBAS,#DRVNAM,<B,RLDRV+1> ;REQUEST DRIVE BE
5274 023244          153716 002445          CLR      -(SP)
(13) 023246          012746 005423          BISB    RLDRV+1,(SP)
(12) 023252          013746 002440          MOV     #DRVNAM,-(SP)
(11) 023256          012746 005412          MOV     RLBAS,-(SP)
(10) 023262          012746 010206          MOV     #BASADD,-(SP)
(9) 023266          012746 007710          MOV     #OPR1A,-(SP)
(8) 023272          012746 011606          MOV     #OPR5,-(SP)
(7) 023276          012746 000007          MOV     #FMTOP1,-(SP)
(6) 023302          010600          MOV     #7,-(SP)
(3) 023306          104017          MOV     SP,RO
(4) 023310          062706 000020          EMT     C$PNTF
(4) 023312          005037 003656          ADD     #20,SP
5275 023316          005037 003656          CLR     O$BUFF          ;CLEAR FOR RESPONSE
5276 023322          104043          G$MANIL #OPROD2,O$BUFF,1,NO
(3) 023322          000404          EMT     C$G$MAN
(3) 023324          000120          BR      10000$
(4) 023326          007514          .WORD   O$BUFF
(5) 023330          000001          .WORD   T$CODE
(5) 023332          005737 003656          .WORD   #OPROD2
(5) 023334          001740          .WORD   1
(3) 023336          005737 003656          10000$: TST     O$BUFF          ;TEST IF RESPONSE YES
5277 023336          001740          BEQ     1$              ;NO - SKIP
5278 023342          005046          2$:     PRINTF   #FMTOP1,#OPR3,#OPR1A,#BASADD,RLBAS,#DRVNAM,<B,RLDRV+1>
(13) 023344          153716 002445          CLR     -(SP)
(12) 023352          012746 005423          BISB    RLDRV+1,(SP)
(11) 023356          013746 002440          MOV     #DRVNAM,-(SP)
(10) 023362          012746 005412          MOV     RLBAS,-(SP)
(9) 023366          012746 010206          MOV     #BASADD,-(SP)
(8) 023372          012746 007674          MOV     #OPR1A,-(SP)
(7) 023376          012746 011606          MOV     #OPR3,-(SP)
(6) 023402          012746 000007          MOV     #FMTOP1,-(SP)
(3) 023406          010600          MOV     #7,-(SP)
(4) 023410          104017          MOV     SP,RO
(4) 023412          062706 000020          EMT     C$PNTF
5280 023416          012737 000004 002416          ADD     #20,SP
5281 023424          012703 000001          MOV     #CYLUP,OPFLAG ;SET CYCLE UP FLAG
5282 023430          012737 006040 002424          MOV     #1,R3          ;SET EXPECTED STATE VALUE
5283 023436          012701 000454          MOV     #NSTACHG,ERHEAD ;SET ERROR HEADER
          MOV     #300.,R1          ;SET WAIT COUNT FOR 30 SECONDS
  
```



5284	023442	004737	016234	3\$:	JSR	PC,GSTATC	;GET STATUS
5285	023446	024436			#T365\$		
5286	023450	005737	002472		TST	T,STAT	;TEST IF STATE IS STILL 0
5287	023454	001022			BNE	10\$	;NO - SKIP
5288	023456	005301			DEC	R1	;DEC WAIT COUNT
5289	023460	001404			BEQ	6\$	;EXIT IF WAIT DONE
5290	023462				WAITMS	#1	
(3)	023462	012700	000001		MOV	#1,R0	
(3)	023466	104026			EMT	CSWTM	
5291	023470	000764			BR	3\$	
5292	023472	005037	003656	6\$:	CLR	OBUFF	;CLEAR FOR RESPONSE
5293	023476				GMANIL	#OPRO03,OBUFF,1,NO	
(3)	023476	104043			EMT	CSGMAN	
(3)	023500	000404			BR	10001\$	
(4)	023502	003656			.WORD	OBUFF	
(5)	023504	000120			.WORD	TSCODE	
(5)	023506	007541			.WORD	#OPRO03	
(5)	023510	000001			.WORD	1	
(3)	023512			10001\$:			
5294	023512	005737	003656		TST	OBUFF	;TEST IF RESPONSE YES
5295	023516	001004			BNE	11\$	;YES - REPORT
5296	023520	000651			BR	1\$	
5297	023522	020337	002472	10\$:	CMP	R3,T,STAT	;CHECK IF NOW STATE 1
5298	023526	001405			BEQ	13\$	;YES - SKIP
5299	023530			11\$:	ERRHRD	301,ERR7	
(3)	023530	104443			TRAP	T\$ERRCODE	
(5)	023532	000455			.WORD	301	
(5)	023534	014010			.WORD	ERR7	
5300	023536				EXIT	TST	
(3)	023536	104032			EMT	C\$EXIT	
(3)	023540	000676			.WORD	L10022-	
5301	023542	012701	000454	13\$:	MOV	#300,R1	;SET WAIT FOR 90 SECONDS
5302	023546	012703	000002		MOV	#2,R3	;SET EXPECTED STATE VALUE
5303	023552	004737	016234	14\$:	JSR	PC,GSTATC	;GET STATUS
5304	023556	024436			#T365\$		
5305	023560	020337	002472		CMP	R3,T,STAT	;CHECK IF STATE 2
5306	023564	001435			BEQ	20\$	;YES - SKIP
5307	023566	101005			BHI	17\$	;CHECK IF NO CHANGE - YES - SKIP
5308	023570				ERRHRD	302,ERR7	
(3)	023570	104443			TRAP	T\$ERRCODE	
(5)	023572	000456			.WORD	302	
(5)	023574	014010			.WORD	ERR7	
5309	023576				EXIT	TST	
(3)	023576	104032			EMT	C\$EXIT	
(3)	023600	000636			.WORD	L10022-	
5310	023602	005301		17\$:	DEC	R1	;DEC WAIT COUNT
5311	023604	001404			BEQ	18\$	;SKIP IF 0
5312	023606				WAITMS	#1	
(3)	023606	012700	000001		MOV	#1,R0	
(3)	023612	104026			EMT	CSWTM	
5313	023614	000756			BR	14\$	
5314	023616			18\$:	ERRHRD	303,ERR7	
(3)	023616	104443			TRAP	T\$ERRCODE	
(5)	023620	000457			.WORD	303	
(5)	023622	014010			.WORD	ERR7	
5315	023624	032737	004000 002464		BIT	#SPDSTAT,T.MP	;TEST IF SPINDLE TIMEOUT



5316	023632	001010			BNE	19\$		:YES - SKIP
5317	023634	012737	006052	002424	MOV	#SPDERR,ERHEAD		:SET ERROR HEADER
5318	023642	012703	010762		MOV	#MSPERR,R3		:SET NAME MESSAGE POINTER
5319	023646				ERRHRD	304,ERR3		
(3)	023646	104443			TRAP	T\$ERRCODE		
(5)	023650	000460			.WORD	304		
(5)	023652	012744			.WORD	ERR3		
5320	023654			19\$:	EXIT	TST		
(3)	023654	104032			EMT	C\$EXIT		
(3)	023656	000560			.WORD	L10022-		
5321	023660	012737	006015	002424	20\$:	MOV	#MISTST,ERHEAD	:SET ERROR HEADER
5322	023666	012704	011462		MOV	#STATE2,R4		:SET CONDITION MESSAGE POINTER
5323	023672	012703	010675		MOV	#MBHSTA,R3		:SET NAME MESSAGE POINTER
5324	023676	032737	000010	002464	BIT	#BHSTAT,T.MP		:TEST IF BRUSH HOME STILL SET
5325	023704	001005			BNE	22\$		:YES - SKIP
5326	023706				ERRHRD	305,ERR5		
(3)	023706	104443			TRAP	T\$ERRCODE		
(5)	023710	000461			.WORD	305		
(5)	023712	013062			.WORD	ERR5		
5327	023714				EXIT	TST		
(3)	023714	104032			EMT	C\$EXIT		
(3)	023716	000520			.WORD	L10022-		
5328	023720	012701	000062		22\$:	MOV	#50,R1	:SET WAIT COUNT FOR 5 SECONDS
5329	023724	004737	016234		23\$:	JSR	PC,G\$STATC	:GET STATUS
5330	023730	024436				#T365\$		
5331	023732	032737	000010	002464	BIT	#BHSTAT,T.MP		:TEST IF BRUSH HOME RESET
5332	023740	001413			BEQ	27\$		:YES - SKIP
5333	023742	005301			DEC	R1		:DEC WAIT COUNT
5334	023744	001404			BEQ	26\$		:SKIP IF ZERO
5335	023746				WAITMS	#1		
(3)	023746	012700	000001		MOV	#1,R0		
(3)	023752	104026			EMT	C\$WTM		
5336	023754	000763			BR	23\$		:LOOP
5337	023756			26\$:	ERRHRD	306,ERR4		
(3)	023756	104443			TRAP	T\$ERRCODE		
(5)	023760	000462			.WORD	306		
(5)	023762	013012			.WORD	ERR4		
5338	023764				EXIT	TST		
(3)	023764	104032			EMT	C\$EXIT		
(3)	023766	000450			.WORD	L10022-		
5339	023770	012701	000454		27\$:	MOV	#300,R1	:SET WAIT COUNT 30 SECONDS
5340	023774	004737	016234		28\$:	JSR	PC,G\$STATC	:GET STATUS
5341	024000	024436				#T365\$		
5342	024002	032737	000010	002464	BIT	#BHSTAT,T.MP		:TEST IF BRUSH HOME SET AGAIN
5343	024010	001013			BNE	32\$		:YES - SKIP
5344	024012	005301			DEC	R1		:ELSE DEC WAIT COUNT
5345	024014	001404			BEQ	30\$		:SKIP IF 0
5346	024016				WAITMS	#1		
(3)	024016	012700	000001		MOV	#1,R0		
(3)	024022	104026			EMT	C\$WTM		
5347	024024	000763			BR	28\$		
5348	024026			30\$:	ERRHRD	307,ERR5		
(3)	024026	104443			TRAP	T\$ERRCODE		
(5)	024030	000463			.WORD	307		
(5)	024032	013062			.WORD	ERR5		
5349	024034				EXIT	TST		



(3)	024034	104032				EMT	CSEXIT		
(3)	024036	000400				.WORD	L10022-		
5350	024040	012737	006040	002424	32\$:	MOV	#NSTACHG,ERHEAD	;SET ERROR HEADER	
5351	024046	012703	000003			MOV	#3,R3	;SET EXPECTED STATE VALUE	
5352	024052	004737	016234			JSR	PC,GSTATC	;GET STATUS	
5353	024056	024436				T365\$			
5354	024060	020337	002472			CMP	R3,T.STAT	;CHECK IF STATE 3	
5355	024064	001405				BEG	36\$	;YES - SKIP	
5356	024066					ERRHRD	308,ERR7		
(3)	024066	104443				TRAP	T\$ERRCODE		
(5)	024070	000464				.WORD	308		
(5)	024072	014010				.WORD	ERR7		
5357	024074					EXIT	TST		
(3)	024074	104032				EMT	CSEXIT		
(3)	024076	000340				.WORD	L10022-		
5358	024100	012737	006015	002424	36\$:	MOV	#MISTST,ERHEAD	;SET ERROR HEADER	
5359	024106	012704	011472			MOV	#STATE3,R4	;SET CONDITION MESSAGE POINTER	
5360	024112	012703	010721			MOV	#MHOSTA,R3	;SET NAME MESSAGE POINTER	
5361	024116	004737	016234			JSR	PC,GSTATC	;GET STATUS	
5362	024122	024436				#T365\$			
5363	024124	032737	000020	002464		BIT	#HOSTAT,T.MP	;TEST IF HEADS OUT SET	
5364	024132	001005				BNE	38\$	;YES - SKIP	
5365	024134					ERRHRD	309,ERR5		
(3)	024134	104443				TRAP	T\$ERRCODE		
(5)	024136	000465				.WORD	309		
(5)	024140	013062				.WORD	ERR5		
5366	024142					EXIT	TST		
(3)	024142	104032				EMT	CSEXIT		
(3)	024144	000272				.WORD	L10022-		
5367	024146	032737	001000	002464	38\$:	BIT	#VCSTAT,T.MP	;TEST IF VOLUME CHECK SET	
5368	024154	001007				BNE	40\$		
5369	024156	012703	010651			MOV	#MVOLCK,R3	;SET NAME MESSAGE POINTER	
5370	024162					ERRHRD	310,ERR5		
(3)	024162	104443				TRAP	T\$ERRCODE		
(5)	024164	000466				.WORD	310		
(5)	024166	013062				.WORD	ERR5		
5371	024170					EXIT	TST		
(3)	024170	104032				EMT	CSEXIT		
(3)	024172	000244				.WORD	L10022-		
5372	024174	032737	040000	002456	40\$:	BIT	#DRVERR,T.CS	;TEST IF DRIVE ERROR SET	
5373	024202	001007				BNE	42\$	;YES - SKIP	
5374	024204	012703	010623			MOV	#MDRERR,R3	;SET NAME MESSAGE POINTER	
5375	024210					ERRHRD	311,ERR5		
(3)	024210	104443				TRAP	T\$ERRCODE		
(5)	024212	000467				.WORD	311		
(5)	024214	013062				.WORD	ERR5		
5376	024216					EXIT	TST		
(3)	024216	104032				EMT	CSEXIT		
(3)	024220	000216				.WORD	L10022-		
5377	024222	012701	005670		42\$:	MOV	#3000,R1	;SET WAIT COUNT FOR 300 MS	
5378	024226	012737	006040	002424		MOV	#NSTACHG,ERHEAD	;SET ERROR HEADER	
5379	024234	012703	000004			MOV	#4,R3	;SET EXPECTED STATE VALUE	
5380	024240	004737	016234		43\$:	JSR	PC,GSTATC	;GET STATUS	
5381	024244	024436				#T365\$			
5382	024246	020337	002472			CMP	R3,T.STAT	;CHECK IF STATE 4	
5383	024252	001413				BEG	49\$	;YES - SKIP	



```

5384 024254 005301 DEC R1 ;DEC WAIT COUNT
5385 024256 001404 BEQ 47$ ;SKIP IF 0
5386 024260 WAITUS #1
(3) 024260 012700 000001 MOV #1,RO
(3) 024264 104027 EMT CSWTU
5387 024266 000764 BR 43$
5388 024270 47$: ERRHRD 312 ERR7
(3) 024270 104443 TRAP T$ERCODE
(5) 024272 000470 .WORD 312
(5) 024274 014010 .WORD ERR7
5389 024276 EXIT TST
(3) 024276 104032 EMT C$EXIT
(3) 024300 000136 .WORD L10022-
5390 024302 012701 000454 49$: MOV #300,R1 ;SET WAIT COUNT FOR 30 MS
5391 024306 012703 000005 MOV #5,R3 ;SET EXPECTED STATE VALUE
5392 024312 004737 016234 50$: JSR PC,G$STATC ;GET STATUS
5393 024316 024436 #T365$
5394 024320 020337 002472 CMP R3,T$STAT ;CHECK IF STATE 5
5395 024324 001413 BEQ 55$ ;YES - SKIP
5396 024326 005301 DEC R1 ;DEC WAIT COUNT
5397 024330 001404 BEQ 51$ ;ELSE SKIP
5398 024332 WAITUS #1
(3) 024332 012700 000001 MOV #1,RO
(3) 024336 104027 EMT CSWTU
5399 024340 000764 BR 50$
5400 024342 51$: ERRHRD 313 ERR7
(3) 024342 104443 TRAP T$ERCODE
(5) 024344 000471 .WORD 313
(5) 024346 014010 .WORD ERR7
5401 024350 EXIT TST
(3) 024350 104032 EMT C$EXIT
(3) 024352 000064 .WORD L10022-
5402 024354 012701 000120 55$: MOV #80,R1 ;SET WAIT FOR 8 MS
5403 024360 004737 016234 56$: JSR PC,G$STATC ;GET STATUS
5404 024364 024436 #T365$
5405 024366 032737 000001 002456 BIT #DRDYMSK,T$CS ;CHECK IF DRIVE READY
5406 024374 001020 BNE 62$ ;YES - SKIP
5407 024376 005301 DEC R1 ;DEC COUNT
5408 024400 001404 BEQ 60$ ;SKIP IF 0
5409 024402 WAITUS #1
(3) 024402 012700 000001 MOV #1,RO
(3) 024406 104027 EMT CSWTU
5410 024410 000763 BR 56$
5411 024412 012737 006015 002424 60$: MOV #MISTST,ERHEAD ;SET ERROR HEADER
5412 024420 012704 011502 MOV #STATES,R4 ;SET CONDITION MESSAGE POINTER
5413 024424 012703 010501 MOV #MDRDY,R3 ;SET NAME MESSAGE POINTER
5414 024430 ERRHRD 314 ERRS
(3) 024430 104443 TRAP T$ERCODE
(5) 024432 000472 .WORD 314
(5) 024434 013062 .WORD ERRS
5415
5416 024436 62$:
5417 024436 T365$:
5418 024436 ENDTST
(3) 024436 L10022:
(3) 024436 104001 EMT C$ETST

```

E07

OUTERR MACY11 30(1046) 04-NOV-77 13:14 PAGE 84-8  
DZRLCA.P11 05-OCT-77 10:52 \*TEST 4

HEAD UNLOADING

SEG 0082

```

5420          SBTTL *TEST 4          HEAD UNLOADING
5421          BGNTST                ;TEST04
(3)          024440
5422          024440 005737 002652      TST      PASNUM      ;TEST IF FIRST PASS
5423          024444 001003                BNE      B$          ;NO - SKIP
5424          024446 005737 014446      TST      MISWIW     ;TEST IF MANUAL INTERVENTION
5425          024452 100402                BMI      10$        ;YES - SKIP
5426          024454          8$:      EXIT TST
(3)          024454 104032                EMT      C$EXIT
(3)          024456 000566                .WORD   L10023-.
5427          024460          10$:
5428          024460          BGNSUB
(3)          024460 104002                EMT      CSBSUB
(3)          024460 012737 006040 002424  MOV     #NSTACHG,ERHEAD ;SET ERROR HEADER
5429          024462 012737 006040 002424  JSR     PC,TSTINT    ;INITIALIZE TEST
5430          024470 004737 016202                JSR     PC,GSTATR   ;GET STATUS
5431          024474 004737 016220                JSR     #T465$
5432          024500 025134                BIT     #DRDYMSK,T.CS ;CHECK IF DRIVE READY
5433          024502 032737 000001 002456  BNE     3$          ;YES - SKIP
5434          024510 001040          1$:      PRINTF  #FMTOP1,#OPR6,#OPR1A,#BASADD,RLBAS,#DRVNAM,<B,RLDRV+1>
(13)         024512 005046                CLR     -(SP)
(13)         024514 153716 002445                BISB   RLDRV+1,(SP)
(12)         024520 012746 005423                MOV     #DRVNAM,-(SP)
(11)         024524 013746 002440                MOV     RLBAS,-(SP)
(10)         024530 012746 005412                MOV     #BASADD,-(SP)
(9)          024534 012746 010206                MOV     #OPR1A,-(SP)
(8)          024540 012746 007752                MOV     #OPR6,-(SP)
(7)          024544 012746 011606                MOV     #FMTOP1,-(SP)
(6)          024550 012746 000007                MOV     #7,-(SP)
(3)          024554 010600                MOV     SP,R0
(4)          024556 104017                EMT     C$PNTF
(4)          024560 062706 000020                ADD     #20,SP
5436          024564 005037 003656                CLR     OBUF
5437          024570          GMANIL  #OPR02,OBUF,1,NO ;CLEAR FOR RESPONSE
(3)          024570 104043                EMT     C$GMAN
(3)          024572 000404                BR      10000$
(4)          024574 003656                .WORD  OBUF
(5)          024576 000120                .WORD  T$CODE
(5)          024600 007514                .WORD  #OPR02
(5)          024602 000001                .WORD  1
(3)          024604          10000$:
5438          024604 005737 003656                TST     OBUF        ;TST RESPONSE YES
5439          024610 001740                BEQ     1$          ;NO - SKIP
5440
5441          024612 052737 000010 002416  3$:      BIS     #ULOAD,OPFLAG ;SET UNLOAD OPERATION
5442          024620          4$:      PRINTF  #FMTOP1,#OPR3,#OPR1A,#BASADD,RLBAS,#DRVNAM,<B,RLDRV+1>
(13)         024620 005046                CLR     -(SP)
(13)         024622 153716 002445                BISB   RLDRV+1,(SP)
(12)         024626 012746 005423                MOV     #DRVNAM,-(SP)
(11)         024632 013746 002440                MOV     RLBAS,-(SP)
(10)         024636 012746 005412                MOV     #BASADD,-(SP)
(9)          024642 012746 010206                MOV     #OPR1A,-(SP)
(8)          024646 012746 007674                MOV     #OPR3,-(SP)
(7)          024652 012746 011606                MOV     #FMTOP1,-(SP)
(6)          024656 012746 000007                MOV     #7,-(SP)

```



(3)	024662	010600		MOV	SP, R0	
(4)	024664	104017		EMT	C\$PNTF	
(4)	024666	062706	000020	ADD	#20, SP	
5443	024672	012703	000006	MOV	#6, R3	: SET EXPECTED STATE VALUE
5444	024676	012704	000144	MOV	#100., R4	: SET SECOND LEVEL COUNT
5445	024702	012701	001274	MOV	#700., R1	: SET WAIT COUNT FOR 30 SECONDS
5446	024706	004737	016234	5\$: JSR	PC, GSTATC	: GET STATUS
5447	024712	025134			T465\$	
5448	024714	020337	002472	CMP	R3, T.STAT	: CHECK IF STATE 6
5449	024720	001436		BEQ	11\$	: YES - SKIP
5450	024722	022737	000005 002472	CMP	#5, T.STAT	: TEST IF STATE 5
5451	024730	001025		BNE	9\$	: NO - REPORT WRONG STATE
5452	024732	005304		8\$: DEC	R4	: DEC 2ND LEVEL COUNT
5453	024734	001004		BNE	6\$	: SKIP IF NOT 0
5454	024736	005301		DEC	R1	: ELSE DEC 1ST LEVEL COUNT
5455	024740	001406		BEQ	7\$	: IF 0 - SKIP TO QUESTION
5456	024742	012704	000144	MOV	#100., R4	: ELSE RESET 2ND LEVEL
5457	024746			6\$: WAITUS	#1	: WAIT 100 US
(3)	024746	012700	000001	MOV	#1, R0	
(3)	024752	104027		EMT	C\$WTU	
5458	024754	000754		BR	5\$	
5459	024756	005037	003656	7\$: CLR	OBUFF	: CLEAR FOR RESPONSE
5460	024762			GMANIL	#OPR003, OBUFF, 1, NO	
(3)	024762	104043		EMT	C\$GMAN	
(3)	024764	000404		BR	10001\$	
(4)	024766	003656		.WORD	OBUFF	
(5)	024770	000120		.WORD	T\$CODE	
(5)	024772	007541		.WORD	#OPR003	
(5)	024774	000001		.WORD	1	
(3)	024776			10001\$: TST	OBUFF	: TEST IF RESPONSE YES
5461	024776	005737	003656	BEQ	4\$	: NO - SKIP
5462	025002	001706		9\$: ERRHRD	401, ERR7	: ELSE REPORT STATE CHANGE WRONG
5463	025004			TRAP	T\$ERRCODE	
(3)	025004	104443		.WORD	401	
(5)	025006	000621		.WORD	ERR7	
(5)	025010	014010		EXIT	SUB	
5464	025012			EMT	C\$EXIT	
(3)	025012	104032		.WORD	L10024-	
(3)	025014	000126		11\$: MOV	#7, R3	: SET EXPECTED STATE VALUE
5465	025016	012703	000007	MOV	#3000., R1	: SET COUNT FOR 300MS
5466	025022	012701	005670	12\$: JSR	PC, GSTATC	: GET STATUS
5467	025026	004737	016234		#T465\$	
5468	025032	025134		CMP	R3, T.STAT	: CHECK IF STATE 7
5469	025034	020337	002472	BEQ	18\$	: YES - SKIP
5470	025040	001413		DEC	R1	: DEC WAIT COUNT
5471	025042	005301		BEQ	16\$	: SKIP IF 0
5472	025044	001404		WAITUS	#1	
5473	025046			MOV	#1, R0	
(3)	025046	012700	000001	EMT	C\$WTU	
(3)	025052	104027		BR	12\$	
5474	025054	000764		16\$: ERRHRD	402, ERR7	: REPORT WRONG STATE CHANGE
5475	025056			TRAP	T\$ERRCODE	
(3)	025056	104443		.WORD	402	
(5)	025060	000622		.WORD	ERR7	
(5)	025062	014010		EXIT	SUB	
5476	025064					

```

(3) 025064 104032 EMT CSEXIT
(3) 025066 000054 .WORD L10024-.
5477 025070 005003 18$: CLR R3 ;SET EXPECTED STATE VALUE
5478 025072 012701 001130 MOV #600, R1 ;SET WAIT COUNT FOR 60 SECONDS
5479 025076 004737 016234 20$: JSR PC, GSTATC ;GET STATUS
5480 025102 025134 #T465$
5481 025104 005737 002472 TST T. STAT ;CHECK IF STATE 0
5482 025110 001411 BEQ 24$ ;YES - SKIP
5483 025112 005301 DEC R1 ;DEC WAIT COUNT
5484 025114 001404 BEQ 22$ ;SKIP IF 0
5485 025116 WAITMS #1
(3) 025116 012700 000001 MOV #1, R0
(3) 025122 104026 EMT CSWTM
5486 025124 000764 BR 20$
5487 025126 22$: ERRHRD 403, ERR7 ;REPORT WRONG STATE CHANGE
(3) 025126 104443 TRAP T$ERRCODE
(5) 025130 000623 .WORD 403
(5) 025132 014010 .WORD ERR7
5488 025134 24$:
5489 025134 012737 000002 002430 T465$: MOV #2, ERRSWI ;INIT ERROR SWITCH
5490
5491 025142 ENDSUB
(3) 025142 L10024:
(3) 025142 104003
5492 025144 26$: EMT C$ESUB
(13) 025144 005046 PRINTF #FMTOP1, #OPR6, #OPR1A, #BASADD, RLBAS, #DRVNAM, <B, RLDV+1> ;REQUEST CYCLE UP
(13) 025146 153716 002445 CLR -(SP)
(12) 025152 012746 005423 BISB RLDV+1, (SP)
(11) 025156 013746 002440 MOV #DRVNAM, -(SP)
(10) 025162 012746 005412 MOV RLBAS, -(SP)
(9) 025166 012746 010206 MOV #BASADD, -(SP)
(8) 025172 012746 007752 MOV #OPR1A, -(SP)
(7) 025176 012746 011606 MOV #OPR6, -(SP)
(6) 025202 012746 000007 MOV #FMTOP1, -(SP)
(3) 025206 010600 MOV #7, -(SP)
(4) 025210 104017 MOV SP, R0
(4) 025212 062706 000020 EMT C$PNTF
5493 025216 005037 003656 ADD #20, SP
5494 025222 CLR OBUFF ;CLEAR FOR RESPONSE
(3) 025222 104043 GMANIL #OPROD2, OBUFF, 1, NO
(3) 025224 000404 EMT C$GMAN
(4) 025226 003656 BR 10000$
(5) 025230 000120 .WORD OBUFF
(5) 025232 007514 .WORD T$CODE
(5) 025234 000001 .WORD #OPROD2
(3) 025236 10000$: .WORD 1
5495 025236 005737 003656 10000$: TST OBUFF ;TEST RESPONSE YES
5496 025242 001740 29$: BEG 26$ ;NO - SKIP
5497 025244
5498
5499 025244 ENDTST
(3) 025244 L10023:
(3) 025244 104001 EMT C$ETST

```



```

5501 .SBTTL *TEST 5 DRIVE SELECT
5502 BGNTST ;TEST05
5503 (3) 025246 012737 000002 002430 MOV #2,ERRSWI ;SET FOR NO ERROR RETURN TS::
5504 025246 005737 002652 TST PASNUM ;TEST IF FIRST PASS
5505 025260 001173 BNE EXT05 ;NO - SKIP
5506 025262 032737 000004 014446 BIT #DRSELT,MISWIW ;TEST IF SELECT TESTS
5507 025270 001567 BEQ EXT05 ;NO - SKIP
5508 1$: PRINTF #FMTOP1,#OPR7,#OPR1A,#BASADD,RLBAS,#DRVNAM,<B,RLDRV+1> ;REQUEST REMOVE A
(13) 025272 005046 CLR -(SP)
(13) 025274 153716 002445 BISB RLDRV+1,(SP)
(12) 025300 012746 005423 MOV #DRVNAM,-(SP)
(11) 025304 013746 002440 MOV RLBAS,-(SP)
(10) 025310 012746 005412 MOV #BASADD,-(SP)
(9) 025314 012746 010206 MOV #OPR1A,-(SP)
(8) 025320 012746 010005 MOV #OPR7,-(SP)
(7) 025324 012746 011606 MOV #FMTOP1,-(SP)
(6) 025330 012746 000007 MOV #7,-(SP)
(3) 025334 010600 MOV SP,RO
(4) 025336 104017 EMT C$PNTF
(4) 025340 062706 000020 ADD #20,SP
5509 025344 005037 003656 CLR OBUFF ;CLEAR FOR RESPONSE
5510 025350 GMANIL #OPR002,OBUFF,1,NO
(3) 025350 104043 EMT CSGMAN
(3) 025352 000404 BR 10000$
(4) 025354 003656 .WORD OBUFF
(5) 025356 000120 .WORD T$CODE
(5) 025360 007514 .WORD #OPR002
(5) 025362 000001 .WORD 1
(3) 025364 10000$: TST OBUFF ;TEST RESPONSE YES
5511 025364 005737 003656 BEQ 1$ ;NO - SKIP
5512 025370 001740 3$: MOV #TOSERR,ERHEAD ;SET ERROR HEADER MESSAGE
5513 025372 012737 006152 002424 JSR PC,T$TINT ;INITIALIZE TEST
5514 025400 004737 016202 JSR PC,G$STATC ;DO SELECT AND GET STATUS
5515 025404 004737 016234 #T504$
5516 025410 025572 MOV RLDV,TEMPO ;STORE ORIGINAL DRIVE NUMBER
5517 025412 013737 002444 002530 MOV RLDV,R1 ;PUT IT IN R1
5518 025420 013701 002444 MOV #4,R4 ;SET COUNT FOR NUMBER OF PLUGS
5519 025424 012704 000004 LPT05: ADD #400,R1 ;BUMP TO NEXT DRIVE
5520 025430 062701 000400 CMP #2000,R1 ;CHECK IF TOO LARGE
5521 025434 022701 002000 BNE 4$ ;NO - SKIP
5522 025440 001001 CLR R1 ;ELSE CLEAR TO DRIVE 0
5523 025442 005001 MOV R1,RLDRV ;PUT IT BACK IN RLDV
5524 025444 010137 002444 4$: PRINTF #FMTOP3,#OPR8,<B,RLDRV+1>,#OPR1B,#UNDTST
5525 025450 5$: MOV #UNDTST,-(SP)
(11) 025450 012746 010222 MOV #OPR1B,-(SP)
(10) 025454 012746 010212 CLR -(SP)
(9) 025460 005046 BISB RLDRV+1,(SP)
(9) 025462 153716 002445 MOV #OPR8,-(SP)
(8) 025466 012746 010034 MOV #FMTOP3,-(SP)
(7) 025472 012746 011657 MOV #5,-(SP)
(6) 025476 012746 000005 MOV SP,RO
(3) 025502 010600 EMT C$PNTF
(4) 025504 104017 ADD #14,SP
(4) 025506 062706 000014 ;INSERT PLUG REQUEST
5526

```

```

5527 025512 005037 003656 CLR OBUFF ;CLEAR FOR RESPONSE
5528 025516 GMANIL #OPRO02,OBUFF,1,NO
(3) 025516 104043 EMT CSGMAN
(3) 025520 000404 BR 10001$
(4) 025522 003656 .WORD OBUFF
(5) 025524 000120 .WORD T$CODE
(5) 025526 007514 .WORD #OPRO02
(5) 025530 000001 .WORD 1
(3) 025532 10001$: TST OBUFF ;TEST RESPONSE YES
5529 025532 005737 003656 BEQ 5$ ;NO - SKIP
5530 025536 001744 BGNSUB
(3) 025540 TS.1:
(3) 025540 104002 EMT CSBSUB
5532 025542 004737 016234 JSR PC,GSTATC ;GET STATUS - REPORT ANY ERROR
5533 025546 025550 #60$
5534 025550 012737 000002 002430 60$: MOV #2,ERRSWI ;INIT ERROR SWITCH
5535
5536 025556 ENDSUB
(3) 025556 L10026:
(3) 025556 104003 EMT C$ESUB
5537 025560 005304 DEC R4 ;DEC COUNT
5538 025562 001322 BNE LPT05 ;LOOP IF NOT ZERO
5539 025564 013737 002530 002444 MOV TEMPO,RLDRV ;ELSE RESTORE RLDRV
5540 025572 TS04$:
5541 025572 4$: PRINTF #FMT1,#OPR8,#OPR9
(9) 025572 012746 010053 MOV #OPR9,-(SP)
(8) 025576 012746 010034 MOV #OPR8,-(SP)
(7) 025602 012746 011700 MOV #FMT1,-(SP)
(6) 025606 012746 000003 MOV #3,-(SP)
(3) 025612 010600 MOV SP,RO
(4) 025614 104017 EMT CSPNTF
(4) 025616 062706 000010 ADD #10,SP
5542 025622 005037 003656 CLR OBUFF ;CLEAR FOR RESPONSE
5543 025626 GMANIL #OPRO02,OBUFF,1,NO
(3) 025626 104043 EMT CSGMAN
(3) 025630 000404 BR 10000$
(4) 025632 003656 .WORD OBUFF
(5) 025634 000120 .WORD T$CODE
(5) 025636 007514 .WORD #OPRO02
(5) 025640 000001 .WORD 1
(3) 025642 10000$: TST OBUFF ;TEST RESPONSE YES
5544 025642 005737 003656 BEQ 4$ ;NO - SKIP
5545 025646 001751 EXT05:
5546 025650 ENDTST
(3) 025650 L10025:
(3) 025650 104001 EMT C$ETST
5548

```



```

5550          .SBTTL *TEST 6          DRIVE SELECT TEST
5551          BGNTST                ;TEST06
5552          (3) 025652                T6::
5553          025652 005737 002652      TST PASNUM          ;CHECK IF FIRST PASS
5554          025656 001004                BNE 1$              ;NO - SKIP
5555          025660 032737 000004 014446 BIT #DRSELT,MISWIW ;CHECK IF TEST DRIVE SELECT
5556          025666 001002                BNE 4$              ;YES - SKIP
5557          025670 104032                1$: EXIT TST
5558          025672 000630                EMT C$EXIT
5559          025674 012737 006106 002424 4$: .WORD L10027-
5560          025702 004737 016202                MOV #GSTER1,ERHEAD ;SET ERROR HEADER
5561          025706 013703 002654                JSR PC,TSTINT      ;INITIALIZE TEST
5562          025712 023727 002014 000001 MOV P$ETNM,R3      ;GET PARAM SET NUMBER
5563          025722 005203                CMP L$UNIT,#1      ;TEST IF MORE THAN 1 UNIT
5564          025724 020337 002014                BLOS 5$            ;NO - SKIP
5565          025730 101401                INC R3              ;BUMP PARAMETER SET NUMBER
5566          025732 005003                CMP R3,L$UNIT      ;CHECK IF PAST VALID PARAMETER TABLE
5567          025734 010300                BLOS 3$            ;NO - SKIP
5568          025736 104042                CLR R3              ;ELSE CLEAR TO POINT TO ENTRY 0
5569          025740 103370                GPHARD R3,R0
5570          025742 010004                MOV R3,R0
5571          025744 021437 002440                EMT C$GPHARD
5572          025750 001364                BNCOMPLETE 2$      ;SKIP IF NOT AVAILABLE
5573          025752 005037 002420                BCC 2$
5574          025756 012737 016250 002446 MOV R0,R4          ;PUT POINTER INTO R4
5575          025764 056437 000006 002446 CMP (R4),RLBAS    ;CHECK IF SAME CONTROLLER
5576          025772 012737 000013 002452 BNE 2$            ;NO - SKIP
5577          026000 013762 002452 000004 CLR DONE          ;CLEAR DONE FLAG
5578          026006 013762 002446 000000 MOV #GSTAT,L.CS   ;LOAD GET STATUS
5579          026014 012700 000003                BIS 6(R4),L.CS    ;INSERT DRIVE
5580          026020 104026                MOV #GETSTAT:DRSET,L.DA ;SET UP TO CLEAR DRIVE
5581          026022 005737 002420                MOV L.DA,RLDA(R2) ;LOAD DA REG
5582          026026 001735                MOV L.CS,RLCS(R2) ;LOAD CS REG
5583          026030 032737 100000 002456 WAITMS #3          ;WAIT 300 MS
5584          026036 001415                MOV #3,R0
5585          026040 000730                EMT C$WTM
5586          026042 012746 010070                TST DONE          ;TEST IF INTERRUPT
5587          026044 012746 012117                BEQ 2$            ;NO - SKIP
5588          026046 012746 000002                BIT #ANYERR,T.CS ;TEST IF ANY ERROR SET
5589          026052 012746 000002                BEQ 7$            ;NO - GO TEST
5590          026056 010600                BR 2$             ;ELSE CHECK NEXT DRIVE
5591          026060 104017                PRINTF #FMT9,#OPR10 ;REPORT CAN'T FIND 2ND DRIVE
5592          026062 062706 000006                MOV #OPR10,-(SP)
5593          026066 000137 026522                MOV #FMT9,-(SP)
5594          026072 016437 000006 002532 7$: MOV #2,-(SP)
5595          026100 013700 002444                MOV SP,R0
5596          026104 013705 002532                EMT C$PNTF
5597          026110 042700 002000                ADD #6,SP
5598          026114 042700 002000                JMP LC$EXT
5599          026120 020527 001400                MOV 6(R4),TEMP1  ;STORE NEW ADDRESS
5600          026122 000006 002532 002532 9$: MOV RLDV,R0      ;ASK FOR PLUG CHANGE
5601          026124 000006 002532 002532 MOV TEMP1,R5      ;GET DRIVE UNDER TEST
5602          026126 000006 002532 002532 BIC #2000,R0      ;GET NEW ADDRESS
5603          026128 000006 002532 002532 BIC #2000,R0      ;CLEAR FOR ADDRESS 0 TO 3
5604          026130 000006 002532 002532 BIC #2000,R0
5605          026132 000006 002532 002532 CMP R5,#1400      ;TEST IF DRIVE NUMBER 3
    
```

DRIVE SELECT TEST

```

5592 026124 001001 BNE 21$ ;NO - SKIP
5593 026126 005005 CLR R5 ;ELSE SET TO DRIVE NUMBER 0
5594 026130 062705 000400 21$: ADD #400,R5 ;BUMP TO NEXT ADDRESS
5595 026134 020500 CMP R5,R0 ;THIS EQUAL TO NEW ADDRESS?
5596 026136 001770 BEQ 20$ ;YES - SKIP
5597 026140 052705 000200 BIS #CRDYMSK,R5 ;ELSE SET CONTROLLER READY BIT
5598 026144 010562 000000 MOV R5,RLCS(R2) ;AND LOAD CS REG
5599 026150 PRINTF #FMTOP2,#OPR8,<B,RLDRV+1>,#OPR1B,<B,TEMP1+1>
(11) 026150 005046 CLR -(SP)
(11) 026152 153716 002533 BISB TEMP1+1,(SP)
(10) 026156 012746 010212 MOV #OPR1B,-(SP)
(9) 026162 005046 CLR -(SP)
(9) 026164 153716 002445 BISB RLDRV+1,(SP)
(8) 026170 012746 010034 MOV #OPR8,-(SP)
(7) 026174 012746 011635 MOV #FMTOP2,-(SP)
(6) 026200 012746 000005 MOV #5,-(SP)
(3) 026204 010600 MOV SP,R0
(4) 026206 104017 EMT C$PNTF
(4) 026210 062706 000014 ADD #14,SP
5600 026214 005037 003656 CLR OBUFF ;CLEAR FOR RESPONSE
5601 026220 GMANIL #OPR002,OBUFF,1,NO
(3) 026220 104043 EMT C$GMAN
(3) 026222 000404 BR 10000$
(4) 026224 003656 .WORD OBUFF
(5) 026226 000120 .WORD T$CODE
(5) 026230 007514 .WORD #OPR002
(5) 026232 000001 .WORD 1
(3) 026234 10000$: TST OBUFF ;TEST IF RESPONSE YES
5602 026234 005737 003656 BEQ 9$ ;NO - SKIP
5603 026240 001717 MOV #10.,R4 ;SET COUNT
5604 026242 012704 000012 BGNSUB
(3) 026246 T6.1:
(3) 026246 EMT C$BSUB
5606 026250 013737 002444 002446 8$: MOV RLDRV,L.CS ;SET UP TO SELECT MULTIPLE DRIVES
5607 026256 013762 002446 000000 MOV L.CS,RLCSR(R2) ;DO IT
5608 026264 WAITMS #10.
(3) 026264 012700 000012 MOV #10.,R0
(3) 026270 104026 EMT C$WTM
5609 026272 052737 000104 002446 BIS #GTSTAT,L.CS ;SET GET STATUS
5610 026300 012737 000003 002452 MOV #GETSTAT,L.DA
5611 026306 013762 002452 000004 MOV L.DA,RLDA(R2)
5612 026314 005037 002420 CLR DONE
5613 026320 013762 002446 000000 MOV L.CS,RLCSR(R2) ;DO GET STATUS
5614 026326 WAITUS #1 ;WAIT FOR INTERRUPT
(3) 026326 012700 000001 MOV #1,R0
(3) 026332 104027 EMT C$WTU
5615 026334 005737 002420 TST DONE ;CHECK IF INTERRUPTED
5616 026340 001012 BNE 12$ ;YES - SKIP
5617 026342 004737 016050 JSR PC,WAITN ;WAIT FOR TIMEOUT
5618 026346 012603 MOV (SP)+,R3 ;GET ERROR POINTER
5619 026350 001406 BEQ 12$ ;SKIP IF 0
5620 026352 ERRHRD 601,GSTER1,ERR1
(3) 026352 104463 TRAP T$ERCODE
(5) 026354 001131 .WORD 601
(5) 026356 006106 .WORD GSTER1

```



DRIVE SELECT TEST

(5)	026360	012630				.WORD	ERR1	
5621	026362					EXIT	SUB	
(3)	026362	104032				EMT	CSEXIT	
(3)	026364	000062				.WORD	L10030-	
5622	026366				12\$:	WAITMS	#2	;WAIT FOR DSE TO SET
(3)	026366	012700	000002			MOV	#2,RO	
(3)	026372	104026				EMT	C\$WTM	
5623	026374	004737	016250			JSR	PC,GSTAT	;GET STATUS
5624	026400	026440				60\$		
5625	026402	CJ2737	000400	002464		BIT	#DSESTAT,T.MP	;TEST IF DRIVE SELECT ERROR SET
5626	026410	001007				BNE	16\$	;YES - SKIP
5627	026412	012703	010732			MOV	#MDSERR,R3	;SET NAME MESSAGE POINTER
5628	026416					ERRHRD	602,ERR3	
(3)	026416	104443				TRAP	T\$ERRCODE	
(5)	026420	001132				.WORD	602	
(5)	026422	012744				.WORD	ERR3	
5629	026424					EXIT	SUB	
(3)	026424	104032				EMT	CSEXIT	
(3)	026426	000020				.WORD	L10030-	
5630	026430	010562	000000		16\$:	MOV	R5,RLCS(R2)	;LOAD IN DIFFERENT ADDRESS
5631	026434	005304				DEC	R4	;DEC COUNT
5632	026436	001304				BNE	8\$	;LOOP IF NOT ZERO
5633	026440	012737	000002	002430	60\$:	MOV	#2,ERRSWI	;INIT ERROR SWITCH
5634	026446					ENDSUB		
(3)	026446					L10030:		
(3)	026446	104003				EMT	C\$ESUB	
5635	026450				15\$:	PRINTF	#FMT9,#OPR11	;REQUEST PLUG CHANGE
(8)	026450	012746	010136			MOV	#OPR11,-(SP)	
(7)	026454	012746	012117			MOV	#FMT9,-(SP)	
(6)	026460	012746	000002			MOV	#2,-(SP)	
(3)	026464	010600				MOV	SP,RO	
(4)	026466	104017				EMT	C\$PNTF	
(4)	026470	062706	000006			ADD	#6,SP	
5636	026474	005037	003656			CLR	O\$UFF	;CLEAR FOR RESPONSE
5637	026500					G\$MANIL	#OPROO2,O\$UFF,1,NO	
(3)	026500	104043				EMT	C\$G\$MAN	
(3)	026502	000404				BR	10000\$	
(4)	026504	003656				.WORD	O\$UFF	
(5)	026506	000120				.WORD	T\$CODE	
(5)	026510	007514				.WORD	#OPROO2	
(5)	026512	000001				.WORD	1	
(3)	026514				10000\$:			
5638	026514	005737	003656			TST	O\$UFF	;TEST RESPONSE YES
5639	026520	001753				BEQ	15\$	;NO - SKIP
5640	026522					LCLEXT:		
(3)	026522					ENDTST		
(3)	026522					L10027:		
(3)	026522	104001				EMT	C\$ETST	

# M07

OUTERR MACY11 30(1046) 04-NOV-77 13:14 PAGE 84-16  
 DZRLCA.P11 05-OCT-77 10:52 \*TEST 7

INITIAL STATE

SEQ 0090

				.SBTTL	*TEST 7	INITIAL STATE	
				BGNTST		;TEST 07	
5643	026524						
5644	026524						
(3)	026524						
5645	026524	012737	006137	002424	MOV	#INITST,ERHEAD	;SET ERROR HEADER
5646	026532	004737	016202		JSR	PC,TSTINT	;INITIALIZE TEST
5647	026536				WAITUS	#10.	;WAIT 1 MS
(3)	026536	012700	000012		MOV	#10.,R0	
(3)	026542	104027			EMT	C\$WTU	
5648	026544	004737	016234		JSR	PC,GSTATC	;GET STATUS
5649	026550	027034			#65\$		
5650	026552	032737	000001	002456	BIT	#DRDYMSK,T.CS	;CHECK IF DRIVE READY
5651	026560	001003			BNE	3\$	;YES-SKIP
5652	026562	012703	010501		MOV	#MDRDY,R3	;SET NAME MESSAGE POINTER
5653	026566	000427			BR	9\$	;GO REPORT
5654	026570	012703	000005		MOV	#5,R3	;SET EXPECTED STATE VALUE
5655					3\$:		
5656	026574	020337	002472		CMP	R3,T.STAT	;CHECK IF STATE OK
5657	026600	001405			BEQ	5\$	;YES-SKIP
5658	026602				ERRHRD	701.,ERR7	;ELSE REPORT STATE ERROR
(3)	026602	104443			TRAP	T\$ERRCODE	
(5)	026604	001275			.WORD	701	
(5)	026606	014010			.WORD	ERR7	
5659	026610				EXIT	TST	;EXIT
(3)	026610	104032			EMT	C\$EXIT	
(3)	026612	000222			.WORD	L10031-	
5660	026614	013701	002464		MOV	T.MP,R1	;GET MP REG
5661	026620	032701	000020		BIT	#HOSTAT,R1	;CHECK HEADS OUT
5662	026624	001003			BNE	7\$	;YES-SKIP
5663	026626	012703	010721		MOV	#MHOSTA,R3	;SET NAME MESSAGE PTR
5664	026632	000405			BR	9\$	;GO REPORT
5665	026634	032701	000010		BIT	#BHSTAT,R1	;CHECK BRUSH HOME SET
5666	026640	001007			BNE	10\$	;YES-SKIP
5667	026642	012703	010675		MOV	#MBHSTA,R3	;SET NAME MESSAGE PTR
5668	026646				ERRHRD	702.,ERR3	;REPORT ERROR
(3)	026646	104443			TRAP	T\$ERRCODE	
(5)	026650	001276			.WORD	702	
(5)	026652	012744			.WORD	ERR3	
5669	026654				EXIT	TST	;EXIT
(3)	026654	104032			EMT	C\$EXIT	
(3)	026656	000156			.WORD	L10031-	
5670	026660	005737	014446		TST	MISWIW	;TEST IF MANUAL INTERVENTION RUN
5671	026664	100034			BPL	16\$	;NO-SKIP
5672	026666	005737	002652		TST	PASNUM	;CHECK IF FIRST PASS
5673	026672	001031			BNE	16\$	;NO-SKIP
5674	026674	032701	000100		BIT	#HSSTAT,R1	;ELSE CHECK HD 0 SELECTED
5675	026700	001411			BEQ	13\$	;YES-SKIP
5676	026702	012703	010634		MOV	#MHSTA,R3	;SET NAME MESSAGE PTR
5677	026706	012704	011553		MOV	#CCYLUP,R4	;SET CONDITION POINTER
5678	026712				ERRHRD	703.,ERR4	;REPORT ERROR
(3)	026712	104443			TRAP	T\$ERRCODE	
(5)	026714	001277			.WORD	703	
(5)	026716	013012			.WORD	ERR4	
5679	026720				EXIT	TST	;EXIT
(3)	026720	104032			EMT	C\$EXIT	
(3)	026722	000112			.WORD	L10031-	
5680	026724	032701	001000		BIT	#VCSTAT,R1	;CHECK VOL CHECK SET
					13\$:		



5681	026730	001003			BNE	15\$	:YES-SKIP
5682	026732	012703	010651		MOV	#MVLCK,R3	:ELSE SET NAME MESSAGE PTR
5683	026736	000743			BR	9\$	:GO REPORT
5684	026740	032737	040000	002456	BIT	#DRVERR,T,CS	:TEST DRIVE ERROR SET
5685	026746	001003			BNE	16\$	:YES-SKIP
5686	026750	012703	010623		MOV	#MDRERR,R3	:ELSE SET NAME MESSAGE PTR
5687	026754	000734			BR	9\$	:GO REPORT
5688	026756	032701	020000		BIT	#WLSTAT,R1	:CHECK WRITE LOCK STATUS
5689	026762	001405			BEQ	17\$	:SKIP IF RESET
5690	026764	012703	010710		MOV	#MWLSTA,R3	:ELSE SET NAME MESSAGE PTR
5691	026770				ERRHRD	705,ERR2	
(3)	026770	104443			TRAP	T\$ERCODE	
(5)	026772	001301			.WORD	705	
(5)	026774	012676			.WORD	ERR2	
5692	026776	042701	021177		BIC	#21177,R1	:CLEAR STAU\$ EXCEPT FOR ERROR BITS
5693	027002	005701			TST	R1	:CHECK IF ANY ERROR SET
5694	027004	001405			BEQ	19\$	:NO-SKIP
5695	027006				ERRHRD	704,ERR6	:ELSE REPORT ALL ERRORS
(3)	027006	104443			TRAP	T\$ERCODE	
(5)	027010	001300			.WORD	704	
(5)	027012	013132			.WORD	ERR6	
5696	027014				EXIT	TST	:EXIT
(3)	027014	104032			EMT	C\$EXIT	
(3)	027016	000016			.WORD	L10031-	
5697	027020	013701	002456		MOV	T,CS,R1	:GET CS REG
5698	027024	042701	141777		BIC	#141777,R1	:CLEAR ALL BUT ERROR BITS
5699	027030	005701			TST	R1	:TEST IF ANY ERROR SET
5700	027032	001365			BNE	18\$	:YES-SKIP TO REPORT
5701	027034						
5702	027034						
5703	027034						
(3)	027034						
(3)	027034	104001			EMT	C\$ETST	

```

5705
5706
5707
5708 027036          .SBTTL *TEST 8      INITIAL RESET STATE
      (3) 027036      BGNTST ;TEST 8
5709 027036 012737 006137 002424  MOV #INITST,ERHEAD      T8::
5710 027044 004737 016202          JSR PC,TSTINT          ;INITIALIZE TEST
5711
5712 027050 004737 016220          JSR PC,GSTATR          ;GET STATUS WITH RESET
5713 027054 027120          #65$
5714 027056 005737 014446          TST MISWIW          ;CHECK IF MAN INTERVENTION WAS RUN
5715 027062 100016          BPL 4$              ;NO-SKIP
5716 027064 005737 002652          TST PASNUM          ;CHECK IF 1ST PASS
5717 027070 001013          BNE 4$              ;NO-SKIP
5718 027072 032737 000100 002464  BIT #HSSTAT,T.MP    ;CHECK HD SELECT STILL 0
5719 027100 001407          BEQ 4$              ;YES-SKIP
5720 027102 012703 010634          MOV #MHSTA,R3       ;SET NAME MESSAGE PTR
5721 027106 012704 011553          MOV #CCYLUP,R4     ;SET CONDITION POINTER
5722 027112          ERRHRD 801,ERR4 ;REPORT ERROR
      (3) 027112 104443          TRAP TSERCODE
      (5) 027114 001441          .WORD 801
      (5) 027116 013012          .WORD ERR4
5723 027120          4$:
5724 027120          65$:
5725 027120          ENDTST
      (3) 027120          L10032:
      (3) 027120 104001          EMT C$ETST
5726

```



```

5728
5729
5730          .SBTTL *TEST 9          DRIVE READY
5731          BGNTST                   ;TEST 9
5732          (3) 027122                T9::
5733          027122 012737 006165 002424 MOV #TO9ERR,ERHEAD ;SET ERROR HEADER
5734          027130 012701 002514 MOV #NEWCYL,R1 ;GET POINTER TO DESIRED LOC
5735          027134 005021 CLR (R1)+ ;CLEAR NEW CYL
5736          027136 005021 CLR (R1)+ ;CLEAR CURRENT CYL
5737          027140 005021 CLR (R1)+ ;DIFFERENCE
5738          027142 005011 CLR (R1) ;SIGN
5739          027144 004737 016202 JSR PC,TSTINT ;INITIALIZE TEST
5740          027150 004737 016220 JSR PC,GSTATR ;GET STATUS WITH RESET
5741          027154 027420 #65$ JSR PC,POSHSB ;POSITION HEAD SELECTED BIT
5742          027156 004737 020264 MOV R5,DESHD ;STORE AS DESIRED HEAD
5743          027162 010537 002524 JSR PC,SIMSEK ;EXECUTE SIMPLE SEEK
5744          027166 004737 017102 JSR #65$
5745          027172 027420 #65$
5746          027174 012703 010501 MOV #MRDY,R3 ;SET NAME MESSAGE PTR
5747          027200 012704 011512 MOV #CDRDY,R4 ;SET CONDITION POINTER
5748          027204 004737 016250 JSR PC,GSTAT ;GET STATUS
5749          027210 027420 #65$
5750          027212 032737 000001 002456 BIT #DRDYMSK,T.CS ;TEST READY SET
5751          027220 001405 BEQ 4$ ;NO-SKIP
5752          (3) 027222 104443 ERRHRD 901,ERR4 ;REPORT READY ERROR
5753          (5) 027224 001605 TRAP T$ERRCODE
5754          (5) 027226 013012 .WORD 901
5755          027230 027420 .WORD ERR4
5756          (3) 027230 104032 EXIT TST ;EXIT
5757          (3) 027232 000166 EMT C$EXIT
5758          027234 012701 000121 4$: MOV #81,R1 ;SET WAIT COUNT
5759          027240 004737 016250 5$: JSR PC,GSTAT ;GET STATUS
5760          027244 027420 #65$
5761          027246 012703 000005 MOV #5,R3 ;SET EXPECTED STATE VALUE
5762          027252 023703 002472 CMP T$STAT,R3 ;CHECK STATE IS 5
5763          027256 001405 BEQ 7$ ;YES-SKIP
5764          (3) 027260 104443 ERRHRD 902,ERR7 ;ELSE REPORT
5765          (5) 027262 001606 TRAP T$ERRCODE
5766          (5) 027264 014010 .WORD 902
5767          (3) 027266 104032 EXIT TST
5768          (3) 027270 000130 EMT C$EXIT
5769          027272 012703 010501 7$: MOV #MRDY,R3
5770          027276 032737 000001 002456 BIT #DRDYMSK,T.CS ;CHECK READY SET
5771          027304 001013 BNE 12$ ;YES-SKIP
5772          027306 005301 DEC R1 ;ELSE DEC WAIT COUNT
5773          027310 001404 BEQ 9$ ;SKIP IF 0
5774          (3) 027312 012700 000001 WAITUS #1
5775          (3) 027316 104027 MOV #1,R0
5776          027320 000747 EMT C$WTU
5777          (3) 027322 104443 BR 5$
5778          (5) 027324 001607 ERRHRD 903,ERR5 ;REPORT READY ERROR
5779          (5) 027324 001607 TRAP T$ERRCODE
5780          (5) 027324 001607 .WORD 903

```

```

(5) 027326 013062 .WORD ERR5
5769 027330 EXIT TST
(3) 027330 104032 EMT C$EXIT
(3) 027332 000066 .WORD L10033-
5770
5771 027334 005737 002456 12$: TST T.CS ;TEST IF ANY ERROR
5772 027340 100005 BPL 15$ ;NO-SKIP
5773 027342 ERRHRD 904 .ERR6
(3) 027342 104443 TRAP T$ERCODE
(5) 027344 001610 .WORD 904
(5) 027346 013132 .WORD ERR6
5774 027350 EXIT TST
(3) 027350 104032 EMT C$EXIT
(3) 027352 000046 .WORD L10033-
5775 027354 012703 010634 15$: MOV #MHSTA,R3 ;SET NAME MESSAGE PTR
5776 027360 004737 020264 JSR PC,POSHSB ;POSITION HEAD SELECT BIT FOR TEST
5777 027364 020537 002524 CMP R5,DESHD ;CHECK IF CORRECT HEAD SELECTED
5778 027370 001413 BEQ 20$ ;YES-SKIP
5779 027372 005737 002524 TST DESHD ;ELSE TEST IF I DESIRED
5780 027376 001405 BEQ 17$ ;NO-REPORT SB 0
5781 027400 ERRHRD 905 .ERR3 ;ELSE REPORT SB 1
(3) 027400 104443 TRAP T$ERCODE
(5) 027402 001611 .WORD 905
(5) 027404 012744 .WORD ERR3
5782 027406 EXIT TST
(3) 027406 104032 EMT C$EXIT
(3) 027410 000010 .WORD L10033-
5783 027412 17$: ERRHRD 906 .ERR2
(3) 027412 104443 TRAP T$ERCODE
(5) 027414 001612 .WORD 906
(5) 027416 012676 .WORD ERR2
5784 027420 20$:
5785 027420 65$:
5786 027420 ENDTST
(3) 027420 L10033:
(3) 027420 104001 EMT C$ETST

```



E08

OUTERR MACY11 30(1046) 04-NOV-77 13:14 PAGE 84-21  
 DZRLCA.P11 05-OCT-77 10:52 \*TEST 10

SEEK SIGN SWITCH

SEQ 0095

5788					.SBTTL	*TEST 10	SEEK SIGN SWITCH	
5789	027422				BGNTST		;TEST 10	
(3)	027422							T10::
5790	027422	012737	006175	002424		MOV	#TIDERR,ERHEAD	;SET ERROR HEADER
5791	027430	012701	002514			MOV	#NEWCYL,R1	
5792	027434	005021				CLR	(R1)+	;CLEAR NEW CYL
5793	027436	005021				CLR	(R1)+	;CLEAR CURRENT CYLINDER
5794	027440	005021				CLR	(R1)+	;CLEAR DIFFERENCE
5795	027442	052721	000001			BIS	#BIT0,(R1)+	;SET FOR SIGN OF 1
5796	027446	004737	020264			JSR	PC,POSHSB	;GET SELECTED HEAD
5797	027452	010521				MOV	R5,(R1)+	;SET AS DESIRED HEAD
5798	027454				T104\$:			
5799	027454				BGNSUB			
(3)	027454							T10.1:
(3)	027454	104002				EMT	C\$BSUB	
5800	027456	004737	016202			JSR	PC,TSTINT	;INITIALIZE TEST
5801	027462	004737	016220			JSR	PC,GSTATR	;GET STATUS
5802	027466	027722				#60\$		
5803	027470	004737	017102			JSR	PC,SIMSEK	;DO SEEK
5804	027474	027722				#60\$		
5805	027476	012703	010501			MOV	#MDRDY,R3	;SET NAME MESSAGE PTR
5806	027502	012704	011512			MOV	#CDRDY,R4	;SET CONDITION MESSAGE PTR
5807	027506	004737	016250			JSR	PC,GSTAT	;GET STATUS
5808	027512	027722				#60\$		
5809	027514	032737	000001	002456		BIT	#DRDYMSK,T.CS	;CHECK READY RESET
5810	027522	001405				BEQ	4\$	;YES-SKIP
5811	027524					ERRHRD	1001..ERR4	;REPORT READY ERROR
(3)	027524	104443				TRAP	T\$ERCODE	
(5)	027526	001751				.WORD	1001	
(5)	027530	013012				.WORD	ERR4	
5812	027532					EXIT	SUB	;EXIT SUBTEST
(3)	027532	104032				EMT	C\$EXIT	
(3)	027534	000166				.WORD	L10035-	
5813								
5814								
5815	027536	012701	000121		4\$:	MOV	#81..R1	;SET WAIT COUNT
5816	027542	004737	016250		5\$:	JSR	PC,GSTAT	;GET STATUS
5817	027546	027722				#60\$		
5818	027550	012703	000005			MOV	#5,R3	;SET EXPECTED STATE
5819	027554	020337	002472			CMP	R3,T.STAT	;CHECK STATE IS 5
5820	027560	001405				BEQ	7\$	;YES-SKIP
5821	027562					ERRHRD	1002..ERR7	;REPORT STATE ERROR
(3)	027562	104443				TRAP	T\$ERCODE	
(5)	027564	001752				.WORD	1002	
(5)	027566	014010				.WORD	ERR7	
5822	027570					EXIT	SUB	;EXIT
(3)	027570	104032				EMT	C\$EXIT	
(3)	027572	000130				.WORD	L10035-	
5823	027574	012703	010501		7\$:	MOV	#MDRDY,R3	;SET NAME MESSAGE PTR
5824	027600	032737	000001	002456		BIT	#DRDYMSK,T.CS	;CHECK READY SET
5825	027606	001013				BNE	12\$	;YES-SKIP
5826	027610	005301				DEC	R1	;DO WAIT COUNT
5827	027612	001404				BEQ	9\$	;SKIP IF 0
5828	027614					WAITUS	#1	
(3)	027614	012700	000001			MOV	#1,R0	
(3)	027620	104027				EMT	C\$WTU	

# F08

OUTERR MACY11 30(1046) 04-NOV-77 13:14 PAGE 84-22  
 DZRLCA.P11 05-OCT-77 10:52 \*TEST 10

SEEK SIGN SWITCH

SEQ 0096

5829	027622	000747		BR	5\$	
5830						
5831	027624		9\$:	ERRHRD	1003...ERR5	;REPORT READY ERROR
(3)	027624	104443		TRAP	T\$ERCODE	
(5)	027626	001753		.WORD	1003	
(5)	027630	013062		.WORD	ERR5	
5832	027632			EXIT	SUB	;EXIT
(3)	027632	104032		EMT	C\$EXIT	
(3)	027634	000066		.WORD	L10035--	
5833	027636	005737	002456	12\$:	T.CS	;TEST IF ANY OTHER ERROR
5834	027642	100005		BPL	15\$	;NO-SKIP
5835	027644			ERRHRD	1004...ERR6	;REPORT ALL ERRORS
(3)	027644	104443		TRAP	T\$ERCODE	
(5)	027646	001754		.WORD	1004	
(5)	027650	013132		.WORD	ERR6	
5836	027652			EXIT	SUB	;EXIT
(3)	027652	104032		EMT	C\$EXIT	
(3)	027654	000046		.WORD	L10035--	
5837						
5838	027656	012703	010634	15\$:	MOV	#MHSTA,R3 ;SET NAME MESSAGE PTR
5839	027662	004737	020264		JSR	PC,POSHSB ;GET SELECTED HEAD BIT
5840	027666	020537	002524		CMP	R5,DESHD ;CHECK IF CORRECT
5841	027672	001413			BEQ	20\$ ;YES - SKIP
5842	027674	005737	002524		TST	DESHD ;WAS IT SET
5843	027700	001405			BEQ	17\$ ;NO-SKIP
5844	027702			ERRHRD	1005...ERR3	;REPORT SB 1
(3)	027702	104443		TRAP	T\$ERCODE	
(5)	027704	001755		.WORD	1005	
(5)	027706	012744		.WORD	ERR3	
5845	027710			EXIT	SUB	
(3)	027710	104032		EMT	C\$EXIT	
(3)	027712	000010		.WORD	L10035--	
5846	027714			17\$:	ERRHRD	1006...ERR2 ;REPORT SB 0
(3)	027714	104443		TRAP	T\$ERCODE	
(5)	027716	001756		.WORD	1006	
(5)	027720	012676		.WORD	ERR2	
5847						
5848	027722			20\$:		
5849	027722			60\$:		
5850	027722			ENDSUB		
(3)	027722			L10035:		
(3)	027722	104003		EMT	C\$ESUB	
5851	027724	005737	002522	TST	DESSGN	;CHECK IF BOTH SIGN USED
5852	027730	001404		BEQ	25\$	;YES-SKIP
5853	027732	005037	002522	CLR	DESSGN	;SET FOR SIGN OF 0
5854	027736	000137	027454	JMP	T104\$	;DO TEST AGAIN
5855	027742			25\$:		
5856	027742			ENDTST		
(3)	027742			L10034:		
(3)	027742	104001		EMT	C\$ETST	



```

5858
5859
5860          .SBTTL *TEST 11          HEAD ALIGNMENT SUPPORT
5861          BGNTST                    ;TEST 11
5862          (3) 027744                T11.:
5863          027744 032737 000010 014446 BIT #HDALIGN,MISWIW ;CHECK IF RUN HEAD ALIGNMENT
5864          027752 001411 002652 BEQ 1$ ;NO-EXIT
5865          027760 001006 002422 TST PASNUM ;TEST IF PASS 0
5866          027762 023737 002444 002422 BNE 1$ ;NO-EXIT
5867          027770 001004 030274 CMP RLDRV,HADONE ;TEST IF HEAD ALIGN DONE THIS DRIVE
5868          027772 000137 1$: JMP T115$ ;NO - SKIP
5869          (3) 027776 104032          ;GO CHECK WRITE LOCK
5870          (3) 030000 000374          .WORD L10036-
5871          030002 013737 002444 002422 2$: MOV RLDRV,HADONE ;SET HEAD ALIGN DONE FLAG
5872          (11) 030010 005046          PRINTF #FMT5,#BASADD,RLBAS,#DRVNAM,<B,RLDRV+1>
5873          (11) 030012 153716 002445 CLR -(SP)
5874          (10) 030016 012746 005423 BISB RLDRV+1,(SP)
5875          (9) 030022 013746 002440 MOV #DRVNAM, -(SP)
5876          (8) 030026 012746 005412 MOV RLBAS, -(SP)
5877          (7) 030032 012746 011733 MOV #BASADD, -(SP)
5878          (6) 030036 012746 000005 MOV #FMT5, -(SP)
5879          (3) 030042 010600          MOV #5, -(SP)
5880          (4) 030044 104017          MOV SP,RO
5881          (4) 030046 062706 000014 EMT C$PNTF
5882          (8) 030052 012746 007357 PRINTF #FMT9,#HAMES1 ;TYPE INSTRUCTIONS
5883          (7) 030056 012746 012117 MOV #HAMES1, -(SP)
5884          (6) 030062 012746 000002 MOV #FMT9, -(SP)
5885          (3) 030066 010600          MOV #2, -(SP)
5886          (4) 030070 104017          MOV SP,RO
5887          (4) 030072 062706 000006 EMT C$PNTF
5888          (9) 030076 012746 007442 PRINTF #FMT9,#HAMES2
5889          (7) 030102 012746 012117 MOV #HAMES2, -(SP)
5890          (6) 030106 012746 000002 MOV #FMT9, -(SP)
5891          (3) 030112 010600          MOV #2, -(SP)
5892          (4) 030114 104017          MOV SP,RO
5893          (4) 030116 062706 000006 EMT C$PNTF
5894          030122          BGNSUB          ADD #6,SP
5895          (3) 030122 104002          T11.1:
5896          030124 004737 016202          3$: EMT C$BSUB
5897          030130 005037 002420 JSR PC,TSTINT ;INITIALIZE TEST
5898          030134 013737 002444 002446 CLR DONE ;CLEAR DONE
5899          030142 052737 000104 002446 MOV RLDRV,L,CS ;SET UP FOR GET STATUS
5900          030150 012737 000013 002452 BIS #GTSTAT,L,CS
5901          030156 013762 002452 000004 MOV #GETSTAT,DRSET,L,DA
5902          030164 013762 002446 000000 MOV L,DA,RLDA(R2)
5903          (3) 030172 012700 000062 MOV L,CS,RLCSR(R2) ;DO GET STATUS
5904          (3) 030176 104026          WAITMS #50 ;WAIT FOR INTERRUPT
5905          030200 005737 002420 MOV #50,RO
5906          030204 001747          EMT C$WTM
5907          TST DONE ;CHECK IF DONE
5908          BEQ 3$ ;NO-GO CLR CONTROLLER

```

```

5885
5886
5887 030206 012737 000021 002452 10$: MOV #HDSSEL!MBSET0,L.DA;LOAD FOR HEAD 1
5888 030214 032737 020000 002464 BIT #WLSTAT,T.MP ;CHECK IF WRITE LOCK SET
5889 030222 001003 BNE 12$ ;YES-SKIP
5890 030224 042737 000020 002452 BIC #HDSSEL,L.DA ;ELSE CLEAR TO HEAD 0
5891 030232 013737 002444 002446 12$: MOV RLDRV,L.CS ;LOAD IN DRIVE NUMBER
5892 030240 052737 000106 002446 BIS #SEEK,L.CS ;SET FOR SEEK
5893 030246 013762 002452 000004 MOV L.DA,RLDA(R2) ;LOAD & EXECUTE SEEK
5894 030254 013762 002446 000000 MOV L.CS,RLCSR(R2)
5895 030262 WAITMS #30. ;WAIT FOR INTERRUPT
(3) 030262 012700 000036 MOV #30.,R0
(3) 030266 104026 EMT CSWTM
5896 030270 000715 BR 3$ ;LOOP
5897
5898 030272 59$: ENDSUB
(3) 030272 L10037:
(3) 030272 104003 EMT C$ESUB
5899 030274 T115$:
5900 030274 BGNSUB
(3) 030274 T11.2:
(3) 030274 104002 EMT C$BSUB
5901 030276 004737 016202 JSR PC,TSTINT ;INITIALIZE TEST
5902 030302 004737 016220 JSR PC,GSTATR ;CLEAR DRIVE
5903 030306 030372 #60$
5904 030310 032737 020000 002464 BIT #WLSTAT,T.MP ;CHECK WRITE LOCK RESET
5905 030316 001425 BEQ 19$ ;YES-SKIP
5906 030320 18$: PRINTF #FMT9,#OPR12 ;REQUEST WRITE LOCK RESET
(8) 030320 012746 010167 MOV #OPR12,-(SP)
(7) 030324 012746 012117 MOV #FMT9,-(SP)
(6) 030330 012746 000002 MOV #2,-(SP)
(3) 030334 010600 MOV SP,R0
(4) 030336 104017 EMT C$PNTF
(4) 030340 062706 000006 ADD #6,SP
5907 030344 005037 003656 CLR OBUFF ;CLEAR FOR RESPONSE
5908 030350 GMANIL #OPR02,OBUFF.1,NO ;GET RESPONSE
(3) 030350 104043 EMT C$GMAN
(3) 030352 000404 BR 10000$
(4) 030354 003656 .WORD OBUFF
(5) 030356 000120 .WORD T$CODE
(5) 030360 007514 .WORD #OPR02
(5) 030362 000001 .WORD 1
(3) 030364 10000$:
5909 030364 005737 003656 TST OBUFF ;WAS ANSWER YES
5910 030370 001753 BEQ 18$ ;NO-REPEAT REQUEST
5911
5912 030372 19$:
5913 030372 60$: ENDSUB
(3) 030372 L10040:
(3) 030372 104003 EMT C$ESUB
5914 030374 20$:
5915 030374 ENDTST
(3) 030374 L10036:
(3) 030374 104001 EMT C$ETST

```



```

5917
5918
5919
5920 030376          SBTTL *TEST 12      HEAD SWITCHING
      (3) 030376          BGNTST      ;TEST 12
5921 030376 012737 006215 002424      MOV #T12ERR,ERHEAD ;SET ERROR HEADER
5922 030404 012701 002514      MOV #NEWCYL,R1 ;GET POINTER TO DESIRED LOCATION
5923 030410 005021      CLR (R1)+ ;CLEAR NEW CYLINDER
5924 030412 005021      CLR (R1)+ ;CLEAR CURRENT CYL.
5925 030414 005021      CLR (R1)+ ;CLEAR DIFFERENCE
5926 030416 005021      CLR (R1)+ ;CLEAR SIGN
5927 030420 012721 000001      MOV #1,(R1)+ ;SET FOR HEAD 1
5928
5929 030424          T124$:
      (3) 030424          BGNSUB
      (3) 030424 104002      EMT CSBSUB ;INITIALIZE TEST
5930 030426 004737 016202      JSR PC,TSTINT ;GET STATUS WITH RESET
5931 030432 004737 016220      JSR PC,GSTATR ;DO SEEK
5932 030436 030672      #60$
5933 030440 004737 017102      JSR PC,SIMSEK ;SET NAME MESSAGE PTR
5934 030444 030672      #60$ ;SET CONDITION POINTER
5935 030446 012703 010501      MOV #MRDY,R3 ;GET STATUS
5936 030452 012704 011512      MOV #CDRDY,R4
5937 030456 004737 016250      JSR PC,GSTAT
5938 030462 030672      #60$
5939 030464 032737 000001 002456      BIT #DRDYMSK,T.CS ;CHECK IF READY
5940 030472 001405      BEQ 5$ ;NO-SKIP
5941 030474          ERRHRD 1201...ERR4 ;REPORT READY ERROR
      (3) 030474 104443      TRAP T$ERCODE
      (5) 030476 002261      .WORD 1201
      (5) 030500 013012      .WORD ERR4
5942 030502          EXIT SUB ;EXIT
      (3) 030502 104032      EMT C$EXIT
      (3) 030504 000166      .WORD L10042-.
5943
5944 030506 012701 000121      5$: MOV #81,R1 ;SET WAIT COUNT
5945 030512 004737 016250      6$: JSR PC,GSTAT ;GET STATUS
5946 030516 030672      #60$
5947 030520 012703 000005      MOV #5,R3 ;SET EXPECTED STATE VALUE
5948 030524 020337 002472      CMP R3,T.STAT ;CHECK IF STATE IS 5
5949 030530 001405      BEQ 7$ ;YES-SKIP
5950 030532          ERRHRD 1202...ERR7 ;REPORT STATE ERROR
      (3) 030532 104443      TRAP T$ERCODE
      (5) 030534 002262      .WORD 1202
      (5) 030536 014010      .WORD ERR7
5951 030540          EXIT SUB
      (3) 030540 104032      EMT C$EXIT
      (3) 030542 000130      .WORD L10042-.
5952
5953 030544 012703 010501      7$: MOV #MRDY,R3 ;SET NAME MESSAGE PTR
5954 030550 032737 000001 002456      BIT #DRDYMSK,T.CS ;CHECK DRIVE READY
5955 030556 001013      BNE 12$ ;YES-SKIP
5956 030560 005301      DEC R1 ;DEC WAIT COUNT
5957 030562 001404      BEQ 9$ ;SKIP IF 0
5958 030564          WAITUS #1
      (3) 030564 012700 000001      MOV #1,R0
    
```

```

(3) 030570 104027 EMT CSWTU
5959 030572 000747 BR 6$
5960
5961 030574 9$: ERRHRD 1203... ERR5 ;REPORT READY ERROR
(3) 030574 104443 TRAP TSERCODE
(5) 030576 002263 .WORD 1203
(5) 030600 013062 .WORD ERR5
5962 030602 EXIT SUB ;EXIT
(3) 030602 104032 EMT C$EXIT
(3) 030604 000066 .WORD L10042-.
5963
5964 030606 005737 002456 12$: TST T.CS ;TEST IF ANY ERROR
5965 030612 100005 BPL 15$ ;NO-SKIP
5966 030614 ERRHRD 1204... ERR6 ;REPORT ALL ERRORS
(3) 030614 104443 TRAP TSERCODE
(5) 030616 002264 .WORD 1204
(5) 030620 013132 .WORD ERR6
5967 030622 EXIT SUB
(3) 030622 104032 EMT C$EXIT
(3) 030624 000046 .WORD L10042-.
5968 030626 012703 010634 15$: MOV #MHSTA,R3 ;SET NAME MESSAGE PTR
5969 030632 004737 020264 JSR PC,POSHSB ;POSITION HEAD SELECT BIT
5970 030636 023705 002524 CMP DESHD,R5 ;CHECK IF CORRECT HEAD SELECTED
5971 030642 001413 BEQ 20$ ;YES-SKIP
5972 030644 005737 002524 TST DESHD ;WAS HEAD 0 SELECTED
5973 030650 001405 BEQ 17$ ;YES-SKIP
5974 030652 ERRHRD 1205... ERR3 ;REPORT HEAD SB 1
(3) 030652 104443 TRAP TSERCODE
(5) 030654 002265 .WORD 1205
(5) 030656 012744 .WORD ERR3
5975 030660 EXIT SUB ;EXIT
(3) 030660 104032 EMT C$EXIT
(3) 030662 000010 .WORD L10042-.
5976 030664 17$: ERRHRD 1206... ERR2 ;ELSE REPORT HEAD SB 0
(3) 030664 104443 TRAP TSERCODE
(5) 030666 002266 .WORD 1206
(5) 030670 012676 .WORD ERR2
5977
5978 030672 20$:
5979 030672 60$:
5980 030672 ENDSUB
(3) 030672 -L10042:
(3) 030672 104003 EMT C$ESUB
5981 030674 005737 002524 TST DESHD ;CHECK IF HD 0 WAS DONE
5982 030700 001404 BEQ 25$ ;YES-SKIP
5983 030702 005037 002524 CLR DESHD ;ELSE SET TO HEAD 0
5984 030706 000137 030424 JMP T124$ ;REDO TEST
5985 030712
5986 030712 25$:
(3) 030712 ENDTST
(3) 030712 L10041: EMT C$ETST

```



# K08

OUTERR MACY11 30(1046) 04-NOV-77 13:14 PAGE 84-27  
 DZRLCA.P11 05-OCT-77 10:52 \*TEST 12

HEAD SWITCHING

SEG C101

```

5988
5989
5990          .SBTTL *TEST 13          READ HEADER (PART 1)
5991 030714          BGNTST          ;TEST 13
(3) 030714
5992 030714 012737 006227 002424          MOV #T13ERR,ERHEAD ;SET ERROR HEADER
5993 030722 012701 002514          MOV #NEWCYL,R1 ;GET ADDRESS OF DESIRED LOCATIONS
5994 030726 005021          CLR (R1)+ ;CLEAR NEW CYL
5995 030730 005021          CLR (R1)+ ;CLEAR CURRENT CYL
5996 030732 005021          CLR (R1)+ ;CLEAR DIFF
5997 030734 005021          CLR (R1)+ ;CLEAR SIGN
5998 030736 005021          CLR (R1)+ ;CLEAR HEAD
5999          T134$:
6000 030740          BGNSUB
(3) 030740          T13.1:
(3) 030740 104002          EMT CSBSUB
6001 030742 004737 016202          JSR PC,TSTINT ;INITIALIZE TEST
6002 030746 004737 016220          JSR PC,GSTATR ;GET STATUS W/RESET
6003 030752 031040          #60$
6004 030754 004737 017102          JSR PC,SIMSEK ;DO SEEK
6005 030760 031040          #60$
6006 030762 012701 000121          MOV #B1,R1 ;SET WAIT COUNT
6007 030766 004737 020314          JSR PC,RDYWAIT ;WAIT FOR READY
6008 030772 031040          #60$
6009
6010 030774 004737 017626          10$: JSR PC,XRDHDC ;DO READ HEADER
6011 031000 031040          #60$
6012 031002 012703 010634          MOV #MHSTA,R3 ;SET NAME MESSAGE PTR
6013 031006 004737 020256          JSR PC,POSHWI ;POSITION HS BIT IN HD WRD 1
6014 031012 020537 002524          CMP R5,DESHD ;CHECK IF HEAD CORRECT
6015 031016 001410          BEQ 15$ ;YES-SKIP
6016 031020          ERRHRD 1301,ERR3 ;REPORT SB 1
(3) 031020 104443          TRAP T$ERRCODE
(5) 031022 002425          .WORD 1301
(5) 031024 012744          .WORD ERR3
6017 031026          EXIT SUB
(3) 031026 104032          EMT C$EXIT
(3) 031030 000010          .WORD L10044-
6018 031032          17$: ERRHRD 1302,ERR2 ;REPORT SB 0
(3) 031032 104443          TRAP T$ERRCODE
(5) 031034 002426          .WORD 1302
(5) 031036 012676          .WORD ERR2
6019
6020          15$:
6021 031040          60$:
6022 031040          ENDSUB
(3) 031040          L10044:
(3) 031040 104003          EMT C$ESUB
6023 031042 005737 002524          TST DESHD ;TEST IF HEAD 1 DONE
6024 031046 001007          BNE 20$ ;YES-SKIP
6025 031050 012737 000001 002524          MOV #1,DESHD ;ELSE SET TO HEAD 1
6026 031056 013737 002464 002530          MOV HDWRD1,TEMPO ;STORE HDR WORD 1
6027 031064 000725          BR T134$ ;DO TEST AGAIN
6028 031066 042737 100177 002530          BIC #1CHDCYL,TEMPO ;CLEAR ALL BUT CYLINDER IN 1ST HEADER
6029 031074 042737 100177 002464          BIC #1CHDCYL,HDWRD1 ;CLEAR ALL BY CYL IN 2ND HEADER
6030 031102 023737 002530 002464          CMP TEMPO,HDWRD1 ;COMPARE IF EQUAL
  
```

L08

OUTERR MACY11 30(1046) 04-NOV-77 13:14 PAGE 84-28  
DZRLCA.P11 05-OCT-77 10:52 \*TEST 13

READ HEADER (PART 1)

SEQ 0102

6031 031110 001405  
6032 031112 012703 007273  
6033 031116 104443  
(3) 031116 104443  
(5) 031120 002432  
(5) 031122 012630  
6034 031124  
6035 031124  
(3) 031124  
(2) 031124 104001

BEG 22\$  
MOV #CYLPER,R3  
ERRHRD 1306,ERR1  
TRAP T\$ERRCODE  
.WORD 1306  
.WORD ERR1

;YES-SKIP  
;SET NAME MESSAGE PTR  
;REPORT HEAD ALIGNMENT PROBLEM

22\$:  
ENDTST  
L10043:

EMT C\$ETST



M08

OUTERR MACY11 30(1046) 04-NOV-77 13:14 PAGE 84-29  
 DZRLCA.P11 05-OCT-77 10:52 \*TEST 14

READ HEADER (PART 2)

SEQ 0103

6037					SBTTL	*TEST 14	READ HEADER (PART 2)	
6038	031126				BGNTST	;TEST 14		
(3)	031126							T14::
6039	031126	012737	006243	002424		MOV	#T14ERR,ERHEAD	;SET ERROR HEADER
6040	031134	012701	002516			MOV	#CURCYL,R1	;GET ADDRESS OF DESIRED VALUE
6041	031140	005021				CLR	(R1)+	;CLEAR CURRENT CYL
6042	031142	005021				CLR	(R1)+	;CLEAR DESIRED DIFF
6043	031144	005021				CLR	(R1)+	;CLEAR SIGN
6044	031146	005021				CLR	(R1)+	;CLEAR DESIRED HEAD
6045	031150				T153\$:			
6046	031150				BGNSUB			
(3)	031150							T14.1:
(3)	031150	104002				EMT	CSBSUB	
6047	031152	004737	016202			JSR	PC,TSTINT	;INITIALIZE TEST
6048	031156	004737	016220			JSR	PC,GSTATR	;CLEAR DRIVE
6049	031162	031356			#60\$			
6050	031164	004737	017102			JSR	PC,SIMSEK	;DO SEEK
6051	031170	031356			#60\$			
6052	031172	012701	000310			MOV	#200,R1	;SET WAIT COUNT FOR 20 MS
6053	031176	004737	020314			JSR	PC,RDYWAIT	;WAIT FOR READY
6054	031202	031356			#60\$			
6055	031204	004737	020710			JSR	PC,RDALHD	;DO READ HEADER ALL HEADERS
6056	031210	031356			#60\$			
6057	031212	005037	002426			CLR	MORECE	;CLEAR MORE COMPARE ERRORS FOR REPORT
6058	031216	052737	000002	002416		BIS	#HDCMP,OPFLAG	;SET HDR COMPARE FLAG
6059	031224	005003				CLR	R3	;CLEAR FOR HDR COUNT
6060	031226	012704	003256			MOV	#IBUFF,R4	;GET POINTER FOR HDR TO BE CHECKED
6061	031232	012705	002530			MOV	#TEMPO,R5	;GET POINTER TO TEST AREA
6062	031236	012701	000050			MOV	#40,R1	;SET HDR COUNT
6063	031242	011415				MOV	(R4),(R5)	;GET FIRST HEADER WORD
6064	031244	042715	100100			BIC	#BIT15:HDHSEL,(R5)	;CLEAR BIT 15 AND HEAD SEL BIT
6065	031250	005737	002524			TST	DESHD	;TEST IF HD 0 DESIRED
6066	031254	001404				BEQ	10\$	;YES-SKIP
6067	031256	052715	000100			BIS	#HDHSEL,(R5)	;ELSE SET HEAD BIT
6068	031262	005065	000002			CLR	2(R5)	;CLEAR 2ND WORD OF TEST AREA
6069	031266	021524			10\$:	CMP	(R5),(R4)+	;COMPARE HEADER WORD
6070	031270	001405				BEQ	13\$	;SKIP IF OK
6071	031272	005744				TST	-(R4)	;ELSE POSITION R4 TO BAD WORD
6072	031274					ERRHRD	1501,ERR10	;REPORT ERROR
(3)	031274	104443				TRAP	T\$ERCODE	
(5)	031276	002735				.WORD	1501	
(5)	031300	014220				.WORD	ERR10	
6073	031302	005724				TST	(R4)+	;BUMP R4 TO NEXT WORD
6074	031304	005203			13\$:	INC	R3	;BUMP WORD COUNT
6075	031306	005724				TST	(R4)+	;TEST 2ND WORD IS 0
6076	031310	001405				BEQ	15\$	;YES - SKIP
6077	031312	022544				CMP	(R5)+,-(R4)	;POSITION PTRS FOR REPORT
6078	031314					ERRHRD	1501,ERR10	;REPORT ERROR
(3)	031314	104443				TRAP	T\$ERCODE	
(5)	031316	002735				.WORD	1501	
(5)	031320	014220				.WORD	ERR10	
6079	031322	024524				CMP	-(R5),(R4)+	;REPOSITION POINTER
6080	031324	005724			15\$:	TST	(R4)+	;POSITION R4 PAST ECC WORD
6081	031326	005203				INC	R3	;BUMP WORD COUNT
6082	031330	005215				INC	(R5)	;BUMP SECTOR COUNT
6083	031332	011500				MOV	(R5),R0	;CHECK IF SECTOR IS PAST LAST SECTOR

# N08

OUTERR MACY11 30(1046) 04-NOV-77 13:14 PAGE 84-30  
DZRLCA.P11 05-OCT-77 10:52 \*TEST 14

READ HEADER (PART 2)

SEQ 0104

6084	031334	042700	177700		BIC	#1CHDSEC,RO	
6085	031340	022700	000050		CMP	#40.,RO	
6086	031344	001002			BNE	17\$	:NO-SKIP
6087	031346	042715	000077		BIC	#HDSEC,(R5)	:ELSE CLEAR SECTOR TO 0
6088	031352	005301		17\$	DEC	R1	:DEC HDR COUNT
6089	031354	001344			BNE	10\$	:YES-SKIP
6090							
6091	031356			60\$:			
6092	031356			ENDSUB			
(3)	031356			L10046:			
(3)	031356	104003			EMT	CSESUB	
6093	031360	005737	002524		TST	DESHD	:CHECK IF HD 1 TESTED
6094	031364	001005			BNE	20\$	:YES-SKIP
6095	031366	012737	000001	002524	MOV	#1,DESHD	:ELSE SET TO HEAD 1
6096	031374	000137	031150		JMP	T153\$	:REDO TEST
6097	031400			20\$:			
6098	031400			ENDTST			
(3)	031400			L10045:			
(3)	031400	104001			EMT	CSETST	
6099	031402			ENDMOD			



6102	031402				BGNMOD	HRDPRM			
6103	031402				BGNHRD				
(3)	031402	000025					.WORD	L10047-L\$HARD/2	
6104	031404				GPRML	CNTYPE,CNT,1,YES			
(4)	031404	004130					.WORD	T\$CODE	
(4)	031406	031520					.WORD	CNTYPE	
(4)	031410	000001					.WORD	1	
6105	031412				GPRMA	CSRMSG,CSR,0,160000,177776,YES			
(4)	031412	000031					.WORD	T\$CODE	
(4)	031414	031456					.WORD	CSRMSG	
(4)	031416	160000					.WORD	T\$LOLIM	
(4)	031420	177776					.WORD	T\$HILIM	
6106	031422				GPRMA	VECMMSG,VECT,0,0,776,YES			
(4)	031422	001031					.WORD	T\$CODE	
(4)	031424	031472					.WORD	VECMMSG	
(4)	031426	000000					.WORD	T\$LOLIM	
(4)	031430	000776					.WORD	T\$HILIM	
6107	031432				GPRMD	BRMSG,PRIOR,0,340,0,7,YES			
(4)	031432	002032					.WORD	T\$CODE	
(4)	031434	031501					.WORD	BRMSG	
(4)	031436	000340					.WORD	340	
(4)	031440	000000					.WORD	T\$LOLIM	
(4)	031442	000007					.WORD	T\$HILIM	
6108	031444				GPRMD	DRMSG,DRSB,0,3400,0,7,YES			
(4)	031444	003032					.WORD	T\$CODE	
(4)	031446	031512					.WORD	DRMSG	
(4)	031450	003400					.WORD	3400	
(4)	031452	000000					.WORD	T\$LOLIM	
(4)	031454	000007					.WORD	T\$HILIM	
6109									
6110	031456				ENDHRD			.EVEN	
(2)									
(3)	031456				L10047:				
6111									
6112	031456	052502	020123	042101	CSRMSG:	.ASCIZ	/BUS ADDRESS/		
	031464	051104	051505	000123					
6113	031472	042526	052103	051117	VECMMSG:	.ASCIZ	/VECTOR/		
	031500	000							
6114	031501	102	020122	042514	BRMSG:	.ASCIZ	/BR LEVEL/		
	031506	042526	000114						
6115	031512	051104	053111	000105	DRMSG:	.ASCIZ	/DRIVE/		
6116	031520	046122	030461	000	CNTYPE:	.ASCIZ	/RL11/		
6117	031525				ENDMOD				
6118		031526						.EVEN	
6119									
6120	031526				BGNMOD	SFTPRM			
6121	031526				BGNSFT				
(3)	031526	000021					.WORD	L10050-L\$SOFT/2	
6122									
6128	031530				GPRML	SELQ,MISWI,4,YES			
(4)	031530	000130					.WORD	T\$CODE	
(4)	031532	031572					.WORD	SELQ	
(4)	031534	000004					.WORD	4	
6129	031536				GPRML	ALGNQ,MISWI,10,YES			
(4)	031536	000130					.WORD	T\$CODE	
(4)	031540	031625					.WORD	ALGNQ	





009

PDP-11 DIAGNOSTIC SUPERVISOR  
DZRLCA.SUP 11-OCT-77 15:40

MACY11 30(1046) 04-NOV-77 13:14 PAGE 86  
\*TEST 14 READ HEADER (PART 2)

SEG 0107

6175  
17471 062704  
17473 071776  
17474 071776 000000  
17476 072000  
17477 000200

.TITLE PDP-11 DIAGNOSTIC SUPERVISOR  
END.SUPV=+.2  
.=71776  
.WORD 0  
XIXI=  
.END 200

ABOFLA 032256 G  
 ABOPAS 032170 G  
 ABO.FM 035132  
 AFMID 002622  
 AFMIDU 002624  
 ALGNQ 031625  
 ALLCYL= 000001  
 ALLOC 052722  
 ALLSEC= 000002  
 ANYERR= 100000  
 ARMID 002626  
 ARMIDU 002630  
 AUTOQ 031752  
 AUTOSZ= 000020  
 ASAAW 037042  
 ASAAZ 037056  
 ASAAZ 037064  
 ASAAZ 037100  
 ASABA 037110  
 BADADD= 004000  
 BAMSK = 000060  
 BANAM 005530  
 BASADD 005412  
 BELL 011433  
 BGN.SU= 032004  
 BHSTAT= 000010  
 BINMSG 051232  
 BIT0 = 000001 G  
 BIT00 = 000001 G G  
 BIT01 = 000002 G G  
 BIT02 = 000004 G G  
 BIT03 = 000010 G G  
 BIT04 = 000020 G G  
 BIT05 = 000040 G G  
 BIT06 = 000100 G G  
 BIT07 = 000200 G G  
 BIT08 = 000400 G G  
 BIT09 = 001000 G G  
 BIT1 = 000002 G G  
 BIT10 = 002000 G G  
 BIT11 = 004000 G G  
 BIT12 = 010000 G G  
 BIT13 = 020000 G G  
 BIT14 = 040000 G G  
 BIT15 = 100000 G G  
 BIT2 = 000004 G G  
 BIT3 = 000010 G G  
 BIT4 = 000020 G G  
 BIT5 = 000040 G G  
 BIT6 = 000100 G G  
 BIT7 = 000200 G G  
 BIT8 = 000400 G G  
 BIT9 = 001000 G G

BLD.HW 037722  
 BLOCK 055056  
 BRMSG 031501  
 BSFLAG 002432  
 BSFVAL 002664  
 BSNSTR 010400  
 BYPSNM 010311  
 BSAB 041324  
 BSAAF 041236  
 CAFDT 011564  
 CALLPC= 000022  
 CALLPS= 000024  
 CALLSP= 000026  
 CALLTC= 000030  
 CAL.CL 057440  
 CAL.TI 057476 G  
 CAMSK = 077600  
 CCYLUP 011553  
 CORDY 011512  
 CHKLUP 041340  
 CHKSTR 053264  
 CHKTTY 051352  
 CHK.FO 033550  
 CHK.MA 037500  
 CHK.PC 044566  
 CHK.SW 033272  
 CHRCNT 052604  
 CH.FLA 037202  
 CH.PAS 037224  
 CKDATA= 000102  
 CKERLM 015656  
 CLEAR 040622 G  
 CLKACC 032166 G  
 CLKBFR 057442  
 CLKCNT 032164 G G  
 CLKRES 061040 G G  
 CLKSER 061340 G G  
 CLKSON 032230 G G  
 CLK.SE 037302 G  
 CLNCOD 015466 G  
 CLRPAR 022502  
 CLR.MA 037556  
 CNT = 000010  
 CNTYPE 031520  
 CNVT 055516  
 COMMTA 055336  
 COMPOP= 007777  
 CONHNG= 000004  
 CONTCL 061120 G  
 CONTIN 014666  
 COSTAT= 000040  
 COUNT 002646  
 CRDYS= 000200

CRLF 051434  
 CSNAM 005523  
 CSR = 000000  
 CSRMSG 031456  
 CURCYL 002516  
 CURR.T 032204 G  
 CYLPER 007273  
 CYLTBI 002342  
 CYLUP = 000004  
 CYLWD 010276  
 CSAD 044540  
 CSAE 044552  
 CSAK 045370  
 CSAL 045500  
 CSABRT= 000021  
 CSADR = 000020  
 CSAU = 000054  
 CSBRK = 000022  
 CSBSEG= 000004  
 CSBSUB= 000002  
 CSBUFF= 000030  
 CSCCFG= 000046  
 CSCLEA= 000012  
 CSCLP1= 000006  
 CSCVEC= 000036  
 CSOCLN= 000044  
 CSODDU= 000053  
 CSDRPT= 000024  
 CSOU = 000055  
 CSEDIT= 000006  
 CSERDF= 000002  
 CSERHR= 000003  
 CSERSF= 000001  
 CSERSO= 000004  
 CSESCA= 000010  
 CSESEG= 000005  
 CSESUB= 000003  
 CSETST= 000001  
 CSEXIT= 000032  
 CSGMAN= 000043  
 CSGPHR= 000042  
 CSGPRI= 000040  
 CSGTIM= 000052  
 CSINIT= 000011  
 CSINLP= 000020  
 CSKWF= 000035  
 CSKWON= 000034  
 CSLOOP= 000100  
 CSMANI= 000051  
 CSMSG = 000023  
 CSPNTB= 000014  
 CSPNTF= 000017  
 CSPNTS= 000016

CSPNTX= 000015  
 CSPOIN= 000040  
 CSQIO = 000377  
 CSROBU= 000007  
 CSREFG= 000050  
 CSREQT= 000045  
 CSRESE= 000033  
 CSREVI= 000001  
 CSRPT = 000025  
 CSSEFG= 000047  
 CSSPRI= 000041  
 CSSVEC= 000037  
 CSTPRI= 000013  
 CSUNBU= 000031  
 CSWTM = 000026  
 CSWTS = 000027  
 C1OMS 011532  
 CSSEC 011576  
 CSOOMS 011545  
 DANAM 005535  
 DATACM= 000001  
 DCKERR= 004000  
 DCLIM = 000012  
 DCLIMW 014460  
 DECMMSG 051246  
 DESDIF 002520  
 DESHD 002524  
 DESSEC 002526  
 DESSGN 002522  
 DIAG.T 032264 G  
 DIFAUG 002510  
 DIFWD 010252  
 DIRBIT= 000004  
 DIRMSK= 077600  
 DLTERR= 010000  
 DONE 002420  
 DPDVD 062050 G  
 DPMUL 061736 G  
 DRDYS= 000001  
 DRMSG 031512  
 DRSB = 000006  
 DRSELT= 000004  
 DRSET = 000010  
 DRVCNT 002506  
 DRVERR= 040000  
 DRVNAV 005423  
 DRVNAV 005430  
 DSESTA= 000400  
 DSMSK = 001400  
 DSPCOD 014462 G  
 DUNIT. 032174 G  
 DVC.FT 045340  
 DSAAG 046210

DSAAH 046226  
 DSAAI 051000  
 DSAAJ 051004  
 DSAK 051022  
 DSAL 051040  
 DSAM 051050  
 EF.CON= 000036 G  
 EF.NEW= 000035 G G  
 EF.PWR= 000034 G G  
 EF.RES= 000037 G G  
 EF.STA= 000040 G G  
 EFO1 = 000001 G G  
 EFO2 = 000002 G G  
 EFO3 = 000003 G G  
 EFO4 = 000004 G G  
 EFO5 = 000005 G G  
 EFO6 = 000006 G G  
 EFO7 = 000007 G G  
 EFO8 = 000010 G G  
 EFO9 = 000011 G G  
 EFO10 = 000012 G G  
 EFO11 = 000013 G G  
 EFO12 = 000014 G G  
 EFO13 = 000015 G G  
 EFO14 = 000016 G G  
 EFO15 = 000017 G G  
 EFO16 = 000020 G G  
 EMT.TR 032262 G  
 END.OF 040610  
 END.SU= 062704  
 EOP.CH 061362 G  
 EOP.FM 035146  
 EOP.IN 037220  
 ERHEAD 002424  
 ERLIM = 000010  
 ERLIMQ 031726  
 ERLIMW 014456  
 ERRCNT 002650  
 ERRFOR 045556  
 ERRHAN 044572  
 ERRSWI 002430  
 ERPVEC 002642  
 ERR.HR 045350  
 ERR.SF 045354  
 ERR1 012630 G  
 ERR1FO 045642 G  
 ERR1O 014220 G G  
 ERR2 012676 G G  
 ERR3 012744 G G  
 ERR4 013012 G G  
 ERR5 013062 G G  
 ERR6 013132 G G  
 ERR7 014010 G



ERR8 014060 G  
 ERR9 014154 G  
 ESC.PC 044564  
 EXACYL 002636  
 EXHCYL 002634  
 EXOCYL 002632  
 EXROT 002640  
 EXTOS 025650  
 FBSFIL 003062  
 FILL 052102  
 FILL.C 000204 G  
 FLAGS 032226 G  
 FLAGTA 055254  
 FLAG.I 037266  
 FLA.SE 055222  
 FLG.MA 037226  
 FMTOP1 011606  
 FMTOP2 011635  
 FMTOP3 011657  
 FMT1 011700  
 FMT1.1 011705  
 FMT11 012124  
 FMT12 012132  
 FMT13 012140  
 FMT14 012204  
 FMT15 012236  
 FMT16 012272  
 FMT17 012303  
 FMT18 012325  
 FMT19 012357  
 FMT2 011714  
 FMT20 012414  
 FMT21 012444  
 FMT22 012467  
 FMT23 012523  
 FMT24 012537  
 FMT25 012544  
 FMT26 012554  
 FMT27 012600  
 FMT28 012617  
 FMT3 011717  
 FMT4 011722  
 FMT5 011733  
 FMT6 011753  
 FMT7 012015  
 FMT8 012065  
 FMT9 012117  
 FOLWRT= 000100  
 FORM.T 045652  
 FREE 053160  
 FRMWD 010303  
 FWDSKO= 002000  
 FWDSKS= 000400

FSAU = 000015  
 FSBGN = 000040  
 FSCLEA= 000007  
 FSDU = 000016  
 FSEND = 000041  
 FSHARD= 000004  
 FSHW = 000013  
 F\$INIT= 000006  
 FSJMP = 000050  
 F\$MOD = 000000  
 F\$MSG = 000011  
 F\$PWR = 000017  
 F\$RPT = 000012  
 F\$SEG = 000003  
 F\$SOFT= 000005  
 F\$SRV = 000010  
 F\$SUB = 000002  
 F\$SW = 000014  
 F\$TEST= 000001  
 GARBAG 052606  
 GETCHR 051312  
 GETCMN 054676  
 GETPAR 046370  
 GETPOS 020562  
 GETSTA= 000003  
 GETSWI 053672  
 GET.TW 053442  
 GLBDAT 002112 G  
 GLBEQA 002112 G  
 GLBERR 012630 G  
 GLBSUB 015612 G  
 GLBTXT 004534 G  
 GSTAT 016250  
 GSTATC 016234  
 GSTATG 016260  
 GSTATR 016220  
 GSTER1 006106  
 GTSTAT= 000104  
 G\$EXCP= 000400  
 G\$HILI= 000002  
 G\$LOLI= 000001  
 G\$NO = 000000  
 G\$OFFS= 000400  
 G\$OFST= 000376  
 G\$PRMA= 000001  
 G\$PRMD= 000002  
 G\$PRML= 000000  
 G\$RADA= 000140  
 G\$RADB= 000000  
 G\$RADD= 000040  
 G\$RADF= 000200  
 G\$RADL= 000120  
 G\$RADO= 000020

G\$RADT= 000100  
 G\$XFER= 000004  
 G\$YES = 000010  
 HADONE 002422  
 HAMES1 007357  
 HAMES2 007442  
 HCESTA= 040000  
 HCORED 036764  
 HCOREQ 036644  
 HCORET 032216 G  
 HCR CER= 004000  
 HDALIG= 000010  
 HDCYL = 077600  
 HDHSEL= 000100  
 HDMOVF 007234  
 HDRCMP= 000002  
 HDR40 = 100000  
 HDSEC = 000077  
 HDSEL = 000020  
 HDWD 010265  
 HDWRD1 002464  
 HDWRD2 002466  
 HDWRD3 002470  
 HEAD = 000006  
 HEADLM= 010000  
 HEADW 014454  
 HERTZ. 036604  
 HFIN 002602  
 HFINU 002604  
 HFOUT 002606  
 HFOUTU 002610  
 HICYL = 020000  
 HILIM = 000004  
 HILIMW 014452  
 HNFERR= 010000  
 HOLDSP= 000020  
 HOSTAT= 000020  
 HPTCOD 014430 G  
 HRDPRM 031402 G  
 HRDWS 022532 G  
 HRIN 002612  
 HRINU 002614  
 YROUT 002616  
 HROUTU 002620  
 HSMK = 000100  
 HSSTAT= 000100  
 H\$AAB 056044  
 I\$BUFF 003256  
 I\$INIT 032206 G  
 I\$ITCO 014520 G  
 I\$ITIA 051262  
 I\$ITST 006137  
 I\$IT.M 037624

INIT.R 032020 G  
 INOUTS= 000020  
 INPUTA 052210  
 INTEBL= 000100  
 INTFOR 045506  
 INTHLR 015620 G  
 INVAL 036732  
 INVINT 045400  
 INV.SW 033226  
 IN.SUF 040574  
 I\$AU = 000041  
 I\$CLN = 000041  
 I\$DU = 000041  
 I\$HRD = 000041  
 I\$INIT= 000041  
 I\$MOD = 000041  
 I\$MSG = 000041  
 I\$PWR = 000041  
 I\$RPT = 000041  
 I\$SEG = 000041  
 I\$SFT = 000041  
 I\$SRV = 000041  
 I\$SUB = 000041  
 I\$TST = 000041  
 I\$JMP = 000167  
 KBPTR 032036 G  
 KBUF 032040 G  
 LABACF 007204  
 LABACR 007220  
 LABEXP 007113  
 LABHCF 007154  
 LABHCR 007170  
 LABIN 007070  
 LABMID 007076  
 LABOCF 007124  
 LABOCR 007140  
 LABOUT 007105  
 LAB1 005547  
 LAB2 005562  
 LCLEXT 026522  
 LINE.F 032260 G  
 LOAD.F 037222  
 LOCERR 002656  
 LOCYL = 040000  
 LOGMSG 051254  
 LOLIM = 000002  
 LOLIMW 014450  
 LPBFR 032034 G  
 LPCNTR 032032 G  
 LPT.AD 036622  
 LPT.RE 036616  
 LPTOS 025430  
 LSI.RE 036612

LUP 057344  
 LUP.AD 044570  
 L\$AUT 002070 G  
 L\$CCP 002044 G  
 L\$CLEA 015466 G  
 L\$DEPO 002011 G  
 L\$DEVP 002052 G  
 L\$DISP 014464 G  
 L\$DR 002102 G  
 L\$DRCT 002062 G  
 L\$DRS 002064 G  
 L\$DRST 002102 G  
 L\$DTP 002040 G  
 L\$DU 015606 G  
 L\$DUT 002072 G  
 L\$DVTY 002104 G  
 L\$EF 002024 G  
 L\$EXP1 002032 G  
 L\$EXP2 002034 G  
 L\$EXP3 002036 G  
 L\$HARD 031404 G  
 L\$HPCP 002046 G  
 L\$HPTP 002056 G  
 L\$HW 014432 G  
 L\$ICP 002042 G  
 L\$INIT 014520 G  
 L\$LDAP 002076 G  
 L\$LAST 032004 G  
 L\$MREV 002012 G  
 L\$NAME 002000 G  
 L\$REPP 002054 G  
 L\$REV 002010 G  
 L\$SOFT 031530 G  
 L\$SFC 002030 G  
 L\$SPCP 002050 G  
 L\$SPTP 002060 G  
 L\$STA 002066 G  
 L\$SW 014446 G  
 L\$TIML 002022 G  
 L\$TIMU 002020 G  
 L\$TIM1 002016 G  
 L\$TSTI 002074 G  
 L\$UNIT 002014 G  
 L.BA 002450  
 L.CLK. 036570  
 L.CS 002446  
 L.DA 002452  
 L.MP 002454  
 L10000 012674  
 L10001 012742  
 L10002 013010  
 L10003 013060  
 L10004 013130



L10005	014006	MCYLUP	004774	MSTERR	011015	OPR1A	010206	PRI04 =	000200	G
L10006	014056	MDATCP	004636	MTMBS	005350	OPR1B	010212	PRI05 =	000240	G
L10007	014152	MDCRC	010534	MTOSLO	005603	OPR10	010070	PRI06 =	000300	G
L10010	014216	MDHEDR	002000	MUL	061604	OPR11	010136	PRI07 =	000340	G
L10011	014426	MDLT	010561	MULOAD	004763	OPR12	010167	PRNTST	052452	
L10012	014444	MDROY	010501	MUNDEF	011235	OPR2	007642	PRO.CM	037174	
L10013	014462	MDRERR	010623	MVOLCK	010651	OPR3	007674	PSETNM	002654	
L10014	015464	MDRRES	005622	MWDERR	011051	OPR5	007710	PTAB.S	032214	G
L10015	015604	MDRVST	010747	MWGERR	011000	OPR6	007752	PUTCHR	051266	
L10016	015610	MDSERR	010732	MWLSTA	010710	OPR7	010005	PWCON	015012	
L10017	015654	MEM.SI	036632	MWORD	005575	OPR8	010034	PWRFLG	002662	
L10020	023000	MERRS	011424	MWRCHK	004572	OPR9	010053	PWR.FA	062542	G
L10021	023202	MEXERS	011361	MWRITE	004606	ORIN	002566	PWR.FL	032016	G
L10022	024436	MFLERR	011122	MWRSET	004717	ORINU	002570	PWR.MS	062670	
L10023	025244	MFMTER	005323	MWRTAB	011343	ORMID	002572	PWR.SA	062664	
L10024	025142	MFOLWR	005050	M4OHDR	004703	ORMIDU	002574	PWR.UP	062666	
L10025	025650	MFWDSK	005127	NEWCYL	002514	OROUT	002576	P.CLK	036576	
L10026	025556	MFWSKO	005162	NEWPRI	061330	OROUTU	002600	P2T01E	006267	
L10027	026522	MGTSTA	004622	NEXSTAR	055440	OUTINS=	000040	P2T02E	006267	
L10030	026446	MHCERR	011033	NOCLR =	000010	OSAPTS=	000000	P2T03E	006306	
L10031	027034	MHCRC	010524	NOERCT	002657	OSAU =	000000	P2T04E	006332	
L10032	027120	MHDERR	011105	NOIRPT=	000002	OSBGNR=	000000	P2T05E	006354	
L10033	027420	MHDRCP	004651	NOOP =	000100	OSBGNS=	000001	P2T06E	006376	
L10034	027742	MHFCRC	010573	NOPWR	005463	OSDU =	000001	P2T07E	006420	
L10035	027722	MHNF	010545	NO.CLK	034342	OSGNSW=	000001	P2T08E	006444	
L10036	030374	MHOSTA	010721	NO.FLA	055234	OSPOIN=	000001	P2T09E	006466	
L10037	030272	MHSTA	010634	NO.LPT	052552	PARSE5	054750	P2T10E	006473	
L10040	030372	MINOUT	005025	NO.PTA	037032	PART1 =	000000	P2T11E	006510	
L10041	030712	MIN.IN	032004	NR =	000000	PAR.LA	050742	P2T12E	006525	
L10042	030672	MIN.US	032006	NSTACH	006040	PASCNT	002644	P2T13E	006541	
L10043	031124	MISTST	006015	NUMBIN	045676	PASNEW	014714	P2T14E	006561	
L10044	031040	MISWI =	000000	NUM.LA	046044	PASNUM	002652	P2T15E	006604	
L10045	031400	MISWIW	014446	NUM.UN	032402	PATTBL	002224	P2T16E	006634	
L10046	031356	MITEST =	100000	NUNITS	041312	PAT1	004256	P2T17E	006657	
L10047	031456	MNDRST	011175	NXMERR=	020000	PAT10	004532	P2T18E	006717	
L10050	031572	MNEERR	011150	NXTFOR	055510	PAT2	004260	P2T19E	006744	
MAJ.IN	032010	MNOCLR	005731	NXTPAS	014706	PAT3	004320	RDALHD	020710	
MAJ.LO	057444	MNOINT	005652	OBUFF	003656	PAT4	004360	RDDATA=	000114	
MAJ.US	032012	MODR	061650	OCTMSG	051240	PAT5	004420	RDHEAD=	000110	
MANQ	031664	MOPER	004733	OFIN	002552	PAT6	004426	RDNOHR=	000116	
MAN.TI	034312	MOPERR	011066	OFINU	002554	PAT7	004466	RDYCHK	017366	
MAPROX	007060	MORECE	002426	OFMID	002556	PAT8	004470	RDYWAI	020314	
MAP16	062306	MOUTIN	005004	OFMIDU	002560	PAT9	004530	READRL	016016	
MASK.B	041336	MPNAM	005542	OFOUT	002562	POSHD0	020270	READ.P	057446	G
MASK.W	041334	MQUALS=	003760	OFOUTU	002564	POSHSB	020264	REGBAC	062272	G
MBADAD	005252	MREAD	004542	OLDCYL	002512	POSHW1	020256	REGSAV	062256	G
MBADSF	005273	MREADH	004555	OPFLAG	002416	PRINTC	052562	RELDWT=	040000	
MBHSTA	010675	MRESKO	005216	OPIERR=	002000	PRINTF	056064	REQN.P	037204	
MBSET0=	000001	MREVSK	005074	OPMSG5	002112	PRI0R =	000004	REQN.T	037176	
MCERR	010512	MRLFAL	011302	OPR002	007514	PRI00 =	000000	RESE3	011437	G
MCONHN	005705	MRLSLT	004747	OPR003	007541	PRI01 =	000040	RESE4	011443	G
MCOSTA	010662	MSEEK	004534	OPR004	010235	PRI02 =	000100	RESE5	011450	G
MCYLOC	011170	MSPERR	010762	OPR1	007564	PRI03 =	000140	RESE6	011455	G



RESPAR	002474	STARTC	061114	G	TOSLOW=	000001	T.BA	002460	USER.P	032210	G
RESTAR	014656	STATE2	011462		TRPFLG	002660	T.CS	002456	USER.T	032212	G
REYBL	002164	STATE3	011472		TRPHAN	015612	T.DA	002462	VALDES	007021	
REVSKO=	001000	STATES	011502		TSTINT	016202	T.MP	002464	VALID.	032452	
REVSKS=	000200	STOSTA=	010000		TSTLAB	006007	T.STAT	002472	VAL.LA	033202	
RE.SET	033374	STRCHR	052142		TST.AB	041450	T05ERR	006152	VAL.SW	037240	
RLBA =	000002	STREQ.	036744		TST.TO	033254	T09ERR	006165	VCNAST	005751	
RLBAS	002440	STRT.T	037200		TYPEC	051600	T1	022532	VCSTAT=	001000	
RLCS =	000000	ST.REQ	037120		TYPEPC	045474	T10	027422	VECMG	031472	G
RLCSR =	000000	ST.SET	033444		TYPFLA	055116	T10ERR	006175	VECT =	000002	
RLDA =	000004	SUBSTK	002250		TYPLIN	051476	T10.1	027454	WAITIN	016050	
RLDRV	002444	SUNIT.	037206		TYPNUM	051064	T104\$	027454	WCMSK =	017777	
RLMP =	000006	SUPERV	035164		TYPSTR	051516	T11	027744	WCRNG =	160000	
RLVEC	002442	SUPFLA	032172	G	TYP.ER	045360	T11.1	030122	WDESTA=	100000	
RORWOP=	020000	SUPV.T	032350	G	TY.UNI	040614	T11.2	030274	WGESTA=	002000	
RPTOP	021252	SUP.PR	033216		T\$ARGC=	000002	T115\$	030274	WIDTH	046244	
RPTREM	022246	SVCBGL=	000001		T\$CODE=	000130	T12	030376	WLSTAT=	020000	
RPTRES	022040	SVCCNT=	177777		T\$ERRC=	000043	T12ERR	006215	WRTSWI	002434	
RSTACK	061532	SVCGBL=	177777		T\$ERRN=	002735	T12.1	030424	WTDATA=	000112	
RSTRT	014602	SVCHAN	041516		T\$EXCP=	000000	T124\$	030424	XEQDIA	061416	G
RSX.FL	037216	SVCINS=	000000		T\$FLAG=	000040	T13	030714	XEQSUB	061404	G
SAMSK =	000077	SVCSTK=	177777		T\$HILT=	000377	T13ERR	006227	XEQ.CL	041254	
SBSFIL	002666	SVCSUB=	000001		T\$LOLI=	000000	T13.1	030740	XEQ.CM	036562	
SEARCH	053410	SVCTAG=	000000		T\$LSYM=	010000	T134\$	030740	XEQ.IN	040736	
SECWD	010271	SVCTST=	000001		T\$MCL=	177777	T14	031126	XEQ.LA	035120	
SEEK =	000106	SWCHAN	037024		T\$NEST=	177777	T14ERR	006243	XEQ.OP	041030	
SEEKOP=	010000	SWITCH	055414		T\$NSKO=	000000	T14.1	031150	XEQ.PR	034352	
SEGSTA	032232	SW.PTA	037010		T\$NSK1=	000005	T153\$	031150	XEQ.TE	041074	
SELO	031572	SYS.FT	045330		T\$NSK2=	000002	T16ERR	006257	XRDHD	017636	
SEQMES	010324	T\$LSYM=	010000		T\$SAYL=	177777	T2	023002	XRDHDC	017626	
SETDON	014734	TBLSTR	002436		T\$SEGL=	177777	T25TBL	002274	XRDHDG	017642	
SET.MA	037412	TCERR	010456		T\$SUBN=	000001	T3	023204	XTIME	060124	G
SFTPRM	031526	TEMPO	002530		T\$TAGL=	177777	T33TBL	002322	XTIMEN	060750	
SGNWD	010260	TEMP1	002532		T\$TAGN=	010051	T365\$	024436	XTIMST	060146	
SHIFT	062370	TEMP2	002534		T\$TEMP=	000000	T4	024440	XXDP.D	036772	
SIMSEK	017102	TEMP3	002536		T\$TEST=	000016	T4.1	024460	X\$ALWA=	000000	
SIZE.C	061246	TEMP4	002540		T\$TSTM=	177777	T465\$	025134	X\$FALS=	000040	
SIZE.M	061164	TEMP5	002542		T\$TSTS=	000001	T5	025246	X\$OFFS=	000400	
SIZ.TR	061324	TEMP6	002544		T\$SCLE=	010015	T5.1	025540	X\$TRUE=	000020	
SKTMES	006756	TEMP7	002546		T\$SDU =	010016	T504\$	025572	XIX1 =	072000	
SPDERR	006052	TEMP8	002550		T\$SHAR=	010047	T6	025652	\$BREG	037300	
SPDSTA=	004000	TERMI	057434		T\$SHW =	010012	T6.1	026246	\$ENDAD	061370	G
SPEC.U	037122	TERMLI	055242		T\$SINI=	010014	T7	026524	\$SAV2	062434	G
SPTCOD	014444	TERMTA	051224		T\$MSG=	010011	T8	027036	\$SAV3	062450	G
SPV.SE	033624	TEST.M	037134		T\$SOF=	010050	T9	027122	\$SAV4	062466	G
SRTMES	006772	TIMFLG	032162	G	T\$SRV=	010017	ULOAD =	000010	\$SAV5	062506	G
SSINDX	002414	TIM.CO	032014	G	T\$SUB=	010046	UNDTST	010222	=	072000	
STAMES	010367	TIM.OP	045650		T\$SW =	010013	UNI.MA	037124			
STAMSK=	000007	TOO.MA	051204		T\$TES=	010045	UNXERR	005772			

. ABS. 072000 000

ERRORS DETECTED: 0

DSKZ:DZRLCA,DSKZ:DZRLCA/EQ:PART1=DZRLCA.SML,DZRLCA.PT1,DZRLCA.P11,DZRLCA.PT2,DZRLCA.SUP

OUTERR MACY11 30(1046) 04-NOV-77 13:14 PAGE 97-4  
DZRLCA.SUP 11-OCT-77 15:40 SYMBOL TABLE

SEQ 0112

RUN-TIME: 45 49 1 SECONDS  
RUN-TIME RATIO: 1257/96=13.0  
CORE USED: 19K (35 PAGES)



J09