

.REM &

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36

IDENTIFICATION

PRODUCT CODE: AC-E451A-MC
PRODUCT NAME: CXTSAA0 DEC/X11 TS11/TS04 MOD
PRODUCT DATE: FEB 1979
MAINTAINER: DEC/X11 SUPPORT GROUP

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS MANUAL.

THE SOFTWARE DESCRIBED IN THIS DOCUMENT IS FURNISHED TO THE PURCHASER UNDER A LICENSE FOR USE ON A SINGLE COMPUTER SYSTEM AND CAN BE COPIED (WITH INCLUSION OF DIGITALS COPYRIGHT NOTICE) ONLY FOR USE IN SUCH SYSTEM, EXCEPT AS MAY OTHERWISE BE PROVIDED IN WRITING BY DIGITAL.

DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL.

COPYRIGHT (C) 1978,1979 DIGITAL EQUIPMENT CORPORATION

37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67
68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92

1.0 ABSTRACT

TSA IS AN IOMODX MODULE THAT CAN EXERCISE UP TO 4 TS11/TS04 MAGNETIC TAPE SUBSYSTEMS. IT EXERCISES THE DRIVES BY DOING A WRITE, READ REVERSE, IN-CORE COMPARE, READ FORWARD, IN CORE COMPARE. THIS SEQUENCE OF FUNCTIONS WILL BE DEFINED AS A CYCLE. AN "END OF PASS" WILL BE REACHED AFTER 512 CYCLES. ALL ERRORS DETECTED ARE REPORTED ON THE CONSOLE TTY.

2.0 REQUIREMENTS

HARDWARE: 1 TO 4 TS11/TS04 TAPE SUBSYSTEMS.
STORAGE: TSA REQUIRES 1345 WORDS OF STORAGE.

3.0 PASS DEFINITION

ONE PASS OF THE TSA MODULE CONSISTS OF 512 CYCLES OF THE BASIC TEST SEQUENCE (WRITE, READ REVERSE, DATA COMPARE, READ FORWARD, DATA COMPARE). THE WRITE AND READ DATA LENGTHS ARE 256 WORDS.

4.0 EXECUTION TIME

ONE PASS OF TSA RUNNING ALONE ON A PDP-11/34 TAKES APPROXIMATELY 1 MINUTE.

5.0 CONFIGURATION REQUIREMENTS

DEFAULT PARAMETERS:

DEVADR: 172520 VECTOR: 224 BR1: 5 DEVCNT: 1

REQUIRED PARAMETERS:

(REQUIRED FOR MULTIPLE DRIVE OPERATION ONLY)

SR2: VECTOR FOR 2ND DRIVE

SR3: VECTOR FOR 3RD DRIVE

SR4: VECTOR FOR 4TH DRIVE

6.0 DEVICE/OPTION SETUP

MAKE CERTAIN THAT ALL DRIVES ARE POWERED UP, WRITE ENABLED AND ON LINE. HAVING ALL DRIVES AT LOAD POINT IS NOT ESSENTIAL TO THE OPERATION OF THE MODULE BUT WILL ENSURE THAT THE RECORD COUNT ACCURATELY REFLECTS THE NUMBER OF RECORDS FROM LOAD POINT ON THE 1ST PASS OF TAPE. (THE RECORD COUNT ACCOMPANIES ALL ERROR PRINTOUTS AND CAN BE USED TO IDENTIFY BAD SPOTS ON TAPE).

93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117
118
119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142
143
144
145
146
147
148

7.0 MODULE OPERATION

TEST SEQUENCE:

- A. SET UP DEVICE REGISTER ADDRESSES AND MODULE VARIABLES.
- B. INITIALIZE ALL DEVICES.
- C. GET A DEVICE ADDRESS.
- D. ISSUE SET CHARACTERISTIC AND ERASE COMMANDS TO THE DEVICE.
- E. IF NOT END OF DEVICES, GO TO C.
- F. GET NEXT DEVICE ADDRESS.
- G. DO A WRITE - IF ERRORS, REPORT AND RETRY TO THE RETRY LIMIT.
- H. DO A READ REVERSE - IF ERRORS, REPORT AND RETRY TO THE RETRY LIMIT.
- I. DO A DATA CHECK - IF ERRORS, REPORT AND CONTINUE.
- J. DO A READ FORWARD - IF ERRORS, REPORT AND RETRY TO THE RETRY LIMIT.
- K. DO A DATA CHECK - IF ERRORS, REPORT AND CONTINUE.
- L. IF AT END OF TAPE - DO A REWIND.
- M. IF END OF PASS, REPORT AND GO TO C, ELSE GO TO F.

ERROR RECOVERY SEQUENCE:

```
IF RETRY LIMIT HAS BEEN REACHED, THEN:  
: PRINT UNRECOVERABLE ERROR.  
: IF BIT 0 IS SET IN SRI, THEN:  
: : DROP THIS DEVICE FROM THE TEST SEQUENCE.  
ELSE:  
: PRINT RECOVERABLE ERROR.  
: INCREMENT THE RETRY COUNTER.  
: IF THE FUNCTION IS A READ, THEN:  
: : IF THE RETRY COUNT IS HALF THE LIMIT OR MORE, THEN:  
: : : SET THE OPPOSITE DIRECTION BIT IN THE RETRY COMMAND.  
: : ISSUE THE RETRY COMMAND TO THE DEVICE.
```

RETRY LIMITS:

FOR READ/WRITE COMMANDS = 16 RETRIES.
FOR ALL OTHER COMMANDS = 8 RETRIES.

149
150
151
152
153
154
155
156
157
158
159
160
161
162
163
164
165
166
167
168
169
170
171
172
173
174
175
176
177
178
179
180
181
182
183
184
185
186
187
188
189
190
191
192
193
194
195
196
197
198
199
200
201
202

8.0 OPERATION OPTIONS

SRI BIT0 CLEAR (0):

IF AN UNRECOVERABLE ERROR OCCURS ON ANY FUNCTION, THE FUNCTION IS ABORTED AND TESTING CONTINUES.

SRI BIT0 SET (1):

IF AN UNRECOVERABLE ERROR OCCURS ON ANY FUNCTION, THE DEVICE IS DROPPED FROM THE TEST CYCLE.

SRI BIT1 CLEAR (0):

ALL RECOVERABLE ERRORS ARE REPORTED.

SRI BIT1 SET (1):

RECOVERABLE ERRORS ARE NOT REPORTED.

9.0 NON-STANDARD PRINTOUTS

ALL PRINTOUTS HAVE THE STANDARD FORMATS DESCRIBED IN THE DEC/X11 DOCUMENTS.

ERROR MESSAGES DUMP THE CONTENTS OF 10 LOCATIONS IN THE FOLLOWING ORDER:

DCNT MTYPE MLEN RPC XSTAT0 XSTAT1 XSTAT2 XSTAT3
RECORD RTRYC

DCNT = DEVICE NUMBER (0 - 3).
MTYPE = MESSAGE PACKET 1ST WORD - MESSAGE TYPE.
MLEN = MESSAGE PACKET 2ND WORD - MESSAGE LENGTH.
RPC = MESSAGE PACKET 3RD WORD - RESIDUAL FRAME COUNT.
XSTAT0 = MESSAGE PACKET 4TH WORD - EXTENDED STATUS REG 0.
XSTAT1 = MESSAGE PACKET 5TH WORD - EXTENDED STATUS REG 1.
XSTAT2 = MESSAGE PACKET 6TH WORD - EXTENDED STATUS REG 2.
XSTAT3 = MESSAGE PACKET 7TH WORD - EXTENDED STATUS REG 3.
RECORD = RECORD COUNT - NUMBER OF RECORDS FROM BOT.
RTRYC = RETRY COUNT (WILL BE 0 ON ORIGINAL ERROR).

10.0 DEFINITION OF ERRORS

RECOVERABLE ERROR - TERMINATION CLASS CODE OF 4 OR 5 AND RETRY LIMIT NOT EXCEEDED.

UNRECOVERABLE ERROR - TERMINATION CLASS CODE OF 6 OR TERMINATION CLASS CODE OF 4 OR 5 AND RETRY LIMIT EXCEEDED.

&

```
203 000000- IOMODX <TSAA > 172520,224,5,0,0,512,163,BUFIN,256,256-
204 000000- MODULE 150000,TSAA 172520,224,5,0,0,512,163,BUFIN,256,256.
205
206 ; TITLE TSAA DEC/X11 SYSTEM EXERCISER MODULE
207 ; DDCRM VERSION 6 23-MAY-78
208 ; LIST BIN
209 *****LIST*****
210 BEGIN:
211 MODNAM: .ASCII /TSAA / ;MODULE NAME
212 XPLAG: .BYTE OPEN ;USED TO KEEP TRACK OF WBUFF USAGE
213 ADDR: 172520+0 ;1ST DEVICE ADDR
214 VECTOR: 224+0 ;1ST DEVICE VECTOR.
215 BR1: .BYTE PR1Y5+0 ;1ST BR LEVEL.
216 BR2: .BYTE PR1Y0+0 ;2ND BR LEVEL.
217 DVID1: 0+1 ;DEVICE INDICATOR 1.
218 SR1: OPEN ;SWITCH REGISTER 1
219 SR2: OPEN ;SWITCH REGISTER 2
220 SR3: OPEN ;SWITCH REGISTER 3
221 SR4: OPEN ;SWITCH REGISTER 4
222 *****LIST*****
223 STAT: 150000 ;STATUS WORD
224 INIT: START ;MODULE START ADDR.
225 SPOINT: MODSP ;MODULE STACK POINTER.
226 PASCNT: 0 ;PASS COUNTER.
227 ICOUNT: 512- ;# OF ITERATIONS PER PASS=512.
228 SOFCNT: 0 ;LOC TO COUNT ITERATIONS
229 HRDCNT: 0 ;LOC TO SAVE TOTAL SOFT ERRORS
230 SOFPAS: 0 ;LOC TO SAVE TOTAL HARD ERRORS
231 HRDPAS: 0 ;LOC TO SAVE SOFT ERRORS PER PASS
232 SYSCNT: 0 ;LOC TO SAVE HARD ERRORS PER PASS
233 RANUM: 0 ;# OF SYS ERRORS ACCUMULATED
234 CMFIC: 0 ;HOLDS RANDOM # WHEN RAND MACRO IS CALLED
235 RES1: 0 ;RESERVED FOR MONITOR USE
236 RES2: 0 ;RESERVED FOR MONITOR USE
237 SVR0: OPEN ;LOC TO SAVE R0.
238 SVR1: OPEN ;LOC TO SAVE R1.
239 SVR2: OPEN ;LOC TO SAVE R2.
240 SVR3: OPEN ;LOC TO SAVE R3.
241 SVR4: OPEN ;LOC TO SAVE R4.
242 SVR5: OPEN ;LOC TO SAVE R5.
243 SVR6: OPEN ;LOC TO SAVE R6.
244 CSRA: OPEN ;ADDR OF CURRENT CSR.
245 SBADR: OPEN ;ADDR OF GOOD DATA, OR
246 ACSR: OPEN ;CONTENTS OF CSR.
247 WASADR: OPEN ;ADDR OF BAD DATA OR
248 ASAT: OPEN ;STATUS REG CONTENTS.
249 ERRTP: OPEN ;TYPE OF ERROR
250 ASB: OPEN ;EXPECTED DATA.
251 AWAS: OPEN ;ACTUAL DATA.
252 RSTRT: RSTRT ;RESTART ADDRESS AFTER END OF PASS
253 WDMTO: OPEN ;WORDS TO MEMORY PER ITERATION
254 WDFR: OPEN ;WORDS FROM MEMORY PER ITERATION
255 INTR: OPEN ;# OF INTERRUPTS PER ITERATION
256 IOMU: 163 ;MODULE IDENTIFICATION NUMBER=163
257 RBUFFA: BUFIN ;READ BUFFER VIRTUAL ADDRESS
258 RBUFFP: OPEN ;READ BUFFER PHYSICAL ADDRESS
```

```
259 000130- 000000 RBUFFE: OPEN ;READ BUFFER EA BITS
260 000132- 000400 RBUFFS: 256 ;SIZE OF THE READ BUFFER
261 000134- 000000 WBUFFA: OPEN ;WRITE BUFFER PHYSICAL ADDRESS
262 000136- 000000 WBUFFE: OPEN ;WRITE BUFFER EA BITS
263 000140- 000400 WBUFFS: 256 ;WRITE BUFFER SIZE REQUESTED
264 000142- 000000 WDFRPSZ: OPEN ;WRITE BUFFER SIZE AVAILABLE
265 000144- 000000 CDERICT: OPEN ;DATA/DATCK ERROR COUNT
266 000146- 000000 CDMCT: OPEN ;DATA/DATCK WORD COUNT
267 000148- 000000 FREE: OPEN ;RESERVED FOR FUTURE USE
268 000150- 000040 FREE: .REPT SPSIZ ;MODULE STACK STARTS HERE.
269 .-NLIST
270 .-WORD 0
271 .-LIST
272 .-ENDR
273 MODSP:
274 000252-
275 *****LIST*****
```

275
276
277
278
279 000252
280 000252
281
282 000001
283 000001
284
285
286
287
288
289 140204
290 100611
291 100205
292 100201
293 100201
294 102210
295 101205
296 101601
297 101201
298
299
300 020000
301
302
303
304 000200
305 100000
306
307
308
309 000001
310
311
312 000020
313 000020
314 000010
315 000016
316 000004
317 000040
318 177777
319
320

```
.LIST MC
.WLIST ME
.MCALL STRUCT
STRUCT
; INITIALIZE STRUCTURED MACROS
.PRINT ;SPMAC; VERSION 1.1
; LIST STRUCTURED MACRO INSTRUCTIONS.
; LIST STRUCTURED MACRO TAGS.
SLSTTAG=1
-----
; THE FOLLOWING ARE TS04 COMMAND DEFINITIONS.
SCH=140204 ;SET CHARACTERISTIC.
ERS=100611 ;ERASE.
WRA=100205 ;WRITE.
RDA=100601 ;READ REVERSE.
RDF=100201 ;READ FORWARD.
RWD=102210 ;REWIND.
WTR=101205 ;WRITE RETRY.
RRR=101601 ;READ REVERSE RETRY.
RFR=101201 ;READ FORWARD RETRY.
; THE FOLLOWING ARE COMMAND WORD BIT DEFINITIONS.
CM.OPP=20000 ;OPPOSITE DIRECTION BIT.
; THE FOLLOWING ARE TSSR(STATUS REGISTER) BIT DEFINITIONS.
TS.SSR=200 ;SUBSYSTEM READY.
TS.SC=100000 ;SPECIAL CONDITION.
; THE FOLLOWING ARE EXTENDED STATUS REGISTER 0 BIT DEFINITIONS.
XSO.EOT=1 ;END OF TAPE.
; MISCELLANEOUS DEFINITIONS.
WRRETRY=16. ;WRITE COMMAND RETRY LIMIT.
RRRETRY=16. ;READ COMMAND RETRY LIMIT.
CRRETRY=8. ;RETRY LIMIT FOR NON-READ/WRITE CMDS.
MSGCNT=14. ;MESSAGE PACKET LENGTH IN BYTES.
SCHCNT=4. ;SET CHARACTERISTIC BLOCK LENGTH IN WORDS.
SCDPL=40. ;CHARACTERISTIC CODE DEFAULT.
TERM=177777 ;TABLE TERMINATION INDICATOR.
-----
```

321
322
323 000252 000622
324 000254 000000
325 000256 000000
326 000260 000644
327 000262 000000
328 000264 000000
329 000266 000634
330 000270 000000
331 000272 000000
332
333
334
335 000274 000000
336 000276 000000
337 000300 000000
338 000302 000000
339
340
341
342 000304 000000
343 000306 000000
344 000310 000000
345
346
347
348 000312 000000
349 000314 000000
350 000316 000000
351 000320 000000
352
353
354
355
356 000322 000000
357 000324 000000
358 000326 000000
359 000330 000000
360 000332 000000
361 000334 000000
362 000336 000000
363 000340 000000
364 000342 000000
365 000344 000000
366 000346 000000
367 000350 000000
368 000352 000000
369 000354 000000
370 000356 000000
371 000360 000000

```
; THE FOLLOWING LOCATIONS ARE USED TO REQUEST BUFFERS FROM THE MONITOR.
CBUPVA: CNDPKT ;COMMAND PACKET VIRTUAL ADDRESS.
CBUPPA: 0 ;COMMAND PACKET PHYSICAL ADDRESS.
CBUPEA: 0 ;COMMAND PACKET EA BITS.
MBUPVA: MSGPKT ;MESSAGE PACKET VIRTUAL ADDRESS.
MBUPPA: 0 ;MESSAGE PACKET PHYSICAL ADDRESS.
MBUPEA: 0 ;MESSAGE PACKET EA BITS.
SBUPVA: MSGBLK ;MESSAGE BLOCK VIRTUAL ADDRESS.
SBUPPA: 0 ;MESSAGE BLOCK PHYSICAL ADDRESS.
SBUPEA: 0 ;MESSAGE BLOCK EA BITS.
; THE FOLLOWING LOCATIONS ARE THE DEVICE POINTERS.
DCNT: 0 ;DEVICE COUNTER.
DINX: 0 ;DEVICE INDEX.
DIWD: 0 ;DEVICE INDICATOR.
VIND: 0 ;VARIABLE DEVICE INDICATOR.
; THE FOLLOWING LOCATIONS ARE DEVICE VARIABLES.
TSSR: 0 ;STATUS REGISTER ADDRESS OF CURRENT DEVICE.
VECT: 0 ;VECTOR ADDRESS OF CURRENT DEVICE.
RECORD: 0 ;RECORD COUNT OF CURRENT DEVICE.
; THE FOLLOWING LOCATIONS ARE COMMAND VARIABLES.
CMD: 0 ;CURRENT TS04 COMMAND WORD.
RCMD: 0 ;RETRY COMMAND WORD.
RTRVL: 0 ;RETRY LIMIT.
RTRVC: 0 ;RETRY COUNT.
; THE FOLLOWING TABLES ARE USED TO SET THE DEVICE VARIABLES.
; THESE TABLES ARE INITIALIZED DURING MODULE START INITIALIZATION.
TTSDB: 0 ;TTSDB ADR FOR DEVICE 0.
;TTSDB ADR FOR DEVICE 1.
;TTSDB ADR FOR DEVICE 2.
;TTSDB ADR FOR DEVICE 3.
TTSSR: 0 ;TSSR ADR FOR DEVICE 0.
;TTSSR ADR FOR DEVICE 1.
;TTSSR ADR FOR DEVICE 2.
;TTSSR ADR FOR DEVICE 3.
TVECT: 0 ;VECTOR ADR FOR DEVICE 0.
;VECTOR ADR FOR DEVICE 1.
;VECTOR ADR FOR DEVICE 2.
;VECTOR ADR FOR DEVICE 3.
TREC: 0 ;RECORD COUNT FOR DEVICE 0.
;RECORD COUNT FOR DEVICE 1.
;RECORD COUNT FOR DEVICE 2.
;RECORD COUNT FOR DEVICE 3.
```

```

372
373
374 000362 140204
375 000364 140204
376 000366 000010
377 000370 005053
378 000372 000270
379 000374 000270
380 000376 000270
381 000400 100611
382 000402 100611
383 000404 000010
384 000406 005064
385 000408 000560
386 000412 000560
387 000414 000560
388 000416 100205
389 000420 101205
390 000422 000070
391 000424 005072
392 000426 000134
393 000430 000136
394 000432 000142
395 000434 100601
396 000436 101601
397 000440 000020
398 000442 005100
399 000444 000126
400 000446 000130
401 000448 000132
402 000452 100201
403 000454 101201
404 000456 000020
405 000460 005111
406 000462 000126
407 000464 000132
408 000466 000132
409 000470 102210
410 000472 102210
411 000474 000010
412 000476 005172
413 000500 000270
414 000502 000560
415 000504 000560
416
417
418
419 000506 000
420 000507 000
421 000510 000
422 000511 000
423

```

```

) THE FOLLOWING TABLES ARE USED TO SET UP COMMAND VARIABLES.
SCHAR: SCH ;SET CHARACTERISTIC COMMAND.
SCH ;RETRY COMMAND.
CRETRY ;RETRY LIMIT.
SCHAS ;ADDRESS OF CMD ASCII.
SBUFFA ;ADDRESS OF BUFFER PHYSICAL ADR.
SBUFFE ;ADDRESS OF BUFFER EXTENDED ADR.
SBUFFS ;ADDRESS OF BUFFER SIZE.
ERASE: ERS ;ERASE COMMAND.
ERS ;RETRY COMMAND.
CRETRY ;RETRY LIMIT.
ERSAS ;ADDRESS OF CMD ASCII.
BCON ;ADDRESS OF BUFFER PHYSICAL ADR.
BCON ;ADDRESS OF BUFFER EXTENDED ADR.
BCON ;ADDRESS OF BUFFER SIZE.
WRITE: WRT ;WRITE COMMAND.
WRT ;RETRY COMMAND.
WRTR ;RETRY LIMIT.
WRTRAS ;ADDRESS OF CMD ASCII.
WBUFFA ;ADDRESS OF BUFFER PHYSICAL ADR.
WBUFFE ;ADDRESS OF BUFFER EXTENDED ADR.
WBUFFS ;ADDRESS OF BUFFER SIZE.
RREV: RRR ;READ REVERSE COMMAND.
RRR ;RETRY COMMAND.
RRETRY ;RETRY LIMIT.
RDRAS ;ADDRESS OF CMD ASCII.
RBUFFA ;ADDRESS OF BUFFER PHYSICAL ADR.
RBUFFE ;ADDRESS OF BUFFER EXTENDED ADR.
RBUFFS ;ADDRESS OF BUFFER SIZE.
RFWD: RFR ;READ FORWARD COMMAND.
RFR ;RETRY COMMAND.
RRETRY ;RETRY LIMIT.
RDRAS ;ADDRESS OF CMD ASCII.
RBUFFA ;ADDRESS OF BUFFER PHYSICAL ADR.
RBUFFE ;ADDRESS OF BUFFER EXTENDED ADR.
RBUFFS ;ADDRESS OF BUFFER SIZE.
REWIND: RWD ;REWIND COMMAND.
RWD ;RETRY COMMAND.
CRETRY ;RETRY LIMIT.
RDRAS ;ADDRESS OF CMD ASCII.
BCON ;ADDRESS OF BUFFER PHYSICAL ADR.
BCON ;ADDRESS OF BUFFER EXTENDED ADR.
BCON ;ADDRESS OF BUFFER SIZE.
) THE FOLLOWING BYTES ARE USED AS PROGRAM CONTROL FLAGS.
EOD: .BYTE 0 ;END OF DEVICES.
DROP: .BYTE 0 ;CURRENT DEVICE HAS BEEN DROPPED.
DMOD: .BYTE 0 ;MODULE IS TO BE DROPPED.
EREC: .BYTE 0 ;ERROR RECOVERY IS REQUIRED.
.EVEN

```

```

424
425
426
427 000512 000
428 000513 000
429 000514 000
430 000515 000
431
432
433
434
435 000516 003610
436 000520 003660
437 000522 003732
438 000524 004010
439 000526 004062
440 000528 004170
441 000530 004226
442 000532 004276
443 000534 004234
444
445
446
447
448 000536 004454
449 000540 004464
450 000542 004474
451 000544 004504
452
453
454
455
456 000546 000000
457
458 000550 000000
459 000552 000000
460 000554 000000
461 000556 000000
462
463
464
465 000560 000001
466 000562 000002
467 000564 000004
468 000566 000010
469
470
471
472
473 000570 000274
474 000572 000644
475 000574 000646
476 000576 000650
477 000600 000652
478 000602 000654
479 000604 000656

```

```

) THE FOLLOWING BYTES ARE UNEXPECTED INTERRUPT FLAGS AND MUST BE
ASSEMBLED IN ORDER.
UIFLO: .BYTE 0 ;DEVICE 0.
UIFL1: .BYTE 0 ;DEVICE 1.
UIFL2: .BYTE 0 ;DEVICE 2.
UIFL3: .BYTE 0 ;DEVICE 3.
.EVEN
) THE FOLLOWING LOCATIONS CONTAIN ADDRESSES OF THE TERMINATION CLASS CODE
HANDLING ROUTINES AND MUST BE ASSEMBLED IN ORDER.
TCCRA: TCC0 ;TERMINATION CLASS CODE 0.
TCC1 ;TERMINATION CLASS CODE 1.
TCC2 ;TERMINATION CLASS CODE 2.
TCC3 ;TERMINATION CLASS CODE 3.
TCC4 ;TERMINATION CLASS CODE 4.
TCC5 ;TERMINATION CLASS CODE 5.
TCC6 ;TERMINATION CLASS CODE 6.
TCC7 ;TERMINATION CLASS CODE 7.
) THE FOLLOWING LOCATIONS CONTAIN ADDRESSES OF UNEXPECTED INTERRUPT
ROUTINES AND MUST BE ASSEMBLED IN ORDER.
UIADR: UID0 ;DEVICE 0.
UID1 ;DEVICE 1.
UID2 ;DEVICE 2.
UID3 ;DEVICE 3.
) THE FOLLOWING LOCATIONS CONTAIN ADDRESSES OF THE COMMAND PACKET WORDS.
THESE ADDRESSES ARE CALCULATED AND STORED DURING INITIALIZATION.
CMDADR: 0 ;COMBINED PHYSICAL COMMAND PACKET
;ADDRESS WITH EXTENDED BITS IN BITS 0+1.
CMDPK1: 0 ;ADDRESS OF COMMAND PACKET 1ST WORD.
CMDPK2: 0 ;ADDRESS OF COMMAND PACKET 2ND WORD.
CMDPK3: 0 ;ADDRESS OF COMMAND PACKET 3RD WORD.
CMDPK4: 0 ;ADDRESS OF COMMAND PACKET 4TH WORD.
) THE FOLLOWING CONSTANTS MUST BE ASSEMBLED IN ORDER.
BCON: 1
2
4
10
) THE FOLLOWING TABLE CONTAINS ADDRESSES OF VARIABLES TO BE PRINTED
IN THE EXTENDED ERROR REPORTS.
TABLE: DCNT ;DEVICE NUMBER
MSGPKT ;STATUS MESSAGE TYPE.
MSGPKT+2 ;STATUS MESSAGE LENGTH IN BYTES.
MSGPKT+4 ;RESIDUAL FRAME COUNT.
MSGPKT+6 ;EXTENDED STATUS REGISTER 0.
MSGPKT+10 ;EXTENDED STATUS REGISTER 1.
MSGPKT+12 ;EXTENDED STATUS REGISTER 2.

```

```

480 000606 000660 MSGPKT+14 ;EXTENDED STATUS REGISTER 3.
481 000618 000310 RECORD ;RECORD COUNT.
482 000612 000320 RTRVC ;RTRY COUNT.
483 000614 177777 TERM ;TABLE TERMINATOR.
484
485 ; MISCELLANEOUS PROGRAM VARIABLES.
486
487 SBUSFSZ: SCHCNT ;SET CHARACTERISTIC BLOCK LENGTH IN WORDS.
488 000620 000000 TIME: 0 ;TIMEOUT COUNTER.
489
490 ; THIS IS THE COMMAND PACKET - IT MUST BE ON A MODULO 4 BOUNDRY.
491
492 CNDPKT: 0 ;TS04 COMMAND WORD.
493 0 ;BUFFER PHYSICAL ADDRESS.
494 000624 000000 ;BUFFER EXTENDED ADR IN BITS 0+1.
495 0 ;BUFFER LENGTH IN BYTES.
496 000630 000000 ;EXTENSION TO INSURE MODULO 4 BOUNDRY
497 000632 000000 ;(1ST 4 WORDS CAN BE PUSHED DOWN 1 WORD).
498
499 ; THIS IS THE SET CHARACTERISTIC BLOCK.
500
501 MSGBLK: 0 ;MESSAGE PACKET PHYSICAL ADDRESS.
502 0 ;MESSAGE PACKET EXTENDED ADR IN BITS 0+1.
503 000636 000000 ;MESSAGE PACKET LENGTH IN BYTES.
504 000640 000016 SCDFLT ;DEFAULT CHARACTERISTIC CODE.
505
506 ; THIS IS THE MESSAGE PACKET.
507
508 MSGPKT: 0 ;MESSAGE TYPE.
509 0 ;MESSAGE LENGTH IN BYTES.
510 000650 000000 ;RESIDUAL FRAME COUNT.
511 000652 000000 RFC: 0 ;EXTENDED STATUS REGISTER 0.
512 000654 000000 XSTAT0: 0 ;EXTENDED STATUS REGISTER 1.
513 000656 000000 XSTAT1: 0 ;EXTENDED STATUS REGISTER 2.
514 000660 000000 XSTAT2: 0 ;EXTENDED STATUS REGISTER 3.
515
516 ; THIS IS THE READ BUFFER.
517
518 BUFIN: .BLKW 256. ;512 BYTES.
519

```

```

520 001662 START: LET WOTO := RBUFSZ SHFT 1 ;LET # OF READ WDS PER CYCLE = BUFFER SIZE X2.
521 001662 016767 176244 176224 ;MOV RBUFSZ,WOTO
522 001670 006367 176220 ;ASL WOTO
523 001674 LET WDFR := WBUFSZ ;LET # OF WRITE WDS PER CYCLE = BUFFER SIZE.
524 001674 016767 176242 176214 ;MOV WBUFSZ,WDFR
525 001702 LET INTR := #3 ;LET # OF INTERRUPTS PER CYCLE = 3.
526 001710 012767 000003 176210 ;MOV #3,INTR
527 001710 LET DIND := DVID1 ;LET DEVICE INDICATOR AND SAVE IT.
528 001710 016767 176100 176362 ;MOV DVID1,DIND
529 001716 LET DMOD :B= #0 ;CLEAR MODULE DROP FLAG.
530 001716 105067 176566 ;CLR DMOD
531 001722 CALL IDP ;CALL IDP-INITIALIZE DEVICE POINTERS.
532 001722 004767 001046 ;JSR PC,IDP
533 001726 WHILE EOD EQ #0 DO ;WHILE THERE ARE MORE DEVICES:
534 001726 105767 176554 ;50000$: TSTR EOD
535 001732 001053 ;BNE 50001$
536 001734 LET R1 := DCNT ;SAVE DEVICE COUNTER IN REGISTER.
537 001734 016701 176334 ;MOV DCNT,R1
538 001740 LET R2 := DINK ;SAVE DEVICE INDEX IN REGISTER.
539 001740 016702 176332 ;MOV DINK,R2
540 001744 LET R3 := R2 SHFT 1 ;SAVE DEVICE ADDRESS INCREMENT IN REGISTER.
541 001744 010203 ;MOV R2,R3
542 001746 006303 ;ASL R3
543 001750 LET TTSDR(R2) := ADDR + R3 ;GENERATE AND STORE TSDBR ADR IN TSDBR TABLE.
544 001750 016762 176032 000322 ;MOV ADDR,TTSDR(R2)
545 001756 060362 000322 ;ADD R3,TTSDR(R2)
546 001762 LET TTSSR(R2) := TTSDR(R2) + #2 ;GENERATE AND STORE TSSR ADR IN TSSR TABLE.
547 001762 016262 000322 000332 ;MOV TTSDR(R2),TTSSR(R2)
548 001770 062762 000002 000332 ;ADD #2,TTSSR(R2)
549 001776 IF R2 EQ #0 THEN ;IF THIS IS THE FIRST DEVICE THEN:
550 001776 005702 ;TST R2
551 001800 001004 ;BNE 50002$
552 002002 LET TVECT := VECTOR ;STORE VECTOR DEFAULT IN VECTOR TABLE.
553 002002 016767 176002 176332 ;MOV VECTOR,TVECT
554 002010 ELSE ;ELSE - FOR ALL OTHER DEVICES:
555 002010 000403 ;BR 50003$
556 002012 LET TVECT(R2) := SR1(R2) ;STORE SR2-SR4 CONTENTS IN VECTOR TABLE.
557 002012 016262 000016 000342 ;MOV SR1(R2),TVECT(R2)
558 002020 ENDF
559 002020 50003$:
560 002020 LET TREC(R2) := #0 ;CLEAR THIS DEVICE'S RECORD COUNT.
561 002020 005062 000352 ;CLR TREC(R2)
562 002024 LET UIFLO(R1) :B= #0 ;CLEAR UNEXPECTED INTERRUPT FLAG.
563 002024 105061 000512 ;CLR UIFLO(R1)
564 002030 CALL DVSET ;CALL DVSET-SET UP DEVICE VARIABLES.
565 002030 004767 000672 ;JSR PC,DVSET
566 002034 LET R4 := VECT ;SAVE VECTOR ADDRESS IN REGISTER.
567 002034 016704 176246 ;MOV VECT,R4
568 002040 LET (R4)+ := UIADR(R2) ;POINT VECTOR TO UNEXPECTED INTERRUPT ROUTINE.
569 002040 016224 000536 ;MOV UIADR(R2),(R4)+
570 002044 LET (R4) :B= BR1 ;STORE INTERRUPT PRIORITY IN VECTOR.
571 002044 116714 175742 ;MOV BR1,(R4)
572 002050 LET @TSSR := #0 ;ISSUE SUBSYSTEM INITIALIZATION TO TS04.
573 002050 005077 176230 ;CLR @TSSR
574
575

```



```

576 002054 004767 000744 CALL UPDP ;CALL UPDP-UPDATE DEVICE POINTER TO NEXT DEV.
577 002054 004767 000744 ENDDO ;END OF DEVICE INITIALIZATION LOOP.
578 002060 000722 BR 50007S ;BYPASS DT03 BUS SWITCH CHECK WHEN STARTING.
579 002062 000404 BR CONTUE ;BYPASS DT03 BUS SWITCH CHECK WHEN STARTING.
580 002062 000404 BR 50007S ;BYPASS DT03 BUS SWITCH CHECK WHEN STARTING.
581 002062 000404 BR 50007S ;BYPASS DT03 BUS SWITCH CHECK WHEN STARTING.
582 002064 005767 175744 RESTR: IF PASCNT EQ #0 THEN ;IF THE PASS COUNT IS CLEARED THEN:
583 002064 005767 175744 TST PASCNT
584 002070 001001 BNE 50004S
585 002072 000673 BR START ;GO TO START PROCESSORS HAVE BEEN SWITCHED.
586 002074 000673 ENDP ;END OF DT03 BUS SWITCH CHECK.
587 002074 000673 BR 50004S
588 002074 000673 BR 50004S
589 002074 000673 BR 50004S
590 002074 000673 BR 50004S
591 002074 000673 BR 50004S
592 002074 000673 BR 50004S
593 002074 000673 BR 50004S
594 002074 000673 BR 50004S
595 002074 000673 BR 50004S
596 002074 000673 BR 50004S
597 002102 104415 000000 000124 CONTUE: GETPAS,BEGIN, RBUFVA ;GET PHYSICAL ADDRESS FROM 16-BIT RBUFVA
598 002102 104415 000000 000252 GETPAS,BEGIN, CBUFVA ;GET PHYSICAL ADDRESS FROM 16-BIT CBUFVA
599 002110 032767 000003 176136 .LIST MC
600 002110 032767 000003 176136 IF #BIT0BIT1 SETIM CBUPPA THEN ;IF CMDPKT ADR IS NOT ON A MODULO 4 BOUNDRY THEN
601 002120 062767 000002 176124 LET CBUFVA := CBUFVA + #2 ;INCREASE CMDPKT VIRTUAL ADR BY 2.
602 002120 062767 000002 176124 ADD #2,CBUFVA
603 002126 104415 000000 000252 .LIST MC
604 002126 104415 000000 000252 GETPAS,BEGIN, CBUFVA ;GET PHYSICAL ADDRESS FROM 16-BIT CBUFVA
605 002134 016767 176116 176404 .LIST MC
606 002134 016767 176116 176404 ENDP ;END OF CMD PACKET ADDRESS CHECK.
607 002134 016767 176116 176404 LET CMDADR := CBUPEA SHIF -4 ;SHIF EXTENDED ADR TO BITS 0+1,
608 002142 006267 176374 MOV CBUPEA,CMDADR
609 002142 006267 176374 ASR CMDADR
610 002142 006267 176374 ASR CMDADR
611 002142 006267 176374 ASR CMDADR
612 002142 006267 176374 ASR CMDADR
613 002142 006267 176374 LET CMDADR := CMDADR + CBUPPA ;ADD PHYSICAL AND EXTENDED ADDRESSES
614 002142 006267 176374 ADD CBUPPA,CMDADR
615 002152 006267 176374 .LIST MC
616 002152 006267 176374 ENDP ;AND STORE AS CMD PACKET ADDRESS.
617 002170 016767 176056 176352 LET CMDPK1 := CBUFVA ;SAVE ADDRESS OF COMMAND PACKET
618 002170 016767 176056 176352 LET CMDPK2 := CBUFVA + #2 ;SAVE ADDRESS OF COMMAND PACKET
619 002170 016767 176056 176352 LET CMDPK3 := CBUFVA + #4 ;SAVE ADDRESS OF COMMAND PACKET
620 002170 016767 176056 176352 LET CMDPK4 := CBUFVA + #6 ;SAVE ADDRESS OF COMMAND PACKET
621 002204 062767 000002 176340 MOV #4,CMDPK3
622 002204 062767 000002 176340 MOV #2,CMDPK2
623 002204 062767 000002 176340 MOV #2,CMDPK2
624 002204 062767 000002 176340 MOV #2,CMDPK2
625 002204 062767 000002 176340 MOV #2,CMDPK2
626 002204 062767 000002 176340 MOV #2,CMDPK2
627 002204 062767 000002 176340 MOV #2,CMDPK2
628 002204 062767 000002 176340 MOV #2,CMDPK2
629 002204 062767 000002 176340 MOV #2,CMDPK2
630 002204 062767 000002 176340 MOV #2,CMDPK2
631 002204 062767 000002 176340 MOV #2,CMDPK2

```

```

632 002242 104415 000000 000260 .LIST MC
633 002242 104415 000000 000260 GETPAS,BEGIN, MBUFVA ;GET PHYSICAL ADDRESS FROM 16-BIT MBUFVA
634 002250 104415 000000 000266 GETPAS,BEGIN, SBUFVA ;GET PHYSICAL ADDRESS FROM 16-BIT SBUFVA
635 002256 016767 176000 176350 .LIST MC
636 002256 016767 176000 176350 ENDP ;PHYSICAL ADDRESS FROM MONITOR.
637 002256 016767 176000 176350 LET MSGBLK := MBUFVA ;MOVE MESSAGE PACKET ADDRESS TO
638 002256 016767 176000 176350 MOV MBUFVA,MSGBLK
639 002256 016767 176000 176350 LET MSGBLK+2 := MBUFEA SHIF -4 ;CHARACTERISTIC BLOCK 1ST WORD.
640 002256 016767 176000 176350 SHIF EXTENDED ADDRESS TO BITS 0+1,
641 002264 016767 175774 176344 MOV MBUFEA,MSGBLK+2
642 002264 016767 175774 176344 ASR MSGBLK+2
643 002264 016767 175774 176344 ASR MSGBLK+2
644 002264 016767 175774 176344 ASR MSGBLK+2
645 002264 016767 175774 176344 ASR MSGBLK+2
646 002264 016767 175774 176344 ASR MSGBLK+2
647 002312 004767 000456 CALL IDP ;AND STORE IN CHARACTERISTIC BLOCK 2ND WD.
648 002312 004767 000456 WHILEB EOD EQ #0 DD ;CALL IDP-INITIALIZE DEVICE POINTERS.
649 002316 004767 000456 ;WHILE THERE ARE MORE DEVICES:
650 002316 004767 000456 TSTB EOD
651 002316 004767 000456 BNE 50007S
652 002316 004767 000456 CALL DVSET ;CALL DVSET-SET UP DEVICE
653 002316 004767 000456 BNE 50007S
654 002316 004767 000456 CALL CVSET ;CALL CVSET-SET UP COMMAND VARIABLES.
655 002316 004767 000456 BNE 50007S
656 002334 004567 000272 ;ADR OF SET CHAR CMD VARIABLE TABLE.
657 002334 004567 000272 CALL ICCS ;CALL ICCS-ISSUE SET CHARACTERISTICS.
658 002336 004767 000742 ;COMMAND AND CHECK STATUS.
659 002336 004767 000742 IFB DROP EQ #0 THEN ;IF CURRENT DEVICE NOT DROPPED THEN:
660 002342 004767 000742 TSTB DROP
661 002342 004767 000742 BNE 50010S
662 002342 004767 000742 CALL CVSET ;CALL CVSET-SET UP CMD VARIABLES.
663 002342 004767 000742 BNE 50010S
664 002350 004567 000252 ;ADR OF ERASE CMD VARIABLE TABLE.
665 002350 004567 000252 CALL ICCS ;CALL ICCS-ISSUE ERASE COMMAND
666 002356 004767 000722 ;AND CHECK STATUS.
667 002356 004767 000722 ENDP ;END OF DEVICE DROP CHECK.
668 002362 004767 000436 CALL UPDP ;CALL UPDP-UPDATE DEVICE POINTERS.
669 002362 004767 000436 ENDDO ;END OF SET CHARACTERISTIC LOOP.
670 002366 000753 BR 50006S
671 002366 000753 BR 50006S
672 002366 000753 BR 50006S
673 002366 000753 BR 50006S
674 002366 000753 BR 50006S
675 002370 000753 BR 50006S
676 002370 000753 BR 50006S

```

```

677 002370- BEGIN MAIN ;BEGINNING OF MAIN MODULE.
678 002370- ;SMAIN:
679 002370- WHILE ICOUNT LT ICOUNT DO ;WHILE CYCLE COUNT IS LESS THEN THE
680 002370- ; 50001$:
681 002370- 026767 175444 175440 ;CMP ICOUNT,ICOUNT
682 002376- 002105 ;BGE 50002$:
683 ;
684 002400- ;NUMBER OF CYCLES PER PASS:
685 002400- 105767 176104 ;IF DROP MODULE FLAG IS SET THEN:
686 002404- 001402 ;TSTB DMOD
687 ; ;BEQ 50003$:
688 002406- ; ;JMP MAIN FLOW-DROP MODULE.
689 002413- 000167 000204 ;LEAVE MODULE
690 002412- ;END MODULE DROP CHECK.
691 ; ;50003$:
692 ;
693 002412- 104414 000000- .NLIST MC
694 ;LIST ME ;GET WRITE BUFFER INFORMATION
695 ;LIST MC
696 ;LIST ME
697 LET R2 := DINK ;SAVE DEVICE INDEX IN REGISTER
698 002416- 016702 175654 ;MOV DINK,R2
699 002423- 005262 000352- LET TREC(R2) := TREC(R2) + #1 ;INCREMENT DEVICE RECORD COUNT
700 ;INC TREC(R2)
701 002426- 004767 000274 ;CALL DVSET-SET UP DEVICE VARIABLES
702 ;JSR PC,DVSET
703 002432- 004567 000170 ;CALL CVSET-SET UP COMMAND VARIABLES
704 ;WORD WRITE ;ADDRESS OF WRITE CMD VARIABLE TABLE
705 002440- 004767 000640 ;CALL ICCS-ISSUE WRITE CMD + CHECK STATUS
706 ;JSR PC,ICCS
707 002444- 105767 176037 ;IF CURRENT DEVICE HAS NOT BEEN DROPPED THEN:
708 ;TSTB DROP
709 002450- 001053 ;BNE 50004$:
710 002456- 004367 000150 ;CALL CVSET-SET UP COMMAND VARIABLES
711 ;WORD REV ;ADDRESS OF READ REV CMD VARIABLE TABLE
712 002460- 004767 000620 ;CALL ICCS-ISSUE READ REV + CHECK STATUS
713 ;JSR PC,ICCS
714 002464- 105767 176017 ;IF THIS DEVICE HAS NOT BEEN DROPPED THEN:
715 ;TSTB DROP
716 002472- 001043 ;BNE 50005$:
717 002472- 012767 000001 175406 LET ERRTP := #1 ;LET ERROR TYPE EQUAL DATA COMPARE
718 ;MOV #1,ERRTP
719 ;
720 002500- 104412 000000- 000126- .NLIST MC
721 ;LIST ME ;REQUEST FOR MONITOR TO CHECK DATA
722 ;LIST ME ;IF ERROR, CONTINUE
723 ;*2
724 002510- 004567- 000112 .NLIST MC
725 ;LIST ME ;CALL DVSET-SET UP COMMAND VARIABLES
726 002514- 000452- ;JSR R5,CVSET ;ADDRESS OF READ REV CMD VARIABLE TABLE
727 ;WORD R5WD ;CALL ICCS-ISSUE READ REV + STATUS CHECK
728 002522- 004767 000562 ;CALL ICCS ;JSR PC,ICCS
729 ;IF DEVICE HAS NOT BEEN DROPPED THEN:
730 002522- 105767 175761 ;TSTB DROP
731 002526- 001024 ;BNE 50006$:
732 002530- 012767 000001 175350 LET ERRTP := #1 ;LET ERROR TYPE EQUAL DATA COMPARE
733 ;MOV #1,ERRTP

```

```

733 ;
734 ;
735 002536- 104412 000000- 000126- .NLIST MC
736 002544- 002546- ;LIST ME ;REQUEST FOR MONITOR TO CHECK DATA
737 ;LIST ME ;IF ERROR, CONTINUE
738 ;*2
739 ;
740 002546- 032767 000001 176076 .NLIST MC
741 ;LIST ME ;IF AT END OF TAPE THEN:
742 002549- 001411 ;BIT #X50.EOT,XSTATO
743 002552- 004567 000044 ;BEQ 50007$:
744 002562- 000470- ;CALL CVSET-SETUP CMD VARIABLES
745 ;JSR R5,CVSET ;ADDRESS OF REWIND CMD VARIABLE TABLE
746 ;CALL ICCS ;CALL ICCS-ISSUE REWIND CHECK STATUS
747 ;JSR PC,ICCS
748 002574- 004767 000514 ;SAVE DEVICE INDEX IN REGISTER
749 ;MOV DINK,R2
750 002574- 005062 000352- LET TREC(R2) := #0 ;CLEAR DEVICE RECORD COUNT
751 ;CLR TREC(R2)
752 ;ENDIF ;END OF TAPE CHECK
753 ;50007$:
754 ;ENDIF ;END DEVICE DROP CHECK
755 ;50008$:
756 ;ENDIF ;END DEVICE DROP CHECK
757 ;50009$:
758 ;ENDIF ;END DEVICE DROP CHECK
759 002600- 004767 000220 ;CALL UPDP-UPDATE DEVICE POINTERS
760 ;JSR PC,UPDP
761 ;
762 002604- 104413 000000- .NLIST MC
763 ;LIST ME ;SIGNAL END OF ITERATION.
764 ;LIST ME ;MONITOR SHALL TEST END OF PASS
765 ;LIST ME
766 002610- 000667 ;END MODULE CYCLE LOOP. BR 50001$
767 002610- ;
768 002612- ;
769 002612- ;
770 ;
771 ;
772 002616- BEGIN FINI ;BEGINNING OF FINI MODULE.
773 002616- ;
774 002616- ;
775 ;
776 ;
777 002616- 104410 000000- .NLIST MC
778 ;LIST ME ;
779 ;LIST ME ;
780 002622- ;END FINI ;END OF FINI MODULE.
781 ;
782 ;

```



```

849 *****
850 *
851 *SUBROUTINE NAME: DVSET
852 *
853 *FUNCTION: SETS UP ALL DEVICE VARIABLES.
854 *
855 *CALLING SEQUENCE: CALL DVSET.
856 *
857 *PARAMETERS PASSED: NONE
858 *
859 *REGISTERS USED: R2.
860 *
861 *SUBORDINATE ROUTINES: NONE
862 *
863 *****
864
865 002726 010246 DVSET: PUSH R2 ;SAVE TABLE INDEX REGISTER ON STACK.
866 002726 010246 LET R2 := DIX ;LET INDEX REGISTER EQUAL DEVICE INDEX.
867 002730 016702 175342 LET CSRA := TTSSR(R2) ;GET TSSR ADR FROM TSSR TABLE AND SAVE IT.
868 002734 016267 000322 175136 LET TSSR := TTSSR(R2) ;GET TSSR ADR FROM TSSR TABLE AND SAVE IT.
869 002734 016267 000332 175136 LET TSSR := TTSSR(R2) ;GET TSSR ADR FROM TSSR TABLE AND SAVE IT.
870 002734 016267 000322 175136 LET TSSR := TTSSR(R2) ;GET TSSR ADR FROM TSSR TABLE AND SAVE IT.
871 002734 016267 000332 175136 LET TSSR := TTSSR(R2) ;GET TSSR ADR FROM TSSR TABLE AND SAVE IT.
872 002734 016267 000332 175136 LET TSSR := TTSSR(R2) ;GET TSSR ADR FROM TSSR TABLE AND SAVE IT.
873 002734 016267 000332 175136 LET TSSR := TTSSR(R2) ;GET TSSR ADR FROM TSSR TABLE AND SAVE IT.
874 002734 016267 000342 175330 LET TSSR := TTSSR(R2) ;GET TSSR ADR FROM TSSR TABLE AND SAVE IT.
875 002734 016267 000352 175324 LET TSSR := TTSSR(R2) ;GET TSSR ADR FROM TSSR TABLE AND SAVE IT.
876 002734 016267 000352 175324 LET TSSR := TTSSR(R2) ;GET TSSR ADR FROM TSSR TABLE AND SAVE IT.
877 002764 105067 175516 LET EOD := #0 ;CLEAR END OF DEVICE FLAG.
878 002764 105067 175516 LET EOD := #0 ;CLEAR END OF DEVICE FLAG.
879 002770 012602 POP R2 ;RESTORE THE TABLE INDEX REGISTER.
880 002770 012602 POP R2 ;RESTORE THE TABLE INDEX REGISTER.
881 002772 000207 RTS PC ;RETURN.
882
883

```

```

884 *****
885 *
886 *SUBROUTINE NAME: IDP
887 *
888 *FUNCTION: INITIALIZES DEVICE POINTERS.
889 *
890 *DEFINITION OF DEVICE POINTERS:
891 * 1. DEVICE COUNTER-COUNTS 0-3.
892 * 2. DEVICE INDEX-COUNTS 0-6 BY 2'S
893 * 3. VARIABLE DEVICE INDICATOR-CONTAINS
894 * ONLY THE BIT OF THE CURRENT DEVICE
895 * FROM THE DEVICE INDICATOR IN THE HEADER.
896 *
897 *
898 *
899 *
900 *
901 *
902 *
903 *
904 *
905 *
906 *
907 *
908 *
909 *
910 *
911 *
912 *
913 *
914 *
915 *
916 *****
917
918 002774 005067 175274 IDP: LET DCNT := #0 ;CLEAR DEVICE COUNTER. CLR DCNT
919 003000 005067 175272 LET DIX := #0 ;CLEAR DEVICE INDEX. CLR DIX
920 003000 005067 175272 LET VDIND := #1 ;LET VARIABLE DEVICE INDICATOR EQUAL 1. MOV #1,VDIND
921 003004 012767 000001 175270 LET EOD := #0 ;CLEAR END OF DEVICES FLAG. CLR EOD
922 003012 105067 175470 LET DROP := #0 ;CLEAR DEVICE DROPPED FLAG. CLR DROP
923 003016 105067 175465 LET DROP := #0 ;CLEAR DEVICE DROPPED FLAG. CLR DROP
924 003016 105067 175465 LET DROP := #0 ;CLEAR DEVICE DROPPED FLAG. CLR DROP
925 003022 000207 RTS PC ;RETURN.
926
927
928
929

```

DEVICE	1	0	1	1	2	1	3
COUNTER	1	0	1	1	2	1	3
INDEX	1	0	2	1	4	1	6
VARIABLE IND.	1	1	2	1	4	1	8

```

930
931
932
933
934
935
936
937
938
939
940
941
942
943
944
945
946 003024 010246
947 003024 010246
948 003025 016702 175242
949 003025 016702 175242
950 003032 105762 000512
951 003032 105762 000512
952 003036 001424
953 003040 012767 000014 175040
954 003040 012767 000014 175040
955 003046 017767 175232 175030
956 003046 017767 175232 175030
957 003054 017767 175020 175020
958 003054 017767 175020 175020
959
960
961 003062 104403 000000 005142
962 003070 104403 000000 005206
963
964 003076 104405 000000 000570
965
966
967
968 003104 004767 000126
969 003104 004767 000126
970 003110 105067 175373
971 003110 105067 175373
972 003110 105067 175373
973 003110 105067 175373
974 003114 005267 175154
975 003114 005267 175154
976 003120 026727 175150 000003
977 003120 026727 175150 000003
978 003126 003423
979 003130 105767 175352
980 003130 105767 175352
981 003134 001405
982 003134 001405
983 003136 112767 000001 175344
984 003136 112767 000001 175344
985 003136 112767 000001 175344

```

```

*****
*SUBROUTINE NAME: UPDP
*FUNCTION: UPDATE DEVICE POINTERS TO NEXT DEVICE.
*CALLING SEQUENCE: CALL UPDP
*PARAMETERS PASSED: NONE
*REGISTERS USED: R2
*SUBORDINATE ROUTINES: DROPD
*****
UPDP: PUSH R2 ;SAVE TABLE INDEX REGISTER ON STACK.
      LET R2 := DCNT ;LET IDNEX REGISTER EQUAL DEVICE COUNTER
      IFB UIPLO(R2) NE #0 THEN ;IF AN UNEXPECTED INTERRUPT HAS OCCURRED THEN:
          LET ERRRTYP := #14 ;LET ERROR TYPE EQUAL #14
          LET ASTAT := @TSSR ;SAVE CONTENTS OF TSSR FOR PRINTOUT.
          LET ACSR := @CSRA ;SAVE CONTENTS OF TSDB(CSR) FOR PRINTOUT.
          .LIST MC
          .LIST MR
          MSCNS,BEGIN,UNEX ;ASCII MESSAGE CALL WITH COMMON HEADER
          MSCNS,BEGIN,CMDA ;ASCII MESSAGE CALL WITH COMMON HEADER
          *****
          BRDRC,BEGIN,TABLE ;UNEXPECTED INTERRUPT
          *****
          .LIST MC
          .LIST MR
          CALL DROPD ;CALL DROPD-DROP THE CURRENT DEVICE.
          ENDIF ;END OF UNEXPECTED INTERRUPT CHECK.
      REPEAT ;CLEAR DEVICE DROPPED FLAG.
          LET DCNT := DCNT + #1 ;INCREMENT DEVICE COUNTER,
          IF DCNT GT #3 THEN ;IF DEVICE COUNT GREATER THAN 3 THEN:
              IFB EOD NE #0 THEN ;IF END OF DEVICES FLAG IS SET THEN:
                  LET DMOD := #1 ;SET DROP MODULE FLAG
      UNTIL DROPPED FLAG
      RTS PC ;RETURN.

```

```

986 003144 000432
987 003146 000412
988 003146 000412
989 003150 112767 000001 175330
990 003150 112767 000001 175330
991 003156 005067 175112
992 003156 005067 175112
993 003162 005067 175110
994 003162 005067 175110
995 003166 012767 000001 175106
996 003166 012767 000001 175106
997 003174 000412
998 003174 000412
999 003176 016767 175072 175072
1000 003176 016767 175072 175072
1001 003204 006367 175062
1002 003204 006367 175062
1003 003210 016702 175062
1004 003214 016267 000560 175060
1005 003214 016267 000560 175060
1006 003222 036767 175054 175050
1007 003222 036767 175054 175050
1008 003230 001731
1009 003232 012602
1010 003232 012602
1011 003234 000207
1012 003234 000207
1013
1014
1015
1016
1017
1018
1019

```

```

      BR UPDRTH ;BRANCH TO RETURN-ALL DEVICES DROPPED.
      ELSE ;ELSE-IF END OF DEVICES NOT SET:
          LET EOD := #1 ;SET END OF DEVICES FLAG,
          LET DCNT := #0 ;CLEAR DEVICE COUNTER,
          LET DINX := #0 ;CLEAR DEVICE INDEX,
          LET VDIND := #1 ;SET VARIABLE DEV INDICATOR TO 1,
          ENDIF ;END OF DEVICE COUNTER WRAP AROUND CHECK.
      ELSE ;ELSE-IF DEVICE COUNT IS 3 OR LESS:
          LET DINX := DCNT SHIFT 1 ;LET DEV INDEX EQUAL DEV COUNT X 2,
          LET R2 := DINX ;LET INDEX REGISTER EQUAL DEVICE INDEX,
          LET VDIND := BCON(R2) ;LET THE VARIABLE DEVICE INDICATOR EQUAL BCON(R2),VDIND
          .THE APPROPRIATE BIT-
          ENDIF ;END OF DEVICE POINTER SET UP.
      UNTIL VDIND SET IN DIND ;END OF DEVICE SEARCH REPEAT LOOP.
UPDRTH: POP R2 ;RESTORE TABLE INDEX REGISTER.
      RTS PC ;RETURN.

```



```

1114 003402 004767 177630 JSR PC,DROPD
1115 003406 000476 BR ICCRTN ;BRANCH TO ICCRTN-RETURN
1116 003410 000476 ENDIF ;END OF READY TIMEOUT PROCESSING,
1117 003410 000476 500205
1118 003410 000476 LET TIME := TIME - #1 ;UPDATE THE TIMEOUT COUNTER,
1119 003410 005367 175204 UNTIL #TS.SSR SETIN @TSSR ;END OF READY WAIT/REPEAT LOOP.
1120 003414 005367 175204 DEC TIME
1121 003414 032777 000200 174662 BIT #TS.SSR,@TSSR
1122 003414 001736 001736 BEQ 500175
1123 003422 001736 LET @VECT := #ICCS1 ;POINT VECTOR TO PIRQ CALL.
1124 003424 012777 003530 174654 LET @CSRA := CMDADR ;ISSUE THE CMD PACKET TO THE TS04.
1125 003432 016777 175110 174440 MOV #ICCS1,@VECT
1126 003432 016777 175110 174440 MOV CMDADR,@CSRA
1127 003440 000240 WOP ;GIVE TS04 ONE INSTUCTION TIME TO RESPOND.
1128 003440 000240 IF #TS.SSR SETIN @TSSR THEN ;IF READY DID NOT DROP THEN:
1129 003445 000200 174634 BIT #TS.SSR,@TSSR
1130 003450 001425 BEQ 500215
1131 003452 000003 LET ERRRTYP := #3 ;LET ERROR TYPE EQUAL 3
1132 003452 012767 000003 174426 LET ASTAT := @TSSR ;SAVE CONTENTS OF TSSR FOR PRINTOUT.
1133 003460 017767 174620 174416 LET ACSR := @CSRA ;SAVE CONTENTS OF TSDR(CSR) FOR PRINTOUT.
1134 003466 017767 174406 MOV @CSRA,ACSR
1135 003466 017767 174406
1136 003466 017767 174406
1137 003466 017767 174406
1138 003466 017767 174406
1139 003466 017767 174406
1140 003502 104403 000000 005135 MSGN,BEGIN,READ ;ASCII MESSAGE CALL WITH COMMON HEADER
1141 003502 104403 000000 005206 MSGN,BEGIN,CMDA ;ASCII MESSAGE CALL WITH COMMON HEADER
1142 003510 104405 000000 000570 HRDRS,BEGIN,TABLE ;READY DID NOT DROP
1143 003510 104405 000000 000570 *****
1144 003510 104405 000000 000570 *****
1145 003510 104405 000000 000570 *****
1146 003516 004767 177514 CALL DROPD ;CALL DROPD-DROP CURRENT DEVICE
1147 003516 004767 177514 JSR PC,DROPD
1148 003522 000430 BR ICCRTN ;BRANCH TO ICCRTN-RETURN
1149 003524 000430 ENDIF ;END OF READY DROP PROCESSING,
1150 003524 000430 500215:
1151 003524 000430
1152 003524 000430
1153 003524 104400 000000 ICCS1: ;EXIT TO MONITOR. MODULE WAIT FOR INTERRUPT.
1154 003530 104400 000000 EXITS,BEGIN
1155 003530 104400 000000
1156 003530 000004 000000 003536 PIRQS,BEGIN,ICCS2 ;QUEUE UP TO CONTINUE AT ICCS2 AND RTI
1157 003530 000004 000000 003536 *****
1158 003530 000004 000000 003536 *****
1159 003536 000004 000000 003536 *****
1160 003536 000004 000000 003536 *****
1161 003536 016702 174534 ICCS2: LET R2 := DINX ;LET INDEX REGISTER EQUAL DEVICE INDEX.
1162 003542 016277 000536 174536 MOV DINX,R2
1163 003542 016277 000536 174536 LET @VECT := UIADR(R2) ;POINT VECTOR TO UNEXPECTED INTERRUPT ROUTINE.
1164 003550 032777 100000 174526 MOV UIADR(R2),@VECT
1165 003550 032777 100000 174526 IF #TS.SC SETIN @TSSR THEN ;IF SPECIAL CONDITION IS SET IN TSSR THEN:
1166 003556 001406 BIT #TS.SC,@TSSR
1167 003556 001406 BEQ 500225
1168 003560 017702 174520 LET R2 := @TSSR CLR.BY #177761 ;MASK TERMINATION CODE OUT OF TSSR.
1169 003564 042702 177761 MOV @TSSR,R2
1170 003564 042702 177761 BIC #177761,R2

```

```

1170 003570 004772 000516 JSR PC,@TCCRA(R2) ;GO TO APPROPRIATE TCC HANDLING ROUTINE.
1171 003574 000516 ENDIF ;END OF SPECIAL CONDITION STATUS CHECK.
1172 003574 000516 500225:
1173 003574 105767 174711 IFB EREC NE #0 THEN ;IF ERROR RECOVERY REQUIRED FLAG IS SET THEN:
1174 003574 105767 174711 TSTB EREC
1175 003600 001401 000641 BEQ 500235
1176 003602 000641 BR ICCSR ;GO DO ERROR RECOVERY
1177 003604 000641 ENDIF ;END OF ERROR RECOVERY REQUIREMENT CKECK.
1178 003604 000641 500235:
1179 003604 000641 ICCRTN: POP R2 ;RESTORE TABLE INDEX REGISTER.
1180 003604 012602 RTS PC ;RETURN.
1181 003606 000207 MOV (SP)+,R2
1182 003606 000207
1183 003606 000207

```

```

1184
1185
1186
1187
1188
1189
1190
1191
1192
1193
1194
1195
1196
1197
1198
1199
1200
1201
1202
1203
1204 003610*
1205 003610* 005067 174272
1206 003614*
1207 003614* 017767 174464 174262
1208 003622*
1209 003622* 017767 174252 174252
1210
1211
1212
1213 003630* 104403 000000* 005145*
1214 003636* 104403 000000* 005208*
1215
1216 003644* 104406 000000* 000570*
1217
1218
1219
1220 003652*
1221 003652* 004767 177360
1222 003656* 000207

```

```

*****
*SUBROUTINE NAME: TCC0
*FUNCTION: PROCESSES TERMINATION CLASS CODE 0
(UNDEFINED SPECIAL CONDITION STATUS).
*CALLING SEQUENCE: CALL TCC0
*PARAMETERS PASSES: NONE
*REGISTERS USED: NONE
*SUBORDINATE ROUTINES: DROPD
*ENTRY PREREQUISITES: - COMMAND HAS BEEN ISSUED TO TS04.
- INTERRUPT HAS BEEN RECEIVED.
*****
TCC0: LET ERRTP := #0 ;LET ERROR TYPE EQUAL 0,
;LET ERROR TYPE EQUAL 0, CLR ERRTP
LET ASTAT := @TSSR ;SAVE CONTENTS OF TSSR FOR PRINTOUT
MOV @TSSR,ASTAT
LET ACSR := @CSRA ;SAVE CONTENTS OF TSDB(CSR) FOR PRINTOUT
MOV @CSRA,ACSR
-NLIST MC
-NLIST MC
MSGN,BEGIN,SPEC ;ASCII MESSAGE CALL WITH COMMON HEADER
MSGN,BEGIN,CMDA ;ASCII MESSAGE CALL WITH COMMON HEADER
*****
SOFER,BEGIN,TABLE ;SPECIAL CONDITION STATUS
*****
-NLIST MC
-NLIST MC
CALL DROPD ;CALL DROPD-DROP THE DEVICE.
JSR PC,DROPD
RTS PC ;RETURN.
-----

```

```

1223
1224
1225
1226
1227
1228
1229
1230
1231
1232
1233
1234
1235
1236
1237
1238
1239
1240
1241
1242 003660*
1243 003660* 012767 000006 174220
1244 003666*
1245 003666* 017767 174412 174210
1246 003674*
1247 003674* 017767 174200 174200
1248
1249
1250 003702* 104403 000000* 005152*
1251 003710* 104403 000000* 005208*
1252
1253 003716* 104405 000000* 000570*
1254
1255
1256
1257 003724*
1258 003724* 004767 177360
1259 003730* 000207
1260
1261

```

```

*****
*SUBROUTINE NAME: TCC1
*FUNCTION: PROCESSES TCC1 (ATTENTION CONDITION).
*CALLING SEQUENCE: CALL TCC1
*PARAMETERS PASSES: NONE
*REGISTERS USED: NONE
*SUBORDINATE ROUTINES: DROPD
*ENTRY PREREQUISITES: - COMMAND HAS BEEN ISSUED TO TS04.
- INTERRUPT HAS BEEN RECEIVED.
*****
TCC1: LET ERRTP := #6 ;SET ERROR TYPE EQUAL 6,
;SET ERROR TYPE EQUAL 6, MOV #6,ERRTP
LET ASTAT := @TSSR ;SAVE CONTENTS OF TSSR FOR PRINTOUT
MOV @TSSR,ASTAT
LET ACSR := @CSRA ;SAVE CONTENTS OF TSDB(CSR) FOR PRINTOUT
MOV @CSRA,ACSR
-NLIST MC
-NLIST MC
MSGN,BEGIN,DEVI ;ASCII MESSAGE CALL WITH COMMON HEADER
MSGN,BEGIN,CMDA ;ASCII MESSAGE CALL WITH COMMON HEADER
*****
HRDRS,BEGIN,TABLE ;DEVICE OFF LINE
*****
-NLIST MC
-NLIST MC
CALL DROPD ;CALL DROPD-DROP THE DEVICE.
JSR PC,DROPD
RTS PC ;RETURN.
-----

```



```

1465 *****
1466 *SUBROUTINE NAME:      TCC7
1467 *FUNCTION:             PROCESSES TCC7 (FATAL SUBSYSTEM ERROR).
1468 *CALLING SEQUENCE:    CALL TCC7
1469 *PARAMETERS PASSED:   NONE
1470 *REGISTERS USED:      NONE
1471 *SUBORDINATE ROUTINES: DROPD
1472 *ENTRY PREREQUISITES: - COMMAND HAS BEEN ISSUED TO TS04.
1473                      - INTERRUPT HAS BEEN RECEIVED.
1474 *****
1475 TCC7:  LET ERRTP := #55                ;LET ERROR TYPE EQUAL 55.
1476                      MOV #55,ERRTP
1477                      LET ASTAT := @TSSR          ;SAVE CONTENTS OF TSSR FOR PRINTOUT.
1478                      MOV @TSSR,ASTAT
1479                      LET ACSR := @CSRA          ;SAVE CONTENTS OF TSDR(CSR) FOR PRINTOUT.
1480                      MOV @CSRA,ACSR
1481                      .LIST MC
1482                      .LIST ME
1483                      MSCR, BEGIN, PATA          ;ASCII MESSAGE CALL WITH COMMON HEADER
1484                      MSCR, BEGIN, CMDA          ;ASCII MESSAGE CALL WITH COMMON HEADER
1485                      *****
1486                      SOFERS, BEGIN, TABLE     ;FATAL SUBSYSTEM ERROR
1487                      ;*****
1488                      .LIST MC
1489                      .LIST ME
1490                      CALL DROPD                ;CALL DROPD-DROP THE DEVICE.
1491                      JSR PC, DROPD
1492                      RTS PC                    ;RETURN
1493                      -----
1494
1484 004234* 012767 000055 173644
1485 004234* 012767 000055 173644
1486 004242* 017767 174036 173634
1487 004242* 017767 174036 173634
1488 004250* 017767 173624 173624
1489 004250* 017767 173624 173624
1490
1491 004256* 104403 000000 005166*
1492 004264* 104403 000000 005208*
1493
1494 004272* 104405 000000 000570*
1495
1496
1497
1498
1499 004300*
1500 004300* 004767 176732
1501 004304* 000207
1502
1503

```

```

1504 *****
1505 *SUBROUTINE NAME:      RECR
1506 *FUNCTION:             PRINT RECOVERABLE ERROR MESSAGE.
1507 *CALLING SEQUENCE:    CALL RECR
1508 *PARAMETERS PASSED:   NONE
1509 *REGISTERS USED:      NONE
1510 *SUBORDINATE ROUTINES: NONE
1511 *****
1512 RECR:  IF #BIT1 NOTSET IN SR1 THEN          ;IF BIT 1 NOT SET IN SR1 THEN:
1513                      BIT #BIT1, SR1
1514                      BNE 50034$
1515                      LET ERRTP := #53          ;LET ERROR TYPE EQUAL 53.
1516                      MOV #53, ERRTP
1517                      LET ASTAT := @TSSR          ;SAVE CONTENTS OF TSSR FOR PRINTOUT.
1518                      MOV @TSSR, ASTAT
1519                      LET ACSR := @CSRA          ;SAVE CONTENTS OF TSDR(CSR) FOR PRINTOUT.
1520                      MOV @CSRA, ACSR
1521                      .LIST MC
1522                      .LIST ME
1523                      MSCR, BEGIN, RECD          ;ASCII MESSAGE CALL WITH COMMON HEADER
1524                      MSCR, BEGIN, CMDA          ;ASCII MESSAGE CALL WITH COMMON HEADER
1525                      *****
1526                      SOFERS, BEGIN, TABLE     ;RECOVERABLE ERROR
1527                      ;*****
1528                      .LIST MC
1529                      .LIST ME
1530                      ELSE
1531                      ;ELSE-IF BIT 1 SET IN SR1:
1532                      BR 50035$
1533                      LET SOFCNT := SOFCNT + #1          ;UPDATE SOFT ERROR COUNT.
1534                      INC SOFCNT
1535                      ENDIF
1536                      ;END SWITCH REGISTER CHECK.
1537                      RTS PC                    ;RETURN
1538                      -----
1539
1540 004306* 032767 000002 173502
1541 004314* 001023
1542 004316* 012767 000053 173562
1543 004316* 012767 000053 173562
1544 004324* 017767 173754 173552
1545 004324* 017767 173754 173552
1546 004332* 017767 173542 173542
1547
1548 004340* 104403 000000 005166*
1549 004346* 104403 000000 005208*
1550
1551 004354* 104406 000000 000570*
1552
1553
1554
1555
1556 004362* 000402
1557 004362* 000402
1558 004364*
1559 004364*
1560 004371* 005267 173452
1561 004370*
1562 004370*
1563 004370* 000207
1564

```

```

1548 ;*****
1549 ;*
1550 ;* SUBROUTINE NAME: UNRER
1551 ;*
1552 ;* FUNCTIONS: - PRINT RECOVERABLE ERROR MESSAGE.
1553 ;* - DROP DEVICE IF BIT0 SET IN SRI.
1554 ;*
1555 ;* CALLING SEQUENCE: CALL UNRER
1556 ;*
1557 ;* PARAMETERS PASSED: NONE
1558 ;*
1559 ;* REGISTERS USED: NONE
1560 ;*
1561 ;* SUBORDINATE ROUTINES: DROPD
1562 ;*
1563 ;*****
1564 UNRER: LET ERRTP := #54 ;LET ERROR TYPE EQUAL 54.
1565 ;LIST MC
1566 ;LIST ME
1567 ;MOV #54,ERRTP
1568 ;SAVE CONTENTS OF TSSR FOR PRINTOUT.
1569 ;MOV @TSSR,ASTAT
1570 ;SAVE CONTENTS OF TSDB(CSR) FOR PRINTOUT.
1571 ;MOV @CSRA,ACSR
1572 ;LIST MC
1573 ;LIST ME
1574 ;MSGMS,BEGIN,UNRE ;ASCII MESSAGE CALL WITH COMMON HEADER
1575 ;MSGMS,BEGIN,CMDA ;ASCII MESSAGE CALL WITH COMMON HEADER
1576 ;*****
1577 ;ORDER:BEGIN,TABLE ;UNRECOVERABLE ERROR
1578 ;*****
1579 ;LIST MC
1580 ;LIST ME
1581 ;IF #BIT0 SETIN SRI THEN ;IF BIT0 SET IN SRI THEN:
1582 ;BIT #BIT0,SRI
1583 ;BEQ 50036$
1584 ;CALL DROPD ;CALL DROPD-DROP THE DEVICE.
1585 ;JSR PC,DROPD
1586 ;ENDIF ;END SWITCH REGISTER CHECK.
1587 ;RTS PC ;RETURN 50036$:
1588 ;
1589 ;
  
```

```

1590 ;*****
1591 ;*
1592 ;* ROUTINES TO SERVICE UNEXPECTED INTERRUPTS
1593 ;*
1594 ;*
1595 ;*****
1596 ;LIST MC
1597 ;LIST ME
1598 ;SET DEVICE 0 UNEXPECTED INTERRUPT FLAG.
1599 ;MOV #1,UIFL0
1600 ;RTI ;RETURN FROM INTERRUPT.
1601 ;
1602 ;SET DEVICE 1 UNEXPECTED INTERRUPT FLAG.
1603 ;MOV #1,UIFL1
1604 ;RTI ;RETURN FROM INTERRUPT.
1605 ;
1606 ;SET DEVICE 2 UNEXPECTED INTERRUPT FLAG.
1607 ;MOV #1,UIFL2
1608 ;RTI ;RETURN FROM INTERRUPT.
1609 ;
1610 ;SET DEVICE 3 UNEXPECTED INTERRUPT FLAG.
1611 ;MOV #1,UIFL3
1612 ;RTI ;RETURN FROM INTERRUPT.
1613 ;
1614 ;
1615 ;
  
```


1136#	1137#	1143#	1161#	1162#	1163#	1164#	1168#	1169#	1170#	1205#	1206#	1207#
1208#	1209#	1210#	1220#	1243#	1244#	1245#	1246#	1247#	1248#	1258#	1285#	1286#
1287#	1288#	1289#	1290#	1323#	1324#	1325#	1326#	1327#	1328#	1339#	1366#	1368#
1369#	1370#	1371#	1378#	1379#	1380#	1381#	1386#	1387#	1388#	1397#	1406#	1424#
1425#	1426#	1427#	1433#	1434#	1435#	1436#	1437#	1438#	1439#	1440#	1500#	1521#
1522#	1523#	1524#	1563#	1564#	1565#	1566#	1567#	1568#	1569#	1570#	1571#	1572#
1573#	1574#	1575#	1581#	1582#	1583#	1584#	1585#	1586#	1587#	1588#	1589#	1590#
1591#	1592#	1593#	1594#	1595#	1596#	1597#	1598#	1599#	1600#	1601#	1602#	1603#
1604#	1605#	1606#	1607#	1608#	1609#	1610#	1611#	1612#	1613#	1614#	1615#	1616#
1617#	1618#	1619#	1620#	1621#	1622#	1623#	1624#	1625#	1626#	1627#	1628#	1629#
1630#	1631#	1632#	1633#	1634#	1635#	1636#	1637#	1638#	1639#	1640#	1641#	1642#
1643#	1644#	1645#	1646#	1647#	1648#	1649#	1650#	1651#	1652#	1653#	1654#	1655#
1656#	1657#	1658#	1659#	1660#	1661#	1662#	1663#	1664#	1665#	1666#	1667#	1668#
1669#	1670#	1671#	1672#	1673#	1674#	1675#	1676#	1677#	1678#	1679#	1680#	1681#
1682#	1683#	1684#	1685#	1686#	1687#	1688#	1689#	1690#	1691#	1692#	1693#	1694#
1695#	1696#	1697#	1698#	1699#	1700#	1701#	1702#	1703#	1704#	1705#	1706#	1707#
1708#	1709#	1710#	1711#	1712#	1713#	1714#	1715#	1716#	1717#	1718#	1719#	1720#
1721#	1722#	1723#	1724#	1725#	1726#	1727#	1728#	1729#	1730#	1731#	1732#	1733#
1734#	1735#	1736#	1737#	1738#	1739#	1740#	1741#	1742#	1743#	1744#	1745#	1746#
1747#	1748#	1749#	1750#	1751#	1752#	1753#	1754#	1755#	1756#	1757#	1758#	1759#
1760#	1761#	1762#	1763#	1764#	1765#	1766#	1767#	1768#	1769#	1770#	1771#	1772#
1773#	1774#	1775#	1776#	1777#	1778#	1779#	1780#	1781#	1782#	1783#	1784#	1785#
1786#	1787#	1788#	1789#	1790#	1791#	1792#	1793#	1794#	1795#	1796#	1797#	1798#
1799#	1800#	1801#	1802#	1803#	1804#	1805#	1806#	1807#	1808#	1809#	1810#	1811#
1812#	1813#	1814#	1815#	1816#	1817#	1818#	1819#	1820#	1821#	1822#	1823#	1824#
1825#	1826#	1827#	1828#	1829#	1830#	1831#	1832#	1833#	1834#	1835#	1836#	1837#
1838#	1839#	1840#	1841#	1842#	1843#	1844#	1845#	1846#	1847#	1848#	1849#	1850#
1851#	1852#	1853#	1854#	1855#	1856#	1857#	1858#	1859#	1860#	1861#	1862#	1863#
1864#	1865#	1866#	1867#	1868#	1869#	1870#	1871#	1872#	1873#	1874#	1875#	1876#
1877#	1878#	1879#	1880#	1881#	1882#	1883#	1884#	1885#	1886#	1887#	1888#	1889#
1890#	1891#	1892#	1893#	1894#	1895#	1896#	1897#	1898#	1899#	1900#	1901#	1902#
1903#	1904#	1905#	1906#	1907#	1908#	1909#	1910#	1911#	1912#	1913#	1914#	1915#
1916#	1917#	1918#	1919#	1920#	1921#	1922#	1923#	1924#	1925#	1926#	1927#	1928#
1929#	1930#	1931#	1932#	1933#	1934#	1935#	1936#	1937#	1938#	1939#	1940#	1941#
1942#	1943#	1944#	1945#	1946#	1947#	1948#	1949#	1950#	1951#	1952#	1953#	1954#
1955#	1956#	1957#	1958#	1959#	1960#	1961#	1962#	1963#	1964#	1965#	1966#	1967#
1968#	1969#	1970#	1971#	1972#	1973#	1974#	1975#	1976#	1977#	1978#	1979#	1980#
1981#	1982#	1983#	1984#	1985#	1986#	1987#	1988#	1989#	1990#	1991#	1992#	1993#
1994#	1995#	1996#	1997#	1998#	1999#	2000#	2001#	2002#	2003#	2004#	2005#	2006#
2007#	2008#	2009#	2010#	2011#	2012#	2013#	2014#	2015#	2016#	2017#	2018#	2019#
2020#	2021#	2022#	2023#	2024#	2025#	2026#	2027#	2028#	2029#	2030#	2031#	2032#
2033#	2034#	2035#	2036#	2037#	2038#	2039#	2040#	2041#	2042#	2043#	2044#	2045#
2046#	2047#	2048#	2049#	2050#	2051#	2052#	2053#	2054#	2055#	2056#	2057#	2058#
2059#	2060#	2061#	2062#	2063#	2064#	2065#	2066#	2067#	2068#	2069#	2070#	2071#
2072#	2073#	2074#	2075#	2076#	2077#	2078#	2079#	2080#	2081#	2082#	2083#	2084#
2085#	2086#	2087#	2088#	2089#	2090#	2091#	2092#	2093#	2094#	2095#	2096#	2097#
2098#	2099#	2100#	2101#	2102#	2103#	2104#	2105#	2106#	2107#	2108#	2109#	2110#
2111#	2112#	2113#	2114#	2115#	2116#	2117#	2118#	2119#	2120#	2121#	2122#	2123#
2124#	2125#	2126#	2127#	2128#	2129#	2130#	2131#	2132#	2133#	2134#	2135#	2136#
2137#	2138#	2139#	2140#	2141#	2142#	2143#	2144#	2145#	2146#	2147#	2148#	2149#
2150#	2151#	2152#	2153#	2154#	2155#	2156#	2157#	2158#	2159#	2160#	2161#	2162#
2163#	2164#	2165#	2166#	2167#	2168#	2169#	2170#	2171#	2172#	2173#	2174#	2175#
2176#	2177#	2178#	2179#	2180#	2181#	2182#	2183#	2184#	2185#	2186#	2187#	2188#
2189#	2190#	2191#	2192#	2193#	2194#	2195#	2196#	2197#	2198#	2199#	2200#	2201#
2202#	2203#	2204#	2205#	2206#	2207#	2208#	2209#	2210#	2211#	2212#	2213#	2214#
2215#	2216#	2217#	2218#	2219#	2220#	2221#	2222#	2223#	2224#	2225#	2226#	2227#
2228#	2229#	2230#	2231#	2232#	2233#	2234#	2235#	2236#	2237#	2238#	2239#	2240#
2241#	2242#	2243#	2244#	2245#	2246#	2247#	2248#	2249#	2250#	2251#	2252#	2253#
2254#	2255#	2256#	2257#	2258#	2259#	2260#	2261#	2262#	2263#	2264#	2265#	2266#
2267#	2268#	2269#	2270#	2271#	2272#	2273#	2274#	2275#	2276#	2277#	2278#	2279#
2280#	2281#	2282#	2283#	2284#	2285#	2286#	2287#	2288#	2289#	2290#	2291#	2292#
2293#	2294#	2295#	2296#	2297#	2298#	2299#	2300#	2301#	2302#	2303#	2304#	2305#
2306#	2307#	2308#	2309#	2310#	2311#	2312#	2313#	2314#	2315#	2316#	2317#	2318#
2319#	2320#	2321#	2322#	2323#	2324#	2325#	2326#	2327#	2328#	2329#	2330#	2331#
2332#	2333#	2334#	2335#	2336#	2337#	2338#	2339#	2340#	2341#	2342#	2343#	2344#
2345#	2346#	2347#	2348#	2349#	2350#	2351#	2352#	2353#	2354#	2355#	2356#	2357#
2358#	2359#	2360#	2361#	2362#	2363#	2364#	2365#	2366#	2367#	2368#	2369#	2370#
2371#	2372#	2373#	2374#	2375#	2376#	2377#	2378#	2379#	2380#	2381#	2382#	2383#
2384#	2385#	2386#	2387#	2388#	2389#	2390#	2391#	2392#	2393#	2394#	2395#	2396#
2397#	2398#	2399#	2400#	2401#	2402#	2403#	2404#	2405#	2406#	2407#	2408#	2409#
2410#	2411#	2412#	2413#	2414#	2415#	2416#	2417#	2418#	2419#	2420#	2421#	2422#
2423#	2424#	2425#	2426#	2427#	2428#	2429#	2430#	2431#	2432#	2433#	2434#	2435#
2436#	2437#	2438#	2439#	2440#	2441#	2442#	2443#	2444#	2445#	2446#	2447#	2448#
2449#	2450#	2451#	2452#	2453#	2454#	2455#	2456#	2457#	2458#	2459#	2460#	2461#
2462#	2463#	2464#	2465#	2466#	2467#	2468#	2469#	2470#	2471#	2472#	2473#	2474#
2475#	2476#	2477#	2478#	2479#	2480#	2481#	2482#	2483#	2484#	2485#	2486#	2487#
2488#	2489#	2490#	2491#	2492#	2493#	2494#	2495#	2496#	2497#	2498#	2499#	2500#
2501#	2502#	2503#	2504#	2505#	2506#	2507#	2508#	2509#	2510#	2511#	2512#	2513#
2514#	2515#	2516#	2517#	2518#	2519#	2520#	2521#	2522#	2523#	2524#	2525#	2526#
2527#	2528#	2529#	2530#	2531#	2532#	2533#	2534#	2535#	2536#	2537#	2538#	2539#
2540#	2541#	2542#	2543#	2544#	2545#	2546#	2547#	2548#	2549#	2550#	2551#	2552#
2553#	2554#	2555#	2556#	2557#	2558#	2559						

