


```

LL          TTTTTTTTTT DDDDDDDD RRRRRRRR I I I I I VV      VV EEEEEEEEE E RRRRRRRR
LL          TTTTTTTTTT DDDDDDDD RRRRRRRR I I I I I VV      VV EEEEEEEEE E RRRRRRRR
LL          TT          DD          RR          II      VV      VV EE          RR          RR
LL          TT          DD          RR          II      VV      VV EE          RR          RR
LL          TT          DD          RR          II      VV      VV EE          RR          RR
LL          TT          DD          RR          II      VV      VV EE          RR          RR
LL          TT          DD          RR          II      VV      VV EE          RR          RR
LL          TT          DD          RR          II      VV      VV EE          RR          RR
LL          TT          DD          RR          II      VV      VV EE          RR          RR
LL          TT          DD          RR          II      VV      VV EE          RR          RR
LL          TT          DD          RR          II      VV      VV EE          RR          RR
LLLLLLLLLL TT          DDDDDDDD RR          RR          I I I I I VV      VV EE          RR          RR
LLLLLLLLLL TT          DDDDDDDD RR          RR          I I I I I VV      VV EE          RR          RR

```

```

LL          I I I I I SSSSSSSS
LL          I I I I I SSSSSSSS
LL          II      SS
LL          II      SS
LL          II      SS
LL          II      SSSSSS
LL          II      SSSSSS
LL          II      SS
LL          II      SS
LL          II      SS
LL          II      SS
LLLLLLLLLL I I I I I SSSSSSSS
LLLLLLLLLL I I I I I SSSSSSSS

```

(4)	179	Global Definitions
(5)	216	Local Definitions
(18)	813	Driver Prologue Table
(19)	879	Local Storage
(22)	1025	Port Vector
(25)	1142	LT\$CTRL_INIT - Controller Initialization
(26)	1245	LT\$HISTORY - Save history in the buffer
(27)	1297	LT\$STRETRY - Entry to start driver
(28)	1371	LT\$GETFFI - Get the FFI block and initialize FFI interface
(29)	1438	LT\$SHUTENTRY - Shutdown entry point
(30)	1570	TQE TIMER BUILDING AND WAITING ROUTINES
(31)	1636	LT\$SHUT_DONE - Datalink shutdown complete entry
(32)	1660	LT\$ASYNCERR - Process async errors from datalink
(33)	1672	LT\$SETENTRY - Set a new multicast message
(34)	1768	LT\$UNIT_INIT - Unit Initialization
(35)	1836	LT\$UCB_INIT - Initialize a terminal UCB
(36)	1875	LT\$STARTIO - Start I/O routine
(37)	2127	LT\$FLUSH_DATA - Flush buffered output data and drain TT buffer
(38)	2150	LT\$ABORT - Abort (flush) buffered output data
(38)	2176	LT\$FLOW_CHANGE - Change flow control
(39)	2197	LT\$XON - Resume input stream into class driver
(39)	2247	LT\$XOFF - Stop input stream into class driver
(40)	2306	LT\$FFI_RCV_MSG - FAST Interface Receive Complete routine
(41)	2491	PROCESS RECEIVED MESSAGE
(42)	2554	CIRCUIT STATE TRANSITIONS
(43)	2613	PROCESS RECEIVED SLOT DATA
(44)	2737	PROCESS SLOT CREDITS RECEIVED
(45)	2837	BUILD A STOP SLOT
(46)	2882	PROCESS OUTPUT SLOT DATA
(48)	3138	CONSUME CREDIT WHEN FILLING IN SLOT FIELD
(49)	3222	SEND REPLY RESPONSE TO RECEIVED MESSAGE
(50)	3297	LT\$CREATECSB - Create a CSB
(51)	3350	LT\$NEW_CIRCUIT - Get Concentrator State Block
(52)	3555	LT\$DEALLOCBSB - Deallocate a CSB
(53)	3661	LT\$CREATEUCB - Create an LT UCB
(54)	3699	LT\$DESTROYUCB - Destroy an LT UCB
(55)	3747	LT\$ALC_UCB - Allocate New LT UCB
(56)	3894	LT\$HANGUP_UCB - Cause Terminal Hangup On UCB
(57)	3937	LT\$DISCONNECT - Port Disconnect
(58)	4001	LT\$KILLUCB - Delete a dried up UCB
(59)	4043	LT\$SIDELINEUCB - Set a UCB aside
(60)	4074	LT\$CIRCDEAD - Declare circuit dead
(61)	4113	LT\$STOPCIRC - Transmit stop message
(62)	4195	LT\$SET_TIMER - Start Timer
(63)	4259	LT\$TICK - Timer Service Routine
(64)	4476	LT\$XMIT - Transmit a message
(65)	4612	LT\$XMT_FFIDONE - FFI Transmit done routine
(66)	4681	LT\$FFIPOSTDONE - Garbage transmit posting routine

:JAY0002
-1

```

0000 1 .TITLE LTDRIVER - Local Area Terminal Port Driver
0000 .1 .IDENT 'V04-002'
0000 3
0000 4 :*****
0000 5 :*
0000 6 :* COPYRIGHT (c) 1978, 1980, 1982, 1984 BY
0000 7 :* DIGITAL EQUIPMENT CORPORATION, MAYNARD, MASSACHUSETTS.
0000 8 :* ALL RIGHTS RESERVED.
0000 9 :*
0000 10 :* THIS SOFTWARE IS FURNISHED UNDER A LICENSE AND MAY BE USED AND COPIED
0000 11 :* ONLY IN ACCORDANCE WITH THE TERMS OF SUCH LICENSE AND WITH THE
0000 12 :* INCLUSION OF THE ABOVE COPYRIGHT NOTICE. THIS SOFTWARE OR ANY OTHER
0000 13 :* COPIES THEREOF MAY NOT BE PROVIDED OR OTHERWISE MADE AVAILABLE TO ANY
0000 14 :* OTHER PERSON. NO TITLE TO AND OWNERSHIP OF THE SOFTWARE IS HEREBY
0000 15 :* TRANSFERRED.
0000 16 :*
0000 17 :* THE INFORMATION IN THIS SOFTWARE IS SUBJECT TO CHANGE WITHOUT NOTICE
0000 18 :* AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT
0000 19 :* CORPORATION.
0000 20 :*
0000 21 :* DIGITAL ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS
0000 22 :* SOFTWARE ON EQUIPMENT WHICH IS NOT SUPPLIED BY DIGITAL.
0000 23 :*
0000 24 :*
0000 25 :*****
0000 26
0000 27 : Do not remove items from this list. Add X when item is done.
0000 28 : to be done:
0000 29
0000 30 : - LATCP should be allowed to specify the Ethernet device.
0000 31 : - fix slot stop and circuit stop code for correct message format
0000 32 : including reason code and text.
0000 33 : - transmit two slots/message from host transmit loop.
0000 34 : - allocate and be able to send additional buffers based about the servers
0000 35 : value of XTRABFRs (in START message).
0000 36 : - send credits in DATA_B slots.
0000 37 :

```

```

0000 39
0000 40
0000 41 :*****
0000 42 :*
0000 43 :* Copyright (c) 1982, 1984
0000 44 :* by digital equipment corporation, maynard, mass.
0000 45 :*
0000 46 :* this software is furnished under a license and may be used and copied
0000 47 :* only in accordance with the terms of such license and with the
0000 48 :* inclusion of the above copyright notice. this software or any other
0000 49 :* copies thereof may not be provided or otherwise made available to any
0000 50 :* other person. no title to and ownership of the software is hereby
0000 51 :* transferred.
0000 52 :*
0000 53 :* the information in this software is subject to change without notice
0000 54 :* and should not be construed as a commitment by digital equipment
0000 55 :* corporation.
0000 56 :*
0000 57 :* digital assumes no responsibility for the use or reliability of its
0000 58 :* software on equipment which is not supplied by digital.
0000 59 :*
0000 60 :*****
0000 61
0000 62 ++
0000 63 Facility:
0000 64
0000 65 VAX/VMS Terminal Driver
0000 66
0000 67 Abstract:
0000 68
0000 69 Local Area Terminal Port Driver
0000 70
0000 71 This is an alternate port driver for use with the VMS terminal
0000 72 driver. It forms the host end of the Local Area Terminal (LAT)
0000 73 protocol and communicates with a LAT concentrator to provide
0000 74 terminal communications on a local area network.
0000 75
0000 76 This driver performs IO using a datalink driver via the FFI
0000 77 mechanism. Its connection with the datalink driver is controlled
0000 78 by a program called LATCP.
0000 79
0000 80
0000 81
0000 82 Authors:
0000 83
0000 84 Bruce Mann
0000 85 Darrell Duffy
0000 86 Joe Marchesani
0000 87 Rich Bailey
0000 88
0000 89 Revision history:
0000 90
0000 .1 V04-002 JAY0002 John A. Ywoskus 17-Dec-1984
0000 .2 Add CPU dispatch table to determine max slots/circuit.
0000 .3 Fix odd length reject slot format.
0000 .4
0000 .5 V04-001 JAY0001 John A. Ywoskus 28-Sep-1984

```

:JAY0002
:JAY0002
:JAY0002
:JAY0002
:JAY0001

LTDRIVER
V04-002

- Local Area Terminal Port Driver I 14

8-JAN-1985 17:22:25 VAX/VMS Macro V04-00
5-SEP-1984 11:40:22 [LAT.BUGSRC]LTDRIVER.MAR;1

Page 3
(3)

:JAY0001
:JAY0001
:JAY0001
:JAY0001
-85

0000 .6 :
0000 .7 :
0000 .8 :
0000 .9 :
0000 176 :
0000 177 :--

Add code to not set any flow control characters if
terminal is set /PASSALL.
Add MicroVAX II to CPU RATING.
Mark terminals OFFLINE when called at DISCONNECT entry.

```
0000 179      .SBTTL Global Definitions
0000 180
0000 181      .ENABLE SUPPRESSION
0000 182
0000 183      :
0000 184      :
0000 185      :
0000 186      :
0000 187      $LATDEF      : LAT communication area defs
0000 188      $ACBDEF      : Ast control block
0000 189      $ADPDEF      : Define adapter
0000 190      $CRBDEF      : Define crb
0000 191      $CXBDEF      : Complex buffer
0000 192      $DDBDEF      : Define ddb
0000 193      $DEVDEF      : Define device characteristics
0000 194      $DPTDEF      : Define dpt
0000 195      $DYNDEF      : Dynamic memory block codes
0000 196      $FFIDEF      : Fast Interface block
0000 197      $FKBDEF      : Fork block definitions
0000 198      $IPLDEF      : IPL levels
0000 199      $MTXDEF      : Mutex offsets
0000 200      $ORBDEF      : Object's Rights Block offsets
0000 201      $PCBDEF      : Process control block
0000 202      $PHDDEF      : Process header block
0000 203      $PRDEF      : Processor register definitions
0000 204      $RSNDEF      : Resouce wait codes
0000 205      $TQEDEF      : Timer queue elements
0000 206      $UCBDEF      : Define ucb
0000 207      $VECDEF      : Define vector for crb
0000 208
0000 209      $TTYDEF      : Define terminal driver symbols
0000 210      $TTDEF      : Define terminal types
0000 211      $TT2DEF      : Define extended characteristics
0000 212      $TTYMACS     : Define terminal driver macros
0000 213      $TTYDEFS     : Define terminal driver symbols
0000 214
```

```

0000 216 .SBTTL Local Definitions
0000 217 :
0000 218 :
0000 219 :
0000 220 .MACRO ALIGN_LONG
0000 221 .iif ne <.&3>, .BLKB <4-<.&3>> ; align to longword boundary, if needed
0000 222 .ENDM ALIGN_LONG
0000 223 :
0000 224 :
0000 225 :
0000 226 :
0000 227 :
00000001 0000 228 LT_HISTORY = 1 ; keep history of received/transitted ni fra
0000 229 ::&& LT_CRED_CHECK = 1 ; validate credit total for UCBs
0000 230 ::&& LT_XMT_CHECK = 1 ; validate transmit frame slots dynamically
0000 231 :
0000 232 :
0000 233 Constants defined for the VMS LAT host implementation
0000 234 :
00000007 0000 235 TTY_C_BELL = 7 ; Control_G (^G) ... bell character
00000003 0000 236 LATSC_VMS = 3 ; VAX/VMS product type code
00000004 0000 237 LATSC_VMS_VER = 4 ; Part of VAX/VMS V4.0
00000008 0000 238 LATSC_IPL = 8 ; Fork IPL to synchronize this driver
00000014 0000 239 LATSC_PROGRESS = 20 ; Must make progress every 20 msgs
00000002 0000 240 LATSC_XMT_BUFFERS = 2 ; Number of transmit buffers
00000001 0000 241 LATSC_MAX_RCRED = 1 ; Maximum number of credits extended
00000050 0000 242 LATSC_UCB_BUFSIZ = 80 ; Size of UCB buffering
00000004 0000 243 LATSC_UCB_SLOTSIZ = 4 ; Size of formatted slot buffer in UCB
00000002 0000 244 LATSC_UCB_TIMEOUT = 2 ; Allow 2 seconds before deleting UCB's
00000020 0000 245 LATSC_MAX_CSBS = 32 ; Maximum number of circuits handled
00000040 0000 246 LATSC_MAX_SLOTS = 64 ; Maximum slots in a message, this also
0000 247 ; implies max connections per circuit
00000005 0000 248 LATSC_HI_VER = 5 ; Highest supported LAT protocol version
00000005 0000 249 LATSC_LO_VER = 5 ; Lowest supported LAT protocol version
00000005 0000 250 LATSC_CUR_VER = 5 ; Current LAT protocol version
00000000 0000 251 LATSC_CUR_ECO = 0 ; Current LAT protocol ECO version
000005DC 0000 252 LATSC_MAX_MSGSIZ = 1500 ; Maximum Data Link message size
000000FF 0000 253 LATSC_MAX_SLOTSIZ = 255 ; Maximum Slot size
00000040 0000 254 LATSC_LOC_LEN = 64 ; Maximum length of LOcation field
00000020 0000 255 LATSC_GRP_LEN = 32 ; Maximum number of group codes
00000008 0000 256 LATSC_SVC_LEN = 8 ; Maximum number of service classes
00000006 0000 257 LATSC_MAX_SERVICES = 6 ; Maximum number of services
00000009 0000 258 LATSC_MULTICAST1 = ^X0009 ; LAT Multicast address
0000002B 0000 259 LATSC_MULTICAST2 = ^X002B ;
00000F00 0000 260 LATSC_MULTICAST3 = ^X0F00 ;
00000002 0000 261 LATSC_HOST_TIMER = 2 ; Host circuit timeout value (in SEcs)
0000000A 0000 262 LATSC_MULTICAST_TIMER = 10 ; Multicast message timer
00000050 0000 263 LATSC_CIR_TIMER = 80 ; Host preferred circuit timer (in MS)
004C4B40 0000 264 LATSC_SHUTDELAY = 5*1000*1000 ; Delay time = 1/2 second
0000000A 0000 265 LATSC_KEEP_CSB = 10 ; Keep last 10 CSBs
0000 266 :
0000 267 :
0000 268 :
0000 269 :
0000 270 :
00000134 0000 271 $DEFINI UCB GLOBAL
00000134 0000 272 . = UCBSC_TT_LENGTH

```



```

0134 273 ALIGN_LONG ; align to longword boundary
0134 274 $DEF UCBSL_LT_CSB .BLKL 1 ; CSB address
0138 275 $DEF UCBSL_LT_DEADLINK .BLKL 1 ; Link for dead ucbs
013C 276 $DEF UCBSL_LT_INPBUF .BLKL 1 ; Pointer to LAT type ahead buffer
0140 277 $DEF UCBSB_LT_REMID .BLKB 1 ; Remote slot index number
0141 278 $DEF UCBSB_LT_LOCID .BLKB 1 ; Local slot index number
0142 279 $DEF UCBSB_LT_DATAW .BLKB 1 ; Data waiting flags
0143 280 $VIELD UCB,0,<-
0143 281 <LT_DATA,1,M>- ; * Output data waiting
0143 282 <LT_FLOW,1,M>- ; * Send current flow control values
0143 283 <LT_ABORT,1,M>- ; * Send abort request
0143 284 >
0143 285
0143 286 $DEF UCBSB_LT_LATSTS .BLKB 1 ; Status for local terminal connection
0144 287 $VIELD UCB,0,<-
0144 288 <LT_HANGUP,1,M>- ; * We are hanging up the slot
0144 289 <LT_DEAD,1,M>- ; * We have linked the UCB on deadlist
0144 290 <LT_OVFLOW,1,M>- ; * We had an overflow on input (XOFF)
0144 291 <LT_BOUND,1,M>- ; * Terminal is bound, dcn't delete UCB
0144 292 <LT_INPUT,1,M>- ; * Input stream in progress
0144 293 >
0144 294
0144 295 $DEF UCBSB_LT_STATE .BLKB 1 ; Slot state
0145 296 $EQU UCBSB_LT_STATE_START 1 ; * State is starting
0145 297 $EQU UCBSB_LT_STATE_RUN 2 ; * State is running
0145 298 $EQU UCBSB_LT_STATE_STOP 3 ; * State is stopping (send stop slot)
0145 299 $EQU UCBSB_LT_STATE_KILL 4 ; * Kill UCB immediately
0145 300
0145 301 $DEF UCBSB_LT_REASON .BLKB 1 ; Reason for stopping slot
0146 302 $DEF UCBSB_LT_TCRED .BLKB 1 ; Available credits for this slot
0147 303 $DEF UCBSB_LT_XCRED .BLKB 1 ; Credits extended to concentrator
0148 304 $DEF UCBSB_LT_RCRED .BLKB 1 ; Credits to be returned to concentrator
0149 305 $DEF UCBSB_LT_SLOTSZ .BLKB 1 ; Slot size (negotiated)
014A 306 $DEF UCBSB_LT_MAXC .BLKB 1 ; Size of UCB buffering
014B 307 $DEF UCBSB_LT_CURC .BLKB 1 ; Current character count
014C 308 $DEF UCBSB_LT_CBUF .BLKB LAT$C_UCB_BUFSIZ ; Startio data buffer
019C 309 $DEF UCBSB_LT_EBUF ; Startio data buffer end
019C 310 $DEF UCBSB_LT_LENGTH ; Length of block
019C 311 $DEFEND UCB

```

```

0000 313
0000 314 :+
0000 315 : Circuit state block
0000 316 :
0000 317 : For each concentrator, one virtual circuit is maintained.
0000 318 : Protocol state is maintained in circuit state blocks.
0000 319 : The CSB addresses are stored in a vector starting
0000 320 : at CSB_TABLE.
0000 321 :-
0000 322
0000 323 $DEFINI CSB GLOBAL
0000 324 .BLKL 1
00000004 0000 325 .BLKL 1
00000008 0004 326 $DEF CSB_W_SIZE .BLKW 1 ; Size of this block in bytes
000A 327 $DEF CSB_B_TYPE .BLKB 1 ; Type of block
000B 328 $DEF CSB_B_STATE .BLKB 1 ; Virtual circuit state:
000C 329 $SEQU CSB_C_STATE_HALT 0 ; * Circuit halted state
000C 330 $SEQU CSB_C_STATE_START 1 ; * Circuit starting state
000C 331 $SEQU CSB_C_STATE_RUN 2 ; * Circuit running state
000C 332 :
000C 333 : Counter area - must follow standard block header!
000C 334 :
000C 335 ASSUME GHBST_CSBCTR EQ
000C 336 $DEF CSB_Z_LCB .BLKB LCB_C_LENGTH ; Circuit block counter area
001C 337 :
001C 338 : Server name area - must immediately follow counter area
001C 339 :
001C 340 $DEF CSB_B_SERVER .BLKB 1 ; Length of server name
001D 341 $DEF CSB_T_SERVER .BLKB GHBSK_NAMELEN ; Server name field
002D 342 $DEF CSB_B_REFC .BLKB 1 ; Number of UCBs attached to this CSB
002E 343 :
002E 344 : Destination Ethernet address - must immediately follow server name area
002E 345 :
002E 346 $DEF CSB_Z_DST .BLKW 3 ; Concentrator physical address
0034 347 :
0034 348 $DEF CSB_Q_XBUFQ .BLKQ 1 ; Current transmit buffer queue
003C 349 $DEF CSB_Q_XWAITQ .BLKQ 1 ; Transmit buffers waiting queue
0044 350 $DEF CSB_L_XCXB .BLKL LATSC_XMT_BUFFERS ; Transmit CXBs in progress
004C 351 $DEF CSB_L_STOPREASON .BLKL 1 ; Address of the stop reason block
0050 352 $DEF CSB_W_TIMEOUT .BLKW 1 ; Timeout cell for CSB
0052 353 $DEF CSB_W_XMTTMO .BLKW 1 ; Timeout count for retransmit
0054 354 $DEF CSB_W_PROGRESS .BLKW 1 ; Progress counter
0056 355 $DEF CSB_W_PROGSEQ .BLKW 1 ; Transmit error control for progress
0058 356 $DEF CSB_B_XMTBSY .BLKB 1 ; Transmit busy and count of waiters
0059 357 $DEF CSB_B_XMTCNT .BLKB 1 ; Count of buffers to transmit
005A 358 $DEF CSB_B_XCXB_INX .BLKB 1 ; XCXB index
005B 359 $DEF CSB_B_SPARE .BLKB 1 ; SPARE
005C 360 :
005C 361 ; Start of circuit header as it appears in transmitted messages
005C 362 :
005C 363 $DEF CSB_T_CIRCHDR .BLKB 1 ; Lat circuit header
005C 364 $DEF CSB_B_FLAG .BLKB 1 ; Message flags byte
005D 365 $DEF CSB_B_NUM_SLOTS .BLKB 1 ; Number of slots
005E 366 $DEF CSB_W_REMTD .BLKB 1 ; Remote virtual circuit id
005E 367 $DEF CSB_B_REMIDN .BLKB 1 ; Remote virtual circuit id number
005F 368 $DEF CSB_B_REMIDS .BLKB 1 ; Remote virtual circuit id sequence
0060 369 $DEF CSB_W_LOCID .BLKB 1 ; Local virtual circuit id

```

```
0060 370 $DEF CSB_B_LOCIDN .BLKB 1 ; Local virtual circuit id number
0061 371 $DEF CSB_B_LOCIDS .BLKB 1 ; Local virtual circuit id sequence
0062 372 $DEF CSB_W_XSEQ ; Transmitter error control
0062 373 $DEF CSB_B_XSEQ .BLKB 1 ; Sequence number being transmitted
0063 374 $DEF CSB_B_XACK .BLKB 1 ; Highest sequence number received
0064 375 $SEQU CSB_S_CIRCHDR <.-CSB_T_CIRCHDR> ; Size of header
0064 376
0064 377 ; End of circuit header
0064 378
0064 379 $DEF CSB_W_RSEQ ; Sequence number to receive
0064 380 $DEF CSB_B_RSEQ .BLKB 1 ; Sequence number to receive
0065 381 $DEF CSB_B_RACK .BLKB 1 ; Highest sequence number acknowledged
0066 382 $DEF CSB_W_TIMRESET .BLKW 1 ; Timeout reset value
0068 383 $DEF CSB_B_INX .BLKB 1 ; CSB table index
0069 384 $DEF CSB_B_MAX_SLOTS .BLKB 1 ; Maximum number of slots (negotiated)
006A 385 $DEF CSB_W_MAX_MSGSIZ .BLKW 1 ; Maximum message size (negotiated)
006C 386 $DEF CSB_C_FIXLENGTH ; Length of fixed block
006C 387 :
006C 388 : UCB list area (size = 4*min(lat$c_max_slots,server_slot_count) )
006C 389 :
006C 390 ALIGN_LONG ; align to longword boundary
006C 391 $DEF CSB_L_UCBLST
006C 392
006C 393 $DEFEND CSB
```

```
0000 395
0000 396 :+
0000 397 :
0000 398 :
0000 399 :
0000 400 :
0000 401 :
0000 402 :
0000 403 :
0000 404 :
0000 405 :-
0000 406
0000 407 $DEFINI INB GLOBAL
0000 408
0000 409 $DEF INB_W_BOFF .BLKW 1 ; Offset to start of data
0002 410 $DEF INB_W_BCNT .BLKW 1 ; Count of data remaining
0004 411 $DEF INB_L_SPARE .BLKL 1 ; Spare longword
0008 412 $DEF INB_W_SIZE .BLKW 1 ; Size of structure
000A 413 $DEF INB_B_TYPE .BLKB 1 ; Type of structure
000B 414 $DEF INB_B_SPARE .BLKB 1 ; Spare byte
000C 415 $DEF INB_C_LENGTH ; Size of structure header
000C 416
000C 417 $DEFEND INB
0000 418
```

Terminal overflow input buffer definitions

The terminal overflow buffer is only used when a call is made to the XOFF routine to stop the input flow. The overflow buffer is allocated and the rest of the input data is copied to the overflow buffer. When we are resumed at XON, the data from the input overflow buffer is dumped into the class driver.

```

0000 420
0000 421 :+
0000 422 :   Receive buffer offsets and bit definitions
0000 423 :
0000 424 :   The format of receive and transmit buffers is identical for fields
0000 425 :   Starting with and following the destination address field. Ease of
0000 426 :   implemenatation dictates that the offsets be defined relative to
0000 427 :   the start of the buffer.
0000 428 :
0000 429 :   These are the offsets into the architecturally defined portion of
0000 430 :   the receive buffer itself.
0000 431 :-
0000 432
0000 433       $DEFINI RCV       GLOBAL
0000 434
00000000 0000 435  .=0
0000 436 $DEF  RCV_T_DATA           ; Start of data is right here
0000 437 $DEF  RCV_B_FLAG         .BLKB 1 ; Flags byte and message type
0001 438      ;
0001 439      ; Flag bits:
0001 440      ;
0001 441  _VIELD FLAG,0,<-          ; * Flags byte bit definitions recv & xmit
0001 442      <RRF,1,M>,-          ; * Response requested flag
0001 443      <MASTER,1,M>,-      ; * Remote station always sets this flag
0001 444      <MTYPE,6,M>,-      ; * Message type bits
0001 445      >
0001 446      ;
0001 447      ; Message types:
0001 448      ;
0001 449  $EQU  MTYP_C_RUN           0 ; * Run message
0001 450  $EQU  MTYP_C_START        1 ; * Start message
0001 451  $EQU  MTYP_C_HALT         2 ; * Halt message
0001 452  $EQU  MTYP_C_CONF         10 ; * Configuration message
0001 453
0001 454 $DEF  RCV_B_NUM_SLOTS .BLKB 1 ; Number of slots in buffer
0002 455 $DEF  RCV_W_DSTID         ; Destination virtual circuit id
0002 456 $DEF  RCV_B_DSTIDN .BLKB 1 ; Destination virtual circuit id number
0003 457 $DEF  RCV_B_DSTIDS .BLKB 1 ; Destination virtual circuit id seq
0004 458 $DEF  RCV_W_SRCID         ; Source virtual circuit id
0004 459 $DEF  RCV_B_SRCIDN .BLKB 1 ; Source virtual circuit id number
0005 460 $DEF  RCV_B_SRCIDS .BLKB 1 ; Source virtual circuit id
0006 461      ; sequence number
0006 462
0006 463 $DEF  RCV_B_SEQ .BLKB 1 ; Buffer sequence number
0007 464 $DEF  RCV_B_ACK .BLKB 1 ; Sequence number acknowledgement
0008 465 $DEF  RCV_T_MDATA         ; Start of type dependent data
0008 466
0008 467       $DEFEND RCV

```

```

0000 469
0000 470 :
0000 471 : Define START message offsets (used for both xmits and recvs)
0000 472 :
0000 473 $DEFINI STRT GLOBAL
0000 474 $DEF STRT_W_MSGSIZ .BLKW 1 ; Data link frame size
0002 475 $DEF STRT_B_PVER .BLKB 1 ; Circuit protocol version
0003 476 $DEF STRT_B_PECO .BLKB 1 ; Circuit Eng. change order level
0004 477 $DEF STRT_B_MAXSLOTS .BLKB 1 ; Maximum simultaneous slots
0005 478 $DEF STRT_B_DL_BFRS .BLKB 1 ; Number of extra rcv bfrs in server
0006 479 $DEF STRT_B_CIR_TIMR .BLKB 1 ; Local circuit timer in milliseconds
0007 480 $DEF STRT_B_KPA_TIMR .BLKB 1 ; Local keep alive timer in seconds
0008 481 $DEF STRT_W_FAC_NUM .BLKW 1 ; Facility number
000A 482 $DEF STRT_W_PROD_TYP .BLKW 1 ; Product type code
000C 483 $DEF STRT_C_LENGTH ; Length of fixed portion of message
000C 484 :
000C 485 : Start of variable length parameters
000C 486 :
000C 487 $DEF STRT_B_VAR ; Start of variable portion of start message
000C 488 $DEF STRT_B_NODE_LEN .BLKB 1 ; Destination node name length
000D 489 $DEF STRT_T_NODE .BLKB GHBSK_NAMELEN ; Destination node name text
001D 490 $DEF STRT_B_SYS_LEN .BLKB 1 ; Source node name length
001E 491 $DEF STRT_T_SYS .BLKB GHBSK_NAMELEN ; Source node name text
002E 492 $DEF STRT_B_ID_LEN .BLKB 1 ; Source node descriptor length
002F 493 $DEF STRT_T_ID .BLKB GHBSK_IDLEN ; Source node descriptor text
006F 494 $DEF STRT_B_LOC_LEN .BLKB 1 ; Source location length
0070 495 $DEF STRT_T_LOC .BLKB LATSC_LOC_LEN ; Source location text
00B0 496 $DEF STRT_B_PARAM .BLKB 1 ; Parameter code
00B1 497 $SEQU STRT_C_VAR_LEN <.-STRT_B_VAR> ; Length of variable portion of start
00B1 498 ; message
00B1 499 $DEFEND STRT
0000 500
0000 501 :
0000 502 : Define STOP message offsets
0000 503 :
0000 504 $DEFINI STOP GLOBAL
0000 505 $DEF STOP_B_RCODE .BLKB ; Circuit disconnect reason
0001 506 $DEF STOP_B_RLEN .BLKB ; Reason length in bytes
0002 507 $DEF STOP_T_REAS ; Reason ASCII text
0002 508 $DEFEND STOP
0000 509

```

```

0000 511
0000 512 :+
0000 513 : Transmit buffer offsets and bit definitions
0000 514 :
0000 515 : The buffer header is defined to be the same as that used by
0000 516 : the Ethernet datalink drivers.
0000 517 :-
0000 518
0000 519 $DEFINI CXB GLOBAL ; Transmit complex buffer
0000 520 :
0000 521 : Define the transmit/receive offsets in the CXB
0000 522 :
0000001C 0000 523 . = CXB$L_END_ACTION
001C 524 $DEF CXB$T_ENDADR .BLKL 1 ; End address of data to transmit
0020 525
0000000C 0020 526 . = CXB$W_LENGTH
000C 527 ASSUME CXB$W_OFFSET EQ CXB$W_LENGTH+2
000C 528 $DEF CXB$T_CSBB ; CSB address
000C 529
00000014 000C 530 . = CXB$L_IRP
0014 531 $DEF CXB$T_SAVE .BLKL 1 ; BOFF & BCNT save area
0018 532
0018 533 $DEFEND CXB
0000 534
0000 535 :
0000 536 : Start of architecturally defined offsets
0000 537 :
0000 538 $DEFINI XMT GLOBAL
0000 539
0000003A 0000 540 . = CXB$C_HEADER - <6+6+2>
003A 541 $DEF XMT_G_DST .BLKW 3 ; Destination address
0040 542
00000048 0040 543 . = CXB$C_HEADER
0048 544 $DEF XMT_T_DATA ; Start of transmitted data
0048 545 $DEF XMT_B_FLAG .BLKB 1 ; Flags byte and message type
0049 546
0049 547 :
0049 548 : Run message format:
0049 549 :
0049 550 $DEF XMT_B_NUM_SLOTS .BLKB 1 ; Number of slots in buffer
004A 551 $DEF XMT_W_DSTID ; Destination virtual circuit id
004A 552 $DEF XMT_B_DSTIDN .BLKB 1 ; Destination virtual circuit id number
004B 553 $DEF XMT_B_DSTIDS .BLKB 1 ; Destination virtual circuit id seq
004C 554 $DEF XMT_W_SRCID ; Source virtual circuit id
004C 555 $DEF XMT_B_SRCIDN .BLKB 1 ; Source virtual circuit id number
004D 556 $DEF XMT_B_SRCIDS .BLKB 1 ; Source virtual circuit id
004E 557 ; sequence number
004E 558
004E 559 $DEF XMT_B_SEQ .BLKB 1 ; Buffer sequence number
004F 560 $DEF XMT_B_ACK .BLKB 1 ; Sequence number acknowledgement
0050 561 $DEF XMT_T_MDATA ; Start of RUN message data
0050 562
0050 563 :
0050 564 : Multicast (CONFIGURATION) message format:
0050 565 :
00000049 0050 566 . = XMT_B_FLAG+1
0049 567 $DEF XMT_B_MC_CIR_TIMER .BLKB 1 ; Circuit timer

```

```

004A 568 $DEF XMT_B_MC_HI_VER .BLKB 1 ; Highest supported protocol version
004B 569 $DEF XMT_B_MC_LO_VER .BLKB 1 ; Lowest supported protocol version
004C 570 $DEF XMT_B_MC_CUR_VER .BLKB 1 ; version of this message
004D 571 $DEF XMT_B_MC_CUR_ECO .BLKB 1 ; eco of this message
004E 572 $DEF XMT_B_MC_INCARN .BLKB 1 ; Message incarnation
004F 573 $DEF XMT_B_MC_CHG_FLAG .BLKB 1 ; Changed fields in this msg
0050 574
0050 575 YIELD XMT_CHFLG,0,<-
0050 576 ZGROUP,1,M>,- ; * NODE group codes changed
0050 577 <NDESC,1,M>,- ; * NODE descriptor changed
0050 578 <SVCNAM,1,M>,- ; * Service name/number changed
0050 579 <RATE,1,M>,- ; * Service ratings changed
0050 580 <SDESC,1,M>,- ; * Service classes changed
0050 581 <CLASS,1,M>,- ; * Service classes changed
0050 582 <1>- ; * RESERVED
0050 583 <OTHER,1,M>,- ; * One of the OTHER fields changed
0050 584 >
0050 585 $SEQU XMT_CHFLG_M_ALL <^XFF> ; * All codes changed
0050 586
0050 587 $DEF XMT_W_MC_MSG_SIZ .BLKW 1 ; Maximum frame size
0052 588 $SEQU XMT_C_MC_LENGTH <.-XMT_T_DATA> ; Size of fixed part of multicast me
0052 589
0052 590 $DEF XMT_B_MC_SET ; Start of LATCP set portion of multicast msg
0052 591 $DEF XMT_B_MC_MULTIMR .BLKB 1 ; Multicast message timer
0053 592 $DEF XMT_B_MC_STATUS .BLKB 1 ; Node status
0054 593 $DEF XMT_B_MC_GRP_LEN .BLKB 1 ; Number of group codes
0055 594 $DEF XMT_T_MC_GROUP .BLKB LATSC_GRP_LEN ; Group code field
0075 595 $DEF XMT_B_MC_NODE_LEN .BLKB 1 ; Node name length
0076 596 $DEF XMT_T_MC_NODE .BLKB GHBSK_NAMELEN ; NODE name
0086 597 $DEF XMT_B_MC_NUM_SVCS .BLKB 1 ; Number of services
0087 598
0087 599 $DEF XMT_B_MC_RATE .BLKB 1 ; Service rating
0088 600 $DEF XMT_B_MC_NAME_LEN .BLKB 1 ; Service name length
0089 601 $DEF XMT_T_MC_NAME .BLKB GHBSK_NAMELEN ; Service name
0099 602 $DEF XMT_B_MC_ID_LEN .BLKB 1 ; Length of Identification field
009A 603 $DEF XMT_T_MC_ID .BLKB GHBSK_IDLEN ; Identification field
00DA 604 $SEQU XMT_C_MC_SVC_SIZE <.-XMT_B_MC_RATE> ; Size of each service field
00DA 605
00DA 606 $DEF XMT_T_MC_MORE_SVC .BLKB <<LATSC_MAX_SERVICES-1>*XMT_C_MC_SVC_SIZE>
0279 607
0279 608 $DEF XMT_B_MC_SVC_LEN .BLKB 1 ; Number of service classes
027A 609 $DEF XMT_B_MC_SVC .BLKB LATSC_SVC_LEN ; Service classes
0282 610 $SEQU XMT_C_MC_TOTAL <.-XMT_T_DATA> ; Length of total message
0282 611 ASSUME XMT_C_MC_TOTAL LE LATSC_MAX_MSGSIZ
0282 612
0282 613 $SEQU XMT_C_HDRLEN <XMT_T_DATA - XMT_T_DATA> ; Length of header
0282 614 ; Length of header
0282 615 $SEQU XMT_C_MAXDATA <LATSC_MAX_MSGSIZ - XMT_C_HDRLEN> ; Data in slots
0282 616 ; Data in slots
0282 617 $SEQU XMT_C_MAXLEN <LATSC_MAX_MSGSIZ + XMT_T_DATA> ; Total size of a buffer
0282 618 ; Total size of a buffer
0282 619 $DEFEND XMT

```



```

0000 621 :+
0000 622 :
0000 623 : Buffer slot offsets
0000 624 :
0000 625 : Each slot is formatted identically in both
0000 626 :- transmit and receive buffers as defined below.
0000 627 :
0000 628 $DEFINI SLT GLOBAL
0000 629
0000 630 $DEF SLT_T_START ; Start of slot
0000 631 $DEF SLT_B_DSTID .BLKB 1 ; Destination slot ID
0001 632 $DEF SLT_B_SRCID .BLKB 1 ; Source slot ID
0002 633 $DEF SLT_B_COUNT .BLKB 1 ; Character count in slot
0003 634 $DEF SLT_B_REAS ; Stop/reject slot reason (low nibble)
0003 635 $DEF SLT_B_CRED ; Credits extended (low order nibble)
0003 636 $DEF SLT_B_TYPE .BLKB 1 ; Slot type (high order nibble)
0004 637 ; STOP/REJECT reason codes:
0004 638 $SEQU SLT_C_USD 1 ; * User requested disconnect
0004 639 $SEQU SLT_C_SYS 2 ; * System shutdown
0004 640 $SEQU SLT_C_INVSLOT 3 ; * Invalid slot received
0004 641 $SEQU SLT_C_INVSVC 4 ; * Invalid service class received
0004 642 $SEQU SLT_C_RESOURCE 5 ; * Insufficient resources
0004 643 ; Slot type codes:
0004 644 $SEQU SLT_C_DA_SLOT <^X00> ; * DATA A slot
0004 645 $SEQU SLT_C_STR_SLOT <^X09> ; * START slot
0004 646 $SEQU SLT_C_DB_SLOT <^X0A> ; * DATA B slot
0004 647 $SEQU SLT_C_ATT_SLOT <^X0B> ; * ATTENTION slot
0004 648 $SEQU SLT_C_REJ_SLOT <^X0C> ; * REJECT slot
0004 649 $SEQU SLT_C_STP_SLOT <^X0D> ; * STOP slot
0004 650 $DEF SLT_T_DATA ; Start of slot data
0004 651
0004 652 :
0004 653 : Start slot data definitions
0004 654 :
00000004 0004 655 = SLT_T_DATA
0004 656 $DEF SLT_B_SVCC .BLKB 1 ; Service class
0005 657 $SEQU SLT_C_SVC_INTT 1 ; * Interactive Terminals
0005 658 $DEF SLT_B_AT_SLTSIZ .BLKB 1 ; Maximum length of attention slot
0006 659 $DEF SLT_B_DT_SLTSIZ .BLKB 1 ; Maximum length of Data slot
0007 660 $DEF SLT_B_DST_NAMLEN .BLKB 1 ; Length of destination slot name
0008 661 $DEF SLT_T_DST_NAME .BLKB GHBSK_NAMELEN
0018 662 $DEF SLT_B_SRC_NAMLEN .BLKB 1 ; Length of source slot name
0019 663 $DEF SLT_B_SRC_NAME .BLKB GHBSK_NAMELEN
0029 664 $SEQU SLT_S_START_SLOT <.-SLT_T_DATA> ; Length of Start slot
0029 665 $DEF SLT_B_PARAMS ; Start of parameter area
0029 666 $SEQU SLT_C_START_FLAG 1 ; * Start slot parameter flag is code 1
0029 667 -VIELD SLT_FLAG,0,<-
0029 668 <REMOTE,1,M>,- ; * Remote line
0029 669 <LOGIN,1,M>,- ; * Disable auto-login
0029 670 <BIND,1,M>,- ; * Terminal UCB is bound to server
0029 671 >
0029 672
0029 673 :
0029 674 : DATA_B slot data definitions
0029 675 :
00000004 0029 676 = SLT_T_DATA
0004 677 $DEF SLT_B_DB_CONTROL .BLKB 1 ; DATA_B slot control flag

```

```
0005 678      _VIELD  SLT_DB,0,<-
0005 679      <IFENA,1,M>,-
0005 680      <IFDIS,1,M>,-
0005 681      <OFENA,1,M>,-
0005 682      <OFDIS,1,M>,-
0005 683      <BREAK,1,M>,-
0005 684      >
0005 685 $DEF  SLT_B_DB_OFOF  .BLKB  1
0006 686 $DEF  SLT_B_DB_OFON  .BLKB  1
0007 687 $DEF  SLT_B_DB_IFOF  .BLKB  1
0008 688 $DEF  SLT_B_DB_IFON  .BLKB  1
0009 689 $EQU  SLT_S_DB_LEN   <.-SLT_T_DATA>
0009 690 $EQU  SLT_S_DB_SLOT  <.-SLT_T_START>
0009 691
0009 692
0009 693 :: ATTention slot data definitions
0009 694 ::
00000004 0009 695 :: = SLT_T_DATA
0004 696 $DEF  _SCT_B_ATT_CONTROL  .BLKB  1
0005 697      _VIELD  SCT_ATT,0,<-
0005 698      <,55,-
0005 699      <ABORT,1,M>,-
0005 700      >
0005 701 $EQU  SLT_S_ATT_LEN   <.-SLT_T_DATA>
0005 702 $EQU  SLT_S_ATT_SLOT  <.-SLT_T_START>
0005 703
0005 704
0005 705 :: STOP slot data definitions
0005 706 ::
00000004 0005 707 :: = SLT_T_DATA
0004 708 $DEF  _SCT_B_STP_RLEN  .BLKB  1
0005 709 $EQU  SLT_S_STP_LEN   <.-SLT_T_DATA>
0005 710 $EQU  SLT_S_STP_SLOT  <.-SLT_T_START>
0005 711 $DEF  SLT_T_STP_REAS
0005 712
0005 713 ::
0005 714 :: REJECT slot data definitions
0005 715 ::
00000004 0005 716 :: = SLT_T_DATA
0004 717 $DEF  _SCT_B_REJ_RLEN  .BLKB  1
0004 718 $EQU  SLT_S_REJ_LEN   <.-SLT_T_DATA>
0004 719 $EQU  SLT_S_REJ_SLOT  <.-SLT_T_START>
0004 720 $DEF  SLT_T_REJ_REAS
0004 721
0004 722 $DEFEND SLT
```

:JAY0002
-1

```
: Turn on flow control of keyboard i
: Turn off flow control of keyb inpu
: Output flow on
: Output flow off
: Break condition detected (recv slo
: Output-off flow char (from keyboard
: Output-on flow char (from keyboard
: Input-off flow character (from hos
: Input-on flow character (from host
: Length of DATA_B data
: Length of DATA_B slot
```

```
: ATTENTION slot control flag
: RESERVED
: Abort (flush pipe)
: Length of Attention data
: Length of Attention slot
```

```
: STOP slot reason length
: Length of fixed STOP slot data
: Length of fixed STOP slot
: STOP slot reason (variable)
```

```
: REJ slot reason length
: Length of fixed REJ slot data
: Length of fixed REJ slot
: REJ slot reason (variable)
```

```

0000 724 :
0000 725 : Local macros
0000 726 :
0000 727 :
0000 728 .MACRO INC_CTR, BASE, TYPE=L, ?L
0000 729 INC'TYPE BASE ; Increment counter
0000 730 BNEQ L ; Br if no overflow
0000 731 DEC'TYPE BASE ; Else, latch at maximum
0000 732 L:
0000 733 .END INC_CTR
0000 734
0000 735 .MACRO ADD_CTR, BASE1, BASE2, TYPE=L, ?L
0000 736 ADD'TYPE BASE1, BASE2 ; Add counters
0000 737 BCC L ; Br if no overflow
0000 738 MNEG'TYPE #1, BASE2 ; Else, latch at maximum
0000 739 L:
0000 740 .END ADD_CTR
0000 741
0000 742 .MACRO $DISPATCH, INDX, VECTOR, TYPE=W, NMODE=S^#, ?MN, ?MX, ?S, ?SS, ?ZZ
0000 743 SS:
0000 744
0000 745 .MACRO $DSP1, $DSP1 1
0000 746 .IRP $DSP1_2, $DSP1_1
0000 747 $DSP2_2 $DSP1_2
0000 748 .ENDR
0000 749 .ENDM $DSP1
0000 750
0000 751 .MACRO $DSP2, $DSP2 1, $DSP2 2
0000 752 .=<$DSP2 1-MN>*2 + 5
0000 753 .WORD $DSP2_2-S
0000 754 .ENDM $DSP2
0000 755
0000 756
0000 757 .MACRO $BND1, $BND1 1, $BND1 2, $BND1 3
0000 758 $BND2 $BND1_1, $BND1_2
0000 759 .ENDM $BND1
0000 760
0000 761 .MACRO $BND2, $BND2 1, $BND2 2
0000 762 .IIF $BND2_1, $BND2_2-., .=$BND2_2
0000 763 .ENDM $BND2
0000 764
0000 765 .MACRO $BND $BND 1, $BND 2
0000 766 .IRP $BND_3, <$BND_2>
0000 767 $BNDT $BND_1, $BND_3
0000 768 .ENDR
0000 769 .ENDM $BND
0000 770
0000 771 .=0
0000 772 ZZ:
0000 773 $BND GT, <VECTOR>
0000 774 MX:
0000 775 $BND LT, <VECTOR>
0000 776 MN:
0000 777 .=SS
0000 778
0000 779 CASE'TYPE INDX, #<MN-ZZ>, NMODE'<MX-MN>
0000 780 S:

```

```
0000 781      .REPT  MX-MN+1
0000 782      .WORD  <MX-MN>*2 + 2
0000 783      .ENDR
0000 784
0000 785      .=S
0000 786
0000 787      $DSP1  <<VECTOR>>
0000 788
0000 789      .=<MX-MN>*2 + S + 2
0000 790
0000 791 .ENDM $DISPATCH
0000 792
0000 793
0000 794      .MACRO  SETBIT BIT, BASE, ?L      ; Set specified bit
0000 795      BBSS   BIT, BASE, L
0000 796 L:
0000 797      .ENDM
0000 798
0000 799      .MACRO  CLRBIT BIT, BASE, ?L      ; Clear specified bit
0000 800      BBCC   BIT, BASE, L
0000 801 L:
0000 802      .ENDM
0000 803
0000 804      .MACRO  BREAK
0000 805      JSB   G^INISBRK
0000 806      .ENDM
0000 807
0000 808      .MACRO  DEBUG
0000 809      TSTL  @#-1
0000 810      .ENDM  DEBUG
0000 811
```

```

0000 813      .SBTTL  Driver Prologue Table
0000 814
00000000 815      .PSECT  $$$105_PROLOGUE
0000 816
0000 817      :
0000 818      : Driver prologue table:
0000 819      :
0000 820
0000 821  LT$DPT::
0000 822      DPTAB      -      : Driver start
0000 823      END=LT$END,-      : Driver prologue table
0000 824      UCBSIZE=UCB$C_LT_LENGTH,-; Size of each ucb of port driver
0000 825      ADAPTER=NULL,-      : Adapter type
0000 826      NAME=LTDRIVER,-      : Name of driver
0000 827      VECTOR=LT$VECTOR      : Port driver vector table
0038 828      DPT_STORE  INIT
0038 829      DPT_STORE  UCB,UCB$B_FIPL,B,LAT$C_IPL ; Fork ipl
003C 830      DPT_STORE  UCB,UCB$L_DEVCHAR,L,<-; Characteristics
003C 831      DEVSM_REC!-
003C 832      DEVSM_AVL!-
003C 833      DEVSM_IDV!-
003C 834      DEVSM_ODV!-
003C 835      DEVSM_TRM!-
003C 836      DEVSM_CCL>
0043 837      DPT_STORE  UCB,UCB$L_DEVCHAR2,L,<-
0043 838      DEVSM_NNM>      : Prefix name with <node$>
004A 839      DPT_STORE  UCB,UCB$B_DEVCLASS,B,DC$ TERM;
004E 840      DPT_STORE  UCB,UCB$B_TT_DETYPE,B,TT$ UNKNOWN      : Type
0052 841      DPT_STORE  UCB,UCB$W_TT_DESIZE,@W,TTY$GW_DEFBUF      : Buffer size
0059 842      DPT_STORE  UCB,UCB$L_TT_DECHAR,@L,TTY$GL_DEFCHAR      : Default characters
0060 843      DPT_STORE  UCB,UCB$L_TT_DECHA1,@L,TTY$GL_DEFCHAR2; Default characters
0067 844      DPT_STORE  UCB,UCB$W_TT_DESPEE,@B,TTY$GB_DEFSPEED; Default speed
006E 845      DPT_STORE  UCB,UCB$W_TT_DESPEE+1,@B,TTY$GB_RSPEED; Default rspeed
0075 846      DPT_STORE  UCB,UCB$B_TT_DEPARI,@B,TTY$GB_PARITY      : Default parity
007C 847      :** DPT_STORE  UCB,UCB$B_TT_PARITY,@B,TTY$GB_PARITY      : Default parity
007C 848      DPT_STORE  UCB,UCB$B_DEVTYPE,B,TT$ UNKNOWN      : Type
0080 849      DPT_STORE  UCB,UCB$W_DEVBUFSIZ,@W,TTY$GW_DEFBUF      : Buffer size
0087 850      DPT_STORE  UCB,UCB$L_DEVDEPEND,@L,TTY$GL_DEFCHAR      : Default characters
008E 851      DPT_STORE  UCB,UCB$L_TT_DEVDP1,@L,TTY$GL_DEFCHAR2; Default characters
0095 852      DPT_STORE  UCB,UCB$W_TT_SPEED,@B,TTY$GB_DEFSPEED      : Default speed
009C 853      DPT_STORE  UCB,UCB$W_TT_SPEED+1,@B,TTY$GB_RSPEED      : Default rspeed
00A3 854      DPT_STORE  UCB,UCB$B_DIPL,B,LAT$C_IPL      : Device ipl
00A7 855      DPT_STORE  UCB,UCB$L_TT_WFLINK,L,0      : Zero write queue.
00AE 856      DPT_STORE  UCB,UCB$L_TT_WBLINK,L,0      : Zero write queue.
00B5 857      DPT_STORE  UCB,UCB$L_TT_RTIMOU,L,0      : Zero read timed out
00BC 858      :** DPT_STORE  UCB,UCB$W_TT_PRTCTL,W,TTY$M_PC_NOTIME      : Disable all timers
00BC 859      DPT_STORE  ORB,ORB$B_FLAGS,B,-      : Default flags
00BC 860      ZORB$M_PROT 16>      : SOGW word protection
00C0 861      DPT_STORE  ORB,ORB$W_PROT,@W,TTY$GW_PROT      : Default protection
00C7 862      DPT_STORE  ORB,ORB$L_OWNER,@L,TTY$GL_OWNUIC      : Default owner uic
00CE 863      DPT_STORE  DDB,DOB$L_DDT,D,LT$DDT
00D3 864
00D3 865      DPT_STORE  REINIT
00D3 866      DPT_STORE  CRB,CRB$L_INTD+VEC$L_INITIAL,D,LT$CTRL_INIT ; Controller init
00D8 867      DPT_STORE  CRB,CRB$L_INTD+VEC$L_UNITINIT,D,LT$UNIT_INIT ; Unit init
00DD 868
0000 869      DPT_STORE  END

```

0000 870
0000 871
0000 872
0000 873
0000 874
0000 875
0000 876
0038 877

DDTAB DEVNAM = LT,- ; Dummy port driver dispatch table
START = 0,-
FUNCTB = 0

LTDRIVER
V04-002

- Local Area Terminal Port Driver N 15
Local Storage

8-JAN-1985 17:22:25
5-SEP-1984 11:40:22

VAX/VMS Macro V04-00
[LAT.BUGSRC]LTDRIVER.MAR;1

Page 21
(19)

:JAY0002
:JAY0002
:JAY0002
:JAY0002
:JAY0002
:JAY0002
:JAY0002
:JAY0002
:JAY0002

40 0118 .21
40 0119 .22
40 011A .23
40 011B .24
40 011C .25
40 011D .26
011E .27
00000010 011E .28

.BYTE LATSC_MAX_SLOTS :
.BYTE LATSC_MAX_SLOTS :
.BYTE LATSC_MAX_SLOTS :
.BYTE LATSC_MAX_SLOTS :
.BYTE LATSC_MAX_SLOTS :
.BYTE LATSC_MAX_SLOTS :

11
12
13
14
15
16

MAX_PR_SID = 16


```

011E 917
011E 918 :
011E 919 : Host counter block
011E 920 :
011E 921 :
011E 922 .ALIGN LONG
00000180 0120 923 GHB_AREA: .BLKB GHB$$_COMM_AREA ; Communications area
0120 924 .BLKB GHB$$_COMM_AREA
0180 925
0180 926 .ALIGN LONG
0180 927
00000184 0180 928 GHB_L_UCBO: .BLKL 1 ; LT UCB zero address
00000188 0184 929 GHB_L_DEADLINK: .BLKL 1 ; List of dead UCBs
0000018C 0188 930 GHB_L_FFI: .BLKL 1 ; FFI block address
00000190 018C 931 GHB_L_NULLCPU: .BLKL 1 ; Pointer to null CPU time
00000194 0190 932 GHB_L_LASTCPU: .BLKL 1 ; Value of last null CPU sample
00000198 0194 933 GHB_L_NULLSEC: .BLKL 1 ; Value of latt null CPU sample on secondary
00000199 0198 934 GHB_B_STATUS: .BLKB 1 ; Host status byte
0199 935 GHB_STS,0,<-
0199 936 <MULTI,1,M>,- ; Multicast buffer in use
0199 937 <ACTIVE,1,M>,- ; LTDRIVER is active
0199 938 <SHUT,1,M>,- ; Shutdown is in progress
0199 939 <TQE,1,M>,- ; Waiting for TQE to fire
0199 940 >
0000019A 0199 941 GHB_B_INCARN: .BLKB 1 ; Incarnation number for multicast message
0000019B 019A 942 GHB_B_OLD_CSBCNT: .BLKB 1 ; Count of old CSBs on queue
0000019C 019B 943 GHB_B_RATE: .BLKB 1 ; Initial rating computed from memory size
019C 944 :
019C 945 ; Multicast data set by LATCP
019C 946 :
019C 947 .ALIGN LONG
0000019E 019C 948 GHB_W_MC_SIZE: .BLKW 1 ; Size of name and ID strings
000003E8 019E 949 GHB_T_MC_DATA: .BLKB XMT_C_MC_TOTAL+16 ; Name and ID storage + fudge factor
03E8 950 :
03E8 951 : Multicast (Configuration) Message Destination Ethernet address
03E8 952 :
03E8 953 :
03E8 954 .ALIGN LONG
0009 03E8 955 GHB_Q_MULTIAADD: .WORD LAT$C_MULTIAADD1 ; LAT Multicast destination address
002B 03EA 956 .WORD LAT$C_MULTIAADD2 ;
0F00 03EC 957 .WORD LAT$C_MULTIAADD3 ;
03EE 958 ; Picks up next word also (garbage)
03EE 959 :
03EE 960 ; Data to control multicast buffer
03EE 961 :
000003F0 03EE 962 GHB_W_MULTIMR: .BLKW 1 ; Timer for multicast transmits
000003F4 03F0 963 GHB_L_MULTIBFR: .BLKL 1 ; Address of the multicast buffer
03F4 964 :
03F4 965 :
03F4 966 ; Host Multicast (Configuration) Message fixed portion template
03F4 967 ; (Fields are order-dependent and adjacent)
03F4 968 :
03F4 969 ASSUME XMT_B_FLAG EQ XMT_T_DATA
03F4 970 ASSUME XMT_B_MC_CUR_TIMER EQ XMT_B_FLAG+1
03F4 971 ASSUME XMT_B_MC_HI_VER EQ XMT_B_MC_CUR_TIMER+1
03F4 972 ASSUME XMT_B_MC_LO_VER EQ XMT_B_MC_HI_VER+1
03F4 973 ASSUME XMT_B_MC_CUR_VER EQ XMT_B_MC_LO_VER+1

```

```

03F4 974 ASSUME XMT_B_MC_CUR_ECO EQ XMT_B_MC_CUR_VER+1
03F4 975 ASSUME XMT_B_MC_INCARN EQ XMT_B_MC_CUR_ECO+1
03F4 976 ASSUME XMT_B_MC_CHG_FLAG EQ XMT_B_MC_INCARN+1
03F4 977 ASSUME XMT_W_MC_MSG_SIZ EQ XMT_B_MC_CHG_FLAG+1
03F4 978 ASSUME XMT_B_MC_SET EQ XMT_W_MC_MSG_SIZ+2
03F4 979 GHB_T_MC_MSG: ; Start of multicast msg fixed data
28 03F4 980 .BYTE MTYP_C_CONF@FLAG y MTYPE ; Message type
08 03F5 981 .BYTE <LATSC_CIR_TIMER+95/10 ; Host preferred Circuit timer
05 03F6 982 .BYTE LATSC_HI_VER ; Highest LAT protocol version supported
05 03F7 983 .BYTE LATSC_LO_VER ; Lowest LAT protocol version supported
05 03F8 984 .BYTE LATSC_CUR_VER ; Current LAT protocol version
00 03F9 985 .BYTE LATSC_CUR_ECO ; Current LAT protocol ECO version
00 03FA 986 .BYTE 0 ; Message incarnation (filled in later)
00 03FB 987 .BYTE 0 ; Change flags (filled in later)
05DC 03FC 988 .WORD LATSC_MAX_MSGSIZ ; Maximum message size
03FE 989
03FE 990 ::
03FE 991 :: Standard Start message (fixed portion) template
03FE 992 ::
03FE 993 ASSUME STRT_W_MSGSIZ EQ 0
03FE 994 ASSUME STRT_B_PVER EQ STRT_W_MSGSIZ+2
03FE 995 ASSUME STRT_B_PECO EQ STRT_B_PVER+1
03FE 996 ASSUME STRT_B_MAXSLOTS EQ STRT_B_PECO+1
03FE 997 ASSUME STRT_B_DL_BFRS EQ STRT_B_MAXSLOTS+1
03FE 998 ASSUME STRT_B_CIR_TIMR EQ STRT_B_DL_BFRS+1
03FE 999 ASSUME STRT_B_KPA_TIMR EQ STRT_B_CIR_TIMR+1
03FE 1000 ASSUME STRT_W_FAC_NUM EQ STRT_B_KPA_TIMR+1
03FE 1001 ASSUME STRT_W_PROD_TYP EQ STRT_W_FAC_NUM+2
00000400 03FE 1002 GHB_W_STRT_LEN: .BLKW 1 ; Length of start message
0400 1003 GHB_T_STRT_MSG: ; Start of start message fixed data
05DC 0400 1004 .WORD LATSC_MAX_MSGSIZ ; Maximum Ethernet frame size
05 0402 1005 .BYTE LATSC_CUR_VER ; Current LAT protocol version
00 0403 1006 .BYTE LATSC_CUR_ECO ; Current LAT ECO version
00 0404 .1 .BYTE 0 ; Maximum number of Slots per circuit
00 0405 1008 .BYTE 0 ; Number of additional buffers (remote)
00000408 0406 1009 .BLKB 2 ; Remote parameters only
0000 0408 1010 .WORD 0 ; Facility number (not yet implemented)
0003 040A 1011 .WORD LATSC_VMS ; Product type code
040C 1012
040C 1013 ASSUME STRT_B_VAR EQ STRT_W_PROD_TYP+2
000004B1 040C 1014 GHB_T_STRT_VAR: .BLKB STRT_C_VAR_LEN ; Variable portion of start message
04B1 1015 ::
04B1 1016 :: Standard Start slot template
04B1 1017 ::
04B1 1018 GHB_T_STRT_SLOT: ; Start of the start slot data
01 04B1 1019 .BYTE SLT_C_SVC_INIT ; Service class
FF 04B2 1020 .BYTE LATSC_MAX_SLOTSIZ ; Attention slot size
FF 04B3 1021 .BYTE LATSC_MAX_SLOTSIZ ; Data slot size
000004B6 04B4 1022 .BLKB 2 ; Null source and destination slot names
00000005 04B6 1023 GHB_C_STRT_SLOTL = <.-GHB_T_STRT_SLOT>

```

:JAY0002
-1

```

04B6 1025      .SBTTL Port Vector
04B6 1026
04B6 1027 :
04B6 1028 : The associated class driver uses this table to command the port driver.
04B6 1029 : The address of this table is contained in the terminal ucb extension area.
04B6 1030 : The offset definitions are defined by ttydefs.
04B6 1031 :
04B6 1032 :
04B6 1033 :
04B6 1034 : LAT specific dispatch table
04B6 1035 :
04B6 1036 : ORDER DEPENDENCY
04B6 1037 : The following symbol must immediately precede the vector
04B6 1038 :
04B6 1039 :
04B6 1040      .ALIGN LONG
04B8 1041 GHB_L_AREA:
000004BC 04B8 1042      .BLKL 1 ; Address of counter vector
04BC 1043 LT$VECTOR:
04BC 1044      $VECINI LT,LT$NULL
04F4 1045      $VEC STARTIO,LT$STARTIO ; Start new output
04C0 1046      $VEC DISCONNECT,LT$DISCONNECT ; Hangup port
04C4 1047      $VEC ABORT,LT$ABORT ; Abort output
04E0 1048      $VEC SET_LINE,LT$FLOW_CHANGE ; Change flow control
04C8 1049      $VEC XON,LT$XON ; Send xon sequence
04D0 1050      $VEC XOFF,LT$XOFF ; Send xoff sequence
04D4 1051 : $VEC DS_SET,LT$DS_SET ; Dataset transitions
04D4 1052      $VECEND
04F8 1053
04F8 1054 LT$NULL: ; Null port routine
05 04F8 1055      RSB

```

```

04F9 1057
04F9 1058 :
04F9 1059 : Stop reasons
04F9 1060 :
04F9 1061
04F9 1062 .MACRO $REASON RSNCD, RSNBIT, RSNSTR, ?L
04F9 1063     .ALIGN WORD
04F9 1064     .SIGNED WORD L-.
04F9 1065     .BYTE RSNCD, RSNBIT
04F9 1066 L:     .ASCIC /RSNSTR/
04F9 1067 .ENDM
04F9 1068
00000001 04F9 1069 LAT_C_CRSN_DONE           = 1           ; No slots in VC
00000002 04F9 1070 LAT_C_CRSN_IVMSG          = 2           ; Invalid message
00000003 04F9 1071 LAT_C_CRSN_IVSCI         = 3           ; Invalid slave conn id
00000004 04F9 1072 LAT_C_CRSN_IVMCI         = 4           ; invalid master conn id
00000005 04F9 1073 LAT_C_CRSN_DISC         = 5           ; Disconnect requested
00000006 04F9 1074 LAT_C_CRSN_PROGRESS      = 6           ; No progress being made
00000007 04F9 1075 LAT_C_CRSN_TMO           = 7           ; Timeout of circuit
00000008 04F9 1076 LAT_C_CRSN_RETRANS        = 8           ; Retransmit count exceeded
00000009 04F9 1077 LAT_C_CRSN_RESOURCE       = 9           ; No resources
0000000A 04F9 1078 LAT_C_CRSN_TIMRANG        = 10          ; Timer value out of range
04F9 1079
04F9 1080
00000000 04F9 1081 LAT_C_RSN_XXX = 0           ; junk
04F9 1082
04F9 1083 LT_RSN_START:
04F9 1084     $REASON -
04F9 1085         GH$V_START,-
04F9 1086         LAT_C_RSN_XXX,-
04F9 1087     <other than start msg with a zero src index>
0529 1088 LT_RSN_CSBZERO:
0529 1089     $REASON -
0529 1090         GH$V_CSBZERO,-
0529 1091         LAT_C_RSN_XXX,-
0529 1092     <circuit index zero>
0541 1093 LT_RSN_CSBRANGE:
0541 1094     $REASON -
0541 1095         GH$V_CSBRANGE,-
0541 1096         LAT_C_RSN_XXX,-
0541 1097     <circuit index out of range>
0561 1098 LT_RSN_CSBINVALID:
0561 1099     $REASON -
0561 1100         GH$V_CSBINVALID,-
0561 1101         LAT_C_RSN_XXX,-
0561 1102     <circuit index invalid>
057C 1103 LT_RSN_CSBSTALE:
057C 1104     $REASON -
057C 1105         GH$V_CSBSTALE,-
057C 1106         LAT_C_RSN_XXX,-
057C 1107     <circuit stale reference>
0598 1108 LT_RSN_HALT:
0598 1109     $REASON -
0598 1110         GH$V_HALT,-
0598 1111         LAT_C_RSN_XXX,-
0598 1112     <circuit forced to halt>
05B3 1113 LT_RSN_INVALIDLOCID:

```

```
05B3 1114 $REASON -
05B3 1115 GHBSV_INVALIDLOCID,-
05B3 1116 LAT_C_RSN_XXX,-
05B3 1117 <invalid local slot id>
05CE 1118 LT_RSN_INVALIDREMID:
05CE 1119 $REASON -
05CE 1120 GHBSV_INVALIDREMID,-
05CE 1121 LAT_C_RSN_XXX,-
05CE 1122 <invalid remote slot id>
05E9 1123 LT_RSN_BADCREDITS:
05E9 1124 $REASON -
05E9 1125 GHBSV_BADCREDITS,-
05E9 1126 LAT_C_RSN_XXX,-
05E9 1127 <bad number of credits in slot>
060C 1128 LT_RSN_REPCREATE:
060C 1129 $REASON -
060C 1130 GHBSV_REPCREATE,-
060C 1131 LAT_C_RSN_XXX,-
060C 1132 <repeat create of slot by server>
0630 1133 LT_RSN_REPDISC:
0630 1134 $REASON -
0630 1135 GHBSV_REPDISC,-
0630 1136 LAT_C_RSN_XXX,-
0630 1137 <repeat disconnect of slot by server>
0658 1138
0658 1139 .ALIGN LONG
0658 1140
```

```

0658 1142      .SBTTL LT$CTRL_INIT - Controller Initialization
0658 1143
0658 1144      .DEFAULT DISPLACEMENT, WORD
0658 1145      :++
0658 1146      : LT$CTRL_INIT - Initialize port driver
0658 1147      :
0658 1148      : Functional description:
0658 1149      :
0658 1150      : This routine is entered at driver load and power recovery.
0658 1151      :
0658 1152      : Inputs:
0658 1153      :
0658 1154      :         R6 = DDB address
0658 1155      :         R8 = CRB address
0658 1156      :
0658 1157      : Outputs:
0658 1158      :
0658 1159      :         R0 through r3 are modified.
0658 1160      :
0658 1161      : Implicit inputs:
0658 1162      :
0658 1163      :         IPL = IPL$_POWER
0658 1164      :
0658 1165      :--
0658 1166      LT$CTRL_INIT:                               ; Initialize controller
0658 1167      :
0658 1168      : Save the address of unit zero for cloning ucbs, if its here now.
0658 1169      :
51   04  A6   D0 0658 1170      MOVL   DDB$_UCB(R6), R1           ; Its in the device data block
FB1D CF   05  13 065C 1171      BEQL   5$                               ; Do not store a zero
065E 1172      MOVL   R1, GHB_L_UCB0           ; Save its address
0663 1173 5$:
0663 1174      MOVL   G^SCH$GL NULLPCB+PCB$_PHD,- ; Get address of NULL PHD
FB20 CF   51  000006C'GF  D0 0669 1175      GHB_L_NULLCPU
FB1B CF   38  FB20 CF   C0 066C 1176      ADDL   #PHD$_CPUTIM,GHB_L_NULLCPU ; Get offset to "idle time"
0671 1177
0671 1178
0671 1179      : Attempt to relocate terminal class vector table in case we are the
0671 1180      : first port driver to load.
0671 1181
0671 1182
0671 1183      MOVL   G^TTY$GL_DPT,R1           ; Get terminal class driver DPT address
0677
0678 1184      MOVZWL DPT$_VECTOR(R1),R0        ; Get offset to class vector
50   51   1E  A1   3C 067C 1185      ADDL3  R0,R1,R0           ; Calculate virtual address
067E 1186 10$:      TSTL   (R0)                ; Already relocated or done?
0680 1187      BLEQ   20$                ; Br if yes
0682 1188      ADDL   R1,(R0)+           ; Else, add bias
0684 1189      BRB    10$                ; Loop till done
0687 1190
0689 1191      : Relocate port vector table
0689 1192
0689 1193 20$:
51   0000'CF  DE 0689 1194      MOVAL  LT$_DPT,R1           ; Get our DPT address
50   FE2A CF  DE 068E 1195      MOVAL  LT$_VECTOR,R0       ; Get address of our dispatch vector
0693 1196 30$:      TSTL   (R0)                ; Already relocated or done?
0693 1197

```

```

      05 15 0695 1198
      80 51 C0 0697 1199
      F7 11 069A 1200
          069C 1201 40$:
      075D CF 9E 069C 1202
      FA8D CF          06A0 1203
      0835 CF 9E 06A3 1204
      FA82 CF          06A7 1205
      0965 CF 9E 06AA 1206
      FA73 CF          06AE 1207
      FA6B CF 9E 06B1 1208
      FE00 CF          06B5 1209
      00000000 GF 90 06B8 1210
      FAD8 CF          06BE 1211
          06C1 1212
      FAD9 CF 9E 06C1 1213
      FA74 CF          06C5 1214
          06C8 1215
          06C8 1216
          06C8 1217
      00050004 8F D0 06C8 1218
      FA4F CF          06CE
          06D1 1219
          06D1 1220
          06D1 1221
          0A 90 06D1 1222
      FAC4 CF          06D3 1223
      F95E CF 9E 06D6 1224
      FA63 CF          06DA 1225
      50 FA63 CF 9E 06DD 1226
          60 D5 06E2 1227
          07 12 06E4 1228
          60 50 D0 06E6 1229
      04 A0 50 D0 06E9 1230
          06ED 1231
          06ED 1232 50$:
          06ED .1
          06ED .2
      00000000 GF 9A 06ED .3
          50 50 06F3
          50 10 91 06F4 .4
          08 1E 06F7 .5
          40 8F 90 06F9 .6
      FA0D CF          06FC
          06FF .7
          08 11 06FF .8
      FA07 CF 40 90 0701 .9 55$:
      FA03 CF          0706
          0709 .10
          0709 .11
          0709 .12
          0709 .13
      00000000 GF D0 0709 .14 60$:
          50 070F
      00002000 8F C6 0710 1236
          50 0716
      50 08 50 C3 0717 1237
  
```

```

BLEQ 40$ ; Br if yes, powerfail
ADDL R1,(R0)+ ; Else, add bias
BRB 30$ ; Loop til done

MOVAB LT$STRETRY,- ; Set address of start entry point
      GHB$L_STRETRY+GHB_AREA ;
MOVAB LT$SHUTENTRY,- ; Set address shutdown entry point
      GHB$L_SHUTENTRY+GHB_AREA ;
MOVAB LT$SETENTRY,- ; Set address of multicast set entry
      GHB$L_SETEENTRY+GHB_AREA ;
MOVAB GHB_AREA,- ; Save address of the common area
      GHB_L_AREA ; so we can find them from LATCP
MOVB G^EXE$GQ SYSTIME,- ; Get a random number
      GHB_B_INCARN ; and save for the message seed value

MOVAB GHB_T_MC_DATA,- ; Address of multicast data area
      GHB$L_NODE+GHB_AREA

ASSUME GHB$B_LATVERSION EQ GHB$W_VMSVERSION+2
ASSUME GHB$B_LATECO EQ GHB$B_LATVERSION+1
MOVL #<<LAT$C_CUR_ECO>>@8! - ; Store current ECO

      LAT$C_CUR_VER>@16! - ; and VERSION
      LAT$C_VMS_VER, - ; and VMS VERSION
      GHB$W_VMSVERSION+GHB_AREA
MOVAB #LAT$C_KEEP_CSB,- ; Set number of CSBs to keep around
      GHB_B_OLD_CSBCNT
MOVAB GHB_L_CSBTABLE,- ; Store address of CSB table
      GHB$L_CSBLST+GHB_AREA
MOVAB GHB$Q_OLD_CSBS+GHB_AREA,R0 ; Get address of old CSB entries
TSTL (R0) ; Already initialized?
BNEQ 50$ ; Br if yes, skip next section
MOVL R0,(R0) ; Initialize listhead
MOVL R0,4(R0) ; ...

; Set up the maximum circuit session limit value for this processor
MOVZBL G^EXE$GB_CPUTYPE,R0 ; Get CPU type code

CMPB #MAX_PR_SID,R0 ; Within range?
BGEQU 55$ ; Branch if so
MOVAB #LAT$C_MAX_SLOTS,- ; Else load default maximum
      W^GHB_B_MAX_SLOTS
BRB 60$ ; And branch
MOVAB GHB_T_MAX_SLOT_TABLE[R0],- ; Load maximum session count
      W^GHB_B_MAX_SLOTS

; Setup the initial rating value, based on memory size
MOVL G^MMG$GL_MAXPFN,R0 ; Get the max PFN count
DIVL #8192,R0 ; Weight by 4MB chunks
SUBL3 R0,#8,R0 ; Compute for up to 32 MB systems
  
```

```

:JAY0002
:JAY0002
:JAY0002
:JAY0002
:JAY0002
:JAY0002
:JAY0002
:JAY0002
:JAY0002
:JAY0002
:JAY0002
:JAY0002
:JAY0002
:JAY0002
:JAY0002
  
```

```
02 18 071B 1238 BGEQ 70$ ; Br if result okay
50 D4 071D 1239 CLRL R0 ; Else, more than 32 MB - impressive!
FF 8F 50 83 071F 1240 70$: SUBB3 R0,#255,GHB_B_RATE ; Store initial rating
FA75 CF 0723
05 0726 1241 RSB
0727 1242
0727 1243 .IF DEFINED LT_HISTORY
```



```

0727 1245      .SBTTL  LT$HISTORY - Save history in the buffer
0727 1246      :++
0727 1247      : LT$HISTORY - Save history in the buffer
0727 1248      :
0727 1249      :   Save history on transmits and receives.
0727 1250      :   The history buffer is defined as follows:
0727 1251      :
0727 1252      :
0727 1253      :   +-----+
0727 1254      :   | Pointer to next slot |
0727 1255      :   | Pointer to end of buffer |
0727 1256      :   | spare!type! buffer size |
0727 1257      :   |
0727 1258      :   | ... data ... |
0727 1259      :   +-----+
0727 1260      :
0727 1261      :
0727 1262      :
0727 1263      :
0727 1264      : Inputs:
0727 1265      :   R0 -> data to save
0727 1266      :
0727 1267      : Outputs:
0727 1268      :   R1 is clobbered
0727 1269      :--
0727 1270      :
00000020 0727 1271      SLOT_SIZE = 32                ; Size of each history slot
0727 1272      :
0727 1273      LT$HISTORY:
51  F9FD CF  D0 0727 1274      MOVL  GHBSL_HISTORY+GHB_AREA,R1 ; Point to history buffer
      2E  13 0727 1275      BEQL  90$                ; Br if none
      50  DD 0727 1276      :
      20  C1 0727 1277      PUSHL R0                ; Save R0
      50  61 0730 1278      ADDL3 #SLOT_SIZE,-          ; Compute end address for this slot
04  A1  50  D1 0732 1279      HBF [NEXT(R1),R0
      04  1B 0734 1280      Cmpl  R0,HBF_L_BUFEND(R1) ; Are we past the end?
      OC  A1  9E 0738 1281      BLEQU 30$                ; Br if no, continue
      61  61 073A 1282      MOVAB HBF_Z_DATA(R1),- ; Else, back to beginning
      51  61  D0 073D 1283      HBF_L_NEXT(R1)
00000000'GF 7D 073E 1284 30$: MOVL  HBF_L_NEXT(R1),R1 ; Get address of next available slot
      81  81 0741 1285      MOVQ  G^EXE$GQ_SYSTIME,(R1)+ ; Store time in first quadword
      50  6E  D0 0747      :
      81  80  7D 0748 1286      MOVL  (SP),R0                ; Get back buffer address
      81  80  7D 074B 1287      MOVQ  (R0)+, (R1)+          ; Save the data
      81  80  7D 074E 1288      MOVQ  (R0)+, (R1)+          ; Save the data
      81  80  7D 0751 1289      MOVQ  (R0)+, (R1)+          ; Save the data
      F9CF DF  51  D0 0754 1290      ASSUME HBF_L_NEXT EQ 0
      50  8ED0 0754 1291      MOVL  R1,GHBSL_HISTORY+GHB_AREA ; Save address of next slot
      05  0759 1292      POPL  R0                ; Restore R0
      075C 1293      :
      075C 1294 90$: RSB
      075D 1295      .ENDC  ;; DEFINED LT_HISTORY
    
```

```

075D 1297      .SBTTL LT$STRETRY - Entry to start driver
075D 1298      :++
075D 1299      : LT$STRETRY - Start LTDRIVER entry point
075D 1300      :
075D 1301      : Functional description:
075D 1302      :
075D 1303      :     This entry is called by the startup program to initialize the
075D 1304      :     driver. Here we save the datalink UCB address, allocate the CSB's
075D 1305      :     and start the first receive.
075D 1306      :
075D 1307      : Inputs:
075D 1308      :     R5 = UCB address of datalink
075D 1309      :
075D 1310      : Implicit inputs:
075D 1311      :
075D 1312      :     Called in user context.
075D 1313      :
075D 1314      : Outputs:
075D 1315      :     R0 = success or failure
075D 1316      :--
075D 1317
075D 1318
075D 1319      LT$STRETRY:
075D 1320      DSBINT #LAT$C_IPL          ; Raise IPL to prevent interruption
F9CC CF 55 D0 0763 1321      MOVL R5,GHB$L_UCB+GHB_AREA    ; Save the datalink UCB address
0768 1322
59 F8CC CF 9E 0768 1323      MOVAB GHB_L_CSBTABLE,R9      ; Get CSB table base address
   SA 20 9A 076D 1324      MOVZBL #LAT$C_MAX_CSBS,R10  ; Get table length in longwords
   FB 89 D4 0770 1325      CLRL (R9)+                ; Zero the whole table
   FB 5A F5 0772 1326      SOBGTR R10,20$          ; Do whole table
0775 1327
0775 1328      ; Save the last CPU idle value
0775 1329
   FA13 DF D0 0775 1330      MOVL @GHB_L_NULLCPU,-      ; Save last idle value
   FA14 CF 0779 1331      GHB_L_LASTCPU
00000000'GF D0 077C 1332      MOVL G^EXE$GL_MP,R0      ; Get ptr to MP code
   50
   07 13 0783 1333      BEQL 40$                ; Br if not there
   0000'CO D0 0785 1334      MOVL MP$SGL_NULLCPU(R0),- ; Else, get Secondary null time
   FA08 CF 0789 1335      GHB_L_NULLSEC
078C 1336      40$:
078C 1337      ; See if the datalink supports the fast interface and if so
078C 1338      ; then allocate an FFI block and initialize that interface.
078C 1339
   51 24 A5 D4 078C 1340      CLRL R0                  ; Assume error
   51 40 A1 D0 078E 1341      MOVL UCBSL_CRB(R5), R1    ; Get address of datalink's CRB
   36 13 0792 1342      MOVL CRBSL_INTD+VECSL_START(R1), R1 ; Get address of FFI INIT routine
   0045 30 0796 1343      BEQL 70$                ; Br if not present
   30 50 E9 0798 1344      BSBW LT$GETFFI          ; Else, create and initialize FFI
F9E5 CF 54 D0 079B 1345      BLBC R0,70$             ; Br if error
   079E 1346      MOVL R4,GHB_L_FFI          ; Else, save FFI block address
   07A3 1347
   07A3 1348      CLRBIT #GHB_STS_V_MULTI,- ; Clear the multicast busy flag
   07A3 1349      GHB_B_STATUS
   FC43 CF D4 07A9 1350      CLRL GHB_C_MULTIBFR     ; No multicast buffer is possible
   01B5 30 07AD 1351      BSBW LT$SETENTRY       ; Setup multicast message
07B0 1352

```

50	F9CC CF	D0	07B0	1353		MOVL	GHB_L_UCB0, R0	:	Set unit seed in the ucb
	17	13	07B5	1354		BEQL	70\$:	No ucb0, bad news
	60	B4	07B7	1355		CLRW	UCB\$W_MB_SEED(R0)	:	Start with unit 1
	105C	30	07B9	1356		BSBW	LT\$SET_TIMER	:	Start timer, so we always have a tick
			07BC	1357					
55	F974 CF	D0	07BC	1358		MOVL	GHB\$L_UCB+GHB_AREA, R5	:	Get datalink UCB address
	5C A5	B6	07C1	1359		INCW	UCB\$W_REF(CR5)	:	One more ref to keep it around for us
	8000 8F	A8	07C4	1360		BISW	#^x8000,UCB\$W_DEVSTS(R5)	:	Allow unit to be re-started
	68 A5		07C8						
			07CA	1361					automatically by datalink
50	00'8F	9A	07CA	1362		MOVZBL	#SS\$ NORMAL, R0	:	Return success
	0B 50	E8	07CE	1363	70\$:	BLBS	R0, 80\$:	Br if okay
	F95F CF	D4	07D1	1364		CLRL	GHB\$L_UCB+GHB_AREA	:	Else, forget about datalink UCB
	5E	10	07D5	1365		BSBB	LT\$SH0TENTRY	:	Clean it all up
50	0000'8F	3C	07D7	1366		MOVZWL	#SS\$_INSFMEM, R0	:	Return not enough memory
			07DC	1367	80\$:	ENBINT		:	Restore IPL
		05	07DF	1368		RSB			
			07E0	1369					

```

07E0 1371      .SBTTL  LT$GETFFI - Get the FFI block and initialize FFI interface
07E0 1372      :++
07E0 1373      : LT$GETFFI - Get FFI block
07E0 1374      :
07E0 1375      : Functional description:
07E0 1376      :
07E0 1377      :     Initialize the FFI interface.
07E0 1378      :
07E0 1379      : Inputs:
07E0 1380      :
07E0 1381      :     R1 = Address of FFI INIT routine in datalink driver
07E0 1382      :     R5 = UCB address of datalink
07E0 1383      :
07E0 1384      : Outputs:
07E0 1385      :
07E0 1386      :     R0 = Status
07E0 1387      :     R1-R4 are destroyed.
07E0 1388      :
07E0 1389      :--
07E0 1390
07E0 1391  LT$GETFFI:
51      51      DD 07E0 1392      PUSHL   R1                ; Save init routine address
3E      3E      9A 07E2 1393      MOVZBL  #FFISC_LENGTH,R1    ; Set length of buffer to allocate
00000000 GF 16 07E5 1394      JSB     G^EXES$ALONONPAGED ; Try to allocate an FFI block
31      50      E9 07EB 1395      BLBC    R0,30$             ; Br if error
54      52      D0 07EE 1396      MOVL    R2,R4              ; Copy FFI block address
07F1 1397      ASSUME  FFISL_FL EQ 0
07F1 1398      ASSUME  FFISL_BL EQ FFISL_FL+4
07F1 1399      ASSUME  FFISW_SIZE EQ FFISL_BL+4
07F1 1400      ASSUME  FFISB_TYPE EQ FFISW_SIZE+2
07F1 1401      ASSUME  FFISB_SPARE EQ FFISB_TYPE+1
001.7^03E 82 7C 07F1 1402      CLRQ    (R2)+               ; Clear link pointers
8F      8F      D0 07F3 1403      MOVL    #<DYN$C_BUFIO@16>!FFISC_LENGTH,(R2)+ ; Store block size & type
82
07F9
07FA 1404      ASSUME  FFISL_CTX_DL EQ FFISB_SPARE+1
07FA 1405      ASSUME  FFISL_XMIT EQ FFISL_CTX_DL+4
07FA 1406      ASSUME  FFISL_XMIT_DONE EQ FFISC_XMIT+4
07FA 1407      ASSUME  FFISL_RECV_DONE EQ FFISL_XMIT_DONE+4
07FA 1408      ASSUME  FFISL_ERROR EQ FFISL_RECV_DONE+4
07FA 1409      ASSUME  FFISL_SHUT_DONE EQ FFISL_ERROR+4
82      82      7C 07FA 1410      CLRQ    (R2)+               ; Zero CTX & XMIT routine address
82      1B54 CF 9E 07FC 1411      MOVAB   W^LT$XMT_FFIDONE,(R2)+ ; Store XMIT Complete routine address
82      0D1C CF 9E 0801 1412      MOVAB   W^LT$FFI_RCV_MSG,(R2)+ ; Store RECV Complete routine address
82      0964 CF 9E 0806 1413      MOVAB   W^LT$ASYNCERR,(R2)+    ; Store address of ERROR handler
82      0953 CF 9E 080B 1414      MOVAB   W^LT$SHUT_DONE,(R2)+   ; Store address of SHUTDOWN handler
0810 1415      ASSUME  FFISL_SPARE0 EQ FFISL_SHUT_DONE+4
0810 1416      ASSUME  FFISL_SPARE1 EQ FFISL_SPARE0+4
0810 1417      ASSUME  FFISL_SPARE2 EQ FFISL_SPARE1+4
0810 1418      ASSUME  FFISL_SPARE3 EQ FFISL_SPARE2+4
82      82      7C 0810 1419      CLRQ    (R2)+               ; Not used
82      7C      7C 0812 1420      CLRQ    (R2)+
0814 1421      ASSUME  FFISL_DL_UCB EQ FFISL_SPARE3+4
0814 1422      ASSUME  FFISL_PID EQ FFISL_DL_UCB+4
0814 1423      ASSUME  FFISW_CHAN EQ FFISC_PID+4
82      55      D0 0814 1424      MOVL    R5,(R2)+           ; Store datalink UCB address
82      82      D4 0817 1425      CLRL    (R2)+               ; Zero PID
82      82      B4 0819 1426      CLRW    (R2)+               ; Zero CHAN
    
```

50	00'8F	9A	081B	1427	MOVZBL	#SS\$ _NORMAL,R0	:	Return success
	51	8ED0	081F	1428	POPL	R1	:	Restore R1
	OF	50	E9	0822	BLBC	R0,90\$:	Br if allocation error
		53	D4	0825	CLRL	R3	:	No parameters
		61	16	0827	JSB	(R1)	:	Else, call datalink init routine
	08	50	E8	0829	BLBS	R0,90\$:	Br if success
50		54	D0	082C	MOVL	R4,R0	:	Else, copy FFI block address
	13A7	30	082F	1434	BSBW	LT\$DEALPOOL	:	Deallocate the FFI block
		50	D4	0832	CLRL	R0	:	Return failure
		05	0834	1436	RSB		:	

```

0835 1438 .SBTTL LTSSHUTENTRY - Shutdown entry point
0835 1439 :++
0835 1440 : LTSSHUTENTRY - Shutdown LTDRIVER entry point
0835 1441 :
0835 1442 : Functional description:
0835 1443 :
0835 1444 :     Shutdown things when we are done.
0835 1445 :
0835 1446 : Inputs:
0835 1447 :     none
0835 1448 :
0835 1449 : Implicit inputs:
0835 1450 :
0835 1451 :     Called in user context.
0835 1452 :
0835 1453 : Outputs:
0835 1454 :     none
0835 1455 :--
0835 1456
0835 1457 LTSSHUTENTRY:
0835 1458     DSBINT #LAT$C IPL ; Sync with rest of things
0838 1459     SETBIT #GHB_STS_V_SHUT,- ; Indicate that shutdown has been
0838 1460             GHB_B_STATUS ; requested
0841 1461 :
0841 1462 :
0841 1463 :     Deallocate and shut down all the circuits
0841 1464 :
59  F7F3 CF DE 0841 1465     MOVAL GHB_L_CSBTABLE, R9 ; Table of CSB addresses
    5A 20 9A 0846 1466     MOVZBL #LAT$C_MAX_CSBS, R10 ; and its length
    58 89 D0 0849 1467 40$: MOVL (R9)+, R8 ; Get a CSB address
    03 13 084C 1468     BEQL 60$ ; No CSB address here
    OED9 30 084E 1469     BSBW LT$CIRCDEAD ; Kill all processes on this one
    F5 5A F5 0851 1470 60$: SOBGTR R10, 40$ ; Til end of table
0854 1471 :
0854 1472 :
0854 1473 :     We can reduce our interest in the datalink UCB here early because
0854 1474 :     the LAT control program still has a channel to the UCB and is still
0854 1475 :     active. The UCB will disappear when the LATCP deassigns its last
0854 1476 :     channel to it.
0854 1477 :
0854 1478 :
59  F8DC CF D0 0854 1479     MOVL GHB$L_UCB+GHB_AREA, R9 ; Get datalink UCB and reduce our interest
    19 13 0859 1480     BEQL 80$ ; No ucb here
    8000 8F AA 085B 1481     BICW #^x8000,UCB$W_DEVSTS(R9); Don't want datalink to re-start
    68 A9 085F 1482 :
    5C A9 B7 0861 1483 :     any more!
    F8CC CF D4 0861 1483     DECW UCBSW_REFC(R9) ; Let datalink UCB go away.
    0864 1484     CLRL GHB$L_UCB+GHB_AREA ; Forget we ever had it
    0868 1485 : ; This prevents more circuits from
    0868 1486 : ; being accepted.
    0868 1487 :
    0868 1488 :     Wait for any datalink re-start timer to expire. Spin on
    0868 1489 :     the INTERLOCK bit.
    0868 1490 :
    0868 1491     SETIPL #IPL$ASTDEL ; Prevent us from being deleted,
    0868 1492 : ; but allow scheduling activity
04 68 A9 OE E1 086B 1493 70$: BBC #14,UCB$W_DEVSTS(R9),80$ ; Proceed if UCB can evaporate

```

```

70 10 0870 1494 BSBB BUILD_TQE ; Wait around for a while
F7 11 0872 1495 BRB 70$ ; Try again
    0874 1496
    0874 1497 80$:
    0874 1498
    0874 1499
    0874 1500
    0874 1501
    0874 1502
    0874 1503
    0874 1504
    0874 1505
    0877 1506
    02 11 0877 1507 BRB 110$ ; Prevent us from being deleted,
    0879 1508 ; but allow scheduling activity
    0879 1509 ; See if CSB's are all gone
    0879 1510 ; Now delay while we wait for CSB's to run down
    67 10 0879 1511 100$: BSBB BUILD_TQE ; Build TQE to wait on and wait
59 F7B9 CF DE 087B 1512 110$: MOVAL GHB_L_CSBTABLE,R9 ; Table of CSB addresses
    5A 20 9A 0880 1514 MOVZBL #LATSC_MAX_CSBS, R10 ; and its length
    58 89 D0 0883 1515 120$: MOVL (R9)+, R8 ; Get a CSB address
    F1 12 0886 1516 BNEQ 100$ ; Just spin here looking
    F8 5A F5 0888 1517 SOBGTR R10, 120$ ; Til end of table
    088B 1518
    088B 1519 ; Now wait for all the UCBs to dissappear except unit 0
    088B 1520
    02 11 088B 1521 BRB 160$ ; Check if we're all done
    088D 1522
    53 10 088D 1523 140$: BSBB BUILD_TQE ; Build TQE to wait on and wait
    088F 1524
    088F 1525 ; Now delay while we wait for terminal UCB's to run down
    088F 1526
50 F8ED CF D0 088F 1527 160$: MOVL GHB_L_UCB0,R0 ; Get the LT UCB address
    OA 13 0894 1528 BEQL 180$ ; ???
51 24 A0 D0 0896 1529 MOVL UCBSL_CRB(R0),R1 ; Get the CRB address
01 0C A1 B1 089A 1530 CMPW CRB$W_REFC(R1),#1 ; All done ?
    ED 12 089E 1531 BNEQ 140$ ; Br if no
    08A0 1532 180$:
    08A0 1533 ; Reset completion routines for datalink's FFI interface
    08A0 1534
    08A0 1535
55 F8E1 CF D0 08A3 1536 SETIPL #LATSC IPL ; Sync access to rest of driver
    0C 13 08A8 1537 MOVL GHB_L_FFI, R5 ; Get FFI block address
    1BD8 CF 9E 08AA 1538 BEQL 200$ ; Br if none
    18 A5 08AE 1539 MOVAB W^LTS$DROPCTXB,- ; Drop all RECEIVE buffers
    1BCF CF 9E 08B0 1540 MOVAB W^LTS$FFIPOSTDONE,- ; Deallocate all TRANSMIT CXBs
    14 A5 08B4 1541 FFISL_XMIT_DONE(R5)
    08B6 1542 200$:
    08B6 1543 ; Deallocate the multicast buffer
    08B6 1544
50 FB36 CF D0 08B6 1545 MOVL GHB_L_MULTIBFR,R0 ; Get the multicast buffer
    08 13 08BB 1546 BEQL 220$ ; Br if none
    08BD 1547 ASSUME GHB_STS_V_MULTI EQ 0
03 F8D7 CF E8 08BD 1548 BLBS GHB_B_STATUS,220$ ; Br if multicast buffer is active
    1314 30 08C2 1549 BSBW LT$DEALPOOL ; Else, deallocate the multicast buffer
    FB27 CF D4 08C5 1550 220$: CLRL GHB_L_MULTIBFR ; Forget we had a multicast buffer

```

```

08C9 1551
08C9 1552
08C9 1553
50 F877 DF 0F 08C9 1554 240$: REMQUE @GHB$Q_OLD_CSBS+GHB_AREA,R0 ; Get CSB address
      05 1D 08CE 1555 BVS 300$ ; Br if none
      1306 30 08D0 1556 BSBw LT$DEALPOOL ; Else, deallocate the CSB
      F4 11 08D3 1557 BRB 240$ ; Loop til done
      OA 90 08D5 1558 300$: MOVb #LAT$C_KEEP_CSBS,- ; Reset number of CSBs to keep around
      F8C0 CF 08D7 1559 GHB_B_OLD_CSBCNT
      08DA 1560
      08DA 1561 ; Mark LTDRIVER as inactive
      08DA 1562
      F8BA CF 94 08DA 1563 CLRb GHB_B_STATUS ; Clear ACTIVE flag to stop timer
      08DE 1564 ; clear SHUTdown flag
      08DE 1565 ; clear MULTicast buffer flag
      08DE 1566
      05 08E1 1567 ENBINT
      08E2 1568 RSB

```



```

08E2 1570      .SBTTL TQE TIMER BUILDING AND WAITING ROUTINES
08E2 1571      :++
08E2 1572      : BUILD_TQE - Build a TQE
08E2 1573      :
08E2 1574      : Inputs:
08E2 1575      :     IPL = ASTDEL
08E2 1576      :
08E2 1577      : Implicit inputs:
08E2 1578      :     Called in user context
08E2 1579      :
08E2 1580      :
08E2 1581      : Outputs:
08E2 1582      :     R0-R5 are destroyed
08E2 1583      :--
08E2 1584      :
08E2 1585      BUILD_TQE:
00000000'GF 16 08E2 1586      JSB      G^EXESALLOCTQE      ; Allocate a TQE (returns IPL = ASTDEL)
                   4A 50 E9 08E8 1587      BLBC      RO,90$      ; Br if allocation failure
0B A2 01 90 08EB 1588      MOVB      #TQESC_SSSNGL,TQESB_RQTYPE(R2) ; Indicate single shot request
OC A2 36'AF 9E 08EF 1589      MOVAB     B^SHUT_TIMER,TQESL_FPC(R2) ; Set wake up routine address
                   7E DC 08F4 1590      MOVPSL   -(SP)      ; Push current PSL to resume process
08F6 1591      ASSUME     IPL$ SYNCH EQ IPL$_TIMER
08F6 1592      SETIPL   #IPL$ SYNCH      ; Sync access to system data base
00000000'GF 7D 08F9 1593      MOVQ      G^EXESGQ_SYSTIME,R0      ; Get current time
                   50
004C4B40 8F C0 0900 1594      ADDL      #LAT$C_SHUTDELAY,R0      ; Calculate expiration time
                   50
                   51 00 D8 0907 1595      ADWC      #0,R1      ; Add carry to top half
                   55 52 D0 090A 1596      MOVL      R2,R5      ; Copy TQE address
00000000'GF 16 090D 1597      JSB      G^EXESINSTIMQ      ; Insert TQE on timer queue
                   08 11 0913 1598      CLRBIT   #GHB_STS_V TQE,-      ; Indicate TQE not complete - yet
                   03 E0 0913 1599      GHB_B_STATUS
                   03 E0 0919 1600      BRB      60$      ; Wait for TQE
14 F878 CF E0 0918 1601 40$: BBS      #GHB_STS_V TQE,-      ; Br if TQE is complete
                   7E DC 091D 1602      GHB_B_STATUS,90$
00000000'GF 7E DC 0921 1603      MOVPSL   -(SP)      ; Push current PSL to resume process
                   54 D0 0923 1604 60$: MOVL      G^SCH$GL_CURPCB,R4      ; Get current PCB address
                   50 01 9A 092A 1605      MOVZBL   #RSNS_ASTWAIT,R0      ; Set waiting resource
00000000'GF 16 092D 1606      JSB      G^SCH$RWAIT      ; Make process wait for resource
                   E6 11 0933 1607      BRB      40$      ; Check if TQE expired
                   05 0935 1608 90$: RSB      ; Return to caller
0936 1609
0936 1610      :++
0936 1611      : SHUT_TIMER
0936 1612      :
0936 1613      : This routine wakes up the waiting process
0936 1614      :
0936 1615      : Inputs:
0936 1616      :     R4 = PCB address
0936 1617      :     R5 = TQE address
0936 1618      :
0936 1619      :     IPL = IPL$_TIMER
0936 1620      :
0936 1621      : Outputs:
0936 1622      :     R0 is destroyed
0936 1623      :     R5 = TQE address of system non-repeating TQE

```

```
0936 1624 :--  
0936 1625  
0936 1626 SHUT_TIMER:  
0936 1627 SETBIT #GHB_STS V TQE,- ; Indicate TQE has completed  
0936 1628 GHB-B STATUS  
50 01 9A 093C 1629 MOVZBL #RSNS_A$TWAIT,R0 ; Set waiting resource  
00000000'GF 16 093F 1630 JSB G^SCH$RAVAIL ; Mark resource available  
50 55 D0 0945 1631 MOVL R5,R0 ; Copy TQE address  
128E 30 0948 1632 BSBW LT$DEALPOOL ; Deallocate the TQE  
00000000'GF DE 094B 1633 MOVAL G^EXE$AL_TQENOREPT,R5 ; Setup SYSTEM no repeat TQE address  
55 0951  
05 0952 1634 RSB ; Return to caller
```



```
0964 1660 .SBTTL LTSASYNCERR - Process async errors from datalink
0964 1661 :++
0964 1662 : LTSASYNCERR - Process async errors from datalink
0964 1663 :
0964 1664 : Functional description:
0964 1665 :
0964 1666 : Do Nothing.
0964 1667 :
0964 1668 :--
05 0964 1669 LTSASYNCERR:
0964 1670 RSB
```

```

0965 1672 .SBTTL LT$SETENTRY - Set a new multicast message
0965 1673 :++
0965 1674 : LT$SETENTRY - Set new multicast message
0965 1675 :
0965 1676 : Functional description:
0965 1677 :
0965 1678 : Take the data from the multicast data area and store it in a new message
0965 1679 : or bump the incarnation so we know to do it next time.
0965 1680 :
0965 1681 : Inputs:
0965 1682 :     None.
0965 1683 :
0965 1684 : Outputs:
0965 1685 :     R0 = success or failure
0965 1686 :     All other registers are preserved.
0965 1687 :
0965 1688 : Implicit outputs:
0965 1689 :     Multicast timer set to 1 second interval.
0965 1690 :
0965 1691 :--
0965 1692 :
0965 1693 LT$SETENTRY:
0965 1694 DSBINT #LAT$C_IPL
007E 8F BB 096B 1695 PUSHR #^M<R1,R2,R3,R4,R5,R6> : Save registers
52 FA7B CF D4 096F 1696 CLRL R6 : Assume no old CXB change flags
1A 13 0971 1697 MOVL GHB_L_MULTIBFR, R2 : Get the Multicast CXB
F81D CF 96 0976 1698 BEQL 10$ : Br if none, go make one
03 F818 CF E9 0978 1699 INCB GHB_B_INCARN : Bump the incarnation count
0099 31 097C 1700 ASSUME GHB_STS_V_MULTI EQ 0
097C 1701 BLBC GHB_B_STATUS, 5$ : Br if multicast buffer is free
0981 1702 BRW 70$ : Else, do this operation later
0984 1703 :
0984 1704 : Multicast buffer is available, deallocate it!
0984 1705 :
56 4F A2 90 0984 1706 5$: MOVB XMT_B_MC_CHG_FLAG(R2),R6: Save previous change flags
50 52 D0 0988 1707 MOVL R2,-R0 : Deallocate the old CXB buffer
FA61 CF D4 098B 1708 CLRL GHB_L_MULTIBFR : NO more mutlicast CXB buffer
1247 30 098F 1709 BSBW LT$DEALPOOL : Dump the buffer
0992 1710 :
51 F806 CF 3C 0992 1711 10$: MOVZWL GHB_W_MC_SIZE, R1 : Get size of data set by LATCP
00000052 8F C0 0997 1712 ADDL #XMT_B_MC_SET, R1 : plus message overhead
099D 1713 :
00000000 GF 16 099E 1713 JSB G^EXESALONONPAGED : Now get the buffer
7B 50 E9 09A4 1714 BLBC R0, 80$ : No pool for buffer
08 A2 51 B0 09A7 1715 MOVW R1, CXBSW_SIZE(R2) : Size of buffer
09AB 1716 ASSUME CXBSB_CODE EQ CXBSB_TYPE+1
011B 8F B0 09AB 1717 MOVW #<1085!DYN$C_CXB,- : Set type and indicate multicast
0A A2 B0 09AF 1718 CXBSB_TYPE(R2) : buffer
0048 8F B0 09B1 1719 MOVW #XMT_T_DATA,CXBSW_BOFF(R2) : Set offset to start of data
18 A2 :
FA34 CF 52 D0 09B7 1720 MOVL R2, GHB_L_MULTIBFR : Save address of the buffer
09BC 1721 :
09BC 1722 : Copy fixed portion of multicast message
09BC 1723 :
51 FA34 CF 9E 09BC 1724 MOVAB GHB_T_MC_MSG,R1 : Point to msg template
61 0A 28 09C1 1725 MOVCS #XMT_C_MC_LENGTH,(R1),- : Copy the fixed portion of message
48 A2 09C4 1726 XMT_T_DATA(R2)
    
```

```

    09C6 1727
    09C6 1728
    09C6 1729
51  F7D4 CF 9E 09C6 1730
61  F7CD CF 28 09CB 1731
    09D0
    09D1 1732
    09D1 1733
    09D1 1734
52  FA1B CF D0 09D1 1735
56  FF 8F 8D 09D6 1736
    09DA
    09DC 1737
    09DC 1738
    09E0 1739
50  4E A2 9E 09E2 1740
    48 A2 C2 09E6 1741
    53 50 B0 09E9 1742
1A  A2 53 B0 09ED 1743
    09ED 1744
    09ED 1745
51  F7AF CF 9E 09ED 1746
53  FA16 CF 9E 09F2 1747
    56 53 D0 09F7 1748
    50 81 9A 09FA 1749
    51 50 C0 09FD 1750
    50 61 9B 0A00 1751
    50 B6 0A03 1752
63  61 50 28 0A05 1753
    50 61 9B 0A09 1754
    50 B6 0A0C 1755
63  61 50 28 0A0E 1756
    83 B4 0A12 1757
    53 56 C2 0A14 1758
    53 0C A1 0A17 1759
    F9E1 CF 0A1A
    0A1D 1760
50  0000'8F 3C 0A1D 1761 70$:
F9C7 CF 01 B0 0A22 1762 80$:
    007E 8F BA 0A27 1763 90$:
    0A2B 1764
    0A2E 1765
    0A2F 1766

: Copy the variable data set by LATCP
MOVAB GHB_T_MC_DATA,R1 ; Get address of variable data
MOVCS GHB_W_MC_SIZE,(R1),(R3) ; Copy the variable data

: Set change flags, and incarnation number
MOVL GHB_L_MULTIBFR,R2 ; Get back the multicast buffer
XORB3 #XMT_CHFLG_M_ALL,R6,- ; Set change flags

XMT_B_MC_CHG_FLAG(R2)
MOVAB GHB_B_INCARN, ; Set incarnation number
XMT_B_MC_INCARN(R2)
MOVAB XMT_T_DATA(R2), R0 ; Address of start of data
SUBL R0,-R3 ; Calculate the length
MOVW R3, CXBSW_BCNT(R2) ; Set length of message

: Copy the node name and descriptor for the START message
MOVAB GHB_T_MC_DATA+2,R1 ; Get address of multicast variable data
MOVAB GHB_T_START_VAR,R3 ; Get address of start msg variable data
MOVL R3,-R6 ; Save address of start of variable data
MOVZBL (R1)+, R0 ; Get size of group codes
ADDL R0, R1 ; Calculate address of node name
MOVZBW (R1), R0 ; Get size of node name
INCW R0 ; Include the byte count
MOVCS R0,(R1),(R3) ; Copy the node name
MOVZBW (R1), R0 ; Get size of node descriptor
INCW R0 ; Include the byte count
MOVCS R0,(R1),(R3) ; Copy the node descriptor
CLRW (R3)+ ; No location text, no parameters
SUBL R6, R3 ; Calculate length of start message
ADDW3 #STRT_C_LENGTH, R3, - ; Store length in holding cell

GHB_W_STRT_LEN
MOVZWL #SSS-NORMAL, R0 ; Return success
MOVW #1, GHB_W_MULTIMR ; Send multicast msg on next tick
POPR #^M<R1,R2,R3,R4,R5,R6> ; Restore registers
ENBINT
RSB
    
```

```

0A2F 1768      .SBTTL LTSUNIT_INIT - Unit Initialization
0A2F 1769      :++
0A2F 1770      : LTSUNIT_INIT - Unit Initialization
0A2F 1771      :
0A2F 1772      : Functional description:
0A2F 1773      :
0A2F 1774      : This routine performs a simple unit initialization.
0A2F 1775      :
0A2F 1776      : Inputs:
0A2F 1777      :
0A2F 1778      :     R5 = UCB address
0A2F 1779      :
0A2F 1780      : Outputs:
0A2F 1781      :
0A2F 1782      :     R0-R3 are modified
0A2F 1783      :--
0A2F 1784      :
0A2F 1785      : LTSUNIT_INIT:
0A2F 1786      : BBS      #UCBSV_POWER,-          ; Skip if power fail recovery
0A31 1787      :         UCBSL_STS(R5), 70$      ;
0A34 1788      :
0A34 1789      : MOVL     G*TTY$GL_DPT,R1        ; Address of class dpt
0A3A 1790      :
0A3B 1791      : MOVZWL  DPT$W_VECTOR(R1),R0     ; Locate class driver vector table
0A3F 1792      : ADDL    R0,R1                  ; Relocate base address
0A42 1793      : MOVL    R1,UCBSL_TT_CLASS(R5)  ; Set terminal class driver vector
0A47 1794      :
0A47 1795      : MOVL    CLASS_GETNXT(R1),UCBSL_TT_GETNXT(R5)
0A4C 1796      : MOVL    CLASS_PUTNXT(R1),UCBSL_TT_PUTNXT(R5)
0A4F 1797      :
0A52 1798      : MOVL    UCBSL_DDB(R5),R0        ; Get DDB address
0A56 1799      : MOVL    CLASS_DDT(R1),DDB$SL_DDT(R0)
0A5B 1800      : MOVL    CLASS_DDT(R1),UCBSL_DDT(R5) ; Set DDT address in UCB
0A5E 1801      :
0A61 1802      : TSTW    UCBSW_UNIT(R5)          ; Special action for ucb 0
0A64 1803      : BEQL    20$                    ; Its is unit zero
0A66 1804      : CLRBIT  #UCBSV_TEMPLATE,-      ; All others lose the template
0A66 1805      :         UCBSL_STS(R5)          ; bit so they won't clone on assign
0A6B 1806      : BRB     40$                    ; Continue
0A6D 1807      : MOVL    R5, GMB_L_UCB0         ; Save address of ucb zero
0A72 1808      :
0A72 1809      : We are setting or clearing some bits in the LTA0 device here so that all
0A72 1810      : later lta devices will have them set/clear the same way. These bits are
0A72 1811      : different from the defaults that are set in the sysgen parameters for
0A72 1812      : the other types of terminals.
0A72 1813      :
0A72 1814      : SETBIT  #TT$V_MODEM,-          ; Set modem so we do modem
0A72 1815      :         UCBSL_TT_DECHAR(R5)    ; processing for this terminal
0A72 1816      : SETBIT  #TT$V_REMOTE,-        ; Set remote so we know its a remote
0A72 1817      :         UCBSL_TT_DECHAR(R5)    ; terminal forever.
0A78 1818      : CLRBIT  #TT2$V_AUTOBAUD,-     ; See setup_ucb routine for reasons
0A78 1819      :         UCBSL_TT_DECHA1(R5)    ; We do not autobaud here.
0A7E 1820      : SETBIT  #TT2$V_HANGUP,-       ; Set default for terminal to hangup
0A84 1821      :         UCBSL_TT_DECHA1(R5)    ; on logout. this can be cleared by
                                ; the user from his terminal.

```

```

0A84 1822          SETBIT #TTYSV_PC_NOTIME,-      ; no timer service please
0A84 1823          UCBSW_TT_PRTCTL(R5)        ; ...
0A8A 1824 40$:    ;
0A8A 1825          ; Finish initializing UCB.
0A8A 1826          ;
OF 10 0A8A 1827    BSBB LTSUCB_INIT           ; Initialize the terminal UCB
OC 11 0A8C 1828    BRB 90$                    ; And leave
50 0134 C5 D0 0A8E 1829
05 13 0A93 1830 70$: MOVL UCBSL_LT_CSB(R5), R0 ; On power fail, reset the timeout
66 A0 B0 0A95 1831 BEQL 90$                  ; No CSB, just forget it
50 A0 0A98 1832    MOVW CSB_W_TIMRESET(R0),-  ; And just wait on some thing
05 0A9A 1833    CSB_W_TIMEOUT(R0)           ; To happen.
0A9A 1834 90$:   RSB

```



```

0A9B 1836      .SBTTL LTSUCB_INIT - Initialize a terminal UCB
0A9B 1837      :++
0A9B 1838      : LTSUCB_INIT - Initialize a terminal UCB
0A9B 1839      :
0A9B 1840      : Functional description:
0A9B 1841      :
0A9B 1842      :         Init the terminal UCB before starting a process to use it.
0A9B 1843      :
0A9B 1844      : Inputs:
0A9B 1845      :     R5 = UCB address
0A9B 1846      :
0A9B 1847      : Outputs:
0A9B 1848      :     R5 = UCB address
0A9B 1849      :     R0, R1 clobbered
0A9B 1850      :--
0A9B 1851
0A9B 1852 LTSUCB_INIT:
0080 54 A5 B5 0A9B 1853 TSTW UCBSW_UNIT(R5)      : Is this unit #0?
      3D 13 0A9E 1854 BEQL 90$                    : Br if yes, skip it
      5C A5 B5 0AA0 1855 TSTW UCBSW_REFC(R5)      : Any channels attached?
      21 12 0AA3 1856 BNEQ 40$                    : Br if yes, don't reinit UCB
01 54 A5 78 0AA5 1857 ASHL UCBSW_UNIT(R5),#1,R1  : Build unit's bit mask
      51 0AA9
0080 C5 51 B0 0AAA 1858 MOVW R1,UCBSB_ERTCNT(R5)  : Save it
      0141 C5 94 0AAF 1859 CLRB UCBSB_LT_LOCID(R5)  : Flag as available (no local slot indx)
      FA05 CF DE 0AB3 1860 MOVAL LTSVECTOR,-      : Set the port address in ucb
      0118 C5 0AB7 1861 UCBSL TT_PORT(R5)      : in case port driver reloaded
      00CC C5 D4 0ABA 1862 CLRL UCBSL TT_WFLINK(R5)  : Zero to force reinit of queue head
      51 0114 C5 D0 0ABE 1863 MOVL UCBSL TT_CLASS(R5),R1 : Address class vector table
      08 B1 16 0AC3 1864 JSB @CLASS_SETUP_UCB(R1)  : Init UCB fields
      0AC6 1865 40$:
      0142 C5 90 0AC6 1866 MOVB #UCBSM_LT_DATA,-      : Look for data first time
      50 8F 90 0AC8 1867 UCBSB_LT_DATAW(R5)
      014A C5 90 0ACB 1868 MOVB #LATSC_UCB_BUFSIZ,-      : Init buffer
      014B C5 94 0ACE 1869 UCBSB_LT_MAXC(R5)
      0146 C5 94 0AD1 1870 CLRB UCBSB_LT_CURC(R5)
      0120 C5 B4 0AD5 1871 CLRB UCBSB_LT_TCRED(R5)
      05 0ADD 1872 CLRW UCBSB_LT_TCRED(R5)
      90$: RSB UCBSW TT_OUTLEN(R5) : No data waiting
    
```

```

OADE 1875      .SBTTL LT$STARTIO - Start I/O routine
OADE 1876      :++
OADE 1877      : LT$STARTIO - Start I/O Operation
OADE 1878      :
OADE 1879      : Functional description:
OADE 1880      :
OADE 1881      : This routine is entered from the device independent terminal startio
OADE 1882      : Routine to enable output interrupts on an idle unit.
OADE 1883      :
OADE 1884      : Inputs:
OADE 1885      :
OADE 1886      : R3 = character      and      cc = plus
OADE 1887      : R3 = address      and      cc = minus      and      R2 = count
OADE 1888      : R5 = ucb address
OADE 1889      :
OADE 1890      : Outputs:
OADE 1891      :
OADE 1892      : R5 = UCB address
OADE 1893      : R0,R1,R2,R3 and R4 are modified
OADE 1894      :--
OADE 1895      :
OADE 1896      LT$STARTIO:
OADE 1897      PUSH  #^M<R5,R6,R8,R9,R10>      ; Start I/O on unit
58 0760 8F  BB  OAE2 1898      MOVL  UCBS$LT_CS(B5),R8      ; Get Circuit State Block
0134 C5  DO  OAE7 1899      BEQL  85$      ; Br if UCB is hanging up
59 13  OAE9 1900      :
OAE9 1901      : Dispatch on our terminal UCB state
OAE9 1902      :
OAE9 1903      $DISPATCH UCBS$LT_STATE(R5),TYPE=B,-
OAE9 1904      <-      ; state      ; action
OAE9 1905      <UCB$C_LT_STATE_KILL 168$>,- ; KILL state, flush data
OAE9 1906      >
OAF1 1907      :
OAF1 1908      : All other states -- okay to send data
OAF1 1909      :
0142 01 88  OAF1 1910      BISB  #UCBSM_LT_DATA,-      ; Assume output data available
C5  OAF3 1911      UCBS$LT_DATAW(R5)
OAF6 1912      :
OAF6 1913      : Buffer data locally
OAF6 1914      :
OAF6 1915      5$: $DISPATCH UCBS$TT_OUTTYPE(R5),TYPE=B,-
OAF6 1916      <-      ; type      ; action
OAF6 1917      < 0      170$>,-      ; No data, allow more calls
OAF6 1918      < 1      10$>,-      ; Single character
OAF6 1919      >
OB00 1920      :
OB00 1921      : Default to burst data
OB00 1922      :
53 011C C5  DO  OB00 1923      MOVL  UCBS$LT_OUTADR(R5),R3      ; Get output buffer address
52 0120 C5  3C  OB05 1924      MOVZWL UCBS$W_TT_OUTLEN(R5),R2      ; and character count
21 11  OB0A 1925      BRB  30$      ; Continue in common path
OB0C 1926      :
50 014A C5  9E  OB0C 1927      10$: MOVAB UCBS$LT_MAXC(R5),R0      ; Get address of maxc
60 80 91  OB11 1928      CMPB  (R0)+,(R0)      ; Any room left ?
02 14  OB14 1929      BGTR  20$      ; Br if yes
60 97  OB16 1930      DECB  (R0)      ; Make room for it
60 96  OB18 1931      20$: INCB  (R0)      ; Update count

```

```

51 00 9A OB1A 1932 MOVZBL (R0),R1 ; Get count
50 51 C0 OB1D 1933 ADDL R1,R0 ; Form destination address
60 53 90 OB20 1934 MOVB R3,(R0) ; Load character
OB23 1935 :
OB23 1936 : We are setting up the address and count of buffered characters in
OB23 1937 : case we are balanced and we should send these characters in a msg
OB23 1938 : to come out of balanced mode
OB23 1939 :
52 014B C5 9A OB23 1940 MOVZBL UCBSB_LT_CURC(R5), R2 ; Get count of buffered characters
53 014C C5 9E OB28 1941 MOVAB UCBSB_LT_CBUF(R5), R3 ; Get address of buffer
00 E1 OB2D 1942 30$: BBC #FLAG_V_RRF,- ; Br if we can we send an
03 5C AB OB2F 1943 CSB_B_FLAG(R8),70$ ; unsolicited message
00E0 31 OB32 1944 60$: BRW 190$
OB35 1945 :
OB35 1946 : Transmit data to concentrator
OB35 1947 :
0146 C5 97 OB35 1948 70$: DECB UCBSB_LT_TCRED(R5) ; Use a credit
0A 18 OB39 1949 BGEQ 90$ ; Br if we have one to use
0146 C5 96 OB3B 1950 80$: INCB UCBSB_LT_TCRED(R5) ; Else, no credits
OB3F 1951 :
OB3F 1952 : Woops. We find we have data and we can't send it anywhere since
OB3F 1953 : we have no credit. Never mind we can just leave here. We will
OB3F 1954 : receive a credit message eventually. We are set non-balanced here
OB3F 1955 : and if we leave so that all the int bits are turned off in the
OB3F 1956 : other ucbs, and this one, then we won't get anymore embarrassing
OB3F 1957 : startio calls. When we get the credit message we will start things
OB3F 1958 : up again.
OB3F 1959 :
00CE 31 OB3F 1960 BRW 180$ ; Leave quietly
OB42 1961 :
OB42 1962 : We have nowhere to put the data and the circuit is down, so just
OB42 1963 : clear interrupt expected, discard the data and return
OB42 1964 :
00C4 31 OB42 1965 85$: BRW 168$ ; Leave, flush data & clear INT expected
OB45 1967 :
56 34 AB 7E OB45 1968 90$: MOVAQ CSB_Q_XBUFQ(R8),R6 ; Get transmit buffer queue address
56 66 D1 OB49 1969 CMPL (R6),-R6 ; Is there a transmit buffer?
ED 13 OB4C 1970 BEQL 80$ ; Br if no transmit buffer, ignore it
5D AB 01 90 OB4E 1971 MOVB #1, CSB_B_NUM_SLOTS(R8) ; We have data for the server now
OB52 1972 SETBIT #FLAG_V_RRF,- ; No more unsolicited messages
OB52 1973 CSB_B_FLAG(R8)
52 AB 02 B0 OB57 1974 MOVW #LATSC_HOST_TIMER,- ; Set retransmit timer
OB5B 1975 CSB_W_XMTTMO(R8)
56 66 D0 OB5B 1976 MOVL (R6), R6 ; Get the buffer address
50 014C C5 9E OB5E 1977 MOVAB UCBSB_LT_CBUF(R5), R0 ; Address the UCB extension
50 53 D1 OB63 1978 CMPL R3, R0 ; Is that our buffer?
04 12 OB66 1979 BNEQ 100$ ; Br if no
OB68 1980 : ***
OB68 1981 : Reading the code I noticed the following line(s) would not work if
OB68 1982 : the startio entry were to discover that it were balanced after
OB68 1983 : previous previous calls stored data in the UCB extensions because
OB68 1984 : we were not balanced. I guess that never happens, because UCBSB_LT_CURC
OB68 1985 : would not be equal to one, as assumed below, but some higher value. BEM
OB68 1986 : ***
014B C5 97 OB68 1987 DECB UCBSB_LT_CURC(R5) ; Yes. Don't save the character there
OB6C 1988 100$:

```

```

5A 59 50 A6 9E OB6C 1989 MOVAB XMT_T_MDATA(R6), R9 ; Address of the slot to use (first)
0149 C5 9A OB70 1990 MOVZBL UCBSB_LT_SLOTSZ(R5), R10; Get the maximum slot size
OB75 1991
OB75 1992 ASSUME SLT_B_DSTID EQ 0
OB75 1993 ASSUME SLT_B_SRCID EQ <SLT_B_DSTID+1>
OB75 1994 ASSUME SLT_B_COUNT EQ <SLT_B_SRCID+1>
OB75 1995 ASSUME SLT_B_CRED EQ <SLT_B_COUNT+1>
OB75 1996
OB75 1997 ASSUME UCBSB_LT_LOCID EQ UCBSB_LT_REMID+1
OB75 1998
89 0140 C5 B0 OB75 1999 MOVW UCBSB_LT_REMID(R5), (R9)+ ; Load remote and local ids
89 5A 90 OB7A 2000 MOVB R10, (R9)+ ; Save the character count
OB7D 2001
OB7D 2002 ; Extend credits to concentrator if needed
OB7D 2003
0147 C5 81 OB7D 2004 ADDB3 UCBSB_LT_XCRED(R5),- ; See if we need to send
50 01 OB81 2005 #LAT$C_MAX_RCRED,R0 ; a credit to the remote
0148 C5 50 80 OB83 2006 ADDB R0,UCBSB_LT_RCRED(R5) ; Add them to total credits to send
0147 C5 50 82 OB88 2007 SUBB R0,UCBSB_LT_XCRED(R5) ; Credits have been extended
89 0148 C5 90 OB8D 2008 MOVB UCBSB_LT_RCRED(R5), (R9)+ ; Load credits
0148 C5 94 OB92 2009 CLRB UCBSB_LT_RCRED(R5) ; Don't send them again!
OB96 2010
5A 52 D1 OB96 2011 110$: CMPL R2, R10 ; Do we have more than we can handle?
03 1B OB99 2012 BLEQU 120$ ; Br if no, its just fine
52 5A D0 OB9B 2013 MOVL R10, R2 ; Use just what we can handle
5A 52 C2 OB9E 2014 120$: SUBL R2, R10 ; Adjust what we have left
OBA1 2015 ; ***
OBA1 2016 ; Reading the code I noticed the following line(s) would not work if
OBA1 2017 ; the startio entry were to discover that it were balanced after
OBA1 2018 ; previous calls stored data in the UCB extensions because
OBA1 2019 ; we were not balanced. I guess that never happens, because R2 would
OBA1 2020 ; not reflect the UCB extension data area. BEM
OBA1 2021 ; ***
011C C5 52 C0 OBA1 2022 ADDL2 R2,UCBSL_TT_OUTADR(R5) ; Update UCB state
0120 C5 52 A2 OBA6 2023 SUBW2 R2,UCBSW_TT_OUTLEN(R5) ; Update UCB state
55 DD OBAB 2024 PUSHL R5 ; Save the UCB address
69 63 52 28 OBAD 2025 MOVC3 R2,(R3),(R9) ; Copy the string
55 8ED0 OBB1 2026 POPL R5 ; Restore the UCB address
59 53 D0 OBB4 2027 MOVL R3,R9 ; Set address of next available byte
5A D5 OBB7 2028 TSTL R10 ; Do we have any left?
28 13 OBB9 2029 BEQL 155$ ; Br if no, all done.
010C D5 16 OBBB 2030 JSB @UCBSL_TT_GETNXT(R5) ; Else, call back class driver for more
19 13 OBBF 2031 BEQL 150$ ; Br if no more to be had
OC 14 OBC1 2032 BGTR 140$ ; Br is single character
OBC3 2033
OBC3 2034 ; Found a burst of data
OBC3 2035
53 011C C5 D0 OBC3 2036 MOVL UCBSL_TT_OUTADR(R5),R3 ; Get output buffer address
52 0120 C5 3C OBC8 2037 MOVZWL UCBSW_TT_OUTLEN(R5),R2 ; and charcter count
C7 11 OBCD 2038 BRB 110$ ; Else buffer address
OBCF 2039
OBCF 2040 140$:
OBCF 2041 ; Found a single character
OBCF 2042
52 01 D0 OBCF 2043 MOVL #1, R2 ; Else, just one character returned
69 53 90 OBD2 2044 MOVB R3, (R9) ; and fake many chars returned
53 59 D0 OBD5 2045 MOVL R9, R3 ; Copy buffer address

```

```

BC 11 OBD8 2046 BRB 110$ ; and continue
OBDA 2047
64 A5 02 AA OBDA 2048 150$: BICW #UCBSM_INT,UCBSL_STS(R5); Allow more start io calls (checked)
01 8A OBDE 2049 BICB #UCBSM_LT_DATA,- ; no output data available
0142 C5 OBE0 2050 UCBSB_LT_DATAW(R5)
52 59 56 C3 OBE3 2051 155$: SUBL3 R6, R9, R2 ; Make the length of the data to
00000048 8F C2 OBE7 2052 SUBL #XMT_T_DATA, R2 ; transmit
52 OBE8 2053
59 01 D6 OBEE 2053 INCL R9 ; Round end address of data
1C A6 59 CA OBF0 2054 BICL #1,R9
52 0C C2 OBF3 2055 MOVL R9,CXBSL_T_ENDADR(R6) ; Store it in the CXB
OBF7 2056 SUBL #<<XMT_T_MDATA- - ; Make total characters in slot
OBF8 2057 XMT_T_DATA> + - ; minus those already accounted for
OBF9 2058 SLT_T_DATA>, R2 ; beyond the circuit and slot headers
52 A6 52 90 OBF9 2059 MOVB R2,<SLT_B_COUNT+- ; Store that count away.
OBF9 2060 XMT_T_MDATA>(R6) ; In the first slot maxc
OBF9 2061
OBF9 2062 .IF DEFINED LT_XMT_CHECK
OBF9 2063 ;
OBF9 2064 ; debug code
OBF9 2065 ;
OBF9 2066 MOVQ CSB_T_CIRCHDR(R8),- ; Move the circ header
OBF9 2067 XMT_T_DATA(R6) ; to look at real msg
OBF9 2068 MOVZBL XMT_B_NUM_SLOTS(R6), R1 ; number of valid slots
OBF9 2069 BNEQ 160$ ; We have some, skip check
OBF9 2070 ; No slots - we must only have a circuit header!
OBF9 2071 MOVAB XMT_T_MDATA(R6), R0 ; Past circuit header
OBF9 2072 CMPL R0,R9 ; Only have a circuit header?
OBF9 2073 BEQL 160$ ; Br if yes, okay
OBF9 2074 DEBUG ; Not correct
OBF9 2075
OBF9 2076 .ENDC ;; DEFINED LT_XMT_CHECK
OBF9 2077
54 58 D0 OBF9 2078 160$: MOVL R8, R4 ; CSB address for call
OE9C 30 OC01 2079 BSBW LT$XMITONE ; Transmit the buffer
0760 8F BA OC04 2080 POPR #^M<R5,R6,R8,R9,R10>
05 0C08 2081 RSB
OC09 2082
OC09 2083 168$: ;
OC09 2084 ; Discard output data, no session active !
OC09 2085 ;
004D 30 OC09 2086 BSBW LT$FLUSH_DATA ; Flush the output data
OC0C 2087
OC0C 2088 170$: ;
OC0C 2089 ; Allow more calls to startio
OC0C 2090 ;
64 A5 02 AA OC0C 2091 BICW #UCBSM_INT, - ; Allow more calls here
OC10 2092 UCBSL_STS(R5) ;
0760 8F BA OC10 2093 180$: POPR #^M<R5,R6,R8,R9,R10>
05 OC14 2094 RSB
OC15 2095
OC15 2096 ;
OC15 2097 ;
OC15 2098 ;
OC15 2099 ;
OC15 2100 ;
OC15 2101 ;

```

Not balanced, so buffer data if we can.
R2 = count
R3 -> data

```

54 014C C5 9E 0C15 2102 190$: MOVAB UCBSB_LT_CBUF(R5), R4 : Address of character buffer
54 53 D1 0C1A 2103 CMPL R3, R4 : Is this the character buffer?
28 13 0C1D 2104 BEQL 210$ : Br if yes, check if its full
50 014B C5 9A 0C1F 2105 MOVZBL UCBSB_LT_CURC(R5), R0 : Calculate amount of room
51 D4 0C24 2106 CLRL R1 : left in the output buffer
014A C5 50 83 0C26 2107 SUBB3 R0, - :
51 0C2B :
52 51 D1 0C2C 2108 UCBSB_LT_MAXC(R5), R1 :
DF 15 0C2F 2109 CMPL R1, R2 : Do we have room?
0120 C5 B4 0C31 2110 BLEQ 180$ : Br if no, so shut output off
014B C5 52 80 0C35 2111 CLRW UCBSW TT OUTLEN(R5) : Else, forget about the data here.
51 6440 9E 0C3A 2112 ADDB2 R2, UCBSB_LT_CURC(R5) : Calculate the number of chars
OC3E 2113 MOVAB (R4)[R0], -R1 : and get address to put them
61 63 55 DD 0C3E 2114 200$: PUSHL R5 : Save the UCB address
52 28 0C40 2115 MOVC3 R2, (R3), (R1) : Copy the string
55 8ED0 0C44 2116 POPL R5 : Restore the UCB address
0C47 2118
014B C5 91 0C47 2119 210$: CMPB UCBSB_LT_CURC(R5), - : Is buffer full?
014A C5 0C4B :
0C4E 2120 UCBSB_LT_MAXC(R5)
010C D5 18 0C4E 2121 BGEQ 180$ : Br if yes, shut off output
B6 13 0C50 2122 JSB @UCBSL TT_GETNXT(R5) : Else, get more data
FE9D 31 0C54 2123 BEQL 170$ : No more data, so just return
OC56 2124 BRW 5$ : Else, process data
OC59 2125

```

```
0C59 2127 .SBTTL LTSFLUSH_DATA - Flush buffered output data and drain TT buffer
0C59 2128 :++
0C59 2129 : LTSFLUSH_DATA - Flush buffered output data and drain class driver buffer
0C59 2130 :
0C59 2131 : Functional description:
0C59 2132 :
0C59 2133 : Flush buffered output data and drain class driver output buffer.
0C59 2134 :
0C59 2135 : Inputs:
0C59 2136 : R5 = UCB address
0C59 2137 :
0C59 2138 : Outputs:
0C59 2139 : R3 is destroyed.
0C59 2140 :--
0C59 2141 :
0C59 2142 LTSFLUSH DATA:
010C D5 16 0C59 2143 20$: JSB @UCBSL_TT_GETNXT(R5) ; Call back for more to class driver
02 13 0C5D 2144 BEQL 90$ ; Br if no more to be had
FB 11 0C5F 2145 BRB 20$ ; Else, drain all output data
0120 C5 B4 0C61 2146 90$: CLRW UCBSW_TT_OUTLEN(R5) ; Clear CLASS driver output data
014B C5 94 0C65 2147 CLRB UCBSB_LT_CURC(R5) ; Dump UCB output buffering
05 0C69 2148 RSB
```

LT
VO
:
:
:
-1

```

0C6A 2150 .SBTTL LTSABORT - Abort (flush) buffered output data
0C6A 2151 :++
0C6A 2152 : LTSABORT - Abort buffered output data
0C6A 2153 :
0C6A 2154 : Functional description:
0C6A 2155 :
0C6A 2156 : Abort (flush) buffered output data
0C6A 2157 :
0C6A 2158 : Inputs:
0C6A 2159 : R5 = UCB address
0C6A 2160 :
0C6A 2161 : Outputs:
0C6A 2162 :
0C6A 2163 : --
0C6A 2164 :
014B C5 94 0C6A 2165 LTSABORT:
0120 C5 B4 0C6E 2166 CLR B UCBSB_LT_CURC(R5) ; Dump UCB buffering
0C72 2167 CLR W UCBSW_TT_OUTLEN(R5) ; Dump pending class driver data,
0142 04 88 0C72 2168 BIS B #UCBSM_LT_ABORT,- ; (might have dissappeared)
0142 C5 05 0C74 2169 RSB UCBSB_LT_DATAW(R5) ; Abort requested
0C77 2170
0C78 2171
0C78 2172
0C78 2173
0C78 2174
0C78 2175
0C78 2176 .SBTTL LTSFLOW_CHANGE - Change flow control
0C78 2177 :
0C78 2178 :+
0C78 2179 : LTSFLOW_CHANGE
0C78 2180 :
0C78 2181 : Function: Inform terminal server of change in host flow control.
0C78 2182 : The terminal server will mimic host policy.
0C78 2183 :
0C78 2184 : Inputs:
0C78 2185 : R5 = UCB address
0C78 2186 :
0C78 2187 : Outputs:
0C78 2188 :
0C78 2189 : -
0C78 2190 :
0142 02 88 0C78 2191 LTSFLOW_CHANGE:
0142 C5 05 0C7A 2192 BIS B #UCBSM_LT_FLOW,- ; Flow change
0C7D 2193 RSB UCBSB_LT_DATAW(R5)
0C7E 2194
0C7E 2195

```



```

    OC7E 2197      .SBTTL LT$XON - Resume input stream into class driver
    OC7E 2198      :++
    OC7E 2199      : LT$XON - Resume input stream into class driver
    OC7E 2200      :
    OC7E 2201      : Inputs:
    OC7E 2202      : R3 = XON character
    OC7E 2203      : R5 = UCB address
    OC7E 2204      :
    OC7E 2205      : Outputs:
    OC7E 2206      :
    OC7E 2207      : R3 is destroyed
    OC7E 2208      :--
    OC7E 2209      : LT$XON:
    1803 8F  BB  OC7E 2210      PUSH  #^M<R0,R1,R11,AP>      ; Save registers
    OC82 2211      CLRBIT #UCBSV_LT_OVFLOW,-      ; Clear overflow indicator
    OC82 2212      UCBSB_LT_LATSTS(R5)
    50  013C C5  D0  OC88 2213      MOVL  UCBSL_LT_INPBUF(R5),R0      ; Get address of input buffer
    0147 C5  96  OC8D 2214      BEQL  70$                      ; Br if none, nothing to do
    OC8F 2215      INCB  UCBSB_LT_XCRED(R5)      ; Okay to return credit now
    OC93 2216      :
    OC93 2217      .IF DEFINED LT_CRED_CHECK
    OC93 2218      BLEQ  10$                      ; Br if okay
    OC93 2219      DEBUG                          ; Else, we went too far
    OC93 2220      10$:
    OC93 2221      .ENDC      ;; DEFINED LT_CRED_CHECK
    OC93 2222      :
    OC93 2223      ASSUME UCBSB_LT_LATSTS EQ UCBSB_LT_DATAW+1
    OC93 2224      :
    1001 8F  AB  OC93 2225      BISW  #<UCBSM_LT_INPUTAB>!UCBSM_LT_DATA,- ; Data potentially available
    0142 C5  OC97 2226      UCBSB_LT_DATAW(R5)      ; and INPUT stream in enabled
    64  A5  02  88  OC9A 2227      BISB  #UCBSM_INT,UCBSL_STS(R5); Force no data to be returned
    5C  02  A0  3C  OC9E 2228      MOVZWL INB_W_BCNT(R0),AP      ; Get count of bytes remaining
    5B  60  3C  OCA2 2229      MOVZWL INB_W_BOFF(R0),R11     ; Get offset to start of input data
    5B  50  C0  OCA5 2230      ADDL  R0,R1T                  ; Calculate address of input data
    OCAB 2231      :
    OCAB 2232      : Feed remaining data into class driver
    OCAB 2233      :
    53  8B  9A  OCAB 2234      30$: MOVZBL (R11)+,R3      ; Get next character
    0110 D5  16  OCAB 2235      JSB  @UCBSL_TT_PUTNXT(R5)      ; Pass character to class driver
    0F  02  E0  OCAF 2236      BBS  #UCBSV_LT_OVFLOW,-      ; Br if overflow, wait for next XON
    0143 C5  OC81 2237      UCBSB_LT_LATSTS(R5),50$
    0F  F0  5C  F5  OC85 2238      SOBGTR AP,30$      ; Loop if more
    50  013C C5  D0  OC88 2239      MOVL  UCBSL_LT_INPBUF(R5),R0      ; Get input buffer address
    0F  19  30  OC8D 2240      BSBW  LT$DEALPOOL      ; Deallocate the input buffer
    013C C5  D4  OCC0 2241      CLRL  UCBSL_LT_INPBUF(R5)      ; Zero input buffer pointer
    0143 C5  10  8A  OCC4 2242      50$: BICB  #UCBSM_LT_INPUT,-      ; Input stream is now disabled
    1803 8F  BA  OCC6 2243      UCBSB_LT_LATSTS(R5)
    05  OC89 2244      70$: POPR  #^M<R0,R1,R11,AP>      ; Restore registers
    OC8D 2245      RSB
    OCCE 2246      :
    OCCE 2247      .SBTTL LT$XOFF - Stop input stream into class driver
    OCCE 2248      :
    OCCE 2249      :++
    OCCE 2250      : LT$XOFF - Stop input stream into class driver
    OCCE 2251      :
    OCCE 2252      : Inputs:
    OCCE 2253      : R3 = XOFF character (^S or ^G)
    
```

```

OCCE 2254 : R5 = UCB address
OCCE 2255 : AP = count of bytes remaining
OCCE 2256 : R11 = address of input data
OCCE 2257 :
OCCE 2258 : Implicit inputs:
OCCE 2259 :
OCCE 2260 : UCBSV_LT_INPUT bit must be on UCBSB_LT_LATSTS status byte.
OCCE 2261 :
OCCE 2262 : Outputs:
OCCE 2263 : R3 is destroyed
OCCE 2264 :
OCCE 2265 :
OCCE 2266 :
OCCE 2267 : LT$XOFF:
07 37 BB OCCE 2267 PUSHR #*M<R0,R1,R2,R4,R5> : Save registers
53 91 OCDO 2268 CMPB R3,#TTY_C_BELL : Is this a control G?
44 13 OCD3 2269 BEQL 90$ : Br if yes, do nothing
04 E1 OCD5 2270 BBC #UCBSV_LT_INPUT,- : Br if input stream not enabled
3E 0143 C5 OCDF 2271 UCBSB_LT_LATSTS(R5),90$
01 5C D1 OCDB 2272 CMLP AP,#1 : Any data to buffer? (counting current)
39 15 OCDE 2273 BLEQ 90$ : Br if no, skip it
5C D7 OCEO 2274 DECL AP : Else, account for character just passed
OCCE 2275 SETBIT #UCBSV_LT_OVERFLOW,- : Set overflow indicator
OCCE 2276 UCBSB_LT_LATSTS(R5)
52 013C C5 D0 OCEB 2277 MOVL UCBSL_LT_INPBUF(R5),R2 : Get input buffer
16 12 OCED 2278 BNEQ 30$ : Br if one there
51 5C OC 0C C1 OCEF 2279 ADDL3 #INB_C_LENGTH,AP,R1 : Else, calculate length of buffer
00000000 GF 16 OCF3 2280 JSB G*EXESALONONPAGED : Allocate a buffer
1D 50 E9 OCF9 2281 BLBC R0,90$ : Br if no buffer
013C C5 52 D0 OCFC 2282 MOVL R2,UCBSL_LT_INPBUF(R5) : Save address of input buffer
08 A2 51 B0 OD01 2283 MOVW R1,INB_W_SIZE(R2) : Set size of input buffer
30$:
0A A2 13 9B OD05 2284 ASSUME INB_B_SPARE EQ INB_B_TYPE+1
02 A2 5C B0 OD09 2285 MOVZBW #DYNSC_BUFIO,INB_B_TYPE(R2) : Set structure type
62 0C B0 OD0D 2286 MOVW AP,INB_W_BCNT(R2) : Set size of remaining string
OD10 2287 MOVW #INB_C_LENGTH,INB_W_BOFF(R2) : Set offset to start of data
OD10 2288 :
OD10 2289 : Don't return credit... wait for XON
OD10 2290 :
0147 C5 97 JD10 2291 DECB UCBSB_LT_XCRED(R5) : Don't return credit
OD14 2292 :
OD14 2293 .IF DEFINED LT_CRED_CHECK
OD14 2294 CMPB UCBSB_LT_XCRED(R5),- : Did we goof?
OD14 2295 #-LATSC_MAX_RCRED
OD14 2296 BGEQU 10$ : Br if okay
OD14 2297 DEBUG : Else, we went too far
OD14 2298 10$:
OD14 2299 .ENDC ;; DEFINED LT_CRED_CHECK
6B 5C 28 OD14 2300
OC A2 OD14 2301 MOV C3 AP,(R11),INB_C_LENGTH(R2) : Copy the data
37 BA OD19 2302 90$: POPR #*M<R0,R1,R2,R4,R5> : Restore registers
05 OD1B 2303 RSB : Return to caller
OD1C 2304

```

```

OD1C 2306      .SBTTL  LTSFFI_RCV_MSG - FAST Interface Receive Complete routine
OD1C 2307      :++
OD1C 2308      : LTSFFI_RCV_MSG - FAST Interface Receive Complete routine
OD1C 2309      :
OD1C 2310      : Functional description:
OD1C 2311      :
OD1C 2312      : Each time a frame is received, the data is passed to the class driver
OD1C 2313      : for each terminal represented within the frame. Echoed data is copied
OD1C 2314      : into a frame to be transmitted back to the concentrator, and finally
OD1C 2315      : the transmit frame is queued for transmission after appropriate
OD1C 2316      : virtual circuit maintenance functions are performed.
OD1C 2317      :
OD1C 2318      : Inputs:
OD1C 2319      :
OD1C 2320      :     R3 = CXB address
OD1C 2321      :     R4 = FFI address
OD1C 2322      :
OD1C 2323      :     IPL = SYNCH
OD1C 2324      :
OD1C 2325      : Outputs:
OD1C 2326      :
OD1C 2327      :     R1-R5 are preserved.
OD1C 2328      :
OD1C 2329      :     The interrupt is dismissed when the received frame
OD1C 2330      :     has been completely processed. The CXB is always
OD1C 2331      :     returned to the datalink driver.
OD1C 2332      :
OD1C 2333      : --
OD1C 2334      :
OD1C 2335      : ASSUME  LATSC_IPL EQ IPL$ SYNCH
OD1C 2336      : LTSFFI_RCV MSG:
OD1C 2337      : PUSHR  #^M<R1,R2,R3,R4,R5,R6,R7,R8,R9,R10,R11,AP,FP> ; Save registers
OD20 2338      :
OD20 2339      : MOVZWL CXBSW_BOFF(R3),R6      ; Get offset to start of data
OD24 2340      : ADDL   R3,R6                  ; Get pointer to start of data
OD27 2341      :
OD27 2342      : .IF DEFINED LT_HISTORY
OD27 2343      :
OD27 2344      : Save history of receives
OD27 2345      :
OD27 2346      : MOVAB  RCV_B_FLAG(R6), R0      ; Address is circuit header
OD2A 2347      : BSBW   LT$HISTORY              ; Store the data
OD2D 2348      : .ENDC  ;; DEFINED LT_HISTORY
OD2D 2349      :
OD2D 2350      : INC_CTR GHBSL_RCOUNT+GHB_AREA . Count frame
OD37 2351      :
OD37 2352      : Validate received frame
OD37 2353      :
OD37 2354      : MOVZWL RCV_W_DSTID(R6),R0      ; Get remote vci
OD3B 2355      : BNEQ  120$                    ; Got index, okay
OD3D 2356      : CMPB  #<MTYP_C_START@FLAG_V_MTYPE>!- ; Is this a start message?
OD3E 2357      : FLAG M-MASTER, -
OD3E 2358      : RCV_B_FLAG(R6)
OD40 2359      : BNEQ  91$                      ; Br if no, signal protocol error
OD42 2360      :
OD42 2361      : START message received on an inactive circuit, try to start up a
OD42 2362      : new circuit.
  
```

```

3FFE 8F  BB
56 18 A3 3C
56 53  CO
50 66 9E
F9FA 30
50 02 A6 3C
76 12
91
66 06 12
29
  
```

```

F3EE CF D5 OD42 2363 :
      4F 13 OD42 2364 : TSTL GHBSL_UCB+GHB_AREA : Data link UCB still here?
04 A6 B5 OD46 2365 : BEQL 99$ : No, then don't accept circuit
      32 13 OD48 2366 : TSTM RCV_W_SRCID(R6) : Is the source ID zero?
06 A6 95 OD48 2367 : BEQL 96$ : Br if yes, protocol error
      32 12 OD4D 2368 : TSTB RCV_B_SEQ(R6) : Is this the correct sequenced msg?
057B 30 OD50 2369 : BNEQ 97$ : Br if not, protocol error
10 50 EB OD52 2370 : BSBW LTSNEW_CIRCUIT : Initialize and/or allocate CSB
      50 D5 OD55 2371 : BLBS R0, 19$ : Go ahead, CSB address in R8
      40 12 OD58 2372 : : startup any transmits waiting
      2F 11 OD58 2373 : TSTL R0 : Are we ignoring a duplicate start msg?
      2F 11 OD5A 2374 : BNEQ 100$ : Br if yes, just retransmit start msg
      2F 11 OD5C 2375 : INC_CTR GHBSL_RESOURCE+GHB_AREA : Else, no CSB to use
      2F 11 OD66 2376 : BRB 99$ : So just ignore it
      2F 11 OD68 2377 :
00B5 31 OD68 2378 19$: BRW 190$ : Long branch
      2F 11 OD6B 2379 :
5D 00 9A OD6B 2380 91$: MOVZBL #GHBSV_START,FP : Invalid START message received
      17 11 OD6E 2381 : BRB 98$ : continue
5D 02 9A OD70 2382 93$: MOVZBL #GHBSV_CSBRANGE,FP : Bad range on CSB index
      12 11 OD73 2383 : BRB 98$ : continue
5D 03 9A OD75 2384 94$: MOVZBL #GHBSV_CSBINVALID,FP : Invalid CSB index
      0D 11 OD78 2385 : BRB 98$ : continue
5D 04 9A OD7A 2386 95$: MOVZBL #GHBSV_CSBSTALE,FP : Stale CSB index
      08 11 OD7D 2387 : BRB 98$ : continue
5D 06 9A OD7F 2388 96$: MOVZBL #GHBSV_INVALIDREMID,FP : Invalid remote circuit id
      03 11 OD82 2389 : BRB 98$ : continue
5D 0A 9A OD84 2390 97$: MOVZBL #GHBSV_INVALIDSEQ,FP : Invalid sequence number
      03 11 OD87 2391 : BRB 98$ : continue
      03 11 OD87 2392 98$: SETBIT FP,GHBSL_PROTOMASK+GHB_AREA : Set bit mask
      03 11 OD87 2393 : INC_CTR GHBSL_PROTOCOL+GHB_AREA : Increment counter
3FFE 8F BA OD97 2394 99$: POPR #R0,R1,R2,R3,R4,R5,R6,R7,R8,R9,R10,R11,AP,FP> : Restore registers
      05 05 OD98 2395 : RSB : Return to caller
      05 05 OD9C 2396 :
      05 05 OD9C 2397 :
      05 05 OD9C 2398 :
      05 05 OD9C 2399 :
      05 05 OD9C 2400 100$: INC_CTR GHBSL_DUPLMSG+GHB_AREA : We received a duplicate message
      05 05 ODA6 2401 : INC_CTR GHBSL_RETRANS+GHB_AREA : We are retransmitting a message
04B2 31 ODB0 2402 : BRW LTSREPLY_REXMIT : This data is stale, resend buffers
      05 05 ODB3 2403 :
      05 05 ODB3 2404 :
      05 05 ODB3 2405 : Non-zero circuit ID !
      05 05 ODB3 2406 : - circuit must be active already
      05 05 ODB3 2407 :
      05 05 ODB3 2408 : Inputs: R0 = CSB index
      05 05 ODB3 2409 : R3 = CXB address
      05 05 ODB3 2410 : R6 = Pointer to start of data
      05 05 ODB3 2411 :
      05 05 ODB3 2412 :
      05 05 ODB3 2413 120$: MOVZBL R0,R1 : Get CSB index
      05 05 ODB6 2414 : CMPL R1, #LATSC_MAX_CSBS : Range check
      05 05 ODB9 2415 : BGTR 93$ : Br if bad range, protocol error
5B F274 CF41 D0 ODBB 2416 : MOVL GHB_L_CSBTABLE-4[R1],R8 : Get CSB address
      02 13 ODC1 2417 : BEQL 94$ : Br if invalid CSB, protocol error
      05 05 ODC3 2418 : CMPW R0,CSB_W_LOCID(R8) : Valid reference ?
      05 05 ODC7 2419 : BNEQ 95$ : Br if no, Stale reference to CSB

```

```

    ODC9 2420      INC_CTR CSB_Z_LCB+LCB_L_MSG_RCV(R8) ; Count one more rcvd msg
    ODD1 2421      :
    ODD1 2422      :   Check ACK number and complete any transmits acknowledged
    ODD1 2423      :
    53 07 AC 9A ODD1 2424 130$: MOVZBL RCV_B_ACK(R6), R3      ; Get the ack from the message
    65 AB 53 90 ODD5 2425      MOVB   R3, CSB_B_RACK(R8)      ;
    53 62 AB 82 ODD9 2426      SUBB   CSB_B_XSEQ(R8), R3      ; Set up the normalized ack
    52 51 52 7E ODDD 2427      MOVAQ  CSB_Q_XWAITQ(R8), R2    ; Look through the wait queue for it
    ODE1 2428      MOVL   R2, RT      ;
    ODE4 2429      :
    51 61 D0 ODE4 2430 140$: MOVL   (R1), R1      ; Next item in queue
    52 51 D1 ODE7 2431 150$: CMPL   R1, R2      ; End of queue
    4E A1 62 AB 83 ODEA 2432      BEQL   190$      ; Done with that search
    50 ODEC 2433      SUBB3   CSB_B_XSEQ(R8), -      ; Normalize the seq of message
    ODF1 2434      XMT_B_SEQ(R1), -      ;
    ODF2 2435      RO      ;
    53 50 91 ODF2 2436      CMPB   R0, R3      ; If the seq is greater than ack,
    ED 14 ODF5 2437      BGTR   140$      ; wait on another ack
    54 61 D0 ODF7 2438      MOVL   (R1), R4      ; Save link to next item
    51 61 OF ODF8 2439      REMQUE (R1), R1      ; Remove acked message from wait queue
    38 BB 61 OE ODFD 2440      INSQUE (R1), -      ; And insert on tail of transmit queue
    OE01 2441      @CSB_Q_XBUFQ+4(R8)      ;
    51 59 AB 97 OE01 2442      DECB   CSB_B_XMTCNT(R8)      ; One less to transmit
    54 D0 OE04 2443      MOVL   R4, RT      ; Restore link
    DE 11 OE07 2444      BRB    150$      ;
    OE09 2445 170$:      :
    OE09 2446      :   Invalid sequence number received
    OE09 2447      :
    OE09 2448      INC_CTR CSB_Z_LCB+LCB_W_SEQ_ERR(R8), W ; Bad sequence number
    89 11 OE11 2449 180$: BRB    100$      ; Also count as duplicate
    OE12 2450      :
    OE13 2451      :   No transmit buffer available
    OE13 2452      :
    OE13 2453      INC_CTR GHBSL_NOXBFR+GHB_AREA      ; Not transmit buffer available
    FF77 31 OE1D 2454 190$: BRW    99$      ; And exit
    OE20 2455      :
    OE20 2456      :   Make sure that we have a transmit buffer to respond with
    OE20 2457      :
    52 34 AB 7E OE20 2458 190$: MOVAQ  CSB_Q_XBUFQ(R8), R2    ; Look to see if we have at least one
    62 52 D1 OE24 2459      CMPL   R2, (R2)      ; transmit buffer
    EA 13 OE27 2460      BEQL   180$      ; Br if None, just retransmit and wait
    OE29 2461      :
    66 AB B0 OE29 2462      MOVW   CSB_W_TIMRESET(R8), -      ; Reset timer for timeout of circuit
    50 AB OE2C 2463      CSB_W_TIMEOUT(R8)      ; Since we got a valid message.
    64 AB 06 A6 91 OE2E 2464      CMPB   RCV_B_SEQ(R6), CSB_B_RSEQ(R8) ; Right sequence number?
    D4 12 OE33 2465      BNEQ   170$      ; Br if no, retransmit all messages
    OE35 2466      :
    OE35 2467      :
    OE35 2468      :
    OE35 2469      :   Dispatch on message type
    OE35 2470      :
    OE35 2471      :   Inputs:
    OE35 2472      :
    OE35 2473      :   R8 = CSB address
    OE35 2474      :   R6 = CXB address
    OE35 2475      :
  
```



```

OE4C 2491 .SBTTL PROCESS RECEIVED MESSAGE
OE4C 2492 :++
OE4C 2493 :
OE4C 2494 : Other guy is halted or all screwed up
OE4C 2495 :
OE4C 2496 :--
OE4C 2497 :
OE4C 2498 LT$FORCE_HALT: ; receive halt msg
OE4C 2499 ; invalid circuit state in msg
OE4C 2500 ; invalid circuit state in CSB
OE4C 2501 ; invalid local vci
OE4C 2502 SETBIT #GHBSV HALT,-
OE4C 2503 GHBSL_PROTOMASK+GHB_AREA ; Circuit forced to halted
OE52 2504 INC_CTR GHBSL_PROTOCOL+GHB_AREA ; Increment protocol error counter
OE5C 2505
O8CB 30 OE5C 2506 LT$STATE_HALT:
O403 31 OE5F 2507 BSBW LT$CIRCDEAD ; Circuit is dead now
OE62 2508 BRW LT$REPLY_REXMIT ; Transmit halt message
OE62 2509
OE62 2510 :++
OE62 2511 :
OE62 2512 : Other system is halted
OE62 2513 :
OE62 2514 :--
OE62 2515 :
O8C5 30 OE62 2516 LT$RCV_HALT_MSG:
O3F8 31 OE62 2517 BSBW LT$CIRCDEAD ; Circuit is dead now
OE65 2518 BRW LT$REPLY_DONE ; All done
OE68 2519
OE68 2520 :++
OE68 2521 :
OE68 2522 : Other guy is starting up
OE68 2523 :
OE68 2524 :--
OE68 2525 :
OE68 2526 LT$RCV_START_MSG:
OE68 2527
OE68 2528 $DISPATCH CSB_B_STATE(R8),TYPE=B,- ; Dispatch on our CSB state
OE68 2529 <- ; state ; action
OE68 2530 <CSB_C_STATE_HALT LT$STATE_START>,- ; Enter the START state
OE68 2531 <CSB_C_STATE_START LT$REPLY_MSG>,- ; Re-send START message
OE68 2532 <CSB_C_STATE_RUN LT$STATE_HALT>,- ; Enter the HALTED state
OE68 2533 >
D7 11 OE73 2534
OE73 2535 BRB LT$FORCE_HALT ; What kind of kinky state is this ?
OE75 2536
OE75 2537 :++
OE75 2538 :
OE75 2539 : Other guy is running
OE75 2540 :
OE75 2541 :--
OE75 2542 :
OE75 2543 LT$RCV_RUN_MSG:
OE75 2544
OE75 2545 $DISPATCH CSB_B_STATE(R8),TYPE=B,- ; Dispatch on our CSB state
OE75 2546 <- ; state ; action
OE75 2547 <CSB_C_STATE_HALT LT$REPLY_MSG>,- ; Send STOP message

```

LTDRIVER
V04-002

- Local Area Terminal Port Driver ^{C 3}
PROCESS RECEIVED MESSAGE

8-JAN-1985 17:22:25 VAX/VMS Macro V04-00 Page 61
5-SEP-1984 11:40:22 [LAT.BUGSRC]LTDRIVER.MAR;1 (41)

		0E75	2548		<CSB_C_STATE_START	LT\$STATE_ENTER_RUN>,- ; Enter RUN state
		0E75	2549		<CSB_C_STATE_RUN	LT\$STATE_RUN>,- ; Stay in RUN state
		0E75	2550	>		
CA	11	0E80	2551			
		0E80	2552	BRB	LT\$FORCE_HALT	; What kind of kinky state is this ?


```

.OE82 2554 .SBTTL CIRCUIT STATE TRANSITIONS
.OE82 2555 :++
.OE82 2556 :
.OE82 2557 : We can go only from halted to starting
.OE82 2558 :
.OE82 2559 :--
.OE82 2560 :
.OE82 2561 LTSSTATE START:
01 90 OE82 2562 MOVB #CSB_C_STATE_START,- ;
0B A8 OE84 2563 CSB_B_STATE(R8) ; Now we are starting
04 90 OE86 2564 MOVB #MTYP_C_START@FLAG_V_MTYPE,- ; Set the start message type
5C A8 OE88 2565 CSB_B_FLAG(R8) ;
04 A6 B0 OE8A 2566 MOVW RCV_W_SRCID(R6),- ;
5E A8 OE8D 2567 CSB_W_REMID(R8) ; Save his circuit id
59 34 A8 D0 OE8F 2568 MOVL CSB_Q_XBUFQ(R8),R9 ; Format a start message
50 F569 CF 9E OE93 2569 MOVAB GHBT_STRT_MSG,R0 ; Get start address of template data
60 F562 CF 28 OE98 2570 MOVC3 GHBT_W_STRT_LEN,(R0),- ; Copy the start message
50 A9 OE9D 2571 XMT_T_MDATA(R9) ;
1C A9 53 D0 OE9F 2572 MOVL R3,CXBSL_T_ENDADR(R9) ; Store end address of data
03B4 31 OEA3 2573 BRW LT$REPLY_ALT ; Go send the reply message
OEA6 2574 :
OEA6 2575 :++
OEA6 2576 :
OEA6 2577 : We transit to the running state only from the starting state
OEA6 2578 :
OEA6 2579 :--
OEA6 2580 :
OEA6 2581 LTSSTATE ENTER_RUN: ; Enter the RUNNING state
02 90 OEA6 2582 MOVB #CSB_C_STATE_RUN,- ; Now we are running
0B A8 OEA8 2583 CSB_B_STATE(R8) ;
5C A8 90 OEA8 2584 MOVB #MTYP_C_RUN@FLAG_V_MTYPE,- ; Set the run message type
OEA8 2585 CSB_B_FLAG(R8) ;
OEA8 2586 :
OEA8 2587 :++
OEA8 2588 :
OEA8 2589 : Update state from validated frame
OEA8 2590 :
OEA8 2591 :--
OEA8 2592 :
OEA8 2593 LTSSTATE RUN:
04 A6 B1 OEA8 2594 CMPW RCV_W_SRCID(R6),- ; Referencing a valid circuit?
5E A8 OEB1 2595 CSB_W_REMID(R8) ;
59 34 A8 D0 OEB3 2596 BNEQ LT$FORCE_HALT ; Br if not, force a halt
OEB5 2597 MOVL CSB_Q_XBUFQ(R8),R9 ; Get transmit buffer address
OEB9 2598 :
OEB9 2599 : Set up for the receive loop
OEB9 2600 :
OEB9 2601 CLRBIT #FLAG_V_RRF,- ; No response requested until
OEB9 2602 CSB_B_FLAG(R8) ; a credit is used
5D A8 94 OEBE 2603 CLRB CSB_B_NUM_SLOTS(R8) ; Assume no output data (balanced)
52 A8 B4 OEC1 2604 CLRW CSB_W_XMTTMO(R8) ; Circuit state is no longer timed
57 08 A6 9E OEC4 2605 MOVAB RCV_T_MDATA(R6),R7 ; Receive buffer first slot address
59 50 A9 9E OEC8 2606 MOVAB XMT_T_MDATA(R9),R9 ; Transmit buffer first slot address
5A 6A A8 3C OEC9 2607 MOVZWL CSB_W_MAX_MSGSIZ(R8),R10 ; Total chars available to slots
5D 01 A6 9A OED0 2608 MOVZBL RCV_B_NUM_SLOTS(R6),FP ; Get slot loop count
03 12 OED4 2609 BNEQ SLOT_COOP_IN ; Got some input data
016B 31 OED6 2610 BRW SLOT_LOOP_OUT ; Go process output buffer

```

LTDRIVER
V04-002

- Local Area Terminal Port Driver^{E 3}
CIRCUIT STATE TRANSITIONS

8-JAN-1985 17:22:25 VAX/VMS Macro V04-00
5-SEP-1984 11:40:22 [LAT.BUGSRC]LTDRIVER.MAR;1

Page 63
(42)

OED9 2611

LT
VO

```

OED9 2613 .SBTTL PROCESS RECEIVED SLOT DATA
OED9 2614 :++
OED9 2615 :PROCESS RECEIVED SLOT DATA
OED9 2616 :
OED9 2617 :Functional description:
OED9 2618 :
OED9 2619 :Now we are set up to pass data to and from the class driver:
OED9 2620 :
OED9 2621 :The following loop copies data from the receive buffer into the class
OED9 2622 :driver.
OED9 2623 :
OED9 2624 :Inputs:
OED9 2625 :R0-R4 available
OED9 2626 :R5 = UCB address
OED9 2627 :R6 = CXB address
OED9 2628 :R7 = current receive buffer slot address
OED9 2629 :R8 = CSB address
OED9 2630 :R9 = current transmit buffer slot address
OED9 2631 :R10 = transmit buffer bytes left
OED9 2632 :R11 = scratch (used as current input slot character copy base register)
OED9 2633 :AP = scratch (used as loop count register)
OED9 2634 :FP = number of slots to process in received message
OED9 2635 :
OED9 2636 :Outputs:
OED9 2637 :none.
OED9 2638 :
OED9 2639 :We continue by processing the output slot loop.
OED9 2640 :
OED9 2641 :--

```

```

OED9 2642 .ENABLE LOCAL_BLOCK
OED9 2643 SLOT_LOOP IN:
OED9 2644 MOVZBL SLT_B_DSTID(R7),R1 ; Input data slot loop
OED9 2645 BNEQ 20$ ; Is this slot alive?
OED9 2646 TSTB SLT_B_SRCID(R7) ; Br if possible
OED9 2647 BEQL 10$ ; Is the remote index valid?
OED9 2648 ; Br if not, ignore slot
OED9 2649 ;
OED9 2650 ; Zero local slot index with non-zero remote (someone's attempting
OED9 2651 ; to login). Must be a start slot!
OED9 2652 EXTZV #4,#4,SLT_B_CRED(R7),R0 ; Get slot type
OED9 2653 CMPB #SLT_C_STR_SLOT,R0 ; Is this a start slot?
OED9 2654 BNEQ LOOP_ABORT ; Br if not, ignore slot
OED9 2655 BSBW LT$ACC_UCB ; Try to allocate an LT UCB
OED9 2656 BLBS R0,10$ ; Br if success
OED9 2657 INC_CTR GHB$RESOURCE+GHB_AREA ; Else, no UCB for us to use
OED9 2658 ;
OED9 2659 ; Send back a reject slot in the case of resource errors
OED9 2660 ;
OED9 2661 CMPL R10,- ; Enough room for REJECT slot header?
OED9 2662 #SLT_S_REJ_SLOT ;
OED9 2663 BLSS 10$ ; Nope, just ignore the data
OED9 2664 INCB CSB_B_NUM_SLOTS(R8) ; Increment slot count
OED9 2665 MOVVB SLT_B_SRCID(R7),(R9)+ ; Copy local id from receive message
OED9 2666 CLRB (R9)+ ; Tell him we are not here!
OED9 2667 CLRB (R9)+ ; Load status byte count
OED9 2668 MOVVB #SLT_C_REJ_SLOT@4,(R9) ; Load REJECT slot format

```

:JAY0002
:JAY0002
:JAY0002
:JAY0002
:JAY0002
:JAY0002
:JAY0002
:JAY0002

```

51 67 9A OED9 2644
   3D 12 OEDC 2645
01 A7 95 OEDE 2646
   35 13 OEE1 2647
   OEE3 2648
   OEE3 2649
   OEE3 2650
   OEE3 2651
50 04 04 EF OEE3 2652
   03 A7 OEE6 2653
   50 09 91 OEE9 2654
   57 12 OEEC 2655
   0656 30 OEEE 2656
   24 50 E8 OEF1 2657
   OEF4 2658
   OEFE 2659
   OEFE 2660
04 5A D1 OEFE .1
   OF01 .2
   OF01 .3
   5D AB 96 OF03 .4
89 01 A7 90 OF06 .5
   89 94 OF0A .6
   89 94 OF0C .7
69 C0 8F 90 OF0E .8

```

```

89 05 88 OF12 9
5A 04 C2 OF15 10
O0EC 31 OF18 2674 10$:
OF1B 2675 20$:
OF1B 2676
OF1B 2677
69 A8 51 91 OF1B 2678
58 1A OF1F 2679
55 68 A841 D0 OF21 2680
2D 18 OF26 2681
01 A7 91 OF28 2682
0140 C5 OF2B
63 13 OF2E 2683
01 A7 95 OF30 2684
10 12 OF33 2685
OF35 2686
OF35 2687
OF35 2688
04 04 EF OF35 2689 40$:
03 A7 OF38
50 0D 91 OF3B 2690
05 12 OF3E 2691
0740 30 OF40 2692
4B 11 OF43 2693
OF45 2694
OF45 2695
OF45 2696
OF45 2697
OF45 2698
OF45 2699
OF4B 2700
OF55 2701
OF55 2702
OF55 2703
OF55 2704
01 A7 95 OF55 2705 70$:
36 13 OF58 2706
OF5A 2707
OF5A 2708
06 5A D1 OF5A 2709
OF5D 2710
31 19 OF5D 2711
5D A8 96 OF5F 2712
89 01 A7 90 OF62 2713
89 89 94 OF66 2714
89 01 90 OF68 2715
89 D0 8F 90 OF6B 2716
89 03 90 OF6F 2717
OF72 2718
5A 89 94 OF72 2719
06 C2 OF74 2720
17 11 OF77 2721
OF79 2722
OF79 2723
OF79 2724
01 A7 95 OF79 2725 90$:
12 13 OF7C 2726

```

BISB #SLT_C_RESOURCE,(R9)+ ; Load reason code (resource error)
SUBL2 #SLT_S_REJ_SLOT,R10 ; Adjust bytes left for other slots
BRW NEXT_SLOT ; Just process the next slot.
: Validate UCB reference - non-zero local index
: :
CMPB R1,CSB_B_MAX_SLOTS(R8) ; Do a range check on the local index
BGTRU 90\$; Br if not in range
MOVL CSB_L_UCBLST-4(R8)[R1],R5 ; Get UCB address
BGEQ 70\$; That slot doesn't live here anymore
CMPB SLT_B_SRCID(R7),UCBSB_LT_REMID(R5) ; Valid remote reference?
: :
BEQL LOAD_CREDITS ; Br if yes, process slot
TSTB SLT_B_SRCID(R7) ; Else, are we hanging up from remote?
BNEQ LOOP_ABORT ; Br if no, invalid slot
: :
: Received a zero in the slot source-id - is this a stop slot?
: :
EXTZV #4,#4,SLT_B_CRED(R7),R0 ; Get slot type
: :
CMPB #SLT_C_STP_SLOT,R0 ; Is this a STOP slot?
BNEQ LOOP_ABORT ; Br if not, do nothing
BSBW LT\$HANGUP_UCB_NOW ; Hangup the UCB to logout process
BRB NEXT_SLOT0 ; Process next slot
: :
: Flag protocol error and ignore slot
: :
LOOP_ABORT:
SETBIT #GHBSV_INVALIDLOCID,-
GHBSL_PROTOMASK+GHB_AREA ; Invalid remote ID or slot format
INC_CTR GHBSL_PROTOCOL+GHB_AREA ;
: :
: Conditionally send stop slot
: :
TSTB SLT_B_SRCID(R7) ; Check remote slot index
BEQL NEXT_SLOT0 ; Br if empty slot
: :
ASSUME SLT_S_STP_SLOT&1 EQ 1 ; Assume we need rounding
CMPL R10,- ; Enough room for STOP slot header?
: :
BLSS NEXT_SLOT0 ; Nope, just ignore the data
INCB CSB_B_NUM_SLOTS(R8) ; Increment slot count
MOVB SLT_B_SRCID(R7),(R9)+ ; Copy local id from receive message
CLRB (R9)+ ; Tell him we are not here !
MOVB #SLT_S_STP_LEN,(R9)+ ; Load slot byte count
MOVB #SLT_C_STP_SLOT&4,(R9)+ ; Load stop slot format
MOVB #SLT_C_INV_SLOT,(R9)+ ; load reason code
ASSUME SLT_S_STP_SLOT&1 EQ 1 ; Assume we need rounding
CLRB (R9)+ ; round up to even boundary
SUBL2 #SLT_S_STP_SLOT+1,R10 ; Adjust bytes left for other slots
BRB NEXT_SLOT0 ; Go do next input slot
: :
: Range check error, is this really a disconnect slot ?
: :
TSTB SLT_B_SRCID(R7) ; Empty remote slot index? (stop slot?)
BEQL NEXT_SLOT0 ; Br if yes, ignore the slot.

		OF7E	2727	SETBIT	#GHBSV	INVALIDREMID,-	
		OF7E	2728		GHBSL_PROTOMASK+GHB_AREA;	Invalid	LOCID with REMID non_zero
		OF84	2729	INC_CTR	GHBSL_PROTOCOL+GHB_AREA	; Count	as protocol error
C5	11	OF8E	2730	BRB	70\$; Send	a stop slot
		OF90	2731				
		OF90	2732	NEXT_SLOTO:			
0074	31	OF90	2733	BRW	NEXT_SLOT	; Branch	aid
		OF93	2734				
		OF93	2735	.DISABLE	LOCAL_BLOCK		

```

      OF93 2737      .SBTTL PROCESS SLOT CREDITS RECEIVED
      OF93 2738      :++
      OF93 2739      :
      OF93 2740      : Update UCB credit account from received message slots
      OF93 2741      :
      OF93 2742      :--
      OF93 2743      LOAD_CREDITS:
50  03 A7  90  OF93 2744      MOVB  SLT_B_CRED(R7),R0      ; Get credits and slot type
      OF97 2745      ASSUME SLT_C_DA_SLOT EQ 0      ; assumption
      OF97 2746      BGEQ  50$      ; Got a DATA_A slot
50  04 00  EF  OF99 2747      EXTZV #0, #4, SLT_B_CRED(R7), R0 ; Get the credit counts
      OF9C 2748      EXTZV #4, #4, SLT_B_CRED(R7), R1 ; Get the slot type
51  04 04  EF  OF9F 2748      EXTZV #4, #4, SLT_B_CRED(R7), R1 ; Get the slot type
      OFA2 2749      $DISPATCH R1,TYPE=B,-      ; Dispatch on slot type
      OFA5 2750      <-      ; slot type      ; action
      OFA5 2751      <SLT_C_DB_SLOT 20$>,-      ; DATA_B slot????
      OFA5 2752      <SLT_C_ATT_SLOT 40$>,-      ; Attention slot
      OFA5 2753      >
      OFAD 2754      BRW  LOOP_ABORT      ; All others, including Reject slot
      FF95 31  OFAD 2755
      OFB0 2756      ; DATA_B slot
      OFB0 2757
      OFB0 2758
      OFB0 2759 20$:  BISB  #UCBSM_LT_DATA,-      ; Remember to at least send back the
0142 C5  88  OFB2 2760      UCBSB_LT_DATAW(R5)      ; credits!
0147 C5  96  OFB5 2761      INCB  UCBSB_CT_XCRED(R5)      ; One less credit on remote end (negative)
      OFB9 2762      BLEQ  40$      ; Br if credits not exceeded, proceed
      OFBB 2763      BSBW  LTSHANGUP_UCB      ; Else, Hangup the UCB to logout process
      OFBE 2764
      OFBE 2765      ; ATTention slot, IGNORE DATA
0146 C5  50  80  OFBE 2767 40$:  ADDB  R0,UCBSB_LT_TCRED(R5) ; Update credits
      OFC3 2768      BRB  NEXT_SLOT      ; Skip to next slot
      OFC5 2769
      OFC5 2770      ; RUN slot
0146 C5  50  80  OFC5 2771
      OFC5 2772 50$:  ADDB  R0,UCBSB_LT_TCRED(R5) ; Update credits
      OFCA 2773
      OFCA 2774
      OFCA 2775      .IF DEFINED LT_CRED_CHECK
      OFCA 2776      CMPB  UCBSB_CT_TCRED(R5),#2
      OFCA 2777      BLEQ  60$      ; Br if ok
      OFCA 2778      SETBIT #GHBSV_BADCREDITS,-
      OFCA 2779      GHBSL_PROTOMASK+GHB_AREA, Too many credits in host
      OFCA 2780      INC  CTR GHBSL_PROTOCOL+GHB_AREA ; Too many credits in host
      OFCA 2781      BSBW  LTSHANGUP_UCB      ; Hangup the UCB to logout process
      OFCA 2782 60$:
      OFCA 2783      .ENDC      ;; DEFINED LT_CRED_CHECK
      OFCA 2784
      OFCA 2785      :
      OFCA 2786      : Move terminal data through class driver
      OFCA 2787      :
      OFCA 2788      : R3 - contains the character
      OFCA 2789      : R5 - UCB address
      OFCA 2790
5C  02 A7  9A  OFCA 2791      MOVZBL SLT_B_COUNT(R7),AP      ; Character count for this slot

```

```

5B 04 37 13 OFCE 2792 BEQL NEXT_SLOT : No input here
0143 C5 00 9E OFD0 2793 MOVAB SLT T_DATA(R7),R11 : Source of characters
EO OFD4 2794 BBS #UCBSV_LT_HANGUP, - : If device is hanging up, do not con-
2D OFD9
0147 C5 96 OFDA 2795 UCBSB_LT_LATSTS(R5),NEXT_SLOT : fuse class driver with more data
05 15 OFDA 2796 INCB UCBSB_LT_XCRED(R5) : One less credit on remote end (negative)
06AD 30 OFDE 2797 BLEQ 70$ : Br if credits not exceeded, proceed
22 11 OFE0 2798 BSBW LESHANGUP_UCB : Else, Hangup the UCB to logout process
OFES 2799 BRB NEXT_SLOT : Continue
OFES 2800 70$: :
OFES 2801 : Indicate that input stream is running again, and data is potentially
OFES 2802 : available.
OFES 2803 :
OFES 2804 ASSUME UCBSB_LT_LATSTS EQ UCBSB_LT_DATAW+1
OFES 2805
1001 8F AB OFES 2806 BISW #<UCBSM_LT_INPUT@8>!UCBSM_LT_DATA,- : Data potentially available
0142 C5 05 OFE9 2807 UCBSB_LT_DATAW(R5) : and INPUT stream in enabled
64 A5 02 88 OFEC 2808 BISB #UCBSM_INT,UCBSL_STS(R5); Force no data to be returned
OFF0 2809 :
OFF0 2810 : Dump characters into class driver
OFF0 2811 :
53 8B 9A OFF0 2812 80$: MOVZBL (R11)+,R3 : Get next character
09 0143 C5 E0 OFF3 2813 BBS #UCBSV_LT_OVFLOW,- : Br if overflow, wait for XON
0110 D5 16 OFF5 2814 UCBSB_LT_LATSTS(R5),90$
1B 12 OFF9 2815 JSB @UCBSL_TT_PUTNXT(R5) : Pass character to class driver
EE 5C F5 OFFD 2816 BNEQ ECHO_ERROR : Br if character being echoed
2817 SOBGTR AP,80$ : Do all characters
1002 2818
0143 10 8A 1002 2819 90$: BICB #UCBSM_LT_INPUT,- : Input stream is now disabled
C5 1004 2820 UCBSB_LT_LATSTS(R5)
1007 2821 :
1007 2822 : Bump pointers to the next slot
1007 2823 :
1007 2824 NEXT_SLOT:
50 02 A7 9A 1007 2825 MOVZBL SLT B COUNT(R7), R0 : Max bytes in the slot
05 A740 9E 100B 2826 MOVAB <SLT_T_DATA+1>(R7)- : Compute address of next slot +1
57 100F 2827 [R0], R7 : to help round to word
57 01 CA 1010 2828 BICL #1, R7 : make it a word boundary.
5D D7 1013 2829 DECL TP : Loop on all slots
2D 13 1015 2830 BEQL SLOT_LOOP_OUT : Done all input slots, now process
FEBF 31 1017 2831 : any output data
101A 2832 BRW SLOT_LOOP_IN : Process all received slots
101A 2833
101A 2834 ECHO_ERROR: : Character being echoed???
101A 2835 DEBUG :;&& Should not get to here

```

```

1020 2837 .SBTTL BUILD A STOP SLOT
1020 2838 :++
1020 2839 : BUILD A STOP SLOT
1020 2840 :
1020 2841 : Functional description:
1020 2842 :
1020 2843 : Build a stop slot in the out message buffer, then delete the UCB.
1020 2844 :
1020 2845 : Inputs:
1020 2846 : R5 = UCB address
1020 2847 : R8 = CSB address
1020 2848 : R9 = current transmit buffer slot address
1020 2849 : R10 = transmit buffer bytes left
1020 2850 :
1020 2851 : Outputs:
1020 2852 : R5 = UCB address
1020 2853 : R8 = CSB address
1020 2854 : R9 = current transmit buffer slot address
1020 2855 : R10 = transmit buffer bytes left
1020 2856 :
1020 2857 :--
1020 2858 :
014B C5 95 1020 2859 SEND_STOP_SLOT:
      03 13 1024 2860 TSTB UCBSB_LT_CURC(R5) ; Is UCB data waiting?
00B9 31 1026 2861 BEQL 30$ ; Br if no, send the STOP slot
      1029 2862 BRW CREDIT_CHECK ; Send data if our credit is good
04 5A D1 1029 2863 30$: CMPL R10, #SLT_T_DATA ; Enough room for STOP slot?
      1E 15 102C 2864 BLEQ ONE_LESS ; Br if no, send it next time
      SD AB 96 102E 2865 INCB CSB_B_NUM_SLOTS(R8) ; Update slot count
      1031 2866
89 0140 C5 90 1031 2867 ASSUME SLT_B_DSTID EQ 0
      1031 2868 MOVB UCBSB_LT_REMID(R5), (R9)+ ; Send the remote slot index
      1036 2870
      1036 2871 ASSUME SLT_B_SRCID EQ SLT_B_DSTID+1
      1036 2872 ASSUME SLT_B_COUNT EQ SLT_B_SRCID+1
      89 B4 1036 2873 CLRW (R9)+ ; Zero SRCID for a stop slot
      1038 2874 ; and no data
      1038 2875 ASSUME SLT_B_CRED EQ SLT_B_COUNT+1
89 D0 8F 90 1038 2876 MOVB #SLT_C_STP_SLOT24, (R9)+ ; Load stop slot format & no credits
      5A 04 C2 103C 2877 SUBL #SLT_T_DATA, R10 ; Adjust bytes left for other slots
      103F 2878 ; ** Skip call if HOST BIND
      0694 30 103F 2879 BSBW LTKILLUCB ; Wipe out the UCB now.
      08 11 1042 2880 BRB ONE_LESS ; Get next slot

```

LT
VO

:J
-1

:J
:J
-3


```

1044 2882 .SBTTL PROCESS OUTPUT SLOT DATA
1044 2883 :++
1044 2884 : PROCESS OUTPUT SLOT DATA
1044 2885 :
1044 2886 : Functional description:
1044 2887 :
1044 2888 : Now output any waiting data from each UCB on this circuit and any
1044 2889 : data returned from the class driver is transferred to the appropriate
1044 2890 : output slot in the transmit buffer.
1044 2891 :
1044 2892 : Inputs:
1044 2893 : R0-R4 available
1044 2894 : R5 = UCB address
1044 2895 : R6,R7 = scratch
1044 2896 : R8 = CSB address
1044 2897 : R9 = current transmit buffer slot address
1044 2898 : R10 = transmit buffer bytes left
1044 2899 : R11-FP = scratch
1044 2900 :
1044 2901 : Outputs:
1044 2902 : none.
1044 2903 :
1044 2904 : We continue processing in the send reply message section.
1044 2905 :
1044 2906 :--
1044 2907 SLOT_LOOP OUT:
5D 2D AB 9A 1044 2908 MOVZBL CSB_B_REFC(R8),FP ; Set output UCB loop count
57 6C AB DE 1048 2909 MOVAL CSB_L_UCBLST(R8),R7 ; Set base address of UCB vector
104C 2910 ONE_LESS: ; One less unit left
SD D7 104C 2911 DECL FP ; Any UCBs left ?
03 18 104E 2912 BGEQ 10$ ; Br if yes
01EB 31 1050 2913 BRW LOOP_EXIT ; Else, exit loop
1053 2914 10$:
55 87 D0 1053 2915 MOVL (R7)+,R5 ; Get next UCB address
FB 13 1056 2916 BEQL 10$ ; ignore holes in non-dense vector
1058 2917 ;
1058 2918 ; Dispatch on our terminal UCB state
1058 2919 ;
1058 2920 $DISPATCH UCBSB_LT_STATE(R5),TYPE=B,-
1058 2921 <- : state : action
1058 2922 <UCBSC_LT_STATE_STOP SEND_STOP_SLOT>,- ; STOP state, send stop slot
1058 2923 <UCBSC_LT_STATE_KILL ONE_LESS>,- ; KILL state, ignore this
1058 2924 >
1062 2925 ; RUN and START, just fall through
0142 C5 95 1062 2926 ;
E4 13 1066 2927 TSTB UCBSB_LT_DATAW(R5) ; Is there any data waiting?
1068 2928 BEQL ONE_LESS ; Br if no, skip this UCB
1068 2929 ;
1068 2930 ; Check for ABORT message first
1068 2931 ;
1A 0142 C5 02 E5 1068 2932 BBCC #UCBSV_LT_ABORT,- ; Br if no abort requested
106A 2933 UCBSB_LT_DATAW(R5),30$ ; and clear flag
106E 2934 ;
106E 2935 ; Send an ATTention slot
106E 2936 ;
06 5A D1 106E 2937 ASSUME SLT_S_ATT_SLOT&1 EQ 1 ; Assume we need rounding
106E 2938 CMPL R10, #SLT_S_ATT_SLOT+1 ; Enough room for ATTENTION slot ?

```

```

      30 15 1071 2939
SD AB 96 1073 2940
      1076 2941
      1076 2942
      1076 2943
      1076 2944
      1076 2945
      1076 2946
      1076 2947
      1076 2948
89 0140 C5 B0 1076 2949
89 89 01 90 107B 2950
89 B0 8F 90 107E 2951
      1082 2952
      1082 2953
89 20 B0 1082 2954
5A 06 C2 1085 2955
      1088 2956
      1088 2957
      1088 2958
      1088 2959
54 0142 C5 E5 1088 2960
      108A 2961
      108E 2962
      108E 2963
      108E 2964
      108E 2965
      0146 C5 97 108E 2965
      0C 18 1092 2966
      0146 C5 96 1094 2967
      1098 2968
      1098 2969
      42 11 109E 2970
      10A0 2971
      10A0 2972
      10A0 2973
      0A 5A D1 10A0 2974
      10A3 2975
      10A3 2976
      3D 15 10A3 2976
SD AB 96 10A5 2977
      10A8 2978
      10A8 2979
      10A8 2980
      10A8 2981
      10A8 2982
      10A8 2983
      10A8 2984
      10A8 2985
      10A8 2986
      10A8 2987
      10A8 2988
      10A8 2989
89 0140 C5 B0 10A8 2990
89 89 05 90 10AD 2991
89 A0 8F 90 10B0 2992
      10B4 .1
      10B4 .2
      10B4 .3

```

```

BLEQ 50$ : Br if no, skip it (use br helper)
INCB CSB_B_NUM_SLOTS(R8) : Update slot count
ASSUME UCBSB_LT_LOCID EQ UCBSB_LT_REMID+1
ASSUME SLT_B_DSTID EQ 0
ASSUME SLT_B_SRCID EQ SLT_B_DSTID+1
ASSUME SLT_B_COUNT EQ SLT_B_SRCID+1
ASSUME SLT_B_TYPE EQ SLT_B_COUNT+1
ASSUME SLT_B_ATT_CONTROL EQ SLT_B_TYPE+1
MOVW UCBSB_LT_REMID(R5), (R9)+ : Send the remote slot id
MOVB #SLT_S_ATT_LEN, (R9)+ : Set ATTENTION slot data size
MOVB #SLT_C_ATT_SLOT@4, (R9)+ : Load ATTn type & no credits
ASSUME SLT_S_ATT_SLOT@1 EQ 1 : Assume we need rounding
MOVW #SLT_ATT_M_ABORT, (R9)+ : Send abort flag & zero byte
SUBL #SLT_S_ATT_SLOT+1, R10 : Account from room taken
:
: Check for flow control message
:
30$:
BBCC #UCBSV_LT_FLOW, - : Br if no flow requested
UCBSB_LT_DATAW(R5), 90$ : and clear flag
:
: Send DATA_B slot
:
DECB UCBSB_LT_TCRED(R5) : Use up a credit
BGEQ 40$ : Br if okay, continue
INCB UCBSB_LT_TCRED(R5) : Else, restore credits
SETBIT #UCBSV_LT_FLOW, - : Remember to send flow control
UCBSB_LT_DATAW(R5) : when we have good credit
BRB 90$ : And continue
:
40$:
ASSUME SLT_S_DB_SLOT@1 EQ 1 : Assume we need rounding
CMPL R10, - : Enough room for DATA_B slot ?
#<SLT_S_DB_SLOT+1> : rounded up
50$:
BLEQ 90$ : Br if no, skip it (branch helper)
INCB CSB_B_NUM_SLOTS(R8) : Update slot count
ASSUME UCBSB_LT_LOCID EQ UCBSB_LT_REMID+1
ASSUME SLT_B_DSTID EQ 0
ASSUME SLT_B_SRCID EQ SLT_B_DSTID+1
ASSUME SLT_B_COUNT EQ SLT_B_SRCID+1
ASSUME SLT_B_TYPE EQ SLT_B_COUNT+1
ASSUME SLT_B_DB_CONTROL EQ SLT_B_TYPE+1
ASSUME SLT_B_DB_OFOF EQ SLT_B_DB_CONTROL+1
ASSUME SLT_B_DB_OFON EQ SLT_B_DB_OFOF+1
ASSUME SLT_B_DB_IFOF EQ SLT_B_DB_OFON+1
ASSUME SLT_B_DB_IFON EQ SLT_B_DB_IFOF+1
MOVW UCBSB_LT_REMID(R5), (R9)+ : Send the remote slot id
MOVB #SLT_S_DB_LEN, (R9)+ : Set DATA_B data size
MOVB #SLT_C_DB_SLOT@4, (R9)+ : Load DATA_B type & no credits
:
: If the terminal is set to PASSALL, then we will disable all
: flow control. Else, we will use XON/XOFF flow control if we

```

:JAY0001
:JAY0001
:JAY0001

LT
V04

```

: JAY0001          10B4      .4      : are set /HOSTSYNC or we will use NULL/BELL flow control if
: JAY0001          10B4      .5      : we are set /NOHOSTSYNC.
: JAY0001          10B4      .6      :
: JAY0001          10B4      .7      :
: JAY0001          10B7      .8      :
: JAY0001          10BD      .9      :
: JAY0001          10BE      .9      :
: JAY0001          10C3      .10     :
: JAY0001          10C7      .11     :
: JAY0001          10CC      .12     :
: JAY0001          10D0      .13     :
: JAY0001          10D0      .14     : 60$:
: JAY0001          10D0      .15     :
: JAY0001          10D0      .16     :
: JAY0001          10D5      .17     :
: JAY0001          10D5      3003     :
: JAY0001          10D9      3004     :
: JAY0001          10DD      3005     :
: JAY0001          10DD      3006     : 70$:
: JAY0001          10DD      3007     :
: JAY0001          10DD      3008     :
: JAY0001          10DF      3009     :
: JAY0001          10E2      3010     :
: JAY0001          10E2      3011     :
: JAY0001          10E2      3012     :
: JAY0001          10E2      3013     :
: JAY0001          10E2      3014     : 90$:
: JAY0001          10E2      3015     :

```

: are set /HOSTSYNC or we will use NULL/BELL flow control if
we are set /NOHOSTSYNC.
: Assume no flow control
: Assume default values
: Br if PASSALL
: Else, use flow control
: Assumed ^S and ^Q
: Else, we were wrong
: Check /TTSYNC
: Br if ^S and ^Q
: assumption was correct
: Else, clear output flow enable
: and set output flow disable
: Assume we need rounding
: Round up
: Adjust bytes left (rounded up)
: Check if there is any output data waiting

```

10E2 3017 :++
10E2 3018 :
10E2 3019 : Any credits and enough room in output buffer for this slot ?
10E2 3020 :
10E2 3021 :--
10E2 3022 CREDIT_CHECK: ; UNUSED LABEL (breaks up LSB)
10E2 3023 :
10E2 3024 : Flush all characters to transmit buffer
10E2 3025 :
10E2 3026 : R8 = CSB address
10E2 3027 : R5 = UCB address
10E2 3028 :
56 0149 C5 9A 10E2 3029 MOVZBL UCBSB_LT_SLOTSZ(R5),R6 ; Get maximum slot size
56 5A D1 10E7 3030 CMPL R10,R6 ; Is space left greater?
56 03 14 10EA 3031 BGTR 10$ ; Br if yes, then we can use it
56 5A D0 10EC 3032 MOVL R10,R6 ; Else, use lesser size
56 04 C2 10EF 3033 10$: SUBL #SLT_T_DATA, R6 ; Subtract slot header size
08 14 10F2 3034 BGTR 30$ ; Br if enough room
20$: 10F4 3035 SETBIT #FLAG_V_RRF,- ; Else, indicate response requested
10F4 3036 CSB_B_FLAG(R8) ; since not all data fit in buffer
FF50 31 10F9 3037 BRW ONE_CESS ; No room left in output slot
5C 56 D0 10FC 3038 30$: MOVL R6,AP ; Get room left in output slot
5B 04 A9 9E 10FF 3039 MOVAB SLT_T_DATA(R9),R11 ; Sink of characters
1103 3040 :
1103 3041 : Check if we have credits, or if we need to return credits
1103 3042 : before building the message.
1103 3043 :
0146 C5 95 1103 3044 TSTB UCBSB_LT_TCRED(R5) ; Any credits we can use to send msg?
09 14 1107 3045 BGTR 40$ ; Br if yes, okay to build data message
1109 3046 ASSUME LAT$C_MAX_RCRED EQ 1
0147 C5 95 1109 3047 TSTB UCBSB_LT_XCRED(R5) ; Remote have any credits?
E5 12 110D 3048 BNEQ 20$ ; Br if yes, just leave now
00C4 31 110F 3049 BRW USE_CREDIT ; Else, send back credits
1112 3050 40$:
1112 3051 : Any data from startio ?
1112 3052 :
52 014B C5 9A 1112 3053 MOVZBL UCBSB_LT_CURC(R5),R2 ; Get characters in startio ?
4A 13 1117 3054 BEQL 70$ ; Br if none
53 014C C5 9E 1119 3055 MOVAB UCBSB_LT_CBUF(R5),R3 ; Set address of buffer
52 5C D1 111E 3056 CMPL AP,R2 ; Got enough room in xmit buffer?
29 18 1121 3057 BGEQ 60$ ; Br if yes
1123 3058 :
1123 3059 : R2 = COUNT
1123 3060 : R3 -> DATA
1123 3061 :
014B C5 5C 82 1123 3062 SUBB2 AP, UCBSB_LT_CURC(R5) ; Save residual count
55 DD 1128 3063 PUSHL R5 ; Save the UCB address
68 63 5C 28 112A 3064 MOVCL AP,(R3),(R11) ; Copy the string from UCB to output bfr
55 8ED0 112E 3065 POPL R5 ; Restore the UCB address
58 53 D0 1131 3066 MOVL R3,R11 ; Set address of next available byte
52 014C C5 9E 1134 3067 MOVAB UCBSB_LT_CBUF(R5), R2 ; Copy residual chars to beginning
53 014B C5 9A 1139 3068 MOVZBL UCBSB_LT_CURC(R5), R3 ; of UCB buffer area
55 DD 113E 3069 PUSHL R5 ; Save the UCB address
62 61 53 28 1140 3070 MOVCL R3,(R1),(R2) ; Move the string up in the UCB
55 8ED0 1144 3071 POPL R5 ; Restore the UCB address
5C D4 1147 3072 CLRL AP ; No more room left
00BA 31 1149 3073 BRW USE_CREDIT ; Use a credit and send them

```

```

114C 3074
014B C5 94 114C 3075 60$: CLRB UCBSB_LT_CURC(R5) ; No data now
5C 52 C2 1150 3076 : SUBL2 R2,AP ; Adjust room left in slot
6B 63 55 DD 1153 3077 : PUSHL R5 ; Save the UCB address
52 28 1155 3078 : MOVCL R2,(R3),(R11) ; Copy the string
5B 53 8ED0 1159 3079 : POPL R5 ; Restore the UCB address
5C D0 115C 3080 : MOVL R3,R11 ; Set address of next available byte
5C D5 115F 3081 : TSTL AP ; Any room left in slot?
73 15 1161 3082 : BLEQ USE_CREDIT ; No, just transmit data
1163 3083 :
1163 3084 : Check if there is any data from last time
1163 3085 :
52 0120 C5 32 1163 3086 70$: CVTWL UCBSW_TT_OUTLEN(R5),R2 ; Any data left from last time?
5C 2C 15 1168 3087 : BLEQ GET_MORE ; Br if no, try for new data
53 011C C5 D0 116A 3088 : MOVL UCBSL_TT_OUTADR(R5),R3 ; Get address of data
52 5C D1 116F 3089 : CMPL AP,R2 ; Enough room in buffer?
03 18 1172 3090 : BGEQ 80$ ; Br if yes
52 5C D0 1174 3091 : MOVL AP,R2 ; Use all the space we have left
0120 C5 52 A2 1177 3092 80$: SUBW2 R2,UCBSW_TT_OUTLEN(R5) ; Adjust descriptor
011C C5 52 C0 117C 3093 : ADDL2 R2,UCBSL_TT_OUTADR(R5) ;
5C 52 C2 1181 3094 : SUBL R2,AP ; Adjust count of chars left
6B 63 55 DD 1184 3095 : PUSHL R5 ; Save the UCB address
52 28 1186 3096 : MOVCL R2,(R3),(R11) ; Copy the string
5B 53 8ED0 118A 3097 : POPL R5 ; Restore the UCB address
5C D0 118D 3098 : MOVL R3,R11 ; Set address of next available byte
5C D5 1190 3099 : TSTL AP ; Any room left now?
02 14 1192 3100 : BGTR GET_MORE ; Br if yes, get some more data
40 11 1194 3101 : BRB USE_CREDIT ; Else, try next slot
1196 3102 :
1196 3103 :
1196 3104 : Loop draining class driver until no data is left or buffer is full
1196 3105 :
010C D5 16 1196 3106 GET_MORE: JSB @UCBSL_TT_GETNXT(R5) ; Get characters from class driver
119A 3107 :
119A 3108 :
119A 3109 : R1-R4 modified
119A 3110 : R3 = ?? and cc = 0 ; No more data
119A 3111 : R3 = char and cc = + ; One character
119A 3112 : R3 = ?? and cc = - ; Burst data (TT_OUTADR, TT_OUTLEN)
119A 3113 : R5 = ucb address
119A 3114 :
40 13 119A 3115 : BEQL USE_CREDIT1 ; No characters
09 19 119C 3116 : BLSS GOT_A_LOT ; Got more than one character
119E 3117 :
8B 53 90 119E 3118 : MOVB R3,(R11)+ ; Copy character to output
5C D7 11A1 3119 : DECL AP ; Adjust room in slot
F1 14 11A3 3120 : BGTR GET_MORE ; Go get more
2F 11 11A5 3121 : BRB USE_CREDIT ; No room left in slot
11A7 3122 :
53 011C C5 D0 11A7 3123 GOT_A_LOT: MOVL UCBSL_TT_OUTADR(R5),R3 ; Get output buffer address
52 0120 C5 3C 11AC 3124 : MOVZWL UCBSW_TT_OUTLEN(R5),R2 ; and charcter count
52 5C D1 11B1 3125 : CMPL AP,R2 ; Got enough room in output buffer?
03 18 11B4 3126 : BGEQ 10$ ; Br if yes
52 5C D0 11B6 3127 : MOVL AP,R2 ; Output maximum possible
5C 52 C2 11B9 3128 10$: SUBL2 R2,AP ; Adjust room left in slot
011C C5 52 C0 11BC 3129 : ADDL R2,UCBSL_TT_OUTADR(R5) ; Update output address
0120 C5 52 A2 11C1 3130 : SUBW2 R2,UCBSW_TT_OUTLEN(R5) ; and charcter count

```

6B	63	55	DD	11C6	3131	PUSHL	R5	:	Save the UCB address
		52	28	11C8	3132	MOVCL	R2,(R3),(R11)	:	Copy the string
		55	8ED0	11CC	3133	POPL	R5	:	restore the UCB address
	5B	53	D0	11CF	3134	MOVL	R3,R11	:	set address of next available byte
		5C	D5	11D2	3135	TSTL	AP	:	Any room left in slot ?
		CO	14	11D4	3136	BGTR	GET_MORE	:	Br if yes, look for more

```

11D6 3138      .SBTTL CONSUME CREDIT WHEN FILLING IN SLOT FIELD
11D6 3139      :
11D6 3140      : If any data was added to output slot, use credit locally, pass credit
11D6 3141      : to other end if needed, and set circuit mode to unbalanced.
11D6 3142      :
11D6 3143      :
11D6 3144      .ENABL LSB
11D6 3145      USE_CREDIT:
11D6 3146      BISW  #UCBSM_INT,UCBSL_STS(R5); Set interrupt expected, locks
11DA 3147      BRB   10$; out transmits from STARTIO
11DC 3148      : Continue
11DC 3149      USE_CREDIT1:
11DC 3150      FICW  #UCBSM_INT,UCBSL_STS(R5); Clear interrupt expected
11E0 3151      JBS   #UCBSV_LT_OVFLOW,-; Don't clear data waiting flag
05 0143 C5     11E2 3152      UCBSB_LT_LATSTS(R5),10$; if we're waiting for OVFLOW to clear
11E6 3153      BICB  #UCBSM_LT_DATA,-; No more output data waiting
0142 C5     11E8 3154      UCBSB_LT_DATAW(R5)
11EB 3155      10$:
11EB 3156      ::EE
11EB 3157      SUBL3 AP,R6,AP; form character count in AP
11EB 3158      DECB  UCBSB_LT_TCRED(R5); Use up a credit
11EB 3159      BISB  #FLAG_M_RRF,-; Set response requested flag
11EB 3160      BISB  CSB B FLAG(R8);
11ED 3161      BISB  #FLAG_M_RRF,-; Set response requested flag
11ED 3162      BISB  CSB B FLAG(R8);
5C 56 5C A8 88 11EB 3160      BISB  #FLAG_M_RRF,-; Set response requested flag
11ED 3161      BISB  CSB B FLAG(R8);
11EF 3162      SUBL3 AP,R6,AP; Calculate character count in AP
0146 C5     11F3 3163      BEQL  20$; Br if no data, DON'T use credit
11F5 3164      DECB  UCBSB_LT_TCRED(R5); Else, use up a credit
11F9 3165      ASSUME SLT_C_DA_SLOT EQ 0
11F9 3166      ADDB3 UCBSB_LT_XCRED(R5),-; Calculate credits to send to remote
50 01 08 11 11FD 3167      #LATSC_MAX_RCRED,R0; system as DATA_A slot
11FF 3168      BRB   40$; Send credits and data
1201 3169      ASSUME SLT_C_DA_SLOT EQ 0
1201 3170      ADDB3 UCBSB_LT_XCRED(R5),-; See if we need to send
50 01 32 13 1205 3171      #LATSC_MAX_RCRED,R0; a credit to the remote
0148 C5     1207 3172      BEQL  60$; Br if no, send nothing
0147 C5     1209 3173      ADDB  R0,UCBSB_LT_RCRED(R5); Else, add in credits to send
0147 C5     120E 3174      SUBB  R0,UCBSB_LT_XCRED(R5); Credits have been extended
1213 3175      :
1213 3176      :
1213 3177      : Setup slot header and advance pointer to next transmit slot header
1213 3178      :
1213 3178      ASSUME UCBSB_LT_LOCID EQ UCBSB_LT_REMID+1
1213 3179      ASSUME SLT_B_SRCID EQ SLT_B_DSTID+1
1213 3180      :
0140 C5     1213 3181      MOVW  UCBSB_LT_REMID(R5),-; Set up slot connection ids
69 1217 3182      SLT B DSTID(R9)
02 5D A8 96 1218 3183      INCB  CSB B NUM_SLOTS(R8); Update slot count
A9 5C 90 121B 3184      MOVB  AP,SLT_B_COUNT(R9); Load character count
0148 C5     121F 3185      MOVB  UCBSB_LT_RCRED(R5),-; Load slot type and credits
03 A9 1223 3186      SLT B CRED(R9)
1225 3187      ASSUME SLT_C_DA_SLOT EQ 0
0148 C5     1225 3188      CLRB  UCBSB_LT_RCRED(R5); Set RUN state, no more credits
50 59 D0 1229 3189      MOVL  R9, R0; Copy slot starting address
59 58 D0 122C 3190      MOVL  R11, R9; Address of start of next slot
59 59 D6 122F 3191      INCL  R9; Make word address
59 01 CA 1231 3192      BICL  #1, R9; which is even
50 59 50 C3 1234 3193      SUBL3 R0, R9, R0; Compute bytes used by slot
5A 50 C2 1238 3194      SUBL2 R0, R10; Adjust bytes left for other slots

```

```

FE0E 31 123B 3195 60$: BRW ONE_LESS ; go do next UCB
123E 3196
123E 3197 LOOP_EXIT:
123E 3198 :
123E 3199 : Compute and save the number of bytes in the transmit buffer.
123E 3200 :
123E 3201 : R9 -> end of data in the transmit buffer
123E 3202 :
123E 3203 :
123E 3204 : There is a special case where the XMIT buffer can be taken,
123E 3205 : and that is when the circuit is halted. So if the circuit is
123E 3206 : in the HALT state, then we can assume we no longer have the
123E 3207 : XMIT buffer that we copied data into.
123E 3208 :
123E 3209 $DISPATCH CSB_B_STATE(R8),TYPE=B,- ; Dispatch on our CSB state
123E 3210 <- : state : action
123E 3211 <CSB_C_STATE_HALT LTSREPLY_DONE>,- ; All done, exit
123E 3212 >
1245 3213
5D A8 95 1245 3214 TSTB CSB_B_NUM_SLOTS(R8) ; Are there any slots?
04 12 1248 3215 BNEQ 80$ ; Br if yes, continue
01 8A 124A 3216 BICB #FLAG M RRF,- ; Else, clear RRF flag
5C A8 124C 3217 CSB_B_FLAG(R8)
51 34 A8 D0 124E 3218 80$: MOVL CSB_B_XBUFQ(R8), R1 ; Address of buffer
1C A1 59 D0 1252 3219 MOVL R9,-CXBSL_T_ENDADR(R1) ; Save end address of data
1256 3220 .DSABL LSB

```



```

1256 3222      .SBTTL SEND REPLY RESPONSE TO RECEIVED MESSAGE
1256 3223
1256 3224 LTSREPLY_MSG:
1256 3225      :
1256 3226      : We come here to transmit a new frame in response to a received frame
1256 3227      :
1256 3228      R8 = CSB address
1256 3229      :
59  34 AB  D0 1256 3230      MOVL CSB_Q_XBUFQ(R8),R9      ; Transmit buffer address
125A 3231
125A 3232 LTSREPLY_ALT:
125A 3233      :IF DEFINED LT_XMT_CHECK
125A 3234      :
125A 3235      : Debug code
125A 3236      :
125A 3237      : check the format of the slots and make sure that they are
125A 3238      : well formatted.
125A 3239      :
125A 3240      R8 = CSB address
125A 3241      R9 = transmit buffer address
125A 3242      R0-R3 clobbered
125A 3243      :
125A 3244      MOVAQ CSB_Q_XBUFQ(R8), R0      ; Address of transmit head
125A 3245      CMPL  R9, R0                    ; Is there a transmit buffer
125A 3246      BNEQ  5$                        ; Nope, its the queue head
125A 3247      DEBUG                                ; Can't be the queue head
125A 3248
125A 3249 5$:      MOVQ  CSB_T_CIRCHDR(R8),-   ; Move the circ header
125A 3250      XMT_T_DATA(R9)                    ; to look at real msg
125A 3251      CMPB  XMT_B_FLAG(R9),-           ; Only analyse running msgs
125A 3252      #MTP_C_RUN@FLAG_V_MTYPE         ; with slots
125A 3253      BNEQ  50$                          ; Not a running message
125A 3254      MOVL  CXBSL_T_ENDADR(R9), R2
125A 3255      MOVAB XMT_T_MDATA(R9), R0        ; First slot address
125A 3256      MOVZBL XMT_B_NUM_SLOTS(R9), R1   ; number of valid slots
125A 3257      BNEQ  10$                          ; We have some
125A 3258      ; No slot - message must only have a circuit header!
125A 3259      CMPL  R2, R0                    ; Only circuit header?
125A 3260      BEQL  50$                          ; Br if yes, okay
125A 3261      DEBUG                                ; Not correct
125A 3262      BRB  50$
125A 3263
125A 3264 10$:     MOVZBL SLT_B_COUNT(R0), R3   ; Look to next slot
125A 3265      BGEQ  30$                          ; Must be greater or zero
125A 3266      DEBUG                                ; Maxc not valid
125A 3267 30$:     ADDL  #SLT_T_DATA, R3        ; Slot header length
125A 3268      ADDL  R3, R0
125A 3269      INCL  R0
125A 3270      BICL  #1, R0
125A 3271      CMPL  R0, R2
125A 3272      BLEQU 40$                          ; Still inside buffer?
125A 3273      DEBUG                                ; Yep
125A 3274 40$:     SOBGTR R1, 10$            ; Slot beyond buffer
125A 3275 50$:     ; Check all slots
125A 3276      .ENDC      ;; DEFINED LT_XMT_CHECK
125A 3277
54  58  D0 125A 3278      MOVL  R8, R4                        ; CSB address to r4
  
```

```

080F 30 125D 3279          BSBW  LTSXMIT          ; Transmit the buffer
      1260 3280
3FFE 8F BA 1260 3281  LTSREPLY_DONE:      ; All done
      05 1260 3282          POPR  #^M<R1,R2,R3,R4,R5,R6,R7,R8,R9,R10,R11,AP,FP> ; Restore registers
      1264 3283          RSB
      1265 3284
      1265 3285
      1265 3286  LTSREPLY_REXMIT:
      1265 3287          :
      1265 3288          Retransmit last message
      1265 3289          :
      1265 3290          R8 = CSB address
      1265 3291          :
54   58  D0 1265 3292          MOVL  R8, R4          ; CSB address to R4
      0869 30 1268 3293          BSBW  LTSREXMIT      ; Transmit all waiting buffers
      F3   11 1268 3294          BRB   LTSREPLY_DONE  ; Finish up
      126D 3295

```

```

126D 3297 .SBTTL LT$CREATECSB - Create a CSB
126D 3298 :++
126D 3299 LT$CREATECSB - Create a CSB
126D 3300
126D 3301 Allocate a CSB for use and initialize it partially.
126D 3302
126D 3303 Inputs:
126D 3304 R4 -> next entry in CSB table beyond the one that is free
126D 3305 R1 = length of UCB list at end of CSB
126D 3306
126D 3307 Outputs:
126D 3308 R8 = new CSB address
126D 3309 R0 = success or failure
126D 3310
126D 3311 CSB table entry set to its address
126D 3312
126D 3313 R1-R2 are destroyed.
126D 3314 :--
126D 3315
126D 3316 LT$CREATECSB:
00000070 8F C0 126D 3317 ADDL #CSB_C_FIXLENGTH+4,R1 ; Add in size of fixed block +
51 1273 ; one "no access" UCB slot
53 DD 1274 3318 PUSHL R3 ; Save R3
00000000 GF 16 1276 3319 JSB G^EXESALONONPAGED ; Get block
53 8ED0 127C 3320 POPL R3 ; Restore R3
4D 50 E9 127F 3321 BLBC R0, 10$ ; Got block
00 6E 00 BB 1282 3322 PUSHR #^M<R1,R2,R3,R4,R5> ; Save registers
62 51 2C 1284 3323 MOVCS #0,(SP),#0,R1,(R2) ; Zero block
3E BA 1288 3324
08 A2 51 B0 128A 3325 POPR #^M<R1,R2,R3,R4,R5> ; Restore registers
0A A2 33 90 128C 3326 MOVW R1,CSB_W_SIZE(R2) ; Save size of CSB in CSB
50 EDA0 CF DE 1290 3327 MOVB #DYN$C-CDB, - ; Store an unlikely type in the
50 54 50 C3 1294 3328 CSB_B_TYPE(R2) ; the block
50 50 04 C6 1294 3329 MOVAL GHB_L_CSBTABLE, R0 ; Create the slave index from the
60 A2 50 90 1294 3330 SUBL3 R0,-R4, R0 ; address in the CSB table
68 A2 50 90 129D 3331 DIVL2 #4, R0 ; from 1 to n
EOB CF 40 90 12A0 3332 MOVB R0, CSB_B_LOCIDN(R2) ; and save it in the CSB
61 A2 90 12A4 3333 MOVB R0, CSB_B_INX(R2) ; Save it here also
12AD 3334 MOVB GHB_B_LOC_CCHK[R0],- ; Obtain the check field for this
12AF 3335 CSB_B_LOCIDS(R2) ; CSB slot
12AF 3336 ;
12AF 3337 ; Initialize queue headers
12AF 3338 ;
50 34 A2 9E 12AF 3339 MOVAB CSB_Q_XBUFQ(R2), R0 ; Initialize the queue headers for the
60 50 D0 12B3 3340 MOVL R0,-(R0) ; transmit buffers
04 A0 50 D0 12B6 3341 MOVL R0, 4(R0)
50 3C A2 9E 12BA 3342 MOVAB CSB_Q_XWAITQ(R2), R0
60 50 D0 12BE 3343 MOVL R0,-(R0)
04 A0 50 D0 12C1 3344 MOVL R0, 4(R0)
58 52 D0 12C5 3345 MOVL R2, R8
74 52 D0 12C8 3346 MOVL R2,-(R4)
50 00 8F 9A 12CB 3347 MOVZBL #SS$_NORMAL, R0
05 12CF 3348 RSB

```

```

12D0 3350      .SBTTL  LTSNEW_CIRCUIT - Get Concentrator State Block
12D0 3351      :++
12D0 3352      : LTSNEW_CIRCUIT - Get concentrator state block and initialize it
12D0 3353      :
12D0 3354      : Functional description:
12D0 3355      :
12D0 3356      : Whenever a frame with a zero svci is seen and the circuit state is
12D0 3357      : starting, we attempt to allocate a CSB and start a circuit. First
12D0 3358      : we check for a CSB with the same source address. If any are found
12D0 3359      : and the mvci matches and the state is starting, then we retransmit
12D0 3360      : our starting message for that circuit. If the other things are not
12D0 3361      : true, then the circuit is clobbered to that source since the mvci
12D0 3362      : does not match or the circuit is already running and the concentrator
12D0 3363      : is trying to restart it perhaps because it rebooted.
12D0 3364      :
12D0 3365      : Inputs:
12D0 3366      :     R3 = CXB address
12D0 3367      :     R6 = receive buffer address
12D0 3368      :     R10 = IDB address
12D0 3369      :
12D0 3370      : Outputs:
12D0 3371      :     R6 = receive buffer address
12D0 3372      :     R8 = CSB address
12D0 3373      :     R0,R1,R2,R3,R4,R7 and R9 are modified
12D0 3374      :--
12D0 3375      :
12D0 3376      LTSNEW_CIRCUIT:
12D0 3377      MOVAB  GHB_L_CSBTABLE,R4      ; Find free entry in CSB_TABLE
12D0 3378      MOVZBL #LATSC_MAX_CSBS,R2   ; Length of table in longwords
12D0 3379      10$:  MOVL  (R4)+,R8        ; Get CSB address
12D0 3380      BEQL  30$                  ; Ignore unallocated ones for pass
12D0 3381      :
12D0 3382      : If this is the same source address, then we are looking for a duplicate
12D0 3383      : starting message. It will have the same local index and a state of
12D0 3384      : starting. If this is not the case, then just clobber the circuit.
12D0 3385      :
12D0 3386      12DD 3386      CMPL  CXBSQ_STATION(R3),-   ; NI source address match?
12D0 3387      12E0 3387      CSB_Z_DST(R8)
12D0 3388      12E2 3388      BNEQ  30$                  ; Br if not, look for more
12D0 3389      12E4 3389      CMPW  CXBSQ_STATION+4(R3),-   ; Rest match too?
12D0 3390      12E7 3390      CSB_Z_DST+4(R8)
12D0 3391      12E9 3391      BNEQ  30$                  ; Br if not, look for more
12D0 3392      12EB 3392      CMPW  RCV_W_DSTID(R6),-   ; Is this a duplicate starting msg
12D0 3393      12EE 3393      CSB_W_LOCID(R8)           ; with the same local vc indx/seq?
12D0 3394      12F0 3394      BNEQ  20$                  ; Br if not, kill circuit
12D0 3395      12F2 3395      CMPB  CSB_B_STATE(R8),-   ; Is the state still starting?
12D0 3396      12F5 3396      #CSB_C_STATE_START
12D0 3397      12F6 3397      BNEQ  20$                  ; Br if not, kill circuit
12D0 3398      12F8 3398      MOVL  #2, R0
12D0 3399      12FB 3399      RSB
12D0 3400      12FC 3400      ; our starting message
12D0 3401      20$:  BSBW  LTSCIRCDEAD      ; Get rid of UCBs
12D0 3402      12FF 3402      MNEGL #1, CSB_Z_DST(R8)   ; Form illegal address
12D0 3403      1303 3403      MNEGW #1, CSB_Z_DST+4(R8) ; to stop next compare
12D0 3404      1307 3404      ;
12D0 3405      30$:  SOBGTR R2,10$      ; Try whole table
12D0 3406      ;
    
```

```

54  ED64 CF 9E
    52 20 9A
    58 84 D0
      2A 13
    28 A3 D1
    2E A8 12
    2C A3 B1
    32 A8 12
      1C 12
    02 A6 B1
    60 A8 12
      0A 12
    0B A8 91
      01 12
      04 12
    50 02 D0
      05 12
      042B 30
    2E A8 01 CE
    32 A8 01 AE
      1307
      CE 52 F5
    130A
    
```

:JAY0002
-1

:JAY0002
:JAY0002
:JAY0002
-3

				130A	3407
				130A	3408
				130A	3409
OF	EE89	CF	E0	130C	3410
54	ED24	CF	DE	1310	3411
	52	20	9A	1315	3412
		84	D5	1318	3413
		06	13	131A	3414
	F9	52	F5	131C	3415
				131F	3416
				131F	3417
				131F	3418
		50	D4	131F	3419
			05	1321	3420
				1322	3421
				1322	3422
				1322	3423
				1322	3424
				1322	3425
50	08	A6	9E	1322	3426
05	02	A0	91	1326	3427
				132A	3428
		F3	12	132A	3429
				132C	3430
				132C	3431
				132C	3432
				132C	3433
				132C	3434
				132C	3435
	06	A0	95	132C	3436
		EE	15	132F	3437
				1331	3438
				1331	3439
				1331	3440
				1331	3441
				1331	3442
				1331	3443
				1331	3444
				1331	3445
				1331	3446
				1331	3447
55	EDD7	CF	9A	1336	3448
55	04	A0	91	133A	3449
		04	1E	133C	3450
55	04	A0	90	1340	3451
51	55	02	78	1344	3452
				1344	3453
		FF26	30	1347	3454
		D5	50	134A	3455
69	A8	55	90	134E	3456
				134E	3457
				134E	3458
				134E	3459
50	08	A6	9E	1352	3460
51	0C	A0	9A	1356	3461
52	0D	A0	9E	135A	3462
	52	51	C0	135D	3463
	51	62	9A		

```

: Search failed, try to find a free CSB
BBS #GHB_STS V SHUT - ; Br if we are shutting down,
GHB_B STATUS, 50$ ; don't let connection succeed
MOVAL GHB_C CSBTABLE, R4 ; Look again for a free CSB
MOVZBL #LATSC_MAX_CSBS, R2 ; Set max CSBs
TSTL (R4)+ ; Is this slot free?
BEQL 60$ ; Br if yes, great
SOBGTR R2, 40$ ; Loop til done

: Return resource error
CLRL R0 ; Return failure indicating resource
RSB ; failure

60$:
: Check the protocol version of the incoming message and reject all but
: our own.
MOVAB RCV_T_MDATA(R6), R0 ; Address of first slot
CMPB STRT_B_PVER(R0), - ; Check version number
#LATSC_CUR_VER
BNEQ 50$ ; Must be equal

: Check the circuit timer value (in multiples of 10 ms).
: We will accept anything in the range 10 to 1270 ms; legal
: values are 1 to 127 in this byte field.
TSTB STRT_B_CIR_TIMER(R0) ; Is this field positive and non-zero?
BLEQ 50$ ; Br if not, illegal value

ECO is not checked
R4 -> CSB table address -4

: Compute size needed for UCB list at end of CSB,
: size is based on MIN [GHB_B_MAX_SLOTS, STRT_B_MAXSLOTS(R0)]
MOVZBL W^GHB_B_MAX_SLOTS, R5 ; Assume ours is MIN value
CMPB STRT_B_MAXSLOTS(R0), R5 ; Is rcvd slot count larger?
BGEQU 70$ ; Br if yes, use ours
MOV B STRT_B_MAXSLOTS(R0), R5 ; Else, use smaller of two
ASHL #2, R5, R1 ; Multiply by 4, and save in R1

BSBW LTSCREATECSB ; Create a CSB
BLBC R0, 50$ ; Br if resource error
MOV B R5, CSB_B_MAX_SLOTS(R8) ; Save the maximum allowed slot count

: Save the server's name
ASSUME STRT_B_SYS_LEN EQ STRT_T_NODE+GHB_SK_NAMELEN
MOVAB RCV_T_MDATA(R6), R0 ; Get address of first slot
MOVZBL STRT_B_NODE_LEN(R0), R1 ; Get length of dest node name
MOVAB STRT_T_NODEPTR(R0), R2 ; Get address of dest node name
ADDL R1, R2 ; Skip dest node name, point to src name
MOVZBL (R2), R1 ; Get length of src (server) name

```

10	51	D1	1360	3464	CMP	R1,#GHBSK_NAMELEN	: Is the name length okay?		
	06	15	1363	3465	BLEQ	758	: Br if yes, continue		
51	10	9A	1365	3466	MOVZBL	#GHBSK_NAMELEN,R1	: Else, use maximum allowed		
62	51	90	1368	3467	MOVB	R1,(R2)	: Make size of name valid		
	51	D6	1368	3468	INCL	R1	: Account for length byte		
	09	BB	136D	3469	PUSHR	#*M<R0,R3>	: Save registers		
62	51	28	136F	3470	MOV3	R1,(R2),CSB_B_SERVER(R8)	: Copy the server name		
	1C	A8	1372						
	09	BA	1374	3471	POPR	#*M<R0,R3>	: Restore registers		
			1376	3472					
			1376	3473					
			1376	3474					
			1376	3475					
			1376	3476	MOVW	#3600,CSB_W_TIMRESET(R8)	: Assume a default of one hour		
0E10	8F	B0	1376	3476					
	66	A8	137A						
51	07	A0	137C	3477	MOVZBL	STRT_B_KPA_TIMER(R0),R1	: Make timer reset value		
	11	13	1380	3478	BEQL	808	: Not a good value		
51	05	C4	1382	3479	MULL2	#5,R1	: Look for five times the period,		
	51	D6	1385	3480	INCL	R1	: and one more		
55	51	3C	1387	3481	MOVZWL	R1,R5	: Check for overflow		
55	51	D1	138A	3482	CMP	R1,R5	: Did we overflow?		
	04	12	138D	3483	BNEQ	808	: Br if yes, use default value		
66	A8	51	138F	3484	MOVW	R1,CSB_W_TIMRESET(R8)	: Set the value in the CSB		
			1393	3485					
			1393	3486					
			1393	3487					
05D4	8F	B0	1393	3488	MOVW	#XMT_C_MAXDATA,-	: Assume ours is maximum allowed		
	6A	A8	1397	3489		CSB_W_MAX_MSGSIZ(R8)	: message size		
	08	A2	1399	3490	SUBW	#XMT_C_HDRLEN,-	: Account for header is remotes size		
	60		139B	3491		STRT_B_MSGSIZ(R0)			
	0A	15	139C	3492	BLEQ	908	: Br if not large enough		
	60	B1	139E	3493	CMPL	STRT_W_MSGSIZ(R0),-	: Is remotes buffer larger?		
	6A	A8	13A0	3494		CSB_W_MAX_MSGSIZ(R8)			
	04	1E	13A2	3495	BGEQU	908	: Br if yes, use ours		
	60	B0	13A4	3496	MOVW	STRT_W_MSGSIZ(R0),-	: Else, use smaller of two		
	6A	A8	13A6	3497		CSB_W_MAX_MSGSIZ(R8)			
			13A8	3498					
			13A8	3499					
			13A8	3500					
5E	A8	04	A6	B0	13A8	3501	MOVW	RCV_W_SRCID(R6),CSB_W_REMID(R8)	: In case of retransmit
	5D	A8	94	13AD	3502	CLRB	CSB_B_NUM_SLOTS(R8)	: Mode default is balanced	
	52	A8	B4	13B0	3503	CLRW	CSB_W_XMTTMO(R9)	: Not timed state	
	66	A8	B0	13B3	3504	MOVW	CSB_W_TIMRESET(R8),-	: Set a nonzero timeout value	
	50	A8		13B6	3505		CSB_B_TIMEOUT(R8)	: even if the normal value is zero.	
	2D	A8	94	13B8	3506	CLRB	CSB_B_REFC(R8)	: No UCBs here	
	14	B0	13BB	3507	MOVW	#LATSC_PROGRESS,-	: Set for allowing progress		
	54	A8		13BD	3508		CSB_W_PROGRESS(R8)	: while we start up.	
				13BF	3509				
	28	A3	D0	13BF	3510	MOVL	CXBSQ_STATION(R3),-	: Store remotes's NI address.	
	2E	A8		13C2	3511		CSB_Z_DST(R8)		
	2C	A3	B0	13C4	3512	MOVW	CXBSQ_STATION+4(R3),-	: ...	
	32	A8		13C7	3513		CSB_Z_DST+4(R8)		
	00	90	13C9	3514	MOVB	#CSB_C_STATE_HALT,-	: Circuit is halted		
	0B	A8		13CB	3515		CSB_B_STATE(R8)		
62	A8	01	AE	13CD	3516	MNEGW	#1,CSB_W_XSEQ(R8)	: Initialize transmit sequence	
	FF00	8F	B0	13D1	3517	MOVW	#<-128!05,CSB_W_RSEQ(R8)	: Initialize receive sequence	
	64	A8		13D5					

```

13D7 3518
13D7 3519
13D7 3520
54 58 AB 94 13D7 3521
59 AB 94 13DA 3522
34 AB DE 13DD 3523
55 02 9A 13E1 3524
13E4 3525
13E4 3526 100$:
00000000 GF 16 13E9 3527
25 50 E9 13EF 3528
08 A2 51 B0 13F2 3529
13F6 3530
0A A2 1B B0 13F6 3531
13FA 3532
13FA 3533
0C A2 58 D0 13FA 3534
2E AB 7D 13FE 3535
28 A2 1401 3536
48 A2 7C 1403 3537
0048 8F B0 1406 3538
18 A2 140A 3539
64 62 0E 140C 3540
D2 55 F5 140F 3541
1412 3542
50 00'8F 9A 1412 3543
05 1416 3544
1417 3545
1417 3546
1417 3547
1417 3548
54 58 D0 1417 3549 110$:
0003 30 141A 3550
50 D4 141D 3551
05 141F 3552
1420 3553
: Obtain all necessary transmit buffers for use
:
CLRB CSB_B_XMTBSY(R8) : Not busy transmitting
CLRB CSB_B_XMTCNT(R8) : No buffers waiting to transmit
MOVAL CSB_Q_XBUFQ(R8), R4 : Address of the transmit queue head
MOVZBL #LATSC_XMT_BUFFERS, R5 : Set number of buffers
:
MOVZWL #XMT_C_MAXLEN, R1 : Size of the buffers
JSB G^EXESALONONPAGED : Allocate the buffer
BLBC R0, 110$ : No such buffer
MOVW R1, CXBSW_SIZE(R2) : Store the size,
ASSUME CXBSB_CODE EQ CXBSB_TYPE+1
MOVW #DYNST_CXB, - : the block type
CXBSB_TYPE(R2) : and indicate not multicast buffer
:
MOVL R8, CXBSL_T(CSB(R2)) : Save CSB address in CXB
MOVQ CSB_Z_DST(R8), - : Initialize the destination address
CXBSQ_STATION(R2)
CLRQ XMT_T_DATA(R2) : Zero circuit header
MOVW #XMT_T_DATA, - : Store offset to start of data
CXBSB_BOFF(R2)
INSQUE (R2), (R4) : Queue the buffer
SOBGTR R5, 100$ : for each of the buffers
:
MOVZBL #SSB_NORMAL, R0
RSB
:
: Resource error return
:
MOVL R8, R4 : Move the CSB address for the call
BSBW LT$DEALOCB : Clean up the CSB before we leave
CLRL R0 : Return an error
RSB

```

```

1420 3555 .SBTTL LT$DEALOCB - Deallocate a CSB
1420 3556 :++
1420 3557 : LT$DEALOCB
1420 3558 :
1420 3559 : FUNCTIONAL DESCRIPTION:
1420 3560 :
1420 3561 : Deallocate the transmit buffers.
1420 3562 :
1420 3563 : INPUTS:
1420 3564 : R4 = CSB address
1420 3565 :
1420 3566 : OUTPUTS:
1420 3567 : R0-R3 are destroyed
1420 3568 :
1420 3569 : --
1420 3570 :
1420 3571 LT$DEALOCB:
50 51 01 9A 1420 3572 MOVZBL #LATSC_XMT_BUFFERS-1,R1 : Get number of transmits -1
50 44 A441 D0 1423 3573 10$: MOVL CSB_L_XCB(R4)(R1), R0 : Is an FFI transmit in progress ?
: 03 13 1428 3574 BEQL 20$ : no
: OC A0 D4 142A 3575 CLRL CXB$L_T_CSB(R0) : Delete backpointer to CSB in CXB
50 F3 51 F4 142D 3576 20$: SOBGEQ R1,10$ : Loop if more
50 34 B4 OF 1430 3577 25$: REMQUE @CSB_Q_XBUFQ(R4), R0 : Now dump all the buffers
: 05 1D 1434 3578 BVS 30$ : No more buffers
: 07A0 30 1436 3579 BSBW LT$DEALPOOL : Dump a buffer
: F5 11 1439 3580 BRB 25$ :
: 143B 3581
50 3C B4 OF 143B 3582 30$: REMQUE @CSB_Q_XWAITQ(R4), R0 : Now dump all the waiters
: 05 1D 143F 3583 BVS 40$ : No more buffers
: 0795 30 1441 3584 BSBW LT$DEALPOOL : Dump a buffer
: F5 11 1444 3585 BRB 30$ :
: 1446 3586
53 68 A4 9A 1446 3587 40$: MOVZBL CSB_B_INX(R4), R3 : Find our place in the table
: 06 12 144A 3588 BNEQ 50$ : Great
: 144C 3589 DEBUG : Not properly initialized CSB
: 1452 3590
50 EC61 CF43 96 1452 3591 50$: INCB GHB_B_LOC CCHK[R3] : Bump the slot check digit
50 EBD8 CF43 DE 1457 3592 MOVAL GHB_L_CSBTABLE-4[R3],R0 : Address in table
: 54 60 D1 145D 3593 CMPL (R0), R4 : Check this address with the one
: 06 13 1460 3594 BEQL 60$ : we have.
: 1462 3595 DEBUG : Table is clobbered or CSB addr bad
: 1468 3596
: 60 D4 1468 3597 60$: CLRL (R0) : No CSB address here anymore
: 146A 3598 :
: 146A 3599 : We will now save this CSB on the OLD CSB queue, but we will
: 146A 3600 : have to remove an old entry if we exceed our limit.
: 146A 3601 :
50 54 D0 146A 3602 MOVL R4,R0 : Copy CSB address just in case
: 146D 3603 : we want to deallocate it
: OC A4 D5 146D 3604 TSTL CSB_Z_LCB+LCB_L_MSG_XMT(R4) : Any information in counters?
: 08 12 1470 3605 BNEQ 70$ : Br if yes, save it
: 10 A4 D5 1472 3606 TSTL CSB_Z_LCB+LCB_L_MSG_RCV(R4) : Any information in counters?
: 03 12 1475 3607 BNEQ 70$ : Br if yes, save it
: 008C 31 1477 3608 BRW 180$ : Else, nothing interesting here
: 147A 3609
: 147A 3610 70$: :
: 147A 3611 : We will now scan the CSB list for any old CSBs that match this
: : one, that way we will only save 1 entry per server.

```


51	ECC6	CF	9E	147A	3612		
	52	51	D0	147A	3613	MOVAB	@GHBSQ_OLD_CSBS+GHB_AREA,R1 ; Get listhead of old CSBs
	52	62	D0	147F	3614	MOVL	R1,R2 ;
	51	52	D1	1482	3615	MOVL	(R2),R2 ; ..twice
		68	D1	1485	3616	CMPL	R2,R1 ; Get next in queue
	2E	A4	D1	1488	3617	BEQL	100\$; Are we back to start?
	2E	A2		148A	3618	CMPL	CSB_Z_DST(R4),- ; Br if yes, no more - insert new entry
		F1	12	148D	3619		CSB_Z_DST(R2) ; Does the Ethernet address match?
	32	A4	B1	148F	3620	BNEQ	80\$; Br if no, try next
	32	A2		1491	3621	CMPW	CSB_Z_DST+4(R4),- ; Full address match?
		EA	12	1494	3622		CSB_Z_DST+4(R2)
	53	1C	A4	1496	3623	BNEQ	80\$; Br if no, try next
	1C	A2	53	1498	3624	MOVZBL	CSB_B_SERVER(R4),R3 ; Get length of server name
			E0	149C	3625	CMPB	R3,CSB_B_SERVER(R2) ; Lengths match?
			07	14A0	3626	BNEQ	80\$; Br if no, try next
	1D	A4	53	14A2	3627	PUSHR	#*M<R0,R1,R2> ; Save registers
		1D	A2	14A4	3628	CMPC3	R3,CSB_T_SERVER(R4),- ; Does the server name match?
			07	14A8	3629		CSB_T_SERVER(R2)
			D4	14AA	3630	POPR	#*M>R0,R1,R2> ;
				14AC	3631	BNEQ	80\$; Br if no, try next
				14AE	3632		
				14AE	3633		
				14AE	3634		Take sum of counters and store in CSB @ R2
				14AE	3635	ADD_CTR	CSB_Z_LCB+LCB_L_MSG_XMT(R4),- ; XMITs
				14AE	3636		CSB_Z_LCB+LCB_L_MSG_XMT(R2)
				14B9	3637	ADD_CTR	CSB_Z_LCB+LCB_L_MSG_RCV(R4),- ; RCVs
				14B9	3638		CSB_Z_LCB+LCB_L_MSG_RCV(R2)
				14C4	3639	ADD_CTR	CSB_Z_LCB+LCB_L_MSG_REXMT(R4),- ; REXMTs
				14C4	3640		CSB_Z_LCB+LCB_L_MSG_REXMT(R2)
				14CF	3641	ADD_CTR	CSB_Z_LCB+LCB_W_SEQ_ERR(R4),- ; SEQ_ERRs
				14CF	3642		CSB_Z_LCB+LCB_W_SEQ_ERR(R2),W
				14DA	3643	ADD_CTR	CSB_Z_LCB+LCB_B_INV_MSG(R4),- ; INV_MSGs
				14DA	3644		CSB_Z_LCB+LCB_B_INV_MSG(R2),B
				14E5	3645	ADD_CTR	CSB_Z_LCB+LCB_B_INV_SLOT(R4),- ; INV_SLOTS
				14E5	3646		CSB_Z_LCB+LCB_B_INV_SLOT(R2),B
		14	11	14F0	3647	BRB	180\$; And delete the CSB @ R4
				14F2	3648		
				14F2	3649		Insert new CSB into list
				14F2	3650		
	EC51	DF	64	14F2	3651	INSQUE	(R4), @GHBSQ_OLD_CSBS+ - ; Save CSB at end of CSB queue
				14F7	3652		GHB_AREA+4 ; since queue is time ordered
		EC9F	CF	14F7	3653	DECB	GHB_B_OLD_CSBCNT ; Use up one more slot on queue
			OC	14FB	3654	BGEQ	190\$; Br if still within CSB limits
		EC99	CF	14FD	3655	INCB	GHB_B_OLD_CSBCNT ; Else, restore count
	50	EC3F	DF	1501	3656	REMQUE	@GHBSQ_OLD_CSBS+ - ; Remove oldest entry
				1506	3657		GHB_AREA,R0
		06D0	30	1506	3658	BSBW	LT\$DEALPOOL ; Deallocate the CSB block
			05	1509	3659	RSB	

```

150A 3661 .SBTTL LT$CREATEUCB - Create an LT UCB
150A 3662 :++
150A 3663 : LT$CREATEUCB - Create an LT UCB
150A 3664 :
150A 3665 : Create a UCB by cloning it from the master UCB zero and
150A 3666 : initialize it as part of the io database. We can't lock
150A 3667 : the io database for write access, because we aren't a
150A 3668 : process. So we just do it and hope for the best. The
150A 3669 : modifications are such that code scanning the database will
150A 3670 : not be fooled if they are straight forward. It is possible
150A 3671 : to write code that will be confused when a new ucb appears,
150A 3672 : but we don't have any solution other than waiting for the
150A 3673 : the request to come here when the database is not locked.
150A 3674 : That would probably mean that many connection attempts would
150A 3675 : time out.
150A 3676 :
150A 3677 : NB !!
150A 3678 :
150A 3679 : The I/O data base is not locked!!
150A 3680 :
150A 3681 : Inputs:
150A 3682 : none
150A 3683 :
150A 3684 : Outputs:
150A 3685 : R5 = new UCB address
150A 3686 : R0 = success or failure
150A 3687 :
150A 3688 : R1-R4 clobbered
150A 3689 :--
150A 3690 :
150A 3691 LT$CREATEUCB:
150A 3692 MOVL GHB_L UCBO, R5 ; Get the UCB to clone from
150A 3693 JSB G^IOCS$CLONE_UCB ; Clone the UCB
150A 3694 BLBC R0,90$ ; Exit on error
150A 3695 MOVL R2,R5 ; Else, copy new UCB address
150A 3696 CLRW UCBSW_REF C(R5) ; No refs yet!
150A 3697 90$: RSB

```

```

55 EC72 CF DO
00000000'GF 16
06 50 E9
55 52 DO
5C A5 B4
05 151E

```

```

151F 3699 .SBTTL LT$DESTROYUCB - Destroy an LT UCB
151F 3700 :++
151F 3701 : LT$DESTROYUCB - Destroy an LT UCB
151F 3702 :
151F 3703 : Delete a ucb from the io data base that has been disconnected.
151F 3704 : This routine must be called at high IPL when the I/O database
151F 3705 : is not in use by anyone. We are going to deallocate a block
151F 3706 : and if anyone has its address in a register, we are going
151F 3707 : to go crash with a bang. This situation is not quite the
151F 3708 : same as the creation case where one can be much more cavalier.
151F 3709 :
151F 3710 : Also note, that we must ensure that the LT UCB has been detached
151F 3711 : from any VT UCB, and that the REFC has gone to zero. There is
151F 3712 : a condition where the class driver will not detach a VT UCB
151F 3713 : even though the disconnect entry point is called. This occurs if
151F 3714 : logout has not been run yet, but is about to be run. In this
151F 3715 : case, the class driver will not have detached the LT UCB from the
151F 3716 : VT UCB and we can check for that condition.
151F 3717 :
151F 3718 : NB !!!
151F 3719 : The I/O database is NOT locked for write access, BUT the MUTEX
151F 3720 : is available!
151F 3721 :
151F 3722 : Inputs:
151F 3723 : R5 = UCB to destroy
151F 3724 :
151F 3725 : Outputs:
151F 3726 : R5 = UCB address
151F 3727 : R0-R1 are destroyed.
151F 3728 :--
151F 3729 :
151F 3730 LT$DESTROYUCB:
00C0 C5 55 D1 151F 3731 CMPL R5,UCBSL_TT_LOGUCB(R5) ; Is this UCB ready for deletion?
12 12 1524 3732 BNEQ 50$ ; Br if no, requeue it
SC A5 B5 1526 3733 TSTW UCBSW_REFC(R5) ; All refs gone?
OD 12 1529 3734 BNEQ 50$ ; Br if no, requeue it
152B 3735 SETBIT #UCBSV_DELETEUCB, - ; Else, allow UCB to be deleted
152B 3736 UCBSL_STS(R5)
0000000'GF 16 1530 3737 JSB G^IOCSDELETE_UCB ; Delete the UCB
OE 11 1536 3738 BRB 90$ ; leave
1538 3739
0144 C5 04 90 1538 3740 50$: MOVB #UCBSC_LT_STATE_KILL,- ; Enter the KILL UCB state
153A 3741 UCBSB_LT_STATE(R5)
153D 3742 CLRBIT #UCBSV_LT_DEAD,- ; Clear the dead indicator
153D 3743 UCBSB_LT_LATSTS(R5)
014A 30 1543 3744 BSBW LT$HANGUP_UCB ; And hangup the UCB again!
05 1546 3745 90$: RSB ; Return

```

```

1547 3747 .SBTTL LTSALC_UCB - Allocate New LT UCB
1547 3748 :++
1547 3749 : LTSALC_UCB - Allocate a new LT UCB
1547 3750 :
1547 3751 : Subroutine to select a UCB for a slot.
1547 3752 :
1547 3753 : Inputs:
1547 3754 : R7 = receive buffer slot address
1547 3755 : R8 = CSB address
1547 3756 :
1547 3757 : Outputs:
1547 3758 : R0 = success or failure
1547 3759 : R5 = UCB address
1547 3760 : R7 = receive buffer slot address
1547 3761 : R8 = CSB address
1547 3762 : R1,R2,R3,R4 modified
1547 3763 :--
1547 3764 :
1547 3765 LTSALC_UCB:
50 D4 1547 3766 CLR R0 ; Return failure if no UCB
1549 3767
1549 3768 ::&& *TEMP* concentrator bug
1549 3769
54 6C A8 DE 1549 3770 MOVAL CSB_L_UCBLST(R8), R4 ; Search the list for this CSB
53 54 D0 154D 3771 MOVL R4, R3 ; Save the address
51 69 A8 9A 1550 3772 MOVZBL CSB_B_MAX_SLOTS(R8), R1 ; Get maximum in list
55 84 D0 1554 3773 1$: MOVL (R4)+, R5 ; Look in the table
OB 13 1557 3774 BEQL 2$ ; A free slot, my word
01 A7 91 1559 3775 CMPB SLT_B_SRCID(R7),- ; Is this the same terminal calling
0140 C5 155C 3776 UCBSB_LT_REMID(R5) ; again?
03 12 155F 3777 BNEQ 2$ ; No, then continue
010C 31 1561 3778 BRW 95$ ; Yes, then setup message again
ED 51 F5 1564 3779 2$: SOBGTR R1, 1$ ; look again
1567 3780
1567 3781 ::&& *TEMP* concentrator bug
1567 3782
1567 3783
54 6C A8 DE 1567 3784 MOVAL CSB_L_UCBLST(R8), R4 ; Search the list for this CSB
53 54 D0 156B 3785 MOVL R4, R3 ; save the address
51 69 A8 9A 156E 3786 MOVZBL CSB_B_MAX_SLOTS(R8), R1 ; Get maximum in list
55 84 D0 1572 3787 10$: MOVL (R4)+, R5 ; Look in the table
06 13 1575 3788 BEQL 20$ ; A free slot, my word
F8 51 F5 1577 3789 SOBGTR R1, 10$ ; look again
00F2 31 157A 3790 15$: BRW 90$ ; None to be had here, so fail
157D 3791
02 A7 91 157D 3792 20$: CMPB SLT_B_COUNT(R7),- ; Is slot big enough?
05 1580 3793 #<SLT_B_DST_NAMLEN-SLT_T_DATA>+2
0A 18 1581 3794 BGEQ 30$ ; Br if yes, okay
ED 11 1583 3795 INC_CTR CSB_Z_LCB+LCB_B_INV_SLOT(R8) ; Else, say invalid slot
158B 3796 BRB 15$ ; And exit
158D 3797
54 54 DD 158D 3798 30$: PUSHL R4 ; Save the address in table
53 53 C2 158F 3799 SUBL2 R3, R4 ; Compute the index for this CSB
54 04 C6 1592 3800 DIVL2 #4, R4 ; as a small integer
54 54 DD 1595 3801 PUSHL R4 ; Save the index too
FF70 30 1597 3802 BSBW LTS_CREATEUCB ; Create a raw lt UCB
54 BED0 159A 3803 POPL R4 ; Obtain the index

```

```

53 8ED0 159D 3804      POPL      R3      ; and its address in CSB table
      15A0 3805      ;
      D7 50  E9 15A0 3806      BLBC      R0, 15$      ; Do we have one?, nope, too bad
      73 55  D0 15A3 3807      MOVL      R5, -(R3)    ; Store its address in CSB table
      F4F2 30 15A6 3808      BSBW      LT$UCB INIT  ; Initialize the ucb
0141 C5 54 90 15A9 3809      MOVB      R4, UCBSB_LT_LOCID(R5) ; Set local slot index
      01  A7 90 15AE 3810      MOVB      SLT_B_SRCID(R7), - ; Load remote circuit id
      0140 C5 15B1 3811      UCBSB_LT REMID(R5) ;
      04 00  EF 15B4 3812      EXTZV     #0, #4, SLT_B_CRED(R7), R0 ; Get credit total extended
      50 03  A7 15B7 3813      ADDB3     #1, R0, UCBSB_LT_TCRED(R5); Give ourself an extra credit for
      50 01  81 15BA 3814      ; sending the start slot
0146 C5 15BD 3815      MOVB      #SLT_C_STR_SLOT@4!LATSC_MAX_RCRED, - ; Set slot type and credits
      91 8F 90 15C0 3816      UCBSB_LT RCRED(R5) ;
0148 C5 15C3 3817      MNEGB     #LATSC_MAX_RCRED, - ; Set credits extended to remote end
      01 01  8E 15C6 3818      UCBSB_LT XCRED(R5) ; kept as negative value
0147 C5 15C8 3819      CLRW     UCBSW_ERRCNT(R5) ; Reset the error counter that
0082 C5  B4 15CB 3820      BISW      #<UCBSM INT!- ; we bump as we shut down.
      AB 15CF 3821      UC9SM_ONLINE>, - ; Expecting interrupts & online
      64 A5 12 15D0 3822      UCBSL_STS(R5) ;
0134 C5 58  D0 15D3 3823      MOVL      R8, UCBSL_LT_CSB(R5) ; Load CSB address
      2D AB 96 15D8 3824      INCB     CSB_B_REFC(R8) ; One more UCB here
      15DB 3825      ;
      15DB 3826      ;
      15DB 3827      ; Compute maximum allowed slot size
      FF 8F 90 15DB 3828      ;
0149 C5 15DE 3829      MOVB      #LATSC_MAX_SLOTSIZ, - ; Assume ours is the maximum
      06 A7 91 15E1 3830      UCBSB_LT SLOTSZ(R5) ; slot size
0149 C5 15E4 3831      CMPB     SLT_B_DT_SLTSIZ(R7), - ; Is remotes size smaller?
      06 06 1E 15E7 3832      UCBSB_LT_SLOTSZ(R5) ;
      06 A7 90 15E9 3833      BGEQU     40$ ; Br if no, use ours
0149 C5 15EC 3834      MOVB      SLT_B_DT_SLTSIZ(R7), - ; Else, take remotes
      0144 C5 90 15EF 3835      UCBSB_LT_SLOTSZ(R5) ;
      05 02 90 15F1 3836      40$: MOVB      #UCBSC_LT_STATE_RUN, - ; Set the initial state to RUN
0148 C5 90 15F4 3837      UCBSB_LT_STATE(R5) ;
      55 DD 15F6 3838      MOVB      #GHB_C_STRT_SLOTL, - ; Build a start slot
      05 28 15F9 3839      UCBSB_LT_CORC(R5) ;
      EE B1 CF 15FB 3840      PUSHL    R5 ; Save UCB address
014C C5 15FD 3841      MOVCS    #GHB_C_STRT_SLOTL, - ; Make it look like output data
      55 8ED0 1600 3842      GHB_T_STRT_SLOT, - ;
      01 88 1603 3843      UCBSB_LT_CBUF(R5) ;
0142 C5 1606 3844      POPL     R5 ; Save UCB address
      1608 3845      BISB     #UCBSM_LT_DATA, - ; Force data through output slot
      160B 3846      UCBSB_LT_DATAW(R5) ;
      160B 3847      ;
      160B 3848      ; Check for the disable login flag
      51 07 A7 9E 160B 3849      ;
      50 81 9A 160F 3850      MOVAB     SLT_B_DST_NAMLEN(R7), R1 ; Skip to dest. slot name field
      51 50 C0 1612 3851      MOVZBL   (R1)+, R0 ; Get size of dest. name field
      50 81 9A 1615 3852      ADDL     R0, R1 ; Skip the dest. name field
      51 50 C0 1618 3853      MOVZBL   (R1)+, R0 ; Get size of src name field
      50 04 A7 9E 161B 3854      ADDL     R0, R1 ; Skip the src name field
      52 51 50 C3 161F 3855      MOVAB     SLT_T_DATA(R7), R0 ; Compute size of slot skipped
      50 02 A7 9A 1623 3856      SUBL3    R0, R1, R2 ;
      50 52 C2 1627 3857      MOVZBL   SLT_B_COUNT(R7), R0 ; Get size of entire slot
      SUBL   R2, R0 ; Compute bytes remaining

```

```

52 30 15 162A 3859 BLEQ 70$ ; Br if no more data, do login
    81 9A 162C 3860 60$: MOVZBL (R1)+,R2 ; Get parameter code
    28 13 162F 3861 BEQL 70$ ; Br if none, assume auto-login
    50 D7 1631 3862 DECL R0 ; One less byte left
    27 15 1633 3863 BLEQ 70$ ; Br if no more data, do login
53 81 9A 1635 3864 MOVZBL (R1)+,R3 ; Get size of parameter
50 53 C2 1638 3865 SUBL R3,R0 ; Get remaining byte count
    1F 15 163B 3866 BLEQ 70$ ; Br if no more data, do login
54 51 D0 163D 3867 MOVL R1,R4 ; Save current parameter address
51 53 C0 1640 3868 ADDL R3,R1 ; Skip to next parameter
01 52 D1 1643 3869 CMPL R2,#SLT_C_START_FLAG ; Is this the start slot flag byte?
    E4 12 1646 3870 BNEQ 60$ ; Br if no, look for next
OC 64 02 E1 1648 3871 BBC #SLT_FLAG_V_BIND,(R4),65$ ; Br if not a bind request
    164C 3872 CLRBIT #TT2SV_HANGUP,- ; Else, set terminal to NOHANGUP
    164C 3873 UCBSL TT_DECHA1(R5) ; on logout
    1652 3874 SETBIT #UCBSV_LT_BOUND,- ; Don't delete UCB after STOP slot
    1652 3875 UCBSB CT_CATSTS(R5) ; ... only if we must KILL the UCB!
OF 64 01 E0 1658 3876 65$: BBS #SLT_FLAG_V_LOGIN,(R4),80$ ; Br if login is disabled
    165C 3877 ;
    165C 3878 ; Ask the class driver to log us in
    165C 3879 ;
51 0114 C5 D0 165C 3880 70$: MOVL UCBSL_TT_CLASS(R5), R1 ; Class dispatch vector
00002000 8F D0 1661 3881 MOVL #1013, R3 ; Framing error with zero byte
    53 1667
    14 B1 16 1668 3882 JSB @CLASS_READERROR(R1) ; Cause read error
50 00'8F 9A 166B 3883 80$: MOVZBL #SS$_NORMAL, R0 ; Do we have a UCB for you.
    05 166F 3884 90$: RSB
    1670 3885
    1670 3886 ;:88 *TEMP* concentrator bug
    1670 3887
    1670 3888 95$: SETBIT #GHBSV_REPCREATE,- ; Set mask bit
    1670 3889 GHBSL_PROTOMASK+GHB_AREA ; Repeat create of slot
FF6C 31 1676 3890 INC_CTR GHBSL_PROTOCOL+GHB_AREA ; Increment protocol error counter
    1680 3891 BRW 40$
    1683 3892 ;:88 *TEMP* concentrator bug

```

```

1683 3894      .SBTTL  LASHANGUP_UCB - Cause Terminal Hangup On UCB
1683 3895      :++
1683 3896      : LASHANGUP_UCB - Hangup an LT UCB
1683 3897      :
1683 3898      : Cause all the hangup effects on a terminal device. This should cause
1683 3899      : process rundown and deallocation of all channels to the UCB.
1683 3900      :
1683 3901      : Inputs:
1683 3902      :     R5 = UCB address
1683 3903      :
1683 3904      : Outputs:
1683 3905      :     none.
1683 3906      :
1683 3907      :--
1683 3908      .ENABL  LSB
1683 3909      LASHANGUP_UCB_NOW:
1683 3910      :
1683 3911      : Dispatch on UCB (slot) state
1683 3912      :
1683 3913      $DISPATCH UCBSB_LT_STATE(R5),TYPE=B,-
1683 3914      <-      : state      : action
1683 3915      <UCBSC_LT_STATE_STOP  LASKILLUCB>,-      : Already disconnected,
1683 3916      >
1688 3917      :
1688 3918      : Else
1688 3919      :
1688 3920      MOVB  #UCBSC_LT_STATE_KILL,-      : Enter the KILL UCB state
1688 3921      UCBSB_LT_STATE(R5)
1690 3922      :
1690 3923      LASHANGUP_UCB:
1690 3924      PUSHR #*M<R0,R1,R2,R3,R4>      : Save registers
1692 3925      BICW  #UCBSM_INT,UCBSL_STS(R5)  : No interrupt expected (allows
1696 3926      : STARTIO to be called again
1696 3927      : to flush data).
1696 3928      SETBIT #UCBSV_LT_HANGUP,-      : Indicate that we're shutting
1696 3929      UCBSB_LT_LATSTS(R5)            : down
169C 3930      MOVL  UCBSL_TT_CLASS(R5),R0      : Class driver vector address
16A1 3931      JSB  @CLASS_DISCONNECT(R0)      : Call routine
16A4 3932      POPR  #*M<R0,R1,R2,R3,R4>      : Restore the regs
16A6 3933      90$:  RSB
16A7 3934      :
16A7 3935      .DSABL  LSB
    
```

0144 04 90 C5
 64 A5 02 BB AA
 50 0114 C5 D0
 18 B0 16
 1F BA
 05

```

16A7 3937      .SBTTL LTSDISCONNECT - Port Disconnect
16A7 3938      :++
16A7 3939      : LTSDISCONNECT - Disconnect the terminal Port driver
16A7 3940      :
16A7 3941      : Port driver entry to disconnect a terminal. called when
16A7 3942      : Last reference is gone. here we free the slot in the buffer
16A7 3943      : And bump the sequence number. also we set the UCB offline.
16A7 3944      :
16A7 3945      : Inputs:
16A7 3946      : R5 = UCB address
16A7 3947      : R0 -> lbc = delete UCB
16A7 3948      : R0 -> lbs = do not delete UCB
16A7 3949      :
16A7 3950      : Outputs:
16A7 3951      : R5 = UCB address
16A7 3952      : All other registers are preserved.
16A7 3953      :
16A7 3954      : Implicit inputs:
16A7 3955      : UCBSB_LT_STATE = KILL -> kill UCB immediately.
16A7 3956      : STOP -> send stop slot, then kill UCB.
16A7 3957      : ??? -> all others, set to STOP state.
16A7 3958      :
16A7 3959      :--
16A7 3960      :
16A7 3961      : LTSDISCONNECT:
16A7 3962      :
16A7 3963      : Do not touch the UCB if it is the template UCBO
16A7 3964      :
16A7 3965      : Cmpl R5,GMB_L_UCBO ; Is this the template ucb ?
EAD4 CF 55 D1 16A7 3965      : BEQL 90$ ; Br if yes, don't touch it!
27 13 16AC 3966      :
16AE 3967      :
16AE 3968      : Dispatch on our UCB state
16AE 3969      :
16AE 3970      : $DISPATCH UCBSB_LT_STATE(R5),TYPE=B,-
16AE 3971      : <- : state : action
16AE 3972      : <UCBSB_LT_STATE_KILL 50$>,- ; KILLED, just kill the UCB now
16AE 3973      : <UCBSB_LT_STATE_STOP 90$>,- ; STOPed, we've been here before
16AE 3974      : >
16B8 3975      :
16B8 3976      : ; ALL other states,
16B8 3977      :
16B8 3978      : If the circuit is gone, or there is no CSB for the UCB
16B8 3979      : then just delete the UCB immediately
16B8 3980      :
0134 C5 D5 16B8 3980      : fSTL UCBSL_LT_CSB(R5) ; Do we have a circuit?
14 13 16BC 3981      : BEQL 50$ ; Br if none
16BE 3982      :
16BE 3983      : Conditionally skip deallocation of UCB, on "hangup".
16BE 3984      :
14 50 E8 16BE 3985      : BLBS R0,90$ ; Br if not to "hangup" UCB
10 AA 16C1 .1 ; No longer ONLINE
64 A5 16C3 .2 ; so no one can use again
03 90 16C5 3986      : MOVB #UCBSB_LT_STATE_STOP,- ; Else, set STOP state,
0144 C5 16C7 3987      : UCBSB_LT_STATE(R5) ; to send STOP slot
16CA 3988      :
16CA 3989      : Make sure that no data is given to CLASS driver, after
16CA 3990      : we've been here!
16CA 3991      :

```

:JAY0001
:JAY0001

		16CA	3992		SETBIT	#UCBSV_LT_HANGUP,-	:	Indicate that we're shutting
		16CA	3993			UCBSB_LT_LATSTS(R5)	:	down
03	11	16D0	3994		BRB	90\$:	Delete UCB when STOP is sent!
		16D2	3995				:	
0001	30	16D2	3996	50\$:	BSBW	LT\$KILLUCB	:	Get rid of the UCB now
		16D5	3997				:	
	05	16D5	3998	90\$:	RSB		:	Done
		16D6	3999				:	

```

16D6 4001 .SBTTL LTSKILLUCB - Delete a dried up UCB
16D6 4002 :++
16D6 4003 : LTSKILLUCB - Delete an LT UCB
16D6 4004 :
16D6 4005 : The UCB is all dried up one way or another. So we must delete it if
16D6 4006 : possible, else put it on the deadlink list to be deleted on the next
16D6 4007 : timer tick.
16D6 4008 :
16D6 4009 : Inputs:
16D6 4010 : R5 = UCB address
16D6 4011 :
16D6 4012 : Outputs:
16D6 4013 : R5 = UCB address
16D6 4014 : All other registers preserved.
16D6 4015 :
16D6 4016 :--
16D6 4017 :
16D6 4018 LTSKILLUCB:
1F BB 16D6 4019 PUSH  #*M<R0,R1,R2,R3,R4> : Save some volatile regs
AA 16D8 4020 BICW  #<UCBSM INT! - : No interrupt expected
64 A5 12 16D9 4021 UCBSM_ONLINE>,- : Not online, but free now
F57A 30 16D9 4022 UCBSL_STS(R5) : For use again
0027 30 16DC 4023 LTSFLUSH DATA : Flush all output data
12 0143 C5 E3 16DF 4024 LTSIDELINEUCB : Set the UCB aside from the circuit
16E2 4025 #UCBSV LT DEAD,- : If we already linked UCB to deadlist
16E4 4026 UCBSB [T [ATSTS(R5),20S : then we have made an error
16E8 4027 SETBIT #GHBSV REPDISC,- : KILLUCB called twice
16E8 4028 GHBSL_PROTOMASK+GHB_AREA:
16EE 4029 INC_CTR GHBSL_PROTOCOL+GHB_AREA : Increment protocol error counter
OC 11 16FB 4030 BRB 90S :
16FA 4031 20S: :
16FA 4032 : We must destroy the UCB (not called from $DASSGN, so queue the
16FA 4033 : UCB to the deadlist so it can be deallocated by the timer service.
16FA 4034 : This is because the CLASS driver still uses the UCB even if we
16FA 4035 : deallocate it!
16FA 4036 :
EA86 CF DO 16FA 4037 MOVL GHB_L_DEADLINK,- : Link UCB into chain of dead UCBs
0138 C5 DO 16FE 4038 UCBSL_LT_DEADLINK(R5) : for disposal at timeout
EA7E CF 55 DO 1701 4039 MOVL R5, GHB [ DEADLINK :
1F BA 1706 4040 90S: POPR #*M<R0,R1,R2,R3,R4> : Restore the regs
05 1708 4041 RSB

```

```

1709 4043 .SBTTL LTSSIDELINEUCB - Set a UCB aside
1709 4044 :++
1709 4045 : LTSSIDELINEUCB
1709 4046 :
1709 4047 : Functional description:
1709 4048 :
1709 4049 : Set a UCB aside to dry up on its own. Disconnect it from a running
1709 4050 : circuit.
1709 4051 :
1709 4052 : Inputs:
1709 4053 :     R5 = UCB address
1709 4054 :
1709 4055 : Outputs:
1709 4056 :     none
1709 4057 :     All registers preserved.
1709 4058 :
1709 4059 :--
1709 4060
1709 4061 LTSSIDELINEUCB:
54 0134 18 BB 1709 4062 PUSHM #*M<R3,R4> : Save registers
    0134 C5 D0 1708 4063 MOVL UCBSL_LT_CSB(R5), R4 : Get the CSB address
    15 13 1710 4064 BEQL 10$ : None, this is already done
53 0141 C5 9A 1712 4065 MOVZBL UCBSB_LT_LOCID(R5), R3 : Use the local slot index in UCB
    68 A443 D4 1717 4066 CLRL CSB_L_UCBLST-4(R4)[R3] : to adjust state of UCB list in CSB
    0134 C5 D4 1718 4067 CLRL UCBSL_LT_CSB(R5) : Remember we have been here
    2D A4 97 171F 4068 DECB CSB_B_REFC(R4) : One less UCB on this circuit
    03 12 1722 4069 BNEQ 10$ : We have more UCBs here
    0044 30 1724 4070 BSBW LTSSSTOPCIRC : Then don't wait for return traffic
    18 BA 1727 4071 10$: POPR #*M<R3,R4> : Restore registers
    05 1729 4072 RSB : Return to caller

```

```

172A 4074 .SBTTL LTSCIRCDEAD - Declare circuit dead
172A 4075 :++
172A 4076 : LTSCIRCDEAD - Declare circuit dead.
172A 4077 :
172A 4078 : Functional description:
172A 4079 :
172A 4080 : Log off all the processes on each UCB and waiting for them
172A 4081 : to free their UCBs. This will cause the CSB to go free too.
172A 4082 : If this CSB has no ucb's attached, then the CSB is just cleaned up.
172A 4083 :
172A 4084 : Inputs:
172A 4085 : R8 = CSB address
172A 4086 :
172A 4087 : Outputs:
172A 4088 : All UCB's hungup.
172A 4089 :
172A 4090 :--
172A 4091 :
172A 4092 LTSCIRCDEAD:
03FF 8F BB 172A 4093 PUSH  #^M<R0,R1,R2,R3,R4,R5,R6,R7,R8,R9> ; Save registers
2D AB 95 172E 4094 TSTB  CSB_B_REFC(R8) ; Do we have any UCBs?
57 69 AB 9A 1731 4095 BEQL  100$ ; Br if no, so deallocate CSB
56 6C AB DE 1733 4096 MOVZBL CSB_B_MAX_SLOTS(R8), R7 ; Else, number of UCBs to scan
55 86 D0 173B 4097 MOVAL CSB_L_UCB[ST(R8), R6] ; List of the UCBs
FF40 03 18 173E 4098 20$: MOVL (R6)+, R5 ; Get next UCB address
F5 57 F5 1740 4099 BGEQ 60$ ; Not system address
03FF 8F BA 1743 4100 BSBW  LISHANGUP_UCB_NOW ; Hangup the process on this UCB
05 1746 4101 60$: SOBGTR R7, 20$ ; For all the units here
1746 4102
1746 4103 90$: POPR #^M<R0,R1,R2,R3,R4,R5,R6,R7,R8,R9> ; Restore registers
174A 4104 RSB ; Return to caller
174B 4105
174B 4106 ; Refc has gone to zero, send a stop message
174B 4107
54 58 D0 174B 4108 100$: MOVL R8, R4 ; Setup CSB address
1B 10 174E 4109 BSBB LT$STOPCIRC ; Send a stop message on circ
F4 11 1750 4110 BRB 90$ ; And exit
1752 4111

```

```

1752 4113 .SBTTL LT$STOPCIRC - Transmit stop message
1752 4114 :++
1752 4115 : LT$STOPCIRC - Transmit stop message
1752 4116 :
1752 4117 : Functional description:
1752 4118 :
1752 4119 : Format and transmit stop message
1752 4120 :
1752 4121 : Inputs
1752 4122 :         R4 = CSB address
1752 4123 :         CSB_L_STOPREASON      addr of stop reason block
1752 4124 :
1752 4125 : Outputs:
1752 4126 :         none
1752 4127 :
1752 4128 :--
1752 4129
1752 4130 DEFREASN:
1752 4131 .ASCIC /Node terminated circuit./

20 65 64 6F 4E 00' 1752 4132
6E 69 6D 72 65 74 1758
63 20 64 65 74 61 175E
74 69 75 63 72 69 1764
      2E 176A
      18 1752
      176B 4132
      176B 4133 LT$STOPCIRC:
03FF 8F BB 176B 4134 PUSH R4,R1,R2,R3,R4,R5,R6,R7,R8,R9 ; Save registers
58 54 D0 176F 4135 MOVL R4, R8 ; Set CSB addr in r8
2D AB 95 1772 4136 TSTB CSB_B_REFC(R8) ; We are not supposed to send
      06 13 1775 4137 BEQL 10$ ; stop messages with
      08 AB 91 177D 4138 10$: CMPB CSB_B_STATE(R8),- ; outstanding ucbs on circ
      00 1780 4140 #CSB_C_STATE_HALT ; Have we been here before?
      03 12 1781 4141 BNEQ 15$ ; Br if no
008A 01 B0 1783 4142 BRW 90$ ; Else, exit
66 AB 01 B0 1786 4143 15$: MOVW #1,CSB_W_TIMRESET(R8) ; Set timers for quick timeout
50 AB 01 B0 178A 4144 MOVW #1,CSB_W_TIMEOUT(R8)
      00 90 178E 4145 MOVB #CSB_C_STATE_HALT,- ; and set state to halted
      08 AB B4 1790 4146 CLRW CSB_B_STATE(R8)
      60 AB 7E 1792 4147 MOVAQ CSB_W_LOCID(R8) ; Zero the local ID
      34 AB 0F 1795 4148 REMQUE @CSB_Q_XBUFQ(R8), R0 ; Transmit buffer queue
57 00 B0 0F 1799 4149 BVC 30$ ; Do we have a free buffer?
      0F 1C 179D 4150 REMQUE @CSB_Q_XWAITQ(R8), R7 ; Yep, got it
57 3C B8 0F 179F 4151 BVC 20$ ; Get a waiting bfr
      06 1C 17A3 4152 DEBUG ; Ok, so use it
      17A5 4153 20$: DECB CSB_B_XMTCNT(R8) ; All buffers gone?????
      59 AB 97 17AB 4154 30$: INSQUE (R7), (R0) ; One less buffer on waitq
60 67 0E 17AE 4155 MOVL R7, R9 ; Make it a free buffer
57 59 57 D0 17B1 4156 MOVAB XMT_T_DATA(R7), R7 ; Save bfr header adr
      48 A7 9E 17B4 4157 MOVB #MTP_C_HALT@FLAG_V_MTYPE,- ; Stop message data
      08 90 17B8 4158 CLRB CSB_B_FLAG(R8) ; Send a HALT message
      5C AB 94 17BC 4160 CLRB CSB_B_NUM_SLOTS(R8) ; No slot data
      5D AB 9E 17BF 4161 MOVAB XMT_T_MDATA(R9), R3 ; Set default end of data
53 50 A9 9E 17C3 4162 CLRB (R3)+ ; Set default reason code
      83 94 17C5 4163 MOVAB DEFREASN, R0 ; Store a default text string
50 8A AF 9E 17C9 4164 MOVZBL (R0), R1 ; the count

```

63	60	51	D6	17CC	4165	INCL	R1	:	including the count
	56	4C	A8	D0	17CE	4166	MOV3	R1, (R0), (R3)	: move count and string
		29	13	17D2	4167	MOVL	CSB_L_STOPREASON(R8), R6	:	Do we have a reason
	50	02	A6	9A	17D6	4168	BEQL	40\$: No reason
					17D8	4169	MOVZBL	2(R6), R0	: Set the reason bit
					17DC	4170	SETBIT	R0, GHB\$L_PROTOMASK+GHB_AREA	: and count the error
					17E2	4171	INC_CTR	GHB\$L_PROTOCOL+GHB_AREA	: as a halt
50	A9	03	A6	90	17EC	4172	MOV3	3(R6), -	: Store the reason code
					17F1	4173	STOP_B	RCODE+XMT_T_MDATA(R9)	:
	50	66	3C	17F1	4174	MOVZWL	(R6), R0	:	Offset to the string
	50	56	C0	17F4	4175	ADDL	R6, R0	:	Set the address
	51	60	9A	17F7	4176	MOVZBL	(R0), R1	:	Get the count
		51	D6	17FA	4177	INCL	R1	:	and set the count
	60	51	28	17FC	4178	MOV3	R1, (R0), -	:	copy the counted string
		51	A9		17FF			:	
					1801	4179	STOP_B	RLEN+XMT_T_MDATA(R9)	: Leave r3 pointing beyond
					1801	4180	40\$:		
1C	A9	53	D0	1801	4181	MOV3	R3, CXB\$L_T_ENDADR(R9)	:	and store in buffer
	54	58	D0	1805	4182	MOV3	R8, R4	:	copy CSB address
		0264	30	1808	4183	BSBW	LT\$XMIT	:	and transmit the msg
	03FF	8F	BA	180B	4184	50\$:	POPR	#*M<R0,R1,R2,R3,R4,R5,R6,R7,R8,R9>	: Restore registers
			05	180F	4185	RSB		:	Return to caller
					1810	4186			
					1810	4187	:	Stop message sent once	
					1810	4188	:	Just wipe CSB now	
					1810	4189			
	54	58	D0	1810	4190	90\$:	MOV3	R8, R4	:
		FCOA	30	1813	4191	BSBW	LT\$DEALOC	CSB	: CSB address to R4
		F3	11	1816	4192	BRB	50\$: Deallocate CSB to pool
					1818	4193			: And exit

```

1818 4195 .SBTTL LT$SET_TIMER - Start Timer
1818 4196 :++
1818 4197 : LT$SET_TIMER - Start the timer
1818 4198 :
1818 4199 : Functional description:
1818 4200 :
1818 4201 : Start timer ticking to scan the CSB's for dead circuits
1818 4202 :
1818 4203 : Inputs:
1818 4204 : R0-R2 available
1818 4205 :
1818 4206 : Implicit Inputs:
1818 4207 :
1818 4208 : IPL = LAT$C_IPL (8)
1818 4209 :
1818 4210 : Outputs:
1818 4211 : R0-R2 are destroyed.
1818 4212 :
1818 4213 :--
1818 4214 :
1818 4215 LT$SET_TIMER:
50 E8C0 CF 9E 1818 4216 MOVAB GHB G_TQE, R0 : Address of timer queue element
1F E976 CF E2 181D 4217 BBSS #GHB_STS_V_ACTIVE,- : Br if timer already active
000D*CF 04 88 181F 4218 GHB_B_STATUS,10$ : and mark as active
08 A0 30 B0 1823 4219 BISB #DPT$M_NOUNLOAD,DPT$TAB+DPT$B_FLAGS ; Make driver unloadable
0A A0 90 1828 4220 MOVW #TQESC_LENGTH,- : Setup timer queue entry block
55 50 D0 182A 4221 TQESW SIZE(R0) : For its first use
0F 90 182C 4222 MOVB #DYN$C_TQE,- : With both the size and the type
0A A0 182E 4223 TQESB_TYPE(R0) : Code.
38 BB 1830 4224 PUSHR #^M<R3,R4,R5> : Save the fork context
55 50 D0 1832 4225 MOVL R0, R5 : Use TQE as a fork block
1835 4226 :
1835 4227 : Use the TQE as a fork block to start the timer. This is because the
1835 4228 : timer must be started at or below QUEUEAST to synchronize access to the
1835 4229 : TIMER QUEUE.
1835 4230 :
1835 4231 MOVB #IPL$_QUEUEAST,- : Set delivery IPL
0B A5 90 1837 4232 FKBSB_FIPL(R5) : of fork block
08 10 1839 4233 BSBB 40$ : Create fork process
E8F8 CF 01 CE 183B 4234 MNEGL #1,GHBSL_TIM_ACT+GHB_AREA : Mark the timer as active for LATCP
38 BA 1840 4235 POPR #^M<R3,R4,R5> : Restore our context
05 1842 4236 10$: RSB : And return
1843 4237 :
1843 4238 :
1843 4239 : Fork process to start the timer. We need to go to synch from
1843 4240 : fork ipl to start the timer. We do this by going through
1843 4241 : Queueast IPL to be safe - using the TQE as a fork block.
1843 4242 :
1843 4243 :
00000000*GF 16 1843 4244 40$: JSB G^EXE$FORK : Fork to start the timer ticking
1849 4245 DSBINT #IPL$_SYNCH : Raise to synch
188C*CF 9E 184F 4246 MOVAB W^LT$TICK,- : Address of tick routine
0C A5 1853 4247 TQESL FPC(R5) : is the fork pc
00000000*GF D0 1855 4248 MOVL G^TTY$GL_DELTA,- : The tick time is from tty sysgen
20 A5 185B 4249 TQESQ DELTA(R5) : parameter for modem control
05 90 185D 4250 MOVB #TQESC_SSREPT,- : Repeating tick
0B A5 185F 4251 TQESB_RQTYPE(R5) :

```



```

187C 4259 .SBTTL LTSTICK - Timer Service Routine
187C 4260 :++
187C 4261 LTSTICK - Timer Service Routine
187C 4262 :
187C 4263 Functional description:
187C 4264 :
187C 4265 Enter here on each timer tick. We scan the CSB table and
187C 4266 timeout each UCB with a matching CSB for each CSB that has
187C 4267 timed out. For each receive on a circuit that has not timed
187C 4268 out we will reset its timer.
187C 4269 :
187C 4270 Inputs:
187C 4271 R5 = TQE address
187C 4272 :
187C 4273 IPL = TIMER
187C 4274 :
187C 4275 Outputs:
187C 4276 R0-R4 are destroyed.
187C 4277 :
187C 4278 :--
187C 4279 .ENABLE LOCAL_BLOCK
187C 4280 :
187C 4281 STOP_TQE:
OB A5 04 8A 187C 4282 BICB #TQESM_REPEAT,TQESB_RQTYPE(R5) ; Stop the TQE
000D'CF 04 8A 1880 4283 BICB #DPTSM_NOUNLOAD,DPTSTAB+DPTSB_FLAGS ; Clear the repeat flag
E8AF CF D4 1885 4284 CLRL GHBSL_TIM_ACT+GHB_AREA ; Make driver reloadable again
1889 4285 ; Tell LATCP we are no longer
01DB 31 1889 4286 BRW 300$ ; active
188C 4287 ; And leave
188C 4288 LTSTICK:
OFEO 8F BB 188C 4289 DSBINT #LATSC_IPL ; Raise to synchronize LAT
EO E8FD CF E1 1892 4290 PUSHR #*M<R5,R6,R7,R8,R9,R10,R11> ; Save all the registers
1896 4291 BBC #GHB_STS_V_ACTIVE,- ; Br if we went inactive
1898 4292 GHB_B_STATUS,STOP_TQE
189C 4293 :
189C 4294 : Scan all CSBs to retransmit in balanced mode and time out circuits
189C 4295 that appear to be dead.
189C 4296 :
SA SB 20 D0 189C 4297 MOVL #LATSC_MAX_CSBS, R11 ; Scan the CSB table for
E795 CF DE 189F 4298 MOVAL GHB_L_CSBTABLE, R10 ; Active entries and check
58 8A D0 18A4 4299 20$: MOVL (R10)+, R8 ; Get the CSB address
43 13 18A7 4300 BEQL 90$ ; Br if no CSB in this slot
18A9 4301 :
18A9 4302 Are we coming out of balanced mode and need to retransmit the
18A9 4303 First message again??
18A9 4304 :
02 0B A8 91 18A9 4305 CMPB CSB_B_STATE(R8), - ; State must be running
18AD 4306 #CSB_C_STATE_RUN ; for active circuits
26 12 18AD 4307 BNEQ 60$ ; Br if not
52 A8 B5 18AF 4308 TSTW CSB_W_XMTTMO(R8) ; Timing out restart message?
21 13 18B2 4309 BEQL 60$ ; Br if no
52 A8 B7 18B4 4310 DECW CSB_W_XMTTMO(R8) ; Check for timeout
1C 14 18B7 4311 BGTR 60$ ; Br if not time yet
18B9 4312 INC_CTR GHBSL_RETRANS+GHB_AREA ; Count a retransmission
18C3 4313 INC_CTR CSB_Z_LCB+LCB_L_MSG_REXMT(R8) ;
54 58 D0 18CB 4314 MOVE R8, R4 ; CSB address for call
0203 30 18CE 4315 BSBW LT$REXMIT ; Transmit the message

```

```

52 AB 02 B0 18D1 4316      MOVW    #LATSC_HOST_TIMER,CSB_W_XMTTMO(R8) ; Reset the timeout
          18D5 4317      ;
          18D5 4318      ; Timeout circuit if needed
          18D5 4319      ;
          50 AB B7 18D5 4320 60$:  DECW    CSB_W_TIMEOUT(R8)           ; Check the circuit timeout
          12      12 18DB 4321      BNEQ    90$                    ; Br if not expired
          FE43 30 18DA 4322      INC     CTR GHBSL_CIRCDOWN+GHB_AREA ; Count circ down event
          66 AB B0 18E4 4323      BSBW   LT$CIRCDEAD             ; Declare the circuit dead
          50 AB B0 18E7 4324      MOVW    CSB_W_TIMRESET(R8),- ; Reset the timeout to wait
          B5 5B F5 18EA 4325      CSB_W_TIMEOUT(R8) ; a while
          18EC 4326 90$:  SOBGTR  R11, 20$ ; Loop till we are done
          18EF 4327      ;
          18EF 4328      ;
          18EF 4329      ;
          18EF 4330      ;
          18EF 4331      ;
          18EF 4332      ;
          18EF 4333      ;
          00000000'GF DE 18EF 4334 100$: MOVAL  G^IOCSGL_MUTEX, R0 ; Is anyone owning the io data
          50      18F5      ;
          FFFF 8F 60 B1 18F6 4335      CMPW   MTXSW_OWNCNT(R0), #-1 ; base? If so, then we must
          1A      12 18FB 4336      BNEQ   130$                    ; try again later.
          54  E883 CF D0 18FD 4337      MOVL   GHB_L_DEADLINK, R4 ; Good we own it then
          E87E CF D4 1902 4338      CLRL   GHB_L_DEADLINK ; Reset list pointer
          54      D5 1906 4339 110$:  TSTL   R4 ; Any work to do?
          OD      13 1908 4340      BEQL   130$                    ; All done
          55      54 D0 190A 4341      MOVL   R4, R5 ; UCB to delete
          54  0138 C5 D0 190D 4342      MOVL   UCBSL_LT_DEADLINK(R5), R4 ; Save link to next one
          FCOA 30 1912 4343      BSBW   LT$DESTROYUCB ; Destroy this UCB
          EF      11 1915 4344      BRB    110$ ; and go back for more
          1917 4345      ;
          1917 4346 130$:  ;
          1917 4347      ;
          1917 4348      ;
          1917 4349      ;
          1917 4350      ;
          1917 4351      ;
          1917 4352      ;
          1917 4353      ;
          EAD3 CF B7 1917 4354      DECW   GHB_W_MULTIMR ; Time to transmit?
          03      15 1918 4355      BLEQ   150$ ; Br if yes, do it
          0147 31 191D 4356 140$:  BRW    300$ ; Else, still time to go
          1920 4357      ;
          52  EACC CF D0 1920 4358 150$:  MOVL   GHB_L_MULTIBFR, R2 ; Get multicast buffer
          OD      13 1925 4359      BEQL   155$ ; Br if none
          1927 4360      ASSUME  GHB_STS_V_MULTI EQ 0 ;
          F1  E86D CF E8 1927 4361      BLBS  GHB_B_STATUS,140$ ; Ignore, if already in progress
          E869 CF 91 192C 4362      CMPB  GHB_B_INCARN, - ; Has it been rebuilt?
          4E  A2      1930 4363      ;
          06      13 1932 4364      BEQL   XMT_B_MC_INCARN(R2) ; if so, incarn has been
          F02E 30 1934 4365 155$:  BSBW   160$ ; bumped to say so
          E3  50  E9 1937 4366      BLBC  LT$SETENTRY ; Go rebuild the message
          E860 CF 98 193A 4367 160$:  MOVZBW <XMT_B_MC_MULTIMR-XMT_B_MC_SET>- ; Br if failure
          EAAD CF 193E ; Reset multicast timer
          05      12 1941 4368      BNEQ   +GHB_T_MC_DATA,GHB_W_MULTIMR ; from LATCP set data
          1941 4369 ; Br if value is okay

```

Now check to see if there are dead ucbs waiting to be cleaned up and if noone is using the io database right now, we can delete them all in a flash.

Transmit a configuration message if its time. We tell all concentrators our node name, announcement string every so often so they know we exist.

```

EAA6 CF OA B0 1943 4370 MOVW #LATSC_MULTI_TIMER,GHB_W_MULTIMR ; Reset timer
52 EAA4 CF D0 1948 4371 161$: MOVL GHB_L_MULTIBFR, R2 ; Get multicast buffer
      194D 4372
      194D 4373 : Adjust host rating
      194D 4374
51 54 A2 9E 194D 4375 MOVAB XMT_B_MC_GRP_LEN(R2), R1 ; Compute address of node name:
50 81 9A 1951 4376 MOVZBL (R1)+, R0 ; get count of groups
51 50 C0 1954 4377 ADDL R0, R1 ; add in start address
50 81 9A 1957 4378 MOVZBL (R1)+, R0 ; Compute address of node desc.
51 50 C0 195A 4379 ADDL R0, R1 ; add in start address
50 81 9A 195D 4380 MOVZBL (R1)+, R0 ; Calc start address of services
51 50 C0 1960 4381 ADDL R0, R1 ; add in start address
54 51 D0 1963 4382 MOVL R1, R4 ; Save address of service count
02 81 91 1966 4383 CMPB (R1)+, #2 ; Do we have two service names?
      03 18 1969 4384 BGEQ 163$ ; Br if yes, process it
      00BE 31 196B 4385 BRW 170$ ; Else, skip it
50 81 9A 1970 4387 163$: INCL R1 ; Skip rating byte
51 50 C0 1973 4388 MOVZBL (R1)+, R0 ; Calc start of first svc desc.
50 81 9A 1976 4389 ADDL R0, R1 ;
51 50 C0 1979 4390 MOVZBL (R1)+, R0 ; Calc start of second svc rate
      197C 4391 ADDL R0, R1 ;
      197C 4392 :
      197C 4393 : Compute the service rating as follows:
      197C 4394 :
      197C 4395 :   cpu_idle_time * 255
      197C 4396 : ----- * cpu_weight
      197C 4397 : 100 * multicast timer
      197C 4398 :
      197C 4399 : where: cpu_weight is 1 for a 790, 1/2 for 785, 3/8 for 780, etc.
      197C 4400 :
      197C 4401 :
50 E810 CF C3 197C 4402 SUBL3 GHB_L_LASTCPU,@GHB_L_NULLCPU,R0 ; Calculate "idle time"
      E809 DF 1980
      E804 DF D0 1984 4403 MOVL @GHB_L_NULLCPU,GHB_L_LASTCPU ; Set new last cpu time
      E805 CF 1988
00000000 GF D0 198B 4404 MOVL G^EXESGL_MP,R6 ; Get ptr to MP code
      56 1991
      17 13 1992 4405 BEQL 164$ ; Br if not there
57 E7FC CF C3 1994 4406 SUBL3 GHB_L_NULLSEC,- ; Else, compute secondary idle
      0000 C6 1998 4407 MPSSGL_NULLCPU(R6),R7 ; time
      0000 C6 D0 199C 4408 MOVL MPSSGL_NULLCPU(R6),- ; And set new secondary
      E7F1 CF 19A0 4409 GHB_L_NULLSEC ; null time
57 FF 8F 78 19A3 4410 ASHL #-1,R7,R7 ; Get 50% of secondary null time
      57 19A7
      50 57 C2 19A8 4411 SUBL R7,R0 ; Let secondary account for
      19AB 4412 ; only 50% additional power
000000FF 8F C4 19AB 4413 164$: MULL #255,R0 ; Multiply by highest rating possibl
      50 19B1
53 01 9A 1982 4414 MOVZBL #1,R3 ; Start with 1
      1985 4415 CPUDISP <<790, EIGHT>,- ; Give 790 the highest rating
      1985 4416 <785, FOUR>,- ; Rate 785 as four
      1985 4417 <780, THREE>,- ; Rate 780 as three
      1985 4418 <750, TWO>,- ; Rate 750 as two
      1985 1 <UV2, TWO>,- ; Rate MicroVAX II as two
      1985 4419 <730, ONE>,- ; etc.
      1985 4420 <UV1, ONE>> ;

```

```

53 04 C0 19E7 4421
53 04 D6 19E7 4422 EIGHT: ADDL #4,R3 ; Rating will be highest
53 04 D6 19EA 4423 FOUR: INCL R3 ; next rating
53 04 D6 19EC 4424 THREE: INCL R3 ; etc.
53 04 D6 19EE 4425 TWO: INCL R3 ;
53 04 D6 19F0 4426 ONE: ;
50 53 C4 19F0 4427 MULL R3,R0 ; Compute adjusted rating
00000320 8F C6 19F3 4428 DIVL #800,R0 ; Divide by highest rating + %
53 E7A0 CF 9A 19FA 4429 MOVZBL <XMT_B_MC_MULTIMR-XMT_B_MC_SET>- ; Get multicast timer
53 04 D6 19FF 4430 +GHB_T_MC_DATA,R3 ;
50 53 C6 19FF 4431 DIVL R3,R0 ; Normalize rating by time
000000FF 8F OD 13 1A02 4432 BEQL 165$ ; Br if zero rating
50 FE 8F 06 D1 1A04 4433 CMPL R0,#255 ; Ridiculous rating ?
50 FE 8F 15 1A0B 4434 BLEQ 167$ ; Br if no, continue
50 FE 8F 9A 1A0D 4435 MOVZBL #254,R0 ; Else, set highest rating
1A11 4436 ; let INCL up it to 255
1A11 4437 165$: ;
1A11 4438 ; Don't let rating fall to zero, unless the joblimit is reached
1A11 4439 ; or the jobcnt if greater than or equal to the joblim.
1A11 4440 ;
00000000 GF 02 D6 1A11 4441 INCL R0 ; Else, set to minimum
00000000 GF 02 B1 1A13 4442 167$: CMPW G^SYSSGW_IJOBcnt,G^SYSSGW_IJOBlim ; Are we maxed out?
61 50 05 1F 1A1E 4443 BLSSU 169$ ; Br if no, continue
61 50 05 D4 1A20 4444 CLRL R0 ; Else, set to minimum
61 50 05 91 1A22 4445 169$: CMPB R0,(R1) ; New second service rating?
61 50 05 13 1A25 4446 BEQL 170$ ; Br if no
61 50 05 90 1A27 4447 MOVB R0,(R1) ; Else, set new 2nd svc rating
0A 11 1A2A 4448 BRB 175$ ;
00000000 GF 01 A4 91 1A2C 4449 170$: CMPB G^SYSSGW_IJOBcnt, 1(R4) ; New number of interactive
00000000 GF 01 A4 1A32 4450 ; users?
00000000 GF 13 13 1A34 4451 BEQL 180$ ; Br if no
00000000 GF 01 A4 90 1A36 4453 175$: MOVB G^SYSSGW_IJOBcnt, 1(R4) ; Use the interactive count
4E A2 96 1A3E 4454 ; as the second rating
E754 CF 96 1A3E 4455 INCB XMT_B_MC_INCARN(R2) ; set new incarnation
4F A2 08 8C 1A41 4456 INCB GHB_B_INCARN ; no call LTISETENTRY next time
54 E73B CF 8C 1A45 4457 XORB #XMT_CHFLG_M_RATE,XMT_B_MC_CHG_FLAG(R2) ; flag rate change
54 E73B CF D0 1A49 4458 180$: MOVL GHB_L_FFI, R4 ; Get FFI block address
54 E73B CF 17 13 1A4E 4460 BEQL 300$ ; Br if none
53 52 D0 1A50 4461 SETBIT #GHB_STS_V_MULTI,GHB_B_STATUS ; Indicate that multicast is active
E98B CF 7D 1A56 4462 MOVL R2,R3 ; Copy CXB address
28 A3 7D 1A59 4463 MOVQ GHB_Q_MULTIADD,- ; Copy the destination address
28 A3 7D 1A5D 4464 CXBSQ_STATION(R3) ;
14 A3 18 A3 D0 1A5F 4465 ASSUME CXBSW_BCNT EQ CXBSW_BOFF+2 ; Save BOFF and BCNT
14 A3 18 A3 D0 1A5F 4466 MOVL CXBSW_BOFF(R3),CXBSW_T_SAVE(R3) ;
10 B4 16 1A64 4467 JSB @FFISL_XMIT(R4) ; Start XMIT operation
0FEO 8F BA 1A67 4469 300$: POPR #*M<R5,R6,R7,R8,R9,R10,R11> ; Restore the regs
0FEO 8F BA 1A67 4470 ENBINT ; Restore priority
0FEO 8F BA 1A6B 4471 RSB ;
0FEO 8F BA 1A6E 4472 ;

```



```

1A6F 4476 .SBTTL LTSXMIT - Transmit a message
1A6F 4477 :++
1A6F 4478 : LTSXMIT - Transmit a message
1A6F 4479 :
1A6F 4480 : FUNCTIONAL DESCRIPTION:
1A6F 4481 :
1A6F 4482 : If the CXB is outstanding then record the fact that there is
1A6F 4483 : a waiting message. If the CXB is not outstanding, then ready
1A6F 4484 : it for transmission and send it to the other driver as a write.
1A6F 4485 :
1A6F 4486 : Transmissions must make progress. That is the sequence and acks
1A6F 4487 : of the messages must change over time or we decide that the
1A6F 4488 : circuit is really deadlocked and we take it down. We are generous
1A6F 4489 : with the counter for detecting this deadlock.
1A6F 4490 :
1A6F 4491 : Input:
1A6F 4492 : R4 = CSB address
1A6F 4493 :
1A6F 4494 : Output:
1A6F 4495 : R0-R5 clobbered
1A6F 4496 :-
1A6F 4497 :
1A6F 4498 .ENABLE LOCAL_BLOCK
1A6F 4499
1A6F 4500 LTSXMIT:
53 34 B4 0F 1A6F 4501 REMQUE @CSB_Q_XBUFQ(R4), R3 : Remove the buffer from queue
      06 1C 1A73 4502 BVC 5$ : We had better have a buffer here.
      59 A4 96 1A75 4503 DEBUG : Fatal error, no buffer
      62 A4 96 1A7B 4504 5$: INCB CSB_B_XMTCNT(R4) : One more buffer to transmit
      5C A4 7D 1A7E 4505 INCB CSB_B_XSEQ(R4) : Next message to send
      48 A3 9E 1A81 4506 MOVQ CSB_T_CIRCHDR(R4),- : Set the circuit header for the
50 48 A3 9E 1A84 4507 XMT_T_DATA(R3) : message
1C A3 50 C2 1A86 4508 MOVAB XMT_T_DATA(R3), R0 : Start of data to send
      1C A3 B0 1A8A 4509 SUBL R0,-CXBSL_T_ENDADR(R3) : Make length from end address
      1A A3 1A8E 4510 MOVW CXBSL_T_ENDADR(R3),- : Copy length to CXB format
40 B4 63 0E 1A91 4511 CXBSW_BCNT(R3)
      58 A4 95 1A93 4512 INSQUE (R3),@CSB_Q_XWAITQ+4(R4) : Queue to tail of waiting buffers
      3D 13 1A97 4513 TSTB CSB_B_XMTBSY(R4) : Transmitter busy?
      58 A4 96 1A9A 4514 BEQL 60$ : Br if no, start transmitting
      1A9C 4515 10$: INCB CSB_B_XMTBSY(R4) : Else, count another transmit
      1A9F 4516 20$: RSB : we just placed one on the wait queue
      05 1A9F 4517
      1AA0 4518
      1AA0 4519 :
      1AA0 4520 : Transmit just the one buffer, not all the ones waiting.
      1AA0 4521 :
1A6F 4522 LTSXMITONE:
53 34 B4 0F 1AA0 4523 REMQUE @CSB_Q_XBUFQ(R4), R3 : Get the one buffer of interest
      06 1C 1AA4 4524 BVC 30$ : Got it
      59 A4 96 1AA6 4525 DEBUG : No buffer for this transmit
      62 A4 96 1AAC 4526 30$: INCB CSB_B_XMTCNT(R4) : Count one more on wait queue
      5C A4 7D 1AAF 4527 INCB CSB_B_XSEQ(R4) : Next message to send
      48 A3 9E 1AB2 4528 MOVQ CSB_T_CIRCHDR(R4),- : Set the circuit header for the
50 48 A3 9E 1AB5 4529 XMT_T_DATA(R3) : message
1C A3 50 C2 1AB7 4530 MOVAB XMT_T_DATA(R3), R0 : Start of data to send
      1C A3 B0 1ABB 4531 SUBL R0,-CXBSL_T_ENDADR(R3) : Make length from end address
      1ABF 4532 MOVW CXBSL_T_ENDADR(R3),- : Copy length to CXB format

```

```

1A A3      95 1AC2 4533      CXBSW_BCNT(R3)
58 A4      12 1AC4 4534      TSTB   CSB_B_XMTBSY(R4)      : Are we busy??
05        12 1AC7 4535      BNEQ   40$                : Br if yes, so carry on
58 A4      96 1AC9 4536      INCB   CSB_B_XMTBSY(R4)      : Just one buffer
25        11 1ACC 4537      BRB    90$                : Go
40 B4      63 0E 1ACE 4539 40$:  INSQUE (R3), @CSB_Q_XWAITQ+4(R4) : Place it on the queue
CB        11 1AD2 4540      BRB    10$                : And transmit later
58 A4      95 1AD4 4542      LTSREXMIT:                : Entry to start a retransmit
58 A4      12 1AD7 4544      TSTB   CSB_B_XMTBSY(R4)      : Is the transmit busy??
58 A4      90 1AD9 4545 60$:  MOVW   CSB_B_XMTCNT(R4), -    : Br if yes, just leave
1A4E      4546      CSB_B_XMTBSY(R4)          : Start a series of retransmits
1A4E      4547
1A4E      4548
1A4E      4549 ::**      debug code
59 A4      91 1A4E 4550      CMPB   CSB_B_XMTCNT(R4), -    : All buffers on the transmit queue?
02        1A4E 4551      #LATSC_XMT_BUFFERS
09        19 1AE2 4552      BLSS   80$                : Nope
06        13 1AE4 4553      BEQL   70$                : Yes all of them
01        01 1AEC 4555 70$:  NOP                          : More than all of them
1AED      4556 80$:
1AED      4557 ::**      debug code
1AED      4558
1AED      4559 LTSXMTGO:                : Enter to transmit for waiters
53 3C B4    0F 1AED 4560      REMQUE @CSB_Q_XWAITQ(R4), R3  : Obtain the next waiting buffer
AC        1D 1AF1 4561      BVS    20$                : Br if no buffer to transmit
56 A4      B1 1AF3 4562 90$:  CMPW   CSB_W_PROGSEQ(R4), -    : Are we making progress?
62 A4      12 1AF6 4563      CSB_W_XSEQ(R4)            : are the seq and ack fields changing?
1F        12 1AF8 4564      BNEQ   100$               : Br if yes, splendid
54 A4      B7 1AFA 4565      DECB   CSB_W_PROGRESS(R4)    : Nope, give them some time then
23        14 1AFD 4566      BGTR   110$               : We have more time then
34 A4      63 0E 1AFF 4567      INSQUE (R3), CSB_Q_XBUFQ(R4) : Put the buffer back into the CSB
58        DD 1B03 4568      INC_CTR GMBL_CIRCDOWN+GMB_AREA : Count a circuit timeout
58        D0 1B0D 4569      PUSHL  R8                  : No more time. Clobber the circuit
FC15      30 1B0F 4570      MOVL   R4, R8              : Since it appears to be deadlocked.
58 BED0    1B12 4571      BSBW   LTSCIRCDEAD         : and clean it all up
05        05 1B15 4572      POPL   R8
1B18      4573      RSB
1B19      4574
62 A4      B0 1B19 4575 100$:  MOVW   CSB_W_XSEQ(R4), -    : Reset the current sequence and ack
56 A4      13 1B1C 4576      CSB_W_PROGSEQ(R4)         : to check against
14        B0 1B1E 4577      MOVW   #LATSC_PROGRESS, -   : and reset the progress counter
54 A4      1B20 4578      CSB_W_PROGRESS(R4)
1B22      4579
1B22      4580 110$:
1B22      4581
1B22      4582
1B22      4583
1B22      4584
55 E662 CF  D0 1B22 4584      Build the CXB to transmit
2A        13 1B27 4585      MOVL   GMB_L_FFI, R5       : Get the FFI block address
51 5A A4    9A 1B29 4586      BEQL   150$                : Br if none
44 A441    53 D0 1B2D 4587      MOVZBL CSB_B_XCXB_INX(R4), R1 : Get XMIT CXB index slot
51        96 1B32 4588      MOVL   R3, -CSB_L_XCXB(R4)[R1] : Save address of CXB
51 FE BF    8A 1B34 4589      INCB   R1                  : Skip to next slot
BICB     #^C<LATSC_XMT_BUFFERS-1>,R1 : Modulo maximum

```

5A	A4	51	90	1B38	4590	MOVW	R1, CSB_B_XCXB_INX(R4)	:	Save for next time
		54	DD	1B3C	4591	PUSHL	R4	:	Save R4
	54	55	DO	1B3E	4592	MOVL	R5, R4	:	Else, copy the FFI block address
14	A3	18	A3	DO	1B41	4593	ASSUME	CXBSW_BCNT EQ CXBSW_BOFF+2	
					1B41	4594	MOVL	CXBSW_BOFF(R3), CXBSW_T_SAVE(R3)	: Save BOFF and BCNT
					1B46	4595			: progress
					1B46	4596			
					1B46	4597			
					1B46	4598			
					1B46	4599			
50	48	A3	9E	1B46	4600	MOVAB	XMT_B_FLAG(R3), R0	:	Address of data to save
		EBDA	30	1B4A	4601	BSBW	LTSRHISTORY	:	Save the data
				1B4D	4602				
				1B4D	4603				
				1B4D	4604				
	10	B4	16	1B4D	4605	JSB	@FFISL_XMIT(R4)	:	Start the XMIT operation
		54	BED0	1B50	4606	POPL	R4	:	Restore R4
			05	1B53	4607	RSB		:	Return to caller
				1B54	4608				
				1B54	4609				
				1B54	4610				

150\$:

.DISABLE LOCAL_BLOCK


```

1854 4612      .SBTTL LTSXMT_FFIDONE - FFI Transmit done routine
1854 4613      :++
1854 4614      : LTSXMT_FFIDONE - FFI Transmit completion routine
1854 4615      :
1854 4616      : FUNCTIONAL DESCRIPTION:
1854 4617      :
1854 4618      : Post routine for a transmit. Called directly from datalink
1854 4619      : driver with CXB address in R3. We have r0 - r5 to work with.
1854 4620      :
1854 4621      : INPUTS:
1854 4622      : R0 = Status of XMIT request
1854 4623      : R3 = CXB address
1854 4624      : R4 = FFI block address
1854 4625      :
1854 4626      : IPL = SYNCH
1854 4627      :
1854 4628      : OUTPUTS:
1854 4629      : R1,R2,R4,R5 clobbered
1854 4630      :--
1854 4631      : ASSUME IPL$ SYNCH EQ LATSC_IPL
1854 4632 LTSXMT_FFIDONE:
1854 4633      PUSHR #M<R1,R2,R4,R5>      : Save registers
1854 4634      ASSUME CXBSW_BCNF EQ CXBSW_BOFF+2
1854 4635      MOVL CXBSL_T_SAVE(R3),CXBSW_BOFF(R3) ; Restore BOFF and BLNT
1854 4636      INC_CTR GMB$L_XCOUNT+GMB_AREA      : Count one more buffer away
1854 4637      BLBS R0,20$                    : Br if no error
1854 4638      MOVZWL R0,GMB$L_XERRCOD+GMB_AREA    : Save error code
1854 4639      INC_CTR GMB$L_XERR+GMB_AREA          : Count one more error, but ignore it
1854 4640 20$: BLBS CXBSB_CODE(R3),110$      : Br if multicast buffer
1854 4641      MOVL CXBSL_T_CSB(R3),R4           : Get CSB address
1854 4642      BNEQ 40$                          : Got it, continue
1854 4643      MOVL R3,R0                          : Toss this CXB then since the
1854 4644      BSBW LT$DEALPOOL                    : CSB seems to be gone.
1854 4645      BRB 70$                          : Leave quietly
1854 4646
1854 4647 40$: MOVZBL #LATSC_XMT_BUFFERS-1,R0 : Get number of CXBs
1854 4648 45$: CMPL R3,CSB_L_XCXB(R4)[R0]    : Same as we sent?
1854 4649      BEQL 50$                          : Br if yes, remove it
1854 4650      SOBGEQ R0,45$                      : Loop if more
1854 4651      DEBUG                               : :: oops
1854 4652 50$: CLRL CSB_L_XCXB(R4)[R0]      : Zero entry
1854 4653      INC_CTR CSB_Z_LCB+LCB_L_MSG_XMT(R4) : Count one more transmit
1854 4654      INSQUE (R3),@CSB_Q_XWAITQ+4(R4) : Queue to tail for retransmit
1854 4655      DECB CSB_B_XMTBSYTR4)           : Any more to transmit??
1854 4656      BEQL 60$                          : Nope all done
1854 4657      BSBW LTSXMTGO                      : Transmit for waiter
1854 4658      BRB 70$                          : Not done transmitting all yet
1854 4659 60$:
1854 4660      :
1854 4661      : If all UCBs are gone and we have transmitted a stop message last,
1854 4662      : then we can make this CSB go away.
1854 4663      :
1854 4664
1854 4665      TSTB CSB_B_REFC(R4)                  : Are all the UCB's gone?
1854 4666      BNEQ 70$
1854 4667      CMPB CSB_B_FLAG(R4),-              : Is the circuit dead?
1854 4668      #MTP_C_HALT@FLAG_V_MTYPE
    
```

03	12	1BBF	4669		BNEQ	70\$:	Br if not
F85C	30	1BC1	4670		BSBW	LTSDEALOCSE	:	Get rid of the circuit block
36	BA	1BC4	4671	70\$:	POPR	#^M<R1,R2,R4,R5>	:	Restore registers
	05	1BC6	4672		RSB		:	
		1BC7	4673		:		:	
		1BC7	4674		:	Multicast buffer completed	:	
		1BC7	4675		:		:	
		1BC7	4676	110\$:	CLRBIT	#GHB_STS_V MULTI,-	:	Multicast is not busy now
		1BC7	4677			GHB_B_STATUS	:	
F5	11	1BCD	4678		BRB	70\$:	And exit
		1BCF	4679				:	

```
1BCF 4681 .SBTTL LT$FFIPOSTDONE - Garbage transmit posting routine
1BCF 4682 :++
1BCF 4683 : LT$FFIPOSTDONE - Garbage transmit posting routine
1BCF 4684 :
1BCF 4685 : FUNCTIONAL DESCRIPTION:
1BCF 4686 :
1BCF 4687 : Final post routine to dry up a CXB I/O when we are done
1BCF 4688 : with the channel. We simply deallocate any transmit buffer returned.
1BCF 4689 :
1BCF 4690 : INPUTS:
1BCF 4691 : R3 = CXB address
1BCF 4692 : R4 = FFI block address
1BCF 4693 :
1BCF 4694 : OUTPUTS:
1BCF 4695 : R0 clobbered
1BCF 4696 :--
1BCF 4697 :
1BCF 4698 LT$FFIPOSTDONE:
50 36 BB 1BCF 4699 PUSH  #^M<R1,R2,R4,R5> ; Save registers
53 53 DO 1BD1 4700 MOVL  R3,R0 ; Copy CXB address
03 10 1BD4 4701 BSBB  LT$DEALPOOL ; Drop the buffer
36 BA 1BD6 4702 POPR  #^M<R1,R2,R4,R5> ; Restore registers
1BD8 4703 LT$DROPCTXB: ; Drop all RECEIVE CXBs
05 1BD8 4704 RSB
1BD9 4705
00000000'GF 17 1BD9 4706 LT$DEALPOOL:
1BD9 4707 JMP  G^EXE$DEANONPAGED ; Deallocate the FFI block
1BDF 4708
1BDF 4709 LT$SEND: ; End of driver
1BDF 4710
1BDF 4711 .END
```

LTDRIVER
Symbol table

- Local Area Terminal Port Driver C 7

8-JAN-1985 17:22:25 VAX/VMS Macro V04-00
5-SEP-1984 11:40:22 [LAT.BUGSRC]LTDRIVER.MAR;1

Page 113
(66)

\$\$\$	= 00000020	R	02	CSB_W_PROGRESS	00000054	G	
\$\$BASE	= 00000001			CSB_W_PROGSEQ	00000056	G	
\$\$DISPL	= 0000000A			CSB_W_REMID	0000005E	G	
\$\$GENSW	= 00000001			CSB_W_RSEQ	00000064	G	
\$\$HIGH	= 00000009			CSB_W_SIZE	00000008	G	
\$\$LIMIT	= 00000008			CSB_W_TIMEOUT	00000050	G	
\$\$LOW	= 00000001			CSB_W_TIMRESET	00000066	G	
\$\$MNSW	= 00000001			CSB_W_XMTTMO	00000052	G	
\$\$MXSW	= 00000001			CSB_W_XSEQ	00000062	G	
\$\$OP	= 00000002			CSB_Z_DST	0000002E	G	
ATS_NULL	*****	X	02	CSB_Z_LCB	0000000C	G	
BIT...	= 00000004			CXBSB_CODE	= 0000000B		
BUGS_UNSUPRTCPU	*****	X	03	CXBSB_TYPE	= 0000000A		
BUILD_TQF	000008E2	R	03	CXBSB_HEADER	= 00000048		
CLASS_DDT	= 00000010			CXBSL_END_ACTION	= 0000001C		
CLASS_DISCONNECT	= 00000018			CXBSL_IRP	= 00000014		
CLASS_GETNXT	= 00000000			CXBSL_T_CSB	0000000C	G	
CLASS_PUTNXT	= 00000004			CXBSL_T_ENDADR	0000001C	G	
CLASS_READERROR	= 00000014			CXBSL_T_SAVE	00000014	G	
CLASS_SETUP_UCB	= 00000008			CXBSQ_STATION	= 00000028		
CRBSL_INTD	= 00000024			CXBSW_BCNT	= 0000001A		
CRBSW_REFC	= 0000000C			CXBSW_BOFF	= 00000018		
CREDIT_CHECK	000010E2	R	03	CXBSW_LENGTH	= 0000000C		
CSB_B_FLAG	0000005C	G		CXBSW_OFFSET	= 0000000E		
CSB_B_INX	00000068	G		CXBSW_SIZE	= 00000008		
CSB_B_LOCIDN	00000060	G		DC\$ TERM	*****	X	02
CSB_B_LOCID	00000061	G		DDBSL_DDT	= 0000000C		
CSB_B_MAX_SLOTS	00000069	G		DDBSL_UCB	= 00000004		
CSB_B_NUM_SLOTS	0000005D	G		DEFREASN	00001752	R	03
CSB_B_RACK	00000065	G		DEVSM_AVL	= 00040000		
CSB_B_REFC	0000002D	G		DEVSM_CCL	= 00000002		
CSB_B_REMIDN	0000005E	G		DEVSM_IDV	= 04000000		
CSB_B_REMIDS	0000005F	G		DEVSM_NNM	= 00000200		
CSB_B_RSEQ	00000064	G		DEVSM_ODV	= 08000000		
CSB_B_SERVER	0000001C	G		DEVSM_REC	= 00000001		
CSB_B_SPARE	0000005B	G		DEVSM_TRM	= 00000004		
CSB_B_STATE	0000000B	G		DPTSB_FLAGS	= 0000000D		
CSB_B_TYPE	0000000A	G		DPTSC_LENGTH	= 00000038		
CSB_B_XACK	00000063	G		DPTSC_VERSION	= 00000004		
CSB_B_XCXB_INX	0000005A	G		DPT\$INITAB	00000038	R	02
CSB_B_XMTBSY	00000058	G		DPT\$M_NOUNLOAD	= 00000004		
CSB_B_XMTCNT	00000059	G		DPT\$REINITAB	000000D3	R	02
CSB_B_XSEQ	00000062	G		DPT\$TAB	00000000	R	02
CSB_C_FIXLENGTH	0000006C	G		DPT\$W_VECTOR	= 0000001E		
CSB_C_STATE_HALT	= 00000000	G		DYN\$C_BUFIO	= 00000013		
CSB_C_STATE_RUN	= 00000002	G		DYN\$C_CDB	= 00000033		
CSB_C_STATE_START	= 00000001	G		DYN\$C_CRB	= 00000005		
CSB_L_STOPREASON	0000004C	G		DYN\$C_CXB	= 0000001B		
CSB_L_UCBLST	0000006C	G		DYN\$C_DDB	= 00000006		
CSB_L_XCXB	00000044	G		DYN\$C_DPT	= 0000001E		
CSB_Q_XBUFQ	00000034	G		DYN\$C_ORB	= 00000049		
CSB_Q_XWAITQ	0000003C	G		DYN\$C_TQE	= 0000000F		
CSB_S_CIRCHDR	= 00000008	G		DYN\$C_UCB	= 00000010		
CSB_T_CIRCHDR	0000005C	G		ECHO_ERROR	0000101A	R	03
CSB_T_SERVER	0000001D	G		EIGHT	000019E7	R	03
CSB_W_LOCID	00000060	G		EXESALLOCTQE	*****	X	03
CSB_W_MAX_MSGSIZ	0000006A	G		EXESALONONPAGED	*****	X	03

LTDRIIVER
Symbol table

- Local Area Terminal Port Driver D 7

8-JAN-1985 17:22:25 VAX/VMS Macro V04-00
5-SEP-1984 11:40:22 [LAT.BUGSRC]LTDRIIVER.MAR;1

EXESAL_TQENOREPT	*****	X	03	GHBSL_STRETRY	= 00000010		
EXESDEANONPAGED	*****	X	03	GHBSL_TIM_ACT	= 00000018		
EXESFORK	*****	X	03	GHBSL_UCB	= 00000014		
EXESGB_CPUDATA	*****	X	03	GHBSL_XCOUNT	= 00000038		
EXESGB_CPUTYPE	*****	X	03	GHBSL_XERR	= 0000003C		
EXESGL_MP	*****	X	03	GHBSL_XERRCOD	= 00000040		
EXESGR_SYSTIME	*****	X	03	GHBSQ_OLD_CSBS	= 00000024		
EXESINSTIMQ	*****	X	03	GHBSS_COMM_AREA	= 00000060		
FFISB_SPARE	= 0000000B			GHBST_CSBCTR	= 0000000C		
FFISB_TYPE	= 0000000A			GHBST_BADCREDITS	= 00000008		
FFISC_LENGTH	= 0000003E			GHBST_CSBINVALID	= 00000003		
FFISL_BL	= 00000004			GHBST_CSBRANGE	= 00000002		
FFISL_CTX_DL	= 0000000C			GHBST_CSBSALE	= 00000004		
FFISL_DL_OCB	= 00000034			GHBST_CSZERO	= 00000001		
FFISL_ERROR	= 0000001C			GHBST_HALT	= 00000005		
FFISL_FL	= 00000000			GHBST_INVALIDLOCID	= 00000007		
FFISL_PID	= 00000038			GHBST_INVALIDDREMID	= 00000006		
FFISL_RECV_DONE	= 00000018			GHBST_INVALIDSEQ	= 0000000A		
FFISL_SHUT_DONE	= 00000020			GHBST_REPCREATE	= 00000009		
FFISL_SPARE0	= 00000024			GHBST_REPDISC	= 0000000B		
FFISL_SPARE1	= 00000028			GHBST_START	= 00000000		
FFISL_SPARE2	= 0000002C			GHBST_VMSVERSION	= 00000000		
FFISL_SPARE3	= 00000030			GHB_AREA	00000120	R	03
FFISL_XMIT	= 00000010			GHB_B_INCARN	00000199	R	03
FFISL_XMIT_DONE	= 00000014			GHB_B_LOC_CCHK	000000B8	R	03
FFISW_CHAN	= 0000003C			GHB_B_MAX_SLOTS	0000010C	R	03
FFISW_SIZE	= 00000008			GHB_B_OLD_CSBCNT	0000019A	R	03
FKBSB_FIPL	= 0000000B			GHB_B_RATE	0000019B	R	03
FLAG_M_MASTER	= 00000002	G		GHB_B_STATUS	00000198	R	03
FLAG_M_MTYPE	= 000000FC	G		GHB_C_STRT_SLOTL	= 00000005		
FLAG_M_RRF	= 00000001	G		GHB_G_TQE	000000DC	R	03
FLAG_S_MASTER	= 00000001	G		GHB_L_AREA	000004B8	R	03
FLAG_S_MTYPE	= 00000006	G		GHB_L_CSBTABLE	00000038	R	03
FLAG_S_RRF	= 00000001	G		GHB_L_DEADLINK	00000184	R	03
FLAG_V_MASTER	= 00000001	G		GHB_L_FFI	00000188	R	03
FLAG_V_MTYPE	= 00000002	G		GHB_L_LASTCPU	00000190	R	03
FLAG_V_RRF	= 00000000	G		GHB_L_MULTIBFR	000003F0	R	03
FOUR	000019EA	R	03	GHB_L_NULLCPU	0000018C	R	03
FUNCTAB_LEN	= 00000000			GHB_L_NULLSEC	00000194	R	03
GET MORE	00001196	R	03	GHB_L_UCBO	00000180	R	03
GHBSB_LATECO	= 00000003			GHB_Q_MULTIADD	000003E8	R	03
GHBSB_LATVERSION	= 00000002			GHB_STS_M_ACTIVE	= 00000002	G	
GHBSK_IDLEN	= 00000040			GHB_STS_M_MULTI	= 00000001	G	
GHBSK_NAMELEN	= 00000010			GHB_STS_M_SHUT	= 00000004	G	
GHBSL_CIRCDOWN	= 00000048			GHB_STS_M_TQE	= 00000008	G	
GHBSL_CSBLST	= 00000020			GHB_STS_S_ACTIVE	= 00000001	G	
GHBSL_DUPLMSG	= 00000034			GHB_STS_S_MULT:	= 00000001	G	
GHBSL_HISTORY	= 00000008			GHB_STS_S_SHUT	= 00000001	G	
GHBSL_NODE	= 0000001C			GHB_STS_S_TQE	= 00000001	G	
GHBSL_NOXBFR	= 00000058			GHB_STS_V_ACTIVE	= 00000001	G	
GHBSL_PROTOCOL	= 0000004C			GHB_STS_V_MULTI	= 00000000	G	
GHBSL_PROTOMASK	= 00000050			GHB_STS_V_SHUT	= 00000002	G	
GHBSL_RCOUNT	= 0000002C			GHB_STS_V_TQE	= 00000003	G	
GHBSL_RESOURCE	= 00000054			GHB_T_MAX_SLOT_TABLE	0000010D	R	03
GHBSL_RETRANS	= 00000044			GHB_T_MC_DATA	0000019E	R	03
GHBSL_SEENTRY	= 00000004			GHB_T_MC_MSG	000003F4	R	03
GHBSL_SHUTENTRY	= 0000000C			GHB_T_STRT_MSG	00000400	R	03

LTDRIVER
Symbol table

- Local Area Terminal Port Driver E 7

8-JAN-1985 17:22:25 VAX/VMS Macro V04-00
5-SEP-1984 11:40:22 [LAT.BUGSRC]LTDRIVER.MAR;1

GHB_T_STRT_SLOT	000004B1	R	03	LAT_C_CRSN_IVMSG	=	00000002		
GHB_T_STRT_VAR	0000040C	R	03	LAT_C_CRSN_IVSCI	=	00000003		
GHB_W_MC_SIZE	0000019C	R	03	LAT_C_CRSN_PROGRESS	=	00000006		
GHB_W_MULTIMR	000003EE	R	03	LAT_C_CRSN_RESOURCE	=	00000009		
GHB_W_STRT_LEN	000003FE	R	03	LAT_C_CRSN_RETRANS	=	00000008		
GOT_A_LOT	000011A7	R	03	LAT_C_CRSN_TIMRANG	=	0000000A		
HBF_L_BUFEND	= 00000004			LAT_C_CRSN_TMO	=	00000007		
HBF_L_NEXT	= 00000000			LAT_C_CRSN_XXX	=	00000000		
HBF_Z_DATA	= 0000000C			LCB_B_INV_MSG	=	0000000E		
INB_B_SPARE	0000000B	G		LCB_B_INV_SLOT	=	0000000F		
INB_B_TYPE	0000000A	G		LCB_C_LENGTH	=	00000010		
INB_C_LENGTH	0000000C	G		LCB_L_MSG_RCV	=	00000004		
INB_L_SPARE	00000004	G		LCB_L_MSG_REXMT	=	00000008		
INB_W_BCNT	00000002	G		LCB_L_MSG_XMT	=	00000000		
INB_W_BOFF	00000000	G		LCB_W_SEQ_ERR	=	0000000C		
INB_W_SIZE	00000008	G		LOAD_CREDITS		00000F93	R	03
IOCSCLONE_UCB	*****	X	03	LOOP_ABORT		00000F45	R	03
IOCSDELETE_UCB	*****	X	03	LOOP_EXIT		0000123E	R	03
IOCSGL_MUTEX	*****	X	03	LTSABORT		00000C6A	R	03
IOCSMNTVER	*****	X	03	LTSALC_UCB		00001547	R	03
IOCSRETURN	*****	X	03	LTSASYNCERR		00000964	R	03
IPLS_ASTDEL	= 00000002			LTSCIRCDEAD		0000172A	R	03
IPLS_QUEUEAST	= 00000006			LTSCREATECSB		0000126D	R	03
IPLS_SYNCH	= 00000008			LTSCREATEUCB		0000150A	R	03
IPLS_TIMER	= 00000008			LTSCTRL_INIT		00000658	R	03
LATSC_CIR_TIMER	= 00000050			LTSDDT		00000000	RG	03
LATSC_CUR_ECO	= 00000000			LTSDEALOCBS		00001420	R	03
LATSC_CUR_VER	= 00000005			LTSDEALPOOL		00001BD9	R	03
LATSC_GRP_LEN	= 00000020			LTSDESTROYUCB		0000151F	R	03
LATSC_HI_VER	= 00000005			LTSDISCONNECT		000016A7	R	03
LATSC_HOST_TIMER	= 00000002			LTSDPT		00000000	RG	02
LATSC_IPL	= 00000008			LTSDROPXCB		00001BD8	R	03
LATSC_KEEP_CSB	= 0000000A			LTSEND		00001BDF	R	03
LATSC_LOC_LEN	= 00000040			LTSFFIPOSTDONE		00001BCF	R	03
LATSC_LO_VER	= 00000005			LTSFFI_RCV_MSG		00000D1C	R	03
LATSC_MAX_CSBS	= 00000020			LTSFLOW_CHANGE		00000C78	R	03
LATSC_MAX_MSGSIZ	= 000005DC			LTSFLUSH_DATA		00000C59	R	03
LATSC_MAX_RCRD	= 00000001			LTSFORCE_HALT		00000E4C	R	03
LATSC_MAX_SERVICES	= 00000006			LTSGETFFI		000007E0	R	03
LATSC_MAX_SLOTS	= 00000040			LTSHANGUP_UCB		00001690	R	03
LATSC_MAX_SLOTSIZ	= 000000FF			LTSHANGUP_UCB_NOW		00001683	R	03
LATSC_MULTIADD1	= 00000009			LTSHISTORY		00000727	R	03
LATSC_MULTIADD2	= 0000002B			LTSKILLUCB		000016D6	R	03
LATSC_MULTIADD3	= 00000F00			LTSNEW_CIRCUIT		000012D0	R	03
LATSC_MULTI_TIMER	= 0000000A			LTSNULL		000004F8	R	03
LATSC_PROGRESS	= 00000014			LTSRCV_HALT_MSG		00000E62	R	03
LATSC_SHUTDELAY	= 004C4B40			LTSRCV_RUN_MSG		00000E75	R	03
LATSC_SVC_LEN	= 00000008			LTSRCV_START_MSG		00000E68	R	03
LATSC_UCB_BUFSIZ	= 00000050			LTSREPLY_ALT		0000125A	R	03
LATSC_UCB_SLOTSIZ	= 00000004			LTSREPLY_DONE		00001260	R	03
LATSC_UCB_TIMEOUT	= 00000002			LTSREPLY_MSG		00001256	R	03
LATSC_VMS	= 00000003			LTSREPLY_REXMIT		00001265	R	03
LATSC_VMS_VER	= 00000004			LTSREXMIT		00001AD4	R	03
LATSC_XMT_BUFFERS	= 00000002			LTSSETENTRY		00000965	R	03
LAT_C_CRSN_DISC	= 00000005			LTSSET_TIMER		00001818	R	03
LAT_C_CRSN_DONE	= 00000001			LTSSET_TIMER		00000835	R	03
LAT_C_CRSN_IVMCI	= 00000004			LTSSET_TIMER		00000953	RG	03

LTDRIVER
Symbol table

- Local Area Terminal Port Driver F 7

8-JAN-1985 17:22:25 VAX/VMS Macro V04-00
5-SEP-1984 11:40:22 [LAT.BUGSRC]LTDRIVER.MAR;1

```

LTSSIDELINEUCB      00001709 R      03
LTSSSTARTIO         00000ADE R      03
LTSSTATE_ENTER_RUN 00000EA6 R      03
LTSSTATE_HALT       00000E5C R      03
LTSSTATE_RUN        00000EAE R      03
LTSSTATE_START      00000E82 R      03
LTSSTOPCIRC         0000176B R      03
LTSSTRETRY          0000075D R      03
LTSTICK             0000188C R      03
LTSUCB_INIT         00000A9B R      03
LTSUNIT_INIT        00000A2F R      03
LTSVEC              000004BC R      03
LTSVECEND           000004F4 R      03
LTSVECTOR           000004BC R      03
LTSXMIT             00001A6F R      03
LTSXMITONE          00001AA0 R      03
LTSXMTGO            00001AED R      03
LTSXMT_FFIDONE      00001B54 R      03
LTSXOFF             00000CCE R      03
LTSXON              00000C7E R      03
LT_HISTORY          = 00000001
LT_RSN_BADCREDITS   000005E9 R      03
LT_RSN_CSBINVALID   00000561 R      03
LT_RSN_CSBRANGE     00000541 R      03
LT_RSN_CSBSTALE     0000057C R      03
LT_RSN_CSBZERO      00000529 R      03
LT_RSN_HALT         00000598 R      03
LT_RSN_INVALIDLOCID 000005B3 R      03
LT_RSN_INVALIDREMID 000005CE R      03
LT_RSN_REPCREATE    0000060C R      03
LT_RSN_REPDISC      00000630 R      03
LT_RSN_START        000004F9 R      03
MAX_PR_SID          = 00000010
MMSGGL_MAXPFN      ***** X      03
MPSSGL_NULLCPU     ***** X      03
MTXSW_OWCNT        = 00000000
MTYP_C_CONF        = 0000000A G
MTYP_C_HALT        = 00000002 G
MTYP_C_RUN         = 00000000 G
MTYP_C_START       = 00000001 G
NEXT_SLOT          00001007 R      03
NEXT_SLOT0         00000F90 R      03
ONE                000019F0 R      03
ONE_LESS           0000104C R      03
ORBSB_FLAGS        = 0000000B
ORBSL_OWNER        = 00000000
ORBSM_PROT_16      = 00000001
ORBSW_PROT         = 00000018
PCBSL_PND          = 0000006C
PHDSL_CPUTIM       = 00000038
PORT_ABORT         = 00000020
PORT_DISCONNECT     = 00000004
PORT_LENGTH        = 00000038
PORT_SET_LINE      = 0000000B
PORT_STARTIO       = 000C0000
PORT_XOFF          = 00000014
PORT_XON           = 00000010

```

```

PRS_IPL             = 00000012
PRS_SID_TYP730     = 00000003
PRS_SID_TYP750     = 00000002
PRS_SID_TYP780     = 00000001
PRS_SID_TYP785     = 00000009
PRS_SID_TYP790     = 00000004
PRS_SID_TYPMAX     = 00000008
PRS_SID_TYPUV1     = 00000007
PRS_SID_TYPUV2     = 00000008
RCV_B_ACK          00000007 G
RCV_B_DSTIDN       00000002 G
RCV_B_DSTIDS       00000003 G
RCV_B_FLAG         00000000 G
RCV_B_NUM_SLOTS    00000001 G
RCV_B_SEQ          00000006 G
RCV_B_SRCIDN       00000004 G
RCV_B_SRCIDS       00000005 G
RCV_T_DATA         00000000 G
RCV_T_MDATA        00000008 G
RCV_W_DSTID        00000002 G
RCV_W_SRCID        00000004 G
RSNS_AWAIT         = 00000001
SCHSGL_CURPCB      ***** X
SCHSGL_NULLPCB     ***** X
SCHSRVAIL          ***** X
SCHSRWAIT          ***** X
SEND_STOP_SLOT     00001020 R
SHUT_TIMER         00000936 R
SIZ...             = 00000001
SLOT_LOOP_IN       00000ED9 R
SLOT_LOOP_OUT      00001044 R
SLOT_SIZE          = 00000020
SLT_ATT_M_ABORT    = 00000020 G
SLT_ATT_S_ABORT    = 00000001 G
SLT_ATT_V_ABORT    = 00000005 G
SLT_B_ATT_CONTROL  00000004 G
SLT_B_ATT_SLTSIZ   00000005 G
SLT_B_COUNT        00000002 G
SLT_B_CRED         00000003 G
SLT_B_DB_CONTROL   00000004 G
SLT_B_DB_IFOF      00000007 G
SLT_B_DB_IFON      00000008 G
SLT_B_DB_OFOF      00000005 G
SLT_B_DB_OFON      00000006 G
SLT_B_DSTID        00000000 G
SLT_B_DST_NAMLEN   00000007 G
SLT_B_DT_SLTSIZ    00000006 G
SLT_B_PARAMS       00000029 G
SLT_B_REAS         00000003 G
SLT_B_REJ_RLEN     00000004 G
SLT_B_SRCID        00000001 G
SLT_B_SRC_NAME     00000019 G
SLT_B_SRC_NAMLEN   00000018 G
SLT_B_STP_RLEN     00000004 G
SLT_B_SVCC         00000004 G
SLT_B_TYPE         = 00000003 G
SLT_C_ATT_SLOT     = 0000000B G

```

LTDRIVER
Symbol table

- Local Area Terminal Port Driver

6 7

8-JAN-1985 17:22:25 VAX/VMS Macro V04-00
5-SEP-1984 11:40:22 [LAT.BUGSRC]LTDRIVER.MAR;1

```

SLT_C_DA_SLOT = 00000000 G
SLT_C_DB_SLOT = 0000000A G
SLT_C_INVSLT = 00000003 G
SLT_C_INVSVC = 00000004 G
SLT_C_REJ_SLOT = 0000000C G
SLT_C_RESOURCE = 00000005 G
SLT_C_START_FLAG = 00000001 G
SLT_C_STP_SLOT = 0000000D G
SLT_C_STR_SLOT = 00000009 G
SLT_C_SVC_INTT = 00000001 G
SLT_C_SYS = 00000002 G
SLT_C_USD = 00000001 G
SLT_DB_M_BREAK = 00000010 G
SLT_DB_M_IFDIS = 00000002 G
SLT_DB_M_IFENA = 00000001 G
SLT_DB_M_OFDIS = 00000008 G
SLT_DB_M_OFENA = 00000004 G
SLT_DB_S_BREAK = 00000001 G
SLT_DB_S_IFDIS = 00000001 G
SLT_DB_S_IFENA = 00000001 G
SLT_DB_S_OFDIS = 00000001 G
SLT_DB_S_OFENA = 00000001 G
SLT_DB_V_BREAK = 00000004 G
SLT_DB_V_IFDIS = 00000001 G
SLT_DB_V_IFENA = 00000000 G
SLT_DB_V_OFDIS = 00000003 G
SLT_DB_V_OFENA = 00000002 G
SLT_FLAG_M_BIND = 00000004 G
SLT_FLAG_M_LOGIN = 00000002 G
SLT_FLAG_M_REMOTE = 00000001 G
SLT_FLAG_S_BIND = 00000001 G
SLT_FLAG_S_LOGIN = 00000001 G
SLT_FLAG_S_REMOTE = 00000001 G
SLT_FLAG_V_BIND = 00000002 G
SLT_FLAG_V_LOGIN = 00000001 G
SLT_FLAG_V_REMOTE = 00000000 G
SLT_S_ATT_LEN = 00000001 G
SLT_S_ATT_SLOT = 00000005 G
SLT_S_DB_LEN = 00000005 G
SLT_S_DB_SLOT = 00000009 G
SLT_S_REJ_LEN = 00000000 G
SLT_S_REJ_SLOT = 00000004 G
SLT_S_START_SLOT = 00000025 G
SLT_S_STP_LEN = 00000001 G
SLT_S_STP_SLOT = 00000005 G
SLT_T_DATA = 00000004 G
SLT_T_DST_NAME = 00000008 G
SLT_T_REJ_REAS = 00000004 G
SLT_T_START = 00000000 G
SLT_T_STP_REAS = 00000005 G
SSB_IRSFMEM = ***** X 03
SSB_NORMAL = ***** X 03
STOP_B_RCODE = 00000000 G
STOP_B_RLEN = 00000001 G
STOP_TQE = 0000187C R 03
STOP_T_REAS = 00000002 G
STRT_B_CIR_TIMR = 00000006 G

```

```

STRT_B_DL_BFRS = 00000005 G
STRT_B_ID_LEN = 0000002E G
STRT_B_KPA_TIMR = 00000007 G
STRT_B_LOC_LEN = 0000006F G
STRT_B_MAXSLOTS = 00000004 G
STRT_B_NODE_LEN = 0000000C G
STRT_B_PARAM = 00000080 G
STRT_B_PECO = 00000003 G
STRT_B_PVER = 00000002 G
STRT_B_SYS_LEN = 0000001D G
STRT_B_VAR = 0000000C G
STRT_C_LENGTH = 0000000C G
STRT_C_VAR_LEN = = 000000A5 G
STRT_T_ID = 0000002F G
STRT_T_LOC = 00000070 G
STRT_T_NODE = 0000000D G
STRT_T_SYS = 0000001E G
STRT_W_FAC_NUM = 00000008 G
STRT_W_MSGSIZ = 00000000 G
STRT_W_PROD_TYP = 0000000A G
SYSSGW_IJOBENT = ***** X 03
SYSSGW_IJOBLIM = ***** X 03
THREE = 000019EC R
TQESB_RQTYPE = = 00000008 G
TQESB_TYPE = = 0000000A G
TQESC_LENGTH = = 00000030 G
TQESC_SSREPT = = 00000005 G
TQESC_SSSNGL = = 00000001 G
TQESL_FPC = = 0000000C G
TQESM_REPEAT = = 00000004 G
TQESQ_DELTA = = 00000020 G
TQESW_SIZE = = 00000008 G
TTSV_HOSTSYNC = = 00000004 G
TTSV_PASSALL = = 00000000 G
TTSV_REMOTE = = 0000000D G
TTSV_TTSYNC = = 00000005 G
TTS_UNKNOWN = = 00000000 G
TT2SV_AUTOBAUD = = 00000001 G
TT2SV_HANGUP = = 00000002 G
TTYSGB_DEFSPEED = ***** X 02
TTYSGB_PARITY = ***** X 02
TTYSGB_RSPEED = ***** X 02
TTYSGL_DEFCHAR = ***** X 02
TTYSGL_DEFCHAR2 = ***** X 02
TTYSGL_DELTA = ***** X 03
TTYSGL_DPT = ***** X 03
TTYSGL_OWNUIC = ***** X 02
TTYSGW_DEFBUF = ***** X 02
TTYSGW_PROT = ***** X 02
TTYSV_PC_NOTIME = = 00000000 G
TTY_C_BECL = = 00000007 G
TWO = 000019EE R 03
UCBSB_DEVCLASS = = 00000040 G
UCBSB_DEVTYPE = = 00000041 G
UCBSB_DIPL = = 0000005E G
UCBSB_ERTCNT = = 00000080 G
UCBSB_FIPL = = 00000008 G

```

03
03

X X X X X X X X
02
02
02
03
02
02

03

LTDRIVER
Symbol table

- Local Area Terminal Port Driver H 7

8-JAN-1985 17:22:25 VAX/VMS Macro V04-00
5-SEP-1984 11:40:22 [LAT.BUGSRC]LTDRIVER.MAR;1

Page 118
(66)

UCBSB_LT_CBUF	0000014C	G	UCBSS_LT_DATA	= 00000001	G
UCBSB_LT_CURC	0000014B	G	UCBSS_LT_DEAD	= 00000001	G
UCBSB_LT_DATAW	00000142	G	UCBSS_LT_FLOW	= 00000001	G
UCBSB_LT_EBUF	0000019C	G	UCBSS_LT_HANGUP	= 00000001	G
UCBSB_LT_LATSTS	00000143	G	UCBSS_LT_INPUT	= 00000001	G
UCBSB_LT_LOCID	00000141	G	UCBSS_LT_OVFLOW	= 00000001	G
UCBSB_LT_MAXC	0000014A	G	UCBSV_DELETEUCB	= 00000010	
UCBSB_LT_RCRED	00000148	G	UCBSV_LT_ABORT	= 00000002	G
UCBSB_LT_REASON	00000145	G	UCBSV_LT_BOUND	= 00000003	G
UCBSB_LT_REMID	00000140	G	UCBSV_LT_DATA	= 00000000	G
UCBSB_LT_SLOTSZ	00000149	G	UCBSV_LT_DEAD	= 00000001	G
UCBSB_LT_STATE	00000144	G	UCBSV_LT_FLOW	= 00000001	G
UCBSB_LT_TCRED	00000146	G	UCBSV_LT_HANGUP	= 00000000	G
UCBSB_LT_XCRED	00000147	G	UCBSV_LT_INPUT	= 00000004	G
UCBSB_TT_DEPARI	= 000000EC		UCBSV_LT_OVFLOW	= 00000002	G
UCBSB_TT_DETYPE	= 000000F0		UCBSV_POWER	= 00000005	
UCBSB_TT_OUTYPE	= 0000010B		UCBSV_TEMPLATE	= 0000000D	
UCBSC_LT_LENGTH	0000019C	G	UCBSW_DEVBUFSIZ	= 00000042	
UCBSC_LT_STATE_KILL	= 00000004	G	UCBSW_DEVSTS	= 00000068	
UCBSC_LT_STATE_RUN	= 00000002	G	UCBSW_ERRCNT	= 00000082	
UCBSC_LT_STATE_START	= 00000001	G	UCBSW_MB_SEED	= 00000000	
UCBSC_LT_STATE_STOP	= 00000003	G	UCBSW_REFC	= 0000005C	
UCBSC_TT_LENGTH	= 00000134		UCBSW_TT_DESIZE	= 000000F1	
UCBSL_CRB	= 00000024		UCBSW_TT_DESPEE	= 000000E8	
UCBSL_DDB	= 00000028		UCBSW_TT_OUTLEN	= 00000120	
UCBSL_DDT	= 00000088		UCBSW_TT_PRTCTL	= 00000122	
UCBSL_DEVCHAR	= 00000038		UCBSW_TT_SPEED	= 000000F4	
UCBSL_DEVCHAR2	= 0000003C		UCBSW_UNIT	= 00000054	
UCBSL_DEVDEPEND	= 00000044		USE_CREDIT	000011D6	R 03
UCBSL_LT_CSB	00000134	G	USE_CREDIT1	000011DC	R 03
UCBSL_LT_DEADLINK	00000138	G	VECSL_INITIAL	= 0000000C	
UCBSL_LT_INPBUF	0000013C	G	VECSL_START	= 0000001C	
UCBSL_STS	= 00000064		VECSL_UNITINIT	= 00000018	
UCBSL_TT_CLASS	= 00000114		XMT_B_ACK	0000004F	G
UCBSL_TT_DECHA1	= 000000C8		XMT_B_DSTIDN	0000004A	G
UCBSL_TT_DECHAR	= 000000C4		XMT_B_DSTIDS	0000004B	G
UCBSL_TT_DEVDP1	= 00000048		XMT_B_FLAG	00000048	G
UCBSL_TT_GETNXT	= 0000010C		XMT_B_MC_CHG_FLAG	0000004F	G
UCBSL_TT_LOGUCB	= 000000C0		XMT_B_MC_CIR_TIMER	00000049	G
UCBSL_TT_OUTADR	= 0000011C		XMT_B_MC_CUR_ECO	0000004D	G
UCBSL_TT_PORT	= 00000118		XMT_B_MC_CUR_VER	0000004C	G
UCBSL_TT_PUTNXT	= 00000110		XMT_B_MC_GRP_LEN	00000054	G
UCBSL_TT_RTIMOU	= 00000084		XMT_B_MC_HI_VER	0000004A	G
UCBSL_TT_WBLINK	= 000000D0		XMT_B_MC_ID_LEN	00000099	G
UCBSL_TT_WFLINK	= 000000CC		XMT_B_MC_INCARN	0000004E	G
UCBSM_INT	= 00000002		XMT_B_MC_LO_VER	0000004B	G
UCBSM_LT_ABORT	= 00000004	G	XMT_B_MC_MUXTMR	00000052	G
UCBSM_LT_BOUND	= 00000008	G	XMT_B_MC_NAME_LEN	00000088	G
UCBSM_LT_DATA	= 00000001	G	XMT_B_MC_NODE_LEN	00000075	G
UCBSM_LT_DEAD	= 00000002	G	XMT_B_MC_NUM_SVCS	00000086	G
UCBSM_LT_FLOW	= 00000002	G	XMT_B_MC_RATE	00000087	G
UCBSM_LT_HANGUP	= 00000001	G	XMT_B_MC_SET	00000052	G
UCBSM_LT_INPUT	= 00000010	G	XMT_B_MC_STATUS	00000053	G
UCBSM_LT_OVFLOW	= 00000004	G	XMT_B_MC_SVC	0000027A	G
UCBSM_ONLINE	= 00000010		XMT_B_MC_SVC_LEN	00000279	G
UCBSS_LT_ABORT	= 00000001	G	XMT_B_NUM_SLOTS	00000049	G
UCBSS_LT_BOUND	= 00000001	G	XMT_B_SEQ	0000004E	G

LTDRIVER
Symbol table

- Local Area Terminal Port Driver ¹ 7

8-JAN-1985 17:22:25 VAX/VMS Macro V04-00
5-SEP-1984 11:40:22 [LAT.BUGSRC]LTDRIVER.MAR;1

Page 119
(66)

```

XMT_B_SRCIDN      0000004C  G
XMT_B_SRCIDS      0000004D  G
XMT_CHFLG_M_ALL   = 000000FF  G
XMT_CHFLG_M_CLASS = 00000020  G
XMT_CHFLG_M_GROUP = 00000001  G
XMT_CHFLG_M_NDESC = 00000002  G
XMT_CHFLG_M_OTHER = 00000080  G
XMT_CHFLG_M_RATE  = 00000008  G
XMT_CHFLG_M_SDESC = 00000010  G
XMT_CHFLG_M_SVCNAM = 00000004  G
XMT_CHFLG_S_CLASS = 00000001  G
XMT_CHFLG_S_GROUP = 00000001  G
XMT_CHFLG_S_NDESC = 00000001  G
XMT_CHFLG_S_OTHER = 00000001  G
XMT_CHFLG_S_RATE  = 00000001  G
XMT_CHFLG_S_SDESC = 00000001  G
XMT_CHFLG_S_SVCNAM = 00000001  G
XMT_CHFLG_V_CLASS = 00000005  G
XMT_CHFLG_V_GROUP = 00000000  G
XMT_CHFLG_V_NDESC = 00000001  G
XMT_CHFLG_V_OTHER = 00000007  G
XMT_CHFLG_V_RATE  = 00000003  G
XMT_CHFLG_V_SDESC = 00000004  G
XMT_CHFLG_V_SVCNAM = 00000002  G
XMT_C_HDRLEN      = 00000008  G
XMT_C_MAXDATA     = 000005D4  G
XMT_C_MAXLEN      = 00000624  G
XMT_C_MC_LENGTH   = 0000000A  G
XMT_C_MC_SVC_SIZE = 00000053  G
XMT_C_MC_TOTAL    = 0000023A  G
XMT_G_DST         = 0000003A  G
XMT_T_DATA        = 00000048  G
XMT_T_MC_GROUP    = 00000055  G
XMT_T_MC_ID       = 0000009A  G
XMT_T_MC_MORE_SVC = 000000DA  G
XMT_T_MC_NAME     = 00000089  G
XMT_T_MC_NODE     = 00000076  G
XMT_T_MDATA       = 00000050  G
XMT_W_DSTID       = 0000004A  G
XMT_W_MC_MSG_SIZE = 00000050  G
XMT_W_SRCID       = 0000004C  G
    
```

! Psect synopsis !

PSECT name	Allocation	PSECT No.	Attributes
.ABS	00000000 (0.)	00 (0.)	NOPIC USR CON ABS LCL NOSHR NOEXE NORD NOWRT NOVEC BYTE
\$ABS\$	00000282 (642.)	01 (1.)	NOPIC USR CON ABS LCL NOSHR EXE RD WRT NOVEC BYTE
\$\$\$105_PROLOGUE	000000DE (222.)	02 (2.)	NOPIC USR CON REL LCL NOSHR EXE RD WRT NOVEC BYTE
\$\$\$115_DRIVER	00001BDF (7135.)	03 (3.)	NOPIC USR CON REL LCL NOSHR EXE RD WRT NOVEC LONG

! Performance indicators !

Phase	Page faults	CPU Time	Elapsed Time
-----	-----	-----	-----
Initialization	96	00:00:00.19	00:00:02.34
Command processing	137	00:00:00.50	00:00:03.20
Pass 1	1002	00:00:31.72	00:01:40.19
Symbol table sort	2	00:00:03.08	00:00:07.20
Pass 2	428	00:00:09.41	00:00:29.42
Symbol table output	2	00:00:00.39	00:00:00.73
Psect synopsis output	2	00:00:00.01	00:00:00.01
Cross-reference output	0	00:00:00.00	00:00:00.00
Assembler run totals	1671	00:00:45.31	00:02:23.10

The working set limit was 3000 pages.
233724 bytes (457 pages) of virtual memory were used to buffer the intermediate code.
There were 160 pages of symbol table space allocated to hold 2613 non-local and 352 local symbols.
4681 source lines were read in Pass 1, producing 49 object records in Pass 2.
105 pages of virtual memory were used to define 97 macros.

! Macro library statistics !

Macro library name	Macros defined
-----	-----
\$255SDUA18:[LAT.OBJ]LAT.MLB;2	1
\$255SDUA18:[SYS.OBJ]LIB.MLB;1	39
\$255SDUA18:[SYSLIB]STARLET.MLB;3	10
TOTALS (all libraries)	50

2819 GETS were required to define 50 macros.

There were no errors, warnings or information messages.

MACRO/LIS=LIS\$:LTDRIVER/OBJ=OBJ\$:LTDRIVER MSRCS:LTDRIVER/UPDATE=(BUGS:LTDRIVER)+EXECMLS/LIB+LIBS:LAT/LIB

0444 AH-EF71A-SE
VAX/VMS V4.1 SRC LST MCRF UPD

A grid of 16 columns and 20 rows of source code listings. Each cell contains a small window of text, likely representing a single line or a small block of code from a larger file. The text is too small to read in detail but appears to be a mix of comments and code lines. Some larger, bolded text is visible in several cells, including:

- LTDRIVER MAP
- LTDRIVER LIS
- TRUNC LIS
- RWUB LIS
- SMALOC LIS
- SNDR LIS
- LAT

