

64000

**HP64000
Logic Development
System**

**Model 64602A
Timing Acquisition Board**

 **HEWLETT
PACKARD**

CERTIFICATION

Hewlett-Packard Company certifies that this product met its published specifications at the time of shipment from the factory. Hewlett-Packard further certifies that its calibration measurements are traceable to the United States National Bureau of Standards, to the extent allowed by the Bureau's calibration facility, and to the calibration facilities of other International Standards Organization members.

WARRANTY

This Hewlett-Packard system product is warranted against defects in materials and workmanship for a period of 90 days from date of installation. During the warranty period, HP will, at its options, either repair or replace products which prove to be defective.

Warranty service of this product will be performed at Buyer's facility at no charge within HP service travel areas. Outside HP service travel areas, warranty service will be performed at Buyer's facility only upon HP's prior agreement and Buyer shall pay HP's round trip travel expenses. In all other cases, products must be returned to a service facility designated by HP.

For products returned to HP for warranty service. Buyer shall prepay shipping charges to HP and HP shall pay shipping charges to return the product to Buyer. However, Buyer shall pay all shipping charges, duties, and taxes for products returned to HP from another country.

HP warrants that its software and firmware designated by HP for use with an instrument will execute its programming instructions when properly installed on that instrument. HP does not warrant that the operation of the instrument, or software, or firmware will be uninterrupted or error free.

LIMITATION OF WARRANTY

The foregoing warranty shall not apply to defects resulting from improper or inadequate maintenance by Buyer, Buyer-supplied software or interfacing, unauthorized modification or misuse, operation outside of the environmental specifications for the product, or improper site preparation or maintenance.

NO OTHER WARRANTY IS EXPRESSED OR IMPLIED. HP SPECIFICALLY DISCLAIMS THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

EXCLUSIVE REMEDIES

THE REMEDIES PROVIDED HEREIN ARE BUYER'S SOLE AND EXCLUSIVE REMEDIES. HP SHALL NOT BE LIABLE FOR ANY DIRECT, INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, WHETHER BASED ON CONTRACT, TORT, OR ANY OTHER LEGAL THEORY.

ASSISTANCE

Product maintenance agreements and other customer assistance agreements are available for Hewlett-Packard products.

For any assistance, contact your nearest Hewlett-Packard Sales and Service Office. Addresses are provided at the back of this manual.

HEWLETT-PACKARD
SERVICE MANUAL
MODEL 64602A
TIMING ACQUISITION BOARD

REPAIR NUMBERS

This Manual applies directly to Models
with Repair Numbers prefixed 2148A.

© COPYRIGHT HEWLETT-PACKARD COMPANY 1982,1983
LOGIC SYSTEMS DIVISION
COLORADO SPRINGS, COLORADO, U.S.A.

ALL RIGHTS RESERVED

Manual Part Number: 64602-90902
Microfiche Part Number: 64602-90802

PRINTED: OCTOBER 1982
CHANGED: NOVEMBER 1982

SAFETY SUMMARY

The following general safety precautions must be observed during all phases of operation, service, and repair of this instrument. Failure to comply with these precautions or with specific warnings elsewhere in this manual violates safety standards of design, manufacture, and intended use of the instrument. Hewlett-Packard Company assumes no liability for the customer's failure to comply with these requirements.

GROUND THE INSTRUMENT.

To minimize shock hazard, the instrument chassis and cabinet must be connected to an electrical ground. The instrument is equipped with a three-conductor ac power cable. The power cable must either be plugged into an approved three-contact electrical outlet or used with a three-contact to two-contact adapter with the grounding wire (green) firmly connected to an electrical ground (safety ground) at the power outlet. The power jack and mating plug of the power cable meet International Electrotechnical Commission (IEC) safety standards.

DO NOT OPERATE IN AN EXPLOSIVE ATMOSPHERE.

Do not operate the instrument in the presence of flammable gases or fumes. Operation of any electrical instrument in such an environment constitutes a definite safety hazard.

KEEP AWAY FROM LIVE CIRCUITS.

Operating personnel must not remove instrument covers. Component replacement and internal adjustments must be made by qualified maintenance personnel. Do not replace components with power cable connected. Under certain conditions, dangerous voltages may exist even with the power cable removed. To avoid injuries, always disconnect power and discharge circuits before touching them.

DO NOT SERVICE OR ADJUST ALONE.

Do not attempt internal service or adjustment unless another person, capable of rendering first aid and resuscitation, is present.

DO NOT SUBSTITUTE PARTS OR MODIFY INSTRUMENT.

Because of the danger of introducing additional hazards, do not install substitute parts or perform any unauthorized modification of the instrument. Return the instrument to a Hewlett-Packard Sales and Service Office for service and repair to ensure that safety features are maintained.

DANGEROUS PROCEDURE WARNINGS.

Warnings, such as the example below, precede potentially dangerous procedures throughout this manual. Instructions contained in the warnings must be followed.

WARNING

**Dangerous voltages, capable of causing death, are present in this instrument.
Use extreme caution when handling, testing, and adjusting.**

TABLE OF CONTENTS

Section	Page
I	GENERAL INFORMATION.....1-1
	1-1. Introduction.....1-1
	1-4. Instruments Covered by this Manual.....1-1
	1-9. Description.....1-2
	1-14. Specifications.....1-2
II	INSTALLATION.....2-1
	2-1. Introduction.....2-1
	2-3. Initial Inspection.....2-1
	2-7. Installation Instructions.....2-1
	2-23. Operating, Storage, and Shipment Environment.....2-3
III	OPERATION.....3-1
IV	PERFORMANCE TESTS & TROUBLESHOOTING.....4-1
	4-2. Introduction.....4-1
	4-16. Physical Setup.....4-3
	4-18. Keyboard Setup (All 9 Tests).....4-4
	4-20. Keyboard Setup (One Test).....4-5
	4-22. Explanation of Test Descriptions.....4-5
	4-26. Test 1: Serial Programming.....4-6
	4-30. Test 2: Ram Counters.....4-7
	4-34. Test 3: Fast Sample Test.....4-8
	4-38. Test 4: Dual Threshold Mode.....4-9
	4-43. Test 5: Glitch Mode Test.....4-11
	4-48. Test 6: DACs Trigger Test.....4-13
	4-51. Test 7: Checker Board.....4-14
	4-54. Test 8: RAM Filled.....4-15
	4-57. Test 9: Galloping One's.....4-16
	4-59. Supplementary Board ID Test.....4-18
	4-61. Supplementary PV Skew Test.....4-19
	4-69. PV Softkey Sequence.....4-22
	4-70. Signature Analysis.....4-27

TABLE OF CONTENTS (CONTINUED)

Section	Page
V	ADJUSTMENTS.....5-1
5-1.	Introduction.....5-1
5-3.	Safety Requirements.....5-1
5-5.	Equipment Required.....5-1
5-7.	Description.....5-1
5-10.	Keyboard Setup.....5-2
5-12.	DACs Negative Full Scale Adjustment.....5-2
5-14.	DACs Positive Full Scale Adjustment.....5-3
VI	REPLACEABLE PARTS.....6-1
6-1.	Introduction.....6-1
6-3.	Abbreviations.....6-1
6-5.	Replaceable Parts.....6-1
6-7.	Ordering Information.....6-2
6-10.	Spare Parts Kit.....6-2
6-12.	Direct Mail Order System.....6-2
VII	MANUAL CHANGES.....7-1
VIII	THEORY AND SCHEMATICS.....8-1
8-1.	Introduction.....8-1
8-6.	Theory and Block Diagrams.....8-2
8-29.	Logic Convention.....8-9
8-34.	Mnemonics.....8-10

LIST OF ILLUSTRATIONS

Figure	Title	Page
1-1.	Model 64602A Timing Acquisition Board.....	1-0
2-1.	Timing Configuration.....	2-2
2-2.	Timing Bus Cables.....	2-4
4-1.	PV Test Display.....	4-4
4-2.	Skew Test Setup.....	4-19
4-3.	First Skew Test.....	4-20
4-4.	Second Skew Test.....	4-21
4-4.	PV Softkey Sequence (Figures 4-5 to 4-13).....	4-22
5-1.	Adjustment Locator.....	5-3
8-1.	Probe and Glitch Chip Block Diagram.....	8-3
8-2.	Serial-To-Parallel Encoders Block Diagram.....	8-5
8-3.	Acquisition Board Block Diagram.....	8-7
8-4.	System Block Diagram.....	8-8
8-5.	Service Sheet 1: Mode Selection.....	8-16
8-6.	Service Sheet 2: Memory Address Counters (MACs).....	8-18
8-7.	Service Sheet 3: DACs, Probe Bus, & Timing Bus.....	8-20
8-8.	Service Sheet 4: Glitch Chip & Encoders.....	8-22
8-9.	Service Sheet 5: Acquisition Memory.....	8-24

LIST OF TABLES

Table	Title	Page
6-1.	Reference Designators and Abbreviations.....	6-3
6-2.	Replaceable Parts List.....	6-4
6-3.	List of Manufacturer's Code.....	6-7
8-1.	64602A Mnemonics.....	8-10
8-2.	Logic Symbolology.....	8-14

General Information - Model 64602A




Figure 1-1. Model 64602A Timing Acquisition Board

SECTION I

GENERAL INFORMATION

1-1. INTRODUCTION.

1-2. This Service Manual contains information required to install, test and service the Hewlett-Packard Model 64602A Timing Analysis Acquisition Board. Operating instructions are provided in a separate Operating Manual supplied with the instrument.

1-3. Shown on the title page is a microfiche part number. This number can be used to order 4X6-inch microfilm transparencies of the manual. Each microfiche contains up to 96 photoduplicates of the manual pages.

1-4. INSTRUMENTS COVERED BY THIS MANUAL.

1-5. Attached to the instrument or printed on the printed circuit board is the repair number. The repair number is in the form: 0000A0000. It is in two parts; the first four digits and the letter are the repair prefix, and the last five are the suffix. The prefix is the same for all identical instruments. The suffix, however, is assigned sequentially and is different for each instrument. The contents of this manual apply to instruments with the repair number prefix(es) listed under REPAIR NUMBERS on the title page.

1-6. An instrument manufactured after the printing of this manual may have a repair number prefix that is not listed on the title page. This unlisted repair number prefix indicates that the instrument is different from those described in this manual. The manual for this newer instrument is accompanied by a Manual Changes supplement. This supplement contains "change information" that explains how to adapt the manual for the newer instrument.

1-7. In addition to change information, the supplement contains information for correcting errors in the manual. To keep this manual as current as possible, Hewlett-Packard recommends that you periodically request the latest Manual Changes supplement. The supplement for this manual is identified with the manual print date and part number, both of which appear on the manual title page. Complimentary copies of the supplement are available from Hewlett-Packard.

1-8. For information concerning a repair number prefix that is not listed on the title page or in the Manual Changes supplement, contact your nearest Hewlett-Packard Office.

General Information - Model 64602A

1-9. DESCRIPTION.

1-10. The Timing Analyzer is used to monitor information flow in the time domain. The information may be a software program, the actions of a hardware state machine, or random logic signals.

1-11. The Timing Analyzer consists of one Model 64601A Timing Control Board, and from one to two Timing Data Acquisition Boards.

1-12. Up to two Acquisition Boards may be combined to form a Timing Analyzer with as many as 16 channels.

1-13. Logic Analyzers within one Mainframe may be connected together using the Inter Module Bus (IMB). One possible use of the IMB is to allow a State Analyzer to trigger a Timing Analyzer.

1-14. SPECIFICATIONS.

1-15. Instrument specifications are listed in Table 1-1. These specifications are the performance standards or limits against which the instrument is tested.

General Information - Model 64602A

Specifications (continued)

Triggering

Time duration accuracy: +/- (20% + 2ns).
Minimum width for narrower-than trigger: 6ns typical.
Minimum width for transition trigger: 6ns typical.
Displayed position accuracy: +/- 4 samples in Wide Sample, Dual Threshold, and Glitch Modes.
: +/- 8 samples in Fast Sample Mode.
Delay from input to external BNC drive: Typically 60ns.
Delay from input to internal IMB drive: Typically 55ns.
Dead time for post-qualify measurement reset.
Typically 50ns + the time required to fill the memory with the selected amount of pre-trigger information.
Reset time for duration trigger: To meet the duration specifications, the trigger duty cycle must be no greater than 40%.

BNC Drive

Output signal swing in transition trigger mode:
Amplitude: 2.0V typical.
Width at 50%: 10ns typical.
Output signal swing in width greater-than trigger mode:
Amplitude: 2.5V typical.
Width: Input trigger width minus the selected duration.
Output signal swing in width less-than trigger mode:
Amplitude: same as in transition trigger mode.
Width: same as in transition trigger mode.

Position: occurs when trigger pattern disappears, before the selected duration times out.

IMB Functions (interconnection with other modules):

Master Enable (LE/ME)-----: drive, receive (Execute/Halt only)
Trigger Enable (LE/TE)-----: drive, receive.
Trigger (HE/TR)-----: drive, receive.
Delay Clock (HE/DLCK)-----: receive only.
Storage Enable (LE/SE)-----: not used.

SECTION II
INSTALLATION

2-1. INTRODUCTION.

2-2. This section contains information for installing the Model 64602A. Included are initial inspection procedures, preparation for use, and instructions for repacking the instrument for shipment.

2-3. INITIAL INSPECTION.

2-4. Inspect the shipping container for damage. If the shipping container or cushioning material is damaged, it should be kept until contents of the shipment have been checked for completeness and the instrument has been checked mechanically and electrically. Procedures for checking electrical performance are given in Section IV. If the contents are not complete, if there is mechanical damage or defect, or if the instrument does not pass the Performance Tests, notify the nearest Hewlett-Packard Office. If the shipping container is damaged, or if the cushioning material shows signs of stress, notify the carrier as well as the Hewlett-Packard Office. Keep the shipping materials for carrier's inspection. The HP office will arrange for repair or replacement at HP option without waiting for claim settlement.

2-5. PREPARATION FOR USE.

2-6. There are no specific preparation for use procedures except the actual installation of the boards in the Mainframe cardcage.

2-7. INSTALLATION INSTRUCTIONS.

WARNING

WHEN REMOVING OR INSTALLING THE TIMING ANALYZER BOARDS,
THE MAINFRAME A.C. LINE POWER MUST BE TURNED OFF.

Installation - Model 64602A




Figure 2-1. Timing Configuration

2-8. Mainframe Configuration.

2-9. Depending on the number of channels required, the timing analyzer will use two or three card slots of the mainframe cardcage.

2-10. One Timing Acquisition Board (64602A) should be installed in the lowest numbered card slot available. The Timing Control Board (64601A) then goes in the next higher slot. And if there is a second Acquisition Board, it will go in the next higher slot. In other words, Acquisition Boards are installed on either side of the Control Board. SEE FIGURE 2-1.

2-11. Up to two Acquisition Boards may be installed with one Control Board, forming one Timing Analysis Subsystem.

2-12. Inter Module Bus (IMB).

2-13. Some systems may contain a combination of a Timing Analyzer and another type of Analysis Subsystem. The Inter Module Bus, located at the upper left-hand corner of the board (when viewing from the component side) connects two or more analysis modules together for controlling and arming purposes. For example, a Timing Analyzer may arm a State Analyzer, and vice versa.

2-14. Although the 64602A has an Inter Module Bus jack, there is no electrical connection between this IMB jack and the rest of the board. The 64602A communicates with the IMB through the 64601A Timing Control Board. Since there is no electrical connection to the 64602A IMB jack and the rest of the board, this jack may have a ribbon cable connected to it for mechanical support.

2-15. Probe Bus

2-16. The timing analyzer communicates with the system under test by means of the 64604A Timing Probe. The probe cable connects to the probe bus located on the top center of the 64602A acquisition board.

2-17. Clock Cables.

2-18. Each 64602A acquisition board requires two clock inputs from the control board. Sample clocks are supplied from the control board via BNC cables connected to J1 and J2 on the upper left-hand part of the acquisition board.

2-19. Clocks should be paired: The left-hand two jacks, J1 and J2, on the control board should be connected to one acquisition board; and the right-hand two jacks should be connected to any second acquisition board.

Installation - Model 64602A

2-20. Timing Bus.

2-21. The timing bus is at the top right-hand corner of the 64602A Acquisition Board (when viewing from the component side). The timing bus connects the timing Control Board to one or two Acquisition Boards.

2-22. The timing Control and Acquisition Boards must be grouped together to allow the timing bus ribbon cable to connect the Control Board to the Acquisition Board. When there are two Acquisition boards, which are placed on either side of the Control Board, a 3-position ribbon cable is used. Use only the timing bus cable with a part number given in the 64601A Control Board parts list. See FIGURE 2-2.

- 4 - XE/TRIG from Acq.
- 5 - XE/TRIG from Acq.
- 11 - H/MEMFUL from Acq.
- 12 - H/MEMFUL from Acq.
- 15 - HE/RESET from Contr.
- 19 - H/RUN from Contr.
- 20 - L/PVC from Contr.





Figure 2-2. Timing Bus Cables

2-23. OPERATING, STORAGE, AND SHIPMENT ENVIRONMENTS.

CAUTION

THE GLITCH (U27) AND ENCODER (U22-25, U29-32) CHIPS ARE VERY SENSITIVE TO STATIC. THEY SHOULD BE LEFT IN CONDUCTIVE FOAM UNTIL INSTALLATION. GROUNDING STRAPS AND A GROUNDED WORK STATION ARE RECOMMENDED WHEN HANDLING THE ICS.

2-24. Operating Environment.

2-25. The Model 64602A may be operated in environments within the limits shown below. It should be protected from temperature extremes which cause condensation within the instrument.

Temperature.....+10° to +40° degrees Celsius
Humidity.....5% to 80% relative humidity
Altitude.....15 000 m (50 000 ft)

2-26. Storage Environment.

2-27. The Model 64602A may be stored or shipped in environments within the following limits:

Temperature.....-40° to +70° degrees Celsius
Humidity.....5% to 80% relative humidity
Altitude.....15 000 m (50 000 ft)

2-28. Packing.

2-29. Tagging for Service. If the instrument is to be shipped to a Hewlett-Packard Sales/Service Office for service or repair, attach a tag showing owner (with address), complete instrument repair number, and a description of the service required.

2-30. Original Packing. Containers and materials identical to those used in factory packing are available through Hewlett-Packard Offices. Mark the container FRAGILE to ensure careful handling. In any correspondence, refer to the instrument by model number and complete repair number.

Installation - Model 64602A

2-31. Other Packing. The following general instructions should be used for repacking with commercially available materials:

- a. Wrap instrument in heavy plastic or paper. (If shipping to Hewlett-Packard Office or Service Center, attach a tag indicating type of service required, return address, model number, and complete repair number.
- b. Use a strong shipping container. A double wall carton made of 350 pound test material is adequate.
- c. Use a layer of shock-absorbing material 70 to 100 mm (3 to 4 inches) thick around all sides of the instrument to provide firm cushioning and prevent movement inside container.
- d. Seal shipping container securely.
- e. Mark shipping container FRAGILE to ensure careful handling.
- f. In any correspondence, refer to instrument by model number and complete repair number.

SECTION III

OPERATION

The operation of the Model 64602A is a function of the system software. Complete system keyboard operation is beyond the scope of the service manual. Please refer to the operator's manual (64601-90903) for the procedure.

NOTES

SECTION IV

PERFORMANCE TESTS

4-1. SECTION IV TABLE OF CONTENTS.

<u>Topic</u>	<u>Paragraph</u>	<u>Page</u>
Introduction.....	4-2.....	4-1
Troubleshooting techniques.....	4-8.....	4-2
Physical setup conditions.....	4-16.....	4-3
Keyboard setup for all 9 PV tests.....	4-18.....	4-4
Keyboard setup for one PV test.....	4-20.....	4-5
Explanation of PV tests.....	4-22.....	4-5
PV tests 1-9.....	4-26.....	4-6
Supplementary Board ID Test.....	4-59.....	4-18
Supplementary Skew Test.....	4-61.....	4-19
Figures illustrating softkey sequence.....	4-69.....	4-22
Signature tables.....	4-70.....	4-27

4-2. INTRODUCTION.

4-3. Performance verification tests check the major circuit blocks for proper operation, giving the operator at least 90% confidence that the board is operating correctly.

4-4. There are 9 PV Tests and 2 Supplementary Tests. The supplementary tests use different access instructions. They are described after the the regular 9 PV tests.

4-5. Signature analysis instructions and tables are given at the end of the section.

4-6. The performance verification tests are also used in troubleshooting: (1) They help to isolate troubles to particular blocks, and within particular blocks; (2) Each test corresponds to a one signature loop when running signature analysis.

4-7. Each test is shown on the mainframe screen as a bracket group of 0's. The 0's correspond to steps in a particular test. When the board fails a test step, the "0" for that step becomes a "1".

4-8. TROUBLESHOOTING TECHNIQUES.

4-9. Although each of the PV tests checks a specific circuit block, signals from other blocks are used. A failure in one block can be caused by failures in blocks upstream. The following steps are suggested for troubleshooting.

4-10. Check board seating.

4-11. Check cable connections.

All cables should be fastened securely. The clock cables should be paired on the left or right two jacks. The timing bus and IMB cables should have the pin 1 wire connected to pin 1 on the jack. No cables other than the two listed in the 64601A Control Board manual parts list may be used for the timing bus.

4-12. Check supply voltages.

Supply voltages from the mainframe (+5V, -5.2V, -12V) should be within 5%. The -3.25V should be within 3%.

4-13. Isolate the problem to one board.

When a PV failure occurs, isolate the problem to either an acquisition board, or the control board. Check signatures on the timing bus, which connects the control board to the acquisition board(s). Look first at the signals HE/RUN and HE/RESET from the control board. If these are good, look at the return signals from the acquisition board(s), H/MEMFUL, XE/TRIG1(2). In a two-acquisition board system, H/MEMFUL comes from the acquisition board in the lower numbered slot only.

4-14. Check the programming.

In PV tests the mainframe stimulates the timing analyzer and verifies correct operation by looking at the status registers. Read each test description to see what is being stimulated. Look at the signatures on the outputs of address decoders, data latches, and mode registers where the mainframe is stimulating that PV test circuit block. Correct signatures may be traced back to where signals become incorrect.

4-15. Check the status registers.

A PV failure means the status registers for the acquisition board on service sheet 5 will have one or more incorrect output signatures. The signal path may then be traced back to the problem.

4-16. PHYSICAL SETUP CONDITIONS FOR THE PV TESTS.

4-17. Conditions for the following tests:

- a. Connect the timing pod to the 64602A acquisition board by means of timing cable 64604-61601.
- b. Leave the probe leads disconnected, so that the probe inputs are floating near ground.
- c. Make sure the two clock cables are securely connected. Clock cables should be connected in pairs to either the two right or two left jacks of the 64601A control board.
- d. The timing bus cable should be connected to the jacks at the upper right hand corner (when viewing from the component side) of both the 64601A control board and the one or two 64602A acquisition board(s). Only timing bus cables (two or three position) listed in the 64601A parts list should be used.
- e. NOTE: In noisy environments, ground each probe input, using the ground lead for each probe. Failure to do this may result in the PV displaying intermittent, non-existent failures.

CAUTION

THE GLITCH (U27) AND ENCODER (U22-25, U29-32) CHIPS ARE VERY SENSITIVE TO STATIC. THEY SHOULD BE LEFT IN CONDUCTIVE FOAM UNTIL INSTALLATION. GROUNDING STRAPS AND A GROUNDED WORK STATION ARE RECOMMENDED WHEN HANDLING THE ICS.

Performance Tests and Troubleshooting - Model 64602A

4-18. KEYBOARD SETUP (For running all nine PV tests repeatedly).

4-19. To verify that the entire board is operating correctly, perform the following steps on the mainframe keyboard:

- a. With the operating system initialized and awaiting a command, press the softkey labeled "opt_test" (you may have to keep pressing the "etc" softkey until you see "opt_test" on the screen). Or you may type "option_test" in lower case.
- b. Press [RETURN]. You should see a listing of all the optional boards that are present in your mainframe, along with their slot numbers.
- c. Type in the Timing Acquisition Board slot number.
- d. Press [RETURN].
- e. Press softkey "run".
- f. Press softkey "slot".
- g. Type in the Timing Acquisition Board slot number.
- h. Press softkey "repeated".
- i. Press [RETURN]. As shown in Figure 4-1, the screen will now show all 9 Acquisition Board PV tests. Tests that pass will be indicated by "0", and failures will be indicated by "1". The screen will also show the number of times the tests are run, and the number of failures.
- j. When finished with the test, press the "stop" softkey.




Figure 4-1. Display of PV Tests.

4-20. KEYBOARD SETUP (For running one PV test repeatedly).

4-21. To run one test at a time repeatedly for signature analysis, perform the following steps: (See Figures 4-2 to 4-10)

- a. Press softkey "opt_test"; RETURN.
- b. Type in the Timing Acquisition Board slot number; RETURN.
- c. Press softkey "run".
- d. Press softkey "slot".
- e. Type in the Timing Acquisition Board slot number.
- f. Press softkey "test". The screen will now list all
- g. the Timing Acquisition Board PV tests.
- h. Type in the number of the test you wish to run.
- i. Press the soft key "repeated".
- j. Press [RETURN].

4-22. EXPLANATION OF THE TEST DESCRIPTIONS.

4-23. There are 9 performance verification tests for the Timing Acquisition Board. Each of these tests has one or more TEST STEPS, denoted by the 0's or 1's within brackets. A "0" in the bracket indicates a PASS for that test step; and a "1" indicates FAIL.

1. SERIAL PROGRAMMING	[00]
2. RAM COUNTERS	[0000000000]
3. FAST SAMPLE	[000000]
4. DUAL THRESHOLD	[000000]
5. GLITCH	[00000][00000]
6. DACS TRIGGER	[00000000000000]
7. CHECKER BOARD	[00000000][00000000]
8. RAM FILLED	[00000000][00000000]
9. GALLOPING ONE'S	[00000000][00000000]
	[00000000][00000000]
	[00000000][00000000]

4-24. The numbered TEST STEPS described in each PV test correspond, from left to right, to the 0's or 1's within the displayed brackets.

4-25. The numbered TEST STEPS describe the commands given by the system software. They do not call for operator intervention.

4-26. TEST 1: SERIAL PROGRAMMING

[0 0]

test steps: 1 2

4-27. Purpose. This test checks the glitch chip (U27) programming.

4-28. Test Steps. (Description of software execution)

1. The 20-bit glitch chip holding register is loaded with all HIGHs and a single LOW is walked through. After 20 clocks, nineteen HIGHs and one LOW should have appeared at the holding register output (U27-8).
2. The holding register is loaded with all LOWs and a single HIGH is clocked through. After 20 clocks, a HIGH should appear at U27-8.

4-29. D/A Converter Adjustment.

This test will also allow adjustment of the -FS(full scale) pot for the D/A converters. The -FS, +FS1, and +FS2 pots are located together at the top of the board.

See Section 5 for the adjustment procedure.

4-30. TEST 2: RAM COUNTERS

[0 0 0 0 0 0 0 0 0 0 0]

test steps: 1 2 3 4 5 6 7 8 9 10 11

4-31. Purpose. This test checks memory-address-counter clocking and counting.

4-32. Test Steps. (Description of software execution)

1. Analyzer is reset. The X-counters should read 00H. (Y-counters cannot be read directly). H/MEMFUL should be false.
2. Memory Address Counters are set to AAH (AAx and AAy).
3. X-counter is clocked to FFH. (Since the Y-counter is behind, at most, by one clock, it will be at FFH or FEH).
4. X-counter is clocked once more. It should read 00H.
5. Analyzer is clocked to one before the memory is full. Both X and Y counters should be 01H. H/MEMFUL should still be false.

The wrap-around latch (U4) sends H/MEMFUL to the mainframe processor when the memory address counters overflow for the first time during acquisition. H/MEMFUL will continue true from then on, no matter how many times the counters go around, until the analyzer is RESET. Thus, the counters indicate when memory has been filled with new data at least once.

6. Clock once more. H/MEMFUL should be high. This indicates indirectly that the Y-counter has been counting correctly.
7. Reset, and set the memory address to 55H (55x and 55y). H/MEMFUL should be low.
8. X-counter is clocked to FFH.
9. X-counter is clocked once more. It should read 00H.
10. Analyzer is clocked to one before the memory is full. Both X and Y counters should be 01H. H/MEMFUL should still be false.
11. Clock once more. H/MEMFUL should be high.

4-33. D/A Converter Adjustment.

After test #2 (ram counters) is run, the DACs are left with +2.117V (+/- 7.0mV) on TP1 and TP2. Adjustments may be made using the procedure in Section 5.

4-34. <u>TEST 3: FAST SAMPLE TEST</u>	[0 0 0 0 0 0]
test steps:	1 2 3 4 5 6

4-35. Purpose.

This test verifies that the counters are running, that clocks are getting through the system, and that the fast sample latch (U71B) sets and resets. The following conditions are programmed: fast sample mode is set; glitch chip is programmed to never trigger.

4-36. Test Steps. (Description of software execution)

1. Reset and turn on the Fast Sample Mode. H/MEMFUL should be false.
2. The fast sample latch should be set.
3. Start acquisition. H/MEMFUL should go true.
4. Reset and turn on the Wide Sample Mode/200MHz. H/MEMFUL should be false.
5. The fast sample latch should be reset.
6. Start acquisition. H/MEMFUL should go true.

4-37. D/A Converter Verification.

| After test #3 (fast sample) is run TP1 and TP2 should show 0V (+/- 4.5mv). This test is for Verification only. See Section 5 for the adjustment procedure.

4-38. TEST 4: DUAL THRESHOLD MODE

[0 0 0 0 0 0 0]

test steps: 1 2 3 4 5 6 7

4-39. Purpose.

This test exercises the timing probe, the glitch chip (U27), the two D/A converters (DACs), and the dual threshold latch (U71A) in the Dual Threshold Mode.

4-40. Theory.

In the Dual Threshold Mode, DAC A (U76) sets the lower threshold, using channels 0-3; and DAC B (U78) sets the upper threshold, using channels 4-7.

Since two channels are needed for each probe input, an analyzer with only one acquisition board is reduced to four channels. Only the low order probe inputs--0,1,2,3--are active.

Each of these low order probe inputs comes into the board on two separate channels: probe 0 => channels 0 & 4, probe 1 => channels 1 & 5, probe 2 => channels 2 & 6, and probe 3 => channels 3 & 7.

Since one of the set-up conditions for the PV tests is that the probes are left disconnected and floating near ground, incoming data levels are simulated by varying the DAC thresholds: a HIGH probe input is simulated by a LOW threshold.

The dual threshold mode is set by the dual threshold latch (U71A), which sends HE/DT to the probe bus (J1-22). HE/DT is used to latch the probe pod into the dual threshold and fast sample modes. In both of these modes, only four probe inputs are active.

4-41. Test Steps. (Description of software execution)

1. The dual threshold latch, U71A, is reset.
2. The dual threshold latch is set.

Performance Tests and Troubleshooting - Model 64602A

TEST 4: DUAL THRESHOLD MODE (continued)

In each of the next five tests, the DACs are exercised in all of the following ways:

- a. Both thresholds are set to maximum (+12.7V): all probe data will be seen as LOW.
 - b. Both thresholds are set to minimum (-12.8V): all probe data will be seen as HIGH.
 - c. Upper thresholds are set to +12.7V, and lower thresholds are set to -12.8V.
 - d. Upper thresholds are set to -12.8V, and lower thresholds are set to +12.7V.
 - e. DACs are set back to condition "a".
3. Program the glitch chip to always trigger. XE/TRIG should be true under all the above conditions.
 4. Program the glitch chip to trigger only on a HIGH. XE/TRIG should be true only under condition b.
 5. Program the glitch chip to trigger only on a selected middle level. Trigger should occur only under condition d.
 6. Program the glitch chip to trigger only on a LOW. Trigger should occur only under condition a.
 7. This step checks that XE/TRIG and XE/TRIGPOL to the status register U82 were the correct polarity in all the above tests.

4-42. D/A Converter Adjustment Verification.

After test #4 (dual threshold) is run, the DACs are left with TP1=+1.666 and TP2=-1.666 (with the probes disconnected). THIS TEST IS FOR VERIFICATION ONLY!. Adjustments are made using test #1 and test #2.

4-43. TEST 5: GLITCH MODE TEST

[0 0 0 0 0]	[0 0 0 0 0]
test steps: 1 2 3 4 5	6 7 8 9 10

4-44. Theory.

Glitches are defined as two or more transitions between sample times.

When the DAC thresholds are set HIGH or LOW, it makes inputs from the floating probes appear to be at the opposite level. In this test the DAC thresholds are "wiggled" between clock edges to create glitches.

4-45. Purpose.

This test exercises the probe and glitch chip (U27) in the glitch mode. The test verifies a trigger (XE/TRIG at U82-4) under the following conditions:

- a. The sample clock begins with a leading edge. That is, the first sample time corresponds to a leading clock edge.
- b. The sample clock begins with a trailing edge.
- c. Glitch transitions, between sample times, begin with a leading edge.
- d. Glitch transitions begin with a trailing edge.
- e. Two glitch transitions occur between clock edges.
- f. Three glitch transitions occur between clock edges.

4-46. Test Steps. (Description of software execution)

In the first bracket group, the sample clock alternates HIGH-LOW-HIGH. Each test covers a sequence, starting and ending with the the clock HIGH.

1. The Glitch Mode is set. No trigger (XE/TRIG=1 at U82-4) should occur on a normal data transition.
2. Two glitch transitions, beginning with a falling edge, occur between samples: XE/TRIG = 1.
3. Three glitch transitions occur, beginning with a falling edge: XE/TRIG=1.
4. Two glitch transitions occur, beginning with a rising edge: XE/TRIG=1.
5. Three glitch transitions occur, beginning with a rising edge: XE/TRIG=1.

GLITCH MODE TEST (continued)

In the second bracket group, the clock alternates LOW-HIGH-LOW.

6. No trigger on a normal data transition.
7. XE/TRIG = 1 after two transitions which begin on a falling edge.
8. Triggers on three transitions which begin on a falling edge.
9. Triggers on two transitions which begin on a rising edge.
10. Triggers on three transitions which begin on a rising edge.

4-47. D/A Converter Adjustment Verification.

After test #5 (glitch mode) is run, the DACs are left with TP1=-1.666 and TP2=+1.666 (with the probes disconnected). THIS TEST IS FOR VERIFICATION ONLY! Adjustments are made using test #1 and test #2.

4-48. TEST 6: DACS TRIGGER TEST

	[0 0 0 0 0 0 0 0 0 0 0 0 0 0 0]
test steps:	1 2 3 4 5 6 7 8 9 10 11 12 13 14

4-49. Purpose.

This test checks the D/A converters, the probes, and the glitch chip.

4-50. Test Steps. (Description of software execution)

In each of the following tests, the DACs are exercised as in the DUAL THRESHOLD TEST above.

1. The glitch chip is programmed to always trigger. XE/TRIG should be true under all the conditions given in the DUAL THRESHOLD TEST.
- 2-9. The glitch chip is programmed so that one channel at a time will never trigger. In other words, a "never-trigger" is walked through all the channels, and the thresholds are exercised under all conditions. XE/TRIG (U82-4) should be false for all these tests.
10. The glitch chip is programmed so that all channels will trigger on a HIGH. XE/TRIG should be true only under condition b, as given in the Dual Threshold Test.
11. The glitch chip is programmed so that all channels will trigger on a LOW. XE/TRIG should be true only under condition a.
12. Channels 0-3 are programmed with a LOW threshold, and channels 4-7 are programmed with a HIGH threshold. XE/TRIG should be true only under condition c.
13. Channels 0-3 are programmed with a HIGH threshold, and channels 4-7 are programmed with a LOW threshold. XE/TRIG should be true only under condition d.
14. For all the above tests, XE/TRIG to the timing bus was true at the correct times.

4-51. TEST 7: CHECKER BOARD

test steps:	1	2
	[0 0 0 0 0 0 0 0]	[0 0 0 0 0 0 0 0]
RAM channels:	0 7 1 6 2 5 3 4	0 7 1 6 2 5 3 4

4-52. Purpose.

This test checks the RAMs and the output stage of the encoders by loading two alternating patterns of HIGHS and LOWs into each memory channel, and then verifying. The patterns are generated by the pattern generator inside the encoders.

A memory channel consists of the four RAMs loaded by a particular probe channel in the Wide Sample Mode.

Each "0" in a bracket corresponds to a memory channel in the following order: 0,7,1,6,2,5,3,4.

4-53. Test Steps. (Description of software execution)

1. Load 01010101... into memory channels 1,2,5,6; and 10101010... into memory channels 0,3,4,7. The RAM looks like one big checker board. All locations are tested.
2. Load 10101010... into memory channels 1,2,5,6; and 010101... into channels 0,3,4,7. This is the same as the previous test except that all bits are complemented.

4-54. TEST 8: RAM FILLED

test steps:	1	2
	[0 0 0 0 0 0 0 0]	[0 0 0 0 0 0 0 0]
RAM channels:	0 7 1 6 2 5 3 4	0 7 1 6 2 5 3 4

4-55. Purpose.

This test checks the acquisition RAM by loading in all HIGHS or all LOWs, and then verifying.

A "memory channel" consists of four RAMs that correspond to a particular probe channel in Wide Sample Mode.

Each "0" in a bracket corresponds to a memory channel in the following order: 0,7,1,6,2,5,3,4.

4-56. Test Steps. (Description of software execution)

1. By programming the DAC thresholds for a maximum positive value, load all LOWs into memory channels 0-7, and verify. All locations are tested.
2. By programming the DACs with a maximum negative threshold, load all HIGHS into RAM channels 0-7. All locations are tested.

4-57. TEST 9: GALLOPING ONE'S

[00000000][00000000]
 [00000000][00000000]
 [00000000][00000000]
 [00000000][00000000]

This test checks address lines, rather than memory itself. The bracket GROUPs represent address lines, or bits. (Since the X and Y addresses are identical for this test, only eight address bits, corresponding to a 16-bit location, are needed.) The "0's" in each group represent memory channels in the order: 0,7,1,6,2,5,3,4. Thus:

A0	A1
[chs.0,7,1,6,2,5,3,4]	[chs.0,7,1,6,2,5,3,4]
A2	A3
[chs.0,7,1,6,2,5,3,4]	[chs.0,7,1,6,2,5,3,4]
A4	A5
[chs.0,7,1,6,2,5,3,4]	[chs.0,7,1,6,2,5,3,4]
A6	A7
[chs.0,7,1,6,2,5,3,4]	[chs.0,7,1,6,2,5,3,4]

4-58. Procedure used by the software in this test.

After clearing memory, load FFFFH into the same 16-bit address in all channels. Read that location in each channel. Then read the memory. If only the location corresponding to the exercised address bit contains FFFFH, no address lines are open or shorted.

Addresses are chosen in the following way: One address bit at a time is first made LOW, then HIGH. The corresponding power-of-two addresses will then be: 01H,...,08H and FEH,...,7FH, as follows:

HEX ADDR.	ADDR. LINES								CHANNELS: 0,7,1,6,2,5,3,4
	A7	A6	A5	A4	A3	A2	A1	A0	
01	L	L	L	L	L	L	L	H	EACH
02	L	L	L	L	L	L	H	L	EACH
04	L	L	L	L	L	H	L	L	EACH
08	L	L	L	L	H	L	L	L	EACH
10	L	L	L	H	L	L	L	L	EACH
20	L	L	H	L	L	L	L	L	EACH
40	L	H	L	L	L	L	L	L	EACH
80	H	L	L	L	L	L	L	L	EACH
and then:									
FE	H	H	H	H	H	H	H	L	EACH
FD	H	H	H	H	H	H	L	H	EACH
FB	H	H	H	H	H	L	H	H	EACH
F7	H	H	H	H	L	H	H	H	EACH
EF	H	H	H	L	H	H	H	H	EACH
DF	H	H	L	H	H	H	H	H	EACH
BF	H	L	H	H	H	H	H	H	EACH
7F	L	H	H	H	H	H	H	H	EACH

GALLOPING ONE'S (continued)

For example, when bit A0 is exercised:

- a. Address 01H should be the only location in all channels to contain FFFFH.
- b. Then address FEH should be the only location in all channels to contain FFFFH.
- c. If both of these conditions are true, the first bracket will contain only "0's".

The following inferences can be made from this test:

- a. If the selected address does not contain FFFFH, that address line is open and will be indicated by one or more "0's" instead of "0's".
- b. Two or more address lines are shorted if any of the other addresses also contain FFFFH. For example, when exercising 01H, if 09H also contains FFFFH, then A0 is shorted to A3. This will cause "1" to appear on all channels of those two address lines, eg: [11111111]
[11111111].
- c. A RAM internal short, after the input buffers, may appear as a "+" on one of the channels, eg: [0000+000], indicating channel 2. Since a memory channel is composed of four RAMs, the problem can then be narrowed down to one of four RAMs.
- d. The encoders or glitch chip may also cause failures to occur in this test, even though previous tests have passed. For example, if both the X and Y addresses are the same, except for A0, and the signatures are correct on the address lines, check the signatures on the outputs of the RAMs. If these are correct, but one or more of the input data line signatures are wrong, the problem is likely to be the encoder for that channel.

4-59. SUPPLEMENTARY BOARD ID TEST

4-60. The board ID circuits have stable signatures when "opt_test" is pressed. If the Timing Boards are not then listed on the screen, the ID circuitry is not working. Check the ID circuitry signatures (U75, U82).

4-61. SUPPLEMENTARY PV SKEW TEST.

4-62. The Skew Test is a supplementary PV test which checks the skew between channels.

4-63. Skew is the difference in delay between any two channels.

4-64. There are two stages to the skew test. In the first stage one of the eight probe channels is chosen as a reference channel, and either one or all of the other seven channels is measured for skew against the reference.

4-65. The second stage of the test is done in the fast sample mode. This test measures the amount of skew in the two channels paired in the fast sample mode. If the first stage test measured 0.0 ns skew for these two channels, the skew now measured in the Fast Sample Delay Line test should be exactly 2.5 ns, which is the delay caused by the fast sample delay line.

4-66. To access the Skew Test, perform the following:

1. Press "opt_test". RETURN.
2. Type in the slot number for either the timing control or acquisition boards. RETURN.
3. Type in "skew". RETURN.
4. The screen should now display the setup information for the skew test as shown in figure 4-2.

SKEW TEST - SET UP INFORMATION: 200 MHz TIMING ANALYZER

Probes should be connected to a (50 ohm) signal source whose frequency is 10.01 MHz (ECL output with 50% duty cycle) with the following provisions:

- 1: The reference probe is connected to an output and one or the rest of the probes are connected to the same or a complementary output.
- 2: For testing the delay line used in the fast sample mode, only probes 0 - 3 (& 8 - 11 with 16 channels) are used as references.

Figure 4-2. Skew Test Setup

4-67. To perform the first skew test:

1. Press "skew_test".
2. You may now choose a reference channel, and then press RETURN.
3. If you don't choose a reference channel, the system will automatically select channel 0.
4. When you press RETURN, the display will show the skew of all the other channels with respect to the reference channel, using both positive and negative edges. (SEE FIGURE 4-3). The test cycles 25 times and lasts about one and three-quarter minutes.
5. The amount of skew shown in this test when the probe is connected properly according to the setup conditions shown in the first display should be 1.5 ns typical.

```
200 MHz TIMING: Nano Seconds of SKEW - with respect to
  POSITIVE EDGES:   NEGATIVE EDGES: of the reference channel's signal
CHANNEL: 0   ref           ref
      1   0.0ns           0.0ns
      2   0.0ns           0.0ns
      3   0.0ns           0.0ns
      4   0.0ns           0.0ns
      5   0.0ns           0.0ns
      6   0.0ns           0.0ns
      7   0.0ns           0.0ns
```

Figure 4-3. First Skew Test

4-68. To perform the second skew test:

1. Press "fast_samp"
2. The screen will display "fast_sample_delay_line_test".
3. You may now either choose a reference channel, or let the system default to channel 0.
4. Press RETURN. The screen will show the amount of skew in the channel paired in the fast sample mode with the reference channel. For example, if channel 0 is the reference channel, channel 4 will be the other channel used in the measurement because channel 4 is paired with channel 0 in the fast sample mode. Similarly, channels 1 and 5, channels 2 and 6, and channels 3 and 7 will be paired. (SEE FIGURE 4-4).
5. The amount of skew shown in this test when the probe is connected properly according to the setup conditions shown in the first display should be 2.5 ns typical, which is the length of the delay line.

```

200 MHz TIMING: Nano Seconds of FAST SAMPLE DELAY-LINE-SKEW (2.5nS Typ.)
  POSITIVE EDGES:   NEGATIVE EDGES: of the reference channel's signal
CHANNEL: 0      ref                ref
          1
          2
          3
          4      0.0ns              0.0ns
          5
          6
          7
    
```

Figure 4-4. Second Skew Test

Performance Tests and Troubleshooting - Model 64602A

4-69. PV SOFTKEY SEQUENCE.

The following figures (4-5 to 4-13) show the softkey sequence needed to run a single PV test repeatedly for signature analysis. Each PV test corresponds to one signature loop. The signature lists are given after the figures.

```
I/O BUS CONFIGURATION

HDRS  DEVICE
  0  13037 DISC CONTROLLER
      UNIT 0  7925 DISC MEMORY  LU=0
  1  2608 PRINTER
  2  64000
  3  64000
  4  64000
  5  64000
  6  THIS 64000
  7  64000

STATUS: Awaiting command _____ 14:18

__user_id__  date & time opt_test  terminal  (COMDFILE)  BACKUP  -- ETC --  print
```

Figure 4-5. Press "opt_test".

```
HP 64000 Option Performance Verification

Card #  ID #  Module
-----
  3    1004H  200 MHz Timing Data Acquisition
  4    1001H  200 MHz Timing Control
  7    1100H  10 MHz State Controller
  8    1200H  10 MHz State 40 Channel Data Acquisition

STATUS: Awaiting command _____ 14:18

__end__  (SLOT#)  _____  print
```

Figure 4-6. Type the slot number.

```

200 MHz Timing: Performance Verification (c. 11/5/81) Fri, 15 Jan 1982, 9:48
Slot # ID # Module                               Tested Failed
-----
3      1004H 200 MHz Timing Data Acquisition         0       0
4      1001H 200 MHz Timing Control                 0       0
Timing analyzer control board available for AIMB stimulus

STATUS: Awaiting command _____ 14:18
3
end      run      show      list      append  stim aimb _____

```

Figure 4-7. Press "run".

```

200 MHz Timing: Performance Verification (c. 11/5/81) Fri, 15 Jan 1982, 15:38
Slot # ID # Module                               Tested Failed
-----
3      1004H 200 MHz Timing Data Acquisition         0       0
4      1001H 200 MHz Timing Control                 0       0
Timing analyzer control board available for AIMB stimulus

STATUS: Awaiting command _____ 14:18
run
_____ slot      repeated _____ (RETURN)

```

Figure 4-8. Press "slot".

Performance Tests and Troubleshooting - Model 64602A

```
200 MHz Timing: Performance Verification (c. 11/5/81) Fri, 15 Jan 1982, 15:38
Slot # ID # Module                               Tested  Failed
-----
 3   1004H 200 MHz Timing Data Acquisition         0       0
 4   1001H 200 MHz Timing Control                 0       0
Timing analyzer control board available for AIMB stimulus

STATUS: Awaiting command _____ 14:18
run slot
<SLOT#> _____
```

Figure 4-9. Type the slot number.

```
200 MHz Timing: Performance Verification (c. 11/5/81) Fri, 15 Jan 1982, 15:38
Slot # ID # Module                               Tested  Failed
-----
 3   1004H 200 MHz Timing Data Acquisition         0       0
 4   1001H 200 MHz Timing Control                 0       0
Timing analyzer control board available for AIMB stimulus

STATUS: Awaiting command _____ 14:18
run slot 3
_____ test repeated _____ <RETURN>
```

Figure 4-10. Press "test".




Figure 4-11. Type the test number.




Figure 4-12. Press "repeated".

Performance Tests and Troubleshooting - Model 64602A

```
PV RESULTS: Slot # 3 200MHz Timing - DATA ACQUISITION Fri, 15 Jan 1982, 8:59  
  
TESTED   FAILED   OPEN = 0, SHORT = +, FAILED = 1, PASSED = 0  
89       0       SERIAL PROGRAMMING [ 0 0 ]  
  
STATUS: Awaiting command _____ 14:18  
run slot 3 test 1 repeated  
_____ log fail thru fail _____ <RETURN>
```

Figure 4-13. Press [RETURN].

4-70. SIGNATURE ANALYSIS.

4-71. The following 9 signature loops correspond to the previously given performance verification tests. That is, if a PV test fails, run the signature loop corresponding to that test. For example, if one of the test steps for TEST 1: SERIAL PROGRAMMING shows a "1" instead of a "0" in the bracket, look at the signatures for LOOP 1. In order to take the signatures, run TEST 1 repeatedly, using the procedure illustrated by the above figures (4-2 to 4-10).

Performance Tests and Troubleshooting - Model 64602A

64602A Timing Acquisition Board
SERIAL PROGRAMMING #1

NORM MODE

VH = CC7A

DATA THRESHOLD: ecl & ttl

CLOCK THRESHOLD: ttl

ST-SP-QL THRESHOLD: ttl

Location of ST/SP/START: sa gate neg. edge
Location of QUAL/STOP: sa gate pos. edge
Location of CLOCK: sa clk pos. edge
Location of GROUND: gnd

ECL

```

-----
U 7-13 7524
U 7-15 FP5P
U 11-13 7524
U 16-11 9UA5
U 16-15 8808
U 17- 2 9UA5
U 17- 3 AFH7
U 17- 5 8808
U 27- 1 low
U 27- 2 high
U 27- 3 596F
U 27- 4 low
U 27- 5 high
U 27- 6 596F
U 27- 8 8808
U 27- 9 high
U 27-10 FP5P
U 27-12 0000
U 27-13 high
U 27-14 0000
U 27-15 high
U 27-16 high
U 27-17 low
U 27-18 high
U 27-19 high
U 27-20 low
U 27-21 high
U 27-22 high
U 27-23 low
U 27-24 high
U 27-25 high
U 27-26 low
U 27-27 0000
U 27-28 high
U 27-29 0000
U 27-31 AFH7
U 27-32 high
U 27-33 low
    
```

```

U 27-34 high
U 27-35 low
U 27-36 high
U 27-37 596F
U 27-38 low
U 27-39 high
U 27-40 596F
    
```

TTL

```

-----
U 11-11 FP5P
U 16-12 9UA5
U 16-13 8808
U 70- 1 low
U 70- 4 HHCH
U 70- 5 870C
U 70- 6 CC7A
(TOTLZ=0161)
U 70- 7 870C
U 70- 9 870C
U 70-11 high
U 70-13 high
U 70-14 0000
(TOTLZ=0161)
U 70-15 high
U 70-16 HHCH
U 70-19 A899
U 72- 1 high
U 72- 2 CC7A
(TOTLZ=0161)
U 72- 3 7524
U 72- 4 HHCH
U 72- 5 A899
U 72- 6 7524
U 72- 7 CC7A
U 72- 9 high
U 72-10 high
U 72-12 high
U 72-13 A899
U 72-14 CC7A
(TOTLZ=0161)
U 72-15 CC7A
(TOTLZ=0391)
U 73- 1 13P3
U 73- 2 A899
U 73- 3 CC7A
(TOTLZ=0161)
U 73- 4 0000
    
```

U 73- 5 CC7A
(TOTLZ=0161)
U 73- 6 CC7A
U 73- 8 7524
U 73- 9 CC7A
(TOTLZ=0161)
U 73-10 FP5P
U 73-11 CC7A
(TOTLZ=2187)
U 73-12 HHCH
U 73-13 0000
(TOTLZ=0001)
U 75- 1 CC7A
(TOTLZ=1195)
U 75- 2 CC7A
(TOTLZ=0161)
U 75- 3 high
U 75- 4 CC7A
(TOTLZ=0161)
U 75- 5 CC7A
(TOTLZ=2187)
U 75- 6 CC7A
(TOTLZ=0161)
U 75- 8 high
U 75- 9 CC7A
(TOTLZ=0161)
U 75-10 high
U 75-11 CC7A
(TOTLZ=0161)
U 75-12 0000
(TOTLZ=0161)
U 75-13 CC7A
(TOTLZ=2187)
U 81- 2 7524
U 81- 3 HHCH
U 81- 4 13P3
U 81- 5 high
U 81- 6 AB99
U 81-10 high
U 81-11 low
U 81-12 high
U 81-13 high
U 82- 1 AB99
U 82- 4 9UA5
U 82- 5 7F14
U 82- 6 8808
U 82- 7 487C
U 82- 9 870C
U 82-10 low
U 82-12 high
U 82-13 870C
U 82-14 high
U 82-15 high

Performance Tests and Troubleshooting - Model 64602A

64602A Timing Acquisition Board
RAM COUNTERS #2

NORM MODE

VH = UP73

DATA THRESHOLD : ecl & ttl
CLOCK THRESHOLD: ttl
ST-SP-QL THRESHOLD: ttl

Location of ST/SP/START: sa gate neg. edge
Location of QUAL/STOP: sa gate pos. edge
Location of CLOCK: sa clk pos. edge
Location of GROUND: gnd

ECL

TTL

U 5- 3 0402	U 10- 2 U1U4	U 4- 1 0200
U 5- 7 0200	U 10- 3 0U87	U 4- 2 U1U4
U 5-11 U5U6	U 10- 4 U1U4	U 4- 3 0F06
U 5-15 U3U4	U 10- 5 0U87	U 4- 4 high
U 6- 1 high	U 10- 6 0985	U 4- 5 0U87
U 6- 2 U3U4	U 10- 7 U7U6	U 4- 6 U1U4
U 6- 3 0402	U 10- 9 0000	U 4- 7 UUU3
U 6- 4 U1U4	U 10-10 U7U6	U 4- 9 0180
U 6- 5 high	U 10-13 U7U6	U 4-10 high
U 6- 6 U5U6	U 10-14 0985	U 4-11 0UP6
U 6- 7 0U87	U 10-15 U7U6	U 4-12 UUU3
U 6-10 U3U4	U 14- 1 high	U 4-13 0200
U 6-11 0U87	U 14- 2 A1H8	U 4-14 0U87
U 6-12 high	U 14- 3 high	U 4-15 CPH6
U 6-13 U1U4	U 14- 4 A1H8	U 5- 4 0402
U 6-14 0200	U 14- 5 5UAC	U 5- 5 0200
U 6-15 U5U6	U 14- 6 5UAC	U 5-12 U5U6
U 7- 2 0985	U 14- 7 UP73	U 5-13 U3U4
U 7- 4 U7U6	U 14- 9 5UAC	U 16- 4 40A5
U 7- 5 0985	U 14-10 A1H8	U 16- 5 CPH6
U 7- 9 0000	U 14-12 UP73	U 22- 7 40A5
U 7-10 U7U6	(TOTLZ=0001)	U 22-15 741F
U 7-11 0985	U 14-13 0000	U 23- 7 40A5
U 7-14 0985	U 14-14 high	U 23-15 741F
U 9- 1 high	U 14-15 0U87	U 24- 7 40A5
U 9- 2 U7U6	U 16- 3 40A5	U 24-15 8A6U
U 9- 3 U7U6	U 16- 6 40A5	U 25- 7 40A5
U 9- 4 low	U 22- 6 U3U4	U 25-15 8A6U
U 9- 5 0985	U 22-14 U5U6	U 29- 7 40A5
U 9- 6 high		U 29-15 8A6U
U 9- 7 0985		U 30- 7 40A5
U 9-10 0985		U 30-15 8A6U
U 9-11 high		U 31- 7 40A5
U 9-12 0985		U 31-15 741F
U 9-13 low		U 32- 7 40A5
U 9-14 U7U6		U 32-15 741F
U 9-15 U7U6		U 65- 1 CPH6
U 10- 1 high		U 65- 2 0402

Performance Tests and Troubleshooting - Model 64602A

U 65- 3	0040	U 68-12	0864	U 73- 1	5UAC
U 65- 4	2052	U 68-13	387P	U 73- 2	A1H8
U 65- 5	0040	U 68-14	0CP4	U 73- 3	UP73
U 65- 6	2052	U 68-15	0804	(TOTLZ=0001)	
U 65- 7	5UAC	U 69- 1	CPH6	U 73- 4	low
U 65- 9	5UAC	U 69- 2	0200	U 73- 5	UP73
U 65-10	0804	U 69- 3	0040	(TOTLZ=0001)	
U 65-11	387U	U 69- 4	2052	U 73- 6	high
U 65-12	0864	U 69- 5	0040	U 73- 8	high
U 65-13	387U	U 69- 6	2052	U 73- 9	UP73
U 65-14	0864	U 69- 7	5UAC	(TOTLZ=0001)	
U 65-15	0804	U 69- 9	5UAC	U 73-10	low
U 66- 1	CPH6	U 69-10	high	U 73-11	UP73
U 66- 2	0200	U 69-11	3F7H	(TOTLZ=0199)	
U 66- 3	0040	U 69-12	0F66	U 73-12	5UAC
U 66- 4	2052	U 69-13	3F7F	U 79- 1	A1H8
U 66- 5	0040	U 69-14	0UP6	U 79- 2	0864
U 66- 6	2052	U 69-15	0F06	U 79- 3	6715
U 66- 7	5UAC	U 70- 1	low	U 79- 4	387U
U 66- 9	5UAC	U 70- 4	5UAC	U 79- 5	771H
U 66-10	0F06	U 70- 5	7U39	U 79- 6	0864
U 66-11	3F7H	U 70- 6	UP73	U 79- 7	6794
U 66-12	0F66	(TOTLZ=0001)		U 79- 8	387U
U 66-13	3F7H	U 70- 7	2192	U 79- 9	741F
U 66-14	0F66	U 70- 8	741F	U 79-11	0CP4
U 66-15	0F06	U 70- 9	7U38	U 79-12	6715
U 67- 1	low	U 70-11	high	U 79-13	387P
U 67- 2	UP33	U 70-12	741F	U 79-14	771H
U 67- 3	0040	U 70-13	0180	U 79-15	0864
U 67- 4	HP21	U 70-14	0000	U 79-16	6715
U 67- 5	2052	(TOTLZ=0001)		U 79-17	387U
U 67- 6	UP33	U 70-15	high	U 79-18	771H
U 67- 7	0040	U 70-16	5UAC	U 79-19	A1H8
U 67- 8	HP21	U 70-17	0000	U 81- 4	5UAC
U 67- 9	2052	U 70-18	0000	U 81- 5	high
U 67-11	HP21	U 70-19	A1H8	U 81- 6	A1H8
U 67-12	2052	U 72- 1	high	U 81- 8	8A6U
U 67-13	UP33	U 72- 2	UP73	U 81- 9	741F
U 67-14	0040	(TOTLZ=0001)		U 81-10	high
U 67-15	HP21	U 72- 3	UP73	U 82- 1	A1H8
U 67-16	2052	(TOTLZ=0091)		U 82- 2	0UP6
U 67-17	UP33	U 72- 4	5UAC	U 82- 3	701P
U 67-18	0040	U 72- 5	A1H8	U 82- 4	low
U 67-19	low	U 72- 6	high	U 82- 5	7U39
U 68- 1	CPH6	U 72- 7	high	U 82- 6	high
U 68- 2	0402	U 72- 9	high	U 82- 7	2093
U 68- 3	0040	U 72-10	high	U 82- 9	7U38
U 68- 4	2052	U 72-11	high	U 82-10	low
U 68- 5	0040	U 72-12	high	U 82-11	771H
U 68- 6	2052	U 72-13	A1H8	U 82-12	high
U 68- 7	5UAC	U 72-14	UP73	U 82-13	7U39
U 68- 9	5UAC	(TOTLZ=0001)		U 82-14	high
U 68-10	high	U 72-15	UP73	U 82-15	high
U 68-11	387U	(TOTLZ=0123)			

Performance Tests and Troubleshooting - Model 64602A

64602A Timing Acquisition Board
FAST SAMPLE #3

NORM MODE

VH = FH25

DATA THRESHOLD: ecl & ttl
CLOCK THRESHOLD: ttl
ST-SP-QL THRESHOLD: ttl

Location of ST/SP/START: sa gate neg. edge
Location of QUAL/STOP: sa gate pos. edge
Location of CLOCK: sa clk pos. edge
Location of GROUND: and

ECL

```

-----
U 7- 1 high          U 12- 3 F070          U 27-18 5852
U 7- 2 0000          U 12- 4 F070          U 27-19 5852
U 7- 4 3395          U 12-14 6692          U 27-20 9577
U 7- 5 0000          U 14- 1 high          U 27-21 5852
U 7-11 0000          U 14- 2 ACC7          U 27-22 5852
U 7-12 A755          U 14- 3 FH25          U 27-23 9577
U 7-13 6A70          U 14- 4 ACC7          U 27-24 5852
U 7-14 0000          U 14- 5 6692          U 27-25 5852
U 7-15 A755          U 14- 6 6692          U 27-26 9577
U 9- 1 high          U 14- 7 FH25          U 27-28 high
U 9- 2 3395          U 14- 9 6692          U 27-29 3395
U 9- 3 3395          U 14-10 ACC7          U 27-31 AF8C
U 9- 4 low           U 14-11 high          U 27-32 high
U 9- 5 0000          U 14-12 FH25          U 27-33 low
U 9- 6 high          U 14-14 high          U 27-34 high
U 9- 7 0000          U 14-15 677P          U 27-35 3PF0
U 9-10 0000          U 16- 3 0000          U 27-36 U3P5
U 9-11 0H55          U 16- 6 0000          U 27-37 5H96
U 9-12 0000          U 16-11 9998          U 27-38 3PF0
U 9-13 F070          U 16-15 U836          U 27-39 U3P5
U 9-14 3395          U 17- 2 9998          U 27-40 5H96
U 9-15 3395          U 17- 3 AF8C
U 10- 1 high         U 17- 5 U836
U 10- 2 AA5C          U 27- 1 3PF0
U 10- 3 677P          U 27- 2 U3P5
U 10- 4 AA5C          U 27- 3 5H96
U 10- 5 677P          U 27- 4 9577
U 10- 6 0000          U 27- 5 5852
U 10- 7 3395          U 27- 6 U621
U 10- 9 0000          U 27- 8 U836
U 10-10 3395          U 27- 9 high
U 10-11 0000          U 27-10 A755
U 10-12 0000          U 27-12 3395
U 10-13 3395          U 27-13 high
U 10-14 0000          U 27-14 3395
U 10-15 3395          U 27-15 5852
U 11-13 6A70          U 27-16 5852
U 12- 2 0H55          U 27-17 9577
    
```


Performance Tests and Troubleshooting - Model 64602A

TTL

 U 4- 2 AA5C
 U 4- 3 0000
 (TOTLZ=0015)
 U 4- 4 high
 U 4- 5 677P
 U 4- 6 AA5C
 U 4- 7 AA5C
 U 4- 9 677P
 U 4-10 high
 U 4-12 AA5C
 U 4-14 677P
 U 4-15 FH25
 U 11- 7 C18H
 U 11-11 A755
 U 12- 5 0H55
 U 12- 7 4HF5
 U 12-11 6692
 U 16- 4 0000
 U 16- 5 FH25
 U 16-12 9998
 U 16-13 U836
 U 70- 1 low
 U 70- 4 6692
 U 70- 5 P7FA
 U 70- 6 FH25
 U 70- 7 681A
 U 70- 8 C18H
 U 70- 9 4782
 U 70-11 4HF5
 U 70-12 C18H
 U 70-13 677P
 U 70-14 0000
 U 70-15 0H55
 U 70-16 6692
 U 70-19 18F5
 U 71- 1 high
 U 71- 2 4F41
 U 71- 3 4F41
 U 71- 4 1427
 U 71- 5 high
 U 71- 6 4HF5
 U 71- 7 80P0
 U 71- 9 F070
 U 71-10 0H55
 U 71-11 high
 U 71-12 A755
 U 71-13 1946
 U 71-14 1946
 U 71-15 high
 U 72- 1 high
 U 72- 2 FH25
 U 72- 3 7P57

U 72- 4 6692
 U 72- 5 18F5
 U 72- 6 6A70
 U 72- 7 H902
 U 72- 9 4F41
 U 72-10 1946
 U 72-11 high
 U 72-12 high
 U 72-13 0FP2
 U 72-14 FH25
 U 72-15 9822
 U 73- 1 H5P0
 U 73- 2 18F5
 U 73- 3 FH25
 U 73- 4 1427
 U 73- 5 FH25
 U 73- 6 H902
 U 73- 8 6A70
 U 73- 9 FH25
 U 73-10 A755
 U 73-11 FH25
 U 73-12 6692
 U 73-13 0000
 U 75- 1 FH25
 (TOTLZ=0059)
 U 75- 2 FH25
 U 75- 3 high
 U 75- 4 FH25
 U 75- 5 FH25
 (TOTLZ=0207)
 U 75- 6 FH25
 U 75- 8 high
 U 75- 9 FH25
 U 75-10 high
 U 75-11 FH25
 U 75-12 0000
 U 75-13 FH25
 (TOTLZ=0207)
 U 81- 2 7P57
 U 81- 3 6692
 U 81- 4 H5P0
 U 81- 5 high
 U 81- 6 18F5
 U 81- 9 C18H
 U 81-10 high
 U 81-11 low
 U 81-12 high
 U 81-13 high
 U 82- 1 18F5
 U 82- 3 322H
 U 82- 4 9998
 U 82- 5 P7FH

U 82- 6 U836
 U 82- 7 322H
 U 82- 9 322H
 U 82-10 low
 U 82-12 high
 U 82-13 P7FA
 U 82-14 high
 U 82-15 high

Performance Tests and Troubleshooting - Model 64602A

64602A Timing Acquisition Board
 DUAL THRESHOLD #4

NORM MODE

VH = 75CC

DATA THRESHOLD: ecl & ttl

CLOCK THRESHOLD: ttl

ST-SP-QL THRESHOLD: ttl

Location of ST/SP/START: sa gate neg. edge

Location of QUAL/STOP: sa gate pos. edge

Location of CLOCK: sa clk pos. edge

Location of GROUND: gnd

ECL		TTL			
-----		-----			
U 7-13	1H46	U 27-28	high	U 11- 7	0CCC
U 7-15	68UH	U 27-29	high	U 11-11	68UH
U 11- 3	7P00	U 27-30	low	U 12- 7	A8F7
U 11-13	1H46	U 27-31	6537	U 12-11	3AHH
U 12- 3	6PCP	U 27-32	high	U 16-12	442A
U 12-14	3AHH	U 27-33	low	U 16-13	54A6
U 16-11	442A	U 27-34	high	U 22-15	0CCC
U 16-15	54A6	U 27-35	H2CF	U 23-15	0CCC
U 17- 2	442A	U 27-36	A707	U 24-15	7P00
U 17- 3	6537	U 27-37	low	U 25-15	7P00
U 17- 5	54A6	U 27-38	H2CF	U 29-15	7P00
U 27- 1	H2CF	U 27-39	A707	U 30-15	7P00
U 27- 2	A707	U 27-40	low	U 31-15	0CCC
U 27- 3	low			U 32-15	0CCC
U 27- 4	H2CF			U 70- 1	low
U 27- 5	A707			U 70- 4	3AHH
U 27- 6	low			U 70- 5	8580
U 27- 7	7P00			U 70- 6	75CC
U 27- 8	54A6			U 70- 7	545U
U 27- 9	high			U 70- 8	0CCC
U 27-10	68UH			U 70- 9	8FCU
U 27-11	low			U 70-11	A8F7
U 27-12	high			U 70-12	0CCC
U 27-13	high			U 70-13	low
U 27-14	high			U 70-14	0000
U 27-15	low			U 70-15	high
U 27-16	6FAP			U 70-16	3AHH
U 27-17	1915			U 70-19	HP3P
U 27-18	low			U 71- 1	high
U 27-19	6FAP			U 71- 2	P4A6
U 27-20	1915			U 71- 3	P4A6
U 27-21	low			U 71- 4	U9A5
U 27-22	6FAP			U 71- 5	high
U 27-23	1915			U 71- 6	A8F7
U 27-24	low			U 71- 7	HH7F
U 27-25	6FAP			U 71- 9	low
U 27-26	1915			U 71-10	high
U 27-27	high			U 71-11	high

Performance Tests and Troubleshooting - Model 64602A

U 71-12	68UH	U 81- 3	3AHH
U 71-13	high	U 81- 4	AC85
U 71-14	high	U 81- 5	high
U 71-15	high	U 81- 6	HP3P
U 72- 1	high	U 81- 8	7P00
U 72- 2	75CC	U 81- 9	0CCC
U 72- 3	P4P3	U 81-10	high
U 72- 4	3AHH	U 81-11	low
U 72- 5	HP3P	U 81-12	high
U 72- 6	1H46	U 81-13	high
U 72- 7	8F1P	U 82- 1	HP3P
U 72- 9	P4A6	U 82- 2	low
U 72-10	high	U 82- 3	8580
U 72-11	high	U 82- 4	442A
U 72-12	high	U 82- 5	6794
U 72-13	279C	U 82- 6	54A6
U 72-14	75CC	U 82- 7	H98A
U 72-15	P4A6	U 82- 9	767U
U 73- 1	AC85	U 82-10	low
U 73- 2	HP3P	U 82-11	5125
U 73- 3	75CC	U 82-12	high
U 73- 4	U9A5	U 82-13	8580
U 73- 5	75CC	U 82-14	high
U 73- 6	8F1P	U 82-15	high
U 73- 8	1H46		
U 73- 9	75CC		
U 73-10	68UH		
U 73-11	75CC		
(TOTLZ=0207)			
U 73-12	3AHH		
U 73-13	0000		
U 76- 2	U48A		
U 76- 3	5125		
U 76- 4	A2HA		
U 76- 5	UPH0		
U 76- 6	0H2U		
U 76- 7	5125		
U 76- 8	U1UF		
U 76- 9	0CCC		
U 76-11	8F1P		
U 76-13	75CC		
U 76-19	1367		
U 78- 2	650H		
U 78- 3	545U		
U 78- 4	8FCU		
U 78- 5	8580		
U 78- 6	767U		
U 78- 7	6794		
U 78- 8	H98A		
U 78- 9	8580		
U 78-11	8F1P		
U 78-13	75CC		
U 78-19	8U27		
U 81- 2	P4P3		

Performance Tests and Troubleshooting - Model 64602A

64602A Timing Acquisition Board
GLITCH #5

NORM MODE

VH = 75UA

DATA THRESHOLD HIGH: ecl & ttl
CLOCK THRESHOLD: ttl
ST-SP-QL THRESHOLD: ttl

Location of ST/SP/START: sa gate neg. edge
Location of QUAL/STOP: sa gate pos. edge
Location of CLOCK: sa clk pos. edge
Location of GROUND: gnd

ECL

U 5- 3	41P2	U 9-14	796U	U 22-14	41P2
U 5- 7	3C6F	U 9-15	796U	U 22-35	796U
U 5-11	41P2	U 10- 1	high	U 23-35	796U
U 5-15	3C6F	U 10- 2	0000	U 24-35	796U
U 6- 1	high	U 10- 3	75UA	U 25-35	796U
U 6- 2	3C6F	U 10- 4	0000	U 27- 1	4CF6
U 6- 3	41P2	U 10- 5	75UA	U 27- 2	3P3F
U 6- 4	0000	U 10- 6	0F95	U 27- 3	0000
U 6- 5	high	U 10- 7	796U	U 27- 4	4CF6
U 6- 6	41P2	U 10- 9	0000	U 27- 5	3P3F
U 6- 7	75UA	U 10-10	796U	U 27- 6	0000
U 6-10	3C6F	U 10-11	0000	U 27- 7	8A13
U 6-11	75UA	U 10-12	0000	U 27- 8	3C3F
U 6-12	high	U 10-13	796U	U 27- 9	high
U 6-13	0000	U 10-14	0F95	U 27-10	8H66
U 6-14	3C6F	U 10-15	796U	U 27-11	0F95
U 6-15	41P2	U 11- 3	8A13	U 27-12	796U
U 7- 1	high	U 11-13	U89F	U 27-13	high
U 7- 2	0F95	U 12- 3	0669	U 27-14	796U
U 7- 3	0000	U 12-14	CAUH	U 27-15	18CP
U 7- 4	796U	U 14- 1	high	U 27-16	3P3F
U 7- 5	0F95	U 14- 2	FU07	U 27-17	4CF6
U 7-10	796U	U 14- 3	75UA	U 27-18	18CP
U 7-11	0F95	U 14- 4	FU07	U 27-19	3P3F
U 7-12	8H66	U 14- 5	CAUH	U 27-20	4CF6
U 7-13	U89F	U 14- 6	CAUH	U 27-21	18CP
U 7-14	0F95	U 14- 7	75UA	U 27-22	3P3F
U 7-15	8H66	U 14- 9	CAUH	U 27-23	4CF6
U 9- 1	high	U 14-10	FU07	U 27-24	18CP
U 9- 2	796U	U 14-12	75UA	U 27-25	3P3F
U 9- 3	796U	U 14-14	high	U 27-26	4CF6
U 9- 5	0F95	U 14-15	75UA	U 27-27	796U
U 9- 6	high	U 16-11	73H5	U 27-28	high
U 9- 7	0F95	U 16-15	3C3F	U 27-29	796U
U 9-10	0F95	U 17- 2	73H5	U 27-30	0F95
U 9-11	high	U 17- 3	3H13	U 27-31	3H13
U 9-12	0F95	U 17- 5	3C3F	U 27-32	high
U 9-13	low	U 22- 6	3C6F	U 27-33	low

TTL

U 27-34	high	U 5- 4	41P2	U 24-20	low
U 27-35	4CF6	U 5- 5	3C6F	U 24-21	low
U 27-36	3P3F	U 5-12	41P2	U 24-22	5436
U 27-37	0000	U 5-13	3C6F	U 24-23	6P48
U 27-38	4CF6	U 11- 7	UUP9	U 24-24	low
U 27-39	3P3F	U 11-11	8H66	U 24-37	low
U 27-40	0000	U 12- 7	P727	U 24-38	00U9
U 29-35	796U	U 12-11	CAUH	U 24-39	low
U 30-35	796U	U 16-12	73H5	U 24-40	4373
U 31-35	796U	U 16-13	3C3F	U 25- 1	CPC2
U 32-35	796U	U 22- 1	F07H	U 25- 2	CPC2
		U 22- 2	436C	U 25- 3	374A
		U 22- 3	low	U 25- 4	374A
		U 22- 4	low	U 25-15	8A13
		U 22-15	UUP9	U 25-17	74PU
		U 22-17	low	U 25-18	74PU
		U 22-18	low	U 25-19	74PU
		U 22-19	low	U 25-20	74PU
		U 22-20	low	U 25-21	4FH6
		U 22-21	low	U 25-22	2C0A
		U 22-22	5436	U 25-23	45A3
		U 22-23	6P48	U 25-24	45A3
		U 22-24	low	U 25-37	PF12
		U 22-37	low	U 25-38	PF12
		U 22-38	00U9	U 25-39	65PA
		U 22-39	low	U 25-40	65PA
		U 22-40	4373	U 29- 1	F07H
		U 23- 1	CPC2	U 29- 2	436C
		U 23- 2	CPC2	U 29- 3	low
		U 23- 3	374A	U 29- 4	low
		U 23- 4	374A	U 29-15	8A13
		U 23-15	UUP9	U 29-17	low
		U 23-17	74PU	U 29-18	low
		U 23-18	74PU	U 29-19	low
		U 23-19	74PU	U 29-20	low
		U 23-20	74PU	U 29-21	low
		U 23-21	4FH6	U 29-22	5436
		U 23-22	2C0A	U 29-23	6P48
		U 23-23	45A3	U 29-24	low
		U 23-24	45A3	U 29-37	low
		U 23-37	PF12	U 29-38	00U9
		U 23-38	PF12	U 29-39	low
		U 23-39	65PA	U 29-40	4373
		U 23-40	65PA	U 30- 1	CPC2
		U 24- 1	F07H	U 30- 2	CPC2
		U 24- 2	436C	U 30- 3	374A
		U 24- 3	low	U 30- 4	374A
		U 24- 4	low	U 30-15	8A13
		U 24-15	8A13	U 30-17	74PU
		U 24-17	low	U 30-18	74PU
		U 24-18	low	U 30-19	74PU
		U 24-19	low	U 30-20	74PU

Performance Tests and Troubleshooting - Model 64602A

U 30-21	4FH6	U 70-15	high	U 78- 9	H3P8
U 30-22	2C0A	U 70-16	CAUH	U 78-11	4261
U 30-23	45A3	U 70-19	high	U 78-13	75UA
U 30-24	45A3	U 71- 1	high	U 78-19	4CF6
U 30-37	PF12	U 71- 2	A546		
U 30-38	PF12	U 71- 3	A546		
U 30-39	65PA	U 71- 4	379C		
U 30-40	65PA	U 71- 5	high		
U 31- 1	F07H	U 71- 6	P727		
U 31- 2	436C	U 72- 1	high		
U 31- 3	low	U 72- 2	75UA		
U 31- 4	low	U 72- 3	FU07		
U 31-15	UUP9	U 72- 4	CAUH		
U 31-17	low	U 72- 5	high		
U 31-18	low	U 72- 6	U89F		
U 31-19	low	U 72- 7	4261		
U 31-20	low	U 72- 9	A546		
U 31-21	low	U 72-10	high		
U 31-22	5436	U 72-11	high		
U 31-23	6P48	U 72-12	high		
U 31-24	low	U 72-13	4261		
U 31-37	low	U 72-14	75UA		
U 31-38	00U9	U 72-15	A546		
U 31-39	low	U 73- 1	low		
U 31-40	4373	U 73- 2	high		
U 32- 1	CPC2	U 73- 3	75UA		
U 32- 2	CPC2	U 73- 4	379C		
U 32- 3	374A	U 73- 5	75UA		
U 32- 4	374A	U 73- 6	4261		
U 32-15	UUP9	U 73- 8	U89F		
U 32-17	74PU	U 73- 9	75UA		
U 32-18	74PU	U 73-10	8H66		
U 32-19	74PU	U 73-11	75UA		
U 32-20	74PU	(TOTLZ=0207)			
U 32-21	4FH6	U 73-12	CAUH		
U 32-22	2C0A	U 73-13	0000		
U 32-23	45A3	U 76- 2	4H23		
U 32-24	45A3	U 76- 3	7HAU		
U 32-37	PF12	U 76- 4	2H9C		
U 32-38	PF12	U 76- 5	H3P8		
U 32-39	65PA	U 76- 6	7AC8		
U 32-40	65PA	U 76- 7	HP50		
U 70- 1	low	U 76- 8	6A64		
U 70- 2	75UA	U 76- 9	UUP9		
U 70- 4	CAUH	U 76-11	4261		
U 70- 5	H3P8	U 76-13	75UA		
U 70- 6	75UA	U 76-19	4CF6		
U 70- 7	U251	U 78- 2	1520		
U 70- 8	UUP9	U 78- 3	U251		
U 70- 9	3267	U 78- 4	3267		
U 70-11	P727	U 78- 5	H3P8		
U 70-12	UUP9	U 78- 6	7AC8		
U 70-13	low	U 78- 7	7HAU		
U 70-14	0000	U 78- 8	2H9C		

64602A Timing Acquisition Board
 DACS TRIGGER #6

NORM MODE

VH = H7CH

DATA THRESHOLD: ecl & ttl
 CLOCK THRESHOLD: ttl
 ST-SP-QL THRESHOLD: ttl

Location of ST/SP/START: sa gate neg. edge
 Location of QUAL/STOP: sa gate pos. edge
 Location of CLOCK: sa clock pos. edge
 Location of GROUND: gnd

ECL

```

-----
U 7-12 2619
U 7-13 U1A4
U 7-15 2619
U 11-13 U1A4
U 12-14 PCHP
U 16-11 CC3A
U 16-15 A24P
U 17- 2 CC3A
U 17- 3 FPF9
U 17- 5 A24P
U 22-26 P620
U 23-26 7309
U 24-26 P620
U 25-26 7309
U 27- 1 623C
U 27- 2 C586
U 27- 3 P620
U 27- 4 623C
U 27- 5 C586
U 27- 6 P620
U 27- 8 A24P
U 27- 9 high
U 27-10 2619
U 27-13 high
U 27-15 7309
U 27-16 724H
U 27-17 A5U0
U 27-18 7309
U 27-19 724H
U 27-20 A5U0
U 27-21 7309
U 27-22 724H
U 27-23 A5U0
U 27-24 7309
U 27-25 724H
U 27-26 A5U0
U 27-28 high
U 27-31 FPF9
  
```

```

U 27-32 high
U 27-33 low
U 27-34 high
U 27-35 623C
U 27-36 C586
U 27-37 P620
U 27-38 623C
U 27-39 C586
U 27-40 P620
U 29-26 P620
U 30-26 7309
U 31-26 P620
U 32-26 7309
  
```

TTL

```

-----
U 11-11 2619
U 12-11 PCHP
U 16-12 CC3A
U 16-13 A24P
U 70- 1 low
U 70- 4 PCHP
U 70- 5 CHF1
U 70- 6 H7CH
U 70- 7 HA87
U 70- 9 1P78
U 70-11 high
U 70-13 73F7
U 70-14 0000
U 70-15 high
U 70-16 PCHP
U 70-19 P711
U 72- 1 high
U 72- 2 H7CH
U 72- 3 OFFU
U 72- 4 PCHP
U 72- 5 P711
U 72- 6 U1A4
U 72- 7 2AH6
U 72- 9 high
U 72-10 high
U 72-11 high
U 72-12 high
U 72-13 1A7A
U 72-14 H7CH
U 72-15 H7CH
(TOTLZ=0125)
U 73- 1 30AF
U 73- 2 P711
U 73- 3 H7CH
U 73- 4 UH6C
U 73- 5 H7CH
U 73- 6 2AH6
U 73- 8 U1A4
  
```

Performance Tests and Troubleshooting - Model 64602A

U 73- 9 H7CH
U 73-10 2619
U 73-11 H7CH
(TOTLZ=0207)
U 73-12 PCHP
U 73-13 0000
U 76- 2 P2U0
U 76-10 low
U 76-11 2AH6
U 76-13 H7CH
U 76-19 FFAC
U 78- 2 3P15
U 78- 3 HA87
U 78- 4 1P78
U 78- 5 CHF1
U 78- 6 U401
U 78- 7 3801
U 78- 8 U311
U 78-10 low
U 78-11 2AH6
U 78-13 H7CH
U 78-19 F47A
U 81- 2 OFFU
U 81- 3 PCHP
U 81- 4 30AF
U 81- 5 high
U 81- 6 P711
U 81-10 high
U 81-11 low
U 81-12 high
U 81-13 high
U 82- 1 P711
U 82- 4 CC3A
U 82- 5 3801
U 82- 6 A24P
U 82- 7 U311
U 82- 9 U401
U 82-10 low
U 82-12 high
U 82-13 CHF1
U 82-14 high
U 82-15 high

Performance Tests and Troubleshooting - Model 64602A

64602A Timing Acquisition Board
 CHECKER BOARD #7

NORM MODE

UH = UF19

DATA THRESHOLD HIGH: ecl & ttl
 CLOCK THRESHOLD: ttl
 ST-SP-QL THRESHOLD: ttl

Location of ST/SP/START: sa gate neg. edge
 Location of QUAL/STOP: sa gate pos. edge
 Location of CLOCK: sa clk pos. edge
 Location of GROUND: gnd

ECL

 U 5-11 0000
 U 5-15 F1CU
 U 11- 3 6P32
 U 11-12 F1CU
 U 12-15 F1CU
 U 22- 6 F1CU
 U 22-14 F1CU

TTL

 U 5-12 F1CU 22 U026
 U 5-13 F1CU 23 FH80
 U 11- 7 922C 24 U026
 U 11-10 UF19 37 82F8
 (TOTLZ=4625) 38 7PH1
 U 12-10 F1CU 39 82F8
 40 7PH1
 U 22 1 7PH1
 1 2 82F8 U 33 1 7450
 U 23 3 7PH1 1 2 315C
 1 4 82F8 U 34 3 U437
 U 31 12 3HA6 4 1F58
 1 15 922C 5 U9AF
 U 32 17 U026 6 2702
 18 FH80 7 705A
 19 U026 8 low
 20 FH80 9 82F8
 21 U026 10 5684
 22 FH80 11 7PH1
 23 U026 12 AA9H
 24 FH80 13 82F8
 37 7PH1 14 5684
 38 82F8 15 7PH1
 39 7PH1 16 AA9H
 40 82F8 17 high
 18 A7CU
 19 low
 20 F1CU
 21 1561
 22 high
 U 24 1 82F8 U 35 1 7450
 1 2 7PH1 1 2 315C
 U 25 3 82F8 U 36 3 U437
 1 4 7PH1 4 1F58
 U 29 12 3HA6 5 U9AF
 1 15 6P32 6 2702
 U 30 17 FH80 7 705A
 18 U026
 19 FH80
 20 U026
 21 FH80

Performance Tests and Troubleshooting - Model 64602A

8	low		17	high		4	1F58
9	82F8		18	7F28		5	U9AF
10	5684		19	low		6	2702
11	7PH1		20	F1CU		7	705A
12	AA9H		21	1561		8	low
13	82F8		22	high		9	82F8
14	5684	U 41	1	7450		10	5684
15	7PH1	I	2	315C		11	7PH1
16	AA9H	U 42	3	U437		12	AA9H
17	high		4	1F58		13	82F8
18	PCUF		5	U9AF		14	5684
19	low		6	2702		15	7PH1
20	F1CU		7	705A		16	AA9H
21	1561		8	low		17	high
22	high		9	7PH1		18	P721
U 37	1		10	5684		19	low
I	2		11	82F8		20	F1CU
U 38	3		12	AA9H		21	1561
	4		13	7PH1		22	high
	5		14	5684	U 47	1	7450
	6		15	82F8	I	2	315C
	7		16	AA9H	U 48	3	U437
	8		17	high		4	1F58
	9		18	4076		5	U9AF
	10		19	low		6	2702
	11		20	F1CU		7	705A
	12		21	1561		8	low
	13		22	high		9	82F8
	14	U 43	1	7450		10	5684
	15	I	2	315C		11	7PH1
	16	U 44	3	U437		12	AA9H
	17		4	1F58		13	82F8
	18		5	U9AF		14	5684
	19		6	2702		15	7PH1
	20		7	705A		16	AA9H
	21		8	low		17	high
	22		9	7PH1		18	A800
U 39	1		10	5684		19	low
I	2		11	82F8		20	F1CU
U 40	3		12	AA9H		21	1561
	4		13	7PH1		22	high
	5		14	5684	U 49	1	7450
	6		15	82F8	I	2	315C
	7		16	AA9H	U 50	3	U437
	8		17	high		4	1F58
	9		18	577U		5	U9AF
	10		19	low		6	2702
	11		20	F1CU		7	705A
	12		21	1561		8	low
	13		22	high		9	U026
	14	U 45	1	7450		10	C65H
	15	I	2	315C		11	FH80
	16	U 46	3	U437		12	AA9H

Performance Tests and Troubleshooting - Model 64602A

13	U026		22	high		9	FH80
14	C65H	U 55	1	7450		10	C65H
15	FH80	I	2	315C		11	U026
16	AA9H	U 56	3	U437		12	AA9H
17	high		4	1F58		13	FH80
18	A7CU		5	U9AF		14	C65H
19	low		6	2702		15	U026
20	F1CU		7	705A		16	AA9H
21	1561		8	low		17	high
22	high		9	FH80		18	577U
U 51	1		10	C65H		19	low
I	2		11	U026		20	F1CU
U 52	3		12	AA9H		21	1561
	4		13	FH80		22	high
	5		14	C65H	U 61	1	7450
	6		15	U026	I	2	315C
	7		16	AA9H	U 62	3	U437
	8		17	high		4	1F58
	9		18	7F28		5	U9AF
10	C65H		19	low		6	2702
11	FH80		20	F1CU		7	705A
12	AA9H		21	1561		8	low
13	U026		22	high		9	U026
14	C65H	U 57	1	7450		10	C65H
15	FH80	I	2	315C		11	FH80
16	AA9H	U 58	3	U437		12	AA9H
17	high		4	1F58		13	U026
18	PCUF		5	U9AF		14	C65H
19	low		6	2702		15	FH80
20	F1CU		7	705A		16	AA9H
21	1561		8	low		17	high
22	high		9	FH80		18	P721
U 53	1		10	C65H		19	low
I	2		11	U026		20	F1CU
U 54	3		12	AA9H		21	1561
	4		13	FH80		22	high
	5		14	C65H	U 63	1	7450
	6		15	U026	I	2	315C
	7		16	AA9H	U 64	3	U437
	8		17	high		4	1F58
	9		18	4076		5	U9AF
10	C65H		19	low		6	2702
11	U026		20	F1CU		7	705A
12	AA9H		21	1561		8	low
13	FH80		22	high		9	U026
14	C65H	U 59	1	7450		10	C65H
15	U026	I	2	315C		11	FH80
16	AA9H	U 60	3	U437		12	AA9H
17	high		4	1F58		13	U026
18	7318		5	U9AF		14	C65H
19	low		6	2702		15	FH80
20	F1CU		7	705A		16	AA9H
21	1561		8	low		17	high

Performance Tests and Troubleshooting - Model 64602A

18	A800	U 67-14	315C	U 70-13	727U
19	low	U 67-15	05C5	U 70-14	0000
20	F1CU	U 67-16	U437	(TOTLZ=4625)	
21	1561	U 67-17	P978	U 70-15	high
22	high	U 67-18	1F58	U 70-16	0000
U 65- 1	UF19	U 67-19	low	U 70-19	high
(TOTLZ=0002)		U 68- 1	UF19	U 72- 1	high
U 65- 2	0000	(TOTLZ=0002)		U 72- 2	UF19
(TOTLZ=4625)		U 68- 2	0000	(TOTLZ=4625)	
U 65- 3	1561	(TOTLZ=4625)		U 72- 3	UF19
U 65- 4	U9AF	U 68- 3	1F58	(TOTLZ=0FLO)	
U 65- 5	2702	U 68- 4	U437	U 72- 4	0000
U 65- 6	705A	U 68- 5	315C	(TOTLZ=4625)	
U 65- 7	0000	U 68- 6	7450	U 72- 5	high
(TOTLZ=4625)		U 68- 7	0000	U 72- 6	high
U 65- 9	0000	(TOTLZ=4625)		U 72- 7	high
(TOTLZ= 4625)		U 68- 9	0000	U 72- 9	high
U 65-10	3UA3	(TOTLZ=4625)		U 72-10	high
U 65-11	705A	U 68-10	high	U 72-12	F1CU
U 65-12	2702	U 68-11	7450	U 72-13	UF19
U 65-13	U9AF	U 68-12	315C	(TOTLZ=49743)	
U 65-14	1561	U 68-13	U437	U 72-14	UF19
U 65-15	4CF9	U 68-14	1F58	(TOTLZ=4625)	
U 66- 1	UF19	U 68-15	3UA3	U 72-15	F1CU
(TOTLZ=0002)		U 69- 1	UF19	U 73- 1	low
U 66- 2	0000	(TOTLZ=0002)		U 73- 2	high
(TOTLZ=4625)		U 69- 2	0000	U 73- 3	UF19
U 66- 3	1561	(TOTLZ=4625)		(TOTLZ=4625)	
U 66- 4	U9AF	U 69- 3	1F58	U 73- 4	low
U 66- 5	2702	U 69- 4	U437	U 73- 5	UF19
U 66- 6	705A	U 69- 5	315C	(TOTLZ=4625)	
U 66- 7	0000	U 69- 6	7450	U 73- 6	high
(TOTLZ=4625)		U 69- 7	0000	U 73- 8	high
U 66- 9	0000	(TOTLZ=4625)		U 73- 9	UF19
(TOTLZ= 4625)		U 69- 9	0000	(TOTLZ=4625)	
U 66-10	3UA3	(TOTLZ=4625)		U 73-10	low
U 66-11	705A	U 69-10	high	U 73-11	UF19
U 66-12	2702	U 69-11	7450	(TOTLZ=0FLO)	
U 66-13	U9AF	U 69-12	315C	U 73-12	0000
U 66-14	1561	U 69-13	U437	U 73-13	UF19
U 66-15	4CF9	U 69-14	1F58	(TOTLZ=4625)	
U 67- 1	low	U 69-15	3UA3	U 74- 1	922C
U 67- 2	P041	U 70- 1	low	U 74- 2	A9F0
U 67- 3	1561	U 70- 4	0000	U 74- 3	PHA9
U 67- 4	082P	(TOTLZ=4625)		U 74- 4	26UH
U 67- 5	U9AF	U 70- 5	FH6H	U 74- 5	0000
U 67- 6	FH42	U 70- 6	UF19	(TOTLZ=4625)	
U 67- 7	2702	(TOTLZ=4625)		U 74- 6	1C5C
U 67- 8	8849	U 70- 7	H636	U 74- 7	A7CU
U 67- 9	705A	U 70- 8	922C	U 74- 9	7318
U 67-11	8F43	U 70- 9	FH6H	U 74-10	4076
U 67-12	7450	U 70-11	high	U 74-11	P721
U 67-13	HC1C	U 70-12	922C	U 74-12	A800

Performance Tests and Troubleshooting - Model 64602A

U 74-13	577U	U 80-15	5684
U 74-14	7F28	U 80-16	FH6H
U 74-15	PCUF	U 80-17	AA9H
U 75- 1	26UH	U 80-18	H636
U 75- 2	UF19	U 80-19	P742
(TOTLZ=4625)		U 81- 1	UF19
U 75- 3	26UH	(TOTLZ=4625)	
U 75- 4	UF19	U 81- 2	1C5C
(TOTLZ=4625)		U 81- 3	P742
U 75- 5	UF19	U 81- 4	low
(TOTLZ=0FLO)		U 81- 5	high
U 75- 6	UF19	U 81- 6	high
(TOTLZ=4625)		U 81- 8	6P32
U 75- 8	high	U 81- 9	922C
U 75- 9	UF19	U 81-10	high
(TOTLZ=4625)		U 81-11	3HA6
U 75-10	high	U 81-12	high
U 75-11	UF19	U 81-13	F1CU
(TOTLZ=4625)		U 82- 1	high
U 75-12	0000	U 82- 2	1F58
U 75-13	UF19	U 82- 3	FH6H
(TOTLZ= 0FLO)		U 82- 4	high
U 79- 1	high	U 82- 5	H636
U 79- 2	1561	U 82- 6	low
U 79- 3	H636	U 82- 7	FH6H
U 79- 4	U9AF	U 82- 9	H636
U 79- 5	PHA9	U 82-10	low
U 79- 6	2702	U 82-11	PHA9
U 79- 7	A9F0	U 82-12	high
U 79- 8	705A	U 82-13	FH6H
U 79- 9	922C	U 82-14	high
U 79-11	1F58	U 82-15	high
U 79-12	H636	U 83- 1	P742
U 79-13	U437	U 83- 2	C65H
U 79-14	H636	U 83- 3	H636
U 79-15	315C	U 83- 4	AA9H
U 79-16	FH6H	U 83- 5	FH6H
U 79-17	7450	U 83- 6	C65H
U 79-18	FH6H	U 83- 7	PHA9
U 79-19	high	U 83- 8	AA9H
U 80- 1	P742	U 83- 9	922C
U 80- 2	5684	U 83-11	AA9H
U 80- 3	FH6H	U 83-12	FH6H
U 80- 4	AA9H	U 83-13	C65H
U 80- 5	H636	U 83-14	H636
U 80- 6	5684	U 83-15	AA9H
U 80- 7	FH6H	U 83-16	FH6H
U 80- 8	AA9H	U 83-17	C65H
U 80- 9	H636	U 83-18	H636
U 80-11	5684	U 83-19	P742
U 80-12	A9F0		
U 80-13	AA9H		
U 80-14	H636		

Performance Tests and Troubleshooting - Model 64602A

64602A Timing Acquisition Board
RAM FILLED #8

NORM MODE

VH = 38UF

DATA THRESHOLD HIGH: ecl & ttl
CLOCK THRESHOLD: ttl
ST-SP-QL THRESHOLD: ttl

Location of ST/SP/START: sa gate neg. edge
Location of QUAL/STOP: sa gate pos. edge
Location of CLOCK: sa clk pos. edge
Location of GROUND: gnd

ECL

TTL

U 7-12 8505	U 27-21 70UC	U 11- 7 2237
U 7-13 CHU9	U 27-22 64U3	U 11-11 8505
U 7-15 8505	U 27-23 5F0U	U 12- 5 64U3
U 11- 3 1AFC	U 27-24 70UC	U 12- 7 F9P6
U 11-13 CHU9	U 27-25 64U3	U 12-11 C91H
U 12- 2 64U3	U 27-26 5F0U	U 16-12 78UU
U 12- 3 5F0U	U 27-27 38UF	U 16-13 9PP7
U 12- 4 5F0U	U 27-28 high	U 22 1 70UC
U 12-14 C91H	U 27-29 38UF	I 2 70UC
U 16-11 78UU	U 27-30 low	U 23 3 70UC
U 16-15 9PP7	U 27-31 HPP4	I 4 70UC
U 17- 2 78UU	U 27-32 high	U 31 5 low
U 17- 3 HPP4	U 27-33 low	I 15 2237
U 17- 5 9PP7	U 27-34 high	U 32 17 70UC
U 22-26 70UC	U 27-35 5F0U	18 70UC
U 23-26 70UC	U 27-36 64U3	19 70UC
U 24-26 70UC	U 27-37 70UC	20 70UC
U 25-26 70UC	U 27-38 5F0U	21 70UC
U 27- 1 5F0U	U 27-39 64U3	22 70UC
U 27- 2 64U3	U 27-40 70UC	23 70UC
U 27- 3 70UC	U 29-26 70UC	24 70UC
U 27- 4 5F0U	U 30-26 70UC	37 70UC
U 27- 5 64U3	U 31-26 70UC	38 70UC
U 27- 6 70UC	U 32-26 70UC	39 70UC
U 27- 7 1AFC		40 70UC
U 27- 8 9PP7		U 24 1 70UC
U 27- 9 high		I 2 70UC
U 27-10 8505		U 25 3 70UC
U 27-11 low		I 4 70UC
U 27-12 38UF		U 29 15 1AFC
U 27-13 high		I 17 70UC
U 27-14 38UF		U 30 18 70UC
U 27-15 70UC		19 70UC
U 27-16 64U3		20 70UC
U 27-17 5F0U		21 70UC
U 27-18 70UC		22 70UC
U 27-19 64U3		
U 27-20 5F0U		

Performance Tests and Troubleshooting - Model 64602A

	23	70UC		1	2	U519		10	387H	
	24	70UC		U 38	3	F50C		11	70UC	
	37	70UC		I	4	3H26		12	387H	
	38	70UC		U 53	5	FF3F		13	70UC	
	39	70UC		I	6	3F80		14	387H	
	40	70UC		U 54	7	4H36		15	70UC	
					8	low		16	387H	
U 33	1	351H			9	70UC		17	high	
I	2	U519			10	387H		18	484C	
U 34	3	F50C			11	70UC		19	low	
I	4	3H26			12	387H		20	38UF	
U 49	5	FF3F			13	70UC		21	3810	
I	6	3F80			14	387H		22	high	
U 50	7	4H36			15	70UC				
	8	low			16	387H	U 43	1	351H	
	9	70UC			17	high	I	2	U519	
	10	387H			18	0CC2	U 44	3	F50C	
	11	70UC			19	low	I	4	3H26	
	12	387H			20	38UF	U 59	5	FF3F	
	13	70UC			21	3810	I	6	3F80	
	14	387H			22	high	U 60	7	4H36	
	15	70UC						8	low	
	16	387H		U 39	1	351H		9	70UC	
	17	high		I	2	U519		10	387H	
	18	CC58		U 40	3	F50C		11	70UC	
	19	low		I	4	3H26		12	387H	
	20	38UF		U 55	5	FF3F		13	70UC	
	21	3810		I	6	3F80		14	387H	
	22	high		U 56	7	4H36		15	70UC	
					8	low		16	387H	
					9	70UC		17	high	
U 35	1	351H			10	387H		18	P108	
I	2	U519			11	70UC		19	low	
U 36	3	F50C			12	387H		20	38UF	
I	4	3H26			13	70UC		21	3810	
U 51	5	FF3F			14	387H		22	high	
I	6	3F80			15	70UC				
U 52	7	4H36			16	387H		U 45	1	351H
	8	low			17	high		I	2	U519
	9	70UC			18	014C		U 46	3	F50C
	10	387H			19	low		I	4	3H26
	11	70UC			20	38UF		U 61	5	FF3F
	12	387H			21	3810		I	6	3F80
	13	70UC			22	high		U 62	7	4H36
	14	387H							8	low
	15	70UC							9	70UC
	16	387H		U 41	1	351H			10	387H
	17	high		I	2	U519			11	70UC
	18	U602		U 42	3	F50C			12	387H
	19	low		I	4	3H26			13	70UC
	20	38UF		U 57	5	FF3F			14	387H
	21	3810		I	6	3F80			15	70UC
	22	high		U 58	7	4H36			16	387H
					8	low			17	high
U 37	1	351H			9	70UC				

Performance Tests and Troubleshooting - Model 64602A

18	2A7U	U 72-13	04P4	U 78-11	04P4
19	low	U 72-14	38UF	U 78-12	low
20	38UF	U 72-15	38UF	U 78-13	38UF
21	3810	(TOTLZ=0125)		U 78-19	AH15
22	high	U 73- 1	low	U 79- 1	high
		U 73- 2	high	U 79- 2	3810
U 47	1 351H	U 73- 3	38UF	U 79- 3	14A7
I	2 U519	U 73- 4	3F18	U 79- 4	FF3F
U 48	3 F50C	U 73- 5	38UF	U 79- 5	CC64
I	4 3H26	U 73- 6	04P4	U 79- 6	3F80
U 63	5 FF3F	U 73- 8	CHU9	U 79- 7	5A62
I	6 3F80	U 73- 9	38UF	U 79- 8	4H36
U 64	7 4H36	U 73-10	8505	U 79- 9	2237
	8 low	U 73-11	38UF	U 79-11	3H26
	9 70UC	U 73-12	C91H	U 79-12	28CU
	10 387H	U 74- 1	2237	U 79-13	F50C
	11 70UC	U 74- 2	5A62	U 79-14	14A7
	12 387H	U 74- 3	CC64	U 79-15	U519
	13 70UC	U 74- 4	91H3	U 79-16	14A7
	14 387H	U 74- 5	C91H	U 79-17	351H
	15 70UC	U 74- 6	28FP	U 79-18	14A7
	16 387H	U 74- 7	CC58	U 79-19	high
	17 high	U 74- 9	0CC2	U 80- 1	1032
	18 PFA1	U 74-10	484C	U 80- 2	387H
	19 low	U 74-11	2A7U	U 80- 3	14A7
	20 38UF	U 74-12	PFA1	U 80- 4	387H
	21 3810	U 74-13	P1U8	U 80- 5	14A7
	22 high	U 74-14	014C	U 80- 6	387H
		U 74-15	U602	U 80- 7	F22H
U 70- 1	low	U 75- 1	91H3	U 80- 8	387H
U 70- 4	C91H	U 75- 2	38UF	U 80- 9	C658
U 70- 5	14A7	U 75- 3	91H3	U 80-11	387H
U 70- 6	38UF	U 76- 1	low	U 80-12	5A62
U 70- 7	2968	U 76- 2	28CU	U 80-13	387H
U 70- 8	2237	U 76- 3	14A7	U 80-14	14A7
U 70- 9	F22H	U 76- 4	14A7	U 80-15	387H
U 70-11	F9P6	U 76- 5	14A7	U 80-16	14A7
U 70-12	2237	U 76- 6	14A7	U 80-17	387H
U 70-13	38UF	U 76- 7	CC64	U 80-18	28CU
U 70-14	0000	U 76- 8	5A62	U 80-19	1032
U 70-15	64U3	U 76- 9	2237	U 82- 1	high
U 70-16	C91H	U 76-10	low	U 82- 2	3H26
U 70-19	high	U 76-11	04P4	U 82- 3	14A7
U 72- 1	high	U 76-12	low	U 82- 4	78UU
U 72- 2	38UF	U 76-13	38UF	U 82- 5	14A7
U 72- 3	81P1	U 76-19	AH15	U 82- 6	9PP7
U 72- 4	C91H	U 78- 2	C658	U 82- 7	14A7
U 72- 5	high	U 78- 3	2968	U 82- 9	14A7
U 72- 6	CHU9	U 78- 4	F22H	U 82-10	low
U 72- 7	04P4	U 78- 5	14A7	U 82-11	CC64
U 72- 9	high	U 78- 6	14A7	U 82-12	high
U 72-10	high	U 78- 7	14A7	U 82-13	14A7
U 72-11	high	U 78- 8	14A7	U 82-14	high
U 72-12	high	U 78- 9	14A7	U 82-15	high

Performance Tests and Troubleshooting - Model 64602A

U 83- 1	1032
U 83- 2	387H
U 83- 3	14A7
U 83- 4	387H
U 83- 5	14A7
U 83- 6	387H
U 83- 7	CC64
U 83- 8	387H
U 83- 9	2237
U 83-11	387H
U 83-12	14A7
U 83-13	387H
U 83-14	14A7
U 83-15	387H
U 83-16	14A7
U 83-17	387H
U 83-18	2968
U 83-19	1032

Performance Tests and Troubleshooting - Model 64602A

64602A Timing Acquisition Board
 GALLOPING ONES #9

NORM MODE

VH = 4F27

DATA THRESHOLD HIGH: ecl & ttl
 CLOCK THRESHOLD: ttl
 ST-SP-QL THRESHOLD: ttl

Location of ST/SP/START: sa gate neg. edge
 Location of QUAL/STOP: sa gate pos. edge
 Location of CLOCK: sa clk pos. edge
 Location of GROUND: gnd

ECL

TTL

U 22-26 2317	U 27-31 low	U 4- 1 0000
U 22-35 7PCC	U 27-32 high	U 4- 2 6PCC
U 23-26 2317	U 27-33 low	U 4- 3 0000
U 23-35 7PCC	U 27-34 high	U 4- 4 high
U 24-26 2317	U 27-35 C01P	U 4- 5 229F
U 24-35 7PCC	U 27-36 UF39	U 4- 6 6PCC
U 25-26 2317	U 27-37 2317	U 4- 7 0059
U 25-35 7PCC	U 27-38 C01P	U 4- 9 4F7P
U 27- 1 C01P	U 27-39 UF39	U 4-10 high
U 27- 2 UF39	U 27-40 2317	U 4-11 0089
U 27- 3 2317	U 29-26 2317	U 4-12 0059
U 27- 4 C01P	U 29-35 7PCC	U 4-13 0000
U 27- 5 UF39	U 30-26 2317	U 4-14 229F
U 27- 6 2317	U 30-35 7PCC	U 4-15 4F27
U 27- 7 249H	U 31-26 2317	
U 27- 8 low	U 31-35 7PCC	U 22 1 2317
U 27- 9 high	U 32-26 2317	2 2317
U 27-10 low	U 32-35 7PCC	U 23 3 2317
U 27-11 329F		4 2317
U 27-12 7PCC		U 31 15 68CA
U 27-13 high		17 2317
U 27-14 7PCC		U 32 18 2317
U 27-15 2317		19 2317
U 27-16 UF39		20 2317
U 27-17 C01P		21 2317
U 27-18 2317		22 2317
U 27-19 UF39		23 2317
U 27-20 C01P		24 2317
U 27-21 2317		37 2317
U 27-22 UF39		38 2317
U 27-23 C01P		39 2317
U 27-24 2317		40 2317
U 27-25 UF39		
U 27-26 C01P		U 24 1 2317
U 27-27 7PCC		2 2317
U 27-28 high		U 25 3 2317
U 27-29 7PCC		4 2317
U 27-30 329F		U 29 15 249H

Performance Tests and Troubleshooting - Model 64602A

I	17	2317		19	low	I	4	0089
U 30	18	2317		20	4F27	U 57	5	AH9F
	19	2317		21	8531	I	6	3UC6
	20	2317		22	high	U 58	7	F7U9
	21	2317					8	low
	22	2317	U 37	1	75H2		9	2317
	23	2317	I	2	U9C4		10	753A
	24	2317	U 38	3	49HC		11	2317
	37	2317	I	4	0089		12	753A
	38	2317	U 53	5	AH9F		13	2317
	39	2317	I	6	3UC6		14	753A
	40	2317	U 54	7	F7U9		15	2317
				8	low		16	753A
U 33	1	75H2		9	2317		17	high
I	2	U9C4		10	753A		18	U5HP
U 34	3	49HC		11	2317		19	low
I	4	0089		12	753A		20	4F27
U 49	5	AH9F		13	2317		21	8531
I	6	3UC6		14	753A		22	high
U 50	7	F7U9		15	2317			
	8	low		16	753A	U 43	1	75H2
	9	2317		17	high	I	2	U9C4
	10	753A		18	PP9H	U 44	3	49HC
	11	2317		19	low	I	4	0089
	12	753A		20	4F27	U 59	5	AH9F
	13	2317		21	8531	I	6	3UC6
	14	753A		22	high	U 60	7	F7U9
	15	2317					8	low
	16	753A	U 39	1	75H2		9	2317
	17	high	I	2	U9C4		10	753A
	18	F82U	U 40	3	49HC		11	2317
	19	low	I	4	0089		12	753A
	20	4F27	U 55	5	AH9F		13	2317
	21	8531	I	6	3UC6		14	753A
	22	high	U 56	7	F7U9		15	2317
				8	low		16	753A
				9	2317		17	high
U 35	1	75H2		10	753A		18	64AP
I	2	U9C4		11	2317		19	low
U 36	3	49HC		12	753A		20	4F27
I	4	0089		13	2317		21	8531
U 51	5	AH9F		14	753A		22	high
I	6	3UC6		15	2317			
U 52	7	F7U9		16	753A	U 45	1	75H2
	8	low		17	high	I	2	U9C4
	9	2317		18	C06F	U 46	3	49HC
	10	753A		19	low	I	4	0089
	11	2317		20	4F27	U 61	5	AH9F
	12	753A		21	8531	I	6	3UC6
	13	2317		22	high	U 62	7	F7U9
	14	753A					8	low
	15	2317					9	2317
	16	753A	U 41	1	75H2		10	753A
	17	high	I	2	U9C4		11	2317
	18	9H37	U 42	3	49HC			

Performance Tests and Troubleshooting - Model 64602A

12	753A	U 66- 6	F7U9	U 69-15	14A2
13	2317	U 66- 7	6538	U 70- 1	low
14	753A	U 66- 9	6538	U 70- 4	6538
15	2317	U 66-10	14A2	U 70- 5	5694
16	753A	U 66-11	F7U9	U 70- 6	4F27
17	high	U 66-12	3UC6	U 70- 7	5694
18	4704	U 66-13	AH9F	U 70- 8	68CA
19	low	U 66-14	8531	U 70- 9	5694
20	4F27	U 66-15	0000	U 70-11	high
21	8531	U 67- 1	low	U 70-12	68CA
22	high	U 67- 2	4FAP	U 70-13	4F7P
		U 67- 3	8531	U 70-14	0000
U 47	1	U 67- 4	05UF	U 70-15	low
I	2	U 67- 5	AH9F	U 70-16	6538
U 48	3	U 67- 6	C593	U 70-19	high
I	4	U 67- 7	3UC6	U 72- 1	high
U 63	5	U 67- 8	39U5	U 72- 2	4F27
I	6	U 67- 9	F7U9	U 72- 3	291U
U 64	7	U 67-11	8CHP	U 72- 4	6538
	8	U 67-12	75H2	U 72- 5	high
	9	U 67-13	7391	U 72- 6	high
	10	U 67-14	U9C4	U 72- 7	291U
	11	U 67-15	P1CC	U 72- 9	high
	12	U 67-16	49HC	U 72-10	high
	13	U 67-17	F916	U 72-11	high
	14	U 67-18	0089	U 72-12	high
	15	U 67-19	low	U 72-13	291U
	16	U 68- 1	4F27	U 72-14	4F27
	17	U 68- 2	0000	U 72-15	4F27
	18	U 68- 3	0089	(TOTLZ=0125)	
	19	U 68- 4	49HC	U 73- 1	low
	20	U 68- 5	U9C4	U 73- 2	high
	21	U 68- 6	75H2	U 73- 3	4F27
	22	U 68- 7	6538	U 73- 4	6538
		U 68- 9	6538	U 73- 5	4F27
U 65- 1	4F27	U 68-10	high	U 73- 6	291U
U 65- 2	0000	U 68-11	75H2	U 73- 8	high
U 65- 3	8531	U 68-12	U9C4	U 73- 9	4F27
U 65- 4	AH9F	U 68-13	49HC	U 73-10	low
U 65- 5	3UC6	U 68-14	0089	U 73-11	4F27
U 65- 6	F7U9	U 68-15	14A2	(TOTLZ=0207)	
U 65- 7	6538	U 69- 1	4F27	U 73-12	6538
U 65- 9	6538	U 69- 2	0000	U 74- 1	68CA
U 65-10	14A2	U 69- 3	0089	U 74- 2	730U
U 65-11	F7U9	U 69- 4	49HC	U 74- 3	373A
U 65-12	3UC6	U 69- 5	U9C4	U 74- 4	288P
U 65-13	AH9F	U 69- 6	75H2	U 74- 5	6538
U 65-14	8531	U 69- 7	6538	U 74- 6	4HC6
U 65-15	low	U 69- 9	6538	U 74- 7	F82U
U 66- 1	4F27	U 69-10	high	U 74- 9	PP9H
U 66- 2	0000	U 69-11	75H2	U 74-10	U5HP
U 66- 3	8531	U 69-12	U9C4	U 74-11	4704
U 66- 4	AH9F	U 69-13	49HC	U 74-12	902C
U 66- 5	3UC6	U 69-14	0089	U 74-13	64AP

Performance Tests and Troubleshooting - Model 64602A

U 74-14	C06F	U 82-11	373A
U 74-15	9H37	U 82-12	high
U 75- 1	288P	U 82-13	5694
U 75- 2	4F27	U 82-14	high
U 75- 3	288P	U 82-15	high
U 79- 1	high	U 83- 1	0191
U 79- 2	8531	U 83- 2	753A
U 79- 3	5694	U 83- 3	5694
U 79- 4	AH9F	U 83- 4	753A
U 79- 5	373A	U 83- 5	5694
U 79- 6	3UC6	U 83- 6	753A
U 79- 7	730U	U 83- 7	373A
U 79- 8	F7U9	U 83- 8	753A
U 79- 9	68CA	U 83- 9	68CA
U 79-11	0089	U 83-11	753A
U 79-12	33AF	U 83-12	5694
U 79-13	49HC	U 83-13	753A
U 79-14	5694	U 83-14	5694
U 79-15	U9C4	U 83-15	753A
U 79-16	5694	U 83-16	5694
U 79-17	964F	U 83-17	753A
U 79-18	5694	U 83-18	5694
U 79-19	high	U 83-19	0191
U 80- 1	0191		
U 80- 2	753A		
U 80- 3	5694		
U 80- 4	753A		
U 80- 5	5694		
U 80- 6	753A		
U 80- 7	5694		
U 80- 8	753A		
U 80- 9	33AF		
U 80-11	753A		
U 80-12	730U		
U 80-13	753A		
U 80-14	5694		
U 80-15	753A		
U 80-16	5694		
U 80-17	753A		
U 80-18	33AF		
U 80-19	0191		
U 81- 2	4HC6		
U 81- 3	0191		
U 81- 8	249H		
U 81- 9	68CA		
U 82- 1	high		
U 82- 2	0089		
U 82- 3	5694		
U 82- 4	high		
U 82- 5	5694		
U 82- 6	low		
U 82- 7	5694		
U 82- 9	5694		
U 82-10	low		

NOTES

SECTION V
ADJUSTMENTS

5-1. INTRODUCTION.

5-2. This section describes adjustments and checks required to return the instrument to peak operating capability after repairs have been made.

5-3. SAFETY REQUIREMENTS.

5-4. Although this instrument has been designed in accordance with international safety standards, general safety precautions must be observed during all phases of operation, service, and repair of the instrument. Failure to comply with precautions listed in the Safety Summary at the front of this manual or with specific warnings given throughout the manual could result in serious injury or death or damage to equipment. Service adjustments should be performed only by qualified service personnel.

5-5. EQUIPMENT REQUIRED.

- 5-6. a. Digital voltmeter with at least four-place accuracy, such as the HP 3466A DVM, or equivalent.
- b. Nonconductive alignment tool.
- c. Shorting clip lead.

5-7. DESCRIPTION.

5-8. The 64602A timing acquisition board has only three adjustments, one for DAC negative full-scale, and two for DAC positive full-scale.

5-9. PV tests 1 and 2 are used to make the DAC adjustments.

Adjustments - Model 64602A

5-10. KEYBOARD SETUP.

5-11. Use the following steps to access the 64602A Acquisition Board PV tests, which are used to make the DAC adjustments:

- a. With the operating system initialized and awaiting a command, press the softkey labeled "opt_test" (you may have to keep pressing the "etc" softkey until you see "opt_test" on the screen).
- b. Press [RETURN]. You should see a listing of all the optional boards that are present in your mainframe, along with their slot numbers.
- c. Type in the Timing Acquisition Board slot number.
- d. Press [RETURN].
- e. Press softkey "run".
- f. Press softkey "slot".
- g. Type in the Timing Acquisition Board slot number.
- h. Press softkey "test". The screen will now list all the Timing Acquisition Board PV tests.
- i. Type in the number of the test you wish to run. (For the acquisition board adjustments, use tests 1 and 2).
- j. Press [RETURN].

5-12. DACS NEGATIVE FULL-SCALE ADJUSTMENT.

- 5-13.
- a. Disconnect the timing probe from the acquisition board before making this adjustment.
 - b. If it has not already been done, press softkey "opt_test", [RETURN], and then the following softkeys in sequence: "run slot (type in acq. bd. slot) test 1".
 - c. Press [RETURN]
 - d. Connect the ground lead of the DVM to the GND test point located on the upper middle part of the board.
 - e. Short TP1 to TP2 with the clip lead.
 - f. Connect the V-ohms lead of the DVM to TP1.
 - g. Adjust -FS (R2) for $-2.133\text{V} \pm 0.5\text{mV}$ at TP1.
 - h. Remove the clip lead shorting TP1 to TP2.
 - i. Check that TP1 and TP2 are within 4.0mv of each other; if they are they are not, suspect U77 (op-amp) within the DAC circuitry.




Figure 5-1. Adjustments

5-14. DACS POSITIVE FULL-SCALE ADJUSTMENT.

- 5-15. a. Disconnect the timing probe from the acquisition board before making this adjustment.
- b. If it has not already been done, press softkey "opt_test", [RETURN], and then the following softkeys in sequence: "run slot (type in acq. bd. slot) test 2".
- c. Press [RETURN].
- d. Connect the ground lead of the DVM to the GND testpoint located on located on the upper middle part of the board.
- e. Connect the V-ohms lead of the DVM to TP1.
- f. Adjust +FS1 (R1) for +2.117V +/- 0.5mV at TP1.
- g. Connect the V-ohms lead of the DVM to TP2.
- h. Adjust +FS2 (R3) for +2.117V +/- 0.5mV at TP2.

NOTES

SECTION VI

REPLACEABLE PARTS

6-1. INTRODUCTION.

6-2. This section contains information for ordering parts. Table 6-1 lists abbreviations used in the parts list and throughout the manual. Table 6-2 lists all replaceable parts in reference designator order. Table 6-3 contains the names and addresses that correspond to the manufacturers' five-digit code numbers.

6-3. ABBREVIATIONS.

6-4. Table 6-1 lists abbreviations used in the parts list, the schematics and throughout the manual. In some cases, two forms of the abbreviation are used: one all in capital letters, and one partial or no capitals. This occurs because the abbreviations in the parts list are always capitals. However, in the schematics and other parts of the manual, other abbreviation forms are used with both lower-case and upper-case letters.

6-5. REPLACEABLE PARTS LIST.

6-6. Table 6-2 is the list of replaceable parts and is organized as follows:

- a. Chassis-mounted parts are in alphanumerical order by reference designation.
- b. Electrical assemblies and their components in alphanumerical order by reference designation.
- c. Miscellaneous parts.

The information given for each part consists of the following:

- a. The Hewlett-Packard part number and the check digit.
- b. The total quantity (Qty) in the instrument.
- c. The description of the part.
- d. A five-digit code that indicates the manufacturer.
- e. The manufacturer's part number.

The total quantity for each part is given only once, at the first appearance of the part number in the list.

Replaceable Parts - Model 64602A

6-7. ORDERING INFORMATION.

6-8. To order a part listed in the replaceable parts table, quote the Hewlett-Packard part number and check digit, indicate the quantity required, and address the order to the nearest Hewlett-Packard office.

6-9. To order a part that is not listed in the replaceable parts table, include the instrument model number, instrument repair number, the description and function of the part, and the number of parts required. Address the order to the nearest Hewlett-Packard office.

6-10. SPARE PARTS KIT.

6-11. A service kit is available. To order, please contact your local sales and service representative.

6-12. DIRECT MAIL ORDER SYSTEM.

6-13. Within the USA, Hewlett-Packard can supply parts through a direct mail order system. Advantages of using the system are as follows:

- a. Direct ordering and shipment from the HP Parts Center in Mountain View, California.
- b. No maximum or minimum on any mail order (there is a minimum order amount, for parts ordered through a local HP office when the orders require billing and invoicing).
- c. Prepaid transportation (there is a small handling charge for each order).
- d. No invoices - to provide these advantages, a check or money order must accompany each order.

6-14. Mail-order forms and specific ordering information are available through your local HP office. Addresses and phone numbers are located at the back of this manual.

Table 6-1. Reference Designators and Abbreviations

REFERENCE DESIGNATORS							
A	assembly	F	fuse	MP	mechanical part	U	integrated circuit
B	motor	FL	filter	P	plug	V	vacuum tube neon bulb, photocell, etc
BT	battery	IC	integrated circuit	Q	transistor	VR	voltage regulator
C	capacitor	J	jack	R	resistor	W	wire
CP	coupler	K	relay	RT	thermistor	X	socket
CR	diode	L	inductor	S	switch	Y	crystal
DL	delay line	LS	loud speaker	T	transformer	Z	tuned cavity network
DS	device signaling (lamp)	M	meter	TB	terminal board		
E	misc electronic part	MK	microphone	TP	test point		
ABBREVIATIONS							
A	amperes	H	henries	N/O	normally open	RMO	rack mount only
AFC	automatic frequency control	HDW	hardware	NOM	nominal	RMS	root-mean square
AMPL	amplifier	HEX	hexagonal	NPO	negative positive zero (zero temperature coefficient)	RWV	reverse working voltage
BFO	beat frequency oscillator	HG	mercury	NPN	negative positive-negative	S-B	slow-blow screw
BE CU	beryllium copper	HR	hours ¹	NRFR	not recommended for field replacement	SE	selenium
BH	binder head	HZ	hertz	NSR	not separately replaceable	SECT	sections
BP	bandpass	IF	intermediate freq	OB	order by description	SEMICON	semiconductor
BRS	brass	IMPG	impregnated	OH	oval head	SI	silicon
BWO	backward wave oscillator	INCD	incandescent	OX	oxide	SIL	silver
CCW	counter-clockwise	INCL	includes ¹			SL	slide
CER	ceramic	INS	insulation (ed) ¹			SPG	spring
CMO	cabinet mount only	INT	internal			SPL	special
COEF	coefficient	K	kilo 1000			SST	stainless steel
COM	common	LH	left hand	P	peak	SR	split ring
COMP	composition	LIN	linear taper	PC	printed circuit	STL	steel
COMPL	complete	LK WASH	lock washer	PF	picofarads 10 ⁻¹² farads	TA	tantalum
CONN	connector	LOG	logarithmic taper	PH BRZ	phosphor bronze	TD	time delay
CP	cadmium plate	LPF	low pass filter	PHL	phillips	TGL	toggle
CRT	cathode-ray tube	M	milli 10 ⁻³	PIV	peak inverse voltage	THD	thread
CW	clockwise	MEG	meg 10 ⁶	PNP	positive-negative-positive	TI	titanium
DEPC	deposited carbon	MET FLM	metal film	P/O	part of	TOL	tolerance
DR	drive	MET OX	metallic oxide	POLY	polystyrene	TRIM	trimmer
ELECT	electrolytic	MFR	manufacturer	PORC	porcelain	TWT	traveling wave tube
ENCAP	encapsulated	MHZ	mega hertz	POS	position(s)	U	micro 10 ⁻⁶
EXT	external	MINAT	miniature	POT	potentiometer	VAR	variable
F	farads	MOM	momentary	POT	peak-to-peak	VDCW	dc working volts
FH	flat head	MOS	metal oxide substrate	PP	point	W/	with
FIL H	fillister head	MTG	mounting	PT	point	W	watts
FXD	fixed	MY	"mylar"	PWV	peak working voltage	WIV	working inverse voltage
G	giga 10 ⁹	N	nano 10 ⁻⁹	RECT	rectifier	WW	wirewound
GE	germanium	N/C	normally closed	RF	radio frequency	W/O	without
GL	glass	NE	neon	RH	round head or		
GRD	grounded ¹	NI PL	nickel plate		right hand		

Replaceable Parts - Model 64602A

Table 6-2. Replaceable Parts List

Reference Designation	HP Part Number	C D	Qty	Description	Mfr Code	Mfr Part Number
	64602A	0		TIMING ANALYSIS ACQUISITION BOARD	28480	64602A
A1	64602-66503	2		200 MHZ TIMING ANALYSIS BOARD	28480	64602-66503
A1C1	0160-4385	2	1	CAPACITOR-FXD 15PF +-5% 200VDC CER 0+-30	28480	0160-4385
A1C2	0160-4383	0	1	CAPACITOR-FXD 6.8PF +- .5PF 200VDC CER	20932	5024E0200RD689D
A1C3	0160-3879	7	47	CAPACITOR-FXD .01UF +-20% 100VDC CER	28480	0160-3879
A1C4	0160-3879	7		CAPACITOR-FXD .01UF +-20% 100VDC CER	28480	0160-3879
A1C5	0160-3443	1	5	CAPACITOR-FXD .1UF +80-20% 50VDC CER	28480	0160-3443
A1C6	0160-3443	1		CAPACITOR-FXD .1UF +80-20% 50VDC CER	28480	0160-3443
A1C7	0140-0151	0	3	CAPACITOR-FXD 820PF +-2% 300VDC MICA	72136	DM15F821G0300WV1CR
A1C8	0160-3879	7		CAPACITOR-FXD .01UF +-20% 100VDC CER	28480	0160-3879
A1C9	0160-3879	7		CAPACITOR-FXD .01UF +-20% 100VDC CER	28480	0160-3879
A1C10	0160-3879	7		CAPACITOR-FXD .01UF +-20% 100VDC CER	28480	0160-3879
A1C11	0160-3879	7		CAPACITOR-FXD .01UF +-20% 100VDC CER	28480	0160-3879
A1C12	0140-0151	0		CAPACITOR-FXD 820PF +-2% 300VDC MICA	72136	DM15F821G0300WV1CR
A1C13	0160-3879	7		CAPACITOR-FXD .01UF +-20% 100VDC CER	28480	0160-3879
A1C14	0160-3879	7		CAPACITOR-FXD .01UF +-20% 100VDC CER	28480	0160-3879
A1C15	0160-3879	7		CAPACITOR-FXD .01UF +-20% 100VDC CER	28480	0160-3879
A1C16	0160-3443	1		CAPACITOR-FXD .1UF +80-20% 50VDC CER	28480	0160-3443
A1C17	0140-0151	0		CAPACITOR-FXD 820PF +-2% 300VDC MICA	72136	DM15F821G0300WV1CR
A1C18	0160-3879	7		CAPACITOR-FXD .01UF +-20% 100VDC CER	28480	0160-3879
A1C19	0160-3879	7		CAPACITOR-FXD .01UF +-20% 100VDC CER	28480	0160-3879
A1C20	0160-3879	7		CAPACITOR-FXD .01UF +-20% 100VDC CER	28480	0160-3879
A1C21	0160-3879	7		CAPACITOR-FXD .01UF +-20% 100VDC CER	28480	0160-3879
A1C22	0160-3879	7		CAPACITOR-FXD .01UF +-20% 100VDC CER	28480	0160-3879
A1C23	0160-3879	7		CAPACITOR-FXD .01UF +-20% 100VDC CER	28480	0160-3879
A1C24	0160-3879	7		CAPACITOR-FXD .01UF +-20% 100VDC CER	28480	0160-3879
A1C25	0160-3879	7		CAPACITOR-FXD .01UF +-20% 100VDC CER	28480	0160-3879
A1C26	0180-2255	3	2	CAPACITOR-FXD 2.2UF+-20% 20VDC TA	28480	0180-2255
A1C27	0160-3879	7		CAPACITOR-FXD .01UF +-20% 100VDC CER	28480	0160-3879
A1C28	0160-3879	7		CAPACITOR-FXD .01UF +-20% 100VDC CER	28480	0160-3879
A1C29	0160-3879	7		CAPACITOR-FXD .01UF +-20% 100VDC CER	28480	0160-3879
A1C30	0160-3879	7		CAPACITOR-FXD .01UF +-20% 100VDC CER	28480	0160-3879
A1C31	0160-3879	7		CAPACITOR-FXD .01UF +-20% 100VDC CER	28480	0160-3879
A1C32	0160-3879	7		CAPACITOR-FXD .01UF +-20% 100VDC CER	28480	0160-3879
A1C33	0160-3879	7		CAPACITOR-FXD .01UF +-20% 100VDC CER	28480	0160-3879
A1C34	0160-3879	7		CAPACITOR-FXD .01UF +-20% 100VDC CER	28480	0160-3879
A1C35	0160-3879	7		CAPACITOR-FXD .01UF +-20% 100VDC CER	28480	0160-3879
A1C36	0180-2255	3		CAPACITOR-FXD 2.2UF+-20% 20VDC TA	28480	0180-2255
A1C37	0160-3879	7		CAPACITOR-FXD .01UF +-20% 100VDC CER	28480	0160-3879
A1C38	0160-3879	7		CAPACITOR-FXD .01UF +-20% 100VDC CER	28480	0160-3879
A1C39	0160-3879	7		CAPACITOR-FXD .01UF +-20% 100VDC CER	28480	0160-3879
A1C40	0160-3879	7		CAPACITOR-FXD .01UF +-20% 100VDC CER	28480	0160-3879
A1C41	0160-3879	7		CAPACITOR-FXD .01UF +-20% 100VDC CER	28480	0160-3879
A1C42	0160-3879	7		CAPACITOR-FXD .01UF +-20% 100VDC CER	28480	0160-3879
A1C43	0160-3879	7		CAPACITOR-FXD .01UF +-20% 100VDC CER	28480	0160-3879
A1C44	0160-3879	7		CAPACITOR-FXD .01UF +-20% 100VDC CER	28480	0160-3879
A1C45	0160-3879	7		CAPACITOR-FXD .01UF +-20% 100VDC CER	28480	0160-3879
A1C46	0160-3879	7		CAPACITOR-FXD .01UF +-20% 100VDC CER	28480	0160-3879
A1C47	0160-3879	7		CAPACITOR-FXD .01UF +-20% 100VDC CER	28480	0160-3879
A1C48	0160-3879	7		CAPACITOR-FXD .01UF +-20% 100VDC CER	28480	0160-3879
A1C49	0160-3879	7		CAPACITOR-FXD .01UF +-20% 100VDC CER	28480	0160-3879
A1C50	0160-3879	7		CAPACITOR-FXD .01UF +-20% 100VDC CER	28480	0160-3879
A1C51	0160-5338	7	1	CAPACITOR-FXD .33UF +-10% 50VDC CER	28480	0160-5338
A1C52	0160-2306	3	2	CAPACITOR-FXD 27PF +-5% 300VDC MICA	28480	0160-2306
A1C53	0160-3443	1		CAPACITOR-FXD .1UF +80-20% 50VDC CER	28480	0160-3443
A1C54	0160-2306	3		CAPACITOR-FXD 27PF +-5% 300VDC MICA	28480	0160-2306
A1C55	0160-3443	1		CAPACITOR-FXD .1UF +80-20% 50VDC CER	28480	0160-3443
A1C56	0160-3879	7		CAPACITOR-FXD .01UF +-20% 100VDC CER	28480	0160-3879
A1C57	0180-1746	5	5	CAPACITOR-FXD 15UF+-10% 20VDC TA	56289	150D156X9020B2
A1C58	0180-1746	5		CAPACITOR-FXD 15UF+-10% 20VDC TA	56289	150D156X9020B2
A1C59	0160-3879	7		CAPACITOR-FXD .01UF +-20% 100VDC CER	28480	0160-3879
A1C60	0160-3879	7		CAPACITOR-FXD .01UF +-20% 100VDC CER	28480	0160-3879
A1C61	0180-1746	5		CAPACITOR-FXD 15UF+-10% 20VDC TA	56289	150D156X9020B2
A1C62	0180-1746	5		CAPACITOR-FXD 15UF+-10% 20VDC TA	56289	150D156X9020B2
A1C63	0160-3879	7		CAPACITOR-FXD .01UF +-20% 100VDC CER	28480	0160-3879
A1C65	0160-3879	7		CAPACITOR-FXD .01UF +-20% 100VDC CER	28480	0160-3879
A1C66	0160-3879	7		CAPACITOR-FXD .01UF +-20% 100VDC CER	28480	0160-3879
A1C67	0160-3879	7		CAPACITOR-FXD .01UF +-20% 100VDC CER	28480	0160-3879
A1C68	0180-1746	5		CAPACITOR-FXD 15UF+-10% 20VDC TA	56289	150D156X9020B2
A1C69	0160-4492	5	2	CAPACITOR-FXD 18PF +-5% 200VDC CER	51642	200-200-NPO-180J
A1C70	0160-4492	5		CAPACITOR-FXD 18PF +-5% 200VDC CER	51642	200-200-NPO-180J

See introduction to this section for ordering information
 *Indicates factory selected value

Table 6-2. Replaceable Parts List (Con't)

Reference Designation	HP Part Number	C D	Qty	Description	Mfr Code	Mfr Part Number
A1CR1	1901-0040	1	2	DIODE-SWITCHING 30V 50MA 2NS DO-35	28480	1901-0040
A1CR2	1901-0040	1		DIODE-SWITCHING 30V 50MA 2NS DO-35	28480	1901-0040
A1CR3	1901-0535	9	2	DIODE-SM SIG SCHOTTKY	28480	1901-0535
A1CR4	1901-0535	9		DIODE-SM SIG SCHOTTKY	28480	1901-0535
A1J3	1250-1189	0	1	CONNECTOR-RF SMB FEM PC 50-OHM	28480	1250-1189
A1J4	1250-0543	8	1	CONNECTOR-RF SM-SNP M PC 50-OHM	28480	1250-0543
A1MP1	0520-0133	4	2	SCREW-MACH 2-56 .5-IN-LG PAN-HD-POZI	00000	ORDER BY DESCRIPTION
A1MP2	1205-0461	4	1	HEAT SINK	28480	1205-0461
A1MP3	1480-0116	8	2	PIN-GRV .062-IN-DIA .25-IN-LG STL	28480	1480-0116
A1MP4	2190-0014	1	2	WASHER-LK INTL T NO. 2 .089-IN-ID	28480	2190-0014
A1MP5	4320-0095	7		U CHANNEL NPRN .047-WD-CHAN .219-WD.	28480	4320-0095
A1MP6	64602-21102	5	1	HEAT SINK-COVER	28480	64602-21102
A1MP7	64602-85001	7	1	BOARD EJECTOR	28480	64602-85001
A1MP8	64602-85002	8	1	BOARD EJECTOR	28480	64602-85002
A1R1	2100-3351	6	2	RESISTOR-TRMR 500 10% C SIDE-ADJ 1-TRN	28480	2100-3351
A1R2	2100-3349	2	1	RESISTOR-TRMR 100 10% C SIDE-ADJ 1-TRN	28480	2100-3349
A1R3	2100-3351	6		RESISTOR-TRMR 500 10% C SIDE-ADJ 1-TRN	28480	2100-3351
A1R4	0757-0402	1	3	RESISTOR 110 1% .125W F TC=0+-100	24546	C4-1/8-T0-111-F
A1R5	0757-0442	9	2	RESISTOR 10K 1% .125W F TC=0+-100	24546	C4-1/8-T0-1002-F
A1R6	0757-0280	3	9	RESISTOR 1K 1% .125W F TC=0+-100	24546	C4-1/8-T0-1001-F
A1R7	0757-0280	3		RESISTOR 1K 1% .125W F TC=0+-100	24546	C4-1/8-T0-1001-F
A1R8	0757-0405	4	1	RESISTOR 162 1% .125W F TC=0+-100	24546	C4-1/8-T0-162R-F
A1R9	0698-3132	4	1	RESISTOR 261 1% .125W F TC=0+-100	24546	C4-1/8-T0-2610-F
A1R10	0757-0280	3		RESISTOR 1K 1% .125W F TC=0+-100	24546	C4-1/8-T0-1001-F
A1R11	0757-0280	3		RESISTOR 1K 1% .125W F TC=0+-100	24546	C4-1/8-T0-1001-F
A1R12	0757-0401	0	1	RESISTOR 100 1% .125W F TC=0+-100	24546	C4-1/8-T0-101-F
A1R13	0698-3242	7	1	RESISTOR 357 1% .125W F TC=0+-100	24546	C4-1/8-T0-357R-F
A1R14	0757-0412	3	3	RESISTOR 365 1% .125W F TC=0+-100	24546	C4-1/8-T0-365R-F
A1R15	0757-0402	1		RESISTOR 110 1% .125W F TC=0+-100	24546	C4-1/8-T0-111-F
A1R16	0757-0402	1		RESISTOR 110 1% .125W F TC=0+-100	24546	C4-1/8-T0-111-F
A1R17	0698-0082	7	2	RESISTOR 464 1% .125W F TC=0+-100	24546	C4-1/8-T0-4640-F
A1R18	0757-0412	3		RESISTOR 365 1% .125W F TC=0+-100	24546	C4-1/8-T0-365R-F
A1R19	0698-0082	7		RESISTOR 464 1% .125W F TC=0+-100	24546	C4-1/8-T0-4640-F
A1R20	0757-0412	3		RESISTOR 365 1% .125W F TC=0+-100	24546	C4-1/8-T0-365R-F
A1R21	0757-0280	3		RESISTOR 1K 1% .125W F TC=0+-100	24546	C4-1/8-T0-1001-F
A1R22	0757-0280	3		RESISTOR 1K 1% .125W F TC=0+-100	24546	C4-1/8-T0-1001-F
A1R23	0698-8607	8	2	RESISTOR 4.5K .1% .125W F TC=0+-25	28480	0698-8607
A1R24	0698-6599	3	2	RESISTOR 4.64K 1% .125W F TC=0+-25	28480	0698-6599
A1R25	0757-0280	3		RESISTOR 1K 1% .125W F TC=0+-100	24546	C4-1/8-T0-1001-F
A1R26	0698-4468	1	1	RESISTOR 1.13K 1% .125W F TC=0+-100	24546	C4-1/8-T0-1131-F
A1R27	0698-6582	4	2	RESISTOR 2.222K .1% .125W F TC=0+-50	28480	0698-6582
A1R28	0698-6582	4		RESISTOR 2.222K .1% .125W F TC=0+-50	28480	0698-6582
A1R29	0698-4414	7	2	RESISTOR 158 1% .125W F TC=0+-100	24546	C4-1/8-T0-158R-F
A1R30	0698-6612	1	2	RESISTOR 2K .1% .125W F TC=0+-50	28480	0698-6612
A1R31	0698-4414	7		RESISTOR 158 1% .125W F TC=0+-100	24546	C4-1/8-T0-158R-F
A1R32	0698-6612	1		RESISTOR 2K .1% .125W F TC=0+-50	28480	0698-6612
A1R33	0698-6599	3		RESISTOR 4.64K 1% .125W F TC=0+-25	28480	0698-6599
A1R34	0698-8607	8		RESISTOR 4.5K .1% .125W F TC=0+-25	28480	0698-8607
A1R35	0757-0280	3		RESISTOR 1K 1% .125W F TC=0+-100	24546	C4-1/8-T0-1001-F
A1R38	0757-0280	3		RESISTOR 1K 1% .125W F TC=0+-100	24546	C4-1/8-T0-1001-F
A1R39	0757-0442	9		RESISTOR 10K 1% .125W F TC=0+-100	24546	C4-1/8-T0-1002-F
A1TP1	0360-0535	0	5	TERMINAL TEST POINT PCB	00000	ORDER BY DESCRIPTION
A1TP2	0360-0535	0		TERMINAL TEST POINT PCB	00000	ORDER BY DESCRIPTION
A1TP3	0360-0535	0		TERMINAL TEST POINT PCB	00000	ORDER BY DESCRIPTION
A1TP4	0360-0535	0		TERMINAL TEST POINT PCB	00000	ORDER BY DESCRIPTION
A1TP5	0360-0535	0		TERMINAL TEST POINT PCB	00000	ORDER BY DESCRIPTION
A1U1	1810-0302	5	1	NETWORK-RES 8-SIP47.0 OHM X 4	01121	208B470
A1U2	1810-0538	9	4	NETWORK-RES 9-SIP MULTI-VALUE	28480	1810-0538
A1U3	1810-0271	7	3	NETWORK-RES 10-SIP200.0 OHM X 9	01121	210A201
A1U4	1820-1212	9	1	IC FF TTL LS J-K NEG-EDGE-TRIG	01295	SN74LS122AN
A1U5	1820-1052	5	2	IC XLTR ECL ECL-TO-TTL QUAD 2-INP	04713	MC10125L
A1U6	1820-1400	7	1	IC GATE ECL AND QUAD 2-INP	04713	MC10104P
A1U7	1820-0920	4	1	IC RCVR ECL LINE RCVR QUAD 2-INP	04713	MC1692L
A1U8	1810-0539	0	1	DELAY LINE 7 PIN SIP; TOTAL DELAY	28480	1810-0539
A1U9	1820-0796	2	1	IC GATE ECL NOR QUAD 2-INP	04713	MC1662L
A1U10	1820-1320	0	1	IC RCVR ECL LINE RCVR TPL 2-INP	04713	MC10216L
A1U11	1820-1173	1	2	IC XLTR ECL TTL-TO-ECL QUAD 2-INP	04713	MC10124L
A1U12	1820-1173	1		IC XLTR ECL TTL-TO-ECL QUAD 2-INP	04713	MC10124L
A1U13	1826-0544	0	1	V REF 8-DIP-C	04713	MC1403U
A1U14	1820-0810	1	1	IC RCVR ECL LINE RCVR TPL 2-INP	04713	MC10116P
A1U15	1810-0219	3	2	NETWORK-RES 8-SIP220.0 OHM X 4	01121	208B221
A1U16	1820-1052	5		IC XLTR ECL ECL-TO-TTL QUAD 2-INP	04713	MC10125L
A1U17	1820-0793	9	1	IC GATE ECL EXCL-NOR TPL 2-INP	04713	MC1674L
A1U18	1810-0271	7		NETWORK-RES 10-SIP200.0 OHM X 9	01121	210A201
A1U19	1810-0219	3		NETWORK-RES 8-SIP220.0 OHM X 4	01121	208B221
A1U20	1810-0538	9		NETWORK-RES 9-SIP MULTI-VALUE	28480	1810-0538

See introduction to this section for ordering information
 *Indicates factory selected value

Table 6-2. Replaceable Parts List (Con't)

Reference Designation	HP Part Number	C D	Qty	Description	Mfr Code	Mfr Part Number	
A1U21	1810-0271	7	8	NETWORK-RES 10-SIP200.0 OHM X 9	01121	210A201	
A1U22	1NB4-5017	7		IC-ENCODER	28480	1NB4-5017	
A1U23	1NB4-5017	7		IC-ENCODER	28480	1NB4-5017	
A1U24	1NB4-5017	7		IC-ENCODER	28480	1NB4-5017	
A1U25	1NB4-5017	7		IC-ENCODER	28480	1NB4-5017	
A1U26	1810-0538	9	1	NETWORK-RES 9-SIP MULTI-VALUE	28480	1810-0538	
A1U27	1NB4-5007	8		IC-GLITCH DETECTOR	28480	1NB4-5007	
A1U28	1810-0538	9		NETWORK-RES 9-SIP MULTI-VALUE	28480	1810-0538	
A1U29	1NB4-5017	7		IC-ENCODER	28480	1NB4-5017	
A1U30	1NB4-5017	7		IC-ENCODER	28480	1NB4-5017	
A1U31	1NB4-5017	7	7	IC-ENCODER	28480	1NB4-5017	
A1U32	1NB4-5017	7		IC-ENCODER	28480	1NB4-5017	
A1U64	1816-1476	8	32	IC TTL 1024 (1K) STAT RAM 45-NS 3-S	28480	1816-1476	
A1U65	1820-2890	6		4	IC CNTR TTL S BIN SYNCHRO POS-EDGE-TRIG	07263	93516DC
A1U66	1820-2890	6	4	IC CNTR TTL S BIN SYNCHRO POS-EDGE-TRIG	07263	93516DC	
A1U67	1820-1917	1		IC BFR TTL LS LINE DRVR OCTL	01295	SN74LS240N	
A1U68	1820-2890	6		IC CNTR TTL S BIN SYNCHRO POS-EDGE-TRIG	07263	93516DC	
A1U69	1820-2890	6		IC CNTR TTL S BIN SYNCHRO POS-EDGE-TRIG	07263	93516DC	
A1U70	1820-2024	3		1	IC DRVR TTL LS LINE DRVR OCTL	01295	SN74LS244N
A1U71	1820-1282	3	1	IC FF TTL LS J-K BAR POS-EDGE-TRIG	01295	SN74LS109AN	
A1U72	1820-1245	8		1	IC DCDR TTL LS 2-TO-4-LINE DUAL 2-INP	01295	SN74LS155N
A1U73	1820-1144	6		1	IC GATE TTL LS NOR QUAD 2-INP	01295	SN74LS02N
A1U74	1820-2550	0		1	IC DCDR TTL LS 3-TO-8-LINE	01295	SN74LS137N
A1U75	1820-2657	8		1	IC GATE TTL ALS OR QUAD 2-INP	01295	SN74ALS32N
A1U76	1826-0856	7		2	IC CONV B-B-D/A 20-DIP-P PKG	34335	AM6080APC
A1U77	1826-0974	5			1	IC OP AMP GP DUAL 14-DIP-C PKG	07263
A1U78	1826-0856	7		1	IC CONV B-B-D/A 20-DIP-P PKG	34335	AM6080APC
A1U79	1820-1917	1	IC BFR TTL LS LINE DRVR OCTL		01295	SN74LS240N	
A1U80	1820-1917	1	IC BFR TTL LS LINE DRVR OCTL		01295	SN74LS240N	
A1U81	1820-2656	7	1		IC GATE TTL ALS NAND QUAD 2-INP	01295	SN74ALS00N
A1U82	1820-1492	7	1	IC BFR TTL LS INV HEX 1-INP	01295	SN74LS368AN	
A1U83	1820-1917	1		IC BFR TTL LS LINE DRVR OCTL	01295	SN74LS240N	
A1XU22	1200-0654	7	8	SOCKET-IC 40-CONT DIP DIP-SLDR	28480	1200-0654	
A1XU23	1200-0654	7		SOCKET-IC 40-CONT DIP DIP-SLDR	28480	1200-0654	
A1XU24	1200-0654	7		SOCKET-IC 40-CONT DIP DIP-SLDR	28480	1200-0654	
A1XU25	1200-0654	7		SOCKET-IC 40-CONT DIP DIP-SLDR	28480	1200-0654	
A1XU27A	1200-0963	1		2	PIN-SOCKET-20	28480	1200-0963
A1XU27B	1200-0963	1	PIN-SOCKET-20		28480	1200-0963	
A1XU29	1200-0654	7	7	SOCKET-IC 40-CONT DIP DIP-SLDR	28480	1200-0654	
A1XU30	1200-0654	7		SOCKET-IC 40-CONT DIP DIP-SLDR	28480	1200-0654	
A1XU31	1200-0654	7		SOCKET-IC 40-CONT DIP DIP-SLDR	28480	1200-0654	
A1XU32	1200-0654	7		SOCKET-IC 40-CONT DIP DIP-SLDR	28480	1200-0654	
A1XU64	1200-0612	7		32	SOCKET-IC 22-CONT DIP DIP-SLDR	28480	1200-0612
A1XU67	1200-0639	8			7	SOCKET-IC 20-CONT DIP DIP-SLDR	28480
A1XU70	1200-0639	8		3	SOCKET-IC 20-CONT DIP DIP-SLDR	28480	1200-0639
A1XU72	1200-0607	0			SOCKET-IC 16-CONT DIP DIP-SLDR	28480	1200-0607
A1XU74	1200-0607	0	SOCKET-IC 16-CONT DIP DIP-SLDR		28480	1200-0607	
A1XU75	1200-0638	7	2		SOCKET-IC 14-CONT DIP DIP-SLDR	28480	1200-0638
A1XU76	1200-0639	8			SOCKET-IC 20-CONT DIP DIP-SLDR	28480	1200-0639
A1XU78	1200-0639	8	8	SOCKET-IC 20-CONT DIP DIP-SLDR	28480	1200-0639	
A1XU79	1200-0639	8		SOCKET-IC 20-CONT DIP DIP-SLDR	28480	1200-0639	
A1XU80	1200-0639	8		SOCKET-IC 20-CONT DIP DIP-SLDR	28480	1200-0639	
A1XU81	1200-0638	7		SOCKET-IC 14-CONT DIP DIP-SLDR	28480	1200-0638	
A1XU82	1200-0607	0	8	SOCKET-IC 16-CONT DIP DIP-SLDR	28480	1200-0607	
A1XU83	1200-0639	8		SOCKET-IC 20-CONT DIP DIP-SLDR	28480	1200-0639	
W1	64600-61601	1	2	CABLE-RF	28480	64600-61601	
W2	64604-61601	5		1	CABLE-PROBE	28480	64604-61601

See introduction to this section for ordering information
 *Indicates factory selected value

Table 6-3. List of Manufacturers' Codes

Mfr No.	Manufacturer Name	Address	Zip Code
50167	FUJITSU LTD	TOKYO	
54013	HITACHI	TOKYO	
00000	ANY SATISFACTORY SUPPLIER		
01121	ALLEN-BRADLEY CO	MILWAUKEE	53204
01295	TEXAS INSTR INC SEMICOND CMPNT DIV	DALLAS	75222
02111	SPECTROL ELECTRONICS CORP	CITY OF IND	91745
04713	MOTOROLA SEMICONDUCTOR PRODUCTS	PHOENIX	85008
07263	FAIRCHILD SEMICONDUCTOR DIV	MOUNTAIN VIEW	94042
11236	CTS OF BERNE INC	BERNE	46711
19701	MEPCO/ELECTRA CORP	MINERAL WELLS	76067
20932	EMCON DIV ITW	SAN DIEGO	92129
24546	CORNING GLASS WORKS (BRADFORD)	BRADFORD	16701
25403	AMPEREX ELEK CORP SEMICON & MC DIV	SLATERSVILLE	02876
27014	NATIONAL SEMICONDUCTOR CORP	SANTA CLARA	95051
27167	CORNING GLASS WORKS (WILMINGTON)	WILMINGTON	28401
28480	HEWLETT-PACKARD CO CORPORATE HQ	PALO ALTO	94304
3L585	RCA CORP SOLID STATE DIV	SOMERVILLE	
34335	ADVANCED MICRO DEVICES INC	SUNNYVALE	94086
52763	STETTNER-TRUSH INC	CAZENOVIA	13035
56289	SPRAGUE ELECTRIC CO	NORTH ADAMS	01247
72136	ELECTRO MOTIVE CORP	FLORENCE	04226
75042	TRW INC PHILADELPHIA DIV	PHILADELPHIA	19108

See introduction to this section for ordering information


NOTES

SECTION VII

MANUAL CHANGES

7-1. This section normally contains information for backdating this manual for models with repair numbers prior to the one shown on the title page. This edition includes information for the first repair number, so there would ordinarily be no backdating material. However some of the earliest customers received a Revision A board, which is somewhat different from the presently shipped Revision B board.

7-2. The Rev A board only, has a small pair of soldered jumpers at the very bottom left-hand corner (when viewing from the component side). Both A and B on these jumpers must be connected to 1, as shown.



7-3. Two 2.2 uF capacitors were changed to .01 uF capacitors. On the REV A component locator, shown below, these were C26 and C36. In comparing this old locator with the present one, you will notice the positions of the capacitors next to the encoders have changed. C26 has become C24 and is connected between +5V and ground. C36 is unconnected. A listing of the .01 uF capacitors next to the encoders (U22-27, U29-32) on the REV A board is given:

C22,23,25,26,28,29,34-36,38-40 are connected from +5V to ground.

C24,27,30,32,37,41 are connected from -3.25V to ground.

C31,33 are connected from -5.2V to ground.

7-4. The capacitor connections on the REV B board are given on Service Sheet 1 of Section 8. Capacitor positions for the REV B board are shown on the component locators in this manual.




Figure 7-1. REV A Component Locator.

SECTION VIII

THEORY AND SCHEMATICS

CAUTION

THE GLITCH (U27) AND ENCODER (U22-25, U29-32) CHIPS ARE VERY SENSITIVE TO STATIC. THEY SHOULD BE LEFT IN CONDUCTIVE FOAM UNTIL INSTALLATION. GROUNDING STRAPS AND A GROUNDED WORK STATION ARE RECOMMENDED WHEN HANDLING THE ICS.

8-1. INTRODUCTION.

8-2. This section contains block diagrams, mnemonic tables, schematics and theory. Some theory is also given with the PV test descriptions in SECTION 4.

8-3. There are four modes of timing analyzer operation: Wide Channel, in which eight channels are sampled at a 200MHz rate and stored as 4096 bits of serial data per channel; 4-Channel Glitch Capture Mode which identifies multiple transitions between clock pulses, with both 4K of data and 4K of glitch information stored per channel; 4-Channel Dual Threshold Mode in which four channels are compared to two thresholds, and 4K is stored for each threshold on each channel; 4-Channel Fast Sample Mode in which four channels are sampled in a time-interleaved fashion for an effective 400MHz sample rate, and 8K of data is stored for each channel.

8-4. PROBE THEORY.

8-5. The probe bus passes data from the system under test to the analyzer via the 64604A timing probe. The probe compares the voltages on inputs 0-3 and 4-7 to a corresponding pair of d.c. thresholds from two D/A converters on the acquisition board. The DACs supply middle thresholds to the probe in the wide sample, glitch, and fast sample modes. In the dual threshold mode the DACs supply both upper and lower thresholds.

8-6. GLITCH CHIP. (Figs. 8-1, 8-8)

8-7. The glitch chip (U27) receives timing data from the probe. The glitch chip contains a 20-bit holding register which is programmed by the mainframe for a specified trigger pattern and mode of operation, as follows:

- Bit 1: Chooses recognition of either pattern, or pattern complement.
- Bit 2: Chooses synchronous triggering, in which the pattern is compared with already sampled data, rather than with the asynchronous incoming data. This is used for glitch triggering, which is by definition synchronous, ie, referenced to sample times.
- Bit 3: Chooses either data sampling from all probes, or, in the glitch mode, from only the four low-order probes (0-3), which are then used for both data and glitch information.
- Bit 4: Don't care.
- Bits 5-20: Each pair of bits defines the trigger condition on a different channel, as follows:

A	B	
0	0	Always trigger, ie, don't care.
0	1	Trigger on a high signal.
1	0	Trigger on a low signal.
1	1	Never trigger, ie, not don't care.

8-8. The glitch chip samples incoming probe data on both edges of the sample clock from the analyzer Control Board. Since both clock edges are used, at the 200MHz maximum sample rate the clock need only be 100MHz. Two pairs of complementary clock signals go into the glitch chip: HE/phi2A, LE/phi2A, HE/phi2B, and LE/phi2B. The "A" clocks differ from each other by 180 degrees, as do the "B" clocks. "A" and "B" clocks are identical except in the Fast Sample Mode, when the "B" clock is delayed by 2.5ns to double the number of sample edges.

8-9. In Fast Sample Mode the control bit to the probe is set, as in dual threshold mode, to doubly compare channels 0-3; but now both threshold voltages are set to the same value. This produces two outputs per channel; and with four separate clock sampling times instead of two, the sample rate is effectively 400MHz.

8-10. In Dual Threshold Mode a control bit to the probe connects the Ch. 0-3 inputs to two comparators. Each of the four inputs is compared to two thresholds from the acquisition board D/A converters. The lower threshold comparisons come into the glitch chip on channels 0-3, and the upper ones on channels 4-7. Software unscrambles the four pairs of data streams into a 3-level signal on four channels--high, middle, and low.

8-11. In Glitch Mode the glitch chip ignores data on channels 4-7 but performs normal sampling plus glitch capture on channels 0-3. Glitches are detected by looking for transitions which conflict with sampled data, such as positive-then-negative transitions after the data was found to be low during the previous sample time.





Figure 8-1.
64604A Probe & the "Glitch Chip"
Block Diagram
ACQ 8-3

GLITCH CHIP (continued)

8-12. Since a glitch is by definition a synchronous event--an event bounded by sampling times--triggering on a glitch must be synchronous also. Triggering then occurs only with reference to sample times. When glitches are to be captured only, and not used for triggering, the pattern recognition circuitry is left in its asynchronous mode. Triggering then occurs whenever incoming data conforms to the specified pattern, regardless of whether or not this happens at sample time. The glitch and data information for each of the four channels is processed by the glitch chip as two separate channels would be in the wide channel mode, and the software recombines them into one channel with both glitch and data attributes.

8-13. When the glitch chip finds a match between its pattern and the data on all channels, it will emit an active Low trigger signal, LE/TRIG, for the duration of the match, or until it is reset. XE/TRIG, derived from LE/TRIG, may be programmed High or Low true by the trigger polarity signal, XE/TRIGPOL. A High trigger is used in ANDing a High trigger from another acquisition board; Low triggers are used for ORing. Trigger polarity can also determine whether transition triggering will occur on an "entering" or "leaving" pattern.

8-14. SERIAL-TO-PARALLEL ENCODERS. (Figs. 8-2, 8-8)

8-15. The encoders change the serial stream for each channel from the glitch chip to a pair of 8-bit parallel loads for the RAM.

8-16. Each encoder contains two 8-bit shift registers, which are alternately loaded at the sample clock rate. When a register is full it feeds eight parallel bits to the RAM; then the other register is loaded and unloaded.

8-17. Write pulses for the RAM and clocking pulses for the memory address counters are derived in only one encoder (U22) by dividing the sample clock rate by eight. Thus, acquisition memory need not be especially fast, but can operate at one-sixteenth of 200MHz. The write pulses are out of phase from each other by one-half clock period.

8-18. ACQUISITION RAM. (Figs. 8-3, 8-9)

8-19. Each of the two 8-bit encoder shift registers loads one 256 x 8 RAM (consisting of two 256 x 4 chips) at a time. In each channel, one group of 256 x 8 RAM is designated "X" memory and the other group of 256 x 8 RAM is designated "Y" memory. A single memory channel, therefore, contains 256 times 8 plus 256 times 8 bits, or 4096 bits.

8-20. Memory is eight channels wide and 4K bits deep in the Wide Sample Mode. In the Fast Sample Mode, however, memory is 8K deep and 4 channels wide, since every second channel in the glitch chip is clocked with the delayed phi2B clock in order to get twice as many clock edges, or sample points, in a time period. Every second encoder is also clocked with the phi2B clock.




Figure 8-2.
Serial-to-Parallel Encoders
Block Diagram

8-21. MEMORY ADDRESS COUNTERS (MACs). (Fig. 8-6)

8-22. There are two counters, one for "X" memory bank addresses, and one for the "Y" memory bank. After being set to zero before a run by HE/RESET, the MACs are clocked by write pulses (derived from the sample clock and divided by eight) from one of the encoders. Since they are driven by asymmetrical clocks with a fixed phase relationship, the counters differ at most by one count, with the X counter leading.

8-23. A wrap-around latch (U4) which receives the terminal count and the least significant bit of the Y counter, indicates by H/MEMFUL when the memory has been completely filled with new data at least once.

8-24. The window counter on the analyzer Control Board ends the trace a programmed number of sample clocks after tracepoint. Since the trace is ended by stopping the sample clock, the MACs are also stopped. By reading this end-of-trace address, and the three trigger position bits (H/TCO-2) the mainframe CPU can find where tracepoint occurs in memory.


8-25. The "window" programmed into the control board window counter determines trigger position in memory. The "window" is amount of memory between tracepoint and the end-of-acquisition. For example, in our 4K system, if tracepoint occurs at address 3000 (decimal) and the window counter stops acquisition 10 addresses later, then displayed pre-trigger information will begin at address 3011, continue through 4095, and end at 2999. The window, from tracepoint to the end of trace, will be 10 locations; and displayed pre-trigger memory will consist of 4085 locations. (Actually, only 4060, or 8140, bits are displayed).

8-26. The following steps occur in a acquisition run:

- a. Before an acquisition run, the MACs and encoders are reset.
- b. A run begins and memory fills, with the MACs counting addresses.
- c. Tracepoint may or may not occur before the memory is filled once.
- d. When tracepoint occurs, the Control Board window counter will count down from a programmed delay, finally stopping acquisition and the MACs.
- e. When acquisition is stopped, the CPU will read the last address to which data was written by reading the X address, the least significant Y address bit, and the trigger enable counter on the Control Board.

8-27. DIGITAL/ANALOG CONVERTERS (DACs). (Fig. 8-7)

8-28. The DACs set the middle threshold for the probes in the Wide Sample, Glitch, and Fast Sample Modes. In Dual Threshold Mode, DAC A (U76) sets the lower threshold, using channels 0-3; and DAC B (U78) sets the upper threshold, using channels 4-7.



64602A TIMING ACQUISITION BOARD

Figure 8-3.
64602A Timing Acquisition Board
Block Diagram




Figure 8-4.
Timing Analysis System
Block Diagram
ACQ 8-8

8-29. LOGIC CONVENTION

8-30. Logic states are defined as follows:

0-----False, negated, inactive, or unasserted state.

1-----True, active, or asserted state.

8-31. Voltage levels representing logic states:

LOW (L)-----The more negative of two voltage levels.

HIGH (H)-----The more positive of two voltage levels.

8-32. Signals may be either high true, or low true, as indicated by the mnemonics on the service sheets.

8-33. The 64602A includes both TTL and ECL ICs. Worst case voltage levels for trouble shooting and signature analysis purposes are as follows: (IC data sheet specifications may be better than this).

TTL Voltage Levels		ECL Voltage Levels	
Level	Voltage	Level	Voltage
LOW	<0.8	LOW	<-1.50
HIGH	>2.0	HIGH	>-1.10

8-34. MNEMONICS.

8-35. Mnemonic definitions are listed in Table 8-1 in the alphabetical order of characters after the slash. The following convention is used:

- a. An L or H before the slash indicates active LOW or HIGH.
- b. An E after L or H, but before the slash, indicates an ECL signal.
- c. No E before the slash indicates a TTL signal.
- d. An X instead of L or H means the signal may be programmed as either active LOW or HIGH.
- e. The functional mnemonic appears after the slash.

Table 8-1. Mnemonics

<u>MNEMONIC</u>	<u>DEFINITION</u>	<u>SCHEMATICS</u>	<u>ORIGIN</u>
L/A0-15	Address lines from mother-board.	1,2	1
H/BDO	Buffered data-line 0 from mother-board.	1,4	1
HE/CKGHR	Clock to glitch chip holding register.	1,4	1
L/D0-15	Data lines from mother-board.	1,3,5	1
HE/DT	Enable dual-threshold mode.	1,3	1
L/ENDAC	Enable D/A converters.	1,4	1
HE/ENFAST	Enable fast-sample mode.	1,4	1
H/ENTEST	Enable test.	1,4	1

<u>MNEMONIC</u>	<u>DEFINITION</u>	<u>SCHEMATICS</u>	<u>ORIGIN</u>
HE/GHR	Glitch holding register data.	1,4	1
L/IDBD	Identify board, derived from L/ID.	1,3	1
HE/PROBE 0-7 LE/PROBE 0-7	Inputs and inverse inputs from probe.	3,4	3
H/INIT	Initializes encoders. Derived from HE/RESET.	3,4	3
L/LOADCTR	Load counter. Enable loading memory address counters.	1,2	1
H/MEMFUL	Memory full. Indicates that memory has been loaded with good data at least once.	2,3	2
L/OERAMO-7	Output enable RAM.	1,5	5
L/STBBD	Strobe board, derived from L/SELBD.	1,3	1
H/RAMOUT0-15	RAM output.	5	5
L/RESETCTR	Reset address counters.	2,3	3
HE/RUN	Enables run mode.	2,3	3
L/WRTY	Enables write to Y memory bank.	2,5	2
HE/phi2 LE/phi2	Sample rate clocks from the control board.	2	2
LE/phi2A * HE/phi2A * HE/phi2B * LE/phi2B *	Buffered sample clocks to the glitch chip.	2,4	1
L/READCTR	Read counter. Enables reading memory address counter.	1,5	1
L/READRAM	Read RAM. Enables reading acquisition RAM	1,5	1

Theory and Schematics - Model 64602A

<u>MNEMONIC</u>	<u>DEFINITION</u>	<u>SCHEMATICS</u>	<u>ORIGIN</u>
XE/TRIG	Trigger signal from glitch chip. May be either HIGH or LOW true, depending on XE/TRIGPOL.	4,5	4
XE/TRIGPOL	Trigger polarity. Determines whether trigger will be HIGH or LOW true for an AND/OR combination with a trigger from another acquisition board.	4,5	4
HE/TSTENCK	Test enable memory address counter clock.	1,2	1
LE/WRT	Write. Enables write to acquisition RAM.	1,2	1
LE/WRTX	Write enable from U22 encoder to X memory bank.	2,4	4
LE/WRTY	Write enable from U22 encoder to Y memory bank.	2,4	4
H/XADRO-7	Address lines from the encoders to the X memory bank.	2,5	2
H/YADRO-7	Address lines from the encoders to the Y memory bank.	2,5	2
H/XCH0D0-7 *			
H/XCH1D0-7 *			
H/XCH2D0-7 *			
H/XCH3D0-7 *	X channel data. Encoder output from	4,5	4
H/XCH4D0-7 *	each probe channel to X memory bank.		
H/XCH5D0-7 *			
H/XCH6D0-7 *			
H/XCH7D0-7 *			
H/YCH0D0-7 *			
H/YCH1D0-7 *			
H/YCH2D0-7 *			
H/YCH3D0-7 *	Y channel data. Encoder output from	4,5	4
H/YCH4D0-7 *	each probe channel to Y memory bank.		
H/YCH5D0-7 *			
H/YCH6D0-7 *			
H/YCH7D0-7 *			

Table 8-2. Logic Symbols

GENERAL

All signals flow from left to right, relative to the symbol's orientation with inputs on the left side of the symbol, and outputs on the right side of the symbol (the symbol may be reversed if the dependency notation is a single term.)


All dependency notation is read from left to right (relative to the symbol's orientation).

An external state is the state of an input or output outside the logic symbol.


An internal state is the state of an input or output inside the logic symbol. All internal states are True = High.

SYMBOL CONSTRUCTION

Some symbols consist of an outline or combination of outlines together with one or more qualifying symbols, and the representation of input and output lines.



Some have a common Control Block with an array of elements:



CONTROL BLOCK - All inputs and dependency notation affect the array elements directly. Common outputs are located in the control block. (Control blocks may be above or below the array elements.)

ARRAY ELEMENTS - All array elements are controlled by the control block as a function of the dependency notation. Any array element is independent of all other array elements. Unless indicated, the least significant element is always closest to the control block. The array elements are arranged by binary weight. The weights are indicated by powers of 2 (shown in []).

Table 8-2. Logic Symbols (Cont'd)

INPUTS - Inputs are located on the left side of the symbol and are affected by their dependency notation.

Common control inputs are located in the control block and control the inputs/outputs to the array elements according to the dependency notation.

Inputs to the array elements are located with the corresponding array element with the least significant element closest to the control block.

OUTPUTS - Outputs are located on the right side of the symbol and are effected by their dependency notation.

Common control outputs are located in the control block.

Outputs of array elements are located in the corresponding array element with the least significant bit closest to the control block.

CHIP FUNCTION - The labels for chip functions are defined, i.e., CTR - counter, MUX - multiplexer.

DEPENDENCY NOTATION

Dependency notation is always read from left to right relative to the symbol's orientation.

Dependency notation indicates the relationship between inputs, outputs, or inputs and outputs. Signals having a common relationship will have a common number, i.e., C7 and 7D...C7 controls D. Dependency notation 2,3,5,6+/1,C7 is read as when 2 and 3 and 5 and 6 are true, the input will cause the counter to increment by one count...or (/) the input (C7) will control the loading of the input value (7D) into the D flip-flops.

The following types of dependencies are defined:

- AND (G), OR (V), and Negate (N) denote Boolean relationship between inputs and outputs in any combination.
- Interconnection (Z) indicates connections inside the symbol.
- Control (C) identifies a timing input or a clock input of a sequential element and indicates which inputs are controlled by it.
- Set (S) and Reset (R) specify the internal logic states (outputs) of an RS bistable element when the R or S input stands at its internal 1 state.
- Enable (EN) identifies an enable input and indicates which inputs and outputs are controlled by it (which outputs can be in their high impedance state).
- Mode (M) identifies an input that selects the mode of operation of an element and indicates the inputs and outputs depending on that mode.
- Address (A) identifies the address inputs.
- Transmission (X) identifies bi-directional inputs and outputs that are connected together when the transmission input is true.

DEPENDENCY NOTATION SYMBOLS

A	Address (selects inputs/outputs) (indicates binary range)	N	Negate (compliments state)
C	Control (permits action)	R	Reset Input
EN	Enable (permits action)	S	Set Input
G	AND (permits action)	V	OR (permits action)
M	Mode (selects action)	Z	Interconnection
		X	Transmission

Table 8-2. Logic Symbols (Cont'd)

OTHER SYMBOLS

	Analog Signal		Inversion		Shift Right (or down)
	AND		Negation		Solidus (allows an input or output to have more than one function)
	Bit Grouping		Nonlogic Input/Output		Tri-State
	Buffer		Open Circuit (external resistor)		Causes notation and symbols to effect inputs/outputs in an AND relationship, and to occur in the order read from left to right.
	Compare		Open Circuit (external resistor)		Used for factoring terms using algebraic techniques.
	Dynamic		OR		Information not defined.
	Exclusive OR		Passive Pull Down (internal resistor)		Logic symbol not defined due to complexity.
	Hysteresis		Passive Pull Up (internal resistor)		
	Interrogation		Postponed		
	Internal Connection		Shift Left (or up)		

LABELS

BG	Borrow Generate	CO	Carry Output	J	J Input
BI	Borrow Input	CP	Carry Propagate	K	K Input
BO	Borrow Output	CT	Content	P	Operand
BP	Borrow Propagate	D	Data Input	T	Transition
CG	Carry Generate	E	Extension (input or output)	+	Count Up
CI	Carry Input	F	Function	-	Count Down

MATH FUNCTIONS



	Adder		Greater Than
	Arithmetic Logic Unit		Less Than
	Comparator		Look Ahead Carry Generator
	Divide By		Multiplier
	Equal To		Subtractor

CHIP FUNCTIONS

BCD	Binary Coded Decimal	DIR	Directional	RAM	Random Access Memory
BIN	Binary	DMUX	Demultiplexer	RCVR	Line Receiver
BUF	Buffer	FF	Flip-Flop	ROM	Read Only Memory
CTR	Counter	MUX	Multiplexer	SEG	Segment
DEC	Decimal	OCT	Octal	SRG	Shift Register

DELAY and MULTIVIBRATORS

	Astable
	Delay
	Nonretriggerable Monostable
	Nonvolatile
	Retriggerable Monostable




ICs ON THIS SCHEMATIC

Ref Des	HP Part No.	Mfr. Part No.
U7	1820-0920	MC1692L
U11,12	1820-1173	MC10124L
U14	1820-0810	MC10116P
U70	1820-2024	SN74LS244N
U71	1820-1282	SN74LS109
U72	1820-1245	SN74LS155N
U73	1820-1144	SN74LS02N
U74	1820-2550	SN74LS137N
U75	1820-2657	SN74ALS32N
U81	1820-2646	SN74ALS00N

PARTS ON THIS SCHEMATIC

C7, 8, 10-12, 14, 15, 17-19, 21-31, 33-50, 53, 55-68
 R4, 7, 10, 11, 13, 21, 22, 38
 TP (SA GATE)
 U3, 15, 18, 19, 21 (resistor packs)

IC POWER SUPPLY CONFIGURATION



RESISTOR PAKS (UNCONNECTED PINS)
 U3 - PINS 3, 7-10
 U15 - NONE
 U18 - PIN 10
 U19 - PINS 5,6
 U21 - PINS 3-7









Figure 8-5.
 Service Sheet 1
 Mode Selection
 ACQ 8-15





64602A TIMING ACQUISITION BOARD



ICs ON THIS SCHEMATIC

Ref Des	HP Part No.	Mfr. Part No.
U13	1826-0544	1403U
U76,78	1826-0856	6080A
U77	1826-0974	747

PARTS ON THIS SCHEMATIC

- C3-6, 16, 51, 52, 54
- R1-3, 23-34
- TP1, 2







Figure 8-7.
Service Sheet 3
DACs, Probe Bus, & Timing Bus
Change 1 ACQ 8-19





ICs ON THIS SCHEMATIC

Ref Des	HP Part No.	Mfr. Part No.
U17	1820-0793	MC1674L
U22-25, 29-32	1NB4-5017	
U27	1NB4-5007	

PARTS ON THIS SCHEMATIC

- C69
- C70
- C4
- CR2
- R5
- Q1
- U26, 28 (resistor packs)

IC POWER SUPPLY CONFIGURATION






Figure 8-8.
Service Sheet 4
Glitch Chip & Encoders
Change 1 ACQ 8-21



ICs ON THIS SCHEMATIC

Ref Des	HP Part No.	Mfr. Part No.
U16	1820-1052	MC10125L
U33-64	1816-1476	93L422DC SLT
U70	1820-2024	74LS244N
U79,80,83	1820-1917	74LS240N
U82	1820-1492	74LS368

PARTS ON THIS SCHEMATIC

C20
CR3,CR4
R17-20

IC POWER SUPPLY CONFIGURATION






Figure 8-9.
Service Sheet 5
Acquisition Memory
ACQ 8-23

SALES & SUPPORT OFFICES

Arranged alphabetically by country



Product Line Sales/Support Key

Key Product Line

- A Analytical
- CM Components
- C Computer Systems Sales only
- CH Computer Systems Hardware Sales and Services
- CS Computer Systems Software Sales and Services
- E Electronic Instruments & Measurement Systems
- M Medical Products
- MP Medical Products Primary SRO
- MS Medical Products Secondary SRO
- P Personal Computation Products
- * Sales only for specific product line
- ** Support only for specific product line

IMPORTANT: These symbols designate general product line capability. They do not insure sales or support availability for all products within a line, at all locations. Contact your local sales office for information regarding locations where HP support is available for specific products.

HP distributors are printed in italics.

ANGOLA

Telectra
Empresa Técnica de Equipamentos
R. Barbosa Rodrigues, 41-1 DT.
Caixa Postal 6487
LUANDA
Tel: 35515,35516
E,M,P

ARGENTINA

Hewlett-Packard Argentina S.A.
Avenida Santa Fe 2035
MARINEZ 1640 BUENOS AIRES
Tel: 798-5735, 792-1293
Telex: 17595 BIONAR
Cable: HEWPACKARG
A,E,CH,CS,P
Biotron S.A.C.I.M. e I.
Av Paseo Colon 221, Piso 9
1399 BUENOS AIRES
Tel: 30-4846, 30-1851
Telex: 17595 BIONAR
M

AUSTRALIA

Adelaide, South Australia Office

Hewlett-Packard Australia Ltd.
153 Greenhill Road
PARKSIDE, S.A. 5063
Tel: 272-5911
Telex: 82536
Cable: HEWPARAD Adelaide
A,CH,CM,E,MS,P*

Brisbane, Queensland Office

Hewlett-Packard Australia Ltd.
10 Payne Road
THE GAP, Queensland 4061
Tel: 30-4133
Telex: 42133
Cable: HEWPARAD Brisbane
A,CH,CM,E,M,P

Canberra, Australia Capital Territory Office

Hewlett-Packard Australia Ltd.
121 Wollongong Street
FYSHWICK, A.C.T. 2609
Tel: 80 4244
Telex: 62650
Cable: HEWPARAD Canberra
CH,CM,E,P

Melbourne, Victoria Office

Hewlett-Packard Australia Ltd.
31-41 Joseph Street
BLACKBURN, Victoria 3130
Tel: 890 6351
Telex: 31-024
Cable: HEWPARAD Melbourne
A,CH,CM,CS,E,MS,P

Perth, Western Australia Office

Hewlett-Packard Australia Ltd.
261 Stirling Highway
CLAREMONT, W.A. 6010
Tel: 383-2188
Telex: 93859
Cable: HEWPARAD Perth
A,CH,CM,E,MS,P

Sydney, New South Wales Office

Hewlett-Packard Australia Ltd.
17-23 Talavera Road
P.O. Box 308
NORTH RYDE, N.S.W. 2113
Tel: 887-1611
Telex: 21561
Cable: HEWPARAD Sydney
A,CH,CM,CS,E,MS,P

AUSTRIA

Hewlett-Packard Ges.m.b.h.
Grottenhofstrasse 94
Verkaufsburo Graz
A-8052 GRAZ
Tel: 291-5-66
Telex: 32375
*CH,E**

Hewlett-Packard Ges.m.b.h.
Liebigasse 1
P.O. Box 72
A-1222 VIENNA
Tel: (0222) 23-65-11-0
Telex: 134425 HEPA A
A,CH,CM,CS,E,MS,P

BAHRAIN

Green Salon
P.O. Box 557
BAHRAIN
Tel: 255503-255950
Telex: 84419
P
Wael Pharmacy
P.O. Box 648
BAHRAIN
Tel: 256123
Telex: 8550 WAEL BN
E,M

BELGIUM

Hewlett-Packard Belgium S.A./N.V.
Blvd de la Woluwe, 100
Woluwedal
B-1200 BRUSSELS
Tel: (02) 762-32-00
Telex: 23-494 paloben brv
A,CH,CM,CS,E,MP,P

BRAZIL

Hewlett-Packard do Brasil I.e.C. Ltda.
Alameda Rio Negro, 750
Alphaville
06400 BARUERI SP
Tel: (011) 421.1311
Telex: (011) 33872 HPBR-BR
Cable: HEWPACK Sao Paulo
A,CH,CM,CS,E,M,P
Hewlett-Packard do Brasil I.e.C. Ltda.
Avenida Epitacio Pessoa, 4664
22471 RIO DE JANEIRO-RJ
Tel: (021) 286.0237
Telex: 021-21905 HPBR-BR
Cable: HEWPACK Rio de Janeiro
*A,CH,CM,E,MS,P**

CANADA

Alberta
Hewlett-Packard (Canada) Ltd.
210, 7220 Fisher Street S.E.
CALGARY, Alberta T2H 2H8
Tel: (403) 253-2713
A,CH,CM,E,MS,P**
Hewlett-Packard (Canada) Ltd.
11620A-168th Street
EDMONTON, Alberta T5M 3T9
Tel: (403) 452-3670
*A,CH,CM,CS,E,MS,P**

British Columbia

Hewlett-Packard (Canada) Ltd.
10691 Shellbridge Way
RICHMOND,
British Columbia V6X 2W7
Tel: (604) 270-2277
Telex: 610-922-5059
A,CH,CM,CS,E,MS,P**

Manitoba

Hewlett-Packard (Canada) Ltd.
380-550 Century Street
WINNIPEG, Manitoba R3H 0Y1
Tel: (204) 786-6701
*A,CH,CM,E,MS,P**

New Brunswick

Hewlett-Packard (Canada) Ltd.
37 Sheadiac Road
MONCTON, New Brunswick E2B 2V0
Tel: (506) 855-2841
*CH***

Nova Scotia

Hewlett-Packard (Canada) Ltd.
P.O. Box 931
900 Windmill Road
DARTMOUTH, Nova Scotia B2Y 3Z6
Tel: (902) 469-7820
CH,CM,CS,E,MS,P**

Ontario

Hewlett-Packard (Canada) Ltd.
552 Newbold Street
LONDON, Ontario N6E 2S5
Tel: (519) 686-9181
A,CH,CM,E,MS,P**
Hewlett-Packard (Canada) Ltd.
6877 Goreway Drive
MISSISSAUGA, Ontario L4V 1M8
Tel: (416) 678-9430
A,CH,CM,CS,E,MP,P

Hewlett-Packard (Canada) Ltd.
2670 Queensview Dr.
OTTAWA, Ontario K2B 8K1
Tel: (613) 820-6483
A,CH,CM,CS,E,MS,P**
Hewlett-Packard (Canada) Ltd.
220 Yorkland Blvd., Unit #11
WILLOWDALE, Ontario M2J 1R5
Tel: (416) 499-9333
CH

Quebec

Hewlett-Packard (Canada) Ltd.
17500 South Service Road
Trans-Canada Highway
KIRKLAND, Quebec H9J 2M5
Tel: (514) 697-4232
*A,CH,CM,CS,E,MP,P**
Hewlett-Packard (Canada) Ltd.
Les Galeries du Vallon
2323 Du Versant Nord
STE. FOY, Quebec G1N 4C2
Tel: (418) 687-4570
CH

CHILE

Jorge Calcagni y Cia. Ltda.
Arturo Buhrie 065
Casilla 16475
SANTIAGO 9
Tel: 222-0222
Telex: Public Booth 440001
A,CM,E,M
Olympia (Chile) Ltda.
Av. Rodrigo de Araya 1045
Casilla 256-V
SANTIAGO 21
Tel: (02) 22 55 044
Telex: 240-565 OLYMP CL
Cable: Olympiachile Santiagochile
CH,CS,P

CHINA, People's Republic of

China Hewlett-Packard Rep. Office
P.O. Box 418
1A Lane 2, Luchang St.
Beiwei Rd., Xuanwu District
BEIJING
Tel: 33-1947, 33-7426
Telex: 22601 CTSHP CN
Cable: 1920
A,CH,CM,CS,E,P

COLOMBIA

Instrumentación
H. A. Langebaek & Kier S.A.
Carrera 4A No. 52A-26
Apartado Aereo 6287
BOGOTA 1, D.E.
Tel: 212-1466
Telex: 44400 INST CO
Cable: AARIS Bogota
CM,E,M

COSTA RICA

Científica Costarricense S.A.
Avenida 2, Calle 5
San Pedro de Montes de Oca
Apartado 10159
SAN JOSE
Tel: 24-38-20, 24-08-19
Telex: 2367 GALGUR CR
CM,E,M

CYPRUS

Telexera Ltd.
P.O. Box 4809
14C Stassinou Avenue
NICOSIA
Tel: 62698
Telex: 2894 LEVIDO CY
E,M,P

DENMARK

Hewlett-Packard A/S
Datavej 52
DK-3460 BIRKEROD
Tel: (02) 81-66-40
Telex: 37409 hpas dk
A,CH,CM,CS,E,MS,P
Hewlett-Packard A/S
Rolphedsvej 32
DK-8240 RISSKOV
Tel: (06) 17-60-00
Telex: 37409 hpas dk
CH,E

DOMINICAN REPUBLIC

Microprog S.A.
Juan Tomás Mejía y Cotes No. 60
Arroyo Hondo
SANTO DOMINGO
Tel: 565-6268
Telex: 4510 ARENTA DR (RCA)
P

ECUADOR

CYEDE Cia. Ltda.
Avenida Eloy Alfaro 1749
Casilla 6423 CCI
QUITO
Tel: 450-975, 243-052
Telex: 2548 CYEDE ED
CM,E
Hospitalar S.A.
Robles 625
Casilla 3590
QUITO
Tel: 545-250, 545-122
Telex: 2485 HOSPTEL ED
Cable: HOSPITALAR-Quito
M

EGYPT

International Engineering Associates
24 Hussein Hegazi Street
Kasr-el-Aini
CAIRO
Tel: 23829, 21641
Telex: IEA UN 93830
CH,CS,E,M
Informatic For Systems
22 Talaat Harb Street
CAIRO
Tel: 759006
Telex: 93938 FRANK UN
CH,CS,P
Egyptian International Office
for Foreign Trade
P.O.Box 2558
CAIRO
Tel: 650021
Telex: 93337 EGPOR
P

EL SALVADOR

IPESA de El Salvador S.A.
29 Avenida Norte 1216
SAN SALVADOR
Tel: 26-6858, 26-6868
Telex: 20539 EPISA
A,CH,CM,CS,E,P



SALES & SUPPORT OFFICES

Arranged alphabetically by country

FINLAND

Hewlett-Packard Oy
Revontulentie 7
SF-02100 **ESPOO** 10
Tel: 00358-0-4550211
Telex: 9100
A,CH,CM,CS,E,MS,P
Hewlett-Packard Oy
Aatoksenkatu 10-C
SF-40720-72 **JYVASKYLA**
Tel: (941) 216318
CH

Hewlett-Packard Oy
Kainuntie 1-C
SF-90140-14 **OULU**
Tel: (981) 338785
CH

FRANCE

Hewlett-Packard France
Z.I. Mercure B
Rue Berthelot
F-13763 Les Milles Cedex
AIX-EN-PROVENCE
Tel: 16 (42) 59-41-02
Telex: 410770F
A,CH,E,MS,P*

Hewlett-Packard France
64, rue Marchand Saillant
F-61000**ALENCON**
Tel: 16 (33) 29 04 42

Hewlett-Packard France
Boite Postale 503
F-25026 **BESANCON**
28 rue de la Republique
F-25000 **BESANCON**
Tel: 16 (81) 83-16-22
CH,M

Hewlett-Packard France
13, Place Napoleon III
F-29000 **BREST**
Tel: 16 (98) 03-38-35

Hewlett-Packard France
Chemin des Mouilles
Boite Postale 162
F-69130 **ECULLY** Cedex
Tel: 16 (78) 833-81-25
Telex: 310617F
A,CH,CS,E,MP

Hewlett-Packard France
Tour Lorraine
Boulevard de France
F-91035 **EVRY** Cedex
Tel: 16 6 077-96-60
Telex: 692315F
E

Hewlett-Packard France
5, avenue Raymond Chanas
F-38320 **EYBENS**
Tel: 16 (76) 25-81-41
Telex: 980124 HP GRENOb EYBE
CH

Hewlett-Packard France
Centre d'Affaire Paris-Nord
Bâtiment Ampère 5 étage
Rue de la Commune de Paris
Boite Postale 300
F-93153 **LE BLANC MESNIL**
Tel: 16 (1) 865-44-52
Telex: 211032F
CH,CS,E,MS

Hewlett-Packard France
Parc d'Activités Cadera
Quartier Jean Mermoz
Avenue du Président JF Kennedy
F-33700 **MERIGNAC**
Tel: 16 (56) 34-00-84
Telex: 550105F
CH,E,MS

Hewlett-Packard France
Immeuble "Les 3 B"
Nouveau Chemin de la Garde
ZAC de Bois Briand
F-44085 **NANTES** Cedex
Tel: 16 (40) 50-32-22
CH**

Hewlett-Packard France
125, rue du Faubourg Bannier
F-45000 **ORLEANS**
Tel: 16 (38) 68 01 63

Hewlett-Packard France
Zone Industrielle de Courtaboeuf
Avenue des Tropiques
F-91947 Les Ulis Cedex **ORSAY**
Tel: (6) 907-78-25
Telex: 600048F
A,CH,CM,CS,E,MP,P

Hewlett-Packard France
Paris Porte-Maillot
15, Avenue de L'Amiral Bruix
F-75782 **PARIS CEDEX** 16
Tel: 16 (1) 502-12-20
Telex: 613663F
CH,MS,P

Hewlett-Packard France
124, Boulevard Tourasse
F-64000 **PAU**
Tel: 16 (59) 80 38 02

Hewlett-Packard France
2 Allée de la Bourgonnette
F-35100 **RENNES**
Tel: 16 (99) 51-42-44
Telex: 740912F
CH,CM,E,MS,P*

Hewlett-Packard France
98 Avenue de Bretagne
F-76100 **ROUEN**
Tel: 16 (35) 63-57-66
CH**,CS

Hewlett-Packard France
Boite Postale 56
F-67033 **STRASBOURG** Cedex
4 Rue Thomas Mann
F-67200 **STRASBOURG** Cedex
Tel: 16 (88) 28-56-46
Telex: 890141F
CH,E,MS,P*

Hewlett-Packard France
Le Péripole
3, Chemin du Pigeonnier de la
Cépière
F-31083 **TOULOUSE** Cedex
Tel: 16 (61) 40-11-12
Telex: 531639F
A,CH,CS,E,P*

Hewlett-Packard France
9, rue Baudin
F-26000 **VALENCE**
Tel: 16 (75) 42 76 16
Hewlett-Packard France
Garolor
ZAC de Bois Briand
F-57640 **VIGY**
Tel: 16 (8) 771 20 22
CH

Hewlett-Packard France
Immeuble Périceentre
F-59658 **VILLENEUVE D'ASCQ** Cedex
Tel: 16 (20) 91-41-25
Telex: 160124F
CH,E,MS,P*

GERMAN FEDERAL REPUBLIC

Hewlett-Packard GmbH
Geschäftsstelle
Keilstrasse 2-4
D-1000 **BERLIN** 30
Tel: (030) 24-90-86
Telex: 018 3405 hpbln d
A,CH,E,M,P

Hewlett-Packard GmbH
Geschäftsstelle
Herrenberger Strasse 110
D-7030 **BOBLINGEN**
Tel: (7031) 667-750
Telex: bbn or
A,CH,CM,CS,E,MP,P

Hewlett-Packard GmbH
Geschäftsstelle
Emanuel-Leutze-Strasse 1
D-4000 **DUSSELDORF**
Tel: (0211) 5971-1
Telex: 085/86 533 hpdd d
A,CH,CS,E,MS,P

Hewlett-Packard GmbH
Vertriebszentrale Frankfurt
Bernstrasse 117
Postfach 560 140
D-6000 **FRANKFURT** 56
Tel: (0611) 50-04-1
Telex: 04 13249 hpffm d
A,CH,CM,CS,E,MP,P

Hewlett-Packard GmbH
Geschäftsstelle
Kapstadtring 5
D-2000 **HAMBURG** 60
Tel: (040) 63804-1
Telex: 021 63 032 hphh d
A,CH,CS,E,MS,P

Hewlett-Packard GmbH
Geschäftsstelle
Heidering 37-39
D-3000 **HANNOVER** 91
Tel: (0511) 5706-0
Telex: 092 3259
A,CH,CM,E,MS,P

Hewlett-Packard GmbH
Geschäftsstelle
Rosslauer Weg 2-4
D-6800 **MANNHEIM**
Tel: (0621) 70050
Telex: 0462105
A,C,E

Hewlett-Packard GmbH
Geschäftsstelle
Messerschmittstrasse 7
D-7910 **NEU ULM**
Tel: 0731-70241
Telex: 0712816 HP ULM-D
A,C,E*

Hewlett-Packard GmbH
Geschäftsstelle
Neumeyerstrasse 90
D-8500 **NÜRNBERG**
Tel: (0911) 52 20 83-87
Telex: 0623 860
CH,CM,E,MS,P

Hewlett-Packard GmbH
Geschäftsstelle
Eschenstrasse 5
D-8028 **TAUFKIRCHEN**
Tel: (089) 6117-1
Telex: 0524985
A,CH,CM,E,MS,P

GREAT BRITAIN

See United Kingdom

GREECE

Kostas Karayannis S.A.
8 Omirou Street
ATHENS 133
Tel: 32 30 303, 32 37 371
Telex: 215962 RKAR GR
A,CH,CM,CS,E,M,P
PLAISIO S.A.
G. Gerardos
24 Stournara Street
ATHENS
Tel: 36-11-160
Telex: 221871
P

GUATEMALA

IPESA
Avenida Reforma 3-48, Zona 9
GUATEMALA CITY
Tel: 316627, 314786
Telex: 4192 TELTRO GU
A,CH,CM,CS,E,M,P

HONG KONG

Hewlett-Packard Hong Kong, Ltd.
G.P.O. Box 795
5th Floor, Sun Hung Kai Centre
30 Harbour Road
HONG KONG
Tel: 5-8323211
Telex: 66678 HEWPA HX
Cable: HEWPACK HONG KONG
E,CH,CS,P

CET Ltd.
1402 Tung Way Mansion
199-203 Hennessy Rd.
Wanchia, **HONG KONG**
Tel: 5-729376
Telex: 85148 CET HX
CM

Schmidt & Co. (Hong Kong) Ltd.
Wing On Centre, 28th Floor
Connaught Road, C.
HONG KONG
Tel: 5-455644
Telex: 74766 SCHMX HX
A,M

ICELAND

Elding Trading Company Inc.
Hafnarvölli-Tryggvagotu
P.O. Box 895
IS-REYKJAVIK
Tel: 1-58-20, 1-63-03
M

INDIA

Computer products are sold through
Blue Star Ltd. All computer repairs
and maintenance service is done
through Computer Maintenance
Corp.

Blue Star Ltd.
Sabri Complex II Floor
24 Residency Rd.
BANGALORE 560 025
Tel: 55660

Telex: 0845-430
Cable: BLUESTAR
A,CH*,CM,CS*,E
Blue Star Ltd.
Band Box House
Prabhadevi

BOMBAY 400 025
Tel: 422-3101
Telex: 011-3751
Cable: BLUESTAR
A,M

Blue Star Ltd.
Sahas
414/2 Vir Savarkar Marg
Prabhadevi
BOMBAY 400 025
Tel: 422-6155
Telex: 011-4093
Cable: FROSTBLUE
A,CH*,CM,CS*,E,M

Blue Star Ltd.
Kalyan, 19 Vishwas Colony
Alkapuri, **BORODA**, 390 005
Tel: 65235
Cable: BLUE STAR
A

Blue Star Ltd.
7 Hare Street
CALCUTTA 700 001
Tel: 12-01-31
Telex: 021-7655
Cable: BLUESTAR
A,M

Blue Star Ltd.
133 Kodambakkam High Road
MADRAS 600 034
Tel: 82057
Telex: 041-379
Cable: BLUESTAR
A,M

Blue Star Ltd.
Bhandari House, 7th/8th Floors
91 Nehru Place
NEW DELHI 110 024
Tel: 682547
Telex: 031-2463
Cable: BLUESTAR
A,CH*,CM,CS*,E,M

Blue Star Ltd.
15/16:C Wellesley Rd.
PUNE 411 011
Tel: 22775
Cable: BLUE STAR
A

Blue Star Ltd.
2-2-47/1108 Bolarum Rd.
SECUNDERABAD 500 003
Tel: 72057
Telex: 0155-459
Cable: BLUEFROST
A,E

Blue Star Ltd.
T.C. 7/603 Poornima
Maruthankuzhi
TRIVANDRUM 695 013
Tel: 65799
Telex: 0884-259
Cable: BLUESTAR
E
Computer Maintenance Corporation
Ltd.

115, Sarojini Devi Road
SECUNDERABAD 500 003
Tel: 310-184, 345-774
Telex: 031-2960
CH**

INDONESIA

BERCA Indonesia P.T.
P.O.Box 496/JKT.
Jl. Abdul Muis 62
JAKARTA
Tel: 373009
Telex: 46748 BERSAL IA
Cable: BERSAL JAKARTA
P

BERCA Indonesia P.T.
P.O.Box 2497/Jkt Antara Bldg.,
17th Floor
Jl. Medan Merdeka Selatan 17
JAKARTA-PUSAT
Tel: 21-344-181
Telex: BERSAL IA
A,CS,E,M

BERCA Indonesia P.T.
P.O. Box 174/SBY.
Jl. Kutei No. 11
SURABAYA
Tel: 68172
Telex: 31146 BERSAL SB
Cable: BERSAL-SURABAYA
A*,E,M,P

IRAQ

Hewlett-Packard Trading S.A.
Service Operation
Al Mansour City 9B/3/7
BAGHDAD
Tel: 551-49-73
Telex: 212-455 HEPAIRAQ IK
CH,CS

SALES & SUPPORT OFFICES

Arranged alphabetically by country

3



IRELAND

Hewlett-Packard Ireland Ltd.
82/83 Lower Leeson Street
DUBLIN 2
Tel: (1) 60 88 00
Telex: 30439
A,CH,CM,CS,E,M,P

Cardiac Services Ltd.
Kilmore Road
Artane
DUBLIN 5
Tel: (01) 351820
Telex: 30439
M

ISRAEL

Eidan Electronic Instrument Ltd.
P.O.Box 1270
JERUSALEM 91000
16, Ohaliav St.
JERUSALEM 94467
Tel: 533 221, 553 242
Telex: 25231 AB/PAKRD IL
A

Electronics Engineering Division
Motorola Israel Ltd.
16 Kremenetski Street
P.O. Box 25016
TEL-AVIV 67899
Tel: 3-338973
Telex: 33569 Motil IL
Cable: BASTEL Tel-Aviv
CH,CM,CS,E,M,P

ITALY

Hewlett-Packard Italiana S.p.A
Traversa 99C
Via Giulio Petroni, 19
I-70124 **BARI**
Tel: (080) 41-07-44
M

Hewlett-Packard Italiana S.p.A.
Via Martin Luther King, 38/111
I-40132 **BOLOGNA**
Tel: (051) 402394
Telex: 511630
CH,E,MS

Hewlett-Packard Italiana S.p.A.
Via Principe Nicola 43G/C
I-95126 **CATANIA**
Tel: (095) 37-10-87
Telex: 970291
C,P

Hewlett-Packard Italiana S.p.A.
Via G. Di Vittorio 9
I-20063 **CERNUSCO SUL NAVIGLIO**
Tel: (2) 903691
Telex: 334632
A,CH,CM,CS,E,MP,P

Hewlett-Packard Italiana S.p.A.
Via Nuova San Rocco a
Capodimonte, 62/A
I-80131 **NAPLES**
Tel: (081) 7413544
Telex: 710698
A,CH,E

Hewlett-Packard Italiana S.p.A.
Viale G. Modugno 33
I-16156 **GENOVA PEGLI**
Tel: (010) 68-37-07
Telex: 215238
E,C

Hewlett-Packard Italiana S.p.A.
Via Turazza 14
I-35100 **PADOVA**
Tel: (049) 664888
Telex: 430315
A,CH,E,MS

Hewlett-Packard Italiana S.p.A.
Viale C. Pavese 340
I-00144 **ROMA**
Tel: (06) 54831
Telex: 610514
A,CH,CM,CS,E,MS,P*

Hewlett-Packard Italiana S.p.A.
Corso Svizzera, 184
I-10149 **TORINO**
Tel: (011) 74 4044
Telex: 221079
CH,E

JAPAN

Yokogawa-Hewlett-Packard Ltd.
152-1, Onna
000 **ATSUGI**, Kanagawa, 243
Tel: (0462) 28-0451
CM,C*,E

Yokogawa-Hewlett-Packard Ltd.
Towa Building
2-3, Kaigan-dori, 2 Chome Chuo-ku
KOBE, 650
Tel: (078) 392-4791
C,E

Yokogawa-Hewlett-Packard Ltd.
Kumagaya Asahi 82 Bldg
3-4 Tsukuba
KUMAGAYA, Saitama 360
Tel: (0485) 24-6563
CH,CM,E

Yokogawa-Hewlett-Packard Ltd.
Asahi Shinbun Daiichi Seimei Bldg.
4-7, Hanabata-cho
KUMAMOTO, 860
Tel: (0963) 54-7311
CH,E

Yokogawa-Hewlett-Packard Ltd.
Shin-Kyoto Center Bldg.
614, Higashi-Shiokoji-cho
Karasuma-Nishiiru
Shiokoji-dori, Shimogyo-ku
KYOTO, 600
Tel: 075-343-0921
CH,E

Yokogawa-Hewlett-Packard Ltd.
Mito Mitsui Bldg
4-73, Sannomaru, 1 Chome
MITO, Ibaragi 310
Tel: (0292) 25-7470
CH,CM,E

Yokogawa-Hewlett-Packard Ltd.
Sumitomo Seimei 14-9 Bldg.
Meieki-Minami, 2 Chome
Nakamura-ku
NAGOYA, 450
Tel: (052) 571-5171
CH,CM,CS,E,MS

Yokogawa-Hewlett-Packard Ltd.
Chuo Bldg.,
4-20 Nishinakajima, 5 Chome
Yodogawa-ku
OSAKA, 532
Tel: (06) 304-6021
Telex: YHPOSA 523-3624
A,CH,CM,CS,E,MP,P*

Yokogawa-Hewlett-Packard Ltd.
27-15, Yabe, 1 Chome
SAGAMIHARA Kanagawa, 229
Tel: 0427 59-1311

Yokogawa-Hewlett-Packard Ltd.
Daiichi Seimei Bldg.
7-1, Nishi Shinjuku, 2 Chome
Shinjuku-ku, **TOKYO** 160
Tel: 03-348-4611-5
CH,E

Yokogawa-Hewlett-Packard Ltd.
29-21 Takaido-Higashi, 3 Chome
Suginami-ku **TOKYO** 168
Tel: (03) 331-6111
Telex: 232-2024 YHPTOK
A,CH,CM,CS,E,MP,P*

Yokogawa-Hewlett-Packard Ltd.
Daiichi Asano Building
2-8, Odori, 5 Chome
UTSUNOMIYA, Tochigi 320
Tel: (0286) 25-7155
CH,CS,E

Yokogawa-Hewlett-Packard Ltd.
Yasuda Seimei Nishiguchi Bldg.
30-4 Tsuruya-cho, 3 Chome
YOKOHAMA 221
Tel: (045) 312-1252
CH,CM,E

JORDAN

Mouasher Cousins Company
P.O. Box 1387
AMMAN
Tel: 24907, 39907
Telex: 21456 SABCO JO
CH,E,M,P

KENYA

ADCOM Ltd., Inc., Kenya
P.O.Box 30070
NAIROBI
Tel: 331955
Telex: 22639
E,M

KOREA

Samsung Electronics Computer
Division
76-561 Yeoksam-Dong
Kwangnam-Ku
C.P.O. Box 2775
SEOUL
Tel: 555-7555, 555-5447
Telex: K27364 SAMSAN
A,CH,CM,CS,E,M,P

KUWAIT

Al-Khaldiya Trading & Contracting
P.O. Box 830 Safat
KUWAIT
Tel: 42-4910, 41-1726
Telex: 22481 Areeg kt
CH,E,M
Photo & Cine Equipment
P.O. Box 270 Safat
KUWAIT
Tel: 42-2846, 42-3801
Telex: 22247 Matin kt
P

LEBANON

G.M. Dolmadjian
Achratieh
P.O. Box 165.167
BEIRUT
Tel: 290293
MP**

LUXEMBOURG

Hewlett-Packard Belgium S.A./N.V.
Blvd de la Woluwe, 100
Woluwedal
B-1200 **BRUSSELS**
Tel: (02) 762-32-00
Telex: 23-494 paloben bru
A,CH,CM,CS,E,MP,P

MALAYSIA

Hewlett-Packard Sales (Malaysia)
Sdn. Bhd.
1st Floor, Bangunan British
American
Jalan Semantan, Damansara Heights
KUALA LUMPUR 23-03
Tel: 943022
Telex: MA31011
A,CH,E,M,P*
Protel Engineering
P.O.Box 1917
Lot 6624, Section 64
23/4 Pending Road
Kuching, **SARAWAK**
Tel: 36299
Telex: MA 70904 PROTEL
Cable: PROTELENG
A,E,M

MALTA

Philip Toledo Ltd.
Notabile Rd.
MRIEHEL
Tel: 447 47, 455 66
Telex: Media MW 649
P

MEXICO

Hewlett-Packard Mexicana, S.A.
de C.V.
Av. Periferico Sur No. 6501
Tepepan, Xochimilco
MEXICO D.F. 16020
Tel: 676-4600
Telex: 17-74-507 HEWPACK MEX
A,CH,CS,E,MS,P
Hewlett-Packard Mexicana, S.A.
de C.V.
Ave. Colonia del Valle #409
Col. del Valle
Municipio de Garza Garcia
MONTERREY, N.L.
Tel: 78 42 41
Telex: 038 410
CH

ECISA

José Vasconcelos No. 218
Col. Condesa Deleg. Cuauhtémoc
MEXICO D.F. 06140
Tel: 553-1206
Telex: 17-72755 ECE ME
M

MOROCCO

Dolbeau
81 rue Karatchi
CASABLANCA
Tel: 3041-82, 3068-38
Telex: 23051, 22822
E
Gerap
2 rue d'Agadir
Boite Postale 156
CASABLANCA
Tel: 272093, 272095
Telex: 23 739
P

NETHERLANDS

Hewlett-Packard Nederland B.V.
Van Heuven Goedhartlaan 121
NL 1181KK **AMSTELVEEN**
P.O. Box 667
NL1180 AR **AMSTELVEEN**
Tel: (020) 47-20-21
Telex: 13 216 HEPA NL
A,CH,CM,CS,E,MP,P
Hewlett-Packard Nederland B.V.
Bongerd 2
NL 2906VK **CAPELLE, A/D IJSSEL**
P.O. Box 41
NL 2900AA **CAPELLE, A/D IJSSEL**
Tel: (10) 51-64-44
Telex: 21261 HEPAC NL
A,CH,CS,E

NEW ZEALAND

Hewlett-Packard (N.Z.) Ltd.
169 Manukau Road
P.O. Box 26-189
Epsom, **AUCKLAND**
Tel: 687-159
Cable: HEWPACK Auckland
CH,CM,E,P*
Hewlett-Packard (N.Z.) Ltd.
4-12 Cruickshank Street
Kilbirnie, **WELLINGTON 3**
P.O. Box 9443
Courtenay Place, **WELLINGTON 3**
Tel: 877-199
Cable: HEWPACK Wellington
CH,CM,E,P

Northrop Instruments & Systems
Ltd.
369 Khyber Pass Road
P.O. Box 8602
AUCKLAND
Tel: 794-091
Telex: 60605
A,M

Northrop Instruments & Systems
Ltd.
110 Mandeville St.
P.O. Box 8388
CHRISTCHURCH
Tel: 486-928
Telex: 4203
A,M

Northrop Instruments & Systems
Ltd.
Sturdee House
85-87 Ghuznee Street
P.O. Box 2406
WELLINGTON
Tel: 850-091
Telex: NZ 3380
A,M

NORTHERN IRELAND

See United Kingdom

NORWAY

Hewlett-Packard Norge A/S
Folke Bernadottes vei 50
P.O. Box 3558
N-5033 **FYLLINGSDALEN** (Bergen)
Tel: (05) 16-55-40
Telex: 16621 hpnas n
CH,CS,E,MS
Hewlett-Packard Norge A/S
Østerdalen 18
P.O. Box 34
N-1345 **ØSTERÅS**
Tel: (02) 17-11-80
Telex: 16621 hpnas n
A,CH,CM,CS,E,M,P

OMAN

Khimjil Ramdas
P.O. Box 19
MUSCAT
Tel: 722225, 745601
Telex: 3289 BROKER MB MUSCAT
P
Suhail & Saud Bahwan
P.O.Box 169
MUSCAT
Tel: 734 201-3
Telex: 3274 BAHWAN MB

PAKISTAN

Mushko & Company Ltd.
1-B, Street 43
Sector F-8/1
ISLAMABAD
Tel: 26875
Cable: FEMUS Rawalpindi
A,E,M
Mushko & Company Ltd.
Oosman Chambers
Abdullah Haroon Road
KARACHI 0302
Tel: 524131, 524132
Telex: 2894 MUSKO PK
Cable: COOPERATOR Karachi
A,E,M,P*

PANAMA

Electrónico Balboa, S.A.
Calle Samuel Lewis, Ed. Alfa
Apartado 4929
PANAMA 5
Tel: 64-2700
Telex: 3483 ELECTRON PG
A,CM,E,M,P

SALES & SUPPORT OFFICES

Arranged alphabetically by country

PERU

Cia Electro Médica S.A.
Los Flamencos 145, San Isidro
Casilla 1030
LIMA 1
Tel: 41-4325, 41-3703
Telex: Pub. Booth 25306
CM,E,M,P

PHILIPPINES

The Online Advanced Systems Corporation
Rico House, Amorsolo Cor. Herrera Street
Legaspi Village, Makati
P.O. Box 1510
Metro MANILA
Tel: 85-35-81, 85-34-91, 85-32-21
Telex: 3274 ONLINE
A,CH,CS,E,M

Electronic Specialists and Proponents Inc.
690-B Epifanio de los Santos Avenue
Cubao, **QUEZON CITY**
P.O. Box 2649 Manila
Tel: 98-96-81, 98-96-82, 98-96-83
Telex: 40018, 42000 ITT GLOBE
MACKAY BOOTH
P

PORTUGAL

Mundinter
Intercambio Mundial de Comércio S.A.R.L.
P.O. Box 2761
Avenida Antonio Augusto de Aguiar 138
P-LISBON
Tel: (19) 53-21-31, 53-21-37
Telex: 16691 munter p
M
Soquimica
Av. da Liberdade, 220-2
1298 LISBOA Codex
Tel: 56 21 81/2/3
Telex: 13316 SABASA
P
Telectra-Empresa Técnica de Equipamentos Eléctricos S.A.R.L.
Rua Rodrigo da Fonseca 103
P.O. Box 2531
P-LISBON 1
Tel: (19) 68-60-72
Telex: 12598
CH,CS,E,P

PUERTO RICO

Hewlett-Packard Puerto Rico
P.O. Box 4407
CAROLINA, Puerto Rico 00628
Calle 272 Edificio 203
Urb. Country Club
RIO PIEDRAS, Puerto Rico
Tel: (809) 762-7255
A,CH,CS

QATAR

Computearbia
P.O. Box 2750
DOHA
Tel: 883555
Telex: 4806 CHPARB
P
Eastern Technical Services
P.O. Box 4747
DOHA
Tel: 329 993
Telex: 4156 EASTEC DH

Nasser Trading & Contracting
P.O. Box 1563
DOHA
Tel: 22170, 23539
Telex: 4439 NASSER DH
M

SAUDI ARABIA

Modern Electronic Establishment
Hewlett-Packard Division
P.O. Box 281
Thuobah
AL-KHOBAR
Tel: 864-46 78
Telex: 671 106 HPMEEK SJ
Cable: ELECTA AL-KHOBAR
CH,CS,E,M,P

Modern Electronic Establishment
Hewlett-Packard Division
P.O. Box 1228
Redec Plaza, 6th Floor
JEDDAH
Tel: 644 38 48
Telex: 4027 12 FARNAS SJ
Cable: ELECTA JEDDAH
CH,CS,E,M,P

Modern Electronic Establishment
Hewlett-Packard Division
P.O. Box 2728
RIYADH
Tel: 491-97 15, 491-63 87
Telex: 202049 MEERYD SJ
CH,CS,E,M,P

SCOTLAND

See United Kingdom

SINGAPORE

Hewlett-Packard Singapore (Sales)
Pte. Ltd.
P.O. Box 58 Alexandra Post Office
SINGAPORE, 91115
6th Floor, Inchcape House
450-452 Alexandra Road
SINGAPORE 05111
Tel: 631788
Telex: HPSGSO RS 34209
Cable: HEWPACK, Singapore
A,CH,CS,E,MS,P
Dynamar International Ltd.
Unit 05-11 Block 6
Kolam Ayer Industrial Estate
SINGAPORE 1334
Tel: 747-6188
Telex: RS 26283
CM

SOUTH AFRICA

Hewlett-Packard So Africa (Pty.) Ltd.
P.O. Box 120
Howard Place **CAPE PROVINCE** 7450
Pine Park Center, Forest Drive, Pinelands
CAPE PROVINCE 7405
Tel: 53-7954
Telex: 57-20006
A,CH,CM,E,MS,P
Hewlett-Packard So Africa (Pty.) Ltd.
P.O. Box 37099
92 Overport Drive
DURBAN 4067
Tel: 28-4178, 28-4179, 28-4110
Telex: 6-22954
CH,CM

Hewlett-Packard So Africa (Pty.) Ltd.
6 Linton Arcade
511 Cape Road
Linton Grange
PORT ELIZABETH 6001
Tel: 041-302148
CH

Hewlett-Packard So Africa (Pty.) Ltd. P.O. Box 33345
Glenstantia 0010 **TRANSVAAL**
1st Floor East
Constantia Park Ridge Shopping Centre
Constantia Park
PRETORIA
Tel: 982043
Telex: 32163
CH,E

Hewlett-Packard So Africa (Pty.) Ltd.
Private Bag Wendywood
SANDTON 2144
Tel: 802-5111, 802-5125
Telex: 4-20877
Cable: HEWPACK Johannesburg
A,CH,CM,CS,E,MS,P

SPAIN

Hewlett-Packard Española S.A.
Calle Entenza, 321
E-BARCELONA 29
Tel: 322.24.51, 321.73.54
Telex: 52603 hpbee
A,CH,CS,E,MS,P

Hewlett-Packard Española S.A.
Calle San Vicente S/No
Edificio Albia II
E-BILBAO 1
Tel: 423.83.06
A,CH,E,MS
Hewlett-Packard Española S.A.
Cria. de la Coruña, Km. 16, 400
Las Rozas
E-MADRID
Tel: (1) 637.00.11
CH,CS,M

Hewlett-Packard Española S.A.
Avda. S. Francisco Javier, S/no
Planta 10. Edificio Sevilla 2,
E-SEVILLA 5
Tel: 64.44.54
Telex: 72933
A,CS,MS,P

Hewlett-Packard Española S.A.
Calle Ramon Gorrillo, 1 (Entlo.3)
E-VALENCIA 10
Tel: 361-1354
CH,P

SWEDEN

Hewlett-Packard Sverige AB
Sunnanvagen 14K
S-22226 LUND
Tel: (046) 13-69-79
Telex: (854) 17886 (via Spånga office)
CH
Hewlett-Packard Sverige AB
Vastra Vintergatan 9
S-70344 ÖREBRO
Tel: (19) 10-48-80
Telex: (854) 17886 (via Spånga office)
CH

Hewlett-Packard Sverige AB
Skalholtsgatan 9, Kista
Box 19
S-16393 SPÅNGA
Tel: (08) 750-2000
Telex: (854) 17886
A,CH,CM,CS,E,MS,P
Hewlett-Packard Sverige AB
Frötallisgatan 30
S-42132 VÄSTRA-FRÖLUNDA
Tel: (031) 49-09-50
Telex: (854) 17886 (via Spånga office)
CH,E,P

SWITZERLAND

Hewlett-Packard (Schweiz) AG
Clarastrasse 12
CH-4058 BASLE
Tel: (61) 33-59-20
A

Hewlett-Packard (Schweiz) AG
7, rue du Bois-du-Lan
Case Postale 365
CH-1217 MEYRIN 1
Tel: (0041) 22-83-11-11
Telex: 27333 HPAG CH
CH,CM,CS

Hewlett-Packard (Schweiz) AG
Allmend 2
CH-8967 WIDEN
Tel: (0041) 57 31 21 11
Telex: 53933 hpag ch
Cable: HPAG CH
A,CH,CM,CS,E,MS,P

SYRIA

General Electronic Inc.
Nuri Basha P.O. Box 5781
DAMASCUS
Tel: 33-24-87
Telex: 11216 ITIKAL SY
Cable: ELECTROBOR DAMASCUS
E
Middle East Electronics
Place Azmé
P.O. Box 2308
DAMASCUS
Tel: 334592
Telex: 11304 SATACO SY
M,P

TAIWAN

Hewlett-Packard Far East Ltd.
Kaohsiung Office
2/F 68-2, Chung Cheng 3rd Road
KAOHSIUNG
Tel: 241-2318, 261-3253
CH,CS,E

Hewlett-Packard Far East Ltd.
Taiwan Branch
5th Floor
205 Tun Hwa North Road
TAIPEI
Tel: (02) 712-0404
Cable: HEWPACK Taipei
A,CH,CM,CS,E,M,P
Ing Lih Trading Co.
3rd Floor, 7 Jen-Ai Road, Sec. 2
TAIPEI 100
Tel: (02) 3948191
Cable: INGLIH TAIPEI
A

THAILAND

Unimesa
30 Palpong Ave., Suriwong
BANGKOK 5
Tel: 235-5727
Telex: 84439 Simonco TH
Cable: UNIMESA Bangkok
A,CH,CS,E,M
Bangkok Business Equipment Ltd.
5/5-6 Dejo Road
BANGKOK
Tel: 234-8670, 234-8671
Telex: 87669-BEQUIPT TH
Cable: BUSIQUIPT Bangkok
P

TRINIDAD & TOBAGO

Caribbean Telecoms Ltd.
50/A Jerningham Avenue
P.O. Box 732
PORT-OF-SPAIN
Tel: 62-44213, 62-44214
Telex: 235,272 HUGCO WG
CM,E,M,P

TUNISIA

Tunisie Electronique
31 Avenue de la Liberté
TUNIS
Tel: 280-144
E,P
Corema
1 ter. Av. de Carthage
TUNIS
Tel: 253-821
Telex: 12319 CABAM TN
M

TURKEY

Teknim Company Ltd.
Iran Caddesi No. 7
Kavaklidere, **ANKARA**
Tel: 275800
Telex: 42155 TKNM TR
E
E.M.A.
Medina Eldem Sokak No.41/6
Yüksel Caddesi
ANKARA
Tel: 175 622
M

UNITED ARAB EMIRATES

Emilat Ltd.
P.O. Box 1641
SHARJAH
Tel: 354121, 354123
Telex: 68136 Emilat Sh
CH,CS,E,M,P

UNITED KINGDOM

GREAT BRITAIN
Hewlett-Packard Ltd.
Trafalgar House
Navigation Road
ALTRINCHAM
Cheshire WA14 1NU
Tel: (061) 928-6422
Telex: 668068
A,CH,CS,E,M
Hewlett-Packard Ltd.
Oakfield House, Oakfield Grove
Clifton
BRISTOL BS8 2BN, Avon
Tel: (027) 38606
Telex: 444302
CH,M,P

SALES & SUPPORT OFFICES

Arranged alphabetically by country

5



GREAT BRITAIN (Cont'd)

Hewlett-Packard Ltd.
Fourier House
257-263 High Street
LONDON COLNEY
Herts., AL2 1HA, St. Albans
Tel: (0727) 24400
Telex: 1-8952716
CH,CS,E

Hewlett-Packard Ltd.
Quadrangle
106-118 Station Road
REDHILL, Surrey
Tel: (0737) 68655
Telex: 947234
CH,CS,E

Hewlett-Packard Ltd.
Avon House
435 Stratford Road
SHIRLEY, Solihull
West Midlands B90 4BL
Tel: (021) 745 8800
Telex: 339105
CH

Hewlett-Packard Ltd.
West End House 41
High Street, West End
SOUTHAMPTON
Hampshire SO3 3DQ
Tel: (703) 886767
Telex: 477138
CH

Hewlett-Packard Ltd.
King Street Lane
WINNERSH, Wokingham
Berkshire RG11 5AR
Tel: (0734) 784774
Telex: 847178
A,CH,E,M

Hewlett-Packard Ltd.
Nine Mile Ride
WOKINGHAM
Berkshire, RG11 3LL
Tel: 3446 3100
Telex: 84-88-05
CH,CS,E

NORTHERN IRELAND

Cardiac Services Company
95A Finaghy Road South
BELFAST BT 10 0BY
Tel: (0232) 625-566
Telex: 747626
M

SCOTLAND

Hewlett-Packard Ltd.
SOUTH QUEENSFERRY
West Lothian, EH30 9GT
Tel: (031) 3311188
Telex: 72682
A,CH,CM,CS,E,M

UNITED STATES

Alabama

Hewlett-Packard Co.
P.O. Box 7000
8290 Whitesburg Drive, S.E.
HUNTSVILLE, AL 35802
Tel: (205) 830-2000
CH,CM,CS,E,M*

Arizona

Hewlett-Packard Co.
8080 Point Parkway West
PHOENIX, AZ 85044
Tel: (602) 273-8000
A,CH,CM,CS,E,MS

Hewlett-Packard Co.
2424 East Aragon Road
TUCSON, AZ 85706
Tel: (602) 889-4631
CH,E,MS**

California

Hewlett-Packard Co.
99 South Hill Dr.
4BRISBANE, CA 94005
Tel: (415) 330-2500
CH,CS

Hewlett-Packard Co.
7621 Canoga Avenue
CANOGA PARK, CA 91304
Tel: (213) 702-8363
A,CH,CS,E,P

Hewlett-Packard Co.
P.O. Box 7830 (93747)
5060 E. Clinton Avenue, Suite 102
FRESNO, CA 93727
Tel: (209) 252-9652
CH,CS,MS

Hewlett-Packard Co.
P.O. Box 4230
1430 East Orangethorpe
FULLERTON, CA 92631
Tel: (714) 870-1000
CH,CM,CS,E,MP

Hewlett-Packard Co.
320 S. Kellogg, Suite B
GOLETA, CA 93117
Tel: (805) 967-3405
CH

Hewlett-Packard Co.
5400 W. Rosecrans Boulevard
LAWDALE, CA 90260
P.O. Box 92105
LOS ANGELES, CA 90009
Tel: (213) 970-7500

Telex: 910-325-6608
CH,CM,CS,MP

Hewlett-Packard Co.
3200 Hillview Avenue
PALO ALTO, CA 94304
Tel: (415) 857-8000
CH,CS,E

Hewlett-Packard Co.
P.O. Box 15976 (95813)
4244 So. Market Court, Suite A
SACRAMENTO, CA 95834
Tel: (916) 929-7222
A*,CH,CS,E,MS

Hewlett-Packard Co.
9606 Aero Drive
P.O. Box 23333 **SAN DIEGO, CA 92123**
Tel: (619) 279-3200
CH,CM,CS,E,MP

Hewlett-Packard Co.
2305 Camino Ramon "C"
SAN RAMON, CA 94583
Tel: (415) 838-5900
CH,CS

Hewlett-Packard Co.
P.O. Box 4230
Fullerton, CA 92631
363 Brookhollow Drive
SANTA ANA, CA 92705
Tel: (714) 641-0977

A,CH,CM,CS,MP
Hewlett-Packard Co.
3003 Scott Boulevard
SANTA CLARA, CA 95050
Tel: (408) 988-7000
Telex: 910-338-0586
A,CH,CM,CS,E,MP

Hewlett-Packard Co.
5703 Corsa Avenue
WESTLAKE VILLAGE, CA 91362
Tel: (213) 706-6800
E*,CH*,CS*

Colorado

Hewlett-Packard Co.
24 Inverness Place, East
ENGLEWOOD, CO 80112
Tel: (303) 771-3455
Telex: 910-935-0785
A,CH,CM,CS,E,MS

Connecticut

Hewlett-Packard Co.
47 Barnes Industrial Road South
P.O. Box 5007
WALLINGFORD, CT 06492
Tel: (203) 265-7801
A,CH,CM,CS,E,MS

Florida

Hewlett-Packard Co.
P.O. Box 24210 (33307)
2901 N.W. 62nd Street
FORT LAUDERDALE, FL 33309
Tel: (305) 973-2600
CH,CS,E,MP

Hewlett-Packard Co.
P.O. Box 13910
6177 Lake Ellenor Drive
ORLANDO, FL 32809
Tel: (305) 859-2900
A,CH,CM,CS,E,MS

Hewlett-Packard Co.
5750B N. Hoover Blvd., Suite 123
TAMPA, FL 33614
Tel: (813) 884-3282
A*,CH,CM,CS,E*,M*

Georgia

Hewlett-Packard Co.
P.O. Box 105005
30348 **ATLANTA, GA 2000** South Park Place
ATLANTA, GA 30339
Tel: (404) 955-1500
Telex: 810-766-4890
A,CH,CM,CS,E,MP

Hawaii

Hewlett-Packard Co.
Kawaihahao Plaza, Suite 190
567 South King Street
HONOLULU, HI 96813
Tel: (808) 526-1555
A,CH,E,MS

Illinois

Hewlett-Packard Co.
P.O. Box 1607
304 Eldorado Road
BLOOMINGTON, IL 61701
Tel: (309) 662-9411
CH,MS**

Hewlett-Packard Co.
1100 31st Street, Suite 100
DOWNERS GROVE, IL 60515
Tel: (312) 960-5760
CH,CS

Hewlett-Packard Co.
5201 Tollview Drive
ROLLING MEADOWS, IL 60008
Tel: (312) 255-9800
Telex: 910-687-1066
A,CH,CM,CS,E,MP

Indiana

Hewlett-Packard Co.
P.O. Box 50807
7301 No. Shadeland Avenue
INDIANAPOLIS, IN 46250
Tel: (317) 842-1000
A,CH,CM,CS,E,MS

Iowa

Hewlett-Packard Co.
1776 22nd Street, Suite 1
WEST DES MOINES, IA 50262
Tel: (515) 224-1435
CH,MS**

Hewlett-Packard Co.
2415 Heinz Road
IOWA CITY, IA 52240
Tel: (319) 351-1020
CH,E*,MS

Kansas

Hewlett-Packard Co.
7804 East Funston Road
Suite 203
WICHITA, KA 67207
Tel: (316) 684-8491
CH

Kentucky

Hewlett-Packard Co.
10300 Linn Station Road
Suite 100
LOUISVILLE, KY 40223
Tel: (502) 426-0100
A,CH,CS,MS

Louisiana

Hewlett-Packard Co.
P.O. Box 1449
KENNER, LA 70063
160 James Drive East
ST. ROSE, LA 70087
Tel: (504) 467-4100
A,CH,CS,E,MS

Maryland

Hewlett-Packard Co.
3701 Koppers Street
BALTIMORE, Md. 21227
Tel: (301) 644-5800
Telex: 710-862-1943
A,CH,CM,CS,E,MS
Hewlett-Packard Co.
2 Choke Cherry Road
ROCKVILLE, MD 20850
Tel: (301) 948-6370
A,CH,CM,CS,E,MP

Massachusetts

Hewlett-Packard Co.
32 Hartwell Avenue
LEXINGTON, MA 02173
Tel: (617) 861-8960
A,CH,CM,CS,E,MP

Michigan

Hewlett-Packard Co.
23855 Research Drive
FARMINGTON HILLS, MI 48024
Tel: (313) 476-6400
A,CH,CM,CS,E,MP

Hewlett-Packard Co.
4326 Cascade Road S.E.
GRAND RAPIDS, MI 49506
Tel: (616) 957-1970
CH,CS,MS

Hewlett-Packard Co.
1771 W. Big Beaver Road
TROY, MI 48084
Tel: (313) 643-6474
CH,CS

Minnesota

Hewlett-Packard Co.
2025 W. Larpenteur Ave.
ST. PAUL, MN 55113
Tel: (612) 644-1100
A,CH,CM,CS,E,MP

Missouri

Hewlett-Packard Co.
11131 Colorado Avenue
KANSAS CITY, MO 64137
Tel: (816) 763-8000
A,CH,CM,CS,E,MS

Hewlett-Packard Co.
13001 Hollenberg Drive
BRIDGETON, MO 63044
Tel: (314) 344-5100
A,CH,CS,E,MP

Nebraska

Hewlett-Packard
10824 Old Mill Rd., Suite 3
OMAHA, NE 68154
Tel: (402) 334-1813
CM,MS

New Jersey

Hewlett-Packard Co.
W120 Century Road
PARAMUS, NJ 07652
Tel: (201) 265-5000
A,CH,CM,CS,E,MP

Hewlett-Packard Co.
60 New England Av. West
PISCATAWAY, NJ 08854
Tel: (201) 981-1199
A,CH,CM,CS,E

New Mexico

Hewlett-Packard Co.
P.O. Box 11634 (87192)
11300 Lomas Blvd., N.E.
ALBUQUERQUE, NM 87112
Tel: (505) 292-1330
CH,CS,E,MS

New York

Hewlett-Packard Co.
Computer Drive South
ALBANY, NY 12205
Tel: (518) 458-1550
Telex: 710-444-4691
A,CH,E,MS

Hewlett-Packard Co.
P.O. Box AC
9600 Main Street
CLARENCE, NY 14031
Tel: (716) 759-8621
CH

Hewlett-Packard Co.
200 Cross Keys Office Park
FAIRPORT, NY 14450
Tel: (716) 223-9950
CH,CM,CS,E,MS

Hewlett-Packard Co.
7641 Henry Clay Blvd.
LIVERPOOL, NY 13088
Tel: (315) 451-1820
A,CH,CM,E,MS

Hewlett-Packard Co.
No. 1 Pennsylvania Plaza
55th Floor
34th Street & 8th Avenue
MANHATTAN NY 10001
Tel: (212) 971-0800
CH,CS,E*,M*

Hewlett-Packard Co.
250 Westchester Avenue
WHITE PLAINS, NY 10604
Tel: (914) 328-0884
CM,CH,CS,E

Hewlett-Packard Co.
3 Crossways Park West
WOODBURY, NY 11797
Tel: (516) 921-0300
Telex: 510-221-2183
A,CH,CM,CS,E,MS



SALES & SUPPORT OFFICES

Arranged alphabetically by country

UNITED STATES (Cont'd)

North Carolina

Hewlett-Packard Co.
P.O. Box 26500 (27420)
5605 Roanne Way
GREENSBORO, NC 27409
Tel: (919) 852-1800
A,CH,CM,CS,E,MS

Ohio

Hewlett-Packard Co.
9920 Carver Road
CINCINNATI, OH 45242
Tel: (513) 891-9870
CH,CS,MS

Hewlett-Packard Co.
16500 Sprague Road
CLEVELAND, OH 44130
Tel: (216) 243-7300
A,CH,CM,CS,E,MS

Hewlett-Packard Co.
962 Crupper Ave.
COLUMBUS, OH 43229
Tel: (614) 436-1041
CH,CM,CS,E*

Hewlett-Packard Co.
P.O. Box 280
330 Progress Rd.
DAYTON, OH 45449
Tel: (513) 859-8202
A,CH,CM,E*,MS

Oklahoma

Hewlett-Packard Co.
P.O. Box 75609 (73147)
304 N. Meridian, Suite A
3
OKLAHOMA CITY, OK 73107
Tel: (405) 946-9499
A*,CH,E*,MS

Hewlett-Packard Co.
3840 S. 103rd E. Avenue
Logan Building, Suite 100
TULSA, OK 74145
Tel: (918) 665-3300
A** ,CH,CS,M*

Oregon

Hewlett-Packard Co.
9255 S. W. Pioneer Court
WILSONVILLE, OR 97070
Tel: (503) 682-8000
A,CH,CS,E*,MS

Pennsylvania

Hewlett-Packard Co.
1021 8th Avenue
KING OF PRUSSIA, PA 19046
Tel: (215) 265-7000
A,CH,CM,CS,E,MP

Hewlett-Packard Co.
111 Zeta Drive
PITTSBURGH, PA 15238
Tel: (412) 782-0400
A,CH,CS,E,MP

South Carolina

Hewlett-Packard Co.
P.O. Box 21708 (29221)
Brookside Park, Suite 122
1 Harbison Way
COLUMBIA, SC 29210
Tel: (803) 732-0400
CH,E,MS

Tennessee

Hewlett-Packard Co.
3070 Directors Row
MEMPHIS, TN 38131
Tel: (901) 346-8370
A,CH,MS

Texas

Hewlett-Packard Co.
Suite C-110
4171 North Mesa
EL PASO, TX 79902
Tel: (915) 533-3555
CH,E*,MS**

Hewlett-Packard Co.
P.O. Box 42816 (77042)
10535 Harwin Street
HOUSTON, TX 77036
Tel: (713) 776-6400
A,CH,CM,CS,E,MP

Hewlett-Packard Co.
P.O. Box 1270
930 E. Campbell Rd.
RICHARDSON, TX 75080
Tel: (214) 231-6101
A,CH,CM,CS,E,MP

Hewlett-Packard Co.
P.O. Box 32993 (78216)
1020 Central Parkway South
SAN ANTONIO, TX 78232
Tel: (512) 494-9336
CH,CS,E,MS

Utah

Hewlett-Packard Co.
P.O. Box 26626 (84126)
3530 W. 2100 South
SALT LAKE CITY, UT 84119
Tel: (801) 974-1700
A,CH,CS,E,MS

Virginia

Hewlett-Packard Co.
P.O. Box 9669 (23228)
RICHMOND, Va. 23228
4305 Cox Road
GLEN ALLEN, Va. 23060
Tel: (804) 747-7750
A,CH,CS,E,MS

Washington

Hewlett-Packard Co.
158 15 S.E. 37th Street
BELLEVUE, WA 98006
Tel: (206) 643-4000
A,CH,CM,CS,E,MP
Hewlett-Packard Co.
Suite A
708 North Argonne Road
SPOKANE, WA 99206
Tel: (509) 922-7000
CH,CS

West Virginia

Hewlett-Packard Co.
P.O. Box 4297
4604 MacCorkle Ave., S.E.
CHARLESTON, WV 25304
Tel: (304) 925-0492
A,MS

Wisconsin

Hewlett-Packard Co.
150 S. Sunny Slope Road
BROOKFIELD, WI 53005
Tel: (414) 784-8800
A,CH,CS,E*,MP

URUGUAY

Pablo Ferrando S.A.C. e I.
Avenida Italia 2877
Casilla de Correo 370
MONTEVIDEO
Tel: 80-2586
Telex: Public Booth 901
A,CM,E,M

VENEZUELA

Hewlett-Packard de Venezuela C.A.
3A Transversal Los Ruices Norte
Edificio Segre
Apartado 50933
CARACAS 1071
Tel: 239-4133
Telex: 25146 HEWPACK
A,CH,CS,E,MS,P

Hewlett-Packard de Venezuela C.A.
Calle 72-Entre 3H Y 3Y, No.3H-40
Edificio Ada-Evelyn, Local B
Apartado 2646
MARACAIBO, Estado Zulia
Tel: (061) 80.304
C,E*

Hewlett-Packard de Venezuela C.A.
Calle Vargas Rondon
Edificio Seguros Carabobo, Piso 10
VALENCIA
Tel:(041) 51 385
CH,CS,P

Colimodio S.A.
Este 2 - Sur 21 No. 148
Apartado 1053
CARACAS 1010
Tel: 571-3511
Telex: 21529 COLMODIO
M

ZIMBABWE

Field Technical Sales
45 Kelvin Road, North
P.B. 3458
SALISBURY
Tel: 705 231
Telex: 4-122 RH
C,E,M,P

HEADQUARTERS OFFICES

If there is no sales office listed for your area, contact one of these headquarters offices.

NORTH/CENTRAL AFRICA

Hewlett-Packard S.A.
7 Rue du Bois-du-Lan
CH-1217 MEYRIN 1, Switzerland
Tel: (022) 83 12 12
Telex: 27835 hpse
Cable: HEWPACKSA Geneve

ASIA

Hewlett-Packard Asia Ltd.
6th Floor, Sun Hung Kai Centre
30 Harbour Rd.
G.P.O. Box 795
HONG KONG
Tel: 5-832 3211
Telex: 66678 HEWPA HX
Cable: HEWPACK HONG KONG

CANADA

Hewlett-Packard (Canada) Ltd.
6877 Goreway Drive
MISSISSAUGA, Ontario L4V 1M8
Tel: (416) 678-9430
Telex: 610-492-4246

EASTERN EUROPE

Hewlett-Packard Ges.m.b.h.
Liebiggasse 1
P.O.Box 72
A-1222 VIENNA, Austria
Tel: (222) 2365110
Telex: 1 3 4425 HEPA A

NORTHERN EUROPE

Hewlett-Packard S.A.
Uilenstede 475
NL-1183 AG AMSTELVEEN
The Netherlands
P.O.Box 999
NL-1180 AZ AMSTELVEEN
The Netherlands
Tel: 20 437771

OTHER EUROPE

Hewlett-Packard S.A.
7 rue du Bois-du-Lan
CH-1217 MEYRIN 1, Switzerland
Tel: (022) 83 12 12
Telex: 27835 hpse
Cable: HEWPACKSA Geneve

MEDITERRANEAN AND MIDDLE EAST

Hewlett-Packard S.A.
Mediterranean and Middle East
Operations
Atrina Centre
32 Kifissias Ave.
Maroussi, ATHENS, Greece
Tel: 682 88 11
Telex: 21-6588 HPAT GR
Cable: HEWPACKSA Athens

EASTERN USA

Hewlett-Packard Co.
4 Choce Cherry Road
Rockville, MD 20850
Tel: (301) 258-2000

MIDWESTERN USA

Hewlett-Packard Co.
5201 Tollview Drive
ROLLING MEADOWS, IL 60008
Tel: (312) 255-9800

SOUTHERN USA

Hewlett-Packard Co.
P.O. Box 105005
450 Interstate N. Parkway
ATLANTA, GA 30339
Tel: (404) 955-1500

WESTERN USA

Hewlett-Packard Co.
3939 Lankershim Blvd.
LOS ANGELES, CA 91604
Tel: (213) 877-1282

OTHER INTERNATIONAL AREAS

Hewlett-Packard Co.
Intercontinental Headquarters
3495 Deer Creek Road
PALO ALTO, CA 94304
Tel: (415) 857-1501
Telex: 034-8300
Cable: HEWPACK

March 1983 5952-6900

HP distributors are printed in italics.

