

PDP11

ASH
MD-11-DCKBI-B

EP-DCKBI-B-DL-A
COPYRIGHT © 1976
FICHE 1 OF 1

NOV 1976
digital
MADE IN USA

1	2	3	4	5	6
7	8	9	10	11	12
13	14	15	16	17	18
19	20	21	22	23	24
25	26	27	28	29	30
31	32	33	34	35	36
37	38	39	40	41	42
43	44	45	46	47	48
49	50	51	52	53	54
55	56	57	58	59	60
61	62	63	64	65	66
67	68	69	70	71	72
73	74	75	76	77	78
79	80	81	82	83	84
85	86	87	88	89	90
91	92	93	94	95	96
97	98	99	100	101	102

49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67
68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104

- 1.0 ABSTRACT
THIS PROGRAM WILL INCREMENTLY TEST AND ISOLATE SIMPLE MALFUNCTIONS RELATED TO THE ASH INSTRUCTION
- 2.0 REQUIREMENTS
- 2.1 EQUIPMENT
BASIC 11/45 SYSTEM OR
11/40 WITH KE11-E OPTION
- 2.2 STORAGE
THIS PROGRAM USES 0 THRU 17500
- 2.3 PRELIMINARY PROGRAMS
DOAA THRU DOMA
- 3.0 LOADING PROCEDURE
LOAD PROGRAM USING ABS LOADER
- 4.0 STARTING PROCEDURE
LOAD ADDRESS 200. PRESS START. THE PROGRAM WILL LOOP AND RING THE BELL, AND PRINT AN '*', ON PASS COMPLETION.
- 5.0 OPERATING PROCEDURE
- 5.1 SWITCH SETTINGS
NONE
- 5.2 SUBROUTINE ABSTRACTS
- 5.2.1 SCOPE
SCOPE IS A MOVE PC,R1 AND STORES THE PC+2 IN R1.
- 5.2.2 HLT
HLT IS A HALT INSTRUCTION.
- 6.0 ERRORS
ALL ERRORS WILL CAUSE A HALT
TRAP AND INTERRUPT ERRORS WILL CAUSE A HALT AT VECTOR+2.
- 6.1 ERROR RECOVERY
PRESS CONTINUE TO PROCEDE TO NEXT TEST
- 6.2 ERROR LOOPING
TO LOOP ON AN ERROR, PLACE A BRANCH TO THE PREVIOUS SCOPE INSTRUCTION IN PLACE OF THE HALT INSTRUCTION.
NOTE THAT IF THE ERROR IS INTERMITTANT THAT THE TEST WILL DROP THRU THE HALT AND PROCEED TO THE NEXT TEST.
THEREFORE, TO LOOP THE TEST CONTINUOSLY REPLACE THE BEQ .+4 INSTRUCTION IMMEDIATLY PRECEEDING THE HALT WITH A BRANCH BACK TO THE PREVIOUS SCOPE.

TO LOOP ON TRAP FAILURES, PATCH IN THE FOLLOWING ROUTINE AT THE ADDRESS OF THE TRAP VECTOR.

TRAPVEC: TRAPVEC+4
TRAPVEC+2: 0

105
106
107
108
109
110
111
112
113
114
115
116
117
118
119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142
143
144
145
146
147
148
149
150
151
152
153

TRAPVEC+4: 012716 ;MOVE SCOPE ADDRESS TO STACK
TRAPVEC+6: ADDRESS ;ADDRESS OF PREVIOUS SCOPE
TRAPVEC+10: 000006 ;RETURN TO TEST AT SCOPE

RESTORE ALL LOCATIONS BEFORE PROCEEDING TO NEXT TEST.

7.0 RESTRICTIONS
NONE

8.0 MISCELLANEOUS
ON TRAP ERRORS THE STACK POINTER(R6) WILL CONTAIN THE ADDRESS WHERE THE TRAP OCCURED.

8.1 EXECUTION TIME
THE PROGRAM TAKES ABOUT 1 MINUTE.

8.2 STACK POINTER
THIS PROGRAM INITIALLY SETS THE STACK POINTER AT 500.

9.0 PROGRAM DESCRIPTION

THIS IS A TEST OF THE ASH INSTRUCTION. IT TESTS ASH WITH DIFFERENT SHIFT COUNTS IN ALL THE REGISTERS.

9.1 NOTE: THE LAST ROUTINE IN THIS DIAGNOSTIC IS DESIGNED TO VERIFY THAT ECO M7238-0004/FCO M7238-0004 (11/40 ONLY) HAS BEEN IMPLEMENTED AND IS FUNCTIONING PROPERLY. THIS ECO/FCO AFFECTS THE 11/40 EIS (M7238) OPTION ONLY; THUS, ALL 11/45'S MUST PASS THIS ROUTINE. ALSO, THE ECO HAS BEEN PHASED INTO PRODUCTION SO ALL 11/40'S WITH THE M7238 MODULE MUST PASS THE ROUTINE IN MANUFACTURING.
FIELD SERVICE - ALL M7238 MODULES INCORPORATING THIS ECO OR FCO WILL HAVE CS REVISION E OR ABOVE AND MUST PASS THIS ROUTINE. ANY M7238 MODULE BELOW THIS CS REVISION LEVEL WILL FAIL THE ROUTINE. THIS IS ACCEPTABLE ONLY IF THE CUSTOMER SOFTWARE DOES NOT MAKE USE OF THE DECREMENTED OPERAND RESULTING FROM THE EXECUTION OF AN EXTENDED INSTRUCTION (ASH, ASHC, MUL, OR DIV) USING DESTINATION MODE FIVE. IF THE CUSTOMER SOFTWARE DOES MAKE USE OF THIS DECREMENTED OPERAND THEN FCO M7238-0004 (CS REV. E) MUST BE INCORPORATED AND THE LAST ROUTINE IN THE DIAGNOSTIC MUST PASS. IF THE FIELD SERVICE TECHNICIAN HAS DETERMINED FROM THE ABOVE CRITERIA THAT A PARTICULAR M7238 MODULE IS NOT REQUIRED TO PASS THE LAST ROUTINE, THEN HE MAY INSERT THE APPROPRIATE CODE TO JUMP FROM THE 'SCOPE' INSTRUCTION TO 'ENDPAS', THUS BYPASSING THE ROUTINE. SEE THE ECO OR FCO FOR MORE INFORMATION.

%

.TITLE MAINDEC-11-DCKBI-B ASH TEST
;COPYRIGHT 1972,1976 DIGITAL EQUIPMENT CORP., MAYNARD, MASS
;PROGRAM BY BOB BRAIN

177564
177566

.ENABL ABS
TPS= 177564
TPB= 177566

010701
000000
177776
177570
177570
000001
000000
000000

SCOPE= 10701
HLT= HALT
PS= 177776
SWR= 177570
DISPLAY=SWR
N= 1
DUMMY= HALT
M=0

000000

. = 0

; TRAP CATCHER 0 - 776

000046

000046
013730

. = 46
SENDAD

000052

000052
000000

. = 52
0

000200

000200
000167

000576

. = 200

JMP BEG1

001000

001000
000000

. = 1000
ICNT: 0

001002

023727

000042

013730

BEG1:

0
CMP 2#42, #SENDAD

; PASS COUNT
; AUTOMATIC MODE?
; YES, SKIP HEADER

001010

001412

001012

012705

013756

001016

105737

177564

IS:

MOV #MSG1, RS
TSTB 2#TPS

; GET ADDRESS OF PRINT MESSAGE
; CHECK FOR READY

001022

100375

001024

105715

001026

001403

001030

112537

177566

BPL -4
TSTB (5)
BEQ BEG
MOVB (5)+, 2#TPB

; END OF MESSAGE?
; YES, GO START TEST
; PRINT CHARACTER

001036

012706

000500

BEG:

MOV #500, %6

; ** STACK AT 500 **

001042

005037

177776

001046

032737

001000

177570

CLR 2#PS
BIT #1000, 2#SWR

; WHICH REGISTER SET?

001054

001403

001056

012737

004000

177776

001064

032737

000400

177570

BEQ .+10
MOV #4000, 2#PS
BIT #400, 2#SWR

; ALTERNATE!
; LOAD UB REG??

001072

001403

001074

113737

177570

177770

MOVB 2#SWR, 2#177770

:TEST 1 ASH 0 SHIFTED BY -16. = 0 PS = 4

001102	010701			SCOPE		
001104	012700	000000		MOV	#0,%0	;LOAD RO WITH 0
001110	072027	177760		ASH	#-16,%0	;SHIFT RO BY -16.
001114	013767	177776	012622	MOV	2#PS,PSW	;SAVE PS
001122	122767	000004	012614	CMPB	#4,PSW	;IS THE PS 4?
001130	001401			BEQ	.+4	
001132	000000			HLT		;THE PS IS NOT EQUAL TO 4
001134	022700	000000		CMP	#0,%0	;IS THE RESULT 0?
001140	001401			BEQ	.+4	
001142	000000			HLT		;RO IS NOT EQUAL TO 0

:TEST 2 ASH 0 SHIFTED BY 0 = 0 PS = 4

001144	010701			SCOPE		
001146	012700	000000		MOV	#0,%0	;LOAD RO WITH 0
001152	072027	000000		ASH	#0,%0	;SHIFT RO BY 0
001156	013767	177776	012560	MOV	2#PS,PSW	;SAVE PS
001164	122767	000004	012552	CMPB	#4,PSW	;IS THE PS 4?
001172	001401			BEQ	.+4	
001174	000000			HLT		;THE PS IS NOT EQUAL TO 4
001176	022700	000000		CMP	#0,%0	;IS THE RESULT 0?
001202	001401			BEQ	.+4	
001204	000000			HLT		;RO IS NOT EQUAL TO 0

:TEST 3 ASH 0 SHIFTED BY 16. = 0 PS = 4

001206	010701			SCOPE		
001210	012700	000000		MOV	#0,%0	;LOAD RO WITH 0
001214	072027	000020		ASH	#16,%0	;SHIFT RO BY 16.
001220	013767	177776	012516	MOV	2#PS,PSW	;SAVE PS
001226	122767	000004	012510	CMPB	#4,PSW	;IS THE PS 4?
001234	001401			BEQ	.+4	
001236	000000			HLT		;THE PS IS NOT EQUAL TO 4
001240	022700	000000		CMP	#0,%0	;IS THE RESULT 0?
001244	001401			BEQ	.+4	
001246	000000			HLT		;RO IS NOT EQUAL TO 0

:TEST 4 ASH 1 SHIFTED BY 0 = 1 PS = 0

001250	010701			SCOPE		
001252	012700	000001		MOV	#1,%0	;LOAD RO WITH 1
001256	072027	000000		ASH	#0,%0	;SHIFT RO BY 0
001262	013767	177776	012454	MOV	2#PS,PSW	;SAVE PS
001270	122767	000000	012446	CMPB	#0,PSW	;IS THE PS 0?
001276	001401			BEQ	+.4	
001300	000000			HLT		;THE PS IS NOT EQUAL TO 0
001302	022700	000001		CMP	#1,%0	;IS THE RESULT 1?
001306	001401			BEQ	+.4	
001310	000000			HLT		;RO IS NOT EQUAL TO 1

:TEST 5 ASH 1 SHIFTED BY 1 = 2 PS = 0

001312	010701			SCOPE		
001314	012700	000001		MOV	#1,%0	;LOAD RO WITH 1
001320	072027	000001		ASH	#1,%0	;SHIFT RO BY 1
001324	013767	177776	012412	MOV	2#PS,PSW	;SAVE PS
001332	122767	000000	012404	CMPB	#0,PSW	;IS THE PS 0?
001340	001401			BEQ	+.4	
001342	000000			HLT		;THE PS IS NOT EQUAL TO 0
001344	022700	000002		CMP	#2,%0	;IS THE RESULT 2?
001350	001401			BEQ	+.4	
001352	000000			HLT		;RO IS NOT EQUAL TO 2

:TEST 6 ASH 1 SHIFTED BY 2 = 4 PS = 0

001354	010701			SCOPE		
001356	012700	000001		MOV	#1,%0	;LOAD RO WITH 1
001362	072027	000002		ASH	#2,%0	;SHIFT RO BY 2
001366	013767	177776	012350	MOV	2#PS,PSW	;SAVE PS
001374	122767	000000	012342	CMPB	#0,PSW	;IS THE PS 0?
001402	001401			BEQ	+.4	
001404	000000			HLT		;THE PS IS NOT EQUAL TO 0
001406	022700	000004		CMP	#4,%0	;IS THE RESULT 4?
001412	001401			BEQ	+.4	
001414	000000			HLT		;RO IS NOT EQUAL TO 4

:TEST 7 ASH 1 SHIFTED BY 3 = 10 PS = 0

001416	010701			SCOPE		
001420	012700	000001		MOV	#1,%0	;LOAD RO WITH 1
001424	072027	000003		ASH	#3,%0	;SHIFT RO BY 3
001430	013767	177776	012306	MOV	2#PS,PSW	;SAVE PS
001436	122767	000000	012300	CMPB	#0,PSW	;IS THE PS 0?
001444	001401			BEQ	.+4	
001446	000000			HLT		;THE PS IS NOT EQUAL TO 0
001450	022700	000010		CMP	#10,%0	;IS THE RESULT 10?
001454	001401			BEQ	.+4	
001456	000000			HLT		;RO IS NOT EQUAL TO 10

:TEST 10 ASH 1 SHIFTED BY 4 = 20 PS = 0

001460	010701			SCOPE		
001462	012700	000001		MOV	#1,%0	;LOAD RO WITH 1
001466	072027	000004		ASH	#4,%0	;SHIFT RO BY 4
001472	013767	177776	012244	MOV	2#PS,PSW	;SAVE PS
001500	122767	000000	012236	CMPB	#0,PSW	;IS THE PS 0?
001506	001401			BEQ	.+4	
001510	000000			HLT		;THE PS IS NOT EQUAL TO 0
001512	022700	000020		CMP	#20,%0	;IS THE RESULT 20?
001516	001401			BEQ	.+4	
001520	000000			HLT		;RO IS NOT EQUAL TO 20

:TEST 11 ASH 1 SHIFTED BY 5 = 40 PS = 0

001522	010701			SCOPE		
001524	012700	000001		MOV	#1,%0	;LOAD RO WITH 1
001530	072027	000005		ASH	#5,%0	;SHIFT RO BY 5
001534	013767	177776	012202	MOV	2#PS,PSW	;SAVE PS
001542	122767	000000	012174	CMPB	#0,PSW	;IS THE PS 0?
001550	001401			BEQ	.+4	
001552	000000			HLT		;THE PS IS NOT EQUAL TO 0
001554	022700	000040		CMP	#40,%0	;IS THE RESULT 40?
001560	001401			BEQ	.+4	
001562	000000			HLT		;RO IS NOT EQUAL TO 40

:TEST 12 ASH 1 SHIFTED BY 6 = 100 PS = 0

001564	010701			SCOPE		
001566	012700	000001		MOV	#1,%0	;LOAD RO WITH 1
001572	072027	000006		ASH	#6,%0	;SHIFT RO BY 6
001576	013767	177776	012140	MOV	2#PS,PSW	;SAVE PS
001604	122767	000000	012132	CMPB	#0,PSW	;IS THE PS 0?
001612	001401			BEQ	+.4	
001614	000000			HLT		;THE PS IS NOT EQUAL TO 0
001616	022700	000100		CMP	#100,%0	;IS THE RESULT 100?
001622	001401			BEQ	+.4	
001624	000000			HLT		;RO IS NOT EQUAL TO 100

:TEST 13 ASH 1 SHIFTED BY 7 = 200 PS = 0

001626	010701			SCOPE		
001630	012700	000001		MOV	#1,%0	;LOAD RO WITH 1
001634	072027	000007		ASH	#7,%0	;SHIFT RO BY 7
001640	013767	177776	012076	MOV	2#PS,PSW	;SAVE PS
001646	122767	000000	012070	CMPB	#0,PSW	;IS THE PS 0?
001654	001401			BEQ	+.4	
001656	000000			HLT		;THE PS IS NOT EQUAL TO 0
001660	022700	000200		CMP	#200,%0	;IS THE RESULT 200?
001664	001401			BEQ	+.4	
001666	000000			HLT		;RO IS NOT EQUAL TO 200

:TEST 14 ASH 1 SHIFTED BY 10 = 400 PS = 0

001670	010701			SCOPE		
001672	012700	000001		MOV	#1,%0	;LOAD RO WITH 1
001676	072027	000010		ASH	#10,%0	;SHIFT RO BY 10
001702	013767	177776	012034	MOV	2#PS,PSW	;SAVE PS
001710	122767	000000	012026	CMPB	#0,PSW	;IS THE PS 0?
001716	001401			BEQ	+.4	
001720	000000			HLT		;THE PS IS NOT EQUAL TO 0
001722	022700	000400		CMP	#400,%0	;IS THE RESULT 400?
001726	001401			BEQ	+.4	
001730	000000			HLT		;RO IS NOT EQUAL TO 400

:TEST 15 ASH 1 SHIFTED BY 11 = 1000 PS = 0

001732	010701			SCOPE		
001734	012700	000001		MOV	#1,%0	;LOAD RO WITH 1
001740	072027	000011		ASH	#11,%0	;SHIFT RO BY 11
001744	013767	177776	011772	MOV	3#PS,PSW	;SAVE PS
001752	122767	000000	011764	CMPB	#0,PSW	;IS THE PS 0?
001760	001401			BEQ	+.4	
001762	000000			HLT		;THE PS IS NOT EQUAL TO 0
001764	022700	001000		CMP	#1000,%0	;IS THE RESULT 1000?
001770	001401			BEQ	+.4	
001772	000000			HLT		;RO IS NOT EQUAL TO 1000

:TEST 16 ASH 1 SHIFTED BY 12 = 2000 PS = 0

001774	010701			SCOPE		
001776	012700	000001		MOV	#1,%0	;LOAD RO WITH 1
002002	072027	000012		ASH	#12,%0	;SHIFT RO BY 12
002006	013767	177776	011730	MOV	3#PS,PSW	;SAVE PS
002014	122767	000000	011722	CMPB	#0,PSW	;IS THE PS 0?
002022	001401			BEQ	+.4	
002024	000000			HLT		;THE PS IS NOT EQUAL TO 0
002026	022700	002000		CMP	#2000,%0	;IS THE RESULT 2000?
002032	001401			BEQ	+.4	
002034	000000			HLT		;RO IS NOT EQUAL TO 2000

:TEST 17 ASH 1 SHIFTED BY 13 = 4000 PS = 0

002036	010701			SCOPE		
002040	012700	000001		MOV	#1,%0	;LOAD RO WITH 1
002044	072027	000013		ASH	#13,%0	;SHIFT RO BY 13
002050	013767	177776	011666	MOV	3#PS,PSW	;SAVE PS
002056	122767	000000	011660	CMPB	#0,PSW	;IS THE PS 0?
002064	001401			BEQ	+.4	
002066	000000			HLT		;THE PS IS NOT EQUAL TO 0
002070	022700	004000		CMP	#4000,%0	;IS THE RESULT 4000?
002074	001401			BEQ	+.4	
002076	000000			HLT		;RO IS NOT EQUAL TO 4000

:TEST 20 ASH 1 SHIFTED BY 14 = 10000 PS = 0

002100	010701			SCOPE		
002102	012700	000001		MOV	#1,%0	;LOAD RO WITH 1
002106	072027	000014		ASH	#14,%0	;SHIFT RO BY 14
002112	013767	177776	011624	MOV	3#PS,PSW	;SAVE PS
002120	122767	000000	011616	CMPB	#0,PSW	;IS THE PS 0?
002126	001401			BEQ	+.4	
002130	000000			HLT		;THE PS IS NOT EQUAL TO 0
002132	022700	010000		CMP	#10000,%0	;IS THE RESULT 10000?
002136	001401			BEQ	+.4	
002140	000000			HLT		;RO IS NOT EQUAL TO 10000

:TEST 21 ASH 1 SHIFTED BY 15 = 20000 PS = 0

002142	010701			SCOPE		
002144	012700	000001		MOV	#1,%0	;LOAD RO WITH 1
002150	072027	000015		ASH	#15,%0	;SHIFT RO BY 15
002154	013767	177776	011562	MOV	3#PS,PSW	;SAVE PS
002162	122767	000000	011554	CMPB	#0,PSW	;IS THE PS 0?
002170	001401			BEQ	+.4	
002172	000000			HLT		;THE PS IS NOT EQUAL TO 0
002174	022700	020000		CMP	#20000,%0	;IS THE RESULT 20000?
002200	001401			BEQ	+.4	
002202	000000			HLT		;RO IS NOT EQUAL TO 20000

:TEST 22 ASH 1 SHIFTED BY 16 = 40000 PS = 0

002204	010701			SCOPE		
002206	012700	000001		MOV	#1,%0	;LOAD RO WITH 1
002212	072027	000016		ASH	#16,%0	;SHIFT RO BY 16
002216	013767	177776	011520	MOV	3#PS,PSW	;SAVE PS
002224	122767	000000	011512	CMPB	#0,PSW	;IS THE PS 0?
002232	001401			BEQ	+.4	
002234	000000			HLT		;THE PS IS NOT EQUAL TO 0
002236	022700	040000		CMP	#40000,%0	;IS THE RESULT 40000?
002242	001401			BEQ	+.4	
002244	000000			HLT		;RO IS NOT EQUAL TO 40000

:TEST 23 ASH 40000 SHIFTED BY 177762 = 1 PS = 0

002246	010701			SCOPE		
002250	012700	040000		MOV	#40000,%0	;LOAD RO WITH 40000
002254	072027	177762		ASH	#177762,%0	;SHIFT RO BY 177762
002260	013767	177776	011456	MOV	3#PS,PSW	;SAVE PS
002266	122767	000000	011450	CMPB	#0,PSW	;IS THE PS 0?
002274	001401			BEQ	+.4	
002276	000000			HLT		;THE PS IS NOT EQUAL TO 0
002300	022700	000001		CMP	#1,%0	;IS THE RESULT 1?
002304	001401			BEQ	+.4	
002306	000000			HLT		;RO IS NOT EQUAL TO 1

:TEST 24 ASH 40000 SHIFTED BY 177763 = 2 PS = 0

002310	010701			SCOPE		
002312	012700	040000		MOV	#40000,%0	;LOAD RO WITH 40000
002316	072027	177763		ASH	#177763,%0	;SHIFT RO BY 177763
002322	013767	177776	011414	MOV	3#PS,PSW	;SAVE PS
002330	122767	000000	011406	CMPB	#0,PSW	;IS THE PS 0?
002336	001401			BEQ	+.4	
002340	000000			HLT		;THE PS IS NOT EQUAL TO 0
002342	022700	000002		CMP	#2,%0	;IS THE RESULT 2?
002346	001401			BEQ	+.4	
002350	000000			HLT		;RO IS NOT EQUAL TO 2

:TEST 25 ASH 40000 SHIFTED BY 177764 = 4 PS = 0

002352	010701			SCOPE		
002354	012700	040000		MOV	#40000,%0	;LOAD RO WITH 40000
002360	072027	177764		ASH	#177764,%0	;SHIFT RO BY 177764
002364	013767	177776	011352	MOV	3#PS,PSW	;SAVE PS
002372	122767	000000	011344	CMPB	#0,PSW	;IS THE PS 0?
002400	001401			BEQ	+.4	
002402	000000			HLT		;THE PS IS NOT EQUAL TO 0
002404	022700	000004		CMP	#4,%0	;IS THE RESULT 4?
002410	001401			BEQ	+.4	
002412	000000			HLT		;RO IS NOT EQUAL TO 4

MO1

MAINDEC-11-DCKBI-B ASH TEST
DCKBIB.SRC

MACY11 27(732) 01-OCT-76 13:03 PAGE 13

```
*****  
:TEST 26 ASH 40000 SHIFTED BY 177765 = 10 PS = 0  
*****
```

002414	010701			SCOPE		
002416	012700	040000		MOV	#40000,%0	;LOAD R0 WITH 40000
002422	072027	177765		ASH	#177765,%0	;SHIFT R0 BY 177765
002426	013767	177776	011310	MOV	@#PS,PSW	;SAVE PS
002434	122767	000000	011302	CMPB	#0,PSW	;IS THE PS 0?
002442	001401			BEQ	.+4	
002444	000000			HLT		;THE PS IS NOT EQUAL TO 0
002446	022700	000010		CMP	#10,%0	;IS THE RESULT 10?
002452	001401			BEQ	.+4	
002454	000000			HLT		;R0 IS NOT EQUAL TO 10

```
*****  
:TEST 27 ASH 40000 SHIFTED BY 177766 = 20 PS = 0  
*****
```

002456	010701			SCOPE		
002460	012700	040000		MOV	#40000,%0	;LOAD R0 WITH 40000
002464	072027	177766		ASH	#177766,%0	;SHIFT R0 BY 177766
002470	013767	177776	011246	MOV	@#PS,PSW	;SAVE PS
002476	122767	000000	011240	CMPB	#0,PSW	;IS THE PS 0?
002504	001401			BEQ	.+4	
002506	000000			HLT		;THE PS IS NOT EQUAL TO 0
002510	022700	000020		CMP	#20,%0	;IS THE RESULT 20?
002514	001401			BEQ	.+4	
002516	000000			HLT		;R0 IS NOT EQUAL TO 20

```
*****  
:TEST 30 ASH 40000 SHIFTED BY 177767 = 40 PS = 0  
*****
```

002520	010701			SCOPE		
002522	012700	040000		MOV	#40000,%0	;LOAD R0 WITH 40000
002526	072027	177767		ASH	#177767,%0	;SHIFT R0 BY 177767
002532	013767	177776	011204	MOV	@#PS,PSW	;SAVE PS
002540	122767	000000	011176	CMPB	#0,PSW	;IS THE PS 0?
002546	001401			BEQ	.+4	
002550	000000			HLT		;THE PS IS NOT EQUAL TO 0
002552	022700	000040		CMP	#40,%0	;IS THE RESULT 40?
002556	001401			BEQ	.+4	
002560	000000			HLT		;R0 IS NOT EQUAL TO 40

:TEST 31 ASH 40000 SHIFTED BY 177770 = 100 PS = 0

002562	010701			SCOPE		
002564	012700	040000		MOV	#40000,%0	;LOAD RO WITH 40000
002570	072027	177770		ASH	#177770,%0	;SHIFT RO BY 177770
002574	013767	177776	011142	MOV	@#PS,PSW	;SAVE PS
002602	122767	000000	011134	CMPB	#0,PSW	;IS THE PS 0?
002610	001401			BEQ	+.4	
002612	000000			HLT		;THE PS IS NOT EQUAL TO 0
002614	022700	000100		CMP	#100,%0	;IS THE RESULT 100?
002620	001401			BEQ	+.4	
002622	000000			HLT		;RO IS NOT EQUAL TO 100

:TEST 32 ASH 40000 SHIFTED BY 177771 = 200 PS = 0

002624	010701			SCOPE		
002626	012700	040000		MOV	#40000,%0	;LOAD RO WITH 40000
002632	072027	177771		ASH	#177771,%0	;SHIFT RO BY 177771
002636	013767	177776	011100	MOV	@#PS,PSW	;SAVE PS
002644	122767	000000	011072	CMPB	#0,PSW	;IS THE PS 0?
002652	001401			BEQ	+.4	
002654	000000			HLT		;THE PS IS NOT EQUAL TO 0
002656	022700	000200		CMP	#200,%0	;IS THE RESULT 200?
002662	001401			BEQ	+.4	
002664	000000			HLT		;RO IS NOT EQUAL TO 200

:TEST 33 ASH 40000 SHIFTED BY 177772 = 400 PS = 0

002666	010701			SCOPE		
002670	012700	040000		MOV	#40000,%0	;LOAD RO WITH 40000
002674	072027	177772		ASH	#177772,%0	;SHIFT RO BY 177772
002700	013767	177776	011036	MOV	@#PS,PSW	;SAVE PS
002706	122767	000000	011030	CMPB	#0,PSW	;IS THE PS 0?
002714	001401			BEQ	+.4	
002716	000000			HLT		;THE PS IS NOT EQUAL TO 0
002720	022700	000400		CMP	#400,%0	;IS THE RESULT 400?
002724	001401			BEQ	+.4	
002726	000000			HLT		;RO IS NOT EQUAL TO 400

:TEST 34 ASH 40000 SHIFTED BY 177773 = 1000 PS = 0

002730	010701			SCOPE		
002732	012700	040000		MOV	#40000,%0	:LOAD RO WITH 40000
002736	072027	177773		ASH	#177773,%0	:SHIFT RO BY 177773
002742	013767	177776	010774	MOV	2#PS,PSW	:SAVE PS
002750	122767	000000	010766	CMPB	#0,PSW	:IS THE PS 0?
002756	001401			BEQ	+.4	
002760	000000			HLT		:THE PS IS NOT EQUAL TO 0
002762	022700	001000		CMP	#1000,%0	:IS THE RESULT 1000?
002766	001401			BEQ	+.4	
002770	000000			HLT		:RO IS NOT EQUAL TO 1000

:TEST 35 ASH 40000 SHIFTED BY 177774 = 2000 PS = 0

002772	010701			SCOPE		
002774	012700	040000		MOV	#40000,%0	:LOAD RO WITH 40000
003000	072027	177774		ASH	#177774,%0	:SHIFT RO BY 177774
003004	013767	177776	010732	MOV	2#PS,PSW	:SAVE PS
003012	122767	000000	010724	CMPB	#0,PSW	:IS THE PS 0?
003020	001401			BEQ	+.4	
003022	000000			HLT		:THE PS IS NOT EQUAL TO 0
003024	022700	002000		CMP	#2000,%0	:IS THE RESULT 2000?
003030	001401			BEQ	+.4	
003032	000000			HLT		:RO IS NOT EQUAL TO 2000

:TEST 36 ASH 40000 SHIFTED BY 177775 = 4000 PS = 0

003034	010701			SCOPE		
003036	012700	040000		MOV	#40000,%0	:LOAD RO WITH 40000
003042	072027	177775		ASH	#177775,%0	:SHIFT RO BY 177775
003046	013767	177776	010670	MOV	2#PS,PSW	:SAVE PS
003054	122767	000000	010662	CMPB	#0,PSW	:IS THE PS 0?
003062	001401			BEQ	+.4	
003064	000000			HLT		:THE PS IS NOT EQUAL TO 0
003066	022700	004000		CMP	#4000,%0	:IS THE RESULT 4000?
003072	001401			BEQ	+.4	
003074	000000			HLT		:RO IS NOT EQUAL TO 4000

:TEST 37 ASH 40000 SHIFTED BY 177776 = 10000 PS = 0

003076	010701			SCOPE		
003100	012700	040000		MOV	#40000,%0	;LOAD RO WITH 40000
003104	072027	177776		ASH	#177776,%0	;SHIFT RO BY 177776
003110	013767	177776	010626	MOV	2#PS,PSW	;SAVE PS
003116	122767	000000	010620	CMPB	#0,PSW	;IS THE PS 0?
003124	001401			BEQ	+.4	
003126	000000			HLT		;THE PS IS NOT EQUAL TO 0
003130	022700	010000		CMP	#10000,%0	;IS THE RESULT 10000?
003134	001401			BEQ	+.4	
003136	000000			HLT		;RO IS NOT EQUAL TO 10000

:TEST 40 ASH 40000 SHIFTED BY 177777 = 20000 PS = 0

003140	010701			SCOPE		
003142	012700	040000		MOV	#40000,%0	;LOAD RO WITH 40000
003146	072027	177777		ASH	#177777,%0	;SHIFT RO BY 177777
003152	013767	177776	010564	MOV	2#PS,PSW	;SAVE PS
003160	122767	000000	010556	CMPB	#0,PSW	;IS THE PS 0?
003166	001401			BEQ	+.4	
003170	000000			HLT		;THE PS IS NOT EQUAL TO 0
003172	022700	020000		CMP	#20000,%0	;IS THE RESULT 20000?
003176	001401			BEQ	+.4	
003200	000000			HLT		;RO IS NOT EQUAL TO 20000

:TEST 41 ASH 40000 SHIFTED BY 0 = 40000 PS = 0

003202	010701			SCOPE		
003204	012700	040000		MOV	#40000,%0	;LOAD RO WITH 40000
003210	072027	000000		ASH	#0,%0	;SHIFT RO BY 0
003214	013767	177776	010522	MOV	2#PS,PSW	;SAVE PS
003222	122767	000000	010514	CMPB	#0,PSW	;IS THE PS 0?
003230	001401			BEQ	+.4	
003232	000000			HLT		;THE PS IS NOT EQUAL TO 0
003234	022700	040000		CMP	#40000,%0	;IS THE RESULT 40000?
003240	001401			BEQ	+.4	
003242	000000			HLT		;RO IS NOT EQUAL TO 40000

: TEST 42 ASH 100000 SHIFTED BY -15. = -1 PS = 10

003244	010701			SCOPE		
003246	012700	100000		MOV	#100000,%0	;LOAD RO WITH 100000
003252	072027	177761		ASH	#-15,%0	;SHIFT RO BY -15.
003256	013767	177776	010460	MOV	2#PS,PSW	;SAVE PS
003264	122767	000010	010452	CMPB	#10,PSW	;IS THE PS 10?
003272	001401			BEQ	.+4	
003274	000000			HLT		;THE PS IS NOT EQUAL TO 10
003276	022700	177777		CMP	#-1,%0	;IS THE RESULT -1?
003302	001401			BEQ	.+4	
003304	000000			HLT		;RO IS NOT EQUAL TO -1

: TEST 43 ASH -1 SHIFTED BY 15. = 100000 PS = 11

003306	010701			SCOPE		
003310	012700	177777		MOV	#-1,%0	;LOAD RO WITH -1
003314	072027	000017		ASH	#15,%0	;SHIFT RO BY 15.
003320	013767	177776	010416	MOV	2#PS,PSW	;SAVE PS
003326	122767	000011	010410	CMPB	#11,PSW	;IS THE PS 11?
003334	001401			BEQ	.+4	
003336	000000			HLT		;THE PS IS NOT EQUAL TO 11
003340	022700	100000	:	CMP	#100000,%0	;IS THE RESULT 100000?
003344	001401			BEQ	.+4	
003346	000000			HLT		;RO IS NOT EQUAL TO 100000

: TEST 44 ASH -1 SHIFTED BY 16. = 0 PS = 7

003350	010701			SCOPE		
003352	012700	177777		MOV	#-1,%0	;LOAD RO WITH -1
003356	072027	000020		ASH	#16,%0	;SHIFT RO BY 16.
003362	013767	177776	010354	MOV	2#PS,PSW	;SAVE PS
003370	122767	000007	010346	CMPB	#7,PSW	;IS THE PS 7?
003376	001401			BEQ	.+4	
003400	000000			HLT		;THE PS IS NOT EQUAL TO 7
003402	022700	000000		CMP	#0,%0	;IS THE RESULT 0?
003406	001401			BEQ	.+4	
003410	000000			HLT		;RO IS NOT EQUAL TO 0

: TEST 45 ASH 137777 SHIFTED BY 15. = 100000 PS = 13
: *****

003412	010701			SCOPE		
003414	012700	137777		MOV	#137777,%0	;LOAD RO WITH 137777
003420	072027	000017		ASH	#15,%0	;SHIFT RO BY 15.
003424	013767	177776	010312	MOV	#PS,PSW	;SAVE PS
003432	122767	000013	010304	CMPB	#13,PSW	;IS THE PS 13?
003440	001401			BEQ	+.4	
003442	000000			HLT		;THE PS IS NOT EQUAL TO 13
003444	022700	100000		CMP	#100000,%0	;IS THE RESULT 100000?
003450	001401			BEQ	+.4	
003452	000000			HLT		;RO IS NOT EQUAL TO 100000

: TEST 46 ASH 125252 SHIFTED BY 1 = 52524 PS = 3
: *****

003454	010701			SCOPE		
003456	012700	125252		MOV	#125252,%0	;LOAD RO WITH 125252
003462	072027	000001		ASH	#1,%0	;SHIFT RO BY 1
003466	013767	177776	010250	MOV	#PS,PSW	;SAVE PS
003474	122767	000003	010242	CMPB	#3,PSW	;IS THE PS 3?
003502	001401			BEQ	+.4	
003504	000000			HLT		;THE PS IS NOT EQUAL TO 3
003506	022700	052524		CMP	#52524,%0	;IS THE RESULT 52524?
003512	001401			BEQ	+.4	
003514	000000			HLT		;RO IS NOT EQUAL TO 52524

: TEST 47 ASH 125252 SHIFTED BY -1 = 152525 PS = 10
: *****

003516	010701			SCOPE		
003520	012700	125252		MOV	#125252,%0	;LOAD RO WITH 125252
003524	072027	177777		ASH	#-1,%0	;SHIFT RO BY -1
003530	013767	177776	010206	MOV	#PS,PSW	;SAVE PS
003536	122767	000010	010200	CMPB	#10,PSW	;IS THE PS 10?
003544	001401			BEQ	+.4	
003546	000000			HLT		;THE PS IS NOT EQUAL TO 10
003550	022700	152525		CMP	#152525,%0	;IS THE RESULT 152525?
003554	001401			BEQ	+.4	
003556	000000			HLT		;RO IS NOT EQUAL TO 152525

:TEST 50 ASH 125252 SHIFTED BY -2 = 165252 PS = 11

003560	010701			SCOPE		
003562	012700	125252		MOV	#125252,%0	:LOAD R0 WITH 125252
003566	072027	177776		ASH	#-2,%0	:SHIFT R0 BY -2
003572	013767	177776	010144	MOV	@#PS,PSW	:SAVE PS
003600	122767	000011	010136	CMPB	#11,PSW	:IS THE PS 11?
003606	001401			BEQ	+.4	
003610	000000			HLT		:THE PS IS NOT EQUAL TO 11
003612	022700	165252		CMP	#165252,%0	:IS THE RESULT 165252?
003616	001401			BEQ	+.4	
003620	000000			HLT		:R0 IS NOT EQUAL TO 165252

:TEST 51 ASH 40000 SHIFTED BY 177762 = 1 PS = 0

003622	010701			SCOPE		
003624	012701	040000		MOV	#40000,%1	:LOAD R1 WITH 40000
003630	072127	177762		ASH	#177762,%1	:SHIFT R1 BY 177762
003634	013767	177776	010102	MOV	@#PS,PSW	:SAVE PS
003642	122767	000000	010074	CMPB	#0,PSW	:IS THE PS 0?
003650	001401			BEQ	+.4	
003652	000000			HLT		:THE PS IS NOT EQUAL TO 0
003654	022701	000001		CMP	#1,%1	:IS THE RESULT 1?
003660	001401			BEQ	+.4	
003662	000000			HLT		:R1 IS NOT EQUAL TO 1

:TEST 52 ASH 40000 SHIFTED BY 177763 = 2 PS = 0

003664	010701			SCOPE		
003666	012701	040000		MOV	#40000,%1	:LOAD R1 WITH 40000
003672	072127	177763		ASH	#177763,%1	:SHIFT R1 BY 177763
003676	013767	177776	010040	MOV	@#PS,PSW	:SAVE PS
003704	122767	000000	010032	CMPB	#0,PSW	:IS THE PS 0?
003712	001401			BEQ	+.4	
003714	000000			HLT		:THE PS IS NOT EQUAL TO 0
003716	022701	000002		CMP	#2,%1	:IS THE RESULT 2?
003722	001401			BEQ	+.4	
003724	000000			HLT		:R1 IS NOT EQUAL TO 2

:TEST 53 ASH 40000 SHIFTED BY 177764 = 4 PS = 0

003726	010701			SCOPE		
003730	012701	040000		MOV	#40000,%1	;LOAD R1 WITH 40000
003734	072127	177764		ASH	#177764,%1	;SHIFT R1 BY 177764
003740	013767	177776	007776	MOV	@#PS,PSW	;SAVE PS
003746	122767	000000	007770	CMPB	#0,PSW	;IS THE PS 0?
003754	001401			BEQ	+.4	
003756	000000			HLT		;THE PS IS NOT EQUAL TO 0
003760	022701	000004		CMP	#4,%1	;IS THE RESULT 4?
003764	001401			BEQ	+.4	
003766	000000			HLT		;R1 IS NOT EQUAL TO 4

:TEST 54 ASH 40000 SHIFTED BY 177765 = 10 PS = 0

003770	010701			SCOPE		
003772	012701	040000		MOV	#40000,%1	;LOAD R1 WITH 40000
003776	072127	177765		ASH	#177765,%1	;SHIFT R1 BY 177765
004002	013767	177776	007734	MOV	@#PS,PSW	;SAVE PS
004010	122767	000000	007726	CMPB	#0,PSW	;IS THE PS 0?
004016	001401			BEQ	+.4	
004020	000000			HLT		;THE PS IS NOT EQUAL TO 0
004022	022701	000010		CMP	#10,%1	;IS THE RESULT 10?
004026	001401			BEQ	+.4	
004030	000000			HLT		;R1 IS NOT EQUAL TO 10

:TEST 55 ASH 40000 SHIFTED BY 177766 = 20 PS = 0

004032	010701			SCOPE		
004034	012701	040000		MOV	#40000,%1	;LOAD R1 WITH 40000
004040	072127	177766		ASH	#177766,%1	;SHIFT R1 BY 177766
004044	013767	177776	007672	MOV	@#PS,PSW	;SAVE PS
004052	122767	000000	007664	CMPB	#0,PSW	;IS THE PS 0?
004060	001401			BEQ	+.4	
004062	000000			HLT		;THE PS IS NOT EQUAL TO 0
004064	022701	000020		CMP	#20,%1	;IS THE RESULT 20?
004070	001401			BEQ	+.4	
004072	000000			HLT		;R1 IS NOT EQUAL TO 20

:TEST 56 ASH 40000 SHIFTED BY 177767 = 40 PS = 0

004074	010701			SCOPE		
004076	012701	040000		MOV	#40000,%1	;LOAD R1 WITH 40000
004102	072127	177767		ASH	#177767,%1	;SHIFT R1 BY 177767
004106	013767	177776	007630	MOV	@#PS,PSW	;SAVE PS
004114	122767	000000	007622	CMPB	#0,PSW	;IS THE PS 0?
004122	001401			BEQ	+.4	
004124	000000			HLT		;THE PS IS NOT EQUAL TO 0
004126	022701	000040		CMP	#40,%1	;IS THE RESULT 40?
004132	001401			BEQ	+.4	
004134	000000			HLT		;R1 IS NOT EQUAL TO 40

:TEST 57 ASH 40000 SHIFTED BY 177770 = 100 PS = 0

004136	010701			SCOPE		
004140	012701	040000		MOV	#40000,%1	;LOAD R1 WITH 40000
004144	072127	177770		ASH	#177770,%1	;SHIFT R1 BY 177770
004150	013767	177776	007566	MOV	@#PS,PSW	;SAVE PS
004156	122767	000000	007560	CMPB	#0,PSW	;IS THE PS 0?
004164	001401			BEQ	+.4	
004166	000000			HLT		;THE PS IS NOT EQUAL TO 0
004170	022701	000100		CMP	#100,%1	;IS THE RESULT 100?
004174	001401			BEQ	+.4	
004176	000000			HLT		;R1 IS NOT EQUAL TO 100

:TEST 60 ASH 40000 SHIFTED BY 177771 = 200 PS = 0

004200	010701			SCOPE		
004202	012701	040000		MOV	#40000,%1	;LOAD R1 WITH 40000
004206	072127	177771		ASH	#177771,%1	;SHIFT R1 BY 177771
004212	013767	177776	007524	MOV	@#PS,PSW	;SAVE PS
004220	122767	000000	007516	CMPB	#0,PSW	;IS THE PS 0?
004226	001401			BEQ	+.4	
004230	000000			HLT		;THE PS IS NOT EQUAL TO 0
004232	022701	000200		CMP	#200,%1	;IS THE RESULT 200?
004236	001401			BEQ	+.4	
004240	000000			HLT		;R1 IS NOT EQUAL TO 200

: TEST 61 ASH 40000 SHIFTED BY 177772 = 400 PS = 0
: *****

004242	010701			SCOPE		
004244	012701	040000		MOV	#40000,%1	;LOAD R1 WITH 40000
004250	072127	177772		ASH	#177772,%1	;SHIFT R1 BY 177772
004254	013767	177776	007462	MOV	@#PS,PSW	;SAVE PS
004262	122767	000000	007454	CMPB	#0,PSW	;IS THE PS 0?
004270	001401			BEQ	+.4	
004272	000000			HLT		;THE PS IS NOT EQUAL TO 0
004274	022701	000400		CMP	#400,%1	;IS THE RESULT 400?
004300	001401			BEQ	+.4	
004302	000000			HLT		;R1 IS NOT EQUAL TO 400

: TEST 62 ASH 40000 SHIFTED BY 177773 = 1000 PS = 0
: *****

004304	010701			SCOPE		
004306	012701	040000		MOV	#40000,%1	;LOAD R1 WITH 40000
004312	072127	177773		ASH	#177773,%1	;SHIFT R1 BY 177773
004316	013767	177776	007420	MOV	@#PS,PSW	;SAVE PS
004324	122767	000000	007412	CMPB	#0,PSW	;IS THE PS 0?
004332	001401			BEQ	+.4	
004334	000000			HLT		;THE PS IS NOT EQUAL TO 0
004336	022701	001000		CMP	#1000,%1	;IS THE RESULT 1000?
004342	001401			BEQ	+.4	
004344	000000			HLT		;R1 IS NOT EQUAL TO 1000

: TEST 63 ASH 40000 SHIFTED BY 177774 = 2000 PS = 0
: *****

004346	010701			SCOPE		
004350	012701	040000		MOV	#40000,%1	;LOAD R1 WITH 40000
004354	072127	177774		ASH	#177774,%1	;SHIFT R1 BY 177774
004360	013767	177776	007356	MOV	@#PS,PSW	;SAVE PS
004366	122767	000000	007350	CMPB	#0,PSW	;IS THE PS 0?
004374	001401			BEQ	+.4	
004376	000000			HLT		;THE PS IS NOT EQUAL TO 0
004400	022701	002000		CMP	#2000,%1	;IS THE RESULT 2000?
004404	001401			BEQ	+.4	
004406	000000			HLT		;R1 IS NOT EQUAL TO 2000

:TEST 64 ASH 40000 SHIFTED BY 177775 = 4000 PS = 0

004410	010701			SCOPE		
004412	012701	040000		MOV	#40000,%1	;LOAD R1 WITH 40000
004416	072127	177775		ASH	#177775,%1	;SHIFT R1 BY 177775
004422	013767	177776	007314	MOV	@#PS,PSW	;SAVE PS
004430	122767	000000	007306	CMPB	#0,PSW	;IS THE PS 0?
004436	001401			BEQ	+.4	
004440	000000			HLT		;THE PS IS NOT EQUAL TO 0
004442	022701	004000		CMP	#4000,%1	;IS THE RESULT 4000?
004446	001401			BEQ	+.4	
004450	000000			HLT		;R1 IS NOT EQUAL TO 4000

:TEST 65 ASH 40000 SHIFTED BY 177776 = 10000 PS = 0

004452	010701			SCOPE		
004454	012701	040000		MOV	#40000,%1	;LOAD R1 WITH 40000
004460	072127	177776		ASH	#177776,%1	;SHIFT R1 BY 177776
004464	013767	177776	007252	MOV	@#PS,PSW	;SAVE PS
004472	122767	000000	007244	CMPB	#0,PSW	;IS THE PS 0?
004500	001401			BEQ	+.4	
004502	000000			HLT		;THE PS IS NOT EQUAL TO 0
004504	022701	010000		CMP	#10000,%1	;IS THE RESULT 10000?
004510	001401			BEQ	+.4	
004512	000000			HLT		;R1 IS NOT EQUAL TO 10000

:TEST 66 ASH 40000 SHIFTED BY 177777 = 20000 PS = 0

004514	010701			SCOPE		
004516	012701	040000		MOV	#40000,%1	;LOAD R1 WITH 40000
004522	072127	177777		ASH	#177777,%1	;SHIFT R1 BY 177777
004526	013767	177776	007210	MOV	@#PS,PSW	;SAVE PS
004534	122767	000000	007202	CMPB	#0,PSW	;IS THE PS 0?
004542	001401			BEQ	+.4	
004544	000000			HLT		;THE PS IS NOT EQUAL TO 0
004546	022701	020000		CMP	#20000,%1	;IS THE RESULT 20000?
004552	001401			BEQ	+.4	
004554	000000			HLT		;R1 IS NOT EQUAL TO 20000

:TEST 67 ASH 40000 SHIFTED BY 0 = 40000 PS = 0

004556	010701			SCOPE		
004560	012701	040000		MOV	#40000,%1	;LOAD R1 WITH 40000
004564	072127	000000		ASH	#0,%1	;SHIFT R1 BY 0
004570	013767	177776	007146	MOV	@#PS,PSW	;SAVE PS
004576	122767	000000	007140	CMPB	#0,PSW	;IS THE PS 0?
004604	001401			BEQ	+.4	
004606	000000			HLT		;THE PS IS NOT EQUAL TO 0
004610	022701	040000		CMP	#40000,%1	;IS THE RESULT 40000?
004614	001401			BEQ	+.4	
004616	000000			HLT		;R1 IS NOT EQUAL TO 40000

:TEST 70 ASH 100000 SHIFTED BY -15. = -1 PS = 10

004620	010701			SCOPE		
004622	012701	100000		MOV	#100000,%1	;LOAD R1 WITH 100000
004626	072127	177761		ASH	#-15,%1	;SHIFT R1 BY -15.
004632	013767	177776	007104	MOV	@#PS,PSW	;SAVE PS
004640	122767	000010	007076	CMPB	#10,PSW	;IS THE PS 10?
004646	001401			BEQ	+.4	
004650	000000			HLT		;THE PS IS NOT EQUAL TO 10
004652	022701	177777		CMP	#-1,%1	;IS THE RESULT -1?
004656	001401			BEQ	+.4	
004660	000000			HLT		;R1 IS NOT EQUAL TO -1

:TEST 71 ASH -1 SHIFTED BY 15. = 100000 PS = 11

004662	010701			SCOPE		
004664	012701	177777		MOV	#-1,%1	;LOAD R1 WITH -1
004670	072127	000017		ASH	#15,%1	;SHIFT R1 BY 15.
004674	013767	177776	007042	MOV	@#PS,PSW	;SAVE PS
004702	122767	000011	007034	CMPB	#11,PSW	;IS THE PS 11?
004710	001401			BEQ	+.4	
004712	000000			HLT		;THE PS IS NOT EQUAL TO 11
004714	022701	100000		CMP	#100000,%1	;IS THE RESULT 100000?
004720	001401			BEQ	+.4	
004722	000000			HLT		;R1 IS NOT EQUAL TO 100000

:TEST 72 ASH -1 SHIFTED BY 16. = 0 PS = 7

004724	010701			SCOPE		
004726	012701	177777		MOV	#-1,%1	;LOAD R1 WITH -1
004732	072127	000020		ASH	#16,%1	;SHIFT R1 BY 16.
004736	013767	177776	007000	MOV	3#PS,PSW	;SAVE PS
004744	122767	000007	006772	CMPB	#7,PSW	;IS THE PS 7?
004752	001401			BEQ	+.4	
004754	000000			HLT		;THE PS IS NOT EQUAL TO 7
004756	022701	000000		CMP	#0,%1	;IS THE RESULT 0?
004762	001401			BEQ	+.4	
004764	000000			HLT		;R1 IS NOT EQUAL TO 0

:TEST 73 ASH 137777 SHIFTED BY 15. = 100000 PS = 13

004766	010701			SCOPE		
004770	012701	137777		MOV	#137777,%1	;LOAD R1 WITH 137777
004774	072127	000017		ASH	#15,%1	;SHIFT R1 BY 15.
005000	013767	177776	006736	MOV	3#PS,PSW	;SAVE PS
005006	122767	000013	006730	CMPB	#13,PSW	;IS THE PS 13?
005014	001401			BEQ	+.4	
005016	000000			HLT		;THE PS IS NOT EQUAL TO 13
005020	022701	100000		CMP	#100000,%1	;IS THE RESULT 100000?
005024	001401			BEQ	+.4	
005026	000000			HLT		;R1 IS NOT EQUAL TO 100000

:TEST 74 ASH 125252 SHIFTED BY 1 = 52524 PS = 3

005030	010701			SCOPE		
005032	012701	125252		MOV	#125252,%1	;LOAD R1 WITH 125252
005036	072127	000001		ASH	#1,%1	;SHIFT R1 BY 1
005042	013767	177776	006674	MOV	3#PS,PSW	;SAVE PS
005050	122767	000003	006666	CMPB	#3,PSW	;IS THE PS 3?
005056	001401			BEQ	+.4	
005060	000000			HLT		;THE PS IS NOT EQUAL TO 3
005062	022701	052524		CMP	#52524,%1	;IS THE RESULT 52524?
005066	001401			BEQ	+.4	
005070	000000			HLT		;R1 IS NOT EQUAL TO 52524


```
*****
;TEST 75 ASH 125252 SHIFTED BY -1 = 152525 PS = 10
*****
```

005072	010701			SCOPE		
005074	012701	125252		MOV	#125252,%1	;LOAD R1 WITH 125252
005100	072127	177777		ASH	#-1,%1	;SHIFT R1 BY -1
005104	013767	177776	006632	MOV	@#PS,PSW	;SAVE PS
005112	122767	000010	006624	CMPB	#10,PSW	;IS THE PS 10?
005120	001401			BEQ	+.4	
005122	000000			HLT		;THE PS IS NOT EQUAL TO 10
005124	022701	152525		CMP	#152525,%1	;IS THE RESULT 152525?
005130	001401			BEQ	+.4	
005132	000000			HLT		;R1 IS NOT EQUAL TO 152525

```
*****
;TEST 76 ASH 125252 SHIFTED BY -2 = 165252 PS = 11
*****
```

005134	010701			SCOPE		
005136	012701	125252		MOV	#125252,%1	;LOAD R1 WITH 125252
005142	072127	177776		ASH	#-2,%1	;SHIFT R1 BY -2
005146	013767	177776	006570	MOV	@#PS,PSW	;SAVE PS
005154	122767	000011	006562	CMPB	#11,PSW	;IS THE PS 11?
005162	001401			BEQ	+.4	
005164	000000			HLT		;THE PS IS NOT EQUAL TO 11
005166	022701	165252		CMP	#165252,%1	;IS THE RESULT 165252?
005172	001401			BEQ	+.4	
005174	000000			HLT		;R1 IS NOT EQUAL TO 165252

```
*****
;TEST 77 ASH 40000 SHIFTED BY 177762 = 1 PS = 0
*****
```

005176	010701			SCOPE		
005200	012702	040000		MOV	#40000,%2	;LOAD R2 WITH 40000
005204	072227	177762		ASH	#177762,%2	;SHIFT R2 BY 177762
005210	013767	177776	006526	MOV	@#PS,PSW	;SAVE PS
005216	122767	000000	006520	CMPB	#0,PSW	;IS THE PS 0?
005224	001401			BEQ	+.4	
005226	000000			HLT		;THE PS IS NOT EQUAL TO 0
005230	022702	000001		CMP	#1,%2	;IS THE RESULT 1?
005234	001401			BEQ	+.4	
005236	000000			HLT		;R2 IS NOT EQUAL TO 1

:TEST 100 ASH 40000 SHIFTED BY 177763 = 2 PS = 0

005240	010701			SCOPE		
005242	012702	040000		MOV	#40000,%2	;LOAD R2 WITH 40000
005246	072227	177763		ASH	#177763,%2	;SHIFT R2 BY 177763
005252	013767	177776	006464	MOV	@#PS,PSW	;SAVE PS
005260	122767	000000	006456	CMPB	#0,PSW	;IS THE PS 0?
005266	001401			BEQ	+.4	
005270	000000			HLT		;THE PS IS NOT EQUAL TO 0
005272	022702	000002		CMP	#2,%2	;IS THE RESULT 2?
005276	001401			BEQ	+.4	
005300	000000			HLT		;R2 IS NOT EQUAL TO 2

:TEST 101 ASH 40000 SHIFTED BY 177764 = 4 PS = 0

005302	010701			SCOPE		
005304	012702	040000		MOV	#40000,%2	;LOAD R2 WITH 40000
005310	072227	177764		ASH	#177764,%2	;SHIFT R2 BY 177764
005314	013767	177776	006422	MOV	@#PS,PSW	;SAVE PS
005322	122767	000000	006414	CMPB	#0,PSW	;IS THE PS 0?
005330	001401			BEQ	+.4	
005332	000000			HLT		;THE PS IS NOT EQUAL TO 0
005334	022702	000004		CMP	#4,%2	;IS THE RESULT 4?
005340	001401			BEQ	+.4	
005342	000000			HLT		;R2 IS NOT EQUAL TO 4

:TEST 102 ASH 40000 SHIFTED BY 177765 = 10 PS = 0

005344	010701			SCOPE		
005346	012702	040000		MOV	#40000,%2	;LOAD R2 WITH 40000
005352	072227	177765		ASH	#177765,%2	;SHIFT R2 BY 177765
005356	013767	177776	006360	MOV	@#PS,PSW	;SAVE PS
005364	122767	000000	006352	CMPB	#0,PSW	;IS THE PS 0?
005372	001401			BEQ	+.4	
005374	000000			HLT		;THE PS IS NOT EQUAL TO 0
005376	022702	000010		CMP	#10,%2	;IS THE RESULT 10?
005402	001401			BEQ	+.4	
005404	000000			HLT		;R2 IS NOT EQUAL TO 10

:TEST 103 ASH 40000 SHIFTED BY 177766 = 20 PS = 0

005406	010701			SCOPE		
005410	012702	040000		MOV	#40000,%2	;LOAD R2 WITH 40000
005414	072227	177766		ASH	#177766,%2	;SHIFT R2 BY 177766
005420	013767	177776	006316	MOV	2#PS,PSW	;SAVE PS
005426	122767	000000	006310	CMPB	#0,PSW	;IS THE PS 0?
005434	001401			BEQ	+.4	
005436	000000			HLT		;THE PS IS NOT EQUAL TO 0
005440	022702	000020		CMP	#20,%2	;IS THE RESULT 20?
005444	001401			BEQ	+.4	
005446	000000			HLT		;R2 IS NOT EQUAL TO 20

:TEST 104 ASH 40000 SHIFTED BY 177767 = 40 PS = 0

005450	010701			SCOPE		
005452	012702	040000		MOV	#40000,%2	;LOAD R2 WITH 40000
005456	072227	177767		ASH	#177767,%2	;SHIFT R2 BY 177767
005462	013767	177776	006254	MOV	2#PS,PSW	;SAVE PS
005470	122767	000000	006246	CMPB	#0,PSW	;IS THE PS 0?
005476	001401			BEQ	+.4	
005500	000000			HLT		;THE PS IS NOT EQUAL TO 0
005502	022702	000040		CMP	#40,%2	;IS THE RESULT 40?
005506	001401			BEQ	+.4	
005510	000000			HLT		;R2 IS NOT EQUAL TO 40

:TEST 105 ASH 40000 SHIFTED BY 177770 = 100 PS = 0

005512	010701			SCOPE		
005514	012702	040000		MOV	#40000,%2	;LOAD R2 WITH 40000
005520	072227	177770		ASH	#177770,%2	;SHIFT R2 BY 177770
005524	013767	177776	006212	MOV	2#PS,PSW	;SAVE PS
005532	122767	000000	006204	CMPB	#0,PSW	;IS THE PS 0?
005540	001401			BEQ	+.4	
005542	000000			HLT		;THE PS IS NOT EQUAL TO 0
005544	022702	000100		CMP	#100,%2	;IS THE RESULT 100?
005550	001401			BEQ	+.4	
005552	000000			HLT		;R2 IS NOT EQUAL TO 100

:TEST 106 ASH 40000 SHIFTED BY 177771 = 200 PS = 0

005554	010701			SCOPE		
005556	012702	040000		MOV	#40000,%2	;LOAD R2 WITH 40000
005562	072227	177771		ASH	#177771,%2	;SHIFT R2 BY 177771
005566	013767	177776	006150	MOV	@PS,PSW	;SAVE PS
005574	122767	000000	006142	CMPB	#0,PSW	;IS THE PS 0?
005602	001401			BEQ	+.4	
005604	000000			HLT		;THE PS IS NOT EQUAL TO 0
005606	022702	000200		CMP	#200,%2	;IS THE RESULT 200?
005612	001401			BEQ	+.4	
005614	000000			HLT		;R2 IS NOT EQUAL TO 200

:TEST 107 ASH 40000 SHIFTED BY 177772 = 400 PS = 0

005616	010701			SCOPE		
005620	012702	040000		MOV	#40000,%2	;LOAD R2 WITH 40000
005624	072227	177772		ASH	#177772,%2	;SHIFT R2 BY 177772
005630	013767	177776	006106	MOV	@PS,PSW	;SAVE PS
005636	122767	000000	006100	CMPB	#0,PSW	;IS THE PS 0?
005644	001401			BEQ	+.4	
005646	000000			HLT		;THE PS IS NOT EQUAL TO 0
005650	022702	000400		CMP	#400,%2	;IS THE RESULT 400?
005654	001401			BEQ	+.4	
005656	000000			HLT		;R2 IS NOT EQUAL TO 400

:TEST 110 ASH 40000 SHIFTED BY 177773 = 1000 PS = 0

005660	010701			SCOPE		
005662	012702	040000		MOV	#40000,%2	;LOAD R2 WITH 40000
005666	072227	177773		ASH	#177773,%2	;SHIFT R2 BY 177773
005672	013767	177776	006044	MOV	@PS,PSW	;SAVE PS
005700	122767	000000	006036	CMPB	#0,PSW	;IS THE PS 0?
005706	001401			BEQ	+.4	
005710	000000			HLT		;THE PS IS NOT EQUAL TO 0
005712	022702	001000		CMP	#1000,%2	;IS THE RESULT 1000?
005716	001401			BEQ	+.4	
005720	000000			HLT		;R2 IS NOT EQUAL TO 1000

:TEST 111 ASH 40000 SHIFTED BY 177774 = 2000 PS = 0

005722	010701			SCOPE		
005724	012702	040000		MOV	#40000,%2	:LOAD R2 WITH 40000
005730	072227	177774		ASH	#177774,%2	:SHIFT R2 BY 177774
005734	013767	177776	006002	MOV	@#PS,PSW	:SAVE PS
005742	122767	000000	005774	CMPB	#0,PSW	:IS THE PS 0?
005750	001401			BEQ	+.4	
005752	000000			HLT		:THE PS IS NOT EQUAL TO 0
005754	022702	002000		CMP	#2000,%2	:IS THE RESULT 2000?
005760	001401			BEQ	+.4	
005762	000000			HLT		:R2 IS NOT EQUAL TO 2000

:TEST 112 ASH 40000 SHIFTED BY 177775 = 4000 PS = 0

005764	010701			SCOPE		
005766	012702	040000		MOV	#40000,%2	:LOAD R2 WITH 40000
005772	072227	177775		ASH	#177775,%2	:SHIFT R2 BY 177775
005776	013767	177776	005740	MOV	@#PS,PSW	:SAVE PS
006004	122767	000000	005732	CMPB	#0,PSW	:IS THE PS 0?
006012	001401			BEQ	+.4	
006014	000000			HLT		:THE PS IS NOT EQUAL TO 0
006016	022702	004000		CMP	#4000,%2	:IS THE RESULT 4000?
006022	001401			BEQ	+.4	
006024	000000			HLT		:R2 IS NOT EQUAL TO 4000

:TEST 113 ASH 40000 SHIFTED BY 177776 = 10000 PS = 0

006026	010701			SCOPE		
006030	012702	040000		MOV	#40000,%2	:LOAD R2 WITH 40000
006034	072227	177776		ASH	#177776,%2	:SHIFT R2 BY 177776
006040	013767	177776	005676	MOV	@#PS,PSW	:SAVE PS
006046	122767	000000	005670	CMPB	#0,PSW	:IS THE PS 0?
006054	001401			BEQ	+.4	
006056	000000			HLT		:THE PS IS NOT EQUAL TO 0
006060	022702	010000		CMP	#10000,%2	:IS THE RESULT 10000?
006064	001401			BEQ	+.4	
006066	000000			HLT		:R2 IS NOT EQUAL TO 10000

:TEST 114 ASH 40000 SHIFTED BY 177777 = 20000 PS = 0

006070	010701			SCOPE		
006072	012702	040000		MOV	#40000,%2	;LOAD R2 WITH 40000
006076	072227	177777		ASH	#177777,%2	;SHIFT R2 BY 177777
006102	013767	177776	005634	MOV	@#PS,PSW	;SAVE PS
006110	122767	000000	005626	CMPB	#0,PSW	;IS THE PS 0?
006116	001401			BEQ	+.4	
006120	000000			HLT		;THE PS IS NOT EQUAL TO 0
006122	022702	020000		CMP	#20000,%2	;IS THE RESULT 20000?
006126	001401			BEQ	+.4	
006130	000000			HLT		;R2 IS NOT EQUAL TO 20000

:TEST 115 ASH 40000 SHIFTED BY 0 = 40000 PS = 0

006132	010701			SCOPE		
006134	012702	040000		MOV	#40000,%2	;LOAD R2 WITH 40000
006140	072227	000000		ASH	#0,%2	;SHIFT R2 BY 0
006144	013767	177776	005572	MOV	@#PS,PSW	;SAVE PS
006152	122767	000000	005564	CMPB	#0,PSW	;IS THE PS 0?
006160	001401			BEQ	+.4	
006162	000000			HLT		;THE PS IS NOT EQUAL TO 0
006164	022702	040000		CMP	#40000,%2	;IS THE RESULT 40000?
006170	001401			BEQ	+.4	
006172	000000			HLT		;R2 IS NOT EQUAL TO 40000

:TEST 116 ASH 100000 SHIFTED BY -15. = -1 PS = 10

006174	010701			SCOPE		
006176	012702	100000		MOV	#100000,%2	;LOAD R2 WITH 100000
006202	072227	177761		ASH	#-15,%2	;SHIFT R2 BY -15.
006206	013767	177776	005530	MOV	@#PS,PSW	;SAVE PS
006214	122767	000010	005522	CMPB	#10,PSW	;IS THE PS,10?
006222	001401			BEQ	+.4	
006224	000000			HLT		;THE PS IS NOT EQUAL TO 10
006226	022702	177777		CMP	#-1,%2	;IS THE RESULT -1?
006232	001401			BEQ	+.4	
006234	000000			HLT		;R2 IS NOT EQUAL TO -1


```
*****
:TEST 117 ASH -1 SHIFTED BY 15. = 10000 PS = 11
:*****
```

006236	010701			SCOPE		
006240	012702	177777		MOV	#-1,%2	;LOAD R2 WITH -1
006244	072227	000017		ASH	#15,%2	;SHIFT R2 BY 15.
006250	013767	177776	005466	MOV	@#PS,PSW	;SAVE PS
006256	122767	000011	005460	CMPB	#11,PSW	;IS THE PS 11?
006264	001401			BEQ	+.4	
006266	000000			HLT		;THE PS IS NOT EQUAL TO 11
006270	022702	100000		CMP	#100000,%2	;IS THE RESULT 100000?
006274	001401			BEQ	+.4	
006276	000000			HLT		;R2 IS NOT EQUAL TO 100000

```
*****
:TEST 120 ASH -1 SHIFTED BY 16. = 0 PS = 7
:*****
```

006300	010701			SCOPE		
006302	012702	177777		MOV	#-1,%2	;LOAD R2 WITH -1
006306	072227	000020		ASH	#16,%2	;SHIFT R2 BY 16.
006312	013767	177776	005424	MOV	@#PS,PSW	;SAVE PS
006320	122767	000007	005416	CMPB	#7,PSW	;IS THE PS 7?
006326	001401			BEQ	+.4	
006330	000000			HLT		;THE PS IS NOT EQUAL TO 7
006332	022702	000000		CMP	#0,%2	;IS THE RESULT 0?
006336	001401			BEQ	+.4	
006340	000000			HLT		;R2 IS NOT EQUAL TO 0

```
*****
:TEST 121 ASH 137777 SHIFTED BY 15. = 10000 PS = 13
:*****
```

006342	010701			SCOPE		
006344	012702	137777		MOV	#137777,%2	;LOAD R2 WITH 137777
006350	072227	000017		ASH	#15,%2	;SHIFT R2 BY 15.
006354	013767	177776	005362	MOV	@#PS,PSW	;SAVE PS
006362	122767	000013	005354	CMPB	#13,PSW	;IS THE PS 13?
006370	001401			BEQ	+.4	
006372	000000			HLT		;THE PS IS NOT EQUAL TO 13
006374	022702	100000		CMP	#100000,%2	;IS THE RESULT 100000?
006400	001401			BEQ	+.4	
006402	000000			HLT		;R2 IS NOT EQUAL TO 100000

: TEST 122 ASH 125252 SHIFTED BY 1 = 52524 PS = 3
: *****

006404	010701			SCOPE		
006406	012702	125252		MOV	#125252,%2	;LOAD R2 WITH 125252
006412	072227	000001		ASH	#1,%2	;SHIFT R2 BY 1
006416	013767	177776	005320	MOV	2#PS,PSW	;SAVE PS
006424	122767	000003	005312	CMPB	#3,PSW	;IS THE PS 3?
006432	001401			BEQ	+.4	
006434	000000			HLT		;THE PS IS NOT EQUAL TO 3
006436	022702	052524		CMP	#52524,%2	;IS THE RESULT 52524?
006442	001401			BEQ	+.4	
006444	000000			HLT		;R2 IS NOT EQUAL TO 52524

: TEST 123 ASH 125252 SHIFTED BY -1 = 152525 PS = 10
: *****

006446	010701			SCOPE		
006450	012702	125252		MOV	#125252,%2	;LOAD R2 WITH 125252
006454	072227	177777		ASH	#-1,%2	;SHIFT R2 BY -1
006460	013767	177776	005256	MOV	2#PS,PSW	;SAVE PS
006466	122767	000010	005250	CMPB	#10,PSW	;IS THE PS 10?
006474	001401			BEQ	+.4	
006476	000000			HLT		;THE PS IS NOT EQUAL TO 10
006500	022702	152525		CMP	#152525,%2	;IS THE RESULT 152525?
006504	001401			BEQ	+.4	
006506	000000			HLT		;R2 IS NOT EQUAL TO 152525

: TEST 124 ASH 125252 SHIFTED BY -2 = 165252 PS = 11
: *****

006510	010701			SCOPE		
006512	012702	125252		MOV	#125252,%2	;LOAD R2 WITH 125252
006516	072227	177776		ASH	#-2,%2	;SHIFT R2 BY -2
006522	013767	177776	005214	MOV	2#PS,PSW	;SAVE PS
006530	122767	000011	005206	CMPB	#11,PSW	;IS THE PS 11?
006536	001401			BEQ	+.4	
006540	000000			HLT		;THE PS IS NOT EQUAL TO 11
006542	022702	165252		CMP	#165252,%2	;IS THE RESULT 165252?
006546	001401			BEQ	+.4	
006550	000000			HLT		;R2 IS NOT EQUAL TO 165252

:TEST 125 ASH 40000 SHIFTED BY 177762 = 1 PS = 0

006552	010701			SCOPE		
006554	012703	040000		MOV	#40000,%3	;LOAD R3 WITH 40000
006560	072327	177762		ASH	#177762,%3	;SHIFT R3 BY 177762
006564	013767	177776	005152	MOV	@#PS,PSW	;SAVE PS
006572	122767	000000	005144	CMPB	#0,PSW	;IS THE PS 0?
006600	001401			BEQ	+.4	
006602	000000			HLT		;THE PS IS NOT EQUAL TO 0
006604	022703	000001		CMP	#1,%3	;IS THE RESULT 1?
006610	001401			BEQ	+.4	
006612	000000			HLT		;R3 IS NOT EQUAL TO 1

:TEST 126 ASH 40000 SHIFTED BY 177763 = 2 PS = 0

006614	010701			SCOPE		
006616	012703	040000		MOV	#40000,%3	;LOAD R3 WITH 40000
006622	072327	177763		ASH	#177763,%3	;SHIFT R3 BY 177763
006626	013767	177776	005110	MOV	@#PS,PSW	;SAVE PS
006634	122767	000000	005102	CMPB	#0,PSW	;IS THE PS 0?
006642	001401			BEQ	+.4	
006644	000000			HLT		;THE PS IS NOT EQUAL TO 0
006646	022703	000002		CMP	#2,%3	;IS THE RESULT 2?
006652	001401			BEQ	+.4	
006654	000000			HLT		;R3 IS NOT EQUAL TO 2

:TEST 127 ASH 40000 SHIFTED BY 177764 = 4 PS = 0

006656	010701			SCOPE		
006660	012703	040000		MOV	#40000,%3	;LOAD R3 WITH 40000
006664	072327	177764		ASH	#177764,%3	;SHIFT R3 BY 177764
006670	013767	177776	005046	MOV	@#PS,PSW	;SAVE PS
006676	122767	000000	005040	CMPB	#0,PSW	;IS THE PS 0?
006704	001401			BEQ	+.4	
006706	000000			HLT		;THE PS IS NOT EQUAL TO 0
006710	022703	000004		CMP	#4,%3	;IS THE RESULT 4?
006714	001401			BEQ	+.4	
006716	000000			HLT		;R3 IS NOT EQUAL TO 4

:TEST 130 ASH 40000 SHIFTED BY 177765 = 10 PS = 0

006720	010701			SCOPE		
006722	012703	040000		MOV	#40000,%3	;LOAD R3 WITH 40000
006726	072327	177765		ASH	#177765,%3	;SHIFT R3 BY 177765
006732	013767	177776	005004	MOV	@#PS,PSW	;SAVE PS
006740	122767	000000	004776	CMPB	#0,PSW	;IS THE PS 0?
006746	001401			BEQ	+.4	
006750	000000			HLT		;THE PS IS NOT EQUAL TO 0
006752	022703	000010		CMP	#10,%3	;IS THE RESULT 10?
006756	001401			BEQ	+.4	
006760	000000			HLT		;R3 IS NOT EQUAL TO 10

:TEST 131 ASH 40000 SHIFTED BY 177766 = 20 PS = 0

006762	010701			SCOPE		
006764	012703	040000		MOV	#40000,%3	;LOAD R3 WITH 40000
006770	072327	177766		ASH	#177766,%3	;SHIFT R3 BY 177766
006774	013767	177776	004742	MOV	@#PS,PSW	;SAVE PS
007002	122767	000000	004734	CMPB	#0,PSW	;IS THE PS 0?
007010	001401			BEQ	+.4	
007012	000000			HLT		;THE PS IS NOT EQUAL TO 0
007014	022703	000020		CMP	#20,%3	;IS THE RESULT 20?
007020	001401			BEQ	+.4	
007022	000000			HLT		;R3 IS NOT EQUAL TO 20

:TEST 132 ASH 40000 SHIFTED BY 177767 = 40 PS = 0

007024	010701			SCOPE		
007026	012703	040000		MOV	#40000,%3	;LOAD R3 WITH 40000
007032	072327	177767		ASH	#177767,%3	;SHIFT R3 BY 177767
007036	013767	177776	004700	MOV	@#PS,PSW	;SAVE PS
007044	122767	000000	004672	CMPB	#0,PSW	;IS THE PS 0?
007052	001401			BEQ	+.4	
007054	000000			HLT		;THE PS IS NOT EQUAL TO 0
007056	022703	000040		CMP	#40,%3	;IS THE RESULT 40?
007062	001401			BEQ	+.4	
007064	000000			HLT		;R3 IS NOT EQUAL TO 40

:TEST 133 ASH 40000 SHIFTED BY 177770 = 100 PS = 0

007066	010701			SCOPE		
007070	012703	040000		MOV	#40000,%3	;LOAD R3 WITH 40000
007074	072327	177770		ASH	#177770,%3	;SHIFT R3 BY 177770
007100	013767	177776	004636	MOV	@#PS,PSW	;SAVE PS
007106	122767	000000	004630	CMPB	#0,PSW	;IS THE PS 0?
007114	001401			BEQ	+.4	
007116	000000			HLT		;THE PS IS NOT EQUAL TO 0
007120	022703	000100		CMP	#100,%3	;IS THE RESULT 100?
007124	001401			BEQ	+.4	
007126	000000			HLT		;R3 IS NOT EQUAL TO 100

:TEST 134 ASH 40000 SHIFTED BY 177771 = 200 PS = 0

007130	010701			SCOPE		
007132	012703	040000		MOV	#40000,%3	;LOAD R3 WITH 40000
007136	072327	177771		ASH	#177771,%3	;SHIFT R3 BY 177771
007142	013767	177776	004574	MOV	@#PS,PSW	;SAVE PS
007150	122767	000000	004566	CMPB	#0,PSW	;IS THE PS 0?
007156	001401			BEQ	+.4	
007160	000000			HLT		;THE PS IS NOT EQUAL TO 0
007162	022703	000200		CMP	#200,%3	;IS THE RESULT 200?
007166	001401			BEQ	+.4	
007170	000000			HLT		;R3 IS NOT EQUAL TO 200

:TEST 135 ASH 40000 SHIFTED BY 177772 = 400 PS = 0

007172	010701			SCOPE		
007174	012703	040000		MOV	#40000,%3	;LOAD R3 WITH 40000
007200	072327	177772		ASH	#177772,%3	;SHIFT R3 BY 177772
007204	013767	177776	004532	MOV	@#PS,PSW	;SAVE PS
007212	122767	000000	004524	CMPB	#0,PSW	;IS THE PS 0?
007220	001401			BEQ	+.4	
007222	000000			HLT		;THE PS IS NOT EQUAL TO 0
007224	022703	000400		CMP	#400,%3	;IS THE RESULT 400?
007230	001401			BEQ	+.4	
007232	000000			HLT		;R3 IS NOT EQUAL TO 400

:TEST 136 ASH 40000 SHIFTED BY 177773 = 1000 PS = 0

007234	010701			SCOPE		
007236	012703	040000		MOV	#40000,%3	;LOAD R3 WITH 40000
007242	072327	177773		ASH	#177773,%3	;SHIFT R3 BY 177773
007246	013767	177776	004470	MOV	@#PS,PSW	;SAVE PS
007254	122767	000000	004462	CMPB	#0,PSW	;IS THE PS 0?
007262	001401			BEQ	+.4	
007264	000000			HLT		;THE PS IS NOT EQUAL TO 0
007266	022703	001000		CMP	#1000,%3	;IS THE RESULT 1000?
007272	001401			BEQ	+.4	
007274	000000			HLT		;R3 IS NOT EQUAL TO 1000

:TEST 137 ASH 40000 SHIFTED BY 177774 = 2000 PS = 0

007276	010701			SCOPE		
007300	012703	040000		MOV	#40000,%3	;LOAD R3 WITH 40000
007304	072327	177774		ASH	#177774,%3	;SHIFT R3 BY 177774
007310	013767	177776	004426	MOV	@#PS,PSW	;SAVE PS
007316	122767	000000	004420	CMPB	#0,PSW	;IS THE PS 0?
007324	001401			BEQ	+.4	
007326	000000			HLT		;THE PS IS NOT EQUAL TO 0
007330	022703	002000		CMP	#2000,%3	;IS THE RESULT 2000?
007334	001401			BEQ	+.4	
007336	000000			HLT		;R3 IS NOT EQUAL TO 2000

:TEST 140 ASH 40000 SHIFTED BY 177775 = 4000 PS = 0

007340	010701			SCOPE		
007342	012703	040000		MOV	#40000,%3	;LOAD R3 WITH 40000
007346	072327	177775		ASH	#177775,%3	;SHIFT R3 BY 177775
007352	013767	177776	004364	MOV	@#PS,PSW	;SAVE PS
007360	122767	000000	004356	CMPB	#0,PSW	;IS THE PS 0?
007366	001401			BEQ	+.4	
007370	000000			HLT		;THE PS IS NOT EQUAL TO 0
007372	022703	004000		CMP	#4000,%3	;IS THE RESULT 4000?
007376	001401			BEQ	+.4	
007400	000000			HLT		;R3 IS NOT EQUAL TO 4000

:TEST 141 ASH 40000 SHIFTED BY 177776 = 10000 PS = 0

007402	010701			SCOPE		
007404	012703	040000		MOV	#40000,%3	:LOAD R3 WITH 40000
007410	072327	177776		ASH	#177776,%3	:SHIFT R3 BY 177776
007414	013767	177776	004322	MOV	@#PS,PSW	:SAVE PS
007422	122767	000000	004314	CMPB	#0,PSW	:IS THE PS 0?
007430	001401			BEQ	+.4	
007432	000000			HLT		:THE PS IS NOT EQUAL TO 0
007434	022703	010000		CMP	#10000,%3	:IS THE RESULT 10000?
007440	001401			BEQ	+.4	
007442	000000			HLT		:R3 IS NOT EQUAL TO 10000

:TEST 142 ASH 40000 SHIFTED BY 177777 = 20000 PS = 0

007444	010701			SCOPE		
007446	012703	040000		MOV	#40000,%3	:LOAD R3 WITH 40000
007452	072327	177777		ASH	#177777,%3	:SHIFT R3 BY 177777
007456	013767	177776	004260	MOV	@#PS,PSW	:SAVE PS
007464	122767	000000	004252	CMPB	#0,PSW	:IS THE PS 0?
007472	001401			BEQ	+.4	
007474	000000			HLT		:THE PS IS NOT EQUAL TO 0
007476	022703	020000		CMP	#20000,%3	:IS THE RESULT 20000?
007502	001401			BEQ	+.4	
007504	000000			HLT		:R3 IS NOT EQUAL TO 20000

:TEST 143 ASH 40000 SHIFTED BY 0 = 40000 PS = 0

007506	010701			SCOPE		
007510	012703	040000		MOV	#40000,%3	:LOAD R3 WITH 40000
007514	072327	000000		ASH	#0,%3	:SHIFT R3 BY 0
007520	013767	177776	004216	MOV	@#PS,PSW	:SAVE PS
007526	122767	000000	004210	CMPB	#0,PSW	:IS THE PS 0?
007534	001401			BEQ	+.4	
007536	000000			HLT		:THE PS IS NOT EQUAL TO 0
007540	022703	040000		CMP	#40000,%3	:IS THE RESULT 40000?
007544	001401			BEQ	+.4	
007546	000000			HLT		:R3 IS NOT EQUAL TO 40000

:TEST 144 ASH 100000 SHIFTED BY -15. = -1 PS = 10
:*****

007550	010701			SCOPE		
007552	012703	100000		MOV	#100000,%3	;LOAD R3 WITH 100000
007556	072327	177761		ASH	#-15,%3	;SHIFT R3 BY -15.
007562	013767	177776	004154	MOV	@#PS,PSW	;SAVE PS
007570	122767	000010	004146	CMPB	#10,PSW	;IS THE PS 10?
007576	001401			BEQ	+.4	
007600	000000			HLT		;THE PS IS NOT EQUAL TO 10
007602	022703	177777		CMP	#-1,%3	;IS THE RESULT -1?
007606	001401			BEQ	+.4	
007610	000000			HLT		;R3 IS NOT EQUAL TO -1

:TEST 145 ASH -1 SHIFTED BY 15. = 100000 PS = 11
:*****

007612	010701			SCOPE		
007614	012703	177777		MOV	#-1,%3	;LOAD R3 WITH -1
007620	072327	000017		ASH	#15,%3	;SHIFT R3 BY 15.
007624	013767	177776	004112	MOV	@#PS,PSW	;SAVE PS
007632	122767	000011	004104	CMPB	#11,PSW	;IS THE PS 11?
007640	001401			BEQ	+.4	
007642	000000			HLT		;THE PS IS NOT EQUAL TO 11
007644	022703	100000		CMP	#100000,%3	;IS THE RESULT 100000?
007650	001401			BEQ	+.4	
007652	000000			HLT		;R3 IS NOT EQUAL TO 100000

:TEST 146 ASH -1 SHIFTED BY 16. = 0 PS = 7
:*****

007654	010701			SCOPE		
007656	012703	177777		MOV	#-1,%3	;LOAD R3 WITH -1
007662	072327	000020		ASH	#16,%3	;SHIFT R3 BY 16.
007666	013767	177776	004050	MOV	@#PS,PSW	;SAVE PS
007674	122767	000007	004042	CMPB	#7,PSW	;IS THE PS 7?
007702	001401			BEQ	+.4	
007704	000000			HLT		;THE PS IS NOT EQUAL TO 7
007706	022703	000000		CMP	#0,%3	;IS THE RESULT 0?
007712	001401			BEQ	+.4	
007714	000000			HLT		;R3 IS NOT EQUAL TO 0

:TEST 147 ASH 137777 SHIFTED BY 15. = 100000 PS = 13
:*****

007716	010701			SCOPE		
007720	012703	137777		MOV	#137777,%3	;LOAD R3 WITH 137777
007724	072327	000017		ASH	#15,%3	;SHIFT R3 BY 15.
007730	013767	177776	004006	MOV	@#PS,PSW	;SAVE PS
007736	122767	000013	004000	CMPB	#13,PSW	;IS THE PS 13?
007744	001401			BEQ	.+4	
007746	000000			HLT		;THE PS IS NOT EQUAL TO 13
007750	022703	100000		CMP	#100000,%3	;IS THE RESULT 100000?
007754	001401			BEQ	.+4	
007756	000000			HLT		;R3 IS NOT EQUAL TO 100000

:TEST 150 ASH 125252 SHIFTED BY 1 = 52524 PS = 3
:*****

007760	010701			SCOPE		
007762	012703	125252		MOV	#125252,%3	;LOAD R3 WITH 125252
007766	072327	000001		ASH	#1,%3	;SHIFT R3 BY 1
007772	013767	177776	003744	MOV	@#PS,PSW	;SAVE PS
010000	122767	000003	003736	CMPB	#3,PSW	;IS THE PS 3?
010006	001401			BEQ	.+4	
010010	000000			HLT		;THE PS IS NOT EQUAL TO 3
010012	022703	052524		CMP	#52524,%3	;IS THE RESULT 52524?
010016	001401			BEQ	.+4	
010020	000000			HLT		;R3 IS NOT EQUAL TO 52524

:TEST 151 ASH 125252 SHIFTED BY -1 = 152525 PS = 10
:*****

010022	010701			SCOPE		
010024	012703	125252		MOV	#125252,%3	;LOAD R3 WITH 125252
010030	072327	177777		ASH	#-1,%3	;SHIFT R3 BY -1
010034	013767	177776	003702	MOV	@#PS,PSW	;SAVE PS
010042	122767	000010	003674	CMPB	#10,PSW	;IS THE PS 10?
010050	001401			BEQ	.+4	
010052	000000			HLT		;THE PS IS NOT EQUAL TO 10
010054	022703	152525		CMP	#152525,%3	;IS THE RESULT 152525?
010060	001401			BEQ	.+4	
010062	000000			HLT		;R3 IS NOT EQUAL TO 152525

:TEST 152 ASH 125252 SHIFTED BY -2 = 165252 PS = 11

010064	010701			SCOPE		
010066	012703	125252		MOV	#125252,%3	:LOAD R3 WITH 125252
010072	072327	177776		ASH	#-2,%3	:SHIFT R3 BY -2
010076	013767	177776	003640	MOV	@#PS,PSW	:SAVE PS
010104	122767	000011	003632	CMPB	#11,PSW	:IS THE PS 11?
010112	001401			BEQ	+.4	
010114	000000			HLT		:THE PS IS NOT EQUAL TO 11
010116	022703	165252		CMP	#165252,%3	:IS THE RESULT 165252?
010122	001401			BEQ	+.4	
010124	000000			HLT		:R3 IS NOT EQUAL TO 165252

:TEST 153 ASH 40000 SHIFTED BY 177762 = 1 PS = 0

010126	010701			SCOPE		
010130	012704	040000		MOV	#40000,%4	:LOAD R4 WITH 40000
010134	072427	177762		ASH	#177762,%4	:SHIFT R4 BY 177762
010140	013767	177776	003576	MOV	@#PS,PSW	:SAVE PS
010146	122767	000000	003570	CMPB	#0,PSW	:IS THE PS 0?
010154	001401			BEQ	+.4	
010156	000000			HLT		:THE PS IS NOT EQUAL TO 0
010160	022704	000001		CMP	#1,%4	:IS THE RESULT 1?
010164	001401			BEQ	+.4	
010166	000000			HLT		:R4 IS NOT EQUAL TO 1

:TEST 154 ASH 40000 SHIFTED BY 177763 = 2 PS = 0

010170	010701			SCOPE		
010172	012704	040000		MOV	#40000,%4	:LOAD R4 WITH 40000
010176	072427	177763		ASH	#177763,%4	:SHIFT R4 BY 177763
010202	013767	177776	003534	MOV	@#PS,PSW	:SAVE PS
010210	122767	000000	003526	CMPB	#0,PSW	:IS THE PS 0?
010216	001401			BEQ	+.4	
010220	000000			HLT		:THE PS IS NOT EQUAL TO 0
010222	022704	000002		CMP	#2,%4	:IS THE RESULT 2?
010226	001401			BEQ	+.4	
010230	000000			HLT		:R4 IS NOT EQUAL TO 2

:TEST 155 ASH 40000 SHIFTED BY 177764 = 4 PS = 0

010232 010701
010234 012704 040000
010240 072427 177764
010244 013767 177776 003472
010252 122767 000000 003464
010260 001401
010262 000000
010264 022704 000004
010270 001401
010272 000000

SCOPE
MOV #40000,%4 ;LOAD R4 WITH 40000
ASH #177764,%4 ;SHIFT R4 BY 177764
MOV @PS,PSW ;SAVE PS
CMPB #0,PSW ;IS THE PS 0?
BEQ .+4
HLT ;THE PS IS NOT EQUAL TO 0
CMP #4,%4 ;IS THE RESULT 4?
BEQ .+4
HLT ;R4 IS NOT EQUAL TO 4

:TEST 156 ASH 40000 SHIFTED BY 177765 = 10 PS = 0

010274 010701
010276 012704 040000
010302 072427 177765 003430
010306 013767 177776 003422
010314 122767 000000
010322 001401
010324 000000
010326 022704 000010
010332 001401
010334 000000

SCOPE
MOV #40000,%4 ;LOAD R4 WITH 40000
ASH #177765,%4 ;SHIFT R4 BY 177765
MOV @PS,PSW ;SAVE PS
CMPB #0,PSW ;IS THE PS 0?
BEQ .+4
HLT ;THE PS IS NOT EQUAL TO 0
CMP #10,%4 ;IS THE RESULT 10?
BEQ .+4
HLT ;R4 IS NOT EQUAL TO 10

:TEST 157 ASH 40000 SHIFTED BY 177766 = 20 PS = 0

010336 010701
010340 012704 040000
010344 072427 177766 003366
010350 013767 177776 003360
010356 122767 000000
010364 001401
010366 000000
010370 022704 000020
010374 001401
010376 000000

SCOPE
MOV #40000,%4 ;LOAD R4 WITH 40000
ASH #177766,%4 ;SHIFT R4 BY 177766
MOV @PS,PSW ;SAVE PS
CMPB #0,PSW ;IS THE PS 0?
BEQ .+4
HLT ;THE PS IS NOT EQUAL TO 0
CMP #20,%4 ;IS THE RESULT 20?
BEQ .+4
HLT ;R4 IS NOT EQUAL TO 20

:TEST 160 ASH 40000 SHIFTED BY 177767 = 40 PS = 0

010400	010701			SCOPE		
010402	012704	040000		MOV	#40000,%4	;LOAD R4 WITH 40000
010406	072427	177767		ASH	#177767,%4	;SHIFT R4 BY 177767
010412	013767	177776	003324	MOV	2#PS,PSW	;SAVE PS
010420	122767	000000	003316	CMPB	#0,PSW	;IS THE PS 0?
010426	001401			BEQ	.+4	
010430	000000			HLT		;THE PS IS NOT EQUAL TO 0
010432	022704	000040		CMP	#40,%4	;IS THE RESULT 40?
010436	001401			BEQ	.+4	
010440	000000			HLT		;R4 IS NOT EQUAL TO 40

:TEST 161 ASH 40000 SHIFTED BY 177770 = 100 PS = 0

010442	010701			SCOPE		
010444	012704	040000		MOV	#40000,%4	;LOAD R4 WITH 40000
010450	072427	177770		ASH	#177770,%4	;SHIFT R4 BY 177770
010454	013767	177776	003262	MOV	2#PS,PSW	;SAVE PS
010462	122767	000000	003254	CMPB	#0,PSW	;IS THE PS 0?
010470	001401			BEQ	.+4	
010472	000000			HLT		;THE PS IS NOT EQUAL TO 0
010474	022704	000100		CMP	#100,%4	;IS THE RESULT 100?
010500	001401			BEQ	.+4	
010502	000000			HLT		;R4 IS NOT EQUAL TO 100

:TEST 162 ASH 40000 SHIFTED BY 177771 = 200 PS = 0

010504	010701			SCOPE		
010506	012704	040000		MOV	#40000,%4	;LOAD R4 WITH 40000
010512	072427	177771		ASH	#177771,%4	;SHIFT R4 BY 177771
010516	013767	177776	003220	MOV	2#PS,PSW	;SAVE PS
010524	122767	000000	003212	CMPB	#0,PSW	;IS THE PS 0?
010532	001401			BEQ	.+4	
010534	000000			HLT		;THE PS IS NOT EQUAL TO 0
010536	022704	000200		CMP	#200,%4	;IS THE RESULT 200?
010542	001401			BEQ	.+4	
010544	000000			HLT		;R4 IS NOT EQUAL TO 200

:TEST 163 ASH 40000 SHIFTED BY 177772 = 400 PS = 0
:*****

010546	010701			SCOPE		
010550	012704	040000		MOV	#40000,%4	;LOAD R4 WITH 40000
010554	072427	177772		ASH	#177772,%4	;SHIFT R4 BY 177772
010560	013767	177776	003156	MOV	3#PS,PSW	;SAVE PS
010566	122767	000000	003150	CMPB	#0,PSW	;IS THE PS 0?
010574	001401			BEQ	+.4	
010576	000000			HLT		;THE PS IS NOT EQUAL TO 0
010600	022704	000400		CMP	#400,%4	;IS THE RESULT 400?
010604	001401			BEQ	+.4	
010606	000000			HLT		;R4 IS NOT EQUAL TO 400

:TEST 164 ASH 40000 SHIFTED BY 177773 = 1000 PS = 0
:*****

010610	010701			SCOPE		
010612	012704	040000		MOV	#40000,%4	;LOAD R4 WITH 40000
010616	072427	177773		ASH	#177773,%4	;SHIFT R4 BY 177773
010622	013767	177776	003114	MOV	3#PS,PSW	;SAVE PS
010630	122767	000000	003106	CMPB	#0,PSW	;IS THE PS 0?
010636	001401			BEQ	+.4	
010640	000000			HLT		;THE PS IS NOT EQUAL TO 0
010642	022704	001000		CMP	#1000,%4	;IS THE RESULT 1000?
010646	001401			BEQ	+.4	
010650	000000			HLT		;R4 IS NOT EQUAL TO 1000

:TEST 165 ASH 40000 SHIFTED BY 177774 = 2000 PS = 0
:*****

010652	010701			SCOPE		
010654	012704	040000		MOV	#40000,%4	;LOAD R4 WITH 40000
010660	072427	177774		ASH	#177774,%4	;SHIFT R4 BY 177774
010664	013767	177776	003052	MOV	3#PS,PSW	;SAVE PS
010672	122767	000000	003044	CMPB	#0,PSW	;IS THE PS 0?
010700	001401			BEQ	+.4	
010702	000000			HLT		;THE PS IS NOT EQUAL TO 0
010704	022704	002000		CMP	#2000,%4	;IS THE RESULT 2000?
010710	001401			BEQ	+.4	
010712	000000			HLT		;R4 IS NOT EQUAL TO 2000

:TEST 166 ASH 40000 SHIFTED BY 177775 = 4000 PS = 0

010714	010701			SCOPE		
010716	012704	040000		MOV	#40000,%4	;LOAD R4 WITH 40000
010722	072427	177775		ASH	#177775,%4	;SHIFT R4 BY 177775
010726	013767	177776	003010	MOV	@#PS,PSW	;SAVE PS
010734	122767	000000	003002	CMPB	#0,PSW	;IS THE PS 0?
010742	001401			BEQ	+.4	
010744	000000			HLT		;THE PS IS NOT EQUAL TO 0
010746	022704	004000		CMP	#4000,%4	;IS THE RESULT 4000?
010752	001401			BEQ	+.4	
010754	000000			HLT		;R4 IS NOT EQUAL TO 4000

:TEST 167 ASH 40000 SHIFTED BY 177776 = 10000 PS = 0

010756	010701			SCOPE		
010760	012704	040000		MOV	#40000,%4	;LOAD R4 WITH 40000
010764	072427	177776		ASH	#177776,%4	;SHIFT R4 BY 177776
010770	013767	177776	002746	MOV	@#PS,PSW	;SAVE PS
010776	122767	000000	002740	CMPB	#0,PSW	;IS THE PS 0?
011004	001401			BEQ	+.4	
011006	000000			HLT		;THE PS IS NOT EQUAL TO 0
011010	022704	010000		CMP	#10000,%4	;IS THE RESULT 10000?
011014	001401			BEQ	+.4	
011016	000000			HLT		;R4 IS NOT EQUAL TO 10000

:TEST 170 ASH 40000 SHIFTED BY 177777 = 20000 PS = 0

011020	010701			SCOPE		
011022	012704	040000		MOV	#40000,%4	;LOAD R4 WITH 40000
011026	072427	177777		ASH	#177777,%4	;SHIFT R4 BY 177777
011032	013767	177776	002704	MOV	@#PS,PSW	;SAVE PS
011040	122767	000000	002676	CMPB	#0,PSW	;IS THE PS 0?
011046	001401			BEQ	+.4	
011050	000000			HLT		;THE PS IS NOT EQUAL TO 0
011052	022704	020000		CMP	#20000,%4	;IS THE RESULT 20000?
011056	001401			BEQ	+.4	
011060	000000			HLT		;R4 IS NOT EQUAL TO 20000


```

:*****
:TEST 171 ASH 40000 SHIFTED BY 0 = 40000 PS = 0
:*****
    
```

011062	010701			SCOPE		
011064	012704	040000		MOV	#40000,%4	;LOAD R4 WITH 40000
011070	072427	000000		ASH	#0,%4	;SHIFT R4 BY 0
011074	013767	177776	002642	MOV	@#PS,PSW	;SAVE PS
011102	122767	000000	002634	CMPB	#0,PSW	;IS THE PS 0?
011110	001401			BEQ	+.4	
011112	000000			HLT		;THE PS IS NOT EQUAL TO 0
011114	022704	040000		CMP	#40000,%4	;IS THE RESULT 40000?
011120	001401			BEQ	+.4	
011122	000000			HLT		;R4 IS NOT EQUAL TO 40000

```

:*****
:TEST 172 ASH 100000 SHIFTED BY -15. = -1 PS = 10
:*****
    
```

011124	010701			SCOPE		
011126	012704	100000		MOV	#100000,%4	;LOAD R4 WITH 100000
011132	072427	177761		ASH	#-15,%4	;SHIFT R4 BY -15.
011136	013767	177776	002600	MOV	@#PS,PSW	;SAVE PS
011144	122767	000010	002572	CMPB	#10,PSW	;IS THE PS 10?
011152	001401			BEQ	+.4	
011154	000000			HLT		;THE PS IS NOT EQUAL TO 10
011156	022704	177777		CMP	#-1,%4	;IS THE RESULT -1?
011162	001401			BEQ	+.4	
011164	000000			HLT		;R4 IS NOT EQUAL TO -1

```

:*****
:TEST 173 ASH -1 SHIFTED BY 15. = 100000 PS = 11
:*****
    
```

011166	010701			SCOPE		
011170	012704	177777		MOV	#-1,%4	;LOAD R4 WITH -1
011174	072427	000017		ASH	#15,%4	;SHIFT R4 BY 15.
011200	013767	177776	002536	MOV	@#PS,PSW	;SAVE PS
011206	122767	000011	002530	CMPB	#11,PSW	;IS THE PS 11?
011214	001401			BEQ	+.4	
011216	000000			HLT		;THE PS IS NOT EQUAL TO 11
011220	022704	100000		CMP	#100000,%4	;IS THE RESULT 100000?
011224	001401			BEQ	+.4	
011226	000000			HLT		;R4 IS NOT EQUAL TO 100000

:TEST 174 ASH -1 SHIFTED BY 16. = 0 PS = 7
:*****

011230	010701			SCOPE		
011232	012704	177777		MOV	#-1,%4	;LOAD R4 WITH -1
011236	072427	000020		ASH	#16,%4	;SHIFT R4 BY 16.
011242	013767	177776	002474	MOV	@#PS,PSW	;SAVE PS
011250	122767	000007	002466	CMPB	#7,PSW	;IS THE PS 7?
011256	001401			BEQ	+.4	
011260	000000			HLT		;THE PS IS NOT EQUAL TO 7
011262	022704	000000		CMP	#0,%4	;IS THE RESULT 0?
011266	001401			BEQ	+.4	
011270	000000			HLT		;R4 IS NOT EQUAL TO 0

:TEST 175 ASH 137777 SHIFTED BY 15. = 100000 PS = 13
:*****

011272	010701			SCOPE		
011274	012704	137777		MOV	#137777,%4	;LOAD R4 WITH 137777
011300	072427	000017		ASH	#15,%4	;SHIFT R4 BY 15.
011304	013767	177776	002432	MOV	@#PS,PSW	;SAVE PS
011312	122767	000013	002424	CMPB	#13,PSW	;IS THE PS 13?
011320	001401			BEQ	+.4	
011322	000000			HLT		;THE PS IS NOT EQUAL TO 13
011324	022704	100000		CMP	#100000,%4	;IS THE RESULT 100000?
011330	001401			BEQ	+.4	
011332	000000			HLT		;R4 IS NOT EQUAL TO 100000

:TEST 176 ASH 125252 SHIFTED BY 1 = 52524 PS = 3
:*****

011334	010701			SCOPE		
011336	012704	125252		MOV	#125252,%4	;LOAD R4 WITH 125252
011342	072427	000001		ASH	#1,%4	;SHIFT R4 BY 1
011346	013767	177776	002370	MOV	@#PS,PSW	;SAVE PS
011354	122767	000003	002362	CMPB	#3,PSW	;IS THE PS 3?
011362	001401			BEQ	+.4	
011364	000000			HLT		;THE PS IS NOT EQUAL TO 3
011366	022704	052524		CMP	#52524,%4	;IS THE RESULT 52524?
011372	001401			BEQ	+.4	
011374	000000			HLT		;R4 IS NOT EQUAL TO 52524

:TEST 177 ASH 125252 SHIFTED BY -1 = 152525 PS = 10
:*****

011376	010701			SCOPE		
011400	012704	125252		MOV	#125252,%4	;LOAD R4 WITH 125252
011404	072427	177777		ASH	#-1,%4	;SHIFT R4 BY -1
011410	013767	177776	002326	MOV	@#PS,PSW	;SAVE PS
011416	122767	000010	002320	CMPB	#10,PSW	;IS THE PS 10?
011424	001401			BEQ	.+4	
011426	000000			HLT		;THE PS IS NOT EQUAL TO 10
011430	022704	152525		CMP	#152525,%4	;IS THE RESULT 152525?
011434	001401			BEQ	.+4	
011436	000000			HLT		;R4 IS NOT EQUAL TO 152525

:TEST 200 ASH 125252 SHIFTED BY -2 = 165252 PS = 11
:*****

011440	010701			SCOPE		
011442	012704	125252		MOV	#125252,%4	;LOAD R4 WITH 125252
011446	072427	177776		ASH	#-2,%4	;SHIFT R4 BY -2
011452	013767	177776	002264	MOV	@#PS,PSW	;SAVE PS
011460	122767	000011	002256	CMPB	#11,PSW	;IS THE PS 11?
011466	001401			BEQ	.+4	
011470	000000			HLT		;THE PS IS NOT EQUAL TO 11
011472	022704	165252		CMP	#165252,%4	;IS THE RESULT 165252?
011476	001401			BEQ	.+4	
011500	000000			HLT		;R4 IS NOT EQUAL TO 165252

:TEST 201 ASH 40000 SHIFTED BY 177762 = 1 PS = 0
:*****

011502	010701			SCOPE		
011504	012705	040000		MOV	#40000,%5	;LOAD R5 WITH 40000
011510	072527	177762		ASH	#177762,%5	;SHIFT R5 BY 177762
011514	013767	177776	002222	MOV	@#PS,PSW	;SAVE PS
011522	122767	000000	002214	CMPB	#0,PSW	;IS THE PS 0?
011530	001401			BEQ	.+4	
011532	000000			HLT		;THE PS IS NOT EQUAL TO 0
011534	022705	000001		CMP	#1,%5	;IS THE RESULT 1?
011540	001401			BEQ	.+4	
011542	000000			HLT		;R5 IS NOT EQUAL TO 1

: TEST 202 ASH 40000 SHIFTED BY 177763 = 2 PS = 0
: *****

011544	010701			SCOPE		
011546	012705	040000		MOV	#40000,%5	;LOAD R5 WITH 40000
011552	072527	177763		ASH	#177763,%5	;SHIFT R5 BY 177763
011556	013767	177776	002160	MOV	2#PS,PSW	;SAVE PS
011564	122767	000000	002152	CMPB	#0,PSW	;IS THE PS 0?
011572	001401			BEQ	+.4	
011574	000000			HLT		;THE PS IS NOT EQUAL TO 0
011576	022705	000002		CMP	#2,%5	;IS THE RESULT 2?
011602	001401			BEQ	+.4	
011604	000000			HLT		;R5 IS NOT EQUAL TO 2

: TEST 203 ASH 40000 SHIFTED BY 177764 = 4 PS = 0
: *****

011606	010701			SCOPE		
011610	012705	040000		MOV	#40000,%5	;LOAD R5 WITH 40000
011614	072527	177764		ASH	#177764,%5	;SHIFT R5 BY 177764
011620	013767	177776	002116	MOV	2#PS,PSW	;SAVE PS
011626	122767	000000	002110	CMPB	#0,PSW	;IS THE PS 0?
011634	001401			BEQ	+.4	
011636	000000			HLT		;THE PS IS NOT EQUAL TO 0
011640	022705	000004		CMP	#4,%5	;IS THE RESULT 4?
011644	001401			BEQ	+.4	
011646	000000			HLT		;R5 IS NOT EQUAL TO 4

: TEST 204 ASH 40000 SHIFTED BY 177765 = 10 PS = 0
: *****

011650	010701			SCOPE		
011652	012705	040000		MOV	#40000,%5	;LOAD R5 WITH 40000
011656	072527	177765		ASH	#177765,%5	;SHIFT R5 BY 177765
011662	013767	177776	002054	MOV	2#PS,PSW	;SAVE PS
011670	122767	000000	002046	CMPB	#0,PSW	;IS THE PS 0?
011676	001401			BEQ	+.4	
011700	000000			HLT		;THE PS IS NOT EQUAL TO 0
011702	022705	000010		CMP	#10,%5	;IS THE RESULT 10?
011706	001401			BEQ	+.4	
011710	000000			HLT		;R5 IS NOT EQUAL TO 10

;TEST 205 ASH 40000 SHIFTED BY 177766 = 20 PS = 0

011712	010701			SCOPE		
011714	012705	040000		MOV	#40000,%5	;LOAD R5 WITH 40000
011720	072527	177766		ASH	#177766,%5	;SHIFT R5 BY 177766
011724	013767	177776	002012	MOV	@#PS,PSW	;SAVE PS
011732	122767	000000	002004	CMPB	#0,PSW	;IS THE PS 0?
011740	001401			BEQ	+.4	
011742	000000			HLT		;THE PS IS NOT EQUAL TO 0
011744	022705	000020		CMP	#20,%5	;IS THE RESULT 20?
011750	001401			BEQ	+.4	
011752	000000			HLT		;R5 IS NOT EQUAL TO 20

;TEST 206 ASH 40000 SHIFTED BY 177767 = 40 PS = 0

011754	010701			SCOPE		
011756	012705	040000		MOV	#40000,%5	;LOAD R5 WITH 40000
011762	072527	177767		ASH	#177767,%5	;SHIFT R5 BY 177767
011766	013767	177776	001750	MOV	@#PS,PSW	;SAVE PS
011774	122767	000000	001742	CMPB	#0,PSW	;IS THE PS 0?
012002	001401			BEQ	+.4	
012004	000000			HLT		;THE PS IS NOT EQUAL TO 0
012006	022705	000040		CMP	#40,%5	;IS THE RESULT 40?
012012	001401			BEQ	+.4	
012014	000000			HLT		;R5 IS NOT EQUAL TO 40

;TEST 207 ASH 40000 SHIFTED BY 177770 = 100 PS = 0

012016	010701			SCOPE		
012020	012705	040000		MOV	#40000,%5	;LOAD R5 WITH 40000
012024	072527	177770		ASH	#177770,%5	;SHIFT R5 BY 177770
012030	013767	177776	001706	MOV	@#PS,PSW	;SAVE PS
012036	122767	000000	001700	CMPB	#0,PSW	;IS THE PS 0?
012044	001401			BEQ	+.4	
012046	000000			HLT		;THE PS IS NOT EQUAL TO 0
012050	022705	000100		CMP	#100,%5	;IS THE RESULT 100?
012054	001401			BEQ	+.4	
012056	000000			HLT		;R5 IS NOT EQUAL TO 100

:TEST 210 ASH 40000 SHIFTED BY 177771 = 200 PS = 0

012060	010701			SCOPE		
012062	012705	040000		MOV	#40000,%5	;LOAD R5 WITH 40000
012066	072527	177771		ASH	#177771,%5	;SHIFT R5 BY 177771
012072	013767	177776	001644	MOV	@#PS,PSW	;SAVE PS
012100	122767	000000	001636	CMPB	#0,PSW	;IS THE PS 0?
012106	001401			BEQ	+.4	
012110	000000			HLT		;THE PS IS NOT EQUAL TO 0
012112	022705	000200		CMP	#200,%5	;IS THE RESULT 200?
012116	001401			BEQ	+.4	
012120	000000			HLT		;R5 IS NOT EQUAL TO 200

:TEST 211 ASH 40000 SHIFTED BY 177772 = 400 PS = 0

012122	010701			SCOPE		
012124	012705	040000		MOV	#40000,%5	;LOAD R5 WITH 40000
012130	072527	177772		ASH	#177772,%5	;SHIFT R5 BY 177772
012134	013767	177776	001602	MOV	@#PS,PSW	;SAVE PS
012142	122767	000000	001574	CMPB	#0,PSW	;IS THE PS 0?
012150	001401			BEQ	+.4	
012152	000000			HLT		;THE PS IS NOT EQUAL TO 0
012154	022705	000400		CMP	#400,%5	;IS THE RESULT 400?
012160	001401			BEQ	+.4	
012162	000000			HLT		;R5 IS NOT EQUAL TO 400

:TEST 212 ASH 40000 SHIFTED BY 177773 = 1000 PS = 0

012164	010701			SCOPE		
012166	012705	040000		MOV	#40000,%5	;LOAD R5 WITH 40000
012172	072527	177773		ASH	#177773,%5	;SHIFT R5 BY 177773
012176	013767	177776	001540	MOV	@#PS,PSW	;SAVE PS
012204	122767	000000	001532	CMPB	#0,PSW	;IS THE PS 0?
012212	001401			BEQ	+.4	
012214	000000			HLT		;THE PS IS NOT EQUAL TO 0
012216	022705	001000		CMP	#1000,%5	;IS THE RESULT 1000?
012222	001401			BEQ	+.4	
012224	000000			HLT		;R5 IS NOT EQUAL TO 1000

:TEST 213 ASH 40000 SHIFTED BY 177774 = 2000 PS = 0

012226	010701			SCOPE		
012230	012705	040000		MOV	#40000,%5	;LOAD R5 WITH 40000
012234	072527	177774		ASH	#177774,%5	;SHIFT R5 BY 177774
012240	013767	177776	001476	MOV	@#PS,PSW	;SAVE PS
012246	122767	000000	001470	CMPB	#0,PSW	;IS THE PS 0?
012254	001401			BEQ	+.4	
012256	000000			HLT		;THE PS IS NOT EQUAL TO 0
012260	022705	002000		CMP	#2000,%5	;IS THE RESULT 2000?
012264	001401			BEQ	+.4	
012266	000000			HLT		;R5 IS NOT EQUAL TO 2000

:TEST 214 ASH 40000 SHIFTED BY 177775 = 4000 PS = 0

012270	010701			SCOPE		
012272	012705	040000		MOV	#40000,%5	;LOAD R5 WITH 40000
012276	072527	177775		ASH	#177775,%5	;SHIFT R5 BY 177775
012302	013767	177776	001434	MOV	@#PS,PSW	;SAVE PS
012310	122767	000000	001426	CMPB	#0,PSW	;IS THE PS 0?
012316	001401			BEQ	+.4	
012320	000000			HLT		;THE PS IS NOT EQUAL TO 0
012322	022705	004000		CMP	#4000,%5	;IS THE RESULT 4000?
012326	001401			BEQ	+.4	
012330	000000			HLT		;R5 IS NOT EQUAL TO 4000

:TEST 215 ASH 40000 SHIFTED BY 177776 = 10000 PS = 0

012332	010701			SCOPE		
012334	012705	040000		MOV	#40000,%5	;LOAD R5 WITH 40000
012340	072527	177776		ASH	#177776,%5	;SHIFT R5 BY 177776
012344	013767	177776	001372	MOV	@#PS,PSW	;SAVE PS
012352	122767	000000	001364	CMPB	#0,PSW	;IS THE PS 0?
012360	001401			BEQ	+.4	
012362	000000			HLT		;THE PS IS NOT EQUAL TO 0
012364	022705	010000		CMP	#10000,%5	;IS THE RESULT 10000?
012370	001401			BEQ	+.4	
012372	000000			HLT		;R5 IS NOT EQUAL TO 10000

:TEST 216 ASH 40000 SHIFTED BY 177777 = 20000 PS = 0

012374	010701			SCOPE		
012376	012705	040000		MOV	#40000,%5	;LOAD R5 WITH 40000
012402	072527	177777		ASH	#177777,%5	;SHIFT R5 BY 177777
012406	013767	177776	001330	MOV	@#PS,PSW	;SAVE PS
012414	122767	000000	001322	CMPB	#0,PSW	;IS THE PS 0?
012422	001401			BEQ	.+4	
012424	000000			HLT		;THE PS IS NOT EQUAL TO 0
012426	022705	020000		CMP	#20000,%5	;IS THE RESULT 20000?
012432	001401			BEQ	.+4	
012434	000000			HLT		;R5 IS NOT EQUAL TO 20000

:TEST 217 ASH 40000 SHIFTED BY 0 = 40000 PS = 0

012436	010701			SCOPE		
012440	012705	040000		MOV	#40000,%5	;LOAD R5 WITH 40000
012444	072527	000000		ASH	#0,%5	;SHIFT R5 BY 0
012450	013767	177776	001266	MOV	@#PS,PSW	;SAVE PS
012456	122767	000000	001260	CMPB	#0,PSW	;IS THE PS 0?
012464	001401			BEQ	.+4	
012466	000000			HLT		;THE PS IS NOT EQUAL TO 0
012470	022705	040000		CMP	#40000,%5	;IS THE RESULT 40000?
012474	001401			BEQ	.+4	
012476	000000			HLT		;R5 IS NOT EQUAL TO 40000

:TEST 220 ASH 100000 SHIFTED BY -15. = -1 PS = 10

012500	010701			SCOPE		
012502	012705	100000		MOV	#100000,%5	;LOAD R5 WITH 100000
012506	072527	177761		ASH	#-15,%5	;SHIFT R5 BY -15.
012512	013767	177776	001224	MOV	@#PS,PSW	;SAVE PS
012520	122767	000010	001216	CMPB	#10,PSW	;IS THE PS 10?
012526	001401			BEQ	.+4	
012530	000000			HLT		;THE PS IS NOT EQUAL TO 10
012532	022705	177777		CMP	#-1,%5	;IS THE RESULT -1?
012536	001401			BEQ	.+4	
012540	000000			HLT		;R5 IS NOT EQUAL TO -1

:TEST 221 ASH -1 SHIFTED BY 15. = 100000 PS = 11

012542	010701			SCOPE		
012544	012705	177777		MOV	#-1,%5	;LOAD R5 WITH -1
012550	072527	000017		ASH	#15,%5	;SHIFT R5 BY 15.
012554	013767	177776	001162	MOV	@#PS,PSW	;SAVE PS
012562	122767	000011	001154	CMPB	#11,PSW	;IS THE PS 11?
012570	001401			BEQ	+.4	
012572	000000			HLT		;THE PS IS NOT EQUAL TO 11
012574	022705	100000		CMP	#100000,%5	;IS THE RESULT 100000?
012600	001401			BEQ	+.4	
012602	000000			HLT		;R5 IS NOT EQUAL TO 100000

:TEST 222 ASH -1 SHIFTED BY 16. = 0 PS = 7

012604	010701			SCOPE		
012606	012705	177777		MOV	#-1,%5	;LOAD R5 WITH -1
012612	072527	000020		ASH	#16,%5	;SHIFT R5 BY 16.
012616	013767	177776	001120	MOV	@#PS,PSW	;SAVE PS
012624	122767	000007	001112	CMPB	#7,PSW	;IS THE PS 7?
012632	001401			BEQ	+.4	
012634	000000			HLT		;THE PS IS NOT EQUAL TO 7
012636	022705	000000		CMP	#0,%5	;IS THE RESULT 0?
012642	001401			BEQ	+.4	
012644	000000			HLT		;R5 IS NOT EQUAL TO 0

:TEST 223 ASH 137777 SHIFTED BY 15. = 100000 PS = 13

012646	010701			SCOPE		
012650	012705	137777		MOV	#137777,%5	;LOAD R5 WITH 137777
012654	072527	000017		ASH	#15,%5	;SHIFT R5 BY 15.
012660	013767	177776	001056	MOV	@#PS,PSW	;SAVE PS
012666	122767	000013	001050	CMPB	#13,PSW	;IS THE PS 13?
012674	001401			BEQ	+.4	
012676	000000			HLT		;THE PS IS NOT EQUAL TO 13
012700	022705	100000		CMP	#100000,%5	;IS THE RESULT 100000?
012704	001401			BEQ	+.4	
012706	000000			HLT		;R5 IS NOT EQUAL TO 100000

:TEST 224 ASH 125252 SHIFTED BY 1 = 52524 PS = 3

012710	010701			SCOPE		
012712	012705	125252		MOV	#125252,%5	;LOAD R5 WITH 125252
012716	072527	000001		ASH	#1,%5	;SHIFT R5 BY 1
012722	013767	177776	001014	MOV	3#PS,PSW	;SAVE PS
012730	122767	000003	001006	CMPB	#3,PSW	;IS THE PS 3?
012736	001401			BEQ	.+4	
012740	000000			HLT		;THE PS IS NOT EQUAL TO 3
012742	022705	052524		CMP	#52524,%5	;IS THE RESULT 52524?
012746	001401			BEQ	.+4	
012750	000000			HLT		;R5 IS NOT EQUAL TO 52524

:TEST 225 ASH 125252 SHIFTED BY -1 = 152525 PS = 10

012752	010701			SCOPE		
012754	012705	125252		MOV	#125252,%5	;LOAD R5 WITH 125252
012760	072527	177777		ASH	#-1,%5	;SHIFT R5 BY -1
012764	013767	177776	000752	MOV	3#PS,PSW	;SAVE PS
012772	122767	000010	000744	CMPB	#10,PSW	;IS THE PS 10?
013000	001401			BEQ	.+4	
013002	000000			HLT		;THE PS IS NOT EQUAL TO 10
013004	022705	152525		CMP	#152525,%5	;IS THE RESULT 152525?
013010	001401			BEQ	.+4	
013012	000000			HLT		;R5 IS NOT EQUAL TO 152525

:TEST 226 ASH 125252 SHIFTED BY -2 = 165252 PS = 11

013014	010701			SCOPE		
013016	012705	125252		MOV	#125252,%5	;LOAD R5 WITH 125252
013022	072527	177776		ASH	#-2,%5	;SHIFT R5 BY -2
013026	013767	177776	000710	MOV	3#PS,PSW	;SAVE PS
013034	122767	000011	000702	CMPB	#11,PSW	;IS THE PS 11?
013042	001401			BEQ	.+4	
013044	000000			HLT		;THE PS IS NOT EQUAL TO 11
013046	022705	165252		CMP	#165252,%5	;IS THE RESULT 165252?
013052	001401			BEQ	.+4	
013054	000000			HLT		;R5 IS NOT EQUAL TO 165252

013056	012704	177771		MOV	#-7,%4	
013062	012702	013750		MOV	#51,%2	
013066	012703	013752		MOV	#52,%3	

:TEST 227 11/40 ASH 125252 SHIFTED BY S1 = 177525 PS = 10

013072	010701			SCOPE		
013074	012700	125252		MOV	#125252,%0	;LOAD RO WITH 125252
013100	072067	000644		ASH	S1,%0	;SHIFT RO BY S1
013104	013767	177776	000632	MOV	@#PS,PSW	;SAVE PS
013112	122767	000010	000624	CMPB	#10,PSW	;IS THE PS 10?
013120	001401			BEQ	+.4	
013122	000000			HLT		;THE PS IS NOT EQUAL TO 10
013124	022700	177525		CMP	#177525,%0	;IS THE RESULT 177525?
013130	001401			BEQ	+.4	
013132	000000			HLT		;RO IS NOT EQUAL TO 177525

:TEST 230 11/40 ASH 125252 SHIFTED BY @S2 = 177525 PS = 10

013134	010701			SCOPE		
013136	012700	125252		MOV	#125252,%0	;LOAD RO WITH 125252
013142	072077	000604		ASH	@S2,%0	;SHIFT RO BY @S2
013146	013767	177776	000570	MOV	@#PS,PSW	;SAVE PS
013154	122767	000010	000562	CMPB	#10,PSW	;IS THE PS 10?
013162	001401			BEQ	+.4	
013164	000000			HLT		;THE PS IS NOT EQUAL TO 10
013166	022700	177525		CMP	#177525,%0	;IS THE RESULT 177525?
013172	001401			BEQ	+.4	
013174	000000			HLT		;RO IS NOT EQUAL TO 177525

:TEST 231 11/40 ASH 125252 SHIFTED BY @S1 = 177525 PS = 10

013176	010701			SCOPE		
013200	012700	125252		MOV	#125252,%0	;LOAD RO WITH 125252
013204	072037	013750		ASH	@S1,%0	;SHIFT RO BY @S1
013210	013767	177776	000526	MOV	@#PS,PSW	;SAVE PS
013216	122767	000010	000520	CMPB	#10,PSW	;IS THE PS 10?
013224	001401			BEQ	+.4	
013226	000000			HLT		;THE PS IS NOT EQUAL TO 10
013230	022700	177525		CMP	#177525,%0	;IS THE RESULT 177525?
013234	001401			BEQ	+.4	
013236	000000			HLT		;RO IS NOT EQUAL TO 177525

:TEST 232 11/40 ASH 125252 SHIFTED BY %4 = 177525 PS = 10
:*****

013240	010701			SCOPE		
013242	012700	125252		MOV	#125252,%0	:LOAD RO WITH 125252
013246	072004			ASH	%4,%0	:SHIFT RO BY %4
013250	013767	177776	000466	MOV	2#PS,PSW	:SAVE PS
013256	122767	000010	000460	CMPB	#10,PSW	:IS THE PS 10?
013264	001401			BEQ	+.4	
013266	000000			HLT		:THE PS IS NOT EQUAL TO 10
013270	022700	177525		CMP	#177525,%0	:IS THE RESULT 177525?
013274	001401			BEQ	+.4	
013276	000000			HLT		:RO IS NOT EQUAL TO 177525

:TEST 233 11/40 ASH 125252 SHIFTED BY (2)+ = 177525 PS = 10
:*****

013300	010701			SCOPE		
013302	012700	125252		MOV	#125252,%0	:LOAD RO WITH 125252
013306	072022			ASH	(2)+,%0	:SHIFT RO BY (2)+
013310	013767	177776	000426	MOV	2#PS,PSW	:SAVE PS
013316	122767	000010	000420	CMPB	#10,PSW	:IS THE PS 10?
013324	001401			BEQ	+.4	
013326	000000			HLT		:THE PS IS NOT EQUAL TO 10
013330	022700	177525		CMP	#177525,%0	:IS THE RESULT 177525?
013334	001401			BEQ	+.4	
013336	000000			HLT		:RO IS NOT EQUAL TO 177525

:TEST 234 11/40 ASH 125252 SHIFTED BY -(2) = 177525 PS = 10
:*****

013340	010701			SCOPE		
013342	012700	125252		MOV	#125252,%0	:LOAD RO WITH 125252
013346	072042			ASH	-(2),%0	:SHIFT RO BY -(2)
013350	013767	177776	000366	MOV	2#PS,PSW	:SAVE PS
013356	122767	000010	000360	CMPB	#10,PSW	:IS THE PS 10?
013364	001401			BEQ	+.4	
013366	000000			HLT		:THE PS IS NOT EQUAL TO 10
013370	022700	177525		CMP	#177525,%0	:IS THE RESULT 177525?
013374	001401			BEQ	+.4	
013376	000000			HLT		:RO IS NOT EQUAL TO 177525

:TEST 235 11/40 ASH 125252 SHIFTED BY 2(3) = 177252 PS = 11

013400	010701			SCOPE		
013402	012700	125252		MOV	#125252,%0	;LOAD RO WITH 125252
013406	072063	000002		ASH	2(3),%0	;SHIFT RO BY 2(3)
013412	013767	177776	000324	MOV	2#PS,PSW	;SAVE PS
013420	122767	000011	000316	CMPB	#11,PSW	;IS THE PS 11?
013426	001401			BEQ	+.4	
013430	000000			HLT		;THE PS IS NOT EQUAL TO 11
013432	022700	177252		CMP	#177252,%0	;IS THE RESULT 177252?
013436	001401			BEQ	+.4	
013440	000000			HLT		;RO IS NOT EQUAL TO 177252

:TEST 236 11/40 ASH 125252 SHIFTED BY 2(3) = 177525 PS = 10

013442	010701			SCOPE		
013444	012700	125252		MOV	#125252,%0	;LOAD RO WITH 125252
013450	072073	000000		ASH	2(3),%0	;SHIFT RO BY 2(3)
013454	013767	177776	000262	MOV	2#PS,PSW	;SAVE PS
013462	122767	000010	000254	CMPB	#10,PSW	;IS THE PS 10?
013470	001401			BEQ	+.4	
013472	000000			HLT		;THE PS IS NOT EQUAL TO 10
013474	022700	177525		CMP	#177525,%0	;IS THE RESULT 177525?
013500	001401			BEQ	+.4	
013502	000000			HLT		;RO IS NOT EQUAL TO 177525

:TEST 237 11/40 ASH 125252 SHIFTED BY 2(3)+ = 177525 PS = 10

013504	010701			SCOPE		
013506	012700	125252		MOV	#125252,%0	;LOAD RO WITH 125252
013512	072033			ASH	2(3)+,%0	;SHIFT RO BY 2(3)+
013514	013767	177776	000222	MOV	2#PS,PSW	;SAVE PS
013522	122767	000010	000214	CMPB	#10,PSW	;IS THE PS 10?
013530	001401			BEQ	+.4	
013532	000000			HLT		;THE PS IS NOT EQUAL TO 10
013534	022700	177525		CMP	#177525,%0	;IS THE RESULT 177525?
013540	001401			BEQ	+.4	
013542	000000			HLT		;RO IS NOT EQUAL TO 177525

```
*****
:TEST 240 11/40 ASH 125252 SHIFTED BY 2-(3) = 177525 PS = 10
*****
```

013544	010701			SCOPE		
013546	012700	125252		MOV	#125252,%0	;LOAD R0 WITH 125252
013552	072053			ASH	2-(3),%0	;SHIFT R0 BY 2-(3)
013554	013767	177776	000162	MOV	2#PS,PSW	;SAVE PS
013562	122767	000010	000154	CMPB	#10,PSW	;IS THE PS 10?
013570	001401			BEQ	+.4	
013572	000000			HLT		;THE PS IS NOT EQUAL TO 10
013574	022700	177525		CMP	#177525,%0	;IS THE RESULT 177525?
013600	001401			BEQ	+.4	
013602	000000			HLT		;R0 IS NOT EQUAL TO 177525

```
*****
:TEST 241 CHECKS THAT ASH WITH DST MODE 5 RETURNS
:DECREMENTED OPERAND TO DST REGISTER
*****
:NOTE: THIS ROUTINE DOES NOT HAVE TO PASS IN SOME CASES IN FIELD
:SERVICE ONLY. IT MUST PASS IN MANUFACTURING TO REFLECT ECO M7238-0004.
:SEE PARAGRAPH 9.1 AT BEGINNING OF PROGRAM FOR FULL EXPLANATION.
```

013604	010701			SCOPE		
013606	012700	000100		MOV	#100,R0	;LOAD R0 WITH 100
013612	012701	013636		MOV	#Q+2,R1	;LOAD R1 WITH DST OPERAND
013616	072051			ASH	2-(1),R0	;SHIFT USING DST MODE 5
013620	022701	013634		CMP	#Q,R1	;DECREMENTED OPERAND RETURNED TO R1?
013624	001404			BEQ	PASCNT	;YES
013626	000000			HLT		;R1 DOES NOT HAVE DECREMENTED OPERAND
013630	000402			BR	PASCNT	;BRANCH AHEAD ON CONTINUE
013632	000003			.WORD	3	
013634	013632			.WORD	.-2	
013636	005267	165136		PASCNT: INC	ICNT	
013642	016737	165132	177570	MOV	ICNT,2#DISPLAY	
013650	022767	020000	165122	CMP	#20000,ICNT	
013656	001402			BEQ	+.6	
013660	000167	165152		JMP	BEG	
013664	005067	165110		CLR	ICNT	
013670	105737	177564		TSTB	2#TPS	
013674	100375			BPL	.-4	
013676	112737	000007	177566	MOVB	#7,2#TPB	;RING BELL FOR PASS COMPLETE
013704	105737	177564		TSTB	2#TPS	
013710	100375			BPL	.-4	
013712	112737	000052	177566	MOVB	#52,2#TPB	;ALSO PRINT '*' FOR PASS COMPLETE
013720	013700	000042		MOV	2#42,%0	;GET MONITOR RETURN ADDRESS
013724	001405			BEQ	AGAIN	;SKIP IF NONE
013726	000005			RESET		
013730	004710			SENDAD: JSR	7,(0)	;GO BACK TO THE MONITOR
013732	000240			NOP		
013734	000240			NOP		
013736	000240			NOP		
013740	000137	000200		AGAIN: JMP	2#200	;RESTART THE PROGRAM

H05

013744	000000		
013746	000007		
013750	177771		
013752	013750		
013754	177772		
013756	005015	041504	041113
013764	026511	020102	051501
013772	020110	047111	052123
014000	052522	052103	047511
014006	020116	042524	052123
014014	005015	000012	

PSW: 0
SQ: 7
S1: -7
S2: S1
S3: -6

MSG1: .ASCIZ <15><12>/DCKBI-B ASH INSTRUCTION TEST/<15><12><12>

000001

.END

AGAIN 013740
 BEG 001036
 BEG1 001002
 DISPLA= 177570
 DUMMY = 000000
 HLT = 000000

2957	2963#	191#	2948										
182	187												
178	181#												
165#	2945*												
167#													
162#	211	214	228	231	245	248	263	266	290	283	297	300	
314	317	331	334	348	351	365	368	382	385	399	402	416	
419	433	436	450	453	467	470	484	487	501	504	518	521	
535	538	552	555	569	572	586	589	603	606	620	623	637	
640	654	657	671	674	688	691	705	708	722	725	739	742	
756	759	773	776	790	793	807	810	824	827	841	844	858	
861	875	878	892	895	909	912	926	929	943	946	960	963	
977	980	994	997	1011	1014	1028	1031	1045	1048	1062	1065	1079	
1082	1096	1099	1113	1116	1130	1133	1147	1150	1164	1167	1181	1184	
1198	1201	1215	1218	1232	1235	1249	1252	1266	1269	1283	1286	1300	
1303	1317	1320	1334	1337	1351	1354	1368	1371	1385	1388	1402	1405	
1419	1422	1436	1439	1453	1456	1470	1473	1487	1490	1504	1507	1521	
1524	1538	1541	1555	1558	1572	1575	1589	1592	1606	1609	1623	1626	
1640	1643	1657	1660	1674	1677	1691	1694	1708	1711	1725	1728	1742	
1745	1759	1762	1776	1779	1793	1796	1810	1813	1827	1830	1844	1847	
1861	1864	1878	1881	1895	1898	1912	1915	1929	1932	1946	1949	1963	
1966	1980	1983	1997	2000	2014	2017	2031	2034	2048	2051	2065	2068	
2082	2085	2099	2102	2116	2119	2133	2136	2150	2153	2167	2170	2184	
2187	2201	2204	2218	2221	2235	2238	2252	2255	2269	2272	2286	2289	
2303	2306	2320	2323	2337	2340	2354	2357	2371	2374	2388	2391	2405	
2408	2422	2425	2439	2442	2456	2459	2473	2476	2490	2493	2507	2510	
2524	2527	2541	2544	2558	2561	2575	2578	2592	2595	2609	2612	2626	
2629	2643	2646	2660	2663	2677	2680	2694	2697	2711	2714	2728	2731	
2745	2748	2765	2768	2782	2785	2799	2802	2816	2819	2833	2836	2850	
2853	2867	2870	2884	2887	2901	2904	2918	2921	2939				
180#	2944*	2945	2946	2949*									
168#	253	270	287	304	321	338	355	372	389	406	423	440	
457	474	491	508	525	542	559	576	593	610	627	644	661	
678	695	712	729	746	763	780	797	814	831	848	865	882#	
899	916	933	950	967	984	1001	1018	1035	1052	1069	1086	1103	
1120	1137	1154	1171	1188	1205	1222	1239	1256#	1273	1290	1307	1324	
1341	1358	1375	1392	1409	1426	1443	1460	1477	1494	1511	1528	1545	
1562	1579	1596	1613	1630#	1647	1664	1681	1698	1715	1732	1749	1766	
1783	1800	1817	1834	1851	1868	1885	1902	1919	1936	1953	1970	1987	
2004#	2021	2038	2055	2072	2089	2106	2123	2140	2157	2174	2191	2208	
2225	2242	2259	2276	2293	2310	2327	2344	2361	2378#	2395	2412	2429	
2446	2463	2480	2497	2514	2531	2548	2565	2582	2599	2616	2633	2650	
2667	2684	2701	2718	2735	2752#								
183	2970#												
166#	201	218#	235#	252#	253	270#	287#	304#	321#	338#	355#	372#	
389#	406#	423#	440#	457#	474#	491#	508#	525#	542#	559#	576#	593#	
610#	627#	644#	661#	678#	695#	712#	729#	746#	763#	780#	797#	814#	
831#	848#	865#	882#	899#	916#	933#	950#	967#	984#	1001#	1018#	1035#	
1052#	1069#	1086#	1103#	1120#	1137#	1154#	1171#	1188#	1205#	1222#	1239#	1256#	
1273#	1290#	1307#	1324#	1341#	1358#	1375#	1392#	1409#	1426#	1443#	1460#	1477#	
1494#	1511#	1528#	1545#	1562#	1579#	1596#	1613#	1630#	1647#	1664#	1681#	1698#	
1715#	1732#	1749#	1766#	1783#	1800#	1817#	1834#	1851#	1868#	1885#	1902#	1919#	
1936#	1953#	1970#	1987#	2004#	2021#	2038#	2055#	2072#	2089#	2106#	2123#	2140#	
2157#	2174#	2191#	2208#	2225#	2242#	2259#	2276#	2293#	2310#	2327#	2344#	2361#	
2378#	2395#	2412#	2429#	2446#	2463#	2480#	2497#	2514#	2531#	2548#	2565#	2582#	
2599#	2616#	2633#	2650#	2667#	2684#	2701#	2718#	2735#	2752#	2772#	2789#		

ICNT 001000
 M = 000006

MSG1 013756
 N = 000241

PASCNT 013636
PS = 177776

PSW 013744

Q 013634
R = 100000

RO =%000000
R1 =%000001
RS =%000005
SCOPE = 010701

2806#	2823#	2840#	2857#	2874#	2891#	2908#	2925#						
2938	2940	2944#											
163#	192*	195*	208	225	242	260	277	294	311	328	345	362	
379	396	413	430	447	464	481	498	515	532	549	566	583	
600	617	634	651	668	685	702	719	736	753	770	787	804	
821	838	855	872	889	906	923	940	957	974	991	1008	1025	
1042	1059	1076	1093	1110	1127	1144	1161	1178	1195	1212	1229	1246	
1263	1280	1297	1314	1331	1348	1365	1382	1399	1416	1433	1450	1467	
1484	1501	1518	1535	1552	1569	1586	1603	1620	1637	1654	1671	1688	
1705	1722	1739	1756	1773	1790	1807	1824	1841	1858	1875	1892	1909	
1926	1943	1960	1977	1994	2011	2028	2045	2062	2079	2096	2113	2130	
2147	2164	2181	2198	2215	2232	2249	2266	2283	2300	2317	2334	2351	
2368	2385	2402	2419	2436	2453	2470	2487	2504	2521	2538	2555	2572	
2589	2606	2623	2640	2657	2674	2691	2708	2725	2742	2762	2779	2796	
2813	2830	2847	2864	2881	2898	2915							
208*	209	225*	226	242*	243	260*	261	277*	278	294*	295	311*	
312	328*	329	345*	346	362*	363	379*	380	396*	397	413*	414	
430*	431	447*	448	464*	465	481*	482	498*	499	515*	516	532*	
533	549*	550	566*	567	583*	584	600*	601	617*	618	634*	635	
651*	652	668*	669	685*	686	702*	703	719*	720	736*	737	753*	
754	770*	771	787*	788	804*	805	821*	822	838*	839	855*	856	
872*	873	889*	890	906*	907	923*	924	940*	941	957*	958	974*	
975	991*	992	1008*	1009	1025*	1026	1042*	1043	1059*	1060	1076*	1077	
1093*	1094	1110*	1111	1127*	1128	1144*	1145	1161*	1162	1178*	1179	1195*	
1196	1212*	1213	1229*	1230	1246*	1247	1263*	1264	1280*	1281	1297*	1298	
1314*	1315	1331*	1332	1348*	1349	1365*	1366	1382*	1383	1399*	1400	1416*	
1417	1433*	1434	1450*	1451	1467*	1468	1484*	1485	1501*	1502	1518*	1519	
1535*	1536	1552*	1553	1569*	1570	1586*	1587	1603*	1604	1620*	1621	1637*	
1638	1654*	1655	1671*	1672	1688*	1689	1705*	1706	1722*	1723	1739*	1740	
1756*	1757	1773*	1774	1790*	1791	1807*	1808	1824*	1825	1841*	1842	1858*	
1859	1875*	1876	1892*	1893	1909*	1910	1926*	1927	1943*	1944	1960*	1961	
1977*	1978	1994*	1995	2011*	2012	2028*	2029	2045*	2046	2062*	2063	2079*	
2080	2096*	2097	2113*	2114	2130*	2131	2147*	2148	2164*	2165	2181*	2182	
2198*	2199	2215*	2216	2232*	2233	2249*	2250	2266*	2267	2283*	2284	2300*	
2301	2317*	2318	2334*	2335	2351*	2352	2368*	2369	2385*	2386	2402*	2403	
2419*	2420	2436*	2437	2453*	2454	2470*	2471	2487*	2488	2504*	2505	2521*	
2522	2538*	2539	2555*	2556	2572*	2573	2589*	2590	2606*	2607	2623*	2624	
2640*	2641	2657*	2658	2674*	2675	2691*	2692	2708*	2709	2725*	2726	2742*	
2743	2762*	2763	2779*	2780	2796*	2797	2813*	2814	2830*	2831	2847*	2848	
2864*	2865	2881*	2882	2898*	2899	2915*	2916	2931*	2932	2948*	2949	2965*	
2935	2937	2942#											
253#	270#	287#	304#	321#	338#	355#	372#	389#	406#	423#	440#	457#	
474#	491#	508#	525#	542#	559#	576#	593#	610#	627#	644#	661#	678#	
695#	712#	729#	746#	763#	780#	797#	814#	831#	848#	865#	882#	899#	
1018#	1035#	1052#	1069#	1086#	1103#	1120#	1137#	1154#	1171#	1188#	1205#	1222#	
1341#	1358#	1375#	1392#	1409#	1426#	1443#	1460#	1477#	1494#	1511#	1528#	1545#	
1664#	1681#	1698#	1715#	1732#	1749#	1766#	1783#	1800#	1817#	1834#	1851#	1868#	
1885#	2004#	2021#	2038#	2055#	2072#	2089#	2106#	2123#	2140#	2157#	2174#	2191#	
2208#	2225#	2242#	2259#	2276#	2293#	2310#	2327#	2344#	2361#	2378#	2395#	2412#	
2531#	2548#	2565#	2582#	2599#	2616#	2633#							
2934#	2936#	2937											
183#													
161#	205	222	239	257	274	291	308	325	342	359	376	393	
410	427	444	461	478	495	512	529	546	563	580	597	614	
631	648	665	682	699	716	733	750	767	784	801	818	835	

K05

852	869	886	903	920	937	954	971	988	1005	1022	1039	1056
1073	1090	1107	1124	1141	1158	1175	1192	1209	1226	1243	1260	1277
1294	1311	1328	1345	1362	1379	1396	1413	1430	1447	1464	1481	1498
1515	1532	1549	1566	1583	1600	1617	1634	1651	1668	1685	1702	1719
1736	1753	1770	1787	1804	1821	1838	1855	1872	1889	1906	1923	1940
1957	1974	1991	2008	2025	2042	2059	2076	2093	2110	2127	2144	2161
2178	2195	2212	2229	2246	2263	2280	2297	2314	2331	2348	2365	2382
2399	2416	2433	2450	2467	2484	2501	2518	2535	2552	2569	2586	2603
2620	2637	2654	2671	2688	2705	2722	2739	2756	2773	2790	2807	2824
2844	2861	2878	2895	2912	2929	2946	2963	2980	2997	3014	3031	3048
164#	165	193	196	198								
2966#												
2753	2761	2795	2967#	2968								
2754	2778	2968#										
2969#												
253#	270#	287#	304#	321#	338#	355#	372#	389#	406#	423#	440#	457#
474#	491#	508#	525#	542#	559#	576#	593#	610#	627#	644#	661#	678#
695#	712#	729#	746#	763#	780#	797#	814#	831#	848#	865#	882#	899#
1018#	1035#	1052#	1069#	1086#	1103#	1120#	1137#	1154#	1171#	1188#	1205#	1222#
1341#	1358#	1375#	1392#	1409#	1426#	1443#	1460#	1477#	1494#	1511#	1528#	1545#
1664#	1681#	1698#	1715#	1732#	1749#	1766#	1783#	1800#	1817#	1834#	1851#	1868#
1885#	2004#	2021#	2038#	2055#	2072#	2089#	2106#	2123#	2140#	2157#	2174#	2191#
2208#	2225#	2242#	2259#	2276#	2293#	2310#	2327#	2344#	2361#	2378#	2395#	2412#
2531#	2548#	2565#	2582#	2599#	2616#	2633#	2650#	2667#	2684#	2701#	2718#	2735#
160#	188#	2952#	2955#									
159#	184	2950	2953									
174	181	2959#										
170#	171	173#	175#	177#	179#	185	194	197	210	213	227	230
244	247	262	265	279	282	296	299	313	316	330	333	347
350	364	367	381	384	398	401	415	418	432	435	449	452
466	469	483	486	500	503	517	520	534	537	551	554	568
571	585	588	602	605	619	622	636	639	653	656	670	673
687	690	704	707	721	724	738	741	755	758	772	775	789
792	806	809	823	826	840	843	857	860	874	877	891	894
908	911	925	928	942	945	959	962	976	979	993	996	1010
1013	1027	1030	1044	1047	1061	1064	1078	1081	1095	1098	1112	1115
1129	1132	1146	1149	1163	1166	1180	1183	1197	1200	1214	1217	1231
1234	1248	1251	1265	1268	1282	1285	1299	1302	1316	1319	1333	1336
1350	1353	1367	1370	1384	1387	1401	1404	1418	1421	1435	1438	1452
1455	1469	1472	1486	1489	1503	1506	1520	1523	1537	1540	1554	1557
1571	1574	1588	1591	1605	1608	1622	1625	1639	1642	1656	1659	1673
1676	1690	1693	1707	1710	1724	1727	1741	1744	1758	1761	1775	1778
1792	1795	1809	1812	1826	1829	1843	1846	1860	1863	1877	1880	1894
1897	1911	1914	1928	1931	1945	1948	1962	1965	1979	1982	1996	1999
2013	2016	2030	2033	2047	2050	2064	2067	2081	2084	2098	2101	2115
2118	2132	2135	2149	2152	2166	2169	2183	2186	2200	2203	2217	2220
2234	2237	2251	2254	2268	2271	2285	2288	2302	2305	2319	2322	2336
2339	2353	2356	2370	2373	2387	2390	2404	2407	2421	2424	2438	2441
2455	2458	2472	2475	2489	2492	2506	2509	2523	2526	2540	2543	2557
2560	2574	2577	2591	2594	2608	2611	2625	2628	2642	2645	2659	2662
2676	2679	2693	2696	2710	2713	2727	2730	2744	2747	2761	2764	2778
2784	2798	2801	2815	2818	2832	2835	2849	2852	2866	2869	2883	2886
2900	2903	2917	2920	2942	2947	2951	2954					

SWR = 177570
 SO = 013746
 S1 = 013750
 S2 = 013752
 S3 = 013754
 T = 000001

TPB = 177566
 TPS = 177564
 SENDAD = 013730
 . = 014020

.SERRO	1#
.SERRT	1#
.SMULT	1#
.SPOWE	1#
.SRAND	1#
.SRDDE	1#
.SRDOC	1#
.SREAD	1#
.SR2AZ	1#
.SSAVE	1#
.SSB2D	1#
.SSB20	1#
.SSCOP	1#
.SSIZE	1#
.SSUPR	1#
.STRAP	1#
.STYPB	1#
.STYPD	1#
.STYPE	1#
.STYPO	1#
.S4OCA	1#
.117D	1#

ASH	207	224	241	259	276	293	310	327	344	361	378	395	412	429	446
	463	480	497	514	531	548	565	582	599	616	633	650	667	684	701
	718	735	752	769	786	803	820	837	854	871	888	905	922	939	956
	973	990	1007	1024	1041	1058	1075	1092	1109	1126	1143	1160	1177	1194	1211
	1228	1245	1262	1279	1296	1313	1330	1347	1364	1381	1398	1415	1432	1449	1466
	1483	1500	1517	1534	1551	1568	1585	1602	1619	1636	1653	1670	1687	1704	1721
	1738	1755	1772	1789	1806	1823	1840	1857	1874	1891	1908	1925	1942	1959	1976
	1993	2010	2027	2044	2061	2078	2095	2112	2129	2146	2163	2180	2197	2214	2231
	2248	2265	2282	2299	2316	2333	2350	2367	2384	2401	2418	2435	2452	2469	2486
	2503	2520	2537	2554	2571	2588	2605	2622	2639	2656	2673	2690	2707	2724	2741
	2761	2778	2795	2812	2829	2846	2863	2880	2897	2914	2936				
BEG	182	187	194	197	210	213	227	230	244	247	262	265	279	282	296
	299	313	316	330	333	347	350	364	367	381	384	398	401	415	418
	432	435	449	452	466	469	483	486	500	503	517	520	534	537	551
	554	568	571	585	588	602	605	619	622	636	639	653	656	670	673
	687	690	704	707	721	724	738	741	755	758	772	775	789	792	806
	809	823	826	840	843	857	860	874	877	891	894	908	911	925	928
	942	945	959	962	976	979	993	996	1010	1013	1027	1030	1044	1047	1061
	1064	1078	1081	1095	1098	1112	1115	1129	1132	1146	1149	1163	1166	1180	1183
	1197	1200	1214	1217	1231	1234	1248	1251	1265	1268	1282	1285	1299	1302	1316
	1319	1333	1336	1350	1353	1367	1370	1384	1387	1401	1404	1418	1421	1435	1438
	1452	1455	1469	1472	1486	1489	1503	1506	1520	1523	1537	1540	1554	1557	1571
	1574	1588	1591	1605	1608	1622	1625	1639	1642	1656	1659	1673	1676	1690	1693
	1707	1710	1724	1727	1741	1744	1758	1761	1775	1778	1792	1795	1809	1812	1826
	1829	1843	1846	1860	1863	1877	1880	1894	1897	1911	1914	1928	1931	1945	1948
	1962	1965	1979	1982	1996	1999	2013	2016	2030	2033	2047	2050	2064	2067	2081
	2084	2098	2101	2115	2118	2132	2135	2149	2152	2166	2169	2183	2186	2200	2203
	2217	2220	2234	2237	2251	2254	2268	2271	2285	2288	2302	2305	2319	2322	2336
	2339	2353	2356	2370	2373	2387	2390	2404	2407	2421	2424	2438	2441	2455	2458
	2472	2475	2489	2492	2506	2509	2523	2526	2540	2543	2557	2560	2574	2577	2591
	2594	2608	2611	2625	2628	2642	2645	2659	2662	2676	2679	2693	2696	2710	2713
	2727	2730	2744	2747	2764	2767	2781	2784	2798	2801	2815	2818	2832	2835	2849
	2852	2866	2869	2883	2886	2900	2903	2917	2920	2938	2947	2957			
BIT	193	196													
BPL	185	2951	2954												
BR	189	2940													
CLR	192	2949													
CMP	181	212	229	246	264	281	298	315	332	349	366	383	400	417	434
	451	468	485	502	519	536	553	570	587	604	621	638	655	672	689
	706	723	740	757	774	791	808	825	842	859	876	893	910	927	944
	961	978	995	1012	1029	1046	1063	1080	1097	1114	1131	1148	1165	1182	1199
	1216	1233	1250	1267	1284	1301	1318	1335	1352	1369	1386	1403	1420	1437	1454
	1471	1488	1505	1522	1539	1556	1573	1590	1607	1624	1641	1658	1675	1692	1709
	1726	1743	1760	1777	1794	1811	1828	1845	1862	1879	1896	1913	1930	1947	1964
	1981	1998	2015	2032	2049	2066	2083	2100	2117	2134	2151	2168	2185	2202	2219
	2236	2253	2270	2287	2304	2321	2338	2355	2372	2389	2406	2423	2440	2457	2474
	2491	2508	2525	2542	2559	2576	2593	2610	2627	2644	2661	2678	2695	2712	2729
	2746	2766	2783	2800	2817	2834	2851	2868	2885	2902	2919	2937	2946		
CMPB	209	226	243	261	278	295	312	329	346	363	380	397	414	431	448
	465	482	499	516	533	550	567	584	601	618	635	652	669	686	703
	720	737	754	771	788	805	822	839	856	873	890	907	924	941	958
	975	992	1009	1026	1043	1060	1077	1094	1111	1128	1145	1162	1179	1196	1213
	1230	1247	1264	1281	1298	1315	1332	1349	1366	1383	1400	1417	1434	1451	1468
	1485	1502	1519	1536	1553	1570	1587	1604	1621	1638	1655	1672	1689	1706	1723
	1740	1757	1774	1791	1808	1825	1842	1859	1876	1893	1910	1927	1944	1961	1978
	1995	2012	2029	2046	2063	2080	2097	2114	2131	2148	2165	2182	2199	2216	2233

	2250	2267	2284	2301	2318	2335	2352	2369	2386	2403	2420	2437	2454	2471	2488
	2505	2522	2539	2556	2573	2590	2607	2624	2641	2658	2675	2692	2709	2726	2743
	2763	2780	2797	2814	2831	2848	2865	2882	2899	2916					
HALT	162	167	171												
INC	2944														
JMP	178	2948	2963												
JSR	2959														
MOV	183	191	195	206	208	223	225	240	242	258	260	275	277	292	294
	309	311	326	328	343	345	360	362	377	379	394	396	411	413	428
	430	445	447	462	464	479	481	496	498	513	515	530	532	547	549
	564	566	581	583	598	600	615	617	632	634	649	651	666	668	683
	685	700	702	717	719	734	736	751	753	768	770	785	787	802	804
	819	821	836	838	853	855	870	872	887	889	904	906	921	923	938
	940	955	957	972	974	989	991	1006	1008	1023	1025	1040	1042	1057	1059
	1074	1076	1091	1093	1108	1110	1125	1127	1142	1144	1159	1161	1176	1178	1193
	1195	1210	1212	1227	1229	1244	1246	1261	1263	1278	1280	1295	1297	1312	1314
	1329	1331	1346	1348	1363	1365	1380	1382	1397	1399	1414	1416	1431	1433	1448
	1450	1465	1467	1482	1484	1499	1501	1516	1518	1533	1535	1550	1552	1567	1569
	1584	1586	1601	1603	1618	1620	1635	1637	1652	1654	1669	1671	1686	1688	1703
	1705	1720	1722	1737	1739	1754	1756	1771	1773	1788	1790	1805	1807	1822	1824
	1839	1841	1856	1858	1873	1875	1890	1892	1907	1909	1924	1926	1941	1943	1958
	1960	1975	1977	1992	1994	2009	2011	2026	2028	2043	2045	2060	2062	2077	2079
	2094	2096	2111	2113	2128	2130	2145	2147	2162	2164	2179	2181	2196	2198	2213
	2215	2230	2232	2247	2249	2264	2266	2281	2283	2298	2300	2315	2317	2332	2334
	2349	2351	2366	2368	2383	2385	2400	2402	2417	2419	2434	2436	2451	2453	2468
	2470	2485	2487	2502	2504	2519	2521	2536	2538	2553	2555	2570	2572	2587	2589
	2604	2606	2621	2623	2638	2640	2655	2657	2672	2674	2689	2691	2706	2708	2723
	2725	2740	2742	2752	2753	2754	2760	2762	2777	2779	2794	2796	2811	2813	2828
	2830	2845	2847	2862	2864	2879	2881	2896	2898	2913	2915	2934	2935	2945	2956
MOV8	188	198	2952	2955											
NOP	2960	2961	2962												
RESET	2958														
TSTB	184	186	2950	2953											
.ASCIZ	2970														
.ENABL	1	158													
.END	2977														
.IIF	201	218	235	253	270	287	304	321	338	355	372	389	406	423	440
	457	474	491	508	525	542	559	576	593	610	627	644	661	678	695
	712	729	746	763	780	797	814	831	848	865	882	899	916	933	950
	967	984	1001	1018	1035	1052	1069	1086	1103	1120	1137	1154	1171	1188	1205
	1222	1239	1256	1273	1290	1307	1324	1341	1358	1375	1392	1409	1426	1443	1460
	1477	1494	1511	1528	1545	1562	1579	1596	1613	1630	1647	1664	1681	1698	1715
	1732	1749	1766	1783	1800	1817	1834	1851	1868	1885	1902	1919	1936	1953	1970
	1987	2004	2021	2038	2055	2072	2089	2106	2123	2140	2157	2174	2191	2208	2225
	2242	2259	2276	2293	2310	2327	2344	2361	2378	2395	2412	2429	2446	2463	2480
	2497	2514	2531	2548	2565	2582	2599	2616	2633	2650	2667	2684	2701	2718	2735
	2755	2772	2789	2806	2823	2840	2857	2874	2891	2908	2925				
.LIST	1	154	171	218	235	252	253	270	287	304	321	338	355	372	389
	406	423	440	457	474	491	508	525	542	559	576	593	610	627	644
	661	678	695	712	729	746	763	780	797	814	831	848	865	882	899
	916	933	950	967	984	1001	1018	1035	1052	1069	1086	1103	1120	1137	1154
	1171	1188	1205	1222	1239	1256	1273	1290	1307	1324	1341	1358	1375	1392	1409
	1426	1443	1460	1477	1494	1511	1528	1545	1562	1579	1596	1613	1630	1647	1664
	1681	1698	1715	1732	1749	1766	1783	1800	1817	1834	1851	1868	1885	1902	1919
	1936	1953	1970	1987	2004	2021	2038	2055	2072	2089	2106	2123	2140	2157	2174
	2191	2208	2225	2242	2259	2276	2293	2310	2327	2344	2361	2378	2395	2412	2429

	2446	2463	2480	2497	2514	2531	2548	2565	2582	2599	2616	2633	2650	2667	2684
.MACR	2701	2718	2735	2752	2772	2789	2806	2823	2840	2857	2874	2891	2908	2925	
.MACRO	171	172													
.NLIST	1	154	171	218	235	252	253	270	287	304	321	338	355	372	389
	406	423	440	457	474	491	508	525	542	559	576	593	610	627	644
	661	678	695	712	729	746	763	780	797	814	831	848	865	882	899
	916	933	950	967	984	1001	1018	1035	1052	1069	1086	1103	1120	1137	1154
	1171	1188	1205	1222	1239	1256	1273	1290	1307	1324	1341	1358	1375	1392	1409
	1426	1443	1460	1477	1494	1511	1528	1545	1562	1579	1596	1613	1630	1647	1664
	1681	1698	1715	1732	1749	1766	1783	1800	1817	1834	1851	1868	1885	1902	1919
	1936	1953	1970	1987	2004	2021	2038	2055	2072	2089	2106	2123	2140	2157	2174
	2191	2208	2225	2242	2259	2276	2293	2310	2327	2344	2361	2378	2395	2412	2429
	2446	2463	2480	2497	2514	2531	2548	2565	2582	2599	2616	2633	2650	2667	2684
.PAGE	2701	2718	2735	2752	2772	2789	2806	2823	2840	2857	2874	2891	2908	2925	
	201	253	304	355	406	457	508	559	610	661	712	763	814	865	916
	967	1018	1069	1120	1171	1222	1273	1324	1375	1426	1477	1528	1579	1630	1681
	1732	1783	1834	1885	1936	1987	2038	2089	2140	2191	2242	2293	2344	2395	2446
	2497	2548	2599	2650	2701	2755	2806	2857	2908						
.REN	1														
.REPT	171	253	508	882	1256	1630	2004	2378							
.TITLE	154														
.WORD	2941	2942													

ERRORS DETECTED: 0
 DEFAULT GLOBALS GENERATED: 0

*.DCKBIB.SEG/SOL/CRF/PAGNUM/NL:TOC=SYSMAC.CO,DCKBIB.SRC
 RUN-TIME: 31 40 3 SECONDS
 RUN-TIME RATIO: 137/75=1.8
 CORE USED: 33K (65 PAGES)

