

KT11-C

BASIC LOGIC TEST 2
MD-11-DCKTB-B

EP-DCKTB-B-DL-A
COPYRIGHT © 1976
FICHE 1 OF 1

NOV 1976
digital
MADE IN U.S.

The microfiche card contains a grid of 40 frames of technical data, arranged in 10 rows and 4 columns. Each frame contains a different set of data, likely representing a single test case or a specific component's behavior. The data is presented in a structured, tabular format, with some frames including waveforms or timing diagrams. The frames are separated by thin lines, and the overall layout is consistent across the card.

BO1

DCKTB-B MACY11 27:732) 01-OCT-76 13:14 PAGE 2
DCKTBB.P11

.REM *

IDENTIFICATION

PRODUCT CODE: MAINDEC-11-DCKTB-B
PRODUCT NAME: KT11-C BASIC LOGIC TEST TWO
DATE CREATED: 15 APRIL 1972
MAINTAINER. DIAGNOSTIC GROUP
AUTHOR: RICK FADDEN

1.0 ABSTRACT

THIS PROGRAM AND THE PREVIOUS ONE (DCKTA) INCREMENTALLY TEST THE BASIC LOGIC FUNCTIONS OF THE KT11-C MEMORY MANAGEMENT OPTION FOR THE PDP-11/45. THEY FULLY TEST RELOCATION, DIRECT AND INDIRECT ADDRESSING OF THE MEMORY MANAGEMENT REGISTERS, AND CORRECT OPERATION OF ALL THE BITS IN THE REGISTERS. THE VARIOUS ABORTS ARE TESTED, AS IS PROPER "LOCKING" AND "UNLOCKING" OF THE ERROR TRACKING LOGIC.

2.0 REQUIREMENTS

2.1 EQUIPMENT

PDP-11/45 WITH KT11-C OPTION

2.2 STORAGE

THE PROGRAM REQUIRES MEMORY LOCATIONS 0 TO 17474.

3.0 LOADING PROCEDURE

LOAD PROGRAM INTO MEMORY USING ABS LOADER.

4.0 STARTING PROCEDURE

LOAD ADDRESS 200.

SET DESIRED SWITCH REGISTER SETTINGS (ALL DOWN FOR WORST CASE).
PRESS START.

THE PROGRAM WILL DISPLAY THE NUMBER OF THE CURRENT SUBTEST IN THE DISPLAY REGISTER, AND WILL RING THE BELL ON COMPLETION OF A PASS.

5.0 OPERATING PROCEDURE

5.1 OPERATIONAL SWITCH SETTINGS

SW 15=1 OR UP -- HALT ON ERROR
 SW 14=1 OR UP -- SCOPE LOOP
 SW 13=1 OR UP -- INHIBIT PRINTOUT
 SW 11=1 OR UP -- INHIBIT ITERATIONS
 SW 08=1 OR UP -- LOAD MICROBREAK REGISTER WITH VALUE IN
 SW 00-07.

5.2 SUBROUTINE ABSTRACTS

5.2.1 SCOPE

THIS SUBROUTINE CALL IS PLACED BETWEEN EACH SUBTEST. IT RECORDS THE STARTING ADDRESS OF EACH SUBTEST AS IT IS BEING ENTERED. IF A SCOPE LOOP IS REQUESTED, IT WILL JUMP TO THE START OF THE SUBTEST THAT THE SCOPE LOOP IS REQUESTED FOR. IF SCOPE LOOP IS NOT REQUESTED, THERE WILL BE 1024 ITERATIONS ON THAT SUBTEST BEFORE THE NEXT SUBTEST IS ENTERED. SWITCH 11 ON A 1 INHIBITS ITERATION OF SUBTESTS.

5.2.2 HLT

THIS ENT CALLS THE SUBROUTINE PRINT, WHICH PRINTS OUT THE LOCATION COUNTER AT THE TIME OF FAILURE AND THE CONTENTS OF THE PROCESSOR STATUS REGISTER. NOTE THAT THE LOCATION COUNTER WILL BE THE ADDRESS OF THE HLT PLUS TWO.

5.2.3 TRAPCATCHER

THIS IS A SERIES OF INSTRUCTIONS STARTING AT LOCATION 0 DESIGNED TO DETECT AND ISOLATE UNEXPECTED TRAPS AND INTERRUPTS TO THE TRAP AND INTERRUPT VECTOR AREA OF MEMORY.

EACH VECTOR ENTRANCE ADDRESS IS LOADED WITH THE ADDRESS OF THE NEXT LOCATION. THE NEXT LOCATION IS LOADED WITH A HALT (000000). THUS AN ILLEGAL TRAP OR INTERRUPT WILL CAUSE A HALT AT THE TRAP LOCATION PLUS TWO.

IF A HALT OCCURS IN THE TRAP OR INTERRUPT AREA EXAMINE REGISTER SIX. IT WILL CONTAIN THE CURRENT STACK ADDRESS. THE CONTENTS OF THE CURRENT STACK ADDRESS IS THE VALUE OF THE LOCATION COUNTER WHEN THE TRAP OR INTERRUPT OCCURRED.

5.2.4 EMTSRV (EMT DECODER)

THIS ROUTINE DECODES ALL EMT CALLS, INCLUDING PATCHES AND THE HLT CALL WHICH PASSES CONTROL TO THE PRINT ROUTINE.

5.2.5 CLRALL

THIS ROUTINE CLEARS ALL THE PAR'S AND PDR'S OF THE KT11-C, AS WELL AS SRD.

5.2.6 RWALL

THIS ROUTINE MAPS ALL PAGES TO BANK 0 BY CLEARING ALL THE PAR'S. ALL PAGES ARE MADE 4K READ-WRITE BY LOADING ALL THE PDR'S WITH THE VALUE 77406.

5.2.7 RWISP

THIS ROUTINE MAPS ALL I-SPACE PAGES RW, 4K, BANK 0.

5.2.8 RWOSP

THIS ROUTINE MAPS ALL D-SPACE PAGES RW, 4K, BANK 0.

5.3 PROGRAM AND/OR OPERATOR ACTION

THIS TEST CONTINUES THE SERIES OF TESTS OF THE KT11-C OPTION STARTED IN MAINDEC-11-DCKTA. NO OPERATOR INTERVENTION IS REQUIRED. THE BELL IS RUNG AT THE END OF EACH PASS, AND THE CURRENT SUBTEST NUMBER IS DISPLAYED IN THE DISPLAY REGISTER.

6.0 ERRORS

6.1 ERROR PRINTOUT

PRINTOUTS ARE IN A STANDARD TWO-WORD FORMAT. THE FIRST WORD IS THE OCTAL VALUE OF THE PC+2 OF THE DETECTED ERROR. THE SECOND IS THE CONTENTS OF THE PROCESSOR STATUS REGISTER WHEN THE ERROR WAS DETECTED.

6.2 ERROR RECOVERY

IN GENERAL, TEST FAILURES WILL PRINTOUT AN ERROR MESSAGE AND CONTINUE. IF THE "HALT ON ERROR" SWITCH IS SET, HITTING CONTINUE WILL RECOVER. IF THE PROGRAM HANGS UP IN A LOOP, THE ERROR IS LIKELY TO BE A SIGNAL WHICH WAS NEVER RECEIVED. IF A HALT OCCURS IN THE TRAP AND VECTOR AREA THE PROGRAM MUST BE RESTARTED. IF THE PROGRAM HALTS IN THE MAIN FLOW, CONSULT THE LISTING IF NO MESSAGE IS TYPED OUT.

6.3 BRANCH SELF

A BRANCH TO SELF IS USED IN THE KT11-C DIAGNOSTICS TO INDICATE A FAILURE WHEN A HALT OR A HLT TRAP CALL COULD CAUSE A PROBLEM.

7.0 RESTRICTIONS

PROGRAM MUST BE LOADED INTO LOWER 4K OF MEMORY.

8.0 MISCELLANEOUS

8.1 EXECUTION TIME

EACH PASS TAKES APPROXIMATELY 1 MINUTE WITH CORE MEMORY.

8.2 STACK POINTERS

THE KERNEL STACK POINTER IS USUALLY INITIALIZED TO 1000. HOWEVER, IN CERTAIN TESTS IT MAY BE INITIALIZED TO A LOWER ADDRESS (VIRTUAL) TO MAKE UP FOR RELOCATION OF THE BANK.

THE SUPERVISOR STACK POINTER IS INITIALIZED TO 2000.

THE USER STACK POINTER IS INITIALIZED TO 3000.

8.3 DISPLAY REGISTER

THE NUMBER OF THE CURRENT SUBTEST IS DISPLAYED.

8.4 EXECUTION ORDER CHECKING

SINCE THE KT11-C MAY CAUSE AN INCORRECT FETCH IF IT IS NOT WORKING CORRECTLY, THE ORDER OF EXECUTION OF ALL SUBTESTS IS CHECKED. THE SCOPE ROUTINE, WHEN IT CHANGES FROM ONE SUBTEST TO THE NEXT, INCREMENTS A COUNTER CALLED TESTCT. AT THE START OF EACH SUBTEST, THIS COUNTER IS CHECKED FOR THE CORRECT VALUE FOR THAT SUBTEST. IF TESTS ARE NOT EXECUTED IN THE CORRECT ORDER, TESTCT WILL NOT CONTAIN THE EXPECTED VALUE, AND AN ERROR PRINTOUT WILL OCCUR.

9.0 PROGRAM DESCRIPTION

THIS PROGRAM COMPLETES THE SERIES OF TESTS OF THE KT11-C OPTION STARTED IN MAINDEC-11-DCKTA (BASIC LOGIC TEST ONE). THE BELL IS RUNG AT THE END OF EACH PASS, AND THE CURRENT SUBTEST NUMBER IS DISPLAYED IN THE DISPLAY REGISTER.

*

;SECOND BASIC LOGIC TEST OF KT11-C
 ;COPYRIGHT 1972, DIGITAL EQUIPMENT CORP., MAYNARD, MASS. 01754

;OPERATING INSTRUCTIONS
 : 1. LOAD TEST USING THE ABSOLUTE LOADER
 : 2. LOAD SA 200
 : 3. SET SR TO INITIAL SETTINGS
 : 4. PRESS START

;SWITCH REGISTER SETTINGS ARE:
 : SW15=1 CAUSES HALT ON ERROR
 : SW14=1 CAUSES SCOPE LOOPING
 : SW13=1 INHIBITS ERROR PRINTOUT
 : SW11=1 INHIBITS ITERATIONS
 : SW08=1 LOAD MICROBREAK REGISTER WITH LOW BYTE OF SWITCH REGISTER

;DEFINITIONS
 SCOPE=TRAP
 NOP=240
 R0=%0
 R1=%1
 R2=%2
 R3=%3
 R4=%4
 R5=%5
 R6=%6
 R7=%7
 SP=%6
 PC=%7
 SR=177570
 PS=177776

104400
 000240
 000000
 000001
 000002
 000003
 000004
 000005
 000006
 000007
 000006
 000007
 177570
 177776

;LOAD TRAP CATCHER INTO 0 THRU 777
 ;LOAD EACH VECTOR ADDRESS WITH THE ADDRESS OF THE NEXT
 ;LOCATION, AND LOAD EACH LOCATION IMMEDIATELY FOLLOWING
 ;A VECTOR ADDRESS WITH A HALT INSTRUCTION
 ;CODE NOT LISTED TO MAKE LISTING EASIER TO READ

;LOAD VECTOR AREA
 .=30
 EMTSRV
 340
 .=34
 SCOPEC
 0
 .=46
 LOGIC
 .=52
 40000

000030 000030
 000032 015614
 000032 000340
 000034 000034
 000034 015056
 000036 000000
 000036 000046
 000046 014500
 000052 000052
 000052 040000

;LOAD STARTING AREA
 .=200
 JMP START

000200 000200 003216
 000167

;LOAD DATA AREA
 .=1000

001000

001000	000000	KSTACK: 0	;KERNEL STACK BUFFER AREA
	002000	. = +776	
002000	000000	SSTACK: 0	;SUPERVISOR STACK BUFFER AREA
	003000	. = +776	
003000	000000	USTACK: 0	;USER STACK BUFFER AREA
003002	000000	.WORD 0,0,0,0	
003010	000000		
003012	000200	K200: 200	;CONSTANTS
003014	001000	K1000: 1000	
003016	177564	TCSR: 177564	;TELEPRINTER REGISTERS
003020	177566	TDBR: 177566	
003022	000000	TEMP: 0	;TEMPORARY STORAGE LOCATIONS
003024	000000	TEMPX: 0	
003026	000000	TEMP1: 0	
003030	000000	TEMP2: 0	
003032	177572	SR0: 177572	;KT11-C STATUS REGISTER ADDRESSES
003034	177573	SR0H: 177573	
003036	177574	SR1: 177574	
003040	177575	SR1H: 177575	
003042	177576	SR2: 177576	
003044	177577	SR2H: 177577	
003046	172516	SR3: 172516	
003050	172517	SR3H: 172517	
003052		ADRTAB:	
003052	177600	UIPDR0: 177600	;USER I-SPACE PAGE DESCRIPTOR REGISTER ADDRESSES
003054	177602	UIPDR1: 177602	
003056	177604	UIPDR2: 177604	
003060	177606	UIPDR3: 177606	
003062	177610	UIPDR4: 177610	
003064	177612	UIPDR5: 177612	
003066	177614	UIPDR6: 177614	
003070	177616	UIPDR7: 177616	
003072	177620	UDPDR0: 177620	;USER D-SPACE PAGE DESCRIPTOR REGISTER ADDRESSES
003074	177622	UDPDR1: 177622	
003076	177624	UDPDR2: 177624	
003100	177626	UDPDR3: 177626	
003102	177630	UDPDR4: 177630	
003104	177632	UDPDR5: 177632	
003106	177634	UDPDR6: 177634	
003110	177636	UDPDR7: 177636	
003112	177640	UIPAR0: 177640	;USER I-SPACE PAGE ADDRESS REGISTER ADDRESSES
003114	177642	UIPAR1: 177642	
003116	177644	UIPAR2: 177644	
003120	177646	UIPAR3: 177646	
003122	177650	UIPAR4: 177650	
003124	177652	UIPAR5: 177652	
003126	177654	UIPAR6: 177654	
003130	177656	UIPAR7: 177656	
003132	177660	UDPAR0: 177660	;USER D-SPACE PAGE ADDRESS REGISTER ADDRESSES
003134	177662	UDPAR1: 177662	
003136	177664	UDPAR2: 177664	
003140	177666	UDPAR3: 177666	
003142	177670	UDPAR4: 177670	
003144	177672	UDPAR5: 177672	
003146	177674	UDPAR6: 177674	

003150	177676	UDPAR7:	177676	
003152	172200	SIPDR0:	172200	;SUPERVISOR I-SPACE PAGE DESCRIPTOR REGISTER ADDRESSES
003154	172202	SIPDR1:	172202	
003156	172204	SIPDR2:	172204	
003160	172206	SIPDR3:	172206	
003162	172210	SIPDR4:	172210	
003164	172212	SIPDR5:	172212	
003166	172214	SIPDR6:	172214	
003170	172216	SIPDR7:	172216	
003172	172220	SDPDR0:	172220	;SUPERVISOR D-SPACE PAGE DESCRIPTOR REGISTER ADDRESSES
003174	172222	SDPDR1:	172222	
003176	172224	SDPDR2:	172224	
003200	172226	SDPDR3:	172226	
003202	172230	SDPDR4:	172230	
003204	172232	SDPDR5:	172232	
003206	172234	SDPDR6:	172234	
003210	172236	SDPDR7:	172236	
003212	172240	SIPAR0:	172240	;SUPERVISOR I-SPACE PAGE ADDRESS REGISTER ADDRESSES
003214	172242	SIPAR1:	172242	
003216	172244	SIPAR2:	172244	
003220	172246	SIPAR3:	172246	
003222	172250	SIPAR4:	172250	
003224	172252	SIPAR5:	172252	
003226	172254	SIPAR6:	172254	
003230	172256	SIPAR7:	172256	
003232	172260	SDPAR0:	172260	;SUPERVISOR D-SPACE PAGE ADDRESS REGISTER ADDRESSES
003234	172262	SDPAR1:	172262	
003236	172264	SDPAR2:	172264	
003240	172266	SDPAR3:	172266	
003242	172270	SDPAR4:	172270	
003244	172272	SDPAR5:	172272	
003246	172274	SDPAR6:	172274	
003250	172276	SDPAR7:	172276	
003252	172300	KIPDR0:	172300	;KERNEL I-SPACE PAGE DESCRIPTOR REGISTER ADDRESSES
003254	172302	KIPDR1:	172302	
003256	172304	KIPDR2:	172304	
003260	172306	KIPDR3:	172306	
003262	172310	KIPDR4:	172310	
003264	172312	KIPDR5:	172312	
003266	172314	KIPDR6:	172314	
003270	172316	KIPDR7:	172316	
003272	172320	KDPDR0:	172320	;KERNEL D-SPACE PAGE DESCRIPTOR REGISTER ADDRESSES
003274	172322	KDPDR1:	172322	
003276	172324	KDPDR2:	172324	
003300	172326	KDPDR3:	172326	
003302	172330	KDPDR4:	172330	
003304	172332	KDPDR5:	172332	
003306	172334	KDPDR6:	172334	
003310	172336	KDPDR7:	172336	
003312	172340	KIPAR0:	172340	;KERNEL I-SPACE PAGE ADDRESS REGISTER ADDRESSES
003314	172342	KIPAR1:	172342	
003316	172344	KIPAR2:	172344	
003320	172346	KIPAR3:	172346	
003322	172350	KIPAR4:	172350	

K01

003324	172352	KIPAR5:	172352	
003326	172354	KIPAR6:	172354	
003330	172356	KIPAR7:	172356	
003332	172360	KDPAR0:	172360	;KERNEL D-SPACE PAGE ADDRESS REGISTER ADDRESSES
003334	172362	KDPAR1:	172362	
003336	172364	KDPAR2:	172364	
003340	172366	KDPAR3:	172366	
003342	172370	KDPAR4:	172370	
003344	172372	KDPAR5:	172372	
003346	172374	KDPAR6:	172374	
003350	172376	KDPAR7:	172376	
	003350	ADREND=	.-2	

003352	177600	PDRTAB:	177600	;STARTING ADDRESSES OF PDR'S FOR EACH MODE
003354	172200		172200	
003356	172300		172300	
003360	177640	PARTAB:	177640	;STARTING ADDRESSES OF PAR'S FOR EACH MODE
003362	172240		172240	
003364	172340		172340	

003366	003252	STATAB:	KIPDR0	;ADDRESS OF KERNEL TABLE OF PDR'S AND PAR'S
003370	000000		0	
003372	003152		SIPDR0	;ADDRESS OF SUPERVISOR TABLE OF PDR'S AND PAR'S
003374	040000		40000	
003376	003052		UIPDR0	;ADDRESS OF USER TABLE OF PDR'S AND PAR'S
003400	140000	STAEND:	140000	

003402	000000	STAPNT:	0	
003404	000000	SAVEA:	0	
003406	000000	SAVEB:	0	
003410	000250	KTVEC:	250	;KT11-C TRAP AND ABORT VECTOR ADDRESS
003412	000252	KTSTA:	252	
003414	177770	UBRK:	177770	;MICROBREAK REGISTER ADDRESS
003416	177770	MSKB:	177770	
003420	000000	TESTCT:	0	;INDICATES NUMBER OF CURRENT TEST

;SET UP FOR START OF BASIC LOGIC TESTS				
003422	005037	177776	START: CLR	#PS ;INITIALIZE STATUS
003426	012706	001000	MOV	#KSTACK, SP ;SETUP KERNEL STACK
003432	012737	040000	MOV	#40000, #PS ;INITIALIZE SUPERVISOR STACK
003440	012706	002000	MOV	#SSTACK, SP
003444	012737	140000	MOV	#140000, #PS ;INITIALIZE USER STACK
003452	012706	003000	MOV	#USTACK, SP
003456	005037	177776	CLR	#PS
003462	012767	002000	MOV	#2000, ICOUNT ;INITIALIZE ITERATION COUNT
003470	012767	003510	MOV	#TEST1+2, RETURN ;SETUP SCOPE AND ITERATION LOOP RETURN
003476	012767	000001	MOV	#1, TESTCT ;INITIALIZE TEST COUNTER
003504	000401		BR	+.4 ;SKIP SCOPE INSTRUCTION

;SHOW THAT INIT CLEARS SR0<9,11-15>				
003506	104400		TEST1: SCOPE	
003510	012737	000001	MOV	#1, #SR ;DISPLAY TEST NUMBER
003516	005037	177776	CLR	#PS ;INITIALIZE PROCESSOR STATUS
003522	012706	001000	MOV	#KSTACK, SP ;INITIALIZE KERNEL STACK POINTER
003526	005077	177314	CLR	#SR3 ;INITIALIZE SR3

```

003532 005077 177274          CLR      @SR0          ;INITIALIZE SR0
003536 026727 177656 000001  CMP      TESTCT,#1    ;IS THIS TEST BEING EXECUTED IN THE
003544 001401          BEQ      .+4          ;CORRECT SEQUENCE? - BRANCH IF YES
003546 104006          HLT                      ;TEST EXECUTED OUT OF ORDER - TESTCT
                                ;CONTAINS NUMBER OF PREVIOUS TEST PLUS ONE

003550 112777 000372 177256  MOV      #372,@SR0H   ;SET SR0 BITS 9,11-15
003556 122777 000372 177250  CMPB     #372,@SR0H   ;MAKE SURE THEY SET CORRECTLY
003564 001401          BEQ      .+4          ;
003566 104006          HLT                      ;SR0 INCORRECT (HIGH BYTE)
003570 105777 177222          TSTB     @TCSR        ;WAIT FOR TTY READY
003574 100375          BPL      .-4          ;
003576 000005          RESET                   ;ISSUE INIT
003600 122777 000000 177226  CMPB     #0,@SR0H     ;CHECK SR0 HIGH BYTE
003606 001401          BEQ      .+4          ;
003610 104006          HLT                      ;SR0 INCORRECT AFTER INIT
003612 012767 000010 011364  MOV      #10,ICOUNT   ;DROP ITERATION COUNT

```

```

;SHOW THAT IF AN INSTRUCTION IS COMPLETED BEFORE A MEMORY MANAGEMENT FAULT
;OCCURS, BIT 7 OF SR0 WILL BE SET ("INSTRUCTION COMPLETE") AND SR2 WILL
;CONTAIN THE ADDRESS OF THE VECTOR REFERENCE THAT ABORTED
;TO TEST THIS, TRACE TRAP IS USED. THE VECTOR IS MADE NON-RESIDENT BY MAKING
;KERNEL PAGE 0 READ/WRITE, MAPPED DOWN FROM 17776 TO 100. THUS THE MEMORY MANAGEMENT
;VECTOR IS RESIDENT WHILE THE TRACE TRAP VECTOR IS OUTSIDE THE ALLOWED
;PAGE LENGTH. ALL D-SPACES ARE ENABLED.

```

```

003620 104400          TEST2: SCOPE
003622 012737 000002 177570  MOV      #2,@SR       ;DISPLAY TEST NUMBER
003630 005037 177776          CLR      @PS          ;INITIALIZE PROCESSOR STATUS
003634 012706 001000          MOV      #KSTACK,SP   ;INITIALIZE KERNEL STACK POINTER
003640 005077 177202          CLR      @SR3        ;INITIALIZE SR3
003644 005077 177162          CLR      @SR0        ;INITIALIZE SR0
003650 026727 177544 000002  CMP      TESTCT,#2    ;IS THIS TEST BEING EXECUTED IN THE
003656 001401          BEQ      .+4          ;CORRECT SEQUENCE? - BRANCH IF YES
003660 104006          HLT                      ;TEST EXECUTED OUT OF ORDER - TESTCT
                                ;CONTAINS NUMBER OF PREVIOUS TEST PLUS ONE

003662 004767 010656          JSR      %7,RWALL     ;INITIALIZE ALL PAGES RW,4K,BANK 0
003666 012777 000416 177376  MOV      #416,@KDPDR0 ;MAP KERNEL D-SPACE PAGE 0 TO EXCLUDE
                                ;LOCATIONS 0 TO 77
003674 012777 007600 177446  MOV      #7600,@KDPAR7 ;MAP KERNEL D-SPACE PAGE 7 TO THE
                                ;EXTERNAL BANK
003702 012777 000007 177136  MOV      #7,@SR3      ;ENABLE D-SPACES
003710 012777 003756 177472  MOV      #RET2,@KTVEC ;SETUP MEMORY MANAGEMENT ABORT RETURN
003716 005077 177470          CLR      @KTSTA
003722 012746 000020          MOV      #20,-(SP)    ;PREPARE STACK TO TURN ON T-BIT
003726 012746 003734          MOV      #.+6,-(SP)
003732 000006          RTT
003734 012777 000001 177070  MOV      #1,@SR0
                                ;SET T-BIT VIA RTT
                                ;TURN ON KT11-C - SHOULD
                                ;ATTEMPT TO TRACE TRAP AT END OF
                                ;INSTRUCTION - SHOULD GET A PAGE
                                ;LENGTH ERROR ON THAT ATTEMPT
                                ;NO PAGE LENGTH ERROR ON TRACE TRAP
                                ;SETUP TO CLEAR T-BIT

003742 000000          HALT
003744 005046          CLR      -(SP)
003746 012746 003754          MOV      #.+6,-(SP)
003752 000006          RTT
003754 000422          BR      CONT2
                                ;CLEAR T-BIT

```


MO1

DCKTB-B MACY11 27(732) 01-OCT-76 13:14 PAGE 13
 DCKTB8.P11

```

003756 042777 000001 177046 RET2: BIC #1,@SR0 ;TURN OFF KT11-C
003764 022777 040220 177040 CMP #40220,@SR0 ;CK SRO
003772 001401 BEQ .+4
003774 104006 HLT ;SRO INCORRECT - SHOULD SHOW PL FAULT
;KERNEL 0 D-SPACE REFERENCE
;AND INSTRUCTION WAS COMPLETED

003776 022777 000000 177032 CMP #0,@SR1
004004 001401 BEQ .+4 ;CK SRI
004006 104006 HLT ;SRI INCORRECT - INSTRUCTION WAS COMPLETED
;SO SRI SHOULD CONTAIN ZERO

004010 022777 000014 177024 CMP #14,@SR2
004016 001401 BEQ .+4 ;CK SR2
004020 104006 HLT ;SR2 INCORRECT - SHOULD CONTAIN
;ADDRESS OF TRACE TRAP VECTOR WHICH ABORTED

004022 005077 177004 CONT2: CLR @SR0 ;REINITIALIZE SRO
004026 016777 177360 177354 MOV KTSTA,@KTVEC ;RESTORE TRAP CATCHER
004034 005077 177006 CLR @SR3 ;DISABLE D-SPACE

;SHOW THAT INIT CLEARS SRO (<?) (INSTRUCTION COMPLETE)
004040 104400 TEST3: SCOPE
004042 012737 000003 177570 MOV #3,@#SR ;DISPLAY TEST NUMBER
004050 005037 177776 CLR @#PS ;INITIALIZE PROCESSOR STATUS
004054 012706 001000 MOV #KSTACK,SP ;INITIALIZE KERNEL STACK POINTER
004060 005077 176762 CLR @SR3 ;INITIALIZE SR3
004064 005077 176742 CLR @SR0 ;INITIALIZE SRO
004070 026727 177324 000003 CMP TESTCT,#3 ;IS THIS TEST BEING EXECUTED IN THE
004076 001401 BEQ .+4 ;CORRECT SEQUENCE? - BRANCH IF YES
004100 104006 HLT ;TEST EXECUTED OUT OF ORDER - TESTCT
;CONTAINS NUMBER OF PREVIOUS TEST PLUS ONE

004102 004767 010436 JSR %7,RWALL ;MAP ALL PAGES 4K,RW,BANK 0
004106 012777 000416 177136 MOV #416,@KIPDR0 ;MAP KERNEL 0 RW,4K LESS 1 PAGE
;DOWN (100-17776 RW)

004114 012777 007600 177206 MOV #7600,@KIPAR7 ;MAP KERNEL PAGE 7 TO THE EXTERNAL BANK
004122 012777 077403 177124 MOV #77403,@KIPDR1 ;MAP KERNEL PAGE 1 NR
004130 012777 004170 177252 MOV #RET3,@KTVEC ;SETUP ABORT RETURN
004136 005077 177230 CLR @KTSTA
004142 012746 000020 MOV #20,-(SP) ;SET T BIT IN STATUS ON STACK
004146 012746 004160 MOV #ADR3,-(SP) ;SETUP ADDRESS ON STACK
004152 005277 176654 INC @SR0 ;TURN ON KT11-C
004156 000002 RTI ;SHOULD TRACE TRAP IMMEDIATELY SINCE T-BIT
;IS SET - SINCE T-BIT VECTOR IS OUTSIDE ALLOWED
;PAGE LENGTH, SHOULD DO A MEMORY
;MANAGEMENT ABORT

```

```

004160 000000          ADR3:  HALT          ;NO PL ABORT OCCURRED
004162 005037 177776          CLR          @#PS          ;RESTORE STATUS
004166 000415          BR           DONE3
004170 022777 040201 176634 RET3:  CMP          @40201,@SRO  ;CHECK SRO
004176 001401          BEQ          .+4
004200 104006          HLT
                                     ;SRO INCORRECT - SHOULD SHOW
                                     ;REFERENCE TO KERNEL I-SPACE 0.
                                     ;INSTRUCTION COMPLETE SHOULD BE SET,
                                     ;AND PL ABORT SHOULD BE SET
                                     ;WAIT FOR ANY TTY OUTPUT TO FINISH

004202 105777 176610          TSTB         @TCSR
004206 100375          BPL          .-4
004210 000005          RESET
004212 005777 176614          TST         @SRO          ;ISSUE INIT - SHOULD CLEAR SRO
004216 001401          BEQ          .+4          ;CHECK SRO
004220 104006          HLT
00 222 005077 176604          DONE3:  CLR         @SRO          ;SRO INCORRECT AFTER INIT
004226 016777 177160 177154  MOV          KTSTA,@KTVEC ;REINITIALIZE SRO
004234 012737 000016 000014  MOV          @16,@14      ;RESTORE T-BIT TRAP CATCHER

;SHOW THAT INIT CLEARS SRO(0-6)
;REFERENCE NR USER PAGE 7 D-SPACE TO SET ALL BITS(0-6)
;THEN ISSUE INIT
TEST4:  SCOPE
004242 104400          MOV          #4,@#SR      ;DISPLAY TEST NUMBER
004244 012737 000004 177570  CLR          @#PS          ;INITIALIZE PROCESSOR STATUS
004252 005037 177776          MOV          @KSTACK,SP  ;INITIALIZE KERNEL STACK POINTER
004256 012706 001000          CLR          @SR3        ;INITIALIZE SR3
004262 005077 176560          CLR          @SRO        ;INITIALIZE SRO
004266 005077 176540          CMP          TESTCT,#4   ;IS THIS TEST BEING EXECUTED IN THE
004272 026727 177122 000004  BEQ          .+4          ;CORRECT SEQUENCE? - BRANCH IF YES
004300 001401          HLT                    ;TEST EXECUTED OUT OF ORDER - TESTCT
004302 104006          ;CONTAINS NUMBER OF PREVIOUS TEST PLUS ONE

004304 004767 010234          JSR          %7,RWALL     ;MAP ALL PAGES INITIALLY RW,4K,BANK 0
004310 012777 077407 176572  MOV          @77407,@UDPDR7 ;MAKE USER 7 D-SPACE NR
004316 012777 007600 177024  MOV          @7600,@KDPAR7 ;MAP KERNEL 7 D-SPACE TO THE
                                     ;EXTERNAL BANK
004324 012777 000007 176514  MOV          #7,@SR3     ;ENABLE ALL D-SPACES
004332 012777 004370 177050  MOV          @RET4,@KTVEC ;SETUP ABORT RETURN
004340 005077 177046          CLR          @KTSTA
004344 012737 140000 177776  MOV          @140000,@#PS ;SET MODE TO USER
004352 012706 003000          MOV          @KSTACK,R6 ;SETUP USER STACK IN CASE NEEDED
004356 005277 176450          INC          @SRO        ;TURN ON KT11-C
004362 005737 160000          TST         @#160000    ;REFERENCE NR PAGE 7
004366 000777          BR           .           ;NO ABORT ON NR REFERENCE TO USER D-SPACE
                                     ;PAGE 7
004370 022777 100177 176434 RET4:  CMP          @100177,@SRO ;CHECK SRO
004376 001401          BEQ          .+4
004400 104006          HLT
                                     ;SRO INCORRECT - SHOULD HAVE LOCKED
                                     ;ON NR REFERENCE TO USER 7 D-SPACE
                                     ;WAIT FOR ANY TTY OUTPUT TO FINISH

004402 105777 176410          TSTB         @TCSR
004406 100375          BPL          .-4
004410 000005          RESET
004412 005777 176414          TST         @SRO          ;ISSUE INIT
004416 001401          BEQ          .+4          ;CHECK SRO
004420 104006          HLT                    ;SRO INCORRECT AFTER INIT
    
```

```

004422 005077 176404          CLR      2SR0          ;REINITIALIZE SRO
004426 012767 000010 010550      MOV      #10,ICOUNT   ;DROP ITERATION COUNT
004434 016777 176752 176746      MOV      KTSTA,2KTVEC

;SHOW THAT BYTE ADDRESSING OF SRO WORKS
004442 104400          TESTS: SCOPE
004444 012737 000005 177570      MOV      #5,2#SR      ;DISPLAY TEST NUMBER
004452 005037 177776          CLR      2#PS         ;INITIALIZE PROCESSOR STATUS
004456 012706 001000          MOV      #KSTACK,SP  ;INITIALIZE KERNEL STACK POINTER
004462 005077 176360          CLR      2SR3        ;INITIALIZE SR3
004466 005077 176340          CLR      2SR0        ;INITIALIZE SRO
004472 026727 176722 000005      CMP      TESTCT,#5   ;IS THIS TEST BEING EXECUTED IN THE
004500 001401          BEQ     .+4          ;CORRECT SEQUENCE? - BRANCH IF YES
004502 104006          HLT                ;TEST EXECUTED OUT OF ORDER - TESTCT
;CONTAINS NUMBER OF PREVIOUS TEST PLUS ONE

004504 004767 010034          JSR      %7,RWALL    ;MAP ALL PAGES RW 4K, BANK 0
004510 012777 007600 176612      MOV      #7600,2KIPAR7 ;MAP KERNEL 7 TO THE EXTERNAL BANK
004516 012777 170001 176306      MOV      #170001,2SR0 ;TURN ON KT11-C AND SET ERROR FLAGS
004524 105077 176302          CLR      2SR0        ;DATOB (LOW) TO SRO
004530 022777 170000 176274      CMP      #170000,2SR0 ;CHECK SRO
004536 001401          BEQ     .+4
004540 104006          HLT                ;SRO INCORRECT AFTER CLR8 (LOW)
004542 012777 170001 176262      MOV      #170001,2SR0 ;DATOB (HIGH) TO SRO
004550 105077 176260          CLR      2SR0H       ;SAVE CONTENTS OF SRO
004554 017701 176252          MOV      2SR0,R1     ;TURN OFF KT11-C
004560 005077 176246          CLR      2SR0        ;CHECK SAVED CONTENTS OF SRO
004564 022701 000001          CMP      #1,R1
004570 001401          BEQ     .+4
004572 104006          HLT                ;SRO INCORRECT AFTER DATOB
;(SEE CONTENTS SAVED IN R1)

;SHOW THAT SRO <1-3> TRACK THE PAGE REFERENCED IF
;KT11-C IS ON AND THE REFERENCE IS NOT TO A KT11-C REGISTER
;SHOW THAT EACH VALUE IS CORRECTLY "LOCKED" IN SRO AFTER AN ABORT
004574 104400          TESTS: SCOPE
004576 012737 000006 177570      MOV      #6,2#SR      ;DISPLAY TEST NUMBER
004604 005037 177776          CLR      2#PS         ;INITIALIZE PROCESSOR STATUS
004610 012706 001000          MOV      #KSTACK,SP  ;INITIALIZE KERNEL STACK POINTER
004614 005077 176226          CLR      2SR3        ;INITIALIZE SR3
004620 005077 176206          CLR      2SR0        ;INITIALIZE SRO
004624 026727 176570 000006      CMP      TESTCT,#6   ;IS THIS TEST BEING EXECUTED IN THE
004632 001401          BEQ     .+4          ;CORRECT SEQUENCE? - BRANCH IF YES
004634 104006          HLT                ;TEST EXECUTED OUT OF ORDER - TESTCT
;CONTAINS NUMBER OF PREVIOUS TEST PLUS ONE

004636 004767 007702          JSR      %7,RWALL    ;INITIALLY SET ALL PAGES 4K, RW, BANK 0
004642 012777 007600 176500      MOV      #7600,2KDPAR7 ;MAP KERNEL 7 D-SPACE TO THE EXTERNAL BANK
004650 012777 000006 176170      MOV      #6,2SR3     ;ENABLE KERNEL AND SUPERVISOR D-SPACES
004656 012777 004734 176524      MOV      #RET6,2KTVEC ;SET UP ABORT RETURN
004664 005077 176522          CLR      2KTSTA
004670 016701 176276          MOV      S0PDR0,R1   ;LOAD R1 WITH THE ADDRESS OF THE FIRST
;SUPERVISOR D-SPACE PDR
004674 005002          CLR      R2          ;R2 WILL BE USED TO ADDRESS THE NR PAGE
004676 012703 100061          MOV      #100061,R3  ;R3 CONTAINS THE EXPECTED CONTENTS OF SRO
004702 012704 000010          MOV      #10,R4      ;R4 IS A COUNTER

```

DCKTB-B MACY11 27(732) 01-OCT-76 13:14 PAGE 16
DCKTB8.P11

```

004706 012711 077400      LOOP6:  MOV    #77400, @R1      ; MAP SUPERVISOR PDR BEING TESTED 4K, NR
004712 012737 040000 177776  MOV    #40000, @#PS      ; SET MODE TO SUPERVISOR
004720 005277 176106      INC    @SR0              ; TURN ON KT11-C
004724 005712      TST    @R2              ; ADDRESS NON-RESIDENT PAGE
004726 000777      BR     .                ; REFERENCE TO NR PAGE DIDN'T ABORT
004730 000005      RESET .                ; AFTER ERROR, TURN OFF KT11-C
004732 000416      BR     DONE6           ;
004734 017705 176072      RET6:  MOV    @SR0, R5      ; SAVE CONTENTS OF SR0
004740 005077 176066      CLR    @SR0            ; TURN OFF KT11-C
004744 020503      CMP    R5, R3          ; CHECK SAVED CONTENTS
                                ; OF SR0 (IN R5)
                                ;
004746 001401      BEQ    .+4            ; SR0 INCORRECT AFTER NR ABORT
004750 104006      HLT                    ; R3 CONTAINS THE EXPECTED CONTENTS
                                ; R5 CONTAINS THE ACTUAL CONTENTS
                                ; RESTORE STACK POINTER
004752 022626      CMP    (R6)+, (R6)+    ; MOVE POINTER TO ADDRESS NEXT PDR
004754 005721      TST    (R1)+          ; CHANGE R3 TO EXPECTED CONTENTS OF SR0
004756 062703 000002      ADD    #2, R3         ; AFTER A NR REFERENCE TO THE NEXT PAGE
                                ; CHANGE R2 TO ADDRESS THE NEXT SUPERVISOR PAGE
004762 052702 020000      ADD    #20000, R2      ; CHECK REFERENCE TO ALL SUPERVISOR D-SPACE PAGES
004766 077431      SOB    R4, LOOP6      ; RESTORE TRAP CATCHER
004770 016777 176416 176412  DONE6: MOV    KTSTA, @KTVEC
004776 005077 176410      CLR    @KTSTA

; SHOW THAT SR0 (<4> TRACKS PAGE REFERENCES (I-SPACE VS. D-SPACE) IF
; KT11-C IS ON AND REFERENCE IS NOT TO A KT11-C REGISTER
; SHOW THAT EACH VALUE IS CORRECTLY "LOCKED"
; IN SR0 AFTER AN ABORT
005002 104400      TEST7: SCOPE
005004 012737 000007 177570  MOV    #7, @#SR
005012 005037 177776      CLR    @#PS
005016 012706 001000      MOV    #*STACK, SP
005022 005077 176020      CLR    @SR3
005026 005077 176000      CLR    @SR0
005032 026727 176362 000007  CMP    TESTCT, #7
005040 001401      BEQ    .+4
005042 104006      HLT

; DISPLAY TEST NUMBER
; INITIALIZE PROCESSOR STATUS
; INITIALIZE KERNEL STACK POINTER
; INITIALIZE SR3
; INITIALIZE SR0
; IS THIS TEST BEING EXECUTED IN THE
; CORRECT SEQUENCE? - BRANCH IF YES
; TEST EXECUTED OUT OF ORDER - TESTCT
; CONTAINS NUMBER OF PREVIOUS TEST PLUS ONE

005044 004767 007474      JSR    %7, RWALL
005050 012777 007600 176272  MOV    #7600, @KDPR7
005056 012777 077400 176170  MOV    #77400, @KIPDR1
005064 012777 077400 176202  MOV    #77400, @KIPDR1
005072 012777 005126 176310  MOV    @RET7A, @KTVEC
005100 012777 000704 175740  MOV    #4, @SR3
005106 005277 175720      INC    @SR0
005112 005737 020000      TST    @#20000

; INITIALLY MAKE ALL PAGES 4K, RW, BANK 0
; MAP KERNEL D-SPACE PAGE 7 TO THE EXTERNAL BANK
; MAKE KERNEL PAGE 1 NR
; SETUP ABORT RETURN
; ENABLE KERNEL D-SPACE
; TURN ON KT11-C
; REFERENCE KERNEL 1 D-SPACE
; SHOULD ABORT SINCE IT'S MAPPED NR
; TURN OFF KT11-C
; REFERENCE TO NR PAGE DIDN'T ABORT

005116 005077 175710      CLR    @SR0
005122 104006      HLT
005124 000435      BR     DONE7
005126 017701 175700      RET7A: MOV    @SR0, R1
005132 005077 175674      CLR    @SR0
005136 022701 100023  CMP    #100023, R1
005142 001401      BEQ    .+4
005144 104006      HLT

; SAVE CONTENTS OF SR0
; TURN OFF KT11-C
; CHECK SAVED CONTENTS OF SR0
; SR0 INCORRECT (SAVED IN R1) - SHOULD SHOW

```



```

005146 012777 005200 176234      MOV      #RET7B, &KTVEC      ; NR ABORT, KERNEL D-SPACE PAGE 1
005154 005277 175652              INC      &SRO                ; SETUP NEW ABORT RETURN
005160 012707 025164              MOV      #ADR7+20000, PC     ; TURN ON KT11-C
005164 000000      ADR7:  HALT                  ; CHANGE TO KERNEL PAGE 1 PC
005166 042707 160000              BIC      #160000, PC         ; NR FETCH FROM THIS ADDRESS SHOULD ABORT
005172 005077 175634              CLR      &SRO                ; RESTORE TO BANK 0 PC
005176 000410              BR       DONE7               ; TURN OFF KT11-C
005200 017701 175626      RET7B:  MOV      &SRO, R1     ; SAVE CONTENTS OF SRO
005204 005077 175622              CLR      &SRO                ; TURN OFF KT11-C
005210 022701 100003              CMP      #100003, R1        ; CHECK SAVED CONTENTS OF SRO
005214 001401              BEQ     .+4
005216 104006              HLT
                                ; SRO INCORRECT - (CONTENTS SAVED IN R1)
                                ; SHOULD SHOW NR ABORT, KERNEL PAGE 1 I-SPACE
005220 016777 176166 176162  DONE7:  MOV      KTSTA, &KTVEC     ; RESTORE TRAP CATCHER

; SHOW THAT SRO (5-6) TRACK PAGE REFERENCED (MODE) IF
; KT11-C IS ON AND THE REFERENCE IS NOT TO A KT11-C REGISTER
; SHOW THAT EACH VALUE IS CORRECTLY "LOCKED" IN SRO AFTER AN ABORT
005226 104400      TEST10: SCOPE
005230 012737 000010 177570      MOV      #10, &#SR          ; DISPLAY TEST NUMBER
005236 005037 177776              CLR      &#PS                ; INITIALIZE PROCESSOR STATUS
005242 012706 001000              MOV      #&STACK, SP       ; INITIALIZE KERNEL STACK POINTER
005246 005077 175574              CLR      &SR3               ; INITIALIZE SR3
005252 005077 175554              CLR      &SRO               ; INITIALIZE SRO
005256 026727 176136 000010      CMP      TESTCT, #10        ; IS THIS TEST BEING EXECUTED IN THE
005264 001401              BEQ     .+4                  ; CORRECT SEQUENCE? - BRANCH IF YES
005266 104006              HLT                          ; TEST EXECUTED OUT OF ORDER - TESTCT
                                ; CONTAINS NUMBER OF PREVIOUS TEST PLUS ONE

005270 004767 007250              JSR      X7, R#ALL           ; MAP ALL PAGES RW 4K, BANK 0
005274 012777 007600 176046      MOV      #7600, &KDPAR7     ; MAP KERNEL 7 D-SPACE TO EXTERNAL BANK
005302 012777 077400 175764      MOV      #77400, &KDPR1     ; MAKE PAGE 1 IN EACH MODE'S D-SPACE
005310 012777 077400 175656      MOV      #77400, &SDPR1     ; NON-RESIDENT
005316 012777 077400 175550      MOV      #77400, &UDPR1
005324 012777 005360 176056      MOV      #RET10A, &KTVEC    ; SETUP ABORT RETURN
005332 012777 000007 175506      MOV      #7, &SR3           ; ENABLE ALL D-SPACES
005340 005277 175466              INC      &SRO                ; TURN ON KT11-C
005344 005737 020000              TST     &#20000             ; REFERENCE KERNEL PAGE 1 D-SPACE (NR) - SHOULD ABORT
005350 005077 175456              CLR      &SRO                ; TURN OFF KT11-C
005354 104006              HLT                          ; NR REFERENCE DIDN'T ABORT
005356 000464              BR       DONE10
005360 017701 175446      RET10A: MOV      &SRO, R1     ; SAVE SRO CONTENTS IN R1
005364 005077 175442              CLR      &SRO                ; TURN OFF KT11-C
005370 022701 100023              CMP      #100023, R1        ; CHECK SAVED CONTENTS OF SRO
005374 001401              BEQ     .+4
005376 104006              HLT
                                ; SRO INCORRECT (CONTENTS SAVED IN R1) - SHOULD SHOW NR
                                ; ERROR, KERNEL D-SPACE PAGE 1
005400 012777 005434 176002      MOV      #RET10B, &KTVEC    ; SETUP NEXT ABORT RETURN
005406 012737 040000 177776      MOV      #40000, &#PS       ; CHANGE MODE TO SUPERVISOR
005414 005277 175412              INC      &SRO                ; TURN ON KT11-C
005420 005737 020000              TST     &#20000             ; REFERENCE SUPERVISOR PAGE 1
                                ; D-SPACE (NR)-SHOULD ABORT
005424 005077 175402              CLR      &SRO                ; TURN OFF KT11-C
005430 104006              HLT                          ; NR REFERENCE DIDN'T ABORT
005432 000436              BR       DONE10

```

```

005434 012701 175372          RET108: MOV    @SR0,R1          ;SAVE CONTENTS OF SR0
005440 005077 175366          CLR    @SR0                ;TURN OFF KT11-C
005444 022701 100063          CMP    @100063,R1         ;CHECK SAVED CONTENTS OF SR0
005450 001401                    BEQ    .+4
005452 104006                    HLT
;SR0 INCORRECT (CONTENTS SAVED IN R1) - SHOULD SHOW NR
;ERROR, SUPERVISOR D-SPACE PAGE 1

005454 012777 005510 175726      MOV    @RET10C,@KTVEC     ;SETUP NEXT ABORT RETURN
005462 012737 140000 177776      MOV    @140000,@#PS      ;CHANGE MODE TO USER
005470 005277 175336          INC    @SR0               ;TURN ON KT11-C
005474 005737 020000          TST    @20000            ;REFERENCE USER PAGE 1 D-SPACE (NR)
005500 005077 175326          CLR    @SR0               ;TURN OFF KT11-C
005504 104006                    HLT
;NR REFERENCE DIDN'T ABORT
005506 000410                    BR
005510 017701 175316          RET10C: MOV   @SR0,R1     ;SAVE CONTENTS OF SR0
005514 005077 175312          CLR    @SR0               ;TURN OFF KT11-C
005520 022701 100163          CMP    @100163,R1       ;CHECK SAVED CONTENTS OF SR0
005524 001401                    BEQ    .+4
005526 104006                    HLT
;SR0 INCORRECT - SHOULD SHOW NR
;ERROR, USER D-SPACE PAGE 1
;(CONTENTS SAVED IN R1)

005530 016777 175656 175652  DONE10: MOV   KTSTA,@KTVEC ;RESTORE TRAP CATCHER

;SHOW THAT SR0 <1-6> DOESN'T TRACK IF KT11-C IS OFF OR IF REFERENCE IS TO
;AN INTERNAL (KT11-C) REGISTER
TEST11: SCOPE
005536 104400                    MOV    @11,@#SR          ;DISPLAY TEST NUMBER
005540 012737 000011 177570      CLR    @#PS              ;INITIALIZE PROCESSOR STATUS
005546 005037 177776          MOV    @KSTACK,SP       ;INITIALIZE KERNEL STACK POINTER
005552 012706 001000          CLR    @SR3              ;INITIALIZE SR3
005556 005077 175264          CLR    @SR0              ;INITIALIZE SR0
005562 005077 175244          CMP    TESTCT,@11        ;IS THIS TEST BEING EXECUTED IN THE
005566 026727 175626 000011  BEQ    .+4                ;CORRECT SEQUENCE? - BRANCH IF YES
005574 001401                    HLT                       ;TEST EXECUTED OUT OF ORDER - TESTCT
005576 104006                    ;CONTAINS NUMBER OF PREVIOUS TEST PLUS ONE

005600 004767 006740          JSR    %7,RWALL          ;SET ALL PAGES RW, 4K, BANK 0
005604 012777 007600 175436      MOV    @7600,@SDPAR7    ;MAP SUPERVISOR 7 D-SPACE TO THE
;EXTERNAL BANK
005612 012777 000007 175226      MOV    @7,@SR3           ;ENABLE ALL D-SPACES
005620 012737 040000 177776      MOV    @40000,@#PS      ;SET MODE TO SUPERVISOR
005626 005277 175200          INC    @SR3              ;TURN ON KT11-C
005632 042777 000001 175172      BIC    @1,@SR0           ;TURN OFF KT11-C - SHOULD
;NOT TRACK REFERENCE TO SUPERVISOR
;D-SPACE 7 WHICH IS AN INTERNAL
;REFERENCE (TO SR0)
005640 005037 177776          CLR    @#PS              ;CHANGE TO KERNEL MODE
005644 022777 000060 175160      CMP    @60,@SR0         ;CHECK SR0
005652 001401                    BEQ    .+4
005654 104006                    HLT
;SR0 INCORRECT - SHOULD SHOW REFERENCE
;TO SUPERVISOR 0 D-SPACE
;IF IT SHOWS SUPERVISOR 7 D-SPACE,
;IT TRACKED THE INTERNAL REFERENCE
;IF IT SHOWS KERNEL 0, IT IS
;TRACKING WITH KT11-C OFF

005656 005077 175150          CLR    @SR0
005662 005077 175160          CLR    @SR3

```

```

;SHOW THAT ALL BITS IN SR2 WORK BY ROTATING A BIT THRU SR2.  MAP USER NR
;(ALL PAGES), THEN SET UP THE DESIRED VALUE FOR SR2 ON THE KERNEL
;STACK AND RTI TO USER.  THIS SHOULD GIVE A NR ABORT WITH THE DESIRED
;VALUE IN SR2
TEST12: SCOPE
005666 104400
005670 012737 000012 177570      MOV      #12,@#SR      ;DISPLAY TEST NUMBER
005676 005037 177776      CLR      @#PS          ;INITIALIZE PROCESSOR STATUS
005702 012706 001000      MOV      #KSTACK,SP   ;INITIALIZE KERNEL STACK POINTER
005706 005077 175134      CLR      @SR3         ;INITIALIZE SR3
005712 005077 175114      CLR      @SR0         ;INITIALIZE SR0
005716 026727 175476 000012      CMP      TESTCT,#12   ;IS THIS TEST BEING EXECUTED IN THE
005724 001401      BEQ     .+4           ;CORRECT SEQUENCE? - BRANCH IF YES
005726 104006      HLT                    ;TEST EXECUTED OUT OF ORDER - TESTCT
                                ;CONTAINS NUMBER OF PREVIOUS TEST PLUS ONE

005730 004767 006560      JSR      %7,CLRALL    ;INITIALLY CLEAR ALL KT11-C REGISTERS
005734 012777 077406 175310      MOV      #77406,@KIPDR0 ;MAP KERNEL 0 I-SPACE 4K,RW,BANK 0
005742 012777 007600 175360      MOV      #7600,@KIPDR7 ;MAP KERNEL 7 I-SPACE 4K,RW,
005750 012777 077406 175312      MOV      #77406,@KIPDR7 ;EXTERNAL BANK
005756 012700 000002      MOV      #2,R0        ;SETUP FIRST VALUE TO BE CHECKED
005762 012777 006012 175420      MOV      #RET12,@KTVEC ;SETUP ABORT RETURN
005770 005077 175416      CLR      @KTSTA
005774 012746 140000      LOOP12: MOV      #140000,-(R6) ;PUSH USER MODE ON STACK
006000 010046      MOV      R0,-(R6)    ;PUSH VALUE TO BE CHECKED ON STACK
006002 005277 175024      INC      @SR0        ;TURN ON KT11-C
006006 000002      RTI                    ;POP STACK - NEW PC SHOULD
                                ;GIVE NR ABORT
                                ;SHOULDN'T BE ANY WAY TO ARRIVE HERE
006010 000777      BR      .
006012 042777 000001 175012  RET12: BIC      #1,@SR0    ;TURN OFF KT11-C
006020 020077 175016      CMP      R0,@SR2     ;CHECK VALUE IN SR2
006024 001401      BEQ     .+4
006026 104006      HLT                    ;SR2 INCORRECT - SHOULD CONTAIN
                                ;THE PC POPPED OFF THE STACK
                                ;WHOSE VALUE IS IN R0

006030 005077 174776      CLR      @SR0
006034 022626      CMP      (R6)+,(R6)+ ;RESTORE STACK POINTER
006036 006300      ASL     R0           ;SHIFT BIT TO BE TESTED
006040 103355      BCC     LOOP12      ;BRANCH IF NOT DONE
006042 016777 175344 175340      MOV      @KTSTA,@KTVEC ;RESTORE TRAP CATCHER

;SHOW THAT A MEMORY MANAGEMENT TRAP CONDITON WILL NOT CAUSE A TRAP IF
;THE MANAGEMENT TRAP FLAG IN SR0 IS ALREADY SET
;SHOW THAT HAVING THE ABORT ERROR
;BITS SET WILL NOT PREVENT A MEMORY MANAGEMENT TRAP
TEST13: SCOPE
006050 104400
006052 012737 000013 177570      MOV      #13,@#SR    ;DISPLAY TEST NUMBER
006060 005037 177776      CLR      @#PS        ;INITIALIZE PROCESSOR STATUS
006064 012706 001000      MOV      #KSTACK,SP  ;INITIALIZE KERNEL STACK POINTER
006070 005077 174752      CLR      @SR3        ;INITIALIZE SR3
006074 005077 174732      CLR      @SR0        ;INITIALIZE SR0
006100 026727 175314 000013      CMP      TESTCT,#13  ;IS THIS TEST BEING EXECUTED IN THE
006106 001401      BEQ     .+4         ;CORRECT SEQUENCE? - BRANCH IF YES
006110 104006      HLT                    ;TEST EXECUTED OUT OF ORDER - TESTCT
                                ;CONTAINS NUMBER OF PREVIOUS TEST PLUS ONE

```

```

006112 004767 006426 JSR %7,RWALL ;INITIALIZE ALL PAGES RW,4K, BANK 0
006116 012777 077405 175132 MOV #77405,%KIPDR2 ;SET KERNEL PAGE 2 RRW,W,4K
006124 012777 007600 175176 MOV #7600,%KIPDR7 ;MAP KERNEL PAGE 7 TO EXTERNAL BANK
006132 012777 006174 175250 MOV #RET13A,%KTVEC ;SETUP MEMORY MANAGEMENT ABORT RETURN
006140 005077 175246 CLR %KTSTA
006144 005277 174662 INC %SRO ;TURN ON KT11-C
006150 012777 161001 174654 MOV #161001,%SRO ;ENABLE MEMORY MANAGEMENT TRAPPING
;AND SET THE ABORT ERROR BITS
;WRITE KERNEL PAGE 2 (RRW,W)-SHOULD TRAP

006156 013737 007000 047000 MOV %7000,%47000
006164 005077 174642 CLR %SRO
006170 104006 HLT ;NO TRAP OCCURRED
006172 000416 BR CONT13
006174 022626 RET13A: CMP (SP)+,(SP)+ ;RESTORE THE STACK POINTER
006176 017701 174630 MOV %SRO,R1 ;SAVE CONTENTS OF SRO
006202 005077 174624 CLR %SRO ;TURN OFF KT11-C
006206 022701 171001 CMP #171001,R1 ;CHECK SAVED CONTENTS OF SRO
006212 001401 BEQ .+4
006214 104006 HLT ;SAVED CONTENTS OF SRO INCORRECT (CONTAINED IN R1)
006216 022777 077705 175032 CMP #77705,%KIPDR2 ;CHECK THE PDR CORRESPONDING TO THE TRAP REFERENCE
006224 001401 BEQ .+4
006226 104006 HLT ;THE PDR CORRESPONDING TO THE TRAP REFERENCE
;IS INCORRECT
;SETUP MEMORY MANAGEMENT TRAP RETURN
;TURN ON KT11-C, ENABLE MMGT TRAPPING,
;AND SET MEMORY MANAGEMENT TRAP

006230 012777 006314 175152 CONT13: MOV #RET13B,%KTVEC
006236 012777 011001 174566 MOV #11001,%SRO

006244 012777 077405 175004 MOV #77405,%KIPDR2
006252 013737 007000 047000 MOV %7000,%47000
;CLEAR A AND W BITS
;WRITE KERNEL PAGE 2 (RRW,W) -
;SHOULDN'T TRAP SINCE MEMORY MANAGEMENT
;TRAP HASN'T BEEN CLEARED YET
;TURN OFF KT11-C
;CHECK SRO

006260 042777 000001 174544 BIC #1,%SRO
006266 022777 011000 174536 CMP #11000,%SRO
006274 001401 BEQ .+4
006276 104006 HLT ;SRO INCORRECT-SHOULD SHOW MEMORY MANAGEMENT TRAP,
;MMGT ENABLE, AND PAGE 0 I-SPACE
;CHECK PDR CORRESPONDING TO THE TRAP REFERENCE

006300 022777 077705 174750 CMP #77705,%KIPDR2
006306 001401 BEQ .+4
006310 104006 HLT ;PDR CORRESPONDING TO THE TRAP REFERENCE IS INCORRECT
006312 000405 BR DONE13
006314 022626 RET13B: CMP (SP)+,(SP)+ ;RESTORE THE STACK POINTER
006316 042777 000001 174506 BIC #1,%SRO ;TURN OFF KT11-C
006324 104006 HLT ;MMGT TRAP ACCESS TRAPPED BEFORE
;PREVIOUS MMGT TRAP WAS CLEARED
;RESTORE MEMORY MANAGEMENT TRAP RETURN
;TO CAUSE A HALT ON A FALSE TRAP OR ABORT
;REINITIALIZE SRO

006326 016777 175060 175054 DONE13: MOV KTSTA,%KTVEC
006334 005077 174472 CLR %SRO

;IF MEMORY MANAGEMENT ENABLE IS SET WITH AN ATTENTION (A) BIT ALREADY SET, NO TRAP
;WILL OCCUR UNTIL ANOTHER MEMORY MANAGEMENT FAULT OCCURS

006340 104400 TEST14: SCOPE
006342 012737 000014 177570 MOV #14,%SR ;DISPLAY TEST NUMBER
006350 005037 177776 CLR %PS ;INITIALIZE PROCESSOR STATUS
006354 012706 001000 MOV %KSTACK,SP ;INITIALIZE KERNEL STACK POINTER
006360 005077 174462 CLR %SR3 ;INITIALIZE SR3
006364 005077 174442 CLR %SRO ;INITIALIZE SRO
006370 026727 175024 000014 CMP TESTCT,#14 ;IS THIS TEST BEING EXECUTED IN THE

```


DCKTB-B MACY11 27(732) 01-OCT-76 13:14 PAGE 22
DCKTB8.P11

```

006646 005077 174540          CLR  @KTSTA
006652 012777 010001 174152    MOV  @10001,@SR0 ;TURN ON KT11-C AND SET
;MEMORY MANAGEMENT FAULT
006660 005737 020000          TST  @#20000 ;REFERENCE KERNEL PAGE 1-SHOULD
;ABORT SINCE IT'S MAPPED NR
006664 042777 000001 174140    BIC  @1,@SR0 ;TURN OFF KT11-C IF NO ABORT
006672 104006          HLT ;NO ABORT ON REFERENCE TO NR
;KERNEL PAGE 1 AFTER SETTING
;MEMORY MANAGEMENT FAULT
006674 000403          BR   DONE15 ;TURN OFF KT11-C AFTER ABORT
006676 005077 174130    RET15: CLR @SR0 ;RESTORE STACK POINTER
006702 022626          CMP  (SP)+,(SP)+ ;RESTORE TRAP CATCHER
006704 016777 174502 174476    DONE15: MOV @KTSTA,@KTVEC

;SHOW THAT IF THE INSTRUCTION SETTING MEMORY MANAGEMENT TRAP ENABLE
;CAUSES A TRAP REFERENCE BEFORE SETTING ENABLE, THE TRAP WILL NOT OCCUR
;ALSO SHOW THAT MEMORY MANAGEMENT WILL NOT TRAP ON AN INTERNAL REFERENCE
006712 104400          TEST16: SCOPE
006714 012737 000016 177570    MOV  @16,@SR ;DISPLAY TEST NUMBER
006722 005037 177776          CLR  @#PS ;INITIALIZE PROCESSOR STATUS
006726 012706 001000          MOV  @KSTACK,SP ;INITIALIZE KERNEL STACK POINTER
006732 005077 174110          CLR  @SR3 ;INITIALIZE SR3
006736 005077 174070          CLR  @SR0 ;INITIALIZE SR0
006742 026727 174452 000016    CMP  TESTCT,@16 ;IS THIS TEST BEING EXECUTED IN THE
006750 001401          BEQ  .+4 ;CORRECT SEQUENCE? - BRANCH IF YES
006752 104006          HLT ;TEST EXECUTED OUT OF ORDER - TESTCT
;CONTAINS NUMBER OF PREVIOUS TEST PLUS ONE

006754 004767 005564          JSR  %7,RWALL ;MAP ALL PAGES 4K, RW, BANK 0
006760 012777 007600 174342    MOV  @7600,@KIPDR7 ;MAP KERNEL 7 TO THE EXTERNAL BANK, RWT
006766 012777 077404 174274    MOV  @77404,@KIPDR7
006774 012777 077404 174252    MOV  @77404,@KIPDR1 ;MAP KERNEL 1 RWT, 4K
007002 012777 007100 174400    MOV  @RET16,@KTVEC ;SETUP TRAP RETURN IN CASE
007010 005077 174376          CLR  @KTSTA
007014 005277 174012          INC  @SR0 ;TURN ON KT11-C
007020 053777 023014 174004    BIS  @#K1000+20000,@SR0 ;SET MEMORY MANAGEMENT TRAP ENABLE
;AND REFERENCE A RWT PAGE (KERNEL PAGE 1) FIRST

007026 012777 007112 174354    MOV  @RET16A,@KTVEC
007034 032777 001000 173770    BIT  @1000,@SR0 ;TRAP REFERENCE TO A KT11-C REGISTER
007042 001001          BNE  .+4
007044 104006          HLT ;MEMORY MANAGEMENT TRAP ENABLE WASN'T SET
007046 005077 173760          CLR  @SR0 ;TURN OFF KT11-C
007052 022777 077604 174174    CMP  @77604,@KIPDR1 ;CHECK KERNEL PDR1
007060 001401          BEQ  .+4
007062 104006          HLT ;KERNEL PDR 1 WRONG-SHOULD SHOW THAT
;PAGE WAS REFERENCED BUT NOT WRITTEN
007064 022777 077404 174176    CMP  @77404,@KIPDR7 ;CHECK KERNEL PDR 7
007072 001401          BEQ  .+4
007074 104006          HLT ;KERNEL PDR 7 INCORRECT-SHOULDN'T HAVE
;TRACKED REFERENCE TO KT11-C REGISTER

007076 000411          BR   DONE16
007100 042777 000001 173724    RET16: BIC @1,@SR0 ;TURN OFF KT11-C
007106 104006          HLT ;TRAP OCCURRED ON THE INSTRUCTION SETTING TRAP ENABLE
007110 000404          BR   DONE16
007112 042777 000001 173712    RET16A: BIC @1,@SR0
007120 104006          HLT ;TRAP OCCURRED ON A REFERENCE TO AN INTERNAL
;KT11-C REGISTER

```

```

007122 005077 173704      DONE16: CLR  @SR0
007126 016777 174260 174254      MOV  KTSTA,@KTVEC

;SHOW THAT IF AN INSTRUCTION WHICH TURNS OFF MEMORY MANAGEMENT
;TRAPPING MAKES A TRAP REFERENCE, A TRAP WILL OCCUR
TEST17: SCOPE
007134 104400      MOV  #17,@#SR      ;DISPLAY TEST NUMBER
007136 012737 000017 177570      CLR  @#PS          ;INITIALIZE PROCESSOR STATUS
007144 005037 177776      MOV  #KSTACK,SP   ;INITIALIZE KERNEL STACK POINTER
007150 012706 001000      CLR  @SR3         ;INITIALIZE SR3
007154 005077 173666      CLR  @SR0         ;INITIALIZE SRO
007160 005077 173646      CMP  TESTCT,#17   ;IS THIS TEST BEING EXECUTED IN THE
007164 026727 174230 000017      BEQ  .+4          ;CORRECT SEQUENCE? - BRANCH IF YES
007172 001401      BEQ  .+4          ;TEST EXECUTED OUT OF ORDER - TESTCT
007174 104006      HLT              ;CONTAINS NUMBER OF PREVIOUS TEST PLUS ONE

007176 004767 005342      JSR  %7,RWALL     ;MAP ALL PAGES 4K, RW, BANK 0
007202 012777 077404 174044      MOV  #77404,@KIPDR1 ;MAP KERNEL 1 RWT
007210 012777 007600 174112      MOV  #7600,@KIPAR7 ;MAP KERNEL 7 TO THE EXTERNAL BANK
007216 012777 007256 174164      MOV  #RET17,@KTVEC ;SETUP TRAP RETURN
007224 005077 174162      CLR  @KTSTA
007230 012777 001001 173574      MOV  #1001,@SR0   ;TURN ON KT11-C AND ENABLE MEMORY MANAGEMENT TRAPPING
007236 043777 023014 173566      BIC  @#K1000+20000,@SR0 ;PICK UP VALUE TO DO BIT CLEAR
;WITH THRU KERNEL 1(RWT)
;CAUSES A TRAP REFERENCE WHICH SHOULD TRAP
;IF NO TRAP, TURN OFF KT11-C
;TRAP REFERENCE TO KERNEL PAGE 1 WHEN CLEARING
;TRAP ENABLE DIDN'T TRAP
007244 042777 000001 173560      BIC  #1,@SR0
007252 104006      HLT

007254 000410      BR   DONE17
007256 042777 000001 173546      RET17: BIC #1,@SR0 ;TURN OFF KT11-C AFTER TRAP
007264 022777 010000 173540      CMP  #10000,@SR0 ;CHECK SRO
007272 001401      BEQ  .+4
007274 104006      HLT ;SRO INCORRECT AFTER MEMORY MANAGEMENT TRAP
007276 016777 174110 174104      DONE17: MOV  KTSTA,@KTVEC

;SHOW THAT SETTING PROGRAMMER'S AID SYSTEM TRAP (BIT 11) WON'T PREVENT POTENTIAL
;MEMORY MANAGEMENT TRAPS
TEST20: SCOPE
007304 104400      MOV  #20,@#SR     ;DISPLAY TEST NUMBER
007306 012737 000020 177570      CLR  @#PS          ;INITIALIZE PROCESSOR STATUS
007314 005037 177776      MOV  #KSTACK,SP   ;INITIALIZE KERNEL STACK POINTER
007320 012706 001000      CLR  @SR3         ;INITIALIZE SR3
007324 005077 173646      CLR  @SR0         ;INITIALIZE SRO
007330 005077 173476      CMP  TESTCT,#20   ;IS THIS TEST BEING EXECUTED IN THE
007334 026727 174060 000020      BEQ  .+4          ;CORRECT SEQUENCE? - BRANCH IF YES
007342 001401      BEQ  .+4          ;TEST EXECUTED OUT OF ORDER - TESTCT
007344 104006      HLT              ;CONTAINS NUMBER OF PREVIOUS TEST PLUS ONE

007346 004767 005172      JSR  %7,RWALL     ;INITIALIZE ALL PAGES RW, 4K, BANK 0
007352 012777 077404 173674      MOV  #77404,@KIPDR1 ;MAP KERNEL PAGE 1 RWT, 4K, BANK 0
007360 012777 007600 173742      MOV  #7600,@KIPAR7 ;MAP KERNEL PAGE 7 TO THE EXTERNAL BANK
007366 012777 007424 174014      MOV  #RET20,@KTVEC ;SETUP MEMORY MANAGEMENT TRAP RETURN
007374 005077 174012      CLR  @KTSTA
007400 012777 005001 173424      MOV  #5001,@SR0   ;TURN ON KT11-C, MGMT TRAP ENABLE
;AND SET PROGRAMMER'S AID SYSTEM
;TRAP (BIT 11)

```

```

007406 005737 021000          TST      @#21000      ;REFERENCE KERNEL PAGE 1 (RRWT)-SHOULD TRAP
007412 042777 000001 173412    BIC      #1,@SR0     ;TURN OFF KT11-C
007420 104006          HLT                     ;SETTING SRO <11> INHIBITED
007422 000411          BR      DONE20        ;A MEMORY MANAGEMENT TRAP
007424 022626          RET20: CMP     (SP)+,(SP)+ ;RESTORE STACK POINTER
007426 042777 000001 173376    BIC      #1,@SR0     ;TURN OFF KT11-C
007434 022777 015000 173370    CMP      #15000,@SR0 ;CHECK SRO
007442 001401          BEQ      .+4
007444 104006          HLT                     ;SRO INCORRECT AFTER MEMORY
                                ;MANAGEMENT TRAP
007446 005077 173360          DONE20: CLR     @SR0   ;INITIALIZE SRO
007452 016777 173734 173730    MOV     KTSTA,@KTVEC ;RESTORE TRAP RETURN TO CAUSE A
                                ;HALT IN CASE OF A FALSE ABORT OR TRAP

                                ;SETTING SRO<11> SHOULD NOT PREVENT ABORTS OR LOCK UP TRACKING
007460 104400          TEST21: SCOPE
007462 012737 000021 177570    MOV     #21,@#SR     ;DISPLAY TEST NUMBER
007470 005037 177776          CLR     @#PS         ;INITIALIZE PROCESSOR STATUS
007474 012706 001000          MOV     #KSTACK,SP  ;INITIALIZE KERNEL STACK POINTER
007500 005077 173342          CLR     @SR3        ;INITIALIZE SR3
007504 005077 173322          CLR     @SR0        ;INITIALIZE SRO
007510 026727 173704 000021    CMP     TESTCT,#21  ;IS THIS TEST BEING EXECUTED IN THE
007516 001401          BEQ      .+4         ;CORRECT SEQUENCE? - BRANCH IF YES
007520 104006          HLT                     ;TEST EXECUTED OUT OF ORDER - TESTCT
                                ;CONTAINS NUMBER OF PREVIOUS TEST PLUS ONE

007522 004767 005016          JSR     %7,RWALL     ;INITIALIZE ALL PAGES RW, 4K, BANK 0
007526 012777 077400 173520    MOV     #77400,@KIPDR1 ;MAP KERNEL PAGE 1 NR
007534 012777 007600 173566    MOV     #7600,@KIPAR7 ;MAP KERNEL PAGE 7 TO EXTERNAL BANK
007542 012777 007616 173640    MOV     #RET21,@KTVEC ;SETUP MEMORY MANAGEMENT ABORT
007550 005077 173636          CLR     @KTSTA      ;RETURN
007554 012777 004001 173250    MOV     #4001,@SR0   ;TURN ON KT11-C, AND SET PROGRAMMER'S AID
007562 000240          NOP                     ;SYSTEM TRAP (BIT 11)
007564 017701 173252          AD21: MOV     @SR2,R1  ;CHECK TO SEE THAT SR2 IS STILL TRACKING
007570 022701 007564          CMP     #AD21,R1
007574 001401          BEQ      .+4
007576 104006          HLT
007600 005737 021000          TST      @#21000     ;SR2 NOT TRACKING AFTER SRO<11> SET
007604 042777 000001 173220    BIC      #1,@SR0     ;READ NR PAGE-SHOULD ABORT
007612 104006          HLT                     ;TURN OFF KT11-C IF NO ABORT
007614 000410          BR      DONE21        ;SRO <11> SET PREVENTED NR REFERENCE FROM ABORTING
007616 042777 000001 173206    RET21: BIC     #1,@SR0 ;TURN OFF KT11-C
007624 022777 104002 173200    CMP     #104002,@SR0 ;CHECK SRO
007632 001401          BEQ      .+4
007634 104006          HLT                     ;SRO INCORRECT - SHOULD SHOW NR REFERENCE TO KERNEL
                                ;PAGE 1, AND BIT 11 SHOULD STILL BE SET
007636 016777 173550 173544    DONE21: MOV     KTSTA,@KTVEC ;RESTORE TRAP CATCHER

                                ;SHOW THAT IF THE STACK IS MAPPED TO A RRWTW PAGE AN IMPLICIT
                                ;STACK WRITE WILL CAUSE A MEMORY MANAGEMENT TRAP TO OCCUR
007644 104400          TEST22: SCOPE
007646 012737 000022 177570    MOV     #22,@#SR     ;DISPLAY TEST NUMBER
007654 005037 177776          CLR     @#PS         ;INITIALIZE PROCESSOR STATUS
007660 012706 001000          MOV     #KSTACK,SP  ;INITIALIZE KERNEL STACK POINTER
007664 005077 173156          CLR     @SR3        ;INITIALIZE SR3
007670 005077 173136          CLR     @SR0        ;INITIALIZE SRO

```



```

007674 026727 173520 000022      CMP      TESTCT, #22      ; IS THIS TEST BEING EXECUTED IN THE
007702 001401                      BEQ      .+4             ; CORRECT SEQUENCE? - BRANCH IF YES
007704 104006                      HLT                               ; TEST EXECUTED OUT OF ORDER - TESTCT
                                           ; CONTAINS NUMBER OF PREVIOUS TEST PLUS ONE

007706 004767 004602      JSR      %7, CLRALL      ; INITIALLY CLEAR ALL KT11-C REGISTERS
007712 012777 077405 173352      MOV      #77405, @KDPDR0 ; SETUP KERNEL 0 D-SPACE RRWTW
007720 012777 007600 173422      MOV      #7600, @KDPAR7  ; MAP KERNEL 7 D-SPACE 4K, RW,
007726 012777 077406 173354      MOV      #77406, @KDPDR7 ; EXTERNAL BANK
007734 012777 077406 173310      MOV      #77406, @KIPDR0 ; SETUP KERNEL 0 I-SPACE RW
007742 012777 000004 173076      MOV      #4, @SR3       ; ENABLE KERNEL D-SPACE
007750 012777 010002 173432      MOV      @RET22, @KTVEC ; SETUP TRAP RETURN
007756 012777 001001 173046      MOV      #1001, @SRO    ; TURN ON KT11-C AND ENABLE MEMORY
                                           ; MANAGEMENT TRAPPING
                                           ; IMPLICIT STACK WRITE TO RRWTW SPACE

007764 004767 000002      JSR      PC, ADR22
007770 000240                      NOP
007772 005077 173034      ADR22:  CLR      @SRO    ; TURN OFF KT11-C
007776 104006                      HLT                               ; IMPLICIT STACK WRITE OF RRWTW SPACE
010000 000425                      BR      DONE22                 ; VIA JSR DIDN'T TRAP
010002 042777 000001 173022      RET22:  BIC      #1, @SRO    ; TURN OFF KT11-C
010010 022706 000772                      CMP      #KSTACK-6, SP      ; CHECK STACK POINTER
010014 001401                      BEQ      .+4
010016 104006                      HLT                               ; STACK POINTER INCORRECT - SHOULD HAVE BEEN
                                           ; PUSHED ONCE BY JSR AND TWICE BY MMGT TRAP
                                           ; CHECK SRO

010020 022777 011020 173004      CMP      #11020, @SRO
010026 001401                      BEQ      .+4
010030 104006                      HLT                               ; SRO INCORRECT - SHOULD SHOW KERNEL
                                           ; I-SPACE 0, WITH TRAP ENABLE AND MMGT TRAP SET
                                           ; CHECK CONTENTS OF STACK

010032 022766 007770 000004      CMP      #ADR22-2, 4(R6)
010040 001401                      BEQ      .+4
010042 104006                      HLT                               ; ADDRESS OF RETURN FROM JSR NOT
                                           ; ON STACK CORRECTLY
                                           ; CHECK CONTENTS OF STACK

010044 022716 007772      CMP      #ADR22, (SP)
010050 001401                      BEQ      .+4
010052 104006                      HLT                               ; ADDRESS IN PC AT TIME OF
                                           ; MEMORY MANAGEMENT TRAP NOT
                                           ; CORRECTLY STORED ON-STACK

010054 005077 172766      DONE22: CLR      @SR3      ; DISABLE D-SPACES
010060 016777 173326 173322      MOV      KTSTA, @KTVEC    ; RESTORE TRAP CATCHER

; TEST PAGE LENGTH ERROR CHECKING (EXPAND DOWN NOT SET)
; KERNEL PAGE 1 IS USED WITH ALL PAGE LENGTH VALUES
; SHOW THAT REFERENCES TO BOTH BOUNDARIES OF THE ALLOWED AREA DON'T TRAP OR ABORT
; SHOW THAT A REFERENCE TO THE FIRST WORD BEYOND THE ALLOWABLE AREA DOES TRAP
TEST23: SCOPE
010066 104400                      MOV      #23, @#SR        ; DISPLAY TEST NUMBER
010070 012737 000023 177570      CLR      @#PS           ; INITIALIZE PROCESSOR STATUS
010076 005037 177776                      MOV      #KSTACK, SP     ; INITIALIZE KERNEL STACK POINTER
010102 012706 001000                      CLR      @SR3           ; INITIALIZE SR3
010106 005077 172734                      CLR      @SRO           ; INITIALIZE SRO
010112 005077 172714                      CMP      TESTCT, #23
010116 026727 173276 000023      BEQ      .+4             ; IS THIS TEST BEING EXECUTED IN THE
010124 001401                      HLT                               ; CORRECT SEQUENCE? - BRANCH IF YES
010126 104006                      HLT                               ; TEST EXECUTED OUT OF ORDER - TESTCT
                                           ; CONTAINS NUMBER OF PREVIOUS TEST PLUS ONE

```

010130	004767	004410			JSR	%7,RWALL	; INITIALIZE ALL PAGES TO RW, 4K, BANK 0
010134	012777	007600	173166		MOV	#7600,@KIPAR7	; MAP KERNEL PAGE 7 TO THE EXTERNAL BANK
010142	012702	000006			MOV	#6,R2	; R2 CONTAINS VALUE TO BE LOADED IN THE
							; PDR BEING CHECKED (INCLUDING PLF)
010146	012701	020076			MOV	#20076,R1	; R1 IS USED TO REFERENCE THE TOP ADDRESS
							; WITHIN THE ALLOWED AREA
010152	012777	010232	173230		MOV	#RET23A,@KTVEC	; SETUP ABORT RETURN IN CASE REFERENCE
010160	005077	173226			CLR	@KTSTA	; WITHIN ALLOWED AREA ABORTS
010164	005277	172642		LOOP23:	INC	@SRO	; TURN ON KT11-C
010170	010277	173060			MOV	R2,@KIPDR1	; SET KERNEL PAGE 1 TO NEW PAGE LENGTH
010174	005727	020000			TST	#20000	; READ LOWER BOUNDARY-SHOULDN'T ABORT
010200	005711				TST	@R1	; READ UPPER ALLOWED BOUNDARY-SHOULDN'T
							; ABORT
010202	012777	010252	173200		MOV	#RET23B,@KTVEC	; SETUP ABORT RETURN
010210	020127	037776			CMP	R1,#37776	; CHECK FOR DONE (TO AVOID REFERENCING
							; NEXT PAGE)
010214	103041				BHIS	DONE23	; EXIT LOOP IF DONE
010216	005761	000002			TST	2(R1)	; REFERENCE OUTSIDE ALLOWED AREA -
							; SHOULD ABORT
010222	005077	172604			CLR	@SRO	; TURN KT11-C OFF IF NO ABORT
010226	104006				HLT		; NO ABORT OCCURRED ON A REFERENCE
							; OUTSIDE THE ALLOWED PAGE LENGTH
							; THE ADDRESS REFERENCED WAS THE VALUE CONTAINED IN
							; R1 PLUS 2
010230	000426				BR	CONT23	
010232	042777	000001	172572	RET23A:	BIC	#1,@SRO	; TURN OFF KT11-C
010240	022626				CMP	(SP)+,(SP)+	; RESTORE STACK POINTER
010242	104006				HLT		; REFERENCE WITHIN ALLOWED AREA
							; CAUSED A TRAP OR ABORT
010244	005077	172562			CLR	@SRO	; CLEAR ERROR BITS
010250	000416				BR	CONT23	
010252	022626			RET23B:	CMP	(SP)+,(SP)+	; RESTORE STACK POINTER
010254	017703	172552			MOV	@SRO,R3	; SAVE CURRENT SRO
010260	005077	172546			CLR	@SRO	; TURN OFF KT11-C
010264	022703	040003			CMP	#40003,R3	; CK SAVED SRO
010270	001401				BEQ	+.4	
010272	104006				HLT		; CONTENTS OF SRO INCORRECT AFTER
							; PAGE LENGTH ERROR ABORT - SHOULD SHOW PL ERROR
							; AND KERNEL PAGE 1
010274	022777	000002	172530		CMP	#2,@SRO	; CHECK SRO TO BE SURE PL BIT CLEARED
010302	001401				BEQ	+.4	
010304	104006				HLT		; SRO INCORRECT AFTER CLEARING IT
							; ONLY KERNEL PAGE 1 SHOULD STILL BE SET
010306	062701	000100		CONT23:	ADD	#100,R1	; SETUP R1 TO REFERENCE BOUNDARY OF
							; NEXT PAGE
010312	062702	000400			ADD	#400,R2	; ADD 1 TO VALUE TO BE LOADED IN
							; PAGE LENGTH FIELD
010316	000722				BR	LOOP23	; CHECK NEXT PAGE LENGTH VALUE
010320	005077	172506		DONE23:	CLR	@SRO	; TURN OFF KT11-C
010324	016777	173062	173056		MOV	KTSTA,@KTVEC	; RESTORE MEMORY MANAGEMENT ABORT RETURN
010332	005077	173054			CLR	@KTSTA	; TO CAUSE HALT ON A FALSE TRAP
							; OR ABORT

```

; TEST PAGE LENGTH ERROR CHECKING (EXPAND DOWN SET)
; KERNEL PAGE 1 IS TESTED WITH ALL VALUES OF PAGE LENGTH FIELD
; SHOW THAT REFERENCES TO BOTH BOUNDARIES OF THE ALLOWED AREA DON'T TRAP OR ABORT

```

```

;SHOW THAT A REFERENCE TO THE WORD IMMEDIATELY BELOW THE ALLOWED AREA DOES TRAP
TEST24: SCOPE
010336 104400          MOV      #24, @SR          ; DISPLAY TEST NUMBER
010340 012737 000024 177570  CLR      @PS              ; INITIALIZE PROCESSOR STATUS
010346 005037 177776          MOV      @KSTACK, SP     ; INITIALIZE KERNEL STACK POINTER
010352 012706 001000          CLR      @SR3            ; INITIALIZE SR3
010356 005077 172464          CLR      @SRO           ; INITIALIZE SRO
010362 005077 172444          CMP      TESTCT, #24     ; IS THIS TEST BEING EXECUTED IN THE
010366 026727 173026 000024  BEQ      .+4             ; CORRECT SEQUENCE? - BRANCH IF YES
010374 001401          HLT                      ; TEST EXECUTED OUT OF ORDER - TESTCT
010376 104006          ; CONTAINS NUMBER OF PREVIOUS TEST PLUS ONE

010400 004767 004140          JSR      %7, RWALL        ; INITIALIZE ALL PAGES RW, 4K, BANK 0
010404 012777 007600 172716  MOV      #7600, @KIPAR7  ; MAP KERNEL PAGE 7 TO EXTERNAL BANK
010412 012702 077416          MOV      #77416, R2      ; R2 CONTAINS VALUE TO BE LOADED IN THE
                                ; PDR BEING CHECKING (INCLUDING PLF)
010416 012701 037700          MOV      #37700, R1     ; R1 IS USED TO REFERENCE THE LOWEST
                                ; ALLOWED ADDRESS IN THE PAGE
010422 012777 010502 172760  MOV      @RET24A, @KTVEC ; SETUP ABORT RETURN IN CASE REFERENCE
010430 005077 172756          CLR      @KTSTA         ; WITHIN ALLOWED AREA ABORTS
010434 005277 172372          LOOP24: INC @SRO        ; TURN ON KT11-C
010440 010277 172610          MOV      R2, @KIPDR1    ; SET KERNEL PAGE 1 TO NEW PAGE LENGTH
010444 005727 037776          TST     #37776         ; REFERENCE UPPER ALLOWED BOUNDARY
010450 005711          TST     @R1            ; REFERENCE LOWER ALLOWED BOUNDARY
                                ; - NEITHER REFERENCE SHOULD ABORT
010452 012777 010522 172730  MOV      @RET24B, @KTVEC ; SETUP ABORT RETURN
010460 020127 020000          CMP     R1, #20000      ; CHECK FOR DONE
010464 003441          BLE     DONE24         ; EXIT LOOP IF DONE
010466 005761 177776          TST     -2(R1)         ; REFERENCE BELOW ALLOWED AREA -
                                ; SHOULD ABORT
010472 005077 172334          CLR     @SRO          ; TURN KT11-C OFF
010476 104006          HLT                      ; NO ABORT OCCURRED ON A REFERENCE
                                ; OUTSIDE THE ALLOWED PAGE LENGTH
                                ; THE ADDRESS REFERENCED WAS THE VALUE CONTAINED IN
                                ; R1 MINUS 2

010500 000426          BR      CONT24
010502 042777 000001 172322 RET24A: BIC     #1, @SRO      ; TURN OFF KT11-C
010510 022626          CMP     (SP)+, (SP)+    ; RESTORE STACK POINTER
010512 104006          HLT                      ; REFERENCE WITHIN ALLOWED AREA CAUSED
                                ; A TRAP OR ABORT
                                ; CLEAR ERROR BITS

010514 005077 172312          CLR     @SRO
010520 000416          BR      CONT24
010522 022626          RET24B: CMP (SP)+, (SP)+ ; RESTORE STACK POINTER
010524 017703 172302          MOV     @SRO, R3       ; SAVE CURRENT SRO
010530 005077 172276          CLR     @SRO          ; TURN OFF KT11-C
010534 022703 040003          CMP     #40003, R3     ; CK SAVED SRO
010540 001401          BEQ     .+4
010542 104006          HLT                      ; CONTENTS OF SRO INCORRECT AFTER
                                ; PAGE LENGTH ERROR ABORT
                                ; CHECK SRO TO BE SURE PL BIT CLEARED

010544 022777 000002 172260  CMP     #2, @SRO
010552 001401          BEQ     .+4
010554 104006          HLT
010556 162701 000100          CONT24: SUB #100, R1
                                ; SRO INCORRECT AFTER CLEARING IT
                                ; SETUP R1 TO REFERENCE POUNDARY
                                ; OF NEXT PAGE DOWN
010562 162702 000400          SUB     #400, R2       ; INCREASE ALLOWED PAGE LENGTH
                                ; (DOWN) BY 1 PAGE

```

010566	000722			BR	LOOP24	:CHECK NEXT PAGE LENGTH VALUE
010570	005077	172236		CLR	2SR0	:TURN OFF KT11-C
010574	016777	172612	172606	MOV	KTSTA,2KTVEC	:RESTORE MEMORY MANAGEMENT ABORT RETURN
010602	005077	172604		CLR	2KTSTA	:TO CAUSE A HALT ON A FALSE TRAP
						:OR ABORT
						:TEST ALL COMBINATIONS OF VALUES FOR THE PAGE LENGTH COMPARATORS-
						:USE KERNEL I-SPACE PAGE 1
010606	104400			TEST25:	SCOPE	
010610	012737	000025	177570	MOV	225,22SR	:DISPLAY TEST NUMBER
010616	005037	177776		CLR	22PS	:INITIALIZE PROCESSOR STATUS
010622	012706	001000		MOV	2KSTACK,SP	:INITIALIZE KERNEL STACK POINTER
010626	005077	172214		CLR	2SR0	:INITIALIZE SR3
010632	005077	172174		CLR	2SR0	:INITIALIZE SR0
010636	026727	172556	000025	CMP	TESTCT,225	:IS THIS TEST BEING EXECUTED IN THE
010644	001401			BEQ	.+4	:CORRECT SEQUENCE? - BRANCH IF YES
010646	104006			HLT		:TEST EXECUTED OUT OF ORDER - TESTCT
						:CONTAINS NUMBER OF PREVIOUS TEST PLUS ONE
010650	012767	000020	004326	MOV	220,ICOUNT	:DROP ITERATION COUNT
010656	004767	003662		JSR	27,RWALL	:INITIALIZE ALL PAGES RW, BANK 0
010662	012777	007600	172440	MOV	27600,2KIPAR7	:MAP KERNEL PAGE 7 EXTERNAL
010670	012777	011000	172512	MOV	2RET25,2KTVEC	:SETUP ABORT RETURN
010676	005077	172510		CLR	2KTSTA	
010702	012701	000006		MOV	26,R1	:R1 CONTAINS THE VALUE TO BE
						:LOADED INTO THE PDR
010706	012777	000001	172116	MOV	21,2SR0	:TURN ON KT11-C
010714	012703	020000		L25A: MOV	220000,R3	:R3 CONTAINS VA USED TO REFERENCE PAGE 1
010720	010177	172330		MOV	R1,2KIPDR1	:LOAD NEW PAGE LENGTH FIELD
010724	010102			L25B: MOV	R1,R2	:R2 IS A COPY OF R1 USED FOR CALCULATIONS
010726	010304			MOV	R3,R4	:R4 IS A COPY OF R3 USED FOR CALCULATIONS
010730	042704	160000		BIC	2160000,R4	:CLEAR ALL BUT ADDRESS OFFSET IN R4
010734	005713			TST	(R3)	:USE VA IN R3 TO REFERENCE PAGE 1
010736	000302			SWAB	R2	:NO TRAP-CHECK TO MAKE SURE
010740	042702	177400		BIC	2177400,R2	:THAT THE ADDRESS REFERENCED WAS
010744	072427	177772		ASH	2-6,R4	:WITHIN THE ALLOWED PAGE LENGTH
010750	020402			CMP	R4,R2	
010752	003401			BLE	.+4	
010754	104006			HLT		:REFERENCE OUTSIDE ALLOWED PAGE LENGTH
						:DIDN'T ABORT - R3 CONTAINS VA USED
010756	062703	000100		C25: ADD	2100,R3	:R1 CONTAINS VALUE LOADED INTO THE PDR
010762	020327	037776		CMP	R3,237776	:CHANGE R3 TO REFERENCE NEXT BLOCK
010766	003756			BLE	L25B	:CHECK FOR ALL BLOCKS REFERENCED
010770	062701	000400		ADD	2400,R1	:BRANCH IF NOT
						:INCREMENT VALUE TO BE LOADED INTO
						:THE PAGE LENGTH FIELD
010774	100347			BPL	L25A	:BRANCH IF NOT DONE
010776	000412			BR	DONE25	:EXIT
011000	022626			RET25: CMP	(SP)+,(SP)+	:RESTORE STACK POINTER
011002	000302			SWAB	R2	:CHECK TO MAKE SURE VIRTUAL
011004	042702	177400		BIC	2177400,R2	:ADDRESS WAS OUTSIDE ALLOWED
011010	072427	177772		ASH	2-6,R4	:PAGE LENGTH
011014	020402			CMP	R4,R2	
011016	003001			BGT	.+4	
011020	104006			HLT		:REFERENCE WITHIN ALLOWED
011022	000755			BR	C25	:PAGE LENGTH ABORTED-R3 CONTAINS

```

011024 016777 172362 172356 DONE25: MOV      KTSTA, @KTEC
011032 005077 171774          CLR      @SR0
;VA USED, R1 CONTAINS VALUE
;LOADED INTO THE PDR
;RESTORE TRAP CATCHER
;TURN OFF KT11-C

;SHOW THAT THE W BIT DOESN'T SET IF THE KT11-C IS OFF
011036 104400          TEST26: SCOPE
011040 012737 000026 177570      MOV      #26, @SR
011046 005037 177776          CLR      @PS
011052 012706 001000          MOV      @KSTACK, SP
011056 005077 171764          CLR      @SR3
011062 005077 171744          CLR      @SR0
011066 026727 172326 000026      CMP      TESTCT, #26
011074 001401          BEQ     .+4
011076 104006          HLT

;DISPLAY TEST NUMBER
;INITIALIZE PROCESSOR STATUS
;INITIALIZE KERNEL STACK POINTER
;INITIALIZE SR3
;INITIALIZE SR0
;IS THIS TEST BEING EXECUTED IN THE
;CORRECT SEQUENCE? - BRANCH IF YES
;TEST EXECUTED OUT OF ORDER - TESTCT
;CONTAINS NUMBER OF PREVIOUS TEST PLUS ONE

011100 012767 002000 004076      MOV      #2000, ICOUNT
011106 004767 003402          JSR     %7, CLALL
011112 013737 010000 010000      MOV      @#10000, @#10000
011120 005777 172126          TST     @KIPDR0
011124 001401          BEQ     .+4
011126 104006          HLT

;RESTORE ITERATION COUNT
;CLEAR ALL KT11-C REGISTERS
;WRITE BANK 0
;CHECK CORRESPONDING PDR
;W BIT SET OR ANOTHER BIT INCORRECT
;IN KERNEL I-SPACE 0 PDR

;SHOW THAT THE W BIT IS CLEARED BY WRITING (VIA DATO) THE CORRESPONDING PAR
;CHECK EACH PDR
011130 104400          TEST27: SCOPE
011132 012737 000027 177570      MOV      #27, @SR
011140 005037 177776          CLR      @PS
011144 012706 001000          MOV      @KSTACK, SP
011150 005077 171672          CLR      @SR3
011154 005077 171652          CLR      @SR0
011160 026727 172234 000027      CMP      TESTCT, #27
011166 001401          BEQ     .+4
011170 104006          HLT

;DISPLAY TEST NUMBER
;INITIALIZE PROCESSOR STATUS
;INITIALIZE KERNEL STACK POINTER
;INITIALIZE SR3
;INITIALIZE SR0
;IS THIS TEST BEING EXECUTED IN THE
;CORRECT SEQUENCE? - BRANCH IF YES
;TEST EXECUTED OUT OF ORDER - TESTCT
;CONTAINS NUMBER OF PREVIOUS TEST PLUS ONE:

011172 004767 003346          JSR     %7, RWALL
011176 012777 000007 171642      MOV      #7, @SR3
011204 012777 007600 172136      MOV      #7600, @KDPAR7
011212 012777 007600 172030      MOV      #7600, @SDPAR7
011220 012777 007600 171722      MOV      #7600, @UDPAR7
011226 012737 040000 177776      MOV      #40000, @PS
011234 012706 002000          MOV      @SSTACK, R6
011240 012737 140000 177776      MOV      #140000, @PS
011246 012706 003000          MOV      @USTACK, R6
011252 012700 003366          MOV      @STATAB, R0
011256 012001          LOP27: MOV      (R0)+, R1

;INITIALLY MAP ALL PAGES RW, 4K, BANK 0
;ENABLE ALL D-SPACES
;MAP D-SPACE 7, ALL MODES,
;TO THE EXTERNAL BANK

;SET MODE TO SUPERVISOR
;SETUP SUPERVISOR STACK POINTER
;SET MODE TO USER
;SETUP USER STACK POINTER
;POINT R0 TO THE TABLE OF MODE INFORMATION
;POINT R1 TO THE ADDRESS OF
;THE CURRENT I-SPACE PDR
;R2 CONTAINS VIRTUAL ADDRESS TO
;REFERENCE DESIRED PAGE
;SETUP STATUS FOR CURRENT MODE
;TURN ON KT11-C
;CHANGE CURRENT PC TO REFERENCE
;DESIRED PAGE

011260 012702 011276          MOV      @ADR27A, R2

011264 012037 177776          MOV      (R0)+, @PS
011270 005277 171536          LOP27A: INC      @SR0
011274 010207          MOV      R2, PC
    
```

```

011276 005027 000000      ADR27A: CLR      #0      ;WRITE I-SPACE
011302 042707 160000      BIC      #160000,PC ;CHANGE TO PAGE 0 PC
011306 005077 171520      CLR      @SR0      ;TURN OFF KT11-C
011312 004767 000056      JSR      %7,CKWBIT ;TEST W BIT
011316 005721      TST      (R1)+      ;MOVE POINTER
011320 062702 020000      ADD      #20000,R2  ;CHANGE VA TO REFERENCE NEXT PAGE
011324 103361      BCC      LOP27A     ;LOOP UNTIL ALL I-SPACE PDR'S HAVE BEEN
                                ;CHECKED IN THE CURRENT MODE
011326 012702 017776      MOV      #17776,R2  ;SETUP R2 TO REFERENCE DESIRED PAGE
011332 005277 171474      LOP27B: INC      @SR0      ;TURN ON KT11-C
011336 011212      MOV      (R2),(R2) ;WRITE IN D-SPACE
011340 005077 171456      CLR      @SR0      ;TURN OFF KT11-C
011344 004767 000024      JSR      %7,CKWBIT ;TEST W BIT
011350 005721      TST      (R1)+      ;MOVE POINTER
011352 062702 020000      ADD      #20000,R2  ;CHANGE VA TO REFERENCE NEXT PAGE
011356 103365      BCC      LOP27B     ;LOOP UNTIL ALL D-SPACE PDR'S HAVE BEEN
                                ;CHECKED IN THE CURRENT MODE
011360 020027 003400      CMP      R0,#STAEND ;HAVE ALL MODES BEEN TESTED?
011364 002734      BLT      LOP27      ;NO BRANCH
011366 005077 171454      CLR      @SR3      ;YES CLEAR ALL D-SPACE ENABLES
011372 000415      BR      TEST30     ;EXIT
011374 032771 000100 000000  CKWBIT: BIT      #100,@(R1) ;CHECK W BIT
011402 001001      BNE      .+4
011404 104006      HLT
                                ;W BIT DIDN'T SET IN PDR WHOSE
                                ;ADDRESS IS POINTED TO BY R1
011406 005071 000040      CLR      @40(R1)   ;CLEAR W BIT BY WRITING CORRESPONDING
                                ;PAR VIA DAT0
011412 032771 000100 000000  BIT      #100,@(R1) ;CHECK W BIT
011420 001401      BEQ      .+4
011422 104006      HLT
                                ;W BIT DIDN'T CLEAR IN PDR WHOSE
                                ;ADDRESS IS POINTED TO BY R1
011424 000207      RTS      %7

;SHOW THAT THE W BIT IS CLEARED BY A DATOB TO THE PDR
;CHECK BOTH HIGH AND LOW DATOB'S, ON KERNEL 0 I-SPACE ONLY
011426 104400      TEST30: SCOPE
011430 012737 000030 177570      MOV      #30,@#SR  ;DISPLAY TEST NUMBER
011436 005037 177776      CLR      @#PS      ;INITIALIZE PROCESSOR STATUS
011442 012706 001000      MOV      #KSTACK,SP ;INITIALIZE KERNEL STACK POINTER
011446 005077 171374      CLR      @SR3      ;INITIALIZE SR3
011452 005077 171354      CLR      @SR0      ;INITIALIZE SR0
011456 026727 171736 000030      CMP      TESTCT,#30 ;IS THIS TEST BEING EXECUTED IN THE
011464 001401      BEQ      .+4      ;CORRECT SEQUENCE? - BRANCH IF YES
011466 104006      HLT              ;TEST EXECUTED OUT OF ORDER - TESTCT
                                ;CONTAINS NUMBER OF PREVIOUS TEST PLUS ONE
011470 004767 003050      JSR      %7,RWALL   ;MAP ALL PAGES 4K, RW, BANK 0
011474 012777 007600 171626      MOV      #7600,@KIPAR7 ;MAP KERNEL 7 TO THE EXTERNAL BANK
011502 005277 171324      INC      @SR0      ;TURN ON KT11-C
011506 013737 000000 000000      MOV      @#0,@#0   ;WRITE INTO PAGE 0
011514 005077 171312      CLR      @SR0      ;TURN OFF KT11-C
011520 032777 000100 171524      BIT      #100,@KIPDR0 ;CHECK W BIT
011526 001001      BNE      .+4
011530 104006      HLT
                                ;W BIT NOT SET AFTER WRITING PAGE 0
011532 112777 000106 171512      MOV      #106,@KIPDR0 ;DATOB SHOULD CLEAR W BIT
011540 032777 030100 171504      BIT      #100,@KIPDR0

```


011546	001401			BEQ	.+4			
011550	104006			HLT			; W BIT DIDN'T CLEAR VIA DATOB (LOW) ; TO THE PDR	
011552	005277	171254		INC	2SR0		; TURN ON KT11-C	
011556	013737	017776	017776	MOV	2#17776,2#17776		; WRITE INTO PAGE 0 AGAIN	
011564	005077	171242		CLR	2SR0		; TURN OFF KT11-C	
011570	032777	000100	171454	BIT	#100,2KIPDR0		; CHECK W BIT	
011576	001001			BNE	.+4			
011600	104006			HLT			; W BIT NOT SET AFTER WRITING PAGE 0	
011602	016701	171444		MOV	KIPDR0,R1		; SETUP R1 TO REFERENCE HIGH BYTE	
011606	005201			INC	R1		; OF KIPDR0	
011610	112711	000177		MOVB	#177,2R1		; DATOB TO HIGH BYTE OF KIPDR0	
011614	032777	000100	171430	BIT	#100,2KIPDR0		; CHECK W BIT	
011622	001401			BEQ	.+4			
011624	104006			HLT			; W BIT DIDN'T CLEAR VIA DATOB ; TO HIGH BYTE OF PDR	
; SHOW THAT THE W BIT IS CLEARED BY A DATOB TO THE PAR								
; CHECK BOTH HIGH AND LOW DATOB'S, ON KERNEL 0 I-SPACE ONLY								
011626	104400			TEST31: SCOPE				
011630	012737	000031	177570	MOV	#31,2#SR		; DISPLAY TEST NUMBER	
011636	005037	177776		CLR	2#PS		; INITIALIZE PROCESSOR STATUS	
011642	012706	001000		MOV	#KSTACK,SP		; INITIALIZE KERNEL STACK POINTER	
011646	005077	171174		CLR	2SR3		; INITIALIZE SR3	
011652	005077	171154		CLR	2SR0		; INITIALIZE SR0	
011656	026727	171536	000031	CMP	TESTCT,#31		; IS THIS TEST BEING EXECUTED IN THE	
011664	001401			BEQ	.+4		; CORRECT SEQUENCE? - BRANCH IF YES	
011666	104006			HLT			; TEST EXECUTED OUT OF ORDER - TESTCT ; CONTAINS NUMBER OF PREVIOUS TEST PLUS ONE	
011670	004767	002650		JSR	%7,RWALL		; MAP ALL PAGES 4K RW BANK 0	
011674	012777	007600	171426	MOV	#7600,2KIPAR7		; MAP KERNEL 7 TO THE EXTERNAL BANK	
011702	005277	171124		INC	2SR0		; TURN ON KT11-C	
011706	013737	000000	000000	MOV	2#0,2#0		; WRITE INTO PAGE 0	
011714	005077	171112		CLR	2SR0		; TURN OFF KT11-C	
011720	032777	000100	171324	BIT	#100,2KIPDR0		; CHECK W BIT	
011726	001001			BNE	.+4			
011730	104006			HLT			; W BIT NOT SET AFTER WRITING PAGE 0	
011732	112777	000000	171352	MOVB	#0,2KIPAR0		; DATOB TO THE PAR	
011740	032777	000100	171304	BIT	#100,2KIPDR0		; CHECK W BIT	
011746	001401			BEQ	.+4			
011750	104006			HLT			; W BIT DIDN'T CLEAR VIA DATOB ; (LOW) TO THE PAR	
011752	005277	171054		INC	2SR0		; TURN ON KT11-C	
011756	013737	017776	017776	MOV	2#17776,2#17776		; WRITE INTO PAGE 0 AGAIN	
011764	005077	171042		CLR	2SR0		; TURN OFF KT11-C	
011770	032777	000100	171254	BIT	#100,2KIPDR0		; CHECK W BIT	
011776	001001			BNE	.+4			
012000	104006			HLT			; W BIT NOT SET AFTER WRITING PAGE 0	
012002	016701	171304		MOV	KIPAR0,R1		; SETUP R1 TO REFERENCE HIGH BYTE	
012006	005201			INC	R1		; OF KIPAR0	
012010	112711	000000		MOVB	#0,2R1		; DATOB TO HIGH BYTE OF KIPAR0	
012014	032777	000100	171230	BIT	#100,2KIPDR0		; CHECK W BIT	
012022	001401			BEQ	.+4			
012024	104006			HLT			; W BIT DIDN'T CLEAR VIA DATOB ; TO HIGH BYTE OF PAR	


```

012262 005721          TST      (R1)+          ;MOVE POINTER
012264 077207          SOB      R2,LOP32E      ;CHECK ALL PDR'S IN THIS SET
012266 062701 000040    AOD      #40,R1        ;CHANGE R1 TO REFERENCE NEXT
                                ;SET OF PDR ADDRESSES
012272 020127 003350    CMP      R1,#ADREND     ;CHECK FOR DONE
012276 002762          BLT      LOP32D         ;IF NOT, CHECK NEXT SET OF PDR'S
012300 005037 177776    CLR      @#PS          ;SET MODE TO KERNEL
012304 005277 170522    INC      @SR0         ;TURN KTI1-C ON
012310 105777 170502    TSTB    @TCSR        ;WAIT FOR ANY TTY OUTPUT TO FINISH
012314 100375          BPL      .-4
012316 000005          RESET
012320 000005          RESET
012322 012701 003052    MOV      #ADRTAB,R1    ;INIT WITH KTI1-C ON
012326 012702 000020    LOP32F: MOV     #20,R2  ;INIT WITH KTI1-C OFF
                                ;R1 REFERENCES ADDRESS OF PDR
                                ;R2 KEEPS TRACK OF WHEN TO CHANGE
                                ;REGISTER SETS
012332 032771 000100 000000 LOP32G: BIT     #100,@(R1) ;CHECK W BIT
012340 001001          BNE      .+4
012342 104006          HLT
                                ;INIT CLEARED W BIT IN PDR WHOSE
                                ;ADDRESS IS POINTED TO BY R1
012344 005721          TST      (R1)+          ;MOVE POINTER
012346 077207          SOB      R2,LOP32E      ;CHECK ALL PDR'S IN THIS SET
012350 062701 000040    AOD      #40,R1        ;CHANGE R1 TO REFERENCE NEXT SET
                                ;OF PDR ADDRESSES
012354 020127 003350    CMP      R1,#ADREND     ;CHECK FOR DONE
012360 002762          BLT      LOP32F         ;IF NOT, CHECK NEXT SET OF PDR'S
012362 005077 170444    CLR      @SR0         ;REINITIALIZE SR0, SR3
012366 005077 170454    CLR      @SR3

;SHOW THAT EACH "A" BIT IN THE I-SPACE PDR'S CAN BE SET BY REFERENCING
;THE CORRESPONDING PAGE MAPPED READ WRITE AND TRAP ON WRITE WITHOUT
;MEMORY MANAGEMENT ENABLE SET
;SHOW THAT ONLY ONE "A" BIT SETS ON EACH REFERENCE
;SHOW THAT EACH "A" BIT IN THE I-SPACE PDR'S IS CLEARED BY A DATO TO THE PDR,
;AND BY A DATO TO THE CORRESPONDING PAR
012372 104400          TEST33: SCOPE
012374 012737 060033 177570    MOV      #33,@#SR
012402 005037 177776    CLR      @#PS
012406 012706 001000    MOV      #KSTACK,SP
012412 005077 170430    CLR      @SR3
012416 005077 170410    CLR      @SR0
012422 026727 170772 000033    CMP      TESTCT,#33
012430 001401          BEQ      .+4
012432 104006          HLT
                                ;DISPLAY TEST NUMBER
                                ;INITIALIZE PROCESSOR STATUS
                                ;INITIALIZE KERNEL STACK POINTER
                                ;INITIALIZE SR3
                                ;INITIALIZE SR0
                                ;IS THIS TEST BEING EXECUTED IN THE
                                ;CORRECT SEQUENCE? - BRANCH IF YES
                                ;TEST EXECUTED OUT OF ORDER - TESTCT
                                ;CONTAINS NUMBER OF PREVIOUS TEST PLUS ONE
012434 004767 002252          JSR      %7,RWTWAL
                                ;MAP ALL PAGES 4K, RWTW
                                ;MAP ALL EXCEPT D-SPACE 7 (ALL MODES)
                                ;TO BANK 0 - MAP D-SPACE 7 (ALL MODES)
                                ;TO EXTERNAL BANK
012440 012737 040000 177776    MOV      #40000,@#PS
012446 012706 002000    MOV      #SSTACK,R6
012452 012737 140000 177776    MOV      #140000,@#PS
012460 012706 003000    MOV      #ISTACK,R6
012464 012777 000007 170354    MOV      #7,@SR3
012472 012700 003366    MOV      #STATAB,R0
012476 012001          LOP33A: MOV     (R0)+,R1 ;R1 POINTS TO ADDRESS OF PDR BEING TESTED

```

012500	012037	177776		MOV	(R0)+,2#PS	;SET STATUS TO REFERENCE DESIRED MODE
012504	012702	012522		MOV	#ADR33A,R2	;R2 AND R3 CONTAIN VIRTUAL ADDRESSES
012510	012703	012642		MOV	#ADR33B,R3	;USED TO REFERENCE CURRENT PAGE
012514	005277	170312		LOP33B: INC	2SR0	;TURN ON KT11-C
012520	010207			MOV	R2,PC	;CHANGE ADDRESS TO REFERENCE DESIRED PAGE
012522	005027	000000		ADR33A: CLR	#0	;WRITE IN I-SPACE
012526	042707	160000		BIC	#160000,PC	;CHANGE TO BANK 0 ADDRESS
012532	005077	170274		CLR	2SR0	;TURN OFF KT11-C
012536	032771	000200	000000	BIT	#200,2(R1)	;CHECK "A" BIT
012544	001001			BNE	.+4	
012546	104006			HLT		; "A" BIT NOT SET IN PDR WHOSE ADDRESS IS POINTED TO ; BY R1, AFTER WRITING CORRESPONDING PAGE ; MAPPED RMTW
012550	012704	003052		MOV	#ADRTAB,R4	;SETUP TO CHECK ALL OTHER "A" BITS
012554	012705	000020		LOP33C: MOV	#20,R5	;R5 KEEPS TRACK OF WHEN TO CHANGE REGISTER SETS
012560	020104			LOP33D: CMP	R1,R4	;DON'T CHECK IF ITS THE PDR BEING
012562	001405			BEQ	CNT33A	;TESTED
012564	032774	000200	000000	BIT	#200,2(R4)	;OTHERWISE MAKE SURE THE "A" BIT DIDN'T SET
012572	001401			BEQ	.+4	
012574	104006			HLT		; THE "A" BIT WAS SET IN THE PDR WHOSE ; ADDRESS IS POINTED TO BY R4, WITHOUT THE ; CORRESPONDING PAGE HAVING BEEN REFERENCED ; R2 CONTAINS THE ADDRESS THAT WAS REFERENCED ; MOVE POINTER
012576	005724			CNT33A: TST	(R4)+	
012600	077511			SQB	R5,LOP33D	;CHECK ALL PDR'S IN THIS SET
012602	062704	000040		ADD	#40,R4	;CHANGE ADDRESS TO REFERENCE NEXT SET OF PDR'S
012606	020427	003350		CMP	R4,#ADREND	;HAVE ALL REGISTERS BEEN CHECKED?
012612	002760			BLT	LOP33C	;NO-BRANCH
012614	012771	077605	000000	MOV	#77605,2(R1)	;YES-CLEAR "A" BIT BY DATO TO PDR
012622	032771	000200	000000	BIT	#200,2(R1)	;CHECK THE "A" BIT
012630	001401			BEQ	.+4	
012632	104006			HLT		; DATO TO PDR WHOSE ADDRESS IS POINTED ; TO BY R1 DIDN'T CLEAR THE A BIT ; TURN ON KT11-C ; SET "A" BIT AGAIN
012634	005277	170172		INC	2SR0	
012640	010307			MOV	R3,PC	
012642	005027	000000		ADR33B: CLR	#0	
012646	042707	160000		BIC	#160000,PC	
012652	005077	170154		CLR	2SR0	;TURN OFF KT11-C
012656	032771	000200	000000	BIT	#200,2(R1)	;CHECK THE "A" BIT
012664	001001			BNE	.+4	
012666	104006			HLT		; A BIT NOT SET AFTER WRITING I-SPACE ; PAGE WHOSE ADDRESS IS POINTED TO BY R1- ; MAPPED RMTW
012670	017171	000040	000040	MOV	240(R1),240(R1)	;CLEAR "A" BIT BY DATO TO PAR
012676	032771	000200	000000	BIT	#200,2(R1)	;CHECK THE "A" BIT
012704	001401			BEQ	.+4	
012706	104006			HLT		; DATO TO CORRESPONDING PAR DIDN'T CLEAR "A" BIT ; IN PDR WHOSE ADDRESS IS POINTED TO BY R1 ; MOVE POINTER
012710	005721			TST	(R1)+	
012712	062702	020000		ADD	#20000,R2	;CHANGE VIRTUAL ADDRESSES TO REFERENCE
012716	062703	020000		ADD	#20000,R3	;NEXT PAGE
012722	103274			BCC	LOP33B	;CHECK ALL I-SPACE PDR'S IN THIS MODE
012724	020067	170450		CMP	RD,STAEND	
012730	002662			BLT	LOP33A	;CHECK ALL 3 MODES
012732	005077	170110		CLR	2SR3	;CLEAR ALL D-SPACE ENABLES

```

: SHOW THAT EACH "A" BIT IN THE D-SPACE PDR'S CAN BE SET BY REFERENCING
: THE CORRESPONDING PAGE MAPPED READ WRITE AND TRAP ON WRITE
: WITHOUT MEMORY MANAGEMENT ENABLE SET
: SHOW THAT EACH "A" BIT IN THE D-SPACE PDR'S CAN BE CLEARED BY A DATO TO
: THE PDR, AND BY A DATO TO THE CORRESPONDING PAR
012736 104400
012740 012737 000034 177570
012746 005037 177776
012752 012706 001000
012756 005077 170064
012762 005077 170044
012766 026727 170426 000034
012774 001401
012776 104006
TEST34: SCOPE
MOV #34, @#SR ; DISPLAY TEST NUMBER
CLR @#PS ; INITIALIZE PROCESSOR STATUS
MOV #KSTACK, SP ; INITIALIZE KERNEL STACK POINTER
CLR @SR3 ; INITIALIZE SR3
CLR @SR0 ; INITIALIZE SR0
CMP TESTCT, #34 ; IS THIS TEST BEING EXECUTED IN THE
BEQ .+4 ; CORRECT SEQUENCE? - BRANCH IF YES
HLT ; TEST EXECUTED OUT OF ORDER - TESTCT
; CONTAINS NUMBER OF PREVIOUS TEST PLUS ONE

013000 004767 001706 JSR %7, RWTWAL ; MAP ALL PAGES 4K, RWTW, BANK 0
; EXCEPT D-SPACE 7, MAPPED TO THE
; EXTERNAL BANK
013004 012737 040000 177776 MOV #40000, @#PS ; SET MODE TO SUPERVISOR
013012 012706 002000 MOV #SSTACK, R6 ; SET UP SUPERVISOR STACK POINTER
013016 012737 140000 177776 MOV #140000, @#PS ; SET MODE TO USER
013024 012706 003000 MOV #USTACK, R6 ; SET UP USER STACK POINTER
013030 012777 000007 170010 MOV #7, @SR3 ; ENABLE ALL D-SPACES
013036 012700 003366 MOV #STATAB, R0 ; R0 POINTS TO TABLE OF MODE INFORMATION
LOP34A: MOV (R0)+, R1 ; R1 POINTS TO ADDRESS OF PDR BEING
; TESTED
013042 012001 ADD #20, R1 ; SETUP MODE TO BE TESTED
013044 062701 000020 MOV (R0)+, @#PS ; USE R2 TO REFERENCE PAGE TO SET THE A BIT
013050 012037 177776 MOV #17776, R2 ; TURN ON KT11-C
013054 012702 017776 LOP34B: INC @SR0 ; WRITE IN D-SPACE PAGE TO SET "A" BIT
013060 005277 167746 MOV @R2, @R2 ; TURN OFF KT11-C
013064 011212 CLR @SR0 ; CHECK THE "A" BIT
013066 005077 167740 BIT #200, @ (R1) ; "A" BIT NOT SET AFTER WRITING D-SPACE
013072 032771 000200 000000 BNE .+4 ; PAGE MAPPED RWTW
013100 001001 HLT ; ADDRESS REFERENCED IS IN R2
013102 104006 ; CLEAR "A" BIT BY DATO TO PDR
; CHECK THE "A" BIT

013104 017171 000000 000000 MOV @ (R1), @ (R1) ; DATO TO PDR DIDN'T CLEAR "A" BIT -
013112 032771 000200 000000 BIT #200, @ (R1) ; PDR ADDRESS IS POINTED TO BY R1
013120 001401 BEQ .+4 ; TURN ON KT11-C
013122 104006 HLT ; SET "A" BIT AGAIN
; TURN OFF KT11-C
; CHECK "A" BIT

013124 005277 167702 INC @SR0 ; "A" BIT NOT SET AFTER WRITING D-SPACE
013130 011212 MOV @R2, @R2 ; PAGE MAPPED RWTW
013132 005077 167674 CLR @SR0 ; ADDRESS REFERENCED IS IN R2
013136 032771 000200 000000 BIT #200, @ (R1) ; CLEAR THE "A" BIT BY DATO TO PAR
013144 001001 BNE .+4 ; CHECK THE "A" BIT
013146 104006 HLT ; "A" BIT NOT SET AFTER WRITING D-SPACE
; PAGE MAPPED RWTW
; ADDRESS REFERENCED IS IN R2
; CLEAR THE "A" BIT BY DATO TO PAR
; CHECK THE "A" BIT

013150 017171 000040 000040 MOV @40 (R1), @40 (R1) ; DATO TO PAR DIDN'T CLEAR "A" BIT
013156 032771 000200 000000 BIT #200, @ (R1) ; IN CORRESPONDING PDR WHOSE ADDRESS IS POINTED TO BY R1
013164 001401 BEQ .+4 ; MOVE POINTER
013166 104006 HLT

013170 005721 TST (R1)+

```

```

013172 062702 020000      ADD      #20000,R2      ;CHANGE R2 TO REFERENCE NEXT PAGE
013176 103330      BCC     LOP348        ;CHECK ALL D-SPACE PDR'S IN THIS MODE
013200 020027 003400      CMP     R0,#STAEND
013204 002716      BLT     LOP34A
013206 005077 167634      CLR     @SR3          ;CHECK ALL 3 MODES
                                ;CHECK ALL D-SPACE ENABLES

;SHOW THAT THE A BIT IS CLEARED BY A DATOB TO THE PDR AND ALSO BY
;A DATOB TO THE CORRESPONDING PAR. CHECK BOTH HIGH AND LOW BYTES, ON
;KERNEL PAGE 1 I-SPACE
TEST35: SCOPE
013212 104400      MOV     @#35,@#SR      ;DISPLAY TEST NUMBER
013214 012737 000035 177570    CLR     @#PS          ;INITIALIZE PROCESSOR STATUS
013222 005037 177776      MOV     @#KSTACK,SP   ;INITIALIZE KERNEL STACK POINTER
013226 012706 001000      CLR     @SR3          ;INITIALIZE SR3
013232 005077 167610      CLR     @SR0          ;INITIALIZE SR0
013236 005077 167570      CMP     TESTCT,#35    ;IS THIS TEST BEING EXECUTED IN THE
013242 026727 170152 000035  BEQ     .+4           ;CORRECT SEQUENCE? - BRANCH IF YES
013250 001401      HLT
013252 104006

013254 004767 001264      JSR     %7,RWALL      ;MAP ALL PAGES 4K, RW, BANK 0
013260 012777 007600 170042    MOV     #7600,@KIPAR7 ;MAP KERNEL 7 TO THE EXTERNAL BANK
013266 012777 077404 167760    MOV     #77404,@KIPDR1 ;MAP KERNEL 1 RAWT
013274 005277 167532      INC     @SR0          ;TURN ON KT11-C
013300 005737 020000      TST     @#20000      ;SET THE A BIT
013304 005077 167522      CLR     @SR0          ;TURN OFF KT11-C
013310 032777 000200 167736    BIT     #200,@KIPDR1 ;MAKE SURE THAT THE A BIT SET
013316 001001      BNE     .+4
013320 104006      HLT
013322 117777 167726 167724    MOVB   @KIPDR1,@KIPDR1 ;THE A BIT DIDN'T SET IN KIPDR1
013330 032777 000200 167716    BIT     #200,@KIPDR1 ;DATOB TO THE LOW BYTE OF THE PDR
013336 001401      BEQ     .+4           ;CHECK THE A BIT
013340 104006      HLT
                                ;THE A BIT WASN'T CLEARED BY DATOB
                                ;TO THE LOW BYTE OF THE PDR
013342 005277 167464      INC     @SR0          ;TURN ON KT11-C
013346 005737 020000      TST     @#20000      ;SET THE A BIT AGAIN
013352 005077 167454      CLR     @SR0          ;TURN OFF KT11-C
013356 016701 167672      MOV     KIPDR1,R1    ;SETUP R1 TO REFERENCE HIGH BYTE
013362 005201      INC     R1            ;OF THE PDR
013364 111111      MOVB   @R1,@R1       ;DATOB TO HIGH BYTE OF PDR
013366 032777 000200 167660    BIT     #200,@KIPDR1 ;CHECK A BIT
013374 001401      BEQ     .+4
013376 104006      HLT
                                ;THE A BIT WASN'T CLEARED BY A
                                ;DATOB TO THE HIGH BYTE OF THE PDR
013400 005277 167426      INC     @SR0          ;TURN ON KT11-C
013404 005737 020000      TST     @#20000      ;SET THE A BIT AGAIN
013410 005077 167416      CLR     @SR0          ;TURN OFF KT11-C
013414 117777 167674 167672    MOVB   @KIPAR1,@KIPAR1 ;DATOB TO LOW BYTE OF THE PAR
013422 032777 000200 167624    BIT     #200,@KIPDR1 ;CHECK THE A BIT
013430 001401      BEQ     .+4
013432 104006      HLT
                                ;THE A BIT WASN'T CLEARED BY A DATOB
                                ;TO THE LOW BYTE OF THE PAR
013434 005277 167372      INC     @SR0          ;TURN ON KT11-C
013440 005737 020000      TST     @#20000      ;SET THE A BIT AGAIN
013444 005077 167362      CLR     @SR0          ;TURN OFF KT11-C
013450 016701 167640      MOV     KIPAR1,R1    ;SETUP R1 TO ADDRESS THE HIGH

```


K03

DCKTB-S MACY11 27(732) 01-OCT-76 13:14 PAGE 37
 DCKTB8.P11

```

013454 005201          INC      R1          ;BYTE OF THE PAR
013456 111111          MOV     @R1,@R1      ;DATAB TO HIGH BYTE OF PAR
013460 032777 000200 167566 BIT     @200,@KIPDR1
013466 001401          BEQ     .+4
013470 104006          HLT

;THE A BIT WAS NOT CLEARED BY A
;DATAB TO THE HIGH BYTE OF THE PAR

;SHOW THAT INIT DOESN'T CLEAR THE "A" BITS, WITH KT11-C ON OR OFF
;ALL "A" BITS ARE CHECKED
TEST36: SCOPE
013472 104400          MOV     #36,@#SR      ;DISPLAY TEST NUMBER
013474 012737 000036 177570 CLR     @#PS          ;INITIALIZE PROCESSOR STATUS
013502 005037 177776          MOV     #KSTACK,SP   ;INITIALIZE KERNEL STACK POINTER
013506 012706 001000          CLR     @SR3         ;INITIALIZE SR3
013512 005077 167330          CLR     @SR0         ;INITIALIZE SR0
013516 005077 167310          CMP     TESTCT,#36   ;IS THIS TEST BEING EXECUTED IN THE
013522 026727 167672 000036 BEQ     .+4          ;CORRECT SEQUENCE? - BRANCH IF YES
013530 001401          HLT                ;TEST EXECUTED OUT OF ORDER - TESTCT
013532 104006          ;CONTAINS NUMBER OF PREVIOUS TEST PLUS ONE

013534 004767 001152          JSR     %7,RWTWAL     ;MAKE ALL PAGES READ WRITE AND TRAP ON WRITE
013540 012777 007600 167602 MOV     #7600,@KDPAR7 ;MAP D-SPACE PAGE 7, ALL MODES,
013546 012777 007600 167474 MOV     #7600,@SDPAR7 ;TO THE EXTERNAL BANK
013554 012777 007600 167366 MOV     #7600,@UDPAR7
013562 012777 000007 167256 MOV     #7,@SR3
013570 012700 003366          MOV     #STATAB,R0   ;ENABLE ALL D-SPACES
013574 005720          TST     (R0)+         ;POINT R0 TO THE TABLE OF MODE INFORMATION
013576 012037 177776          MOV     (R0)+,@#PS   ;SET THE STATUS TO REFERENCE THE DESIRED SET OF
;REGISTERS
013602 012702 013616          MOV     #ADR36,R2    ;R2 REFERENCES THE DESIRED PAGE
013606 012777 000001 167216 MOV     #1,@SR0      ;TURN ON THE KT11-C
;CHANGE PC TO THE DESIRED PAGE
LOP36A: MOV     R2,PC
ADR36:  CLR     #0
;WRITE I-SPACE
;CHANGE R2 TO REFERENCE THE NEXT PAGE
013622 062702 020000          ADD     #20000,R2
013626 103372          BCC    LOP36A
;WRITE ALL I-SPACES IN THIS MODE
013630 042707 160000          BIC     #160000,PC   ;CHANGE TO BANK 0 PC
013634 012702 017776          MOV     #17776,R2   ;SETUP R2 TO REFERENCE THE FIRST D-SPACE PAGE
LOP36B: MOV     @R2,@R2
;WRITE INTO D-SPACE
;CHANGE R2 TO REFERENCE THE NEXT PAGE
013642 062702 020000          ADD     #20000,R2
013646 103374          BCC    LOP36B
;REFERENCE ALL PAGES IN THIS MODE
013650 005077 167156          CLR     @SR0
;TURN OFF KT11-C
013654 020027 003400          CMP     R0,#STAEND
013660 002745          BLT    LOOP36
;SET "A" BITS IN ALL MODES
013662 005037 177776          CLR     @#PS
;RETURN TO KERNEL
013666 005277 167140          INC     @SR0
;TURN ON KT11-C
013672 105777 167120          TSTB   @TCSR
;WAIT FOR ANY TTY OUTPUT TO FINISH
013676 100375          BPL    .-4
;ISSUE INIT WITH KT11-C ON
013700 000005          RESET
;ISSUE INIT WITH KT11-C OFF
013702 000005          RESET
;MAKE SURE KT11-C IS OFF
013704 005077 167122          CLR     @SR0
;R1 POINTS TO ADDRESS OF 1ST PDR
013710 012701 003052          MOV     #ADRTAB,R1
;R2 INDICATES WHEN TO CHANGE REGISTER SETS
LOP36C: MOV     #20,R2
013714 012702 000020          MOV     #20,R2
LOP36D: BIT     @200,@(R1)
013720 032771 000200 000000 BIT     @200,@(R1)
;CHECK THE "A" BIT
013726 001001          BNE    .+4
;OK IF STILL SET
013730 104006          HLT                ;RESET CLEARED "A" BIT IN
;PDR WHOSE ADDRESS IS

```

```

013732 005721          TST      (R1)+          ;POINTED TO BY R1
013734 077207          SOB      R2,LOP36D      ;MOVE POINTER
013736 062701 000040  ADD      #40,R1        ;CHECK ALL PDR'S IN THIS SET
013742 020127 003350  CMP      R1,#ADREND
013746 002762          BLT      LOP36C        ;CHECK ALL 3 SETS
013750 005077 167072  CLR      @SR3         ;DISABLE ALL D-SPACES

;SHOW THAT A DATO TO A PDR WILL CLEAR THE A AND W BITS
;EVEN WHEN THE INSTRUCTION ALSO CAUSES A TRAP REFERENCE TO
;THE CORRESPONDING PAGE
;MAP KERNEL PAGE 1 RRWT AND MAKE A WRITE ACCESS TO PAGE 1
;TO SET THE A AND W BITS
;THEN LOAD THE PDR, MAKING A TRAP REFERENCE TO PAGE 1 IN THE SOURCE
;FETCH OF THE SAME INSTRUCTION-THE A AND W BITS SHOULD BE CLEARED DUE
;TO THE DATO TO THE PDR
TEST37: SCOPE
013754 104400          MOV      #37,@#SR      ;DISPLAY TEST NUMBER
013756 012737 000037 177570  CLR      @#PS         ;INITIALIZE PROCESSOR STATUS
013764 005037 177776          MOV      #KSTACK,SP   ;INITIALIZE KERNEL STACK POINTER
013770 012706 001000          CLR      @SR3        ;INITIALIZE SR3
013774 005077 167046          CLR      @SRO        ;INITIALIZE SRO
014000 005077 167026          CMP      TESTCT,#37   ;IS THIS TEST BEING EXECUTED IN THE
014004 026727 167410 000037  BEQ      .+4         ;CORRECT SEQUENCE? - BRANCH IF YES
014012 001401          HLT
014014 104006          ;TEST EXECUTED OUT OF ORDER - TESTCT
;CONTAINS NUMBER OF PREVIOUS TEST PLUS ONE

014016 004767 000522          JSR      %7,RWALL     ;INITIALIZE ALL PAGES RW, BANK 0
014022 012777 007600 167300  MOV      #7600,@KIPAR7 ;MAP KERNEL PAGE 7 TO THE EXTERNAL BANK
014030 012777 077404 167216  MOV      #77404,@KIPDR1 ;MAKE KERNEL PAGE 1 RRWT
014036 012777 000001 166766  MOV      #1,@SRO      ;TURN ON KT11-C
014044 013737 020000 020000  MOV      @#20000,@#20000 ;READ AND WRITE PAGE 1
014052 022777 077704 167174  CMP      #77704,@KIPDR1 ;CHECK PDR OF PAGE 1
014060 001401          BEQ      .+4
014062 104006          HLT
;KERNEL I-SPACE PAGE 1 PDR
;INCORRECT - A AND W BITS SHOULD
;BE SET DUE TO PREVIOUS MOVE INSTRUCTION
014064 012767 077704 166730  MOV      #77704,TEMP   ;LOAD TEMP WITH VALUE TO BE MOVED TO KIPDR1
014072 016777 006724 167154  MOV      TEMP+20000,@KIPDR1 ;PAGE 1 REFERENCE SHOULD SET
;THE A BIT, BUT DATO TO THE PDR CLEARS A AND W BITS
014100 022777 077404 167146  CMP      #77404,@KIPDR1 ;CHECK PAGE 1 PDR
014106 001401          BEQ      .+4
014110 104006          HLT
014112 005077 166714          CLR      @SRO        ;PDR INCORRECT - A AND W BITS
;SHOULD HAVE BEEN CLEARED

;CHECK TO SEE THAT MULTIPLE ACCESSES TO A PAGE AFTER SETTING THE
;A AND W BITS DON'T CLEAR THE A AND W BITS
TEST40: SCOPE
014116 104400          MOV      #40,@#SR     ;DISPLAY TEST NUMBER
014120 012737 000040 177570  CLR      @#PS         ;INITIALIZE PROCESSOR STATUS
014126 005037 177776          MOV      #KSTACK,SP   ;INITIALIZE KERNEL STACK POINTER
014132 012706 001000          CLR      @SR3        ;INITIALIZE SR3
014136 005077 166704          CLR      @SRO        ;INITIALIZE SRO
014142 005077 166664          CMP      TESTCT,#40   ;IS THIS TEST BEING EXECUTED IN THE
014146 026727 167246 000040  BEQ      .+4         ;CORRECT SEQUENCE? - BRANCH IF YES
014154 001401          HLT
014156 104006          ;TEST EXECUTED OUT OF ORDER - TESTCT

```

```

;CONTAINS NUMBER OF PREVIOUS TEST PLUS ONE
014160 012767 000010 001016      MOV      #10,ICOUNT      ;DROP ITERATION COUNT
014166 004767 000352             JSR      %7,RWALL      ;INITIALIZE ALL PAGES 4K, RW, BANK 0
014172 012777 007600 167130      MOV      #7600,@KIPAR7 ;MAP KERNEL PAGE 7 TO THE EXTERNAL BANK
014200 012777 077405 167046      MOV      #77405,@KIPDR1 ;MAP KERNEL PAGE 1 RRWTW
014206 012777 000001 166616      MOV      #1,@SR0       ;TURN ON KT11-C
014214 013737 020000 020000      MOV      @#20000,@#20000 ;READ AND WRITE PAGE 1
014222 022777 077705 167024      CMP      #77705,@KIPDR1 ;CHECK THE PDR
014230 001401             BEQ      .+4
014232 104006             HLT

;KERNEL I-SPACE PDR1 INCORRECT
;A AND W BITS SHOULD BE SET
;POINT R1 TO PAGE 1
014234 012701 020000             MOV      #20000,R1
014240 012702 000100             MOV      #100,R2
014244 005721             L40:    TST      (R1)+
014246 077202             SOB      R2,L40
014250 005077 166556             CLR      @SR0          ;TURN OFF KT11-C
014254 022777 077705 166772      CMP      #77705,@KIPDR1 ;CHECK A AND W BITS AGAIN
014262 001401             BEQ      .+4
014264 104006             HLT

;KERNEL I-SPACE PDR 1
;INCORRECT AFTER REPEATEDLY READING PAGE 1
;SHOW THAT IF KT11-C IS ON, SETTING THE CURRENT MODE TO 10 WILL
;CAUSE A MEMORY MANAGEMENT ABORT. NON RESIDENT SHOULD BE SET, AND ALSO PL SHOULD
;BE SET IF THE REFERENCE IS OUTSIDE THE FIRST BLOCK
014266 104400             TEST41: SCOPE
014270 012737 000041 177570      MOV      #41,@#SR      ;DISPLAY TEST NUMBER
014276 005037 177776             CLR      @#PS          ;INITIALIZE PROCESSOR STATUS
014302 012706 001000             MOV      #KSTACK,SP   ;INITIALIZE KERNEL STACK POINTER
014306 005077 166534             CLR      @SR3         ;INITIALIZE SR3
014312 005077 166514             CLR      @SR0         ;INITIALIZE SR0
014316 026727 167076 000041      CMP      TESTCT,#41   ;IS THIS TEST BEING EXECUTED IN THE
014324 001401             BEQ      .+4          ;CORRECT SEQUENCE? - BRANCH IF YES
014326 104006             HLT                  ;TEST EXECUTED OUT OF ORDER - TESTCT
;CONTAINS NUMBER OF PREVIOUS TEST PLUS ONE
014330 012767 002000 000646      MOV      #2000,ICOUNT ;RESTORE ITERATION COUNT
014336 004767 000202             JSR      %7,RWALL      ;INITIALIZE ALL PAGES 4K, RW, BANK 0
014342 012777 007600 166760      MOV      #7600,@KIPAR7 ;MAP KERNEL 7 TO EXTERNAL BANK
014350 012777 014416 167032      MOV      #RET41,@KTVEC ;SETUP MEMORY MANAGEMENT ABORT RETURN
014356 005077 167030             CLR      @KTSTA
014362 012777 000001 166442      MOV      #1,@SR0      ;TURN ON KT11-C
014370 012737 100000 177776      MOV      #100000,@#PS ;SET MODE TO 10-FETCH OF NEXT
014376 000240             ADD41: NOP             ;INSTRUCTION SHOULD ABORT
014400 005037 177776             CLR      @#PS          ;RESTORE MODE TO KERNEL
014404 042777 000001 166420      BIC      #1,@SR0      ;TURN OFF KT11-C
014412 104006             HLT                  ;NO ABORT WHEN MODE WAS SET
014414 000415             BR       CONT41       ;TO 10 (ILLEGAL) WITH KT11-C ON
014416 042777 000001 166406      RET41: BIC      #1,@SR0 ;TURN OFF KT11-C AFTER ABORT
014424 022777 140100 166400      CMP      #140100,@SR0 ;CK SR0
014432 001401             BEQ      .+4
014434 104006             HLT

;SR0 INCORRECT AFTER MODE 10 ABORT
;NR, PL, AND MODE 10 SHOULD BE SET
;CHECK SR2
014436 022777 014376 166376      CMP      #ADD41,@SR2
014444 001401             BEQ      .+4
014446 104006             HLT

;SR2 INCORRECT - SHOULD CONTAIN

```

```

; ADDRESS OF THE INSTRUCTION
; IMMEDIATELY AFTER THE ONE SETTING
; THE MODE TO 10
; REINITIALIZE SRO
; RESTORE TRAP CATCHER
014450 005077 166356 CONT41: CLR JSRO
014454 016777 166732 166726 MOV KTSTA, &KTVEC

014462 104400 SCOPE

014464 004767 001174 JSR %7, BELL

014470 013701 000042 MOV #42, R1 ; MONITOR HOOK
014474 001405 BEQ END
014476 000005 RESET
014500 004711 LOGIC: JSR %7, @R1
014502 000240 NOP
014504 000240 NOP
014506 000240 NOP

014510 000167 166706 END: JMP START

; SUBROUTINE TO CLEAR ALL KT11-C REGISTERS (EXCEPT SR1, SR2)
014514 005077 166312 CLRALL: CLR JSRO
014520 005077 166322 CLR JSR3
014524 005000 CLR RO ; RO IS USED TO INDEX THRU THE ADDRESS TABLE
014526 012701 000140 MOV #96, R1 ; COUNT OF REGISTERS TO BE CLEARED
014532 005070 003052 CLR @ADRTAB(RO) ; CLEAR REGISTERS THRU ADDRESS TABLE
014536 005720 TST (RO)+ ; MOVE POINTER
014540 077104 SOB R1, CLRLP ; LOOP TILL DONE
014542 000207 RTS %7

; SUBROUTINE TO MAKE ALL PAGES RW, BANK 0, 4K, UP
014544 005077 166262 RWALL: CLR JSRO
014550 012701 003052 MOV @ADRTAB, R1 ; R1 POINTS TO ADDRESS OF PDR
014554 012700 000020 RWL1: MOV #20, RO ; RO KEEPS TRACK OF WHEN TO CHANGE REGISTER SETS
014560 005071 000040 RWL2: CLR @40(R1) ; CLEAR PAR
014564 012731 077406 MOV #77406, @ (R1)+ ; SET PDR TO 4K, RW
014570 077005 SOB RO, RWL2
014572 062701 000040 ADD #40, R1
014576 020127 003350 CMP R1, @ADREND ; CHECK FOR END OF TABLE
014602 002764 BLT RWL1
014604 000207 RTS %7

; SUBROUTINE TO MAKE ALL I SPACE PAGES RW, BANK 0, 4K, UP
014606 005077 166220 RWISP: CLR JSRO
014612 012701 003052 MOV @ADRTAB, R1 ; R1 POINTS TO ADDRESS OF I-SPACE PDR
014616 012700 000010 RWI1: MOV #10, RO
014622 005071 000040 RWI2: CLR @40(R1) ; CLEAR PAR
014626 012731 077406 MOV #77406, @ (R1)+ ; MAP PDR RW, 4K
014632 077005 SOB RO, RWI2
014634 062701 000060 ADD #60, R1
014640 020127 003350 CMP R1, @ADREND ; CHECK FOR DONE
014644 002764 BLT RWI1 ; BRANCH IF NOT
014646 000207 RTS %7

; SUBROUTINE TO MAKE ALL D-SPACE PAGES RW, BANK 0, 4K, UP
014650 005077 166156 RWOSP: CLR JSRO

```

014654	012701	003072		MOV	#ADRTAB+20,R1	;R1 POINTS TO ADDRESS OF D-SPACE PDR
014660	012700	000010		RWD1: MOV	#10,R0	
014664	005071	000040		RWD2: CLR	240(R1)	;CLEAR PAR
014670	012731	077406		MOV	#77406,@(R1)+	;MAP PDR RW,4K
014674	077005			SOB	R0,RWD2	
014676	062701	000060		ADD	#60,R1	
014702	020127	003350		CMP	R1,#ADREND	;CHECK FOR DONE
014706	002764			BLT	RWD1	;BRANCH IF NOT
014710	000207			RTS	%7	

;ROUTINE TO MAKE ALL PAGES READ/WRITE AND TRAP ON WRITE
;ALL PAGES ARE MAPPED 4K, BANK 0 EXCEPT FOR D-SPACE PAGE 7,
;ALL OF WHICH ARE MAPPED TO THE EXTERNAL BANK

014712	005077	166114		RWTWAL: CLR	2SR0	
014716	012701	003052		MOV	#ACRTAB,R1	;R1 POINTS TO ADDRESS OF PDR
014722	012700	000320		RWTW1: MOV	#20,R0	
014726	005071	000040		RWTW2: CLR	240(R1)	;CLEAR PAR
014732	012731	077405		MOV	#77405,@(R1)+	;MAP PDR RWTW,4K
014736	077005			SOB	R0,RWTW2	
014740	062701	000040		ADD	#40,R1	
014744	020127	003350		CMP	R1,#ADREND	
014750	002764			BLT	RWTW1	
014752	012777	007600	166370	MOV	#7600,@KDPAR7	;MAP PAGE 7, ALL MODES,
014760	012777	007600	166262	MOV	#7600,@SDPAR7	;TO THE EXTERNAL BANK
014766	012777	007600	166154	MOV	#7600,@JDPAR7	
014774	000207			RTS	%7	

;ROUTINE TO LOOP THRU A SINGLE INSTRUCTION TEST
;LOAD THE STARTING ADDRESS OF THE TEST
;YOU WISH TO RUN (THE ADDRESS OF THE TESTXX
;TAG) AT THE 1ST HALT, SET SWITCH REGISTER
;OPTIONS AT THE 2ND HALT.
;NOTE THAT SW11 MUST BE DOWN AFTER THE 2ND HALT

014776	005037	177776		TESTXX: CLR	2#PS	
015002	012706	001000		MOV	#KSTACK,SP	
015006	000000			HALT		;WAIT FOR STARTING ADDRESS
015010	016767	162554	000036	MOV	SR,RETRNX	;LOAD STARTING ADDRESS IN RETRNX
015016	062767	000002	000030	ADD	#2,RETRNX	;ADD 2 TO POINT TO INSTRUCTION AFTER
015024	000000			HALT		;SET SR OPTIONS
015026	005067	000154		CLR	SCOPEF	;KEEP COUNT AT ZERO
015032	012767	015044	000150	MOV	#XLOOP,RETURN	;LOAD SCOPE LOOP RETURN POINTER
015040	000177	000010		JMP	@RETRNX	;JUMP TO TEST
015044	005067	000136		XLOOP: CLR	SCOPEF	;KEEP COUNT AT ZERO
015050	000177	000000		JMP	@RETRNX	;JUMP TO TEST
015054	000000			RETRNX: 0		

;SCOPE AND/OR ITERATION LOOP FOR EACH TEST

015056	032737	040000	177570	SCOPEC: BIT	#40000,@#SR	;TEST SR FOR SCOPE
015064	001015			BNE	SCOPEB	;YES SCOPE
015066	032737	004000	177570	BIT	#4000,@#SR	;NO-TEST FOR ITERATION
015074	001025			BNE	SCOPEC	;INHIBIT ITERATION
015076	026767	000104	000100	CMP	SCOPEF,ICOUNT	;COMPARE CURRENT COUNT TO MAX NUMBER
015104	100021			BPL	SCOPEC	;EXIT-DONE
015106	005267	000074		INC	SCOPEF	;INCREMENT COUNT
015112	012737	000340	177776	MOV	#340,@#PS	;PREVENT TRAPPING WHILE MOVING STACK

015120	022606			SCOPEB: CMP	(6)+,%6	: REPOSITION STACK
015122	012637	177776		MOV	(6)+,%8PS	: RESTORE PREVIOUS PROCESSOR STATUS
015126	032737	000400	177570	BIT	#400,%8SR	: LOAD MICROBREAK REGISTER?
015134	001403			BEQ	.+10	: NO-BRANCH
015136	113777	177570	166250	MOVB	%8SR,%2UBR	: YES-LOAD FROM LOW BYTE OF SR
015144	000177	000040		JMP	%RETURN	: REPEAT TEST
015150	005067	000032		SCOPEG: CLR	SCOPEF	: CLEAR COUNT
015154	005267	166240		INC	TESTCT	: STEP TEST COUNTER TO ALLOW CHECKING ORDER OF EXECUTION
015160	011667	000024		MOV	%6,%RETURN	: SAVE SCOPE RETURN POINTER
015164	032737	000400	177570	BIT	#400,%8SR	
015172	001403			BEQ	.+10	
015174	113777	177570	166212	MOVB	%8SR,%2UBR	
015202	000002			RTI		: RETURN INLINE-NEXT TEST
015204	002000			ICOUNT: 2000		: ITERATION COUNT
015206	000000			SCOPEF: 0		: COUNT LOCATION FOR ITERATION LOOP
015210	000000			RETURN: 0		: ADDRESS OF LAST TEST

				: ENTERED WITH SYSTEM TRAP CALL (HLT)		
				: PRINT OUT THE ERROR PC+2 AND STATUS REGISTER		
015212	012767	000340	162556	PRINT: MOV	#340,%8PS	: SET PRIORITY TO 7
015220	036727	162344	020000	BIT	SR,%20000	: TEST FOR INHIBIT PRINT OUT
015226	001401			BEQ	.+4	: BRANCH TO PRINT
015230	000432			BR	CK	: INHIBIT, CHECK FOR HALT
015232	012667	000100		MOV	(6)+,%SAVPC	: PC OF FAILING ROUTINE
015236	012667	000076		MOV	(6)+,%SAVPSR	: PSR OF ERROR CONDITION
015242	024646			CMP	-(6),-(6)	: RESTORE STACK
015244	012767	000200	162524	MOV	#200,%8PS	
015252	004767	000424		JSR	%7,%CALF	: OUTPUT CARRIAGE RETURN AND LINE FEED
015256	016767	000054	000322	MOV	%SAVPC,%PTEMP1	: LOAD WITH FAILING PC+2
015264	004767	000104		JSR	%7,%PROCT	: PRINT FAILING PC+2
015270	105777	165522		TSTB	%TCSR	: WAIT FOR TTY READY
015274	100375			BPL	.-4	
015276	012777	000240	165514	MOV	#240,%2DBR	: OUTPUT A SPACE
015304	016767	000030	000274	MOV	%SAVPSR,%PTEMP1	: LOAD PROCESSOR STATUS
015312	004767	000056		JSR	%7,%PROCT	: PRINT PROCESSOR STATUS
015316	005767	162246		CK: TST	SR	: CHECK SR FOR HALT SWITCH
015322	100001			BPL	.+4	: BRANCH IF NOT SET
015324	000000			HALT		: HALT ON ERROR UP
015326	000002			RTI		: RETURN TO MAIN LINE
015330	000000			SAVR2: 0		
015332	000000			SAVR3: 0		
015334	000000			SAVR4: 0		
015336	000000			SAVPC: 0		
015340	000000			SAVPSR: 0		

				: SUBROUTINE TO PRINT OUT OCTAL NUMBER		
				: PRSHRT DELETES LEADING ZEROS		
				: PROCT PRINTS OUT 6 OCTAL DIGITS		
015342	012767	000001	000232	PRSHRT: MOV	#1,%PRSHRT	: SET FLAG TO INDICATE SHORT PRINTOUT
015350	005767	000232		TST	%PTEMP1	: CHECK FOR ZERO
015354	001011			BNE	PROCT+4	: BRANCH IF NOT ZERO
015356	105777	165434		TSTB	%TCSR	: WAIT FOR TTY READY
015362	100375			BPL	.-4	
015364	012777	000260	165426	MOV	#260,%2DBR	: OUTPUT A SINGLE ZERO
015372	000207			RTS	%7	: RETURN


```

015374 005067 000202          PROCT: CLR      PRSFLG      ; CLEAR FLAG TO INDICATE FULL PRINTOUT
015400 005067 000206          CLR      PTEMP3     ; CLEAR R4 FOR COUNTING CHARACTERS OUTPUT
015404 005067 000174          CLR      PRFLG      ; INITIALIZE CARRY FLAG FOR ROTATES
015410 012767 000260 000172  MOV      #260,PTEMP2 ; SETUP R3
015416 005767 000164          TST      PTEMP1     ; CHECK BIT 15 OF NUMBER
015422 100002          BPL      .+6        ; BRANCH IF ZERO
015424 005267 000160          INC      PTEMP2     ; INCREMENT R3 IF ONE
015430 006167 000152          ROL      PTEMP1     ; ROTATE LEFT MOST OCTAL TO RIGHT END
015434 006167 000146          ROL      PTEMP1
015440 005567 000140          ADC      PRFLG      ; STORE CARRY
015444 005767 000132          P.CK:  TST      PRSFLG ; CHECK FOR SHORT PRINTOUT
015450 001404          BEQ      P.WAIT     ; BRANCH IF NOT SET
015452 026727 000132 000260  CMP      PTEMP2,#260 ; CHECK FOR ZERO IF SET
015460 001410          BEQ      P.CONT     ; IF SET, GO TO NEXT CHARACTER
015462 105777 165330          P.WAIT: TSTB     @TCSR   ; WAIT FOR TTY READY
015466 100375          BPL      P.WAIT
015470 016777 000114 165322  MOV      PTEMP2,@TDBR ; OUTPUT NEXT CHARACTER
015476 005067 000100          CLR      PRSFLG     ; PRINT REST OF NUMBER AFTER A NON-ZERO DIGIT
015502 005267 000104          P.CON . INC      PTEMP3 ; COUNT
015506 026727 000100 000006  CMP      PTEMP3,#6   ; CHECK FOR DONE
015514 001001          BNE     P.CNT1     ; BRANCH IF NOT DONE
015516 000207          RTS
015520 000241          P.CNT1: CLC        ; CLEAR CARRY
015522 005767 000056          TST      PRFLG     ; CHECK FOR PREVIOUS CARRY
015526 001403          BEQ      .+10      ; BRANCH IF PREVIOUSLY ZERO
015530 005067 000050          CLR      PRFLG     ; INITIALIZE FLAG
015534 000261          SEC        ; SET CARRY
015536 006167 000044          ROL      PTEMP1     ; ROTATE NEXT CHARACTER INTO RIGHT END OF REGISTER
015542 006167 000040          ROL      PTEMP1
015546 006167 000034          ROL      PTEMP1
015552 005567 000026          ADC      PRFLG     ; STORE CARRY
015556 016767 000024 000024  MOV      PTEMP1,PTEMP2 ; LOAD DATA INTO R3
015564 042767 177770 000016  BIC     #177770,PTEMP2 ; CLEAR ALL BUT LOWEST OCTAL DIGIT
015572 052767 000260 000010  BIS     #260,PTEMP2  ; SET TO ASCII EQUIVALENT
015600 000721          BR      P.CK       ; LOOP
015602 000000          PRSFLG: 0
015604 000000          PRFLG:  0
015606 000000          PTEMP1: 0          ; CONTAINS VALUE TO BE OUTPUT
015610 000000          PTEMP2: 0          ; SCRATCH
015612 000000          PTEMP3: 0          ; USED TO COUNT CHARACTERS OUTPUT

; EMT HANDLER
; FIRST 3 CALLS LEFT OPEN IN TABLE FOR EASY PATCHES
015614 011667 000032          EMTSRV: MOV      @SP,EPC ; GET CALL
015620 162767 000002 000024  SUB      #2,EPC
015626 017767 000020 000016  MOV      @EPC,EPC
015634 105067 000013          CLRB   EPC+1       ; SAVE OFFSET ONLY
015640 062767 015654 000004  ADD      @EMTAB,EPC ; POINT TO TABLE OF ADDRESSES
015646 017707 000000          MOV      @EPC,PC   ; JUMP TO DESIRED ROUTINE
015652 000000          EPC:    0
          104000      PATCH1=EMT+0
          104002      PATCH2=EMT+2
          104004      PATCH3=EMT+4
          104006      HLT   =EMT+6
015654 104000          EMTAB: PATCH1
015656 104002          PATCH2

```

015660 104004
015662 015212

PATCH3
PRINT

015664 105777 165126
015670 100375
015672 012777 000207 165120
015700 000207

;BELL ON PASS COMPLETE
BELL: TSTB @TCSR
BPL .-4
MOV #207,@TDBR
RTS %7

015702 105777 165110
015706 100375
015710 012777 000215 165102
015716 105777 165074
015722 100375
015724 012777 000212 165066
015732 000207
017712

;SUBROUTINE TO OUTPUT CARRIAGE RETURN AND LINEFEED
CRLF: TSTB @TCSR ;WAIT FOR TTY READY
BPL .-4
MOV #215,@TDBR ;ROUTPUT CARRIAGE RETURN
TSTB @TCSR ;WAIT FOR TTY READY
BPL .-4
MOV #212,@TDBR ;OUTPUT LINEFEED
RTS %7 ;RETURN
.=17712

017712 125252
000001

DESTAD: 125252
.END

ADD14	006454	952#	958																	
ADD41	014376	1990#	2000																	
ADREND=	003350	402#	1615	1634	1693	1895	2041	2053	2065	2079										
ADRTAB	003052	303#	1601	1623	1680	1885	2028*	2035	2047	2059	2073									
ADR14	006456	954#	967																	
ADR22	007772	1177	1179#	1191	1195															
ADR27A	011276	1437	1443#																	
ADR3	004160	541	547#																	
ADR32	012174	1583	1587#																	
ADR33A	012522	1668	1672#																	
ADR33B	012642	1669	1702#																	
ADR36	013616	1864	1867#																	
ADR7	005164	718	719#																	
AD21	007564	1140#	1141																	
BELL	015664	2011	2231#																	
CK	015316	2138	2151#																	
CKWBIT	011374	1446	1455	1464#																
CLRALL	014514	844	1168	1405	2024#															
CLRLP	014532	2028#	2030																	
CNT33A	012576	1683	1690#																	
CONT13	006230	895	906#																	
CONT2	004022	502	517#																	
CONT23	010306	1243	1249	1262#																
CONT24	010556	1310	1316	1327#																
CONT41	014450	1994	2006#																	
CR_LF	015702	2143	2237#																	
C25	010756	1372#	1386																	
DESTAD	017712	2246#																		
DONE10	005530	756	770	783	791#															
DONE13	006326	921	926#																	
DONE14	006546	956	962	965	975#															
DONE15	006704	1003	1006#																	
DONE16	007122	1044	1047	1051#																
DONE17	007276	1079	1084#																	
DONE20	007446	1110	1117#																	
DONE21	007636	1147	1153#																	
DONE22	010054	1181	1201#																	
DONE23	010320	1235	1267#																	
DONE24	010570	1302	1332#																	
DONE25	011024	1378	1389#																	
DONE3	004222	549	562#																	
DONE6	004770	665	680#																	
DONE7	005220	709	722	729#																
EMTAB	015654	2218	2225#																	
EMTSRV	015614	263	2214#																	
END	014510	2014	2021#																	
EPC	015652	2214#	2215#	2216#	2217#	2218#	2219	2220#												
ERR14	006472	946	957#																	
HLT =	104006	450	456	462	480	506	511	515	530	552	561	577	595	602						
		616	625	632	646	671	695	708	714	727	742	755	761	769						
		775	782	788	803	819	841	860	881	894	901	904	916	920						
		924	940	960	963	969	973	988	1001	1019	1034	1038	1042	1046						
		1049	1064	1077	1083	1096	1109	1115	1130	1143	1146	1151	1165	1180						
		1185	1189	1193	1197	1216	1239	1246	1255	1260	1284	1306	1313	1322						
		1326	1347	1369	1385	1401	1409	1422	1466	1472	1486	1496	1500	1507						
		1513	1526	1536	1540	1547	1553	1566	1607	1628	1653	1677	1686	1698						

R4	=%000004	246#	658*	679*	1361*	1362*	1366*	1367	1382*	1383	1680*	1682	1684	1690
		1692*	1693											
R5	=%000005	247#	666*	668	1681*	1691*								
R6	=%000006	248#	588*	674	851*	852*	864	1191	1431*	1433*	1575*	1577*	1661*	1663*
		1743*	1745*											
R7	=%000007	249#												
SAVEA	003404	419#												
SAVEB	003406	420#												
SAVPC	015336	2139*	2144	2158#										
SAVPSR	015340	2140*	2149	2159#										
SAVR2	015330	2155#												
SAVR3	015332	2156#												
SAVR4	015334	2157#												
SCOPE	= 104400	240#	442	472	522	569	608	638	687	734	795	833	873	932
		980	1011	1056	1088	1122	1157	1208	1276	1339	1393	1414	1478	1518
		1558	1645	1728	1788	1844	1907	1938	1972	2009				
SCOPEB	015120	2108	2115#											
SCOPEC	015056	266	2107#											
SCOPEF	015206	2098*	2101*	2111	2113*	2121*	2129#							
SCOPEG	015150	2110	2112	2121#										
SDPAR0	003232	361#												
SDPAR1	003234	362#												
SDPAR2	003236	363#												
SDPAR3	003240	364#												
SDPAR4	003242	365#												
SDPAR5	003244	366#												
SDPAR6	003246	367#												
SDPAR7	003250	368#	807*	1428*	1572*	1857*	2082*							
SDPOR0	003172	345#	654											
SDPOR1	003174	346#	748*											
SDPOR2	003176	347#												
SDPOR3	003200	348#												
SDPOR4	003202	349#												
SDPOR5	003204	350#												
SDPOR6	003206	351#												
SDPOR7	003210	352#												
SIPAR0	003212	353#												
SIPAR1	003214	354#												
SIPAR2	003216	355#												
SIPAR3	003220	356#												
SIPAR4	003222	357#												
SIPAR5	003224	358#												
SIPAR6	003226	359#												
SIPAR7	003230	360#												
SIPOR0	003152	337#	413											
SIPOR1	003154	338#												
SIPOR2	003156	339#												
SIPOR3	003160	340#												
SIPOR4	003162	341#												
SIPOR5	003164	342#												
SIPOR6	003166	343#												
SIPOR7	003170	344#												
SP	=%000006	250#	430*	432*	434*	445*	475*	491*	492*	499*	500*	525*	540*	541*
		572*	611*	641*	690*	737*	798*	836*	876*	896	922	935*	958	967
		983*	1005	1014*	1059*	1091*	1111	1125*	1160*	1183	1195	1211*	1245	1250
		1279*	1312	1317	1342*	1379	1396*	1417*	1481*	1521*	1561*	1648*	1731*	1791*

TEST16	006712	1011#				
TEST17	007134	1056#				
TEST2	003620	472#				
TEST20	007304	1088#				
TEST21	007460	1122#				
TEST22	007644	1157#				
TEST23	010066	1208#				
TEST24	010336	1276#				
TEST25	010606	1339#				
TEST26	011036	1393#				
TEST27	011130	1414#				
TEST3	004040	522#				
TEST30	011426	1463	1478#			
TEST31	011626	1518#				
TEST32	012026	1558#				
TEST33	012372	1645#				
TEST34	012736	1728#				
TEST35	013212	1788#				
TEST36	013472	1844#				
TEST37	013754	1907#				
TEST4	004242	569#				
TEST40	014116	1938#				
TEST41	014266	1972#				
TEST5	004442	608#				
TEST6	004574	638#				
TEST7	005002	687#				
UBRK	003414	423#	2119*	2126*		
UDPAR0	003132	328#				
UDPAR1	003134	329#				
UDPAR2	003136	330#				
UDPAR3	003140	331#				
UDPAR4	003142	332#				
UDPAR5	003144	333#				
UDPAR6	003146	334#				
UDPAR7	003150	335#	1429*	1573*	1858*	2083*
UDPDR0	003072	312#				
UDPDR1	003074	313#	749*			
UDPDR2	003076	314#				
UDPDR3	003100	315#				
UDPDR4	003102	316#				
UDPDR5	003104	317#				
UDPDR6	003106	318#				
UDPDR7	003110	319#	581*			
UIPAR0	003112	320#				
UIPAR1	003114	321#				
UIPAR2	003116	322#				
UIPAR3	003120	323#				
UIPAR4	003122	324#				
UIPAR5	003124	325#				
UIPAR6	003126	326#				
UIPAR7	003130	327#				
UIPDR0	003052	304#	415			
UIPDR1	003054	305#				
UIPDR2	003056	306#				
UIPDR3	003060	307#				
UIPDR4	003062	308#				

M04

DCKTB-B MACY11 27(732) 01-OCT-76 13:14 PAGE 53
 DCKTB8.P11 CROSS REFERENCE TABLE -- USER SYMBOLS

UIPDR5	003064	309#												
UIPDR6	003066	310#												
UIPDR7	003070	311#												
USTACK	003000	283#	434	588	1433	1577	1663	1745						
XLOOP	015044	2099	2101#											
.	= 017714	260#	262#	265#	268#	270#	274#	278#	280#	282#	402	439	449	455
		458	461	479	492	500	505	510	514	529	551	557	560	576
		591	594	598	601	615	624	631	645	663	670	694	713	726
		741	760	774	787	802	818	840	856	859	880	900	903	915
		919	939	959	968	972	987	1018	1033	1037	1041	1063	1082	1095
		1114	1129	1142	1150	1164	1184	1188	1192	1196	1215	1254	1259	1283
		1321	1325	1346	1368	1384	1400	1408	1421	1465	1471	1485	1495	1499
		1506	1512	1525	1535	1539	1546	1552	1565	1606	1620	1627	1652	1676
		1685	1697	1706	1712	1735	1756	1762	1769	1775	1795	1806	1810	1820
		1828	1838	1851	1881	1888	1914	1924	1932	1945	1956	1965	1979	1997
		2001	2118	2125	2137	2147	2152	2168	2176	2195	2232	2238	2241	2244#

DCKTB-B MACY11 27(732) 01-OCT-76 13:14 PAGE 56
DCKTB8.P11 CROSS REFERENCE TABLE -- MACRO NAMES

.\$S820	10
.\$SCOP	10
.\$SIZE	10
.\$SUPR	10
.\$STRAP	10
.\$STYPB	10
.\$STYPD	10
.\$STYPE	10
.\$STYPO	10
.\$40CA	10
.\$1170	10

DCKTB-B MAC'11 27(732) 01-OCT-76 13:14 PAGE 60
DCKTBB.P11 CROSS REFERENCE TABLE -- PERMANENT SYMBOLS

	1729	1789	1845	1908	1939	1973									
.MACR	427														
.MACRO	1														
.NLIST	981	260	427	443	473	523	570	609	639	688	735	796	834	874	933
	1729	1012	1057	1089	1123	1158	1209	1277	1340	1399	1415	1479	1519	1559	1646
.REM	1729	1789	1845	1908	1939	1973									
.REPT	1														
.TITLE	260														
.WORD	1														
	284														

ERRORS DETECTED: 0
DEFAULT GLOBALS GENERATED: 0

*, DCKTBB.SEQ/SOL/CRF/PAGNUM/NL:TOC=SYSMAC.CO, DCKTBB.P11
RUN-TIME: 26 34 3 SECONDS
RUN-TIME RATIO: 134/65=2.0
CORE USED: 33K (65 PAGES)

