

.REM %

IDENTIFICATION

PRODUCT CODE: AC-9244F-MC  
PRODUCT NAME: CZRKKF0 RK11 BASIC LOGIC TEST 2  
DATE CREATED: JUNE 1978  
MAINTAINER: DIAGNOSTIC GROUP  
AUTHOR: JIM KAPADIA  
REVISED BY: PERVEZ ZAKI  
TOM SAWYER  
CHUCK HESS

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS MANUAL.

THE SOFTWARE DESCRIBED IN THIS DOCUMENT IS FURNISHED TO THE PURCHASER UNDER A LICENSE FOR USE ON A SINGLE COMPUTER SYSTEM AND CAN BE COPIED (WITH INCLUSION OF DIGITAL'S COPYRIGHT NOTICE) ONLY FOR USE IN SUCH SYSTEM, EXCEPT AS MAY OTHERWISE BE PROVIDED IN WRITING BY DIGITAL.

DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL.

COPYRIGHT (C) 1975, 1978 BY DIGITAL EQUIPMENT CORPORATION

MAIN DEC CHANGE NOTICE  
MAY BE REQUIRED FOR  
PROGRAM TO OPERATE

QUICK LOOK-UP OPERATING INSTRUCTIONS  
FOR A QUICK REFERENCE, LOOK UP THE FOLLOWING SECTIONS:

- 1.0 ABSTRACT
- 2.0 REQUIREMENTS
- 4.1 LOADING AND OPERATOR ACTION
- 7.0 SWITCH OPTIONS

FOR A MORE COMPLETE EXPLANATION REFER TO THE TABLE OF CONTENTS BELOW AND THE FOLLOWING DOCUMENT.

TABLE OF CONTENTS

1.0	ABSTRACT
2.0	REQUIREMENTS
2.1	EQUIPMENT
2.2	PRELIMINARY PROGRAMS
2.3	EXECUTION TIME
3.0	STARTING ADDRESS
4.0	PROGRAM CONTROL MODES & OPERATOR ACTION
4.1	PAPER TAPE
4.2	RKDP DUMP MODE
4.3	RKDP CHAIN MODE
4.4	ACT11
5.0	DRIVE SELECTION
6.0	DRIVE-LESS TEST
7.0	SWITCH OPTIONS
8.0	SCOPE LOOPS
9.0	PROGRAM STRUCTURE
9.1	SET-UP PHASE
9.2	DRIVE DEPENDENT CONTROLLER TESTS
10.0	ERROR REPORTING
11.0	ERROR INTERPRETATION
12.0	HANDLERS AND COMMON ROUTINES
12.1	TRAP HANDLER
12.2	SCOPE HANDLER
12.3	ERROR HANDLER
12.4	CONTROL RESET ROUTINE
12.5	CONTROL READY ROUTINE
12.6	DRIVE RESET ROUTINE
12.7	TIME DELAY ROUTINE
12.8	WAIT FOR INTERRUPT ROUTINE
12.9	OTHER ROUTINES
	TTY HANDLER (I/O), ERROR TIMEOUT ROUTINE
	POWER DOWN/POWER UP ROUTINE
13.0	UNEXPECTED TIMEOUTS & RK11 INTERRUPTS
14.0	QUICK VERIFYING MODE

1.0 ABSTRACT

THE RK11 LOGIC TESTS CONSIST OF A SERIES OF TESTS AIMED AT CHECKING THE BASIC LOGIC OF THE RK11 CONTROLLER. THIS PROGRAM IS THE SECOND PART OF THE TWO-PART RK11 LOGIC TESTS. IT SHOULD BE NOTED THAT LOGIC TEST I AND LOGIC TEST II TOGETHER CONSTITUTE A COMPLETE PROGRAM AND BOTH OF THEM SHOULD BE RUN.

WHEN USED IN CONJUNCTION WITH A DRIVE IT IS CAPABLE OF DETECTING FAULTS IN THE DRIVE ALSO.

USED CORRECTLY THIS PROGRAM CAN BE AN EFFECTIVE ANALYTIC AND DIAGNOSTIC TOOL.

2.0 REQUIREMENTS

2.1 EQUIPMENT

- A. PDP11 WITH CONSOLE TELETYPE.
- B. 8K OF MEMORY
- C. RK11 OR RKV11 CONTROLLER
- D. 1-8 RK05 OR RK05F DRIVES OR THE RK05 SIMULATOR (DRIVE TYPES MAY BE MIXED)

2.2 PRELIMINARY PROGRAMS

RK11 BASIC LOGIC TEST I (MD-11-DZRKJ)

2.3 EXECUTION TIME

ERROR FREE FIRST PASS ON PDP11/20 WITH CORE MEMORY TAKES APPROXIMATELY TWO MINUTES. CONSIDERABLY LESS FOR FASTER MACHINES OR MEMORIES.

3.0 STARTING ADDRESS

200 FOR ANY MODE OF OPERATION. NORMAL START UP WITH ALL SWITCHES DOWN.

4.0 PROGRAM CONTROL MODES & OPERATOR ACTION

PAPER TAPE LOADING  
RKDP DUMP MODE  
RKDP CHAIN MODE  
ACT11

4.1 PAPER TAPE LOADING

4.1.1 LOAD PROGRAM INTO MEMORY USING STANDARD PROCEDURE FOR .ABS TAPES.

4.1.2 MAKE SURE THAT THE DRIVES TO BE CHECKED ARE LOADED WITH DISKS AND ARE IN 'RUN'. 'WRT ENABLE' THEM. CHECK THAT 'WRT PROT' LIGHT ON THESE DRIVES IS OFF. PUT DRIVES THAT ARE NOT TO BE TESTED ON 'LOAD'.

4.1.3 LOAD ADDRESS 200

4.1.4 SET SWITCHES IF DESIRED (SEE SEC 7.0) IF TESTING ON SIMULATOR PUT SW<10> UP.

PRESS START.

4.1.5 THE PROGRAM IDENTIFIES ITSELF (NAME,MAINDEC NO), THEN THE FOLLOWING QUESTION IS ASKED:

DRIVES TO BE TESTED?

THE USER SHOULD TYPE IN THE DRIVE NUMBERS THAT ARE IN 'RUN' AND TO BE TESTED. CARRIAGE RETURN SHOULD TERMINATE THE STRING. IF AN RK-05F IS TO BE TESTED, TYPE THE SUFFIX 'F' WITH THE FIRST DRIVE OF THE PAIR. FOR EXAMPLE, IF DRIVES 2 AND 3 ARE ON AN RK-05F, TYPE ONLY 2F.

EXMP: DRIVES TO BE TESTED? 0,1,2<CR>

THE DRIVES DO NOT HAVE TO BE IN LOGICAL ORDER.

EXMP: DRIVES TO BE TESTED? 2,4<CR>

IF ANY ONE DRIVE IS TO BE TESTED, TYPE IN THAT NUMBER. IT DOES NOT HAVE TO BE DRIVE 0.

THUS A NORMAL SEQUENCE WITH DRIVES 0,1 WOULD BE:

RK11 BASIC LOGIC TEST 2  
MAINDEC-11-CZRKKF  
DRIVES TO BE TESTED? 0,1<CR>

4.1.6 THERE IS A "RUBOUT" FEATURE WHICH ALLOWS RUBBING OUT ANY NUMBER OF CHARACTERS THAT WERE TYPED IN WRONG. THE RUBBED OUT CHARACTERS ARE ECHOED BACK WITHIN SLASHES.

"^U" DELETES THE ENTIRE LINE

4.1.7 IF REPLY TO ANY OF THE ABOVE QUESTION IS IN A WRONG  
FORMAT (EX: 012<CR>;0,8<CR>; 0,A<CR>; M<CR> ETC), IT  
IS AUTOMATICALLY REJECTED, A "??" IS PRINTED OUT;

THE CORRECT ANSWER CAN NOW BE RETYPED AGAIN.

4.1.8 THE DRIVE NUMBER BEING TESTED OUT IS PRINTED:

DRIVE N ;N=0,1...7  
IF THE DRIVE IS AN RK-05F, AN F IS APPENDED

AT THE END OF A PASS THE FOLLOWING TYPE-OUT OCCURS

END PASS # X

WHERE X= PASS NUMBER (1,2,3---), CONTROL IS PASSED  
TO THE BEGINNING OF THE PROGRAM AND RE-EXECUTION  
BEGINS. NO QUESTIONS ARE TO BE ANSWERED AGAIN.

4.1.9 ERROR FREE PASSES OF THE PROGRAM APPEAR AS SHOWN  
BELOW.

RK11 BASIC LOGIC TEST 2  
MAINDEC-11-CZRKKF  
DRIVES TO BE TESTED?  
0,1<CR>  
DRIVE 0  
DRIVE 1  
END PASS # 1  
0  
DRIVE 1  
END PASS # 2  
...  
...

4.2 RKDP DUMP MODE

4.2.1 THE PROGRAM IS LOADED INTO THE MEMORY BY THE RKDP  
MONITOR

4.2.2 START AS NORMALLY USING SA 200

4.2.3 THE PROGRAM IDENTIFIES ITSELF (NAME,MAINDEC NO.).  
ON FINDING OUT THAT THE LOADING WAS BY RKDP (DUMP  
MODE), THE FOLLOWING MESSAGE APPEARS:

'TO TEST DRIVE 'N' HALT PROGRAM, REMOVE RKDP PACK AND REPLACE IT  
WITH A WORK PACK, CLEAR LOCATION 40, AND RESTART PROGRAM'

IF DRIVE 'N' IS TO BE TESTED, THE RKDP PACK ON THAT

DRIVE SHOULD BE REPLACED BY ANOTHER PACK, THE DRIVE SHOULD BE PUT ON 'WRT ENABL' (BECAUSE RKDP WRITE PROTECTS THE DRIVE).

IF DRIVE 'N' IS NOT TO BE CHECKED, THEN THE MESSAGE SHOULD BE IGNORED.

AFTER THIS, THE SEQUENCE OF QUESTIONING IS AS EXPLAINED IN SEC 4.1.5.

#### 4.3 RKDP CHAIN MODE

THE PROGRAM IS CHAIN-LOADED FROM THE RKDP PACK ON DRIVE 'N'. AFTER THE PROGRAM IDENTIFIES ITSELF THE FOLLOWING PRINTOUT OCCURS.

'DRIVE 'N' NOT TESTED'

THERE IS NO OPERATOR INTERVENTION REQUIRED. THE PROGRAM FINDS OUT THE NUMBER OF DRIVES PRESENT.

#### 4.4 ACT11 MODE

THE PROGRAM IS LOADED BY THE ACT11 MONITOR. ON STARTING, IDENTIFIES ITSELF, ASCERTAINS THE NUMBER OF DRIVES AND PROCEEDS WITH THE EXECUTION OF THE TESTS AS BEFORE.

#### 5.0 DRIVE SELECTION

IF ANY PARTICULAR DRIVE IS TO BE SELECTED FOR TESTING, PUT THAT DRIVE ON 'RUN', 'WRITE ENABLE'; PUT REST OF THE DRIVES ON 'LOAD', 'WRITE LOCK' AND IN REPLY TO THE QUESTION (TO BE TESTED?) TYPE IN THE DRIVE NUMBER FOLLOWED BY CR. SEE SEC 4.1.5.

#### 6.0 DRIVE-LESS TEST

USE RK11 BASIC LOGIC TEST I, WHICH IS ACTUALLY THE FIRST PART OF THE TWO-PART RK11 BASIC LOGIC TESTS. SEE SEC 1.0, 2.2.

#### 7.0 SWITCH OPTIONS

IF THE PROGRAM IS BEING RUN ON A SWITCHLESS PROCESSOR (I.E. AN 11/34) THE PROGRAM WILL DETERMINE THAT THE HARDWARE SWITCH REGISTER IS NOT PRESENT AND WILL USE A 'SOFTWARE' SWITCH REGISTER. THE 'SOFTWARE' SWITCH REGISTER IS LOCATED AT LOCATION 176 (8). THE SETTINGS OF THE 'SOFTWARE' SWITCHES ARE CONTROLLED THROUGH A KEYBOARD ROUTINE WHICH IS CALLED BY TYPING A 'CONTROL G'. THE PROGRAM WILL RECOGNIZE THE 'CONTROL G' WHENEVER THE PROGRAM ENTERS

THE SCOPE ROUTINE OR BEGINS A NEW TEST. THE 'SOFTWARE' SWITCH VALUES ARE ENTERED AS AN OCTAL NUMBER IN RESPONSE TO THE PROMPT FROM THE SWITCH ENTRY ROUTINE:

'SWR = NNNNNN NEW ='

EACH TIME SWITCH SETTING ARE ENTERED, THE ENTIRE SWITCH REGISTER IMAGE MUST BE ENTERED. LEADING ZEROS ARE NOT REQUIRED., 'RUBOUT' AND 'CONTROL U' FUNCTIONS MAY BE USED TO CORRECT TYPING ERRORS DURING SWITCH ENTRY.

ON PROCESSORS WITH HARDWARE SWITCH REGISTERS, THE 'SOFTWARE' SWITCH REGISTER MAY BE USED. IF THE PROGRAM FINDS ALL 16 SWITCHES IN THE 'UP' POSITION, ALL SWITCH REGISTER REFERENCES WILL BE TO THE 'SOFTWARE' REGISTER AND THE PROCEDURES DESCRIBED ABOVE MUST BE FOLLOWED.

SW<15>=1	HALT ON ERROR
SW<14>=1	LOOP ON TEST
SW<13>=1	INHIBIT ERROR PRINTOUTS
SW<12>=1	CYCLE ON ERROR TO THE PREVIOUS 'SCOPE' STATEMENT
SW<11>=1	INHIBIT ITERATIONS
SW<10>=1	TESTING ON SIMULATOR
SW<09>=1	LOOP ON SPECIFIC ERROR
SW<08>=1	LOOP ON TEST AS PER SW<07:00>
SW<06>=1	DROP THE DRIVE AFTER MAXIMUM ALLOWABLE NUMBER OF ERRORS OCCUR

7.1 SW<15>

THE PROGRAM HALTS ON ENCOUNTERING AN ERROR, AFTER TYPING OUT THE ERROR MESSAGE AND PERTINENT INFORMATION. PRESSING "CONTINUE" RESTORES NORMAL OPERATION OF THE PROGRAM.

7.2 SW<14>

THE PROGRAM LOOPS ON THE SUBTEST THAT IS BEING EXECUTED WHEN THE SWITCH IS PUT ON. THIS SWITCH IS USED NORMALLY ALONG SW 15. SEE SEC 8.0.

7.3 SW <13>

THIS SWITCH INHIBITS ALL ERROR MESSAGES. NORMALLY USED WHEN LOOPING ON TEST (SW 14) OR LOOPING ON ERROR (SW 9).

7.4 SW <12>

THIS SWITCH ALLOWS THE PORGRAM TO CYCLE FROM THE POINT OF EFROR TO THE PREVIOUS SCOPE STATEMENT. NOTE THAT IN DOING SO ANY INITIALIZATION BEING DONE AT THE BEGINING OF THE SUBTEST WILL BE DONE AGAIN AND AGAIN. SEE SEC 8.0 FOR DIFFERENT SCOPE LOOPS

AVAILABLE.

7.5 SW <11>

EACH SUBTEST WILL BE EXECUTED ONLY ONCE. NORMALLY AFTER THE FIRST PASS, EACH SUBTEST IS ITERATED A NUMBER OF TIMES (USUALLY 50, 5 IN SOME CASES). SETTING THIS SWITCH INHIBITS ITERATIONS, SO THAT QUICK PASSES CAN BE MADE.

7.6 SW <10>

THIS SWITCH WHEN SET INDICATES THAT TESTING IS BEING DONE ON A SIMULATOR. THE SWITCH SHOULD BE PUT UP BEFORE STARTING THE PROGRAM. NOTE THAT RK11C IS NOT COMPATIBLE WITH THE SIMULATOR.

7.7 SW <09>

THIS SWITCH PROVIDES THE TIGHTEST POSSIBLE SCOPE LOOP. NOTE THAT THE SW12 THE INITIALIZATION OF PARAMETERS AT THE BEGINNING OF THE SUBTEST MAY NOT BE DONE IN THIS CASE. THIS SWITCH IS HELPFUL WHEN A PARTICULAR PART OF A SUBTEST IS BEING REPEATED USING DIFFERENT PARAMETERS AND YOU WANT TO SCOPE ON THE PARAMETER IN ERROR. (EXAMPLE: RKDA IS BEING WRITTEN AND READ BACK WITH COUNT PATTERNS FROM 1 TO 177777. PATTERN 561 IS GIVING ERROR, YOU MIGHT NOT WANT TO GO THROUGH THE 560 PATTERNS BEFORE HITTING ERROR ON THE 561TH PATTERN. IN THIS CASE SW 9 WILL GIVE YOU A SCOPE LOOP ON THE 561TH PATTERN ONLY

7.8 SW <08>

THIS SWITCH IS USED TO SELECT A PARTICULAR TEST (AS PER SW<00-07>) FOR EXECUTION AND SUBSEQUENT LOOPING. THUS IF TEST 15 IS TO BE SELECTED THE SWITCH SETTING WOULD BE 000415. IT SHOULD BE NOTED THAT BEFORE SELECTING TEST 15, ALL THE PREVIOUS TESTS (1-14) WILL BE EXECUTED.

7.9 SW<06>

THIS SWITCH ALLOWS THE PROGRAM TO DROP A DRIVE FROM THE SELECTION LIST AND TESTING AFTER MAXIMUM ALLOWABLE ERROR COUNT (TOTAL NUMBER OF ERRORS) ON THAT DRIVE IS EXCEEDED. THE MAXIMUM ALLOWABLE ERROR COUNT IS 5, AFTER 5 ERRORS HAVE OCCURED DRIVE IS DROPPED AND A MESSAGE (DRIVE # XXX DROPPED) IS PRINTED.

8.0 SCOPE LOOPS



THERE ARE THREE KINDS OF SCOPE LOOPS AVAILABLE

1. SW14: LOOPING IS DONE FOR THE ENTIRE SUB-TEST
2. SW12: LOOPING IS DONE FROM THE POINT OF ERROR BACK TO THE PREVIOUS 'SCOPE' STATEMENT.
3. SW09: PROVIDE THE TIGHTEST POSSIBLE SCOPE LOOP SEE SEC. 7.7

EXAMPLE:

TST1: SCOPE  
:

INITIALIZATION  
:

ERROR 1  
:  
ERROR 2  
:  
ERROR 3  
:  
ERROR 4  
:  
:

TST2: SCOPE

THE SEQUENCE OF LOOPING FOR DIFFERENT CASES IS EXPLAINED BELOW. NOTE THAT 'TST1' AND 'TST2' ARE TAGS WHICH DEFINE THE BOUNDARY OF A TEST, (IN THIS CASE TEST 1). TEST 1 STARTS AT 'TST1' AND ENDS JUST BEFORE 'TST2'.

IN THE ILLUSTRATION BELOW --> INDICATES THE POINT FROM WHERE RETURN IS MADE AND LOOPING IS DONE.

1. ERROR 2 OCCURS, SW 14 SET.

TST1..ERROR 2..TST2-->TST1..ERROR 2..TST2-->TST1...

2. ERROR 2 OCCURS, SW 12 SET.

TST1...ERROR 2-->TST1...ERROR2-->TST1...

3. ERROR 2,3; SW 14 SET.

TST1..ERROR 2..ERROR 3..TST2-->TST1..ERROR 2..ERROR 3..TST2-->TST' ..

4. ERROR 2,3; SW 12 SET.

TST1...ERROR 2-->TST1...ERROR 2-->TST1....

NOTE THAT LOOPING IS DONE FROM THE VERY FIRST ERROR ENCOUNTERED. THE MORE BASIC AND ERROR THE EARLIER IT OCCURS AND IS DETECTED AND SHOULD BE FIXED.

IN THE ABOVE EXAMPLE NO PART OF THE SUB-TEST IS BEING REPEASING DIFFERENT PARAMETERS, HENCE IT SO HAPPENS THAT SW 9 AND 12 GIVE THE SAME KIND OF LOOPS. THE EXAMPLE BELOW WILL DEMONSTRATE THE DIFFERENCE BETWEEN SW 9 AND 12.

TST1: SCOPE  
 :

INITIALIZATION

```

:
:
: ERROR 1
:
: MOV #1$, $LPERR ; '$LPERR' CONTAINS
: ; THE ADDRESS TO LOOP
: ; BACK ON ERROR- SW 9

```

```

1$: :
:
: ER I N REPETITIONS
: I
TST2: SCOPE
:
:

```

1. SW 12 SET, ERROR 2 OCCURS DURING K.TH REPETITIONS

TST1..1,2...K.ERROR 2-->TST1..1,2...K.ERROR 2-->TST1..

2. SW 9 SET, ERROR 2 OCCURS DURING K.TH REPETITION

1\$..K..ERROR 2-->1\$..K..ERROR 2-->1\$..

## 9.0 PROGRAM STRUCTURE

THERE ARE THREE DISTINCT PARTS OF THE PROGRAM.

SET-UP PHASE  
 DRIVE-DEPENDENT CONTROLLER TESTS

### 9.1 SET-UP PHASE

SETTING UP OF INITIAL POINTERS, VECTORS, TABLES IS DONE IN THIS PART. IN THIS SECTION THE DECISION IS MADE ABOUT THE PROGRAM MODE-PAPER TAPE, RKOP DUMP, CHAIN OR ACT11. IF IN A NON-INTERVENTION MODE (CHAIN, ACT11) NUMBER OF DRIVES AND THE TYPE OF CONTROLLER IS FOUND OUT. FLAGS ARE SET TO INDICATE

WHICH DRIVES ARE TO BE TESTED, ETC.

## 9.2 DRIVE DEPENDENT CONTROLLER TESTS

THIS SECTION FORMS A MAJOR PART OF THE PROGRAM WHEREIN MOST OF THE CONTROLLER IS CHECKED.

JUST BEFORE ENTERING THIS SECTION THE PROGRAM FINDS OUT WHICH DRIVE IS TO BE CHECKED. IF IN RKDP CHAIN MODE, DRIVE 'N' IF PRESENT, IS SKIPPED AND THE NEXT AVAILABLE DRIVE IS SELECTED.

THE DRIVE NUMBER BEING TESTED IS PRINTED OUT:

DRIVE N ;N=0,1,2...7

THE TESTING IS DONE IN A LOGICAL HIERCHY, SIMPLER THINGS FIRST, THEN MORE COMPLEX AND SO ON.

IN ONE OF THE TESTS THE ENTIRE DISK PACK IS FORMATTED, CHECKS ARE MADE FOR ERROR CONDITIONS. THE FIRST WORD OF EVERY SECTOR IS WRITTEN AS A PSUEDO-HEADER, REFLECTING THE ABSOLUTE ADDRESS OF THAT SECTOR (DRIVE #, CYLINDER #, SURFACE #, SECTOR #). EXAMPLE: THE PSUEDO-HEADER FOR SECTOR 5, SURFACE 0, CYLINDER 20, DRIVE 0 WOULD BE 001005.

IN THE NEXT TEST THE HEADERS FROM THE ENTIRE PACK ARE READ AND CHECKED FOR CORRECTNESS. IN A SUBSEQUENT TEST ALL THE PSUEDO-HEADERS ARE READ AND VERIFIED.

ALL THE FUNCTIONS ARE CHECKED OUT. 'SEEK' IS CHECKED IN THE THREE DIFFERENT VELOCITY MODES (HIGH, MEDIUM, LOW). VARIOUS ERRORS LIKE 'NXD', 'NXC', ETC. ARE SIMULATED AND CHECKED.

HARDWARE POGIC IS CHECKED USING ALL THE DRIVES THAT HAVE BEEN INDICATED.

AT THE END OF THIS SECTION, A CHECK IS MADE IF ALL INDICATED DRIVES HAVE BEEN TESTED. IF NOT, CONTROL IS TRANSFERRED TO THE BEGINNING OF THIS SECTION.

THUS ONE PASS OF THE PROGRAM INVOLVES DOING

1. SUBTEST #1 ONCE
2. DRIVE-DEPENDENT TESTS FOR ALL THE SELECTED DRIVES.

## 10.0 ERROR REPORTING

THE ERROR TABLE STARTING AT \$ERRTB CONTAINS INFORMATION PERTAINING TO EVERY ERROR THAT CAN OCCUR. EACH ITEM IN THE TABLE CONSISTS OF FOUR

ENTRIES.

- A. EM - THIS IS A POINTER TO THE ERROR MESSAGE TO BE TYPED OUT WHEN THE ERROR OCCURS.
- B. DH - THIS IS A POINTER TO THE DATA HEADER TO BE TYPED OUT.
- C. DT - THIS IS A POINTER TO THE DATA WHICH IS TO BE TYPED TYPED OUT UNDER THE HEADERS.
- D. 0 - THIS IS A TERMINATOR SIGNIFYING THE END OF THE ITEM.

THE ERROR CALL IS AN EMT INSTRUCTION WITH ITS LOWER BYTE ENCODED TO INDICATE THE ERROR NUMBER. THUS OR 1" WOULD BE (EMT+1) IE 104001.

EVERY ERROR CORRESPONDS TO AN ITEM IN THE ERROR TABLE. THUS "ERROR 14" WOULD CORRESPOND TO ITEM 14. AS FAR AS POSSIBLE, THE ERROR MESSAGES HAVE BEEN KEPT SHORT, BUT CLARITY IS NOT SACRIFICED FOR BREVITY. INSPITE OF THIS, IF THE USER FINDS A NEED, HE CAN LOOK UP THE ENTIRE ERROR MESSAGE IN THE ERROR ITEMS TABLE FOUND IN THE BEGINNING OF THE LISTINGS. THUS FOR "ERROR 14", "ITEM 14" IN THE ITEM TABLE CAN BE LOOKED UP. WHEN THE ERROR INSTRUCTION IS EXECUTED A TRAP OCCURS TO THE ERROR HA LOCATED AT \$ERROR WHICH PROCESSES THE ERROR CALL. SEE SEC 12.3

11.0 ERROR INTERPRETATION

WHENEVER AN ERROR MESSAGE IS PRINTED OUT, ALL REGISTERS AND OTHER DATA PERTAINING TO THE ERROR ARE ALSO GIVEN. RKDS, RKER...RKBA INDICATE THE CONTENTS OF THE CORRESPONDING REGISTERS AT THE TIME OF ERROR.

EVERY ERROR MESSAGE CONTAINS A PC. THIS PC INDICATES THE POSITION IN PROGRAM WHERE THE ERROR CALL IS LOCATED. THE ERROR MESSAGE, BECAUSE OF PRACTICAL CONSIDERATIONS IS MADE SHORT AND MEANINGFUL. THE USER IS ADVTO LOOK UP THE PC IN THE PROGRAM LISTING, WHERE HE WILL FIND MORE INFORMATION ABOUT THE ERROR. IN MANY INSTANCES, A SINGLE FAULT WILL GIVE RISE TO MORE THAN ONE ERROR REPORT. A LITTLE DELIBERATION AND CAREFUL EXAMINATION OF THE DATA GIVEN WILL BE CERTAINLY VERY HELPFUL IN PINPOINTING THE FAULT. A BRIEF EXPLANATION OF WHAT IS BEING CHECKED IN THE SUBTEST IS GIVEN AT THE BEGINNING OF EVERY SUBTEST. ALL THE NUMBERS GIVEN WITH ERROR MESSAGES ARE IN OCTAL.

12.0 HANDLERS AND COMMON ROUTINES

THE COMPOSED ROUTINES USED IN THE PROGRAM ARE CALLED IN TWO WAYS.

- A. AS A SUBROUTINE THROUGH 'JSR' CALL
- B. THROUGH A 'TRAP' HANDLER

#### 12.1 TRAP HANDLER

MANY COMMONLY USED ROUTINES IN THE PROGRAM ARE CALLED USING THE TRAP INSTRUCTION AND THE 'TRAP' HANDLER. THE LOWER BYTE OF THE TRAP INSTRUCTION IS ENCODED DIFFERENTLY FOR DIFFERENT ROUTINES. THE TRAP HANDLER IS LOCATED AT '\$TRAP'. WHEN A CALL FOR A ROUTINE IS EXECUTED, A TRAP OCCURS TO THE HANDLER 'TRAP'. THE HANDLER PICKS UP THE LOWER BYTE OF THE "CALL INSTRUCTION" AND USES IT TO FORM THE STARTING ADDRESS OF THE ROUTINE TO GO TO FOR SERVICE.

#### 12.2 SCOPE HANDLER

THE 'IOT' TRAP IS USED BY THE 'SCOPE' STATEMENT. WHEN 'SCOPE' IS EXECUTED, AN IOT TRAP OCCURS TO MEMORY LOCATION '\$SCOPE'. THE SCOPE HANDLER STARTS AT '\$SCOPE'. DEPENDING ON THE SWITCH SETTINGS THE HANDLER DECIDES TO LOOP ON TEXT, INHIBIT ITERATIONS ETC. THERE ARE CERTAIN POINTERS AND FLAGS WHICH ARE ADJUSTED. THUS, IT IS NOT ADVISABLE START THE PROGRAM AT ANY GIVEN LOCATION SINCE THE VARIOUS POINTERS AND FLAGS MAY NOT BE CORRECTLY ADJUSTED.

#### 12.3 ERROR HANDLER

AN EMT TRAP INSTRUCTION IS USED BY THE ERROR CALL. THE LOWER BYTE IS ENCODED TO GIVE DIFFERENT ERROR CALLS. (EX: ERROR 1 = 104000+1; ERROR 16 = 104000+16). WHEN THE ERROR STATEMENT IS EXECUTED, A TRAP OCCURS TO MEMORY LOCATION '\$ERROR'. THE ERROR HANDLER IS LOCATED AT '\$ERROR'. THE HANDLER FORMS THE POINTER TO ERROR TABLE, WHICH IS USED IF AN ERROR MESSAGE IS TO BE TYPED DEPENDING ON THE SWITCH SETTINGS, A DECISION ABOUT HALTING ON ERROR, INHIBITING TYPEOUT, LOOPING ON ERROR ETC. IS MADE. IF AN ERROR MESSAGE IS TO BE TYPED OUT AN EXIT IS MADE TO THE ERROR MESSAGE TYPEOUT ROUTINE LOCATED AT '\$ERRTYP'.

#### 12.4 CONTROL RESET ROUTINE

THE CALL FOR THIS ROUTINE IS "CNT.RESET" AND IS AN ENCODED 'TRAP' INSTRUCTION. WHEN "CNT.RESET" IS EXECUTED THE CONTROL RESET ROUTINE STARTING AT

"CN.RST" IS ENTERED. A CONTROL RESET IS ISSUED THE PROGRAM WAITS TILL THE CONTROL READY SETS, ON WHICH THE ROUTINE IS EXITED. IF CONTROL READY DOES NOT SET WITHIN A CERTAIN TIME AN ERROR IS REPORTED. THE PC TYPED OUT IS THE LOCATION WHERE THE "CNT.RESET" CALL IS LOCATED. THE WAITING TIME IS 2.8 MS FOR 11/20 AND 560 US FOR 11/45 WITH BIPOLAR MEMORY.

12.5 CONTROL READY ROUTINE

THIS ROUTINE IS CALLED BY "CNT.RDY" (AN ENCODED 'TRAP' INSTRUCTION) AND IS LOCATED AT "CN.RDY". THE ROUTINE WAITS FOR THE CONTROL READY TO SET AND WHEN IT DOES, EXITS IF CONTROL READY DOES NOT SET WITHIN A SPECIFIED TIME AN ERROR MESSAGE IS GIVEN

CNTRL RDY DIDN'T SET  
PC = XXXXXX RKCS = YYYYYY

THE PC IS THE LOCATION AT WHICH THE "CNT.RDY" CALL IS LOCATED. THE WAITING TIME IS 949 MS FOR 11/20 AND 189 MS FOR 11/45 WITH BIPOLAR MEMORY.

12.6 DRIVE RESET ROUTINE

THE DRIVE - RESET ROUTINE IS LOCATED AT "DRESET" AND IS CALLED BY A "JSR". IT ISSUES A DRIVE RESET AND WAITS FOR THE R/W/S RDY TO SET, ON WHICH THE ROUTINE IS EXITED. THE WAITING TIME IS 4959 MS FOR 11/20 AND 991 MS FOR 11/45 WITH BIPOLAR MEMORY.

12.7 TIME DELAY ROUTINE

THIS ROUTINE PROVIDES A VARIABLE TIME DELAY. THE CALL IS DELAY ,N WHERE N=1 TO 177777 (OCTAL) TIME DELAY PROVIDED= 7.5 TIMES( X ) N MICRO SECS FOR 11/20, 1.5N US FOR 11/45 (N CONVERTED TO DECIMAL BEFORE COMPUTING DELAY) IF THE USER WANTS TO CHANGE THE DELAY AT ANY POINT IT CAN BE DONE BY SIMPLY CHANGING VARIABLE 'N'.

12.8 WAIT FOR INTERRUPT ROUTINE

THIS ROUTINE PROVIDES A VARIABLE TIME LIMIT DURING WHICH RK11 INTERRUPT MAY OCCUR. THE IS  
WAT.INT .N N=1 TO 1777777 (OCTAL)  
WAITING TIME=7.5 TIMES( X ) N US FOR 11/20, 1.5N US

FOR 11/45 UPON ENTERING THE ROUTINE CPU PRIORITY IS DROPPED SO THAT RK11 CAN INTERRUPT.

## 12.9 OTHER ROUTINES

THERE ARE OTHER COMMONLY USED ROUTINES AS LISTED BELOW.

\$TYPE:  
TYPE ROUTINE FOR TYPING OUT ASCII STRINGS.  
LOCATED AT "\$TYPE"  
CALLED BY "TYPE"

\$TYPOC:  
ROUTINE FOR TYPING OUT OCTAL NUMBERS.  
LOCATED AT "\$TYPOC"  
CALLED BY "TYPOC"

\$TYPDS:  
ROUTINE FOR TYPING OUT DECIMAL NUMBERS.  
LOCATED AT "\$TYPDS"  
CALLED BY "TYPDS"

\$RDLIN:  
ROUTINE FOR INPUTTING ASCII STRINGS FROM TTY.  
LOCATED AT "\$RDLIN"  
CALLED BY "RDLIN"

\$ERRTYP:  
ROUTINE FOR TYPING OUT ERROR MESSAGES.  
LOCATED AT \$ERRTYP  
CALLED BY "JSR \$ERRTYP"

\$PWRDN:  
ROUTINE FOR HANDLING POWER FAILURE.  
LOCATED AT \$PWRDN  
CALLED WHEN THERE IS A POWER FAILURE.

\$PWRUP:  
ROUTINE FOR HANDLING POWER UP AFTER A POWER FAIL.  
LOCATED \$PWRUP  
CALLED WHEN POWER RETURNS AFTER HAVING GONE DOWN.

## 13.0 UNEXPECTED TIMEOUTS AND RK11 INTERRUPTS

WHEN AN UNEXPECTED TIMEOUT OCCURS, THE PC AT WHICH TIME OUT OCCURED IS TYPED OUT AND THE PROGRAM HALTS. IF IT IS INTACT, IT CAN BE RESTARTED BY PRESSING CONTINUE.

IF AN UNEXPECTED RK11 INTERRUPT OCCURS THE PROGRAM TYPES OUT THE PC AT WHICH THE INTERRUPT CAME IN AND THEN HALTS. PRESSING CONTINUE WOULD RESTART THE PROGRAM FROM BEGINING. SW 9- LOOPING CAITY IS PROVIDED AS A TROUBLE SHOOTING AID.

14.0 QUICK VERIFYING MODE

THE FIRST PASS OF THE PROGRAM IS A QUICK VERIFYING MODE. ALL THE TESTS ARE DONE ONLY ONCE, ON SUBSEQUENT PASSES THE TESTS ARE ITERATED (NORMALLY 50 TIMES, 5 IN SOME CASES). THUS THE FIRST PASS TAKES A SHORTER TIME TO COMPLETE, WHEREAS SUBSEQUENT PASSES TAKE MORE TIME.

%

852  
853  
854  
855  
856  
857  
858  
859  
860  
861  
862  
863  
864  
865  
866  
867  
868  
869  
870  
871  
872  
873  
874  
875  
876  
877  
878  
879  
880  
881  
882  
883  
884  
885  
886  
887  
888  
889  
890  
891  
892  
893

```
.TITLE MD-11-CZRKKF, RK11 BASIC LOGIC TEST 2
;*COPYRIGHT (C) 1974,1977
;*DIGITAL EQUIPMENT CORP.
;*MAYNARD, MASS. 01754
;*
;*PROGRAM BY JIM KAPADIA
;*
;*THIS PROGRAM WAS ASSEMBLED USING THE PDP-11 MAINDEC SYSMAC
;*PACKAGE (MAINDEC-11-DZQAC-C3), JAN 19, 1977.
;*
;*PROGRAM REVISED BY TOM SAWYER, MARCH, 1976
;*REVISED BY CHUCK HESS, AUGUST, 1976
.SBTTL OPERATIONAL SWITCH SETTINGS
;*
;*          SWITCH          USE
;*          -----          -
;*          15          HALT ON ERROR
;*          14          LOOP ON TEST
;*          13          INHIBIT ERROR TYPEOUTS
;*          12          CYCLE ON ERROR TO PREVIOUS 'SCOPE' STATEMENT
;*          11          INHIBIT ITERATIONS
;*          10          TESTING ON SIMULATOR
;*          9          LOOP ON ERROR
;*          8          LOOP ON TEST IN SWR<7:0>
;*          6          DROP THE DRIVE IF MORE THAN 5 ERRORS
;*
;*****
;*YOU ARE ADVISED TO READ THE DOCUMENT BEFORE USING THIS PROGRAM.
;*ON GETTING AN ERROR REFER TO THE LISTINGS AT THE PC POINTED
```



```

894 ;OUT IN THE ERROR MESSAGE. ADJACENT ERROR MESSAGES IF FOLLOWED
895 ;CAREFULLY COULD LEAD TO AN EASY PINPOINTING OF THE FAULT
896
897 ;*****
898 .SBTTL BASIC DEFINITIONS
899
900 ;*INITIAL ADDRESS OF THE STACK POINTER *** 1100 ***
901 STACK= 1100
902
903 .EQUIV EMT,ERROR ;:BASIC DEFINITION OF ERROR CALL
904 .EQUIV IOT,SCOPE ;:BASIC DEFINITION OF SCOPE CALL
905
906 ;*MISCELLANEOUS DEFINITIONS
907 HT= 11 ;:CODE FOR HORIZONTAL TAB
908 LF= 12 ;:CODE FOR LINE FEED
909 CR= 15 ;:CODE FOR CARRIAGE RETURN
910 CRLF= 200 ;:CODE FOR CARRIAGE RETURN-LINE FEED
911 PS= 177776 ;:PROCESSOR STATUS WORD
912 .EQUIV PS,PSW
913 STKLMT= 177774 ;:STACK LIMIT REGISTER
914 PIRQ= 177772 ;:PROGRAM INTERRUPT REQUEST REGISTER
915 DSWR= 177570 ;:HARDWARE SWITCH REGISTER
916 DDISP= 177570 ;:HARDWARE DISPLAY REGISTER
917
918 ;*GENERAL PURPOSE REGISTER DEFINITIONS
919 R0= %0 ;:GENERAL REGISTER
920 R1= %1 ;:GENERAL REGISTER
921 R2= %2 ;:GENERAL REGISTER
922 R3= %3 ;:GENERAL REGISTER
923 R4= %4 ;:GENERAL REGISTER
924 R5= %5 ;:GENERAL REGISTER
925 R6= %6 ;:GENERAL REGISTER
926 R7= %7 ;:GENERAL REGISTER
927 SP= %6 ;:STACK POINTER
928 PC= %7 ;:PROGRAM COUNTER
929
930 ;*PRIORITY LEVEL DEFINITIONS
931 PRO= 0 ;:PRIORITY LEVEL 0
932 PR1= 40 ;:PRIORITY LEVEL 1
933 PR2= 100 ;:PRIORITY LEVEL 2
934 PR3= 140 ;:PRIORITY LEVEL 3
935 PR4= 200 ;:PRIORITY LEVEL 4
936 PR5= 240 ;:PRIORITY LEVEL 5
937 PR6= 300 ;:PRIORITY LEVEL 6
938 PR7= 340 ;:PRIORITY LEVEL 7
939
940 ;*SWITCH REGISTER* SWITCH DEFINITIONS
941 SW15= 100000
942 SW14= 40000
943 SW13= 20000
944 SW12= 10000
945 SW11= 4000
946 SW10= 2000
947 SW09= 1000
948 SW08= 400
949 SW07= 200
950 SW06= 100

```

```

950 SW05= 40
951 SW04= 20
952 SW03= 10
953 SW02= 4
954 SW01= 2
955 SW00= 1
956 .EQUIV SW09,SW9
957 .EQUIV SW08,SW8
958 .EQUIV SW07,SW7
959 .EQUIV SW06,SW6
960 .EQUIV SW05,SW5
961 .EQUIV SW04,SW4
962 .EQUIV SW03,SW3
963 .EQUIV SW02,SW2
964 .EQUIV SW01,SW1
965 .EQUIV SW00,SW0
966
967 ;*DATA BIT DEFINITIONS (BIT00 TO BIT15)
968 BIT15= 100000
969 BIT14= 40000
970 BIT13= 20000
971 BIT12= 10000
972 BIT11= 4000
973 BIT10= 2000
974 BIT09= 1000
975 BIT08= 400
976 BIT07= 200
977 BIT06= 100
978 BIT05= 40
979 BIT04= 20
980 BIT03= 10
981 BIT02= 4
982 BIT01= 2
983 BIT00= 1
984 .EQUIV BIT09,BIT9
985 .EQUIV BIT08,BIT8
986 .EQUIV BIT07,BIT7
987 .EQUIV BIT06,BIT6
988 .EQUIV BIT05,BIT5
989 .EQUIV BIT04,BIT4
990 .EQUIV BIT03,BIT3
991 .EQUIV BIT02,BIT2
992 .EQUIV BIT01,BIT1
993 .EQUIV BIT00,BIT0
994
995 ;*BASIC "CPU" TRAP VECTOR ADDRESSES
996 ERRVEC= 4 ;:TIME OUT AND OTHER ERRORS
997 RESVEC= 10 ;:RESERVED AND ILLEGAL INSTRUCTIONS
998 TBITVEC=14 ;: "T" BIT
999 TRTVEC= 14 ;:TRACE TRAP
1000 BPTVEC= 14 ;:BREAKPOINT TRAP (BPT)
1001 IOTVEC= 20 ;:INPUT/OUTPUT TRAP (IOT) **SCOPE**
1002 PWRVEC= 24 ;:POWER FAIL
1003 EMTVEC= 30 ;:EMULATOR TRAP (EMT) **ERROR**
1004 TRAPVEC=34 ;: "TRAP" TRAP
1005 TKVEC= 60 ;:TTY KEYBOARD VECTOR

```

```

1006      000064      TPVEC= 64          ;;TTY PRINTER VECTOR
1007      000240      PIRQVEC=240       ;;PROGRAM INTERRUPT REQUEST VECTOR
1008      .SBTTL TRAP CATCHER
1009
1010      000000      .=0
1011      ;*ALL UNUSED LOCATIONS FROM 4 - 776 CONTAIN A ".+2,HALT"
1012      ;*SEQUENCE TO CATCH ILLEGAL TRAPS AND INTERRUPTS
1013      ;*LOCATION 0 CONTAINS 0 TO CATCH IMPROPERLY LOADED VECTORS
1014      .=174
1015      000174      000000      DISPREG: .WORD 0          ;;SOFTWARE DISPLAY REGISTER
1016      000176      000000      SWREG: .WORD 0           ;;SOFTWARE SWITCH REGISTER
1017      .SBTTL STARTING ADDRESS(ES)
1018      000200      000137      002836      JMP @#START ;;JUMP TO STARTING ADDRESS OF PROGRAM
1019      .SBTTL ACT11 HOOKS
1020
1021      ;*****
1022      ;HOOKS REQUIRED BY ACT11
1023      000204      $SVPC=.          ;SAVE PC
1024      000046      .=46
1025      000046      020740      SENDAD          ;;1)SET LOC.46 TO ADDRESS OF SENDAD IN .SEOP
1026      000052      .=52
1027      000052      000000      .WORD 0          ;;2)SET LOC.52 TO ZERO
1028      000204      .=$SVPC          ;; RESTORE PC

```

```

1029      .SBTTL COMMON TAGS
1030
1031      ;*****
1032      ;THIS TABLE CONTAINS VARIOUS COMMON STORAGE LOCATIONS
1033      ;USED IN THE PROGRAM.
1034
1035      .=1100
1036      001100      $CMTAG:          ;;START OF COMMON TAGS
1037      001100      000000      $PASS: .WORD 0          ;;CONTAINS PASS COUNT
1038      001102      000      $TESTNM: .BYTE 0         ;;CONTAINS THE TEST NUMBER
1039      001103      000      $ERFLG: .BYTE 0          ;;CONTAINS ERROR FLAG
1040      001104      000000      $ICNT: .WORD 0         ;;CONTAINS SUBTEST ITERATION COUNT
1041      001106      000000      $LPADR: .WORD 0        ;;CONTAINS SCOPE LOOP ADDRESS
1042      001110      000000      $LPERR: .WORD 0       ;;CONTAINS SCOPE RETURN FOR ERRORS
1043      001112      000000      $ERTTL: .WORD 0      ;;CONTAINS TOTAL ERRORS DETECTED
1044      001114      000      $ITEMB: .BYTE 0         ;;CONTAINS ITEM CONTROL BYTE
1045      001115      001      $ERRMAX: .BYTE 1         ;;CONTAINS MAX. ERRORS PER TEST
1046      001116      000000      $ERRPC: .WORD 0      ;;CONTAINS PC OF LAST ERROR INSTRUCTION
1047      001120      000000      $GDADR: .WORD 0     ;;CONTAINS ADDRESS OF 'GOOD' DATA
1048      001122      000000      $BDADR: .WORD 0     ;;CONTAINS ADDRESS OF 'BAD' DATA
1049      001124      000000      $GDDAT: .WORD 0    ;;CONTAINS 'GOOD' DATA
1050      001126      000000      $BDDAT: .WORD 0    ;;CONTAINS 'BAD' DATA
1051      001130      000000      .WORD 0           ;;RESERVED--NOT TO BE USED
1052      001132      000000      .WORD 0
1053      001134      000      $AUTOB: .BYTE 0         ;;AUTOMATIC MODE INDICATOR
1054      001135      000      $INTAG: .BYTE 0         ;;INTERRUPT MODE INDICATOR
1055      001136      000000      .WORD 0
1056      001140      177570      $SWR: .WORD $SWR      ;;ADDRESS OF SWITCH REGISTER
1057      001142      177570      $DISPLAY: .WORD $DDISP ;;ADDRESS OF DISPLAY REGISTER
1058      001144      177560      $TKS: 177560        ;;TTY KBD STATUS
1059      001146      177562      $TKB: 177562        ;;TTY KBD BUFFER
1060      001150      177564      $TPS: 177564        ;;TTY PRINTER STATUS REG. ADDRESS
1061      001152      177566      $TPB: 177566        ;;TTY PRINTER BUFFER REG. ADDRESS
1062      001154      000      $NULL: .BYTE 0       ;;CONTAINS NULL CHARACTER FOR FILLS
1063      001155      002      $FILLS: .BYTE 2        ;;CONTAINS # OF FILLER CHARACTERS REQUIRED
1064      001156      012      $FILLC: .BYTE 12       ;;INSERT FILL CHARS. AFTER A "LINE FEED"
1065      001157      000      $TFPLG: .BYTE 0     ;;"TERMINAL AVAILABLE" FLAG (BIT<07>=0=YES)
1066      001160      000000      $REGAD: .WORD 0     ;;CONTAINS THE ADDRESS FROM
1067      ;;WHICH ($REGO) WAS OBTAINED
1068      001162      000000      $REGO: .WORD 0      ;;CONTAINS (($REGAD)+0)
1069      001164      000000      $REG1: .WORD 0      ;;CONTAINS (($REGAD)+2)
1070      001166      000000      $REG2: .WORD 0      ;;CONTAINS (($REGAD)+4)
1071      001170      000000      $REG3: .WORD 0      ;;CONTAINS (($REGAD)+6)
1072      001172      000000      $REG4: .WORD 0      ;;CONTAINS (($REGAD)+10)
1073      001174      000000      $REG5: .WORD 0      ;;CONTAINS (($REGAD)+12)
1074      001176      000000      $REG6: .WORD 0      ;;CONTAINS (($REGAD)+14)
1075      001200      000000      $REG7: .WORD 0      ;;CONTAINS (($REGAD)+16)
1076      001202      000000      $REG10: .WORD 0     ;;CONTAINS (($REGAD)+20)
1077      001204      000000      $REG11: .WORD 0    ;;CONTAINS (($REGAD)+22)
1078      001206      000000      $TIMES: 0           ;;MAX. NUMBER OF ITERATIONS
1079      001210      000000      $ESCAPE: 0         ;;ESCAPE ON ERROR ADDRESS
1080      001212      077      $QUES: .ASCII ?/?   ;;QUESTION MARK
1081      001213      015      $CRLF: .ASCII <15> ;;CARRIAGE RETURN
1082      001214      000012      $LF: .ASCII <12>   ;;LINE FEED
1083      ;*****
1084      001216      005015      051104      053111      $MSG1: .ASCIIZ <15><12>/DRIVE PRESENT/

```

```

1085 001224 020105 051120 051505
1086 001232 052116 000
1087 001236 001236 .EVEN
1088 001236 005015 047516 042516 MSG2: .ASCIZ <15><12>/NONE/
1089 001244 000
1090
1091 001245 015 041412 052116 MSG3: .ASCIZ <15><12>/CNT RDY DIDN'T SET/
1092 001252 051040 054504 042040
1093 001260 042111 023516 020124
1094 001266 042523 000124
1095
1096 001272 005015 051104 053111 MSG4: .ASCIZ <15><12>/DRIVE /
1097 001300 020105 000
1098
1099 001303 015 040412 046114 MSG5: .ASCII <15><12>/ALL DRVS/
1100 001310 042040 053122 123
1101
1102 001315 040 051104 050117 MSG6: .ASCIZ / DROPD/<15><12>
1103 001322 006504 000012
1104 .EVEN
1105
1106 ;RK11 REGISTERS
1107 ;IF FOR ANY REASON THE REGISTER ADDRESSES ARE DIFFERENT FROM THESE
1108 ;{GIVEN BELOW}, THE CONTENTS OF THE APPROPRIATE POINTERS SHOULD BE
1109 ;MODIFIED SO THAT THE CORRECT ADDRESS IS USED.
1110 ;
1111 .EVEN
1112 001326 177400 RKDS: 177400
1113 001330 177402 RKER: 177402
1114 001332 177404 RKCS: 177404
1115 001334 177406 RKWC: 177406
1116 001336 177410 RKBA: 177410
1117 001340 177412 RKDA: 177412
1118 001342 177416 RKDB: 177416
1119
1120
1121 ;TAGS AND GENERAL DATA AREA
1122 ;
1123 ;
1124
1125 001344 000000 SIMUL: 0 ;FLAG TO BE SET TO 1 WHEN ON SIMULATOR
1126 001346 000000 FTITLE: 0 ;FLAG FOR PRINTING PROGRAM TITLE
1127 001350 000000 DRIVAD: 0 ;CONTAINS ADDRESS OF THE DRIVE UNDER TEST
1128 001352 000000 DRVDON: 0 ;CONTAINS THE NUMBER OF DRIVES CHECKED.
1129 ;IT IS INCREMENTED EACH TIME THE TESTS FOR
1130 ;A DRIVE IS COMPLETED.
1131 001354 000000 DRVPTR: 0 ;CONTAINS THE POINTER TO THE DRIVE FLAG (DRIVE0
1132 ;DRIVE7) OF THE DRIVE TO BE CHECKED NEXT.
1133 001356 000000 INDX1: 0 ;GENERAL INDEX FOR KEEPING COUNT
1134 001360 000000 INDX2: 0 ;GENERAL INDEX
1135 001362 000000 COUNT: 0 ;GENERAL COUNT REGISTER
1136 001364 000000 COUNT1: 0 ;COUNT REGISTER USED FOR 'DRESET' SUBROUTINE
1137 001366 000000 TIMER: 0 ;TIMER REGISTER
1138 001370 000000 EFLG1: 0 ;SET, TO INDICATE A PARTICULAR
1139 ;ERROR CONDITION
1140

```

```

1141 001372 000100 SEEK0: 100 ;CONTAINS ADDRESS OF CYLINDER 2
1142 001374 001000 SEEK1: 1000 ;CONTAINS ADDRESS OF CYLINDER 20
1143 001376 014500 SEEK2: 14500 ;CONTAINS ADDRESS OF CYLINDER 312
1144 001400 000200 RKPRI: 200 ;CONTAINS THE CPU LEVEL AT WHICH
1145 ;RK11 NORMALLY INTERRUPTS. THIS WORD
1146 ;SHOULD BE CHANGED IF RK11 IS DESINGATED
1147 ;A BR LEVEL OTHER THAN 5. E.G. IF IT IS CHANGED
1148 ;TO 6, THIS WORD SHOULD BE CHANGED TO 240.
1149 001402 000220 RKVEC: 220 ;CONTAINS THE NORMAL VECTOR ADDRESS TO WHICH
1150 ;RK11 INTERRUPTS. IF THIS IS NOT SO, CHANGE
1151 ;THIS WORD TO CONTAIN MODIFIED VECTOR ADDRESS.
1152 001404 000000 FFLAG: 0
1153 001406 000000 ODDEVN: 0 ;USED TO DETERMINE WHICH OF RK-05F DRIVES ACTIVE
1154 ;0 IF EVEN DRIVE
1155 ;-1 IF ODD DRIVE
1156 001410 000000 DDPCH: 0 ;IF PROGRAM LOADED FROM RK05, CONTAINS
1157 ;ADDRESS OF DRIVE WITH RKOP PACK
1158 001412 000000 DRVS: 0 ;CONTAINS THE NUMBER OF DRIVES PRESENT
1159
1160
1161
1162
1163 ;THE FLAGS BELOW (BIT 0) ARE SET TO 1 TO INDICATE THAT A PARTICULAR DRIVE
1164 ;IS PRESENT AND IS TO BE TESTED. BIT 12, IF SET, INDICATES THAT THE DRIVE
1165 ;WAS DROPPED AFTER MAXIMUM ALLOWABLE NUMBER OF ERRORS OCCURED ON THAT
1166 ;DRIVE (SW 6 SET).
1167 ;IF MORE THAN 5 ERRORS OCCUR IN THE HARDWARE POLLING TEST (LAST)
1168 ;THEN ALL DRIVES ARE DROPPED. BUT BIT 12 IS NOT SET.
1169
1170 001414 000000 DRIV0: 0 ;FLAG SET TO 1 WHEN DRIVE 0 PRESENT
1171 001416 000000 DRIV1: 0 ;FOR DRIVE 1
1172 001420 000000 DRIV2: 0 ;FOR DRIVE 2
1173 001422 000000 DRIV3: 0 ;FOR DRIVE 3
1174 001424 000000 DRIV4: 0 ;FOR DRIVE 4
1175 001426 000000 DRIV5: 0 ;FOR DRIVE 5
1176 001430 000000 DRIV6: 0 ;FOR DRIVE 6
1177 001432 000000 DRIV7: 0 ;FOR DRIVE 7
1178
1179 001434 000000 T56FLG: 0
1180 001436 000000 PHYDRV: 0
1181 001440 000000 SIZYET: 0

```

1182  
1183  
1184  
1185  
1186  
1187  
1188  
1189  
1190  
1191  
1192  
1193  
1194  
1195  
1196  
1197  
1198  
1199  
1200  
1201  
1202  
1203  
1204  
1205  
1206  
1207  
1208  
1209  
1210  
1211  
1212  
1213  
1214  
1215  
1216  
1217  
1218  
1219  
1220  
1221  
1222  
1223  
1224  
1225  
1226  
1227  
1228  
1229  
1230  
1231  
1232  
1233  
1234  
1235  
1236  
1237

001442

.SBTTL ERROR POINTER TABLE

;\*THIS TABLE CONTAINS THE INFORMATION FOR EACH ERROR THAT CAN OCCUR.  
;\*THE INFORMATION IS OBTAINED BY USING THE INDEX NUMBER FOUND IN  
;\*LOCATION \$ITEMB. THIS NUMBER INDICATES WHICH ITEM IN THE TABLE IS PERTINENT.  
;\*NOTE1: IF \$ITEMB IS 0 THE ONLY PERTINENT DATA IS (\$ERRPC).  
;\*NOTE2: EACH ITEM IN THE TABLE CONTAINS 4 POINTERS EXPLAINED AS FOLLOWS:

;\* EM            ::POINTS TO THE ERROR MESSAGE  
;\* DH            ::POINTS TO THE DATA HEADER  
;\* DT            ::POINTS TO THE DATA  
;\* DF            ::POINTS TO THE DATA FORMAT

\$ERRTB:

THE ERROR ITEMS TABLE CONSISTS OF ALL THE POSSIBLE ERROR MESSAGES  
USED IN THIS PROGRAM. AN ERROR CALL IN THE PROGRAM CORRESPONDS TO  
THE ITEM NUMBER IN THE ERROR TABLE. THUS 'ERROR 1' IN THE  
PROGRAM CORRESPONDS TO 'ITEM 1' IN THE ERROR TABLE.  
'EM###' IS THE POINTER TO THE ERROR MESSAGE WHICH WILL BE TYPED  
OUT IN CASE THAT ERROR WERE TO OCCUR. THUS FOR 'ERROR 1' THE ERROR  
MESSAGE TYPE OUT WILL BE 'TIME OUT ON RK11 REG'.  
'DH###' IS THE POINTER TO THE HEADER BLOCK WHICH WILL BE TYPED OUT  
IMMEDIATELY AFTER THE ERROR MESSAGE.  
'DT###' SERVES AS A POINTER TO THE MEMORY LOCATIONS WHERE  
THE INFORMATION RELEVANT TO THE ERROR TYPE OUTS (LIKE PC, CONTENTS  
OF RKCS ETC.) WILL BE PICKED UP FROM.  
THE LAST ROW CONTAINING '0' SERVES AS A TERMINATOR.  
EXAMPLE:  
IF ON RUNNING THIS PROGRAM A TIMEOUT WERE TO OCCUR ON ADDRESSING RKDS  
(177400), BECAUSE OF SOME FAULT, THE FOLLOWING TYPEOUT WOULD  
OCCUR ON THE TELETYPE.

```

;
;      TIME OUT ON RK11 REG
;      PC      REG
;      #####  177400
;

```

NOTE THAT ##### WOULD BE THE ACTUAL PC WHERE 'ERROR 1' IS LOCATED.

THE ERROR HANDLER IS LOCATED AT '\$ERROR'. THE ERROR CALL IS AN 'EMT'  
INSTRUCTION WITH ITS LOWER BYTE ENCODED TO PROVIDE INDEXING TO THE  
ITEMS IN THE ERROR TABLE.  
THUS 'ERROR 1' IS 104001  
'ERROR 103' IS 104126 ETC.

;ERROR ITEMS TABLE

1238  
1239  
1240  
1241  
1242  
1243  
1244  
1245  
1246  
1247  
1248  
1249  
1250  
1251  
1252  
1253  
1254  
1255  
1256  
1257  
1258  
1259  
1260  
1261  
1262  
1263  
1264  
1265  
1266  
1267  
1268  
1269  
1270  
1271  
1272  
1273  
1274  
1275  
1276  
1277  
1278  
1279  
1280  
1281  
1282  
1283  
1284  
1285  
1286  
1287  
1288  
1289  
1290  
1291  
1292  
1293

001442 025402  
001444 032327  
001446 031742  
001450 000000  
  
001452 027253  
001454 032113  
001456 031762  
001460 000000  
  
001462 025427  
001464 032047  
001466 031732  
001470 000000  
  
001472 025456  
001474 032213  
001476 031724  
001500 000000  
  
001502 025470  
001504 032155  
001506 031762  
001510 000000  
  
001512 025500  
001514 032155  
001516 031762  
001520 000000  
  
001522 025510  
001524 032213  
001526 031724  
001530 000000  
  
001532 025531  
001534 032327  
001536 031742  
001540 000000

;ITEM 1

```

EM12  ;'SIN' IS SET
DH44  ;PC  RKCS  RKER  RKDS  RKDA
DT20  ;$ERRPC $REG0 $REG1 $REG2 $REG3
0

```

;ITEM 2

```

EM70  ;CNTRL RDY DIDN'T SET ON READ/FMT FROM DISK ADDRESS
DH14  ;PC  RKCS  RKER  RKWC
DT26  ;$ERRPC $REG0 $REG1 $REG2
0

```

;ITEM 3

```

EM16  ;RKDA WRONG AFTER SSE
DH4   ;PC  EXPCT RECVD
DT2   ;$ERRPC $REG0 $REG1
0

```

;ITEM 4

```

EM21  ;RKDS ERROR
DH34  ;PC  RKDS
DT1   ;$ERRPC $REG0
0

```

;ITEM 5

```

EM30  ;'DPL' BIT SET, CHECK DRIVE POWER
DH30  ;PC  RKCS  RKER  RKDS
DT26  ;$ERRPC $REG0 $REG1 $REG2
0

```

;ITEM 6

```

EM31  ;'DRU' BIT SET, CHECK DRIVE
DH30  ;PC  RKCS  RKER  RKDS
DT26  ;$ERRPC $REG0 $REG1 $REG2
0

```

;ITEM 7

```

EM32  ;'RK05' BIT NOT SET
DH34  ;PC  RKDS
DT1   ;$ERRPC $REG0
0

```

;ITEM 10

```

EM33  ;'DRY' NOT SET
DH44  ;PC  RKCS  RKER  RKDS  RKDA
DT20  ;$ERRPC $REG0 $REG1 $REG2 $REG3
0

```

1294			;ITEM	11	
1295					
1296	001542	025551		EM34	;'SDK' DID NOT SET
1297	001544	032213		DH34	;PC RKDS
1298	001546	031724		DT1	;\$ERRPC \$REGO
1299	001550	000000		0	
1300					
1301			;ITEM	12	
1302					
1303	001552	025570		EM35	;'SEC COUNTR' DIDN'T COUNT TO 0
1304	001554	032231		DH35	;PC SEC-CNTR
1305	001556	031724		DT1	;\$ERRPC \$REGO
1306	001560	000000		0	
1307					
1308			;ITEM	13	
1309					
1310	001562	025623		EM36	;'SEC COUNTR' DIDN'T INCREMENT
1311	001564	032251		DH36	;PC PRSNT-COUNT NXT-COUNT
1312	001566	031732		DT2	;\$ERRPC \$REGO \$REG1
1313	001570	000000		0	
1314					
1315			;ITEM	14	
1316					
1317	001572	025653		EM37	;'SECTOR COUNTER' INCREMENTED WRONG
1318	001574	032047		DH4	;PC EXPCTD RECVD
1319	001576	031732		DT2	;\$ERRPC \$REGO \$REG1
1320	001600	000000		0	
1321					
1322			;ITEM	15	
1323					
1324	001602	025707		EM40	;'DIDN'T GET SC-SA FOR THIS SECTOR
1325	001604	032301		DH40	;PC SECTOR RKDS
1326	001606	031732		DT2	;\$ERRPC \$REGO \$REG1
1327	001610	000000		0	
1328					
1329			;ITEM	16	
1330					
1331	001612	025747		EM41	;'ERROR-'R/W/S R/W' SHOULD BE SET
1332	001614	032213		DH34	;PC RKDS
1333	001616	031724		DT1	;\$ERRPC \$REGO
1334	001620	000000		0	
1335					
1336			;ITEM	17	
1337					
1338	001622	025415		EM13	;RKBA ERROR
1339	001624	032047		DH4	;PC EXPCT RECVD
1340	001626	031732		DT2	;\$ERRPC \$REGO \$REG1
1341	001630	000000		0	
1342					
1343			;ITEM	20	
1344					
1345	001632	026004		EM43	;'UNEXPECTED RK11 INTERRUPT
1346	001634	032150		DH21	;PC
1347	001636	031756		DT21	;\$ERRPC
1348	001640	000000		0	
1349					

1350			;ITEM	21	
1351					
1352	001642	026036		EM44	;'CNTRL RDY' DIDN'T SET AFTER SEEK OR DRIVE RESET
1353	001644	032327		DH44	;PC RKCS RKER RKDS RKDA
1354	001646	031742		DT20	;\$ERRPC \$REGO \$REG1 \$REG2 \$REG3
1355	001650	000000		0	
1356					
1357			;ITEM	22	
1358					
1359	001652	026112		EM45	;'ERR' OR 'HE' SET ON SEEK OR DRIVE RESET
1360	001654	032327		DH44	;PC RKCS RKER RKDS RKDA
1361	001656	031742		DT20	;\$ERRPC \$REGO \$REG1 \$REG2 \$REG3
1362	001660	000000		0	
1363					
1364			;ITEM	23	
1365					
1366	001662	026160		EM46	;'RKER BIT, ON SEEK OR DRIVE RESET
1367	001664	032155		DH30	;PC RKCS RKER RKDS
1368	001666	031762		DT26	;\$ERRPC \$REGO \$REG1 \$REG2
1369	001670	000000		0	
1370					
1371			;ITEM	24	
1372					
1373	001672	026216		EM47	;'RKCS CHANGED AFTER FUNCTION WAS DONE
1374	001674	032047		DH4	;PC EXPCT RECVD
1375	001676	031732		DT2	;\$ERRPC \$REGO \$REG1
1376	001700	000000		0	
1377					
1378			;ITEM	25	
1379					
1380	001702	026260		EM50	;'R/W/S RDY' DID NOT CLEAR
1381	001704	032155		DH30	;PC RKCS RKER RKDS
1382	001706	031762		DT26	;\$ERRPC \$REGO \$REG1 \$REG2
1383	001710	000000		0	
1384					
1385			;ITEM	26	
1386					
1387	001712	026307		EM51	;'R/W/S RDY' DIDN'T SET AFTER SEEK OR DRIVE RESET
1388	001714	032327		DH44	;PC RKCS RKER RKDS RKDA
1389	001716	031742		DT20	;\$ERRPC \$REGO \$REG1 \$REG2 \$REG3
1390	001720	000000		0	
1391					
1392			;ITEM	27	
1393					
1394	001722	026362		EM52	;'RKDA CHANGED AFTER SEEK
1395	001724	032047		DH4	;PC EXPCTD REGVD
1396	001726	031732		DT2	;\$ERRPC \$REGO \$REG1
1397	001730	000000		0	
1398					
1399			;ITEM	30	
1400					
1401	001732	026407		EM53	;'CNTRL RDY' DIDN'T CLEAR AS GO WAS SET
1402	001734	032155		DH30	;PC RKCS RKER RKDS
1403	001736	031762		DT26	;\$ERRPC \$REGO \$REG1 \$REG2
1404	001740	000000		0	
1405					

```
1406 ;ITEM 31
1407 EM54 ;'CNTRL RDY' DIDN'T SET ON DOING WRITE/FMT STARTING
1408 001742 026452 ; FROM <DSK-ADRES>
1409 DH54 ;PC RKCS RKER RKDS RKDA
1410 001744 032374 ;DRV# CYL <DSK-ADRES> SUR SECTR
1411 DT54 ;$ERRPC $REG0 $REG1 $REG2 $REG3
1412 001746 031774 ;$REG4 $REG5 $REG6 $REG7
1413 0
1414 001750 000000
1415 ;ITEM 32
1416 EM55 ;'HE' OR 'ERR' ON WRITE/FMT STARTING FROM
1417 ;<DSK-ADRES>
1418 001752 026544 ;PC RKCS RKER RKDS RKDA
1419 001754 032374 ;DRV# CYL <DSK-ADRES> SUR SECTR
1420 DT54 ;$ERRPC $REG0 $REG1 $REG2 $REG3
1421 001756 031774 ;$REG4 $REG5 $REG6 $REG7
1422 001760 000000
1423 ;ITEM 33
1424 EM56 ;RKDA INCREMENTED WRONG ON WRITE OR WRITE FORMAT
1425 DH56 ;PC EXPCT: DRV# CYL SUR SECTR
1426 001762 026623 ;RECVD: DRV# CYL SUR SECTR
1427 001764 032503 ;$ERRPC $REG0 $REG1 $REG2 $REG3
1428 001766 031774 ;$REG4 $REG5 $REG6 $REG7
1429 001770 000000
1430 ;ITEM 34
1431 EM57 ;RKWC DIDN'T OVERFLOW ON WRITE OR WRITE FORMAT
1432 DH5 ;PC RECVD
1433 001772 026662 DT1 ;$ERRPC $REG0
1434 001774 032075 0
1435 001776 031724 ;ITEM 35
1436 EM60 ;RKBA INCREMENTED WRONG ON WRITE OR WRITE FORMAT
1437 002002 026720 ;PC EXPCT RECVD
1438 002004 032047 DT2 ;$ERRPC $REG0 $REG1
1439 002006 031732 0
1440 002010 000000 ;ITEM 36
1441 EM61 ;RKER SET, ON WRITE/READ/FORMAT
1442 002012 026757 ;PC RKCS RKER RKDS
1443 002014 032155 DT26 ;$ERRPC $REG0 $REG1 $REG2
1444 002016 031762 0
1445 002020 000000 ;ITEM 37
1446 EM62 ;RKDB ERROR
1447 002022 027014 DH4 ;PC EXPCT RECVD
1448 002024 032047 DT2 ;$ERRPC $REG0 $REG1
1449 002026 031732 0
1450 002030 000000
```

```
1462 ;ITEM 40
1463 EM63 ;RKDA INCREMENTED WRONG ON READ OR READ FORMAT
1464 002032 027026 ;PC EXPCT: DRV# CYL SUR SECTR
1465 002034 032503 ;RECVD: DRV# CYL SUR SECTR
1466 002036 031774 DT54 ;$ERRPC $REG0 $REG1 $REG2 $REG3
1467 ;$REG4 $REG5 $REG6 $REG7
1468 002040 000000 0
1469 ;ITEM 41
1470 EM64 ;RKWC DID NOT OVERFLOW ON READ OR READ FORMAT
1471 DH64 ;PC RKWC RKDA
1472 002042 027072 DT2 ;$ERRPC $REG0 $REG1
1473 002044 032610 0
1474 002046 031732 ;ITEM 42
1475 EM65 ;RKBA INCREMENTED WRONG ON READ OR READ FORMAT
1476 DH4 ;PC EXPCT RECVD
1477 002050 000000 DT2 ;$ERRPC $REG0 $REG1
1478 002052 027135 0
1479 002054 032047 ;ITEM 43
1480 EM66 ;INCORRECT HEADER FROM 'SECTOR'
1481 002056 031732 DH66 ;PC SECTR EXPCT RECVD
1482 002060 000000 DT26 ;$ERRPC $REG0 $REG1 $REG2.
1483 002062 027201 0
1484 002064 032634 ;ITEM 44
1485 002066 031762 EM67 ;DATA ERROR
1486 002070 000000 DH67 ;PC EXPCT RECVD DSK-ADRES
1487 002072 027240 DT26 ;$ERRPC $REG0 $REG1 $REG2
1488 002074 032672 0
1489 002076 031762 ;ITEM 45
1490 002100 000000 EM70 ;'CNTRL RDY' DIDN'T SET ON DOING READ/FMT STARTING
1491 ; FROM <DSK-ADRES>
1492 002102 027253 DH54 ;PC RKCS RKER RKDS RKDA
1493 002104 032374 ;DRV# CYL <DSK-ADRES> SUR SECTR
1494 002106 031774 DT54 ;$ERRPC $REG0 $REG1 $REG2 $REG3
1495 002110 000000 ;$REG4 $REG5 $REG6 $REG7
1496 002112 027344 ;ITEM 46
1497 002114 032374 EM71 ;'HE' OR 'ERR' BIT SET ON READ/FMT STARTING
1498 002116 031774 DH54 ; FROM <DSK-ADRES>
1499 ;PC RKCS RKER RKDS RKDA
1500 ;DRV# CYL <DSK-ADRES> SUR SECTR
1501 ;$ERRPC $REG0 $REG1 $REG2 $REG3
1502 ;$REG4 $REG5 $REG6 $REG7
```

1518	002120	000000		0
1519				
1520			:ITEM	47
1521				
1522	002122	027422	EM72	:WRONG DRIVE ID IN RKDS AFTER SEEK
1523	002124	032047	DH4	:PC EXPCT RECVD
1524	002126	031732	DT2	;\$ERRPC \$REGO \$REG1
1525	002130	000000		0
1526				
1527			:ITEM	50
1528				
1529	002132	027464	EM73	:HARDWARE POLL, DRIVE ID BITS(13-15) SHOULD BE CLEAR
1530	002134	032213	DH34	:PC RKDS
1531	002136	031732	DT2	;\$ERRPC \$REGO
1532	002140	000000		0
1533				
1534			:ITEM	51
1535				
1536	002142	027536	EM74	:HARDWARE POLL, INTERRUPTING DRIVE # NOT PRESENT
1537	002144	032732	DH74	:PC DRIVE #
1538	002146	031724	DT1	;\$ERRPC \$REGO
1539	002150	000000		0
1540				
1541			:ITEM	52
1542				
1543	002152	027606	EM75	:'DRIVE #' DID NOT INTERRUPT DURING HARDWARE POLL
1544	002154	032732	DH74	:PC DRIVE #
1545	002156	031724	DT1	;\$ERRPC \$REGO
1546	002160	000000		0
1547				
1548			:ITEM	53
1549				
1550	002162	027656	EM76	:SCP DID NOT SET AFTER WAS DONE
1551	002164	033106	DH117	:PC RKCS
1552	002166	031724	DT1	;\$ERRPC \$REGO
1553	002170	000000		0
1554				
1555			:ITEM	54
1556				
1557	002172	027721	EM77	:RKDA CHANGED AFTER 'DRIVE RESET'
1558	002174	032047	DH4	:PC EXPCT RECVD
1559	002176	031732	DT2	;\$ERRPC \$REGO \$REG1
1560	002200	000000		0
1561				
1562			:ITEM	55
1563				
1564	002202	027756	EM100	:DATA ERROR AT WORD#
1565	002204	032753	DH100	:PC WORD# EXPCT RECVD
1566	002206	031762	DT26	;\$ERRPC \$REGO \$REG1 \$REG2
1567	002210	000000		0
1568				
1569			:ITEM	56
1570				
1571	002212	030001	EM101	:CNTRL RDY DID NOT SET AFTER READ CHECK
1572	002214	032327	DH44	:PC RKCS RKER RKDS RKDA
1573	002216	031742	DT20	;\$ERRPC \$REGO \$REG1 \$REG2 \$REG3

1574	002220	000000		0
1575				
1576			:ITEM	57
1577				
1578	002222	030043	EM102	:'ERR' OF 'HE' SET ON READ CHECK
1579	002224	032155	DH30	:PC RKCS RKER RKDS
1580	002226	031762	DT26	;\$ERRPC \$REGO \$REG1 \$REG2
1581	002230	000000		0
1582				
1583			:ITEM	60
1584				
1585	002232	030067	EM103	:'CSE' ON READ CHECK
1586	002234	033010	DH103	:PC RKER
1587	002236	031724	DT1	;\$ERRPC \$REGO
1588	002240	000000		0
1589				
1590			:ITEM	61
1591				
1592	002242	030105	EM104	:RKWC DID NOT OVERFLOW ON READ CHECK OR WRITE CHECK
1593	002244	033024	DH104	:PC RECVD RKCS
1594	002246	031732	DT2	;\$ERRPC \$REGO \$REG1
1595	002250	000000		0
1596				
1597			:ITEM	62
1598				
1599	002252	030156	EM105	:RKDA INCREMENTED WRONG ON READ CHECK
1600	002254	032047	DH4	:PC EXPCT RECVD
1601	002256	031732	DT2	;\$ERRPC \$REGO \$REG1
1602	002260	000000		0
1603				
1604			:ITEM	63
1605				
1606	002262	030214	EM106	:RKBA CHANGED AFTER READ CHECK
1607	002264	032047	DH4	:PC EXPCT RECVD
1608	002266	031732	DT2	;\$ERRPC \$REGO \$REG1
1609	002270	000000		0
1610				
1611			:ITEM	64
1612				
1613	002272	030245	EM107	:MEMORY WORD CHANGED AFTER READ CHECK
1614	002274	033050	DH107	:PC LOC EXPCT RECVD
1615	002276	031762	DT26	;\$ERRPC \$REGO \$REG1 \$REG2
1616	002300	000000		0
1617				
1618			:ITEM	65
1619				
1620	002302	030306	EM110	:CNTRL RDY DID NOT SET AFTER WRITE CHECK
1621	002304	032327	DH44	:PC RKCS RKER RKDS RKDA
1622	002306	031742	DT20	;\$ERRPC \$REGO \$REG1 \$REG2 \$REG3
1623	002310	000000		0
1624				
1625			:ITEM	66
1626				
1627	002312	030351	EM111	:HE OR ERR BIT SET AFTER DOING WRITE CHECK
1628	002314	032155	DH30	:PC RKCS RKER RKDS
1629	002316	031762	DT26	;\$ERRPC \$REGO \$REG1 \$REG2

1630	002320	000000		0
1631				
1632			:ITEM	67
1633				
1634	002322	030376	EM112	:WRITE CHECK ERROR
1635	002324	032155	DH30	:PC RKCS RKER RKDS
1636	002326	031762	DT26	:\$ERRPC \$REG0 \$REG1 \$REG2
1637	002330	000000		0
1638				
1639			:ITEM	70
1640				
1641	002332	030417	EM113	:RKDA INCREMENTED WRONG ON WRITE CHECK
1642	002334	032047	DH4	:PC EXPCT RECVD
1643	002336	031732	DT2	:\$ERRPC \$REG0 \$REG1
1644	002340	000000		0
1645				
1646			:ITEM	71
1647				
1648	002342	030456	EM114	:RKBA INCREMENTED WRONG ON WRITE CHECK
1649	002344	032047	DH4	:PC EXPCT RECVD
1650	002346	031732	DT2	:\$ERRPC \$REG0 \$REG1
1651	002350	000000		0
1652				
1653			:ITEM	72
1654				
1655	002352	030515	EM115	:RKBA INCREMENTED WITH IBA SET
1656	002354	032047	DH4	:PC EXPCT RECVD
1657	002356	031732	DT2	:\$ERRPC \$REG0 \$REG1
1658	002360	000000		0
1659				
1660			:ITEM	73
1661				
1662	002362	030551	EM116	:WRONG MEMORY LOCATION CHANGED WITH IBA SET
1663	002364	032753	DH100	:PC WORD# EXPCT RECVD
1664	002366	031762	DT26	:\$ERRPC \$REG0 \$REG1 \$REG2
1665	002370	000000		0
1666				
1667			:ITEM	74
1668				
1669	002372	030624	EM117	:RK11 DID NOT INTERRUPT WHEN IDE WAS SET
1670	002374	033106	DH117	:PC RKCS
1671	002376	031724	DT1	:\$ERRPC \$REG0
1672	002400	000000		0
1673				
1674			:ITEM	75
1675				
1676	002402	030671	EM120	:RK11 DID NOT INTERRUPT AFTER SEEK WAS INITIATED
1677	002404	033106	DH117	:PC RKCS
1678	002406	031724	DT1	:\$ERRPC \$REG0
1679	002410	000000		0
1680				
1681			:ITEM	76
1682				
1683	002412	030744	EM121	:SCP SET BEFORE SEEK COMPLETED
1684	002414	033106	DH117	:PC RKCS
1685	002416	031724	DT1	:\$ERRPC \$REG0

1686	002420	000000		0
1687				
1688			:ITEM	77
1689				
1690	002422	031002	EM122	:RK11 DID NOT INTERRUPT AFTER SEEK COMPLETED
1691	002424	032155	DH30	:PC RKCS RKER RKDS
1692	002426	031762	DT26	:\$ERRPC \$REG0 \$REG1 \$REG2
1693	002430	000000		0
1694				
1695			:ITEM	100
1696				
1697	002432	031051	EM123	:CNTRL RESET DID NOT CLEAR 'SCP' BIT
1698	002434	033106	DH117	:PC RKCS
1699	002436	031724	DT1	:\$ERRPC \$REG0
1700	002440	000000		0
1701				
1702			:ITEM	101
1703				
1704	002442	031110	EM124	:RK11 DID NOT INTERRUPT AFTER READ WAS DONE
1705	002444	033106	DH117	:PC RKCS
1706	002446	031724	DT1	:\$ERRPC \$REG0
1707	002450	000000		0
1708				
1709			:ITEM	102
1710				
1711	002452	031152	EM125	:CNTRL RESET DID NOT CLEAR REGISTER
1712	002454	032020	DH2	:PC REGADD RECVD
1713	002456	031732	DT2	:\$ERRPC \$REG0 \$REG1
1714	002460	000000		0
1715				
1716			:ITEM	103
1717				
1718	002462	031211	EM126	:RK11 DID NOT INTERRUPT AT CPU LEVEL
1719	002464	033122	DH126	:PC LEVEL RKCS
1720	002466	031732	DT2	:\$ERRPC \$REG0 \$REG1
1721	002470	000000		0
1722				
1723			:ITEM	104
1724				
1725	002472	031252	EM127	:RK11 INTERRUPTED AT WRONG CPU LEVEL
1726	002474	033122	DH126	:PC LEVEL RKCS
1727	002476	031732	DT2	:\$ERRPC \$REG0 \$REG1
1728	002500	000000		0
1729				
1730			:ITEM	105
1731				
1732	002502	031314	EM130	: 'ERR BIT' DID NOT SET IN RKER
1733	002504	033150	DH130	:PC RKCS RKER ERR BIT
1734	002506	031762	DT26	:\$ERRPC \$REG0 \$REG1 \$REG2
1735	002510	000000		0
1736				
1737				
1738			:ITEM	106
1739				
1740	002512	031351	EM131	:HE OR ERR DID NOT SET
1741	002514	033207	DH131	:PC RKCS RKER



1742	002516	031732	DT2	;\$ERRPC \$REGO	\$REG1		
1743	002520	000000	0				
1744							
1745			;ITEM	107			
1746							
1747	002522	031376	EM132	;\$RKER ERROR			
1748	002524	032047	DH4	;\$PC EXPCT	RECVD		
1749	002526	031732	DT2	;\$ERRPC \$REGO	\$REG1		
1750	002530	000000	0				
1751							
1752			;ITEM	110			
1753							
1754	002532	031410	EM133	;\$NXC BIT DID NOT SET			
1755	002534	033235	DH133	;\$PC RKCS	RKER	RKDA	
1756	002536	031762	DT26	;\$PC \$REGO	\$REG1	\$REG2	
1757	002540	000000	0				
1758							
1759			;ITEM	111			
1760							
1761	002542	031433	EM134	;\$RK11 DIDN'T INTERRUPT ON SOFT ERROR			
1762	002544	033207	DH131	;\$PC RKCS	RKER		
1763	002546	031732	DT2	;\$ERRPC \$REGO	\$REG1		
1764	002550	000000	0				
1765							
1766			;ITEM	112			
1767							
1768	002552	031474	EM135	;\$MEX BITS INCREMENTED WRONG IN RKCS			
1769	002554	032047	DH4	;\$PC EXPCTD	RECVD		
1770	002556	031732	DT2	;\$ERRPC \$REGO	\$REG1		
1771	002560	000000	0				
1772							
1773			;ITEM	113			
1774							
1775	002562	030306	EM110	;\$CNTRL RDY DID NOT SET AFTER WRT CHK			
1776	002564	032113	DH14	;\$PC RKCS	RKER	RKWC	
1777	002566	031762	DT26	;\$ERRPC \$REGO	\$REG1	\$REG2	
1778	002570	000000	0				
1779							
1780			;ITEM	114			
1781							
1782	002572	031531	EM137	;\$'WPS' NOT CLEAR			
1783	002574	032327	DH44	;\$PC RKCS	RKER	RKDS	RKDA
1784	002576	031742	DT20	;\$ERRPC \$REGO	\$REG1	\$REG2	\$REG3
1785	002600	000000	0				
1786							
1787			;ITEM	115			
1788							
1789	002602	031547	EM140	;\$DATA ERROR ON TRANSFER FROM DISK TO TTY			
1790	002604	033273	DH140	;\$PC EXPCT	RECVD	RKBA	RKCS
1791	002606	031742	DT20	;\$ERRPC \$REGO	\$REG1	\$REG2	\$REG3
1792	002610	000000	0				
1793							
1794							
1795			;ITEM	116			
1796							
1797	002612	031616	EM141	;\$'DRIVE #' PRESENT, BUT NOT SPECIFIED			

1798	002614	032732	DH74	;\$PC DRIVE #			
1799	002616	031724	DT1	;\$ERRPC \$REGO			
1800	002620	000000	0				
1801							
1802			;ITEM	117			
1803							
1804	002622	025370	EM11	;\$RKWC ERROR			
1805	002624	032047	DH4	;\$PC EXPCT	RECVD		
1806	002626	031732	DT2	;\$ERRPC \$REGO	\$REG1		
1807	002630	000000	0				
1808							
1809	002632	031662	;ITEM	120			
1810	002634	000000	EM142				
1811			0				
1812							
1813							

```

1814 002636 000005          START: RESET          ;CLEAR THE BUS
1815          ;;GIVE DRIVES TIME TO LOAD HEADS IN CASE OF AN APT START.
1816 002640 023737 000042 000046 CMP @#42,@#46          ;ARE WE IN ACT11 AUTOMATIC MODE?
1817 002646 001016          BNE STARTA          ;NO, SKIP DELAY
1818 002650 005077 176464          CLR @RKDA          ;SELECT UNIT 0
1819 002654 012700 000250          MOV #250,R0          ;WAIT FOR..
1820 002660 032777 000200 176440 20$: BIT #200,@RKDS          ;DRIVE READY..
1821 002666 001006          BNE STARTA          ;IN CASE..
1822 002670 005001          CLR R1          ;OF APT..
1823 002672 005301          DEC R1          ;START, BUT..
1824 002674 001376          BNE .-2          ;DON'T WAIT..
1825 002676 005300          DEC R0          ;FOREVER.
1826 002700 001367          BNE 20$
1827 002702 000000          HALT          ;RKDS BIT 7 (DRIVE READY) N'VER SET
1828 002704
1829
1830          STARTA:
1831          .SBTTL INITIALIZE THE COMMON TAGS
1832          ;;CLEAR THE COMMON TAGS ($SCMTAG) AREA
1833 002704 012706 001100          MOV #SCMTAG,R6          ;FIRST LOCATION TO BE CLEARED
1834 002710 005026          CLR (R6)+          ;CLEAR MEMORY LOCATION
1835 002712 022706 001140          CMP #SWR,R6 ;DONE?
1836 002716 001374          BNE .-6          ;LOOP BACK IF NO
1837 002720 012706 001100          MOV #STACK,SP          ;SETUP THE STACK POINTER
1838
1839          ;;INITIALIZE A FEW VECTORS
1840 002724 012737 022140 000020          MOV #SCOPE,@#IOTVEC ;IOT VECTOR FOR SCOPE ROUTINE
1841 002732 012737 000340 000022          MOV #340,@#IOTVEC+2 ;LEVEL 7
1842 002740 012737 022412 000030          MOV #ERROR,@#EMTVEC ;EMT VECTOR FOR ERROR ROUTINE
1843 002746 012737 000340 000032          MOV #340,@#EMTVEC+2 ;LEVEL 7
1844 002754 012737 024676 000034          MOV #STRAP,@#TRAPVEC ;TRAP VECTOR FOR TRAP CALLS
1845 002762 012737 000340 000036          MOV #340,@#TRAPVEC+2;LEVEL 7
1846 002770 012737 024776 000024          MOV #SPWRDN,@#PWRVEC ;POWER FAILURE VECTOR
1847 002776 012737 000340 000026          MOV #340,@#PWRVEC+2 ;LEVEL 7
1848 003004 005037 001206          CLR $TIMES          ;INITIALIZE NUMBER OF ITERATIONS
1849 003010 005037 001210          CLR $ESCAPE          ;CLEAR THE ESCAPE ON ERROR ADDRESS
1850 003014 112737 000001 001115          MOV #1,$SERMAX          ;ALLOW ONE ERROR PER TEST
1851 003022 012737 003022 001106          MOV #.,$LPADR          ;INITIALIZE THE LOOP ADDRESS FOR SCOPE
1852 003030 012737 003030 001110          MOV #.,$LPERR          ;SETUP THE ERROR LOOP ADDRESS
1853
1854          ;;SIZE FOR A HARDWARE SWITCH REGISTER. IF NOT FOUND OR IT IS
1855          ;;EQUAL TO A "-1" SETUP FOR A SOFTWARE SWITCH REGISTER.
1856 003036 013746 000004          MOV @#ERRVEC,-(SP) ;SAVE ERROR VECTOR
1857 003042 012737 003076 000004          MOV #64$,@#ERRVEC ;SET UP ERROR VECTOR
1858 003050 012737 177570 001140          MOV #DDSWR,SWR ;SETUP FOR A HARDWARE SWITCH REGISTER
1859 003056 012737 177570 001142          MOV #DDDISP,DISPLAY ;AND A HARDWARE DISPLAY REGISTER
1860 003064 022777 177777 176046          CMP #-1,@SWR ;TRY TO REFERENCE HARDWARE SWR
1861 003072 001012          BNE 66$ ;BRANCH IF NO TIMEOUT TRAP OCCURRED
1862
1863          ;AND THE HARDWARE SWR IS NOT = -1
1864 003074 000403          BR 65$ ;BRANCH IF NO TIMEOUT
1865 003076 012716 003104          64$: MOV #65$,(SP) ;SET UP FOR TRAP RETURN
1866 003102 000002          RTI
1867 003104 012737 000176 001140          65$: MOV #SWREG,SWR ;POINT TO SOFTWARE SWR
1868 003112 012737 000174 001142          MOV #DISPREG,DISPLAY
1869 003120 012637 000004          66$: MOV (SP)+,@#ERRVEC ;RESTORE ERROR VECTOR
1870
1871          67$:
1872 003124 023737 000042 000046          CMP @#42,@#46          ;ARE WE IN ACT11 AUTOMATIC MODE?
1873 003132 001416          BEQ 69$          ;YES, SKIP TITLE
1874
1875          .SBTTL TYPE PROGRAM NAME
1876          ;;TYPE THE NAME OF THE PROGRAM IF FIRST PASS
1877
1878
1879
1880
1881
1882
1883
1884
1885
1886
1887
1888
1889
1890
1891
1892
1893
1894
1895
1896
1897
1898
1899
1900
1901
1902
1903
1904
1905
1906
1907
1908
1909
1910
1911
1912
1913
1914
1915
1916
1917
1918
1919
1920
1921
1922
1923
1924
1925

```

```

1870 003134 005227 177777          INC #-1          ;FIRST TIME?
1871 003140 001043          BNE 67$          ;BRANCH IF NO
1872 003142 104401 003200          TYPE ,68$          ;TYPE ASCIZ STRING
1873          .SBTTL GET VALUE FOR SOFTWARE SWITCH REGISTER
1874 003146 005737 000042          TST @#42          ;ARE WE RUNNING UNDER XXDP/ACT?
1875 003152 001006          BNE 69$          ;BRANCH IF YES
1876 003154 023727 001140 000176          CMP SWR,#SWREG          ;SOFTWARE SWITCH REG SELECTED?
1877 003162 001005          BNE 70$          ;BRANCH IF NO
1878 003164 104406          GTSWR          ;GET SOFT-SWR SETTINGS
1879 003166 000403          BR 70$
1880 003170 112737 000001 001134          69$: MOV #1,$AUTOB          ;SET AUTO-MODE INDICATOR
1881 003176          70$:
1882 003176 000424          BR 67$          ;GET OVER THE ASCIZ
1883          ;;68$: .ASCIZ <CRLF>/RK11 LOGIC TEST 2/<15><12>/MAINDEC-11-CZRKKF/<CRLF>
1884          67$:
1885 003250 012700 001410          MOV #DDPCH,R0
1886 003254 012701 177764          MOV #-14,R1
1887 003260 005020          1$: CLR (R0)+          ;CLEAR OUT DRIVE TABLE AREA
1888 003262 005201          INC R1
1889 003264 001375          BNE 1$
1890 003266 005227 177777          INC #-1          ;FIRST START ?
1891 003272 001020          BNE START1          ;BR IF NOT
1892 003274 013746 000004          MOV ERRVEC,-(SP) ;SAVE ERROR VECTOR ADDRESS
1893 003300 012737 003314 000004          MOV #2$,ERRVEC ;NEW VECTOR ADDRESS
1894 003306 005737 177776          TST PS          ;SEE IF PROGRAM CAN REFERENCE THE
1895          ;PROCESSOR STATUS WORD
1896 003312 000406          BR 3$          ;BR IF REFERENCE DIDN'T CAUSE TRAP
1897 003314 012737 000140 001400          2$: MOV #140,RKPRI          ;SETUP INTERRUPTING PRIORITY TO VALUE
1898          ;WHICH WILL ALLOW INTERRUPT ON AN LSI-11
1899 003322 012716 003330          MOV #3$,(SP)          ;SETUP RETURN ADDRESS
1900 003326 000002          RTI          ;RETURN
1901 003330 012637 000004          3$: MOV (SP)+,ERRVEC ;RESTORE THE ERROR VECTOR
1902
1903
1904
1905
1906
1907
1908
1909
1910
1911
1912
1913
1914
1915
1916
1917
1918
1919
1920
1921
1922
1923
1924
1925

```

```

1926      ;:65$: .ASCIZ <15><12>/NOT TESTING DRIVE /
1927      64$:
1928      CLR      -(SP)      ;CLEAR WORD ON STACK
1929      MOVB     DDPCH,(SP) ;GET DRIVE ADDRESS
1930      TYPOS    ;TYPE THE ADDRESS
1931      .BYTE    1          ;ONLY 1 CHARACTER
1932      .BYTE    0          ;SUPPRESS LEADING ZEROS
1933      JMP      ST3        ;GET NUMBER OF DRIVES
1934      4$: INC      #-1     ;FIRST TIME THROUGH HERE ?
1935      BNE     ST2        ;BR IF NOT
1936      TYPE     ,67$      ;;TYPE ASCIZ STRING
1937      BR      66$       ;;GET OVER THE ASCIZ
1938
1939      ;:67$: .ASCIZ <15><12>/TO TEST DRIVE /
1940      66$:
1941      CLR      -(SP)      ;CLEAR WORD ON THE STACK
1942      MOVB     DDPCH,(SP) ;GET DRIVE ADDRESS
1943      TYPOS    ;TYPE THE DRIVE ADDRESS
1944      .BYTE    1          ;ONLY 1 CHARACTER
1945      .BYTE    0          ;SUPPRESS LEADING ZEROS
1946      TYPE     ,69$      ;;TYPE ASCIZ STRING
1947      BR      68$       ;;GET OVER THE ASCIZ
1948
1949      ;:69$: .ASCIZ / HALT PROGRAM, REMOVE RKDP PACK AND REPLACE IT/<15><12>
1950      68$:
1951      TYPE     ,71$      ;;TYPE ASCIZ STRING
1952      BR      70$       ;;GET OVER THE ASCIZ
1953
1954      ;:71$: .ASCIZ /WITH A WORK PACK, CLEAR LOCATION 40, AND RESTART PROGRAM/
1955      70$:
1956      ;FIND OUT FROM USER WHICH DRIVES (LOGICAL ADDRESSES) ARE TO BE
1957      ;TESTED (DRIVES TO BE TESTED ?). IN REPLY THE USER SHOULD TYPE IN THE
1958      ;LOGICAL ADDRESSES SEPERATED BY COMMAS. THUS IF 2 DRIVES 0,1 ARE PRESENT:
1959      ;
1960      ; 'DRIVS TO B TSTD?'
1961      ; '0,1<CR>' A CAR. RET. SHOULD BE TYPED TO TERMINATE THE LIST.
1962      ST2: MOV      #DRIVS,R0
1963      MOV      #-13,R1
1964      13$: CLR      (R0)+
1965      INC      R1
1966      BNE     13$
1967      TYPE     ,65$      ;;TYPE ASCIZ STRING
1968      BR      64$       ;;GET OVER THE ASCIZ
1969
1970      ;:65$: .ASCIZ <15><12>/DRIVES TO BE TESTED ?/<15><12>
1971      64$:
1972      RDLIN    (SP)+,R0    ;GET STARTING ADRES OF ASCII STRING
1973      MOV      #-10,R1    ;SET UP COUNT
1974      MOVB     (R0)+,R2    ;GET ASCII CHARACTER
1975      BIC      #177400,R2 ;MASK UNWANTED BITS
1976      MOV      #DRIVO,R3
1977      MOV      #-10,R4
1978      MOV      #60,R5
1979      2$: CMP      R5,R2    ;WAS THE TYPED IN CHARACTER
1980      BEQ     3$          ;A NUMBER BETWEEN 0-7?
1981      INC      R5          ;YES, BRANCH
1982      INC      (R3)+      ;NO, INCREMENT
1983      INC      R4          ;INCREMENT POINTER TO DRV FLAG
1984      INC      R4          ;CHARACTER THAT WAS INPUT

```

```

1982      BNE     2$          ;SHOULD BE 0-7, IF ANY OTHER
1983      ;TYPE ?? & AGAIN ASK FOR
1984      ;DRIVS TO BE TSTD?
1985      TST      R2          ;IS IT A TERMINATOR?
1986      BEQ     6$          ;YES, EXIT. NO DRIVES INDICATED.
1987      4$:
1988      TYPE     ,67$      ;;TYPE ASCIZ STRING
1989      BR      66$       ;;GET OVER THE ASCIZ
1990
1991      ;:67$: .ASCIZ /?/?/
1992      66$:
1993      BR      ST2        ;GO, AGAIN ASK QUESTION
1994      TST      @R3        ;SEE IF ALL READY SELECTED
1995      BNE     4$          ;ERROR IF SELECTED ALL READY
1996      INC      @R3        ;SET UP FLAG FOR THE DRIVE
1997      INC      DRIVS     ;INCREMENT TOTAL NO OF DRIVES PRESENT
1998      11$: MOVB     @R0,R2 ;GET NEXT CHAR
1999      BIC      #177400,R2 ;CHARACTER ONLY
2000      CMP      #1,R2     ;IS IT 'F'?
2001      BNE     8$          ;NO, GO ON
2002      BIT      #BIT15,@R3 ;SET BIT 15 TO SHOW RK05F
2003      BIT      #BIT0,R5  ;EVEN DRIVE?
2004      BEQ     9$          ;EVEN DRIVE SO BRANCH
2005      TST      -(R3)     ;CHECK EVEN DRIVE
2006      BNE     4$          ;EVEN ALL READY SELECTED
2007      MOV      #BIT15!BIT0,-2(R3) ;SELECT EVEN DRIVE
2008      BR      10$        ;CONTINUE
2009      TST      2(R3)     ;CHECK ODD DRIVE
2010      BNE     4$          ;ERROR IF SELECTED BEFORE
2011      MOV      #BIT15!BIT0,2(R3) ;SELECT ODD DRIVE
2012      10$: INC      DRIVS ;COUNT DRIVES SELECTED
2013      TSTB    (R0)+      ;POINT TO NEXT CHAR
2014      BR      11$        ;CHECK FOR COMMA
2015      CMP      #54,R2    ;IS IT A 'COMMA'?
2016      BEQ     5$          ;YES, GO PROCESS NXT WORD
2017      TST      R2        ;NO, IS IT A TERMINATOR?
2018      BNE     4$          ;IF NOT, SOMETHING WRONG
2019      ;GO ASK QUESTION AGAIN
2020      BR      6$          ;EXIT, IF A TERMINATOR
2021      TSTB    (R0)+      ;INCREMENT PTR TO NXT BYTE
2022      ;IN INPUT BUFFER
2023      INC      R1        ;THERE SHOULD BE NO MORE THAN
2024      BNE     1$          ;8 DRIVES, HENCE IF MORE
2025      BR      4$          ;THAN 8 DIFFERENT NOS. TYPED IN, ERROR!
2026      ;GO AGAIN ASK THE QUESTION
2027
2028      6$: CLR      SIZYET ;NO SIZI.G NEEDED
2029      BIT      #SW10,@SWR ;TESTING ON SIMULATOR?
2030      BNE     7$          ;YES, BRANCH
2031      CLR      SIMUL     ;NO, CLR FLAG
2032      BR      ST4
2033
2034      7$: MOV      #1,SIMUL ;SET FLAG TO INDICATE SIMULATOR
2035      BR      ST4
2036
2037

```

```

2038 ;CHECK NUMBER OF DRIVES
2039 004262 012737 177777 001440 ST3: MOV #1,SIZ:ET ;CHECK FOR RK05F LATER
2040 004270 012737 004442 000004 MOV #55,@#4 ;SET UP ADRES FOR TIME-OUT VECTOR
2041 004276 005777 175024 TST @RKDS ;REFERENCE RKDS
2042 004302 005777 175032 TST @RKDA ;REFERENCE RKDA
2043 004306 012737 004534 000004 MOV #BADTMO,@#4
2044 004314 104401 TYPE MSG1
2045 004316 001216 MSG1
2046 004320 012700 177770 MOV #-10,R0 ;INITIALIZE COUNT FOR THE 8 DRIVES
2047 004324 005037 001412 CLR DRVS ;INITIALIZE # OF DRIVES PRESENT TO 0
2048 004330 005001 CLR R1 ;INITIALIZE ADDRESS TO DRIVE 0
2049 004332 005004 CLR R4
2050 004334 012702 001414 MOV #DRIVO,R2
2051 004340 010177 174774 1$: MOV R1,@RKDA ;ADDRESS THE DRIVE
2052 004344 020177 174770 CMP R1,@RKDA ;CHECK, WAS IT ADDRESSED?
2053 004350 001405 BEQ 3$ ;YES
2054 004352 012703 004356 2$: MOV #2$,R3
2055 004356 004737 021026 JSR PC,TYERM ;WHILE CHECKING NUMBER OF DRIVE
2056 ;UNDER NON-MANUAL MODE :-
2057 ;RKDA HAD TO BE ADRESED BUT
2058 ;IT WAS FOUND THAT THE DRIVE NO
2059 ;THAT WAS WRITTEN COULD NOT BE READ BACK
2060 ;CORRECTLY.
2061
2062 004362 000413 BR 4$
2063 004364 032777 000200 174734 3$: BIT #200,@RKDS ;CHECK IF 'DRY' BIT IS SET, IF SET DRIVE IS
2064 ;PRESENT
2065 004372 001407 BEQ 4$
2066 004374 104401 TYPE
2067 004376 001213 $CRLF
2068 004400 005237 001412 INC DRVS ;IF PRESENT, INCREMENT # OF DRIVES
2069 004404 005212 INC (R2) ;SET UP FLAG INDICATING THIS DRIVE PRESENT
2070 004406 010446 MOV R4,-(SP)
2071 004410 104402 TYPOC
2072 004412 005722 4$: TST (R2)+ ;SHIFT POINTER TO NXT DRIVE INDICATOR
2073 004414 062701 020000 ADD #20000,R1 ;SET UP ADDRESS FOR THE NEXT DRIVE
2074 004420 005204 INC R4 ;HAVE U CHECKED FOR ALL 8 DRIVES
2075 004422 005200 INC R0
2076 004424 001345 BNE 1$
2077 004426 005737 001412 TST DRVS
2078 004432 001011 BNE ST4
2079 004434 104401 TYPE MSG2
2080 004436 001236 BR ST4 ;GO CHECK THE DRIVE INDEPENDENT
2081 004440 000406 BR ST4 ;CONTROLLER LOGIC
2082 ;GET PC WHERE TIMEOUT OCCURED
2083 004442 011603 5$: MOV (SP),R3 ;RESTORE STACK
2084 004444 022626 CMP (SP)+,(SP)+
2085 004446 062703 177776 ADD #-2,R3
2086 004452 004737 021026 JSR PC,TYERM ;GO TYPE ERROR MESSAGE
2087 ;WHILE CHECKING FOR THE NUMB&R OF
2088 ;DRIVES IN NON-MANUAL MODE:-
2089 ;RKDS AND RKDA HAD TO BE REFERENCE". TIMEOUT
2090 ;OCCURED ON REFERENCING.PC IN THE ERROR
2091 ;MESSAGE INDICATES WHERE THE TIMEOUT OCCURED.
2092
2093 ;

```

```

2094
2095
2096 004456 005037 001434 ST4: CLR T56FLG
2097 004462 005737 001412 TST DRVS
2098 004466 001004 BNE 1$
2099 004470 004727 021742 JSR PC,WATIME
2100 004474 000137 020652 JMP SEOP
2101 004500 012737 001414 001354 1$: MOV #DRIVO,DRVPTR
2102 004506 005037 001352 CLR DRVDO ;INITIALIZE THE NO. OF DRIVES
2103 ;THAT HAVE BEEN CHECKED
2104 004512 005037 001350 CLR DRIVAD ;INITIALIZE DRIVE ADDRESS TO
2105 ;THE FIRST DRIVE
2106 004516 012737 004534 000004 MOV #BADTMO,@#4 ;SET TIME OUT VECTOR FOR UNEXPECTED
2107 ;TIME OUTS
2108 004524 012777 004600 174650 MOV #BADINT,@RKVEC ;SET UP RK11 INTERRUPT VECTOR FOR
2109 ;UNEXPECTED INTERRUPTS FROM RK11
2110 004532 000465 BR TST1 ;GO TO TEST 1
2111
2112
2113
2114
2115 ;THIS ROUTINE HANDLES UNEXPECTED TIME OUTS
2116
2117 004534 011600 BADTMO: MOV (SP),R0 ;SAVE PC WHERE TIME OUT OCCURED
2118 004536 005740 TST -(R0)
2119 004540 022626 CMP (SP)+,(SP)+ ;RESTORE STACK POINTER
2120 004542 104401 004550 TYPE ,65$ ;TYPE ASCIZ STRING
2121 004546 000407 BR 64$ ;GET OVER THE ASCIZ
2122 ;;65$: .ASCIZ <15><12>/TIMOUT,PC=/
2123 64$:
2124 004566 010046 MOV R0,-(SP) ;SET UP FOR TYPING OUT PC
2125 004570 104402 TYPOC ;GO TYPE OUT OCTAL PC
2126 004572 000000 HALT
2127 004574 000137 002636 JMP @#START
2128
2129
2130
2131 ;THIS ROUTINE HANDLES UNEXPECTED INTERRUPTS FROM RK11
2132 ;SW 9 AND 10 FOR LOOPING ON ERROR
2133 ;AND LOOPING ON TEST IN WHICH TIMEOUT
2134 ;OCCURRED, ARE PROVIDED.
2135
2136 004600 011600 BADINT: MOV (SP),R0 ;SAVE PC WHERE INTERRUPT OCCURED
2137 004602 005740 TST -(R0)
2138 004604 032777 020000 174326 BIT #20000,@SWR ;INHIBIT ERROR TYPEOUT?
2139 004612 001014 BNE 1$ ;YES, DON'T TYPE OUT
2140 004614 104401 TYPE
2141 004616 001213 $CRLF
2142 004620 104401 TYPE EM43
2143 004622 026004 TYPE 'UNEXPEXED RK11 INTERRUPT'
2144 ;TYPE ' AT PC='
2145 004624 104401 004632 TYPE ,65$ ;TYPE ASCIZ STRING
2146 004630 000403 BR 64$ ;GET OVER THE ASCIZ
2147 ;;65$: .ASCIZ /,PC=/
2148 64$:
2149 004640 010046 MOV R0,-(SP) ;SET UP FOR TYPING OUT PC

```

```

2150 004642 104402          TYP0C          ;GO TYPE OCTAL PC WHERE BAD
2151                          ;INTERUPT OCCURED
2152 004644 032777 001000 174266 1$: BIT #1000,@SWR ;LOOP ON ERROR?
2153 004652 001403          BEQ 2$          ;NO, BRANCH
2154 004654 022626          CMP (SP)+,(SP)+ ;YES, REPOSITION STACK
2155 004656 000177 174224  JMP @SLPADR     ;GO TO THE STARTING ADDRESS OF
2156                          ;THE TEST THAT GAVE UNEXPECTED INTERRUPT
2157 004662 032777 040000 174250 2$: BIT #40000,@SWR ;LOOP ON TEST?
2158 004670 001401          BEQ 3$          ;NO, BRANCH
2159 004672 000002          RTI            ;YES, LOOP. GO BACK WHER U INTERRUPTED FROM.
2160 004674 000000          3$: HALT       ;UNEXPECTED INTERRUPT OCCURED AS
2161                          ;INDICATED IN THE TYPE OUT.U CAN LLJJP
2162                          ;ON ERROR, TEST,OR INHIBIT TYPEOUT BY
2163                          ;SETTING APPROPRIATE SWITCH'S.
2164 004676 000137 002636  JMP @*START     ;GO BACK TO THE START OF THE
2165                          ;PROGRAM. THUS PRESSING CONTINUE
2166                          ;AFTER THE ABOVE HALT WILL
2167                          ;RESTART THE PROGRAM
2168
2169
2170
2171                          ;RESTART AFTER POWER FALL
2172                          ;THE PROGRAM WOULD RESTART HERE IF POWER CAME BACK AFTER A FALIURE.
2173
2174 004702 004737 021742  PFSTRT: JSR PC,WATIME ;KILL TIME
2175
2176
2177
2178 ;*****
2179 ;*TEST 1 CHECK THAT THE DRIVES THAT ARE NOT SPECIFIED ARE NOT FOUND TO BE PRESENT
2180 ;*THIS TEST CHECKS THAT THE DRIVES THAT ARE NOT SPECIFIED
2181 ;*(IN RESPONSE TO "DRIVES TO BE TSTD?") ARE NOT FOUND TO BE PRESENT.
2182 ;*EVERY DRIVE FROM 0 TO 7 IS ADDRESSED. IF A PARTICULAR DRIVE
2183 ;*GIVES 'DRY' (IN RKDS), IT IS CHECKED THAT THIS DRIVE
2184 ;*WAS SPECIFIED BY THE USER. IF IT WAS NOT AN ERROR IS
2185 ;*REPORTED, GIVING THE DRIVE NUMBER. IT IS LIKELY THAT THE USER
2186 ;*MAY HAVE FORGOTTEN TO PUT THE DRIVE (THAT IS NOT SPECIFIED) ON
2187 ;*'LOAD'. IF THIS IS THE CASE THEN PUT THIS DRIVE ON 'LOAD'.
2188 ;*IF THIS IS NOT THE CASE, THERE IS A GENUINE ERROR. (TWO DIFFERENT
2189 ;*DRIVE ADDRESSES MAY BE RESULTING IN THE SELECTION OF THE SAME
2190 ;*PHYSICAL DRIVE.)
2191 ;*****
2192 004706 000004  TST1: SCOPE
2193
2194 004710 012700 001414  MOV #DRIVO,RO ;INITIALIZE POINTER
2195 004714 005001  CLR R1 ;INITIALIZE DRIVE ADRES 0
2196 004716 005002  CLR R2 ;INITIALIZE DRIVE # 0
2197 004720 005737 001410 1$: TST DDPCH ;LOADED FROM AN RK05 ?
2198 004724 001403  BEQ 2$ ;B IF NOT
2199 004726 120237 001410  CMPB R2,DDPCH ;LOADED FROM THIS DRIVE ?
2200 004732 001435  BEQ 4$ ;BR IF YES
2201 004734 010177 174400 2$: MOV R1,@RKDA ;ADRES THE DRIVE
2202 004740 105777 174362  TSTB @RKDS ;DRIVE READY?
2203 004744 100005  BPL 3$ ;NO, THIS DRIVE NOT PRESENT
2204 ;YES, THIS DRIVE SELECTED
2205 004746 005710  TST @R0 ;WAS THIS DRIVE SPECIFIED BY

```

```

2206                          ;THE USER?
2207 004750 001026  BNE 4$          ;YES, OK
2208                          ;NO, THIS DRIVE # WAS NOT SPECIFIED
2209                          ;BY THE USER, BUT STILL IS GIVING
2210                          ;'DRY' WHEN ADRESED. REPORT ERROR.
2211 004752 010237 001162  MOV R2,$REGO ;GET DRIVE #
2212 004756 104116  ERROR 116    ;THIS DRIVE # WAS NOT SPECIFIED BY
2213                          ;THE USER, BUT WHEN ADRESED GAVE
2214                          ;'DRY'. CHECK THAT THIS DRIVE # IF
2215                          ;PHYSICALLY PRESENT IS ON 'LOAD'. IF
2216                          ;THIS IS NOT THE CASE, THEN ONE DRIVE
2217                          ;MAY BE GETTING SELECTED BY TWO DIFFERENT
2218                          ;LOGICAL ADDRESSES.
2219 004760 005710  3$: TST @R0 ;CHECK THAT THIS DRIVE WAS NOT INDICATED
2220 004762 001421  BEQ 4$          ;IF IT WAS, & IT IS NOT FOUND TO BE
2221                          ;PRESENT (DRY CLEAR), REPORT ERROR.
2222 004764 004737 020774  JSR PC,GTARG ;GET RKCS, ER, DS, DA
2223 004770 104010  ERROR 10    ;DRIVE # (AS IN RKDA) WAS INDICATED BY
2224                          ;THE USER, BUT WAS NOT FOUND TO BE PRESENT.
2225                          ;CHECK THAT THE ROTARY DRIVE SELECTION
2226                          ;SWITCH ON THE MODULE IS SET TO THE RIGHT
2227                          ;DRIVE #.
2228
2229 004772 005010  CLR @R0 ;THIS DRIVE IS NOT FOUND TO BE PRESENT
2230                          ;HENCE DROP IT FROM THE SELECTION TABLE.
2231 004774 010003  MOV R0,R3 ;DRIVE #DR
2232 004776 162703 001414  SUB #DRIVO,R3 ;MINUS OFFSET FOR TABLE
2233 005002 042703 000003  BIC #3,R3 ;EVEN DRIVE OF PAIR
2234 005006 062703 001414  ADD #DRIVO,R3 ;POINT TO EVEN OF PAIR IF RK05 F
2235 005012 042723 100000  BIC #100000,(R3)+ ;NOT SPECIFIED AS F MODEL
2236 005016 042713 100000  BIC #100000,(R3) ;SAME
2237 005022 005337 001412  DEC DRVS ;DECREMENT DRIVE COUNT
2238 005026 005202  4$: INC R2 ;INCRMNT DRIVE #
2239 005030 005720  TST (R0)+ ;INCRMNT POINTER
2240 005032 062701 020000  ADD #20000,R1 ;INCRMNT ADRES TO NXT DRIVE
2241 005036 001330  BNE 1$ ;LUP BAK IF NOT DONE
2242
2243
2244                          ;THIS PART OF THE PROGRAM IS GOING TO BE REPEATED FOR
2245                          ;EACH DRIVE PRESENT
2246                          ;
2247                          ;'DRIVAD' CONTAINS IN BITS 15,14,13 THE ADDRESS OF THE
2248                          ;DRIVE BEING CURRENTLY CHECKED.
2249                          ;
2250 005040  NUDRV:
2251
2252
2253 ;*****
2254 ;*TEST 2 FIND OUT NEXT DRIVE TO BE CHECKED
2255 ;THIS CODE FINDS OUT THE NEXT DRIVE THAT IS PRESENT AND THEN SETS UP
2256 ;THE ADDRESS IN DRIVAD (BITS 13,14,15). THUS THROUGHOUT THE FOLLOWING TESTS
2257 ;THE DRIVE TESTED IS THE DRIVE WHOOSE ADDRESS IS IN 'DRIVAD'.
2258 ;*****
2259 005040 000004  TST2: SCOPE
2260 005042 012737 000001 001206  MOV #1,$TIMES ;;DO 1 ITERATION
2261 005050 012737 000002 001102  MOV #2,$TSTNM ;RESET POINTER TO THIS TEST

```

2262 ;NO. CHANGE THIS (2) IN CASE THE  
2263 ;TEST NO. CHANGES  
2264 005066 005037 001112 CLR \$ERTTL ;CLEAR TOTAL ERROR COUNT  
2265 005062 005737 001412 TST DRIVS ;R THERE ANY DRIVES PRESENT?  
2266 005066 001002 BNE .+6 ;YES, BRANCH  
2267 005070 000137 020652 4S: JMP \$EOP ;NO. JMP TO THE END  
2268 005074 013701 001354 MOV DRVPTR,R1 ;GET THAT POINTER TO THE NEXT  
2269 ;DRIVE FLAG  
2270 005100 032721 000001 2S: BIT #BIT0,(R1)+ ;IS THIS DRIVE PRESENT?  
2271 005104 001005 BNE 1\$ ;YES  
2272 005106 062737 020000 001350 6S: ADD #20000,DRIVAD ;FORM NXT DRIVE ADRES  
2273 005114 001371 BNE 2\$  
2274 005116 000764 BR 4\$  
2275 005120 005737 001410 1S: TST DDPCH ;PROGRAM LOADED FROM AN RK05 ?  
2276 005124 001413 BEQ 3\$ ;NO, BRANCH  
2277 005126 013746 001350 MOV DRIVAD,-(SP) ;PUT TEST DRIVE ADDRESS ON THE STACK  
2278 005132 000316 SWAB (SP) ;SETUP TO RIGHT JUSTIFY THE ADDRESS  
2279 005134 006216 ASR (SP) ;RIGHT JUSTIFY THE ADDRESS  
2280 005136 006216 ASR (SP) ;RIGHT JUSTIFY THE ADDRESS  
2281 005140 006216 ASR (SP) ;RIGHT JUSTIFY THE ADDRESS  
2282 005142 006216 ASR (SP) ;RIGHT JUSTIFY THE ADDRESS  
2283 005144 006216 ASR (SP) ;RIGHT JUSTIFY THE ADDRESS  
2284 005146 122637 001410 CMPB (SP)+,DDPCH ;PROGRAM LOADED FROM THIS DRIVE ?  
2285 005152 001755 BEQ 6\$ ;BR IF YES, DON'T TEST THE DRIVE  
2286 005154 010137 001354 3S: MOV R1,DRVPTR ;STORE POINTER TO THE NEXT  
2287 ;DRIVE FLAG  
2288 005160 104401 001272 TYPE ,MSG4 ;GET THE DRIVE ADDRESS  
2289 005164 013746 001350 MOV DRIVAD,-(R6) ;GO SHIFT IT TO THE RIGHT  
2290 005170 004737 021200 JSR PC,SHFTRT  
2291 005174 005037 001404 CLR FFLAG  
2292 005200 011600 MOV (R6),R0 ;DRIVE NUMBER  
2293 005202 104403 TYPOS ;GO TYPE THE OCTAL # FOR THE  
2294 ;DRIVE THAT IS BEING CHECKED  
2295 005204 001 000 .,BYTE 1,0  
2296 005205 006300 ASL R0 ;INDEX TO TABLE  
2297 005210 005760 001414 TST DRIVO(R0) ;SEE IF F  
2298 005214 100006 BPL 5\$ ;NO  
2299 005216 104401 005224 TYPE ,65\$ ;TYPE ASCIZ STRING  
2300 005222 000401 BR 64\$ ;GET OVER THE ASCIZ  
2301 ;:65\$: .ASCIZ /F/  
2302 005226 005237 001404 64\$: INC FFLAG ;SET F FLAG  
2303 005226 104401 5S: TYPE  
2304 005232 104401 SCRLF ;TYPE CR, LF  
2305 005234 001213  
2306 ;:\*\*\*\*\*  
2307 ;\*TEST 3 CHECK THAT DRIVE IS SUPPLIED WITH POWER-DPL BIT  
2308 ;:\*\*\*\*\*  
2309 005236 000004 TST3: SCOPE  
2310 005240 104413 CNT.RESET ;GO, DO CONTROL RESET  
2311 ;THIS IS A CALL FOR THE 'CNTRL-  
2312 ;RESET' ROUTINE. A CONTROL RESET IS  
2313 ;ISSUED AND AFTER A CERTAIN TIME  
2314 ;IF THE 'CNTRL RDY' DOES NOT SET  
2315 ;AN ERROR IS REPORTED. NOTE THAT  
2316 ;THE PC IN ERROR MESSAGE IS THE  
2317 ;PC WHERE 'CNT.RESET' IS LOCATED.

2318 ;THIS IS A VERY BASIC ERR& IF IT  
2319 ;OCCURS GO BACK TO TEST 10  
2320 005242 013700 001326 MOV RKDS,R0  
2321 005246 013777 001350 174064 MOV DRIVAD,@RKDA ;ADDRESS THE DRIVE UNDER TEST  
2322 005254 005710 TST @R0 ;CHECK IF ANY BIT OF RKDS IS SET?  
2323 005256 001003 BNE 1\$ ;IF SET, BRANCH  
2324 005260 011037 001162 MOV @R0,\$REGO ;GET RKDS  
2325 005264 104004 ERROR 4 ;RKDS ERROR! RKDS IF ADDRESSED  
2326 ;CORRECTLY SHOULD BE NON-ZERO  
2327 005266 012777 000015 174036 1S: MOV #15,@RKCS ;ISSUE A DRV RESET, IF DRV  
2328 ;POWER IS LO, DPL WILL SET  
2329 005274 005001 CLR R1  
2330 005276 032710 010000 2S: BIT #10000,@R0 ;IS 'DPL' BIT SET?  
2331 005302 001003 BNE 3\$ ;DPL IS SET, BRANCH  
2332 005304 005201 INC R1 ;WAIT FOR SOME TIME TO  
2333 005306 001373 BNE 2\$ ;SEE IF DPL WOULD SET  
2334 005310 000403 BR 4\$-2 ;OK, DPL NOT SET  
2335 005312 004737 021002 3S: JSR PC,GT3RG ;GO, GET RKCS, ER, DS  
2336 005316 104005 ERROR 5 ;DPL BIT OF RKDS IS SET, CHECK DRIVE POWER  
2337  
2338  
2339 005320 005001 CLR R1  
2340 005322 032710 000100 4S: BIT #100,@R0 ;DID R/W/S RDY BIT SET?  
2341 005326 001010 BNE TST4 ;YES, EXIT  
2342 005330 104417 000011 DELAY ,11 ;TIME DELAY  
2343 005334 005201 INC R1 ;WAIT FOR R/W/S RDY  
2344 005336 001371 BNE 4\$  
2345 005340 017737 173762 001162 MOV @RKDS,\$REGO ;GET RKDS  
2346 005346 104016 ERROR 16 ;R/W/S RDY DID NOT SET AFTER  
2347 ;DRIVE RESET. DRIVE RESET WAS DONE  
2348 ;TO CHECK 'DPL' BIT. THIS TEST  
2349 ;IS NOT FOR CHECKING DRIVE RESET.  
2350 ;U MIGHT WANT TO USE THE TEST PROVIDED  
2351 ;FOR CHECKING DRIVE RESET.  
2352  
2353 ;:\*\*\*\*\*  
2354 ;\*TEST 4 CHECK THAT 'DRIVE UNSAFE' IS CLEAR, 'HDEN' IS SET, 'WPS' IS CLEAR  
2355 ;:\*\*\*\*\*  
2356 005350 000004 TST4: SCOPE  
2357 005352 104413 CNT.RESET ;GO, DO CONTROL RESET  
2358 ;THIS IS A CALL FOR THE 'CNTRL-  
2359 ;RESET' ROUTINE. A CONTROL RESET IS  
2360 ;ISSUED AND AFTER A CERTAIN TIME  
2361 ;IF THE 'CNTRL RDY' DOES NOT SET  
2362 ;AN ERROR IS REPORTED. NOTE THAT  
2363 ;THE PC IN ERROR MESSAGE IS THE  
2364 ;PC WHERE 'CNT.RESET' IS LOCATED.  
2365 ;THIS IS A VERY BASIC ERR & IF IT  
2366 ;OCCURS GO BACK TO TEST 10  
2367 005354 013777 001350 173756 MOV DRIVAD,@RKDA ;SET DRIVE ADDRESS  
2368 005362 017700 173740 MOV @RKDS,R0 ;GET RKDS  
2369 005366 032700 002000 BIT #2000,R0 ;IS 'DRU' BIT OF RKDS SET?  
2370 005372 001403 BEQ 1\$ ;NO  
2371 005374 004737 021002 JSR PC,GT3RG ;GO, GET RKCS, ER, DS  
2372 005400 104006 ERROR 6 ;'DRU' BIT OF RKDS IS SET, CHECK  
2373 ;DRIV BY PUTTING RUN/LOAD SW TO LOAD

```
2374                                     ;THEN BACK TO RUN
2375 005402 032700 004000 1$: BIT #400,R0 ;IS 'HDEN' BIT SET?
2376 005406 001004 BNE 2$ ;YES, BRANCH
2377 005410 017737 173712 001162 MOV @RKDS,$REGO ;GET RKDS
2378 005416 104007 ERROR 7 ;ERROR, 'RKOS' BIT IS NOT SET
2379
2380 005420 032777 000040 173700 2$: BIT #40,@RKDS ;IS 'WPS' CLEAR?
2381 005426 001403 BEQ TST5 ;YES, EXIT
2382 005430 004737 020774 JSR PC,GT4RG ;GET RKCS, ER, DS, DA
2383 005434 104114 ERROR 114 ;'WPS'-WRITE PROTECT STATUS- BIT OF
;OF RKDS SHOULD BE CLEAR, IF THIS DRIVE
;IS WRITE ENABLED. CHECK & SEE IF THIS
;DRIVE IS WRITE ENABLED. IF IT IS NOT,
;WRITE ENABLE IT.
;
;*****
;TEST 5 CHECK THAT 'DRIVE READY' IS SET IN RKDS
;*****
TST5: SCOPE
CNT.RESET ;GO, DO CONTROL RESET
;THIS IS A CALL FOR THE 'CNTRL-
;RESET' ROUTINE. A CONTROL RESET IS
;ISSUED AND AFTER A CERTAIN TIME
;IF THE 'CNTRL RDY' DOES NOT SET
;AN ERROR IS REPORTED. NOTE THAT
;THE PC IN ERROR MESSAGE IS THE
;PC WHERE 'CNT.RESET' IS LOCATED.
;THIS IS A VERY BASIC ERR & IF IT
;OCCURS GO BACK TO TEST 10
2404 005442 013777 001350 173670 MOV DRIVAD,@RKDA ;ADDRS THE DRIVE
2405 005450 105777 173652 TSTB @RKDS ;IS 'DRY' SET?
2406 005454 100403 BMI TST6 ;YES, OK
2407 005456 004737 020774 JSR PC,GT4RG ;GO, GET RKCS, ER, DS, DA
2408 005462 104010 ERROR 10 ;'DRY' NOT SET
2409
;*****
;TEST 6 CHECK THAT 'SOK' BIT CAN SET
;* THIS TEST CHECKS THAT WITHIN A CERTAIN TIME
;* 'SOK' BIT CAN SET, IF IT DOES NOT AN ERROR IS REPORTED
;*****
TST6: SCOPE
MOV DRIVAD,@RKDA ;ADDRS THE DRIVE
CLR R1 ;INITIALIZE COUNT FOR TIMING WAIT LOOP
2418 005476 032777 000400 173622 1$: BIT #400,@RKDS ;IS SOK SET?
2419 005504 001006 BNE TST7 ;EXIT
2420 005506 005201 INC R1 ;NO, WAIT
2421 005510 001372 BNE 1$ ;WAITED LONG?
2422 005512 017737 173610 001162 MOV @RKDS,$REGO ;GET RKDS
2423 005520 104011 ERROR 11 ;WAITED LONG BUT 'SEC OK' BIT DID NOT
;SET
;
;*****
;TEST 7 CHECK THAT 'SECTOR COUNTER' CAN COUNT FROM 0-13
```

```
;* THIS TEST CHECKS THAT THE SECTOR COUNTER CAN COUNT FROM
;* 0-13
;* 1) FIRST, FOR INITIALIZING PURPOSES THERE IS A TIMED LOOP
;* DURING WHICH SECTOR COUNTER SHOULD COUNT DOWN TO 0. IF THIS
;* IS NOT DONE AN ERROR IS REPORTED
;* 2) AFTER A COUNT OF 0 IS REAC.ED, THE PROGRAM WAITS
;* FOR A CERTAIN TIME, DURING WHICH THE SEC COUNTER
;* IS SAMPLED. IF THE COUNTER DOES NOT CHANGE WITHIN THIS
;* TIME PERIOD AN ERROR IS REPORTED.
;* 3) UPON FINDING THAT THE COUNTER HAS CHANGED, IT IS CHECKED
;* IF IT INCREMENTED CORRECTLY. IF IT DID NOT AN ERROR IS REPORTED
;* 4) IF IT INCREMENTED CORRECTLY, THE PROGRAM AGAIN WAITS IN A
;* LOOP TILL THE COUNTER CHANGES. (STEPS 2,3,4 ARE REPEATED
;* TILL THE COUNTER COUNTS UP TO 13)
;*****
TST7: SCOPE
CNT.RESET ;GO, DO CONTROL RESET
;THIS IS A CALL FOR THE 'CNTRL-
;RESET' ROUTINE. A CONTROL RESET IS
;ISSUED AND AFTER A CERTAIN TIME
;IF THE 'CNTRL RDY' DOES NOT SET
;AN ERROR IS REPORTED. NOTE THAT
;THE PC IN ERROR MESSAGE IS THE
;PC WHERE 'CNT.RESET' IS LOCATED.
;THIS IS A VERY BASIC ERR & IF IT
;OCCURS GO BACK TO TEST 10
2456 005526 013777 001350 173604 MOV DRIVAD,@RKDA ;INITIALIZE
2457 005534 013700 001326 MOV RKDS,R0 ;'COUNT' - TO TIME 'ERROR 35'
2458 005540 005037 001356 CLR INDX1 ;INITIALIZE 'COUNT' - TO TIME
2459 005544 005005 CLR R5 ;'ERROR 36' (WAIT LOOP)
2461 005546 012704 177764 MOV #-14,R4 ;INITIALIZE 'COUNT' - FOR THE 12 SECTORS.
2462 005552 012703 000001 MOV #1,R3 ;R3 CONTAINS THE 'NEXT' COUNT OF SEC-CNTR
;R1 CONTAINS THE 'PREVIOUS' COUNT OF SEC-CNTR
;R2 CONTAINS THE 'PRESENT' COUNT OF SEC-CNTR
2465 005556 005037 001360 1$: CLR INDX2 ;INITIALIZE 'COUNT' - TO TIME
; (WAIT LOOP) 'ERROR 34'
2467 005562 005237 001356 INC INDX1 ;KEEP TIMING FOR 'ERROR 35'
2468 005566 001440 BEQ 6$ ;BRANCH & REPORT ERROR IF WAITED LONG?
2469 005570 005237 001360 2$: INC INDX2 ;KEEP TIMING FOR 'ERROR 34'
2470 005574 001441 BEQ 7$ ;BRANCH & REPORT ERROR IF WAITED LONG?
2471
2472 005576 011001 MOV @R0,R1 ;GET RKDS
2473 005600 032701 000400 BIT #400,R1 ;IS 'SOK' SET?
2474 005604 001771 BEQ 2$ ;NO, WAIT FOR IT TO SET
2475 005606 021001 CMP @R0,R1 ;MAKE SURE THAT 2 CONSECUTIVE
2476 005610 001362 BNE 1$ ;READINGS OF SEC-CNTR ARE SAME
2477 005612 042701 177760 BIC #177760,R1 ;YES, MASK OUT NON-SEC CNTR BITS
2478 005616 001357 BNE 1$ ;IS IT SECTOR 0, IF NOT LOOP BACK &
;WAIT FOR SECTOR 0
2480 005620 005204 3$: INC R4 ;KEEP TRACK OF SECTORS CHECKED
2481 005622 001447 BEQ TST10 ;EXIT,IF ALL SECTORS CHKD
2482 005624 005205 4$: INC R5 ;KEEP TIMING FOR 'ERROR 36'
2483 005626 001431 BEQ 8$ ;BR & REPORT ERROR IF WAITED LONG
2484 005630 011002 MOV @R0,R2 ;GET RKDS
2485 005632 032702 000400 BIT #400,R2 ;IS SOK SET?
```

```

2486 005636 001772      BEQ      4$      ;NO, WAIT FOR SOK
2487 005640 021002      CMP      @R0,R2  ;MAKE SURE THAT 2 CONSECUTIVE
2488 005642 001370      BNE     4$      ;READINGS OF SEC-CNTR ARE SAME
2489 005644 042702      BIC     #177760,R2 ;MASK NON-SEC-CNTR BITS
2490 005650 020201      CMP      R2,R1  ;HAS SEC CNTR INCREMENTED?
2491 005652 001764      BEQ     4$      ;NO, WAIT FOR IT TO CHANGE
2492 005654 020203      CMP      R2,R3  ;YES, DID IT INCREMENT CORRECTLY?
2493 005656 001023      BNE     9$      ;NO - REPORT ERROR
2494
2495 005660 005203      5$: INC      R3      ;INCREMENT "NEXT COUNT"
2496 005662 005201      INC      R1      ;INCREMENT "PREVIOUS COUNT"
2497 005664 005005      CLR      R5      ;INITIALIZE AGAIN FOR TIMING 'ERROR 36'
2498 005666 000754      BR       3$      ;GO & CHECK THE NEXT SECTOR COUNT
2499
2500 005670 010137 001162  6$: MOV      R1,$REGO ;GET 'SEC CNTR'
2501 005674 104012      ERROR   12      ;WAITED LONG, BUT SECTOR COUNTER
2502                          ;DID NOT COUNT TO 0
2503 005676 000421      BR       TST10   ;EXIT
2504
2505 005700 017737 173422 001162 7$: MOV      @RKDS,$REGO ;GET RKDS
2506 005706 104011      ERROR   11      ;WAITED LONG, BUT 'SOK' BIT DID
2507                          ;NOT SET
2508 005710 000414      BR       TST10   ;EXIT
2509
2510 005712 010237 001162  8$: MOV      R2,$REGO ;GET SEC CNTR (PRESENT COUNT)
2511 005716 010337 001164      MOV      R3,$REG1 ;GET "NEXT COUNT"
2512 005722 104013      ERROR   13      ;WAITED LONG, BUT THE SECTOR
2513                          ;COUNTER DID NOT INCREMENT FROM
2514                          ;THE PRESENT COUNT TO THE NEXT COUNT
2515 005724 000406      BR       TST10   ;EXIT
2516
2517 005726 010337 001162  9$: MOV      R3,$REGO ;GET 'NEXT COUNT' (SEC CNTR SHOULD BE THIS)
2518 005732 010237 001164      MOV      R2,$REG1 ;GET PRESENT COUNT (WHAT SEC CNTR WAS)
2519 005736 104014      ERROR   14      ;SEC CNTR INCREMENTED WRONG, DID
2520                          ;NOT INCREMENT FROM PRESENT COUNT
2521                          ;TO NEXT COUNT
2522 005740 000747      BR       5$
2523
2524
2525
2526 ;*****
2527 ;*TEST 10 CHECK THAT SC=SA CAN BE GENERATED
2528 ;* THIS TEST CHECKS THAT SC=SA CAN BE GENERATED FOR
2529 ;* EVERY SECTOR
2530 ;*****
2530 005742 000004      TST10: SCOPE
2531 005744 104413      CNT.RESET      ;GO, DO CONTROL RESET
2532                          ;THIS IS A CALL FOR THE 'CNTRL-
2533                          ;RESET' ROUTINE. A CONTROL RESET IS
2534                          ;ISSUED AND AFTER A CERTAIN TIME
2535                          ;IF THE 'CNTRL RDY' DOES NOT SET
2536                          ;AN ERROR IS REPORTED. NOTE THAT
2537                          ;THE PC IN ERROR MESSAGE IS THE
2538                          ;PC WHERE 'CNT.RESET' IS LOCATED.
2539                          ;THIS IS A VERY BASIC ERR & IF IT
2540                          ;OCCURS GO BACK TO TEST 10
2541 005746 013704 001350      MOV      DRIVAD,R4

```

```

2542 005752 013700 001326      MOV      RKDS,R0
2543 005756 012703 177764      MOV      #4,R3
2544 005762 010477 173352      1$: MOV      R4,@RKDA ;INITIALIZE COUNT FOR # OF SECTORS
2545 005766 005005      CLR      R5      ;ADDRESS THE DRIVE
2546 005770 005205      2$: INC      R5      ;INITIALIZE COUNT - FOR TIMING ERROR
2547 005772 001410      BEQ     3$      ;KEEP TIMING FOR ERROR
2548 005774 011001      MOV      @R0,R1  ;REPORT ERROR IF WAITED LONG
2549 005776 032701 000020      BIT      #20,R1  ;GET RKDS
2550 006002 001772      BEQ     2$      ;IS SC=SA SET?
2551 006004 005204      4$: INC      R4      ;NO, WAIT FOR IT
2552 006006 005203      INC      R3      ;ADDRS THE NEXT SECTOR
2553 006010 001364      BNE     1$      ;ARE ALL SECTORS CHECKED FOR SC=SA
2554 006012 000406      BR       TST11   ;NO, GO & CHECK NEXT
2555                          ;YES. EXIT
2556 006014 110437 001162  3$: MOV      R4,$REGO ;GET SECTOR ADDRESS
2557 006020 010137 001164      MOV      R1,$REG1 ;GET RKDS
2558 006024 104015      ERROR   15      ;COULD NOT GET SC=SA FOR THIS
2559                          ;'SECTOR ADDRESS'
2560 006026 000766      BR       4$      ;GO CHK FOR THE REST
2561
2562 ;*****
2563 ;*TEST 11 CHECK THAT 'R/W/S RDY' IS SET & 'SIN' IS CLEAR
2564 ;*****
2565 006030 000004      TST11: SCOPE
2566 006032 104413      CNT.RESET      ;GO, DO CONTROL RESET
2567 006034 013777 001350 173276  MOV      DRIVAD,@RKDA ;ADDRESS THE DRIVE
2568 006042 005001      CLR      R1
2569 006044 017700 173256  1$: MOV      @RKDS,R0 ;GET RKDS
2570 006050 032700 000100      BIT      #100,R0 ;IS R/W/S RDY SET?
2571 006054 001007      BNE     2$      ;YES, BRANCH
2572 006056 005201      3$: INC      R1      ;INCREASE LOOP TIME
2573 006060 001376      BNE     3$      ;FOR DRIVE RESET OF HEADS
2574 006062 005201      INC      R1      ;WAITED LONG ENOUGH?
2575 006064 001367      BNE     1$      ;IF NOT LUP BAK & WAIT
2576 006066 010037 001162  4$: MOV      R0,$REGO ;GET RKDS
2577 006072 104016      ERROR   16      ;R/W/S RDY SHOULD BE SET
2578 006074 032700 001000  2$: BIT      #1000,R0 ;IS SIN CLEAR?
2579 006100 001403      BEQ     TST12   ;;YES, EXIT
2580 006102 004737 020774      JSR      PC,GT4RG ;GET RKDS, ER_DS, DA
2581 006106 104001      ERROR   1       ;'SIN' SHOULD HAVE BEEN CLEAR
2582                          ;IT WAS NOT CLEAR
2583                          ;NEXT TEST IS GOING TO CHECK
2584                          ;DRIVE RESET, SIN SHOULD BE
2585                          ;CLEARED THEN. IT WILL BE CHECKED
2586                          ;THERE.
2587
2588 ;*****
2589 ;*TEST 12 CHECK 'DRIVE RESET'
2590 ;*THIS TEST CHECKS THE VERY BASIC DRIVE RESET LOGIC.
2591 ;*SINCE THE HEADS ARE AT CYLINDER 0 (GOING INTO THIS
2592 ;*TEST) DRIVE RESET RETRACTS THEM BACK BEYOND CYLINDER 0.
2593 ;*AFTER WHICH THEY ARE PUSHED FORWARD TO CYLINDER 0 AGAIN.
2594 ;*IN THE LATER PART OF THIS PROGRAM THERE IS A DRIVE RESET
2595 ;*TEST WHICH DOES THE RESET FROM LAST CYLINDER.
2596 ;*****
2597 006110 000004      TST12: SCOPE

```



```

2598 006112 104413          CNT.RESET          ;GO, DO CONTROL RESET
2599                          ;THIS IS A CALL FOR THE 'CNTRL-
2600                          ;RESET' ROUTINE. A CONTROL RESET IS
2601                          ;ISSUED AND AFTER A CERTAIN TIME
2602                          ;IF THE 'CNTRL RDY' DOES NOT SET
2603                          ;AN ERROR IS REPORTED. NOTE THAT
2604                          ;THE PC IN ERROR MESSAGE IS THE
2605                          ;PC WHERE 'CNT.RESET' IS LOCATED.
2606                          ;THIS IS A VERY BASIC ERR & IF IT
2607                          ;OCCURS GO BACK TO TEST 10
2608 006114 013700 001332          MOV      RKCS,R0
2609 006120 005004          CLR      R4          ;INITIALIZ COUNT - TO TIME ERROR
2610 006122 013777 001350 173210    MOV      DRIVAD,@RKDA ;ADDRESS THE DRIVE
2611 006130 012710 000015          MOV      #15,@R0     ;'DRIVE RESET', GO
2612 006134 104412          CHKCRDY          ;GO CHECK IF CONTROL RDY IS SET
2613                          ;IF SO, SKIP THE EROR MESSAGE.
2614 006136 104021          ERROR    21        ;CNTRL RDY DID NOT SET AFTER
2615                          ;SENDING CYL ADDR TO THE DRIV.
2616                          ;'ADD ACK' SHOULD HAVE COME BACK
2617                          ;FROM DRIVE, THEREUPON SETTING 'CN RDY'
2618 006140 012705 177776 2$:      MOV      #-2,R5
2619 006144 032777 000100 173154 6$: BIT      #100,@RKDS ;CHECK FOR R/W/S READY
2620 006152 001402          BEQ     .+6
2621 006154 000137 006176          JMP     R5
2622 006160 005204          INC     R4
2623 006162 001370          BNE    R4
2624 006164 005205          INC     R5
2625 006166 001366          BNE    R5
2626 006170 004737 020774          JSR    PC,GT4RG     ;GO, GET RKCS, ER, DS, DA
2627 006174 104026          ERROR    26        ;R/W/S RDY DID NOT SET AFTER
2628                          ;DRIVE RESET
2629
2630 006176 032777 001000 173122 3$: BIT      #1000,@RKDS ;DID SIN SET?
2631 006204 001403          BEQ     5$         ;NO, BRANCH
2632 006205 004737 020774          JSR    PC,GT4RG     ;GO, GET RKCS,ER,DS,DA
2633 006212 104001          ERROR    1         ;SIN SET, AFTER A
2634                          ;DRIVE RESET.
2635 006214 032710 140000 5$:      BIT      #140000,@R0 ;WAS 'ERR' BIT OR 'HE' BIT SET?
2636 006220 001403          BEQ     4$         ;NO
2637 006222 004737 020774          JSR    PC,GT4RG     ;GO, GET RKCS, ER, DS, DA
2638 006226 104022          ERROR    22        ;'ERR' OR 'HE' BIT SET WHILE DOING
2639                          ;DRIVE RESET
2640 006230 022710 000214 4$:      CMP     #214,@R0    ;DOES RKCS STILL CONTAIN THE
2641                          ;'DRIV RES' BITS
2642 006234 001406          BEQ     TST13      ;YES, EXIT
2643 006236 012737 000214 001162    MOV     #214,$REG0 ;GET EXPCTD RKCS
2644 006244 011037 001164          MOV     @R0,$REG1  ;GET RKCS, RECVD
2645 006250 104024          ERROR    24        ;NO - RKCS SHOULD CONTAIN THE 'DRIV RES'
2646                          ;FUNCTION, ERROR IF DIFFERENT.
2647
2648 ;*****
2649 ;*TEST 13 CHECK 'SEEK' TO CYLINDER 0
2650 ;* THIS TEST CHECKS THE SEEK LOGIC DOING SEEK TO CYLINDER 0.
2651 ;* NOTE THAT SINCE THE HEADS ARE ALREADY ON CYLINDER 0, NO
2652 ;* HEAD MOVEMENT IS INVOLVEDN AND THE STRESS IS ON THE BASIC SEEK
2653 ;* LOGIC.
    
```

```

2654 ;*****
2655 006252 000004          TST13: SCOPE
2656 006254 104413          CNT.RESET          ;GO, DO CONTROL RESET
2657                          ;THIS IS A CALL FOR THE 'CNTRL-
2658                          ;RESET' ROUTINE. A CONTROL RESET IS
2659                          ;ISSUED AND AFTER A CERTAIN TIME
2660                          ;IF THE 'CNTRL RDY' DOES NOT SET
2661                          ;AN ERROR IS REPORTED. NOTE THAT
2662                          ;THE PC IN ERROR MESSAGE IS THE
2663                          ;PC WHERE 'CNT.RESET' IS LOCATED.
2664                          ;THIS IS A VERY BASIC ERR & IF IT
2665                          ;OCCURS GO BACK TO TEST 10
2666 006256 104421          TST.SIN          ;GO CHECK IF SIN SET. IF SET
2667                          ;A DO DRIVE RESET TO CLEAR 'T
2668 006260 013700 001332          MOV      RKCS,R0
2669 006264 013777 001350 173046    MOV      DRIVAD,@RKDA ;ADDRESS THE DRIVE
2670
2671 006272 012710 000011          MOV      #11,@R0    ;'SEEK' GO
2672 006276 104412          CHKCRDY          ;GO CHECK IF CONTROL RDY IS SET
2673                          ;IF SO, SKIP THE EROR MESSAGE.
2674 006300 104021          ERROR    21        ;'CNTRL RDY' DID NOT SET AFTER SENDING
2675                          ;CYL ADDR TO THE DRIVE, 'ADD ACK'
2676                          ;SHOULD HAVE COME BACK FROM THE
2677                          ;DRIVE, THEREUPON SETTING 'CNTRL RDY'
2678 006302 005005 2$:      CLR      R5
2679 006304 032777 000100 173014    BIT      #100,@RKDS ;DID R/W/S RDY BIT SET?
2680 006312 001005          BNE    3$         ;YES, BRANCH
2681 006314 005205          INC     R5
2682 006316 001372          BNE    2$+2       ;WAITED LONG ENOUGH?
2683 006320 004737 020774          JSR    PC,GT4RG     ;IF NOT, LUP BAK & WAIT
2684 006324 104026          ERROR    26        ;GO, GET RKCS, ER, DS, DA
2685 006326 032777 001000 172772 3$: BIT      #1000,@RKDS ;R/W/S RDY DID NOT SET AFTER SEEK
2686 006334 001403          BEQ     6$         ;DID SIN SET?
2687 006336 004737 020774          JSR    PC,GT4RG     ;NO, BRANCH
2688 006342 104001          ERROR    1         ;GO, GET RKCS,ER,DS,DA
2689                          ;SIN SET ON DOING SEEK
2690                          ;TO CYL 0 NOTE THIS IS THE
2691                          ;FIRST TIME THE HEADS HAVE
2692                          ;BEEN MOVED
2693 006344 032710 140000 6$:      BIT      #140000,@R0 ;WAS 'ERR' OR 'HE' BIT SET?
2694 006350 001403          BEQ     4$         ;NO
2695
2696 006352 004737 020774          JSR    PC,GT4RG     ;GO, GET RKCS, ER, DS, DA
2697 006356 104022          ERROR    22        ;'ERR' OR 'HE' BIT SET WHILE DOING 'SEEK'
2698
2699 006360 005777 172744 4$:      TST     @RKER      ;WAS ANY BIT IN RKER SET?
2700 006364 001403          BEQ     5$         ;NO
2701 006366 004737 021002          JSR    PC,GT3RG     ;GO, GET RKCS, ER, DS
2702 006372 104023          ERROR    23        ;RKER SHOWS AN ERROR BIT, CHECK
2703
2704 006374 022710 000210 5$:      CMP     #210,@R0    ;DOES RKCS STILL CONTAIN 'SEEK' FUNCTION
2705 006400 001406          BEQ     TST14      ;YES, EXIT
2706 006402 012737 000210 001162    MOV     #210,$REG0 ;GET EXPCTD RKCS
2707 006410 011037 001164          MOV     @R0,$REG1  ;GET RKCS RECVD
2708 006414 104024          ERROR    24        ;NO, RKCS SHOULD BE STILL CONTAINING
2709                          ;'SEEK' FUNCTION ERROR - IF IT CHANGED
    
```

```

2710 ;
2711 ;*****
2712 ;*TEST 14 CHECK R/W/S RDY IS CLEAR WHEN HEADS ARE IN MOTION
2713 ;*THIS TEST CHECKS THAT R/W/S DOES GET CLEARED
2714 ;*WHEN THE HEADS ARE IN MOTION. SINCE 'MOVE L' ON
2715 ;*M7700 (RK05) GENERATES THIS SIGNAL, ABSENCE OF
2716 ;*R/W/S RDY-CLEAR COULD MEAN A FAULT ON M7702
2717 ;*WHERE 'MOVE L' IS GENERATED.
2718 ;*NOTE THIS IS THE FIRST TIME HEADS ARE MADE TO MOVE BY SEEKING
2719 ;*TO CYLINDER 2.
2720 ;*****
2721 006416 000004 TST14: SCOPE
2722 006420 104413 CNT.RESET ;GO, DO CONTROL RESET
2723 ;THIS IS A CALL FOR THE 'CNTRL-
2724 ;RESET' ROUTINE. A CONTROL RESET IS
2725 ;ISSUED AND AFTER A CERTAIN TIME
2726 ;IF THE 'CNTRL RDY' DOES NOT SET
2727 ;AN ERROR IS REPORTED. NOTE THAT
2728 ;THE PC IN ERROR MESSAGE IS THE
2729 ;PC WHERE 'CNT.RESET' IS LOCATED.
2730 ;THIS IS A VERY BASIC ERR & IF IT
2731 ;OCCURS GO BACK TO TEST 10
2732 006422 104421 TST.SIN ;GO CHECK IF SIN IS SET
2733 ;IF SET DO DRV-RESET TO CLR IT
2734 006424 004737 021504 JSR PC,DRESET ;MAKE SURE HEADS R ON CYL 0
2735 006430 104026 ERROR 26 ;R/W/S RDY DIDN'T SET
2736 ;AFTER THE ABOVE DRV RESET
2737 006432 005005 CLR R5
2738 006434 013777 001350 172676 MOV DRIVAD,@RKDA
2739 006442 052777 000100 172670 BIS #100,@RKDA ;SEEK CYLINDER 2
2740 006450 013701 001326 MOV RKDS,R1
2741 006454 012777 000011 172650 MOV #11,@RKCS ;SEEK, GO
2742 006462 032711 000100 1$: BIT #100,@R1 ;DID R/W/S RDY CLR?
2743 006466 001405 BEQ 2$ ;YES, BRANCH
2744 006470 005205 INC R5
2745 006472 100373 BPL 1$
2746 006474 004737 021002 JSR PC,GT3RG
2747 006500 104025 ERROR 25 ;R/W/S RDY WAS NOT CLEAR WHEN HEADS
2748 ;WERE SEEKING TO CYLINDER 2
2749
2750 006502 004737 021436 2$: JSR PC,TSTRWS ;GO, WAIT FOR R/W/S RDY TO SET
2751 006506 104016 ERROR 16 ;R/W/S RDY DID NOT SET AFTER SEEK
2752 ;WAS TRIED TO CYLINDER 2 (ABOVE).
2753 ;NOTE THIS WAS THE FIRST TIME A SEEK
2754 ;WAS TRIED TO A CYLINDER OTHER THAN
2755 ;0.
2756
2757
2758
2759 ;*****
2760 ;*TEST 15 CHECK 'WRITE' FORMAT FUNCTION-CYLINDER 0, SECTOR 0
2761 ;*THIS TEST CHECKS THE LOGIC INVOLVED IN THE WRITE FMT
2762 ;*FUNCTION. ON ISSUING A WRT FMT, THE FOLLOWING IS CHECKED
2763 ;*1) CNTRL RDY WAS CLEARED AS GO WAS SET.
2764 ;*2) CNTRL RDY SETS WITHIN A CERTAIN TIME ON COMPLETION OF FUNCTION
2765

```

```

2766 ;*3) IF 'HE' OR 'ERR' BIT SET?
2767 ;*4) IF RKDA INCREMENTED CORRECTLY FROM 0 TO 1?
2768 ;*5) IF RKWC OVERFLOWED CORRECTLY TO 0?
2769 ;*6) IF RKBA INCREMENTED CORRECTLY BY 2?
2770 ;*7) IF ANY BIT IN RKER SET?
2771 ;*8) IF THE 'WRT FMT' FUNCTION BITS ARE STILL IN THE RKCS?
2772 ;*NOTE THAT ONE WORD '125252' WAS WRITTEN ON SECTOR
2773 ;*0 & IT WILL BE CHECKED IN THE NEXT TESTS.
2774 ;*****
2775 006510 000004 TST15: SCOPE
2776 006512 104413 CNT.RESET ;GO, DO CONTROL RESET
2777 ;THIS IS A CALL FOR THE 'CNTRL-
2778 ;RESET' ROUTINE. A CONTROL RESET IS
2779 ;ISSUED AND AFTER A CERTAIN TIME
2780 ;IF THE 'CNTRL RDY' DOES NOT SET
2781 ;AN ERROR IS REPORTED. NOTE THAT
2782 ;THE PC IN ERROR MESSAGE IS THE
2783 ;PC WHERE 'CNT.RESET' IS LOCATED.
2784 ;THIS IS A VERY BASIC ERR & IF IT
2785 ;OCCURS GO BACK TO TEST 10
2786 006514 104421 TST.SIN ;GO CHECK IF SIN IS SET
2787 ;IF SET, DO DRIVE RESET TO CLR IT
2788 006516 012703 033342 MOV #OUTBUF,R3
2789 ;THIS CODE SETS UP A 256 WORD BUFFER
2790 ;WHICH WILL BE USED TO WRITE 1 SECTOR
2791 ;ON THE DISK
2792 ;1ST WORD 000001
2793 ;2ND WORD 177777 2'S COMPLEMENT
2794 ;3RD WORD 000002 OF ABOVE
2795 ;4TH WORD 177776
2796 ;...
2797 ;253RD WORD 000177
2798 ;254TH WORD 177601
2799 ;255TH WORD 000000
2800 ;256TH WORD 125252
2801
2802 006522 012700 000001 MOV #1,R0 ;SET COUNT
2803
2804 006526 010023 9$: MOV R0,(R3)+ ;SET UP DATA WORDS
2805 006530 010013 MOV R0,(R3)
2806 006532 005423 NEG (R3)+
2807 006534 005200 INC R0
2808 006536 022700 000200 CMP #200,R0 ;DONE?
2809 006542 001371 BNE 9$
2810 006544 005023 CLR (R3)+ ;SET 255TH WORD TO 0
2811 006546 012713 125252 MOV #125252,@R3 ;SET 256TH WORD
2812
2813 006552 012703 033342 MOV #OUTBUF,R3 ;RESET POINTER TO OUTBUF
2814 006556 013701 001332 MOV RKCS,R1
2815 006562 013702 001336 MOV RKBA,R2
2816 006566 010312 MOV R3,@R2 ;FROM HERE-SET UP CURRENT ADDRESS
2817 006570 012777 177400 172536 MOV #-400,@RKWC ;SET UP WORD COUNT 400 WORDS
2818 006576 013777 001350 17253$ MOV DRIVAD,@RKDA ;SET UP DISK ADDRS. SECTOR 0, CYLINDER 0
2819 006604 012711 002003 MOV #2003,@R1 ;WRITE FORMAT, GO
2820
2821 006610 105711 1$: TSTB @R1 ;WAS 'CNTRL RDY' CLEARED AS GO WAS SET?

```

```

2822 006612 100003          BPL      2$          ;YES, BRANCH
2823 006614 004737 021002 JSR      PC,GT3RG   ;GO, GET RKCS, ER, DS
2824 006620 104030          ERROR    30          ;'CNTRL RDY' DIDN'T CLEAR AS GO
2825                                     ;WAS SET TO 'WRITE FORMAT'
2826
2827 006622 005000          2$: CLR      RO          ;WAS 'CNTRL RDY' SET ON COMPLETION OF WRITE?
2828 006624 105711          TSTB   @R1          ;YES, BRANCH
2829 006626 100411          BMI      3$          ;NO, HAVE U WAITED LONG ENOUGH?
2830 006630 005200          INC      RO          ;IF NOT, LOOP BACK & WAIT
2831 006632 001374          BNE     2$+2        ;IF YES, REPORT ERROR
2832 006634 004737 020774 JSR      PC,GT4RG   ;GO, GET RKCS, ER, DS,DA
2833 006640 013737 001350 001202 MOV      DRIVAD,$REG10
2834 006646 104416          BRKDA4          ;GO TO 'BDA4' & BREAK CONTENTS OF
2835                                     ;$REG10 INTO DR #,CYL,SUR,SFC BITS
2836 006650 104031          ERROR    31          ;'CNTRL RDY' DIDN'T SET ON COMPLETION
2837                                     ;OF WRITE FORMAT
2838                                     ;WRT FMT WAS DONE STARTING AT <DSK-ADRES>
2839                                     ;INDICATED IN EROR MSGE.
2840 006652 004737 021234          3$: JSR      PC,CHKHE ;GO CHECK IF 'HE' OR 'ERR' BIT SET.
2841                                     ;IF YES, SAVE RKCS, ER, DS, DA.
2842                                     ;RETURN HERE IF ERROR.
2843 006656 104032          ERROR    32          ;'HE' OR 'ERR' BIT SET WHILE DOING
2844                                     ;A WRITE FORMAT
2845                                     ;WRT FMT WAS DONE STARTING AT <DSK-ADRES>
2846                                     ;INDICATED IN EROR MSGE.
2847 006660 004737 021262          4$: JSR      PC,CHKDA ;GO CHECK IF RKDA INCREMENTED CORRECTLY
2848                                     ;IF NOT, RETURN HERE.
2849 006664 104033          ERROR    33          ;RKDA SHOULD HAVE INCREMENTED BY
2850                                     ;1 SECTOR, IT DID NOT
2851 006666 004737 021316          5$: JSR      PC,CHKWC ;CHECK IF WORD COUNT OVERFLOWED, IF
2852                                     ;NOT RETURN HERE.
2853 006672 104034          ERROR    34          ;RKWC DID NOT OVERFLOW TO 0, AFTER
2854                                     ;XFER ON WRITE FORMAT
2855 006674 022712 034342          6$: CMP      #OUTBUF+1000,@R2 ;DID RKBA INCREMENT CORRECTLY?
2856 006700 001406          BEQ     7$          ;YES, BRANCH
2857 006702 012737 034342 001162 MOV      #OUTBUF+1000,$REG0 ;GET EXPCD RKBA
2858 006710 011237 001164          MOV      @R2,$REG1  ;GET ACTUAL RKBA
2859 006714 104035          ERROR    35          ;RKBA DIDN'T INCREMENT BY 1000 AFTER
2860                                     ;WRITE FORMAT OF 400 WORDS
2861 006716 004737 021342          7$: JSR      PC,CHKER ;CHECK IOF ANY BIT IN RKER SET.
2862                                     ;IF YES RETURN HERE.
2863 006722 104036          ERROR    36          ;RKER BIT SET ON DOING 1 WORD
2864                                     ;WRITE FORMAT
2865 006724 022711 002202          8$: CMP      #2202,@R1    ;DOES RKCS STILL HAVE 'WRT FMT' BITS?
2866 006730 001406          BEQ     TST16       ;YES, EXIT
2867 006732 012737 002202 001162 MOV      #2202,$REG0 ;GET EXP:TD RKCS
2868 006740 011137 001164          MOV      @R1,$REG1  ;GET ACTUAL RKCS
2869 006744 104024          ERROR    24          ;RKCS DIDN'T CONTAIN 'WRT FMT' BITS
2870                                     ;AFTER THE FUNCTION WAS COMPLETED
2871                                     ;
2872                                     ;*****
2873                                     ;*TEST 16 CHECK 'READ FORMAT' FUNCTION-CYLINDER 0, SECTOR 0
2874                                     ;*THIS TEST CHECKS THE LOGIC INVOLVED IN THE WRITE FMT
2875                                     ;*FUNCTION. ON ISSUING A WRT FMT, THE FOLLOWING IS CHECKED
2876                                     ;*1) CNTRL RDY WAS CLEARED AS GO WAS SET.
2877                                     ;*2) CNTRL RDY SETS WITHIN A CERTAIN TIME ON COMPLETION OF FUNCTION

```

```

2878                                     ;*3) IF 'HE' OR 'ERR' BIT SET?
2879                                     ;*4) IF RKDA INCREMENTED CORRECTLY FROM 0 TO 1?
2880                                     ;*5) IF RKWC OVERFLOWED CORRECTLY TO 0?
2881                                     ;*6) IF RKBA INCREMENTED CORRECTLY BY 2?
2882                                     ;*7) IF ANY BIT IN RKER SET?
2883                                     ;*8) IF THE CORRECT HEADER WAS RECEIVED?
2884                                     ;*9) FOR RK11C, AFTER RD FMT RKDB CONTAINS THE CHECKSUM
2885                                     ;*FOR THAT SECTOR. (125252 IN THIS CASE, BECAUSE THE
2886                                     ;*FIRST WORD IN SEC 0 WAS WRITTEN AS 125252 IN
2887                                     ;*THE PREVIOUS TEST)
2888                                     ;*10) FOR RK11D, AFTER RD FMT RKDB SHOULD CONTAIN
2889                                     ;*A ZERO
2890                                     ;*11) IF THE RD FMT FUNCTION BITS ARE STILL IN
2891                                     ;*THE RKCS?
2892                                     ;*****
2893 TST16: SCOPE
2894 CLR      RO
2895 CNT.RESET          ;GO, DO CONTROL RESET
2896                                     ;THIS IS A CALL FOR THE 'CNTRL-
2897 ;RESET' ROUTINE. A CONTROL RESET IS
2898 ;ISSUED AND AFTER A CERTAIN TIME
2899 ;IF THE 'CNTRL RDY' DOES NOT SET
2900 ;AN ERROR IS REPORTED. NOTE THAT
2901 ;THE PC IN ERROR MESSAGE IS THE
2902 ;PC WHERE 'CNT.RESET' IS LOCATED.
2903 ;THIS IS A VERY BASIC ERR & IF IT
2904 ;OCCURS GO BACK TO TEST 10
2905 006754 104421          TST.SIN          ;GO CHECK IF SIN IS SET
2906                                     ;IF SET, DO DRIVE RESET TO CLR IT
2907 006756 013701 001332          MOV      RKCS,R1
2908 006762 013702 001336          MOV      RKBA,R2
2909 006766 012703 033342          MOV      #OUTBUF,R3
2910 006772 010312          MOV      R3,@R2    ;SETUP ADRS WHERE HEADER WORD IS TO BE
2911                                     ;X-FERRED
2912 006774 012777 177777 172332          MOV      #-1,@RKWC ;SET UP WORD COUNT
2913 007002 013777 001350 172330          MOV      DRIVAD,@RKDA ;SET UP DISK ADRS, SECTOR 0, CYLINDER 0
2914 007010 012711 002005          MOV      #2005,@R1 ;READ FORMAT, GO
2915
2916 007014 105711          1$: TSTB   @R1          ;WAS 'CNTRL RDY' CLEARED AS GO WAS SET?
2917 007016 100003          BPL      2$          ;YES, BRANCH
2918 007020 004737 021002          JSR      PC,GT3RG   ;GO, GET RKCS, RKER
2919 007024 104030          ERROR    30          ;CNTRL RDY DIDN'T CLEAR AS GO WAS
2920                                     ;SET TO 'READ FORMAT'
2921 007026 005000          2$: CLR      RO          ;WAS 'CNTRL RDY' SET ON COMPLETION OF
2922 007030 105711          TSTB   @R1          ;TRANSFER
2923                                     ;YES, BRANCH
2924 007032 100411          BMI      3$          ;NO, HAVE U WAITED LONG ENOUGH?
2925 007034 005200          INC      RO          ;IF NOT, LOOP BACK & WAIT
2926 007036 001374          BNE     2$+2        ;IF YES, REPORT ERROR
2927
2928 007040 004737 020774          JSR      PC,GT4RG   ;GO, GET RKCS, ER, DS,DA
2929 007044 013737 001350 001202 MOV      DRIVAD,$REG10
2930 007052 104416          BRKDA4          ;GO TO 'BDA4' & BREAK CONTENTS OF
2931                                     ;$REG10 INTO DR #,CYL,SUR,SFC BITS
2932 007054 104045          ERROR    45          ;'CNTRL RDY' DIDN'T SET ON COMPLETION
2933                                     ;OF READ FORMAT

```

```

2934                                     ;READ FMT WAS DONE STARTING AT <DSK-ADRES>
2935                                     ;INDICATED IN EROR MESGE
2936 007056 004737 021234                35:   JSR    PC,CHKHE ;CHECK IF 'ERR' OR 'HE' BIT SET, IF
2937                                     ;YES RETURN HERE.
2938 007062 104046                        ERROR  46   ;'HE' OR 'ERR' BIT SET WHILE
2939                                     ;DOING A 'READ FORMAT'
2940                                     ;READ FMT WAS DONE STARTING AT <DSK-ADRES>
2941                                     ;INDICATED IN EROR MESGE
2942 007064 004737 021262                45:   JSR    PC,CHKDA ;CHECK IF RKDA INCREMENTED CORRECTLY
2943                                     ;IF NOT, RETURN HERE.
2944 007070 104040                        ERROR  40   ;RKDA SHOULD HAVE INCREMENTED
2945                                     ;BY 1 SECTOR, IT DID NOT
2946
2947 007072 004737 021316                55:   JSR    PC,CHKWC ;CHECK IF RKWC OVERFLOWED TO 0, IF
2948                                     ;NOT RETURN HERE.
2949 007076 104041                        ERROR  41   ;RKWC DID NOT OVERFLOW TO 0
2950                                     ;AFTER XFER ON READ FORMAT
2951 007100 022712 033344                65:   CMP    #OUTBUF+2,@R2 ;DID RKBA INCREMENT TO NXT WORD ADDR?
2952 007104 001406                        BEQ    75     ;YES, BRANCH
2953 007106 012737 033344 001162        MOV    #OUTBUF+2,$REG0 ;GET EXPCTD RKBA
2954 007114 011237 001164                MOV    @R2,$REG1    ;GET ACTUAL RKBA
2955 007120 104042                        ERROR  42   ;RKBA DIDN'T INCREMENT BY 2 AFTER
2956                                     ;'READ FORMAT' OF 1 WORD
2957 007122 004737 021342                75:   JSR    PC,CHKER ;CHECK IF ANY BIT IN RKER SET, IF
2958                                     ;YES RETURN HERE.
2959 007126 104036                        ERROR  36   ;RKER BIT SET ON DOING
2960                                     ;1 WORD READ FORMAT
2961 007130 005713                        85:   TST    @R3       ;DOES OUTBUF CONTAIN THE HEADER
2962                                     ;WORD-0
2963                                     ;YES, BRANCH
2964 007132 001407                        BEQ    95     ;GET SECTOR NO.
2965 007134 005037 001162                CLR    $REG0       ;EXPCTD HEADER
2966 007140 005037 001164                CLR    $REG1       ;GET HEADER RECVD
2967 007144 011337 001166                MOV    @R3,$REG2   ;CORRECT HEADER WORD-0-WAS
2968 007150 104043                        ERROR  43   ;NOT RECEIVED ON READ FORMAT
2969 007152 022711 002204                95:   CMP    #2204,@R1  ;DOES RKCS HAVE THE 'RDFMT' BITS?
2970 007156 001406                        BEQ    TST17      ;YES, BRANCH
2971 007160 012737 002204 001162        MOV    #2204,$REG0 ;GET EXPCTD RKCS
2972 007166 011137 001164                MOV    @R1,$REG1   ;GET ACTUAL RKCS
2973 007172 104024                        ERROR  24   ;RKCS DIDN'T CONTAIN 'RD FMT'
2974                                     ;BITS AFTER FUNCTION WAS
2975                                     ;COMPLETED
2976
2977
2978
2979
2980 ;*****
2981 ;*TEST 17 CHECK 'READ' FUNCTION-CYLINDER 0,SECTOR 0
2982 ;*THIS IS THE FIRST TIME A PURE READ IS PREFORMED IN THIS
2983 ;*TEST SEQUENCE. THE FOLLOWING IS CHECKED
2984 ;*1) CNTRL RDY CLEARS AS GO IS SET
2985 ;*2) CNTRL RDY SETS WITHIN A CERTAIN TIME ON COMPLETION
2986 ;*OF FUNCTION
2987 ;*3) IF 'HE' OR 'ERR' BIT SET?
2988 ;*4) IF RKDA INCREMENTED CORRECTLY?
2989 ;*5) IF RKWC OVERFLOWED TO 0?
2990 ;*6) IF RKBA INCREMENTED CORRECTLY?

```

```

2990                                     ;*7) IF ANY RKER BIT SET?
2991                                     ;*8) IF THE CORRECT PSUEDO-HEADER (FIRST WORD) WAS
2992                                     ;*READ FROM SECTOR 0
2993                                     ;*9) IF THE 'READ' FUNCTION BITS ARE STILL IN RKCS
2994 ;*****
2995 007174 000004                        TST17: SCOPE
2996 007176 104413                        CNT.RESET
2997                                     ;GO, DO CONTROL RESET
2998                                     ;THIS IS A CALL FOR THE 'CNTRL-
2999                                     ;RESET' ROUTINE. A CONTROL RESET IS
3000                                     ;ISSUED AND AFTER A CERTAIN TIME
3001                                     ;IF THE 'CNTRL RDY' DOES NOT SET
3002                                     ;AN ERROR IS REPORTED. NOTE THAT
3003                                     ;THE PC IN ERROR MESSAGE IS THE
3004                                     ;PC WHERE 'CNT.RESET' IS LOCATED.
3005                                     ;THIS IS A VERY BASIC ERR & IF IT
3006                                     ;OCCURS GO BACK TO TEST 10
3007 007200 104421                        TST.SIN   ;GO CHECK IF SIN IS SET
3008                                     ;IF SET, DO DRIVE RESET TO CLR IT
3009 007202 013701 001332                MOV    RKCS,R1
3010 007206 005000                        CLR    R0
3011 007210 013702 001336                MOV    RKBA,R2
3012 007214 012703 033342                MOV    #OUTBUF,R3
3013 007220 010312                        MOV    R3,@R2
3014 007222 012777 177400 172104        MOV    #-400,@RKWC ;SET UP ADDR WHERE DATA WORD IS
3015 007230 013777 001350 172102        MOV    DRIVAD,@RKDA ;TO BE X-FERRED
3016 007236 012711 000005                MOV    #5,@R1      ;SET UP WORD COUNT
3017                                     ;SET UP DISK ADRS, SECTOR 0, CYLINDER 0
3018 007242 105711                        15:   TSTB   @R1       ;READ, GO
3019 007244 100003                        BPL    25
3020 007246 004737 021002                JSR    PC,GT3RG    ;WAS 'CNTRL RDY' CLEARED AS GO WAS SET?
3021 007252 104030                        ERROR  30   ;YES, BRANCH
3022                                     ;GO, GET RKCS, ER
3023 007254 005000                        25:   CLR    R0       ;CNTRL RDY DID NOT CLEAR AS GO
3024 007256 105711                        TSTB   @R1       ;WAS SET TO 'READ'
3025                                     ;WAS CNTRL RDY SET ON COMPLETION
3026 007260 100411                        BMI    35
3027 007262 005200                        INC    R0
3028 007264 001374                        BNE    25+2      ;OF TRANSFER?
3029                                     ;YES, BRANCH
3030 007266 004737 020774                JSR    PC,GT4RG    ;NO, HAVE U WAITED LONG ENOUGH?
3031 007272 013737 001350 001202        MOV    BRKDA4     ;IF NOT, LOOP BACK & WAIT
3032 007300 104416                        BRKDA4 ;IF YES, REPORT ERROR
3033                                     ;GO, GET RKCS, ER, DS,DA
3034 007302 104045                        ERROR  45   ;GO TO 'BD44' & BREAK CONTENTS OF
3035                                     ;$REG10 INTO DR #,CYL,SUR,SEC BITS
3036                                     ;CNTRL RDY DID NOT SET ON
3037                                     ;COMPLETION OF READ
3038                                     ;READ WAS DONE STARTING AT <DSK-ADRES>
3039 007304 004737 021234                35:   JSR    PC,CHKHE ;INDICATED IN EROR MESGE
3040 007310 104046                        ERROR  46   ;CHECK IF 'ERR' OR 'HE' BIT IS SET
3041                                     ;IF YES, RETURN HERE
3042                                     ;'HE' OR 'ERR' BIT SET WHILE
3043                                     ;DOING A READ.
3044                                     ;READ WAS DONE STARTING AT <DSK-ADRES>
3045 007312 004737 021262                45:   JSR    PC,CHKDA ;INDICATED IN EROR MESGE
3046                                     ;CHECK IF RKDA INCREMENTED CORRECTLY,

```

```

3046                                     ;IF NOT RETURN HERE.
3047 007316 104040                       ERROR 40                       ;RKDA DID NOT INCREMENT
3048                                     ;BY 1 (SECTOR)
3049 007320 004737 021316                 5$: JSR PC,CHKWC                 ;CHECK IF RKWC OVERFLOWED TO 0,
3050                                     ;IF NOT RETURN HERE.
3051 007324 104041                       ERROR 41                       ;RKWC DID NOT OVERFLOW TO 0,
3052                                     ;AFTER X-FER ON READ
3053 007326 022712 034342                 6$: CMP #OUTBUF+1000,@R2         ;DID RKBA INCREMENT CORRECTLY?
3054 007332 001406                       BEQ 7$                          ;YES, BRANCH
3055 007334 012737 034342 001162         MOV #OUTBUF+1000,$REG0          ;GET EXPCTD RKBA
3056 007342 011237 001164                 MOV @R2,$REG1                  ;GET ACTUAL RKBA
3057 007346 104042                       ERROR 42                       ;RKBA DID NOT INCREMENT BY 2
3058                                     ;AFTER 'READ' OF 1 WORD
3059 007350 004737 021342                 7$: JSR PC,CHKR                 ;CHECK IF ANY BIT IN RKER SET,
3060                                     ;IF YES RETURN HERE.
3061 007354 104036                       ERROR 36                       ;RKER BIT SET ON DOING 1
3062                                     ;WORD 'READ'
3063 007356 022713 000001                 8$: CMP #1,@R3                 ;DCES OUTBUF CONTAIN THE RIGHT
3064                                     ;DATA WORD
3065 007362 001411                       BEQ 9$                          ;YES BRANCH
3066 007364 012737 000001 001162         MOV #1,$REG0                  ;GET EXPCTD DATA WORD
3067 007372 011337 001164                 MOV (R3),$REG1                ;GET RECVD DATA WORD
3068 007376 013737 001350 001166         MOV DRIVAD,$REG2              ;GET DISK ADRS FROM WHICH READ WAS DONE
3069 007404 104044                       ERROR 44                       ;DID NOT READ THE CORRECT
3070                                     ;DATA WORD--FROM DISK ADRES,
3071                                     ;
3072                                     ;SEC 0, CYL 0, SUR 0
3073                                     ;
3074                                     ;AFTER 1 SECTOR READ RKDB CONTAINS
3075                                     ;FOR RK11C
3076                                     ;THE CHECKSUM FOR THAT SECTOR
3077                                     ;FOR RK11D
3078                                     ;THE LAST WORD TRANSFERRED TO MEMORY
3079                                     ;
3080                                     ;IT SO HAPPENS THAT WITH THE SECTOR
3081                                     ;THAT WAS READ, RKDB CONTAINS THE
3082                                     ;SAME INFORMATION FOR BOTH RK11C
3083                                     ;AND RK11D
3084 007406 022777 125252 171726 9$: CMP #125252,@RKDB             ;DOES RKDB CONTAIN THE EXPCTD WORD?
3085 007414 001407                       BEQ 10$                         ;YES, BRANCH
3086 007416 012737 125252 001162         MOV #125252,$REG0            ;GET EXPCTD RKDB
3087 007424 017737 171712 001164         MOV @RKDB,$REG1              ;GET RECVD RKDB
3088 007432 104037                       ERROR 37                       ;RKDB DOES NOT CONTAIN THE
3089                                     ;EXPCTD WORD AFTER A READ OF SEC 0
3090                                     ;CYL 0
3091 007434 022711 000204                 10$: CMP #204,@R1              ;DOES RKCS HAVE THE 'READ' BITS?
3092 007440 001406                       BEQ 11$                         ;YES, BRANCH
3093 007442 012737 000204 001162         MOV #204,$REG0               ;GET EXPCTD RKCS
3094 007450 011137 001164                 MOV @R1,$REG1                ;GET RECVD RKCS
3095 007454 104024                       ERROR 24                       ;RKCS DID NOT CONTAIN 'READ'
3096                                     ;FUNCTION BITS AFTER OPERATION
3097                                     ;WAS COMPLETED
3098 007456 104413                 11$: CNT.RESET                ;GO DO CONTROL RESET
3099 007460 005777 171656                 TST @RKDB                     ;DID CONTROL RESET CLEAR RKDB?
3100 007464 001407                       BEQ TST20                      ;YES, EXIT
3101 007466 013737 001342 001164         MOV RKDB,$REG1               ;GET ADRES OF RKDB

```

```

3102 007474 017737 171642 001164         MOV @RKDB,$REG1              ;GET CONTENTS OF RKDB
3103 007502 104102                       ERROR 102                      ;CONTROL RESET DIDN'T CLR RKDB
3104
3105 ;:*****
3106 ;*TEST 20 CHECK 'WRITE FORMAT' -CYLINDER 0, SECTOR 0-13
3107 ;*THIS TEST GOES ONE STEP FURTHER. & PERFORMS A WRT
3108 ;*FMT ON CYLINDER 0 & CHECKS THE FOLLOWING
3109 ;*1) IF CNTRL RDY SET WITHIN A CERTAIN TIME ON COMPLETION
3110 ;*OF THE FUNCTION
3111 ;*2) IF 'HE' OR 'ERR' BIT SET?
3112 ;*3) IF THE RKDA INCREMENTS CORRECTLY?
3113 ;*4) IF THE RKDB IS CLEAR?
3114 ;*WRT FMT IS DONE ONE SECTOR AT A TIME
3115 ;*THE FIRST WORD OF EVERY SECTOR IS WRITTEN AS A
3116 ;*PSEUDO-HEADER CONSISTING OF DRIVE #, CYLINDER #, SURFACE
3117 ;*& SECTOR #. THIS WILL BE READ & CHECKED IN THE FOLLOWING TEST.
3118 ;:*****
3119 007504 000004                 TST20: SCOPE
3120 007506 013703 001332         MOV RKCS,R3                  ;SET UP COUNT FOR 12 SECTORS
3121 007512 012702 177764         MOV #-14,R2
3122 007516 013704 001340         MOV RKDA,R4
3123 007522 013701 001350         MOV DRIVAD,R1                ;GET DRIVE ADDRESS
3124 007526 010105                 MOV R1,R5                    ;STORE IT
3125 007530 005205                 INC R5
3126 007532 012737 007540 001110         MOV #1$,$LPERR              ;SET RETURN ADRES FOR LUPING
3127                                     ;ON ERROR (SW 9)
3128 007540 104413                 1$: CNT.RESET                ;GO, DO CONTROL RESET
3129                                     ;THIS IS A CALL FOR THE 'CNTRL-
3130                                     ;RESET' ROUTINE. A CONTROL RESET IS
3131                                     ;ISSUED AND AFTER A CERTAIN TIME
3132                                     ;IF THE 'CNTRL RDY' DOES NOT SET
3133                                     ;AN ERROR IS REPORTED. NOTE THAT
3134                                     ;THE PC IN ERROR MESSAGE IS THE
3135                                     ;PC WHERE 'CNT.RESET' IS LOCATED.
3136                                     ;THIS IS A VERY BASIC ERR & IF IT
3137                                     ;OCCURS GO BACK TO TEST 10
3138 007542 104421                 TST.SIN                       ;GO CHECK IF SIN IS SET
3139                                     ;IF SET, DO DRIVE RESET TO CLR IT
3140 007544 005000                 CLR R0
3141 007546 010137 033342         MOV R1,OUTBUF                ;THIS WORD TO BE X-FERRED. FIRST
3142                                     ;WORD OF EACH SECTOR WILL BE THE
3143                                     ;ACTUAL DRIVE-ADRS CONSISTING OF
3144                                     ;DRIVE NO, CYL ADRES, SURFACE
3145                                     ;SECTOR NO.
3146 007552 012777 033342 171556         MOV #OUTBUF,@RKBA           ;ADRS FROM WHICH DATA WORD IS TO
3147                                     ;X-FERRED
3148 007560 012777 177777 171546         MOV #-1,@RKWC                ;SET UP WORD COUNT
3149 007566 010114                 MOV R1,@R4                   ;ADRS THE DRIVE, CYL 0, & CORRECT SECTOR
3150 007570 012713 002003         MOV #2003,@R3                ;WRITE FORMAT, GO
3151
3152 007574 105777 171532                 2$: TSTB @RKCS                ;DID 'CNTRL RDY' SET?
3153 007600 100410                 BMI 3$                        ;YES, BRANCH
3154 007602 005200                 INC R0                        ;NO, HAVE U WAITED LONG?
3155 007604 001373                 BNE 2$                        ;IF NOT, LOOP BACK & WAIT
3156                                     ;IF YES, REPORT ERROR
3157 007606 004737 020774         JSR PC,GT4RG                 ;GO, GET RKCS, ER, DS,DA

```



```

3270 ;RKBA SHOULD INCREMENT BY 24 BYTES
3271 ;AT THE END OF X-FER
3272 010032 022777 033372 171276 4$: CMP #OUTBUF+30,@RKBA ;DID RKBA INCREMENT CORRECTLY?
3273 010040 001407 BEQ 5$ ;YES, BRANCH
3274 010042 012737 033372 001162 MOV #OUTBUF+30,$REG0 ;GET EXPCTD RKBA
3275 010050 017737 171262 001164 MOV @RKBA,$REG1 ;GET ACTUAL RKBA
3276 010056 104042 ERROR 42 ;RKBA DID NOT INCREMENT CORRECTLY
3277 ;AFTER READ FORMAT OF 12 HEADERS
3278 010060 004737 021316 5$: JSR PC,CHKWC ;GO CHECK IF RKWC OVERFLOWED TO 0
3279 ;IF NOT RETURN HERE.
3280 010064 104041 ERROR 41 ;RKWC DID NOT OVERFLOW TO 0
3281 ;AFTER 'RD FMT' OF 12 HEADERS
3282 ;OF CYLINDER 0
3283 010066 005724 6$: TST (R4)+ ;WAS THE CORRECT HEADER RECEIVED?
3284 010070 001413 BEQ 7$ ;YES, BRANCH
3285 010072 010037 001162 MOV R0,$REG0 ;GET SECTOR FOR WHICH THE HEADER
3286 010076 062737 000014 001162 ADD #14,$REG0 ;COULD NOT BE READ CORRECT
3287 010104 005037 001164 CLR $REG1 ;EXPTD HEADER=0, FOR CYL 0
3288 010110 014437 001166 MOV -(R4),$REG2 ;GET WRONG HEADER RCVD
3289 010114 104043 ERROR 43 ;HEADER WAS NOT READ RIGHT FOR
3290 ;SECTOR (AS IN ER MSGE), & CYL 0
3291 010116 005724 7$: TST (R4)+ ;WAS THE CORRECT HEADER RCVD?
3292 010120 005200 INC R0 ;YES, HAVE U CHECKED FOR ALL 12 SECTORS?
3293 010122 001361 BNE 6$ ;IF NOT, LOOP BACK & CHK HDR FRM NXT SECTR
3294 JSR PC,CHKER ;CHECK IF ANY BIT IN RKER IS SET,
3295 010124 004737 021342 ;IF YES, RETURN HERE.
3296 ERROR 36 ;RKER BIT SET ON DOING RD FMT
3297 010130 104036 ;OF CYL 0, SECTORS 0-13
3298 8$: CMP #2204,@R1 ;DOES RKCS STILL CONTAIN FUNCTION BITS?
3299 BEQ TST22 ;YES, EXIT
3300 010136 001406 MOV #2204,$REG0 ;GET EXPCTD RKCS
3301 010140 012737 002204 001164 MOV @R1,$REG1 ;GET ACTUAL RKCS
3302 010146 011137 001164 MOV @R1,$REG1 ;GET ACTUAL RKCS
3303 010152 104024 ERROR 24 ;RKCS DID NOT CONTAIN 'RD FMT'
3304 ;FUNCTION BITS ON COMPETION OF
3305 ;THE FUNCTION
3306
3307
3308
3309 ;*****
3310 ;*TEST 22 CHECK 'READ',CYLINDER 0, SECTORS 0 TO 13
3311 ;*THIS TEST PERFORMS A READ OF ALL THE SECTORS OF CYLINDER 0
3312 ;*8 CHECKS THE FOLLOWING
3313 ;*1) CNTRL RDY SETS WITHIN A CERTAIN TIME ON COMPLETION
3314 ;*OF THE FUNCTION
3315 ;*2) IF 'HE' OR 'ERR' BIT SET?
3316 ;*3) IF THE CORRECT PSEUDO-HEADER (FIRST WORD OF EVERY)
3317 ;*SECTOR, WRITTEN IN A PREVIOUS TEST) WAS RECEIVED.
3318 ;*4) IF RKCS CONTAINS THE CORRECT WORD.
3319 ;*4) IF RKDA INCREMENTED CORRECTLY.
3320 ;*5) IF REST OF THE (377) WORDS IN EACH SECTOR ARE '0', NOTE
3321 ;*PREVIOUSLY ONE WORD WAS WRITTEN PER SECTOR.
3322 ;*6) IF RKCS STILL CONTAINS THE 'READ' FUNCTION BITS
3323 ;*7) IF CONTROL RESET CLEARS RKDB.
3324 ;* IF TESTING IS BEING DONE ON A SIMULATOR ONLY LAST SECTOR(13)
3325 ;*IS READ BECAUSE THE SIMULATOR CAN STORE ONLY 1 SECTOR (256 WORDS).

```

```

3326 ;*HENCE ONLY THE DATA WRITTEN LAST CAN BE READ BACK.
3327 ;*****
3328 010154 000004 TST22: SCOPE
3329 010156 012737 010230 001110 MOV #1$,$LPERR ;SET RETURN ADRES FOR LUPING
3330 ;ON ERROR (SW 9)
3331 010164 013703 001332 MOV RKCS,R3
3332 010170 013701 001350 MOV DRIVAD,R1
3333 010174 010105 MOV R1,R5
3334 010176 012704 033342 MOV #OUTBUF,R4
3335 010202 005737 001344 TST SIMUL ;TESTING ON SIMULATOR?
3336 010206 001405 BEQ 9$ ;NO, BRANCH
3337 ;IF TESTING ON SIMULATOR READ
3338 ;SECTOR 13 ONLY
3339 010210 052701 000013 BIS #13,R1 ;SET BITS FOR SEC 13
3340 010214 052705 000020 BIS #20,R5 ;RKDA SHOULD INCRMNT TO THIS AFTER READ
3341 010220 000403 BR 1$
3342 010222 012702 177764 9$: MOV #-14,R2 ;SET COUNT FOR 12 SECTORS
3343 010226 005205 INC R5 ;RKDA SHOULD INCREMENT TO
3344 ;THIS AFTER 1 SECTOR READ
3345 010230 104413 1$: CNT.RESET ;GO, DO CONTROL RESET
3346 ;THIS IS A CALL FOR THE 'CNTRL-
3347 ;RESET' ROUTINE. A CONTROL RESET IS
3348 ;ISSUED AND AFTER A CERTAIN TIME
3349 ;IF THE 'CNTRL RDY' DOES NOT SET
3350 ;AN ERROR IS REPORTED. NOTE THAT
3351 ;THE PC IN ERROR MESSAGE IS THE
3352 ;PC WHERE 'CNT.RESET' IS LOCATED.
3353 ;THIS IS A VERY BASIC ERR & IF IT
3354 ;OCCURS GO BACK TO TEST 10
3355 010232 104421 TST.SIN ;GO CHECK IF SIN IS SET
3356 ;IF SET, DO DRIVE RESET TO CLR IT
3357 010234 010177 171100 MOV R1,@RKDA ;ADDRESS THE DRIVE
3358 010240 010477 171072 MOV R4,@RKBA ;ADRS TO WHICH X-FER DATA FROM DISK
3359 010244 012777 177400 171062 MOV #-400,@RKWC ;SETUP WORD COUNT
3360 010252 012713 000005 MOV #5,@R3 ;READ,GO
3361
3362 010256 005000 CLR R0
3363 010260 105713 2$: TSTB @R3 ;DID CNTRL RDY SET ON COMPETION?
3364 010262 100410 BMI 3$ ;YES, BRANCH
3365 010264 005200 INC R0 ;NO, WAIT FOR IT TO SET
3366 010266 001374 BNE 2$ ;IF WAITED LONG ENOUGH, REPORT
3367 ;ERROR. OTHERWISE LOOP BAK & WAIT
3368 010270 004737 020774 JSR PC,GT4RG ;GO, GET RKCS, ER, DS,DA
3369 010274 010137 001202 MOV R1,$REG10 ;GET SECTOR ADDRESS WHERE ERROR OCCURED
3370 010300 104416 BRKDA4 ;GO TO 'BDA4' & BREAK CONTENTS OF
3371 ;$REG10 INTO DR #,CYL,SUR,SEC BITS
3372 010302 104045 ERROR 45 ;CNTRL RDY DID NOT SET ON COMPLETION
3373 ;OF READ OF CYLINDER 0, SECTOR
3374 ;AS SHOWN IN <DSK-ADRES>
3375 ;READ WAS DONE STARTING AT <DSK-ADRES>
3376 ;INDICATED IN EROR MESGE
3377 010304 004737 021226 3$: JSR PC,CHKHE1 ;CHECK IF 'ERR' OR 'HE' BIT IS SET,
3378 ;IF YES RETURN HERE.
3379 010310 104046 ERROR 46 ;HE OR ERR BIT SET
3380 ;ON 'READ' OF CYLINDER 0, SECTOR
3381 ;AS SHOWN IN <DSK-ADRES>

```

```

3382                                     ;READ WAS DONE STARTING AT <DSK-ADRES>
3383                                     ;INDICATED IN EROR MESGE
3384 010312 020114                       4$:  CMP      R1,(R4)      ;WAS THE DATA WORD RECVD, CORRECT?
3385                                     ;THE FIRST DATA WORD OF EACH SECTOR
3386                                     ;IS AN ADRS WORD COMPRISING OF DRIVE NO,
3387                                     ;CYLINDER ADRS, SUR, SECTOR ADRS
3388 010314 001407                       BEQ      5$
3389 010316 010137 001162                MOV      R1,$REG0      ;GET EXPCTD DATA WORD FROM DISK
3390 010322 011437 001164                MOV      (R4),$REG1    ;GET THE DATA WORD RECVD
3391 010326 010137 001166                MOV      R1,$REG2      ;GET DISK ADRES
3392 010332 104044                       ERROR    44            ;DID NOT RECIEVE CORRECT DATA WCRD ON
3393                                     ;READ, OF CYLINDER 0, SECTOR AS SHOWN IN 'DSK
3394                                     ;ADRES' OF EXPCTD DATA WORD
3395 010334 004737 021270                5$:  JSR      PC,CHKDA1 ;CHECK IF RKDA INCREMENTED CORRECTLY,
3396                                     ;IF NOT RETURN HERE.
3397 010340 104040                       ERROR    40            ;RKDA DID NOT INCREMENT CORRECTLY
3398                                     ;AFTER READ OF 1 WORD, FROM CYL 0
3399                                     ;SEC IN ERROR IS 1 LESS THAN THAT
3400                                     ;SHOWN IN EXPCTD RKDA
3401                                     ;
3402                                     ;AS A RESULT OF 'WRT FMT' IN A PREVIOUS TEST
3403                                     ;FIRST WORD OF EVERY SECTOR IS NON-
3404                                     ;ZERO (PSUEDO-HDR), REST 377 WORDS
3405                                     ;ARE ALL 0'S.
3406                                     ;CHECK IF THE REST OF THE 377
3407                                     ;WORDS APE ALL 0'S
3408 010342 012737 177775 001370         MOV      #-3,EFLG1     ;ALLOW ONLY 3 ERRORS
3409 010350 012700 033344                 MOV      #OUTBUF+2,R0 ;INITIALIZE PTR TO 2ND WRD IN BUFR
3410 010354 012737 177401 001362         MOV      #-377,COUNT  ;CHECK 377 WORDS IN THE BUFFER
3411 010362 005710                       11$:  TST      @R0        ;IS THIS WRD 0?
3412 010364 001005                       BNE     12$           ;NO, ERROR
3413 010366 005720                       TST     (R0)+        ;INCRMNT PTR TO NXT WRD
3414 010370 005237 001362                INC      COUNT        ;CHKD ALL 377 WRDS?
3415 010374 001372                       BNE     11$
3416 010376 000412                       BR      7$            ;YES, BRANCH
3417 010400 005037 001162                12$:  CLR      $REG0     ;GET EXPCTD WORD
3418 010404 012037 001164                MOV     (R0)+,$REG1   ;GET WORD RECVD
3419 010410 010137 001166                MOV     R1,$REG2      ;GET DISK ADRES, ERROR IN THIS
3420                                     ;SECTOR
3421 010414 104044                       ERROR    44            ;DATA ERROR, THE LAST 377 WORDS
3422                                     ;READ FROM EACH SECTOR SHOULD BE 0
3423                                     ;IN A PREVIOUS TEST, FIRST WORD OF
3424                                     ;EVERY SEC (CYL 0) WAS WRITTEN AS A
3425                                     ;PSUEDO-HDR, REST OF THE WORDS IN THE
3426                                     ;SECTR ARE AUTOMATICALLY WRITTEN AS
3427                                     ;0'S. THIS ERROR MAY MEAN THAT IT
3428                                     ;DIDN'T HAPPEN SO
3429 010416 005237 001370                INC      EFLG1        ;ALLOW ONLY 3 DATA ERORS OF THIS KIND
3430 010422 001357                       BNE     11$
3431
3432
3433 010424 005737 001344                7$:  TST      SIMUL     ;TESTING ON SIMULATOR?
3434 010430 001011                       BNE     10$           ;YES BRANCH
3435                                     ;IF NOT TESTING ON SIMULATOR GO AHEAD
3436                                     ; & READ ALL 12 SECTORS ON CYL 0
3437 010432 005201                       INC      R1            ;INCREMENT DRIV-ADRES TO NXT SECTOR

```

```

3438 010434 005205                       INC      R5            ;INCREMENT 'EXPCTD DRIV-ADRES'
3439 010436 122705 000014                 CMPB    #14,R5        ;R U GOING TO READ THE LAST SECTOR?
3440 010442 001002                       BNE     .+6           ;IF NOT, BRANCH
3441 010444 062705 000004                 ADD     #4,R5         ;IF YES, INCREMENT 'EXPCTD RKDA'
3442                                     ;CORRECTLY
3443 010450 005202                       INC      R2            ;HAVE U READ ALL 12 SECTORS?
3444 010452 001266                       BNE     1$            ;IF NOT LOOP BACK & READ THE
3445                                     ;NXT SECTOR
3446 010454 022713 000204                10$:  CMP      #204,@R3  ;DDOS RKCS, STILL HAVE THE 'READ' FUNCTION
3447 010460 001406                       BEQ     8$            ;YES, BRANCH
3448 010462 012737 000204 001162         MOV      #204,$REG0   ;GET EXPCTD RKCS
3449 010470 011337 001164                 MOV     @R3,$REG1    ;GET RKCS RECVD
3450 010474 104024                       ERROR    24           ;RKCS SHOULD STILL CONTAIN THE 'READ'
3451                                     ;FUNCTION BITS
3452 010476 104413                       8$:  CNT.RESET        ;GO ,DO CONTROL RESET
3453                                     ;THIS IS A CALL FOR THE 'CNTRL-
3454                                     ;RESET' ROUTINE. A CONTROL RESET IS
3455                                     ;ISSUED AND AFTER A CERTAIN TIME
3456                                     ;IF THE 'CNTRL RDY' DOES NOT SET
3457                                     ;AN ERROR IS REPORTED. NOTE THAT
3458                                     ;THE PC IN ERROR MESSAGE IS THE
3459                                     ;PC WHERE 'CNT.RESET' IS LOCATED.
3460                                     ;THIS IS A VERY BASIC ERR & IF IT
3461                                     ;OCCURS GO BACK TO TEST 10
3462 010500 005777 170636                 TST     @RKDB         ;DID CNTRL RESET CLEAR RKDB?
3463 010504 001407                       BEQ     TST23        ;YES, EXIT
3464 010506 013737 001342 001162         MOV      RKDB,$REG0   ;GET ADRES OF RKDB
3465 010514 017737 170622 001164         MOV      @RKDB,$REG1 ;GET CONTENTS OF RKDB
3466 010522 104102                       ERROR    102         ;CONTROL RESET DID NOT
3467                                     ;CLEAR RKDB

```

```

3470
3471 ;*****
3472 ;*TEST 23 CHECK 'WRITE FORMAT' OF THE DISK
3473 ;*THIS TEST WRITE FORMATS THE ENTIRE DISK. THE FIRST
3474 ;*WORD OF EVERY SECTOR IS WRITTEN TO BE A PSUEDO-HEADER
3475 ;*CONSISTING OF THE DRIVE #, CYLINDER #, SURFACE & SECTOR #.
3476 ;*1 SECTOR IS WRITTEN A TIME. THE WRITING IS DONE
3477 ;*IN THIS ORDER: CYL 0-SUR 0; CYL 0-SUR 1; CYL 1-SUR 0
3478 ;*CYL 1-SUR 1; CYL 2-SUR 0; CYL 2-SUR 1----- CYL 312-SUR 1.
3479 ;*IMPORTANCE OF THIS TEST SHOULD BE REALIZED, THIS IS
3480 ;*THE FIRST TIME EACH & EVERY SECTOR ON THE DISK IS
3481 ;*ACCESSED & WRITTEN ON. THIS IS THE FIRST TIME RKDA
3482 ;*IS BEING MADE TO INCREMENT OVER THE ENTIRE DISK (FROM
3483 ;*000000 TO 014520) IF A 'SIN' OCCURS AT ANY POINT
3484 ;*A DRIVE RESET IS DONE BEFORE DOING WRT FMT FOR THE NEXT
3485 ;*SECTOR. ANY OTHER ERROR IS CLEARED THROUGH A CONTROL RESET.
3486 ;*THE FOLLOWING CHECKING IS DONE AFTER WRITING EACH
3487 ;*CYLINDER.
3488 ;*1. CNTRL RDY SETS WITHIN A CERTAIN TIME ON COMPLETION
3489 ;*OF THE FUNCTION.
3490 ;*2. IF 'SIN' OCCURRED?
3491 ;*3. IF 'HE' OR 'ERR' BIT SET?
3492 ;*4. IF RKDA INCREMENTED CORRECTLY, INCLUDING BOUNDARY
3493 ;*CONDITIONS (SECTOR COUNTER BITS OVERFLOWING INTO SURFACE,
3494 ;*SURFACE BIT OVERFLOWING INTO CYLINDER BITS) AT THE END

```



```

3494 ;*OF THIS POINTERS ARE INCREMENTED ADJUSTED, ETC.
3495 ;*& 'WRT FMT' ON THE NEXT SECTOR IS DONE.
3496 ;:*****
3497 010524 000004 TST23: SCOPE
3498 010526 012737 000001 001206 MOV #1,$TIMES ;:DO 1 ITERATION
3499 010534 012737 010564 001110 MOV #1,$LPERR ;:SET RETURN ADRES FOR LUPING
3500 ;:ON ERROR (SW 9)
3501 010542 005003 CLR R3 ;:(R3)=0, SURFACE 0 BEING WRITTEN
3502 ;:(R3)=1, SURFACE 1 BEING WRITTEN
3503 010544 012704 177465 MOV #-313,R4 ;:SET UP COUNT FOR 203 CYLINDERS
3504 010550 012702 177764 MOV #-14,R2 ;:SET UP COUNT FOR 12 SECTORS
3505 010554 013701 001350 MOV DRIVAD,R1 ;:GET DRIVE ADRES
3506 010560 010105 MOV R1,R5 ;:STORE IT
3507 010562 005205 INC R5
3508 010564 104413 1$: CNT.RESET ;:GO, DO CONTROL RESET
3509 ;:THIS IS A CALL FOR THE 'CNTRL-
3510 ;:RESET' ROUTINE. A CONTROL RESET IS
3511 ;:ISSUED AND AFTER A CERTAIN TIME
3512 ;:IF THE 'CNTRL RDY' DOES NOT SET
3513 ;:AN ERROR IS REPORTED. NOTE THAT
3514 ;:THE PC IN ERROR MESSAGE IS THE
3515 ;:PC WHERE 'CNT.RESET' IS LOCATED.
3516 ;:THIS IS A VERY BASIC ERR & IF IT
3517 ;:OCCURS GO BACK TO TEST 10
3518 010566 104421 TST.SIN ;:GO CHECK IF SIN IS SET
3519 ;:IF SET, DO DRIVE RESET TO CLR IT
3520 010570 005037 001362 7$: CLR COUNT
3521 010574 010137 033342 MOV R1,OUTBUF ;:THIS WORD TO BE WRITTEN. THE FIRST
3522 ;:WORD OF EACH SECTOR WILL BE THE ACTUAL
3523 ;:DISK-ADRES, CONSISTING OF THE DRIVE NO.,
3524 ;:CYL ADRES, SURFACE BIT SECTOR ADRES
3525 010600 012777 033342 170530 MOV #OUTBUF,@RKBA ;:ADRES FROM WHICH WORD IS TO B X-FERRED
3526 010606 012777 177777 170520 MOV #-1,@RKWC ;:SET UP WORD COUNT
3527 010614 010177 170520 MOV R1,@RKDA ;:ADRES THE DRIVE, WITH CORRECT CYL
3528 ;:& SECTOR ADRES
3529 010620 012777 002003 170504 MOV #2003,@RKCS ;:WRITE FORMAT, GO
3530 3531 010626 105777 170500 2$: TSTB @RKCS ;:DID CNTRL RDY SET
3532 010632 100411 BMI 3$ ;:YES, BRANCH
3533 010634 005237 001362 INC COUNT ;:NO, HAVE U WAITED LONG ENOUGH?
3534 010640 001372 BNE 2$ ;:IF NOT, LOOP BACK & WAIT
3535 ;:IF YES, REPORT ERROR
3536 010642 004737 020774 JSR PC,GT4RG ;:GO, GET RKCS, ER, DS,DA
3537 010646 010137 001202 MOV R1,$REG10 ;:GET DISK ADRES, WHERE ERROR OCCURED
3538 010652 104416 BRKDA4 ;:GO TO 'BDA4' & BREAK CONTENTS OF
3539 ;:$REG10 'NTG DR #,CYL,SUR,SEC BITS
3540 010654 104031 ERROR 31 ;:CNTRL RDY DID NOT SET ON COMPLETION
3541 ;:OF 'WRITE FORMAT', ON SECTGR AS
3542 ;:SHOWN IN <DSK-ADRES>
3543 ;:WRT FMT WAS DONE STARTING AT <DSK-ADRES>
3544 ;:INDICATED IN EROR MSGE.
3545 010656 032777 001000 170442 3$: BIT #1000,@RKDS ;:DID SIN BIT SET?
3546 010664 001405 BEQ 4$ ;:NO, BRANCH
3547 010666 004737 021002 JSR PC,GT3RG ;:GO, GET RKCS, ER, DS
3548 010672 010137 001170 MOV R1,$REG3 ;:GET, DISK-ADRES WHERE ERROR OCCURED
3549 010676 104001 ERROR 1 ;:SIN SET WHILE DOING WRT FMT

```

```

3550 ;:TO DISK-ADRES (AS IN $REG3)
3551 3552 010700 004737 021226 4$: JSR PC,CHKHE1 ;:CHECK IF 'ERR' OR 'HE' BIT IS SET
3553 ;:IF YES, RETURN HERE.
3554 010704 104032 ERROR 32 ;:HE OR ERR SET WHILE DOING WRITE
3555 ;:FORMAT ON SECTOR AS INDICATED IN
3556 ;:<DSK-ADRES>
3557 ;:WRT FMT WAS DONE STARTING AT <DSK-ADRES>
3558 ;:INDICATED IN EROR MSGE.
3559 010706 004737 021270 5$: JSR PC,CHKDA1 ;:CHECK IF RKDA INCREMENTED CORRECTLY,
3560 ;:IF NOT, RETURN HERE.
3561 010712 104033 ERROR 33 ;:RKDA DID NOT INCREMENT CORRECTLY
3562 ;:AFTER 'WRITE FORMAT' WAS DONE
3563 ;:TO THE SECTOR PREVIOUS TO THAT
3564 ;:INDICATED IN 'EXPCTD' RKDA
3565 010714 005201 6$: INC R1 ;:INCREMENT TO THE NXT SECTOR
3566 010716 005205 INC R5 ;:INCREMENT R5, TO WHAT RKDA WILL INCREMENT
3567 010720 022702 177776 CMP #-2,R2 ;:R U GOING TO FORMAT THE LAST SECTOR
3568 ;:IN THE CYLINDER ?
3569 010724 001002 BNE .+6 ;:IF NOT, BRANCH
3570 010726 062705 000004 ADD #4,R5 ;:INCREMENT R5 CORRECTLY TO 'EXPCTD RKDA'
3571 010732 005202 INC R2 ;:HAVE U FORMATTED ALL 12 SECTORS
3572 ;:ON THIS CYLINDER
3573 010734 001313 BNE 1$ ;:IF NOT, LOOP BACK & FORMAT THE
3574 ;:NEXT SECTOR
3575 ;:YES
3576 010736 012702 177764 MOV #-14,R2 ;:RESET THE COUNT FOR 12 SECTORS
3577 010742 042701 000037 BIC #37,R1 ;:CLEAR THE SEC ADRES BITS
3578 010746 005703 TST R3 ;:SURFACE 1?
3579 010750 001006 BNE 8$ ;:YES, BRANCH
3580 010752 005203 INC R3 ;:NO, SET FLAG
3581 010754 062701 000020 ADD #20,R1 ;:INCREMENT TO THE NXT SURFACE
3582 010760 010105 MOV R1,R5 ;:THIS IS WHAT RKDA SHOULD
3583 010762 005205 INC R5 ;:INCREMENT TO.
3584 010764 000677 BR 1$ ;:GO, DO NXT SURFACE
3585 010766 062701 000040 8$: ADD #40,R1 ;:INCREMENT TO NXT CYL
3586 010772 010105 MOV R1,R5 ;:POSITION FOR
3587 010774 005205 INC R5 ;:EXPCTD RKDA
3588 010776 005003 CLR R3
3589 011000 005204 INC R4 ;:HAVE U FORMATTED ALL 203 CYLINDERS
3590 011002 001270 BNE 1$ ;:IF NOT, LOOP BACK & FORMAT THE
3591 ;:NEXT CYLINDER
3592
3593 ;:*****
3594 ;:TEST 24 CHECK 'READ FORMAT' FOR THE ENTIRE DISK
3595 ;:THIS TEST READ FORMATS THE ENTIRE DISK, WHICH WAS WRT
3596 ;:FORMATTED IN THE PREVIOUS TEST. THE FOLLOWING CHECKING
3597 ;:IS DONE
3598 ;:1. CNTRL RDY SETS WITHIN A CERTAIN TIME ON COMPLETION
3599 ;:OF FUNCTION
3600 ;:2. IF 'SIN' OCCURRED?
3601 ;:3. IF 'HE' OR 'ERR' OCCURRED?
3602 ;:4. RKDA INCREMENTED CORRECTLY.
3603 ;:5. IF THE CORRECT HEADER WAS READ.
3604
3605

```

```

3606 ;*6. IF RKWC OVERFLOWED CORRECTLY.
3607 ;*12 SECTORS (1 CYLINDER) ARE READ AT A TIME. IF 'SIN'
3608 ;*OCCURS A DRIVE RESET IS DONE BEFORE READING THE NEXT
3609 ;*SECTOR. READING IS DONE IN THIS ORDER: CYL 0-SUR 0;
3610 ;*CYL 0-SUR 1; CYL 1-SUR 0; CYL 1-SUR 1; CYL 2-SUR 0;
3611 ;*CYL 2-SUR 1;-----CYL 312-SUR 1. IF TESTING ON SIMULATOR, ONLY
3612 ;*THE LAST CYLINDER (312), LAST SECTOR (13), SURFACE 1 IS READ.
3613 ;*****
3614 011004 000004          TST24: SCOPE
3615 011006 012737 000001 001206  MOV      #1,$STIMES      ;:DD 1 ITERATION
3616 011014 012737 011100 001110  MOV      #1,$SLPERR     ;:SET RETURN ADRES FOR LUPING
3617                                ;ON ERROR ($W 0)
3618 011022 005037 001356  CLR      INDX1          ;:INDX1=0, SURFACE 0 BEING READ
3619                                ;:INDX1=1, SURFACE 1 BEING READ
3620 011026 013701 001350  MOV      DRIVAD,R1      ;:GET DRIVE ADRES
3621 011032 010102  MOV      R1,R2
3622 011034 005737 001344  TST     SIMUL           ;:TESTING ON SIMULATOR?
3623 011040 001410  BEQ     12$            ;:NO, BRANCH
3624 011042 052701 014533  BIS      #14533,R1      ;:SET BITS FOR CYL 312, SEC 13, SUR 1
3625                                ;ON SIMULATOR, CHECK ONLY CYL 312,
3626                                ;SECTOR 13, SURFACE 1
3627 011046 052702 014540  BIS      #14540,R2      ;:RKDA SHOULD INCRMNT TO THIS AFTR
3628                                ;RD FMT OF 1 SECTOR
3629 011052 012737 177777 001370  MOV      #-1,EFLG1      ;:SET COUNT FOR READING HDR
3630                                ;FROM 1 SECTOR ONLY
3631 011060 000407  BR      1$
3632 011062 012705 177465 12$: MOV      #-313,R5      ;:SET UP COUNT FOR 203 CYLINDERS
3633 011066 012737 177764 001370  MOV      #-14,EFLG1     ;:SET COUNT FOR 12 HRS TO BE
3634                                ;READ FROM EACH CYLINDER
3635 011074 062702 000020  ADD      #20,R2         ;:THIS IS WHAT RKDA SHOULD INCREMENT
3636                                ;BY, AFTER 'RD FMT' OF EACH CYLINDER
3637 011100 104413 1$: CNT.RESET ;:GO, DO CONTROL RESET
3638                                ;THIS IS A CALL FOR THE 'CNTRL-
3639                                ;RESET' ROUTINE. A CONTROL RESET IS
3640                                ;ISSUED AND AFTER A CERTAIN TIME
3641                                ;IF THE 'CNTRL RDY' DOES NOT SET
3642                                ;AN ERROR IS REPORTED. NOTE THAT
3643                                ;THE PC IN ERROR MESSAGE IS THE
3644                                ;PC WHERE 'CNT.RESET' IS LOCATED.
3645                                ;THIS IS A VERY BASIC ERR & IF IT
3646                                ;OCCURS GO BACK TO TEST 10
3647
3648 011102 104421          TST.SIN ;:CHECK IF SIN IS SET
3649                                ;IF SET DO DRV-RESET TO CLR IT
3650
3651 011104 012703 033342 11$: MOV      #OUTBUF,R3 ;:STORE ADRES OF BUFFER
3652 011110 005037 001360  CLR      INDX2
3653 011114 010377 170216  MOV      R3,@RKBA      ;:ADRES TO WHICH DATA IS TO BE X-FERRED
3654                                ;FROM THE DISK
3655 011120 013777 001370 170206  MOV      EFLG1,@RKWC    ;:SET UP WORD COUNT FOR 12 HEADERS
3656                                ;TO BE READ OFF EACH CYLINDER
3657                                ;(ONLY 1 FOR SIMULATOR)
3658 011126 010177 170206  MOV      R1,@RKDA      ;:ADRES THE DRIVE WITH CORRECT
3659                                ;CYLINDER & SECTOR ADRES
3660 011132 012777 002005 170172  MOV      #2005,@RKCS    ;:READ FORMAT, GO
3661

```

```

3662 011140 105777 170166 2$: TSTB   @RKCS ;:DID CNTRL RDY SET?
3663 011144 100411  BMI     3$ ;:YES, BRANCH
3664 011146 005237 001360  INC     INDX2 ;:NO, HAVE U WAITED LONG ENOUGH?
3665 011152 001372  BNE     2$ ;:IF NOT, LOOP BACK & WAIT FOR IT
3666                                ;:IF YES, REPORT ERROR
3667 011154 004737 020774  JSR     PC,GT4RG ;:GO, GET RKCS, ER, DS,DA
3668 011160 010137 001202  MOV     R1,$REG10 ;:GET DRIV-ADRES STARTING WHICH
3669                                ;'READ FORMAT' WAS DONE
3670 011164 104416  BRKDA4 ;:GO TO 'BDA4' & BREAK CONTENTS OF
3671                                ;$REG10 INTO DR #,CYL,SUR,SEC BITS
3672 011166 104045  ERROR   45 ;:CNTRL RDY DID NOT SET AFTER
3673                                ;READ FORMAT. 'RKDA' IN EROR MSGE
3674                                ;GIVES THE CONTENTS OF RKDA AT THE
3675                                ;TIME OF ERROR.
3676                                ;READ FMT WAS DONE STARTING AT <DSK-ADRES>
3677                                ;INDICATED IN EROR MSGE.
3678
3679 011170 032777 001000 170130 3$: BIT     #1000,@RKDS ;:DID 'SIN' SET?
3680 011176 001405  BEQ     4$ ;:NO, BRANCH
3681 011200 004737 021002  JSR     PC,GT3RG ;:GO, GET RKCS, ER, DS
3682 011204 010137 001170  MOV     R1,$REG3 ;:GET DISK-ADRES WHERE 'SIN'
3683                                ;OCCURED
3684 011210 104001  ERROR   1 ;:SIN ERROR ON DOING RD FMT
3685                                ;TO CYL INDICATED IN $REG3
3686
3687 011212 004737 021226 4$: JSR     PC,CHKHE1 ;:CHECK IF 'ERR' OR 'HE' BIT IS SET.
3688                                ;IF YES, RETURN HERE.
3689 011216 104046  ERROR   46 ;:HE OR ERR WHILE DOING A READ
3690                                ;FORMAT. 'RKDA' IN EROR MSGE GIVES
3691                                ;THE CONTENTS OF RKDA AT THE TIME OF ERROR
3692                                ;READ FMT WAS DONE STARTING AT <DSK-ADRES>
3693                                ;INDICATED IN EROR MSGE
3694                                ;DID RKDA INCREMENT CORRECTLY BY 12 SEC
3694 011220 020277 170114 5$: CMP     R2,@RKDA
3695 011224 001410  BEQ     6$
3696 011226 010237 001202  MOV     R2,$REG10 ;:GET EXPCTD RKDA
3697 011232 104415  BRKDA0 ;:GO TO 'BDA0' & BREAK CONTENTS OF
3698                                ;$REG10 INTO DR #,CYL,SUR,SEC BITS
3699 011234 017737 170100 001202  MOV     @RKDA,$REG10 ;:GET RECVD RKDA
3700 011242 104416  BRKDA4 ;:GO TO 'BDA4' & BREAK CONTENTS OF
3701                                ;$REG10 INTO DR #,CYL,SUR,SEC BITS
3702 011244 104040  ERROR   40 ;:RKDA DID NOT INCREMENT BY 12 SECTORS
3703                                ;AFTER RD FMT WAS DONE. ADRES
3704                                ;OF CYLINDER IN ERROR CAN BE OBTAINED
3705                                ;FROM 'EXPCTD' RDA
3706 011246 013700 001370 6$: MOV     EFLG1,R0 ;:SET UP COUNT FOR 12 HEADERS TO B CHKD
3707                                ;(ONLY 1 IF SIMULATOR)
3708 011252 010104  MOV     R1,R4 ;:GET DRIV-ADRES FROM WHERE RDFMT WAS DONE
3709 011254 042704 160037  BIC     #160037,R4 ;:GET THE CYLINDER ADRES ONLY. (HEADER)
3710 011260 020413 7$: CMP     R4,(R3) ;:IS THE RECVD HEADER SAME AS EXPCTD?
3711 011262 001412  BEQ     8$
3712 011264 010437 001164  MOV     R4,$REG1 ;:GET EXPCTD HEADER WORD
3713 011270 011337 001166  MOV     (R3),$REG2 ;:GET HEADER WORD RECVD
3714 011274 010037 001162  MOV     R0,$REG0
3715 011300 062737 000014 001162  ADD     #14,$REG0 ;:GET THE SECTOR (OCTAL NO) WHICH DID
3716                                ;NOT GIVE THE CORRECT HEADER
3717 011306 104043  ERROR   43 ;:DID NOT RECIEVE THE CORRECT HEADER

```

```

3718                                     ;WORD FROM 'SECTOR' AS INDICATED
3719                                     ;(NOTE SECTOR # IS OCTAL)
3720 011310 005723          BS:   TST   (R3)+   ;INCREMENT POINTER TO THE NXT WORD
3721                                     ;IN MEMORY WHERE THE RECV HDR IS STORED
3722 011312 005200          INC   R0       ;HAVE U CHECKED ALL 12 HEADERS?
3723 011314 001361          BNE   7$       ;IF NOT, LOOP BACK & CHK THE NXT.
3724                                     ;YES, ALL HEADERS FOR THIS CYLINDER
3725                                     ;CHECKED.
3726 011316 004737 021316   JSR   PC,CHKWC ;CHECK IF RKWC OVERFLOWED TO 0, IF
3727                                     ;NOT RETURN HERE.
3728 011322 104041          ERROR  41      ;RKWC DID NOT OVERFLOW AFTER DOING
3729                                     ;RDFMT OF 12 SECTORS ON THE CYLINDER
3730                                     ;NOTE THAT 'RKDA' IS THE INCREMENTED
3731                                     ;RKDA AFTER THE RDFMT
3732 011324 005737 001344   9$:   TST   SIMUL   ;TSTING ON SIMULATOR?
3733 011330 001031          BNE   TST25    ;;IF YES, EXIT
3734                                     ;NO
3735 011332 005737 001356   TST   INDX1   ;DOING SURFACE 1
3736 011336 001011          BNE   10$     ;YES, BRANCH
3737 011340 005237 001356   INC   INDX1   ;NO
3738 011344 062701 000020   ADD   #20,R1  ;INCREMENT DRIV ADRES TO THE NXT SURFACE
3739 011350 010102          MOV   R1,R2
3740 011352 062702 000020   ADD   #20,R2
3741                                     ;THIS IS WHAT RKDA SHOULD INCREMENT
3742 011356 000137 011100   JMP   1$     ;TO, AFTER READ FMT OF THE CYLINDER
3743 011362 005037 001356   CLR   INDX1   ;GO RD FMT THE NXT SURFACE
3744 011366 042701 000037   BIC   #37,R1  ;CLR SEC, SURFACE BITS
3745 011372 062701 000040   ADD   #40,R1  ;INCREMENT TO NXT CYL
3746 011376 010102          MOV   R1,R2   ;THIS IS WHAT RKDA SHOULD BE
3747 011400 062702 000020   ADD   #20,R2  ;AFTER RD FMT OF CYLINDER
3748 011404 005205          INC   R5       ;HAVE U DONE ALL CYLINDERS?
3749 011406 001402          BEQ   TST25    ;;EXIT
3750 011410 000137 011100   JMP   1$     ;IF NOT, LOOP BACK & READ FMT FROM
3751                                     ;THE NXT CYLINDER
3752
3753
3754
3755 ;*****
3756 ;*TEST 25 CHECK 'READ' OF THE ENTIRE DISK
3757 ;*READ OF THE ENTIRE DISK (ONE WORD PER SECTOR) IS DONE
3758 ;*IN THIS TEST. IN A PREVIOUS TEST THE FIRST WORD OF
3759 ;*EVERY SECTOR WAS WRITTEN LIKE A PSUEDO-HEADER (DRIVE #,
3760 ;*CYLINDER #, SURFACE & SECTOR #). THESE PSUEDO HEADERS
3761 ;*WILL BE READ & CHECKED IN THIS TEST, PROVING THAT ANY
3762 ;*SECTOR CAN BE ACCESSED AND READ.
3763 ;*THE FOLLOWING CHECKING IS DONE
3764 ;*1. CNTRL RDY SETS WITHIN A CERTAIN TIME ON COMPLETION
3765 ;*OF FUNCTION.
3766 ;*2. IF 'SIN' OCCURRED?
3767 ;*3. IF 'HE' OR 'ERR' OCCURRED?
3768 ;*4. THE CORRECT FIRST WORD FROM EVERY SECTOR
3769 ;*WAS RECEIVED. THIS WORD REFLECTS THE ABSOLUTE
3770 ;*DISK ADDRESS (DRV #, CYL #, SUR, SEC#) OF THAT SECTOR.
3771 ;*5. IF RKDB CONTAINED THE CORRECT WORD.
3772 ;*IF 'SIN' OCCURS DRIVE RESET IS DONE BEFORE READING
3773 ;*THE NEXT SECTOR. READ IS DONE IN THIS ORDER SEC 0-11
3774 ;*CYL 0 SUR 0 -> SEC 0-11 CYL 0 SUR 1 -> SEC 0-11 CYL 1,....

```

```

3774                                     ;*IF TESTING ON SIMULATOR ONLY LAST CYLINDER (312), LAST
3775                                     ;*SECTOR (13), SURFACE 1 IS READ.
3776 ;*****
3777 011414 000004          TST25: SCOPE
3778 011416 012737 000001 001206   MOV   #1,$TIMES   ;DO 1 ITERATION
3779 011424 012737 011470 001110   MOV   #1,$LPERR   ;SET RET,RN ADRES FOR
3780                                     ;LOOPING ON ERROR (SW9)
3781 011432 012703 033342   MOV   #OUTBUF,R3
3782 011436 005004          CLR   R4       ;FLAG, CLEAR WHEN READING SURFACE 0
3783                                     ;SET WHEN READING SURFACE 1
3784 011440 013701 001350   MOV   DRIVAD,R1 ;GET DRIVE ADDRESS
3785 011444 005737 001344   TST   SIMUL   ;TSTING ON SIMULATOR?
3786 011450 001403          BEQ   10$     ;IF NOT BRANCH
3787 011452 052701 014533   BIS   #14533,R1 ;SET ADRES BITS FOR LAST CYL (312)
3788 011456 000404          BR   1$      ;LAST SECTOR (13), SURFACE 1
3789 011460 012700 177764   10$: MOV   #-14,R0 ;SET COUNT FOR 12 SECTORS
3790 011464 012705 177465   MOV   #-313,R5 ;SET UP COUNT FOR 203 CYLINDERS
3791
3792 011470 104413          1$:   CNT.RESET   ;GO, DO CONTROL RESET
3793                                     ;THIS IS A CALL FOR THE 'CNTRL-
3794 ;RESET' ROUTINE. A CONTROL RESET IS
3795 ;ISSUED AND AFTER A CERTAIN TIME
3796 ;IF THE 'CNTRL RDY' DOES NOT SET
3797 ;AN ERROR IS REPORTED. NOTE THAT
3798 ;THE PC IN ERROR MESSAGE IS THE
3799 ;PC WHERE 'CNT.RESET' IS LOCATED.
3800 ;THIS IS A VERY BASIC ERR & IF IT
3801 ;OCCURS GO BACK TO TEST 10
3802 011472 104421          TST.SIN
3803                                     ;GO CHECK SIN, IF SET DD
3804                                     ;DRIVE RESET TO CLR IT
3804 011474 005037 001356   8$:   CLR   INDX1
3805 011500 010377 167632   MOV   R3,@RKBA ;ADRES TO WHICH DATA IS TO B X-FERNEED
3806                                     ;FROM THE DISK
3807 011504 012777 177777 167622   MOV   #-1,@RKWC ;SET UP WORD COUNT
3808 011512 010177 167622   MOV   R1,@RKDA ;ADRES THE DRIVE WITH CORRECT
3809                                     ;CYLINDER & SECTOR ADRES
3810 011516 012777 000005 167606   MOV   #5,@RKCS  ;READ, GO
3811
3812 011524 105777 167600   2$:   TSTB  @RKCS   ;DID CNTRL RDY SET?
3813 011530 100411          BMI   3$     ;YES, BRANCH
3814 011532 005237 001356   INC   INDX1   ;NO, HAVE U WAITED LONG ENOUGH
3815 011536 001372          BNE   2$     ;IF NOT, LOOP BACK & WAIT FOR IT
3816                                     ;IF YES, REPORT ERROR
3817 011540 004737 020774   JSR   PC,GT4RG ;GO, GET RKCS, ER, DS,DA
3818 011544 010137 001202   MOV   R1,$REG10 ;GET DISK-ADRES WHERE ERROR OCCURED
3819 011550 104416          BRKDA4
3820                                     ;GO TO 'BDA4' & BREAK CONTENTS OF
3821 ;$REG10 INTO DR #,CYL,SUR,SEC BITS
3822 011552 104045          ERROR  45    ;CNTRL RDY DID NOT SET AFTER DOING
3823                                     ;A 1 WORD READ FROM ADRES AS
3824 ;INDICATED IN <DISK-ADRES>
3825 ;'RKDA' IN EROR MSGE GIVES THE
3826 ;CONTENTS OF RKDA AT THE TIME OF ERROR
3827 011554 032777 001000 167544 3$:   BIT   #1000,@RKDS ;DID 'SIN' SET?
3828 011562 001405          BEQ   4$     ;NO, BRANCH
3829 011564 004737 021002   JSR   PC,GT3RG ;GO, GET RKCS, ER, DS

```

```

3830 011570 010137 001170      MOV    R1,$REG3      ;GET DISK-ADRES WHERE SIN OCCURED3
3831 011574 104001              ERROR 1              ;'SIN' ERROR ON DOING READ FROM
3832                          ;DISK-ADRES INDICATED IN $REG3
3833 011576 004737 021226      4$:   JSR    PC,CHKHE1 ;CHECK IF 'ERR' OR 'HE' BIT IS SET,
3834                          ;IF YES, RETURN HERE.
3835 011602 104046              ERROR 46             ;'HE' OR 'ERR' ON DOING A READ OF
3836                          ;1 WORD FROM ADRES AS INDICATED
3837                          ;IN <DISK-ADRES>
3838                          ;'RKDA' IN EROR MSGE GIVES THE
3839                          ;CONTENTS OF RKDA AT THE TIME OF EROR
3840 011604 020113              5$:   CMP    R1,(R3)    ;WAS THE CORRECT DATA WORD RECVD?
3841 011606 001407              BEQ    6$
3842 011610 010137 001162      MOV    R1,$REG0      ;GET EXPCTD DATA WORD
3843 011614 011337 001164      MOV    (R3),$REG1    ;GET DATA WORD RECVD
3844 011620 010137 001166      MOV    R1,$REG2      ;GET DISK-ADRES
3845 011624 104044              ERROR 44             ;DID NOT RECIEVE THE CORRECT
3846                          ;DATA WORD FROM DISK ON DOING
3847                          ;1 WORD READ FROM 'DISK-ADRES'
3848                          ;AS INDICATED BY 'EXPCTD' DATA WORD
3849                          ;NOTE THAT IN A PREVIOUS TEST THE
3850                          ;FIRST WORD OF EACH SECTOR IS UNIQUELY
3851                          ;WRITTEN WITH A WORD GIVING THE
3852                          ;ABSOLUTE ADDRESS OF THAT SECTOR IN
3853                          ;TERMS OF, DRIV #, CYL ADRES, SUR, SEC ADRS.
3854 011626 020177 167510      6$:   CMP    R1,@RKDB   ;DDES RKDB CONTAIN CORRECT WORD
3855 011632 001406              BEQ    7$            ;YES, BRANCH
3856 011634 010137 001162      MOV    R1,$REG0      ;NO, GET EXPCTD RKDB
3857 011640 017737 167476 001164  MOV    @RKDB,$REG1   ;GET RKDB RECVD
3858 011646 104037              ERROR 37             ;RKDB ERROR DN READ.
3859                          ;FOR RK11C, AFTER A READ RKDB
3860                          ;CONTAINS CHECKSUM FOR THE SECTOR
3861                          ;READ.
3862                          ;WHEREAS FOR RK11D, AFTER READ
3863                          ;RKDB CONTAINS THE LAST WORD
3864                          ;READ FROM THAT SECTOR &
3865                          ;X-FERRED TO MEMORY
3866 011650 005737 001344      7$:   TST    SIMUL      ;TESTING ON SIMULATOR?
3867 011654 001022              BNE   TST26         ;IF YES, EXIT
3868 011656 005201              INC   R1             ;INCREMENT TO ADRES NEXT SECTOR
3869 011660 005200              INC   R0             ;HAVE U CHKD ALL 12 SECTORS?
3870 011662 001302              BNE   1$            ;IF NOT, LUP BAK & CHK THE NXT
3871                          ;IF YES...
3872 011664 012700 177764      MOV    #-14,R0       ;RESET THE COUNT FOR 12 SECTORS
3873 011670 042701 000037      BIC   #37,R1         ;CLEAR SECTOR, SURFACE BITS
3874 011674 005704              TST   R4             ;DOING SURFACE 1?
3875 011676 001004              BNE   9$            ;YES, BR-NCH
3876 011700 005204              INC   R4             ;NO
3877 011702 062701 000020      ADD   #20,R1         ;INCREMENT THE ADRES TO NXT SURFACE
3878 011706 000670              BR    1$            ;GO READ SURFACE 1
3879 011710 005004              9$:   CLR   R4
3880 011712 062701 000040      ADD   #40,R1         ;INCREMENT TO NXT CYL
3881 011716 005205              INC   R5             ;HAVE U CHKD ALL 203 CYLINDERS
3882 011720 001263              BNE   1$            ;IF NOT, LOOP BACK & CHK THE NXT CYLINDER
3883                          ;YES
3884
3885

```

```

3886 ;*****
3887 ;*TEST 26 CHECK 'SEEK' FUNCTION, WITH DIFFERENT VELOCITY MODES
3888 ;* THIS TEST CHECKS SEEK IN DIFFERENT VELOCITY MODES (DIFF <3,
3889 ;* 3 < DIFF < 31, DIFF > 31). FOR THESE 3 BASIC VELOCITIES SEEK IS DONE BOTH
3890 ;* IN FWD AND REV DIRECTION TO CHECK THE ADDER & DIFFERENCE LOGIC. IF
3891 ;* WHILE DOING A SEEK 'SIN' OCCURS, A DRIVE RESET IS DONE TO INITIALIZE
3892 ;* THE POSITIONING LOGIC
3893 ;*****
3894 011722 000004      TST26: SCOPE
3895 011724 012737 000005 001206  MOV    #5,STIMES    ;DO 5 ITERATIONS
3896 011732 012703 001372      MOV    #SEEK0,R3    ;INITIALIZE POINTER TO THE FIRST
3897                          ;SEEK ADDRESS
3898 011736 005037 001356      CLR   INDX1         ;INDX1, WHEN 0 INDICATES SEEK IN FWD DIRECTION
3899                          ;WHEN 1 INDICATES SEEK IN REV DIRECTION
3900 011742 013700 001332      MOV    RKCS,R0
3901 011746 013701 001326      MOV    RKDS,R1
3902 011752 013702 001330      MOV    RKER,R2
3903 011756 012737 011764 001110  MOV    #1$,$LPPERR  ;SET RETURN ADRES FOR LUPING ON
3904                          ;EROR (SW 9)
3905 011764 000240      1$:   NOP
3906 011766 104413      2$:   CNT.RESET
3907                          ;GO, DO CONTROL RESET
3908                          ;THIS IS A CALL FOR THE 'CNTRL-
3909                          ;RESET' ROUTINE. A CONTROL RESET IS
3910                          ;ISSUED AND AFTER A CERTAIN TIME
3911                          ;IF THE 'CNTRL RDY' DOES NOT SET
3912                          ;AN EROR IS REPORTED. NOTE THAT
3913                          ;THE PC IN ERROR MESSAGE IS THE
3914                          ;PC WHERE 'CNT.RESET' IS LOCATED.
3915                          ;THIS IS A VERY BASIC ERR & IF IT
3916 011770 104421      TST.SIN            ;OCCURS GO BACK TO TEST 10
3917                          ;GO, CHECK IF SIN IS SET, IF SET
3918                          ;DO DRV-RESET TO CLEAR IT
3919
3920 011772 013704 001350      MOV    DRIVAD,R4    ;GET DRIV-ADRES
3921 011776 051304      BIS   (R3),R4       ;SET CYLINDER BITS
3922 012000 010477 167334      MOV    R4,@RKDA     ;ADRS THE DRIVE
3923 012004 012710 000011      MOV    #11,@R0     ;SET 'SEEK', 'GO'
3924
3925 012010 104412      CHKCRDY            ;GO CHECK IF CONTROL RDY IS SET
3926                          ;IF SO, SKIP THE EROR MESSAGE.
3927 012012 104021      ERROR 21          ;'CNTRL RDY' DID NOT SET AFTER
3928                          ;SENDING CYL ADD TO THE DRIV, 'ADD ACK'
3929                          ;FROM DRIVE SHLD HAVE COME BACK
3930                          ;THEREUPON SETTING 'CNTRL RDY'
3931 012014 005005      4$:   CLR   R5
3932 012016 032711 000100      5$:   BIT   #100,@R1  ;DID R/W/S RDY SET?
3933 012022 001005      BNE   6$            ;YES, BRANCH
3934 012024 005205      INC   R5            ;NO, WAIT
3935 012026 001373      BNE   5$            ;WAITED LONG?
3936 012030 004737 020774      JSR   PC,GT4RG     ;GO, GET RKCS, ER, DS, DA
3937 012034 104026      ERROR 26          ;R/W/S RDY DID NOT SET ON
3938                          ;COMPLETION OF SEEK
3939 012036 032711 001000      6$:   BIT   #1000,@R1 ;DID SIN SET?
3940 012042 001403      BEQ   7$            ;NO, BRANCH
3941 012044 004737 020774      JSR   PC,GT4RG     ;GO, GET RKCS, ER, DS, DA

```

```

3942 012050 104001          ERROR 1          ;SIN SET ON DOING SEEK
3943 012052 032710 140000 75: BIT #140000,@R0 ;DID 'HE' OR 'ERR' SET?
3944 012056 001403          BEQ 85           ;YES
3945 012060 004737 020774 JSR PC,GT4RG     ;GO, GET RKCS, ER, DS, DA
3946 012064 104022          ERROR 22         ;ERR OF 'HE' BIT SET WHEN
3947                                     ;SEEKING TO CYL AS INDICATED
3948                                     ;IN RKDA
3949
3950 012066 022710 000210 85: CMP #210,@R0    ;DOES RKCS STILL CONTAIN THE 'SEEK' FNCTION
3951 012072 001406          BEQ 95           ;YES - EXIT
3952 012074 011037 001164 MOV @R0,$REG1    ;NO, GET RKCS RECVD
3953 012100 012737 000210 001162 MOV #210,$REG0   ;GET EXPCTD RKCS
3954 012106 104024          ERROR 24         ;RKCS SHOULD CONTAIN THE 'SEEK' BITS
3955                                     ;IF NOT, ERROR
3956
3957 012110 020477 167224 95: CMP R4,@RKDA    ;DID RKDA CHANGE?
3958 012114 001406          BEQ 105          ;NO
3959 012116 010437 001162 MOV R4,$REG0     ;YES, GET EXPCTD?
3960 012122 017737 167212 001164 MOV @RKDA,$REG1 ;GET RKDA
3961 012130 104027          ERROR 27         ;RKDA CHANGED AFTER DOING SEEK
3962
3963 012132 010477 167202 105: MOV R4,@RKDA    ;ADRES THE DRIVE, SEC 0
3964 012136 012777 033342 167172 MOV #OUTBUF,@RKBA ;READ ONE HEADER INTO THIS
3965 012144 012777 177777 167162 MOV #-1,@RKWC    ;BUS ADRES
3966 012152 012710 002005 MOV #2005,@R0    ;GO, READ FORMAT
3967 012156 104414          CNT.RDY         ;WAIT FOR CNTRL RDY
3968 012160 021337 033342 CMP (R3),OUTBUF  ;WAS THE CORRECT READE4R READ (FROM
3969 012164 001410          BEQ 115          ;CYLINDER TO WHICH SEEK WAS DONE BEFORE)
3970 012166 005037 001162 CLR $REG0         ;STORE SEC # FROME WHERE HDP WAS RD (0)
3971 012172 011337 001164 MOV (R3),$REG1   ;GET EXPCTD HEADER
3972 012176 013737 033342 001166 MOV OUTBUF,$REG2 ;GET HDR RECVD
3973 012204 104043          ERROR 43         ;WRONG HDR WAS RECVD FROM CYLINDER (ADRES
3974                                     ;IN ER MSGE). NOTE THAT A PURE SEEK WAS
3975                                     ;DONE TO THIS CYL BEFORE R.LADING HDR
3976                                     ;USING READ FORMAT
3977 012206 005737 001356 115: TST INDX1       ;SEEK IN REVRSE DIRECTION?
3978 012212 001007          BNE 125         ;YES, BRANCH
3979 012214 005723          TST (R3)+       ;NO, INCREMENT PTR TO NXT SEEK ADRES
3980 012216 022703 001400 CMP #SEEK2+2,R3 ;DONE WITH ALL SKS IN FWD DIR?
3981 012222 001260          BNE 15            ;NO, GO & DO NXT ONE
3982 012224 005237 001356 INC INDX1         ;SET FLAG INDICATING SK IN REVRSE
3983 012230 005743          TST -(R3)       ;
3984 012232 005743 125: TST -(R3)         ;POSITION PTR TO NXT SK IN REV
3985 012234 022703 001370 CMP #SEEK0-2,R3 ;DONE WITH ALL?
3986 012240 001251          BNE 15          ;IF NOT, DO NXT ONE
3987
3988
3989
3990
3991 ;*****
3992 ;*TEST 27 CHECK DRIVE RESET FROM LAST CYLINDER
3993 ;*THE HEADS ARE POSITIONED ON THE LAST CYLINDER (DOING
3994 ;*AN IMPLIED SEEK-READ). THEN A DRIVE RESET IS ISSUED.
3995 ;*IT'S CHECKED IF THE HEADS WERE BROUGHT BACK TO 0 BY
3996 ;*DOING A 1 WORD READ & CHECKING THAT THE CORRECT WORD
3997 ;*WAS RECEIVED. IF TESTING ON SIMULATOR THIS TEST IS SKIPPED.
3998 ;*****

```

```

3998 012242 000004          TST27: SCOPE
3999 012244 012737 000005 001206 MOV #5,$TIMES    ;; DO 5 ITERATIONS
4000 012252 005737 001344 TST SIMUL        ;R U ON A SIMULATOR?
4001 012256 001124          BNE TST30       ;YES, EXIT
4002 012260 013701 001332 MOV RKCS,R1
4003 012264 104413          CNT.RESET      ;GO, DO CONTROL RESET
4004                                     ;THIS IS A CALL FOR THE 'CNTRL-
4005                                     ;RESET' ROUTINE. A CONTROL RESET IS
4006                                     ;ISSUED AND AFTER A CERTAIN TIME
4007                                     ;IF THE 'CNTRL RDY' DOES NOT SET
4008                                     ;AN ERROR IS REPORTED. NOTE THAT
4009                                     ;THE PC IN ERROR MESSAGE IS THE
4010                                     ;PC WHERE 'CNT.RESET' IS LOCATED.
4011                                     ;THIS IS A VERY BASIC ERR & IF IT
4012                                     ;OCCURS GO BACK TO TEST 10
4013 012266 005000          CLR R0
4014 012270 012703 033342 MOV #OUTBUF,R3   ;ADRES WHERE DATA WILL BE READ INTO
4015 012274 013704 001350 MOV DRIVAD,R4
4016 012300 010405          MOV R4,R5
4017 012302 052705 014500 BIS #14500,R5    ;SET CYL ADRES=312 (OCTAL)
4018 012306 010577 167026 MOV R5,@RKDA    ;ADRES THE DRIVE, LAST CYLINDER
4019 012312 012777 177777 167014 MOV #-1,@RK..C  ;READ 1 WORD
4020 012320 010377 167012 MOV R3,@RKBA    ;INTO THIS MEMORY ADRES
4021
4022 012324 012711 000005 MOV #5,@R1      ;READ, GO
4023
4024 012330 005000          CLR R0
4025 012332 104414 15: CNT.RDY    ;THIS IS A CALL FOR CN.RDY ROUTINE
4026                                     ;WHICH WAITS FOR CNTRL RDY TO SET.
4027                                     ;A RETURN IS MADE AFTER CNTRL RDY
4028                                     ;SETS. IF WITHIN A CERTAIN TIME
4029                                     ;CNTRL RDY DOESN'T SET AN ERROR
4030                                     ;MESSAGE IS GIVEN. WAITING TIME
4031                                     ;883 MS FOR 11/20, 175 MS FOR 11/45
4032 012334 020513 25: CMP R5,@R3    ;WAS THE CORRECT WORD READ?
4033 012336 001407          BEQ 35          ;YES, SEEK TO 312 WAS DONE CORRECTLY5,0
4034 012340 010537 001162 MOV R5,$REG0    ;GET EXPCTD WORD
4035 012344 011337 001164 MOV @R3,$REG1   ;GET WORD RECVD
4036 012350 010537 001166 MOV R5,$REG2    ;GET DSK-ADRES FROM WHERE WORD WAS READ
4037 012354 104044          ERROR 44         ;DID NOT READ BACK CORRECT WORD FROM
4038                                     ;LAST CYL, SEC 0. IF TEST 45 & 46
4039                                     ;WERE SUCCESSFULLY DONE THIS
4040                                     ;ERROR MEANS THAT IMPLIED SEEK
4041                                     ;TO CYL 312 COULD NOT B DONE
4042 012356 012711 000015 35: MOV #15,@R1     ;DRIVE RESET, GO
4043 012362 104414          CNT.RDY    ;THIS IS A CALL FOR CN.RDY ROUTINE
4044                                     ;WHICH WAITS FOR CNTRL RDY TO SET.
4045                                     ;A RETURN IS MADE AFTER CNTRL RDY
4046                                     ;SETS. IF WITHIN A CERTAIN TIME
4047                                     ;CNTRL RDY DOESN'T SET AN ERROR
4048                                     ;MESSAGE IS GIVEN. WAITING TIME
4049                                     ;883 MS FOR 11/20, 175 MS FOR 11/45
4050 012364 005000          CLR R0
4051 012366 032777 000100 166732 45: BIT #100,@RKDS  ;DID R/W/S RDY SET?
4052 012374 001011          BNE 55          ;YES, BRANCH
4053 012376 012702 177763 MOV #-15,R2     ;IF U R ON A SLOWER MACHINE

```

```

4054 012402 005202      INC      R2      ;& DO NOT NEED SUCH A LARGE MACHINE
4055 012404 001376      BNE      .-2     ; TIME LOOP, CHANGE THESE 3
4056                      ; INSTRUCTIONS TO 'NOP' THE
4057                      ; LOOP TIME WILL BE REDUCED
4058                      ; TO 1100 MS
4059                      ;
4060                      ; THE TOTAL TIME FOR THE ABOVE
4061                      ; LOOPS (W/O PUTTING 'NOP'S) IS
4062                      ; 5304 MS FOR 11/20 AND
4063                      ; 1061 MS FOR 11/45 WITH MDS
4064                      ; OR BIPOLAR MEMORY
4065 012406 005200      INC      R0      ; WAITED LONG?
4066 012410 001366      BNE      4$      ; IF NOT, LUP BAK & WAIT
4067                      ; IF YES, ERROR
4068 012412 004737 020774 JSR      PC,GT4RG ; GET RKCS,ER,DS,DA
4069 012416 104026      ERROR    26      ; R/W/S RDY DID NOT SET AFTER
4070                      ; DOING DRIVE RESET
4071 012420 032711 140000 5$: BIT      #140000,@R1 ; DID HE OR ERR BIT SET?
4072 012424 001403      BEQ      6$      ; IF NOT, BRANCH
4073                      ;
4074 012426 004737 020774 JSR      PC,GT4RG ; GET RKCS,ER,DS,DA FOR ERROR MESSAGE
4075 012432 104022      ERROR    22      ; HE OR ERR BIT SET ON DOING DRIVE
4076                      ; RESET FROM LAST CYLINDER
4077 012434 005205      6$: INC      R5      ; POSITION R5 TO EXPCTD RKDA
4078 012436 020577 166676 CMP      R5,@RKDA ; DID THE CYL ADRES BITS IN RKDA GET CHANGED?
4079 012442 001406      BEQ      7$      ; NO, BRANCH
4080 012444 010537 001162 MOV      R5,$REG0 ; GET EXPCTD RKDA
4081 012450 017737 166664 MOV      @RKDA,$REG1 ; GET RKDA RECVD
4082 012456 104054      ERROR    54      ; CYLINDER ADRES BITS IN RKDA
4083                      ; GOT CHANGED AFTER
4084                      ; DRIVE RESET, FROM LAST CYLINDER
4085 012460 012777 177777 7$: MOV      #-1,@RKWC ; READ 1 WORD
4086 012466 010377 166644 MOV      R3,@RKBA ; INTO THIS ADRES
4087 012472 010477 166642 MOV      R4,@RKDA ; FROM THIS DSK ADRES-CYL 0, SEC 0
4088                      ;
4089 012476 012711 000005 MOV      #5,@R1 ; READ, GO
4090                      ;
4091 012502 005000      CLR      R0      ; THIS IS A CALL FOR CN.RDY ROUTINE
4092 012504 104414      8$: CNT.RDY ; WHICH WAITS FOR CNTRL RDY TO SET.
4093                      ; A RETURN IS MADE AFTER CNTRL RDY
4094                      ; SETS. IF WITHIN A CERTAIN TIME
4095                      ; CNTRL RDY DOESN'T SET AN ERROR
4096                      ; MESSAGE IS GIVEN. WAITING TIME
4097                      ; 883 MS FOR 11/20, 175 MS FOR 11/45
4098                      ; WAS THE CORRECT WORD READ?
4099 012506 020413      9$: CMP      R4,@R3 ; YES, EXIT
4100 012510 001407      BEQ      TST30 ; GET EXPCTD WORD
4101 012512 010437 001162 MOV      R4,$REG0 ; GET WORD RECVD
4102 012516 011337 001164 MOV      @R3,$REG1 ; GET DISK ADRES WHERE ERROR OCCURED
4103 012522 010437 001166 MOV      R4,$REG2 ; DID NOT READ CORRECT WORD FROM
4104 012526 104044      ERROR    44      ; CYL 0, SEC 0. IF TEST 45 & 46
4105                      ; WERE SUCCESSFULLY DONE THIS
4106                      ; ERROR COULD MEAN THAT DRIVE-RESET
4107                      ; DID NOT BRING HEADS BACK TO 0.
4108
4109

```

```

4110
4111 ;*****
4112 ;*TEST 30 'WRITE' - 256 WORD BLOCK ON SECTOR 0, CYLINDER 0
4113 ;THE TEST BELOW SHOULD BE CONSIDERED AS A SET UP PHASE FOR
4114 ;THE FOLLOWING TEST. IT WRITES A BLOCK OF 256 WORDS IN
4115 ;SECTOR 0, CYLINDER 0 WITH A SPECIFIC PATTERN AND THIS WRITTEN
4116 ;BLOCK WILL BE MADE USE OF IN THE NEXT TEST TO CHECK
4117 ;OUT 'WRITE-CHECK' AND 'READ CHECK' FUNCTIONS.
4118 ;*****
4119 012530 000004      TST30: SCOPE
4120 012532 104413      CNT.RESET ; GO, DO CONTROL RESET
4121                      ; THIS IS A CALL FOR THE 'CNTRL-
4122                      ; RESET' ROUTINE. A CONTROL RESET IS
4123                      ; ISSUED AND AFTER A CERTAIN TIME
4124                      ; IF THE 'CNTRL RDY' DOES NOT SET
4125                      ; AN ERROR IS REPORTED. NOTE THAT
4126                      ; THE PC IN ERROR MESSAGE IS THE
4127                      ; PC WHERE 'CNT.RESET' IS LOCATED.
4128                      ; THIS IS A VERY BASIC ERR& IF IT
4129                      ; OCCURS GO BACK TO TEST 10
4130 012534 104421      TST.SIN ; CHECK IF SIN IS SET, IF SET
4131                      ; DD DRIVE RESET TO CLEAR IT
4132 012536 013704 001332 MOV      RKCS,R4 ; THE FOLLOWING CODE IS FOR SETTING
4133                      ; UP THE I/O BUFFER IN MEMORY (STARTING AT
4134                      ; OUTBUF), WITH A PARTICULAR 256 WORD PATTERN.
4135                      ; STARTING FROM THE FIRST WORD IN THE BUFFER
4136                      ; THE LO BYTE WILL BE A COUNT PATTERN
4137                      ; FROM 0 TO 255 (DECIMAL), WHEREAS THE
4138                      ; HI-BYTE WILL BE THE COMPLEMENT OF LO BYTE.
4139                      ; A DECREASING COUNT PATTERN FROM 255 TO 0.
4140                      ; I.E.THE BUFFER WILL LOOK LIKE:
4141                      ; OUTBUF      (1 111 111 1 00 000 000)
4142                      ; OUTBUF+2    (1 111 111 0 00 000 001)
4143                      ;
4144                      ; LAST WORD      (0 000 000 0 11 111 111)
4145
4146
4147 012542 012700 033342 MOV      #OUTBUF,R0 ; SET UP FIRST WORD IN I/O BUFFER
4148 012546 012701 177401 MOV      #177401,R1 ; INCREMENT COUNT
4149 012552 012702 177400 MOV      #-400,R2 ; SET UP COUNT FOR 256 WORDS
4150 012556 012703 177400 MOV      #177400,R3 ; SET UP THE FIRST PATTERN TO B WRITTEN
4151
4152 012562 010320      MOV      R3,(R0)+ ; SET UP NEXT WORD PATTERN
4153 012564 005202      INC      R2      ; WRITE IT IN NXT I/O BUFFER WORD
4154 012566 060103      ADD      R1,R3 ; HAVE U WRITTEN ALL 256 WORDS
4155 012570 010320      MOV      R3,(R0)+ ; IF NOT GO & WRITE NEXT PATTERN
4156 012572 005202      INC      R2
4157 012574 001374      BNE      1$
4158
4159 012576 012777 177400 1$: MOV      #-400,@RKWC ; WRITE 256 WORDS
4160 012604 012777 033342 MOV      #OUTBUF,@RKBA ; STARTING FROM THIS BUS ADRES
4161 012612 013777 001350 MOV      DRIVAD,@RKDA ; TO THIS DISK ADRES, CYL 0, SEC 0
4162
4163 012620 012714 000003 MOV      #3,@R4 ; WRITE, GO
4164
4165 012624 105714      2$: TSTB   @R4 ; WAS CNTRL RDY CLEARED AS GO WAS SET?

```

```

4166 012626 100003 BPL 3S-2 ;YES, BRANCH
4167 012630 004737 JSR PC,GT3RG ;GET RKCS, ER, DS
4168 012634 104030 ERROR 30 ;CNTRL RDY DID NOT CLEAR AS GO WAS SET
4169 ;TO 'WRITE'
4170
4171 012636 005002 CLR R2
4172 012640 105777 166466 3S: TSTB @RKCS ;DID CNTRL RDY SET?
4173 012644 100411 BMI 4S ;YES, BRANCH
4174 012646 005202 INC R2 ;WAITED LONG ENOUGH?
4175 012650 001373 BNE 3S ;IF NOT, LUP BAK & WAIT
4176 ;IF YES, ERROR
4177 012652 004737 020774 JSR PC,GT4RG ;GO, GET RKCD, ER, DS, DA
4178 012656 013737 001350 001202 MOV DRIVAD,$REG10 ;GET THE STARTING ADRES
4179 012664 104416 BRKDA4 ;BREAK CONTENTS OF $REG10 INTO
4180 ;DRV #, CYL, SUR, SEC #
4181 012666 104031 ERROR 31 ;CNTRL RDY DID NOT SET ON COMPLETION
4182 ;OF WRITE OF 256 WORDS ON CYL 0, SEC 0
4183 ;'RKDA' IN EROR MSGE GIVES THE
4184 ;CONTENTS OF RKDA AT THE TIME OF ERROR
4185 ;WRITE WAS DONE STARTING AT <DSK-ADRES>
4186 ;INDICATED IN EROR MSGE
4187 012670 004737 021234 4S: JSR PC,CHKHL ;CHECK IF 'ERR' OR 'HE' BIT IS SET.
4188 ;IF YES, RETURN HERE
4189 012674 104032 ERROR 32 ;HE OR ERR BIT SET ON DOING WRITE OF
4190 ;256 WORDS ON CYL 0, SEC 0
4191 ;WRITE WAS DONE STARTING AT <DSK-ADRES>
4192 ;INDICATED IN EROR MSGE
4193 ;'RKDA' IN EROR MSGE GIVES THE
4194 ;CONTENTS OF RKDA AT THE TIME OF ERROR
4195 012676 020077 166434 5S: CMP R0,@RKBA ;DID RKBA INCREMENT CORRECTLY?
4196 012702 001406 BEQ 6S ;YES, BRANCH
4197 012704 010037 001162 MOV R0,$REG0 ;GET EXPCTD RKBA
4198 012710 017737 166422 001164 MOV @RKBA,$REG1 ;GET RKBA RECVD
4199 012716 104035 ERROR 35 ;RKBA DID NOT INCREMENT CORRECTLY
4200 ;(BY 1000 OCTAL BYTES) AFTER WRITE
4201 ;OF 400 (OCTAL) WORDS ON SEC 0, CYL 0
4202 012720 004737 021316 6S: JSR PC,CHKWC ;CHECK IF RKWC OVERFLOWED TO 0.
4203 ;IF NOT RETURN HERE.
4204 012724 104034 ERROR 34 ;RKWC DID NOT OVERFLOW, AFTER A
4205 ;WRITE OF 256 WORDS ON CYL 0, SEC 0
4206 012726 004737 021262 7S: JSR PC,CHKDA ;CHECK IF RKDA INCREMENTED CORRECTLY.
4207 ;IF NOT RETURN HERE
4208 012732 104033 ERROR 33 ;RKDA DID NOT INCREMENT BY 1 AFTER
4209 ;A WRITE OF 256 WORDS IN CYL 0, SEC 0
4210 012734 004737 021342 8S: JSR PC,CHKER ;CHECK IF ANY BIT RKER IS SET
4211 ;IF YES :ETURN HERE.
4212 012740 104036 ERROR 36 ;RKER BIT SET ON DOING WRITE ON
4213 ;CYLINDER 0, SECTOR 0
4214 012742 022714 000202 9S: CMP #202,@R4 ;DOES RKCS STILL CONTAIN THE WRITE BITS?
4215 012746 001406 BEQ TST31 ;YES, EXIT
4216 012750 012737 000202 001162 MOV #202,$REG0 ;GET EXPECTED RKCS
4217 012756 011437 001164 MOV @R4,$REG1 ;GET RKCS RECVD
4218 012762 104024 ERROR 24 ;RKCS DID NOT CONTAIN THE 'WRITE'
4219 ;BITS AFTER THE FUNCTION WAS DONE.
4220
4221

```

```

4222 ;*****
4223 ;*TEST 31 CHECK THAT WRITE WAS DONE CORRECTLY
4224 ;*THIS TEST CHECKS IF THE 'WRITE' OF 256 WORDS DONE IN PREVIOUS
4225 ;*TEST IS GOOD. THE SEQUENCE OF OPERATIONS IS AS FOLLOWING:
4226 ;*1) DO A READ OF 256 WORDS FROM SECTOR 0, CYLINDER 0
4227 ;* INTO A BUFFER STARTING AT 'OUTBUF'.
4228 ;*2) COMPARE & CHECK THE DATA THAT IS READ (STARTING AT 'OUTBUF')
4229 ;* WITH THE DATA THAT WAS GENERATED PREVIOUSLY
4230 ;*3) REPORT AN ERROR IF THE DATA READ BACK FROM DISK DOES
4231 ;* NOT COMPARE WITH DATA THAT WAS SUPPOSE TO HAVE BEEN WRITTEN
4232 ;*****
4233 012764 000004 TST31: SCOPE
4234 012766 104413 CNT.RESET ;GO, DO CONTROL RESET
4235 ;THIS IS A CALL FOR THE 'CNTRL-
4236 ;RESET' ROUTINE. A CONTROL RESET IS
4237 ;ISSUED AND AFTER A CERTAIN TIME
4238 ;IF THE 'CNTRL RDY' DOES NOT SET
4239 ;AN ERROR IS REPORTED. NOTE THAT
4240 ;THE PC IN ERROR MESSAGE IS THE
4241 ;PC WHERE 'CNT.RESET' IS LOCATED.
4242 ;THIS IS A VERY BASIC ERR& IF IT
4243 ;OCCURS GO BACK TO TEST 10
4244 012770 104421 TST.SIN ;CHECK IF SIN IS SET, IF SET
4245 ;DO DRIVE RESET TO CLEAR IT
4246 012772 012700 177400 MOV #-400,R0 ;SET COUNT FOR 400 WORDS
4247 012776 012701 033342 MOV #OUTBUF,R1 ;TO BE C'EAURED IN THE BUFFER
4248 013002 005021 BS: CLR (R1)+ ;CLR THE 400 WORD BUFFER
4249 013004 005200 INC R0 ;STARTING AT 'OUTBUF'
4250 013006 001375 BNE BS
4251 013010 005000 CLR R0
4252 013012 012777 177400 166314 MOV #-400,@RKWC ;READ 256 WORDS
4253 013020 012777 033342 166310 MOV #OUTBUF,@RKBA ;INTO THIS ADRES
4254 013026 013777 001350 166304 MOV DRIVAD,@RKDA ;STARTING FROM THIS DISK ADRES
4255
4256 013034 012777 000005 166270 MOV #5,@RKCS ;READ, GO
4257
4258 013042 105777 166264 1S: TSTB @RKCS ;DID CNTRL RDY SET?
4259 013046 100411 BMI 2S ;YES, BRANCH
4260 013050 005200 INC R0 ;WAITED LONG ENOUGH?
4261 013052 001373 BNE 1S ;IF NOT, LUP BAK & WAIT
4262 ;ERROR, IF YES
4263 013054 004737 020774 JSR PC,GT4RG ;GO, GET RKCD, ER, DS, DA
4264 013060 013737 001350 001202 MOV DRIVAD,$REG10 ;GET THE STARTING ADRES
4265 013066 104416 BRKDA4 ;GO TO 'BDA4' & BREAK CONTENTS OF
4266 ;$REG10 INTO DRV #, CYL, SUR, SEC BITS
4267 013070 104045 ERROR 45 ;CNTRL RDY DID NOT SET AFTER READ
4268 ;OF 400 WORDS FROM CYL 0, SEC 0
4269 ;'RKDA' IN EROR MSGE GIVES THE
4270 ;CONTENTS OF RKDA AT THE TIME OF ERROR
4271 ;READ WAS DONE STARTING AT <DSK-ADRES>
4272 ;INDICATED IN EROR MSGE
4273 013072 032777 001000 166220 2S: BIT #1000,@RKDS ;IS SIN SET?
4274 013100 001033 BNE TST32 ;IF YES, EXIT
4275 013102 012701 177400 5S: MOV #-400,R1
4276 013106 012702 177777 MOV #177777,R2
4277 013112 012703 033342 MOV #OUTBUF,R3

```

```

4278 013116 012705 177773      MOV    #-5,R5
4279 013122 062702 177401      ADD    #177401,R2
4280 013126 020213              CMP    R2,(R3) ;WAS THE READ WORD SAME AS THE WORD
4281                          ;THAT WAS SUPPOSE TO BE WRITTEN
4282 013130 001414              BEQ    7$      ;YES, BRANCH
4283                          ;NO, BRANCH
4284 013132 010137 001162      MOV    R1,$REG0 ;GET THE # OF WORD
4285 013136 062737 000401      ADD    #401,$REG0 ;THAT IS IN ERROR (EXAMPLE=1,2--376,377,400)
4286 013144 010237 001164      MOV    R2,$REG1 ;GET EXPCTD WORD (THAT WAS SUPPOSED TO
4287                          ;BE WRITTEN)
4288 013150 011337 001166      MOV    (R3),$REG2 ;GET WORD RECVD (THAT WAS READ BAK)
4289 013154 104055              ERROR  55      ;DID NOT READ BACK WORD THAT WAS SUPPOSED
4290                          ;TO HAVE BEEN WRITTEN PREVIOUSLY. POSITION
4291                          ;OF WORD IN ERROR IS AS INDICATED BY
4292                          ;WORD # ($REG0), SEC 0. CYL 0
4293 013156 005205              INC    R5
4294 013160 001403              BEQ    TST32
4295 013162 005723              TST    (R3)+   ;EXIT
4296                          ;INCREMENT POINTER TO NXT WORD (THAT
4297                          ;WAS READ BACK)
4298 013164 005201              INC    R1      ;HAVE U CHKD ALL 256 WORDS?
4299 013166 001355              BNE   6$      ;IF NOT, LUP BAK & CHK THE NXT WORD
4300                          ;IF YES, EXIT
4301
;*****
;TEST 32 CHECK 'READ CHECK' FUNCTION - CYLINDER 0, SECTOR 0
;THIS TEST CHECKS OUT THE BASIC 'READ CHECK' LOGIC, USING THE DATA BLOCK
;'CYLINDER, SECTOR 0' WRITTEN IN A PREVIOUS TEST. HENCE THE TEST WHICH
;WRITES THE DATA BLOCK SHOULD BE DONE PRIOR TO THIS TEST.
;*****
TST32: SCOPE
CNT.RESET ;GO, DO CONTROL RESET
;THIS IS A CALL FOR THE 'CNTRL-
;RESET' ROUTINE. A CONTROL RESET IS
;ISSUED AND AFTER A CERTAIN TIME
;IF THE 'CNTRL RDY' DOES NOT SET
;AN ERROR IS REPORTED. NOTE THAT
;THE PC IN ERROR MESSAGE IS THE
;PC WHERE 'CNT.RESET' IS LOCATED.
;THIS IS A VERY BASIC ERR& IF IT
;OCCURS GO BACK TO TEST 10
;CHECK IF SIN IS SET, IF SET
;DO DRIVE RESET TO CLEAR IT
4319
4320 013176 013701 001332      MOV    RKCS,R1
4321 013202 013702 001334      MOV    RKWC,R2
4322 013206 013703 001340      MOV    RKDA,R3
4323 013212 013704 001336      MOV    RKBA,R4
4324 013216 012737 052525      MOV    #52525,OUTBUF
4325 013224 012712 177400      MOV    #-400,@R2 ;READ CHECK 256 WORDS
4326 013230 013713 001350      MOV    DRIVAD,@R3 ;STARTING FROM CYL 0, SECTOR 0
4327 013234 012714 033342      MOV    #OUTBUF,@R4
4328 013240 012711 000013      MOV    #13,@R1 ;READ CHECK, GO
4329
4330 013244 105711              TSTB   @R1    ;DID CNTRL RDY GET CLEARED AS GO WAS SET?
4331 013246 100003              BPL    2$    ;YES, BRANCH
4332 013250 004737 021002      JSR    PC,GT3RG ;GET RKCS, ER, DS
4333 013254 104030              ERROR  30    ;CNTRL RDY DID NOT CLEAR AS GO

```

```

4334 013256 104412              2$:  CHKCRDY ;GO CHECK IF CONTROL RDY IS SET
4335                          ;IF SO, SKIP THE EROR MESSAGE.
4336                          ;WAS SET TO 'READ CHECK'
4337 013260 104056              ERROR  56    ;CNTRL RDY DID NOT SET ON DOING
4338                          ;'READ CHECK' FROM CYL 0, SEC 0
4339 013262 032711 140000      3$:  BIT    #140000,@R1 ;DID 'ERR' OR 'HE' BIT SET?
4340 013266 001403              BEQ    4$    ;NO, BRANCH
4341 013270 004737 021002      JSR    PC,GT3RG ;GO, GET RKCS, ER, DS FOR ERROR MESSAGE
4342 013274 104057              ERROR  57    ;'ERR' OR 'HE' BIT SET ON DOING
4343                          ;'READ CHECK' ON CYLINDER 0, SEC 0
4344 013276 032777 000002 166024 4$:  BIT    #2,@RKER ;DID 'CSE' BIT SET IN RKER?
4345 013304 001404              BEQ    5$    ;NO, BRANCH
4346 013306 017737 166016 001162  MOV    @RKER,$REG0 ;GET RKER
4347 013314 104060              ERROR  60    ;SOFT ERROR - CSE - ON DOING 'READ
4348                          ;CHECK' ON CYLINDER 0, SECTOR 0
4349                          ;U SHOULD HAVE GOT ERROR 102 ALSO
4350 013316 005712              5$:  TST    @R2    ;DID WORD COUNT OVERFLOW TO 0?
4351 013320 001405              BEQ    6$    ;YES, BRANCH
4352 013322 011237 001162      MOV    @R2,$REG0 ;GET RKWC
4353 013326 011137 001164      MOV    @R1,$REG1 ;GET RKCS
4354 013332 104061              ERROR  61    ;WORD COUNT DID NOT OVERFLOW
4355                          ;ON DOING 'READ CHK' ON CYL 0, SEC 0
4356 013334 013702 001350      6$:  MOV    DRIVAD,R2 ;RKDA SHOULD INCREMENT
4357 013340 005202              INC    R2      ;TO THIS AFTER 'RD CHK' IS DONE
4358 013342 020213              CMP    R2,@R3 ;DID RKDA INCREMENT CORRECTLY?
4359 013344 001405              BEQ    7$    ;GET EXPCTD RKDA
4360 013346 010237 001162      MOV    R2,$REG0 ;GET RKDA RECVD
4361 013352 011337 001164      MOV    @R3,$REG1 ;RKDA DID NOT INCREMENT CORRECTLY
4362 013356 104062              ERROR  62    ;(BY 1) ON DOING 'READ CHK' ON
4363                          ;CYL 0, SEC 0
4364                          ;DID RKBA GET CHANGED?
4365 013360 022714 033342      7$:  CMP    #OUTBUF,@R4 ;NO, BRANCH (RKBA WON'T CHANGE, NO NPR'S)
4366 013364 001406              BEQ    8$    ;GET EXPCTD RKBA
4367 013366 012737 033342 001162  MOV    #OUTBUF,$REG0 ;GET RKBA RECVD
4368 013374 011437 001164      MOV    @R4,$REG1 ;RKBA CHANGED AFTER DOING 'READ CHK'
4369 013400 104063              ERROR  63    ;ON CYLINDER 0, SECTOR 0. SHOULD
4370                          ;NOT CHANGE, FOR, NO NPR'S.
4371                          ;'OUTBUF' SHOULD STILL CONTAIN THE
4372 013402 022737 052525 033342 8$:  CMP    #52525,OUTBUF ;SAME WORD AS IT DID BEFORE 'RD CHK'
4373                          ;NOTE THAT AT THE BEGINING OF THIS TEST
4374                          ;52525 WAS WRITTEN INTO 'OUTBUF'
4375                          ;YES, EXIT
4376 013410 001412              BEQ    TST33 ;REPORT ERROR IF 'OUTBUF' CHANGED
4377                          ;GET ADRES OF OUTBUF
4378 013412 012737 033342 001162  MOV    #OUTBUF,$REG0 ;GET EXPCTD WORD IN 'OUTBUF'
4379 013420 012737 052525 001164  MOV    #52525,$REG1 ;GET WORD FOUND IN 'OUTBUF'
4380 013426 013737 033342 001166  MOV    OUTBUF,$REG2 ;AS MENTIONED ABOVE, IF 'WRITE' OF
4381 013434 104064              ERROR  64    ;256 WORD DATA BLOCK WAS DONE
4382                          ;CORRECTLY BEFORE, THEN THIS ERROR
4383                          ;COULD MEAN THAT AN NPR WAS DONE
4384                          ;ON 'READ CHECK'.
4385
;*****
;TEST 33 CHECK THE 'WRITE CHECK' FUNCTION - ON CYLINDER 0, SECTOR 0
;THIS TEST CHECKS OUT THE BASIC 'WRITE CHECK' LOGIC, USING THE 256

```



```

4390 ;*WORD DATA BLOCK (SECTOR 0, CYLINDER 0) WRITTEN IN A PREVIOUS
4391 ;*TEST. THE BUFFER IN MEMORY, USED FOR COMPARISON OF DATA, IS THE
4392 ;*ONE STARTING AT 'OUTBUF'. HENCE THE TEST WHICH WRITES THE
4393 ;*256 WORD BLOCK ON THE DISK (AS WELL AS CREATING THE 256
4394 ;*256 WORD MEMORY BUFFER) SHOULD BE DONE BEFORE THIS TEST.
4395 ;*****
4396 013436 000004 TST33: SCOPE
4397 013440 104413 CNT.RESET ;GO, DO CONTROL RESET
4398 ;THIS IS A CALL FOR THE 'CNTRL-
4399 ;RESET' ROUTINE. A CONTROL RESET IS
4400 ;ISSUED AND AFTER A CERTAIN TIME
4401 ;IF THE 'CNTRL RDY' DOES NOT SET
4402 ;AN ERROR IS REPORTED. NOTE THAT
4403 ;THE PC IN ERROR MESSAGE IS THE
4404 ;PC WHERE 'CNT.RESET' IS LOCATED.
4405 ;THIS IS A VERY BASIC ERR& IF IT
4406 ;OCCURS GO BACK TO TEST 10
4407 013442 104421 TST.SIN ;CHECK IF SIN IS SET, IF SET
4408 ;DO DRIVE RESET TO CLEAR IT
4409 013444 013701 001332 MOV RKCS,R1
4410 013450 012700 177400 MOV #-400,R0
4411 013454 012702 033342 MOV #OUTBUF,R2
4412 013460 012703 177777 MOV #177777,R3
4413 013464 062703 177401 15: ADD #177401,R3
4414 013470 010322 MOV R3,(R2)+
4415 013472 005200 INC R0
4416 013474 001373 BNE 1$
4417 013476 012777 177400 165630 MOV #-400,@RKWC ;WRITE CHECK 256 WORDS
4418 013504 012777 033342 165624 MOV #OUTBUF,@RKBA ;STARTING AT THIS BUS ADRES
4419 013512 013777 001350 165620 MOV DRIVAD,@RKDA ;WITH THIS DISK DATA BLOCK (CYL 0, SEC 0)
4420 013520 012711 000007 MOV #7,@R1 ;WRITE CHECK, GO
4421 CLR R0 ;GIVE SOME TIME
4422 013524 005000 25: TSTB @R1 ;DID CNTRL RDY CLEAR AS GO WAS SET?
4423 013526 105711 BPL 3$ ;YES BRANCH
4424 013530 100003 JSR PC,GT3RG ;GET RKCS, ER, DS
4425 013532 004737 021002 ERROR 30 ;CNTRL RDY DID NOT CLEAR AS GO WAS
4426 013536 104030 ;SET TO DO WRITE CHECK
4427 ;GO CHECK IF CONTROL RDY IS SET
4428 013540 104412 35: CHKCRDY ;IF SO, SKIP THE EROR MESSAGE.
4429 ERROR 65 ;CNTRL RDY DID NOT SET AFTER
4430 013542 104065 ;COMPLETING WRITE CHECK ON
4431 ;CYLINDER 0, SECTOR 0
4432 ;DID HE OR ERR BIT SET
4433 013544 032711 140000 45: BIT #140000,@R1 ;NO, BRANCH
4434 013550 001403 BEQ 5$ ;GO GET RKCS ER DS FOR ERROR MESSAGE
4435 013552 004737 021002 JSR PC,GT3RG ;HE OR ERR BIT SET ON DOING WRITE
4436 013556 104066 ERROR 66 ;CHK ON CYLINDER 0, SEC 0
4437 ;DID WCE SET IN RKER?
4438 013560 032777 000001 165542 55: BIT #1,@RKER ;NO, BRANCH
4439 013566 001403 BEQ 6$ ;YES GET RKCS, ER, DS
4440 013570 004737 021002 JSR PC,GT3RG ;WCE ON WRITE CHECK OF CYL 0, SEC 0
4441 013574 104067 ERROR 67 ;NOTE THAT IF A PREVIOUS TEST
4442 ;& THEN COMPARED WITH MEMORY BUFFER
4443 ;TO SEE IF IT WAS WRITTEN CORRECT WAS
4444 ;DONE RIGHT BEFORE, THIS ERROR SHOULD NOT
4445

```

```

4446 ;HAPPEN UNLESS THERE IS A FAULT IN THE
4447 ;COMPARING LOGIC OF 'WRT CHK'
4448 013576 005777 165532 65: TST @RKWC ;DID RKWC OVERFLOW?
4449 013602 001406 BEQ 7$ ;YES, BRANCH
4450 013604 017737 165524 001162 MOV @RKWC,$REG0 ;NO, GET RKWC
4451 013612 011137 001164 MOV @R1,$REG1 ;GET RKCS
4452 013616 104061 ERROR 61 ;RKWC DID NOT OVERFLOW AFTER
4453 ;WRITE CHECK ON CYL 0, SEC 0
4454 013620 013704 001350 75: MOV DRIVAD, R4 ;RKDA SHOULD INCREMENT
4455 013624 005204 INC R4 ;TO THIS AFTER WRT CHK
4456 013626 020477 165506 CMP R4,@RKDA ;DID RKDA INCREMENT CORRECTLY?
4457 013632 001406 BEQ 9$ ;YES, BRANCH
4458 013634 010437 001162 MOV R4,$REG0 ;NO, GET EXPCTD RKDA
4459 013640 017737 165474 001164 MOV @RKDA,$REG1 ;GET RKDA RECVD
4460 013646 104070 ERROR 70 ;RKDA DID NOT INCREMENT CORRECTLY
4461 ;(BY 1 SECTOR) AFTER WAT CHK ON SEC 0, CYL 0
4462 013650 022777 034342 165460 85: CMP #OUTBUF+1000,@RKBA ;DID RKBA INCREMENT CORRECTLY?
4463 013656 001407 BEQ 9$ ;YES, EXIT
4464 013660 012737 034342 001162 MOV #OUTBUF+1000,$REG0 ;GET EPCTD RKBA
4465 013666 017737 165444 001164 MOV @RKBA,$REG1 ;GET RKBA RECVD
4466 013674 104071 ERROR 71 ;RKBA DID NOT INCREMENT CORRECTLY
4467 ;(BY 1000 BYTES) AFTER A WRT CHK
4468 ;OF 256 WORDS ON CYL 0, SEC 0
4469 013676 022711 000206 95: CMP #206,@R1 ;DOES RKCS STILL CONTAIN THE WRT CHK BITS?
4470 013702 001406 BEQ TST34 ;YES, BRANCH
4471 013704 012737 000206 001162 MOV #206,$REG0 ;NO, GET EXPCTD RKCS
4472 013712 011137 001164 MOV @R1,$REG1 ;GET RKCS RECVD
4473 013716 104024 ERROR 24 ;RKCS BITS CHANGED AFTER WRT CHK
4474 ;WAS DONE
4475 ;*****
4476 ;*TEST 34 CHECK THAT IBA INHIBITS INCREMENTING OF RKBA
4477 ;*THIS TEST CHECKS THAT THE BUS ADDRESS DOES NOT INCREMENT WHEN
4478 ;*THE IBA BIT IS SET. SEQUENCE OF OPERATIONS:
4479 ;*1) CLEAR OUT 256 WORD BUFFER IN MEMORY (OUTBUF)
4480 ;*2) READ FROM SECTOR 0, CYLINDER 0 THE 256 WORD BLOCK THAT WAS
4481 ;*WRITTEN IN A PREVIOUS TEST (NOTE: THAT TEST SHOULD HAVE BEEN
4482 ;*DONE BEFORE THIS). IBA BIT IS SET DURING READ BACK.
4483 ;*3) CHECK THAT RKBA DID NOT INCREMENT
4484 ;*4) CHECK THAT THE ENTIRE BLOCK WAS READ INTO THE SAME MEMORY
4485 ;*WORD (OUTBUF) & THE REST OF THE WORDS IN THAT BUFFER ARE 0
4486 ;*AS PREVIOUSLY CLEARED OUT.
4487 ;*****
4488 013720 000004 TST34: SCOPE
4489 013722 104413 CNT.RESET ;GO, DO CONTROL RESET
4490 ;THIS IS A CALL FOR THE 'CNTRL-
4491 ;RESET' ROUTINE. A CONTROL RESET IS
4492 ;ISSUED AND AFTER A CERTAIN TIME
4493 ;IF THE 'CNTRL RDY' DOES NOT SET
4494 ;AN ERROR IS REPORTED. NOTE THAT
4495 ;THE PC IN ERROR MESSAGE IS THE
4496 ;PC WHERE 'CNT.RESET' IS LOCATED.
4497 ;THIS IS A VERY BASIC ERR& IF IT
4498 ;OCCURS GO BACK TO TEST 10
4499 013724 104421 TST.SIN ;CHECK IF SIN IS SET, IF SET
4500 ;DO DRIVE RESET TO CLEAR IT
4501 013726 013701 001332 MOV RKCS,R1

```

```

4502 013732 012700 177400      MOV      #-400,R0      ;SET UP COUNT FOR 256 WORDS
4503 013736 012702 033342      MOV      #OUTBUF,R2
4504 013742 010203      MOV      R2,R3
4505
4506 013744 005023      1$: CLR      (R3)+      ;CLEAR OUT THE 256
4507 013746 005200      INC      R0            ;WORD MEMORY BUFFER STARTING
4508 013750 001375      BNE     1$           ;AT 'OUTBUF'
4509 013752 012777 177400 165354  MOV      #-400,@RKWC   ;READ BACK 256 WORDS
4510 013760 010277 165352      MOV      R2,@RKBA     ;INTO THIS BUS ADRES (IBA WILL B SET)
4511 013764 013777 001350 165346  MOV      DRIVAD,@RKDA  ;FROM THIS DSK ADRES (SEC 0, CYL 0)
4512                                     ;NOTE: SEC 0 HAS BEEN WRITTEN IN A
4513                                     ;PREVIOUS TEST WITH A UNIQUE PATTERN
4514 013772 012711 004005      MOV      #4005,@R1    ;READ. GO, IBA SET
4515
4516 013776 005037 001362      2$: CLR      COUNT     ;DID CNTRL RDY SET?
4517 014002 105711      TSTB   @R1           ;YES, BRANCH
4518 014004 100412      BMI     3$           ;WAITED LONG ENOUGH?
4519 014006 005237 001362      INC      COUNT       ;IF NOT, LUP BAK & WAIT
4520 014012 001373      BNE     2$           ;GO, GET RKCS, ER, DS, DA
4521 014014 004737 020774      JSR     PC,GT4RG     ;GET THE STARTING ADRES
4522 014020 013737 001350 001202  MOV      DRIVAD,$REG10 ;BREAK CONTENTS OF $REG10
4523 014026 104416      BRKDA4
4524
4525 014030 104045      ERROR   45          ;CNTRL RDY DID NOT SET AFTER DOING
4526                                     ;READ
4527 014032 004737 021234      3$: JSR     PC,CHKHE   ;CHECK IF 'ERR' OR 'HE' BIT IS SET.
4528                                     ;IF YES, RETURN HERE.
4529 014036 104046      ERROR   46          ;ERR BIT SET ON DOING READ FROM SEC 0.
4530                                     ;CYL 0 (INDICATED IN <DSK-ADRES>)
4531                                     ;'RKDA' IN EROR MSGE GIVES THE
4532                                     ;CONTENTS OF RKDA AT THE TIME OF EROR
4533
4534 014040 020277 165272      4$: CMP      R2,@RKBA   ;DID RKBA INCREMENT?
4535 014044 001406      BEQ     5$           ;OK IF NOT, BRANCH
4536 014046 010237 001162      MOV      R2,$REG0    ;GET EXPCTD RKBA
4537 014052 017737 165260 001164  MOV      @RKBA,$REG1 ;GET RKBA RECVD
4538 014060 104072      ERROR   72          ;RKBA INCREMNTED WHEN IBA BIT WAS
4539                                     ;SET, SHOULD NOT HAVE
4540 014062 032777 001000 165236  5$: BIT      #1000,@RKDS ;IS SIN SET?
4541 014070 001042      BNE     TST35        ;:IF YES, EXIT
4542 014072 012700 177400      MOV      #-400,R0
4543 014076 022712 000377      CMP      #377,@R2    ;CHECK THAT THE FIRST WORD IN
4544                                     ;'OUTBUF' IS 377 (LAST WORD OF SEC 0,
4545                                     ;CYL 0). NOTE THAT READ WAS DONE
4546 014102 001411      BEQ     6$           ;INTO THIS SAME WRD WITH IBA SET
4547 014104 012737 000377 001162  MOV      #377,$REG0   ;GET EX:CTD WORD (LAST WORD OF THE BUFFER
4548 014112 011237 001164      MOV      (R2),$REG1  ;GET WORD RECVD (LAST WRD FROM SEC 0)
4549 014116 013737 001350 001166  MOV      DRIVAD,$REG2 ;DISK ADRES WHERE EROR OCCURED
4550                                     ;(SEC 0, CYL 0 LAST WORD)
4551                                     ;DATA EROR
4552 014124 104044      ERROR   44          ;THE FIRST WORD IN MEM BUFFER (OUTBUF)
4553                                     ;SHOULD BE NON-ZERO & SHOULD CONTAIN
4554                                     ;THE LAST WORD READ BACK FROM SEC 0
4555                                     ;CYL 0, THIS DID NOT HAPPEN IF THE EROR OCCURS
4556 014126 005722      6$: TST      (R2)+     ;INCREMENT POINTER TO THE NXT WORD
4557 014130 012705 177773      MOV      #-5,R5     ;ALLOW ONLY 5 MESAGES FOR ERR 116
    
```

```

4558 014134 005200      7$: INC      R0            ;CHKD ALL 256 WORDS IN THE BUFFER?
4559 014136 001417      BEQ     TST35        ;:YES, EXIT
4560 014140 005722      TST     (R2)+       ;IS THIS WORD 0?
4561 014142 001774      BEQ     7$          ;YES, LUP BAK & CHK THE NXT WORD?
4562 014144 005037 001164      CLR      $REG1,$REG2 ;ERROR. GET EXPCTD WORD = 0
4563 014150 014237 001166      MOV      -(R2),$REG2 ;GET WORD THAT WAS FOUND IN THE BUFFER
4564 014154 010004      MOV      R0,R4
4565 014156 062704 000401      ADD     #401,R4
4566 014162 010437 001162      MOV      R4,$REG0    ;THIS 'WORD #' IN MEMORY BUFFER
4567                                     ;SHOULD HAVE BEEN ZERO
4568 014166 104073      ERROR   73          ;THE 256 WORD BUFER (STARTING AT
4569                                     ;OUTBUF) WAS CLEARED BEFORE READING
4570                                     ;BAK SEC 0 INTO IT. SINCE THE IBA
4571                                     ;BIT WAS SET DURING THE READ, ONLY
4572                                     ;THE FIRST WORD OF (OUTBUF) SHOULD
4573                                     ;HAVE CHANGED, THE REST OF THE WORDS
4574                                     ;SHOULD BE STILL 0. IF THIS EROR
4575                                     ;OCCURS, 'WORD #' (OF THE BUFFER) AS
4576                                     ;INDICATED IN THE EROR MESSAGE) GOT
4577                                     ;CHANGED WHEN READ WAS DONE FROM
4578                                     ;THE DISK, INDICATING THAT WITH IBA
4579                                     ;SET X-FER WAS NOT DONE INTO THE
4580                                     ;SAME MEMORY LOCATION. 'WORD #'
4581                                     ;IS OCTAL & SPECIFIES THE POSITION
4582                                     ;IN THE BUFFER (FIRST WORD IS 'WORD #' 1)
4583 014170 005205      INC      R5
4584 014172 001401      BEQ     TST35        ;:EXIT
4585 014174 000757      BR      7$
4586
4587
4588
4589
4590
4591
4592
4593
4594
4595 014176 000004      TST35: SCOPE
4596 014200 104413      CNT.RESET          ;GO, DO CONTROL RESET
4597                                     ;THIS IS A CALL FOR THE 'CNTRL-
4598                                     ;RESET' ROUTINE. A CONTROL RESET IS
4599                                     ;ISSUED AND AFTER A CERTAIN TIME
4600                                     ;IF THE 'CNTRL RDY' DOES NOT SET
4601                                     ;AN EROR IS REPORTED. NOTE THAT
4602                                     ;THE PC IN EROR MESSAGE IS THE
4603                                     ;PC WHERE 'CNT.RESET' IS LOCATED.
4604                                     ;THIS IS A VERY BASIC ERR& IF IT
4605                                     ;OCCURS GO BACK TO TEST 10
4606 014202 104421      TST.SIN          ;CHECK IF SIN IS SET, IF SET
4607                                     ;DO DRIVE RESET TO CLEAR IT
4608 014204 012746 000340      MOV      #340,-(SP)
4609 014210 012746 014216      MOV      #645,-(SP)
4610 014214 000002      RTI
4611 014216
4612 014216 013701 001332      64$: MOV      RKCS,R1
4613 014222 013700 001402      MOV      RKVEC,R0   ;GET POINTER TO RK VECTOR ADRES
    
```

```

4614 014226 012720 014262      MOV    #1$, (R0)+      ;SET UP INTERRUPT VECTOR FOR RK11
4615 014232 012710 000340      MOV    #340, (R0)     ;SET PSW ON INTERRUPT
4616 014236 105711                TSTB   @R1             ;WAIT FOR CNTRL RDY TO SET
4617 014240 100376                BPL    -2              ;
4618 014242 012711 000100      MOV    #100, @R1      ;SET IDE BIT IN RKCS
4619 014246 104420 000005      WAT.INT ,5            ;WAIT FOR INTERRUPT, ATLEAST
4620                                ;37 US FOR 11/20, 7 US FOR 11/45
4621 014252 011137 001162      MOV    @R1, $REG0     ;GET RKCS
4622 014256 104074                ERROR  74             ;RK11 DID NOT INTERRUPT WHEN IDE
4623                                ;WAS SET, WITH CNTRLE RDY SET & GO
4624                                ;CLEAR
4625 014260 000400                BR     1$              ;
4626 014262 022626      1$:  CMP    (SP)+, (SP)+  ;RK11 INTERRUPTED CORRECTLY TO
4627                                ;THIS. RESTORE STACK POINTER
4628                                ; (FROM RK11 INTERRUPT)
4629 014264 022626      CMP    (SP)+, (SP)+  ;RESTORE STACK POINTER
4630                                ; (FROM WAT.INT)
4631 014266 012777 014302 165106  MOV    #2$, @RKVEC    ;IF THERE IS FAULTY POLLING OR INTERUPT
4632                                ; LOGIC SECOND INTERRUPT MIGHT OCCUR
4633 014274 104420 000005      WAT.INT ,5            ; WAIT FOR INTERRUPT, IF ANY
4634                                ; DUE TO FAULTY LOGIC
4635
4636 014300 000403                BR     3$              ;
4637                                ;
4638 014302 022626      2$:  CMP    (SP)+, (SP)+  ;RESTORE STACK PTR (FROM RK11 INTRUPT)
4639 014304 022626      CMP    (SP)+, (SP)+  ;RESTORE STACK PTR (FROM WAT.INT)
4640 014306 104020                ERROR  20             ;AN UNEXPECTED RK11 INTERRUPT
4641                                ; OCCURED. THERE SHOULD HAVE BEEN
4642                                ; ONLY 1 INTERRUPT (TO 1$ ABOVE)
4643 014310 012777 004600 165064 3$:  MOV    #BADINT, @RKVEC ;RESTORE VECTOR ADRES FOR
4644                                ; UNEXPECTED RK11 INTERRUPT,
4645 014316 012746 000340      MOV    #340, -(SP)    ;
4646 014322 012746 014330      MOV    #65$, -(SP)   ;
4647 014326 000002                RTI                    ;
4648 014330                65$:
4649
4650                                ;*****
4651                                ;*TEST 36 CHECK THAT WITH IDE SET RK11 INTERRUPTS AFTER INTIATION & COMPLETION OF
4652                                ;*THIS TEST CHECKS THAT AN INTERRUPT FROM RK11 OCCURS AFTER
4653                                ;*A SEEK IS INITIATED WITH 'IDE' BIT SET, AND THEN A SECOND
4654                                ;*INTERRUPT OCCURS AFTER THE SEEK IS DONE. IT ALSO CHECKS THAT
4655                                ;*AFTER THE FIRST INTERRUPT 'SCP' BIT IS NOT SET, WHEREAS AFTER
4656                                ;*THE SECOND INTERRUPT 'SCP' IS SET.
4657                                ;*THIS TEST ALSO CHECKS A PART OF THE POLLING LOGIC.
4658                                ;*****
4659                                ;*****
4660 014330 000004      TST36: SCOPE
4661 014332 012737 000005 001206  MOV    #5, $TIMES     ;DO 5 ITERATIONS
4662 014340 104413                CNT.RESET             ;GO, DO CONTROL RESET
4663                                ;THIS IS A CALL FOR THE 'CNTRL-
4664                                ;RESET' ROUTINE. A CONTROL RESET IS
4665                                ;ISSUED AND AFTER A CERTAIN TIME
4666                                ;IF THE 'CNTRL RDY' DOES NOT SET
4667                                ;AN ERROR IS REPORTED. NOTE THAT
4668                                ;THE PC IN ERROR MESSAGE IS THE
4669                                ;PC WHERE 'CNT.RESET' IS LOCATED.
    
```

```

4670                                ;THIS IS A VERY BASIC ERR& IF IT
4671                                ;OCCURS GO BACK TO TEST 10
4672 014342 013700 001332      MOV    RKCS, R0       ;
4673 014346 013777 001350 164764  MOV    DRIVAD, @RKDA  ;ADRES THE DRIVE
4674 014354 004737 021504      JSR    PC, DRESET    ;GO, DO DRIVE RESET
4675 014360 104026                ERROR  26             ;R/W/S RDY DIDN'T SET AFTER DOING
4676                                ;ABOVE DRIVE RESET
4677 014362 013701 001402      2$:  MOV    RKVEC, R1    ;
4678 014366 012721 014432      MOV    #3$, (R1)+    ;SET UP VECTOR ADRES FOR RK11 INTERUPT
4679 014372 012711 000340      MOV    #340, (R1)    ;SET UP PSW ON INTERRUPT
4680 014376 052777 000040 164734  BIS    #40, @RKDA    ;ADRES CYLINDER #1
4681 014404 012710 000111      MOV    #111, @R0     ;SEEK, GO WITH IDE SET
4682 014410 104420 000300      WAT.INT ,300        ;WAIT FOR THE DRIVE TO
4683                                ; INTERRUPT AFTER ADRES WAS RECVD
4684                                ; WAITING TIME= 1.4 MS FOR 11/20
4685                                ; 280 US FOR 11/45
4686                                ; ERROR, IF INTERUPT DID NOT OCCUR
4687                                ; BY NOW
4688 014414 012777 004600 164760  MOV    #BADINT, @RKVEC ;RESTORE UNEXPECTED RK11 INTERRUPT
4689 014422 011037 001162      MOV    @R0, $REG0    ;GET RKCS
4690 014426 104075                ERROR  75             ;INTERRUPT DID NOT OCCUR AFTER
4691                                ;SEEK WAS INITIATED WITH IDE SET
4692 014430 000402                BR     3$+4           ;
4693 014432 022626      3$:  CMP    (SP)+, (SP)+  ;OK, IF RK11 INTERRUPTED TO THIS
4694                                ; RESTORE STACK POINTER (FROM RK11 INTERRUPT)
4695 014434 022626      CMP    (SP)+, (SP)+  ;RESTORE STACK POINTER (FROM
4696                                ; WAT.INT)
4697 014436 012777 014502 164736  MOV    #5$, @RKVEC    ;SET UP NEW VECTOR ADRES FOR RK11
4698 014444 032710 020000      BIT    #20000, @R0   ;IS SCP CLEAR
4699 014450 001403                BEQ    4$              ;YES, BRANCH
4700 014452 011037 001162      MOV    @R0, $REG0    ;GET RKCS
4701 014456 104076                ERROR  76             ;SCP SET BEFORE SEEK TO LAST
4702                                ; CYLINDER WAS DONE
4703 014460 104420 056700      4$:  WAT.INT ,56700    ;WAIT FOR DRIVE TO INTERRUPT
4704                                ; AFTER SEEK WAS COMPLETED
4705                                ; WAITING TIME=180 MS FOR 11/20
4706                                ; 36 MS FOR 11/45
4707 014464 012777 004600 164710  MOV    #BADINT, @RKVEC ;IT'S AN ERROR IF BY THIS TIME
4708                                ; INTERRUPT HAS NOT OCCURED
4709 014472 004737 021002      JSR    PC, GT3RG     ;GO GET RKCS, ER, DS
4710 014476 104077                ERROR  77             ;RK11 DID NOT INTERRUPT AFTER SEEK (TO
4711                                ; LAST CYLINDER) WAS DONE WITH IDE SET
4712 014500 000401                BR     5$+2           ;
4713 014502 02 626                5$:  CMP    (SP)+, (SP)+  ;OK, IF RK11 INTERRUPTED TO THIS AFTER
4714                                ; SEEK WAS COMPLETED, RESTORE
4715                                ; STACK POINTER (FROM RK11 INTERRUPT)
4716 014504 022626      CMP    (SP)+, (SP)+  ;RESTORE STACK POINTER (FROM
4717                                ; WAT.INT)
4718 014506 012777 004600 164666  MOV    #BADINT, @RKVEC ;RESTORE RK11 INTERRUPT VECTOR ADRES
4719                                ; FOR UNEXPECTED INTERUTS
4720 014514 032710 020000      BIT    #20000, @R0   ;DID SCP BIT SET?
4721 014520 001003                BNE    6$              ;YES, BRANCH
4722 014522 011037 001162      MOV    @R0, $REG0    ;GET RKCS
4723 014526 104053                ERROR  53             ;SCP DID NOT SET AFTER RK11 INTERRUPTED
4724                                ; INDICATING SEEK WAS DONE
4725 014530 017701 164572      6$:  MOV    @RKDS, R1    ;GET RKDS
    
```

```

4726 014534 042701 017777      BIC      #17777,R1      ;MASK NON-ID BITS IN RKDS
4727 014540 020137 001350      CMP      R1,DRIVAD    ;CORRECT ID BITS IN RKDS?
4728 014544 001414                BEQ      75           ;YES, BRANCH
4729
4730 014546 013746 001350      MOV      DRIVAD,-(SP) ;PUSH DRV ADRES ON THE STACK
4731 014552 004737 021200      JSR      PC,SHFTRT   ;GO, SHIFT RIGHT DRV #
4732 014556 012637 001162      MOV      (SP)+,$REG0 ;GET EXPTD DRV #
4733 014562 010146                MOV      R1,-(SP)    ;PUSH ID BITS ON THE STACK
4734 014564 004737 021200      JSR      PC,SHFTRT   ;GO SHIFT THEM RIGHT
4735 014570 012637 001164      MOV      (SP)+,$REG1 ;POP THE RECVD ID BITS
4736 014574 104047                ERROR    47          ;WRONG ID BITS WERE RECVD IN
                          ;RKDS AFTER SEEK WAS DONE (INTRUPT
                          ;MODE). 'EXPCT' INDICATES THE DRIVE
                          ;# THAT SHOULD HAVE BEEN IN THE
                          ;ID BITS, 'RECVD' INDICATES THE
                          ;DRIVE # THAT WAS RECVD IN THE ID BITS
4737
4738
4739
4740
4741
4742
4743 014576                75:
4744 014576 012746 000340      MOV      #340,-(SP)
4745 014602 012746 014610      MOV      #64$,-(SP)
4746 014606 000002                RTI
4747 014610
4748 014610 104413                64$:
4749 014612 013777 001350 164520  CNT.RESET      ;GO DO CONTROL RESET
4750 014620 032777 160000 164500  MOV      DRIVAD,@RKDA ;ADRES THE DRIVE
4751 014626 001404                BIT      #160000,@RKDS ;DID CNTRL RESET CLEAR DRIVE ID BITS?
4752 014630 017737 164472 001162  BEQ      85           ;YES, BR'NCH
4753 014636 104050                MOV      @RKDS,$REG0 ;GET RKDS
4754
4755
4756
4757 014640 022710 000200      ERROR    50          ;CONTROL RESET DIDN'T CLEAR THE
                          ;DRIVE ID BITS (13-15) IN RKDS
4758 014644 001403                85:
4759 014646 011037 001162      CMP      #200,@R0    ;WAS SCP BIT CLEARED BY CNTRL RESET?
4760 014652 104100                BEQ      TST37       ;;YES, EXIT
4761
4762
4763
4764
4765
4766
4767
4768 014654 000004                MOV      @R0,$REG0 ;GET RKCS
4769 014656 104413                ERROR    100        ;CNTRL RESET DID NOT CLEAR SCP BIT
4770
4771
4772
4773
4774
4775
4776
4777
4778
4779 014660 104421                TST.SIN
4780
4781
;*****
;*TEST 37 CHECK THAT WITH IDE SET RK11 INTERRUPTS WHEN READ IS DONE
;*THIS TEST CHECKS THAT WHEN A DATA TRANSFER FUNCTION IS DONE
;*WITH IDE BIT SET, RK11 INTERRUPTS WHEN THE FUNCTION IS COMPLETED
;*FUNCTION USED IN THIS TEST IS READ.
;*****
TST37: SCOPE
CNT.RESET      ;GO, DO CONTROL RESET
              ;THIS IS A CALL FOR THE 'CNTRL-
              ;RESET' ROUTINE. A CONTROL RESET IS
              ;ISSUED AND AFTER A CERTAIN TIME
              ;IF THE 'CNTRL RDY' DOES NOT SET
              ;AN ERROR IS REPORTED. NOTE THAT
              ;THE PC IN ERROR MESSAGE IS THE
              ;PC WHERE 'CNT.RESET' IS LOCATED.
              ;THIS IS A VERY BASIC ERR# IF IT
              ;OCCURS GO BACK TO TEST 10
              ;CHECK IF SIN IS SET, IF SET
              ;DO DRIVE RESET TO CLEAR IT

```

```

4782 014662 013700 001332      MOV      RKCS,R0
4783 014666 013702 001340      MOV      RKDA,R2
4784 014672 013704 001336      MOV      RKBA,R4
4785 014676 013701 001350      MOV      DRIVAD,R1
4786 014702 052701 000013      BIS      #13,R1      ;SET BITS FOR SEC 13
4787 014706 012777 177600 164420  MOV      #-200,@RKWC ;READ 200 (OCTAL WORDS)
4788 014714 010112                MOV      R1,@R2     ;FROM THIS DISK ADRES (CYL 0, SEC 13)
4789 014716 012714 033342      MOV      #OUTBUF,@R4 ;INTO THIS BUS ADRES
4790 014722 013705 001402      MOV      RKVEC,R5
4791 014726 012725 014764      MOV      #1$,(R5)+  ;SET UP VECTOR ADRES FOR RK11 TO INTRUPT
4792 014732 012715 000340      MOV      #340,(R5)  ;SET PSW ON INTERRUPT
4793 014736 012710 000105      MOV      #105,@R0  ;READ, GO, IDE SET
4794 014742 104420 127710      WAT.INT ,127710    ;WAIT FOR RK11 TO INTERRUPT ON
                          ;COMPLETION OF READ
                          ;WAITING TIME= 337 MS FOR 11/20
                          ;67 MS FOR 11/45
4795
4796
4797
4798 014746 012777 004600 164426  MOV      #BADINT,@RKVEC ;RESTORE UNEXPTD INTERRUPT VECTOR ADRES
4799 014754 011037 001162      MOV      @R0,$REG0 ;GET RKCS
4800 014760 104101                ERROR    101        ;RK11 DID NOT INTERRUPT AFTER READ
                          ;WAS DONE, IDE BIT SET.
4801
4802 014762 000404                1$:
4803 014764 022626                BR      1$+10
4804
4805 014766 022626                CMP      (SP)+,(SP)+ ;OK, IF RK11 INTERRUPTED TO THIS
4806 014770 012777 004600 164404  MOV      #BADINT,@RKVEC ;RESTORE STACK POINTER (FROM RK11 INTERRUPT)
                          ;RESTORE STACK POINTER (FROM WAT.INT)
4807
4808 014776 004737 021342      JSR      PC,CHKR    ;RESTORE UNEXPTD RK11 INTERRUPT
                          ;VECTOR ADRES
4809
4810 015002 104036                JSR      PC,CHKR    ;CHECK IF ANY BIT IN RKER IS SET,
                          ;IF YES, RETURN HERE.
4811
4812 015004 062701 000005      ERROR    36         ;RKER SET ON DOING READ FROM SEC 0,
                          ;CYL 13 IN INTERRUPT MODE
4813 015010 020112                4$:
4814 015012 001405                ADD      #5,R1      ;RKDA SHOULD HAVE INCREMENTED TO THIS
4815 015014 010137 001162      CMP      R1,@R2     ;DID RKDA INCREMENT CORRECTLY?
4816 015020 011237 001164      BEQ      2$         ;YES BRANCH
4817 015024 104040                MOV      R1,$REG0  ;GET EXPTD RTDA
4818
4819 015026 004737 021316      MOV      @R2,$REG1 ;GET RKDA RECVD
4820
4821 015032 104041                ERROR    40         ;RKDA INCREMENTED WRONG ON DOING
                          ;A READ ON CYL 0, SEC 13
4822
4823
4824 015034                2$:
4825 015034 012746 000340      JSR      PC,CHKWC  ;CHECK THAT RKWC OVERFLOWED TO 0,
4826 015040 012746 015046      ERROR    41         ;IF NOT RETURN HERE.
4827 015044 000002                ;RKWC DIDN'T OUFLO AFTER
4828 015046                ;A READ OF 200 WORDS
4829 015046 022714 033742      3$:
4830 015052 001406                MOV      #340,-(SP)
4831 015054 012737 033742 001162  MOV      #64$,-(SP)
4832 015062 011437 001164      RTI
4833 015066 104042                64$:
4834
4835
4836
4837
4838
4839
4840
4841
4842
4843
4844
4845
4846
4847
4848
4849
4850
4851
4852
4853
4854
4855
4856
4857
4858
4859
4860
4861
4862
4863
4864
4865
4866
4867
4868
4869
4870
4871
4872
4873
4874
4875
4876
4877
4878
4879
4880
4881
4882
4883
4884
4885
4886
4887
4888
4889
4890
4891
4892
4893
4894
4895
4896
4897
4898
4899
4900
4901
4902
4903
4904
4905
4906
4907
4908
4909
4910
4911
4912
4913
4914
4915
4916
4917
4918
4919
4920
4921
4922
4923
4924
4925
4926
4927
4928
4929
4930
4931
4932
4933
4934
4935
4936
4937
;*****
;*TEST 40 CHECK THAT RK11 INTERRUPTS AT BR5 ONLY
;*****

```

```

4838 ;*THIS TEST CHECKS THAT RK11 CAN INTERRUPT AT BR5 ONLY. IF IT
4839 ;*INTERRUPTS AT A LEVEL HIGHER THAN BR5 AN ERROR IS INDICATED.
4840 ;*IF IT DOES NOT INTERRUPT AT BR5 OR LOWER THEN ALSO AN
4841 ;*ERROR IS INDICATED. IF FOR SOME REASON THE INTERRUPT
4842 ;*LEVEL IS CHANGED FROM BR5, THEN CONTENTS OF RKPRI WILL
4843 ;*HAVE TO BE CHANGED ACCORDINGLY AND STILL TEXT WILL
4844 ;*CHECK FOR THIS BR LEVEL.
4845 ;*****
4846 015070 000004 TST40: SCOPE
4847 015072 104413 CNT.RESET ;GO, DO CONTROL RESET
4848 ;THIS IS A CALL FOR THE 'CNTRL-
4849 ;RESET' ROUTINE. A CONTROL RESET IS
4850 ;ISSUED AND AFTER A CERTAIN TIME
4851 ;IF THE 'CNTRL RDY' DOES NOT SET
4852 ;AN ERROR IS REPORTED. NOTE THAT
4853 ;THE PC IN ERROR MESSAGE IS THE
4854 ;PC WHERE 'CNT.RESET' IS LOCATED.
4855 ;THIS IS A VERY BASIC ERR& IF IT
4856 ;OCCURS GO BACK TO TEST 10
4857 015074 104421 TST.SIN ;CHECK IF SIN IS SET, IF
4858 ;DO DRIVE RESET TO CLR IT
4859 015076 012737 015132 001110 MOV #1$,LPCRR ;SET RETURN ADRES FOR LUPING
4860 ;ON ERROR (SW 9)
4861 015104 013700 001332 MOV RKCS,R0
4862 015110 013777 001350 164222 MOV DRIVAD,@RKDA
4863 015116 012701 000007 MOV #7,R1 ;PRIORITY LEVEL 7
4864 015122 012702 000340 MOV #340,R2 ;BR LEVEL 7 FOR PSW
4865 015126 013703 001400 MOV RKPRI,R3 ;NOTE. IF RK11 INTERRUPT LEVEL IS
;CHANGED FROM 5 TO ANY OTHER LEVEL
;THEN CHANGE CONTENTS OF 'RKPRI'
; ACCORDINGLY
4866
4867
4868
4869 015132 013704 001402 1$: MOV RKVEC,R4
4870 015136 012724 015244 MOV #3$, (R4)+ ;SET UP ADRES FOR RK11 TO INTERUPT
4871 015142 012714 000340 MOV #340, (R4) ;SET UP PSW ON INTERRUPT
4872 015146 010246 MOV R2, -(SP) ;SET PROCESSOR PRIORITY LEVEL AS
4873 015150 012746 015156 MOV #4$, -(SP)
4874 015154 000002 RTI
4875 015156 4$:
4876 015156 012710 000100 MOV #100,@R0 ;INDICATED BY R2
4877 015162 012705 177760 MOV #-20,R5 ;SET THE IDE BIT
4878 015166 005205 INC R5 ;WAIT FOR THE RK11 INTERRUPT
4879 015170 001376 BNE -2 ;WAITING TIME=78 US FOR 11/20
4880 015172 020203 CMP R2,R3 ;13 US FOR 11/45
4881 015174 003005 BGT 2$ ;WAS THE CPU PRIORITY LEVEL LESS THAN
;THE RK11 LEVEL? IF YES, RK11
;SHOULD HAVE INTERRUPTED. ERROR,
;IF IT C.D NOT
4882
4883
4884 015176 010137 001162 MOV R1,$REG0 ;GET CPU BR LEVEL
4885 015202 011037 001164 MOV @R0,$REG1 ;GET RKCS
4886 015206 104103 ERROR 103 ;THOUGH CPU LEVEL WAS LESS THAN
;THE RK11 LEVEL (5). RK11 DID NOT
;INTERRUPT
4887
4888
4889 015210 005010 2$: CLR @R0 ;CLEAR RKCS
4890 015212 062702 177740 ADD #-40,R2 ;DECREASE THE PRIORITY LEVEL (FOR
;CPU) BY 1
4891
4892 015216 005301 DEC R1 ;CPU WILL B AT THIS LEVEL
4893 015220 001344 BNE 1$ ;LUP BAK & CHK FOR THIS BR LEVEL.

```

```

4894
4895 015222 012777 004600 164152 MOV #BADINT,@RKVEC ;DONE WITH CHKING FOR ALL LEVELS.
4896 ;RESTORE UNEXPECTED RK11 INTERRUPT
4897 ;VECTOR
4897 015230 012746 000340 MOV #340, -(SP)
4898 015234 012746 015242 MOV #64$, -(SP)
4899 015240 000002 RTI
4900 015242 64$:
4901 015242 000414 BR TST41 ;EXIT, TO NXT TST
4902
4903 015244 022626 3$: CMP (SP)+, (SP)+ ;RESTORE STACK POINTER
4904 015246 012777 004600 164126 MOV #BADINT,@RKVEC ;RESTORE UNEXPECTED RK11 INTERRUPT
4905 ;VECTOR
4906 015254 020203 CMP R2,R3 ;IF THIS INTERRUPT OCCURED WHEN
4907 015256 003754 BLE 2$ ;CPU LEVEL WAS LESS THAN THE
;RK11 PRIORITY LEVEL (5) THEN IT IS
;OK. IF NOT SO, ERROR
4908
4909
4910 015260 010137 001162 MOV R1,$REG0 ;GET CPU BR LEVEL
4911 015264 011037 001164 MOV @R0,$REG1 ;GET RKCS
4912 015270 104104 ERROR 104 ;RK11 INTERRUPTED WHEN THE CPU
;LEVEL (AS POINTED BY R1) WAS
;HIGHER OR SAME AS THE RK11
;LEVEL (5)
4913
4914
4915
4916 015272 000746 BR 2$ ;GO BACK & CHK THE NXT LEVEL
4917
4918 ;*****
4919 ;*TEST 41 SIMULATE & CHECK 'OVR' ERROR
4920 ;*THIS TEST SIMULATES OVERRUN ERROR AND CHECKS IF THE OVR
4921 ;*BIT IN RKER GETS SET. THEN IT IS CLEARED USING CNTRL RESET
4922 ;*& CHECKED THAT IT WAS CLEARED. OVR CONDITION IS SIMULATED
4923 ;*BY TRYING TO READ 401(OCTAL) WORDS FROM LAST CYLINDER(312),
4924 ;*LAST SECTOR (13), SURFACE 1.
4925 ;*****
4926 015274 000004 TST41: SCOPE
4927 015276 104413 CNT.RESET ;GO, DO CONTROL RESET
4928 ;THIS IS A CALL FOR THE 'CNTRL-
4929 ;RESET' ROUTINE. A CONTROL RESET IS
4930 ;ISSUED AND AFTER A CERTAIN TIME
4931 ;IF THE 'CNTRL RDY' DOES NOT SET
4932 ;AN ERROR IS REPORTED. NOTE THAT
4933 ;THE PC IN ERROR MESSAGE IS THE
4934 ;PC WHERE 'CNT.RESET' IS LOCATED.
4935 ;THIS IS A VERY BASIC ERR& IF IT
4936 ;OCCURS GO BACK TO TEST 10
4937 015300 104421 TST.SIN ;CHECK IF SIN IS SET, IF
4938 ;SET, DO DRIVE RESET TO CLR IT
4939 015302 013701 001350 MOV DRIVAD,R1 ;GET ADRES OF DRIVE
4940 015306 052701 014533 BIS #14533,R1 ;SET BITS FOR LAST CYLINDER (312),
;SUR 1, LAST SECTOR (13)
4941
4942 015312 012777 177377 164014 MOV #-401,@RKWC ;READ 401 WORDS
4943 015320 012777 033342 164010 MOV #OUTBUF,@RKBA ;INTO THIS MEMORY BUFFER
4944 015326 010177 164006 MOV R1,@RKDA ;FROM THIS DSK ADRES, LAST CYL,
;LAST SEC, SURFACE 1
4945
4946 015332 012777 000005 163772 MOV #5,@RKCS ;READ, GO
4947
4948
4948 015340 005002 CLR R2
4949 015342 105777 163764 1$: TSTB @RKCS ;DID CNTRL RDY SET?

```

```

4950 015346 100410      BMI      2$      ;YES, BRANCH
4951 015350 005202      INC      R2      ;NO, WAIT FOR IT
4952 015352 001373      BNE     1$      ;IF WAITED LONG, REPORT ERROR MESSAGE BECAUSE
4953                                     ;OVR SHOULD HAVE SET HE CAUSING
4954                                     ;CNTRL RDY TO SET BY NOW
4955 015354 017737 163754 001166      MOV     @RKWC,$REG2
4956 015362 004737 021010      JSR    PC,GT2RG
4957 015366 104002      ERROR  2        ;GO, GET RKCS, ER
4958                                     ;CNTRL RDY DID NOT SET AFTER DOING
4959                                     ;AN OVR READ. HE SHOULD HAVE OCCURRED
4960                                     ;SETTING CNTRL RDY (HE BECAUSE OF
4961                                     ;OVR CONDITIONS)
4962 015370 032777 040000 163732 2$:  BIT     #40000,@RKER
4963                                     ;DID OVR BIT SET IN RKER?
4964 015376 001006      BNE     3$
4965 015400 004737 021010      JSR    PC,GT2RG
4966                                     ;GET RKCS, ER
4967 015404 012737 040000 001166      MOV     #40000,$REG2
4968                                     ;THIS BIT (OVR) DID NOT SET.
4969 015412 104105      ERROR  105     ;OVR ERROR BIT DID NOT SET IN RKER
4970                                     ;ON SIMULATING OVR CONDITIONS
4971 015414 022777 140204 163710 3$:  CMP     #140204,@RKCS
4972                                     ;DID HE & ERR SET WHEN OVR SET IN RKER?
4973 015422 001403      BEQ     4$
4974 015424 004737 021010      JSR    PC,GT2RG
4975 015430 104106      ERROR  106     ;YES, BRANCH
4976                                     ;GET RKCS, ER
4977                                     ;HE OR ERR BIT DID NOT SET IN RKCS WHEN
4978                                     ;AN OVR ERROR WAS SIMULATED
4979 015432 104413      4$:  CNT.RESET
4980                                     ;CLEAR OVR, ERR, HE BITS
4981                                     ;GO, DO CONTROL RESET
4982                                     ;THIS IS A CALL FOR THE 'CNTRL-
4983                                     ;RESET' ROUTINE. A CONTROL RESET IS
4984                                     ;ISSUED AND AFTER A CERTAIN TIME
4985                                     ;IF THE 'CNTRL RDY' DOES NOT SET
4986                                     ;AN ERROR IS REPORTED. NOTE THAT
4987                                     ;THE PC IN ERROR MESSAGE IS THE
4988                                     ;PC WHERE 'CNT.RESET' IS LOCATED.
4989                                     ;THIS IS A VERY BASIC ERR& IF IT
4990                                     ;OCCURS GO BACK TO TEST 10
4991 015434 004737 021356      JSR    PC,CHKECLR
4992                                     ;CHECK IF 'OVR' BIT WAS CLEARED BY
4993                                     ;CON.RESET. IF NOT RETURN HERE.
4994                                     ;CNTRL RESET DID NOT CLEAR OVR
4995                                     ;BIT IN RKER
4996 015440 104102      ERROR  102     ;CHECK IF 'ERR' & 'HE' BIT GOT CLEARED BY
4997 015442 004737 021402      5$:  JSR    PC,CHKCCLR
4998                                     ;CON.RESET. IF NOT RETURN HERE.
4999 015446 104102      ERROR  102     ;CNTRL RESET DID NOT CLEAR
5000                                     ;HE OR ERR BIT IN RKCS.
5001 015450 004737 021504      6$:  JSR    PC,DRESET
5002 015454 104026      ERROR  26      ;GO DO DRIVE RESET
5003                                     ;R/W/S RDY DIDN'T SET
5004                                     ;AFTER THE ABOVE DRIVE RESET
5005
5006 ;*****
5007 ;*TEST 42 SIMULATE & CHECK PGE ERROR
5008 ;*THIS TEST SIMULATES 'PROGRAMMING ERROR' & CHECKS IF IT IS
5009 ;*DETECTED BY PGE BIT IN RKER. THEN A CNTRL RESET IS DONE &
5010 ;*IT IS CHECKED IF PGE BIT WAS CLEARED. IT IS ALSO CHECKED IF
5011 ;*THE SETTING & CLEARING OF PGE BIT SETS & CLEARS HE, ERR
5012 ;*BITS IN RKCS.
5013 ;*****
5014 TST42: SCOPE
5015 CNT.RESET ;GO, DO CONTROL RESET
5016 ;THIS IS A CALL FOR THE 'CNTRL-

```

```

5006 ;RESET' ROUTINE. A CONTROL RESET IS
5007 ;ISSUED AND AFTER A CERTAIN TIME
5008 ;IF THE 'CNTRL RDY' DOES NOT SET
5009 ;AN ERROR IS REPORTED. NOTE THAT
5010 ;THE PC IN ERROR MESSAGE IS THE
5011 ;PC WHERE 'CNT.RESET' IS LOCATED.
5012 ;THIS IS A VERY BASIC ERR& IF IT
5013 ;OCCURS GO BACK TO TEST 10
5014 015462 104421      TST.SIN
5015 ;GO CHECK IF SIN IS SET, IF
5016 ;SET DO DRIVE RESET TO CLR IT
5017 015464 013701 001330      MOV     RKER,R1
5018 015470 013777 001350 16364L      MOV     DRIVAD,@RKDA ;ADRES THE DRIVE, CYLINDER 0
5019 015476 012777 002011 163626      MOV     #2011,@RKCS
5020                                     ;SEEK, GO WITH FMT SET
5021 015504 104414      CNT.RDY
5022                                     ;THIS IS A CALL FOR 'CN.RDY'
5023                                     ;ROUTINE WHICH WAITS FOR CNT
5024                                     ;RDY TO SET. IF CNTRL RDY DOES
5025                                     ;NOT SET WITHIN 883 MS/ 11-20
5026                                     ;(176 MS FOR 11-45 WITH BIPOLAR)
5027 015506 032711 004000      BIT     #4000,@R1
5028 015512 001006      BNE     1$
5029 015514 012737 004000 001166      MOV     #4000,$REG2
5030 015522 004737 021010      JSR    PC,GT2RG
5031 015526 104105      ERROR  105     ;AN ERROR IS REPORTED
5032                                     ;DID PGE BIT IN RKER SET?
5033                                     ;YES, BRANCH
5034 015530 022777 142210 163574 1$:  CMP     #142210,@RKCS
5035 015536 001403      BEQ     2$
5036 015540 004737 021010      JSR    PC,GT2RG
5037 015544 104106      ERROR  106     ;GO, GET RKCS, ER
5038                                     ;HE OR ERR BIT DID NOT SET WHEN
5039                                     ;PGE SET IN RKER.
5040                                     ;CLEAR PGE, HE, ERR BITS
5041 015546 104413      2$:  CNT.RESET
5042                                     ;GO, DO CONTROL RESET
5043                                     ;THIS IS A CALL FOR THE 'CNTRL-
5044                                     ;RESET' ROUTINE. A CONTROL RESET IS
5045                                     ;ISSUED AND AFTER A CERTAIN TIME
5046                                     ;IF THE 'CNTRL RDY' DOES NOT SET
5047                                     ;AN ERROR IS REPORTED. NOTE THAT
5048                                     ;THE PC IN ERROR MESSAGE IS THE
5049                                     ;PC WHERE 'CNT.RESET' IS LOCATED.
5050                                     ;THIS IS A VERY BASIC ERR& IF IT
5051                                     ;OCCURS GO BACK TO TEST 10
5052 015550 004737 021356      JSR    PC,CHKECLR
5053                                     ;CHECK IF 'PGE' BIT GOT CLEARED BY
5054                                     ;CONTROL RESET, IF NOT RETURN HERE.
5055 015554 104102      ERROR  102     ;CNTRL RESET DID NOT CLEAR
5056 015556 004737 021402      3$:  JSR    PC,CHKCCLR
5057 015562 104102      ERROR  102     ;PGE BIT IN RKER
5058                                     ;CHECK IF 'ERR' BITGOT CLEARED BY
5059                                     ;CON.RESET, IF NOT RETURN HERE.
5060                                     ;RKCS BITS HE OR ERR DID NOT
5061                                     ;GET CLEARED BY CNTRL RESET
5062 ;*****
5063 ;*TEST 43 SIMULATE & CHECK NXM ERROR

```

```

5062 ;*THIS TEST SIMULATES A NON-EXISTENT MEMORY ERROR (NXM) AND
5063 ;*CHECKS IF IT IS DETECTED BY NXM BIT OR RKER. LOCATION 760000
5064 ;*IS REFERENCED & IT HAPPENS TO BE A NON EXISTENT LOCATION
5065 ;*(FOR DIAGNOSTIC PURPOSES LIKE THIS). IT IS ALSO CHECKED
5066 ;*IF HE & ERR BITS ALSO SET AND ALL 3 BITS CAN BE CLEARED
5067 ;* BY CONTROL RESET
5068 ;*****
5069 015564 000004 ;TST43: SCOPE
5070 015566 104413 CNT.RESET ;GO, DO CONTROL RESET
5071 ;THIS IS A CALL FOR THE 'CNTRL-
5072 ;RESET' ROUTINE. A CONTROL RESET IS
5073 ;ISSUED AND AFTER A CERTAIN TIME
5074 ;IF THE 'CNTRL RDY' DOES NOT SET
5075 ;AN ERROR IS REPORTED. NOTE THAT
5076 ;THE PC IN ERROR MESSAGE IS THE
5077 ;PC WHERE 'CNT.RESET' IS LOCATED.
5078 ;THIS IS A VERY BASIC ERR& IF IT
5079 ;OCCURS GO BACK TO TEST 10
5080 015570 104421 TST.SIN ;GO CHECK IF SIN IS SET
5081 ;IF SET DO DRIVE RESET TO CLR IT
5082 015572 005002 CLR R2
5083 015574 013700 001332 MOV RKCS,R0
5084 015600 012777 177777 163526 MOV #-1,@RKWC ;WRITE CHECK 1 WORD
5085 015606 012777 160000 163522 MOV #160000,@RKBA ;AT THIS BUS ADRES
5086 015614 013777 001350 163516 MOV DRIVAD,@RKDA ;WITH THIS DISK ADRES (CYL 0, SEC 0)
5087 015622 012710 000067 MOV #67,@R0 ;WRT CHK GO, MEX BITS SET
5088 015626 105777 163500 1$: TSTB @RKCS ;DID CNTRL RDY SET AS A RESULT OF HE?
5089 015632 100410 BMI 2$ ;YES, BRANCH
5090 015634 005202 INC R2 ;WAITED LONG ENOUGH?
5091 015636 001373 BNE 1$ ;IF NOT LUP BAK & WAIT
5092 015640 004737 021010 JSR PC,GT2RG ;GET RKCS, ER
5093 015644 017737 163464 001166 MOV @RKWC,$REG2 ;GET RKWC
5094 015652 104113 ERROR 113 ;CNTRL RDY DID NOT SET ON DOING
5095 ;A WRT CHK WITH A NXM LOCATION.
5096 ;THIS HE SHOULD HAVE SET THE
5097 ;CNTRL RDY BIT IN RKCS
5098 015654 032777 002000 163446 2$: BIT #2000,@RKER ;DID NXM BIT IN RKER SET?
5099 015662 001006 BNE 3$ ;YES, BRANCH
5100 015664 004737 021010 JSR PC,GT2RG ;GO GET RKCS, RKER
5101 015670 012737 002000 001166 MOV #2000,$REG2 ;THIS BIT (NXM) DID NOT SET IN RKER
5102 015676 104105 ERROR 105 ;NXM BIT DID NOT SET IN RKER ON
5103 ;SIMULATING NXM CONDITION.
5104 015700 022710 140266 3$: CMP #140266,@R0 ;DID HE & ERR BIT SET?
5105 015704 001403 BEQ 4$ ;YES, BRANCH
5106 015706 004737 021010 JSR PC,GT2RG ;GO, GET RKCS, RKER
5107 015712 104106 ERROR 106 ;HE OR ERR BIT DID NOT SET WHEN
5108 ;NXM ERROR WAS SIMULATED
5109 ;CLEAR NXM, HE, ERR BITS
5110 015714 104413 4$: CNT.RESET ;GO, DO CONTROL RESET
5111 ;THIS IS A CALL FOR THE 'CNTRL-
5112 ;RESET' ROUTINE. A CONTROL RESET IS
5113 ;ISSUED AND AFTER A CERTAIN TIME
5114 ;IF THE 'CNTRL RDY' DOES NOT SET
5115 ;AN ERROR IS REPORTED. NOTE THAT
5116 ;THE PC IN ERROR MESSAGE IS THE
5117 ;PC WHERE 'CNT.RESET' IS LOCATED.

```

```

5118 ;THIS IS A VERY BASIC ERR& IF IT
5119 ;OCCURS GO BACK TO TEST 10
5120 015716 004737 021356 JSR PC,CHKECLR ;CHECK IF 'NXM' BIT GOT C;LEARED BY
5121 ;CON.RESET, IF NOT RETURN HERE.
5122 015722 104102 ERROR 102 ;CNTRL RESET DID NOT CLEAR
5123 ;NXM BIT IN RKER
5124 015724 004737 021402 5$: JSR PC,CHKCCLR ;CHECK IF 'HE' & 'ERR' BITS GOT CLEARED
5125 ;BY CON.RESET, IF NOT RETURN HERE.
5126 015730 104102 ERROR 102 ;CNTRL RESET DID NOT CLEAR
5127 ;HE OR ERR BIT IN RKCS.
5128 015732 004737 021436 6$: JSR PC,TSTRWS ;GO CHECK IF R/W/S RDY IS SET &
5129 ;WAIT FOR IT. SKIP ERROR IF IT IS SET
5130 015736 104016 ERROR 16 ;R/W/S RDY IS NOT SET
5131 ;*****
5132 ;*TEST 44 SIMULATE & CHECK NXD ERROR
5133 ;*THIS TEST SIMULATES NON-EXISTENT DISK ERROR & CHECKS IF
5134 ;*IT IS DETECTED BY NXD BIT OF RKER. IF ALL EIGHT ARE PRESENT
5135 ;*THEN THIS TEST IS ABORTED FOR SIMULATION CANNOT BE DONE.
5136 ;*****
5137 ;TST44: SCOPE
5138 015740 000004 CNT.RESET ;GO, DO CONTROL RESET
5139 015742 104413 ;THIS IS A CALL FOR THE 'CNTRL-
5140 ;RESET' ROUTINE. A CONTROL RESET IS
5141 ;ISSUED AND AFTER A CERTAIN TIME
5142 ;IF THE 'CNTRL RDY' DOES NOT SET
5143 ;AN ERROR IS REPORTED. NOTE THAT
5144 ;THE PC IN ERROR MESSAGE IS THE
5145 ;PC WHERE 'CNT.RESET' IS LOCATED.
5146 ;THIS IS A VERY BASIC ERR& IF IT
5147 ;OCCURS GO BACK TO TEST 10
5148 ;CHECK IF SIN IS SET, IF SET
5149 015744 104421 TST.SIN ;DO DRV RESET TO CLR IT
5150 ;*****
5151 015746 013700 001332 MOV RKCS,R0
5152 015752 012702 160000 MOV #160000,R2 ;ADRES DRIVE 7 TO FIND
5153 ;IF IT IS PRESENT
5154 015756 010277 163356 1$: MOV R2,@RKDA ;ADRES DRIVE # POINTED TO BY R2
5155 015762 104417 000001 DELAY ,1 ;TIME DELAY, 7.5 US ON 11/20,
5156 ;1.5 US ON 11/45
5157 015766 105777 163334 TSTB @RKDS ;IS IT PRESENT?
5158 015772 100004 BPL 2$ ;NO, BRANCH
5159 015774 062702 160000 ADD #-20000,R2 ;ADRES THE NXT DRIVE IN THE
5160 ;REVERSE ORDER. I.E. 7,6,...
5161 016000 001366 BNE 1$ ;LUP BAK & TRY TO FIND A DRIVE
5162 ;THAT'S NOT PRESENT
5163 016002 000435 BR TST45 ;EXIT TO THE NXT TST
5164 ;*****
5165 016004 012710 000015 2$: MOV #15,@R0 ;DRIVE RESET, ON A NX DRIVE
5166 016010 104417 000106 DELAY ,106 ;TIME DELAY, 525 US ON 11/20
5167 ;105 US ON 11/45
5168 016014 105777 163310 TSTB @RKER ;DID NXD BIT IN RKER SET?
5169 016020 001006 BNE 3$ ;YES, BRANCH
5170 016022 004737 021010 JSR PC,GT2RG ;GET RKCS, RKER
5171 016026 012737 000200 001166 MOV #200,$REG2 ;THIS BIT (NXD) IN RKER DID NOT SET
5172 016034 104105 ERROR 105 ;NXD BIT DID NOT SET ON TRYING
5173 ;TO PERFORM A FUNCTION ON A

```

```

5174 ;NON-EXISTENT DRIVE
5175 ;CHECK THAT THE JUMPER CARD CONTAINING
5176 ;JUMPERS FOR DRIVES PRESENT IS PROPERLY
5177 ;CONNECTED
5178 ;NOTE THAT ON RK11C IF A DRIVE
5179 ;IS OFFLINE BUT PHYSICALLY PRESENT
5180 ;(IE. DRY IS CLR FOR THAT DRIVE)
5181 ;& A FUNCTION IS INITIATED ON THAT
5182 ;DRIVE NXD WON'T SET, BUT U WILL
5183 ;GET ONLY A DRE,HE & ERR.
5184 016036 022710 140214 3$: CMP #140214,@R0 ;DID HE & ERR SET WHEN NXD SET?
5185 016042 001403 BEQ 4$ ;YES BRANCH
5186 016044 004737 021010 JSR PC,GT2RG ;HE OR ERR BIT DID NOT SET
5187 016050 104106 ERROR 106 ;WHEN NXD WAS SIMULATED
5188 ;CLEAR NXD, HE, ERR BITS
5189 016052 104413 4$: CNT.RESET ;GO, DO CONTROL RESET
5190 ;THIS IS A CALL FOR THE 'CNTRL-
5191 ;RESET' ROUTINE. A CONTROL RESET IS
5192 ;ISSUED AND AFTER A CERTAIN TIME
5193 ;IF THE 'CNTRL RDY' DOES NOT SET
5194 ;AN ERROR IS REPORTED. NOTE THAT
5195 ;THE PC IN ERROR MESSAGE IS THE
5196 ;PC WHERE 'CNT.RESET' IS LOCATED.
5197 ;THIS IS A VERY BASIC ERR& IF IT
5198 ;OCCURS GO BACK TO TEST 10
5199 016054 004737 021356 JSR PC,CHKECLR ;CHECK IF 'NXD' BIT WAS CLEARED BY
5200 ;CON.RESET. IF NOT, RETURN HERE.
5201 016060 104102 ERROR 102 ;CNTRL RESET DID NOT CLEAR
5202 ;NXD BIT IN RKER
5203 016062 004737 021402 5$: JSR PC,CHKCCLR ;CHECK IF 'HE' & 'ERR' BITS WERE CLEARED
5204 ;BY CON.RESET. IF NOT RETURN HERE.
5205 016066 104102 ERROR 102 ;CNTRL RESET DID NOT CLEAR
5206 ;HE OR ERR BIT IN RKCS
5207 016070 004737 021436 JSR PC,TSTRWS ;GO CHECK & WAIT FOR R/W/S RDY
5208 ;TO SET. IF SET SKIP ERROR
5209 016074 104016 ERROR 16 ;R/W/S SHOULD BE SET. IT'S
5210 ;NOT
5211
5212 ;*****
5213 ;*TEST 45 SIMULATE & CHECK NXC ERROR
5214 ;*THIS TEST SIMULATES THE NON-EXISTENT CYLINDER ERROR & CHECKS
5215 ;*IF IT IS DETECTED BY THE NXC BIT OF RKER, HE & ERR BITS
5216 ;*OF RKCS. IT IS CHECKED IF THEY CAN BE CLEARED BY CONTROL
5217 ;*RESET
5218 ;*****
5219 016076 000004 TST45: SCOPE
5220 016100 013700 MOV RKCS,R0
5221 016104 012737 177773 001362 2$: MOV #-5,COUNT ;ALLOW 'ERROR 133' ONLY 5 TIMES
5222 016112 013702 001350 MOV DRIVAD,R2 ;GET ADRES OF DRIVE
5223 016116 052702 014540 BIS #14540,R2 ;SET BITS FOR CYL 313
5224 016122 012737 016130 001110 MOV #3$,$LPERR ;SET RETURN ADRES FOR
5225 ;LUPING ON EROR (SW9)
5226 016130 104413 3$: CNT.RESET ;GO, DO CONTROL RESET
5227 ;THIS IS A CALL FOR THE 'CNTRL-
5228 ;RESET' ROUTINE. A CONTROL RESET IS
5229 ;ISSUED AND AFTER A CERTAIN TIME

```

```

5230 ;IF THE 'CNTRL RDY' DOES NOT SET
5231 ;AN ERROR IS REPORTED. NOTE THAT
5232 ;THE PC IN ERROR MESSAGE IS THE
5233 ;PC WHERE 'CNT.RESET' IS LOCATED.
5234 ;THIS IS A VERY BASIC ERR& IF IT
5235 ;OCCURS GO BACK TO TEST 10
5236 016132 004737 021436 JSR PC,TSTRWS ;GO CHECK & WAIT FOR R/W/S RDY
5237 ;TO SET. IF SET SKIP ERROR BELOW
5238 016136 104016 ERROR 16 ;R/W/S RDY IS NOT SET
5239 016140 104421 TST.SIN ;CHECK IF SIN IS SET. IF SET
5240 ;DO DRIVE RESET TO CLR IT
5241 016142 010277 163172 MOV R2,@RKDA ;ADRES DRIVE, NXC CYLINDER
5242 016146 012710 000011 MOV #11,@R0 ;SEEK, GO TO NXC CYL
5243 016152 104412 CHKCRDY ;GO CHECK IF CONTROL RDY IS SET
5244 ;IF SO, SKIP THE EROR MESSAGE.
5245 016154 104021 ERROR 21 ;SEEK WAS TRIED TO A NON EXISTENT
5246 ;CYLINDER. NXC SHOULD HAVE OCCURED
5247 ;SETTING CNTRL RDY. BUT CNTRL RDY
5248 ;DID NOT SET.
5249 016156 032777 000100 163144 9$: BIT #100,@RKER ;DID NXC SET?
5250 016164 001020 BNE 4$ ;YES, BRANCH
5251 016166 004737 021010 JSR PC,GT2RG ;GO GET RKCS, ER
5252 016172 017737 163142 001166 MOV @RKDA,$REG2 ;GET RKDA
5253 016200 104110 ERROR 110 ;NXC DID NOT SET WHEN SEEK
5254 ;WAS TRIED TO CYLINDER AS INDICATED
5255 ;IN RKDA
5256 016202 004737 021436 JSR PC,TSTRWS ;CHECK & WAIT FOR R/W/S RDY,
5257 ;IF SET SKIP ERROR
5258 016206 104016 ERROR 16 ;R/W/S SHOULD BE SET
5259 016210 104413 CNT.RESET ;GO DO CONTROL RESET
5260 016212 004737 021504 JSR PC,DRESET ;GO DO DRIVE RESET
5261 016216 104026 ERROR 26 ;NXC DID NOT SET AND DRIVE MAY
5262 ;HAVE TRIED TO DO A SEEK, AFTER
5263 ;WHICH R/W/S RDY DID NOT SET
5264 016220 005237 001362 INC COUNT ;ALLOW ONLY 5 MESSAGES FOR
5265 016224 001405 BEQ 5$ ;ERROR 133
5266 016226 062702 000040 4$: ADD #40,R2 ;ADRES THE NXT CYL(IN NON-EXISTENT ZONE)
5267 016232 032702 017740 BIT #17740,R2 ;CHKD FOR ALL NXC'S?
5268 016236 001334 BNE 3$ ;IF NOT, LUP BAK & CHK THE NXT NXC
5269
5270 016240 032710 140000 5$: BIT #140000,@R0 ;DID HE & ERR BIT SET WHEN NXC BIT SET?
5271 016244 001003 BNE 6$ ;YES, BRANCH
5272 016246 004737 021010 JSR PC,GT2RG ;GET RKCS, ER
5273 016252 104106 ERROR 106 ;HE OR ERR BIT DID NOT SET IN RKCS
5274 ;WHEN NXC ERROR WAS SIMULATED
5275 ;CLEAR HE, ERR, NXC BITS
5276 016254 104413 6$: CNT.RESET ;GO, DO CONTROL RESET
5277 ;THIS IS A CALL FOR THE 'CNTRL-
5278 ;RESET' ROUTINE. A CONTROL RESET IS
5279 ;ISSUED AND AFTER A CERTAIN TIME
5280 ;IF THE 'CNTRL RDY' DOES NOT SET
5281 ;AN ERROR IS REPORTED. NOTE THAT
5282 ;THE PC IN ERROR MESSAGE IS THE
5283 ;PC WHERE 'CNT.RESET' IS LOCATED.
5284 ;THIS IS A VERY BASIC ERR& IF IT
5285 ;OCCURS GO BACK TO TEST 10

```



```

5286 016256 004737 021356 JSR PC,CHKECLR ;CHECK IF 'NXC' BIT WAS CLEARED BY
5287 ;CON.RESET. IF NOT, RETURN HERE.
5288 016262 104102 ERROR 102 ;CNTRL RESET DID NOT CLEAR
5289 ;NXC BIT IN RKER.
5290 016264 032710 140000 7$: BIT #140000,@R0 ;DID HE & ERR BITS GET CLEARED?
5291 016270 001405 BEQ TST46 ;:YES, E.A.T
5292 016272 010037 001162 MOV R0,$REG0 ;GET ADRES OF RKCS
5293 016276 011037 001164 MOV @R0,$REG1 ;GET RKCS CONTENTS
5294 016302 104102 ERROR 102 ;CNTRL RESET DID NOT CLEAR
5295 ;HE OR ERR BIT IN RKCS
5296
5297 ;*****
5298 ;*TEST 46 SIMULATE & CHECK NXS ERROR
5299 ;*THIS TEST SIMULATES NON-EXISTENT SECTOR ERROR & CHECKS THAT
5300 ;*IT IS DETECTED BY NXS BIT OF RKER. IT IS CHECKED THAT
5301 ;*WHEN NXS SETS HE & ERR OF RKER ALSO SETS, AND ALL THREE
5302 ;*CAN BE CLEARED BY CONTROL RESET.
5303 ;*****
5304 016304 000004 TST46: SCOPE
5305 016306 104413 CNT.RESET ;GO, DO CONTROL RESET
5306 ;THIS IS A CALL FOR THE 'CNTRL-
5307 ;RESET' ROUTINE. A CONTROL RESET IS
5308 ;ISSUED AND AFTER A CERTAIN TIME
5309 ;IF THE 'CNTRL RDY' DOES NOT SET
5310 ;AN ERROR IS REPORTED. NOTE THAT
5311 ;THE PC IN ERROR MESSAGE IS THE
5312 ;PC WHERE 'CNT.RESET' IS LOCATED.
5313 ;THIS IS A VERY BASIC ERR& IF IT
5314 ;OCCURS GO BACK TO TEST 10
5315 016310 013700 001332 MOV RKCS,R0 ;GET ADRES OF DRIVE
5316 016314 013777 001350 163016 MOV DRIVAD,@RKDA ;SET BITS FOR SECTOR 12 (DECIMAL)
5317 016322 052777 000014 163016 BIS #14,@RKDA ;READ 1 WORD
5318 016330 012777 177777 162776 MOV #-1,@RKWC ;INTO THIS BUS ADRES
5319 016336 012777 033342 162772 MOV #OUTBUF,@RKBA ;READ. GO (FROM NX SECTOR)
5320 016344 012710 000005 MOV #5,@R0 ;THIS IS A CALL FOR 'CN.RDY'
5321 016350 104414 CNT.RDY ;ROUTINE WHICH WAITS FOR CNT
5322 ;RDY TO SET. IF CNTRL RDY DOES
5323 ;NOT SET WITHIN 883 MS/ 11-20
5324 ;(176 MS FOR 11-45 WITH BIPOLAR)
5325 ;AN ERROR IS REPORTED
5326 ;NXS ERROR SHOULD OCCUR NOW
5327
5328 016352 017702 162752 MOV @RKER,R2 ;DID NXS BIT SET IN RKER?
5329 016356 032702 000040 BIT #40,R2 ;YES, BRANCH
5330 016362 001006 BNE 1$ ;GO GET RKCS, RKER
5331 016364 004737 021010 JSR PC,GT2RG ;THIS BIT (NXS) IN RKER DID NOT SET
5332 016370 012737 000040 001166 MOV #40,$REG2 ;NXS BIT DID NOT SET ON SIMULATING
5333 016376 104105 ERROR 105 ;NXS ERROR
5334 ;MASK NXS BIT
5335 016400 042702 000040 1$: BIC #40,R2 ;CHECK IF ANY OTHER
5336 016404 001407 BEQ 2$ ;RKER BIT SET
5337 ;GET EXPCD RKER
5338 016406 012737 000040 001167 MOV #40,$REG0 ;GET RKER RCVD
5339 016414 017737 162710 001164 MOV @RKER,$REG1 ;ONLY 'NXS' SHOULD BE SET
5340 016422 104107 ERROR 107 ;IN RKER, ANOTHER RKER BIT
5341

```

```

5342 ;WAS SET. (NOTE 'NXS' WAS
5343 ;SIMULATED)
5344 016424 022710 140204 2$: CMP #140204,@R0 ;DID HE & ERR BITS SET?
5345 016430 001403 BEQ 3$ ;YES, BRANCH
5346 016432 004737 021010 JSR PC,GT2RG ;GO GET RKCS, RKER
5347 016436 104106 ERROR 106 ;HE OR ERR BIT DID NOT SET WHEN
5348 ;NXS ERROR OCCURED
5349 ;CLEAR NXS, HE, ERR BITS
5350 016440 104413 3$: CNT.RESET ;GO, DO CONTROL RESET
5351 ;THIS IS A CALL FOR THE 'CNTRL-
5352 ;RESET' ROUTINE. A CONTROL RESET IS
5353 ;ISSUED AND AFTER A CERTAIN TIME
5354 ;IF THE 'CNTRL RDY' DOES NOT SET
5355 ;AN ERROR IS REPORTED. NOTE THAT
5356 ;THE PC IN ERROR MESSAGE IS THE
5357 ;PC WHERE 'CNT.RESET' IS LOCATED.
5358 ;THIS IS A VERY BASIC ERR& IF IT
5359 ;OCCURS GO BACK TO TEST 10
5360 016442 004737 021356 JSR PC,CHKECLR ;CHECK IF 'NXS' BIT WAS CLEARED BY
5361 ;CON.RESET. IF NOT, RETURN HERE.
5362 016446 104102 ERROR 102 ;CNTRL RESET DID NOT CLEAR
5363 ;NXS BIT IN RKER
5364 016450 004737 021402 4$: JSR PC,CHKCCLR ;CHECK IF 'HE' & 'ERR' BITS WERE CLEARED
5365 ;BY CON.RESET. IF NOT, RETURN HERE.
5366 016454 104102 ERROR 102 ;RKCS BITS ERR OR HE WERE NOT
5367 ;CLEARED BY CNTRL RESET
5368
5369 ;*****
5370 ;*TEST 47 SIMULATE & CHECK WCE
5371 ;*THIS TEST SIMULATES A WRITE CHECK ERROR AND CHECKS THAT IT
5372 ;*IS DETECTED BY WCE BIT OF RKER. FOR COMPARISON IT USES
5373 ;*THE 256 WORDS DATA BLOCK WRITTEN ON SECTOR 0, CYLINDER 0
5374 ;*IN A PREVIOUS TEST. THIS BLOCK IS COMPARED WITH THE 256 WORDS
5375 ;*MEMORY BUFFER STARTING AT 'OUTBUF'. WCE IS SIMULATED BY
5376 ;*DROPPING A BIT FROM ONE OF THE WORDS IN THE MEMORY BUFFER.
5377 ;*****
5378 016456 000004 TST47: SCOPE
5379 016460 013700 001332 MOV RKCS,R0 ;GO, DO CONTROL RESET
5380 016464 104413 CNT.RESET ;THIS IS A CALL FOR THE 'CNTRL-
5381 ;RESET' ROUTINE. A CONTROL RESET IS
5382 ;ISSUED AND AFTER A CERTAIN TIME
5383 ;IF THE 'CNTRL RDY' DOES NOT SET
5384 ;AN ERROR IS REPORTED. NOTE THAT
5385 ;THE PC IN ERROR MESSAGE IS THE
5386 ;PC WHERE 'CNT.RESET' IS LOCATED.
5387 ;THIS IS A VERY BASIC ERR& IF IT
5388 ;OCCURS GO BACK TO TEST 10
5389 ;CHECK IF SIN IS SET. IF
5390 016466 104421 TST.SIN ;SET DO DRV-RESET TO CLR IT
5391 ;THIS CODE SETS UP A MEMORY
5392 016470 012701 033342 MOV #OUTBUF,R1 ;BUFFER OF 256 WORDS STARTING
5393 016474 012702 177400 MOV #-400,R2 ;AT OUTBUF
5394 016500 012703 177777 MOV #177777,R3 ;FIRST WORD 177400
5395 ;SECOND 177001
5396
5397 016504 062703 177401 1$: ADD #177401,R3

```

```

5398 016510 010321      MOV      R3,(R1)+      ;LAST WORD 000377
5399 016512 005202      INC      R2            ;HAVE U GENERATED ALL 256 WORDS?
5400 016514 001373      BNE     1$            ;IF NOT, LUP BAK & GENERATE NXT
5401
5402 016516 012737 170007 033360      MOV      #170007,OUTBUF+16 ;WCE WILL B SIMULATED BY DROPPING A
5403                                     ;BIT IN THE EIGHTH WORD WHICH IS
5404                                     ;SUPPOSED TO B 174007
5405 016524 012777 177400 162602      MOV      #-400,@RKWC    ;WRT CHK 400 WORDS
5406 016532 012777 033342 162576      MOV      #OUTBUF,@RKBA ;STARTING AT THIS BUS ADRES
5407 016540 013777 001350 162572      MOV      DRIVAD,@RKDA  ;WITH THIS DISK ADRES, SEC 0, CYL 0
5408 016546 012710 000007      MOV      #7,@R0        ;WRT CHK, GO
5409
5410 016552 104412      CHKCRDY                ;GO CHECK IF CONTROL RDY IS SET
5411                                     ;IF SO, SKIP THE EROR MESSAGE.
5412 016554 104065      ERROR   65            ;CNTRL RDY DID NOT SET
5413                                     ;AFTER WRT CHK
5414                                     ;DID WCE BIT SET?
5414 016556 032777 000001 162544 3$:   BIT      #1,@RKER
5415 016564 001006      BNE     4$            ;GO, GET RKCS, RKER
5416 016566 004737 021010      JSR     PC,GT2RG      ;THIS BIT (WCE) DID NOT SET
5417 016572 012737 000001 001166      MOV      #1,$REG2     ;WCE DID NOT SET ON SIMULATING
5418 016600 104105      ERROR   105          ;WCE CONDITIONS
5419                                     ;IS RKCS CORRECT?
5420 016602 022710 100206      4$:   CMP      #100206,@R0 ;YES, BRANCH
5421 016606 001403      BEQ     5$            ;GO, GET RKCS, RKER
5422 016610 004737 021010      JSR     PC,GT2RG      ;HE DR EROR BIT DID NOT SET WHEN
5423 016614 104106      ERROR   106          ;WCE WAS SIMULATED
5424                                     ;CNTRL RESET
5425 016616 104413      5$:   CNT.RESET
5426 016620 004737 021356      JSR     PC,CHKCECLR   ;WAS 'WCE' BIT CLEARED?
5427                                     ;IF NOT, RETURN HERE.
5428 016624 104102      ERROR   102          ;CNTRL RESET DID NOT CLEAR
5429                                     ;WCE BIT IN RKER
5430 016626 004737 021402      6$:   JSR     PC,CHKCCLR   ;CHECK IF 'ERR' BIT WAS CLEARED. IF
5431                                     ;NOT RETURN HERE.
5432 016632 104102      ERROR   102          ;CNTRL RESET DID NOT CLEAR
5433                                     ;RKCS
5434
5435 ;*****
5436 ;*TEST 50 CHECK THAT SSE STOPS ALL CONTROL ACTION ON SOFT ERROR
5437 ;*THIS TEST CHECKS THAT WHEN 'STOP ON SOFT ERROR' BIT IS SET IN
5438 ;*RKCS AND A SOFT ERROR IS ENCOUNTERED ALL CONTROL ACTION WILL
5439 ;*STOP AT THE END OF THE CURRENT SECTOR IF IDE BIT IS CLEAR.
5440 ;*SOFT ERROR IS SIMULATED BY A WCE AS IN THE PREVIOUS
5441 ;*TEST. THE PREVIOUS TEST & THE TEST WHICH WRITES DATA
5442 ;*BLOCK ON CYLINDER 0, SECTOR 0, SHOULD BE DONE PRIOR
5443 ;*TO THIS TEST. A TWO SECTOR 'WRT CHK' WILL BE DONE.
5444 ;*CONTROL ACTION SHOULD STOP AFTER THE FIRST SECTOR DURING
5445 ;*WHICH A SOFT ERROR IS SIMULATED.
5446 ;*****
5447 016634 000004      TST50: SCOPE
5448 016636 104413      CNT.RESET            ;GO, DO CONTROL RESET
5449                                     ;THIS IS A CALL FOR THE 'CNTRL-
5450                                     ;RESET' ROUTINE. A CONTROL RESET IS
5451                                     ;ISSUED AND AFTER A CERTAIN TIME
5452                                     ;IF THE 'CNTRL RDY' DOES NOT SET
5453                                     ;AN ERROR IS REPORTED. NOTE THAT

```

```

5454                                     ;THE PC IN ERROR MESSAGE IS THE
5455                                     ;PC WHERE 'CNT.RESET' IS LOCATED.
5456                                     ;THIS IS A VERY BASIC ERR& IF IT
5457                                     ;OCCURS GO BACK TO TEST 10
5458 016640 104421      TST.SIN                ;CHECK IF SIN IS SET, IF
5459                                     ;SET DO 'DRIVE RESET TO CLR IT
5460 016642 013700 001332      MOV      RKCS,R0
5461 016646 012737 170007 033360      MOV      #170007,OUTBUF+16 ;WCE IS SIMULATED BY DROPPING A BIT
5462                                     ;IN THE EIGHTH WORD (WHICH IS ACTUALLY
5463                                     ;174007). NOTE THAT 256 WORD MEMORY
5464                                     ;BUFFER IS CREATED IN THE PREVIOUS TEST.
5465 016654 013701 001350      MOV      DRIVAD,R1
5466 016660 012777 177000 162446      MOV      #-1000,@RKWC ;WRT CHK 1000 (OCTAL) WORDS, 2 SECTORS
5467 016666 012777 033342 162442      MOV      #OUTBUF,@RKBA ;FROM THIS BUS ADRES
5468 016674 010177 162440      MOV      R1,@RKDA     ;WITH THIS DISK ADRES, SEC 0, CYL 0
5469 016700 012710 000407      MOV      #407,@R0    ;WRT CHK, GO, SSE
5470 016704 104412      CHKCRDY                ;GO CHECK IF CONTROL RDY IS SET
5471                                     ;IF SO, SKIP THE EROR MESSAGE.
5472 016706 104065      ERROR   65            ;CNTRL RDY DID NOT SET AFTER WRT
5473                                     ;CHK. A SOFT ERROR (WCE) IN
5474                                     ;SECTOR 0 SHOULD HAVE STOPPED
5475                                     ;ALL CONTROL ACTION.
5476 016710 022777 000001 162412 2$:   CMP      #1,@RKER
5477                                     ;CHECK ONLY 'WCE' BIT SHOULD
5478                                     ;BE SET?
5479 016716 001407      BEQ     3$            ;YES, BRANCH
5480 016720 012737 000001 001162      MOV      #1,$REG0     ;GET EXPCTD RKER
5481 016726 017737 162376 001164      MOV      @RKER,$REG1 ;GET RKER RECVD
5482 016734 104107      ERROR   107          ;ONLY BIT 'WCE' OF RKER
5483                                     ;SHOULD BE SET (WCE WAS
5484                                     ;SIMULATED ABOVE). ERROR
5485                                     ;IF IT'S NOT
5486 016736 005201      3$:   INC      R1            ;CHECK THAT RKDA INCREMENTED BY
5487 016740 020177 162374      CMP      R1,@RKDA     ;1 SECTOR ONLY IMPLYING THAT
5488                                     ;CNTRL ACTION DID STOP AFTE..
5489                                     ;SOFT ERROR IN SECTOR 0
5490 016744 001406      BEQ     TST51         ;YES, EXIT
5491 016746 010137 001162      MOV      R1,$REG0     ;GET EXPCTD RKDA
5492 016752 017737 162362 001164      MOV      @RKDA,$REG1 ;GET RKDA RECVD
5493 016760 104070      ERROR   70            ;RKDA SHOULD HAVE INCRMNTD
5494                                     ;BY 1 SECTOR ONLY. IT DIDN'T.
5495                                     ;WCE WAS SIMULATED IN THE
5496                                     ;FIRST SECTOR & A WRT CHK
5497                                     ;OF 2 SECTORS WAS ISSUED.
5498                                     ;CONTROLLER SHOULD STOP AFTER
5499                                     ;DETECTING WCE IN THE FIRST
5500                                     ;SECTOR. HENCE RKDA SHOULD
5501                                     ;INCREMENT BY 1 SECTOR ONLY
5502
5503 ;*****
5504 ;*TEST 51 CHECK THAT RK11 INTERRUPTS ON SOFT ERROR WHEN SSE & IDE ARE SET
5505 ;*THIS TEST CHECKS WHEN SSE BIT IS SET WITH IDE SET AND A SOFT
5506 ;*ERROR OCCURS, THEN ALL CONTROL ACTION WILL STOP AND A BUS
5507 ;*REQUEST (INTERRUPT) WILL OCCUR AT THE END OF THE CURRENT
5508 ;*SECTOR. SOFT ERROR IS SIMULATED BY WCE AS IN PREVIOUS
5509 ;*TEST. PREREQUISITES FOR THIS TEST ARE THE SAME AS THOSE

```

```

5510 ;*FOR THE PREVIOUS TEST.
5511 ;*****
5512 016762 000004 TST51: SCOPE
5513 016764 104413 CNT.RESET ;GO, DO CONTROL RESET
5514 ;THIS IS A CALL FOR THE 'CNTRL-
5515 ;RESET' ROUTINE. A CONTROL RESET IS
5516 ;ISSUED AND AFTER A CERTAIN TIME
5517 ;IF THE 'CNTRL RDY' DOES NOT SET
5518 ;AN ERROR IS REPORTED. NOTE THAT
5519 ;THE PC IN ERROR MESSAGE IS THE
5520 ;PC WHERE 'CNT.RESET' IS LOCATED.
5521 ;THIS IS A VERY BASIC ERR& IF IT
5522 ;OCCURS GO BACK TO TEST 10
5523 016766 104421 TST.SIN ;CHECK IF SIN IS SET, IF
5524 ;SET DO DRIVE RESET TO CLR IT
5525 016770 012737 170007 033360 MOV #170007,OUTBUF+16 ;WCE IS SIMULATED BY DROPPING A BIT
5526 ;IN THE EIGHTH WORD (WHICH IS 174007)
5527 ;NGTE THAT THE 256 WORD MEMORY
5528 ;BUFFER (STARTING AT OUTBUF) IS
5529 ;CREATED IN A PREVIOUS TEST.
5530 016776 013701 001350 MOV DRIVAD,R1
5531 017002 012777 177000 162324 MOV #-1000,@RKWC ;WRT CHK 1000 (OCTAL) WORDS, 2 SECTORS
5532 017010 012777 033342 162320 MOV #OUTBUF,@RKBA ;FROM THIS BUS ADRES
5533 017016 010177 162316 MOV R1,@RKDA ;WITH THIS DISK ADRES, SEC 0, CYL 0
5534 017022 013700 001402 MOV RKVEC,R0
5535 017026 012720 017060 MOV #1$,@R0+ ;SET UP INTERRUPT VECTOR FOR RK11
5536 017032 012710 000340 MOV #340,@R0 ;SET PSW ON INTERRUPT
5537 017036 012777 000507 162266 MOV #507,@RKCS ;WRT CHK, GO, SSE, IDE SET
5538 017044 104420 177777 WAT.INT,177777 ;WAIT FOR INTERRUPT FROM RK11
5539 ;TIME=485 MS FOR 11/20,
5540 ;97 MS FOR 11/45
5541 017050 004737 021010 JSR PC,GT2RG ; ;11/05
5542 017054 104111 ERROR 111 ;RK11 DID NOT INTERRUPT AFTER A SOFT
5543 ;ERROR (SIMULATED) IN SECTOR 0
5544 017056 000417 BR 2$
5545
5546 017060 022626 1$: CMP (SP)+,(SP)+ ;RESTORE STACK POINTER (FROM RK11 INTRUPT)
5547 017062 022626 CMP (SP)+,(SP)+ ;POP STACK (FROM WAT.INT)
5548 017064 012777 004600 162310 MOV #BADINT,@RKVEC ;RESTORE RK11 INTERRUPT VECTOR
5549 ;ADRES FOR UNEXPECTED INTERRUPTS
5550 017072 005201 INC R1
5551 017074 020177 162240 CMP R1,@RKDA ;CHECK THAT RKDA INCREMENTED
5552 ;BY ONLY 1 SECTOR BEFORE INTERRUPT
5553 ;OCCURRED
5554 017100 001406 BEQ 2$
5555 017102 010137 001162 MOV R1,$REG0 ;GET EXPCTD RKDA
5556 017106 017737 162226 001164 MOV @RKDA,$REG1 ;GET RKDA RECVD
5557 017114 104003 ERROR 3 ;RKDA SHOULD HAVE INCREMENTED BY
5558 ;1 SECTOR ONLY, IF ALL CNTRL ACTION
5559 ;HAD STOPPED AFTER SOFT ERROR
5560 ;:(SIMULATED) IN SECTOR 0. IT DID NOT.
5561 017116 2$:
5562 017116 012746 000340 MOV #340,-(SP)
5563 017122 012746 017130 MOV #64$,-(SP)
5564 017126 000002 RTI
5565 017130 64$:

```

```

5566 017130 005077 162176 CLR @RKCS ;CLEAR THE IDE BIT
5567
5568
5569 ;*****
5570 ;*TEST 52 CHECK THE MEX BITS IN RKCS
5571 ;*THIS TEST CHECKS OUT THE EXTENDED MEMORY BITS OF THE RKCS.
5572 ;*THE RKBA IS SET TO 177776 AND A ONE WORD WRITE CHECK IS TRIED.
5573 ;*THIS COULD GIVE RISE TO NXM ERROR, BUT EVEN THEN THE RKBA
5574 ;*SHOULD OVERFLOW INTO THE MEX BITS. SIMILIARLY IT IS CHECKED
5575 ;*THAT THE OVERFLOWING BIT CAN MAKE THE MEX BITS COUNT
5576 ;*01,10,11,00.
5577 ;*****
5578 017134 000004 TST52: SCOPE
5579 017136 013700 001332 MOV RKCS,R0
5580 017142 012701 177774 MOV #-4,R1 ;SET UP THE COUNT
5581 017146 005002 CLR R2 ;INITIALIZE MEX BITS TO B SET IN RKCS
5582 017150 012737 017156 001110 MOV #1$,SLPERR ;SET RETURN ADRES FOR
5583 ;LUPING ON EROR (SW9)
5584 017156 104417 000142 1$: DELAY ,142 ;TIME DELAY
5585 017162 004737 021436 JSR PC,TSTRWS ;WAIT FOR R/W/S RDY
5586 017166 104016 ERROR 16 ;R/W/S RDY IS NOT SET
5587 017170 104413 CNT.RESET ;GO, DO CONTROL RESET
5588 ;THIS IS A CALL FOR THE 'CNTRL-
5589 ;RESET' ROUTINE. A CONTROL RESET IS
5590 ;ISSUED AND AFTER A CERTAIN TIME
5591 ;IF THE 'CNTRL RDY' DOES NOT SET
5592 ;AN ERROR IS REPORTED. NOTE THAT
5593 ;THE PC IN ERROR MESSAGE IS THE
5594 ;PC WHERE 'CNT.RESET' IS LOCATED.
5595 ;THIS IS A VERY BASIC ERR& IF IT
5596 ;OCCURS GO BACK TO TEST 10
5597 017172 010210 MOV R2,@R0 ;SET MEX BITS (AS IN R2) IN RKCS
5598 017174 012777 177777 162132 MOV #-1,@RKWC ;WRT CHK 1 WORD
5599 017202 013777 001350 162130 MOV DRIVAD,@RKDA ;THIS DISK ADRES, SEC 0, CYL 0
5600 017210 012777 177776 162120 MOV #177776,@RKBA ;THIS BUS ADRES. NOTE THIS BA
5601 ;IN CONJUNCTION WITH MEX BITS OF RKCS
5602 017216 052710 000007 BIS #7,@R0 ;WRT CHK, GO
5603 ;THERE MAY BE A NXM OR WCE BUT
5604 ;WHATEVER THE CASE RKBA SHOULD
5605 ;OVERFLOW MAKING THE MEX BITS COUNT
5606 017222 104412 CHKCRDY ;GO CHECK IF CONTROL RDY IS SET
5607 ;IF SO, SKIP THE EROR MESSAGE.
5608 017224 104065 ERROR 65 ;CNTRL RDY DID NOT SET AFTER WRT CHK
5609 017226 010205 3$: MOV R2,R5
5610 017230 062705 000020 ADD #20,R5 ;MEX BITS SHOULD INCREMENT BY 1 TO THIS
5611 017234 042705 000100 BIC #100,R5 ;MASK OUT IDE BIT POSITION, IF SET
5612 017240 011004 MOV @R0,R4 ;GET RKCS
5613 017242 042704 177717 BIC #177717,R4 ;MASK OUT ALL BITS EXCEPT MEX
5614 017246 020504 CMP R5,R4 ;DID MEX BITS INCREMENT CORRECTLY?
5615 017250 001405 BEQ 4$ ;YES, BRANCH
5616 017252 010537 001162 MOV R5,$REG0 ;GET EXPCTD MEX BITS
5617 017256 010437 001164 MOV R4,$REG1 ;GET MEX BITS RECVD
5618 017262 104112 ERROR 112 ;MEX BITS DID NOT INCREMENT AS
5619 ;'EXPCTD' WHEN RKBA OVERFLOW'ED.
5620 ;NOTE THAT BIT POSITION 4 & 5
5621 ;REFLECT MEX BITS 0 & 1 IN THE

```

```

5622          017264 017703 162040          4S:  MOV  @RKER,R3      ;ERROR MESSAGE.
5623          017270 010305                    MOV  R3,R5          ;GET RKER
5624          017272 042703 003001          BIC  #3001,R3      ;MASK WCE,DLT,NXM BIT, IF SET
5625          017276 001410                    BEQ  5S            ;BRANCH IF REST OF RKER CLR
5626          017300 042705 177776          BIC  #17776,R5    ;MASK NON-WCE BITS
5627          017304 010537 001162          MOV  R5,$REG0     ;THIS IS THE EXPCTD RKER
5628          017310 017737 162014 001164    MOV  @RKER,$REG1  ;GET RKER RECVD
5629          017316 104107                    ERROR 107         ;ERROR IN RKER. IT SHOULD
5630          ;BE AS EXPECTED IN
5631          ;ERROR MESSAGE
5632          017320 062702 000020          5S:  ADD  #20,R2     ;INCREMENT TO NXT MEX BIT
5633          017324 005201                    INC  R1           ;HAVE U CHKD THE MEX BITS 4 TIMES?
5634          017326 001313                    BNE  1$         ;IF NOT, LUP BACK
5635
5636          ;*****
5637          ;*TEST 53 TRANSFER FROM DISK TO TTY
5638          ;* THIS TEST CHECKS THE HIGH ORDER BITS OF THE ADDRESS
5639          ;* LINES. FIRST A ONE WORD (100) IS WRITTEN ON SECTOR,
5640          ;* 2, CYL 0. THEN IT IS READ BACK, BUT THE NPR IS DONE
5641          ;* NOT TO THE MEMORY, BUT THE TELETYPE BUFFER (TKS 177560)
5642          ;* AND IT CHECKED THAT THE WORD WAS RECEIVED CORRECTLY.
5643          ;* IF IT IS NOT, AN ERROR IS REPORTED. THIS TEST IS
5644          ;* SKIPPED ON AN 11/05.
5645          ;*****
5646          TST53: SCOPE
5647          017330 000004          MOV  #1,$TIMES   ;;DO 1 ITERATION
5648          017332 012737 000001 001206    ;THIS CODE FINDS OUT IF THE CPU
5649          ;IS AN 11/05 OR ELSE.
5650          ;ON AN 11/05, R0 (177700) CAN BE
5651          ;ADDRESSED AS A MEMORY LOCATION, BUT
5652          ;ON ANY OTHER CPU IF 177700 IS REFERENCED
5653          ;A TIME OUT WILL OCCUR.
5654          ;SET UP TIME OUT VECTOR
5655          017340 012737 017362 000004    MOV  #55,@#4     ;REFERENCE R0
5656          017345 005737 177700          TST  @#177700    ;R0 WAS REFERENCED W/O TIMEOUT
5657          017352 012737 004534 000004    MOV  #BADTMO,@#4 ;HENCE 11/05
5658          ;SKIP THIS TEST
5659          017360 000520          BR   TST54      ;RESTORE STACK POINTER
5660          017362 022626          CMP  (SP)+,(SP)+ ;RESTORE TIMEOUT VECTOR
5661          017364 012737 004534 000004    MOV  #BADTMO,@#4
5662          017372 012746 000340          MOV  #340,-(SP)
5663          017376 012746 017404          MOV  #64$,-(SP)
5664          017402 000002          RTI
5665          64$:
5666          017404 013700 001332          MOV  RKCS,R0
5667          017410 104413          CNT.RESET
5668          ;GO, DO CONTROL RESET
5669          ;THIS IS A CALL FOR THE 'CNTRL-
5670          ;RESET' ROUTINE. A CONTROL RESET IS
5671          ;ISSUED AND AFTER A CERTAIN TIME
5672          ;IF THE 'CNTRL RDY' DOES NOT SET
5673          ;AN ERROR IS REPORTED. NOTE THAT
5674          ;THE PC IN ERROR MESSAGE IS THE
5675          ;PC WHERE 'CNT.RESET' IS LOCATED.
5676          ;THIS IS A VERY BASIC ERR& IF IT
5677          ;OCCURS GO BACK TO TEST 10
5677          017412 012701 033342          MOV  #OUTBUF,R1

```

```

5678          017416 013704 001336          MOV  RKBA,R4
5679          017422 012711 000100          MOV  #100,@R1   ;WRITE THIS WORD
5680          017426 012777 177777 161700    MOV  #-1,@RKWC  ;WRITE 1 WORD
5681          017434 013702 001350          MOV  DRIVAD,R2
5682          017440 052702 000002          BIS  #2,R2      ;ON CYL 0, SEC 2
5683          017444 010277 161670          MOV  R2,@RKDA
5684          017450 010114          MOV  R1,@R4    ;FROM THIS MEMORY LOC
5685          017452 012710 000003          MOV  #3,@R0    ;WRITE, GO
5686          017456 005003          CLR  R3
5687          017460 105710          1$: TSTB @R0
5688          017462 100410          BMI  2$
5689          017464 005203          INC  R3
5690          017466 001374          BNE  1$
5691          017470 004737 020774          JSR  PC,GT4RG  ;GET RKCS, ER, DS
5692          017474 010237 001202          MOV  R2,$REG10 ;GET THE STARTING ADRES
5693          017500 104416          BRKDA4          ;BREAK IT INTO DRV #, CYL, SUR, SEC #
5694          017502 104031          ERROR 31       ;CNTRL RDY DID NOT SET AFTER
5695          ;WRITE OF 1 WORD ON CYL 0, SEC 2
5696          017504 012777 177777 161622 2$: MOV  #-1,@RKWC ;READ 1 WORD
5697          017512 010277 161622          MOV  R2,@RKDA  ;FROM SEC 2, CYL 0
5698          017516 013714 001144          MOV  $TKS,@R4  ;INTO TTY STATUS REGISTER
5699          017522 005077 161416          CLR  @$TKS     ;CLEAR TTY KEY BRD STATUS REG
5700
5701          017526 012710 000065          MOV  #65,@R0   ;READ, MEX BITS SET
5702          017532 005003          CLR  R3
5703          017534 105710          3$: TSTB @R0
5704          017536 100410          BMI  4$
5705          017540 005203          INC  R3
5706          017542 001374          BNE  3$
5707          017544 004737 020774          JSR  PC,GT4RG  ;GET THE STARTING ADRES
5708          017550 010237 001202          MOV  R2,$REG10 ;BREAK IT INTO DR#, CYL, SUR, SEC#
5709          017554 104416          BRKDA4          ;CNTRL RDY DIDN'T SET AFTER
5710          017556 104045          ERROR 45       ;READ OF 1 WORD FROM CYL 0, SEC 2.
5711          ;IN EROR MSGE, <DSK-ADRES> GIVES
5712          ;ADRES WHERE READ BEGAN. 'RKDA'
5713          ;GIVES CONTENTS OF RKDA AT TIME OF ERROR
5714          ;WAS THE CORRECT WORD READ INTO
5715          ;THE TTY STATUS REGISTER?
5716          017560 032737 000100 001144 4$: BIT  #100,$TKS ;;YES. EXIT
5717          017566 001015          BNE  TST54
5718          017570 017705 161350          MOV  @$TKS,R5   ;GET THE WORD RECVD FROM DISK
5719          017574 010537 001164          MOV  R5,$REG1
5720          017600 052705 000100          BIS  #100,R5
5721          017604 010537 001162          MOV  R5,$REG0  ;THIS WORD WAS EXPCTD
5722          017610 011437 001166          MOV  @R4,$REG2 ;STORE EXPCTD WORD
5723          017614 011037 001170          MOV  @R0,$REG3 ;GET RKBA
5724          017620 104115          ERROR 115     ;GET RKC.
5725          ;DATA ERROR. A ONE WORD (100)
5726          ;NPR WAS TRIED FROM DISK TO
5727          ;TTY KEYBOARD STATUS REGISTER
5728          ;(17756) . BIT 6 SHOULD HAVE BEEN
5729          ;SET AS RESULT OF THIS
5730          ;BUT IT WAS NOT
5731
5732          ;*****
5733          ;*TEST 54 CHECK THAT RKBA CAN COUNT CORRECTLY

```

```

5734
5735
5736
5737
5738
5739
5740
5741
5742 017622 000004
5743 017624 012737 000005 001206
5744 017632 104421
5745 017634 005001
5746 017636 012702 000002
5747
5748 017642 012737 017654 001110
5749
5750
5751 017650 013705 001336
5752 017654 004737 021436 1$:
5753 017660 104016
5754 017662 104413
5755 017664 012777 177777 161442
5756 017672 010115
5757 017674 013777 001350 161436
5758 017702 012777 000067 161422
5759 017710 104412
5760
5761 017712 104065
5762
5763
5764
5765 017714 005237 001356
5766 017720 001417
5767
5768 017722 020215 3$:
5769
5770 017724 001410
5771 017726 010137 001162
5772 017732 011537 001164
5773 017736 104017
5774
5775
5776
5777
5778
5779
5780
5781 017740 005237 001360
5782 017744 001405
5783 017746 060201
5784 017750 010102
5785 017752 062702 000002
5786 017756 001336
5787
5788 017760 5$:
5789

```

```

5790
5791
5792
5793
5794
5795
5796
5797 017760 000004
5798 017762 012737 000001 001206
5799 017770 005737 001404
5800 017774 001403
5801 017776 004537 025160
5802 020002 104120
5803
5804 020004 1$:
5805
5806
5807
5808
5809
5810
5811
5812
5813
5814 020004 000004
5815 020006 012737 000001 001206
5816 020014 005237 001352
5817
5818 020020 004737 021504
5819 020024 104026
5820 020026 023737 001412 001352 BTEOP:
5821
5822 020034 001405
5823 020036 062737 020000 001350
5824 020044 000137 005040
5825
5826 020050 005037 001112 1$:
5827
5828
5829
5830
5831
5832
5833
5834
5835
5836
5837
5838
5839
5840
5841
5842
5843
5844
5845 020054 000004

```

```

5846 020056 012737 00005 001206 MOV #5,STIMES ;DO 5 ITERATIONS
5847 020064 005237 001440 INC SIZYET ;FOUNR RK05F YET?
5848 020070 001002 BNE 25$ ;YES
5849 020072 004737 025304 JSR PC,SIZEF ;FIND WHICH ARE RK-05F
5850 020076 005037 001436 25$: CLR PHYDRV ;NUMBER OF ACTUAL DRIVES
5851 020102 012700 001414 MOV #DRIVO,RO ;TABLE
5852 020106 005710 23$: TST (RO) ;DRIVE HERE+?
5853 020110 001405 BEQ 22$ ;NO
5854 020112 005237 001436 INC PHYDRV ;COUNT DRIVE
5855 020116 005710 TST (RO) ;RK05F?
5856 020120 100001 BPL 22$ ;NO
5857 020122 005720 TST (RO)+ ;DONT COUNT F TWICE
5858 020124 005720 22$: TST (RO)+ ;NEXT DRIVE
5859 020126 020027 001433 CMP RO,#DRIV7+1 ;ALL YET
5860 020132 002765 BLT 23$ ;NO
5861 020134 005037 001406 CLR ODDEVN ;EVEN DRIVES FIRST IF F
5862 020140 005737 001412 T56: TST DRIVS ;ANY DRIVES PRESENT?
5863 020144 001002 BNE 20$ ;YES
5864 020146 000137 020652 JMP SEOP ;NO
5865 020152 005237 001434 20$: INC TS6FLG
5866 020156 013700 001332 MOV RKCS,RO
5867 020162 005037 001356 CLR INDX1 ;FLAG TO INDICATE:
5868 ;(INDX1)=0 POLLING DONE AFTER ALL
5869 ;DRIVES SEEK TO CYL 0
5870 ;(INDX1)=1 POLLING DONE AFTER ALL
5871 ;DRIVES SEEK TO CYL 4
5872 020166 005037 001360 15$: CLR INDX2 ;FLAG INDICATING TYPE OF INTERRUPT
5873 ;SET TO NON-ZERO TO INDICATE
5874 ;THAT THE INTERRUPT IS DUE TO
5875 ;SEEK DONE
5876 020172 104413 CNT.RESET ;GO, DO CONTROL RESET
5877 ;THIS IS A CALL FOR THE 'CNTRL-
5878 ;RESET' ROUTINE. A CONTROL RESET IS
5879 ;ISSUED AND AFTER A CERTAIN TIME
5880 ;IF THE 'CNTRL RDY' DOES NOT SET
5881 ;AN ERROR IS REPORTED. NOTE THAT
5882 ;THE PC IN ERROR MESSAGE IS THE
5883 ;PC WHERE 'CNT.RESET' IS LOCATED.
5884 ;THIS IS A VERY BASIC ERR& IF IT
5885 ;OCCURS GO BACK TO TEST 10
5886 020174 005737 001356 TST INDX1 ;PERFORMING SEEKS TO CYL 4
5887 020200 001002 BNE .+6 ;YES, BRANCH
5888 020202 005002 CLR R2 ;NO
5889 020204 000402 BR .+6
5890 020206 012702 000200 MOV #200,R2 ;SET ADRES FOR FOURTH CYLINDER
5891 020212 012701 001414 MOV #DRIVO,R1 ;INITIALIZE POINTER
5892 020216 012703 177770 MOV #-10,R3 ;SET COUNT FOR 8 DRIVES
5893 020222 012705 033342 MOV #OUTBUF,R5 ;INITIALIZE POINTER TO INDICATOR AREA
5894 020226 005025 CLR (R5)+ ;CLEAR OUT THE 8-WORD INDICATOR
5895 020230 005203 INC R3 ;AREA WHICH IS USED FOR DOING
5896 020232 001375 BNE .-4 ;SOFTWARE POLLING LATER ON
5897 020234 012703 177770 MOV #-10,R3 ;SET COUNT FOR 8 POSSIBLE DRIVES
5898 020240 012705 033342 MOV #OUTBUF,R5 ;INITIALIZE POINTER TO INDICATOR AREA
5899 020244 1$: MOV #340,-(SP)
5900 020244 012746 000340 MOV #64$,-(SP)
5901 020250 012746 020256
    
```

```

5902 020254 000002 RTI
5903 020256 64$: BIT #BIT0,(R1) ;IS THIS DRIVE PRESENT?
5904 020256 032711 000001 BEQ 4$ ;IF NOT, BRANCH
5905 020262 001433 TST (R1) ;RK06F?
5906 020264 005711 BPL 17$ ;NO, CONTINUE
5907 020266 100012 BNE 16$ ;DRIVE EVEN?
5908 020270 032702 020000 BIT #BIT13,R2 ;YES
5909 020274 001404 BEQ 16$ ;DO WE WANT ODD?
5910 020276 005737 001406 TST ODDEVN ;NO, SO DO NOT TEST
5911 020302 001423 BEQ 4$ ;ADD THIS DRIVE TO LIST
5912 020304 000403 BR 17$ ;DO WE WANT EVEN?
5913 020306 005737 001406 16$: TST ODDEVN ;NO, SO SKIP
5914 020312 001017 BNE 4$ ;SET UP THIS WORD IN THE
5915 020314 010215 17$: MOV R2,(R5) ;INDICATOR AREA SHOWING THAT THIS
5916 ;DRIVE (AS IN BITS 13-15 OF R2)
5917 ;IS PRESENT
5918 ;MASK OUT UNWANTED BITS (CYL.SUR.SEC BITS)
5919 020316 042725 017777 BIC #17777,(R5)+
5920 020322 005004 CLR R4
5921 020324 105710 2$: TSTB @R0 ;IS CNTRL RDY SET?
5922 020326 100405 BMI 3$ ;YES, BRANCH
5923 020330 005204 INC R4 ;NO, WAIT FOR IT
5924 020332 001374 BNE 2$ ;IF WAITED LONG REPORT ERROR
5925 020334 004737 020774 JSR PC,GT4RG ;GO, GET RKCS,ER,DS,DA
5926 020340 104021 ERROR 21 ;CNTRL RDY DID NOT SET AFTER ACCEPTING
5927 ;ADRES FROM PREVIOUS SEEK
5928 020342 010277 160772 3$: MOV R2,@RKDA ;ADRES THIS DRIVE, CYL 0 OR CYL 4
5929 ;(WHICHEVER THE CASE MAY BE)
5930 020346 012710 000111 MOV #111,@R0 ;SEEK.GO,IDE SET
5931 020352 005721 4$: TST (R1)+ ;NEXT DRIVE DATA
5932 020354 062702 020000 ADD #20000,R2 ;INCREMENT DRIVE ADRES (BITS 15,14,13)
5933 020360 005203 INC R3 ;TO NEXT ONE
5934 020362 001330 BNE 1$ ;BRANCH BACK IF ALL DRIVES ARE
5935 ;NOT CHECKED TO SEE IF THE NEXT
5936 ;DRIVE IS PRESENT (& IF SO ISSUE A
5937 ;SEEK TO IT)
5938 ;BY NOW SEEKS HAVE BEEN ISSUED
5939 ;TO ALL DRIVES PRESENT & POLLING
5940 ;HAS BEGUN
5941 020364 005004 CLR R4
5942 020366 013702 5$: MOV RKVEC,R2
5943 020372 012722 020424 MOV #6$, (R2)+ ;SET ADRES FOR RK11 TO INTERRUPT
5944 020376 012712 000340 MOV #340,(R2) ;SET PSW ON INTERRUPT
5945 020402 013746 001400 MOV RKPRI,-(SP) ;DROP CPU PRIORITY TO 4 SO THAT
5946 020406 012746 020414 MOV #18$,-(SP) ;RK11 CAN INTERRUPT
5947 020412 000002 RTI
5948 020414 000240 18$: NOP ;THIS IS A TIME LOOP DURING
5949 020416 005204 INC R4 ;WHICH ALL DRIVES PRESENT SHOULD
5950 020420 001375 BNE 18$ ;INTERRUPT
5951 020422 000452 BR 11$ ;BRANCH AND CHECK IF ALL AVAILABLE
5952 ;DRIVES INTERRUPTED CORRECTLY
5953 020424 022626 6$: CMP (SP)+,(SP)+ ;RESTORE STACK POINTER
5954 020426 005737 001360 TST INDX2 ;WAS THIS FIRST INTERRUPT
5955 ;DUE TO 'ADRES ACK' AFTER INITIATION
5956 ;OF SEEK?
5957 020432 001021 BNE 9$ ;IF YES, CHECK THE FOLLOWING
    
```

```

5958
5959 020434 032710 020000 BIT #20000,@R0 ;CHECK THAT SCP IS NOT SET
5960 020440 001403 BEQ 75 ;BRANCH IF SCP CLEAR
5961 020442 011037 001162 MOV @R0,$REG0 ;GET RKCS
5962 020446 104076 ERROR 76 ;AFTER THE FIRST INTERRUPT WHICH
;IS DUE TO INITIATION OF SEEK, SCP
;SHOULD NOT HAVE SET. IT DID
5963
5964
5965 020450 017701 160652 75: MOV @RKDS,R1
5966 020454 032701 160000 BIT #160000,R1 ;RKDS BITS 15-13 SHOULD BE CLR
5967 020460 001403 BEQ 85
5968 020462 010137 001162 MOV R1,$REG0 ;GET RKDS
5969 020466 104050 ERROR 50 ;SEEK, WITH IDE SET WAS ISSUED TO
;ALL AVAILABLE DRIVES. THE FIRST
;INTERUPT IS DUE TO SEEK INITIATED
;BY FRST DRV. DRV ID BITS 13-15
;SHOULD BE CLR AFTR THIS FRST INRUPT.
;THEY WERE NOT IF THIS ERROR OCCURS.
5970
5971
5972
5973
5974
5975 020470 005237 001360 85: INC INDX2 ;SET UP FLAG INDICATING
;THAT THE FIRST INTERRUPT DUE
;TO INITIATION OF SEEK WAS
;PROCESSED
5976
5977
5978
5979 020474 000734 BR 5$ ;GO BACK TO THE WAIT LOOP & WAIT
;FOR NEXT INTERRUPT FROM RK11
5980
5981 020476 013703 001436 95: MOV PHYDRV,R3 ;SET COUNT OF # OF DRIVES PRESENT
5982 020502 012705 033342 MOV #OUTBUF,R5 ;INITIALIZE POINTER
5983 020506 017701 160614 MOV @RKDS,R1 ;GET RKDS
5984 020512 042701 017777 BIC #17777,R1 ;MASK BITS 0-12
5985
5986
5987
5988
5989
5990
5991 020516 020125 CMP R1,(R5)+ ;BRANCH IF INTERRUPTING DRIVE WAS FOUND
5992 020520 001411 BEQ 10$ ;HAVE U CHKD ALL DRVS PRESENT?
5993 020522 005303 DEC R3 ;IF NOT LUP BAK & CHK
5994 020524 001374 BNE -6 ;REPORT ERROR IF THE INTERRUPTING
;DRIVE # (AS IN RKDS 13-15) WAS NOT
;ANY ONE OF THOSE THAT ARE PRESENT
5995
5996
5997
5998 020526 010146 MOV R1,-(R6) ;GET WORD TO B SHFTD RT
5999 020530 004737 021200 JSR PC,SHFTRT ;GO SHFT IT
6000 020534 012637 001162 MOV (R6)+,$REG0 ;THIS DRIVE # WAS RCVD IN RKDS AS
;THE INTERRUPTING DRIVE, BUT THIS
;DRIVE IS NOT PHYSICALLY PRESENT
6001
6002
6003 020540 104051 ERROR 51 ;RKDS INDICATES AN INTERRUPTING
;DRIVE # (DURING H'WARE POLL) BUT
;THAT DRIVE IS ACTUALLY NOT PRESENT
6004
6005
6006 020542 000401 BR 10$+2
6007 020544 005245 10$: INC -(R5) ;SET UP FLAG INDICATING THAT
;THE INTERRUPT FOR THIS DRIVE
;(AFTER IT HAD COMPLETED ITS SEEK)
;WAS PROCESSED
6008
6009
6010
6011 020546 000707 BR 5$ ;GO BAK & WAIT FOR FURTHER INTRUPTS
6012 020550 013703 001436 11$: MOV PHYDRV,R3 ;GET # OF DRIVES
6013 020554 012705 033342 MOV #OUTBUF,R5 ;INITIALIZE POINTER
    
```

```

6014
6015 020560 105715 14$: TSTB (R5) ;DID THIS DRIVE INTERRUPT?
6016 020562 001006 BNE 13$ ;YES, BRANCH
6017 020564 011546 MOV (R5)-,(R6) ;GET THIS DRIVE #
6018 020566 004737 021200 JSR PC,SHFTRT ;SHIFT IT TO THE RIGHT
6019 020572 012637 001162 MOV (R6)+,$REG0 ;THIS DRIVE # DID NOT INTERRUPT
;DURING H'WARE POLL
6020
6021 020576 104052 ERROR 52 ;DRIVE # (AS IN $REG0) DID NOT
;INTERRUPT DURING HARDWARE POLL
6022
6023 020600 062705 000002 13$: ADD #2,R5 ;INCREMENT POINTER TO THE NEXT FLAG
6024 020604 005303 DEC R3 ;CHKD FOR ALL DRIVES?
6025 020606 001364 BNE 14$ ;IF NOT LUP BACK
6026
6027 020610 005737 001356 TST INDX1 ;DONE POLLING FOR SEEKS TO CYL 3127
6028 020614 001004 BNE TSTEND ;IF YES, EXIT
6029 020616 005237 001356 INC INDX1 ;IF NOT, INCREMENT FLAG
6030 020622 000137 020166 JMP 15$ ;GO DO IT
6031
6032
6033
6034
6035
6036
6037
6038
6039
6040
6041
6042
6043
6044
6045
6046
6047
6048
6049
6050
6051
6052
6053
6054
6055 020626 005237 001406 TSTEND: INC ODDEVN ;NOW ODD IF RK05F
6056 020632 022737 000002 001406 CMP #2,ODDEVN ;SEE IF DONE
6057 020640 001402 BEQ 21$ ;ALL DONE
6058 020642 000137 020140 JMP T56 ;TEST AGAIN
6059 020646 005037 001434 21$: CLR T56FLG
6060
6061
6062
6063
6064
6065
6066
6067
6068
6069
        .SBTTL END OF PASS ROUTINE
        ;*****
        ;*INCREMENT THE PASS NUMBER ($PASS)
        ;*INDICATE END-OF-PROGRAM AFTER 1 PASSES THRU THE PROGRAM
        ;*TYPE "END PASS #XXXX" (WHERE XXXX IS A DECIMAL NUMBER)
        ;*IF THERES A MONITOR GO TO IT
        ;*IF THERE ISN'T JUMP TO ST4
    
```

6070  
6071 020552  
6072 020652 000004  
6073 020654 005037 001102  
6074 020660 005037 001206  
6075 020664 005237 001100  
6076 020670 042737 100000 001100  
6077 020576 005327  
6078 020700 000001  
6079 020702 003022  
6080 020704 012737  
6081 020706 000001  
6082 020710 020700  
6083 020712 104401 020757  
6084 020716 013746 001100  
6085 020722 104405  
6086 020724 104401 020754  
6087 020730 013700 000042  
6088 020734 001405  
6089 020736 000005  
6090 020740 004710  
6091 020742 000240  
6092 020744 000240  
6093 020746 000240  
6094 020750  
6095 020750 000137  
6096 020752 004456  
6097 020754 377 377 000  
6098 020757 015 042412 042116  
6099 020764 050040 051501 020123  
6100 020772 000043  
6101  
6102  
6103  
6104  
6105  
6106  
6107  
6108  
6109  
6110  
6111  
6112  
6113  
6114  
6115  
6116  
6117  
6118  
6119  
6120  
6121  
6122  
6123  
6124  
6125

SEOP: SCOPE  
CLR STSTNM ;;ZERO THE TEST NUMBER  
CLR STIMES ;;ZERO THE NUMBER OF ITERATIONS  
INC \$PASS ;;INCREMENT THE PASS NUMBER  
BIC #10000,\$PASS ;;DON'T ALLOW A NEG. NUMBER  
DEC (PC)+ ;;LOOP?  
SEOPCT: .WORD 1  
BGT \$DDAGN ;;YES  
MOV (PC)+,(PC)+ ;;RESTORE COUNTER  
SENDCT: .WORD 1  
SEOPCT  
TYPE ,SENDMG ;;TYPE "END PASS #"  
MOV \$PASS,-(SP) ;;SAVE SPASS FOR TYPEOUT  
TYPDS ;;GO TYPE--DECIMAL ASCII WITH SIGN  
TYPE ,SENULL ;;TYPE A NULL CHARACTER  
SGET42: MOV @#42,R0 ;;GET MONITOR ADDRESS  
BEQ \$DDAGN ;;BRANCH IF NO MONITOR  
RESET ;;CLEAR THE WORLD  
SENDAD: JSR PC,(R0) ;;GO TO MONITOR  
NOP ;;SAVE ROOM  
NOP ;;FOR  
NOP ;;ACT11  
\$DDAGN: JMP @(PC)+ ;;RETURN  
ST4  
\$RTNAD: .WORD ST4  
\$ENULL: .BYTE -1,-1,0 ;;NULL CHARACTER STRING  
\$ENDMG: .ASCIZ <15><12>/END PASS #/

.SBTTL GT2RG: ROUTINE FOR GETTING RKCS,RKER  
;SUBROUTINE FOR TRANSFERRING THE CONTENTS OF RKCS, RKER  
;TO \$REG0, \$REG1 RESPECTIVELY BEFORE TYPING OUT AN ERROR MESSAGE.  
;CALL: JSR PC,GT2RG  
.SBTTL GT3RG: ROUTINE FOR GETTING RKCS, RKER, RKDS  
;GT3RG  
;SUBROUTINE FOR TRANSFERRING THE CONTENTS OF RKCS, RKER, RKDS  
;TO \$REG0, \$REG1, \$REG2 RESPECTIVELY BEFORE TYPING OUT AN  
;ERROR MESSAGE.  
;CALL: JSR PC,GT3RG  
.SBTTL GT4RG: ROUTINE FOR GETTING RKCS, RKER, RKDS, RKDA  
;GT4RG  
;SUBROUTINE FOR TRANSFERRING CONTENTS OF RKCS, RKER, RKDS

6126  
6127  
6128  
6129  
6130 020774 017737 160340 001170  
6131 021002 017737 160320 001166  
6132 021010 017737 160314 001164  
6133 021016 017737 160310 001162  
6134 021024 000207  
6135  
6136  
6137  
6138  
6139  
6140  
6141  
6142  
6143  
6144  
6145  
6146  
6147  
6148 021026  
6149 021026 104401 021034  
6150 021032 000406  
6151  
6152 021050  
6153 021050 010346  
6154 021052 104402  
6155 021054 000207  
6156  
6157  
6158  
6159  
6160  
6161  
6162  
6163  
6164  
6165  
6166  
6167  
6168  
6169  
6170  
6171  
6172  
6173  
6174  
6175  
6176  
6177  
6178  
6179  
6180 021056 010046  
6181 021060 012700 001172

GT4RG: ROUTINE FOR GETTING RKCS, RKER, RKDS, RKDA  
;RKDA TO \$REG0, \$REG1, \$REG2, \$REG3 RESPECTIVELY BEFORE  
;TYPING OUT AN ERROR MESSAGE.  
;CALL: JSR PC,GT4RG  
GT4RG: MOV @RKDA,\$REG3 ;GET RKDA  
GT3RG: MOV @RKDS,\$REG2 ;GET RKDS  
GT2RG: MOV @RKER,\$REG1 ;GET RKER  
MOV @RKCS,\$REG0  
RTS PC  
.SBTTL TYERM: SPECIAL ERROR MESSAGE ROUTINE  
;TYERM  
;THIS ROUTINE TYPES OUT 'EROR AT PC=X'  
;X IS THE PC WHERE THE EXPLANATION AS TO WHAT HAPPENED IS GIVEN. THIS ROUTINE  
;IS USED ONLY FOR NON-MANUAL MODE OF THE PROGRAM.  
;CALL: JSR TYERM  
TYERM:  
TYPE ,65\$ ;;TYPE ASCIZ STRING  
BR 64\$ ;;GET OVER THE ASCIZ  
;65\$: .ASCIZ <15><12>/EROR,PC=/  
64\$:  
MOV R3,-(SP)  
TYPDC  
RTS PC  
.SBTTL BDA0, BDA4: BREAK DISK ADDRESS INTO SEC, SUR, CYL, DRIVE  
;BDA0, BDA4  
;THIS ROUTINE BREAKS A DISK ADDRESS (BITS 0-15) INTO DRIVE #,  
;CYLINDER #, SURFACE, SECTOR #. THE ROUTINE IS CALLED BY USING EITHER  
;BRKDA0 OR BRKDA4, BOTH BEING 'TRAP' INSTRUCTIONS WITH THEIR LOWER BYTES  
;ENCODED TO PROVIDE INDEXING TO 'BDA0' OR 'BDA4'. BEFORE CALLING  
;THE ROUTINE THE DISK ADDRESS WHICH IS TO BE BROKEN AS ABOVE  
;IS DEPOSITED IN \$REG10.  
;'BRKDA0' PUTS THE BRKDA4 PUTS THE  
;DRIVE # INTO \$REG0 DRIVE # INTO \$REG4  
;CYLINDER # INTO \$REG1 CYLINDER # INTO \$REG5  
;SURFACE # INTO \$REG2 SURFACE # INTO \$REG6  
;SECTOR # INTO \$REG3 SECTOR # INTO \$REG7  
;CALL: BRKDA0 BRKDA4  
BDA0: MOV R0,-(SP) ;PUSH R0 ONTO THE STACK  
MOV #\$REG3+2,R0 ;SET UP POINTER



```

6182 021064 000403 BR BDA4:
6183 021066 010046 MDV R0,-(SP) ;PUSH R0 ONTO THE STACK
6184 021070 012700 001202 MDV #SREG7+2,R0 ;SET UP POINTER
6185 021074 032777 020000 160036 BDA4: BIT #20000,@SWR ;INHIBIT TYPEOUT?
6186 021102 001034 BNE 2$ ;YES, BRANCH TO EXIT POINT
6187 021104 010146 MOV R1,-(SP) ;PUSH R1 ON STACK
6188 021106 010246 MOV R2,-(SP) ;PUSH R2 ON STACK
6189 021110 013701 001202 MOV $REG10,R1 ;GET THE ADDRESS WHICH
6190 021114 042701 177760 BIC #177760,R1 ;HAS TO BE BROKEN
6191 021120 010140 MOV R1,-(R0) ;EXTRACT SECTOR BITS 0-3
6192 021122 013701 001202 MOV $REG10,R1 ;MOVE SECTOR BITS TO $REG3 OR $REG7
6193 021126 006201 ASR R1 ;GET THE DSK-ADRES TO BE BROKEN
6194 021130 006201 ASR R1 ;SHIFT RIGHT 4 TIMES
6195 021132 006201 ASR R1
6196 021134 006201 ASR R1
6197 021136 010102 MOV R1,R2 ;STORE THIS
6198 021140 042702 177776 BIC #177776,R2 ;EXTRACCT THE SURFACE BIT
6199 021144 010240 MOV R2,-(R0) ;MOVE SURFACE BIT TO $REG3 OR $REG6
6200 021146 006201 ASR R1
6201 021150 010102 MOV R1,R2 ;STORE IT
6202 021152 042702 177400 BIC #177400,R2 ;EXTRACT THE CYLINDER BITS
6203 021156 010240 MOV R2,-(R0) ;MOVE CYLINDER BITS TO $REG1 OR $REG5
6204 021160 000301 SWAB R1 ;SWAB HI-LO BYTES
6205 021162 042701 177770 BIC #177770,R1 ;EXTRACT THE DRIVE #
6206 021166 010140 MOV R1,-(R0) ;MOVE DRIVE # TO $REG0 OR $REG4
6207 021170 012602 MOV (SP)+,R2 ;RESTORE R2
6208 021172 012601 MOV (SP)+,R1 ;RESTORE R1
6209 021174 012600 MOV (SP)+,R0 ;RESTORE R0 FROM THE STACK
6210 021176 000002 RTI ;RETURN FROM INTERRUPT, EXIT THIS
6211 ;ROUTINE
6212
6213
6214
6215
6216
6217
6218
6219
6220
6221
6222
6223
6224
6225
6226
6227
6228
6229
6230
6231
6232
6233
6234
6235
6236
6237

```

.SBTTL SHFTRT: SHIFT RIGHT ROUTINE

```

;SHFTRT
;THIS ROUTINE SHIFTS A WORD TO THE RIGHT 13 TIMES. THE WORD TO BE SHIFTED
;IS PUT ON THE STACK BEFORE ENTERING THIS ROUTINE AND IT IS POPPED UP
;FROM THE STACK AFTER THE SHIFT HAS BEEN DONE.
;CALL: JSR PC,SHFTRT

```

```

6227 021200 012737 177763 021224 SHFTRT: MOV # -15,2$ ;SET UP A COUNT OF 13
6228 021206 000241 CLC ;CLEAR THA C BIT
6229 021210 006066 000002 1$: ROR 2(R6) ;ROTATE RIGHT THE WORD TO B SHFTD
6230 021214 005237 021224 INC 2$ ;SHIFTED 13 TIMES?
6231 021220 001373 BNE 1$ ;IF NOT LUP BAK & SHIFT
6232 021222 000207 RTS PC ;EXIT FROM THIS SUBROUTINE
6233
6234
6235
6236
6237

```

```

6238
6239
6240
6241
6242
6243
6244
6245
6246
6247
6248
6249
6250
6251
6252
6253
6254
6255
6256
6257
6258
6259
6260
6261 021226 010137 001202 CHKHE1: MOV R1,$REG10 ;SAVE THE DISK ADRES
6262 021232 000403 BR CHE1
6263
6264 021234 013737 001350 001202 CHKHE: MOV DRIVAD,$REG10 ;SAVE THE DISK ADRES
6265 021242 032777 140000 160062 CHE1: BIT #140000,@RKCS ;IS 'HE' OR 'ERR' BIT SET?
6266 021250 001467 BEQ CRETRN ;NO
6267 021252 004737 020774 JSR PC,GT4RG ;GET RKCS,ER,DS, DA
6268 021256 104416 BRKDA4 ;GO TO 'BDA4' & BREAK CONTENTS 0
6269 ;$REG10 INTO DR#, CYL, SUR, SEC BITS
6270 021260 000207 RTS PC ;RETURN TO THE ERROR MESSAGE
6271
6272
6273
6274
6275
6276
6277
6278
6279
6280
6281
6282 021262 013705 001350 CHKDA: MOV DRIVAD,R5 ;RKDA SHOULD INCREMENT TO THIS
6283 021266 005205 INC R5 ;AFTER DATA TRANSFER IS DONE
6284 021270 020577 160044 CHKDA1: CMP R5,@RKDA ;DID RKDA INCREMENT CORRECTLY?
6285 021274 001455 BEQ CRETRN ;IF YES, BRANCH
6286 ;IF NOT, REPORT ERROR
6287 021276 010537 001202 MOV R5,$REG10 ;GET EXPCTD RKDA
6288 021302 104415 BRKDA0 ;GO TO 'BDA0' & BREAK CONTENTS OF
6289 ;$REG10 INTO DR #,CYL,SUR,SEC BITS
6290 021304 017737 160030 001202 MOV @RKDA,$REG10 ;GET ACTUAL RKDA
6291 021312 104416 BRKDA4 ;GO TO 'BDA4' & BREAK CONTENTS OF
6292 ;$REG10 INTO DR #,CYL,SUR,SEC BITS
6293 021314 000207 RTS PC ;RETURN TO THE ERROR MESSAGE

```

.SBTTL CHKDA: CHECK IF RKDA INCREMENTED CORRECTLY

```

;CHKDA
;THIS ROUTINE CHECKS IF RKDA INCREMENTED CORRECTLY. IF RKDA INCREMENTED
;CORRECTLY RETURN IS MADE TO SKIP THE ERROR MESSAGE.
;IF RKDA DID NOT INCREMENT CORRECTLY, THE EXPECTED AND RECIEVED VALUES
;OF RKDA ARE SAVED AND A RETURN IS MADE TO THE ERROR MESSAGE FOLLOWING THE
;'JSR' CALL.

```

```

6294
6295
6296
6297
6298
6299
6300
6301
6302 021316 005777 160012
6303 021322 001442
6304
6305 021324 017737 160004 001162
6306 021332 017737 160002 001164
6307 021340 000207
6308
6309
6310
6311
6312
6313
6314
6315
6316 021342 005777 157762
6317 021346 001430
6318
6319 021350 004737 021002
6320
6321 021354 000207
6322
6323
6324
6325
6326
6327
6328
6329 021356 005777 157746
6330 021362 001422
6331 021364 013737 001330 001162
6332 021372 017737 157732 001164
6333 021400 000207
6334
6335
6336
6337
6338
6339
6340 021402 022777 000200 157722
6341 021410 001407
6342 021412 013737 001332 001162
6343 021420 017737 157706 001164
6344 021426 000207
6345
6346 021430 062716 000002
6347 021434 000207
6348
6349

```

```

.SBTTL CHKWC: CHECK IF RKWC OVERFLOWED

;CHKWC
;THIS ROUTINE CHECKS IF RKWC OVERFLOWED 0 0. IF IT DID A RETURN IS MADE
;TO SKIP THE ERROR MESSAGE. IF NOT, THE CONTENTS OF RKWC AND RKDA ARE SAVED
;AND A RETURN IS MADE TO THE ERROR MESSAGE FOLLOWING THE 'JSR' CALL.
CHKWC: TST @RKWC ;DID WORD COUNT OVERFLOW TO 0?
      BEQ CRETRN ;IF YES, BRANCH
      ;IF NOT, ERROR
      MOV @RKWC,$REG0 ;GET RKWC
      MOV @RKDA,$REG1 ;GET RKDA
      RTS PC ;RETURN TO THE ERROR MESSAGE

.SBTTL CHKER: CHECK RKER CONTENTS

;CHKER
;THIS ROUTINE CHECKS IF ANY BIT IN RKER SET. IF NOT RETURN IS MADE TO SKIP
;THE ERROR MESSAGE. IF ANY BIT IS SET THE CONTENTS OF RKCS, RKER, RKDS ARE
;SAVED AND A RETURN IS MADE TO THE ERROR MESSAGE.
CHKER: TST @RKER ;DID ANY BIT IN RKER SET?
      BEQ CRETRN ;NO, BRANCH
      JSR PC,GT3RG ;GO, GET RKCS, ER, DS
      RTS PC ;RETURN TO THE ERROR MESSAGE

;CHKECLR
;THIS ROUTINE CHECKS THAT RKER IS CLEAR. IF NOT, THE CONTENTS OF RKER
;ARE SAVED AND A RETURN IS MADE TO THE ERROR MESSAGE FOLLOWING THE 'JSR'
;CALL. IF RKER IS CLEAR THE ERROR MESSAGE IS SKIPPED ON RETURN.
CHKECLR: TST @RKER ;ANY BIT IN RKER SET?
        BEQ CRETRN ;NO
        MOV RKER,$REG0 ;GET ADRES OF RKER
        MOV @RKER,$REG1 ;GET CONTENTS OF RKER
        RTS PC ;RETURN TO THE ERROR MESSAGE

;CHKCCLR
;THIS ROUTINE CHECKS THAT RKCS IS CLEAR. IF NOT, THE CONTENTS OF RKCS ARE
;SAVED AND A RETURN IS MADE TO THE ERROR MESSAGE. IF RKCS IS CLEAR THE
;ERROR MESSAGE IS SKIPPED ON RETURN.
CHKCCLR: CMP #200,@RKCS ;IS RKCS CLEAR?
        BEQ CRETRN ;YES
        MOV RKCS,$REG0 ;SAVE ADRES OF RKCS
        MOV @RKCS,$REG1 ;SAVE THE CONTENT OF RKCS
        RTS PC ;RETURN TO THE ERROR MESSAGE

CRETRN: ADD #2,(SP) ;SKIP ERROR MESSAGE ON
        RTS PC ;RETURN

```

```

6350
6351
6352
6353
6354
6355
6356
6357
6358
6359
6360 021436 013777 001350 157674
6361 021444 005037 001366
6362 021450 032777 000100 157650
6363 021456 001007
6364 021460 005237 001366
6365 021464 001371
6366 021466 017737 157634 001162
6367 021474 000207
6368
6369 021476 062716 000002
6370
6371 021502 000207
6372
6373
6374
6375
6376
6377
6378
6379
6380
6381
6382
6383
6384
6385
6386
6387
6388
6389
6390 021504 005037 001364
6391 021510 013777 001350 157622
6392 021516 012777 000015 157606
6393 021524 104414
6394
6395
6396
6397
6398
6399 021526 032777 000100 157572
6400 021534 001013
6401 021536 012746 177770
6402 021542 005216
6403 021544 001376
6404 021546 005726
6405 021550 005237 001364

```

```

.SBTTL TSTRWS: WAIT FOR R/W/S RDY ROUTINE

;TSTRWS
;THIS ROUTINE WAITS FOR R/W/S RDY TO SET. WHEN IT SETS, THE RETURN PC
;IS INCREMENTED SO THAT ON RETURN (TO THE MAIN PROGRAM) THE ERROR
;MESSAGE FOLLOWING THE 'JSR' CALL IS SKIPPED. IF R/W/S RDY DOES NOT SET
;THEN A RETURN IS MADE TO THE ERROR MESSAGE (FOLLOWING THE 'JSR' CALL).
;WAITING TIME IS APPROX. 1040 MS FOR 11/20, APPROX. 208 MS FOR 11/45
;CALL: JSR TSTRWS

TSTRWS: MOV DRIVAD,@RKDA ;ADRES THE DRIVE
        CLR TIMER ;INITIALIZE COUNT
        BIT #100,@RKDS ;DID R/W/S RDY SET?
        BNE 2$ ;YES, BRANCH
        INC TIMER ;WAIT FOR R/W/S RDY
        BNE 1$ ;ERROR IF IT'S NOT SET BY NOW
        MOV @RKDS,$REG0 ;GET RKDS
        RTS PC ;EXIT (TO ERROR FOLLOWING 'JSR TSTRWS')

2$: ADD #2,(SP) ;ADJUST RETURN ADRES TO SKIP OVER
    ;ERROR (FOLLOWING 'JSR TSTRWS')
    RTS PC ;EXIT

.SBTTL DRESET: DRIVE RESET ROUTINE

;DRESET
;THIS ROUTINE DOES A DRIVE RESET ON THE DRIVE WHOOSE ADDRESS IS IN
;RKDA. MULTIPLE RETURN ADDRESSES FOR THIS ROUTINE ARE PROVIDED.
;IF THERE IS NO ERROR (R/W/S RDY SETS WITHIN CERTAIN TIME), THEN BEFORE
;EXITING FROM THIS ROUTINE THE RETURN ADDRESS IS INCREMENTED BY 2, TO SKIP
;THE ERROR MESSAGE ON RETURN. IF THERE IS AN ERROR, THE 3 REGISTERS (CS,ER,DS)
;ARE STORED AND THEN A NORMAL EXIT IS MADE FROM THIS ROUTINE TO THE
;ERROR MESSAGE FOLLOWING THE CALL FOR THIS ROUTINE.
;CALL: JSR PC,DRESET

DRESET: CLR COUNT1 ;INITIALIZE THE COUNT
        MOV DRIVAD,@RKDA ;ADRES THE DRIVE
        MOV #15,@RKCS ;DRIVE RESET, GO
        CNT.RDY ;THIS IS A CALL FOR 'CN.RDY'
        ;ROUTINE WHICH WAITS FOR CNT
        ;RDY TO 'ET. IF CNTRL RDY DOES
        ;NOT SET WITHIN 883 MS/ 11-20
        ;(176 MS FOR 11-45 WITH BIPOLAR)
        ;AN ERROR IS REPORTED
        BIT #100,@RKDS ;DID R/W/S RDY SET?
        BNE 2$
        MOV #-10,-(SP) ;PUSH COUNT ON SP
        INC (SP) ;COUNT IT DOWN
        BNE -2
        TST (SP)+ ;POP UP SP
        INC COUNT1 ;IF NOT WAIT

```

```
        BNE      1$                ;WAITED LONG?
        JSR      PC,GT4RG
        BR       2$+4
25:     ADD      #2,@R6
        RTS      PC

        .SBTTL   TSTSIN: CHECK 'SIN' ROUTINE

;TSTSIN
;THIS ROUTINE CHECKS IF 'SIN' IS SET, IF IT IS SET A
;DRIVE RESET IS DONE TO CLEAR 'SIN' AND INITIALIZE POSITIONER.
;CALL:          TST,SIN
;IF ON DOING DRIVE RESET R/W/S RDY DOES NOT SET A MESSAGE
;          ERROR PC=XXXXXX IS GIVEN.
;          XXXXXX=PC IN THE MAIN PROGRAM WHERE 'TST.SIN' CALL IS LOCATED.
6424
6425 021572 013777 001350 157540 TSTSIN: MOV   DRIVAD,@RKDA ;ADRES THE DRIVE
6426 021600 032777 001000 157520          BIT   #1000,@RKDS ;IS SIN SET?
        BEQ      1$
        JSR      PC,DRESET ;GO DO DRIVE RESET, SIN SET
        BR       2$        ;REPORT ERROR
6428 021610 004737 021504          BR       2$
6429 021614 000401
6430 021616 000002 1$:      RTI
6431 021620 032777 020000 157312 2$:      BIT   #SW13,@SWR ;INHIBIT TYPEOUT?
        BNE      1$        ;IF YES, SKIP TYPEOUT
        TYPE     ,65$      ;;TYPE ASCIZ STRING
        BR       64$      ;;GET OVER THE ASCIZ
6432 021626 001373 021636          BR       64$
6433 021630 104401
6434 021634 000406          ;:65$: .ASCIZ /ERROR PC= /
6435
6436 021652
6437 021652 011646
6438 021654 062716 177776          64$:      MOV   (SP),-(SP) ;GET THE PC WHERE 'TST.SIN' IS LOCATED
        ADD      #-2,(SP) ;GO TYPE OUT PC
        TYPOC
        BR       1$

        .SBTTL   DELAY: TIME DELAY ROUTINE

;DELAY
;THIS ROUTINE PROVIDES A VARIABLE TIME DELAY. THE CALL FOR THIS
;ROUTINE IS AN ENCODED 'TRAP' INSTRUCTION.
;CALL:          DELAY ,N      N IS ANY OCTAL NO. FROM 1 TO 177777
;THE DELAY PROVIDED IS 7.5N US (CONVERT N TO DECIMAL) FOR 11/20
;          1.5N US FOR 11/45
;IF THE USER WANTS TO CHANGE THE DELAY TIME (EXMP: SHORTER DELAY TO
;GET A TIGHTER SCOPE LOOP) THE VARIABLE 'N' FOLLOWING 'DELAY' SHOULD
;BE CHANGED TO SUIT THE INDIVIDUAL NEED.
6456 021664 017637 000000 001366 DELA.Y: MOV   @(SP),TIMER ;GET 'AMOUNT' (N) FOR WHICH
6457 021672 062716 000002          ADD      #2,(SP) ;DELAY IS TO BE PROVIDED
;ADJUST STACK POINTER TO SKIP OVER 'N'
6458          1$:   DEC   TIMER ;COUNT DOWN TO 0
6459 021676 005337 001366          BNE     1$
6460 021702 001375
6461
```

```
        RTI                ;RETURN TO MAIN PROGRAM

        .SBTTL   WAT.INT:      WAIT FOR INTERRUPT ROUTINE

;WAT.INT
;THIS ROUTINE PROVIDES A VARIABLE TIME WAIT LOOP DURING WHICH AN INTERRUPT
;FROM RK11 CAN OCCUR. THE CALL IS AN ENCODED 'TRAP' INSTRUCTION.
;CALL:          WAT.INT ,N      N IS ANY OCTAL NO. FROM 1 TO 177777
;WAIT LOOP TIME= APPROX. 7.5N US (CONVERT N TO DECIMAL) FOR 11/20
;APPROX. 1.5N US FOR 11/45
;UPON ENTERING THE ROUTINE THE CPU PRIORITY IS DROPPED SO THAT
;RK11 CAN INTERRUPT. NOTE THAT WHEN RK11 INTERRUPTS THIS ROUTINE
;IS EXITED WITHOUT POPPING THE STACK, THIS POPPING IS DONE AFTER GETTING
;TO RK11 INTERRUPT HANDLER.
;IF FOR ANY REASON THE WAIT LOOP TIME HAS TO BE CHANGED IT CAN BE DONE
;BY SIMPLY CHANGING THE VARIABLE 'N' FOLLOWING THE 'WAT.INT'.
6484 021706 017637 000000 001366 WATINT: MOV   @(SP),TIMER ;GET 'AMOUNT' (N) FOR WHICH
6485 021714 062716 000002          ADD      #2,(SP) ;WAITING IS TO BE DONE
;ADJUST STACK POINTER FOR CORRECT RETURN
;DROP CPU PRIORITY SO THAT RK11 CAN
; INTERRUPT
6487 021720 013746 001400          MOV   RKPRI,-(SP)
6488 021724 012746 021732          MOV   #1$,-(SP)
6489 021730 000002          RTI
6490 021732 005337 001366          1$:   DEC   TIMER ;WAIT FOR RK11 TO INTERRUPT
6491 021736 001375          BNE     1$
6492
6493          ;IF INTERRUPT HAS NOT OCCURED BY NOW
6494 021740 000002          RTI ;RETURN AND REPORT ERROR
6495          ;EXIT
6496
6497
6498
6499
;WATIME
6500 021742 005000          WATIME: CLR   R0
6501 021744 005001          CLR   R1
6502 021746 005200          1$:   INC   R0
6503 021750 001376          BNE     1$
6504 021752 105201          INCB  R1
6505 021754 001374          BNE     1$
6506 021756 000207          RTS   PC
6507
6508
6509          .SBTTL   CHKCRDY:      CHECK CONTROL READY
6510
6511          ;;CH.CRDY
6512          ;THIS ROUTINE WAITS FOR THE CONTROL READY TO SET. IF THE CONTROL READY BIT
6513          ;DOES NOT SET WITHIN A CERTAIN TIME, THEN THE CONTENTS OF RKCS, RKER, RKDS
6514          ;AND RKDA ARE SAVED AND AN EXIT MADE TO THE ERROR MESSAGE FOLLOWING THE
6515          ;'JSR' CALL FOR THIS ROUTINE.
6516          ;IF CONTROL READY SETS THEN THE RETURN ADDRESS IS ADJUSTED TO SKIP THE
6517          ;ERROR MESSAGE ON RETURN.
```

```

6518 ;CALL: CHKCRDY
6519 ; ERROR ;RETURN HERE IF ERROR
6520 ; --- ;RETURN HERE IF NO ERROR
6521
6522 021760 005037 001366 CH.CRDY: CLR TIMER
6523 021764 105777 157342 1$: TSTB @RKCS ;CNTRL RDY SET?
6524 021770 100406 BMI 25 ;YES
6525 021772 005237 001366 INC TIMER
6526 021776 001372 BNE 15 ;NO, WAIT
6527 022000 004737 020774 JSR PC,GT4RG ;SAVE RKCS, ER, DS, DA
6528 022004 000002 RTI
6529
6530 022006 062716 000002 2$: ADD #2,(SP) ;ADJUST RETURN ADDRESS TO
6531 022012 000002 RTI ;SKIP ERROR MESSAGE ON RETURN
6532
6533 .SBTTL CON.RESET: CONTROL REST ROUTINE
6534
6535 ;CON.RESET
6536 ;THIS ROUTINE ISSUES A CONTROL RESET AND WAITS FOR
6537 ;THE 'CNTRL RDY' FLAG TO SET. WHEN THE FLAG SETS
6538 ;AN EXIT IS MADE OUT OF THE ROUTINE. IF 'CNTRL-RDY'
6539 ;DOES NOT SET WITHIN A CERTAIN TIME AN ERROR MESSAGE
6540 ; CNT RDY DIDN'T SET
6541 ; PC=XXXXXX RKCS=YYYYYY
6542 ;IS GIVEN. NOTE THAT XXXXXX IS THE PC WHERE 'CNT.RESET' OR 'CNT.RDY'
6543 ;IS CALLED.
6544
6545 ;CALL: CNT.RESET
6546
6547
6548
6549
6550
6551 .SBTTL CNT.RDY: WAIT FOR CONTROL READY ROUTINE
6552
6553 ;CN.RDY
6554 ;THIS ROUTINE WAITS FOR THE CONTROL READY BIT TO SET AND WHEN IT
6555 ;SETS EXITS OUT. IF WITHIN A CERTAIN TIME CNTRL RDY DOES
6556 ;NOT SET AN ERROR IS REPORTED. WAITING TIME IS 883 MS FOR 11/20
6557 ;175 MS FOR 11/45 WITH BIPOLAR MEMORY.
6558 ;CALL: CNT.RDY
6559 022014 012777 000001 157310 CN.RST: MOV #1,@RKCS ;ISSUE A CONTROL RESET
6560 022022 012737 177500 001170 MOV #-300,$REG3 ;SET UP COUNT
6561 022030 000402 BR CN.RDY+4 ;SKIP OVER CN.RDY
6562 022032 005037 001170 CN.RDY: CLR $REG3
6563 022036 105777 157270 1$: TSTB @RKCS ;DID CNT:~L-RDY SET?
6564 022042 100435 BMI 3$ ;YES, EXIT
6565 022044 005237 001170 INC $REG3 ;WAITED LONG?
6566 022050 001372 BNE 1$ ;IF NOT, GO BAK & WAIT
6567 022052 032777 020000 157060 2$: BIT #SW13,@SWR ;INHIBIT TYPEOUT?
6568 022060 001026 BNE 3$ ;IF YES, SKIP TYPEOUT
6569 022062 104401 TYPE ;
6570 022064 001245 MSG3 ;TYPE ASCIZ STRING
6571 022066 104401 022074 TYPE ,65$ ;GET OVER THE ASCIZ
6572 022072 000403 BR 64$
6573 ;:65$: .ASCIZ <15><12>/PC#/

```

```

6574 022102
6575 022102 011646
6576 022104 162716 000002
6577 022110 104402
6578
6579 022112 104401 022120
6580 022116 000404
6581
6582 022130
6583 022130 017746 157176
6584 022134 104402
6585
6586 022136 000002
6587
6588
6589
6590
6591
6592
6593
6594
6595
6596
6597
6598
6599
6600
6601
6602
6603
6604
6605
6606
6607
6608
6609 022140
6610 022140 104407
6611 022142 032777 040000 156770 1$: MOV (SP),-(SP) ;GO TYPE PC IN THE MAIN PROGRAM,
6612 022150 001111 TYPOC #2,(SP) ;WHERE ERROR OCCURRED
6613 ;TYPE ,67$ ;:TYPE ASCIZ STRING
6614 ;BR 66$ ;:GET OVER THE ASCIZ
6615 ;:67$: .ASCIZ / RKCS=/
6616 66$: MOV @RKCS,-(SP) ;GET RKCS
6617 TYPOC ;GO TYPE IT
6618
6619 3$: RTI ;RETURN FROM THIS
6620 ;ROUTINE TO THE MAIN
6621 ;PROGRAM
6622
6623 ;THIS PART OF THE PROGRAM CONTAINS THE COMMON ROUTINES CALLED
6624 ;FROM THE SYSMAC.SML PACKAGE
6625 ;
6626 .SBTTL SCOPE HANDLER ROUTINE
6627
6628 ;*****
6629 ;*THIS ROUTINE CONTROLS THE LOOPING OF SUBTESTS. IT WILL INCREMENT
6630 ;*AND LOAD THE TEST NUMBER($STNM) INTO THE DISPLAY REG.(DISPLAY<7:0>)
6631 ;*AND LOAD THE ERROR FLAG (SERFLG) INTO DISPLAY<15:08>
6632 ;*THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
6633 ;*SW14=1 LOOP ON TEST
6634 ;*SW11=1 INHIBIT ITERATIONS
6635 ;*SW09=1 LOOP ON ERROR
6636 ;*SW08=1 LOOP ON TEST IN SWR<7:0>
6637 ;*CALL SCOPE ;:SCOPE=IOT
6638 ;*
6639
6640 $SCOPE:
6641 022140 104407 CKSWR ;:TEST FOR CHANGE IN SOFT-SWR
6642 022142 032777 040000 156770 1$: BIT #BIT14,@SWR ;:LOOP ON PRESENT TEST?
6643 022150 001111 BNE SOVER ;:YES IF SW14=1
6644 ;*****START OF CODE FOR THE XOR TESTER*****
6645 $XTSTR: BR 6$ ;:IF RUNNING ON THE "XOR" TESTER CHANGE
6646 ;:THIS INSTRUCTION TO A "NOP" (NOP=240)
6647 MOV @ERRVEC,-(SP) ;:SAVE THE CONTENTS OF THE ERROR VECTOR
6648 MOV #5,@ERRVEC ;:SET FOR TIMEOUT
6649 TST @177060 ;:TIME OUT ON XOR?
6650 MOV (SP)+,@ERRVEC ;:RESTORE THE ERROR VECTOR
6651 BR SSVLAD ;:GO TO THE NEXT TEST
6652 66$: CMP (SP)+,(SP)+ ;:CLEAR THE STACK AFTER A TIME OUT
6653 MOV (SP)+,@ERRVEC ;:RESTORE THE ERROR VECTOR
6654 BR 7$ ;:LOOP ON THE PRESENT TEST
6655 ;*****END OF CODE FOR THE XOR TESTER*****
6656 66$: BIT #BIT08,@SWR ;:LOOP ON SPEC. TEST?
6657 BEQ 2$ ;:BR IF NO
6658 CMPB @SWR,$STNM ;:ON THE RIGHT TEST? SWR<7:0>
6659 BEQ SOVER ;:BR IF YES
6660 2$: TSTB SERFLG ;:HAS AN ERROR OCCURRED?
6661
6662
6663
6664
6665
6666
6667
6668
6669
6670
6671
6672
6673
6674
6675
6676
6677
6678
6679
6680
6681
6682
6683
6684
6685
6686
6687
6688
6689
6690
6691
6692
6693
6694
6695
6696
6697
6698
6699
6700
6701
6702
6703
6704
6705
6706
6707
6708
6709
6710
6711
6712
6713
6714
6715
6716
6717
6718
6719
6720
6721
6722
6723
6724
6725
6726
6727
6728
6729
6730
6731
6732
6733
6734
6735
6736
6737
6738
6739
6740
6741
6742
6743
6744
6745
6746
6747
6748
6749
6750
6751
6752
6753
6754
6755
6756
6757
6758
6759
6760
6761
6762
6763
6764
6765
6766
6767
6768
6769
6770
6771
6772
6773
6774
6775
6776
6777
6778
6779
6780
6781
6782
6783
6784
6785
6786
6787
6788
6789
6790
6791
6792
6793
6794
6795
6796
6797
6798
6799
6800
6801
6802
6803
6804
6805
6806
6807
6808
6809
6810
6811
6812
6813
6814
6815
6816
6817
6818
6819
6820
6821
6822
6823
6824
6825
6826
6827
6828
6829
6830
6831
6832
6833
6834
6835
6836
6837
6838
6839
6840
6841
6842
6843
6844
6845
6846
6847
6848
6849
6850
6851
6852
6853
6854
6855
6856
6857
6858
6859
6860
6861
6862
6863
6864
6865
6866
6867
6868
6869
6870
6871
6872
6873
6874
6875
6876
6877
6878
6879
6880
6881
6882
6883
6884
6885
6886
6887
6888
6889
6890
6891
6892
6893
6894
6895
6896
6897
6898
6899
6900
6901
6902
6903
6904
6905
6906
6907
6908
6909
6910
6911
6912
6913
6914
6915
6916
6917
6918
6919
6920
6921
6922
6923
6924
6925
6926
6927
6928
6929
6930
6931
6932
6933
6934
6935
6936
6937
6938
6939
6940
6941
6942
6943
6944
6945
6946
6947
6948
6949
6950
6951
6952
6953
6954
6955
6956
6957
6958
6959
6960
6961
6962
6963
6964
6965
6966
6967
6968
6969
6970
6971
6972
6973
6974
6975
6976
6977
6978
6979
6980
6981
6982
6983
6984
6985
6986
6987
6988
6989
6990
6991
6992
6993
6994
6995
6996
6997
6998
6999
7000

```

```

6630 022234 001421      BEQ      3$          ;;BR IF NO
6631 022236 123737      CMPB     $ERMAX,$ERFLG ;;MAX. ERRORS FOR THIS TEST OCCURRED?
6632 022244 101015      BHI      3$          ;;BR IF NO
6633 022246 032777      BIT      #BIT09,@SWR  ;;LOOP ON ERROR?
6634 022254 001404      BEQ      4$          ;;BR IF NO
6635 022256 013737      MOV     $LPERR,$LPADR ;;SET LOOP ADDRESS TO LAST SCOPE
6636 022254 000443      BR      $OVER
6637 022256 105037      CLRB    $ERFLG      ;;ZERO THE ERROR FLAG
6638 022272 005037      CLR     $TIMES      ;;CLEAR THE NUMBER OF ITERATIONS TO MAKE
6639 022276 000415      BR      1$          ;;ESCAPE TO THE NEXT TEST
6640 022300 032777      BIT     #BIT11,@SWR  ;;INHIBIT ITERATIONS?
6641 022306 001011      BNE     1$          ;;BR IF YES
6642 022310 005737      TST     $PASS       ;;IF FIRST PASS OF PROGRAM
6643 022314 001406      BEQ     1$          ;; INHIBIT ITERATIONS
6644 022316 005237      INC     $ICNT       ;;INCREMENT ITERATION COUNT
6645 022322 023737      CMP     $TIMES,$ICNT ;;CHECK THE NUMBER OF ITERATIONS MADE
6646 022330 002021      BGE     $OVER       ;;BR IF MORE ITERATION REQUIRED
6647 022332 012737      MOV     #1,$ICNT    ;;REINITIALIZE THE ITERATION COUNTER
6648 022340 013737      MOV     $MXCNT,$TIMES ;;SET NUMBER OF ITERATIONS TO DO
6649 022346 105237      $SVLAD: INCB $TSTNM   ;;COUNT TEST NUMBERS
6650 022352 011637      MOV     (SP),$LPADR  ;;SAVE SCOPE LOOP ADDRESS
6651 022356 011637      MOV     (SP),$LPERR  ;;SAVE ERROR LOOP ADDRESS
6652 022362 005037      CLR     $ESCAPE     ;;CLEAR THE ESCAPE FROM ERROR ADDRESS
6653 022366 112737      MOV     #1,$ERMAX   ;;ONLY ALLOW ONE(1) ERROR ON NEXT TEST
6654 022374 013777      $OVER: MOV $TSTNM,@DISPLAY ;;DISPLAY TEST NUMBER
6655 022402 013716      MOV     $LPADR,(SP)  ;;FUDGE RETURN ADDRESS
6656 022406 000002      RTI
6657 022410 000050      $MXCNT: 50          ;;FIXES PS
                                           ;;MAX. NUMBER OF ITERATIONS

6658
6659
6660 ;*****
6661
6662 .SBTTL ERROR HANDLER ROUTINE
6663
6664 ;*SW15=1 HALT ON ERROR
6665 ;*SW13=1 INHIBIT ERROR TYPEOUTS
6666 ;*SW10=1 TESTING ON SIMULATOR
6667 ;*SW09=1 LOOP ON ERROR
6668 ;*SW12=1 CYCLE ON ERROR TO PREVIOUS 'SCOPE'
6669 ;*SW06=1 DROP DRIVE AFTER MAXIMUM (ALLOWABLE) ERRORS ON THE DRIVE
6670 ;*GO TO $ERRTYP ON ERROR

6671
6672 022412 104407      $ERROR: CKSWR      ;;CHECK FOR SOFTWARE SWITCH REGISTER REQUEST
6673 022414 105237      7$: INCB $ERFLG    ;;SET THE ERROR FLAG
6674 022420 001775      BEQ     7$          ;;DON'T LET THE FLAG GO TO ZERO
6675 022422 013777      MOV     $TSTNM,@DISPLAY ;;DISPLAY TEST NUMBER AND ERROR FLAG
6676 022430 005237      1$: INC $ERRTTL    ;;COUNT THE NUMBER OF ERRORS
6677
6678 022434 032777      BIT     #BIT6,@SWR  ;;DESELECT DRIVE SW SET?
6679 022442 001404      BEQ     6$          :NO
6680 022444 023727      CMP     $ERRTL,#5   ;;MORE THAN 5 ERRORS ON THIS DRIVE?
6681 022452 101053      BHI     8$          ;;YES, DESELECT THE DRIVE
6682
6683 022454 011637      6$: MOV (SP),$ERRPC   ;;GET ADDRESS OF ERROR INSTRUCTION
6684 022460 162737      SUB     #2,$ERRPC   ;;
6685 022466 117737      MOV     @ $ERRPC,$ITEMB ;;STRIP AND SAVE THE ERROR ITEM CODE
    
```

```

6686 022474 032777      020000 156436      BIT     #SW13,@SWR   ;;SKIP TYPEOUT IF SET
6687 022502 001004      BNE     2$          ;;SKIP TYPEOUTS
6688 022504 004737      JSR     PC,@$ERRTYP ;;GO TO USER ERROR ROUTINE
6689 022510 104401      TYPE   , $CRLF
6690 022514 023737      000046 2$: CMP #42,@#46      ;;ARE WE IN ACT11 AUTO MODE?
6691 022522 001403      BEQ     .+10        ;;YES, HALT ON ERROR
6692 022524 005777      TST     @SWR       ;;HALT ON ERROR?
6693 022530 100002      BPL     3$          ;;SKIP IF CONTINUE
6694 022532 000000      HALT
6695 022534 104407      CKSWR      ;;CHECK FOR SOFTWARE SWITCH REGISTER REQUEST
6696 022536 032777      010000 156374 3$: BIT #SW12,@SWR     ;;SW 12 SET?
6697 022544 001402      BEQ     .+6         ;;NO, BRANCH
6698 022546 013716      MOV     $LPADR,(SP) ;;ADJUST RETURN ADRES FOR SW12
6699 022552 032777      010000 156360      BIT     #SW09,@SWR  ;;LOOP ON ERROR SWITCH SET?
6700 022560 001402      BEQ     4$          ;;BR IF NO
6701 022562 013716      MOV     $LPERR,(SP) ;;FUDGE RETURN FOR LOOPING
6702 022566 005737      4$: TST $ESCAPE     ;;CHECK FOR AN ESCAPE ADDRESS
6703 022572 001402      BEQ     5$          ;;BR IF NONE
6704 022574 013716      MOV     $ESCAPE,(SP) ;;FUDGE RETURN ADDRESS FOR ESCAPE
6705 022600 000002      5$: RTI          ;;RETURN
6706
6707 022602 005737      8$: TST T56FLG     ;;IF EROR WAS IN LAST TEST (POLL)
6708                                     ;;DROP ALL THE DRIVES
6709
6710 022606 001407      BEQ     10$        ;;
6711 022610 104401      TYPE   ,MSG5
6712 022614 005037      CLR     DRVS
6713 022620 022626      CMP     (SP)+,(SP)+
6714 022622 000137      JMP     $EOP
6715 022626 013746      10$: MOV DRVPTR,-(SP) ;;DROP THE DRIVE FROM THE
6716 022632 162716      SUB     #2,(SP)    ;;SELECTION LIST
6717 022636 013746      MOV     DRIVAD,-(SP) ;;DRIVE ADDR TO STACK
6718 022642 004737      JSR     PC,$HFTRT  ;;RIGHT JUSTIFY
6719 022646 042716      BIC     #1,(R6)    ;;MAKE EVEN
6720 022652 062716      ADD     @DRIVO,(SP) ;;POINTS TO TABLE FOR EVEN DRIVE
6721 022656 042776      000000      BIC     #BIT15,@(R6) ;;TEST REMAINING DRIVE AS RK05E
6722 022664 062716      ADD     #2,(R6)    ;;POINT TO ODD
6723 022670 042736      BIC     #BIT15,@(SP)+ ;;TEST AS RK-05E
6724 022674 012736      MOV     #BIT12,@(SP)+ ;;INDICATE THIS DRIVE DROPPED
6725 022700 104401      TYPE   ,MSG4
6726 022704 013746      MOV     DRIVAD,-(R6) ;;PUSH DRIVE # ON STACK
6727 022710 004737      JSR     PC,$HFTRT  ;;SHIFT IT BEFORE TYPING
6728 022714 104402      TYPOC
6729 022716 104401      TYPE   ,MSG6
6730 022722 005337      DEC     DRVS      ;;DECREMENT # OF DRIVES PRESENT
6731 022726 022626      9$: CMP (SP)+,(SP)+ ;;RESTORE STACK
6732 022730 000137      JMP     BTEDP     ;;GO BACK TO THE END OF PROGRM
6733                                     ;;LINKAGE.
6734
6735 .SBTTL ERROR MESSAGE TYPEOUT ROUTINE
6736
6737 ;*****
6738 ;*THIS ROUTINE USES THE "ITEM CONTROL BYTE" ($ITEMB) TO DETERMINE WHICH
6739 ;*ERROR IS TO BE REPORTED. IT THEN OBTAINS, FROM THE "ERROR TABLE" ($ERRTB),
6740 ;*AND REPORTS THE APPROPRIATE INFORMATION CONCERNING THE ERROR.
6741 022734      $ERRTYP:
    
```

```

6742 022734 104401 001213      TYPE      ,SCRLF      ;; "CARRIAGE RETURN" & "LINE FEED"
6743 022740 010046              MOV      RO,-(SP)    ;;SAVE RO
6744 022742 005000              CLR      RO          ;;:PICKUP THE ITEM INDEX
6745 022744 153700 001114      BISB     @#$ITEMB,RO
6746 022750 001004              BNE     1$          ;;:IF ITEM NUMBER IS ZERO, JUST
6747                          ;;:TYPE THE PC OF THE ERROR
6748 022752 013746 001116      MOV      SERRPC,-(SP) ;;:SAVE SERRPC FOR TYPEOUT
6749                          ;;:ERROR ADDRESS
6750 022756 104402              TYPOC                    ;;:GO TYPE--OCTAL ASCII(ALL DIGITS)
6751 022760 000426              BR      6$          ;;:GET OUT
6752 022762 005300      1$: DEC      RO          ;;:ADJUST THE INDEX SO THAT IT WILL
6753 022764 006300              ASL     RO          ;;: WORK FOR THE ERROR TABLE
6754 022766 006300              ASL     RO
6755 022770 006300              ASL     RO
6756 022772 062700              ADD     #SERRTB,RO   ;;:FORM TABLE POINTER
6757 022776 012037 023006      MOV      (RO)+,2$    ;;:PICKUP "ERROR MESSAGE" POINTER
6758 023002 001404              BEQ     3$          ;;:SKIP TYPEOUT IF NO POINTER
6759 023004 104401              TYPE                    ;;:TYPE THE "ERROR MESSAGE"
6760 023006 000000      2$:      0          ;;: "ERROR MESSAGE" POINTER GOES HERE
6761 023010 104401 001213      TYPE      ,SCRLF    ;; "CARRIAGE RETURN" & "LINE FEED"
6762 023014 012037 023024      MOV      (RO)+,4$    ;;:PICKUP "DATA HEADER" POINTER
6763 023020 001404              BEQ     5$          ;;:SKIP TYPEOUT IF 0
6764 023022 104401              TYPE                    ;;:TYPE THE "DATA HEADER"
6765 023024 000000      4$:      0          ;;: "DATA HEADER" POINTER GOES HERE
6766 023026 104401 001213      TYPE      ,SCRLF    ;; "CARRIAGE RETURN" & "LINE FEED"
6767 023032 011000      5$: MOV      (RO),RO   ;;:PICKUP "DATA TABLE" POINTER
6768 023034 001004              BNE     7$          ;;:GO TYPE THE DATA
6769 023036 012600      6$: MOV      (SP)+,RO  ;;:RESTORE RO
6770 023040 104401 001213      TYPE      ,SCRLF    ;; "CARRIAGE RETURN" & "LINE FEED"
6771 023044 000207              RTS     PC          ;;:RETURN
6772 023046              7$:
6773 023046 013046              MOV     @ (RO)+,-(SP) ;;:SAVE @ (RO)+ FOR TYPEOUT
6774 023050 104402              TYPOC                    ;;:GO TYPE--OCTAL ASCII(ALL DIGITS)
6775 023052 005710              TST     (RO)        ;;:IS THERE ANOTHER NUMBER?
6776 023054 001770              BEQ     6$          ;;:BR IF NO
6777 023056 104401 023064      TYPE      ,8$        ;;:TYPE TWO(2) SPACES
6778 023062 000771              BR      7$          ;;:LOOP
6779 023064 020040 000      8$: .ASCIZ  / /        ;;:TWO(2) SPACES
6780 023070
6781
6782 .SBTTL TYPE ROUTINE
6783
6784 ;;*****
6785 ;;ROUTINE TO TYPE ASCIZ MESSAGE. MESSAGE MUST TERMINATE WITH A 0 BYTE.
6786 ;;THE ROUTINE WILL INSERT A NUMBER OF NULL CHARACTERS AFTER A LINE FEED.
6787 ;;NOTE1: SNULL CONTAINS THE CHARACTER TO BE USED AS THE FILLER CHARACTER.
6788 ;;NOTE2: SFILLS CONTAINS THE NUMBER OF FILLER CHARACTERS REQUIRED.
6789 ;;NOTE3: SFILLC CONTAINS THE CHARACTER TO FILL AFTER.
6790 ;;
6791 ;;CALL:
6792 ;;*1) USING A TRAP INSTRUCTION
6793 ;;* TYPE ,MESADR ;;MESADR IS FIRST ADDRESS OF AN ASCIZ STRING
6794 ;;OR
6795 ;;* TYPE
6796 ;;* MESADR
6797 ;;*

```

```

6798
6799 023070 105737 001157      $TYPE: TSTB  $TPFLG    ;;:IS THERE A TERMINAL?
6800 023074 100002              BPL     1$          ;;:BR IF YES
6801 023076 000000              HALT                    ;;:HALT HERE IF NO TERMINAL
6802 023100 000407              BR      3$          ;;:LEAVE
6803 023102 010046      1$: MOV      RO,-(SP)    ;;:SAVE RO
6804 023104 017600 000002      MOV      @2(SP),RO   ;;:GET ADDRESS OF ASCIZ STRING
6805 023110 112046      2$: MOVB     (RO)+,-(SP) ;;:PUSH CHARACTER TO BE TYPED ONTO STACK
6806 023112 001005              BNE     4$          ;;:BR IF IT ISN'T THE TERMINATOR
6807 023114 005726              TST     (SP)+       ;;:IF TERMINATOR POP IT OFF THE STACK
6808 023116 012600      60$: MOV      (SP)+,RO  ;;:RESTORE RO
6809 023120 062716 000002      3$: ADD     #2,(SP)   ;;:ADJUST RETURN PC
6810 023124 000002              RTI                    ;;:RETURN
6811 023126 122716 000011      4$: CMPB     #HT,(SP)  ;;:BRANCH IF <HT>
6812 023132 001430              BEQ     8$          ;;:BRANCH IF NOT <CRLF>
6813 023134 122716 000200      CMPB     #CRLF,(SP) ;;:BRANCH IF NOT <CRLF>
6814 023140 001006              BNE     5$          ;;:BRANCH IF NOT <CRLF>
6815 023142 005726              TST     (SP)+       ;;:POP <CR><LF> EQUIV
6816 023144 104401              TYPE                    ;;:TYPE A CR AND LF
6817 023146 001213      SCRLF
6818 023150 105037 023304      CLRB     $CHARCNT    ;;:CLEAR CHARACTER COUNT
6819 023154 000755              BR      2$          ;;:GET NEXT CHARACTER
6820 023156 004737 023240      5$: JSR      PC,$TYPEC  ;;:GO TYPE THIS CHARACTER
6821 023162 123726 001156      6$: CMPB     $FILLC,(SP)+ ;;:IS IT TIME FOR FILLER CHARS.?
6822 023166 001350              BNE     2$          ;;:IF NO GO GET NEXT CHAR.
6823 023170 013746 001154      MOV      $NULL,-(SP) ;;:GET # OF FILLER CHARS. NEEDED
6824                          ;;:AND THE NULL CHAR.
6825 023174 105366 000001      7$: DECB     1(SP)    ;;:DOES A NULL NEED TO BE TYPED?
6826 023200 002770              BLT     6$          ;;:BR IF NO--GO POP THE NULL OFF OF STACK
6827 023202 004737 023240      JSR      PC,$TYPEC  ;;:GO TYPE A NULL
6828 023206 105337 023304      DECB     $CHARCNT    ;;:DO NOT COUNT AS A COUNT
6829 023212 000770              BR      7$          ;;:LOOP
6830
6831
6832
6833
6834 023214 112716 000040      8$: MOVB     #' ,(SP)  ;;:REPLACE TAB WITH SPACE
6835 023220 004737 023240      9$: JSR      PC,$TYPEC  ;;:TYPE A SPACE
6836 023224 132737 000007 023304  BITB     #7,$CHARCNT ;;:BRANCH IF NOT AT
6837 023232 001372              BNE     9$          ;;:TAB STOP
6838 023234 005726              TST     (SP)+       ;;:TAB STOP
6839 023236 000724              BR      2$          ;;:POP SPACE OFF STACK
6840 023240 105777 155704      $TYPEC: TSTB  $STPS    ;;:GET NEXT CHARACTER
6841 023244 100375              BPL     $TYPEC      ;;:WAIT UNTIL PRINTER IS READY
6842 023246 116677 000002 155676  MOVB     2(SP),@STPB  ;;:LOAD CHAR TO BE TYPED INTO DATA REG.
6843 023254 122766 000015 000002  CMPB     #CR,2(SP)   ;;:IS CHARACTER A CARRIAGE RETURN?
6844 023262 001003              BNE     1$          ;;:BRANCH IF NO
6845 023264 105037 023304      CLRB     $CHARCNT    ;;:YES--CLEAR CHARACTER COUNT
6846 023270 000406              BR      $TYPEC      ;;:EXIT
6847 023272 122766 000012 000002  1$: CMPB     #LF,2(SP) ;;:IS CHARACTER A LINE FEED?
6848 023300 001402              BEQ     $TYPEC      ;;:BRANCH IF YES
6849 023302 105227              INCB     (PC)+       ;;:COUNT THE CHARACTER
6850 023304 000000      $CHARCNT: .WORD 0    ;;:CHARACTER COUNT STORAGE
6851 023306 000207      $STPLX: RTS     PC
6852
6853 .SBTTL CONVERT BINARY TO DECIMAL AND TYPE ROUTINE

```

```

6854
6855
6856
6857
6858
6859
6860
6861
6862
6863
6864
6865 023310
6866 023310 010046
6867 023312 010146
6868 023314 010246
6869 023316 010346
6870 023320 010546
6871 023322 012746 020200
6872 023326 016605 000020
6873 023332 100004
6874 023334 005405
6875 023336 112766 000055 000001
6876 023344 005000
6877 023346 012703 023524
6878 023352 112723 000040
6879 023356 005002
6880 023360 016001 023514
6881 023364 160105
6882 023366 002402
6883 023370 005202
6884 023372 000774
6885 023374 060105
6886 023376 005702
6887 023400 001002
6888 023402 105716
6889 023404 100407
6890 023406 106316
6891 023410 103003
6892 023412 116663 000001 177777
6893 023420 052702 000060
6894 023424 052702 000040
6895 023430 110223
6896 023432 005720
6897 023434 020027 000010
6898 023440 002746
6899 023442 003002
6900 023444 010502
6901 023446 000764
6902 023450 105726
6903 023452 100003
6904 023454 116663 177777 177776
6905 023462 105013
6906 023464 012605
6907 023466 012603
6908 023470 012602
6909 023472 012601

```

```

;*****
;THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 5-DIGIT
;SIGNED DECIMAL (ASCII) NUMBER AND TYPE IT. DEPENDING ON WHETHER THE
;NUMBER IS POSITIVE OR NEGATIVE A SPACE OR A MINUS SIGN WILL BE TYPED
;BEFORE THE FIRST DIGIT OF THE NUMBER. LEADING ZEROS WILL ALWAYS BE
;REPLACED WITH SPACES.
;CALL:
;* MOV NUM,-(SP) ;PUT THE BINARY NUMBER ON THE STACK
;* TYPDS ;GO TO THE ROUTINE
$TYPDS:
MOV R0,-(SP) ;PUSH R0 ON STACK
MOV R1,-(SP) ;PUSH R1 ON STACK
MOV R2,-(SP) ;PUSH R2 ON STACK
MOV R3,-(SP) ;PUSH R3 ON STACK
MOV R5,-(SP) ;PUSH R5 ON STACK
MOV #20200,-(SP) ;SET BLANK SWITCH AND SIGN
MOV 20(SP),R5 ;GET THE INPUT NUMBER
BPL 1$ ;BR IF INPUT IS POS.
NEG R5 ;MAKE THE BINARY NUMBER POS.
MOVB #'-,(1(SP)) ;MAKE THE ASCII NUMBER NEG.
1$: CLR R0 ;ZERO THE CONSTANTS INDEX
MOV #SDBLK,R3 ;SETUP THE OUTPUT POINTER
MOVB #' ,(R3)+ ;SET THE FIRST CHARACTER TO A BLANK
2$: CLR R2 ;CLEAR THE BCD NUMBER
MOV SDBTL(R0),R1 ;GET THE CONSTANT
3$: SUB R1,R5 ;FORM THIS BCD DIGIT
BLT 4$ ;BR IF DONE
INC R2 ;INCREASE THE BCD DIGIT BY 1
BR 3$
4$: ADD R1,R5 ;ADD BACK THE CONSTANT
TST R2 ;CHECK IF BCD DIGIT=0
BNE 5$ ;FALL THROUGH IF 0
TSTB (SP) ;STILL DOING LEADING 0'S?
BMI 7$ ;BR IF YES
5$: ASLB (SP) ;MSD?
BCC 6$ ;BR IF NO
MOVB 1(SP),-1(R3) ;YES--SET THE SIGN
6$: BIS #0,R2 ;MAKE THE BCD DIGIT ASCII
7$: BIS #' ,R2 ;MAKE IT A SPACE IF NOT ALREADY A DIGIT
MOVB R2,(R3)+ ;PUT THIS CHARACTER IN THE OUTPUT BUFFER
(RO)+ ;JUST INCREMENTING
CMP R0,#10 ;CHECK THE TABLE INDEX
BLT 2$ ;GO DO THE NEXT DIGIT
BGT 8$ ;GO TO EXIT
MOV R5,R2 ;GET THE LSD
BR 6$ ;GO CHANGE TO ASCII
8$: TSTB (SP)+ ;WAS THE LSD THE FIRST NON-ZERO?
BPL 9$ ;BR IF NO
MOVB -1(SP),-2(R3) ;YES--SET THE SIGN FOR TYPING
9$: CLRB (R3) ;SET THE TERMINATOR
MOV (SP)+,R5 ;POP STACK INTO R5
MOV (SP)+,R3 ;POP STACK INTO R3
MOV (SP)+,R2 ;POP STACK INTO R2
MOV (SP)+,R1 ;POP STACK INTO R1

```

```

6910 023474 012600
6911 023476 104401 023524
6912 023502 016666 000002 000004
6913 023510 012616
6914 023512 000002
6915 023514 023420
6916 023516 001750
6917 023520 000144
6918 023522 000012
6919 023524 000004
6920
6921
6922
6923
6924
6925
6926
6927
6928
6929
6930
6931
6932
6933
6934
6935
6936
6937
6938
6939
6940
6941
6942
6943
6944
6945
6946 023534 017646 000000
6947 023540 116637 000001 023757
6948 023546 112637 023761
6949 023552 062716 000002
6950 023556 000406
6951 023560 112737 000001 023757
6952 023566 112737 000006 023761
6953 023574 112737 000005 023756
6954 023602 010346
6955 023604 010446
6956 023606 010546
6957 023610 113704 023761
6958 023614 005404
6959 023616 062704 000006
6960 023622 110437 023760
6961 023626 113704 023757
6962 023632 016605 000012
6963 023636 005003
6964 023640 006105
6965 023642 000404

```

```

MOV (SP)+,R0 ;POP STACK INTO R0
TYPE ,SDBLK ;NOW TYPE THE NUMBER
MOV 2(SP),4(SP) ;ADJUST THE STACK
MOV (SP)+,(SP)
RTI ;RETURN TO USER
SDBTL: 10000.
1000.
100.
10.
SDBLK: .BLKW 4
.SBTL BINARY TO DCTAL (ASCII) AND TYPE
;*****
;THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 6-DIGIT
;OCTAL (ASCII) NUMBER AND TYPE IT.
;STYPOS---ENTER HERE TO SETUP SUPPRESS ZEROS AND NUMBER OF DIGITS TO TYPE
;CALL:
;* MOV NUM,-(SP) ;NUMBER TO BE TYPED
;* TYPON ;CALL FOR TYPEOUT
;* .BYTE N ;N=1 TO 6 FOR NUMBER OF DIGITS TO TYPE
;* .BYTE M ;M=1 OR 0
;* ;1=TYPE LEADING ZEROS
;* ;0=SUPPRESS LEADING ZEROS
;*STYPON---ENTER HERE TO TYPE OUT WITH THE SAME PARAMETERS AS THE LAST
;*STYPOS OR STYPOC
;CALL:
;* MOV NUM,-(SP) ;NUMBER TO BE TYPED
;* TYPON ;CALL FOR TYPEOUT
;*STYPOC---ENTER HERE FOR TYPEOUT OF A 16 BIT NUMBER
;CALL:
;* MOV NUM,-(SP) ;NUMBER TO BE TYPED
;* TYPOC ;CALL FOR TYPEOUT
$TYPOS: MOV @(SP),-(SP) ;PICKUP THE MODE
MOVB 1(SP),SOFILL ;LOAD ZERO FILL SWITCH
MOVB (SP)+,$MODE+1 ;NUMBER OF DIGITS TO TYPE
ADD #2,(SP) ;ADJUST RETURN ADDRESS
BR $TYPON
$TYPOC: MOVB #1,SOFILL ;SET THE ZERO FILL SWITCH
MOVB #6,$MODE+1 ;SET FOR SIX(6) DIGITS
$TYPON: MOVB #5,SOCNT ;SET THE ITERATION COUNT
MOV R3,-(SP) ;SAVE R3
MOV R4,-(SP) ;SAVE R4
MOV R5,-(SP) ;SAVE R5
MOVB $MODE+1,R4 ;GET THE NUMBER OF DIGITS TO TYPE
NEG R4
ADD #6,R4 ;SUBTRACT IT FOR MAX. ALLOWED
MOV R4,$MODE ;SAVE IT FOR USE
MOVB $OFILL,R4 ;GET THE ZERO FILL SWITCH
MOV 12(SP),R5 ;PICKUP THE INPUT NUMBER
1$: CLR R3 ;CLEAR THE OUTPUT WORD
ROL R5 ;ROTATE MSB INTO "C"
BR 3$ ;GO DO MSB

```

```

6966 023644 006105      25:  ROL  R5          ;;FORM THIS DIGIT
6967 023646 006105      ROL  R5
6968 023650 006105      ROL  R5
6969 023652 010503      MOV  R5,R3
6970 023654 006103      35:  ROL  R3          ;;GET LSB OF THIS DIGIT
6971 023656 105337      DECB $OMODE      ;;TYPE THIS DIGIT?
6972 023662 100016      BPL  7$          ;;BR IF NO
6973 023664 042703      BIC  #177770,R3 ;;GET RID OF JUNK
6974 023670 001002      BNE  4$          ;;TEST FOR 0
6975 023672 005704      TST  R4          ;;SUPPRESS THIS 0?
6976 023674 001403      BEQ  5$          ;;BR IF YES
6977 023676 005204      INC  R4          ;;DON'T SUPPRESS ANYMORE 0'S
6978 023700 052703      BIS  #'0,R3      ;;MAKE THIS DIGIT ASCII
6979 023704 052703      BIS  #'1,R3      ;;MAKE ASCII IF NOT ALREADY
6980 023710 110337      MOVB R3,B$       ;;SAVE FOR TYPING
6981 023714 104401      TYPE ,B$        ;;GO TYPE THIS DIGIT
6982 023720 105337      75:  DECB $OCNT    ;;COUNT BY 1
6983 023724 003347      BGT  2$          ;;BR IF MORE TO DO
6984 023726 002402      BLT  6$          ;;BR IF DONE
6985 023730 005204      INC  R4          ;;INSURE LAST DIGIT ISN'T A BLANK
6986 023732 000744      BR   2$          ;;GO DO THE LAST DIGIT
6987 023734 012605      65:  MOV  (SP)+,R5   ;;RESTORE R5
6988 023736 012604      MOV  (SP)+,R4   ;;RESTORE R4
6989 023740 012603      MOV  (SP)+,R3   ;;RESTORE R3
6990 023742 016666      MOV  2(SP),4(SP) ;;SET THE STACK FOR RETURNING
6991 023750 012616      MOV  (SP)+,(SP)
6992 023752 000002      RTI             ;;RETURN
6993 023754 000     85:  .BYTE  0        ;;STORAGE FOR ASCII DIGIT
6994 023755 000     .BYTE  0        ;;TERMINATOR FOR TYPE ROUTINE
6995 023756 000     $OCNT: .BYTE  0        ;;OCTAL DIGIT COUNTER
6996 023757 000     $OFILL: .BYTE  0       ;;ZERO FILL SWITCH
6997 023760 000000     $OMODE: .WORD  0       ;;NUMBER OF DIGITS TO TYPE
6998
6999
7000
7001
7002
7003
7004
7005
7006
7007
7008
7009 023762 022737 000176 001140  SCKSWR: CMP  #SWREG,SWR    ;;IS THE SOFT-SWR SELECTED?
7010 023770 031074      BNE  15$         ;;BRANCH IF NO
7011 023772 105777 155146      TSTB @STKS      ;;CHAR THERE?
7012 023776 103071      BPL  15$         ;;IF NO, DON'T WAIT AROUND
7013 024000 117746 155142      MOVB @STKB,-(SP) ;;SAVE THE CHAR
7014 024004 042716 177800      BIC  #'C177,(SP) ;;STRIP-OFF THE ASCII
7015 024010 022726 000007      CMP  #7,(SP)+   ;;IS IT A CONTROL G?
7016 024014 001062      BNE  15$         ;;NO, RETURN TO USER
7017 024016 123727 001136 000001  CMPB $AUTOB,#1  ;;ARE WE RUNNING IN AUTO-MODE?
7018 024024 001456      BEQ  15$         ;;BRANCH IF YES
7019
7020 024026 104401 024647      TYPE , $CNTLG   ;;ECHO THE CONTROL-G (^G)
7021 024032 104401 024654      SGTSWR: TYPE , $MSWR    ;;TYPE CURRENT CONTENTS

```

.SBTTL TTY INPUT ROUTINE

```

;*****
;ENABL LSB
;*****
;*SOFTWARE SWITCH REGISTER CHANGE ROUTINE.
;*ROUTINE IS ENTERED FROM THE TRAP HANDLER, AND WILL
;*SERVICE THE TEST FOR CHANGE IN SOFTWARE SWITCH REGISTER CALL
;*WHEN OPERATING IN TTY FLAG MODE.
SCKSWR: CMP  #SWREG,SWR    ;;IS THE SOFT-SWR SELECTED?
        BNE  15$         ;;BRANCH IF NO
        TSTB @STKS      ;;CHAR THERE?
        BPL  15$         ;;IF NO, DON'T WAIT AROUND
        MOVB @STKB,-(SP) ;;SAVE THE CHAR
        BIC  #'C177,(SP) ;;STRIP-OFF THE ASCII
        CMP  #7,(SP)+   ;;IS IT A CONTROL G?
        BNE  15$         ;;NO, RETURN TO USER
        CMPB $AUTOB,#1  ;;ARE WE RUNNING IN AUTO-MODE?
        BEQ  15$         ;;BRANCH IF YES
SGTSWR: TYPE , $CNTLG   ;;ECHO THE CONTROL-G (^G)
        TYPE , $MSWR    ;;TYPE CURRENT CONTENTS

```

```

7022 024036 013746 000176      MOV  SWREG,-(SP) ;;SAVE SWREG FOR TYP/OUT
7023 024042 104402      TYPCC      ;;GO TYPE--OCTAL ASCII(ALL DIGITS)
7024 024044 104401 024665      TYPE , $MNEW    ;;PROMPT FOR NEW SWR
7025 024050 005046      195: CLR  -(SP)     ;;CLEAR COUNTER
7026 024052 005046      CLR  -(SP)     ;;THE NEW SWR
7027 024054 105777 155054      75:  TSTB @STKS   ;;CHAR THERE?
7028 024060 100375      BPL  7$        ;;IF NOT TRY AGAIN
7029
7030 024062 117746 155660      MOVB @STKB,-(SP) ;;PICK UP CHAR
7031 024066 042716 177600      BIC  #'C177,(SP) ;;MAKE IT 7-BIT ASCII
7032
7033
7034
7035 024072 021627 000025      95:  CMP  (SP),#25  ;;IS IT A CONTROL-U?
7036 024076 001005      BNE  10$       ;;BRANCH IF NOT
7037 024100 104401 024842      TYPE , $CNTLU  ;;YES, ECHO CONTROL-U (^U)
7038 024104 062706 000006      205: ADD  #6,SP     ;;IGNORE PREVIOUS INPUT
7039 024110 000757      BR   19$      ;;LET'S TRY IT AGAIN
7040
7041
7042 024112 021627 000015      105: CMP  (SP),#15  ;;IS IT A <CR>?
7043 024116 001022      BNE  16$       ;;BRANCH IF NO
7044 024120 005766 000004      TST  4(SP)     ;;YES, IS IT THE FIRST CHAR?
7045 024124 001403      BEQ  11$       ;;BRANCH IF YES
7046 024126 018677 000002 155004  MOV  2(SP),@SWR ;;SAVE NEW SWR
7047 024134 062706 000006      115: ADD  #6,SP     ;;CLEAR UP STACK
7048 024140 104401 001213      145: TYPE , $CRLF  ;;ECHO <CR> AND <LF>
7049 024144 123727 001135 000001  CMPB $INTAG,#1  ;;RE-ENABLE TTY KBD INTERRUPTS?
7050 024152 001003      BNE  15$       ;;BRANCH IF NOT
7051 024154 012777 000100 154762  MOV  #100,@STKS ;;RE-ENABLE TTY KBD INTERRUPTS
7052 024162 000002      155: RTI             ;;RETURN
7053 024164 004737 023240      165: JSR  PC,$TYPEC  ;;ECHO CHAR
7054 024170 021627 000060      CMP  (SP),#60  ;;CHAR < 0?
7055 024174 002420      BLT  18$       ;;BRANCH IF YES
7056 024176 021627 000067      CMP  (SP),#67  ;;CHAR > 7?
7057 024202 003015      BGT  18$       ;;BRANCH IF YES
7058 024204 042726 000060      BIC  #60,(SP)+ ;;STRIP-OFF ASCII
7059 024210 005766 000002      TST  2(SP)     ;;IS THIS THE FIRST CHAR
7060 024214 001403      BEQ  17$       ;;BRANCH IF YES
7061 024216 006316      ASL  (SP)      ;;NO, SHIFT PRESENT
7062 024220 006316      ASL  (SP)      ;; CHAR OVER TO MAKE
7063 024222 006316      ASL  (SP)      ;; ROOM FOR NEW ONE.
7064 024224 005266 000062 175:  INC  2(SP)     ;;KEEP COUNT OF CHAR
7065 024230 056616 177776      BIS  -2(SP),(SP) ;;SET IN NEW CHAR
7066 024234 000707      BR   7$        ;;GET THE NEXT ONE
7067 024236 104401 001212      185: TYPE , $QUES  ;;TYPE ?<CR><LF>
7068 024242 000720      BR   20$      ;;SIMULATE CONTROL-U
7069
7070
7071
7072
7073
7074
7075
7076
7077
;*****
;THIS ROUTINE WILL INPUT A SINGLE CHARACTER FROM THE TTY
;CALL
;RDCHR      ;;INPUT A SINGLE CHARACTER FROM THE TTY
;RETURN HERE ;;CHARACTER IS ON THE STACK
;          ;;WITH PARITY BIT STRIPPED OFF

```



```

7078 ;
7079 ;
7080 024244 011646 $RDCHR: MOV (SP),-(SP) ;;PUSH DOWN THE PC
7081 024246 016666 000004 000002 MOV 4(SP),2(SP) ;;SAVE THE PS
7082 024254 105777 154664 1$: TSTB @STKS ;;WAIT FOR
7083 024260 100375 BPL 1$ ;;A CHARACTER
7084 024262 117766 154660 000004 MOVVB @STKB,4(SP) ;;READ THE TTY
7085 024270 042766 177600 000004 BIC #~C<177>,4(SP) ;;GET RID OF JUNK IF ANY
7086 024276 026627 000004 000023 CMP 4(SP),#23 ;;IS IT A CONTROL-S?
7087 024304 001013 BNE 3$ ;;BRANCH IF NO
7088 024306 105777 154632 2$: TSTB @STKS ;;WAIT FOR A CHARACTER
7089 024312 100375 BPL 2$ ;;LOOP UNTIL ITS THERE
7090 024314 117746 154626 MOVVB @STKB,-(SP) ;;GET CHARACTER
7091 024320 042716 177600 BIC #~C177,(SP) ;;MAKE IT 7-BIT ASCII
7092 024324 026627 000021 CMP (SP)+,#21 ;;IS IT A CONTROL-Q?
7093 024330 001366 BNE 2$ ;;IF NOT DISCARD IT
7094 024332 000750 BR 1$ ;;YES, RESUME
7095 024334 026627 000004 000140 3$: CMP 4(SP),#140 ;;IS IT UPPER CASE?
7096 024342 002407 BLT 4$ ;;BRANCH IF YES
7097 024344 026627 000004 000175 CMP 4(SP),#175 ;;IS IT A SPECIAL CHAR?
7098 024352 003003 BGT 4$ ;;BRANCH IF YES
7099 024354 042766 000040 000004 BIC #40,4(SP) ;;MAKE IT UPPER CASE
7100 024362 000002 4$: RTI ;;GO BACK TO USER
7101 ;*****
7102 ;*THIS ROUTINE WILL INPUT A STRING FROM THE TTY
7103 ;*CALL:
7104 ;* RDLIN RDLIN ;;INPUT A STRING FROM THE TTY
7105 ;* RETURN HERE RETURN HERE ;;ADDRESS OF FIRST CHARACTER WILL BE ON THE STACK
7106 ;* ;* ;;TERMINATOR WILL BE A BYTE OF ALL 0'S
7107 ;
7108 024364 010346 $RDLIN: MOV R3,-(SP) ;;SAVE R3
7109 024366 005046 CLR -(SP) ;;CLEAR THE RUBOUT KEY
7110 024370 012703 024620 1$: MOV #TTYIN,R3 ;;GET ADDRESS
7111 024374 022703 024642 2$: CMP #TTYIN+22,R3 ;;BUFFER FULL?
7112 024400 101456 BLOS 4$ ;;BR IF YES
7113 024402 104410 RDCHR (SP)+,(R3) ;;GO READ ONE CHARACTER FROM THE TTY
7114 024404 112613 MOVVB (SP)+,(R3) ;;GET CHARACTER
7115 024406 122713 000177 10$: CMPB #177,(R3) ;;IS IT A RUBOUT
7116 024412 001022 BNE 5$ ;;BR IF NO
7117 024414 005716 TST (SP) ;;IS THIS THE FIRST RUBOUT?
7118 024416 001007 BNE 6$ ;;BR IF NO
7119 024420 112737 000134 024616 MOVVB #'\",9$ ;;TYPE A BACK SLASH
7120 024426 104401 024616 TYPE ,9$
7121 024432 012716 177777 MOV #-1,(SP) ;;SET THE RUBOUT KEY
7122 024436 005303 6$: DEC R3 ;;BACKUP BY ONE
7123 024440 020327 024620 CMP R3,#TTYIN ;;STACK EMPTY?
7124 024444 103434 BLO 4$ ;;BR IF YES
7125 024446 111337 024616 MOVVB (R3),9$ ;;SETUP TO TYPEOUT THE DELETED CHAR.
7126 024452 104401 024616 TYPE ,9$ ;;GO TYPE
7127 024456 000746 BR 2$ ;;GO READ ANOTHER CHAR.
7128 024460 005716 5$: TST (SP) ;;RUBOUT KEY SET?
7129 024462 001406 BEQ 7$ ;;BR IF NO
7130 024464 112737 000134 024616 MOVVB #'\",9$ ;;TYPE A BACK SLASH
7131 024472 104401 024616 TYPE ,9$
7132 024476 005016 CLR (SP) ;;CLEAR THE RUBOUT KEY
7133 024500 122713 000025 7$: CMPB #25,(R3) ;;IS CHARACTER A CTRL U?
    
```

```

7134 024504 001003 BNE 8$ ;;BR IF NO
7135 024506 104401 024642 TYPE ,SCNTLU ;;TYPE A CONTROL "U"
7136 024512 000726 BR 1$ ;;GO START OVER
7137 024514 122713 000022 9$: CMPB #22,(R3) ;;IS CHARACTER A "R"?
7138 024520 001011 BNE 3$ ;;BRANCH IF NO
7139 024522 105013 CLRFB (R3) ;;CLEAR THE CHARACTER
7140 024524 104401 001213 TYPE ,SCRLF ;;TYPE A "CR" & "LF"
7141 024530 104401 024620 TYPE ,TTYIN ;;TYPE THE INPUT STRING
7142 024534 000717 BR 2$ ;;GO PICKUP ANOTHER CHARACTER
7143 024536 104401 001212 4$: TYPE ,SQUES ;;TYPE A '?'
7144 024542 000712 BR 1$ ;;CLEAR THE BUFFER AND LOOP
7145 024544 111337 024616 3$: MOVVB (R3),9$ ;;ECHO THE CHARACTER
7146 024550 104401 024616 TYPE ,9$
7147 024554 122723 000015 CMPB #15,(R3)+ ;;CHECK FOR RETURN
7148 024560 001305 BNE 2$ ;;LOOP IF NOT RETURN
7149 024562 105063 177777 CLRFB -1(R3) ;;CLEAR RETURN (THE 15)
7150 024566 104401 001214 TYPE ,SLF ;;TYPE A LINE FEED
7151 024572 005726 TST (SP)+ ;;CLEAN RUBOUT KEY FROM THE STACK
7152 024574 012603 MOV (SP)+,R3 ;;RESTORE R3
7153 024576 011646 MOV (SP),-(SP) ;;ADJUST THE STACK AND PUT ADDRESS OF THE
7154 024600 016666 000004 000002 MOV 4(SP),2(SP) ;; FIRST ASCII CHARACTER ON IT
7155 024606 012766 024620 000004 MOV #TTYIN,4(SP)
7156 024614 000002 RTI ;;RETURN
7157 024616 000 9$: .BYTE 0 ;;STORAGE FOR ASCII CHAR. TO TYPE
7158 024617 000 .BYTE 0 ;;TERMINATOR
7159 024620 000022 $TTYIN: .BLKB 22 ;;RESERVE 22 BYTES FOR TTY INPUT
7160 024642 052536 005015 000 SCNTLU: .ASCIZ /~U/<15><12> ;;CONTROL "U"
7161 024647 136 006507 000012 SCNTLG: .ASCIZ /~G/<15><12> ;;CONTROL "G"
7162 024654 005015 053523 020122 $MSWR: .ASCIZ <15><12>/SWR = /
7163 024662 020075 000
7164 024665 040 047040 053505 $MNEW: .ASCIZ / NEW = /
7165 024672 036440 000040
7166 ;CONTROL U, RUBOUT CAPABILITY
7167 .SBTTL TRAP DECODER
7168 ;
7169 ;*****
7170 ;*THIS ROUTINE WILL PICKUP THE LOWER BYTE OF THE "TRAP" INSTRUCTION
7171 ;*AND USE IT TO INDEX THROUGH THE TRAP TABLE FOR THE STARTING ADDRESS
7172 ;*OF THE DESIRED ROUTINE. THEN USING THE ADDRESS OBTAINED IT WILL
7173 ;*GO TO THAT ROUTINE.
7174 ;
7175 024676 010046 $TRAP: MOV R0,-(SP) ;;SAVE R0
7176 024700 016600 000002 MOV 2(SP),R0 ;;GET TRAP ADDRESS
7177 024704 005740 TST -(R0) ;;BACKUP BY 2
7178 024706 111000 MOVVB (R0),R0 ;;GET RIGHT BYTE OF TRAP
7179 024710 006300 ASL R0 ;;POSITION FOR INDEXING
7180 024712 016000 024732 MOV $TRPAD(R0),R0 ;;INDEX TO TABLE
7181 024716 000200 RTS R0 ;;GO TO ROUTINE
7182 ;
7183 ;
7184 ;
7185 ;
7186 024720 011646 $TRAP2: MOV (SP),-(SP) ;;MOVE THE PC DOWN
7187 024722 016666 000004 000002 MOV 4(SP),2(SP) ;;MOVE THE PSW DOWN
7188 024730 000002 RTI ;;RESTORE THE PSW
7189 ;
    
```

```

7190 .SBTTL TRAP TABLE
7191 ;THIS TABLE CONTAINS THE STARTING ADDRESSES OF THE ROUTINES CALLED
7192 ;BY THE "TRAP" INSTRUCTION.
7193
7194 ;
7195 ; ROUTINE
7196 ;-----
7197 024732 024720 STRPAD: .WORD STRAP2
7198 024734 023070 $TYPE ;;CALL=TYPE TRAP+1(104401) TTY TYPEOUT ROUTINE
7199 024736 023560 $TYPOC ;;CALL=TYPOC TRAP+2(104402) TYPE OCTAL NUMBER (WITH LEADING ZEROS)
7200 024740 023534 $TYPOS ;;CALL=TYPOS TRAP+3(104403) TYPE OCTAL NUMBER (NO LEADING ZEROS)
7201 024742 023574 $TYPON ;;CALL=TYPON TRAP+4(104404) TYPE OCTAL NUMBER (AS PER LAST CALL)
7202 024744 023310 $TYPDS ;;CALL=TYPDS TRAP+5(104405) TYPE DECIMAL NUMBER (WITH SIGN)
7203
7204 024746 024032 $GTSWR ;;CALL=GTSWR TRAP+6(104406) GET SOFT-SWR SETTING
7205
7206 024750 023762 $CKSWR ;;CALL=CKSWR TRAP+7(104407) TEST FOR CHANGE IN SOFT-SWR
7207 024752 024244 $RDCHR ;;CALL=RDCHR TRAP+10(104410) TTY TYPEIN CHARACTER ROUTINE
7208 024754 024364 $RDLIN ;;CALL=RDLIN TRAP+11(104411) TTY TYPEIN STRING ROUTINE
7209
7210 024756 021760 CH.CRDY ;;CALL=CHKCRDY TRAP+12(104412) CHECK CONTROL READY
7211
7212 024760 022014 CN.RST ;;CALL=CNTR.RESET TRAP+13(104413) CONTROL RESET ROUTINE
7213
7214 024762 022032 CN.RDY ;;CALL=CNTR.RDY TRAP+14(104414) WAIT FOR CNTRL RDY TO SET
7215
7216 024764 021056 BDA0 ;;CALL=BRKDA0 TRAP+15(104415) BREAK RKDA INTO DR #,CYL,SUR,SEC BITS
7217
7218 024766 021066 BDA4 ;;CALL=BRKDA4 TRAP+16(104416) BREAK RKDA INTO DR #,CYL,SUP,SEC BITS
7219
7220 024770 021664 DELA.Y ;;CALL=DELAY TRAP+17(104417) TIME DELAY ROUTINE
7221
7222 024772 021706 WATINT ;;CALL=WAT.INT TRAP+20(104420) WAIT FOR RK11 INTERRUPT ROUTINE
7223
7224 024774 021572 TSTSIN ;;CALL=TST.SIN TRAP+21(104421) TEST SIN ROUTINE
7225
7226
7227 .SBTTL POWER DOWN AND UP ROUTINES
7228
7229 ;*****
7230 ;POWER DOWN ROUTINE
7231 024776 012737 025142 000024 $PWRDN: MOV #SILLUP,@#PWRVEC ;;SET FOR FAST UP
7232 025004 012737 000340 000026 MOV #340,@#PWRVEC+2 ;;PRIO:7
7233 025012 010046 MOV R0,-(SP) ;;PUSH R0 ON STACK
7234 025014 010146 MOV R1,-(SP) ;;PUSH R1 ON STACK
7235 025016 010246 MOV R2,-(SP) ;;PUSH R2 ON STACK
7236 025020 010346 MOV R3,-(SP) ;;PUSH R3 ON STACK
7237 025022 010446 MOV R4,-(SP) ;;PUSH R4 ON STACK
7238 025024 010546 MOV R5,-(SP) ;;PUSH R5 ON STACK
7239 025026 017746 154106 MOV @SWR,-(SP) ;;PUSH @SWR ON STACK
7240 025032 010537 025146 MOV SP,$SAVR6 ;;SAVE SP
7241 025036 012737 025050 000024 MOV $PWRUP,@#PWRVEC ;;SET UP VECTOR
7242 025044 000000 HALT
7243 025046 000776 BR -2 ;;HANG UP
7244
7245 ;*****

```

```

7246 ;POWER UP ROUTINE
7247 025050 012737 025142 000024 $PWRUP: MOV #SILLUP,@#PWRVEC ;;SET FOR FAST DOWN
7248 025056 013706 025146 MOV $SAVR6,SP ;;GET SP
7249 025062 003037 025146 CLR $SAVR6 ;;WAIT LDDP FOR THE TTY
7250 025068 005237 025146 1$: INC $SAVR6 ;;WAIT FOR THE INC
7251 025072 001375 BNE 1$ ;;OF WORD
7252 025074 012677 154040 MOV (SP)+,@SWR ;;POP STACK INTO @SWR
7253 025100 012605 MOV (SP)+,R5 ;;POP STACK INTO R5
7254 025102 012604 MOV (SP)+,R4 ;;POP STACK INTO R4
7255 025104 012603 MOV (SP)+,R3 ;;POP STACK INTO R3
7256 025106 012602 MOV (SP)+,R2 ;;POP STACK INTO R2
7257 025110 012601 MOV (SP)+,R1 ;;POP STACK INTO R1
7258 025112 012600 MOV (SP)+,R0 ;;POP STACK INTO R0
7259 025114 012737 024776 000024 MOV $PWRDN,@#PWRVEC ;;SET UP THE POWER DOWN VECTOR
7260 025122 012737 000340 000026 MOV #340,@#PWRVEC+2 ;;PRIO:7
7261 025130 104401 TYPE ;;REPORT THE POWER FAILURE
7262 025132 025150 $PWRMG: .WORD $POWER ;;POWER FAIL MESSAGE POINTER
7263 025134 012716 MOV (PC)+,(SP) ;;RESTART AT PFSTRT
7264 025136 004702 $PWRAD: .WORD PFSTRT ;;RESTART ADDRESS
7265 025140 000002 RTI
7266 025142 000000 $ILLUP: HALT ;;THE POWER UP SEQUENCE WAS STARTED
7267 025144 000776 BR -2 ;;BEFORE THE POWER DOWN WAS COMPLETE
7268 025146 000000 $SAVR6: 0
7269 025150 005015 047520 042527 $POWER: .ASCIZ <15><12>*POWER*
7270 025156 000122 .EVEN
7271
7272
7273 025160 004737 021504 FCHECK: JSR PC,DRESET ;;RESETB DRIVE
7274 025164 104026 ERROR 26
7275 025166 104413 CNT.RESET
7276 025170 013737 001350 025302 MOV DRIVAD,DRHOLD ;;SAVE DRIVE ADDR
7277 025176 032737 020000 001350 BIT #20000,DRIVAD ;;SEE IF ODD
7278 025204 001404 BEQ 1$
7279 025206 042737 020000 001350 BIC #20000,DRIVAD ;;MAKE EVEN
7280 025214 000403 BR 2$
7281 025216 052737 020000 001350 1$: BIS #20000,DRIVAD ;;MAKE ODD
7282 025224 013777 001350 154106 2$: MOV DRIVAD,@RKDA ;;DRIVE ADDR
7283 025232 012777 000011 154072 MOV #11,@RKCS ;;DRIVE SEEK
7284 025240 104414 CNT.RDY
7285 025242 013777 025302 154070 MOV DRHOLD,@RKDA ;;OTHER DRIVE
7286 025250 104414 CNT.RDY
7287 025252 032777 000100 154046 BIT #100,@RKDS ;;HEAEDS IN MOTION?
7288 025260 001001 BNE 3$ ;;NO SO RK-05J
7289 025262 005725 TST (R5)+ ;;YES RK-05F
7290 025264 013737 025302 001350 3$: MOV DRHOLD,DRIVAD ;;RESTORE ADDR
7291 025272 004737 021504 JSR PC,DRESET ;;WAIT FOR RESET
7292 025276 104026 ERROR 26
7293 025300 000205 RTS R5
7294 025302 000000 DRHOLD: 0
7295 025304 005037 001350 SIZEF: CLR DRIVAD ;;START AT DRO
7296 025310 012700 001414 MOV #DRIVO,R0 ;;TABLE OF AVAIL DRIVES
7297 025314 005710 4$: TST (R0) ;;THIS DRIVE HERE?
7298 025316 001413 BEQ 2$ ;;NO
7299 025320 005760 000002 TST 2(R0) ;;COMPLEMENT HERE?
7300 025324 001410 BEQ 2$ ;;NO
7301 025326 004537 025160 JSR R5,FCHECK ;;SEE IF F MOD'CL

```

```

7302 025332 000405          BR      2$          ;J MODEL
7303 025334 052710 100000    BIS      #100000,(R0) ;SET SIGN FOR F
7304 025340 052760 100000 000002  BIS      #100000,2(R0) ;BOTH DRIVES
7305 025346 005720          2$:      TST      (R0)+
7306 025350 005720          TST      (R0)+      ;NEXT PAIR OF DRIVES
7307 025352 062737 040000 001350  ADD      #40000,DRIVAD ;NEXT ACTUL ADDR
7308 025360 022700 001433    CMP      #DRIV7+1,R0  ;CHECKED ALL?
7309 025364 003353          BGT      4$          ;NOT YET
7310 025366 000207          RTS      PC
7311
7312          ;ERROR MESSAGES
7313
7314          .SBTTL  ERROR MESSAGES
7315
7316 025370 045522 041527 042440 EM11:  .ASCIZ  /RKWC EROR/
7317 025376 047522 000122
7318
7319
7320 025402 044523 020116 051511 EM12:  .ASCIZ  /SIN IS SET/
7321 025410 051440 052105 000
7322
7323 025415 122 041113 020101 EM13:  .ASCIZ  /RKBA EROR/
7324 025422 051105 051117 000
7325
7326 025427 122 042113 020101 EM16:  .ASCIZ  /RKDA WRONG AFTER 'SSE'/
7327 025434 051127 047117 020107
7328 025442 043101 042524 020122
7329 025450 051447 042523 000047
7330
7331 025456 045522 051504 042440 EM21:  .ASCIZ  /RKDS EROR/
7332 025464 047522 000122
7333
7334 025470 050104 020114 042523 EM30:  .ASCIZ  /DPL SET/
7335 025476 000124
7336
7337 025500 051104 020125 042523 EM31:  .ASCIZ  /DRU SET/
7338 025506 000124
7339
7340 025510 045522 032460 041040 EM32:  .ASCIZ  /RK05 BIT NOT SET/
7341 025516 052111 047040 052117
7342 025524 051440 052105 000
7343
7344 025531 104 054522 041040 EM33:  .ASCIZ  /DRY BIT NOT SET/
7345 025536 052111 047040 052117
7346 025544 051440 052105 000
7347
7348 025551 123 045517 042040 EM34:  .ASCIZ  /SOK DIDN'T SET/
7349 025556 042111 023516 020124
7350 025564 042523 000124
7351
7352 025570 042523 026503 047103 EM35:  .ASCIZ  /SEC-CNTR DIDN'T COUNT TO 0/
7353 025576 051124 042040 042111
7354 025604 023516 020124 047503
7355 025612 047125 020124 047524
7356 025620 030040 000
7357
    
```

```

7358 025623 123 041505 041455 EM36:  .ASCIZ  /SEC-CNTR DIDN'T INCRMNT/
7359 025630 052116 020122 044504
7360 025636 047104 052047 044440
7361 025644 041516 046522 052116
7362 025652 000
7363
7364 025653 123 041505 041455 EM37:  .ASCIZ  /SEC-COUNTR INCRMENTED WRONG/
7365 025660 052517 052116 020122
7366 025666 047111 051103 042515
7367 025674 052116 042105 053440
7368 025702 047522 043516 000
7369
7370 025707 104 042111 023516 EM40:  .ASCIZ  /DIDN'T GET SC=SA FOR THIS SECTR/
7371 025714 020124 042507 020124
7372 025722 041523 051475 020101
7373 025730 047506 020122 044124
7374 025736 051511 051440 041505
7375 025744 051124 000
7376
7377 025747 105 047522 026522 EM41:  .ASCIZ  *ERROR-R/W/S RDY SHOULD BE SET*
7378 025754 027522 027527 020123
7379 025762 042122 020131 044123
7380 025770 052517 042114 041040
7381 025776 020105 042523 000124
7382
7383 026004 047125 054105 042520 EM43:  .ASCIZ  /UNEXPECTED RK11 INTERRUPT/
7384 026012 052103 042105 051040
7385 026020 030513 020061 047111
7386 026026 042524 051122 050125
7387 026034 000124
7388
7389 026036 047103 051124 020114 EM44:  .ASCIZ  /CNTRL RDY DIDN'T SET AFTER SEEK OR DR RESET/
7390 026044 042122 020131 044504
7391 026052 047104 052047 051440
7392 026060 052105 040440 052106
7393 026066 051105 051440 042505
7394 026074 020113 051117 042040
7395 026102 020122 042522 042523
7396 026110 000124
7397
7398 026112 051105 020122 051117 EM45:  .ASCIZ  /ERR OR HE BIT SET ON SEEK OR DR RESET/
7399 026120 044040 020105 044502
7400 026126 020124 042523 020124
7401 026134 047117 051440 042505
7402 026142 020113 051117 042040
7403 026150 020122 042522 042523
7404 026156 000124
7405
7406 026160 045522 051105 041040 EM46:  .ASCIZ  /RKER BIT, ON SEEK OR DR RESET/
7407 026166 052111 020054 047117
7408 026174 051440 042505 020113
7409 026202 051117 042040 020122
7410 026210 042522 042523 000124
7411
7412 026216 045522 051503 041440 EM47:  .ASCIZ  /RKCS CHNGD AFTR FUNCTION WAS DONE/
7413 026224 047110 042107 040440
    
```

7414	026232	052106	020122	052506				
7415	026240	041516	044524	047117				
7416	026246	053440	051501	042040				
7417	026254	047117	000105					
7418								
7419	026260	027522	027527	020123	EM50:	.ASCIZ	"R/W/S RDY DIDN'T CLEAR"	
7420	026266	042122	020131	044504				
7421	026274	047104	052047	041440				
7422	026302	042514	051101	000				
7423								
7424	026307	122	053457	051457	EM51:	.ASCIZ	"R/W/S RDY DIDN'T SET AFTR SEEK OR DR RESET"	
7425	026314	051040	054504	042040				
7426	026322	042111	023516	020124				
7427	026330	042523	020124	043101				
7428	026336	051124	051440	042505				
7429	026344	020113	051117	042040				
7430	026352	020122	042522	042523				
7431	026360	000124						
7432								
7433	026362	045522	040504	041440	EM52:	.ASCIZ	/RKDA CHNGD AFTR SEEK/	
7434	026370	047110	042107	040440				
7435	026376	052106	020122	042523				
7436	026404	045505	000					
7437								
7438	026407	103	052116	046122	EM53:	.ASCIZ	/CNTRL RDY DIDN'T CLR AS GO WAS SET/	
7439	026414	051040	054504	042040				
7440	026422	042111	023516	020124				
7441	026430	046103	020122	051501				
7442	026436	043440	020117	040527				
7443	026444	020123	042523	000124				
7444								
7445	026452	047103	051124	020114	EM54:	.ASCIZ	"CNTRL RDY DIDN'T SET ON WRT/FMT STARTING FROM <DSK-ADRES>"	
7446	026460	042122	020131	044504				
7447	026466	047104	052047	051440				
7448	026474	052105	047440	020116				
7449	026502	051127	027524	046506				
7450	026510	020124	052123	051101				
7451	026516	044524	043516	043040				
7452	026524	047522	020115	042074				
7453	026532	045523	040455	051104				
7454	026540	051505	000076					
7455								
7456	026544	042510	047440	020122	EM55:	.ASCIZ	"HE OR ERR ON WRT/FMT STARTING FROM <DSK-ADRES>"	
7457	026552	051105	020122	047117				
7458	026560	053440	052122	043057				
7459	026566	052115	051440	040524				
7460	026574	052122	047111	020107				
7461	026602	051106	046517	036040				
7462	026610	051504	026513	042101				
7463	026616	042522	037123	000				
7464								
7465	026623	122	042113	02010	EM56:	.ASCIZ	/RKDA INCRMN TD WRONG ON WRT-FMT/	
7466	026630	047111	051103	047115				
7467	026636	042124	053440	047522				
7468	026644	043516	047440	020116				
7469	026652	051127	026524	046506				

7470	026660	000124						
7471								
7472	026662	045522	041527	042040	EM57:	.ASCIZ	/RKWC DIDN'T OVRFLD ON WRT FMT/	
7473	026670	042111	023516	020124				
7474	026676	053117	043122	047514				
7475	026704	047440	020116	051127				
7476	026712	020124	046506	000124				
7477								
7478	026720	045522	040502	044440	EM60:	.ASCIZ	/RKBA INCRMN TD WRONG ON WRT FMT/	
7479	026726	041516	046522	052116				
7480	026734	020104	051127	047117				
7481	026742	020107	047117	053440				
7482	026750	052122	043040	052115				
7483	026756	000						
7484								
7485	026757	122	042513	020122	EM61:	.ASCIZ	/RKER SET,ON WRT OR RD OR FMT/	
7486	026764	042523	026124	047117				
7487	026772	053440	052122	047440				
7488	027000	020122	042122	047440				
7489	027006	020122	046506	000124				
7490								
7491	027014	045522	041104	042440	EM62:	.ASCIZ	/RKDB EROR/	
7492	027022	047522	000122					
7493								





```

7718 031100 020122 051447 050103
7719 031106 000047
7720
7721 031110 045522 030461 042040 EM124: .ASCIZ /RK11 DIDN'T INTRUPT AFTER RD DONE/
7722 031116 042111 023516 020124
7723 031124 047111 051124 050125
7724 031132 020124 043101 042524
7725 031140 020122 042122 042040
7726 031146 047117 000105
7727
7728 031152 047103 051124 020114 EM125: .ASCIZ /CNTRL RESET DIDN'T CLR REGISTR/
7729 031160 042522 042523 020124
7730 031166 044504 047104 052047
7731 031174 041440 051114 051040
7732 031202 043505 051511 051124
7733 031210 000
7734
7735 031211 122 030513 020061 EM126: .ASCIZ /RK11 DIDN'T INTRUPT AT CPU LEVEL/
7736 031216 044504 047104 052047
7737 031224 044440 052116 052522
7738 031232 052120 040440 020124
7739 031240 050103 020125 042514
7740 031246 042526 000114
7741
7742 031252 045522 030461 044440 EM127: .ASCIZ /RK11 INTRUPTED AT WRONG CPU LEVEL/
7743 031260 052116 052522 052120
7744 031266 042105 040440 020124
7745 031274 051127 047117 020107
7746 031302 050103 020125 042514
7747 031310 042526 000114
7748
7749 031314 042447 051122 041040 EM130: .ASCIZ /'ERR BIT' DIDN'T SET IN RKER/
7750 031322 052111 020047 044504
7751 031330 047104 052047 051440
7752 031336 052105 044440 020116
7753 031344 045522 051105 000
7754
7755 031351 110 020105 051117 EM131: .ASCIZ /HE DR ERR DIDN'T SET/
7756 031356 042440 051122 042040
7757 031364 042111 023516 020124
7758 031372 042523 000124
7759
7760 031376 045522 051105 042440 EM132: .ASCIZ /RKER ERROR/
7761 031404 047522 000122
7762
7763 031410 054116 020103 044502 EM133: .ASCIZ /NXC BIT DIDN'T SET/
7764 031416 020124 044504 047104
7765 031424 052047 051440 052105
7766 031432 000
7767
7768 031433 122 030513 020061 EM134: .ASCIZ /RK11 DIDN'T INTRUPT ON SOFT ERROR/
7769 031440 044504 047104 052047
7770 031446 044440 052116 052522
7771 031454 052120 047440 020116
7772 031462 047523 052106 042440
7773 031470 047522 000122
    
```

```

7774
7775 031474 042515 020130 044502 EM135: .ASCIZ /MEX BITS INCRMNTD WRONG-RKCS/
7776 031502 051524 044440 041516
7777 031510 046522 052116 020104
7778 031516 051127 047117 026507
7779 031524 045522 051503 000
7780
7781 031531 127 051520 047040 EM137: .ASCIZ /WPS NOT CLEAR/
7782 031536 052117 041440 042514
7783 031544 051101 000
7784
7785 031547 104 052101 020101 EM140: .ASCIZ /DATA EROR ON TRANSFER FROM DISK TO TTY/
7786 031554 051105 051117 047440
7787 031562 020116 051124 047101
7788 031570 043123 051105 043040
7789 031576 047522 020115 044504
7790 031604 045523 052040 020117
7791 031612 052124 000131
7792
7793 031616 042047 044522 020126 EM141: .ASCIZ /'DRIV #' PRESENT, BUT NOT INDICATED/
7794 031624 023443 050040 042522
7795 031632 042523 052116 020054
7796 031640 052502 020124 047516
7797 031646 020124 047111 044504
7798 031654 040503 042524 000104
7799 031662 047040 020117 052502 EM142: .ASCIZ / NO BUSY ON OTHER HALF OF RK-05F/
7800 031670 054523 047440 020116
7801 031676 052117 042510 020122
7802 031704 040510 043114 047440
7803 031712 020106 045522 030055
7804 031720 043065 000
7805
7806
7807
7808
7809
7810 031724 .EVEN
7811
7812 .SBTTL ERROR DATA POINTERS
7813
7814 031724 001116 001162 000000 DT1: .WORD $ERRPC,$REG0,0
7815
7816 031732 001116 001162 001164 DT2: .WORD $ERRPC,$REG0,$REG1,0
7817 031740 000000
7818
7819 031742 001116 001162 001164 DT20: .WORD $ERRPC,$REG0,$REG1,$REG2,$REG3,0
7820 031750 001166 001170 000000
7821
7822 031756 001116 000000 DT21: .WORD $ERRPC,0
7823
7824 031762 001116 001162 001164 DT26: .WORD $ERRPC,$REG0,$REG1,$REG2,0
7825 031770 001166 000000
7826
7827 031774 001116 001162 001164 DT54: .WORD $ERRPC,$REG0,$REG1,$REG2,$REG3,$REG4,$REG5,$REG6,$REG7,0
7828 032002 001166 001170 001172
7829 032010 001174 001176 001200
    
```

7830 032016 000000  
7831  
7832  
7833  
7834  
7835  
7836  
7837 032020 020040 041520 020040 DH2: .ASCIZ / PC REGADD RECVD/  
7838 032026 051040 043505 042101  
7839 032034 020104 020040 051040  
7840 032042 041505 042126 000  
7841  
7842 032047 040 050040 020103 DH4: .ASCIZ / PC EXPCT RECVD/  
7843 032054 020040 042440 050130  
7844 032062 052103 020040 051040  
7845 032070 041505 042126 000  
7846  
7847 032075 040 050040 020103 DH5: .ASCIZ / PC RECVD/  
7848 032102 020040 051040 041505  
7849 032110 042126 000  
7850  
7851 032113 040 050040 020103 DH14: .ASCIZ / PC RKCS RKER RKWC/  
7852 032120 020040 051040 041513  
7853 032126 020123 020040 051040  
7854 032134 042513 020122 020040  
7855 032142 051040 053513 000103  
7856  
7857 032150 020040 041520 000 DH21: .ASCIZ / PC/  
7858  
7859 032155 040 050040 020103 DH30: .ASCIZ / PC RKCS RKER RKDS/  
7860 032162 020040 020040 045522  
7861 032170 051503 020040 020040  
7862 032176 045522 051105 020040  
7863 032204 020040 045522 051504  
7864 032212 000  
7865  
7866 032213 040 050040 020103 DH34: .ASCIZ / PC RKDS/  
7867 032220 020040 020040 045522  
7868 032226 051504 000  
7869  
7870 032231 040 050040 020103 DH35: .ASCIZ / PC SEC-CNTR/  
7871 032236 020040 042523 026503  
7872 032244 047103 051124 000  
7873  
7874 032251 040 050040 020103 DH36: .ASCIZ / PC PRSNT NXT-CNT/  
7875 032256 020040 020040 051120  
7876 032264 047123 020124 047040  
7877 032272 052130 041455 052116  
7878 032300 000  
7879  
7880 032301 040 050040 020103 DH40: .ASCIZ / PC SECTOR RKDS/  
7881 032306 020040 051440 041505  
7882 032314 047524 020122 020040  
7883 032322 045522 051504 000  
7884  
7885 032327 040 050040 020103 DH44: .ASCIZ / PC RKCS RKER RKDS RKDA/

7886 032334 020040 051040 041513  
7887 032342 020123 020040 051040  
7888 032350 042513 020122 020040  
7889 032356 051040 042113 020123  
7890 032364 020040 051040 042113  
7891 032372 000101  
7892  
7893 032374 020040 041520 020040 DH54: .ASCIZ / PC RKCS RKER RKDS RKDA DRV#...CYL.<DSK-ADRS>.SUR..SEC/  
7894 032402 020040 045522 051503  
7895 032410 020040 020040 045522  
7896 032416 051105 020040 020040  
7897 032424 045522 051504 020040  
7898 032432 020040 045522 040504  
7899 032440 020040 042040 053124  
7900 032446 027043 027056 041456  
7901 032454 046131 036056 051504  
7902 032462 026513 042101 051522  
7903 032470 027076 052523 027122  
7904 032476 051456 041505 000  
7905  
7906 032503 040 041520 020040 DH56: .ASCIZ / PC EXPC: DR# CYL SUR SEC REC: DR# CYL SUR SEC/  
7907 032510 054105 041520 020072  
7908 032516 051104 020043 020040  
7909 032524 054503 020114 020040  
7910 032532 020040 052523 020122  
7911 032540 020040 051440 041505  
7912 032546 020040 042522 053103  
7913 032554 020072 051104 020043  
7914 032562 020040 054503 020114  
7915 032570 020040 020040 052523  
7916 032576 020122 020040 020040  
7917 032604 042523 000103  
7918  
7919 032610 020040 041520 020040 DH64: .ASCIZ / PC RKWC RKDA/  
7920 032616 020040 045522 041527  
7921 032624 020040 051040 042113  
7922 032632 000101  
7923  
7924 032634 020040 041520 020040 DH66: .ASCIZ / PC SECTR EXPCT RECVD/  
7925 032642 020040 042523 052103  
7926 032650 020122 020040 054105  
7927 032656 041520 020124 020040  
7928 032664 042522 053103 000104  
7929  
7930 032672 020040 041520 020040 DH67: .ASCIZ / PC EXPCT RECVD DSK-ADRS/  
7931 032700 020040 054105 041520  
7932 032706 020124 020040 042522  
7933 032714 053103 020104 042040  
7934 032722 045523 040455 051104  
7935 032730 000123  
7936  
7937 032732 020040 041520 020040 DH74: .ASCIZ / PC DRIV #/  
7938 032740 020040 020040 051104  
7939 032746 053111 021440 000  
7940  
7941 032753 040 050040 020103 DH100: .ASCIZ / PC WORD # EXPCT RECVD/









CROSS REFERENCE TABLE -- USER SYMBOLS
INDX2 001360 1134# 2465\* 2469\* 3652\* 3664\* 5781\* 5872\* 5954 5975\*
IOTVEC= 000020 1001# 1837\* 1838\*
LF = 000012 907# 6846 6852
MSG1 001216 1084# 2045
MSG2 001236 1088# 2080
MSG3 001245 1091# 6570
MSG4 001272 1096# 2288 6724
MSG5 001303 1099# 6710
MSG6 001315 1102# 6728
NUDRV 005040 2250# 5824
ODDEVN 001406 1153# 5861\* 5910 5913 6055\* 6056
OUTBUF 033342 2788 2813 2855 2857 2909 2951 2953 3011 3053 3055 3141\* 3146 3237
3272 3274 3334 3409 3521\* 3525 3651 3781 3964 3968 3972 4014 4147
4160 4247 4253 4277 4324\* 4327 4365 4367 4372 4378 4380 4411 4418
4462 4464 4503 4789 4829 4831 4943 5319 5392 5402\* 5408 5461\* 5467
5525\* 5532 5677 5893 5898 5982 6013 8000#
2174# 7264
PHYDRV 001436 1180# 5850\* 5854\* 5981 6012
PIRQ = 177772 913#
PIRQVE= 000240 1007#
PR0 = 000000 930#
PR1 = 000040 931#
PR2 = 000100 932#
PR3 = 000140 933#
PR4 = 000200 934#
PR5 = 000240 935#
PR6 = 000300 936#
PR7 = 000340 937#
PS = 177776 910# 911 1894
PSW = 177776 911#
PWRVEC= 000024 1002# 1843\* 1844\* 7231\* 7232\* 7241\* 7247\* 7259\* 7260\*
RDCHR = 104410 7113 7207\*
RDLIN = 104411 1968 7208#
RESVEC= 000010 997#
RKBA 001335 1116# 2815 2908 3010 3146\* 3238\* 3272 3275 3358\* 3525\* 3653\* 3805\* 3964\*
4020\* 4086\* 4160\* 4195 4198 4253\* 4323 4418\* 4462 4465 4510\* 4534 4537
4784 4943\* 5085\* 5319\* 5406\* 5467\* 5532\* 5600\* 5678 5751
RKCS 001332 1114# 2327\* 2608 2668 2741\* 2814 2907 3008 3120 3152 3233 3240\* 3242
3331 3529\* 3531 3660\* 3662 3610\* 3812 3900 4002 4132 4172 4256\* 4258
4320 4409 4501 4612 4672 4782 4861 4946\* 4949 4967 5019\* 5035 5083
5088 5151 5220 5315 5379 5460 5537\* 5566\* 5579 5666 5758\* 5866 6133
6265 6340 6342 6343 6392\* 6523 6559\* 6563 6583 7283\*
RKDA 001340 1117# 1818\* 2042 2051\* 2052 2201\* 2321\* 2367\* 2404\* 2416\* 2456\* 2544\* 2567\*
2610\* 2669\* 2738\* 2739\* 2818\* 2913\* 3015\* 3122 3235 3357\* 3527\* 3658\* 3694
3699 3808\* 3922\* 3957 3960 3963\* 4018\* 4078 4081 4087\* 4161\* 4254\* 4322
4419\* 4456 4459 4511\* 4673\* 4680\* 4749\* 4783 4862\* 4944\* 5017\* 5086\* 5154\*
5241\* 5252 5316\* 5317\* 5407\* 5458\* 5486 5491 5533\* 5551 5556 5599\* 5683\*
5697\* 5757\* 5828 6130 6284 6290 6306 6360\* 6391\* 6425\* 7282\*
RKDB 001342 1118# 3084 3087 3099 3101 3102 3181 3186 3462 3464 3465 3854 3857
RKDS 001326 1112# 1820 2041 2063 2202 2320 2345 2368 2377 2380 2405 2418 2422
2457 2505 2542 2569 2619 2630 2679 2685 2740 2845 2846 2847 2848 2849 2850
4051 4273 4540 4725 4750 4752 5157 5965 5983 6131 6362 6366 6399
6426 7287
RKER 001330 1113# 2699 3902 4344 4346 4438 4961 5016 5098 5168 5249 5328 5339
5414 5476 5480 5623 5629 6132 6316 6329 6331 6332
RKPRI 001400 1144# 1897\* 4865 5945 6487

CROSS REFERENCE TABLE -- USER SYMBOLS
RKVEC 001402 1149# 2108\* 4613 4631\* 4643\* 4677 4688\* 4697\* 4707\* 4718\* 4790 4798\* 4806\*
4869 4895\* 4904\* 5534 5548\* 5942
RKWC 001334 1115# 2817\* 2912\* 3014\* 3148\* 3239\* 3359\* 3526\* 3655\* 3807\* 3965\* 4019\* 4085\*
4159\* 4252\* 4321 4417\* 4448 4450 4509\* 4787\* 4942\* 4955 5084\* 5093 5318\*
5405\* 5466\* 5531\* 5598\* 5680\* 5696\* 5755\* 6302 6305
1141# 3896 3985
SEEK0 001372 1142#
SEEK1 001374 1143#
SEEK2 001376 1143# 3980
SHFTRT 021200 2290 4731 4734 5999 6018 6228# 6717 6726
SIMUL 001344 1125# 2030\* 3335 3433 3622 3732 3785 3866 4000
SIZEF 025304 5849 7295#
SIYET = 001440 1181# 2027\* 2039\* 5847\*
STACK = 001100 901# 1835
START 002636 1018 1814# 2127 2164
STARTA 002704 1817 1821 1828#
START1 003334 1891 1905#
STKLMT = 177774 912#
ST2 003736 1911 1935 1959# 1992
ST3 004262 1922 1933 2039#
ST4 004456 2031 2034 2078 2081 2096# 6096
SWR 001140 1056# 1833 1854\* 1858 1862\* 1876 2028 2138 2152 2157 6187 6431 6567
6611 6625 6627 6633 6640 6678 6688 6692 6696 6699 7009 7046\* 7239
7252\*
1016# 1862 1876 7009 7022
965# 965
954# 964
953# 963
952# 962
951# 961
950# 960
949# 959
948# 958
947# 957
946# 956 6699
964#
945# 2028
944#
943# 6696
942# 6431 6567 6686
941#
940#
963#
962#
961#
960#
959#
958#
957#
956#
955#
954#
1137# 6361\* 6364\* 6456\* 6459\* 6484\* 6490\* 6522\* 6525\*
1005#
1005#
1004# 1841\* 1842\*
999#



Table with columns for symbols (e.g., \$MAIL, \$MNEW) and their corresponding reference numbers. Includes entries like \$MONT, \$MOWE, \$MVER, \$MPASS, etc.

Table with columns for symbols (e.g., \$\$AVRE, \$\$AVRE, \$\$CODE) and their corresponding reference numbers. Includes entries like \$\$STUP, \$\$VLAD, \$\$VPC, \$\$SWR, etc.

4055	4617	4879	5887	5889	5896	5994	6097	6101	6152#	6403	6436#	6582#
6657	6658	6691	6697	6780#	6852	6919#	7002	7159#	7160	7166	7243	7267
7810#	7997#	8000#										

COMMEN	1#	1008#													
ENDCOM	1#	1008#													
ERROR	902#	2212	2223	2325	2336	2346	2372	2378	2383	2408	2423	2501	2506	2512	2519
	2558	2577	2581	2614	2627	2633	2638	2645	2674	2684	2688	2697	2702	2708	2735
	2747	2751	2824	2836	2843	2849	2853	2859	2863	2869	2919	2932	2938	2944	2949
	2955	2959	2967	2973	3021	3034	3041	3047	3051	3057	3061	3069	3088	3095	3103
	3162	3168	3177	3187	3251	3258	3267	3276	3280	3289	3297	3303	3372	3379	3392
	3397	3421	3450	3466	3540	3549	3554	3561	3672	3684	3689	3702	3717	3728	3821
	3831	3835	3845	3858	3927	3937	3942	3946	3954	3961	3973	4037	4069	4075	4082
	4104	4168	4181	4189	4199	4204	4208	4212	4218	4267	4289	4333	4337	4342	4347
	4354	4362	4369	4381	4426	4430	4436	4441	4452	4460	4466	4473	4525	4529	4538
	4552	4568	4622	4640	4675	4690	4701	4710	4723	4736	4753	4760	4770	4810	4817
	4821	4833	4886	4912	4957	4965	4970	4985	4989	4992	5031	5038	5053	5057	5094
	5102	5107	5122	5126	5130	5172	5187	5201	5205	5209	5238	5255	5253	5258	5261
	5273	5288	5294	5333	5340	5347	5362	5366	5412	5418	5423	5428	5432	5472	5481
	5492	5542	5557	5586	5608	5618	5630	5694	5710	5724	5753	5761	5773	5802	5819
	5926	5962	5969	6003	6021	7274	7292								
ESCAPE	1#	1008#													
GETPRI	1#	1008#													
GETSWR	1#	852#	1008#	1873#											
MESSAGE	2177#	2180	2253#	2255	2410#	2412	2427#	2430	2524#	2527	2588#	2590	2648#	2650	2711#
	2713	2760#	2762	2872#	2874	2978#	2981	3105#	3107	3200#	3202	3308#	3311	3470#	3472
	3594#	3597	3753#	3756	3885#	3888	3989#	3992	4110#	4113	4221#	4224	4300#	4303	4387#
	4389	4475#	4477	4587#	4589	4651#	4653	4762#	4764	4836#	4838	4918#	4920	4995#	4997
	5060#	5062	5132#	5134	5212#	5214	5297#	5299	5369#	5371	5435#	5437	5502#	5505	5568#
	5571	5637#	5639	5731#	5734	5791#	5793	5806#	5808	5828#	5831				
MORETA	1029#	1084													
MULT	1#	1008#													
NEWTST	1#	1008#	2178	2253	2306	2353	2390	2410	2428	2525	2562	2588	2648	2711	2760
	2872	2979	3105	3200	3309	3470	3595	3754	3886	3990	4111	4222	4301	4387	4475
	4587	4651	4762	4836	4918	4995	5060	5132	5212	5297	5369	5435	5503	5569	5637
	5732	5791	5806	5829											
POP	1#	1008#	6906	7252	7253										
PRIOR7	1198#	4608	4645	4743	4824	4897	5561	5662	5899						
PUSH	1#	1008#	6865	7233	7239										
REPORT	1#	1008#													
SCOPE	903#	2192	2259	2309	2356	2393	2415	2445	2530	2565	2597	2655	2721	2775	2893
	2995	3119	3219	3328	3497	3614	3777	3894	3998	4119	4233	4307	4396	4488	4595
	4660	4768	4846	4926	5003	5069	5138	5219	5304	5378	5447	5512	5578	5647	5742
	5797	5814	5845	6072											
SETPRI	1#	1008#													
SETTRA	7190#	7199	7200	7201	7202	7204	7206	7207	7208	7210	7212	7214	7216	7218	7220
	7222	7224													
SETUP	1#	1008#	1828												
SKIP	1#	1008#	2341	2381	2406	2419	2481	2503	2508	2515	2554	2579	2642	2705	2866
	2970	3100	3300	3463	3733	3749	3867	4001	4100	4215	4274	4294	4376	4470	4541
	4559	4584	4758	4830	4901	5163	5291	5489	5659	5717					
SLASH	1#	1008#													
SPACE	1008#														
STARS	1#	1008#	1021	1031	1083	2178	2191	2253	2258	2306	2308	2353	2355	2390	2392
	2410	2414	2428	2444	2525	2529	2562	2564	2588	2596	2648	2654	2711	2720	2760
	2774	2872	2892	2979	2994	3105	3118	3200	3218	3309	3327	3470	3496	3595	3613
	3754	3776	3886	3893	3990	3997	4111	4118	4222	4232	4301	4306	4387	4395	4475
	4487	4587	4594	4651	4659	4762	4767	4836	4845	4918	4925	4995	5002	5060	5068
	5132	5137	5212	5218	5297	5303	5369	5377	5435	5446	5503	5511	5569	5577	5637
	5646	5732	5741	5791	5796	5806	5813	5829	5844	6064	6597	6736	6784	6855	6923

	7001	7004	7072	7101	7169	7229	7245									
SXRSU	1#	1008#	1850#													
TRMTRP	7190#															
TYPBIN	1#	1008#														
TYPDEC	1#	1008#	6084													
TYPNAM	1#	852#	1008#	1868												
TYPNUM	1#	1008#														
TYPOCS	1#	1008#														
TYPOCT	1#	1008#	6748	6772	7022											
TYPTXT	1#	1008#	1923	1936	1945	1949	1964	1987	2120	2145	2299	6148	6433	6571	6579	
SSCMRE	1029#	1068	1069	1070	1071	1072	1073	1074	1075	1076	1077					
SSCMTM	1029#															
SSESCA	1#	1008#														
SSNEWT	1#	1008#	2178	2253	2306	2353	2390	2410	2428	2525	2562	2588	2648	2711	2760	
	2872	2979	3105	3200	3309	3470	3595	3754	3886	3990	4111	4222	4301	4387	4475	
	4587	4651	4762	4836	4918	4995	5060	5132	5212	5297	5369	5435	5503	5569	5637	
	5732	5791	5806	5829												
SSSET	7190#	7199	7200	7201	7202	7204	7206	7207	7208	7210	7212	7214	7216	7218	7220	
	7222	7224														
SSSKIP	1#	1008#	2341	2381	2406	2419	2481	2503	2508	2515	2554	2579	2542	2705	2866	
	2970	3100	3300	3463	3733	3749	3867	4001	4100	4215	4274	4294	4376	4470	4541	
	4559	4584	4758	4830	4901	5163	5291	5489	5659	5717						
.EQUAT	1#	852#	898													
.HEADE	1#	852#	861													
.KT11	1#															
.SETUP	1#	852#	1814													
.SWRHI	1#	852#	873													
.SWRLD	852#	885#														
.\$ACT1	1#	852#	1019													
.\$APTB	1#															
.\$APTH	1#															
.\$APTY	1#															
.\$ASTA	1#															
.\$CATC	1#	852#	1008													
.\$CHTA	1#	852#	1029													
.\$DB2D	1#															
.\$DB2O	1#															
.\$DIV	1#															
.\$EOP	1#	852#	6062													
.\$ERRO	1#															
.\$ERRT	1#	852#	6734													
.\$MULT	1#															
.\$POVE	1#	852#	7227													
.\$RAND	1#															
.\$RDDE	1#	852#														
.\$RDOC	1#															
.\$READ	1#	852#	6999													
.\$R2AZ	1#															
.\$SAVE	1#															
.\$SB2D	1#															
.\$SB2O	1#															
.\$SCOP	1#	852#	6595													
.\$SIZE	1#															
.\$SUPR	1#															
.\$TRAP	1#	852#	7167													
.\$TYPB	1#															

.\$TYPD	1#	852#	6853
.\$TYPE	1#	852#	6782
.\$TYPD	1#	852#	6921
.\$40CA	1#		
.1170	1#		

. ABS. 034342 000

ERRORS DETECTED: 0

CZRKKF,CZRKKF.LST/CRF/SOL=CZRKKF.SML,CZRKKF.P11  
RUN-TIME: 22 31 1 SECONDS  
RUN-TIME RATIO: 392/55=7.0  
CORE USED: 34K (67 PAGES)